



scope Commands

- [scope](#), on page 3
- [scope adapter](#), on page 5
- [scope app-software](#), on page 6
- [scope auto-install](#), on page 7
- [scope auto-macpool](#), on page 8
- [scope banner](#), on page 10
- [scope cabling](#), on page 11
- [scope callhome](#), on page 12
- [scope card](#), on page 13
- [scope cfg-export-policy](#), on page 14
- [scope cfg-export-reminder](#), on page 15
- [scope chassis](#), on page 16
- [scope cimc](#), on page 17
- [scope cloud-connector](#), on page 18
- [scope default-auth](#), on page 19
- [scope environment-features](#), on page 20
- [scope eth-uplink](#), on page 21
- [scope eth-server](#), on page 22
- [scope export-config](#), on page 23
- [scope fabric](#), on page 24
- [scope fabric-interconnect](#), on page 26
- [scope fan-module](#), on page 27
- [scope faulty-policy](#), on page 28
- [scope firmware](#), on page 29
- [scope firmware-install](#), on page 30
- [scope flow-control](#), on page 31
- [scope health monitoring policy](#), on page 32
- [scope hw-crypto](#), on page 34
- [scope import-config](#), on page 36
- [scope info-policy](#), on page 37
- [scope interface](#), on page 38
- [scope ipsec](#), on page 40
- [scope ipv6-config](#), on page 41

- [scope ldap](#), on page 42
- [scope licdebug](#), on page 43
- [scope license](#), on page 44
- [scope mem-leak-logging](#), on page 45
- [scope monitoring](#), on page 46
- [scope network-features](#), on page 47
- [scope org](#), on page 48
- [scope packet-capture](#), on page 49
- [scope password-profile](#), on page 50
- [scope profile](#), on page 51
- [scope qos](#), on page 52
- [scope radius](#), on page 53
- [scope reservation](#), on page 54
- [scope security](#), on page 55
- [scope server](#), on page 56
- [scope server-features](#), on page 57
- [scope service-profile](#), on page 58
- [scope services](#), on page 59
- [scope slot](#), on page 60
- [scope ssa](#), on page 61
- [scope stats-collection-policy](#), on page 62
- [scope stats-threshold-policy](#), on page 64
- [scope storage-features](#), on page 66
- [scope system](#), on page 67
- [scope tacacs](#), on page 68
- [scope telemetry](#), on page 69
- [scope vnic](#), on page 70
- [sub scopes \(scope fabric-interconnect\)](#), on page 71

scope

To “scope into” (enter) an existing managed object, use the relevant **scope** command in the appropriate command mode.

scope *object_type* *name* [*parameters*]

Syntax Description	<table><tr><td><i>object_type</i></td><td>The type of object to be entered. Examples include local user account and organization.</td></tr><tr><td><i>name</i></td><td>The name of the specific object to be entered.</td></tr><tr><td><i>parameters</i></td><td>(Optional) Any additional properties or parameters needed to identify the object. With this command, the <i>name</i> is generally sufficient to identify an object. Refer to the description of the create command for the specific object type for more information.</td></tr></table>	<i>object_type</i>	The type of object to be entered. Examples include local user account and organization.	<i>name</i>	The name of the specific object to be entered.	<i>parameters</i>	(Optional) Any additional properties or parameters needed to identify the object. With this command, the <i>name</i> is generally sufficient to identify an object. Refer to the description of the create command for the specific object type for more information.
<i>object_type</i>	The type of object to be entered. Examples include local user account and organization.						
<i>name</i>	The name of the specific object to be entered.						
<i>parameters</i>	(Optional) Any additional properties or parameters needed to identify the object. With this command, the <i>name</i> is generally sufficient to identify an object. Refer to the description of the create command for the specific object type for more information.						
Command Modes	Depends on the type of object being scoped into; refer to the description of the create command for the specific object type for more information.						
Command History	Refer to the description of the create command for the specific object type for history information.						
Usage Guidelines	<p>Objects are abstract representations of physical components or logical entities that can be managed. For example, the chassis, security modules, network modules, ports, and processors are physical components represented as managed objects, while licenses, user roles, and platform policies are logical entities represented as managed objects.</p> <p>FXOS provides four general commands for managing objects: create, delete, enter, and scope. For example, you can create a local user account, you can delete a local user account, and you can enter a local user account to assign or change properties for that account; you also can “scope into” the local user account to assign or change properties.</p> <p>Generally, the keywords and options available to each of these object-management commands are the same, so we detail only the create version of the various object commands. In other words, for information about the delete command for a particular object, refer to the description of the create command for that object. For example, refer to create local-user for information related to scoping into an existing local user account.</p>						

Example

This example shows how to enter security mode, scope into a local user account and display account details:

```
firepower # scope security
firepower /security # scope local-user test_user
firepower /security/local-user # show detail
Local User test_user:
  First Name: test
  Last Name: user
  Email: test_user@testuser.com
  Phone:
  Expiration: Never
  Password: ****
```

```
User lock status: Not Locked
Account status: Active
User Roles:
  Name: admin
  Name: read-only
User SSH public key:
firepower /security/local-user #
```

Related Commands

Command	Description
create local-user	Creates a new local user account.
enter local-user	Adds or edits a local user account.
delete local-user	Deletes an existing local user account.

scope adapter

To enter adapter mode, use the **scope adapter** command.

scope adapter {*rack_server/id* | *chassis/server/id*}

Syntax Description	<i>rack_server/id</i>	The adapter location specified using the rack-server and adapter IDs entered in n/n format.
	<i>chassis/server/id</i>	The adapter location specified using the chassis, server and adapter IDs entered in n/n/n format. Note The chassis ID is always 1.
Command Modes	EXEC mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	In adapter mode, you can activate or update a firmware version, view a variety of adapter-specific data, and scope into host and external Ethernet interfaces.	

Example

This example shows how to enter adapter mode using the chassis, server and adapter IDs:

```
firepower# scope adapter 1/1/1
firepower /chassis/server/adapter #
```

Related Commands	Command	Description
	connect adapter	Connects to the command shell for a specific adapter.
	scope chassis	Enters chassis mode.

scope app-software

To enter application software mode, use the **scope app-software** command.

scope app-software

Syntax Description

This command has no arguments or keywords.

Command Modes

scope ssa/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You can use the **download image** command in application software mode to copy a logical device software image to the Firepower 4100/9300 chassis.

Example

This example shows how to enter application software mode:

```
firepower# scope ssa
firepower /ssa # scope app-software
firepower /ssa/app-software #
```

Related Commands

Command	Description
download image	Copies a logical device software image to the Firepower 4100/9300 chassis.
show download-task	Shows progress of the image file download.

scope auto-install

To enter automatic installation mode for infrastructure updates, use the **scope auto-install** command.

scope auto-install

Syntax Description

This command has no arguments or keywords.

Command Modes

Firmware (/firmware) mode

Command History

Release	Modification
1.4(1)	Command added.

Usage Guidelines

None

Example

This example shows how to enter firmware mode and then auto-install mode:

```
FP9300-A# scope firmware
FP9300-A /firmware # scope auto-install
FP9300-A /firmware/auto-install #
```

Related Commands

Command	Description
install platform	Upgrades UCS Infra components (UCSM, FI and IOM) to infra version specified.

scope auto-macpool

To manage the MAC address pool for container instance interface , use the **scope auto-macpool** command.

scope auto-macpool

Syntax Description

This command has no arguments or keywords.

Command Modes

scope ssa/

Command History

Release	Modification
2.4(1)	Command added.

Usage Guidelines

The FXOS chassis automatically generates MAC addresses for container instance interfaces, and guarantees that a shared interface in each instance uses a unique MAC address.

If you manually assign a MAC address to a shared interface within the application, then the manually-assigned MAC address is used. If you later remove the manual MAC address, the autogenerated address is used. In the rare circumstance that the generated MAC address conflicts with another private MAC address in your network, we suggest that you manually set the MAC address for the interface within the application.

Because autogenerated addresses start with A2, you should not start manual MAC addresses with A2 due to the risk of overlapping addresses.



Note Even if you are not sharing a subinterface, if you manually configure MAC addresses, make sure you use unique MAC addresses for all subinterfaces on the same parent interface to ensure proper classification.

The FXOS chassis generates the MAC address using the following format:

A2xx.yyzz.zzzz

Where xx.yy is a user-defined prefix or a system-defined prefix, and zz.zzzz is an internal counter generated by the chassis. The system-defined prefix matches the lower 2 bytes of the first MAC address in the burned-in MAC address pool that is programmed into the IDPROM. Use **connect fxos**, then **show module** to view the MAC address pool. For example, if the range of MAC addresses shown for module 1 is b0aa.772f.f0b0 to b0aa.772f.f0bf, then the system prefix will be f0b0.

The user-defined prefix is an integer that is converted into hexadecimal. For an example of how the user-defined prefix is used, if you set a prefix of 77, then the chassis converts 77 into the hexadecimal value 004D (yyxx). When used in the MAC address, the prefix is reversed (xxyy) to match the chassis native form:

A24D.00zz.zzzz

For a prefix of 1009 (03F1), the MAC address is:

A2F1.03zz.zzzz

Example

This example shows how to enter mac-pool mode:

```
firepower# scope ssa
firepower /ssa # scope auto-macpool
firepower /ssa/auto-macpool #
```

Related Commands

Command	Description
scope ssa	Enters ssa mode.
set prefix	Sets the MAC address prefix.
show mac-address	Shows the assigned MAC addresses.

scope banner

To enter banner-management mode, use the **scope banner** command.

scope banner

Syntax Description	This command has no arguments or keywords.	
Command Modes	scope security/	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	In this mode, you can manage the banner presented by the appliance prior to user log-in.	

Example

This example shows you how to enter banner mode and view the current pre-login banner:

```
firepower # scope security
firepower /security # scope banner
firepower /security/banner # show pre-login-banner

Pre login banner:
  Message
  -----
  Firepower-9300-2
  Western Data Center

firepower /security/banner #
```

Related Commands	Command	Description
	clear message	Removes the text from an existing pre-login banner; the actual banner object itself is not deleted.
	create pre-login-banner	Creates a banner to be presented prior to the log-in screen; the banner object is initially empty.
	set message	Adds or replaces the lines of text presented as the pre-login banner.

scope cabling

To enter cabling mode, use the **scope cabling** command.

scope cabling

Syntax Description	This command has no arguments or keywords.	
Command Modes	EXEC mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	You can access fabric mode from cabling mode, where you can view and manage port breakouts.	

Example

This example shows how to enter cabling mode:

```
FP9300-A # scope cabling
FP9300-A /cabling #
```

Related Commands	Command	Description
	scope fabric-interconnect	Enter fabric interconnect mode.

scope callhome

To enter callhome mode, use the **scope callhome** command.

scope callhome

Syntax Description

This command has no arguments or keywords.

Command Modes

Monitoring mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object.

Example

This example shows how to enter callhome mode from monitoring mode:

```
FP9300-A#scope monitoring
FP9300-A /monitoring # scope callhome
FP9300-A /monitoring/callhome #
```

Related Commands

Command	Description
show callhome	Shows Call Home configuration and status information.

scope card

To enter administrative mode for a specific fabric card, use the **scope card** command.

scope card *card_ID*

Syntax Description	<i>card_ID</i>	The fabric card's numeric identifier.
Command Modes	scope fabric-interconnect/	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	In card mode, you can take the fabric card offline or online.	

Example

This example shows how to enter card mode and view available commands:

```
firepower# scope fabric-interconnect
firepower /fabric-interconnect # scope card 2
firepower /fabric-interconnect/card # ?
  acknowledge  Acknowledge
  scope        Changes the current mode
  set          Set property values
  show         Show system information

firepower /fabric-interconnect/card #
```

Command	Description
set adminstate	Takes a fabric card offline or online.

scope cfg-export-policy

To enter the configuration export policy, use the **scope cfg-export-policy** command.

scope cfg-export-policy*name*

Syntax Description	<i>name</i>	The name of the configuration export policy to enter.
		You cannot create or delete a configuration export policy. You can only configure the existing default policy; enter default as the policy name.
Command Modes	scope org/	
Command History	Release	Modification
	2.0.1	Command added.
Usage Guidelines	You cannot create or delete a configuration export policy; you can only configure the existing default policy.	

Example

This example shows how to enter the configuration export policy and view the details of its current settings:

```
firepower # scope org
firepower /org # scope cfg-export-policy default
firepower /org/cfg-export-policy # show detail
Config Export policy:
  Name: default
  Description: Configuration Export Policy
  Admin State: Enable
  Protocol: Ftp
  Hostname: 192.168.1.2
  User: user1
  Remote File: /export/cfg-backup.xml
  Schedule: Daily
  Port: Default
  Current Task:
firepower /org/cfg-export-policy #
```

Related Commands	Command	Description
	export-config	Exports the current system configuration to a remote server as an XML file; creates an export-configuration object.
	import-config	Copies a previously exported XML configuration file to this appliance.
	set password-encryption-key	Specifies a key used when encrypting sensitive information during configuration export.

scope cfg-export-reminder

To enter the configuration-export reminder object, use the **scope cfg-export-reminder** command.

scope cfg-export-reminder

Syntax Description	This command has no arguments or keywords.	
Command Modes	scope org/	
Command History	Release	Modification
	2.0.1	Command added.
Usage Guidelines	You cannot create or delete a configuration-export reminder object; you can only configure the existing reminder object.	

Example

This example shows how to enter the configuration-export reminder object and view its current settings:

```
firepower # scope org
firepower /org # scope cfg-export-reminder
firepower /org/cfg-export-reminder # show
```

```
Config Export Reminder:
  Config Export Reminder (Days): 30
  AdminState: Enable
firepower /org/cfg-export-reminder #
```

Related Commands	Command	Description
	import-config	Copies a previously exported XML configuration file to this appliance.
	scope cfg-export-policy	Enters the configuration export policy.
	set password-encryption-key	Specifies a key used when encrypting sensitive information during configuration export.

scope chassis

To enter chassis mode, use the **scope chassis** command.

scope chassis *chassis_id*

Syntax Description	<i>chassis_id</i>	Chassis identification number. This value is always 1 .
Command Modes	EXEC mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter chassis mode:

```
firepower# scope chassis 1
firepower /chassis #
```

Related Commands	Command	Description
	show chassis	Shows chassis information.

scope cimc

To enter cimc mode, use the **scope cimc** command.

scope cimc

Syntax Description	This command has no arguments or keywords.	
Command Modes	scope chassis, scope server.	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object.	

Example

This example shows how to enter cimc mode:

```
tb-03# scope chassisss
tb-03 /chassis # scope server
tb-03 /chassis/server # scope cimc
tb-03 /chassis/server/cimc #
```

Related Commands	Command	Description
	Acknowledge	Acknowledge
	Activate	Activate component with specified image version.
	Create	Create managed objects.
	Delete	Delete managed objects.
	Enter	Enters a managed object.
	Reset	Reset managed objects.
	Scope	Changes the current mode.
	Show	Show system information.
	Update	Update backup firmware with specified image version.

scope cloud-connector

To enter cloud connector mode, use the **scope cloud-connector** command.

scope cloud-connector

Syntax Description	This command has no arguments or keywords.	
Command Modes	EXEC mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter cloud connector mode:

```
FP9300-A # scope cloud-connector
FP9300-A /cloud-connector #
```

Related Commands	Command	Description
	show cloud-connector	Shows cloud connector configuration information.

scope default-auth

To enter default authentication mode, use the **scope default-auth** command.

scope default-auth

Syntax Description

This command has no arguments or keywords.

Command Modes

Security mode

Authentication domain (/security/auth-domain)

Command History

Release	Modification
1.4(1)	Command added.

Usage Guidelines

Use the **set** commands in this mode to configure default authentication parameters such as authentication service and session timeout values.

An authentication domain must be created prior to using this command to enter the default authentication mode for a domain.

Example

This example shows how to enter security mode and then default authentication mode:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth #
```

Related Commands

Command	Description
set realm	Sets the default authentication service.
show	Shows default authentication settings.

scope environment-features

To enter environment features in configuration mode, use the **scope environment-features** command.

scope environment-features

Syntax Description

This command has no arguments or keywords.

Command Modes

Scope system

Command History

Release

Modification

2.3.1

Command added.

Usage Guidelines

You do not have to enter this mode with a managed object

Example

This example shows how to enter environment features mode:

```
firepower # scope system
firepower /system # scope environment-features
firepower /system/environment-features # show
```

Related Commands

Command	Description
show	Shows the information about the domain environment features.

scope eth-uplink

To enter Ethernet uplink mode, use the **scope eth-uplink** command.

scope eth-uplink

Syntax Description	This command has no arguments or keywords.	
Command Modes	EXEC mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object.	

Example

This example shows how to enter Ethernet uplink mode:

```
firepower#scope eth-uplink
firepower /eth-uplink #
```

Related Commands	Command	Description
	show	Shows Ethernet uplink information.

scope eth-server

To enter Ethernet server mode, use the **scope eth-server** command.

scope eth-server

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC mode

Command History

Release	Modification
2.3.1	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object.

Example

This example shows how to enter ethernet server mode:

```
firepower#scope eth-server
firepower /eth-server #
```

Related Commands

Command	Description
show	Shows Ethernet server information.

scope export-config

To enter an existing export-configuration object, use the **scope export-config** command.

scope export-config*hostname*

Syntax Description	<i>hostname</i>	The identifier of the export-configuration object; this is the name or IP address of the remote server on which the configuration was backed up.
Command Modes	scope system/	
Command History	Release	Modification
	1.1.1(1)	Command added.
Usage Guidelines	An export-configuration object is created when you issue an export-config command to back up the current logical device and platform configuration, and scope export-config is used to enter the object and edit its parameters—there are no create or enter commands associated with export-configuration objects. There is a delete command available which you can use to delete an export-configuration object.	

Example

This example shows how to scope into a previously exported configuration object:

```
firepower # scope system
firepower /system # scope export-config 192.168.1.2
firepower /system/export-config #
```

Related Commands	Command	Description
	cfg-export-policy	Configures a configuration export policy.
	delete export-config	Deletes an existing export-configuration object.
	export-config	Exports the current system configuration to a remote server as an XML file; creates an export-configuration object.

scope fabric

To enter fabric mode, use the **scope fabric** command.

scope fabric [**a**]

Syntax Description	a	Specifies Fabric A. There is only one fabric on Firepower devices. Use of this keyword is optional.
Command Modes	scope eth-uplink, scope eth-server	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	In fabric mode, you can manage interfaces, port-channels, aggregate interfaces, and VLANs.	

Example

This example shows how to enter fabric mode:

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric #
```

```
firepower# scope eth-server
firepower /eth-server # scope fabric
firepower /eth-server/fabric #
```

Related Commands	Command	Description
	show interface	In fabric mode, lists information for all device interfaces.
	show port-channel	In fabric mode, lists information and status for all port-channels.
	show fabric-port-channel	In fabric mode, lists information and status for all port channels.
	show fault	In fabric mode, lists all the faults.
	show detail	It displays the fabric information
	show event	It displays fsm event information
	show expand	It displays expanded fabric information. The detail key word is available with this option.

Command	Description
show fsm	It displays fsm information for the current application, according to the specified keyword. Status: displays fsm status information. Task: displays fsm task information
show interface	It displays ethernet interface status.

scope fabric-interconnect

To enter fabric interconnect mode, use the **scope fabric-interconnect** command.

scope fabric-interconnect a

Syntax Description	a	Specifies Fabric A. There is only one fabric on Firepower devices.
Command Modes	EXEC mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter fabric interconnect mode:

```
firepower# scope fabric-interconnect a
firepower /fabric-interconnect #
```

Related Commands	Command	Description
	show fabric-interconnect	Shows fabric interconnect information.

scope fan-module

To enter a specific fan module, use the **scope fan-module** command in chassis mode.

scope fan-module { **1** *module_id* }

Syntax Description	<i>tray_id</i>	The <i>tray_id</i> is always 1.
	<i>module_id</i>	Identifies the specific fan module to enter; value can be 1 through 8.
Command Modes	scope chassis/	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to scope into fan-module mode:

```
firepower# scope chassis
firepower /chassis # scope fan-module 1 2
firepower /chassis/fan-module #
```

Related Commands	Command	Description
	scope fan	Scopes into a specific fan.

scope faulty-policy

To enter the fault policy for one of the functional areas of the system, use the **scope faulty policy** command.

scope faulty policy

Syntax Description

This command has no arguments or keywords.

Command Modes

scope monitoring

Command History

Release	Modification
2.3.1	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object

Related Commands

Command	Description
Show detail	Shows the detailed fault policy information of the system.
Set Ack-action	Specifies acknowledge action.
Set Clear-action	Specifies Clear action.
Set Clear-interval	Specifies Clear interval.
Set Flap-interval	Specifies Flap interval.
Set Retention-interval	Specifies Retention interval. (dd:hh:mm:ss)

scope firmware

To enter firmware mode, use the **scope firmware** command.

scope firmware

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC mode

Command History

Release	Modification
---------	--------------

1.1(1)	Command added.
--------	----------------

Usage Guidelines

You do not have to enter this mode with a managed object.

Example

This example shows how to enter firmware mode:

```
firepower# scope firmware
firepower /firmware #
```

Related Commands

Command	Description
show server firmware	Shows server firmware information.
show server version	Shows server firmware version.

scope firmware-install

To enter firmware-installation mode, use the **scope firmware-install** command.

scope firmware-install

Syntax Description	This command has no arguments or keywords.	
Command Modes	Firmware mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	Use this scope to update system firmware with a previously downloaded firmware package.	

Example

This example shows how to enter firmware-installation mode:

```
FP9300-A# scope firmware
FP9300-A /firmware # scope firmware-install
FP9300-A /firmware-install #
```

Related Commands	Command	Description
	download image	Downloads a firmware package.
	install firmware	Installs a firmware package.

scope flow-control

To enter flow-control mode, use the **scope flow-control** command.

scope flow-control

Syntax Description

This command has no arguments or keywords.

Command Modes

scope eth-uplink/

Command History

Release	Modification
1.1.1	Command added.

Usage Guidelines

Flow-control policies determine whether the Ethernet ports send and receive IEEE 802.3x pause frames when the receive buffer for a port fills. These pause frames request that the transmitting port stop sending data for a few milliseconds until the buffer clears. For flow control to work between devices, you must enable the corresponding send and receive flow-control parameters for both devices.

The `default` flow-control policy disables send and receive control, and sets the priority to auto-negotiate.

Example

The following example shows how to scope into flow-control mode and view current policy information:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope flow-control
firepower /eth-uplink/flow-control # show policy detail
Flowctrl policy:
  Name: default
  receive: Off
  send: Off
  Prio: Auto
firepower /eth-uplink/flow-control #
```

Related Commands

Command	Description
create policy	Adds a new named flow-control policy.
set	In flow-control/policy mode, sets flow-control policy properties.
show policy	Shows property values for a flow-control policy.

scope health monitoring policy

Memory usage metrics

Memory stats collected can be enabled or disabled using the cli under **scope** 'stats-collection-memory'. By default, it is enabled.

Also fault threshold can be set for all memory monitoring faults. The threshold-value can range between 50-99. By default, it is set at 95%.

```
scope health-monitoring-policy
scope stats-collection-memory
enable | disable
set fault-threshold <threshold-value>
```

Command Modes	Monitoring mode	
Command History	Release	Modification
	2.11.1	This command was introduced.
Usage Guidelines	This command enables or disables memory monitoring and also changes the fault threshold value for all the memory monitoring faults.	

Example

```
firepower# scope monitoring
firepower /monitoring # scope health-monitoring-policy
firepower /monitoring/health-monitoring-policy # scope stats-collection-memory
firepower /monitoring/health-monitoring-policy/stats-collection-memory # set fault-threshold
75
firepower /monitoring/health-monitoring-policy/stats-collection-memory # disable
firepower /monitoring/health-monitoring-policy/stats-collection-memory* # commit-buffer
firepower /monitoring/health-monitoring-policy/stats-collection-memory # show
Memory stats collection policy:
Admin State Fault-Threshold (%)
-----
Disabled 75
firepower /monitoring/health-monitoring-policy/stats-collection-memory # show detail
Admin State: Disabled
Fault Threshold (%): 75
```

CPU usage metrics

CPU stats collected can be enabled or disabled using the cli under scope 'stats-collection-cpu'. By default it is enabled.

Also fault threshold can be set for all cpu monitoring faults. The threshold-value can range between 50-99. By default it is set at 90%.

```
scope health-monitoring-policy
scope stats-collection-cpu
```


enable | disable
set fault-threshold <threshold-value>

Command Modes	Monitoring mode
----------------------	-----------------

Command History	Release	Modification
	2.11.1	This command was introduced.

Usage Guidelines	This command enables or disables CPU monitoring and also changes the fault threshold value for all the CPU monitoring faults.
-------------------------	---

Example

```
firepower# scope monitoring
firepower /monitoring # scope health-monitoring-policy
firepower /monitoring/health-monitoring-policy # scope stats-collection-cpu
firepower /monitoring/health-monitoring-policy/stats-collection-cpu # set fault-threshold
85
firepower /monitoring/health-monitoring-policy/stats-collection-cpu # enable
firepower /monitoring/health-monitoring-policy/stats-collection-cpu * # commit-buffer
firepower /monitoring/health-monitoring-policy/stats-collection-cpu # show
Cpu stats collection policy:
Admin State Fault-Threshold (%)
-----
Enabled 85
firepower /monitoring/health-monitoring-policy/stats-collection-cpu # show detail
Admin State: Enabled
Fault Threshold (%): 85
```

scope hw-crypto

To enable or disable TLS crypto acceleration on a container instance, use the **scope hw-crypto** command. For more information about TLS crypto acceleration, see the *Firewall Management Center Configuration Guide*.

scope hw-crypto

Command Modes

connect module

Command History

Release	Modification
2.7.1	This command was introduced.

Usage Guidelines

This command enables or disables TLS crypto acceleration on a container instance.

Examples

Following is an example of enabling TLS crypto acceleration on a container instance:

```
scope ssa
/ssa # show app-instance
```

App Name	Identifier	Slot ID	Admin State	Oper State	Running Version	Startup Version
Deploy Type	Turbo Mode	Profile Name	Cluster	State	Cluster Role	
ftd	FTD-FDM	1	Enabled	Online	6.5.0.1159	6.5.0.1159
	Native	No		Not Applicable	None	
ftd	ftd2	2	Enabled	Online	6.5.0.1159	6.5.0.1159
	Container	No	Default-Small	Not Applicable	None	

```

/ssa # sc slot 2
/ssa/slot # scope app-instance ftd ftd2
/ssa/slot/app-instance # scope hw-crypto
/ssa/slot/app-instance/hw-crypto # set admin-state enabled
/ssa/slot/app-instance/hw-crypto* # commit-buffer

```

Following is an example of disabling TLS crypto acceleration on a container instance:

```
scope ssa
/ssa # show app-instance
```

App Name	Identifier	Slot ID	Admin State	Oper State	Running Version	Startup Version
Deploy Type	Turbo Mode	Profile Name	Cluster	State	Cluster Role	
ftd	FTD-FDM	1	Enabled	Online	6.5.0.1159	6.5.0.1159
	Native	No		Not Applicable	None	
ftd	ftd2	2	Enabled	Online	6.5.0.1159	6.5.0.1159
	Container	No	Default-Small	Not Applicable	None	

```

/ssa # sc slot 2
/ssa/slot # scope app-instance ftd ftd2
/ssa/slot/app-instance # scope hw-crypto
/ssa/slot/app-instance/hw-crypto # set admin-state disabled
/ssa/slot/app-instance/hw-crypto* # commit-buffer

```

Related Commands

Command	Description
create hw-crypto	Create a TLS crypto acceleration configuration for a container instance.
delete hw-crypto	Delete a TLS crypto acceleration configuration for a container instance.
show hw-crypto	Displays status of TLS crypto acceleration configuration on a container instance.

scope import-config

To enter an existing import-configuration object, use the **scope import-config** command.

scope import-config*hostname*

Syntax Description	<i>hostname</i>	The identifier of the import-configuration object; this is the name or IP address of the remote server on which the configuration resides.
Command History	Release	Modification
	1.1.(1)	Command added.
Usage Guidelines	<p>An export-configuration object is created when you issue an export-config command to back up the current logical device and platform configuration; the import-config command is used to import a previously exported configuration file, while simultaneously creating an import-configuration object.</p> <p>You can use scope import-config to enter an existing import-configuration object and edit its parameters. There are no create or enter commands associated with import-configuration objects. There is a delete command available which you can use to delete an import-configuration object.</p>	

Example

This example shows how to scope into an existing import-configuration object:

```
firepower # scope system
firepower /system # scope import-config 192.168.1.2
firepower /system/import-config #
```

Related Commands	Command	Description
	cfg-export-policy	Configures a configuration export policy.
	delete import-config	Deletes an existing import-configuration object.
	import-config	Imports previously exported system configuration from a remote server; creates an import-configuration object.

scope info-policy

To enter system info policies in configuration mode, use the **scope info-policy** command.

scope info-policy

Syntax Description	This command has no arguments or keywords.	
Command Modes	Scope system	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object	

Example

This example shows how to enter info policy mode:

```
firepower # scope system
firepower /system # scope info-policy
firepower /system/info-policy #
```

Related Commands	Command	Description
	Show	Shows the information about the info policies.

scope interface

To enter configuration mode for a specific interface, use the **scope interface** command.

scope interface { **Ethernet***slot_id*/*port_id* | *slot_num* }

Syntax Description	Ethernet <i>slot_id</i> / <i>port_id</i>	The Ethernet port name.
	<i>slot_num</i>	The interface slot number.
Command Modes	scope eth-uplink/scope fabric a/	
Command History	Release	Modification
	1.1.1	Command added.

Example

This example shows how to scope into configuration mode for a specific interface and view its current configuration:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # scope interface Ethernet1/5
firepower /eth-uplink/fabric/interface # show detail
```

```
Interface:
  Port Name: Ethernet1/5
  User Label:
  Port Type: Data
  Admin State: Enabled
  Oper State: Up
  State Reason:
  flow control policy: default
  Auto negotiation: No
  Admin Speed: 1 Gbps
  Oper Speed: 1 Gbps
  Admin Duplex: Full Duplex
  Oper Duplex: Full Duplex
  Ethernet Link Profile name: default
  Oper Ethernet Link Profile name: fabric/lan/eth-link-prof-default
  Uddl Oper State: Admin Disabled
  Inline Pair Admin State: Enabled
  Inline Pair Peer Port Name:
  Allowed Vlan: All
  Network Control Policy: default
  Current Task:
firepower /eth-uplink/fabric/interface #
```

Related Commands	Command	Description
	disable	Disables the current interface.

Command	Description
enable	Enables the current interface.
set	In interface mode, sets interface configuration parameters.
show interface	Displays interface configuration and status information.

scope ipsec

To enter IPSec mode, use the **scope ipsec** command.

scope ipsec

Syntax Description	This command has no arguments or keywords.	
Command Modes	Security mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object.	

Example

This example shows how to enter IPSec mode:

```
FP9300-A# scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec #
```

Related Commands	Command	Description
	show connection	Shows information about the IPSec connection.

scope ipv6-config

To enter IPv6 configuration mode, where you can configure the fabric's IPv6 management interface, use the **scope ipv6-config** command in fabric interconnect mode.

scope ipv6-config

Syntax Description	This command has no arguments or keywords.	
Command Modes	Fabric interconnect mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object.	

Example

This example shows how to enter IPv6 configuration mode:

```
FP9300-A# scope fabric-interconnect a  
FP9300-A /fabric-interconnect # scope ipv6-config  
FP9300-A /fabric-interconnect/ipv6-config #
```

Related Commands	Command	Description
	show ipv6-if	Shows IPv6 management-interface information.

scope ldap

To enter Lightweight Directory Access Protocol (LDAP) configuration mode, use the **scope ldap** command.

scope ldap

Syntax Description

This command has no arguments or keywords.

Command Modes

scope security/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object.

Example

This example shows how to enter LDAP mode:

```
firepower# scope security
firepower /security # scope ldap
firepower /security/ldap #
```

Related Commands

Command	Description
create ldap-group-rule	Creates LDAP provider group rule parameters.
create server	In security/ldap mode, creates a new LDAP server.
set	In security/ldap/server mode, sets a variety of LDAP server-related parameters, including enable/disable of SSL.

scope licdebug

To enter license debug mode from license mode, use the **scope licdebug** command.

scope licdebug

Syntax Description

This command has no arguments or keywords.

Command Modes

License mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to enter license debug mode from license mode:

```
FP9300-A # scope license
FP9300-A /license # scope licdebug
FP9300-A /license/licdebug #
```

Related Commands

Command	Description
scope license	Enters license mode.

scope license

To enter license mode, use the **scope license** command.

scope license

Syntax Description

This command has no arguments or keywords.

Command Modes

Any command mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to enter license mode from EXEC level:

```
FP9300-A# scope license
FP9300-A /license #
```

Related Commands

Command	Description
show license	Shows the usage of some or all license packages.

scope mem-leak-logging

To enable the stack trace state to detect the memory leak of each UCSM process, use the **scope mem-leak-logging** command.

scope mem-leak-logging *set*

Syntax Description	<i>set</i> set memory leak logging for the knob.
Command Modes	scope monitoring/scope sysdebug
Usage Guidelines	Use this command to enable the memory leak feature to debug memory leak issues for the specified process and to enable the stack trace.

Example

This example shows how to set the knob state and enable stack trace mode:

```
Firepower#scope monitoring
Firepower /monitoring# scope sysdebug
Firepower /monitoring/sysdebug# scope mem-leak-logging
Firepower /monitoring/sysdebug/mem-leak-logging # set ?
  appag-log           Memory Leak Logging for appAG
  bladeag-log          Memory Leak Logging for bladeAG
  dcosag-log           Memory Leak Logging for dcosAG
  dme-log              Memory Leak Logging for dme
  extvmmag-log         Memory Leak Logging for extvmmAG
  hostagentag-log      Memory Leak Logging for hostagentAG
  licenseag-log        Memory Leak Logging for licenseAG
  nicag-log            Memory Leak Logging for nicAG
  portag-log           Memory Leak Logging for portAG
  rsdag-log            Memory Leak Logging for rsdag
  serviceorchag-log    Memory Leak Logging for serviceOrchAG
  sessionmgrag-log     Memory Leak Logging for sessionmgrAG
  statsag-log          Memory Leak Logging for statsAG
  svcmonag-log         Memory Leak Logging for svcmonAG
Firepower /monitoring/sysdebug/mem-leak-logging # set statsag-log enable ?
  <CR>
  stacktrace Stacktrace for Memory Leak Report
Firepower /monitoring/sysdebug/mem-leak-logging # set statsag-log enable stacktrace ?
  off Off
  on  On
```

scope monitoring

To enter system monitoring mode, use the **scope monitoring** command.

scope monitoring

Syntax Description

This command has no arguments or keywords.

Command Modes

Any command mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object.

Example

This example shows how to enter monitoring mode:

```
FP9300-A#scope monitoring
FP9300-A /monitoring #
```

Related Commands

Command	Description
show server status	Shows information about the status of a server.

scope network-features

To enter network features in configuration mode, use the **scope network-features** command.

scope network-features

Syntax Description	This command has no arguments or keywords.	
Command Modes	Scope system	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object	

Example

This example shows how to enter network features mode:

```
firepower # scope system
firepower /system # scope network-features
firepower /system/network-features* # show
```

Related Commands	Command	Description
	show	Shows the information about the domain network features.

scope org

To enter organization mode, use the **scope org** command.

scope org [*org_name*]

Syntax Description	<i>org_name</i>	(Optional) The organization name.
Command Modes	Any command mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter organization mode:

```
FP9300-A# scope org org100
FP9300-A /org #
```

Related Commands	Command	Description
	show org	Lists currently defined organizations.

scope packet-capture

To enter packet capture mode, use the **scope packet-capture** command.

scope packet-capture

Syntax Description

This command has no arguments or keywords.

Command Modes

Any command mode

Command History

Release	Modification
---------	--------------

1.1(1)	Command added.
--------	----------------

Usage Guidelines

You do not have to enter this mode with a managed object.

Example

This example shows how to enter packet capture mode:

```
FP9300-A#scope packet-capture
FP9300-A /monitoring #
```

Related Commands

Command	Description
traceroute	Traces the route to another device on the network.

scope password-profile

To enter password profile mode, use the **scope password-profile** command.

scope password-profile

Syntax Description	This command has no arguments or keywords.	
Command Modes	Security mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter password profile security mode:

```
FP9300-A # scope security
FP9300-A /security # scope password-profile
FP9300-A /security/password-profile #
```

Related Commands	Command	Description
	show password-profile	Shows password-profile information.

scope profile

To enter Smart Call Home and Smart Licensing destination profile mode, use the **scope profile** command.

scope profile *profile_name*

Syntax Description	<i>profile_name</i>	The name of the destination profile; between 1 and 16 characters.
Command Modes	Callhome (/monitoring/callhome/) mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter profile mode and then display the destination configured for the profile:

```

FP9300-A /monitoring/callhome # scope profile SLProfile
FP9300-A /monitoring/callhome/profile # show destination

Destination:
  Name          Transport Protocol Email or HTTP/HTTPS URL Address
  -----
  SLDest        Https
https://tools.cisco.com/its/service/oddce/services/DDCEService
FP9300-A /monitoring/callhome/profile #

```

Related Commands	Command	Description
	show profile	Lists currently defined Smart Call Home and Smart Licensing profiles; available in monitoring/callhome mode.

scope qos

To enter qos mode, use the **scope qos** command.

scope qos

Syntax Description

This command has no arguments or keywords.

Command Modes

scope eth-server

Command History

Release	Modification
2.3.1	Command added.

Usage Guidelines

In qos mode, you can distinguish the traffic, queuing bandwidth for each packet, regardless of packet, and size.

Example

This example shows how to enter qos mode.

```
Firepower# scope eth-server
Firepower /eth-server # scope qos
Firepower /eth-server/qos #
```

Related Commands

Command	Description
show eth-best-effort	It displays the detailed information of ethernet best effort class.
show eth-classified	It displays the detailed information of ethernet classified class.
show fc	It displays the information of fc class available on the system.
Show event	It displays fsm event information.
show fsm	It displays fsm information for the current application, according to the specified keyword. Status : displays fsm status information. Task: displays fsm task information

scope radius

To enter Remote Authentication Dial-In User Service (RADIUS) configuration mode, use the **scope radius** command.

scope radius

Syntax Description	This command has no arguments or keywords.	
Command Modes	Scope security	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object	

Example

This example shows how to enter radius mode:

```
firepower # scope security
firepower /security # scope radius
firepower /security/radius #
```

scope reservation

To enter license reservation mode, use the **scope reservation** command.

scope reservation

Syntax Description

This command has no arguments or keywords.

Command Modes

License mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to enter reservation mode from license mode:

```
FP9300-A# scope license
FP9300-A /license # scope reservation
FP9300-A /license/reservation #
```

Related Commands

Command	Description
request universal	Generates a reservation request code.
show license	Shows the usage of some or all license packages.

scope security

To enter security mode, use the **scope security** command.

scope security

Syntax Description

This command has no arguments or keywords.

Command Modes

Any command mode

Command History

Release	Modification
---------	--------------

1.1(1)	Command added.
--------	----------------

Usage Guidelines

You do not have to enter this mode with a managed object.

Example

This example shows how to enter security mode:

```
firepower# scope security
firepower /security #
```

Related Commands

Command	Description
show security	In EXEC mode, shows information about current security policies.

scope server

To enter server mode, use the **scope server** command.

scope server { *id* | *dynamic_uid* | *chassis_id/blade_id* }

Syntax Description

<i>id</i>	The server ID; an integer between 1 and 255.
<i>dynamic_uid</i>	The server's dynamic universally unique ID (UUID).
<i>chassis_id/blade_id</i>	The server specified using chassis and blade IDs; must be entered in n/n format.
Note The chassis ID is always 1 .	

Command Modes

EXEC mode

Command History

Release	Modification
1.1(1)	Command added.

Example

This example shows how to enter server mode:

```
FP9300-A# scope server 1/1
FP9300-A /chassis/server #
```

Related Commands

Command	Description
show server adapter	Shows information about the network adapters in a server.
show server identity	Shows identity information about a server.

scope server-features

To enter server features in configuration mode, use the **scope server-features** command.

scope server-features

Syntax Description	This command has no arguments or keywords.	
Command Modes	Scope system	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object	

Example

This example shows how to enter server features mode:

```
firepower # scope system
firepower /system # scope server-features
firepower /system/server-features* # show
```

Related Commands	Command	Description
	show	Shows the information about the domain server features.

scope service-profile

To enter service profile mode, use the **scope service-profile** command.

scope service-profile { *dynamic_uuid* | *org* | *server* }

Syntax Description	<i>dynamic_uuid</i>	The dynamic UUID of the service profile.
	<i>org</i>	The name of the organization for which the service profile was created; between 1 and 16 characters.
	<i>server</i>	The ID of the server for which the service profile was created.

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	1.1(1)	Command added.

Usage Guidelines	To use this command with the <i>org</i> option, an organization and a service profile for that organization must already exist.
	To use this command with the <i>server</i> option, the server can be specified with its server ID, or the chassis ID and blade ID (n/n format). The chassis ID is always 1 .

Example

This example shows how to enter service profile mode:

```
firepower # scope service-profile server 1/1
firepower /org/service-profile #
```

Related Commands	Command	Description
	show service-profile	Shows service-profile information.

scope services

To enter system services in configuration mode, use the **scope services** command.

scope services

Syntax Description	This command has no arguments or keywords.	
Command Modes	Scope system	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object	

Example

This example shows how to enter services mode:

```
firepower # scope system
firepower /system # scope services
firepower /system/services #
```

Related Commands	Command	Description
	Show	Shows the information about the services.

scope slot

To enter slot mode for a specific SSP module, use the **scope slot** command.

scope slot *slot_ID*

Syntax Description	<i>slot_ID/id</i>	Identifies the module slot. For the FP9300, this value can be 1, 2, or 3; on the FP4100, this value is 1.
Command Modes	scope ssa/	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	In slot mode, you can update the application image on the logical device.	

Example

This example shows how to enter slot mode:

```
firepower# scope ssa
firepower /ssa # scope slot 2
firepower /ssa/slot #
```

Related Commands	Command	Description
	show security	Shows security information.

scope ssa

To enter security services (ssa) mode, use the **scope ssa** command.

scope ssa

Syntax Description

This command has no arguments or keywords.

Command Modes

EXEC mode

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object.

Example

This example shows how to enter ssa mode:

```
FP9300-A# scope ssa
FP9300-A /ssa #
```

Related Commands

Command	Description
show security	Shows security information.

scope stats-collection-policy

To enter the statistics collection policy for one of the functional areas of your system, use the **scope stats-collection-policy** command.

scope stats-collection-policy *policy-area*

Syntax Description

policy-area

The specific collection policy area:

- **Adapter** – statistics related to the adapters.
- **Chassis** – statistics related to the blade chassis.
- **FEX** – statistics related to configured Fabric Extender(s).
- **Host** – this policy is a placeholder for future support.
- **Port** – statistics related to the ports, including server ports, uplink Ethernet ports, and uplink Fibre Channel ports.
- **Server** – statistics related to servers.

Command Modes

scope monitoring/

Command History

Release

Modification

1.1(1)

Command added.

Usage Guidelines

Statistics can be collected and reported for several of the functional areas of your system.

Use the **set collection-interval** command to define how frequently statistics are collected, and use the **set reporting-interval** command to define how frequently the statistics are reported. These intervals define a statistics collection policy.

Reporting intervals are longer than collection intervals so that multiple statistical data points can be collected during the reporting interval, which provides sufficient data to calculate and report minimum, maximum, and average values.



Note

There is one default statistics collection policy for each of the functional areas. You cannot create additional statistics collection policies and you cannot delete the existing default policies. You can only modify the default policies.

Example

This example shows how to enter the statistics collection policy for ports, set the collection interval to one minute, set the reporting interval to 30 minutes, and then commit the transaction:

```
firepower # scope monitoring
firepower /monitoring # scope stats-collection-policy port
```

```
firepower /monitoring/stats-collection-policy # set collection-interval 1minute
firepower /monitoring/stats-collection-policy* # set reporting-interval 30minute
firepower /monitoring/stats-collection-policy* # commit-buffer
firepower /monitoring/stats-collection-policy #
```

Related Commands

Command	Description
set collection-interval	Specifies how frequently statistics are collected.
set reporting-interval	Specifies how frequently statistics are reported.

scope stats-threshold-policy

To enter the statistics threshold policy for one of the components of your system, use the **scope stats-threshold-policy** command.

scope stats-threshold-policy *policy-name*

Syntax Description

<i>policy-name</i>	The name of the specific threshold policy to enter. You cannot create or delete a statistics threshold policy for Ethernet server ports or Ethernet uplink ports. You can only configure the existing default policy, so for these policies, enter default as the <i>policy-name</i> .
--------------------	--

Command Modes

scope eth-server/
scope eth-uplink/
scope org/

Command History

Release	Modification
1.1(1)	Command added.

Usage Guidelines

A statistics threshold policy monitors statistics about certain aspects of the system and generates an event if a specified threshold is crossed. You can set both minimum and maximum thresholds. For example, you can configure the policy to raise an alarm if the CPU temperature exceeds a certain value, or if a server is overutilized or underutilized.

There is one default statistics threshold policy each for Ethernet server ports or Ethernet uplink ports. You cannot create additional statistics threshold policies and you cannot delete the existing default policies for these components—you can only modify the default policies.

However, you can create and delete statistics threshold policies in organization mode (`scope org/`). See the **create stats-threshold-policy** command for more information.



Note Use the **set collection-interval** command to define how frequently statistics are collected, and use the **set reporting-interval** command to define how frequently the statistics are reported. These intervals define a statistics collection policy.

Examples

This example shows how to scope into the default Ethernet uplink statistics threshold policy, create an error statistics class, create a cyclic redundancy check (CRC) error count property, specify that the normal CRC error count per polling interval is 1000, create an above normal warning threshold of 1250, and then commit the class:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope stats-threshold-policy default
firepower /eth-uplink/stats-threshold-policy # create class ether-error-stats
```



```

firepower /eth-uplink/stats-threshold-policy/class* # create property crc-delta
firepower /eth-uplink/stats-threshold-policy/class/property* # set normal-value 1000
firepower /eth-uplink/stats-threshold-policy/class/property* # create threshold-value
above-normal warning
firepower /eth-uplink/stats-threshold-policy/class/property/threshold-value* # set escalating
1250
firepower /eth-uplink/stats-threshold-policy/class/property/threshold-value* # commit-buffer
firepower /eth-uplink/stats-threshold-policy/class/property/threshold-value #

```

This example shows how to scope into organization mode, create a new statistics threshold policy for server and server component statistics, create a threshold policy class for CPU environment statistics, create a CPU temperature property, specify that the normal CPU temperature is 48.5° C, create an above normal warning threshold of 50° C, and commit the entire transaction:

```

firepower # scope org
firepower /org # create stats-threshold-policy ServStatsPolicy
firepower /org/stats-threshold-policy* # create class cpu-env-stat
firepower /org/stats-threshold-policy/class* # create property temperature
firepower /org/stats-threshold-policy/class/property* # set normal-value 48.5
firepower /org/stats-threshold-policy/class/property* # create threshold-value above-normal
warning
firepower /org/stats-threshold-policy/class/property/threshold-value* # set escalating 50.0
firepower /org/stats-threshold-policy/class/property/threshold-value* # commit-buffer
firepower /org/stats-threshold-policy/class/property/threshold-value #

```

This example shows how to scope into the default ethernet server statistics threshold policy.

```

Firepower# scope eth-server
Firepower /eth-server # scope stats-threshold-policy default
Firepower /eth-server/stats-threshold-policy #

```

Related Commands

Command	Description
create class	Creates a new class of statistics.
create property	Creates a new property for a class of statistics.
create threshold-value	Specifies an above- or below-normal threshold for a class property.
scope stats-collection-policy	Enters stats-collection-policy mode, where you manage statistics collection and reporting intervals.
create	Created managed objects
delete	Delete managed objects
enter	Enters a managed objects
scope	Changes the current mode
set	Set property values
show	Show system information

scope storage-features

To enter storage features in configuration mode, use the **scope storage-features** command.

scope storage-features

Syntax Description

This command has no arguments or keywords.

Command Modes

Scope system

Command History

Release	Modification
2.3.1	Command added.

Usage Guidelines

You do not have to enter this mode with a managed object

Example

This example shows how to enter storage features mode:

```
firepower # scope system
firepower /system # scope environment-features
firepower /system/environment-features # show
```

Related Commands

Command	Description
show	Shows the information about the domain storage features.

scope system

To enter system-management mode, use the **scope system** command.

scope system

Syntax Description	This command has no arguments or keywords.	
Command Modes	EXEC mode	
Command History	Release	Modification
	1.1(1)	Command added.
Usage Guidelines	In this mode, you can manage the system configuration, including exporting and importing a configuration file.	

Example

This example shows how to enter system-management mode:

```
firepower# scope system
firepower /system #
```

Related Commands	Command	Description
	show system	Shows information about the systems configured on this device.

scope tacacs

To enter Terminal Access Controller Access Control System (TACACS) configuration mode, use the **scope tacacs** command.

scope tacacs

Syntax Description

This command has no arguments or keywords.

Command Modes

Scope security

Command History

Release

Modification

2.3.1

Command added.

Usage Guidelines

You do not have to enter this mode with a managed object

Example

This example shows how to enter tacacs mode:

```
firepower # scope security
firepower /security # scope tacacs
firepower /security/tacacs #
```

scope telemetry

To enter telemetry mode, use the **scope telemetry** command.

scope telemetry

Syntax Description

This command has no arguments or keywords.

Command Modes

scope system, scope services

Command History

Release	Modification
2.3.1	Command added.

Usage Guidelines

You can use the enable or disable and show commands

Related Commands

Command	Description
show detail	Shows the telemetry information of the system.

scope vnic

To enter virtual NIC mode, use the **scope vnic** command.

scope vnic *dynamic_mac*

Syntax Description	<i>dynamic_mac</i>	The virtual NIC's dynamic MAC address.
Command Modes	EXEC mode Service profile mode	
Command History	Release	Modification
	1.1(1)	Command added.

Example

This example shows how to enter virtual NIC mode while in organization mode:

```
FP9300-A # scope org org10
FP9300-A /org # scope service-profile sp10
FP9300-A /org/service-profile # scope vnic vNIC10
FP9300-A /org/service-profile/vnic #
```

Related Commands	Command	Description
	show server adapter	Shows information about the available network adapters.

sub scopes (scope fabric-interconnect)

To enter switch uplink mode, use the **scope sw-uplink** command in scope fabric interconnect mode.

scope sw-uplink

Syntax Description	This command has no arguments or keywords.	
Command Modes	EXEC mode	
Command History	Release	Modification
	2.3.1	Command added.
Usage Guidelines	You do not have to enter this mode with a managed object.	

Example

This example shows how to enter sw-uplink mode:

```
firepower# scope fabric-interconnect
firepower /fabric-interconnect # scope sw-uplink
firepower /fabric-interconnect/sw-uplink #
```

Related Commands	Command	Description
	show	Shows the information about the sw-uplink.

