



## set Commands

---

- [set absolute-session-timeout](#), on page 4
- [set account-status](#), on page 5
- [set address](#), on page 6
- [set admin-state](#), on page 7
- [set auth-server-group](#), on page 8
- [set authentication](#), on page 9
- [set auto-negotiation](#), on page 10
- [set cert](#), on page 11
- [set certchain](#), on page 13
- [set \(certreq\)](#), on page 15
- [set \(cfg-export-policy\)](#), on page 17
- [set \(cfg-export-reminder\)](#), on page 19
- [set cli](#) , on page 20
- [set clock](#) , on page 22
- [set cluster-control-link network](#), on page 23
- [set collection-interval](#), on page 24
- [set con-absolute-session-timeout](#), on page 26
- [set con-session-timeout](#), on page 27
- [set cpu-core-count](#), on page 28
- [set deploy-type](#), on page 30
- [set descr](#), on page 32
- [set duplex](#), on page 33
- [set email](#), on page 34
- [set enforce-strong-password](#), on page 35
- [set expiration](#), on page 37
- [set \(export-config\)](#), on page 38
- [set firstname](#), on page 40
- [set flow-control-policy](#), on page 41
- [set \(flow-control policy\)](#), on page 42
- [set frequency](#), on page 44
- [set http-proxy-server-enable](#), on page 45
- [set http-proxy-server-port](#), on page 46
- [set http-proxy-server-url](#), on page 47

- [set https](#), on page 48
- [set \(interface\)](#), on page 51
- [set ipv6](#), on page 54
- [set ipv6-auto eui64](#), on page 55
- [set ipv6-auto stablesec](#), on page 56
- [set ipv6-ready](#), on page 57
- [set keyring-name](#), on page 58
- [set lastname](#), on page 59
- [set link-state-sync](#), on page 60
- [set local-address](#), on page 61
- [set log-level](#), on page 62
- [set max-login-attempts](#), on page 63
- [set message](#), on page 64
- [set min-password-length](#), on page 66
- [set mode](#), on page 67
- [set modulus](#), on page 68
- [set nd](#), on page 69
- [set out-of-band](#), on page 70
- [set password](#), on page 72
- [set password-encryption-key](#), on page 73
- [set \(password-profile\)](#), on page 75
- [set phone](#), on page 77
- [set \(port-channel\)](#), on page 78
- [set port-channel-mode](#), on page 81
- [set port-type](#), on page 83
- [set port-type \(aggr-interface\)](#), on page 87
- [set prefix](#), on page 90
- [set protocol](#), on page 92
- [set realm](#), on page 94
- [set refresh-period](#), on page 95
- [set regenerate](#), on page 96
- [set remote-address](#), on page 97
- [set remote-ike-ident](#), on page 98
- [set remote-subnet](#), on page 99
- [set remote-user](#), on page 100
- [set reporting-interval](#), on page 101
- [set resource-profile-name](#), on page 103
- [set session-timeout](#), on page 105
- [set snmp-adminappinstance](#), on page 106
- [set snmp](#), on page 108
- [set \(snmp-trap\)](#), on page 110
- [set \(snmp-user\)](#), on page 112
- [set speed](#), on page 114
- [set speed \(aggr-interface\)](#), on page 116
- [set ssh-server](#), on page 119
- [set sshkey](#), on page 120

- [set startup-version](#), on page 121
- [set timezone](#), on page 122
- [set trustpoint](#), on page 124
- [set use-2-factor](#), on page 125
- [set user-account-unlock-time](#), on page 126
- [set user-label](#), on page 127
- [set value \(create bootstrap-key FIREWALL\\_MODE\)](#), on page 129
- [set value \(create bootstrap-key MANAGEMENT\\_TYPE\)](#), on page 130
- [set value \(create bootstrap-key PERMIT\\_EXPERT\\_MODE\)](#), on page 131
- [set vlan](#), on page 132

# set absolute-session-timeout

To set the absolute session timeout, use the **set absolute-session-timeout** command.

**set absolute-session-timeout** *seconds*

<b>Syntax Description</b>	<i>seconds</i>	Absolute session timeout for Web, SSH, and Telnet sessions; value can be 0 to 3600 seconds. To disable this timeout, set the value to 0.
---------------------------	----------------	--

<b>Command Modes</b>	Default authentication (/security/default-auth) mode
----------------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

<b>Usage Guidelines</b>	The absolute session timeout closes user sessions after the specified timeout period has passed, regardless of session use. This absolute timeout is global across all forms of access including serial console, SSH, and HTTPS.
-------------------------	--

## Example

This example shows how to enter default authentication mode and then set the absolute timeout for all sessions to four minutes:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set absolute-session-timeout 240
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>set refresh-period</b>	Sets the Web session refresh period.
	<b>show detail</b>	Displays the current session and absolute session timeout settings.

## set account-status

To specify whether a local user account is active or inactive, use the **set account-status** command.

```
set account-status { active | inactive }
```

Syntax Description	active	Specifies that the local user account is active.
	inactive	Specifies that the local user account is disabled.

**Command Modes** Local user (/security/local-user) mode

Command History	Release	Modification
	1.1(1)	Command added.

**Usage Guidelines** You must be a user with admin or AAA privileges to use this command.  
The admin account is always set to active. It cannot be modified.

### Example

This example shows how to enter local user mode and deactivate a local user account:

```
FP9300-A # scope security
FP9300-A /security # scope local-user test_user
FP9300-A /security/local-user # set account-status inactive
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

Related Commands	Command	Description
	set expiration	Specifies the date on which the user account expires.

# set address

To set an email or URL address for a Smart Call Home or Smart Licensing destination, use the **set address** command.

**set address** *address*

<b>Syntax Description</b>	<i>address</i>	The email address or URL of the Smart Call Home or Smart Licensing destination.
<b>Command Modes</b>	scope monitoring/scope callhome/scope profile/scope destination/	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.4(1)	Command added.
<b>Usage Guidelines</b>	<p>Each Firepower 4100/9300 chassis must be registered with the Smart Call Home License Authority or Smart License satellite server. Use this command to set an email or HTTP/HTTPS URL address as the licensing destination.</p> <p>License Authority example: <code>https://tools.cisco.com/its/service/oddce/services/DDCEService</code></p> <p>Satellite server example: <code>https://ip_address/Transportgateway/services/DeviceRequestHandler</code></p>	
	<p><b>Example</b></p> <p>This example shows how to create and enter a Smart Call Home destination:</p> <pre>firepower # scope monitoring firepower /monitoring # scope callhome firepower /monitoring/callhome # scope profile SLProfile firepower /monitoring/callhome/profile # scope destination SLDest firepower /monitoring/callhome/profile/destination # set address https://tools.cisco.com/its/service/oddce/services/DDCEService firepower /monitoring/callhome/profile/destination* # commit-buffer firepower /monitoring/callhome/profile/destination #</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>create destination</b>	Creates a new Smart Call Home destination.
	<b>delete destination</b>	Deletes an existing Smart Call Home destination.
	<b>set protocol</b>	Sets the transport protocol for a Smart Call Home destination.

## set admin-state

To enable or disable the administrative state of a Smart Call Home policy, use the **set admin-state** command.

```
set admin-state { disabled | enabled }
```

Syntax Description	disabled	enabled
	Sets the policy administrative state to disabled.	Sets the policy administrative state to enabled.

**Command Modes** scope monitoring/scope callhome/policy/

Command History	Release	Modification
	1.1(1)	Command added.

**Usage Guidelines** Use this command to enable or disable the Call Home policy when a fault or system event matching the associated cause is encountered.

### Example

This example shows how to enter and enable a Call Home policy instance for link-down events:

```
firepower /monitoring/callhome # enter policy link-down
firepower /monitoring/callhome/policy* # set admin-state enabled
firepower /monitoring/callhome/policy* # commit-buffer
firepower /monitoring/callhome/policy #
```

Related Commands	Command	Description
	<b>enter policy</b>	Enters a Smart Call Home policy.
	<b>delete policy</b>	Deletes an existing Smart Call Home policy.
	<b>scope policy</b>	Scopes into a Smart Call Home policy.
	<b>show</b>	Displays Call Home configuration or policy information.

## set auth-server-group

To specify a default authentication server group, use the **set auth-server-group** command.

```
set auth-server-group admin
```

<b>Syntax Description</b>	<i>admin</i>	The name of the authentication server group.
<b>Command Modes</b>	Default authentication mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

### Example

This example shows how to specify the default authentication server group:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set auth-server-group admin_server
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	set realm	Specifies the default authentication service.

# set authentication

To set the default authentication method for the user during login and when connecting to the FXOS CLI via the console port, use the **set authentication** command.

## set authentication

### Syntax Description

This command has no arguments or keywords.

### Command Modes

scope security

### Command History

Release	Modification
2.10(1)	Command added.

### Usage Guidelines

You can set the default method by which a user is authenticated during login and when connecting to the FXOS CLI via the console port.

### Example

This example shows how to enter security mode and set default authentication method:

```
firepower# scope security
firepower /security # set authentication
    console Console authentication
    default Default authentication
```

### Related Commands

Command	Description
<b>show authentication</b>	Displays the existing authentication service.

# set auto-negotiation

To enable or disable the autonegotiation of an interface, use the **set auto-negotiation** command.

**set auto-negotiation** { **on** | **off** }

Syntax Description	on	(Optional) Auto-Negotiation is turned on.
	off	(Optional) Auto-Negotiation is turned off.

**Command Modes** scope eth-uplink/scope fabric a/scope interface/

Command History	Release	Modification
	2.1.1	Command added.

**Usage Guidelines** This command works only on specific port types.

## Example

This example shows how to enable or disable autonegotiation:

```
Firepower-9300 # scope eth-uplink
Firepower-9300 /eth-uplink # scope fabric a
Firepower-9300 /eth-uplink #/fabric # scope interface Ethernet2/1
Firepower-9300 /eth-uplink/fabric/interface* # set auto-negotiation on
Firepower-9300 /eth-uplink/fabric/interface* # commit-buffer
Firepower-9300 /eth-uplink/fabric/interface #
```

Related Commands	Command	Description
	<b>scope interface</b>	Displays the Ethernet interface information of the interface.

# set cert

To add an RSA certificate to a keyring, use the **set cert** command.

## set cert

<b>Syntax Description</b>	This command has no arguments or keywords.	
<b>Command Modes</b>	Keyring mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.
<b>Usage Guidelines</b>	After entering the command, you are prompted to enter the certificate text, which must end with <b>ENDOFBUBF</b> .	

## Example

This example shows how to enter the certificate text for a keyring:

```

FP9300-A /security/keyring # set cert
Enter lines one at a time. Enter ENDOFBUBF to finish. Press ^C to abort.
Keyring certificate:
>-----BEGIN CERTIFICATE-----
MIIFqDCCA5CgAwIBAgIBBDANBgkqhkiG9w0BAQsFADBwMQswCQYDVQQGEwJVUzEL
MAkGA1UECAwCQ0ExDDAKBgNVBACMA1NKQzEOMAwGA1UECgwFQ21zY28xDTALBgNV
BAsMBFNUQ1UxXzAxBG9NBAMMAkNBMR0wGAYJKoZIhvcNAQkBFgtzc3Bac3NwLm51
dDAeFw0xNjEyMTUyMTM0NTRaFw>0yNjEyMTMyMTM0NTRaMHwxZAJBgNVBAYTA1VT
MQswCQYDVQQIDAJDQTEPMA0GA1UECgwGbmV3c3RnMRAdDgYDVQQLDAdzXzdzdGJ1
MRMwEQYDVQQDDAAppbnRlcm0xLWNhMSgwJgYJKoZIhvcNAQkBFhlpbnRlcm0xLWNh
QGludGVybTETeY2EubmV0MlICiJANBgkqhkiG9w0BAQEFAAOCAg8AMIICCgKCAgEA
wLpNnyEx5I4P8uDoW>KWF3IZsegjhLANsodxuAUmhmwKekd0OpZZxHMw1wSO4IBX5
4itJS0xyXFzPmeptG3OXvNqCcsT+4BXl3DoGgPMULccc4NesHeg2z8+q3SPA6uZh
iseWNvKfnUjixbQEBtcrWB1SKnZuOz1cpuBn34gtgeFFoCEXN+EZVpPESiandVh
8pCFlipC/08ZJ3o9GW2j0eHJN84sguIEDL812ROejQvpmfGUGu11stkIIuh+wB+V
VRhUBVG7p>v57I6DHeeRp6cDMLXaM3iMTelhdShyo5YUaRJmak/t8kCqhtGXfuLLI
E2AkxKXeever9n6cpQd5JiNzCT/t9IQL/T/CCqMICRXLfPLCS9o5S5O2B6QFgcTZ
yKR6hsmwe22wpK8QI7/5oWNX1olb96hHJ7RPbG7RXYqmcLiXY/d2j9/RuNoPJawI
hLkfhoidPA28xlnfIB1azCmMmdPcBO6cbUQfCj5hSmk3StVQKgcJcaujz55TGGd1
G>jnxDMX9twwz7Ee51895Xmtr24qqaCXJoW/dPhcIIXRdJPMsTJ4yPG0BieuRwd0p
i8w/rFwbHzv4C9Fthw1JrRxH1yeHJHrLlZgJ5txSaVUIgrgVCJaf6/jrRRWoRjWt
AzvzYql2dZPCcEAYgP7JcaQpvdpuDgq++NgBtygiqECAwEAAaNBMD8wDAYDVR0T
BAUwAwEB/zAvBgNVHR8EKDAMCScGtqAghh5odHRwOi8vMTkyLjE2OC40LjI5>L21u
dGVybS5jcmwwDQYJKoZIhvcNAQELBQADggIBAG/XujJh5G5UWo+cwTSitAezWbJA
h1dAiXZ/OYWZSxkFRliErKdupLqL0ThjnX/wRFfEXbrBQwm5kWAUUDr97D1Uz+2A
8LC5I8SWKXmyf0jUtsnEQbDZb33oVL7yXJk/A0SF0jihpPheMA+YRazalT9xj9KH
PE7nHCJmbb2ptrHUyvBrKSYrSeEqOpQU2+otnFyV3rS9aelgV>juaWyaWoc3lZl0i
CC2tJvY3NnM56j5iesxUCeY/SZ2/ECXN7RRBViLHma3gFKmWf3xeNiKkxmJCxOaa
UWPC1x2V66I8DG9uUz1Wyd7902dy52aAphAHC6hqlzb6v+gw1Tld7UxaqVd8CD5W
ATjNs+ifkJS1h5ERxHjgcurZXOpR+NWpwF+UDzbMXxx+KAAXCI6ltCd8Pb3wOUC3
PKVwEXaTcCcxGx71eRlpWPZFYeoi4N2NGE9OXRjz0>K/KERZgNhsIW3bQMjcw3aX6
OXskEuKgsayctnWyxVqNnqpuz06kqyubh4+ZgGKZ5LNEXYmGNz3oED1rUN636Tw
SjGAPHgErozyTFDixCei6aR0lGdP/Hwvb0/+uThIe89g8WZ0djTKFUM8uBO3f+II
/cbuyB01+JrDMq8NkAjxKlJlp1c3WbfCue/qcwtcfUBYZ4i53a56UNF5Ef0rpy/8
B/+07Me/p2y9Luqa
-----END CERTIFICATE-----

```

```
ENDOFBUF  
FP9300-A /security/keyring* #
```

Related Commands	Command	Description
	<b>set modulus</b>	Specifies the RSA key modulus (SSL key length) in bits.
	<b>set regenerate</b>	Regenerates the RSA keys in the default keyring.
	<b>set trustpoint</b>	Specifies whether the keyring certificate can be regenerated.

# set certchain

To enter a list (or chain) of certificates for the current trustpoint, use the **set certchain** command.

**set certchain** [*cert\_chain*]

<b>Syntax Description</b>	<i>cert_chain</i>	(Optional) The certificate chain obtained from a Certificate Authority.  If this variable is omitted, you are prompted to enter the certificate information manually.
<b>Command Modes</b>	Trustpoint mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

## Usage Guidelines

The certificates must be in Base64 encoded X.509 (CER) format.

If you do not specify the certificate chain with the command, you are prompted to enter a certificate or a list of trust points defining a certification path to the root Certificate Authority (CA). Type `ENDOFBUF` to finish the entry.

See “Certificates, Key Rings, and Trusted Points” in the *Cisco FXOS CLI Configuration Guide* for information about obtaining a trust certificate.

## Example

This example shows how to create and enter a new trustpoint, and then paste a certificate chain into the trustpoint :

```

FP9300-A # scope security
FP9300-A /security # enter trustpoint tPoint4
FP9300-A /security/trustpoint* # set certchain
Enter lines one at a time. Enter ENDOFBUF to finish. Press ^C to abort.
Trustpoint Certificate Chain:
> -----BEGIN CERTIFICATE-----
> MIIDMCCApmgAwIBAgIBADANBgkqhkiG9w0BAQQFADB0MQswCQYDVQQGEwJVUzEL
> BxMMU2FuIEpvc2UsIENBMRUwEwYDVQQKEwxFeGFtcGx1IEluYy4xEzARBgNVBASt
> ClRlc3QgR3JvdXAxGTAXBgNVBAMTEHRlc3QuZXhhbXBsZS5jb20xH2AdBgkqhkiG
> 9w0BCQEWEHVzZXJAZXhhbXBsZS5jb20wgZ8wDQYJKoZIhvcNAQEBBQADgY0AMIGJ
> AoGBAMZw4nTepNIDhVzb0j7Z2Je4xAG56zmSHRMQeOGHemdh66u2/XAoLx7YCcYU
> ZgAMivvCsKgb/6CjQtsofvtrmC/eAehuK3/SINv7wd6Vv2pBt6ZpXgd4VBKOND1
> GMbkPayV1QjbG4MD2dx2+H8EH3lMtdZrgKvPxPTE+bf5wZVNAgMBAAGgJTAjBgkq
> hkiG9w0BCQcxFhMUQSBjaGFsbGVuZ2UgcGFzc3dvcnQwDQYJKoZIhvcNAQEFBQAD
> gYEAG61CaJoJavMhzC190306Mg51zq1zXcz75+VFj2I6rH9asckCl3mkOVx5gJU
> Ptt5CVQpNgNLdvbDPSsXretysOhqHmp9+CLv8FDuy1CDYfuaLtv1WvfhevskV0j6
> jtcEMyZ+f7+3yh42lido3nO4MIgeBgnVHSMegZYwgZOAFLLnjtcEMyZ+f7+3yh42
> lido3nO4oXikdjB0MQswCQYDVQQGEwJVUzELMAkGA1UECBMCQ0ExFDASBgNVBAcT
> ClNhbncRhIENsYXJhMRswCQYDVQQKEwJKODw92YSBTExN0ZW1zIEluYy4xFDASBgNV
> BAsTC0Vuz21uZWVyaW5nMQ8wDQYDVQQDEwZ0ZXN0Q0GCAQAwdAYDVR0TBAAUwAwEB
> /zANBgkqhkiG9w0BAQQFAAOBgQAhWaRwXNR6B4g6Lsnr+fptHv+WVhB5fKqGQqXc
> wR4pYiO4z42/j9Ijenh75tCKMhW51az8copP1EBmOcyuhf5C6vasren1ddkkYt4
> PR0vxGc40whuiozBolesmsmJbbedUCwQgdFDWhDIZJwK5+N3x/kfa2EHU6id1avt

```

```
> 4YL5Jg==
> -----END CERTIFICATE-----
> ENDOFBUF
FP9300-A /security/trustpoint* # commit-buffer
FP9300-A /security/trustpoint #
```

**Related Commands**

Command	Description
<b>enter trustpoint</b>	Enters a trustpoint.
<b>show trustpoint</b>	Shows current trustpoint information.

## set (certreq)

To specify parameters for a keyring certificate request, use the **set** command in certificate request mode.

```
set { country | dns | e-mail | fi-a-ip | fi-a-ipv6 | fi-b-ip | fi-b-ipv6 | ip | ipv6 | locality | org-name | org-unit-name |
password | state | subject-name }
```

Syntax	Description
<i>country</i>	(Optional) Specify a two-letter country code for the request; letters must be capitalized.
<i>dns</i>	(Optional) Specify the domain name assigned to the network; common to all host names. This is an alternative to <i>subject-name</i> .
<i>e-mail</i>	(Optional) Specify the email address associated with the request.
<i>fi-a-ip</i>	Not used.
<i>fi-a-ipv6</i>	Not used.
<i>fi-b-ip</i>	Not used; there is no fabric interconnect B.
<i>fi-b-ipv6</i>	Not used; there is no fabric interconnect B.
<i>ip</i>	(Optional) Specify the IPv4 address of the device domain.
<i>ipv6</i>	(Optional) Specify the IPv6 address of the device domain.
<i>locality</i>	(Optional) Specify the city or town in which the company requesting the certificate is headquartered.  Enter up to 64 characters. You can use any letters, numbers, or spaces, as well as the following special characters: , (comma), . (period), @ (at sign), ^ (carat), ( (open parenthesis), ) (close parenthesis), - (dash), _ (underscore), + (plus sign), : (colon), / (forward slash).
<i>org-name</i>	(Optional) Specify the name of the organization requesting the certificate.  Enter up to 64 characters. You can use any letters, numbers, or spaces, as well as the following special characters: , (comma), . (period), @ (at sign), ^ (carat), ( (open parenthesis), ) (close parenthesis), - (dash), _ (underscore), + (plus sign), : (colon), / (forward slash).
<i>org-unit-name</i>	(Optional) Specify the name of the unit within the organization.  Enter up to 64 characters. You can use any letters, numbers, or spaces, as well as the following special characters: , (comma), . (period), @ (at sign), ^ (carat), ( (open parenthesis), ) (close parenthesis), - (dash), _ (underscore), + (plus sign), : (colon), / (forward slash).
<i>password</i>	(Optional) You are asked to enter and then confirm a password for the request.

<i>state</i>	(Optional) Specify the state or province in which the company requesting the certificate is headquartered.  Enter up to 64 characters. You can use any letters, numbers, or spaces, as well as the following special characters: , (comma), . (period), @ (at sign), ^ (carat), ( (open parenthesis), ) (close parenthesis), - (dash), _ (underscore), + (plus sign), : (colon), / (forward slash).
<i>subject-name</i>	(Optional) Specify the fully qualified domain name of the local fabric interconnect.

**Command Modes** scope security/enter keyring/scope certreq/

Command History	Release	Modification
	1.1(1)	Command added.

**Usage Guidelines** After creating or entering a certificate request, use these options to specify information about the request.

### Example

This example shows how to specify information about a certificate request:

```
firepower /security/keyring # enter certreq
firepower /security/keyring/certreq # set subject-name FP9300-1.testnet.com
firepower /security/keyring/certreq* # set password
Certificate request password:
Confirm certificate request password:
firepower /security/keyring/certreq* #
```

Related Commands	Command	Description
	<b>create certreq</b>	Creates a new keyring certificate request.
	<b>delete certreq</b>	Deletes an existing keyring certificate request.
	<b>enter certreq</b>	Enters a keyring certificate request.
	<b>set (keyring)</b>	Sets keyring-related information, including modulus and trustpoint.

## set (cfg-export-policy)

To specify or edit the parameters for an existing configuration-export policy, use the **set** command in configuration-export-policy mode.

**set** { **adminstate** | **descr** | **hostname** | **password** | **port** | **protocol** | **remote-file** | **schedule** | **user** }

Syntax	Description
<b>adminstate</b> { <b>disable</b>   <b>enable</b> }	Enables or disables policy administration. When disabled, configuration back-ups are not exported according to the policy schedule.
<b>descr</b> <i>description</i>	(Optional) You can add a description to the configuration object; the description can be between one and 256 characters. Most alphanumeric characters are allowed, as are dashes and underscores; the string can end with punctuation such as semi-colon, period (full stop), and exclamation point, but you cannot embed those characters in the description.
<b>hostname</b> <i>host_ID</i>	(Optional) Specify the IP address or host name of the remote server to which the configuration back-up is exported. This host can be a server, storage array, local drive, or any read/write media that is accessible on the network.  <b>Note</b> To use an actual host name, a configured DNS server must be available.
<b>password</b>	(Optional) Specify the password used to connect to the remote server; you are asked to enter and then confirm the password.
<b>port</b> { <i>number</i>   <b>default</b> }	(Optional) You can change the port on which communications with the remote server take place; if this option is not specified, the protocol's default port is used.  The options are a port-ID number between zero and 4294967295, or <b>default</b> for the current protocol's default port.
<b>protocol</b> <i>name</i>	(Optional) Specify the file-transfer protocol to use. Available options are: <ul style="list-style-type: none"> <li>• <b>ftp</b></li> <li>• <b>scp</b></li> <li>• <b>sftp</b></li> <li>• <b>tftp</b></li> </ul>
<b>remote-file</b> <i>name</i>	(Optional) Specify the full path, including a file name, for the exported configuration; can be between one and 128 characters.
<b>schedule</b> { <b>bi-weekly</b>   <b>daily</b>   <b>weekly</b> }	(Optional) Specify how frequently the configuration is automatically exported: <ul style="list-style-type: none"> <li>• <b>bi-weekly</b> – Export occurs every two weeks.</li> <li>• <b>daily</b> – Export occurs every day.</li> <li>• <b>weekly</b> – Export occurs once a week.</li> </ul>

---

**user** *name* (Optional) Specify the user-account name employed to connect to the remote host; can be between zero and 510 characters.

---

**Command Modes**

scope org/scope cfg-export-policy/

---

**Command History**

Release	Modification
1.1.1	Command added.

---

**Usage Guidelines**

Changing `set adminstate` to `enable` and then issuing a `commit-buffer` command immediately triggers a configuration export.

**Example**

This example shows how to configure the default configuration-export policy, and then check the policy parameters:

```
firepower # scope org
firepower /org # scope cfg-export-policy default
firepower /org/cfg-export-policy # set protocol scp
firepower /org/cfg-export-policy* # set hostname 192.168.1.2
firepower /org/cfg-export-policy* # set remote-file /export/cfg-backup.xml
firepower /org/cfg-export-policy* # set user user1
firepower /org/cfg-export-policy* # set password
Enter a password:
Confirm the password:
firepower /org/cfg-export-policy* # set schedule weekly
firepower /org/cfg-export-policy* # set adminstate enable
firepower /org/cfg-export-policy* # commit-buffer
firepower /org/cfg-export-policy # show detail
Config Export policy:
  Name: default
  Description: Configuration Export Policy
  Admin State: Enable
  Protocol: Scp
  Hostname: 192.168.1.2
  User: user1
  Remote File: /export/cfg-backup.xml
  Schedule: Weekly
  Port: Default
  Current Task:
firepower /org/cfg-export-policy #
```

**Related Commands**

Command	Description
<b>export-config</b>	Exports the current system configuration to a remote server as an XML file; creates an export-configuration object.
<b>import-config</b>	Copies a previously exported XML configuration file to this appliance.
<b>set password-encryption-key</b>	Specifies a key used when encrypting sensitive information during configuration export.

## set (cfg-export-reminder)

To specify or edit the parameters for the configuration-export reminder object, use the **set** command in configuration-export-reminder mode.

```
set { adminstate | frequency }
```

<b>Syntax Description</b>	<b>adminstate</b> { <b>disable</b>   <b>enable</b> }	Enable or disable the export reminder. When disabled, configuration back-up reminder faults are not generated.
	<b>frequency</b> <i>number_of_days</i>	Specify the number of days that can pass without a configuration back-up occurring. After this period, the system will generate a reminder fault. This value can be between one and 365 days.
<b>Command Modes</b>	scope org/scope cfg-export-reminder/	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1.3	Command added.
<b>Usage Guidelines</b>	When the reminder is enabled, the system generates a fault when a configuration export hasn't been executed in the specified number of days.	

### Example

This example shows how to enter the export-reminder object, enable it, specify how often back-ups must occur, and then view the settings:

```
firepower # scope org
firepower /org # scope cfg-export-reminder
firepower /org/cfg-export-reminder # set adminstate enable
firepower /org/cfg-export-reminder* # set frequency 30
firepower /org/cfg-export-policy* # commit-buffer
firepower /org/cfg-export-reminder # show
```

```
Config Export Reminder:
  Config Export Reminder (Days): 30
  AdminState: Enable
firepower /org/cfg-export-reminder #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>scope cfg-export-policy</b>	Enters the configuration export policy.
	<b>show</b>	In configuration-export reminder mode, shows the current reminder object set-up.

# set cli

To specify whether command output lines wrap or truncate to fit the width of the terminal window, whether table headers are displayed, and whether commas or spaces are used to separate fields in command output tables, use the **set cli** command.

```
set cli {suppress-field-spillover {off|on}|suppress-headers {off|on}|table-field-delimiter {comma|none } }
```

## Syntax Description

<b>suppress-field-spillover</b> { <b>off</b>   <b>on</b> }	Use <b>off</b> to wrap output lines in the terminal window. Use <b>on</b> to truncate output lines at the end of the terminal window.
<b>suppress-headers</b> { <b>off</b>   <b>on</b> }	Use <b>off</b> to display table headers. Use <b>on</b> to not display table headers.
<b>table-field-delimiter</b> { <b>comma</b>   <b>none</b> }	Use <b>comma</b> to separate fields in command output tables with commas. Use <b>none</b> to separate fields in command output tables with spaces.

## Command Default

Command output lines wrap in the terminal window.  
Table headers are displayed.  
Spaces are used to separate fields in command output tables.

## Command Modes

Any command mode

## Command History

Release	Modification
1.1(1)	Command added.

## Usage Guidelines

Use this command to specify whether command output lines wrap or truncate to fit the width of the terminal window, whether table headers are displayed, and whether commas or spaces are used to separate fields in command output tables.

## Example

This example shows how to specify that command output lines truncate, and then how to reset to wrap:

```
FP9300-A# set cli suppress-field-spillover on
FP9300-A# show fault
Severity Code Last Transition Time ID Description
-----
Warning F16520 2010-01-21T18:33:22.065 5785755 [FSM:STAGE:RETRY]: detect
mezz cards in 1/6 (FSM-STAGE:sam:dme:ComputeBladeDiscover:NicPresence)
Condition F77960 2010-01-21T18:32:31.255 1089623 [FSM:STAGE:REMOTE-ERROR]: R
esult: end-point-unavailable Code: unspecified Message: sendSamDmeAdapterInfo: i
dentify failed

FP9300-A# set cli suppress-field-spillover off
FP9300-A# show fault
```

```

Severity Code      Last Transition Time      ID      Description
-----
Warning F16520  2010-01-21T18:33:22.065  5785755 [FSM:STAGE:RETRY:]: detect
Condition F77960  2010-01-21T18:32:31.255  1089623 [FSM:STAGE:REMOTE-ERROR]: R
FP9300-A#
    
```

**Related Commands**

Command	Description
show cli	Shows current CLI settings.
terminal	Sets the number of lines, and the width of the lines, displayed in the terminal window.

# set clock

To manually set the clock timing in FXOS, use the **set clock** command.

## set clock

<b>Syntax Description</b>	<b>set clock</b>	Use <b>set clock</b> to manually set the clock in FXOS.
<b>Command Modes</b>	scope system/scope services	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

## Example

This example shows how to set the clock in FXOS:

```
firepower# scope system
firepower /system# scope services
firepower /system/services # set clock aug 23 2021 12 00 00
firepower /system/services* # commit
firepower /system/services # show clock
Tue Aug 24 12:00:02 UTC 2021
```

# set cluster-control-link network

To set the cluster control link IP network in the cluster bootstrap configuration for the threat defense and ASA, use the **set cluster-control-link network** command.

**set cluster-control-link network** *a.b.0.0*

<b>Syntax Description</b>	<i>a.b.0.0</i>	Specifies any /16 network address, except for loopback (127.0.0.0/8) and multicast (224.0.0.0/4) addresses. If you set the value to 0.0.0.0, then the default network is used: 127.2.0.0.
---------------------------	----------------	---

<b>Command Default</b>	The default network is 127.2.0.0.
------------------------	-----------------------------------

<b>Command Modes</b>	scope ssa/create logical-device/create cluster-bootstrap/
----------------------	---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.4(1)	Command added.

<b>Usage Guidelines</b>	The chassis auto-generates the cluster control link interface IP address for each unit based on the chassis ID and slot ID: <i>a.b.chassis_id.slot_id</i> .
-------------------------	---

Bootstrap settings are meant for initial deployment only, or for disaster recovery. For normal operation, you can change most values in the application CLI configuration.

## Example

The following example shows how to set the mode to routed mode:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 clustered
Firepower /ssa/logical-device* # create cluster-bootstrap
firepower /ssa/logical-device/cluster-bootstrap* # set cluster-control-link network 10.10.0.0
firepower /ssa/logical-device/cluster-bootstrap* #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>create logical-device</b>	Creates the logical device.
	<b>create cluster-bootstrap</b>	Creates the cluster bootstrap configuration for the application.

# set collection-interval

To define how frequently monitored statistics are collected, use the **set collection-interval** command.

**set collection-interval** *interval*

<b>Syntax Description</b>	<i>interval</i>	Length of time defining the statistics collection interval; available values are: <ul style="list-style-type: none"> <li>• <code>1minute</code> – one-minute intervals</li> <li>• <code>2minutes</code> – two-minute intervals</li> <li>• <code>30seconds</code> – 30-second intervals</li> <li>• <code>5minutes</code> – five-minute intervals</li> </ul>
---------------------------	-----------------	--

<b>Command Modes</b>	scope monitoring/scope stats-collection-policy/
----------------------	---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

**Usage Guidelines**

Use the **set collection-interval** command to define how frequently statistics are collected, and use the **set reporting-interval** command to define how frequently the statistics are reported. These intervals define a statistics collection policy.

Reporting intervals are longer than collection intervals so that multiple statistical data points can be collected during the reporting interval, which provides sufficient data to calculate and report minimum, maximum, and average values.

Statistics can be collected and reported for each of the following functional areas of your Firepower system; use the **scope stats-collection-policy** command to access a specific collection policy:

- `Adapter` – statistics related to the adapters.
- `Chassis` – statistics related to the blade chassis.
- `FEX` – statistics related to configured Fabric Extender(s).
- `Host` – this policy is a placeholder for future support.
- `Port` – statistics related to the ports, including server ports, uplink Ethernet ports, and uplink Fibre Channel ports.
- `Server` – statistics related to servers.



**Note** There is one default statistics collection policy for each of the functional areas. You cannot create additional statistics collection policies and you cannot delete the existing default policies. You can only modify the default policies.

### Example

This example shows how to enter the statistics collection policy for ports, set the collection interval to one minute, set the reporting interval to 30 minutes, and then commit the transaction:

```
firepower # scope monitoring
firepower /monitoring # scope stats-collection-policy port
firepower /monitoring/stats-collection-policy # set collection-interval 1minute
firepower /monitoring/stats-collection-policy* # set reporting-interval 30minute
firepower /monitoring/stats-collection-policy* # commit-buffer
firepower /monitoring/stats-collection-policy #
```

### Related Commands

Command	Description
<b>scope stats-collection-policy</b>	Enters stats-collection-policy mode, where you manage statistics collection and reporting intervals.
<b>set reporting-interval</b>	Specifies how frequently statistics are reported.

# set con-absolute-session-timeout

To set the serial console absolute session timeout, use the **set con-absolute-session-timeout** command.

**set con-absolute-session-timeout** *seconds*

<b>Syntax Description</b>	<i>seconds</i>	Serial console absolute session timeout; value can be 0 to 3600 seconds. To disable this timeout, set the value to 0.
---------------------------	----------------	---

<b>Command Modes</b>	Default authentication mode
----------------------	-----------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

**Usage Guidelines** You can separately configure the absolute session timeout for serial console sessions. This means you can disable the serial console absolute session timeout for debugging while maintaining the absolute timeout for other forms of access.

## Example

This example shows how to enter default authentication mode and then set the serial console absolute timeout to four minutes:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set con-absolute-session-timeout 240
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>set refresh-period</b>	Sets the Web session refresh period.
	<b>show detail</b>	Displays the current session and absolute session timeout settings.

## set con-session-timeout

To set the serial console idle session timeout, use the **set con-session-timeout** command.

**set con-session-timeout** *seconds*

<b>Syntax Description</b>	<i>seconds</i>	Serial console idle session timeout; value can be 0 to 3600 seconds. To disable this timeout, set the value to 0.
---------------------------	----------------	---

<b>Command Modes</b>	Default authentication mode
----------------------	-----------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

**Usage Guidelines** Use this command to specify the idle session timeout for serial console sessions.

### Example

This example shows how to enter default authentication mode and then set the serial console idle timeout to four minutes:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set con-session-timeout 240
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>set refresh-period</b>	Sets the Web session refresh period.
	<b>show detail</b>	Displays the current session and absolute session timeout settings.

## set cpu-core-count

To set the CPU cores for a resource profile for use with container instances, use the **set cpu-core-count** command.

**set cpu-core-count** *cores*

### Syntax Description

<i>cores</i>	Sets the number of cores for the profile, between 6 and the maximum, depending on your chassis, as an even number. You <i>cannot</i> specify 8 cores.
--------------	---

### Command Modes

scope ssa/create resource-profile/

### Command History

Release	Modification
2.4(1)	Command added.

### Usage Guidelines

To specify resource usage per container instance, create one or more resource profiles. When you deploy the logical device/application instance, you specify the resource profile that you want to use. The resource profile sets the number of CPU cores; RAM is dynamically allocated according to the number of cores, and disk space is set to 40 GB per instance.

- The minimum number of cores is 6.
- You cannot specify 8 cores due to internal architecture.
- You can assign cores as an even number (6, 10, 12, 14 etc.) up to the maximum.
- The maximum number of cores available depends on the security module/chassis model.

The chassis includes a default resource profile called "Default-Small," which includes the minimum number of cores. You can change the definition of this profile, and even delete it if it is not in use. Note that this profile is created when the chassis reloads and no other profile exists on the system.

You cannot change the resource profile settings if it is currently in use. You must disable any instances that use it, then change the resource profile, and finally reenable the instance. If you resize instances in an established High Availability pair, then you should make all members the same size as soon as possible.

If you change the resource profile settings after you add the threat defense instance to the management center, update the inventory for each unit on the **Devices > Device Management > Device > System > Inventory** dialog box.

### Example

The following example adds three resource profiles.

```
firepower# scope ssa
firepower /ssa # enter resource-profile basic
firepower /ssa/resource-profile* # set description "lowest level"
firepower /ssa/resource-profile* # set cpu-core-count 6
firepower /ssa/resource-profile* # exit
firepower /ssa # enter resource-profile standard
firepower /ssa/resource-profile* # set description "middle level"
```

```

firepower /ssa/resource-profile* # set cpu-core-count 10
firepower /ssa/resource-profile* # exit
firepower /ssa # enter resource-profile advanced
firepower /ssa/resource-profile* # set description "highest level"
firepower /ssa/resource-profile* # set cpu-core-count 12
firepower /ssa/resource-profile* # commit-buffer
firepower /ssa/resource-profile #

```

Related Commands	Command	Description
	<b>create resource-profile</b>	Adds a resource profile for use with container instances.
	<b>set resource-profile-name</b>	Assigned the resource profile to the application instance.
	<b>show monitor detail</b>	Shows resource usage for the security module/engine slot.
	<b>show resource detail</b>	Shows resource allocation for the application instance.
	<b>show resource-profile user-defined</b>	Shows resource profile assignments.

## set deploy-type

To set the deployment type for an application instance, either native or container, use the **set deploy-type** command.

```
set deploy-type { native | container }
```

<b>Syntax Description</b>	<b>container</b>	Sets the application instance to the container type.
	<b>native</b>	Sets the application instance to the native type.
<b>Command Default</b>	The default type is native.	
<b>Command Modes</b>	scope ssa/scope slot/create app-instance/	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.4(1)	Command added for threat defense.

### Usage Guidelines

Application instances run in the following deployment types:

- Native instance—A native instance uses all of the resources (CPU, RAM, and disk space) of the security module/engine, so you can only install one native instance.
- Container instance—A container instance uses a subset of resources of the security module/engine, so you can install multiple container instances. Multi-instance capability is only supported for the threat defense; it is not supported for the ASA.



**Note** Multi-instance capability is similar to ASA multiple context mode, although the implementation is different. Multiple context mode partitions a single application instance, while multi-instance capability allows independent container instances. Container instances allow hard resource separation, separate configuration management, separate reloads, separate software updates, and full threat defense feature support. Multiple context mode, due to shared resources, supports more contexts on a given platform. Multiple context mode is not available on the threat defense.

For the Firepower 9300, you can use a native instance on some modules, and container instances on the other module(s).

### Example

The following example adds an threat defense application instance, and sets it to the container type:

```
Firepower# scope ssa
Firepower /ssa # scope slot 1
Firepower /ssa/slot # enter app-instance ftd MyDevice1
```

```
Firepower /ssa/slot/app-instance* # set deploy-type container
Firepower /ssa/slot/app-instance* # set resource-profile-name silver 1
Firepower /ssa/slot/app-instance* # set startup-version 6.3.0.1
Firepower /ssa/slot/app-instance* # exit
Firepower /ssa/slot* # exit
Firepower /ssa* #
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>show app-attrib</b>	Shows current application attributes.
<b>create resource-profile</b>	Creates a resource profile for use with container instances.
<b>show resource-profile-name</b>	Shows available resource profiles.

# set descr

To set a description for the port-channel, use the **set descr** command.

**set descr** *description*

<b>Syntax Description</b>	<b>description</b>	(Optional) Description. Enter up to 256 characters.
<b>Command Modes</b>	scope eth-uplink/scope fabric a/port-channel/	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.1	Command added.
<b>Usage Guidelines</b>	If your description includes spaces, special characters, or punctuation, you must begin and end your description with quotation marks. The quotation marks will not appear in the description field of any show command output Ethernet.	

## Example

This example shows how to set the description:

```
firepower-9300 # scope eth-uplink
firepower-9300 /eth-uplink # scope fabric a
firepower-9300 /eth-uplink/fabric # create port-channel id
firepower-9300 /eth-uplink/fabric/port-channel* # enable
firepower-9300 /eth-uplink/fabric/port-channel* # set descr "link"
firepower-9300 /eth-uplink/fabric/port-channel* # commit-buffer
firepower-9300 /eth-uplink/fabric/port-channel #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show interface</b>	Displays information about the interface, which includes the duplex parameter.

# set duplex

To set the duplex for all members of the port-channel, use the **set duplex** command.

```
set duplex { fullduplex | halfduplex }
```

Syntax Description	fullduplex	(Optional) Specifies the duplex mode as full.
	halfduplex	(Optional) Specifies the duplex mode as half.

**Command Modes** scope eth-uplink/scope fabric a/port-channel/

Command History	Release	Modification
	2.0.1	Command added.

**Usage Guidelines** You must set the speed before setting the duplex mode. If you specify 10- or 100-Mbps speed, the port is automatically configured to use half-duplex mode, but you can specify full-duplex mode instead. Gigabit Ethernet is full duplex only. You cannot change the duplex mode on Gigabit Ethernet ports or on a 10/100/1000-Mbps port that is set for Gigabit Ethernet.

## Example

This example shows how to set the interface duplex mode:

```
firepower-9300# scope eth-uplink
firepower-9300 /eth-uplink # scope fabric a
firepower-9300 /eth-uplink/fabric # create port-channel id
firepower-9300 /eth-uplink/fabric/port-channel* # enable
firepower-9300 /eth-uplink/fabric/port-channel* # set duplex halfduplex
firepower-9300 /eth-uplink/fabric/port-channel* # commit-buffer
firepower-9300 /eth-uplink/fabric/port-channel #
```

Related Commands	Command	Description
	show interface	Displays information about the interface, which includes the duplex parameter.

# set email

To set a contact email address for a user account, use the **set email** command.

**set email** *email\_address*

## Syntax Description

<i>email_address</i>	An email address for the user account. Specify the email address in the format: <i>user_name@domain_name</i> .
----------------------	--

## Command Modes

Callhome (/monitoring/callhome) mode – to specify a primary contact email address to be included in Call Home messages.

Local user (/security/local-user) mode – to specify a contact email address for the current local user.

## Command History

Release	Modification
1.1(1)	Command added.

## Usage Guidelines

If the email address includes special characters, such as # (hash), spaces, or & (ampersand), the email server may not be able to deliver email messages to that address. Cisco recommends using email addresses which comply with RFC2821 and RFC2822, and include only 7-bit ASCII characters.

In callhome mode, you can use a maximum of 2083 characters for the email address.

In local user mode, you can use a maximum of 510 characters for the email address.

## Example

This example shows how to specify an email address for the current local user:

```
FP9300-A /security/local-user # set email admin@example.com
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

## Related Commands

Command	Description
<b>create local-user</b>	Creates a new local user account.
<b>set phone-contact</b>	Specifies a telephone contact number for a Smart Call Home account.

# set enforce-strong-password

To enable and disable strong password enforcement, use the **set enforce-strong-password** command.

```
set enforce-strong-password { no | yes }
```

Syntax Description	no	Disables strong password enforcement.
	yes	Enables strong password enforcement.
Command Modes	Security mode	
Command History	Release	Modification
	1.1(1)	Command added.

## Usage Guidelines

A password is required for each locally authenticated user account. A user with admin or AAA privileges can configure the system to perform a password strength check on all user passwords. If password strength checking is enabled, each user must have a “strong” password.

We recommend that each user have a strong password. If password strength checking is enabled for locally authenticated users, FXOS rejects any password that does not meet the following requirements:

- Must contain a minimum of 8 characters and a maximum of 80 characters. (The [set min-password-length, on page 66](#) command can be used to specify the minimum number of characters required.)
- Must include at least one uppercase alphabetic character.
- Must include at least one lowercase alphabetic character.
- Must include at least one non-alphanumeric (special) character.
- Must not contain a character that is repeated more than three times consecutively, such as aaabbb.
- Must not contain three consecutive numbers or letters in any order, such as passwordABC or password321.
- Must not be identical to the user name or the reverse of the user name.
- Must pass a password dictionary check. For example, the password must not be based on a standard dictionary word.
- Must not contain the following symbols: \$ (dollar sign), ? (question mark), and = (equals sign).
- Must not be blank for local user and admin accounts.

## Example

This example shows how to enter security mode and enable strong password enforcement:

```
FP9300-A# scope security
FP9300-A /security # set enforce-strong-password yes
FP9300-A /security* # commit-buffer
```

```
FP9300-A /security #
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>set min-password-length</b>	Specifies a minimum password length.

# set expiration

To set an expiration date for a local user account, use the **set expiration** command.

```
set expiration { { apr | aug | dec | feb | jan | jul | jun | mar | may | nov | oct | sep } day year }
```

Syntax Description		
	{ <b>apr</b>   <b>aug</b>   <b>dec</b>   <b>feb</b>   <b>jan</b>   <b>jul</b>   <b>jun</b>   <b>mar</b>   <b>may</b>   <b>nov</b>   <b>oct</b>   <b>sep</b> }	The three-letter month abbreviation.
	<i>day</i>	Numeric day of the month; valid values are 1 through 31.
	<i>year</i>	Numeric year for expiration; maximum value is 2037.

**Command Modes** Local user mode—to specify an expiration date for the current local user.

Command History	Release	Modification
	1.1(1)	Command added.

**Usage Guidelines** After you configure a user account with an expiration date, you cannot reconfigure the account to not expire. You can however, reconfigure the account with a different expiration date.

## Example

This example shows how to enter security mode, create a new local user account and specify an expiration date for that account:

```
FP9300-A# scope security
FP9300-A /security # create local-user test_user
FP9300-A /security/local-user* # set expiration dec 31 2019
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

Related Commands	Command	Description
	<b>create local-user</b>	Creates a new local user account.
	<b>set password</b>	Specifies a password for a user account.

## set (export-config)

To edit the parameters for an existing export-configuration object, use the **set** command in export-configuration mode.

```
set { descr | password | port | protocol | remote-file | user }
```

### Syntax Description

<b>descr</b> <i>description</i>	(Optional) You can add a description to the configuration object; can be between one and 256 characters. Most alphanumeric characters are allowed, as are dashes and underscores; the string can end with punctuation such as semi-colon, period (full stop), and exclamation point, but you cannot embed those characters in the description.
<b>password</b>	(Optional) You can change the password used to connect to the remote server; you are asked to enter and then confirm the password.
<b>port</b> { <i>number</i>   <b>default</b> }	(Optional) You can change the port on which communications with the remote server take place. The options are a port-ID number between zero and 4294967295, or <b>default</b> for the current protocol's default port.
<b>protocol</b> <i>name</i>	(Optional) You can change the file-transfer protocol used to transmit the configuration back-up to the remote server. Available options are: <ul style="list-style-type: none"> <li>• ftp</li> <li>• scp</li> <li>• sftp</li> <li>• tftp</li> </ul>
<b>remote-file</b> <i>name</i>	(Optional) You can change the name of the back-up configuration file; can be between one and 128 characters.
<b>user</b> <i>name</i>	(Optional) You can change the user-account name employed to connect to the remote host; can be between zero and 510 characters.

### Command Modes

scope system/scope export-config/

### Command History

Release	Modification
1.1.3	Command added.

### Usage Guidelines

Use these options to change the back-up options for an existing export-configuration object.

An export-configuration object is created when you issue an **export-config** command to back up the current logical device and platform configuration, and **scope export-config** is used to enter the object and edit its parameters.

Please note the following:

- Beginning with FXOS 2.6.1, you must specify a key for use when encrypting sensitive information such as passwords and other secret keys during configuration export, and you must have specified it before you attempt to export the configuration.

Also, the same key used during export must be set on the target system when you import an exported configuration, unless the file was exported from an FXOS release prior to 2.6.1, in which case the target system will not check the encryption key and will allow the import.

- Do not modify the contents of the configuration file. If a configuration file is modified, configuration import using that file might fail.
- To avoid overwriting existing back-up files, please be sure to change the file name in the export operation, or copy the existing file to another location.

### Example

This example shows how to add a description to an existing export-configuration object:

```
firepower # scope system
firepower /system # scope export-config 192.168.1.2
firepower /system/export-config # set descr one-time_back-up_be_sure_to_change_file_name
firepower /system/export-config* # commit-buffer
firepower /system/export-config #
```

Related Commands	Command	Description
	<b>cfg-export-policy</b>	Configures a configuration export policy.
	<b>export-config</b>	Exports the current system configuration to a remote server as an XML file; creates an export-configuration object.
	<b>import-config</b>	Copies a previously exported XML configuration file to this appliance.
	<b>set password-encryption-key</b>	Specifies a key used when encrypting sensitive information during configuration export.

# set firstname

To specify the first name of a local user, use the **set firstname** command.

**set firstname** *name*

<b>Syntax Description</b>	<i>name</i>	The user's first name; can be zero to 32 characters.
<b>Command Modes</b>	Local user mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

## Example

This example shows how to enter security mode, create a new local user account and specify a first name and a last name for that user:

```
FP9300-A# scope security
FP9300-A /security # create local-user test_user
FP9300-A /security/local-user* # set firstname john
FP9300-A /security/local-user* # set lastname doe
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

Command	Description
<b>create local-user</b>	Creates a new local user account.
<b>set lastname</b>	Specifies the surname for a local user account.

# set flow-control-policy

To assign a flow control policy to an interface or a port-channel, use the **set flow-control-policy** command.

**set flow-control-policy** *name*

<b>Syntax Description</b>	<i>name</i>	The name of the flow control policy; maximum of 16 characters.
<b>Command Modes</b>	scope eth-uplink/scope fabric a/scope interface/ scope eth-uplink/scope fabric a/scope port-channel/	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.1	Command added.
<b>Usage Guidelines</b>	When you create a new flow control policy, you are automatically entered into flow-control/policy mode (eth-uplink/flow-control/policy) with an asterisk indicating the new policy is not yet committed. You can set policy property values and then commit the new policy. After you create a flow control policy, the policy name cannot be changed. You must delete the policy and create a new one.	

## Example

This example shows how to assign a flow control policy to an interface:

```
firepower-9300 # scope eth-uplink
firepower-9300 /eth-uplink # scope fabric
firepower-9300 /eth-uplink #/fabric # scope interface Ethernet1/8
firepower-9300 /eth-uplink/fabric/interface* # set flow-control-policy eth1-8flowcontrol
firepower-9300 /eth-uplink/fabric/interface* # commit-buffer
firepower-9300 /eth-uplink/fabric/interface #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>create policy (flow control)</b>	Creates a new flow control policy.
	<b>show interface</b>	Displays the interface status, which includes the speed parameters.
	<b>show port-channel</b>	Displays information about a port channel.

## set (flow-control policy)

To specify or edit the parameters for an existing flow-control policy, use the **set** command in flow-control/policy mode.

**set** { **prio** | **receive** | **send** }

Syntax Description		
<b>prio</b> { <b>auto</b>   <b>on</b> }	Sets the flow-control priority option:	<ul style="list-style-type: none"> <li>• <b>auto</b> – This device and the network will negotiate whether Point-to-Point Protocol (PPP) is used on this fabric.</li> <li>• <b>on</b> – PPP is enabled on this fabric.</li> </ul>
<b>receive</b> <b>off</b>	Specifies that pause requests from the network are ignored and traffic flow continues normally.	
<b>send</b> <b>off</b>   <b>on</b>	Sets the flow-control send parameter:	<ul style="list-style-type: none"> <li>• <b>off</b> – Traffic flows normally regardless of packet load.</li> <li>• <b>on</b> – This device sends a pause request to the network if the incoming packet buffer becomes full. The pause remains in effect for a few milliseconds while traffic returns to normal levels.</li> </ul>

**Command Modes** scope eth-uplink/scope flow-control/policy/

### Command History

Release	Modification
1.1.1	Command added.

### Usage Guidelines

Use this command to specify flow control receive options. When you specify **off**, pause requests from the network are ignored and traffic flow continues as normal. When you specify **on**, pause requests are honored and all traffic is halted on that uplink port until the network cancels the pause request.

Use this command to specify flow control send options. When you specify **off**, traffic on the port flows normally regardless of the packet load. When you specify **on**, the FXOS sends a pause request to the network if the incoming packet rate becomes too high. The pause remains in effect for a few milliseconds before traffic is reset to normal levels.

### Example

This example shows how to create and enter a named policy for flow control, and then set policy parameters:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope flow-control
firepower /eth-uplink/flow-control # enter policy FCpolicy1
firepower /eth-uplink/flow-control/policy* # set prio auto
firepower /eth-uplink/flow-control/policy* # set send on
firepower /eth-uplink/flow-control/policy* # commit-buffer
```

```
firepower /eth-uplink/flow-control/policy #
```

**Related Commands**

Command	Description
<b>show policy</b>	In flow-control/policy mode, displays property values for the current flow-control policy. In flow-control mode, displays property values for all currently defined flow-control policies.

# set frequency

To generate a fault when a configuration export hasn't been executed in a certain number of days, use the **set frequency** command.

**set frequency** *days*

<b>Syntax Description</b>	<i>days</i>	Config Export Reminder (Days).
<b>Command Modes</b>	scope org/scope cfg-export-reminder/	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0.1	Command added.

## Example

This example shows how to set the configuration frequency days for export reminder:

```
firepower-9300* # scope org
firepower-9300 /org* # scope cfg-export-reminder
firepower-9300 /org/scope cfg-export-reminder* # set frequency 2
firepower-9300 /org/scope cfg-export-reminder* # commit-buffer
firepower-9300 /org/scope cfg-export-reminder* # show detail
Config Export Reminder:
Config Export Reminder (Days): 10
AdminState: Enable
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	set adminstate	Specifies the admin state for the export reminder.

# set http-proxy-server-enable

To enable or disable an HTTP/HTTPS proxy for Smart Software Licensing and Smart Call Home, use the **set http-proxy-server-enable** command.

**set http-proxy-server-enable** {off|on}

Syntax Description	off	Disables the Smart Call Home HTTP/HTTPS proxy.
	on	Enables the Smart Call Home HTTP/HTTPS proxy.

**Command Default** The HTTP/HTTPS proxy is disabled by default.

**Command Modes** Callhome mode

**Usage Guidelines** If your network uses an HTTP proxy for Internet access, you must enable the proxy and configure its address for Smart Software Licensing. This proxy is also used for Smart Call Home in general.

## Example

This example shows how to enable an HTTP proxy:

```
FP9300-A# scope monitoring
FP9300-A /monitoring # scope callhome
FP9300-A /monitoring/callhome # set http-proxy-server-enable on
FP9300-A /monitoring/callhome #
```

Related Commands	Command	Description
	<b>set http-proxy-server-url</b>	Sets the HTTP or HTTPS address of the proxy server.
<b>set http-proxy-server-port</b>	Sets the communications port for the proxy server.	

# set http-proxy-server-port

To set the HTTP/HTTPS proxy server port for Smart Software Licensing and Smart Call Home, use the **set http-proxy-server-port** command.

**set http-proxy-server-port** *port\_number*

<b>Syntax Description</b>	<i>port_number</i>	The port for the HTTP or HTTPS proxy server; range is 1 to 65535.
<b>Command Default</b>	The HTTP/HTTPS proxy is disabled by default. The proxy must be enabled before you enter the server address and port number.	
<b>Command Modes</b>	Callhome mode	
<b>Usage Guidelines</b>	If your network uses an HTTP proxy for Internet access, you must enable the proxy and configure its address for Smart Software Licensing. This proxy is also used for Smart Call Home in general.	

## Example

This example shows how to enter an HTTP/HTTPS proxy-server port number:

```
FP9300-A# scope monitoring
FP9300-A /monitoring # scope callhome
FP9300-A /monitoring/callhome # set http-proxy-server-port 443
FP9300-A /monitoring/callhome #
```

Related Commands	Command	Description
	<b>set http-proxy-server-enable</b>	Enables or disables the HTTP/HTTPS proxy for Smart Software Licensing and Smart Call Home.
	<b>set http-proxy-server-url</b>	Sets the HTTP/HTTPS address for the proxy server.

# set http-proxy-server-url

To set the HTTP/HTTPS proxy server address for Smart Software Licensing and Smart Call Home, use the **set http-proxy-server-url** command.

**set http-proxy-server-url** *url*

<b>Syntax Description</b>	<i>url</i>	The HTTP or HTTPS address of the proxy server; can be a maximum of 2083 characters.
<b>Command Default</b>	The HTTP/HTTPS proxy is disabled by default. The proxy must be enabled before you enter the server address.	
<b>Command Modes</b>	Callhome mode	
<b>Usage Guidelines</b>	If your network uses an HTTP proxy for Internet access, you must enable the proxy and configure its address for Smart Software Licensing. This proxy is also used for Smart Call Home in general.	

## Example

This example shows how to enter an HTTPS proxy-server address:

```
FP9300-A# scope monitoring
FP9300-A /monitoring # scope callhome
FP9300-A /monitoring/callhome # set http-proxy-server-url https://209.165.201.10
FP9300-A /monitoring/callhome #
```

Related Commands	Command	Description
	<b>set http-proxy-server-enable</b>	Enables or disables the HTTP/HTTPS proxy for Smart Software Licensing and Smart Call Home.
	<b>set http-proxy-server-port</b>	Sets the communications port for the proxy server.

# set https

To specify HTTPS service parameters, use the **set https** command.

```
set https { auth-type { cert-auth | cred-auth } | cipher-suite cipher_string | cipher-suite-mode
{ custom | high-strength | low-strength | medium-strength } | crl-mode { relaxed | strict } | keyring
keyring_name | port port_number }
```

## Syntax Description

<b>auth-type</b> { <b>cert-auth</b>   <b>cred-auth</b> }	(Optional) Specifies the type of authentication to use for HTTPS access:  <ul style="list-style-type: none"> <li>• <b>cert-auth</b>—Sets your system to use a client certificate in conjunction with LDAP to authenticate users for HTTPS access.</li> <li>• <b>cred-auth</b>—Sets the system to use credential-based user authentication for HTTPS access.</li> </ul>
<b>cipher-suite</b> <i>cipher_string</i>	(Optional) Specifies the definition string for the cipher suite to be used with the custom <b>cipher-suite-mode</b> .  <p>The specification string can contain up to 256 characters and must conform to the OpenSSL Cipher Suite specifications. You cannot use any spaces or special characters, except ! (exclamation point), + (plus sign), - (hyphen), and : (colon). See <a href="http://httpd.apache.org/docs/2.0/mod/mod_ssl.html#sslciphersuite">http://httpd.apache.org/docs/2.0/mod/mod_ssl.html#sslciphersuite</a> for additional information.</p> <p><b>Note</b> This string is ignored if <b>cipher-suite-mode</b> is set to anything other than <b>custom</b>.</p>
<b>cipher-suite-mode</b> { <b>custom</b>   <b>high-strength</b>   <b>low-strength</b> }	(Optional) Sets the level of Cipher Suite security used:  <ul style="list-style-type: none"> <li>• <b>custom</b>—Lets you define a custom Cipher Suite security specification string using the <b>cipher-suite</b> option.</li> <li>• <b>high-strength</b>—ALL:!EDH-RSA-DES-CBC3-SHA: !EDH-DSS-DES-CBC3-SHA: !DES-CBC3-SHA:!ADH:!3DES: !EXPORT40:!EXPORT56:!LOW:!MEDIUM:!eNULL:!RC4:!MD5: !IDEA:+HIGH:+EXP</li> <li>• <b>low-strength</b>—ALL:!EDH-RSA-DES-CBC3-SHA: !EDH-DSS-DES-CBC3-SHA: !DES-CBC3-SHA:!ADH:!3DES: !EXPORT40:!EXPORT56:RC4+RSA: !IDEA:+HIGH:+MEDIUM:+LOW:+EXP:+eNULL</li> <li>• <b>medium-strength</b>—ALL:!EDH-RSA-DES-CBC3-SHA: !EDH-DSS-DES-CBC3-SHA: !DES-CBC3-SHA:!ADH:!3DES:!EXPORT40:!EXPORT56: !LOW:!RC4:!MD5:!IDEA:+HIGH:+MEDIUM:+EXP:+eNULL</li> </ul> <p>Generally, cipher strength is roughly based on the bits of security (or symmetric key size), with “low” meaning less than 128 bits of security, “medium” meaning equal to 128 bits, and “high” meaning greater than 128 bits of security.</p>

---

**crl-mode** { **relaxed** | **strict** } (Optional) Defines the level of certificate revocation list (CRL) checking for HTTPS connections:

- **relaxed**—Certificates found on a CRL may be used to allow HTTPS authentication, depending on the reason for the certificate's listing; a warning message is logged whenever this occurs. Essentially disables CRL checking.
- **strict**—Connection authentication fails for any certificate on a CRL; a warning message is logged whenever this occurs. Also, the CRL must be up to date.

---

**keyring** *keyring\_name* (Optional) Specifies the name of the RSA keyring to be used for HTTPS connections.

---

**port** *port\_number* (Optional) Specifies the port to be used for HTTPS connections; can be 1 to 65535. Default is 443.

---

#### Command Default

The default HTTPS authentication configuration on the Firepower 4100/9300 chassis is credential-based. The default Cipher Suite security level is medium strength.

#### Command Modes

Services mode

#### Command History

Release	Modification
1.1(1)	Command added.

#### Usage Guidelines

If certificate authentication is enabled, that is the only form of authentication permitted for HTTPS.

The following requirements must be met by the client certificate to use this feature:

- The user name must be included in the X509 attribute Subject Alternative Name email.
- The client certificate must be signed by a root CA which has had its certificate imported into a trustpoint on the supervisor.



#### Caution

When you commit most of these configuration parameters (specifically keyring, port, cipher-suite, and custom cipher-suite-mode), all current HTTP and HTTPS sessions are closed without user warning.

---

#### Example

This example shows how to enable certificate-based authentication for HTTPS access:

```
FP9300-A# scope system
FP9300-A /system # scope services
FP9300-A /system/services # set https auth-type cert-auth
FP9300-A /system/services* # commit-buffer
FP9300-A /system/services #
```

Related Commands	Command	Description
	enable https	Enables the HTTPS service.
	show https	Shows current HTTPS service configuration.

## set (interface)

To specify or change the parameters for an interface, use the **set** command in interface mode.

### set

{ **admin-duplex** | **admin-speed** | **auto-negotiation** | **descr** | **eth-link-profile** | **flow-control-policy** | **nw-ctrl-policy** | **port-type** | **user-label** }

### Syntax Description

<b>admin-duplex</b> { <b>fullduplex</b>   <b>halfduplex</b> }	Defines the duplex mode for the interface: <ul style="list-style-type: none"> <li>• <b>fullduplex</b> – Specifies simultaneous two-way communications.</li> <li>• <b>halfduplex</b> – Specifies one-way-at-a-time communications.</li> </ul>
<b>admin-speed</b> { <b>100gbps</b>   <b>100mbps</b>   <b>10gbps</b>   <b>10mbps</b>   <b>1gbps</b>   <b>40gbps</b> }	Specify the interface data-transfer speed: <ul style="list-style-type: none"> <li>• <b>100gbps</b> – One hundred Gigabits per second.</li> <li>• <b>100mbps</b> – One hundred Megabits per second.</li> <li>• <b>10gbps</b> – Ten Gigabits per second.</li> <li>• <b>10mbps</b> – Ten Megabits per second.</li> <li>• <b>1gbps</b> – One Gigabit per second.</li> <li>• <b>40gbps</b> – Forty Gigabits per second.</li> </ul>
<b>auto-negotiation</b> { <b>no</b>   <b>yes</b> }	Enables or disables auto-negotiation of common transmission parameters such as speed, duplex and flow control. <ul style="list-style-type: none"> <li>• <b>no</b> – Disables auto-negotiation.</li> <li>• <b>yes</b> – Enables auto-negotiation.</li> </ul>
<b>descr</b> <i>description</i>	You can add a description to the interface; the description can be between zero and 256 characters. Most alphanumeric characters are allowed, as are dashes and underscores; spaces are not allowed. The string can end with punctuation such as semi-colon, period (full stop), and exclamation point, but you cannot embed those characters in the description.
<b>eth-link-profile</b> <i>name</i>	You can assign an Ethernet Link Profile to the interface, automatically configuring the interface according to the profile parameters. Provide the name of the profile; can be up to 16 alphanumeric characters.
<b>flow-control-policy</b> <i>name</i>	You can assign a flow-control policy to the interface; provide the policy name, which can be up to 16 alphanumeric characters.
<b>nw-ctrl-policy</b> <i>name</i>	You can assign a network-control policy to the interface; provide the policy name, which can be up to 16 alphanumeric characters.

<b>port-type</b> { <b>cluster</b>   <b>data</b>   <b>data-sharing</b>   <b>firepower-eventing</b>   <b>mgmt</b> }	Specify the interface type or function: <ul style="list-style-type: none"> <li>• <b>cluster</b> – Specify <b>cluster</b> only if you want to use this interface as the cluster control link.</li> <li>• <b>data</b> – Use for regular data transmission. This is the default type.</li> <li>• <b>data-sharing</b> – Use for regular data; only supported with container instances.</li> <li>• <b>firepower-eventing</b> – Use this interface as a secondary management interface for threat defense devices. The firepower-eventing interface is used to carry all event traffic (such as Web events).</li> <li>• <b>mgmt</b> – Use to manage application instances. You can only assign one management interface per logical device.</li> </ul>
--	--

See [set port-type, on page 83](#) for more information about this command.

<b>user-label</b> <i>label</i>	You can apply a descriptive label to this interface. can be between zero and 16 alphanumeric characters.
--------------------------------	--

#### Command Modes

scope eth-uplink/scope fabric a/interface/

#### Command History

Release	Modification
2.4(1)	We added the <b>data-sharing</b> type.
1.1(4)	We added the <b>firepower-eventing</b> type.
1.1(1)	Command added.

#### Usage Guidelines

The type `cluster` is a special interface type used for a clustered logical device. This type is automatically assigned to the cluster control link for inter-unit cluster communications. By default, the cluster control link is automatically created on port-channel 48.

Data interfaces cannot be shared between logical devices.

The type `data-sharing` is supported only with container instances, these data interfaces can be shared by one or more logical devices/container instances (threat defense-only). Each container instance can communicate over the backplane with all other instances that share this interface. Shared interfaces can affect the number of container instances you can deploy. Shared interfaces are not supported for bridge group member interfaces (in transparent mode or routed mode), inline sets, passive interfaces, or failover links.

A `firepower-eventing` interface is a secondary management interface for threat defense devices. To use this interface, you must configure its IP address and other parameters at the threat defense CLI. For example, you can separate management traffic from events (such as Web events). See the “Management Interfaces” section in the *System Configuration* chapter of the Management Center configuration guide. Firepower-eventing interfaces can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface.

Use `mgmt` interfaces to manage application instances. They can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface. You can only assign one management interface per logical device.

The interface speed that you specify can affect the duplex mode used for an interface, so you must set the speed before setting the duplex mode. If you specify 10- or 100-Mbps speed, the port is automatically configured to use half-duplex mode, but you can specify full-duplex mode instead. If you specify a speed of 1000 Mbps (1Gbps) or faster, full duplex is automatically used.

If you edited the default flow control policy, it is already applied to interfaces. If you created a new policy, you can apply it to the interface.

### Example

This example shows how to set the interface speed to 10 Gbps and the port type to data:

```
firepower # scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # enter interface Ethernet1/8
firepower /eth-uplink/fabric/interface # enable
firepower /eth-uplink/fabric/interface* # set admin-speed 10gbps
firepower /eth-uplink/fabric/interface* # set port-type data
firepower /eth-uplink/fabric/interface* # commit-buffer
firepower /eth-uplink/fabric/interface
```

### Related Commands

Command	Description
<b>enter interface</b>	Enters an interface so you can configure and manage the interface settings.
<b>scope interface</b>	Scopes into an interface so you can configure and manage the interface settings.
<b>show interface</b>	Displays interface configuration and status information.

# set ipv6

To enable or disable the IPv6 support on firepower device, use the **set ipv6** command in fabric interconnect mode.

**set ipv6** [ **enable** | **disable** ]

<b>Syntax Description</b>	<b>enable/disable</b>	Enables or disables IPv6 support on the firepower device.
<b>Command Modes</b>	scope fabric-interconnect/scope ipv6-config	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.13(1)	Command added.
<b>Usage Guidelines</b>	By default, IPv6 will not be set. Use this command to enable or disable IPv6.	

## Example

This example shows how to enable IPv6 in a firepower device:

```
firepower # scope fabric-interconnect
firepower /fabric-interconnect # scope ipv6-config
firepower /fabric-interconnect/ipv6-config # set ipv6 enable
firepower /fabric-interconnect/ipv6-config* # commit-buffer
```

## set ipv6-auto eui64

To generate IPv6 address based on eui64 method, use the **set ipv6-auto eui64** command in fabric interconnect mode. The lower 64 bits are derived from the hardware address identifier such as MAC.

### set ipv6 auto eui64

<b>Syntax Description</b>	<b>auto eui64</b>	Generates the ipv6 address based on the hardware identifiers.
<b>Command Modes</b>	scope fabric-interconnect/scope ipv6-config	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.13(1)	Command added.
<b>Usage Guidelines</b>	You must have a valid global address present on the management interface to set ipv6-auto eui64.	

### Example

This example shows how to set the ipv6-auto eui64:

```
firepower # scope fabric-interconnect
firepower /fabric-interconnect # scope ipv6-config
firepower /fabric-interconnect/ipv6-config # set ipv6-auto eui64
firepower /fabric-interconnect/ipv6-config* # commit-buffer
```

## set ipv6-auto stablesec

To generate ipv6 address based on stable secret seed mechanism, use the **set ipv6-auto stablesec** command in fabric interconnect mode.

### set ipv6 auto stablesec

<b>Syntax Description</b>	<b>auto stablesec</b>	Generates the ipv6 address based on the stable secret seed values.
<b>Command Modes</b>	scope fabric-interconnect/scope ipv6-config	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.13(1)	Command added.

### Example

This example shows how to set the ipv6-auto stablesec:

```
firepower # scope fabric-interconnect
firepower /fabric-interconnect # scope ipv6-config
firepower /fabric-interconnect/ipv6-config # set ipv6-auto stablesec
Warning: Setting ipv6readycfg to stablesec will require reboot
firepower /fabric-interconnect/ipv6-config* # commit-buffer
```

## set ipv6-ready

To set the IPv6 address based on eui64 or stable secret seed method based on the input IPv6 address, use the **set ipv6-ready** command in fabric interconnect mode.

**set ipv6-ready** [ **ipv6-addr** *address* **ipv6-readyconfig-eui64** **ipv6-readyprefix** *prefix* | **ipv6-addr** *address* **ipv6-readyconfig stablesec** **ipv6-readyprefix** *prefix* ]

Syntax Description		
<b>ipv6-addr</b> <address>	Input IPv6 address	
<b>ipv6-readyconfig eui64</b>	eui64 method to generate the ipv6 address based on the input address	
<b>ipv6-readyconfig stablesec</b>	stablesec method to generate the ipv6 address based on the input address	
<b>ipv6-readyprefix</b> <prefix>	IPv6 prefix	
Command Modes	scope fabric-interconnect/scope ipv6-config	
Command History	Release	Modification
	2.13(1)	Command added.

### Example

This example shows how to set the set the ipv6 address based on eui64 method :

```
firepower # scope fabric-interconnect
firepower /fabric-interconnect # scope ipv6-config
firepower /fabric-interconnect/ipv6-config # set ipv6-ready ipv6-addr 2003::12
ipv6-readyconfig eui64 ipv6-readyprefix 64
firepower /fabric-interconnect/ipv6-config* # commit-buffer
```

This example shows how to set the set the ipv6 address based on stablesec method :

```
firepower # scope fabric-interconnect
firepower /fabric-interconnect # scope ipv6-config
firepower /fabric-interconnect/ipv6-config # set ipv6-ready ipv6-addr
e2ca:83a7:eb48:8f6f:da04:949b:b701:1049 ipv6-readyconfig stablesec ipv6-readyprefix 64
Warning: Setting ipv6readycfg to stablesec will require reboot
firepower /fabric-interconnect/ipv6-config* # commit-buffer
```

## set keyring-name

To assign a keyring to an IPsec connection, use the **set keyring-name** command.

**set keyring-name** *name*

<b>Syntax Description</b>	<i>name</i>	The name of a keyring to be assigned to the IPsec connection; maximum of 16 characters.
---------------------------	-------------	---

**Command Modes** Connection (/security/ipsec/connection) mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

**Usage Guidelines** Use this command to add a keyring to an IPsec connection.

### Example

This example shows how to add a keyring to the current IPsec connection:

```
FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # enter connection testconn
FP9300-A /security/ipsec/connection # set keyring-name kr22
FP9300-A /security/ipsec/connection* # commit-buffer
FP9300-A /security/ipsec/connection #
```

<b>Command</b>	<b>Description</b>
<b>create connection</b>	Creates a new IPsec connection.
<b>set keyring-passwd</b>	Specifies the passphrase for a keyring assigned to an IPsec connection.

# set lastname

To specify the last name of a local user, use the **set lastname** command.

**set lastname** *name*

<b>Syntax Description</b>	<i>name</i>	The user's surname; can be 0 to 32 characters.
<b>Command Modes</b>	Local user mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

## Example

This example shows how to enter security mode, create a new local user account, and then specify a first name and a last name for that user.

```
FP9300-A# scope security
FP9300-A /security # create local-user test_user
FP9300-A /security/local-user* # set firstname john
FP9300-A /security/local-user* # set lastname doe
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

Command	Description
<b>create local-user</b>	Creates a new local-user account.
<b>set firstname</b>	Specifies the first name for a local user account.

## set link-state-sync

To synchronize the operational link state with the physical link state for data interfaces using a service state, use the **set link-state-sync** command.

### set link-state-sync

#### Syntax Description

This command has no arguments or keywords.

#### Command Modes

scope ssa

#### Command History

Release	Modification
2.9(1)	Command added.

#### Usage Guidelines

Use this command to synchronize the FTD operational link state with the physical link state for data interfaces.

#### Example

This example shows how to enter scope ssa mode and then set the link-state-sync.

```
firepower# scope ssa
firepower /ssa # scope logical-device <logical device identifier>
firepower /ssa/logical-device # set link-state-sync ?
    disabled  Disabled
    enabled   Enabled
```

# set local-address

To specify the local IP address for an IPsec connection, use the **set local-address** command.

**set local-address** *ip\_address*

<b>Syntax Description</b>	<i>ip_address</i>	Provide an IPv4 or IPv6 local gateway address for the IPsec connection; maximum of 510 characters.
<b>Command Modes</b>	Connection mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.
<b>Usage Guidelines</b>	Use this command and the <b>set remote-address</b> command to define the endpoints of an IPsec connection.	

## Example

This example shows how to set the local address for an IPsec connection:

```

FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # enter connection testconn
FP9300-A /security/ipsec/connection # set local-address 209.165.201.12
FP9300-A /security/ipsec/connection* # commit-buffer
FP9300-A /security/ipsec/connection #

```

Command	Description
<b>create connection</b>	Creates a new IPsec connection.
<b>set remote-addr</b>	Sets the remote IP address for an IPsec connection.

# set log-level

To specify the IPsec logging level, use the **set log-level** command.

**set log-level** *log\_level*

<b>Syntax Description</b>	<i>log_level</i>	Enter a value between 0 and 4 to specify IPsec log verbosity; default is 1. <b>0</b> – Basic auditing information; for example, SA up/down. <b>1</b> – General control flow information, with errors. <b>2</b> – More detailed control flow information; includes debugging information. <b>3</b> – Includes raw data dumps (hexadecimal). <b>4</b> – Includes sensitive information in the data dumps; for example, SA keys.
---------------------------	------------------	--

<b>Command Modes</b>	IPsec mode
----------------------	------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

<b>Usage Guidelines</b>	Use the <b>show ipsec-log</b> command to view the logs.
-------------------------	---

## Example

This example shows how to set the IPsec logging level to 2:

```
FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # set log-level 2
FP9300-A /security/ipsec* # commit-buffer
FP9300-A /security/ipsec #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show ipsec-log</b>	Shows the IPsec log file.

## set max-login-attempts

To specify the maximum number of failed login attempts allowed, use the **set max-login-attempts** command.

**set max-login-attempts** *max\_attempts*

<b>Syntax Description</b>	<i>max_attempts</i>	The maximum number of failed login attempts before the user is locked out of the system. The value can range from 0 to 10; the default is 0.
---------------------------	---------------------	--

<b>Command Modes</b>	Security mode
----------------------	---------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

**Usage Guidelines** If any user (including admin users) exceeds this maximum number of login attempts, the user is locked out of the system and must wait a specified amount of time before being allowed to log in again. No notification appears indicating that the user is locked out.

### Example

This example shows how to enter security mode and specify a maximum number of login attempts:

```
FP9300-A# scope security
FP9300-A /security # set max-login-attempts 4
FP9300-A /security* # commit-buffer
FP9300-A /security #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>clear lock-status</b>	Clears a user's locked-out status.
	<b>set user-account-unlock-time</b>	Specifies the amount of time a user remains locked out of the system after reaching the maximum number of login attempts.

# set message

To add or replace the lines of text presented as the pre-login banner, use the **set message** command.

**set message**

## Syntax Description

This command has no arguments or keywords.

## Command Modes

scope security/scope banner/scope pre-login-banner/

## Command History

Release	Modification
1.1(1)	Command added.

## Usage Guidelines

After entering the command, you are prompted to enter the lines of banner text. You must enter `ENDOFBUF` (must be all capital letters) to terminate the banner text.



**Note** The pre-login banner object must already exist; see [create pre-login-banner](#).

## Example

This example shows you how to create and specify a pre-login banner, then commit and view it:

```
firepower # scope security
firepower /security # scope banner
firepower /security/banner # create pre-login-banner
firepower /security/banner/pre-login-banner* # set message
Enter lines one at a time. Enter ENDOFBUF to finish. Press ^C to abort.
Enter prelogin banner:
>Firepower-9300-2
>Western Data Center
>ENDOFBUF
firepower /security/banner/pre-login-banner* # commit
firepower /security/banner/pre-login-banner # show

Pre login banner:
  Message
  -----
  Firepower-9300-2
  Western Data Center

firepower /security/banner/pre-login-banner #
```

## Related Commands

Command	Description
<b>clear message</b>	Removes the text from an existing pre-login banner; the actual banner object itself is not deleted.

Command	Description
<b>create pre-login-banner</b>	Creates a banner to be presented prior to the log-in screen; the banner object is initially empty.

# set min-password-length

To specify a minimum length for user passwords, use the **set min-password-length** command.

**set min-password-length** *num\_chars*

<b>Syntax Description</b>	<i>num_chars</i>	The minimum number of characters required for user passwords; value can range from 8 to 80.
---------------------------	------------------	---

<b>Command Modes</b>	Security mode
----------------------	---------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

**Usage Guidelines** If enabled, users must create passwords with the specified minimum number of characters or more. For example, if *num\_chars* is set to 15, passwords must consist of at least 15 characters.

## Example

This example shows how to enter security mode and specify a minimum password length of 15 characters:

```
FP9300-A# scope security
FP9300-A /security # set min-password-length 15
FP9300-A /security* # commit-buffer
FP9300-A /security #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>set enforce-strong-password</b>	Enables and disables strong password enforcement.

# set mode

To specify the IPSec connection mode, use the **set mode** command.

```
set mode {transport | tunnel}
```

<b>Syntax Description</b>	<b>transport</b>	Sets the connection mode to <b>transport</b> .
	<b>tunnel</b>	Sets the connection mode to <b>tunnel</b> .
<b>Command Modes</b>	Connection mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.
<b>Usage Guidelines</b>	In transport mode, only the payload of an IP packet is encrypted; in tunnel mode, the entire packet is encrypted. Transport mode is generally used for end-to-end sessions, and tunnel mode is used for all other types of connections (for example, between gateways).	

## Example

This example shows how to set the IPSec connection mode to tunnel:

```
FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # enter connection testconn
FP9300-A /security/ipsec/connection # set mode tunnel
FP9300-A /security/ipsec/connection* # commit-buffer
FP9300-A /security/ipsec/connection #
```

Command	Description
<b>create connection</b>	Creates a new IPSec connection.
<b>set local-addr</b>	Sets the local IP address for an IPSec connection.
<b>set remote-addr</b>	Sets the remote IP address for an IPSec connection.

# set modulus

To specify the RSA key modulus (SSL key length) in bits, use the **set modulus** command.

**set modulus** { **mod1536** | **mod2048** | **mod2560** | **mod3072** | **mod3584** | **mod4096** }

## Syntax Description

RSA key modulus (SSL key length) in bits

Valid options are:

- **mod1536** – Modulus is 1536 bits
- **mod2048** – Modulus is 2048 bits
- **mod2560** – Modulus is 2560 bits
- **mod3072** – Modulus is 3072 bits
- **mod3584** – Modulus is 3584 bits
- **mod4096** – Modulus is 4096 bits

## Command Modes

Keyring mode

## Command History

Release	Modification
1.1(1)	Command added.

## Usage Guidelines

Use this command to specify the key length for a keyring.

### Example

This example shows how to specify a key length of 2048 bits for a keyring:

```
FP9300-A# scope security
FP9300-A /security # scope keyring test-ring
FP9300-A /security/keyring # set modulus 2048
FP9300-A /security/keyring* # commit-buffer
switch-A /security/keyring #
```

## Related Commands

Command	Description
<b>set cert</b>	Enters an RSA certificate for a keyring.
<b>set regenerate</b>	Regenerates the RSA keys in the default keyring.
<b>set trustpoint</b>	Specifies whether the keyring certificate can be regenerated.

# set nd

To enable or disable the IPv6 ND support on the firepower device, use the **set nd** command in fabric interconnect mode.

**set nd** [ **enable** | **disable** ]

<b>Syntax Description</b>	<b>enable</b>	Enables the rdnsd (ipv6 recursive dns server discovery daemon) to run, once it is set to enable.
	<b>disable</b>	Disables the rdnsd daemon in the firepower device.
<b>Command Modes</b>	scope fabric-interconnect/scope ipv6-config	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.13(1)	Command added.
<b>Usage Guidelines</b>	By default, ND will not be set. Use this command to enable or disable IPv6.	

## Example

This example shows how to enable ND in a firepower device:

```
firepower # scope fabric-interconnect
firepower /fabric-interconnect # scope ipv6-config
firepower /fabric-interconnect/ipv6-config # set nd enable
firepower /fabric-interconnect/ipv6-config* # commit-buffer
```

## set out-of-band

To change the management IP address for the device, use the **set out-of-band** command.

For an IPv4 address:

```
set out-of-band { gw gateway_address | ip ip_address | netmask network_mask }
```

For an IPv6 address:

```
set out-of-band { ipv6 ipv6_address | ipv6-gw ipv6_gateway | ipv6-prefix ipv6_prefix }
```

### Syntax Description

<b>gw</b> <i>gateway_address</i>	Provide an IPv4 gateway address.
<b>ip</b> <i>ip_address</i>	Provide an IPv4 address for device management access.
<b>netmask</b> <i>network_mask</i>	Provide a netmask for the IPv4 address.
<b>ipv6</b> <i>ipv6_address</i>	Provide an IPv6 address for device management access.
<b>ipv6-gw</b> <i>ipv6_gateway</i>	Provide an IPv6 gateway address.
<b>prefix</b> <i>ipv6_prefix</i>	Provide a prefix length for the IPv6 address.
<b>Note</b>	Only IPv6 Global Unicast addresses are supported as the chassis's IPv6 management address.

### Command Modes

IPv4 address: fabric interconnect mode

IPv6 address: IPv6 configuration (fabric-interconnect/ipv6-config) mode

### Command History

Release	Modification
1.1(1)	Command added.

### Usage Guidelines

After changing the management IP address, you will need to re-establish any existing connections using the new address.

You can enter the three keywords and variables, for either IP address type, in any order on one command line. See the following examples.



**Note** Only IPv6 Global Unicast addresses are supported as the chassis's IPv6 management address.

### Examples

This example shows how to display the current IPv4 management interface and gateway addresses, and specify new addresses:

```
FP9300-A # scope fabric-interconnect a
FP9300-A /fabric-interconnect # show
```

```

Fabric Interconnect:
ID   OOB IP Addr      OOB Gateway      OOB Netmask      OOB IPv6 Address OOB IPv6 Gateway
Prefix Operability
-----
A    192.0.2.112      192.0.2.1        255.255.255.0    ::                ::                64
Operable
FP9300-A /fabric-interconnect # set out-of-band ip 192.0.2.112 netmask 255.255.255.0 gw
192.0.2.1
Warning: When committed, this change may disconnect the current CLI session
FP9300-A /fabric-interconnect* # commit-buffer
FP9300-A /fabric-interconnect #

```

This example shows how to display the current IPv6 management interface and gateway addresses, and specify new addresses:

```

FP9300-A # scope fabric-interconnect a
FP9300-A /fabric-interconnect # scope ipv6-config
FP9300-A /fabric-interconnect/ipv6-config # show ipv6-if

Management IPv6 Interface:
IPv6 Address      Prefix      IPv6 Gateway
-----
2001::8998        64          2001::1
FP9300-A /fabric-interconnect/ipv6-config # set out-of-band ipv6 2001::8999 ipv6-prefix 64
ipv6-gw 2001::1
FP9300-A /fabric-interconnect/ipv6-config* # commit-buffer
FP9300-A /fabric-interconnect/ipv6-config #

```

Command	Description
<b>show</b>	Shows the current device management IP addresses.
<b>show ipv6-if</b>	Shows the current device management IPv6 address.

# set password

To specify the password for a user account, use the **set password** command.

## set password

### Syntax Description

This command has no arguments or keywords.

### Command Modes

`scope security/` – to change the password for the currently logged-in user  
`scope security/scope local-user/` – to specify a password for the current local user

### Command History

Release	Modification
1.1(1)	Command added.

### Usage Guidelines

After entering the **set password** command, you are prompted to enter and confirm the password. For security purposes, the password that you type does not appear in the CLI window.

This password must be a minimum of eight characters and a maximum of 80 characters. Use [set min-password-length, on page 66](#) to define a specific minimum number of characters. Use [set enforce-strong-password, on page 35](#) to require use of “strong” passwords.

### Example

This example shows how to enter security mode, create a new local user account and specify a password for that user:

```
firepower# scope security
firepower /security # create local-user test_user
firepower /security/local-user* # set password
Enter a password:
Confirm the password:
firepower /security/local-user* # commit-buffer
firepower /security/local-user #
```

Command	Description
<b>create local-user</b>	Creates a new local-user account.
<b>set expiration</b>	Specifies the date on which the user account expires.

# set password-encryption-key

To specify a key for use when encrypting sensitive information during configuration export, use the **set password-encryption-key** command.

## set password-encryption-key

### Syntax Description

This command has no arguments or keywords. After you enter the command, you are asked to enter and confirm an encryption key.

The key can be between four and 40 characters long; the key you enter is then used to generate a 128-bit MD5 hash value.

### Command Modes

scope security/

### Command History

Release	Modification
2.6.1	Command added.

### Usage Guidelines

You can use the configuration export feature to export an XML file containing logical device and platform configuration settings for your Firepower 4100/9300 chassis to a remote server. You can later import that configuration file to quickly apply the configuration settings to your Firepower 4100/9300 chassis to return to a known good configuration or to recover from a system failure.

Beginning with FXOS 2.6.1, you must specify a key for use when encrypting sensitive information such as passwords and other secret keys during configuration export, and you must have specified it before you attempt to export the configuration.

Also, the same key used during export must be set on the target system when you import an exported configuration, unless the file was exported from an FXOS release prior to 2.6.1, in which case the target system will allow the import.

Once a password encryption key is set, it cannot be changed or deleted unless you perform a factory-reset or password-recovery. Factory-reset or password-recovery will clear the key as if it had never been set.

### Example

This example shows how to specify a password encryption key prior to exporting the current configuration:

```
firepower # scope security
firepower /security # set password-encryption-key
Enter a key:
Confirm the key:
Warning: Please make note of the encryption key configured. If you change the key, importing
configurations that were exported with the previous key will fail, because Import and
Export requires the same encryption key on the system.
firepower /security* # commit-buffer
firepower /security #
```

Related Commands	Command	Description
	<b>cfg-export-policy</b>	Configures an export policy.
	<b>export-config</b>	Exports the current system configuration to a remote server as an XML file.
	<b>import-config</b>	Copies a previously exported XML configuration file to this appliance.

## set (password-profile)

To specify or change local-user password-profile parameters, use the **set** command in password-profile mode.

**set** { **change-count** | **change-during-interval** | **change-interval** | **history-count** | **no-change-interval** }

### Syntax Description

<b>change-count</b> <i>count</i>	The maximum number of times a user can change his or her password (during the time period specified with <b>set change-interval</b> ); value can be 0 to 10.
<b>change-during-interval</b> { <b>disable</b>   <b>enable</b> }	<p>Enable or disable restrictions on the number of password changes a locally authenticated user can make:</p> <ul style="list-style-type: none"> <li>• <b>disable</b> – Disables restrictions on the number of password changes.</li> <li>• <b>enable</b> – Enables restrictions on the number of password changes.</li> </ul> <p>This option must be enabled before you can specify the maximum number of times a locally authenticated user can change his or her password, and the number of hours over which that number of password changes can be made.</p>
<b>change-interval</b> <i>interval</i>	<p>The interval over which a user's password changes are tallied to ensure they do not exceed the maximum number specified with the <b>set change-count</b> command; the number of hours can be 1 to 745.</p> <p>The <b>set change-during-interval</b> option must be enabled before you can specify this interval.</p>
<b>history-count</b> <i>count</i>	<p>The number of unique passwords that a locally authenticated user must create before that user can re-use a previously used password; value can be 0 to 15.</p> <p>By default, the <i>count</i> value is zero, which disables the password history count, allowing users to re-use previously used passwords at any time.</p>
<b>no-change-interval</b> <i>hours</i>	<p>The length of time in hours during which a user cannot change her or his password again; value can be 1 to 745.</p> <p>The <b>set change-during-interval</b> option must be disabled before you set this time period, otherwise this value is ignored.</p>

### Command Modes

scope security/scope password-profile/

### Command History

Release	Modification
1.1(1)	Command added.

### Usage Guidelines

The **set change-during-interval** option must be enabled before you can specify the maximum number of times a locally authenticated user can change his or her password, and the number of hours over which that number of password changes can be made.

By default, the **set history-count** value is zero, which disables the password history count, allowing users to re-use previously used passwords at any time.

## Examples

This example shows how to enter password profile mode, enable password-change restrictions, specify that a user can change his or her password only twice in any 48-hour period, and then view the current settings:

```
firepower # scope security
firepower /security # scope password-profile
firepower /security/password-profile # set change-during-interval enable
firepower /security/password-profile* # set change-count 2
firepower /security/password-profile* # set change-interval 48
firepower /security/password-profile* # commit-buffer
firepower /security/password-profile # show detail
```

```
Password profile:
  Password history count: 5
  No password changes allowed (in Hours): 24
  Password change during interval: Enable
  Password change interval (in Hours): 48
  Password change count: 2
firepower /security/password-profile #
```

## Related Commands

Command	Description
<b>show detail</b>	Displays the current password-profile settings.

# set phone

To set a contact telephone number for a user account, use the **set phone** command.

**set phone** *tel\_number*

<b>Syntax Description</b>	<i>tel_number</i>	A contact telephone number for the user account; maximum of 20 characters.
---------------------------	-------------------	--

<b>Command Modes</b>	Local user mode
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

## Example

This example shows how to specify an telephone number for the current local user:

```
FP9300-A /security/local-user # set phone +1-408-555-1212
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>create local-user</b>	Creates a new local user account.
	<b>set phone-contact</b>	Specifies a contact telephone number for a Smart Call Home account.

## set (port-channel)

To specify or edit the parameters for an existing port-channel, use the **set** command in port-channel mode.

```
set { auto-negotiation | descr | duplex | flow-control-policy | lACP-policy-name | nw-ctrl-policy |
port-channel-mode | port-type | speed }
```

### Syntax Description

<b>auto-negotiation</b> { <b>no</b>   <b>yes</b> }	Enables or disables auto-negotiation of common transmission parameters such as speed, duplex and flow control. <ul style="list-style-type: none"> <li>• <b>no</b> – Disables auto-negotiation.</li> <li>• <b>yes</b> – Enables auto-negotiation.</li> </ul>
<b>descr</b> <i>description</i>	You can add a description to the port-channel; the description can be between zero and 256 characters. Most alphanumeric characters are allowed, as are dashes and underscores; spaces are not allowed. The string can end with punctuation such as semi-colon, period (full stop), and exclamation point, but you cannot embed those characters in the description.
<b>duplex</b> { <b>fullduplex</b>   <b>halfduplex</b> }	Defines the duplex mode for the port-channel: <ul style="list-style-type: none"> <li>• <b>fullduplex</b> – Specifies simultaneous two-way communications.</li> <li>• <b>halfduplex</b> – Specifies one-way-at-a-time communications.</li> </ul>
<b>flow-control-policy</b> <i>name</i>	You can assign a flow-control policy to the port-channel; provide the policy name, which can be up to 16 alphanumeric characters.
<b>lACP-policy-name</b> <i>name</i>	You can assign a LACP policy to the port-channel; provide the policy name, which can be up to 16 alphanumeric characters.
<b>nw-ctrl-policy</b> <i>name</i>	You can assign a network-control policy to the port-channel; provide the policy name, which can be up to 16 alphanumeric characters.
<b>port-channel-mode</b> { <b>active</b>   <b>on</b> }	Define the mode for the port-channel's physical data or data-sharing interfaces: <ul style="list-style-type: none"> <li>• <b>active</b> – Sends and receives LACP updates. An active port-channel can establish connectivity with either an active or a passive port-channel. You should use the active mode unless you need to minimize the amount of LACP traffic. This is the default.</li> <li>• <b>on</b> – The port-channel is always on, and LACP is not used. An “on” port-channel can only establish a connection with another “on” port-channel.</li> </ul> <p>Non-data interfaces support only active mode.</p>

<b>port-type</b> { <b>cluster</b>   <b>data</b>   <b>data-sharing</b>   <b>firepower-eventing</b>   <b>mgmt</b> }	Specify the port-channel type or function: <ul style="list-style-type: none"> <li>• <b>cluster</b> – Specify <b>cluster</b> only if you want to use this port-channel as the cluster control link.</li> <li>• <b>data</b> – Use for regular data transmission. This is the default type.</li> <li>• <b>data-sharing</b> – Use for regular data; only supported with container instances.</li> <li>• <b>firepower-eventing</b> – Use this port-channel as a secondary management interface for threat defense devices. The firepower-eventing port-channel is used to carry all event traffic (such as Web events).</li> <li>• <b>mgmt</b> – Use to manage application instances. You can only assign one management interface per logical device.</li> </ul>
--	--

See [set port-type](#), on page 83 for more information about this command.

<b>speed</b> { <b>100gbps</b>   <b>100mbps</b>   <b>10gbps</b>   <b>10mbps</b>   <b>1gbps</b>   <b>40gbps</b> }	Specify the port data-transfer speed: <ul style="list-style-type: none"> <li>• <b>100gbps</b> – One hundred Gigabits per second.</li> <li>• <b>100mbps</b> – One hundred Megabits per second.</li> <li>• <b>10gbps</b> – Ten Gigabits per second.</li> <li>• <b>10mbps</b> – Ten Megabits per second.</li> <li>• <b>1gbps</b> – One Gigabit per second.</li> <li>• <b>40gbps</b> – Forty Gigabits per second.</li> </ul>
--	--

**Command Modes** scope eth-uplink/scope fabric a/port-channel/

Command History	Release	Modification
	2.4(1)	We added the <b>data-sharing</b> type.
	1.1(4)	We added the <b>firepower-eventing</b> type.
	1.1(1)	Command added.

**Usage Guidelines** Assign member interfaces to the port-channel before using this command to set parameters.

The LACP port-channel mode applies to data and data-sharing interfaces only. For non-data and non-data-sharing interfaces, the mode is always *active*.

The type `cluster` is a special interface type used for a clustered logical device. This type is automatically assigned to the cluster control link for inter-unit cluster communications. By default, the cluster control link is automatically created on port-channel 48.

Data interfaces cannot be shared between logical devices.

The type `data-sharing` is supported only with container instances, these data interfaces can be shared by one or more logical devices/container instances (threat defense-only). Each container instance can communicate over the backplane with all other instances that share this interface. Shared interfaces can affect the number

of container instances you can deploy. Shared interfaces are not supported for bridge group member interfaces (in transparent mode or routed mode), inline sets, passive interfaces, or failover links.

A `firepower-eventing` interface is a secondary management interface for threat defense devices. To use this interface, you must configure its IP address and other parameters at the threat defense CLI. For example, you can separate management traffic from events (such as Web events). See the “Management Interfaces” section in the *System Configuration* chapter of the Management Center configuration guide. Firepower-eventing interfaces can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface.

Use `mgmt` interfaces to manage application instances. They can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface. You can only assign one management interface per logical device.

The interface speed that you specify can affect the duplex mode used for an interface, so you must set the speed before setting the duplex mode. If you specify 10- or 100-Mbps speed, the port is automatically configured to use half-duplex mode, but you can specify full-duplex mode instead. If you specify a speed of 1000 Mbps (1Gbps) or faster, full duplex is automatically used.

If you edited the default flow control policy, it is already applied to interfaces. If you created a new policy, you can apply it to the port-channel.

### Example

The following example creates Port-Channel 1 with four member interfaces, sets the type to data, and sets the EtherChannel to On mode.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # create port-channel 1
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/1
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/2
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/3
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/4
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # set port-type data
firepower /eth-uplink/fabric/port-channel* # set port-channel-mode on
firepower /eth-uplink/fabric/port-channel* # commit-buffer
firepower /eth-uplink/fabric/port-channel #
```

### Related Commands

Command	Description
<code>create port-channel</code>	Adds an EtherChannel interface.
<code>scope interface</code>	Enters a physical interface so you can configure and manage the interface settings.

# set port-channel-mode

To set the port channel mode for an EtherChannel, use the **set port-channel-mode** command.

```
set port-channel-mode {active | on}
```

<b>Syntax Description</b>	<b>active</b>	Sets the interface in an EtherChannel to be active.
	<b>on</b>	Sets the interface in an EtherChannel to be on. Only supported for Data or Data-sharing interfaces.
<b>Command Default</b>	The default mode is active.	
<b>Command Modes</b>	scope eth-uplink/scope fabric a/create port-channel/	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.4(1)	Command added.

## Usage Guidelines

You can configure each physical Data or Data-sharing interface in an EtherChannel to be:

- **Active**—Sends and receives LACP updates. An active EtherChannel can establish connectivity with either an active or a passive EtherChannel. You should use the active mode unless you need to minimize the amount of LACP traffic.
- **On**—The EtherChannel is always on, and LACP is not used. An “on” EtherChannel can only establish a connection with another “on” EtherChannel.

Non-data interfaces only support active mode.

## Example

The following example adds Port-Channel 1 with 4 member interfaces, sets the type to data, and sets the EtherChannel to On mode.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # create port-channel 1
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/1
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/2
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/3
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/4
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # set port-type data
firepower /eth-uplink/fabric/port-channel* # set port-channel-mode on
```

Related Commands	Command	Description
	<b>create port-channel</b>	Adds an EtherChannel interface.
	<b>create member-port</b>	Assigns a member to the EtherChannel.
	<b>set port-type</b>	Sets the interface type.

## set port-type

To set the port type for an interface, use the **set port-type** command.

**set port-type** { **cluster** | **data** | **data-sharing** | **firepower-eventing** | **mgmt** }

Syntax	Description
<b>cluster</b>	Special interface type used for a clustered logical device. This type is automatically assigned to the cluster control link for inter-unit cluster communications. By default, the cluster control link is automatically created on port-channel 48. For multi-instance clustering, you cannot share a Cluster-type interface across devices. You can add VLAN subinterfaces to the Cluster EtherChannel to provide separate cluster control links per cluster. If you add subinterfaces to a Cluster interface, you cannot use that interface for a native cluster. device manager does not support clustering.
<b>data</b>	Data interfaces cannot be shared between logical devices.
<b>data-sharing</b>	Only supported with container instances, these data interfaces can be shared by one or more logical devices/container instances (threat defense-only). Each container instance can communicate over the backplane with all other instances that share this interface. Shared interfaces can affect the number of container instances you can deploy. Shared interfaces are not supported for bridge group member interfaces (in transparent mode or routed mode), inline sets, passive interfaces, clusters, or failover links.
<b>firepower-eventing</b>	This interface is a secondary management interface for threat defense devices. To use this interface, you must configure its IP address and other parameters at the threat defense CLI. For example, you can separate management traffic from events (such as web events). See the “Management Interfaces” section in the <i>System Configuration</i> chapter of the Management Center configuration guide. Firepower-eventing interfaces can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface.
<b>mgmt</b>	Use management interfaces to manage application instances. They can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface. You can only assign one management interface per logical device.

**Command Default** The default type is data.

**Command Modes**

```
scope eth-uplink/scope fabric a/scope interface/
scope eth-uplink/scope fabric a/scope interface/create subinterface/
scope eth-uplink/scope fabric a/create port-channel/
scope eth-uplink/scope fabric a/create port-channel/create subinterface/
```

Command History	Release	Modification
	2.8(1)	You can set the <b>cluster</b> type on a VLAN subinterface for use with multi-instance clustering.
	2.4(1)	We added the <b>data-sharing</b> type.
	1.1(4)	We added the <b>firepower-eventing</b> type.
	1.1(1)	Command added.

### Usage Guidelines

Container instances can share data-sharing type interfaces. This capability lets you conserve physical interface usage as well as support flexible networking deployments. When you share an interface, the chassis uses unique MAC addresses to forward traffic to the correct instance. However, shared interfaces can cause the forwarding table to grow large due to the need for a full mesh topology within the chassis (every instance must be able to communicate with every other instance that is sharing the same interface). Therefore, there are limits to how many interfaces you can share.

In addition to the forwarding table, the chassis maintains a VLAN group table for VLAN subinterface forwarding. Depending on the number of parent interfaces and other deployment decisions, you can create up to 500 VLAN subinterfaces.

See the following limits for shared interface allocation:

- Maximum 14 instances per shared interface. For example, you can allocate Ethernet1/1 to Instance1 through Instance14.
- Maximum 10 shared interfaces per instance. For example, you can allocate Ethernet1/1.1 through Ethernet1/1.10 to Instance1.

See the following table for interface type support for FTD and ASA applications in standalone and cluster deployments.

Table 1: Interface Type Support

Application		Data	Data: Subinterface	Data-Sharing	Data-Sharing: Subinterface	Mgmt	Firepower Config	Cluster (EtherChannel only)	Cluster: Subinterface
FTD	Standalone Native Instance	Yes	—	—	—	Yes	Yes	—	—
	Standalone Container Instance	Yes	Yes	Yes	Yes	Yes	Yes	—	—
	Cluster Native Instance	Yes (EtherChannel only for inter-chassis cluster)	—	—	—	Yes	Yes	Yes	—
	Cluster Container Instance	Yes (EtherChannel only for inter-chassis cluster)	—	—	—	Yes	Yes	Yes	Yes
ASA	Standalone Native Instance	Yes	—	—	—	Yes	—	Yes	—
	Cluster Native Instance	Yes (EtherChannel only for inter-chassis cluster)	—	—	—	Yes	—	Yes	—

### Examples

The following example adds Port-Channel 1 with 4 member interfaces, sets the type to data, and sets the EtherChannel to On mode.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # create port-channel 1
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/1
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/2
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/3
firepower /eth-uplink/fabric/port-channel/member-port* # exit
firepower /eth-uplink/fabric/port-channel* # create member-port Ethernet1/4
firepower /eth-uplink/fabric/port-channel/member-port* # exit
```

```
firepower /eth-uplink/fabric/port-channel* # set port-type data
firepower /eth-uplink/fabric/port-channel* # set port-channel-mode on
```

The following example adds three subinterfaces and sets the port type to data-sharing.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # enter interface Ethernet1/1
firepower /eth-uplink/fabric/interface # enter subinterface 10
firepower /eth-uplink/fabric/interface/subinterface* # set vlan 10
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # exit
firepower /eth-uplink/fabric/interface # enter subinterface 11
firepower /eth-uplink/fabric/interface/subinterface* # set vlan 11
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # exit
firepower /eth-uplink/fabric/interface # enter subinterface 12
firepower /eth-uplink/fabric/interface/subinterface* # set vlan 12
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # commit-buffer
firepower /eth-uplink/fabric/interface/subinterface #
```

#### Related Commands

Command	Description
<b>create port-channel</b>	Adds an EtherChannel interface.
<b>scope interface</b>	Enters a physical interface so you can configure and manage the interface settings.

## set port-type (aggr-interface)

To configure the port type for the interface, use the **set port-type** command.

```
set port-type { data | data-sharing | mgmt | firepower-eventing | cluster }
```

Syntax Description		
	<b>data</b>	(Optional) Data interfaces cannot be shared between logical devices.
	<b>data-sharing</b>	(Optional) Only supported with container instances, these data interfaces can be shared by one or more logical devices/container instances (FTD-only). Each container instance can communicate over the backplane with all other instances that share this interface. Shared interfaces can affect the number of container instances you can deploy. Shared interfaces are not supported for bridge group member interfaces (in transparent mode or routed mode), inline sets, passive interfaces, or failover links.
	<b>mgmt</b>	(Optional) Use management interfaces to manage application instances. They can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface. You can only assign one management interface per logical device.
	<b>firepower-eventing</b>	(Optional) This interface is a secondary management interface for FTD devices. To use this interface, you must configure its IP address and other parameters at the FTD CLI. For example, you can separate management traffic from events (such as web events). See the "Management Interfaces" section in the Management Center configuration guide System Configuration chapter. Firepower-eventing interfaces can be shared by one or more logical devices to access external hosts; logical devices cannot communicate over this interface with other logical devices that share the interface.
	<b>cluster</b>	(Optional) Special interface type used for a clustered logical device. This type is automatically assigned to the cluster control link for inter-unit cluster communications. By default, the cluster control link is automatically created on Port-channel 48.

**Command Modes** scope cabling/scope fabric a/

Command History	Release	Modification
	2.4(1)	Added the <b>data-sharing</b> type.
	1.1(4)	Added the <b>firepower-eventing</b> type.
	1.1(1)	Command added.

**Usage Guidelines** Container instances can share data-sharing type interfaces. This capability lets you conserve physical interface usage as well as support flexible networking deployments. When you share an interface, the chassis uses unique MAC addresses to forward traffic to the correct instance. However, shared interfaces can cause the forwarding table to grow large due to the need for a full mesh topology within the chassis (every instance

must be able to communicate with every other instance that is sharing the same interface). Therefore, there are limits to how many interfaces you can share.

### Example

The following example shows to configure the interface port-type and then list the available commands:

```
firepower-9300* # scope cabling
firepower-9300 /cabling* # scope fabric a
firepower-9300 /cabling/fabric* # create breakout port breakout 2 1
firepower-9300 /cabling/fabric* # show config
  scope fabric a
+   enter breakout 2 3
+   exit
  exit
firepower-9300 /cabling/fabric* # exit
firepower-9300 /cabling* # exit
```

The system reboots after you use the `commit-buffer` command.

```
firepower-9300* # scope eth-uplink
firepower-9300 /eth-uplink* # scope fabric a
firepower-9300 /eth-uplink/fabric* # show
```

Fabric:

```
  Fabric ID
  -----
  Afirepower-9300 /eth-uplink/fabric* # show
<CR>
>
>>
aggr-interface Aggregate Interface
detail Detail
event Event Management
expand Expand
fault Fault
fsm Fsm
interface Interface
port-channel Port Channel
stats statistics
| Pipe command output to filter

firepower-9300 /eth-uplink/fabric* # show aggr-interface expand
firepower-9300 /eth-uplink/fabric* # show aggr-interface
  1-4 Slot
<CR>
>
>>
detail Detail
expand Expand
n/n Ethernet<Slot Id>/<Aggregate Port Id>
| Pipe command output to filter
firepower-9300 /eth-uplink/fabric* # show aggr-interface expand
firepower-9300 /eth-uplink/fabric* #
  acknowledge Acknowledge
  create Create managed objects
  delete Delete managed objects
  enter Enters a managed object
  scope Changes the current mode
  show Show system information
```

```

firepower-9300 /eth-uplink/fabric* # scope aggr-interface
  1-4 Slot
  n/n Ethernet<Slot Id>/<Aggregate Port Id>

firepower-9300 /eth-uplink/fabric* # scope port-channel 2
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface* # create member-port
Ethernet2/1/1
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface/member-port* # show config
+enter member-port 2 1
+exit
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface/member-port* #
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface/member-port* # exit
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface* # exit
firepower-9300 /eth-uplink/fabric/port-channel* # show config
  enter port-channel 2
    enable
+   enter aggr-interface 2 1
+     enter member-port 2 1
+     exit
+   exit
  enter member-port 1 6
    enable
  exit
  set auto-negotiation no
  set descr ""
  set duplex full duplex
  set flow-control-policy default
  set lacp-policy-name default
  set nw-ctrl-policy default
  set port-channel-mode active
  set port-type data
  set speed 1gbps
  exit

firepower-9300 /eth-uplink/fabric/port-channel* # set port-type
  cluster          Cluster
  data             Data
  data-sharing     Data Sharing
  firepower-eventing Firepower Eventing
  mgmt            Mgmt

firepower-9300 /eth-uplink/fabric/port-channel* # set port-type cluster
firepower-9300 /eth-uplink/fabric/port-channel* commit-buffer
firepower-9300 /eth-uplink/fabric/port-channel #

```

**Related Commands**

Command	Description
create port-channel	Adds an EtherChannel interface
scope interface	Edits a physical interface.

# set prefix

To set the MAC address prefix to use when autogenerating MAC addresses for container instance interfaces, use the **set prefix** command.

**set prefix** *prefix*

<b>Syntax Description</b>	<i>prefix</i>	Specifies a decimal value between 1 and 65535. This prefix is converted to a four-digit hexadecimal number, and used as part of the MAC address.
---------------------------	---------------	--

**Command Modes** scope ssa/scope auto-macpool/

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.4(1)	Command added.

**Usage Guidelines** The FXOS chassis automatically generates MAC addresses for container instance interfaces, and guarantees that a shared interface in each instance uses a unique MAC address.

If you manually assign a MAC address to a shared interface within the application, then the manually-assigned MAC address is used. If you later remove the manual MAC address, the autogenerated address is used. In the rare circumstance that the generated MAC address conflicts with another private MAC address in your network, we suggest that you manually set the MAC address for the interface within the application.

Because autogenerated addresses start with A2, you should not start manual MAC addresses with A2 due to the risk of overlapping addresses.



**Note** Even if you are not sharing a subinterface, if you manually configure MAC addresses, make sure you use unique MAC addresses for all subinterfaces on the same parent interface to ensure proper classification.

The FXOS chassis generates the MAC address using the following format:

A2*xx.yyzz.zzzz*

Where *xx.yy* is a user-defined prefix or a system-defined prefix, and *zz.zzzz* is an internal counter generated by the chassis. The system-defined prefix matches the lower 2 bytes of the first MAC address in the burned-in MAC address pool that is programmed into the IDPROM. Use **connect fxos**, then **show module** to view the MAC address pool. For example, if the range of MAC addresses shown for module 1 is b0aa.772f.f0b0 to b0aa.772f.f0bf, then the system prefix will be f0b0.

The user-defined prefix is an integer that is converted into hexadecimal. For an example of how the user-defined prefix is used, if you set a prefix of 77, then the chassis converts 77 into the hexadecimal value 004D (*yyxx*). When used in the MAC address, the prefix is reversed (*xyyy*) to match the chassis native form:

A2**4D.00***zz.zzzz*

For a prefix of 1009 (03F1), the MAC address is:

A2**F1.03***zz.zzzz*

### Example

The following example sets the MAC prefix to 33.

```
firepower# scope ssa
firepower /ssa # scope auto-macpool
firepower /ssa/auto-macpool # set prefix 33
firepower /ssa/auto-macpool* # commit-buffer
firepower /ssa/auto-macpool
```

Related Commands	Command	Description
	<b>scope ssa</b>	Enters ssa mode.
	<b>scope auto-macpool</b>	Enter auto-macpool mode.
	<b>show mac-address</b>	Shows the assigned MAC addresses.

# set protocol

To specify the protocol to use when communicating with the remote server for the export policy, use the **set protocol** command.

```
set protocol { ftp | scp | sftp | tfp }
```

Syntax Description	Parameter	Description
	<b>ftp</b>	Specifies the File Transfer Protocol (FTP) for file transfer.
	<b>scp</b>	Specifies the Secure Copy Protocol (SCP) for file transfer.
	<b>sftp</b>	Specifies the Secure File Transfer Protocol (SFTP) for file transfer.
	<b>tfp</b>	Specifies the Trivial File Transfer Protocol (TFTP) for file transfer.

**Command Modes** Configuration export policy (/org/cfg-export-policy)

Command History	Release	Modification
	2.0.1	Command added.

**Usage Guidelines** Use this command to specify a file transfer protocol.

## Example

This example shows how to set the port number for the export policy:

```
firepower-9300* # scope org
firepower-9300 /org* # scope cfg-export-policy default
firepower-9300 /org/cfg-export-policy* # set protocol scp
firepower-9300 /org/cfg-export-policy* # commit-buffer
firepower-9300 /org/cfg-export-policy #
```

Related Commands	Command	Description
	<b>set adminstate</b> (/org)	Enables the export policy.
	<b>set hostname</b> (/org)	Specifies the hostname location where the backup file must be stored.
	<b>set password</b> (/org)	Specifies the password for the remote server username.
	<b>set port</b> (/org)	Specifies the port number.
	<b>set protocol</b> (/org)	Specifies the protocol to use when communicating with the remote server.
	<b>set remote-file</b> (/org)	Specifies the full path to where you want the configuration file exported including the filename.
	<b>set schedule</b> (/org)	Specifies the schedule on which you would like to have the configuration automatically exported.

Command	Description
set user (/org)	Specifies the username the system should use to log in to the remote server.

# set realm

To specify the default authentication service, use the **set realm** command.

```
set realm { ldap | local | none | radius | tacacs }
```

Syntax Description		
	<b>ldap</b>	Specifies LDAP authentication.
	<b>local</b>	Specifies local authentication.
	<b>none</b>	Allows local users to log on without specifying a password.
	<b>radius</b>	Specifies RADIUS authentication.
	<b>tacacs</b>	Specifies TACACS+ authentication.

Command Modes	
	Default authentication mode

Command History	Release	Modification
	1.1(1)	Command added.

## Example

This example shows how to enter security/default-auth mode and set the default authentication service to Radius:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set realm radius
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

Related Commands	Command	Description
	<b>set auth-server-group</b>	Specifies an associated authentication provider group.
	<b>set use-2-factor</b>	Sets the authentication method to two-factor authentication for a Radius or TACACS+ realm.

# set refresh-period

To set the Web session refresh period—the maximum time allowed between refresh requests for a user in this domain—use the **set refresh-period** command.

**set refresh-period** *seconds*

<b>Syntax Description</b>	<i>seconds</i>	Number of seconds after which a Web session is considered inactive. Value can be 0 to 3600 seconds; default is 600 seconds.
---------------------------	----------------	---

<b>Command Modes</b>	Default authentication mode
----------------------	-----------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

<b>Usage Guidelines</b>	If this time limit is exceeded, FXOS considers the Web session to be inactive, but it does not terminate the session.
-------------------------	---

## Example

This example shows how to enter default authentication mode and set the session refresh interval:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set refresh-period 800
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	set timeout values	The <b>set absolute-session-timeout</b> , <b>set con-absolute-session-timeout</b> , <b>set con-session-timeout</b> , and <b>set session-timeout</b> commands are used to set various timeout values.

# set regenerate

To regenerate the keys in the default keyring, use the **set regenerate** command.

```
set regenerate { no | yes }
```

Syntax Description	no	Do not regenerate the keys.
	yes	Regenerate the keys.

**Command Modes** Keyring mode

Command History	Release	Modification
	1.1(1)	Command added.

**Usage Guidelines** Use this command to regenerate the RSA keys in the default keyring. This command is accepted only in the default keyring.

## Example

This example shows how to regenerate the keys in the default keyring:

```
FP9300-A# scope security
FP9300-A /security # scope keyring default
FP9300-A /security/keyring # set regenerate yes
FP9300-A /security/keyring* # commit-buffer
switch-A /security/keyring #
```

Related Commands	Command	Description
	<b>set cert</b>	Enters an RSA certificate for a keyring.
	<b>set modulus</b>	Specifies the RSA key modulus (SSL key length) in bits.
	<b>set trustpoint</b>	Specifies whether the keyring certificate can be regenerated.

## set remote-address

To specify the remote IP address for an IPsec connection, use the **set remote-address** command.

**set remote-address** *ip\_address*

<b>Syntax Description</b>	<i>ip_address</i>	Provide an IPv4 or IPv6 remote gateway address for the IPsec connection; maximum of 510 characters.
<b>Command Modes</b>	Connection (/security/ipsec/connection) mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.
<b>Usage Guidelines</b>	Use this command and the <b>set local-address</b> command to define the endpoints of an IPsec connection.	

### Example

This example shows how to set the remote address for an IPsec connection:

```

FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # enter connection testconn
FP9300-A /security/ipsec/connection # set local-address 209.165.202.129
FP9300-A /security/ipsec/connection* # commit-buffer
FP9300-A /security/ipsec/connection #

```

Command	Description
<b>create connection</b>	Creates a new IPsec connection.
<b>set local-addr</b>	Sets the local IP address for an IPsec connection.

## set remote-ike-ident

To specify the remote peer IKE identity for an IPsec tunnel connection, use the **set remote-ike-ident** command.

**set remote-ike-ident** *remote\_ID*

<b>Syntax Description</b>	<i>remote_ID</i>	The IKE identification of the remote peer; maximum of 510 characters.
<b>Command Modes</b>	Connection (/security/ipsec/connection) mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.
<b>Usage Guidelines</b>	Use this command to specify the remote peer's IKE ID for an IPsec connection. This identification is used for peer validation during IKE negotiations.	

### Example

This example shows how to specify the remote IKE ID for an IPsec connection:

```
FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # enter connection testconn
FP9300-A /security/ipsec/connection # set remote-ike-ident 203.0.113.12
FP9300-A /security/ipsec/connection* # commit-buffer
FP9300-A /security/ipsec/connection #
```

Command	Description
<b>create connection</b>	Creates a new IPsec connection.
<b>set remote-addr</b>	Sets the remote IP address for an IPsec connection.

## set remote-subnet

To specify the remote subnet for an IPsec tunnel connection, use the **set remote-subnet** command.

```
set remote-subnet ip_address/mask_bits
```

<b>Syntax Description</b>	<i>ip_address/mask_bits</i>	Provide an IPv4 or IPv6 remote subnet address/mask for the IPsec connection; maximum of 510 characters.
<b>Command Modes</b>	Connection (/security/ipsec/connection) mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.
<b>Usage Guidelines</b>	Use this command to specify the IP address/mask of an IPsec connection's remote subnet.	

### Example

This example shows how to set the remote subnet for an IPsec connection:

```
FP9300-A # scope security
FP9300-A /security # scope ipsec
FP9300-A /security/ipsec # enter connection testconn
FP9300-A /security/ipsec/connection # set remote-subnet 209.165.202.128/27
FP9300-A /security/ipsec/connection* # commit-buffer
FP9300-A /security/ipsec/connection #
```

Command	Description
<b>create connection</b>	Creates a new IPsec connection.
<b>set remote-addr</b>	Sets the remote IP address for an IPsec connection.

## set remote-user

To restrict access to those users matching an established user role, use the **set remote-user** command.

```
set remote-user default-role { assign-default-role | no-login }
```

Syntax Description	assign-default-role	no-login
	When a user attempts to log in and the remote authentication provider does not supply a user role with the user's authentication information, the user is allowed to log in with a read-only user role.	When a user attempts to log in and the remote authentication provider does not supply a user role with the user's authentication information, access is denied.

**Command Modes** Security mode

Command History	Release	Modification
	1.1(1)	Command added.

**Usage Guidelines** **assign-default-role** is the default behavior.

### Example

This example shows how to enter security mode and deny access to users without a user role:

```
FP9300-A# scope security
FP9300-A /security # set remote-user default-role no-login
FP9300-A /security* # commit-buffer
FP9300-A /security #
```

Related Commands	Command	Description
	<b>set authentication</b>	Specifies the default authentication service.

# set reporting-interval

To define how frequently monitored statistics are reported, use the **set reporting-interval** command.

**set reporting-interval** *interval*

<b>Syntax Description</b>	<i>interval</i>	Length of time defining the statistics reporting interval; available values are: <ul style="list-style-type: none"> <li>• 15minutes – 15-minute intervals</li> <li>• 2hours – two-hour (120-minute) intervals</li> <li>• 2minutes – two-minute intervals</li> <li>• 30minutes – 30-minute intervals</li> <li>• 4hours – four-hour (240-minute) intervals</li> <li>• 60minutes – 60-minute (one-hour) intervals</li> <li>• 8hours – eight-hour (480-minute) intervals</li> </ul>
<b>Command Modes</b>	scope monitoring/scope stats-collection-policy/	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.
<b>Usage Guidelines</b>	<p>Use the <b>set collection-interval</b> command to define how frequently statistics are collected, and use the <b>set reporting-interval</b> command to define how frequently the statistics are reported. These intervals define a statistics collection policy.</p> <p>Reporting intervals are longer than collection intervals so that multiple statistical data points can be collected during the reporting interval, which provides sufficient data to calculate and report minimum, maximum, and average values.</p> <p>Statistics can be collected and reported for each of the following functional areas of your Firepower system; use the <b>scope stats-collection-policy</b> command to access a specific collection policy:</p> <ul style="list-style-type: none"> <li>• <b>Adapter</b> – statistics related to the adapters.</li> <li>• <b>Chassis</b> – statistics related to the blade chassis.</li> <li>• <b>FEX</b> – statistics related to configured Fabric Extender(s).</li> <li>• <b>Host</b> – this policy is a placeholder for future support.</li> <li>• <b>Port</b> – statistics related to the ports, including server ports, uplink Ethernet ports, and uplink Fibre Channel ports.</li> <li>• <b>Server</b> – statistics related to servers.</li> </ul>	




---

**Note** There is one default statistics collection policy for each of the functional areas. You cannot create additional statistics collection policies and you cannot delete the existing default policies. You can only modify the default policies.

---

### Example

This example shows how to enter the statistics collection policy for ports, set the collection interval to one minute, set the reporting interval to 30 minutes, and then commit the transaction:

```
firepower # scope monitoring
firepower /monitoring # scope stats-collection-policy port
firepower /monitoring/stats-collection-policy # set collection-interval 1minute
firepower /monitoring/stats-collection-policy* # set reporting-interval 30minute
firepower /monitoring/stats-collection-policy* # commit-buffer
firepower /monitoring/stats-collection-policy #
```

---

### Related Commands

Command	Description
<b>scope stats-collection-policy</b>	Enters stats-collection-policy mode, where you manage statistics collection and reporting intervals.
<b>set collection-interval</b>	Specifies how frequently statistics are collected.

# set resource-profile-name

To set the resource profile for an application instance, use the **set resource-profile-name** command.

**set resource-profile-name** *profile\_name*

<b>Syntax Description</b>	<i>profile_name</i>	Sets the resource profile name for this application instance.
<b>Command Modes</b>	scope ssa/scope slot/create app-instance/	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.4(1)	Can now be used for container instances.
	1.1(1)	Command added for use with vDP.

**Usage Guidelines** For vDP, resource profiles are pre-created in the FXOS configuration when you download the vDP image. For container instances, create resource profiles using the **create resource-profile** command. Use the **show resource-profile system** command to view available profiles.

If you change the resource profile for an application instance that is running, then the instance reboots.

## Example

The following example shows how to set the the resource profile for a vDP application instance:

```
firepower# scope ssa
firepower /ssa # show app
  Name          Version          Author          Supported Deploy Types CSP Type      Is Default App
-----
  asa           9.10.1           cisco           Native           Application Yes
  ftd           6.2.3            cisco           Native           Application Yes
  vdp           8.13.01.09-2    radware         Vm               Application Yes

firepower /ssa # show resource-profile system
Profile Name      App Name  App Version  Is In Use  Security Model  CPU Logical Core Count
RAM Size (MB)    Default Profile Profile Type Description
-----
DEFAULT-4110-RESOURCE
  4               16384    Yes         System     FPR4K-SM-12
DEFAULT-RESOURCE vdp      8.13.01.09-2 No         FPR9K-SM-56, FPR9K-SM-44, FPR9K-SM-36,
FPR9K-SM-24, FPR4K-SM-44, FPR4K-SM-36, FPR4K-SM-24
  6               24576    Yes         System
VDP-10-CORES    vdp      8.13.01.09-2 No         FPR9K-SM-56, FPR9K-SM-44, FPR9K-SM-36,
FPR9K-SM-24, FPR4K-SM-44, FPR4K-SM-36, FPR4K-SM-24
  10              40960    No         System
VDP-2-CORES    vdp      8.13.01.09-2 No         all
  2               8192     No         System
```

```

VDP-4-CORES      vdp      8.13.01.09-2 No      all
4                16384 No      System
VDP-8-CORES      vdp      8.13.01.09-2 No      FPR9K-SM-56, FPR9K-SM-44, FPR9K-SM-36,
FPR9K-SM-24, FPR4K-SM-44, FPR4K-SM-36, FPR4K-SM-24

8                32768 No      System
firepower /ssa/app # exit
firepower /ssa # scope slot 1
firepower /ssa/slot # create app-instance vdp VDP1
firepower /ssa/slot/app-instance* # set resource-profile-name VDP-10-CORES
firepower /ssa/slot/app-instance* #

```

## Example

The following example shows how to set the the resource profile for a threat defense container instance:

```

firepower# scope ssa
firepower /ssa # show resource-profile

Profile Name      App Name  App Version  Is In Use  Security Model  CPU Logical Core Count
RAM Size (MB)    Default Profile Profile Type Description
-----
-----
bronze            N/A      N/A          No         all
6                N/A No      Custom     low end device
silver            N/A      N/A          No         all
8                N/A No      Custom     mid-level

firepower /ssa # scope slot 1
firepower /ssa/slot # create app-instance ftd FTD1
firepower /ssa/slot/app-instance* # set resource-profile-name silver
firepower /ssa/slot/app-instance* #

```

## Related Commands

Command	Description
<b>show app-attri</b>	Shows current application attributes.
<b>create resource-profile</b>	Creates a resource profile for use with constainer instances.
<b>show resource-profile-name</b>	Shows available resource profiles.

## set session-timeout

To set the idle session timeout for Web, SSH, and Telnet sessions, use the **set session-timeout** command.

**set session-timeout** *seconds*

<b>Syntax Description</b>	<i>seconds</i>	Idle session timeout for Web, SSH, and Telnet sessions; value can be 0 to 3600 seconds.
---------------------------	----------------	---

<b>Command Modes</b>	Default authentication mode
----------------------	-----------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

**Usage Guidelines** Use this command to specify the idle session timeout for Web, SSH, and Telnet sessions.

### Example

This example shows how to enter default authentication mode and then set the idle session timeout to four minutes:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set session-timeout 240
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>set refresh-period</b>	Sets the Web session refresh period.
	<b>show detail</b>	Displays the current session and absolute session timeout settings.

## set snmp-adminappinstance

To set Simple Network Management Protocol (SNMP) admin app-instance configuration parameters, use the **set snmp adminappinstance** command.

```
set snmp adminappinstance { slot | appname | id | enable | yes/no }
```

Syntax Description	slot	Slot selection between 1-3
	appname	Displays appname
	id	Displays Identifier name
	enable	Select <b>yes/no</b> to enable/disable

Command Modes	scope monitoring
---------------	------------------

Command History	Release	Modification
	2.3.1	Command added.

### Usage Guidelines

Cisco recommends that you enable only communication services needed to interact with other network applications. So, you must enable the SNMP agent (**enable snmp**).

This is a subcommand of the **show** command in scope monitoring.

### Example

This example shows how to display information of snmp:

```
Firepower /monitoring # set snmp adminappinstance
slot Slot
Firepower /monitoring # set snmp adminappinstance slot
1-3 Admin App Slot
Firepower /monitoring # set snmp adminappinstance slot 1
appname AppName
Firepower /monitoring # set snmp adminappinstance slot 1 appname
WORD Admin App Name (Min size 0, Max size 510)
Firepower /monitoring # set snmp adminappinstance slot 1 appname ftd
id Id
Firepower /monitoring # set snmp adminappinstance slot 1 appname ftd id
WORD Admin App Id (Min size 0, Max size 510)
Firepower /monitoring # set snmp adminappinstance slot 1 appname ftd id FTD
enable Enable
Firepower /monitoring # set snmp adminappinstance slot 1 appname ftd id FTD enable
no No
yes Yes
Firepower /monitoring # set snmp adminappinstance slot 1 appname ftd id FTD enable yes
Firepower /monitoring* # commit-buffer

Firepower /monitoring #
Firepower /monitoring # show snmp
Name: snmp
Admin State: Enabled
```

```
Port: 161
Is Community Set: No
Sys Contact:
Sys Location:
Admin App Enable: Yes
  Admin App Slot: 1
  Admin App Name: ftd
  Admin App Id: FTD
```

# set snmp

To set Simple Network Management Protocol (SNMP) configuration parameters, use the **set snmp** command.

**set snmp** { **community** | **syscontact** | **syslocation** }

## Syntax Description

<b>community</b>	After you enter this command, you are asked to enter a SNMP community name, which can be between 1 and 32 alphanumeric characters. The community name is not displayed as you type; however after you press <b>Enter</b> , the system prompt is displayed with an asterisk indicating you need to commit the buffer.
<b>syscontact</b> <i>name</i>	Enter the name of the person to contact regarding SNMP on this system; can be 0 to 255 alphanumeric characters.
<b>syslocation</b> <i>location</i>	Enter a location for this system; can be 0 to 510 alphanumeric characters.

## Command Modes

scope monitoring/

## Command History

Release	Modification
1.1.1	Command added.

## Usage Guidelines

Cisco recommends that you enable only the communication services needed to interact with other network applications.

You must enable the SNMP agent (**enable snmp**) before configuring SNMP on this system.

Use **set snmp community** to specify the community access string used to permit access to the SNMP trap destination. If SNMPv1 or v2c is set as the SNMP version, the community argument is used as the community string. If SNMPv3 is configured, it is used as the SNMP user name for sending trap messages.

When you specify an SNMP community name, you are also automatically enabling SNMP versions 1 and 2c for polling requests from the SNMP remote manager.



**Note** Be aware that SNMP versions 1 and 2c have serious known security issues: they transmit all information without encryption, including the community string, which serves as the only form of authentication in these versions.

There can be only one community name; however, you can use **set snmp community** to overwrite the existing name. To delete an existing community name, enter **set snmp community** but do not type a community string; that is, simply press **Enter** again. After you commit the buffer, **show snmp** output will include the line `Is Community Set: No.`

## Example

The following example shows you how to scope into monitoring mode, enable SNMP processing, set the SNMP community string and a system contact, commit your changes, and use the **show snmp** command to confirm the changes:

```
firepower # scope monitoring
firepower /monitoring # enable snmp
firepower /monitoring* # set snmp community
Enter a snmp community:
firepower /monitoring* # set snmp syscontact R_Admin
firepower /monitoring* # commit-buffer
firepower /monitoring # show snmp
Name: snmp
  Admin State: Enabled
  Port: 161
  Is Community Set: Yes
  Sys Contact: R_Admin
  Sys Location:
firepower /monitoring #
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>disable snmp</b>	Disables SNMP.
<b>enable snmp</b>	Enables SNMP.
<b>show snmp</b>	Shows the current SNMP configuration.

## set (snmp-trap)

To specify Simple Network Management Protocol (SNMP) trap parameters, use the **set** command in snmp-trap mode.

**set** { **community** | **notificationtype** | **port** | **v3privilege** | **version** }

Syntax Description		
<b>community</b>		Specifies the SNMPv1/v2c community string, or the SNMPv3 user name, to permit access to the trap destination. You are queried for the community name after you enter this command. The name can be up to 32 characters with no spaces; the name is not displayed as you type.
<b>notificationtype</b> { <b>informs</b>   <b>traps</b> }		Specifies the type of SNMP notification produced by this agent: <ul style="list-style-type: none"> <li>• <b>informs</b> – These are unsolicited notifications sent to notify the manager of significant local events. These messages are acknowledged. This option can be used only if <b>version</b> is set to <b>vc2</b>.</li> <li>• <b>traps</b> – These are unsolicited notifications sent to notify the manager of significant local events. These messages are not acknowledged.</li> </ul>
<b>port</b> <i>port_num</i>		Use this command to change the port on which the agent receives SNMP requests; the default port is 161.
<b>v3privilege</b> { <b>auth</b>   <b>noauth</b>   <b>priv</b> }		Use this command to specify the Simple Network Management Protocol version 3 (SNMPv3) security level for the transmitted SNMP traps. <ul style="list-style-type: none"> <li>• <b>auth</b> – Specifies keyed-hash authentication but no encryption.</li> <li>• <b>noauth</b> – Specifies no authentication or encryption. Note that while you can specify it, FXOS does not support this security level with SNMPv3.</li> <li>• <b>priv</b> – Specifies keyed-hash authentication and data encryption (privacy).</li> </ul>
<b>version</b> { <b>v1</b>   <b>v2c</b>   <b>v3</b> }		Use this command to specify the SNMP security model used when sending trap notifications: <ul style="list-style-type: none"> <li>• <b>v1</b> – Specifies SNMP version 1.</li> <li>• <b>v2c</b> – Specifies SNMP version 2c.</li> <li>• <b>v3</b> – Specifies SNMP version 3.</li> </ul> <p><b>Note</b> Be aware that SNMP versions 1 and 2c have serious known security issues: they transmit all information without encryption, including the community string, which serves as the only form of authentication in these versions.</p>

**Command Modes** scope monitoring/snmp-trap

Command History	Release	Modification
	1.1.1	Command added.

**Usage Guidelines** You must enable SNMP (**enable snmp**), and create an SNMP community (**set snmp community**), before you create an SNMP trap and set these parameters.

When you create a new SNMP trap, you are automatically entered into monitoring/snmp-trap mode with an asterisk indicating the new trap is not yet committed.



**Note** You can create up to eight SNMP traps.

If SNMPv1 or v2c is configured with **set version**, the **set community** argument is used as the community string. If SNMPv3 is configured, it is used as the user name for transmitting the notifications.

With SNMPv3, the trap's **v3privilege** setting must be compatible with the associated SNMPv3 user's security level; that is, the associated user's security configuration must be at least as secure as the trap's. For example, if authentication is enabled for the SNMPv3 user (perform authentication but not privacy encryption), then the user's priv-password would not be set. But to send notifications with privacy enabled (that is, authenticate and do privacy encryption) the user's priv-password would be set. The password associated with the SNMPv3 user is used to authenticate the user when a trap/inform is sent.

### Example

The following example enables SNMP, creates an SNMP trap using an IPv4 address, sets the version to v3, sets the v3 privilege level to privacy, and commits the transaction:

```
firepower # scope monitoring
firepower /monitoring/ # enable snmp
firepower /monitoring/ # create snmp-trap 192.168.100.112
firepower /monitoring/snmp-trap* # set notificationtype traps
firepower /monitoring/snmp-trap* # set version v3
firepower /monitoring/snmp-trap* # set v3privilege priv
firepower /monitoring/snmp-trap* # commit-buffer
firepower /monitoring/snmp-trap #
```

Related Commands	Command	Description
	<b>create snmp-trap</b>	Creates a new SNMP trap destination.
	<b>enable snmp</b>	Enables SNMP.

## set (snmp-user)

To specify parameters for an existing Simple Network Management Protocol (SNMP) v3 user, use the **set** command in `snmp-user` mode.

```
set { aes-128 | auth | password | priv-password }
```

Syntax Description		
<b>aes-128</b>	{ no   yes }	Disable or enable the use of Advanced Encryption Standard (AES)-128 encryption: enter <code>no</code> or <code>yes</code> .  By default, AES-128 encryption is disabled.
<b>auth</b>	sha	Enables authentication for SNMPv3 users based on the HMAC Secure Hash Algorithm (SHA).
<b>password</b>		Specify a password for this user; you are asked to enter the password, and confirm it, after you enter this command.
<b>priv-password</b>		Specify a user privacy password; you are asked to enter the password, and confirm it, after you enter this command. The AES privacy password must be a minimum of eight characters.

**Command Modes** scope monitoring/snmp-user

Command History	Release	Modification
	1.1.1	Command added.

**Usage Guidelines** You must enable SNMP (**enable snmp**) before you create an SNMP user and set these parameters.

When you create a new SNMP user, you are automatically entered into `monitoring/snmp-user` mode with an asterisk indicating the new user is not yet committed.

The privacy password, or `priv` option, offers a choice of DES or 128-bit AES encryption for SNMP security encryption. If you enable AES-128 configuration and include a privacy password for an SNMPv3 user, the Firepower chassis uses the privacy password to generate a 128-bit AES key.

### Example

The following example creates an SNMPv3 user named `snmp-user14`, enables AES-128 encryption, sets a privacy password, and commits the transaction:

```
firepower # scope monitoring
firepower /monitoring/ # enable snmp
firepower /monitoring/ # create snmp-user snmp-user14
Password:
firepower /monitoring/snmp-user* # set aes-128 yes
firepower /monitoring/snmp-user* # set priv-password
Enter a password:
Confirm the password:
firepower /monitoring/snmp-user* # commit-buffer
firepower /monitoring/snmp-user #
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>create snmp-user</b>	Creates a new SNMPv3 user.
<b>enable snmp</b>	Enables SNMP.

# set speed

To set the interface speed., use the **set speed** command.



**Note** This command is available in port-channel scope only.

```
set speed { 10mbps | 100mbps | 1gbps | 10gbps | 40gbps | 100gbps }
```

## Syntax Description

<b>10mbps</b>	(Optional) Sets the speed at 10 Mbps.
<b>100mbps</b>	(Optional) Sets the speed at 100 Mbps.
<b>1gbps</b>	(Optional) Sets the speed at 1 Gbps.
<b>10gbps</b>	(Optional) Sets the speed at 10 Gbps.
<b>40gbps</b>	(Optional) Sets the speed at 40 Gbps.
<b>100gbps</b>	(Optional) Sets the speed at 100 Gbps.

## Command Modes

scope eth-uplink/scope fabric a/port-channel/

## Command History

Release	Modification
2.4.1(1)	Command added.

## Usage Guidelines

The interface speed that you specify can affect the duplex mode used for an interface, so you must set the speed before setting the duplex mode. If you specify 10- or 100-Mbps speed, the port is automatically configured to use half-duplex mode, but you can specify full-duplex mode instead. If you specify a speed of 1000 Mbps (1Gbps) or faster, full duplex is automatically used.

## Example

This example shows how to set the interface speed:

```
firepower-9300 # scope eth-uplink
firepower-9300 /eth-uplink # scope fabric a
firepower-9300 /eth-uplink/fabric # create port-channel id
firepower-9300 /eth-uplink/fabric/port-channel* # enable
firepower-9300 /eth-uplink/fabric/port-channel* # set speed
firepower-9300 /eth-uplink/fabric/port-channel* # set speed 1gbps
firepower-9300 /eth-uplink/fabric/port-channel* # commit-buffer
firepower-9300 /eth-uplink/fabric/port-channel #
```

## Related Commands

Command	Description
<b>duplex</b>	Specifies the duplex mode as full or half.

Command	Description
show interface	Displays the interface status, which includes the speed parameters.

## set speed (aggr-interface)

To set the speed of the interface, use the **set speed** command.

```
set speed { 10mbps | 100mbps | 1gbps | 10gbps | 40gbps | 100gbps }
```

Syntax Description		
	<b>10mbps</b>	(Optional) Sets the speed at 10 Mbps.
	<b>100mbps</b>	(Optional) Sets the speed at 100 Mbps.
	<b>1gbps</b>	(Optional) Sets the speed at 1 Gbps.
	<b>10gbps</b>	(Optional) Sets the speed at 10 Gbps.
	<b>40gbps</b>	(Optional) Sets the speed at 40 Gbps.
	<b>100gbps</b>	(Optional) Sets the speed at 100 Gbps.

**Command Modes** scope eth-uplink/scope fabric a/port-channel/

Command History	Release	Modification
	2.4.1(1)	Command added.

**Usage Guidelines** The interface speed that you specify can affect the duplex mode used for an interface, so you must set the speed before setting the duplex mode. If you specify 10- or 100-Mbps speed, the port is automatically configured to use half-duplex mode, but you can specify full-duplex mode instead. If you specify a speed of 1000 Mbps (1Gbps) or faster, full duplex is automatically used.

This example shows how to set the interface speed:

```
firepower-9300* # scope cabling
firepower-9300 /cabling* # scope fabric a
firepower-9300 /cabling/fabric* # create breakout port breakout 2 1
firepower-9300 /cabling/fabric* # show config
  scope fabric a
+   enter breakout 2 3
+   exit
  exit
firepower-9300 /cabling/fabric* # exit
firepower-9300 /cabling* # exit
firepower-9300* # scope eth-uplink
firepower-9300 /eth-uplink* # scope fabric a
firepower-9300 /eth-uplink/fabric* # show

Fabric:
  Fabric ID
  -----
  A
firepower-9300 /eth-uplink/fabric* # show
<CR>
>                               Redirect it to a file
>>                             Redirect it to a file in append mode
aggr-interface Aggregate Interface
```

```

detail          Detail
event           Event Management
expand          Expand
fault           Fault
fsm             Fsm
interface       Interface
port-channel    Port Channel
stats           statistics
|              Pipe command output to filter

firepower-9300 /eth-uplink/fabric* # show aggr-interface expand
firepower-9300 /eth-uplink/fabric* # show aggr-interface
  1-4          Slot
  <CR>
  >            Redirect it to a file
  >>          Redirect it to a file in append mode
  detail       Detail
  expand        Expand
  n/n          Ethernet<Slot Id>/<Aggregate Port Id>
  |            Pipe command output to filter
firepower-9300 /eth-uplink/fabric* # show aggr-interface expand
firepower-9300 /eth-uplink/fabric* #
  acknowledge Acknowledge
  create        Create managed objects
  delete        Delete managed objects
  enter         Enters a managed object
  scope         Changes the current mode
  show          Show system information

firepower-9300 /eth-uplink/fabric* # scope aggr-interface
  1-4          Slot
  n/n          Ethernet<Slot Id>/<Aggregate Port Id>

firepower-9300 /eth-uplink/fabric* # scope port-channel 2
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface* # create member-port
Ethernet2/1/1
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface/member-port* # show config
+enter member-port 2 1
+exit
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface/member-port* # exit
firepower-9300 /eth-uplink/fabric/port-channel/aggr-interface* # exit
firepower-9300 /eth-uplink/fabric/port-channel* # show config
  enter port-channel 2
    enable
  +   enter aggr-interface 2 1
  +     enter member-port 2 1
  +       exit
  +   exit
  +     enter member-port 1 6
  +       enable
  +     exit
  +       set auto-negotiation no
  +         set descr ""
  +           set duplex fullduplex
  +             set flow-control-policy default
  +               set lacp-policy-name default
  +                 set nw-ctrl-policy default
  +                   set port-channel-mode active
  +                     set port-type data
  +                       set speed 1gbps
  + exit
firepower-9300 /eth-uplink/fabric/port-channel* # set speed
  100gbps 100 Gbps
  100mbps 100 Mbps

```

**set speed (aggr-interface)**

```

10gbps  10 Gbps
10mbps  10 Mbps
1gbps   1 Gbps
40gbps  40 Gbps

```

```

firepower-9300 /eth-uplink/fabric/port-channel* # set speed 1gbps
firepower-9300 /eth-uplink/fabric/port-channel* commit-buffer
firepower-9300 /eth-uplink/fabric/port-channel #

```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>duplex</b>	Specifies the duplex mode as full or half.
<b>show interface</b>	Displays the interface status, which includes the speed parameters.

## set ssh-server

To set the SSH host key size, use the **set ssh-server** command.

```
set ssh-server host-key rsa key_size
```

<b>Syntax Description</b>	<b>rsa</b>	Specifies the host key type.
	<i>key-size</i>	The size of the host key.
<b>Command Modes</b>	Services mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.
<b>Usage Guidelines</b>	Use this command to set the SSH host key size.	

### Example

This example shows how to set the SSH host key size to 2048 bits:

```
FP9300-A # scope system
FP9300-A /system # scope services
FP9300-A /system/services # set ssh-server host-key rsa 2048
FP9300-A /system/services* # commit-buffer
FP9300-A /system/services #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>create ssh-server</b>	Creates a new SSH server host key.
	<b>delete ssh-server</b>	Deletes the existing SSH host key.
	<b>show ssh-server</b>	Shows the host key size.

# set sshkey

To specify an SSH key that allows access without a password, use the **set sshkey** command.

```
set sshkey [none | user_ssh_key]
```

Syntax Description	none	(Optional) Enter the <b>none</b> keyword to clear the user's SSH public key.
	<i>user_ssh_key</i>	(Optional) Enter or paste the user's public SSH key.

**Command Modes** Local user mode

Command History	Release	Modification
	1.1(1)	Command added.

**Usage Guidelines** If you press **Enter** after entering **set sshkey**, you are prompted to provide the SSH key, one line at a time. Enter ENDOFBUF to finish. Press Ctrl-C to abort.

## Example

This example shows how to specify a public SSH key for the current local user:

```
FP9300-A /security/local-user # set sshkey
"ssh-rsa
AAAAB3NzaC1yc2EAAAABIwAAAIEAuo9VQ2CmWBI9/S1f30k1CWjnV3lgdXMz00WU15iPw851kdQqap+NFuNmHcb4K
iaQB8X/PDdmtlxQQcawclj+k8f4VcOelBxlsGk5luq5ls1ob1VOIEwcKEL/h5lrdbn1I8y3SS9I/gGiBZ9ARlop9LDpD
m8HPh2LOgyH7Ei1MI8="
FP9300-A /security/local-user* # commit-buffer
FP9300-A /security/local-user #
```

Related Commands	Command	Description
	<b>create local-user</b>	Creates a new local-user account.
	<b>set password</b>	Specifies a password for a user account.

## set startup-version

To specify the startup version of an application, use the **set startup-version** command.

### set startup-version

<b>Syntax Description</b>	<b>startup-version</b>	The startup software version of an application instance
<b>Command Modes</b>	scope ssa	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.
<b>Usage Guidelines</b>	If you press <b>Enter</b> after <b>scope app-instance ftd ftd1</b> , you are prompted to set the startup version.	

### Example

This example shows how to set the startup version for an ftd application:

```
FPR# scope ssa
FPR /ssa # scope slot 1
FPR /ssa/slot # scope app-instance ftd ftd1
FPR /ssa/slot/app-instance # set startup-version 6.6.1.91
Warning: Upgrade of ftd through FXOS is not supported. The specified version of ftd will
be installed. Please reinitialize or reinstall ftd.
```

# set timezone

To set the timezone in FXOS, use the **set timezone** command.

## set timezone

<b>Syntax Description</b>	<b>set timezone</b>	Use the command set timezone to set the timezone in FXOS
<b>Command Modes</b>	scope system/scope services	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.
<b>Usage Guidelines</b>	Use this command to set the timezone in FXOS.	

## Example

This example shows how to set the timezone in FXOS:

```
firepower# scope system
firepower /system# scope services
firepower /system/services # set timezone
Please identify a location so that time zone rules can be set correctly.
Please select a continent or ocean.
1) Africa                4) Arctic Ocean        7) Australia            10) Pacific Ocean
2) Americas              5) Asia                8) Europe
3) Antarctica           6) Atlantic Ocean     9) Indian Ocean

#? 8 <===== Europe

Please select a country.
1) Aaland Islands       18) Greece             35) Norway
2) Albania              19) Guernsey           36) Poland
3) Andorra              20) Hungary            37) Portugal
4) Austria              21) Ireland            38) Romania
5) Belarus              22) Isle of Man        39) Russia
6) Belgium              23) Italy               40) San Marino
7) Bosnia & Herzegovina 24) Jersey             41) Serbia
8) Britain (UK)        25) Latvia             42) Slovakia
9) Bulgaria             26) Liechtenstein     43) Slovenia
10) Croatia             27) Lithuania          44) Spain
11) Czech Republic     28) Luxembourg         45) Sweden
12) Denmark            29) Macedonia         46) Switzerland
13) Estonia            30) Malta              47) Turkey
14) Finland            31) Moldova            48) Ukraine
15) France              32) Monaco             49) Vatican City
16) Germany            33) Montenegro
17) Gibraltar          34) Netherlands

#? 36 <=====Poland

The following information has been given:
```

Poland

```
Therefore timezone 'Europe/Warsaw' will be set.
Local time is now:      Sun Oct 24 08:51:04 CEST 2021.
Universal Time is now:  Sun Oct 24 06:51:04 UTC 2021.
Is the above information OK?
1) Yes
2) No
```

```
#? 1 <===== Yes
```

```
firepower /system/services* # commit
firepower /system/services # show timezone
Timezone: Europe/Warsaw <===== Timezone is set
```

To set the timezone to UTC:

```
firepower /system/services* # set timezone UTC
firepower /system/services* # commit
```

# set trustpoint

To set the certificate trustpoint for a keyring, use the **set trustpoint** command.

**set trustpoint** *trustpoint\_name*

<b>Syntax Description</b>	<i>trustpoint_name</i>	Name of a defined trustpoint.  This name can be between 1 and 32 alphanumeric characters. You cannot use spaces or any special characters other than - (hyphen), _ (underscore), : (colon), and . (period), and you cannot change this name after the object is saved.
<b>Command Modes</b>	scope security/scope keyring/	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.
<b>Usage Guidelines</b>	Use this command to specify the trusted point that signed this keyring's certificate.	

## Example

This example shows how to regenerate the keys in the default keyring:

```
firepower# scope security
firepower /security # scope keyring test-ring
firepower /security/keyring # set trustpoint CiscoCA5
firepower /security/keyring* # commit-buffer
firepower /security/keyring #
```

Command	Description
<b>set cert</b>	Enters an RSA certificate for a keyring.
<b>set modulus</b>	Specifies the RSA key modulus (SSL key length) in bits.
<b>set regenerate</b>	Regenerates the RSA keys in the default keyring.

# set use-2-factor

To enable and disable two-factor authentication for the authentication realm, use the **set use-2-factor** command.



**Note** Two-factor authentication applies only to RADIUS and TACACS+ realms.

**set use-2-factor** {no|yes}

## Syntax Description

<b>no</b>	Disables two-factor authentication for the realm.
<b>yes</b>	Enables two-factor authentication for the realm.

## Command Modes

Default authentication mode

## Command History

Release	Modification
1.1(1)	Command added.

## Usage Guidelines

If you set two-factor authentication for a RADIUS or TACACS+ realm, consider increasing the session-refresh and session-timeout periods so that remote users do not have to re-authenticate too frequently.

## Example

This example shows how to enter default authentication mode and enable two-factor authentication:

```
FP9300-A# scope security
FP9300-A /security # scope default-auth
FP9300-A /security/default-auth # set use-2-factor yes
FP9300-A /security/default-auth* # commit-buffer
FP9300-A /security/default-auth #
```

## Related Commands

Command	Description
<b>set authentication</b>	Specifies the default authentication service.
<b>set timeout values</b>	The <b>set absolute-session-timeout</b> , <b>set con-absolute-session-timeout</b> , <b>set con-session-timeout</b> , and <b>set session-timeout</b> commands are used to set various timeout values.

## set user-account-unlock-time

To specify the amount of time a user remains locked out of the system after reaching the maximum number of login attempts, use the **set user-account-unlock-time** command.

**set user-account-unlock-time** *unlock\_time*

<b>Syntax Description</b>	<i>unlock_time</i>	The amount of time in seconds a user remains locked out of the system. The value can range from 600 to 36000; the default is 1800 seconds (30 minutes).
---------------------------	--------------------	---

<b>Command Modes</b>	Security mode
----------------------	---------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

**Usage Guidelines** If any user (including admin users) exceeds the specified maximum number of login attempts, the user is locked out of the system and must wait this amount of time before being allowed to log in again. No notification appears indicating that the user is locked out.

### Example

This example shows how to enter security mode and specify the amount of time that must pass before a locked-out user can log in again:

```
FP9300-A # scope security
FP9300-A /security # set user-account-unlock-time 900
FP9300-A /security* # commit-buffer
FP9300-A /security #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>clear lock-status</b>	Clears a user's locked-out status.
	<b>set max-login-attempts</b>	Specifies the maximum number of failed login attempts before the user is locked out of the system.

# set user-label

To assign a user-defined identifier to the appliance chassis, use the **set user-label** command in `chassis/` mode.

To assign a user-defined identifier to one of the installed servers, use the **set user-label** command in `server/` mode.

**set user-label** *user\_label*

<b>Syntax Description</b>	<i>user_label</i>	The label you want assigned to the appliance or server; maximum of 32 characters.
<b>Command Modes</b>	scope chassis/ scope chassis/scope server	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	1.1(1)	Command added.

**Usage Guidelines**

You can use the **show detail** command in `chassis/` mode to view the user label currently assigned to the chassis.

You can use the **show detail** command in `chassis/server/` mode to view the user label currently assigned to the connected server.

## Example

This example shows how to assign a user-defined label to the appliance chassis:

```
firepower # scope chassis 1
firepower /chassis # set user-label FP9300-4
firepower /chassis* # commit-buffer
firepower /chassis # show detail
```

```
Chassis:
  Chassis: 1
  User Label: FP9300-4
  Overall Status: Operable
  Oper qualifier: N/A
  Operability: Operable
  Conf State: Ok
  Admin State: Acknowledged
  Conn Path: A
  Conn Status: A
  Managing Instance: A
  Product Name: Cisco Firepower 9300 Security Appliance AC
  PID: FPR-C9300-AC
  VID: V02
  Part Number: 68-100280-04
  Vendor: Cisco Systems Inc
  Model: FPR-C9300-AC
  Serial (SN): JMX1950196H
  HW Revision: 0
```

```

Mfg Date: 2015-12-16T00:00:00.000
Power State: Ok
Thermal Status: Ok
SEEPROM operability status: Operable
Dynamic Reallocation: Chassis
Reserved Power Budget (W): 600
PSU Capacity (W): 0
PSU Line Mode: High Line
PSU State: Ok
Current Task:
firepower /chassis #

```

---

**Related Commands**

Command	Description
<b>show detail</b>	<p>In <code>chassis/</code> mode, shows detailed chassis information including the chassis' current user label.</p> <p>In <code>chassis/server/</code> mode, shows detailed server information including the connected server's user label.</p>

## set value (create bootstrap-key FIREWALL\_MODE)

To specify the firewall mode, routed or transparent, in the bootstrap configuration for the threat defense and ASA, use the **set value** command.

```
set value {routed | transparent}
```

<b>Syntax Description</b>	<b>routed</b>	Sets the firewall mode to routed firewall mode.
	<b>transparent</b>	Sets the firewall mode to transparent firewall.
<b>Command Modes</b>	scope ssa/create logical-device/create mgmt-bootstrap/create bootstrap-key FIREWALL_MODE/	
<b>Command Default</b>	The default mode is routed.	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.4(1)	Added support for the ASA.
	1.1(4)	Command added for FTD.
<b>Usage Guidelines</b>	Bootstrap settings are meant for initial deployment only, or for disaster recovery. For normal operation, you can change most values in the application CLI configuration.	

### Example

The following example shows how to set the mode to routed mode:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
Firepower /ssa/logical-device* # create mgmt-bootstrap ftd
firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key FIREWALL_MODE
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value routed
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # exit
firepower /ssa/logical-device/mgmt-bootstrap* #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>create bootstrap-key FIREWALL_MODE</b>	Sets the firewall mode for the application.
	<b>create logical-device</b>	Creates the logical device.
	<b>create mgmt-bootstrap</b>	Creates the bootstrap configuration for the application.

## set value (create bootstrap-key MANAGEMENT\_TYPE)

To specify the manager, FMC or FDM, in the bootstrap configuration for the threat defense, use the **set value** command.

```
set value {FMC | LOCALLY_MANAGED}
```

<b>Syntax Description</b>	<b>FMC</b> Sets the manager to FDM.				
	<b>LOCALLY_MANAGED</b> Sets the manager to FMC.				
<b>Command Modes</b>	scope ssa/create logical-device/create mgmt-bootstrap/create bootstrap-key LOCALLY_MANAGED/				
<b>Command Default</b>	The default manager is FMC.				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>2.7(1)</td> <td>Command added for FTD.</td> </tr> </tbody> </table>	Release	Modification	2.7(1)	Command added for FTD.
Release	Modification				
2.7(1)	Command added for FTD.				
<b>Usage Guidelines</b>	Bootstrap settings are meant for initial deployment only, or for disaster recovery. For normal operation, you can change most values in the application CLI configuration.				

### Example

The following example shows how to set the manager to FDM:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
Firepower /ssa/logical-device* # create mgmt-bootstrap ftd
firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key MANAGEMENT_TYPE
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value LOCALLY_MANAGED
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # exit
firepower /ssa/logical-device/mgmt-bootstrap* #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>create bootstrap-key FIREWALL_MODE</b>	Sets the firewall mode for the application.
	<b>create logical-device</b>	Creates the logical device.
	<b>create mgmt-bootstrap</b>	Creates the bootstrap configuration for the application.

## set value (create bootstrap-key PERMIT\_EXPERT\_MODE)

To permit Expert Mode from FTD SSH sessions for the threat defense, use the **set value** command.

**set value** {yes | no}

<b>Syntax Description</b>	<b>no</b>	Disallows Expert Mode from an SSH session to the threat defense.
	<b>yes</b>	Allows an Expert Mode from an SSH session to the threat defense.
<b>Command Modes</b>	scope ssa/create logical-device/create mgmt-bootstrap/create bootstrap-key PERMIT_EXPERT_MODE/	
<b>Command Default</b>	The default is no.	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.4(1)	Command added.

**Usage Guidelines** Expert Mode provides FTD shell access for advanced troubleshooting. By default for container instances, Expert Mode is only available to users who access the FTD CLI from the FXOS CLI. This limitation is only applied to container instances to increase isolation between instances. Use Expert Mode only if a documented procedure tells you it is required, or if the Cisco Technical Assistance Center asks you to use it. To enter this mode, use the expert command in the FTD CLI.

### Example

The following example shows how to enable Expert Mode from SSH:

```
firepower# scope ssa
firepower /ssa # create logical-device FTD1 ftd 1 standalone
Firepower /ssa/logical-device* # create mgmt-bootstrap ftd
firepower /ssa/logical-device/mgmt-bootstrap* # create bootstrap-key PERMIT_EXPERT_MODE
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # set value yes
firepower /ssa/logical-device/mgmt-bootstrap/bootstrap-key* # exit
firepower /ssa/logical-device/mgmt-bootstrap* #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>create bootstrap-key FIREWALL_MODE</b>	Sets the firewall mode for the application.
	<b>create logical-device</b>	Creates the logical device.
	<b>create mgmt-bootstrap</b>	Creates the bootstrap configuration for the application.

# set vlan

To set the VLAN ID for a subinterface for use with container instances, use the **set vlan** command.

**set vlan** *id*

<b>Syntax Description</b>	<i>id</i>	Sets the VLAN ID between 1 and 4095.
<b>Command Modes</b>	scope eth-uplink/scope fabric a/scope interface/create subinterface/ scope eth-uplink/scope fabric a/create port-channel/create subinterface/	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.4(1)	Command added.

**Usage Guidelines**

You can add between 250 and 500 VLAN subinterfaces to the chassis, depending on your network deployment. VLAN IDs per interface must be unique, and within a container instance, VLAN IDs must be unique across all assigned interfaces. You can reuse VLAN IDs on *separate* interfaces as long as they are assigned to different container instances. However, each subinterface still counts towards the limit even though it uses the same ID.

## Example

The following example creates 3 subinterfaces on Ethernet 1/1, and sets them to be data-sharing interfaces.

```
firepower# scope eth-uplink
firepower /eth-uplink # scope fabric a
firepower /eth-uplink/fabric # scope interface Ethernet1/1
firepower /eth-uplink/fabric/interface # create subinterface 10
firepower /eth-uplink/fabric/interface/subinterface* # set vlan 10
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # exit
firepower /eth-uplink/fabric/interface # create subinterface 11
firepower /eth-uplink/fabric/interface/subinterface* # set vlan 11
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # exit
firepower /eth-uplink/fabric/interface # create subinterface 12
firepower /eth-uplink/fabric/interface/subinterface* # set vlan 12
firepower /eth-uplink/fabric/interface/subinterface* # set port-type data-sharing
firepower /eth-uplink/fabric/interface/subinterface* # commit-buffer
firepower /eth-uplink/fabric/interface/subinterface #
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>create port-channel</b>	Creates an EtherChannel (port channel).
	<b>create subinterface</b>	Adds a subinterface.

Command	Description
scope interface	Enters the physical interface object.
set port-type	Sets the interface type.

