



Cisco ISE CLI Commands in Configuration Mode

This chapter describes commands that are used in configuration (config) mode in the Cisco ISE command-line interface (CLI). Each of the command in this chapter is followed by a brief description of its use, command syntax, usage guidelines, and one or more examples.

- [Switch to Configuration Mode in EXEC Mode, on page 3](#)
- [Configuring Cisco ISE in the Configuration Mode, on page 4](#)
- [Configuring Cisco ISE in the Configuration Submode, on page 5](#)
- [CLI Configuration Command Default Settings, on page 6](#)
- [backup interface, on page 7](#)
- [cdp holdtime, on page 11](#)
- [cdp run, on page 12](#)
- [cdp timer, on page 13](#)
- [clear screen, on page 14](#)
- [clock timezone, on page 15](#)
- [cls, on page 18](#)
- [conn-limit, on page 19](#)
- [service cache, on page 20](#)
- [do, on page 21](#)
- [end, on page 24](#)
- [exit, on page 25](#)
- [hostname, on page 26](#)
- [icmp echo, on page 28](#)
- [identity-store, on page 29](#)
- [interface, on page 30](#)
- [ip address, on page 32](#)
- [ip default-gateway, on page 34](#)
- [ip domain-name, on page 35](#)
- [ip host, on page 37](#)
- [ip mtu, on page 39](#)
- [ip name-server, on page 40](#)
- [ip route, on page 42](#)
- [ipv6 address, on page 44](#)
- [ipv6 address autoconfig, on page 46](#)
- [ipv6 address dhcp, on page 48](#)

- [ipv6 enable](#), on page 49
- [ipv6 route](#), on page 51
- [kron occurrence](#), on page 53
- [kron policy-list](#), on page 55
- [logging](#), on page 57
- [ntp](#), on page 58
- [ntp authentication-key](#), on page 60
- [ntp maxdistance](#), on page 62
- [ntp server](#), on page 63
- [rate-limit](#), on page 66
- [password-policy](#), on page 68
- [repository](#), on page 70
- [service](#), on page 73
- [shutdown](#), on page 75
- [snmp-server enable](#), on page 76
- [snmp-server user](#), on page 78
- [snmp-server host](#), on page 80
- [snmp-server community](#), on page 83
- [snmp-server contact](#), on page 84
- [snmp-server location](#), on page 85
- [snmp-server trap dskThresholdLimit](#), on page 86
- [snmp engineid](#), on page 87
- [synflood-limit](#), on page 88
- [username](#), on page 89
- [which](#), on page 91

Switch to Configuration Mode in EXEC Mode

In EXEC mode, you can enter into configuration mode by running the **configure** or **configure terminal (conf t)** command.

You cannot enter configuration commands directly in EXEC mode from the Cisco ISE CLI. Some of the configuration commands require you to enter the configuration submode to complete the command configuration.

To exit configuration mode, enter the **exit**, **end**, or **Ctrl-z** command.

Configuration commands include **interface**, **Policy List**, and **repository**.

You can perform configuration tasks in configuration mode. You must save your configuration changes so that you preserve them during a system reload or power outage.

When you save the configuration, these commands remain across Cisco ISE server reboots, but only if you run either of these commands:

- **copy running-config startup-config**
- **write memory**

Configuring Cisco ISE in the Configuration Mode

You can enter configuration and configuration submodes commands to change the actual configuration of the Cisco ISE server in configuration mode.

Step 1 Enter **configure terminal** to enter into the configuration mode.

```
ise/admin# configure terminal
Enter configuration commands, one per line. End with CNTL-Z.
ise/admin(config)# (configuration mode)
```

Step 2 Enter a question mark (?) to obtain a listing of commands in the configuration mode.

```
ise/admin(config)# ?
Configure commands:
cdp                CDP Configuration parameters
clock              Configure timezone
conn-limit         Configure a TCP connection limit from source IP
do                 EXEC command
end                Exit from configure mode
exit               Exit from configure mode
hostname           Configure hostname
icmp               Configure icmp echo requests
interface          Configure interface
ip                 Configure IP features
kron               Configure command scheduler
logging            Configure system logging
no                 Negate a command or set its defaults
ntp                Specify NTP configuration
password-policy    Password Policy Configuration
rate-limit         Configure a TCP/UDP/ICMP packet rate limit from source IP
repository         Configure Repository
service            Specify service to manage
snmp-server        Configure snmp server
synflood-limit     Configure a TCP SYN packet rate limit
username           User creation
```

Step 3 Enter into the configuration submode. The configuration mode has several configuration submodes. Each of these submodes places you deeper in the prompt hierarchy. From this level, you can enter commands directly into the Cisco ISE configuration.

```
ise/admin(config)# interface GigabitEthernet 0
ise/admin(config-GigabitEthernet)#
```

Step 4 Enter **exit** in sequence at the command prompt to exit both Configuration and EXEC modes. When you enter **exit**, Cisco ISE backs you out one level and returns you to the previous level. When you enter **exit** again, Cisco ISE backs you out to the EXEC level.

```
ise/admin(config)# exit
ise/admin# exit
```

Configuring Cisco ISE in the Configuration Submode

You can enter commands for specific configurations in the configuration submodes. You can use the **exit** or **end** command to exit this prompt and return to the configuration prompt.

Step 1 Enter **configure terminal** to enter into the configuration mode.

```
ise/admin# configure terminal
Enter configuration commands, one per line. End with CNTL-Z.
ise/admin(config)# (configuration mode)
```

Step 2 Enter into the configuration submode.

```
ise/admin# configure terminal
ise/admin(config)# interface GigabitEthernet 0
ise/admin(config-GigabitEthernet)# ?
Configure ethernet interface:
  backup    Configure NIC bonding feature
  do        EXEC command
  end       Exit from configure mode
  exit      Exit from this submode
  ip        Configure IP features
  ipv6      Configure IPv6 features
  no        Negate a command or set its defaults
  shutdown  Shutdown the interface
ise/admin(config-GigabitEthernet)#
```

Step 3 Enter **exit** at the command prompt to exit both configuration submode and configuration mode.

```
ise/admin(config-GigabitEthernet)# exit
ise/admin(config)# exit
ise/admin#
```

CLI Configuration Command Default Settings

CLI configuration commands can have a default form, which returns the command settings to the default values. Most commands are disabled by default, so in such cases using the default form has the same result as using the **no** form of the command.

However, some commands are enabled by default and have variables set to certain default values. In these cases, the default form of the command enables the command and sets the variables to their default values.

backup interface

To configure two Ethernet interfaces in to a single virtual interface for high availability (also called as the NIC bonding or NIC teaming feature), use the **backup interface** command in configuration submode. To remove the NIC bonding configuration, use the **no** form of this command. When two interfaces are bonded, the two NICs appear to be a single device with a single MAC address.

The NIC bonding feature in Cisco ISE does not support load balancing or link aggregation features. Cisco ISE supports only the high availability feature of NIC bonding.

The bonding of interfaces ensures that Cisco ISE services are not affected when there is:

- Physical interface failure
- Loss of switch port connectivity (shut or failure)
- Switch line card failure

When two interfaces are bonded, one of the interfaces becomes the primary interface and the other becomes the backup interface. When two interfaces are bonded, all traffic normally flows through the primary interface. If the primary interface fails for some reason, the backup interface takes over and handles all the traffic. The bond takes the IP address and MAC address of the primary interface.

When you configure the NIC bonding feature, Cisco ISE pairs fixed physical NICs to form bonded NICs. The following table outlines which NICs can be bonded together to form a bonded interface.

Cisco ISE Physical NIC Name	Linux Physical NIC Name	Role in Bonded NIC	Bonded NIC Name
Gigabit Ethernet 0	Eth0	Primary	Bond 0
Gigabit Ethernet 1	Eth1	Backup	
Gigabit Ethernet 2	Eth2	Primary	Bond 1
Gigabit Ethernet 3	Eth3	Backup	
Gigabit Ethernet 4	Eth4	Primary	Bond 2
Gigabit Ethernet 5	Eth5	Backup	

The NIC bonding feature is supported on all supported platforms and node personas. The supported platforms include:

- SNS-3400 series appliances - Bond 0 and 1 (Cisco ISE 3400 series appliances support up to 4 NICs)
- SNS-3500 series appliances - Bond 0, 1, and 2
- VMware virtual machines - Bond 0, 1, and 2 (if six NICs are available to the virtual machine)
- Linux KVM nodes - Bond 0, 1, and 2 (if six NICs are available to the virtual machine)

Syntax Description

backup interface

Configures the NIC bonding feature.

GigabitEthernet

Configures the Gigabit Ethernet interface specified as the backup interf

0 - 3	Number of the Gigabit Ethernet port to configure as the backup interface.
-------	---

Command Default

No default behavior or values.

Command Modes

Interface configuration submode (config-GigabitEthernet)#

Command History

Release	Modification
2.1.0.474	This command was introduced.

Usage Guidelines

- As Cisco ISE supports up to six Ethernet interfaces, it can have only three bonds, bond 0, bond 1, and bond 2.
- You cannot change the interfaces that are part of a bond or change the role of the interface in a bond. Refer to the above table for information on which NICs can be bonded together and their role in the bond.
- The Eth0 interface acts as both the management interface as well as the runtime interface. The other interfaces act as runtime interfaces.
- Before you create a bond, the primary interface (primary NIC) must be assigned an IP address. The Eth0 interface must be assigned an IPv4 address before you create bond 0. Similarly, before you create bond 1 and 2, Eth2 and Eth4 interfaces must be assigned an IPv4 or IPv6 address, respectively.
- Before you create a bond, if the backup interface (Eth1, Eth3, and Eth5) has an IP address assigned, remove the IP address from the backup interface. The backup interface should not be assigned an IP address.
- You can choose to create only one bond (bond 0) and allow the rest of the interfaces to remain as is. In this case, bond 0 acts as the management interface and runtime interface, and the rest of the interfaces act as runtime interfaces.
- You can change the IP address of the primary interface in a bond. The new IP address is assigned to the bonded interface because it assumes the IP address of the primary interface.
- When you remove the bond between two interfaces, the IP address assigned to the bonded interface is assigned back to the primary interface.
- If you want to configure the NIC bonding feature on a Cisco ISE node that is part of a deployment, you must deregister the node from the deployment, configure NIC bonding, and then register the node back to the deployment.
- If a physical interface that acts as a primary interface in a bond (Eth0, Eth2, or Eth4 interface) has static route configured, the static routes are automatically updated to operate on the bonded interface instead of the physical interface.

Example 1 - Configure NIC Bonding

The following procedure explains how you can configure bond 0 between Eth0 and Eth1 interfaces.



Note If a physical interface that acts as a backup interface (for example, Eth1, Eth3, Eth5 interfaces), is configured with an IP address, you must remove the IP address from the backup interface. The backup interface should not be assigned an IP address.

```
ise/admin# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ise/admin(config)# interface gigabitEthernet 0
ise/admin(config-GigabitEthernet)# backup interface gigabitEthernet 1
Changing backup interface configuration may cause ISE services to restart.
Are you sure you want to proceed? Y/N [N]: Y
Stopping ISE Monitoring & Troubleshooting Log Processor...
ISE PassiveID Service is disabled
ISE pxGrid processes are disabled
Stopping ISE Application Server...
Stopping ISE Certificate Authority Service...
Stopping ISE EST Service...
ISE Sxp Engine Service is disabled
Stopping ISE Profiler Database...
Stopping ISE Indexing Engine...
Stopping ISE Monitoring & Troubleshooting Session Database...
Stopping ISE AD Connector...
Stopping ISE Database processes...
Starting ISE Monitoring & Troubleshooting Session Database...
Starting ISE Profiler Database...
Starting ISE Application Server...
Starting ISE Indexing Engine...
Starting ISE Certificate Authority Service...
Starting ISE EST Service...
Starting ISE Monitoring & Troubleshooting Log Processor...
Starting ISE AD Connector...
Note: ISE Processes are initializing. Use 'show application status ise'
      CLI to verify all processes are in running state.
ise/admin(config-GigabitEthernet)#
```

Example 2 - Verify NIC Bonding Configuration

To verify if NIC bonding feature is configured, run the **show running-config** command from the Cisco ISE CLI. You will see an output similar to the following:

```
!
interface GigabitEthernet 0
  ipv6 address autoconfig
  ipv6 enable
  backup interface GigabitEthernet 1
  ip address 192.168.118.214 255.255.255.0
!
```

In the output above, "backup interface GigabitEthernet 1" indicates that NIC bonding is configured on Gigabit Ethernet 0, with Gigabit Ethernet 0 being the primary interface and Gigabit Ethernet 1 being the backup interface. Also, the ADE-OS configuration does not display an IP address on the backup interface in the running config, even though the primary and backup interfaces effectively have the same IP address.

You can also run the **show interfaces** command to see the bonded interfaces.

```
ise/admin# show interface
```

```
bond0: flags=5187<UP,BROADCAST,RUNNING,PRIMARY,MULTICAST> mtu 1500
      inet 10.126.107.60 netmask 255.255.255.0 broadcast 10.126.107.255
      inet6 fe80::8a5a:92ff:fe88:4aea prefixlen 64 scopeid 0x20<link>
      ether 88:5a:92:88:4a:ea txqueuelen 0 (Ethernet)
      RX packets 1726027 bytes 307336369 (293.0 MiB)
      RX errors 0 dropped 844 overruns 0 frame 0
      TX packets 1295620 bytes 1073397536 (1023.6 MiB)
      TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
```

```
GigabitEthernet 0
      flags=6211<UP,BROADCAST,RUNNING,SUBORDINATE,MULTICAST> mtu 1500
      ether 88:5a:92:88:4a:ea txqueuelen 1000 (Ethernet)
      RX packets 1726027 bytes 307336369 (293.0 MiB)
      RX errors 0 dropped 844 overruns 0 frame 0
      TX packets 1295620 bytes 1073397536 (1023.6 MiB)
      TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
      device memory 0xfab00000-fabfffff
```

```
GigabitEthernet 1
      flags=6147<UP,BROADCAST,SUBORDINATE,MULTICAST> mtu 1500
      ether 88:5a:92:88:4a:ea txqueuelen 1000 (Ethernet)
      RX packets 0 bytes 0 (0.0 B)
      RX errors 0 dropped 0 overruns 0 frame 0
      TX packets 0 bytes 0 (0.0 B)
      TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
      device memory 0xfaa00000-faafffff
```

cdp holdtime

To specify the amount of time for which the receiving device should hold a Cisco Discovery Protocol packet from the Cisco ISE server before discarding it, use the **cdp holdtime** command in configuration mode.

cdp holdtime *seconds*

To revert to the default setting, use the **no** form of this command.

no cdp holdtime

Syntax Description	holdtime	Specifies the Cisco Discovery Protocol hold time advertised.
	<i>seconds</i>	Advertised hold time value, in seconds. The value ranges from 10 to 255.
Command Default	The default CDP holdtime, in seconds is 180.	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.
Usage Guidelines	<p>Cisco Discovery Protocol packets transmit with a time to live, or hold time, value. The receiving device will discard the Cisco Discovery Protocol information in the Cisco Discovery Protocol packet after the hold time has elapsed.</p> <p>The cdp holdtime command takes only one argument; otherwise, an error occurs.</p> <p>Example</p> <pre>ise/admin(config)# cdp holdtime 60 ise/admin(config)#</pre>	

cdp run

To enable the Cisco Discovery Protocol on all interfaces, use the **cdp run** command in configuration mode.

cdp run *GigabitEthernet*

To disable the Cisco Discovery Protocol, use the **no** form of this command.

no cdp run

Syntax Description

run	Enables the Cisco Discovery Protocol. Disables the Cisco Discovery Protocol when you use the no form of the cdp run command.
<i>GigabitEthernet</i>	(Optional). Specifies the GigabitEthernet interface on which to enable the Cisco Discovery Protocol.
<i>0-3</i>	Specifies the GigabitEthernet interface number on which to enable the Cisco Discovery Protocol.

Command Default

No default behavior or values.

Command Modes

Configuration (config)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

The command has one optional argument, which is an interface name. Without an optional interface name, the command enables the Cisco Discovery Protocol on all interfaces.



Note The default for this command is on interfaces that are already up and running. When you are bringing up an interface, stop the Cisco Discovery Protocol first; then, start the Cisco Discovery Protocol again.

Example

```
ise/admin(config)# cdp run GigabitEthernet 0
ise/admin(config)#
```

cdp timer

To specify how often the Cisco ISE server sends Cisco Discovery Protocol updates, use the **cdp timer** command in configuration mode.

cdp timer *seconds*

To revert to the default setting, use the **no** form of this command.

no cdp timer

Syntax Description	timer	Refreshes at the time interval specified.
	<i>seconds</i>	Specifies how often, in seconds, the Cisco ISE server sends Cisco Discovery Protocol updates. The value ranges from 5 to 254 seconds.
Command Default	The default refreshing time interval value, in seconds is 60.	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.
Usage Guidelines	Cisco Discovery Protocol packets transmit with a time to live, or hold time, value. The receiving device will discard the Cisco Discovery Protocol information in the Cisco Discovery Protocol packet after the hold time has elapsed.	

The **cdp timer** command takes only one argument; otherwise, an error occurs.

Example

```
ise/admin(config)# cdp timer 60
ise/admin(config)#
```

clear screen

To clear the contents of terminal screen, use the **clear screen** command in configuration mode.

clear screen

Syntax Description	This command has no keywords and arguments.	
Command Default	No default behavior or values.	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.
Usage Guidelines	clear screen is a hidden command. Although clear screen is available in Cisco ISE, the CLI interactive Help does not display it if you attempt to view it by entering a question mark at the command line.	

Example

The following example shows how to clear the contents of the terminal:

```
ise/admin(config)# clear screen
ise/admin#
```

clock timezone

To set the time zone, use the **clock timezone** command in configuration mode.

clock timezone *timezone*

To disable the time zone, use the **no** form of this command.

no clock timezone

Syntax Description	timezone	Configures system timezone.
	<i>timezone</i>	Name of the time zone visible when in standard time. Supports up to 64 alphanumeric characters.
If you have the primary Administration node (PAN) auto-failover configuration enabled, disable it before you set the time zone. You can enable it after the time zone is set.		
Command Default	Coordinated Universal Time (UTC)	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.
	3.2	The no form of this command is no longer supported.
Usage Guidelines	The system internally keeps time in UTC. If you do not know your specific time zone, you can enter the region, country, and city (see Tables 4-1, 4-2, and 4-3 for common time zones and time zones for Australia and Asia to enter on your system).	



Note Several more time zones are available to you. Enter **show timezones** and a list of all time zones available appears in the Cisco ISE server. Choose the most appropriate one for your time zone.

If you have the PAN auto-failover configuration enabled in your deployment, the following message appears:

```
PAN Auto Failover is enabled, this operation is not
allowed! Please disable PAN Auto-failover first.
```

Example

```
ise/admin(config)# clock timezone EST
ise/admin(config)# exit
ise/admin# show timezone
EST
ise/admin#
```

Changing the Time Zone on Cisco ISE Nodes

Changing the time zone on the PSN or MnT nodes of a Cisco ISE appliance after installation, causes some known issues with the sorting order of the live logs and live sessions pages. The old logs and sessions are not displayed in the right sorting order based on timestamps. New sessions created after the time zone change are sorted and displayed in the right order. ISE reports may also have data inconsistencies in the timestamp fields and incorrect sorting order.

Common Time Zones

Table 1: Table 4-1 Common Time Zones (Continued)

Acronym or name	Time Zone Name
Europe	
GMT, GMT0, GMT-0, GMT+0, UTC, Greenwich, Universal, Zulu	Greenwich Mean Time, as UTC
GB	British
GB-Eire, Eire	Irish
WET	Western Europe Time, as UTC
CET	Central Europe Time, as UTC + 1 hour
EET	Eastern Europe Time, as UTC + 2 hours
United States and Canada	
EST, EST5EDT	Eastern Standard Time, as UTC - 5 hours
CST, CST6CDT	Central Standard Time, as UTC - 6 hours
MST, MST7MDT	Mountain Standard Time, as UTC - 7 hours
PST, PST8PDT	Pacific Standard Time, as UTC - 8 hours
HST	Hawaiian Standard Time, as UTC - 10 hours

Australia Time Zones



Note Enter the country and city together with a forward slash (/) between them for the Australia time zone; for example, Australia/Currie.

Table 2: Table 4-2 Australia Time Zones (Continued)

Australia			
Australian Capital Territory (ACT)	Adelaide	Brisbane	Broken_Hill
Canberra	Currie	Darwin	Hobart
Lord_Howe	Lindeman	Lord Howe Island (LHI)	Melbourne
North	New South Wales (NSW)	Perth	Queensland
South	Sydney	Tasmania	Victoria
West	Yancowinna		

Asia Time Zones



Note The Asia time zone includes cities from East Asia, Southern Southeast Asia, West Asia, and Central Asia. Enter the region and city or country together separated by a forward slash (/); for example, Asia/Aden.

Table 3: Table 4-3 Asia Time Zones (Continued)

Asia			
Aden	Almaty	Amman	Anadyr
Aqtau	Aqtobe	Ashgabat	Ashkhabad
Baghdad	Bahrain	Baku	Bangkok
Beirut	Bishkek	Brunei	Calcutta
Choibalsan	Chongqing	Columbo	Damascus
Dhakar	Dili	Dubai	Dushanbe
Gaza	Harbin	Hong_Kong	Hovd
Irkutsk	Istanbul	Jakarta	Jayapura
Jerusalem	Kabul	Kamchatka	Karachi
Kashgar	Katmandu	Kuala_Lumpur	Kuching
Kuwait	Krasnoyarsk		

cls

To clear the contents of terminal screen, use the **cls** command in configuration mode.

cls

Syntax Description

This command has no keywords and arguments.

Command Default

No default behavior or values.

Command Modes

Configuration (config)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

cls is a hidden command. Although **cls** is available in Cisco ISE, the CLI interactive Help does not display it if you attempt to view it by entering a question mark at the command line.

Example

The following example shows how to clear the contents of the terminal:

```
ise/admin(config)# cls
ise/admin#
```

conn-limit

To configure the limit of incoming TCP connections from a source IP address, use the **conn-limit** command in configuration mode. To remove this function, use the **no** form of this command.

Syntax Description	<1-2147483647>	Number of TCP connections.
	<i>ip</i>	(Optional). Source IP address to apply the TCP connection limit.
	<i>mask</i>	(Optional). Source IP mask to apply the TCP connection limit.
	<i>port</i>	(Optional). Destination port number to apply the TCP connection limit.
Command Default	No default behavior or values.	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.
	3.2	This command is updated to include assigning a name for the conn-limit configure.
Usage Guidelines	<p>Use this conn-limit command for more than 99 TCP connections. For less than 100 connections, the system displays the following warning:</p> <pre>% Warning: Setting a small conn-limit may adversely affect system performance</pre> <p>Example</p> <pre>ise/admin(config)# conn-limit 25000 ip 10.0.0.1 port 22 ise/admin(config)# end ise/admin</pre>	

service cache

To cache the DNS requests for hosts, use the **service cache enable** command in configuration mode. Enabling this feature will reduce the load on DNS server.

service cache enable hosts ttl *ttl*

To disable this feature, use the no form of this command.

Syntax Description	<i>ttl</i>	You can configure the Time to Live (TTL) value, in seconds, for a host in the cache while enabling the cache. There is no default setting for <i>ttl</i> . The valid range for <i>ttl</i> is from 1 to 2147483647.
Command Default	No default behavior or values.	
Command Modes	Configuration (config)#	
Usage Guidelines	TTL value is honored for negative responses. The TTL value set in the DNS server is honored for positive responses. If there is no TTL defined on the DNS server, then the TTL configured from the command is honored. Cache can be invalidated by disabling the feature.	

Example

```
ise/admin(config)# service cache enable hosts ttl 10000
Enabling dns cache
ise/admin(config)# exit
```

do

To execute an EXEC-system level command from configuration mode or any configuration submode, use the **do** command in any configuration mode.

do *EXEC commands*

Syntax Description

EXEC commands

Specifies to execute an EXEC-system level command (see [Table 4: Table 4-4 Command Options for Do Command \(Continued\)](#)).

Table 4: Table 4-4 Command Options for Do Command (Continued)

Command	Description
application configure	Configures a specific application.
application install	Installs a specific application.
application remove	Removes a specific application.
application reset-config	Resets application configuration to factory defaults.
application reset-passwd	Resets application password for a specified user.
application start	Starts or enables a specific application
application stop	Stops or disables a specific application.
application upgrade	Upgrades a specific application.
backup	Performs a backup (Cisco ISE and Cisco ADE OS) and places the backup in the backup repository.
backup-logs	Performs a backup of all logs in the Cisco ISE server to a remote location.
clock	Sets the system clock in the Cisco ISE server.
configure	Enters configuration mode.
copy	Copies any file from a source to a destination.
debug	Displays any errors or events for various command situations; for example, backup and restore, configuration, copy, resource locking, file transfer, and file management.
delete	Deletes a file in the Cisco ISE server.
dir	Lists files in the Cisco ISE server.
forceout	Forces the logout of all sessions of a specific Cisco ISE node user.
halt	Disables or shuts down the Cisco ISE server.

Command	Description
mkdir	Creates a new directory.
nslookup	Queries the IPv4 or IPv6 address or hostname of a remote system.
password	Updates the CLI account password.
patch	Installs a Patch Bundle or uninstalls an Application patch.
ping	Determines the IPv4 address or hostname of a remote system.
ping6	Determines the IPv6 address of a remote system.
reload	Reboots the Cisco ISE server.
restore	Performs a restore and retrieves the backup out of a repository.
rmdir	Removes an existing directory.
show	Provides information about the Cisco ISE server.
ssh	Starts an encrypted session with a remote system.
tech	Provides Technical Assistance Center (TAC) commands.
terminal length	Sets terminal line parameters.
terminal session-timeout	Sets the inactivity timeout for all terminal sessions.
terminal session-welcome	Sets the welcome message on the system for all terminal sessions.
terminal terminal-type	Specifies the type of terminal connected to the current line of the current session.
traceroute	Traces the route of a remote IP address.
undebg	Disables the output (display of errors or events) of the debug command for various command situations; for example, backup and restore, configuration, copy, resource locking, file transfer, and user management.
write	Erases the startup configuration that forces to run the setup utility and prompts for the network configuration, copies the running configuration to the startup configuration, displays the running configuration on the console.

Command Default

No default behavior or values.

Command Modes

Configuration (config)# or any configuration submode (config-GigabitEthernet)# and (config-Repository)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

Use this **do** command to execute EXEC commands (such as **show**, **clear**, and **debug** commands) while configuring the Cisco ISE server. After the EXEC command is executed, the system will return to configuration mode you were using.

Example

```
ise/admin(config)# do show run
Generating configuration...
!
hostname ise
!
ip domain-name cisco.com
!
interface GigabitEthernet 0
  ip address 172.23.90.113 255.255.255.0
  ipv6 address autoconfig
!
ip name-server 10.0.0.1
ip default-gateway 172.23.90.1
!
clock timezone EST
!
ntp server time.nist.gov
!
username admin password hash $1$JbbHvKVG$xMZ/XL4tH15Knf.FfcZZr. role admin
!
service sshd
!
backup-staging-url nfs://loc-filer02a:/vol/local1/private1/jdoe
!
password-policy
  lower-case-required
  upper-case-required
  digit-required
  no-username
  disable-cisco-passwords
  min-password-length 6
!
logging localhost
logging loglevel 6
!
--More--
ise/admin(config)#
```

end

To end the current configuration session and return to EXEC mode, use the **end** command in configuration mode.

This command has no keywords and arguments.

end

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	Configuration (config)#
----------------------	-------------------------

Command History	Release	Modification
	2.0.0.306	This command was introduced.

Usage Guidelines	This command brings you back to EXEC mode regardless of what configuration mode or submode you are in.
	Use this command when you finish configuring the system and you want to return to EXEC mode to perform verification steps.

Example

```
ise/admin(config)# end
ise/admin#
```


exit

To exit any configuration mode to the next-highest mode in the CLI mode hierarchy, use the **exit** command in configuration mode.

exit

This command has no keywords and arguments.

Command Default

No default behavior or values.

Command Modes

Configuration (config)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

The **exit** command is used in the Cisco ISE server to exit the current command mode to the next highest command mode in the CLI mode hierarchy.

For example, use the **exit** command in configuration mode to return to EXEC mode. Use the **exit** command in the configuration submodes to return to configuration mode. At the highest level, EXEC mode, the **exit** command exits EXEC mode and disconnects from the Cisco ISE server.

Example

```
ise/admin(config)# exit
ise/admin#
```

hostname

To set the hostname of the system, use the **hostname** command in configuration mode.

hostname *hostname*

Syntax Description	<i>hostname</i>	Name of the host. Supports up to 19 alphanumeric characters and a hyphen. The hostname must begin with a character that is not a space.
Command Default	No default behavior or values.	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.

Usage Guidelines



Note If 'Ctrl-C' is issued during the CLI configuration change of 'hostname' command, the system might end up in a state where some application components might have the old hostname while some components might use the new hostname. This will bring the Cisco ISE node to a non-working state.

The workaround for this issue is to run the 'hostname' configuration command again to set the hostname to the desired value.

You can use the **hostname** command to change the current hostname. A single instance type of command, **hostname** only occurs once in the configuration of the system. The hostname must contain one argument; otherwise, an error occurs.

When you update the hostname of the Cisco ISE server with this command, the following warning message is displayed:

```
% Warning: Updating the hostname will cause any certificate using the old
%           hostname to become invalid. Therefore, a new self-signed
%           certificate using the new hostname will be generated now for
%           use with HTTPS/EAP. If CA-signed certs were used on this node,
%           please import them with the correct hostname. If Internal-CA
%           signed certs are being used, please regenerate ISE Root CA certificate.
%           In addition, if this ISE node will be joining a new Active Directory
%           domain, please leave your current Active Directory domain before
%           proceeding. If this ISE node is already joined to
%           an Active Directory domain, then it is strongly advised
%           to rejoin all currently joined join-points in order to
%           avoid possible mismatch between current and previous
%           hostname and joined machine account name.
```

Example

```
ise/admin(config)# hostname new-hostname
% Changing the hostname will cause ISE services to restart
```

```
Continue with hostname change? Y/N [N]: y

Stopping ISE Monitoring & Troubleshooting Log Processor...
ISE Identity Mapping Service is disabled
ISE pxGrid processes are disabled
Stopping ISE Application Server...
Stopping ISE Certificate Authority Service...
Stopping ISE Profiler Database...
Stopping ISE Monitoring & Troubleshooting Session Database...
Stopping ISE AD Connector...
Stopping ISE Database processes...
ISE Database processes already running, PID: 9651
Starting ISE Monitoring & Troubleshooting Session Database...
Starting ISE Profiler Database...
Starting ISE Application Server...
Starting ISE Certificate Authority Service...
Starting ISE Monitoring & Troubleshooting Log Processor...
Starting ISE AD Connector...
Note: ISE Processes are initializing. Use 'show application status ise'
      CLI to verify all processes are in running state.
ise-1/admin#
```

icmp echo

To configure the Internet Control Message Protocol (ICMP) echo responses, use the **icmp echo** command in configuration mode.

icmp echo {*off* | *on*}

Syntax Description

echo	Configures ICMP echo response.
<i>off</i>	Disables ICMP echo response
<i>on</i>	Enables ICMP echo response.

Command Default

The system behaves as if the ICMP echo response is on (enabled).

Command Modes

Configuration (config)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

Use this **icmp echo** to turn on or turn off ICMP echo response.

Example

```
ise/admin(config)# icmp echo off
ise/admin(config)#
```

identity-store

To join a CLI Administrator to an Active Directory domain, use the **identity-store** command in config mode. If the Cisco ISE node has joined multiple domains, you can only join one domain with this command. Each CLI Administrator joins individually. Please allow five minutes for Cisco ISE to complete the operation.

If the domain you join with this command is the same as the one that was joined to the ISE node, then you must rejoin the domain in the Administrators console. The Admin CLI user must be a Super Admin.

Command History

Release	Modification
2.6.0.156	This command was introduced.

Example

```
identity-store active-directory domain-name <aDomainFQDN> user <adUserNameWithJoinPrivs>
```



Note

Active Directory CLI does not support authentication using child domain users. Child domain is considered as a separate domain which needs to be explicitly joined for its corresponding users to be used for authentication.

interface

To configure an interface type and enter the interface configuration mode, use the **interface** command in configuration mode. This command does not have a **no** form.



Note VMware virtual machine may have a number of interfaces available that depends on how many network interfaces (NIC) are added to the virtual machine.

interface GigabitEthernet {0 | 1 | 2 | 3}

Syntax Description

GigabitEthernet	Configures the Gigabit Ethernet interface.
0 - 3	Number of the Gigabit Ethernet port to configure.



Note After you enter the Gigabit Ethernet port number in the **interface** command, you enter the config-GigabitEthernet configuration submode (see the following Syntax Description).

Syntax Description

backup	Configures the NIC bonding feature to provide high availability for the physical interfaces.
do	EXEC command. Allows you to perform any EXEC commands in this mode.
end	Exits the config-GigabitEthernet submode and returns you to EXEC mode.
exit	Exits the config-GigabitEthernet configuration submode.
ip	Sets the IP address and netmask for the Gigabit Ethernet interface.
ipv6	Configures IPv6 autoconfiguration address and IPv6 address from DHCPv6 server.
no	Negates the command in this mode. Two keywords are available: <ul style="list-style-type: none"> • ip—Sets the IP address and netmask for the interface. • ipv6—Sets the IPv6 address for the interface. • shutdown—Shuts down the interface.
shutdown	Shuts down the interface.

Command Default

No default behavior or values.

Command Modes

Interface configuration (config-GigabitEthernet)#

Command History**Release****Modification**

2.0.0.306

This command was introduced.

Usage Guidelines

You can use the **interface** command to configure the interfaces to support various requirements.

Example

```
ise/admin(config)# interface GigabitEthernet 0
ise/admin(config-GigabitEthernet) #
```

ip address

To set the IP address and netmask for the GigabitEthernet interface, use the **ip address** command in interface configuration mode.

ip address *ip-address network mask*

To remove an IP address or disable IP processing, use the **no** form of this command.

no ip address



Note You can configure the same IP address on multiple interfaces. You might want to do this to limit the configuration steps that are needed to switch from using one interface to another.



Note The "no ip address" command is not applicable to the GigabitEthernet 0 interface. However, you can modify the IP address using the "ip address" command.

We do not recommend configuring two interfaces with the same subnet on Cisco ISE because of the difficulty in ascertaining the interface that will be used for data transmission.

Syntax Description

<i>ip-address</i>	IPv4 address.
<i>network mask</i>	Mask of the associated IP subnet.

If you have the primary Administration node (PAN) auto-failover configuration enabled, disable it before you set the IP address. You can enable the PAN auto-failover configuration after the IP address is configured.

Command Default

Enabled.

Command Modes

Interface configuration (config-GigabitEthernet)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines



Note If 'Ctrl-C' is issued during the CLI configuration change of 'ip address' command, in case of IP address change the system may end up in a state where some application components have the old IP address, and some components use the new IP address.

This will bring the Cisco ISE node into a non-working state. The workaround for this is to issue another 'ip address' configuration CLI to set the IP address to the desired value.

Requires exactly one address and one netmask; otherwise, an error occurs.

If you have the PAN auto-failover configuration enabled in your deployment, the following message appears:

```
PAN Auto Failover is enabled, this operation is not
allowed! Please disable PAN Auto-failover first.
```

Example

```
ise/admin(config)# interface GigabitEthernet 1
ise/admin(config-GigabitEthernet)# ip address 209.165.200.227 255.255.255.224
Changing the hostname or IP may result in undesired side effects,
such as installed application(s) being restarted.
.....
To verify that ISE processes are running, use the
'show application status ise' command.
ise/admin(config-GigabitEthernet)#
```

ip default-gateway

To define or set a default gateway with an IP address, use the **ip default-gateway** command in configuration mode.

ip default-gateway *ip-address*



Note Deleting the default gateway is not recommended since it is mandatory for packet traffic to go out of the system. You can enable the default gateway function on another interface instead. If you want to have a quad zero static route, it is recommended that you add that on an interface that is not configured as the default gateway.

Syntax Description

default-gateway	Defines a default gateway with an IP address.
<i>ip-address</i>	IP address of the default gateway.

Command Default

Disabled.

Command Modes

Configuration (config)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

If you enter more than one argument or no arguments at all, an error occurs.

Example

```
ise/admin(config)# ip default-gateway 209.165.202.129
Adding/Changing gateway may cause ise services to restart.
Are you sure you want to proceed? Y/N [N]:
```



Note When you add or change the gateway, you must restart the services for the changes to take effect.

ip domain-name

To define a default domain name that the Cisco ISE server uses to complete hostnames, use the **ip domain-name** command in configuration mode.

ip domain-name *domain-name*

To disable this function, use the **no** form of this command.

no ip domain-name

Syntax Description	domain-name	Defines a default domain name.
	<i>domain-name</i>	Default domain name used to complete the hostnames. Contains at least alphanumeric characters.
Command Default	Enabled.	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.

Usage Guidelines



Note

If 'Ctrl-C' is issued during the CLI configuration change of 'ip domain-name' command, in case of ip domain-name change the system may end up in a state where some application components have the old domain-name and some components use the new domain-name.

This will bring the Cisco ISE node into a non-working state. The workaround for this is to issue another 'ip domain-name' configuration CLI to set the domain name to the desired value.

If you enter more or fewer arguments, an error occurs.

If you update the domain name for the Cisco ISE server with this command, it displays the following warning message:

```
% Warning:  Updating the domain name will cause any certificate using the old
%           domain name to become invalid. Therefore, a new self-signed
%           certificate using the new domain name will be generated now for
%           use with HTTPs/EAP.  If CA-signed certs were used on this node,
%           please import them with the correct domain name.  If Internal-CA
%           signed certs are being used, please regenerate ISE Root CA certificate.
%           In addition, if this ISE node will be joining a new Active Directory
%           domain, please leave your current Active Directory domain before
%           proceeding.
```

Example

```
ise/admin(config)# ip domain-name cisco.com  
ise/admin(config)#
```

ip host

To associate a host alias and fully qualified domain name (FQDN) string to an ethernet interface such as eth1, eth2, and eth3 other than eth0, use the **ip host** command in global configuration mode.

When Cisco ISE processes an authorization profile redirect URL, it replaces the IP address with the FQDN of the Cisco ISE node.

ip host [*ipv4-address* | *ipv6-address*] [*host-alias* | *FQDN-string*]

To remove the association of host alias and FQDN, use the **no** form of this command.

no ip host [*ipv4-address* | *ipv6-address*] [*host-alias* | *FQDN-string*]

Syntax Description	<i>ipv4-address</i>	IPv4 address of the network interface.
	<i>ipv6-address</i>	IPv6 address of the network interface.
	<i>host-alias</i>	Host alias is the name that you assign to the network interface.
	<i>FQDN-string</i>	Fully qualified domain name (FQDN) of the network interface.

If you have the Primary Administration Node (PAN) auto-failover configuration enabled, disable it before you change the host alias and FQDN of an ethernet interface. You can enable the PAN auto-failover configuration after the host alias and FQDN configuration is complete.

If you have the PAN auto-failover configuration enabled in your deployment, the following message appears:

```
PAN Auto Failover is enabled, this operation is
not allowed! Please disable PAN Auto-failover first.
```

Command Default No default behavior or values.

Command Modes Configuration (config)#

Command History	Release	Modification
	2.0.0.306	This command was introduced.

Usage Guidelines Supported IPv6 address formats include:

- Full notation: Eight groups of four hexadecimal digits separated by colons. For example, 2001:0db8:85a3:0000:0000:8a2e:0370:7334
- Shortened notation: Exclude leading zeros in a group; replace groups of zeros with two consecutive colons. For example: 2001:db8:85a3::8a2e:370:7334
- Dotted-quad notation (IPv4-mapped and IPv4 compatible-IPv6 addresses): For example, ::ffff:192.0.2.128

Use the **ip host** command to add host alias and fully qualified domain name (FQDN) string for an IP address mapping. It is used to find out the matching FQDN for ethernet interfaces such as eth1, eth2, and eth3. Use the **show running-config** command to view the host alias definitions.

You can provide either the host alias or the FQDN string, or both. If you provide both the values, the host alias must match the first component of the FQDN string. If you provide only the FQDN string, Cisco ISE replaces the IP address in the URL with the FQDN. If you provide only the host alias, Cisco ISE combines the host alias with the configured IP domain name to form a complete FQDN, and replaces the IP address of the network interface in the URL with the FQDN.



Note We recommend that you include the host alias in the **ip host** command for Cisco ISE 3.1 and later versions.

Example 1

```
ise/admin(config)# ip host 172.21.79.96 isel isel.cisco.com
Host alias was modified. You must restart ISE for change to take effect.
Do you want to restart ISE now? (yes/no) yes
Stopping ISE Monitoring & Troubleshooting Log Processor...
Stopping ISE Application Server...
Stopping ISE Profiler DB...
Stopping ISE Monitoring & Troubleshooting Session Database...
Stopping ISE Database processes...
Starting ISE Database processes...
Stopping ISE Database processes...
Starting ISE Database processes...
Starting ISE Monitoring & Troubleshooting Session Database...
Starting ISE Profiler DB...
Starting ISE Application Server...
Starting ISE Monitoring & Troubleshooting Log Processor...
Note: ISE Processes are initializing. Use 'show application status ise'
      CLI to verify all processes are in running state.
ise/admin(config)#
```

Example 2

```
ise/admin(config)# ipv6 host 2001:db8:cc00:1::1 isel isel.cisco.com
Host alias was modified. You must restart ISE for change to take effect.
Do you want to restart ISE now? (yes/no) yes
Stopping ISE Monitoring & Troubleshooting Log Processor...

Stopping ISE Application Server...
Stopping ISE Profiler DB...
Stopping ISE Monitoring & Troubleshooting Session Database...
Stopping ISE Database processes...
Starting ISE Database processes...
Stopping ISE Database processes...
Starting ISE Database processes...
Starting ISE Monitoring & Troubleshooting Session Database...
Starting ISE Profiler DB...
Starting ISE Application Server...
Starting ISE Monitoring & Troubleshooting Log Processor...
Note: ISE Processes are initializing. Use 'show application status ise'
      CLI to verify all processes are in running state.
ise/admin(config)#
```

ip mtu

To set the maximum transmission unit (MTU) size of IP packets sent and received on an interface, use the **ip mtu** command in the interface configuration mode. To restore the default MTU size, use the **no** form of this command.

ip mtu *bytes*

no ip mtu *bytes*

Syntax Description	mtu	Configures the MTU on a Cisco ISE interface.
Command Default	The MTU is set as 1500.	
Command Modes	Interface configuration (config-GigabitEthernet)#	
Command History	Release	Modification
	2.4.0.357	This command was introduced.
Usage Guidelines	If an IP packet exceeds the MTU set for the interface, the Cisco ISE will fragment it. All devices on a physical medium must have the same protocol MTU in order to operate.	

Example

The following example shows how to configure the MTU on an interface:

```
ise/admin(config)# int GigabitEthernet 1
ise/admin(config-GigabitEthernet)# ip mtu ?
<1280-9999> Recommended range VM:1280-9216;appliance:1280-9999
```

The following example shows the output you can see after configuring the MTU.

```
ise/admin# show run | in mtu
ip mtu 1350
```

ip name-server

To set the Domain Name Server (DNS) for use during a DNS query, use the **ip name-server** command in configuration mode. You can configure one to three DNS servers.

ip name-server *ip-address* {*ip-address**}

To disable this function, use the **no** form of this command.

no ip name-server *ip-address* {*ip-address**}



Note Using the **no** form of this command removes all the name servers from the configuration. The **no** form of this command and one of the IP names removes only that name server.

Syntax Description

name-server	Configures the IP addresses of the name server(s).
<i>ip-address</i>	Address of a name server.
<i>ip-address</i> *	(Optional). IP addresses of additional name servers.

Note You can configure any combination of IPv4 and/or IPv6 addresses. Ensure that the ISE eth0 interface is statically configured with an IPv4 or IPv6 address if you want to add a name-server with an IPv6 address.

If you have the primary Administration node (PAN) auto-failover configuration enabled in your deployment, remove it before you run the **ip name-server** command and enable it after you configure the DNS server(s).

Command Default

No default behavior or values.

Command Modes

Configuration (config)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

The first name server that is added with the **ip name-server** command occupies the first position and the system uses that server first to resolve the IP addresses.

You can add name servers to the system using IPv4 or IPv6 addresses. You can configure one to three IPv4 or IPv6 addresses through a single command. If you have already configured the system with four name servers, you must remove at least one server to add additional name servers.

To place a name server in the first position so that the subsystem uses it first, you must remove all name servers with the **no** form of this command before you proceed.



Note If you modified this setting for AD connectivity, you must restart Cisco ISE for the changes to take effect. Also, ensure that all DNS servers configured in Cisco ISE are able to resolve all relevant AD DNS records. If the configured AD join points are not correctly resolved after the DNS settings are changed, you must manually perform the Leave operation and re-join the AD join point.

If you have the PAN auto-failover configuration enabled in your deployment, the following message appears:

```
PAN Auto Failover is enabled, this operation is not
allowed! Please disable PAN Auto-failover first.
```

Example 1

```
ise/admin(config)# ip name-server ?
<A.B.C.D>|<valid IPv6 format>  Primary DNS server IP address
<A.B.C.D>|<valid IPv6 format>  DNS server 2 IP address
<A.B.C.D>|<valid IPv6 format>  DNS server 3 IP address

ise/admin(config)# ip name-server
```

Example 2

You can see the following output after you configure the IP name server.

```
ise/admin# show run | in name-server
ip name-server 10.0.0.1 10.0.1.1
3201:db8:0:20:f41d:eee:7e66:4eba
ise/admin#
```

Example 3

```
ise/admin(config)# ip name-server ?
ip name-server 10.126.107.120 10.126.107.107 10.106.230.244
DNS Server was modified. If you modified this setting for AD connectivity, you must restart
ISE for the change to take effect.
Do you want to restart ISE now? (yes/no)
```

ip route

To configure the static routes, use the **ip route** command in configuration mode. To remove static routes, use the **no** form of this command.

ip route *prefix mask gateway ip-address*

no ip route *prefix mask*

Syntax Description	<i>prefix</i>	IP route prefix for the destination.
	<i>mask</i>	Prefix mask for the destination.
	<i>ip-address</i>	IP address of the next hop that can be used to reach that network.
Command Default	No default behavior or values.	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.

Usage Guidelines

Static routes are manually configured, which makes them inflexible (they cannot dynamically adapt to network topology changes), but extremely stable. Static routes optimize bandwidth utilization, because no routing updates need to be sent to maintain them. They also make it easy to enforce routing policy.

While the **ip route** command can be used to define static routes on individual Cisco ISE node, this command is enhanced to define a default route for each interface and reduce the effects of asymmetrical IP forwarding, which is inherent in multi-interface IP nodes.

When a single default route is configured on a multi-interface node, all IP traffic received from any of the node's IP interfaces is routed to the next hop of the default gateway that produces asymmetrical IP forwarding. Configuring multiple default routes on the Cisco ISE node eliminates the effects of asymmetric forwarding.

The following example describes how to configure multiple default routes:

Consider the following interface configuration on Cisco ISE node eth0, eth1, eth2, and eth3 interfaces respectively:

```
ISE InterfaceIPNetworkGateway
192.168.114.10 192.168.114.0 192.168.114.1
192.168.115.10 192.168.115.0 192.168.115.1
192.168.116.10 192.168.116.0 192.168.116.1
192.168.117.10 192.168.117.0 192.168.117.1
```

The **ip route** command is used here to define default routes for each interface.

```
ise/admin(config)# ip route 0.0.0.0 0.0.0.0 192.168.114.1
ise/admin(config)# ip route 0.0.0.0 0.0.0.0 192.168.115.1
ise/admin(config)# ip route 0.0.0.0 0.0.0.0 192.168.116.1
```

```
ise/admin(config)# ip route 0.0.0.0 0.0.0.0 192.168.117.1  
ise/admin(config)# ip default-gateway 192.168.118.1
```



Note The "ip default-gateway" shown above is the route of last resort for all interfaces.

The **show ip route** command displays the output of the static routes created using the **ip route** command (default routes and non-default routes) and system created routes including the one configured using "ip default gateway" command. It displays the outgoing interface for each of the routes.



Note When you change the IP address of an interface and if any static route becomes unreachable due to an unreachable gateway, the static route gets deleted from the running configuration. The console displays the route that has become unreachable.

Example 2

```
ise/admin(config)# ip route 192.168.0.0 255.255.0.0 gateway 172.23.90.2  
ise/admin(config)#
```

ipv6 address

To configure a static IPv6 address based on an IPv6 general prefix and enable IPv6 processing for an interface, use the **ipv6 address** command in interface configuration mode.

ipv6 address *ipv6-address/prefix-length*

To remove an IPv6 address or disable IPv6 processing, use the **no** form of this command.

no ipv6 address *ipv6-address/prefix-length*

Syntax Description

<i>ipv6-address</i>	IPv6 address.
<i>prefix-length</i>	The length of the IPv6 prefix. A decimal value between 0 and 128 that indicates how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address). A slash mark must precede the decimal value.

If you have the Primary Administration Node (PAN) auto-failover configuration enabled, disable it before you set the IPv6 address. You can enable the PAN auto-failover configuration after the IPv6 address is configured.

If you have the PAN auto-failover configuration enabled in your deployment, the following message appears:

```
PAN Auto Failover is enabled, this operation is not
allowed! Please disable PAN Auto-failover first.
```

Command Default

No default behavior or values.

Command Modes

Interface configuration (config-GigabitEthernet)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

Supported IPv6 address formats include:

- Full notation: Eight groups of four hexadecimal digits separated by colons. For example, 2001:0db8:85a3:0000:0000:8a2e:0370:7334
- Shortened notation: Exclude leading zeros in a group; replace groups of zeros with two consecutive colons. For example: 2001:db8:85a3::8a2e:370:7334
- Dotted-quad notation (IPv4-mapped and IPv4-compatible IPv6 addresses): For example, ::ffff:192.0.2.128

Using the fe80 prefix assigns a link-local address. Assigning a global address to the interface automatically creates a link-local address.



Note If 'Ctrl-C' is issued during the CLI configuration change of **ipv6 address** command, in case of IPv6 address change, the system may end up in a state where some application components have the old IPv6 address, and some components use the new IPv6 address.

This will bring the Cisco ISE node into a non-working state. The workaround for this is to issue another **ipv6 address** command to set the IPv6 address to the desired value.

Example 1

```
ise/admin(config)# interface GigabitEthernet 1
ise/admin(config-GigabitEthernet)# ipv6 address 2001:DB8:0:1::/64
Changing the IPv6 address may result in undesired side effects on any installed
application(s).
Are you sure you want to proceed? Y/N[N]: y
.....
Note: ISE Processes are initializing. Use 'show application status ise' CLI to verify all
processes are in running state.
ise/admin(config-GigabitEthernet)#
```

Example 2

```
ise/admin(config)# interface GigabitEthernet 1
ise/admin(config-GigabitEthernet)# ipv6 address fe80::250:56ff:fe87:4763/64
ise/admin(config-GigabitEthernet)#
```

ipv6 address autoconfig

To enable automatic configuration of IPv6 addresses using stateless autoconfiguration on an interface and enable IPv6 processing on the interface, use the **ipv6 address autoconfig** command in interface configuration mode.

IPv6 address autoconfiguration is enabled by default in Linux. Cisco ADE 2.0 shows the IPv6 address autoconfiguration in the running configuration for any interface that is enabled.

ipv6 address autoconfig

Use the **no** form of this command to disable autoconfiguration of IPv6 addresses from an interface.

Command Default	No default behavior or values.	
Command Modes	Interface configuration (config-GigabitEthernet)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.
Usage Guidelines	IPv6 stateless autoconfiguration has the security downfall of having predictable IP addresses. This downfall is resolved with privacy extensions. You can verify that the privacy extensions feature is enabled by using the show interface command.	

Example

```
ise/admin(config-GigabitEthernet)# ipv6 address autoconfig
ise/admin(config)#
```

Configuring IPv6 Auto Configuration

To enable IPv6 stateless autoconfiguration, use the **interface GigabitEthernet 0** command in Interface configuration mode:

```
ise/admin# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ise/admin(config)# interface GigabitEthernet 0
ise/admin(config)# (config-GigabitEthernet)# ipv6 address autoconfig
ise/admin(config)# (config-GigabitEthernet)# end
ise/admin#
```

When IPv6 autoconfiguration is enabled, the running configuration shows the interface settings similar to the following:

```
!
interface GigabitEthernet 0
 ip address 172.23.90.116 255.255.255.0
 ipv6 address autoconfig
!
```

You can use the **show interface GigabitEthernet 0** command to display the interface settings. In the example below, you can see that the interface has three IPv6 addresses. The first address (starting with 3ffe) is obtained using the stateless autoconfiguration.

For the stateless autoconfiguration to work, you must have IPv6 route advertisement enabled on that subnet. The next address (starting with fe80) is a link-local address that does not have any scope outside the host.

You will always see a link local address regardless of the IPv6 autoconfiguration or DHCPv6 configuration. The last address (starting with 2001) is obtained from a IPv6 DHCP server.

```
ise/admin# show interface GigabitEthernet 0
eth0      Link encap:Ethernet  HWaddr 00:0C:29:AF:DA:05
          inet addr:172.23.90.116  Bcast:172.23.90.255  Mask:255.255.255.0
          inet6 addr: 3ffe:302:11:2:20c:29ff:feaf:da05/64 Scope:Global
          inet6 addr: fe80::20c:29ff:feaf:da05/64 Scope:Link
          inet6 addr: 2001:558:ff10:870:8000:29ff:fe36:200/64 Scope:Global
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:77848 errors:0 dropped:0 overruns:0 frame:0
          TX packets:23131 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:10699801 (10.2 MiB)  TX bytes:3448374 (3.2 MiB)
          Interrupt:59 Base address:0x2000

ise/admin#
```

Verifying the Privacy Extensions Feature

To verify that the privacy extensions feature is enabled, you can use the **show interface GigabitEthernet 0** command. You can see two autoconfiguration addresses: one address is without the privacy extensions, and the other is with the privacy extensions.

In the example below, the MAC is 3ffe:302:11:2:20c:29ff:feaf:da05/64 and the non-RFC3041 address contains the MAC, and the privacy-extension address is 302:11:2:9d65:e608:59a9:d4b9/64.

The output appears similar to the following:

```
ise/admin# show interface GigabitEthernet 0
eth0      Link encap:Ethernet  HWaddr 00:0C:29:AF:DA:05
          inet addr:172.23.90.116  Bcast:172.23.90.255  Mask:255.255.255.0
          inet6 addr: 3ffe:302:11:2:9d65:e608:59a9:d4b9/64 Scope:Global
          inet6 addr: 3ffe:302:11:2:20c:29ff:feaf:da05/64 Scope:Global
          inet6 addr: fe80::20c:29ff:feaf:da05/64 Scope:Link
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:60606 errors:0 dropped:0 overruns:0 frame:0
          TX packets:2771 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:9430102 (8.9 MiB)  TX bytes:466204 (455.2 KiB)
          Interrupt:59 Base address:0x2000

ise/admin#
```

ipv6 address dhcp

To acquire an IPv6 address on an interface from the Dynamic Host Configuration Protocol for IPv6 (DHCPv6) server, use the **ipv6 address dhcp** command in the interface configuration mode. To remove the address from the interface, use the **no** form of this command.

ipv6 address dhcp

Command Default	No default behavior or values.
Command Modes	Interface configuration (config-GigabitEthernet)#

Command History	Release	Modification
	2.0.0.306	This command was introduced.

Usage Guidelines

Example

```
ise/admin# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ise/admin(config)# interface GigabitEthernet 1
ise/admin(config-GigabitEthernet)# ipv6 address dhcp
ise/admin(config-GigabitEthernet)# end
ise/admin#
```

When IPv6 DHCP is enabled, the running configuration shows the interface settings similar to the following:

```
!
interface GigabitEthernet 1
  ipv6 address dhcp
  ipv6 enable
!
```



Note The IPv6 stateless autoconfiguration and IPv6 address DHCP are not mutually exclusive. It is possible to have both IPv6 stateless autoconfiguration and IPv6 address DHCP on the same interface.

You can use the **show interface** command to display what IPv6 addresses are in use for a particular interface.

When both the IPv6 stateless autoconfiguration and IPv6 address DHCP are enabled, the running configuration shows the interface settings similar to the following:

```
!
interface GigabitEthernet 1
  ipv6 address dhcp
  ipv6 address autoconfig
  ipv6 enable
!
```


ipv6 enable

To enable IPv6 on an interface, use the **ipv6 enable** command in interface configuration mode.

ipv6 enable

Use the **no** form of this command to disable ipv6 on an interface.

no ipv6 enable

Command Default	No default behavior or values.	
Command Modes	Interface configuration (config-GigabitEthernet)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.
Usage Guidelines	Use the ipv6 enable command to enable IPv6 on an interface and automatically generate the link-local address based on the interface MAC address.	

Example 1

```
ise/admin(config)# interface GigabitEthernet 1
ise/admin(config-GigabitEthernet)# ipv6 enable
ise/admin(config-GigabitEthernet)#
```

Example 2

By default, ipv6 is enabled on all interfaces. If you want to disable it, use the **no** form of this command.

```
ise/admin# show interface gigabitEthernet 1
GigabitEthernet 1
flags=4163UP,BROADCAST,RUNNING,MULTICAST mtu 1500
inet6 fe80::20c:29ff:fe83:a610 prefixlen 64 scopeid 0x20 link
ether 00:0c:29:83:a6:10 txqueuelen 1000 (Ethernet)
RX packets 11766 bytes 1327285 (1.2 MiB)
RX errors 0 dropped 13365 overruns 0 frame 0
TX packets 6 bytes 508 (508.0 B)
TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
```

```
ise/admin# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ise/admin(config)# interface gigabitEthernet 1
ise/admin(config-GigabitEthernet)# no ipv6 enable
ise/admin(config-GigabitEthernet)# exit
ise/admin(config)# end
ise/admin# show interface gigabitEthernet 1
GigabitEthernet 1
flags=4163 UP,BROADCAST,RUNNING,MULTICAST mtu 1500
ether 00:0c:29:83:a6:10 txqueuelen 1000 (Ethernet)
RX packets 64 bytes 5247 (5.1 KiB)
RX errors 0 dropped 13365 overruns 0 frame 0
TX packets 3 bytes 258 (258.0 B)
TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
```

 `ipv6 enable`

ipv6 route

To manually configure IPv6 static routes and define an explicit path between two networking devices, use the **ipv6 route** command in global configuration mode. Static routes are not automatically updated and you must manually reconfigure the static routes if the network topology changes.

ipv6 route *ipv6-address/prefix-length gateway route-specific gateway*

To remove an IPv6 static route, use the **no** form of this command.

no ipv6 route *ipv6-address/prefix-length gateway route-specific gateway*

To configure a default static route with an IPv6 address, use the **ipv6 route ::0 gateway route-specific gateway** command in global configuration mode. To disable the default static route with an IPv6 address, use the **no** form of this command.

Syntax Description	<i>ipv6-address</i>	IPv6 address.
	<i>prefix-length</i>	The length of the IPv6 prefix. A decimal value between 0 and 128 that indicates how many of the high-order contiguous bits of the address comprise the network portion of the address (the network portion of the address). A slash mark must precede the decimal value.
	<i>route-specific gateway</i>	IPv6 address of the next hop that can be used to reach that network.
Command Default	No default behavior or values.	
Command Modes	Global configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.
Usage Guidelines	Supported IPv6 address formats include:	

- Full notation: Eight groups of four hexadecimal digits separated by colons. For example, 2001:0db8:85a3:0000:0000:8a2e:0370:7334
- Shortened notation: Exclude leading zeros in a group; replace groups of zeros with two consecutive colons. For example: 2001:db8:85a3::8a2e:370:7334
- Dotted-quad notation (IPv4-mapped and IPv4-compatible IPv6 addresses): For example, ::ffff:192.0.2.128

Use the **show ipv6 route** command to view the configured IPv6 routes.

Example 1

```
ise/admin(config)# ipv6 route 2001:DB8:cc00:1::/64 gateway 2001:DB8::cc00:1::1
```

Example 2

```
ise/admin(config)# ipv6 route ::/0 gateway 2001:db::5
```

where ::/0 indicates a default route prefix.

kron occurrence

To schedule one or more Command Scheduler commands to run at a specific date and time or a recurring level, use the **kron occurrence** command in configuration mode. To delete this schedule, use the **no** form of this command.

kron occurrence *occurrence-name*

Syntax Description	occurrence	Schedules Command Scheduler commands.
	<i>occurrence-name</i>	Name of the occurrence. Supports up to 80 alphanumeric characters. (See the following note and Syntax Description.)



Note After you enter the *occurrence-name* in the **kron occurrence** command, you enter the config-Occurrence configuration submode (see the following Syntax Description).

Syntax Description	at	Identifies that the occurrence is to run at a specified calendar date and time. Usage: at [<i>hh:mm</i>] [<i>day-of-week</i> <i>day-of-month</i> <i>month day-of-month</i>].
	do	EXEC command. Allows you to perform any EXEC commands in this mode.
	end	Exits the kron-occurrence configuration submode and returns you to EXEC mode.
	exit	Exits the kron-occurrence configuration mode.
	no	Negates the command in this mode. Three keywords are available: <ul style="list-style-type: none"> • at—Usage: at [<i>hh:mm</i>] [<i>day-of-week</i> <i>day-of-month</i> <i>month day-of-month</i>]. • policy-list—Specifies a policy list to be run by the occurrence. Supports up to 80 alphanumeric characters. • recurring—Execution of the policy lists should be repeated.
	policy-list	Specifies a Command Scheduler policy list to be run by the occurrence.
	recurring	Identifies that the occurrences run on a recurring basis.
	Note	If kron occurrence is not recurring, then the kron occurrence configuration for the scheduled backup is removed after it is executed.

Command Default No default behavior or values.

Command Modes Configuration (config-Occurance)#

Command History**Release****Modification**

2.0.0.306

This command was introduced.

Usage Guidelines

Use the **kron occurrence** and **policy-list** commands to schedule one or more policy lists to run at the same time or interval.

Use the **kron policy-list** command in conjunction with the **cli** command to create a Command Scheduler policy that contains the EXEC CLI commands to be scheduled to run in the Cisco ISE server at a specified time.

**Note**

When you run the **kron** command, backup bundles are created with a unique name (by adding a time stamp) to ensure that the files do not overwrite each other.

**Note**

It is recommended that you schedule configuration or monitoring backups through the GUI by using the **Administration > System > Backup and Restore** page.

Example 1: Weekly Backup

```
ise/admin(config)# kron occurrence WeeklyBackup
ise/admin(config-Occurrence)# at 14:35 Monday
ise/admin(config-Occurrence)# policy-list SchedBackupPolicy
ise/admin(config-Occurrence)# recurring
ise/admin(config-Occurrence)# exit
ise/admin(config)#
```

Example 2: Daily Backup

```
ise/admin(config)# kron occurrence DailyBackup
ise/admin(config-Occurrence)# at 02:00
ise/admin(config-Occurrence)# exit
ise/admin(config)#
```

Example 3: Weekly Backup

```
ise/admin(config)# kron occurrence WeeklyBackup
ise/admin(config-Occurrence)# at 14:35 Monday
ise/admin(config-Occurrence)# policy-list SchedBackupPolicy
ise/admin(config-Occurrence)# no recurring
ise/admin(config-Occurrence)# exit
ise/admin(config)#
```

kron policy-list

To specify a name for a Command Scheduler policy and enter the kron-Policy List configuration submode, use the **kron policy-list** command in configuration mode. To delete a Command Scheduler policy, use the **no** form of this command.

kron policy-list *list-name*

Syntax Description	policy-list	Specifies a name for Command Scheduler policies.
	<i>list-name</i>	Name of the policy list. Supports up to 80 alphanumeric characters.



Note After you enter the list-name in the **kron policy-list** command, you enter the config-Policy List configuration submode (see the following Syntax Description).

Syntax Description	cli	Command to be executed by the scheduler. Supports up to 80 alphanumeric characters.
	do	EXEC command. Allows you to perform any EXEC commands in this mode.
	end	Exits from the config-Policy List configuration submode and returns you to configuration mode.
	exit	Exits this submode.
	no	Negates the command in this mode. One keyword is available: <ul style="list-style-type: none"> cli—Command to be executed by the scheduler.

Command Default No default behavior or values.

Command Modes Configuration (config-Policy List)#

Command History	Release	Modification
	2.0.0.306	This command was introduced.

Usage Guidelines Use the **kron policy-list** command in conjunction with the **cli** command to create a Command Scheduler policy that contains the EXEC CLI commands to be scheduled to run on the ISE server at a specified time. Use the **kron occurrence** and **policy list** commands to schedule one or more policy lists to run at the same time or interval.



Note You cannot use the **kron policy-list** command to schedule configuration and operational data backups from the CLI. You can schedule these backups from the Cisco ISE Admin portal.

Example

```
ise/admin(config)# kron policy-list BackupLogs
ise/admin(config-Policy List)# cli backup-logs ScheduledBackupLogs repository SchedBackupRepo
encryption-key plain xyzabc
ise/admin(config-Policy List)# exit
ise/admin(config)#
```


logging

To configure the log level, use the **logging** command in configuration mode.

logging loglevel {0 | 1 | 2 | 3 | 4 | 5 | 6 | 7}

To disable this function, use the **no** form of this command.

no logging

Syntax Description	<table><tr><th>loglevel</th><td>The command to configure the log level for the logging command.</td></tr><tr><td>0-7</td><td><div>The desired priority level to set the log messages. Priority levels are (en number for the keyword):</div><ul style="list-style-type: none">• 0-emerg—Emergencies: System unusable.• 1-alert—Alerts: Immediate action needed.• 2-crit—Critical: Critical conditions.• 3-err—Error: Error conditions.• 4-warn—Warning: Warning conditions.• 5-notif—Notifications: Normal but significant conditions.• 6-inform—(Default) Informational messages.• 7-debug—Debugging messages.</td></tr></table>	loglevel	The command to configure the log level for the logging command.	0-7	<div>The desired priority level to set the log messages. Priority levels are (en number for the keyword):</div> <ul style="list-style-type: none">• 0-emerg—Emergencies: System unusable.• 1-alert—Alerts: Immediate action needed.• 2-crit—Critical: Critical conditions.• 3-err—Error: Error conditions.• 4-warn—Warning: Warning conditions.• 5-notif—Notifications: Normal but significant conditions.• 6-inform—(Default) Informational messages.• 7-debug—Debugging messages.
loglevel	The command to configure the log level for the logging command.				
0-7	<div>The desired priority level to set the log messages. Priority levels are (en number for the keyword):</div> <ul style="list-style-type: none">• 0-emerg—Emergencies: System unusable.• 1-alert—Alerts: Immediate action needed.• 2-crit—Critical: Critical conditions.• 3-err—Error: Error conditions.• 4-warn—Warning: Warning conditions.• 5-notif—Notifications: Normal but significant conditions.• 6-inform—(Default) Informational messages.• 7-debug—Debugging messages.				
Command Default	No default behavior or values.				
Command Modes	Configuration (config)#				
Command History	Release	Modification			
	2.0.0.306	This command was introduced.			
Usage Guidelines	<p>This command requires the loglevel keyword.</p> <p>Example</p> <pre>ise/admin(config)# logging loglevel 0 ise/admin(config)#</pre>				

ntp

To specify an NTP configuration, use the **ntp** command in configuration mode with **authentication-key**, **maxdistance**, and **server** commands.

ntp authentication-key <key id> <authentication key encryption type> **hash** | **plain** <key value>

ntp maxdistance <maximum distance>

ntp reselectdistance <reselect distance>

ntp server {ip-address | hostname} key <peer key number>

no ntp server

Syntax Description

authentication-key	Specifies authentication keys for trusted time sources.
maxdistance	Maximum allowed root distance of the sources to not be rejected. By default, maximum root distance configured in Cisco ISE is 16 seconds.
reselectdistance	Fixed distance for sources that are currently not selected. By default, the distance is 100 microseconds.
server	Specifies NTP server to use.

Command Default

None

Command Modes

Configuration (config)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

Use the **ntp** command to specify an NTP configuration.

To terminate NTP service on a device, you must enter the **no ntp** command with keywords or arguments such as **authentication-key**, **maxdistance** and **server**. For example, if you previously issued the **ntp server** command, use the **no ntp** command with **server**.

Example

```
ise/admin(config)# ntp ?
  authentication-key  Authentication key for trusted time sources
  maxdistance        Maximum allowed root distance of the sources to not be rejected
  reselectdistance    Fixed distance for sources that are currently not selected
  server             Specify NTP server to use
ise/admin(config)#
ise/admin(config)# no ntp server
ise/admin(config)# do show ntp
% no NTP servers configured
ise/admin(config)#
```

```
ise/admin(config)# ntp reselectdistance ?
```

```
<1-10000000> Reselect distance in microseconds  
ise/admin(config)# ntp reselectdistance 3000
```

ntp authentication-key

To specify an authentication key for a time source, use the **ntp authentication-key** command in configuration command with a unique identifier and a key value.

ntp authentication-key <key id> **md5 hash** | **plain** key value

ntp authentication-key <key id> **sha1 hash** | **plain** key value

ntp authentication-key <key id> **sha256 hash** | **plain** key value

ntp authentication-key <key id> **sha512 hash** | **plain** key value

To disable this capability, use the **no** form of this command.

no ntp authentication-key

Syntax Description

authentication-key	Configures authentication keys for trusted time sources.
<i>key id</i>	The identifier that you want to assign to this key. Supports numeric values 1–65535.
md5	The encryption type for the authentication key.
sha1	The encryption type for the authentication key.
sha256	The encryption type for the authentication key.
sha512	The encryption type for the authentication key.
hash	Hashed key for authentication. Specifies an encrypted (hashed) key that follows the encryption type. Supports up to 4112 length.
plain	Plaintext key for authentication. Specifies an unencrypted plaintext key that follows the encryption type. Supports up to 1028 length.
<i>key value</i>	The key value in the format matching either <authentication key encryption type> plain hash , above. Note Hex key value can be added with the prefix HEX: .

Command Default

None

Command Modes

Configuration (config)#.

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

Use the **ntp authentication-key** command to set up a time source with an authentication key for NTP authentication and specify its pertinent key identifier, key encryption type, and key value settings. Add this key to the trusted list before you add this key to the **ntp server** command.

Time sources without the NTP authentication keys that are added to the trusted list will not be synchronized.



Note The **show running-config** command will always show keys that are entered in Message Digest 5 (MD5) plain format converted into hash format for security. For example, **ntp authentication-key 1 md5 hash ee18afc7608ac7ecdbefc5351ad118bc9ce1ef3**.

Example 1

```
ise/admin# configure
ise/admin(config)#
ise/admin(config)# ntp authentication-key 1 ?
  md5      MD5 authentication
  sha1     SHA1 authentication
  sha256   SHA256 authentication
  sha512   SHA512 authentication
```

Example 2

```
ise/admin# configure
ise/admin(config)#
ise/admin(config)# ntp authentication-key 1 sha1 plain ?
  <WORD> Plain text or hexadecimal number with the HEX: prefix key for a (Max Size - 1028)
```

Example 3

```
ise/admin(config)# no ntp authentication-key 3
(Removes authentication key 3.)
```

Example 4

```
ise/admin(config)# no ntp authentication-key
(Removes all authentication keys.)
```

ntp maxdistance

The **ntp maxdistance** command sets the maximum allowed root distance of the sources to not be rejected by the source selection algorithm. The distance includes the accumulated dispersion, which might be large when the source is no longer synchronised, and half of the total round-trip delay to the primary source.

By default, the maximum root distance configured in Cisco ISE is 16 seconds.

To reset to the default value, use the **no** form of this command.

ntp maxdistance

Syntax Description	maxdistance	Maximum allowed root distance of the sources to not be rejected.
Command Default	None	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.
Usage Guidelines	Setting maxdistance to a larger value can be useful to allow synchronisation with a server that only has a very infrequent connection to its sources and can accumulate a large dispersion between updates of its clock.	

Example

```
ise/admin(config)# ntp maxdistance ?
<1-128>
```

ntp server

To allow for software clock synchronization by the NTP server for the system, use the **ntp server** command in configuration mode. Allows up to three servers each with a key in a separate line. The key is an optional parameter but the key is required for NTP authentication.

The Cisco ISE always requires a valid and reachable NTP server.

Although key is an optional parameter, it must be configured if you need to authenticate an NTP server.

To disable this capability, use the **no** form of this command only when you want to remove an NTP server and add another one.

ntp server {*ip-address* | *hostname*} **minpoll** <*minimum poll*> **key**<*peer key number*>

ntp server {*ip-address* | *hostname*} **trust**

Syntax Description

server	Allows the system to synchronize with a specified server.
<i>ip-address</i> <i>hostname</i>	IPv4 or IPv6 address or hostname of the server providing the clock synchronization. Arguments are limited to 255 alphanumeric characters that the ISE eth0 interface is statically configured with an IPv6 address want to add an NTP server with an IPv6 address.
<i>key</i>	(Optional). Peer key number. Supports up to 65535 numeric characters. This key needs to be defined with a key value, by using the ntp authentication-key command. For authentication to work, the key and the key value should be the same which is defined on the actual NTP server.
minpoll	Minimum interval between requests sent to the server as a power of 2 in seconds. For example, minpoll 5 would mean that the polling interval should not be below 32 seconds. The default is 6 (64 seconds), the minimum is -6 (1/6 second), and the maximum is 24 (6 months).
trust	Assume time from this source is always true.



Note *key* and **minpoll** options can be interchanged.

Command Default

No servers are configured by default.

Command Modes

Configuration (config)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

The **show ntp** command displays the status of synchronization. If none of the configured NTP servers are reachable or not authenticated (if NTP authentication is configured), then this command displays synchronization to local with the least stratum.

If an NTP server is not reachable or is not properly authenticated, then its reach as per this command statistics will be 0.



Note This command gives conflicting information during the synchronization process. The synchronization process can take up to 20 minutes to complete.

Example

```
ise/admin# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ise/admin(config)# ntp server 209.165.200.225 ?
    key                Peer key number
    minpoll             Minimum interval between requests sent to the server
    trust               Assume time from this source is always true

ise/admin# show running-config
interface GigabitEthernet 0
 ip address 209.165.200.225 255.255.255.0
 ipv6 address autoconfig
 ipv6 enable
!
ip name-server 209.165.200.226
!
ip default-gateway 209.165.200.227
!
ip route 2.2.2.0 255.255.255.0 gateway 127.0.0.1
!
!
clock timezone Asia/Kolkata
!
ntp authentication-key nn md5 hash xxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxxx

ntp server 209.165.200.228 key nn
ntp server 209.165.200.229
!

ise/admin(config)# ntp server 209.165.200.225 trust
ise/admin(config)# ntp server 209.165.200.225 key 2 trust
ise/admin(config)# ntp server 209.165.200.225 key 2 minpoll 7 trust
ise/admin(config)# ntp server 209.165.200.225 minpoll 7 trust
ise/admin(config)# ntp server 209.165.200.225 minpoll 7 key 2 trust
```

Verifying the Status of Synchronization

To check the status of synchronization, use the **show ntp** command.

Example 1

```
ise/admin# show ntp
Primary NTP   : ntp.esl.cisco.com
Secondary NTP : 171.68.10.80
```



```

Tertiary NTP : 171.68.10.150
synchronised to local net at stratum 11
  time correct to within 448 ms
  polling server every 64 s
    remote      refid      st t when poll reach  delay  offset  jitter
=====
*127.127.1.0    .LOCL.             10 l  46  64  37   0.000   0.000   0.001
 171.68.10.80   .RMOT.             16 u  46  64   0   0.000   0.000   0.000
 171.68.10.150  .INIT.             16 u  47  64   0   0.000   0.000   0.000
Warning: Output results may conflict during periods of changing synchronization.
ise/admin#

```

Example 2

```

ise/admin# show ntp
Primary NTP   : ntp.esl.cisco.com
Secondary NTP : 171.68.10.150
Tertiary NTP  : 171.68.10.80
synchronised to NTP server (171.68.10.150) at stratum 3
  time correct to within 16 ms
  polling server every 64 s
    remote      refid      st t when poll reach  delay  offset  jitter
=====
 127.127.1.0    .LOCL.             10 l   35  64  377   0.000   0.000   0.001
+171.68.10.80   144.254.15.122     2 u   36  64  377   1.474   7.381   2.095
*171.68.10.150  144.254.15.122     2 u   33  64  377   0.922  10.485   2.198
Warning: Output results may conflict during periods of changing synchronization.
ise/admin#

```

rate-limit

To configure the limit of TCP, UDP, or ICMP packets from a source IP address, use the **rate-limit** command in configuration mode. To remove this function, use the **no** form of this command.

rate-limit 250 ip-address net-mask port

Syntax Description	<1-10000>	An average number of TCP, UDP, or ICMP packets per second.
	ip-address	The source IP address to which the packet rate limit must be applied. Enter <i>ip</i> for IPv4 addresses and ipv6 for IPv6 addresses.
	<i>ip</i>	
	or	
	<i>ipv6</i>	
	net-mask	The source IP mask to which the packet rate limit must be applied.
	port	The destination port number to which the packet rate limit must be applied.

Command Default No default behavior or values.

Command Modes Configuration (config)#

Command History	Release	Modification
	2.0.0.306	This command was introduced.

Usage Guidelines The actual rate limit that is set may differ from the number that you have configured due to the design of the netfilter hashtable. The following is a list of how netfilter rounds off rate limit values, at the time of writing this document:

- For limit values from 5001/s to 10000/s, Netfilter rounds up the value to 10000/s.
- For limit values from 3334/s to 5000/s, Netfilter rounds up the value to 5000/s.
- For limit values from 2501/s to 3333/s, Netfilter rounds up the value to 3333/s.
- For limit values from 2001/s to 2500/s, Netfilter rounds up the value to 2500/s.
- For limit values from 1667/s to 2000/s, Netfilter rounds up the value to 2000/s.
- For limit values from 1429/s to 1666/s, Netfilter rounds up the value to 1666/s.
- For limit values from 1251/s to 1428/s, Netfilter rounds up the value to 1428/s.
- For limit values from 1112/s to 1250/s, Netfilter rounds up the value to 1250/s.
- For limit values from 1001/s to 1111/s, Netfilter rounds up the value to 1111/s.
- For limit values from 910/s to 1000/s, Netfilter rounds up the value to 1000/s.
- For limit values from 834/s to 909/s, Netfilter rounds up the value to 909/s.

- For limit values under 150, no rounding is done.

See netfilter documentation for more details on how hashlimits work.

Example

```
ise49/admin(config)# rate-limit 4000 ip 20.20.20.20 port 443
% Notice : Actual rate limit rounded up by iptables to 5000 per second
ise49/admin(config)# do show running-config | incl rate
rate-limit 5000 ip 20.20.20.20 port 443
ise49/admin(config)#
ise49/admin(config)# rate-limit 6000 ip 10.10.10.10 port 443
% Notice : Actual rate limit rounded up by iptables to 10000 per second
ise49/admin(config)# do show running-config | incl rate
rate-limit 10000 ip 10.10.10.10 port 443
rate-limit 5000 ip 20.20.20.20 port 443
ise49/admin(config)#
```

password-policy



Note You can also configure the password policy from the Cisco ISE GUI. Note that if a password policy is configured through the Cisco ISE GUI, it overwrites and takes precedence over any password policy configured through the Cisco ISE CLI.

To enable or configure the passwords on the system, use the **password-policy** command in configuration mode. To disable this function, use the **no** form of this command.

password-policy options



Note The **password-policy** command requires a policy option (see Syntax Description). You must enter the **password-expiration-enabled** command before the other password-expiration commands.



Note After you enter the **password-policy** command, you can enter the config-password-policy configuration submode.

Syntax Description

<i>digit-required</i>	Requires a digit in user passwords.
<i>disable-cisco-password</i>	Disables the ability to use the word Cisco or any combination as the password.
<i>disable-repeat-chars</i>	Disables the ability of the password to contain more than four identical characters.
<i>do</i>	Exec command.
<i>end</i>	Exit from configure mode.
<i>exit</i>	Exit from this submode.
<i>lower-case-required</i>	Requires a lowercase letter in user passwords.
<i>min-password-length</i>	Minimum number of characters for a valid password. Supports up to 40 characters.
<i>no</i>	Negate a command or set its defaults.
<i>no-previous-password</i>	Prevents users from reusing a part of their previous password.
<i>no-username</i>	Prohibits users from reusing their username as a part of a password.
<i>password-delta</i>	Number of characters to be different from the old password.
<i>password-expiration-days</i>	Number of days until a password expires. Supports an integer up to 3650.

<i>password-expiration-enabled</i>	Enables password expiration. Note You must enter the password-expiration-enabled command before the other password-expiration commands.
<i>password-expiration-warning</i>	Number of days before expiration that warnings of impending expiration. Supports an integer up to 3650.
<i>password-lock-enabled</i>	Locks a password after several failures.
<i>password-lock-retry-count</i>	Number of failed attempts before user password locks. Supports an integer up to 20.
<i>password-lock-timeout</i>	Sets the time in minutes after which the account lockout is cleared. Supports values from 5 minutes to 1440 minutes.
<i>special-required</i>	Requires a special character in user passwords.
<i>upper-case-required</i>	Requires an uppercase letter in user passwords.

Command Default No default behavior or values.

Command Modes Configuration (config-password-policy)#

Command History	Release	Modification
	2.0.0.306	This command was introduced.

Usage Guidelines None.

Example

```
ise/admin(config)# password-policy
ise/admin(config-password-policy)# password-expiration-days 30
ise/admin(config-password-policy)# exit
ise/admin(config)#
```

repository

To enter the repository submode for configuration of backups, use the **repository** command in configuration mode.

repository *repository-name*

Syntax Description	<i>repository-name</i>	Name of repository. Supports up to 80 alphanumeric characters.
--------------------	------------------------	--



Note After you enter the name of the repository in the **repository** command, you enter the config-Repository configuration submode (see the Syntax Description).

Syntax Description	do	EXEC command. Allows you to perform any of the EXEC commands in the mode.
	end	Exits the config-Repository submode and returns you to EXEC mode.
	exit	Exits this mode.
	no	Negates the command in this mode. Two keywords are available: <ul style="list-style-type: none"> • url—Repository URL. • user—Repository username and password for access.
	url	URL of the repository. Supports up to 300 alphanumeric characters (see Table 4-5).
	user	Configure the username and password for access. Supports up to 30 alphanumeric characters for username and supports 15 alphanumeric characters for password. Passwords can consist of the following characters: 0 through 9, a through z, A through Z, -, ., , @, #, \$, %, ^, &, *, (,), +, and =.



Note Server is the server name and path refers to /subdir/subsubdir. Remember that a colon(:) is required after the server for an NFS network server.

Table 5: Table 4-5 URL Keywords (Continued)

Keyword	Source of Destination
URL	Enter the repository URL, including server and path information. Supports up to 300 alphanumeric characters.
cdrom:	Local CD-ROM drive (read only).

Keyword	Source of Destination
disk:	<p>Local storage.</p> <p>You can run the show repository repository_name to view all files in the repository.</p> <p>Note All local repositories are created on the /localdisk partition. If you specify disk:// in the repository URL, the system creates directories in a path that is relative to /localdisk. For example, if you entered disk://backup, the directory is created at /localdisk/backup.</p>
ftp:	Source or destination URL for an FTP network server. Use url ftp://serv
http:	Source or destination URL for an HTTP network server (read only).
https:	Source or destination URL for an HTTPS network server (read only).
nfs:	Source or destination URL for an NFS network server. Use url nfs://serv
sftp:	Source or destination URL for an SFTP network server. Use url sftp://serv
tftp:	<p>Source or destination URL for a TFTP network server. Use url tftp://serv</p> <p>Note You cannot use a TFTP repository for performing a Cisco ISE upgrade.</p>

Command Default No default behavior or values.

Command Modes Configuration (config-Repository)#

Command History	Release	Modification
	2.0.0.306	This command was introduced.

Usage Guidelines When configuring **url sftp:** in the submode, you must first load the RSA fingerprint (AKA host-key) from the target SFTP host into ISE. You can do this by using the **crypto host_key add** command through the CLI. See the [crypto](#) command for more information.

To disable this function, use the command **crypto host_key delete** in the EXEC mode.

Cisco ISE displays the following warning when you configure a secure ftp repository in the Cisco ISE Admin portal in Administration > System > Maintenance > Repository > Add Repository.

The host key of the SFTP server must be added through the CLI by using the host-key option before this repository can be used.

A corresponding error is thrown in the Cisco ADE logs when you try to back up into a secure FTP repository without configuring the host-key.

**Note**

Cisco ISE initiates outbound SSH or SFTP connections in FIPS mode even if FIPS mode is not enabled on ISE. Ensure that the remote SSH or SFTP servers that communicate with ISE allow FIPS 140-2 approved cryptographic algorithms.

Cisco ISE uses embedded FIPS 140-2 validated cryptographic modules. For details of the FIPS compliance claims, see the [FIPS Compliance Letter](#).

service

To specify a service to manage, use the **service** command in configuration mode.

service sshd

To disable this function, use the **no** form of this command.

no service

Syntax	Description				
sshd	Secure Shell Daemon. The daemon program for SSH.				
enable	Enables sshd service.				
encryption-algorithm	Configures SSH encryption algorithms. The supported algorithms are aes128-cbc, aes128-ctr, aes256-cbc, and aes256-ctr.				
encryption-mode	Configures SSH encryption mode on system. The supported modes are ctr.				
key-exchange-algorithm	Specifies allowable key exchange algorithms for sshd service.				
diffie-hellman-group14-sha1	Restricts key exchange algorithm to diffie-hellman-group14-sha1				
Loglevel	Specifies the log level of messages from sshd to secure system log. <ul style="list-style-type: none"> • 1—QUIET • 2—FATAL • 3—ERROR • 4—INFO (default) • 5—VERBOSE • 6—DEBUG • 7—DEBUG1 • 8—DEBUG2 • 9—DEBUG3 				
Command Default	No default behavior or values.				
Command Modes	Configuration (config)#				
Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>2.0.0.306</td><td>This command was introduced.</td></tr> </table>	Release	Modification	2.0.0.306	This command was introduced.
Release	Modification				
2.0.0.306	This command was introduced.				
Usage Guidelines	None.				

Example

```
ise/admin(config)# service sshd
ise/admin(config)# service sshd enable
ise/admin(config)# service sshd encryption-algorithm
Configure aes128-cbc algo
Configure aes128-ctr algo
Configure aes256-cbc algo
Configure aes256-ctr algo
ise/admin(config)# service sshd encryption-mode
Configure cbc cipher suites
Configure ctr cipher suites
ise/admin(config)# service sshd key-exchange-algorithm diffie-hellman-group14-sha1
ise/admin(config)# service sshd loglevel 4
ise/admin(config)#
```

```
ise/admin(config)# service sshd
ise/admin(config)# service sshd enable
ise/admin(config)# service sshd encryption-algorithm
Configure aes128-cbc algo
Configure aes128-ctr algo
Configure aes256-cbc algo
Configure aes256-ctr algo
ise/admin(config)# service sshd encryption-mode
Configure cbc cipher suites
Configure ctr cipher suites
ise/admin(config)# service sshd key-exchange-algorithm diffie-hellman-group14-sha1
ise/admin(config)# service sshd loglevel 4
ise/admin(config)#
```

shutdown

To shut down an interface, use the **shutdown** command in the interface configuration mode. To disable this function, use the **no** form of this command.

This command has no keywords and arguments.

Command Default

No default behavior or values.

Command Modes

Configuration (config-GigabitEthernet)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

When you shut down an interface using this command, you lose connectivity to the Cisco ISE appliance through that interface (even though the appliance is still powered on).

However, if you have configured the second interface on the appliance with a different IP and have not shut down that interface, you can access the appliance through that second interface.

To shut down an interface, you can also modify the ifcfg-eth[0,1] file, which is located at /etc/sysconfig/network-scripts, using the ONBOOT parameter:

- Disable an interface: set ONBOOT="no"
- Enable an interface: set ONBOOT="yes"

You can also use the **no shutdown** command to enable an interface.

Example

```
ise/admin(config)# interface GigabitEthernet 0
ise/admin(config-GigabitEthernet)# shutdown
```

snmp-server enable

To enable the SNMP server on Cisco ISE, use the **snmp-server enable** command in global configuration mode.

snmp-server enable

To disable the SNMP server, use the **no** form of this command.

Command Default

The SNMP server is enabled.

Command Modes

Configuration (config)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Example

```
ise/admin(config)# snmp-server enable
ise/admin(config)#
```

MIBs

The SNMP agent on the Cisco ISE provides read-only access to the following MIBs for all versions of SNMP:

- SNMPv2-MIB
- RFC1213-MIB
- IF-MIB
- IP-MIB
- IP-FORWARD-MIB
- TCP-MIB
- UDP-MIB
- HOST-RESOURCES-MIB
- ENTITY-MIB-Only 3 MIB variables are supported on the ENTITY-MIB:
 - Product ID: entPhysicalModelName
 - Version ID: entPhysicalHardwareRev
 - Serial Number: entPhysicalSerialNumber
- DISMAN-EVENT-MIB
- NOTIFICATION-LOG-MIB
- CISCO-CDP-MIB

You can query for the system object identifiers for SNS devices. The system object identifier for ISE 3315 is the default value displayed if a new device series has been introduced but is not updated in Cisco ISE release and patch releases.

For example:

```
ise/admin(config)# snmpwalk -v 2c -c snmpV2cCommunityString iseFQDN-or-IP
SNMPv2-MIB::sysObjectID.0SNMPv2-MIB::sysObjectID.0 = OID: SNMPv2-SMI::enterprises.9.1.1426
```

Appliances	SysObjID
ISE 3315	1.3.6.1.4.1.9.1.1423
ISE 3395	1.3.6.1.4.1.9.1.1424
ISE 3355	1.3.6.1.4.1.9.1.1425
SNS 3495	1.3.6.1.4.1.9.1.2139
SNS 3415	1.3.6.1.4.1.9.1.2140
SNS 3595	1.3.6.1.4.1.9.1.2266
SNS 3515	1.3.6.1.4.1.9.1.2265
SNS 3615	1.3.6.1.4.1.9.1.2784
SNS 3655	1.3.6.1.4.1.9.1.2785
SNS 3695	1.3.6.1.4.1.9.1.2786
SNS 3715	1.3.6.1.4.1.9.1.3270
SNS 3755	1.3.6.1.4.1.9.1.3271
SNS 3795	1.3.6.1.4.1.9.1.3272
VM	1.3.6.1.4.1.9.1.1426

snmp-server user

To configure a new SNMP user, use the **snmp-server user** command in global configuration mode.

snmp-server user *username* **v3** {**hash** | **plain**} *auth-password* *priv-password*

snmp-server user *username* **v3** **sha1** {**hash** | **plain**} *auth-password* *priv-password*

snmp-server user *username* **v3** **sha224** {**hash** | **plain**} *auth-password* *priv-password*

snmp-server user *username* **v3** **sha256** {**hash** | **plain**} *auth-password* *priv-password*

snmp-server user *username* **v3** **sha384** {**hash** | **plain**} *auth-password* *priv-password*

snmp-server user *username* **v3** **sha512** {**hash** | **plain**} *auth-password* *priv-password*



Note This command must be used only for SNMP version 3.

To remove a specified SNMP user, use the **no** form of this command.

Syntax Description

user	Configure a new user.
<i>username</i>	The name of the user on the host that belongs to the SNMP agent.
v3	Version of the SNMP used to send the traps. Specifies that the SNMP Version 3 security model should be used for enabling the priv and the auth keywords.
{ hash plain }	Password is in encrypted or plain format. Encrypted passwords must be in hexadecimal format.
<i>auth-password</i>	Specifies the authentication user password. The minimum length for a password is one character; however, we recommend that you use at least nine characters for security . To create a password with the hash symbol (#) or exclamation mark (!), you must first enter the backslash symbol (\), for example, abc\!23 , abc12\# , and so on.
Note	If you forget a password, you cannot recover it, and must reconfigure the user. You can specify a plain-text password or a localized digest. The localized digest must match the authentication algorithm selected for the user, which can be either MD5 or SHA. When the user configuration is displayed on the console or is written to a file (for example, the startup-configuration file), the localized authentication and privacy digests are always displayed instead of the plain-text password.

priv-password

Specifies the encryption user password. The minimum length for a password is one character; however, we recommend that you use at least eight characters for security.

To create a password with the hash symbol (#) or exclamation mark (!), you must first enter the backslash symbol (\), for example, **abc\!23**, **abc12\#**, and so on.

Note If you forget a password, you cannot recover it, and must reconfigure the user. You can specify a plain-text password or a localized digest. The localized digest must match the authentication algorithm selected for the user, which can be either MD5 or SHA. When the user configuration is displayed on the console or is written to the configuration (for example, the startup-configuration file), the localized authentication and privacy digests are always displayed instead of the plain-text password.

sha1	Sha1 authentication type.
sha224	Sha224 authentication type.
sha256	Sha256 authentication type.
sha384	Sha384 authentication type.
sha512	Sha512 authentication type.

Command Default

Disabled.

Command Modes

Configuration (config)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

After you configure users, make sure to configure SNMP Version 3 hosts. Along with the target IP address, you must configure a username, because traps are only sent to a configured user.

Example

```
ise/admin(config)# snmp-server user testuser v3 ?
hash      Hash Passwords
plain     Plain Passwords
sha1      Sha1 authentication
sha224    Sha224 authentication
sha256    Sha256 authentication
sha384    Sha384 authentication
sha512    Sha512 authentication
```

```
ise/admin(config)# snmp-server user testuser v3 hash authpassword privpassword
ise/admin(config)#
```

snmp-server host

To send SNMP traps to a recipient, use the **snmp-server host** command in configuration mode. By default, SNMP traps are enabled. By default, the UDP port is 162.



Note SNMP user needs to be created before using the `snmp-server host` command.

```
snmp-server host {ip-address | hostname} version {{1 | 2c} community | 3 username engine_ID {hash | plain} auth-password priv-password}
```

```
snmp-server host {ip-address | hostname} version {{1 | 2c} community | 3 username engine_ID sha1 {hash | plain} auth-password priv-password}
```

```
snmp-server host {ip-address | hostname} version {{1 | 2c} community | 3 username engine_ID sha224 {hash | plain} auth-password priv-password}
```

```
snmp-server host {ip-address | hostname} version {{1 | 2c} community | 3 username engine_ID sha256 {hash | plain} auth-password priv-password}
```

```
snmp-server host {ip-address | hostname} version {{1 | 2c} community | 3 username engine_ID sha384 {hash | plain} auth-password priv-password}
```

```
snmp-server host {ip-address | hostname} version {{1 | 2c} community | 3 username engine_ID sha512 {hash | plain} auth-password priv-password}
```

To remove trap forwarding, use the **no** form of this command.



Note When SNMP Version 3 hosts are configured in Cisco ISE, a user must be associated with that host because traps are sent only to a configured user. To receive traps, after you have added the **snmp-server host** command, you must configure the user credentials on the NMS with the same credentials as those configured in Cisco ISE.

Syntax Description

host	Configures hosts to receive SNMP notifications.
<i>ip-address</i>	IP address of the SNMP notification host. Supports up to 32 alphanumeric characters.
<i>hostname</i>	Name of the SNMP notification host. Supports up to 32 alphanumeric characters.
version {1 2c 3}	<p>(Optional). Version of the SNMP used to send the traps. Default = 1.</p> <p>If you use the version keyword, specify one of the following keywords:</p> <ul style="list-style-type: none"> 1—SNMPv1. 2c—SNMPv2C. 3—SNMP v3.

<i>community</i>	Specifies the shared secret key between Cisco ISE and the NMS. Case-sensitive value that can be up to 32 characters in length. Spaces are not allowed. The community-string is "public." Cisco ISE uses this key to determine whether an incoming SNMP request is valid.
<i>username</i>	(Optional; required only if you choose SNMP version 3) Associates a user with the host when SNMP Version 3 hosts are configured in Cisco ISE.
<i>engine_ID</i>	(Optional; required only if you choose SNMP version 3) Remote Engine ID.
<i>auth-password</i>	(Optional; required only if you choose SNMP version 3) Specifies the authentication user password.
<i>priv-password</i>	(Optional; required only if you choose SNMP version 3) Specifies the encryption user password.
sha1	Sha1 authentication type.
sha224	Sha224 authentication type.
sha256	Sha256 authentication type.
sha384	Sha384 authentication type.
sha512	Sha512 authentication type.

Command Default

Enabled.

Command Modes

Configuration (config)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

Cisco ISE sends a 'coldStart(0)' trap when the appliance boots up (reloads), if SNMP is already configured. Cisco ISE uses the Net-SNMP client that sends a 'coldStart(0)' trap when it first starts up, and an enterprise-specific trap 'nsNotifyShutdown' when it stops.

It generates an enterprise-specific trap 'nsNotifyRestart' (rather than the standard 'coldStart(0)' or 'warmStart(1)' traps) typically after you reconfigure SNMP using the **snmp-server host** command.

**Note**

If the SNMP trap target is specified by hostname or FQDN and resolved by DNS to both IPv4 and IPv6 addresses, ISE sends SNMP traps to IPv6 dual-stack target receivers through IPv4 and not through IPv6. To ensure that the traps are sent through IPv6, an ISE admin may either resolve hostname or FQDN only to IPv6 by DNS, or specify the IPv6 address directly, when configuring SNMP traps.

Examples

```
ise/admin(config)# snmp-server community new ro
```

snmp-server host

```
ise/admin(config)# snmp-server host 209.165.202.129 version 1 password
ise/admin(config)#
```

```
ise/admin(config)# snmp-server host isel version 2c public
ise/admin(config)# snmp-server community public ro
2012-09-24T18:37:59.263276+00:00 isel snmptrapd[29534]: isel.cisco.com [UDP:
[192.168.118.108]:44474]: Trap ,
DISMAN-EVENT-MIB::sysUpTimeInstance = Timeticks: (29) 0:00:00.29, SNMPv2-MIB::snmpTrapOID.0
= OID: SNMPv2-MIB::coldStart,
SNMPv2-MIB::snmpTrapEnterprise.0 = OID: NET-SNMP-MIB::netSnmpAgentOIDs.10
ise/admin(config)# snmp-server contact admin@cisco.com
2012-09-24T18:43:32.094128+00:00 isel snmptrapd[29534]: isel.cisco.com [UDP:
[192.168.118.108]:53816]: Trap ,
DISMAN-EVENT-MIB::sysUpTimeInstance = Timeticks: (33311) 0:05:33.11, SNMPv2-MIB::snmpTrapOID.0
= OID: NET-SNMP-AGENT-MIB::nsNotifyRestart, SNMPv2-MIB::snmpTrapEnterprise.0 = OID:
NET-SNMP-MIB::netSnmpNotificationPrefix
```

```
ise/admin(config)# snmp-server host a.b.c.d version 3 testuser 0x12439343 hash authpassword
privpassword
ise/admin(config)#
```

```
ise/admin(config)# snmp-server host a.b.c.d version 3 testuser 0x12439343 ?
hash    Hash Passwords
plain   Plain Passwords
sha1    Sha1 authentication
sha224  Sha224 authentication
sha256  Sha256 authentication
sha384  Sha384 authentication
sha512  Sha512 authentication
```

snmp-server community

To set up the community access string to permit access to the Simple Network Management Protocol (SNMP), use the **snmp-server community** command in configuration mode.

snmp-server community *community-string* **ro**

To disable this function, use the **no** form of this command.

no snmp-server

Syntax Description	community	Sets SNMP community string.
	community-string	Accessing string that functions much like a password and allows access to the community. No blank spaces allowed. Supports up to 255 alphanumeric characters.
	ro	Specifies read-only access.
Command Default	No default behavior or values.	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.
Usage Guidelines	The snmp-server community command requires a community string and the ro argument; otherwise, an error occurs.	
Example		
ise/admin(config)# snmp-server community new ro		
ise/admin(config)#		

snmp-server contact

To configure the SNMP contact Management Information Base (MIB) value on the system, use the **snmp-server contact** command in configuration mode. To remove the system contact information, use the **no** form of this command.

snmp-server contact *contact-name*

Syntax Description	contact	Identifies the contact person for this managed node. Supports up to 255 alphanumeric characters.
	<i>contact-name</i>	String that describes the system contact information of the node. Supports up to 255 alphanumeric characters.
Command Default	No default behavior or values.	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.
Usage Guidelines	None.	

Example

```
ise/admin(config)# snmp-server contact Luke
ise/admin(config)#
```

snmp-server location

To configure the SNMP location MIB value on the system, use the **snmp-server location** command in configuration mode. To remove the system location information, use the **no** form of this command.

snmp-server location *location*

Syntax Description	location	Configures the physical location of this managed node. Supports up to 255 alphanumeric characters.
	<i>location</i>	String that describes the physical location information of the system. Supports up to 255 alphanumeric characters.
Command Default	No default behavior or values.	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.
Usage Guidelines	Cisco recommends that you use underscores (_) or hyphens (-) between the terms within the <i>word</i> string. If you use spaces between terms within the <i>word</i> string, you must enclose the string in quotation marks ("").	

Example 1

```
ise/admin(config)# snmp-server location Building_3/Room_214
ise/admin(config)#
```

Example 2

```
ise/admin(config)# snmp-server location "Building 3/Room 214"
ise/admin(config)#
```

snmp-server trap dskThresholdLimit

To configure the SNMP server to receive traps if one of the Cisco ISE partitions reaches its threshold disk utilization limit, use the **snmp-server trap dskThresholdLimit** command in Configuration mode.

snmp-server trap dskThresholdLimit *value*

To stop sending disk threshold utilization limit traps, use the **no** form of this command.

Syntax Description	<i>value</i>	Number that represents the percentage of available disk space. The value ranges from 1 to 100.
Command Default	No default behavior or values.	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.1.0.474	This command was introduced.

Usage Guidelines

This configuration is common for all the partitions in Cisco ISE. If you configure the threshold limit as 40, then you will receive a trap as soon as a partition utilizes 60% of its disk space and only 40% of the disk space is available. That is, a trap is sent when the configured amount of free space is reached.

After you configure this command from the Cisco ISE CLI, a cron job runs every five minutes and monitors the Cisco ISE partitions one by one. If any one of the partitions reaches its threshold limit, then Cisco ISE sends a trap to the configured SNMP server with the disk path and the threshold limit value. Multiple traps are sent if multiple partitions reached the threshold limit. You can view the SNMP traps using the traps receiver in a MIB browser.

Example

```
ise/admin(config)# snmp-server trap dskThresholdLimit 40
ise/admin(config)#
```

snmp engineid

To change the existing engine ID to a new value, use the **snmp engineid command** in configuration mode. This command displays a warning that all existing users need to be re-created.

snmp engineid *engine_ID_string*

To remove the configured engine ID, use the **no** form of this command.

Syntax Description	engineid	Changes an existing engine ID to a new value that you specify.
	<i>engine_ID_string</i>	String of maximum 24 characters that identifies the engine ID.
Command Default	No command defaults.	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.

Example

```
ise/admin(config)# snmp engineid Abcdef129084B
% Warning: As a result of engineID change, all SNMP users will need
           to be recreated.
ise/admin(config)#
```

synflood-limit

To configure a TCP SYN packet rate limit.

synflood-limit ?

Syntax Description	synflood-limit	Average number of TCP SYN packets allowed per second.
	?	The valid range is from 1 to 2147483647.

Command Default No default behavior or values.

Command Modes Configuration (config)#

Command History	Release	Modification
	2.0.0.306	This command was introduced.

Usage Guidelines Use this **synflood-limit** to configure a TCP SYN packet rate limit.

The actual rate limit that is set may differ from the number that you have configured due to the design of the synflood limits. The following is a list of how limit values are rounded up, at the time of writing this document:

- For limit values from 5001/s to 10000/s, the value is rounded up to 10000/s.
- For limit values from 3334/s to 5000/s, the value is rounded up to 5000/s.
- For limit values from 2501/s to 3333/s, the value is rounded up to 3333/s.
- For limit values from 2001/s to 2500/s, the value is rounded up to 2500/s.
- For limit values from 1667/s to 2000/s, the value is rounded up to 2000/s.
- For limit values from 1429/s to 1666/s, the value is rounded up to 1666/s.
- For limit values from 1251/s to 1428/s, the value is rounded up to 1428/s.
- For limit values from 1112/s to 1250/s, the value is rounded up to 1250/s.
- For limit values from 1001/s to 1111/s, the value is rounded up to 1111/s.
- For limit values from 910/s to 1000/s, the value is rounded up to 1000/s.
- For limit values from 834/s to 909/s, the value is rounded up to 909/s.
- For limit values under 150, no rounding is done.

Example

```
ise49/admin(config)# synflood-limit 5099
ise49/admin(config)# do show running-config | include syn
synflood limit 10000
```


username

To add a user who can access the Cisco ISE appliance using SSH, use the **username** command in configuration mode. If the user already exists, the password, the privilege level, or both change with this command. To delete the user from the system, use the **no** form of this command.

username *username* **password** **hash** | **plain** {*password*} **role** **admin** | **user** **email** {*email-address*}

For an existing user, use the following command option:

username *username* **password** **role** **admin** | **user** {*password*}

Syntax Description

<i>username</i>	Only one word for the username argument. Blank spaces and quotation (“”) are not allowed. Supports up to 31 alphanumeric characters.
password	Specifies password.
<i>password</i>	Password character length up to 40 alphanumeric characters. You must use the password for all new users.
hash plain	Type of password. Supports up to 34 alphanumeric characters.
role admin user	Sets the user role and the privilege level for the user.
disabled	Disables the user according to the user’s email address.
email	Sets user’s email address.
<i>email-address</i>	Specifies the user’s email address. For example, user1@mydomain.com

Command Default

The initial user during setup.

Command Modes

Configuration (config)#

Command History

Release	Modification
2.0.0.306	This command was introduced.

Usage Guidelines

The **username** command requires that the username and password keywords precede the hash / plain and the admin / user options.

Example 1

```
ise/admin(config)# username admin password hash ##### role admin
ise/admin(config)#
```

Example 2

```
ise/admin(config)# username admin password plain Secr3tp@swd role admin
ise/admin(config)#
```

Example 3

```
ise/admin(config)# username admin password plain Secr3tp@swd role admin email  
admin123@mydomain.com  
ise/admin(config)#
```

which

To display the contents of commands available in admin CLI, use the **which** command in configuration mode.

which

Syntax Description	This command has no keywords and arguments.	
Command Default	No default behavior or values.	
Command Modes	Configuration (config)#	
Command History	Release	Modification
	2.0.0.306	This command was introduced.
Usage Guidelines	which is a hidden command. Although which is available in Cisco ISE, the CLI interactive Help does not display it if you attempt to view it by entering a question mark at the command line.	

Example

The following example shows the output of **which** :

```
ise/admin(config)# which
[  1]. application  configure<STRING>
[  2]. application  install<STRING><STRING>
[  3]. application  remove<STRING>
[  4]. application  reset-config<STRING>
[  5]. application  reset-passwd<STRING><STRING>
[  6]. application  start<STRING>
[  7]. application  start<STRING>  safe
[  8]. application  stop<STRING>
[  9]. application  upgrade  cleanup
[ 10]. application  upgrade  prepare<STRING><STRING>
```

■ which