



CHAPTER 4

Configuring Call Home

Call Home provides an e-mail-based notification of critical system events. A versatile range of message formats are available for optimal compatibility with pager services, standard e-mail, or XML-based automated parsing applications.



Note

Cisco Autonotify is upgraded to a new capability called Smart Call Home. Smart Call Home has significant functionality improvement over Autonotify and is available across the Cisco product range. For detailed information on Smart Call Home, see the Smart Call Home page at this location: <http://www.cisco.com/go/smartcall/>

This chapter includes the following sections:

- [Information About Call Home, page 4-1](#)
- [Guidelines and Limitations, page 4-21](#)
- [Default Settings, page 4-22](#)
- [Configuring Call Home, page 4-22](#)
- [Verifying Call Home Configuration, page 4-37](#)
- [Monitoring Call Home, page 4-40](#)
- [Additional References, page 4-45](#)
- [Feature History for Call Home, page 4-46](#)

Information About Call Home

The Call Home feature provides message throttling capabilities. Periodic inventory messages, port syslog messages, and RMON alert messages are added to the list of deliverable Call Home messages. If required you can also use the Cisco Fabric Services application to distribute the Call Home configuration to all other switches in the fabric.

The Call Home service provides e-mail-based notification of critical system events. A versatile range of message formats are available for optimal compatibility with pager services, standard e-mail, or XML-based automated parsing applications.

Common features may include the following:

- Paging the network support engineer
- E-mailing the Network Operations Center

Send documentation comments to mdsfeedback-doc@cisco.com

- Raising a direct case with the Technical Assistance Center

The Call Home functionality is available directly through the Cisco MDS 9000 Family switches and the Cisco Nexus 5000 Series switches. It provides multiple Call Home messages, each with separate potential destinations. You can define your own destination profiles in addition to predefined profiles; you can configure up to 50 e-mail addresses for each destination profile. Flexible message delivery and format options make it easy to integrate specific support requirements.

The Call Home feature offers the following advantages:

- Fixed set of predefined alerts for trigger events on the switch.
- Automatic execution and attachment of relevant command output.

This section includes the following topics:

- [Call Home Features, page 4-2](#)
- [About Smart Call Home, page 4-3](#)
- [Call Home Destination Profiles, page 4-5](#)
- [Call Home Alert Groups, page 4-5](#)
- [Call Home Message Level Feature, page 4-6](#)
- [Syslog-Based Alerts, page 4-6](#)
- [RMON-Based Alerts, page 4-7](#)
- [General E-Mail Options Using HTTPS Support, page 4-7](#)
- [Multiple SMTP Server Support, page 4-7](#)
- [Periodic Inventory Notification, page 4-8](#)
- [Duplicate Message Throttle, page 4-8](#)
- [Call Home Configuration Distribution, page 4-8](#)
- [Fabric Lock Override, page 4-8](#)
- [Clearing Call Home Name Server Database, page 4-9](#)
- [EMC E-mail Home Delayed Traps, page 4-9](#)
- [Event Triggers, page 4-10](#)
- [Call Home Message Levels, page 4-12](#)
- [Message Contents, page 4-14](#)

Call Home Features

The Call Home functionality is available directly through the Cisco MDS 9000 Family switches and the Cisco Nexus 5000 Series switches. It provides multiple Call Home profiles (also referred to as *Call Home destination profiles*), each with separate potential destinations. You can define your own destination profiles in addition to predefined profiles.

The Call Home function can even leverage support from Cisco Systems or another support partner. Flexible message delivery and format options make it easy to integrate specific support requirements.

The Call Home feature offers the following advantages:

- Fixed set of predefined alerts and trigger events on the switch.
- Automatic execution and attachment of relevant command output.

Send documentation comments to mdsfeedback-doc@cisco.com

- Multiple message format options:
 - Short Text—Suitable for pagers or printed reports.
 - Plain Text—Full formatted message information suitable for human reading.
 - XML—Matching readable format using Extensible Markup Language (XML) and document type definitions (DTDs) named Messaging Markup Language (MML). The MML DTD is published on the Cisco.com website at <http://www.cisco.com/>. The XML format enables communication with the Cisco Systems Technical Assistance Center.
- Multiple concurrent message destinations. You can configure up to 50 e-mail destination addresses for each destination profile.
- Multiple message categories including system, environment, switching module hardware, supervisor module, hardware, inventory, syslog, RMON, and test.
- Secure messages transport directly from your device or through an HTTP proxy server or a downloadable transport gateway (TG). You can use a TG aggregation point to support multiple devices, or in cases where security requires that your devices not be connected directly to the Internet.

About Smart Call Home

Smart Call Home is a component of Cisco SMARTnet Service that offers proactive diagnostics, real-time alerts, and personalized web-based reports on select Cisco devices.

Smart Call Home provides fast resolution of system problems by analyzing Call Home messages sent from your devices and providing a direct notification path to Cisco customer support.

Smart Call Home offers the following features:

- Continuous device health monitoring and real-time diagnostics alerts.
- Analysis of Call Home messages from your device and where appropriate, automatic service request generation, routed to the appropriate TAC team, including detailed diagnostic information to speed problem resolution.
- Web-based access to Call Home messages and recommendations, inventory and configuration information for all Call Home devices. Provides access to associated Field Notices, Security Advisories and End-of-Life Information.

[Table 4-1](#) lists the benefits of Smart Call Home.

Send documentation comments to mdsfeedback-doc@cisco.com

Table 4-1 Benefits of Smart Call Home Compared to Autonotify

Feature	Smart Call Home	Autonotify
Low touch registration	The registration process is considerably streamlined. Customers no longer need to know their device serial number or contract information. They can register devices without manual intervention from Cisco by sending a message from those devices. The procedures are outlined at www.cisco.com/go/smartcall	Requires the customer to request Cisco to add each specific serial number to the database.
Recommendations	Smart Call Home provides recommendations for known issues including those for which SRs are raised and for which SRs are not appropriate but for which customers might want to still take action on.	Autonotify raises SRs for a set of failure scenarios but no recommendations are provided for these.
Device report	Device report includes full inventory and configuration details. Once available, the information in these reports will be mapped to field notices, PSIRTs, EoX notices, configuration best practices and bugs.	No.
History report	The history report is available to look up any message and its contents, including show commands, message processing, analysis results, recommendations and service request numbers for all messages sent over the past three months.	A basic version is available that does not include contents of message.

Send documentation comments to mdsfeedback-doc@cisco.com

Table 4-1 Benefits of Smart Call Home Compared to Autonotify (continued)

Feature	Smart Call Home	Autonotify
Network summary report	A report that provides a summary of the make-up of devices and modules in the customer network (for those devices registered with Smart Call home)	No.
Cisco device support	Device Support will be extended across the Cisco product range. See the supported products table at www.cisco.com/go/smartcall	Deprecated in favor of Smart Call Home in October 2008.

Obtaining Smart Call Home

If you have a service contract directly with Cisco Systems, you can receive automatic case generation from the Technical Assistance Center by registering with the Smart Call Home service.

You need the following items to register:

- The SMARTnet contract number for your switch.
- Your e-mail address
- Your Cisco.com ID

For detailed information on Smart Call Home, including quick start configuration and registration steps, see the Smart Call Home page at this location:

<http://www.cisco.com/go/smartcall/>

Call Home Destination Profiles

A destination profile contains the required delivery information for an alert notification. Destination profiles are typically configured by the network administrator.

Using alert groups you can select the set of Call Home alerts to be received by a destination profile (predefined or user defined). Alert groups are predefined subsets of Call Home alerts supported in all switches in the Cisco MDS 9000 Family and the Cisco Nexus 5000 Series. Different types of Call Home alerts are grouped into different alert groups depending on their type. You can associate one or more alert groups to each profile as required by your network.

Call Home Alert Groups

An alert group is a predefined subset of Call Home alerts supported in all switches in the Cisco MDS 9000 Family and Cisco Nexus 5000 Series. Alert groups allow you to select the set of Call Home alerts to be received by a destination profile (predefined or user-defined). A Call Home alert is sent to e-mail destinations in a destination profile only if that Call Home alert belongs to one of the alert groups associated with that destination profile.

Send documentation comments to mdsfeedback-doc@cisco.com

Using the predefined Call Home alert groups you can generate notification messages when certain events occur on the switch. You can customize predefined alert groups to execute additional **show** commands when specific events occur and to notify you of output other than from the predefined **show** commands.

Customized Alert Group Messages

An alert group is a predefined subset of Call Home alerts supported in all switches in the Cisco MDS 9000 Family and Cisco Nexus 5000 Series switches. Alert groups allow you to select the set of Call Home alerts to be received by a destination profile (predefined or user-defined). The predefined Call Home alert groups generate notification messages when certain events occur on the switch. You can customize predefined alert groups to execute additional **show** commands when specific events occur.

The output from these additional **show** commands is included in the notification message along with the output of the predefined **show** commands.

Call Home Message Level Feature

The Call Home message level feature allows you to filter messages based on their level of urgency. Each destination profile (predefined and user-defined) is associated with a Call Home message level threshold. Any message with a value lower than the urgency threshold is not sent. Call Home severity levels are not the same as system message logging severity levels.

Syslog-Based Alerts

You can configure the switch to send certain syslog messages as Call Home messages. The messages are sent based on the mapping between the destination profile and the alert group mapping, and on the severity level of the generated syslog message.

To receive a syslog-based Call Home alert, you must associate a destination profile with the syslog alert groups (currently there is only one syslog alert group—`syslog-group-port`) and configure the appropriate message level.

The `syslog-group-port` alert group selects syslog messages for the port facility. The Call Home application maps the syslog severity level to the corresponding Call Home severity level (see the [“Call Home Message Levels”](#) section on page 4-12). For example, if you select level 5 for the Call Home message level, syslog messages at levels 0, 1, and 2 are included in the Call Home log.

Whenever a syslog message is generated, the Call Home application sends a Call Home message depending on the mapping between the destination profile and the alert group mapping and based on the severity level of the generated syslog message. To receive a syslog-based Call Home alert, you must associate a destination profile with the syslog alert groups (currently there is only one syslog alert group—`syslog-group-port`) and configure the appropriate message level (see the [“Call Home Message Levels”](#) section on page 4-12).

**Note**

Call Home does not change the syslog message level in the message text. The syslog message texts in the Call Home log appear as they are described in the *Cisco MDS 9000 Family System Messages Reference*.

Send documentation comments to mdsfeedback-doc@cisco.com

RMON-Based Alerts

You can configure the switch to send Call Home notifications corresponding to RMON alert triggers. All RMON-based Call Home messages have their message level set to NOTIFY (2). The RMON alert group is defined for all RMON-based Call Home alerts. To receive an RMON-based Call Home alert, you must associate a destination profile with the RMON alert group.

General E-Mail Options Using HTTPS Support

The HTTPS support for Call Home provides a transport method called HTTP. HTTPS support is used for a secure communication, and HTTP is used for nonsecure communication. You can configure an HTTP URL for the Call Home destination profile as a destination. The URL link can be from a secure server or nonsecure server. For a destination profile configured with the HTTP URL, the Call Home message is posted to the HTTP URL link.

**Note**

The Call Home HTTP configuration can be distributed over CFS on the switches running NX-OS Release 4.2(1) and later. The Call Home HTTP configuration cannot be distributed to switches that support the nondistributable HTTP configuration. Switches running lower versions than NX-OS Release 4.2(1) and later will ignore the HTTP configuration.

Multiple SMTP Server Support

Cisco MDS NX-OS and Cisco NX-OS 5000 Series switches support multiple SMTP servers for Call Home. Each SMTP server has a priority configured between 1 and 100, with 1 being the highest priority and 100 being the lowest. If the priority is not specified, a default value of 50 is used.

You can configure up to five SMTP servers for Call Home. The servers are contacted based on their priority. The highest priority server is contacted first. If the message fails to be sent, the next server in the list is contacted until the limit is exhausted. If two servers have equal priority, the one that was configured earlier is contacted.

If a high-priority SMTP server fails, the other servers will be contacted. A time delay may occur while sending a message. The delay is minimal if the attempt to send the message through the first SMTP server is successful. The delay may increase depending on the number of unsuccessful attempts with different SMTP servers.

**Note**

The new configuration process is not related to the old configuration. However, if the SMTP servers are configured using both the old and new schemes, the older configuration is of the highest priority.

Multiple SMTP servers can be configured on any MDS 9000 Family switch, Cisco Nexus 5000 Series switches, and Cisco Nexus 7000 Series switches running Release 5.0(1a) or later.

The new configuration will only be distributed to switches that have multiple SMTP servers. The older switches in the fabric will ignore the new configuration received over CFS.

In a mixed fabric that has CFS enabled, the switches running NX-OS Release 5.0 can configure new functionalities and distribute the new configuration to other switches with Release 5.0 in the fabric over CFS. However, if an existing switch running NX-OS Release 4.x upgrades to Release 5.0, the new configurations will not be distributed to that switch as a CFS merge is not triggered on an upgrade. There are two options to upgrade:

Send documentation comments to mdsfeedback-doc@cisco.com

- Apply new configuration only when all the switches in the fabric support them. (Recommended option).
- Do an empty commit from an existing NX-OS Release 5.0 switch which has the new configuration

Periodic Inventory Notification

You can configure the switch to periodically send a message with an inventory of all software services currently enabled and running on the switch along with hardware inventory information. The inventory is modified each time the switch is restarted nondisruptively.

Duplicate Message Throttle

You can configure a throttling mechanism to limit the number of Call Home messages received for the same event. If the same message is sent multiple times from the switch within a short period of time, you may be swamped with a large number of duplicate messages.

Call Home Configuration Distribution

You can enable fabric distribution for all Cisco MDS 9000 Family switches and Cisco Nexus 5000 Series switches in the fabric. When you perform Call Home configurations, and distribution is enabled, that configuration is distributed to all the switches in the fabric. However, the switch priority and the Syscontact names are not distributed.

You automatically acquire a fabric-wide lock when you enter the first configuration command operation after you enable distribution in a switch. The Call Home application uses the effective and pending database model to store or commit the configuration changes. When you commit the configuration changes, the effective database is overwritten by the configuration changes in the pending database and all the switches in the fabric receive the same configuration. After making the configuration changes, you can choose to discard the changes by aborting the changes instead of committing them. In either case, the lock is released. See [Chapter 2, “Using the CFS Infrastructure”](#) for more information on the CFS application.

**Note**

The switch priority and the Syscontact name are not distributed.

Fabric Lock Override

If you have performed a Call Home task and have forgotten to release the lock by either committing or discarding the changes, an administrator can release the lock from any switch in the fabric. If the administrator performs this task, your changes to the pending database are discarded and the fabric lock is released.

**Tip**

The changes are only available in the volatile directory and are subject to being discarded if the switch is restarted.

Send documentation comments to mdsfeedback-doc@cisco.com

Clearing Call Home Name Server Database

When the Call Home name server database is full, a new entry cannot be added. The device is not allowed to come online. To clear the name server database, increase the database size or perform a cleanup by removing unused devices. A total of 20,000 name server entries are supported.

EMC E-mail Home Delayed Traps

DCNM-SAN can be configured to generate EMC E-mail Home XML e-mail messages. In SAN-OS Release 3.x or earlier, DCMN-SAN listens to interface traps and generates EMC E-mail Home e-mail messages. Link traps are generated when an interface goes to down from up or vice versa. For example, if there is a scheduled server reboot, the link goes down and DCMN-SAN generates an e-mail notification.

Cisco NX-OS Release 4.1(3) provides the ability to generate a delayed trap so that the number of generated e-mail messages is reduced. This method filters server reboots and avoids generating unnecessary EMC E-mail Home e-mail messages. In NX-OS Release 4.1(3), users have the ability to select the current existing feature or this new delayed trap feature.

Beginning from Cisco NX-OS Release 5.2(2), the Call Home does not send an email alerts when a link comes back online (LinkUp). It sends email alerts only for LinkDown events.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

Event Triggers

This section discusses Call Home trigger events. Trigger events are divided into categories, with each category assigned CLI commands to execute when the event occurs. The command output is included in the transmitted message. [Table 4-2](#) lists the trigger events

Table 4-2 *Event Triggers*

Event	Alert Group	Event Name	Description	Call Home Message Level
Call Home	System and CISCO_TAC	SW_CRASH	A software process has crashed with a stateless restart, indicating an interruption of a service.	5
	System and CISCO_TAC	SW_SYSTEM_INCONSISTENT	Inconsistency detected in software or file system.	5
	Environmental and CISCO_TAC	TEMPERATURE_ALARM	Thermal sensor indicates temperature reached operating threshold.	6
		POWER_SUPPLY_FAILURE	Power supply failed.	6
		FAN_FAILURE	Cooling fan has failed.	5
	Line Card Hardware and CISCO_TAC	LINECARD_FAILURE	Line card hardware operation failed.	7
		POWER_UP_DIAGNOSTICS_FAILURE	Line card hardware failed power-up diagnostics.	7
	Line Card Hardware and CISCO_TAC	PORT_FAILURE	Hardware failure of interface port(s).	6
	Line Card Hardware, Supervisor Hardware, and CISCO_TAC	BOOTFLASH_FAILURE	Failure of boot compact flash card.	6
	Supervisor Hardware and CISCO_TAC	NVRAM_FAILURE	Hardware failure of NVRAM on supervisor hardware.	6
	Supervisor Hardware and CISCO_TAC	FREEDISK_FAILURE	Free disk space is below a threshold on supervisor hardware.	6
	Supervisor Hardware and CISCO_TAC	SUP_FAILURE	Supervisor hardware operation failed. ¹	7
		POWER_UP_DIAGNOSTICS_FAILURE	Supervisor hardware failed power-up diagnostics.	7
	Supervisor Hardware and CISCO_TAC	INBAND_FAILURE	Failure of in-band communications path.	7
	Supervisor Hardware and CISCO_TAC	EOBC_FAILURE	Ethernet out-of-band channel communications failure.	6

Send documentation comments to mdsfeedback-doc@cisco.com

Table 4-2 **Event Triggers (continued)**

Event	Alert Group	Event Name	Description	Call Home Message Level
Call Home	Supervisor Hardware and CISCO_TAC	MGMT_PORT_FAILURE	Hardware failure of management Ethernet port.	5
	License	LICENSE_VIOLATION	Feature in use is not licensed, and are turned off after grace period expiration.	6
Inventory	Inventory and CISCO_TAC	COLD_BOOT	Switch is powered up and reset to a cold boot sequence.	2
		HARDWARE_INSERTION	New piece of hardware inserted into the chassis.	2
		HARDWARE_REMOVAL	Hardware removed from the chassis.	2
Test	Test and CISCO_TAC	TEST	User generated test.	2
Port syslog	Syslog-group-port	SYSLOG_ALERT	Syslog messages corresponding to the port facility.	2
RMON	RMON	RMON_ALERT	RMON alert trigger messages.	2

1. When the active supervisor is removed, a switch over occurs. A call home notification for this event will not be sent.

Send documentation comments to mdsfeedback-doc@cisco.com

Call Home Message Levels

Table 4-3 Event Categories and Executed Commands

Event Category	Description	Executed Commands
System show module show version show tech-support platform show tech-support sysmgr show hardware show sprom all	Events generated by failure of a software system that is critical to unit operation.	show tech-support show system redundancy status
Environmental show module show version show environment show logging logfile tail -n 200	Events related to power, fan, and environment sensing elements such as temperature alarms.	show module show environment
Line Card Hardware show module show version show tech-support platform show tech-support sysmgr show hardware show sprom all	Events related to standard or intelligent line card hardware.	show tech-support
Supervisor Hardware show module show version show tech-support platform show tech-support sysmgr show hardware show sprom all	Events related to supervisor modules.	show tech-support

Send documentation comments to mdsfeedback-doc@cisco.com

Table 4-3 Event Categories and Executed Commands (continued)

Event Category	Description	Executed Commands
Inventory show module show version show hardware show inventory show system uptime show sptom all show license usage	Inventory status is provided whenever a unit is cold booted, or when FRUs are inserted or removed. This is considered a noncritical event, and the information is used for status and entitlement.	show version
Test show module show version	User generated test message.	show version

Call Home messages (sent for syslog alert groups) have the syslog severity level mapped to the Call Home message level (see the “[Syslog-Based Alerts](#)” section on page 4-6).

This section discusses the severity levels for a Call Home message when using one or more switches in the Cisco MDS 9000 Family and the Cisco Nexus 5000 Series. Call Home message levels are preassigned per event type.

Severity levels range from 0 to 9, with 9 having the highest urgency. Each syslog level has keywords and a corresponding syslog level as listed in [Table 4-4](#).

**Note**

Call Home does not change the syslog message level in the message text. The syslog message texts in the Call Home log appear as they are described in the *Cisco MDS 9000 Family System Messages Reference*.

**Note**

Call Home severity levels are not the same as system message logging severity levels (see the *Cisco MDS 9000 Family System Messages Reference*).

Table 4-4 Severity and Syslog Level Mapping

Call Home Level	Keyword Used	Syslog Level	Description
Catastrophic (9)	Catastrophic	N/A	Network wide catastrophic failure.
Disaster (8)	Disaster	N/A	Significant network impact.
Fatal (7)	Fatal	Emergency (0)	System is unusable.
Critical (6)	Critical	Alert (1)	Critical conditions, immediate attention needed.
Major (5)	Major	Critical (2)	Major conditions.
Minor (4)	Minor	Error (3)	Minor conditions.
Warning (3)	Warning	Warning (4)	Warning conditions.

Send documentation comments to mdsfeedback-doc@cisco.com

Table 4-4 Severity and Syslog Level Mapping (continued)

Call Home Level	Keyword Used	Syslog Level	Description
Notify (2)	Notification	Notice (5)	Basic notification and informational messages. Possibly independently insignificant.
Debug (0)	Debugging	Debug (7)	Debugging messages.

Message Contents

The following contact information can be configured on the switch:

- Name of the contact person
- Phone number of the contact person
- E-mail address of the contact person
- Mailing address to which replacement parts must be shipped, if required
- Site ID of the network where the site is deployed
- Contract ID to identify the service contract of the customer with the service provider

[Table 4-5](#) describes the short text formatting option for all message types.

Table 4-5 Short Text Messages

Data Item	Description
Device identification	Configured device name
Date/time stamp	Time stamp of the triggering event
Error isolation message	Plain English description of triggering event
Alarm urgency level	Error level such as that applied to system message

[Table 4-6](#), [Table 4-7](#), and [Table 4-8](#) display the information contained in plain text and XML messages.

Table 4-6 Reactive Event Message Format

Data Item (Plain text and XML)	Description (Plain text and XML)	XML Tag (XML only)
Time stamp	Date and time stamp of event in ISO time notation: <i>YYYY-MM-DDTHH:MM:SS</i> . Note The time zone or daylight savings time (DST) offset from UTC has already been added or subtracted. T is the hardcoded limiter for the time.	/mml/header/time - ch:EventType
Message name	Name of message. Specific event names are listed in the “ Event Triggers ” section on page 4-10.	/mml/header/name
Message type	Specifically “Call Home.”	/mml/header/type - ch:Type
Message group	Specifically “reactive.”	/mml/header/group
Severity level	Severity level of message (see Table 4-4).	/mml/header/level - aml-block:Severity

Send documentation comments to mdsfeedback-doc@cisco.com

Table 4-6 **Reactive Event Message Format (continued)**

Data Item (Plain text and XML)	Description (Plain text and XML)	XML Tag (XML only)
Source ID	Product type for routing.	/mml/header/source - ch:Series
Device ID	Unique device identifier (UDI) for end device generating message. This field should empty if the message is non-specific to a fabric switch. Format is <i>type@Sid@serial</i> , where: <ul style="list-style-type: none"> <i>type</i> is the product model number from backplane SEEPRM. @ is a separator character. <i>Sid</i> is "C," identifying the serial ID as a chassis serial number. <i>serial</i> is the number identified by the Sid field. Example: DS-C9509@C@12345678	/mml/ header/deviceId
Customer ID	Optional user-configurable field used for contract info or other ID by any support service.	/mml/header/customerID - ch:CustomerId
Contract ID	Optional user-configurable field used for contract info or other ID by any support service.	/mml/header/contractId - ch:ContractId>
Site ID	Optional user-configurable field used for Cisco-supplied site ID or other data meaningful to alternate support service.	/mml/header/siterId - ch:SiteId
Server ID	If the message is generated from the fabric switch, it is the unique device identifier (UDI) of the switch. Format is <i>type@Sid@serial</i> , where: <ul style="list-style-type: none"> <i>type</i> is the product model number from backplane SEEPRM. @ is a separator character. <i>Sid</i> is "C," identifying the serial ID as a chassis serial number. <i>serial</i> is the number identified by the Sid field. Example: DS-C9509@C@12345678	/mml/header/serverId - -blank-
Message description	Short text describing the error.	/mml/body/msgDesc - ch:MessageDescription
Device name	Node that experienced the event. This is the host name of the device.	/mml/body/sysName - ch:SystemInfo/Name
Contact name	Name of person to contact for issues associated with the node experiencing the event.	/mml/body/sysContact - ch:SystemInfo/Contact
Contact e-mail	E-mail address of person identified as contact for this unit.	/mml/body/sysContacte-mail - ch:SystemInfo/Contacte-mail
Contact phone number	Phone number of the person identified as the contact for this unit.	/mml/body/sysContactPhone Number - ch:SystemInfo/ContactPhone Number
Street address	Optional field containing street address for RMA part shipments associated with this unit.	/mml/body/sysStreetAddress - ch:SystemInfo/StreetAddress

Send documentation comments to mdsfeedback-doc@cisco.com

Table 4-6 *Reactive Event Message Format (continued)*

Data Item (Plain text and XML)	Description (Plain text and XML)	XML Tag (XML only)
Model name	Model name of the switch. This is the specific model as part of a product family name.	/mml/body/chassis/name - rme:Chassis/Model
Serial number	Chassis serial number of the unit.	/mml/body/chassis/serialNo - rme:Chassis/SerialNumber
Chassis part number	Top assembly number of the chassis.	/mml/body/fru/partNo - rme:chassis/Card/PartNumber
Chassis hardware version	Hardware version of chassis.	/mml/body/chassis/hwVersion - rme:Chassis/HardwareVersion
Supervisor module software version	Top level software version.	/mml/body/fru/swVersion - rme:chassis/Card/SoftwareIdentity
Affected FRU name	Name of the affected FRU generating the event message.	/mml/body/fru/name - rme:chassis/Card/Model
Affected FRU serial number	Serial number of affected FRU.	/mml/body/fru/serialNo - rme:chassis/Card/SerialNumber
Affected FRU part number	Part number of affected FRU.	/mml/body/fru/partNo - rme:chassis/Card/PartNumber
FRU slot	Slot number of FRU generating the event message.	/mml/body/fru/slot - rme:chassis/Card/LocationWithinContainer
FRU hardware version	Hardware version of affected FRU.	/mml/body/fru/hwVersion - rme:chassis/Card/SoftwareIdentity
FRU software version	Software version(s) running on affected FRU.	/mml/body/fru/swVersion - rme:chassis/Card/SoftwareIdentity
Command output name	The exact name of the issued command.	/mml/attachments/attachment/ name - aml-block:Attachment/Name
Attachment type	Specifically command output.	/mml/attachments/attachment/ type - aml-block:Attachment type
MIME type	Normally text or plain or encoding type.	/mml/attachments/attachment/ mime - aml-block:Attachment/Data encoding
Command output text	Output of command automatically executed (see Table 4-3).	/mml/attachments/attachment/ atdata - aml-block:Attachment/Data

Send documentation comments to mdsfeedback-doc@cisco.com

Table 4-7 Inventory Event Message Format

Data Item (Plain text and XML)	Description (Plain text and XML)	XML Tag (XML only)
Time stamp	Date and time stamp of event in ISO time notation: <i>YYYY-MM-DDTHH:MM:SS</i> . Note The time zone or daylight savings time (DST) offset from UTC has already been added or subtracted. T is the hardcoded limiter for the time.	/mml/header/time - ch:EventTime
Message name	Name of message. Specifically “Inventory Update” Specific event names are listed in the “Event Triggers” section on page 4-10.	/mml/header/name
Message type	Specifically “Inventory Update.”	/mml/header/type - ch-inv:Type
Message group	Specifically “proactive.”	/mml/header/group
Severity level	Severity level of inventory event is level 2 (see Table 4-4).	/mml/header/level - aml-block:Severity
Source ID	Product type for routing at Cisco. Specifically “MDS 9000.”	/mml/header/source - ch-inv:Series
Device ID	Unique Device Identifier (UDI) for end device generating message. This field should empty if the message is non-specific to a fabric switch. Format is <i>type@Sid@serial</i> , where: <ul style="list-style-type: none"> <i>type</i> is the product model number from backplane SEEPRM. <i>@</i> is a separator character. <i>Sid</i> is “C,,” identifying the serial ID as a chassis serial number. <i>serial</i> is the number identified by the Sid field. Example: DS-C9509@C@12345678	/mml/ header /deviceId
Customer ID	Optional user-configurable field used for contact info or other ID by any support service.	/mml/header/customerID - ch-inv:CustomerId
Contract ID	Optional user-configurable field used for contact info or other ID by any support service.	/mml/header/contractId - ch-inv:ContractId>
Site ID	Optional user-configurable field, can be used for Cisco-supplied site ID or other data meaningful to alternate support service.	/mml/header/siterId - ch-inv:SiteId
Server ID	If the message is generated from the fabric switch, it is the Unique device identifier (UDI) of the switch. Format is <i>type@Sid@serial</i> , where: <ul style="list-style-type: none"> <i>type</i> is the product model number from backplane SEEPRM. <i>@</i> is a separator character. <i>Sid</i> is “C,,” identifying the serial ID as a chassis serial number. <i>serial</i> is the number identified by the Sid field. Example: DS-C9509@C@12345678	/mml/header/serverId - -blank-
Message description	Short text describing the error.	/mml/body/msgDesc - ch-inv:MessageDescription

Send documentation comments to mdsfeedback-doc@cisco.com

Table 4-7 Inventory Event Message Format (continued)

Data Item (Plain text and XML)	Description (Plain text and XML)	XML Tag (XML only)
Device name	Node that experienced the event.	/mml/body/sysName - ch-inv:SystemInfo/Name
Contact name	Name of person to contact for issues associated with the node experiencing the event.	/mml/body/sysContact - ch-inv:SystemInfo/Contact
Contact e-mail	E-mail address of person identified as contact for this unit.	/mml/body/sysContacte-mail - ch-inv:SystemInfo/Contacte-mail
Contact phone number	Phone number of the person identified as the contact for this unit.	/mml/body/sysContactPhoneNumber - ch-inv:SystemInfo/ContactPhoneNumber
Street address	Optional field containing street address for RMA part shipments associated with this unit.	/mml/body/sysStreetAddress - ch-inv:SystemInfo/StreetAddress
Model name	Model name of the unit. This is the specific model as part of a product family name.	/mml/body/chassis/name - rme:Chassis/Model
Serial number	Chassis serial number of the unit.	/mml/body/chassis/serialNo - rme:Chassis/SerialNumber
Chassis part number	Top assembly number of the chassis.	/mml/body/fru/partNo - rme:chassis/Card/PartNumber
Chassis hardware version	Hardware version of chassis.	/mml/body/fru/hwVersion - rme:chassis/Card/SoftwareIdentity
Supervisor module software version	Top level software version.	/mml/body/fru/swVersion - rme:chassis/Card/SoftwareIdentity
FRU name	Name of the affected FRU generating the event message.	/mml/body/fru/name - rme:chassis/Card/Model
FRU s/n	Serial number of FRU.	/mml/body/fru/serialNo - rme:chassis/Card/SerialNumber
FRU part number	Part number of FRU.	/mml/body/fru/partNo - rme:chassis/Card/PartNumber
FRU slot	Slot number of FRU.	/mml/body/fru/slot - rme:chassis/Card/LocationWithinContainer
FRU hardware version	Hardware version of FRU.	/mml/body/fru/hwVersion - rme:chassis/Card/SoftwareIdentity
FRU software version	Software version(s) running on FRU.	/mml/body/fru/swVersion - rme:chassis/Card/SoftwareIdentity

Send documentation comments to mdsfeedback-doc@cisco.com

Table 4-7 **Inventory Event Message Format (continued)**

Data Item (Plain text and XML)	Description (Plain text and XML)	XML Tag (XML only)
Command output name	The exact name of the issued command.	/mml/attachments/attachment /name - aml-block:Attachment/Name
Attachment type	Specifically command output.	/mml/attachments/attachment /type - aml-block:Attachment type
MIME type	Normally text or plain or encoding type.	/mml/attachments/attachment /mime - aml-block:Attachment/Data encoding
Command output text	Output of command automatically executed after event categories (see “Event Triggers” section on page 4-10).	/mml/attachments/attachment /atdata - aml-block:Attachment/Data

Table 4-8 **User-Generated Test Message Format**

Data Item (Plain text and XML)	Description (Plain text and XML)	XML Tag (XML only)
Time stamp	Date and time stamp of event in ISO time notation: <i>YYYY-MM-DDTHH:MM:SS</i> . Note The time zone or daylight savings time (DST) offset from UTC has already been added or subtracted. T is the hardcoded limiter for the time.	/mml/header/time - ch:EventTime
Message name	Name of message. Specifically test message for test type message. Specific event names listed in the “Event Triggers” section on page 4-10).	/mml/header/name
Message type	Specifically “Test Call Home.”	/mml/header/type - ch:Type
Message group	This field should be ignored by the receiving Call Home processing application, but may be populated with either “proactive” or “reactive.”	/mml/header/group
Severity level	Severity level of message, test Call Home message (see Table 4-4).	/mml/header/level - aml-block:Severity
Source ID	Product type for routing.	/mml/header/source - ch:Series
Device ID	Unique device identifier (UDI) for end device generating message. This field should empty if the message is nonspecific to a fabric switch. Format is <i>type@Sid@serial</i> , where: <ul style="list-style-type: none"> • <i>type</i> is the product model number from backplane SEEPROM. • <i>@</i> is a separator character. • <i>Sid</i> is “C” identifying the serial ID as a chassis serial number. • <i>serial</i> is the number identified by the Sid field. Example: DS-C9509@C@12345678	/mml/ header /deviceId

Send documentation comments to mdsfeedback-doc@cisco.com

Table 4-8 User-Generated Test Message Format (continued)

Data Item (Plain text and XML)	Description (Plain text and XML)	XML Tag (XML only)
Customer ID	Optional user-configurable field used for contract info or other ID by any support service.	/mml/header/customerID - ch:CustomerId
Contract ID	Optional user-configurable field used for contract info or other ID by any support service.	/mml/header/contractId - ch:ContractId
Site ID	Optional user-configurable field used for Cisco-supplied site ID or other data meaningful to alternate support service.	/mml/header/siterId - ch:SiteId
Server ID	If the message is generated from the fabric switch, it is the Unique device identifier (UDI) of the switch. Format is <i>type@Sid@serial</i> , where: <ul style="list-style-type: none"> <i>type</i> is the product model number from backplane SEEPROM. <i>@</i> is a separator character. <i>Sid</i> is “C” identifying the serial ID as a chassis serial number. <i>serial</i> is the number identified by the Sid field. Example: “DS-C9509@C@12345678”	/mml/header/serverId - -blank-
Message description	Short text describing the error.	/mml/body/msgDesc - ch:MessageDescription
Device name	Switch that experienced the event.	/mml/body/sysName - ch:SystemInfo/Name
Contact name	Name of person to contact for issues associated with the node experiencing the event.	/mml/body/sysContact - ch:SystemInfo/Contact
Contact e-mail	E-mail address of person identified as contact for this unit.	/mml/body/sysContacte-mai l - ch:SystemInfo/Contacte-mai l
Contact phone number	Phone number of the person identified as the contact for this unit.	/mml/body/sysContactPhone Number - ch:SystemInfo/ContactPhon eNumber
Street address	Optional field containing street address for RMA part shipments associated with this unit.	/mml/body/sysStreetAddress - ch:SystemInfo/StreetAddres s
Model name	Model name of the switch. This is the specific model as part of a product family name.	/mml/body/chassis/name - rme:Chassis/Model
Serial number	Chassis serial number of the unit.	/mml/body/chassis/serialNo - rme:Chassis/SerialNumber
Chassis part number	Top assembly number of the chassis. For example, 800-xxx-xxxx.	/mml/body/fru/partNo - rme:chassis/Card/PartNumb er

Send documentation comments to mdsfeedback-doc@cisco.com

Table 4-8 User-Generated Test Message Format (continued)

Data Item (Plain text and XML)	Description (Plain text and XML)	XML Tag (XML only)
Command output text	Output of command automatically executed after event categories listed in Table 4-3 .	/mml/attachments/attachment/atdata - aml-block:Attachment/Data
MIME type	Normally text or plain or encoding type.	/mml/attachments/attachment/mime - aml-block:Attachment/Data encoding
Attachment type	Specifically command output.	/mml/attachments/attachment/type - aml-block:Attachment type
Command output name	The exact name of the issued command.	/mml/attachments/attachment/name - aml-block:Attachment/Name

Guidelines and Limitations

Call Home Database Merger Guidelines

When merging two Call Home databases, follow these guidelines:

- Be aware that the merged database contains the following information:
 - A superset of all the destination profiles from the dominant and subordinate switches that take part in the merge protocol.
 - The e-mail addresses and alert groups for the destination profiles.
 - Other configuration information (for example, message throttling, periodic inventory) from the switch that existed in the dominant switch before the merge.

See the [“CFS Merge Support”](#) section on page 2-6 for detailed concepts.

Call Home Configuration Guidelines

When configuring Call Home, follow these guidelines:

- An e-mail server and at least one destination profile (predefined or user-defined) must be configured. The destination profile(s) used depends on whether the receiving entity is a pager, e-mail, or automated service such as Cisco Smart Call Home.
- Switches can forward events (SNMP traps/informs) up to 10 destinations.
- The contact name (SNMP server contact), phone, and street address information must be configured before Call Home is enabled. This configuration is required to determine the origin of messages received.
- The Cisco MDS 9000 Family switch and the Cisco Nexus 5000 Series switch must have IP connectivity to an e-mail server.
- If Cisco Smart Call Home is used, an active service contract must cover the device being configured.

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

Default Settings

Table 4-9 lists the default Call Home settings.

Table 4-9 *Default Call Home Default Settings*

Parameters	Default
Destination message size for a message sent in full text format.	500,000
Destination message size for a message sent in XML format.	500,000
Destination message size for a message sent in short text format.	4000
DNS or IP address of the SMTP server to reach the server if no port is specified.	25
Alert group association with profile.	All
Format type.	XML
Call Home message level.	0 (zero)
HTTP proxy server use.	Disabled and no proxy server configured.
HTTP proxy server message size for full text destination.	1 MB
HTTP proxy server message size for XML.	1 MB

Configuring Call Home

How you configure the Call Home process depends on how you intend to use the feature.

This section includes the following topics:

- [Task Flow for Configuring Call Home, page 4-23](#)
- [Enabling Call Home Function, page 4-24](#)
- [Configuring Destination Profiles, page 4-24](#)
- [Associating an Alert Group, page 4-26](#)
- [Customizing Alert Group Messages, page 4-28](#)
- [Configuring Event Trap Notifications, page 4-30](#)
- [Configuring General E-Mail Options, page 4-30](#)
- [Configuring HTTPS Support, page 4-31](#)
- [Configuring an HTTP Proxy Server, page 4-32](#)
- [Enable or Disable Transport Method, page 4-31](#)
- [Enabling Periodic Inventory Notifications, page 4-34](#)
- [Configuring Duplicate Message Throttle, page 4-34](#)
- [Enabling Call Home Fabric Distribution, page 4-35](#)
- [Fabric Lock Override, page 4-36](#)
- [Call Home Communications Test, page 4-36](#)
- [Configuring Delayed Traps, page 4-36](#)

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

Task Flow for Configuring Call Home

Follow these steps to configure Call Home:

-
- Step 1** Configure contact information.
 - Step 2** Enable or disable Call Home.
 - Step 3** Configure destination profiles.
 - Step 4** Associate one or more alert groups to each profile as required by your network. Customize the alert groups, if desired.
 - Step 5** Configure e-mail options.
 - Step 6** Test Call Home messages.
-

Configuring Contact Information

Switch priority is specific to each switch in the fabric. This priority is used by the operations personnel or TAC support personnel to decide which Call Home message they should respond to first. You can prioritize Call Home alerts of the same severity from each switch.

Prerequisites

- Each switch must include e-mail, phone, and street address information. You can optionally include the contract ID, customer ID, site ID, and switch priority information.

Detailed Steps

To assign the contact information, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# snmp-server contact personname@companyname.com	Configures the SNMP contact name.
Step 3	switch(config)# callhome switch(config-callhome)#	Enters the Call Home configuration submode.
Step 4	switch(config-callhome)# e-mail-contact username@company.com	Assigns the customer's e-mail address. Up to 128 alphanumeric characters are accepted in e-mail address format. Note You can use any valid e-mail address. You cannot use spaces.
Step 5	switch(config-callhome)# phone-contact +1-800-123-4567	Assigns the customer's phone number. Up to 20 alphanumeric characters are accepted in international format. Note You cannot use spaces. Be sure to use the + prefix before the number.

Send documentation comments to mdsfeedback-doc@cisco.com

	Command	Purpose
Step 6	switch(config-callhome)# streetaddress 1234 Picaboo Street, Any city, Any state, 12345	Assigns the customer's street address where the equipment is located. Up to 256 alphanumeric characters are accepted in free format.
Step 7	switch(config-callhome)# switch-priority 0	Assigns the switch priority, with 0 being the highest priority and 7 the lowest. Tip Use this field to create a hierarchical management structure.
Step 8	switch(config-callhome)# customer-id Customer1234	Optional. Identifies the customer ID. Up to 256 alphanumeric characters are accepted in free format.
Step 9	switch(config-callhome)# site-id Site1ManhattanNY	Optional. Identifies the customer site ID. Up to 256 alphanumeric characters are accepted in free format.
Step 10	switch(config-callhome)# contract-id Company1234	Assigns the customer ID for the switch. Up to 64 alphanumeric characters are accepted in free format.

Enabling Call Home Function

Once you have configured the contact information, you must enable the Call Home function.

Detailed Steps

To enable the Call Home function, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters Call Home configuration submode.
Step 3	switch(config-callhome)# enable callhome enabled successfully switch(config-callhome)#	Enables the Call Home function.
	switch(config-callhome)# disable switch(config-callhome)#	Disables the Call Home function. When you disable the Call Home function, all input events are ignored. Note Even if Call Home is disabled, basic information for each Call Home event is sent.

Configuring Destination Profiles

A destination profile contains the required delivery information for an alert notification. Destination profiles are typically configured by the network administrator.

You can configure the following attributes for a destination profile:

- Profile name—A string that uniquely identifies each user-defined destination profile and is limited to 32 alphanumeric characters. The format options for a user-defined destination profile are full-txt, short-txt, or XML (default).

Send documentation comments to mdsfeedback-doc@cisco.com

- Destination address—The actual address, pertinent to the transport mechanism, to which the alert should be sent.
- Message formatting—The message format used for sending the alert (full text, short text, or XML).



Note

If you use the Cisco Smart Call Home service, the XML destination profile is required (see http://www.cisco.com/en/US/partner/products/hw/ps4159/ps4358/products_configuration_example09186a0080108e72.shtml).

Prerequisites

- At least one destination profile is required. You can configure multiple destination profiles of one or more types. You can use one of the predefined destination profiles or define a desired profile. If you define a new profile, you must assign a profile name.

Detailed Steps

To configure predefined destination profile messaging options, follow these steps:

	Command	Purpose
Step 1	<code>switch# config t</code>	Enters configuration mode.
Step 2	<code>switch(config)# callhome</code> <code>switch(config-callhome)#</code>	Enters the Call Home configuration submenu.
Step 3	<code>switch(config-callhome)#</code> <code>destination-profile</code> <code>full-txt-destination e-mail-addr</code> <code>person@place.com</code>	Configures an e-mail address for the predefined full-txt-destination profile. The e-mail addresses in this destination profile receives messages in full-txt format. The full-text format provides the complete, detailed explanation of the failure. Tip Use a standard e-mail address that does not have any text size restrictions.
	<code>switch(config-callhome)#</code> <code>destination-profile</code> <code>full-txt-destination message-size</code> <code>1000000</code>	Configures a maximum destination message size for the predefined full-txt-destination profile. The valid range is 0 to 1,000,000 bytes and the default is 500,000. A value of 0 implies that a message of any size can be sent.
Step 4	<code>switch(config-callhome)#</code> <code>destination-profile</code> <code>short-txt-destination e-mail-addr</code> <code>person@place.com</code>	Configures an e-mail address for the predefined short-txt-destination profile. The e-mail addresses in this destination profile receive messages in short-txt format. This format provides the basic explanation of the failure in the Call Home message. Tip Use a pager-related e-mail address for this option.
	<code>switch(config-callhome)#</code> <code>destination-profile</code> <code>short-txt-destination message-size</code> <code>100000</code>	Configures maximum destination message size for the predefined short-txt-destination profile. The valid range is 0 to 1,000,000 bytes and the default is 4000. A value of 0 implies that a message of any size can be sent.

Send documentation comments to mdsfeedback-doc@cisco.com

	Command	Purpose
Step 5	<pre>switch(config-callhome)# destination-profile XML-destination e-mail-addr findout@cisco.com</pre>	<p>Configures an e-mail address for the predefined XML-destination profile. The e-mail addresses in this destination-profile receives messages in XML format. This format provides information that is compatible with Cisco Systems TAC support.</p> <p>Tip Do not add a pager-related e-mail address to this destination profile because of the large message size.</p>
	<pre>switch(config-callhome)# destination-profile XML-destination message-size 100000</pre>	<p>Configures maximum destination message size for the predefined destination profile XML-destination. The valid range is 0 to 1,000,000 bytes and the default is 500,000. A value of 0 implies that a message of any size can be sent.</p>



Note

Steps 3, 4, and 5 in this procedure can be skipped or configured in any order.

To configure a new destination-profile (and related parameters), follow these steps:

	Command	Purpose
Step 1	<pre>switch# config t</pre>	Enters configuration mode.
Step 2	<pre>switch(config)# callhome switch(config-callhome)#</pre>	Enters the Call Home configuration submenu.
Step 3	<pre>switch(config-callhome)# destination-profile test</pre>	Configures a new destination profile called test.
Step 4	<pre>switch(config-callhome)# destination-profile test e-mail-addr person@place.com</pre>	Configures the e-mail address for the user-defined destination profile (test) sent in default XML format.
Step 5	<pre>switch(config-callhome)# destination-profile test message-size 1000000</pre>	Configures a maximum message size for the destination e-mail addresses in the user-defined destination profile (test) sent in default XML format. The valid range is 0 to 1,000,000 bytes and the default is 500,000. A value of 0 implies that a message of any size can be sent.
Step 6	<pre>switch(config-callhome)# destination-profile test format full-txt</pre>	Configures message-format for the user-defined destination profile (test) to be full text format.
	<pre>switch(config-callhome)# destination-profile test format short-txt</pre>	Configures message-format for the user-defined destination profile (test) to be short text format.



Note

Steps 4, 5, and 6 in this procedure can be skipped or configured in any order.

Associating an Alert Group

Different types of Call Home alerts are grouped into different alert groups depending on their type. You can associate one or more alert groups to each profile as required by your network.

Send documentation comments to mdsfeedback-doc@cisco.com

The alert group feature allows you to select the set of Call Home alerts to be received by a destination profile (either predefined or user-defined). You can associate multiple alert groups with a destination profile.

Restrictions

- A Call Home alert is sent to e-mail destinations in a destination profile only if that Call Home alert belongs to one of the alert groups associated with that destination profile.

Detailed Steps

To associate an alert group with a destination profile, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters Call Home configuration submode.
Step 3	switch(config-callhome)# destination-profile test1 alert-group test	Optional. Configures user-defined destination profile (test1) to receive all user-generated Call Home test notifications.
	switch(config-callhome)# destination-profile short-txt-destination alert-group test	Optional. Configures predefined short-text destination profile to receive all user-generated Call Home test notifications.
Step 4	switch(config-callhome)# destination-profile test1 alert-group all	Optional. Configures user-defined destination profile (test1) to receive Call Home notifications for all events
	switch(config-callhome)# destination-profile short-txt-destination alert-group all	Optional. Configures predefined short-text destination message profile to receive Call Home notifications for all (default) events
Step 5	switch(config-callhome)# destination-profile test1 alert-group Cisco-TAC	Optional. Configures user-defined destination message profile (test1) to receive Call Home notifications for events that are meant only for Cisco TAC or the Auto-notify service.
	switch(config-callhome)# destination-profile xml-destination alert-group Cisco-TAC	Optional. Configures predefined XML destination message profile to receive Call Home notifications for events that are meant only for Cisco TAC or the auto-notify service.
Step 6	switch(config-callhome)# destination-profile test1 alert-group environmental	Optional. Configures user-defined destination message profile (test1) to receive Call Home notifications for power, fan, and temperature-related events.
	switch(config-callhome)# destination-profile short-txt-destination alert-group environmental	Optional. Configures predefined short-text destination message profile to receive Call Home notifications for power, fan, and temperature-related events.

Send documentation comments to mdsfeedback-doc@cisco.com

	Command	Purpose
Step 7	<code>switch(config-callhome)# destination-profile test1 alert-group inventory</code>	Optional. Configures user-defined destination message profile (test1) to receive Call Home notifications for inventory status events.
	<code>switch(config-callhome)# destination-profile short-txt-destination alert-group inventory</code>	Optional. Configures predefined short-text destination message profile to receive Call Home notifications for inventory status events.
Step 8	<code>switch(config-callhome)# destination-profile test1 alert-group linecard-hardware</code>	Optional. Configures user-defined destination message profile (test1) to receive Call Home notifications for module-related events.
	<code>switch(config-callhome)# destination-profile short-txt-destination alert-group linecard-hardware</code>	Optional. Configures predefined short-text destination message profile to receive Call Home notifications for module-related events.
Step 9	<code>switch(config-callhome)# destination-profile test1 alert-group supervisor-hardware</code>	Optional. Configures user-defined destination message profile (test1) to receive Call Home notifications for supervisor-related events.
	<code>switch(config-callhome)# destination-profile short-txt-destination alert-group supervisor-hardware</code>	Optional. Configures predefined short-text destination message profile to receive Call Home notifications for supervisor-related events.
Step 10	<code>switch(config-callhome)# destination-profile test1 alert-group system</code>	Optional. Configures user-defined destination message profile (test1) to receive Call Home notifications for software-related events.
	<code>switch(config-callhome)# destination-profile short-txt-destination alert-group system</code>	Optional. Configures predefined short-text destination message profile to receive Call Home notifications for software-related events.

Customizing Alert Group Messages

To assign **show** commands to be executed when an alert is sent, you must associate the commands with the alert group. When an alert is sent, Call Home associates the alert group with an alert type and attaches the output of the **show** commands to the alert message.



Note

Make sure the destination profiles for a non-Cisco-TAC alert group, with a predefined **show** command, and the Cisco-TAC alert group are not the same.

Restrictions

- You can assign a maximum of five user-defined **show** commands to an alert group. Only **show** commands can be assigned to an alert group.
- Customized **show** commands are only supported for full text and XML alert groups. Short text alert groups (short-txt-destination) do not support customized **show** commands because they only allow 128 bytes of text.

Send documentation comments to mdsfeedback-doc@cisco.com

Detailed Steps

To customize Call Home alert group messages, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters Call Home configuration submenu.
Step 3	switch(config-callhome)# alert-group license user-def-cmd show license usage	Configures a user-defined show command for an alert group license. Note Only valid show commands are accepted.
	switch(config-callhome)# no alert-group license user-def-cmd show license usage	Removes the user-defined show command from the alert group.

Setting the Call Home Message Levels

Restrictions

- The urgency level ranges from 0 (lowest level of urgency) to 9 (highest level of urgency), and the default is 0 (all messages are sent).

Detailed Steps

To set the message level for each destination profile for Call Home, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters Call Home configuration submenu.
Step 3	switch(config-callhome)# destination-profile test message-level 5	Optional. Configures the message level urgency as 5 and above for the user-defined profile (test1).
	switch(config-callhome)# no destination-profile oldestest message-level 7	Removes a previously configured urgency level and reverts it to the default of 0 (all messages are sent).

Configuring the Syslog-Based Alerts

Detailed Steps

To configure the syslog-group-port alert group, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters Call Home configuration submenu.

Send documentation comments to mdsfeedback-doc@cisco.com

	Command	Purpose
Step 3	<code>switch(config-callhome)# destination-profile short-txt-destination alert-group syslog-group-port</code>	Configures the predefined destination profile (short-txt-destination) to receive Call Home Notifications corresponding to syslog messages for the port facility.
Step 4	<code>switch(config-callhome)# destination-profile short-txt-destination message-level 5</code>	Optional. Configures the predefined destination-profile (short-txt-destination) to send a Call Home message for syslog messages whose severity levels map to Call Home severity level of 5 or greater. The default is message level 0 (all syslog messages).

Configuring RMON Alerts

Detailed Steps

To configure RMON alert groups, follow these steps:

	Command	Purpose
Step 1	<code>switch# config t</code>	Enters configuration mode.
Step 2	<code>switch(config)# callhome switch(config-callhome)#</code>	Enters Call Home configuration submode.
Step 3	<code>switch(config-callhome)# destination-profile xml-destination alert-group rmon</code>	Optional. Configures a destination message profile (rmon_group) to send Call Home notifications for configured RMON messages.

Configuring Event Trap Notifications

Detailed Steps

To configure a Call Home event notification trap (except Call Home periodic messages), follow these steps:

	Command	Purpose
Step 1	<code>switch# config t</code>	Enters configuration mode.
Step 2	<code>switch(config)# callhome switch(config-callhome)#</code>	Enters Call Home configuration submode.
Step 3	<code>switch(config-callhome)# snmp-server enable traps callhome event-notify</code>	Enables the SNMP notification trap for Call Home.

Configuring General E-Mail Options

You can configure the from, reply-to, and return-receipt e-mail addresses. While most e-mail address configurations are optional, you must configure the SMTP server address for the Call Home functionality to work.

Send documentation comments to mdsfeedback-doc@cisco.com



Note

Beginning from Cisco NX-OS Release 5.2(2), the Call Home does not send an e-mail alerts when a link comes back online (LinkUp). It sends email alerts only for LinkDown events.

Detailed Steps

To configure general e-mail options, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters Call Home configuration submode.
Step 3	switch(config-callhome)# transport e-mail from user@company1.com	Optional. Configures the from e-mail address.
Step 4	switch(config-callhome)# transport e-mail reply-to person@place.com	Optional. Configures the reply-to e-mail address to which all responses should be sent.

Configuring HTTPS Support

Any predefined or user-defined destination profiles can be configured with the HTTPS URL address.

Detailed Steps

To configure the HTTPS URL address for any destination profile, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters Call Home configuration submode.
Step 3	switch(config-callhome)# destination-profile full-txt-destination http https://httpssever.com/Service	Optional. Configures the predefined full-txt-destination profile with a HTTPS URL address. The Call Home message in full-txt format is uploaded at the configured HTTPS URL address.
Step 4	switch(config-callhome)# destination-profile CiscoTAC-1 http https://httpssever.com/Service	Optional. Configures the predefined CiscoTAC-1 profile with a HTTPS URL address. The Call Home message in XML format is uploaded at the configured HTTPS URL address.
Step 5	switch(config-callhome)# destination-profile test1 http https://httpssever.com/Service	Optional. Configures the user-defined destination profile with a HTTPS URL address. The Call Home message in the configured format is uploaded at the configured HTTPS URL address.

Enable or Disable Transport Method

Any predefined or user-defined destination profiles can be configured to enable or disable a particular transport method. The transport methods are HTTP and e-mail.

Send documentation comments to mdsfeedback-doc@cisco.com

Detailed Steps

To enable or disable transport method for a destination profile, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters Call Home configuration submenu.
Step 3	switch(config-callhome)# destination-profile CiscoTAC-1 transport-method http	Optional. Enables predefined destination profile CiscoTAC-1 for HTTP transport method. Note For user-defined destination profiles, e-mail is the default. You can enable either or both transport mechanisms. If you disable both methods, e-mail will be enabled.
Step 4	switch(config-callhome)# no destination-profile CiscoTAC-1 transport-method email	Optional. Disables predefined destination profile CiscoTAC-1 for e-mail transport-method.
Step 5	switch(config-callhome)# destination-profile full-txt transport-method http	Optional. Enables predefined full-txt-destination profile for HTTP transport method.

Configuring an HTTP Proxy Server

Beginning with Cisco NX-OS Release 5.2, you can configure Smart Call Home to send HTTP messages through an HTTP proxy server. If you do not configure an HTTP proxy server, Smart Call Home sends HTTP messages directly to the Cisco Transport Gateway (TG).

Detailed Steps

To configure an HTTP proxy server, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters Call Home configuration submenu.
Step 3	switch(config-callhome)# transport http proxy server 192.0.2.1	Configures the HTTP proxy server domain name server (DNS) name, IPv4 address, or IPv6 address. Optionally configures the port number. The port range is from 1 to 65535. The default port number is 8080.
Step 4	switch(config-callhome)# transport http proxy enable	Enables Smart Call Home to send all HTTP messages through the HTTP proxy server. Note You can execute this command only after the proxy server address has been configured.
Step 5	switch(config-callhome)# show callhome transport	(Optional) Displays the transport-related configuration for Smart Call Home.



Note

The default value for full text destination and for XML is 1 MB.

Send documentation comments to mdsfeedback-doc@cisco.com

This example shows how to configure Smart Call Home to send HTTP messages through an HTTP proxy server:

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# callhome
switch(config-callhome)# transport http proxy server 10.10.10.1 port 4
switch(config-callhome)# transport http proxy enable
```

Configuring SMTP Server and Ports

This section includes the following topic:

- [Multiple SMTP Server Support, page 4-7](#)

Detailed Steps

To configure the SMTP server and port, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters Call Home configuration submenu.
Step 3	switch(config-callhome)# transport email smtp-server 192.168.1.1	Configures the DNS, IPv4 address, or IPv6 address of the SMTP server to reach the server. The port usage defaults to 25 if no port is specified. Note The port number is optional and, if required, may be changed depending on the server location.
	switch(config-callhome)# transport email smtp-server 192.168.1.1 port 30	

Configuring Multiple SMTP Server Support

To distribute the SMTP server configuration to devices running software releases prior to NX-OS Release 5.0 and earlier, use the following command:

```
switch(config-callhome)# transport email smtp-server
```

For multiple SMTP server capability, use the following command:

```
switch(config-callhome)# [no] transport email mail-server {ipv4 | IPV6 | hostname} [port port number] [priority priority number]
```

Example 4-1 shows how to configure multiple SMTP servers for Call Home messages:

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# callhome
switch(config-callhome)# transport email mail-server 192.0.2.10 priority 4
switch(config-callhome)# transport email mail-server 172.21.34.193
switch(config-callhome)# transport email smtp-server 10.1.1.174
switch(config-callhome)# transport email mail-server 64.72.101.213 priority 60
switch(config-callhome)# transport email from person@company.com
switch(config-callhome)# transport email reply-to person@company.com
```

Based on the configuration above, the SMTP servers would be contacted in this order:

Send documentation comments to mdsfeedback-doc@cisco.com

10.1.1.174 (priority 0)
 192.0.2.10 (priority 4)
 172.21.34.193 (priority 50 - default)
 64.72.101.213 (priority 60)

The **transport email mail-server** command is distributed only to devices running NX-OS Release 5.0(1a) or later. The **transport email smtp-server** command is distributed only to devices running earlier software releases.

Enabling Periodic Inventory Notifications

When you enable this feature without configuring an interval value, the Call Home message is sent every 7 days. This value ranges from 1 to 30 days. By default, this feature is disabled in all switches in the Cisco MDS 9000 Family and Cisco Nexus 5000 Series switches.

Detailed Steps

To enable periodic inventory notification in a Cisco MDS 9000 Family switch or a Cisco Nexus 5000 Series switch, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters the Call Home configuration submenu.
Step 3	switch(config-callhome)# periodic-inventory notification	Enables the periodic inventory notification feature. By default, the Call Home message is sent every 7 days.
	switch(config-callhome)# no periodic-inventory notification	Disables the periodic inventory notification feature (default).
Step 4	switch(config-callhome)# periodic-inventory notification interval 15	Configures the periodic inventory notification message to be sent every 15 days. This value ranges from 1 to 30 days.
	switch(config-callhome)# no periodic-inventory notification interval 15	Defaults to using the factory default of sending a Call Home message every 7 days.

Configuring Duplicate Message Throttle

You can configure a throttling mechanism to limit the number of Call Home messages received for the same event. If the same message is sent multiple times from the switch within a short period of time, you may be swamped with a large number of duplicate messages.

Restrictions

- By default, this feature is enabled in all switches in the Cisco MDS 9000 Family and the Cisco Nexus 5000 Series switches. When enabled, if the number of messages sent exceeds the maximum limit of 30 messages within the 2-hour time frame, then additional messages for that alert type are discarded within that time frame. You cannot modify the time frame or the message counter limit.

Send documentation comments to mdsfeedback-doc@cisco.com

- If 2 hours have elapsed since the first such message was sent and a new message has to be sent, then the new message is sent and the time frame is reset to the time when the new message was sent and the count is reset to 1.

Detailed Steps

To enable message throttling in a Cisco MDS 9000 Family switch or a Cisco Nexus 5000 Series switch, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters the Call Home configuration submode.
Step 3	switch(config-callhome)# no duplicate-message throttle	Disables the duplicate message throttling feature.
	switch(config-callhome)# duplicate-message throttle	Enables the duplicate message throttling feature (default).

Enabling Call Home Fabric Distribution

Detailed Steps

To enable Call Home fabric distribution, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters Call Home configuration submode.
Step 3	switch(config-callhome)# distribute	Enables Call Home configuration distribution to all switches in the fabric. Acquires a fabric lock and stores all future configuration changes in the pending database.
	switch(config-callhome)# no distribute	Disables (default) Call Home configuration distribution to all switches in the fabric.

To commit the Call Home configuration changes, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters Call Home configuration submode.
Step 3	switch(config-callhome)# commit	Distributes the configuration changes to all switches in the fabric and releases the lock. Overwrites the effective database with the changes made to the pending database.

Send documentation comments to mdsfeedback-doc@cisco.com

To discard the Call Home configuration changes, follow these steps:

	Command	Purpose
Step 1	switch# config t	Enters configuration mode.
Step 2	switch(config)# callhome switch(config-callhome)#	Enters Call Home configuration submode.
Step 3	switch(config-callhome)# abort	Discards the configuration changes in the pending database and releases the fabric lock.

Fabric Lock Override

To use administrative privileges and release a locked Call Home session, use the **clear callhome session** command.

```
switch# clear callhome session
```

To use administrative privileges and release a locked Call Home session, use the **clear callhome session** command.

```
switch# clear callhome session
```

Call Home Communications Test

You can test Call Home communications by sending a test message to the configured destination(s) or sending a test inventory message to the configured destination(s).

Detailed Steps

Use the **test** command to simulate a message generation.

To test the Call Home function, follow these steps:

	Command	Purpose
Step 1	switch# callhome test trying to send test callhome message successfully sent test callhome message	Sends a test message to the configured destination(s).
Step 2	switch# callhome test inventory trying to send test callhome message successfully sent test callhome message	Sends a test inventory message to the configured destination(s).

Configuring Delayed Traps

Detailed Steps

To enable the delayed trap feature, perform this task:

	Command	Purpose
Step 1	switch# config t switch(config)#	Enters configuration mode.

Send documentation comments to mdsfeedback-doc@cisco.com

	Command	Purpose
Step 2	switch(config)# system delayed-traps enable mode <i>FX</i>	Enables the system-delayed trap feature.
Step 3	switch(config)# system delayed-traps timer <1-60>	Configures the system-delayed trap timeout value. If no value is entered, a default value of 4 minutes is used. You can choose any value between 1 to 60 minutes.

To disable the delayed trap feature, perform this task:

	Command	Purpose
Step 1	switch# config t switch(config)#	Enters configuration mode.
Step 2	switch(config)# no system delayed-traps enable mode <i>FX</i>	Disables the system-delayed trap feature. This command is used only for the F/FL operationally UP ports. This feature does not apply to E/TE links. By default, this feature is disabled. You have to explicitly enable this feature. Enabling the feature will not affect the existing link-level traps.

Verifying Call Home Configuration

To display the Call Home configuration information, perform one of the following tasks:

- [Displaying Call Home Information, page 4-37](#)
- [Verifying Alert Group Customization, page 4-39](#)
- [Verifying Event Notification Trap, page 4-39](#)[Verifying Call Home Transport, page 4-40](#)
- [Verifying the Number of Name Server Database Entries, page 4-40](#)

Displaying Call Home Information

Use the **show callhome** command to display the configured Call Home information (see Examples 4-1 to 4-7).

Example 4-1 Displays Configured Call Home Information

```
switch# show callhome
callhome enabled
Callhome Information:
contact person name:who@where
contact person's e-mail:person@place.com
contact person's phone number:310-408-4000
street addr:1234 Picaboo Street, Any city, Any state, 12345
site id:Site1ManhattanNewYork
customer id:Customer1234
contract id:Cisco1234
switch priority:0
```

Send documentation comments to mdsfeedback-doc@cisco.com

Example 4-2 Displays Information for All Destination Profiles (Predefined and User-Defined)

```
switch# show callhome destination-profile
XML destination profile information
maximum message size:500000
message format:XML
message-level:0
e-mail addresses configured:
alert groups configured:
cisco_tac

test destination profile information
maximum message size:100000
message format:full-txt
message-level:5
e-mail addresses configured:
admin@yourcompany.com

alert groups configured:
test

full-txt destination profile information
maximum message size:500000
message format:full-txt
message-level:0
e-mail addresses configured:

alert groups configured:
all

short-txt destination profile information
maximum message size:4000
message format:short-txt
message-level:0
e-mail addresses configured:
alert groups configured:
all
```

Example 4-3 Displays Information for a User-defined Destination Profile

```
switch# show callhome destination-profile test
test destination profile information
maximum message size:100000
message format:full-txt
message-level:5
e-mail addresses configured:
user@company.com
alert groups configured:
test
```

Example 4-4 Displays the Full-Text Profile

```
switch# show callhome destination-profile profile full-txt-destination
full-txt destination profile information
maximum message size:250000
e-mail addresses configured:
person2@company2.com
```

Example 4-5 Displays the Short-Text Profile

```
switch# show callhome destination-profile profile short-txt-destination
Short-txt destination profile information
```

Send documentation comments to mdsfeedback-doc@cisco.com

```
maximum message size:4000
e-mail addresses configured:
person2@company2.com
```

Example 4-6 Displays the XML Destination Profile

```
switch# show callhome destination-profile profile XML-destination
XML destination profile information
maximum message size:250000
e-mail addresses configured:
findout@.cisco.com
```

Example 4-7 Displays E-Mail and SMTP Information

```
switch# show callhome transport-e-mail
from e-mail addr:user@company1.com
reply to e-mail addr:pointer@company.com
return receipt e-mail addr:user@company1.com
smtp server:server.company.com
smtp server port:25
```

Displaying Delayed Trap Information

Use the `show running-config | in delay` CLI command to display the system-delayed trap state as shown in [Example 4-8](#) and [Example 4-9](#). If no timer value is specified or if the timer value is set to 4 minutes, the following is displayed:

Example 4-8 Displays the Delayed Trap Information with No Timer Value (Set to the Default 4 Minutes)

```
switch# show running-config | in delay
system delayed-traps enable mode FX
switch#
```

If the timer value is set to any other value other than 4 minutes, [Example 4-9](#) is displayed:

Example 4-9 Displays the Delayed Trap Information with a Timer Value Other Than 4 Minutes

```
switch# show running-config | in delay
system delayed-traps enable mode FX
system delayed-traps timer 5
```

Verifying Alert Group Customization

To verify the alert group customization, use the `show callhome user-def-cmds` command.

```
switch# show callhome user-def-cmds
User configured commands for alert groups :
alert-group test user-def-cmd "show version"
```

Verifying Event Notification Trap

To verify the SNMP event notification trap, use the `show snmp trap | inc callhome` command.

```
switch# show snmp trap | inc callhome
callhome : event-notify Yes
```

Send documentation comments to mdsfeedback-doc@cisco.com

```
callhome : smtp-send-fail No
```

Verifying Call Home Transport

The **show callhome transport** command displays all of the transport-related configurations for Call Home.

```
switch# show callhome transport
http vrf:management

from email addr:xyz-1@cisco.com
reply to email addr:xyz-1@cisco.com

smtp server:72.163.62.211
smtp server port:25
smtp server vrf:management
smtp server priority:0

http proxy server:10.64.65.52
http proxy server port:8080
http proxy status:Enabled
```

The following example shows how to configure SMTP server port:

```
switch# callhome
switch(config-callhome)# transport email mail-server 192.168.10.23 port 4
switch# config t
```

The following example shows how to configure SMTP server priority:

```
switch(config-callhome)# transport email mail-server 192.168.10.23 priority 60
switch# config t
```

Verifying the Number of Name Server Database Entries

To verify the number of name server database entries, follow these steps:

	Command	Purpose
Step 1	switch# show fcns internal info global	Displays the number of device entries in the name server database.
Step 2	switch# show fcns internal info	Displays the number of devices in the name server database at the end of the output.

Monitoring Call Home

This section includes the following topics:

- [Sample Syslog Alert Notification in Full-txt Format, page 4-41](#)
- [Sample Syslog Alert Notification in XML Format, page 4-41](#)
- [Sample RMON Notification in XML Format, page 4-44](#)

Send documentation comments to mdsfeedback-doc@cisco.com

Sample Syslog Alert Notification in Full-txt Format

```

source:MDS9000
Switch Priority:7
Device Id:DS-C9506@CFG@07120011
Customer Id:basu
Contract Id:123
Site Id:San Jose
Server Id:DS-C9506@CFG@07120011
Time of Event:2004-10-08T11:10:44
Message Name:SYSLOG_ALERT
Message Type:Syslog
Severity Level:2
System Name:10.76.100.177
Contact Name:Basavaraj B
Contact e-mail:admin@yourcompany.com
Contact Phone:+91-80-310-1718
Street Address:#71 , Miller's Road
Event Description:2004 Oct 8 11:10:44 10.76.100.177 %PORT-5-IF_TRUNK_UP: %$VSAN 1%$
Interface fc2/5, vsan 1 is up

syslog_facility:PORT
start chassis information:
Affected Chassis:DS-C9506
Affected Chassis Serial Number:FG@07120011
Affected Chassis Hardware Version:0.104
Affected Chassis Software Version:3.1(1)
Affected Chassis Part No:73-8607-01
end chassis information:

```

Sample Syslog Alert Notification in XML Format

```

<?xml version="1.0" encoding="UTF-8" ?>
<soap-env:Envelope xmlns:soap-env="http://www.w3.org/2003/05/soap-envelope">
<soap-env:Header>
<aml-session:Session xmlns:aml-session="http://www.cisco.com/2004/01/aml-session"
soap-env:mustUnderstand="true"
soap-env:role="http://www.w3.org/2003/05/soap-envelope/role/next">
<aml-session:To>http://tools.cisco.com/neddce/services/DDCEService</aml-session:To>
<aml-session:Path>
<aml-session:Via>http://www.cisco.com/appliance/uri</aml-session:Via>
</aml-session:Path>
<aml-session:From>http://www.cisco.com/appliance/uri</aml-session:From>
<aml-session:MessageId>1004:FOX090306QT:3E55A81A</aml-session:MessageId>
</aml-session:Session>
</soap-env:Header>
<soap-env:Body>
<aml-block:Block xmlns:aml-block="http://www.cisco.com/2004/01/aml-block">
<aml-block:Header>
<aml-block:Type>http://www.cisco.com/2005/05/callhome/syslog</aml-block:Type>
<aml-block:CreationDate>2003-02-21 04:16:18 GMT+00:00</aml-block:CreationDate>
<aml-block:Builder>
<aml-block:Name>MDS</aml-block:Name>
<aml-block:Version>4.1</aml-block:Version>
</aml-block:Builder>
<aml-block:BlockGroup>
<aml-block:GroupId>1005:FOX090306QT:3E55A81A</aml-block:GroupId>
<aml-block:Number>0</aml-block:Number>
<aml-block:IsLast>true</aml-block:IsLast>
<aml-block:IsPrimary>true</aml-block:IsPrimary>
<aml-block:WaitForPrimary>false</aml-block:WaitForPrimary>

```

Send documentation comments to mdsfeedback-doc@cisco.com

```

</aml-block:BlockGroup>
<aml-block:Severity>6</aml-block:Severity>
</aml-block:Header>
<aml-block:Content>
<ch:CallHome xmlns:ch="http://www.cisco.com/2005/05/callhome" version="1.0">
<ch:EventTime>2003-02-21 04:16:18 GMT+00:00</ch:EventTime>
<ch:MessageDescription>LICENSE_VIOLATION 2003 Feb 21 04:16:18 switch %$
%DAEMON-3-SYSTEM_MSG: &lt;&lt;%LICMGR-3-LOG_LICAPP_NO_LIC&gt;&gt; License file is missing
for feature SAN_EXTN_OVER_IP</ch:MessageDescription>
<ch:Event>
<ch>Type>syslog</ch>Type>
<ch:SubType>LICENSE_VIOLATION</ch:SubType>
<ch:Brand>Cisco</ch:Brand>
<ch:Series>MDS9000</ch:Series>
</ch:Event>
<ch:CustomerData>
<ch:UserData>
<ch:e-mail>esajjana@cisco.com</ch:e-mail>
</ch:UserData>
<ch:ContractData>
<ch:CustomerId>eeranna</ch:CustomerId>
<ch:SiteId>Bangalore</ch:SiteId>
<ch:ContractId>123</ch:ContractId>
<ch:DeviceId>DS-C9216I-K9@C@FOX090306QT</ch:DeviceId>
</ch:ContractData>
<ch:SystemInfo>
<ch>Name>switch</ch>Name>
<ch>Contact>Eeranna</ch>Contact>
<ch>Contacte-mail>esajjana@cisco.com</ch>Contacte-mail>
<ch:ContactPhoneNumber>+91-80-310-1718</ch:ContactPhoneNumber>
<ch:StreetAddress>#71, Miller&apos;s Road</ch:StreetAddress> </ch:SystemInfo>
</ch:CustomerData> <ch:Device> <rme:Chassis xmlns:rme="http://www.cisco.com/rme/4.0">
<rme:Model>DS-C9216I-K9</rme:Model>
<rme:HardwareVersion>1.0</rme:HardwareVersion>
<rme:SerialNumber>FOX090306QT</rme:SerialNumber>
</rme:Chassis>
</ch:Device>
</ch:CallHome>
</aml-block:Content>
<aml-block:Attachments>
<aml-block:Attachment type="inline">
<aml-block:Name>show logging logfile | tail -n 200</aml-block:Name> <aml-block:Data
encoding="plain">
<![CDATA[syslog_show:: command: 1055 param_count: 0
2003 Feb 21 04:11:48 %KERN-2-SYSTEM_MSG: Starting kernel... - kernel
2003 Feb 21 04:11:48 %KERN-3-SYSTEM_MSG: CMOS: Module initialized - kernel
2003 Feb 21 04:11:48 %KERN-2-SYSTEM_MSG: CARD TYPE: KING BB Index = 2344 - kernel
2003 Feb 21 04:12:04 %MODULE-5-ACTIVE_SUP_OK: Supervisor 1 is active (serial:
JAB100700MC)
2003 Feb 21 04:12:04 %PLATFORM-5-MOD_STATUS: Module 1 current-status is
MOD_STATUS_ONLINE/OK
2003 Feb 21 04:12:06 %IMAGE_DNLD-SLOT1-5-ADDON_IMG_DNLD_COMPLETE: Addon module image
download process completed. Addon Image download completed, installing image please wait..
2003 Feb 21 04:12:07 %IMAGE_DNLD-SLOT1-5-ADDON_IMG_DNLD_SUCCESSFUL: Addon module image
download and install process successful. Addon image installed.
2003 Feb 21 04:12:08 %KERN-3-SYSTEM_MSG: klm_af_xipc: Unknown parameter `start&apos; -
kernel
2003 Feb 21 04:12:08 %KERN-3-SYSTEM_MSG: klm_ips_portcfg: Unknown parameter `start&apos; -
kernel
2003 Feb 21 04:12:08 %KERN-3-SYSTEM_MSG: klm_flamingo: Unknown parameter `start&apos; -
kernel
2003 Feb 21 04:12:10 %PORT-5-IF_UP: Interface mgmt0 is up
2003 Feb 21 04:12:21 switch %LICMGR-3-LOG_LIC_FILE_MISSING: License file(s) missing for
feature ENTERPRISE_PKG.

```

Send documentation comments to mdsfeedback-doc@cisco.com

```

2003 Feb 21 04:12:21 switch %LICMGR-3-LOG_LIC_FILE_MISSING: License file(s) missing for
feature SAN_EXTN_OVER_IP.
2003 Feb 21 04:12:21 switch %LICMGR-3-LOG_LIC_FILE_MISSING: License file(s) missing for
feature ENTERPRISE_PKG.
2003 Feb 21 04:12:21 switch %LICMGR-3-LOG_LIC_FILE_MISSING: License file(s) missing for
feature SAN_EXTN_OVER_IP.
2003 Feb 21 04:12:23 switch %PLATFORM-5-MOD_STATUS: Module 1 current-status is
MOD_STATUS_ONLINE/OK
2003 Feb 21 04:12:23 switch %MODULE-5-MOD_OK: Module 1 is online (serial: JAB100700MC)
2003 Feb 21 04:12:25 switch %PORT-5-IF_DOWN_ADMIN_DOWN: %$VSAN 1%$ Interface fc1/1 is down
(Administratively down)
2003 Feb 21 04:12:25 switch %PORT-5-IF_DOWN_ADMIN_DOWN: %$VSAN 1%$ Interface fc1/2 is down
(Administratively down)
2003 Feb 21 04:12:25 switch %PORT-5-IF_DOWN_ADMIN_DOWN: %$VSAN 1%$ Interface fc1/3 is down
(Administratively down)
2003 Feb 21 04:12:25 switch %PORT-5-IF_DOWN_ADMIN_DOWN: %$VSAN 1%$ Interface fc1/4 is down
(Administratively down)
2003 Feb 21 04:12:26 switch %PLATFORM-5-PS_STATUS: PowerSupply 1 current-status is PS_FAIL
2003 Feb 21 04:12:26 switch %PLATFORM-2-PS_FAIL: Power supply 1 failed or shut down
(Serial number QCS1007109F)
2003 Feb 21 04:12:26 switch %PLATFORM-5-PS_FOUND: Power supply 2 found (Serial number
QCS1007109R)
2003 Feb 21 04:12:26 switch %PLATFORM-2-PS_OK: Power supply 2 ok (Serial number
QCS1007109R)
2003 Feb 21 04:12:26 switch %PLATFORM-5-PS_STATUS: PowerSupply 2 current-status is PS_OK
2003 Feb 21 04:12:26 switch %PLATFORM-2-PS_FANOK: Fan in Power supply 2 ok
2003 Feb 21 04:12:26 switch %PLATFORM-5-FAN_DETECT: Fan module 1 (Serial number
NWG0901031X) ChassisFan1 detected
2003 Feb 21 04:12:26 switch %PLATFORM-2-FAN_OK: Fan module ok
2003 Feb 21 04:12:26 switch %PLATFORM-2-CHASSIS_CLKMODOK: Chassis clock module A ok
2003 Feb 21 04:12:26 switch %PLATFORM-2-CHASSIS_CLKSRC: Current chassis clock source is
clock-A
2003 Feb 21 04:12:26 switch %PORT-5-IF_DOWN_ADMIN_DOWN: %$VSAN 1%$ Interface fc1/5 is down
(Administratively down)
2003 Feb 21 04:12:26 switch %PORT-5-IF_DOWN_ADMIN_DOWN: %$VSAN 1%$ Interface fc1/6 is down
(Administratively down)
2003 Feb 21 04:12:26 switch %PORT-5-IF_DOWN_ADMIN_DOWN: %$VSAN 1%$ Interface fc1/7 is down
(Administratively down)
2003 Feb 21 04:12:26 switch %PORT-5-IF_DOWN_ADMIN_DOWN: %$VSAN 1%$ Interface fc1/8 is down
(Administratively down)
2003 Feb 21 04:12:26 switch %PORT-5-IF_DOWN_ADMIN_DOWN: %$VSAN 1%$ Interface fc1/9 is down
(Administratively down)
2003 Feb 21 04:12:26 switch %PORT-5-IF_DOWN_ADMIN_DOWN: %$VSAN 1%$ Interface fc1/10 is
down (Administratively down)
2003 Feb 21 04:12:27 switch %PORT-5-IF_DOWN_ADMIN_DOWN: %$VSAN 1%$ Interface fc1/11 is
down (Administratively down)
2003 Feb 21 04:12:27 switch %PORT-5-IF_DOWN_ADMIN_DOWN: %$VSAN 1%$ Interface fc1/12 is
down (Administratively down)
2003 Feb 21 04:12:27 switch %PORT-5-IF_DOWN_ADMIN_DOWN: %$VSAN 1%$ Interface fc1/13 is
down (Administratively down)
2003 Feb 21 04:12:27 switch %PORT-5-IF_DOWN_ADMIN_DOWN: %$VSAN 1%$ Interface fc1/14 is
down (Administratively down)
2003 Feb 21 04:12:30 switch %PLATFORM-2-MOD_DETECT: Module 2 detected (Serial number
JAB0923016X) Module-Type IP Storage Services Module Model DS-X9304-SMIP
2003 Feb 21 04:12:30 switch %MODULE-2-MOD_UNKNOWN: Module type [25] in slot 2 is not
supported
2003 Feb 21 04:12:45 switch %VSHD-5-VSHD_SYSLOG_CONFIG_I: Configured from vty by root on
console0
2003 Feb 21 04:14:06 switch %VSHD-5-VSHD_SYSLOG_CONFIG_I: Configured from vty by admin on
console0
2003 Feb 21 04:15:12 switch %VSHD-5-VSHD_SYSLOG_CONFIG_I: Configured from vty by admin on
console0
2003 Feb 21 04:15:52 switch %SYSMGR-3-BASIC_TRACE: core_copy: PID 1643 with message Core
not generated by system for licmgr(0). WCOREDUMP(9) returned zero .

```

Send documentation comments to mdsfeedback-doc@cisco.com

```

2003 Feb 21 04:15:52 switch %SYSMGR-2-SERVICE_CRASHED: Service \"licmgr\" (PID 2272)
hasn't caught signal 9 (no core).
2003 Feb 21 04:16:18 switch %LICMGR-3-LOG_LIC_FILE_MISSING: License file(s) missing for
feature ENTERPRISE_PKG.
2003 Feb 21 04:16:18 switch %LICMGR-3-LOG_LIC_FILE_MISSING: License file(s) missing for
feature SAN_EXTN_OVER_IP.
2003 Feb 21 04:16:18 switch %LICMGR-3-LOG_LIC_FILE_MISSING: License file(s) missing for
feature ENTERPRISE_PKG.
2003 Feb 21 04:16:18 switch %LICMGR-3-LOG_LIC_FILE_MISSING: License file(s) missing for
feature SAN_EXTN_OVER_IP.
2003 Feb 21 04:16:18 switch %CALLHOME-2-EVENT: LICENSE_VIOLATION
2003 Feb 21 04:16:18 switch %CALLHOME-2-EVENT: LICENSE_VIOLATION
2003 Feb 21 04:16:18 switch %CALLHOME-2-EVENT: LICENSE_VIOLATION
2003 Feb 21 04:16:18 switch %CALLHOME-2-EVENT: LICENSE_VIOLATION ]]> </aml-block:Data>
</aml-block:Attachment> <aml-block:Attachment type="inline"> <aml-block:Name>show license
usage</aml-block:Name> <aml-block:Data encoding="plain">
<![CDATA[Feature                               Ins Lic   Status Expiry Date Comments
                                         Count
-----
DMM_184_PKG                               No    0   Unused                Grace expired
FM_SERVER_PKG                             No    -   Unused                Grace expired
MAINFRAME_PKG                             No    -   Unused                Grace expired
ENTERPRISE_PKG                            Yes   -   Unused never          license missing
DMM_FOR_SSM_PKG                           No    0   Unused                Grace expired
SAN_EXTN_OVER_IP                          Yes   8   Unused never          8 license(s) missing
PORT_ACTIVATION_PKG                       No    0   Unused                -
SME_FOR_IPS_184_PKG                       No    0   Unused                Grace expired
STORAGE_SERVICES_184                     No    0   Unused                Grace expired
SAN_EXTN_OVER_IP_18_4                     No    0   Unused                Grace expired
SAN_EXTN_OVER_IP_IPS2                     No    0   Unused                Grace expired
SAN_EXTN_OVER_IP_IPS4                     No    0   Unused                Grace expired
STORAGE_SERVICES_SSN16                    No    0   Unused                Grace expired
10G_PORT_ACTIVATION_PKG                   No    0   Unused                -
STORAGE_SERVICES_ENABLER_PKG              No    0   Unused                Grace expired
-----
**** WARNING: License file(s) missing. **** ]]]> </aml-block:Data> </aml-block:Attachment>
</aml-block:Attachments> </aml-block:Block> </soap-env:Body> </soap-env:Envelope>

```

Sample RMON Notification in XML Format

```

<?xml version="1.0" encoding="UTF-8" ?>
<soap-env:Envelope xmlns:soap-env="http://www.w3.org/2003/05/soap-envelope">
<soap-env:Header>
<aml-session:Session xmlns:aml-session="http://www.cisco.com/2004/01/aml-session"
soap-env:mustUnderstand="true"
soap-env:role="http://www.w3.org/2003/05/soap-envelope/role/next">
<aml-session:To>http://tools.cisco.com/neddce/services/DDCEService</aml-session:To>
<aml-session:Path>
<aml-session:Via>http://www.cisco.com/appliance/uri</aml-session:Via>
</aml-session:Path>
<aml-session:From>http://www.cisco.com/appliance/uri</aml-session:From>
<aml-session:MessageId>1086:FHH0927006V:48BA26BD</aml-session:MessageId>
</aml-session:Session>
</soap-env:Header>
<soap-env:Body>
<aml-block:Block xmlns:aml-block="http://www.cisco.com/2004/01/aml-block">
<aml-block:Header>
<aml-block:Type>http://www.cisco.com/2005/05/callhome/diagnostic</aml-block:Type>
<aml-block:CreationDate>2008-08-31 05:06:05 GMT+00:00</aml-block:CreationDate>
<aml-block:Builder>
<aml-block:Name>MDS</aml-block:Name>
<aml-block:Version>4.1</aml-block:Version>

```

Send documentation comments to mdsfeedback-doc@cisco.com

```

</aml-block:Builder>
<aml-block:BlockGroup>
<aml-block:GroupId>1087:FHH0927006V:48BA26BD</aml-block:GroupId>
<aml-block:Number>0</aml-block:Number>
<aml-block:IsLast>true</aml-block:IsLast>
<aml-block:IsPrimary>true</aml-block:IsPrimary>
<aml-block:WaitForPrimary>>false</aml-block:WaitForPrimary>
</aml-block:BlockGroup>
<aml-block:Severity>2</aml-block:Severity>
</aml-block:Header>
<aml-block:Content>
<ch:CallHome xmlns:ch="http://www.cisco.com/2005/05/callhome" version="1.0">
<ch:EventTime>2008-08-31 05:06:05 GMT+00:00</ch:EventTime>
<ch:MessageDescription>RMON_ALERT WARNING(4) Falling:iso.3.6.1.4.1.9.9.305.1.1.1.0=1 &lt;=
89:1, 4</ch:MessageDescription>
<ch:Event>
<ch>Type>diagnostic</ch>Type>
<ch:SubType>GOLD-major</ch:SubType>
<ch:Brand>Cisco</ch:Brand>
<ch:Series>MDS9000</ch:Series>
</ch:Event>
<ch:CustomerData>
<ch:UserData>
<ch:e-mail>mchinn@cisco.com</ch:e-mail>
</ch:UserData>
<ch:ContractData>
<ch:CustomerId>12ss</ch:CustomerId>
<ch:SiteId>2233</ch:SiteId>
<ch:ContractId>rrr55</ch:ContractId>
<ch:DeviceId>DS-C9513@C@FHH0927006V</ch:DeviceId>
</ch:ContractData>
<ch:SystemInfo>
<ch>Name>sw172-22-46-174</ch>Name>
<ch>Contact>Mani</ch>Contact>
<ch>Contacte-mail>mchinn@cisco.com</ch>Contacte-mail>
<ch>ContactPhoneNumber>+1-800-304-1234</ch>ContactPhoneNumber>
<ch:StreetAddress>1234 wwee</ch:StreetAddress>
</ch:SystemInfo>
</ch:CustomerData>
<ch:Device>
<rme:Chassis xmlns:rme="http://www.cisco.com/rme/4.0">
<rme:Model>DS-C9513</rme:Model>
<rme:HardwareVersion>0.205</rme:HardwareVersion>
<rme:SerialNumber>FHH0927006V</rme:SerialNumber>
</rme:Chassis>
</ch:Device>
</ch:CallHome>
</aml-block:Content>
</aml-block:Block>
</soap-env:Body>
</soap-env:Envelope>

```

Additional References

For additional information related to implementing Call Home, see the following section:

- [MIBs, page 4-46](#)

[Send documentation comments to mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com)

MIBs

MIBs	MIBs Link
<ul style="list-style-type: none"> CISCO-CALLHOME-CAPABILITY-MIB CISCO-CALLHOME-MIB 	To locate and download MIBs, go to the following URL: http://www.cisco.com/en/US/products/ps5989/prod_technical_reference_list.html

Feature History for Call Home

Table 4-10 lists the release history for this feature. Only features that were introduced or modified in Release 3.x or a later release appear in the table.

Table 4-10 Feature History for Call Home
Table 4-10

Feature Name	Releases	Feature Information
Call Home HTTP Proxy Server	5.2	Added the Call Home HTTP Proxy Server support details.
Call Home HTTP Proxy Server	5.2	Added the Call Home HTTP Proxy Server support details. Added Verifying Callhome Transport commands.
Multiple SMTP Server Support	5.0(1a)	Added Multiple SMTP Server Support details. Added Verifying Callhome Transport commands.
Notification Enhancements	5.0(1a)	Added the enhancement in Notification in the Event Filter Using Device Manager.
Call Home	4.1(1b)	Added the HTTPS support for Call Home.
Call Home - Delayed Traps for EMC Call Home configuration window in DCNM-SAN.	4.1(1a)	Added the delayed traps enhancements for EMC Call Home.
Call Home Destination tab	4.2(1)	Added the enhancement in Destination tab.
Call Home HTTPs support	4.2(1)	Added Call Home HTTPs enhancement.
EMC Email Home	3.3(3)	EMC Email Home configuration information was added to this chapter.
EMC Call Home	3.0(1)	Enables the forwarding of traps as XML data using email, according to EMC specifications.
Call Home enhancement	3.0(1)	Enables customization of alert group messages.