



I Commands

This chapter describes the Cisco Nexus Cloud Services Platform commands that begin with the letter I.

import

To import a previously saved backup copy of a virtual service blade (VSB) from remote storage to the Cisco Nexus 1010, use the **import** command.

import [primary | secondary] filename

Syntax	Description
primary	(Optional) The Cisco Nexus 1010 that was assigned the primary role.
secondary	(Optional) The Cisco Nexus 1010 that was assigned the secondary role.
filename	Import file name.

Defaults	None
----------	------

Command Modes	Virtual service blade configuration (config-vsb-config)
---------------	---------------------------------------------------------

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.2(1)SP1(3)	This command was introduced.

Usage Guidelines If importing to a redundant pair of Cisco Nexus 1010s, you must specify whether importing to the primary or secondary.

You have verified that the bootflash: export-import directory is empty. If files are present in this directory, you must delete them before importing a VSB configuration file.

import

Send document comments to nexus1k-docfeedback@cisco.com.

Before importing, you have copied the exported image file from remote storage into the Cisco Nexus 1010 export-import folder in the bootflash: repository.

Examples

This example shows how to import the image file Vdisk1.img.tar.00 to the primary VSB vsm-1 and power off the VSB:

```
n1010# configure terminal
n1010(config) virtual-service-blade vsm-1
n1010-1(config-vsbl-config)# import primary Vdisk1.img.tar.00
Note: import started..
Note: please be patient..
Note: Import cli returns check VSB status for completion
n1010-1(config-vsbl-config)#

```

Related Commands

Command	Description
export	Exports a VSB configuration file from the Cisco Nexus 1010.
show network	Displays information about the network.
show	Displays information about virtual services.
virtual-service-blade	
show virtual-service-blade-type summary	Displays a summary of all virtual service configurations by type, such as Virtual Supervisor Module (VSM) or Network Analysis and Monitoring (NAM).

Send document comments to nexus1k-docfeedback@cisco.com.

install nexus1010

To install management software for the Cisco Nexus 1010, use the **install nexus1010** command.

install nexus1010 {bootflash: *path*}

Syntax Description	bootflash: Specifies a path from the bootflash directory. <i>path</i> Full path to the image file (.iso)
---------------------------	---------------------------------------------------------------------------------------------------------------------------

Defaults	None
-----------------	------

Command Modes	EXEC
----------------------	------

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

Usage Guidelines	You can view the available installation image files by using the dir command. For example:
-------------------------	---------------------------------------------------------------------------------------------------

```
n1010# dir bootflash:
n
    77824      Mar 27 06:02:44 2010  accounting.log
    16384      Mar 26 22:31:33 2010  lost+found/
      5023      Jan 18 00:23:37 2009  mts.log
    48346519    Jan 15 21:33:25 2001  nexus-1010-mzg.4.0.4.SP1.0.171.bin
      4096      Jan 15 21:27:11 2001  repository/

Usage for bootflash://
 308473856 bytes used
 3682906112 bytes free
 3991379968 bytes total
n1010# cd repository
n1010# dir

    77824      Jan 24 05:02:49 2001  accounting.log
      370      Jan 24 05:03:02 2001  cppa_mgr.log
    16384      Jan 15 21:33:09 2001  lost+found/
    1331914    Jan 15 21:33:21 2001  nexus-1010.4.0.4.SP1.0.197.iso
    20971008    Jan 15 21:33:22 2001  nexus-1010-4.0.4.SP1.0.171.iso

Usage for bootflash://
 308473856 bytes used
 3682906112 bytes free
 3991379968 bytes total
Nexus1010#
```

install nexus1010

Send document comments to nexus1k-docfeedback@cisco.com.

Examples

This example shows how to install management software for the Cisco Nexus 1010:

```
n1010# install nexus1010 bootflash:repository/nexus-1010.4.0.4.SP1.0.197.iso
cpa_mgr debug: Using URI: bootflash:/repository/nexus-1010.4.0.4.SP1.0.197.iso
Installing bootflash:/repository/nexus-1010.4.0.4.SP1.0.197.iso
.
.
.
Installation complete.
Save configuration and restart for changes to take effect

n1010#
#
```

Related Commands

Command	Description
copy running-config startup-config	Copies the running configuration to the startup configuration.
dir	Displays the contents of a directory or file.

Send document comments to nexus1k-docfeedback@cisco.com.

interface mgmt

To configure the management interface and enter interface configuration mode, use the **interface management** command.

interface mgmt0

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Global configuration (config)
Interface configuration (config-if)

SupportedUserRoles network-admin

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

Usage Guidelines Use the **interface mgmt0** command to configure the management interface and to enter the interface configuration mode.

Examples This example shows how to enter the interface configuration mode to configure the management interface:

```
n1010(config)# interface mgmt0  
n1010(config-if)#
```

Related Commands	Command	Description
	interface loopback	Create and configures a loopback interface.
	show interface brief	Displays a short version of the interface configuration.

 ■ **interface name mode passthrough**

Send document comments to nexus1k-docfeedback@cisco.com.

interface *name* mode passthrough

To configure a VSB interface in passthrough mode, use the **interface mode passthrough** command.

interface *name* mode passthrough

Syntax Description	<i>name</i>	name of the interface to configure in the passthrough mode.
---------------------------	-------------	-------------------------------------------------------------

Defaults	None
-----------------	------

Command Modes	VSB Interface configuration (config-vsb-config)
----------------------	-------------------------------------------------

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.2(1)SP1(6.1)	This command was introduced.

Usage Guidelines	<ul style="list-style-type: none"> This command can be used only in a flexible topology. Passthrough mode is currently available for VXLAN Gateway VSBs.
-------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Examples	This example shows how to configure a VXLAN Gateway VSB in the passthrough mode:
-----------------	----------------------------------------------------------------------------------

Send document comments to nexus1k-docfeedback@cisco.com.

```

switch(config)# virtual-service-blade VXGW
switch(config-vsbl-config)# virtual-service-blade-type new vxgw.4.2.1.SV2.1.1 iso
Note: please be patient.
switch(config-vsbl-config)# [no] interface vxgw_intf_1 uplink1 uplink GigabitEthernet2
switch(config-vsbl-config)#
switch(config-vsbl-config)# interface vxgw_intf_2 uplink2 uplink GigabitEthernet3
switch(config-vsbl-config)
switch(config-vsbl-config)# interface vxgw_intf_1 uplink1 mode passthrough
vxgw_intf_2 uplink2 mode passthrough
switch(config-vsbl-config)
switch(config-vsbl-config)#enable
Enter vsb image: [vxgw.4.2.1.SV2.1.1 iso]
Enter domain id[1-4095]: 4
Management IP version [V4/V6]:[V4]
Enter primary IP address: 10.105.234.50
Enter primary subnet mask: 255.255.255.224
IPv4 address of the default gateway: 10.105.234.33
Enter Hostname: vxgw
Enter the password for 'admin': pwd123
VSM L3 Ctrl IPv4 address: 10.105.234.53
VSM Primary MAC Address: 00:02:3d:78:c4:0c
Enter VSM uplink port-profile name: UPLINK-VXGW
Enter Encapsulation port-profile name: vxlangw-tvlan1495
Note: VSB installation is in progress, please use show virtual-service-blade commands to
check the installation status.
switch(config-vsbl-config)
```

Related Commands

Command	Description
virtual-service-blade- name name	Create and configures a loopback interface.
show network summary	Displays a summary of all VSBs including the ones configured in passthrough mode.

interface GigabitEthernet

Send document comments to nexus1k-docfeedback@cisco.com.

interface GigabitEthernet

To configure the Gigabit Ethernet interface and enter the interface configuration mode, use the **interface GigabitEthernet** command.

interface GigabitEthernet *id*

Syntax	Description
	<i>id</i> ID of the Gigabit Ethernet interface [intf-id].

Defaults	None
-----------------	------

Command Modes	Interface configuration (config-if)
----------------------	-------------------------------------

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.2(1)SP1(4)	This command was introduced.

Examples	This example shows how to enter the interface configuration mode on GigabitEthernet4:
	<pre>n1010# configure terminal n1010(config)# interface GigabitEthernet4 n1010(config-if)#</pre>

Related Commands	Command	Description
	show interface brief	Displays a short version of the interface configuration.
	show interface ethernet	Displays information about the Ethernet interface.
	show interface mgmt0	Displays information about the traffic on the management interface.
	show interface vethernet	Displays information about the traffic on the specified virtual Ethernet interface.

Send document comments to nexus1k-docfeedback@cisco.com.

interface PortChannel

To configure a port channel interface and enter the interface configuration mode, use the **interface PortChannel** command.

interface PortChannel *id*

Syntax	<i>id</i>	ID of the port channel interface [intf-id].
--------	-----------	---------------------------------------------

Defaults	None
----------	------

Command Modes	Interface configuration (config-if)
---------------	-------------------------------------

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.2(1)SP1(4)	This command was introduced.

Examples	This example shows how to enter the interface configuration mode on a port channel:
	<pre>n1010# configure terminal n1010(config)# interface PortChannel1 n1010(config-if)#</pre>

Related Commands	Command	Description
	show interface brief	Displays a short version of the interface configuration.
	show interface ethernet	Displays information about the Ethernet interface.
	show interface mgmt0	Displays information about the traffic on the management interface.
	show interface vethernet	Displays information about the traffic on the specified virtual Ethernet interface.

interface VsbEthernet

Send document comments to nexus1k-docfeedback@cisco.com.

interface VsbEthernet

To configure the virtual service blade (VSB) Ethernet interface and enter interface configuration mode, use the **interface VsbEthernet** command.

interface VsbEthernet *name*

Syntax	Description
	name Name of virtual service blade interfaceVsbEthernet [vb-id intf-id].

Defaults	None
-----------------	------

Command Modes	Global configuration (config)
----------------------	-------------------------------

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.2(1)SP1(3)	This command was introduced.

Examples	This example shows how to enter the interface configuration mode on VsbEthernet 1/1/2:
	<pre>n1010# configure terminal n1010(config)# interface vsbEthernet 1/1/2 n1010(config-if)#</pre>

Related Commands	Command	Description
	show interface brief	Displays a short version of the interface configuration.
	show interface ethernet	Displays information about the Ethernet interface.
	show interface mgmt0	Displays information about the traffic on the management interface.
	show interface vethernet	Displays information about the traffic on the specified virtual Ethernet interface.

Send document comments to nexus1k-docfeedback@cisco.com.

interface uplink

To assign an uplink to the virtual service blade (VSB) Ethernet interface , use the **interface uplink** command.

interface name uplink name

Syntax	<i>name</i>	Name of the uplink for the interface.
---------------	-------------	---------------------------------------

Defaults	None
-----------------	------

Command Modes	VSB configuration (config-vsbd-config)
----------------------	----------------------------------------

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.2(1)SP1(4)	This command was introduced.

Examples	This example shows how to assign an uplink to VSB:
-----------------	----------------------------------------------------

```
n1010# configure terminal
n1010(config-vsbd-config)#interface control vlan 347
n1010(config-vsbd-config)#interface control uplink PortChannel12
n1010(config-vsbd-config)#

```

Related Commands	Command	Description
	show network summary	Displays network summary information.

ip address

Send document comments to nexus1k-docfeedback@cisco.com.

ip address

To create an IP route, use the **ip address** command. To remove an IP address, use the **no** form of this command.

ip address {address mask | prefix} {next-hop | next-hop-prefix | interface-type interface-number}
[tag tag-value | preference]

no ip address {address mask | prefix} {next-hop | next-hop-prefix | interface-type interface-number}
[secondary | tag tag-value | preference]

Syntax Description	
<i>address</i>	IP address, in format A.B.C.D.
<i>mask</i>	IP network mask, in format A.B.C.D.
<i>prefix</i>	IP prefix and network mask length, in format A.B.C.D/LEN.
<i>next-hop</i>	IP next-hop address, in format A.B.C.D.
<i>next-hop-prefix</i>	IP next-hop prefix in format A.B.C.D./LEN.
<i>interface-type</i>	Interface type.
<i>interface-number</i>	Interface or subinterface number.
secondary	(Optional) Configures additional IP addresses on the interface.
tag	(Optional) Specifies a supply tag.
<i>tag-value</i>	Supply tag value. The range of valid values is from 0 to 4294967295. The default is 0.
<i>preference</i>	(Optional) Route preference.

Defaults	None
-----------------	------

Command Modes	Global configuration (config)
----------------------	-------------------------------

SupportedUserRoles	network-admin
---------------------------	---------------

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

Examples	This example shows how to create an IP address:
	<pre>n1010(config)# configure terminal n1010(config)# ip address 209.165.200.225 255.255.255.224 x n1010(config)#</pre>

Send document comments to nexus1k-docfeedback@cisco.com.

Related Commands	Command	Description
	show ip interface	Displays interfaces for local IP addresses.
	A.B.C.D.	

■ ip address

Send document comments to nexus1k-docfeedback@cisco.com.