



Installing a VSM on the Cisco Cloud Services Platform

You can install the Cisco Nexus 1000V VSM on the Cisco Cloud Services Platform. For more information, see the documentation at <http://www.cisco.com/en/US/products/ps12752/index.html>.



Note

Layer 3 mode is supported for the Cisco Nexus 1000V for Hyper-V.

Installing Cisco Nexus 1000V VSM on Cisco Cloud Service

Prerequisites to Install Cisco Nexus 1000V VSM

Copy the ISO file to the boot flash:repository/ of the virtual service blade as displayed in the following example:

```
switch(config)# dir boot flash:repository
16384      Feb 21 11:31:10 20132018  lost+found/
169932800 May 08 20:20:09 2018  Nexus-1000V.5.2.1.SM3.2.1.iso
653       May 08 20:28:24 2018  vmpresults.txt
```

```
Usage for bootflash://sup-local
326832128 bytes used
3664547840 bytes free
3991379968 bytes total
switch(config)#
```

Installing Cisco Nexus 1000V VSM

Complete the following steps to install the VSM on the Cloud Services Platform:

Step 1 Create a virtual service blade by entering the following commands:

```
switch(config)# show virtual-service-blade summary
```

```
-----
Name           HA-Role      HA-Status    Status      Location
-----
```

```
switch(config)# virtual-service-blade vsm-1
```

```
switch(config-vs-b-config)# virtual-service-blade-type new Nexus-1000V.5.2.1.SM3.2.1.iso
switch(config-vs-b-config)# show virtual-service-blade summary
-----
Name           HA-Role      HA-Status    Status                Location
-----
vsm-1          PRIMARY      NONE         VSB NOT PRESENT      PRIMARY
vsm-1          SECONDARY    NONE         VSB NOT PRESENT      SECONDARY
switch(config-vs-b-config)#
```

- Step 2** Configure the control and packet VLANs for static and flexible topologies. Note that no provisioning is allowed for a management VLAN because the management class interface uses the management VLAN of the Cisco Cloud Services Platform.

```
switch(config-vs-b-config)# interface control vlan 391
switch(config-vs-b-config)# interface packet vlan 392
```

- Step 3** Configure the Cisco Nexus 1000V on the Cisco Cloud Services Platform.

```
switch(config-vs-b-config)# enable
Enter vsb image: [Nexus-1000V.5.2.1.SM3.2.1.iso]
Enter domain id[1-1023]: 391
Management IP version [V4/V6]: [V4]
Enter Management IP address: 172.16.5.5
Enter Management subnet mask: 255.255.255.0
IPv4 address of the default gateway: 172.16.5.1
Enter HostName: vsm-1
Enter the password for 'admin': *****
Note: VSB installation is in progress, please use show virtual-service-blade commands to
check the installation status.
switch(config-vs-b-config)#
```

- Step 4** Display the primary and secondary VSM status.

```
switch(config-vs-b-config)#show virtual-service-blade summary
-----
Name           HA-Role      HA-Status    Status                Location
-----
VSM-1          PRIMARY      NONE         VSB DEPLOY IN PROGRESS PRIMARY
VSM-1          SECONDARY    NONE         VSB NOT PRESENT      SECONDARY
switch(config-vs-b-config)#
```

- Step 5** Log in to the VSM.

```
switch(config)# virtual-service-blade vsm-1
switch(config-vs-b-config)# login virtual-service-blade vsm-1
Telnet escape character is '^\'
Trying 172.1.0.18...
Connected to 172.1.0.18.
Escape character is '^\'

Nexus 1000v Switch
vsm-1 login: admin
Password:
Cisco Nexus operating System (NX-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (c) 2002-2014, Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained in this software are
owned by other third parties and used and distributed under
license. Certain components of this software are licensed under
the GNU General Public License (GPL) version 2.0 or the GNU
Lesser General Public License (LGPL) Version 2.1. A copy of each
such license is available at
http://www.opensource.org/licenses/gpl-2.0.php and
http://www.opensource.org/licenses/lgpl-2.1.php
```

```
switch# show system redundancy status
Redundancy role
-----
      administrative:  primary
      operational:    primary

Redundancy mode
-----
      administrative:  HA
      operational:    HA

This supervisor (sup-1)
-----
      Redundancy state:  Active
      Supervisor state:  Active
      Internal state:   Active with HA standby

Other supervisor (sup-2)
-----
      Redundancy state:  Standby
      Supervisor state:  HA standby
      Internal state:   HA standby
switch#
```
