



## C Commands

---

This chapter describes the Cisco Nexus Virtual Services Appliance commands that begin with the letter C.

### cd

To change to a different directory from the one you are currently working in, use the **cd** command.

```
cd [filesystem:[//directory] | directory]
```

Syntax Description	
<i>filesystem:</i>	(Optional) Name of the file system. Valid file systems are <b>bootflash</b> and <b>volatile</b> .
<i>//directory</i>	(Optional) Name of the directory. The directory name is case sensitive.

Defaults	
<b>bootflash</b>	

Command Modes	
Any command mode	

SupportedUserRoles	
network-admin	

Release	Modification
4.0(4)SP1(1)	This command was introduced.

Usage Guidelines	
You can only change to the directories that are on the active VSM.	
Use the present working directory ( <b>pwd</b> ) command to verify the name of the directory you are currently working in.	

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

---

**Examples**

This example shows how to change to a different directory on the current file system:

```
n1010# cd my-scripts
```

This example shows how to change from the file system you are currently working in to a different file system:

```
n1010# cd volatile:
```

This example shows how to revert back to the default directory, bootflash:

```
n1010# cd
```

---

**Related Commands**

Command	Description
<code>pwd</code>	Displays the name of the directory you are currently working in.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## cdp advertise

To specify the Cisco Discovery Protocol (CDP) version to advertise, use the **cdp advertise** command. To remove the **cdp advertise** configuration, use the **no** form of this command.

```
cdp advertise {v1 | v2}
```

```
no cdp advertise [v1 | v2]
```

Syntax Description	v1	CDP Version 1.
	v2	CDP Version 2.

**Defaults** CDP Version 2

**Command Modes** Global configuration (config)

**Supported User Roles** network-admin

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Examples** This example shows how to set CDP Version 1 as the version to advertise:

```
n1010(config)# cdp advertise v1
```

This example shows how to remove CDP Version 1 as the configuration to advertise:

```
n1010(config)# no cdp advertise v1
```

Related Commands	Command	Description
	show cdp	Displays the CDP configuration.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## cdp enable (global)

To enable the Cisco Discovery Protocol (CDP) globally on all interfaces and port channels, use the **cdp enable** command. To disable CDP globally, use the **no** form of this command.

**cdp enable**

**no cdp enable**

**Syntax Description** This command has no arguments or keywords.

**Defaults** Enabled on all interfaces and port channels

**Command Modes** Global configuration (config)

**SupportedUserRoles** network-admin

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Usage Guidelines** CDP can only be configured on physical interfaces and port channels.

**Examples** This example shows how to enable CDP globally and then show the CDP configuration:

```
n1010# configure terminal
n1010(config)# cdp enable
n1010(config)# show cdp global
Global CDP information:
  CDP enabled globally
  Refresh time is 60 seconds
  Hold time is 180 seconds
  CDPv2 advertisements is enabled
  DeviceID TLV in System-Name(Default) Format
```

This example shows how to disable CDP globally and then show the CDP configuration:

```
n1010(config)# no cdp enable
n1010# show cdp global
Global CDP information:
  CDP disabled globally
  Refresh time is 60 seconds
  Hold time is 180 seconds
  CDPv2 advertisements is enabled
  DeviceID TLV in System-Name(Default) Format
n1010(config)#
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

Related Commands	Command	Description
	<b>cdp enable</b> (interface or port channel)	Enables CDP on an interface or port channel.
	<b>show cdp</b>	Displays the CDP configuration.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## cdp enable (interface or port channel)

To enable the Cisco Discovery Protocol (CDP) on an interface or port channel, use the **cdp enable** command. To disable it, use the **no** form of this command.

**cdp enable**

**no cdp enable**

---

**Syntax Description** This command has no arguments or keywords.

---

**Defaults** None

---

**Command Modes** Interface configuration (config-if)

---

**SupportedUserRoles** network-admin

---

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

---



---

**Usage Guidelines** CDP can only be configured on physical interfaces and port channels.

---

**Examples** This example shows how to enable CDP on port channel 2:

```
n1010# configure terminal
n1010(config)# interface port-channel2
n1010(config-if)# cdp enable
n1010(config-if)#
```

This example shows how to disable CDP on mgmt0:

```
n1010# configure terminal
n1010(config)# interface mgmt0
n1010(config-if)# no cdp enable
n1010(config-if)# show cdp interface mgmt0
    mgmt0 is up
    CDP disabled on interface
    Sending CDP packets every 60 seconds
    Holdtime is 180 seconds
n1010(config-if)#
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>cdp advertise</b>	Assigns the CDP version the interface will advertise—CDP Version 1 or CDP Version 2.
	<b>cdp format device-id</b>	Assigns the CDP device ID.
	<b>cdp holdtime</b>	Sets the maximum amount of time that CDP holds onto neighbor information before discarding it.
	<b>show cdp</b>	Displays the CDP configuration.
	<b>show cdp neighbors</b>	Displays your device from the upstream device.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## cdp format device-id

To specify the device ID format for Cisco Discovery Protocol (CDP), use the **cdp format device-id** command. To remove it, use the **no** form of this command.

```
cdp format device-id { mac-address | serial-number | system-name }
```

```
no cdp format device-id { mac-address | serial-number | system-name }
```

### Syntax Description

<b>mac-address</b>	Specifies the MAC address of the Chassis.
<b>serial-number</b>	Specifies the Chassis serial number.
<b>system-name</b>	Specifies the System name/Fully Qualified Domain Name (default).

### Defaults

System name/Fully Qualified Domain Name

### Command Modes

Global configuration (config)

### Supported User Roles

network-admin

### Command History

Release	Modification
4.0(4)SP1(1)	This command was introduced.

### Usage Guidelines

CDP must be enabled globally before you configure the device ID format. You can configure CDP on physical interfaces and port channels only.

### Examples

This example shows how to configure the CDP device ID with the MAC address format and then display the configuration:

```
n1010(config)# cdp format device-id mac-address
n1010(config)# show cdp global
Global CDP information:
CDP enabled globally
  Sending CDP packets every 5 seconds
  Sending a holdtime value of 10 seconds
  Sending CDPv2 advertisements is disabled
  Sending DeviceID TLV in Mac Address Format
```

This example shows how to remove the CDP device ID MAC address format from the configuration:

```
n1010(config)# no cdp format device-id mac-address
```



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>cdp advertise</b>	Assigns the CDP version the interface will advertise—CDP Version 1 or CDP Version 2.
	<b>cdp enable interface</b>	Enables CDP on an interface or port channel.
	<b>cdp holdtime</b>	Sets the maximum amount of time that CDP holds onto neighbor information before discarding it.
	<b>show cdp</b>	Displays the CDP configuration.
	<b>show cdp neighbors</b>	Displays your device from the upstream device.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## cdp holdtime

To set the maximum amount of time that Cisco Discovery Protocol (CDP) holds onto neighbor information before discarding it, use the **cdp holdtime** command. To remove the CDP holdtime configuration, use the **no** form of this command.

**cdp holdtime** *seconds*

**no cdp holdtime** *seconds*

<b>Syntax Description</b>	<i>seconds</i>	Maximum time that CDP holds on to neighbor information. The range is from 10 to 255 seconds.
<b>Defaults</b>	180 seconds	
<b>Command Modes</b>	Global configuration (config)	
<b>Supported User Roles</b>	network-admin	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.0(4)SP1(1)	This command was introduced.
<b>Usage Guidelines</b>	CDP must be enabled globally before you configure the device ID format. You can configure CDP on physical interfaces and port channels only.	
<b>Examples</b>	<p>This example shows how to set the CDP holdtime to 10 second:</p> <pre>n1010(config)# cdp holdtime 10</pre> <p>This example shows how to remove the CDP holdtime configuration:</p> <pre>n1010(config)# no cdp holdtime 10</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show cdp</b>	Displays the CDP configuration.
	<b>show cdp neighbors</b>	Displays the upstream device from your device.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## cdp timer

To set the refresh time for Cisco Discovery Protocol (CDP) to send advertisements to neighbors, use the **cdp timer** command. To remove the CDP timer configuration, use the **no** form of this command.

**cdp timer** *seconds*

**no cdp timer** *seconds*

Syntax Description	<i>seconds</i>	Time before CDP sends advertisements to neighbors. The range is from 5 to 254 seconds.
--------------------	----------------	--

Defaults	60 seconds
----------	------------

Command Modes	Global configuration (config)
---------------	-------------------------------

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Examples** This example shows how to configure the CDP timer to 10 seconds:

```
n1010(config)# cdp timer 10
```

This example shows how to remove the CDP timer configuration:

```
n1010(config)# no cdp timer 10
```

Related Commands	Command	Description
	<b>show cdp</b>	Displays the CDP configuration.
	<b>show cdp neighbors</b>	Displays the upstream device from your device.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## channel-group

To move an interface from one port channel group to another, use the **channel-group** command. To remove the interface, use the **no** form of this command.

**channel-group** *id* **mode** { **ha** | **active** }

**no channel-group** [*id*]

Syntax Description		
<b>id</b>	Specifies the port channel id of the interface. The valid port channel ID range is 1-6.	
<b>mode</b>	Specifies the port channel mode of the interface. The mode can be either HA or Active.	

Defaults	None
----------	------

Command Modes	Interface Configuration (config-if)
---------------	-------------------------------------

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.2(1)SP1(4)	This command was introduced.

**Examples** This example shows how to add an interface to channel group 1 in active mode:

```
n1010# configure terminal
n1010(config)# interface GigabitEthernet4
n1010(config-if)# channel-group 1 mode active
n1010(config-if)#
```

Related Commands	Command	Description
	<b>show network port-channel summary</b>	Displays summary information on the port channel.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## check logflash

To check the compactFlash, use the **check logflash** command.

```
check logflash [bad-blocks]
```

Syntax Description	bad-blocks	(Optional) Finds bad blocks in compactFlash.
--------------------	------------	--

Defaults	None
----------	------

Command Modes	Any command mode
---------------	------------------

SupportedUserRoles	network-admin
--------------------	---------------

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

Examples	This example shows how to check compactFlash: n1010# <b>check logflash</b>
----------	---

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## clear accounting log

To clear the accounting log, use the **clear accounting log** command.

**clear accounting log**

---

**Syntax Description** This command has no arguments or keywords.

---

**Defaults** None

---

**Command Modes** Any command mode

---

**SupportedUserRoles** network-admin

---

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

---



---

**Examples** This example shows how to clear the accounting log:

```
n1010# clear accounting log
```

---

Related Commands	Command	Description
	<b>show accounting log</b>	Displays the accounting log contents.

---

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## clear cdp

To clear the Cisco Discovery Protocol (CDP) information on an interface, use the **clear cdp** command.

```
clear cdp {counters [interface slot/port] | table [interface slot/port]}
```

Syntax Description	counters	Clears CDP counters on all interfaces.
	<b>interface</b>	(Optional) Clears CDP counters on a specified interface.
	<i>slot/port</i>	Slot number and port number for an existing interface.
	<b>table</b>	Clears the CDP cache on all interfaces.

**Defaults** None

**Command Modes** Any command mode

**SupportedUserRoles** network-admin  
network-operator

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Examples** This example shows how to clear CDP counters on all interfaces:

```
n1010# clear cdp counters
```

This example shows how to clear the CDP cache on all interfaces:

```
n1010# clear cdp table
```

Related Commands	Command	Description
	<b>show cdp</b>	Displays the CDP configuration.
	<b>show cdp neighbor</b>	Displays the CDP configuration.

## ■ clear cli history

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## clear cli history

To clear the history of commands you have entered into the CLI, use the **clear cli history** command.

```
clear cli history
```

---

**Syntax Description** This command has no arguments or keywords.

---

**Defaults** None

---

**Command Modes** Any command mode

---

**SupportedUserRoles** network-admin

---

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

---



---

**Usage Guidelines** Use the **show cli history** command to display the history of the commands that you entered at the CLI.

---

**Examples** This example shows how to clear the command history:

```
n1010# clear cli history
```

---

Related Commands	Command	Description
	show cli history	Displays the command history.

---



*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## clear cores

To clear the core files, use the **clear cores** command.

**clear cores** [**archive**]

Syntax Description	archive	(Optional) Clears the core file on the logflash file system.
--------------------	---------	--

Defaults	None
----------	------

Command Modes	Any command mode
---------------	------------------

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

Usage Guidelines	Use the <b>show system cores</b> command to display information about the core files.
------------------	---

Examples	This example shows how to clear the core file:
----------	--

```
n1010# clear cores
```

Examples	This example shows how to clear the core on the logflash file system:
----------	---

```
n1010# clear cores archive
```

Related Commands	Command	Description
	<b>check logflash</b>	Checks the compactFlash.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## clear counters

To clear interface counters, use the **clear counters** command.

```
clear counters [interface {all | ethernet slot/port | loopback virtual-interface-number | mgmt |
port-channel port-channel-number | vethernet interface-number}]
```

Syntax Description		
<b>interface</b>	(Optional)	Clears interface counters.
<b>all</b>		Clears all interface counters.
<b>ethernet</b> <i>slot/port</i>		Clears Ethernet interface counters. The range is from 1 to 66.
<b>loopback</b> <i>virtual-interface-number</i>		Clears loopback interface counters. The range is from 0 to 1023.
<b>mgmt</b>		Clears the management interface (mgmt0).
<b>port-channel</b> <i>port-channel-number</i>		Clears port-channel interfaces. The range is from 1 to 4096.
<b>vethernet</b> <i>interface-number</i>		Clears virtual Ethernet interfaces. The range is from 1 to 1048575.

**Defaults** None

**Command Modes** Any command mode

**Supported User Roles** network-admin  
network-operator

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Examples** This example shows how to clear the Ethernet interface counters:

```
n1010(config)# clear counters ethernet 2/1
```

Related Commands	Command	Description
	<b>show interface counters</b>	Displays the interface status, which includes the counters.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## clear debug-logfile

To clear the contents of the debug logfile, use the **clear debug-logfile** command.

**clear debug-logfile** *filename*

<b>Syntax Description</b>	<i>filename</i>	Name of the debug logfile to clear.
---------------------------	-----------------	-------------------------------------

<b>Defaults</b>	None
-----------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>SupportedUserRoles</b>	network-admin
---------------------------	---------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.0(4)SP1(1)	This command was introduced.

<b>Examples</b>	This example shows how to clear the debug logfile: n1010# <b>clear debug-logfile syslogd_debugs</b>
-----------------	--

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>debug logfile</b>	Configures a debug logging file.
	<b>debug logging</b>	Enable debug logging.
	<b>show debug logfile</b>	Displays the contents of the debug logfile.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## clear line

To end a session on a specified virtual tty (vty), use the **clear line** command.

**clear line** *word*

<b>Syntax Description</b>	<i>word</i> vty name.
---------------------------	-----------------------

<b>Defaults</b>	None
-----------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>SupportedUserRoles</b>	network-admin network-operator
---------------------------	-----------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.0(4)SP1(1)	This command was introduced.

<b>Examples</b>	This example shows how to end a session on a specified vty: n1010(config)# <b>clear line</b>
-----------------	---

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show users</b>	Displays active user sessions.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## clear logging logfile

To clear messages from the logging file, use the **clear logging logfile** command.

**clear logging logfile**

**Syntax Description** This command has no arguments or keywords.

**Defaults** None

**Command Modes** Any command mode

**SupportedUserRoles** Super user

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Examples** This example shows how to clear messages from the logging file:

```
n1010# clear logging logfile
n1010#
```

Related Commands	Command	Description
	show logging logfile	Displays the logs in the local log file.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## clear logging session

To clear the current logging session, use the **clear logging session** command.

**clear logging session**

**Syntax Description** This command has no arguments or keywords.

**Defaults** None

**Command Modes** Any command mode

**SupportedUserRoles** Super user

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Examples** This example shows how to clear the current logging session:

```
n1010# clear logging session
n1010#
```

Related Commands	Command	Description
	<b>show logging logfile</b>	Displays the logs in the local log file.
	<b>show logging server</b>	Displays the current server configuration for logging system message.
	<b>show logging timestamp</b>	Displays the unit of measure used in the system messages timestamp.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## clear ntp statistics

To clear the Network Time Protocol (NTP) statistics, use the **clear ntp statistics** command.

```
clear ntp statistics {all-peers | io | local | memory}
```

Syntax Description	all-peers	Clears statistics for all NTP peers.
	io	Clears IO statistics.
	local	Clears local statistics.
	memory	Clears memory statistics.

**Defaults** None

**Command Modes** Any command mode

**SupportedUserRoles** network-admin  
network-operator

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Examples** This example shows how to clear statistics for all NTP peers:

```
n1010(config)# clear ntp statistics all-peers
```

Related Commands	Command	Description
	show ntp peers	Displays information about NTP peers.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## clear ssh hosts

To clear the Secure Shell (SSH) host sessions, use the **clear ssh hosts** command.

```
clear ssh hosts
```

---

**Syntax Description** This command has no arguments or keywords.

---

**Defaults** None

---

**Command Modes** Any command mode

---

**SupportedUserRoles** network-admin

---

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

---



---

**Examples** This example shows how to clear all SSH host sessions:

```
n1010# clear ssh hosts
```

---

Related Commands	Command	Description
	ssh server enable	Enables the SSH server.

---



*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

## clear system reset-reason

To clear the switch reset-reason history, use the **clear system reset-reason** command.

**clear system reset-reason**

**Syntax Description** This command has no arguments or keywords.

**Defaults** None

**Command Modes** Any command mode

**SupportedUserRoles** network-admin

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Examples** This example shows how to clear the reset-reason history for the switch:

```
n1010# clear system reset-reason
```

Related Commands	Command	Description
	show system resources	Displays system-related CPU and memory statistics.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## clear user

To clear a user session, use the **clear user** command.

```
clear user user-id
```

<b>Syntax Description</b>	<i>user-id</i>	User identifier.
---------------------------	----------------	------------------

<b>Defaults</b>	None	
-----------------	------	--

<b>Command Modes</b>	Any command mode	
----------------------	------------------	--

<b>SupportedUserRoles</b>	network-admin	
---------------------------	---------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.0(4)SP1(1)	This command was introduced.

<b>Usage Guidelines</b>	Use the <b>show users</b> command to display the current user sessions on the switch.	
-------------------------	---	--

<b>Examples</b>	This example shows how to clear all SSH host sessions:	
	n1010# <b>clear user user1</b>	

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
		<b>show users</b>

***Send document comments to nexus1k-docfeedback@cisco.com.***

## cli var name

To define a CLI variable for a terminal session, use the **cli var name** command. To remove the CLI variable, use the **no** form of this command.

**cli var name** *variable-name variable-text*

**cli no var name** *variable-name*

Syntax Description	variable-name	Name of the variable. The name is alphanumeric, case sensitive, and has a maximum of 31 characters.
	variable-text	Variable text. The text is alphanumeric, can contain spaces, and has a maximum of 200 characters.

**Defaults** None

**Command Modes** Any command mode

**SupportedUserRoles** network-admin

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Usage Guidelines** You can reference a CLI variable using the following syntax:

`$(variable-name)`

Instances where you can use variables in include the following:

- Command scripts
- Filenames

You cannot reference a variable in the definition of another variable.

You can use the predefined variable, `TIMESTAMP`, to insert the time of day. You cannot change or remove the `TIMESTAMP` CLI variable.

You must remove a CLI variable before you can change its definition.

**Examples** This example shows how to define a CLI variable:

```
n1010# cli var name testinterface interface 2/3
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

This example shows how to reference the `TIMESTAMP` variable:

```
n1010# copy running-config > bootflash:run-config-$(TIMESTAMP).cnfg
```

This example shows how to remove a CLI variable:

```
n1010# cli no var name testinterface interface 2/3
```

**Related Commands**

Command	Description
<code>show cli variables</code>	Displays the CLI variables.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## clock set

To manually set the clock, use the **clock set** command.

**clock set** *time day month year*

Syntax Description		
<i>time</i>		Time of day. The format is <i>HH:MM:SS</i> .
<i>day</i>		Day of the month. The range is from 1 to 31.
<i>month</i>		Month of the year. The values are <b>January, February, March, April, May, June, July, August, September, October, November, and December</b> .
<i>year</i>		Year. The range is from 2000 to 2030.

**Defaults** None

**Command Modes** Any command mode

**SupportedUserRoles** network-admin

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Usage Guidelines** Use the **clock set** command when you cannot synchronize your device with an outside clock source, such as NTP.

**Examples** This example shows how to manually set the clock:

```
n1010# clock set 9:00:00 1 June 2008
```

Related Commands	Command	Description
	<b>clock summer-time</b>	Configures the summer-time (daylight saving time) offset.
	<b>clock timezone</b>	Configures the time zone offset from Coordinated Universal Time (UTC).

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## clock summer-time

To configure the summer-time (daylight saving time) offset, use the **clock summer-time** command. To revert to the default, use the **no** form of this command.

**clock summer-time** *zone-name start-week start-day start-month start-time end-week end-day end-month end-time offset-minutes*

**no clock summer-time**

Syntax Description	
<i>zone-name</i>	Time zone string. The time zone string is a three-character string.
<i>start-week</i>	Week of the month to start the summer-time offset. The range is from 1 to 5.
<i>start-day</i>	Day of the month to start the summer-time offset. Valid values are <b>Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, or Sunday</b> .
<i>start-month</i>	Month to start the summer-time offset. Valid values are <b>January, February, March, April, May, June, July, August, September, October, November, and December</b> .
<i>start-time</i>	Time to start the summer-time offset. The format is <i>hh:mm</i> .
<i>end-week</i>	Week of the month to end the summer-time offset. The range is from 1 to 5.
<i>end-day</i>	Day of the month to end the summer-time offset. Valid values are <b>Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, or Sunday</b> .
<i>end-month</i>	Month to end the summer-time offset. Valid values are <b>January, February, March, April, May, June, July, August, September, October, November, and December</b> .
<i>end-time</i>	Time to end the summer-time offset. The format is <i>hh:mm</i> .
<i>offset-minutes</i>	Number of minutes to offset the clock. The range is from 1 to 1440.

**Defaults** None

**Command Modes** Global configuration (config)

**SupportedUserRoles** network-admin

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Examples** This example shows how to configure the offset for summer-time or daylight saving time:

```
n1010# configure terminal
n1010(config)# clock summer-time PDT 1 Sunday March 02:00 1 Sunday November 02:00 60
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

This example shows how to remove the summer-time offset:

```
n1010# configure terminal
n1010(config)# no clock summer-time
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>clock set</b>	Sets the clock, manually.
<b>clock timezone</b>	Configures the time zone offset from Coordinated Universal Time (UTC).

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## clock timezone

To configure the time zone offset from Coordinated Universal Time (UTC), use the **clock timezone** command. To revert to the default, use the **no** form of this command.

**clock timezone** *zone-name* *offset-hours* *offset-minutes*

**no clock timezone**

Syntax Description		
	<i>zone-name</i>	Zone name. The name is a 3-character string for the time zone acronym (for example, PST or EST).
	<i>offset-hours</i>	Number of hours offset from UTC. The range is from -23 to 23.
	<i>offset-minutes</i>	Number of minutes offset from UTC. The range is from 0 to 59.

**Defaults** None

**Command Modes** Any command mode

**SupportedUserRoles** network-admin

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Examples** This example shows how to configure the time zone offset from UTC:

```
n1010# clock timezone EST 5 0
```

This example shows how to remove the time zone offset:

```
n1010# no clock timezone
```

Related Commands	Command	Description
	<b>clock set</b>	Sets the clock, manually.
	<b>clock summer-time</b>	Configures the summer-time (daylight saving time) offset.



*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

# configure terminal

To enter global configuration mode, use the **configure terminal** command.

**configure terminal**

**Syntax Description** This command has no arguments or keywords

**Defaults** None

**Command Modes** Any command mode

**SupportedUserRoles** network-admin

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Usage Guidelines** The configuration changes you make in the Global configuration mode are saved in the running configuration file. To save these changes persistently across reboots and restarts, you must copy them to the startup configuration file using the copy running-config startup-config command.

**Examples** This example shows how to enter global configuration mode:

```
n1010# configure terminal
n1010(config)#
```

Related Commands	Command	Description
	<b>copy running-config startup-config</b>	Copies the running configuration to the startup configuration.
	<b>exit</b>	Exits a configuration mode.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## control uplink

To modify the default control traffic interface name in the flexible network uplink type, use the **control uplink** command.

**control uplink** *interface name*

### Syntax Description

*interface name* The name of the control uplink interface. Interface names can be GigabitEthernet interfaces or Portchannel interfaces.

### Defaults

None

### Command Modes

SVS domain configuration (config-svs-domain)

### Supported User Roles

network-admin

### Command History

Release	Modification
4.2(1)SP1(4)	This command was introduced.

### Examples

This example shows how to modify the control traffic interface name:

```
n1010# configure terminal
n1010(config)# svs-domain
n1010(config-svs-domain)# control uplink GigabitEthernet1
n1010(config-svs-domain)#
```

### Related Commands

Command	Description
<b>network uplink type</b>	Modifies the network uplink type.
<b>show network-uplink type</b>	Displays the uplink configuration.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## control vlan

To modify the VLAN ID of the Virtual Supervisor Module (VSM) domain control VLAN, use the **control vlan** command.

**control vlan** *vlan-id*

<b>Syntax Description</b>	<i>vlan-id</i>	Number that identifies the VSM domain control VLAN. The range is from 1 to 3967 and 4048 to 4093.
---------------------------	----------------	---

<b>Defaults</b>	None
-----------------	------

<b>Command Modes</b>	SVS domain configuration (config-svs-domain)
----------------------	--

<b>Supported User Roles</b>	network-admin
-----------------------------	---------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.0(4)SP1(1)	This command was introduced.

**Examples** This example shows how to modify the VLAN ID of the VSM domain control VLAN to be 1116:

```
n1010# configure terminal
n1010(config)# svs-domain
n1010(config-svs-domain)# control vlan 1116
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>login virtual-service-blade</b>	Logs you into the Cisco Nexus 1000V CLI for the VSM that you are modifying.
	<b>packet vlan</b>	Modifies the VLAN ID of the VSM domain packet VLAN.
	<b>show svcs domain</b>	Displays the domain configuration for the VSM.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

## copy

To copy a file from a source to a destination, use the **copy** command.

**copy** *source-url destination-url*

Syntax Description		
	<i>source-url</i>	Location URL (or variable) of the source file or directory to be copied. The source can be either local or remote, depending upon whether the file is being downloaded or uploaded.
	<i>destination-url</i>	Destination URL (or variable) of the copied file or directory. The destination can be either local or remote, depending upon whether the file is being downloaded or uploaded.

The format of the source and destination URLs varies according to the file or directory location. You may enter either a CLI variable for a directory or a filename that follows the Cisco NX-OS file system syntax (*filesystem:[/directory][/filename]*).

The following tables list URL prefix keywords by the file system type. If you do not specify a URL prefix keyword, the device looks for the file in the current directory.

Table 1 lists URL prefix keywords for bootflash and remote writable storage file systems.

**Table 1 URL Prefix Keywords for Storage File Systems**

Keyword	Source or Destination
<b>bootflash:</b> <i>[/module]</i>	Source or destination URL for boot flash memory. The <i>module</i> argument value is <b>sup-active</b> , <b>sup-local</b> , <b>sup-remote</b> , or <b>sup-standby</b> .
<b>ftp:</b>	Source or destination URL for a FTP network server. The syntax for this alias is as follows: <b>ftp:</b> <i>[/server][/path]/filename</i>
<b>scp:</b>	Source or destination URL for a network server that supports Secure Shell (SSH) and accepts copies of files using the secure copy protocol (scp). The syntax for this alias is as follows: <b>scp:</b> <i>[/[username@]server][/path]/filename</i>
<b>sftp:</b>	Source or destination URL for an SSH FTP (SFTP) network server. The syntax for this alias is as follows: <b>sftp:</b> <i>[/[username@]server][/path]/filename</i>
<b>tftp:</b>	Source or destination URL for a TFTP network server. The syntax for this alias is as follows: <b>tftp:</b> <i>[/server[:port]][/path]/filename</i>

## Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).

Table 2 lists the URL prefix keywords for nonwritable file systems.

**Table 2** URL Prefix Keywords for Special File Systems

Keyword	Source or Destination
<b>core:</b>	Local memory for core files. You can copy core files from the core: file system.
<b>debug:</b>	Local memory for debug files. You can copy core files from the debug: file system.
<b>log:</b>	Local memory for log files. You can copy log files from the log: file system.
<b>system:</b>	Local system memory. You can copy the running configuration to or from the system: file system. The system: file system is optional when referencing the running-config file in a command.
<b>volatile:</b>	Local volatile memory. You can copy files to or from the volatile: file system. All files in the volatile: memory are lost when the physical device reloads.

### Defaults

The default name for the destination file is the source filename.

### Command Modes

Any command mode

### SupportedUserRoles

network-admin

### Command History

Release	Modification
4.0(4)SP1(1)	This command was introduced.

### Usage Guidelines

The entire copying process may take several minutes, depending on the network conditions and the size of the file, and differs from protocol to protocol and from network to network.

The colon character (:) is required after the file system URL prefix keywords (such as **bootflash**).

In the URL syntax for **ftp:**, **scp:**, **sftp:**, and **tftp:**, the server is either an IP address or a hostname.

### Examples

This example shows how to copy a file within the same directory:

```
n1010# copy file1 file2
```

This example shows how to copy a file to another directory:

```
n1010# copy file1 my_files:file2
```

This example shows how to copy a file to another VSM:

```
n1010# copy file1 bootflash://sup-remote/file1.bak
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

This example shows how to copy a file from a remote server:

```
n1010# copy scp://10.10.1.1/image-file.bin bootflash:image-file.bin
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>cd</b>	Changes the current working directory.
<b>cli var name</b>	Configures CLI variables for the session.
<b>dir</b>	Displays the directory contents.
<b>move</b>	Moves a file.
<b>pwd</b>	Displays the name of the current working directory.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

# copy running-configuration startup-configuration

To copy the running configuration to the startup configuration, use the **copy running-configuration startup-configuration** command.

**copy running-configuration startup-configuration**

**Syntax Description** This command has no arguments or keywords

**Defaults** None

**Command Modes** Any command mode

**SupportedUserRoles** network-admin

Command History	Release	Modification
	4.0(4)SP1(1)	This command was introduced.

**Usage Guidelines** Use the **copy running-configuration startup-configuration** command to save configuration changes in the running configuration to the startup configuration in persistent memory. When a device reload or switchover occurs, the saved configuration is applied.

**Examples** This example shows how to copy the running configuration to the startup configuration:

```
n1010# copy running-config startup-config
[#####] 100%
```



**Note** This example also shows how to use a shortened version of the **copy running-configuration startup-configuration** command

Related Commands	Command	Description
	<b>login virtual-service-blade</b>	Logs you into the Cisco Nexus 1000V CLI for the VSM that you are modifying.
	<b>packet vlan</b>	Modifies the VLAN ID of the VSM domain packet VLAN.
	<b>show vs domain</b>	Displays the domain configuration for the VSM.

■ `copy running-configuration startup-configuration`

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***