



## CHAPTER 2

# Configuring the MAC Address Table

---



### Note

For information about creating interfaces, see the document, *Cisco Nexus 1000V Interface Configuration Guide, Release 4.2(1)SV1(5.1)*.

---

This chapter includes the following topics:

- [Information About the MAC Address Table, page 2-1](#)
- [Guidelines and Limitations, page 2-2](#)
- [Default Settings, page 2-2](#)
- [Configuring the MAC Address Table, page 2-2](#)
- [Verifying the Configuration, page 2-6](#)
- [Example Configuration for the MAC Address Table, page 2-8](#)
- [Additional References, page 2-8](#)
- [Feature History for the MAC Address Table, page 2-9](#)

## Information About the MAC Address Table

Layer 2 ports correlate the MAC address on a packet with the Layer 2 port information for that packet using the MAC address table. A MAC address table is built using the MAC source addresses of the frames received. When a frame is received for a MAC destination address not listed in the address table, the frame is flooded to all LAN ports of the same VLAN with the exception of the port that received the frame. When the destination station replies, the relevant MAC source addresses and port IDs are added to the address table. Then subsequent frames are forwarded to a single LAN port without flooding all LAN ports.

You can configure MAC addresses, which are called static MAC addresses, to statically point to specified interfaces on the device. These static MAC addresses override any dynamically learned MAC addresses on those interfaces. You cannot configure broadcast or multicast addresses as static MAC addresses. The static MAC entries are retained across reboots.

The address table per VEM can store up to 32000 MAC entries. An aging timer triggers removal of addresses from the table when they remain inactive for the default time of 300 secs. The aging timer can be configured on a global basis but not per VLAN.

You can configure the length of time an entry remains in the MAC address table, clearing the table, and so forth.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## Guidelines and Limitations

Keep in mind the following guidelines for configuring MAC addresses:

- The forwarding table for each VLAN in a VEM can store up to 4094 MAC addresses.
- You can configure only 1024 static MAC addresses on a single interface.
- Cisco Nexus 1000V supports a maximum of 2000 user configured static MAC addresses on a VSM.
- Cisco Nexus 1000V supports a maximum of 2000 private VLAN MAC addresses on a VSM.

## Default Settings

Table 2-1 lists the default setting for the MAC address aging time.

**Table 2-1** Default MAC Address Aging Time

| Parameters | Default     |
|------------|-------------|
| Aging time | 300 seconds |

## Configuring the MAC Address Table

This section includes the following procedures for configuring the MAC address table:

- [Configuring a Static MAC Address, page 2-2](#)
- [Configuring the Aging Time, page 2-4](#)
- [Clearing Dynamic Addresses from the MAC Address Table, page 2-5](#)

## Configuring a Static MAC Address

Use this procedure to configure a MAC address to statically point to a specific interface.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- You cannot configure broadcast or multicast addresses as static MAC addresses.
- Static MAC addresses override dynamically-learned MAC addresses on an interface.



#### Note

Be aware that the Cisco NX-OS commands may differ from those used in Cisco IOS.

### SUMMARY STEPS

1. **config t**
2. **mac address-table static mac address vlan vlan-id {[drop | interface {type if\_id | port-channel id}]}**

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

```
mac address-table static mac-address vlan vlan-id {interface {interface-name}+ | drop}
[auto-learn]
```

```
no mac address-table static mac-address vlan vlan-id
```

3. `show mac address static interface` [`type if_id`]
4. `copy running-config startup-config`

## DETAILED STEPS

|        | Command  | Purpose   |
|--------|--|---|
| Step 1 | <code>config t</code><br><br><b>Example:</b><br>n1000v# <code>config t</code><br>n1000v(config)#   | Enters global configuration mode.   |
| Step 2 | <code>mac address-table static mac_address</code><br><code>vlan vlan-id</code> {[ <code>drop</code>   <code>interface</code> { <code>type</code><br><code>if_id</code> }   <code>port-channel</code> <code>number</code> ]}<br><br><b>Example:</b><br>n1000v(config)# <code>mac address-table static</code><br>12ab.47dd.ff89 vlan 3 <code>interface ethernet</code><br>3/3<br>n1000v(config)# | Adds a static MAC address in the Layer 2 MAC address table and saves it in the running configuration.<br><br>Interface can be specified as either of the following: <ul style="list-style-type: none"> <li>• <code>ethernet slot/port</code></li> <li>• <code>veth number</code></li> </ul> |
| Step 3 | <code>show mac address static interface</code> [ <code>type</code><br><code>if_id</code> ]<br><br><b>Example:</b><br>n1000v(config)# <code>show mac address static</code><br><br><b>Example:</b><br>n1000v(config)# <code>show mac address static</code><br><code>interface Ethernet 3/3</code>  | (Optional) Displays static MAC addresses.   |
| Step 4 | <code>copy running-config startup-config</code><br><br><b>Example:</b><br>n1000v(config)# <code>copy running-config</code><br><code>startup-config</code>  | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration.  |

### Example:

```
n1000v# config t
```

```
n1000v(config)# mac address static
```

```
n1000v(config)# show mac address static
```

```

VLAN      MAC Address      Type   Age    Port                Module
-----+-----+-----+-----+-----+-----
1         0002.3d11.5502   static 0      N1KV Internal Port   3
1         0002.3d21.5500   static 0      N1KV Internal Port   3
1         0002.3d21.5502   static 0      N1KV Internal Port   3
1         0002.3d31.5502   static 0      N1KV Internal Port   3
1         0002.3d41.5502   static 0      N1KV Internal Port   3
1         0002.3d61.5500   static 0      N1KV Internal Port   3
1         0002.3d61.5502   static 0      N1KV Internal Port   3
1         0002.3d81.5502   static 0      N1KV Internal Port   3
3         12ab.47dd.ff89   static 0      Eth3/3                3
342      0002.3d41.5502   static 0      N1KV Internal Port   3
343      0002.3d21.5502   static 0      N1KV Internal Port   3
Total MAC Addresses: 11

```

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

```
n1000v(config)# show mac address static interface Ethernet 3/3
VLAN      MAC Address      Type  Age      Port      Module
-----+-----+-----+-----+-----+-----
3         12ab.47dd.ff89   static  0        Eth3/3    3
Total MAC Addresses: 1
n1000v(config)#
```

## Configuring the Aging Time

Use this procedure to configure the amount of time that packet source MAC addresses, and the ports on which they are learned, remain in the MAC table containing the Layer 2 information.



### Note

Although it is a global setting, you can also configure MAC aging time in interface configuration mode or VLAN configuration mode.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.
- The aging time is a global setting that cannot be configured per VLAN.



### Note

Be aware that the Cisco NX-OS commands may differ from those used in Cisco IOS.

### SUMMARY STEPS

1. **config t**
2. **mac address-table aging-time *seconds***
3. **show mac address-table**
4. **copy running-config startup-config**

### DETAILED STEPS

|        | Command  | Purpose   |
|--------|--|---|
| Step 1 | <b>config t</b><br><br><b>Example:</b><br>n1000v# config t<br>n1000v(config)#  | Enters global configuration mode.   |
| Step 2 | <b>mac address-table aging-time <i>seconds</i></b><br><br><b>Example:</b><br>n1000v(config)# mac address-table<br>aging-time 600 | Specifies and saves in the running configuration the amount of time that will elapse before an entry in the Layer 2 MAC address table is discarded.<br><br>Allowable entries: <ul style="list-style-type: none"> <li>• 120 to 918000 seconds (default is 300)</li> <li>• If you specify zero (0), MAC aging is disabled.</li> </ul> |

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

|        | Command  | Purpose  |
|--------|--|--|
| Step 3 | <b>show mac address-table aging-time</b><br><br><b>Example:</b><br><pre>n1000v(config)# show mac address-table aging-time Vlan Aging Time ----- 101    300 100    300 1      300 n1000v#</pre> | (Optional) Displays the aging time in the MAC address table.   |
| Step 4 | <b>copy running-config startup-config</b><br><br><b>Example:</b><br><pre>n1000v(config)# copy running-config startup-config</pre>  | (Optional) Saves the running configuration persistently through reboots and restarts by copying it to the startup configuration. |

**Example:**  

```
n1000v# config t
n1000v(config)# mac address-table aging-time 600
n1000v(config)#
```

## Clearing Dynamic Addresses from the MAC Address Table

Use this procedure to clear dynamic Layer 2 entries from the MAC address table.

### BEFORE YOU BEGIN

Before beginning this procedure, you must know or do the following:

- You are logged in to the CLI in EXEC mode.



#### Note

Be aware that the Cisco NX-OS commands may differ from those used in Cisco IOS.

### SUMMARY STEPS

- clear mac address-table dynamic [vlan vlan\_id]
- show mac address-table

### DETAILED STEPS

|        | Command   | Purpose  |
|--------|---|--|
| Step 1 | <b>clear mac address-table dynamic</b><br>[vlan vlan_id]<br><br><b>Example:</b><br><pre>n1000v# clear mac address-table dynamic n1000v#</pre> | Clears the dynamic address entries from the Layer 2 MAC address table.<br><br>This example clears the entire MAC address table of all dynamic entries. |

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

| Command  | Purpose  |
|--|--|
| <b>Example:</b><br>n1000v# clear mac address-table dynamic<br>vlan 5<br>n1000v#                      | This example clears the MAC address table of only those dynamic MAC addresses learned on VLAN 5. |
| <b>Step 2</b> <b>show mac address-table</b><br><br><b>Example:</b><br>n1000v# show mac address-table |  |

## Verifying the Configuration

Use the following commands to verify the Layer 2 MAC address configuration.

| Command  | Purpose  |
|--|--|
| <b>show mac address-table</b>                                  | Displays the MAC address table.<br>See <a href="#">Example 2-1 on page 2-6</a>   |
| <b>show mac address-table static</b>                           | Displays information about the MAC address table static entries.   |
| <b>show mac address-table static   inc veth</b>                | Displays the static MAC address of vEthernet interfaces in case a VEM physical port learns a dynamic MAC and the packet source is in another VEM on the same VSM.<br>See <a href="#">Example 2-2 on page 2-7</a> |
| <b>show mac address static interface</b> [ <i>type if_id</i> ] | Displays all static MAC addresses.<br>See: <ul style="list-style-type: none"> <li>• <a href="#">Example 2-3 on page 2-7</a></li> <li>• <a href="#">Example 2-4 on page 2-7</a></li> </ul>                        |
| <b>show mac address-table aging-time</b>                       | Displays the aging time in the MAC address table.<br>See <a href="#">Example 2-5 on page 2-7</a>   |
| <b>show mac address-table count</b>                            | Displays a count of MAC address entries.<br>See <a href="#">Example 2-6 on page 2-8</a>  |
| <b>show interface</b> <i>interface_id</i> <b>mac</b>           | Displays the MAC addresses and the burn-in MAC address for an interface.   |

### Example 2-1 show mac address-table

```

n1000v# show mac address-table
VLAN      MAC Address      Type   Age   Port                               Module
-----+-----+-----+-----+-----+-----
1         0002.3d11.5502   static 0     N1KV Internal Port                3
1         0002.3d21.5500   static 0     N1KV Internal Port                3
1         0002.3d21.5502   static 0     N1KV Internal Port                3
1         0002.3d31.5502   static 0     N1KV Internal Port                3
1         0002.3d41.5502   static 0     N1KV Internal Port                3
1         0002.3d61.5500   static 0     N1KV Internal Port                3

```

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

```

1          0002.3d61.5502    static 0          N1KV Internal Port      3
1          0002.3d81.5502    static 0          N1KV Internal Port      3
3          12ab.47dd.ff89    static 0          Eth3/3                  3
342       0002.3d41.5502    static 0          N1KV Internal Port      3
342       0050.568d.5a3f    dynamic 0         Eth3/3                  3
343       0002.3d21.5502    static 0          N1KV Internal Port      3
343       0050.568d.2aa0    dynamic 9         Eth3/3                  3
Total MAC Addresses: 13
n1000v#

```

**Example 2-2 show mac address-table static | inc veth**

```

n1000v# show mac address-table static | inc veth
460       0050.5678.ed16    static 0          Veth2                   3
460       0050.567b.1864    static 0          Veth1                   4
n1000v#

```

**Example 2-3 show mac address static**

```

n1000v(config)# show mac address static
VLAN      MAC Address      Type  Age      Port                      Module
-----+-----+-----+-----+-----+-----
1          0002.3d11.5502    static 0          N1KV Internal Port      3
1          0002.3d21.5500    static 0          N1KV Internal Port      3
1          0002.3d21.5502    static 0          N1KV Internal Port      3
1          0002.3d31.5502    static 0          N1KV Internal Port      3
1          0002.3d41.5502    static 0          N1KV Internal Port      3
1          0002.3d61.5500    static 0          N1KV Internal Port      3
1          0002.3d61.5502    static 0          N1KV Internal Port      3
1          0002.3d81.5502    static 0          N1KV Internal Port      3
3          12ab.47dd.ff89    static 0          Eth3/3                  3
342       0002.3d41.5502    static 0          N1KV Internal Port      3
343       0002.3d21.5502    static 0          N1KV Internal Port      3
Total MAC Addresses: 11
n1000v(config)# show mac address static interface Ethernet 3/3
VLAN      MAC Address      Type  Age      Port                      Module
-----+-----+-----+-----+-----+-----
3          12ab.47dd.ff89    static 0          Eth3/3                  3
Total MAC Addresses: 1

```

**Example 2-4 show mac address static interface**

```

n1000v# show mac address static interface Ethernet 3/3
VLAN      MAC Address      Type  Age      Port                      Module
-----+-----+-----+-----+-----+-----
3          12ab.47dd.ff89    static 0          Eth3/3                  3
Total MAC Addresses: 1
n1000v#

```

**Example 2-5 show mac address-table aging-time**

```

n1000v# show mac address-table aging-time
Vlan  Aging Time
-----
101   300
100   300
1     300
n1000v#

```

**[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)**

**Example 2-6** *show mac address-table count*

```
n1000v)# show mac address-table count static
Total MAC Addresses: 12
n1000v#
```

## Example Configuration for the MAC Address Table

The following example shows how to add a static MAC address and establish a global aging time:

```
n1000v# configure terminal
n1000v(config)# mac address-table static 0000.0000.1234 vlan 10 interface ethernet 2/15
n1000v(config)# mac address-table aging-time 120
```

## Additional References

For additional information related to implementing Layer 2 switching, see the following sections:

- [Related Documents, page 2-8](#)
- [Standards, page 2-9](#)

## Related Documents

| Related Topic   | Document Title   |
|---|--|
| VLAN configuration  | <a href="#">“Configuring VLANs” section on page 3-1</a>                                |
| L2 switching configuration limits   | <a href="#">“Layer 2 Switching Configuration Limits” section on page 8-1</a>           |
| Interfaces  | <i>Cisco Nexus 1000V Interface Configuration Guide, Release 4.2(1)SV1(5.1)</i>         |
| Port-Profiles   | <i>Cisco Nexus 1000V Port Profile Configuration Guide, Release 4.2(1)SV1(5.1)</i>      |
| System management   | <i>Cisco Nexus 1000V System Management Configuration Guide, Release 4.2(1)SV1(5.1)</i> |
| Release Notes   | <i>Cisco Nexus 1000V Release Notes, Release 4.2(1)SV1(5.1)</i>                         |
| Complete command syntax, command modes, command history, defaults, usage guidelines, and examples | <i>Cisco Nexus 1000V Command Reference, Release 4.2(1)SV1(5.1)</i>                     |



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## Standards

| Standards   | Title |
|---|-------|
| No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature. | —     |

## Feature History for the MAC Address Table

This section provides the MAC address table release history.

| Feature Name       | Releases     | Feature Information          |
|--------------------|--------------|------------------------------|
| MAC Address Tables | 4.0(4)SV1(1) | This feature was introduced. |

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***