



S Commands

- [show scheduler config, on page 6](#)
- [show scheduler job, on page 8](#)
- [show scheduler logfile, on page 9](#)
- [show scheduler schedule, on page 10](#)
- [show segment-routing, on page 11](#)
- [show segment-routing clients, on page 12](#)
- [show segment-routing ipv4 connected-prefix-sid-map, on page 13](#)
- [show sflow, on page 14](#)
- [show sflow statistics, on page 15](#)
- [show smart-channel, on page 16](#)
- [show snapshots, on page 20](#)
- [show snapshots compare, on page 21](#)
- [show snapshots compare ipv4routes, on page 23](#)
- [show snapshots compare ipv6routes, on page 24](#)
- [show snapshots compare summary, on page 25](#)
- [show snapshots dump, on page 26](#)
- [show snapshots dump, on page 27](#)
- [show snapshots sections, on page 28](#)
- [show snmp-dhcp-relay drop statistics, on page 29](#)
- [show snmp-dhcp-relay statistics pkt, on page 31](#)
- [show snmp-ipv6-dhcp-relay drop statistics, on page 32](#)
- [show snmp-ipv6-dhcp-relay statistics pkt, on page 34](#)
- [show snmp, on page 35](#)
- [show snmp community, on page 38](#)
- [show snmp context, on page 39](#)
- [show snmp engineID, on page 40](#)
- [show snmp group, on page 41](#)
- [show snmp host, on page 42](#)
- [show snmp mib igmpCacheTable, on page 43](#)
- [show snmp mib igmpInterfaceTable, on page 44](#)
- [show snmp mib pimCandidateRPTTable, on page 46](#)
- [show snmp mib pimComponentTable, on page 47](#)
- [show snmp mib pimInterfaceTable, on page 48](#)

- [show snmp mib pimIpMRouteNextHopTable](#), on page 49
- [show snmp mib pimIpMRouteTable](#), on page 50
- [show snmp mib pimJoinPruneInterval](#), on page 51
- [show snmp mib pimNeighborTable](#), on page 52
- [show snmp mib pimRPSetTable](#), on page 53
- [show snmp nms-statistics](#), on page 54
- [show snmp oid-statistics](#), on page 55
- [show snmp pss](#), on page 56
- [show snmp roleddebug](#), on page 57
- [show snmp sessions](#), on page 58
- [show snmp snmpv3stats](#), on page 59
- [show snmp source-interface](#), on page 60
- [show snmp trap](#), on page 61
- [show snmp user](#), on page 62
- [show sockets buffers](#), on page 63
- [show sockets client](#), on page 64
- [show sockets connection](#), on page 72
- [show sockets keychain-dump](#), on page 75
- [show sockets local-port-range](#), on page 76
- [show sockets performance](#), on page 77
- [show sockets secure-lxc](#), on page 78
- [show sockets statistics](#), on page 79
- [show sockets tcp keychain binding](#), on page 89
- [show spanning-tree](#), on page 90
- [show spanning-tree blockedports](#), on page 94
- [show spanning-tree bridge](#), on page 95
- [show spanning-tree inconsistentports](#), on page 97
- [show spanning-tree interface](#), on page 98
- [show spanning-tree interface](#), on page 99
- [show spanning-tree issu-impact](#), on page 102
- [show spanning-tree mst](#), on page 103
- [show spanning-tree mst configuration](#), on page 108
- [show spanning-tree mst configuration digest](#), on page 109
- [show spanning-tree mst interface](#), on page 110
- [show spanning-tree pathcost method](#), on page 113
- [show spanning-tree root](#), on page 114
- [show spanning-tree summary](#), on page 116
- [show spanning-tree summary totals](#), on page 119
- [show ssh key](#), on page 121
- [show ssh server](#), on page 122
- [show startup-config](#), on page 123
- [show startup-config aaa](#), on page 124
- [show startup-config aclmgr](#), on page 125
- [show startup-config adjmgr](#), on page 126
- [show startup-config amt](#), on page 127
- [show startup-config arp](#), on page 128

- [show startup-config bfd](#), on page 129
- [show startup-config bgp](#), on page 130
- [show startup-config bloggerd](#), on page 131
- [show startup-config callhome](#), on page 132
- [show startup-config catena](#), on page 133
- [show startup-config cdp](#), on page 134
- [show startup-config cert-enroll](#), on page 135
- [show startup-config cfs](#), on page 136
- [show startup-config config-profile](#), on page 137
- [show startup-config copp](#), on page 138
- [show startup-config diagnostic](#), on page 139
- [show startup-config dot1x](#), on page 140
- [show startup-config ecp](#), on page 141
- [show startup-config eem](#), on page 142
- [show startup-config eigrp](#), on page 143
- [show startup-config eltm](#), on page 144
- [show startup-config evb](#), on page 145
- [show startup-config exclude](#), on page 146
- [show startup-config expand-port-profile](#), on page 147
- [show startup-config fabric forwarding](#), on page 148
- [show startup-config fabric multicast](#), on page 149
- [show startup-config hw_telemetry](#), on page 150
- [show startup-config icam](#), on page 151
- [show startup-config icmpv6](#), on page 152
- [show startup-config igmp](#), on page 153
- [show startup-config imp](#), on page 154
- [show startup-config interface](#), on page 155
- [show startup-config interface](#), on page 156
- [show startup-config ip](#), on page 157
- [show startup-config ipqos](#), on page 158
- [show startup-config ipv6](#), on page 159
- [show startup-config isis](#), on page 160
- [show startup-config l3vm](#), on page 161
- [show startup-config ldap](#), on page 162
- [show startup-config license](#), on page 163
- [show startup-config lisp](#), on page 164
- [show startup-config lldp](#), on page 165
- [show startup-config log](#), on page 166
- [show startup-config macsec](#), on page 167
- [show startup-config mmode](#), on page 168
- [show startup-config monitor](#), on page 169
- [show startup-config mpls ldp](#), on page 170
- [show startup-config mpls static](#), on page 171
- [show startup-config mpls strip](#), on page 172
- [show startup-config mpls traffic-eng](#), on page 173
- [show startup-config msdp](#), on page 174

- [show startup-config nat, on page 175](#)
- [show startup-config nbm, on page 176](#)
- [show startup-config ngoam, on page 177](#)
- [show startup-config ntp, on page 178](#)
- [show startup-config nxsdk, on page 179](#)
- [show startup-config openflow, on page 180](#)
- [show startup-config ospf, on page 181](#)
- [show startup-config ospfv3, on page 182](#)
- [show startup-config otv-isis, on page 183](#)
- [show startup-config otv, on page 184](#)
- [show startup-config param-list, on page 185](#)
- [show startup-config pim, on page 186](#)
- [show startup-config pim6, on page 187](#)
- [show startup-config plb-services, on page 188](#)
- [show startup-config poe, on page 189](#)
- [show startup-config port-profile, on page 190](#)
- [show startup-config port-security, on page 191](#)
- [show startup-config ptp, on page 192](#)
- [show startup-config radius, on page 193](#)
- [show startup-config rip, on page 194](#)
- [show startup-config rpm, on page 195](#)
- [show startup-config rsvp, on page 196](#)
- [show startup-config security, on page 197](#)
- [show startup-config segment-routing, on page 198](#)
- [show startup-config services, on page 199](#)
- [show startup-config sflow, on page 200](#)
- [show startup-config smart-channel, on page 201](#)
- [show startup-config snmp, on page 202](#)
- [show startup-config switch, on page 203](#)
- [show startup-config tacacs, on page 204](#)
- [show startup-config telemetry, on page 205](#)
- [show startup-config track, on page 206](#)
- [show startup-config udld, on page 207](#)
- [show startup-config vdc-all, on page 208](#)
- [show startup-config vdc, on page 209](#)
- [show startup-config virtual-service, on page 210](#)
- [show startup-config vlan, on page 211](#)
- [show startup-config vlan, on page 212](#)
- [show startup-config vpc, on page 213](#)
- [show startup-config vrf, on page 214](#)
- [show startup-config vrf default, on page 215](#)
- [show startup-config vshd, on page 216](#)
- [show startup-config vtp, on page 217](#)
- [show summary, on page 218](#)
- [show switch-profile, on page 219](#)
- [show switch-profile, on page 220](#)

- [show switch-profile buffer](#), on page 222
- [show switch-profile peer](#), on page 223
- [show switch-profile status](#), on page 224
- [show switch-scope controller](#), on page 226
- [show switching-mode](#), on page 227
- [show switching-mode fabric-speed](#), on page 228
- [show system auto-collect tech-support](#), on page 229
- [show system clis event-history](#), on page 230
- [show system config reload-pending](#), on page 231
- [show system cores](#), on page 232
- [show system dme status](#), on page 233
- [show system error-id](#), on page 234
- [show system exception-info](#), on page 235
- [show system fast-reload stabilization-timer](#), on page 236
- [show system inband queuing statistics](#), on page 237
- [show system inband queuing status](#), on page 239
- [show system kgdb](#), on page 240
- [show system login](#), on page 241
- [show system login failures](#), on page 242
- [show system memory-thresholds](#), on page 243
- [show system mode](#), on page 244
- [show system pss shrink status](#), on page 245
- [show system redundancy ha status](#), on page 246
- [show system redundancy status](#), on page 247
- [show system reset-reason](#), on page 248
- [show system reset-reason](#), on page 249
- [show system reset-reason module](#), on page 250
- [show system resources](#), on page 251
- [show system resources](#), on page 252
- [show system resources module](#), on page 253
- [show system resources module all](#), on page 254
- [show system routing mode](#), on page 255
- [show system srg](#), on page 256
- [show system standby manual-boot](#), on page 257
- [show system switch-mode](#), on page 258
- [show system switchover impact](#), on page 259
- [show system uptime](#), on page 260
- [show system verify bios flash](#), on page 261
- [show system vlan reserved](#), on page 262

show scheduler config

```
show scheduler config [ __readonly__ [ <terminal> ] [ <feature> ] [ <logfilesize> ] [ <emailfrom> ] [
<emailreplyto> ] [ <smtpserver> ] [ <port> ] [ <usevrf> ] [ { TABLE_userconfig <username> [ <password>
] } ] [ { TABLE_jobconfig <jobdata> } ] [ { TABLE_scheduleconfig <schedulename> [ <scheduletype> ] [
{ TABLE_jobs <status> } ] [ <email> } ] ] ]
```

Syntax Description

show	Show running system information
scheduler	Show scheduler config or data
config	Display scheduler config
<i>__readonly__</i>	(Optional)
<i>terminal</i>	(Optional) logfile terminal
<i>feature</i>	(Optional) name service
<i>logfilesize</i>	(Optional) logfilesize
<i>emailfrom</i>	(Optional) emailfrom
<i>emailreplyto</i>	(Optional) emailreplyto
<i>smtpserver</i>	(Optional) smtpserver
<i>port</i>	(Optional) port
<i>usevrf</i>	(Optional) usevrf
TABLE_userconfig	(Optional) userconfig
<i>username</i>	(Optional) username
<i>password</i>	(Optional) password
TABLE_jobconfig	(Optional) job configs
<i>jobdata</i>	(Optional) jobdata
TABLE_scheduleconfig	(Optional) schedule configs
<i>schedulename</i>	(Optional) schedulename
<i>scheduletype</i>	(Optional) scheduletype
TABLE_jobs	(Optional) jobs
<i>status</i>	(Optional) status
<i>email</i>	(Optional) email

Command Mode

- /exec

show scheduler job

```
show scheduler job [ name <s0> ] [ __readonly__ [ { TABLE_schedulerjobs <jobname> [ <jobdata> ] } ] ]
```

Syntax Description

show	Show running system information
scheduler	Show scheduler config or data
job	Display job information
name	(Optional) Specify the name of job
<i>s0</i>	(Optional) Specify the job name
__readonly__	(Optional)
TABLE_schedulerjobs	(Optional) schedulerjobs
<i>jobname</i>	(Optional) job name
<i>jobdata</i>	(Optional) job data

Command Mode

- /exec

show scheduler logfile

```
show scheduler logfile [ __readonly__ [ { TABLE_joblog <jobname> [ <jobstatus> ] [ <schedulename> ] [ <scheduleusername> ] [ <completiontime> ] [ <joboutput> ] } ] ]
```

Syntax Description

show	Show running system information
scheduler	Show scheduler config or data
logfile	Display scheduler job output log
__readonly__	(Optional)
TABLE_joblog	(Optional) jobs log
<i>jobname</i>	(Optional) job name
<i>jobstatus</i>	(Optional) job status
<i>schedulename</i>	(Optional) schedulename
<i>scheduleusername</i>	(Optional) scheduleusername
<i>completiontime</i>	(Optional) completiontime
<i>joboutput</i>	(Optional) joboutput

Command Mode

- /exec

show scheduler schedule

```
show scheduler schedule [ name <s0> ] [ __readonly__ [ { TABLE_schedules <schedulename> [
<scheduleusername> ] [ <schedulertype> ] [ <starttime> ] [ <lastexecetime> ] [ <lastcompletiontime> ] [
<execcount> ] [ <jobcount> ] [ { TABLE_jobs <jobname> [ <execstatus> ] } } ] ] ]
```

Syntax Description

show	Show running system information
scheduler	Show scheduler config or data
schedule	Display schedule information
name	(Optional) Specify the name of schedule
<i>s0</i>	(Optional) Specify the schedule name
<i>__readonly__</i>	(Optional)
TABLE_schedules	(Optional) schedules
<i>schedulename</i>	(Optional) Schedule name
<i>scheduleusername</i>	(Optional) schedule username
<i>schedulertype</i>	(Optional) schedulertype
<i>starttime</i>	(Optional) starttime
<i>lastexecetime</i>	(Optional) last exec time
<i>lastcompletiontime</i>	(Optional) lastcompletiontime
<i>execcount</i>	(Optional) execcount
<i>jobcount</i>	(Optional) jobcount
TABLE_jobs	(Optional) jobs
<i>jobname</i>	(Optional) jobname
<i>execstatus</i>	(Optional) execstatus

Command Mode

- /exec

show segment-routing

```
show segment-routing [ detail ] [ __readonly__ <srvname> <state> <process_id> [ <srgb_min_label>
<srgb_max_label> <srgb_alloc_status> [ <oper_srgb_min_label> <oper_srgb_max_label> ] <cleanup_intvl>
<retry_intvl> [ <num_retries> ] [ <srgb_alloc_hdl> ] [ <cleanup_timer_state> <retry_timer_state> ] ] [
<ulib_reg_status> [ <ulib_pib_hdl> ] ] ]
```

Syntax Description

show	Show running system information
segment-routing	Display segment-routing status info
detail	(Optional) Show detailed information
__readonly__	(Optional)
<i>srvname</i>	(Optional) Service name
<i>state</i>	(Optional) Process state
<i>process_id</i>	(Optional) Process id
<i>srgb_min_label</i>	(Optional) Configured SRGB min label
<i>srgb_max_label</i>	(Optional) Configured SRGB max label
<i>srgb_alloc_status</i>	(Optional) SRGB allocation status
<i>oper_srgb_min_label</i>	(Optional) Operational SRGB min label
<i>oper_srgb_max_label</i>	(Optional) Operational SRGB max label
<i>cleanup_intvl</i>	(Optional) SRGB cleanup interval
<i>retry_intvl</i>	(Optional) SRGB alloc retry interval
<i>num_retries</i>	(Optional) SRGB alloc retries done
<i>srgb_alloc_hdl</i>	(Optional) SRGB alloc handle
<i>cleanup_timer_state</i>	(Optional) SRGB cleanup timer state
<i>retry_timer_state</i>	(Optional) SRGB retry timer state
<i>ulib_reg_status</i>	(Optional) ULIB registration done
<i>ulib_pib_hdl</i>	(Optional) ULIB PIB handle

Command Mode

- /exec

show segment-routing clients

```
show segment-routing clients [ __readonly__ [ { TABLE_client <client_pib_name> <client_pib_index>
<client_uuid> <client_pid> <client_sap> [ { TABLE_tib <vrf_name> <tib_name> [ <pfxsid_cleanup_status>
] } ] } ] <total_clients> ]
```

Syntax Description

show	Show running system information
segment-routing	Display segment-routing status info
clients	Display client info
__readonly__	(Optional)
TABLE_client	(Optional)
<i>client_pib_name</i>	(Optional) Client name
<i>client_pib_index</i>	(Optional) Client pib index
<i>client_uuid</i>	(Optional) Client UUID
<i>client_pid</i>	(Optional) Client PID
<i>client_sap</i>	(Optional) Client SAP
TABLE_tib	(Optional)
<i>vrf_name</i>	(Optional) VRF name
<i>tib_name</i>	(Optional) Table name
<i>pfxsid_cleanup_status</i>	(Optional) Prefixsid Cleanup Pending?
<i>total_clients</i>	(Optional) Total number of clients

Command Mode

- /exec

show segment-routing ipv4 connected-prefix-sid-map

```
show segment-routing ipv4 connected-prefix-sid-map [ __readonly__ [ { TABLE_tib <vrf_name> <tib_name>
[ { TABLE_pfxsid <prefix> <index> <absolute> <range> <valid> } ] } ] ]
```

Syntax Description

show	Show running system information
segment-routing	Display segment-routing status info
ipv4	Display info for IPv4 address-family
connected-prefix-sid-map	Display prefix-sid mapping
__readonly__	(Optional)
TABLE_tib	(Optional)
<i>vrf_name</i>	(Optional) Vrf name
<i>tib_name</i>	(Optional) Table name
TABLE_pfxsid	(Optional)
<i>prefix</i>	(Optional) Prefix
<i>index</i>	(Optional) Segment ID
<i>absolute</i>	(Optional) Segment ID is absolute?
<i>range</i>	(Optional) Range of Segment IDs from index
<i>valid</i>	(Optional) Segment ID is valid?

Command Mode

- /exec

show sflow

show sflow [__readonly__ <sampling-rate> <max-sampled-size> <counter-poll-interval> <max-datagram-size> <collector-ip> <collector-vrf> <source-ip> <collector-port> <agent-ip> <data-source-interface>]

Syntax Description

show	Show running system information
sflow	Display sFlow global configuration
__readonly__	(Optional) Read only
<i>sampling-rate</i>	(Optional) Sampling Rate
<i>max-sampled-size</i>	(Optional) Max Sampled Size
<i>counter-poll-interval</i>	(Optional) Counter Poll Interval
<i>max-datagram-size</i>	(Optional) Max Datagram Size
<i>collector-ip</i>	(Optional) Collector IP
<i>collector-vrf</i>	(Optional) Collector VRF
<i>source-ip</i>	(Optional) Source IP
<i>collector-port</i>	(Optional) Collector Port
<i>agent-ip</i>	(Optional) Agent IP
<i>data-source-interface</i>	(Optional) Data Source Interface

Command Mode

- /exec

show sflow statistics

show sflow statistics [*__readonly__* <total-packets> <total-samples> <processed-samples> <dropped-samples> <rate-limiter-drops> <dropped-sflow-samples> <sent-datagrams> <dropped-datagrams>]

Syntax Description

show	Show running system information
sflow	Display sFlow global configuration
statistics	Display sFlow statistics
<i>__readonly__</i>	(Optional) Read only
<i>total-packets</i>	(Optional) Total Packets
<i>total-samples</i>	(Optional) Total Samples
<i>processed-samples</i>	(Optional) Processed Samples
<i>dropped-samples</i>	(Optional) Dropped Samples
<i>rate-limiter-drops</i>	(Optional) Rate-Limiter Drops
<i>dropped-sflow-samples</i>	(Optional) Dropped sflow Samples
<i>sent-datagrams</i>	(Optional) Sent Datagrams
<i>dropped-datagrams</i>	(Optional) Dropped Datagrams

Command Mode

- /exec

show smart-channel

```
show smart-channel <svc-name> [ brief ] [ __readonly__ <is_firstentry> <is_detail> <is_active>
<is_firstentry_routemap> <is_firstentry_standby> <is_firstentry_acl> <is_lastentry> [ TABLE_summary
<service_name> <lb_scheme> [ <interface> ] <state> <buckets> [ <reason> ] <vrf_name> <userACL> [
TABLE_device <device_grp> <dg_probe> <dg_probe_port> ] [ TABLE_route_map [ <route_map> ] [
<interface> ] [ <r_status> ] [ <int_track_id> ] ] [ TABLE_vip [ <vip_ip> ] [ <vip_probe> ] [ <vip_port> ] [
TABLE_vip_node [ <vip_node> ] [ <vip_nodev6> ] <vip_config> <vip_weight> <vip_node_probe>
<vip_node_probe_port> <vip_node_probe_ip> <vip_status> <vip_track_id> <vip_ip_sla_id> [
TABLE_vip_standby [ <vip_standby_ip> ] [ <vip_standby_ipv6> ] <vip_standby_config>
<vip_standby_weight> <vip_standby_probe> <vip_standby_probe_port> <vip_standby_probe_ip>
<vip_standby_status> <vip_standby_track_id> <vip_standby_sla_id> ] [ TABLE_vip_acl [ <vip_access_list>
] ] ] [ TABLE_node [ <node> ] [ <nodev6> ] <config> <weight> <node_probe> <node_probe_port>
<node_probe_ip> <status> <track_id> <ip_sla_id> [ TABLE_standby [ <standby_ip> ] [ <standby_ipv6> ]
<standby_config> <standby_weight> <standby_probe> <standby_probe_port> <standby_probe_ip>
<standby_status> <standby_track_id> <standby_sla_id> ] [ TABLE_acl [ <access_list> ] ] ] ] ]
```

Syntax Description

show	Show running system information
smart-channel	smart channel
<i>svc-name</i>	smart channel name
brief	(Optional) brief
<i>__readonly__</i>	(Optional) Read Only
<i>is_firstentry</i>	(Optional)
<i>is_detail</i>	(Optional)
<i>is_active</i>	(Optional)
<i>is_firstentry_routemap</i>	(Optional)
<i>is_firstentry_acl</i>	(Optional)
<i>is_lastentry</i>	(Optional)
<i>is_firstentry_standby</i>	(Optional)
TABLE_summary	(Optional)
<i>service_name</i>	(Optional) service_name
<i>lb_scheme</i>	(Optional) lb scheme
<i>interface</i>	(Optional) interface
<i>state</i>	(Optional) state
<i>buckets</i>	(Optional) buckets

<i>reason</i>	(Optional) inactive reason
<i>vrf_name</i>	(Optional) VRF-Name
<i>userACL</i>	(Optional) user access-list
TABLE_device	(Optional)
<i>device_grp</i>	(Optional) service device group
<i>dg_probe</i>	(Optional) probe type
<i>dg_probe_port</i>	(Optional) probe port
TABLE_route_map	(Optional)
<i>route_map</i>	(Optional) service route map
<i>interface</i>	(Optional) interface
<i>r_status</i>	(Optional) route map status
<i>int_track_id</i>	(Optional) interface track id
TABLE_vip	(Optional)
<i>vip_ip</i>	(Optional) vip ip
<i>vip_probe</i>	(Optional) vip protocol
<i>vip_port</i>	(Optional) vip port
TABLE_vip_node	(Optional)
<i>vip_node</i>	(Optional) service node ip
<i>vip_nodev6</i>	(Optional) service node IPv6
<i>vip_config</i>	(Optional) node config
<i>vip_weight</i>	(Optional) node weight
<i>vip_status</i>	(Optional) node status
<i>vip_node_probe</i>	(Optional) node probe type
<i>vip_node_probe_port</i>	(Optional) node probe port
<i>vip_node_probe_ip</i>	(Optional) node probe ip
<i>vip_track_id</i>	(Optional) node track id
<i>vip_ip_sla_id</i>	(Optional) node ip sla id
TABLE_vip_standby	(Optional)
<i>vip_standby_ip</i>	(Optional) standby node ip

<i>vip_standby_ipv6</i>	(Optional) standby node ipv6
<i>vip_standby_config</i>	(Optional) standby node config
<i>vip_standby_weight</i>	(Optional) standby node weight
<i>vip_standby_status</i>	(Optional) standby node status
<i>vip_standby_probe</i>	(Optional) standby node probe type
<i>vip_standby_probe_port</i>	(Optional) standby node probe port
<i>vip_standby_probe_ip</i>	(Optional) standby node probe ip
<i>vip_standby_track_id</i>	(Optional) standby node track id
<i>vip_standby_sla_id</i>	(Optional) standby node sla id
TABLE_vip_acl	(Optional)
<i>vip_access_list</i>	(Optional) access list
TABLE_node	(Optional)
<i>node</i>	(Optional) service node ip
<i>nodev6</i>	(Optional) service node IPv6
<i>config</i>	(Optional) node config
<i>weight</i>	(Optional) node weight
<i>status</i>	(Optional) node status
<i>node_probe</i>	(Optional) node probe type
<i>node_probe_port</i>	(Optional) node probe port
<i>node_probe_ip</i>	(Optional) node probe ip
<i>track_id</i>	(Optional) node track id
<i>ip_sla_id</i>	(Optional) node ip sla id
TABLE_standby	(Optional)
<i>standby_ip</i>	(Optional) standby node ip
<i>standby_ipv6</i>	(Optional) standby node ipv6
<i>standby_config</i>	(Optional) standby node config
<i>standby_weight</i>	(Optional) standby node weight
<i>standby_status</i>	(Optional) standby node status
<i>standby_probe</i>	(Optional) standby node probe type

<i>standby_probe_port</i>	(Optional) standby node probe port
<i>standby_probe_ip</i>	(Optional) standby node probe ip
<i>standby_track_id</i>	(Optional) standby node track id
<i>standby_sla_id</i>	(Optional) standby node sla id
TABLE_acl	(Optional)
<i>access_list</i>	(Optional) access list

Command Mode

- /exec

show snapshots

show snapshots [__readonly__ TABLE_snapshot <snap_name> <snap_ctime> <description>]

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
__readonly__	(Optional)
TABLE_snapshot	(Optional)
<i>snap_name</i>	(Optional) snapshot name
<i>snap_ctime</i>	(Optional) snapshot create time
<i>description</i>	(Optional) snapshot description

Command Mode

- /exec

show snapshots compare

```
show snapshots compare <snapshot-name-T1> <snapshot-name-T2> [ __readonly__ TABLE_feature
<feat_name> [ <feat_state1> <feat_state2> ] [ TABLE_element <elemkey1> <elemval1> [ <elemkey2>
<elemval2> ] [ <elemkey3> <elemval3> ] [ <elemkey4> <elemval4> ] [ <elemstate1> <elemstate2> ] [
TABLE_value <tag> <val1> <val2> ] [ TABLE_subrow <subrowkey> <subrowval> [ <substate1> <substate2>
] [ TABLE_subvalue <tag> <val1> <val2> ] ] ] ]
```

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
compare	Compare two snapshots
<i>snapshot-name-T1</i>	Name of a snapshot taken at interval T1
<i>snapshot-name-T2</i>	Name of a snapshot taken at interval T2
<i>__readonly__</i>	(Optional)
TABLE_feature	(Optional)
<i>feat_name</i>	(Optional) feature name
<i>feat_state1</i>	(Optional) feature state in snapshot1
<i>feat_state2</i>	(Optional) feature state in snapshot2
TABLE_element	(Optional)
<i>elemkey1</i>	(Optional) element key1
<i>elemval1</i>	(Optional) element value1
<i>elemkey2</i>	(Optional) element key2
<i>elemval2</i>	(Optional) element value2
<i>elemkey3</i>	(Optional) element key3
<i>elemval3</i>	(Optional) element value3
<i>elemkey4</i>	(Optional) element key4
<i>elemval4</i>	(Optional) element value4
<i>elemstate1</i>	(Optional) element state in snapshot 1
<i>elemstate2</i>	(Optional) element state in snapshot 2
TABLE_value	(Optional)
<i>tag</i>	(Optional) element tag

<i>val1</i>	(Optional) element value for tag in snapshot1
<i>val2</i>	(Optional) element value for tag in snapshot2
TABLE_subrow	(Optional)
<i>subrowkey</i>	(Optional) subrow key
<i>subrowval</i>	(Optional) subrow value
<i>substate1</i>	(Optional) subrow state in snapshot 1
<i>substate2</i>	(Optional) subrow state in snapshot 2
TABLE_subvalue	(Optional)
<i>tag</i>	(Optional) subrow tag
<i>val1</i>	(Optional) subrow value for tag in snapshot1
<i>val2</i>	(Optional) subrow value for tag in snapshot2

Command Mode

- /exec

show snapshots compare ipv4routes

```
show snapshots compare <snapshot-name-T1> <snapshot-name-T2> ipv4routes [ __readonly__
TABLE_summary <item_desc> <summary_val1> <summary_val2> [ <changed> ] [ TABLE_prefix <prefix>
<missing_snapshot> ] ]
```

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
compare	Compare two snapshots
<i>snapshot-name-T1</i>	Name of a snapshot taken at interval T1
<i>snapshot-name-T2</i>	Name of a snapshot taken at interval T2
ipv4routes	Compare ipv4 route information
<i>__readonly__</i>	(Optional)
TABLE_summary	(Optional)
<i>item_desc</i>	(Optional) item description
<i>summary_val1</i>	(Optional) summary value in snapshot1
<i>summary_val2</i>	(Optional) summary value in snapshot2
<i>changed</i>	(Optional) changed flag
TABLE_prefix	(Optional)
<i>prefix</i>	(Optional) route prefix
<i>missing_snapshot</i>	(Optional) missing in snapshot name

Command Mode

- /exec

show snapshots compare ipv6routes

```
show snapshots compare <snapshot-name-T1> <snapshot-name-T2> ipv6routes [ __readonly__
TABLE_summary <item_desc> <summary_val1> <summary_val2> [ <changed> ] [ TABLE_prefix <prefix>
<missing_snapshot> ] ]
```

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
compare	Compare two snapshots
<i>snapshot-name-T1</i>	Name of a snapshot taken at interval T1
<i>snapshot-name-T2</i>	Name of a snapshot taken at interval T2
ipv6routes	Compare ipv6 route information
<i>__readonly__</i>	(Optional)
TABLE_summary	(Optional)
<i>item_desc</i>	(Optional) item description
<i>summary_val1</i>	(Optional) summary value in snapshot1
<i>summary_val2</i>	(Optional) summary value in snapshot2
<i>changed</i>	(Optional) changed flag
TABLE_prefix	(Optional)
<i>prefix</i>	(Optional) route prefix
<i>missing_snapshot</i>	(Optional) missing in snapshot name

Command Mode

- /exec

show snapshots compare summary

```
show snapshots compare <snapshot-name-T1> <snapshot-name-T2> summary [ __readonly__
TABLE_summary <item_desc> <summary_val1> <summary_val2> [ <changed> ] ]
```

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
compare	Compare two snapshots
<i>snapshot-name-T1</i>	Name of a snapshot taken at interval T1
<i>snapshot-name-T2</i>	Name of a snapshot taken at interval T2
summary	Compare summary information
__readonly__	(Optional)
TABLE_summary	(Optional)
<i>item_desc</i>	(Optional) item description
<i>summary_val1</i>	(Optional) summary value in snapshot1
<i>summary_val2</i>	(Optional) summary value in snapshot2
<i>changed</i>	(Optional) changed flag

Command Mode

- /exec

show snapshots dump

show snapshots dump <snapshot-name> [__readonly__ TABLE_snapshot <file_name> <snap_name>]

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
dump	Dump contents of snapshot
<i>snapshot-name</i>	Name of a snapshot
__readonly__	(Optional)
TABLE_snapshot	(Optional)
<i>file_name</i>	(Optional) snapshot XML file name
<i>snap_name</i>	(Optional) snapshot name

Command Mode

- /exec

show snapshots dump

```
show snapshots dump <snapshot-name> <section-name> [ __readonly__ TABLE_snapshot <file_name>
<snap_name> ]
```

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
dump	Dump contents of snapshot
<i>snapshot-name</i>	Name of a snapshot
<i>section-name</i>	Name of snapshot section
<i>__readonly__</i>	(Optional)
TABLE_snapshot	(Optional)
<i>file_name</i>	(Optional) snapshot XML file name
<i>snap_name</i>	(Optional) snapshot name

Command Mode

- /exec

show snapshots sections

show snapshots sections [__readonly__ TABLE_snapsection <sectname> <sectcmd> <sectrow> <sectkey1> <sectkey2>]

Syntax Description

show	Show running system information
snapshots	Snapshots present on the switch
sections	User-specified snapshot sections
__readonly__	(Optional)
TABLE_snapsection	(Optional)
<i>sectname</i>	(Optional) snapshot section name
<i>sectcmd</i>	(Optional) snapshot section show command
<i>sectrow</i>	(Optional) snapshot section row id
<i>sectkey1</i>	(Optional) snapshot section key1
<i>sectkey2</i>	(Optional) snapshot section key2

Command Mode

- /exec

show snmp-dhcp-relay drop statistics

```
show snmp-dhcp-relay drop statistics [ interface <intf> | ifindex <intf-in> ] [ __readonly__ {
TABLE-cdrDropStatsTable <intf-out> <relay_disable> <invalid_msg_type> <intf_err> <tx_sock_err>
<tx_fail_client_intf> <unknown_op_intf> <l3_unknown_op_intf> <max_hops> <opt82_fail> <malformed>
<untrusted_relay_intf> <mct_drop> } ]
```

Syntax Description

show	Show running system information
snmp-dhcp-relay	DHCP Relay
drop	Statistics related to DHCP drop statistics
statistics	Statistics related to DHCP
interface	(Optional) input interface
<i>intf</i>	(Optional) interface
ifindex	(Optional) interface index value
<i>__readonly__</i>	(Optional) Read only
TABLE-cdrDropStatsTable	(Optional)
<i>intf-in</i>	(Optional) Interface Index
<i>intf-out</i>	(Optional) Table index
<i>relay_disable</i>	(Optional) relay was disabled
<i>invalid_msg_type</i>	(Optional) invalid message type
<i>intf_err</i>	(Optional) interface error
<i>tx_sock_err</i>	(Optional) failed to send at server
<i>tx_fail_client_intf</i>	(Optional) failed to send to client
<i>unknown_op_intf</i>	(Optional) unknown output interface
<i>l3_unknown_op_intf</i>	(Optional) unknown vrf or interface
<i>max_hops</i>	(Optional) max hops exceeded
<i>opt82_fail</i>	(Optional) Option82 validation failed
<i>malformed</i>	(Optional) malformed pkts
<i>untrusted_relay_intf</i>	(Optional) untrusted interface
<i>mct_drop</i>	(Optional) dropped on MCT

 show snmp-dhcp-relay drop statistics

Command Mode

- /exec

show snmp-dhcp-relay statistics pkt

```
show snmp-dhcp-relay statistics { [ interface <intf> | ifindex <intf-in> ] pkt-type <type-in> } [ __readonly__
{ TABLE-cdrStatsTable <intf-out> <type-out> <rx_pkts> <tx_pkts> <drops> } ]
```

Syntax Description

show	Show running system information
snmp-dhcp-relay	DHCP Relay
statistics	Statistics related to DHCP
interface	(Optional) input interface
<i>intf</i>	(Optional) interface
ifindex	(Optional) Interface Index Value
pkt-type	DHCP Packet type
__readonly__	(Optional) Read only
TABLE-cdrStatsTable	(Optional)
<i>intf-in</i>	(Optional) table index - ifindex
<i>intf-out</i>	(Optional) table index
<i>type-in</i>	table index - packet type
<i>type-out</i>	(Optional) table index
<i>rx_pkts</i>	(Optional) received pkt count
<i>tx_pkts</i>	(Optional) transmitted pkt count
<i>drops</i>	(Optional) dropped pkt count

Command Mode

- /exec

show snmp-ipv6-dhcp-relay drop statistics

```
show snmp-ipv6-dhcp-relay drop statistics [ interface <intf> | ifindex <intf-in> ] [ __readonly__ {
TABLE-cdrIpv6DropStatsTable <intf-out> <relay_disabled> <max_hops> <invalid_pkt> <unknown_op_intf>
<invalid_vrf> <opt_insert_failed> <dir_reply_frm_server> <ipv6_not_configured> <intf_err>
<vpn_option_disabled> <ipv6_ext_hdr_present> <mct_drop> } ]
```

Syntax Description

show	Show running system information
snmp-ipv6-dhcp-relay	IPv6 DHCP Relay
drop	Statistics related to IPv6 DHCP drop statistics
statistics	Statistics related to IPv6 DHCP
interface	(Optional) input interface
<i>intf</i>	(Optional) interface
ifindex	(Optional) interface index value
<i>__readonly__</i>	(Optional) Read only
TABLE-cdrIpv6DropStatsTable	(Optional)
<i>intf-in</i>	(Optional) Interface Index
<i>intf-out</i>	(Optional) Table index
<i>relay_disabled</i>	(Optional) DHCPv6 Relay is disabled
<i>max_hops</i>	(Optional) Max hops exceeded
<i>invalid_pkt</i>	(Optional) Packet validation failed
<i>unknown_op_intf</i>	(Optional) Unknown output interface
<i>invalid_vrf</i>	(Optional) Invalid VRF
<i>opt_insert_failed</i>	(Optional) Option Insertion Failed
<i>dir_reply_frm_server</i>	(Optional) Direct Replies (Recnfg/Adv/Reply) from server
<i>ipv6_not_configured</i>	(Optional) IPv6 addr not configured
<i>intf_err</i>	(Optional) Interface error
<i>vpn_option_disabled</i>	(Optional) VPN Option Disabled
<i>ipv6_ext_hdr_present</i>	(Optional) IPv6 extn headers present
<i>mct_drop</i>	(Optional) DHCP request dropped on MCT

Command Mode

- /exec

show snmp-ipv6-dhcp-relay statistics pkt

```
show snmp-ipv6-dhcp-relay statistics { [ interface <intf> | ifindex <intf-in> ] pkt-type <type-in> } [
__readonly__ { TABLE-cdrIpv6StatsTable <intf-out> <type-out> <rx_pkts> <tx_pkts> <drops> } ]
```

Syntax Description

show	Show running system information
snmp-ipv6-dhcp-relay	IPv6 DHCP Relay
statistics	Statistics related to IPv6 DHCP
interface	(Optional) input interface
<i>intf</i>	(Optional) interface
ifindex	(Optional) Interface Index Value
pkt-type	DHCP Packet type
__readonly__	(Optional) Read only
TABLE-cdrIpv6StatsTable	(Optional)
<i>intf-in</i>	(Optional) table index - ifindex
<i>intf-out</i>	(Optional) table index
<i>type-in</i>	table index - packet type
<i>type-out</i>	(Optional) table index
<i>rx_pkts</i>	(Optional) received pkt count
<i>tx_pkts</i>	(Optional) transmitted pkt count
<i>drops</i>	(Optional) dropped pkt count

Command Mode

- /exec

show snmp

```
show snmp [ __readonly__ <sys_contact> <sys_location> <snmp_input_packets> <bad_snmp_version>
<unknown_community_name> <illegal_community_name> <encoding_Err> <req_var_nums> <alt_var_nums>
<get_req_in> <getnext_req_in> <set_req_in> <noname_pdu_in> <badval_pdu_in> <ro_pdu_in>
<genral_err_in> <get_resp_in> <unknown_ctx> <snmp_output_packets> <trap_pdu> <toobig_err>
<noname_pdu_out> <badval_pdu_out> <genral_err_out> <get_req_out> <getnext_req_out> <set_req_out>
<get_resp_out> <silent_drops> [ <max_pkt_size> ] [ { TABLE_snmp_community <community_name>
<grouporaccess> <context> <aclfilter> } ] [ { TABLE_snmp_users <user> <auth> <priv> [ { TABLE_groups
<group> } ] [ <acl_filter> ] [ <engineID> } ] ] <tcp_auth_status> [ <port_mon_status> [ <policy_name>
<pol_admin_status> <plo_oper_status> <pol_port_type> [ TABLE_policies <counter> <threshold> <interval>
<rising_threshold> <rising_event> <falling_threshold> <falling_event> <pmon_config> ] ] ] <protocol_status>
] [ { TABLE_snmp_contexts <context_name> <proto_instanceid> <vrf> <topology> [ <vlan> | <MST> ] }
]
```

Syntax Description

show	Show running system information
snmp	show snmp information
__readonly__	(Optional) Read Only
TABLE_snmp_community	(Optional) Table that displays the community information
TABLE_snmp_users	(Optional) Table that displays the user information
TABLE_groups	(Optional) Table that displays the group information
TABLE_policies	(Optional) Table that displays the policy information
TABLE_snmp_contexts	(Optional) Table that displays the context information
sys_contact	(Optional) System Contact
sys_location	(Optional) System Location
snmp_input_packets	(Optional) SNMP input packets
bad_snmp_version	(Optional) bad snmp version in Input SNMP packets
unknown_community_name	(Optional) unknown community name in Input SNMP packets
illegal_community_name	(Optional) Illegal community name in Input SNMP packets
encoding_Err	(Optional) Encoding Errors in Input SNMP packets
req_var_nums	(Optional) number of requested variables
alt_var_nums	(Optional) number of altered variable
get_req_in	(Optional) GET request in Input SNMP packets
getnext_req_in	(Optional) GET-NEXT request in Input SNMP packets

<i>set_req_in</i>	(Optional) SET request in Input SNMP packets
<i>noname_pdu_in</i>	(Optional) NONAME PDU in Input SNMP packets
<i>badval_pdu_in</i>	(Optional) Bad value PDU in Input SNMP packets
<i>ro_pdu_in</i>	(Optional) Read only PDU in Input SNMP packets
<i>genral_err_in</i>	(Optional) Genral Error in Input SNMP packets
<i>get_resp_in</i>	(Optional) Get Response PDU in Input SNMP packets
<i>unknown_ctx</i>	(Optional) Unknown context Name in Input SNMP packets
<i>snmp_output_packets</i>	(Optional) SNMP Output Packets
<i>trap_pdu</i>	(Optional) Trap PDU in Output SNMP Packets
<i>toobig_err</i>	(Optional) Too Big errors in Output SNMP Packets
<i>noname_pdu_out</i>	(Optional)
<i>badval_pdu_out</i>	(Optional) NoName PDU in Output SNMP Packets
<i>genral_err_out</i>	(Optional) Genral Error in Output SNMP Packets
<i>get_req_out</i>	(Optional) GET request in Output SNMP Packets
<i>getnext_req_out</i>	(Optional) GET-NEXTrequest in Output SNMP Packets
<i>set_req_out</i>	(Optional) SET request in Output SNMP packets
<i>get_resp_out</i>	(Optional) Get Response PDU in Output SNMP Packets
<i>silent_drops</i>	(Optional) Silent Drop packets
<i>max_pkt_size</i>	(Optional) Maximum packet size
<i>community_name</i>	(Optional) community name
<i>grouporaccess</i>	(Optional) Group name
<i>context</i>	(Optional) context Name
<i>aclfilter</i>	(Optional) Acl filter name
<i>user</i>	(Optional) User name
<i>auth</i>	(Optional) Auth type
<i>priv</i>	(Optional) Priv Type
<i>group</i>	(Optional) Group name
<i>acl_filter</i>	(Optional) acl filter
<i>engineID</i>	(Optional) engine id for the user

<i>tcp_auth_status</i>	(Optional) TCP authentication status
<i>port_mon_status</i>	(Optional) Port monitor status
<i>policy_name</i>	(Optional) policy name
<i>pol_admin_status</i>	(Optional) Policy Admin status
<i>plo_oper_status</i>	(Optional) Police oper status
<i>pol_port_type</i>	(Optional) policy port type
<i>counter</i>	(Optional) counters
<i>threshold</i>	(Optional) Threshold
<i>interval</i>	(Optional) Interval
<i>rising_threshold</i>	(Optional) Rising threshold
<i>rising_event</i>	(Optional) Rising Event
<i>falling_threshold</i>	(Optional) Falling threshold
<i>falling_event</i>	(Optional) Falling Event
<i>pmon_config</i>	(Optional) PMON configured
<i>protocol_status</i>	(Optional) Protocol Enable status
<i>context_name</i>	(Optional) context name
<i>proto_instanceid</i>	(Optional) Protocol instance ID
<i>vrf</i>	(Optional) VRF Name
<i>topology</i>	(Optional) Topology
<i>vlan</i>	(Optional) VLAN name
<i>MST</i>	(Optional) MST name

Command Mode

- /exec

show snmp community

```
show snmp community [ __readonly__ { TABLE_snmp_community <community_name> <grouporaccess>
<context> <aclfilter> } ]
```

Syntax Description

show	Show running system information
snmp	show snmp information
community	show snmp community strings
__readonly__	(Optional) Read Only
TABLE_snmp_community	(Optional) contains all snmp community names
<i>community_name</i>	(Optional) community name
<i>grouporaccess</i>	(Optional) group or access name
<i>context</i>	(Optional) context name
<i>aclfilter</i>	(Optional) acl filter name

Command Mode

- /exec

show snmp context

```
show snmp context [ __readonly__ { TABLE_snmp_contexts <context_name> <proto_instanceid> <vrf>  
<topology> [ <vlan> | <MST> ] } ]
```

Syntax Description

<code>show</code>	Show running system information
<code>snmp</code>	show snmp information
<code>context</code>	show snmp context mapping entries
<code>__readonly__</code>	(Optional)
<code>TABLE_snmp_contexts</code>	(Optional) All SNMP Contexts Entries
<code>context_name</code>	(Optional) SNMP context Name
<code>proto_instanceid</code>	(Optional) Name of the protocol instance
<code>vrf</code>	(Optional) VRF name
<code>topology</code>	(Optional) Name of the Topology
<code>vlan</code>	(Optional) VLAN Name
<code>MST</code>	(Optional)

Command Mode

- /exec

show snmp engineID

show snmp engineID [__readonly__ <engineIDHex> <engineIDDec>]

Syntax Description

show	Show running system information
snmp	show snmp information
engineID	show snmp engineID
__readonly__	(Optional)
<i>engineIDHex</i>	(Optional) SNMP engineID in HEX
<i>engineIDDec</i>	(Optional) SNMP engineID in Decimal

Command Mode

- /exec

show snmp group

```
show snmp group [ __readonly__ { TABLE_role <role_name> <role_description> [ <attribute_scope> ] [
<permit_vsan> ] [ <permit_vlan> ] [ <permit_vlan_id> ] [ <permit_interface> ] [ <permit_interface_slot> ]
[ <permit_vrf> ] [ TABLE_vrf<permit_vrf_name> ] [ { TABLE_rule [ <rule_num> ] [ <rule_action> ] {
<rule_permission> | <rule_permission_mds> } [ <rule_featuretype> ] [ <rule_entity> ] } } ] ]
```

Syntax Description

show	Show running system information
snmp	show snmp information
group	show snmp group
__readonly__	(Optional) Read Only
TABLE_role	(Optional) Table displays role
<i>role_name</i>	(Optional) Role Name
<i>role_description</i>	(Optional) Role Description
<i>attribute_scope</i>	(Optional) Role scope
<i>permit_vsan</i>	(Optional) permitted vsan
<i>permit_vlan</i>	(Optional)
<i>permit_vlan_id</i>	(Optional)
<i>permit_interface</i>	(Optional)
<i>permit_interface_slot</i>	(Optional)
<i>permit_vrf</i>	(Optional)
TABLE_rule	(Optional)
<i>rule_num</i>	(Optional)
<i>rule_action</i>	(Optional)
<i>rule_permission</i>	(Optional)
<i>rule_permission_mds</i>	(Optional)
<i>rule_featuretype</i>	(Optional)
<i>rule_entity</i>	(Optional)

Command Mode

- /exec

show snmp host

```
show snmp host [ __readonly__ { TABLE_host <host><port><version><level><type><secname> [ [ <vrf>
] [ TABLE_vrf_filters <vrf_filter> ] [ <src_intf> ] ] } ]
```

Syntax Description

show	Show running system information
snmp	show snmp information
host	show snmp hosts
__readonly__	(Optional) Read Only
TABLE_host	(Optional) displays the list of hosts configured for snmp requests
TABLE_vrf_filters	(Optional) displays the host vrf filters
<i>vrf</i>	(Optional) VRF Name
<i>vrf_filter</i>	(Optional) vrf filters
<i>src_intf</i>	(Optional) source interface

Command Mode

- /exec

show snmp mib igmpCacheTable

```
show snmp mib igmpCacheTable [ <igmpCacheAddress-in> ] [ <igmpCacheIfIndex-in> ] [ __readonly__
TABLE_igmpCacheTable <igmpCacheAddress-out> <igmpCacheIfIndex-out> <igmpCacheSelf>
<igmpCacheLastReporter> <igmpCacheUpTime> <igmpCacheExpiryTime> <igmpCacheStatus>
<igmpCacheVersion1HostTimer> ]
```

Syntax Description

show	Show running system information
snmp	show snmp
mib	show mib tables
igmpCacheTable	show mib table igmpCacheTable
<i>igmpCacheAddress-in</i>	(Optional) igmpCacheAddress
<i>igmpCacheIfIndex-in</i>	(Optional) igmpCacheIfIndex
<i>__readonly__</i>	(Optional)
TABLE_igmpCacheTable	(Optional)
<i>igmpCacheAddress-out</i>	(Optional) mib table index igmpCacheAddress
<i>igmpCacheIfIndex-out</i>	(Optional) mib table index igmpCacheIfIndex
<i>igmpCacheSelf</i>	(Optional) mib object igmpCacheSelf
<i>igmpCacheLastReporter</i>	(Optional) mib object igmpCacheLastReporter
<i>igmpCacheUpTime</i>	(Optional) mib object igmpCacheUpTime
<i>igmpCacheExpiryTime</i>	(Optional) mib object igmpCacheExpiryTime
<i>igmpCacheStatus</i>	(Optional) mib object igmpCacheStatus
<i>igmpCacheVersion1HostTimer</i>	(Optional) mib object igmpCacheVersion1HostTimer

Command Mode

- /exec

show snmp mib igmpInterfaceTable

```
show snmp mib igmpInterfaceTable [ <igmpInterfaceIfIndex-in> ] [ __readonly__ TABLE_igmpInterfaceTable
<igmpInterfaceIfIndex-out> <igmpInterfaceQueryInterval> <igmpInterfaceStatus> <igmpInterfaceVersion>
<igmpInterfaceQuerier> <igmpInterfaceQueryMaxResponseTime> <igmpInterfaceQuerierUpTime>
<igmpInterfaceQuerierExpiryTime> <igmpInterfaceVersion1QuerierTimer>
<igmpInterfaceWrongVersionQueries> <igmpInterfaceJoins> <igmpInterfaceProxyIfIndex>
<igmpInterfaceGroups> <igmpInterfaceRobustness> <igmpInterfaceLastMembQueryIntvl> ]
```

Syntax Description

show	Show running system information
snmp	show snmp
mib	show mib tables
igmpInterfaceTable	show mib table igmpInterfaceTable
<i>igmpInterfaceIfIndex-in</i>	(Optional) igmpInterfaceIndex
<i>__readonly__</i>	(Optional)
<i>TABLE_igmpInterfaceTable</i>	(Optional)
<i>igmpInterfaceIfIndex-out</i>	(Optional) mib table index igmpInterfaceIfIndex
<i>igmpInterfaceQueryInterval</i>	(Optional) mib object igmpInterfaceQueryInterval
<i>igmpInterfaceStatus</i>	(Optional) mib object igmpInterfaceStatus
<i>igmpInterfaceVersion</i>	(Optional) mib object igmpInterfaceVersion
<i>igmpInterfaceQuerier</i>	(Optional) mib object igmpInterfaceQuerier
<i>igmpInterfaceQueryMaxResponseTime</i>	(Optional) mib object igmpInterfaceQueryMaxResponseTime
<i>igmpInterfaceQuerierUpTime</i>	(Optional) mib object igmpInterfaceQuerierUpTime
<i>igmpInterfaceQuerierExpiryTime</i>	(Optional) mib object igmpInterfaceQuerierExpiryTime
<i>igmpInterfaceVersion1QuerierTimer</i>	(Optional) mib object igmpInterfaceVersion1QuerierTimer
<i>igmpInterfaceWrongVersionQueries</i>	(Optional) mib object igmpInterfaceWrongVersionQueries
<i>igmpInterfaceJoins</i>	(Optional) mib object igmpInterfaceJoins
<i>igmpInterfaceProxyIfIndex</i>	(Optional) mib object igmpInterfaceProxyIfIndex
<i>igmpInterfaceGroups</i>	(Optional) mib object igmpInterfaceGroups
<i>igmpInterfaceRobustness</i>	(Optional) mib object igmpInterfaceRobustness
<i>igmpInterfaceLastMembQueryIntvl</i>	(Optional) mib object igmpInterfaceLastMembQueryIntvl

Command Mode

- /exec

show snmp mib pimCandidateRPTable

```
show snmp mib pimCandidateRPTable [ <pimCandidateRPGroupAddress-in> ] [
<pimCandidateRPGroupMask-in> ] [ __readonly__ TABLE_pimCandidateRPTable
<pimCandidateRPGroupAddress-out> <pimCandidateRPGroupMask-out> <pimCandidateRPAAddress>
<pimCandidateRPRowStatus> ]
```

Syntax Description

show	Show running system information
snmp	show snmp
mib	show mib tables
pimCandidateRPTable	show mib table pimCandidateRPTable
<i>pimCandidateRPGroupAddress-in</i>	(Optional) pimCandidateRPGroupAddress
<i>pimCandidateRPGroupMask-in</i>	(Optional) pimCandidateRPGroupMask
<i>__readonly__</i>	(Optional)
TABLE_pimCandidateRPTable	(Optional)
<i>pimCandidateRPGroupAddress-out</i>	(Optional) mib table index pimCandidateRPGroupAddress
<i>pimCandidateRPGroupMask-out</i>	(Optional) mib table index pimCandidateRPGroupMask
<i>pimCandidateRPAAddress</i>	(Optional) mib object pimCandidateRPAAddress
<i>pimCandidateRPRowStatus</i>	(Optional) mib object pimCandidateRPRowStatus

Command Mode

- /exec

show snmp mib pimComponentTable

```
show snmp mib pimComponentTable [ <pimComponentIndex-in> ] [ __readonly__
TABLE_pimComponentTable <pimComponentIndex-out> <pimComponentBSRAddress>
<pimComponentBSRExpiryTime> <pimComponentCRPHoldTime> <pimComponentStatus> ]
```

Syntax Description

show	Show running system information
snmp	show snmp
mib	show mib tables
pimComponentTable	show mib table pimComponentTable
<i>pimComponentIndex-in</i>	(Optional) pimComponentIndex
<i>__readonly__</i>	(Optional)
<i>TABLE_pimComponentTable</i>	(Optional)
<i>pimComponentIndex-out</i>	(Optional) mib table index pimComponentIndex
<i>pimComponentBSRAddress</i>	(Optional) mib object pimComponentBSRAddress
<i>pimComponentBSRExpiryTime</i>	(Optional) mib object pimComponentBSRExpiryTime
<i>pimComponentCRPHoldTime</i>	(Optional) mib object pimComponentCRPHoldTime
<i>pimComponentStatus</i>	(Optional) mib object pimComponentStatus

Command Mode

- /exec

show snmp mib pimInterfaceTable

```
show snmp mib pimInterfaceTable [ <pimInterfaceIfIndex-in> ] [ __readonly__ TABLE_pimInterfaceTable
<pimInterfaceIfIndex-out> <pimInterfaceAddress> <pimInterfaceNetMask> <pimInterfaceMode>
<pimInterfaceDR> <pimInterfaceHelloInterval> <pimInterfaceStatus> <pimInterfaceJoinPruneInterval>
<pimInterfaceCBSRPreference> ]
```

Syntax Description

show	Show running system information
snmp	show snmp
mib	show mib tables
pimInterfaceTable	show mib table pimInterfaceTable
<i>pimInterfaceIfIndex-in</i>	(Optional) pimInterfaceIndex
<i>__readonly__</i>	(Optional)
<i>TABLE_pimInterfaceTable</i>	(Optional)
<i>pimInterfaceIfIndex-out</i>	(Optional) mib table index pimInterfaceIfIndex
<i>pimInterfaceAddress</i>	(Optional) mib object pimInterfaceAddress
<i>pimInterfaceNetMask</i>	(Optional) mib object pimInterfaceNetMask
<i>pimInterfaceMode</i>	(Optional) mib object pimInterfaceMode
<i>pimInterfaceDR</i>	(Optional) mib object pimInterfaceDR
<i>pimInterfaceHelloInterval</i>	(Optional) mib object pimInterfaceHelloInterval
<i>pimInterfaceStatus</i>	(Optional) mib object pimInterfaceStatus
<i>pimInterfaceJoinPruneInterval</i>	(Optional) mib object pimInterfaceJoinPruneInterval
<i>pimInterfaceCBSRPreference</i>	(Optional) mib object pimInterfaceCBSRPreference

Command Mode

- /exec

show snmp mib pimIpMRouteNextHopTable

```
show snmp mib pimIpMRouteNextHopTable [ <ipMRouteNextHopGroup-in> <ipMRouteNextHopSource-in>
<ipMRouteNextHopSourceMask-in> <ipMRouteNextHopIfIndex-in> <ipMRouteNextHopAddress-in> ] [
__readonly__ TABLE_pimIpMRouteNextHopTable <ipMRouteNextHopGroup-out>
<ipMRouteNextHopSource-out> <ipMRouteNextHopSourceMask-out> <ipMRouteNextHopIfIndex-out>
<ipMRouteNextHopAddress-out> <pimIpMRouteNextHopPruneReason> ]
```

Syntax Description

show	Show running system information
snmp	show snmp
mib	show mib tables
pimIpMRouteNextHopTable	show mib table pimIpMRouteNextHopTable
<i>ipMRouteNextHopGroup-in</i>	(Optional) ipMRouteNextHopGroup
<i>ipMRouteNextHopSource-in</i>	(Optional) ipMRouteNextHopSource
<i>ipMRouteNextHopSourceMask-in</i>	(Optional) ipMRouteNextHopSourceMask
<i>ipMRouteNextHopIfIndex-in</i>	(Optional) ipMRouteNextHopIfIndex
<i>ipMRouteNextHopAddress-in</i>	(Optional) ipMRouteNextHopAddress
__readonly__	(Optional)
TABLE_pimIpMRouteNextHopTable	(Optional)
<i>ipMRouteNextHopGroup-out</i>	(Optional) mib table index ipMRouteNextHopGroup
<i>ipMRouteNextHopSource-out</i>	(Optional) mib table index pimComponentBSRAAddress
<i>ipMRouteNextHopSourceMask-out</i>	(Optional) mib table index pimComponentBSRExpiryTime
<i>ipMRouteNextHopIfIndex-out</i>	(Optional) mib table index pimComponentCRPHoldTime
<i>ipMRouteNextHopAddress-out</i>	(Optional) mib table index pimComponentStatus
<i>pimIpMRouteNextHopPruneReason</i>	(Optional) mib object pimIpMRouteNextHopPruneReason

Command Mode

- /exec

show snmp mib pimIpMRouteTable

```
show snmp mib pimIpMRouteTable [ <ipMRouteGroup-in> ] [ <ipMRouteSource-in> ] [
<ipMRouteSourceMask-in> ] [ __readonly__ TABLE_pimIpMRouteTable <ipMRouteGroup-out>
<ipMRouteSource-out> <ipMRouteSourceMask-out> <pimIpMRouteUpstreamAssertTimer>
<pimIpMRouteAssertMetric> <pimIpMRouteAssertMetricPref> <pimIpMRouteAssertRPTBit>
<pimIpMRouteFlags> ]
```

Syntax Description

show	Show running system information
snmp	show snmp
mib	show mib tables
pimIpMRouteTable	show mib table pimIpMRouteTable
<i>ipMRouteGroup-in</i>	(Optional) ipMRouteGroup
<i>ipMRouteSource-in</i>	(Optional) ipMRouteSource
<i>ipMRouteSourceMask-in</i>	(Optional) ipMRouteSourceMask
<i>__readonly__</i>	(Optional)
TABLE_pimIpMRouteTable	(Optional)
<i>ipMRouteGroup-out</i>	(Optional) mib table index ipMRouteGroup-out
<i>ipMRouteSource-out</i>	(Optional) mib table index ipMRouteSource-out
<i>ipMRouteSourceMask-out</i>	(Optional) mib table index ipMRouteSourceMask-out
<i>pimIpMRouteUpstreamAssertTimer</i>	(Optional) mib object pimIpMRouteUpstreamAssertTimer
<i>pimIpMRouteAssertMetric</i>	(Optional) mib object pimIpMRouteAssertMetric
<i>pimIpMRouteAssertMetricPref</i>	(Optional) mib object pimIpMRouteAssertMetricPref
<i>pimIpMRouteAssertRPTBit</i>	(Optional) mib object pimIpMRouteAssertRPTBit
<i>pimIpMRouteFlags</i>	(Optional) mib object pimIpMRouteFlags

Command Mode

- /exec

show snmp mib pimJoinPruneInterval

show snmp mib pimJoinPruneInterval [__readonly__ <pimJoinPruneInterval>]

Syntax Description

show	Show running system information
snmp	show snmp
mib	show mib tables
pimJoinPruneInterval	show mib scalar pimJoinPruneInterval
__readonly__	(Optional) Read Only
<i>pimJoinPruneInterval</i>	(Optional) mib object pimJoinPruneInterval

Command Mode

- /exec

show snmp mib pimNeighborTable

```
show snmp mib pimNeighborTable [ <pimNeighborAddress-in> ] [ __readonly__ TABLE_pimNeighborTable
<pimNeighborAddress-out> <pimNeighborIfIndex> <pimNeighborUpTime> <pimNeighborExpiryTime> ]
```

Syntax Description

show	Show running system information
snmp	show snmp
mib	show mib tables
pimNeighborTable	show mib table pimNeighborTable
<i>pimNeighborAddress-in</i>	(Optional) pimNeighborAddress
<i>__readonly__</i>	(Optional)
<i>TABLE_pimNeighborTable</i>	(Optional)
<i>pimNeighborAddress-out</i>	(Optional) mib table index pimNeighborAddress
<i>pimNeighborIfIndex</i>	(Optional) mib object pimNeighborIfIndex
<i>pimNeighborUpTime</i>	(Optional) mib object pimNeighborUpTime
<i>pimNeighborExpiryTime</i>	(Optional) mib object pimNeighborExpiryTime

Command Mode

- /exec

show snmp mib pimRPSetTable

```
show snmp mib pimRPSetTable [ <pimRPSetComponent-in> ] [ <pimRPSetGroupAddress-in> ] [
<pimRPSetGroupMask-in> ] [ <pimRPSetAddress-in> ] [ __readonly__ TABLE_pimRPSetTable
<pimRPSetGroupAddress-out> <pimRPSetGroupMask-out> <pimRPSetAddress-out> <pimRPSetHoldTime>
<pimRPSetExpiryTime> <pimRPSetComponent-out> ]
```

Syntax Description

show	Show running system information
snmp	show snmp
mib	show mib tables
pimRPSetTable	show mib table pimRPSetTable
<i>pimRPSetComponent-in</i>	(Optional) pimRPSetComponent
<i>pimRPSetGroupAddress-in</i>	(Optional) pimRPSetGroupAddress
<i>pimRPSetGroupMask-in</i>	(Optional) pimRPSetGroupMask
<i>pimRPSetAddress-in</i>	(Optional) pimRPSetAddress
__readonly__	(Optional)
TABLE_pimRPSetTable	(Optional)
<i>pimRPSetGroupAddress-out</i>	(Optional) mib table index pimRPSetGroupAddress
<i>pimRPSetGroupMask-out</i>	(Optional) mib table index pimRPSetGroupMask
<i>pimRPSetAddress-out</i>	(Optional) mib table index pimRPSetAddress
<i>pimRPSetHoldTime</i>	(Optional) mib object pimRPSetHoldTime
<i>pimRPSetExpiryTime</i>	(Optional) mib object pimRPSetExpiryTime
<i>pimRPSetComponent-out</i>	(Optional) mib table index pimRPSetComponent

Command Mode

- /exec

show snmp nms-statistics

show snmp nms-statistics [__readonly__ <header> [<nms_stats>]]

Syntax Description

show	Show running system information
snmp	Show snmp information
nms-statistics	Show SNMP NMS statistics
__readonly__	(Optional) Read Only
<i>header</i>	(Optional) NMS Statistics header
<i>nms_stats</i>	(Optional) NMS Statistics

Command Mode

- /exec

show snmp oid-statistics

```
show snmp oid-statistics [ last-access ] [ __readonly__ <header> { TABLE_snmp_gen <oid_stats> |  
TABLE_snmp_la <oid_last_access_stats> } ]
```

Syntax Description

show	Show running system information
snmp	Show snmp information
oid-statistics	Show SNMP oid statistics
last-access	(Optional) Show SNMP oid statistics of last-access
__readonly__	(Optional) Read Only
<i>header</i>	(Optional) OID Statistics header
TABLE_snmp_gen	(Optional) contains all snmp oid statistics
<i>oid_stats</i>	(Optional) OID Statistics
TABLE_snmp_la	(Optional) contains all snmp oid last access statistics
<i>oid_last_access_stats</i>	(Optional) OID Last Access Statistics

Command Mode

- /exec

show snmp pss

show snmp pss

Syntax Description

show	Show running system information
snmp	show snmp information
pss	show SNMP pss

Command Mode

- /exec

show snmp roleddebug

show snmp roleddebug

Syntax Description

show	Show running system information
snmp	show snmp information
roleddebug	show SNMP roleddebug

Command Mode

- /exec

show snmp sessions

show snmp sessions [__readonly__ { TABLE_session <dest> }]

Syntax Description

show	Show running system information
snmp	show snmp information
sessions	show snmp sessions
__readonly__	(Optional) Read Only
TABLE_session	(Optional) table displays destination
<i>dest</i>	(Optional) destination

Command Mode

- /exec

show snmp snmpv3stats

show snmp snmpv3stats

Syntax Description

show	Show running system information
snmp	show snmp information
snmpv3stats	show SNMP snmpdebug

Command Mode

- /exec

show snmp source-interface

```
show snmp source-interface [ __readonly__ { <trap_srcintf> <informs_srcintf> } ]
```

Syntax Description

show	Show running system information
snmp	show snmp information
source-interface	show source-interface through which notifications are sent
__readonly__	(Optional) Read Only
<i>trap_srcintf</i>	(Optional) Displays the source interface for traps
<i>informs_srcintf</i>	(Optional) Displays the source interface for informs

Command Mode

- /exec

show snmp trap

```
show snmp trap [ __readonly__ { TABLE_snmp_trap <trap_type><description><isEnabled> } ]
```

Syntax Description

show	Show running system information
snmp	show snmp information
trap	show snmp traps
__readonly__	(Optional) Read Only
TABLE_snmp_trap	(Optional) All snmp traps configured

Command Mode

- /exec

show snmp user

```
show snmp user [ <s0> [ engineID <s1> ] ] [ __readonly__ [ { TABLE_snmp_users <user> <auth> <priv> [
{ TABLE_groups <group> } ] [ <acl_filter> ] [ <engineID> ] } ] ]
```

Syntax Description

show	Show running system information
snmp	show snmp information
user	show SNMPv3 users
<i>s0</i>	(Optional) Name of the user
engineID	(Optional) engineID
<i>s1</i>	(Optional) Target's SNMP engineID(colon separated) for SNMPv3 inform
__readonly__	(Optional) Read Only
TABLE_snmp_users	(Optional) table displays the snmp users
TABLE_groups	(Optional) table displays the gropus for specific user
<i>user</i>	(Optional) user name
<i>auth</i>	(Optional) auth type
<i>priv</i>	(Optional) priv type
<i>group</i>	(Optional) group belongs to
<i>acl_filter</i>	(Optional) acl filter
<i>engineID</i>	(Optional) engineID for specific user

Command Mode

- /exec

show sockets buffers

show sockets buffers [{ [all <count>] [free <count>] }]

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
buffers	Display detailed buffer statistics
all	(Optional) Dump buffers from ALL list
free	(Optional) Dump buffers from FREE list
<i>count</i>	(Optional) Number of buffers to dump

Command Mode

- /exec

show sockets client

```
show sockets client { [ pid <pid> ] [ tcp | udp | raw ] [ detail ] [ kstack-ns-all ] } [ __readonly__ [
TABLE_total_clients [ <socket-type> <total-clients> ] [ <no-total-clients> ] ] [ TABLE_cl_sk { <prefix>
<client-name> <pid> <No-of-clients> } [ <fast-tcp-mts-ctrl-q> ] [ { <cancel-requests> <cancel-unblocks>
<cancel-misses> <select-drops> <select-wakes> } ] [ TABLE_det [ { <fd> <client-id> [ <mts-sap> ] } ] ] [
TABLE_st [ <soc-calls> ] [ <bind-calls> ] [ <listen-calls> ] [ <accept-calls> ] [ <acc-dispat-err> ] [
<connect-calls> ] [ <connec-dispatch> ] [ <recvmsg-dispatch> ] [ <recv-dis-nblock> ] [ <recvmsg-call> ] [
<brecv-dispatch> ] [ <fsendmsg-calls> ] [ <sendmsg-dispatch> ] [ <sendmsg-calls> ] [ <msendmsg-calls> ]
[ <select-calls> ] [ <select-dispatch> ] [ <select-need-work> ] [ <sh-calls> ] [ <close-calls> ] [ <fcntl-calls>
] [ <ioctl-calls> ] [ <setsock-calls> ] [ <getsock-calls> ] [ <getsockname-calls> ] [ <getpeer-calls> ] [
<fork-calls> ] [ <execve-calls> ] [ <dup-calls> ] [ <can-calls> ] [ <can-miss> ] [ <can-unblk-sele> ] [
<soc-ha-calls> ] [ <pfork-client> ] [ <read-fd> ] [ <write-fd> ] [ <read-fd-set> ] [ <write-fd-set> ] [
<fast-tcp-send-req> ] [ <fast-tcp-send-suc> ] [ <fast-tcp-ack> ] ] [ TABLE_sterr [ <sock-err> ] [
<sock-nodev-err> ] [ <bind-err> ] [ <lis-err> ] [ <accept-err> ] [ <connect-err> ] [ <recvmsg-err> ] [
<brecvmsg-err> ] [ <fsendmsg-err> ] [ <sendmsg-err> ] [ <msndmsg-err> ] [ <select-err> ] [ <sel-nomem-err>
] [ <shut-err> ] [ <close-err> ] [ <fcntl-err> ] [ <ioctl-err> ] [ <setsoc-err> ] [ <getsoc-err> ] [ <getsocname-err>
] [ <getpeername-err> ] [ <fork-err> ] [ <execve-err> ] [ <dup-err> ] [ <psoc-vrf-err> ] [ <psoc-nosoc-err> ]
[ <psoc-sock-null-err> ] [ <psoc-socre-err> ] [ <pbind-nsoc-err> ] [ <pbd-getsocaddr> ] [ <pbind-sobind-err>
] [ <plisten-nsoc-err> ] [ <plis-solis-err> ] [ <pacc-nsoc-err> ] [ <pacc-no-nsoc-err> ] [ <pacc-soc-null-err>
] [ <pacc-copy-err> ] [ <pacc-no-acc-err> ] [ <pacc-woublo-err> ] [ <pacc-connabo-err> ] [
<pacc-cond-wait-err> ] [ <pacc-so-err-err> ] [ <pacc-err-err> ] [ <pcon-no-soc-err> ] [ <pcon-ealready-err>
] [ <pconn-getsock> ] [ <pconn-socon-err> ] [ <pconn-einpro-err> ] [ <pconn-con-wait-err> ] [
<psend-no-soc-err> ] [ <psend-inval-iov> ] [ <psend-getsoc-err> ] [ <psend-msg-ctrl-err> ] [
<psend-sockarg-err> ] [ <psend-pru-sosend> ] [ <precv-nosock-err> ] [ <precv-inval-iovlen> ] [
<precv-pru-sorecv> ] [ <precv-cp-msg-err> ] [ <precv-cp-msg-nlen> ] [ <precv-cp-data-err> ] [
<pbrecv-rcvmsg-err> ] [ <pshut-no-soc-err> ] [ <psetsoc-val-err> ] [ <psetsoc-inv-val> ] [ <psetsoc-no-soc-err>
] [ <psetsoc-sosetopt> ] [ <pgetsoc-no-socerr> ] [ <pgetsoc-cp-err> ] [ <pgetsoc-val-err> ] [ <pgetsoc-sogt-err>
] [ <pgtsoc-no-soc-err> ] [ <pgtsoc-cp-err> ] [ <pgtsoc-pru-soc-err> ] [ <pgtsoc-cpout-err> ] [
<pgtprne-no-soc-err> ] [ <pgtprne-enot-err> ] [ <pgtprne-cp-err> ] [ <pgtprne-pru-pradd> ] [
<pgtprne-cpout-err> ] [ <pclose-no-soc-err> ] [ <pclose-socnull-err> ] [ <pclose-p-cls2-err> ] [
<pfcntl-no-soc-err> ] [ <pfcntl-soc-null> ] [ <pfcntl-enotsup> ] [ <pfcntl-einval-err> ] [ <pioctl-no-soc-err>
] [ <pioctl-enotsup> ] [ <pioctl-pru-cntl> ] [ <pfork-enomem-err> ] [ <pdup-no-soc-err> ] [ <pudp-soc-null-err>
] [ <ha-nomem-err> ] [ <ha-tlv-err> ] [ <ha-soc-arg-err> ] [ <ha-cli-tlv-err> ] [ <ha-pss-upd-err> ] [
<ha-no-soc-err> ] [ <ha-soc-tlv-err> ] [ <ha-soc-pss-upd> ] [ <ha-inpcb-tlv> ] [ <ha-inpcb-pssky> ] [
<ha-ip-mopt-tlv> ] [ <ha-ip-mopt-pss> ] [ <ha-ip6-mopt-tlv> ] [ <ha-ip6-mopt-pss> ] [ <ha-tcpcb-tlv> ] [
<ha-tcpcb-pss> ] [ <ft-tcp-wblock> ] [ <ft-send-p-sndmsg> ] [ <ft-ack-rcv-no-soc> ] [ <lxc-tgid-err> ] ] [
TABLE_sp_cl [ <can-requests> <can-unblocks> <can-misses> <sel-drops> <sel-wakes> ] ] ] ]
```

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
client	Display sockets client information
pid	(Optional) Display specific client process information
<i>pid</i>	(Optional) Display client process <pid>

<code>tcp</code>	(Optional) Display TCP clients
<code>udp</code>	(Optional) Display UDP clients
<code>raw</code>	(Optional) Display RAW clients
<code>detail</code>	(Optional) Display socket details
<code>kstack-ns-all</code>	(Optional) Show kernel clients for all namespaces
<code>__readonly__</code>	(Optional)
<code>TABLE_total_clients</code>	(Optional) Total no of client sockets
<code>socket-type</code>	(Optional) Sockets type
<code>total-clients</code>	(Optional) total clients
<code>no-total-clients</code>	(Optional) number of total clients
<code>TABLE_cl_sk</code>	(Optional) Display Client sockets
<code>prefix</code>	(Optional) Prefix to the sockets
<code>client-name</code>	(Optional) Display socket client info
<code>pid</code>	(Optional) Display client process <pid>
<code>No-of-clients</code>	(Optional) Number of socket clients
<code>fast-tcp-mts-ctrl-q</code>	(Optional) Fast tcp mts control queue
<code>cancel-requests</code>	(Optional) cancel requests
<code>cancel-unblocks</code>	(Optional) cancel unblocks
<code>cancel-misses</code>	(Optional) cancel misses
<code>select-drops</code>	(Optional) select drops
<code>select-wakes</code>	(Optional) select wakes
<code>TABLE_det</code>	(Optional) Display Socket client Details
<code>fd</code>	(Optional) Client socket fd
<code>client-id</code>	(Optional) Client socket id
<code>mts-sap</code>	(Optional) socket mts addr sap
<code>TABLE_st</code>	(Optional) Sock detail Ctrl statistics
<code>soc-calls</code>	(Optional) sockets calls
<code>bind-calls</code>	(Optional) socket bind calls
<code>listen-calls</code>	(Optional) socket listen calls

<i>accept-calls</i>	(Optional) socket accept calls
<i>acc-dispat-err</i>	(Optional) socket accept dispatch error
<i>connect-calls</i>	(Optional) socket connect calls
<i>connec-dispatch</i>	(Optional) socket dispatch calls
<i>recvmsg-dispatch</i>	(Optional) receive msg dispatch
<i>recv-dis-nblock</i>	(Optional) receive dispatch nonblock
<i>recvmsg-call</i>	(Optional) receive message call
<i>brecv-dispatch</i>	(Optional) broadcast receive dispatch
<i>fsendmsg-calls</i>	(Optional) forward send message dispatch
<i>sendmsg-dispatch</i>	(Optional) send message dispatch
<i>sendmsg-calls</i>	(Optional) send message calls
<i>msendmsg-calls</i>	(Optional) multicast send message calls
<i>select-calls</i>	(Optional) select calls
<i>select-dispatch</i>	(Optional) select dispatch
<i>select-need-work</i>	(Optional) select need work
<i>sh-calls</i>	(Optional) show calls
<i>close-calls</i>	(Optional) close calls
<i>fcntl-calls</i>	(Optional) fcntl calls
<i>ioctl-calls</i>	(Optional) ioctl calls
<i>setsock-calls</i>	(Optional) setsock calls
<i>getsock-calls</i>	(Optional) getsock calls
<i>getsockname-calls</i>	(Optional) get socket name calls
<i>getpeer-calls</i>	(Optional) get peer calls
<i>fork-calls</i>	(Optional) fork calls
<i>execve-calls</i>	(Optional) execve calls
<i>dup-calls</i>	(Optional) duplicate calls
<i>can-calls</i>	(Optional) cancel calls
<i>can-miss</i>	(Optional) cancel miss
<i>can-unblk-sele</i>	(Optional) cancel unblock select

<i>soc-ha-calls</i>	(Optional) socket ha calls
<i>pfork-client</i>	(Optional) pfork client
<i>read-fd</i>	(Optional) socket read fd
<i>write-fd</i>	(Optional) socket write fd
<i>read-fd-set</i>	(Optional) socket read fd set
<i>write-fd-set</i>	(Optional) socket write fd set
<i>fast-tcp-send-req</i>	(Optional) socket fast tcp send request
<i>fast-tcp-send-suc</i>	(Optional) socket fast tcp send success
<i>fast-tcp-ack</i>	(Optional) socket fast tcp ack
TABLE_sterr	(Optional) Client Socket Error Statistics
<i>sock-err</i>	(Optional) socket error
<i>sock-nODEV-err</i>	(Optional) socket nodev error
<i>bind-err</i>	(Optional) socket bind error
<i>lis-err</i>	(Optional) socket listen error
<i>accept-err</i>	(Optional) socket accept error
<i>connect-err</i>	(Optional) socket connect error
<i>recvmsg-err</i>	(Optional) socket receive message error
<i>brcvmsg-err</i>	(Optional) socket broadcast receive message error
<i>fsendmsg-err</i>	(Optional) socket forward send message error
<i>sendmsg-err</i>	(Optional) socket send message error
<i>msndmsg-err</i>	(Optional) socket multicast send message error
<i>select-err</i>	(Optional) socket select error
<i>sel-nomem-err</i>	(Optional) socket select no member error
<i>shut-err</i>	(Optional) socket shutdown error
<i>close-err</i>	(Optional) socket close error
<i>fcntl-err</i>	(Optional) socket fcntl error
<i>ioctl-err</i>	(Optional) socket ioctl error
<i>setsoc-err</i>	(Optional) set socket error
<i>getsoc-err</i>	(Optional) get socket error

<i>getsocname-err</i>	(Optional) get socket name error
<i>getpeername-err</i>	(Optional) get peer name error
<i>fork-err</i>	(Optional) socket fork error
<i>execve-err</i>	(Optional) socket execve error
<i>dup-err</i>	(Optional) socket duplicate error
<i>psoc-vrf-err</i>	(Optional) psocket vrf error
<i>psoc-nosoc-err</i>	(Optional) psocket nosoc error
<i>psoc-sock-null-err</i>	(Optional) psocket socket null error
<i>psoc-socre-err</i>	(Optional) psocket socre error
<i>pbind-nsock-err</i>	(Optional) pbind nsock error
<i>pbid-getsocaddr</i>	(Optional) pbd getsocaddr
<i>pbind-sobind-err</i>	(Optional) pbind sobind error
<i>plisten-nsoc-err</i>	(Optional) plisten nsoc error
<i>plis-solis-err</i>	(Optional) plisten socket listen error
<i>pacc-nsoc-err</i>	(Optional) paccept new socket error
<i>pacc-no-nsoc-err</i>	(Optional) paccept no new socket error
<i>pacc-soc-null-err</i>	(Optional) paccept socket null error
<i>pacc-copy-err</i>	(Optional) paccept copy error
<i>pacc-no-acc-err</i>	(Optional) paccept no accept error
<i>pacc-woublo-err</i>	(Optional) paccept would block error
<i>pacc-connabo-err</i>	(Optional) paccept connect abort error
<i>pacc-cond-wait-err</i>	(Optional) paccept condition wait error
<i>pacc-so-err-err</i>	(Optional) paccept socket error
<i>pacc-err-err</i>	(Optional) paccept error
<i>pcon-no-soc-err</i>	(Optional) pconnect no socket error
<i>pcon-ealready-err</i>	(Optional) pconnect ready error
<i>pconn-getsock</i>	(Optional) pconnect get socket
<i>pconn-socon-err</i>	(Optional) pconnect socket on error
<i>pconn-einpro-err</i>	(Optional) pconnect einprogress error

<i>pconn-con-wait-err</i>	(Optional) pconnect condition wait error
<i>psend-no-soc-err</i>	(Optional) psend no socket error
<i>psend-inval-iov</i>	(Optional) psend invalidate iov
<i>psend-getsoc-err</i>	(Optional) psend getsocket error
<i>psend-msg-ctrl-err</i>	(Optional) psend message control error
<i>psend-sockarg-err</i>	(Optional) psend socket argument error
<i>psend-pru-sosend</i>	(Optional) psend pru socket send
<i>precv-nosock-err</i>	(Optional) preceive no socket error
<i>precv-inval-iovlen</i>	(Optional) preceive invalidate iovlen
<i>precv-pru-sorecv</i>	(Optional) preceive pru so receive
<i>precv-cp-msg-err</i>	(Optional) preceive copy message error
<i>precv-cp-msg-nlen</i>	(Optional) preceive copy message new length
<i>precv-cp-data-err</i>	(Optional) preceive copy data error
<i>pbrecv-rcvmsg-err</i>	(Optional) preceive receive message error
<i>pshut-no-soc-err</i>	(Optional) pshutdown no socket error
<i>psetsoc-val-err</i>	(Optional) pset socket value error
<i>psetsoc-inv-val</i>	(Optional) pset socket invalidate error
<i>psetsoc-no-soc-err</i>	(Optional) pset socket no socket error
<i>psetsoc-sosetopt</i>	(Optional) pset socket set opt
<i>pgetsoc-no-socerr</i>	(Optional) pget socket no socket error
<i>pgetsoc-cp-err</i>	(Optional) pget socket copy error
<i>pgetsoc-val-err</i>	(Optional) pget socket validate error
<i>pgetsoc-sogt-err</i>	(Optional) pget socket sogt error
<i>pgtsoc-no-soc-err</i>	(Optional) pget socket no socket error
<i>pgtsoc-cp-err</i>	(Optional) pget socket copy error
<i>pgtsoc-pru-soc-err</i>	(Optional) pget socket pru socket error
<i>pgtsoc-cpout-err</i>	(Optional) pget socket copy out error
<i>pgtprne-no-soc-err</i>	(Optional) pget peer name no socket error
<i>pgtprne-enot-err</i>	(Optional) pget peer name enot connect error

<i>pgtprne-cp-err</i>	(Optional) pget peer name copy error
<i>pgtprne-pru-pradd</i>	(Optional) pget peer name pru peer address
<i>pgtprne-cpout-err</i>	(Optional) pget peer name copy out error
<i>pclose-no-soc-err</i>	(Optional) pclose no socket error
<i>pclose-socnull-err</i>	(Optional) pclose socket null error
<i>pclose-p-cls2-err</i>	(Optional) pclose p close2 error
<i>pfcntl-no-soc-err</i>	(Optional) pfcntl no socket error
<i>pfcntl-soc-null</i>	(Optional) pfcntl socket null
<i>pfcntl-enotsup</i>	(Optional) pfcntl enotsupport errors
<i>pfcntl-einval-err</i>	(Optional) pfcntl invalidate error
<i>pioctl-no-soc-err</i>	(Optional) pioctl no socket error
<i>pioctl-enotsup</i>	(Optional) pioctl enotsup
<i>pioctl-pru-cntl</i>	(Optional) pioctl pru cntl
<i>pfork-enomem-err</i>	(Optional) pfork eno-memory error
<i>pdup-no-soc-err</i>	(Optional) pudp no socket error
<i>pudp-soc-null-err</i>	(Optional) pudp socket null error
<i>ha-nomem-err</i>	(Optional) ha no memory error
<i>ha-tlv-err</i>	(Optional) ha tlv error
<i>ha-soc-arg-err</i>	(Optional) ha socket argument error
<i>ha-cli-tlv-err</i>	(Optional) ha cli tlv error
<i>ha-pss-upd-err</i>	(Optional) ha pss udp error
<i>ha-no-soc-err</i>	(Optional) ha no socket error
<i>ha-soc-tlv-err</i>	(Optional) ha socket tlv error
<i>ha-soc-pss-upd</i>	(Optional) ha socket pss udp
<i>ha-inpcb-tlv</i>	(Optional) ha inpcb tlv value
<i>ha-inpcb-pssky</i>	(Optional) ha inpcb pssky value
<i>ha-ip-mopt-tlv</i>	(Optional) ha ip mopt tlv value
<i>ha-ip-mopt-pss</i>	(Optional) ha ip mopt pss value
<i>ha-ip6-mopt-tlv</i>	(Optional) ha ip6 mopt tlv value

<i>ha-ip6-mopt-pss</i>	(Optional) ha ip6 mopt pss value
<i>ha-tcpcb-tlv</i>	(Optional) ha socket update tcpcb to tlv error
<i>ha-tcpcb-pss</i>	(Optional) ha socket update tcpcb psskey update error
<i>ft-tcp-wblock</i>	(Optional) fast tcp send would block error
<i>ft-send-p-sndmsg</i>	(Optional) fast tcp send p_sendmsg errors
<i>ft-ack-rcv-no-soc</i>	(Optional) fast ack receive no socket
<i>lxc-tgid-err</i>	(Optional) Containers tgid err
TABLE_sp_cl	(Optional) Sock specific Ctrl statistics
<i>can-requests</i>	(Optional) socket control cancel request
<i>can-unblocks</i>	(Optional) socket cancel unblocks
<i>can-misses</i>	(Optional) socket cancel misses
<i>sel-drops</i>	(Optional) select drops
<i>sel-wakes</i>	(Optional) select wakes

Command Mode

- /exec

show sockets connection

```
show sockets connection [ pid <pid> | tcp | udp | raw ] [ local { <srcIP> | <srcIP6> } ] [ foreign { <dstIP> | <dstIP6> } ] [ detail ] [ keydetails ] [ __readonly__ TABLE_vrf <vrf-name-out> TABLE_afi <afi>
TABLE_conn <prot> <tcp-state> <rcv-count> <laddr> <lport> <faddr> <fport> <intf> <rcv-count>
<snd-count> <type> <ttl> <tos> <options> <state> <iss> <snd-una> <snd-nxt> <snd_wnd> <irs> <rcv-nxt>
<rcv-wnd> <snd-cwnd> <srtt> <rtt> <rttvar> <krtt> <rttmin> <mss> <dur> <flags> <md5-cnt> <md5-host>
<md5-err> <rcv-hiwat> <rcv-lowat> <rcv-flags> <snd-hiwat> <snd-lowat> <snd-flags> <tcp-count>
<udp-count> <raw-count> ]
```

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
connection	Display connection information
pid	(Optional) Display specific client process connection status
<i>pid</i>	(Optional) Display client process connection status <pid>
tcp	(Optional) Display all TCP connections
udp	(Optional) Display all UDP connections
raw	(Optional) Display all raw connections
local	(Optional) Display all TCP connections with specified local address
<i>srcIP</i>	(Optional) Display all TCP connections with specified local address
foreign	(Optional) Display all TCP connections with specified foreign address
<i>dstIP</i>	(Optional) Display all TCP connections with specified foreign address
detail	(Optional) Display detailed connection information
keydetails	(Optional) Display md5 key specific details
__readonly__	(Optional)
TABLE_vrf	(Optional) vrf table
<i>vrf-name-out</i>	(Optional) vrf name out
TABLE_afi	(Optional) afi table
<i>afi</i>	(Optional) afi id
TABLE_conn	(Optional) connection table
<i>prot</i>	(Optional) socket protocol
<i>tcp-state</i>	(Optional) socket tcp state

<i>rcv-count</i>	(Optional) socket connection receive count
<i>laddr</i>	(Optional) socket conenction laddr
<i>lport</i>	(Optional) socket connection lport
<i>faddr</i>	(Optional) socket connection faddr
<i>fport</i>	(Optional) socket connection fport
<i>intf</i>	(Optional) socket connection interface
<i>snd-count</i>	(Optional) socket connection send count
<i>type</i>	(Optional) socket connection type
<i>ttl</i>	(Optional) socket connection ttl
<i>tos</i>	(Optional) socket connection tos
<i>options</i>	(Optional) socket connection option
<i>state</i>	(Optional) socket connection state
<i>iss</i>	(Optional) socket connection iss
<i>snd-una</i>	(Optional) socket connection send unavailable
<i>snd-nxt</i>	(Optional) socket connection send next
<i>snd_wnd</i>	(Optional) socket connection send window
<i>irs</i>	(Optional) socket connection irs
<i>rcv-nxt</i>	(Optional) socket connection receive next
<i>rcv-wnd</i>	(Optional) socket connection receive window
<i>snd-cwnd</i>	(Optional) socket connection close sent window
<i>srtt</i>	(Optional) socket connection srtt
<i>rtt</i>	(Optional) socket connection rtt
<i>rttvar</i>	(Optional) socket connection rttvar
<i>krtt</i>	(Optional) socket connection krtt
<i>rttmin</i>	(Optional) socket connection rtt mintues
<i>mss</i>	(Optional) socket connection mss
<i>dur</i>	(Optional) socket connection duration
<i>flags</i>	(Optional) socket connection flags
<i>md5-cnt</i>	(Optional) socket connection md5 count

<i>md5-host</i>	(Optional) socket connection md5 host
<i>md5-err</i>	(Optional) socket connection md5 error
<i>rcv-hiwater</i>	(Optional) socket connection receive hiwater
<i>rcv-lowat</i>	(Optional) socket connection receive lowat
<i>rcv-flags</i>	(Optional) socket connection receive flags
<i>snd-hiwater</i>	(Optional) socket connection send hiwater
<i>snd-lowat</i>	(Optional) socket connection send lowat
<i>snd-flags</i>	(Optional) socket connection send flags
<i>tcp-count</i>	(Optional) socket connection tcp count
<i>udp-count</i>	(Optional) socket connection udp count
<i>raw-count</i>	(Optional) socket connection raw count

Command Mode

- /exec

show sockets keychain-dump

show sockets keychain-dump

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
keychain-dump	Dump the pss information for keychains

Command Mode

- /exec

show sockets local-port-range

```
show sockets local-port-range [ __readonly__ <kstack_local_port_range_start> <kstack_local_port_range_end>
<netstack_local_port_range_start> <netstack_local_port_range_end> ]
```

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
local-port-range	Display local port range
__readonly__	(Optional)
<i>kstack_local_port_range_start</i>	(Optional) Kstack local port range start
<i>kstack_local_port_range_end</i>	(Optional) Kstack local port range end
<i>netstack_local_port_range_start</i>	(Optional) Netstack local port range start
<i>netstack_local_port_range_end</i>	(Optional) Netstack local port range end

Command Mode

- /exec

show sockets performance

show sockets performance [clear]

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
performance	Display detailed perf statistics
clear	(Optional) Clear perf statistics

Command Mode

- /exec

show sockets secure-lxc

show sockets secure-lxc

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
secure-lxc	Display secure-container sockets information

Command Mode

- /exec

show sockets statistics

```

show sockets statistics [ all | tcp | tcp6 | tcpsum | udp | udp6 | udpsum | raw | raw6 | rawsum ] [ __readonly__
[ { TABLE_stat [ <rx-total> ] [ <rx-bad-csum> ] [ <rx-bad-offset> ] [ <rx-too-short> ] [ <rx-bad-md5> ] [
<rx-inseq-pack> ] [ <rx-inseq-bytes> ] [ <rx-dup-pack> ] [ <rx-dup-bytes> ] [ <rx-partdup-pack> ] [
<rx-partdup-bytes> ] [ <rx-oo-pack> ] [ <rx-oo-bytes> ] [ <rx-afterwin-pack> ] [ <rx-afterwin-bytes> ] [
<rx-afterclose-pack> ] [ <rx-winprobe-pack> ] [ <rx-winupdate-pack> ] [ <rx-dupack-pack> ] [
<rx-dupack-unsent-pack> ] [ <rx-ack-pack> ] [ <rx-ack-bytes> ] [ <rx-rcv-memdrop> ] [ <rx-dig-mssing> ]
[ <rx-dig-unexpected> ] [ <rx-dig-notused> ] [ <rx-dig-valid> ] [ <rx-dig-invalid> ] [ <rx-get-passwd-fail> ]
[ <rx-md5-mbuf-exded> ] [ <rx-uspec-src-recvd> ] [ <rx-pkt-too-short> ] [ <rx-sin-finest> ] [ <rx-black-hole-syn>
] [ <rx-black-hole> ] [ <rx-drop-no-inpcb> ] [ <rx-drop-notecpcb> ] [ <rx-drp-sock-closed> ] [ <rx-syn-with-rst>
] [ <rx-syn-drop> ] [ <rx-bandlim> ] [ <rx-forged-pkt> ] [ <rx-drp-mbcst> ] [ <rx-drp-syn-add> ] [
<rx-drp-syn-recvd> ] [ <rx-drp-cc-sent> ] [ <rx-drp-rst-ccsent> ] [ <rx-frecv-enqueue> ] [
<rx-frecv-enqueue-fail> ] [ <rx-ftp-cant-rcv-more> ] [ <rx-ftp-data-ack-toapp-fail> ] [
<rx-ftp-data-ack-toapp> ] [ <tx-total> ] [ <tx-urg> ] [ <tx-ctrl> ] [ <tx-data-pack> ] [ <tx-data-bytes> ] [
<tx-reasm-pack> ] [ <tx-reasm-bytes> ] [ <tx-ackonly-pack> ] [ <tx-winprobe-pack> ] [ <tx-winupdate-bytes>
] [ <tx-encrypt> ] [ <tx-unencrypt> ] [ <tx-md5rst> ] [ <tx-conn-init> ] [ <tx-conn-accepted> ] [ <tx-conn-estd>
] [ <closed> ] [ <dropped> ] [ <emb-dropped> ] [ <tx-rxmt-timeout> ] [ <tx-rxmt-timeout-dropped> ] [
<tx-ka-timeout> ] [ <tx-ka-probe> ] [ <tx-ka-drop> ] [ <gen-seg-timed> ] [ <gen-rtt-updated> ] [ <gen-delack>
] [ <gen-persist-timeout> ] [ <gen-paws-drop> ] [ <gen-predack> ] [ <gen-predat> ] [ <gen-pcb-cachemiss>
] [ <gen-cache-drtt> ] [ <gen-cache-drttvar> ] [ <gen-cached-ssthresh> ] [ <gen-usedrtt> ] [ <gen-usedrttvar>
] [ <gen-usedssthresh> ] [ <gen-persistdrop> ] [ <gen-badsyn> ] [ <gen-mturedsent> ] [ <gen-list-endrop> ] [
<gen-rpm-bind-synsock> ] [ <gen-rpm-bindsynadd> ] [ <gen-rpm-bindlookup> ] [ <gen-rpm-bindsetsock>
] [ <gen-rpm-unbind-getpass> ] [ <gen-rpm-unbinduser1> ] [ <gen-rpm-unbinduser2> ] [
<gen-rpm-unbindrollover> ] [ <gen-rpm-unbind-synfree> ] [ <gen-rpm-unbind-tpfree> ] [ <syn-sc-added> ]
[ <syn-retransmitted> ] [ <syn-dupsyn> ] [ <syn-dropped> ] [ <syn-completed> ] [ <syn-bucket-overflow> ]
[ <syn-cache-overflow> ] [ <syn-sc-reset> ] [ <syn-sc-stale> ] [ <syn-sc-aborted> ] [ <syn-sc-badack> ] [
<syn-sc-unreach> ] [ <syn-sc-zonefail> ] [ <syn-sc-sendcookie> ] [ <syn-sc-recvcookie> ] [ <syn-sc-crosshits>
] [ <syn-sc-supsyncrosshits> ] [ <syn-sc-removecrosshits> ] [ <udp-rx-total> ] [ <udp-rx-bad-csum> ] [
<udp-rx-no-csum> ] [ <udp-rx-too-short> ] [ <udp-rx-bad-len> ] [ <udp-rx-no-port> ] [ <udp-rx-no-port-bcast>
] [ <udp-rx-no-port-mcast> ] [ <udp-rx-full-socket-drop> ] [ <udp-tx-total> ] [ <raw-rx-version> ] [
<raw-rx-rcvd> ] [ <raw-rx-no-port> ] [ <raw-rx-full-socket-drop> ] [ <raw-tx-sent> ] [ <inpcb-tot-alloc> ] [
<inpcb-tot-bind> ] [ <inpcb-tot-laddr> ] [ <inpcb-tot-connect> ] [ <inpcb-tot-disconnect> ] [ <inpcb-tot-detach>
] [ <inpcb-tot-detach-noinc> ] [ <inpcb-tot-detach-rort> ] [ <inpcb-tot-rtfree> ] [ <inpcb-tot-setsock-addr> ]
[ <inpcb-tot-setpeeraddr> ] [ <inpcb-tot-notify> ] [ <inpcb-tot-lookup-npacl-deny> ] [
<inpcb-tot-lookup-npacl-allow> ] [ <inpcb-tot-inshash-ipv4> ] [ <inpcb-tot-inshash-ipv6> ] [
<inpcb-tot-brehash-ipv4> ] [ <inpcb-tot-brehash-ipv6> ] [ <inpcb-tot-bremhash> ] [ <inpcb-err-allocnomem>
] [ <inpcb-err-bindeinavl> ] [ <inpcb-err-eaddrinuse> ] [ <inpcb-err-eagain> ] [ <inpcb-err-eagain2> ] [
<inpcb-err-eaddrnotavail> ] [ <inpcb-err-eafnosupport> ] [ <inpcb-err-enomem> ] [ <inpcb-err-ehostunreach>
] [ <inpcb-err-laddr-errno> ] [ <inpcb-err-laddr-ehostunreach2> ] [ <inpcb-err-connectladdr> ] [
<inpcb-err-connect-eaddrinuse> ] [ <inpcb-err-connbinding> ] [ <inpcb-err-sockaddrnomem> ] [
<inpcb-err-sockaddrreconnreset> ] [ <inpcb-err-peeraddr-enomem> ] [ <inpcb-err-econnreset> ] [
<inpcb-err-respond-enobufs> ] [ <inpcb-err-binshash-enobufs> ] [ <in6pcb-tot-setport> ] [ <in6pcb-tot-bind>
] [ <in6pcb-tot-laddr> ] [ <in6pcb-tot-connect> ] [ <in6pcb-tot-disconnect> ] [ <in6pcb-tot-detach> ] [
<in6pcb-tot-sockaddr> ] [ <in6pcb-tot-peeraddr> ] [ <in6pcb-tot-notify> ] [ <in6pcb-tot-lookuplocal> ] [
<in6pcb-tot-hashnpacli-deny> ] [ <in6pcb-err-setporteagain> ] [ <in6pcb-err-setporteagain2> ] [
<in6pcb-err-seteagain3> ] [ <in6pcb-bind-eafnosupport> ] [ <in6pcb-err-bindeaddrinuse> ] [
<in6pcb-err-bindeaddrinuse2> ] [ <in6pcb-err-bindeaddrinuse3> ] [ <in6pcb-err-bindeaddrinuse4> ] [
<in6pcb-err-bindsetport> ] [ <in6pcb-err-bindeagain> ] [ <in6pcb-err-laddr-eafnosupport> ] [
<in6pcb-err-eaddrnotavail> ] [ <in6pcb-err-laddr-enomem> ] [ <in6pcb-err-laddr-ehostreach> ] [

```

```
<in6pcb-err-laddr-ehostunreach2> ] [ <in6pcb-err-laddr-ehostunreach3> ] [ <in6pcb-err-laddr-ehostunreach4>
] [ <in6pcb-err-laddr-enxio> ] [ <in6pcb-err-connladdr> ] [ <in6pcb-err-conneaddrinuse> ] [
<in6pcb-err-connbind> ] [ <in6pcb-err-sockaddr-enomem> ] [ <in6pcb-err-v4maps-enomem> ] [
<in6pcb-err-setsock-noinp> ] [ <in6pcb-err-setpeer-noinp> ] [ <in6pcb-err-sockaddr-noinp> ] [
<in6pcb-err-peeraddr-noinp> ] [ <in6pcb-err-notify-einavl> ] [ <in6pcb-err-ctloutput-nosoopt> ] } } ] ]
```

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
statistics	Display sockets statistics
all	(Optional) Display TCP/UDP/RAW v4/v6 protocols statistics
tcp	(Optional) Display TCP v4 protocol statistics
tcp6	(Optional) Display TCP v6 protocol statistics
tcpsum	(Optional) Display sum of TCP v4 and TCP v6 protocols statistics
udp	(Optional) Display UDP v4 protocol statistics
udp6	(Optional) Display UDP v6 protocol statistics
udpsum	(Optional) Display sum of UDP v4 and UDP v6 protocols statistics
raw	(Optional) Display RAW v4 protocol statistics
raw6	(Optional) Display RAW v6 protocol statistics
rawsum	(Optional) Display sum of RAW v4 and RAW v6 protocols statistics
__readonly__	(Optional)
TABLE_stat	(Optional) sockets statistics table
<i>rx-total</i>	(Optional) total packets received
<i>rx-bad-csum</i>	(Optional) packets received with ccksum errs
<i>rx-bad-offset</i>	(Optional) packets received with bad offset
<i>rx-too-short</i>	(Optional) packets received too short
<i>rx-bad-md5</i>	(Optional) Recieved bad digest
<i>rx-inseq-pack</i>	(Optional) packets received in sequence
<i>rx-inseq-bytes</i>	(Optional) bytes received in sequence
<i>rx-dup-pack</i>	(Optional) duplicate-only packets received
<i>rx-dup-bytes</i>	(Optional) duplicate-only bytes received
<i>rx-partdup-pack</i>	(Optional) packets with some duplicate data

<i>rx-partdup-bytes</i>	(Optional) dup. bytes in part-dup. packets
<i>rx-oo-pack</i>	(Optional) out-of-order packets received
<i>rx-oo-bytes</i>	(Optional) out-of-order bytes received
<i>rx-afterwin-pack</i>	(Optional) packets with data after window
<i>rx-afterwin-bytes</i>	(Optional) bytes rcvd after window
<i>rx-afterclose-pack</i>	(Optional) packets rcvd after close
<i>rx-winprobe-pack</i>	(Optional) rcvd window probe packets
<i>rx-winupdate-pack</i>	(Optional) rcvd window update packets
<i>rx-dupack-pack</i>	(Optional) rcvd duplicate acks
<i>rx-dupack-unsent-pack</i>	(Optional) rcvd acks for unsent data
<i>rx-ack-pack</i>	(Optional) rcvd ack packets
<i>rx-ack-bytes</i>	(Optional) bytes acked by rcvd acks
<i>rx-rcv-memdrop</i>	(Optional) packets dropped for lack of memory
<i>rx-dig-mssing</i>	(Optional) digest missing
<i>rx-dig-unexpected</i>	(Optional) digest unexpected
<i>rx-dig-notused</i>	(Optional) digest not used
<i>rx-dig-valid</i>	(Optional) digest valid
<i>rx-dig-invalid</i>	(Optional) digest invalid
<i>rx-get-passwd-fail</i>	(Optional) get pass failed for RST
<i>rx-md5-mbuf-exded</i>	(Optional) md5 passwd exceeds mbuf
<i>rx-uspec-src-recv</i>	(Optional) Dropped Unspecified src pkt recieved
<i>rx-pkt-too-short</i>	(Optional) Dropped Packet too short
<i>rx-sin-finest</i>	(Optional) Dropped packet set with SYN/FIN
<i>rx-black-hole-syn</i>	(Optional) Dropped black hole SYN
<i>rx-black-hole</i>	(Optional) Dropped black hole
<i>rx-drop-no-inpcb</i>	(Optional) Dropped no inpcb
<i>rx-drop-notpcb</i>	(Optional) Dropped no tcpb
<i>rx-drp-sock-closed</i>	(Optional) Dropped socket closed
<i>rx-syn-with-rst</i>	(Optional) Dropped SYN with reset

<i>rx-syn-drop</i>	(Optional) Dropped SYN
<i>rx-bandlim</i>	(Optional) Dropped Bandlim rst open port
<i>rx-forged-pkt</i>	(Optional) Dropped Same src/dst
<i>rx-drp-mbcst</i>	(Optional) Dropped Broadcast/Multicast
<i>rx-drp-syn-add</i>	(Optional) Dropped Adding SYN failed
<i>rx-drp-syn-recvd</i>	(Optional) ACK recvd not for our SYN
<i>rx-drp-cc-sent</i>	(Optional) Dropped cc sent
<i>rx-drp-rst-ccsent</i>	(Optional) Dropped cc sent with reset
<i>rx-frecv-enqueue</i>	(Optional) Fast recv packets enqueued
<i>rx-frecv-enqueue-fail</i>	(Optional) Fast recv enqueue failed
<i>rx-ftp-cant-rcv-more</i>	(Optional) Fast TCP can not recv more
<i>rx-ftp-data-ack-toapp-fail</i>	(Optional) Fast TCP data ACK to app failed
<i>rx-ftp-data-ack-toapp</i>	(Optional) Fast TCP data ACK to app
<i>tx-total</i>	(Optional) total packets sent
<i>tx-urg</i>	(Optional) packets sent with URG only
<i>tx-ctrl</i>	(Optional) control (SYN FIN RST) packets sent
<i>tx-data-pack</i>	(Optional) data packets sent
<i>tx-data-bytes</i>	(Optional) data bytes sent
<i>tx-reasm-pack</i>	(Optional) data packets retransmitted
<i>tx-reasm-bytes</i>	(Optional) data bytes retransmitted
<i>tx-ackonly-pack</i>	(Optional) ack-only packets sent
<i>tx-winprobe-pack</i>	(Optional) window probes sent
<i>tx-winupdate-bytes</i>	(Optional) window update-only packets sent
<i>tx-encrypt</i>	(Optional) Encrypted packets sent
<i>tx-unencrypt</i>	(Optional) Unencrypted packets sent
<i>tx-md5rst</i>	(Optional) No of encrypted RST packets
<i>tx-conn-init</i>	(Optional) connections initiated
<i>tx-conn-accepted</i>	(Optional) connections accepted
<i>tx-conn-estd</i>	(Optional) connections established

<i>closed</i>	(Optional) conn. closed (includes drops)
<i>dropped</i>	(Optional) connections dropped
<i>emb-dropped</i>	(Optional) embryonic connections dropped
<i>tx-rxmt-timeout</i>	(Optional) total rxmt timeout
<i>tx-rxmt-timeout-dropped</i>	(Optional) connections dropped in rxmt timeout
<i>tx-ka-timeout</i>	(Optional) keepalive timeouts
<i>tx-ka-probe</i>	(Optional) keepalive probes sent
<i>tx-ka-drop</i>	(Optional) connections dropped in keepalive
<i>gen-seg-timed</i>	(Optional) segs where we tried to get rtt
<i>gen-rtt-updated</i>	(Optional) times we succeeded to get rtt
<i>gen-delack</i>	(Optional) delayed acks sent
<i>gen-persist-timeout</i>	(Optional) persist timeouts
<i>gen-paws-drop</i>	(Optional) segments dropped due to PAWS
<i>gen-predack</i>	(Optional) hdr predict ok for acks
<i>gen-preddat</i>	(Optional) hdr predict ok for data pkts
<i>gen-pcb-cachemiss</i>	(Optional) PCB cache miss
<i>gen-cache-drtt</i>	(Optional) times cached RTT in route updated
<i>gen-cache-drttvar</i>	(Optional) times cached rttvar updated
<i>gen-cached-ssthresh</i>	(Optional) times cached ssthresh updated
<i>gen-usedrtt</i>	(Optional) times RTT initialized from route
<i>gen-usedrttvar</i>	(Optional) times RTTVAR initialized from rt
<i>gen-usedssthresh</i>	(Optional) times ssthresh initialized from rt
<i>gen-persistdrop</i>	(Optional) timeout in persist state
<i>gen-badsyn</i>	(Optional) bogus SYN, e.g. premature ACK
<i>gen-mturedsent</i>	(Optional) resends due to MTU discovery
<i>gen-list-endrop</i>	(Optional) listen queue overflows
<i>gen-rpm-bind-synsock</i>	(Optional) rpm bind in synsock
<i>gen-rpm-bindsynadd</i>	(Optional) rpm bind in synadd
<i>gen-rpm-bindlookup</i>	(Optional) rpm bind in lookup

<i>gen-rpm-bindsetsock</i>	(Optional) rpm bind in setsock
<i>gen-rpm-unbind-getpass</i>	(Optional) rpm unbind get pass
<i>gen-rpm-unbinduser1</i>	(Optional) rpm unbind by user
<i>gen-rpm-unbinduser2</i>	(Optional) rpm unbind by user1
<i>gen-rpm-unbindrollover</i>	(Optional) rpm unbind during rollover
<i>gen-rpm-unbind-synfree</i>	(Optional) rpm unbind in syn free
<i>gen-rpm-unbind-tpfree</i>	(Optional) rpm unbind in tp free
<i>syn-sc-added</i>	(Optional) entry added to syncache
<i>syn-retransmitted</i>	(Optional) syncache entry was retransmitted
<i>syn-dupsyn</i>	(Optional) duplicate SYN packet
<i>syn-dropped</i>	(Optional) could not reply to packet
<i>syn-completed</i>	(Optional) successful extraction of entry
<i>syn-bucket-overflow</i>	(Optional) syncache per-bucket limit hit
<i>syn-cache-overflow</i>	(Optional) syncache cache limit hit
<i>syn-sc-reset</i>	(Optional) RST removed entry from syncache
<i>syn-sc-stale</i>	(Optional) timed out or listen socket gone
<i>syn-sc-aborted</i>	(Optional) syncache entry aborted
<i>syn-sc-badack</i>	(Optional) removed due to bad ACK
<i>syn-sc-unreach</i>	(Optional) ICMP unreachable received
<i>syn-sc-zonefail</i>	(Optional) zalloc() failed
<i>syn-sc-sendcookie</i>	(Optional) SYN cookie sent
<i>syn-sc-recvcookie</i>	(Optional) SYN cookie received
<i>syn-sc-crosshits</i>	(Optional) crosshits on the SC blocks
<i>syn-sc-supsyncrosshits</i>	(Optional) crosshits dup SYN on SC block
<i>syn-sc-removecrosshits</i>	(Optional) crosshits on SC blocks to remove
<i>udp-rx-total</i>	(Optional) total udp packets
<i>udp-rx-bad-csum</i>	(Optional) udp checksum error
<i>udp-rx-no-csum</i>	(Optional) udp no checksum
<i>udp-rx-too-short</i>	(Optional) udp packets drops

<i>udp-rx-bad-len</i>	(Optional) udp bad length
<i>udp-rx-no-port</i>	(Optional) udp no port
<i>udp-rx-no-port-bcast</i>	(Optional) udp no port broadcast
<i>udp-rx-no-port-mcast</i>	(Optional) udp no port multicast
<i>udp-rx-full-socket-drop</i>	(Optional) udp dropped full socket
<i>udp-tx-total</i>	(Optional) udp total packets
<i>raw-rx-version</i>	(Optional) raw sockets version
<i>raw-rx-rcvd</i>	(Optional) raw sockets connection received
<i>raw-rx-no-port</i>	(Optional) raw socket no port
<i>raw-rx-full-socket-drop</i>	(Optional) raw socket full sockets drop
<i>raw-tx-sent</i>	(Optional) raw socket connection sent
<i>inpcb-tot-alloc</i>	(Optional) inpcb allocation
<i>inpcb-tot-bind</i>	(Optional) inpcb bind
<i>inpcb-tot-laddr</i>	(Optional) inpcb laddr
<i>inpcb-tot-connect</i>	(Optional) inpcb connect
<i>inpcb-tot-disconnect</i>	(Optional) inpcb disconnect
<i>inpcb-tot-detach</i>	(Optional) inpcb detach
<i>inpcb-tot-detach-noinc</i>	(Optional) inpcb detaach no increment
<i>inpcb-tot-detach-rort</i>	(Optional) inpcb detach no return
<i>inpcb-tot-rtfree</i>	(Optional) inpcb rt free
<i>inpcb-tot-setsock-addr</i>	(Optional) inpcb set socket address
<i>inpcb-tot-setpeeraddr</i>	(Optional) inpcb set peer address
<i>inpcb-tot-notify</i>	(Optional) inpcb notify
<i>inpcb-tot-lookup-npacl-deny</i>	(Optional) inpcb lookup hash npacl deny
<i>inpcb-tot-lookup-npacl-allow</i>	(Optional) inpcb lookup npacl allow
<i>inpcb-tot-inshash-ipv4</i>	(Optional) inpcb inshash ipv4
<i>inpcb-tot-inshash-ipv6</i>	(Optional) inpcb inshash ipv6
<i>inpcb-tot-brehash-ipv4</i>	(Optional) inpcb brehash ipv4
<i>inpcb-tot-brehash-ipv6</i>	(Optional) inpcb brehash ipv6

<i>inpcb-tot-bremhash</i>	(Optional) inpcb brehash
<i>inpcb-err-allocnomem</i>	(Optional) inpcb allocation no memory error
<i>inpcb-err-bindeinavl</i>	(Optional) inpcb bind inval error
<i>inpcb-err-eaddrinuse</i>	(Optional) inpcb eaddr in use error
<i>inpcb-err-eagain</i>	(Optional) inpcb eagain error
<i>inpcb-err-eagain2</i>	(Optional) inpcb eagain2 error
<i>inpcb-err-eaddrnotavail</i>	(Optional) inpcb eaddr not availableerror
<i>inpcb-err-eafnosupport</i>	(Optional) inpcb eaf no support error
<i>inpcb-err-enomem</i>	(Optional) inpcb no-memory error
<i>inpcb-err-ehostunreach</i>	(Optional) inpcb ehost unreachable error
<i>inpcb-err-laddr-enixio</i>	(Optional) inpcb laddr enxio error
<i>inpcb-err-laddr-ehostunreach2</i>	(Optional) inpcb laddr ehost unreachable2 error
<i>inpcb-err-connectladdr</i>	(Optional) inpcb connect laddr error
<i>inpcb-err-connect-eaddrinuse</i>	(Optional) inpcb connect eaddress in use error
<i>inpcb-err-connbind</i>	(Optional) inpcb connect bind error
<i>inpcb-err-sockaddrenomem</i>	(Optional) inpcb socket address no memory error
<i>inpcb-err-sockadreconnreset</i>	(Optional) inpcb socket address econnect reset error
<i>inpcb-err-peeraddr-enomem</i>	(Optional) inpcb peer address no memory error
<i>inpcb-err-econnrest</i>	(Optional) inpcb connection rest error
<i>inpcb-err-respond-enobufs</i>	(Optional) inpcb respond no buffer error
<i>inpcb-err-binshash-enobufs</i>	(Optional) inpcb binshash no buffer error
<i>in6pcb-tot-setport</i>	(Optional) in6pcb set port error
<i>in6pcb-tot-bind</i>	(Optional) in6pcb bind
<i>in6pcb-tot-laddr</i>	(Optional) in6pcb laddr
<i>in6pcb-tot-connect</i>	(Optional) in6pcb connect
<i>in6pcb-tot-disconnect</i>	(Optional) in6pcb disconnect
<i>in6pcb-tot-detach</i>	(Optional) in6pcb detach
<i>in6pcb-tot-sockaddr</i>	(Optional) in6pcb socket address
<i>in6pcb-tot-peeraddr</i>	(Optional) in6pcb peer address

<i>in6pcb-tot-notify</i>	(Optional) in6pcb notify
<i>in6pcb-tot-lookuplocal</i>	(Optional) in6pcb lookup local
<i>in6pcb-tot-hashnpacl-deny</i>	(Optional) in6pcb hash npacl deny
<i>in6pcb-err-setporteagain</i>	(Optional) in6pcb set port again error
<i>in6pcb-err-setporteagain2</i>	(Optional) in6pcb set port again2 error
<i>in6pcb-err-seteagain3</i>	(Optional) in6pcb set port again3 error
<i>in6pcb-bind-eafnosupport</i>	(Optional) in6pcb bind eaf no support error
<i>in6pcb-err-bindeaddrinuse</i>	(Optional) in6pcb bind address in use error
<i>in6pcb-err-bindeaddrinuse2</i>	(Optional) in6pcb bind address in use2 error
<i>in6pcb-err-bindeaddrinuse3</i>	(Optional) in6pcb bind address in use3 error
<i>in6pcb-err-bindeaddrinuse4</i>	(Optional) in6pcb bind address in use4 error
<i>in6pcb-err-bindsetport</i>	(Optional) in6pcb bind setport error
<i>in6pcb-err-bindeagain</i>	(Optional) in6pcb bind again error
<i>in6pcb-err-laddr-eafnosupport</i>	(Optional) in6pcb laddr eaf no support error
<i>in6pcb-err-eaddrnotavail</i>	(Optional) in6pcb address not available error
<i>in6pcb-err-laddr-enomem</i>	(Optional) in6pcb laddr no memory error
<i>in6pcb-err-laddr-ehostreach</i>	(Optional) in6pcb laddr host reach error
<i>in6pcb-err-laddr-ehostunreach2</i>	(Optional) in6pcb laddr host reach2 error
<i>in6pcb-err-laddr-ehostunreach3</i>	(Optional) in6pcb laddr host reach3 error
<i>in6pcb-err-laddr-ehostunreach4</i>	(Optional) in6pcb laddr host reach4 error
<i>in6pcb-err-laddr-ecxio</i>	(Optional) in6pcb laddr enxio error
<i>in6pcb-err-connladdr</i>	(Optional) in6pcb connect laddr error
<i>in6pcb-err-conneaddrinuse</i>	(Optional) in6pcb connect eaddress in use error
<i>in6pcb-err-connbind</i>	(Optional) in6pcb connect bind error
<i>in6pcb-err-sockaddr-enomem</i>	(Optional) in6pcb socket address no memory error
<i>in6pcb-err-v4maps-enomem</i>	(Optional) in6pcb v4maps no memory error
<i>in6pcb-err-setsock-noinp</i>	(Optional) in6pcb set socket noinp error
<i>in6pcb-err-setpeer-noinp</i>	(Optional) in6pcb set peer noinp error
<i>in6pcb-err-sockaddr-noinp</i>	(Optional) in6pcb socket address noinp error

<i>in6pcb-err-peeraddr-noinp</i>	(Optional) in6pcb peer address noinp error
<i>in6pcb-err-notify-einavl</i>	(Optional) in6pcb notify ingress available error
<i>in6pcb-err-ctloutput-nosoopt</i>	(Optional) in6pcb control output no socket opt error

Command Mode

- /exec

show sockets tcp keychain binding

```
show sockets tcp keychain binding [ __readonly__ { TABLE_keychain <keychain> <handle> <ref_count> } ]
```

Syntax Description

show	Show running system information
sockets	Display sockets status and configuration
tcp	TCP information
keychain	Keychain information
binding	Binding information reagarding RPM
__readonly__	(Optional)
TABLE_keychain	(Optional) all sockets tcp keychains
<i>keychain</i>	(Optional) xml keychain information
<i>handle</i>	(Optional) xml handle information
<i>ref_count</i>	(Optional) xml refcount information

Command Mode

- /exec

show spanning-tree

```
{ show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] [ __readonly__ TABLE_tree <tree_id>
<tree_tree_type> <tree_protocol> <port_count> <bridge_mac> <bridge_priority> <tree_designated_root>
<tree_designated_root_priority> <stp_active> <root_path_cost> <root_port_if_index> <root_port_priority>
<root_port_number> <topology_change> <topology_change_detected> <topology_change_count>
<topology_change_time_since_last> <tc_initiator_if_index> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> <max_age> <hello_time> <forward_delay> <hold_time> <hello_timer>
<topology_change_timer> <tcn_timer> <aging_timer> <disabled> <blocking> <listening> <learning>
<forwarding> <invalid> TABLE_port <if_index> [ <vpc> ] <port_info_tree_id> <state> <role> <port_priority>
<port_number> <port_protocol> <port_tree_type> <path_cost> <port_designated_root>
<port_designated_root_priority> <designated_cost> <designated_bridge> <designated_bridge_priority>
<designated_port> <tc_acknowledge> <forward_transition_count> <self_looped> <inconsistency> <bpdu_in>
<bpdu_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p>
<oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> [ <oper_networkport> ]
<forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> <pvstsim_inc_timer> [ <boundary>
] [ <simulate_pvst_cfg> ] [ <simulate_pvst> ] [ <prestd> ] ] } { show spanning-tree [ vlan <vlan-id> |
bridge-domain <bd-id> ] { <verbosity> | active } + [ __readonly__ TABLE_tree <tree_id> <tree_tree_type>
<tree_protocol> <port_count> <bridge_mac> <bridge_priority> <tree_designated_root>
<tree_designated_root_priority> <stp_active> <root_path_cost> <root_port_if_index> <root_port_priority>
<root_port_number> <topology_change> <topology_change_detected> <topology_change_count>
<topology_change_time_since_last> <tc_initiator_if_index> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> <max_age> <hello_time> <forward_delay> <hold_time> <hello_timer>
<topology_change_timer> <tcn_timer> <aging_timer> <disabled> <blocking> <listening> <learning>
<forwarding> <invalid> TABLE_port <if_index> <port_info_tree_id> <state> <role> <port_priority>
<port_number> <port_protocol> <port_tree_type> <path_cost> <port_designated_root>
<port_designated_root_priority> <designated_cost> <designated_bridge> <designated_bridge_priority>
<designated_port> <tc_acknowledge> <forward_transition_count> <self_looped> <inconsistency> <bpdu_in>
<bpdu_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p>
<oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> [ <oper_networkport> ]
<forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> <pvstsim_inc_timer> [ <boundary>
] [ <simulate_pvst_cfg> ] [ <simulate_pvst> ] [ <prestd> ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
bridge-domain	(Optional) Bridge-Domain Switch Spanning Trees
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
<i>bd-id</i>	(Optional) Bridge-Domain range, Example: 2,4-5,7,9-11
<i>verbosity</i>	verbosity
active	Report on active interfaces only
__readonly__	(Optional) Read Only

<i>TABLE_tree</i>	(Optional)
<i>tree_id</i>	(Optional) Tree Id
<i>tree_tree_type</i>	(Optional) Tree Type
<i>tree_protocol</i>	(Optional) Tree Protocol
<i>port_count</i>	(Optional) Number of Ports in Tree
<i>bridge_mac</i>	(Optional) Bridge Mac
<i>bridge_priority</i>	(Optional) Bridge Priority
<i>tree_designated_root</i>	(Optional) Designated Root Mac
<i>tree_designated_root_priority</i>	(Optional) Designated Root Priority
<i>stp_active</i>	(Optional) Spanning Tree State
<i>root_path_cost</i>	(Optional) Root Path Cost
<i>root_port_if_index</i>	(Optional) Root Port
<i>root_port_priority</i>	(Optional) Root Port Priority
<i>root_port_number</i>	(Optional) Root Port Number
<i>topology_change</i>	(Optional) Topology Change flag is set ?
<i>topology_change_detected</i>	(Optional) Topology Change detected flag is set ?
<i>topology_change_count</i>	(Optional) Topology Change Count
<i>topology_change_time_since_last</i>	(Optional) Time since last TC
<i>tc_initiator_if_index</i>	(Optional) Topology Change initiator port
<i>max_age</i>	(Optional) Max Age
<i>hello_time</i>	(Optional) Hello Time
<i>forward_delay</i>	(Optional) Forward delay
<i>bridge_max_age</i>	(Optional) Configured Bridge Max Age
<i>bridge_hello_time</i>	(Optional) Configured Hello Time
<i>bridge_forward_delay</i>	(Optional) Configured Forward Delay
<i>hold_time</i>	(Optional) Configured Hold Time
<i>hello_timer</i>	(Optional) Hello Timer Value
<i>topology_change_timer</i>	(Optional) Topology Change Timer Value
<i>tcn_timer</i>	(Optional) TCN Timer Value

<i>aging_timer</i>	(Optional) Ageing Timer Value
<i>disabled</i>	(Optional) Number of ports Disabled
<i>blocking</i>	(Optional) Number of ports Blocking
<i>listening</i>	(Optional) Number of ports Listening
<i>learning</i>	(Optional) Number of ports Learning
<i>forwarding</i>	(Optional) Number of ports Forwarding
<i>invalid</i>	(Optional) Number of ports Invalid
TABLE_port	(Optional)
<i>if_index</i>	(Optional) Interface
<i>vpc</i>	(Optional) STP Port memebr of MCT/VPC PO
<i>port_info_tree_id</i>	(Optional) Tree Id
<i>state</i>	(Optional) STP Port State
<i>role</i>	(Optional) STP Port Role
<i>port_priority</i>	(Optional) Port priority
<i>port_number</i>	(Optional) Port Number
<i>port_protocol</i>	(Optional) Tree Protocol
<i>port_tree_type</i>	(Optional) Tree Type
<i>path_cost</i>	(Optional) Cost configured on this port
<i>port_designated_root</i>	(Optional) Designated Root Mac
<i>port_designated_root_priority</i>	(Optional) Designated Root Priority
<i>designated_cost</i>	(Optional) Designated cost
<i>designated_bridge</i>	(Optional) Designated bridge mac
<i>designated_bridge_priority</i>	(Optional) Designated bridge priority
<i>designated_port</i>	(Optional) Designated Port Id
<i>tc_acknowledge</i>	(Optional) Is topology change acknowledge flag set ?
<i>forward_transition_count</i>	(Optional) Port transitions to Forwarding
<i>self_looped</i>	(Optional) Is Port self looped ?
<i>inconsistency</i>	(Optional) PVST+ Inconsistency Error Flags
<i>bpdu_in</i>	(Optional) BPDUs received on this stp port

<i>bpdus_out</i>	(Optional) BPDUs send on this stp port
<i>port_fast</i>	(Optional) Port Fast configured on port
<i>link_type</i>	(Optional) Link type configured on this port
<i>port_guard</i>	(Optional) Port Guard mode of port
<i>bpdu_guard</i>	(Optional) Bpdu Guard mode configured
<i>bpdu_filter</i>	(Optional) Bpdu Filter mode configured
<i>oper_portfast</i>	(Optional) Is portfast enabled ?
<i>oper_p2p</i>	(Optional) Is port P2P ?
<i>oper_loopguard</i>	(Optional) Is loopguard enabled ?
<i>oper_bpduguard</i>	(Optional) Is bpduguard enabled ?
<i>oper_bpdufilter</i>	(Optional) Is bpdufilter enabled ?
<i>int_bpdufilter</i>	(Optional) Is internal bpdufilter enabled ?
<i>forward_delay_timer</i>	(Optional) Forward Delay timer
<i>hold_timer</i>	(Optional) Hold Timer
<i>message_age</i>	(Optional) Message age timer
<i>peer</i>	(Optional) STP protocol of the peer
<i>dispute</i>	(Optional) Is port Disputed ?
<i>pvstsim_inc_timer</i>	(Optional) PVST Simulation Inconsistency Hold Timer
<i>boundary</i>	(Optional) Is port boundary ?
<i>prestd</i>	(Optional) Is port Pre STD MST ?
<i>simulate_pvst</i>	(Optional) Is port is pvst simulate mode ?
<i>oper_networkport</i>	(Optional) Is network port enabled ?
<i>simulate_pvst_cfg</i>	(Optional) PVST Simulation configured on port

Command Mode

- /exec

show spanning-tree blockedports

```
{ show spanning-tree [ vlan <vlan-id> ] blockedports [ __readonly__ [ TABLE_tree [ <port_info_tree_id> ]
[ TABLE_port [ <if_index> ] ] ] [ <tree_type> ] [ <num_ports> ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
__readonly__	(Optional)
TABLE_tree	(Optional)
<i>port_info_tree_id</i>	(Optional) Tree name
TABLE_port	(Optional)
<i>if_index</i>	(Optional) Port name
<i>tree_type</i>	(Optional) Tree Type
<i>num_ports</i>	(Optional) Number of Ports
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
blockedports	Show blocked ports

Command Mode

- /exec

show spanning-tree bridge

```
{ show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] bridge [ priority [ system-id ] ] [ __readonly__
{ TABLE_tree <tree_id> <tree_tree_type> <tree_protocol> <bridge_mac> <bridge_priority>
<bridge_forward_delay> <bridge_max_age> <bridge_hello_time> } ] } | { show spanning-tree [ vlan <vlan-id>
| bridge-domain <bd-id> ] bridge [ { detail | brief } ] [ __readonly__ { TABLE_tree <tree_id> <tree_tree_type>
<tree_protocol> <bridge_mac> <bridge_priority> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> } ] } | { show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] bridge [ { address
| forward-time | hello-time | id | max-age | protocol } ] [ __readonly__ { TABLE_tree <tree_id> <tree_tree_type>
<tree_protocol> <bridge_mac> <bridge_priority> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> } ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
bridge-domain	(Optional) Bridge-Domain Switch Spanning Trees
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
<i>bd-id</i>	(Optional) Bridge-Domain range, Example: 2,4-5,7,9-11
bridge	Status and configuration of this bridge
address	(Optional) Mac address of this bridge
forward-time	(Optional) Forward delay interval
hello-time	(Optional) Hello time
id	(Optional) Spanning tree bridge identifier
max-age	(Optional) Max age
protocol	(Optional) Spanning tree protocol
brief	(Optional) Brief summary of the status and configuration output
detail	(Optional) Detailed of the status and configuration
priority	(Optional) Bridge priority of this bridge
system-id	(Optional) Spanning tree priority with system id extension
__readonly__	(Optional) Read Only
TABLE_tree	(Optional)
<i>tree_id</i>	(Optional) Tree Id
<i>tree_tree_type</i>	(Optional) Tree Type

<i>tree_protocol</i>	(Optional) Tree Protocol
<i>bridge_mac</i>	(Optional) Bridge Mac
<i>bridge_priority</i>	(Optional) Bridge Priority
<i>bridge_forward_delay</i>	(Optional) Configured Forward Delay
<i>bridge_max_age</i>	(Optional) Configured Bridge Max Age
<i>bridge_hello_time</i>	(Optional) Configured Hello Time

Command Mode

- /exec

show spanning-tree inconsistentports

```
{ show spanning-tree [ vlan <vlan-id> ] inconsistentports [ __readonly__ [ TABLE_tree <port_info_tree_id>
<if_index> <inconsistency> ] [ <tree_type> ] [ <num_ports> ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
inconsistentports	Show inconsistent ports
<i>__readonly__</i>	(Optional)
TABLE_tree	(Optional)
<i>port_info_tree_id</i>	(Optional) Tree name
<i>if_index</i>	(Optional) Port name
<i>inconsistency</i>	(Optional) Inconsistency type
<i>tree_type</i>	(Optional) Tree Type
<i>num_ports</i>	(Optional) Number of Ports

Command Mode

- /exec

show spanning-tree interface

```
{ show spanning-tree [ vlan <vlan-id> ] interface <interface-id> { cost | inconsistency | edge | priority | rootcost
| state } [ __readonly__ [ TABLE_vlan_interface_info <tree_name> [ <cost> ] [ <edge> ] [ <inconsistency>
] [ <priority> ] [ <rootcost> ] [ <state> ] ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
interface	Spanning Tree interface status and configuration
<i>interface-id</i>	
cost	Port path cost
inconsistency	Port inconsistency state
edge	Edge Port configuration
priority	Port priority
rootcost	Path cost to root
state	Port spanning tree state
__readonly__	(Optional)
TABLE_vlan_interface_info	(Optional)
<i>tree_name</i>	(Optional) Spanning tree name
<i>cost</i>	(Optional) Path cost
<i>edge</i>	(Optional) Portfast enabled or not
<i>inconsistency</i>	(Optional) Port inconsistency
<i>priority</i>	(Optional) Port Priority
<i>rootcost</i>	(Optional) Designated Cost
<i>state</i>	(Optional) Port state

Command Mode

- /exec

show spanning-tree interface

```
{ show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] interface <interface-id> [ __readonly__ {
TABLE_port <if_index> [ <vpc> ] <port_info_tree_id> <state> <role> <port_priority> <port_number>
<port_protocol> <port_tree_type> <path_cost> <port_designated_root> <port_designated_root_priority>
<designated_cost> <designated_bridge> <designated_bridge_priority> <designated_port> <tc_acknowledge>
<forward_transition_count> <self_looped> <inconsistency> <bpdu_in> <bpdu_out> <port_fast> <link_type>
<port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p> <oper_loopguard> <oper_bpduguard>
<oper_bpdufilter> <int_bpdufilter> <oper_networkport> <forward_delay_timer> <hold_timer> <message_age>
<peer> <dispute> <pvstsim_inc_timer> [ <boundary> ] [ <simulate_pvst_cfg> ] [ <simulate_pvst> ] [ <prestd>
] } ] } | { show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] interface <interface-id> { <verbosity>
| active } + [ __readonly__ { TABLE_port <if_index> [ <vpc> ] <port_info_tree_id> <state> <role>
<port_priority> <port_number> <port_protocol> <port_tree_type> <path_cost> <port_designated_root>
<port_designated_root_priority> <designated_cost> <designated_bridge> <designated_bridge_priority>
<designated_port> <tc_acknowledge> <forward_transition_count> <self_looped> <inconsistency> <bpdu_in>
<bpdu_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter> <oper_portfast> <oper_p2p>
<oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> <oper_networkport>
<forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> <pvstsim_inc_timer> [ <boundary>
] [ <simulate_pvst_cfg> ] [ <simulate_pvst> ] [ <prestd> ] } ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
bridge-domain	(Optional) Bridge-Domain Switch Spanning Trees
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
<i>bd-id</i>	(Optional) Bridge-Domain range, Example: 2,4-5,7,9-11
interface	Spanning Tree interface status and configuration
<i>interface-id</i>	
<i>verbosity</i>	verbosity
active	Report on active instances only
__readonly__	(Optional) Read Only
TABLE_port	(Optional)
<i>if_index</i>	(Optional) Interface
<i>vpc</i>	(Optional) STP Port memebr of MCT/VPC PO
<i>port_info_tree_id</i>	(Optional) Tree Id
<i>state</i>	(Optional) STP Port State

<i>role</i>	(Optional) STP Port Role
<i>port_priority</i>	(Optional) Port priority
<i>port_number</i>	(Optional) Port Number
<i>port_protocol</i>	(Optional) Tree Protocol
<i>port_tree_type</i>	(Optional) Tree Type
<i>path_cost</i>	(Optional) Cost configured on this port
<i>port_designated_root</i>	(Optional) Designated Root Mac
<i>port_designated_root_priority</i>	(Optional) Designated Root Priority
<i>designated_cost</i>	(Optional) Designated cost
<i>designated_bridge</i>	(Optional) Designated bridge mac
<i>designated_bridge_priority</i>	(Optional) Designated bridge priority
<i>designated_port</i>	(Optional) Designated Port Id
<i>tc_acknowledge</i>	(Optional) Is topology change acknowledge flag set ?
<i>forward_transition_count</i>	(Optional) Port transitions to Forwarding
<i>self_looped</i>	(Optional) Is Port self looped ?
<i>inconsistency</i>	(Optional) PVST+ Inconsistency Error Flags
<i>bpdu_in</i>	(Optional) BPDUs received on this stp port
<i>bpdu_out</i>	(Optional) BPDUs send on this stp port
<i>port_fast</i>	(Optional) Port Fast configured on port
<i>link_type</i>	(Optional) Link type configured on this port
<i>port_guard</i>	(Optional) Port Guard mode of port
<i>bpdu_guard</i>	(Optional) Bpdu Guard mode configured
<i>bpdu_filter</i>	(Optional) Bpdu Filter mode configured
<i>oper_portfast</i>	(Optional) Is portfast enabled ?
<i>oper_p2p</i>	(Optional) Is port P2P ?
<i>oper_loopguard</i>	(Optional) Is loopguard enabled ?
<i>oper_bpduguard</i>	(Optional) Is bpduguard enabled ?
<i>oper_bpdufilter</i>	(Optional) Is bpdufilter enabled ?
<i>int_bpdufilter</i>	(Optional) Is internal bpdufilter enabled ?

<i>forward_delay_timer</i>	(Optional) Forward Delay timer
<i>hold_timer</i>	(Optional) Hold Timer
<i>message_age</i>	(Optional) Message age timer
<i>peer</i>	(Optional) STP protocol of the peer
<i>dispute</i>	(Optional) Is port Disputed ?
<i>pvtsim_inc_timer</i>	(Optional) PVST Simulation Inconsistency Hold Timer
<i>boundary</i>	(Optional) Is port boundary ?
<i>prestd</i>	(Optional) Is port Pre STD MST ?
<i>simulate_pvst</i>	(Optional) Is port is pvst simulate mode ?
<i>oper_networkport</i>	(Optional) Is network port enabled ?
<i>simulate_pvst_cfg</i>	(Optional) PVST Simulation configured on port

Command Mode

- /exec

show spanning-tree issu-impact

```
show spanning-tree issu-impact [ __readonly__ [ TABLE_topology <tc_detected> <tc_name> <no_of_tc>
<time> <tc_string> ] [ TABLE_BA_ports <port_name> ] [ <criteria1> ] [ <criteria2> ] [
TABLE_non_edge_ports <port> <vlan> <role> <sts> <tree> <instance> ] [ <criteria3> ] ]
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
issu-impact	Show whether STP meets ISSU criteria
__readonly__	(Optional)
TABLE_topology	(Optional)
<i>tc_detected</i>	(Optional)
<i>tc_name</i>	(Optional)
<i>no_of_tc</i>	(Optional)
<i>time</i>	(Optional)
<i>tc_string</i>	(Optional)
TABLE_BA_ports	(Optional)
<i>port_name</i>	(Optional)
TABLE_non_edge_ports	(Optional)
<i>port</i>	(Optional)
<i>vlan</i>	(Optional)
<i>role</i>	(Optional)
<i>sts</i>	(Optional)
<i>tree</i>	(Optional)
<i>instance</i>	(Optional)
<i>criterial1</i>	(Optional)
<i>criteria2</i>	(Optional)
<i>criteria3</i>	(Optional)

Command Mode

- /exec

show spanning-tree mst

```
{ show spanning-tree mst [ <mst-id> ] [ __readonly__ TABLE_tree <tree_id> <tree_tree_type> <tree_protocol>
<port_count> <bridge_mac> <bridge_priority> <tree_designated_root> <tree_designated_root_priority>
<stp_active> <root_path_cost> <root_port_if_index> <root_port_priority> <root_port_number>
<topology_change> <topology_change_detected> <topology_change_count>
<topology_change_time_since_last> <tc_initiator_if_index> <bridge_forward_delay> <bridge_max_age>
<bridge_hello_time> <max_age> <hello_time> <forward_delay> <hold_time> <hello_timer>
<topology_change_timer> <tcn_timer> <aging_timer> <disabled> <blocking> <listening> <learning>
<forwarding> <invalid> <ist-master-id-mac> <ist-master-prio> <ist-path-cost> <remaining-hops> <max-hops>
<txholdcount> <tree-vlan-map> TABLE_port <if_index> <port_info_tree_id> <state> <role> <port_priority>
<port_number> <port_protocol> <port_tree_type> <path_cost> <port_designated_root>
<port_designated_root_priority> <designated_cost> <designated_bridge> <designated_bridge_priority>
<designated_port> <tc_acknowledge> <forward_transition_count> <self_looped> <inconsistency> <bpdus_in>
<bpdus_out> <port_fast> <link_type> <port_guard> <bpduguard> <bpduguard> <bpduguard> <oper_portfast> <oper_p2p>
<oper_loopguard> <oper_bpduguard> <oper_bpduguard> <int_bpduguard> [ <oper_networkport> ]
<forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> <pvstsim_inc_timer> <boundary>
[ <simulate_pvst_cfg> ] <simulate_pvst> <prest> [ <designated_ist_master> ] [
<designated_ist_master_priority> ] [ <designated_ist_cost> ] [ <vlan-map> ] ] } { show spanning-tree mst
[ <mst-id> ] detail [ __readonly__ TABLE_tree <tree_id> <tree_tree_type> <tree_protocol> <port_count>
<bridge_mac> <bridge_priority> <tree_designated_root> <tree_designated_root_priority> <stp_active>
<root_path_cost> <root_port_if_index> <root_port_priority> <root_port_number> <topology_change>
<topology_change_detected> <topology_change_count> <topology_change_time_since_last>
<tc_initiator_if_index> <bridge_forward_delay> <bridge_max_age> <bridge_hello_time> <max_age>
<hello_time> <forward_delay> <hold_time> <hello_timer> <topology_change_timer> <tcn_timer>
<aging_timer> <disabled> <blocking> <listening> <learning> <forwarding> <invalid> <ist-master-id-mac>
<ist-master-prio> <ist-path-cost> <remaining-hops> <max-hops> <txholdcount> <tree-vlan-map> TABLE_port
<if_index> <port_info_tree_id> <state> <role> <port_priority> <port_number> <port_protocol>
<port_tree_type> <path_cost> <port_designated_root> <port_designated_root_priority> <designated_cost>
<designated_bridge> <designated_bridge_priority> <designated_port> <tc_acknowledge>
<forward_transition_count> <self_looped> <inconsistency> <bpdus_in> <bpdus_out> <port_fast> <link_type>
<port_guard> <bpduguard> <bpduguard> <bpduguard> <oper_portfast> <oper_p2p> <oper_loopguard> <oper_bpduguard>
<oper_bpduguard> <int_bpduguard> [ <oper_networkport> ] <forward_delay_timer> <hold_timer>
<message_age> <peer> <dispute> <pvstsim_inc_timer> <boundary> [ <simulate_pvst_cfg> ] <simulate_pvst>
<prest> [ <designated_ist_master> ] [ <designated_ist_master_priority> ] [ <designated_ist_cost> ] [
<vlan-map> ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
mst	Multiple spanning trees
<i>mst-id</i>	(Optional) MST instance range, example: 0-3,5,7-9
detail	Detailed information
__readonly__	(Optional) Read Only
TABLE_tree	(Optional)

<i>tree_id</i>	(Optional) Tree Id
<i>tree_tree_type</i>	(Optional) Tree Type
<i>tree_protocol</i>	(Optional) Tree Protocol
<i>port_count</i>	(Optional) Number of Ports in Tree
<i>bridge_mac</i>	(Optional) Bridge Mac
<i>bridge_priority</i>	(Optional) Bridge Priority
<i>tree_designated_root</i>	(Optional) Designated Root Mac
<i>tree_designated_root_priority</i>	(Optional) Designated Root Priority
<i>stp_active</i>	(Optional) Spanning Tree State
<i>root_path_cost</i>	(Optional) Root Path Cost
<i>root_port_if_index</i>	(Optional) Root Port
<i>root_port_priority</i>	(Optional) Root Port Priority
<i>root_port_number</i>	(Optional) Root Port Number
<i>topology_change</i>	(Optional) Topology Change flag is set ?
<i>topology_change_detected</i>	(Optional) Topology Change detected flag is set ?
<i>topology_change_count</i>	(Optional) Topology Change Count
<i>topology_change_time_since_last</i>	(Optional) Time since last TC
<i>tc_initiator_if_index</i>	(Optional) Topology Change initiator port
<i>max_age</i>	(Optional) Max Age
<i>hello_time</i>	(Optional) Hello Time
<i>forward_delay</i>	(Optional) Forward delay
<i>bridge_max_age</i>	(Optional) Configured Bridge Max Age
<i>bridge_hello_time</i>	(Optional) Configured Hello Time
<i>bridge_forward_delay</i>	(Optional) Configured Forward Delay
<i>hold_time</i>	(Optional) Configured Hold Time
<i>hello_timer</i>	(Optional) Hello Timer Value
<i>topology_change_timer</i>	(Optional) Topology Change Timer Value
<i>tcn_timer</i>	(Optional) TCN Timer Value
<i>aging_timer</i>	(Optional) Ageing Timer Value

<i>disabled</i>	(Optional) Number of ports Disabled
<i>blocking</i>	(Optional) Number of ports Blocking
<i>listening</i>	(Optional) Number of ports Listening
<i>learning</i>	(Optional) Number of ports Learning
<i>forwarding</i>	(Optional) Number of ports Forwarding
<i>invalid</i>	(Optional) Number of ports Invalid
<i>ist-master-id-mac</i>	(Optional) IST Master ID MAC address
<i>ist-master-prio</i>	(Optional) IST Master ID priority
<i>ist-path-cost</i>	(Optional) IST path cost
<i>remaining-hops</i>	(Optional) Remaining hops
<i>max-hops</i>	(Optional) Max Hops
<i>txholdcount</i>	(Optional) TX Hold count
<i>tree-vlan-map</i>	(Optional) Bitmap of vlans mapped to tree
TABLE_port	(Optional)
<i>if_index</i>	(Optional) Interface
<i>state</i>	(Optional) STP Port State
<i>role</i>	(Optional) STP Port Role
<i>port_priority</i>	(Optional) Port priority
<i>port_number</i>	(Optional) Port Number
<i>port_info_tree_id</i>	(Optional) Tree Id
<i>port_tree_type</i>	(Optional) Tree Type
<i>port_protocol</i>	(Optional) Tree Protocol
<i>path_cost</i>	(Optional) Cost configured on this port
<i>port_designated_root</i>	(Optional) Designated Root Mac
<i>port_designated_root_priority</i>	(Optional) Designated Root Priority
<i>designated_cost</i>	(Optional) Designated cost
<i>designated_bridge</i>	(Optional) Designated bridge mac
<i>designated_bridge_priority</i>	(Optional) Designated bridge priority
<i>designated_port</i>	(Optional) Designated Port Id

<i>tc_acknowledge</i>	(Optional) Is topology change acknowledge flag set ?
<i>forward_transition_count</i>	(Optional) Port transitions to Forwarding
<i>self_looped</i>	(Optional) Is Port self looped ?
<i>inconsistency</i>	(Optional) PVST+ Inconsistency Error Flags
<i>bpdu_in</i>	(Optional) BPDUs received on this stp port
<i>bpdu_out</i>	(Optional) BPDUs send on this stp port
<i>port_fast</i>	(Optional) Port Fast configured on port
<i>link_type</i>	(Optional) Link type configured on this port
<i>port_guard</i>	(Optional) Port Guard mode of port
<i>bpdu_guard</i>	(Optional) Bpdu Guard mode configured
<i>bpdu_filter</i>	(Optional) Bpdu Filter mode configured
<i>oper_portfast</i>	(Optional) Is portfast enabled ?
<i>oper_p2p</i>	(Optional) Is port P2P ?
<i>oper_loopguard</i>	(Optional) Is loopguard enabled ?
<i>oper_bpduguard</i>	(Optional) Is bpduguard enabled ?
<i>oper_bpdufilter</i>	(Optional) Is bpdufilter enabled ?
<i>int_bpdufilter</i>	(Optional) Is internal bpdufilter enabled ?
<i>forward_delay_timer</i>	(Optional) Forward Delay timer
<i>hold_timer</i>	(Optional) Hold Timer
<i>message_age</i>	(Optional) Message age timer
<i>peer</i>	(Optional) STP protocol of the peer
<i>boundary</i>	(Optional) Is port boundary ?
<i>simulate_pvst</i>	(Optional) Is port is pvst simulate mode ?
<i>dispute</i>	(Optional) Is port Disputed ?
<i>pvstsim_inc_timer</i>	(Optional) PVST Simulation Inconsistency Hold Timer
<i>prestd</i>	(Optional) Is port Pre STD MST ?
<i>designated_ist_master</i>	(Optional) Ist master mac
<i>designated_ist_master_priority</i>	(Optional) Ist master priority
<i>designated_ist_cost</i>	(Optional) Ist master path cost

<i>vlan-map</i>	(Optional) Bitmap of vlans mapped to port
<i>oper_networkport</i>	(Optional) Is network port enabled ?
<i>simulate_pvst_cfg</i>	(Optional) PVST Simulation configured on port

Command Mode

- /exec

show spanning-tree mst configuration

```
{ show spanning-tree mst configuration [ __readonly__ <stp-mode> <name> <rev-id> { Instance_to_vlan_map
<mst_id> <vlan_bit_map> } [ <pvlan-sync> ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
mst	Multiple spanning trees
configuration	MST current region configuration
<i>__readonly__</i>	(Optional) Read Only
<i>stp-mode</i>	(Optional) Spanning Tree operating mode
<i>name</i>	(Optional) Configuration name
<i>rev-id</i>	(Optional) Configuration revision number
Instance_to_vlan_map	(Optional) Instance to vlan mapping Info
<i>mst_id</i>	(Optional) MST Instance ID
<i>vlan_bit_map</i>	(Optional) VLAN Bitmap
<i>pvlan-sync</i>	(Optional) pvlan synchronization

Command Mode

- /exec

show spanning-tree mst configuration digest

```
{ show spanning-tree mst configuration digest [ __readonly__ <stp-mode> <name> <rev-id> <digest>
<prestd-digest> [ <pvlan-sync> ] ] }
```

Syntax Description

<code>show</code>	Show running system information
<code>spanning-tree</code>	Show spanning tree information
<code>mst</code>	Multiple spanning trees
<code>configuration</code>	MST current region configuration
<code>digest</code>	Display MST configuration digest
<code>__readonly__</code>	(Optional) Read Only
<code>stp-mode</code>	(Optional) Spanning Tree operating mode
<code>name</code>	(Optional) Configuration name
<code>rev-id</code>	(Optional) Configuration revision number
<code>digest</code>	(Optional) MST region configuration digest
<code>prestd-digest</code>	(Optional) MST region configuration pre-std digest
<code>pvlan-sync</code>	(Optional) pvlan synchronization

Command Mode

- /exec

show spanning-tree mst interface

```
{ show spanning-tree mst [ <mst-id> ] interface <interface-id> [ __readonly__ TABLE_port <if_index>
<port_info_tree_id> <state> <role> <port_priority> <port_number> <port_protocol> <port_tree_type>
<path_cost> <port_designated_root> <port_designated_root_priority> <designated_cost> <designated_bridge>
<designated_bridge_priority> <designated_port> <tc_acknowledge> <forward_transition_count> <self_looped>
<inconsistency> <bpdus_in> <bpdus_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter>
<oper_portfast> <oper_p2p> <oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> [
<oper_networkport> ] <forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> [
<pvstsim_inc_timer> ] <boundary> [ <simulate_pvst_cfg> ] <simulate_pvst> <prestd> [
<designated_ist_master> ] [ <designated_ist_master_priority> ] [ <designated_ist_cost> ] [ <vlan-map> ] ]
} | { show spanning-tree mst [ <mst-id> ] interface <interface-id> detail [ __readonly__ TABLE_port <if_index>
<port_info_tree_id> <state> <role> <port_priority> <port_number> <port_protocol> <port_tree_type>
<path_cost> <port_designated_root> <port_designated_root_priority> <designated_cost> <designated_bridge>
<designated_bridge_priority> <designated_port> <tc_acknowledge> <forward_transition_count> <self_looped>
<inconsistency> <bpdus_in> <bpdus_out> <port_fast> <link_type> <port_guard> <bpdu_guard> <bpdu_filter>
<oper_portfast> <oper_p2p> <oper_loopguard> <oper_bpduguard> <oper_bpdufilter> <int_bpdufilter> [
<oper_networkport> ] <forward_delay_timer> <hold_timer> <message_age> <peer> <dispute> [
<pvstsim_inc_timer> ] <boundary> [ <simulate_pvst_cfg> ] <simulate_pvst> <prestd> [
<designated_ist_master> ] [ <designated_ist_master_priority> ] [ <designated_ist_cost> ] [ <vlan-map> ] ]
}
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
mst	Multiple spanning trees
<i>mst-id</i>	(Optional) MST instance range, example: 0-3,5,7-9
interface	Spanning Tree interface status and configuration
<i>interface-id</i>	Specify an interface as a target for the command
detail	Detailed information
__readonly__	(Optional) Read Only
TABLE_port	(Optional)
<i>if_index</i>	(Optional) Interface
<i>port_info_tree_id</i>	(Optional) Tree Id
<i>state</i>	(Optional) STP Port State
<i>role</i>	(Optional) STP Port Role
<i>port_priority</i>	(Optional) Port priority
<i>port_number</i>	(Optional) Port Number

<i>port_tree_type</i>	(Optional) Tree Type
<i>port_protocol</i>	(Optional) Tree Protocol
<i>path_cost</i>	(Optional) Cost configured on this port
<i>port_designated_root</i>	(Optional) Designated Root Mac
<i>port_designated_root_priority</i>	(Optional) Designated Root Priority
<i>designated_cost</i>	(Optional) Designated cost
<i>designated_bridge</i>	(Optional) Designated bridge mac
<i>designated_bridge_priority</i>	(Optional) Designated bridge priority
<i>designated_port</i>	(Optional) Designated Port Id
<i>tc_acknowledge</i>	(Optional) Is topology change acknowledge flag set ?
<i>forward_transition_count</i>	(Optional) Port transitions to Forwarding
<i>self_looped</i>	(Optional) Is Port self looped ?
<i>inconsistency</i>	(Optional) PVST+ Inconsistency Error Flags
<i>bpdu_in</i>	(Optional) BPDUs received on this stp port
<i>bpdu_out</i>	(Optional) BPDUs send on this stp port
<i>port_fast</i>	(Optional) Port Fast configured on port
<i>link_type</i>	(Optional) Link type configured on this port
<i>port_guard</i>	(Optional) Port Guard mode of port
<i>bpdu_guard</i>	(Optional) Bpdu Guard mode configured
<i>bpdu_filter</i>	(Optional) Bpdu Filter mode configured
<i>oper_portfast</i>	(Optional) Is portfast enabled ?
<i>oper_p2p</i>	(Optional) Is port P2P ?
<i>oper_loopguard</i>	(Optional) Is loopguard enabled ?
<i>oper_bpduguard</i>	(Optional) Is bpduguard enabled ?
<i>oper_bpdufilter</i>	(Optional) Is bpdufilter enabled ?
<i>int_bpdufilter</i>	(Optional) Is internal bpdufilter enabled ?
<i>forward_delay_timer</i>	(Optional) Forward Delay timer
<i>hold_timer</i>	(Optional) Hold Timer
<i>message_age</i>	(Optional) Message age timer

<i>peer</i>	(Optional) STP protocol of the peer
<i>boundary</i>	(Optional) Is port boundary ?
<i>simulate_pvst</i>	(Optional) Is port is pvst simulate mode ?
<i>dispute</i>	(Optional) Is port Disputed ?
<i>prestd</i>	(Optional) Is port Pre STD MST ?
<i>designated_ist_master</i>	(Optional) Ist master mac
<i>designated_ist_master_priority</i>	(Optional) Ist master priority
<i>designated_ist_cost</i>	(Optional) Ist master path cost
<i>vlan-map</i>	(Optional) Bitmap of vlans mapped to port
<i>oper_networkport</i>	(Optional) Is network port enabled ?
<i>pvstsim_inc_timer</i>	(Optional) PVST Simulation Inconsistency Hold Timer
<i>simulate_pvst_cfg</i>	(Optional) PVST Simulation configured on port

Command Mode

- /exec

show spanning-tree pathcost method

```
{ show spanning-tree pathcost method [ __readonly__ <stp-pathcost-method> [ <stp-operpathcost-method> ] ] }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
pathcost	Show Spanning pathcost options
method	Default pathcost calculation method
__readonly__	(Optional)
<i>stp-pathcost-method</i>	(Optional) STP Pathcost Method
<i>stp-operpathcost-method</i>	(Optional) STP Pathcost Method

Command Mode

- /exec

show spanning-tree root

```
{ show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] root [ priority [ system-id ] ] [ __readonly__
TABLE_tree <tree_id> <tree_tree_type> <tree_protocol> <tree_designated_root>
<tree_designated_root_priority> <root_path_cost> <root_port_if_index> <root_port_priority>
<root_port_number> <max_age> <hello_time> <forward_delay> ] } | { show spanning-tree [ vlan <vlan-id>
| bridge-domain <bd-id> ] root [ { address | cost | forward-time | hello-time | id | max-age | port } ] [
__readonly__ TABLE_tree <tree_id> <tree_tree_type> <tree_protocol> <tree_designated_root>
<tree_designated_root_priority> <root_path_cost> <root_port_if_index> <root_port_priority>
<root_port_number> <max_age> <hello_time> <forward_delay> ] } | { show spanning-tree [ vlan <vlan-id>
| bridge-domain <bd-id> ] root [ { detail | brief } ] [ __readonly__ TABLE_tree <tree_id> <tree_tree_type>
<tree_protocol> <tree_designated_root> <tree_designated_root_priority> <root_path_cost>
<root_port_if_index> <root_port_priority> <root_port_number> <max_age> <hello_time> <forward_delay>
] } }
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
bridge-domain	(Optional) Bridge-Domain Switch Spanning Trees
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
<i>bd-id</i>	(Optional) Bridge-Domain range, Example: 2,4-5,7,9-11
root	Status and configuration of the root bridge
address	(Optional) Mac address of this bridge
cost	(Optional) Path cost from this bridge to the root
forward-time	(Optional) Forward delay interval
hello-time	(Optional) Hello time
id	(Optional) Spanning tree bridge identifier
max-age	(Optional) Max age
port	(Optional) Root port
brief	(Optional) Brief summary of interface information
detail	(Optional) Detailed information
priority	(Optional) Bridge priority of this bridge
system-id	(Optional) Spanning tree priority with system id extension
__readonly__	(Optional) Read Only

TABLE_tree	(Optional)
<i>tree_id</i>	(Optional) Tree Id
<i>tree_tree_type</i>	(Optional) Tree Type
<i>tree_protocol</i>	(Optional) Tree Protocol
<i>tree_designated_root</i>	(Optional) Designated Root Mac
<i>tree_designated_root_priority</i>	(Optional) Designated Root Priority
<i>root_path_cost</i>	(Optional) Root Path Cost
<i>root_port_if_index</i>	(Optional) Root Port
<i>root_port_priority</i>	(Optional) Root Port Priority
<i>root_port_number</i>	(Optional) Root Port Number
<i>max_age</i>	(Optional) Max Age
<i>hello_time</i>	(Optional) Hello Time
<i>forward_delay</i>	(Optional) Forward delay

Command Mode

- /exec

show spanning-tree summary

```
show spanning-tree [ vlan <vlan-id> | bridge-domain <bd-id> ] summary [ __readonly__ <stp-mode> [
<stp_tree_root_info> <tree_type> <bridge_mac> <bridge_priority> <tree_designated_root>
<tree_designated_root_priority> ] + [ <stp_root_bmp_info> <stp_root_tree_type> <tree_root_bmp>
<stp_l2gstp_bmp_info> <stp_l2gstp_tree_type> [ <stp_l2gstp_bmp> ] ] <stp_global_info> <pcost_method>
<oper_pcost_method> <port_fast> <bpdu_guard> <bpdu_filter> <oper_loopguard> <bridge_assurance>
<networkport_default> <simulate_pvst> <max-hops> <peer_switch_cfg> <oper_peer_switch>
<stp_l2gstp_domain_id> <stp_lite> [ TABLE_tree <stp_tree_summary> <summary_tree_type> <disabled>
<blocking> <listening> <learning> <forwarding> <invalid> <port_count> ] [ <stp_summary_totals>
<total_tree_type> <disabled> <blocking> <listening> <learning> <forwarding> <invalid> <port_count> ] ]
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
vlan	(Optional) VLAN Switch Spanning Trees
bridge-domain	(Optional) Bridge-Domain Switch Spanning Trees
<i>vlan-id</i>	(Optional) vlan range, Example: 1,3-5,7,9-11
<i>bd-id</i>	(Optional) Bridge-Domain range, Example: 2,4-5,7,9-11
summary	Summary of port states
<i>__readonly__</i>	(Optional) Read Only
<i>stp-mode</i>	(Optional) Spanning Tree operating mode
<i>stp_tree_root_info</i>	(Optional) STP Tree Root info marker
<i>tree_type</i>	(Optional) Tree Type
<i>bridge_mac</i>	(Optional) Bridge Mac
<i>bridge_priority</i>	(Optional) Bridge Priority
<i>tree_designated_root</i>	(Optional) Designated Root Mac
<i>tree_designated_root_priority</i>	(Optional) Designated Root Priority
<i>stp_root_bmp_info</i>	(Optional) STP root bitmap info marker
<i>stp_root_tree_type</i>	(Optional) Tree Type
<i>tree_root_bmp</i>	(Optional) STP tree root bmp
<i>stp_l2gstp_bmp_info</i>	(Optional) L2 Gateway STP bitmap marker
<i>stp_l2gstp_tree_type</i>	(Optional) Tree Type
<i>stp_l2gstp_bmp</i>	(Optional) L2 Gateway STP bitmap

<i>stp_global_info</i>	(Optional) STP global info marker
<i>pcost_method</i>	(Optional) STP pathcost method
<i>oper_pcost_method</i>	(Optional) STP oper pathcost method
<i>port_fast</i>	(Optional) Port Fast configured on port
<i>bpdu_guard</i>	(Optional) Bpdu Guard mode configured
<i>bpdu_filter</i>	(Optional) Bpdu Filter mode configured
<i>oper_loopguard</i>	(Optional) Is loopguard enabled ?
<i>bridge_assurance</i>	(Optional) Bridge Assurance
<i>networkport_default</i>	(Optional) Network Port default
<i>simulate_pvst</i>	(Optional) Is port is pvst simulate mode ?
<i>max-hops</i>	(Optional) Max Hops
<i>peer_switch_cfg</i>	(Optional) peer switch configuration status
<i>oper_peer_switch</i>	(Optional) peer switch operational status
<i>stp_l2gstp_domain_id</i>	(Optional) L2 Gateway STP Domain ID
<i>stp_lite</i>	(Optional) STP-Lite
TABLE_tree	(Optional)
<i>stp_tree_summary</i>	(Optional) STP Tree Summary
<i>summary_tree_type</i>	(Optional) Tree Type
<i>disabled</i>	(Optional) Number of ports Disabled
<i>blocking</i>	(Optional) Number of ports Blocking
<i>listening</i>	(Optional) Number of ports Listening
<i>learning</i>	(Optional) Number of ports Learning
<i>forwarding</i>	(Optional) Number of ports Forwarding
<i>invalid</i>	(Optional) Number of ports Invalid
<i>port_count</i>	(Optional) Number of Ports in Tree
<i>stp_summary_totals</i>	(Optional) Total num STP trees
<i>total_tree_type</i>	(Optional) Tree Type
<i>disabled</i>	(Optional) Number of ports Disabled
<i>blocking</i>	(Optional) Number of ports Blocking

<i>listening</i>	(Optional) Number of ports Listening
<i>learning</i>	(Optional) Number of ports Learning
<i>forwarding</i>	(Optional) Number of ports Forwarding
<i>invalid</i>	(Optional) Number of ports Invalid
<i>port_count</i>	(Optional) Number of Ports in Tree

Command Mode

- /exec

show spanning-tree summary totals

```
show spanning-tree summary totals [ __readonly__ <stp-mode> <stp_tree_root_info> <tree_type>
<bridge_mac> <bridge_priority> <tree_designated_root> <tree_designated_root_priority> <stp_root_bmp_info>
<stp_root_tree_type> <tree_root_bmp> <stp_l2gstp_bmp_info> <stp_l2gstp_tree_type> <stp_l2gstp_bmp>
<stp_global_info> <pcost_method> <oper_pcost_method> <port_fast> <bpdu_guard> <bpdu_filter>
<oper_loopguard> <bridge_assurance> <networkport_default> <simulate_pvst> <max-hops>
<peer_switch_cfg> <oper_peer_switch> <stp_l2gstp_domain_id> <stp_lite> <stp_summary_totals>
<total_tree_type> <disabled> <blocking> <listening> <learning> <forwarding> <invalid> <port_count> ]
```

Syntax Description

show	Show running system information
spanning-tree	Show spanning tree information
summary	Summary of port states
totals	Only show totals
__readonly__	(Optional) Read Only
stp-mode	(Optional) Spanning Tree operating mode
stp_tree_root_info	(Optional) STP Tree Root info marker
tree_type	(Optional) Tree Type
bridge_mac	(Optional) Bridge Mac
bridge_priority	(Optional) Bridge Priority
tree_designated_root	(Optional) Designated Root Mac
tree_designated_root_priority	(Optional) Designated Root Priority
stp_root_bmp_info	(Optional) STP root bitmap info marker
stp_root_tree_type	(Optional) Tree Type
tree_root_bmp	(Optional) STP tree root bmp
stp_l2gstp_bmp_info	(Optional) L2 Gateway STP bitmap marker
stp_l2gstp_tree_type	(Optional) Tree Type
stp_l2gstp_bmp	(Optional) L2 Gateway STP bitmap
stp_global_info	(Optional) STP global info marker
pcost_method	(Optional) STP pathcost method
oper_pcost_method	(Optional) STP oper pathcost method
port_fast	(Optional) Port Fast configured on port

<i>bpdu_guard</i>	(Optional) Bpdu Guard mode configured
<i>bpdu_filter</i>	(Optional) Bpdu Filter mode configured
<i>oper_loopguard</i>	(Optional) Is loopguard enabled ?
<i>bridge_assurance</i>	(Optional) Bridge Assurance
<i>networkport_default</i>	(Optional) Network Port default
<i>simulate_pvst</i>	(Optional) Is port is pvst simulate mode ?
<i>max-hops</i>	(Optional) Max Hops
<i>peer_switch_cfg</i>	(Optional) peer switch configuration status
<i>oper_peer_switch</i>	(Optional) peer switch operational status
<i>stp_l2gstp_domain_id</i>	(Optional) L2 Gateway STP Domain ID
<i>stp_lite</i>	(Optional) STP-Lite
<i>stp_summary_totals</i>	(Optional) Total num STP trees
<i>total_tree_type</i>	(Optional) Tree Type
<i>disabled</i>	(Optional) Number of ports Disabled
<i>blocking</i>	(Optional) Number of ports Blocking
<i>listening</i>	(Optional) Number of ports Listening
<i>learning</i>	(Optional) Number of ports Learning
<i>forwarding</i>	(Optional) Number of ports Forwarding
<i>invalid</i>	(Optional) Number of ports Invalid
<i>port_count</i>	(Optional) Number of Ports in Tree

Command Mode

- /exec

show ssh key

```
show ssh key [ { dsa [ md5 ] | rsa [ md5 ] | [ md5 ] } ] [ __readonly__ { TABLE_sessions <key_type>
<key_time> <key_data> <key_bitcount> <key_fingerprint> } ]
```

Syntax Description

show	Show running system information
ssh	Show SSH information
key	Show ssh keys
dsa	(Optional) Show dsa ssh keys
rsa	(Optional) Show rsa ssh keys
md5	(Optional) Show Fingerprint in MD5 Format
__readonly__	(Optional)
TABLE_sessions	(Optional) ssh key
<i>key_type</i>	(Optional) keys type
<i>key_time</i>	(Optional) timestamp
<i>key_data</i>	(Optional) ssh key data
<i>key_bitcount</i>	(Optional) bitcount
<i>key_fingerprint</i>	(Optional) fingerprint

Command Mode

- /exec

show ssh server

```
show ssh server [ __readonly__ { operation_status <o_status> } ]
```

Syntax Description

show	Show running system information
ssh	Show SSH information
server	Show whether ssh server is enabled or not
__readonly__	(Optional)
operation_status	(Optional) run-time information about ssh
<i>o_status</i>	(Optional) operational status of ssh server

Command Mode

- /exec

show startup-config

show startup-config

Syntax Description

show	Show running system information
startup-config	Current startup configuration

Command Mode

- /exec

show startup-config aaa

show startup-config aaa

Syntax Description

show	show startup-cfg
startup-config	show startup system information
aaa	Display aaa configuration

Command Mode

- /exec

show startup-config aclmgr

show startup-config aclmgr [all]

Syntax Description

show	Show running system information
startup-config	Display the startup configuration
aclmgr	show startup config for aclmgr
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config adjmgr

show startup-config adjmgr [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
adjmgr	Display adjmgr information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config amt

show startup-config amt [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
amt	Display amt information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config arp

show startup-config arp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
arp	Display arp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config bfd

show startup-config bfd [all]

Syntax Description

show	Show system information
startup-config	Display the startup configuration
bfd	show startup config for bfd
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config bgp

show startup-config bgp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
bgp	Display bgp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config bloggerd

show startup-config bloggerd [all]

Syntax Description

show	show startup-cfg
startup-config	show system startup configuration information
bloggerd	Display bloggerd configuration
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config callhome

show startup-config callhome

Syntax Description

show	show startup-cfg
startup-config	show startup system information
callhome	Display callhome configuration

Command Mode

- /exec

show startup-config catena

show startup-config catena

Syntax Description

show	show startup-cfg
startup-config	show startup system information
catena	catena instances

Command Mode

- /exec

show startup-config cdp

show startup-config cdp [all]

Syntax Description

show	show startup-cfg
startup-config	show system startup configuration information
cdp	Display cdp configuration
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config cert-enroll

show startup-config cert-enroll

Syntax Description

show	show startup-cfg
startup-config	show startup system information
cert-enroll	Display certificates configuration

Command Mode

- /exec

show startup-config cfs

show startup-config cfs [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
cfs	Display cfs configurations
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config config-profile

show startup-config config-profile [<all_conf_profile_name>]

Syntax Description

show	Show startup-config
startup-config	Current startup configuration
config-profile	Display port-profile configuration
<i>all_conf_profile_name</i>	(Optional) Enter the name of the profile

Command Mode

- /exec

show startup-config copp

show startup-config copp [all]

Syntax Description

show	Show running system information
startup-config	System startup-config commands
copp	Control-Plane Policing
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config diagnostic

show startup-config diagnostic [all]

Syntax Description

show	Show running system information
startup-config	Contents of startup configuration
diagnostic	Diagnostic configuration
all	(Optional) Display running config with defaults

Command Mode

- /exec

show startup-config dot1x

show startup-config dot1x

Syntax Description

show	show startup-cfg
startup-config	show startup system information
dot1x	Display dot1x configuration

Command Mode

- /exec

show startup-config ecp

show startup-config ecp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
ecp	ECP (Edge Control Protocol)
all	(Optional) Display startup config with defaults

Command Mode

- /exec

show startup-config eem

show startup-config eem

Syntax Description

show	Show running system information
startup-config	Show the system startup configuration
eem	Show the event manager startup configuration

Command Mode

- /exec

show startup-config eigrp

show startup-config eigrp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
eigrp	Display eigrp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config eltm

show startup-config eltm

Syntax Description

show	Show running system information
startup-config	Current startup configuration
eltm	Display eltm configurations

Command Mode

- /exec

show startup-config evb

show startup-config evb [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
evb	EVB (Edge Virtual Bridge)
all	(Optional) Display startup config with defaults

Command Mode

- /exec

show startup-config exclude

show startup-config exclude <feature-list> +

Syntax Description

show	Show running system information
startup-config	Current startup configuration
exclude	Exclude startup configuration of specified features
<i>feature-list</i>	Exclude features

Command Mode

- /exec

show startup-config expand-port-profile

show startup-config expand-port-profile

Syntax Description

show	Show running system information
startup-config	System startup-config commands
expand-port-profile	Expand port profile

Command Mode

- /exec

show startup-config fabric forwarding

show startup-config fabric forwarding [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
fabric	Fabric
forwarding	Fabric Forwarding Protocol: Host Mobility Manager (HMM)
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config fabric multicast

show startup-config fabric multicast [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
fabric	Fabric
multicast	Multicast information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config hw_telemetry

show startup-config hw_telemetry [all]

Syntax Description

startup-config	Current startup configuration
hw_telemetry	show startup config for hw_telemetry
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config icam

show startup-config icam

Syntax Description

show	show startup-cfg
startup-config	show startup system information
icam	icam services

Command Mode

- /exec

show startup-config icmpv6

show startup-config icmpv6 [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
icmpv6	Display icmpv6 information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config igmp

show startup-config igmp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
igmp	Display igmp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config imp

show startup-config imp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
imp	Display imp information
all	(Optional) Display start config with defaults clis

Command Mode

- /exec

show startup-config interface

show startup-config interface <if0> [membership] [expand-port-profile]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
interface	Interface configuration
<i>if0</i>	interface type and number in module/slot format
membership	(Optional) Show membership information
expand-port-profile	(Optional) Expand port profile

Command Mode

- /exec

show startup-config interface

show startup-config interface [<if0>] [expand-port-profile]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
interface	Interface configuration
<i>if0</i>	(Optional) interface type and number in module/slot format
expand-port-profile	(Optional) Expand port profile

Command Mode

- /exec

show startup-config ip

show startup-config ip [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
ip	Display ip information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config ipqos

show startup-config ipqos [all]

Syntax Description

show	Show running system information
startup-config	Display the startup configuration
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config ipv6

show startup-config ipv6 [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
ipv6	Display ipv6 information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config isis

show startup-config isis [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
isis	Display isis information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config l3vm

show startup-config l3vm [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
l3vm	Display l3vm information
all	(Optional) Display running config with defaults

Command Mode

- /exec

show startup-config ldap

show startup-config ldap

Syntax Description

show	show startup-cfg
startup-config	show startup system information
ldap	Display ldap configuration

Command Mode

- /exec

show startup-config license

show startup-config license [all]

Syntax Description

show	show startup-cfg
startup-config	show startup system information
license	Display licensing configuration
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config lisp

show startup-config lisp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
lisp	Display lisp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config lldp

show startup-config lldp [all]

Syntax Description

show	show startup-cfg
startup-config	show system startup configuration information
lldp	Display lldp configuration
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config log

show startup-config { log | mdp-log } [bootstrap]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
mdp-log	Displays execution log of last used mdp ascii startup configuration
log	Displays execution log of last used ascii startup configuration
bootstrap	(Optional) Bootstrap config replay execution log

Command Mode

- /exec

show startup-config macsec

show startup-config macsec

Syntax Description

show	Show running system information
startup-config	show startup system information
macsec	Show CTS information

Command Mode

- /exec

show startup-config mmode

show startup-config mmode [all]

Syntax Description

show	Show running system information
startup-config	Show startup configuration
mmode	Display maintenance mode startup configuration
all	(Optional) Show startup config with defaults

Command Mode

- /exec

show startup-config monitor

show startup-config monitor

Syntax Description

show	Show running system information
startup-config	Current startup configuration
monitor	Configure Ethernet SPAN sessions

Command Mode

- /exec

show startup-config mpls ldp

show startup-config mpls ldp [all]

Syntax Description

show	Show running system information
startup-config	Current operating configuration
mpls	Display MPLS status and configuration
ldp	Label Distribution Protocol
all	(Optional) Display running-config with defaults

Command Mode

- /exec

show startup-config mpls static

show startup-config mpls static [all]

Syntax Description

show	Show running system information
startup-config	Current operating configuration
mpls	Display MPLS status and configuration
static	Static Label Bindings
all	(Optional) Display running-config with defaults

Command Mode

- /exec

show startup-config mpls strip

show startup-config mpls strip [all]

Syntax Description

show	Show running system information
mpls	Configure MPLS settings
strip	Stripping of MPLS headers
startup-config	System startup configuration
all	(Optional) Show startup configuration for STRIPCL with defaults

Command Mode

- /exec

show startup-config mpls traffic-eng

show startup-config mpls traffic-eng [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
mpls	show startup config for mpls features
traffic-eng	show startup-config for Traffic Engineering
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config msdp

show startup-config msdp [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
msdp	Display msdp information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config nat

show startup-config nat [all]

Syntax Description

show	Show system information
startup-config	Display the startup configuration
nat	show startup config for nat
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config nbm

show startup-config nbm

Syntax Description

show	Show running system information
startup-config	Current startup configuration
nbm	Non Blocking Multicast

Command Mode

- /exec

show startup-config ngoam

show startup-config ngoam

Syntax Description

show	Show running system information
startup-config	Show startup system information
ngoam	ngoam configuration

Command Mode

- /exec

show startup-config ntp

show startup-config ntp [all]

Syntax Description

show	Show information
startup-config	Show startup system configuration
ntp	Show NTP information
all	(Optional) Show all NTP startup configuration

Command Mode

- /exec

show startup-config nxsdk

show startup-config nxsdk [all]

Syntax Description

show	Show running system information
startup-config	Display the startup configuration
nxsdk	NXOS SDK
all	(Optional) Display running config with defaults

Command Mode

- /exec

show startup-config openflow

show startup-config openflow [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
openflow	Show startup config for OpenFlow
all	(Optional) Show startup config with defaults

Command Mode

- /exec

show startup-config ospf

show startup-config ospf [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
ospf	Display ospf information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config ospfv3

show startup-config ospfv3 [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
ospfv3	Display ospfv3 information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config otv-isis

show startup-config otv-isis [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
otv-isis	Display otv-isis information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config otv

show startup-config otv [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
otv	Display otv information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config param-list

show startup-config param-list [<plistname>]

Syntax Description

show	Show startup-cfg
startup-config	show startup configuration
param-list	Display param-list configuration
<i>plistname</i>	(Optional) Enter the name of the param list

Command Mode

- /exec

show startup-config pim

show startup-config pim [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
pim	Display pim information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config pim6

show startup-config pim6 [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
pim6	Display pim6 information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config plb-services

show startup-config plb-services

Syntax Description

show	show startup-cfg
startup-config	show startup system information
plb-services	PLB services

Command Mode

- /exec

show startup-config poe

show startup-config poe [all]

Syntax Description

show	Show running system information
startup-config	Current saved configuration
poe	Power over Ethernet
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config port-profile

show startup-config port-profile [<all_profile_name>]

Syntax Description

show	Show startup-config
startup-config	Current startup configuration
port-profile	Display port-profile configuration
<i>all_profile_name</i>	(Optional) Enter the name of the profile

Command Mode

- /exec

show startup-config port-security

show startup-config port-security [all]

Syntax Description

show	show startup-cfg
startup-config	show startup system information
port-security	Display port-security configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config ptp

show startup-config ptp [all]

Syntax Description

startup-config	Current startup configuration
ptp	show startup config for ptp
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config radius

show startup-config radius

Syntax Description

show	show startup-cfg
startup-config	show startup system information
radius	Display radius configuration

Command Mode

- /exec

show startup-config rip

show startup-config rip [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
rip	Display rip information
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config rpm

show startup-config rpm [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
rpm	Display Route Policy Manager (RPM) information
all	(Optional) Display startup config with defaults

Command Mode

- /exec

show startup-config rsvp

show startup-config rsvp

Syntax Description

show	Show running system information
startup-config	Current startup configuration
rsvp	Display RSVP status

Command Mode

- /exec

show startup-config security

show startup-config security

Syntax Description

show	show startup-cfg
startup-config	show startup system information
security	Display security configuration

Command Mode

- /exec

show startup-config segment-routing

show startup-config segment-routing [all]

Syntax Description

show	Show running system information
startup-config	Show startup configuration
segment-routing	Display segment-routing startup configuration
all	(Optional) Show startup config with defaults

Command Mode

- /exec

show startup-config services

show startup-config services

Syntax Description

show	show startup-cfg
startup-config	show startup system information
services	services

Command Mode

- /exec

show startup-config sflow

show startup-config sflow [all]

Syntax Description

startup-config	Current startup configuration
sflow	show startup config for sflow
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config smart-channel

show startup-config smart-channel

Syntax Description

show	show startup-cfg
startup-config	show startup system information
smart-channel	smart-channel services

Command Mode

- /exec

show startup-config snmp

show startup-config snmp [all]

Syntax Description

show	show startup-cfg
startup-config	show startup system information
snmp	Display snmp configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config switch

show startup-config { switch-profile | include-switch-profile }

Syntax Description

show	Show running system information
startup-config	System startup configuration
switch-profile	Show switch-profile information
include-switch-profile	Show startup and switch-profile configuration

Command Mode

- /exec

show startup-config tacacs

show startup-config tacacs +

Syntax Description

show	show startup-cfg
startup-config	show startup system information

Command Mode

- /exec

show startup-config telemetry

show startup-config telemetry [all]

Syntax Description

show	show startup system configuration
startup-config	show startup system information
telemetry	Display telemetry configuration
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config track

show startup-config track

Syntax Description

show	Show running system information
startup-config	Show the system startup configuration
track	Show the track startup configuration

Command Mode

- /exec

show startup-config uddl

show startup-config uddl

Syntax Description

show	Show running system information
startup-config	Current startup configuration
uddl	Show uddl configuration

Command Mode

- /exec

show startup-config vdc-all

show startup-config vdc-all

Syntax Description

show	Show running system information
startup-config	Current startup configuration
vdc-all	Display config from all VDC

Command Mode

- /exec

show startup-config vdc

show startup-config vdc [all]

Syntax Description

show	Show running system information
startup-config	Current saved configuration
vdc	Show Virtual Device Contexts
all	(Optional) show startup config with defaults

Command Mode

- /exec

show startup-config virtual-service

show startup-config virtual-service

Syntax Description

show	Show running system information
startup-config	System startup-config commands
virtual-service	Show startup config for virtualization services

Command Mode

- /exec

show startup-config vlan

show startup-config vlan <vlan-id>

Syntax Description

show	Show running system information
startup-config	System startup-config commands
vlan	Vlan commands
<i>vlan-id</i>	VLAN ID 1-4094 or range(s): 1-5, 10 or 2-5,7-19

Command Mode

- /exec

show startup-config vlan

show startup-config vlan

Syntax Description

show	Show running system information
startup-config	System startup-config commands
vlan	Vlan commands

Command Mode

- /exec

show startup-config vpc

show startup-config vpc [all]

Syntax Description

startup-config	Current startup configuration
vpc	show startup config for vPC
all	(Optional) show running config with defaults

Command Mode

- /exec

show startup-config vrf

show startup-config vrf <vrf-cfg-name> [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
vrf	Display VRF information
<i>vrf-cfg-name</i>	Configurable VRF name
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config vrf default

show startup-config vrf default [all]

Syntax Description

show	Show running system information
startup-config	Current startup configuration
vrf	Display VRF information
default	Known VRF name
all	(Optional) Display running config with defaults clis

Command Mode

- /exec

show startup-config vshd

show startup-config vshd

Syntax Description

show	Show startup system information
startup-config	Current startup configuration
vshd	Show startup config for vshd

Command Mode

- /exec

show startup-config vtp

show startup-config vtp [all]

Syntax Description

show	Show running system information
startup-config	System startup-config commands
vtp	Show startup configuration for VTP
all	(Optional) Show startup configuration for VTP with defaults

Command Mode

- /exec

show summary

```
show { ip mbgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] | ip bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] all | ip bgp [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ] [ ipv4 [ { unicast | multicast } ] ] } summary [ vrf { <vrf-name> | <vrf-known-name> | ALL_VRFS_012345678901234 } ]
```

Syntax Description

show	Show running system information
ip	Display IP information
bgp	Display BGP status and configuration
mbgp	Display MBGP status and configuration
vrf	(Optional) Virtual Router Context
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
summary	Display summarized information of BGP state
ipv4	(Optional) Display BGP information for IPv4 address family
unicast	(Optional) Display BGP information for unicast address family
multicast	(Optional) Display BGP information for multicast address family
all	Display BGP information for all address families

Command Mode

- /exec

show switch-profile

show switch-profile [__readonly__ <profile_name> <cfg_rev>]

Syntax Description

show	Show running system information
switch-profile	Show switch-profiles
__readonly__	(Optional)
<i>profile_name</i>	(Optional)
<i>cfg_rev</i>	(Optional)

Command Mode

- /exec

show switch-profile

```
show switch-profile [ <profile-name> ] { session-history | status commit } [ __readonly__ <prof-name>
TABLE_session <session_index> <start_usec> <start_time> <end_usec> <end_time> <revision_number>
<session_type> <session_subtype> <peer_triggered> <profile_status> <local_status> <local_error>
<peer_address> <peer_sync_status> <merge_flags> <remote_status> <remote_error> ]
```

Syntax Description

show	Show running system information
switch-profile	Show switch-profile
session-history	Switch-profile session-history
<i>profile-name</i>	(Optional) switch-profile name
status	Switch-profile sync status
commit	Switch-profile last commit status
__readonly__	(Optional)
<i>prof-name</i>	(Optional)
TABLE_session	(Optional)
<i>session_index</i>	(Optional)
<i>start_usec</i>	(Optional)
<i>start_time</i>	(Optional)
<i>end_usec</i>	(Optional)
<i>end_time</i>	(Optional)
<i>revision_number</i>	(Optional)
<i>session_type</i>	(Optional)
<i>session_subtype</i>	(Optional)
<i>peer_triggered</i>	(Optional)
<i>profile_status</i>	(Optional)
<i>local_status</i>	(Optional)
<i>local_error</i>	(Optional)
<i>peer_address</i>	(Optional)
<i>peer_sync_status</i>	(Optional)

<i>merge_flags</i>	(Optional)
<i>remote_status</i>	(Optional)
<i>remote_error</i>	(Optional)

Command Mode

- /exec

show switch-profile buffer

show switch-profile [<profile-name>] buffer [__readonly__ <prof-name> <seq_no> <cmd>]

Syntax Description

show	Show running system information
switch-profile	Show switch-profile
buffer	buffered commands
<i>profile-name</i>	(Optional) switch-profile name
__readonly__	(Optional)
<i>prof-name</i>	(Optional)
<i>seq_no</i>	(Optional)
<i>cmd</i>	(Optional)

Command Mode

- /exec

show switch-profile peer

```
show switch-profile [ <profile-name> ] peer [ <dest-ip> ] [ details ] [ __readonly__ <prof-name> <rev>
<peer_address> <peer_sync_status> <merge_flags> <remote_status> <remote_error> <cmd> ]
```

Syntax Description

show	Show running system information
switch-profile	Show switch-profile
<i>profile-name</i>	(Optional) switch-profile name
peer	peer info
<i>dest-ip</i>	(Optional) IPv4 address (A.B.C.D) of destination
details	(Optional) information in detail
<i>__readonly__</i>	(Optional)
<i>prof-name</i>	(Optional)
<i>rev</i>	(Optional)
<i>peer_address</i>	(Optional)
<i>peer_sync_status</i>	(Optional)
<i>merge_flags</i>	(Optional)
<i>remote_status</i>	(Optional)
<i>remote_error</i>	(Optional)
<i>cmd</i>	(Optional)

Command Mode

- /exec

show switch-profile status

```
show switch-profile [ <profile-name> ] status [ __readonly__ <prof-name> <start_usec> <start_time>
<end_usec> <end_time> <revision_number> <session_type> <session_subtype> <peer_triggered>
<profile_status> <local_status> <local_error> <peer_address> <peer_sync_status> <merge_flags>
<remote_status> <remote_error> ]
```

Syntax Description

show	Show running system information
switch-profile	Show switch-profile
status	Switch-profile sync status
<i>profile-name</i>	(Optional) switch-profile name
<i>__readonly__</i>	(Optional)
<i>prof-name</i>	(Optional)
<i>start_usec</i>	(Optional)
<i>start_time</i>	(Optional)
<i>end_usec</i>	(Optional)
<i>end_time</i>	(Optional)
<i>revision_number</i>	(Optional)
<i>session_type</i>	(Optional)
<i>session_subtype</i>	(Optional)
<i>peer_triggered</i>	(Optional)
<i>profile_status</i>	(Optional)
<i>local_status</i>	(Optional)
<i>local_error</i>	(Optional)
<i>peer_address</i>	(Optional)
<i>peer_sync_status</i>	(Optional)
<i>merge_flags</i>	(Optional)
<i>remote_status</i>	(Optional)
<i>remote_error</i>	(Optional)

Command Mode

- /exec

show switch-scope controller

show switch-scope controller

Syntax Description

show	Show running system information
switch-scope	switch-scope
controller	Controller command

Command Mode

- /exec

show switching-mode

show switching-mode [__readonly__ TABLE_switching_mode <switching-mode-desc>]

Syntax Description

show	Show running system information
switching-mode	Show the operating switching mode
__readonly__	(Optional)
TABLE_switching_mode	(Optional) the xml switching_mode configuration
<i>switching-mode-desc</i>	(Optional) switching mode description

Command Mode

- /exec

show switching-mode fabric-speed

show switching-mode fabric-speed [__readonly__ TABLE_switching_mode <switching-mode-desc>]

Syntax Description

show	Show running system information
switching-mode	Show the operating switching mode
__readonly__	(Optional)
TABLE_switching_mode	(Optional) the xml switching_mode configuration
<i>switching-mode-desc</i>	(Optional) switching mode description
fabric-speed	Show the fabric speed

Command Mode

- /exec

show system auto-collect tech-support

show system auto-collect tech-support [__readonly__ <result>]

Syntax Description

show	Show running system information
system	System management commands
auto-collect	Auto collection of information
tech-support	Collect tech-support in case of service causing supervisor reset
__readonly__	(Optional)
<i>result</i>	(Optional) show tech collection enable status

Command Mode

- /exec

show system clis event-history

show system [internal] clis event-history { nvdb | client | errors | parser | ha | cli | objstr | objstr-errors }

Syntax Description

show	Display output
system	System-related show commands
internal	(Optional) Commands for internal use
clis	cli server
event-history	Event history logs for clis
nvdb	Log of NVDB and PSS events
client	Log of client interaction events
errors	Log of errors
parser	Log of parser events
ha	Log of ha events
cli	Log of command events
objstr	Log of Object Store events
objstr-errors	Log of Object Store error events

Command Mode

- /exec

show system config reload-pending

show system config reload-pending [__readonly__ { TABLE_reload_pending <cmds_list> }]

Syntax Description

show	Show running system information
system	System-related show commands
config	Config commands which require reload
reload-pending	Commands which require a reload
__readonly__	(Optional)
TABLE_reload_pending	(Optional) reload pending commands list
cmds_list	(Optional) cmds_list

Command Mode

- /exec

show system cores

show system cores [__readonly__ { <content> }]

Syntax Description

show	Show running system information
system	System-related show commands
cores	Displays core transfer option
__readonly__	(Optional)
<i>content</i>	(Optional) Core transfer option

Command Mode

- /exec

show system dme status

show system dme status [__readonly__ <dme-status>]

Syntax Description

show	Show running system information
system	System-related show commands
dme	Display dme information
status	Display dme enable/disable status information
__readonly__	(Optional)
<i>dme-status</i>	(Optional) DME enable/disable status

Command Mode

- /exec

show system error-id

show system error-id { list | <i0> } [__readonly__ <errorid> <facility> <desc>]

Syntax Description

show	Show running system information
system	System-related show commands
error-id	Show description about errors
list	Show description about all error IDs
<i>i0</i>	Show description about specific error
<i>__readonly__</i>	(Optional)
<i>errorid</i>	(Optional)
<i>facility</i>	(Optional)
<i>desc</i>	(Optional)

Command Mode

- /exec

show system exception-info

```
show system exception-info [ __readonly__ { TABLE_exception { <second> <panic_data> <register_data>
<stack_pointer> <stack_depth> <stack_timestamp> <stac_magic> <hdr_length> <stack_data> <pre_usec>
<pre_sec> <int_t> <reason> <service> <version> } } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
exception-info	Show last exception log information
__readonly__	(Optional)
TABLE_exception	(Optional)
<i>second</i>	(Optional) Time of exception
<i>panic_data</i>	(Optional) Panic information dump
<i>register_data</i>	(Optional) CPU register dump
<i>stack_pointer</i>	(Optional) Current Stack-pointer
<i>stack_depth</i>	(Optional) Current Stack-depth
<i>stack_timestamp</i>	(Optional) Stack dump timestamp
<i>stac_magic</i>	(Optional) Stack Magic
<i>hdr_length</i>	(Optional) Hdr length
<i>stack_data</i>	(Optional) Stack Dump
<i>pre_usec</i>	(Optional)
<i>pre_sec</i>	(Optional)
<i>int_t</i>	(Optional)
<i>reason</i>	(Optional) Reason
<i>service</i>	(Optional) Service
<i>version</i>	(Optional) Version

Command Mode

- /exec

show system fast-reload stabilization-timer

show system fast-reload stabilization-timer [__readonly__ { <timer_val> }]

Syntax Description

show	Show running system information
system	System management commands
fast-reload	fast-reload software
stabilization-timer	Network stabilization time in seconds before fast-reload can be executed after the previous reload
__readonly__	(Optional) Read Only
<i>timer_val</i>	(Optional) XML attribute for timer value

Command Mode

- /exec

show system inband queuing statistics

```
show system inband queuing statistics [ __readonly__ { TABLE_sys_inband_queue_stats <inbandpktunmap>
<inbandpktbpdqueue> <inbandpktmapq0> <inbandpktmapq1> <klmpktmapbpdu> <klmpktmaparp>
<klmpktmapq0> <klmpktmapq1> <klmpktmapveobc> <queuename> [ TABLE_bpdu_stats { <pmrecvpkts>
<pmdroppkts> <pmcongested> <rcvbuf> <sndbuf> <ipmndrop> } ] [ TABLE_q_stats { <indexstat>
<ipmrecvpkts> <ipmdroppkts> <ipmcongested> <ircvbuf> <isndbuf> <ipmndrop> } ] } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
inband	Inband Commands
queuing	Inband Queuing commands
statistics	Inband statistics
__readonly__	(Optional)
TABLE_sys_inband_queue_stats	(Optional) System Inband Statistics
<i>inbandpktunmap</i>	(Optional) Inband packets unmapped
<i>inbandpktbpdqueue</i>	(Optional) Inband packets mapped to bpdu
<i>inbandpktmapq0</i>	(Optional) Inband packets mapped to q0
<i>inbandpktmapq1</i>	(Optional) Inband packets mapped to q1
<i>klmpktmapbpdu</i>	(Optional) In KLM packets mapped to bpdu
<i>klmpktmaparp</i>	(Optional) In KLM packets mapped to arp
<i>klmpktmapq0</i>	(Optional) In KLM packets mapped to q0
<i>klmpktmapq1</i>	(Optional) In KLM packets mapped to q1
<i>klmpktmapveobc</i>	(Optional) In KLM packets mapped to veobc
<i>queuename</i>	(Optional) Inband queue name
TABLE_bpdu_stats	(Optional) BPDU Statistics
<i>pmrecvpkts</i>	(Optional) BPDU Receive Packets
<i>pmdroppkts</i>	(Optional) BPDU Drop Packets
<i>pmcongested</i>	(Optional) BPDU Congested
<i>rcvbuf</i>	(Optional) BPDU Receive Buffer
<i>sndbuf</i>	(Optional) BPDU Send Buffer

<i>pmnoderop</i>	(Optional) BPDU No drop
TABLE_q_stats	(Optional) Queue Statistics
<i>indexstat</i>	(Optional) Queue Index
<i>ipmrecvpkts</i>	(Optional) Queue receive packets
<i>ipmdroppkts</i>	(Optional) Queue drop packets
<i>ipmcongested</i>	(Optional) Queue Congested
<i>ircvbuf</i>	(Optional) Queue receive buffer
<i>isndbuf</i>	(Optional) Queue send buffer
<i>ipmnodeop</i>	(Optional) Queue no drop

Command Mode

- /exec

show system inband queuing status

```
show system inband queuing status [ __readonly__ [ { TABLE_sys_inband_queue_status <pminbandweigh0>  
<pminbandweigh1> <pminbandweigh2> } ] ]
```

Syntax Description

show	Show running system information
system	System-related show commands
inband	Inband Commands
queuing	Inband Queuing commands
status	Selective Packet Discard Information
__readonly__	(Optional)
TABLE_sys_inband_queue_status	(Optional) System Inband Status
<i>pminbandweigh0</i>	(Optional) BPDU Weight
<i>pminbandweigh1</i>	(Optional) Q0 Weight
<i>pminbandweigh2</i>	(Optional) Q1 Weight

Command Mode

- /exec

show system kgdb

show system kgdb

Syntax Description

show	Show running system information
system	System-related show commands
kgdb	Displays state of kgdb_enable flag

Command Mode

- /exec

show system login

```
show system login [ __readonly__ [ [ <acc_list> ] [ <attempts> ] ] [ <within> <block_for> <time> ] [ <fail_count> ] [ <switch_mode> ] ]
```

Syntax Description

<code>show</code>	Show running system information
<code>system</code>	System-related show commands
<code>login</code>	Display Secure Login Configurations and State
<code>__readonly__</code>	(Optional)
<code>acc_list</code>	(Optional) Appiled ACL's
<code>attempts</code>	(Optional) Number of login failures
<code>within</code>	(Optional) Number of login failures within time
<code>block_for</code>	(Optional) Login disabled for time
<code>time</code>	(Optional) Time remaining to re-enble login
<code>fail_count</code>	(Optional) Login failure count
<code>switch_mode</code>	(Optional) Mode of operation

Command Mode

- /exec

show system login failures

```
show system login failures [ __readonly__ [ { TABLE_loginStats <username> <port> <remote_addr>
<app_name> <time> } ] ]
```

Syntax Description

show	Show running system information
system	System-related show commands
login	Secure Login
failures	Display Login failures in the current watch period
__readonly__	(Optional)
TABLE_loginStats	(Optional)
<i>username</i>	(Optional) User name
<i>port</i>	(Optional) Login port number
<i>remote_addr</i>	(Optional) Remote address
<i>app_name</i>	(Optional) Application name
<i>time</i>	(Optional) Login time

Command Mode

- /exec

show system memory-thresholds

```
show system memory-thresholds [ __readonly__ <critical_mem_threshold> <severe_mem_threshold>
<minor_mem_threshold> ]
```

Syntax Description

show	Show running system information
__readonly__	(Optional)
<i>critical_mem_threshold</i>	(Optional) Critical System Memory Threshold
<i>severe_mem_threshold</i>	(Optional) Severe System Memory Threshold
<i>minor_mem_threshold</i>	(Optional) Minor System Memory Threshold
system	System management commands
memory-thresholds	Set memory thresholds on the card

Command Mode

- /exec

show system mode

show system mode [__readonly__ <system_mode> [<timer_state>]]

Syntax Description

show	Show running system information
system	System configuration commands
mode	Show system mode
__readonly__	(Optional)
<i>system_mode</i>	(Optional) system mode
<i>timer_state</i>	(Optional) timer state

Command Mode

- /exec

show system pss shrink status

```
show system pss shrink status [ details ] [ __readonly__ { [ <summary> ] [ TABLE_per_vdc <vdc_id> [
TABLE_detail_events <service> <vdc> <event> ] ] [ TABLE_events <service> <vdc> <event> ] } ] ]
```

Syntax Description

<code>show</code>	Show running system information
<code>system</code>	System-related show commands
<code>pss</code>	Displays last pss shrink status
<code>shrink</code>	Displays last pss shrink status
<code>status</code>	Displays last pss shrink status
<code>details</code>	(Optional) Displays last pss shrink status details
<code>__readonly__</code>	(Optional)
<code>summary</code>	(Optional) PSS shrink summary
<code>TABLE_per_vdc</code>	(Optional)
<code>vdc_id</code>	(Optional) VDC id
<code>TABLE_detail_events</code>	(Optional) PSS shrink events
<code>service</code>	(Optional) Service name
<code>vdc</code>	(Optional) VDC number
<code>event</code>	(Optional) PSS evnets
<code>TABLE_events</code>	(Optional) PSS shrink events
<code>service</code>	(Optional) Service name
<code>vdc</code>	(Optional) VDC number
<code>event</code>	(Optional) PSS evnets

Command Mode

- /exec

show system redundancy ha status

```
show system redundancy ha status [ __readonly__ { [ TABLE_ha_status <vdc_id> <this_sup_internal_state>
<other_sup_internal_state> ] } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
redundancy	redundancy status
ha	vdc redundancy status
status	all vdc redundancy status
__readonly__	(Optional)
TABLE_ha_status	(Optional) HA status for all vdc's
<i>vdc_id</i>	(Optional) vdc id
<i>this_sup_internal_state</i>	(Optional) This Supervisor State
<i>other_sup_internal_state</i>	(Optional) Remote Supervisor State

Command Mode

- /exec

show system redundancy status

```
show system redundancy status [ __readonly__ { <rdn_mode_admin> <rdn_mode_oper> <this_sup>
<this_sup_rdn_state> <this_sup_sup_state> <this_sup_internal_state> [ <other_sup> ] [ <other_sup_rdn_state>
] [ <other_sup_sup_state> ] [ <other_sup_internal_state> ] } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
redundancy	redundancy status
status	Current redundancy status
<i>__readonly__</i>	(Optional) readonly
<i>rdn_mode_admin</i>	(Optional) Redundancy Mode Admin
<i>rdn_mode_oper</i>	(Optional) Redundancy Mode Operational
<i>this_sup</i>	(Optional) This Supervisor
<i>this_sup_rdn_state</i>	(Optional) Redundancy State
<i>this_sup_sup_state</i>	(Optional) Supervisor State
<i>this_sup_internal_state</i>	(Optional) Supervisor State
<i>other_sup</i>	(Optional) Other Supervisor
<i>other_sup_sup_state</i>	(Optional) Supervisor State
<i>other_sup_rdn_state</i>	(Optional) Redundancy tate
<i>other_sup_internal_state</i>	(Optional) Supervisor State

Command Mode

- /exec

show system reset-reason

```
show system reset-reason [ __readonly__ { TABLE_reason <slot> { TABLE_rr <time> <reason> <service>
<version> } } ]
```

Syntax Description

<code>show</code>	Show running system information
<code>system</code>	System-related show commands
<code>reset-reason</code>	Show last reset reason
<code>__readonly__</code>	(Optional)
<code>TABLE_reason</code>	(Optional) Reset reason info
<code>slot</code>	(Optional) slot
<code>TABLE_rr</code>	(Optional) reset reason
<code>time</code>	(Optional) time
<code>reason</code>	(Optional) reset reason
<code>service</code>	(Optional) service name
<code>version</code>	(Optional) version

Command Mode

- /exec

show system reset-reason

```
show system reset-reason <s0> <santa-cruz-range> [ __readonly__ { TABLE_xbarreason <slot> { TABLE_rr  
<time> <reason> <service> <version> } } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
reset-reason	Show last reset reason
<i>s0</i>	Show xbar module reset reason
<i>santa-cruz-range</i>	please enter the xbar module number
<i>__readonly__</i>	(Optional)
<i>TABLE_xbarreason</i>	(Optional) Reset reason info
<i>slot</i>	(Optional) slot
<i>TABLE_rr</i>	(Optional) reset reason
<i>time</i>	(Optional) time
<i>reason</i>	(Optional) reset reason
<i>service</i>	(Optional) service name
<i>version</i>	(Optional) version

Command Mode

- /exec

show system reset-reason module

```
show system reset-reason module <module> [ __readonly__ { TABLE_reason <slot> { TABLE_rr <time>
<reason> <service> <version> } } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
reset-reason	Show last reset reason
module	Show per module reset-reason code
<i>module</i>	please enter module number
<i>__readonly__</i>	(Optional)
TABLE_reason	(Optional) Reset reason info
<i>slot</i>	(Optional) slot
TABLE_rr	(Optional) reset reason
<i>time</i>	(Optional) time
<i>reason</i>	(Optional) reset reason
<i>service</i>	(Optional) service name
<i>version</i>	(Optional) version

Command Mode

- /exec

show system resources

show system resources <i0>

Syntax Description

show	Show running system information
system	System-related show commands
resources	Show system resources
<i>i0</i>	time interval in seconds

Command Mode

- /exec

show system resources

```
show system resources [ __readonly__ { [ <load_avg_1min> ] [ <load_avg_5min> ] [ <load_avg_15min> ]
[ <processes_total> ] [ <processes_running> ] [ <cpu_state_user> ] [ <cpu_state_kernel> ] [ <cpu_state_idle>
] [ TABLE_cpu_usage <cpuid> <user> <kernel> <idle> ] [ <memory_usage_total> ] [ <memory_usage_used>
] [ <memory_usage_free> ] [ <current_memory_status> ] } ]
```

Syntax Description

<code>show</code>	Show running system information
<code>system</code>	System-related show commands
<code>resources</code>	Show system resources
<code>__readonly__</code>	(Optional)
<code>TABLE_cpu_usage</code>	(Optional) All Cpu Usage Information
<code>load_avg_1min</code>	(Optional) Load Average 1 Min
<code>load_avg_5min</code>	(Optional) Load Average 5 Min
<code>load_avg_15min</code>	(Optional) Load Average 15 Min
<code>processes_total</code>	(Optional) Total processes
<code>processes_running</code>	(Optional) Running Processes
<code>cpu_state_user</code>	(Optional) CPU State User
<code>cpu_state_kernel</code>	(Optional) CPU State Kernel
<code>cpu_state_idle</code>	(Optional) CPU State Idle
<code>cpuid</code>	(Optional) CPU id
<code>user</code>	(Optional) user time
<code>kernel</code>	(Optional) kernel time
<code>idle</code>	(Optional) idle time
<code>memory_usage_total</code>	(Optional) Memory Usage Total
<code>memory_usage_used</code>	(Optional) Memory Usage Used
<code>memory_usage_free</code>	(Optional) Memory Usage Free
<code>current_memory_status</code>	(Optional) Current Memory Status

Command Mode

- /exec

show system resources module

show system resources [*<i0>*] module *<module>*

Syntax Description

show	Show running system information
system	System-related show commands
resources	Show system resources
<i>i0</i>	(Optional) time interval in seconds
module	Show system resources for specified module
<i>module</i>	module number

Command Mode

- /exec

show system resources module all

```
show system resources [ <i0> ] module all [ __readonly__ { TABLE_cpuinfo <sts_msg1> <str1> <cpu_module>
<cpu_5sec> <cpu_1min> <cpu_5min> } { TABLE_meminfo <sts_msg2> <str2> <mem_module> <mem_total>
<mem_used> <mem_free> <mem_total> } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
resources	Show system resources
<i>i0</i>	(Optional) time interval in seconds
module	Show system resources for specified module
all	Show system resources for all modules
__readonly__	(Optional)
TABLE_cpuinfo	(Optional)
<i>sts_msg1</i>	(Optional)
<i>str1</i>	(Optional)
<i>cpu_module</i>	(Optional)
<i>cpu_5sec</i>	(Optional)
<i>cpu_1min</i>	(Optional)
<i>cpu_5min</i>	(Optional)
TABLE_meminfo	(Optional)
<i>sts_msg2</i>	(Optional)
<i>str2</i>	(Optional)
<i>mem_module</i>	(Optional)
<i>mem_total</i>	(Optional)
<i>mem_used</i>	(Optional)
<i>mem_free</i>	(Optional)
<i>mem_total</i>	(Optional)

Command Mode

- /exec

show system routing mode

```
show system routing mode [ __readonly__ TABLE_system_routing_mode { [ <configured-sys-routing-mode>
] [ <applied-sys-routing-mode> ] [ <svi-hardware-flood-mode> ] [ <routing-perf-mode> ] [
<mrouting-perf-mode> ] } ]
```

Syntax Description

show	Show running system information
system	Show system information
routing	Show routing related information
mode	Show mode related information
__readonly__	(Optional)
TABLE_system_routing_mode	(Optional) the xml system_routing_mode configuration
<i>configured-sys-routing-mode</i>	(Optional) Configured system routing mode description
<i>applied-sys-routing-mode</i>	(Optional) Applied system routing mode description
<i>svi-hardware-flood-mode</i>	(Optional) Configured SVI hardware flood mode description
<i>routing-perf-mode</i>	(Optional) Applied System Routing Performance Mode description
<i>mrouting-perf-mode</i>	(Optional) Applied System Mrouting Performance Mode

Command Mode

- /exec

show system srg

show system srg

Syntax Description

show	Show running system information
system	System-related show commands
srg	Displays the system SRG

Command Mode

- /exec

show system standby manual-boot

show system standby manual-boot [__readonly__ { <content> }]

Syntax Description

show	Show running system information
system	System-related show commands
standby	Displays system standby manual boot option
manual-boot	Displays system standby manual boot option
__readonly__	(Optional)
<i>content</i>	(Optional) Displays system standby manual boot option

Command Mode

- /exec

show system switch-mode

show system switch-mode [__readonly__ <op_mode>]

Syntax Description

show	Show running system information
system	System-related show commands
switch-mode	Show current operational mode of the switch
__readonly__	(Optional)
<i>op_mode</i>	(Optional) Operational Mode

Command Mode

- /exec

show system switchover impact

show system switchover impact [<uri0> [<uri1>]]

Syntax Description

show	Show running system information
system	System-related show commands
switchover	Show the software switchover impact between two images
impact	impact {standby_system_uri} {active_system_uri}
<i>uri0</i>	(Optional) Enter standby URI
<i>uri1</i>	(Optional) Enter active URI

Command Mode

- /exec

show system uptime

```
show system uptime [ __readonly__ { <sys_st_time> <sys_up_days> <sys_up_hrs> <sys_up_mins>
<sys_up_secs> <kn_up_days> <kn_up_hrs> <kn_up_mins> <kn_up_secs> [ <as_up_days> ] [ <as_up_hrs>
] [ <as_up_mins> ] [ <as_up_secs> ] } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
uptime	Show how long the system has been up and running
__readonly__	(Optional) readonly
<i>sys_st_time</i>	(Optional) System Start Time
<i>sys_up_days</i>	(Optional) System Uptime Days
<i>sys_up_hrs</i>	(Optional) System Uptime Hours
<i>sys_up_mins</i>	(Optional) System Uptime Minutes
<i>sys_up_secs</i>	(Optional) System Uptime Seconds
<i>kn_up_days</i>	(Optional) Kernel Uptime Days
<i>kn_up_hrs</i>	(Optional) Kernel Uptime Hours
<i>kn_up_mins</i>	(Optional) Kernel Uptime Minutes
<i>kn_up_secs</i>	(Optional) Kernel Uptime Seconds
<i>as_up_days</i>	(Optional) Active Sup Uptime Days
<i>as_up_hrs</i>	(Optional) Active Sup Uptime Hours
<i>as_up_mins</i>	(Optional) Active Sup Uptime Minutes
<i>as_up_secs</i>	(Optional) Active Sup Uptime Seconds

Command Mode

- /exec

show system verify bios flash

```
show system verify bios { flash <i0> [ module <module> ] | protection <i1> [ module <module1> ] } [
__readonly__ { <return> <verify_result> <protection_status> } ]
```

Syntax Description

show	Show running system information
system	System-related show commands
verify	Verify commands
bios	Verify bios
flash	verify bios flash or protection status
<i>i0</i>	Select primary or alternate flash
module	(Optional) Module number
<i>module</i>	(Optional) Enter module number
protection	verify bios flash or protection status
<i>i1</i>	Select primary or alternate flash
module	(Optional) Module number
<i>module1</i>	(Optional) Enter module number
__readonly__	(Optional)
<i>return</i>	(Optional)
<i>verify_result</i>	(Optional)
<i>protection_status</i>	(Optional)

Command Mode

- /exec

show system vlan reserved

```
show system vlan reserved [ __readonly__ { TABLE_vlan <current_reserved_vlan_start>
<current_reserved_vlan_end> [ <future_reserved_vlan_start> ] [ <future_reserved_vlan_end> ] } ]
```

Syntax Description

show	Show running system information
system	system wide configuration
vlan	VLAN status
reserved	Show system VLAN allocation
__readonly__	(Optional) Read Only
TABLE_vlan	(Optional)
<i>current_reserved_vlan_start</i>	(Optional) System current running reserved vlan start
<i>current_reserved_vlan_end</i>	(Optional) System current running reserved vlan end
<i>future_reserved_vlan_start</i>	(Optional) System future running reserved vlan start
<i>future_reserved_vlan_end</i>	(Optional) System future running reserved vlan end

Command Mode

- /exec