



P Commands

- [packet-size](#), on page 6
- [param-list param-list](#), on page 7
- [parity](#), on page 8
- [parity](#), on page 9
- [passive-interface default](#), on page 10
- [passive-interface default](#), on page 11
- [passive-interface default](#), on page 12
- [passive-interface default](#), on page 13
- [password](#), on page 14
- [password](#), on page 15
- [password](#), on page 16
- [password prompt username](#), on page 17
- [password secure-mode](#), on page 18
- [password strength-check](#), on page 19
- [path-option dynamic explicit identifier](#), on page 20
- [path-selection metric igp](#), on page 21
- [path-selection metric igp](#), on page 22
- [path-selection overload allow](#), on page 23
- [path](#), on page 24
- [path next-hop out-label-stack](#), on page 25
- [pathtrace nve](#), on page 26
- [pause buffer-size2 pause-threshold2 resume-threshold2](#), on page 28
- [pause priority](#), on page 29
- [payload](#), on page 30
- [pcc](#), on page 31
- [pce-address ipv4](#), on page 32
- [pcep](#), on page 33
- [pcep](#), on page 34
- [peer-gateway](#), on page 35
- [peer-ip](#), on page 36
- [peer-keepalive destination](#), on page 37
- [peer-switch](#), on page 39
- [peer-type fabric](#), on page 40

- peer local service, on page 41
- peer vpc, on page 42
- perf, on page 43
- periodic-inventory notification, on page 44
- periodic-inventory notification interval, on page 45
- periodic to, on page 46
- periodic to, on page 47
- permit|deny, on page 48
- permit interface, on page 49
- permit vlan, on page 50
- permit vrf, on page 51
- permit vsan, on page 52
- personality, on page 53
- personality backup, on page 54
- personality restore, on page 55
- phone-contact, on page 56
- pim, on page 57
- pim, on page 58
- ping, on page 59
- ping6, on page 61
- ping mpls, on page 62
- ping nve, on page 66
- ping sr-mpls, on page 68
- platform rate-limiter span-egress, on page 71
- plb, on page 72
- plb analytics, on page 73
- plb device-group, on page 74
- pnp startup-vlan, on page 75
- police, on page 76
- police, on page 78
- policer, on page 82
- policer, on page 83
- policy-map, on page 84
- policy-map type control-plane, on page 85
- policy-map type network-qos, on page 86
- policy-map type queuing, on page 87
- policy, on page 88
- policy, on page 89
- policy, on page 90
- policy, on page 91
- pop, on page 92
- port-channel fast-convergence, on page 93
- port-channel hash-distribution, on page 94
- port-channel limit, on page 95
- port-channel load-balance1 ethernet, on page 96
- port-channel load-balance2 resilient, on page 97

- port-channel load-defer, on page 98
- port-channel port hash-distribution, on page 99
- port-channel port load-defer, on page 100
- port-channel scale-fanout, on page 101
- port-group, on page 102
- port-license, on page 103
- port-license, on page 104
- port-profile, on page 105
- port-type, on page 106
- port, on page 107
- port, on page 108
- port, on page 109
- port control, on page 110
- port destination, on page 111
- port type ethernet, on page 112
- postcard-telemetry exporter, on page 113
- postcard-telemetry flow-profile, on page 114
- postcard-telemetry monitor, on page 115
- postcard-telemetry queue-profile, on page 116
- postcard-telemetry system monitor, on page 117
- postcard-telemetry watchlist ip, on page 118
- power efficient-ethernet auto, on page 119
- power efficient-ethernet sleep threshold aggressive, on page 120
- power inline, on page 121
- power inline default_consumption, on page 122
- power inline police action, on page 123
- power inline port priority, on page 124
- power redundancy-mode ps-redundant, on page 125
- precision milliseconds, on page 126
- preempt, on page 127
- preempt, on page 128
- preempt delay minimum, on page 129
- preempt delay minimum reload sync preempt delay reload minimum sync preempt delay sync minimum reload preempt delay reload sync minimum preempt delay sync reload minimum preempt delay minimum sync reload preempt delay reload sync preempt delay sync reload preempt delay minimum sync preempt delay sync minimum preempt delay minimum reload preempt delay reload minimum preempt delay minimum preempt delay reload preempt delay sync preempt, on page 130
- preference, on page 132
- preference, on page 133
- preference max, on page 134
- preference min, on page 135
- prefix out, on page 136
- priority-flow-control auto-restore multiplier, on page 137
- priority-flow-control fixed-restore multiplier, on page 138
- priority-flow-control mode, on page 139
- priority-flow-control override-interface mode off, on page 140

- [priority-flow-control recover interface](#), on page 141
- [priority-flow-control watch-dog-interval on](#), on page 142
- [priority-flow-control watch-dog-interval on](#), on page 143
- [priority-flow-control watch-dog forced on](#), on page 144
- [priority-flow-control watch-dog interval](#), on page 145
- [priority-flow-control watch-dog shutdown-multiplier](#), on page 146
- [priority](#), on page 147
- [priority2](#), on page 148
- [priority](#), on page 149
- [priority](#), on page 150
- [priority](#), on page 151
- [priority](#), on page 152
- [priority](#), on page 153
- [private-vlan](#), on page 154
- [private-vlan association](#), on page 155
- [private-vlan mapping](#), on page 156
- [private-vlan synchronize](#), on page 157
- [probe-interval](#), on page 158
- [probe-interval](#), on page 159
- [probe](#), on page 160
- [probe](#), on page 161
- [probe](#), on page 162
- [probe](#), on page 163
- [probe](#), on page 164
- [probe](#), on page 165
- [probe get](#), on page 166
- [probe get](#), on page 167
- [probe get](#), on page 168
- [probe get](#), on page 169
- [probe host](#), on page 170
- [probe host](#), on page 171
- [probe host](#), on page 172
- [probe host](#), on page 173
- [probe host](#), on page 174
- [probe host](#), on page 175
- [probe port](#), on page 176
- [probe port](#), on page 177
- [probe port](#), on page 178
- [probe port](#), on page 179
- [probe port](#), on page 180
- [probe port](#), on page 181
- [profile](#), on page 182
- [profile](#), on page 183
- [profile](#), on page 184
- [propagate-sgt](#), on page 185
- [protected](#), on page 186

- protected, on page 187
- protection, on page 188
- proto, on page 189
- protocol-version, on page 190
- protocol-version, on page 191
- protocol, on page 192
- protocol, on page 193
- ptp, on page 194
- ptp announce timeout, on page 195
- ptp clock-sync auto, on page 196
- ptp correction-range, on page 197
- ptp correction-range logging, on page 198
- ptp correction hardware, on page 199
- ptp device-type boundary, on page 200
- ptp domain, on page 201
- ptp mean-path-delay, on page 202
- ptp multicast master-only, on page 203
- ptp offload, on page 204
- ptp pdelay-req-interval, on page 205
- ptp priority1, on page 206
- ptp priority2, on page 207
- ptp source, on page 208
- ptp vlan, on page 209
- push, on page 210
- pwd, on page 211
- python, on page 212
- python instance, on page 213

packet-size

```
{ packet-size <packetsize> }
```

Syntax Description

packet-size	Packet
packetsize	Size

Command Mode

- /exec/configure/configngoamconnectcheck

param-list param-list

[no] param-list <plistname> [cross-check] | param-list <plistname>

Syntax Description

no	(Optional) Negate a command or set its defaults
param-list	Configure a parameter list
plistname	Enter the name of the parameter list
cross-check	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED

Command Mode

- /exec/configure

parity

[no] parity { even | none | odd }

Syntax Description

no	(Optional) Negate a command or set its defaults
parity	Set terminal parity
even	Even parity
none	No parity
odd	Odd parity

Command Mode

- /exec/configure/com1

parity

[no] parity <parity-value>

Syntax Description

no	(Optional) Negate a command or set its defaults
parity	Set terminal parity
parity-value	terminal parity value

Command Mode

- /exec/configure/console

passive-interface default

[no] passive-interface default

Syntax Description

no	(Optional) Negate a command or set its defaults
passive-interface	Suppress routing updates on the interface
default	interfaces passive by default

Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

passive-interface default

[no] passive-interface default <level>

Syntax Description

no	(Optional) Negate a command or set its defaults
passive-interface	Suppress IS-IS PDU
default	Undo a command
level	IS-IS level

Command Mode

- /exec/configure/router-isis/router-isis-vrf-common

passive-interface default

[no] passive-interface default

Syntax Description

no	(Optional) Negate a command or set its defaults
passive-interface	Suppress routing updates on the interface
default	interfaces passive by default

Command Mode

- /exec/configure/router-ospf3 /exec/configure/router-ospf3/vrf

passive-interface default

[no] passive-interface default

Syntax Description

no	(Optional) Negate a command or set its defaults
passive-interface	Suppress routing updates on the interface
default	interfaces passive by default

Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-common

password

```
password [ vrf { <vrf-name> | <vrf-known-name> } ] { required [ req-for <req-pfx-list> ] | { fallback | option
<seq-num> opt-for <opt-pfx-list> } { key-chain <name> } } | no password [ vrf { <vrf-name> |
<vrf-known-name> } ] { required | fallback | option <seq-num> }
```

Syntax Description

no	Negate a command or set its defaults
password	Configure LDP password
vrf	(Optional) VRF Routing/Forwarding instance information
vrf-name	(Optional) VPN Routing/Forwarding instance name
vrf-known-name	(Optional) Known VRF name
required	Password is required for the peer
req-for	(Optional) Prefix list specifying control on LDP peers
req-pfx-list	(Optional) Prefix list for LDP peers
fallback	Specifies a fallback password will follow
option	LDP password option
seq-num	Sequence number of the LDP password option
opt-for	Prefix list specifying control on LDP peers
opt-pfx-list	Prefix list for LDP peers
key-chain	Specifies a key-chain name will follow
name	Key-chain name

Command Mode

- /exec/configure/ldp

password

password <password-string> | { no | default } password [<password-string>]

Syntax Description

no	Negate a command or set its defaults
default	Inherit values from a peer template
password	Configure a password for neighbor
password-string	Neighbor password

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor /exec/configure/router-bgp/router-bgp-neighbor-stmp
/exec/configure/router-bgp/router-bgp-vrf-neighbor
/exec/configure/router-bgp/router-bgp-template-neighbor
/exec/configure/router-bgp/router-bgp-prefixneighbor
/exec/configure/router-bgp/router-bgp-vrf-prefixneighbor

password

{ [no] password <passwd> }

Syntax Description

password	password
passwd	password

Command Mode

- /exec/configure/dot1x-cred

password prompt username

[no] password prompt username

Syntax Description

no	(Optional) Negate a command or set its defaults
password	Password for the user
prompt	Enable prompt for password
username	Enable prompt for password on username command

Command Mode

- /exec/configure

password secure-mode

[no] password secure-mode

Syntax Description

no	(Optional) Negate a command or set its defaults
password	Password for the user
secure-mode	Enable secure mode for changing password

Command Mode

- /exec/configure

password strength-check

[no] password strength-check

Syntax Description

no	(Optional) Negate a command or set its defaults
password	Password for the user
strength-check	Strength check of password

Command Mode

- /exec/configure

path-option dynamic explicit identifier

```
[no] path-option [ protect ] <pref> | path-option <pref> dynamic [ attributes <attr-name> | { bandwidth <kbps> | lockdown } + ] | path-option [ protect ] <pref> explicit { identifier <id-num> | name <name> } [ { attributes <attr-name> [ verbatim ] | { bandwidth <kbps> | lockdown | verbatim } + } ]
```

Syntax Description

no	Negate a command or set its defaults
path-option	a primary or fallback path setup option
protect	(Optional) a path protection setup option
pref	preference for this path option
dynamic	setup based on dynamically calculated path
explicit	setup based on preconfigured path
identifier	Specify an IP explicit path by number
id-num	Number of ip explicit path
name	Specify an IP explicit path by name
name	Name of ip explicit path
attributes	(Optional) Specify an LSP attribute list
attr-name	(Optional) Name of LSP attribute list
verbatim	(Optional) send out path as is, with no checking
bandwidth	(Optional) override the bandwidth configured on the tunnel
kbps	(Optional) bandwidth requirement in kbps
lockdown	(Optional) not a candidate for reoptimization
kbps	(Optional) bandwidth requirement in kbps
lockdown	(Optional) not a candidate for reoptimization

Command Mode

- /exec/configure/if-te /exec/configure/tunnel-te/cbts-member

path-selection metric igp

[no] path-selection metric | path-selection metric { igp | te }

Syntax Description

no	Negate a command or set its defaults
path-selection	Path Selection Configuration
metric	Metric type for path calculation
igp	Use IGP Metric
te	Use TE Metric

Command Mode

- /exec/configure/if-te /exec/configure/tunnel-te/cbts-member

path-selection metric igp

path-selection metric { igp | te } | no path-selection metric

Syntax Description

no	Negate a command or set its defaults
path-selection	Path Selection Configuration
metric	Metric Type Configuration
igp	Use IGP metric
te	Use TE metric (*Default)

Command Mode

- /exec/configure/te

path-selection overload allow

[no] path-selection overload allow | path-selection overload allow { head [middle] [tail] | middle [tail] | tail }

Syntax Description

no	Negate a command or set its defaults
path-selection	Path Selection Configuration
overload	Overload Node Configuration
allow	Allow overloaded nodes in CSPFs
head	Allow overloaded head node in TE CSPF
middle	(Optional) Allow overloaded middle node in TE CSPF
tail	(Optional) Allow overloaded tail node in TE CSPF

Command Mode

- /exec/configure/te

path

path { <dn> | environment |

Syntax Description

	vxlan
	vxlan
path	Create a sensor path
dn	Distinguished Name
environment	Monitor chassis information including fan,temperature,power,storage,supervisor,linecard

Command Mode

- /exec/configure/telemetry/sensor-group

path next-hop out-label-stack

```
{ no path <path-num> | path <path-num> next-hop <next-hop> out-label-stack { <static-outlabel> + |
implicit-null } }
```

Syntax Description

no	Negate a command or set its defaults
path	Configure an outgoing path for the LSP
path-num	Path identifier
next-hop	Nexthop
next-hop	Destination IPv4 next hop
out-label-stack	Series of output labels
static-outlabel	Label Value
implicit-null	IETF MPLS implicit null label (3)

Command Mode

- /exec/configure/mpls_static/ipv4/lsp/inlabel/forw

pathtrace nve

```
pathtrace nve { { { ip { <numeric10> | <numeric11> | unknown } } [ vrf { <vrf-name> | <vrf-known-name>
} | { <dot1qid1> } ] } | mac <dmac> <dot1qid> [ <intfid> ] } [ profile <pid> ] [ payload { [ mac-addr <dstmac>
<smac> ] [ dot1q <dot1q-id> ] [ ip <dstip> <srcip> | ipv6 <dstip6> <srcip6> ] [ port <sport> <dport> ] [
proto <proto-id> ] [ src-intf <src_if> ] } payload-end ] [ copy-to <copy-to-ip> [ ext-id <ext_id> ] ] [
```

Syntax Description

pathtrace	Test
nve	network virtualization edge
numeric10	Peer vtep ip address
unknown	Peer vtep ip is unknown, will be derived from payload
intfid	(Optional) Name of the interface for ngoam pathtrace on which dot1q is configured
payload	(Optional) Enter customer payload
mac-addr	(Optional) Mac
dstmac	(Optional) Destination mac address
smac	(Optional) Source mac address
dot1q	(Optional) Encapsulation dot1q/bd
dot1q-id	(Optional) Encapsulation dot1q/bd on which the mac is learnt
ip	ip address
dstip	(Optional) Destination ipv4 address
srcip	(Optional) source ipv4 address
ipv6	(Optional) ipv6 address
port	(Optional) L4 port info
sport	(Optional) Source port
dport	(Optional) Destination port
proto	(Optional) Protocol
proto-id	(Optional) IANA Protocol id
src-intf	(Optional) Interface on which the host with src ip of the payload is connected
src_if	(Optional) Interface

payload-end	(Optional) End payload info input
profile	(Optional) NGOAM profile to use
pid	(Optional) NGOAM profile id
mac	Mac
dmac	Destination mac address
dot1qid	Encapsulation dot1q/bd on which the mac is learnt
dot1qid1	(Optional) Encapsulation dot1q/bd on which the mac is learnt
vrf	(Optional) Display per-VRF information
vrf-name	(Optional) VRF name
vrf-known-name	(Optional) Known VRF name
copy-to	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
copy-to-ip	(Optional) IPv4 addr to send responses to
ext-id	(Optional) Identifier passed from caller
ext_id	(Optional) 32-bit identifier

Command Mode

- /exec

pause buffer-size2 pause-threshold2 resume-threshold2

[no] pause buffer-size2 <size-in-bytes> pause-threshold2 <xoff-bytes> resume-threshold2 <xon-bytes>

Syntax Description

no	(Optional) Negate a command or set its defaults
pause	PAUSE characteristics (CBFC)
buffer-size2	Ingress buffer size in bytes
pause-threshold2	Buffer limit for pausing in bytes
resume-threshold2	Buffer limit at which to resume in bytes

Command Mode

- /exec/configure/policy-map/type/queuing/class

pause priority

[no] pause { priority-group <priority-group-number> }

Syntax Description

no	(Optional) Negate a command or set its defaults
pause	PAUSE characteristics (CBFC)
priority-group	ingress priority-group to which the traffic is mapped and pause limits are applied
priority-group-number	Priority group value

Command Mode

- /exec/configure/policy-map/type/queuing/class

payload

[no] payload

Syntax Description

no	(Optional) Negate a command or set its defaults
payload	Configure ngoam connectivity check payload

Command Mode

- /exec/configure/configngoamconnectcheck

pcc

[no] pcc

Syntax Description

no	(Optional) Negate a command or set its defaults
pcc	PCC related configuration

Command Mode

- /exec/configure/sr/te

pce-address ipv4

[no] pce-address ipv4 <ip-address> [precedence <precedence>]

Syntax Description

no	(Optional) Negate a command or set its defaults
pce-address	Configure the address of the PCE
ipv4	Configure v4 address of the PCE
precedence	(Optional) Precedence of the PCE
ip-address	PCE address
precedence	(Optional) Path-option preference

Command Mode

- /exec/configure/sr/te/pcc

pcep

[no] pcep

Syntax Description

no	(Optional) Negate a command or set its defaults
pcep	Dynamic path needs to be computed externally via PCEP

Command Mode

- /exec/configure/sr/te/color/cndpaths/pref/dyn

pcep

[no] pcep

Syntax Description

no	(Optional) Negate a command or set its defaults
pcep	Dynamic path needs to be computed externally via PCEP

Command Mode

- /exec/configure/sr/te/pol/cndpaths/pref/dyn

peer-gateway

peer-gateway [exclude-vlan <vlan-list>] | no peer-gateway

Syntax Description

no	Negate a command or set its defaults
peer-gateway	Enable L3 forwarding for packets destined to peer's gateway mac-address
exclude-vlan	(Optional) Specify VLANs to be excluded from peer-gateway functionality
vlan-list	(Optional) Specify the list of vlans

Command Mode

- /exec/configure/vpc-domain

peer-ip

[no] peer-ip { <addr> }

Syntax Description

no	(Optional) Negate a command or set its defaults
peer-ip	Static IP Address Configuration
addr	Remote Peer IP Address

Command Mode

- /exec/configure/if-nve/vni/ingr-rep

peer-keepalive destination

```
peer-keepalive destination [ <dst-ip> | <dst-ipv6> ] [ [ source [ <src-ip> | <src-ipv6> ] | udp-port
<udp-port-num> | vrf { <vrf-name> | <vrf-known-name> } | { interval <interval-ms> timeout <time-out> } |
tos-byte <tos-byte-value> | hold-timeout <hold-time-out> ] + [ [ source [ <src-ip> | <src-ipv6> ] | udp-port
<udp-port-num> | vrf { <vrf-name> | <vrf-known-name> } | { interval <interval-ms> timeout <time-out> } |
tos { <tos-value> | min-delay | max-throughput | max-reliability | min-monetary-cost | normal } | hold-timeout
<hold-time-out> ] + [ [ source [ <src-ip> | <src-ipv6> ] | udp-port <udp-port-num> | vrf { <vrf-name> |
<vrf-known-name> } | { interval <interval-ms> timeout <time-out> } | precedence { <prec-vlaue> | network
| internet | critical | flash-override | flash | immediate | priority | routine } | hold-timeout <hold-time-out> ] +
]
```

Syntax Description

peer-keepalive	Keepalive/Hello with peer switch
destination	specify destination ip address of peer switch
dst-ip	(Optional) IPv4 address (A.B.C.D) of destination
source	(Optional) source interface for hello
src-ip	(Optional) IPv4 address (A.B.C.D) of source
udp-port	(Optional) enter UDP port number used for hello
udp-port-num	(Optional) udp port number for hellos
vrf	(Optional) vrf to be used for hello messages
vrf-name	(Optional) vrf to be used for hellos
vrf-known-name	(Optional) Known VRF name
interval	(Optional) enter interval in milleseconds
interval-ms	(Optional) Enter interval in milleseconds
timeout	(Optional) enter timeout in seconds
time-out	(Optional) enter timeout in seconds
precedence	(Optional) Precedence
prec-vlaue	(Optional) Precedence value
network	(Optional) network (7)
internet	(Optional) internet (6)
critical	(Optional) critical (5)
flash-override	(Optional) flash-override (4)
flash	(Optional) flash (3)

immediate	(Optional) immediate (2)
priority	(Optional) priority (1)
routine	(Optional) routine (0)
tos	(Optional) Type of Service(IPV4)/Traffic Class(IPV6)
tos-value	(Optional) Enter 4-bit TOS value
min-delay	(Optional) min-delay (8)
max-throughput	(Optional) max-throughput (4)
max-reliability	(Optional) max-reliability (2)
min-monetary-cost	(Optional) min-monetary-cost (1)
normal	(Optional) normal (0)
tos-byte	(Optional) Type of Service Byte (IPv4)/Traffic Class Octet(IPv6)
tos-byte-value	(Optional) Enter 8-bit TOS value
hold-timeout	(Optional) hold timeout to ignore stale peer alive messages
hold-time-out	(Optional) Enter hold-timeout in seconds

Command Mode

- /exec/configure/vpc-domain

peer-switch

[no] peer-switch

Syntax Description

no	(Optional) Negate a command or set its defaults
peer-switch	Enable peer switch on vPC pair switches

Command Mode

- /exec/configure/vpc-domain

peer-type fabric

peer-type { fabric-external | fabric-border-leaf } | { no | default } peer-type

Syntax Description

no	Negate a command or set its defaults
default	Inherit values from a peer template
peer-type	Neighbor facing
fabric-external	Fabric external
fabric-border-leaf	Fabric Border Leaf

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor-sess

peer local service

[no] peer local service <service-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
peer	Peer cli for sandwich mode failure notification
local	Peer involved in sandwich mode
service	Peer service involved in sandwich mode
service-name	Peer service name string

Command Mode

- /exec/configure/itd

peer vpc

[no] peer <svc-name> vpc <num>

Syntax Description

no	(Optional) Negate a command or set its defaults
peer	smart channel peer
vpc	vpc
svc-name	peer smart channel name
num	VPC number to assign to smart-channel

Command Mode

- /exec/configure/smartc

perf

```
perf [ { record { context-switch | profile } { system | process <i0> } [ <s1> ] } | { stop { all | <s0> } } | { list } | { create-archive <s2> } | { remove { all | <s3> } } ]
```

Syntax Description

perf	Run perf tool to collect or process event data
record	(Optional) Record events to a file for later analysis
stop	(Optional) Stop a perf record.
list	(Optional) List recorded datasets
create-archive	(Optional) Create an archive of dataset for download
remove	(Optional) Remove recorded dataset(s)
all	(Optional) Act on all recorded datasets
context-switch	(Optional) Record context-switch events
profile	(Optional) Record periodic runtime samples
system	(Optional) Record events for all processes on all CPUs
process	(Optional) Record events for a specific process with the given pid
i0	(Optional) pid of process to record events
s0	(Optional) id of perf record session to stop
s1	(Optional) id to use for perf record session
s2	(Optional) id of perf dataset to create an archive
s3	(Optional) id of perf dataset to remove

Command Mode

- /exec

periodic-inventory notification

[no] periodic-inventory notification

Syntax Description

no	(Optional) Negate a command or set its defaults
periodic-inventory	Configure periodic software inventory message dispatch
notification	Enable periodic software inventory message dispatch

Command Mode

- /exec/configure/callhome

periodic-inventory notification interval

periodic-inventory notification { interval <i0> | timeofday <s0> }

Syntax Description

periodic-inventory	Configure periodic software inventory message dispatch
notification	Enable periodic software inventory message dispatch
interval	Configure the time period for periodic inventory
i0	Time period in days (default is 7 days)
timeofday	Configure the timeofday for periodic inventory in HH:MM format
s0	Time period in HH:MM format

Command Mode

- /exec/configure/callhome

periodic to

```
{ [ <seqno> ] | no } periodic { { Monday | Tuesday | Wednesday | Thursday | Friday | Saturday | Sunday } +
| daily | weekdays | weekend } <stime> to <etime>
```

Syntax Description

seqno	(Optional) Sequence number
no	Negate a command or set its defaults
periodic	Periodic time and date
Monday	Monday
Tuesday	Tuesday
Wednesday	Wednesday
Thursday	Thursday
Friday	Friday
Saturday	Saturday
Sunday	Sunday
daily	Every day of the week
weekdays	Monday thru Friday
weekend	Saturday and Sunday
stime	Starting time
to	Ending day and time
etime	Ending time

Command Mode

- /exec/configure/timerange

periodic to

```
{ [ <seqno> ] | no } periodic { Monday | Tuesday | Wednesday | Thursday | Friday | Saturday | Sunday }
<stime> to { <eday> } <etime>
```

Syntax Description

seqno	(Optional) Sequence number
no	Negate a command or set its defaults
periodic	Periodic time and date
Monday	Monday
Tuesday	Tuesday
Wednesday	Wednesday
Thursday	Thursday
Friday	Friday
Saturday	Saturday
Sunday	Sunday
eday	Day of the week
stime	Starting time
to	Ending day and time
etime	Ending time

Command Mode

- /exec/configure/timerange

permitdeny

```
<seqno> <permitdeny> <mpls> { <label1_any> | { <label1> [ mask <label1_mask> ] } } [ <label2_any> | {
<label2> [ mask <label2_mask> ] } ] [ <label3_any> | { <label3> [ mask <label3_mask> ] } ] [ <label4_any>
| { <label4> [ mask <label4_mask> ] } ] { <mplsaction> <mplsactionid> }
```

Syntax Description

seqno	Sequence number
permitdeny	Permit/deny
mask	(Optional) mask
label1	mpls label one
label2	(Optional) mpls label two
label3	(Optional) mpls label three
label4	(Optional) mpls label four
label1_mask	(Optional) mpls label one mask
label2_mask	(Optional) mpls label two mask
label3_mask	(Optional) mpls label three mask
label4_mask	(Optional) mpls label four mask
label1_any	label one Any
label2_any	(Optional) label two Any
label3_any	(Optional) label three Any
label4_any	(Optional) label four Any
mpls	mpls keyword
mplsaction	mpls ACL Action
mplsactionid	redirect: Ethernet1/1,port-channel1 set-erspan-dscp: <1-63> set-erspan-gre-proto: <1-65535>

Command Mode

- /exec/configure/mplsac1

permit interface

[no] permit interface <if0>

Syntax Description

no	(Optional) Negate a command or set its defaults
permit	Permit access to interfaces (applicable if interface policy is 'deny')
interface	Enter the range of interfaces accessible the role
if0	Enter the interface range

Command Mode

- /exec/configure/role/interface

permit vlan

[no] permit vlan <vlan-mrange>

Syntax Description

no	(Optional) Negate a command or set its defaults
permit	Permit access to vlans (applicable if vlan policy is 'deny')
vlan	Enter the range of vlans accessible the role
vlan-mrange	Enter the vlan range

Command Mode

- /exec/configure/role/vlan

permit vrf

[no] permit vrf <vrf-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
permit	Permit access to vrf (applicable if vrf policy is 'deny')
vrf	Enter the range of vrf accessible the role
vrf-name	Enter the vrf name

Command Mode

- /exec/configure/role/vrf

permit vsan

[no] permit vsan <vsan-mrange>

Syntax Description

no	(Optional) Negate a command or set its defaults
permit	Permit access to vsans (applicable if vsan policy is 'deny')
vsan	Enter the range of vsans accessible the role
vsan-mrange	Enter the vsan range

Command Mode

- /exec/configure/role/vsan

personality

[no] personality

Syntax Description

no	(Optional) Negate a mode
personality	Config Personality

Command Mode

- /exec/configure

personality backup

```
personality backup { <uri_local> | <uri_remote> [ password <password> ] [ vrf <vrf-known-name> ] }
```

Syntax Description

personality	personality
backup	backup personality
password	(Optional) The password for personality backups
vrf	(Optional) The VRF for personality backups
uri_local	Personality backup local destination
uri_remote	Personality backup remote destination
password	(Optional) Password for SCP username
vrf-known-name	(Optional) VRF name

Command Mode

- /exec

personality restore

personality restore <uri> [user-name <user>] [password <password>] [hostname <hostname>] [vrf <vrf_name>]

Syntax Description

personality	Personality
restore	Restore the personality file
uri	Personality file
user-name	(Optional) The username for downloads
user	(Optional) The username
password	(Optional) The password for downloads
password	(Optional) The password
hostname	(Optional) The hostname for downloads
hostname	(Optional) The hostname
vrf	(Optional) The VRF for downloads
vrf_name	(Optional) The VRF name

Command Mode

- /exec

phone-contact

{ phone-contact <s0> | no phone-contact }

Syntax Description

no	Negate a command or set its defaults
phone-contact	Contact person's phone number
s0	Phone number in international format(such as +1-800-123-4567)

Command Mode

- /exec/configure/callhome

pim

[no] pim

Syntax Description

no	(Optional) Negate a command or set its defaults
pim	Policies for a Remote Receiver

Command Mode

- /exec/configure/nbm-vrf/nbm-host-policy

pim

[no] pim

Syntax Description

no	(Optional) Negate a command or set its defaults
pim	Policies for a Remote Receiver

Command Mode

- /exec/configure/nbm-host-policy

ping

```
ping [ { { <alpha> | <numeric> [ loopback interface <interface> ] } | { multicast <group> interface <interface>
[ loopback ] } } [ [ source-interface <src-intf> | vrf { <vrf-name> | <vrf-known-name> } ] [ count { <count>
| unlimited } | packet-size <packetsize> | vrf { <vrf-name> | <vrf-known-name> } | interval <interval> | source
{ <alpha> | <numeric1> } | df-bit | timeout <timeout> } + [ [ count { <count> | unlimited } | packet-size
<packetsize> | source-interface <src-intf> | interval <interval> | df-bit | timeout <timeout> } + ] ]
```

Syntax Description

ping	Test
count	(Optional) Number
unlimited	(Optional) Unlimited
count	(Optional) Number
packet-size	(Optional) Packet
packetsize	(Optional) Size
source-interface	(Optional) Select source interface
src-intf	(Optional) Specify interface
interval	(Optional) Wait
interval	(Optional) Interval
numeric	(Optional) IP address of remote system
numeric1	(Optional) IP
alpha	(Optional) Enter
multicast	(Optional) Multicast
group	(Optional) Multicast
interface	(Optional) Interface
interface	(Optional) Interface
loopback	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
source	(Optional) Source
df-bit	(Optional) Enable
timeout	(Optional) Specify
timeout	(Optional) Timeout
vrf	(Optional) Display per-VRF information

vrf-name	(Optional) VRF name
vrf-known-name	(Optional) Known VRF name

Command Mode

- /exec

ping6

```
ping6 { { <host> | <hostname> } | { multicast <group> } } [ [ { count { <count> | unlimited } } | { packet-size <packet-size> } ] | [ source { <host1> | <hostname> } ] | vrf { <vrf-name> | <vrf-known-name> } | timeout <timeout> | { interval <interval> } ] + | [ { count { <count> | unlimited } } | { packet-size <packet-size> } ] | { source-interface <src-intf> } | timeout <timeout> | { interval <interval> } ] + ]
```

Syntax Description

ping6	Test
count	(Optional) Number
count	(Optional) Number
unlimited	(Optional) unlimited
packet-size	(Optional) Packet
packetsize	(Optional) Size
source-interface	(Optional) Select source interface
src-intf	(Optional) Specify interface
interval	(Optional) Wait
interval	(Optional) Interval
hostname	Enter
multicast	Multicast
vrf	(Optional) Display per-VRF information
vrf-name	(Optional) VRF name
vrf-known-name	(Optional) Known VRF name
source	(Optional) Source
timeout	(Optional) Specify
timeout	(Optional) Timeout

Command Mode

- /exec

ping mpls

```
ping mpls { nil-fec { { labels <comma-separated-labels> } } output { ointerface <tx-interface> } nexthop
<nexthop-ip-addr> } | { policy { { name <srte-policy-name> } | { endpoint <srte-policy-endpoint> color
<srte-policy-color> } } [ { output { ointerface <tx-interface> } [ nexthop <nexthop-ip-addr> ] ] } } } [ {
repeat <count> } | { { size <size> } | { sweep <min-size> <max-size> <increment> } } | { timeout <seconds>
} | { interval <milliseconds> } | { destination <addr-start> [ <addr-end> [ <addr-incr-mask> | <addr-incr> ] ]
} | { source <addr> } | { exp <exp-value> } | { pad <pattern> } | { ttl <ttl> } | { verbose } | { reply { { mode
{ <reply-mode-ipv4> | router-alert | control-channel | no-reply } } | { dscp { <dscp-bits> | af11 | af12 | af13 |
af21 | af22 | af23 | af31 | af32 | af33 | af41 | af42 | af43 | cs1 | cs2 | cs3 | cs4 | cs5 | cs6 | cs7 | default | ef } } | {
pad-tlv } } } + | { force-explicit-null } | { dsmap [ hashkey { none | { hash-ipv4 { bitmap <bitmap-size> } }
} ] } | { flags { fec } } ] +
```

Syntax Description

ping	need
mpls	Test
nil-fec	Target
labels	A
comma-separated-labels	A
repeat	(Optional) Repeat
count	(Optional) Repeat
size	(Optional) Packet
size	(Optional) Datagram
sweep	(Optional) Sweep
min-size	(Optional)
max-size	(Optional)
increment	(Optional) Sweep
timeout	(Optional) Timeout
seconds	(Optional) Timeout
interval	(Optional) Send
milliseconds	(Optional) Send
destination	(Optional) Destination
addr-start	(Optional) Destination
addr-end	(Optional) Destination

addr-incr-mask	(Optional) Destination
addr-incr	(Optional) Destination
source	(Optional) Source
addr	(Optional) Source
exp	(Optional) EXP
exp-value	(Optional) EXP
pad	(Optional) Pad
pattern	(Optional) Pad
ttl	(Optional) Time
ttl	(Optional) TTL
verbose	(Optional) verbose
reply	(Optional) Reply
mode	(Optional) Reply
reply-mode-ipv4	(Optional) Send
router-alert	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
control-channel	(Optional) Send
no-reply	(Optional) Send
dscp	(Optional) DSCP
dscp-bits	(Optional) Differentiated
af11	(Optional) Match
af12	(Optional) Match
af13	(Optional) Match
af21	(Optional) Match
af22	(Optional) Match
af23	(Optional) Match
af31	(Optional) Match
af32	(Optional) Match
af33	(Optional) Match
af41	(Optional) Match

af42	(Optional) Match
af43	(Optional) Match
cs1	(Optional) Match
cs2	(Optional) Match
cs3	(Optional) Match
cs4	(Optional) Match
cs5	(Optional) Match
cs6	(Optional) Match
cs7	(Optional) Match
default	(Optional) Match
ef	(Optional) Match
pad-tlv	(Optional) Reply
force-explicit-null	(Optional) Force
output	Output
ointerface	Echo
tx-interface	Echo
nexthop	Next
nexthop-ip-addr	Next
dsmap	(Optional) Request
hashkey	(Optional) Downstream
none	(Optional) Hash
hash-ipv4	(Optional) IPv4
bitmap	(Optional) Hash
bitmap-size	(Optional) Multipath
flags	(Optional) Flag
fec	(Optional) Request
policy	Derive
name	Specify
color	Specify

endpoint	Specify
srte-policy-name	The
srte-policy-color	The
srte-policy-endpoint	The

Command Mode

- /exec

ping nve

```
ping nve { { { { ip { <numeric10> | <numeric11> | unknown } } [ vrf { <vrf-name> | <vrf-known-name>
} ] { <dot1qid1> } ] } | mac <dmac> <dot1qid> [ <intfid> ] } [ profile <pid> ] } [ payload { [ mac-addr
<dstmac> <smac> ] [ dot1q <dot1q-id> ] [ ip <dstip> <srcip> | ipv6 <dstipv6> <srcipv6> ] [ port <sport>
<dport> ] [ proto <proto-id> ] [ src-intf <src_if> ] } payload-end ] [ source { <numeric1> | <numeric2> } |
```

Syntax Description

{	<count>
ping	Test
nve	network virtualization edge
numeric10	Ipv4 address of remote host / VTEP
unknown	Peer vtep ip is unknown, Applicable only for channel Nv03
dot1qid	Encapsulation dot1q/bd on which the mac is learnt
intfid	(Optional) Name of the interface for ngoam ping on which dot1q is configured
payload	(Optional) Enter customer payload
port	(Optional) L4 port info
sport	(Optional) Source port
dport	(Optional) Destination port
proto	(Optional) Protocol
proto-id	(Optional) IANA Protocol id
src-intf	(Optional) Interface on which the host with src ip of the payload is connected
src_if	(Optional) Interface
payload-end	(Optional) End of payload info
profile	(Optional) NGOAM profile to use
pid	(Optional) NGOAM profile id
mac	Mac
mac-addr	(Optional) Mac
ip	ip address
dstip	(Optional) Destination ipv4 address

srcip	(Optional) source ipv4 address
ipv6	(Optional) ipv6 address
dmac	Destination mac address
dstmac	(Optional) Destination mac address
smac	(Optional) Source mac address
dot1q	(Optional) Encapsulation dot1q/bd
dot1q-id	(Optional) Encapsulation dot1q/bd on which the mac is learnt
dot1qid1	(Optional) Encapsulation dot1q/bd on which the mac is learnt
vrf	(Optional) Display per-VRF information
vrf-name	(Optional) VRF name
vrf-known-name	(Optional) Known VRF name
source	(Optional) Source
numeric1	(Optional) IP

Command Mode

- /exec

ping sr-mpls

```
ping sr-mpls { <sr-ipv4-prefix> fec-type { { igp isis } | { bgp } | { generic } } } [ { repeat <count> } | { size
<size> } | { sweep <min-size> <max-size> <increment> } } | { timeout <seconds> } | { interval <milliseconds>
} | { destination <addr-start> [ <addr-end> [ <addr-incr-mask> | <addr-incr> ] ] } | { source <addr> } | { exp
<exp-value> } | { pad <pattern> } | { ttl <ttl> } | { verbose } | { reply { { mode { <reply-mode-ipv4> |
router-alert | control-channel | no-reply } } | { dscp { <dscp-bits> | af11 | af12 | af13 | af21 | af22 | af23 | af31
| af32 | af33 | af41 | af42 | af43 | cs1 | cs2 | cs3 | cs4 | cs5 | cs6 | cs7 | default | ef } } | { pad-tlv } } } + | {
force-explicit-null } | { dsmap [ hashkey { none | { hash-ipv4 { bitmap <bitmap-size> } } } ] } | { flags { fec
} } ] +
```

Syntax Description

ping	need
sr-mpls	Test
sr-ipv4-prefix	IP
fec-type	Type
igp	Kind
isis	ISIS
bgp	BGP
generic	Generic
repeat	(Optional) Repeat
count	(Optional) Repeat
size	(Optional) Packet
size	(Optional) Datagram
sweep	(Optional) Sweep
min-size	(Optional)
max-size	(Optional)
increment	(Optional) Sweep
timeout	(Optional) Timeout
seconds	(Optional) Timeout
interval	(Optional) Send
milliseconds	(Optional) Send
destination	(Optional) Destination

addr-start	(Optional) Destination
addr-end	(Optional) Destination
addr-incr-mask	(Optional) Destination
addr-incr	(Optional) Destination
source	(Optional) Source
addr	(Optional) Source
exp	(Optional) EXP
exp-value	(Optional) EXP
pad	(Optional) Pad
pattern	(Optional) Pad
ttl	(Optional) Time
ttl	(Optional) TTL
verbose	(Optional) verbose
reply	(Optional) Reply
mode	(Optional) Reply
reply-mode-ipv4	(Optional) Send
router-alert	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
control-channel	(Optional) Send
no-reply	(Optional) Send
dscp	(Optional) DSCP
dscp-bits	(Optional) Differentiated
af11	(Optional) Match
af12	(Optional) Match
af13	(Optional) Match
af21	(Optional) Match
af22	(Optional) Match
af23	(Optional) Match
af31	(Optional) Match
af32	(Optional) Match

af33	(Optional) Match
af41	(Optional) Match
af42	(Optional) Match
af43	(Optional) Match
cs1	(Optional) Match
cs2	(Optional) Match
cs3	(Optional) Match
cs4	(Optional) Match
cs5	(Optional) Match
cs6	(Optional) Match
cs7	(Optional) Match
default	(Optional) Match
ef	(Optional) Match
pad-tlv	(Optional) Reply
force-explicit-null	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
dsmap	(Optional) Request
hashkey	(Optional) Downstream
none	(Optional) Hash
hash-ipv4	(Optional) IPv4
bitmap	(Optional) Hash
bitmap-size	(Optional) Multipath
flags	(Optional) Flag
fec	(Optional) Request

Command Mode

- /exec

platform rate-limiter span-egress

```
{ platform | hardware } rate-limiter span-egress <rate> [ module <module> ] | no { platform | hardware }
rate-limiter span-egress [ <rate> ] [ module <module> ]
```

Syntax Description

no	Negate a command or set its defaults
platform	Platform configuration commands
hardware	Hardware Internal Information
rate-limiter	Configure Rate-Limiter for packets forwarded
span-egress	SPAN/ERSPAN egress packets
rate	value in kbit per sec
module	(Optional) Specify a module number
module	(Optional) Specify a module number

Command Mode

- /exec/configure

plb

[no] plb [<svc-name>] [service <service-name>]

Syntax Description

no	(Optional) Negate a command or set its defaults
plb	Configure PLB
svc-name	(Optional) Specify PLB service name [Deprecated]
service	(Optional) Configure PLB service [Preferred]
service-name	(Optional) Specify PLB service name

Command Mode

- /exec/configure

plb analytics

[no] plb analytics <service-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
plb	Configure PLB
analytics	Enable PLB service analytics
service-name	PLB service name

Command Mode

- /exec/configure

plb device-group

[no] plb device-group <group-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
plb	Configure PLB
device-group	Configure PLB device group
group-name	Specify device-group name

Command Mode

- /exec/configure

pnp startup-vlan

[no] pnp startup-vlan <vlan>

Syntax Description

no	(Optional) disable pnp startup vlan configured. default value is vlan 1
pnp	plug and play
startup-vlan	PnP startup-vlan
vlan	PNP vlan id. Default vlan is 1

Command Mode

- /exec/configure

police

```
[no] police [ { { [ cir ] { <cir-val> [ <opt_kbps_mbps_gbps_pps_cir> ] | percent <cir-perc> } } { [ [ bc ]
<bc-val> [ <opt_kbytes_mbytes_gbytes_bc> ] ] } } { [ { pir { <pir> [ <opt_kbps_mbps_gbps_pps_pir> ] |
percent1 <pir-perc> } } [ [ be ] <be-val> [ <opt_kbytes_mbytes_gbytes_be> ] ] ] } } { { conform {
<opt_drop_transmit_conform> | { set-cos-transmit <set-cos-val> } | { set-dscp-transmit { <set-dscp-val> |
<opt_set_dscp> } } | { set-prec-transmit { <set-prec-val> | <opt_set_prec> } } } } [ { exceed {
<opt_drop_transmit_exceed> | { set dscp1 dscp2 table cir-markdown-map } } } ] [ { violate {
<opt_drop_transmit_violate> | { set1 dscp3 dscp4 table1 pir-markdown-map } } } ] ] ] ] }
```

Syntax Description

no	Negate a command or set its defaults
police	Police
cir	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
opt_kbps_mbps_gbps_pps_cir	(Optional) Units
percent	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
pir	(Optional) Specify peak information rate
opt_kbps_mbps_gbps_pps_pir	(Optional) Units
percent1	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
be	(Optional) Specify extended burst
opt_kbytes_mbytes_gbytes_be	(Optional) Units
bc	(Optional) Specify committed burst
opt_kbytes_mbytes_gbytes_bc	(Optional) Units
conform	(Optional) Specify a conform action
opt_drop_transmit_conform	(Optional) Set the action
set-cos-transmit	(Optional) Set conform action cos val
set-cos-val	(Optional) 802.1Q Class of Service value
set-dscp-transmit	(Optional) Set conform action dscp val
set-dscp-val	(Optional) DSCP value
opt_set_dscp	(Optional)
set-prec-transmit	(Optional) Set conform action precedence val
set-prec-val	(Optional) IP Precedence value
opt_set_prec	(Optional)

exceed	(Optional) Specify a exceed action
opt_drop_transmit_exceed	(Optional) Set the action
set	(Optional) Set exceed action to cir-markdown-map
dscp1	(Optional) Exceed from field
dscp2	(Optional) Exceed to field
table	(Optional) To specify table name
cir-markdown-map	(Optional) Well known markdown map
violate	(Optional) Specify a violate action
opt_drop_transmit_violate	(Optional) Set the action
set1	(Optional) Set violate action to pir-markdown-map
dscp3	(Optional) Violate from field
dscp4	(Optional) Violate to field
table1	(Optional) To specify table name
pir-markdown-map	(Optional) Well known markdown map

Command Mode

- /exec/configure/pmap/class

police

```
[no] police { { [ cir ] { <cir-val> [ bps | kbps | mbps | gbps ] | percent <cir-perc> } [ [ bc ] { <committed-burst>
[ bytes | kbytes | mbytes | ms | us ] } ] [ pir { <pir-val> [ bps2 | kbps2 | mbps2 | gbps2 | pps2 ] | percent <pir-perc>
} [ [ be ] { <extended-burst> [ bytes2 | kbytes2 | mbytes2 | ms2 | us2 | packets2 ] } ] ] [ conform { transmit |
set-prec-transmit { <prec-val> | <prec-enum> } | set-dscp-transmit { <dscp-val> | <dscp-enum> } |
set-cos-transmit <cos-val> | set-discard-class-transmit <disc-class-val> | set-qos-transmit <qos-grp-val> |
set-mpls-exp-imposition-transmit <exp-value-imp> | set-mpls-exp-topmost-transmit <exp-value-top> } [
exceed { drop1 | set <exc-frm-field> <exc-to-field> table cir-markdown-map | set-prec-transmit1 { <prec-val1>
| <prec-enum1> } | set-dscp-transmit1 { <dscp-val1> | <dscp-enum1> } | set-cos-transmit1 <cos-val1> |
set-discard-class-transmit1 <disc-class-val1> | set-qos-transmit1 <qos-grp-val1> |
set-mpls-exp-imposition-transmit1 <exp-value-imp1> | set-mpls-exp-topmost-transmit1 <exp-value-top1> }
] [ violate { drop2 | set <vio-frm-field> <vio-to-field> table2 pir-markdown-map | set-prec-transmit2 {
<prec-val2> | <prec-enum2> } | set-dscp-transmit2 { <dscp-val2> | <dscp-enum2> } | set-cos-transmit2
<cos-val2> | set-discard-class-transmit2 <disc-class-val2> | set-qos-transmit2 <qos-grp-val2> |
set-mpls-exp-imposition-transmit2 <exp-value-imp2> | set-mpls-exp-topmost-transmit2 <exp-value-top2> }
] ] } | aggregate <policer-name> }
```

Syntax Description

no	(Optional) Negate a command or set its defaults
police	police
cir	(Optional) Specify committed information rate
bc	(Optional) Specify committed burst
percent	Specify rate as percentage of interface data-rate
cir-perc	Percentage
pir-perc	(Optional) Percentage
pir	(Optional) Specify peak information rate
be	(Optional) Specify extended burst (for 1R3C meter)
bps	(Optional) Bits per second
kbps	(Optional) Kilo bits per second
mbps	(Optional) Mega bits per second
gbps	(Optional) Giga bits per second
bps2	(Optional) Bits per second
kbps2	(Optional) Kilo Bits per second
mbps2	(Optional) Mega Bits per second
gbps2	(Optional) Giga Bits per second

pps2	(Optional) Packets per second
bytes	(Optional) Bytes
kbytes	(Optional) Kilo bytes
mbytes	(Optional) Mega bytes
us	(Optional) Micro second(s)
ms	(Optional) Milli second(s)
bytes2	(Optional) Bytes
kbytes2	(Optional) Kilo Bytes
mbytes2	(Optional) Mega Bytes
ms2	(Optional) Milli seconds
us2	(Optional) Micro seconds
packets2	(Optional) Packets
conform	(Optional) Specify a conform action
exceed	(Optional) Specify a exceed action
violate	(Optional) Specify a violate action
transmit	(Optional) Transmit packet
drop1	(Optional) Drop packet
drop2	(Optional) Drop packet
set-prec-transmit	(Optional) Set precedence and send it
set-prec-transmit1	(Optional) Set precedence and send it
set-prec-transmit2	(Optional) Set precedence and send it
prec-val	(Optional) Precedence value
prec-val1	(Optional) Precedence value
prec-val2	(Optional) Precedence value
prec-enum	(Optional)
prec-enum1	(Optional)
prec-enum2	(Optional)
set-dscp-transmit	(Optional) Set dscp and send it
set-dscp-transmit1	(Optional) Set dscp and send it

set-dscp-transmit2	(Optional) Set dscp and send it
dscp-val	(Optional) DSCP value
dscp-val1	(Optional) DSCP value
dscp-val2	(Optional) DSCP value
dscp-enum	(Optional)
dscp-enum1	(Optional)
dscp-enum2	(Optional)
set-cos-transmit	(Optional) Set cos and send it
set-cos-transmit1	(Optional) Set cos and send it
set-cos-transmit2	(Optional) Set cos and send it
cos-val	(Optional) new cos value
cos-val1	(Optional) new cos value
cos-val2	(Optional) new cos value
set-discard-class-transmit	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
set-discard-class-transmit1	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
set-discard-class-transmit2	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
disc-class-val	(Optional) new discard-class value
disc-class-val1	(Optional) new discard-class value
disc-class-val2	(Optional) new discard-class value
set-qos-transmit	(Optional) Set qos-group and send it
set-qos-transmit1	(Optional) Set qos-group and send it
set-qos-transmit2	(Optional) Set qos-group and send it
qos-grp-val	(Optional) QoS group value
qos-grp-val1	(Optional) QoS group value
qos-grp-val2	(Optional) QoS group value
set-mpls-exp-imposition-transmit	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
set-mpls-exp-imposition-transmit1	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
set-mpls-exp-imposition-transmit2	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
exp-value-imp	(Optional) MPLS imposition value

exp-value-imp1	(Optional) MPLS imposition value
exp-value-imp2	(Optional) MPLS imposition value
set-mpls-exp-topmost-transmit	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
set-mpls-exp-topmost-transmit1	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
set-mpls-exp-topmost-transmit2	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
exp-value-top	(Optional) MPLS topmost value
exp-value-top1	(Optional) MPLS topmost value
exp-value-top2	(Optional) MPLS topmost value
set	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
exc-frn-field	(Optional)
exc-to-field	(Optional)
vio-frn-field	(Optional)
vio-to-field	(Optional)
table	(Optional) Set using the table-map
table2	(Optional) Set using the table-map
cir-markdown-map	(Optional) Markdown map table name for exceed action
pir-markdown-map	(Optional) Markdown map table name for violate action
aggregate	Choose aggregate policer for current class
policer-name	Enter aggregate-policer name

Command Mode

- /exec/configure/policy-map/class

policer

[no] policer

Syntax Description

no	(Optional) Negate a command or set its defaults
policer	Flow rate limiter installed in hardware

Command Mode

- /exec/configure/nbm-vrf/nbm-flow-policy/attr

policer

[no] policer

Syntax Description

no	(Optional) Negate a command or set its defaults
policer	Flow rate limiter installed in hardware

Command Mode

- /exec/configure/nbm-flow-policy/attr

policy-map

[no] policy-map [type qos] [match-first] <pmap-name-qos>

Syntax Description

no	(Optional) Negate a command or set its defaults
policy-map	Configure a policy map
type	(Optional) Specify the type of this policy-map
qos	(Optional) Qos policy
match-first	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
pmap-name-qos	Policy-map name (alphanumeric)

Command Mode

- /exec/configure

policy-map type control-plane

[no] policy-map type control-plane <pmap-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
policy-map	Configure a policy map
type	Specify the type of this policy-map
control-plane	Control-Plane
pmap-name	Policy-map name (alphanumeric)

Command Mode

- /exec/configure

policy-map type network-qos

[no] policy-map type network-qos <pmap-name-nq>

Syntax Description

no	(Optional) Negate a command or set its defaults
policy-map	Configure a policy map
type	Specify the type of this policy-map
network-qos	Network QoS policy
pmap-name-nq	Policy-map name

Command Mode

- /exec/configure

policy-map type queuing

[no] policy-map type queuing [match-first] <pmap-name-que>

Syntax Description

no	(Optional) Negate a command or set its defaults
policy-map	Configure a policy map
type	Specify the type of this policy-map
queuing	Queuing policy
match-first	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
pmap-name-que	Policy-map name (alphanumeric)

Command Mode

- /exec/configure

policy

[no] policy { <cfg-pol-name> | <unknown-pol-name> }

Syntax Description

no	(Optional) Negate a command or set its defaults
policy	NBM Flow policy
cfg-pol-name	Policy name
unknown-pol-name	Policy name

Command Mode

- /exec/configure/nbm-flow-policy

policy

policy { { dynamic identity <device-id> } | { static sgt <sgt> [trusted] } } | no policy static | no policy dynamic

Syntax Description

policy	Enable and define policy to be applied
dynamic	apply to authorization server for policy
identity	specify identity of peer for authorization request
device-id	peer's device-id
static	configure static policy
sgt	SGT tag for pkts from this device
sgt	sgt value
trusted	(Optional) specify trust state of the link

Command Mode

- /exec/configure/cts-manual

policy

[no] policy <pol-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
policy	Identifying name for policy with max 128 characters
pol-name	Configure Policy name

Command Mode

- /exec/configure/sr/te

policy

[no] policy { <cfg-pol-name> | <unknown-pol-name> }

Syntax Description

no	(Optional) Negate a command or set its defaults
policy	NBM Flow policy
cfg-pol-name	Policy name
unknown-pol-name	Policy name

Command Mode

- /exec/configure/nbm-vrf/nbm-flow-policy

pop

pop [<name>]

Syntax Description

pop	pop mode from stack or restore from name
name	(Optional) name

Command Mode

- /global

port-channel fast-convergence

port-channel fast-convergence | no port-channel fast-convergence

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure port channel parameters
fast-convergence	Enable/Disable port-channel fast convergence

Command Mode

- /exec/configure

port-channel hash-distribution

port-channel hash-distribution <type> | no port-channel hash-distribution [<type>]

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure port channel parameters
hash-distribution	Configure port-channel hash-distribution
type	adaptive/fixed (default adaptive)

Command Mode

- /exec/configure/

port-channel limit

port-channel limit | no port-channel limit

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure the maximum number of supported vPCs
limit	limit to 244 vPCs

Command Mode

- /exec/configure/vpc-domain

port-channel load-balance1 ethernet

port-channel load-balance1 ethernet <algorithm> [symmetric] | no port-channel load-balance1 ethernet [<algorithm> [symmetric]]

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure port channel parameters
load-balance1	Configure port-channel load balance
ethernet	Ethernet port-channel
algorithm	Configure port-channel load balance
symmetric	(Optional) symmetric load balancing

Command Mode

- /exec/configure

port-channel load-balance2 resilient

port-channel load-balance2 resilient | no port-channel load-balance2 resilient

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure port channel parameters
load-balance2	Configure port-channel load balance
resilient	Configure port-channel load balance resilient mode

Command Mode

- /exec/configure

port-channel load-defer

port-channel load-defer <load-defer-timeout> | no port-channel load-defer [<load-defer-timeout>]

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure port channel parameters
load-defer	Load defer time interval
load-defer-timeout	Load defer time interval in seconds (default 120 seconds)

Command Mode

- /exec/configure/

port-channel port hash-distribution

port-channel port hash-distribution <type> | no port-channel port hash-distribution [<type>]

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure port channel parameters
port	Configure port-channel port hash-distribution
hash-distribution	Configure port-channel port hash-distribution
type	adaptive/fixed (default adaptive)

Command Mode

- /exec/configure/if-eth-port-channel-switch /exec/configure/if-eth-port-channel /exec/configure/if-eth-port-channel-p2p

port-channel port load-defer

port-channel port load-defer | no port-channel port load-defer

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure port channel parameters
port	Configure port-channel load-defer for member ports
load-defer	Configure port-channel load-defer

Command Mode

- /exec/configure/if-eth-port-channel-switch /exec/configure/if-eth-port-channel /exec/configure/if-eth-port-channel-p2p

port-channel scale-fanout

port-channel scale-fanout | no port-channel scale-fanout

Syntax Description

no	Negate a command or set its defaults
port-channel	Configure port channel parameters
scale-fanout	Enable/disable port-channel scale-fanout when ports span more than 16 ASIC units

Command Mode

- /exec/configure

port-group

{ port-group <name> } | { no port-group <name> }

Syntax Description

no	Negate a command or set its defaults
port-group	smart channel port group
name	smart channel port group name

Command Mode

- /exec/configure/smartc

port-license

[no] port-license [acquire]

Syntax Description

no	(Optional) Negate a command or set its defaults
port-license	Enable port activation license
acquire	(Optional) Acquire port activation license

Command Mode

- /exec/configure/if-fc /exec/configure/if-bay /exec/configure/if-ext

port-license

[no] port-license [acquire]

Syntax Description

no	(Optional) Negate a command or set its defaults
port-license	Enable port activation license
acquire	(Optional) Acquire port activation license

Command Mode

- /exec/configure/if-fc /exec/configure/if-bay /exec/configure/if-ext

port-profile

[no] port-profile [type <typeval>] { <profilename> | <s0> }

Syntax Description

no	(Optional) Negate a command or set its defaults
port-profile	Configure a port-profile
profilename	Enter the name of the profile
s0	Enter the name of the profile
type	(Optional) configure type of the profile
typeval	(Optional)

Command Mode

- /exec/configure

port-type

[no] port-type <type>

Syntax Description

no	(Optional) Negate a command or set its defaults
port-type	Identifies if port is fabric-facing or not
type	Facing port-type

Command Mode

- /exec/configure/if-eth-non-member /exec/configure/if-port-channel /exec/configure/if-ethernet-all /exec/configure/if-ethernet-p2p /exec/configure/if-ether-sub-p2p

port

```
{ port <sport> <dport> }
```

Syntax Description

port	L4 port info
sport	Source port
dport	Destination port

Command Mode

- /exec/configure/configngoamccpayload

port

{ no port | port <value> }

Syntax Description

no	
port	Port on which to listen
value	Max port value

Command Mode

- /exec/configure/config-twamp-srvr

port

{ { [no] port <i0> } | { no port } }

Syntax Description

no	(Optional) Negate a command or set its defaults
port	Specify port on which local radius server listens
i0	Radius server port (default is 1700)

Command Mode

- /exec/configure/locsvr-da-radius

port control

[no] port control <port-control-name>

Syntax Description

no	(Optional) Negate a command or set its defaults
port	Configure PLB port control
control	control
port-control-name	Port control name

Command Mode

- /exec/configure/plb-inout

port destination

{ port { destination | source } <port> } | { no port { destination | source } }

Syntax Description

no	Negate a command or set its defaults
port	specify flow port address
source	specify flow source port address
destination	specify flow destination port address
port	port number

Command Mode

- /exec/configure/configngoamprofileflow

port type ethernet

[no] port <port-range> type { ethernet | fc }

Syntax Description

no	(Optional) Negate a command or set its defaults
port	Configure a port
port-range	Enter a port range
type	Configure a port type
ethernet	Ethernet Port
fc	FC Port

Command Mode

- /exec/configure/slot

postcard-telemetry exporter

[no] postcard-telemetry exporter <exportername>

Syntax Description

postcard-telemetry	Enable/Disable postcard telemetry configuration
exporter	Define a events Exporter
exportername	Name of event Exporter

Command Mode

- /exec/configure/config-postcard

postcard-telemetry flow-profile

[no] postcard-telemetry flow-profile

Syntax Description

postcard-telemetry	Enable/Disable postcard telemetry configuration
flow-profile	Define a POSTCARD flow-profile

Command Mode

- /exec/configure/config-postcard

postcard-telemetry monitor

[no] postcard-telemetry monitor <monitorname>

Syntax Description

postcard-telemetry	Enable/Disable postcard telemetry configuration
monitor	Define a POSTCARD Monitor
monitorname	Name of POSTCARD Monitor

Command Mode

- /exec/configure/config-postcard

postcard-telemetry queue-profile

[no] postcard-telemetry queue-profile [<queue_profilename> | queue-profile-default]

Syntax Description

postcard-telemetry	Enable/Disable postcard telemetry configuration
queue-profile	Define a POSTCARD queue_profile
queue_profilename	(Optional) Name of POSTCARD queue_profile
queue-profile-default	(Optional) Queue Profile Default Configuration

Command Mode

- /exec/configure/config-postcard

postcard-telemetry system monitor

[no] postcard-telemetry system monitor <monitorname>

Syntax Description

system	global config
postcard-telemetry	postcard global settings
monitor	postcard Monitor to be applied
monitorname	postcard Monitor to be applied

Command Mode

- /exec/configure/config-postcard

postcard-telemetry watchlist ip

[no] postcard-telemetry watchlist ip <watchlistname>

Syntax Description

postcard-telemetry	Enable/Disable postcard telemetry configuration
watchlist	Define a POSTCARD watchlist
ip	Configure POSTCARD IP watchlist
watchlistname	Name of POSTCARD watchlist

Command Mode

- /exec/configure/config-postcard

power efficient-ethernet auto

[no] power efficient-ethernet auto

Syntax Description

no	(Optional) Negate a command or set its defaults
power	Configure EEE for the port
efficient-ethernet	Configure Energy Efficient Ethernet (EEE)
auto	Auto negotiate EEE

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

power efficient-ethernet sleep threshold aggressive

[no] power efficient-ethernet sleep threshold aggressive

Syntax Description

no	(Optional) Negate a command or set its defaults
power	Configure EEE for the port
efficient-ethernet	Configure Energy Efficient Ethernet (EEE)
sleep	EEE LPI sleep configuration
threshold	EEE LPI sleep threshold
aggressive	Enable/ Disable EEE LPI aggressive sleep mode

Command Mode

- /exec/configure/if-ethernet-all /exec/configure/if-eth-base

power inline

```
{ power inline { <port-mode-never> | <port-mode> [ max <wattage> ] } } | { no power inline {
<port-mode-never> | <port-mode> } }
```

Syntax Description

no	Negate a command or set its defaults
power	Power over Ethernet
port-mode-never	configure POE port mode
port-mode	configure POE port mode
max	(Optional) Configure the max power per interface
wattage	(Optional) milli-watts

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

power inline default_consumption

{ power inline default_consumption <wattage> } | { no power inline default_consumption }

Syntax Description

no	Negate a command or set its defaults
power	Power over Ethernet
default_consumption	POE port default consumption
wattage	milli-watts

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

power inline police action

{ power inline police action <police-action> } | { no power inline police action }

Syntax Description

no	Negate a command or set its defaults
power	Power over Ethernet
police	Configure POE port police parameters
action	Configure action in port when power allocation exceeds
police-action	configure POE port action

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

power inline port priority

{ power inline port priority <port-priority> } | { no power inline port priority <port-priority> }

Syntax Description

no	Negate a command or set its defaults
power	Power over Ethernet
port	Configure POE port parameters
priority	Configure the priority for the port
port-priority	configure POE port priority

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

power redundancy-mode ps-redundant

[no] power redundancy-mode ps-redundant

Syntax Description

no	(Optional) Negate a command or set its defaults
power	Configure power supply
redundancy-mode	Configure power supply redundancy mode
ps-redundant	Configure power supply redundancy mode as PS redundant

Command Mode

- /exec/configure

precision milliseconds

{ { no | default } precision | precision { milliseconds | microseconds } }

Syntax Description

no	
precision	milliseconds
default	Set a command to its defaults
precision	Set precision of measurement
microseconds	Precision microseconds
milliseconds	Precision milliseconds

Command Mode

- /exec/configure/ip-sla/jitter

preempt

[no] preempt

Syntax Description

no	(Optional) Negate a command or set its defaults
preempt	Enable preemption of lower priority master

Command Mode

- /exec/configure/if-eth-any/vrrp

preempt

[no] preempt | preempt

Syntax Description

no	Negate a command or set its defaults
preempt	Enable preemption of lower priority Master

Command Mode

- /exec/configure/if-eth-any/vrrpv3

preempt delay minimum

[no] preempt delay | preempt delay minimum <secs>

Syntax Description

no	Negate a command or set its defaults
preempt	Enable preemption of lower priority Master
delay	Wait before preempting
minimum	Delay at least this long
secs	Seconds to delay

Command Mode

- /exec/configure/if-eth-any/vrrpv3

preempt delay minimum reload sync preempt delay reload minimum sync preempt delay sync minimum reload preempt delay reload sync minimum preempt
 delay sync reload minimum preempt delay minimum sync reload preempt delay reload sync preempt delay sync reload preempt delay minimum sync preempt
 delay sync minimum preempt delay minimum reload preempt delay reload minimum preempt delay minimum preempt delay reload preempt delay sync preempt

preempt delay minimum reload sync preempt delay reload minimum sync preempt delay sync minimum reload preempt delay reload sync minimum preempt delay sync reload minimum preempt delay minimum sync reload preempt delay reload sync preempt delay sync reload preempt delay minimum sync preempt delay sync minimum preempt delay minimum reload preempt delay reload minimum preempt delay minimum preempt delay reload preempt delay sync preempt

preempt delay minimum <min-delay> reload <rel-delay> sync <sync-delay> | preempt delay reload <rel-delay>
 minimum <min-delay> sync <sync-delay> | preempt delay sync <sync-delay> minimum <min-delay> reload
 <rel-delay> | preempt delay reload <rel-delay> sync <sync-delay> minimum <min-delay> | preempt delay
 sync <sync-delay> reload <rel-delay> minimum <min-delay> | preempt delay minimum <min-delay> sync
 <sync-delay> reload <rel-delay> | preempt delay reload <rel-delay> sync <sync-delay> | preempt delay sync
 <sync-delay> reload <rel-delay> | preempt delay minimum <min-delay> sync <sync-delay> | preempt delay
 sync <sync-delay> minimum <min-delay> | preempt delay minimum <min-delay> reload <rel-delay> | preempt
 delay reload <rel-delay> | preempt delay sync <sync-delay> | preempt | no preempt | { minimum
 [<min-delay>] [[reload [<rel-delay>]] [sync [<sync-delay>]]] [sync [<sync-delay>]] [reload [<rel-delay>]]] | reload [<rel-delay>] [[minimum [<min-delay>]] [sync [<sync-delay>]]] [sync [<sync-delay>]] [minimum [<min-delay>]]] | sync [<sync-delay>] [[reload [<rel-delay>]] [minimum [<min-delay>]]] [[minimum [<min-delay>]] [reload [<rel-delay>]]] } }

Syntax Description

no	Negate a command or set its defaults
preempt	Overthrow lower priority Active routers
delay	Wait before preempting
minimum	Delay at least this long
min-delay	Number of seconds for minimum delay
reload	Delay after reload
rel-delay	Number of seconds for reload delay
sync	Wait for IP redundancy clients
sync-delay	Number of seconds for sync delay

Command Mode

preempt delay minimum reload sync preempt delay reload minimum sync preempt delay sync minimum reload preempt delay reload sync minimum preempt
delay sync reload minimum preempt delay minimum sync reload preempt delay reload sync preempt delay sync reload preempt delay minimum sync preempt
delay sync minimum preempt delay minimum reload preempt delay reload minimum preempt delay minimum preempt delay reload preempt delay sync preempt

- /exec/configure/if-eth-any/hsrp_ipv4 /exec/configure/if-eth-any/hsrp_ipv6

preference

[no] preference <pref>

Syntax Description

no	(Optional) Negate a command or set its defaults
preference	Policy path-option preference entry
pref	Path-option preference

Command Mode

- /exec/configure/sr/te/pol/cndpaths

preference

[no] preference <pref>

Syntax Description

no	(Optional) Negate a command or set its defaults
preference	Candidate path-option preference entry
pref	Path-option preference

Command Mode

- /exec/configure/sr/te/color/cndpaths

preference max

[no] preference max <pref-val>

Syntax Description

no	(Optional) Negate a command or set its defaults
pref-val	maximum value

Command Mode

- /exec/configure/config-dhcp-guard

preference min

[no] preference min <pref-val>

Syntax Description

no	(Optional) Negate a command or set its defaults
pref-val	maximum value

Command Mode

- /exec/configure/config-dhcp-guard

prefix out

[no | default] { prefix-list <prfxlist-name> } { out | in }

Syntax Description

no	(Optional) Negate a command or set its defaults
default	(Optional) Inherit values from a peer template
prefix-list	Apply prefix-list
prfxlist-name	Name of prefix-list
out	Apply policy to outgoing routes
in	Apply policy to incoming routes

Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-vpnv4
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-mdt
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-vpnv6
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-l2vpn-vpls
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-mvpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv6-mvpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-l2vpn-evpn
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv4-label
- /exec/configure/router-bgp/router-bgp-neighbor/router-bgp-neighbor-af-ipv6-label

priority-flow-control auto-restore multiplier

[no] priority-flow-control auto-restore multiplier { <val> }

Syntax Description

no	(Optional) Negate the command
priority-flow-control	pfc related commands
auto-restore	auto restore
multiplier	Auto restore multiplier
val	Auto multiplier value

Command Mode

- /exec/configure

priority-flow-control fixed-restore multiplier

[no] priority-flow-control fixed-restore multiplier { <val> }

Syntax Description

no	(Optional) Negate the command
priority-flow-control	pfc related commands
fixed-restore	fixed restore
multiplier	Fixed restore multiplier
val	Fixed multiplier value

Command Mode

- /exec/configure

priority-flow-control mode

[no] priority-flow-control mode { auto | on [send-tlv] | off } [force]

Syntax Description

no	(Optional) Negate a command or set its defaults
priority-flow-control	Enable/Disable PFC
mode	PFC Mode
auto	Set Auto Mode
on	Force PFC to On
off	Force PFC to Off
force	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
send-tlv	(Optional) Send DCBX TLV for PFC config

Command Mode

- /exec/configure/if-switching /exec/configure/if-routing /exec/configure/if-port-channel /exec/configure/if-port-channel-sub

priority-flow-control override-interface mode off

[no] priority-flow-control override-interface mode off

Syntax Description

no	(Optional) Negate a command or set its defaults
priority-flow-control	Global priority-flow-control settings
override-interface	Overrides interface priority-flow-control mode
mode	Priority-flow-control mode
off	Off

Command Mode

- /exec/configure

priority-flow-control recover interface

priority-flow-control recover interface <if_list> [qos-group <qgrp-num>] [module <module_idx>] [instance <inst>]

Syntax Description

priority-flow-control	Change PFC settings
recover	Recover PFC queue from stuck state
interface	Interface
if_list	List of interfaces
qos-group	(Optional) No-drop class to be recovered
qgrp-num	(Optional) qos-group number of the no-drop class
module	(Optional) Slot/module
module_idx	(Optional) Slot/module number
instance	(Optional) ASIC Instance Number
inst	(Optional) ASIC Instance Number in Decimal

Command Mode

- /exec

priority-flow-control watch-dog-interval on

```
[no] priority-flow-control watch-dog-interval { on [ disable-action ] [ interface-multiplier <multiplier-val> ]
| off }
```

Syntax Description

no	(Optional) Negate a command or set its defaults
priority-flow-control	Enable/Disable PFC
watch-dog-interval	Watch dog interval
on	PFC watch-dog interval to On
disable-action	(Optional) Only generate syslog for stuck queue, no action
interface-multiplier	(Optional) Shutdown multiplier value
multiplier-val	(Optional) Shutdown mutlipler value
off	PFC watch-dog interval to Off

Command Mode

- /exec/configure/if-switching /exec/configure/if-routing /exec/configure/if-port-channel /exec/configure/if-port-channel-sub

priority-flow-control watch-dog-interval on

[no] priority-flow-control watch-dog-interval { on | off }

Syntax Description

no	(Optional) Negate the command
priority-flow-control	Enable/Disable PFC
watch-dog-interval	Watch dog interval
on	Enable PFC watch-dog interval globally
off	Disable PFC watch-dog interval globally

Command Mode

- /exec/configure

priority-flow-control watch-dog forced on

[no] priority-flow-control watch-dog forced { on | off }

Syntax Description

no	(Optional) Negate the command
priority-flow-control	pfc related commands
watch-dog	watch dog interval
forced	Force enable watch-dog behaviour globally
on	Enable PFC watch-dog globally
off	Disable PFC watch-dog globally

Command Mode

- /exec/configure

priority-flow-control watch-dog interval

[no] priority-flow-control watch-dog interval <interval-val>

Syntax Description

no	(Optional) Negate the command
priority-flow-control	pfm related commands
watch-dog	watch dog interval
interval	Poll interval
interval-val	Watch dog interval value in ms

Command Mode

- /exec/configure

priority-flow-control watch-dog shutdown-multiplier

[no] priority-flow-control watch-dog shutdown-multiplier { <val> }

Syntax Description

no	(Optional) Negate the command
priority-flow-control	pfc related commands
watch-dog	watch dog interval
shutdown-multiplier	Shutdown multiplier
val	Shutdown multiplier

Command Mode

- /exec/configure

priority

[no] priority | priority <val>

Syntax Description

no	Negate a command or set its defaults
priority	Priority of this VRRP group
val	Priority level

Command Mode

- /exec/configure/if-eth-any/vrrpv3

priority2

[no] priority2 [level2 <value>]

Syntax Description

no	(Optional) Negate a command or set its defaults
priority2	Configure traffic class priority
level2	(Optional) Specify level of priority
value	(Optional) Strict-priority level (1=hi 2=med 3=lo)

Command Mode

- /exec/configure/policy-map/type/queuing/class

priority

priority <priority> [forwarding-threshold lower <lower-value> upper <upper-value>] | no priority [forwarding-threshold]

Syntax Description

no	Negate a command or set its defaults
priority	Priority level
priority	Priority value
forwarding-threshold	(Optional) Set forwarding threshold
lower	(Optional) Set lower threshold value
lower-value	(Optional) Lower threshold value
upper	(Optional) Set upper threshold value
upper-value	(Optional) Upper threshold value

Command Mode

- /exec/configure/if-eth-any/hsrp_ipv4 /exec/configure/if-eth-any/hsrp_ipv6

priority

priority <value> | no priority

Syntax Description

no	Negate a command or set its defaults
priority	Configure Bundle priority
value	Priority value

Command Mode

- /exec/configure/anycast

priority

{ priority <priority_value> [forwarding-threshold lower <lower-value> upper <upper-value>] | no priority [forwarding-threshold] }

Syntax Description

no	Negate a command or set its defaults
priority	Configure the vr priority
priority_value	Configure the vr priority
forwarding-threshold	(Optional) Set forwarding threshold
lower	(Optional) Set lower threshold value
lower-value	(Optional) Lower threshold value
upper	(Optional) Set upper threshold value
upper-value	(Optional) Upper threshold value

Command Mode

- /exec/configure/if-eth-any/vrrp

priority

[no] priority | priority <setup_prio> [<hold_prio>]

Syntax Description

no	Negate a command or set its defaults
priority	Specify LSP priority
setup_prio	setup priority
hold_prio	(Optional) hold priority

Command Mode

- /exec/configure/te/lsp-attr

priority

[no] priority | priority <setup_pri> [<hold_pri>]

Syntax Description

no	Negate a command or set its defaults
priority	tunnel priority
setup_pri	setup priority
hold_pri	(Optional) hold priority

Command Mode

- /exec/configure/if-te /exec/configure/tunnel-te/cbts-member

private-vlan

[no] private-vlan <pvlan-type>

Syntax Description

no	(Optional) Negate a command or set its defaults
private-vlan	Configure a private VLAN
pvlan-type	PVLAN Type

Command Mode

- /exec/configure/vlan

private-vlan association

```
{ private-vlan association [ { add | remove } ] <secondary_vlans> } | { no private-vlan association [ <secondary_vlans> ] }
```

Syntax Description

private-vlan	Configure a private VLAN
association	Add association between private VLANs
add	(Optional) Add a VLAN to private VLAN list
remove	(Optional) Remove a VLAN from private VLAN list
no	Negate a command or set its defaults
secondary_vlans	VLAN IDs of the private VLANs to be configured

Command Mode

- /exec/configure/vlan

private-vlan mapping

```
{ private-vlan mapping [ { add | remove } ] <secondary_vlans> } | { no private-vlan mapping [ <secondary_vlans> ] }
```

Syntax Description

private-vlan	Configure a private VLAN
mapping	Set the private VLAN interface mapping
add	(Optional) Add a VLAN to private VLAN list
remove	(Optional) Remove a VLAN from private VLAN list
no	Negate a command or set its defaults
secondary_vlans	Secondary VLAN IDs of the private VLAN interface mapping

Command Mode

- /exec/configure/if-vlan

private-vlan synchronize

private-vlan synchronize

Syntax Description

private-vlan	Set private-vlan synchronization
synchronize	Synchronize vlans

Command Mode

- /exec/configure/spanning-tree/mst/configuration

probe-interval

probe-interval <probeinterval-val> | no probe-interval

Syntax Description

no	Negate a command or set its defaults
probe-interval	OpenFlow controller probe interval timer (default is 180 seconds)
probeinterval-val	probe interval timer value in secs

Command Mode

- /exec/configure/openflow/switch

probe-interval

probe-interval <probeinterval-val> | no probe-interval

Syntax Description

no	Negate a command or set its defaults
probe-interval	OpenFlow controller probe interval timer (default is 180 seconds)
probeinterval-val	probe interval timer value in secs

Command Mode

- /exec/configure/openflow/switch/sub-switch

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
probe-id-icmp	Service mode
frequency	(Optional) Frequency in seconds
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count
ip	(Optional) ip address for probe
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe

```
{ probe <probe-id-icmp> [ frequency <freq-num> | timeout <timeout> | retry-down-count <count> |
retry-up-count <up-count> | source-interface <interface> | ip <ip-addr> ] + } | { no probe }
```

Syntax Description

no	Negate a command or set its defaults
probe	Catena probe
probe-id-icmp	Service mode
frequency	(Optional) Frequency in seconds
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count
source-interface	(Optional) catena probe Source-Interface
interface	(Optional) source interface for probe
ip	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/catena-device-grp

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
probe-id-icmp	Service mode
frequency	(Optional) Frequency in seconds
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count
ip	(Optional) ip address for probe
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
probe-id-icmp	Service mode
frequency	(Optional) Frequency in seconds
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count

Command Mode

- /exec/configure/itd-device-group

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	Configure probe for node
probe-id-icmp	Service mode
frequency	(Optional) Configure probe frequency for a node
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Configure probe timeout for a node
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Configure retry-count before node declared down
count	(Optional) Count
retry-up-count	(Optional) Configure retry-count after node declared up
up-count	(Optional) Count
ip	(Optional) Configure ip address for probe
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node

probe

[no] probe <probe-id-icmp> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	Configure probe for node
probe-id-icmp	Service mode
frequency	(Optional) Configure probe frequency for a node
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Configure probe timeout for a node
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Configure retry-count before node declared down
count	(Optional) Count
retry-up-count	(Optional) Configure retry-count after node declared up
up-count	(Optional) Count
ip	(Optional) Configure ip address for probe
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node-standby

probe get

[no] probe <probe-id-http> get [<url-name> | cache | frequency <freq-num> | timeout <timeout> |
 retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
probe-id-http	Service mode
get	Host name/Target address
url-name	(Optional) Specify only the user input text/filename. http://<node-ip>/<user input>
cache	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
frequency	(Optional) Frequency
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Timeout
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count

Command Mode

- /exec/configure/itd-device-group

probe get

```
{ probe <probe-id-http> get [ <url-name> | cache | frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | source-interface <interface> | ip <ip-addr> ] + } | { no probe }
```

Syntax Description

no	Negate a command or set its defaults
probe	Catena probe
probe-id-http	Service mode
get	Host name/Target address
url-name	(Optional) Specify only the user input text/filename. http://<node-ip>/<user input>
cache	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
frequency	(Optional) Frequency
freq-num	(Optional) Frequency
timeout	(Optional) Timeout
timeout	(Optional) Timeout
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count
source-interface	(Optional) catena probe Source-Interface
interface	(Optional) source interface for probe
ip	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/catena-device-grp

probe get

[no] probe <probe-id-http> get [<url-name> | cache | frequency <freq-num> | timeout <timeout> |
 retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
probe-id-http	Service mode
get	Host name/Target address
url-name	(Optional) Specify only the user input text/filename. http://<node-ip>/<user input>
cache	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
frequency	(Optional) Frequency
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Timeout
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count
ip	(Optional) ip address for probe
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe get

[no] probe <probe-id-http> get [<url-name> | cache | frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
probe-id-http	Service mode
get	Host name/Target address
url-name	(Optional) Specify only the user input text/filename. http://<node-ip>/<user input>
cache	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
frequency	(Optional) Frequency
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Timeout
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count
ip	(Optional) ip address for probe
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe host

```
{ probe <probe-id-dns> host <host-name> [ frequency <freq-num> | timeout <timeout> | retry-down-count
<count> | retry-up-count <up-count> | source-interface <interface> | ip <ip-addr> ] + } | { no probe }
```

Syntax Description

no	Negate a command or set its defaults
probe	Catena probe
probe-id-dns	Service mode
host	Host name/Target address
host-name	DNS Target IP Address or Hostname
frequency	(Optional) Frequency
freq-num	(Optional) Frequency
timeout	(Optional) Timeout
timeout	(Optional) Timeout
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count
source-interface	(Optional) catena probe Source-Interface
interface	(Optional) source interface for probe
ip	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/catena-device-grp

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
probe-id-dns	Service mode
host	Host name/Target address
host-name	DNS Target IP Address or Hostname
frequency	(Optional) Frequency
freq-num	(Optional) Frequency
timeout	(Optional) Timeout
timeout	(Optional) Timeout
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count
ip	(Optional) ip address for probe
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
probe-id-dns	Service mode
host	Host name/Target address
host-name	DNS Target IP Address or Hostname
frequency	(Optional) Frequency in seconds
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count
ip	(Optional) ip address for probe
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
probe-id-dns	Service mode
host	Host name/Target address
host-name	DNS Target IP Address or Hostname
frequency	(Optional) Frequency in seconds
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count

Command Mode

- /exec/configure/itd-device-group

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	PLB probe
probe-id-dns	Service mode
host	Host name/Target address
host-name	DNS Target IP Address or Hostname
frequency	(Optional) Frequency in seconds
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count
ip	(Optional) ip address for probe
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node

probe host

[no] probe <probe-id-dns> host <host-name> [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	Configure probe for node
probe-id-dns	Service mode
host	Host name/Target address
host-name	DNS Target IP Address or Hostname
frequency	(Optional) Configure probe frequency for a node
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Configure probe timeout for a node
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Configure retry-count before node declared down
count	(Optional) Count
retry-up-count	(Optional) Configure retry-count after node declared down
up-count	(Optional) Count
ip	(Optional) Configure ip address for probe
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node-standby

probe port

```
{ probe <probe-id> port <port-num> [ control <status> ] [ frequency <freq-num> | timeout <timeout> |
retry-down-count <count> | retry-up-count <up-count> | source-interface <interface> | ip <ip-addr> ] + } | {
no probe }
```

Syntax Description

no	Negate a command or set its defaults
probe	Catena probe
probe-id	Service mode
port	Port
port-num	Port number
control	(Optional) control protocol
status	(Optional) control protocol status
frequency	(Optional) Frequency in seconds
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count
source-interface	(Optional) catena probe Source-Interface
interface	(Optional) source interface for probe
ip	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/catena-device-grp

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
probe-id	Service mode
port	Port
port-num	Port number
control	(Optional) control protocol
status	(Optional) control protocol status
frequency	(Optional) Frequency in seconds
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count
ip	(Optional) ip address for probe
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
probe-id	Service mode
port	Port
port-num	Port number
control	(Optional) control protocol
status	(Optional) control protocol status
frequency	(Optional) Frequency in seconds
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count
ip	(Optional) ip address for probe
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/itd-dg-node-standby

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	ITD probe
probe-id	Service mode
port	Port
port-num	Port number
control	(Optional) control protocol
status	(Optional) control protocol status
frequency	(Optional) Frequency in seconds
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Timeout in seconds
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Retry-count when node goes down
count	(Optional) Count
retry-up-count	(Optional) Retry-count when node comes back up
up-count	(Optional) Count

Command Mode

- /exec/configure/itd-device-group

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	Configure probe for PLB device group node
probe-id	Service mode
port	TCP/UDP Port
port-num	Port number
control	(Optional) control protocol
status	(Optional) control protocol status
frequency	(Optional) Configure probe frequency for a node
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Configure probe timeout for a node
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Configure retry-count before node declared down
count	(Optional) Count
retry-up-count	(Optional) Configure retry-count after node declared up
up-count	(Optional) Count
ip	(Optional) Configure ip address for probe
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node

probe port

[no] probe <probe-id> port <port-num> [control <status>] [frequency <freq-num> | timeout <timeout> | retry-down-count <count> | retry-up-count <up-count> | ip <ip-addr>] +

Syntax Description

no	(Optional) Negate a command or set its defaults
probe	Configure probe for node
probe-id	Service mode
port	TCP/UDP Port
port-num	Port number
control	(Optional) control protocol
status	(Optional) control protocol status
frequency	(Optional) Configure probe frequency for a node
freq-num	(Optional) Frequency in seconds
timeout	(Optional) Configure probe timeout for a node
timeout	(Optional) Timeout in seconds
retry-down-count	(Optional) Configure retry-count before node declared down
count	(Optional) Count
retry-up-count	(Optional) Configure retry-count after node declared up
up-count	(Optional) Count
ip	(Optional) Configure ip address for probe
ip-addr	(Optional) IP4 prefix in format i.i.i.i

Command Mode

- /exec/configure/plb-dg-node-standby

profile

[no] profile <profilename>

Syntax Description

profile	Specify the profile to be applied
profilename	profile name to be applied

Command Mode

- /exec/configure/nfm-system

profile

{ profile <pid> | no profile }

Syntax Description

no	Negate a command or set its defaults
profile	NGOAM profile to use
pid	NGOAM profile id

Command Mode

- /exec/configure/configngoamconnectcheck

profile

[no] profile <profile-name>

Syntax Description

no	(Optional) Negate the command
profile	Packet Drop Profile
profile-name	Profile name

Command Mode

- /exec/configure/pkt-drop

propagate-sgt

[no] propagate-sgt

Syntax Description

propagate-sgt	Enable SGT propagation from this port (the default use the no form to disable)
---------------	--

Command Mode

- /exec/configure/cts-dot1x /exec/configure/cts-manual

protected

[no] { protected | unprotected }

Syntax Description

no	(Optional) Negate a command or set its defaults
protected	Candidate path-option protected
unprotected	Candidate path-option unprotected

Command Mode

- /exec/configure/sr/te/pol/cndpaths/pref/constraint/sgmnt

protected

[no] { protected | unprotected }

Syntax Description

no	(Optional) Negate a command or set its defaults
protected	Candidate path-option protected
unprotected	Candidate path-option unprotected

Command Mode

- /exec/configure/sr/te/color/cndpaths/pref/constraint/sgmnt

protection

[no] protection | protection [fast-reroute [bw-protect]]

Syntax Description

no	Negate a command or set its defaults
protection	Enable failure protection
fast-reroute	(Optional) Enable fast-reroute failure protection
bw-protect	(Optional) Enable BW protection

Command Mode

- /exec/configure/te/lsp-attr

proto

{ proto <proto-id> }

Syntax Description

proto	Protocol
proto-id	IANA Protocol id

Command Mode

- /exec/configure/configngoamccpayload

protocol-version

protocol-version { <10> | <13> | negotiate } | no protocol-version

Syntax Description

no	Negate a command or set its defaults
protocol-version	Set OpenFlow protocol version
10	Use only OF 1.0 protocol to connect to controller
13	Use only OF 1.3 protocol to connect to controller
negotiate	Negotiate protocol with controller

Command Mode

- /exec/configure/openflow/switch

protocol-version

protocol-version { <10> | <13> | negotiate } | no protocol-version

Syntax Description

no	Negate a command or set its defaults
protocol-version	Set OpenFlow protocol version
10	Use only OF 1.0 protocol to connect to controller
13	Use only OF 1.3 protocol to connect to controller
negotiate	Negotiate protocol with controller

Command Mode

- /exec/configure/openflow/switch/sub-switch

protocol

[no] protocol <proto> [prefix-list <pflist-name>]

Syntax Description

no	(Optional) Negate a command or set its defaults
proto	
pflist-name	(Optional) Name of the prefix-list to be matched

Command Mode

- /exec/configure/config-snoop-policy

protocol

{ protocol <num> } | { no protocol }

Syntax Description

no	Negate a command or set its defaults
protocol	specify flow protocol number
num	flow protocol number

Command Mode

- /exec/configure/configngoamprofileflow

ptp

[no] ptp

Syntax Description

no	(Optional) Negate a command or set its defaults
ptp	Precision Time Protocol (IEEE 1588) Subsystem

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp announce timeout

[no] ptp announce timeout { <val> | smpte-2059-2 <smpte-val> | aes67 <aes-val> }

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
announce	announce
timeout	timeout
smpte-2059-2	SMPTE-2059-2
aes67	AES67-2015
val	
smpte-val	SMPTE-2059-2 val
aes-val	AES67-2015 val

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp clock-sync auto

[no] ptp clock-sync auto

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
clock-sync	clock-sync
auto	auto adjust frequency

Command Mode

- /exec/configure

ptp correction-range

[no] ptp correction-range <threshold-value>

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
correction-range	set correction range threshold value
threshold-value	correction threshold (ns) [-value, +value], default 100000 (100 us)

Command Mode

- /exec/configure

ptp correction-range logging

[no] ptp correction-range logging

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
correction-range	set correction range threshold value
logging	enable logging for corrections exceeding threshold value

Command Mode

- /exec/configure

ptp correction hardware

[no] ptp correction hardware

Syntax Description

no	(Optional) Negate a command or set its defaults
ptp	Precision Time Protocol (IEEE 1588) Subsystem
correction	Corrections for PTP
hardware	Frequency correction from hardware or software

Command Mode

- /exec/configure

ptp device-type boundary

[no] ptp device-type { boundary-clock | generalized-ptp }

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
device-type	ptp device-type
boundary-clock	boundary-clock
generalized-ptp	Generalized PTP

Command Mode

- /exec/configure

ptp domain

[no] ptp domain <domain-val>

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
domain	ptp clock domain
domain-val	Enter domain value

Command Mode

- /exec/configure

ptp mean-path-delay

[no] ptp mean-path-delay <threshold-value>

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
mean-path-delay	set mean-path-delay threshold value
threshold-value	mean-path-delay threshold (ns), default 1000000000 (1 sec)

Command Mode

- /exec/configure

ptp multicast master-only

[no] ptp multicast master-only

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
multicast	multicast
master-only	master only

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

ptp offload

[no] ptp offload

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
offload	Allows increasing number of PTP sessions per system by offloading some timers to linecard

Command Mode

- /exec/configure

ptp pdelay-req-interval

[no] ptp pdelay-req-interval <val>

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
pdelay-req-interval	Log mean peer delay request interval
val	value

Command Mode

- /exec/configure

ptp priority1

[no] ptp priority1 <val>

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
priority1	priority1
val	priority1

Command Mode

- /exec/configure

ptp priority2

[no] ptp priority2 <val>

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
priority2	Priority2
val	priority2

Command Mode

- /exec/configure

ptp source

```
[no] ptp source <src-ip> [ vrf { <vrf-name> | <vrf-cfg-name> } ]
```

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
source	source IP address
src-ip	IPv4 address (A.B.C.D) of source
vrf	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
vrf-name	(Optional) vrf to be used for hellos
vrf-cfg-name	(Optional) Configurable VRF name

Command Mode

- /exec/configure

ptp vlan

[no] ptp vlan <vlan>

Syntax Description

ptp	Precision Time Protocol (IEEE 1588) Subsystem
vlan	vlan
vlan	vlan

Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

push

push [<name>]

Syntax Description

push	push current mode to stack or save it under name
name	(Optional) name

Command Mode

- /global

pwd

pwd

Syntax Description

pwd	View current directory
-----	------------------------

Command Mode

- /exec

python

python [<uri> [<pyargs>] +]

Syntax Description

python	run a python command/script, or enter python mode (if no arg)
uri	(Optional) path to a python file
pyargs	(Optional) python command line arguments (maximum 32)

Command Mode

- /exec

python instance

[no] python instance <inst> [<uri> [<pyargs>] +] | python instance <inst> <uri> [<pyargs>] +

Syntax Description

no	Negate a command or set its defaults
python	run a python command/script, or enter python mode (if no arg)
instance	label with an instance number
inst	instance number
uri	(Optional) path to a python file
pyargs	(Optional) python command line arguments (maximum 32)

Command Mode

- /exec/configure

