



Working with Configuration Files

This chapter describes how to work with your device configuration files.

- [Information About Configuration Files, on page 1](#)
- [Guidelines and Limitations for Configuration Files, on page 2](#)
- [Managing Configuration Files, on page 2](#)
- [Verifying the Device Configuration, on page 12](#)
- [Examples of Working with Configuration Files, on page 12](#)
- [Related Documents for Configuration files, on page 13](#)

Information About Configuration Files

Configuration files contain the Cisco NX-OS software commands used to configure the features on a Cisco NX-OS device. Commands are parsed (translated and executed) by the Cisco NX-OS software when the system is booted (from the startup-config file) or when you enter commands at the CLI in a configuration mode.

To change the startup configuration file, you can either save the running-configuration file to the startup configuration using the **copy running-config startup-config** command or copy a configuration file from a file server to the startup configuration.

Types of Configuration Files

The Cisco NX-OS software has two types of configuration files, running configuration and startup configuration. The device uses the startup configuration (startup-config) during device startup to configure the software features. The running configuration (running-config) contains the current changes that you make to the startup-configuration file. The two configuration files can be different. You might want to change the device configuration for a short time period rather than permanently. In this case, you would change the running configuration by using commands in global configuration mode but not save the changes to the startup configuration.

To change the running configuration, use the **configure terminal** command to enter global configuration mode. As you use the Cisco NX-OS configuration modes, commands generally are executed immediately and are saved to the running configuration file either immediately after you enter them or when you exit a configuration mode.

To change the startup-configuration file, you can either save the running configuration file to the startup configuration or download a configuration file from a file server to the startup configuration.

Guidelines and Limitations for Configuration Files

Configuration file guidelines and limitations are as follows:

- Beginning with NX-OS 7.0(3)I7(4), the **reload timer** command is supported to enable a reboot after a delay of 5 -60 seconds.

Managing Configuration Files

This section describes how to manage configuration files.

Saving the Running Configuration to the Startup Configuration

You can save the running configuration to the startup configuration to save your changes for the next time you that reload the device.

SUMMARY STEPS

1. (Optional) **show running-config**
2. **copy running-config startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	(Optional) show running-config Example: switch# show running-config	Displays the running configuration.
Step 2	copy running-config startup-config Example: switch# copy running-config startup-config	Copies the running configuration to the startup configuration.

Copying a Configuration File to a Remote Server

You can copy a configuration file stored in the internal memory to a remote server as a backup or to use for configuring other Cisco NX-OS devices.

SUMMARY STEPS

1. **copy running-config** *scheme://server/[url /]filename*
2. **copy startup-config** *scheme://server/[url /]filename*

DETAILED STEPS

	Command or Action	Purpose
Step 1	copy running-config <i>scheme://server/[url /]filename</i> Example: <pre>switch# copy running-config tftp://10.10.1.1/sw1-run-config.bak</pre>	Copies the running-configuration file to a remote server. For the <i>scheme</i> argument, you can enter tftp: , ftp: , scp: , or sftp: . The <i>server</i> argument is the address or name of the remote server, and the <i>url</i> argument is the path to the source file on the remote server. The <i>server</i> , <i>url</i> , and <i>filename</i> arguments are case sensitive.
Step 2	copy startup-config <i>scheme://server/[url /]filename</i> Example: <pre>switch# copy startup-config tftp://10.10.1.1/sw1-start-config.bak</pre>	Copies the startup-configuration file to a remote server. For the <i>scheme</i> argument, you can enter tftp: , ftp: , scp: , or sftp: . The <i>server</i> argument is the address or name of the remote server, and the <i>url</i> argument is the path to the source file on the remote server. The <i>server</i> , <i>url</i> , and <i>filename</i> arguments are case sensitive.

Example

This example shows how to copy the configuration file to a remote server:

```
switch# copy running-config
tftp://10.10.1.1/sw1-run-config.bak
switch# copy startup-config
tftp://10.10.1.1/sw1-start-config.bak
```

Downloading the Running Configuration From a Remote Server

You can configure your Cisco NX-OS device by using configuration files that you created on another Cisco NX-OS device and uploaded to a remote server. You then download the file from the remote server to your device using TFTP, FTP, Secure Copy (SCP), or Secure Shell FTP (SFTP) to the running configuration.

Before you begin

Ensure that the configuration file that you want to download is in the correct directory on the remote server.

Ensure that the permissions on the file are set correctly. Permissions on the file should be set to world-read.

Ensure that your Cisco NX-OS device has a route to the remote server. The Cisco NX-OS device and the remote server must be in the same subnetwork if you do not have a router or a default gateway to route traffic between subnets.

Check connectivity to the remote server using the **ping** or **ping6** command.

SUMMARY STEPS

1. **copy** *scheme://server/[url/]filename* **running-config**
2. (Optional) **show running-config**
3. (Optional) **copy running-config startup-config**
4. (Optional) **show startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	copy <i>scheme://server/[url]/filename</i> running-config Example: <pre>switch# copy tftp://10.10.1.1/my-config running-config</pre>	Downloads the running-configuration file from a remote server. For the <i>scheme</i> argument, you can enter tftp: , ftp: , scp: , or sftp: . The <i>server</i> argument is the address or name of the remote server, and the <i>url</i> argument is the path to the source file on the remote server. The <i>server</i> , <i>url</i> , and <i>filename</i> arguments are case sensitive.
Step 2	(Optional) show running-config Example: <pre>switch# show running-config</pre>	Displays the running configuration.
Step 3	(Optional) copy running-config startup-config Example: <pre>switch# copy running-config startup-config</pre>	Copies the running configuration to the startup configuration.
Step 4	(Optional) show startup-config Example: <pre>switch# show startup-config</pre>	Displays the startup configuration.

Downloading the Startup Configuration From a Remote Server

You can configure your Cisco NX-OS device by using configuration files that you created on another Cisco NX-OS device and uploaded to a remote server. You then download the file from the remote server to your device using TFTP, FTP, Secure Copy (SCP), or Secure Shell FTP (SFTP) to the startup configuration.


Caution

This procedure disrupts all traffic on the Cisco NX-OS device.

Before you begin

Log in to a session on the console port.

Ensure that the configuration file that you want to download is in the correct directory on the remote server.

Ensure that the permissions on the file are set correctly. Permissions on the file should be set to world-read.

Ensure that your Cisco NX-OS device has a route to the remote server. The Cisco NX-OS device and the remote server must be in the same subnetwork if you do not have a router or a default gateway to route traffic between subnets.

Check connectivity to the remote server using the **ping** or **ping6** command.

SUMMARY STEPS

1. **write erase**

2. **reload**
3. **copy *scheme://server/[url /]filename* running-config**
4. **copy running-config startup-config**
5. (Optional) **show startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	write erase Example: <pre>switch# write erase</pre>	Erases the startup configuration file.
Step 2	reload Example: <pre>switch# reload This command will reboot the system. (y/n)? [n] y ... Enter the password for "admin": <password> Confirm the password for "admin": <password> ... Would you like to enter the basic configuration dialog (yes/no): n switch#</pre>	Reloads the Cisco NX-OS device. Note Do not use the setup utility to configure the device.
Step 3	copy <i>scheme://server/[url /]filename</i> running-config Example: <pre>switch# copy tftp://10.10.1.1/my-config running-config</pre>	Downloads the running configuration file from a remote server. For the <i>scheme</i> argument, you can enter tftp: , ftp: , scp: , or sftp: . The <i>server</i> argument is the address or name of the remote server, and the <i>url</i> argument is the path to the source file on the remote server. The <i>server</i> , <i>url</i> , and <i>filename</i> arguments are case sensitive.
Step 4	copy running-config startup-config Example: <pre>switch# copy running-config startup-config</pre>	Saves the running configuration file to the startup configuration file.
Step 5	(Optional) show startup-config Example: <pre>switch# show startup-config</pre>	Displays the running configuration.

Copying Configuration Files to an External Flash Memory Device

You can copy configuration files to an external flash memory device as a backup for later use.

Before you begin

Insert the external Flash memory device into the active supervisor module.

SUMMARY STEPS

1. (Optional) **dir** {slot0: | usb1: | usb2:}[*directory*]
2. **copy running-config** {slot0: | usb1: | usb2:}[*directory*]*filename*
3. **copy startup-config** {slot0: | usb1: | usb2:}[*directory*]*filename*

DETAILED STEPS

	Command or Action	Purpose
Step 1	(Optional) dir {slot0: usb1: usb2:}[<i>directory</i>] Example: switch# dir slot0:	Displays the files on the external flash memory device.
Step 2	copy running-config {slot0: usb1: usb2:}[<i>directory</i>] <i>filename</i> Example: switch# copy running-config slot0:dsn-running-config.cfg	Copies the running configuration to an external flash memory device. The <i>filename</i> argument is case sensitive.
Step 3	copy startup-config {slot0: usb1: usb2:}[<i>directory</i>] <i>filename</i> Example: switch# copy startup-config slot0:dsn-startup-config.cfg	Copies the startup configuration to an external flash memory device. The <i>filename</i> argument is case sensitive.

Copying the Running Configuration from an External Flash Memory Device

You can configure your Cisco NX-OS device by copying configuration files created on another Cisco NX-OS device and saved to an external flash memory device.

Before you begin

Insert the external flash memory device into the active supervisor module.

SUMMARY STEPS

1. (Optional) **dir** {slot0: | usb1: | usb2:}[*directory*]
2. **copy** {slot0: | usb1: | usb2:}[*directory*]*filename* **running-config**
3. (Optional) **show running-config**
4. (Optional) **copy running-config startup-config**
5. (Optional) **show startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	(Optional) dir {slot0: usb1: usb2:}[<i>directory</i>] Example:	Displays the files on the external flash memory device.

	Command or Action	Purpose
	<code>switch# dir slot0:</code>	
Step 2	copy {slot0: usb1: usb2:}[directory/]filename running-config Example: <code>switch# copy slot0:dsn-config.cfg running-config</code>	Copies the running configuration from an external flash memory device. The <i>filename</i> argument is case sensitive.
Step 3	(Optional) show running-config Example: <code>switch# show running-config</code>	Displays the running configuration.
Step 4	(Optional) copy running-config startup-config Example: <code>switch# copy running-config startup-config</code>	Copies the running configuration to the startup configuration.
Step 5	(Optional) show startup-config Example: <code>switch# show startup-config</code>	Displays the startup configuration.

Copying the Startup Configuration from an External Flash Memory Device

You can recover the startup configuration on your Cisco NX-OS device by downloading a new startup configuration file saved on an external flash memory device.

Before you begin

Insert the external flash memory device into the active supervisor module.

SUMMARY STEPS

1. (Optional) **dir {slot0: | usb1: | usb2:}[directory/]**
2. **copy {slot0: | usb1: | usb2:}[directory/]filename startup-config**
3. (Optional) **show startup-config**

DETAILED STEPS

	Command or Action	Purpose
Step 1	(Optional) dir {slot0: usb1: usb2:}[directory/] Example: <code>switch# dir slot0:</code>	Displays the files on the external flash memory device.
Step 2	copy {slot0: usb1: usb2:}[directory/]filename startup-config Example: <code>switch# copy slot0:dsn-config.cfg startup-config</code>	Copies the startup configuration from an external flash memory device. The <i>filename</i> argument is case sensitive.

	Command or Action	Purpose
Step 3	(Optional) show startup-config Example: switch# show startup-config	Displays the startup configuration.

Copying Configuration Files to an Internal File System

You can copy configuration files to the internal memory as a backup for later use.

SUMMARY STEPS

1. **copy running-config** [*filesystem:*][*directory/*] | [*directory/*]*filename*
2. **copy startup-config** [*filesystem:*][*directory/*] | [*directory/*]*filename*

DETAILED STEPS

	Command or Action	Purpose
Step 1	copy running-config [<i>filesystem:</i>][<i>directory/</i>] [<i>directory/</i>] <i>filename</i> Example: switch# copy running-config bootflash:sw1-run-config.bak	Copies the running-configuration file to internal memory. The <i>filesystem</i> , <i>directory</i> , and <i>filename</i> arguments are case sensitive.
Step 2	copy startup-config [<i>filesystem:</i>][<i>directory/</i>] [<i>directory/</i>] <i>filename</i> Example: switch# copy startup-config bootflash:sw1-start-config.bak	Copies the startup-configuration file to internal memory. The <i>filesystem</i> , <i>directory</i> , and <i>filename</i> arguments are case sensitive.

Rolling Back to a Previous Configuration

Problems, such as memory corruption, can occur that make it necessary for you to recover your configuration from a backed up version.



Note

Each time that you enter a **copy running-config startup-config** command, a binary file is created and the ASCII file is updated. A valid binary configuration file reduces the overall boot time significantly. A binary file cannot be uploaded, but its contents can be used to overwrite the existing startup configuration. The **write erase** command clears the binary file.

SUMMARY STEPS

1. **write erase**
2. **reload**
3. **copy configuration_file running-configuration**

4. copy running-config startup-config

DETAILED STEPS

	Command or Action	Purpose
Step 1	write erase Example: <pre>switch# write erase</pre>	Clears the current configuration of the switch.
Step 2	reload Example: <pre>switch# reload</pre>	Restarts the device. You will be prompted to provide a kickstart and system image file for the device to boot and run. Note By default, the reload command reloads the device from a binary version of the startup configuration. Beginning with Cisco NX-OS 6.2(2), you can use the reload ascii command to copy an ASCII version of the configuration to the start up configuration when reloading the device.
Step 3	copy <i>configuration_file</i> running-configuration Example: <pre>switch# copy bootflash:start-config.bak running-configuration</pre>	Copies a previously saved configuration file to the running configuration. Note The <i>configuration_file</i> filename argument is case sensitive.
Step 4	copy running-config startup-config Example: <pre>switch# copy running-config startup-config</pre>	Copies the running configuration to the start-up configuration.

Removing the Configuration for a Missing Module

When you remove an I/O module from the chassis, you can also remove the configuration for that module from the running configuration.



Note You can only remove the configuration for an empty slot in the chassis.

Before you begin

Remove the I/O module from the chassis.

SUMMARY STEPS

1. (Optional) **show hardware**
2. **purge module *slot* running-config**

3. (Optional) copy running-config startup-config

DETAILED STEPS

	Command or Action	Purpose
Step 1	(Optional) show hardware Example: switch# show hardware	Displays the installed hardware for the device.
Step 2	purge module slot running-config Example: switch# purge module 3 running-config	Removes the configuration for a missing module from the running configuration.
Step 3	(Optional) copy running-config startup-config Example: switch# copy running-config startup-config	Copies the running configuration to the startup configuration.

Erasing a Configuration

You can erase the configuration on your device to return to the factory defaults.

You can erase the following configuration files saved in the persistent memory on the device:

- Startup
- Boot
- Debug

The **write erase** command erases the entire startup configuration, except for the following:

- Boot variable definitions
- The IPv4 configuration on the mgmt0 interface, including the following:
 - Address
 - Subnet mask

To remove the boot variable definitions follow step-1 and step-2.

To remove the boot variables, running configuration, and the IP configuration on the management interface follow step-3 to step-5.

SUMMARY STEPS

1. **write erase boot**
2. **reload**
3. **write erase**
4. **write erase boot**
5. **reload**

DETAILED STEPS

	Command or Action	Purpose
Step 1	write erase boot Example: <pre>switch# write erase boot</pre>	Erases the boot variable definitions.
Step 2	reload Example: <pre>switch# reload</pre>	Restarts the device. You will be prompted to provide a kickstart and system image file for the device to boot and run. By default, the reload command reloads the device from a binary version of the startup configuration.
Step 3	write erase Example: <pre>switch# write erase</pre>	Erases the boot variable definitions.
Step 4	write erase boot Example: <pre>switch# write erase boot</pre>	Erases the boot variable definitions and the IPv4 configuration on the management interface.
Step 5	reload Example: <pre>switch# reload</pre>	Restarts the device. You will be prompted to provide a kickstart and system image file for the device to boot and run. By default, the reload command reloads the device from a binary version of the startup configuration.

Clearing Inactive Configurations

You can clear inactive Quality of Service (QoS) and/or access control list (ACL) configurations.

SUMMARY STEPS

1. (Optional) **show running-config type inactive-if-config**
2. **clear inactive-config policy**
3. (Optional) **show inactive-if-config log**

DETAILED STEPS

	Command or Action	Purpose
Step 1	(Optional) show running-config type inactive-if-config Example: <pre># show running-config ipqos inactive-if-config</pre>	Displays any inactive ACL or QoS configurations. The values for the <i>type</i> argument are aclmgr and ipqos . <ul style="list-style-type: none"> • aclmgr— Displays any inactive configurations for aclmgr.

	Command or Action	Purpose
		<ul style="list-style-type: none"> • ipqos—Displays any inactive configurations for qosmgr.
Step 2	clear inactive-config policy Example: <pre># clear inactive-config qos clear qos inactive config Inactive if config for QoS manager is saved at/bootflash/qos_inactive_if_config.cfg for vdc default & for other than default vdc: /bootflash/vdc_x/qos_inactive_if_config.cfg (where x is vdc number) you can see the log file @ show inactive-if-config log</pre>	Clears inactive configurations. The values for the <i>policy</i> argument are qos and acl . The following describes the values: <ul style="list-style-type: none"> • qos—Clears inactive QoS configurations. • acl—Clears inactive ACL configurations. • acl qos—Clears inactive ACL configurations and inactive QoS configurations.
Step 3	(Optional) show inactive-if-config log Example: <pre># show inactive-if-config log</pre>	Displays the commands that were used to clear the inactive configurations.

Verifying the Device Configuration

To verify the configuration, use one of the following commands:

Command	Purpose
show running-config	Displays the running configuration.
show startup-config	Displays the startup configuration.
show time-stamp running-config last-changed	Displays the timestamp when the running configuration was last changed.

For detailed information about the fields in the output from these commands, see the Cisco Nexus command reference for your device.

Examples of Working with Configuration Files

This section includes examples of working with configuration files.

Copying Configuration Files

This example shows how to copy a running configuration to the bootflash: file system:

```
switch# copy system:running-config bootflash:my-config
```

Backing Up Configuration Files

This example shows how to back up the startup configuration to the bootflash: file system (ASCII file):

```
switch# copy startup-config bootflash:my-config
```

This example shows how to back up the startup configuration to the TFTP server (ASCII file):

```
switch# copy startup-config tftp://172.16.10.100/my-config
```

This example shows how to back up the running configuration to the bootflash: file system (ASCII file):

```
switch# copy running-config bootflash:my-config
```

Rolling Back to a Previous Configuration

To roll back your configuration to a snapshot copy of a previously saved configuration, you need to perform the following steps:

1. Clear the current running image with the **write erase** command.
2. Restart the device with the **reload** command.



Note By default, the **reload** command reloads the device from a binary version of the startup configuration.

You can use the **reload ascii** command to copy an ASCII version of the configuration to the start up configuration when reloading the device.

3. Copy the previously saved configuration file to the running configuration with the **copy configuration_file running-configuration** command.
4. Copy the running configuration to the start-up configuration with the **copy running-config startup-config** command.

Related Documents for Configuration files

Related Topic	Document Title
Cisco NX-OS Licensing	<i>Cisco NX-OS Licensing Guide</i>
Command Reference	<i>Cisco Nexus 3548 Switch NX-OS Fundamentals Command Reference</i>

