



## T Commands

---

- `table-map`, on page 6
- `table-map`, on page 7
- `table-map`, on page 8
- `table-map`, on page 9
- `table-map`, on page 10
- `table-map`, on page 11
- `table-map`, on page 12
- `table-map`, on page 13
- `tac-pac`, on page 14
- `tac-pac`, on page 15
- `tacacs-server` `deadtime`, on page 16
- `tacacs-server` `directed-request`, on page 17
- `tacacs-server` `host` `key` `0 6 7`, on page 18
- `tacacs-server` `host` `test`, on page 19
- `tacacs-server` `key` `0 6 7`, on page 20
- `tacacs-server` `test`, on page 21
- `tacacs-server` `timeout`, on page 22
- `tacacs` `enable`, on page 23
- `tag`, on page 24
- `tag` `happens in`, on page 25
- `tahoe-python` `module`, on page 26
- `tahoe-python` `module` `quoted`, on page 27
- `tail`, on page 28
- `tail`, on page 29
- `tar`, on page 30
- `telsh`, on page 31
- `telsh`, on page 32
- `tcp-connect`, on page 33
- `telemetry`, on page 34
- `telnet`, on page 35
- `telnet6`, on page 36
- `telnet` `login-attempts`, on page 37
- `telnet` `server` `enable`, on page 38

- [template](#), on page 39
- [template data timeout](#), on page 40
- [template peer-policy](#), on page 41
- [template peer-session](#), on page 42
- [template peer](#), on page 43
- [terminal](#), on page 44
- [terminal alias](#), on page 45
- [terminal ask-on-term](#), on page 46
- [terminal color](#), on page 47
- [terminal context management](#), on page 48
- [terminal deep-help](#), on page 49
- [terminal dont-ask](#), on page 50
- [terminal edit-mode vi](#), on page 51
- [terminal event-manager bypass](#), on page 52
- [terminal history no-exec-in-config](#), on page 53
- [terminal history no-exec-in-config](#), on page 54
- [terminal history no-exec-in-config](#), on page 55
- [terminal home](#), on page 56
- [terminal length](#), on page 57
- [terminal length](#), on page 58
- [terminal lock](#), on page 59
- [terminal log-all](#), on page 60
- [terminal no](#), on page 61
- [terminal output xml](#), on page 62
- [terminal output xml](#), on page 63
- [terminal output xml](#), on page 64
- [terminal password](#), on page 65
- [terminal prompt](#), on page 66
- [terminal redirection-mode](#), on page 67
- [terminal reset-role](#), on page 68
- [terminal reset vlan-config-mutex](#), on page 69
- [terminal session-timeout](#), on page 70
- [terminal sticky-mode](#), on page 71
- [terminal terminal-type](#), on page 72
- [terminal time](#), on page 73
- [terminal tree-update](#), on page 74
- [terminal unlock](#), on page 75
- [terminal verify-only](#), on page 76
- [terminal width](#), on page 77
- [terminal width](#), on page 78
- [threshold-percent](#), on page 79
- [threshold](#), on page 80
- [time-range](#), on page 81
- [timeout](#), on page 82
- [timer](#), on page 83
- [timers](#), on page 84

- timers, on page 85
- timers, on page 86
- timers, on page 87
- timers advertise, on page 88
- timers basic, on page 89
- timers bestpath-defer maximum, on page 90
- timers bestpath-limit, on page 91
- timers bgp, on page 92
- timers lsa-arrival, on page 93
- timers lsa-arrival, on page 94
- timers lsa-group-pacing, on page 95
- timers lsa-group-pacing, on page 96
- timers prefix-peer-timeout, on page 97
- timers prefix-peer-wait, on page 98
- timers throttle lsa, on page 99
- timers throttle lsa, on page 100
- timers throttle spf, on page 101
- timers throttle spf, on page 102
- tls, on page 103
- topology, on page 104
- topology holddown sigerr, on page 105
- tos, on page 106
- tr, on page 107
- trace buffer size, on page 108
- traceroute, on page 109
- traceroute6, on page 110
- traceroute nve, on page 111
- track-adjacency-nexthop, on page 113
- track, on page 114
- track, on page 115
- track, on page 116
- track, on page 117
- track, on page 118
- track, on page 119
- track, on page 120
- track, on page 121
- track, on page 122
- track, on page 123
- track data, on page 124
- track interface, on page 125
- track interface priority, on page 126
- track running-state track startup-state, on page 127
- traffic-class, on page 128
- traffic-share, on page 129
- transmit-delay, on page 130
- transmit-delay, on page 131

- transmit-delay, on page 132
- transport connection-mode passive, on page 133
- transport email, on page 134
- transport email mail-server, on page 135
- transport http proxy enable, on page 136
- transport http proxy server, on page 137
- transport http use-vrf, on page 138
- transport type tcp, on page 139
- transport udp, on page 141
- trigger forwarding distribution module, on page 142
- trigger init ingress in-select 3 out-select 0, on page 143
- trigger init ingress in-select 3 out-select 03, on page 144
- trigger init ingress in-select 3 out-select 0 reverse, on page 145
- trigger init ingress in-select 3 out-select 1, on page 146
- trigger init ingress in-select 3 out-select 2, on page 147
- trigger init ingress in-select 3 out-select 4, on page 148
- trigger init ingress in-select 3 out-select 5, on page 149
- trigger init ingress in-select 3 out-select 5 reverse, on page 150
- trigger init ingress in-select 4 out-select 0, on page 151
- trigger init ingress in-select 4 out-select 04, on page 152
- trigger init ingress in-select 4 out-select 0 reverse, on page 153
- trigger init ingress in-select 4 out-select 1, on page 154
- trigger init ingress in-select 4 out-select 2, on page 155
- trigger init ingress in-select 4 out-select 3, on page 156
- trigger init ingress in-select 4 out-select 5, on page 157
- trigger init ingress in-select 4 out-select 5 reverse, on page 158
- trigger init ingress in-select 5 out-select 0, on page 159
- trigger init ingress in-select 5 out-select 05, on page 160
- trigger init ingress in-select 5 out-select 05 reverse, on page 161
- trigger init ingress in-select 5 out-select 0 reverse, on page 162
- trigger init ingress in-select 5 out-select 1, on page 163
- trigger init ingress in-select 5 out-select 2, on page 164
- trigger init ingress in-select 5 out-select 3, on page 165
- trigger init ingress in-select 5 out-select 4, on page 166
- trigger init ingress in-select 6 out-select 0, on page 167
- trigger init ingress in-select 6 out-select 0 reverse, on page 168
- trigger init ingress in-select 6 out-select 1, on page 169
- trigger init ingress in-select 6 out-select 2, on page 170
- trigger init ingress in-select 6 out-select 3, on page 171
- trigger init ingress in-select 6 out-select 4, on page 172
- trigger init ingress in-select 6 out-select 5, on page 173
- trigger init ingress in-select 6 out-select 5 reverse, on page 174
- trigger init ingress in-select 7 out-select 0, on page 175
- trigger init ingress in-select 7 out-select 0 reverse, on page 176
- trigger init ingress in-select 7 out-select 1, on page 177
- trigger init ingress in-select 7 out-select 2, on page 178

- [trigger init ingress in-select 7 out-select 3](#), on page 179
- [trigger init ingress in-select 7 out-select 4](#), on page 180
- [trigger init ingress in-select 7 out-select 5](#), on page 181
- [trigger init ingress in-select 7 out-select 5 reverse](#), on page 182
- [trigger reset](#), on page 183
- [trigger route download vrf ipv4](#), on page 184
- [trustpoint server-identity](#), on page 185
- [ttag-marker-interval](#), on page 186
- [ttag-marker enable](#), on page 187
- [ttag](#), on page 188
- [ttl-security hops](#), on page 189
- [tunnel destination](#), on page 190
- [tunnel mode](#), on page 191
- [tunnel path-mtu-discovery](#), on page 192
- [tunnel path-mtu-discovery age-timer](#), on page 193
- [tunnel path-mtu-discovery min-mtu](#), on page 194
- [tunnel source](#), on page 195
- [tunnel ttl](#), on page 196
- [tunnel use-vrf](#), on page 197
- [type type](#), on page 198

# table-map

[no] table-map <policy-name> [ filter ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
table-map	Policy for filtering/modifying OSPFV3 routes before sending them to RIB
<i>policy-name</i>	Route-map name
filter	(Optional) To block the OSPFV3 routes from being sent to RIB

## Command Mode

- /exec/configure/router-ospf3/router-ospf3-af-ipv6 /exec/configure/router-ospf3/vrf/router-ospf3-af-ipv6

# table-map

[no] table-map <policy-name> [ filter ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
table-map	Policy for filtering/modifying OSPF routes before sending them to RIB
<i>policy-name</i>	Route-map name
filter	(Optional) To block the OSPF routes from being sent to RIB

## Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

# table-map

[no] table-map <table-map-name>

## Syntax Description

no	(Optional) Negate a command or set its defaults
table-map	Configure a table map
<i>table-map-name</i>	Table map name

## Command Mode

- /exec/configure



# table-map

table-map <default-tmap-enum-name>

## Syntax Description

table-map	Configure a table map
<i>default-tmap-enum-name</i>	

## Command Mode

- /exec/configure

# table-map

[no] table-map <policy-name> [ filter ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
table-map	Table-map policy used to filter routes and tune attributes before downloading to RIB
filter	(Optional) Filter the routes based on policy results
<i>policy-name</i>	A 'routing-rules' route-map name

## Command Mode

- /exec/configure/router-isis/router-isis-vrf-common /exec/configure/router-isis/router-isis-af-ipv4

# table-map

[no] table-map <policy-name> [ filter ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
table-map	Table-map policy used to filter routes and tune attributes before downloading to RIB
filter	(Optional) Filter the routes based on policy results
<i>policy-name</i>	A 'routing-rules' route-map name

## Command Mode

- /exec/configure/router-isis/router-isis-af-ipv6

# table-map

[no] table-map <map> [ filter ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
table-map	Configure Table Map information
<i>map</i>	Route-map name
filter	(Optional) Filter routes which are rejected by route-map

## Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-common

# table-map

[no] table-map <rmap-name> [ filter ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
table-map	Apply table-map to filter routes downloaded into URIB
<i>rmap-name</i>	Route-map name
filter	(Optional) Selective route download

## Command Mode

- /exec/configure/router-bgp/router-bgp-af

# tac-pac

tac-pac [ <uri0> ]

## Syntax Description

tac-pac	save tac info in a compressed .gz file at specific location
<i>uri0</i>	(Optional) Select destination filesystem

## Command Mode

- /exec

# tac-pac

tac-pac [ <uri0> [ vrf <vrf-known-name> ] ]

## Syntax Description

tac-pac	save tac info in a compressed .gz file at specific location
<i>uri0</i>	(Optional) Select destination filesystem
vrf	(Optional) Display per-VRF information
<i>vrf-known-name</i>	(Optional) Known VRF name

## Command Mode

- /exec

# tacacs-server deadline

[no] tacacs-server deadline <i0>

## Syntax Description

no	(Optional) Negate a command or set its defaults
tacacs-server	Configure TACACS+ server related parameters
deadline	duration for which non-reachable server is skipped
<i>i0</i>	Length of time, in minutes

## Command Mode

- /exec/configure



# tacacs-server directed-request

[no] tacacs-server directed-request

## Syntax Description

no	(Optional) Negate a command or set its defaults
tacacs-server	Configure TACACS+ server related parameters
directed-request	enable direct authentication requests to server

## Command Mode

- /exec/configure

## tacacs-server host key 0 6 7

```
{ { [ no ] tacacs-server host { <hostipname> } { { key { 0 <s0> | 6 <s6> | 7 <s1> | <s2> } [ port <i1> ] [
timeout <i2> ] } | { [ port1 <i3> ] [ timeout1 <i4> ] } } } | { no tacacs-server host <hostipname> key } }
```

### Syntax Description

<i>key</i>	0
no	(Optional) Negate a command or set its defaults
tacacs-server	Configure TACACS+ server related parameters
host	TACACS+ server's DNS name or its IP address
<i>hostipname</i>	IPV4/IPV6 address or DNS name
key	TACACS+ shared secret
0	TACACS+ shared secret(clear text)
<i>s0</i>	TACACS+ shared secret(clear text)
port	(Optional) TACACS+ server port
<i>i1</i>	(Optional) TACACS+ server port
timeout	(Optional) TACACS+ server timeout period in seconds
<i>i2</i>	(Optional) TACACS+ server timeout period in seconds
6	TACACS+ shared secret(type-6 encrypted)
<i>s6</i>	TACACS+ shared secret(encrypted)
7	TACACS+ shared secret(encrypted)
<i>s1</i>	TACACS+ shared secret(encrypted)
port1	(Optional) TACACS+ server port
<i>i3</i>	(Optional) TACACS+ server port
timeout1	(Optional) TACACS+ server timeout period in seconds
<i>i4</i>	(Optional) TACACS+ server timeout period in seconds
<i>s2</i>	TACACS+ shared secret(clear text)

### Command Mode

- /exec/configure

## tacacs-server host test

```
[no] tacacs-server host <hostipnam> test { { username <s0> { [ password <s1> [ idle-time <i1> ] ] [ idle-time <i1> ] } } | { password <s1> [ idle-time <i1> ] } | { idle-time <i1> } }
```

### Syntax Description

<i>username</i>	<s0>
no	(Optional) Negate a command or set its defaults
tacacs-server	Configure TACACS+ server related parameters
host	TACACS+ server's DNS name or its IP address
<i>hostipnam</i>	IPV4/IPV6 address or DNS name
test	Parameters to send test packets
<i>s0</i>	user name
password	(Optional) user password in test packets
<i>s1</i>	(Optional) user password
idle-time	(Optional) time interval for monitoring the server
<i>i1</i>	(Optional) time period in minutes

### Command Mode

- /exec/configure

## tacacs-server key 0 6 7

```
{ { [ no ] tacacs-server key { 0 <s0> [ timeout <i0> ] | 6 <s6> [ timeout6 <i6> ] | 7 <s1> [ timeout1 <i1> ] | <s2> [ timeout2 <i2> ] } } } | { no tacacs-server key } }
```

### Syntax Description

no	(Optional) Negate a command or set its defaults
tacacs-server	Configure TACACS+ server related parameters
key	Global TACACS+ server shared secret
0	default TACACS+ shared secret(clear text)
<i>s0</i>	default TACACS+ shared secret(clear text)
timeout	(Optional) Global TACACS+ server timeout period in seconds
<i>i0</i>	(Optional) Global TACACS+ server timeout period in seconds
6	default TACACS+ shared secret(type-6 encrypted)
<i>s6</i>	default TACACS+ shared secret(type-6 encrypted)
timeout6	(Optional) Global TACACS+ server timeout period in seconds
<i>i6</i>	(Optional) Global TACACS+ server timeout period in seconds
7	default TACACS+ shared secret(encrypted)
<i>s1</i>	default TACACS+ shared secret(encrypted)
timeout1	(Optional) Global TACACS+ server timeout period in seconds
<i>i1</i>	(Optional) Global TACACS+ server timeout period in seconds
<i>s2</i>	default TACACS+ shared secret(clear text)
timeout2	(Optional) Global TACACS+ server timeout period in seconds
<i>i2</i>	(Optional) Global TACACS+ server timeout period in seconds

### Command Mode

- /exec/configure

## tacacs-server test

```
[no] tacacs-server test { { username <s0> { [ password <s1> [ idle-time <i1> ] ] | [ idle-time <i1> ] } } | { password <s1> [ idle-time <i1> ] } | { idle-time <i1> } }
```

### Syntax Description

<i>username</i>	<s0>
no	(Optional) Negate a command or set its defaults
tacacs-server	Configure TACACS+ server related parameters
test	Parameters to send test packets
<i>s0</i>	user name
password	(Optional) user password in test packets
<i>s1</i>	(Optional) user password
idle-time	(Optional) time interval for monitoring the server
<i>i1</i>	(Optional) time period in minutes

### Command Mode

- /exec/configure

# tacacs-server timeout

[no] tacacs-server timeout <i0>

## Syntax Description

no	(Optional) Negate a command or set its defaults
tacacs-server	Configure TACACS+ server related parameters
timeout	Global TACACS+ server timeout period in seconds
<i>i0</i>	Global TACACS+ server timeout period in seconds

## Command Mode

- /exec/configure

# tacacs enable

[no] tacacs + enable

## Syntax Description

no	(Optional) Negate a command or set its defaults
enable	Enable tacacs+

## Command Mode

- /exec/configure

# tag

```
{ { no | default } tag | tag <text> }
```

## Syntax Description

no	
default	Set a command to its defaults
tag	User defined tag
<i>text</i>	Tag string line

## Command Mode

- /exec/configure/ip-sla/udp /exec/configure/ip-sla/jitter /exec/configure/ip-sla/tcp  
/exec/configure/ip-sla/icmpEcho /exec/configure/ip-sla/dns /exec/configure/ip-sla/fabricPathEcho  
/exec/configure/ip-sla/http



# tag happens in

```
[no] tag <tag_id> <op> <tag_id> [ <op> <tag_id> [ <op> <tag_id> ] ] happens <threshold> in <interval> |
no tag
```

## Syntax Description

no	(Optional) Negate a command or set its defaults
tag	event tag identifier
<i>tag_id</i>	tag name
<i>op</i>	boolean operator
happens	The number of occurrences before raising the event
<i>threshold</i>	Occurs value
in	Number of occurrences must occur within this time period
<i>interval</i>	Enter seconds value

## Command Mode

- /exec/configure/event-manager-applet

# tahoe-python module

tahoe-python module <module>

## Syntax Description

tahoe-python	enter python mode for tahoe systems
module	Module number of the linecard
<i>module</i>	Enter module number

## Command Mode

- /exec

# tahoe-python module quoted

tahoe-python module <module> quoted <quoted-cmd>

## Syntax Description

tahoe-python	enter python mode for tahoe systems
module	Module number of the linecard
<i>module</i>	Enter module number
quoted	enter the command with quotes Add multiple commands separated by semi-colon
<i>quoted-cmd</i>	the command(s) to run in tahoe python

## Command Mode

- /exec

# tail

```
| tail [ -n <lines> ]
```

## Syntax Description

	Pipe command output to filter
tail	Display last lines
-n	(Optional) modify number of lines (default 10)
<i>lines</i>	(Optional) number of lines to print

## Command Mode

- /output

# tail

tail <uri0> [ <i1> ]

## Syntax Description

tail	Display the last part of a file
<i>uri0</i>	Filename to be displayed
<i>i1</i>	(Optional) Enter the number of lines to be displayed

## Command Mode

- /exec

# tar

```
tar { create <new-archive-file> [ gz-compress | bz2-compress | uncompressed ] + [ remove | absolute | verbose ] + <files> + | append <archive-file> [ remove | absolute | verbose ] + <files> + | extract <archive-file> [ screen | to <dest-dir> | keep-old | verbose ] + | list <archive-file> }
```

## Syntax Description

tar	archiving operations
create	create an archive (merge several files together)
append	append some files to an existing archive
extract	extract files from archive (unmerge them)
verbose	(Optional) display files while merging/extracting
gz-compress	(Optional) compress archive with gzip, the default -> .tar.gz
bz2-compress	(Optional) compress archive with bzip2 -> .tar.bz2
uncompressed	(Optional) dont compress archive -> .tar
remove	(Optional) remove files after adding them to the archive
absolute	(Optional) don't strip leading '/'s from file names
keep-old	(Optional) don't replace existing files when extracting
screen	(Optional) extract files to screen
list	shows the list of files which are part of the archive
<i>new-archive-file</i>	the name of the archive (extension will be added if none of tar/tgz/tar.gz/tar.bz2/tbz2/tar.Z specified)
<i>archive-file</i>	the name of the archive (extension will be added if none of tar/tgz/tar.gz/tar.bz2/tbz2/tar.Z specified)
<i>files</i>	name of file to be added into archive
to	(Optional) extract to specific directory (default is bootflash)
<i>dest-dir</i>	(Optional) destination dir where to extract to (created if not exist), default is bootflash

## Command Mode

- /exec

# tclsh

tclsh <file> [ <args> ] +

## Syntax Description

tclsh	source tclsh script
<i>file</i>	the file to run
<i>args</i>	(Optional) args to tcl script

## Command Mode

- /exec

# tclsh

tclsh

## Syntax Description

tclsh	Execute tclsh
-------	---------------

## Command Mode

- /exec



# tcp-connect

```
[no] tcp-connect { <hostname> | <ip-address> } <dest-port> { [ control { disable | enable } ] [ source-ip { <source-ip-hostname> | <source-ip-address> } ] [ source-port <src-port> ] } +
```

## Syntax Description

no	(Optional)
<i>control</i>	(Optional) enable
<i>source-ip-address</i>	(Optional) <src-port>
tcp-connect	TCP Connect Operation
<i>hostname</i>	Destination hostname, broadcast disallowed
<i>ip-address</i>	Destination IP address, broadcast disallowed
<i>dest-port</i>	Port Number (Recommended port range between 1025-65534)
enable	(Optional) Enable control packets exchange (default)
disable	(Optional) Disable control packets exchange
source-ip	(Optional) Source address
<i>source-ip-hostname</i>	(Optional) source IP hostname, broadcast disallowed
source-port	(Optional) Source Port
<i>src-port</i>	(Optional) Port Number (Recommended port range between 1025-65534)

## Command Mode

- /exec/configure/ip-sla

# telemetry

[no] telemetry

## Syntax Description

no	(Optional) Negate a command or set its default
telemetry	

## Command Mode

- /exec/configure

# telnet

```
{ telnet { <so> | <host> } } [ <i0> ] [ [ source { <host_src> | <interface> } ] [ vrf { <vrf-name> | <vrf-known-name> } ] ]
```

## Syntax Description

telnet	Telnet to another system
<i>so</i>	Enter hostname
<i>host</i>	Enter a valid IPv4 address
source	(Optional) Set source address in IPv4 header
<i>host_src</i>	(Optional) Set IPV4 address as source
<i>interface</i>	(Optional) Set interface to send IPv4 packet
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>i0</i>	(Optional) Enter the port number

## Command Mode

- /exec

# telnet6

```
{ telnet6 { <s1> | <host1> } } [ <i0> ] [ [ source { <host1_src> | <interface> } ] [ vrf { <vrf-name> | <vrf-known-name> } ] ]
```

## Syntax Description

telnet6	Telnet6 to another system using IPv6 addressing
<i>s1</i>	Enter hostname
source	(Optional) Set source address in IPv6 header
<i>interface</i>	(Optional) Set interface to send IPv6 packet
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
<i>i0</i>	(Optional) Enter the port number

## Command Mode

- /exec

# telnet login-attempts

```
{ { telnet login-attempts <d0> } | { no telnet login-attempts [ <d0> ] } }
```

## Syntax Description

no	Negate a command or set its defaults
telnet	telnet login
login-attempts	Set maximum login attempts
<i>d0</i>	Specify max-attempt number

## Command Mode

- /exec/configure/

# telnet server enable

[no] telnet server enable

## Syntax Description

no	(Optional) Negate a command or set its defaults
telnet	Enable telnet
server	Enable telnet
enable	Enable telnet

## Command Mode

- /exec/configure

# template

template <res-mgr-template-known-name-all>

## Syntax Description

template	Change the template for this vdc
<i>res-mgr-template-known-name-all</i>	Resource template for this vdc

## Command Mode

- /exec/configure/vdc

# template data timeout

{ [ no ] template data timeout <time> | no template data timeout }

## Syntax Description

template	Version 9 Template
data	Data
timeout	Template Data resend time
<i>time</i>	Time in seconds

## Command Mode

- /exec/configure/nfm-exporter-v9



# template peer-policy

[no] template peer-policy <peer-policy-template-name>

## Syntax Description

no	(Optional) Negate a command or set its defaults
template	Enter template command mode
peer-policy	Template configuration for policy parameters
<i>peer-policy-template-name</i>	Name of peer-policy template

## Command Mode

- /exec/configure/router-bgp

# template peer-session

[no] template peer-session <peer-session-template-name>

## Syntax Description

no	(Optional) Negate a command or set its defaults
template	Enter template command mode
peer-session	Template configuration for session parameters
<i>peer-session-template-name</i>	Name of peer-session template

## Command Mode

- /exec/configure/router-bgp

# template peer

[no] template peer <peer-template-name>

## Syntax Description

no	(Optional) Negate a command or set its defaults
template	Enter template command mode
peer	Template configuration for peer parameters
<i>peer-template-name</i>	Neighbor template name

## Command Mode

- /exec/configure/router-bgp

# terminal

```
terminal { monitor | no { monitor1 | monitor-force } }
```

## Syntax Description

terminal	Set terminal line parameters
monitor	Copy Syslog output to the current terminal line
no	Negate a command or set its defaults
monitor1	Copy Syslog output to the current terminal line
monitor-force	Copy Syslog output to the current terminal line

## Command Mode

- /exec

# terminal alias

[no] terminal alias [ persist ] [ <alias-name> [ <command> ] ]

## Syntax Description

<i>no</i>	(Optional) Negate a command or set its defaults
<i>terminal</i>	Set terminal line parameters
<i>alias</i>	show aliases (if no arguments) create 'exec' aliases (not persistent). Persistent aliases are in config mode, see 'cli alias
<i>persist</i>	(Optional) add terminal alias to <username>.rc.cli file (auto-executed at login time)
<i>alias-name</i>	(Optional) Name of the alias. (if last argument: shows the value of that alias) Command lines can start with an alias and it will be expanded before parsing. An alias can also be used right after a pipe. The substitution text can contain things like '\$1 \$2' and those \$<number> will be substituted by correspondingly numbered token from the command line starting the counting after the alias.
<i>command</i>	(Optional) Value of the alias (what the alias will be substituted with)

## Command Mode

- /exec

# terminal ask-on-term

[no] terminal ask-on-term <term>

## Syntax Description

no	(Optional) Negate a command or set its defaults
terminal	Set terminal line parameters
ask-on-term	ask backend driven question on given terminal
<i>term</i>	the terminal (/dev/ptsX)

## Command Mode

- /exec

# terminal color

[no] terminal color [ persist ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
terminal	Set terminal line parameters
color	enable colorization of prompt(green if last command ok, red if error), command line (blue), output (default color)
persist	(Optional) add command to <username>.rc.cli file (auto-execed at login time)

## Command Mode

- /exec

# terminal context management

[no] terminal context management

## Syntax Description

no	(Optional) Negate a command or set its defaults
terminal	Set terminal line parameters
context	set the vrf context
management	vrf context management

## Command Mode

- /exec



# terminal deep-help

[no] terminal deep-help

## Syntax Description

no	(Optional) Negate a command or set its defaults
terminal	Set terminal line parameters
deep-help	enable cli syntax and list

## Command Mode

- /exec

# terminal dont-ask

[no] terminal dont-ask [ persist ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
terminal	Set terminal line parameters
dont-ask	Don't ask 'are you sure' questions, take default answer instead
persist	(Optional) add command to <username>.rc.cli file (auto-execed at login time)

## Command Mode

- /exec

# terminal edit-mode vi

[no] terminal edit-mode vi [ persist ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
terminal	Set terminal line parameters
edit-mode	set command line edition keys (vi or emacs emacs is default)
vi	edit like in vi by default in insert-mode, use ~ for command-mode
persist	(Optional) add command to <username>.rc.cli file (auto-execed at login time)

## Command Mode

- /exec

# terminal event-manager bypass

terminal [ <noarg> ] event-manager bypass

## Syntax Description

terminal	Set terminal line parameters
<i>noarg</i>	(Optional)
event-manager	Event manager cli event
bypass	Bypass event manager cli event publish

## Command Mode

- /exec

# terminal history no-exec-in-config

[no] terminal history no-exec-in-config

## Syntax Description

no	(Optional) Negate a command or set its defaults
terminal	Set terminal line parameters
history	configure terminal history properties
no-exec-in-config	don't recall exec commands while in config mode

## Command Mode

- /exec

## terminal history no-exec-in-config

[no] terminal history no-exec-in-config

### Syntax Description

no	(Optional) Negate a command or set its defaults
terminal	Set terminal line parameters
history	configure terminal history properties
no-exec-in-config	don't recall exec commands while in config mode

### Command Mode

- /exec

# terminal history no-exec-in-config

[no] terminal history no-exec-in-config

## Syntax Description

no	(Optional) Negate a command or set its defaults
terminal	Set terminal line parameters
history	configure terminal history properties
no-exec-in-config	don't recall exec commands while in config mode

## Command Mode

- /exec

# terminal home

terminal home

## Syntax Description

terminal	Set terminal line parameters
home	go back to line 1 position 1 without erasing the screen (to be used in cli command loops)

## Command Mode

- /exec



# terminal length

terminal length <i0>

## Syntax Description

terminal	Set terminal line parameters
length	Set number of lines on a screen
<i>i0</i>	Number of lines on screen (0 for no pausing)

## Command Mode

- /exec/configure/console

# terminal length

terminal length <i0>

## Syntax Description

terminal	Set terminal line parameters
length	Set number of lines on a screen
<i>i0</i>	Number of lines on screen (0 for no pausing)

## Command Mode

- /exec

# terminal lock

terminal lock

## Syntax Description

terminal	Set terminal line parameters
lock	Locks the CLI Config mode

## Command Mode

- /exec

# terminal log-all

[no] terminal log-all

## Syntax Description

no	(Optional) Negate a command or set its defaults
terminal	Configure terminal settings
log-all	Accounting log all commands including the show commands

## Command Mode

- /exec/configure

# terminal no

terminal no { length | terminal-type | width }

## Syntax Description

terminal	Set terminal line parameters
no	Negate a command or set its defaults
length	Set number of lines on a screen
terminal-type	Set the terminal type
width	Set width of the display terminal

## Command Mode

- /exec

# terminal output xml

[no] terminal output xml <namespace-version>

## Syntax Description

no	(Optional) Negate a command or set its defaults
terminal	Set terminal line parameters
output	how output of show commands should be formatted
xml	xml output
<i>namespace-version</i>	enter the version for xml output

## Command Mode

- /exec

# terminal output xml

[no] terminal output xml

## Syntax Description

no	(Optional) Negate a command or set its defaults
terminal	Set terminal line parameters
output	how output of show commands should be formatted
xml	xml output

## Command Mode

- /exec

# terminal output xml

[no] terminal output xml

## Syntax Description

no	(Optional) Negate a command or set its defaults
terminal	Set terminal line parameters
output	how output of show commands should be formatted
xml	xml output

## Command Mode

- /exec



# terminal password

terminal password <password> | no terminal password [ <password> ]

## Syntax Description

no	Negate a command or set its defaults
terminal	Set terminal line parameters
password	set a password to be used in copy scp/ftp commands use online help on the argument to disable echo so you don't need to type control-x-e twice (to toggle echo), echo will be re-enabled after carriage-return
<i>password</i>	Enter the password (online help that you just did disabled echo so type your password and press return

## Command Mode

- /exec

# terminal prompt

[no] terminal prompt [ fix [ <name> ] [ with-cr ] | mode | { fq-command | command } | status | exec-time | time | no-echo ] +

## Syntax Description

no	(Optional) Negate a command or set its defaults
terminal	Set terminal line parameters
prompt	configure how the prompt should look like
fix	(Optional) set the prompt to a fix name (default _prompt_)
with-cr	(Optional) add a carriage return at the end of the prompt
<i>name</i>	(Optional) name to use as a fix prompt
mode	(Optional) include the cli mode name (ex: config-if) into the prompt
fq-command	(Optional) include the fully qualified command just executed (formatted like in accounting log)
command	(Optional) include the previous command (not including the mode and mode instance)
status	(Optional) include the status of previous command (0=success)
exec-time	(Optional) include the time it took to execute previous command
time	(Optional) include the time when prompt was printed
no-echo	(Optional) dont echo the typed characters

## Command Mode

- /exec

# terminal redirection-mode

terminal redirection-mode <mode>

## Syntax Description

terminal	Set terminal line parameters
redirection-mode	Set the redirection mode
<i>mode</i>	

## Command Mode

- /exec

# terminal reset-role

terminal reset-role <num>

## Syntax Description

terminal	Set terminal line parameters
reset-role	Reset the privilege role to default
<i>num</i>	Enter the role num

## Command Mode

- /exec

# terminal reset vlan-config-mutex

terminal reset vlan-config-mutex

## Syntax Description

terminal	Set terminal line parameters
reset	Force reset of the vlan config mode mutex
vlan-config-mutex	Vlan configuration mutex

## Command Mode

- /exec

# terminal session-timeout

terminal session-timeout <i0>

## Syntax Description

terminal	Set terminal line parameters
session-timeout	Set session timeout
<i>i0</i>	Enter timeout in minutes, 0 to disable

## Command Mode

- /exec

# terminal sticky-mode

terminal [ <noarg> ] sticky-mode

## Syntax Description

terminal	Set terminal line parameters
<i>noarg</i>	(Optional)
sticky-mode	Search for the command match in current mode only

## Command Mode

- /exec

# terminal terminal-type

terminal terminal-type <*s0*>

## Syntax Description

terminal	Set terminal line parameters
terminal-type	Set the terminal type
<i>s0</i>	Terminal type

## Command Mode

- /exec



# terminal time

terminal time [ <name> ] [ delta ]

## Syntax Description

terminal	Set terminal line parameters
time	save the current time under a variable
<i>name</i>	(Optional) the variable to store the time in
delta	(Optional) print the delta time to the currently saved time value

## Command Mode

- /exec

# terminal tree-update

terminal tree-update

## Syntax Description

terminal	Set terminal line parameters
tree-update	Updates the main parse tree

## Command Mode

- /exec

# terminal unlock

terminal unlock

## Syntax Description

terminal	Set terminal line parameters
unlock	Force unlocking of the CLI config mode

## Command Mode

- /exec

# terminal verify-only

terminal [ <noarg> ] verify-only [ username <user> ]

## Syntax Description

terminal	Set terminal line parameters
<i>noarg</i>	(Optional)
verify-only	Verify command and do not execute
username	(Optional) Username for aaa authorization
<i>user</i>	(Optional) Username for aaa authorization

## Command Mode

- /exec

# terminal width

terminal width <*i0*>

## Syntax Description

terminal	Set terminal line parameters
width	Set width of the display terminal
<i>i0</i>	Number of characters on a screen line

## Command Mode

- /exec/configure/console

# terminal width

terminal width <*i0*>

## Syntax Description

terminal	Set terminal line parameters
width	Set width of the display terminal
<i>i0</i>	Number of characters on a screen line

## Command Mode

- /exec

# threshold-percent

```
threshold-percent { percent-threshold { percentup <up-percentage> [ percentdown<down-percentage> ] |  
percentdown<down-percentage> [ percentup <up-percentage> ] } } | no threshold-percent { percent-threshold  
}
```

## Syntax Description

no	Negate a command or set its defaults
threshold-percent	Threshold parameters
percent-threshold	Percentage threshold
percentup	Up threshold
<i>up-percentage</i>	Up threshold percentage

## Command Mode

- /exec/configure/tr-list-thrp

# threshold

{ { no | default } threshold | threshold <milliseconds> }

## Syntax Description

no	
default	Set a command to its defaults
threshold	Operation threshold
<i>milliseconds</i>	Millisecond threshold value

## Command Mode

- /exec/configure/ip-sla/udp /exec/configure/ip-sla/jitter /exec/configure/ip-sla/tcp  
/exec/configure/ip-sla/icmpEcho /exec/configure/ip-sla/dns /exec/configure/ip-sla/fabricPathEcho  
/exec/configure/ip-sla/http



# time-range

[no] time-range <name>

## Syntax Description

no	(Optional) Negate a command or set its defaults
time-range	Define time range entries
<i>name</i>	Time range name

## Command Mode

- /exec/configure

# timeout

{ { no | default } timeout |

## Syntax Description

no	
default	Set a command to its defaults
timeout	Timeout of an operation

## Command Mode

- /exec/configure/ip-sla/udp /exec/configure/ip-sla/jitter /exec/configure/ip-sla/tcp  
/exec/configure/ip-sla/icmpEcho /exec/configure/ip-sla/dns /exec/configure/ip-sla/fabricPathEcho  
/exec/configure/ip-sla/http

# timer

timer <value> | no timer

## Syntax Description

no	Negate a command or set its defaults
timer	Configure Bundle timer value
<i>value</i>	Hello timer value

## Command Mode

- /exec/configure/anycast

# timers

timers <keepalive-interval> <hold-time> | { no | default } timers [ <keepalive-interval> <hold-time> ]

## Syntax Description

no	Negate a command or set its defaults
default	Inherit values from a peer template
timers	Configure keepalive and hold timers
<i>keepalive-interval</i>	Keepalive interval (seconds)
<i>hold-time</i>	Holdtime (seconds)

## Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor-sess

# timers

```
timers { <hello-time> { <hold-time> | ms-hold <hold-time-msec> } | ms-hello <hello-time-msec> {
<hold-time-sec> | msec-hold <hold-time-msec> } | redirect <redirect-time> <sec-hold-time> } | no timers [
{ <hello-time> [ { <hold-time> | ms-hold <hold-time-msec> } ] | ms-hello [ <hello-time-msec> [
<hold-time-sec> | msec-hold <hold-time-msec> ] ] | redirect [ <redirect-time> [ <sec-hold-time> ] ] } ]
```

## Syntax Description

no	Negate a command or set its defaults
timers	Adjust GLBP timers
<i>hello-time</i>	Specify Hello interval in seconds
<i>hold-time</i>	Specify Hold time in seconds
ms-hold	Specify hold time in milliseconds
<i>hold-time-msec</i>	Hold time in milliseconds
ms-hello	Specify hello interval in milliseconds
<i>hello-time-msec</i>	hello interval in milliseconds
<i>hold-time-sec</i>	Hold time in seconds
msec-hold	Specify hold time in milliseconds
redirect	Specify time-out value for failed forwarders
<i>redirect-time</i>	Interval in seconds to redirect to failed forwarders
<i>sec-hold-time</i>	Time-out interval in seconds for failed forwarders

## Command Mode

- /exec/configure/if-eth-any/glbp

# timers

```
[no] timers { nsf { route-hold <hold-interval> | converge <converge-interval> | signal <signal-interval> } |
active-time [ <max-active-time> | disabled ] }
```

## Syntax Description

no	(Optional) Negate a command or set its defaults
timers	Set EIGRP timers
nsf	EIGRP NSF timer
route-hold	EIGRP hold time for routes learned from nsf peer
<i>hold-interval</i>	Seconds
active-time	EIGRP time limit for active state
<i>max-active-time</i>	(Optional) EIGRP active-state time limit in minutes
disabled	(Optional) disable EIGRP time limit for active state
converge	EIGRP time limit for convergence after switchover
<i>converge-interval</i>	Seconds
signal	EIGRP time limit for signaling NSF restart
<i>signal-interval</i>	Seconds

## Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-common

# timers

timers { <hello-time> { <hold-time> | msec-hold <msec-hold> } | msec-hello <msec-hello> { <hold-time> | msec-hold <msec-hold> } } | no timers

## Syntax Description

no	Negate a command or set its defaults
timers	Hello and hold timers
<i>hello-time</i>	Hello interval in seconds
<i>hold-time</i>	Hold time in seconds
msec-hold	Specify hold interval in milliseconds
<i>msec-hold</i>	Hold interval in milliseconds
msec-hello	Specify hello interval in milliseconds
<i>msec-hello</i>	Hello interval in milliseconds

## Command Mode

- /exec/configure/if-eth-any/hsrp\_ipv4 /exec/configure/if-eth-any/hsrp\_ipv6

# timers advertise

[no] timers advertise | timers advertise <val>

## Syntax Description

no	Negate a command or set its defaults
timers	Set the VRRP timers
advertise	Set the advertise timer
<i>val</i>	Advertisement interval in milliseconds

## Command Mode

- /exec/configure/if-eth-any/vrrpv3



## timers basic

timers basic <update> <invalid> <holddown> <garbage> | no timers basic [ <update> <invalid> <holddown> <garbage> ]

### Syntax Description

no	Negate a command or set its defaults
timers	RIP set timers
basic	RIP set basic timers
<i>update</i>	RIP update period
<i>invalid</i>	RIP route timeout period
<i>holddown</i>	RIP route holddown period
<i>garbage</i>	RIP route garbage period

### Command Mode

- /exec/configure/router-rip/router-rip-af-common /exec/configure/router-rip/router-rip-vrf-af-common

## timers bestpath-defer maximum

[no] timers bestpath-defer <bestpath-defer-time> maximum <bestpath-defer-time-max>

### Syntax Description

no	(Optional) Negate a command or set its defaults
timers	Configure bgp related timers
bestpath-defer	Configure bestpath defer timer value for batch prefix processing
<i>bestpath-defer-time</i>	Bestpath defer time (mseconds)
maximum	Configure bestpath defer timer maximum value
<i>bestpath-defer-time-max</i>	Maximum bestpath defer time (mseconds)

### Command Mode

- /exec/configure/router-bgp/router-bgp-af

## timers bestpath-limit

timers bestpath-limit <bestpath-timeout> [ always ] | no timers bestpath-limit [ <bestpath-timeout> ]

### Syntax Description

no	Negate a command or set its defaults
timers	Configure bgp related timers
bestpath-limit	Configure timeout for first bestpath after restart
<i>bestpath-timeout</i>	Bestpath timeout (seconds)
always	(Optional) Configure update-delay-always option

### Command Mode

- /exec/configure/router-bgp/vrf-cmds

# timers bgp

[no] timers bgp <keepalive-interval> <hold-time>

## Syntax Description

no	(Optional) Negate a command or set its defaults
timers	Configure bgp related timers
bgp	Configure different bgp keepalive and holdtimes
<i>keepalive-interval</i>	Keepalive interval (seconds)
<i>hold-time</i>	Holdtime (seconds)

## Command Mode

- /exec/configure/router-bgp/vrf-cmds

# timers lsa-arrival

```
{ { timers lsa-arrival <interval> } | { no timers lsa-arrival [ <interval> ] } }
```

## Syntax Description

no	Negate a command or set its defaults
timers	Configure timer related constants
lsa-arrival	Mimimum interval between arrival of a LSA
<i>interval</i>	Interval value (milliseconds)

## Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

# timers lsa-arrival

```
{ { timers lsa-arrival <interval> } | { no timers lsa-arrival [ <interval> ] } }
```

## Syntax Description

no	Negate a command or set its defaults
timers	Configure timer related constants
lsa-arrival	Mimimum interval between arrival of a LSA
<i>interval</i>	Interval value (millisecond)

## Command Mode

- /exec/configure/router-ospf3 /exec/configure/router-ospf3/vrf

# timers lsa-group-pacing

```
{ { timers lsa-group-pacing <interval> } | { no timers lsa-group-pacing [ <interval> ] } }
```

## Syntax Description

no	Negate a command or set its defaults
timers	Configure timer related constants
lsa-group-pacing	LSA group refresh/maxage interval
<i>interval</i>	Interval value (seconds)

## Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

## timers lsa-group-pacing

```
{ { timers lsa-group-pacing <interval> } | { no timers lsa-group-pacing [ <interval> ] } }
```

### Syntax Description

no	Negate a command or set its defaults
timers	Configure timer related constants
lsa-group-pacing	LSA group refresh/maxage interval
<i>interval</i>	Interval value (seconds)

### Command Mode

- /exec/configure/router-ospf3 /exec/configure/router-ospf3/vrf



## timers prefix-peer-timeout

timers prefix-peer-timeout <prefixpeer-timeout> | no timers prefix-peer-timeout [ <prefixpeer-timeout> ]

### Syntax Description

no	Negate a command or set its defaults
timers	Configure bgp related timers
prefix-peer-timeout	Configure how long state for a prefix peer is maintained
<i>prefixpeer-timeout</i>	Prefix Peer timeout (seconds)

### Command Mode

- /exec/configure/router-bgp/vrf-cmds

# timers prefix-peer-wait

timers prefix-peer-wait <prefixpeer-wait> | no timers prefix-peer-wait [ <prefixpeer-wait> ]

## Syntax Description

no	Negate a command or set its defaults
timers	Configure bgp related timers
prefix-peer-wait	Configure wait timer for a prefix peer
<i>prefixpeer-wait</i>	Prefix peer wait timer (seconds)

## Command Mode

- /exec/configure/router-bgp/vrf-cmds

## timers throttle lsa

```
{ { timers throttle lsa <start-time> <hold-time> <max-time> } | { no timers throttle lsa [ <start-time>  
<hold-time> <max-time> ] } }
```

### Syntax Description

no	Negate a command or set its defaults
timers	Configure timer related constants
throttle	Set rate-limiting values (milliseconds)
lsa	Set rate-limiting for LSA generation
<i>start-time</i>	Start interval (milliseconds)
<i>hold-time</i>	Hold interval (milliseconds)
<i>max-time</i>	Max interval (milliseconds)

### Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

## timers throttle lsa

```
{ { timers throttle lsa <start-time> <hold-time> <max-time> } | { no timers throttle lsa [ <start-time>
<hold-time> <max-time> ] } }
```

### Syntax Description

no	Negate a command or set its defaults
timers	Configure timer related constants
throttle	Set rate-limiting values (milliseconds)
lsa	Set rate-limiting for LSA generation
<i>start-time</i>	Start interval (milliseconds)
<i>hold-time</i>	Hold interval (milliseconds)
<i>max-time</i>	Max interval (milliseconds)

### Command Mode

- /exec/configure/router-ospf3 /exec/configure/router-ospf3/vrf

## timers throttle spf

```
{ { timers throttle spf <start-time> <hold-time> <max-time> } | { no timers throttle spf [ <start-time> <hold-time> <max-time> ] } }
```

### Syntax Description

no	Negate a command or set its defaults
timers	Configure timer related constants
throttle	Configure timer related constants
spf	OSPF SPF timers
<i>start-time</i>	Initial SPF schedule delay in milliseconds
<i>hold-time</i>	Minimum hold time between SPF calculations
<i>max-time</i>	Maximum wait time between SPF calculations

### Command Mode

- /exec/configure/router-ospf /exec/configure/router-ospf/vrf

## timers throttle spf

```
{ { timers throttle spf <start-time> <hold-time> <max-time> } | { no timers throttle spf [ <start-time>
<hold-time> <max-time> ] } }
```

### Syntax Description

no	Negate a command or set its defaults
timers	Configure timer related constants
throttle	Configure timer related constants
spf	OSPF SPF timers
<i>start-time</i>	Initial SPF schedule delay in milliseconds
<i>hold-time</i>	Minimum hold time between SPF calculations
<i>max-time</i>	Maximum wait time between SPF calculations

### Command Mode

- /exec/configure/router-ospf3/router-ospf3-af-ipv6 /exec/configure/router-ospf3/vrf/router-ospf3-af-ipv6

# tls

[no] tls

## Syntax Description

no	(Optional) Negate a command or set its defaults
tls	One Platform TLS transport configuration mode

## Command Mode

- /exec/configure/onep

# topology

[no] topology <tpg-id>

## Syntax Description

no	(Optional) Negate a command or set its defaults
topology	Configure Layer-2 Topology for IS-IS
<i>tpg-id</i>	L2 Topology ID 1-63

## Command Mode

- /exec/configure/l2mp-isis/l2mp-isis-vrf-common



# topology holddown sigerr

[no] topology holddown sigerr | topology holddown sigerr <sec>

## Syntax Description

no	Negate a command or set its defaults
topology	Topology Database Configuration
holddown	Topology Database hold down timers
sigerr	Link hold down time for signalling errors
<i>sec</i>	Hold down time in seconds

## Command Mode

- /exec/configure/te

# tos

{ { no | default } tos | tos <tos-value> }

## Syntax Description

no	
default	Set a command to its defaults
tos	Type of Service
<i>tos-value</i>	Type of Service Value

## Command Mode

- /exec/configure/ip-sla/udp /exec/configure/ip-sla/jitter /exec/configure/ip-sla/tcp  
/exec/configure/ip-sla/icmpEcho /exec/configure/ip-sla/http

## tr

```
| tr [ -c | -d | -s | -t ] + <SET1> [ <SET2> ]
```

**Syntax Description**

	Pipe command output to filter
tr	Translate, squeeze, and/or delete characters
-c	(Optional) first complement SET1
-d	(Optional) delete characters in SET1, do not translate
-s	(Optional) replace each sequence of a repeated character from SET1 with single occurrence of that character
-t	(Optional) first truncate SET1 to length of SET2
<i>SET1</i>	character SET1: CHAR1-CHAR2 = all characters from CHAR1 to CHAR2 in ascending order special chars: (tab) (new line) [:alnum:] [:alpha:] [:digit:] [:graph:] (printable, no space) [:print:] (printable, with space) [:lower:] [:upper:] [:space:] (tab or space)
<i>SET2</i>	(Optional) character SET2 (for translation length is extended to length of SET1 by repeating last char, excess chars are ignored): format same as SET1 [CHAR*] = copies of CHAR until length of SET1 [CHAR*REPEAT] = REPEAT copies of CHAR

**Command Mode**

- /output

## trace buffer size

trace buffer { error | warning | event } size <size>

### Syntax Description

trace	MPLS static trace
buffer	MPLS static trace buffer
error	MPLS static error trace
warning	MPLS static warning trace
event	MPLS static event trace
size	trace buffer size in Kbytes
<i>size</i>	trace buffer size in Kbytes

### Command Mode

- /exec/configure/mpls\_static

# traceroute

```
traceroute { <host> | <hostname> } [ port <portnumber> ] [ [ source-interface <src-intf> ] | [ source { <host> | <hostname> | <interface> } ] ] [ vrf { <vrf-name> | <vrf-known-name> } ] ] ]
```

## Syntax Description

traceroute	Traceroute
<i>host</i>	IP address of remote system
<i>hostname</i>	Hostname of remote system
port	(Optional) Set destination port
<i>portnumber</i>	(Optional) Enter destination port number
source	(Optional) Set source address in IP header
<i>interface</i>	(Optional) Interface
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
source-interface	(Optional) Select source interface
<i>src-intf</i>	(Optional) Specify interface

## Command Mode

- /exec

# tracert6

```
tracert6 { <host> | <hostname> } [ [ source { <host> | <hostname> | <interface> } ] [ vrf { <vrf-name> | <vrf-known-name> } ] ] [ source-interface <src-intf> ] ]
```

## Syntax Description

tracert6	Tracert6
<i>hostname</i>	Hostname of remote system
source	(Optional) Set source address in IPv6 header
<i>interface</i>	(Optional) Interface
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
source-interface	(Optional) Select source interface
<i>src-intf</i>	(Optional) Specify interface

## Command Mode

- /exec

## traceroute nve

```
traceroute nve { { { ip { <numeric10> | <numeric11> | unknown } } [ vrf { <vrf-name> | <vrf-known-name>
} ] { <dot1qid1> } ] } | mac <dmac> <dot1qid> <intfid> } [ profile <pid> ] [ payload { [ mac-addr <dstmac>
<smac> ] [ dot1q <dot1q-id> ] [ ip <dstip> <srcip> | ipv6 <dstipv6> <srcipv6> ] [ port <sport> <dport> ] [
proto <proto-id> ] } payload-end ] [ source { <numeric1> | <numeric2> } ]
```

### Syntax Description

traceroute	Test
nve	network virtualization edge
<i>numeric10</i>	Ipv4 address of remote host / VTEP
unknown	Peer vtep ip is unknown, will be derived from payload
<i>intfid</i>	Name of the interface for ngoam traceroute on which dot1q is configured
profile	(Optional) NGOAM profile to use
<i>pid</i>	(Optional) NGOAM profile id
mac	Mac
<i>dmac</i>	Destination mac address
<i>dot1qid</i>	Encapsulation dot1q/bd on which the mac is learnt
<i>dot1qid1</i>	(Optional) Encapsulation dot1q/bd on which the mac is learnt
vrf	(Optional) Display per-VRF information
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
source	(Optional) Source
<i>numeric1</i>	(Optional) IP
payload	(Optional) Enter customer payload
mac-addr	(Optional) Mac
<i>dstmac</i>	(Optional) Destination mac address
<i>smac</i>	(Optional) Source mac address
dot1q	(Optional) Encapsulation dot1q/bd
<i>dot1q-id</i>	(Optional) Encapsulation dot1q/bd on which the mac is learnt
ip	ip address

<i>dstip</i>	(Optional) Destination ipv4 address
<i>srcip</i>	(Optional) source ipv4 address
<i>ipv6</i>	(Optional) ipv6 address
<i>port</i>	(Optional) L4 port info
<i>sport</i>	(Optional) Source port
<i>dport</i>	(Optional) Destination port
<i>proto</i>	(Optional) Protocol
<i>proto-id</i>	(Optional) IANA Protocol id
<i>payload-end</i>	(Optional) End payload info input

**Command Mode**

- /exec



# track-adjacency-nexthop

[no] track-adjacency-nexthop

## Syntax Description

no	(Optional) Negate a command or set its defaults
track-adjacency-nexthop	Track next-hop for same-site Overlay adjacencies

## Command Mode

- /exec/configure/otv-isis

# track

```
track <object-id> { list { boolean <bool-val> } }
```

## Syntax Description

track	Object tracking configuration command
<i>object-id</i>	Tracked Object
list	Object tracking list
boolean	boolean list type
<i>bool-val</i>	boolean list type

## Command Mode

- /exec/configure

# track

track <object-id>

## Syntax Description

track	Object tracking deletion command
<i>object-id</i>	Tracked Object

## Command Mode

- /exec/configure

# track

[no] track <object-id> [ force ]

## Syntax Description

no	Negate a command or set its defaults
track	Object tracking deletion command
<i>object-id</i>	Tracked Object
force	(Optional) Completely remove the object

## Command Mode

- /exec/configure

# track

```
track <object-id> { { ip_v4 route <route-prefix> reachability [ hmm ] } | { ip_v6 routev6 <v6route-prefix> reachability [ hmm ] } }
```

## Syntax Description

track	Object tracking configuration command
<i>object-id</i>	Tracked Object
ip_v4	IPv4 protocol
route	IPv4 route
<i>route-prefix</i>	Specify ipv4 route prefix
ip_v6	IPv6 protocol
routev6	IPv6 route
reachability	Route reachability state
hmm	(Optional) Track routes owned by hmm

## Command Mode

- /exec/configure

# track

```
track <object-id> { ip_v4 sla <sla-id> [ sla_reachability | sla_state ] }
```

## Syntax Description

track	Object tracking configuration command
<i>object-id</i>	Tracked Object
ip_v4	IPv4 protocol
sla	IP Service Level Agreement
<i>sla-id</i>	Entry number
sla_reachability	(Optional) Reachability
sla_state	(Optional) return code state

## Command Mode

- /exec/configure

# track

```
track <object-id> { list threshold <weight-val> }
```

## Syntax Description

track	Object tracking configuration command
<i>object-id</i>	Tracked Object
list	Object tracking list
threshold	threshold type
<i>weight-val</i>	threshold weight type

## Command Mode

- /exec/configure

# track

```
track <object-id> { list threshold <percentage-val> }
```

## Syntax Description

track	Object tracking configuration command
<i>object-id</i>	Tracked Object
list	Object tracking list
threshold	threshold type
<i>percentage-val</i>	threshold percentage type

## Command Mode

- /exec/configure



# track

track <track-obj> | no track <track-obj>

## Syntax Description

no	Negate a command or set its defaults
track	Tracking object to suspend vPC if object goes down
<i>track-obj</i>	Tracked object

## Command Mode

- /exec/configure/vpc-domain

# track

[no] track <object-number> [ decrement <value> ]

## Syntax Description

no	(Optional) Negate a command or set its defaults
track	Associates track object to HSRP group
<i>object-number</i>	Set the object number to the group
decrement	(Optional) Decrements when tracked object goes down
<i>value</i>	(Optional) Set the value to decrement from priority

## Command Mode

- /exec/configure/if-eth-any/hsrp\_ipv4 /exec/configure/if-eth-any/hsrp\_ipv6

# track

track <object-number> | no track

## Syntax Description

no	Negate a command or set its defaults
track	Associates track object to Anycast Bundle
<i>object-number</i>	Set the object number

## Command Mode

- /exec/configure/anycast

# track data

[no] track data <loc-uri>

## Syntax Description

no	(Optional) Negate a command or set its defaults
data	User files to preserve
track	Track file uri
<i>loc-uri</i>	Enter file uri

## Command Mode

- /exec/configure/personality

# track interface

```
track <object-id> interface <ifnum> { line-protocol | ipv4 routing | ipv6 routingv6 }
```

## Syntax Description

track	Object tracking configuration commands
<i>object-id</i>	Tracked Object
interface	Interface to track
<i>ifnum</i>	Interface type and number
line-protocol	Track interface line-protocol
ipv4	IPv4 parameters
routing	Track interface ipv4 routing
ipv6	IPv6 parameters
routingv6	Track interface ipv6 routing

## Command Mode

- /exec/configure

## track interface priority

```
{ { track { { interface <intf_num> priority <priority_value> } | { <object-num> [ decrement <decrement-value> ] } } } | { no track [ { { interface <intf_num> priority <priority_value> } | { <object-num> [ decrement <decrement-value> ] } } ] } }
```

### Syntax Description

no	Negate a command or set its defaults
track	Track the availability of another interface/object
interface	Select the tracked interface(Native tracking)
<i>intf_num</i>	
priority	Vr priority used when the tracked interface is down
<i>priority_value</i>	
<i>object-num</i>	Set the object number to the group(Object tracking)
decrement	(Optional) Decrements priority when tracked object goes down
<i>decrement-value</i>	(Optional) Set the value to decrement from priority

### Command Mode

- /exec/configure/if-eth-any/vrrp

## track running-state track startup-state

[no] track running-state | [ no ] track startup-state

### Syntax Description

no	(Optional) Negate a command or set its defaults
track	Track file uri
running-state	active patches, third-party RPMs, and running-config
startup-state	committed patches, third-party RPMs, and startup-config

### Command Mode

- /exec/configure/personality

# traffic-class

```
{ { no | default } traffic-class | traffic-class <traffic-class> }
```

## Syntax Description

no	
default	Set a command to its defaults
traffic-class	Traffic Class
<i>traffic-class</i>	Traffic Class Value

## Command Mode

- /exec/configure/ip-sla/udp /exec/configure/ip-sla/jitter /exec/configure/ip-sla/tcp  
/exec/configure/ip-sla/icmpEcho /exec/configure/ip-sla/http



# traffic-share

[no] traffic-share { balanced | { min across-interfaces } }

## Syntax Description

no	(Optional) Negate a command or set its defaults
traffic-share	How to compute traffic share over alternate paths
balanced	Share inversely proportional to metric
min	All traffic shared among min metric paths
across-interfaces	Use different interfaces for equal-cost paths

## Command Mode

- /exec/configure/router-eigrp/router-eigrp-vrf-common /exec/configure/router-eigrp/router-eigrp-af-common

# transmit-delay

```
{ { transmit-delay <delay> } | { no transmit-delay [ <delay> ] } }
```

## Syntax Description

no	Negate a command or set its defaults
transmit-delay	Packet transmission delay
<i>delay</i>	(seconds)

## Command Mode

- /exec/configure/router-ospf/vrf/router-ospf-slink

# transmit-delay

```
{ { transmit-delay <delay> } | { no transmit-delay [ <delay> ] } }
```

## Syntax Description

no	Negate a command or set its defaults
transmit-delay	Packet transmission delay
<i>delay</i>	(seconds)

## Command Mode

- /exec/configure/router-ospf/router-ospf-vlink /exec/configure/router-ospf/vrf/router-ospf-vlink

# transmit-delay

```
{ { transmit-delay <delay> } | { no transmit-delay [ <delay> ] } }
```

## Syntax Description

no	Negate a command or set its defaults
transmit-delay	Packet transmission delay
<i>delay</i>	(seconds)

## Command Mode

- /exec/configure/router-ospf3/router-ospf3-vlink /exec/configure/router-ospf3/vrf/router-ospf3-vlink

## transport connection-mode passive

[ no | default ] transport connection-mode passive

### Syntax Description

no	(Optional) Negate a command or set its defaults
default	(Optional) Inherit values from a peer template
transport	BGP transport connection
connection-mode	Specify type of connection
passive	Allow passive connection setup only

### Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor /exec/configure/router-bgp/router-bgp-neighbor-stmp  
/exec/configure/router-bgp/router-bgp-vrf-neighbor  
/exec/configure/router-bgp/router-bgp-template-neighbor

# transport email

```
{ transport email { from <s0> | reply-to <s1> | smtp-server { <hostipv4> | <hostipv6> | <hostname> } [ port <i1> ] [ use-vrf <s2> ] } | no transport email smtp-server | no transport email { from | reply-to } }
```

## Syntax Description

no	Negate a command or set its defaults
transport	Configure transport related configuration
email	Configure email transport related configuration
from	Configure from email address
<i>s0</i>	Provide from email address, example: SJ-9500-1@xyz.com
reply-to	Configure replyto email address
<i>s1</i>	Provide reply-to email address, example: admin@xyz.com
smtp-server	Configure SMTP server address
<i>hostname</i>	SMTP server(DNS name or IPv4 or IPv6 address)
<i>hostipv4</i>	IPV4 address of SMTP server
port	(Optional) Configure SMTP server port (default:25)
<i>i1</i>	(Optional) SMTP server port
use-vrf	(Optional) Configure vrf name
<i>s2</i>	(Optional) vrf name

## Command Mode

- /exec/configure/callhome

## transport email mail-server

```
{ [ no ] transport email mail-server { <hostipv4> | <hostipv6> | <hostname> } [ port <i1> ] [ priority <i2> ]
[ use-vrf <s2> ] }
```

### Syntax Description

no	(Optional) Negate a command or set its defaults
transport	Configure transport related configuration
email	Configure email transport related configuration
mail-server	Configure SMTP server address (for supporting multiple SMTP-servers)
<i>hostname</i>	SMTP server(DNS name or IPv4 or IPv6 address)
<i>hostipv4</i>	IPV4 address of SMTP server
port	(Optional) Configure SMTP server port (default:25)
<i>i1</i>	(Optional) SMTP server port
use-vrf	(Optional) Configure vrf name
<i>s2</i>	(Optional) vrf name
priority	(Optional) Configure SMTP server priority (1-100) (default:50)
<i>i2</i>	(Optional) SMTP server priority

### Command Mode

- /exec/configure/callhome

# transport http proxy enable

[no] transport http proxy enable

## Syntax Description

no	(Optional) Negate a command or set its defaults
transport	Configure transport related configuration
http	Configure transport option for http urls
proxy	Configure proxy for http transport
enable	Enable the usage of proxy server for messages sent over http(s)

## Command Mode

- /exec/configure/callhome



## transport http proxy server

```
{ transport http proxy server { <hostname> } [ port <i1> ] } | { no transport http proxy server }
```

### Syntax Description

no	Negate a command or set its defaults
transport	Configure transport related configuration
http	Configure transport option for http urls
proxy	Configure proxy for http transport
server	Configure proxy server address and port
<i>hostname</i>	Proxy server name or IP address(DNS name or IPv4 or IPv6 address)
port	(Optional) Configure Proxy server port (default:8080)
<i>i1</i>	(Optional) Proxy server port

### Command Mode

- /exec/configure/callhome

## transport http use-vrf

transport http use-vrf <s2> | no transport http use-vrf

### Syntax Description

no	Negate a command or set its defaults
transport	Configure transport related configuration
http	Configure transport option for http urls
use-vrf	Configure vrf name
s2	vrf name

### Command Mode

- /exec/configure/callhome

## transport type tcp

```
[no] transport type { { tcp [ port <tpportnum> ] [ access-class <aclname> ] } | { tls [ {
disable-remotecert-validation [ { localcert <localtp> [ { port <tpportnum> [ access-class <aclname> ] } ] | {
access-class <aclname> [ port <tpportnum> ] } ] } | { port <tpportnum> [ { localcert <localtp> [ access-class
<aclname> ] } ] | { access-class <aclname> [ localcert <localtp> ] } ] } | { access-class <aclname> [ { localcert
<localtp> [ port <tpportnum> ] | { port <tpportnum> [ localcert <localtp> ] } ] } ] | { localcert <localtp> [ {
disable-remotecert-validation [ { port <tpportnum> [ access-class <aclname> ] } | { access-class <aclname> [
port <tpportnum> ] } ] } | { port <tpportnum> [ { disable-remotecert-validation [ access-class <aclname> ] } |
{ access-class <aclname> [ disable-remotecert-validation ] } ] } | { access-class <aclname> [ {
disable-remotecert-validation [ port <tpportnum> ] } | { port <tpportnum> [ disable-remotecert-validation ] } ]
} ] | { port <tpportnum> [ { disable-remotecert-validation [ { localcert <localtp> [ access-class <aclname> ]
} ] | { access-class <aclname> [ localcert <localtp> ] } ] } ] | { localcert <localtp> [ { disable-remotecert-validation
[ access-class <aclname> ] } | { access-class <aclname> [ disable-remotecert-validation ] } ] } | { access-class
<aclname> [ { disable-remotecert-validation [ localcert <localtp> ] } | { localcert <localtp> [
disable-remotecert-validation ] } ] } ] } | { access-class <aclname> [ { disable-remotecert-validation [ {
localcert <localtp> [ port <tpportnum> ] | { port <tpportnum> [ localcert <localtp> ] } ] } | { localcert <localtp>
[ { disable-remotecert-validation [ port <tpportnum> ] } | { port <tpportnum> [ disable-remotecert-validation ]
} ] } ] | { port <tpportnum> [ { disable-remotecert-validation [ localcert <localtp> ] } | { localcert <localtp> [
disable-remotecert-validation ] } ] } ] } | { remotecert <remotetp> [ { localcert <localtp> [ { port <tpportnum>
[ access-class <aclname> ] } | { access-class <aclname> [ port <tpportnum> ] } ] } | { port <tpportnum> [ {
localcert <localtp> [ access-class <aclname> ] } | { access-class <aclname> [ localcert <localtp> ] } ] } ] | {
access-class <aclname> [ { localcert <localtp> [ port <tpportnum> ] | { port <tpportnum> [ localcert <localtp>
} ] } ] } ] | { localcert <localtp> [ { remotecert <remotetp> [ { port <tpportnum> [ access-class <aclname> ] }
] | { access-class <aclname> [ port <tpportnum> ] } ] } ] | { port <tpportnum> [ { remotecert <remotetp> [ access-class
<aclname> ] } | { access-class <aclname> [ remotecert <remotetp> ] } ] } ] | { access-class <aclname> [ {
remotecert <remotetp> [ port <tpportnum> ] } | { port <tpportnum> [ remotecert <remotetp> ] } ] } ] } | { port
<tpportnum> [ { remotecert <remotetp> [ { localcert <localtp> [ access-class <aclname> ] } | { access-class
<aclname> [ localcert <localtp> ] } ] } ] | { localcert <localtp> [ { remotecert <remotetp> [ access-class
<aclname> ] } | { access-class <aclname> [ remotecert <remotetp> ] } ] } ] | { access-class <aclname> [ {
remotecert <remotetp> [ localcert <localtp> ] } | { localcert <localtp> [ remotecert <remotetp> ] } ] } ] } ] | {
access-class <aclname> [ { remotecert <remotetp> [ { localcert <localtp> [ port <tpportnum> ] } | { port
<tpportnum> [ localcert <localtp> ] } ] } ] | { localcert <localtp> [ { remotecert <remotetp> [ port <tpportnum>
} ] } | { port <tpportnum> [ remotecert <remotetp> ] } ] } ] | { port <tpportnum> [ { remotecert <remotetp> [ localcert
<localtp> ] } | { localcert <localtp> [ remotecert <remotetp> ] } ] } ] } ] } ] }
```

### Syntax Description

no	(Optional) Negate a command or set its defaults
transport	Transport command
type	Session transport
tcp	TCP transport
tls	TLS transport
disable-remotecert-validation	(Optional) Disable Remote Certificate Validation
localcert	(Optional) Local Certificate

<i>localtp</i>	(Optional) Local Trust Point Name
<i>remotecert</i>	(Optional) Remote Certificate Validation
<i>remotetp</i>	(Optional) Remote Trust Point Name
<i>port</i>	(Optional) Port number
<i>tpportnum</i>	(Optional) Number
<i>access-class</i>	(Optional) Filter incoming connections based on IP access list
<i>aclname</i>	(Optional) IP access list name

**Command Mode**

- /exec/configure/onep

# transport udp

```
{ [ no ] transport udp <portnumber> | no transport udp }
```

## Syntax Description

transport	Transport Destination Port
udp	Destination UDP Port
<i>portnumber</i>	Destination UDP Port

## Command Mode

- /exec/configure/nfm-exporter

# trigger forwarding distribution module

trigger forwarding distribution module <module>

## Syntax Description

trigger	Trigger
forwarding	Trigger related to forwarding
distribution	Trigger distribution of forwarding data to LCs
module	distribute to a particular module
<i>module</i>	module number

## Command Mode

- /exec

# trigger init ingress in-select 3 out-select 0

trigger init { ingress | egress } in-select 3 out-select 0

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
0	pktrw
3	outerl2-outerl3-outerl4

## Command Mode

- /exec/alamns

## trigger init ingress in-select 3 out-select 03

trigger init { ingress | egress } in-select 3 out-select 03

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
03	pkt_lsb
3	outerl2-outerl3-outerl4

### Command Mode

- /exec/elanms



# trigger init ingress in-select 3 out-select 0 reverse

trigger init { ingress | egress } in-select 3 out-select 0 reverse

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
0	pktrw
3	outerl2-outerl3-outerl4
reverse	Program reverse ELAM

## Command Mode

- /exec/elamns

# trigger init ingress in-select 3 out-select 1

trigger init { ingress | egress } in-select 3 out-select 1

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
1	pkt_fifo_lsb
3	outerl2-outerl3-outerl4

## Command Mode

- /exec/elanms

## trigger init ingress in-select 3 out-select 2

trigger init { ingress | egress } in-select 3 out-select 2

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
2	pkt_fifo_msb
3	outerl2-outerl3-outerl4

### Command Mode

- /exec/alamns

## trigger init ingress in-select 3 out-select 4

trigger init { ingress | egress } in-select 3 out-select 4

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
4	pkt_msb
3	outerl2-outerl3-outerl4

### Command Mode

- /exec/elanms

# trigger init ingress in-select 3 out-select 5

trigger init { ingress | egress } in-select 3 out-select 5

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
5	sideband
3	outer12-outer13-outer14

## Command Mode

- /exec/alamns

## trigger init ingress in-select 3 out-select 5 reverse

trigger init { ingress | egress } in-select 3 out-select 5 reverse

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
5	sideband
3	outer12-outer13-outer14
reverse	Program reverse ELAM

### Command Mode

- /exec/eamns

# trigger init ingress in-select 4 out-select 0

trigger init { ingress | egress } in-select 4 out-select 0

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
0	pktrw
4	innerl2-innerl3-innerl4

## Command Mode

- /exec/alamns

## trigger init ingress in-select 4 out-select 04

trigger init { ingress | egress } in-select 4 out-select 04

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
04	pkt_msb
4	inner12-inner13-inner14

### Command Mode

- /exec/elanms



## trigger init ingress in-select 4 out-select 0 reverse

trigger init { ingress | egress } in-select 4 out-select 0 reverse

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
0	pktrw
4	innerl2-innerl3-innerl4
reverse	Program reverse ELAM

### Command Mode

- /exec/elamns

# trigger init ingress in-select 4 out-select 1

trigger init { ingress | egress } in-select 4 out-select 1

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
1	pkt_fifo_lsb
4	inner12-inner13-inner14

## Command Mode

- /exec/elamns

## trigger init ingress in-select 4 out-select 2

trigger init { ingress | egress } in-select 4 out-select 2

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
2	pkt_fifo_msb
4	innerl2-innerl3-innerl4

### Command Mode

- /exec/alamns

## trigger init ingress in-select 4 out-select 3

trigger init { ingress | egress } in-select 4 out-select 3

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
3	pkt_lsb
4	inner12-inner13-inner14

### Command Mode

- /exec/elanms

# trigger init ingress in-select 4 out-select 5

trigger init { ingress | egress } in-select 4 out-select 5

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
5	sideband
4	innerl2-innerl3-innerl4

## Command Mode

- /exec/alamns

## trigger init ingress in-select 4 out-select 5 reverse

trigger init { ingress | egress } in-select 4 out-select 5 reverse

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
5	sideband
4	inner12-inner13-inner14
reverse	Program reverse ELAM

### Command Mode

- /exec/eamns

# trigger init ingress in-select 5 out-select 0

trigger init { ingress | egress } in-select 5 out-select 0

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
0	pktrw
5	outerl2-innerl2

## Command Mode

- /exec/alamns

# trigger init ingress in-select 5 out-select 05

trigger init { ingress | egress } in-select 5 out-select 05

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
05	sideband
5	outer12-inner12

## Command Mode

- /exec/elanms



# trigger init ingress in-select 5 out-select 05 reverse

trigger init { ingress | egress } in-select 5 out-select 05 reverse

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
05	sideband
5	outerl2-innerl2
reverse	Program reverse ELAM

## Command Mode

- /exec/elamns

## trigger init ingress in-select 5 out-select 0 reverse

trigger init { ingress | egress } in-select 5 out-select 0 reverse

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
0	pktrw
5	outerl2-innerl2
reverse	Program reverse ELAM

### Command Mode

- /exec/eamns

# trigger init ingress in-select 5 out-select 1

trigger init { ingress | egress } in-select 5 out-select 1

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
1	pkt_fifo_lsb
5	outerl2-innerl2

## Command Mode

- /exec/alamns

## trigger init ingress in-select 5 out-select 2

trigger init { ingress | egress } in-select 5 out-select 2

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
2	pkt_fifo_msb
5	outerl2-innerl2

### Command Mode

- /exec/elanms

# trigger init ingress in-select 5 out-select 3

trigger init { ingress | egress } in-select 5 out-select 3

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
3	pkt_lsb
5	outerl2-innerl2

## Command Mode

- /exec/alamns

## trigger init ingress in-select 5 out-select 4

trigger init { ingress | egress } in-select 5 out-select 4

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
4	pkt_msb
5	outerl2-innerl2

### Command Mode

- /exec/elanms

# trigger init ingress in-select 6 out-select 0

trigger init { ingress | egress } in-select 6 out-select 0

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
0	pktrw
6	outer13-inner13

## Command Mode

- /exec/alamns

## trigger init ingress in-select 6 out-select 0 reverse

trigger init { ingress | egress } in-select 6 out-select 0 reverse

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
0	pktrw
6	outer13-inner13
reverse	Program reverse ELAM

### Command Mode

- /exec/eamns



# trigger init ingress in-select 6 out-select 1

trigger init { ingress | egress } in-select 6 out-select 1

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
1	pkt_fifo_lsb
6	outer13-inner13

## Command Mode

- /exec/alamns

## trigger init ingress in-select 6 out-select 2

trigger init { ingress | egress } in-select 6 out-select 2

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
2	pkt_fifo_msb
6	outer13-inner13

### Command Mode

- /exec/elanms

# trigger init ingress in-select 6 out-select 3

trigger init { ingress | egress } in-select 6 out-select 3

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
3	pkt_lsb
6	outerl3-innerl3

## Command Mode

- /exec/alamns

## trigger init ingress in-select 6 out-select 4

trigger init { ingress | egress } in-select 6 out-select 4

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
4	pkt_msb
6	outer13-inner13

### Command Mode

- /exec/elanms

# trigger init ingress in-select 6 out-select 5

trigger init { ingress | egress } in-select 6 out-select 5

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
5	sideband
6	outer13-inner13

## Command Mode

- /exec/alamns

## trigger init ingress in-select 6 out-select 5 reverse

trigger init { ingress | egress } in-select 6 out-select 5 reverse

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
5	sideband
6	outer13-inner13
reverse	Program reverse ELAM

### Command Mode

- /exec/eamns

# trigger init ingress in-select 7 out-select 0

trigger init { ingress | egress } in-select 7 out-select 0

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
0	pktrw
7	outerl4-innerl4

## Command Mode

- /exec/alamns

## trigger init ingress in-select 7 out-select 0 reverse

trigger init { ingress | egress } in-select 7 out-select 0 reverse

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
0	pktrw
7	outer14-inner14
reverse	Program reverse ELAM

### Command Mode

- /exec/eamns



# trigger init ingress in-select 7 out-select 1

trigger init { ingress | egress } in-select 7 out-select 1

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
1	pkt_fifo_lsb
7	outerl4-innerl4

## Command Mode

- /exec/alamns

## trigger init ingress in-select 7 out-select 2

trigger init { ingress | egress } in-select 7 out-select 2

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
2	pkt_fifo_msb
7	outer14-inner14

### Command Mode

- /exec/elanms

# trigger init ingress in-select 7 out-select 3

trigger init { ingress | egress } in-select 7 out-select 3

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
3	pkt_lsb
7	outerl4-innerl4

## Command Mode

- /exec/alamns

## trigger init ingress in-select 7 out-select 4

trigger init { ingress | egress } in-select 7 out-select 4

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
4	pkt_msb
7	outerl4-innerl4

### Command Mode

- /exec/elanms

# trigger init ingress in-select 7 out-select 5

trigger init { ingress | egress } in-select 7 out-select 5

## Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
5	sideband
7	outer14-inner14

## Command Mode

- /exec/alamns

## trigger init ingress in-select 7 out-select 5 reverse

trigger init { ingress | egress } in-select 7 out-select 5 reverse

### Syntax Description

trigger	Define A Trigger
init	Initialize Trigger
ingress	Ingress Fields
egress	Egress Fields
in-select	in-select
out-select	out-select
5	sideband
7	outer14-inner14
reverse	Program reverse ELAM

### Command Mode

- /exec/eamns

# trigger reset

trigger reset

## Syntax Description

trigger	Define A Trigger
reset	Reset triggers

## Command Mode

- /exec/eamns

## trigger route download vrf ipv4

```
trigger route download vrf <vrf-name> { ipv4 <route4> | ipv6 <route6> } [ module <slot-num> ]
```

### Syntax Description

trigger	Trigger
route	IP route related
download	Download
vrf	vrf
<i>vrf-name</i>	vrf name
ipv4	ipv4
<i>route4</i>	ipv4 prefix
ipv6	ipv6
module	(Optional) Module
<i>slot-num</i>	(Optional) Slot number of the module

### Command Mode

- /exec



# trustpoint server-identity

```
{ trustpoint server-identity <tp-server> } | { no trustpoint server-identity [ <tp-server> ] } | { [ no ] trustpoint client-verification <tp-client> }
```

## Syntax Description

no	Negate a command or set its defaults
trustpoint	Trustpoint configuration
server-identity	Server trustpoint
<i>tp-server</i>	Trustpoint name
client-verification	Client trustpoint
<i>tp-client</i>	Trustpoint name

## Command Mode

- /exe/configure/onep/tls

# ttag-marker-interval

[no] ttag-marker-interval <seconds>

## Syntax Description

no	(Optional) Negate a command or set its defaults
ttag-marker-interval	Marker packet interval
<i>seconds</i>	Interval in seconds

## Command Mode

- /exec/configure

# ttag-marker enable

[no] ttag-marker enable

## Syntax Description

no	(Optional) Negate a command or set its defaults
ttag-marker	Enable/Disable marker packet on interface
enable	Enable/Disable marker packet on interface

## Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

# ttag

[no] ttag

## Syntax Description

no	(Optional) Negate a command or set its defaults
ttag	enable ingress packet with ttag on this interface

## Command Mode

- /exec/configure/if-eth-base /exec/configure/if-ethernet-all

## ttl-security hops

ttl-security hops <ebgp-ttl> | { no | default } ttl-security hops [ <ebgp-ttl> ]

### Syntax Description

no	Negate a command or set its defaults
default	Inherit values from a peer template
ttl-security	Enable TTL Security Mechanism
hops	Specify hop count for remote peer
<i>ebgp-ttl</i>	EBGP hop count value

### Command Mode

- /exec/configure/router-bgp/router-bgp-neighbor-sess

# tunnel destination

tunnel destination { { <ip-addr> | <ip-prefix> | { <ip-addr> <ip-mask> } } | <ipv6-addr> } | no tunnel destination  
 [ <ip-addr> | <ip-prefix> | { <ip-addr> <ip-mask> } | <ipv6-addr> ]

## Syntax Description

no	Negate a command or set its defaults
tunnel	protocol-over-protocol tunneling
destination	destination of tunnel packets
<i>ip-addr</i>	IPv4 address (A.B.C.D)
<i>ip-prefix</i>	IPv4 mask (A.B.C.D/LEN)
<i>ip-mask</i>	IPv4 mask A.B.C.D

## Command Mode

- /exec/configure/if-gre-tunnel

## tunnel mode

tunnel mode { { gre [ ip | ipv6 ] } | { ipip [ ip | ipv6 ] } | { ipip decapsulate-any [ ip | ipv6 ] } | { ipv6ip [ decapsulate-any ] } | { ipv6ipv6 [ decapsulate-any ] } } | no tunnel mode

### Syntax Description

no	Negate a command or set its defaults
tunnel	protocol-over-protocol tunneling
mode	tunnel encapsulation method
gre	generic route encapsulation protocol
ipip	IP in IP protocol
decapsulate-any	decapsulate any
ip	(Optional) over IP
ipv6	(Optional) over IPv6
ipv6ip	IPv6 in IPv4 protocol
ipv6ipv6	IPv6 in IPv6 protocol

### Command Mode

- /exec/configure/if-any-tunnel

# tunnel path-mtu-discovery

[no] tunnel path-mtu-discovery

## Syntax Description

no	(Optional) Negate a command or set its defaults
tunnel	protocol-over-protocol tunneling
path-mtu-discovery	Enable Path MTU Discovery on tunnel

## Command Mode

- /exec/configure/if-any-tunnel



## tunnel path-mtu-discovery age-timer

tunnel path-mtu-discovery age-timer { <age-time> | infinite } | no tunnel path-mtu-discovery age-timer [ { <age-time> | infinite } ]

### Syntax Description

no	Negate a command or set its defaults
tunnel	protocol-over-protocol tunneling
path-mtu-discovery	Enable Path MTU Discovery on tunnel
age-timer	Set PMTUD aging timer
<i>age-time</i>	Aging time
infinite	Disable pathmtu aging timer

### Command Mode

- /exec/configure/if-any-tunnel

## tunnel path-mtu-discovery min-mtu

tunnel path-mtu-discovery min-mtu <mtu> | no tunnel path-mtu-discovery min-mtu [ <mtu> ]

### Syntax Description

no	Negate a command or set its defaults
tunnel	protocol-over-protocol tunneling
path-mtu-discovery	Enable Path MTU Discovery on tunnel
min-mtu	Min pmtud mtu allowed
<i>mtu</i>	Bytes

### Command Mode

- /exec/configure/if-any-tunnel

# tunnel source

tunnel source { <intf> | <ip-prefix> | { <ip-addr> [ <ip-mask> ] } | <ipv6-addr> | direct } | no tunnel source [ <intf> | <ip-prefix> | { <ip-addr> [ <ip-mask> ] } | <ipv6-addr> | direct ]

## Syntax Description

no	Negate a command or set its defaults
tunnel	protocol-over-protocol tunneling
source	source of tunnel packets
<i>intf</i>	interface
<i>ip-addr</i>	IPv4 address (A.B.C.D)
<i>ip-prefix</i>	IPv4 address (A.B.C.D/LEN)
<i>ip-mask</i>	(Optional) IPv4 mask A.B.C.D
direct	all directly connected IP

## Command Mode

- /exec/configure/if-gre-tunnel

# tunnel ttl

tunnel ttl <ttl\_val> | no tunnel ttl [ <ttl\_val> ]

## Syntax Description

no	Negate a command or set its defaults
tunnel	protocol-over-protocol tunneling
ttl	set time to live
<i>ttl_val</i>	time to live value

## Command Mode

- /exec/configure/if-any-tunnel

# tunnel use-vrf

```
tunnel use-vrf { <vrf-name> | <vrf-known-name> } | no tunnel use-vrf [ { <vrf-name> | <vrf-known-name> } ]
```

## Syntax Description

no	Negate a command or set its defaults
tunnel	protocol-over-protocol tunneling
use-vrf	set tunnel vrf membership
<i>vrf-name</i>	VRF name
<i>vrf-known-name</i>	Known VRF name

## Command Mode

- /exec/configure/if-any-tunnel

# type type

type <fex> | type <swcardid> | no type

## Syntax Description

no	Negate the command
type	FEX Card type
<i>fex</i>	Fex Type
<i>swcardid</i>	Card type

## Command Mode

- /exec/configure/fex