

Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)



## Preface

---

This preface describes the audience, organization, and conventions of the *Cisco Nexus 5000 Series NX-OS Fabric Extender Command Reference*. It also provides information on how to obtain related documentation.

This preface includes the following sections:

- [Audience, page 1](#)
- [Supported Switches, page 1](#)
- [Organization, page 2](#)
- [Document Conventions, page 3](#)
- [Related Documentation, page 4](#)
- [Obtaining Documentation and Submitting a Service Request, page 6](#)

## Audience

This publication is for experienced users who configure and maintain Cisco NX-OS devices.

## Supported Switches

This section includes the following topics:

- [Cisco Nexus 5000 Platform Switches, page 1](#)
- [Cisco Nexus 5500 Platform Switches, page 2](#)

## Cisco Nexus 5000 Platform Switches

[Table 1](#) lists the Cisco switches supported in the Cisco Nexus 5000 Platform.



### Note

For more information on these switches, see the *Cisco Nexus 5500 Platform and Cisco Nexus 5000 Platform Hardware Installation Guide* available at the following URL:

[http://www.cisco.com/en/US/products/ps9670/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps9670/tsd_products_support_series_home.html)

**[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)**

**Table 1 Supported Cisco Nexus 5000 Platform Switches**

Switch	Description
Cisco Nexus 5010 Switch	The Cisco Nexus 5010 is a 1 rack unit (RU) switch. It delivers 500 Gbps of wire-speed switching capacity designed for traditional, virtualized, unified, and high-performance computing (HPC) environments.
Cisco Nexus 5020 Switch	The Cisco Nexus 5020 is a 2 rack unit (RU) switch. It delivers 1+ Tbps of wire-speed switching capacity designed for traditional, virtualized, unified, and HPC environments.



**Note**

The Cisco Nexus 5000 Platform switches only supports Internet Group Management Protocol (IGMP) snooping. IGMP, Protocol Independent Multicast (PIM), and Multicast Source Discovery Protocol (MSDP) are not supported on the Cisco Nexus 5000 Platform switches.

## Cisco Nexus 5500 Platform Switches

Table 2 lists the Cisco switches supported in the Cisco Nexus 5500 Platform.



**Note**

For more information on these switches, see the *Cisco Nexus 5500 Platform and Cisco Nexus 5000 Platform Hardware Installation Guide* available at the following URL:  
[http://www.cisco.com/en/US/products/ps9670/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps9670/tsd_products_support_series_home.html)

**Table 2 Supported Cisco Nexus 5500 Platform Switches**

Switch	Description
Cisco Nexus 5548P Switch	The Cisco Nexus 5548P switch is the first switch in the Cisco Nexus 5500 Platform. It is a one-rack-unit (1 RU), 10-Gigabit Ethernet and Fibre Channel over Ethernet (FCoE) switch that offers up to 960-Gbps throughput and up to 48 ports.
Cisco Nexus 5596P Switch	The Cisco Nexus 5596P switch is a top-of-rack, 10-Gigabit Ethernet and FCoE switch offering up to 1920-Gigabit throughput and up to 96 ports.

## Organization

This document is organized as follows:

**[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)**

Chapter Title	Description
<a href="#">New and Changed Information</a>	Describes the new and changed information for the new Cisco NX-OS software releases.
<a href="#">A Commands</a>	Describes the Cisco NX-OS Fabric Extender commands that begin with A.
<a href="#">D Commands</a>	Describes the Cisco NX-OS Fabric Extender commands that begin with D.
<a href="#">F Commands</a>	Describes the Cisco NX-OS Fabric Extender commands that begin with F.
<a href="#">H Commands</a>	Describes the Cisco NX-OS Fabric Extender commands that begin with H.
<a href="#">L Commands</a>	Describes the Cisco NX-OS Fabric Extender commands that begin with L.
<a href="#">P Commands</a>	Describes the Cisco NX-OS Fabric Extender commands that begin with P.
<a href="#">S Commands</a>	Describes the Cisco NX-OS Fabric Extender commands that begin with S.
<a href="#">Show Commands</a>	Describes the Cisco NX-OS Fabric Extender <b>show</b> commands.
<a href="#">T Commands</a>	Describes the Cisco NX-OS Fabric Extender commands that begin with T.

## Document Conventions

Command descriptions use these conventions:

Convention	Description
<b>boldface font</b>	Commands and keywords are in boldface.
<i>italic font</i>	Arguments for which you supply values are in italics.
[ ]	Elements in square brackets are optional.
{x   y   z}	Alternative keywords are grouped in braces and separated by vertical bars.
[ x   y   z ]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

Screen examples use these conventions:

screen font	Terminal sessions and information that the switch displays are in screen font.
<b>boldface screen font</b>	Information you must enter is in boldface screen font.
<i>italic screen font</i>	Arguments for which you supply values are in italic screen font.
< >	Nonprinting characters, such as passwords, are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

**[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)**

This document uses the following conventions:



**Note**

Means reader *take note*. Notes contain helpful suggestions or references to material not covered in the manual.



**Caution**

Means reader *be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

## Related Documentation

Documentation for Cisco Nexus 5000 Series Switches and Cisco Nexus 2000 Series Fabric Extender is available at the following URL:

[http://www.cisco.com/en/US/products/ps9670/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/ps9670/tsd_products_support_series_home.html)

The following are related Cisco Nexus 5000 Series and Cisco Nexus 2000 Series Fabric Extender documents:

## Release Notes

*Cisco Nexus 5000 Series and Cisco Nexus 2000 Series Release Notes*

*Cisco Nexus 5000 Series Switch Release Notes*

## Configuration Guides

*Cisco Nexus 5000 Series Configuration Limits for Cisco NX-OS Release 5.0(2)N1(1)*

*Cisco Nexus 5000 Series Configuration Limits for Cisco NX-OS Release 4.2(1)N1(1) and Release 4.2(1)N2(1)*

*Cisco Nexus 5000 Series NX-OS Fibre Channel over Ethernet Configuration Guide*

*Cisco Nexus 5000 Series NX-OS Layer 2 Switching Configuration Guide*

*Cisco Nexus 5000 Series NX-OS Multicast Routing Configuration Guide*

*Cisco Nexus 5000 Series NX-OS Quality of Service Configuration Guide*

*Cisco Nexus 5000 Series NX-OS SAN Switching Configuration Guide*

*Cisco Nexus 5000 Series NX-OS Security Configuration Guide*

*Cisco Nexus 5000 Series NX-OS System Management Configuration Guide*

*Cisco Nexus 5000 Series NX-OS Unicast Routing Configuration Guide*

*Cisco Nexus 5000 Series Switch NX-OS Software Configuration Guide*

*Cisco Nexus 5000 Series Fabric Manager Configuration Guide, Release 3.4(1a)*

*Cisco Nexus 7000 Series NX-OS Fundamentals Configuration Guide, Release 6.x*

*Cisco Nexus 2000 Series Fabric Extender Software Configuration Guide*

**[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)**

## Maintain and Operate Guides

*Cisco Nexus 5000 Series NX-OS Operations Guide*

## Installation and Upgrade Guides

*Cisco Nexus 5000 Series and Cisco Nexus 5500 Platform Hardware Installation Guide*

*Cisco Nexus 2000 Series Hardware Installation Guide*

*Cisco Nexus 5000 Series NX-OS Software Upgrade and Downgrade Guide, Release 4.2(1)NI(1)*

*Regulatory Compliance and Safety Information for the Cisco Nexus 5000 Series Switches and Cisco Nexus 2000 Series Fabric Extenders*

## Licensing Guide

*Cisco NX-OS Licensing Guide*

## Command References

*Cisco Nexus 5000 Series NX-OS FabricPath Command Reference*

*Cisco Nexus 5000 Series NX-OS Fabric Extender Command Reference*

*Cisco Nexus 5000 Series NX-OS Fibre Channel Command Reference*

*Cisco Nexus 5000 Series NX-OS Fundamentals Command Reference*

*Cisco Nexus 5000 Series NX-OS Layer 2 Interfaces Command Reference*

*Cisco Nexus 5000 Series NX-OS Multicast Routing Command Reference*

*Cisco Nexus 5000 Series NX-OS QoS Command Reference*

*Cisco Nexus 5000 Series NX-OS Security Command Reference*

*Cisco Nexus 5000 Series NX-OS System Management Command Reference*

*Cisco Nexus 5000 Series NX-OS TrustSec Command Reference*

*Cisco Nexus 5000 Series NX-OS Unicast Routing Command Reference*

*Cisco Nexus 5000 Series NX-OS vPC Command Reference*

## Technical References

*Cisco Nexus 5000 Series and Cisco Nexus 2000 Series Fabric Extender MIBs Reference*

## Error and System Messages

*Cisco NX-OS System Messages Reference*

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

## Troubleshooting Guide

*Cisco Nexus 5000 Troubleshooting Guide*

# Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation* at: <http://www.cisco.com/c/en/us/td/docs/general/whatsnew/whatsnew.html>.

Subscribe to *What's New in Cisco Product Documentation*, which lists all new and revised Cisco technical documentation as an RSS feed and delivers content directly to your desktop using a reader application. The RSS feeds are a free service.

Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)



## New and Changed Information

---

This chapter provides release-specific information for each new and changed feature in the *Cisco Nexus 5000 Series NX-OS Fabric Extender Command Reference*. The latest version of this document is available at the following Cisco website:

[http://www.cisco.com/en/US/products/ps9670/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps9670/prod_command_reference_list.html)

To check for additional information about this Cisco NX-OS Release, see the *Cisco Nexus 5000 Series Switch Release Notes* available at the following Cisco website:

[http://www.cisco.com/en/US/products/ps9670/prod\\_release\\_notes\\_list.html](http://www.cisco.com/en/US/products/ps9670/prod_release_notes_list.html)

## New and Changed Information for Cisco NX-OS Releases

This section includes the following topics:

- [New and Changed Information for Cisco NX-OS Release 5.2\(1\)N1\(1\)](#), page 13
- [New and Changed Information for Cisco NX-OS Release 5.1\(3\)N1\(1\)](#), page 13
- [New and Changed Information for Cisco NX-OS Release 5.0\(3\)N2\(1\)](#), page 14
- [New and Changed Information for Cisco NX-OS Release 5.0\(3\)N1\(1\)](#), page 14
- [New and Changed Information for Cisco NX-OS Release 5.0\(2\)N2\(1\)](#), page 14
- [New and Changed Information for Cisco NX-OS Release 5.0\(2\)N1\(1\)](#), page 14
- [New and Changed Information for Cisco NX-OS Release 4.2\(1\)N2\(1\)](#), page 15
- [New and Changed Information for Cisco NX-OS Release 4.2\(1\)N1\(1\)](#), page 15
- [New and Changed Information for Cisco NX-OS Release 4.1\(3\)N1\(1\)](#), page 16
- [New and Changed Information for Cisco NX-OS Release 4.0\(1a\)N2\(1\)](#), page 16

### New and Changed Information for Cisco NX-OS Release 5.2(1)N1(1)

There are no new or changed commands for this release.

### New and Changed Information for Cisco NX-OS Release 5.1(3)N1(1)

[Table 1](#) summarizes the new and changed features for Cisco NX-OS Release 5.1(3)N1(1) and tells you where they are documented.

**[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)**

**Table 1** *New and Changed Information for Release 5.1(3)N1(1)*

Feature	Description	Where Documented
FCoE over Adapter Fabric Extender (Adapter-FEX)	This feature was introduced. The following commands were updated to include support for Adapter-FEX: <ul style="list-style-type: none"> <li><b>fcoe</b></li> </ul>	<a href="#">fcoe</a>
Fabric Extender hardware enhancements	The The Cisco Nexus N2248TP-E Fabric Extender was introduced. The following commands were introduced on a 2248TP-E Fabric Extender: <ul style="list-style-type: none"> <li><b>hardware shared-buffer-size</b></li> <li><b>hardware uplink-pause-no-drop</b></li> </ul> The following commands were updated: <ul style="list-style-type: none"> <li><b>hardware queue-limit</b></li> </ul>	<a href="#">hardware queue-limit</a> <a href="#">hardware shared-buffer-size</a> <a href="#">hardware uplink-pause-no-drop</a>

## New and Changed Information for Cisco NX-OS Release 5.0(3)N2(1)

There are no new and changed features for Cisco NX-OS Release 5.0(3)N2(1).

## New and Changed Information for Cisco NX-OS Release 5.0(3)N1(1)

There are no new and changed features for Cisco NX-OS Release 5.0(3)N1(1).

## New and Changed Information for Cisco NX-OS Release 5.0(2)N2(1)

There are no new and changed features for Cisco NX-OS Release 5.0(2)N2(1).

## New and Changed Information for Cisco NX-OS Release 5.0(2)N1(1)

[Table 2](#) summarizes the new and changed features for Cisco NX-OS Release 5.0(2)N1(1) and tells you where they are documented.



**[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)**

**Table 2** *New and Changed Information for Release 5.0(2)N1(1)*

Feature	Description	Where Documented
Bootup diagnostic level	You can control the diagnostic level of all the Fabric Extenders connected to the switch.	<a href="#">diagnostic bootup level</a>
Support for Fabric Extender preprovisioning	You can preprovision a module in a chassis slot of a Cisco Nexus 2000 Series Fabric Extender.	<a href="#">provision</a> <a href="#">slot</a> <a href="#">show provision</a> <a href="#">show running-config</a> <a href="#">exclude-provision</a> <a href="#">show startup-config</a> <a href="#">exclude-provision</a>

## New and Changed Information for Cisco NX-OS Release 4.2(1)N2(1)

[Table 3](#) summarizes the new and changed features for Cisco NX-OS Release 4.2(1)N2(1) and tells you where they are documented.

**Table 3** *New and Changed Information for Release 4.2(1)N2(1)*

Feature	Description	Where Documented
Cisco Nexus 2000 Series Fabric Extender enhancements	The following commands were updated: <ul style="list-style-type: none"> <li><b>diagnostic bootup level</b></li> </ul> The following commands were introduced: <ul style="list-style-type: none"> <li><b>hardware buffer-threshold</b></li> <li><b>hardware queue-limit</b></li> </ul>	<a href="#">diagnostic bootup level</a> <a href="#">hardware buffer-threshold</a> <a href="#">hardware queue-limit</a>

## New and Changed Information for Cisco NX-OS Release 4.2(1)N1(1)

[Table 4](#) summarizes the new and changed features for Cisco NX-OS Release 4.2(1)N1(1) and tells you where they are documented.

**Table 4** *New and Changed Information for Release 4.2(1)N1(1)*

Feature	Description	Where Documented
Cisco Nexus 2000 Series Fabric Extender enhancements	The following commands were introduced: <ul style="list-style-type: none"> <li><b>fex queue-limit</b></li> <li><b>type</b></li> </ul> The following commands were updated: <ul style="list-style-type: none"> <li><b>pinning max-links</b></li> </ul>	<a href="#">fex queue-limit</a> <a href="#">pinning max-links</a> <a href="#">type</a> <a href="#">Show Commands</a>

**[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)**

## New and Changed Information for Cisco NX-OS Release 4.1(3)N1(1)

Table 5 summarizes the new and changed features for Cisco NX-OS Release 4.1(3)N1(1) and tells you where they are documented.

**Table 5** *New and Changed Information for Release 4.1(3)N1(1)*

Feature	Description	Where Documented
Cisco Nexus 2000 Series Fabric Extender enhancements	The <b>beacon</b> command was deprecated and replaced with the <b>locator-led</b> command.  The following commands were introduced: <ul style="list-style-type: none"> <li>• <b>show queuing interface</b></li> </ul>	<a href="#">locator-led fex</a> <a href="#">show queuing interface</a>

## New and Changed Information for Cisco NX-OS Release 4.0(1a)N2(1)

Table 6 summarizes the new and changed features for Cisco NX-OS Release 4.0(1a)N2(1) and tells you where they are documented.

**Table 6** *New and Changed Information for Release 4.0(1a)N2(1)*

Feature	Description	Where Documented
Cisco Nexus 2000 Series Fabric Extender	This feature was introduced to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.	<a href="#">attach fex</a> <a href="#">beacon</a> <a href="#">description (fex)</a> <a href="#">feature fex</a> <a href="#">fex</a> <a href="#">fex associate</a> <a href="#">fex pinning redistribute</a> <a href="#">logging fex</a> <a href="#">pinning max-links</a> <a href="#">serial</a> <a href="#">switchport mode fex-fabric</a> <a href="#">Show Commands</a>

*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*



## A Commands

---

This chapter describes the Cisco NX-OS commands that begin with A that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

**[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)**

## attach fex

To access the command-line interface (CLI) of a connected Fabric Extender to run diagnostic commands, use the **attach fex** command.

**attach fex** *chassis\_ID*

<b>Syntax Description</b>	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
---------------------------	-------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.0(1a)N2(1)	This command was introduced.

<b>Usage Guidelines</b>	Use the <b>attach fex</b> command to access the CLI on a connected Fabric Extender and performing diagnostic commands. We recommend that you use this command only following direction from Cisco technical support personnel.
-------------------------	--

<b>Examples</b>	This example shows how to access the CLI of a connected Fabric Extender to run diagnostic commands: switch# <b>attach fex 101</b>
-----------------	--

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*



## D Commands

---

This chapter describes the Cisco NX-OS commands that begin with D that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

## description (fex)

To specify a description for a Fabric Extender, use the **description** command. To revert to the default description, use the **no** form of this command.

**description** *description*

**no description**

<b>Syntax Description</b>	<i>description</i>	Description of a Fabric Extender. The default is the string FEXxxxx where xxxx is the chassis ID. For example, if the chassis ID is 123, the default description is FEX0123. The maximum length is 20 alphanumeric characters.
---------------------------	--------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Fabric extender configuration mode
----------------------	------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.0(1a)N2(1)	This command was introduced.

**Examples** This example shows how to specify a description for a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# description Rack16_FEX101
```

This example shows how to revert to the default description for a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# no description
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>fex</b>	Creates a Fabric Extender and enters Fabric Extender configuration mode.
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## diagnostic bootup level

To configure the bootup diagnostic level to trigger diagnostics when the device boots, use the **diagnostic bootup level** command. To remove the bootup diagnostic level configuration, use the **no** form of this command.

**diagnostic bootup level** {bypass | complete}

**no diagnostic bootup level** {bypass | complete}

### Syntax Description

<b>bypass</b>	Specifies that all bootup tests are skipped.
<b>complete</b>	Specifies that all bootup diagnostics are performed. This is the default value.

### Command Default

Complete

### Command Modes

Global configuration mode

### Command History

Release	Modification
4.0(0)N1(1)	This command was introduced.
4.2(1)N2(1)	Support was added to control the diagnostic level of all the Fabric Extenders connected to the switch.

### Examples

This example shows how to configure the bootup diagnostics level to trigger the complete diagnostics:

```
switch(config)# diagnostic bootup level complete
switch(config)#
```

This example shows how to remove the bootup diagnostics level configuration:

```
switch(config)# no diagnostic bootup level complete
switch(config)#
```

### Related Commands

Command	Description
<b>show diagnostic bootup level</b>	Displays the bootup diagnostics level.
<b>show diagnostic bootup result</b>	Displays the results of the diagnostics tests.

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***



*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*



## **F Commands**

---

This chapter describes the Cisco NX-OS commands that begin with F that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## fcoe

To associate a Cisco Nexus 2000 Series Fabric Extender (FEX) to a switch for pinning Fibre Channel over Ethernet (FCoE) Initialization Protocol (FIP) and FCoE traffic, use the **fcoe** command. To remove the association, use the **no** form of this command.

```
fcoe [vsan vsan-id]
```

```
no fcoe [vsan]
```

### Syntax Description

<b>vsan vsan-id</b>	Specifies the VSAN status. The VSAN ID range is from 1 to 4094.
---------------------	---

### Command Default

None

### Command Modes

FEX configuration mode  
VLAN configuration mode

### Command History

Release	Modification
5.1(3)N1(1)	This command was introduced.

### Usage Guidelines

Before you use this command, make sure that you enable the Fabric Extender (FEX) features on the switch by using the **feature fex** command.

You can use this command only on a Cisco Nexus 2232P Fabric Extender. When you bind an interface to a virtual Fibre Channel interface to enable FCoE traffic, you must use slot number 1. The port number can be from 1 to 32.



### Note

- In single homed FEX topology, the FCoE keyword is not required.
- In dual homed FEX topology, the FCoE keyword is only required in the FEX configuration on one of the Nexus switches.

### Examples

This example shows how to configure a FEX as FCoE enabled:

```
switch# configure terminal
switch(config)# feature fex
switch(config)# fex 100
switch(config-fex)# fcoe
switch(config-fex)#
```

This example shows how to configure a pair of FEXs to carry FCoE traffic in a fabric virtual port channel (vPC) topology, with the host uplink ports in the FEXs configured to the same port channel:

```
switch# configure terminal
switch(config)# feature lacp
switch(config)# feature fex
```

## ***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

```

switch(config)# feature fcoe
switch(config)# fex 100
switch(config-fex)# fcoe
switch(config-fex)# exit
switch(config)# interface vfc 1
switch(config-if)# bind interface eth101/1/1
switch(config)# interface eth101/1/1
switch(config-if)# channel-group 1
switch(config)# fex 102
switch(config-fex)# fcoe
switch(config)# interface vfc 1
switch(config-if)# bind interface eth102/1/1
switch(config)# interface eth102/1/1
switch(config-if)# channel-group 1
switch(config-if)#

```

This example shows how to configure FCoE traffic on a VLAN:

```

switch# configure terminal
switch(config)# vlan 5
switch(config-vlan)# fcoe vsan 1
switch(config-vlan)#

```

This example shows how to disable FCoE traffic on a FEX:

```

switch# configure terminal
switch(config)# fex 100
switch(config-fex)# no fcoe
switch(config-fex)#

```

### **Related Commands**

<b>Command</b>	<b>Description</b>
<b>feature fcoe</b>	Enables the FCoE feature on the switch.
<b>feature fex</b>	Enables the FEX feature on the switch.
<b>feature lacp</b>	Enables the Link Aggregation Control Protocol (LACP).
<b>show fex</b>	Displays information about a specific FEX.

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

## feature fex

To enable Fabric Extender (FEX) features on the switch, use the **feature fex** command. To disable FEX, use the **no** form of this command.

**feature fex**

**no feature fex**

---

**Syntax Description** This command has no arguments or keywords.

---

**Command Default** None

---

**Command Modes** Global configuration mode

---

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

---



---

**Examples** This example shows how to enable FEX features on the switch:

```
switch(config)# feature fex
switch(config)#
```

---

Related Commands	Command	Description
	<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
	<b>show feature</b>	Displays the features enabled or disabled on the switch.

---

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

## fex

To create a Fabric Extender and enter fabric extender configuration mode, use the **fex** command. To delete the Fabric Extender configuration, use the **no** form of this command.

**fex** *chassis\_ID*

**no fex** *chassis\_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Usage Guidelines	You can create and configure the Fabric Extender before you connect and associate it to an interface on the parent switch. Once you associate the Fabric Extender to the switch, the configuration you created is transferred over to the Fabric Extender and applied.
------------------	--

Examples	This example shows how to enter Fabric Extender configuration mode:
----------	---

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)#
```

This example shows how to delete the Fabric Extender configuration:

```
switch(config-fex)# no fex 101
switch(config)#
```

Related Commands	Command	Description
	<b>beacon</b>	Turns on the locator beacon LED of a Fabric Extender.
	<b>description (fex)</b>	Specifies a description for a Fabric Extender.
	<b>fex associate</b>	Associates a Fabric Extender to an Ethernet or EtherChannel interface.
	<b>pinning max-links</b>	Specifies the number of statically pinned uplinks connected to a Fabric Extender.
	<b>serial</b>	Assigns a serial number to a Fabric Extender.

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

<b>Command</b>	<b>Description</b>
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
<b>type</b>	Specifies the Fabric Extender card.

***Send comments to nexus5k-docfeedback@cisco.com***

## fex associate

To associate a Fabric Extender to a fabric interface, use the **fex associate** command. To disassociate the Fabric Extender, use the **no** form of this command.

**fex associate** *chassis\_ID*

**no fex associate** [*chassis\_ID*]

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	Interface configuration mode
---------------	------------------------------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

Usage Guidelines	Before you can associate an interface on the parent switch to the Fabric Extender, you must first make the interface into a fabric interface by entering the <b>switchport mode fex-fabric</b> command.
------------------	---



### Note

On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release 4.2(1)N1(1), the **switchport mode fex-fabric** command is not supported on an Ethernet interface.

Examples	This example shows how to associate the Fabric Extender to an Ethernet interface:
----------	---

```
switch# configure terminal
switch(config)# interface ethernet 1/40
switch(config-if)# switchport mode fex-fabric
switch(config-if)# fex associate 101
```

This example shows how to associate the Fabric Extender to an EtherChannel interface:

```
switch# configure terminal
switch(config)# interface port-channel 4
switch(config-if)# switchport mode fex-fabric
switch(config-if)# fex associate 101
```

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

Related Commands	Command	Description
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
	<b>switchport mode fex-fabric</b>	Sets the interface to be an uplink port.



[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## fex pinning redistribute

To redistribute the host interfaces on a Fabric Extender, use the **fex pinning redistribute** command.

```
fex pinning redistribute chassis_ID
```

<b>Syntax Description</b>	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
---------------------------	-------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.0(1a)N2(1)	This command was introduced.

**Usage Guidelines**

When you provision the Fabric Extender using the statically pinned mode (see the *Cisco Nexus 2000 Series Fabric Extender Software Configuration Guide*), the host interfaces on the Fabric Extender are pinned to the fabric interfaces in the order that they were initially configured. The next time that you reboot the Fabric Extender, the configured fabric interfaces are pinned to the host interfaces in an ascending order by the port number of the fabric interface.

Use the **fex pinning redistribute** command if you want to configure the same fixed distribution of host interfaces without restarting the Fabric Extender after your initial configuration.



### Caution

This command disrupts all the host interface ports of the Fabric Extender. However, the disruption is shorter than would be the case if you reboot the Fabric Extender.

**Examples**

This example shows how to redistribute the host interfaces on a Fabric Extender:

```
switch# fex pinning redistribute 101
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
		<b>pinning max-links</b>
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
	<b>show interface fex-intf</b>	Displays the Fabric Extender ports pinned to a specific switch interface.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## fex queue-limit

To limit the amount of input buffer space (in bytes) allocated to each Fabric Extender port, use the **fex queue-limit** command. To disable the drop threshold and allow a Fabric Extender port to use all available buffer space, use the **no** form of this command.

**fex queue-limit**

**no fex queue-limit**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Fabric Extender queue limit is available in the default configuration and is set on.

**Command Modes** System QoS configuration mode

### Command History

Release	Modification
4.2(1)N1(1)	This command was introduced.

### Usage Guidelines

By default, the drop threshold applies to each Fabric Extender port to limit the amount of buffer being allocated for each port. To restore the default queue limit of each Fabric Extender port, use the **fex queue-limit** command.

### Examples

This example shows how to set the queue limit for the input buffer for each Fabric Extender port:

```
switch(config)# system qos
switch(config-sys-qos)# fex queue-limit
switch(config-sys-qos)#
```

This example shows how to restore the default queue limit for each Fabric Extender port:

```
switch(config)# system qos
switch(config-sys-qos)# no fex queue-limit
switch(config-sys-qos)#
```

### Related Commands

Command	Description
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*



## H Commands

---

This chapter describes the Cisco NX-OS commands that begin with H that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## hardware buffer-threshold

To limit the amount of input hardware buffer usage for each Fabric Extender, use the **hardware buffer-threshold** command. To revert to the default and allow a Fabric Extender to use all available hardware buffer space, use the **no** form of this command.

**hardware** *fex\_card\_typ* **buffer-threshold** *buffer-limit*

**no hardware** *fex\_card\_typ* **buffer-threshold**

### Syntax Description

<i>fex_card_type</i>	Fabric Extender card type. The following Fabric Extender card types are supported: <ul style="list-style-type: none"> <li>• <b>N2148T</b>—Fabric Extender 48x1G 4x10G SFP+ Module</li> </ul> See the “Usage Guidelines” section for a description of this Fabric Extender.
<i>buffer-limit</i>	Buffer threshold limit in bytes. The range is from 81920 to 316160.

### Command Default

None

### Command Modes

Fabric extender configuration mode

### Command History

Release	Modification
4.2(1)N2(1)	This command was introduced.

### Usage Guidelines



#### Note

This command is supported only on a Cisco Nexus 2148T Fabric Extender.

The Cisco Nexus 2148T Fabric Extender has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.

The **buffer-threshold** keyword sets the consumption level of input buffers before an indication is sent to the egress queue to start observing the tail drop threshold. If the buffer usage is lower than the configured buffer threshold, the tail drop threshold is ignored.

### Examples

This example shows how to configure the hardware buffer threshold limit on a Cisco Nexus 2148T Fabric Extender:

```
switch(config)# fex 110
switch(config-fex)# hardware N2148T buffer-threshold 163840
switch(config-fex)#
```

## ***Send comments to nexus5k-docfeedback@cisco.com***

This example shows how to remove the hardware buffer threshold configured on a Cisco Nexus 2148T Fabric Extender:

```
switch(config)# fex 110  
switch(config-fex)# no hardware N2148T buffer-threshold  
switch(config-fex)#
```

### **Related Commands**

<b>Command</b>	<b>Description</b>
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
<b>show queuing interface</b>	Displays information about interface queuing parameters, including buffer threshold and queue limits.
<b>show running-config fex</b>	Displays the running configuration for Fabric Extenders.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## hardware queue-limit

To control the egress queue tail drop threshold level on a Fabric Extender, use the **hardware queue-limit** command. To disable the drop threshold and allow a Fabric Extender to use all available hardware buffer space, use the **no** form of this command.

**hardware** *fex\_card\_typ* **queue-limit** [*queue-limit*] [**rx** | **tx**]

**no hardware** *fex\_card\_typ* **queue-limit** [**rx** | **tx**]

### Syntax Description

<i>fex_card_type</i>	Fabric Extender card type. The following Fabric Extender card types are supported: <ul style="list-style-type: none"> <li><b>N2148T</b>—Fabric Extender 48x1G 4x10G SFP+ Module</li> <li><b>N2224TP</b>—Fabric Extender 24x1G 2x10G SFP+ Module</li> <li><b>N2232P</b>—Fabric Extender 32x10G SFP+ 8x10G SFP+ Module</li> <li><b>N2232TM</b>—Fabric Extender 32x10GBase-T 8x10G SFP+ Module</li> <li><b>N2248T</b>—Fabric Extender 48x1G 4x10G SFP+ Module</li> <li><b>N2248TP-E</b>—Fabric Extender 48x1G 4x10G SFP+ Module</li> </ul> See the “Usage Guidelines” section for a description of these Fabric Extenders.
<i>queue-limit</i>	(Optional) Queue limit in bytes. The range is from 81920 to 652800 for a Cisco Nexus 2148T Fabric Extender, from 32768 to 33538048 for a on a Cisco Nexus 2248TP-E Fabric Extender, and from 5120 to 652800 for all other supported Fabric Extenders.
<b>rx</b>	(Optional) Specifies the default queue-limit for receiving (ingress). <p><b>Note</b> This keyword is supported only on a Cisco Nexus 2248TP-E Fabric Extender.</p>
<b>tx</b>	(Optional) Specifies the default queue-limit for transmission (egress). <p><b>Note</b> This keyword is supported only on a Cisco Nexus 2248TP-E Fabric Extender.</p>

### Command Default

The default queue-limit for **rx** (ingress) on a Cisco Nexus 2248TP-E Fabric Extender is 1MB.  
The default queue-limit for **tx** (egress) on a Cisco Nexus 2248TP-E Fabric Extender is 4MB.

### Command Modes

Fabric extender configuration mode

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

Command History	Release	Modification
	4.2(1)N2(1)	This command was introduced.
	5.1(3)N1(1)	<p>The Cisco Nexus 2248TP-E Fabric Extender was introduced. The <b>rx</b> and <b>tx</b> keywords was introduced for this Fabric Extender.</p> <p>The queue limit is changed to 5120 to 652800 bytes for all Cisco Nexus 2000 Series Fabric Extender, except Cisco Nexus 2148T Fabric Extender and Cisco Nexus 2248TP-E Fabric Extender.</p> <p><b>Note</b> On a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release prior to 5.1(3)N1(1), the queue limit range was from 2560 to 652800 bytes.</p>

### Usage Guidelines

You can use a lower queue limit value on the Fabric Extender to prevent one blocked receiver from affecting traffic being sent to other noncongested receivers (head-of-line blocking); however, this will increase burst absorption on the ingress traffic. A higher queue limit value provides better burst absorption and less head-of-line blocking protection.

#### Supported Cisco Nexus 2000 Series Fabric Extender

The following Cisco Nexus 2000 Series Fabric Extenders are supported on a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release 4.2(1)N2(1):

- Cisco Nexus 2148T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.
- Cisco Nexus N2224TP Fabric Extender—It has two 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 24 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts. It does not support Fibre Channel over Ethernet (FCoE).
- Cisco Nexus 2232P Fabric Extender—It has eight 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 32 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its downlink connection to servers or hosts.
- Cisco Nexus 2248T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.

The following Cisco Nexus 2000 Series Fabric Extenders are supported on a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release 5.0(3)N2(1):

- Cisco Nexus 2148T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.
- Cisco Nexus N2224TP Fabric Extender—It has two 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 24 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts. It does not support Fibre Channel over Ethernet (FCoE).
- Cisco Nexus 2232P Fabric Extender—It has eight 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 32 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its downlink connection to servers or hosts.

## Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

- Cisco Nexus 2232TM Fabric Extender—It has eight 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 32 10-Gigabit BASE-T Ethernet fabric interfaces for its downlink connection to servers or hosts.
- Cisco Nexus 2248T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.

The following Cisco Nexus 2000 Series Fabric Extenders was introduced on a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release 5.1(3)N1(1):

- Cisco Nexus N2248TP-E Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces with small form-factor pluggable (SFP+) interface adapters for its downlink connection to servers or hosts.

### Examples

This example shows how to configure the hardware buffer queue limit on a Cisco Nexus 2248T Fabric Extender:

```
switch(config)# fex 110
switch(config-fex)# hardware N2248T queue-limit 327680
switch(config-fex)#
```

This example shows how to remove the hardware buffer queue limit configured on a Cisco Nexus 2248T Fabric Extender:

```
switch(config)# fex 110
switch(config-fex)# no hardware N2248T queue-limit
switch(config-fex)#
```

### Related Commands

Command	Description
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
<b>show queuing interface</b>	Displays information about interface queuing parameters, including buffer threshold and queue limits.
<b>show running-config fex</b>	Displays the running configuration for Fabric Extenders.



[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## hardware shared-buffer-size

To configure the shared buffer size for a Cisco Nexus 2000 Series Fabric Extender, use the **hardware shared-buffer-size** command. To revert to the default setting, use the **no** form of this command.

```
hardware fex_card_type shared-buffer-size [buffer-size]
```

```
no hardware fex_card_type shared-buffer-size [buffer-size]
```

Syntax Description		
<i>fex_card_type</i>	Fabric Extender card type. The following Fabric Extender card types are supported:	<ul style="list-style-type: none"> <li><b>N2248TP-E</b>—Fabric Extender 48x1G 4x10G SFP+ Module</li> </ul> See the “Usage Guidelines” section for a description of this Fabric Extender.
<i>buffer-size</i>	(Optional) Shared buffer size (KB). The range is from 10800KB to 25392KB.	

**Command Default** The default size of the shared buffer is 25392KB.

**Command Modes** Fabric Extender configuration mode

Command History	Release	Modification
	5.1(3)N1(1)	This command was introduced.
		The Cisco Nexus N2248TP-E Fabric Extender was introduced.

### Usage Guidelines



**Note**

This command is supported only on a Cisco Nexus 2248TP-E Fabric Extender.

The Cisco Nexus N2248TP-E Fabric Extender has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces with small form-factor pluggable (SFP+) interface adapters for its downlink connection to servers or hosts.

The total available buffer is 32MB which is shared in both direction (ingress, egress).

The default size of the shared buffer is 25392KB. However, when configuring an Ethernet-based pause no-drop class, the shared buffer size changes to 10800KB. This change is required to increase the dedicated buffer that supports the pause no-drop class. The pause no-drop class does not use buffer space from the shared-pool.

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

### Examples

This example shows how to configure the hardware buffer size on a Cisco Nexus 2248TP-E Fabric Extender:

```
switch# configure terminal
switch(config)# fex 100
switch(config-fex)# hardware N2248TTP-E shared-buffer-size 25000
switch(config-fex)#
```

This example shows how to remove the hardware pause no-drop configuration between a Cisco Nexus 2248TTP-E Fabric Extender and a switch:

```
switch# configure terminal
switch(config)# fex 100
switch(config-fex)# no hardware N2248TTP-E shared-buffer-size 25000
switch(config-fex)#
```

### Related Commands

Command	Description
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
<b>show running-config fex</b>	Displays the running configuration for Fabric Extenders.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## hardware uplink-pause-no-drop

To configure a pause no-drop class up to a distance of 3000 meters between the Cisco Nexus 2000 Series Fabric Extender and a Cisco Nexus 5000 Series switch, use the **hardware uplink-pause-no-drop** command. To revert to the default setting, use the **no** form of this command.

**hardware** *fex\_card\_type* **uplink-pause-no-drop distance** [*distance-value*]

**no hardware** *fex\_card\_type* **uplink-pause-no-drop distance** [*distance-value*]

### Syntax Description

<i>fex_card_type</i>	Fabric Extender card type. The following Fabric Extender card types are supported: <ul style="list-style-type: none"> <li><b>N2248TP-E</b>—Fabric Extender 48x1G 4x10G SFP+ Module</li> </ul> See the “Usage Guidelines” section for a description of this Fabric Extender.
<b>distance</b>	Specifies the distance between the Fabric Extender and switch.
<i>distance-value</i>	(Optional) Distance in meters. The range is from 300 to 3000.

### Command Default

The default distance between a Fabric Extender and the switch is 300 meters.

### Command Modes

Fabric Extender configuration mode

### Command History

Release	Modification
5.1(3)N1(1)	This command was introduced. The Cisco Nexus N2248TP-E Fabric Extender was introduced.

### Usage Guidelines



#### Note

This command is supported only on a Cisco Nexus 2248TP-E Fabric Extender.

The Cisco Nexus N2248TP-E Fabric Extender has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces with small form-factor pluggable (SFP+) interface adapters for its downlink connection to servers or hosts.

### Examples

This example shows how to configure the hardware pause no-drop class up to a distance of 3000 meters between a Cisco Nexus 2248TTP-E Fabric Extender and a switch:

```
switch# configure terminal
switch(config)# fex 100
switch(config-fex)# hardware N2248TTP-E pause-no-drop distance 3000
switch(config-fex)#
```

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

This example shows how to remove the hardware pause no-drop configuration between a Cisco Nexus 2248TTP-E Fabric Extender and a switch:

```
switch# configure terminal
switch(config)# fex 100
switch(config-fex)# no hardware N2248TTP-E pause-no-drop distance 3000
switch(config-fex)#
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
<b>show running-config fex</b>	Displays the running configuration for Fabric Extenders.

*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*



## L Commands

---

This chapter describes the Cisco NX-OS commands that begin with L that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## locator-led fex

To turn on the locator LED of a Fabric Extender, use the **locator-led** command. To turn off the locator LED, use the **no** form of this command.

**locator-led fex** *chassis\_ID*

**no locator-led fex** *chassis\_ID*

<b>Syntax Description</b>	<i>chassis_ID</i>	Fabric Extender chassis ID. The range is from 100 to 199.
---------------------------	-------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.1(3)N1(1)	This command was introduced.

<b>Usage Guidelines</b>	Use the <b>locator-led</b> command to toggle the locator LED of a Fabric Extender, which allows you to easily identify the machine in a busy data center.
-------------------------	---

The **locator-led** command replaces the following command, which is deprecated in Cisco NX-OS Release 4.1(3)N1(1) and later releases:

- **[no] beacon**

<b>Examples</b>	This example shows how to turn on the locator LED for a specific Fabric Extender chassis:
-----------------	---

```
switch# locator-led fex 100
switch#
```

This example shows how to turn off the locator beacon LED for a specific Fabric Extender chassis:

```
switch# no locator-led fex 100
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
<b>show locator-led</b>	Displays the status of the locator LED in Fabric Extender modules.	

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## logging fex

To set the logging alert level for Fabric Extender events, use the **logging fex** command. To reset the logging level, use the **no** form of this command.

**logging fex** [*severity-level*]

**no logging fex** [*severity-level*]

<b>Syntax Description</b>	<p><i>severity-level</i> (Optional) Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows:</p> <ul style="list-style-type: none"> <li>• 0—emergency: System unusable</li> <li>• 1—alert: Immediate action needed</li> <li>• 2—critical: Critical condition—default level</li> <li>• 3—error: Error condition</li> <li>• 4—warning: Warning condition</li> <li>• 5—notification: Normal but significant condition</li> <li>• 6—informational: Informational message only</li> <li>• 7—debugging: Appears during debugging only</li> </ul>
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

**Examples** This example shows how to set the logging alert level for Fabric Extender events:

```
switch(config)# logging fex 4
```

This example shows how to reset the logging level:

```
switch(config)# no logging fex
```

Related Commands	Command	Description
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***



*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*



## **P Commands**

---

This chapter describes the Cisco NX-OS commands that begin with P that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## pinning max-links

To specify the number of statically pinned uplinks, use the **pinning max-links** command. To reset to the default, use the **no** form of this command.

**pinning max-links** *uplinks*

**no pinning max-links**

<b>Syntax Description</b>	<i>uplinks</i>	Number of uplinks. The range is from 1 to 8. The default is 1.  This command is applicable only if the Fabric Extender is connected to its parent switch using one or more statically pinned fabric interfaces.
---------------------------	----------------	---

**Command Default** The default number of uplinks is 1.

**Command Modes** Fabric extender configuration mode

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.
	4.2(1)N1(1)	The number of uplinks is extended to 8.
	<b>Note</b>	In releases prior to Cisco NX-OS Release 4.2(1)N1(1), the maximum number of uplinks was 4.

**Usage Guidelines** Use the **pinning max-links** command when you create a number of pinned fabric interface connections to enable the parent switch to determine a distribution of host interfaces. The host interfaces are divided by the number of *uplinks* and distributed accordingly.



**Caution**

Changing the value of *uplinks* is disruptive. All the host interfaces on the Fabric Extender are brought down and back up as the parent switch reassigns its static pinning.

**Examples**

This example shows how to specify the number of statically pinned uplinks for a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# pinning max-links 4
```

This example shows how to revert to the uplink count to the default for a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# no pinning max-links
```

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
	<b>fex pinning redistribute</b>	Redistributes the host interfaces on a Fabric Extender.
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## provision

To preprovision a module in a chassis slot, use the **provision** command. To remove a preprovisioned module from a slot, use the **no** form of this command.

**provision model** *model-name*

**no provision model** [*model-name*]

Syntax Description	model	Specifies the type of module to be provisioned.
	<i>model-name</i>	Module name. The supported modules are as follows: <ul style="list-style-type: none"> <li>• <b>N2K-C2148T</b>—Cisco Nexus 2000 Series Fabric Extender 48x1G 4x10G Module</li> <li>• <b>N2K-C2232P</b>—Cisco Nexus 2000 Series Fabric Extender 32x10G Module</li> <li>• <b>N2K-C2232TM</b>—Cisco Nexus 2000 Series Fabric Extender 32x10G Module</li> <li>• <b>N2K-C2248T</b>—Cisco Nexus 2000 Series Fabric Extender 48x1G 4x10G Module</li> <li>• <b>N2K-N2224TP</b>—Cisco Nexus 2000 Series Fabric Extender 24x1G 2x10G SFP+ Module</li> <li>• <b>N55-M16FP</b>—Cisco 16 port Port Fiber Channel Expansion Module 16 x SFP</li> <li>• <b>N55-M16P</b>—Cisco 16x10-Gigabit Ethernet Expansion Module</li> <li>• <b>N55-M16UP</b>—Cisco 16x10-Gigabit Flexible Ethernet Expansion Module</li> <li>• <b>N55-M8P8FP</b>—Cisco 8 Port 1/2/4/8-Gigabit Fibre Channel + 8 Port 10-Gigabit Ethernet Expansion Module</li> <li>• <b>N5K-M1008</b>—Cisco 8 Port Fiber Channel Expansion Module 8 x SFP</li> <li>• <b>N5K-M1060</b>—Cisco 6 Port Fiber Channel Expansion Module 6 x SFP</li> <li>• <b>N5K-M1404</b>—Expansion Module 4 x 10GBase-T LAN, 4 x Fiber Channel</li> <li>• <b>N5K-M1600</b>—Cisco 6-port 10 Gigabit Ethernet SFP Module 6 x SFP</li> </ul>

**Command Default** None

**Command Modes** Slot configuration mode  
Switch profile configuration mode

## *Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*

### Command History

Release	Modification
5.0(2)N1(1)	This command was introduced.

### Usage Guidelines

Use this command to define the modules (line card or Cisco Nexus 2000 Series Fabric Extender) to preprovision. If the card type does not match the card in the slot or the module is not compatible with the chassis, you see the following messages:

```
ERROR: The card type does not match the card in slot
```

or

```
ERROR: This module cannot be configured for this chassis
```

You can configure features or interfaces (Ethernet, Fibre Channel) on the modules before the modules are inserted in the switch chassis. You can also use this command to manage the configuration of these features or interfaces when the module is offline due to a failure or scheduled downtime. These configurations are applied when the module comes online.

When you preprovision a module by specifying the type of module, platform manager will allow only modules of matching type to come online. If you configure the interfaces for the module without specifying the module type, the configuration is applied when the module comes online, regardless of the module type.

You can preprovision modules and interfaces in a switch profile. The modules and interfaces are preprovisioned when you apply (commit) the switch profile. Once the module is inserted and interfaces are created, the preprovisioning module passes on the configuration to the respective applications before the interfaces come up.

Mutual exclusion is a mechanism where configuration outside the switch profile is not allowed in the switch profile and vice-versa. This requirement is to ensure that configuration in the switch profile is exactly the same on both switches. Preprovisioned configuration is the same as a configuration when the module is online, so mutual exclusion checks would continue to apply normally.

When you downgrade from Cisco NX-OS release 5.0(2)N1(1), which supports preprovisioning, to an earlier release of Cisco NX-OS that does not support module preprovisioning, you will be prompted to remove preprovisioning configuration that you configured on the switch.

### Examples

This example shows how to preprovision a module in slot 2 of the chassis:

```
switch(config)# slot 2
switch(config-slot)# provision model N5K-M1404
switch(config-slot)#
```

This example shows how to remove a preprovisioned module from a chassis slot:

```
switch(config)# slot 2
switch(config-slot)# no provision model N5K-M1404
switch(config-slot)#
```

This example shows how to remove all preprovisioned modules or line cards from a chassis slot:

```
switch(config)# slot 2
switch(config-slot)# no provision model
switch(config-slot)#
```

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show module</b>	Displays module information.
	<b>show provision</b>	Displays provisioned modules.
	<b>show switch-profile</b>	Displays switch profile information.
	<b>show running-config exclude-provision</b>	Displays the running configuration excluding the preprovisioned features.
	<b>slot</b>	Enables a slot for preprovisioning a module.
	<b>switch-profile</b>	Configures a switch profile.

*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*



## S Commands

---

This chapter describes the Cisco NX-OS commands that begin with S that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## serial

To assign a serial number to a Fabric Extender, use the **serial** command. To remove the serial number, use the **no** form of this command.

**serial** *serial\_string*

**no serial**

<b>Syntax Description</b>	<i>serial_string</i>	Serial number string for the Fabric Extender. The string is alphanumeric, case sensitive, and has a maximum length of 20 characters.
---------------------------	----------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Fabric extender configuration mode
----------------------	------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.0(1a)N2(1)	This command was introduced.

**Usage Guidelines** The serial number string you define with the **serial** command must match the serial number of the Fabric Extender. If you configure a serial number and then you use the **fex associate** command to associate the corresponding chassis ID to the switch, the association will succeed only if the Fabric Extender reports a matching serial number string.



### Caution

Configuring a serial number other than that of the given Fabric Extender will force the Fabric Extender offline.

**Examples** This example shows how to specify a serial number for a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# serial Rack16_FEX101
```

This example shows how to remove a serial number from a Fabric Extender:

```
switch# configure terminal
switch(config)# fex 101
switch(config-fex)# no serial
```



***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
	<b>fex associate</b>	Associates a Fabric Extender to an Ethernet or EtherChannel interface.
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

# slot

To enable preprovisioning on a slot in a chassis, use the **slot** command. To disable the slot for preprovisioning, use the **no** form of this command.

**slot** *slot-number*

**no slot** *slot-number*

## Syntax Description

<i>slot-number</i>	Slot number in the chassis. The range is from 2 to 199.
--------------------	---

## Command Default

None

## Command Modes

Global configuration mode  
Configuration synchronization mode

## Command History

Release	Modification
5.0(2)N1(1)	This command was introduced.

## Usage Guidelines

Use this command to enable preprovisioning of features or interfaces of a module on a slot in a chassis. Preprovisioning allows you to configure features or interfaces (Ethernet, Fibre Channel) on modules before the modules are inserted in the switch chassis.

## Examples

This example shows how to enable a chassis slot for preprovisioning of a module:

```
switch(config)# slot 2
switch(config-slot)#
```

This example shows how to disable a chassis slot for preprovisioning of a module:

```
switch(config)# no slot 2
switch(config)#
```

## Related Commands

Command	Description
<b>port</b>	Configures ports as Ethernet, native Fibre Channel or Fibre Channel over Ethernet (FCoE) ports.
<b>provision</b>	Preprovisions a module in a slot.
<b>show running-config exclude-provision</b>	Displays the running configuration excluding the preprovisioned features.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## switchport mode fex-fabric

To set the interface type to be an uplink port for a Fabric Extender, use the **switchport mode fex-fabric** command.

**switchport mode fex-fabric**

**no switchport mode fex-fabric**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Interface configuration mode

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

**Examples** This example shows how to set an Ethernet interface to be an uplink port for a Fabric Extender:

```
switch# configure terminal
switch(config)# interface ethernet 1/40
switch(config-if)# switchport mode fex-fabric
```

This example shows how to set an EtherChannel interface to be an uplink port for a Fabric Extender:

```
switch# configure terminal
switch(config)# interface port-channel 4
switch(config-if)# switchport mode fex-fabric
```

Related Commands	Command	Description
	<b>fex associate</b>	Associates a Fabric Extender to an Ethernet or EtherChannel interface.
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*



## Show Commands

---

This chapter describes the Cisco NX-OS **show** commands used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show diagnostic result fex

To display the results from the diagnostic tests for a Fabric Extender chassis, use the **show diagnostic result fex** command.

**show diagnostic result fex** *chassis\_ID*

<b>Syntax Description</b>	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
<b>Command Default</b>	None	
<b>Command Modes</b>	EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.0(1a)N2(1)	This command was introduced.

### Examples

This example shows how to display the results from the diagnostic tests for a Fabric Extender:

```
switch# show diagnostic result fex 100
FEX-100: 48x1GE/Supervisor SerialNo   : JAF1237ABSE
Overall Diagnostic Result for FEX-100  : OK

Test results: (. = Pass, F = Fail, U = Untested)
TestPlatform:
0)          SPROM: -----> .
1)          MV88E6095: -----> .
2)          Fan: -----> .
3)          Power Supply: -----> .
4) Temperature Sensor: -----> .

TestForwardingPorts:
Eth   1  2  3  4  5  6  7  8  9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
Port -----
      . . . . .

Eth   25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
Port -----
      . . . . .

TestFabricPorts:
Fabric 1  2  3  4
Port -----
      . . . .

switch#
```

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

Related Commands	Command	Description
	show fex	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show environment fex

To display the environmental sensor status, use the **show environment fex** command.

```
show environment fex {all | chassis_ID} [temperature | power | fan]
```

Syntax Description		
<b>all</b>		Displays information for all Fabric Extender chassis.
<i>chassis_ID</i>		Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
<b>temperature</b>		(Optional) Displays temperature sensor information.
<b>power</b>		(Optional) Displays power capacity and power distribution information.
<b>fan</b>		(Optional) Displays fan information.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

### Examples

This example shows how to display the environmental sensor status for a Fabric Extender:

```
switch# show environment fex 100
```

```
Temperature Fex 100:
```

Module	Sensor	MajorThresh (Celsius)	MinorThres (Celsius)	CurTemp (Celsius)	Status
1	Outlet-1	85	75	50	ok
1	Inlet-1	100	90	37	ok

```
Fan Fex: 100:
```

Fan	Model	Hw	Status
Chassis	N2K-C2148-FAN	--	ok
PS-1	N5K-PAC-200W	--	ok
PS-2	--	--	absent

```
Power Supply Fex 100:
```

```
Voltage: 12 Volts
```

PS	Model	Power (Watts)	Power (Amp)	Status
1	N5K-PAC-200W	0.00	0.00	ok



***Send comments to nexus5k-docfeedback@cisco.com***

```

2  --          --          --          --

Mod Model                Power      Power      Power      Power      Status
Requested Requested  Allocated Allocated
(Watts)   (Amp)     (Watts)   (Amp)
-----
1  N5K-C5110T-BF-1GE    24.00     2.00      24.00     2.00      powered-up

Power Usage Summary:
-----
Power Supply redundancy mode:                redundant

Total Power Capacity                          0.00 W

Power reserved for Supervisor(s)              24.00 W
Power currently used by Modules                0.00 W

Total Power Available                          -----
                                              -24.00 W
                                              -----

switch#
    
```

Related Commands	Command	Description
	show fex	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show fex

To display information about a specific Fabric Extender or all attached chassis, use the **show fex** command.

```
show fex [chassis_ID [detail]]
```

Syntax	Description
<i>chassis_ID</i>	(Optional) Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
<b>detail</b>	(Optional) Displays a detailed listing.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

### Examples

This example shows how to display information about all attached Fabric Extender chassis:

```
switch# show fex
FEX          FEX          FEX          FEX
Number      Description    State         Model         Serial
-----
100         FEX0100        Online        N5K-C5110T-BF-1GE  JAF1237ABSE
101         FEX0101        Online        N2K-C2248TP-1GE   JAF11223333
102         FEX0102        Online        N5K-C5110T-BF-1GE  JAF1241BLHQ
105         FEX0105        Online        N2K-C2232P-10GE   JAF1331AKBM
switch#
```

This example shows how to display information about a specific Fabric Extender chassis:

```
switch# show fex 101
FEX: 101 Description: FEX0101 state: Online
  FEX version: 4.2(1)N1(1) [Switch version: 4.2(1)N1(1)]
  Extender Model: N2K-C2248TP-1GE, Extender Serial: JAF11223333
  Part No: 73-12748-01
pinning-mode: static Max-links: 1
Fabric port for control traffic: Eth3/5
Fabric interface state:
  Po5 - Interface Up. State: Active
  Eth3/5 - Interface Up. State: Active
  Eth3/6 - Interface Up. State: Active
switch#
```

This example shows how to display the detailed information about all attached Fabric Extender chassis:

```
switch# show fex detail
FEX: 100 Description: FEX0100 state: Online
  FEX version: 4.2(1)N1(1) [Switch version: 4.2(1)N1(1)]
```

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

```

FEX Interim version: 4.2(1)N1(0.309)
Switch Interim version: 4.2(1)N1(0.309)
Extender Model: N5K-C5110T-BF-1GE, Extender Serial: JAF1237ABSE
Part No: 73-12009-02
Card Id: 70, Mac Addr: 00:0d:ec:b1:13:02, Num Macs: 64
Module Sw Gen: 12594 [Switch Sw Gen: 21]
post level: complete
pinning-mode: static Max-links: 1
Fabric port for control traffic: Eth3/3
Fabric interface state:
  Po12 - Interface Up. State: Active
  Eth3/3 - Interface Up. State: Active
  Eth3/4 - Interface Up. State: Active
Fex Port      State Fabric Port Primary Fabric
  Eth100/1/1   Up      Po12      Po12
  Eth100/1/2   Up      Po12      Po12
  Eth100/1/3   Up      Po12      Po12
  Eth100/1/4   Up      Po12      Po12
  Eth100/1/5   Up      Po12      Po12
  Eth100/1/6   Up      Po12      Po12
  Eth100/1/7   Up      Po12      Po12
  Eth100/1/8   Up      Po12      Po12
  Eth100/1/9   Up      Po12      Po12
  Eth100/1/10  Up      Po12      Po12
  Eth100/1/11  Up      Po12      Po12
  Eth100/1/12  Up      Po12      Po12
  Eth100/1/13  Up      Po12      Po12
  Eth100/1/14  Up      Po12      Po12
  Eth100/1/15  Up      Po12      Po12
  Eth100/1/16  Up      Po12      Po12
  Eth100/1/17  Up      Po12      Po12
  Eth100/1/18  Up      Po12      Po12
  Eth100/1/19  Up      Po12      Po12
  Eth100/1/20  Up      Po12      Po12
  Eth100/1/21  Up      Po12      Po12
  Eth100/1/22  Up      Po12      Po12
  Eth100/1/23  Up      Po12      Po12
--More--
switch#

```

---

**Related Commands**

Command	Description
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.

---

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show fex detail

To display detailed information about a specific Fabric Extender or all attached chassis, use the **show fex detail** command.

### show fex detail

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

**Examples** This example shows how to display detailed information about all attached Fabric Extender chassis:

```
switch# show fex detail
FEX: 100 Description: FEX0100 state: Online
  FEX version: 4.2(1)N1(1) [Switch version: 4.2(1)N1(1)]
  FEX Interim version: 4.2(1)N1(0.326)
  Switch Interim version: 4.2(1)N1(0.326)
  Extender Model: N5K-C5110T-BF-1GE, Extender Serial: JAF1237ABSE
  Part No: 73-12009-02
  Card Id: 70, Mac Addr: 00:0d:ec:b1:13:02, Num Macs: 64
  Module Sw Gen: 12594 [Switch Sw Gen: 21]
  post level: complete
  pinning-mode: static Max-links: 1
  Fabric port for control traffic: Eth3/4
  Fabric interface state:
    Po12 - Interface Up. State: Active
    Eth3/3 - Interface Up. State: Active
    Eth3/4 - Interface Up. State: Active
  Fex Port      State  Fabric Port  Primary Fabric
    Eth100/1/1  Up     Po12         Po12
    Eth100/1/2  Up     Po12         Po12
    Eth100/1/3  Up     Po12         Po12
    Eth100/1/4  Up     Po12         Po12
    Eth100/1/5  Up     Po12         Po12
    Eth100/1/6  Up     Po12         Po12
    Eth100/1/7  Up     Po12         Po12
    Eth100/1/8  Up     Po12         Po12
    Eth100/1/9  Up     Po12         Po12
    Eth100/1/10 Up     Po12         Po12
    Eth100/1/11 Up     Po12         Po12
    Eth100/1/12 Up     Po12         Po12
    Eth100/1/13 Up     Po12         Po12
    Eth100/1/14 Up     Po12         Po12
    Eth100/1/15 Up     Po12         Po12
    Eth100/1/16 Up     Po12         Po12
```

**Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)**

Eth100/1/17	Up	Po12	Po12
Eth100/1/18	Up	Po12	Po12
Eth100/1/19	Up	Po12	Po12
Eth100/1/20	Up	Po12	Po12
Eth100/1/21	Up	Po12	Po12
Eth100/1/22	Up	Po12	Po12
Eth100/1/23	Up	Po12	Po12
Eth100/1/24	Up	Po12	Po12
Eth100/1/25	Up	Po12	Po12
Eth100/1/26	Up	Po12	Po12
Eth100/1/27	Up	Po12	Po12
Eth100/1/28	Up	Po12	Po12
Eth100/1/29	Up	Po12	Po12
Eth100/1/30	Up	Po12	Po12
Eth100/1/31	Up	Po12	Po12
Eth100/1/32	Up	Po12	Po12
Eth100/1/33	Down	Po12	Po12
Eth100/1/34	Down	Po12	Po12
Eth100/1/35	Down	Po12	Po12
Eth100/1/36	Down	Po12	Po12
Eth100/1/37	Down	Po12	Po12
Eth100/1/38	Down	Po12	Po12
Eth100/1/39	Down	Po12	Po12
Eth100/1/40	Up	Po12	Po12
Eth100/1/41	Up	Po12	Po12
Eth100/1/42	Up	Po12	Po12
Eth100/1/43	Up	Po12	Po12
Eth100/1/44	Up	Po12	Po12
Eth100/1/45	Up	Po12	Po12
Eth100/1/46	Up	Po12	Po12
Eth100/1/47	Up	Po12	Po12
Eth100/1/48	Up	Po12	Po12

## Logs:

```

04/16/2010 05:05:23.441707: Module register received
04/16/2010 05:05:23.442886: Registration response sent
04/16/2010 05:05:23.551846: Module Online Sequence
04/16/2010 05:05:56.520856: Module Online
04/16/2010 05:29:38.526605: Deleting route to FEX
04/16/2010 05:29:38.536055: Module disconnected
04/16/2010 05:29:38.537686: Offlining Module
04/16/2010 05:29:38.538260: Module Offline Sequence
04/16/2010 05:29:53.646254: Module Offline
04/16/2010 05:29:54.178401: Deleting route to FEX
04/16/2010 05:29:54.184092: Module disconnected
04/16/2010 05:29:54.186230: Offlining Module
04/16/2010 05:31:13.784346: Module register received
04/16/2010 05:31:13.785410: Registration response sent
04/16/2010 05:31:15.676906: Module Online Sequence
04/16/2010 05:31:50.492714: Module Online
04/16/2010 05:32:18.388033: Deleting route to FEX
04/16/2010 05:32:18.393579: Module disconnected
04/16/2010 05:32:18.394845: Offlining Module
04/16/2010 05:32:18.395412: Module Offline Sequence
04/16/2010 05:32:30.336790: Module Offline
04/16/2010 05:32:30.683558: Deleting route to FEX
04/16/2010 05:32:30.690042: Module disconnected
04/16/2010 05:32:30.692101: Offlining Module
04/16/2010 05:33:42.781911: Module register received
04/16/2010 05:33:42.783432: Registration response sent
04/16/2010 05:33:52.542824: Module Online Sequence
04/16/2010 05:34:33.483417: Module Online
<---output truncated--->
switch#

```

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

Related Commands	Command	Description
	<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show fex transceiver

To display information about the transceiver connecting a Fabric Extender to the Cisco Nexus 5000 Series switch, use the **show fex transceiver** command.

**show fex chassis\_ID transceiver [calibration | detail]**

Syntax Description	
<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
<b>calibration</b>	(Optional) Displays detailed calibration information about the transceiver.
<b>detail</b>	(Optional) Displays detailed diagnostic information about the transceiver.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

### Examples

This example shows how to display information about the transceiver that connects a Fabric Extender to the Cisco Nexus 5000 Series switch:

```
switch# show fex 101 transceiver
```

```
Fex Uplink: 1
Fabric Port: Ethernet3/5
  sfp is present
  name is CISCO-AVAGO
  part number is SFBR-7700SDZ
  revision is B4
  serial number is AGD113921ZR
  nominal bitrate is 10300 Mbits/sec
  Link length supported for 50/125mm fiber is 82 m(s)
  Link length supported for 62.5/125mm fiber is 26 m(s)
  cisco id is --
  cisco extended id number is 4
```

```
Fex Uplink: 2
Fabric Port: Ethernet3/6
  sfp is present
  name is CISCO-AVAGO
  part number is SFBR-7700SDZ
  revision is B4
  serial number is AGD113422LS
  nominal bitrate is 10300 Mbits/sec
  Link length supported for 50/125mm fiber is 82 m(s)
  Link length supported for 62.5/125mm fiber is 26 m(s)
  cisco id is --
  cisco extended id number is 4
```

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

```
Fex Uplink: 3
Fabric Port: --
  sfp is present
  name is CISCO-AVAGO
  part number is SFBR-7700SDZ
  revision is B4
  serial number is AGD11392258
  nominal bitrate is 10300 Mbits/sec
  Link length supported for 50/125mm fiber is 82 m(s)
  Link length supported for 62.5/125mm fiber is 26 m(s)
--More--
switch#
```

---

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.

---



[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show fex version

To display the version information about a Fabric Extender, use the **show fex version** command.

**show fex chassis\_ID version**

<b>Syntax Description</b>	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
---------------------------	-------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.0(1a)N2(1)	This command was introduced.

### Examples

This example shows how to display the version information about a Fabric Extender:

```
switch# show fex 101 version
Software
  Bootloader version:          0.2
  System boot mode:           primary
  System image version:       4.2(1)N1(1) [build 4.2(1)N1(0.309)]

Hardware
  Module:                     Fabric Extender 48x1GE + 4x10G Module
  CPU:                        Motorola, e300c4
  Serial number:              JAF11223333
  Bootflash:                  locked

Kernel uptime is 0 day(s), 3 hour(s), 53 minutes(s), 43 second(s)

Last reset at Wed Mar 31 06:28:41 2010
  Reason: Kernel Reboot
  Service: Reload new image
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show interface fex-fabric

To display all Fabric Extender fabric interfaces, use the **show interface fex-fabric** command.

**show interface fex-fabric**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

**Examples** This example shows how to display all Fabric Extender fabric interfaces:

```
switch# show interface fex-fabric
Fabric      Fabric      Fex      FEX
Fex  Port      Port State  Uplink  Model      Serial
-----
105   Eth1/5      Active   5       N2K-C2232P-10GE  JAF1331AKBM
105   Eth1/6      Active   6       N2K-C2232P-10GE  JAF1331AKBM
105   Eth1/7      Active   8       N2K-C2232P-10GE  JAF1331AKBM
105   Eth1/8      Active   7       N2K-C2232P-10GE  JAF1331AKBM
102   Eth1/17     Active   1       N5K-C5110T-BF-1GE  JAF1241BLHQ
102   Eth1/18     Configured 0       N5K-C5110T-BF-1GE  JAF1241BLHQ
102   Eth1/19     Active   3       N5K-C5110T-BF-1GE  JAF1241BLHQ
102   Eth1/20     Active   4       N5K-C5110T-BF-1GE  JAF1241BLHQ
100   Eth3/3      Active   1       N5K-C5110T-BF-1GE  JAF1237ABSE
100   Eth3/4      Active   2       N5K-C5110T-BF-1GE  JAF1237ABSE
101   Eth3/5      Active   1       N2K-C2248TP-1GE    JAF11223333
101   Eth3/6      Active   2       N2K-C2248TP-1GE    JAF11223333
switch#
```

Related Commands	Command	Description
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show interface fex-intf

To display the host interfaces pinned to a fabric interface, use the **show interface fex-intf** command.

```
show interface interface fex-intf
```

<b>Syntax Description</b>	<i>interface</i>	Ethernet or EtherChannel interface.
---------------------------	------------------	-------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.0(1a)N2(1)	This command was introduced.

### Examples

This example shows how to display the host interfaces pinned to an Ethernet fabric interface on the parent switch:

```
switch# show interface ethernet 1/1 fex-intf
```

This example shows how to display the host interfaces pinned to an EtherChannel fabric interface on the parent switch:

```
switch# show interface port-channel 1 fex-intf
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show interface transceiver fex-fabric

To display information about all transceivers connected to fabric interfaces, use the **show interface transceiver fex-fabric** command.

**show interface transceiver fex-fabric** [**calibration** | **detail**]

Syntax Description	calibration	(Optional) Displays detailed calibration information about the transceiver.
	detail	(Optional) Displays detailed diagnostic information about the transceiver.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	4.0(1a)N2(1)	This command was introduced.

### Examples

This example shows how to display information about all transceivers that connect to fabric interfaces:

```
switch# show interface transceiver fex-fabric
Ethernet1/5
  sfp is present
  name is CISCO-MOLEX INC
  part number is 74752-9025
  revision is A
  serial number is MOC12302468
  nominal bitrate is 12000 Mbits/sec
  Link length supported for 50/125mm fiber is 0 m(s)
  Link length supported for 62.5/125mm fiber is 0 m(s)
  cisco id is --
  cisco extended id number is 4

Ethernet1/6
  sfp is present
  name is CISCO-MOLEX INC
  part number is 74752-9025
  revision is A
  serial number is MOC12260214
  nominal bitrate is 12000 Mbits/sec
  Link length supported for 50/125mm fiber is 0 m(s)
  Link length supported for 62.5/125mm fiber is 0 m(s)
  cisco id is --
  cisco extended id number is 4

Ethernet1/7
  sfp is present
  name is CISCO-MOLEX INC
  part number is 74752-9025
  revision is A
  serial number is MOC12301888
```

***Send comments to nexus5k-docfeedback@cisco.com***

```
nominal bitrate is 12000 Mbits/sec
Link length supported for 50/125mm fiber is 0 m(s)
Link length supported for 62.5/125mm fiber is 0 m(s)
cisco id is --
cisco extended id number is 4
```

```
Ethernet1/8
  sfp is present
  name is CISCO-MOLEX INC
--More--
switch#
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show inventory fex

To display the physical inventory of a Fabric Extender, such as the name, description, and volume ID, use the **show inventory fex** command.

**show inventory fex** *chassis\_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

### Examples

This example shows how to display the physical inventory of a specific Fabric Extender chassis:

```
switch# show inventory fex 100
NAME: "FEX 100 CHASSIS", DESCR: "N5K-C5110T-BF-1GE CHASSIS"
PID: N5K-C5110T-BF-1GE , VID: V01 , SN: JAF1237ABSE

NAME: "FEX 100 Module 1", DESCR: "Fabric Extender Module: 48x1GE, 4X10GE Supervisor"
PID: N5K-C5110T-BF-1GE , VID: V00 , SN: JAF1237ABSE

NAME: "FEX 100 Fan 1", DESCR: "Fabric Extender Fan module"
PID: N2K-C2148-FAN , VID: N/A , SN: N/A

NAME: "FEX 100 Power Supply 1", DESCR: "Fabric Extender AC power supply"
PID: N5K-PAC-200W , VID: 00V0, SN: PAC12473L17

switch#
```

Related Commands	Command	Description
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show locator-led

To display the status of the locator LED in a Fabric Extender, use the **show locator-led** command.

### show locator-led status

<b>Syntax Description</b>	<b>status</b>	Displays the status of the locator LED in a Fabric Extender module.
---------------------------	---------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.2(1)N1(1)	This command was introduced.

<b>Usage Guidelines</b>	Use the <b>locator-led</b> command to toggle the locator LED of a Fabric Extender.
-------------------------	--

**Examples** This example shows how to display the modules that have the locator LED set to off or on:

```
switch# show locator-led status
Component          Locator LED Status
-----
FEX 100            off
FEX 101            off
FEX 102            off
FEX 103            off
FEX 105            off
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>locator-led</b>	Turns on the locator LED of a Fabric Extender chassis.
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show module fex

To display the module information for a Fabric Extender, use the **show module fex** command.

```
show module fex [all | chassis_ID]
```

Syntax Description	chassis_ID	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
	all	Displays information about all Fabric Extender modules.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

### Examples

This example shows how to display the module information of Fabric Extenders:

```
switch# show module fex all
FEX Mod Ports Card Type                               Model                               Status.
-----
100 1    48    Fabric Extender 48x1GE Module                       N5K-C5110T-BF-1GE  present
101 1    48    Fabric Extender 48x1GE + 4x10G Mod N2K-C2248TP-1GE  present
102 1    48    Fabric Extender 48x1GE Module                       N5K-C5110T-BF-1GE  present
105 1    32    Fabric Extender 32x10GE + 8x10G Mo N2K-C2232P-10GE  present

FEX Mod Sw                Hw      World-Wide-Name(s) (WWN)
-----
100 1    4.2(1)N1(1)             0.0     --
101 1    4.2(1)N1(1)             0.103   --
102 1    4.2(1)N1(1)             0.2     --
105 1    4.2(1)N1(1)             1.0     --

FEX Mod  MAC-Address(es)                               Serial-Num
-----
100 1    000d.ecb1.1300 to 000d.ecb1.132f                       JAF1237ABSE
101 1    0022.bdd1.3cc0 to 0022.bdd1.3cef                       JAF11223333
102 1    000d.ecb1.25c0 to 000d.ecb1.25ef                       JAF1241BLHQ
105 1    000d.ecca.6f40 to 000d.ecca.6f5f                       JAF1331AKBM
switch#
```

This commands shows how to display the module information for a specific Fabric Extender:

```
switch# show module fex 100
FEX Mod Ports Card Type                               Model                               Status.
-----
100 1    48    Fabric Extender 48x1GE Module                       N5K-C5110T-BF-1GE  present

FEX Mod Sw                Hw      World-Wide-Name(s) (WWN)
-----
```



***Send comments to nexus5k-docfeedback@cisco.com***

```
100 1 4.2(1)N1(1) 0.0 --
FEX Mod MAC-Address(es) Serial-Num
-----
100 1 000d.ecb1.1300 to 000d.ecb1.132f JAF1237ABSE
switch#
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show provision

To display information about provision, use the **show provision** command.

```
show provision failed-config slot-number
```

Syntax Description	failed-config	Displays the configuration that failed to be applied to the slot.
	<i>slot-number</i>	Slot number in the chassis. The range is from 2 to 199.

**Command Default** None

**Command Modes** EXEC mode  
Configuration synchronization mode

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to display the preprovisioning configuration that failed to be applied to slot 2:

```
switch# show provision failed-config 2
Config has not been applied yet for this slot.

switch#
```

Related Commands	Command	Description
	<b>provision</b>	Preprovisions a module in a slot.
	<b>show running-config exclude-provision</b>	Displays the running configuration excluding the preprovisioned features.
	<b>slot</b>	Enables a slot for preprovisioning a module.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show queuing interface

To display the queuing information of interfaces, use the **show queuing interface** command.

**show queuing interface** [**ethernet** *slot-chassis-no/port-slot-no/port-no*]

Syntax Description	ethernet	(Optional) Specifies that queuing information be displayed for an Ethernet interface or a Fabric Extender.
	<i>slot-chassis-no</i>	Slot number of the Ethernet interface or chassis ID of the Fabric Extender. The range is from 1 to 255.
	<i>port-slot-no</i>	Port number of the Ethernet interface or the remote slot ID of the Fabric Extender. The range is from 1 to 128.
	<i>port-no</i>	Port number of the Fabric Extender. The range is from 1 to 48.

**Command Default** Displays the queuing information for all interfaces.

**Command Modes** EXEC mode

Command History	Release	Modification
	4.1(3)N1(1)	This command was introduced.

**Examples** This example shows how to display the queuing information, including the buffer threshold and queue limit values, of a specified interface on a switch that runs Cisco NX-OS 4.2(1)N2(1):

```
switch# show queuing interface eth101/1/1
Ethernet101/1/1 queuing information:
  Input buffer allocation:
  Qos-group: 0 3 4 (shared)
  frh: 3
  drop-type: drop
  cos: 0 2 3 4 6 7
  xon      xoff      buffer-size
  -----+-----+-----
  11520    21760    44800

  Qos-group: 2
  frh: 2
  drop-type: no-drop
  cos: 1 5
  xon      xoff      buffer-size
  -----+-----+-----
  12800    23040    46080

  Queueing:
  queue    qos-group  cos          priority  bandwidth  mtu
  -----+-----+-----+-----+-----+-----
  3         0 3 4        0 2 3 4 6   WRR       99         9280
  2         2          1 5         WRR       1          9280
```

**Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)**

**Buffer threshold: 163840 bytes**

**Queue limit: 327680 bytes**

Queue Statistics:

```
queue rx
-----+-----
3      38557
2      0
```

Port Statistics:

```
tx queue drop
-----
26374
```

Priority-flow-control enabled: no

Flow-control status:

```
cos      qos-group  rx pause  tx pause  masked rx pause
-----+-----+-----+-----+-----
0         0      xon       xon       xon
1         2      xon       xon       xon
2         3      xon       xon       xon
3         0      xon       xon       xon
4         3      xon       xon       xon
5         2      xon       xon       xon
6         0      xon       xon       xon
7         n/a    xon       xon       xon
```

switch#

This example shows how to display the queuing information, including the buffer threshold and queue limit values, of a specified interface on a switch that runs Cisco NX-OS 5.0(2)N2(1):

```
switch# show queuing interface ethernet 1/4
```

```
Interface Ethernet1/4 TX Queuing
qos-group sched-type oper-bandwidth
0         WRR          50
1         WRR          50
5         priority    0
```

```
Interface Ethernet1/4 RX Queuing
```

```
qos-group 0:
q-size: 102400, MTU: 1538
drop-type: drop, xon: 0, xoff: 640
Statistics:
  Pkts received over the port          : 1
  Ucast pkts sent to the cross-bar     : 0
  Mcast pkts sent to the cross-bar     : 1
  Ucast pkts received from the cross-bar : 1577841
  Pkts sent to the port                 : 1577841
  Pkts discarded on ingress             : 0
  Per-priority-pause status            : Rx (Inactive), Tx (Inactive)
```

```
qos-group 1:
q-size: 76800, MTU: 2240
drop-type: no-drop, xon: 128, xoff: 240
Statistics:
  Pkts received over the port          : 0
  Ucast pkts sent to the cross-bar     : 0
  Mcast pkts sent to the cross-bar     : 0
  Ucast pkts received from the cross-bar : 0
  Pkts sent to the port                 : 0
  Pkts discarded on ingress             : 0
  Per-priority-pause status            : Rx (Inactive), Tx (Inactive)
```

## Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

```

qos-group 5:
  q-size: 122880, MTU: 1538
  drop-type: drop, xon: 0, xoff: 768
  Statistics:
    Pkts received over the port           : 0
    Ucast pkts sent to the cross-bar      : 0
    Mcast pkts sent to the cross-bar      : 0
    Ucast pkts received from the cross-bar : 0
    Pkts sent to the port                 : 1
    Pkts discarded on ingress             : 0
    Per-priority-pause status            : Rx (Inactive), Tx (Inactive)
switch#

```

Table 1 describes the significant fields shown in the display.

**Table 1** *show queuing interface Field Descriptions*

Field	Description
Ethernet ...	Ethernet interface information.
qoS-group	Information about QoS groups configured on the switch.
sched-type	Type of schedule.
WRR	Weighted round robin(WRR). Queue eight for scheduling.
Priority	Priority of the queue.
q-size	Queue size.
drop-type	Queue drop type can be either drop or no-drop.
MTU	Maximum transmit unit (MTU) for the queue.
Xon	Transmission on at this threshold.
Xoff	Transmission off at this threshold.
Buffer threshold	Buffer threshold value for the interface.
Queue limit	Queue limit value for the interface.

### Related Commands

Command	Description
<b>hardware buffer-threshold</b>	Configures the hardware buffer threshold.
<b>hardware queue-limit</b>	Configures the hardware queue limit.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show running-config exclude-provision

To display the running configuration without the configuration for offline preprovisioned interfaces, use the **show running-config exclude-provision** command.

**show running-config exclude-provision**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to display the running configuration without the offline preprovisioned interfaces:

```
switch# show running-config exclude-provision

!Command: show running-config exclude-provision
!Time: Mon Sep  6 08:10:16 2010

version 5.0(2)N1(1)
feature fcoe

feature telnet
feature tacacs+
cfs ipv4 distribute
cfs eth distribute
feature uddl
feature interface-vlan
feature lacp
feature vpc
feature lldp
feature vtp
feature fex

username admin password 5 $1$wmFN7Wly$/pjqx1DfAkCCAg/KyxbUz/ role network-admin
username install password 5 ! role network-admin
username praveena password 5 ! role network-operator
no password strength-check
ip domain-lookup
ip domain-lookup
tacacs-server host 192.168.131.54 key 7 "wawy1234"
tacacs-server host 192.168.131.37
tacacs-server host 192.168.131.37 test username user1
aaa group server tacacs+ t1
    server 192.168.131.54
```

## Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

```

aaa group server tacacs+ tacacs
radius-server host 192.168.128.5 key 7 "KkwyCet" authentication accounting
aaa group server radius r1
    server 192.168.128.5
hostname BEND-2
vlan dot1Q tag native
logging event link-status default
logging event trunk-status default
no service recover-errdisable
errdisable recovery interval 600
no errdisable detect cause link-flap
errdisable recovery cause link-flap
errdisable recovery cause udd
--More--
<--output truncated-->
switch#

```

### Related Commands

Command	Description
<b>copy running-config startup-config</b>	Copies the running configuration to the startup configuration.
<b>provision</b>	Preprovisions a module in a slot.
<b>show provision</b>	Displays the preprovisioned module information.
<b>show startup-config exclude-provision</b>	Displays the startup configuration without the preprovisioning information for offline interfaces.
<b>slot</b>	Configures a chassis slot for a predefined module.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show running-config fex

To display the running configuration for Fabric Extenders (FEXs), use the **show running-config fex** command.

**show running-config fex [all]**

<b>Syntax Description</b>	<b>all</b> (Optional) Displays FEX information including default settings.				
<b>Command Default</b>	None				
<b>Command Modes</b>	EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.2(1)N2(1)</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	4.2(1)N2(1)	This command was introduced.
Release	Modification				
4.2(1)N2(1)	This command was introduced.				

### Examples

This example shows how to display information on the running FEX configuration, including the buffer threshold value and queue limit:

```
switch# show running-config fex

!Command: show running-config fex
!Time: Mon Jul 19 07:56:21 2010

version 4.2(1)N2(1)
feature fex

fex 100
  pinning max-links 1
  description "RedwoodFex100"
fex 101
  pinning max-links 1
  description "FEX0101"
fex 150
  pinning max-links 1
  description "PortolaFex150"
fex 151
  pinning max-links 1
  description "PortolaFex151"
fex 160
  pinning max-links 1
  description "FEX0160"
fex 198
  hardware N2232P queue-limit 50000
  pinning max-links 1
  description "WoodsideFex198"
fex 199
  hardware N2232P queue-limit 20000
  no hardware N2248T queue-limit
  hardware N2148T buffer-threshold 163840
```



***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

```
pinning max-links 1
description "WoodsideFex199"

interface port-channel100
  fex associate 100

interface port-channel150
--More--
switch#
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>hardware buffer-threshold</b>	Configures the hardware buffer threshold.
<b>hardware queue-limit</b>	Configures the hardware queue limit.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show sprom fex

To display information about the SPROM, use the **show sprom fex** command.

```
show sprom fex {all | chassis_ID {all | backplane | powersupply module_no}}
```

Syntax Description		
	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
	<b>all</b>	Displays all SPROM content for a specific Fabric Extender.
	<b>backplane</b>	Displays the backplane SPROM content for a specific Fabric Extender.
	<b>powersupply</b>	Displays the power supply SPROM content for a specific Fabric Extender.
	<i>module_no</i>	Power supply module number for a specific Fabric Extender. The range is from 1 to 2.

Command Default	
	None

Command Modes	
	EXEC mode

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

**Examples** This example shows how to display all SPROM content for a specific Fabric Extender:

```
switch# show sprom fex 100 all
DISPLAY FEX 100 SUP sprom contents
Common block:
Block Signature : 0xabab
Block Version   : 3
Block Length    : 160
Block Checksum  : 0x18c9
EEPROM Size     : 65535
Block Count     : 3
FRU Major Type  : 0x6003
FRU Minor Type  : 0x0
OEM String      : Cisco Systems, Inc.
Product Number  : N5K-C5110T-BF-1GE
Serial Number   : JAF1237ABSE
Part Number     : 73-12009-02
Part Revision   : 00
Mfg Deviation   : 0
H/W Version     : 0.0
Mfg Bits        : 0
Engineer Use    : 0
snmpOID         : 9.12.3.1.9.72.5.0
Power Consump   : -200
RMA Code        : 0-0-0-0
CLEI Code       : 000000000000
VID             : V00
Supervisor Module specific block:
```

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

```

Block Signature : 0x6002
Block Version   : 2
Block Length    : 103
Block Checksum  : 0x2648
Feature Bits    : 0x0
HW Changes Bits : 0x2
Card Index      : 11011
MAC Addresses   : 00-00-00-00-00-00
Number of MACs  : 0
Number of EPLD : 0
Port Type-Num   : 2-52
Sensor #1      : 85,75
Sensor #2      : 100,90
Sensor #3      : 100,90
Sensor #4      : 100,90
Sensor #5      : 100,90
Sensor #6      : 100,90
Sensor #7      : 100,90
Sensor #8      : 100,90
Max Connector Power: 1000
Cooling Requirement: 300
Ambient Temperature: 40

DISPLAY FEX 100 backplane sprom contents:
Common block:
Block Signature : 0xabab
Block Version   : 3
Block Length    : 160
Block Checksum  : 0x195d
EEPROM Size     : 65535
Block Count     : 5
FRU Major Type  : 0x6001
FRU Minor Type  : 0x0
OEM String      : Cisco Systems, Inc.
Product Number  : N5K-C5110T-BF-1GE
Serial Number   : JAF1237ABSE
Part Number     : 73-12009-02
Part Revision   : 00
Mfg Deviation   : 0
H/W Version     : 0.0
Mfg Bits        : 0
Engineer Use    : 0
snmpOID        : 9.12.3.1.3.719.0.0
Power Consump   : -800
RMA Code        : 0-0-0-0
CLEI Code       : 00000000
VID            : V01
Chassis specific block:
Block Signature : 0x6001
Block Version   : 3
Block Length    : 39
Block Checksum  : 0x28a
Feature Bits    : 0x0
HW Changes Bits : 0x2
Stackmib OID    : 0
MAC Addresses   : 00-0d-ec-b1-13-00
Number of MACs  : 64
OEM Enterprise  : 0
OEM MIB Offset  : 0
MAX Connector Power: 0
WWN software-module specific block:
Block Signature : 0x6005
Block Version   : 1
Block Length    : 0

```

**Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)**

```

Block Checksum : 0x66
wnn usage bits:
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00
00 00
License software-module specific block:
Block Signature : 0x6006
Block Version : 1
Block Length : 16
Block Checksum : 0x77
lic usage bits:
00 00 00 00 00 00 00 00

DISPLAY FEX 100 power-supply 1 sprom contents:
Common block:
Block Signature : 0xabab
Block Version : 3
Block Length : 124
Block Checksum : 0x15fc
EEPROM Size : 124
Block Count : 1
FRU Major Type : 0xab01
FRU Minor Type : 0x1
OEM String : Cisco Systems, Inc.
Product Number : N5K-PAC-200W
Serial Number : PAC12473L17
Part Number : 341-0335-01
Part Revision : 01
CLEI Code : COUPADSBA
VID : 00V0
snmpOID : 0.0.0.0.0.0.0.0
H/W Version : 0.1
Current : 1667
RMA Code : 0-0-0-0
switch#

```

## ***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

This command shows how to display the power supply SPROM contents for a specific Fabric Extender:

```
switch# show sptom fex 100 powersupply 1
DISPLAY FEX 100 power-supply 1 sptom contents:
Common block:
Block Signature : 0xabab
Block Version   : 3
Block Length    : 124
Block Checksum  : 0x15fc
EEPROM Size     : 124
Block Count     : 1
FRU Major Type  : 0xab01
FRU Minor Type  : 0x1
OEM String      : Cisco Systems, Inc.
Product Number  : N5K-PAC-200W
Serial Number   : PAC12473L17
Part Number     : 341-0335-01
Part Revision   : 01
CLEI Code       : COUPADSBAA
VID             : 00V0
snmpOID         : 0.0.0.0.0.0.0.0
H/W Version     : 0.1
Current        : 1667
RMA Code        : 0-0-0-0
switch#
```

### Related Commands

Command	Description
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show startup-config exclude-provision

To display the startup configuration that excludes the configuration for offline preprovisioned interfaces, use the **show startup-config exclude-provision** command.

**show startup-config exclude-provision**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** EXEC mode

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to display the startup configuration without the offline preprovisioned interfaces:

```
switch# show startup-config exclude-provision
```

Related Commands	Command	Description
	<b>provision</b>	Preprovisions a module in a slot.
	<b>show provision</b>	Displays the preprovisioned module information.
	<b>show running-config exclude-provision</b>	Displays the running configuration excluding the preprovisioned features.
	<b>slot</b>	Configures a chassis slot for a predefined module.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show system reset-reason fex

To display the reason for the last reset of the Fabric Extender, use the **show system reset-reason fex** command.

```
show system reset-reason fex chassis_ID
```

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

### Examples

This example shows how to display the last reset reason for a specific Fabric Extender:

```
switch# show system reset-reason fex 100
----- reset reason for FEX 100 ---

1) At 430815 usecs after Fri Apr 16 04:27:04 2010
   Reset Reason: Reset Requested by CLI command reload (9)
   Service (Additional Info): Reload requested by supervisor
   Image Version: 4.2(1)N1(1)

2) At 505550 usecs after Fri Apr 16 03:39:50 2010
   Reset Reason: Reset due to upgrade (88)
   Service (Additional Info): Reset due to upgrade
   Image Version: 4.2(1u)N1(1u)

3) At 607267 usecs after Fri Apr 16 02:50:10 2010
   Reset Reason: Reset due to upgrade (88)
   Service (Additional Info): Reset due to upgrade
   Image Version: 4.2(1)N1(1)

4) At 857790 usecs after Fri Apr 16 02:00:22 2010
   Reset Reason: Reset due to upgrade (88)
   Service (Additional Info): Reset due to upgrade
   Image Version: 4.2(1u)N1(1u)

switch#
```

Related Commands	Command	Description
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## show version fex

To display the software version information about a Fabric Extender, use the **show version fex** command.

**show version fex** *chassis\_ID*

Syntax Description	<i>chassis_ID</i>	Fabric Extender chassis ID. The chassis ID range is from 100 to 199.
--------------------	-------------------	--

Command Default	None
-----------------	------

Command Modes	EXEC mode
---------------	-----------

Command History	Release	Modification
	4.2(1)N1(1)	This command was introduced.

### Examples

This example shows how to display the software version of a Fabric Extender:

```
switch# show version fex 100
Software
  Bootloader version:      1.12
  System boot mode:       primary
  System image version:    4.2(1)N2(1) [build 4.2(1)N2(1)]

Hardware
  Module:                  Fabric Extender 48x1GE Module
  CPU:                     Motorola, e300c1
  Serial number:           JAF1302ABDP
  Bootflash:               locked

Kernel uptime is 0 day(s), 9 hour(s), 9 minutes(s), 16 second(s)

Last reset at Fri Jul 02 04:27:04 2010
  Reason: Reset Requested by CLI command reload
  Service: Reload requested by supervisor
switch#
```

Related Commands	Command	Description
	<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.



*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*



## T Commands

---

This chapter describes the Cisco NX-OS commands that begin with T that are used to manage a Cisco Nexus 2000 Series Fabric Extender from a Cisco Nexus 5000 Series switch.

**Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)**

## type

To set the Fabric Extender card type to a specific card, use the **type** command. To revert to the default FEX card, use the **no** form of this command.

**type** *fex\_card\_type*

**no type**

### Syntax Description

<i>fex_card_type</i>	Fabric Extender card type. The following Fabric Extender card types are supported: <ul style="list-style-type: none"> <li>• <b>N2148T</b>—Fabric Extender 48x1G 4x10G SFP+ Module</li> <li>• <b>N2224TP</b>—Fabric Extender 24x1G 2x10G SFP+ Module</li> <li>• <b>N2232P</b>—Fabric Extender 32x10G SFP+ 8x10G SFP+ Module</li> <li>• <b>N2232TM</b>—Fabric Extender 32x10GBase-T 8x10G SFP+ Module</li> <li>• <b>N2248T</b>—Fabric Extender 48x1G 4x10G SFP+ Module</li> </ul>
----------------------	---

### Command Default

None

### Command Modes

Fabric extender configuration mode

### Command History

Release	Modification
4.2(1)N1(1)	This command was introduced.

### Usage Guidelines

The following Cisco Nexus 2000 Series Fabric Extenders are supported on a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release 4.2(1)N2(1):

- Cisco Nexus 2148T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.
- Cisco Nexus N2224TP Fabric Extender—It has two 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 24 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts. It does not support Fibre Channel over Ethernet (FCoE).
- Cisco Nexus 2232P Fabric Extender—It has eight 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 32 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its downlink connection to servers or hosts.
- Cisco Nexus 2248T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.

## ***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

The following Cisco Nexus 2000 Series Fabric Extenders are supported on a Cisco Nexus 5000 Series switch that runs a Cisco NX-OS release 5.0(3)N2(1):

- Cisco Nexus 2148T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.
- Cisco Nexus N2224TP Fabric Extender—It has two 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 24 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts. It does not support Fibre Channel over Ethernet (FCoE).
- Cisco Nexus 2232P Fabric Extender—It has eight 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 32 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its downlink connection to servers or hosts.
- Cisco Nexus 2232TM Fabric Extender—It has eight 10-Gigabit Ethernet fabric interfaces with small form-factor pluggable (SFP+) interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 32 10-Gigabit BASE-T Ethernet fabric interfaces for its downlink connection to servers or hosts.
- Cisco Nexus 2248T Fabric Extender—It has four 10-Gigabit Ethernet fabric interfaces with SFP+ interface adapters for its uplink connection to the parent Cisco Nexus 5000 Series switch and 48 1000BASE-T (1-Gigabit) Ethernet host interfaces for its downlink connection to servers or hosts.

### Examples

This example shows how to configure the Fabric Extender card:

```
switch(config)# fex 100
switch(config-fex)# type N2148T
switch(config-fex)#
```

### Related Commands

Command	Description
<b>fex</b>	Creates a Fabric Extender and enters fabric extender configuration mode.
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.

■ type

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***