



R Commands

This chapter describes the basic Cisco NX-OS system commands that begin with R.

Review Draft -- Cisco Confidential

reload

To reload the switch and all attached Fabric Extender chassis or a specific Fabric Extender, use the **reload** command.

```
reload {all | fex chassis_ID}
```

Syntax Description	all	Reboots the entire Cisco Nexus 5500 Series switch and all attached Fabric Extender chassis.
	fex <i>chassis_ID</i>	Reboots a specific Fabric Extender chassis. The chassis ID is from 100 to 199.

Command Default Reloads the Cisco Nexus 5500 Series switch.

Command Modes EXEC mode

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

Usage Guidelines The **reload** command disrupts traffic on the switch and Fabric Extender.



Note The **reload** command does not save the running configuration. Use the **copy running-config startup-config** command to save the current configuration on the device.

Examples This example shows how to reload the Cisco Nexus 5500 Series switch:

```
switch# copy running-config startup-config
switch# reload
This command will reboot the system. (y/n)? [n] y
```

This example shows how to reload a Fabric Extender:

```
switch# reload fex 101
WARNING: This command will reboot FEX 101
Do you want to continue? (y/n) [n] y
```

Related Commands	Command	Description
	copy running-config startup-config	Copies the current running configuration to the startup configuration.
	show version	Displays information about the software version.

Review Draft -- Cisco Confidential

rmdir

To remove a directory, use the **rmdir** command.

```
rmdir [filesystem: [//server/]] directory
```

Syntax Description

<i>filesystem:</i>	(Optional) Name of the file system. Valid values are bootflash , modflash , or volatile .
<i>//server/</i>	(Optional) Name of the server. Valid values are <i>///</i> , <i>//module-1/</i> , <i>//sup-1/</i> , <i>//sup-active/</i> , or <i>//sup-local/</i> . The double slash (<i>//</i>) is required.
<i>directory</i>	Name of a directory to delete. The directory name is case sensitive.

**Note**

There can be no spaces in the *filesystem://server/directory* string. Individual elements of this string are separated by colons (*:*) and slashes (*/*).

Command Default

None

Command Modes

EXEC mode

Command History

Release	Modification
5.0(2)N1(1)	This command was introduced.

Examples

This example shows how to remove a directory:

```
switch# rmdir my_files
```

Related Commands

Command	Description
cd	Changes the current working directory.
delete	Deletes a file or directory.
dir	Displays the directory contents.
pwd	Displays the name of the current working directory.

Review Draft -- Cisco Confidential

run-script

To run a command script file at the command-line interface (CLI), use the **run-script** command.

```
run-script [filesystem://module/][directory/]filename
```

Syntax Description	
<i>filesystem:</i>	(Optional) Name of a file system. The name is case sensitive.
<i>//module/</i>	(Optional) Identifier for a supervisor module. Valid values are sup-active , sup-local , sup-remote , or sup-standby . The identifiers are case sensitive.
<i>directory/</i>	(Optional) Name of a directory. The name is case sensitive.
<i>filename</i>	Name of the command file. The name is case sensitive.

**Note**

There can be no spaces in the *filesystem://server/directory/filename* string. Individual elements of this string are separated by colons (:) and slashes (/).

Command Default	
None	

Command Modes	
EXEC mode	

Command History	Release	Modification
	5.0(2)N1(1)	This command was introduced.

Usage Guidelines	
You must create the command file on a remote device and download it to the Cisco Nexus 5500 Series switch using the copy command.	

Examples	
This example shows how to run a command script file:	

```
switch# run-script script-file
```

Related Commands	Command	Description
	cd	Changes the current working directory.
	copy	Copies files.
	dir	Displays the directory contents.
	echo	Displays a test string on the terminal.
	pwd	Displays the name of the current working directory.
	sleep	Causes the CLI to pause for a defined number of seconds.

Review Draft -- Cisco Confidential

Review Draft -- Cisco Confidential