



R Commands

This chapter describes the Cisco NX-OS interface commands that begin with R.

rate-limit cpu direction

To set the packet per second (PPS) rate limit for an interface, use the **rate-limit cpu direction** command. To revert to the default value, use the **no** form of this command.

rate-limit cpu direction { **both** | **input** | **output** } **pps** *pps_value* **action log**

no rate-limit cpu direction { **both** | **input** | **output** } **pps** *pps_value* **action log**

Syntax Description		
both		Sets the maximum input and output packet rate.
input		Sets the maximum input packet rate.
output		Sets the maximum output packet rate.
pps <i>pps_value</i>		Specifies the packets per second. The range is from 0 to 100,000.
action		Specifies the action is logged.
log		Writes a syslog message if the PPS value matches or exceeds the specified rate limit.

Command Default None

Command Modes Interface configuration mode

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines This command does not require a license.

Examples This example shows how to set the maximum input packet rate to 3 for an interface and enable the logging of syslog messages:

```
switch# configure terminal
switch(config)# interface ethernet 1/5
switch(config-if)# rate-limit cpu direction input pps 3 action log
switch(config-if)#
```

Related Commands	Command	Description
	show running-config	Displays the running system configuration information.

Related Commands

Command	Description
remote ip address	Configures the IPv4 address for a remote machine.
remote port	Configures the TCP port for a remote machine.
remote vrf	Configures the virtual routing and forwarding (VRF) instance for a remote machine.
show svcs connections	Displays SVS connection information.
svs connection	Enables an SVS connection.

resync-database

To resynchronize the switch profile databases, use the **resync-database** command.

resync-database

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Switch profile configuration mode

Command History	Release	Modification
	5.0(2)N2(1)	This command was introduced.

Examples This example shows how to resynchronize the switch profile databases:

```
switch# configure sync
Enter configuration commands, one per line. End with CNTL/Z.
switch(config-sync)# resync-database
Re-synchronization of switch-profile db takes a few minutes...
Re-synchronize switch-profile db completed successfully.
switch(config-sync)#
```

Related Commands	Command	Description
	switch-profile	Configures a switch profile.