



# Configuring Password Encryption

This chapter describes how to configure password encryption on Cisco NX-OS devices.

This chapter includes the following sections:

- [About AES Password Encryption and Master Encryption Keys, on page 1](#)
- [Licensing Requirements for Password Encryption, on page 1](#)
- [Guidelines and Limitations for Password Encryption, on page 2](#)
- [Default Settings for Password Encryption, on page 2](#)
- [Configuring Password Encryption, on page 2](#)
- [Verifying the Password Encryption Configuration, on page 5](#)
- [Configuration Examples for Password Encryption, on page 5](#)

## About AES Password Encryption and Master Encryption Keys

You can enable strong, reversible 128-bit Advanced Encryption Standard (AES) password encryption, also known as type-6 encryption. To start using type-6 encryption, you must enable the AES password encryption feature and configure a master encryption key, which is used to encrypt and decrypt passwords.

After you enable AES password encryption and configure a master key, all existing and newly created clear-text passwords for supported applications (currently RADIUS and TACACS+) are stored in type-6 encrypted format, unless you disable type-6 password encryption. You can also configure Cisco NX-OS to convert all existing weakly encrypted passwords to type-6 encrypted passwords.

## Licensing Requirements for Password Encryption

The following table shows the licensing requirements for this feature:

Product	License Requirement
Cisco NX-OS	Password encryption requires no license. Any feature not included in a license package is bundled with the nx-os image and is provided at no extra charge to you. For an explanation of the Cisco NX-OS licensing scheme, see the <i>Cisco NX-OS Licensing Guide</i> .

# Guidelines and Limitations for Password Encryption

Password encryption has the following configuration guidelines and limitations:

- Only users with administrator privilege (network-admin) can configure the AES password encryption feature, associated encryption and decryption commands, and master keys.
- RADIUS and TACACS+ are the only applications that can use the AES password encryption feature.
- Configurations containing type-6 encrypted passwords are not rollback compliant.
- You can enable the AES password encryption feature without a master key, but encryption starts only when a master key is present in the system.
- Deleting the master key stops type-6 encryption and causes all existing type-6 encrypted passwords to become unusable, unless the same master key is reconfigured.
- To move the device configuration to another device, either decrypt the configuration before porting it to the other device or configure the same master key on the device to which the configuration will be applied.

## Default Settings for Password Encryption

This table lists the default settings for password encryption parameters.

*Table 1: Default Password Encryption Parameter Settings*

Parameters	Default
AES password encryption feature	Disabled
Master key	Not configured

## Configuring Password Encryption

This section describes the tasks for configuring password encryption on Cisco NX-OS devices.

### Configuring a Master Key and Enabling the AES Password Encryption Feature

You can configure a master key for type-6 encryption and enable the Advanced Encryption Standard (AES) password encryption feature.

#### SUMMARY STEPS

1. `[no] key config-key ascii`
2. `configure terminal`
3. `[no] feature password encryption aes`
4. (Optional) `show encryption service stat`

## 5. copy running-config startup-config

### DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	<p><b>[no] key config-key ascii</b></p> <p><b>Example:</b></p> <pre>switch# key config-key ascii New Master Key: Retype Master Key:</pre>	<p>Configures a master key to be used with the AES password encryption feature. The master key can contain between 16 and 32 alphanumeric characters. You can use the <b>no</b> form of this command to delete the master key at any time.</p> <p>If you enable the AES password encryption feature before configuring a master key, a message appears stating that password encryption will not take place unless a master key is configured. If a master key is already configured, you are prompted to enter the current master key before entering a new master key.</p>
<b>Step 2</b>	<p><b>configure terminal</b></p> <p><b>Example:</b></p> <pre>switch# configure terminal switch(config)#</pre>	Enters global configuration mode.
<b>Step 3</b>	<p><b>[no] feature password encryption aes</b></p> <p><b>Example:</b></p> <pre>switch(config)# feature password encryption aes</pre>	Enables or disables the AES password encryption feature.
<b>Step 4</b>	<p>(Optional) <b>show encryption service stat</b></p> <p><b>Example:</b></p> <pre>switch(config)# show encryption service stat</pre>	Displays the configuration status of the AES password encryption feature and the master key.
<b>Step 5</b>	<p>Required: <b>copy running-config startup-config</b></p> <p><b>Example:</b></p> <pre>switch(config)# copy running-config startup-config</pre>	<p>Copies the running configuration to the startup configuration.</p> <p><b>Note</b> This command is necessary to synchronize the master key in the running configuration and the startup configuration.</p>

## Converting Existing Passwords to Type-6 Encrypted Passwords

You can convert existing plain or weakly encrypted passwords to type-6 encrypted passwords.

### Before you begin

Ensure that you have enabled the AES password encryption feature and configured a master key.

### SUMMARY STEPS

#### 1. encryption re-encrypt obfuscated

**DETAILED STEPS**

	Command or Action	Purpose
<b>Step 1</b>	<b>encryption re-encrypt obfuscated</b> <b>Example:</b> switch# encryption re-encrypt obfuscated	Converts existing plain or weakly encrypted passwords to type-6 encrypted passwords.

## Converting Type-6 Encrypted Passwords Back to Their Original States

You can convert type-6 encrypted passwords back to their original states.

**Before you begin**

Ensure that you have configured a master key.

**SUMMARY STEPS**

1. encryption decrypt type6

**DETAILED STEPS**

	Command or Action	Purpose
<b>Step 1</b>	<b>encryption decrypt type6</b> <b>Example:</b> switch# encryption decrypt type6 Please enter current Master Key:	Converts type-6 encrypted passwords back to their original states.

## Deleting Type-6 Encrypted Passwords

You can delete all type-6 encrypted passwords from the Cisco NX-OS device.

**SUMMARY STEPS**

1. encryption delete type6

**DETAILED STEPS**

	Command or Action	Purpose
<b>Step 1</b>	<b>encryption delete type6</b> <b>Example:</b> switch# encryption delete type6	Deletes all type-6 encrypted passwords.

## Verifying the Password Encryption Configuration

To display password encryption configuration information, perform the following task:

Command	Purpose
<code>show encryption service stat</code>	Displays the configuration status of the AES password encryption feature and the master key.

## Configuration Examples for Password Encryption

The following example shows how to create a master key, enable the AES password encryption feature, and configure a type-6 encrypted password for a TACACS+ application:

```
key config-key ascii
  New Master Key:
  Retype Master Key:
configure terminal
feature password encryption aes
show encryption service stat
  Encryption service is enabled.
  Master Encryption Key is configured.
  Type-6 encryption is being used.
feature tacacs+
tacacs-server key Cisco123
show running-config tacacs+
  feature tacacs+
  logging level tacacs 5
  tacacs-server key 6
"JDYkqyIFWeBvzpljSfWmRzrmRSRE8syxKlOSjP9RCCKFinZbJI3GD5c6rckJR/Qju2PKLmOewbheAA=="
```

