



H Commands

- [ha-policy single](#), on page 4
- [ha-stateful](#), on page 5
- [hardware-telemetry fte](#), on page 6
- [hardware-telemetry inband-telemetry](#), on page 7
- [hardware-telemetry ssx](#), on page 8
- [hardware access-list lou resource threshold](#), on page 9
- [hardware access-list match inner-header](#), on page 10
- [hardware access-list module](#), on page 11
- [hardware access-list tcam label ing-racl 9](#), on page 12
- [hardware access-list tcam region](#), on page 13
- [hardware access-list tcam region double-wide](#), on page 14
- [hardware access-list tcam region qualify udf](#), on page 15
- [hardware access-list tcam region tcp-nat](#), on page 16
- [hardware ecmp hash-offset](#), on page 17
- [hardware ecmp hash-polynomial](#), on page 18
- [hardware ejector enable](#), on page 19
- [hardware fan-zone raise-speed](#), on page 20
- [hardware forwarding funcstats clear](#), on page 21
- [hardware forwarding funcstats disable](#), on page 22
- [hardware forwarding funcstats enable](#), on page 23
- [hardware forwarding l3 resource route non-deterministic](#), on page 24
- [hardware forwarding unicast trace](#), on page 25
- [hardware ip glean throttle](#), on page 26
- [hardware ip glean throttle maximum](#), on page 27
- [hardware ip glean throttle syslog](#), on page 28
- [hardware ip glean throttle timeout](#), on page 29
- [hardware ipv6 glean throttle](#), on page 30
- [hardware ipv6 glean throttle maximum](#), on page 31
- [hardware ipv6 glean throttle syslog](#), on page 32
- [hardware ipv6 glean throttle timeout](#), on page 33
- [hardware module boot-order reverse](#), on page 34
- [hardware multicast global-tx-span](#), on page 35
- [hardware profile buffer info poll-interval timer](#), on page 36

- hardware profile buffer info port-threshold threshold, on page 37
- hardware profile buffer monitor unicast, on page 38
- hardware profile buffer qosgroup threshold, on page 39
- hardware profile buffer span-threshold, on page 40
- hardware profile ecmp auto-recovery threshold, on page 41
- hardware profile ecmp resilient, on page 42
- hardware profile ecmp template module, on page 43
- hardware profile forwarding-mode, on page 44
- hardware profile front portmode, on page 45
- hardware profile ipv6 alpm carve-value, on page 46
- hardware profile ipv6 lpm-entries maximum, on page 47
- hardware profile latency monitor, on page 48
- hardware profile module, on page 49
- hardware profile multicast flex-stats-enable, on page 50
- hardware profile multicast max-limit, on page 51
- hardware profile multicast max-limit lpm-entries, on page 52
- hardware profile multicast nlb, on page 53
- hardware profile multicast optimization disable, on page 54
- hardware profile multicast rpf-check-optimization, on page 55
- hardware profile multicast service-reflect port, on page 56
- hardware profile multicast slow-receiver port, on page 57
- hardware profile multicast syslog-threshold, on page 58
- hardware profile openflow, on page 59
- hardware profile pbr skip-selfip, on page 60
- hardware profile pfc mmu buffer-reservation, on page 61
- hardware profile portmode, on page 62
- hardware profile svi flex-stats-enable, on page 63
- hardware profile tcam ipv6-sup-tcam match-inner, on page 64
- hardware profile tcam region, on page 65
- hardware profile tcam region span qualify udf, on page 66
- hardware profile tcam region spanv6-l2 qualify udf, on page 67
- hardware profile tcam region spanv6 qualify udf, on page 68
- hardware profile tcam resource service-template, on page 69
- hardware profile tcam resource template, on page 70
- hardware profile ucast6 lpm-65-to-127-max-limit, on page 71
- hardware profile ucast6 max-limit, on page 72
- hardware profile unicast enable-host-ecmp, on page 73
- hardware profile unicast syslog-threshold, on page 74
- hardware qos pfc mc-drop, on page 75
- hardware sample-redirect module redirect-interface, on page 76
- head, on page 77
- header-type 2, on page 78
- hello-interval, on page 79
- hello-interval, on page 80
- hello-interval, on page 81
- hex, on page 82

- history, on page 83
- history, on page 84
- history, on page 85
- history, on page 86
- history, on page 87
- history, on page 88
- hold adjacency, on page 89
- hold ip route, on page 90
- hold ipv6 route, on page 91
- hold timeout, on page 92
- holdtime, on page 93
- hop-limit maximum, on page 94
- hop-limit minimum, on page 95
- hop, on page 96
- host-reachability protocol, on page 97
- host-reachability protocol controller, on page 98
- host, on page 99
- host group permit, on page 100
- host source group permit, on page 101
- hostname, on page 102
- hostname dynamic, on page 103
- hostname dynamic, on page 104
- hostname dynamic, on page 105
- hsrp, on page 106
- hsrp anycast, on page 107
- hsrp bfd, on page 108
- hsrp bfd all-interfaces, on page 109
- hsrp delay minimum, on page 110
- hsrp force state vlan, on page 111
- hsrp ipv6, on page 112
- hsrp mac-refresh, on page 113
- hsrp timers extended-hold, on page 114
- hsrp use-bia, on page 115
- hsrp version 1, on page 116
- http get, on page 117
- http proxy server, on page 118
- human, on page 119
- human, on page 120
- hw-module logging onboard, on page 121
- hw-module logging onboard, on page 122

ha-policy single

ha-policy { single-sup <hap-change> | dual-sup <sw-change> } +

Syntax Description

ha-policy	Change HA policy for this VDC
<i>hap-change</i>	Change HA policy for this VDC
single-sup	Change HA policy for this VDC for single-sup situations
dual-sup	Change HA policy for this VDC for dual-sup situations
<i>sw-change</i>	Set hap policy

Command Mode

- /exec/configure/vdc

ha-stateful

[no] ha-stateful

Syntax Description

no	(Optional) Negate a command or set its defaults
ha-stateful	Enable stateful OSPF HA

Command Mode

- /exec/configure/router-ospf

hardware-telemetry fte

[no] hardware-telemetry fte

Syntax Description

hardware-telemetry	Hardware telemetry configuration
fte	Enable/Disable Flow Table Events configuration

Command Mode

- /exec/configure

hardware-telemetry inband-telemetry

[no] hardware-telemetry inband-telemetry

Syntax Description

hardware-telemetry	Hardware telemetry configuration
inband-telemetry	Enable/Disable inband telemetry configuration

Command Mode

- /exec/configure

hardware-telemetry ssx

[no] hardware-telemetry ssx

Syntax Description

hardware-telemetry	Hardware Telemetry Configurations
ssx	enable Streaming Statistics Exporter Configurations

Command Mode

- /exec/configure

hardware access-list lou resource threshold

[no] hardware access-list lou resource threshold <threshold>

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Hardware Internal Information
access-list	Access Control List
lou	LOU
resource	hardware resource
threshold	port expansion threshold
<i>threshold</i>	value of threshold

Command Mode

- /exec/configure

hardware access-list match inner-header

[no] hardware access-list match inner-header

Syntax Description

no	(Optional) Negate the command or set its defaults
hardware	Change hardware usage settings
access-list	Access Control List
match	Match criteria in ACL
inner-header	Match inner header fields in IPinIP/GRE packets

Command Mode

- /exec/configure

hardware access-list module

[no] hardware access-list { resource-pooling | resource pooling } module <module-number>

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Show hardware information
access-list	Access Control List
resource-pooling	Enable ACL programming across TCAM banks
resource	hardware resource
pooling	Enable ACL programming across TCAM banks
module	module number
<i>module-number</i>	specify module number

Command Mode

- /exec/configure

hardware access-list tcam label ing-racl 9

[no] hardware access-list tcam label ing-racl 9

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Hardware Internal Information
access-list	Access Control List
tcam	Configure tcam parameters
label	Team entry label info
ing-racl	Ingress RACL region
9	Size in bits for BD-Labels allocated to Ingress-RACL region

Command Mode

- /exec/configure

hardware access-list tcam region

[no] hardware access-list tcam region <type> <tcam_size>

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Hardware Internal Information
access-list	Access Control List
tcam	Configure tcam parameters
region	Configure tcam region
<i>type</i>	Region type
<i>tcam_size</i>	Enter tcam size

Command Mode

- /exec/configure

hardware access-list tcam region double-wide

[no] hardware access-list tcam region <double-wide-region> <tcam_size> double-wide

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Hardware Internal Information
access-list	Access Control List
tcam	Configure tcam parameters
region	Configure tcam region
<i>double-wide-region</i>	Region type
<i>tcam_size</i>	Enter tcam size
double-wide	Double Width

Command Mode

- /exec/configure

hardware access-list tcam region qualify udf

[no] hardware access-list tcam region <udf_tcam_type> qualify { udf | v6udf } { <udf_name> } +

Syntax Description

no	(Optional) Negate the command
hardware	Change hardware usage settings
access-list	Access Control List
tcam	Configure tcam parameters
region	Configure tcam region
<i>udf_tcam_type</i>	Region type
qualify	Configure UDFs to be qualified for span region
udf	Configure UDF names
v6udf	Configure IPv6 UDF names
<i>udf_name</i>	UDF name

Command Mode

- /exec/configure

hardware access-list tcam region tcp-nat

[no] hardware access-list tcam region tcp-nat <tcam_size>

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Hardware Internal Information
access-list	Access Control List
tcam	Configure tcam parameters
region	Configure tcam region
tcp-nat	TCP NAT region within NAT region
<i>tcam_size</i>	Enter tcam size

Command Mode

- /exec/configure

hardware ecmp hash-offset

[no] hardware ecmp hash-offset <value> [concatenation]

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Change hardware usage settings
ecmp	ECMP configuration
hash-offset	Configure hash offset
<i>value</i>	Hash offset 0-15 non-concatenate mode, 0-63 concatenate mode
concatenation	(Optional) Configure hash concatenation

Command Mode

- /exec/configure

hardware ecmp hash-polynomial

hardware ecmp hash-polynomial <poly-type> | no hardware ecmp hash-polynomial

Syntax Description

no	Negate a command or set its defaults
hardware	Change hardware usage settings
ecmp	ECMP configuration
hash-polynomial	Configure hash polynomial
<i>poly-type</i>	Polynomial type

Command Mode

- /exec/configure

hardware ejector enable

[no] hardware ejector enable

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Hardware Internal Information
ejector	Card ejector functionality
enable	enabled means when both ejectors are open, card is powered down

Command Mode

- /exec/configure

hardware fan-zone raise-speed

[no] hardware fan-zone <fan_zone_id> raise-speed <speed-to-raise>

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Hardware Internal Information
fan-zone	Fan Zone supported in the switch
<i>fan_zone_id</i>	please enter fan zone id whose speed needs to be increased
raise-speed	Speed to be added for current fan zone speed
<i>speed-to-raise</i>	please enter additional fan speed

Command Mode

- /exec/configure

hardware forwarding funcstats clear

hardware forwarding funcstats clear

Syntax Description

hardware	Change hardware usage settings
forwarding	Change forwarding related settings
funcstats	Enable/disable funcstats
clear	Clear funcstats information

Command Mode

- /exec

hardware forwarding funcstats disable

hardware forwarding funcstats disable

Syntax Description

hardware	Change hardware usage settings
forwarding	Change forwarding related settings
funcstats	Enable/disable funcstats
disable	Disable funcstats recording and output

Command Mode

- /exec

hardware forwarding funcstats enable

hardware forwarding funcstats enable

Syntax Description

hardware	Change hardware usage settings
forwarding	Change forwarding related settings
funcstats	Enable/disable funcstats
enable	Enable funcstats recording and output

Command Mode

- /exec

hardware forwarding l3 resource route non-deterministic

[no] hardware forwarding l3 resource route non-deterministic

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	hardware information
forwarding	forwarding information
l3	Layer-3
resource	hardware resources
route	TCAM capacity to hold prefixes
non-deterministic	extend upto 1M

Command Mode

- /exec/configure

hardware forwarding unicast trace

[no] hardware forwarding unicast trace

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Hardware Internal Information
forwarding	Hardware forwarding
unicast	Hardware Unicast forwarding
trace	Debug traces

Command Mode

- /exec/configure

hardware ip glean throttle

[no] hardware ip glean throttle

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Hardware information
ip	IP
glean	Glean
throttle	Throttle

Command Mode

- /exec/configure

hardware ip glean throttle maximum

{ hardware ip glean throttle maximum <count> } | { no hardware ip glean throttle maximum }

Syntax Description

no	Negate a command or set its defaults
hardware	Hardware information
ip	IP
glean	Glean
throttle	Throttle
maximum	Maximum number of entries
<i>count</i>	Count

Command Mode

- /exec/configure

hardware ip glean throttle syslog

{ hardware ip glean throttle syslog <pkt-count> } | { no hardware ip glean throttle syslog }

Syntax Description

no	Negate a command or set its defaults
hardware	Hardware information
ip	IP
glean	Glean
throttle	Throttle
syslog	Threshold for syslog for number of packets hitting the entry
<i>pkt-count</i>	Packet count

Command Mode

- /exec/configure

hardware ip glean throttle timeout

{ hardware ip glean throttle timeout <timeout-in-sec> } | { no hardware ip glean throttle timeout }

Syntax Description

no	Negate a command or set its defaults
hardware	Hardware information
ip	IP
glean	Glean
throttle	Throttle
timeout	Timeout
<i>timeout-in-sec</i>	Timeout value in seconds (should be multiple of 30, else will be rounded off to nearest boundary)

Command Mode

- /exec/configure

hardware ipv6 glean throttle

[no] hardware ipv6 glean throttle

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Hardware information
ipv6	IPv6
glean	Glean
throttle	Throttle

Command Mode

- /exec/configure

hardware ipv6 glean throttle maximum

{ hardware ipv6 glean throttle maximum <count> } | { no hardware ipv6 glean throttle maximum }

Syntax Description

no	Negate a command or set its defaults
hardware	Hardware information
ipv6	IPv6
glean	Glean
throttle	Throttle
maximum	Maximum number of entries
<i>count</i>	Count

Command Mode

- /exec/configure

hardware ipv6 glean throttle syslog

```
{ hardware ipv6 glean throttle syslog <pkt-count> } | { no hardware ipv6 glean throttle syslog }
```

Syntax Description

no	Negate a command or set its defaults
hardware	Hardware information
ipv6	IPv6
glean	Glean
throttle	Throttle
syslog	Threshold for syslog for number of packets hitting the entry
<i>pkt-count</i>	Packet count

Command Mode

- /exec/configure

hardware ipv6 glean throttle timeout

{ hardware ipv6 glean throttle timeout <timeout-in-sec> } | { no hardware ipv6 glean throttle timeout }

Syntax Description

no	Negate a command or set its defaults
hardware	Hardware information
ipv6	IPv6
glean	Glean
throttle	Throttle
timeout	Timeout
<i>timeout-in-sec</i>	Timeout value in seconds (should be multiple of 30, else will be rounded off to nearest boundary)

Command Mode

- /exec/configure

hardware module boot-order reverse

[no] hardware module boot-order reverse

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Hardware Internal Information
module	applies on all the modules
boot-order	Configure order of module power-up
reverse	reverse order of module power-up

Command Mode

- /exec/configure

hardware multicast global-tx-span

[no] hardware multicast global-tx-span

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Change hardware usage settings
multicast	Change multicast setting
global-tx-span	Modify table programming to support TX multicast SPAN across slices

Command Mode

- /exec/configure

hardware profile buffer info poll-interval timer

[no] hardware profile buffer info poll-interval [module <module>] timer <msec>

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Change hardware usage settings
profile	profile settings
buffer	Buffer
info	Information
poll-interval	System buffer status polling interval
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
timer	Polling timer
<i>msec</i>	Polling timer value in msec

Command Mode

- /exec/configure

hardware profile buffer info port-threshold threshold

[no] hardware profile buffer info port-threshold [module <module>] threshold <value>

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Change hardware usage settings
profile	profile settings
buffer	Buffer
info	Information
port-threshold	Set port egress buffer usage threshold
module	(Optional) Slot/module
<i>module</i>	(Optional) Slot/module number
threshold	threshold value
<i>value</i>	percentage of maximum usage

Command Mode

- /exec/configure

hardware profile buffer monitor unicast

hardware profile buffer monitor { unicast | multicast } [internal] [sampling <sampling>] [threshold <threshold>] [interface <intf-num> | sclass <sclass>] | no hardware profile buffer monitor

Syntax Description

no	Negate a command or set its defaults
hardware	Configure hardware profile buffer monitor settings
profile	profile buffer monitor settings
buffer	Buffer
monitor	buffer monitor
unicast	unicast
multicast	multicast
internal	(Optional) enable buffer monitoring internal mode
sampling	(Optional) sampling interval in nano-seconds
<i>sampling</i>	(Optional) sampling interval in nano-seconds
threshold	(Optional) histogram threshold in Kbytes with 384 Kbytes increment
<i>threshold</i>	(Optional) histogram threshold in Kbytes with 384 Kbytes increment
interface	(Optional) enable buffer monitoring on an interface
<i>intf-num</i>	(Optional) enable buffer monitoring on an interface
sclass	(Optional) enable buffer monitoring on a system class of services
<i>sclass</i>	(Optional) enable buffer monitoring on a system class of services

Command Mode

- /exec/configure

hardware profile buffer qosgroup threshold

[no] hardware profile buffer qosgroup <groupid> threshold <percentage>

Syntax Description

no	(Optional) Negate the command
hardware	N3500
profile	Profile
buffer	Buffer
qosgroup	Qos-group
<i>groupid</i>	Group-id
threshold	Threshold
<i>percentage</i>	Percentage of maximum usage

Command Mode

- /exec/configure

hardware profile buffer span-threshold

[no] hardware profile buffer span-threshold <percentage>

Syntax Description

no	(Optional) Negate the command
hardware	N3500
profile	Profile
buffer	Buffer
span-threshold	Span Threshold
<i>percentage</i>	Percentage of maximum usage

Command Mode

- /exec/configure

hardware profile ecmp auto-recovery threshold

hardware profile ecmp auto-recovery threshold <percentage> | no hardware profile ecmp auto-recovery threshold

Syntax Description

no	Negate a command or set its defaults
hardware	Change hardware usage settings
profile	profile settings
ecmp	ECMP settings
auto-recovery	ECMP auto-recovery settings
threshold	ECMP table free percentage threshold for auto-recovery
<i>percentage</i>	Percentage

Command Mode

- /exec/configure

hardware profile ecmp resilient

[no] hardware profile ecmp resilient

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Change hardware usage settings
profile	profile settings
ecmp	ECMP settings
resilient	Configure ECMP resilient mode

Command Mode

- /exec/configure

hardware profile ecmp template module

[no] hardware profile ecmp template [l3vpn] module <module>

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Set hardware profile
profile	Profile settings
ecmp	set the ecmp template profile
template	set the ecmp template profile
l3vpn	(Optional) set the l3vpn ecmp template profile
module	Enter module number
<i>module</i>	

Command Mode

- /exec/configure

hardware profile forwarding-mode

```
[no] hardware profile forwarding-mode { warp [ lpm-entry <lpm_warp> host-entry <host> l2-entry <l2>
mcast-entry <mcst_warp> ] | openflow-hybrid | openflow-only | normal [ lpm-entry <ipv4> mcast-entry
<mcst> ] }
```

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Change hardware usage settings
profile	profile settings
forwarding-mode	Forwarding mode setting
warp	Warp forwarding mode setting
openflow-hybrid	Openflow hybrid forwarding mode setting
openflow-only	Openflow only forwarding mode setting
normal	Normal forwarding mode setting
lpm-entry	(Optional) 4K aligned total IPv4 entries
<i>ipv4</i>	(Optional) 4K aligned total IPv4 entries
mcast-entry	(Optional) 4K aligned total Mcast entries
<i>mcst</i>	(Optional) 4K aligned total Mcast entries
<i>lpm_warp</i>	(Optional) 4K aligned total IPv4 entries
<i>mcst_warp</i>	(Optional) 4K aligned total Mcast entries
host-entry	(Optional) 4K aligned total Host entries
<i>host</i>	(Optional) 4K aligned total Host entries
l2-entry	(Optional) 4K aligned total L2 entries
<i>l2</i>	(Optional) 4K aligned total L2 entries

Command Mode

- /exec/configure

hardware profile front portmode

hardware profile front portmode <port-mode> | no hardware profile front portmode

Syntax Description

no	Negate a command or set its defaults
hardware	Change hardware usage settings
profile	profile settings
front	port 1 QSFP/SFP+ settings
portmode	QSFP or SFP+
<i>port-mode</i>	Configure QSFP/sfp+ port mode

Command Mode

- /exec/configure

hardware profile ipv6 alpm carve-value

[no] hardware profile ipv6 alpm carve-value <ipv6_alpm_carve_value>

Syntax Description

no	(Optional) Negate the command
hardware	Change hardware usage settings
profile	profile settings
ipv6	ipv6
alpm	alpm mode
carve-value	carve value
<i>ipv6_alpm_carve_value</i>	maximum entries

Command Mode

- /exec/configure

hardware profile ipv6 lpm-entries maximum

[no] hardware profile ipv6 lpm-entries maximum <ipv6_lpm_max_entry>

Syntax Description

no	(Optional) Negate the command
hardware	Change hardware usage settings
profile	profile settings
ipv6	ipv6
lpm-entries	lpm(non-host) entries
maximum	maximum limit
<i>ipv6_lpm_max_entry</i>	maximum entries

Command Mode

- /exec/configure

hardware profile latency monitor

hardware profile latency monitor [threshold-avg <threshold-avg>] [threshold-max <threshold-max>] [sampling <sampling>] | no hardware profile latency monitor

Syntax Description

no	Negate a command or set its defaults
hardware	Configure hardware profile latency monitor settings
profile	profile latency monitor settings
latency	latency
monitor	latency monitor
threshold-avg	(Optional) average latency threshold in nano-seconds
<i>threshold-avg</i>	(Optional) average latency threshold in nano-seconds
threshold-max	(Optional) maximum latency threshold in nano-seconds
<i>threshold-max</i>	(Optional) maximum latency threshold in nano-seconds
sampling	(Optional) sampling interval in seconds
<i>sampling</i>	(Optional) sampling interval in seconds

Command Mode

- /exec/configure

hardware profile module

[no] hardware profile [vxlan | mpls] module { all | <module> }

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Set hardware profile
profile	Profile settings
vxlan	(Optional) Set the hardware profile for module to vxlan
mpls	(Optional) Set the hardware profile for module to mpls
module	Enter module number
all	All modules
<i>module</i>	

Command Mode

- /exec/configure

hardware profile multicast flex-stats-enable

[no] hardware profile multicast flex-stats-enable

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Change hardware usage settings
profile	profile settings
multicast	Multicast settings
flex-stats-enable	Enable real time stats

Command Mode

- /exec/configure

hardware profile multicast max-limit

{ hardware profile multicast max-limit <mcast-ent> } | { no hardware profile multicast max-limit }

Syntax Description

no	Negate the command
hardware	Change hardware usage settings
profile	profile settings
multicast	Multicast settings
max-limit	maximum limit for multicast entries
<i>mcast-ent</i>	Mcast Table Entries

Command Mode

- /exec/configure

hardware profile multicast max-limit lpm-entries

[no] hardware profile multicast max-limit lpm-entries <ipv4_mcast_lpm_max_entry>

Syntax Description

no	(Optional) Negate the command
hardware	Change hardware usage settings
profile	profile settings
multicast	Multicast settings
max-limit	maximum limit for multicast entries
lpm-entries	lpm(non-host) entries
<i>ipv4_mcast_lpm_max_entry</i>	maximum entries

Command Mode

- /exec/configure

hardware profile multicast nlb

[no] hardware profile multicast nlb

Syntax Description

no	(Optional) Negate the command
hardware	Change hardware usage settings
profile	profile settings
multicast	Multicast settings
nlb	network load balancing for multicast entries

Command Mode

- /exec/configure

hardware profile multicast optimization disable

[no] hardware profile multicast optimization disable

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Set hardware profile
profile	Profile settings
multicast	set multicast profile
optimization	set multicast optimization profile
disable	set the multicast optimization disable profile

Command Mode

- /exec/configure

hardware profile multicast rpf-check-optimization

```
{ hardware profile multicast rpf-check-optimization } | { no hardware profile multicast rpf-check-optimization }  
}
```

Syntax Description

no	Negate the command
hardware	Change hardware usage settings
profile	profile settings
multicast	Multicast settings
rpf-check-optimization	RPF Check optimization on Monticello ASIC

Command Mode

- /exec/configure

hardware profile multicast service-reflect port

```
{ hardware profile multicast service-reflect port <port-num> } | { no hardware profile multicast service-reflect }
}
```

Syntax Description

no	Negate a command or set its defaults
hardware	Change hardware usage settings
profile	profile settings
multicast	Multicast settings
service-reflect	service-reflect settings
port	loopback port
<i>port-num</i>	loopback port-num

Command Mode

- /exec/configure

hardware profile multicast slow-receiver port

hardware profile multicast slow-receiver port <port> | no hardware profile multicast slow-receiver port <port>

Syntax Description

no	Negate the command
hardware	Change hardware usage settings
profile	Profile
multicast	Multicast settings
slow-receiver	Multicast slow receiver
port	Port
<i>port</i>	Port number

Command Mode

- /exec/configure

hardware profile multicast syslog-threshold

[no] hardware profile multicast syslog-threshold <percentage>

Syntax Description

no	(Optional) Negate the command
hardware	Change hardware usage settings
profile	profile settings
multicast	Multicast settings
syslog-threshold	MROUTE table syslog threshold
<i>percentage</i>	Percentage (Default is 90)

Command Mode

- /exec/configure

hardware profile openflow

```
[no] hardware profile { openflow [ agent default { drop | normal } ] | { tap-aggregation [ l2drop ] } }
```

Syntax Description

no	(Optional) Negate the command
hardware	Hardware Internal Information
profile	Profile
openflow	Openflow
tap-aggregation	Tap Aggregation
l2drop	(Optional) Drop non IP traffic ingress on mode tap interfaces
agent	(Optional) Act as Openflow Agent
default	(Optional) Specify default action for frames which don't match any flow
drop	(Optional) Drop all frames that miss MAC
normal	(Optional) [default]Flood unknown traffic

Command Mode

- /exec/configure

hardware profile pbr skip-selfip

[no] hardware profile pbr skip-selfip

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Change hardware usage settings
profile	profile settings
pbr	PBR feature settings
skip-selfip	Configure Skipping PBR for self-ip packets

Command Mode

- /exec/configure

hardware profile pfc mmu buffer-reservation

[no] hardware profile pfc mmu buffer-reservation <percentage>

Syntax Description

no	(Optional) Negate the command
hardware	Hardware Internal Information
profile	profile settings
pfc	System level priority-flow-control settings
mmu	Hardware memory management unit configuration
buffer-reservation	Shared pool buffer reservation
<i>percentage</i>	Percentage of shared pool buffers to be reserved

Command Mode

- /exec/configure

hardware profile portmode

{ hardware profile portmode <port-mode> [2-tuple] } | no hardware profile portmode

Syntax Description

no	Negate a command or set its defaults
hardware	Change hardware usage settings
profile	profile settings
portmode	QSFP port mode setting
<i>port-mode</i>	Configure QSFP port mode
2-tuple	(Optional) Display QSFP portnames in 2-tuple mode even in 10G mode

Command Mode

- /exec/configure

hardware profile svi flex-stats-enable

[no] hardware profile svi flex-stats-enable

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Change hardware usage settings
profile	profile settings
svi	SVI settings
flex-stats-enable	Enable real time stats

Command Mode

- /exec/configure

hardware profile tcam ipv6-sup-tcam match-inner

```
{ hardware profile tcam ipv6-sup-tcam match-inner } | { no hardware profile tcam ipv6-sup-tcam match-inner }  
}
```

Syntax Description

no	Negate a command or set its defaults
hardware	Change hardware usage settings
profile	Profile settings
tcam	Configure tcam parameters
ipv6-sup-tcam	IPv6 SUP TCAM parameters
match-inner	match inner payload for tunnel packets

Command Mode

- /exec/configure

hardware profile tcam region

```
[no] hardware profile tcam region { <tcam_compat_type> <tcam_compat_size> | ifacl <tcam_compat_size>
[ double-wide ] | nat <tcam_compat_size> }
```

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Hardware Internal Information
profile	profile
tcam	Configure tcam parameters
region	Configure tcam region
ifacl	IPV4 PACL size
double-wide	(Optional) Configure tcam as double wide
nat	NAT size
<i>tcam_compat_type</i>	
<i>tcam_compat_size</i>	Enter tcam size

Command Mode

- /exec/configure

hardware profile tcam region span qualify udf

[no] hardware profile tcam region span qualify udf { <udf_name> } +

Syntax Description

no	(Optional) Negate the command
hardware	Change hardware usage settings
profile	Profile settings
tcam	Configure tcam parameters
region	Configure tcam region
span	Configure for span region
qualify	Configure UDFs to be qualified for span region
udf	Configure UDF names
<i>udf_name</i>	UDF name

Command Mode

- /exec/configure

hardware profile tcam region spanv6-l2 qualify udf

[no] hardware profile tcam region spanv6-l2 qualify udf { <udf_name> } +

Syntax Description

no	(Optional) Negate the command
hardware	Change hardware usage settings
profile	Profile settings
tcam	Configure tcam parameters
region	Configure tcam region
spanv6-l2	Configure for span region
qualify	Configure UDFs to be qualified for span region
udf	Configure UDF names
<i>udf_name</i>	UDF name

Command Mode

- /exec/configure

hardware profile tcam region spanv6 qualify udf

[no] hardware profile tcam region spanv6 qualify udf { <udf_name> } +

Syntax Description

no	(Optional) Negate the command
hardware	Change hardware usage settings
profile	Profile settings
tcam	Configure tcam parameters
region	Configure tcam region
spanv6	Configure for span region
qualify	Configure UDFs to be qualified for span region
udf	Configure UDF names
<i>udf_name</i>	UDF name

Command Mode

- /exec/configure

hardware profile tcam resource service-template

[no] hardware profile tcam resource service-template { <name> } [module { <lc> | <fm> }]

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Change hardware usage settings
profile	Profile settings
tcam	Configure tcam parameters
resource	Configure tcam hardware resources
service-template	Commit template
<i>name</i>	Select name of template
module	(Optional) Specify a module number
<i>lc</i>	(Optional) line card number
<i>fm</i>	(Optional) fabric module number

Command Mode

- /exec/configure handle auto 424

hardware profile tcam resource template

```
[no] hardware profile tcam resource template { <name> { ref-template <temp-nontahoe> | ref-template-tahoe
<temp-tahoe> } }
```

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Change hardware usage settings
profile	Profile settings
tcam	Configure tcam parameters
resource	Configure tcam hardware resources
template	Configure template based tcam carving parameters
ref-template	Select a default template as reference
<i>temp-nontahoe</i>	
ref-template-tahoe	Select a default template as reference
<i>temp-tahoe</i>	
<i>name</i>	Create/Select name of custom template

Command Mode

- /exec/configure

hardware profile ucast6 lpm-65-to-127-max-limit

```
{ hardware profile ucast6 lpm-65-to-127-max-limit <unicast-ent> } | { no hardware profile ucast6 lpm-65-to-127-max-limit }
```

Syntax Description

no	Negate the command
hardware	Change hardware usage settings
profile	profile settings
uicast6	unicast ipv6 settings
lpm-65-to-127-max-limit	maximum limit for unicast ipv6 lpm-65-to-127 entries, default is 256
<i>unicast-ent</i>	Unicast ipv6 lpm-65-to-127 Table Entries

Command Mode

- /exec/configure

hardware profile ucast6 max-limit

{ hardware profile ucast6 max-limit <unicast-ent> } | { no hardware profile ucast6 max-limit }

Syntax Description

no	Negate the command
hardware	Change hardware usage settings
profile	profile settings
ucast6	unicast ipv6 settings
max-limit	maximum limit for unicast ipv6 entries
<i>unicast-ent</i>	Unicast ipv6 Table Entries

Command Mode

- /exec/configure

hardware profile unicast enable-host-ecmp

[no] hardware profile unicast enable-host-ecmp [arp-nd | [ipv4 [arp]] | [ipv6 [nd]]]

Syntax Description

no	(Optional) Negate the command
hardware	Change hardware usage settings
profile	profile settings
unicast	Unicast settings
enable-host-ecmp	Enable ECMP support for /32 (IPv4) and /128 (IPv6) routes
ipv4	(Optional) Enable ECMP support for /32 (IPv4 Only) Routes
ipv6	(Optional) Enable ECMP support for /128 (IPv6 Only) Routes
arp-nd	(Optional) Retain ARP (IPv4) and ND (IPv6) Routes in Host-Table
arp	(Optional) Retain ARP Entries in Host-Table
nd	(Optional) Retain ND Entries in Host-Table

Command Mode

- /exec/configure

hardware profile unicast syslog-threshold

```
{ hardware profile unicast syslog-threshold <percentage> } | { no hardware profile unicast syslog-threshold }  
}
```

Syntax Description

no	Negate the command
hardware	Change hardware usage settings
profile	profile settings
unicast	Unicast settings
syslog-threshold	Unicast Route table syslog threshold
<i>percentage</i>	Percentage

Command Mode

- /exec/configure

hardware qos pfc mc-drop

[no] hardware qos pfc mc-drop

Syntax Description

no	(Optional) Negate a command or set its defaults
hardware	Hardware Internal Information
qos	Configure qos related configuration
pfc	Priority-flow-control specific configuration
mc-drop	Multicast packets are dropped in lossless queue

Command Mode

- /exec/configure

hardware sample-redirect module redirect-interface

hardware sample-redirect module <num> redirect-interface <interface>

Syntax Description

hardware	Change hardware usage settings
sample-redirect	Redirect netflow sampled data
module	Line card module
<i>num</i>	slot number
redirect-interface	Interface for redirecting the traffic
<i>interface</i>	Interface Name

Command Mode

- /exec

head

| head [-n <lines>]

Syntax Description

	Pipe command output to filter
head	Display first lines
-n	(Optional) modify number of lines (default 10)
<i>lines</i>	(Optional) number of lines to print

Command Mode

- /output

header-type 2

[no] header-type { 2 | 3 [rfc-compliant] }

Syntax Description

no	(Optional) Negate a command or set its defaults
header-type	Set ERSPAN Source version
2	ERSPAN Source Version 2
3	ERSPAN Source Version 3
rfc-compliant	(Optional) ERSPAN V3 header rfc-compliant

Command Mode

- /exec/configure/config-monitor-erspan-src

hello-interval

```
{ { hello-interval <interval> } | { no hello-interval [ <interval> ] } }
```

Syntax Description

no	Negate a command or set its defaults
hello-interval	Hello interval
<i>interval</i>	(seconds)

Command Mode

- /exec/configure/router-ospf/router-ospf-vlink /exec/configure/router-ospf/vrf/router-ospf-vlink

hello-interval

```
{ { hello-interval <interval> } | { no hello-interval [ <interval> ] } }
```

Syntax Description

no	Negate a command or set its defaults
hello-interval	Hello interval
<i>interval</i>	(seconds)

Command Mode

- /exec/configure/router-ospf3/router-ospf3-vlink /exec/configure/router-ospf3/vrf/router-ospf3-vlink

hello-interval

```
{ { hello-interval <interval> } | { no hello-interval [ <interval> ] } }
```

Syntax Description

no	Negate a command or set its defaults
hello-interval	Hello interval
<i>interval</i>	(seconds)

Command Mode

- /exec/configure/router-ospf/vrf/router-ospf-slink

hex

hex <expr>

Syntax Description

hex	calculator with results in decimal format
<i>expr</i>	the expression to compute (integer arithmetics)

Command Mode

- /exec

history

```
history { { buckets-kept <num-buckets-kept> } | { distributions-of-statistics-kept <num-dist-stats> } | {
enhanced [ interval [ <interval-seconds> [ buckets [ <num-buckets> ] ] ] ] | { filter { all | failures | none |
overThreshold } } | { hours-of-statistics-kept <num-hours-of-stats> } | { lives-kept <life-size-value> } | {
statistics-distribution-interval <dist-interval> } }
```

Syntax Description

<i>interval</i>	(Optional) buckets
<i>interval-seconds</i>	(Optional) <num-buckets>
<i>life-size-value</i>	<dist-interval>
history	History and Distribution Data
buckets-kept	Maximum number of history buckets to collect
<i>num-buckets-kept</i>	Bucket size value (default 15)
distributions-of-statistics-kept	Maximum number of statistics distribution buckets to capture
<i>num-dist-stats</i>	Distribution bucket size value (default 1)
enhanced	Enable enhanced history collection
buckets	(Optional) Number of buckets to collect data
<i>num-buckets</i>	(Optional) Number of buckets
filter	Add operation to History when...
all	Collect every operation in History
failures	Collect operations that fail in History
none	Shutoff History collection
overThreshold	Collect operations that are over threshold in History
hours-of-statistics-kept	Maximum number of statistics hour groups to capture
<i>num-hours-of-stats</i>	Hour groups size value (default 2)
lives-kept	Maximum number of history lives to collect
statistics-distribution-interval	Statistics distribution interval size
<i>dist-interval</i>	Distribution interval value in msec (default 20ms), Value in usec if precision microsecond is enabled

Command Mode

- /exec/configure/ip-sla/udp /exec/configure/ip-sla/tcp /exec/configure/ip-sla/icmpEcho

history

```
{ no | default } history { { buckets-kept } | { distributions-of-statistics-kept } | { enhanced [ interval [
<interval-seconds> [ buckets [ <num-buckets> ] ] ] ] } | { filter } | { hours-of-statistics-kept } | { lives-kept }
| { statistics-distribution-interval } }
```

Syntax Description

no	
<i>interval</i>	(Optional) buckets
default	Set a command to its defaults
history	History and Distribution Data
buckets-kept	Maximum number of history buckets to collect
distributions-of-statistics-kept	Maximum number of statistics distribution buckets to capture
enhanced	Enable enhanced history collection
<i>interval-seconds</i>	(Optional) Interval in seconds
buckets	(Optional) Number of buckets to collect data
<i>num-buckets</i>	(Optional) Number of buckets
filter	Add operation to History when...
hours-of-statistics-kept	Maximum number of statistics hour groups to capture
lives-kept	Maximum number of history lives to collect
statistics-distribution-interval	Statistics distribution interval size

Command Mode

- /exec/configure/ip-sla/udp /exec/configure/ip-sla/tcp /exec/configure/ip-sla/icmpEcho

history

```
{ no | default } history { { buckets-kept } | { distributions-of-statistics-kept } | { filter } | { hours-of-statistics-kept } | { lives-kept } | { statistics-distribution-interval } }
```

Syntax Description

no	
default	Set a command to its defaults
history	History and Distribution Data
buckets-kept	Maximum number of history buckets to collect
distributions-of-statistics-kept	Maximum number of statistics distribution buckets to capture
filter	Add operation to History when...
hours-of-statistics-kept	Maximum number of statistics hour groups to capture
lives-kept	Maximum number of history lives to collect
statistics-distribution-interval	Statistics distribution interval size

Command Mode

- /exec/configure/ip-sla/dns /exec/configure/ip-sla/fabricPathEcho /exec/configure/ip-sla/http

history

```
history { { buckets-kept <num-buckets-kept> } | { distributions-of-statistics-kept <num-dist-stats> } | { filter
{ all | failures | none | overThreshold } } | { hours-of-statistics-kept <num-hours-of-stats> } | { lives-kept
<life-size-value> } | { statistics-distribution-interval <dist-interval> } }
```

Syntax Description

<i>dist-interval</i>	<num-buckets-kept>
<i>num-hours-of-stats</i>	<life-size-value>
<i>distributions-of-statistics-kept</i>	hours-of-statistics-kept
<i>statistics-distribution-interval</i>	
history	History and Distribution Data
buckets-kept	Maximum number of history buckets to collect
<i>num-buckets-kept</i>	Bucket size value (default 15)
<i>num-dist-stats</i>	Distribution bucket size value (default 1)
filter	Add operation to History when...
all	Collect every operation in History
failures	Collect operations that fail in History
none	Shutoff History collection
overThreshold	Collect operations that are over threshold in History
hours-of-statistics-kept	Maximum number of statistics hour groups to capture
lives-kept	Maximum number of history lives to collect
<i>life-size-value</i>	Life size value (default 0)

Command Mode

- /exec/configure/ip-sla/dns /exec/configure/ip-sla/fabricPathEcho /exec/configure/ip-sla/http

history

```
{ no | default } history { { distributions-of-statistics-kept } | { enhanced [ interval [ <interval-seconds> [ buckets [ <num-buckets> ] ] ] ] } | { hours-of-statistics-kept } | { statistics-distribution-interval } }
```

Syntax Description

no	
<i>interval</i>	(Optional) buckets
<i>distributions-of-statistics-kept</i>	hours-of-statistics-kept
<i>statistics-distribution-interval</i>	
default	Set a command to its defaults
history	History and Distribution Data
enhanced	Enable enhanced history collection
<i>interval-seconds</i>	(Optional) Interval in seconds
buckets	(Optional) Number of buckets to collect data
<i>num-buckets</i>	(Optional) Number of buckets
hours-of-statistics-kept	Maximum number of statistics hour groups to capture

Command Mode

- /exec/configure/ip-sla/jitter

history

```
history { { distributions-of-statistics-kept <num-dist-stats> } | { enhanced [ interval [ <interval-seconds> [
buckets [ <num-buckets> ] ] ] ] } | { hours-of-statistics-kept <num-hours-of-stats> } | {
statistics-distribution-interval <dist-interval> } }
```

Syntax Description

<i>interval</i>	(Optional) buckets
<i>num-buckets</i>	(Optional) <num-hours-of-stats>
<i>enhanced</i>	hours-of-statistics-kept
history	History and Distribution Data
distributions-of-statistics-kept	Maximum number of statistics distribution buckets to capture
<i>num-dist-stats</i>	Distribution bucket size value (default 1)
<i>interval-seconds</i>	(Optional) Interval in seconds
buckets	(Optional) Number of buckets to collect data
hours-of-statistics-kept	Maximum number of statistics hour groups to capture
<i>num-hours-of-stats</i>	Hour groups size value (default 2)
statistics-distribution-interval	Statistics distribution interval size
<i>dist-interval</i>	Distribution interval value in msec (default 20ms), Value in usec if precision microsecond is enabled

Command Mode

- /exec/configure/ip-sla/jitter

hold adjacency

hold adjacency <all>

Syntax Description

hold	Hold
adjacency	Display adjacency table
all	Hold all adjcencies

Command Mode

- /exec

hold ip route

```
hold ip { route | rnh } [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] <all>
```

Syntax Description

hold	Hold
ip	IPv4
route	Hold routing information
rnh	Hold only RNH information
vrf	(Optional) VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
all	Hold all routes

Command Mode

- /exec

hold ipv6 route

```
hold ipv6 route [ vrf { <vrf-name> | <vrf-known-name> | <vrf-all> } ] <all>
```

Syntax Description

hold	Hold
ipv6	IPv6
route	Hold routing information
vrf	(Optional) VRF
<i>vrf-name</i>	(Optional) VRF name
<i>vrf-known-name</i>	(Optional) Known VRF name
vrf-all	(Optional) Display information for all VRFs
all	Hold all routes

Command Mode

- /exec

hold timeout

hold timeout <timeout_val>

Syntax Description

hold	Hold timer
timeout	timer timeout
<i>timeout_val</i>	timeout duration in seconds

Command Mode

- /exec/configure/vpc-domain

holdtime

holdtime { infinite | <secs> } | no holdtime

Syntax Description

no	Negate a command or set its defaults
holdtime	LDP session holdtime
infinite	Ignore LDP session holdtime
<i>secs</i>	Holdtime in seconds

Command Mode

- /exec/configure/ldp

hop-limit maximum

[no] hop-limit maximum <limit>

Syntax Description

no	(Optional) Negate a command or set its defaults
<i>limit</i>	Maximum hop count value allowed

Command Mode

- /exec/configure/config-ra-guard

hop-limit minimum

[no] hop-limit minimum <limit>

Syntax Description

no	(Optional) Negate a command or set its defaults
<i>limit</i>	Minimum hop count value allowed

Command Mode

- /exec/configure/config-ra-guard

hop

{ hop <val> } | { no hop }

Syntax Description

no	Negate a command or set its defaults
hop	Configure ngoam hop count
<i>val</i>	Configure ngoam service hop count value

Command Mode

- /exec/configure/configngoamprofile

host-reachability protocol

[no] host-reachability protocol { bgp | openflow | openflow-ir }

Syntax Description

no	(Optional) Negate a command or set its defaults
host-reachability	Configure host reachability advertisement
protocol	Control protocol to use
bgp	Border Gateway Protocol
openflow	OpenFlow
openflow-ir	OpenFlow-IR

Command Mode

- /exec/configure/if-nve

host-reachability protocol controller

[no] host-reachability protocol controller <controller-id>

Syntax Description

no	(Optional) Negate a command or set its defaults
host-reachability	Configure host reachability advertisement
protocol	Control protocol to use
controller	Controller
<i>controller-id</i>	Controller id value

Command Mode

- /exec/configure/if-nve

host

[no] { host <hostaddr> | <prefix> | <addr> <mask> }

Syntax Description

no	(Optional) Negate a command or set its defaults
host	Host address of the object-group member
<i>hostaddr</i>	A.B.C.D Host address
<i>addr</i>	A.B.C.D Network address of object-group member
<i>mask</i>	A.B.C.D wildcard
<i>prefix</i>	A.B.C.D/nn Network prefix of the object-group member

Command Mode

- /exec/configure/objgroup

host group permit

```
{ <seq> host <hostip> group <range> { permit | deny } } | { no <seq> [ host <hostip> group <range> { permit | deny } ] }
```

Syntax Description

<i>seq</i>	Sequence Number
host	Host IP Address
<i>hostip</i>	Host IP Address
group	Configure explicit group ranges
<i>range</i>	Group Prefix
permit	Admission Permitted
deny	Admission Denied

Command Mode

- /exec/configure/nbm-host-policy/sender

host source group permit

```
{ <seq> host <hostip> source <sourceip> group <range> { permit | deny } } | { no <seq> [ host <hostip>  
source <sourceip> group <range> { permit | deny } ] }
```

Syntax Description

<i>seq</i>	Sequence Number
host	Host IP Address
<i>hostip</i>	Host IP Address value
source	Source IP Address
<i>sourceip</i>	Source IP Address value
group	Configure explicit group ranges
<i>range</i>	Group Prefix
permit	Admission Permitted
deny	Admission Denied

Command Mode

- /exec/configure/nbm-host-policy/receiver

hostname

{ hostname | switchname } <name> | no { hostname | switchname }

Syntax Description

no	Negate a command or set its defaults
hostname	Configure system's host name
switchname	Configure system's host name
<i>name</i>	Enter switchname

Command Mode

- /exec/configure

hostname dynamic

[no] hostname dynamic

Syntax Description

no	(Optional) Negate a command or set its defaults
hostname	Set dynamic hostname for IS-IS
dynamic	Dynamic hostname

Command Mode

- /exec/configure/otv-isis/otv-isis-vrf-common

hostname dynamic

[no] hostname dynamic

Syntax Description

no	(Optional) Negate a command or set its defaults
hostname	Set dynamic hostname for IS-IS
dynamic	Dynamic hostname

Command Mode

- /exec/configure/router-isis/router-isis-vrf-common

hostname dynamic

[no] hostname dynamic

Syntax Description

no	(Optional) Negate a command or set its defaults
hostname	Set dynamic hostname for IS-IS
dynamic	Dynamic hostname

Command Mode

- /exec/configure/l2mp-isis/l2mp-isis-vrf-common

hsrp

[no] hsrp <group-id> [ipv4]

Syntax Description

no	(Optional) Negate a command or set its defaults
hsrp	HSRP interface configuration commands
<i>group-id</i>	Group number (0-255 for HSRPv1)
ipv4	(Optional) Configure IP Version 4 group

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan-common /exec/configure/if-port-channel /exec/configure/if-sub /exec/configure/if-ethernet-all

hsrp anycast

[no] hsrp anycast <id> { ipv4 | ipv6 | both }

Syntax Description

no	(Optional) Negate a command or set its defaults
hsrp	HSRP configuration commands
anycast	Anycast related commands
<i>id</i>	Bundle number
ipv4	Associate IP Version 4 for the bundle
ipv6	Associate IP Version 6 for the bundle
both	Associate IP Version 4 and 6 for the bundle

Command Mode

- /exec/configure

hsrp bfd

[no] hsrp bfd

Syntax Description

no	(Optional) Negate a command or set its defaults
hsrp	HSRP interface configuration commands
bfd	BFD protocol

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan-common /exec/configure/if-port-channel /exec/configure/if-sub /exec/configure/if-ethernet-all

hsrp bfd all-interfaces

[no] hsrp bfd all-interfaces

Syntax Description

no	(Optional) Negate a command or set its defaults
hsrp	HSRP interface configuration commands
bfd	BFD protocol
all-interfaces	On all interfaces

Command Mode

- /exec/configure

hsrp delay minimum

hsrp delay { minimum <min-delay> | reload <reload-delay> } + | no hsrp delay [minimum | reload]

Syntax Description

no	Negate a command or set its defaults
hsrp	HSRP interface configuration commands
delay	HSRP initialisation delay
minimum	Minimum delay
reload	Delay after reload
<i>min-delay</i>	<0-10000> Delay in seconds
<i>reload-delay</i>	<0-10000> Delay in seconds

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan-common /exec/configure/if-port-channel /exec/configure/if-sub /exec/configure/if-ethernet-all

hsrp force state vlan

```
hsrp force state vlan { <vlans> | all }
```

Syntax Description

hsrp	Hot Standby Router Protocol (HSRP) information
force	Move the HSRP state
state	HSRP state
vlan	HSRP state changes for these vlans
all	Include all HSRP configured VLANs
<i>vlans</i>	VLAN IDs of the VLAN for which state change will affect

Command Mode

- /exec

hsrp ipv6

[no] hsrp <group-id> ipv6

Syntax Description

no	(Optional) Negate a command or set its defaults
hsrp	HSRP interface configuration commands
<i>group-id</i>	Group number
ipv6	Configure IP Version 6 group

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan-common /exec/configure/if-port-channel /exec/configure/if-sub /exec/configure/if-ethernet-all

hsrp mac-refresh

hsrp mac-refresh [<time>] | no hsrp mac-refresh

Syntax Description

no	Negate a command or set its defaults
hsrp	HSRP interface configuration commands
mac-refresh	Interface mac-refresh time
<i>time</i>	(Optional) Timeout value (0-10000) in sec

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan-common /exec/configure/if-port-channel /exec/configure/if-sub /exec/configure/if-ethernet-all

hsrp timers extended-hold

[no] hsrp timers extended-hold [<extended-hold>]

Syntax Description

no	(Optional) Negate a command or set its defaults
hsrp	HSRP interface configuration commands
timers	Global Timers
extended-hold	Extended Hold
<i>extended-hold</i>	(Optional) Time in seconds

Command Mode

- /exec/configure

hsrp use-bia

[no] hsrp use-bia [scope interface]

Syntax Description

no	(Optional) Negate a command or set its defaults
hsrp	HSRP interface configuration commands
use-bia	HSRP uses interface's burned in address
scope	(Optional) Specify the scope of use-bia
interface	(Optional) Use-bia applies to all groups on this interface or sub-interface

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan-common /exec/configure/if-port-channel /exec/configure/if-sub /exec/configure/if-ethernet-all

hsrp version 1

hsrp version { 1 | 2 } | no hsrp version

Syntax Description

no	Negate a command or set its defaults
hsrp	HSRP interface configuration commands
version	HSRP version
1	Version 1
2	Version 2

Command Mode

- /exec/configure/if-eth-any /exec/configure/if-vlan-common /exec/configure/if-port-channel /exec/configure/if-sub /exec/configure/if-ethernet-all

http get

```
[no] http { get } <WORD> { [ cache { disable | enable } ] [ proxy <proxy-info> ] [ source-ip { <source-ip-hostname> | <source-ip-address> } ] [ source-port <src-port> ] [ version <http-version> ] } +
```

Syntax Description

no	(Optional)
<i>cache</i>	(Optional) enable
<i>proxy</i>	(Optional) <proxy-info>
<i>source-ip</i>	(Optional) <source-ip-hostname>
<i>source-port</i>	(Optional) <src-port>
<i>version</i>	(Optional) <http-version>
http	HTTP Operation
get	HTTP get operation
<i>WORD</i>	URL
enable	(Optional) enable download of cached entries (default)
disable	(Optional) disable download of cached entries (default)
<i>proxy-info</i>	(Optional) proxy information string
<i>source-ip-hostname</i>	(Optional) source IP hostname, broadcast disallowed
<i>source-ip-address</i>	(Optional) source IP address, broadcast disallowed
<i>src-port</i>	(Optional) Port Number (Recommended port range between 1025-65534)
<i>http-version</i>	(Optional) Supported HTTP versions are '1.0' and '1.1'.

Command Mode

- /exec/configure/ip-sla

http proxy server

[no] http proxy server <hostipname> [port <port-num>]

Syntax Description

no	(Optional) Negate a command or set its defaults
http	Configure http related parameters
proxy	Http Proxy related parameters
server	Server address
<i>hostipname</i>	IPV4/IPV6 address or DNS name of proxy server
port	(Optional) Http proxy server port
<i>port-num</i>	(Optional) port number

Command Mode

- /exec/configure/trustpool

human

| human

Syntax Description

	Pipe command output to filter
human	output in human format

Command Mode

- /output

human

| human

Syntax Description

	Pipe command output to filter
human	output in human format

Command Mode

- /output

hw-module logging onboard

```
[no] hw-module logging onboard [ { environmental-history | error-stats | interrupt-stats | module <module>
[ { environmental-history | error-stats | interrupt-stats | obfl-logs | cpuhog } ] | obfl-logs | cpuhog } ]
```

Syntax Description

no	(Optional) Negate a command or set its defaults
hw-module	Enable/Disable OBFL information
logging	Enable/Disable OBFL information
onboard	Enable/Disable OBFL information
environmental-history	(Optional) Enable/Disable OBFL environmental history
error-stats	(Optional) Enable/Disable OBFL error statistics
interrupt-stats	(Optional) Enable/Disable OBFL interrupt statistics
cpuhog	(Optional) Enable/Disable OBFL cpu hog events
module	(Optional) Enable/Disable OBFL information for Module
<i>module</i>	(Optional) Enter module number
obfl-logs	(Optional) Enable/Disable OBFL (boot-uptime/device-version/obfl-history)

Command Mode

- /exec/configure

hw-module logging onboard

[no] hw-module logging onboard [{ counter-stats | module <module> [{ counter-stats }] }]

Syntax Description

no	(Optional) Negate a command or set its defaults
hw-module	Enable/Disable OBFL information
logging	Enable/Disable OBFL information
onboard	Enable/Disable OBFL information
counter-stats	(Optional) Enable/Disable OBFL counter statistics
module	(Optional) Enable/Disable OBFL information for Module
<i>module</i>	(Optional) Enter module number

Command Mode

- /exec/configure