



Cisco Nexus 9000 Series FPGA/EPLD Upgrade Release Notes, Release 9.2(2)

This document lists the current and past versions of EPLD images and describes how to update them for use with the Cisco Nexus 9000 Series switches.

The following table lists the changes to this document.

Date	Description
November 8, 2018	Created the Cisco Nexus 9000 Series EPLD release notes for Release Release 9.2(2).

Table of Contents

INTRODUCTION	3
DECIDING WHEN TO UPGRADE EPLDS	3
SWITCH REQUIREMENTS	3
EPLD UPGRADES AVAILABLE FOR NX-OS MODE RELEASES 7.0(3)I4(6) TO 7.0(3)I6(1)	5
DETERMINING WHETHER TO UPGRADE EPLD IMAGES	9
DOWNLOADING THE EPLD IMAGES	11
INSTALLATION GUIDELINES	12
UPGRADING THE EPLD IMAGES	12
VERIFYING THE EPLD UPGRADES	13
DISPLAYING THE STATUS OF EPLD UPGRADES	13
LIMITATIONS	13
RELATED DOCUMENTATION	13
RELEASE NOTES	14
DOCUMENTATION FEEDBACK	14
OBTAINING DOCUMENTATION AND SUBMITTING A SERVICE REQUEST	14

Introduction

The Cisco Nexus 9000 Series NX-OS mode switches contain several programmable logical devices (PLDs) that provide hardware functionalities in all modules. Cisco provides electronic programmable logic device (EPLD) image upgrades to enhance hardware functionality or to resolve known issues. PLDs include electronic programmable logic devices (EPLDs), field programmable gate arrays (FPGAs), and complex programmable logic devices (CPLDs), but they do not include ASICs. In this document, the term EPLD is used for FPGA and CPLDs.

The advantage of having EPLDs for some module functions is that when you upgrade those functions, you upgrade their software images instead of replacing their hardware.

NOTE: EPLD image upgrades for a line card disrupt the traffic going through the module because the module must power down briefly during the upgrade. The system performs EPLD upgrades on one module at a time, so at any one time the upgrade disrupts only the traffic going through one module.

NOTE: For N9K-C9348GC-FXP, EPLD should be upgraded to minimum 9.2(2) version for 9.2(x) release. Please refer to [CSCvm94301](#) for further details.

Cisco provides the latest EPLD images with each release. Typically, these images are the same as provided in earlier releases but occasionally some of these images are updated. These EPLD image updates are not mandatory unless otherwise specified. The EPLD image upgrades are independent from the Cisco In Service Software Upgrade (ISSU) process, which upgrades the system image with no impact on the network environment.

When Cisco makes an EPLD image upgrade available, these release notes announce their availability, and you can download the EPLD images from <https://software.cisco.com/download/navigator.html>.

Deciding When to Upgrade EPLDs

When new EPLD images are available, the upgrade is recommended if your network environment allows for a maintenance period in which some level of traffic disruption is acceptable. If such a disruption is not acceptable, then consider postponing the upgrade until a better time.

NOTE: The EPLD upgrade operation is a disruptive operation. Execute this operation only at a programmed maintenance time. The system ISSU upgrade is a nondisruptive upgrade.

NOTE: EPLD version is backward compatible.

NOTE: Do not perform an EPLD upgrade during an ISSU system upgrade.

Switch Requirements

The Cisco Nexus 9000 Series switch must be running the Cisco NX-OS operating system and include the following hardware:

- Supervisor modules (2)—each with at least 800 MB of available boot flash memory (Cisco Nexus 9504, 9508, and 9516 switches)
- System controller modules (2) (Cisco Nexus 9504, 9508, and 9516 switches)
- Line cards (Cisco Nexus 9504, 9508, and 9516 switches)
 - Cisco Nexus 9504 switch (1 to 4 line cards)
 - Cisco Nexus 9508 switch (1 to 8 line cards)
 - Cisco Nexus 9516 switch (1 to 16 line cards)

Switch Requirements

- Fabric modules (Cisco Nexus 9504, 9508, and 9516 switches)
 - Fabric modules for 40-Gigabit line cards on a Cisco Nexus 9504, 9508, or 9516 switch (3-6 modules)
 - Fabric modules for 100-Gigabit -E line cards on a Cisco Nexus 9504, 9508, or 9516 switch (4 modules)
 - Fabric modules for 100-Gigabit -S line cards on a Cisco Nexus 9504 or 9508 switch (4 modules)
- Fan modules
 - Cisco Nexus 92304QC, 9272Q, and 93120TX switches (2 modules)
 - Cisco Nexus 9336C-FX2, 9364C, 9396PX, 9396TX, and 93128TX switches (3 modules)
 - Cisco Nexus 9236C, 92160YC-X, 92300YC, 9332PQ, 9372PX, 9372PX-E, 9372TX, 9372TX-E, 93108TC-EX, 93180LC-EX, and 92300YC switches (4 modules)
 - Cisco Nexus 93240YC-FX2 switch (5 modules)
 - Cisco Nexus 9504, 9508, and 9516 switches (3 fan trays)
- Power supplies
 - 500-W AC, 930-W DC, or 1200-W HVAC/HVDC power supplies (2 for the Cisco Nexus 93180LC-EX switches)
 - 650-W AC, 930-W DC, or 1200-W HVAC/HVDC power supplies (2 for the Cisco Nexus 92160YC-X, 92304QC, 9236C, 93108TC-EX, 93180YC-EX, 9332PQ, 9372PX, 9372PX-E, 9372TX, 9372TX-E, 9396PX, and 9396TX switches)
 - 650-W AC or 1200-W HVAC/HVDC power supplies (2 for Cisco Nexus 92300YC switches)
 - 930-W DC power supplies (2 for all Cisco Nexus 9200 and 9300 platform switches (except 92300YC and 9348GC-FXP switches))
 - 11000W AC power supplies (2) for the Cisco Nexus 9336C and 93240YC switches
 - 11000W DC power supplies (2) for the Cisco Nexus 9336C and 93240YC switches
 - 11000W HVAC/HVDC power supplies (2) for the Cisco Nexus 9336C and 93240YC switches
 - 1200-W AC power supplies (2) or 930-W DC power supplies (2) for the Cisco Nexus 9272Q, 93120TX, 93128TX, and 9364C switches
 - 1200-W HVAC/HVDC power supplies (2) for all Cisco Nexus 9200 and 9300 platform switches (except the 9348GC-FXP switch)
 - 3000-W AC power supplies or 3000-W Universal AC/DC or 3000-W DC power supplies for Cisco Nexus 9500 switches
 - 3.15-kW dual input universal AC/DC power for the Cisco Nexus 9500 switches
 - Cisco Nexus 9504 switch (up to 4)
 - Cisco Nexus 9508 switch (up to 8)
 - Cisco Nexus 9516 switch (up to 10)
- Uplink module (Cisco Nexus 93128TX, 9396PX, and 9396TX switches only)

- M4PC-CFP2
- M6PQ
- M6PQ-E
- M12PQ

You must be able to access the switch through a console, SSH, or Telnet (required for setting up a switch running in NX-OS mode).

You must have administrator privileges to work with the Cisco Nexus 9000 Series switch.

EPLD Upgrades Available for NX-OS Mode Releases 7.0(3)I6(1) through 9.2(2)

Each EPLD image that you can download from <https://software.cisco.com/download/navigator.html> is a bundle of EPLD upgrades. To see the recent updated EPLD versions for the Cisco Nexus 9200, 9300, 9300-EX, and 9300-FX platform switches, and the Cisco Nexus 9500 platform switches, see the following tables.

NOTE: All updates to an image are in boldface. If more than one release is shown for a column, the boldface applies to the first release listed for the column.

Available EPLD Images for the Cisco Nexus 9200, 9300, 9300-EX, and 9300-FX Platform Switches

Switch or Uplink Module	EPLD Device	Release 7.0(3)I7(2)	Release 7.0(3)I7(3)	Release 9.2(1)	Release 9.2(2)
Cisco Nexus 92160YC-X (N9K-C92160YC-X)	IOFPGA	0x17 (0.023)	0x17 (0.023)	0x17 (0.023)	0x17 (0.023)
	MIFPGA	0x5 (0.005)	0x5 (0.005)	0x5 (0.005)	0x5 (0.005)
Cisco Nexus 92300YC (N9K-C92300YC)	IOFPGA	0x17 (0.023)	0x17 (0.023)	0x19 (0.025)	0x19 (0.025)
	MIFPGA0	0x5 (0.005)	0x7 (0.007)	0x7 (0.007)	0x7 (0.007)
	MIFPGA1	0x2 (0.002)	0x2 (0.002)	0x2 (0.002)	0x2 (0.002)
Cisco Nexus 92304QC (N9K-C92304QC)	IOFPGA	0x10 (0.016)	0x10 (0.016)	0x10 (0.016)	0x10 (0.016)
	MIFPGA0	0x1 (0.001)	0x1 (0.001)	0x1 (0.001)	0x1 (0.001)
	MIFPGA1	0x1 (0.001)	0x1 (0.001)	0x1 (0.001)	0x1 (0.001)
Cisco Nexus 9236C (N9K-C9236C)	IOFPGA	0x15 (0.021)	0x15 (0.021)	0x15 (0.021)	0x15 (0.021)
	MIFPGA	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)
Cisco Nexus 9272Q (N9K-C9272Q)	IOFPGA	0x16 (0.022)	0x16 (0.022)	0x16 (0.022)	0x16 (0.022)
	MIFPGA0	0x4 (0.004)	0x4 (0.004)	0x4 (0.004)	0x4 (0.004)
	MIFPGA1	0x7 (0.007)	0x7 (0.007)	0x7 (0.007)	0x7 (0.007)
Cisco Nexus 93108TC-EX (N9K-C93108TC-EX)	IOFPGA	0x10 (0.016)	0x10 (0.016)	0x10 (0.016)	0x12 (0.018)
	MIFPGA	0x2 (0.002)	0x2 (0.002)	0x2 (0.002)	0x2 (0.002)
Cisco Nexus 93108TC-FX (N9K-C93108TC-FX)	IOFPGA	0x17 (0.023)	0x17 (0.023)	0x19 (0.025)	0x19 (0.025)
	MIFPGA	0x3 (0.003)	0x3 (0.003)	0x3 (0.003)	0x3 (0.003)
Cisco Nexus 93120TX (N9K-C93120TX)	IOFPGA	0x8 (0.008)	0x8 (0.008)	0x8 (0.008)	0x8 (0.008)
	MIFPGA1	0x10 (0.016)	0x10 (0.016)	0x10 (0.016)	0x10 (0.016)
	MIFPGA2	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)

Switch or Uplink Module	EPLD Device	Release 7.0(3)I7(2)	Release 7.0(3)I7(3)	Release 9.2(1)	Release 9.2(2)
Cisco Nexus 93128TX (N9K-C93128TX)	IOFPGA	0x11 (0.017)	0x11 (0.017)	0x11 (0.017)	0x11 (0.017)
	MIFPGA	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)
Cisco Nexus 93180LC-EX (N9K-C93180LC-EX)	IOFPGA	0x17 (0.023)	0x17 (0.023)	0x19 (0.025)	0x19 (0.025)
	MIFPGA	0x15 (0.021)	0x15 (0.021)	0x15 (0.021)	0x15 (0.021)
Cisco Nexus 93180YC-EX (N9K-C93180YC-EX)	IOFPGA	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)
	MIFPGA	0x4 (0.004)	0x4 (0.004)	0x4 (0.004)	0x4 (0.004)
Cisco Nexus 93180YC-FX (N9K-C93180YC-FX)	IOFPGA	0x17 (0.023)	0x17 (0.023)	0x19 (0.025)	0x19 (0.025)
	MIFPGA	0x10 (0.010)	0x10 (0.010)	0x10 (0.010)	0x10 (0.010)
Cisco Nexus 93240YC-FX2 (N9K-C93240YC-FX2)	IOFPGA	N.A. ¹	0x8 (0.008)	0x8 (0.008)	0x9 (0.009)
	MIFPGA1	N.A. ¹	0x12 (0.018)	0x12 (0.018)	0x12 (0.018)
	MIFPGA2	N.A. ¹	0x7 (0.007)	0x7 (0.007)	0x7 (0.007)
Cisco Nexus 9332PQ (N9K-C9332PQ)	IOFPGA	0x12 (0.018)	0x12 (0.018)	0x12 (0.018)	0x12 (0.018)
	MIFPGA	0x17 (0.023)	0x17 (0.023)	0x17 (0.023)	0x17 (0.023)
Cisco Nexus 9336C-FX2 (N9K-C9336C-FX2)	IOFPGA	N.A. ¹	0x8 (0.008)	0x8 (0.008)	0x9 (0.009)
	MIFPGA	N.A. ¹	0x4 (0.004)	0x4 (0.004)	0x4 (0.004)
Cisco Nexus 9348GC-FXP (N9K-C9348GC-FXP)	IOFPGA	0x6 (0.006)	0x6 (0.006)	0x7 (0.007)	0x8 (0.008)
	MIFPGA	0x8 (0.008)	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)
Cisco Nexus 9364C (N9K-C9364C)	IOFPGA	0x4 (0.004)	0x4 (0.004)	0x5 (0.005)	0x5 (0.005)
	MIFPGA	0x7 (0.007)	0x8 (0.008)	0x8 (0.008)	0x8 (0.008)
	MIFPGA1	0x3 (0.003)	0x3 (0.003)	0x3 (0.003)	0x3 (0.003)
Cisco Nexus 9372PX (N9K-C9372PX)	IOFPGA	0x8 (0.008)	0x8 (0.008)	0x8 (0.008)	0x8 (0.008)
	MIFPGA	0x15 (0.021)	0x15 (0.021)	0x15 (0.021)	0x15 (0.021)
Cisco Nexus 9372PX-E (N9K-C9372PX-E)	IOFPGA	0x8 (0.008)	0x8 (0.008)	0x8 (0.008)	0x8 (0.008)
	MIFPGA	0x15 (0.021)	0x15 (0.021)	0x15 (0.021)	0x15 (0.021)
Cisco Nexus 9372TX (N9K-C9372TX)	IOFPGA	0x6 (0.006)	0x6 (0.006)	0x6 (0.006)	0x6 (0.006)
	MIFPGA	0x15 (0.021)	0x15 (0.021)	0x15 (0.021)	0x15 (0.021)
Cisco Nexus 9372TX-E (N9K-C9372TX-E)	IOFPGA	0x6 (0.006)	0x6 (0.006)	0x6 (0.006)	0x6 (0.006)
	MIFPGA	0x3 (0.003)	0x3 (0.003)	0x3 (0.003)	0x3 (0.003)
Cisco Nexus 9396PX (N9K-C9396PX)	IOFPGA	0x16 (0.022)	0x16 (0.022)	0x16 (0.022)	0x16 (0.022)
	MIFPGA	0x15 (0.021)	0x15 (0.021)	0x15 (0.021)	0x15 (0.021)
Cisco Nexus 9396TX (N9K-C9396TX)	IOFPGA	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)
4-port 100-Gigabit optical uplink module (N9K-M4PC-CFP2)	MIFPGA	0x11 (0.017)	0x11 (0.017)	0x11 (0.017)	0x11 (0.017)
6-port 40-Gigabit optical uplink module (N9K-M6PQ or N9K-M6PQ-E)	MIFPGA	0x10 (0.016)	0x10 (0.016)	0x10 (0.016)	0x10 (0.016)
12-port optical uplink module (N9K-M12PQ)	MIFPGA	0x20 (0.032)	0x20 (0.032)	0x20 (0.032)	0x20 (0.032)

¹ Not available in this release.

Available EPLD Images for the Cisco Nexus 9500 Platform Switches

Component	EPLD Device	Release 7.0(3)I7(2)	Release 7.0(3)I7(3)	Release 9.2(1)	Release 9.2(2)
Supervisor A (N9K-SUP-A)	IOFPGA	0x27 (0.039)	0x27 (0.039)	0x27 (0.039)	0x27 (0.039)
Supervisor A+ (N9K-SUP-A+)	IOFPGA	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)
Supervisor B (N9K-SUP-B)	IOFPGA	0x27 (0.039)	0x27 (0.039)	0x27 (0.039)	0x27 (0.039)
Supervisor B+ (N9K-SUP-B+)	IOFPGA	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)
System Controller (N9K-SC-A)	IOFPGA	0x20 (0.032)	0x20 (0.032)	0x20 (0.032)	0x20 (0.032)
8-port 100-Gigabit CFP2 line card (N9K-X9408)	IOFPGA	0x5 (0.005)	0x5 (0.005)	0x5 (0.005)	0x5 (0.005)
	MIFPGA	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)
32-port 100-Gigabit QSFP28 line card (N9K-X9432C-S)	IOFPGA	0x14 (0.020)	0x14 (0.020)	0x14 (0.020)	0x14 (0.020)
	MIFPGA	0x4 (0.004)	0x4 (0.004)	0x4 (0.004)	0x4 (0.004)
32-port 40-Gigabit QSFP+ line card (N9K-X9432PQ)	IOFPGA	0x16 (0.022)	0x16 (0.022)	0x16 (0.022)	0x16 (0.022)
	MIFPGA	0x13 (0.019)	0x13 (0.019)	0x13 (0.019)	0x13 (0.019)
32-port 100-Gigabit QSFP28 line card (N9K-X9732C-EX) (for -E fabric modules)	IOFPGA	0x11 (0.017)	0x11 (0.017)	0x12 (0.018)	0x12 (0.018)
	MIFPGA	0x7 (0.007)	0x7 (0.007)	0x8 (0.008)	0x8 (0.008)
36-port 100-Gigabit QSFP28 line card (N9K-X9732C-FX)	IOFPGA	N.A. ²	0x3 (0.003)	0x5 (0.005)	0x5 (0.005)
	MIFPGA	N.A. ²	0x1 (0.001)	0x1 (0.001)	0x1 (0.001)
36-port 40-Gigabit QSFP+ line card (N9K-X9636PQ)	IOFPGA	0x16 (0.022)	0x16 (0.022)	0x16 (0.022)	0x17 (0.023)
	MIFPGA	0x13 (0.019)	0x13 (0.019)	0x13 (0.019)	0x13 (0.019)
36-port 40-Gigabit QSFP+ line card (N9K-X9536PQ)	IOFPGA	0x10 (0.016)	0x10 (0.016)	0x10 (0.016)	0x11 (0.017)
	MIFPGA	0x7 (0.007)	0x7 (0.007)	0x7 (0.007)	0x7 (0.007)
36-port 100-Gigabit QSFP28 line card (N9K-X9736C-EX)	IOFPGA	0x11 (0.017)	0x11 (0.017)	0x11 (0.017)	0x12 (0.018)
	MIFPGA	0x7 (0.007)	0x7 (0.007)	0x7 (0.007)	0x8 (0.008)
36-port 100-Gigabit QSFP28 line card (N9K-X9736C-FX)	IOFPGA	0x5 (0.005)	0x5 (0.005)	0x5 (0.005)	0x6 (0.006)
	MIFPGA	0x6 (0.006)	0x6 (0.006)	0x6 (0.006)	0x6 (0.006)
48-port 1-/10-Gigabit SFP+ and 4-port 40-Gigabit QSFP+ line card (N9K-X9464PX)	IOFPGA	0x11 (0.017)	0x11 (0.017)	0x11 (0.017)	0x11 (0.017)
	MIFPGA	0x10 (0.016)	0x10 (0.016)	0x10 (0.016)	0x10 (0.016)
48-port 1/10GBASE-T and 4-port 40-Gigabit QSFP+ line card (N9K-X9464TX)	IOFPGA	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)
	MIFPGA	0x8 (0.008)	0x8 (0.008)	0x8 (0.008)	0x8 (0.008)
48-port 1/10GBASE-T and 4-port 40-Gigabit QSFP+ line card (N9K-X9464TX2)	IOFPGA	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)
	MIFPGA	0x3 (0.003)	0x3 (0.003)	0x3 (0.003)	0x3 (0.003)
48-port 1/10GBASE-T and 4-port 40-Gigabit QSFP+ line card (N9K-X9564TX)	IOFPGA	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)	0x10 (0.010)
	MIFPGA	0x8 (0.008)	0x8 (0.008)	0x8 (0.008)	0x8 (0.008)
48-port 1-/10-Gigabit SFP+ and 4-port 40-Gigabit QSFP+ line card (N9K-X9564PX)	IOFPGA	0x10 (0.016)	0x10 (0.016)	0x10 (0.016)	0x11 (0.017)
	MIFPGA	0x10 (0.016)	0x10 (0.016)	0x10 (0.016)	0x10 (0.016)

Component	EPLD Device	Release 7.0(3)I7(2)	Release 7.0(3)I7(3)	Release 9.2(1)	Release 9.2(2)
48-port 1-/10-/25-Gigabit SFP28 and 4-port 40-/100-Gigabit QSFP28 line card (N9K-X97160YC-EX)	IOFPGA	0x8 (0.008)	0x8 (0.008)	0x8 (0.008)	0x11 (0.017)
	MIFPGA	0x4 (0.004)	0x4 (0.004)	0x4 (0.004)	0x4 (0.004)
48-port 10-Gigabit SFP+ and 4-port 100-Gigabit QSFP28 line card (N9K-X9788TC-FX)	IOFPGA	N.A. ²	0x2 (0.002)	0x2 (0.002)	0x3 (0.003)
	MIFPGA	N.A. ²	0x5 (0.005)	0x5 (0.005)	0x5 (0.005)
Fabric module for Cisco Nexus 9504 40-Gigabit line cards (N9K-C9504-FM)	IOFPGA	0x19 (0.025)	0x19 (0.025)	0x19 (0.025)	0x19 (0.025)
Fabric module for Cisco Nexus 9504 100-Gigabit –EX line (N9K-C9504-FM-E)	IOFPGA	0x13 (0.019)	0x13 (0.019)	0x13 (0.019)	0x14 (0.020)
Fabric module for Cisco Nexus 9504 100-Gigabit –EX line (N9K-C9504-FM-E2)	IOFPGA	N.A. ²	N.A. ²	0x8 (0.008)	0x8 (0.008)
Fabric module for Cisco Nexus 9504 100-Gigabit –S line cards (N9K-C9504-FM-S)	IOFPGA	0x11 (0.017)	0x11 (0.017)	0x11 (0.017)	0x11 (0.017)
Fabric module for Cisco Nexus 9508 40-Gigabit line cards (N9K-C9508-FM)	IOFPGA	0x19 (0.025)	0x19 (0.025)	0x19 (0.025)	0x19 (0.025)
Fabric module for Cisco Nexus 9508 100-Gigabit –EX line cards (N9K-C9508-FM-E)	IOFPGA	0x13 (0.019)	0x13 (0.019)	0x13 (0.019)	0x13 (0.019)
Fabric module for Cisco Nexus 9508 100-Gigabit –S line (N9K-C9508-FM-S)	IOFPGA	0x11 (0.017)	0x11 (0.017)	0x11 (0.017)	0x11 (0.017)
Fabric module for Cisco Nexus 9516 40-Gigabit line cards (N9K-C9516-FM)	IOFPGA	0x13 (0.019)	0x13 (0.019)	0x13 (0.019)	0x13 (0.019)
Fabric module for Cisco Nexus 9516 100-Gigabit –EX line cards (N9K-C9516-FM-E)	IOFPGA	0x7 (0.007)	0x7 (0.007)	0x7 (0.007)	0x7 (0.007)
	MIFPGA	0x4 (0.004)	0x5 (0.005)	0x5 (0.005)	0x7 (0.007)
Fabric module for Cisco Nexus 9516 100-Gigabit -EX and -FX line cards (N9K-C9516-FM-E2)	IOFPGA	N.A. ²	0x9 (0.009)	0x9 (0.009)	0x11 (0.011)
	MIFPGA	N.A. ²	0x7 (0.007)	0x7 (0.007)	0x7 (0.007)

² Not available in this release.

Available EPLD Images for the Cisco Nexus 9500 Platform Switches with R Line Cards

Component	EPLD Device	Release 7.0(3)F3(3a)	Release 7.0(3)F3(4)	Release 9.2(1)	Release 9.2(2)
36-port 100-Gigabit QSFP28 iine card (N9K-X9636C-RX)	IOFPGA	0x15 (0.021)	0x15 (0.021)	0x15 (0.021)	0x15 (0.021)
	MIFPGA	0x3 (0.003)	0x3 (0.003)	0x3 (0.003)	0x3 (0.003)
36-port 100-Gigabit QSFP28 line card (N9K-X9636C-R)	IOFPGA	0xF	0xF	0xF	0xF
	MIFPGA	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)	0x9 (0.009)
36-port 100-Gigabit QSF+ line card (N9K-X9636Q-R)	IOFPGA	0x16 (0.022)	0x16 (0.022)	0x16 (0.022)	0x16 (0.022)
	MIFPGA	0x3 (0.003)	0x3 (0.003)	0x3 (0.003)	0x3 (0.003)
Fabric module for Cisco Nexus 9508 100-Gigabit –R line card (N9K-C9508-	IOFPGA	N.A. ²	N.A. ²	0x10 (0.016)	0x10 (0.016)

Determining Whether to Upgrade EPLD Images

Component	EPLD Device	Release 7.0(3)F3(3a)	Release 7.0(3)F3(4)	Release 9.2(1)	Release 9.2(2)
FM-R)					

² Not available in this release.

Determining Whether to Upgrade EPLD Images

EPLD image number, you can skip the upgrade.

- To determine the EPLD upgrades needed for a Cisco Nexus 3000 Series switch, use the `show install impact epld bootflash:` command on that switch and indicate the `n9000-epld.9.2.2` image. In the following example, the MIFPGA and IOFPGA EPLD images do not need to be upgraded.

```
switch# show install all impact epld n9000-epld.9.2.2.img
Compatibility check:
Module      Type      Upgradable      Impact      Reason
-----
1           SUP      Yes             disruptive  Module Upgradable
```

Retrieving EPLD versions... Please wait.

```
Images will be upgraded according to following table:
Module  Type  EPLD              Running-Version  New-Version  Upg-Required
-----
1      SUP  MI FPGA           0x23            0x23        No
1      SUP  IO FPGA           0x06            0x06        No
1      SUP  MI FPGA2          0x23            0x23        No
```

Downloading the EPLD Images

Before you can prepare the EPLD images for installation, you must download them to the FTP or management server.

- 1 From a browser, go to <https://software.cisco.com/download/navigator.html>.
The browser displays the Cisco website.
- 2 Choose Switches.
A list of switch types displays on the right.
- 3 Select Data Center Switches.
The right side lists the Data Center Switch product series.
- 4 Select Cisco Nexus 9000.
The right side lists the switches in the series that you selected.
- 5 Select the switch that you are updating EPLD images for.
The Downloads page opens and lists what you can download for the switch that you selected.
- 6 Select NX-OS EPLD Updates.
The Download Software page lists the available EPLD images for the switch.
- 7 If you see a new EPLD image for the NX-OS software installed on the switch, click the Download button.
CAUTION: When you are trying to upgrade EPLD, it is recommended to use the same version of EPLD as that of installed software. However, if the installed version of EPLD is already later than the software you are installing, it is not required to downgrade the EPLD.
- 8 Click the link for the file.
The Downloads page displays a Download button and lists information for the file.
- 9 Click Download.
The Supporting Documents page opens to display the rules for downloading the software.
- 10 Read the rules and click Agree.
A File Download dialog box opens to ask if you want to open or save the images file.
- 11 Click Save.
The Save As dialog box appears.
- 12 Indicate where to save the file and click Save.
The file saves to the location that you specified.

Installation Guidelines

To upgrade the EPLD images using CLI commands, follow these guidelines:

- Before you upgrade any EPLD images, be sure that you have updated the Cisco NX-OS operating system to the level required for the images and be sure that you have an EPLD image file.

CAUTION: When you are trying to upgrade EPLD, it is recommended to use the same version of EPLD as that of installed software. However, if the installed version of EPLD is already later than the software you are installing, it is not required to downgrade the EPLD.

- You can execute an upgrade from the active supervisor module only. This upgrade is for one or all of the modules as follows:
 - You can upgrade a module individually.
 - You can upgrade all modules sequentially.
 - You can update the images for online modules only.
- On a Cisco Nexus 9500 platform switch that has two supervisor modules, upgrade the EPLDs for the standby supervisor and then switch the active supervisor to the standby mode to upgrade its EPLDs (the supervisor switchover is not disruptive to traffic on Cisco Nexus 9500 platform switches). On a switch that has only one supervisor module, you can upgrade the active supervisor, but this will disrupt its operations during the upgrade.
- If you interrupt an upgrade, you must reapply the upgrade to the module that was being upgraded during the interruption.
- The upgrade process disrupts traffic on the targeted module.
- Do not insert or remove any modules while an EPLD upgrade is in progress.

- 1 Copy the EPLD image file to bootflash.
- 2 To determine if you need to upgrade the BIOS for the image, use the `show install all impact` command and see the Upgrade Required (Upg-Required) field for the BIOS row in the command output.
- 3 If you do not need to upgrade the BIOS, set the boot variable using the `boot nxos bootflash:n9000-dk9.9.2.2.bin` command.
- 4 Enter the `copy running-config startup-config` command to set the startup boot variables to the NX-OS image.
- 5 If you need to upgrade the BIOS, enter the `install all nxos bootflash:n9000-dk9.9.2.2.bin` command.
- 6 Enter the `install epld bootflash:n9000-epld.9.2.2.img module all` command.

The switch automatically reboots.

Upgrading the EPLD Images

CAUTION: When you are trying to upgrade EPLD, it is recommended to use the same version of EPLD as that of installed software. However, if the installed version of EPLD is already later than the software you are installing, it is not required to downgrade the EPLD.

Verifying the EPLD Upgrades

To verify the EPLD upgrades for a switch or its modules, use the `show version module slot-number epld` command as follows:

- To verify updates for a module on a modular switch (Cisco Nexus 9500 platform switches), indicate the chassis slot number for *slot-number*.
`switch# show version module 22 epld`
- To verify updates for a top-of-rack switch (Cisco Nexus 9200, 9300, and 9300-EX platforms), use 1 for *slot-number*.
`switch# show version module 1 epld`

Displaying the Status of EPLD Upgrades

To display the status of EPLD upgrades on the switch, use the `show install epld status` command.

Limitations

When EPLDs are upgraded, the following guidelines and observations apply:

- If a module is not online, you cannot upgrade its EPLD images.
- If there are two supervisors installed in the switch (Cisco Nexus 9504, 9508, and 9516 switches only), you can either upgrade only the standby supervisor from the active supervisor or upgrade all modules (including both supervisor modules) by using the following commands:
 - `install epld bootflash: image module standby-supervisor-slot-number` (upgrades only the standby supervisor module)

NOTE: After you use this command, you can switchover the active and standby supervisor modules and then upgrade the other supervisor.

 - `install epld bootflash: image module all` (upgrades all of the modules)
- If there is only one supervisor installed in the switch, your upgrading or downgrading of EPLD images is disruptive.

Related Documentation

The entire Cisco NX-OS 9000 Series documentation set is available at the following URL:

<https://www.cisco.com/c/en/us/support/switches/nexus-9000-series-switches/tsd-products-support-series-home.html>

Release Notes

The release notes are available at the following URL:

https://www.cisco.com/en/US/products/ps13386/prod_release_notes_list.html

Documentation Feedback

To provide technical feedback on this document, or to report an error or omission, please send your comments to nexus9k-docfeedback@cisco.com. We appreciate your feedback.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation*, at:

<https://www.cisco.com/c/en/us/td/docs/general/whatsnew/whatsnew.html>.

Subscribe to *What's New in Cisco Product Documentation*, which lists all new and revised Cisco technical documentation as an RSS feed and delivers content directly to your desktop using a reader application. The RSS feeds are a free service.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2018 Cisco Systems, Inc. All rights reserved.