



REVIEW DRAFT - CISCO CONFIDENTIAL

## INDEX

---

### Numerics

- 10/100/1000 ports
  - cable lengths [1-4, 2-26](#)
  - connecting to [2-26](#)
  - described [1-4](#)
  - numbering [1-3](#)
  - pinouts [B-2](#)
  - recommended cables [2-26](#)
- 10/100 Ethernet management port [1-20](#)
- 10-Gigabit Ethernet module slots
  - cable lengths [B-5](#)
  - connecting devices [2-19](#)
  - described [1-5](#)
  - numbering [1-3](#)
  - recommended cables [B-5](#)
- 19- and 24-inch racks [2-14](#)

---

### A

- AC power
  - connecting to [3-3](#)
  - power-supply module described [1-15](#)
  - power supply module installation [3-3](#)
  - specifications [A-2](#)
- adapter pinouts, terminal
  - RJ-45-to-DB-25 [B-10](#)
  - RJ-45-to-DB-9 [B-9](#)
- airflow patterns [1-18, 1-19](#)
- altitude, operating and storage [A-1](#)
- autonegotiation
  - default setting [2-26](#)
  - troubleshooting [4-4](#)

---

### B

- bodily injury protection warning [2-3, 2-10](#)
- brackets
  - See mounting brackets

---

### C

- cable guide, attaching [2-14](#)
- cable lengths [B-5](#)
- cables
  - crossover
    - four twisted-pair pinout [B-8](#)
    - identifying [B-9](#)
    - two twisted-pair pinout [B-8](#)
  - patch cable [B-3](#)
  - recommended [2-26](#)
  - SFP module [B-6](#)
  - StackWise
    - cable numbers [1-14](#)
    - connecting to [2-18](#)
  - straight-through
    - four twisted-pair pinout [B-7](#)
    - two twisted-pair pinout [B-8](#)
  - X2 transceiver module [B-5](#)
- Cisco IOS command-line interface [1-21](#)
- Cisco IP Phones, connecting to [2-26 to 2-27](#)
- Cisco Network Assistant [1-20](#)
- Cisco Power Calculator [2-27](#)
- Cisco TwinGig Converter Module
  - described [1-5](#)
  - installation [2-19](#)
- CiscoView [1-21](#)

**REVIEW DRAFT – CISCO CONFIDENTIAL**

Class 1 laser warning [2-3](#)

CLI [1-21](#)

    accessing by using Express Setup [C-1](#)

    accessing through console port [C-1](#)

code compliance warning [2-4](#)

command-line interface

    See CLI

connection procedures [2-19 to 2-27, 3-3 to 3-10](#)

connectors and cables [B-1 to B-10](#)

console port

    connecting to [C-2](#)

    connectors and cables [B-4](#)

    described [1-20](#)

crossover cable

    See cables

---

**D**

DC circuit warning [2-3](#)

DC power

    power-supply module described [1-15](#)

    specifications [A-3](#)

DC power warning [3-4](#)

device manager

    described [1-21](#)

    to configure switch [2-28](#)

diagnosing problems [4-1](#)

dimensions [A-1](#)

duplex

    default setting [2-26](#)

    LED [1-9](#)

    troubleshooting [4-4](#)

---

**E**

electrical noise, avoiding [2-5](#)

electromagnetic safety [2-4](#)

Ethernet and fiber cable troubleshooting [4-2](#)

Ethernet management port

    described [1-20](#)

    LED POST results [4-1](#)

    LEDs [1-20](#)

Express Setup

    accessing CLI by using [C-1](#)

    for initial switch configuration [2-17](#)

    using to clear switch IP address [4-5](#)

---

**F**

fan module

    airflow patterns [1-18, 1-19](#)

    described [1-17](#)

    installing [3-10](#)

front panel

    10/100/1000 Ethernet ports [1-4](#)

    10-Gigabit Ethernet module slots [1-5](#)

    clearance [2-5](#)

    described [1-2 to 1-12](#)

    LEDs [1-6 to 1-12](#)

    PoE ports [1-4](#)

---

**G**

ground connection [3-5](#)

ground connection warning [2-3, 3-5](#)

---

**H**

HP OpenView [1-21](#)

humidity, relative [A-1](#)

**REVIEW DRAFT – CISCO CONFIDENTIAL****I**

## installation

- assigning the IP address [2-1, C-2](#)
- Cisco TwinGig Converter Modules [2-19](#)
- rack-mounting [2-10 to 2-14](#)
- SFP modules [2-22 to 2-25](#)
- site requirements [2-5](#)
- starting the terminal emulation software [C-2](#)
- table or shelf-mounting [2-17](#)
- X2 transceiver modules [2-19](#)
- See also procedures

**J**

- jewelry removal warning [2-2](#)

**L**

## LEDs

- color meanings [1-9](#)
- duplex [1-9](#)
- fan [1-9](#)
- front panel [1-6 to 1-12](#)
- interpreting [1-9](#)
- master [1-8](#)
- PoE [1-9](#)
- port [1-9 to 1-12](#)
- port mode [1-9 to 1-10](#)
- POST results [4-1](#)
- power supply [1-8](#)
- RPS [1-8](#)
- speed [1-9](#)
- stack [1-12](#)
- STATUS [1-9](#)
- system [1-7](#)
- troubleshooting with [4-1 to 4-2](#)

- lightning activity warning [2-2, 3-2](#)
- link status troubleshooting [4-2](#)
- local and national electrical codes compliance [2-4](#)

**M**

- mode button [1-6](#)
- mounting, table or shelf [2-17](#)
- mounting brackets
  - rack-mount [2-14](#)
  - table- or shelf-mounting [2-17](#)
  - wall-mount [2-15](#)

**N**

- NEBS standard for electromagnetic safety [2-4](#)
- Network Assistant [2-28](#)
- Network Equipment Building Systems
  - See NEBS
- noise, electrical [2-5](#)

**O**

- outside connections warning [2-4](#)
- overheating warning [2-2](#)

**P**

## pinouts

- 10/100/1000 ports [B-2](#)
- adapters [B-9 to B-10](#)
- console port [B-10](#)
- crossover cable [B-9](#)
- crossover cables
  - four twisted-pair [B-8](#)
  - two twisted-pair [B-8](#)
- RJ-45-to-DB-25 terminal adapter [B-10](#)
- RJ-45-to-DB-9 terminal adapter [B-9](#)

**REVIEW DRAFT – CISCO CONFIDENTIAL**

SFP module ports [B-3](#)

straight-through cables

four twisted-pair [B-7](#)

two twisted-pair [B-8](#)

PoE

faults caution [1-11](#)

LED [1-9, 1-11](#)

port connections [2-26](#)

ports described [1-4](#)

power planning tool [2-27](#)

shock hazard warning [2-4, 2-27](#)

troubleshooting [4-3](#)

port and interface troubleshooting [4-3](#)

port LEDs [1-9 to 1-12](#)

port modes

changing [1-6](#)

LEDs [1-9](#)

See also mode button

ports

10/100/1000

connecting to [2-26](#)

described [1-4](#)

pinouts [B-2](#)

recommended cables [2-26](#)

POST

LEDs [4-1](#)

running at power on [4-1](#)

power connection warning [2-3](#)

Power over Ethernet

See PoE

power specifications [A-2](#)

power-supply modules

described [1-15](#)

installation [3-1](#)

procedures

connection [2-19 to 2-27, 3-3 to 3-10](#)

installation [2-10 to 2-17](#)

product disposal warning [2-4](#)

**R**

rack-mounting [2-10 to 2-14](#)

rear panel

clearance [2-5](#)

console port [1-20](#)

described [1-13 to 1-20](#)

Ethernet management port [1-20](#)

fan module [1-17](#)

power-supply module [1-15](#)

RPS connector [1-19](#)

StackWise ports [1-14](#)

redundant power supply

See RPS

restricted access area warning [2-3](#)

RJ-45 connector, console port [B-4](#)

RJ-45 console port [1-13](#)

RPS

connector [1-19](#)

connector cover warning [2-2](#)

described [1-19](#)

LED [1-8](#)

**S**

safety [2-1](#)

serial number location [4-6](#)

servicing equipment warning [2-3](#)

SFP modules

bale-clasp latch removal [2-25](#)

cables [B-6](#)

connectors [B-3](#)

described [1-5](#)

installation [2-22 to 2-25](#)

patch cable [B-3](#)

supported [1-5](#)

SFP module slot numbering [1-4](#)

shelf-mounting [2-17](#)

shielding Ethernet cables warning [2-2](#)

**REVIEW DRAFT – CISCO CONFIDENTIAL**

Simple Network Management Protocol

See SNMP

SNMP network management platforms [1-21](#)

software switch management [1-20](#)

specifications [A-1](#)

speed

default setting [2-26](#)

troubleshooting [4-4](#)

stacking equipment warning [2-2](#)

stacking powering considerations [2-9](#)

StackWise ports [1-14](#)

straight-through cable pinout

four twisted-pair [B-7](#)

two twisted-pair [B-8](#)

SunNet Manager [1-21](#)

switch models [1-1](#)

system LED [1-7](#)

**T**

table-mounting [2-17](#)

technical specifications [A-1](#)

telco racks [2-14](#)

Telnet, and accessing the CLI [1-21](#)

temperature, operating [A-1](#)

transceiver troubleshooting [4-3](#)

troubleshooting

bad or damaged cable [4-2](#)

connection problems [4-2](#)

diagnosing problems [4-1](#)

Ethernet and fiber cables [4-2](#)

link status [4-2](#)

ping end device [4-4](#)

PoE connections [4-3](#)

port and interface settings [4-3](#)

POST [4-1](#)

serial number location [4-6](#)

spanning tree loops [4-4](#)

speed, duplex, and autonegotiation [4-4](#)

switch performance [4-4](#)

transceivers [4-3](#)

with LEDs [4-1 to 4-2](#)

troubleshooting spanning tree loops [4-4](#)

TwinGig Converter Module

See Cisco TwinGig Converter Module

**W**

wall-mounting

attaching brackets [2-15](#)

Catalyst 3560E-12D switches [2-16](#)

warnings

Class 1 laser [2-3](#)

code compliance [2-4](#)

connecting outside of building [2-4](#)

connecting the power [2-3](#)

DC power [3-4](#)

disposal of product [2-4](#)

ground connection [2-3, 3-5](#)

installation [2-1](#)

lightning activity [2-2, 3-2](#)

overheating [2-2](#)

PoE shock hazard [2-4, 2-27](#)

preventing bodily injury [2-3, 2-10](#)

removing jewelry [2-2](#)

removing power from DC circuit [2-3](#)

restricted access area [2-3](#)

RPS connector cover [2-2](#)

servicing equipment [2-3](#)

shielding Ethernet cables [2-2](#)

stacking equipment [2-2](#)

wall-mounting [2-2, 2-15](#)

weight [A-1](#)

---

**X**

X2 transceiver modules

described [1-5](#)

installation [2-19](#)

removing [2-22](#)

See also 10-Gigabit Ethernet module slot