



Command Reference, Cisco IOS XE Denali 16.2.x (Catalyst 3650 Switches)

First Published: 2016-03-31

Last Modified: 2016-07-06

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883



CONTENTS

PREFACE

Preface	xxxiii
Document Conventions	xxxiii
Related Documentation	xxxv
Obtaining Documentation and Submitting a Service Request	xxxv

CHAPTER 1

Using the Command-Line Interface	1
Using the Command-Line Interface	2
Understanding Command Modes	2
Understanding the Help System	3
Understanding Abbreviated Commands	4
Understanding no and default Forms of Commands	4
Understanding CLI Error Messages	4
Using Configuration Logging	5
Using Command History	5
Changing the Command History Buffer Size	5
Recalling Commands	6
Disabling the Command History Feature	6
Using Editing Features	6
Enabling and Disabling Editing Features	7
Editing Commands through Keystrokes	7
Editing Command Lines that Wrap	9
Searching and Filtering Output of show and more Commands	10
Accessing the CLI	10
Accessing the CLI through a Console Connection or through Telnet	11

PART I

CleanAir	13
-----------------	-----------

CHAPTER 2**CleanAir Commands 15**

- ap dot11 5ghz cleanair 16
- ap dot11 5ghz cleanair alarm air-quality 17
- ap dot11 5ghz cleanair alarm device 18
- default ap dot11 5ghz cleanair device 19
- ap dot11 5ghz rrm channel cleanair-event 20
- ap dot11 5ghz rrm channel device 21
- ap dot11 24ghz cleanair 22
- ap dot11 24ghz cleanair alarm air-quality 23
- ap dot11 24ghz cleanair alarm device 24
- default ap dot11 24ghz cleanair device 26
- ap dot11 24ghz rrm channel cleanair-event 28
- ap dot11 24ghz rrm channel device 29
- ap name mode se-connect 30
- default ap dot11 5ghz cleanair device 31
- default ap dot11 5ghz rrm channel cleanair-event 32
- default ap dot11 5ghz rrm channel device 33
- default ap dot11 24ghz cleanair alarm device 34
- default ap dot11 24ghz cleanair device 36
- default ap dot11 24ghz rrm channel cleanair-event 38
- show ap dot11 5ghz cleanair air-quality summary 39
- show ap dot11 5ghz cleanair air-quality worst 40
- show ap dot11 5ghz cleanair config 41
- show ap dot11 5ghz cleanair device type 43
- show ap dot11 24ghz cleanair air-quality summary 45
- show ap dot11 24ghz cleanair air-quality worst 46
- show ap dot11 24ghz cleanair config 47
- show ap dot11 24ghz cleanair summary 49

PART II**Flexible NetFlow Commands 51**

CHAPTER 3**Flexible NetFlow Commands 53**

- cache 55

clear flow exporter	57
clear flow monitor	58
collect	60
collect counter	61
collect interface	62
collect timestamp absolute	63
collect transport tcp flags	64
datalink flow monitor	65
debug flow exporter	66
debug flow monitor	67
debug flow record	68
debug sampler	69
description	70
destination	71
dscp	72
export-protocol netflow-v9	73
exporter	74
flow exporter	75
flow monitor	76
flow record	77
ip flow monitor	78
ipv6 flow monitor	80
match datalink ethertype	82
match datalink mac	83
match datalink vlan	84
match flow cts	85
match flow direction	86
match interface	87
match ipv4	88
match ipv4 destination address	89
match ipv4 source address	90
match ipv4 ttl	91
match ipv6	92
match ipv6 destination address	93

- match ipv6 hop-limit 94
- match ipv6 source address 95
- match transport 96
- match transport icmp ipv4 97
- match transport icmp ipv6 98
- mode random 1 out-of 99
- option 100
- record 102
- sampler 103
- show flow exporter 104
- show flow interface 106
- show flow monitor 108
- show flow record 110
- show sampler 111
- source 113
- template data timeout 115
- transport 116
- ttl 117

PART III

Interface and Hardware Components 119

CHAPTER 4

Interface and Hardware Commands 121

- client vlan 123
- debug ilpower 124
- debug interface 125
- debug lldp packets 126
- debug nmsp 127
- debug platform poe 128
- duplex 129
- errdisable detect cause 131
- errdisable recovery cause 133
- errdisable recovery interval 135
- interface 136
- interface range 138

ip mtu	139
ipv6 mtu	140
lldp (interface configuration)	141
logging event power-inline-status	142
mdix auto	143
mode (power-stack configuration)	144
monitoring	146
network-policy	148
network-policy profile (global configuration)	149
nmsp attachment suppress	150
power efficient-ethernet auto	151
power-priority	152
power inline	154
power inline police	157
power supply	159
show CAPWAP summary	161
show controllers cpu-interface	162
show controllers ethernet-controller	164
show controllers utilization	173
show eee	175
show env	178
show errdisable detect	181
show errdisable recovery	182
show interfaces	183
show interfaces counters	187
show interfaces switchport	189
show interfaces transceiver	191
show memory platform	194
show module	197
show mgmt-infra trace messages ilpower	198
show mgmt-infra trace messages ilpower-ha	200
show mgmt-infra trace messages platform-mgr-poe	201
show network-policy profile	202
show platform CAPWAP summary	203

- show platform forward 204
- show platform hardware fed switch forward 206
- show platform resources 208
- show platform software ilpower 209
- show platform software process list 211
- show platform software process slot switch 214
- show platform software status control-processor 216
- show processes cpu platform monitor 219
- show processes memory platform 221
- show power inline 224
- show stack-power 229
- show stack-power 231
- show system mtu 232
- show tech-support 233
- show wireless interface summary 235
- speed 236
- stack-power 238
- switchport block 240
- system mtu 241
- test mcu read-register 242
- transceiver type all 244
- voice-signaling vlan (network-policy configuration) 245
- voice vlan (network-policy configuration) 247
- wireless ap-manager interface 249
- wireless exclusionlist 250
- wireless linktest 251
- wireless management interface 252
- wireless peer-blocking forward-upstream 253

PART IV IP 255

CHAPTER 5 IP Commands 257

- clear ip nhrp 259
- debug nhrp 260

fhrp delay	262
fhrp version vrrp v3	263
glbp authentication	264
glbp forwarder preempt	266
glbp ip	267
glbp load-balancing	268
glbp name	269
glbp preempt	271
glbp priority	272
glbp timers	273
glbp weighting	275
glbp weighting track	276
ip address dhcp	278
ip address pool (DHCP)	281
ip address	282
ip http server	284
ip http secure-server	286
ip nhrp map	288
ip nhrp map multicast	290
ip nhrp network-id	292
ip nhrp nhs	293
key chain	295
key-string (authentication)	296
key	297
show glbp	298
show ip nhrp nhs	301
show key chain	303
show track	304
track	306
vrrp	308
vrrp description	309
vrrp preempt	310
vrrp priority	311
vrrp timers advertise	312

vrrs leader 313

PART V

IP Multicast Routing Commands 315

CHAPTER 6

IP Multicast Commands 317

cache-memory-max 319

clear ip mfib counters 320

clear ip mroute 321

ip igmp filter 322

ip igmp max-groups 323

ip igmp profile 325

ip igmp snooping 326

ip igmp snooping last-member-query-count 327

ip igmp snooping querier 329

ip igmp snooping report-suppression 331

ip igmp snooping vlan mrouter 332

ip igmp snooping vlan static 333

ip multicast auto-enable 334

ip multicast vlan 335

ip pim accept-register 336

ip pim bsr-candidate 337

ip pim rp-candidate 339

ip pim send-rp-announce 340

ip pim spt-threshold 342

match message-type 343

match service-type 344

match service-instance 345

mrinfo 346

redistribute mdns-sd 348

service-list mdns-sd 349

service-policy-query 350

service-routing mdns-sd 351

service-policy 352

show ip igmp filter 353

show ip igmp profile	354
show ip igmp snooping	355
show ip igmp snooping groups	357
show ip igmp snooping igmpv2-tracking	358
show ip igmp snooping mrouter	359
show ip igmp snooping querier	360
show ip igmp snooping wireless mcast-spi-count	362
show ip igmp snooping wireless mgid	363
show ip pim autorp	364
show ip pim bsr-router	365
show ip pim bsr	366
show ip pim tunnel	367
show mdns cache	369
show mdns requests	371
show mdns statistics	372
show platform ip multicast	373
wireless mdns-bridging	381
wireless multicast	382

PART VI **IPv6** 383

CHAPTER 7	IPv6 Commands 385
	ipv6 flow monitor 386
	ipv6 traffic-filter 387
	show wireless ipv6 statistics 388

PART VII **Layer 2/3** 389

CHAPTER 8	Layer 2/3 Commands 391
	channel-group 393
	channel-protocol 396
	clear lacp 397
	clear pagp 398
	clear spanning-tree counters 399

clear spanning-tree detected-protocols	400
debug etherchannel	401
debug lacp	402
debug pagp	403
debug platform pm	404
debug platform uddl	406
debug spanning-tree	407
interface port-channel	409
lacp max-bundle	410
lacp port-priority	411
lacp rate	412
lacp system-priority	413
pagp learn-method	414
pagp port-priority	416
port-channel	417
port-channel auto	418
port-channel load-balance	419
port-channel load-balance extended	421
port-channel min-links	422
rep admin vlan	423
rep block port	424
rep lsl-age-timer	426
rep lsl-retries	427
rep preempt delay	428
rep preempt segment	429
rep segment	430
rep stcn	432
show etherchannel	433
show interfaces rep detail	436
show lacp	437
show pagp	441
show platform software fed etherchannel	443
show platform pm	444
show rep topology	445

show uddl	447
switchport	450
switchport access vlan	452
switchport mode	455
switchport nonegotiate	457
switchport voice vlan	458
udld	461
udld port	463
udld reset	465

PART VIII
Lightweight Access Point 467

CHAPTER 9
Cisco Lightweight Access Point Commands 469

ap auth-list ap-policy	474
ap bridging	475
ap capwap multicast	476
ap capwap retransmit	477
ap capwap timers	478
ap cdp	480
ap core-dump	481
ap country	482
ap crash-file	483
ap dot11 24ghz preamble	484
ap dot11 24ghz dot11g	485
ap dot11 5ghz channelswitch mode	486
ap dot11 5ghz power-constraint	487
ap dot11 beaconperiod	488
ap dot11 beamforming	489
ap dot11 cac media-stream	490
ap dot11 cac multimedia	493
ap dot11 cac video	495
ap dot11 cac voice	497
ap dot11 cleanair	501
ap dot11 cleanair alarm air-quality	502

ap dot11 cleanair alarm device	503
ap dot11 cleanair device	505
ap dot11 dot11n	507
ap dot11 dtpc	510
ap dot11 edca-parameters	512
ap dot11 rrm group-mode	513
ap dot11 rrm channel cleanair-event	514
ap dot11 l2roam rf-params	515
ap dot11 media-stream	517
ap dot11 rrm ccx location-measurement	519
ap dot11 rrm channel dca	520
ap dot11 rrm group-member	522
ap dot11 rrm logging	523
ap dot11 rrm monitor	525
ap dot11 rrm ndp-type	527
ap dot11 5ghz dot11ac frame-burst	528
ap dot1x max-sessions	529
ap dot1x username	530
ap ethernet duplex	531
ap group	532
ap image	533
ap ipv6 tcp adjust-mss	534
ap led	535
ap link-encryption	536
ap link-latency	537
ap mgmtuser username	538
ap name ap-groupname	540
ap name antenna band mode	541
ap name bhrate	542
ap name bridgegroupname	543
ap name bridging	544
ap name cdp interface	545
ap name console-redirect	546
ap name capwap retransmit	547

ap name command	548
ap name core-dump	549
ap name country	550
ap name crash-file	551
ap name dot11 24ghz rrm coverage	552
ap name dot11 49ghz rrm profile	554
ap name dot11 5ghz rrm channel	556
ap name dot11 antenna	557
ap name dot11 antenna extantgain	559
ap name dot11 cleanair	560
ap name dot11 dot11n antenna	561
ap name dot11 dual-band cleanair	562
ap name dot11 dual-band shutdown	563
ap name dot11 rrm ccx	564
ap name dot11 rrm profile	565
ap name dot11 txpower	567
ap name dot1x-user	568
ap name ethernet	570
ap name ethernet duplex	571
ap name key-zeroize	572
ap name image	573
ap name ipv6 tcp adjust-mss	574
ap name jumbo mtu	575
ap name lan	576
ap name led	577
ap name link-encryption	578
ap name link-latency	579
ap name location	580
ap name mgmtuser	581
ap name mode	583
ap name monitor-mode	585
ap name monitor-mode dot11b	586
ap name name	587
ap name no dot11 shutdown	588

ap name power	589
ap name shutdown	590
ap name slot shutdown	591
ap name sniff	592
ap name ssh	593
ap name telnet	594
ap name power injector	595
ap name power pre-standard	596
ap name reset-button	597
ap name reset	598
ap name slot	599
ap name static-ip	601
ap name stats-timer	602
ap name syslog host	603
ap name syslog level	604
ap name tcp-adjust-mss	605
ap name tftp-downgrade	606
ap power injector	607
ap power pre-standard	608
ap reporting-period	609
ap reset-button	610
service-policy type control subscriber	611
ap static-ip	612
ap syslog	613
ap name no controller	614
ap tcp-adjust-mss size	615
ap tftp-downgrade	616
config wireless wps rogue client mse	617
clear ap name tsm dot11 all	618
clear ap config	619
clear ap eventlog-all	620
clear ap join statistics	621
clear ap mac-address	622
clear ap name wlan statistics	623

debug ap mac-address	624
show ap cac voice	625
show ap capwap	627
show ap cdp	629
show ap config dot11	630
show ap config dot11 dual-band summary	631
show ap config fnf	632
show ap config	633
show ap crash-file	634
show ap data-plane	635
show ap dot11 l2roam	636
show ap dot11 cleanair air-quality	637
show ap dot11 cleanair config	638
show ap dot11 cleanair summary	640
show ap dot11	641
show ap env summary	647
show ap ethernet statistics	648
show ap gps-location summary	649
show ap groups	650
show ap groups extended	651
show ap image	652
show ap is-supported	653
show ap join stats summary	654
show ap link-encryption	655
show ap mac-address	656
show ap monitor-mode summary	658
show ap name auto-rf	659
show ap name bhmode	662
show ap name bhrate	663
show ap name cac voice	664
show ap name config fnf	665
show ap name dot11 call-control	666
show ap name cable-modem	667
show ap name capwap retransmit	668

show ap name ccx rm	669
show ap name cdp	670
show ap name channel	671
show ap name config	672
show ap name config dot11	674
show ap name config slot	678
show ap name core-dump	682
show ap name data-plane	683
show ap name dot11	684
show ap name dot11 cleanair	687
show ap name env	688
show ap name ethernet statistics	689
show ap name eventlog	690
show ap gps-location summary	691
show ap name image	692
show ap name inventory	693
show ap name lan port	694
show ap name link-encryption	695
show ap name service-policy	696
show ap name tcp-adjust-mss	697
show ap name wlan	698
show ap name wlandot11 service policy	700
show ap slots	701
show ap summary	702
show ap tcp-adjust-mss	703
show ap universal summary	704
show ap uptime	705
show wireless ap summary	706
show wireless client ap	707
test ap name	708
test capwap ap name	709
trapflags ap	710
wireless wps rogue ap rldp alarm-only	711
wireless wps rogue ap rldp auto-contain	712

PART IX**Mobility 713**

CHAPTER 10**Mobility Commands 715**

- mobility anchor 716
- wireless mobility 718
- wireless mobility controller 719
- wireless mobility controller (ip_address) 721
- wireless mobility controller peer-group 722
- wireless mobility group keepalive 723
- wireless mobility group member ip 724
- wireless mobility group name 725
- wireless mobility load-balance 726
- show wireless mobility 727
- clear wireless mobility statistics 728

PART X**Network Management 729**

CHAPTER 11**Network Management Commands 731**

- ip wccp 733
- monitor capture (interface/control plane) 735
- monitor capture buffer 739
- monitor capture clear 740
- monitor capture export 741
- monitor capture file 742
- monitor capture limit 744
- monitor capture match 745
- monitor capture start 746
- monitor capture stop 747
- monitor session 748
- monitor session destination 750
- monitor session filter 754
- monitor session source 756
- show ip sla statistics 759

show monitor	761
show monitor capture	763
show platform ip wccp	765
show platform software swspan	766
snmp-server enable traps	768
snmp-server enable traps bridge	771
snmp-server enable traps bulkstat	772
snmp-server enable traps call-home	773
snmp-server enable traps cef	774
snmp-server enable traps cpu	775
snmp-server enable traps envmon	776
snmp-server enable traps errdisable	777
snmp-server enable traps flash	778
snmp-server enable traps isis	779
snmp-server enable traps license	780
snmp-server enable traps mac-notification	781
snmp-server enable traps ospf	782
snmp-server enable traps pim	783
snmp-server enable traps port-security	784
snmp-server enable traps power-ethernet	785
snmp-server enable traps snmp	786
snmp-server enable traps stackwise	787
snmp-server enable traps storm-control	789
snmp-server enable traps stpx	790
snmp-server enable traps transceiver	791
snmp-server enable traps vrfmib	792
snmp-server enable traps vstack	793
snmp-server engineID	794
snmp-server host	795
switchport mode access	799
switchport voice vlan	800

CHAPTER 12**QoS Commands 803**

auto qos classify	804
auto qos trust	810
auto qos video	817
auto qos voip	827
debug auto qos	840
show auto qos	841
class	843
class-map	846
match (class-map configuration)	848
match non-client-nrt	851
match wlan user-priority	852
policy-map	853
priority	856
queue-buffers ratio	858
queue-limit	859
qos wireless-default untrust	861
service-policy (Wired)	862
service-policy (WLAN)	864
set	865
show ap name service-policy	872
show ap name dot11	873
show class-map	876
show platform hardware fed switch	877
show platform software fed switch qos	880
show platform software fed switch qos qsb	881
show wireless client calls	884
show wireless client dot11	885
show wireless client mac-address (Call Control)	886
show wireless client mac-address (TCLAS)	887
show wireless client voice diagnostics	888
show policy-map	889
show wlan	891

trust device 894

PART XII
Radio Resource Management 897

CHAPTER 13
Radio Resource Management Commands 899

airtime-fairness dot11 mode (apgroup) 901

airtime-fairness dot11 optimization (apgroup) 902

airtime-fairness dot11 policy 903

airtime-fairness policy (wlan) 904

ap dot11 rrm 905

ap dot11 rrm ccx 908

ap dot11 rrm channel 909

ap dot11 24ghz rrm channel cleanair-event rogue-contribution 910

ap dot11 24ghz or 5ghz rrm channel dca add 911

ap dot11 24ghz or 5ghz rrm channel dca remove 912

ap dot11 5ghz rrm channel dca chan-width-11n 913

ap dot11 rrm coverage 914

ap dot11 rrm group-member 916

ap dot11 rrm monitor 917

ap dot11 rrm profile 918

ap dot11 rrm tpc-threshold 919

ap dot11 rrm txpower 920

ap dot11 airtime-fairness mode 921

ap dot11 airtime-fairness policy-name 922

 policy-weight 922

ap name dot11 airtime-fairness mode 924

ap name dot11 airtime-fairness optimization 925

ap name no dot11 airtime-fairness wlan-name policy-name 926

ap name dot11 airtime-fairness wlan-name policy 927

no ap dot11 airtime-fairness policy-name 928

clear wireless airtime-fairness statistics 929

show ap dot11 24ghz 930

show ap dot11 5ghz 932

show ap airtime-fairness (per radio) 934

show ap dot11 airtime-fairness (radio bands)	935
show ap name dot11 airtime-fairness summary	936
show ap airtime-fairness (ap)	937
show ap airtime-fairness policy (all)	938
show ap name dot11 airtime-fairness policy statistics	939
show ap airtime-fairness wlan	940
show ap name dot11 airtime-fairness wlan name statistics	941
show ap airtime-fairness ap-group	942

PART XIII
Security 943

CHAPTER 14
Security 945

aaa accounting	947
aaa accounting dot1x	950
aaa accounting identity	952
aaa authentication dot1x	954
aaa authorization network	955
aaa new-model	956
access-session template monitor	958
authentication host-mode	959
authentication mac-move permit	961
authentication priority	962
authentication violation	965
clear errdisable interface vlan	967
clear mac address-table	968
deny (MAC access-list configuration)	970
device-role (IPv6 snooping)	974
device-role (IPv6 nd inspection)	975
device-tracking policy	976
dot1x critical (global configuration)	978
dot1x test eapol-capable	979
dot1x test timeout	980
dot1x timeout	981
epm access-control open	983

ip admission	984
ip admission name	985
ip dhcp snooping database	987
ip dhcp snooping information option format remote-id	989
ip dhcp snooping verify no-relay-agent-address	990
ip http access-class	991
ip source binding	993
ip verify source	994
ipv6 access-list	995
ipv6 snooping policy	997
limit address-count	998
mab request format attribute 32	999
match (access-map configuration)	1001
no authentication logging verbose	1003
no dot1x logging verbose	1004
no mab logging verbose	1005
permit (MAC access-list configuration)	1006
protocol (IPv6 snooping)	1010
radius server	1011
security level (IPv6 snooping)	1013
server-private (RADIUS)	1014
show aaa clients	1016
show aaa command handler	1017
show aaa local	1018
show aaa servers	1019
show aaa sessions	1020
show authentication sessions	1021
show dot1x	1024
show eap pac peer	1026
show ip dhcp snooping statistics	1027
show radius server-group	1030
show storm-control	1032
show vlan access-map	1034
show vlan group	1035

storm-control	1036
switchport port-security aging	1039
switchport port-security mac-address	1041
switchport port-security maximum	1043
switchport port-security violation	1045
tacacs server	1047
tracking (IPv6 snooping)	1048
trusted-port	1050
wireless dot11-padding	1051
wireless security dot1x	1052
wireless security lsc	1054
wireless security strong-password	1055
wireless wps ap-authentication	1056
wireless wps auto-immune	1057
wireless wps cids-sensor	1058
wireless wps client-exclusion	1059
wireless wps mfp infrastructure	1061
wireless wps rogue	1062
wireless wps shun-list re-sync	1063
vlan access-map	1064
vlan filter	1066
vlan group	1067

PART XIV
Stack Manager and High Availability 1069

CHAPTER 15
Stack Manager and High Availability Commands 1071

debug platform stack-manager	1072
main-cpu	1073
mode sso	1074
policy config-sync prc reload	1075
redundancy	1076
redundancy config-sync mismatched-commands	1077
redundancy force-switchover	1079
redundancy reload	1080

reload	1081
session	1083
set trace capwap ap ha	1084
set trace mobility ha	1085
set trace qos ap ha	1087
show checkpoint	1088
show etherchannel summary	1095
show platform ses	1096
show platform stack-manager	1102
show redundancy	1103
show redundancy config-sync	1107
show switch	1109
show trace messages capwap ap ha	1113
show trace messages mobility ha	1114
stack-mac persistent timer	1115
stack-mac update force	1117
standby console enable	1118
switch stack port	1119
switch priority	1121
switch provision	1122
switch renumber	1124

PART XV**System Management 1125**

CHAPTER 16**System Management Commands 1127**

ap hyperlocation	1130
ap ntp ip	1131
arp	1132
boot	1133
cat	1134
clear location	1135
clear location statistics	1136
clear nmsp statistics	1137
clear wireless ccx statistics	1138

clear wireless client tsm dot11 1139
clear wireless location s69 statistics 1140
copy 1141
copy startup-config tftp: 1142
copy tftp: startup-config 1143
debug call-admission wireless all 1144
debug rfid 1145
debug voice diagnostics mac-address 1146
debug wps mfp 1147
delete 1148
dir 1149
emergency-install 1151
exit 1153
flash_init 1154
help 1155
ip nbar protocol-discovery 1156
l2 traceroute 1157
license right-to-use 1158
location 1160
location algorithm 1164
location expiry 1165
location notify-threshold 1166
location plm calibrating 1167
location rfid 1168
location rssi-half-life 1169
mac address-table move update 1170
mgmt_init 1171
mkdir 1172
more 1173
nmsp notification interval 1174
no debug all 1176
readrtc 1177
rename 1178
request platform software console attach switch 1179

request platform software package clean	1181
request platform software package copy	1183
request platform software package describe file	1184
request platform software package expand	1190
request platform software package install auto-upgrade	1192
request platform software package install commit	1193
request platform software package install file	1194
request platform software package install rollback	1197
request platform software package install snapshot	1199
request platform software package verify	1201
request platform software package uninstall	1202
reset	1203
rmdir	1204
sdm prefer	1205
set	1206
show avc client	1209
show avc wlan	1210
show cable-diagnostics tdr	1211
show ap hyperlocation	1213
show debug	1214
show env	1215
show flow monitor	1217
show license right-to-use	1219
show location	1221
show location ap-detect	1222
show mac address-table move update	1224
show nmsp	1225
show sdm prefer	1226
show tech-support wireless	1228
show wireless band-select	1230
show wireless client calls	1231
show wireless client dot11	1232
show wireless client location-calibration	1233
show wireless client probing	1234

show wireless client summary	1235
show wireless client timers	1236
show wireless client voice diagnostics	1237
show wireless country	1238
show wireless detail	1241
show wireless dtls connections	1242
show wireless flow-control	1243
show wireless flow-control statistics	1244
show wireless load-balancing	1245
show wireless performance	1246
show wireless pmk-cache	1247
show wireless probe	1248
show wireless sip preferred-call-no	1249
show wireless summary	1250
shutdown	1251
system env temperature threshold yellow	1252
test cable-diagnostics tdr	1254
traceroute mac	1255
traceroute mac ip	1258
trapflags	1260
trapflags client	1261
type	1262
unset	1263
version	1265
wireless client	1266
wireless client mac-address deauthenticate	1268
wireless client mac-address	1269
wireless load-balancing	1274
wireless sip preferred-call-no	1275
writertc	1276

CHAPTER 17**Tracing Commands 1277**

Information About Tracing 1278

Tracing Overview 1278

- Location of Tracelogs 1278
- Tracelog Naming Convention 1278
- Rotation and Throttling Policy 1279
- Tracing Levels 1279
- set platform software trace 1280
- show platform software trace filter-binary 1284
- show platform software trace message 1285
- show platform software trace level 1289
- request platform software trace archive 1292
- request platform software trace rotate all 1293
- request platform software trace filter-binary 1294
- set platform software trace wireless switch active R0 hyperlocation 1295

PART XVI

VideoStream 1297

CHAPTER 18

VideoStream Commands 1299

- ap dot11 media-stream multicast-direct 1300
- show ap dot11 1301
- show wireless media-stream group 1302
- wireless media-stream multicast-direct 1303
- wireless media-stream 1304

PART XVII

VLAN 1307

CHAPTER 19

VLAN Commands 1309

- client vlan 1310
- clear vtp counters 1311
- debug platform vlan 1312
- debug sw-vlan 1313
- debug sw-vlan ifs 1315
- debug sw-vlan notification 1316
- debug sw-vlan vtp 1317
- interface vlan 1319
- show platform vlan 1321

[show vlan](#) 1322
[show vtp](#) 1325
[show wireless vlan group](#) 1331
[switchport priority extend](#) 1332
[switchport trunk](#) 1333
[vlan](#) 1336
[vlan dot1q tag native](#) 1342
[vtp \(global configuration\)](#) 1343
[vtp \(interface configuration\)](#) 1348
[vtp primary](#) 1349
[wireless broadcast vlan](#) 1350

PART XVIII
WLAN 1351

CHAPTER 20
WLAN Commands 1353

[aaa-override](#) 1355
[accounting-list](#) 1356
[band-select](#) 1357
[broadcast-ssid](#) 1358
[call-snoop](#) 1359
[channel-scan defer-priority](#) 1360
[channel-scan defer-time](#) 1361
[chd](#) 1362
[client association limit](#) 1363
[client vlan](#) 1365
[ccx aironet-iesupport](#) 1366
[datalink flow monitor](#) 1367
[device-classification](#) 1368
[default](#) 1369
[dtim dot11](#) 1372
[exclusionlist](#) 1373
[exit](#) 1374
[exit \(WLAN AP Group\)](#) 1375
[ip access-group](#) 1376

ip flow monitor	1377
ip verify source mac-check	1378
load-balance	1379
mobility anchor	1380
nac	1382
passive-client	1383
peer-blocking	1384
radio	1385
radio-policy	1386
roamed-voice-client re-anchor	1387
security web-auth	1388
service-policy (WLAN)	1389
session-timeout	1390
show wlan	1391
show wireless wlan summary	1394
shutdown	1395
sip-cac	1396
static-ip tunneling	1397
vlan	1398
universal-admin	1399
wgb non-cisco	1400
wlan (AP Group Configuration)	1401
wlan	1402
wlan shutdown	1403
wmm	1404



Preface

- [Document Conventions, on page xxxiii](#)
- [Related Documentation, on page xxxv](#)
- [Obtaining Documentation and Submitting a Service Request, on page xxxv](#)

Document Conventions

This document uses the following conventions:

Convention	Description
^ or Ctrl	Both the ^ symbol and Ctrl represent the Control (Ctrl) key on a keyboard. For example, the key combination ^D or Ctrl-D means that you hold down the Control key while you press the D key. (Keys are indicated in capital letters but are not case sensitive.)
bold font	Commands and keywords and user-entered text appear in bold font .
<i>Italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
Courier font	Terminal sessions and information the system displays appear in <code>courier font</code> .
Bold Courier font	Bold Courier font indicates text that the user must enter.
[x]	Elements in square brackets are optional.
...	An ellipsis (three consecutive nonbolded periods without spaces) after a syntax element indicates that the element can be repeated.
	A vertical line, called a pipe, indicates a choice within a set of keywords or arguments.
[x y]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
{x y}	Required alternative keywords are grouped in braces and separated by vertical bars.

Convention	Description
[x {y z}]	Nested set of square brackets or braces indicate optional or required choices within optional or required elements. Braces and a vertical bar within square brackets indicate a required choice within an optional element.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
< >	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

Reader Alert Conventions

This document may use the following conventions for reader alerts:



Note Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Tip Means *the following information will help you solve a problem*.



Caution Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.



Timesaver Means *the described action saves time*. You can save time by performing the action described in the paragraph.



Warning IMPORTANT SAFETY INSTRUCTIONS

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device. Statement 1071

SAVE THESE INSTRUCTIONS

Related Documentation



Note Before installing or upgrading the device, refer to the device release notes.

- Cisco Catalyst 3650 Switch documentation, located at:
http://www.cisco.com/go/cat3650_docs
- Cisco SFP, SFP+, and QSFP+ modules documentation, including compatibility matrixes, located at:
http://www.cisco.com/en/US/products/hw/modules/ps5455/tsd_products_support_series_home.html
- Error Message Decoder, located at:
<https://www.cisco.com/cgi-bin/Support/Errordecoder/index.cgi>

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/c/en/us/td/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.



Using the Command-Line Interface

This chapter contains the following topics:

- [Using the Command-Line Interface, on page 2](#)

Using the Command-Line Interface

This chapter describes the Cisco IOS command-line interface (CLI) and how to use it to configure your switch.

Understanding Command Modes

The Cisco IOS user interface is divided into many different modes. The commands available to you depend on which mode you are currently in. Enter a question mark (?) at the system prompt to obtain a list of commands available for each command mode.

When you start a session on the switch, you begin in user mode, often called user EXEC mode. Only a limited subset of the commands are available in user EXEC mode. For example, most of the user EXEC commands are one-time commands, such as **show** commands, which show the current configuration status, and **clear** commands, which clear counters or interfaces. The user EXEC commands are not saved when the switch reboots.

To have access to all commands, you must enter privileged EXEC mode. Normally, you must enter a password to enter privileged EXEC mode. From this mode, you can enter any privileged EXEC command or enter global configuration mode.

Using the configuration modes (global, interface, and line), you can make changes to the running configuration. If you save the configuration, these commands are stored and used when the switch reboots. To access the various configuration modes, you must start at global configuration mode. From global configuration mode, you can enter interface configuration mode and line configuration mode.

This table describes the main command modes, how to access each one, the prompt you see in that mode, and how to exit the mode. The examples in the table use the hostname *Switch*.

Table 1: Command Mode Summary

Mode	Access Method	Prompt	Exit Method	About This Mode
User EXEC	Begin a session with your switch.	Switch>	Enter logout or quit .	Use this mode to <ul style="list-style-type: none"> • Change terminal settings. • Perform basic tests. • Display system information.
Privileged EXEC	While in user EXEC mode, enter the enable command.	Device#	Enter disable to exit.	Use this mode to verify commands that you have entered. Use a password to protect access to this mode.
Global configuration	While in privileged EXEC mode, enter the configure command.	Device(config)#	To exit to privileged EXEC mode, enter exit or end , or press Ctrl-Z .	Use this mode to configure parameters that apply to the entire switch.

Mode	Access Method	Prompt	Exit Method	About This Mode
VLAN configuration	While in global configuration mode, enter the vlan <i>vlan-id</i> command.	Device (config-vlan) #	To exit to global configuration mode, enter the exit command. To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to configure VLAN parameters. When VTP mode is transparent, you can create extended-range VLANs (VLAN IDs greater than 1005) and save configurations in the switch startup configuration file.
Interface configuration	While in global configuration mode, enter the interface command (with a specific interface).	Device (config-if) #	To exit to global configuration mode, enter exit . To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to configure parameters for the Ethernet ports.
Line configuration	While in global configuration mode, specify a line with the line vty or line console command.	Device (config-line) #	To exit to global configuration mode, enter exit . To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to configure parameters for the terminal line.

For more detailed information on the command modes, see the command reference guide for this release.

Understanding the Help System

You can enter a question mark (?) at the system prompt to display a list of commands available for each command mode. You can also obtain a list of associated keywords and arguments for any command.

Table 2: Help Summary

Command	Purpose
help	Obtains a brief description of the help system in any command mode.
<i>abbreviated-command-entry ?</i> Device# di? dir disable disconnect	Obtains a list of commands that begin with a particular character string.

Command	Purpose
<i>abbreviated-command-entry</i> <Tab> Device# sh conf <tab> Device# show configuration	Completes a partial command name.
? Switch> ?	Lists all commands available for a particular command mode.
<i>command</i> ? Switch> show ?	Lists the associated keywords for a command.
<i>command keyword</i> ? Device(config)# cdp holdtime ? <10-255> Length of time (in sec) that receiver must keep this packet	Lists the associated arguments for a keyword.

Understanding Abbreviated Commands

You need to enter only enough characters for the switch to recognize the command as unique.

This example shows how to enter the **show configuration** privileged EXEC command in an abbreviated form:

```
Device# show conf
```

Understanding no and default Forms of Commands

Almost every configuration command also has a **no** form. In general, use the **no** form to disable a feature or function or reverse the action of a command. For example, the **no shutdown** interface configuration command reverses the shutdown of an interface. Use the command without the keyword **no** to re-enable a disabled feature or to enable a feature that is disabled by default.

Configuration commands can also have a **default** form. The **default** form of a command returns the command setting to its default. Most commands are disabled by default, so the **default** form is the same as the **no** form. However, some commands are enabled by default and have variables set to certain default values. In these cases, the **default** command enables the command and sets variables to their default values.

Understanding CLI Error Messages

This table lists some error messages that you might encounter while using the CLI to configure your switch.

Table 3: Common CLI Error Messages

Error Message	Meaning	How to Get Help
% Ambiguous command: "show con"	You did not enter enough characters for your switch to recognize the command.	Re-enter the command followed by a question mark (?) with a space between the command and the question mark. The possible keywords that you can enter with the command appear.
% Incomplete command.	You did not enter all the keywords or values required by this command.	Re-enter the command followed by a question mark (?) with a space between the command and the question mark. The possible keywords that you can enter with the command appear.
% Invalid input detected at '^' marker.	You entered the command incorrectly. The caret (^) marks the point of the error.	Enter a question mark (?) to display all the commands that are available in this command mode. The possible keywords that you can enter with the command appear.

Using Configuration Logging

You can log and view changes to the switch configuration. You can use the Configuration Change Logging and Notification feature to track changes on a per-session and per-user basis. The logger tracks each configuration command that is applied, the user who entered the command, the time that the command was entered, and the parser return code for the command. This feature includes a mechanism for asynchronous notification to registered applications whenever the configuration changes. You can choose to have the notifications sent to the syslog.



Note Only CLI or HTTP changes are logged.

Using Command History

The software provides a history or record of commands that you have entered. The command history feature is particularly useful for recalling long or complex commands or entries, including access lists. You can customize this feature to suit your needs.

Changing the Command History Buffer Size

By default, the switch records ten command lines in its history buffer. You can alter this number for a current terminal session or for all sessions on a particular line. These procedures are optional.

Beginning in privileged EXEC mode, enter this command to change the number of command lines that the switch records during the current terminal session:

```
Device# terminal history [size number-of-lines]
```

The range is from 0 to 256.

Beginning in line configuration mode, enter this command to configure the number of command lines the switch records for all sessions on a particular line:

```
Device(config-line)# history [size number-of-lines]
```

The range is from 0 to 256.

Recalling Commands

To recall commands from the history buffer, perform one of the actions listed in this table. These actions are optional.



Note

The arrow keys function only on ANSI-compatible terminals such as VT100s.

Table 4: Recalling Commands

Action	Result
Press Ctrl-P or the up arrow key.	Recalls commands in the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Press Ctrl-N or the down arrow key.	Returns to more recent commands in the history buffer after recalling commands with Ctrl-P or the up arrow key. Repeat the key sequence to recall successively more recent commands.
show history Device(config)# help	While in privileged EXEC mode, lists the last several commands that you just entered. The number of commands that appear is controlled by the setting of the terminal history global configuration command and the history line configuration command.

Disabling the Command History Feature

The command history feature is automatically enabled. You can disable it for the current terminal session or for the command line. These procedures are optional.

To disable the feature during the current terminal session, enter the **terminal no history** privileged EXEC command.

To disable command history for the line, enter the **no history** line configuration command.

Using Editing Features

This section describes the editing features that can help you manipulate the command line.

Enabling and Disabling Editing Features

Although enhanced editing mode is automatically enabled, you can disable it, re-enable it, or configure a specific line to have enhanced editing. These procedures are optional.

To globally disable enhanced editing mode, enter this command in line configuration mode:

```
Switch (config-line)# no editing
```

To re-enable the enhanced editing mode for the current terminal session, enter this command in privileged EXEC mode:

```
Device# terminal editing
```

To reconfigure a specific line to have enhanced editing mode, enter this command in line configuration mode:

```
Device(config-line)# editing
```

Editing Commands through Keystrokes

This table shows the keystrokes that you need to edit command lines. These keystrokes are optional.



Note The arrow keys function only on ANSI-compatible terminals such as VT100s.

Table 5: Editing Commands through Keystrokes

Capability	Keystroke	Purpose
Move around the command line to make changes or corrections.	Press Ctrl-B , or press the left arrow key.	Moves the cursor back one character.
	Press Ctrl-F , or press the right arrow key.	Moves the cursor forward one character.
	Press Ctrl-A .	Moves the cursor to the beginning of the command line.
	Press Ctrl-E .	Moves the cursor to the end of the command line.
	Press Esc B .	Moves the cursor back one word.
	Press Esc F .	Moves the cursor forward one word.
	Press Ctrl-T .	Transposes the character to the left of the cursor with the character located at the cursor.

Capability	Keystroke	Purpose
Recall commands from the buffer and paste them in the command line. The switch provides a buffer with the last ten items that you deleted.	Press Ctrl-Y .	Recalls the most recent entry in the buffer.
	Press Esc Y .	Recalls the next buffer entry. The buffer contains only the last 10 items that you have deleted or cut. If you press Esc Y more than ten times, you cycle to the first buffer entry.
Delete entries if you make a mistake or change your mind.	Press the Delete or Backspace key.	Erases the character to the left of the cursor.
	Press Ctrl-D .	Deletes the character at the cursor.
	Press Ctrl-K .	Deletes all characters from the cursor to the end of the command line.
	Press Ctrl-U or Ctrl-X .	Deletes all characters from the cursor to the beginning of the command line.
	Press Ctrl-W .	Deletes the word to the left of the cursor.
	Press Esc D .	Deletes from the cursor to the end of the word.
Capitalize or lowercase words or capitalize a set of letters.	Press Esc C .	Capitalizes at the cursor.
	Press Esc L .	Changes the word at the cursor to lowercase.
	Press Esc U .	Capitalizes letters from the cursor to the end of the word.
Designate a particular keystroke as an executable command, perhaps as a shortcut.	Press Ctrl-V or Esc Q .	

Capability	Keystroke	Purpose
Scroll down a line or screen on displays that are longer than the terminal screen can display. Note The More prompt is used for any output that has more lines than can be displayed on the terminal screen, including show command output. You can use the Return and Space bar keystrokes whenever you see the More prompt.	Press the Return key.	Scrolls down one line.
	Press the Space bar.	Scrolls down one screen.
Redisplay the current command line if the switch suddenly sends a message to your screen.	Press Ctrl-L or Ctrl-R .	Redisplays the current command line.

Editing Command Lines that Wrap

You can use a wraparound feature for commands that extend beyond a single line on the screen. When the cursor reaches the right margin, the command line shifts ten spaces to the left. You cannot see the first ten characters of the line, but you can scroll back and check the syntax at the beginning of the command. The keystroke actions are optional.

To scroll back to the beginning of the command entry, press **Ctrl-B** or the left arrow key repeatedly. You can also press **Ctrl-A** to immediately move to the beginning of the line.



Note The arrow keys function only on ANSI-compatible terminals such as VT100s.

In this example, the **access-list** global configuration command entry extends beyond one line. When the cursor first reaches the end of the line, the line is shifted ten spaces to the left and redisplayed. The dollar sign (\$) shows that the line has been scrolled to the left. Each time the cursor reaches the end of the line, the line is again shifted ten spaces to the left.

```
Device(config)# access-list 101 permit tcp 131.108.2.5 255.255.255.0 131.108.1
Device(config)# $ 101 permit tcp 131.108.2.5 255.255.255.0 131.108.1.20 255.25
Device(config)# $t tcp 131.108.2.5 255.255.255.0 131.108.1.20 255.255.255.0 eq
Device(config)# $108.2.5 255.255.255.0 131.108.1.20 255.255.255.0 eq 45
```

After you complete the entry, press **Ctrl-A** to check the complete syntax before pressing the **Return** key to execute the command. The dollar sign (\$) appears at the end of the line to show that the line has been scrolled to the right:

```
Device(config)# access-list 101 permit tcp 131.108.2.5 255.255.255.0 131.108.1$
```

The software assumes that you have a terminal screen that is 80 columns wide. If you have a width other than that, use the **terminal width** privileged EXEC command to set the width of your terminal.

Use line wrapping with the command history feature to recall and modify previous complex command entries.

Searching and Filtering Output of show and more Commands

You can search and filter the output for **show** and **more** commands. This is useful when you need to sort through large amounts of output or if you want to exclude output that you do not need to see. Using these commands is optional.

To use this functionality, enter a **show** or **more** command followed by the pipe character (`|`), one of the keywords **begin**, **include**, or **exclude**, and an expression that you want to search for or filter out:

```
command | {begin | include | exclude} regular-expression
```

Expressions are case sensitive. For example, if you enter `| exclude output`, the lines that contain *output* are not displayed, but the lines that contain *Output* appear.

This example shows how to include in the output display only lines where the expression *protocol* appears:

```
Device# show interfaces | include protocol
Vlan1 is up, line protocol is up
Vlan10 is up, line protocol is down
GigabitEthernet1/0/1 is up, line protocol is down
GigabitEthernet1/0/2 is up, line protocol is up
```

Accessing the CLI

You can access the CLI through a console connection, through Telnet, or by using the browser.

You manage the switch stack and the stack member interfaces through the active switch. You cannot manage stack members on an individual switch basis. You can connect to the active switchstack master through the console port or the Ethernet management port of one or more stack members. Be careful with using multiple CLI sessions to the active switchstack master. Commands you enter in one session are not displayed in the other sessions. Therefore, it is possible to lose track of the session from which you entered commands.



Note We recommend using one CLI session when managing the switch stack.

If you want to configure a specific stack member port, you must include the stack member number in the CLI command interface notation.

To debug a specific stack member, you can access it from the active switchstack master by using the **session stack-member-number** privileged EXEC command. The stack member number is appended to the system prompt. For example, *Switch-2#* is the prompt in privileged EXEC mode for stack member 2, and where the system prompt for the active switchstack master is *Switch*. Only the **show** and **debug** commands are available in a CLI session to a specific stack member.

Accessing the CLI through a Console Connection or through Telnet

Before you can access the CLI, you must connect a terminal or a PC to the switch console or connect a PC to the Ethernet management port and then power on the switch, as described in the hardware installation guide that shipped with your switch.

CLI access is available before switch setup. After your switch is configured, you can access the CLI through a remote Telnet session or SSH client.

You can use one of these methods to establish a connection with the switch:

- Connect the switch console port to a management station or dial-up modem, or connect the Ethernet management port to a PC. For information about connecting to the console or Ethernet management port, see the switch hardware installation guide.
- Use any Telnet TCP/IP or encrypted Secure Shell (SSH) package from a remote management station. The switch must have network connectivity with the Telnet or SSH client, and the switch must have an enable secret password configured.

The switch supports up to 16 simultaneous Telnet sessions. Changes made by one Telnet user are reflected in all other Telnet sessions.

The switch supports up to five simultaneous secure SSH sessions.

After you connect through the console port, through the Ethernet management port, through a Telnet session or through an SSH session, the user EXEC prompt appears on the management station.



PART I

CleanAir

- [CleanAir Commands, on page 15](#)



CleanAir Commands

- [ap dot11 5ghz cleanair](#) , on page 16
- [ap dot11 5ghz cleanair alarm air-quality](#), on page 17
- [ap dot11 5ghz cleanair alarm device](#), on page 18
- [default ap dot11 5ghz cleanair device](#), on page 19
- [ap dot11 5ghz rrm channel cleanair-event](#), on page 20
- [ap dot11 5ghz rrm channel device](#), on page 21
- [ap dot11 24ghz cleanair](#), on page 22
- [ap dot11 24ghz cleanair alarm air-quality](#), on page 23
- [ap dot11 24ghz cleanair alarm device](#), on page 24
- [default ap dot11 24ghz cleanair device](#), on page 26
- [ap dot11 24ghz rrm channel cleanair-event](#), on page 28
- [ap dot11 24ghz rrm channel device](#), on page 29
- [ap name mode se-connect](#), on page 30
- [default ap dot11 5ghz cleanair device](#), on page 31
- [default ap dot11 5ghz rrm channel cleanair-event](#), on page 32
- [default ap dot11 5ghz rrm channel device](#), on page 33
- [default ap dot11 24ghz cleanair alarm device](#), on page 34
- [default ap dot11 24ghz cleanair device](#), on page 36
- [default ap dot11 24ghz rrm channel cleanair-event](#), on page 38
- [show ap dot11 5ghz cleanair air-quality summary](#), on page 39
- [show ap dot11 5ghz cleanair air-quality worst](#), on page 40
- [show ap dot11 5ghz cleanair config](#), on page 41
- [show ap dot11 5ghz cleanair device type](#), on page 43
- [show ap dot11 24ghz cleanair air-quality summary](#), on page 45
- [show ap dot11 24ghz cleanair air-quality worst](#), on page 46
- [show ap dot11 24ghz cleanair config](#), on page 47
- [show ap dot11 24ghz cleanair summary](#), on page 49

ap dot11 5ghz cleanair

To enable CleanAir for detecting 5-GHz devices, use the **ap dot11 5ghz cleanair** command in global configuration mode.

ap dot11 5ghz cleanair

Command Default

Disabled.

Command Modes

Global configuration.

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
	This command was introduced.

Usage Guidelines

You must enable this CleanAir command before you configure other CleanAir commands.

This example shows how to enable CleanAir for 5-GHz devices:

```
Device(config)# ap dot11 5ghz cleanair
```

Related Topics

- [ap dot11 5ghz cleanair alarm air-quality](#), on page 17
- [ap dot11 5ghz cleanair alarm device](#), on page 18
- [default ap dot11 5ghz cleanair device](#), on page 19
- [ap dot11 5ghz rrm channel cleanair-event](#), on page 20
- [ap dot11 5ghz rrm channel device](#), on page 21

ap dot11 5ghz cleanair alarm air-quality

To configure the alarm when the Air Quality (AQ) reaches the threshold value for the 5-GHz devices, use the **ap dot11 5ghz cleanair alarm air-quality** command. To disable the alarm when the AQ reaches the threshold value for the 5-GHz devices, use the **no** form of this command.

```
ap dot11 5ghz cleanair alarm air-quality threshold threshold_value
```

Syntax Description	threshold <i>threshold_value</i> Configures the threshold value for air quality. The range is from 1 to 100.						
Command Default	The default threshold value for AQ is 10.						
Command Modes	Global configuration (config).						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE</td> </tr> <tr> <td></td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE		This command was introduced.
Release	Modification						
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE						
	This command was introduced.						
Usage Guidelines	<p>You must enable CleanAir using the ap dot11 5ghz cleanair command before you configure this command.</p> <p>This example shows how to set the threshold value for the AQ:</p> <pre>Device(config)# ap dot11 5ghz cleanair alarm air-quality threshold 30</pre>						

Related Topics

[ap dot11 5ghz cleanair](#), on page 16

[default ap dot11 5ghz cleanair device](#), on page 19

ap dot11 5ghz cleanair alarm device

To configure the alarm for the 5-GHz interference devices, use the **ap dot11 5ghz cleanair alarm device** command.

ap dot11 5ghz cleanair alarm device { **canopy** | **cont-tx** | **dect-like** | **inv** | **jammer** | **nonstd** | **radar** | **superag** | **tdd-tx** | **video** | **wimax-fixed** | **wimax-mobile** }

Syntax Description

canopy	Configures the alarm for canopy interference devices.
cont-tx	Configures the alarm for continuous transmitters.
dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
jammer	Configures the alarm for jammer interference devices.
nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
radar	Configures the alarm for radars.
superag	Configures the alarm for 802.11 SuperAG interference devices.
tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
video	Configures the alarm for video cameras.
wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.

Command Default

The alarm for Wi-Fi inverted devices is enabled and for all other interference devices is disabled.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You must enable CleanAir using the **ap dot11 5ghz cleanair** command before you configure this command.

This example shows how to enable the alarm to notify interferences from a radar device:

```
Device(config)# ap dot11 5ghz cleanair alarm device radar
```

Related Topics

[ap dot11 5ghz cleanair](#) , on page 16

[ap dot11 5ghz cleanair alarm air-quality](#), on page 17

default ap dot11 5ghz cleanair device

To configure the default state of the alarm for 5-GHz interference devices, use the **default ap dot11 5ghz cleanair device** command in global configuration mode.

```
default ap dot11 5ghz cleanair device {canopy | cont-tx | dect-like | inv | jammer | nonstd | radar
| report | superag | tdd-tx | video | wimax-fixed | wimax-mobile}
```

Syntax	Description
canopy	Configures the alarm for canopy interference devices.
cont-tx	Configures the alarm for continuous transmitters.
dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
jammer	Configures the alarm for jammer interference devices.
nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
radar	Configures the alarm for radars.
report	Enables interference device reports.
superag	Configures the alarm for 802.11 SuperAG interference devices.
tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
video	Configures the alarm for video cameras.
wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.

Command Default The alarm for Wi-Fi inverted devices is enabled. The alarm for all other interference devices is disabled.

Command Modes Global configuration (config).

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You must enable CleanAir using the **ap dot11 5ghz cleanair** command before you configure this command.

This example shows how to enable CleanAir to report when a video camera interferes:

```
Device(config)# default ap dot11 5ghz cleanair device video
```

ap dot11 5ghz rrm channel cleanair-event

To enable Event-Driven RRM (EDRRM) and configure the sensitivity for 5-GHz devices, use the **ap dot11 5ghz rrm channel cleanair-event** command in global configuration mode. To disable EDRRM, use the **no** form of the command.

```
ap dot11 5ghz rrm channel cleanair-event [sensitivity {high | low | medium}]
no ap dot11 5ghz rrm channel cleanair-event [sensitivity {high | low | medium}]
```

Syntax Description		
	sensitivity	(Optional) Configures the EDRRM sensitivity of the CleanAir event.
	high	(Optional) Specifies the highest sensitivity to non-Wi-Fi interference as indicated by the air quality (AQ) value.
	low	(Optional) Specifies the least sensitivity to non-Wi-Fi interference as indicated by the AQ value.
	medium	(Optional) Specifies medium sensitivity to non-Wi-Fi interference as indicated by the AQ value.

Command Default EDRRM is disabled and the EDRRM sensitivity is low.

Command Modes Global configuration (config).

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You must enable EDRRM using the **ap dot11 5ghz rrm channel cleanair-event** command before you configure the sensitivity.

This example shows how to enable EDRRM and set the EDRRM sensitivity to high:

```
Device(config)# ap dot11 5ghz rrm channel cleanair-event
Device(config)# ap dot11 5ghz rrm channel cleanair-event sensitivity high
```

Related Topics

- [ap dot11 5ghz cleanair](#), on page 16
- [ap dot11 5ghz rrm channel device](#), on page 21

ap dot11 5ghz rrm channel device

To configure persistent non-Wi-Fi device avoidance in the 802.11a channel, use the **ap dot11 5ghz rrm channel device** command in global configuration mode. To disable persistent device avoidance, use the **no** form of this command.

```
ap dot11 5ghz rrm channel device
no ap dot11 5ghz rrm channel device
```

Syntax Description This command has no arguments or keywords.

Command Default The CleanAir persistent device state is disabled.

Command Modes Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines CleanAir-capable monitor mode access points collect information about persistent devices on all configured channels and stores the information in the device. Local and bridge mode access points detect interference devices on the serving channels only.

This example shows how to enable persistent device avoidance on 802.11a devices:

```
Device(config)# ap dot11 5ghz rrm channel device
```

Related Topics

[ap dot11 5ghz cleanair](#), on page 16

[ap dot11 5ghz rrm channel cleanair-event](#), on page 20

ap dot11 24ghz cleanair

To enable CleanAir for detecting 2.4-GHz devices, use the **ap dot11 24ghz cleanair** command in global configuration mode. To disable CleanAir for detecting 2.4-GHz devices, use the **no** form of this command.

ap dot11 24ghz cleanair

Syntax Description This command has no arguments or keywords.

Command Default Disabled.

Command Modes Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You must enable this CleanAir command before you configure other CleanAir commands.

This example shows how to enable CleanAir for 2.4-GHz devices:

```
Device(config)# ap dot11 24ghz cleanair
```

Related Topics

- [ap dot11 24ghz cleanair alarm air-quality](#), on page 23
- [ap dot11 24ghz cleanair alarm device](#), on page 24
- [default ap dot11 24ghz cleanair device](#), on page 26
- [ap dot11 24ghz rrm channel cleanair-event](#), on page 28
- [ap dot11 24ghz rrm channel device](#), on page 29

ap dot11 24ghz cleanair alarm air-quality

To configure the alarm for the threshold value of Air Quality (AQ) for all 2.4-GHz devices, use the **ap dot11 24ghz cleanair alarm air-quality** command in global configuration mode. To disable the alarm for the threshold value of AQ for all 2.4-GHz devices, use the **no** form of this command.

ap dot11 24ghz cleanair alarm air-quality threshold *threshold_value*

Syntax Description	threshold <i>threshold_value</i> Configures the threshold value for AQ. The range is from 1 to 100.
---------------------------	--

Command Default	The default threshold value for AQ is 10.
------------------------	---

Command Modes	Global configuration (config)
----------------------	-------------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines	You must enable CleanAir using the ap dot11 24ghz cleanair command before you configure this command.
-------------------------	--

This example shows how to set the threshold value for the AQ:

```
Device(config)# ap dot11 24ghz cleanair alarm air-quality threshold 50
```

Related Topics

- [ap dot11 24ghz cleanair](#), on page 22
- [ap dot11 24ghz cleanair alarm device](#), on page 24
- [default ap dot11 24ghz cleanair device](#), on page 26

ap dot11 24ghz cleanair alarm device

To configure the alarm for the 2.4-GHz interference devices, use the **ap dot11 24ghz cleanair alarm device** command in global configuration mode. To disable the alarm for the 2.4-GHz interference devices, use the **no** form of this command.

```
ap dot11 24ghz cleanairalarm {device | bt-discovery | bt-link canopy | cont-tx | dect-like | fh
| inv | jammer | mw-oven | nonstd | superag | tdd-tx video | wimax-fixed | wimax-mobile |
xbox | zigbee}
```

Syntax Description

bt-discovery	Configures the alarm for Bluetooth interference devices.
bt-link	Configures the alarm for any Bluetooth link.
canopy	Configures the alarm for canopy interference devices.
cont-tx	Configures the alarm for continuous transmitters.
dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
fh	Configures the alarm for 802.11 frequency hopping (FH) devices.
inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
jammer	Configures the alarm for jammer interference devices.
mw-oven	Configures the alarm for microwave ovens.
nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
superag	Configures the alarm for 802.11 SuperAG interference devices.
tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
video	Configures the alarm for video cameras.
wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.
xbox	Configures the alarm for Xbox interference devices.
zigbee	Configures the alarm for 802.15.4 interference devices.

Command Default

The alarm for Wi-Fi inverted devices is enabled. The alarm for all other devices is disabled.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You must enable CleanAir using the **ap dot11 24ghz cleanair** command before you configure this command.

This example shows how to enable the alarm to notify interferences from a Zigbee device:

```
Device(config)# ap dot11 24ghz cleanair alarm device zigbee
```

Related Topics

[ap dot11 24ghz cleanair](#), on page 22

[ap dot11 24ghz cleanair alarm air-quality](#), on page 23

[default ap dot11 24ghz cleanair device](#), on page 26

default ap dot11 24ghz cleanair device

To configure the default state of report generation for 2.4-GHz interference devices, use the **default ap dot11 24ghz cleanair device** command in global configuration mode.

```
default ap dot11 24ghz cleanair device {ble-beacon | bt-discovery | bt-link | canopy | cont-tx |
dect-like | fh | inv | jammer | mw-oven | nonstd | report | superag | tdd-tx | video | wimax-fixed |
wimax-mobile | xbox | zigbee}
```

Syntax Description		
	ble-beacon	Configure the BLE beacon feature.
	bt-discovery	Configures the alarm for Bluetooth interference devices.
	bt-link	Configures the alarm for any Bluetooth link.
	canopy	Configures the alarm for canopy interference devices.
	cont-tx	Configures the alarm for continuous transmitters.
	dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
	fh	Configures the alarm for 802.11 frequency hopping devices.
	inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
	jammer	Configures the alarm for jammer interference devices.
	mw-oven	Configures the alarm for microwave ovens.
	nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
	superag	Configures the alarm for 802.11 SuperAG interference devices.
	tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
	video	Configures the alarm for video cameras.

wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.
xbox	Configures the alarm for Xbox interference devices.
zigbee	Configures the alarm for 802.15.4 interference devices.

Command Default

The alarm for Wi-Fi inverted devices is enabled. The alarm for all other devices is disabled.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.
Cisco IOS XE Denali 16.2.1	This command was modified. The ble-beacon keyword was added.

Usage Guidelines

You must enable CleanAir using the **ap dot11 24ghz cleanair** command before you configure this command.

This example shows how to enable CleanAir to report when a video camera interferes:

```
Device(config)# default ap dot11 24ghz cleanair device video
```

Related Topics

- [ap dot11 24ghz cleanair](#), on page 22
- [ap dot11 24ghz cleanair alarm air-quality](#), on page 23
- [ap dot11 24ghz cleanair alarm device](#), on page 24

ap dot11 24ghz rrm channel cleanair-event

To enable Event-Driven RRM (EDRRM) and the sensitivity for 2.4-GHz devices, use the **ap dot11 24ghz rrm channel cleanair-event** command in global configuration mode. To disable EDRRM, use the **no** form of this command.

```
ap dot11 24ghz rrm channel cleanair-event sensitivity {high | low | medium}
no ap dot11 24ghz rrm channel cleanair-event [sensitivity{high | low | medium}]
```

Syntax Description	sensitivity	(Optional) Configures the EDRRM sensitivity of the CleanAir event.
	high	(Optional) Specifies the highest sensitivity to non-Wi-Fi interference as indicated by the air quality (AQ) value.
	low	(Optional) Specifies the least sensitivity to non-Wi-Fi interference as indicated by the AQ value.
	medium	(Optional) Specifies medium sensitivity to non-Wi-Fi interference as indicated by the AQ value.

Command Default EDRRM is disabled and the sensitivity is low.

Command Modes Global configuration (config).

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You must enable EDRRM using the **ap dot11 24ghz rrm channel cleanair-event** command before you configure the sensitivity.

This example shows how to enable EDRRM and set the EDRRM sensitivity to low:

```
Device(config)# ap dot11 24ghz rrm channel cleanair-event
Device(config)# ap dot11 24ghz rrm channel cleanair-event sensitivity low
```

Related Topics

[ap dot11 24ghz cleanair](#), on page 22

[ap dot11 24ghz rrm channel device](#), on page 29

ap dot11 24ghz rrm channel device

To configure persistent non-Wi-Fi device avoidance in the 802.11b channel, use the **ap dot11 24ghz rrm channel device** command in global configuration mode. To disable persistent device avoidance, use the **no** form of this command.

```
ap dot11 24ghz rrm channel device
no ap dot11 24ghz rrm channel device
```

Syntax Description This command has no arguments or keywords.

Command Default Persistent device avoidance is disabled.

Command Modes Global configuration (config).

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines CleanAir-capable monitor mode access points collect information about persistent devices on all configured channels and stores the information in the device. Local and bridge mode access points detect interference devices on the serving channels only.

This example shows how to enable persistent device avoidance:

```
Device(config)# ap dot11 24ghz rrm channel device
```

Related Topics

[ap dot11 24ghz cleanair](#), on page 22

[ap dot11 24ghz rrm channel cleanair-event](#), on page 28

ap name mode se-connect

To configure the access point for SE-Connect mode, use the **ap name *ap_name* mode se-connect** command in privileged exec mode.

ap name *ap_name* mode se-connect

Syntax Description	<i>ap_name</i>	Name of the access point.
Command Default	No access point is configured for SE-Connect mode.	
Command Modes	Privileged EXEC (#)	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines

The access point will reboot after you change the mode.

SE-connect mode enables a user to connect a Spectrum Expert application running on an external Microsoft Windows XP or Vista PC to a Cisco CleanAir-enabled access point in order to display and analyze detailed spectrum data. The Spectrum Expert application connects directly to the access point, by passing the controller. An access point in SE-Connect mode does not provide any Wi-Fi, RF, or spectrum data to the controller. All CleanAir system functionality is suspended while the AP is in this mode, and no clients are served. This mode is intended for remote troubleshooting only.

This example shows how to change the mode of the access point to SE-Connect:

```
Device# ap name AS-5508-5-AP3 mode se-connect
```

```
Changing the AP's mode will cause the AP to reboot.
Are you sure you want to continue? (y/n) [y]: y
% switch-1:wcm: Cisco AP does not support the seconnect mode
```

default ap dot11 5ghz cleanair device

To configure the default state of the alarm for 5-GHz interference devices, use the **default ap dot11 5ghz cleanair device** command in global configuration mode.

```
default ap dot11 5ghz cleanair device {canopy | cont-tx | dect-like | inv | jammer | nonstd | radar
| report | superag | tdd-tx | video | wimax-fixed | wimax-mobile}
```

Syntax	Description
canopy	Configures the alarm for canopy interference devices.
cont-tx	Configures the alarm for continuous transmitters.
dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
jammer	Configures the alarm for jammer interference devices.
nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
radar	Configures the alarm for radars.
report	Enables interference device reports.
superag	Configures the alarm for 802.11 SuperAG interference devices.
tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
video	Configures the alarm for video cameras.
wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.

Command Default The alarm for Wi-Fi inverted devices is enabled. The alarm for all other interference devices is disabled.

Command Modes Global configuration (config).

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You must enable CleanAir using the **ap dot11 5ghz cleanair** command before you configure this command.

This example shows how to enable CleanAir to report when a video camera interferes:

```
Device(config)# default ap dot11 5ghz cleanair device video
```

default ap dot11 5ghz rrm channel cleanair-event

To configure the default state of Event-Driven radio resource management (EDRRM) and the EDRRM sensitivity for 5-GHz devices, use the **default ap dot11 5ghz rrm channel cleanair-event** command in global configuration mode.

default ap dot11 5ghz rrm channel cleanair-event [sensitivity {high | low | medium}]

Syntax Description	Parameter	Description
	sensitivity	(Optional) Configures the EDRRM sensitivity of the CleanAir event.
	high	(Optional) Specifies the highest sensitivity to non-Wi-Fi interference as indicated by the Air Quality (AQ) value.
	low	(Optional) Specifies the least sensitivity to non-Wi-Fi interference as indicated by the AQ value.
	medium	(Optional) Specifies medium sensitivity to non-Wi-Fi interference as indicated by the AQ value.

Command Default EDRRM is disabled and the sensitivity is low.

Command Modes Global configuration (config).

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You must enable EDRRM before you configure the sensitivity.

This example shows how to set the default EDRRM state and sensitivity:

```
Device(config)# default ap dot11 5ghz rrm channel cleanair-event
Device(config)# default ap dot11 5ghz rrm channel cleanair-event sensitivity
```

default ap dot11 5ghz rrm channel device

To configure the default state of the persistent non-Wi-Fi device avoidance in the 802.11a channels, use the **default ap dot11 5ghz rrm channel device** command in global configuration mode.

default ap dot11 5ghz rrm channel device

Syntax Description This command has no arguments or keywords.

Command Default Persistent device state is disabled.

Command Modes Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure persistent non-Wi-Fi device avoidance in the 802.11a channels:

```
Device(config)# default ap dot11 5ghz rrm channel device
```

default ap dot11 24ghz cleanair alarm device

To configure the default value of the alarm for 2.4-GHz interference devices, use the **default ap dot11 24ghz cleanair alarm device** command in global configuration mode.

```
default ap dot11 24ghz cleanair alarm device {bt-discovery | bt-link | canopy | cont-tx |
dect-like | fh | inv | jammer | mw-oven | nonstd | superag | tdd-tx | video | wimax-fixed |
wimax-mobile | xbox | zigbee }
```

Syntax Description		
	bt-discovery	Configures the alarm for Bluetooth interference devices.
	bt-link	Configures the alarm for any Bluetooth link.
	canopy	Configures the alarm for canopy interference devices.
	cont-tx	Configures the alarm for continuous transmitters.
	dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
	fh	Configures the alarm for 802.11 frequency hopping (FH) devices.
	inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
	jammer	Configures the alarm for jammer interference devices.
	mw-oven	Configures the alarm for microwave ovens.
	nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
	superag	Configures the alarm for 802.11 SuperAG interference devices.
	tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
	video	Configures the alarm for video cameras.
	wimax-fixed	Configures the alarm for WiMax fixed interference devices.
	wimax-mobile	Configures the alarm for WiMax mobile interference devices.
	xbox	Configures the alarm for Xbox interference devices.
	zigbee	Configures the alarm for 802.15.4 interference devices.

Command Default The alarm for Wi-Fi inverted devices is enabled. The alarm for all the other devices is disabled.

Command Modes Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You must enable CleanAir using the **ap dot11 24ghz cleanair** command before you configure this command.

This example shows how to configure the default CleanAir 2.4-GHz interference devices alarm:

```
Device(config)# default ap dot11 24ghz cleanair alarm device inv
```

default ap dot11 24ghz cleanair device

To configure the default state of report generation for 2.4-GHz interference devices, use the **default ap dot11 24ghz cleanair device** command in global configuration mode.

```
default ap dot11 24ghz cleanair device {ble-beacon | bt-discovery | bt-link | canopy | cont-tx |
dect-like | fh | inv | jammer | mw-oven | nonstd | report | superag | tdd-tx | video | wimax-fixed |
wimax-mobile | xbox | zigbee}
```

Syntax Description		
	ble-beacon	Configure the BLE beacon feature.
	bt-discovery	Configures the alarm for Bluetooth interference devices.
	bt-link	Configures the alarm for any Bluetooth link.
	canopy	Configures the alarm for canopy interference devices.
	cont-tx	Configures the alarm for continuous transmitters.
	dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
	fh	Configures the alarm for 802.11 frequency hopping devices.
	inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
	jammer	Configures the alarm for jammer interference devices.
	mw-oven	Configures the alarm for microwave ovens.
	nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
	superag	Configures the alarm for 802.11 SuperAG interference devices.
	tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
	video	Configures the alarm for video cameras.

wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.
xbox	Configures the alarm for Xbox interference devices.
zigbee	Configures the alarm for 802.15.4 interference devices.

Command Default

The alarm for Wi-Fi inverted devices is enabled. The alarm for all other devices is disabled.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.
Cisco IOS XE Denali 16.2.1	This command was modified. The ble-beacon keyword was added.

Usage Guidelines

You must enable CleanAir using the **ap dot11 24ghz cleanair** command before you configure this command.

This example shows how to enable CleanAir to report when a video camera interferes:

```
Device(config)# default ap dot11 24ghz cleanair device video
```

Related Topics

- [ap dot11 24ghz cleanair](#), on page 22
- [ap dot11 24ghz cleanair alarm air-quality](#), on page 23
- [ap dot11 24ghz cleanair alarm device](#), on page 24

default ap dot11 24ghz rrm channel cleanair-event

To configure the default Event-Driven radio resource management (EDRRM) state and sensitivity for 2.4-GHz devices, use the **default ap dot11 24ghz rrm channel cleanair-event** command in global configuration mode.

```
default ap dot11 24ghz rrm channel cleanair-event [sensitivity {high | low | medium}]
```

Syntax Description	sensitivity	Configures the EDRRM sensitivity of the CleanAir event.
	high	Specifies the highest sensitivity to non-Wi-Fi interference as indicated by the Air Quality (AQ) value.
	low	Specifies the least sensitivity to non-Wi-Fi interference as indicated by the AQ value.
	medium	Specifies medium sensitivity to non-Wi-Fi interference as indicated by the AQ value.

Command Default EDRRM is disabled and the sensitivity is low.

Command Modes Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to enable EDRRM and set the default EDRRM sensitivity:

```
Device(config)# default ap dot11 24ghz rrm channel cleanair-event
Device(config)# default ap dot11 24ghz rrm channel cleanair-event sensitivity
```

show ap dot11 5ghz cleanair air-quality summary

To display the CleanAir AQ data for 5-GHz band, use the **show ap dot11 5ghz cleanair air-quality summary** command in user EXEC mode or privileged EXEC mode.

show ap dot11 5ghz cleanair air-quality summary

This command has no arguments or keywords.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
	This command was introduced.

This example shows how to display the CleanAir AQ data for 5-GHz band:

```
Device# show ap dot11 5ghz cleanair air-quality summary
```

AQ = Air Quality

DFS = Dynamic Frequency Selection

AP Name	Channel	Avg AQ	Min AQ	Interferers	DFS
AP270ca.9b86.4546	1	99	99	0	No
AP2894.0f26.22df	6	98	97	0	No
AP2894.0f58.cc6b	11	99	99	0	No
AP2894.0f39.1040	6	97	97	0	No
AP2894.0f63.c6da	11	99	99	0	No
AP2894.0f58.d013	6	97	97	0	No

show ap dot11 5ghz cleanair air-quality worst

To display the worst AQ data for 5-GHz band, use the **show ap dot11 5ghz cleanair air-quality worst** command in user EXEC mode or privileged EXEC mode.

show ap dot11 5ghz cleanair air-quality worst

This command has no arguments or keywords.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display the worst AQ data for 5-GHz band:

```
Device# show ap dot11 5ghz cleanair air-quality worst
```

AQ = Air Quality

DFS = Dynamic Frequency Selection

AP Name	Channel	Avg AQ	Min AQ	Interferers	DFS
AP2894.0f39.1040	6	97	97	0	No

show ap dot11 5ghz cleanair config

To display the CleanAir configuration for 5-GHz band, use the **show ap dot11 5ghz cleanair config** command.

show ap dot11 5ghz cleanair config

This command has no arguments or keywords.

Command Modes
User EXEC (>)
Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines In Release 3.3SE, you can configure this command on the Mobility Agent (MA).

This example shows how to display the CleanAir configuration for 5-GHz band on the Mobility Controller:

```
Device# show ap dot11 5ghz cleanair config

CleanAir Solution..... : Enabled
Air Quality Settings:
  Air Quality Reporting..... : Enabled
  Air Quality Reporting Period (min)..... : 15
  Air Quality Alarms..... : Enabled
  Air Quality Alarm Threshold..... : 1
Interference Device Settings:
  Interference Device Reporting..... : Enabled
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
Interference Device Types Triggering Alarms:
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
Interference Device Alarms..... : Enabled
Additional CleanAir Settings:
  CleanAir Event-driven RRM State..... : Enabled
  CleanAir Driven RRM Sensitivity..... : HIGH
```

```
CleanAir Persistent Devices state..... : Enabled
```

This example shows how to display the CleanAir configuration for 5-GHz band on the Mobility Agent:

```
Device# show ap dot11 5ghz cleanair config
```

```
Mobility Controller Link Status..... : UP
CleanAir Solution..... : Enabled
Air Quality Settings:
  Air Quality Reporting..... : Enabled
  Air Quality Reporting Period (min)..... : 15
  Air Quality Alarms..... : Enabled
  Air Quality Alarm Threshold..... : 10
Interference Device Settings:
  Interference Device Reporting..... : Enabled
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
Interference Device Types Triggering Alarms:
  TDD Transmitter..... : Disabled
  Jammer..... : Disabled
  Continuous Transmitter..... : Disabled
  DECT-like Phone..... : Disabled
  Video Camera..... : Disabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Disabled
  WiMax Mobile..... : Disabled
  WiMax Fixed..... : Disabled
Interference Device Alarms..... : Enabled
Additional CleanAir Settings:
  CleanAir Event-driven RRM State..... : Disabled
  CleanAir Driven RRM Sensitivity..... : LOW
  CleanAir Persistent Devices state..... : Disabled
```

show ap dot11 5ghz cleanair device type

To display the 5-GHz interference devices, use the **show ap dot11 5ghz cleanair device type** command.

show ap dot11 5ghz cleanair device type {all | canopy | cont-tx | dect-like | inv | jammer | nonstd | persistent | superag | tdd-tx | video | wimax-fixed | wimax-mobile}

Syntax Description	all	Displays all CleanAir interferer devices for 5-GHz band.
	canopy	Displays CleanAir interferers of type canopy for 5-GHz band.
	cont-tx	Displays CleanAir interferers of type continuous transmitter for 5-GHz band.
	dect-like	Displays CleanAir interferers of type Digital Enhanced Cordless Communication (DECT)-like phone for 5-GHz band.
	inv	Displays CleanAir interferer devices using spectrally inverted WiFi signals for 5-GHz band.
	jammer	Displays CleanAir interferers of type jammer for 5-GHz band.
	nonstd	Displays CleanAir interferer devices using non-standard Wi-Fi channels for 5-GHz band.
	persistent	Displays CleanAir persistent device interferers for 5-GHz band.
	superag	Displays CleanAir interferers of type SuperAG for 5-GHz band.
	tdd-tx	Displays CleanAir Time Division Duplex (TDD) transmitters for 5-GHz band.
	video	Displays CleanAir interferers of type video camera for 5-GHz band.
	wimax-fixed	Displays CleanAir interferers of type WiMax fixed for 5-GHz band.
	wimax-mobile	Displays CleanAir interferers of type WiMax mobile for 5-GHz band.

Command Modes
User EXEC (>)
Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines Interference devices are listed only if there is an interference from any 5-GHz devices.

This example shows how to view all the 5-GHz interference devices:

```
Device# show ap dot11 5ghz cleanair device type all
```

```
DC      = Duty Cycle (%)
ISI     = Interference Severity Index (1-Low Interference, 100-High Interference)
RSSI    = Received Signal Strength Index (dBm)
DevID   = Device ID
```

```
show ap dot11 5ghz cleanair device type
```

No	ClusterID	DevID	Type	AP Name	ISI	RSSI	DC
----	-----------	-------	------	---------	-----	------	----

Channel

show ap dot11 24ghz cleanair air-quality summary

To display the CleanAir AQ data for 2.4-GHz band, use the **show ap dot11 24ghz cleanair air-quality summary** command in user EXEC mode or privileged EXEC mode.

show ap dot11 24ghz cleanair air-quality summary

This command has no arguments or keywords.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display the CleanAir AQ data for 2.4-GHz band:

```
Device# show ap dot11 24ghz cleanair air-quality summary
```

AQ = Air Quality

DFS = Dynamic Frequency Selection

AP Name	Channel	Avg AQ	Min AQ	Interferers	DFS
AP270ca.9b86.4546	1	99	99	0	No
AP2894.0f26.22df	6	98	97	0	No
AP2894.0f58.cc6b	11	99	99	0	No
AP2894.0f39.1040	6	97	97	0	No
AP2894.0f63.c6da	11	99	99	0	No

show ap dot11 24ghz cleanair air-quality worst

To display the worst air quality data for 2.4-GHz band, use the **show ap dot11 24ghz cleanair air-quality worst** command in user EXEC mode or privileged EXEC mode.

show ap dot11 24ghz cleanair air-quality worst

This command has no arguments or keywords.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display the worst AQ data for 2.4-GHz band:

```
Device# show ap dot11 24ghz cleanair air-quality worst
```

AQ = Air Quality

DFS = Dynamic Frequency Selection

AP Name	Channel	Avg AQ	Min AQ	Interferers	DFS
AP2895.0f39.1040	6	97	97	0	No

show ap dot11 24ghz cleanair config

To display the CleanAir configuration for 2.4-GHz band, use the **show ap dot11 24ghz cleanair config** command in user EXEC mode or privileged EXEC mode.

show ap dot11 24ghz cleanair config

This command has no arguments or keywords.

Command Modes User EXEC (>)

Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines In Release 3.3SE, you can configure this command on the Mobility Agent (MA).

This example shows how to display the CleanAir configuration for 2.4-GHz band on the Mobility Controller:

```
Device# show ap dot11 24ghz cleanair config

CleanAir Solution..... : Enabled
Air Quality Settings:
  Air Quality Reporting..... : Enabled
  Air Quality Reporting Period (min)..... : 15
  Air Quality Alarms..... : Enabled
  Air Quality Alarm Threshold..... : 1
Interference Device Settings:
  Interference Device Reporting..... : Enabled
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
Interference Device Types Triggering Alarms:
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
Interference Device Alarms..... : Enabled
Additional CleanAir Settings:
```

```

CleanAir Event-driven RRM State..... : Enabled
CleanAir Driven RRM Sensitivity..... : HIGH
CleanAir Persistent Devices state..... : Enabled

```

This example shows how to display the CleanAir configuration for 2.4-GHz band on the Mobility Agent:

```
Device# show ap dot11 24ghz cleanair config
```

```

Mobility Controller Link Status..... : UP
CleanAir Solution..... : Enabled
Air Quality Settings:
  Air Quality Reporting..... : Enabled
  Air Quality Reporting Period (min)..... : 15
  Air Quality Alarms..... : Enabled
  Air Quality Alarm Threshold..... : 10
Interference Device Settings:
  Interference Device Reporting..... : Enabled
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
Interference Device Types Triggering Alarms:
  TDD Transmitter..... : Disabled
  Jammer..... : Disabled
  Continuous Transmitter..... : Disabled
  DECT-like Phone..... : Disabled
  Video Camera..... : Disabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Disabled
  WiMax Mobile..... : Disabled
  WiMax Fixed..... : Disabled
Interference Device Alarms..... : Enabled
Additional CleanAir Settings:
  CleanAir Event-driven RRM State..... : Disabled
  CleanAir Driven RRM Sensitivity..... : LOW
  CleanAir Persistent Devices state..... : Disabled

```

show ap dot11 24ghz cleanair summary

To display a summary of 2.4-GHz CleanAir devices, use the **show ap dot11 24ghz cleanair summary** command in user EXEC mode or privileged EXEC mode.

show ap dot11 24ghz cleanair summary

This command has no arguments or keywords.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

This is an example of output from the **show ap dot11 24ghz cleanair summary** command:

Device# **show ap dot11 24ghz cleanair summary**

AP Name Spectrum Oper State	MAC Address	Slot ID	Spectrum Capable	Spectrum Intelligence
AP1cdf.0f95.1719 Down	0817.35c7.1a60	0	Disabled	Disabled
AS-5508-5-AP3 Down	0817.35dd.9f40	0	Disabled	Disabled
AP270ca.9b86.4546 Up	0c85.259e.c350	0	Enabled	Enabled
AP2894.0f26.22df Up	0c85.25ab.cca0	0	Enabled	Enabled
AP2894.0f58.cc6b Up	0c85.25c7.b7a0	0	Enabled	Enabled
AP2894.0f39.1040 Up	0c85.25de.2c10	0	Enabled	Enabled
AP2894.0f63.c6da Up	0c85.25de.c8e0	0	Enabled	Enabled

show ap dot11 24ghz cleanair summary



PART II

Flexible NetFlow Commands

- [Flexible NetFlow Commands, on page 53](#)



Flexible NetFlow Commands

- [cache](#), on page 55
- [clear flow exporter](#), on page 57
- [clear flow monitor](#), on page 58
- [collect](#), on page 60
- [collect counter](#), on page 61
- [collect interface](#), on page 62
- [collect timestamp absolute](#), on page 63
- [collect transport tcp flags](#), on page 64
- [datalink flow monitor](#), on page 65
- [debug flow exporter](#), on page 66
- [debug flow monitor](#), on page 67
- [debug flow record](#), on page 68
- [debug sampler](#), on page 69
- [description](#), on page 70
- [destination](#), on page 71
- [dscp](#), on page 72
- [export-protocol netflow-v9](#), on page 73
- [exporter](#), on page 74
- [flow exporter](#), on page 75
- [flow monitor](#), on page 76
- [flow record](#), on page 77
- [ip flow monitor](#), on page 78
- [ipv6 flow monitor](#), on page 80
- [match datalink ethertype](#), on page 82
- [match datalink mac](#), on page 83
- [match datalink vlan](#), on page 84
- [match flow cts](#), on page 85
- [match flow direction](#), on page 86
- [match interface](#), on page 87
- [match ipv4](#), on page 88
- [match ipv4 destination address](#), on page 89
- [match ipv4 source address](#), on page 90
- [match ipv4 ttl](#), on page 91

- [match ipv6](#), on page 92
- [match ipv6 destination address](#), on page 93
- [match ipv6 hop-limit](#), on page 94
- [match ipv6 source address](#), on page 95
- [match transport](#), on page 96
- [match transport icmp ipv4](#), on page 97
- [match transport icmp ipv6](#), on page 98
- [mode random 1 out-of](#), on page 99
- [option](#), on page 100
- [record](#), on page 102
- [sampler](#), on page 103
- [show flow exporter](#), on page 104
- [show flow interface](#), on page 106
- [show flow monitor](#), on page 108
- [show flow record](#), on page 110
- [show sampler](#), on page 111
- [source](#), on page 113
- [template data timeout](#), on page 115
- [transport](#), on page 116
- [ttl](#), on page 117

cache

To configure a flow cache parameter for a flow monitor, use the **cache** command in flow monitor configuration mode. To remove a flow cache parameter for a flow monitor, use the **no** form of this command.

```
cache {timeout {active | inactive} seconds | type normal}
no cache {timeout {active | inactive} | type}
```

Syntax Description	Parameter	Description
	timeout	Specifies the flow timeout.
	active	Specifies the active flow timeout.
	inactive	Specifies the inactive flow timeout.
	<i>seconds</i>	The timeout value in seconds. The range is 1 to 604800 (7 days).
	type	Specifies the type of the flow cache.
	normal	Configures a normal cache type. The entries in the flow cache will be aged out according to the timeout active seconds and timeout inactive seconds settings. This is the default cache type.

Command Default	Description
	The default flow monitor flow cache parameters are used.
	The following flow cache parameters for a flow monitor are enabled: <ul style="list-style-type: none"> • Cache type: normal • Active flow timeout: 1800 seconds • Inactive flow timeout: 15 seconds

Command Modes	Configuration Mode
	Flow monitor configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	Guidelines
	Each flow monitor has a cache that it uses to store all the flows it monitors. Each cache has various configurable elements, such as the time that a flow is allowed to remain in it. When a flow times out, it is removed from the cache and sent to any exporters that are configured for the corresponding flow monitor.

The **cache timeout active** command controls the aging behavior of the normal type of cache. If a flow has been active for a long time, it is usually desirable to age it out (starting a new flow for any subsequent packets in the flow). This age out process allows the monitoring application that is receiving the exports to remain up to date. By default, this timeout is 1800 seconds (30 minutes), but it can be adjusted according to system requirements. A larger value ensures that long-lived flows are accounted for in a single flow record; a smaller value results in a shorter delay between starting a new long-lived flow and exporting some data for it. When you change the active flow timeout, the new timeout value takes effect immediately.

The **cache timeout inactive** command also controls the aging behavior of the normal type of cache. If a flow has not seen any activity for a specified amount of time, that flow will be aged out. By default, this timeout

is 15 seconds, but this value can be adjusted depending on the type of traffic expected. If a large number of short-lived flows is consuming many cache entries, reducing the inactive timeout can reduce this overhead. If a large number of flows frequently get aged out before they have finished collecting their data, increasing this timeout can result in better flow correlation. When you change the inactive flow timeout, the new timeout value takes effect immediately.

The **cache type normal** command specifies the normal cache type. This is the default cache type. The entries in the cache will be aged out according to the **timeout active** *seconds* and **timeout inactive** *seconds* settings. When a cache entry is aged out, it is removed from the cache and exported via any exporters configured for the monitor associated with the cache.

To return a cache to its default settings, use the **default cache** flow monitor configuration command.



Note When a cache becomes full, new flows will not be monitored.

The following example shows how to configure the active timeout for the flow monitor cache:

```
Device(config)# flow monitor FLOW-MONITOR-1
Device(config-flow-monitor)# cache timeout active 4800
```

The following example shows how to configure the inactive timer for the flow monitor cache:

```
Device(config)# flow monitor FLOW-MONITOR-1
Device(config-flow-monitor)# cache timeout inactive 30
```

The following example shows how to configure a normal cache:

```
Device(config)# flow monitor FLOW-MONITOR-1
Device(config-flow-monitor)# cache type normal
```

clear flow exporter

To clear the statistics for a flow exporter, use the **clear flow exporter** command in privileged EXEC mode.

```
clear flow exporter [[name] exporter-name] statistics
```

Syntax Description

name	(Optional) Specifies the name of a flow exporter.
<i>exporter-name</i>	(Optional) Name of a flow exporter that was previously configured.
statistics	Clears the flow exporter statistics.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **clear flow exporter** command removes all statistics from the flow exporter. These statistics will not be exported and the data gathered in the cache will be lost.

You can view the flow exporter statistics by using the **show flow exporter statistics** privileged EXEC command.

Examples

The following example clears the statistics for all of the flow exporters configured on the device:

```
Device# clear flow exporter statistics
```

The following example clears the statistics for the flow exporter named FLOW-EXPORTER-1:

```
Device# clear flow exporter FLOW-EXPORTER-1 statistics
```

clear flow monitor

To clear a flow monitor cache or flow monitor statistics and to force the export of the data in the flow monitor cache, use the **clear flow monitor** command in privileged EXEC mode.

```
clear flow monitor [name] monitor-name [{cache] force-export | statistics}]
```

Syntax Description

name	Specifies the name of a flow monitor.
<i>monitor-name</i>	Name of a flow monitor that was previously configured.
cache	(Optional) Clears the flow monitor cache information.
force-export	(Optional) Forces the export of the flow monitor cache statistics.
statistics	(Optional) Clears the flow monitor statistics.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **clear flow monitor cache** command removes all entries from the flow monitor cache. These entries will not be exported and the data gathered in the cache will be lost.



Note The statistics for the cleared cache entries are maintained.

The **clear flow monitor force-export** command removes all entries from the flow monitor cache and exports them using all flow exporters assigned to the flow monitor. This action can result in a short-term increase in CPU usage. Use this command with caution.

The **clear flow monitor statistics** command clears the statistics for this flow monitor.



Note The current entries statistic will not be cleared by the **clear flow monitor statistics** command because this is an indicator of how many entries are in the cache and the cache is not cleared with this command.

You can view the flow monitor statistics by using the **show flow monitor statistics** privileged EXEC command.

Examples

The following example clears the statistics and cache entries for the flow monitor named FLOW-MONITOR-1:

```
Device# clear flow monitor name FLOW-MONITOR-1
```

The following example clears the statistics and cache entries for the flow monitor named FLOW-MONITOR-1 and forces an export:

```
Device# clear flow monitor name FLOW-MONITOR-1 force-export
```

The following example clears the cache for the flow monitor named FLOW-MONITOR-1 and forces an export:

```
Device# clear flow monitor name FLOW-MONITOR-1 cache force-export
```

The following example clears the statistics for the flow monitor named FLOW-MONITOR-1:

```
Device# clear flow monitor name FLOW-MONITOR-1 statistics
```

collect

To configure non-key fields for the flow monitor record and to enable capturing the values in the fields for the flow created with the record, use the **collect** command in flow record configuration mode.

collect {**counter** | **interface** | **timestamp** | **transport**}

Syntax Description

counter	Configures the number of bytes or packets in a flow as a non-key field for a flow record. For more information, see collect counter, on page 61 .
interface	Configures the input and output interface name as a non-key field for a flow record. For more information, see collect interface, on page 62 .
timestamp	Configures the absolute time of the first seen or last seen packet in a flow as a non-key field for a flow record. For more information, see collect timestamp absolute, on page 63 .
transport	Enables the collecting of transport TCP flags from a flow record. For more information, see collect transport tcp flags, on page 64 .

Command Default

Non-key fields are not configured for the flow monitor record.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The values in non-key fields are added to flows to provide additional information about the traffic in the flows. A change in the value of a non-key field does not create a new flow. In most cases, the values for non-key fields are taken from only the first packet in the flow.

The **collect** commands are used to configure non-key fields for the flow monitor record and to enable capturing the values in the fields for the flow created with the record. The values in non-key fields are added to flows to provide additional information about the traffic in the flows. A change in the value of a non-key field does not create a new flow. In most cases the values for non-key fields are taken from only the first packet in the flow.



Note

Although it is visible in the command-line help string, the **flow username** keyword is not supported.

The following example configures the total number of bytes in the flows as a non-key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# collect counter bytes long
```

collect counter

To configure the number of bytes or packets in a flow as a non-key field for a flow record, use the **collect counter** command in flow record configuration mode. To disable the use of the number of bytes or packets in a flow (counters) as a non-key field for a flow record, use the **no** form of this command.

Command Default The number of bytes or packets in a flow is not configured as a non-key field.

Command Modes Flow record configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines To return this command to its default settings, use the **no collect counter** or **default collect counter** flow record configuration command.

The following example configures the total number of bytes in the flows as a non-key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)#collect counter bytes long
```

The following example configures the total number of packets from the flows as a non-key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# collect counter packets long
```

collect interface

To configure the input interface name as a non-key field for a flow record, use the **collect interface** command in flow record configuration mode. To disable the use of the input interface as a non-key field for a flow record, use the **no** form of this command.

collect interface input
no collect interface input

Syntax Description	input Configures the input interface name as a non-key field and enables collecting the input interface from the flows.
---------------------------	--

Command Default	The input interface name is not configured as a non-key field.
------------------------	--

Command Modes	Flow record configuration
----------------------	---------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	The Flexible NetFlow collect commands are used to configure non-key fields for the flow monitor record and to enable capturing the values in the fields for the flow created with the record. The values in non-key fields are added to flows to provide additional information about the traffic in the flows. A change in the value of a non-key field does not create a new flow. In most cases, the values for non-key fields are taken from only the first packet in the flow.
-------------------------	--

To return this command to its default settings, use the **no collect interface** or **default collect interface** flow record configuration command.

The following example configures the input interface as a non-key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# collect interface input
```

collect timestamp absolute

To configure the absolute time of the first seen or last seen packet in a flow as a non-key field for a flow record, use the **collect timestamp absolute** command in flow record configuration mode. To disable the use of the first seen or last seen packet in a flow as a non-key field for a flow record, use the **no** form of this command.

```
collect timestamp absolute {first | last}
no collect timestamp absolute {first | last}
```

Syntax Description

first Configures the absolute time of the first seen packet in a flow as a non-key field and enables collecting time stamps from the flows.

last Configures the absolute time of the last seen packet in a flow as a non-key field and enables collecting time stamps from the flows.

Command Default

The absolute time field is not configured as a non-key field.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **collect** commands are used to configure non-key fields for the flow monitor record and to enable capturing the values in the fields for the flow created with the record. The values in non-key fields are added to flows to provide additional information about the traffic in the flows. A change in the value of a non-key field does not create a new flow. In most cases the values for non-key fields are taken from only the first packet in the flow.

The following example configures time stamps based on the absolute time of the first seen packet in a flow as a non-key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# collect timestamp absolute first
```

The following example configures time stamps based on the absolute time of the last seen packet in a flow as a non-key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# collect timestamp absolute last
```

collect transport tcp flags

To enable the collecting of transport TCP flags from a flow, use the **collect transport tcp flags** command in flow record configuration mode. To disable the collecting of transport TCP flags from the flow, use the **no** form of this command.

collect transport tcp flags
no collect transport tcp flags

Syntax Description	This command has no arguments or keywords.				
Command Default	The transport layer fields are not configured as a non-key field.				
Command Modes	Flow record configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

Usage Guidelines The values of the transport layer fields are taken from all packets in the flow. You cannot specify which TCP flag to collect. You can only specify to collect transport TCP flags. All TCP flags will be collected with this command. The following transport TCP flags are collected:

- **ack**—TCP acknowledgement flag
- **cwr**—TCP congestion window reduced flag
- **ece**—TCP ECN echo flag
- **fin**—TCP finish flag
- **psh**—TCP push flag
- **rst**—TCP reset flag
- **syn**—TCP synchronize flag
- **urg**—TCP urgent flag

To return this command to its default settings, use the **no collect collect transport tcp flags** or **default collect collect transport tcp flags** flow record configuration command.

The following example collects the TCP flags from a flow:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# collect transport tcp flags
```

datalink flow monitor

To apply a Flexible NetFlow flow monitor to an interface, use the **datalink flow monitor** command in interface configuration mode. To disable a Flexible NetFlow flow monitor, use the **no** form of this command.

datalink flow monitor *monitor-name* **sampler** *sampler-name* **input**
no datalink flow monitor *monitor-name* **sampler** *sampler-name* **input**

Syntax Description		
	<i>monitor-name</i>	Name of the flow monitor to apply to the interface.
	sampler <i>sampler-name</i>	Enables the specified flow sampler for the flow monitor.
	input	Monitors traffic that the switch receives on the interface.

Command Default A flow monitor is not enabled.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Before you apply a flow monitor to an interface with the **datalink flow monitor** command, you must have already created the flow monitor using the **flow monitor** global configuration command and the flow sampler using the **sampler** global configuration command.

To enable a flow sampler for the flow monitor, you must have already created the sampler.



Note The **datalink flow monitor** command only monitors non-IPv4 and non-IPv6 traffic. To monitor IPv4 traffic, use the **ip flow monitor** command. To monitor IPv6 traffic, use the **ipv6 flow monitor** command.

This example shows how to enable Flexible NetFlow datalink monitoring on an interface:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# datalink flow monitor FLOW-MONITOR-1 sampler FLOW-SAMPLER-1 input
```

debug flow exporter

To enable debugging output for flow exporters, use the **debug flow exporter** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

```
debug flow exporter [[name] exporter-name] [{error | event | packets number}]
no debug flow exporter [[name] exporter-name] [{error | event | packets number}]
```

Syntax Description

name	(Optional) Specifies the name of a flow exporter.
<i>exporter-name</i>	(Optional) The name of a flow exporter that was previously configured.
error	(Optional) Enables debugging for flow exporter errors.
event	(Optional) Enables debugging for flow exporter events.
packets	(Optional) Enables packet-level debugging for flow exporters.
<i>number</i>	(Optional) The number of packets to debug for packet-level debugging of flow exporters. The range is 1 to 65535.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

The following example indicates that a flow exporter packet has been queued for process send:

```
Device# debug flow exporter
May 21 21:29:12.603: FLOW EXP: Packet queued for process send
```

debug flow monitor

To enable debugging output for flow monitors, use the **debug flow monitor** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

```
debug flow monitor [{error | [name] monitor-name [{cache [error] | error | packets packets}]}]
no debug flow monitor [{error | [name] monitor-name [{cache [error] | error | packets packets}]}]
```

Syntax Description

error	(Optional) Enables debugging for flow monitor errors for all flow monitors or for the specified flow monitor.
name	(Optional) Specifies the name of a flow monitor.
<i>monitor-name</i>	(Optional) Name of a flow monitor that was previously configured.
cache	(Optional) Enables debugging for the flow monitor cache.
cache error	(Optional) Enables debugging for flow monitor cache errors.
packets	(Optional) Enables packet-level debugging for flow monitors.
<i>packets</i>	(Optional) Number of packets to debug for packet-level debugging of flow monitors. The range is 1 to 65535.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

The following example shows that the cache for FLOW-MONITOR-1 was deleted:

```
Device# debug flow monitor FLOW-MONITOR-1 cache
May 21 21:53:02.839: FLOW MON: 'FLOW-MONITOR-1' deleted cache
```

debug flow record

To enable debugging output for flow records, use the **debug flow record** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

```
debug flow record [{{name}} record-name | options {sampler-table} | [{{detailed | error}}]]
no debug flow record [{{name}} record-name | options {sampler-table} | [{{detailed | error}}]]
```

Syntax Description

name	(Optional) Specifies the name of a flow record.
<i>record-name</i>	(Optional) Name of a user-defined flow record that was previously configured.
options	(Optional) Includes information on other flow record options.
sampler-table	(Optional) Includes information on the sampler tables.
detailed	(Optional) Displays detailed information.
error	(Optional) Displays errors only.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

The following example enables debugging for the flow record:

```
Device# debug flow record FLOW-record-1
```

debug sampler

To enable debugging output for samplers, use the **debug sampler** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

```
debug sampler [{detailed | error | [name] sampler-name [{detailed | error | sampling samples}]}]
no debug sampler [{detailed | error | [name] sampler-name [{detailed | error | sampling}]}]
```

Syntax Description

detailed	(Optional) Enables detailed debugging for sampler elements.
error	(Optional) Enables debugging for sampler errors.
name	(Optional) Specifies the name of a sampler.
<i>sampler-name</i>	(Optional) Name of a sampler that was previously configured.
sampling <i>samples</i>	(Optional) Enables debugging for sampling and specifies the number of samples to debug.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

The following sample output shows that the debug process has obtained the ID for the sampler named SAMPLER-1:

```
Device# debug sampler detailed
*May 28 04:14:30.883: Sampler: Sampler(SAMPLER-1: flow monitor FLOW-MONITOR-1 (ip,Et1/0,O)
  get ID succeeded:1
*May 28 04:14:30.971: Sampler: Sampler(SAMPLER-1: flow monitor FLOW-MONITOR-1 (ip,Et0/0,I)
  get ID succeeded:1
```

description

To configure a description for a flow monitor, flow exporter, or flow record, use the **description** command in the appropriate configuration mode. To remove a description, use the **no** form of this command.

description *description*
no description *description*

Syntax Description *description* Text string that describes the flow monitor, flow exporter, or flow record.

Command Default The default description for a flow sampler, flow monitor, flow exporter, or flow record is "User defined."

Command Modes The following command modes are supported:

Flow exporter configuration

Flow monitor configuration

Flow record configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines To return this command to its default setting, use the **no description** or **default description** command in the appropriate configuration mode.

The following example configures a description for a flow monitor:

```
Device(config)# flow monitor FLOW-MONITOR-1
Device(config-flow-monitor)# description Monitors traffic to 172.16.0.1 255.255.0.0
```

destination

To configure an export destination for a flow exporter, use the **destination** command in flow exporter configuration mode. To remove an export destination for a flow exporter, use the **no** form of this command.

destination *{hostnameip-address}*
no destination *{hostnameip-address}*

Syntax Description

hostname Hostname of the device to which you want to send the NetFlow information.

ip-address IPv4 address of the workstation to which you want to send the NetFlow information.

Command Default

An export destination is not configured.

Command Modes

Flow exporter configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Each flow exporter can have only one destination address or hostname.

When you configure a hostname instead of the IP address for the device, the hostname is resolved immediately and the IPv4 address is stored in the running configuration. If the hostname-to-IP-address mapping that was used for the original Domain Name System (DNS) name resolution changes dynamically on the DNS server, the device does not detect this, and the exported data continues to be sent to the original IP address, resulting in a loss of data.

To return this command to its default setting, use the **no destination** or **default destination** command in flow exporter configuration mode.

The following example shows how to configure the networking device to export the cache entry to a destination system:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# destination 10.0.0.4
```

dscp

To configure a differentiated services code point (DSCP) value for flow exporter datagrams, use the **dscp** command in flow exporter configuration mode. To remove a DSCP value for flow exporter datagrams, use the **no** form of this command.

```
dscp dscp
no dscp dscp
```

Syntax Description	<i>dscp</i> DSCP to be used in the DSCP field in exported datagrams. The range is 0 to 63. The default is 0.
---------------------------	--

Command Default	The differentiated services code point (DSCP) value is 0.
------------------------	---

Command Modes	Flow exporter configuration
----------------------	-----------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	To return this command to its default setting, use the no dscp or default dscp flow exporter configuration command.
-------------------------	---

The following example sets 22 as the value of the DSCP field in exported datagrams:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# dscp 22
```

export-protocol netflow-v9

To configure NetFlow Version 9 export as the export protocol for a Flexible NetFlow exporter, use the **export-protocol netflow-v9** command in flow exporter configuration mode.

export-protocol netflow-v9

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	NetFlow Version 9 is enabled.
------------------------	-------------------------------

Command Modes	Flow exporter configuration
----------------------	-----------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	The device does not support NetFlow v5 export format, only NetFlow v9 export format is supported.
-------------------------	---

The following example configures NetFlow Version 9 export as the export protocol for a NetFlow exporter:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# export-protocol netflow-v9
```

exporter

To add a flow exporter for a flow monitor, use the **exporter** command in the appropriate configuration mode. To remove a flow exporter for a flow monitor, use the **no** form of this command.

exporter *exporter-name*
no exporter *exporter-name*

Syntax Description	<i>exporter-name</i> Name of a flow exporter that was previously configured.
---------------------------	--

Command Default	An exporter is not configured.
------------------------	--------------------------------

Command Modes	Flow monitor configuration
----------------------	----------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	You must have already created a flow exporter by using the flow exporter command before you can apply the flow exporter to a flow monitor with the exporter command.
-------------------------	--

To return this command to its default settings, use the **no exporter** or **default exporter** flow monitor configuration command.

Examples

The following example configures an exporter for a flow monitor:

```
Device(config)# flow monitor FLOW-MONITOR-1
Device(config-flow-monitor)# exporter EXPORTER-1
```

flow exporter

To create a flow exporter, or to modify an existing flow exporter, and enter flow exporter configuration mode, use the **flow exporter** command in global configuration mode. To remove a flow exporter, use the **no** form of this command.

```
flow exporter exporter-name
no flow exporter exporter-name
```

Syntax Description	<i>exporter-name</i> Name of the flow exporter that is being created or modified.
---------------------------	---

Command Default	flow exporters are not present in the configuration.
------------------------	--

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	Flow exporters export the data in the flow monitor cache to a remote system, such as a server running NetFlow collector, for analysis and storage. Flow exporters are created as separate entities in the configuration. Flow exporters are assigned to flow monitors to provide data export capability for the flow monitors. You can create several flow exporters and assign them to one or more flow monitors to provide several export destinations. You can create one flow exporter and apply it to several flow monitors.
-------------------------	---

Examples	The following example creates a flow exporter named FLOW-EXPORTER-1 and enters flow exporter configuration mode:
-----------------	--

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)#
```

flow monitor

To create a flow monitor, or to modify an existing flow monitor, and enter flow monitor configuration mode, use the **flow monitor** command in global configuration mode. To remove a flow monitor, use the **no** form of this command.

flow monitor *monitor-name*
no flow monitor *monitor-name*

Syntax Description	<i>monitor-name</i> Name of the flow monitor that is being created or modified.
---------------------------	---

Command Default	flow monitors are not present in the configuration.
------------------------	---

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	Flow monitors are the component that is applied to interfaces to perform network traffic monitoring. Flow monitors consist of a flow record and a cache. You add the record to the flow monitor after you create the flow monitor. The flow monitor cache is automatically created at the time the flow monitor is applied to the first interface. Flow data is collected from the network traffic during the monitoring process based on the key and nonkey fields in the flow monitor's record and stored in the flow monitor cache.
-------------------------	--

Examples	The following example creates a flow monitor named FLOW-MONITOR-1 and enters flow monitor configuration mode:
-----------------	---

```
Device(config)# flow monitor FLOW-MONITOR-1
Device(config-flow-monitor)#
```

flow record

To create a flow record, or to modify an existing flow record, and enter flow record configuration mode, use the **flow record** command in global configuration mode. To remove a record, use the **no** form of this command.

```
flow record record-name
no flow record record-name
```

Syntax Description	<i>record-name</i> Name of the flow record that is being created or modified.
---------------------------	---

Command Default	A flow record is not configured.
------------------------	----------------------------------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	A flow record defines the keys that uses to identify packets in the flow, as well as other fields of interest that gathers for the flow. You can define a flow record with any combination of keys and fields of interest. The supports a rich set of keys. A flow record also defines the types of counters gathered per flow. You can configure 64-bit packet or byte counters.
-------------------------	---

Examples	The following example creates a flow record named FLOW-RECORD-1, and enters flow record configuration mode:
-----------------	---

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)#
```

ip flow monitor

To enable a Flexible NetFlow flow monitor for IPv4 traffic that the device is receiving, use the **ip flow monitor** command in interface configuration mode. To disable a flow monitor, use the **no** form of this command.

```
ip flow monitor monitor-name [sampler sampler-name] input
no ip flow monitor monitor-name [sampler sampler-name] input
```

Syntax Description	
<i>monitor-name</i>	Name of the flow monitor to apply to the interface.
sampler <i>sampler-name</i>	(Optional) Enables the specified flow sampler for the flow monitor.
input	Monitors IPv4 traffic that the device receives on the interface.

Command Default A flow monitor is not enabled.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Before you can apply a flow monitor to an interface with the **ip flow monitor** command, you must have already created the flow monitor using the **flow monitor** global configuration command.

When you add a sampler to a flow monitor, only packets that are selected by the named sampler will be entered into the cache to form flows. Each use of a sampler causes separate statistics to be stored for that usage.

You cannot add a sampler to a flow monitor after the flow monitor has been enabled on the interface. You must first remove the flow monitor from the interface and then enable the same flow monitor with a sampler.



Note The statistics for each flow must be scaled to give the expected true usage. For example, with a 1 in 100 sampler it is expected that the packet and byte counters will have to be multiplied by 100.

The following example enables a flow monitor for monitoring input traffic:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# ip flow monitor FLOW-MONITOR-1 input
```

The following example enables a flow monitor for monitoring input traffic, with a sampler to limit the input packets that are sampled:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# ip flow monitor FLOW-MONITOR-1 sampler SAMPLER-1 input
```

The following example shows what happens when you try to add a sampler to a flow monitor that has already been enabled on an interface without a sampler:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# ip flow monitor FLOW-MONITOR-1 sampler SAMPLER-2 input
% Flow Monitor: Flow Monitor 'FLOW-MONITOR-1' is already on in full mode and cannot be
enabled with a sampler.
```

The following example shows how to remove a flow monitor from an interface so that it can be enabled with the sampler:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# no ip flow monitor FLOW-MONITOR-1 input
Device(config-if)# ip flow monitor FLOW-MONITOR-1 sampler SAMPLER-2 input
```

ipv6 flow monitor

To enable a flow monitor for IPv6 traffic that the device is receiving, use the **ipv6 flow monitor** command in interface configuration mode. To disable a flow monitor, use the **no** form of this command.

```
ipv6 flow monitor monitor-name [sampler sampler-name] input
no ipv6 flow monitor monitor-name [sampler sampler-name] input
```

Syntax Description	
<i>monitor-name</i>	Name of the flow monitor to apply to the interface.
sampler <i>sampler-name</i>	(Optional) Enables the specified flow sampler for the flow monitor.
input	Monitors IPv6 traffic that the device receives on the interface.

Command Default A flow monitor is not enabled.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Before you can apply a flow monitor to the interface with the **ipv6 flow monitor** command, you must have already created the flow monitor using the **flow monitor** global configuration command.

When you add a sampler to a flow monitor, only packets that are selected by the named sampler will be entered into the cache to form flows. Each use of a sampler causes separate statistics to be stored for that usage.

You cannot add a sampler to a flow monitor after the flow monitor has been enabled on the interface. You must first remove the flow monitor from the interface and then enable the same flow monitor with a sampler.



Note The statistics for each flow must be scaled to give the expected true usage. For example, with a 1 in 100 sampler it is expected that the packet and byte counters will have to be multiplied by 100.

The following example enables a flow monitor for monitoring input traffic:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# ipv6 flow monitor FLOW-MONITOR-1 input
```

The following example enables a flow monitor for monitoring input traffic, with a sampler to limit the input packets that are sampled:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# ipv6 flow monitor FLOW-MONITOR-1 sampler SAMPLER-1 input
```

The following example shows what happens when you try to add a sampler to a flow monitor that has already been enabled on an interface without a sampler:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# ipv6 flow monitor FLOW-MONITOR-1 sampler SAMPLER-2 input
% Flow Monitor: Flow Monitor 'FLOW-MONITOR-1' is already on in full mode and cannot be
enabled with a sampler.
```

The following example shows how to remove a flow monitor from an interface so that it can be enabled with the sampler:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# no ipv6 flow monitor FLOW-MONITOR-1 input
Device(config-if)# ipv6 flow monitor FLOW-MONITOR-1 sampler SAMPLER-2 input
```

match datalink ethertype

To configure the EtherType of the packet as a key field for a flow record, use the **match datalink ethertype** command in flow record configuration mode. To disable the EtherType of the packet as a key field for a flow record, use the **no** form of this command.

match datalink ethertype
no match datalink ethertype

Syntax Description This command has no arguments or keywords.

Command Default The EtherType of the packet is not configured as a key field.

Command Modes Flow record configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

When you configure the EtherType of the packet as a key field for a flow record using the **match datalink ethertype** command, the traffic flow that is created is based on the type of flow monitor that is assigned to the interface:

- When a datalink flow monitor is assigned to an interface using the **datalink flow monitor** interface configuration command, it creates unique flows for different Layer 2 protocols.
- When an IP flow monitor is assigned to an interface using the **ip flow monitor** interface configuration command, it creates unique flows for different IPv4 protocols.
- When an IPv6 flow monitor is assigned to an interface using the **ipv6 flow monitor** interface configuration command, it creates unique flows for different IPv6 protocols.

To return this command to its default settings, use the **no match datalink ethertype** or **default match datalink ethertype** flow record configuration command.

The following example configures the EtherType of the packet as a key field for a flow record:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match datalink ethertype
```

match datalink mac

To configure the use of MAC addresses as a key field for a flow record, use the **match datalink mac** command in flow record configuration mode. To disable the use of MAC addresses as a key field for a flow record, use the **no** form of this command.

```
match datalink mac {destination address input | source address input}
no match datalink mac {destination address input | source address input}
```

Syntax Description		
	destination address	Configures the use of the destination MAC address as a key field.
	input	Specifies the MAC address of input packets.
	source address	Configures the use of the source MAC address as a key field.

Command Default MAC addresses are not configured as a key field.

Command Modes Flow record configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

The **input** keyword is used to specify the observation point that is used by the **match datalink mac** command to create flows based on the unique MAC addresses in the network traffic.



Note When a datalink flow monitor is assigned to an interface or VLAN record, it creates flows only for non-IPv6 or non-IPv4 traffic.

To return this command to its default settings, use the **no match datalink mac** or **default match datalink mac** flow record configuration command.

The following example configures the use of the destination MAC address of packets that are received by the device as a key field for a flow record:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match datalink mac destination address input
```

match datalink vlan

To configure the VLAN ID as a key field for a flow record, use the **match datalink vlan** command in flow record configuration mode. To disable the use of the VLAN ID value as a key field for a flow record, use the **no** form of this command.

```
match datalink vlan input
no match datalink vlan input
```

Syntax Description	input Configures the VLAN ID of traffic being received by the device as a key field.				
Command Default	The VLAN ID is not configured as a key field.				
Command Modes	Flow record configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				
Usage Guidelines	<p>A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the match command.</p> <p>The input keyword is used to specify the observation point that is used by the match datalink vlan command to create flows based on the unique VLAN IDs in the network traffic.</p> <p>The following example configures the VLAN ID of traffic being received by the device as a key field for a flow record:</p> <pre>Device(config)# flow record FLOW-RECORD-1 Device(config-flow-record)# match datalink vlan input</pre>				

match flow cts

To configure CTS source group tag and destination group tag for a flow record, use the **match flow cts** command in flow record configuration mode. To disable the group tag as key field for a flow record, use the **no** form of this command.

```
match flow cts {source | destination} group-tag
no match flow cts {source | destination} group-tag
```

Syntax Description	cts destination group-tag	Configures the CTS destination field group as a key field.
	cts source group-tag	Configures the CTS source field group as a key field.
Command Default	The CTS destination or source field group, flow direction and the flow sampler ID are not configured as key fields.	
Command Modes	Flexible NetFlow flow record configuration (config-flow-record) Policy inline configuration (config-if-policy-inline)	
Command History	Release	Modification
	Cisco IOS XE 3.7.3E	This command was introduced.
	Cisco IOS XE Denali 16.2.1	This command was reintroduced. This command was not supported in Cisco IOS XE Denali 16.1.x
Usage Guidelines	A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the match command.	

The following example configures the source group-tag as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match flow cts source group-tag
```

match flow direction

To configure the flow direction as key fields for a flow record, use the **match flow direction** command in flow record configuration mode. To disable the use of the flow direction as key fields for a flow record, use the **no** form of this command.

match flow direction
no match flow direction

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	The flow direction is not configured as key fields.
------------------------	---

Command Modes	Flow record configuration
----------------------	---------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the match command.
-------------------------	--

The **match flow direction** command captures the direction of the flow as a key field. This feature is most useful when a single flow monitor is configured for input and output flows. It can be used to find and eliminate flows that are being monitored twice, once on input and once on output. This command can help to match up pairs of flows in the exported data when the two flows are flowing in opposite directions.

The following example configures the direction the flow was monitored in as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match flow direction
```

match interface

To configure the input and output interfaces as key fields for a flow record, use the **match interface** command in flow record configuration mode. To disable the use of the input and output interfaces as key fields for a flow record, use the **no** form of this command.

```
match interface {input | output}
no match interface {input | output}
```

Syntax Description

input Configures the input interface as a key field.

output Configures the output interface as a key field.

Command Default

The input and output interfaces are not configured as key fields.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

The following example configures the input interface as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match interface input
```

The following example configures the output interface as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match interface output
```

match ipv4

To configure one or more of the IPv4 fields as a key field for a flow record, use the **match ipv4** command in flow record configuration mode. To disable the use of one or more of the IPv4 fields as a key field for a flow record, use the **no** form of this command.

```
match ipv4 {destination address | protocol | source address | tos | version}
no match ipv4 {destination address | protocol | source address | tos | version}
```

Syntax Description	
destination address	Configures the IPv4 destination address as a key field. For more information see match ipv4 destination address, on page 89 .
protocol	Configures the IPv4 protocol as a key field.
source address	Configures the IPv4 destination address as a key field. For more information see match ipv4 source address, on page 90 .
tos	Configures the IPv4 ToS as a key field.
version	Configures the IP version from IPv4 header as a key field.

Command Default The use of one or more of the IPv4 fields as a key field for a user-defined flow record is not enabled.

Command Modes Flow record configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

The following example configures the IPv4 protocol as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match ipv4 protocol
```

match ipv4 destination address

To configure the IPv4 destination address as a key field for a flow record, use the **match ipv4 destination address** command in flow record configuration mode. To disable the IPv4 destination address as a key field for a flow record, use the **no** form of this command.

match ipv4 destination address
no match ipv4 destination address

Syntax Description This command has no arguments or keywords.

Command Default The IPv4 destination address is not configured as a key field.

Command Modes Flow record configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

To return this command to its default settings, use the **no match ipv4 destination address** or **default match ipv4 destination address** flow record configuration command.

The following example configures the IPv4 destination address as a key field for a flow record:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match ipv4 destination address
```

match ipv4 source address

To configure the IPv4 source address as a key field for a flow record, use the **match ipv4 source address** command in flow record configuration mode. To disable the use of the IPv4 source address as a key field for a flow record, use the **no** form of this command.

match ipv4 source address
no match ipv4 source address

Syntax Description	This command has no arguments or keywords.	
Command Default	The IPv4 source address is not configured as a key field.	
Command Modes	Flow record configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

To return this command to its default settings, use the **no match ipv4 source address** or **default match ipv4 source address** flow record configuration command.

The following example configures the IPv4 source address as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match ipv4 source address
```

match ipv4 ttl

To configure the IPv4 time-to-live (TTL) field as a key field for a flow record, use the **match ipv4 ttl** command in flow record configuration mode. To disable the use of the IPv4 TTL field as a key field for a flow record, use the **no** form of this command.

match ipv4 ttl
no match ipv4 ttl

Syntax Description

This command has no arguments or keywords.

Command Default

The IPv4 time-to-live (TTL) field is not configured as a key field.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match ipv4 ttl** command.

The following example configures IPv4 TTL as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match ipv4 ttl
```

match ipv6

To configure one or more of the IPv6 fields as a key field for a flow record, use the **match ipv6** command in flow record configuration mode. To disable the use of one or more of the IPv6 fields as a key field for a flow record, use the **no** form of this command.

```
match ipv6 {destination address | protocol | source address | traffic-class | version}
no match ipv6 {destination address | protocol | source address | traffic-class | version}
```

Syntax Description	destination address	Configures the IPv4 destination address as a key field. For more information see match ipv6 destination address, on page 93 .
	protocol	Configures the IPv6 protocol as a key field.
	source address	Configures the IPv4 destination address as a key field. For more information see match ipv6 source address, on page 95 .
Command Default	The IPv6 fields are not configured as a key field.	
Command Modes	Flow record configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the match command.	

The following example configures the IPv6 protocol field as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match ipv6 protocol
```

match ipv6 destination address

To configure the IPv6 destination address as a key field for a flow record, use the **match ipv6 destination address** command in flow record configuration mode. To disable the IPv6 destination address as a key field for a flow record, use the **no** form of this command.

```
match ipv6 destination address
no match ipv6 destination address
```

Syntax Description This command has no arguments or keywords.

Command Default The IPv6 destination address is not configured as a key field.

Command Modes Flow record configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

To return this command to its default settings, use the **no match ipv6 destination address** or **default match ipv6 destination address** flow record configuration command.

The following example configures the IPv6 destination address as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match ipv6 destination address
```

match ipv6 hop-limit

To configure the IPv6 hop limit as a key field for a flow record, use the **match ipv6 hop-limit** command in flow record configuration mode. To disable the use of a section of an IPv6 packet as a key field for a flow record, use the **no** form of this command.

match ipv6 hop-limit
no match ipv6 hop-limit

Syntax Description	This command has no arguments or keywords.	
Command Default	The use of the IPv6 hop limit as a key field for a user-defined flow record is not enabled by default.	
Command Modes	Flow record configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

The following example configures the hop limit of the packets in the flow as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match ipv6 hop-limit
```

match ipv6 source address

To configure the IPv6 source address as a key field for a flow record, use the **match ipv6 source address** command in flow record configuration mode. To disable the use of the IPv6 source address as a key field for a flow record, use the **no** form of this command.

match ipv6 source address
no match ipv6 source address

Syntax Description	This command has no arguments or keywords.	
Command Default	The IPv6 source address is not configured as a key field.	
Command Modes	Flow record configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

To return this command to its default settings, use the **no match ipv6 source address** or **default match ipv6 source address** flow record configuration command.

The following example configures a IPv6 source address as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match ipv6 source address
```

match transport

To configure one or more of the transport fields as a key field for a flow record, use the **match transport** command in flow record configuration mode. To disable the use of one or more of the transport fields as a key field for a flow record, use the **no** form of this command.

Syntax Description

destination-port Configures the transport destination port as a key field.

source-port Configures the transport source port as a key field.

Command Default

The transport fields are not configured as a key field.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

The following example configures the destination port as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match transport destination-port
```

The following example configures the source port as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match transport source-port
```

match transport icmp ipv4

To configure the ICMP IPv4 type field and the code field as key fields for a flow record, use the **match transport icmp ipv4** command in flow record configuration mode. To disable the use of the ICMP IPv4 type field and code field as key fields for a flow record, use the **no** form of this command.

```
match transport icmp ipv4 {code | type}
no match transport icmp ipv4 {code | type}
```

Syntax Description

code Configures the IPv4 ICMP code as a key field.

type Configures the IPv4 ICMP type as a key field.

Command Default

The ICMP IPv4 type field and the code field are not configured as key fields.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

The following example configures the IPv4 ICMP code field as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match transport icmp ipv4 code
```

The following example configures the IPv4 ICMP type field as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match transport icmp ipv4 type
```

match transport icmp ipv6

To configure the ICMP IPv6 type field and the code field as key fields for a flow record, use the **match transport icmp ipv6** command in flow record configuration mode. To disable the use of the ICMP IPv6 type field and code field as key fields for a flow record, use the **no** form of this command.

```
match transport icmp ipv6 {code | type}
no match transport icmp ipv6 {code | type}
```

Syntax Description

code Configures the IPv6 ICMP code as a key field.

type Configures the IPv6 ICMP type as a key field.

Command Default

The ICMP IPv6 type field and the code field are not configured as key fields.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

The following example configures the IPv6 ICMP code field as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match transport icmp ipv6 code
```

The following example configures the IPv6 ICMP type field as a key field:

```
Device(config)# flow record FLOW-RECORD-1
Device(config-flow-record)# match transport icmp ipv6 type
```

mode random 1 out-of

To enable random sampling and to specify the packet interval for a sampler, use the **mode random 1 out-of** command in sampler configuration mode. To remove the packet interval information for a sampler, use the **no** form of this command.

```
mode random 1 out-of window-size
no mode
```

Syntax Description	<i>window-size</i> Specifies the window size from which to select packets. The range is 2 to 1024.
---------------------------	--

Command Default	The mode and the packet interval for a sampler are not configured.
------------------------	--

Command Modes	Sampler configuration
----------------------	-----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	A total of four unique samplers are supported on the . Packets are chosen in a manner that should eliminate any bias from traffic patterns and counter any attempt by users to avoid monitoring.
-------------------------	--



Note	The deterministic keyword is not supported, even though it is visible in the command-line help string.
-------------	---

Examples

The following example enables random sampling with a window size of 1000:

```
Device(config)# sampler SAMPLER-1
Device(config-sampler)# mode random 1 out-of 1000
```

option

To configure optional data parameters for a flow exporter for , use the **option** command in flow exporter configuration mode. To remove optional data parameters for a flow exporter, use the **no** form of this command.

option {**exporter-stats** | **interface-table** | **sampler-table**} [{**timeout** *seconds*}]
no option {**exporter-stats** | **interface-table** | **sampler-table**}

Syntax Description		
	exporter-stats	Configures the exporter statistics option for flow exporters.
	interface-table	Configures the interface table option for flow exporters.
	sampler-table	Configures the export sampler table option for flow exporters.
	timeout <i>seconds</i>	(Optional) Configures the option resend time in seconds for flow exporters. The range is 1 to 86400. The default is 600.

Command Default The timeout is 600 seconds. All other optional data parameters are not configured.

Command Modes Flow exporter configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The **option exporter-stats** command causes the periodic sending of the exporter statistics, including the number of records, bytes, and packets sent. This command allows the collector to estimate packet loss for the export records it receives. The optional timeout alters the frequency at which the reports are sent.

The **option interface-table** command causes the periodic sending of an options table, which allows the collector to map the interface SNMP indexes provided in the flow records to interface names. The optional timeout can alter the frequency at which the reports are sent.

The **option sampler-table** command causes the periodic sending of an options table, which details the configuration of each sampler and allows the collector to map the sampler ID provided in any flow record to a configuration that it can use to scale up the flow statistics. The optional timeout can alter the frequency at which the reports are sent.

To return this command to its default settings, use the **no option** or **default option** flow exporter configuration command.

The following example shows how to enable the periodic sending of the sampler option table, which allows the collector to map the sampler ID to the sampler type and rate:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# option sampler-table
```

The following example shows how to enable the periodic sending of the exporter statistics, including the number of records, bytes, and packets sent:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# option exporter-stats
```

The following example shows how to enable the periodic sending of an options table, which allows the collector to map the interface SNMP indexes provided in the flow records to interface names:

```
Device(config)# flow exporter FLOW-EXPORTER-1  
Device(config-flow-exporter)# option interface-table
```

record

To add a flow record for a flow monitor, use the **record** command in flow monitor configuration mode. To remove a flow record for a flow monitor, use the **no** form of this command.

record *record-name*
no record

Syntax Description

record-name Name of a user-defined flow record that was previously configured.

Command Default

A flow record is not configured.

Command Modes

Flow monitor configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Each flow monitor requires a record to define the contents and layout of its cache entries. The flow monitor can use one of the wide range of predefined record formats, or advanced users may create their own record formats.



Note

You must use the **no ip flow monitor** command to remove a flow monitor from all of the interfaces to which you have applied it before you can modify the parameters for the **record** command for the flow monitor.

Examples

The following example configures the flow monitor to use FLOW-RECORD-1:

```
Device(config)# flow monitor FLOW-MONITOR-1
Device(config-flow-monitor)# record FLOW-RECORD-1
```

sampler

To create a flow sampler, or to modify an existing flow sampler, and to enter sampler configuration mode, use the **sampler** command in global configuration mode. To remove a sampler, use the **no** form of this command.

```
sampler sampler-name
no sampler sampler-name
```

Syntax Description	<i>sampler-name</i> Name of the flow sampler that is being created or modified.
---------------------------	---

Command Default	flow samplers are not configured.
------------------------	-----------------------------------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	Flow samplers are used to reduce the load placed by on the networking device to monitor traffic by limiting the number of packets that are analyzed. You configure a rate of sampling that is 1 out of a range of packets. Flow samplers are applied to interfaces in conjunction with a flow monitor to implement sampled .
-------------------------	--

To enable flow sampling, you configure the record that you want to use for traffic analysis and assign it to a flow monitor. When you apply a flow monitor with a sampler to an interface, the sampled packets are analyzed at the rate specified by the sampler and compared with the flow record associated with the flow monitor. If the analyzed packets meet the criteria specified by the flow record, they are added to the flow monitor cache.

Examples

The following example creates a flow sampler name SAMPLER-1:

```
Device(config)# sampler SAMPLER-1
Device(config-sampler)#
```

show flow exporter

To display flow exporter status and statistics, use the **show flow exporter** command in privileged EXEC mode.

```
show flow exporter [{export-ids netflow-v9 | [name] exporter-name [{statistics | templates}]}] statistics | templates}]
```

Syntax Description

export-ids netflow-v9	(Optional) Displays the NetFlow Version 9 export fields that can be exported and their IDs.
name	(Optional) Specifies the name of a flow exporter.
<i>exporter-name</i>	(Optional) Name of a flow exporter that was previously configured.
statistics	(Optional) Displays statistics for all flow exporters or for the specified flow exporter.
templates	(Optional) Displays template information for all flow exporters or for the specified flow exporter.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

The following example displays the status and statistics for all of the flow exporters configured on a device:

```
Device# show flow exporter
Flow Exporter FLOW-EXPORTER-1:
  Description:                Exports to the datacenter
  Export protocol:            NetFlow Version 9
  Transport Configuration:
    Destination IP address:    192.168.0.1
    Source IP address:        192.168.0.2
    Transport Protocol:        UDP
    Destination Port:          9995
    Source Port:               55864
    DSCP:                      0x0
    TTL:                       255
    Output Features:           Used
```

This table describes the significant fields shown in the display:

Table 6: show flow exporter Field Descriptions

Field	Description
Flow Exporter	The name of the flow exporter that you configured.

Field	Description
Description	The description that you configured for the exporter, or the default description User defined.
Transport Configuration	The transport configuration fields for this exporter.
Destination IP address	The IP address of the destination host.
Source IP address	The source IP address used by the exported packets.
Transport Protocol	The transport layer protocol used by the exported packets.
Destination Port	The destination UDP port to which the exported packets are sent.
Source Port	The source UDP port from which the exported packets are sent.
DSCP	The differentiated services code point (DSCP) value.
TTL	The time-to-live value.
Output Features	Specifies whether the output-features command, which causes the output features to be run on Flexible NetFlow export packets, has been used or not.

The following example displays the status and statistics for all of the flow exporters configured on a device:

```
Device# show flow exporter name FLOW-EXPORTER-1 statistics
Flow Exporter FLOW-EXPORTER-1:
  Packet send statistics (last cleared 2w6d ago):
    Successfully sent:          0                (0 bytes)
```

show flow interface

To display the configuration and status for an interface, use the **show flow interface** command in privileged EXEC mode.

show flow interface [*type number*]

Syntax Description

type (Optional) The type of interface on which you want to display accounting configuration information.

number (Optional) The number of the interface on which you want to display accounting configuration information.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

The following example displays the accounting configuration on Ethernet interfaces 0/0 and 0/1:

```
Device# show flow interface gigabitethernet1/0/1

Interface Ethernet1/0
  monitor:          FLOW-MONITOR-1
  direction:       Output
  traffic(ip):      on
Device# show flow interface gigabitethernet1/0/2
Interface Ethernet0/0
  monitor:          FLOW-MONITOR-1
  direction:       Input
  traffic(ip):      sampler SAMPLER-2#
```

The table below describes the significant fields shown in the display.

Table 7: show flow interface Field Descriptions

Field	Description
Interface	The interface to which the information applies.
monitor	The name of the flow monitor that is configured on the interface.
direction:	The direction of traffic that is being monitored by the flow monitor. The possible values are: <ul style="list-style-type: none"> • Input—Traffic is being received by the interface. • Output—Traffic is being transmitted by the interface.

Field	Description
traffic(ip)	<p>Indicates if the flow monitor is in normal mode or sampler mode.</p> <p>The possible values are:</p> <ul style="list-style-type: none">• on—The flow monitor is in normal mode.• sampler—The flow monitor is in sampler mode (the name of the sampler will be included in the display).

show flow monitor

To display the status and statistics for a flow monitor, use the **show flow monitor** command in privileged EXEC mode.

Syntax Description	name	(Optional) Specifies the name of a flow monitor.
	<i>monitor-name</i>	(Optional) Name of a flow monitor that was previously configured.
	cache	(Optional) Displays the contents of the cache for the flow monitor.
	format	(Optional) Specifies the use of one of the format options for formatting the display output.
	csv	(Optional) Displays the flow monitor cache contents in comma-separated variables (CSV) format.
	record	(Optional) Displays the flow monitor cache contents in record format.
	table	(Optional) Displays the flow monitor cache contents in table format.
	statistics	(Optional) Displays the statistics for the flow monitor.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The **cache** keyword uses the record format by default.

The uppercase field names in the display output of the **show flowmonitor monitor-name cache** command are key fields that uses to differentiate flows. The lowercase field names in the display output of the **show flow monitor monitor-name cache** command are nonkey fields from which collects values as additional data for the cache.

Examples

The following example displays the status for a flow monitor:

```
Device# show flow monitor FLOW-MONITOR-1

Flow Monitor FLOW-MONITOR-1:
  Description:      Used for basic traffic analysis
  Flow Record:     flow-record-1
  Flow Exporter:   flow-exporter-1
                  flow-exporter-2

Cache:
  Type:            normal
  Status:          allocated
  Size:            4096 entries / 311316 bytes
  Inactive Timeout: 15 secs
  Active Timeout:  1800 secs
```

This table describes the significant fields shown in the display.

Table 8: show flow monitor monitor-name Field Descriptions

Field	Description
Flow Monitor	Name of the flow monitor that you configured.
Description	Description that you configured or the monitor, or the default description User defined.
Flow Record	Flow record assigned to the flow monitor.
Flow Exporter	Exporters that are assigned to the flow monitor.
Cache	Information about the cache for the flow monitor.
Type	Flow monitor cache type. The value is always normal, as it is the only supported cache type.
Status	Status of the flow monitor cache. The possible values are: <ul style="list-style-type: none"> • allocated—The cache is allocated. • being deleted—The cache is being deleted. • not allocated—The cache is not allocated.
Size	Current cache size.
Inactive Timeout	Current value for the inactive timeout in seconds.
Active Timeout	Current value for the active timeout in seconds.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1:

This table describes the significant fields shown in the display.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1 in a table format:

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-IPv6 (the cache contains IPv6 data) in record format:

The following example displays the status and statistics for a flow monitor:

show flow record

To display the status and statistics for a flow record, use the **show flow record** command in privileged EXEC mode.

```
show flow record [{name] record-name}]
```

Syntax Description	name (Optional) Specifies the name of a flow record.
	<i>record-name</i> (Optional) Name of a user-defined flow record that was previously configured.
Command Default	None
Command Modes	Privileged EXEC
Command History	Release
	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE This command was introduced.

The following example displays the status and statistics for FLOW-RECORD-1:

```
Device# show flow record FLOW-RECORD-1
flow record FLOW-RECORD-1:
  Description:      User defined
  No. of users:    0
  Total field space: 24 bytes
  Fields:
    match ipv6 destination address
    match transport source-port
    collect interface input
```

show sampler

To display the status and statistics for a sampler, use the **show sampler** command in privileged EXEC mode.

```
show sampler [{[name] sampler-name}]
```

Syntax Description	name (Optional) Specifies the name of a sampler.				
	sampler-name (Optional) Name of a sampler that was previously configured.				
Command Default	None				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

The following example displays the status and statistics for all of the flow samplers configured:

```
Device# show sampler
Sampler SAMPLER-1:
  ID:                2083940135
  export ID:         0
  Description:       User defined
  Type:              Invalid (not in use)
  Rate:              1 out of 32
  Samples:           0
  Requests:          0
  Users (0):
  Users (0):

Sampler SAMPLER-2:
  ID:                3800923489
  export ID:         1
  Description:       User defined
  Type:              random
  Rate:              1 out of 100
  Samples:           1
  Requests:          124
  Users (1):
  Users (1):
    flow monitor FLOW-MONITOR-1 (datalink,vlan1) 0 out of 0
```

This table describes the significant fields shown in the display.

Table 9: show sampler Field Descriptions

Field	Description
ID	ID number of the flow sampler.
Export ID	ID of the flow sampler export.
Description	Description that you configured for the flow sampler, or the default description User defined.

Field	Description
Type	Sampling mode that you configured for the flow sampler.
Rate	Window size (for packet selection) that you configured for the flow sampler. The range is 2 to 32768.
Samples	Number of packets sampled since the flow sampler was configured or the device was restarted. This is equivalent to the number of times a positive response was received when the sampler was queried to determine if the traffic needed to be sampled. See the explanation of the Requests field in this table.
Requests	Number of times the flow sampler was queried to determine if the traffic needed to be sampled.
Users	Interfaces on which the flow sampler is configured.

source

To configure the source IP address interface for all of the packets sent by a flow exporter, use the **source** command in flow exporter configuration mode. To remove the source IP address interface for all of the packets sent by a flow exporter, use the **no** form of this command.

```
source interface-type interface-number
no source
```

Syntax Description	<i>interface-type</i> Type of interface whose IP address you want to use for the source IP address of the packets sent by a flow exporter.				
	<i>interface-number</i> Interface number whose IP address you want to use for the source IP address of the packets sent by a flow exporter.				
Command Default	The IP address of the interface over which the datagram is transmitted is used as the source IP address.				
Command Modes	Flow exporter configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

Usage Guidelines	<p>The benefits of using a consistent IP source address for the datagrams that sends include the following:</p> <ul style="list-style-type: none"> • The source IP address of the datagrams exported by is used by the destination system to determine from which device the data is arriving. If your network has two or more paths that can be used to send datagrams from the device to the destination system and you do not specify the source interface from which the source IP address is to be obtained, the device uses the IP address of the interface over which the datagram is transmitted as the source IP address of the datagram. In this situation the destination system might receive datagrams from the same device, but with different source IP addresses. When the destination system receives datagrams from the same device with different source IP addresses, the destination system treats the datagrams as if they were being sent from different devices. To avoid having the destination system treat the datagrams as if they were being sent from different devices, you must configure the destination system to aggregate the datagrams it receives from all of the possible source IP addresses in the device into a single flow. • If your device has multiple interfaces that can be used to transmit datagrams to the destination system, and you do not configure the source command, you will have to add an entry for the IP address of each interface into any access lists that you create for permitting traffic. Creating and maintaining access lists for permitting traffic from known sources and blocking it from unknown sources is easier when you limit the source IP address for datagrams to a single IP address for each device that is exporting traffic.
-------------------------	--



Caution The interface that you configure as the **source** interface must have an IP address configured, and it must be up.



Tip When a transient outage occurs on the interface that you configured with the **source** command, the exporter reverts to the default behavior of using the IP address of the interface over which the datagrams are being transmitted as the source IP address for the datagrams. To avoid this problem, use a loopback interface as the source interface because loopback interfaces are not subject to the transient outages that can occur on physical interfaces.

To return this command to its default settings, use the **no source** or **default source** flow exporter configuration command.

Examples

The following example shows how to configure to use a loopback interface as the source interface for NetFlow traffic:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# source loopback 0
```

template data timeout

To specify a timeout period for resending flow exporter template data, use the **template data timeout** command in flow exporter configuration mode. To remove the template resend timeout for a flow exporter, use the **no** form of this command.

template data timeout *seconds*
no template data timeout *seconds*

Syntax Description	<i>seconds</i> Timeout value in seconds. The range is 1 to 86400. The default is 600.
---------------------------	---

Command Default	The default template resend timeout for a flow exporter is 600 seconds.
------------------------	---

Command Modes	Flow exporter configuration
----------------------	-----------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	Flow exporter template data describes the exported data records. Data records cannot be decoded without the corresponding template. The template data timeout command controls how often those templates are exported.
-------------------------	---

To return this command to its default settings, use the **no template data timeout** or **default template data timeout** flow record exporter command.

The following example configures resending templates based on a timeout of 1000 seconds:

```
Device(config)# flow exporter FLOW-EXPORTER-1
Device(config-flow-exporter)# template data timeout 1000
```

transport

To configure the transport protocol for a flow exporter for , use the **transport** command in flow exporter configuration mode. To remove the transport protocol for a flow exporter, use the **no** form of this command.

```
transport udp udp-port
no transport udp udp-port
```

Syntax Description	udp <i>udp-port</i> Specifies User Datagram Protocol (UDP) as the transport protocol and the UDP port number.				
Command Default	Flow exporters use UDP on port 9995.				
Command Modes	Flow exporter configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				
Usage Guidelines	<p>To return this command to its default settings, use the no transport or default transport flow exporter configuration command.</p> <p>The following example configures UDP as the transport protocol and a UDP port number of 250:</p> <pre>Device(config)# flow exporter FLOW-EXPORTER-1 Device(config-flow-exporter)# transport udp 250</pre>				

ttl

To configure the time-to-live (TTL) value, use the **ttl** command in flow exporter configuration mode. To remove the TTL value, use the **no** form of this command.

```
ttl ttl
no ttl ttl
```

Syntax Description	<i>ttl</i> Time-to-live (TTL) value for exported datagrams. The range is 1 to 255. The default is 255.				
Command Default	Flow exporters use a TTL of 255.				
Command Modes	Flow exporter configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				
Usage Guidelines	<p>To return this command to its default settings, use the no ttl or default ttl flow exporter configuration command.</p> <p>The following example specifies a TTL of 15:</p> <pre>Device(config)# flow exporter FLOW-EXPORTER-1 Device(config-flow-exporter)# ttl 15</pre>				



PART **III**

Interface and Hardware Components

- [Interface and Hardware Commands, on page 121](#)



Interface and Hardware Commands

- [client vlan](#), on page 123
- [debug ilpower](#), on page 124
- [debug interface](#), on page 125
- [debug lldp packets](#), on page 126
- [debug nmsp](#), on page 127
- [debug platform poe](#), on page 128
- [duplex](#), on page 129
- [errdisable detect cause](#), on page 131
- [errdisable recovery cause](#), on page 133
- [errdisable recovery interval](#), on page 135
- [interface](#), on page 136
- [interface range](#), on page 138
- [ip mtu](#), on page 139
- [ipv6 mtu](#), on page 140
- [lldp \(interface configuration\)](#), on page 141
- [logging event power-inline-status](#), on page 142
- [mdix auto](#), on page 143
- [mode \(power-stack configuration\)](#), on page 144
- [monitoring](#), on page 146
- [network-policy](#), on page 148
- [network-policy profile \(global configuration\)](#), on page 149
- [nmsp attachment suppress](#), on page 150
- [power efficient-ethernet auto](#), on page 151
- [power-priority](#), on page 152
- [power inline](#), on page 154
- [power inline police](#), on page 157
- [power supply](#), on page 159
- [show CAPWAP summary](#), on page 161
- [show controllers cpu-interface](#), on page 162
- [show controllers ethernet-controller](#), on page 164
- [show controllers utilization](#), on page 173
- [show eee](#), on page 175
- [show env](#), on page 178

- show errdisable detect, on page 181
- show errdisable recovery, on page 182
- show interfaces, on page 183
- show interfaces counters, on page 187
- show interfaces switchport, on page 189
- show interfaces transceiver, on page 191
- show memory platform, on page 194
- show module, on page 197
- show mgmt-infra trace messages ilpower, on page 198
- show mgmt-infra trace messages ilpower-ha, on page 200
- show mgmt-infra trace messages platform-mgr-poe, on page 201
- show network-policy profile, on page 202
- show platform CAPWAP summary, on page 203
- show platform forward, on page 204
- show platform hardware fed switch forward, on page 206
- show platform resources, on page 208
- show platform software ilpower, on page 209
- show platform software process list, on page 211
- show platform software process slot switch, on page 214
- show platform software status control-processor, on page 216
- show processes cpu platform monitor, on page 219
- show processes memory platform, on page 221
- show power inline, on page 224
- show stack-power , on page 229
- show stack-power , on page 231
- show system mtu, on page 232
- show tech-support , on page 233
- show wireless interface summary, on page 235
- speed, on page 236
- stack-power , on page 238
- switchport block, on page 240
- system mtu, on page 241
- test mcu read-register, on page 242
- transceiver type all, on page 244
- voice-signaling vlan (network-policy configuration), on page 245
- voice vlan (network-policy configuration), on page 247
- wireless ap-manager interface, on page 249
- wireless exclusionlist, on page 250
- wireless linktest, on page 251
- wireless management interface, on page 252
- wireless peer-blocking forward-upstream, on page 253

client vlan

To configure a WLAN interface or an interface group, use the **client vlan** command. To disable the WLAN interface, use the **no** form of this command.

```
client vlan interface-id-name-or-group-name
no client vlan
```

Syntax Description	<i>interface-id-name-or-group-name</i> Interface ID, name, or VLAN group name. The interface ID can also be in digits too.				
Command Default	The default interface is configured.				
Command Modes	WLAN configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				
Usage Guidelines	You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.				

This example shows how to enable a client VLAN on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# client vlan client-vlan1
Device(config-wlan)# end
```

This example shows how to disable a client VLAN on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no client vlan
Device(config-wlan)# end
```

Related Topics

[wlan](#), on page 1402

debug ilpower

To enable debugging of the power controller and Power over Ethernet (PoE) system, use the **debug ilpower** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug ilpower {**cdp** | **controller** | **event** | **ha** | **ipc** | **police** | **port** | **powerman** | **registries** | **scp** | **sense**}
no debug ilpower {**cdp** | **controller** | **event** | **ha** | **ipc** | **police** | **port** | **powerman** | **registries** | **scp** | **sense**}

Syntax Description

cdp	Displays PoE Cisco Discovery Protocol (CDP) debug messages.
controller	Displays PoE controller debug messages.
event	Displays PoE event debug messages.
ha	Displays PoE high-availability messages.
ipc	Displays PoE Inter-Process Communication (IPC) debug messages.
police	Displays PoE police debug messages.
port	Displays PoE port manager debug messages.
powerman	Displays PoE power management debug messages.
registries	Displays PoE registries debug messages.
scp	Displays PoE SCP debug messages.
sense	Displays PoE sense debug messages.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

This command is supported only on PoE-capable switches.

When you enable debugging on a switch stack, it is enabled only on the stack master. To enable debugging on a stack member, you can start a session from the stack master by using the **session** *switch-number* EXEC command. Then enter the **debug** command at the command-line prompt of the stack member. You also can use the **remote command** *stack-member-number* *LINE* EXEC command on the stack master switch to enable debugging on a member switch without first starting a session.

debug interface

To enable debugging of interface-related activities, use the **debug interface** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug interface {interface-id | counters {exceptions | protocol memory} | null interface-number |
port-channel port-channel-number | states | vlan vlan-id}
no debug interface {interface-id | counters {exceptions | protocol memory} | null interface-number |
port-channel port-channel-number | states | vlan vlan-id}
```

Syntax Description

<i>interface-id</i>	ID of the physical interface. Displays debug messages for the specified physical port, identified by type switch number/module number/port, for example, gigabitethernet 1/0/2.
null <i>interface-number</i>	Displays debug messages for null interfaces. The interface number is always 0 .
port-channel <i>port-channel-number</i>	Displays debug messages for the specified EtherChannel port-channel interface. The <i>port-channel-number</i> range is 1 to 48.
vlan <i>vlan-id</i>	Displays debug messages for the specified VLAN. The vlan range is 1 to 4094.
counters	Displays counters debugging information.
exceptions	Displays debug messages when a recoverable exceptional condition occurs during the computation of the interface packet and data rate statistics.
protocol memory	Displays debug messages for memory operations of protocol counters.
states	Displays intermediary debug messages when an interface's state transitions.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

If you do not specify a keyword, all debug messages appear.

The **undebug interface** command is the same as the **no debug interface** command.

When you enable debugging on a switch stack, it is enabled only on the stack master. To enable debugging on a stack member, you can start a session from the stack master by using the **session** *switch-number* EXEC command. Then enter the **debug** command at the command-line prompt of the stack member. You also can use the **remote command** *stack-member-number* *LINE* EXEC command on the stack master switch to enable debugging on a member switch without first starting a session.

debug lldp packets

To enable debugging of Link Layer Discovery Protocol (LLDP) packets, use the **debug lldp packets** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug lldp packets
no debug lldp packets

Syntax Description This command has no arguments or keywords.

Command Default Debugging is disabled.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The **undebug lldp packets** command is the same as the **no debug lldp packets** command. When you enable debugging on a switch stack, it is enabled only on the active switch. To enable debugging on a stack member, you can start a session from the active switch by using the **session switch-number EXEC** command.

debug nmosp

To enable debugging of the Network Mobility Services Protocol (NMSP) on the switch, use the **debug nmosp** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

Syntax Description	all	Displays all NMSP debug messages.
	connection	Displays debug messages for NMSP connection events.
	error	Displays debugging information for NMSP error messages.
	event	Displays debug messages for NMSP events.
	rx	Displays debugging information for NMSP receive messages.
	tx	Displays debugging information for NMSP transmit messages.
	packet	Displays debug messages for NMSP packet events.

Command Default Debugging is disabled.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines



Note Attachment information is not supported in Cisco IOS XE Denali 16.1.1 and later releases.

The **undebug nmosp** command is the same as the **no debug nmosp** command.

When you enable debugging on a switch stack, it is enabled only on the stack master. To enable debugging on a stack member, you can start a session from the stack master by using the **session switch-number** EXEC command. Then enter the **debug** command at the command-line prompt of the stack member. You also can use the **remote command stack-member-number LINE** EXEC command on the stack master switch to enable debugging on a member switch without first starting a session.

debug platform poe

To enable debugging of a Power over Ethernet (PoE) port, use the **debug platform poe** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug platform poe [{error | info}] [switch switch-number]
no debug platform poe [{error | info}] [switch switch-number]
```

Syntax Description

error	(Optional) Displays PoE-related error debug messages.
info	(Optional) Displays PoE-related information debug messages.
switch <i>switch-number</i>	(Optional) Specifies the stack member. This keyword is supported only on stacking-capable switches.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **undebug platform poe** command is the same as the **no debug platform poe** command.

duplex

To specify the duplex mode of operation for a port, use the **duplex** command in interface configuration mode. To return to the default value, use the **no** form of this command.

duplex {**auto** | **full** | **half**}
no duplex {**auto** | **full** | **half**}

Syntax Description

auto Enables automatic duplex configuration. The port automatically detects whether it should run in full- or half-duplex mode, depending on the attached device mode.

full Enables full-duplex mode.

half Enables half-duplex mode (only for interfaces operating at 10 or 100 Mb/s). You cannot configure half-duplex mode for interfaces operating at 1000 or 10,000 Mb/s.

Command Default

The default is **auto** for Gigabit Ethernet ports.

You cannot configure the duplex mode on 10-Gigabit Ethernet ports; it is always **full**.

Duplex options are not supported on the 1000BASE-*x* or 10GBASE-*x* (where *x* is -BX, -CWDM, -LX, -SX, or -ZX) small form-factor pluggable (SFP) modules.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

For Gigabit Ethernet ports, setting the port to **auto** has the same effect as specifying **full** if the attached device does not autonegotiate the duplex parameter.



Note Half-duplex mode is supported on Gigabit Ethernet interfaces if the duplex mode is **auto** and the connected device is operating at half duplex. However, you cannot configure these interfaces to operate in half-duplex mode.

Certain ports can be configured to be either full duplex or half duplex. How this command is applied depends on the device to which the switch is attached.

If both ends of the line support autonegotiation, we highly recommend using the default autonegotiation settings. If one interface supports autonegotiation and the other end does not, configure duplex and speed on both interfaces, and use the **auto** setting on the supported side.

If the speed is set to **auto**, the switch negotiates with the device at the other end of the link for the speed setting and then forces the speed setting to the negotiated value. The duplex setting remains as configured on each end of the link, which could result in a duplex setting mismatch.

You can configure the duplex setting when the speed is set to **auto**.

**Caution**

Changing the interface speed and duplex mode configuration might shut down and reenables the interface during the reconfiguration.

You can verify your setting by entering the **show interfaces** privileged EXEC command.

Examples

This example shows how to configure an interface for full-duplex operation:

```
Device(config)# interface gigabitethernet1/0/1  
Device(config-if)# duplex full
```

errdisable detect cause

To enable error-disable detection for a specific cause or for all causes, use the **errdisable detect cause** command in global configuration mode. To disable the error-disable detection feature, use the **no** form of this command.

```
errdisable detect cause {all | arp-inspection | bpduguard shutdown vlan | dhcp-rate-limit | dtp-flap | gbic-invalid | inline-power | link-flap | loopback | pagp-flap | pppoe-ia-rate-limit | psp shutdown vlan | security-violation shutdown vlan | sfp-config-mismatch}
no errdisable detect cause {all | arp-inspection | bpduguard shutdown vlan | dhcp-rate-limit | dtp-flap | gbic-invalid | inline-power | link-flap | loopback | pagp-flap | pppoe-ia-rate-limit | psp shutdown vlan | security-violation shutdown vlan | sfp-config-mismatch}
```

Syntax Description

all	Enables error detection for all error-disabled causes.
arp-inspection	Enables error detection for dynamic Address Resolution Protocol (ARP) inspection.
bpduguard shutdown vlan	Enables per-VLAN error-disable for BPDU guard.
dhcp-rate-limit	Enables error detection for DHCP snooping.
dtp-flap	Enables error detection for the Dynamic Trunking Protocol (DTP) flapping.
gbic-invalid	Enables error detection for an invalid Gigabit Interface Converter (GBIC) module. Note This error refers to an invalid small form-factor pluggable (SFP) module.
inline-power	Enables error detection for the Power over Ethernet (PoE) error-disabled cause. Note This keyword is supported only on switches with PoE ports.
link-flap	Enables error detection for link-state flapping.
loopback	Enables error detection for detected loopbacks.
pagp-flap	Enables error detection for the Port Aggregation Protocol (PAgP) flap error-disabled cause.
pppoe-ia-rate-limit	Enables error detection for the PPPoE Intermediate Agent rate-limit error-disabled cause.
psp shutdown vlan	Enables error detection for protocol storm protection (PSP).
security-violation shutdown vlan	Enables voice aware 802.1x security.
sfp-config-mismatch	Enables error detection on an SFP configuration mismatch.

Command Default Detection is enabled for all causes. All causes, except per-VLAN error disabling, are configured to shut down the entire port.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines A cause (such as a link-flap or dhcp-rate-limit) is the reason for the error-disabled state. When a cause is detected on an interface, the interface is placed in an error-disabled state, an operational state that is similar to a link-down state.

When a port is error-disabled, it is effectively shut down, and no traffic is sent or received on the port. For the bridge protocol data unit (BPDU) guard, voice-aware 802.1x security, and port-security features, you can configure the switch to shut down only the offending VLAN on the port when a violation occurs, instead of shutting down the entire port.

If you set a recovery mechanism for the cause by entering the **errdisable recovery** global configuration command, the interface is brought out of the error-disabled state and allowed to retry the operation when all causes have timed out. If you do not set a recovery mechanism, you must enter the **shutdown** and then the **no shutdown** commands to manually recover an interface from the error-disabled state.

For protocol storm protection, excess packets are dropped for a maximum of two virtual ports. Virtual port error disabling using the **psp** keyword is not supported for EtherChannel and Flexlink interfaces.

To verify your settings, enter the **show errdisable detect** privileged EXEC command.

This example shows how to enable error-disabled detection for the link-flap error-disabled cause:

```
Device(config)# errdisable detect cause link-flap
```

This command shows how to globally configure BPDU guard for a per-VLAN error-disabled state:

```
Device(config)# errdisable detect cause bpduguard shutdown vlan
```

This command shows how to globally configure voice-aware 802.1x security for a per-VLAN error-disabled state:

```
Device(config)# errdisable detect cause security-violation shutdown vlan
```

You can verify your setting by entering the **show errdisable detect** privileged EXEC command.

errdisable recovery cause

To enable the error-disabled mechanism to recover from a specific cause, use the **errdisable recovery cause** command in global configuration mode. To return to the default setting, use the **no** form of this command.

```
errdisable recovery cause {all | arp-inspection | bpduguard | channel-misconfig | dhcp-rate-limit |
dtp-flap | gbic-invalid | inline-power | link-flap | loopback | mac-limit | pagp-flap | port-mode-failure |
pppoe-ia-rate-limit | psecure-violation | psp | security-violation | sfp-config-mismatch | storm-control |
udld}
```

```
no errdisable recovery cause {all | arp-inspection | bpduguard | channel-misconfig | dhcp-rate-limit |
dtp-flap | gbic-invalid | inline-power | link-flap | loopback | mac-limit | pagp-flap | port-mode-failure |
pppoe-ia-rate-limit | psecure-violation | psp | security-violation | sfp-config-mismatch | storm-control |
udld}
```

Syntax Description		
all		Enables the timer to recover from all error-disabled causes.
arp-inspection		Enables the timer to recover from the Address Resolution Protocol (ARP) inspection error-disabled state.
bpduguard		Enables the timer to recover from the bridge protocol data unit (BPDU) guard error-disabled state.
channel-misconfig		Enables the timer to recover from the EtherChannel misconfiguration error-disabled state.
dhcp-rate-limit		Enables the timer to recover from the DHCP snooping error-disabled state.
dtp-flap		Enables the timer to recover from the Dynamic Trunking Protocol (DTP) flap error-disabled state.
gbic-invalid		Enables the timer to recover from an invalid Gigabit Interface Converter (GBIC) module error-disabled state. Note This error refers to an invalid small form-factor pluggable (SFP) error-disabled state.
inline-power		Enables the timer to recover from the Power over Ethernet (PoE) error-disabled state. This keyword is supported only on switches with PoE ports.
link-flap		Enables the timer to recover from the link-flap error-disabled state.
loopback		Enables the timer to recover from a loopback error-disabled state.
mac-limit		Enables the timer to recover from the mac limit error-disabled state.
pagp-flap		Enables the timer to recover from the Port Aggregation Protocol (PAgP)-flap error-disabled state.

port-mode-failure	Enables the timer to recover from the port mode change failure error-disabled state.
pppoe-ia-rate-limit	Enables the timer to recover from the PPPoE IA rate limit error-disabled state.
psecure-violation	Enables the timer to recover from a port security violation disable state.
psp	Enables the timer to recover from the protocol storm protection (PSP) error-disabled state.
security-violation	Enables the timer to recover from an IEEE 802.1x-violation disabled state.
sfp-config-mismatch	Enables error detection on an SFP configuration mismatch.
storm-control	Enables the timer to recover from a storm control error.
udld	Enables the timer to recover from the UniDirectional Link Detection (UDLD) error-disabled state.

Command Default Recovery is disabled for all causes.

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

A cause (such as all or BPDU guard) is defined as the reason that the error-disabled state occurred. When a cause is detected on an interface, the interface is placed in the error-disabled state, an operational state similar to link-down state.

When a port is error-disabled, it is effectively shut down, and no traffic is sent or received on the port. For the BPDU guard and port-security features, you can configure the switch to shut down only the offending VLAN on the port when a violation occurs, instead of shutting down the entire port.

If you do not enable the recovery for the cause, the interface stays in the error-disabled state until you enter the **shutdown** and the **no shutdown** interface configuration commands. If you enable the recovery for a cause, the interface is brought out of the error-disabled state and allowed to retry the operation again when all the causes have timed out.

Otherwise, you must enter the **shutdown** and then the **no shutdown** commands to manually recover an interface from the error-disabled state.

You can verify your settings by entering the **show errdisable recovery** privileged EXEC command.

Examples

This example shows how to enable the recovery timer for the BPDU guard error-disabled cause:

```
Device(config)# errdisable recovery cause bpduguard
```

errdisable recovery interval

To specify the time to recover from an error-disabled state, use the **errdisable recovery interval** command in global configuration mode. To return to the default setting, use the **no** form of this command.

errdisable recovery interval *timer-interval*
no errdisable recovery interval *timer-interval*

Syntax Description	<i>timer-interval</i> Time to recover from the error-disabled state. The range is 30 to 86400 seconds. The same interval is applied to all causes. The default interval is 300 seconds.				
Command Default	The default recovery interval is 300 seconds.				
Command Modes	Global configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

Usage Guidelines The error-disabled recovery timer is initialized at a random differential from the configured interval value. The difference between the actual timeout value and the configured value can be up to 15 percent of the configured interval.

You can verify your settings by entering the **show errdisable recovery** privileged EXEC command.

Examples

This example shows how to set the timer to 500 seconds:

```
Device(config)# errdisable recovery interval 500
```

interface

To configure an interface, use the **interface** command.

interface {**Auto-Template** *Auto-Template interface-number* | **Capwap** *Capwap interface-number* | **Gigabit Ethernet** *Gigabit Ethernet interface number* | **Group VI** *Group VI interface number* **Internal Interface** *Internal Interface number* **Loopback** *Loopback interface number* **Null** *Null interface number* **Port-channel** *interface number* **Port-channel** *interface number* **TenGigabit Ethernet** *interface number* **Tunnel** *interface number* **Vlan** *interface number*}

Syntax	Description
Auto-Template <i>Auto-template interface-number</i>	Enables you to configure auto-template interface. Values range from 1 to 999.
Capwap <i>Capwap interface number</i>	Enables you to configure CAPWAP tunnel interface. Values range from 0 to 2147483647.
GigabitEthernet <i>Gigabit Ethernet interface number</i>	Enables you to configure Gigabit Ethernet IEEE 802.3z interface. Values range from 0 to 9.
Group VI <i>Group VI interface number</i>	Enables you to configure the internal interface. Values range from 0 to 9.
Internal Interface <i>Internal Interface</i>	Enables you to configure internal interface.
Loopback <i>Loopback Interface number</i>	Enables you to configure loopback interface. Values range from 0 to 2147483647.
Null <i>Null interface number</i>	Enables you to configure null interface. Value is 0.
Port-channel <i>interface number</i>	Enables you to configure Ethernet channel interfaces. Values range from 1 to 128.
TenGigabitEthernet <i>interface number</i>	Enables you to configure a 10-Gigabit Ethernet interface. Values range from 0 to 9.
Tunnel <i>interface number</i>	Enables you to configure the tunnel interface. Values range from 0 to 2147483647.
Vlan <i>interface number</i>	Enables you to configure switch VLAN interfaces. Values range from 0 to 4098.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You can not use the "no" form of this command.

This example shows how you can configure interface:

```
Device# interface Tunnel 15
```

interface range

To configure an interface range, use the **interface range** command.

interface range {**Gigabit Ethernet** *interface-number* | **Loopback** *interface-number* | **Port Channel** *interface-number* | **TenGigabit Ethernet** *interface-number* **Tunnel** *interface-number* **Vlan** *interface-number* **Macro** *WORD*}

Syntax Description	Description
GigabitEthernet <i>interface-number</i>	Configures the Gigabit Ethernet IEEE 802.3z interface. Values range from 1 to 9.
Loopback <i>interface-number</i>	Configures the loopback interface. Values range from 0 to 2147483647.
Port-Channel <i>interface-number</i>	Configures 10-Gigabit Ethernet channel of interfaces. Values range from 1 to 128.
TenGigabit Ethernet <i>interface-number</i>	Configures 10-Gigabit Ethernet interfaces. Values range from 0 to 9.
Tunnel <i>interface-number</i>	Configures the tunnel interface. Values range from 0 to 2147483647.
VLAN <i>interface-number</i>	Configures the switch VLAN interfaces. Values range from 1 to 4095.
Macro <i>WORD</i>	Configures the keywords to interfaces. Support up to 32 characters.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how you can configure interface range:

```
Device(config)# interface range vlan 1
```

ip mtu

To set the IP maximum transmission unit (MTU) size of routed packets on all routed ports of the switch or switch stack, use the **ip mtu** command in interface configuration mode. To restore the default IP MTU size, use the **no** form of this command.

```
ip mtu bytes
no ip mtu bytes
```

Syntax Description	<i>bytes</i> MTU size, in bytes. The range is from 68 up to the system MTU value (in bytes).				
Command Default	The default IP MTU size for frames received and sent on all switch interfaces is 1500 bytes.				
Command Modes	Interface configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

Usage Guidelines The upper limit of the IP value is based on the switch or switch stack configuration and refers to the currently applied system MTU value. For more information about setting the MTU sizes, see the **system mtu** global configuration command.

To return to the default IP MTU setting, you can apply the **default ip mtu** command or the **no ip mtu** command on the interface.

You can verify your setting by entering the **show ip interface** *interface-id* or **show interfaces** *interface-id* privileged EXEC command.

The following example sets the maximum IP packet size for VLAN 200 to 1000 bytes:

```
Device(config)# interface vlan 200
Device(config-if)# ip mtu 1000
```

The following example sets the maximum IP packet size for VLAN 200 to the default setting of 1500 bytes:

```
Device(config)# interface vlan 200
Device(config-if)# default ip mtu
```

This is an example of partial output from the **show ip interface** *interface-id* command. It displays the current IP MTU setting for the interface.

```
Device# show ip interface gigabitethernet4/0/1
GigabitEthernet4/0/1 is up, line protocol is up
  Internet address is 18.0.0.1/24
  Broadcast address is 255.255.255.255
  Address determined by setup command
  MTU is 1500 bytes
  Helper address is not set
```

<output truncated>

ipv6 mtu

To set the IPv6 maximum transmission unit (MTU) size of routed packets on all routed ports of the switch or switch stack, use the **ipv6 mtu** command in interface configuration mode. To restore the default IPv6 MTU size, use the **no** form of this command.

ipv6 mtu *bytes*
no ipv6 mtu *bytes*

Syntax Description	<i>bytes</i> MTU size, in bytes. The range is from 1280 up to the system MTU value (in bytes).	
Command Default	The default IPv6 MTU size for frames received and sent on all switch interfaces is 1500 bytes.	
Command Modes	Interface configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The upper limit of the IPv6 MTU value is based on the switch or switch stack configuration and refers to the currently applied system MTU value. For more information about setting the MTU sizes, see the **system mtu** global configuration command.

To return to the default IPv6 MTU setting, you can apply the **default ipv6 mtu** command or the **no ipv6 mtu** command on the interface.

You can verify your setting by entering the **show ipv6 interface** *interface-id* or **show interface** *interface-id* privileged EXEC command.

The following example sets the maximum IPv6 packet size for an interface to 2000 bytes:

```
Device(config)# interface gigabitethernet4/0/1
Device(config-if)# ipv6 mtu 2000
```

The following example sets the maximum IPv6 packet size for an interface to the default setting of 1500 bytes:

```
Device(config)# interface gigabitethernet4/0/1
Device(config-if)# default ipv6 mtu
```

This is an example of partial output from the **show ipv6 interface** *interface-id* command. It displays the current IPv6 MTU setting for the interface.

```
Device# show ipv6 interface gigabitethernet4/0/1
GigabitEthernet4/0/1 is up, line protocol is up
  Internet address is 18.0.0.1/24
  Broadcast address is 255.255.255.255
  Address determined by setup command
  MTU is 1500 bytes
  Helper address is not set
```

<output truncated>

lldp (interface configuration)

To enable Link Layer Discovery Protocol (LLDP) on an interface, use the **lldp** command in interface configuration mode. To disable LLDP on an interface, use the **no** form of this command.

Syntax Description		
med-tlv-select		Selects an LLDP Media Endpoint Discovery (MED) time-length-value (TLV) element to send.
<i>tlv</i>		String that identifies the TLV element. Valid values are the following: <ul style="list-style-type: none"> • inventory-management— LLDP MED Inventory Management TLV. • location— LLDP MED Location TLV. • network-policy— LLDP MED Network Policy TLV.
receive		Enables the interface to receive LLDP transmissions.
tlv-select		Selects the LLDP TLVs to send.
power-management		Sends the LLDP Power Management TLV.
transmit		Enables LLDP transmission on the interface.

Command Default LLDP is disabled.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines This command is supported on 802.1 media types.

If the interface is configured as a tunnel port, LLDP is automatically disabled.

The following example shows how to disable LLDP transmission on an interface:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# no lldp transmit
```

The following example shows how to enable LLDP transmission on an interface:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# lldp transmit
```

logging event power-inline-status

To enable the logging of Power over Ethernet (PoE) events, use the **logging event power-inline-status** command in interface configuration mode. To disable the logging of PoE status events, use the **no** form of this command.

logging event power-inline-status
no logging event power-inline-status

Syntax Description This command has no arguments or keywords.

Command Default Logging of PoE events is enabled.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The **no** form of this command does not disable PoE error events.

Examples

This example shows how to enable logging of PoE events on a port:

```
Device(config-if)# interface gigabitethernet1/0/1
Device(config-if)# logging event power-inline-status
Device(config-if)#
```

mdix auto

To enable the automatic medium-dependent interface crossover (auto-MDIX) feature on the interface, use the **mdix auto** command in interface configuration mode. To disable auto-MDIX, use the **no** form of this command.

mdix auto
no mdix auto

Syntax Description This command has no arguments or keywords.

Command Default Auto-MDIX is enabled.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines When auto-MDIX is enabled, the interface automatically detects the required cable connection type (straight-through or crossover) and configures the connection appropriately.

When you enable auto-MDIX on an interface, you must also set the interface speed and duplex to **auto** so that the feature operates correctly.

When auto-MDIX (and autonegotiation of speed and duplex) is enabled on one or both of the connected interfaces, link up occurs, even if the cable type (straight-through or crossover) is incorrect.

Auto-MDIX is supported on all 10/100 and 10/100/1000 Mb/s interfaces and on 10/100/1000BASE-TX small form-factor pluggable (SFP) module interfaces. It is not supported on 1000BASE-SX or -LX SFP module interfaces.

You can verify the operational state of auto-MDIX on the interface by entering the **show controllers ethernet-controller interface-id phy** privileged EXEC command.

This example shows how to enable auto-MDIX on a port:

```
Device# configure terminal
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# speed auto
Device(config-if)# duplex auto
Device(config-if)# mdix auto
Device(config-if)# end
```

mode (power-stack configuration)

To configure power stack mode for the power stack, use the **mode** command in power-stack configuration mode. To return to the default settings, use the **no** form of the command.

mode {**power-shared** | **redundant**} [**strict**]
no mode

Syntax Description		
power-shared		Sets the power stack to operate in power-shared mode. This is the default.
redundant		Sets the power stack to operate in redundant mode. The largest power supply is removed from the power pool to be used as backup power in case one of the other power supplies fails.
strict		(Optional) Configures the power stack mode to run a strict power budget. The stack power needs cannot exceed the available power.

Command Default The default modes are **power-shared** and nonstrict.

Command Modes Power-stack configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines This command is available only on switch stacks running the IP Base or IP Services feature set.

To access power-stack configuration mode, enter the **stack-power stack** *power stack name* global configuration command.

Entering the **no mode** command sets the switch to the defaults of **power-shared** and non-strict mode.



Note For stack power, available power is the total power available for PoE from all power supplies in the power stack, available power is the power allocated to all powered devices connected to PoE ports in the stack, and consumed power is the actual power consumed by the powered devices.

In **power-shared** mode, all of the input power can be used for loads, and the total available power appears as one large power supply. The power budget includes all power from all supplies. No power is set aside for power supply failures. If a power supply fails, load shedding (shutting down of powered devices or switches) might occur.

In **redundant** mode, the largest power supply is removed from the power pool to use as backup power in case one of the other power supplies fails. The available power budget is the total power minus the largest power supply. This reduces the available power in the pool for switches and powered devices, but in case of a failure or an extreme power load, there is less chance of having to shut down switches or powered devices.

In **strict** mode, when a power supply fails and the available power drops below the budgeted power, the system balances the budget through load shedding of powered devices, even if the actual power is less than the available power. In nonstrict mode, the power stack can run in an over-allocated state and is stable as long as

the actual power does not exceed the available power. In this mode, a powered device drawing more than normal power could cause the power stack to start shedding loads. This is normally not a problem because most devices do not run at full power. The chances of multiple powered devices in the stack requiring maximum power at the same time is small.

In both strict and nonstrict modes, power is denied when there is no power available in the power budget.

This is an example of setting the power stack mode for the stack named power1 to power-shared with strict power budgeting. All power in the stack is shared, but when the total available power is allotted, no more devices are allowed power.

```
Device(config)# stack-power stack power1  
Device(config-stackpower)# mode power-shared strict  
Device(config-stackpower)# exit
```

This is an example of setting the power stack mode for the stack named power2 to redundant. The largest power supply in the stack is removed from the power pool to provide redundancy in case one of the other supplies fails.

```
Device(config)# stack-power stack power2  
Device(config-stackpower)# mode redundant  
Device(config-stackpower)# exit
```

monitoring

To enable digital optical monitoring (DOM) and to specify the polling interval, enter the **monitoring** command in the transceiver type configuration mode. To disable monitoring, use the **no** form of the command.

```
monitoring
[{interval seconds}]
no monitoring
```

Syntax Description	interval seconds (Optional) Specifies the interval at which polling of monitoring parameter occurs. The valid range is 300 to 3600 seconds, and the default interval is 600 seconds.				
Command Default	DOM is disabled				
Command Modes	Transceiver type configuration mode (config-xcvr-type)				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Denali 16.3.6</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Denali 16.3.6	This command was introduced.
Release	Modification				
Cisco IOS XE Denali 16.3.6	This command was introduced.				

- Usage Guidelines**
- You can enable optical monitoring only for optical transceivers that support DOM. Use these resources to verify:
- See the following publication on cisco.com:
https://www.cisco.com/c/en/us/td/docs/interfaces_modules/transceiver_modules/compatibility/matrix/DOM_matrix.html
 - Display the list of DOM-supported transceivers on the switch, by entering the **show interfaces transceiver supported-list** command in privileged EXEC mode.

This example shows how to enable monitoring of optical transceivers, set the polling interval to 1500 seconds and display real-time values:

```
Device# configure terminal
Device(config)# transceiver type all
Device(config-xcvr-type)# monitoring interval 1500
Device(config-xcvr-type)# end
Device# show interfaces transceiver detail
```

mA: milliamperes, dBm: decibels (milliwatts), NA or N/A: not applicable.
 ++ : high alarm, + : high warning, - : low warning, -- : low alarm.
 A2D readouts (if they differ), are reported in parentheses.
 The threshold values are calibrated.

Port	Temperature (Celsius)	High Alarm Threshold (Celsius)	High Warn Threshold (Celsius)	Low Warn Threshold (Celsius)	Low Alarm Threshold (Celsius)
Gi5/1/2	43.0	110.0	93.0	-30.0	-40.0
Te5/1/3	32.0	90.0	85.0	-5.0	-10.0

Port	Voltage (Volts)	High Alarm Threshold (Volts)	High Warn Threshold (Volts)	Low Warn Threshold (Volts)	Low Alarm Threshold (Volts)

Gi5/1/2	3.28	3.90	3.70	2.90	2.70
Te5/1/3	3.28	3.63	3.47	3.14	2.97
Port	Current (milliamperes)	High Alarm Threshold (mA)	High Warn Threshold (mA)	Low Warn Threshold (mA)	Low Alarm Threshold (mA)
Gi5/1/2	22.1	80.0	70.0	4.0	2.0
Te5/1/3	19.8	105.0	95.0	4.0	2.0
Port	Optical Transmit Power (dBm)	High Alarm Threshold (dBm)	High Warn Threshold (dBm)	Low Warn Threshold (dBm)	Low Alarm Threshold (dBm)
Gi5/1/2	-5.4	0.9	-1.0	-11.5	-13.4
Te5/1/3	2.4	7.9	4.9	-0.0	-4.0
Port	Optical Receive Power (dBm)	High Alarm Threshold (dBm)	High Warn Threshold (dBm)	Low Warn Threshold (dBm)	Low Alarm Threshold (dBm)
Gi5/1/2	-8.1	0.7	-1.0	-20.0	-24.0
Te5/1/3	-4.2	-0.0	-3.0	-23.0	-27.2

This example shows how to disable monitoring for all transceiver types:

```
Device(config)#transceiver type all
Device(config-xcvr-type)# no monitoring
Device(config-xcvr-type)#end
Device# show interfaces transceiver detail
```

Transceiver monitoring is disabled for all interfaces.
<output truncated>

Related Commands

Command	Description
transceiver type all	Enters the transceiver type configuration mode.
show interfaces transceiver	Display the physical properties of a small form-factor pluggable (SFP) module interface.

network-policy

To apply a network-policy profile to an interface, use the **network-policy** command in interface configuration mode. To remove the policy, use the **no** form of this command.

network-policy *profile-number*
no network-policy

Syntax Description

profile-number The network-policy profile number to apply to the interface.

Command Default

No network-policy profiles are applied.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **network-policy** *profile number* interface configuration command to apply a profile to an interface.

You cannot apply the **switchport voice vlan** command on an interface if you first configure a network-policy profile on it. However, if **switchport voice vlan** *vlan-id* is already configured on the interface, you can apply a network-policy profile on the interface. The interface then has the voice or voice-signaling VLAN network-policy profile applied.

This example shows how to apply network-policy profile 60 to an interface:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# network-policy 60
```

network-policy profile (global configuration)

To create a network-policy profile and to enter network-policy configuration mode, use the **network-policy profile** command in global configuration mode. To delete the policy and to return to global configuration mode, use the **no** form of this command.

network-policy profile *profile-number*
no network-policy profile *profile-number*

Syntax Description	<i>profile-number</i> Network-policy profile number. The range is 1 to 4294967295.	
Command Default	No network-policy profiles are defined.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	<p>Use the network-policy profile global configuration command to create a profile and to enter network-policy profile configuration mode.</p> <p>To return to privileged EXEC mode from the network-policy profile configuration mode, enter the exit command.</p> <p>When you are in network-policy profile configuration mode, you can create the profile for voice and voice signaling by specifying the values for VLAN, class of service (CoS), differentiated services code point (DSCP), and tagging mode.</p> <p>These profile attributes are contained in the Link Layer Discovery Protocol for Media Endpoint Devices (LLDP-MED) network-policy time-length-value (TLV).</p> <p>This example shows how to create network-policy profile 60:</p> <pre>Device(config)# network-policy profile 60 Device(config-network-policy)#</pre>	

nmsp attachment suppress

To suppress the reporting of attachment information from a specified interface, use the **nmsp attachment suppress** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

nmsp attachment suppress
no nmsp attachment suppress

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Interface configuration (config-if)

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use the **nmsp attachment suppress** interface configuration command to configure an interface to not send location and attachment notifications to a Cisco Mobility Services Engine (MSE).



Note Attachment information is not supported in Cisco IOS XE Denali 16.1.1 and later releases.

This example shows how to configure an interface to not send attachment information to the MSE:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# nmsp attachment suppress
```

power efficient-ethernet auto

To enable Energy Efficient Ethernet (EEE) for an interface, use the **power efficient-ethernet auto** command in interface configuration mode. To disable EEE on an interface, use the **no** form of this command.

power efficient-ethernet auto
no power efficient-ethernet auto

Syntax Description This command has no arguments or keywords.

Command Default EEE is disabled.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You can enable EEE on devices that support low power idle (LPI) mode. Such devices can save power by entering LPI mode during periods of low utilization. In LPI mode, systems on both ends of the link can save power by shutting down certain services. EEE provides the protocol needed to transition into and out of LPI mode in a way that is transparent to upper layer protocols and applications.

The **power efficient-ethernet auto** command is available only if the interface is EEE capable. To check if an interface is EEE capable, use the **show eee capabilities EXEC** command.

When EEE is enabled, the device advertises and autonegotiates EEE to its link partner. To view the current EEE status for an interface, use the **show eee status EXEC** command.

This command does not require a license.

This example shows how to enable EEE for an interface:

```
Device(config-if) # power efficient-ethernet auto
Device(config-if) #
```

This example shows how to disable EEE for an interface:

```
Device(config-if) # no power efficient-ethernet auto
Device(config-if) #
```

power-priority

To configure Cisco StackPower power-priority values for a switch in a power stack and for its high-priority and low-priority PoE ports, use the **power-priority** command in switch stack-power configuration mode. To return to the default setting, use the **no** form of the command.

```
power-priority {high value | low value | switch value}
no power-priority {high | low | switch}
```

Syntax Description

high <i>value</i>	Sets the power priority for the ports configured as high-priority ports. The range is 1 to 27, with 1 as the highest priority. The high value must be lower than the value set for the low-priority ports and higher than the value set for the switch.
low <i>value</i>	Sets the power priority for the ports configured as low-priority ports. The range is 1 to 27. The low value must be higher than the value set for the high-priority ports and the value set for the switch.
switch <i>value</i>	Sets the power priority for the switch. The range is 1 to 27. The switch value must be lower than the values set for the low and high-priority ports.

Command Default

If no values are configured, the power stack randomly determines a default priority.

The default ranges are 1 to 9 for switches, 10 to 18 for high-priority ports, 19 to 27 for low-priority ports.

On non-PoE switches, the high and low values (for port priority) have no effect.

Command Modes

Switch stack-power configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

To access switch stack-power configuration mode, enter the **stack-power switch** *switch-number* global configuration command.

Cisco StackPower power-priority values determine the order for shutting down switches and ports when power is lost and load shedding must occur. Priority values are from 1 to 27; the highest numbers are shut down first.

We recommend that you configure different priority values for each switch and for its high priority ports and low priority ports to limit the number of devices shut down at one time during a loss of power. If you try to configure the same priority value on different switches in a power stack, the configuration is allowed, but you receive a warning message.



Note

This command is available only on switch stacks running the IP Base or IP Services feature set.

Examples

This is an example of setting the power priority for switch 1 in power stack a to 7, for the high-priority ports to 11, and for the low-priority ports to 20.

```
Device(config)# stack-power switch 1  
Device(config-switch-stackpower)# stack-id power_stack_a  
Device(config-switch-stackpower)# power-priority high 11  
Device(config-switch-stackpower)# power-priority low 20  
Device(config-switch-stackpower)# power-priority switch 7  
Device(config-switch-stackpower)# exit
```

power inline

To configure the power management mode on Power over Ethernet (PoE) ports, use the **power inline** command in interface configuration mode. To return to the default settings, use the **no** form of this command.

```
power inline {auto [max max-wattage] | never | port priority {high | low} | static [max
max-wattage]}
no power inline {auto | never | port priority {high | low} | static [max max-wattage]}
```

Syntax Description		
	auto	Enables powered-device detection. If enough power is available, automatically allocates power to the PoE port after device detection. Allocation is first-come, first-serve.
	max <i>max-wattage</i>	(Optional) Limits the power allowed on the port. The range is 4000 to 30000 mW. If no value is specified, the maximum is allowed.
	never	Disables device detection, and disables power to the port.
	port	Configures the power priority of the port. The default priority is low.
	priority { high low }	Sets the power priority of the port. In case of a power supply failure, ports configured as low priority are turned off first and ports configured as high priority are turned off last. The default priority is low.
	static	Enables powered-device detection. Pre-allocates (reserves) power for a port before the switch discovers the powered device. This action guarantees that the device connected to the interface receives enough power.

Command Default The default is **auto** (enabled).
The maximum wattage is 30,000 mW.
The default port priority is low.

Command Default Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

This command is supported only on PoE-capable ports. If you enter this command on a port that does not support PoE, this error message appears:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# power inline auto
                        ^
% Invalid input detected at '^' marker.
```

In a switch stack, this command is supported on all ports in the stack that support PoE.

Use the **max max-wattage** option to disallow higher-power powered devices. With this configuration, when the powered device sends Cisco Discovery Protocol (CDP) messages requesting more power than the maximum wattage, the switch removes power from the port. If the powered-device IEEE class maximum is greater than the maximum wattage, the switch does not power the device. The power is reclaimed into the global power budget.



Note The switch never powers any class 0 or class 3 device if the **power inline max max-wattage** command is configured for less than 30 W.

If the switch denies power to a powered device (the powered device requests more power through CDP messages or if the IEEE class maximum is greater than the maximum wattage), the PoE port is in a power-deny state. The switch generates a system message, and the Oper column in the **show power inline** privileged EXEC command output shows *power-deny*.

Use the **power inline static max max-wattage** command to give a port high priority. The switch allocates PoE to a port configured in static mode before allocating power to a port configured in auto mode. The switch reserves power for the static port when it is configured rather than upon device discovery. The switch reserves the power on a static port even when there is no connected device and whether or not the port is in a shutdown or in a no shutdown state. The switch allocates the configured maximum wattage to the port, and the amount is never adjusted through the IEEE class or by CDP messages from the powered device. Because power is pre-allocated, any powered device that uses less than or equal to the maximum wattage is guaranteed power when it is connected to a static port. However, if the powered device IEEE class is greater than the maximum wattage, the switch does not supply power to it. If the switch learns through CDP messages that the powered device needs more than the maximum wattage, the powered device is shut down.

If the switch cannot pre-allocate power when a port is in static mode (for example, because the entire power budget is already allocated to other auto or static ports), this message appears: Command rejected: power inline static: pwr not available. The port configuration remains unchanged.

When you configure a port by using the **power inline auto** or the **power inline static** interface configuration command, the port autonegotiates by using the configured speed and duplex settings. This is necessary to determine the power requirements of the connected device (whether or not it is a powered device). After the power requirements have been determined, the switch hardcodes the interface by using the configured speed and duplex settings without resetting the interface.

When you configure a port by using the **power inline never** command, the port reverts to the configured speed and duplex settings.

If a port has a Cisco powered device connected to it, you should not use the **power inline never** command to configure the port. A false link-up can occur, placing the port in an error-disabled state.

Use the **power inline port priority {high | low}** command to configure the power priority of a PoE port. Powered devices connected to ports with low port priority are shut down first in case of a power shortage.

You can verify your settings by entering the **show power inline EXEC** command.

Examples

This example shows how to enable detection of a powered device and to automatically power a PoE port on a switch:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# power inline auto
```

This example shows how to configure a PoE port on a switch to allow a class 1 or a class 2 powered device:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# power inline auto max 7000
```

This example shows how to disable powered-device detection and to not power a PoE port on a switch:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# power inline never
```

This example shows how to set the priority of a port to high, so that it would be one of the last ports to be shut down in case of power supply failure:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# power inline port priority high
```

power inline police

To enable policing of real-time power consumption on a powered device, use the **power inline police** command in interface configuration mode. To disable this feature, use the **no** form of this command

```
power inline police [action {errdisable | log}]
no power inline police
```

Syntax Description	action errdisable	(Optional) Configures the device to turn off power to the port if the real-time power consumption exceeds the maximum power allocation on the port. This is the default action.
	action log	(Optional) Configures the device to generate a syslog message while still providing power to a connected device if the real-time power consumption exceeds the maximum power allocation on the port.
Command Default	Policing of the real-time power consumption of the powered device is disabled.	
Command Modes	Interface configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

This command is supported only on the LAN Base image.

This command is supported only on Power over Ethernet (PoE)-capable ports. If you enter this command on a device or port that does not support PoE, an error message appears.

In a switch stack, this command is supported on all switches or ports in the stack that support PoE and real-time power-consumption monitoring.

When policing of the real-time power consumption is enabled, the device takes action when a powered device consumes more power than the allocated maximum amount.

When PoE is enabled, the device senses the real-time power consumption of the powered device. This feature is called *power monitoring* or *power sensing*. The device also polices the power usage with the *power policing* feature.

When power policing is enabled, the device uses one of the these values as the cutoff power on the PoE port in this order:

1. The user-defined power level that limits the power allowed on the port when you enter the **power inline auto max max-wattage** or the **power inline static max max-wattage** interface configuration command
2. The device automatically sets the power usage of the device by using CDP power negotiation or by the IEEE classification and LLDP power negotiation.

If you do not manually configure the cutoff-power value, the device automatically determines it by using CDP power negotiation or the device IEEE classification and LLDP power negotiation. If CDP or LLDP are not enabled, the default value of 30 W is applied. However without CDP or LLDP, the device does not allow devices to consume more than 15.4 W of power because values from 15400 to 30000 mW are only allocated based on CDP or LLDP requests. If a powered device consumes more than 15.4 W without CDP or LLDP

negotiation, the device might be in violation of the maximum current *I_{max}* limitation and might experience an *I_{cut}* fault for drawing more current than the maximum. The port remains in the fault state for a time before attempting to power on again. If the port continuously draws more than 15.4 W, the cycle repeats.

When a powered device connected to a PoE+ port restarts and sends a CDP or LLDP packet with a power TLV, the device locks to the power-negotiation protocol of that first packet and does not respond to power requests from the other protocol. For example, if the device is locked to CDP, it does not provide power to devices that send LLDP requests. If CDP is disabled after the device has locked on it, the device does not respond to LLDP power requests and can no longer power on any accessories. In this case, you should restart the powered device.

If power policing is enabled, the device polices power usage by comparing the real-time power consumption to the maximum power allocated on the PoE port. If the device uses more than the maximum power allocation (or *cutoff power*) on the port, the device either turns power off to the port, or the device generates a syslog message and updates the LEDs (the port LEDs are blinking amber) while still providing power to the device.

- To configure the device to turn off power to the port and put the port in the error-disabled state, use the **power inline police** interface configuration command.
- To configure the device to generate a syslog message while still providing power to the device, use the **power inline police action log** command.

If you do not enter the **action log** keywords, the default action is to shut down the port, turn off power to it, and put the port in the PoE error-disabled state. To configure the PoE port to automatically recover from the error-disabled state, use the **errdisable detect cause inline-power** global configuration command to enable error-disabled detection for the PoE cause and the **errdisable recovery cause inline-power interval interval** global configuration command to enable the recovery timer for the PoE error-disabled cause.



Caution

If policing is disabled, no action occurs when the powered device consumes more than the maximum power allocation on the port, which could adversely affect the device.

You can verify your settings by entering the **show power inline police** privileged EXEC command.

Examples

This example shows how to enable policing of the power consumption and configuring the device to generate a syslog message on the PoE port on a device:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# power inline police action log
```

power supply

To configure and manage the internal power supplies on a switch, use the **power supply** command in privileged EXEC mode.

power supply *stack-member-number* **slot** {**A** | **B**} {**off** | **on**}

Syntax Description		
<i>stack-member-number</i>		Stack member number for which to configure the internal power supplies. The range is 1 to 9, depending on the number of switches in the stack. This parameter is available only on stacking-capable switches.
slot		Selects the switch power supply to set.
A		Selects the power supply in slot A.
B		Selects the power supply in slot B. Note Power supply slot B is the closest slot to the outer edge of the switch.
off		Sets the switch power supply to off.
on		Sets the switch power supply to on.

Command Default The switch power supply is on.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The **power supply** command applies to a switch or to a switch stack where all switches are the same platform. In a switch stack with the same platform switches, you must specify the stack member before entering the **slot** {**A** | **B**} **off** or **on** keywords.

To return to the default setting, use the **power supply** *stack-member-number* **on** command.

You can verify your settings by entering the **show env power** privileged EXEC command.

Examples

This example shows how to set the power supply in slot A to off:

```
Device> power supply 2 slot A off
Disabling Power supply A may result in a power loss to PoE devices and/or switches ...
Continue? (yes/[no]): yes
Device
Jun 10 04:52:54.389: %PLATFORM_ENV-6-FRU_PS_OIR: FRU Power Supply 1 powered off
Jun 10 04:52:56.717: %PLATFORM_ENV-1-FAN_NOT_PRESENT: Fan is not present
```

This example shows how to set the power supply in slot A to on:

```
Device> power supply 1 slot B on
Jun 10 04:54:39.600: %PLATFORM_ENV-6-FRU_PS_OIR: FRU Power Supply 1 powered on
```

This example shows the output of the show env power command:

```
Device> show env power
SW  PID                Serial#      Status      Sys Pwr  PoE Pwr  Watts
--  -
1A  PWR-1RUC2-640WAC    DCB1705B05B OK           Good     Good    250/390
1B  Not Present
```

show CAPWAP summary

To display all the CAPWAP tunnels established by the controller to access points and other mobility controllers use the **show CAPWAP summary** command.

show CAPWAP summary

Syntax Description	This command has no arguments or keywords.
Command Default	None
Command Modes	Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display CAPWAP tunnels established by the controllers to the access points and other controllers.

```
Device# show capwap summary
CAPWAP Tunnels General Statistics:
Number of Capwap Data Tunnels = 8
Number of Capwap Mobility Tunnels = 0
Number of Capwap Multicast Tunnels = 0
Name APName Type PhyPortIf Mode McastIf
-----
-----
Ca4 AP-Behind-Router data - unicast -
Ca0 AP1142-kat data - unicast -
Ca5 APRFCHAMBER2-EDISON data - unicast -
Ca6 KATANA_2_RF data - unicast -
Ca1 AP-1040-RF data - unicast -
Ca7 KATANA_1_RF data - unicast -
Ca2 AP3500-2027 data - unicast -
Ca3 AP-1040-out data - unicast -
```

show controllers cpu-interface

To display the state of the CPU network interface ASIC and the send and receive statistics for packets reaching the CPU, use the **show controllers cpu-interface** command in privileged EXEC mode.

show controllers cpu-interface [{switch *stack-member-number*}]

Syntax Description	switch <i>stack-member-number</i> (Optional) Specifies the stack member number.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	This display provides information that might be useful for Cisco technical support representatives troubleshooting the switch.
-------------------------	--

Examples

This is a partial output example from the **show controllers cpu-interface** command:

```
Device# show controllers cpu-interface switch 1
cpu-queue-frames  retrieved dropped invalid hol-block
```

```
-----
Routing Protocol          0          0          0          0
L2 Protocol               241567         0          0          0
sw forwarding             0            0          0          0
broadcast                 68355         0          0          0
icmp                      0            0          0          0
icmp redirect             0            0          0          0
logging                   0            0          0          0
rpf-fail                  0            0          0          0
DOT1X authentication 328174  0          0          0
Forus Traffic             0            0          0          0
Forus Resolution          0            0          0          0
Wireless q5               0            0          0          0
Wireless q1               0            0          0          0
Wireless q2               0            0          0          0
Wireless q3               0            0          0          0
Wireless q4               0            0          0          0
Learning cache            0            0          0          0
Topology control          820408        0          0          0
Proto snooping            0            0          0          0
BFD Low latency           0            0          0          0
Transit Traffic           0            0          0          0
Multi End station         0            0          0          0
Health Check              0            0          0          0
Crypto control            0            0          0          0
Exception                 0            0          0          0
General Punt              0            0          0          0
NFL sampled data          0            0          0          0
STG cache                 0            0          0          0
```

EGR exception	0	0	0	0
show forward	0	0	0	0
Multicast data	0	0	0	0
Gold packet	0	0	0	0

show controllers ethernet-controller

To display per-interface send and receive statistics read from the hardware with keywords, use the **show controllers ethernet-controller** command in EXEC mode.

```
show controllers ethernet-controller [interface-id] [{down-when-looped | phy [detail]}] [port-asic
statistics {exceptions | interface interface-id {l2 | l3} | l3-ifid if-id | port-ifid if-id | vlan-ifid if-id}
[switch stack-member-number] [asic asic-number]]
```

Syntax Description		
	<i>interface-id</i>	(Optional) ID of the physical interface.
	down-when-looped	(Optional) Displays states related to down-when-looped detection.
	phy	(Optional) Displays the status of the internal registers on the switch physical layer device (PHY) for the device or the interface. This display includes the operational state of the automatic medium-dependent interface crossover (auto-MDIX) feature on an interface.
	detail	(Optional) Displays details about the PHY internal registers.
	port-asic	(Optional) Displays information about the port ASIC internal registers.
	statistics	Displays port ASIC statistics, including the Rx/Sup Queue and miscellaneous statistics.
	exceptions	Displays port ASIC exception statistics.
	interface <i>interface-id</i>	Specifies the interface for which to display port ASIC statistics.
	l2	Displays statistics for the Layer 2 interface.
	l3	Displays statistics for the Layer 3 interface.
	l3-ifid <i>if-id</i>	Specifies the Layer 3 IF interface ID for which to display port ASIC statistics.
	port-ifid <i>if-id</i>	Specifies the PortIF interface ID for which to display port ASIC statistics.
	vlan-ifid <i>if-id</i>	Specifies the VLANIF interface ID for which to display port ASIC statistics.
	switch <i>stack-member-number</i>	(Optional) Specifies the stack member number for which to display send and receive statistics.
	asic <i>asic-number</i>	(Optional) Specifies the ASIC number.

Command Modes User EXEC (only supported with the *interface-id* keywords in user EXEC mode)
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Without keywords, this command provides the RMON statistics for all interfaces or for the specified interface.

To display the interface internal registers, use the **phy** keyword. To display information about the port ASIC, use the **port-asic** keyword.

When you enter the **phy** or **port-asic** keywords, the displayed information is useful primarily for Cisco technical support representatives troubleshooting the switch.

Examples

This is an example of output from the **show controllers ethernet-controller** command for an interface:

```
Device# show controllers ethernet-controller gigabitethernet1/0/1
Transmit                               GigabitEthernet1/0/1          Receive
19216827 Total bytes                   0 Total bytes
   41935 Unicast frames                 0 Unicast frames
2683840 Unicast bytes                  0 Unicast bytes
   216662 Multicast frames              0 Multicast frames
16532987 Multicast bytes                0 Multicast bytes
   0 Broadcast frames                   0 Broadcast frames
   0 Broadcast bytes                     0 Broadcast bytes
   0 System FCS error frames             0 IpgViolation frames
   0 MacUnderrun frames                  0 MacOverrun frames
   0 Pause frames                        0 Pause frames
   0 Cos 0 Pause frames                  0 Cos 0 Pause frames
   0 Cos 1 Pause frames                  0 Cos 1 Pause frames
   0 Cos 2 Pause frames                  0 Cos 2 Pause frames
   0 Cos 3 Pause frames                  0 Cos 3 Pause frames
   0 Cos 4 Pause frames                  0 Cos 4 Pause frames
   0 Cos 5 Pause frames                  0 Cos 5 Pause frames
   0 Cos 6 Pause frames                  0 Cos 6 Pause frames
   0 Cos 7 Pause frames                  0 Cos 7 Pause frames
   0 Oam frames                          0 OamProcessed frames
   0 Oam frames                          0 OamDropped frames
251598 Minimum size frames              0 Minimum size frames
   0 65 to 127 byte frames               0 65 to 127 byte frames
   0 128 to 255 byte frames              0 128 to 255 byte frames
6999 256 to 511 byte frames             0 256 to 511 byte frames
   0 512 to 1023 byte frames             0 512 to 1023 byte frames
   0 1024 to 1518 byte frames            0 1024 to 1518 byte frames
   0 1519 to 2047 byte frames            0 1519 to 2047 byte frames
   0 2048 to 4095 byte frames            0 2048 to 4095 byte frames
   0 4096 to 8191 byte frames            0 4096 to 8191 byte frames
   0 8192 to 16383 byte frames           0 8192 to 16383 byte frames
   0 16384 to 32767 byte frame           0 16384 to 32767 byte frame
   0 > 32768 byte frames                 0 > 32768 byte frames
   0 Late collision frames                0 SymbolErr frames
   0 Excess Defer frames                  0 Collision fragments
   0 Good (1 coll) frames                 0 ValidUnderSize frames
   0 Good (>1 coll) frames                0 InvalidOverSize frames
   0 Deferred frames                     0 ValidOverSize frames
   0 Gold frames dropped                  0 FcsErr frames
   0 Gold frames truncated
   0 Gold frames successful
   0 1 collision frames
   0 2 collision frames
   0 3 collision frames
   0 4 collision frames
   0 5 collision frames
   0 6 collision frames
   0 7 collision frames
   0 8 collision frames
   0 9 collision frames
   0 10 collision frames
```

```
show controllers ethernet-controller
```

```

0 11 collision frames
0 12 collision frames
0 13 collision frames
0 14 collision frames
0 15 collision frames
0 Excess collision frames

```

LAST UPDATE 850 msec AGO

Table 10: Transmit Field Descriptions

Field	Description
Total bytes	The total number of bytes sent on an interface.
Unicast Frames	The total number of frames sent to unicast addresses.
Unicast bytes	The total number of bytes sent to unicast addresses.
Multicast frames	The total number of frames sent to multicast addresses.
Multicast bytes	The total number of bytes sent to multicast addresses.
Broadcast frames	The total number of frames sent to broadcast addresses.
Broadcast bytes	The total number of bytes sent to broadcast addresses.
System FCS error frames	The total number of frames that fail the Frame Check Sequence (FCS).
MacUnderrun frames	The total number of frames that have MAC Underrun errors.
Pause frames	The total number of pause frames sent on an interface.
Cos x Pause frames	The total number of class of service (CoS) x pause frames sent on an interface.
Oam frames	The total number of Ethernet Operations, Administration, and Maintenance (OAM) frames sent on an interface.
Minimum size frames	The number of frames that are the minimum allowed frame size.
65 to 127 byte frames	The total number of frames sent on an interface that are 65 to 127 bytes.
128 to 255 byte frames	The total number of frames sent on an interface that are 128 to 255 bytes.
256 to 511 byte frames	The total number of frames sent on an interface that are 256 to 511 bytes.
512 to 1023 byte frames	The total number of frames sent on an interface that are 512 to 1023 bytes.
1024 to 1518 byte frames	The total number of frames sent on an interface that are 1024 to 1518 bytes.
1519 to 2047 byte frames	The total number of frames sent on an interface that are 1519 to 2047 bytes.
2048 to 4095 byte frames	The total number of frames sent on an interface that are 2048 to 4095 bytes.
4096 to 8191 byte frames	The total number of frames sent on an interface that are 4096 to 8191 bytes.

Field	Description
8192 to 16383 byte frames	The total number of frames sent on an interface that are 8192 to 16383 bytes.
16384 to 32767 byte frames	The total number of frames sent on an interface that are 16384 to 32767 bytes.
> 32768 byte frames	The total number of frames sent on an interface that are greater than 32768 bytes.
Late collision frames	After a frame is sent, the number of frames dropped because late collisions were detected while the frame was sent.
Excess defer frames	The number of frames that are not sent after the time exceeds the maximum-packet time.
Good (1 coll) frames	The number of frames that are successfully sent on an interface after one collision occurs. This value does not include the number of frames that are not successfully sent after one collision occurs.
Good (>1 coll) frames	The number of frames that are successfully sent on an interface after more than one collision occurs. This value does not include the number of frames that are not successfully sent after more than one collision occurs.
Deferred frames	The number of frames that are not sent after the time exceeds 2*maximum-packet time.
Gold frames dropped	The number of gold frames that are dropped.
Gold frames truncated	The number of gold frames that are truncated.
Gold frames successful	The number of gold frames that are successful.
1 collision frames	The number of frames that are successfully sent on an interface after one collision occurs.
2 collision frames	The number of frames that are successfully sent on an interface after two collisions occur.
3 collision frames	The number of frames that are successfully sent on an interface after three collisions occur.
4 collision frames	The number of frames that are successfully sent on an interface after four collisions occur.
5 collision frames	The number of frames that are successfully sent on an interface after five collisions occur.
6 collision frames	The number of frames that are successfully sent on an interface after six collisions occur.
7 collision frames	The number of frames that are successfully sent on an interface after seven collisions occur.

Field	Description
8 collision frames	The number of frames that are successfully sent on an interface after eight collisions occur.
9 collision frames	The number of frames that are successfully sent on an interface after nine collisions occur.
10 collision frames	The number of frames that are successfully sent on an interface after ten collisions occur.
11 collision frames	The number of frames that are successfully sent on an interface after 11 collisions occur.
12 collision frames	The number of frames that are successfully sent on an interface after 12 collisions occur.
13 collision frames	The number of frames that are successfully sent on an interface after 13 collisions occur.
14 collision frames	The number of frames that are successfully sent on an interface after 14 collisions occur.
15 collision frames	The number of frames that are successfully sent on an interface after 15 collisions occur.
Excess collisions	The number of frames that could not be sent on an interface after 16 collisions occur.

Table 11: Transmit Field Descriptions

Field	Description
Bytes	The total number of bytes sent on an interface.
Unicast Frames	The total number of frames sent to unicast addresses.
Multicast frames	The total number of frames sent to multicast addresses.
Broadcast frames	The total number of frames sent to broadcast addresses.
Too old frames	The number of frames dropped on the egress port because the packet aged out.
Deferred frames	The number of frames that are not sent after the time exceeds 2*maximum-packet time.
MTU exceeded frames	The number of frames that are larger than the maximum allowed frame size.
1 collision frames	The number of frames that are successfully sent on an interface after one collision occurs.
2 collision frames	The number of frames that are successfully sent on an interface after two collisions occur.

Field	Description
3 collision frames	The number of frames that are successfully sent on an interface after three collisions occur.
4 collision frames	The number of frames that are successfully sent on an interface after four collisions occur.
5 collision frames	The number of frames that are successfully sent on an interface after five collisions occur.
6 collision frames	The number of frames that are successfully sent on an interface after six collisions occur.
7 collision frames	The number of frames that are successfully sent on an interface after seven collisions occur.
8 collision frames	The number of frames that are successfully sent on an interface after eight collisions occur.
9 collision frames	The number of frames that are successfully sent on an interface after nine collisions occur.
10 collision frames	The number of frames that are successfully sent on an interface after ten collisions occur.
11 collision frames	The number of frames that are successfully sent on an interface after 11 collisions occur.
12 collision frames	The number of frames that are successfully sent on an interface after 12 collisions occur.
13 collision frames	The number of frames that are successfully sent on an interface after 13 collisions occur.
14 collision frames	The number of frames that are successfully sent on an interface after 14 collisions occur.
15 collision frames	The number of frames that are successfully sent on an interface after 15 collisions occur.
Excessive collisions	The number of frames that could not be sent on an interface after 16 collisions occur.
Late collisions	After a frame is sent, the number of frames dropped because late collisions were detected while the frame was sent.
VLAN discard frames	The number of frames dropped on an interface because the CFI ¹ bit is set.
Excess defer frames	The number of frames that are not sent after the time exceeds the maximum-packet time.
64 byte frames	The total number of frames sent on an interface that are 64 bytes.
127 byte frames	The total number of frames sent on an interface that are from 65 to 127 bytes.

Field	Description
255 byte frames	The total number of frames sent on an interface that are from 128 to 255 bytes.
511 byte frames	The total number of frames sent on an interface that are from 256 to 511 bytes.
1023 byte frames	The total number of frames sent on an interface that are from 512 to 1023 bytes.
1518 byte frames	The total number of frames sent on an interface that are from 1024 to 1518 bytes.
Too large frames	The number of frames sent on an interface that are larger than the maximum allowed frame size.
Good (1 coll) frames	The number of frames that are successfully sent on an interface after one collision occurs. This value does not include the number of frames that are not successfully sent after one collision occurs.

¹ CFI = Canonical Format Indicator

Table 12: Receive Field Descriptions

Field	Description
Total Bytes	The total amount of memory (in bytes) used by frames received on an interface, including the FCS ² value and the incorrectly formed frames. This value excludes the frame header bits.
Unicast frames	The total number of frames successfully received on the interface that are directed to unicast addresses.
Unicast bytes	The total amount of memory (in bytes) used by unicast frames received on an interface, including the FCS value and the incorrectly formed frames. This value excludes the frame header bits.
Multicast frames	The total amount of memory (in bytes) used by multicast frames received on an interface, including the FCS value and the incorrectly formed frames. This value excludes the frame header bits.
Multicast bytes	The total number of bytes successfully received on the interface that are directed to multicast addresses.
Broadcast frames	The total number of frames successfully received on an interface that are directed to broadcast addresses.
Broadcast bytes	The total amount of memory (in bytes) used by broadcast frames received on an interface, including the FCS value and the incorrectly formed frames. This value excludes the frame header bits.
IpgViolation frames	The total number of frames with an interpacket gap (IPG) violation.
MacOverrun frames	The total number of frames with MacOverrun errors.
Pause frames	The total number of pause frames received on an interface.

Field	Description
Cos x Pause frames	The total number of class of service (CoS) x pause frames received on an interface.
OamProcessed	The total number of Ethernet Operations, Administration, and Maintenance (OAM) frames that are processed on an interface.
OamDropped	The total number of Ethernet Operations, Administration, and Maintenance (OAM) frames that are dropped on an interface.
Minimum size frames	The total number of frames that are the minimum frame size.
65 to 127 byte frames	The total number of frames that are from 65 to 127 bytes.
128 to 255 byte frames	The total number of frames that are from 128 to 255 bytes.
256 to 511 byte frames	The total number of frames that are from 256 to 511 bytes.
512 to 1023 byte frames	The total number of frames that are from 512 to 1023 bytes.
1024 to 1518 byte frames	The total number of frames that are from 1024 to 1518 bytes.
1519 to 2047 byte frames	The total number of frames that are from 1519 to 2047 bytes.
2048 to 4095 byte frames	The total number of frames that are from 2048 to 4095 bytes.
4096 to 8191 byte frames	The total number of frames that are from 4096 to 8191 bytes.
8192 to 16383 byte frames	The total number of frames that are from 8192 to 16383 bytes.
16384 to 32767 byte frames	The total number of frames that are from 16384 to 32767 bytes.
> 32768 byte frames	The total number of frames that are greater than 32768 bytes.
Symbol error frames	The number of frames received on an interface that have symbol errors.
Collision fragments	The number of collision fragments received on an interface.
Valid undersize frames	The number of frames received on an interface that are smaller than 64 bytes (or 68 bytes for VLAN-tagged frames) and that have valid FCS values. The frame size includes the FCS bits but excludes the frame header bits.
Invalid oversize frames	The number of frames received that were larger than maximum allowed maximum transmission unit (MTU) size (including the FCS bits and excluding the frame header) and that have either an FCS error or an alignment error.
Valid oversize frames	The number of frames received on an interface that are larger than the maximum allowed frame size and have valid FCS values. The frame size includes the FCS value but does not include the VLAN tag.
FcsErr frames	The total number of frames received on an interface that have a valid length (in bytes) but do not have the correct FCS values.

² FCS = frame check sequence

This is an example of output from the **show controllers ethernet-controller phy** command for a specific interface:

```
Device# show controllers ethernet-controller gigabitethernet1/0/2 phy
Gi1/0/2 (gpn: 2, port-number: 2)
-----
0000 : 1140 Control Register           : 0001 0001 0100 0000
0001 : 7949 Control STATUS             : 0111 1001 0100 1001
0002 : 0141 Phy ID 1                   : 0000 0001 0100 0001
0003 : 0EE0 Phy ID 2                   : 0000 1110 1110 0000
0004 : 03E1 Auto-Negotiation Advertisement : 0000 0011 1110 0001
0005 : 0000 Auto-Negotiation Link Partner : 0000 0000 0000 0000
0006 : 0004 Auto-Negotiation Expansion Reg : 0000 0000 0000 0100
0007 : 2001 Next Page Transmit Register  : 0010 0000 0000 0001
0008 : 0000 Link Partner Next page Register : 0000 0000 0000 0000
0010 : 3B60 PHY Specific Control        : 0011 1011 0110 0000
0011 : 8010 PHY Specific Status         : 1000 0000 0001 0000
0012 : 6404 PHY Specific Interrupt Enable : 0110 0100 0000 0100
0013 : 0000 PHY Specific Interrupt Status : 0000 0000 0000 0000
```

show controllers utilization

To display bandwidth utilization, use the **show controllers utilization** command in EXEC mode.

show controllers [*interface-id*] **utilization**

Syntax Description	<i>interface-id</i> (Optional) ID of the physical interface.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	User EXEC Privileged EXEC
----------------------	------------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This is an example of output from the **show controllers utilization** command:

```
Device> show controllers utilization
Port          Receive Utilization  Transmit Utilization
Gi1/0/1             0                   0
Gi1/0/2             0                   0
Gi1/0/3             0                   0
Gi1/0/4             0                   0
Gi1/0/5             0                   0
Gi1/0/6             0                   0
Gi1/0/7             0                   0
<output truncated>
Gi2/0/1             0                   0
Gi2/0/2             0                   0
<output truncated>
Total Ports : 48
Switch Receive Bandwidth Percentage Utilization : 0
Switch Transmit Bandwidth Percentage Utilization : 0

Average Switch Percentage Utilization : 0
```

This is an example of output from the **show controllers utilization** command on a specific port:

```
Device> show controllers gigabitethernet1/0/1 utilization
Receive Bandwidth Percentage Utilization : 0
Transmit Bandwidth Percentage Utilization : 0
```

Table 13: Show controllers utilization Field Descriptions

Field	Description
Receive Bandwidth Percentage Utilization	Displays the received bandwidth usage of the switch, which is the sum of the received traffic on all the ports divided by the switch receive capacity.

Field	Description
Transmit Bandwidth Percentage Utilization	Displays the transmitted bandwidth usage of the switch, which is the sum of the transmitted traffic on all the ports divided it by the switch transmit capacity.
Average Switch Percentage Utilization	Displays the average of the transmitted and received bandwidth usage of the switch.

show eee

To display Energy Efficient Ethernet (EEE) information for an interface, use the **show eee** command in EXEC mode.

show eee {**capabilities**| **status**} **interface** *interface-id*

Syntax Description	capabilities	Displays EEE capabilities for the specified interface.
	status	Displays EEE status information for the specified interface.
	interface <i>interface-id</i>	Specifies the interface for which to display EEE capabilities or status information.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You can enable EEE on devices that support low power idle (LPI) mode. Such devices can save power by entering LPI mode during periods of low power utilization. In LPI mode, systems on both ends of the link can save power by shutting down certain services. EEE provides the protocol needed to transition into and out of LPI mode in a way that is transparent to upper layer protocols and applications.

To check if an interface is EEE capable, use the **show eee capabilities** command. You can enable EEE on an interface that is EEE capable by using the **power efficient-ethernet auto** interface configuration command.

To view the EEE status, LPI status, and wake error count information for an interface, use the **show eee status** command.

This is an example of output from the **show eee capabilities** command on an interface where EEE is enabled:

```
Device# show eee capabilities interface gigabitethernet1/0/1
Gi1/0/1
    EEE(efficient-ethernet):  yes (100-Tx and 1000T auto)
    Link Partner              :  yes (100-Tx and 1000T auto)
```

This is an example of output from the **show eee capabilities** command on an interface where EEE is not enabled:

```
Device# show eee capabilities interface gigabitethernet2/0/1
Gi2/0/1
    EEE(efficient-ethernet):  not enabled
```

```
Link Partner          : not enabled
```

This is an example of output from the **show eee status** command on an interface where EEE is enabled and operational. The table that follows describes the fields in the display.

```
Device# show eee status interface gigabitethernet1/0/4
Gil/0/4 is up
  EEE (efficient-ethernet) : Operational
  Rx LPI Status            : Received
  Tx LPI Status            : Received
```

This is an example of output from the **show eee status** command on an interface where EEE is operational and the ports are in low power save mode:

```
Device# show eee status interface gigabitethernet1/0/3
Gil/0/3 is up
  EEE (efficient-ethernet) : Operational
  Rx LPI Status            : Low Power
  Tx LPI Status            : Low Power
  Wake Error Count         : 0
```

This is an example of output from the **show eee status** command on an interface where EEE is not enabled because a remote link partner is incompatible with EEE:

```
Device# show eee status interface gigabitethernet1/0/3
Gil/0/3 is down
  EEE (efficient-ethernet) : Disagreed
  Rx LPI Status            : None
  Tx LPI Status            : None
  Wake Error Count         : 0
```

Table 14: show eee status Field Descriptions

Field	Description
EEE (efficient-ethernet)	<p>The EEE status for the interface. This field can have any of the following values:</p> <ul style="list-style-type: none"> • N/A—The port is not capable of EEE. • Disabled—The port EEE is disabled. • Disagreed—The port EEE is not set because a remote link partner might be incompatible with EEE; either it is not EEE capable, or its EEE setting is incompatible. • Operational—The port EEE is enabled and operating. <p>If the interface speed is configured as 10 Mbps, EEE is disabled internally. When the interface speed moves back to auto, 100 Mbps or 1000 Mbps, EEE becomes active again.</p>

Field	Description
Rx/Tx LPI Status	<p>The Low Power Idle (LPI) status for the link partner. These fields can have any of the following values:</p> <ul style="list-style-type: none">• N/A—The port is not capable of EEE.• Interrupted—The link partner is in the process of moving to low power mode.• Low Power—The link partner is in low power mode.• None—EEE is disabled or not capable at the link partner side.• Received—The link partner is in low power mode and there is traffic activity. <p>If an interface is configured as half-duplex, the LPI status is None, which means the interface cannot be in low power mode until it is configured as full-duplex.</p>
Wake Error Count	<p>The number of PHY wake-up faults that have occurred. A wake-up fault can occur when EEE is enabled and the connection to the link partner is broken.</p> <p>This information is useful for PHY debugging.</p>

show env

To display fan, temperature, and power information, use the **show env** command in EXEC mode.

```
show env {all | fan | power [{all | switch [stack-member-number]}] | stack [stack-member-number] |
temperature [status]}
```

Syntax Description	
all	Displays the fan and temperature environmental status and the status of the internal power supplies.
fan	Displays the switch fan status.
power	Displays the internal power status of the active switch.
all	(Optional) Displays the status of all the internal power supplies in a standalone switch when the command is entered on the switch, or in all the stack members when the command is entered on the stack masteractive switch.
switch	(Optional) Displays the status of the internal power supplies for each switch in the stack or for the specified switch. This keyword is available only on stacking-capable switches.
<i>stack-member-number</i>	(Optional) Number of the stack member for which to display the status of the internal power supplies or the environmental status. The range is 1 to 9.
stack	Displays all environmental status for each switch in the stack or for the specified switch. This keyword is available only on stacking-capable switches.
temperature	Displays the switch temperature status.
status	(Optional) Displays the switch internal temperature (not the external temperature) and the threshold values.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use the **show env** EXEC command to display the information for the switch being accessed—a standalone switch or the stack masteractive switch. Use this command with the **stack** and **switch** keywords to display all information for the stack or for the specified stack member.

If you enter the **show env temperature status** command, the command output shows the switch temperature state and the threshold level.

You can also use the **show env temperature** command to display the switch temperature status. The command output shows the green and yellow states as *OK* and the red state as *FAULTY*. If you enter the **show env all** command, the command output is the same as the **show env temperature status** command output.

Examples

This is an example of output from the **show env all** command:

```
Device>show env all
Switch 1 FAN 1 is OK
Switch 1 FAN 2 is OK
Switch 1 FAN 3 is OK
FAN PS-1 is OK
FAN PS-2 is NOT PRESENT
Switch 1: SYSTEM TEMPERATURE is OK
SW  PID                      Serial#      Status          Sys Pwr  PoE Pwr  Watts
--  -
1A  PWR-C2-250WAC              LIT16372A1M OK             Good      Good     250
1B  Not Present
```

This is an example of output from the **show env fan** command:

```
Device>show env fan
Switch 1 FAN 1 is OK
Switch 1 FAN 2 is OK
Switch 1 FAN 3 is OK
FAN PS-1 is NOT PRESENT
FAN PS-2 is OK
```

This is an example of output from the **show env power all** command on the stack masteractive switch:

```
Device# show env power all
SW  PID                      Serial#      Status          Sys Pwr  PoE Pwr  Watts
--  -
1A  PWR-C2-250WAC              LIT16372A1M OK             Good      Good     250
1B  Not Present
```

This is an example of output from the **show env stack** command on the stack masteractive switch:

```
Device> show env stack
SWITCH: 1
Switch 1 FAN 1 is OK
Switch 1 FAN 2 is OK
Switch 1 FAN 3 is OK
FAN PS-1 is NOT PRESENT
FAN PS-2 is OK
Switch 1: SYSTEM TEMPERATURE is OK
Temperature Value: 28 Degree Celsius
Temperature State: GREEN
Yellow Threshold : 41 Degree Celsius
Red Threshold   : 56 Degree Celsius
```

This example shows how to display the temperature value, state, and the threshold values on a standalone switch. The table describes the temperature states in the command output.

```

Device> show env temperature status
Temperature Value: 33 Degree Celsius
Temperature State: GREEN
Yellow Threshold : 65 Degree Celsius
Red Threshold   : 75 Degree Celsius

```

Table 15: States in the show env temperature status Command Output

State	Description
Green	The switch temperature is in the <i>normal</i> operating range.
Yellow	The temperature is in the <i>warning</i> range. You should check the external temperature around the switch.
Red	The temperature is in the <i>critical</i> range. The switch might not run properly if the temperature is in this range.

show errdisable detect

To display error-disabled detection status, use the **show errdisable detect** command in EXEC mode.

show errdisable detect

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines A gbic-invalid error reason refers to an invalid small form-factor pluggable (SFP) module. The error-disable reasons in the command output are listed in alphabetical order. The mode column shows how error-disable is configured for each feature.

You can configure error-disabled detection in these modes:

- port mode—The entire physical port is error-disabled if a violation occurs.
- vlan mode—The VLAN is error-disabled if a violation occurs.
- port/vlan mode—The entire physical port is error-disabled on some ports and is per-VLAN error-disabled on other ports.

show errdisable recovery

To display the error-disabled recovery timer information, use the **show errdisable recovery** command in EXEC mode.

show errdisable recovery

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines A gbic-invalid error-disable reason refers to an invalid small form-factor pluggable (SFP) module interface.



Note Though visible in the output, the unicast-flood field is not valid.

This is an example of output from the **show errdisable recovery** command:

show interfaces

To display the administrative and operational status of all interfaces or for a specified interface, use the **show interfaces** command in privileged EXEC mode.

```
show interfaces [{interface-id | vlan vlan-id}] [{accounting | capabilities [module number] | debounce | description | etherchannel | flowcontrol | pruning | stats | status [{err-disabled}] | trunk}]
```

Syntax Description

<i>interface-id</i>	(Optional) ID of the interface. Valid interfaces include physical ports (including type, stack member for stacking-capable switches, module, and port number) and port channels. The port channel range is 1 to 48.
vlan <i>vlan-id</i>	(Optional) VLAN identification. The range is 1 to 4094.
accounting	(Optional) Displays accounting information on the interface, including active protocols and input and output packets and octets. Note The display shows only packets processed in software; hardware-switched packets do not appear.
capabilities	(Optional) Displays the capabilities of all interfaces or the specified interface, including the features and options that you can configure on the interface. Though visible in the command line help, this option is not available for VLAN IDs.
module <i>number</i>	(Optional) Displays capabilities of all interfaces on the switch or specified stack member. This option is not available if you entered a specific interface ID.
debounce	(Optional) Displays port debounce timer information for an interface.
description	(Optional) Displays the administrative status and description set for an interface.
etherchannel	(Optional) Displays interface EtherChannel information.
flowcontrol	(Optional) Displays interface flow control information.
mtu	(Optional) Displays the MTU for each interface or for the specified interface.
pruning	(Optional) Displays trunk VTP pruning information for the interface.
stats	(Optional) Displays the input and output packets by switching the path for the interface.

status	(Optional) Displays the status of the interface. A status of unsupported in the Type field means that a non-Cisco small form-factor pluggable (SFP) module is inserted in the module slot.
err-disabled	(Optional) Displays interfaces in an error-disabled state.
trunk	(Optional) Displays interface trunk information. If you do not specify an interface, only information for active trunking ports appears.



Note Though visible in the command-line help strings, the **crb**, **fair-queue**, **irb**, **mac-accounting**, **precedence**, **random-detect**, and **rate-limit** keywords are not supported.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **show interfaces capabilities** command with different keywords has these results:

- Use the **show interface capabilities module *number*** command to display the capabilities of all interfaces on that switch in the stack. If there is no switch with that module number in the stack, there is no output.
- Use the **show interfaces *interface-id* capabilities** to display the capabilities of the specified interface.
- Use the **show interfaces capabilities** (with no module number or interface ID) to display the capabilities of all interfaces in the stack.

This is an example of output from the **show interfaces** command for an interface on stack member 3:

```
Device# show interfaces gigabitethernet3/0/2
GigabitEthernet3/0/2 is down, line protocol is down (notconnect)
  Hardware is Gigabit Ethernet, address is 2037.064d.4381 (bia 2037.064d.4381)
  MTU 1500 bytes, BW 1000000 Kbit/sec, DLY 10 usec,
    reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation ARPA, loopback not set
  Keepalive set (10 sec)
  Auto-duplex, Auto-speed, media type is 10/100/1000BaseTX
  input flow-control is off, output flow-control is unsupported
  ARP type: ARPA, ARP Timeout 04:00:00
  Last input never, output never, output hang never
  Last clearing of "show interface" counters never
  Input queue: 0/2000/0/0 (size/max/drops/flushes); Total output drops: 0
  Queueing strategy: fifo
  Output queue: 0/40 (size/max)
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes, 0 no buffer
    Received 0 broadcasts (0 multicasts)
```

```

0 runts, 0 giants, 0 throttles
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
0 watchdog, 0 multicast, 0 pause input
0 input packets with dribble condition detected
0 packets output, 0 bytes, 0 underruns
0 output errors, 0 collisions, 1 interface resets
0 unknown protocol drops
0 babbles, 0 late collision, 0 deferred
0 lost carrier, 0 no carrier, 0 pause output
0 output buffer failures, 0 output buffers swapped out

```

This is an example of output from the **show interfaces accounting** command:

This is an example of output from the **show interfaces capabilities** command for an interface:

This is an example of output from the **show interfaces interface description** command when the interface has been described as *Connects to Marketing* by using the **description** interface configuration command:

```

Device# show interfaces gigabitethernet1/0/2 description
Interface          Status      Protocol Description
Gil/0/2            up          down      Connects to Marketing

```

This is an example of output from the **show interfaces etherchannel** command when port channels are configured on the switch:

```

Device# show interfaces etherchannel
----
Port-channel34:
Age of the Port-channel = 28d:18h:51m:46s
Logical slot/port      = 12/34          Number of ports = 0
GC                     = 0x00000000      HotStandBy port = null
Passive port list      =
Port state             = Port-channel L3-Ag Ag-Not-Inuse
Protocol               = -
Port security          = Disabled

```

This is an example of output from the **show interfaces interface-id pruning** command when pruning is enabled in the VTP domain:

```

Device# show interfaces gigabitethernet1/0/2 pruning
Port      Vlans pruned for lack of request by neighbor
Gil/0/2   3,4

Port      Vlans traffic requested of neighbor
Gil/0/2   1-3

```

This is an example of output from the **show interfaces stats** command for a specified VLAN interface:

```

Device# show interfaces vlan 1 stats
Switching path  Pkts In   Chars In   Pkts Out   Chars Out
Processor       1165354   136205310  570800     91731594
Route cache     0         0          0          0
Total          1165354   136205310  570800     91731594

```

This is an example of partial output from the **show interfaces status** command. It displays the status of all interfaces:

This is an example of output from the **show interfaces interface-id status** command:

```
Device# show interfaces gigabitethernet1/0/20 status
Port      Name              Status      Vlan      Duplex  Speed      Type
Gi1/0/20  seTX              notconnect  1         auto    auto 10/100/1000Ba
```

This is an example of output from the **show interfaces status err-disabled** command. It displays the status of interfaces in the error-disabled state:

```
Device# show interfaces status err-disabled
Port      Name              Status      Reason
Gi1/0/2   err-disabled     gbic-invalid
Gi2/0/3   err-disabled     dtp-flap
```

This is an example of output from the **show interfaces interface-id pruning** command:

```
Device# show interfaces gigabitethernet1/0/2 pruning
Port Vlans pruned for lack of request by neighbor
```

This is an example of output from the **show interfaces interface-id trunk** command. It displays trunking information for the port.

```
Device# show interfaces gigabitethernet1/0/1 trunk
Port      Mode              Encapsulation  Status      Native vlan
Gi1/0/1   on                802.1q         other       10

Port      Vlans allowed on trunk
Gi1/0/1   none

Port      Vlans allowed and active in management domain
Gi1/0/1   none

Port      Vlans in spanning tree forwarding state and not pruned
Gi1/0/1   none
```

show interfaces counters

To display various counters for the switch or for a specific interface, use the **show interfaces counters** command in privileged EXEC mode.

```
show interfaces [interface-id] counters [{errors | etherchannel | module stack-member-number | protocol status | trunk}]
```

Syntax Description		
<i>interface-id</i>	(Optional) ID of the physical interface, including type, stack member (stacking-capable switches only) module, and port number.	
errors	(Optional) Displays error counters.	
etherchannel	(Optional) Displays EtherChannel counters, including octets, broadcast packets, multicast packets, and unicast packets received and sent.	
module <i>stack-member-number</i>	(Optional) Displays counters for the specified stack member.	Note In this command, the module keyword refers to the stack member number. The module number that is part of the interface ID is always zero.
protocol status	(Optional) Displays the status of protocols enabled on interfaces.	
trunk	(Optional) Displays trunk counters.	



Note Though visible in the command-line help string, the **vlan** *vlan-id* keyword is not supported.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines If you do not enter any keywords, all counters for all interfaces are included.

This is an example of partial output from the **show interfaces counters** command. It displays all counters for the switch.

```
Device# show interfaces counters
Port          InOctets    InUcastPkts  InMcastPkts  InBcastPkts
Gi1/0/1       0            0             0             0
Gi1/0/2       0            0             0             0
Gi1/0/3       95285341    43115        1178430      1950
Gi1/0/4       0            0             0             0
```

<output truncated>

This is an example of partial output from the **show interfaces counters module** command for stack member 2. It displays all counters for the specified switch in the stack.

```
Device# show interfaces counters module 2
Port          InOctets    InUcastPkts  InMcastPkts  InBcastPkts
Gi1/0/1       520         2            0            0
Gi1/0/2       520         2            0            0
Gi1/0/3       520         2            0            0
Gi1/0/4       520         2            0            0
```

<output truncated>

This is an example of partial output from the **show interfaces counters protocol status** command for all interfaces:

```
Device# show interfaces counters protocol status
Protocols allocated:
Vlan1: Other, IP
Vlan20: Other, IP, ARP
Vlan30: Other, IP, ARP
Vlan40: Other, IP, ARP
Vlan50: Other, IP, ARP
Vlan60: Other, IP, ARP
Vlan70: Other, IP, ARP
Vlan80: Other, IP, ARP
Vlan90: Other, IP, ARP
Vlan900: Other, IP, ARP
Vlan3000: Other, IP
Vlan3500: Other, IP
GigabitEthernet1/0/1: Other, IP, ARP, CDP
GigabitEthernet1/0/2: Other, IP
GigabitEthernet1/0/3: Other, IP
GigabitEthernet1/0/4: Other, IP
GigabitEthernet1/0/5: Other, IP
GigabitEthernet1/0/6: Other, IP
GigabitEthernet1/0/7: Other, IP
GigabitEthernet1/0/8: Other, IP
GigabitEthernet1/0/9: Other, IP
GigabitEthernet1/0/10: Other, IP, CDP
```

<output truncated>

This is an example of output from the **show interfaces counters trunk** command. It displays trunk counters for all interfaces.

```
Device# show interfaces counters trunk
Port          TrunkFramesTx  TrunkFramesRx  WrongEncap
Gi1/0/1       0              0              0
Gi1/0/2       0              0              0
Gi1/0/3       80678         0              0
Gi1/0/4       82320         0              0
Gi1/0/5       0              0              0
```

<output truncated>

show interfaces switchport

To display the administrative and operational status of a switching (nonrouting) port, including port blocking and port protection settings, use the **show interfaces switchport** command in privileged EXEC mode.

show interfaces [*interface-id*] **switchport** [{*module number*}]

Syntax Description	<p><i>interface-id</i> (Optional) ID of the interface. Valid interfaces include physical ports (including type, stack member for stacking-capable switches, module, and port number) and port channels. The port channel range is 1 to 48.</p> <hr/> <p>module number (Optional) Displays switchport configuration of all interfaces on the switch or specified stack member.</p> <p>This option is not available if you entered a specific interface ID.</p>				
Command Default	None				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

Usage Guidelines Use the **show interface switchport module number** command to display the switch port characteristics of all interfaces on that switch in the stack. If there is no switch with that module number in the stack, there is no output.

This is an example of output from the **show interfaces switchport** command for a port. The table that follows describes the fields in the display.



Note Private VLANs are not supported in this release, so those fields are not applicable.

```
Device# show interfaces gigabitethernet1/0/1 switchport
Name: Gi1/0/1
Switchport: Enabled
Administrative Mode: trunk
Operational Mode: down
Administrative Trunking Encapsulation: dot1q
Negotiation of Trunking: On
Access Mode VLAN: 1 (default)
Trunking Native Mode VLAN: 10 (VLAN0010)
Administrative Native VLAN tagging: enabled
Voice VLAN: none
Administrative private-vlan host-association: none
Administrative private-vlan mapping: none
Administrative private-vlan trunk native VLAN: none
Administrative private-vlan trunk Native VLAN tagging: enabled
Administrative private-vlan trunk encapsulation: dot1q
Administrative private-vlan trunk normal VLANs: none
Administrative private-vlan trunk associations: none
```

show interfaces switchport

```

Administrative private-vlan trunk mappings: none
Operational private-vlan: none
Trunking VLANs Enabled: 11-20
Pruning VLANs Enabled: 2-1001
Capture Mode Disabled
Capture VLANs Allowed: ALL

```

```

Protected: false
Unknown unicast blocked: disabled
Unknown multicast blocked: disabled
Appliance trust: none

```

Field	Description
Name	Displays the port name.
Switchport	Displays the administrative and operational status of the port. In this display, the port is in switchport mode.
Administrative Mode Operational Mode	Displays the administrative and operational modes.
Administrative Trunking Encapsulation Operational Trunking Encapsulation Negotiation of Trunking	Displays the administrative and operational encapsulation method and whether trunking negotiation is enabled.
Access Mode VLAN	Displays the VLAN ID to which the port is configured.
Trunking Native Mode VLAN Trunking VLANs Enabled Trunking VLANs Active	Lists the VLAN ID of the trunk that is in native mode. Lists the allowed VLANs on the trunk. Lists the active VLANs on the trunk.
Pruning VLANs Enabled	Lists the VLANs that are pruning-eligible.
Protected	Displays whether or not protected port is enabled (True) or disabled (False) on the interface.
Unknown unicast blocked Unknown multicast blocked	Displays whether or not unknown multicast and unknown unicast traffic is blocked on the interface.
Voice VLAN	Displays the VLAN ID on which voice VLAN is enabled.
Appliance trust	Displays the class of service (CoS) setting of the data packets of the IP phone.

show interfaces transceiver

To display the physical properties of a small form-factor pluggable (SFP) module interface, use the **show interfaces transceiver** command in EXEC mode.

show interfaces [*interface-id*] **transceiver** [{**detail** | **module number** | **properties** | **supported-list**}]

Syntax Description	
<i>interface-id</i>	(Optional) ID of the physical interface, including type, stack member (stacking-capable switches only) module, and port number.
detail	(Optional) Displays calibration properties, including high and low numbers and any alarm information for any Digital Optical Monitoring (DoM)-capable transceiver if one is installed in the switch.
module number	(Optional) Limits display to interfaces on module on the switch. The range is 1 to 9. This option is not available if you entered a specific interface ID.
properties	(Optional) Displays speed, duplex, and inline power settings on an interface.
supported-list	(Optional) Lists all supported transceivers.

Command Modes	
	User EXEC
	Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Examples

This is an example of output from the **show interfaces *interface-id* transceiver properties** command:

```
Device# show interfaces transceiver
```

```
If device is externally calibrated, only calibrated values are printed.
++ : high alarm, + : high warning, - : low warning, -- : low alarm.
NA or N/A: not applicable, Tx: transmit, Rx: receive.
mA: milliamperes, dBm: decibels (milliwatts).
```

Port	Temperature (Celsius)	Voltage (Volts)	Current (mA)	Optical Tx Power (dBm)	Optical Rx Power (dBm)
Gi5/1/2	42.9	3.28	22.1	-5.4	-8.1
Te5/1/3	32.0	3.28	19.8	2.4	-4.2

```
Device# show interfaces gigabitethernet1/1/1 transceiver properties
Name : Gi1/1/1
Administrative Speed: auto
Operational Speed: auto
Administrative Duplex: auto
```

show interfaces transceiver

```
Administrative Power Inline: enable
Operational Duplex: auto
Administrative Auto-MDIX: off
Operational Auto-MDIX: off
```

This is an example of output from the **show interfaces *interface-id* transceiver detail** command:

```
Device# show interfaces gigabitethernet1/1/1 transceiver detail
ITU Channel not available (Wavelength not available),
Transceiver is internally calibrated.
mA:milliamperes, dBm:decibels (milliwatts), N/A:not applicable.
++:high alarm, +:high warning, -:low warning, -- :low alarm.
A2D readouts (if they differ), are reported in parentheses.
The threshold values are uncalibrated.
```

Port	Temperature (Celsius)	High Alarm Threshold (Celsius)	High Warn Threshold (Celsius)	Low Warn Threshold (Celsius)	Low Alarm Threshold (Celsius)
Gil/1/1	29.9	74.0	70.0	0.0	-4.0

Port	Voltage (Volts)	High Alarm Threshold (Volts)	High Warn Threshold (Volts)	Low Warn Threshold (Volts)	Low Alarm Threshold (Volts)
Gil/1/1	3.28	3.60	3.50	3.10	3.00

Port	Optical Transmit Power (dBm)	High Alarm Threshold (dBm)	High Warn Threshold (dBm)	Low Warn Threshold (dBm)	Low Alarm Threshold (dBm)
Gil/1/1	1.8	7.9	3.9	0.0	-4.0

Port	Optical Receive Power (dBm)	High Alarm Threshold (dBm)	High Warn Threshold (dBm)	Low Warn Threshold (dBm)	Low Alarm Threshold (dBm)
Gil/1/1	-23.5	-5.0	-9.0	-28.2	-32.2

```
Device# show interfaces transceiver supported-list
Transceiver Type          Cisco p/n min version
                           supporting DOM
```

DWDM GBIC	ALL
DWDM SFP	ALL
RX only WDM GBIC	ALL
DWDM XENPAK	ALL
DWDM X2	ALL
DWDM XFP	ALL
CWDM GBIC	NONE
CWDM X2	ALL
CWDM XFP	ALL
XENPAK ZR	ALL
X2 ZR	ALL
XFP ZR	ALL
Rx_only_WDM_XENPAK	ALL
XENPAK_ER	10-1888-04
X2_ER	ALL
XFP_ER	ALL
XENPAK_LR	10-1838-04
X2_LR	ALL
XFP_LR	ALL

```

XENPAK_LW          ALL
X2_LW             ALL
XFP_LW           NONE
XENPAK_SR        NONE
X2_SR            ALL
XFP_SR           ALL
XENPAK_LX4       NONE
X2_LX4           NONE
XFP_LX4          NONE
XENPAK_CX4       NONE
X2_CX4           NONE
XFP_CX4          NONE
SX_GBIC          NONE
LX_GBIC          NONE
ZX_GBIC          NONE
CWDM_SFP         ALL
Rx_only_WDM_SFP NONE
SX_SFP           ALL
LX_SFP           ALL
ZX_SFP           ALL
EX_SFP           ALL
SX_SFP           NONE
LX_SFP           NONE
ZX_SFP           NONE
GigE_BX_U_SFP   NONE
GigE_BX_D_SFP   ALL
X2_LRM           ALL
SR_SFPP          ALL
LR_SFPP          ALL
LRM_SFPP         ALL
ER_SFPP          ALL
ZR_SFPP          ALL
DWDM_SFPP        ALL
GigE_BX_40U_SFP ALL
GigE_BX_40D_SFP ALL
GigE_BX_40DA_SFP ALL
GigE_BX_80U_SFP ALL
GigE_BX_80D_SFP ALL
GIG_BXU_SFPP     ALL
GIG_BXD_SFPP     ALL
GIG_BX40U_SFPP   ALL
GIG_BX40D_SFPP   ALL
GigE_Dual_Rate_LX_SFP ALL
CWDM_SFPP        ALL
CPAK_SR10        ALL
CPAK_LR4         ALL
QSFP_LR          ALL
QSFP_SR          ALL

```

Related Commands

Command	Description
transceiver type all	Enters the transceiver type configuration mode.
monitoring	Enables digital optical monitoring.

show memory platform

To display memory statistics of a platform, use the **show memory platform** command in privileged EXEC mode.

show memory platform [{**compressed-swap** | **information** | **page-merging**}]

Syntax Description	
compressed-swap	(Optional) Displays platform memory compressed-swap information.
information	(Optional) Displays general information about the platform.
page-merging	(Optional) Displays platform memory page-merging information.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines Prior to Cisco IOS XE Denali 16.3.1, the Free Memory displayed in the command output was obtained from the underlying Linux kernel. This value was not accurate because some memory chunks that was available for use was not considered as free memory.

In Cisco IOS XE Denali 16.3.1, the free memory is accurately computed and displayed in the Free Memory field of the command output.

Examples

The following is sample output from the **show memory platform** command:

```
Switch# show memory platform

Virtual memory   : 12874653696
Pages resident  : 627041
Major page faults: 2220
Minor page faults: 2348631

Architecture    : mips64
Memory (kB)
  Physical      : 3976852
  Total         : 3976852
  Used          : 2761276
  Free          : 1215576
  Active        : 2128196
  Inactive      : 1581856
  Inact-dirty   : 0
  Inact-clean   : 0
  Dirty         : 0
  AnonPages     : 1294984
  Bounce        : 0
  Cached        : 1978168
  Commit Limit  : 1988424
  Committed As  : 3343324
  High Total    : 0
  High Free     : 0
```

```

Low Total      : 3976852
Low Free       : 1215576
Mapped         : 516316
NFS Unstable   : 0
Page Tables    : 17124
Slab           : 0
VMmalloc Chunk : 1069542588
VMmalloc Total : 1069547512
VMmalloc Used  : 2588
Writeback      : 0
HugePages Total : 0
HugePages Free : 0
HugePages Rsvd : 0
HugePage Size  : 2048

Swap (kB)
Total          : 0
Used           : 0
Free           : 0
Cached         : 0

Buffers (kB)   : 437136

Load Average
1-Min          : 1.04
5-Min          : 1.16
15-Min         : 0.94

```

The following is sample output from the **show memory platform information** command:

Device# **show memory platform information**

```

Virtual memory : 12870438912
Pages resident : 626833
Major page faults: 2222
Minor page faults: 2362455

Architecture   : mips64
Memory (kB)
Physical       : 3976852
Total          : 3976852
Used           : 2761224
Free           : 1215628
Active         : 2128060
Inactive       : 1584444
Inact-dirty    : 0
Inact-clean    : 0
Dirty          : 284
AnonPages      : 1294656
Bounce         : 0
Cached         : 1979644
Commit Limit   : 1988424
Committed As   : 3342184
High Total     : 0
High Free      : 0
Low Total      : 3976852
Low Free       : 1215628
Mapped         : 516212
NFS Unstable   : 0
Page Tables    : 17096
Slab           : 0
VMmalloc Chunk : 1069542588
VMmalloc Total : 1069547512

```

show memory platform

```
VMmalloc Used : 2588
Writeback     : 0
HugePages Total: 0
HugePages Free : 0
HugePages Rsvd : 0
HugePage Size : 2048
```

```
Swap (kB)
Total      : 0
Used       : 0
Free       : 0
Cached     : 0
```

```
Buffers (kB) : 438228
```

```
Load Average
1-Min      : 1.54
5-Min      : 1.27
15-Min     : 0.99
```

show module

To display module information such as switch number, model number, serial number, hardware revision number, software version, MAC address and so on, use this command in user EXEC or privileged EXEC mode.

```
show module [{switch-num}]
```

Syntax Description	<i>switch-num</i> (Optional) Number of the switch.				
Command Default	None				
Command Modes	User EXEC (>) Privileged EXEC (#)				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Denali 16.1.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Denali 16.1.1	This command was introduced.
Release	Modification				
Cisco IOS XE Denali 16.1.1	This command was introduced.				
Usage Guidelines	Entering the show module command without the <i>switch-num</i> argument is the same as entering the show module all command.				
Examples	This example shows how to display information for all the modules on a Cisco Catalyst 3850 Series switch:				

show mgmt-infra trace messages ilpower

To display inline power messages within a trace buffer, use the **show mgmt-infra trace messages ilpower** command in privileged EXEC mode.

show mgmt-infra trace messages ilpower [*switch stack-member-number*]

Syntax Description	switch <i>stack-member-number</i> (Optional) Specifies the stack member number for which to display inline power messages within a trace buffer.	
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This is an output example from the **show mgmt-infra trace messages ilpower** command:

```
Device# show mgmt-infra trace messages ilpower
[10/23/12 14:05:10.984 UTC 1 3] Initialized inline power system configuration fo
r slot 1.
[10/23/12 14:05:10.984 UTC 2 3] Initialized inline power system configuration fo
r slot 2.
[10/23/12 14:05:10.984 UTC 3 3] Initialized inline power system configuration fo
r slot 3.
[10/23/12 14:05:10.984 UTC 4 3] Initialized inline power system configuration fo
r slot 4.
[10/23/12 14:05:10.984 UTC 5 3] Initialized inline power system configuration fo
r slot 5.
[10/23/12 14:05:10.984 UTC 6 3] Initialized inline power system configuration fo
r slot 6.
[10/23/12 14:05:10.984 UTC 7 3] Initialized inline power system configuration fo
r slot 7.
[10/23/12 14:05:10.984 UTC 8 3] Initialized inline power system configuration fo
r slot 8.
[10/23/12 14:05:10.984 UTC 9 3] Initialized inline power system configuration fo
r slot 9.
[10/23/12 14:05:10.984 UTC a 3] Inline power subsystem initialized.
[10/23/12 14:05:18.908 UTC b 264] Create new power pool for slot 1
[10/23/12 14:05:18.909 UTC c 264] Set total inline power to 450 for slot 1
[10/23/12 14:05:20.273 UTC d 3] PoE is not supported on .
[10/23/12 14:05:20.288 UTC e 3] PoE is not supported on .
[10/23/12 14:05:20.299 UTC f 3] PoE is not supported on .
[10/23/12 14:05:20.311 UTC 10 3] PoE is not supported on .
[10/23/12 14:05:20.373 UTC 11 98] Inline power process post for switch 1
[10/23/12 14:05:20.373 UTC 12 98] PoE post passed on switch 1
[10/23/12 14:05:20.379 UTC 13 3] Slot #1: PoE initialization for board id 16387
[10/23/12 14:05:20.379 UTC 14 3] Set total inline power to 450 for slot 1
[10/23/12 14:05:20.379 UTC 15 3] Gil/0/1 port config Initialized
[10/23/12 14:05:20.379 UTC 16 3] Interface Gil/0/1 initialization done.
[10/23/12 14:05:20.380 UTC 17 3] Gil/0/24 port config Initialized
[10/23/12 14:05:20.380 UTC 18 3] Interface Gil/0/24 initialization done.
[10/23/12 14:05:20.380 UTC 19 3] Slot #1: initialization done.
```

```
[10/23/12 14:05:50.440 UTC 1a 3] Slot #1: PoE initialization for board id 16387  
[10/23/12 14:05:50.440 UTC 1b 3] Duplicate init event
```

show mgmt-infra trace messages ilpower-ha

To display inline power high availability messages within a trace buffer, use the **show mgmt-infra trace messages ilpower-ha** command in privileged EXEC mode.

show mgmt-infra trace messages ilpower-ha [**switch** *stack-member-number*]

Syntax Description	switch <i>stack-member-number</i> (Optional) Specifies the stack member number for which to display inline power messages within a trace buffer.				
Command Default	None				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th style="border-bottom: 1px solid black;">Release</th> <th style="border-bottom: 1px solid black;">Modification</th> </tr> </thead> <tbody> <tr> <td style="border-bottom: 1px solid black;">Cisco IOS XE 3.3SE</td> <td style="border-bottom: 1px solid black;">This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

This is an output example from the **show mgmt-infra trace messages ilpower-ha** command:

```
Device# show mgmt-infra trace messages ilpower-ha
[10/23/12 14:04:48.087 UTC 1 3] NG3K_ILPOWER_HA: Created NGWC ILP CF client successfully.
```

show mgmt-infra trace messages platform-mgr-poe

To display platform manager Power over Ethernet (PoE) messages within a trace buffer, use the **show mgmt-infra trace messages platform-mgr-poe** privileged EXEC command.

show mgmt-infra trace messages platform-mgr-poe [*switch stack-member-number*]

Syntax Description	switch <i>stack-member-number</i> (Optional) Specifies the stack member number for which to display messages within a trace buffer.				
Command Default	None				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

This is an example of partial output from the **show mgmt-infra trace messages platform-mgr-poe** command:

```
Device# show mgmt-infra trace messages platform-mgr-poe
[10/23/12 14:04:06.431 UTC 1 5495] PoE Info: get power controller param sent:
[10/23/12 14:04:06.431 UTC 2 5495] PoE Info: POE_SHUT sent for port 1 (0:0)
[10/23/12 14:04:06.431 UTC 3 5495] PoE Info: POE_SHUT sent for port 2 (0:1)
[10/23/12 14:04:06.431 UTC 4 5495] PoE Info: POE_SHUT sent for port 3 (0:2)
[10/23/12 14:04:06.431 UTC 5 5495] PoE Info: POE_SHUT sent for port 4 (0:3)
[10/23/12 14:04:06.431 UTC 6 5495] PoE Info: POE_SHUT sent for port 5 (0:4)
[10/23/12 14:04:06.431 UTC 7 5495] PoE Info: POE_SHUT sent for port 6 (0:5)
[10/23/12 14:04:06.431 UTC 8 5495] PoE Info: POE_SHUT sent for port 7 (0:6)
[10/23/12 14:04:06.431 UTC 9 5495] PoE Info: POE_SHUT sent for port 8 (0:7)
[10/23/12 14:04:06.431 UTC a 5495] PoE Info: POE_SHUT sent for port 9 (0:8)
[10/23/12 14:04:06.431 UTC b 5495] PoE Info: POE_SHUT sent for port 10 (0:9)
[10/23/12 14:04:06.431 UTC c 5495] PoE Info: POE_SHUT sent for port 11 (0:10)
[10/23/12 14:04:06.431 UTC d 5495] PoE Info: POE_SHUT sent for port 12 (0:11)
[10/23/12 14:04:06.431 UTC e 5495] PoE Info: POE_SHUT sent for port 13 (e:0)
[10/23/12 14:04:06.431 UTC f 5495] PoE Info: POE_SHUT sent for port 14 (e:1)
[10/23/12 14:04:06.431 UTC 10 5495] PoE Info: POE_SHUT sent for port 15 (e:2)
[10/23/12 14:04:06.431 UTC 11 5495] PoE Info: POE_SHUT sent for port 16 (e:3)
[10/23/12 14:04:06.431 UTC 12 5495] PoE Info: POE_SHUT sent for port 17 (e:4)
[10/23/12 14:04:06.431 UTC 13 5495] PoE Info: POE_SHUT sent for port 18 (e:5)
[10/23/12 14:04:06.431 UTC 14 5495] PoE Info: POE_SHUT sent for port 19 (e:6)
[10/23/12 14:04:06.431 UTC 15 5495] PoE Info: POE_SHUT sent for port 20 (e:7)
[10/23/12 14:04:06.431 UTC 16 5495] PoE Info: POE_SHUT sent for port 21 (e:8)
[10/23/12 14:04:06.431 UTC 17 5495] PoE Info: POE_SHUT sent for port 22 (e:9)
[10/23/12 14:04:06.431 UTC 18 5495] PoE Info: POE_SHUT sent for port 23 (e:10)
```

show network-policy profile

To display the network-policy profiles, use the **show network policy profile** command in privileged EXEC mode.

show network-policy profile [*profile-number*]

Syntax Description

profile-number (Optional) Displays the network-policy profile number. If no profile is entered, all network-policy profiles appear.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

This is an example of output from the **show network-policy profile** command:

```
Device# show network-policy profile
Network Policy Profile 60
  Interface:
    none
```

show platform CAPWAP summary

To display the tunnel identifier and the type all the CAPWAP tunnels established by the controller to the access points and other mobility controllers, use the **show platform CAPWAP summary** command.

show platform CAPWAP summary

Syntax Description This command has no arguments or keywords.

Command Default

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example displays the tunnel identifier and details:

```
Device# show platform capwap summary
Tunnel ID | Type | Src IP | Dst IP | SPrt | DPrt | S | A
-----
0x0088498000000983 data 9.6.44.61 9.12.138.101 5247 41894 1 1
0x00966dc000000010 data 9.6.44.61 9.6.47.101 5247 62526 1 2
0x00938e800000095b data 9.6.44.61 9.12.138.100 5247 45697 1 1
0x00ab1a8000000bd1 data 9.6.44.61 9.12.139.101 5247 38906 1 0
0x00896e40000000bd data 9.6.44.61 9.12.136.100 5247 1836 1 1
```

show platform forward

Use the **show platform forward** privileged EXEC command for an interface to display how the hardware would forward a frame that matches the specified parameters.

```
show platform forward interface-id [ vlan vlan-id ] src-macdst-mac [ l3protocol-id ] [ ipv6
| sap | snap ] [ cos cos [ ip src-ip dst-ip [ frag field ] [ dscp dscp ] { l4protocol-id |
icmp icmp-type icmp-code | igmp igmp-version igmp-type | sctp src-port dst-port | tcp src-post
dst-port flags | udp src-port dst-port ] } [ | { begin | exclude | include } expression ]
```

Syntax Description

<i>interface-id</i>	The input physical interface, the port on which the packet comes in to the switch (including type and port number).
vlan <i>vlan-id</i>	(Optional) Input VLAN ID. The range is 1 to 4094. If not specified, and the input interface is not a routed port, the default is 1.
<i>src-mac</i>	48-bit source MAC address.
<i>dst-mac</i>	48-bit destination MAC address.
ipv6	(Optional) IPv6 frame. This keyword is available only if the switch is running the IP services image.
sap	(Optional) Service access point (SAP) encapsulation type.
snap	(Optional) Subnetwork Access Protocol (SNAP) encapsulation type.
cos <i>cos</i>	(Optional) Class of service (CoS) value of the frame. The range is 0 to 7.
ip <i>src-ip</i> <i>dst-ip</i>	(Optional, but required for IP packets) Source and destination IP addresses in dotted decimal notation.
frag <i>field</i>	(Optional) The IP fragment field for a fragmented IP packet. The range is 0 to 65535.
dscp <i>dscp</i>	(Optional) Differentiated Services Code Point (DSCP) field in the IP header. The range is 0 to 63.
<i>l4protocol-id</i>	The numeric value of the Layer 4 protocol field in the IP header. The range is 0 to 255. For example, 47 is generic routing encapsulation (GRE), and 89 is Open Shortest Path First (OSPF). If the protocol is TCP, User Datagram Protocol (UDP), Internet Control Message Protocol (ICMP), or Internet Group Management Protocol (IGMP), you should use the appropriate keyword instead of a numeric value.
icmp <i>icmp-type</i> <i>icmp-code</i>	ICMP parameters. The <i>icmp-type</i> and <i>icmp-code</i> ranges are 0 to 255.
igmp <i>igmp-version</i> <i>igmp-type</i>	IGMP parameters. The <i>igmp-version</i> range is 1 to 15; the <i>igmp-type</i> range is 0 to 15.
sctp <i>src-port</i> <i>dst-port</i>	Stream Control Transmission Protocol (SCTP) parameters. The ranges for the SCTP source and destination ports are 0 to 65535.

tcp <i>src-port dst-port flags</i>	TCP parameters: TCP source port, destination port, and the numeric value of the TCP flags byte in the header. The src-port and dst-port ranges are 0 to 65535. The flag range is 0 to 1024.
udp <i>src-port dst-port</i>	UDP parameters. The src-port and dst-port ranges are 0 to 65535.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified <i>expression</i> .
<i>expression</i>	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was reintroduced.

Usage Guidelines You should use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

show platform hardware fed switch forward

To display device-specific hardware information, use the **show platform hardware fed switch** *switch_number* command.

This topic elaborates only the forwarding-specific options, that is, the options available with the **show platform hardware fed switch** {*switch_num* | **active** | **standby**} **forward summary** command.

The output of the **show platform hardware fed switch** *switch_number* **forward summary** displays all the details about the forwarding decision taken for the packet.

show platform hardware fed switch {*switch_num* | **active** | **standby**} **forward summary**

Syntax Description	<p>switch {<i>switch_num</i> active standby }</p> <p>The switch for which you want to display information. You have the following options :</p> <ul style="list-style-type: none"> • <i>switch_num</i>—ID of the switch. • active—Displays information relating to the active switch. • standby—Displays information relating to the standby switch, if available.
	<p>forward summary Displays packet forwarding information.</p>

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Do not use this command unless a technical support representative asks you to. Use this command only when you are working directly with a technical support representative while troubleshooting a problem.

Fields displayed in the command output are explained below.

- **Station Index** : The Station Index is the result of the layer 2 lookup and points to a station descriptor which provides the following:
 - **Destination Index** : Determines the egress port(s) to which the packets should be sent to. Global Port Number(GPN) can be used as the destination index. A destination index with 15 down to 12 bits set indicates the GPN to be used. For example, destination index - 0xF04E corresponds to GPN - 78 (0x4e).
 - **Rewrite Index** : Determines what needs to be done with the packets. For layer 2 switching, this is typically a bridging action
 - **Flexible Lookup Pipeline Stages(FPS)** : Indicates the forwarding decision that was taken for the packet - routing or bridging
 - **Replication Bit Map** : Determines if the packets should be sent to CPU or stack
 - Local Data Copy = 1

- Remote Data copy = 0
- Local CPU Copy = 0
- Remote CPU Copy = 0

Example

This is an example of output from the **show platform hardware fed switch** {*switch_num* | **active** | **standby** } **forward summary** command.

```
Device#show platform hardware fed switch 1 forward summary
```

```
Time: Fri Sep 16 08:25:00 PDT 2016
```

```
Incomming Packet Details:
```

```
###[ Ethernet ]###
```

```
dst      = 00:51:0f:f2:0e:11
src      = 00:1d:01:85:ba:22
type     = ARP
```

```
###[ ARP ]###
```

```
hwtype   = 0x1
ptype    = IPv4
hwlen    = 6
plen     = 4
op       = is-at
hwsrc    = 00:1d:01:85:ba:22
psrc     = 10.10.1.33
hwdst    = 00:51:0f:f2:0e:11
pdst     = 10.10.1.1
```

```
Ingress:
```

```
Switch           : 1
Port              : GigabitEthernet1/0/1
Global Port Number : 1
Local Port Number : 1
Asic Port Number  : 21
ASIC Number       : 0
STP state         :
                  blkLrn31to0: 0xffdffffd
                  blkFwd31to0: 0xffdffffd
Vlan              : 1
Station Descriptor : 170
DestIndex         : 0xF009
DestModIndex      : 2
RewriteIndex      : 2
Forwarding Decision: FPS 2A L2 Destination
```

```
Replication Bitmap:
```

```
Local CPU copy   : 0
Local Data copy  : 1
Remote CPU copy  : 0
Remote Data copy : 0
```

```
Egress:
```

```
Switch           : 1
Outgoing Port     : GigabitEthernet1/0/9
Global Port Number : 9
ASIC Number       : 0
Vlan              : 1
```

show platform resources

To display platform resource information, use the **show platform resources** command in privileged EXEC mode.

show platform resources

This command has no arguments or keywords.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines The output of this command displays the used memory, which is total memory minus the accurate free memory.

Example

The following is sample output from the **show platform resources** command:

```
Switch# show platform resources
```

```
**State Acronym: H - Healthy, W - Warning, C - Critical
```

Resource State	Usage	Max	Warning	Critical
Control Processor H	7.20%	100%	90%	95%
DRAM H	2701MB (69%)	3883MB	90%	95%

show platform software ilpower

To display the inline power details of all the PoE ports on the device, use the **show platform software ilpower** command in privileged EXEC mode.

```
show platform software ilpower {details | port {GigabitEthernet interface-number } | system slot-number }
```

Syntax Description	details	Displays inline power details for all the interfaces.
	port	Displays inline power port configuration.
	GigabitEthernet <i>interface-number</i>	The GigabitEthernet interface number. Values range from 0 to 9.
	system <i>slot-number</i>	Displays inline power system configuration.
Command Modes	Privileged EXEC (#)	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.2	This command was modified. The keyword details argument was added.
	Cisco IOS XE Denali 16.1.1	The command was introduced.

Examples

The following is sample output from the **show platform software ilpower details** command:

```
Device# show platform software ilpower details
ILP Port Configuration for interface Gi1/0/1
  Initialization Done:    Yes
  ILP Supported:         Yes
  ILP Enabled:           Yes
  POST:                  Yes
  Detect On:              No
  Powered Device Detected:      No
  Powered Device Class Done:    No
  Cisco Powered Device:        No
  Power is On:                 No
  Power Denied:                No
  Powered Device Type:         Null
  Powerd Device Class:         Null
  Power State:                 NULL
  Current State:               NGWC_ILP_DETECTING_S
  Previous State:              NGWC_ILP_SHUT_OFF_S
  Requested Power in milli watts: 0
  Short Circuit Detected:      0
  Short Circuit Count:         0
  Cisco Powerd Device Detect Count: 0
  Spare Pair mode:            0
  IEEE Detect:                 Stopped
  IEEE Short:                  Stopped
  Link Down:                   Stopped
  Voltage sense:              Stopped
  Spare Pair Architecture:     1
```

show platform software ilpower

```
Signal Pair Power allocation in milli watts: 0
Spare Pair Power On: 0
Powered Device power state: 0
Timer:
  Power Good: Stopped
  Power Denied: Stopped
  Cisco Powered Device Detect: Stopped
```

show platform software process list

To display the list of running processes on a platform, use the **show platform software process list** command in privileged EXEC mode.

```
show platform software process list switch {switch-number | active | standby} {0 | F0 | R0}
[{name process-name | process-id process-ID | sort memory | summary}]
```

Syntax Description	
switch <i>switch-number</i>	Displays information about the switch. Valid values for <i>switch-number</i> argument are from 0 to 9.
active	Displays information about the active instance of the switch.
standby	Displays information about the standby instance of the switch.
0	Displays information about the shared port adapters (SPA) Interface Processor slot 0.
F0	Displays information about the Embedded Service Processor (ESP) slot 0.
R0	Displays information about the Route Processor (RP) slot 0.
name <i>process-name</i>	(Optional) Displays information about the specified process. Enter the process name.
process-id <i>process-ID</i>	(Optional) Displays information about the specified process ID. Enter the process ID.
sort	(Optional) Displays information sorted according to processes.
memory	(Optional) Displays information sorted according to memory.
summary	(Optional) Displays a summary of the process memory of the host device.

Command Modes Privileged EXE (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	The command was introduced.

Usage Guidelines Prior to Cisco IOS XE Denali 16.3.1, the Free Memory displayed in the command output was obtained from the underlying Linux kernel. This value was not accurate because some memory chunks that was available for use was not considered as free memory.

In Cisco IOS XE Denali 16.3.1, the free memory is accurately computed and displayed in the Free Memory field of the command output.

Examples

The following is sample output from the **show platform software process list switch active R0** command:

```
Switch# show platform software process list switch active R0 summary

Total number of processes: 278
```

show platform software process list

```

Running           : 2
Sleeping          : 276
Disk sleeping     : 0
Zombies           : 0
Stopped           : 0
Paging            : 0

Up time           : 8318
Idle time         : 0
User time         : 216809
Kernel time      : 78931

Virtual memory    : 12933324800
Pages resident   : 634061
Major page faults: 2228
Minor page faults: 3491744

Architecture     : mips64
Memory (kB)
  Physical        : 3976852
  Total           : 3976852
  Used            : 2766952
  Free            : 1209900
  Active          : 2141344
  Inactive        : 1589672
  Inact-dirty     : 0
  Inact-clean     : 0
  Dirty           : 4
  AnonPages       : 1306800
  Bounce          : 0
  Cached          : 1984688
  Commit Limit    : 1988424
  Committed As    : 3358528
  High Total      : 0
  High Free       : 0
  Low Total       : 3976852
  Low Free        : 1209900
  Mapped          : 520528
  NFS Unstable    : 0
  Page Tables     : 17328
  Slab            : 0
  VMmalloc Chunk  : 1069542588
  VMmalloc Total  : 1069547512
  VMmalloc Used   : 2588
  Writeback       : 0
  HugePages Total: 0
  HugePages Free  : 0
  HugePages Rsvd  : 0
  HugePage Size   : 2048

Swap (kB)
  Total           : 0
  Used            : 0
  Free            : 0
  Cached          : 0

Buffers (kB)     : 439528

Load Average
  1-Min           : 1.13
  5-Min           : 1.18
  15-Min          : 0.92

```

The table below describes the significant fields shown in the displays.

Table 16: show platform software process list Field Descriptions

Field	Description
Name	Displays the command name associated with the process. Different threads in the same process may have different command values.
Pid	Displays the process ID that is used by the operating system to identify and keep track of the processes.
PPid	Displays process ID of the parent process.
Group Id	Displays the group ID
Status	Displays the process status in human readable form.
Priority	Displays the negated scheduling priority.
Size	Prior to Cisco IOS XE Gibraltar 16.10.1: Displays Virtual Memory size. From Cisco IOS XE Gibraltar 16.10.1 onwards: Displays the Resident Set Size (RSS) that shows how much memory is allocated to that process in the RAM.

show platform software process slot switch

To display platform software process switch information, use the **show platform software process slot switch** command in privileged EXEC mode.

```
show platform software process slot switch {switch-number | active | standby} {0 | F0 | R0}
monitor [{cycles no-of-times [{interval delay [{lines number}]}}]
```

Syntax Description

<i>switch-number</i>	Switch number.
active	Specifies the active instance.
standby	Specifies the standby instance.
0	Specifies the shared port adapter (SPA) interface processor slot 0.
F0	Specifies the Embedded Service Processor (ESP) slot 0.
R0	Specifies the Route Processor (RP) slot 0.
monitor	Monitors the running processes.
<i>cycles no-of-times</i>	(Optional) Sets the number of times to run monitor command. Valid values are from 1 to 4294967295. The default is 5.
<i>interval delay</i>	(Optional) Sets a delay after each . Valid values are from 0 to 300. The default is 3.
<i>lines number</i>	(Optional) Sets the number of lines of output displayed. Valid values are from 0 to 512. The default is 0.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines

The output of the **show platform software process slot switch** and **show processes cpu platform monitor location** commands display the output of the Linux **top** command. The output of these commands display Free memory and Used memory as displayed by the Linux **top** command. The values displayed for the Free memory and Used memory by these commands do not match the values displayed by the output of other platform-memory related CLIs.

Examples

The following is sample output from the **show platform software process slot switch active R0 monitor** command:

```
Switch# show platform software process slot switch active R0 monitor
```

```
top - 00:01:52 up 1 day, 11:20, 0 users, load average: 0.50, 0.68, 0.83
Tasks: 311 total, 2 running, 309 sleeping, 0 stopped, 0 zombie
Cpu(s): 7.4%us, 3.3%sy, 0.0%ni, 89.2%id, 0.0%wa, 0.0%hi, 0.1%si, 0.0%st
Mem: 3976844k total, 3955036k used, 21808k free, 419312k buffers
Swap: 0k total, 0k used, 0k free, 1946764k cached
```

```

  PID USER      PR  NI  VIRT  RES  SHR S %CPU %MEM    TIME+  COMMAND
  5693 root       20   0  3448 1368  912 R   7  0.0   0:00.07 top
 17546 root       20   0 2044m 244m  79m S   7  6.3 186:49.08 fed main event
 18662 root       20   0 1806m 678m 263m S   5 17.5 215:32.38 linux_iods-imag
 30276 root       20   0  171m  42m  33m S   5  1.1 125:06.77 repm
 17835 root       20   0  935m  74m  63m S   4  1.9  82:28.31 sif_mgr
 18534 root       20   0  182m 150m  10m S   2  3.9   8:12.08 smand
     1 root       20   0  8440 4740 2184 S   0  0.1   0:09.52 systemd
     2 root       20   0     0     0     0 S   0  0.0   0:00.00 kthreadd
     3 root       20   0     0     0     0 S   0  0.0   0:02.86 ksoftirqd/0
     5 root        0 -20     0     0     0 S   0  0.0   0:00.00 kworker/0:0H
     7 root       RT   0     0     0     0 S   0  0.0   0:01.44 migration/0
     8 root       20   0     0     0     0 S   0  0.0   0:00.00 rcu_bh
     9 root       20   0     0     0     0 S   0  0.0   0:23.08 rcu_sched
    10 root       20   0     0     0     0 S   0  0.0   0:58.04 rcuc/0
    11 root       20   0     0     0     0 S   0  0.0 21:35.60 rcuc/1
    12 root       RT   0     0     0     0 S   0  0.0   0:01.33 migration/1

```

Related Commands

Command	Description
show processes cpu platform monitor location	Displays information about the CPU utilization of the IOS-XE processes.

show platform software status control-processor

To display platform software control-processor status, use the **show platform software status control-processor** command in privileged EXEC mode.

show platform software status control-processor [{brief}]

Syntax Description	brief (Optional) Displays a summary of the platform control-processor status.
---------------------------	--

Command Modes	Privileged EXEC (#)
----------------------	---------------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines	Prior to Cisco IOS XE Denali 16.3.1, the Free Memory displayed in the command output was obtained from the underlying Linux kernel. This value was not accurate because some memory chunks that was available for use was not considered as free memory.
-------------------------	--

In Cisco IOS XE Denali 16.3.1, the free memory is accurately computed and displayed in the Free Memory field of the command output.

Examples

The following is sample output from the **show platform memory software status control-processor** command:

```
Switch# show platform software status control-processor

2-RP0: online, statistics updated 7 seconds ago
Load Average: healthy
  1-Min: 1.00, status: healthy, under 5.00
  5-Min: 1.21, status: healthy, under 5.00
 15-Min: 0.90, status: healthy, under 5.00
Memory (kb): healthy
  Total: 3976852
  Used: 2766284 (70%), status: healthy
  Free: 1210568 (30%)
  Committed: 3358008 (84%), under 95%
Per-core Statistics
CPU0: CPU Utilization (percentage of time spent)
  User: 4.40, System: 1.70, Nice: 0.00, Idle: 93.80
  IRQ: 0.00, SIRQ: 0.10, IOWait: 0.00
CPU1: CPU Utilization (percentage of time spent)
  User: 3.80, System: 1.20, Nice: 0.00, Idle: 94.90
  IRQ: 0.00, SIRQ: 0.10, IOWait: 0.00
CPU2: CPU Utilization (percentage of time spent)
  User: 7.00, System: 1.10, Nice: 0.00, Idle: 91.89
  IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU3: CPU Utilization (percentage of time spent)
  User: 4.49, System: 0.69, Nice: 0.00, Idle: 94.80
  IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00

3-RP0: unknown, statistics updated 2 seconds ago
Load Average: healthy
  1-Min: 0.24, status: healthy, under 5.00
  5-Min: 0.27, status: healthy, under 5.00
```

```
15-Min: 0.32, status: healthy, under 5.00
Memory (kb): healthy
  Total: 3976852
  Used: 2706768 (68%), status: healthy
  Free: 1270084 (32%)
  Committed: 3299332 (83%), under 95%
Per-core Statistics
CPU0: CPU Utilization (percentage of time spent)
  User: 4.50, System: 1.20, Nice: 0.00, Idle: 94.20
  IRQ: 0.00, SIRQ: 0.10, IOWait: 0.00
CPU1: CPU Utilization (percentage of time spent)
  User: 5.20, System: 0.50, Nice: 0.00, Idle: 94.29
  IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU2: CPU Utilization (percentage of time spent)
  User: 3.60, System: 0.70, Nice: 0.00, Idle: 95.69
  IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU3: CPU Utilization (percentage of time spent)
  User: 3.00, System: 0.60, Nice: 0.00, Idle: 96.39
  IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00

4-RP0: unknown, statistics updated 2 seconds ago
Load Average: healthy
  1-Min: 0.21, status: healthy, under 5.00
  5-Min: 0.24, status: healthy, under 5.00
  15-Min: 0.24, status: healthy, under 5.00
Memory (kb): healthy
  Total: 3976852
  Used: 1452404 (37%), status: healthy
  Free: 2524448 (63%)
  Committed: 1675120 (42%), under 95%
Per-core Statistics
CPU0: CPU Utilization (percentage of time spent)
  User: 2.30, System: 0.40, Nice: 0.00, Idle: 97.30
  IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU1: CPU Utilization (percentage of time spent)
  User: 4.19, System: 0.69, Nice: 0.00, Idle: 95.10
  IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU2: CPU Utilization (percentage of time spent)
  User: 4.79, System: 0.79, Nice: 0.00, Idle: 94.40
  IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU3: CPU Utilization (percentage of time spent)
  User: 2.10, System: 0.40, Nice: 0.00, Idle: 97.50
  IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00

9-RP0: unknown, statistics updated 4 seconds ago
Load Average: healthy
  1-Min: 0.20, status: healthy, under 5.00
  5-Min: 0.35, status: healthy, under 5.00
  15-Min: 0.35, status: healthy, under 5.00
Memory (kb): healthy
  Total: 3976852
  Used: 1451328 (36%), status: healthy
  Free: 2525524 (64%)
  Committed: 1675932 (42%), under 95%
Per-core Statistics
CPU0: CPU Utilization (percentage of time spent)
  User: 1.90, System: 0.50, Nice: 0.00, Idle: 97.60
  IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU1: CPU Utilization (percentage of time spent)
  User: 4.39, System: 0.19, Nice: 0.00, Idle: 95.40
  IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU2: CPU Utilization (percentage of time spent)
  User: 5.70, System: 1.00, Nice: 0.00, Idle: 93.30
  IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
```

show platform software status control-processor

```
CPU3: CPU Utilization (percentage of time spent)
  User:  1.30, System:  0.60, Nice:  0.00, Idle: 98.00
  IRQ:  0.00, SIRQ:  0.10, IOWait: 0.00
```

The following is sample output from the **show platform memory software status control-processor brief** command:

```
Switch# show platform software status control-processor brief
```

Load Average

Slot	Status	1-Min	5-Min	15-Min
2-RP0	Healthy	1.10	1.21	0.91
3-RP0	Healthy	0.23	0.27	0.31
4-RP0	Healthy	0.11	0.21	0.22
9-RP0	Healthy	0.10	0.30	0.34

Memory (kB)

Slot	Status	Total	Used (Pct)	Free (Pct)	Committed (Pct)
2-RP0	Healthy	3976852	2766956 (70%)	1209896 (30%)	3358352 (84%)
3-RP0	Healthy	3976852	2706824 (68%)	1270028 (32%)	3299276 (83%)
4-RP0	Healthy	3976852	1451888 (37%)	2524964 (63%)	1675076 (42%)
9-RP0	Healthy	3976852	1451580 (37%)	2525272 (63%)	1675952 (42%)

CPU Utilization

Slot	CPU	User	System	Nice	Idle	IRQ	SIRQ	IOWait
2-RP0	0	4.10	2.00	0.00	93.80	0.00	0.10	0.00
	1	4.60	1.00	0.00	94.30	0.00	0.10	0.00
	2	6.50	1.10	0.00	92.40	0.00	0.00	0.00
	3	5.59	1.19	0.00	93.20	0.00	0.00	0.00
3-RP0	0	2.80	1.20	0.00	95.90	0.00	0.10	0.00
	1	4.49	1.29	0.00	94.20	0.00	0.00	0.00
	2	5.30	1.60	0.00	93.10	0.00	0.00	0.00
4-RP0	3	5.80	1.20	0.00	93.00	0.00	0.00	0.00
	0	1.30	0.80	0.00	97.89	0.00	0.00	0.00
	1	1.30	0.20	0.00	98.50	0.00	0.00	0.00
9-RP0	2	5.60	0.80	0.00	93.59	0.00	0.00	0.00
	3	5.09	0.19	0.00	94.70	0.00	0.00	0.00
	0	3.99	0.69	0.00	95.30	0.00	0.00	0.00
	1	2.60	0.70	0.00	96.70	0.00	0.00	0.00
9-RP0	2	4.49	0.89	0.00	94.60	0.00	0.00	0.00
	3	2.60	0.20	0.00	97.20	0.00	0.00	0.00

show processes cpu platform monitor

To displays information about the CPU utilization of the IOS-XE processes, use the **show processes cpu platform monitor** command in privileged EXEC mode.

show processes cpu platform monitor location switch {*switch-number* | **active** | **standby**} {**0** | **F0** | **R0**}

Syntax Description	location	Displays information about the Field Replaceable Unit (FRU) location.
	switch	Specifies the switch.
	<i>switch-number</i>	Switch number.
	active	Specifies the active instance.
	standby	Specifies the standby instance.
	0	Specifies the shared port adapter (SPA) interface processor slot 0.
	F0	Specifies the Embedded Service Processor (ESP) slot 0.
	R0	Specifies the Route Processor (RP) slot 0.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines The output of the **show platform software process slot switch** and **show processes cpu platform monitor location** commands display the output of the Linux **top** command. The output of these commands display Free memory and Used memory as displayed by the Linux **top** command. The values displayed for the Free memory and Used memory by these commands do not match the values displayed by the output of other platform-memory related CLIs.

Examples

The following is sample output from the **show processes cpu monitor location switch active R0** command:

```
Switch# show processes cpu platform monitor location switch active R0

top - 00:04:21 up 1 day, 11:22, 0 users, load average: 0.42, 0.60, 0.78
Tasks: 312 total, 4 running, 308 sleeping, 0 stopped, 0 zombie
Cpu(s): 7.4%us, 3.3%sy, 0.0%ni, 89.2%id, 0.0%wa, 0.0%hi, 0.1%si, 0.0%st
Mem: 3976844k total, 3956928k used, 19916k free, 419312k buffers
Swap: 0k total, 0k used, 0k free, 1947036k cached

  PID USER      PR  NI  VIRT  RES  SHR  S  %CPU  %MEM    TIME+  COMMAND
  6294 root        20   0  3448  1368  912  R   9.0   0.0   0:00.07 top
 17546 root        20   0 2044m 244m   79m  S   6.3 187:02.07 fed main event
 30276 root        20   0  171m  42m   33m  S   7.1  1.1 125:15.54 repm
    16 root        20   0     0     0     0  S   5.0   0.0  22:07.92 rcuc/2
    21 root        20   0     0     0     0  R   5.0   0.0  22:13.24 rcuc/3
```

show processes cpu platform monitor

```

18662 root      20    0 1806m 678m 263m R    5 17.5 215:47.59 linux_iosd-imag
   11 root      20    0     0    0    0 S    4  0.0 21:37.41 rcuc/1
10333 root      20    0 6420 3916 1492 S    4  0.1  4:47.03 btrace_rotate.s
   10 root      20    0     0    0    0 S    2  0.0  0:58.13 rcuc/0
 6304 root      20    0   776   12    0 R    2  0.0  0:00.01 ls
17835 root      20    0 935m  74m  63m S    2  1.9 82:34.07 sif_mgr
    1 root      20    0 8440 4740 2184 S    0  0.1  0:09.52 systemd
    2 root      20    0     0    0    0 S    0  0.0  0:00.00 kthreadd
    3 root      20    0     0    0    0 S    0  0.0  0:02.86 ksoftirqd/0
    5 root         0 -20     0    0    0 S    0  0.0  0:00.00 kworker/0:0H
    7 root      RT    0     0    0    0 S    0  0.0  0:01.44 migration/0

```

Related Commands

Command	Description
show platform software process slot switch	Displays platform software process switch information.

show processes memory platform

To display memory usage per Cisco IOS XE process, use the **show processes memory platform** command in privileged EXEC mode.

```
show processes memory platform [{detailed {name process-name | process-id process-ID} [{location | maps [{location}] | smaps [{location}]}] | location | sorted [{location}]}] switch {switch-number | active | standby} {0 | F0 | R0}
```

Syntax Description		
detailed <i>process-name</i>		(Optional) Displays detailed memory information for a specified Cisco IOS XE process.
name <i>process-name</i>		(Optional) Matches the Cisco IOS XE process name.
process-id <i>process-ID</i>		(Optional) Matches the Cisco IOS XE process ID.
location		(Optional) Displays information about the FRU location.
maps		(Optional) Displays memory maps of a process.
smaps		(Optional) Displays smaps of a process.
sorted		(Optional) Displays the sorted output based on the total memory used by Cisco IOS XE processes.
switch <i>switch-number</i>		Displays information about the device.
active		Displays information about the active instance of the switch.
standby		Displays information about the standby instance of the switch.
0		Displays information about the SPA-Inter-Processor slot 0.
F0		Displays information about the Embedded Service Processor (ESP) slot 0.
R0		Displays information about the Route Processor (RP) slot 0.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	The command was introduced.

Usage Guidelines

Prior to Cisco IOS XE Denali 16.3.1, the Free Memory displayed in the command output was obtained from the underlying Linux kernel. This value was not accurate because some memory chunks that was available for use was not considered as free memory.

In Cisco IOS XE Denali 16.3.1, the free memory is accurately computed and displayed in the Free Memory field of the command output.

Examples

The following is sample output from the **show processes memory platform** command:

```
Switch# show processes memory platform

System memory: 3976852K total, 2761580K used, 1215272K free,
Lowest: 1215272K
  Pid  Text      Data  Stack  Dynamic  RSS    Total      Name
-----
    1  1246      4400   132    1308    4400    8328      systemd
   96   233      2796   132     132    2796   12436     systemd-journal
  105   284      1796   132     176    1796    5208     systemd-udev
  707    52      2660   132     172    2660   11688     in.telnetd
  744   968      3264   132    1700    3264    5800      brelay.sh
  835    52      2660   132     172    2660   11688     in.telnetd
  863   968      3264   132    1700    3264    5800      brelay.sh
  928   968      3996   132    2312    3996    6412      reflector.sh
  933   968      3976   132    2312    3976    6412      droputil.sh
  934   968      2140   132     528    2140    4628      oom.sh
  936   173      936    132     132     936    3068      xinetd
  945   968      1472   132     132    1472    4168      libvirtd.sh
  947   592     43164   132   3096    43164  154716     repm
  954    45       932    132     132     932    3132      rpcbind
  986   482      3476   132     132    3476   169288     libvirtd
  988    66       940    132     132     940    2724      rpc.statd
  993   968      928    132     132     928    4232      boothelper_evt.
 1017   21       640    132     132     640    2500      inotifywait
 1089   102      1200   132     132    1200    3328      rpc.mountd
 1328    9      2940   132     148    2940   13844      rotee
 1353   39      532    132     132     532    2336      sleep

!
!
!
```

The following is sample output from the **show processes memory platform information** command:

```
Switch# show processes memory platform location switch active R0

System memory: 3976852K total, 2762844K used, 1214008K free,
Lowest: 1214008K
  Pid  Text      Data  Stack  Dynamic  RSS    Total      Name
-----
    1  1246      4400   132    1308    4400    8328      systemd
   96   233      2796   132     132    2796   12436     systemd-journal
  105   284      1796   132     176    1796    5208     systemd-udev
  707    52      2660   132     172    2660   11688     in.telnetd
  744   968      3264   132    1700    3264    5800      brelay.sh
  835    52      2660   132     172    2660   11688     in.telnetd
  863   968      3264   132    1700    3264    5800      brelay.sh
  928   968      3996   132    2312    3996    6412      reflector.sh
  933   968      3976   132    2312    3976    6412      droputil.sh

!
!
!
```

The following is sample output from the **show processes memory platform sorted** command:

```
Switch# show processes memory platform sorted

System memory: 3976852K total, 2762884K used, 1213968K free,
Lowest: 1213968K
  Pid   Text      Data  Stack  Dynamic    RSS    Total      Name
-----
  9655  3787     264964  136    18004    264964  2675968      wcm
 17261   324     248588  132    103908   248588  2093076    fed main event
  7885 149848    684864  136      80     684864  1853548  linux_iosd-imag
 17891   398     75772  136    1888     75772   958240     sif_mgr
 17067  1087     77912  136    1796     77912   702184     platform_mgr
  4268   391    102084  136    5596    102084  482656     cli_agent
  4856   357     93388  132    3680     93388   340052      dbm
 29842  8722     64428  132    8056     64428   297068     fman_fp_image
  5960  9509     76088  136    3200     76088   287156     fman_rp
!
!
!
```

The following is sample output from the **show processes memory platform sorted location switch active R0** command:

```
Switch# show processes memory platform sorted location switch active R0

System memory: 3976852K total, 2763584K used, 1213268K free,
Lowest: 1213268K
  Pid   Text      Data  Stack  Dynamic    RSS    Total      Name
-----
  9655  3787     264968  136    18004    264968  2675968      wcm
 17261   324     249020  132    103908   249020  2093076    fed main event
  7885 149848    684912  136      80     684912  1853548  linux_iosd-imag
 17891   398     75884  136    1888     75884   958240     sif_mgr
 17067  1087     77820  136    1796     77820   702184     platform_mgr
  4268   391    102084  136    5596    102084  482656     cli_agent
  4856   357     93388  132    3680     93388   340052      dbm
 29842  8722     64428  132    8056     64428   297068     fman_fp_image
  5960  9509     76088  136    3200     76088   287156     fman_rp
!
!
!
```

show power inline

To display the Power over Ethernet (PoE) status for the specified PoE port, the specified stack member, or for all PoE ports in the switch stack, use the **show power inline** command in EXEC mode.

show power inline [{**police** | **priority**}] [{*interface-id* | **module** *stack-member-number*}] [**detail**]

Syntax Description		
police	(Optional) Displays the power policing information about real-time power consumption.	
priority	(Optional) Displays the power inline port priority for each port.	
<i>interface-id</i>	(Optional) ID of the physical interface.	
module <i>stack-member-number</i>	(Optional) Limits the display to ports on the specified stack member. This keyword is supported only on stacking-capable switches.	
detail	(Optional) Displays detailed output of the interface or module.	

Command Modes	
	User EXEC
	Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Examples

This is an example of output from the **show power inline** command. The table that follows describes the output fields.

```
Device> show power inline
Module   Available      Used      Remaining
         (Watts)        (Watts)   (Watts)
-----
1         n/a            n/a       n/a
2         n/a            n/a       n/a
3         1440.0         15.4      1424.6
4         720.0          6.3       713.7
Interface Admin  Oper      Power   Device   Class Max
         (Watts)
-----
Gi3/0/1  auto   off       0.0     n/a      n/a    30.0
Gi3/0/2  auto   off       0.0     n/a      n/a    30.0
Gi3/0/3  auto   off       0.0     n/a      n/a    30.0
Gi3/0/4  auto   off       0.0     n/a      n/a    30.0
Gi3/0/5  auto   off       0.0     n/a      n/a    30.0
Gi3/0/6  auto   off       0.0     n/a      n/a    30.0
Gi3/0/7  auto   off       0.0     n/a      n/a    30.0
Gi3/0/8  auto   off       0.0     n/a      n/a    30.0
Gi3/0/9  auto   off       0.0     n/a      n/a    30.0
Gi3/0/10 auto   off       0.0     n/a      n/a    30.0
```

```

Gi3/0/11 auto off 0.0 n/a n/a 30.0
Gi3/0/12 auto off 0.0 n/a n/a 30.0
<output truncated>

```

This is an example of output from the **show power inline interface-id** command on a switch port:

```

Device> show power inline gigabitethernet1/0/1
Interface Admin Oper Power Device Class Max
              (Watts)
-----
Gi1/0/1 auto off 0.0 n/a n/a 30.0

```

This is an example of output from the **show power inline module switch-number** command on stack member 3. The table that follows describes the output fields.

```

Device> show power inline module 3
Module Available Used Remaining
         (Watts) (Watts) (Watts)
-----
3 865.0 864.0 1.0
Interface Admin Oper Power Device Class Max
              (Watts)
-----
Gi3/0/1 auto power-deny 4.0 n/a n/a 15.4
Gi3/0/2 auto off 0.0 n/a n/a 15.4
Gi3/0/3 auto off 0.0 n/a n/a 15.4
Gi3/0/4 auto off 0.0 n/a n/a 15.4
Gi3/0/5 auto off 0.0 n/a n/a 15.4
Gi3/0/6 auto off 0.0 n/a n/a 15.4
Gi3/0/7 auto off 0.0 n/a n/a 15.4
Gi3/0/8 auto off 0.0 n/a n/a 15.4
Gi3/0/9 auto off 0.0 n/a n/a 15.4
Gi3/0/10 auto off 0.0 n/a n/a 15.4
<output truncated>

```

Table 17: show power inline Field Descriptions

Field	Description
Available	The total amount of configured power ³ on the PoE switch in watts (W).
Used	The amount of configured power that is allocated to PoE ports in watts.
Remaining	The amount of configured power in watts that is not allocated to ports in the system. (Available – Used = Remaining)
Admin	Administration mode: auto, off, static.
Oper	Operating mode: <ul style="list-style-type: none"> • on—The powered device is detected, and power is applied. • off—No PoE is applied. • faulty—Device detection or a powered device is in a faulty state. • power-deny—A powered device is detected, but no PoE is available, or the maximum wattage exceeds the detected powered-device maximum.

Field	Description
Power	The maximum amount of power that is allocated to the powered device in watts. This value is the same as the value in the <i>CutoffPower</i> field in the show power inline police command output.
Device	The device type detected: n/a, unknown, Cisco powered-device, IEEE powered-device, or the name from CDP.
Class	The IEEE classification: n/a or a value from 0 to 4.
Max	The maximum amount of power allocated to the powered device in watts.
AdminPowerMax	The maximum amount power allocated to the powered device in watts when the switch polices the real-time power consumption. This value is the same as the <i>Max</i> field value.
AdminConsumption	The power consumption of the powered device in watts when the switch polices the real-time power consumption. If policing is disabled, this value is the same as the <i>AdminPowerMax</i> field value.

³ The configured power is the power that you manually specify or that the switch specifies by using CDP power negotiation or the IEEE classification, which is different than the real-time power that is monitored with the power sensing feature.

This is an example of output from the **show power inline police** command on a stacking-capable switch:

```
Device> show power inline police
Module   Available   Used   Remaining
         (Watts)    (Watts) (Watts)
-----
1         370.0      0.0    370.0
3         865.0     864.0    1.0

Interface Admin Oper   Admin   Oper   Cutoff Oper
         State State  Police  Police Power  Power
-----
Gi1/0/1  auto  off   none    n/a    n/a    0.0
Gi1/0/2  auto  off   log     n/a    5.4    0.0
Gi1/0/3  auto  off   errdisable n/a    5.4    0.0
Gi1/0/4  off   off   none    n/a    n/a    0.0
Gi1/0/5  off   off   log     n/a    5.4    0.0
Gi1/0/6  off   off   errdisable n/a    5.4    0.0
Gi1/0/7  auto  off   none    n/a    n/a    0.0
Gi1/0/8  auto  off   log     n/a    5.4    0.0
Gi1/0/9  auto  on    none    n/a    n/a    5.1
Gi1/0/10 auto  on    log     ok     5.4    4.2
Gi1/0/11 auto  on    log     log    5.4    5.9
Gi1/0/12 auto  on    errdisable ok     5.4    4.2
Gi1/0/13 auto  errdisable errdisable n/a    5.4    0.0
<output truncated>
```

In the previous example:

- The Gi1/0/1 port is shut down, and policing is not configured.
- The Gi1/0/2 port is shut down, but policing is enabled with a policing action to generate a syslog message.
- The Gi1/0/3 port is shut down, but policing is enabled with a policing action is to shut down the port.

- Device detection is disabled on the Gi1/0/4 port, power is not applied to the port, and policing is disabled.
- Device detection is disabled on the Gi1/0/5 port, and power is not applied to the port, but policing is enabled with a policing action to generate a syslog message.
- Device detection is disabled on the Gi1/0/6 port, and power is not applied to the port, but policing is enabled with a policing action to shut down the port.
- The Gi1/0/7 port is up, and policing is disabled, but the switch does not apply power to the connected device.
- The Gi1/0/8 port is up, and policing is enabled with a policing action to generate a syslog message, but the switch does not apply power to the powered device.
- The Gi1/0/9 port is up and connected to a powered device, and policing is disabled.
- The Gi1/0/10 port is up and connected to a powered device, and policing is enabled with a policing action to generate a syslog message. The policing action does not take effect because the real-time power consumption is less than the cutoff value.
- The Gi1/0/11 port is up and connected to a powered device, and policing is enabled with a policing action to generate a syslog message.
- The Gi1/0/12 port is up and connected to a powered device, and policing is enabled with a policing action to shut down the port. The policing action does not take effect because the real-time power consumption is less than the cutoff value.
- The Gi1/0/13 port is up and connected to a powered device, and policing is enabled with a policing action to shut down the port.

This is an example of output from the **show power inline police interface-id** command on a standalone switch. The table that follows describes the output fields.

```
Device> show power inline police gigabitethernet1/0/1
Interface Admin Oper      Admin      Oper      Cutoff Oper
           State State      Police     Police     Power  Power
-----
Gi1/0/1   auto   off       none       n/a       n/a    0.0
```

Table 18: show power inline police Field Descriptions

Field	Description
Available	The total amount of configured power ⁴ on the switch in watts (W).
Used	The amount of configured power allocated to PoE ports in watts.
Remaining	The amount of configured power in watts that is not allocated to ports in the system. (Available – Used = Remaining)
Admin State	Administration mode: auto, off, static.

Field	Description
Oper State	<p>Operating mode:</p> <ul style="list-style-type: none"> • errdisable—Policing is enabled. • faulty—Device detection on a powered device is in a faulty state. • off—No PoE is applied. • on—The powered device is detected, and power is applied. • power-deny—A powered device is detected, but no PoE is available, or the real-time power consumption exceeds the maximum power allocation. <p>Note The operating mode is the current PoE state for the specified PoE port, the specified stack member, or for all PoE ports on the switch.</p>
Admin Police	<p>Status of the real-time power-consumption policing feature:</p> <ul style="list-style-type: none"> • errdisable—Policing is enabled, and the switch shuts down the port when the real-time power consumption exceeds the maximum power allocation. • log—Policing is enabled, and the switch generates a syslog message when the real-time power consumption exceeds the maximum power allocation. • none—Policing is disabled.
Oper Police	<p>Policing status:</p> <ul style="list-style-type: none"> • errdisable—The real-time power consumption exceeds the maximum power allocation, and the switch shuts down the PoE port. • log—The real-time power consumption exceeds the maximum power allocation, and the switch generates a syslog message. • n/a—Device detection is disabled, power is not applied to the PoE port, or no policing action is configured. • ok—Real-time power consumption is less than the maximum power allocation.
Cutoff Power	The maximum power allocated on the port. When the real-time power consumption is greater than this value, the switch takes the configured policing action.
Oper Power	The real-time power consumption of the powered device.

⁴ The configured power is the power that you manually specify or that the switch specifies by using CDP power negotiation or the IEEE classification, which is different than the real-time power that is monitored with the power sensing feature.

show stack-power

To display information about StackPower stacks or switches in a power stack, use the **show stack-power** command in EXEC mode.

```
{show stack-power [{budgeting | detail | load-shedding | neighbors}] [order power-stack-name] |
[stack-name [stack-id] | switch [switch-id]]}
```

Syntax Description	
budgeting	(Optional) Displays the stack power budget table.
detail	(Optional) Displays the stack power stack details.
load-shedding	(Optional) Displays the stack power load shedding table.
neighbors	(Optional) Displays the stack power neighbor table.
order <i>power-stack-name</i>	(Optional) Displays the load shedding priority for a power stack. Note This keyword is available only after the load-shedding keyword.
stack-name	(Optional) Displays budget table, details, or neighbors for all power stacks or the specified power stack. Note This keyword is not available after the load-shedding keyword.
<i>stack-id</i>	(Optional) Power stack ID for the power stack. The stack ID must be 31 characters or less.
switch	(Optional) Displays budget table, details, load-shedding, or neighbors for all switches or the specified switch.
<i>switch-id</i>	(Optional) Switch ID for the switch. The switch number is from 1 to 9.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.2	Support for all the options was enabled for this command.
	Cisco IOS XE Denali 16.1.1	This command was reintroduced.

Usage Guidelines This command is available only on switch stacks running the IP Base or IP Services image.

If a switch is shut down because of load shedding, the output of the **show stack-power** command still includes the MAC address of the shutdown neighbor switch. The command output shows the stack power topology even if there is not enough power to power a switch.

Examples

This is an example of output from the **show stack-power** command:

show stack-power

```

Device# show stack-power
Power Stack      Stack  Stack  Total  Rsvd  Alloc  Unused  Num  Num
Name            Mode  Topolgy Pwr (W) Pwr (W) Pwr (W) Pwr (W) SW  PS
-----
Powerstack-1    SP-PS  Stndaln  350    150    200    0        1  1

```

This is an example of output from the **show stack-power budgeting** command:

```

Device# show stack-power budgeting
Power Stack      Stack  Stack  Total  Rsvd  Alloc  Unused  Num  Num
Name            Mode  Topolgy Pwr (W) Pwr (W) Pwr (W) Pwr (W) SW  PS
-----
Powerstack-1    SP-PS  Stndaln  350    150    200    0        1  1

      Power Stack      PS-A  PS-B  Power  Alloc  Avail  Consumd Pwr
SW  Name              (W)   (W)   Budgt (W) Power (W) Pwr (W) Sys/PoE (W)
--  -----
1   Powerstack-1      350   0     200    200    0      60 /0
-----
Totals:                200    0      60 /0

```

show stack-power

To display information about StackPower stacks or switches in a power stack, use the **show stack-power** command in EXEC mode.

show stack-power [*power-stack-name*]

Syntax Description	<i>power-stack-name</i> (Optional) Name of the power stack for which to display power information. The name can be up to 31 characters.
---------------------------	---

Command Modes	User EXEC Privileged EXEC
----------------------	------------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	<p>This command is available only on switch stacks running the IP Base or IP Services image.</p> <p>If a switch is shut down because of load shedding, the output of the show stack-power command still includes the MAC address of the shutdown neighbor switch. The command output shows the stack power topology even if there is not enough power to power a switch.</p>
-------------------------	---

Examples	This is an example of output from the show stack-power command:
-----------------	--

```
Device# show stack-power
Power Stack      Stack   Stack   Total   Rsvd    Alloc   Unused   Num   Num
Name             Mode    Topolgy Pwr (W) Pwr (W) Pwr (W) Pwr (W)  SW   PS
-----
Powerstack-1     SP-PS   Stndaln 715     509     190     16      1   1
```

show system mtu

To display the global maximum transmission unit (MTU) or maximum packet size set for the switch, use the **show system mtu** command in privileged EXEC mode.

show system mtu

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines For information about the MTU values and the stack configurations that affect the MTU values, see the **system mtu** command.

Examples This is an example of output from the **show system mtu** command:

```
Device# show system mtu
Global Ethernet MTU is 1500 bytes.
```

show tech-support

To automatically run **show** commands that display system information, use the **show tech-support** command in the privilege EXEC mode.

show tech-support

[**cef** | **cft** | **eigrp** | **evc** | **fnf**] | [**ipc** | **ipmulticast** | **ipsec** | **mfib** | **nat** | **nbar** | **onep** | **ospf** | **page** | **password** | **rsvp** | **subscriber** | **vrrp** | **wccp** | **wireless**]

Syntax	Description
cef	(Optional) Displays CEF related information.
cft	(Optional) Displays CFT related information.
eigrp	(Optional) Displays EIGRP related information.
evc	(Optional) Displays EVC related information.
fnf	(Optional) Displays flexible netflow related information.
ipc	(Optional) Displays IPC related information.
ipmulticast	(Optional) Displays IP multicast related information.
ipsec	(Optional) Displays IPSEC related information.
mfib	(Optional) Displays MFIB related information.
nat	(Optional) Displays NAT related information.
onep	(Optional) Displays ONEP related information.
ospf	(Optional) Displays OSPF related information.
page	(Optional) Displays the command output on a single page at a time. Use the Return key to display the next line of output or use the space bar to display the next page of information. If not used, the output scrolls (that is, it does not stop for page breaks). Press the Ctrl-C keys to stop the command output.
password	(Optional) Leaves passwords and other security information in the output. If not used, passwords and other security-sensitive information in the output are replaced with the label "<removed>".
subscriber	(Optional) Displays subscriber related information.
vrrp	(Optional) Displays VRRP related information.
wccp	(Optional) Displays WCCP related information.
wireless	(Optional) Displays wireless related information.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.2	This command was enhanced to display of the outputs of the following commands in the output modifier : <ul style="list-style-type: none"> • show power inline • show platform software ilpower details • show power inline police • show stack-power budgeting
	Cisco IOS XE Denali 16.1.1	This command was implemented on the Cisco Catalyst 3650 Switch

Usage Guidelines

The output from the **show tech-support** command is very long. To better manage this output, you can redirect the output to a file (for example, **show tech-support > filename**) in the local writable storage file system or the remote file system. Redirecting the output to a file also makes sending the output to your Cisco Technical Assistance Center (TAC) representative easier.

You can use one of the following redirection methods:

- **> filename** - Redirects the output to a file.
- **>> filename** - Redirects the output to a file in append mode.

show wireless interface summary

To display the wireless interface status and configuration, use the **show wireless interface summary** privileged EXEC command.

show wireless interface summary

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

This example shows how to display the summary of wireless interfaces:

```
Device# show wireless interface summary
```

speed

To specify the speed of a 10/100 Mb/s or 10/100/1000 Mb/s port, use the **speed** command in interface configuration mode. To return to the default value, use the **no** form of this command.

```
speed {10 | 100 | 1000 | auto [{10 | 100 | 1000}] | nonegotiate}
no speed
```

Syntax Description		
	10	Specifies that the port runs at 10 Mb/s.
	100	Specifies that the port runs at 100 Mb/s.
	1000	Specifies that the port runs at 1000 Mb/s. This option is valid and visible only on 10/100/1000 Mb/s ports.
	auto	Automatically detects the speed the port should run at based on the port at the other end of the link. If you use the 10 , 100 , or 1000 keywords with the auto keyword, the port only autonegotiates at the specified speeds.
	nonegotiate	Disables autonegotiation, and the port runs at 1000 Mb/s.

Command Default The default is **auto**.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You cannot configure speed on the 10-Gigabit Ethernet ports.

Except for the 1000BASE-T small form-factor pluggable (SFP) modules, you can configure the speed to not negotiate (**nonegotiate**) when an SFP module port is connected to a device that does not support autonegotiation.

If the speed is set to **auto**, the switch negotiates with the device at the other end of the link for the speed setting and then forces the speed setting to the negotiated value. The duplex setting remains as configured on each end of the link, which could result in a duplex setting mismatch.

If both ends of the line support autonegotiation, we highly recommend the default autonegotiation settings. If one interface supports autonegotiation and the other end does not, do use the **auto** setting on the supported side, but set the duplex and speed on the other side.



Caution Changing the interface speed and duplex mode configuration might shut down and reenables the interface during the reconfiguration.

For guidelines on setting the switch speed and duplex parameters, see the “Configuring Interface Characteristics” chapter in the software configuration guide for this release.

You can verify your settings by entering the **show interfaces** privileged EXEC command.

Examples

This example shows how to set speed on a port to 100 Mb/s:

```
Device(config)# interface gigabitethernet1/0/1  
Device(config-if)# speed 100
```

This example shows how to set a port to autonegotiate at only 10 Mb/s:

```
Device(config)# interface gigabitethernet1/0/1  
Device(config-if)# speed auto 10
```

This example shows how to set a port to autonegotiate at only 10 or 100 Mb/s:

```
Device(config)# interface gigabitethernet1/0/1  
Device(config-if)# speed auto 10 100
```

stack-power

To configure StackPower parameters for the power stack or for a switch in the power stack, use the **stack power** command in global configuration mode. To return to the default setting, use the **no** form of the command,

```
stack-power {stack power-stack-name | switch stack-member-number}
no stack-power {stack power-stack-name | switch stack-member-number}
```

Syntax Description	stack <i>power-stack-name</i>	Specifies the name of the power stack. The name can be up to 31 characters. Entering these keywords followed by a carriage return enters power stack configuration mode.
	switch <i>stack-member-number</i>	Specifies the switch number in the stack (1 to 4) to enter switch stack-power configuration mode for the switch.
Command Default	There is no default.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines When you enter the **stack-power stack** *power stack name* command, you enter power stack configuration mode, and these commands are available:

- **default**—Returns a command to its default setting.
- **exit**—Exits ARP access-list configuration mode.
- **mode**—Sets the power mode for the power stack. See the **mode** command.
- **no**—Negates a command or returns to default settings.

If you enter the **stack-power switch** *switch-number* command with a switch number that is not participating in StackPower, you receive an error message.

When you enter the **stack-power switch** *switch-number* command with the number of a switch participating in StackPower, you enter switch stack power configuration mode, and these commands are available:

- **default**—Returns a command to its default setting.
- **exit**—Exits switch stack power configuration mode.
- **no**—Negates a command or returns to default settings.
- **power-priority**—Sets the power priority for the switch and the switch ports. See the **power-priority** command.
- **stack-id** *name*—Enters the name of the power stack to which the switch belongs. If you do not enter the power stack-ID, the switch does not inherit the stack parameters. The name can be up to 31 characters.
- **standalone**—Forces the switch to operate in standalone power mode. This mode shuts down both stack power ports.

Examples

This example removes switch 2, which is connected to the power stack, from the power pool and shutting down both power ports:

```
Device(config)# stack-power switch 2  
Device(config-switch-stackpower)# standalone  
Device(config-switch-stackpower)# exit
```

switchport block

To prevent unknown multicast or unicast packets from being forwarded, use the **switchport block** command in interface configuration mode. To allow forwarding unknown multicast or unicast packets, use the **no** form of this command.

```
switchport block {multicast | unicast}
no switchport block {multicast | unicast}
```

Syntax Description	multicast Specifies that unknown multicast traffic should be blocked.	
	Note Only pure Layer 2 multicast traffic is blocked. Multicast packets that contain IPv4 or IPv6 information in the header are not blocked.	
	unicast Specifies that unknown unicast traffic should be blocked.	
Command Default	Unknown multicast and unicast traffic is not blocked.	
Command Modes	Interface configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	By default, all traffic with unknown MAC addresses is sent to all ports. You can block unknown multicast or unicast traffic on protected or nonprotected ports. If unknown multicast or unicast traffic is not blocked on a protected port, there could be security issues.	
	With multicast traffic, the port blocking feature blocks only pure Layer 2 packets. Multicast packets that contain IPv4 or IPv6 information in the header are not blocked.	
	Blocking unknown multicast or unicast traffic is not automatically enabled on protected ports; you must explicitly configure it.	
	For more information about blocking packets, see the software configuration guide for this release.	
	This example shows how to block unknown unicast traffic on an interface:	

```
Device(config-if)# switchport block unicast
```

You can verify your setting by entering the **show interfaces *interface-id* switchport** privileged EXEC command.

system mtu

To set the global maximum packet size or MTU size for switched packets on Gigabit Ethernet and 10-Gigabit Ethernet ports, use the **system mtu** command in global configuration mode. To restore the global MTU value to its default value use the **no** form of this command.

```
system mtu bytes
no system mtu
```

Syntax Description	<i>bytes</i> The global MTU size in bytes. The range is 1500 to 9198 bytes; the default is 1500 bytes.	
Command Default	The default MTU size for all ports is 1500 bytes.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You can verify your setting by entering the **show system mtu** privileged EXEC command.

The switch does not support the MTU on a per-interface basis.

If you enter a value that is outside the allowed range for the specific type of interface, the value is not accepted.

Examples

This example shows how to set the global system MTU size to 6000 bytes:

```
Device(config)# system mtu 6000
Global Ethernet MTU is set to 6000 bytes.
Note: this is the Ethernet payload size, not the total
Ethernet frame size, which includes the Ethernet
header/trailer and possibly other tags, such as ISL or
802.1q tags.
```

test mcu read-register

To enable debugging of the Power over Ethernet (PoE) controller, use the **test mcu read-register** command in privileged EXEC mode.

test mcu read-register {**det-cls-offset** | **manufacture-id** | **port-mode**}

Syntax Description	
det-cls-offset	Displays the read detection classification register summary.
manufacture-id	Displays the PoE controller manufacture ID.
port-mode	Displays the port mode details.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Examples

The following is sample output from the **test mcu read-register det-cls-offset** command:

```
Device# test mcu read-register det-cls-offset 1
DETECTION ENABLE BIT SUMMARY

Controller   port1      port2      port3      port4      register
-----
1            1          0          1          0          5
2            1          0          1          0          5
3            1          0          1          0          5
4            1          0          1          0          5
5            1          0          1          0          5
6            1          0          1          0          5
7            1          0          1          0          5
8            1          0          1          0          5
9            1          0          1          0          5
10           1          0          1          0          5
11           0          0          1          0          4
12           1          0          0          0          1

CLASSIFICATION ENABLE BIT SUMMARY

Controller   port1      port2      port3      port4      register
-----

```

1	1	0	1	0	5
2	1	0	1	0	5
3	1	0	1	0	5
4	1	0	1	0	5
5	1	0	1	0	5
6	1	0	1	0	5
7	1	0	1	0	5
8	1	0	1	0	5
9	1	0	1	0	5
10	1	0	1	0	5
11	0	0	1	0	4
12	1	0	0	0	1

The following is sample output from the **test mcu read-register manufacture-id** command:

```
MANUFACTURE ID : DEVICE_BCM_PALPATINE reg_val = 0x1B
```

The following is sample output from the **test mcu read-register port-mode** command:

```
PORT MODE SUMMERY
```

Controller	port1	port2	port3	port4	register (hexadecimal)
1	01	00	01	00	22
2	01	00	01	00	22
3	01	00	01	00	22
4	01	00	01	00	22
5	01	00	01	00	22
6	01	00	01	00	22
7	01	00	01	00	22
8	01	00	01	00	22
9	01	00	01	00	22
10	01	00	01	00	22
11	00	00	01	00	20
12	01	00	00	00	2

transceiver type all

To enter the transceiver type configuration mode and enable transceiver monitoring, enter the **transceiver type all** command in global configuration mode. This command does not have the **no** form.

transceiver type all

Syntax Description This command has no arguments or keywords.

Command Default Transceiver type configuration is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.6	This command was introduced.

Usage Guidelines After you have entered the transceiver type configuration mode, you can enter the **monitoring** command to enable digital optical monitoring.

Related Commands	Command	Description
	monitoring	Enables digital optical monitoring.

voice-signaling vlan (network-policy configuration)

To create a network-policy profile for the voice-signaling application type, use the **voice-signaling vlan** command in network-policy configuration mode. To delete the policy, use the **no** form of this command.

```
voice-signaling vlan {vlan-id [{cos cos-value | dscp dscp-value}] | dot1p [{cos l2-priority | dscp dscp}] | none | untagged}
```

Syntax Description	
vlan-id	(Optional) The VLAN for voice traffic. The range is 1 to 4094.
cos <i>cos-value</i>	(Optional) Specifies the Layer 2 priority class of service (CoS) for the configured VLAN. The range is 0 to 7; the default is 5.
dscp <i>dscp-value</i>	(Optional) Specifies the differentiated services code point (DSCP) value for the configured VLAN. The range is 0 to 63; the default is 46.
dot1p	(Optional) Configures the phone to use IEEE 802.1p priority tagging and to use VLAN 0 (the native VLAN).
none	(Optional) Does not instruct the Cisco IP phone about the voice VLAN. The phone uses the configuration from the phone key pad.
untagged	(Optional) Configures the phone to send untagged voice traffic. This is the default for the phone.

Command Default No network-policy profiles for the voice-signaling application type are defined.
 The default CoS value is 5.
 The default DSCP value is 46.
 The default tagging mode is untagged.

Command Modes Network-policy profile configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use the **network-policy profile** global configuration command to create a profile and to enter network-policy profile configuration mode.

The voice-signaling application type is for network topologies that require a different policy for voice signaling than for voice media. This application type should not be advertised if all of the same network policies apply as those advertised in the voice policy TLV.

When you are in network-policy profile configuration mode, you can create the profile for voice-signaling by specifying the values for VLAN, class of service (CoS), differentiated services code point (DSCP), and tagging mode.

These profile attributes are contained in the Link Layer Discovery Protocol for Media Endpoint Devices (LLDP-MED) network-policy time-length-value (TLV).

To return to privileged EXEC mode from the network-policy profile configuration mode, enter the **exit** command.

This example shows how to configure voice-signaling for VLAN 200 with a priority 2 CoS:

```
Device(config)# network-policy profile 1  
Device(config-network-policy)# voice-signaling vlan 200 cos 2
```

This example shows how to configure voice-signaling for VLAN 400 with a DSCP value of 45:

```
Device(config)# network-policy profile 1  
Device(config-network-policy)# voice-signaling vlan 400 dscp 45
```

This example shows how to configure voice-signaling for the native VLAN with priority tagging:

```
Device(config-network-policy)# voice-signaling vlan dot1p cos 4
```

voice vlan (network-policy configuration)

To create a network-policy profile for the voice application type, use the **voice vlan** command in network-policy configuration mode. To delete the policy, use the **no** form of this command.

```
voice vlan {vlan-id [{cos cos-value | dscp dscp-value}] | dot1p [{cos l2-priority | dscp dscp}] | none | untagged}
```

Syntax Description	
vlan-id	(Optional) The VLAN for voice traffic. The range is 1 to 4094.
cos <i>cos-value</i>	(Optional) Specifies the Layer 2 priority class of service (CoS) for the configured VLAN. The range is 0 to 7; the default is 5.
dscp <i>dscp-value</i>	(Optional) Specifies the differentiated services code point (DSCP) value for the configured VLAN. The range is 0 to 63; the default is 46.
dot1p	(Optional) Configures the phone to use IEEE 802.1p priority tagging and to use VLAN 0 (the native VLAN).
none	(Optional) Does not instruct the Cisco IP phone about the voice VLAN. The phone uses the configuration from the phone key pad.
untagged	(Optional) Configures the phone to send untagged voice traffic. This is the default for the phone.

Command Default No network-policy profiles for the voice application type are defined.
 The default CoS value is 5.
 The default DSCP value is 46.
 The default tagging mode is untagged.

Command Modes Network-policy profile configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use the **network-policy profile** global configuration command to create a profile and to enter network-policy profile configuration mode.

The voice application type is for dedicated IP telephones and similar devices that support interactive voice services. These devices are typically deployed on a separate VLAN for ease of deployment and enhanced security through isolation from data applications.

When you are in network-policy profile configuration mode, you can create the profile for voice by specifying the values for VLAN, class of service (CoS), differentiated services code point (DSCP), and tagging mode.

These profile attributes are contained in the Link Layer Discovery Protocol for Media Endpoint Devices (LLDP-MED) network-policy time-length-value (TLV).

To return to privileged EXEC mode from the network-policy profile configuration mode, enter the **exit** command.

This example shows how to configure the voice application type for VLAN 100 with a priority 4 CoS:

```
Device(config)# network-policy profile 1  
Device(config-network-policy)# voice vlan 100 cos 4
```

This example shows how to configure the voice application type for VLAN 100 with a DSCP value of 34:

```
Device(config)# network-policy profile 1  
Device(config-network-policy)# voice vlan 100 dscp 34
```

This example shows how to configure the voice application type for the native VLAN with priority tagging:

```
Device(config-network-policy)# voice vlan dot1p cos 4
```

wireless ap-manager interface

To configure the wireless AP-manager interface, use the **wireless ap-manager interface** command.

```
wireless ap-managerinterface {TenGigabitEthernet interface-number | Vlan interface-number}
```

Syntax Description	TenGigabitEthernet <i>interface-name</i>	Configures 10-Gigabit Ethernet interface. Values range from 0 to 9.
	Vlan <i>interface-name</i>	Configures VLANs. Values range from 1 to 4095.
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure the wireless AP-manager:

```
Device# wireless ap-manager interface vlan
<1-4095> Vlan interface number
```

This example shows how to configure the wireless AP-manager:

```
Device# #wireless ap-manager interface vlan 10
```

wireless exclusionlist

To manage exclusion list entries, use the **wireless exclusionlist** global configuration command. To remove the exclusion list entries, use the **no** form of the command.

```
wireless exclusionlist mac-addr description description
no wireless exclusionlist mac-addr
```

Syntax Description

<i>mac-addr</i>	The MAC address of the local excluded entry.
description <i>description</i>	Specifies the description for an exclusion-list entry.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to create a local exclusion list entry for the MAC address xxx.xxx.xxx:

```
Device# wireless exclusionlist xxx.xxx.xxx
```

This example shows how to create a description for the local exclusion list entry for the MAC address xxx.xxx.xxx:

```
Device# wireless exclusionlist xxx.xxx.xxx description sample
```

wireless linktest

To configure linktest frame size and number of frames to send, use the **wireless linktest** command.

```
wireless linktest {frame-size size | number-of-frames value}
```

Syntax Description	frame-size <i>size</i>	Specifies the link test frame size for each packet. The values range from 1 to 1400.
	number-of-frames <i>value</i>	Specifies the number of frames to be sent for the link test. The values range from 1 to 100.
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure the link test frame size of each frame as 10:

```
Device# wireless linktest frame-size 10
```

wireless management interface

To configure wireless management parameters on an interface, use the **wireless management interface** global configuration command. To remove a wireless management parameters on an interface, use the **no** form of the command.

```
wireless management interface interface-name {TenGigabitEthernet interface-name | Vlan interface-name}
no wireless management interface
```

Syntax Description	interface-name	The interface number.
	TenGigabitEthernet interface-name	The 10-Gigabit Ethernet interface number. The values range from 0 to 9.
	Vlan interface-name	The VLAN interface number. The values range from 1 to 4095.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure VLAN 10 on the wireless interface:

```
Device# wireless management interface Vlan 10
```

wireless peer-blocking forward-upstream

To configure peer-to-peer blocking for forward upstream, use the **wireless peer-blocking forward-upstream** command. To remove a peer-to-peer blocking, use the **no** form of the command.

wireless peer-blocking forward-upstream *interface* {**GigabitEthernet** *interface-number*

TenGigabitEthernet *interface-number*}

no wireless peer-blocking forward-upstream {**GigabitEthernet** *interface-number* **TenGigabitEthernet** *interface-number*}

Syntax Description	GigabitEthernet <i>interface</i>	The Gigabit Ethernet interface number. Values range from 0 to 9.
	TenGigabitEthernet <i>interface</i>	The 10-Gigabit Ethernet interface number. Values range from 0 to 9.
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure peer-to-peer blocking for interface 10-gigabit ethernet interface:

```
Device(config)# wireless peer-blocking forward-upstream TenGigabitEthernet 1/1/4
```

■ wireless peer-blocking forward-upstream



PART **IV**

IP

- [IP Commands, on page 257](#)



IP Commands

- [clear ip nhrp](#), on page 259
- [debug nhrp](#), on page 260
- [fhrp delay](#), on page 262
- [fhrp version vrrp v3](#), on page 263
- [glbp authentication](#), on page 264
- [glbp forwarder preempt](#), on page 266
- [glbp ip](#), on page 267
- [glbp load-balancing](#), on page 268
- [glbp name](#), on page 269
- [glbp preempt](#), on page 271
- [glbp priority](#), on page 272
- [glbp timers](#), on page 273
- [glbp weighting](#), on page 275
- [glbp weighting track](#), on page 276
- [ip address dhcp](#), on page 278
- [ip address pool \(DHCP\)](#), on page 281
- [ip address](#), on page 282
- [ip http server](#), on page 284
- [ip http secure-server](#), on page 286
- [ip nhrp map](#), on page 288
- [ip nhrp map multicast](#), on page 290
- [ip nhrp network-id](#), on page 292
- [ip nhrp nhs](#), on page 293
- [key chain](#), on page 295
- [key-string \(authentication\)](#), on page 296
- [key](#), on page 297
- [show glbp](#), on page 298
- [show ip nhrp nhs](#), on page 301
- [show key chain](#), on page 303
- [show track](#), on page 304
- [track](#), on page 306
- [vrrp](#), on page 308
- [vrrp description](#), on page 309

- [vrrp preempt](#), on page 310
- [vrrp priority](#), on page 311
- [vrrp timers advertise](#), on page 312
- [vrrs leader](#), on page 313

clear ip nhrp

To clear all dynamic entries from the Next Hop Resolution Protocol (NHRP) cache, use the **clear ip nhrp** command in user EXEC or privileged EXEC mode.

```
clear ip nhrp [{vrf {vrf-name | global}}] [{dest-ip-address [{dest-mask}] | tunnel number | counters
[interface tunnel number]}] stats [{tunnel number [{vrf {vrf-name | global}}]}]
```

Syntax Description	Parameter	Description
	vrf	(Optional) Deletes entries from the NHRP cache for the specified virtual routing and forwarding (VRF) instance.
	<i>vrf-name</i>	(Optional) Name of the VRF address family to which the command is applied.
	global	(Optional) Specifies the global VRF instance.
	<i>dest-ip-address</i>	(Optional) Destination IP address. Specifying this argument clears NHRP mapping entries for the specified destination IP address.
	<i>dest-mask</i>	(Optional) Destination network mask.
	counters	(Optional) Clears the NHRP counters.
	interface	(Optional) Clears the NHRP mapping entries for all interfaces.
	tunnel number	(Optional) Removes the specified interface from the NHRP cache.
	stats	(Optional) Clears all IPv4 statistic information for all interfaces.

Command Modes	Mode
	User EXEC (>)
	Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines The **clear ip nhrp** command does not clear any static (configured) IP-to-NBMA address mappings from the NHRP cache.

Examples The following example shows how to clear all dynamic entries from the NHRP cache for an interface:

```
Switch# clear ip nhrp
```

Related Commands	Command	Description
	show ip nhrp	Displays NHRP mapping information.

debug nhrp

To enable Next Hop Resolution Protocol (NHRP) debugging, use the **debug nhrp** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug nhrp [{**attribute** | **cache** | **condition** {**interface tunnel number** | **peer** {**nbma** {*ipv4-nbma-address nbma-name ipv6-nbma-address*} } } | **unmatched** | **vrf vrf-name**} | **detail** | **error** | **extension** | **group** | **packet** | **rate**}]

no debug nhrp [{**attribute** | **cache** | **condition** {**interface tunnel number** | **peer** {**nbma** {*ipv4-nbma-address nbma-name ipv6-nbma-address*} } } | **unmatched** | **vrf vrf-name**} | **detail** | **error** | **extension** | **group** | **packet** | **rate**}]

Syntax Description

attribute	(Optional) Enables NHRP attribute debugging operations.
cache	(Optional) Enables NHRP cache debugging operations.
condition	(Optional) Enables NHRP conditional debugging operations.
interface tunnel number	(Optional) Enables debugging operations for the tunnel interface.
nbma	(Optional) Enables debugging operations for the non-broadcast multiple access (NBMA) network.
<i>ipv4-nbma-address</i>	(Optional) Enables debugging operations based on the IPv4 address of the NBMA network.
<i>nbma-name</i>	(Optional) NBMA network name.
<i>IPv6-address</i>	(Optional) Enables debugging operations based on the IPv6 address of the NBMA network. Note The <i>IPv6-address</i> argument is not supported in Cisco IOS XE Denali 16.3.1.
vrf vrf-name	(Optional) Enables debugging operations for the virtual routing and forwarding instance.
detail	(Optional) Displays detailed logs of NHRP debugs.
error	(Optional) Enables NHRP error debugging operations.
extension	(Optional) Enables NHRP extension processing debugging operations.
group	(Optional) Enables NHRP group debugging operations.
packet	(Optional) Enables NHRP activity debugging.
rate	(Optional) Enables NHRP rate limiting.
routing	(Optional) Enables NHRP routing debugging operations.

Command Default

NHRP debugging is not enabled.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines



Note In Cisco IOS XE Denali 16.3.1, this command supports only IPv4; the *IPv6-nbma-address* argument although available on the switch, will not work if configured.

Use the **debug nhrp detail** command to view the NHRP attribute logs.

The **Virtual-Access number** keyword-argument pair is visible only if the virtual access interface is available on the device.

Examples

The following sample output from the **debug nhrp** command displays NHRP debugging output for IPv4:

```
Switch# debug nhrp

Aug  9 13:13:41.486: NHRP: Attempting to send packet via DEST 10.1.1.99
Aug  9 13:13:41.486: NHRP: Encapsulation succeeded. Tunnel IP addr 10.11.11.99
Aug  9 13:13:41.486: NHRP: Send Registration Request via Tunnel0 vrf 0, packet size: 105
Aug  9 13:13:41.486:      src: 10.1.1.11, dst: 10.1.1.99
Aug  9 13:13:41.486: NHRP: 105 bytes out Tunnel0
Aug  9 13:13:41.486: NHRP: Receive Registration Reply via Tunnel0 vrf 0, packet size: 125
Aug  9 13:13:41.486: NHRP: netid_in = 0, to_us = 1
```

Related Commands

Command	Description
show ip nhrp	Displays NHRP mapping information.

fhrp delay

To specify the delay period for the initialization of First Hop Redundancy Protocol (FHRP) clients, use the **fhrp delay** command in interface configuration mode. To remove the delay period specified, use the **no** form of this command.

```
fhrp delay { [minimum] [reload] seconds }
no fhrp delay { [minimum] [reload] seconds }
```

Syntax Description

minimum	(Optional) Configures the delay period after an interface becomes available.
reload	(Optional) Configures the delay period after the device reloads.
<i>seconds</i>	Delay period in seconds. The range is from 0 to 3600.

Command Default

None

Command Modes

Interface configuration (config-if)

Examples

This example shows how to specify the delay period for the initialization of FHRP clients:

```
Device(config-if)# fhrp delay minimum 90
```

Related Commands

Command	Description
show fhrp	Displays First Hop Redundancy Protocol (FHRP) information.

fhrp version vrrp v3

To enable Virtual Router Redundancy Protocol version 3 (VRRPv3) and Virtual Router Redundancy Service (VRRS) configuration on a device, use the **fhrp version vrrp v3** command in global configuration mode. To disable the ability to configure VRRPv3 and VRRS on a device, use the **no** form of this command.

fhrp version vrrp v3
no fhrp version vrrp v3

Syntax Description	This command has no keywords or arguments.
Command Default	VRRPv3 and VRRS configuration on a device is not enabled.
Command Modes	Global configuration (config)
Usage Guidelines	When VRRPv3 is in use, VRRP version 2 (VRRPv2) is unavailable.

Examples

In the following example, a tracking process is configured to track the state of an IPv6 object using a VRRPv3 group. VRRP on GigabitEthernet interface 0/0/0 then registers with the tracking process to be informed of any changes to the IPv6 object on the VRRPv3 group. If the IPv6 object state on serial interface VRRPv3 goes down, then the priority of the VRRP group is reduced by 20:

```
Device(config)# fhrp version vrrp v3
Device(config)# interface GigabitEthernet 0/0/0
Device(config-if)# vrrp 1 address-family ipv6
Device(config-if-vrrp)# track 1 decrement 20
```

Related Commands	Command	Description
	track (VRRP)	Enables an object to be tracked using a VRRPv3 group.

glbp authentication

To configure an authentication string for the Gateway Load Balancing Protocol (GLBP), use the **glbp authentication** command in interface configuration mode. To disable authentication, use the **no** form of this command.

```
glbp group-numberauthentication {text string | md5 {key-string [{0 | 7}] key | key-chain name-of-chain}}
```

```
no glbp group-number authentication {text string | md5 {key-string [{0 | 7}] key | key-chain name-of-chain}}
```

Syntax Description

<i>group-number</i>	GLBP group number in the range from 0 to 1023.
text <i>string</i>	Specifies an authentication string. The number of characters in the command plus the text string must not exceed 255 characters.
md5	Message Digest 5 (MD5) authentication.
key-string <i>key</i>	Specifies the secret key for MD5 authentication. The key string cannot exceed 100 characters in length. We recommend using at least 16 characters.
0	(Optional) Unencrypted key. If no prefix is specified, the key is unencrypted.
7	(Optional) Encrypted key.
key-chain <i>name-of-chain</i>	Identifies a group of authentication keys.

Command Default

No authentication of GLBP messages occurs.

Command Modes

Interface configuration (config-if)

Usage Guidelines

The same authentication method must be configured on all the devices that are configured to be members of the same GLBP group, to ensure interoperability. A device will ignore all GLBP messages that contain the wrong authentication information.

If password encryption is configured with the **service password-encryption** command, the software saves the key string in the configuration as encrypted text.

Examples

The following example configures stringxyz as the authentication string required to allow GLBP devices in group 10 to interoperate:

```
Device(config)# interface GigabitEthernet 1/0/1
Device(config-if)# glbp 10 authentication text stringxyz
```

In the following example, GLBP queries the key chain “AuthenticateGLBP” to obtain the current live key and key ID for the specified key chain:

```
Device(config)# key chain AuthenticateGLBP
Device(config-keychain)# key 1
Device(config-keychain-key)# key-string ThisIsASecretKey
Device(config-keychain-key)# exit
```

```
Device(config-keychain)# exit
Device(config)# interface GigabitEthernet 1/0/1
Device(config-if)# ip address 10.0.0.1 255.255.255.0
Device(config-if)# glbp 2 authentication md5 key-chain AuthenticateGLBP
```

Related Commands

Command	Description
glbp ip	Enables GLBP.

glbp forwarder preempt

To configure a device to take over as active virtual forwarder (AVF) for a Gateway Load Balancing Protocol (GLBP) group if the current AVF falls below its low weighting threshold, use the **glbp forwarder preempt** command in interface configuration mode. To disable this function, use the **no** form of this command.

glbp group forwarder preempt [delay minimum seconds]
no glbp group forwarder preempt [delay minimum]

Syntax Description

<i>group</i>	GLBP group number in the range from 0 to 1023.
delay minimum <i>seconds</i>	(Optional) Specifies a minimum number of seconds that the device will delay before taking over the role of AVF. The range is from 0 to 3600 seconds with a default delay of 30 seconds.

Command Default

Forwarder preemption is enabled with a default delay of 30 seconds.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Examples

The following example shows a device being configured to preempt the current AVF when the current AVF falls below its low weighting threshold. If the device preempts the current AVF, it waits 60 seconds before taking over the role of the AVF.

```
Device(config-if)# glbp 10 forwarder preempt delay minimum 60
```

Related Commands

Command	Description
glbp ip	Enables GLBP.

glbp ip

To activate the Gateway Load Balancing Protocol (GLBP), use the **glbp ip** command in interface configuration mode. To disable GLBP, use the **no** form of this command.

```
glbp group ip [ip-address [secondary]]
no glbp group ip [ip-address [secondary]]
```

Syntax Description

<i>group</i>	GLBP group number in the range from 0 to 1023.
<i>ip-address</i>	(Optional) Virtual IP address for the GLBP group. The IP address must be in the same subnet as the interface IP address.
secondary	(Optional) Indicates that the IP address is a secondary GLBP virtual address.

Command Default

GLBP is disabled by default.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Usage Guidelines

The **glbp ip** command activates GLBP on the configured interface. If an IP address is specified, that address is used as the designated virtual IP address for the GLBP group. If no IP address is specified, the designated address is learned from another device configured to be in the same GLBP group. For GLBP to elect an active virtual gateway (AVG), at least one device on the cable must have been configured with the designated address. A device must be configured with, or have learned, the virtual IP address of the GLBP group before assuming the role of a GLBP gateway or forwarder. Configuring the designated address on the AVG always overrides a designated address that is in use.

When the **glbp ip** command is enabled on an interface, the handling of proxy Address Resolution Protocol (ARP) requests is changed (unless proxy ARP was disabled). ARP requests are sent by hosts to map an IP address to a MAC address. The GLBP gateway intercepts the ARP requests and replies to the ARP on behalf of the connected nodes. If a forwarder in the GLBP group is active, proxy ARP requests are answered using the MAC address of the first active forwarder in the group. If no forwarder is active, proxy ARP responses are suppressed.

Examples

The following example activates GLBP for group 10 on GigabitEthernet interface 1/0/1. The virtual IP address to be used by the GLBP group is set to 10.21.8.10.

```
Device(config)# interface GigabitEthernet 1/0/1
Device(config-if)# ip address 10.21.8.32 255.255.255.0
Device(config-if)# glbp 10 ip 10.21.8.10
```

Related Commands

Command	Description
show glbp	Displays GLBP information.

glbp load-balancing

To specify the load-balancing method used by the active virtual gateway (AVG) of the Gateway Load Balancing Protocol (GLBP), use the **glbp load-balancing** command in interface configuration mode. To disable load balancing, use the **no** form of this command.

glbp group load-balancing [{**host-dependent** | **round-robin** | **weighted**}]
no glbp group load-balancing

Syntax Description

<i>group</i>	GLBP group number in the range from 0 to 1023.
host-dependent	(Optional) Specifies a load balancing method based on the MAC address of a host where the same forwarder is always used for a particular host while the number of GLBP group members remains unchanged.
round-robin	(Optional) Specifies a load balancing method where each virtual forwarder in turn is included in address resolution replies for the virtual IP address. This method is the default.
weighted	(Optional) Specifies a load balancing method that is dependent on the weighting value advertised by the gateway.

Command Default

The round-robin method is the default.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Usage Guidelines

Use the host-dependent method of GLBP load balancing when you need each host to always use the same device. Use the weighted method of GLBP load balancing when you need unequal load balancing because devices in the GLBP group have different forwarding capacities.

Examples

The following example shows the host-dependent load-balancing method being configured for the AVG of the GLBP group 10:

```
Device(config)# interface GigabitEthernet 1/0/1
Device(config-if)# glbp 10 ip 10.21.8.10
Device(config-if)# glbp 10 load-balancing host-dependent
```

Related Commands

Command	Description
show glbp	Displays GLBP information.

glbp name

To enable IP redundancy by assigning a name to the Gateway Load Balancing Protocol (GLBP) group, use the **glbp name** command in interface configuration mode. To disable IP redundancy for a group, use the **no** form of this command.

```
glbp group-number name group-name
no glbp group-number name group-name
```

Syntax Description	
<i>group-number</i>	GLBP group number. Range is from 0 to 1023.
<i>group-name</i>	GLBP group name specified as a character string. Maximum number of characters is 255.

Command Default IP redundancy for a group is disabled.

Command Modes Interface configuration (config-if)

Command History	Release	Modification
	Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Usage Guidelines The GLBP redundancy client must be configured with the same GLBP group name so that the redundancy client and the GLBP group can be connected.

Examples The following example assigns the abccomp name to GLBP group 10:

```
Device(config-if)# glbp 10 name abccomp
```

Related Commands	Command	Description
	glbp authentication	Configures an authentication string for the GLBP.
	glbp forwarder preempt	Configures a device to take over as AVF for a GLBP group if it has higher priority than the current AVF.
	glbp ip	Activates GLBP.
	glbp load-balancing	Specifies the load-balancing method used by the AVG of GLBP.
	glbp preempt	Configures the gateway to take over as AVG for a GLBP group if it has higher priority than the current AVG.
	glbp priority	Sets the priority level of the gateway within a GLBP group.
	glbp timers	Configures the time between hello packets sent by the GLBP gateway and the time for which the virtual gateway and virtual forwarder information is considered valid.

Command	Description
glbp timers redirect	Configures the time during which the AVG for a GLBP group continues to redirect clients to a secondary AVF.
glbp weighting	Specifies the initial weighting value of the GLBP gateway.
glbp weighting track	Specifies a tracking object where the GLBP weighting changes based on the availability of the object being tracked.
show glbp	Displays GLBP information.
track	Configures an interface to be tracked where the GLBP weighting changes based on the state of the interface.

glbp preempt

To configure the gateway to take over as active virtual gateway (AVG) for a Gateway Load Balancing Protocol (GLBP) group if it has higher priority than the current AVG, use the **glbp preempt** command in interface configuration mode. To disable this function, use the **no** form of this command.

```
glbp group preempt [delay minimum seconds]
no glbp group preempt [delay minimum]
```

Syntax Description		
	<i>group</i>	GLBP group number in the range from 0 to 1023.
	delay minimum <i>seconds</i>	(Optional) Specifies a minimum number of seconds that the device will delay before taking over the role of AVG. The range is from 0 to 3600 seconds with a default delay of 30 seconds.

Command Default A GLBP device with a higher priority than the current AVG cannot assume the role of AVG. The default delay value is 30 seconds.

Command Modes Interface configuration (config-if)

Command History	Release	Modification
	Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Examples

The following example shows a device being configured to preempt the current AVG when its priority of 254 is higher than that of the current AVG. If the device preempts the current AVG, it waits 60 seconds before assuming the role of AVG.

```
Device(config-if)# glbp 10 preempt delay minimum 60
Device(config-if)# glbp 10 priority 254
```

Related Commands	Command	Description
	glbp ip	Enables GLBP.
	glbp priority	Sets the priority level of the device within a GLBP group.

glbp priority

To set the priority level of the gateway within a Gateway Load Balancing Protocol (GLBP) group, use the **glbp priority** command in interface configuration mode. To remove the priority level of the gateway, use the **no** form of this command.

glbp *group* **priority** *level*
no glbp *group* **priority** *level*

Syntax Description	
<i>group</i>	GLBP group number in the range from 0 to 1023.
<i>level</i>	Priority of the gateway within the GLBP group. The range is from 1 to 255. The default is 100.

Command Default The GLBP virtual gateway preemptive scheme is disabled

Command Modes Interface configuration (config-if)

Usage Guidelines Use this command to control which virtual gateway becomes the active virtual gateway (AVG). After the priorities of several different virtual gateways are compared, the gateway with the numerically higher priority is elected as the AVG. If two virtual gateways have equal priority, the gateway with the higher IP address is selected.

Examples

The following example shows a virtual gateway being configured with a priority of 254:

```
Device(config-if)# glbp 10 priority 254
```

Related Commands	Command	Description
	glbp ip	Enables GLBP.
	glbp preempt	Configures a device to take over as the AVG for a GLBP group if it has higher priority than the current AVG.

glbp timers

To configure the time between hello packets sent by the Gateway Load Balancing Protocol (GLBP) gateway and the time that the virtual gateway and virtual forwarder information is considered valid, use the **glbp timers** command in interface configuration mode. To restore the timers to their default values, use the **no** form of this command.

```
glbp group timers {hellotime{holdtime | msec holdtime} | msec { holdtime | msec holdtime}
| redirect time-interval-to-redirect | timeout}
no glbp group timers {hellotime{holdtime | msec holdtime} | msec { holdtime | msec
holdtime} | redirect time-interval-to-redirect | timeout}
```

Syntax Description

<i>group</i>	GLBP group number in the range from 0 to 1023.
msec	(Optional) Specifies that the following (<i>hellotime</i> or <i>holdtime</i>) argument value will be expressed in milliseconds rather than seconds.
<i>hellotime</i>	Hello interval. The default is 3 seconds (3000 milliseconds).
<i>holdtime</i>	Time before the virtual gateway and virtual forwarder information contained in the hello packet is considered invalid. The default is 10 seconds (10,000 milliseconds).
redirect	Specifies time interval during which the active virtual gateway (AVG) for a Gateway Load Balancing Protocol (GLBP) group continues to redirect clients to a secondary active virtual forwarder (AVF) and time-out values for failed forwarders.
<i>time-interval-to-redirect</i>	The redirect timer interval in the range from 0 to 3600 seconds. The default is 600 seconds (10 minutes). Note The zero value for the <i>time-interval-to-redirect</i> argument cannot be removed from the range of acceptable values because preexisting configurations of Cisco IOS software already using the zero value could be negatively affected during an upgrade. However, be advised that a zero setting is not recommended and <i>time-interval-to-redirect</i> , if used, results in a redirect timer that never expires. If the redirect timer does not expire, then when a device fails, new hosts continue to be assigned to the failed device instead of being redirected to the backup.
<i>timeout</i>	The time interval, in the range from 600 to 64,800 seconds, before the secondary virtual forwarder becomes unavailable. The default is 14,400 seconds (4 hours).

Command Default

GLBP timers are set to their default values.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Usage Guidelines

Devices on which timer values are not configured can learn timer values from the active virtual gateway (AVG). The timers configured on the AVG always override any other timer settings. All devices in a GLBP group should use the same timer values. If a GLBP gateway sends a hello message, the information should be considered valid for one holdtime. Normally, holdtime is greater than three times the value of hello time, ($holdtime > 3 * hellotime$). The range of values for holdtime force the holdtime to be greater than the hello time.

Examples

The following example shows the GLBP group 10 on GigabitEthernet interface 1/0/1 timers being configured for an interval of 5 seconds between hello packets, and the time after which virtual gateway and virtual forwarder information is considered to be invalid to 18 seconds:

```
Device(config)# interface GigabitEthernet 1/0/1
Device(config-if)# glbp 10 ip
Device(config-if)# glbp 10 timers 5 18
```

Related Commands

Command	Description
glbp ip	Activates GLBP.
show glbp	Displays GLBP information.

glbp weighting

To specify the initial weighting value of the Gateway Load Balancing Protocol (GLBP) gateway, use the **glbp weighting** command in interface configuration mode. To restore the default values, use the **no** form of this command.

```
glbp group weighting maximum [lower lower] [upper upper]  
no glbp group weighting
```

Syntax Description		
	<i>group</i>	GLBP group number in the range from 0 to 1023.
	<i>maximum</i>	Maximum weighting value in the range from 1 to 254. Default value is 100.
	lower <i>lower</i>	(Optional) Specifies a lower weighting value in the range from 1 to the specified maximum weighting value. Default value is 1.
	upper <i>upper</i>	(Optional) Specifies an upper weighting value in the range from the lower weighting to the maximum weighting value. The default value is the specified maximum weighting value.

Command Default The default gateway weighting value is 100 and the default lower weighting value is 1.

Command Modes Interface configuration (config-if)

Command History	Release	Modification
	Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Usage Guidelines The weighting value of a virtual gateway is a measure of the forwarding capacity of the gateway. If a tracked interface on the device fails, the weighting value of the device may fall from the maximum value to below the lower threshold, causing the device to give up its role as a virtual forwarder. When the weighting value of the device rises above the upper threshold, the device can resume its active virtual forwarder role.

Use the **glbp weighting track** and **track** commands to configure parameters for an interface to be tracked. If an interface on a device goes down, the weighting for the device can be reduced by a specified value.

Examples

The following example shows the weighting of the gateway for GLBP group 10 being set to a maximum of 110 with a lower weighting limit of 95 and an upper weighting limit of 105:

```
Device(config)# interface GigabitEthernet 1/0/1  
Device(config-if)# ip address 10.21.8.32 255.255.255.0  
Device(config-if)# glbp 10 weighting 110 lower 95 upper 105
```

Related Commands	Command	Description
	glbp weighting track	Specifies an object to be tracked that affects the weighting of a GLBP gateway.
	track	Configures an interface to be tracked.

glbp weighting track

To specify a tracking object where the Gateway Load Balancing Protocol (GLBP) weighting changes based on the availability of the object being tracked, use the **glbp weighting track** command in interface configuration mode. To remove the tracking, use the **no** form of this command.

```
glbp group weighting track object-number [decrement value]
no glbp group weighting track object-number [decrement value]
```

Syntax Description

<i>group</i>	GLBP group number in the range from 0 to 1023.
<i>object-number</i>	Object number representing an item to be tracked. The valid range is 1 to 1000. Use the track command to configure the tracked object.
decrement value	(Optional) Specifies an amount by which the GLBP weighting for the device is decremented (or incremented) when the interface goes down (or comes back up). The value range is from 1 to 254, with a default value of 10.

Command Default

Objects are not tracked for GLBP weighting changes.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Usage Guidelines

This command ties the weighting of the GLBP gateway to the availability of its interfaces. It is useful for tracking interfaces that are not configured for GLBP.

When a tracked interface goes down, the GLBP gateway weighting decreases by 10. If an interface is not tracked, its state changes do not affect the GLBP gateway weighting. For each GLBP group, you can configure a separate list of interfaces to be tracked.

The optional *value* argument specifies by how much to decrement the GLBP gateway weighting when a tracked interface goes down. When the tracked interface comes back up, the weighting is incremented by the same amount.

When multiple tracked interfaces are down, the configured weighting decrements are cumulative.

Use the **track** command to configure each interface to be tracked.

A maximum of 1000 objects can be tracked. Although 1000 tracked objects can be configured, each tracked object uses CPU resources. The amount of available CPU resources on a device is dependent upon variables such as traffic load and how other protocols are configured and run. The ability to use 1000 tracked objects is dependent upon the available CPU. Testing should be conducted on site to ensure that the service works under the specific site traffic conditions.

Examples

In the following example, GigabitEthernet interface 1/0/1 tracks two interfaces represented by the numbers 1 and 2. If interface 1 goes down, the GLBP gateway weighting decreases by the default value of 10. If interface 2 goes down, the GLBP gateway weighting decreases by 5.

```
Device(config)# interface GigabitEthernet 1/0/1
Device(config-if)# ip address 10.21.8.32 255.255.255.0
Device(config-if)# glbp 10 weighting track 1
Device(config-if)# glbp 10 weighting track 2 decrement 5
```

Related Commands

Command	Description
glbp weighting	Specifies the initial weighting value of a GLBP gateway.
track	Configures an interface to be tracked.

ip address dhcp

To acquire an IP address on an interface from the DHCP, use the **ip address dhcp** command in interface configuration mode. To remove any address that was acquired, use the **no** form of this command.

```
ip address dhcp [client-id interface-type number] [hostname hostname]
no ip address dhcp [client-id interface-type number] [hostname hostname]
```

Syntax Description

client-id	(Optional) Specifies the client identifier. By default, the client identifier is an ASCII value. The client-id interface-type number option sets the client identifier to the hexadecimal MAC address of the named interface.
<i>interface-type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>number</i>	(Optional) Interface or subinterface number. For more information about the numbering syntax for your networking device, use the question mark (?) online help function.
hostname	(Optional) Specifies the hostname.
<i>hostname</i>	(Optional) Name of the host to be placed in the DHCP option 12 field. This name need not be the same as the hostname entered in global configuration mode.

Command Default

The hostname is the globally configured hostname of the device. The client identifier is an ASCII value.

Command Modes

Interface configuration (config-if)

Usage Guidelines



Note

Prior to Cisco IOS Release 12.2(8)T, the **ip address dhcp** command could be used only on Ethernet interfaces.

The **ip address dhcp** command allows any interface to dynamically learn its IP address by using the DHCP protocol. It is especially useful on Ethernet interfaces that dynamically connect to an Internet service provider (ISP). Once assigned a dynamic address, the interface can be used with the Port Address Translation (PAT) of Cisco IOS Network Address Translation (NAT) to provide Internet access to a privately addressed network attached to the device.

The **ip address dhcp** command also works with ATM point-to-point interfaces and will accept any encapsulation type. However, for ATM multipoint interfaces you must specify Inverse ARP via the **protocol ip inarp** interface configuration command and use only the aa15snap encapsulation type.

Some ISPs require that the DHCPDISCOVER message have a specific hostname and client identifier that is the MAC address of the interface. The most typical usage of the **ip address dhcp client-id interface-type number hostname hostname** command is when *interface-type* is the Ethernet interface where the command is configured and *interface-type number* is the hostname provided by the ISP.

A client identifier (DHCP option 61) can be a hexadecimal or an ASCII value. By default, the client identifier is an ASCII value. The **client-id interface-type number** option overrides the default and forces the use of the hexadecimal MAC address of the named interface.



Note Between Cisco IOS Releases 12.1(3)T and 12.2(3), the **client-id** optional keyword allows the change of the fixed ASCII value for the client identifier. After Release 12.2(3), the optional **client-id** keyword forces the use of the hexadecimal MAC address of the named interface as the client identifier.

If a Cisco device is configured to obtain its IP address from a DHCP server, it sends a DHCPDISCOVER message to provide information about itself to the DHCP server on the network.

If you use the **ip address dhcp** command with or without any of the optional keywords, the DHCP option 12 field (hostname option) is included in the DISCOVER message. By default, the hostname specified in option 12 will be the globally configured hostname of the device. However, you can use the **ip address dhcp hostname hostname** command to place a different name in the DHCP option 12 field than the globally configured hostname of the device.

The **no ip address dhcp** command removes any IP address that was acquired, thus sending a DHCPRELEASE message.

You might need to experiment with different configurations to determine the one required by your DHCP server. The table below shows the possible configuration methods and the information placed in the DISCOVER message for each method.

Table 19: Configuration Method and Resulting Contents of the DISCOVER Message

Configuration Method	Contents of DISCOVER Messages
ip address dhcp	The DISCOVER message contains “cisco- <i>mac-address</i> -Eth1” in the client ID field. The <i>mac-address</i> is the MAC address of the Ethernet 1 interface and contains the default hostname of the device in the option 12 field.
ip address dhcp hostname hostname	The DISCOVER message contains “cisco- <i>mac-address</i> -Eth1” in the client ID field. The <i>mac-address</i> is the MAC address of the Ethernet 1 interface, and contains <i>hostname</i> in the option 12 field.
ip address dhcp client-id ethernet 1	The DISCOVER message contains the MAC address of the Ethernet 1 interface in the client ID field and contains the default hostname of the device in the option 12 field.
ip address dhcp client-id ethernet 1 hostname hostname	The DISCOVER message contains the MAC address of the Ethernet 1 interface in the client ID field and contains <i>hostname</i> in the option 12 field.

Examples

In the examples that follow, the command **ip address dhcp** is entered for Ethernet interface 1. The DISCOVER message sent by a device configured as shown in the following example would contain “cisco- *mac-address* -Eth1” in the client-ID field, and the value abc in the option 12 field.

```
hostname abc
!
interface GigabitEthernet 1/0/1
 ip address dhcp
```

The DISCOVER message sent by a device configured as shown in the following example would contain “cisco- mac-address -Eth1” in the client-ID field, and the value def in the option 12 field.

```
hostname abc
!
interface GigabitEthernet 1/0/1
 ip address dhcp hostname def
```

The DISCOVER message sent by a device configured as shown in the following example would contain the MAC address of Ethernet interface 1 in the client-id field, and the value abc in the option 12 field.

```
hostname abc
!
interface Ethernet 1
 ip address dhcp client-id GigabitEthernet 1/0/1
```

The DISCOVER message sent by a device configured as shown in the following example would contain the MAC address of Ethernet interface 1 in the client-id field, and the value def in the option 12 field.

```
hostname abc
!
interface Ethernet 1
 ip address dhcp client-id GigabitEthernet 1/0/1 hostname def
```

Related Commands

Command	Description
ip dhcp pool	Configures a DHCP address pool on a Cisco IOS DHCP server and enters DHCP pool configuration mode.

ip address pool (DHCP)

To enable the IP address of an interface to be automatically configured when a Dynamic Host Configuration Protocol (DHCP) pool is populated with a subnet from IP Control Protocol (IPCP) negotiation, use the **ip address pool** command in interface configuration mode. To disable autoconfiguring of the IP address of the interface, use the **no** form of this command.

ip address pool *name*
no ip address pool

Syntax Description

<i>name</i>	Name of the DHCP pool. The IP address of the interface will be automatically configured from the DHCP pool specified in <i>name</i> .
-------------	---

Command Default

IP address pooling is disabled.

Command Modes

Interface configuration

Usage Guidelines

Use this command to automatically configure the IP address of a LAN interface when there are DHCP clients on the attached LAN that should be serviced by the DHCP pool on the device. The DHCP pool obtains its subnet dynamically through IPCP subnet negotiation.

Examples

The following example specifies that the IP address of GigabitEthernet interface 1/0/1 will be automatically configured from the address pool named abc:

```
ip dhcp pool abc
  import all
  origin ipcp
!
interface GigabitEthernet 1/0/1
  ip address pool abc
```

Related Commands

Command	Description
show ip interface	Displays the usability status of interfaces configured for IP.

ip address

To set a primary or secondary IP address for an interface, use the **ip address** command in interface configuration mode. To remove an IP address or disable IP processing, use the no form of this command.

```
ip address ip-address mask [secondary [vrf vrf-name]]
no ip address ip-address mask [secondary [vrf vrf-name]]
```

Syntax Description

<i>ip-address</i>	IP address.
<i>mask</i>	Mask for the associated IP subnet.
secondary	(Optional) Specifies that the configured address is a secondary IP address. If this keyword is omitted, the configured address is the primary IP address. Note If the secondary address is used for a VRF table configuration with the vrf keyword, the vrf keyword must be specified also.
vrf	(Optional) Name of the VRF table. The <i>vrf-name</i> argument specifies the VRF name of the ingress interface.

Command Default

No IP address is defined for the interface.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Release 2.1	This command was introduced.

Usage Guidelines

An interface can have one primary IP address and multiple secondary IP addresses. Packets generated by the Cisco IOS software always use the primary IP address. Therefore, all devices and access servers on a segment should share the same primary network number.

Hosts can determine subnet masks using the Internet Control Message Protocol (ICMP) mask request message. Devices respond to this request with an ICMP mask reply message.

You can disable IP processing on a particular interface by removing its IP address with the **no ip address** command. If the software detects another host using one of its IP addresses, it will print an error message on the console.

The optional **secondary** keyword allows you to specify an unlimited number of secondary addresses. Secondary addresses are treated like primary addresses, except the system never generates datagrams other than routing updates with secondary source addresses. IP broadcasts and Address Resolution Protocol (ARP) requests are handled properly, as are interface routes in the IP routing table.

Secondary IP addresses can be used in a variety of situations. The following are the most common applications:

- There may not be enough host addresses for a particular network segment. For example, your subnetting allows up to 254 hosts per logical subnet, but on one physical subnet you need 300 host addresses. Using secondary IP addresses on the devices or access servers allows you to have two logical subnets using one physical subnet.

- Many older networks were built using Level 2 bridges. The judicious use of secondary addresses can aid in the transition to a subnetted, device-based network. Devices on an older, bridged segment can be easily made aware that many subnets are on that segment.
- Two subnets of a single network might otherwise be separated by another network. This situation is not permitted when subnets are in use. In these instances, the first network is *extended*, or layered on top of the second network using secondary addresses.



Note If any device on a network segment uses a secondary address, all other devices on that same segment must also use a secondary address from the same network or subnet. Inconsistent use of secondary addresses on a network segment can very quickly cause routing loops.



Note When you are routing using the Open Shortest Path First (OSPF) algorithm, ensure that all secondary addresses of an interface fall into the same OSPF area as the primary addresses.

To transparently bridge IP on an interface, you must perform the following two tasks:

- Disable IP routing (specify the **no ip routing** command).
- Add the interface to a bridge group, see the **bridge-group** command.

To concurrently route and transparently bridge IP on an interface, see the **bridge crb** command.

Examples

In the following example, 192.108.1.27 is the primary address and 192.31.7.17 and 192.31.8.17 are secondary addresses for GigabitEthernet interface 1/0/1:

```
interface GigabitEthernet 1/0/1
 ip address 192.108.1.27 255.255.255.0
 ip address 192.31.7.17 255.255.255.0 secondary
```

Related Commands

Command	Description
match ip route-source	Specifies a source IP address to match to required route maps that have been set up based on VRF connected routes.
route-map	Defines the conditions for redistributing routes from one routing protocol into another, or to enable policy routing.
set vrf	Enables VPN VRF selection within a route map for policy-based routing VRF selection.
show ip arp	Displays the ARP cache, in which SLIP addresses appear as permanent ARP table entries.
show ip interface	Displays the usability status of interfaces configured for IP.
show route-map	Displays static and dynamic route maps.

ip http server

To enable the HTTP server on your IP or IPv6 system, including the Cisco web browser user interface, enter the **ip http server** command in global configuration mode. To disable the HTTP server, use the **no** form of this command..

ip http server
no ip http server

Syntax Description This command has no arguments or keywords.

Command Default The HTTP server uses the standard port 80 by default.
 HTTP/TCP port 8090 is open by default.

Command Modes Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The command enables both IPv4 and IPv6 access to the HTTP server. However, an access list configured with the **ip http access-class** command is applied only to IPv4 traffic. IPv6 traffic filtering is not supported.



Caution The standard HTTP server and the secure HTTP (HTTPS) server can run on a system at the same time. If you enable the HTTPS server using the **ip http secure-server** command, disable the standard HTTP server using the **no ip http server** command to ensure that secure data cannot be accessed through the standard HTTP connection.

To close HTTP/TCP port 8090, you must disable both the HTTP and HTTPS servers. Enter the **no http server** and the **no http secure-server** commands, respectively.

Examples

The following example shows how to enable the HTTP server on both IPv4 and IPv6 systems.

After enabling the HTTP server, you can set the base path by specifying the location of the HTML files to be served. HTML files used by the HTTP web server typically reside in system flash memory. Remote URLs can be specified using this command, but use of remote path names (for example, where HTML files are located on a remote TFTP server) is not recommended.

```
Device(config)#ip http server
Device(config)#ip http path flash:
```

Related Commands

Command	Description
ip http access-class	Specifies the access list that should be used to restrict access to the HTTP server.
ip http path	Specifies the base path used to locate files for use by the HTTP server.

Command	Description
ip http secure-server	Enables the HTTPS server.

ip http secure-server

To enable a secure HTTP (HTTPS) server, enter the **ip http secure-server** command in global configuration mode. To disable the HTTPS server, use the **no** form of this command..

ip http secure-server
no ip http secure-server

Syntax Description This command has no arguments or keywords.

Command Default The HTTPS server is disabled.

Command Modes Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The HTTPS server uses the Secure Sockets Layer (SSL) version 3.0 protocol.



Caution

When enabling an HTTPS server, you should always disable the standard HTTP server to prevent unsecured connections to the same services. Disable the standard HTTP server using the **no ip http server** command in global configuration mode (this step is precautionary; typically, the HTTP server is disabled by default).

If a certificate authority (CA) is used for certification, you should declare the CA trustpoint on the routing device before enabling the HTTPS server.

To close HTTP/TCP port 8090, you must disable both the HTTP and HTTPS servers. Enter the **no http server** and the **no http secure-server** commands, respectively.

Examples

In the following example the HTTPS server is enabled, and the (previously configured) CA trustpoint CA-trust-local is specified:

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#ip http secure-server
Device(config)#ip http secure-trustpoint CA-trust-local
Device(config)#end

Device#show ip http server secure status
HTTP secure server status: Enabled
HTTP secure server port: 443
HTTP secure server ciphersuite: 3des-ede-cbc-sha des-cbc-sha rc4-128-md5 rc4-12a
HTTP secure server client authentication: Disabled
HTTP secure server trustpoint: CA-trust-local
```

Related Commands

Command	Description
ip http secure-trustpoint	Specifies the CA trustpoint that should be used for obtaining signed certificates for the HTTPS server.
ip http server	Enables the HTTP server on an IP or IPv6 system, including the Cisco web browser user interface.
show ip http server secure status	Displays the configuration status of the HTTPS server.

ip nhrp map

To statically configure the IP-to-nonbroadcast multiaccess (NBMA) address mapping of IP destinations connected to an NBMA network, use the **ip nhrp map** command in interface configuration mode. To remove the static entry from Next Hop Resolution Protocol (NHRP) cache, use the **no** form of this command.

```
ip nhrp map ip-address {ip-nbma-address | destination-mask [{ip-nbma-address ipv6-nbma-address}]
ipv6-nbma-address}
no ip nhrp map ip-address {ip-nbma-address | destination-mask [{ip-nbma-address ipv6-nbma-address}]
ipv6-nbma-address}
```

Syntax Description

<i>ip-address</i>	IP address of the destinations reachable through the NBMA network. This address is mapped to the NBMA address.
<i>ip-nbma-address</i>	NBMA address that is directly reachable through the NBMA network. The address format varies depending on the medium; for example, ATM has a Network Service Access Point (NSAP) address, Ethernet has a MAC address, and Switched Multimegabit Data Service (SMDS) has an E.164 address. This address is mapped to the IP address.
<i>destination-mask</i>	Destination address mask.
<i>ipv6-nbma-address</i>	IPv6 NBMA address. Note This argument is not supported in Cisco IOS XE Denali 16.3.1.

Command Default

No static IP-to-NBMA cache entries exist.

Command Modes

Interface configuration(config-if)

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines

In Cisco IOS XE Denali 16.3.1, NHRP supports only hub-to-spoke communication; spoke-to-spoke communication is not supported.



Note

In Cisco IOS XE Denali 16.3.1, this command supports only IPv4; the *ipv6-nbma-address* argument although available on the switch, will not work if configured.

Configure at least one static mapping to reach the next-hop server. To statistically configure multiple IP-to-NBMA address mappings, configure this command multiple times.

When using the routing protocols, Open Shortest Path First (OSPF) or Enhanced Interior Gateway Routing Protocol (EIGRP), configure the **ip ospf network point-to-multipoint** (when OSPF is used for hub-to-spoke communication) and **ip split-horizon eigrp** (when EIGRP is used) commands on the tunnel to allow the traffic.

Examples

In the following example, this station in a multipoint tunnel network is statically configured to be served by two next-hop servers 10.0.0.1 and 10.0.1.3. The NBMA address for 10.0.0.1 is statically configured as 192.0.2.1 and the NBMA address for 10.0.1.3 is 198.51.100.1.

```
Switch(config)# interface tunnel 0
Switch(config-if)# ip nhrp nhs 10.0.0.1
Switch(config-if)# ip nhrp nhs 10.0.1.3
Switch(config-if)# ip nhrp map 10.0.0.1 192.0.2.1
Switch(config-if)# ip nhrp map 10.0.1.3 198.51.100.1
```

Related Commands

Command	Description
clear ip nhrp	Clears all dynamic entries from the NHRP cache.
debug nhrp	Enables NHRP debugging.
interface	Configures an interface and enters interface configuration mode.
ip split-horizon eigrp	Enables EIGRP split horizon.
ip ospf network point-to-multipoint	Configures the OSPF network type to point-to-multipoint.

ip nhrp map multicast

To configure nonbroadcast multiaccess (NBMA) addresses used as destinations for broadcast or multicast packets to be sent over a tunnel network, use the **ip nhrp map multicast** command in interface configuration mode. To remove the destinations, use the **no** form of this command.

```
ip nhrp map multicast {ip-nbma-address ipv6-nbma-address | dynamic}
no ip nhrp map multicast {ip-nbma-address ipv6-nbma-address | dynamic}
```

Syntax Description		
<i>ip-nbma-address</i>		NBMA address that is directly reachable through the NBMA network. The address format varies depending on the medium that you are using.
<i>ipv6-nbma-address</i>		IPv6 NBMA address. Note This argument is not supported in Cisco IOS XE Denali 16.3.1.
dynamic		Dynamically learns destinations from client registrations on the hub.

Command Default No NBMA addresses are configured as destinations for broadcast or multicast packets.

Command Modes Interface configuration (config-if)

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines



Note In Cisco IOS XE Denali 16.3.1, this command supports only IPv4; the *ipv6-nbma-address* argument although available on the switch, will not work if configured.

This command applies only to tunnel interfaces. This command is useful for supporting broadcasts over a tunnel network when the underlying network does not support IP multicast. If the underlying network does support IP multicast, you should use the **tunnel destination** command to configure a multicast destination for transmission of tunnel broadcasts or multicasts.

When multiple NBMA addresses are configured, the system replicates the broadcast packet for each address.

Examples

In the following example, if a packet is sent to 10.255.255.255, it is replicated to destinations 10.0.0.1 and 10.0.0.2:

```
Switch(config)# interface tunnel 0
Switch(config-if)# ip address 10.0.0.3 255.0.0.0
Switch(config-if)# ip nhrp map multicast 10.0.0.1
Switch(config-if)# ip nhrp map multicast 10.0.0.2
```

Related Commands

Command	Description
debug nhrp	Enables NHRP debugging.
interface	Configures an interface and enters interface configuration mode.
tunnel destination	Specifies the destination for a tunnel interface.

ip nhrp network-id

To enable the Next Hop Resolution Protocol (NHRP) on an interface, use the **ip nhrp network-id** command in interface configuration mode. To disable NHRP on the interface, use the **no** form of this command.

ip nhrp network-id *number*
no ip nhrp network-id [*{number}*]

Syntax Description

<i>number</i>	Globally unique, 32-bit network identifier from a nonbroadcast multiaccess (NBMA) network. The range is from 1 to 4294967295.
---------------	---

Command Default

NHRP is disabled on an interface.

Command Modes

Interface configuration (config)

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines

In general, all NHRP stations within one logical NBMA network must be configured with the same network identifier.

Examples

The following example enables NHRP on the interface:

```
Switch(config-if)# ip nhrp network-id 1
```

Related Commands

Command	Description
clear ip nhrp	Clears all dynamic entries from the NHRP cache.
debug nhrp	Enables NHRP debugging.
interface	Configures an interface and enters interface configuration mode.

ip nhrp nhs

To specify the address of one or more Next Hop Resolution Protocol (NHRP) servers, use the **ip nhrp nhs** command in interface configuration mode. To remove the address, use the **no** form of this command.

```
ip nhrp nhs {nhs-address [nbma {nbma-address FQDN-string}] [multicast] [priority value] [cluster value] | cluster value max-connections value | dynamic nbma {nbma-address FQDN-string} [multicast] [priority value] [cluster value] | fallback seconds}
no ip nhrp nhs {nhs-address [nbma {nbma-address FQDN-string}] [multicast] [priority value] [cluster value] | cluster value max-connections value | dynamic nbma {nbma-address FQDN-string} [multicast] [priority value] [cluster value] | fallback seconds}
```

Syntax Description

<i>nhs-address</i>	Address of the next-hop server being specified.
nbma	(Optional) Specifies the nonbroadcast multiple access (NBMA) address or FQDN.
<i>nbma-address</i>	NBMA address.
<i>FQDN-string</i>	Next hop server (NHS) fully qualified domain name (FQDN) string.
multicast	(Optional) Specifies the use of NBMA mapping for broadcasts and multicasts.
priority value	(Optional) Assigns a priority to hubs to control the order in which spokes select hubs to establish tunnels. The range is from 0 to 255; 0 is the highest and 255 is the lowest priority.
cluster value	(Optional) Specifies NHS groups. The range is from 0 to 10.
max-connections value	Specifies the number of NHS elements from each NHS group that needs to be active. The range is from 0 to 255.
dynamic	Configures the spoke to learn the NHS protocol address dynamically.
fallback seconds	Specifies the duration, in seconds, for which the spoke must wait before falling back to an NHS of higher priority upon recovery.

Command Default

No next-hop servers are explicitly configured, so normal network layer routing decisions are used to forward NHRP traffic.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines

Use the **ip nhrp nhs** command to specify the address of a next hop server and the networks it serves. Normally, NHRP consults the network layer forwarding table to determine how to forward NHRP packets. When next hop servers are configured, these next hop addresses override the forwarding path that would otherwise be used for NHRP traffic.

For any next hop server that is configured, you can specify multiple networks by repeating the **ip nhrp nhs** command with the same *nhs-address* argument, but with different IP network addresses.

Examples

The following example shows how to register a hub to a spoke using NBMA and FQDN:

```
Switch# configure terminal
Switch(config)# interface tunnel 1
Switch(config-if)# ip nhrp nhs 192.0.2.1 nbma examplehub.example1.com
```

The following example shows how to configure the desired **max-connections** value:

```
Switch# configure terminal
Switch(config)# interface tunnel 1
Switch(config-if)# ip nhrp nhs cluster 5 max-connections 100
```

The following example shows how to configure the NHS fallback time:

```
Switch# configure terminal
Switch(config)# interface tunnel 1
Switch(config-if)# ip nhrp nhs fallback 25
```

The following example shows how to configure NHS priority and group values:

```
Switch# configure terminal
Switch(config)# interface tunnel 1
Switch(config-if)# ip nhrp nhs 192.0.2.1 priority 1 cluster 2
```

Related Commands

Command	Description
ip nhrp map	Statically configures the IP-to-NBMA address mapping of IP destinations connected to an NBMA network.
show ip nhrp	Displays NHRP mapping information.

key chain

To define an authentication key chain needed to enable authentication for routing protocols and enter key-chain configuration mode, use the **key chain** command in global configuration mode. To remove the key chain, use the **no** form of this command.

key chain *name-of-chain*
no key chain *name-of-chain*

Syntax Description	<i>name-of-chain</i>	Name of a key chain. A key chain must have at least one key and can have up to 2147483647 keys.
---------------------------	----------------------	---

Command Default No key chain exists.

Command Modes Global configuration (config)

Usage Guidelines You must configure a key chain with keys to enable authentication.

Although you can identify multiple key chains, we recommend using one key chain per interface per routing protocol. Upon specifying the **key chain** command, you enter key chain configuration mode.

Examples

The following example shows how to specify key chain:

```
Device(config-keychain-key)# key-string chestnut
```

Related Commands	Command	Description
	accept-lifetime	Sets the time period during which the authentication key on a key chain is received as valid.
	key	Identifies an authentication key on a key chain.
	key-string (authentication)	Specifies the authentication string for a key.
	send-lifetime	Sets the time period during which an authentication key on a key chain is valid to be sent.
	show key chain	Displays authentication key information.

key-string (authentication)

To specify the authentication string for a key, use the **key-string**(authentication) command in key chain key configuration mode. To remove the authentication string, use the **no** form of this command.

key-string **key-string** *text*

no key-string *text*

Syntax Description

<i>text</i>	Authentication string that must be sent and received in the packets using the routing protocol being authenticated. The string can contain from 1 to 80 uppercase and lowercase alphanumeric characters.
-------------	--

Command Default

No authentication string for a key exists.

Command Modes

Key chain key configuration (config-keychain-key)

Examples

The following example shows how to specify the authentication string for a key:

```
Device (config-keychain-key) # key-string key1
```

Related Commands

Command	Description
accept-lifetime	Sets the time period during which the authentication key on a key chain is received as valid.
key	Identifies an authentication key on a key chain.
key chain	Defines an authentication key-chain needed to enable authentication for routing protocols.
send-lifetime	Sets the time period during which an authentication key on a key chain is valid to be sent.
show key chain	Displays authentication key information.

key

To identify an authentication key on a key chain, use the **key** command in key-chain configuration mode. To remove the key from the key chain, use the **no** form of this command.

key *key-id*
no key *key-id*

Syntax Description

<i>key-id</i>	Identification number of an authentication key on a key chain. The range of keys is from 0 to 2147483647. The key identification numbers need not be consecutive.
---------------	---

Command Default

No key exists on the key chain.

Command Modes

Key-chain configuration (config-keychain)

Usage Guidelines

It is useful to have multiple keys on a key chain so that the software can sequence through the keys as they become invalid after time, based on the **accept-lifetime** and **send-lifetime** key chain key command settings.

Each key has its own key identifier, which is stored locally. The combination of the key identifier and the interface associated with the message uniquely identifies the authentication algorithm and Message Digest 5 (MD5) authentication key in use. Only one authentication packet is sent, regardless of the number of valid keys. The software starts looking at the lowest key identifier number and uses the first valid key.

If the last key expires, authentication will continue and an error message will be generated. To disable authentication, you must manually delete the last valid key.

To remove all keys, remove the key chain by using the **no key chain** command.

Examples

The following example shows how to specify a key to identify authentication on a key-chain:

```
Device(config-keychain)# key 1
```

Related Commands

Command	Description
accept-lifetime	Sets the time period during which the authentication key on a key chain is received as valid.
key chain	Defines an authentication key chain needed to enable authentication for routing protocols.
key-string (authentication)	Specifies the authentication string for a key.
send-lifetime	Sets the time period during which an authentication key on a key chain is valid to be sent.
show key chain	Displays authentication key information.

show glbp

To display Gateway Load Balancing Protocol (GLBP) information, use the **show glbp** command in privileged EXEC mode.

capability [*interface-type interface-number*]
interface-type interface-number [*group-number*] [*state*] [**brief**]

Syntax Description

capability	(Optional) Displays the GLBP capability interfaces.
<i>interface-type interface-number</i>	(Optional) Interface type and number for which output is displayed.
<i>group-number</i>	(Optional) GLBP group number in the range from 0 to 1023.
<i>state</i>	(Optional) State of the GLBP device, one of the following: active , disabled , init , listen , and standby .
brief	(Optional) Summarizes each virtual gateway or virtual forwarder with a single line of output.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Usage Guidelines

Use the **show glbp** command to display information about GLBP groups on a device. The **brief** keyword displays a single line of information about each virtual gateway or virtual forwarder. The **capability** keyword displays all GLBP-capable interfaces.

Examples

The following is sample output from the **show glbp** command that displays GLBP group 10:

```
Device# show glbp GigabitEthernet 1/0/1 10
GigabitEthernet1/0/1 - Group 10
  State is Active
    1 state change, last state change 00:04:52
  Virtual IP address is 10.21.8.10
  Hello time 3 sec, hold time 10 sec
    Next hello sent in 0.608 secs
  Redirect time 600 sec, forwarder time-out 14400 sec
  Preemption disabled
  Active is local
  Standby is unknown
  Priority 100 (default)
  Weighting 100 (default 100), thresholds: lower 1, upper 100
  Load balancing: round-robin
  Group members:
    ac7e.8a35.6364 (10.21.8.32) local
  There is 1 forwarder (1 active)
  Forwarder 1
    State is Active
      1 state change, last state change 00:04:41
```

```

MAC address is 0007.b400.0a01 (default)
Owner ID is ac7e.8a35.6364
Redirection enabled
Preemption enabled, min delay 30 sec
Active is local, weighting 100

```

The table below describes the significant fields shown in the displays.

Table 20: show glbp Field Descriptions

Field	Description
GigabitEthernet1/0/1 - Group	Interface type and number and GLBP group number for the interface.
State is	<p>State of the virtual gateway or virtual forwarder. For a virtual gateway, the state can be one of the following:</p> <ul style="list-style-type: none"> • Active--The gateway is the active virtual gateway (AVG) and is responsible for responding to Address Resolution Protocol (ARP) requests for the virtual IP address. • Disabled--The virtual IP address has not been configured or learned yet, but another GLBP configuration exists. • Initial--The virtual IP address has been configured or learned, but virtual gateway configuration is not complete. An interface must be up and configured to route IP, and an interface IP address must be configured. • Listen--The virtual gateway is receiving hello packets and is ready to change to the “speak” state if the active or standby virtual gateway becomes unavailable. • Speak--The virtual gateway is attempting to become the active or standby virtual gateway. • Standby--The gateway is next in line to be the AVG.
Virtual IP address is	The virtual IP address of the GLBP group. All secondary virtual IP addresses are listed on separate lines. If one of the virtual IP addresses is a duplicate of an address configured for another device, it will be marked as “duplicate.” A duplicate address indicates that the device has failed to defend its ARP cache entry.
Hello time, hold time	The hello time is the time between hello packets (in seconds or milliseconds). The hold time is the time (in seconds or milliseconds) before other devices declare the active device to be down. All devices in a GLBP group use the hello- and hold-time values of the current AVG. If the locally configured values are different, the configured values appear in parentheses after the hello- and hold-time values.
Next hello sent in	The time until GLBP will send the next hello packet (in seconds or milliseconds).
Preemption	<p>Whether GLBP gateway preemption is enabled. If enabled, the minimum delay is the time (in seconds) for which a higher-priority nonactive device will wait before preempting the lower-priority active device.</p> <p>This field is also displayed under the forwarder section where it indicates GLBP forwarder preemption.</p>

Field	Description
Active is	The active state of the virtual gateway. The value can be “local,” “unknown,” or an IP address. The address (and the expiration date of the address) is the address of the current AVG. This field is also displayed under the forwarder section where it indicates the address of the current AVF.
Standby is	The standby state of the virtual gateway. The value can be “local,” “unknown,” or an IP address. The address (and the expiration date of the address) is the address of the standby gateway (the gateway that is next in line to be the AVG).
Weighting	The initial weighting value with lower and upper threshold values.
Track object	The list of objects that are being tracked and their corresponding states.
IP redundancy name is	The name of the GLBP group.

Related Commands

Command	Description
glbp ip	Enables GLBP.
glbp timers	Configures the time between hello messages and the time before other devices declare the active GLBP device to be down.
glbp weighting track	Specifies an object to be tracked that affects the weighting of a GLBP gateway.

show ip nhrp nhs

To display Next Hop Resolution Protocol (NHRP) next hop server (NHS) information, use the **show ip nhrp nhs** command in user EXEC or privileged EXEC mode.

```
show ip nhrp nhs [{interface}] [detail] [{redundancy [{cluster number | preempted | running | waiting}]]]
```

Syntax Description		
<i>interface</i>	(Optional) Displays NHS information currently configured on the interface. See the table below for types, number ranges, and descriptions.	
detail	(Optional) Displays detailed NHS information.	
redundancy	(Optional) Displays information about NHS redundancy stacks.	
cluster number	(Optional) Displays redundancy cluster information.	
preempted	(Optional) Displays information about NHS that failed to become active and is preempted.	
running	(Optional) Displays NHSs that are currently in Responding or Expecting replies states.	
waiting	(Optional) Displays NHSs awaiting to be scheduled.	

Command Modes User EXEC (>)

Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines The table below lists the valid types, number ranges, and descriptions for the optional *interface* argument.



Note The valid types can vary according to the platform and interfaces on the platform.

Table 21: Valid Types, Number Ranges, and Interface Descriptions

Valid Types	Number Ranges	Interface Descriptions
ANI	0 to 1000	Autonomic-Networking virtual interface
Auto-Template	1 to 999	Auto-Template interface
Capwap	0 to 2147483647	Control and Provisioning of Wireless Access Points protocol (CAPWAP) tunnel interface
GMPLS	0 to 1000	Multiprotocol Label Switching (MPLS) interface

Valid Types	Number Ranges	Interface Descriptions
GigabitEthernet	0 to 9	GigabitEthernet IEEE 802.3z
InternalInterface	0 to 9	Internal interface
LISP	0 to 65520	Locator/ID Separation Protocol (LISP) virtual interface
loopback	0 to 2147483647	Loopback interface
Null	0 to 0	Null interface
PROTECTION_GROUP	0 to 0	Protection-group controller
Port-channel	1 to 128	Port channel interface
TenGigabitEthernet	0 to 9	TenGigabitEthernet interface
Tunnel	0 to 2147483647	Tunnel interface
Tunnel-tp	0 to 65535	MPLS Transport Profile interface
Vlan	1 to 4094	VLAN interface

Examples

The following is sample output from the **show ip nhrp nhs detail** command:

```
Switch# show ip nhrp nhs detail

Legend:
  E=Expecting replies
  R=Responding
Tunnell:
  10.1.1.1          E req-sent 128 req-failed 1 repl-recv 0
Pending Registration Requests:
Registration Request: Reqid 1, Ret 64 NHS 10.1.1.1
```

The table below describes the significant field shown in the display.

Table 22: show ip nhrp nhs Field Descriptions

Field	Description
Tunnell	Interface through which the target network is reached.

Related Commands

Command	Description
ip nhrp map	Statically configures the IP-to-NBMA address mapping of IP destinations connected to an NBMA network.
show ip nhrp	Displays NHRP mapping information.

show key chain

To display the keychain, use the **show key chain** command.

show key chain [*name-of-chain*]

Syntax Description	<i>name-of-chain</i> (Optional) Name of the key chain to display, as named in the key chain command.
---------------------------	--

Command Default If the command is used without any parameters, then it lists out all the key chains.

Command Modes Privileged EXEC (#)

Examples

The following is sample output from the **show key chain** command:

```

show key chain
Device# show key chain

Key-chain AuthenticationGLBP:
  key 1 -- text "Thisisasecretkey"
    accept lifetime (always valid) - (always valid) [valid now]
    send lifetime (always valid) - (always valid) [valid now]
Key-chain glbp2:
  key 100 -- text "abc123"
    accept lifetime (always valid) - (always valid) [valid now]
    send lifetime (always valid) - (always valid) [valid now]

```

Related Commands	Command	Description
	key-string	Specifies the authentication string for a key.
	send-lifetime	Sets the time period during which an authentication key on a key chain is valid to be sent.

show track

To display information about objects that are tracked by the tracking process, use the **show track** command in privileged EXEC mode.

```
show track [{object-number [brief] | application [brief] | interface [brief] | ip[route [brief] | [sla [brief]] | ipv6 [route [brief]] | list [route [brief]] | resolution [ip | ipv6] | stub-object [brief] | summary | timers}]
```

Syntax Description

<i>object-number</i>	(Optional) Object number that represents the object to be tracked. The range is from 1 to 1000.
brief	(Optional) Displays a single line of information related to the preceding argument or keyword.
application	(Optional) Displays tracked application objects.
interface	(Optional) Displays tracked interface objects.
ip route	(Optional) Displays tracked IP route objects.
ip sla	(Optional) Displays tracked IP SLA objects.
ipv6 route	(Optional) Displays tracked IPv6 route objects.
list	(Optional) Displays the list of boolean objects.
resolution	(Optional) Displays resolution of tracked parameters.
summary	(Optional) Displays the summary of the specified object.
timers	(Optional) Displays polling interval timers.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.
XE 3.10S	This command was modified. The output was enhanced to display IPv6 route information.

Usage Guidelines

Use this command to display information about objects that are tracked by the tracking process. When no arguments or keywords are specified, information for all objects is displayed.

A maximum of 1000 objects can be tracked. Although 1000 tracked objects can be configured, each tracked object uses CPU resources. The amount of available CPU resources on a device is dependent upon variables such as traffic load and how other protocols are configured and run. The ability to use 1000 tracked objects is dependent upon the available CPU. Testing should be conducted on site to ensure that the service works under the specific site traffic conditions.

Examples

The following example shows information about the state of IP routing on the interface that is being tracked:

```
Device# show track 1

Track 1
  Interface GigabitEthernet 1/0/1 ip routing
  IP routing is Down (no IP addr)
  1 change, last change 00:01:08
```

The table below describes the significant fields shown in the displays.

Table 23: show track Field Descriptions

Field	Description
Track	Object number that is being tracked.
Interface GigabitEthernet 1/0/1 ip routing	Interface type, interface number, and object that is being tracked.
IP routing is	State value of the object, displayed as Up or Down. If the object is down, the reason is displayed.
1 change, last change	Number of times that the state of a tracked object has changed and the time (in <i>hh:mm:ss</i>) since the last change.

Related Commands

Command	Description
show track resolution	Displays the resolution of tracked parameters.
track interface	Configures an interface to be tracked and enters tracking configuration mode.
track ip route	Tracks the state of an IP route and enters tracking configuration mode.

track

To configure an interface to be tracked where the Gateway Load Balancing Protocol (GLBP) weighting changes based on the state of the interface, use the **track** command in global configuration mode. To remove the tracking, use the **no** form of this command.

```
track object-number interface type number {line-protocol | ip routing | ipv6 routing}
no track object-number interface type number {line-protocol | ip routing | ipv6 routing}
```

Syntax Description

<i>object-number</i>	Object number in the range from 1 to 1000 representing the interface to be tracked.
interface <i>type number</i>	Interface type and number to be tracked.
line-protocol	Tracks whether the interface is up.
ip routing	Tracks whether IP routing is enabled, an IP address is configured on the interface, and the interface state is up, before reporting to GLBP that the interface is up.
ipv6 routing	Tracks whether IPv6 routing is enabled, an IP address is configured on the interface, and the interface state is up, before reporting to GLBP that the interface is up.

Command Default

The state of the interfaces is not tracked.

Command Modes

Global configuration (config)

Usage Guidelines

Use the **track** command in conjunction with the **glbp weighting** and **glbp weighting track** commands to configure parameters for an interface to be tracked. If a tracked interface on a GLBP device goes down, the weighting for that device is reduced. If the weighting falls below a specified minimum, the device will lose its ability to act as an active GLBP virtual forwarder.

A maximum of 1000 objects can be tracked. Although 1000 tracked objects can be configured, each tracked object uses CPU resources. The amount of available CPU resources on a device is dependent upon variables such as traffic load and how other protocols are configured and run. The ability to use 1000 tracked objects is dependent upon the available CPU. Testing should be conducted on site to ensure that the service works under the specific site traffic conditions.

Examples

In the following example, TenGigabitEthernet interface 0/0/1 tracks whether GigabitEthernet interfaces 1/0/1 and 1/0/3 are up. If either of the GigabitEthernet interface goes down, the GLBP weighting is reduced by the default value of 10. If both GigabitEthernet interfaces go down, the GLBP weighting will fall below the lower threshold and the device will no longer be an active forwarder. To resume its role as an active forwarder, the device must have both tracked interfaces back up, and the weighting must rise above the upper threshold.

```
Device(config)# track 1 interface GigabitEthernet 1/0/1 line-protocol
Device(config-track)# exit
Device(config)# track 2 interface GigabitEthernet 1/0/3 line-protocol
Device(config-track)# exit
Device(config)# interface TenGigabitEthernet 0/0/1
Device(config-if)# ip address 10.21.8.32 255.255.255.0
Device(config-if)# glbp 10 weighting 110 lower 95 upper 105
```

```
Device(config-if)# glbp 10 weighting track 1  
Device(config-if)# glbp 10 weighting track 2
```

Related Commands

Command	Description
glbp weighting	Specifies the initial weighting value of a GLBP gateway.
glbp weighting track	Specifies an object to be tracked that affects the weighting of a GLBP gateway.

vrrp

To create a Virtual Router Redundancy Protocol version 3 (VRRPv3) group and enter VRRPv3 group configuration mode, use the **vrrp**. To remove the VRRPv3 group, use the **no** form of this command.

```
vrrp group-id address-family {ipv4 | ipv6}
no vrrp group-id address-family {ipv4 | ipv6}
```

Syntax Description

<i>group-id</i>	Virtual router group number. The range is from 1 to 255.
address-family	Specifies the address-family for this VRRP group.
ipv4	(Optional) Specifies IPv4 address.
ipv6	(Optional) Specifies IPv6 address.

Command Default

None

Command Modes

Interface configuration (config-if)

Usage Guidelines

Examples

The following example shows how to create a VRRPv3 group and enter VRRP configuration mode:

```
Device(config-if)# vrrp 3 address-family ipv4
```

Related Commands

Command	Description
timers advertise	Sets the advertisement timer in milliseconds.

vrrp description

To assign a description to the Virtual Router Redundancy Protocol (VRRP) group, use the **vrrp description** command in interface configuration mode. To remove the description, use the **no** form of this command.

description *text*
no description

Syntax Description

<i>text</i>	Text (up to 80 characters) that describes the purpose or use of the group.
-------------	--

Command Default

There is no description of the VRRP group.

Command Modes

VRRP configuration (config-if-vrrp)

Command History

Release	Modification
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Examples

The following example enables VRRP. VRRP group 1 is described as Building A – Marketing and Administration.

```
Device(config-if-vrrp)# description Building A - Marketing and Administration
```

Related Commands

Command	Description
vrrp	Creates a VRRPv3 group and enters VRRPv3 group configuration mode.

vrrp preempt

To configure the device to take over as master virtual router for a Virtual Router Redundancy Protocol (VRRP) group if it has higher priority than the current master virtual router, use the **preempt** command in VRRP configuration mode. To disable this function, use the **no** form of this command.

preempt [**delay minimum** *seconds*]
no preempt

Syntax Description	delay minimum <i>seconds</i> (Optional) Number of seconds that the device will delay before issuing an advertisement claiming master ownership. The default delay is 0 seconds.
---------------------------	--

Command Default This command is enabled.

Command Modes VRRP configuration (config-if-vrrp)

Command History	Release	Modification
	Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Usage Guidelines By default, the device being configured with this command will take over as master virtual router for the group if it has a higher priority than the current master virtual router. You can configure a delay, which will cause the VRRP device to wait the specified number of seconds before issuing an advertisement claiming master ownership.



Note The device that is the IP address owner will preempt, regardless of the setting of this command.

Examples

The following example configures the device to preempt the current master virtual router when its priority of 200 is higher than that of the current master virtual router. If the device preempts the current master virtual router, it waits 15 seconds before issuing an advertisement claiming it is the master virtual router.

```
Device(config-if-vrrp)#preempt delay minimum 15
```

Related Commands	Command	Description
	vrrp	Creates a VRRPv3 group and enters VRRPv3 group configuration mode.
	priority	Sets the priority level of the device within a VRRP group.

vrrp priority

To set the priority level of the device within a Virtual Router Redundancy Protocol (VRRP) group, use the **priority** command in interface configuration mode. To remove the priority level of the device, use the **no** form of this command.

priority *level*
no priority *level*

Syntax Description	<i>level</i> Priority of the device within the VRRP group. The range is from 1 to 254. The default is 100.
---------------------------	--

Command Default The priority level is set to the default value of 100.

Command Modes VRRP configuration (config-if-vrrp)

Command History	Release	Modification
	Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Usage Guidelines Use this command to control which device becomes the master virtual router.

Examples The following example configures the device with a priority of 254:

```
Device(config-if-vrrp)# priority 254
```

Related Commands	Command	Description
	vrrp	Creates a VRRPv3 group and enters VRRPv3 group configuration mode.
	vrrp preempt	Configures the device to take over as master virtual router for a VRRP group if it has higher priority than the current master virtual router.

vrrp timers advertise

To configure the interval between successive advertisements by the master virtual router in a Virtual Router Redundancy Protocol (VRRP) group, use the **timers advertise** command in VRRP configuration mode. To restore the default value, use the **no** form of this command.

timers advertise [*msec*] *interval*
no timers advertise [*msec*] *interval*

Syntax Description

<i>group</i>	Virtual router group number. The group number range is from 1 to 255.
msec	(Optional) Changes the unit of the advertisement time from seconds to milliseconds. Without this keyword, the advertisement interval is in seconds.
<i>interval</i>	Time interval between successive advertisements by the master virtual router. The unit of the interval is in seconds, unless the msec keyword is specified. The default is 1 second. The valid range is 1 to 255 seconds. When the msec keyword is specified, the valid range is 50 to 999 milliseconds.

Command Default

The default interval of 1 second is configured.

Command Modes

VRRP configuration (config-if-vrrp)

Command History

Release	Modification
Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Usage Guidelines

The advertisements being sent by the master virtual router communicate the state and priority of the current master virtual router.

The **vrrp timers advertise** command configures the time between successive advertisement packets and the time before other routers declare the master router to be down. Routers or access servers on which timer values are not configured can learn timer values from the master router. The timers configured on the master router always override any other timer settings. All routers in a VRRP group must use the same timer values. If the same timer values are not set, the devices in the VRRP group will not communicate with each other and any misconfigured device will change its state to master.

Examples

The following example shows how to configure the master virtual router to send advertisements every 4 seconds:

```
Device(config-if-vrrp)# timers advertise 4
```

Related Commands

Command	Description
vrrp	Creates a VRRPv3 group and enters VRRPv3 group configuration mode.
timers learn	Configures the device, when it is acting as backup virtual router for a VRRP group, to learn the advertisement interval used by the master virtual router.

vrrs leader

To specify a leader's name to be registered with Virtual Router Redundancy Service (VRRS), use the **vrrs leader** command. To remove the specified VRRS leader, use the **no** form of this command.

vrrs leader *vrrs-leader-name*
no vrrs leader *vrrs-leader-name*

Syntax Description	<i>vrrs-leader-name</i>	Name of VRRS Tag to lead.
---------------------------	-------------------------	---------------------------

Command Default A registered VRRS name is unavailable by default.

Command Modes VRRP configuration (config-if-vrrp)

Command History	Release	Modification
	Cisco IOS XE Release 2.1	This command was integrated into Cisco IOS XE Release 2.1.

Examples

The following example specifies a leader's name to be registered with VRRS:

```
Device(config-if-vrrp)# vrrs leader leader-1
```

Related Commands	Command	Description
	vrrp	Creates a VRRP group and enters VRRP configuration mode.



PART **V**

IP Multicast Routing Commands

- [IP Multicast Commands, on page 317](#)



IP Multicast Commands

- [cache-memory-max](#), on page 319
- [clear ip mfib counters](#), on page 320
- [clear ip mroute](#), on page 321
- [ip igmp filter](#), on page 322
- [ip igmp max-groups](#), on page 323
- [ip igmp profile](#), on page 325
- [ip igmp snooping](#), on page 326
- [ip igmp snooping last-member-query-count](#), on page 327
- [ip igmp snooping querier](#), on page 329
- [ip igmp snooping report-suppression](#), on page 331
- [ip igmp snooping vlan mrouter](#), on page 332
- [ip igmp snooping vlan static](#), on page 333
- [ip multicast auto-enable](#), on page 334
- [ip multicast vlan](#), on page 335
- [ip pim accept-register](#), on page 336
- [ip pim bsr-candidate](#), on page 337
- [ip pim rp-candidate](#), on page 339
- [ip pim send-rp-announce](#), on page 340
- [ip pim spt-threshold](#), on page 342
- [match message-type](#), on page 343
- [match service-type](#), on page 344
- [match service-instance](#), on page 345
- [mrinfo](#), on page 346
- [redistribute mdns-sd](#), on page 348
- [service-list mdns-sd](#), on page 349
- [service-policy-query](#), on page 350
- [service-routing mdns-sd](#), on page 351
- [service-policy](#), on page 352
- [show ip igmp filter](#), on page 353
- [show ip igmp profile](#), on page 354
- [show ip igmp snooping](#), on page 355
- [show ip igmp snooping groups](#), on page 357
- [show ip igmp snooping igmpv2-tracking](#), on page 358

- [show ip igmp snooping mrouter](#), on page 359
- [show ip igmp snooping querier](#), on page 360
- [show ip igmp snooping wireless mcast-spi-count](#), on page 362
- [show ip igmp snooping wireless mgid](#), on page 363
- [show ip pim autorp](#), on page 364
- [show ip pim bsr-router](#), on page 365
- [show ip pim bsr](#), on page 366
- [show ip pim tunnel](#), on page 367
- [show mdns cache](#), on page 369
- [show mdns requests](#), on page 371
- [show mdns statistics](#), on page 372
- [show platform ip multicast](#), on page 373
- [wireless mdns-bridging](#), on page 381
- [wireless multicast](#), on page 382

cache-memory-max

To set a percentage of the system memory for cache, use the **cache-memory-max** command. To remove a percentage of system memory for cache, use the **no** form of this command.

cache-memory-max *cache-config-percentage*
no cache-memory-max *cache-config-percentage*

Syntax Description *cache-config-percentage* A percentage of the system memory for cache.

Command Default 10 percent.

Command Modes mDNS configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The number of services learned in a network could be large, so there is an upper limit on the amount of cache memory that can be used. The memory is set by default to a maximum of 10 percent of the system memory.



Note You can override the default value by using this command.

When you try to add new records, and the cache is full, the records in the cache that are close to expiring are deleted to provide space for the new records.

Example

This example sets 20 percent of the system memory for cache:

```
Device(config-mdns)# cache-memory-max 20
```

clear ip mfib counters

To clear all active IPv4 multicast forwarding information base (MFIB) traffic counters, use the **clear ip mfib counters** privileged exec command.

```
clear ip mfib [global | vrf *] counters [group-address] [hostname | source-address]
```

Syntax Description	global	(Optional) Resets the IP multicast forwarding information base cache to the global default configuration.
	vrf *	(Optional) Clears the IP multicast forwarding information base cache for all VPN routing and forwarding instances.
	group-address	(Optional) Limits the active multicast forwarding information base (MFIB) traffic counters to the indicated group address.
	hostname source-address	(Optional) Limits the active multicast forwarding information base (MFIB) traffic counters to the indicated host name or source address.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.
Usage Guidelines	None	

Examples

The following example shows how to reset all active MFIB traffic counters for all multicast tables:

```
Device# clear ip mfib counters
```

The following example shows how to reset the IP multicast forwarding information base cache counters to the global default configuration:

```
Device# clear ip mfib global counters
```

The following example shows how to clear the IP multicast forwarding information base cache for the all VPN routing and forwarding instances:

```
Device# clear ip mfib vrf * counters
```

clear ip mroute

To delete entries from the IP multicast routing table, use the **clear ip mroute** privileged EXEC command.

```
clear ip mroute [vrf vrf-name] {* | ip-address | group-address} [hostname | source-address]
```

Syntax Description	
vrf vrf-name	(Optional) Specifies the name that is assigned to the multicast VPN routing and forwarding (VRF) instance.
*	Specifies all Multicast routes.
<i>ip-address</i>	Multicast routes for the IP address.
<i>group-address</i>	Multicast routes for the group address.
<i>hostname</i>	(Optional) Multicast routes for the host name.
<i>source-address</i>	(Optional) Multicast routes for the source address.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines

The *group-address* variable specifies one of the following:

- Name of the multicast group as defined in the DNS hosts table or with the **ip host** command.
- IP address of the multicast group in four-part, dotted notation.

If you specify a group name or address, you can also enter the source argument to specify a name or address of a multicast source that is sending to the group. A source does not need to be a member of the group.

Examples

The following example shows how to delete all entries from the IP multicast routing table:

```
Device# clear ip mroute *
```

The following example shows how to delete all sources on the 228.3.0.0 subnet that are sending to the multicast group 224.2.205.42 from the IP multicast routing table. This example shows how to delete all sources on network 228.3, not individual sources:

```
Device# clear ip mroute 224.2.205.42 228.3.0.0
```

ip igmp filter

To control whether or not all hosts on a Layer 2 interface can join one or more IP multicast groups by applying an Internet Group Management Protocol (IGMP) profile to the interface, use the **ip igmp filter** interface configuration command on the device stack or on a standalone device. To remove the specified profile from the interface, use the **no** form of this command.

```
ip igmp filter profile number
no ip igmp filter
```

Syntax Description	<i>profile number</i> The IGMP profile number to be applied. The range is 1 to 4294967295.
---------------------------	--

Command Default	No IGMP filters are applied.
------------------------	------------------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines	You can apply IGMP filters only to Layer 2 physical interfaces; you cannot apply IGMP filters to routed ports, switch virtual interfaces (SVIs), or ports that belong to an EtherChannel group.
-------------------------	---

An IGMP profile can be applied to one or more device port interfaces, but one port can have only one profile applied to it.

Example

You can verify your setting by using the **show running-config** privileged EXEC command and by specifying an interface.

ip igmp max-groups

To set the maximum number of Internet Group Management Protocol (IGMP) groups that a Layer 2 interface can join or to configure the IGMP throttling action when the maximum number of entries is in the forwarding table, use the **ip igmp max-groups** interface configuration command on the device stack or on a standalone device. To set the maximum back to the default, which is to have no maximum limit, or to return to the default throttling action, which is to drop the report, use the **no** form of this command.

```
ip igmp max-groups {max number | action { deny | replace }}
no ip igmp max-groups {max number | action }
```

Syntax Description

<i>max number</i>	The maximum number of IGMP groups that an interface can join. The range is 0 to 4294967294. The default is no limit.
action deny	Drops the next IGMP join report when the maximum number of entries is in the IGMP snooping forwarding table. This is the default action.
action replace	Replaces the existing group with the new group for which the IGMP report was received when the maximum number of entries is in the IGMP snooping forwarding table.

Command Default

The default maximum number of groups is no limit.

After the device learns the maximum number of IGMP group entries on an interface, the default throttling action is to drop the next IGMP report that the interface receives and to not add an entry for the IGMP group to the interface.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You can use this command only on Layer 2 physical interfaces and on logical EtherChannel interfaces. You cannot set IGMP maximum groups for routed ports, switch virtual interfaces (SVIs), or ports that belong to an EtherChannel group.

Follow these guidelines when configuring the IGMP throttling action:

- If you configure the throttling action as deny and set the maximum group limitation, the entries that were previously in the forwarding table are not removed but are aged out. After these entries are aged out, when the maximum number of entries is in the forwarding table, the device drops the next IGMP report received on the interface.
- If you configure the throttling action as replace and set the maximum group limitation, the entries that were previously in the forwarding table are removed. When the maximum number of entries is in the forwarding table, the device replaces a randomly selected multicast entry with the received IGMP report.
- When the maximum group limitation is set to the default (no maximum), entering the **ip igmp max-groups {deny | replace}** command has no effect.

Examples

This example shows how to limit to 25 the number of IGMP groups that a port can join:

```
Device(config)# interface gigabitethernet1/0/2  
Device(config-if)# ip igmp max-groups 25
```

This example shows how to configure the device to replace the existing group with the new group for which the IGMP report was received when the maximum number of entries is in the forwarding table:

```
Device(config)# interface gigabitethernet2/0/1  
Device(config-if)# ip igmp max-groups action replace
```

You can verify your setting by using the **show running-config** privileged EXEC command and by specifying an interface.

ip igmp profile

To create an Internet Group Management Protocol (IGMP) profile and enter IGMP profile configuration mode, use the **ip igmp profile** global configuration command on the device stack or on a standalone device. From this mode, you can specify the configuration of the IGMP profile to be used for filtering IGMP membership reports from a switch port. To delete the IGMP profile, use the **no** form of this command.

ip igmp profile *profile number*
no ip igmp profile *profile number*

Syntax Description	<i>profile number</i> The IGMP profile number being configured. The range is from 1 to 4294967295.	
Command Default	No IGMP profiles are defined. When configured, the default action for matching an IGMP profile is to deny matching addresses.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

When you are in IGMP profile configuration mode, you can create the profile by using these commands:

- **deny**—Specifies that matching addresses are denied; this is the default condition.
- **exit**—Exits from igmp-profile configuration mode.
- **no**—Negates a command or resets to its defaults.
- **permit**—Specifies that matching addresses are permitted.
- **range**—Specifies a range of IP addresses for the profile. This can be a single IP address or a range with a start and an end address.

When entering a range, enter the low IP multicast address, a space, and the high IP multicast address.

You can apply an IGMP profile to one or more Layer 2 interfaces, but each interface can have only one profile applied to it.

Example

This example shows how to configure IGMP profile 40 that permits the specified range of IP multicast addresses:

```
Device(config)# ip igmp profile 40
Device(config-igmp-profile)# permit
Device(config-igmp-profile)# range 233.1.1.1 233.255.255.255
```

You can verify your settings by using the **show ip igmp profile** privileged EXEC command.

ip igmp snooping

To globally enable Internet Group Management Protocol (IGMP) snooping on the device or to enable it on a per-VLAN basis, use the **ip igmp snooping** global configuration command on the device stack or on a standalone device. To return to the default setting, use the **no** form of this command.

ip igmp snooping [**vlan** *vlan-id*]

no ip igmp snooping [**vlan** *vlan-id*]

Syntax Description	vlan <i>vlan-id</i> (Optional) Enables IGMP snooping on the specified VLAN. The range is 1 to 1001 and 1006 to 4094.	
Command Default	IGMP snooping is globally enabled on the device. IGMP snooping is enabled on VLAN interfaces.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	When IGMP snooping is enabled globally, it is enabled in all of the existing VLAN interfaces. When IGMP snooping is globally disabled, it is disabled on all of the existing VLAN interfaces. VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping.	

Examples

This example shows how to globally enable IGMP snooping:

```
Device(config)# ip igmp snooping
```

This example shows how to enable IGMP snooping on VLAN 1:

```
Device(config)# ip igmp snooping vlan 1
```

You can verify your settings by entering the **show ip igmp snooping** privileged EXEC command.

ip igmp snooping last-member-query-count

To configure how often Internet Group Management Protocol (IGMP) snooping will send query messages in response to receiving an IGMP leave message, use the **ip igmp snooping last-member-query-count** command in global configuration mode. To set *count* to the default value, use the **no** form of the command.

```
ip igmp snooping [vlan vlan-id] last-member-query-count count
no ip igmp snooping [vlan vlan-id] last-member-query-count count
```

Syntax Description	vlan <i>vlan-id</i> (Optional) Sets the count value on a specific VLAN ID. The range is from 1 to 1001. Do not enter leading zeroes.				
	<i>count</i> The interval at which query messages are sent, in milliseconds. The range is from 1 to 7. The default is 2.				
Command Default	A query is sent every 2 milliseconds.				
Command Modes	Global configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

Usage Guidelines When a multicast host leaves a group, the host sends an IGMP leave message. To check if this host is the last to leave the group, IGMP query messages are sent when the leave message is seen until the **last-member-query-interval** timeout period expires. If no response to the last-member queries are received before the timeout period expires, the group record is deleted.

Use the **ip igmp snooping last-member-query-interval** command to configure the timeout period.

When both IGMP snooping immediate-leave processing and the query count are configured, immediate-leave processing takes precedence.



Note Do not set the count to 1 because the loss of a single packet (the query packet from the device to the host or the report packet from the host to the device) may result in traffic forwarding being stopped even if there is still a receiver. Traffic continues to be forwarded after the next general query is sent by the device, but the interval during which a receiver may not receive the query could be as long as 1 minute (with the default query interval).

The leave latency in Cisco IOS software may increase by up to one last-member-query-interval (LMQI) value when the device is processing more than one leave within an LMQI. In this case, the average leave latency is determined by the $(count + 0.5) * LMQI$. The result is that the default leave latency can range from 2.0 to 3.0 seconds with an average of 2.5 seconds under a higher load of IGMP leave processing. The leave latency under load for the minimum LMQI value of 100 milliseconds and a count of 1 is from 100 to 200 milliseconds, with an average of 150 milliseconds. This is done to limit the impact of higher rates of IGMP leave messages.

The following example sets the last member query count to 5:

```
Device(config)# ip igmp snooping last-member-query-count 5
```

ip igmp snooping querier

To globally enable the Internet Group Management Protocol (IGMP) querier function in Layer 2 networks, use the **ip igmp snooping querier** global configuration command. Use the command with keywords to enable and configure the IGMP querier feature on a VLAN interface. To return to the default settings, use the **no** form of this command.

```
ip igmp snooping [vlan vlan-id] querier [address ip-address | max-response-time response-time
| query-interval interval-count | tcn query {count count | interval interval} | timer expiry
expiry-time | version version]
no ip igmp snooping [vlan vlan-id] querier [address | max-response-time | query-interval |
tcn query {count | interval} | timer expiry | version]
```

Syntax Description		
vlan <i>vlan-id</i>	(Optional) Enables IGMP snooping and the IGMP querier function on the specified VLAN. The range is 1 to 1001 and 1006 to 4094.	
address <i>ip-address</i>	(Optional) Specifies a source IP address. If you do not specify an IP address, the querier tries to use the global IP address configured for the IGMP querier.	
max-response-time <i>response-time</i>	(Optional) Sets the maximum time to wait for an IGMP querier report. The range is 1 to 25 seconds.	
query-interval <i>interval-count</i>	(Optional) Sets the interval between IGMP queriers. The range is 1 to 18000 seconds.	
tcn query	(Optional) Sets parameters related to Topology Change Notifications (TCNs).	
count <i>count</i>	Sets the number of TCN queries to be executed during the TCN interval time. The range is 1 to 10.	
interval <i>interval</i>	Sets the TCN query interval time. The range is 1 to 255.	
timer expiry <i>expiry-time</i>	(Optional) Sets the length of time until the IGMP querier expires. The range is 60 to 300 seconds.	
version <i>version</i>	(Optional) Selects the IGMP version number that the querier feature uses. Select 1 or 2.	

Command Default The IGMP snooping querier feature is globally disabled on the device. When enabled, the IGMP snooping querier disables itself if it detects IGMP traffic from a multicast router.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use this command to enable IGMP snooping to detect the IGMP version and IP address of a device that sends IGMP query messages, which is also called a querier.

By default, the IGMP snooping querier is configured to detect devices that use IGMP Version 2 (IGMPv2) but does not detect clients that are using IGMP Version 1 (IGMPv1). You can manually configure the max-response-time value when devices use IGMPv2. You cannot configure the max-response-time when devices use IGMPv1. (The value cannot be configured and is set to zero).

Non-RFC compliant devices running IGMPv1 might reject IGMP general query messages that have a non-zero value as the max-response-time value. If you want the devices to accept the IGMP general query messages, configure the IGMP snooping querier to run IGMPv1.

VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping.

Examples

This example shows how to globally enable the IGMP snooping querier feature:

```
Device(config)# ip igmp snooping querier
```

This example shows how to set the IGMP snooping querier maximum response time to 25 seconds:

```
Device(config)# ip igmp snooping querier max-response-time 25
```

This example shows how to set the IGMP snooping querier interval time to 60 seconds:

```
Device(config)# ip igmp snooping querier query-interval 60
```

This example shows how to set the IGMP snooping querier TCN query count to 25:

```
Device(config)# ip igmp snooping querier tcn count 25
```

This example shows how to set the IGMP snooping querier timeout to 60 seconds:

```
Device(config)# ip igmp snooping querier timer expiry 60
```

This example shows how to set the IGMP snooping querier feature to version 2:

```
Device(config)# ip igmp snooping querier version 2
```

You can verify your settings by entering the **show ip igmp snooping** privileged EXEC command.

ip igmp snooping report-suppression

To enable Internet Group Management Protocol (IGMP) report suppression, use the **ip igmp snooping report-suppression** global configuration command on the device stack or on a standalone device. To disable IGMP report suppression and to forward all IGMP reports to multicast routers, use the **no** form of this command.

ip igmp snooping report-suppression
no ip igmp snooping report-suppression

Syntax Description This command has no arguments or keywords.

Command Default IGMP report suppression is enabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines IGMP report suppression is supported only when the multicast query has IGMPv1 and IGMPv2 reports. This feature is not supported when the query includes IGMPv3 reports.

The device uses IGMP report suppression to forward only one IGMP report per multicast router query to multicast devices. When IGMP report suppression is enabled (the default), the device sends the first IGMP report from all hosts for a group to all the multicast routers. The device does not send the remaining IGMP reports for the group to the multicast routers. This feature prevents duplicate reports from being sent to the multicast devices.

If the multicast router query includes requests only for IGMPv1 and IGMPv2 reports, the device forwards only the first IGMPv1 or IGMPv2 report from all hosts for a group to all of the multicast routers. If the multicast router query also includes requests for IGMPv3 reports, the device forwards all IGMPv1, IGMPv2, and IGMPv3 reports for a group to the multicast devices.

If you disable IGMP report suppression by entering the **no ip igmp snooping report-suppression** command, all IGMP reports are forwarded to all of the multicast routers.

Example

This example shows how to disable report suppression:

```
Device(config)# no ip igmp snooping report-suppression
```

You can verify your settings by entering the **show ip igmp snooping** privileged EXEC command.

ip igmp snooping vlan mrouter

To add a multicast router port, use the **ip igmp snooping mrouter** global configuration command on the device stack or on a standalone device. To return to the default settings, use the **no** form of this command.

Command Default By default, there are no multicast router ports.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping. The configuration is saved in NVRAM.

Examples

This example shows how to configure a port as a multicast router port:

```
Device(config)# ip igmp snooping vlan 1 mrouter interface gigabitethernet1/0/2
```

You can verify your settings by entering the **show ip igmp snooping** privileged EXEC command.

ip igmp snooping vlan static

To enable Internet Group Management Protocol (IGMP) snooping and to statically add a Layer 2 port as a member of a multicast group, use the **ip igmp snooping vlan static** global configuration command on the device stack or on a standalone device. Use the **no** form of this command to remove ports specified as members of a static multicast group.

ip igmp snooping vlan *vlan-id* **static** *ip-address* **interface** *interface-id*
no ip igmp snooping vlan *vlan-id* **static** *ip-address* **interface** *interface-id*

Syntax Description		
<i>vlan-id</i>	Enables IGMP snooping on the specified VLAN. The range is 1 to 1001 and 1006 to 4094.	
<i>ip-address</i>	Adds a Layer 2 port as a member of a multicast group with the specified group IP address.	
interface <i>interface-id</i>	Specifies the interface of the member port. The <i>interface-id</i> value has these options: <ul style="list-style-type: none"> • <i>fastethernet interface number</i>—A Fast Ethernet IEEE 802.3 interface. • <i>gigabitethernet interface number</i>—A Gigabit Ethernet IEEE 802.3z interface. • <i>tengigabitethernet interface number</i>—A 10-Gigabit Ethernet IEEE 802.3z interface. • <i>port-channel interface number</i>—A channel interface. The range is 0 to 128. 	

Command Default By default, there are no ports statically configured as members of a multicast group.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping. The configuration is saved in NVRAM.

Example

This example shows how to statically configure a host on an interface:

```
Device(config)# ip igmp snooping vlan 1 static 224.2.4.12 interface
gigabitEthernet1/0/1
Configuring port gigabitEthernet1/0/1 on group 224.2.4.12
```

You can verify your settings by entering the **show ip igmp snooping** privileged EXEC command.

ip multicast auto-enable

To support authentication, authorization, and accounting (AAA) enabling of IP multicast, use the **ip multicast auto-enable** command. This command allows multicast routing to be enabled dynamically on dialup interfaces using AAA attributes from a RADIUS server. To disable IP multicast for AAA, use the **no** form of the command.

ip multicast auto-enable
no ip multicast auto-enable

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	None This command is unavailable when using the LAN Base image.
-------------------------	--

Example

This example shows how to enable authentication, authorization, and accounting (AAA) on IP multicast:

```
Device(config)# ip multicast auto-enable
```

ip multicast vlan

To configure IP multicast on a single VLAN, use the **ip multicast vlan** command in global configuration mode. To remove the VLAN from the WLAN, use the **no** form of the command.

```
ip multicast vlan {vlan-name vlan-id}
no ip multicast vlan {vlan-name vlan-id}
```

Syntax Description

vlan-name Specifies the VLAN name.

vlan-id Specifies the VLAN ID.

Command Default

Disabled.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

None

This example configures `vlan_id01` as a multicast VLAN.

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wireless multicast
Device(config)# wlan test-wlan 1
Device(config-wlan)# ip multicast vlan vlan_id01
```

ip pim accept-register

To configure a candidate rendezvous point (RP) switch to filter Protocol Independent Multicast (PIM) register messages, use the **ip pim accept-register** command in global configuration mode. To disable this function, use the **no** form of this command.

```
ip pim [vrf vrf-name ] accept-register {list access-list}
no ip pim [vrf vrf-name ] accept-register
```

Syntax Description	<p>vrf <i>vrf-name</i> (Optional) Configures a PIM register filter on candidate RPs for (S, G) traffic associated with the multicast Virtual Private Network (VPN) routing and forwarding (MVRP) instance specified for the <i>vrf-name</i> argument.</p> <p>list <i>access-list</i> Specifies the <i>access-list</i> argument as a number or name that defines the (S, G) traffic in PIM register messages to be permitted or denied. The range is 100 to 199 and an expanded range of 2000 to 2699. An IP-named access list can also be used.</p>				
Command Default	No PIM register filters are configured.				
Command Modes	Global configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.				

Usage Guidelines

Use this command to prevent unauthorized sources from registering with the RP. If an unauthorized source sends a register message to the RP, the RP will immediately send back a register-stop message.

The access list provided for the **ip pim accept-register** command should only filter on IP source addresses and IP destination addresses. Filtering on other fields (for example, IP protocol or UDP port number) will not be effective and may cause undesired traffic to be forwarded from the RP down the shared tree to multicast group members. If more complex filtering is desired, use the **ip multicast boundary** command instead.

Example

The following example shows how to permit register packets for any source address sending to any group range, with the exception of source address 172.16.10.1 sending to the SSM group range (232.0.0.0/8). These are denied. These statements should be configured on all candidate RPs because candidate RPs will receive PIM registers from first hop routers or switches.

```
Device(config)# ip pim accept-register list ssm-range
Device(config)# ip access-list extended ssm-range
Device(config-ext-nacl)# deny ip any 232.0.0.0 0.255.255.255
Device(config-ext-nacl)# permit ip any any
```

ip pim bsr-candidate

To configure the switch to be a candidate BSR, use the **ip pim bsr-candidate** command in global configuration mode. To remove the switch as a candidate BSR, use the **no** form of this command.

```
ip pim [vrf vrf-name] bsr-candidate interface-id [hash-mask-length] [priority]  
no ip pim [vrf vrf-name] bsr-candidate
```

Syntax Description		
<i>vrf vrf-name</i>	(Optional) Configures the switch to be a candidate BSR for the Multicast Virtual Private Network (MVPN) routing and forwarding (MVRF) instance specified for the <i>vrf-name</i> argument.	
<i>interface-id</i>	ID of the interface on this switch from which the BSR address is derived to make it a candidate. This interface must be enabled for Protocol Independent Multicast (PIM) using the ip pim command. Valid interfaces include physical ports, port channels, and VLANs.	
<i>hash-mask-length</i>	(Optional) Length of a mask (32 bits maximum) that is to be ANDed with the group address before the PIMv2 hash function is called. All groups with the same seed hash correspond to the same rendezvous point (RP). For example, if this value is 24, only the first 24 bits of the group addresses matter. The hash mask length allows one RP to be used for multiple groups. The default hash mask length is 0.	
<i>priority</i>	(Optional) Priority of the candidate BSR (C-BSR). The range is from 0 to 255. The default priority is 0. The C-BSR with the highest priority value is preferred.	

Command Default The switch is not configured to announce itself as a candidate BSR.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines The interface specified for this command must be enabled for Protocol Independent Multicast (PIM) using the **ip pim** command.

This command configures the switch to send BSR messages to all of its PIM neighbors, with the address of the designated interface as the BSR address.

This command should be configured on backbone switches that have good connectivity to all parts of the PIM domain.

The BSR mechanism is specified in RFC 2362. Candidate RP (C-RP) switches unicast C-RP advertisement packets to the BSR. The BSR then aggregates these advertisements in BSR messages, which it regularly multicasts with a TTL of 1 to the ALL-PIM-ROUTERS group address, 224.0.0.13. The multicasting of these messages is handled by hop-by-hop RPF flooding; so no preexisting IP multicast routing setup is required (unlike with AutoRP). In addition, the BSR does not preselect the designated RP for a particular group range (unlike AutoRP); instead, each switch that receives BSR messages will elect RPs for group ranges based on the information in the BSR messages.

Cisco switches always accept and process BSR messages. There is no command to disable this function.

Cisco switches perform the following steps to determine which C-RP is used for a group:

- A longest match lookup is performed on the group prefix that is announced by the BSR C-RPs.
- If more than one BSR-learned C-RP are found by the longest match lookup, the C-RP with the lowest priority (configured with the **ip pim rp-candidate** command) is preferred.
- If more than one BSR-learned C-RP have the same priority, the BSR hash function is used to select the RP for a group.
- If more than one BSR-learned C-RP return the same hash value derived from the BSR hash function, the BSR C-RP with the highest IP address is preferred.

Example

The following example shows how to configure the IP address of the switch on Gigabit Ethernet interface 1/0/0 to be a BSR C-RP with a hash mask length of 0 and a priority of 192:

```
Device(config)# ip pim bsr-candidate GigabitEthernet1/0/1 0 192
```

ip pim rp-candidate

To configure the switch to advertise itself to the BSR as a Protocol Independent Multicast (PIM) Version 2 (PIMv2) candidate rendezvous point (C-RP), use the **ip pim rp-candidate** command in global configuration mode. To remove this switch as a C-RP, use the **no** form of this command.

```
ip pim [vrf vrf-name] rp-candidate interface-id [group-list access-list-number]
no ip pim [vrf vrf-name] rp-candidate interface-id [group-list access-list-number]
```

Syntax Description		
vrf <i>vrf-name</i>	(Optional) Configures the switch to advertise itself to the BSR as PIMv2 C-RP for the Multicast Virtual Private Network (MVPN) routing and forwarding (MVRP) instance specified for the <i>vrf-name</i> argument.	
<i>interface-id</i>	ID of the interface whose associated IP address is advertised as a candidate RP address. Valid interfaces include physical ports, port channels, and VLANs.	
group-list <i>access-list-number</i>	(Optional) Specifies the standard IP access list number that defines the group prefixes that are advertised in association with the RP address.	

Command Default The switch is not configured to announce itself to the BSR as a PIMv2 C-RP.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use this command to configure the switch to send PIMv2 messages so that it advertises itself as a candidate RP to the BSR.

This command should be configured on backbone switches that have good connectivity to all parts of the PIM domain.

The IP address associated with the interface specified by *interface-id* will be advertised as the C-RP address.

The interface specified for this command must be enabled for Protocol Independent Multicast (PIM) using the **ip pim** command.

If the optional **group-list** keyword and *access-list-number* argument are configured, the group prefixes defined by the standard IP access list will also be advertised in association with the RP address.

Example

The following example shows how to configure the switch to advertise itself as a C-RP to the BSR in its PIM domain. The standard access list number 4 specifies the group prefix associated with the RP that has the address identified by Gigabit Ethernet interface 1/0/1.

```
Device(config)# ip pim rp-candidate GigabitEthernet1/0/1 group-list 4
```

ip pim send-rp-announce

To use Auto-RP to configure groups for which the switch will act as a rendezvous point (RP), use the **ip pim send-rp-announce** command in global configuration mode. To unconfigure this switch as an RP, use the **no** form of this command.

ip pim [*vrf vrf-name*] **send-rp-announce** *interface-id* **scope** *ttl-value* [**group-list** *access-list-number*]
[**interval** *seconds*]

no ip pim [*vrf vrf-name*] **send-rp-announce** *interface-id*

Syntax Description

vrf <i>vrf-name</i>	(Optional) Uses Auto-RP to configure groups for which the switch will act as a rendezvous point (RP) for the <i>vrf-name</i> argument.
<i>interface-id</i>	Enter the interface ID of the interface that identifies the RP address. Valid interfaces include physical ports, port channels, and VLANs.
scope <i>ttl-value</i>	Specifies the time-to-live (TTL) value in hops that limits the number of Auto-RP announcements. Enter a hop count that is high enough so that the RP-announce messages reach all mapping agents in the network. There is no default setting. The range is 1 to 255.
group-list <i>access-list-number</i>	(Optional) Specifies the standard IP access list number that defines the group prefixes that are advertised in association with the RP address. Enter an IP standard access list number from 1 to 99. If no access list is configured, the RP is used for all groups.
interval <i>seconds</i>	(Optional) Specifies the interval between RP announcements in seconds. The total holdtime of the RP announcements is automatically set to three times the value of the interval. The default interval is 60 seconds. The range is 1 to 16383.

Command Default

Auto-RP is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Enter this command on the switch that you want to be an RP. When you are using Auto-RP to distribute group-to-RP mappings, this command causes the router to send an Auto-RP announcement message to the well-known group CISCO-RP-ANNOUNCE (224.0.1.39). This message announces the router as a candidate RP for the groups in the range described by the access list.

Examples

The following example shows how to configure the switch to send RP announcements out all Protocol Independent Multicast (PIM)-enabled interfaces for a maximum of 31 hops. The IP address by which the switch wants to be identified as RP is the IP address associated with Gigabit Ethernet interface 1/0/1 at an interval of 120 seconds:

```
Device(config)# ip pim send-rp-announce GigabitEthernet1/0/1 scope 31 group-list 5 interval  
120
```

ip pim spt-threshold

To specify the threshold that must be reached before moving to shortest-path tree (spt), use the **ip pim spt-threshold** command in global configuration mode. To remove the threshold, use the **no** form of this command.

```
ip pim {kpbs | infinity} [group-list access-list]
no ip pim {kpbs | infinity} [group-list access-list]
```

Syntax Description	<i>kpbs</i>	The threshold that must be reached before moving to shortest-path tree (spt). 0 is the only valid entry even though the range is 0 to 4294967. A 0 entry always switches to the source-tree.
	infinity	Specifies that all sources for the specified group use the shared tree, never switching to the source tree.
	group-list <i>access-list</i>	(Optional) Specifies an access list number or a specific access list that you have created by name. If the value is 0 or if the group-list <i>access-list</i> option is not used, the threshold applies to all groups.
Command Default	Switches to the PIM shortest-path tree (spt).	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	None	

Example

The following example makes all sources for access list 16 use the shared tree:

```
Device(config)# ip pim spt-threshold infinity group-list 16
```

match message-type

To set the message type to match for a service list, use the **match message-type** command.

```
match message-type {announcement | any | query}
```

Syntax Description	
announcement	Allows only service advertisements or announcements for the device.
any	Allows any match type.
query	Allows only a query from the client for a certain device in the network.

Command Default None

Command Modes Service list configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Multiple service maps of the same name with different sequence numbers can be created and the evaluation of the filters will be ordered on the sequence number. Service lists are an ordered sequence of individual statements, each one has a permit or deny result. Evaluation of service list consists of a list scan, in a predetermined order, and an evaluation of the criteria of each statement that matches. A list scan is stopped once the first statement match is found and an action permit/deny associated with the statement match is performed. The default action after scanning through the entire list is to deny.



Note It is not possible to use the **match** command if you have used the **service-list mdns-sd service-list-name query** command. The **match** command can be used only for the **permit** or **deny** option.

This example shows how to set the announcement message type to be matched:

```
Device(config-mdns-sd-sl) # match message-type announcement
```

match service-type

To set the value of the mDNS service type string to match, use the **match service-type** command.

match service-type *line*

Syntax Description	<i>line</i> Regular expression to match service type in packets.				
Command Default	None				
Command Modes	Service list configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				
Usage Guidelines	<p>It is not possible to use the match command if you have used the service-list mdns-sd <i>service-list-name</i> query command. The match command can be used only for the permit or deny option.</p> <p>This example shows how to set the value of the mDNS service type string to match:</p> <pre>Device(config-mdns-sd-sl)# match service-type _ipp._tcp</pre>				

match service-instance

To set the service instance to match for a service list, use the **match service-instance** command.

match service-instance *line*

Syntax Description	<i>line</i> Regular expression to match service instance in packets.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Service list configuration
----------------------	----------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	It is not possible to use the match command if you have used the service-list mdns-sd service-list-name query command. The match command can be used only for the permit or deny option.
-------------------------	---

This example shows how to set the service instance to match:

```
Device(config-mdns-sd-sl) # match service-instance servInst 1
```

mrinfo

To query which neighboring multicast routers or multilayer switches are acting as peers, use the **mrinfo** command in user EXEC or privileged EXEC mode.

```
mrinfo [vrf route-name] [hostname | address] [interface-id]
```

Syntax Description	vrf route-name	(Optional) Specifies the VPN routing or forwarding instance.
	hostname address	(Optional) The Domain Name System (DNS) name or IP address of the multicast router or multilayer switch to query. If omitted, the switch queries itself.
	interface-id	(Optional) Specifies the interface ID.
Command Default	The command is disabled.	
Command Modes	User EXEC	
	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Usage Guidelines	<p>The mrinfo command is the original tool of the multicast backbone (MBONE) to determine which neighboring multicast routers or switches are peering with multicast routers or switches. Cisco routers have supported responding to mrinfo requests since Cisco IOS Release 10.2.</p> <p>You can query a multicast router or multilayer switch using the mrinfo command. The output format is identical to the multicast routed version of the Distance Vector Multicast Routing Protocol (DVMRP). (The mrouterd software is the UNIX software that implements DVMRP.)</p>	

Example

The following is sample output from the **mrinfo** command:

```
Device# mrinfo
vrf 192.0.1.0
192.31.7.37 (barnet-gw.cisco.com) [version cisco 11.1] [flags: PMSA]:
  192.31.7.37 -> 192.31.7.34 (sj-wall-2.cisco.com) [1/0/pim]
  192.31.7.37 -> 192.31.7.47 (dirtylab-gw-2.cisco.com) [1/0/pim]
  192.31.7.37 -> 192.31.7.44 (dirtylab-gw-1.cisco.com) [1/0/pim]
```



Note The flags indicate the following:

- P: prune-capable
 - M: mtrace-capable
 - S: Simple Network Management Protocol (SNMP)-capable
 - A: Auto-Rendezvous Point (RP)-capable
-

redistribute mdns-sd

To redistribute services or service announcements across subnets, use the **redistribute mdns-sd** command. To disable redistribution of services or service announcements across subnets, use the **no** form of this command.

redistribute mdns-sd
no redistribute mdns-sd

This command has no arguments or keywords.

Command Default The redistribution of services or service announcements across subnets is disabled.

Command Modes mDNS configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines To redistribute service announcements across interfaces, use the **redistribute mdns-sd** command. This command sends out unsolicited announcements received on one interface to all of the other interfaces. The outgoing announcements are filtered as per the out-service policy defined for the interface or in absence of a per-interface service policy based on the global out-service policy.

In the absence of a redistribute option, services can be discovered by querying in a Layer 3 domain that is not local to the service provider.

Example

This example shows how to redistribute services or service announcements across subnets:

```
Device(config-mdns)# redistribute mdns-sd
```



Note If redistribution is enabled globally, global configuration is given higher priority than interface configuration.

service-list mdns-sd

To enter mDNS service discovery service-list mode on the device, use the **service-list mdns-sd** command. To exit mDNS service discovery service-list mode, use the **no** form of the command.

```
service-list mdns-sd service-list-name {permit | deny} sequence-number [query]
no service-list mdns-sd service-list-name {permit | deny} sequence-number [query]
```

Syntax Description		
	<i>service-list-name</i>	Name of the service list.
	permit <i>sequence number</i>	Permits a filter on the service list to be applied to the sequence number.
	deny <i>sequence number</i>	Denies a filter on the service list to be applied to the sequence number.
	query	Associates a query for the service list name.

Command Default Disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Service filters are modeled around access lists and route maps.

Multiple service maps of the same name with different sequence numbers can be created and the evaluation of the filters will be ordered on the sequence number. Service lists are an ordered sequence of individual statements, each has a permit or deny result. Evaluation of a service list consists of a list scan, in a predetermined order, and an evaluation of the criteria of each statement that matches. A list scan is aborted once the first statement match is found and an action, permit or deny associated with the statement match is performed. Default action after scanning through the entire list will be to deny.

This command can be used to enter mDNS service discovery service-list mode.

In this mode you can:

- Create a service list and apply a filter on the service list according to the **permit** or **deny** option applied to the sequence number.

Example

This example shows how to create a service list and apply a filter on the service list according to the **permit** or **deny** option applied to the sequence number:

```
Device(config)# service-list mdns-sd s11 permit 3
```

service-policy-query

To configure service list query periodicity, use the **service-policy-query** command. To delete the configuration, use the **no** form of this command.

service-policy-query [*service-list-query-name service-list-query-periodicity*]
no service-policy-query

Syntax Description	<i>service-list-query-name service-list-query-periodicity</i> (Optional) Configures the service list query periodicity.
---------------------------	---

Command Default	Disabled.
------------------------	-----------

Command Modes	mDNS configuration
----------------------	--------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	As there are devices that do not send unsolicited announcements and to force learning of services and to keep them refreshed in the cache, this command contains an active query feature which ensures that services listed in the active query list will be queried.
-------------------------	---

Example

This example shows how to configure service list query periodicity:

```
Device(config-mdns) # service-policy-query sl-query1 100
```

service-routing mdns-sd

To enable mDNS gateway functionality for a device and enter multicast DNS configuration mode, use the **service-routing mdns-sd** command. To restore default settings and return to global config mode, enter the **no** form of the command.

service-routing mdns-sd
no service-routing mdns-sd

This command has no arguments or keywords.

Command Default

Disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

mDNS gateway functionality can only be enabled or disabled globally, not on a per-interface basis. The service filter policy and redistribution can be configured globally as well as on a per-interface basis. Any interface specific configuration overrides the global configuration.

Example

This example shows how to enable mDNS gateway functionality for a device and enter multicast DNS configuration mode:

```
Device(config)# service-routing mdns-sd
```

service-policy

To apply a filter on incoming or outgoing service discovery information on a service list, use the **service-policy** command. To remove the filter, use the **no** form of the command.

```
service-policy service-policy-name {IN | OUT}
no service-policy service-policy-name {IN | OUT}
```

Syntax Description	
	<i>service-policy-name</i> IN Applies a filter on incoming service discovery information.
	<i>service-policy-name</i> OUT Applies a filter on outgoing service discovery information.

Command Default Disabled.

Command Modes mDNS configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The Device intercepts mDNS packets. If they are mDNS messages destined to a wireless client (for example, the destination MAC is client's MAC address), and the client's mobility state is either local or foreign, the destination MAC address is overwritten with the client's MAC address and enqueues the packet to be sent out on the associated CAPWAP tunnel.

Example

This example applies a filter on incoming service discovery information on a service list:

```
Device(config-mdns)# service-policy serv-poll IN
```

show ip igmp filter

To display Internet Group Management Protocol (IGMP) filter information, use the **show ip igmp filter** command in privileged EXEC command mode.

```
show ip igmp [vrf vrf-name] filter
```

Syntax Description	vrf <i>vrf-name</i> (Optional) Supports the multicast VPN routing and forwarding (VRF) instance.
---------------------------	---

Command Default	IGMP filters are enabled by default.
------------------------	--------------------------------------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines	The show ip igmp filter command displays information about all filters defined on the device.
-------------------------	--

Example

The following is sample output from the **show ip igmp filter** command:

```
Device# show ip igmp filter
IGMP filter enabled
```

show ip igmp profile

To display all configured Internet Group Management Protocol (IGMP) profiles or a specified IGMP profile, use the **show ip igmp profile** privileged EXEC command.

```
show ip igmp [vrf vrf-name] profile [profile number]
```

Syntax Description	vrf vrf-name (Optional) Supports the multicast VPN routing and forwarding (VRF) instance.				
	profile number (Optional) The IGMP profile number to be displayed. The range is 1 to 4294967295. If no profile number is entered, all IGMP profiles are displayed.				
Command Default	IGMP profiles undefined by default.				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.				
Usage Guidelines	None				

Examples

The following example shows the output of the **show ip igmp profile** privileged EXEC command for profile number 40 on the device:

```
Device# show ip igmp profile 40
IGMP Profile 40
  permit
  range 233.1.1.1 233.255.255.255
```

This example shows the output of the **show ip igmp profile** privileged EXEC command for all profiles configured on the device:

```
Device# show ip igmp profile

IGMP Profile 3
  range 230.9.9.0 230.9.9.0
IGMP Profile 4
  permit
  range 229.9.9.0 229.255.255.255
```

show ip igmp snooping

To display the Internet Group Management Protocol (IGMP) snooping configuration of the device or the VLAN, use the **show ip igmp snooping** command in user or privileged EXEC command mode.

```
show ip igmp snooping [groups | mrouter | querier] [vlan vlan-id] [detail]
```

Syntax Description	groups	(Optional) Displays the IGMP snooping multicast table.
	mrouter	(Optional) Displays the IGMP snooping multicast router ports.
	querier	(Optional) Displays the configuration and operation information for the IGMP querier.
	vlan <i>vlan-id</i>	(Optional) Specifies a VLAN; the range is 1 to 1001 and 1006 to 4094.
	detail	(Optional) Displays operational state information.
Command Default	None	
Command Modes	User EXEC Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Usage Guidelines	<p>VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping.</p> <p>Expressions are case sensitive. For example, if you enter exclude output, the lines that contain output do not appear, but the lines that contain Output appear.</p>	

Examples

This is an example of output from the **show ip igmp snooping vlan 1** command. It shows snooping characteristics for a specific VLAN:

```
Device# show ip igmp snooping vlan 1

Global IGMP Snooping configuration:
-----
IGMP snooping                : Enabled
IGMPv3 snooping (minimal)    : Enabled
Report suppression           : Enabled
TCN solicit query            : Disabled
TCN flood query count        : 2
Robustness variable          : 2
Last member query count      : 2
Last member query interval   : 1000

Vlan 1:
-----
IGMP snooping                : Enabled
```

```

IGMPv2 immediate leave      : Disabled
Multicast router learning mode : pim-dvmrp
CGMP interoperability mode   : IGMP_ONLY
Robustness variable         : 2
Last member query count      : 2
Last member query interval   : 1000

```

This is an example of output from the **show ip igmp snooping** command. It displays snooping characteristics for all VLANs on the device:

```

Device# show ip igmp snooping
Global IGMP Snooping configuration:
-----
IGMP snooping                : Enabled
IGMPv3 snooping (minimal)    : Enabled
Report suppression           : Enabled
TCN solicit query            : Disabled
TCN flood query count        : 2
Robustness variable          : 2
Last member query count      : 2
Last member query interval   : 1000

Vlan 1:
-----
IGMP snooping                : Enabled
IGMPv2 immediate leave       : Disabled
Multicast router learning mode : pim-dvmrp
CGMP interoperability mode    : IGMP_ONLY
Robustness variable          : 2
Last member query count      : 2
Last member query interval   : 1000

Vlan 2:
-----
IGMP snooping                : Enabled
IGMPv2 immediate leave       : Disabled
Multicast router learning mode : pim-dvmrp
CGMP interoperability mode    : IGMP_ONLY
Robustness variable          : 2
Last member query count      : 2
Last member query interval   : 1000
<output truncated>

```

show ip igmp snooping groups

To display the Internet Group Management Protocol (IGMP) snooping multicast table for the device or the multicast information, use the **show ip igmp snooping groups** privileged EXEC command.

```
show ip igmp snooping groups [vlan vlan-id ] [[count] | ip_address]
```

Syntax Description	vlan <i>vlan-id</i> (Optional) Specifies a VLAN; the range is 1 to 1001 and 1006 to 4094. Use this option to display the multicast table for a specified multicast VLAN or specific multicast information.				
Command Modes	Privileged EXEC User EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE/Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE/Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE/Cisco IOS XE 3.3SE	This command was introduced.				
Usage Guidelines	Expressions are case sensitive. For example, if you enter exclude output, the lines that contain output do not appear, but the lines that contain Output appear.				

Examples

This is an example of output from the **show ip igmp snooping groups** command without any keywords. It displays the multicast table for the device:

```
Device# show ip igmp snooping groups
Vlan      Group          Type          Version      Port List
-----
1         224.1.4.4      igmp
1         224.1.4.5      igmp
2         224.0.1.40     igmp          v2           Gi1/0/15
104      224.1.4.2      igmp          v2           Gi2/0/1, Gi2/0/2
104      224.1.4.3      igmp          v2           Gi2/0/1, Gi2/0/2
```

This is an example of output from the **show ip igmp snooping groups count** command. It displays the total number of multicast groups on the device:

```
Device# show ip igmp snooping groups count
Total number of multicast groups: 2
```

This is an example of output from the **show ip igmp snooping groups vlan *vlan-id* *ip-address*** command. It shows the entries for the group with the specified IP address:

```
Device# show ip igmp snooping groups vlan 104 224.1.4.2
Vlan      Group          Type          Version      Port List
-----
104      224.1.4.2      igmp          v2           Gi2/0/1, Gi1/0/15
```

show ip igmp snooping igmpv2-tracking

To display group and IP address entries, use the **show ip igmp snooping igmpv2-tracking** command in privileged EXEC mode.



Note The command displays group and IP address entries only for wireless multicast IGMP joins and not for wired joins. This command also displays output only if wireless multicast is enabled.

show ip igmp snooping igmpv2-tracking

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

show ip igmp snooping mrouter

To display the Internet Group Management Protocol (IGMP) snooping dynamically learned and manually configured multicast router ports for the device or for the specified multicast VLAN, use the **show ip igmp snooping mrouter** privileged EXEC command.

```
show ip igmp snooping mrouter [vlan vlan-id]
```

Syntax Description	vlan <i>vlan-id</i> (Optional) Specifies a VLAN; the range is 1 to 1001 and 1006 to 4094.	
Command Modes	User EXEC Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	<p>VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping. When multicast VLAN registration (MVR) is enabled, the show ip igmp snooping mrouter command displays MVR multicast router information and IGMP snooping information.</p> <p>Expressions are case sensitive. For example, if you enter exclude output, the lines that contain output do not appear, but the lines that contain Output appear.</p>	

Example

This is an example of output from the **show ip igmp snooping mrouter** command. It shows how to display multicast router ports on the device:

```
Device# show ip igmp snooping mrouter
Vlan      ports
----      -
1         Gi2/0/1 (dynamic)
```

show ip igmp snooping querier

To display the configuration and operation information for the IGMP querier configured on a device, use the **show ip igmp snooping querier** user EXEC command.

```
show ip igmp snooping querier [vlan vlan-id] [detail ]
```

Syntax Description	
vlan <i>vlan-id</i>	(Optional) Specifies a VLAN; the range is 1 to 1001 and 1006 to 4094.
detail	(Optional) Displays detailed IGMP querier information.

Command Modes	
	User EXEC
	Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use the **show ip igmp snooping querier** command to display the IGMP version and the IP address of a detected device, also called a querier, that sends IGMP query messages. A subnet can have multiple multicast routers but has only one IGMP querier. In a subnet running IGMPv2, one of the multicast routers is elected as the querier. The querier can be a Layer 3 device.

The **show ip igmp snooping querier** command output also shows the VLAN and the interface on which the querier was detected. If the querier is the device, the output shows the Port field as Router. If the querier is a router, the output shows the port number on which the querier is learned in the Port field.

The **show ip igmp snooping querier detail** user EXEC command is similar to the **show ip igmp snooping querier** command. However, the **show ip igmp snooping querier** command displays only the device IP address most recently detected by the device querier.

The **show ip igmp snooping querier detail** command displays the device IP address most recently detected by the device querier and this additional information:

- The elected IGMP querier in the VLAN
- The configuration and operational information pertaining to the device querier (if any) that is configured in the VLAN

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain output do not appear, but the lines that contain Output appear.

Examples

This is an example of output from the **show ip igmp snooping querier** command:

```
Device> show ip igmp snooping querier
Vlan      IP Address      IGMP Version      Port
-----
1         172.20.50.11    v3                 Gi1/0/1
2         172.20.40.20    v2                 Router
```

This is an example of output from the **show ip igmp snooping querier detail** command:

```
Device> show ip igmp snooping querier detail
Vlan      IP Address      IGMP Version  Port
-----
1         1.1.1.1         v2            Fa8/0/1
Global IGMP device querier status
-----
admin state           : Enabled
admin version         : 2
source IP address     : 0.0.0.0
query-interval (sec) : 60
max-response-time (sec) : 10
querier-timeout (sec) : 120
tcn query count      : 2
tcn query interval (sec) : 10
Vlan 1:  IGMP device querier status
-----
elected querier is 1.1.1.1      on port Fa8/0/1
-----
admin state           : Enabled
admin version         : 2
source IP address     : 10.1.1.65
query-interval (sec) : 60
max-response-time (sec) : 10
querier-timeout (sec) : 120
tcn query count      : 2
tcn query interval (sec) : 10
operational state     : Non-Querier
operational version   : 2
tcn query pending count : 0
```

show ip igmp snooping wireless mcast-spi-count

To display the statistics of the number of multicast stateful packet inspections (SPIs) per multicast group ID (MGID) sent to the device, use the **show ip igmp snooping wireless mcast-spi-count** command in privileged EXEC mode.

show ip igmp snooping wireless mcast-spi-count

This command has no arguments or keywords.

Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	None	

Examples

This is an example of output from the **show ip igmp snooping wireless mcast-spi-count** command:

```
Device# show ip igmp snooping wireless mcast-spi-count

Stats for Mcast Client Add/Delete SPI Messages Sent to WCM

MGID      ADD MSGs      Del MSGs
-----
4160      1323          667
```

show ip igmp snooping wireless mgid

To display multicast group ID (MGID) mappings, use the **show ip igmp snooping wireless mgid** command in privileged EXEC mode.

show ip igmp snooping wireless mgid

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines None

Examples

This is an example of output from the **show ip igmp snooping wireless mgid** command:

```
Device# show ip igmp snooping wireless mgid

Total number of L2-MGIDs      = 0

Total number of MCAST MGIDs = 0

Wireless multicast is Enabled in the system
Vlan    bcast    nonip-mcast    mcast    mgid    Stdby Flags
1       Disabled  Disabled      Enabled   Disabled 0:0:1:0
25      Disabled  Disabled      Enabled   Disabled 0:0:1:0
34      Disabled  Disabled      Enabled   Disabled 0:0:1:0
200     Disabled  Disabled      Enabled   Disabled 0:0:1:0
1002    Enabled   Enabled       Enabled   Disabled 0:0:1:0
1003    Enabled   Enabled       Enabled   Disabled 0:0:1:0
1004    Enabled   Enabled       Enabled   Disabled 0:0:1:0
1005    Enabled   Enabled       Enabled   Disabled 0:0:1:0

Index  MGID                               (S, G, V)
-----
```

show ip pim autorp

To display global information about auto-rp, use the **show ip pim autorp** command in privileged EXEC mode.

show ip pim autorp

Syntax Description This command has no arguments or keywords.

Command Default auto-rp is enabled by default.

Command Modes Privileged EXEC mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines This command displays whether auto-rp is enabled or disabled.

Example

The following command output displays that auto-rp is enabled:

```
Device# show ip pim autorp

AutoRP Information:
  AutoRP is enabled.
  RP Discovery packet MTU is 0.
  224.0.1.40 is joined on GigabitEthernet1/0/1.

PIM AutoRP Statistics: Sent/Received
  RP Announce: 0/0, RP Discovery: 0/0
```

show ip pim bsr-router

To display information related to Protocol Independent Multicast (PIM) bootstrap router (BSR) protocol processing, use the **show ip pim bsr-router** command in user EXEC or privileged EXEC mode.

show ip pim bsr-router

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines In addition to auto-rp, the BSR RP method can be configured. After the BSR RP method is configured, this command will display the BSR router information.

The following is sample output from the **show ip pim bsr-router** command:

```
Device# show ip pim bsr-router

PIMv2 Bootstrap information
This system is the Bootstrap Router (BSR)
  BSR address: 172.16.143.28
  Uptime: 04:37:59, BSR Priority: 4, Hash mask length: 30
  Next bootstrap message in 00:00:03 seconds

Next Cand_RP_advertisement in 00:00:03 seconds.
  RP: 172.16.143.28(Ethernet0), Group acl: 6
```

show ip pim bsr

To display information related to Protocol Independent Multicast (PIM) bootstrap router (BSR) protocol processing, use the **show ip pim bsr** command in user EXEC or privileged EXEC mode.

show ip pim bsr

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines In addition to auto-rp, the BSR RP method can be configured. After the BSR RP method is configured, this command will display the BSR router information.

The following is sample output from the **show ip pim bsr** command:

```
Device# show ip pim bsr

PIMv2 Bootstrap information
This system is the Bootstrap Router (BSR)
  BSR address: 172.16.143.28
  Uptime: 04:37:59, BSR Priority: 4, Hash mask length: 30
  Next bootstrap message in 00:00:03 seconds

Next Cand_RP_advertisement in 00:00:03 seconds.
  RP: 172.16.143.28(Ethernet0), Group acl: 6
```

show ip pim tunnel

To display information about the Protocol Independent Multicast (PIM) register encapsulation and decapsulation tunnels on an interface, use the **show ip pim tunnel** command.

```
show ip pim [vrf vrf-name] tunnel [Tunnel interface-number | verbose]
```

Syntax Description	vrf <i>vrf-name</i> (Optional) Specifies a virtual routing and forwarding (VRF) configuration.						
	Tunnel <i>interface-number</i> (Optional) Specifies the tunnel interface number.						
	verbose (Optional) Provides additional information, such as the MAC encapsulation header and platform-specific information.						
Command Default	None						
Command Modes	Privileged EXEC						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE</td> </tr> <tr> <td></td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE		This command was introduced.
Release	Modification						
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE						
	This command was introduced.						

Usage Guidelines

Use the **show ip pim tunnel** to display information about PIM tunnel interfaces.

PIM tunnel interfaces are used by the IPv4 Multicast Forwarding Information Base (MFIB) for the PIM sparse mode (PIM-SM) registration process. Two types of PIM tunnel interfaces are used by the the IPv4 MFIB:

- A PIM encapsulation tunnel (PIM Encap Tunnel)
- A PIM decapsulation tunnel (PIM Decap Tunnel)

The PIM Encap Tunnel is dynamically created whenever a group-to-rendezvous point (RP) mapping is learned (through auto-RP, bootstrap router (BSR), or static RP configuration). The PIM Encap Tunnel is used to encapsulate multicast packets sent by first-hop designated routers (DRs) that have directly connected sources.

Similar to the PIM Encap Tunnel, the PIM Decap Tunnel interface is dynamically created—but it is created only on the RP whenever a group-to-RP mapping is learned. The PIM Decap Tunnel interface is used by the RP to decapsulate PIM register messages.



Note PIM tunnels will not appear in the running configuration.

The following syslog message appears when a PIM tunnel interface is created:

```
* %LINEPROTO-5-UPDOWN: Line protocol on Interface Tunnel<interface_number>,
changed state to up
```

The following is sample output from the **show ip pim tunnel** taken from an RP. The output is used to verify the PIM Encap and Decap Tunnel on the RP:

```
Device# show ip pim tunnel
```

```
Tunnel0
  Type   : PIM Encap
  RP     : 70.70.70.1*
  Source : 70.70.70.1
Tunnel1*
  Type   : PIM Decap
  RP     : 70.70.70.1*
  Source : -R2#
```



Note The asterisk (*) indicates that the router is the RP. The RP will always have a PIM Encap and Decap Tunnel interface.

show mdns cache

To display mDNS cache information for the device, use the **show mdns cache** privileged EXEC command.

```
show mdns cache [interface type-number | name record-name [type record-type] | type
record-type]
```

Syntax Description	<p>interface <i>type-number</i> (Optional) Specifies a particular interface type and number for which mDNS cache information is to be displayed.</p> <p>name <i>record-name</i> (Optional) Specifies a particular name for which mDNS cache information is to be displayed.</p> <p>type <i>record-type</i> (Optional) Specifies a particular type for which mDNS cache information is to be displayed.</p>				
Command Default	None				
Command Modes	Privileged EXEC User EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				
Usage Guidelines	Expressions are case sensitive. For example, if you enter exclude output, the lines that contain output do not appear, but the lines that contain output appear.				

Example

This is an example of output from the **show mdns cache** command without any keywords:

```
Device# show mdns cache
```

```

[<NAME>] [<TYPE>] [<CLASS>] [<TTL>/Remaining] [Accessed] [If-name] [Mac
Address] [<RR Record Data>]

_airplay._tcp.local PTR IN 4500/4455 0 V1121
b878.2e33.c7c5 CAMPUS APPLE TV1._airplay._tcp.local

CAMPUS APPLE TV1._airplay._tcp.local SRV IN 120/75 2 V1121
b878.2e33.c7c5 CAMPUS-APPLE-TV1.local

CAMPUS-APPLE-TV1.local A IN 120/75 2 V1121
b878.2e33.c7c5 121.1.0.254

CAMPUS APPLE TV1._airplay._tcp.local TXT IN 4500/4455 2 V1121
b878.2e33.c7c5 (162) 'deviceid=B8:78:2E:33:C7:C6'

'features=0x5a7ffff7' 'flags=0x4'

'model=AppleT~'~
```

show mdns cache

```

_ipp._tcp.local PTR IN 4500/4465 2 V12
2894.0fed.447f EPSON XP-400 Series._ipp._tcp.local

EPSON XP-400 Series._ipp._tcp.local SRV IN 120/85 2 V12
2894.0fed.447f EPSONC053AA.local

EPSONC053AA.local A IN 120/85 2 V12
2894.0fed.447f 121.1.0.251

EPSON XP-400 Series._ipp._tcp.local TXT IN 4500/4465 2 V12
2894.0fed.447f (384)'txtvers=1' N XP-400 Series'

      'usbFG=EPSON''usb_MDL=XP~'~

_smb._tcp.local PTR IN 4500/4465 2 V12
2894.0fed.447f EPSON XP-400 Series._smb._tcp.local

EPSON XP-400 Series._smb._tcp.local SRV IN 120/85 2 V12
2894.0fed.447f EPSONC053AA.local

EPSON XP-400 Series._smb._tcp.local TXT IN 4500/4465 2 V12
2894.0fed.447f (1)'' R2-Access1#

```

show mdns requests

To display information for outstanding mDNS requests, including record name and record type information, for the device, use the **show mdns requests** privileged EXEC command.

```
show mdns requests [detail | name record-name | type record-type [ name record-name ]]
```

Syntax Description	detail	Displays detailed mDNS requests information.
	name <i>record-name</i>	Displays detailed mDNS requests information based on name.
	type <i>record-type</i>	Displays detailed mDNS requests information based on type.

Command Default None

Command Modes Privileged EXEC
User EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain output do not appear, but the lines that contain output appear.

Example

This is an example of output from the **show mdns requests** command without any keywords:

```
Device# show mdns requests
MDNS Outstanding Requests
=====
Request name  :  _airplay._tcp.local
Request type  :  PTR
Request class :  IN
-----
Request name  :  *.*
Request type  :  PTR
Request class :  IN
```

show mdns statistics

To display mDNS statistics for the device, use the **show mdns statistics** privileged EXEC command.

```
show mdns statistics {all | service-list list-name | service-policy {all | interface type-number
}}
```

Syntax Description		
all		Displays the service policy, service list, and interface information.
service-list <i>list-name</i>		Displays the service list information.
service-policy		Displays the service policy information.
interface <i>type number</i>		Displays interface information.

Command Default None

Command Modes Privileged EXEC

User EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain output do not appear, but the lines that contain output appear.

Example

This is an example of output from the **show mdns statistics all** command:

```
Device# show mdns statistics all
mDNS Statistics
mDNS packets sent      : 0
mDNS packets received  : 0
mDNS packets dropped   : 0
mDNS cache memory in use: 64224(bytes)
```

show platform ip multicast

To display platform-dependent IP multicast tables and other information, use the **show platform ip multicast** privileged EXEC command.

show platform ip multicast {**groups** | **hardware** [**detail**] | **interfaces** | **retry**}

Syntax Description	groups	Displays IP multicast routes per group.
	hardware [detail]	Displays IP multicast routes loaded into hardware. The optional detail keyword is used to show port members in the destination index and route index.
	interfaces	Displays IP multicast interfaces.
	retry	Displays the IP multicast routes in the retry queue.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE/Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

This example shows how to display platform IP multicast routes per group:

```
Device# show platform ip multicast groups

Total Number of entries:3
MROUTE ENTRY vrf 0 (*, 224.0.0.0)
Token: 0x0000001f6 flags: C
No RPF interface.
Number of OIF: 0
Flags: 0x10 Pkts : 0
OIF Details:No OIF interface.

DI details
-----
Handle:0x603cf7f8 Res-Type:ASIC_RSC_DI Asic-Num:255
Feature-ID:AL_FID_L3_MULTICAST_IPV4 Lkp-ftr-id:LKP_FEAT_INVALID ref_count:1
Hardware Indices/Handles: index0:0x51f6 index1:0x51f6

Cookie length 56
0x0 0x4 0xe0 0x0 0x0 0x0 0x0 0x0
0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0
0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0

Detailed Resource Information (ASIC# 0)
-----

al_rsc_di
RM:index = 0x51f6
```

```

RM:pmap = 0x0
RM:cmi = 0x0
RM:rcp_pmap = 0x0
RM:force data copy = 0
RM:remote cpu copy = 0
RM:remote data copy = 0
RM:local cpu copy = 0
RM:local data copy = 0

```

```

al_rsc_cmi
RM:index = 0x51f6
RM:cti_lo[0] = 0x0
RM:cti_lo[1] = 0x0
RM:cti_lo[2] = 0x0
RM:cpu_q_vpn[0] = 0x0
RM:cpu_q_vpn[1] = 0x0
RM:cpu_q_vpn[2] = 0x0
RM:npu_index = 0x0
RM:strip_seg = 0x0
RM:copy_seg = 0x0
Detailed Resource Information (ASIC# 1)
-----

```

```

al_rsc_di
RM:index = 0x51f6
RM:pmap = 0x0
RM:cmi = 0x0
RM:rcp_pmap = 0x0
RM:force data copy = 0
RM:remote cpu copy = 0
RM:remote data copy = 0
RM:local cpu copy = 0
RM:local data copy = 0

```

```

al_rsc_cmi
RM:index = 0x51f6
RM:cti_lo[0] = 0x0
RM:cti_lo[1] = 0x0
RM:cti_lo[2] = 0x0
RM:cpu_q_vpn[0] = 0x0
RM:cpu_q_vpn[1] = 0x0
RM:cpu_q_vpn[2] = 0x0
RM:npu_index = 0x0
RM:strip_seg = 0x0
RM:copy_seg = 0x0

```

```

=====

```

```

RI details
-----

```

```

SI details
-----

```

```

RM:generic lbl = 0x0
RM:di_handle = 0x51f6
RM:fd const lbl = 0x0
RM:skipid_idx = 0x0
RM:rcp serviceid = 0x0
RM:dejavu prechken= 0x1
RM:local cpu = 0x0
RM:local data = 0x1
RM:remote cpu = 0x0
RM:remote data = 0x1

```

```

=====

HTM details
-----
Handle:0x5d604490 Res-Type:ASIC_RSC_STP_INDEX Asic-Num:255
Feature-ID:AL_FID_L3_MULTICAST_IPV4 Lkp-ftr-id:LKP_FEAT_IPV4_MCAST_ROUTE_STARG ref_count:1
Hardware Indices/Handles: handle0:0x5d604518 handle1:0x5d604580

Detailed Resource Information (ASIC# 0)
-----
Number of HTM Entries: 1

Entry #0: (handle 0x5d604518)

KEY - grp_addr:224.0.0.0 decap_tunnel: 0 encap_tunnel: 0 vrf_id: 0 mtr_id: 0
MASK - grp_addr:240.0.0.0 decap_tunnel: 0 encap_tunnel: 0 vrf_id: 4095 mtr_id: 0
AD: local_source_punt: 1 afd_label_or_clientid: 0 mcast_bridge_frame: 0 mcast_rep_frame: 0

rpf_valid: 1 rpf_le_ptr: 0 afd_client_flag: 0 dest_mod_bridge: 0 dest_mod_route: 1
cpp_type: 0 dest_mod_index: 0 rp_index: 0 priority: 3 rpf_le: 0 station_index: 164
capwap_mgid_present: 0 mgid 0
Detailed Resource Information (ASIC# 1)
-----
Number of HTM Entries: 1

Entry #0: (handle 0x5d604580)

KEY - grp_addr:224.0.0.0 decap_tunnel: 0 encap_tunnel: 0 vrf_id: 0 mtr_id: 0
MASK - grp_addr:240.0.0.0 decap_tunnel: 0 encap_tunnel: 0 vrf_id: 4095 mtr_id: 0
AD: local_source_punt: 1 afd_label_or_clientid: 0 mcast_bridge_frame: 0 mcast_rep_frame: 0

rpf_valid: 1 rpf_le_ptr: 0 afd_client_flag: 0 dest_mod_bridge: 0 dest_mod_route: 1
cpp_type: 0 dest_mod_index: 0 rp_index: 0 priority: 3 rpf_le: 0 station_index: 164
capwap_mgid_present: 0 mgid 0

=====

MROUTE ENTRY vrf 0 (*, 224.0.1.40)
Token: 0x0000001f8 flags: C IC
RPF interface: V1121(74238750229529173)): SVI
Token:0x00000021 flags: F IC NS
Number of OIF: 1
Flags: 0x10 Pkts : 0
OIF Details:
    V1121      F IC NS
DI details
-----
Handle:0x603d0000 Res-Type:ASIC_RSC_DI Asic-Num:255
Feature-ID:AL_FID_L3_MULTICAST_IPV4 Lkp-ftr-id:LKP_FEAT_INVALID ref_count:1
Hardware Indices/Handles: index0:0x51f7 index1:0x51f7

Cookie length 56
0x0 0x20 0xe0 0x0 0x1 0x28 0x0 0x0

0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0

0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0 0x0

Detailed Resource Information (ASIC# 0)
-----

```

show platform ip multicast

```

al_rsc_di
RM:index = 0x51f7
RM:pmap = 0x0
RM:cmi = 0x33f
RM:rcp_pmap = 0x0
RM:force data copy = 0
RM:remote cpu copy = 0
RM:remote data copy = 0
RM:local cpu copy = 0
RM:local data copy = 0

al_rsc_cmi
RM:index = 0x51f7
RM:cti_lo[0] = 0x0
RM:cti_lo[1] = 0x0
RM:cti_lo[2] = 0x0
RM:cpu_q_vpn[0] = 0x0
RM:cpu_q_vpn[1] = 0x0
RM:cpu_q_vpn[2] = 0x0
RM:npu_index = 0x0
RM:strip_seg = 0x0
RM:copy_seg = 0x0
Detailed Resource Information (ASIC# 1)
-----

```

```

al_rsc_di
RM:index = 0x51f7
RM:pmap = 0x0
RM:cmi = 0x33f
RM:rcp_pmap = 0x0
RM:force data copy = 0
RM:remote cpu copy = 0
RM:remote data copy = 0
RM:local cpu copy = 0
RM:local data copy = 0

```

```

al_rsc_cmi
RM:index = 0x51f7
RM:cti_lo[0] = 0x0
RM:cti_lo[1] = 0x0
RM:cti_lo[2] = 0x0
RM:cpu_q_vpn[0] = 0x0
RM:cpu_q_vpn[1] = 0x0
RM:cpu_q_vpn[2] = 0x0
RM:npu_index = 0x0
RM:strip_seg = 0x0
RM:copy_seg = 0x0

```

```

=====
RI details
-----

```

```

SI details
-----

```

```

RM:generic lbl = 0x0
RM:di_handle = 0x51f7
RM:fd const lbl = 0x8
RM:skipid_idx = 0x0
RM:rcp serviceid = 0x0
RM:dejavu prechken= 0x1
RM:local cpu = 0x0
RM:local data = 0x1

```


show platform ip multicast

```

al_rsc_di
RM:index = 0x51f8
RM:pmap = 0x0
RM:cmi = 0x0
RM:rcp_pmap = 0x0
RM:force data copy = 0
RM:remote cpu copy = 0
RM:remote data copy = 0
RM:local cpu copy = 0
RM:local data copy = 0

al_rsc_cmi
RM:index = 0x51f8
RM:cti_lo[0] = 0x0
RM:cti_lo[1] = 0x0
RM:cti_lo[2] = 0x0
RM:cpu_q_vpn[0] = 0x0
RM:cpu_q_vpn[1] = 0x0
RM:cpu_q_vpn[2] = 0x0
RM:npu_index = 0x0
RM:strip_seg = 0x0
RM:copy_seg = 0x0
Detailed Resource Information (ASIC# 1)
-----

```

```

al_rsc_di
RM:index = 0x51f8
RM:pmap = 0x0
RM:cmi = 0x0
RM:rcp_pmap = 0x1
RM:force data copy = 0
RM:remote cpu copy = 0
RM:remote data copy = 0
RM:local cpu copy = 0
RM:local data copy = 0

```

```

al_rsc_cmi
RM:index = 0x51f8
RM:cti_lo[0] = 0x0
RM:cti_lo[1] = 0x0
RM:cti_lo[2] = 0x0
RM:cpu_q_vpn[0] = 0x0
RM:cpu_q_vpn[1] = 0x0
RM:cpu_q_vpn[2] = 0x0
RM:npu_index = 0x0
RM:strip_seg = 0x0
RM:copy_seg = 0x0

```

```

=====
RI details
-----

```

```

ASIC# 0
Replication list :
-----

```

```

Total #ri : 0
start_ri : 15
common_ret : 0

```

```

ASIC# 1
Replication list :

```

```

-----

Total #ri : 6
start_ri : 15
common_ret : 0

Replication entry rep_ri 0xF #elem = 1
0) ri[0]=50 port=58 dirty=0

ASIC# 2
Replication list :
-----

Total #ri : 0
start_ri : 0
common_ret : 0

SI details
-----

RM:generic lbl = 0x0
RM:di_handle = 0x51f8
RM:fd const lbl = 0x8
RM:skipid_idx = 0x0
RM:rcp serviceid = 0x0
RM:dejavu prechken= 0x1
RM:local cpu = 0x0
RM:local data = 0x1
RM:remote cpu = 0x0
RM:remote data = 0x1

=====

HTM details
-----

Handle:0x606ff6f8 Res-Type:ASIC_RSC_STP_INDEX Asic-Num:255
Feature-ID:AL_FID_L3_MULTICAST_IPV4 Lkp-ftr-id:LKP_FEAT_IPV4_MCAST_ROUTE_STARG ref_count:1
Hardware Indices/Handles: handle0:0x606ff3e0 sm handle 0:0x60ab9160 handle1:0x606ff378
sm handle 1:0x60ab6cc0

Detailed Resource Information (ASIC# 0)
-----
Number of HTM Entries: 1

Entry #0: (handle 0x606ff3e0)

KEY - grp_addr:239.255.255.250 decap_tunnel: 0 encap_tunnel: 0 vrf_id: 0 mtr_id: 0
MASK - grp_addr:0.0.0.0 decap_tunnel: 0 encap_tunnel: 0 vrf_id: 0 mtr_id: 0
AD: local_source_punt: 1 afd_label_or_clientid: 0 mcast_bridge_frame: 0 mcast_rep_frame: 0

rpf_valid: 1 rpf_le_ptr: 0 afd_client_flag: 0 dest_mod_bridge: 0 dest_mod_route: 1
cpp_type: 0 dest_mod_index: 0 rp_index: 0 priority: 3 rpf_le: 0 station_index: 178
capwap_mgid_present: 0 mgid 0
Detailed Resource Information (ASIC# 1)
-----
Number of HTM Entries: 1

Entry #0: (handle 0x606ff378)

KEY - grp_addr:239.255.255.250 decap_tunnel: 0 encap_tunnel: 0 vrf_id: 0 mtr_id: 0
MASK - grp_addr:0.0.0.0 decap_tunnel: 0 encap_tunnel: 0 vrf_id: 0 mtr_id: 0

```

show platform ip multicast

```
AD: local_source_punt: 1 afd_label_or_clientid: 0 mcast_bridge_frame: 0 mcast_rep_frame: 0  
rpf_valid: 1 rpf_le_ptr: 0 afd_client_flag: 0 dest_mod_bridge: 0 dest_mod_route: 1  
cpp_type: 0 dest_mod_index: 0 rp_index: 0 priority: 3 rpf_le: 0 station_index: 178  
capwap_mgid_present: 0 mgid 0
```

```
=====
```

wireless mdns-bridging

To enable Ethernet mDNS support, use the **wireless mdns-bridging** command. To disable Ethernet mDNS support, use the **no** form of this command.

wireless mdns-bridging
no wireless mdns-bridging

This command has no keywords or arguments.

Command Default Ethernet mDNS support is enabled by default.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use this command only if you have enabled wireless multicast.

This example shows how to enable Ethernet mDNS support:

```
Device# configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
Device(config)# wireless multicast  
Device(config)# wireless mdns-bridging
```

wireless multicast

To enable Ethernet multicast support, use the **wireless multicast** command.

wireless multicast [**non-ip** [**vlan** *vlan-id*]]

Syntax Description	non-ip	(Optional) Configures multicast non-IP support.
	vlan <i>vlan-id</i>	(Optional) Specifies multicast non-IP for a VLAN. The interface number ranges between 1 and 4095.
Command Default	Disabled	
Command Modes	Interface configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
Usage Guidelines	None	

Examples

This example shows how to configure multicast non-IP VLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wireless multicast non-ip vlan 20
```



PART VI

IPv6

- [IPv6 Commands, on page 385](#)



IPv6 Commands

- [ipv6 flow monitor](#) , on page 386
- [ipv6 traffic-filter](#) , on page 387
- [show wireless ipv6 statistics](#) , on page 388

ipv6 flow monitor

This command activates a previously created flow monitor by assigning it to the interface to analyze incoming or outgoing traffic.

To activate a previously created flow monitor, use the **ipv6 flow monitor** command. To de-activate a flow monitor, use the **no** form of the command.

```
ipv6 flow monitor ipv6-monitor-name [sampler ipv6-sampler-name] {input | output}
no ipv6 flow monitor ipv6-monitor-name [sampler ipv6-sampler-name] {input | output}
```

Syntax Description

<i>ipv6-monitor-name</i>	Activates a previously created flow monitor by assigning it to the interface to analyze incoming or outgoing traffic.
sampler <i>ipv6-sampler-name</i>	Applies the flow monitor sampler.
input	Applies the flow monitor on input traffic.
output	Applies the flow monitor on output traffic.

Command Default

IPv6 flow monitor is not activated until it is assigned to an interface.

Command Modes

Interface Configuration.

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

You cannot attach a NetFlow monitor to a port channel interface. If both service module interfaces are part of an EtherChannel, you should attach the monitor to both physical interfaces.

This example shows how to apply a flow monitor to an interface:

```
Device(config)# interface gigabitethernet 1/1/2
Device(config-if)# ip flow monitor FLOW-MONITOR-1 input
Device(config-if)# ip flow monitor FLOW-MONITOR-2 output
Device(config-if)# end
```

ipv6 traffic-filter

This command enables IPv6 traffic filter.

To enable the filtering of IPv6 traffic on an interface, use the **ipv6 traffic-filter** command. To disable the filtering of IPv6 traffic on an interface, use the **no** form of the command.

Use the **ipv6 traffic-filter** interface configuration command on the switch stack or on a standalone switch to filter IPv6 traffic on an interface. The type and direction of traffic that you can filter depends on the feature set running on the switch stack. Use the **no** form of this command to disable the filtering of IPv6 traffic on an interface.

```
ipv6 traffic-filter [web] acl-name
no ipv6 traffic-filter [web]
```

Syntax Description

web (Optional) Specifies an IPv6 access name for the WLAN Web ACL.

acl-name Specifies an IPv6 access name.

Command Default

Filtering of IPv6 traffic on an interface is not configured.

Command Modes

wlan

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

To configure the dual IPv4 and IPv6 template, enter the **sdm prefer dual-ipv4-and-ipv6 {default | vlan}** global configuration command and reload the switch.

You can use the **ipv6 traffic-filter** command on physical interfaces (Layer 2 or Layer 3 ports), Layer 3 port channels, or switch virtual interfaces (SVIs).

You can apply an ACL to outbound or inbound traffic on Layer 3 interfaces (port ACLs), or to inbound traffic on Layer 2 interfaces (router ACLs).

If **any** port ACL (IPv4, IPv6, or MAC) is applied to an interface, that port ACL is used to filter packets, and any router ACLs attached to the SVI of the port VLAN are ignored.

This example shows how to filter IPv6 traffic on an interface:

```
Device(config-wlan)# ipv6 traffic-filter TestDocTrafficFilter
```

show wireless ipv6 statistics

This command is used to display the IPv6 packet counter statistics.

To view IPv6 packet counter statistics, use the **show wireless ipv6 statistics** command.

show wireless ipv6 statistics

Command Default	None.
------------------------	-------

Command Modes	User EXEC.
----------------------	------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following example shows the summary of the IPv6 packet counter statistics:

```

Device# show wireless ipv6 statistics
NS Forwarding to wireless clients           : Enabled

RS count                                   : 0
RA count                                   : 0
NS count                                   : 0
NA count                                   : 0
Other NDP packet count                     : 0
-----
Non-IPv6 packets count                     : 0
Non-IPv6 Multicast Destination MAC packet count : 0
Invalid length packets count               : 0
Null packets count                         : 0
Invalid Source MAC packets count           : 0
-----
TCP packets count                          : 0
UDP packets count                          : 0
Fragmented packets count                   : 0
No next header packets count               : 0
Other type packets count                   : 0
-----
Total packets count                        : 0
-----
Blocked RA packets count                   : 0
Blocked NS packets count                   : 0

```



PART **VII**

Layer 2/3

- [Layer 2/3 Commands, on page 391](#)



Layer 2/3 Commands

- [channel-group](#), on page 393
- [channel-protocol](#), on page 396
- [clear lacp](#), on page 397
- [clear pagp](#), on page 398
- [clear spanning-tree counters](#), on page 399
- [clear spanning-tree detected-protocols](#), on page 400
- [debug etherchannel](#), on page 401
- [debug lacp](#), on page 402
- [debug pagp](#), on page 403
- [debug platform pm](#), on page 404
- [debug platform uddl](#), on page 406
- [debug spanning-tree](#) , on page 407
- [interface port-channel](#), on page 409
- [lacp max-bundle](#), on page 410
- [lacp port-priority](#), on page 411
- [lacp rate](#), on page 412
- [lacp system-priority](#), on page 413
- [pagp learn-method](#), on page 414
- [pagp port-priority](#), on page 416
- [port-channel](#), on page 417
- [port-channel auto](#), on page 418
- [port-channel load-balance](#), on page 419
- [port-channel load-balance extended](#), on page 421
- [port-channel min-links](#), on page 422
- [rep admin vlan](#), on page 423
- [rep block port](#), on page 424
- [rep lsl-age-timer](#), on page 426
- [rep lsl-retries](#), on page 427
- [rep preempt delay](#), on page 428
- [rep preempt segment](#), on page 429
- [rep segment](#), on page 430
- [rep stcn](#), on page 432
- [show etherchannel](#), on page 433

- [show interfaces rep detail](#), on page 436
- [show lacp](#), on page 437
- [show pagp](#), on page 441
- [show platform software fed etherchannel](#), on page 443
- [show platform pm](#), on page 444
- [show rep topology](#), on page 445
- [show udd](#), on page 447
- [switchport](#), on page 450
- [switchport access vlan](#), on page 452
- [switchport mode](#), on page 455
- [switchport nonegotiate](#), on page 457
- [switchport voice vlan](#), on page 458
- [udd](#), on page 461
- [udd port](#), on page 463
- [udd reset](#), on page 465

channel-group

To assign an Ethernet port to an EtherChannel group, or to enable an EtherChannel mode, or both, use the **channel-group** command in interface configuration mode. To remove an Ethernet port from an EtherChannel group, use the **no** form of this command.

```
channel-group { auto | channel-group-number mode {active | auto [non-silent] | desirable
[non-silent] | on | passive} }
no channel-group
```

Syntax Description		
auto		Enables auto-LAG feature on individual port interface. By default, the auto-LAG feature is enabled on the port.
<i>channel-group-number</i>		Channel group number. The range is 1 to 128.
mode		Specifies the EtherChannel mode.
active		Unconditionally enables Link Aggregation Control Protocol (LACP).
auto		Enables the Port Aggregation Protocol (PAgP) only if a PAgP device is detected.
non-silent		(Optional) Configures the interface for nonsilent operation when connected to a partner that is PAgP-capable. Use in PAgP mode with the auto or desirable keyword when traffic is expected from the other device.
desirable		Unconditionally enables PAgP.
on		Enables the on mode.
passive		Enables LACP only if a LACP device is detected.

Command Default No channel groups are assigned.
No mode is configured.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

For Layer 2 EtherChannels, the **channel-group** command automatically creates the port-channel interface when the channel group gets its first physical port. You do not have to use the **interface port-channel** command in global configuration mode to manually create a port-channel interface. If you create the port-channel interface first, the *channel-group-number* can be the same as the *port-channel-number*, or you can use a new number. If you use a new number, the **channel-group** command dynamically creates a new port channel.

After you configure an EtherChannel, configuration changes that you make on the port-channel interface apply to all the physical ports assigned to the port-channel interface. Configuration changes applied to the physical port affect only the port where you apply the configuration. To change the parameters of all ports in an EtherChannel, apply configuration commands to the port-channel interface, for example, spanning-tree commands or commands to configure a Layer 2 EtherChannel as a trunk.

Active mode places a port into a negotiating state in which the port initiates negotiations with other ports by sending LACP packets. A channel is formed with another port group in either the active or passive mode.

Auto mode places a port into a passive negotiating state in which the port responds to PAgP packets it receives but does not start PAgP packet negotiation. A channel is formed only with another port group in desirable mode. When auto is enabled, silent operation is the default.

Desirable mode places a port into an active negotiating state in which the port starts negotiations with other ports by sending PAgP packets. An EtherChannel is formed with another port group that is in the desirable or auto mode. When desirable is enabled, silent operation is the default.

If you do not specify non-silent with the auto or desirable mode, silent is assumed. The silent mode is used when the device is connected to a device that is not PAgP-capable and rarely, if ever, sends packets. An example of a silent partner is a file server or a packet analyzer that is not generating traffic. In this case, running PAgP on a physical port prevents that port from ever becoming operational. However, it allows PAgP to operate, to attach the port to a channel group, and to use the port for transmission. Both ends of the link cannot be set to silent.

In on mode, a usable EtherChannel exists only when both connected port groups are in the on mode.



Caution

Use care when using the on mode. This is a manual configuration, and ports on both ends of the EtherChannel must have the same configuration. If the group is misconfigured, packet loss or spanning-tree loops can occur.

Passive mode places a port into a negotiating state in which the port responds to received LACP packets but does not initiate LACP packet negotiation. A channel is formed only with another port group in active mode.

Do not configure an EtherChannel in both the PAgP and LACP modes. EtherChannel groups running PAgP and LACP can coexist on the same device or on different devices in the stack (but not in a cross-stack configuration). Individual EtherChannel groups can run either PAgP or LACP, but they cannot interoperate.

If you set the protocol by using the **channel-protocol** interface configuration command, the setting is not overridden by the **channel-group** interface configuration command.

Do not configure a port that is an active or a not-yet-active member of an EtherChannel as an IEEE 802.1x port. If you try to enable IEEE 802.1x authentication on an EtherChannel port, an error message appears, and IEEE 802.1x authentication is not enabled.

Do not configure a secure port as part of an EtherChannel or configure an EtherChannel port as a secure port.

For a complete list of configuration guidelines, see the “Configuring EtherChannels” chapter in the software configuration guide for this release.



Caution Do not assign bridge groups on the physical EtherChannel ports because it creates loops.

This example shows how to configure an EtherChannel on a single device in the stack. It assigns two static-access ports in VLAN 10 to channel 5 with the PAgP mode desirable:

```
Device# configure terminal
Device(config)# interface range GigabitEthernet 2/0/1 - 2
Device(config-if-range)# switchport mode access
Device(config-if-range)# switchport access vlan 10
Device(config-if-range)# channel-group 5 mode desirable
Device(config-if-range)# end
```

This example shows how to configure an EtherChannel on a single device in the stack. It assigns two static-access ports in VLAN 10 to channel 5 with the LACP mode active:

```
Device# configure terminal
Device(config)# interface range GigabitEthernet 2/0/1 - 2
Device(config-if-range)# switchport mode access
Device(config-if-range)# switchport access vlan 10
Device(config-if-range)# channel-group 5 mode active
Device(config-if-range)# end
```

This example shows how to configure a cross-stack EtherChannel in a device stack. It uses LACP passive mode and assigns two ports on stack member 2 and one port on stack member 3 as static-access ports in VLAN 10 to channel 5:

```
Device# configure terminal
Device(config)# interface range GigabitEthernet 2/0/4 - 5
Device(config-if-range)# switchport mode access
Device(config-if-range)# switchport access vlan 10
Device(config-if-range)# channel-group 5 mode passive
Device(config-if-range)# exit
Device(config)# interface GigabitEthernet 3/0/3
Device(config-if)# switchport mode access
Device(config-if)# switchport access vlan 10
Device(config-if)# channel-group 5 mode passive
Device(config-if)# exit
```

You can verify your settings by entering the **show running-config** privileged EXEC command.

channel-protocol

To restrict the protocol used on a port to manage channeling, use the **channel-protocol** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

```
channel-protocol {lacp | pagp}
no channel-protocol
```

Syntax Description

lacp Configures an EtherChannel with the Link Aggregation Control Protocol (LACP).

pagp Configures an EtherChannel with the Port Aggregation Protocol (PAgP).

Command Default

No protocol is assigned to the EtherChannel.

Command Modes

Interface configuration

Command History

Release

Modification

Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE

This command was introduced.

Usage Guidelines

Use the **channel-protocol** command only to restrict a channel to LACP or PAgP. If you set the protocol by using the **channel-protocol** command, the setting is not overridden by the **channel-group** interface configuration command.

You must use the **channel-group** interface configuration command to configure the EtherChannel parameters. The **channel-group** command also can set the mode for the EtherChannel.

You cannot enable both the PAgP and LACP modes on an EtherChannel group.

PAgP and LACP are not compatible; both ends of a channel must use the same protocol.

You cannot configure PAgP on cross-stack configurations.

This example shows how to specify LACP as the protocol that manages the EtherChannel:

```
Device(config-if)# channel-protocol lacp
```

You can verify your settings by entering the **show etherchannel** [*channel-group-number*] **protocol** privileged EXEC command.

clear lacp

To clear Link Aggregation Control Protocol (LACP) channel-group counters, use the **clear lacp** command in privileged EXEC mode.

clear lacp [*channel-group-number*] **counters**

Syntax Description	<i>channel-group-number</i> (Optional) Channel group number. The range is 1 to 128.
	counters Clears traffic counters.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines You can clear all counters by using the **clear lacp counters** command, or you can clear only the counters for the specified channel group by using the **clear lacp *channel-group-number* counters** command.

This example shows how to clear all channel-group information:

```
Device# clear lacp counters
```

This example shows how to clear LACP traffic counters for group 4:

```
Device# clear lacp 4 counters
```

You can verify that the information was deleted by entering the **show lacp counters** or the **show lacp *channel-group-number* counters** privileged EXEC command.

clear pagp

To clear the Port Aggregation Protocol (PAgP) channel-group information, use the **clear pagp** command in privileged EXEC mode.

clear pagp [*channel-group-number*] **counters**

Syntax Description	<i>channel-group-number</i> (Optional) Channel group number. The range is 1 to 128.
	counters Clears traffic counters.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines You can clear all counters by using the **clear pagp counters** command, or you can clear only the counters for the specified channel group by using the **clear pagp channel-group-number counters** command.

This example shows how to clear all channel-group information:

```
Device# clear pagp counters
```

This example shows how to clear PAgP traffic counters for group 10:

```
Device# clear pagp 10 counters
```

You can verify that the information was deleted by entering the **show pagp** privileged EXEC command.

clear spanning-tree counters

To clear the spanning-tree counters, use the **clear spanning-tree counters** command in privileged EXEC mode.

clear spanning-tree counters [**interface** *interface-id*]

Syntax Description	interface <i>interface-id</i>	(Optional) Clears all spanning-tree counters on the specified interface. Valid interfaces include physical ports, VLANs, and port channels. The VLAN range is 1 to 4094.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines If the *interface-id* value is not specified, spanning-tree counters are cleared for all interfaces.

This example shows how to clear spanning-tree counters for all interfaces:

```
Device# clear spanning-tree counters
```

clear spanning-tree detected-protocols

To restart the protocol migration process and force renegotiation with neighboring devices on the interface, use the **clear spanning-tree detected-protocols** command in privileged EXEC mode.

clear spanning-tree detected-protocols [**interface** *interface-id*]

Syntax Description	interface <i>interface-id</i>	(Optional) Restarts the protocol migration process on the specified interface. Valid interfaces include physical ports, VLANs, and port channels. The VLAN range is 1 to 4094. The port-channel range is 1 to 128.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

A device running the rapid per-VLAN spanning-tree plus (rapid-PVST+) protocol or the Multiple Spanning Tree Protocol (MSTP) supports a built-in protocol migration method that enables it to interoperate with legacy IEEE 802.1D devices. If a rapid-PVST+ or an MSTP device receives a legacy IEEE 802.1D configuration bridge protocol data unit (BPDU) with the protocol version set to 0, the device sends only IEEE 802.1D BPDUs on that port. A multiple spanning-tree (MST) device can also detect that a port is at the boundary of a region when it receives a legacy BPDU, an MST BPDU (Version 3) associated with a different region, or a rapid spanning-tree (RST) BPDU (Version 2).

The device does not automatically revert to the rapid-PVST+ or the MSTP mode if it no longer receives IEEE 802.1D BPDUs because it cannot learn whether the legacy switch has been removed from the link unless the legacy switch is the designated switch. Use the **clear spanning-tree detected-protocols** command in this situation.

This example shows how to restart the protocol migration process on a port:

```
Device# clear spanning-tree detected-protocols interface gigabitethernet2/0/1
```

debug etherchannel

To enable debugging of EtherChannels, use the **debug etherchannel** command in privileged EXEC mode. To disable debugging, use the **no** form of the command.

```
debug etherchannel [{all | detail | error | event | idb}]
no debug etherchannel [{all | detail | error | event | idb}]
```

Syntax Description

all	(Optional) Displays all EtherChannel debug messages.
detail	(Optional) Displays detailed EtherChannel debug messages.
error	(Optional) Displays EtherChannel error debug messages.
event	(Optional) Displays EtherChannel event messages.
idb	(Optional) Displays PAgP interface descriptor block debug messages.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **undebug etherchannel** command is the same as the **no debug etherchannel** command.



Note Although the **linecard** keyword is displayed in the command-line help, it is not supported.

When you enable debugging on a stack, it is enabled only on the active switchstack master. To enable debugging on a stack memberthe standby switch, start a session from the active switchstack master by using the **session switch-number** command in privileged EXEC mode. Enter the **debug** command at the command-line prompt of the stack memberstandby switch.

To enable debugging on a stack memberthe standby switch without first starting a session on the active switchstack master, use the **remote command switch-number LINE** command in privileged EXEC mode.

This example shows how to display all EtherChannel debug messages:

```
Device# debug etherchannel all
```

This example shows how to display debug messages related to EtherChannel events:

```
Device# debug etherchannel event
```

debug lacp

To enable debugging of Link Aggregation Control Protocol (LACP) activity, use the **debug lacp** command in privileged EXEC mode. To disable LACP debugging, use the **no** form of this command.

```
debug lacp [{all | event | fsm | misc | packet}]
no debug lacp [{all | event | fsm | misc | packet}]
```

Syntax Description

all	(Optional) Displays all LACP debug messages.
event	(Optional) Displays LACP event debug messages.
fsm	(Optional) Displays messages about changes within the LACP finite state machine.
misc	(Optional) Displays miscellaneous LACP debug messages.
packet	(Optional) Displays the receiving and transmitting LACP control packets.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **undebg etherchannel** command is the same as the **no debug etherchannel** command.

When you enable debugging on a stack, it is enabled only on the active switchstack master. To enable debugging on a stack memberthe standby switch , start a session from the active switchstack master by using the **session switch-number** command in privileged EXEC mode. Enter the **debug** command at the command-line prompt of the stack memberstandby switch.

To enable debugging on a stack memberthe standby switch without first starting a session on the active switchstack master, use the **remote command switch-number LINE** command in privileged EXEC mode.

This example shows how to display all LACP debug messages:

```
Device# debug LACP all
```

This example shows how to display debug messages related to LACP events:

```
Device# debug LACP event
```

debug pagp

To enable debugging of Port Aggregation Protocol (PAgP) activity, use the **debug pagp** command in privileged EXEC mode. To disable PAgP debugging, use the **no** form of this command.

```
debug pagp [{all | dual-active | event | fsm | misc | packet}]
no debug pagp [{all | dual-active | event | fsm | misc | packet}]
```

Syntax Description	
all	(Optional) Displays all PAgP debug messages.
dual-active	(Optional) Displays dual-active detection messages.
event	(Optional) Displays PAgP event debug messages.
fsm	(Optional) Displays messages about changes within the PAgP finite state machine.
misc	(Optional) Displays miscellaneous PAgP debug messages.
packet	(Optional) Displays the receiving and transmitting PAgP control packets.

Command Default Debugging is disabled.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The **undebug pagp** command is the same as the **no debug pagp** command.

When you enable debugging on a stack, it is enabled only on the active switchstack master. To enable debugging on a stack memberthe standby switch , start a session from the active switchstack master by using the **session switch-number** command in privileged EXEC mode. Enter the **debug** command at the command-line prompt of the stack memberstandby switch.

To enable debugging on a stack memberthe standby switch without first starting a session on the active switchstack master, use the **remote command switch-number LINE** command in privileged EXEC mode.

This example shows how to display all PAgP debug messages:

```
Device# debug pagp all
```

This example shows how to display debug messages related to PAgP events:

```
Device# debug pagp event
```

debug platform pm

To enable debugging of the platform-dependent port manager software module, use the **debug platform pm** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug platform pm {all | counters | errdisable | fec | if-numbers | l2-control | link-status | platform |
pm-spi | pm-vectors [detail] | ses | vlans}
no debug platform pm {all | counters | errdisable | fec | if-numbers | l2-control | link-status | platform
| pm-spi | pm-vectors [detail] | ses | vlans}
```

Syntax Description

all	Displays all port manager debug messages.
counters	Displays counters for remote procedure call (RPC) debug messages.
errdisable	Displays error-disabled-related events debug messages.
fec	Displays forwarding equivalence class (FEC) platform-related events debug messages.
if-numbers	Displays interface-number translation event debug messages.
l2-control	Displays Layer 2 control infra debug messages.
link-status	Displays interface link-detection event debug messages.
platform	Displays port manager function event debug messages.
pm-spi	Displays port manager stateful packet inspection (SPI) event debug messages.
pm-vectors	Displays port manager vector-related event debug messages.
detail	(Optional) Displays vector-function details.
ses	Displays service expansion shelf (SES) related event debug messages.
vlans	Displays VLAN creation and deletion event debug messages.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **undebg platform pm** command is the same as the **no debug platform pm** command.

When you enable debugging on a stack, it is enabled only on the active switchstack master. To enable debugging on a stack memberthe standby switch , start a session from the active switchstack master by using the **session**

switch-number command in privileged EXEC mode. Enter the **debug** command at the command-line prompt of the stack memberstandby switch.

To enable debugging on a stack memberthe standby switch without first starting a session on the active switchstack master, use the **remote command** *switch-number LINE* command in privileged EXEC mode.

This example shows how to display debug messages related to the creation and deletion of VLANs:

```
Device# debug platform pm vlans
```

debug platform udd

To enable debugging of the platform-dependent UniDirectional Link Detection (UDLD) software, use the **debug platform udd** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug platform udd [{error | event}] [switch switch-number]
```

```
no debug platform udd [{error | event}] [switch switch-number]
```

Syntax Description

error	(Optional) Displays error condition debug messages.
event	(Optional) Displays UDLD-related platform event debug messages.
switch <i>switch-number</i>	(Optional) Displays UDLD debug messages for the specified stack member.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **undebug platform udd** command is the same as the **no debug platform udd** command.

When you enable debugging on a switch stack, it is enabled only on the active switch. To enable debugging on a stack member, you can start a session from the active switch by using the **session *switch-number*** EXEC command. Then enter the **debug** command at the command-line prompt of the stack member.

debug spanning-tree

To enable debugging of spanning-tree activities, use the **debug spanning-tree** command in EXEC mode. To disable debugging, use the **no** form of this command.

```
debug spanning-tree {all | backbonefast | bpdu | bpdu-opt | config | etherchannel | events | exceptions
| general | ha | mstp | pvst+ | root | snmp | synchronization | switch | uplinkfast}
no debug spanning-tree {all | backbonefast | bpdu | bpdu-opt | config | etherchannel | events |
exceptions | general | mstp | pvst+ | root | snmp | synchronization | switch | uplinkfast}
```

Syntax Description

all	Displays all spanning-tree debug messages.
backbonefast	Displays BackboneFast-event debug messages.
bpdu	Displays spanning-tree bridge protocol data unit (BPDU) debug messages.
bpdu-opt	Displays optimized BPDU handling debug messages.
config	Displays spanning-tree configuration change debug messages.
etherchannel	Displays EtherChannel-support debug messages.
events	Displays spanning-tree topology event debug messages.
exceptions	Displays spanning-tree exception debug messages.
general	Displays general spanning-tree activity debug messages.
ha	Displays high-availability spanning-tree debug messages.
mstp	Debugs Multiple Spanning Tree Protocol (MSTP) events.
pvst+	Displays per-VLAN spanning-tree plus (PVST+) event debug messages.
root	Displays spanning-tree root-event debug messages.
snmp	Displays spanning-tree Simple Network Management Protocol (SNMP) handling debug messages.
switch	Displays device shim command debug messages. This shim is the software module that is the interface between the generic Spanning Tree Protocol (STP) code and the platform-specific code of various device platforms.
synchronization	Displays the spanning-tree synchronization event debug messages.
uplinkfast	Displays UplinkFast-event debug messages.

Command Default Debugging is disabled.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The **undebbug spanning-tree** command is the same as the **no debug spanning-tree** command.

When you enable debugging on a stack, it is enabled only on the active switchstack master. To enable debugging on a stack memberthe standby switch , start a session from the active switchstack master by using the **session switch-number** command in privileged EXEC mode. Enter the **debug** command at the command-line prompt of the stack memberstandby switch.

To enable debugging on a stack memberthe standby switch without first starting a session on the active switchstack master, use the **remote command switch-number LINE** command in privileged EXEC mode.

This example shows how to display all spanning-tree debug messages:

```
Device# debug spanning-tree all
```

interface port-channel

To access or create a port channel, use the **interface port-channel** command in global configuration mode. Use the **no** form of this command to remove the port channel.

```
interface port-channel port-channel-number
no interface port-channel
```

Syntax Description

port-channel-number Channel group number. The range is 1 to 128.

Command Default

No port channel logical interfaces are defined.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
	This command was introduced.

Usage Guidelines

For Layer 2 EtherChannels, you do not have to create a port-channel interface before assigning physical ports to a channel group. Instead, you can use the **channel-group** interface configuration command, which automatically creates the port-channel interface when the channel group obtains its first physical port. If you create the port-channel interface first, the *channel-group-number* can be the same as the *port-channel-number*, or you can use a new number. If you use a new number, the **channel-group** command dynamically creates a new port channel.

Only one port channel in a channel group is allowed.

Follow these guidelines when you use the **interface port-channel** command:

- If you want to use the Cisco Discovery Protocol (CDP), you must configure it on the physical port and not on the port channel interface.
- Do not configure a port that is an active member of an EtherChannel as an IEEE 802.1x port. If IEEE 802.1x is enabled on a not-yet active port of an EtherChannel, the port does not join the EtherChannel.

For a complete list of configuration guidelines, see the “Configuring EtherChannels” chapter in the software configuration guide for this release.

This example shows how to create a port channel interface with a port channel number of 5:

```
Device(config)# interface port-channel 5
```

You can verify your setting by entering the **show running-config** privileged EXEC or **show etherchannel channel-group-number detail** privileged EXEC command.

lACP max-bundle

To define the maximum number of active LACP ports allowed in a port channel, use the **lACP max-bundle** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

```
lACP max-bundle max_bundle_number
no lACP max-bundle
```

Syntax Description	<i>max_bundle_number</i>	The maximum number of active LACP ports in the port channel. The range is 1 to 8. The default is 8.
Command Default	None	
Command Modes	Interface configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

An LACP channel group can have up to 16 Ethernet ports of the same type. Up to eight ports can be active, and up to eight ports can be in hot-standby mode. When there are more than eight ports in an LACP channel group, the device on the controlling end of the link uses port priorities to determine which ports are bundled into the channel and which ports are put in hot-standby mode. Port priorities on the other device (the noncontrolling end of the link) are ignored.

The **lACP max-bundle** command must specify a number greater than the number specified by the **port-channel min-links** command.

Use the **show etherchannel summary** privileged EXEC command to see which ports are in the hot-standby mode (denoted with an H port-state flag in the output display).

This example shows how to specify a maximum of five active LACP ports in port channel 2:

```
Device(config)# interface port-channel 2
Device(config-if)# lACP max-bundle 5
```

lACP port-priority

To configure the port priority for the Link Aggregation Control Protocol (LACP), use the **lACP port-priority** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

lACP port-priority *priority*
no lACP port-priority

Syntax Description	<i>priority</i> Port priority for LACP. The range is 1 to 65535.
---------------------------	--

Command Default	The default is 32768.
------------------------	-----------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE

Usage Guidelines The **lACP port-priority** interface configuration command determines which ports are bundled and which ports are put in hot-standby mode when there are more than eight ports in an LACP channel group.

An LACP channel group can have up to 16 Ethernet ports of the same type. Up to eight ports can be active, and up to eight ports can be in standby mode.

In port-priority comparisons, a numerically lower value has a higher priority: When there are more than eight ports in an LACP channel group, the eight ports with the numerically lowest values (highest priority values) for LACP port priority are bundled into the channel group, and the lower-priority ports are put in hot-standby mode. If two or more ports have the same LACP port priority (for example, they are configured with the default setting of 65535), then an internal value for the port number determines the priority.



Note The LACP port priorities are only effective if the ports are on the device that controls the LACP link. See the **lACP system-priority** global configuration command for determining which device controls the link.

Use the **show lACP internal** privileged EXEC command to display LACP port priorities and internal port number values.

For information about configuring LACP on physical ports, see the configuration guide for this release.

This example shows how to configure the LACP port priority on a port:

```
Device# interface gigabitEthernet2/0/1
Device(config-if)# lACP port-priority 1000
```

You can verify your settings by entering the **show lACP** [*channel-group-number*] **internal** privileged EXEC command.

lacp rate

To set the rate at which Link Aggregation Control Protocol (LACP) control packets are ingressed to an LACP-supported interface, use the **lacp rate** command in interface configuration mode. To return to the default settings, use the **no** form of this command

```
lacp rate {normal | fast}
no lacp rate
```

Syntax Description	<p>normal Specifies that LACP control packets are ingressed at the normal rate, every 30 seconds after the link is bundled.</p>				
	<p>fast Specifies that LACP control packets are ingressed at the fast rate, once every 1 second.</p>				
Command Default	The default ingress rate for control packets is 30 seconds after the link is bundled.				
Command Modes	Interface configuration (config-if)				
Command History	<table border="1"> <thead> <tr> <th data-bbox="324 865 941 919">Release</th> <th data-bbox="941 865 1503 919">Modification</th> </tr> </thead> <tbody> <tr> <td data-bbox="324 919 941 976">Cisco IOS XE Denali 16.2.1</td> <td data-bbox="941 919 1503 976">This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Denali 16.2.1	This command was introduced.
Release	Modification				
Cisco IOS XE Denali 16.2.1	This command was introduced.				
Usage Guidelines	<p>Use this command to modify the duration of LACP timeout. The LACP timeout value on Cisco switch is three times the LACP rate configured on the interface. Using the lacp rate command, you can select the LACP timeout value for a switch to be either 90 seconds or 3 seconds.</p> <p>This command is supported only on LACP-enabled interfaces.</p> <p>This example shows how to specify the fast (1 second) ingress rate on interface GigabitEthernet 0/0:</p> <pre>Device(config)# interface gigabitEthernet 0/0 Device(config-if)# lacp rate fast</pre>				

lACP system-priority

To configure the system priority for the Link Aggregation Control Protocol (LACP), use the **lACP system-priority** command in global configuration mode on the device. To return to the default setting, use the **no** form of this command.

lACP system-priority *priority*
no lACP system-priority

Syntax Description	<i>priority</i> System priority for LACP. The range is 1 to 65535.						
Command Default	The default is 32768.						
Command Modes	Global configuration						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE</td> </tr> <tr> <td></td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE		This command was introduced.
Release	Modification						
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE						
	This command was introduced.						

Usage Guidelines

The **lACP system-priority** command determines which device in an LACP link controls port priorities.

An LACP channel group can have up to 16 Ethernet ports of the same type. Up to eight ports can be active, and up to eight ports can be in standby mode. When there are more than eight ports in an LACP channel group, the device on the controlling end of the link uses port priorities to determine which ports are bundled into the channel and which ports are put in hot-standby mode. Port priorities on the other device (the noncontrolling end of the link) are ignored.

In priority comparisons, numerically lower values have a higher priority. Therefore, the system with the numerically lower value (higher priority value) for LACP system priority becomes the controlling system. If both devices have the same LACP system priority (for example, they are both configured with the default setting of 32768), the LACP system ID (the device MAC address) determines which device is in control.

The **lACP system-priority** command applies to all LACP EtherChannels on the device.

Use the **show etherchannel summary** privileged EXEC command to see which ports are in the hot-standby mode (denoted with an H port-state flag in the output display).

This example shows how to set the LACP system priority:

```
Device(config)# lACP system-priority 20000
```

You can verify your settings by entering the **show lACP sys-id** privileged EXEC command.

pagp learn-method

To learn the source address of incoming packets received from an EtherChannel port, use the **pagp learn-method** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

```
pagp learn-method {aggregation-port | physical-port}
no pagp learn-method
```

Syntax Description	<p>aggregation-port Specifies address learning on the logical port channel. The device sends packets to the source using any port in the EtherChannel. This setting is the default. With aggregation-port learning, it is not important on which physical port the packet arrives.</p> <p>physical-port Specifies address learning on the physical port within the EtherChannel. The device sends packets to the source using the same port in the EtherChannel from which it learned the source address. The other end of the channel uses the same port in the channel for a particular destination MAC or IP address.</p>						
Command Default	The default is aggregation-port (logical port channel).						
Command Modes	Interface configuration						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE</td> </tr> <tr> <td></td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE		This command was introduced.
Release	Modification						
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE						
	This command was introduced.						

Usage Guidelines

The learn method must be configured the same at both ends of the link.

The device supports address learning only on aggregate ports even though the **physical-port** keyword is provided in the command-line interface (CLI). The **pagp learn-method** and the **pagp port-priority** interface configuration commands have no effect on the device hardware, but they are required for PAgP interoperability with devices that only support address learning by physical ports.

When the link partner to the device is a physical learner, we recommend that you configure the device as a physical-port learner by using the **pagp learn-method physical-port** interface configuration command. We also recommend that you set the load-distribution method based on the source MAC address by using the **port-channel load-balance src-mac** global configuration command. Use the **pagp learn-method** interface configuration command only in this situation.

This example shows how to set the learning method to learn the address on the physical port within the EtherChannel:

```
Device(config-if)# pagp learn-method physical-port
```

This example shows how to set the learning method to learn the address on the port channel within the EtherChannel:

```
Device(config-if)# pagp learn-method aggregation-port
```

You can verify your settings by entering the **show running-config** privileged EXEC command or the **show pagp *channel-group-number* internal** privileged EXEC command.

pagp port-priority

To select a port over which all Port Aggregation Protocol (PAgP) traffic through the EtherChannel is sent, use the **pagp port-priority** command in interface configuration mode. If all unused ports in the EtherChannel are in hot-standby mode, they can be placed into operation if the currently selected port and link fails. To return to the default setting, use the **no** form of this command.

pagp port-priority *priority*
no pagp port-priority

Syntax Description	<i>priority</i> Priority number. The range is from 0 to 255.
---------------------------	--

Command Default	The default is 128.
------------------------	---------------------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	The physical port with the highest priority that is operational and has membership in the same EtherChannel is the one selected for PAgP transmission.
-------------------------	--

The device supports address learning only on aggregate ports even though the **physical-port** keyword is provided in the command-line interface (CLI). The **pagp learn-method** and the **pagp port-priority** interface configuration commands have no effect on the device hardware, but they are required for PAgP interoperability with devices that only support address learning by physical ports, such as the Catalyst 1900 switch.

When the link partner to the device is a physical learner, we recommend that you configure the device as a physical-port learner by using the **pagp learn-method physical-port** interface configuration command. We also recommend that you set the load-distribution method based on the source MAC address by using the **port-channel load-balance src-mac** global configuration command. Use the **pagp learn-method** interface configuration command only in this situation.

This example shows how to set the port priority to 200:

```
Device(config-if)# pagp port-priority 200
```

You can verify your setting by entering the **show running-config** privileged EXEC command or the **show pagp channel-group-number internal** privileged EXEC command.

port-channel

To convert the auto created EtherChannel into a manual channel and adding configuration on the EtherChannel, use the **port-channel** command in privileged EXEC mode.

port-channel { *channel-group-number* **persistent** | **persistent** }

Syntax Description	<i>channel-group-number</i>	Channel group number. The range is 1 to 128.
	persistent	Converts the auto created EtherChannel into a manual channel and allows you to add configuration on the EtherChannel.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.7.2E	This command was introduced.
Usage Guidelines	You can use the show etherchannel summary privileged EXEC command to display the EtherChannel information.	

Examples

This example shows how to convert the auto created EtherChannel into a manual channel:

```
Device# port-channel 1 persistent
```

port-channel auto

To enable the auto-LAG feature on a switch globally, use the **port-channel auto** command in global configuration mode. To disable the auto-LAG feature on the switch globally, use **no** form of this command.

port-channel auto
no port-channel auto

Syntax Description

This command has no arguments or keywords.

Command Default

By default, the auto-LAG feature is disabled globally and is enabled on all port interfaces.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.7.2E	This command was introduced.

Usage Guidelines

You can use the **show etherchannel auto** privileged EXEC command to verify if the EtherChannel was created automatically.

Examples

This example shows how to enable the auto-LAG feature on the switch:

```
Device(config)# port-channel auto
```

port-channel load-balance

To set the load-distribution method among the ports in the EtherChannel, use the **port-channel load-balance** command in global configuration mode. To reset the load-balancing mechanism to the default setting, use the **no** form of this command.

```
port-channel load-balance {dst-ip | dst-mac | dst-mixed-ip-port | dst-port | extended | src-dst-ip |
src-dst-mac | src-dst-mixed-ip-port | src-dst-port | src-ip | src-mac | src-mixed-ip-port | src-port}
no port-channel load-balance
```

Syntax Description

dst-ip	Specifies load distribution based on the destination host IP address.
dst-mac	Specifies load distribution based on the destination host MAC address. Packets to the same destination are sent on the same port, but packets to different destinations are sent on different ports in the channel.
dst-mixed-ip-port	Specifies load distribution based on the destination IPv4 or IPv6 address and the TCP/UDP (Layer 4) port number.
dst-port	Specifies load distribution based on the destination TCP/UDP (Layer 4) port number for both IPv4 and IPv6.
extended	Sets extended load balance methods among the ports in the EtherChannel. See the port-channel load-balance extended command.
src-dst-ip	Specifies load distribution based on the source and destination host IP address.
src-dst-mac	Specifies load distribution based on the source and destination host MAC address.
src-dst-mixed-ip-port	Specifies load distribution based on the source and destination host IP address and TCP/UDP (layer 4) port number.
src-dst-port	Specifies load distribution based on the source and destination TCP/UDP (Layer 4) port number.
src-ip	Specifies load distribution based on the source host IP address.
src-mac	Specifies load distribution based on the source MAC address. Packets from different hosts use different ports in the channel, but packets from the same host use the same port.
src-mixed-ip-port	Specifies load distribution based on the source host IP address and TCP/UDP (Layer 4) port number.
src-port	Specifies load distribution based on the TCP/UDP (Layer 4) port number.

Command Default

The default is **src-mac**.

Command Modes

Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You can verify your setting by entering the **show running-config** privileged EXEC command or the **show etherchannel load-balance** privileged EXEC command.

Examples

This example shows how to set the load-distribution method to dst-mac:

```
Device(config)# port-channel load-balance dst-mac
```

port-channel load-balance extended

To set combinations of load-distribution methods among the ports in the EtherChannel, use the **port-channel load-balance extended** command in global configuration mode. To reset the extended load-balancing mechanism to the default setting, use the **no** form of this command.

```
port-channel load-balance extended[{dst-ip | dst-mac | dst-port | ipv6-label | l3-proto | src-ip | src-mac | src-port}]
no port-channel load-balance extended
```

Syntax Description

dst-ip	(Optional) Specifies load distribution based on the destination host IP address.
dst-mac	(Optional) Specifies load distribution based on the destination host MAC address. Packets to the same destination are sent on the same port, but packets to different destinations are sent on different ports in the channel.
dst-port	(Optional) Specifies load distribution based on the destination TCP/UDP (Layer 4) port number for both IPv4 and IPv6.
ipv6-label	(Optional) Specifies load distribution based on the source MAC address and IPv6 flow label.
l3-proto	(Optional) Specifies load distribution based on the source MAC address and Layer 3 protocols.
src-ip	(Optional) Specifies load distribution based on the source host IP address.
src-mac	(Optional) Specifies load distribution based on the source MAC address. Packets from different hosts use different ports in the channel, but packets from the same host use the same port.
src-port	(Optional) Specifies load distribution based on the TCP/UDP (Layer 4) port number.

Command Default

The default is **src-mac**.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

For information about when to use these forwarding methods, see the *Layer 2/3 Configuration Guide (Catalyst 3650 Switches)* for this release.

You can verify your setting by entering the **show running-config** privileged EXEC command or the **show etherchannel load-balance** privileged EXEC command.

Examples

This example shows how to set the extended load-distribution method:

```
Device(config)# port-channel load-balance extended dst-ip dst-mac src-ip
```

port-channel min-links

To define the minimum number of LACP ports that must be bundled in the link-up state and bundled in the EtherChannel in order that a port channel becomes active, use the **port-channel min-links** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

```
port-channel min-links min_links_number
no port-channel min-links
```

Syntax Description	<i>min_links_number</i>	The minimum number of active LACP ports in the port channel. The range is 2 to 8. The default is 1.
Command Default	None	
Command Modes	Interface configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

An LACP channel group can have up to 16 Ethernet ports of the same type. Up to eight ports can be active, and up to eight ports can be in hot-standby mode. When there are more than eight ports in an LACP channel group, the device on the controlling end of the link uses port priorities to determine which ports are bundled into the channel and which ports are put in hot-standby mode. Port priorities on the other device (the noncontrolling end of the link) are ignored.

The **port-channel min-links** command must specify a number a less than the number specified by the **lACP max-bundle** command.

Use the **show etherchannel summary** privileged EXEC command to see which ports are in the hot-standby mode (denoted with an H port-state flag in the output display).

This example shows how to specify a minimum of three active LACP ports before port channel 2 becomes active:

```
Device(config)# interface port-channel 2
Device(config-if)# port-channel min-links 3
```

rep admin vlan

To configure a Resilient Ethernet Protocol (REP) administrative VLAN for REP to transmit hardware flood layer (HFL) messages, use the **rep admin vlan** command in global configuration mode. To return to the default configuration with VLAN 1 as the administrative VLAN, use the **no** form of this command.

```
rep admin vlan vlan-id
no rep admin vlan
```

Syntax Description	<i>vlan-id</i> The 48-bit static MAC address.				
Command Default	The default value of the administrative VLAN is VLAN 1.				
Command Modes	Global configuration (config)				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Denali 16.2.2</td> <td>This command was introduced</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Denali 16.2.2	This command was introduced
Release	Modification				
Cisco IOS XE Denali 16.2.2	This command was introduced				

Usage Guidelines

The range of the REP administrative VLAN is from 2 to 4094.

If you do not configure an administrative VLAN, the default VLAN is VLAN 1. The default VLAN 1 is always configured. There can be only one administrative VLAN on a router and on a segment.

You can verify your settings by entering the **show interfaces rep detail** privileged EXEC command.

The following example shows how to configure VLAN 100 as the REP administrative VLAN:

```
Device(config)# rep admin vlan 100
```

rep block port

To configure a REP VLAN load balancing on the REP primary edge port, use the **rep block port** command in interface configuration mode. To return to the default configuration with VLAN 1 as the administrative VLAN, use the **no** form of this command.

```
rep block port {id port-id | neighbor-offset | preferred} vlan {vlan-list | all}
no rep block port {id port-id | neighbor-offset | preferred}
```

Syntax Description

id <i>port-id</i>	Specifies the VLAN blocking alternate port by entering the unique port ID, which is automatically generated when REP is enabled. The REP port ID is a 16-character hexadecimal value. You can display the port ID for an interface by entering the show interface interface-id rep detail command in privileged EXEC mode.
<i>neighbor-offset</i>	Identifies the VLAN blocking alternate port by entering the offset number of a neighbor. The range is from -256 to +256; a value of 0 is invalid.
preferred	Selects the regular segment port previously identified as the preferred alternate port for VLAN load balancing.
vlan	Identifies the VLANs to be blocked.
<i>vlan-list</i>	VLAN ID or range of VLAN IDs to be displayed. Enter a VLAN ID from 1 to 4094 or a range or sequence of VLANs (such as 1-3, 22, 41-44) to be blocked.
all	Blocks all the VLANs.

Command Default

The default behavior after you enter the **rep preempt segment** command in privileged EXEC (for manual preemption) is to block all VLANs at the primary edge port. This behavior remains until you configure the **rep block port** command.

If the primary edge port cannot determine which port is to be the alternate port, the default action is no preemption and no VLAN load balancing.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Denali 16.2.2	This command was introduced

Usage Guidelines

You must enter this command on the REP primary edge port.

When you select an alternate port by entering an offset number, this number identifies the downstream neighbor port of an edge port. The primary edge port has an offset number of 1; positive numbers above 1 identify downstream neighbors of the primary edge port. Negative numbers identify the secondary edge port (offset number -1) and its downstream neighbors. Do not enter an offset value of 1 because that is the offset number of the primary edge port itself.

If you have configured a preempt delay time by entering the **rep preempt delay seconds** command in interface configuration mode and a link failure and recovery occurs, VLAN load balancing begins after the configured preemption time period elapses without another link failure. The alternate port specified in the load-balancing

configuration blocks the configured VLANs and unblocks all other segment ports. If the primary edge port cannot determine the alternate port for VLAN balancing, the default action is no preemption.

Each port in a segment has a unique port ID. To determine the port ID of a port, enter the **show interfaces interface-id rep detail** command in privileged EXEC mode.

The following example shows how to configure REP VLAN load balancing.

```
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep block port id 0009001818D68700 vlan 1-100
```

rep lsl-age-timer

To configure the REP link status layer (LSL) age-out timer value, use the **rep lsl-age-timer** command in interface configuration mode. To restore the default age-out timer value, use the **no** form of this command.

rep lsl-age-timer *milliseconds*
no rep lsl-age-timer *milliseconds*

Syntax Description	<i>milliseconds</i> REP LSL age-out timer value in milliseconds (ms). The range is from 120 ms to 10000 ms in multiples of 40 ms.	
Command Default	The default LSL age-out timer value is 5 ms.	
Command Modes	Interface configuration (config-if)	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.2	This command was introduced
Usage Guidelines	<p>The rep lsl-age-timer command is used to configure the REP LSL age-out timer value. While configuring REP configurable timers, we recommend that you configure the REP LSL number of retries first and then configure the REP LSL age-out timer value.</p> <p>The following example shows how to configure REP LSL age-out timer value.</p> <pre>Device(config)# interface TenGigabitEthernet 4/1 Device(config-if)# rep segment 1 edge primary Device(config-if)# rep lsl-age-timer 2000</pre>	

rep lsl-retries

To configure the REP link status layer (LSL) number of retries, use the **rep lsl-retries** command in interface configuration mode. To restore the default number of retries, use the **no** form of this command.

```
rep lsl-retries number-of-retries
no rep lsl-retries number-of-retries
```

Syntax Description	<i>number-of-retries</i> Number of LSL retries. The range of retries is from 3 to 10.
---------------------------	---

Command Default	The default number of LSL retries is 5.
------------------------	---

Command Modes	Interface configuration (config-if)
----------------------	-------------------------------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.2	This command was introduced

Usage Guidelines The **rep lsl-retries** command is used to configure the number of retries before the REP link is disabled. While configuring REP configurable timers, we recommend that you configure the REP LSL number of retries first and then configure the REP LSL age-out timer value.

The following example shows how to configure REP LSL retries.

```
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep segment 2 edge primary
```

rep preempt delay

To configure a waiting period after a segment port failure and recovery before REP VLAN load balancing is triggered, use the **rep preempt delay** command in interface configuration mode. To remove the configured delay, use the **no** form of this command.

rep preempt delay *seconds*
no rep preempt delay

Syntax Description	<i>seconds</i> Number of seconds to delay REP preemption. The range is from 15 to 300 seconds. The default is manual preemption without delay.				
Command Default	REP preemption delay is not set. The default is manual preemption without delay.				
Command Modes	Interface configuration (config-if)				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Denali 16.2.2</td> <td>This command was introduced</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Denali 16.2.2	This command was introduced
Release	Modification				
Cisco IOS XE Denali 16.2.2	This command was introduced				

Usage Guidelines

You must enter this command on the REP primary edge port.

You must enter this command and configure a preempt time delay if you want VLAN load balancing to automatically trigger after a link failure and recovery.

If VLAN load balancing is configured, after a segment port failure and recovery, the REP primary edge port starts a delay timer before VLAN load balancing occurs. Note that the timer restarts after each link failure. When the timer expires, the REP primary edge alerts the alternate port to perform VLAN load balancing (configured by using the **rep block port** interface configuration command) and prepares the segment for the new topology. The configured VLAN list is blocked at the alternate port, and all other VLANs are blocked at the primary edge port.

You can verify your settings by entering the **show interfaces rep** privileged EXEC command.

The following example shows how to configure a REP preemption time delay of 100 seconds on the primary edge port.

```
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep preempt delay 100
```

rep preempt segment

To manually start REP VLAN load balancing on a segment, use the **rep preempt segment** command in privileged EXEC mode.

```
rep preempt segment segment-id
```

Syntax Description	<i>segment-id</i> ID of the REP segment. The range is from 1 to 1024.	
Command Default	Manual preemption is the default behavior.	
Command Modes	Privileged EXEC (#)	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.2	This command was introduced

Usage Guidelines

Enter this command on the segment, which has the primary edge port on the router.

Ensure that all the other segment configuration is completed before setting preemption for VLAN load balancing. When you enter the **rep preempt segment** *segment-id* command, a confirmation message appears before the command is executed because preemption for VLAN load balancing can disrupt the network.

If you do not enter the **rep preempt delay** *seconds* command in interface configuration mode on the primary edge port to configure a preemption time delay, the default configuration is to manually trigger VLAN load balancing on the segment. Use the **show rep topology** privileged EXEC command to see which port in the segment is the primary edge port.

If you do not configure VLAN load balancing, entering this command results in the default behavior—the primary edge port blocks all VLANs.

You configure VLAN load balancing by entering the **rep block port** command in interface configuration mode on the REP primary edge port before you manually start preemption.

The following example shows how to manually trigger REP preemption on segment 100.

```
Device# rep preempt segment 100
```

rep segment

To enable REP on the interface and to assign a segment ID to the interface, use the **rep segment** command in interface configuration mode. To disable REP on the interface, use the **no** form of this command.

rep segment *segment-id* [**edge** [**no-neighbor**] [**primary**]] [**preferred**]
no rep segment

Syntax Description

<i>segment-id</i>	Segment for which REP is enabled. Assign a segment ID to the interface. The range is from 1 to 1024.
edge	(Optional) Configures the port as an edge port. Each segment has only two edge ports.
no-neighbor	(Optional) Specifies the segment edge as one with no external REP neighbor.
primary	(Optional) Specifies that the port is the primary edge port where you can configure VLAN load balancing. A segment has only one primary edge port.
preferred	(Optional) Specifies that the port is the preferred alternate port or the preferred port for VLAN load balancing.
Note	Configuring a port as preferred does not guarantee that it becomes the alternate port; it merely gives it a slight edge among equal contenders. The alternate port is usually a previously failed port.

Command Default

REP is disabled on the interface.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Denali 16.2.2	This command was introduced

Usage Guidelines

REP ports must be a Layer 2 IEEE 802.1Q port or 802.1AD port. You must configure two edge ports on each REP segment, a primary edge port and a port to act as a secondary edge port.

If REP is enabled on two ports on a router, both ports must be either regular segment ports or edge ports. REP ports follow these rules:

- If only one port on a router is configured in a segment, the port should be an edge port.
- If two ports on a router belong to the same segment, both ports must be regular segment ports.
- If two ports on a router belong to the same segment and one is configured as an edge port and one as a regular segment port (a misconfiguration), the edge port is treated as a regular segment port.

REP interfaces come up in a blocked state and remain in a blocked state until notified that it is safe to unblock. Be aware of this to avoid sudden connection losses.

When REP is enabled on an interface, the default is for the port to be a regular segment port.

The following example shows how to enable REP on a regular (nonedge) segment port.

```
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep segment 100
```

The following example shows how to enable REP on a port and identify the port as the REP primary edge port.

```
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep segment 100 edge primary
```

The following example shows how to enable REP on a port and identify the port as the REP secondary edge port.

```
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep segment 100 edge
```

The following example shows how to enable REP as an edge no-neighbor port.

```
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep segment 1 edge no-neighbor primary
```

rep stcn

To configure a REP edge port to send segment topology change notifications (STCNs) to another interface or to other segments, use the **rep stcn** command in interface configuration mode. To disable the sending of STCNs to the interface or to the segment, use the **no** form of this command.

```
rep stcn {interface interface-id | segment segment-id-list}
no rep stcn {interface | segment}
```

Syntax Description

interface <i>interface-id</i>	Specifies a physical interface or port channel to receive STCNs.
segment <i>segment-id-list</i>	Specifies one REP segment or a list of segments to receive STCNs. The segment range is from 1 to 1024. You can also configure a sequence of segments (for example 3 to 5, 77, 100).

Command Default

Transmission of STCNs to other interfaces or segments is disabled.

Command Modes

Interface configuration (config-if)

Command History

Release	Modification
Cisco IOS XE Denali 16.2.2	This command was introduced

Usage Guidelines

Enter this command on a segment edge port to send STCNs to one or more segments or to an interface. You can verify your settings by entering the **show interfaces rep detail** privileged EXEC command.

The following example shows how to configure a REP edge port to send STCNs to segments 25 to 50.

```
Device(config)# interface TenGigabitEthernet 4/1
Device(config-if)# rep stcn segment 25-50
```

show etherchannel

To display EtherChannel information for a channel, use the **show etherchannel** command in user EXEC mode.

```
show etherchannel [{channel-group-number} | {detail | port | port-channel | protocol | summary }]}
| [{auto | detail | load-balance | port | port-channel | protocol | summary}]
```

Syntax Description	<i>channel-group-number</i>	(Optional) Channel group number. The range is 1 to 128.
	auto	(Optional) Displays that Etherchannel is created automatically.
	detail	(Optional) Displays detailed EtherChannel information.
	load-balance	(Optional) Displays the load-balance or frame-distribution scheme among ports in the port channel.
	port	(Optional) Displays EtherChannel port information.
	port-channel	(Optional) Displays port-channel information.
	protocol	(Optional) Displays the protocol that is being used in the channel.
	summary	(Optional) Displays a one-line summary per channel group.
Command Default	None	
Command Modes	User EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines If you do not specify a channel group number, all channel groups are displayed.

This is an example of output from the **show etherchannel auto** command:

```
device# show etherchannel auto
Flags:  D - down          P - bundled in port-channel
        I - stand-alone  s - suspended
        H - Hot-standby (LACP only)
        R - Layer3       S - Layer2
        U - in use       f - failed to allocate aggregator
        M - not in use, minimum links not met
        u - unsuitable for bundling
        w - waiting to be aggregated
        d - default port
        A - formed by Auto LAG

Number of channel-groups in use: 1
Number of aggregators:          1
```

```

Group  Port-channel  Protocol  Ports
-----+-----+-----+-----
1      Po1(SUA)          LACP      Gi1/0/45(P) Gi2/0/21(P) Gi3/0/21(P)

```

This is an example of output from the **show etherchannel channel-group-number detail** command:

```

Device> show etherchannel 1 detail
Group state = L2
Ports: 2  Maxports = 16
Port-channels: 1 Max Port-channels = 16
Protocol:      LACP
                Ports in the group:
                -----
Port: Gi1/0/1
-----
Port state      = Up Mstr In-Bndl
Channel group = 1      Mode = Active      Gcchange = -
Port-channel   =      PolGC = -          Pseudo port-channel = Po1
Port index     =      0Load = 0x00       Protocol = LACP

Flags: S - Device is sending Slow LACPDU      F - Device is sending fast LACPDU
      A - Device is in active mode.            P - Device is in passive mode.

Local information:
Port      Flags  State  LACP port  Admin  Oper  Port  Port
Gi1/0/1   SA    bndl   32768     0x1   0x1   0x101 0x3D
Gi1/0/2   A     bndl   32768     0x0   0x1   0x0    0x3D

Age of the port in the current state: 01d:20h:06m:04s

                Port-channels in the group:
                -----
Port-channel: Po1  (Primary Aggregator)

Age of the Port-channel = 01d:20h:20m:26s
Logical slot/port = 10/1      Number of ports = 2
HotStandBy port   = null
Port state        = Port-channel Ag-Inuse
Protocol          = LACP

Ports in the Port-channel:

Index  Load  Port      EC state      No of bits
-----+-----+-----+-----+-----
0      00    Gi1/0/1   Active        0
0      00    Gi1/0/2   Active        0

Time since last port bundled: 01d:20h:24m:44s  Gi1/0/2

```

This is an example of output from the **show etherchannel channel-group-number summary** command:

```

Device> show etherchannel 1 summary
Flags: D - down P - in port-channel
      I - stand-alone s - suspended
      H - Hot-standby (LACP only)
      R - Layer3 S - Layer2
      u - unsuitable for bundling
      U - in use f - failed to allocate aggregator
      d - default port

```

```
Number of channel-groups in use: 1
Number of aggregators: 1
```

Group	Port-channel	Protocol	Ports
1	Po1 (SU)	LACP	Gi1/0/1 (P) Gi1/0/2 (P)

This is an example of output from the **show etherchannel channel-group-number port-channel** command:

```
Device> show etherchannel 1 port-channel
Port-channels in the group:
-----
Port-channel: Po1 (Primary Aggregator)
-----
Age of the Port-channel = 01d:20h:24m:50s
Logical slot/port = 10/1 Number of ports = 2
Logical slot/port = 10/1 Number of ports = 2
Port state = Port-channel Ag-Inuse
Protocol = LACP

Ports in the Port-channel:

Index  Load  Port      EC state          No of bits
-----+-----+-----+-----+-----
  0     00   Gi1/0/1  Active            0
  0     00   Gi1/0/2  Active            0

Time since last port bundled: 01d:20h:24m:44s Gi1/0/2
```

This is an example of output from **show etherchannel protocol** command:

```
Device# show etherchannel protocol
Channel-group listing:
-----
Group: 1
-----
Protocol: LACP
Group: 2
-----
Protocol: PAgP
```

show interfaces rep detail

To display detailed REP configuration and status for all the interfaces or the specified interface, including the administrative VLAN, use the **show interfaces rep detail** command in privileged EXEC mode.

show interfaces [*interface-id*] **rep detail**

Syntax Description	
	<i>interface-id</i> (Optional) Physical interface used to display the port ID.

Command Modes	
	Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.2	This command was introduced

Usage Guidelines Enter this command on a segment edge port to send STCNs to one or more segments or to an interface. You can verify your settings by entering the **show interfaces rep detail** privileged EXEC command.

The following example shows how to display the REP configuration and status for a specified interface.

```
Device# show interfaces TenGigabitEthernet4/1 rep detail

TenGigabitEthernet4/1 REP enabled
Segment-id: 3 (Primary Edge)
PortID: 03010015FA66FF80
Preferred flag: No
Operational Link Status: TWO_WAY
Current Key: 02040015FA66FF804050
Port Role: Open
Blocked VLAN: <empty>
Admin-vlan: 1
Preempt Delay Timer: disabled
Configured Load-balancing Block Port: none
Configured Load-balancing Block VLAN: none
STCN Propagate to: none
LSL PDU rx: 999, tx: 652
HFL PDU rx: 0, tx: 0
BPA TLV rx: 500, tx: 4
BPA (STCN, LSL) TLV rx: 0, tx: 0
BPA (STCN, HFL) TLV rx: 0, tx: 0
EPA-ELECTION TLV rx: 6, tx: 5
EPA-COMMAND TLV rx: 0, tx: 0
EPA-INFO TLV rx: 135, tx: 136
```

show lacp

To display Link Aggregation Control Protocol (LACP) channel-group information, use the **show lacp** command in user EXEC mode.

```
show lacp [channel-group-number] {counters | internal | neighbor | sys-id}
```

Syntax Description	
<i>channel-group-number</i>	(Optional) Channel group number. The range is 1 to 128.
counters	Displays traffic information.
internal	Displays internal information.
neighbor	Displays neighbor information.
sys-id	Displays the system identifier that is being used by LACP. The system identifier consists of the LACP system priority and the device MAC address.

Command Default None

Command Modes User EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You can enter any **show lacp** command to display the active channel-group information. To display specific channel information, enter the **show lacp** command with a channel-group number.

If you do not specify a channel group, information for all channel groups appears.

You can enter the *channel-group-number* to specify a channel group for all keywords except **sys-id**.

This is an example of output from the **show lacp counters** user EXEC command. The table that follows describes the fields in the display.

```
Device> show lacp counters
          LACPDUs      Marker      Marker Response      LACPDUs
Port      Sent  Recv      Sent  Recv      Sent  Recv      Pkts  Err
-----
Channel group:1
Gi2/0/1      19   10         0    0         0    0         0
Gi2/0/2      14    6         0    0         0    0         0
```

Table 24: show lacp counters Field Descriptions

Field	Description
LACPDUs Sent and Recv	The number of LACP packets sent and received by a port.

Field	Description
Marker Sent and Recv	The number of LACP marker packets sent and received by a port.
Marker Response Sent and Recv	The number of LACP marker response packets sent and received by a port.
LACPDUs Pkts and Err	The number of unknown and illegal packets received by LACP for a port.

This is an example of output from the **show lacp internal** command:

```
Device> show lacp 1 internal
Flags: S - Device is requesting Slow LACPDUs
       F - Device is requesting Fast LACPDUs
       A - Device is in Active mode           P - Device is in Passive mode

Channel group 1

Port      Flags  State  LACP port  Admin  Oper  Port  Port
Port      Flags  State  Priority   Key    Key   Number State
Gi2/0/1   SA     bndl   32768     0x3    0x3   0x4   0x3D
Gi2/0/2   SA     bndl   32768     0x3    0x3   0x5   0x3D
```

The following table describes the fields in the display:

Table 25: show lacp internal Field Descriptions

Field	Description
State	State of the specific port. These are the allowed values: <ul style="list-style-type: none"> • ——Port is in an unknown state. • bndl—Port is attached to an aggregator and bundled with other ports. • susp—Port is in a suspended state; it is not attached to any aggregator. • hot-sby—Port is in a hot-standby state. • indiv—Port is incapable of bundling with any other port. • indep—Port is in an independent state (not bundled but able to handle data traffic. In this case, LACP is not running on the partner port). • down—Port is down.
LACP Port Priority	Port priority setting. LACP uses the port priority to put ports in standby mode when there is a hardware limitation that prevents all compatible ports from aggregating.

Field	Description
Admin Key	Administrative key assigned to this port. LACP automatically generates an administrative key value as a hexadecimal number. The administrative key defines the ability of a port to aggregate with other ports. A port's ability to aggregate with other ports is determined by the port physical characteristics (for example, data rate and duplex capability) and configuration restrictions that you establish.
Oper Key	Runtime operational key that is being used by this port. LACP automatically generates this value as a hexadecimal number.
Port Number	Port number.
Port State	<p>State variables for the port, encoded as individual bits within a single octet with these meanings:</p> <ul style="list-style-type: none"> • bit0: LACP_Activity • bit1: LACP_Timeout • bit2: Aggregation • bit3: Synchronization • bit4: Collecting • bit5: Distributing • bit6: Defaulted • bit7: Expired <p>Note In the list above, bit7 is the MSB and bit0 is the LSB.</p>

This is an example of output from the **show lacp neighbor** command:

```
Device> show lacp neighbor
Flags: S - Device is sending Slow LACPDUs   F - Device is sending Fast LACPDUs
       A - Device is in Active mode          P - Device is in Passive mode

Channel group 3 neighbors

Partner's information:

Port          Partner                               Partner   Partner
Gi2/0/1      System ID                             Port Number Age      Flags
32768,0007.eb49.5e80  0xC          19s     SP

              LACP Partner               Partner   Partner
              Port Priority              Oper Key  Port State
              32768                       0x3      0x3C

Partner's information:
```

Port	Partner System ID	Partner Port Number	Age	Partner Flags
Gi2/0/2	32768,0007.eb49.5e80	0xD	15s	SP
	LACP Partner Port Priority	Partner Oper Key	Partner Port State	
	32768	0x3	0x3C	

This is an example of output from the **show lacp sys-id** command:

```
Device> show lacp sys-id
32765,0002.4b29.3a00
```

The system identification is made up of the system priority and the system MAC address. The first two bytes are the system priority, and the last six bytes are the globally administered individual MAC address associated to the system.

show pagp

To display Port Aggregation Protocol (PAgP) channel-group information, use the **show pagp** command in EXEC mode.

```
show pagp [channel-group-number] {counters | dual-active | internal | neighbor}
```

Syntax Description	
<i>channel-group-number</i>	(Optional) Channel group number. The range is 1 to 128.
counters	Displays traffic information.
dual-active	Displays the dual-active status.
internal	Displays internal information.
neighbor	Displays neighbor information.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines You can enter any **show pagp** command to display the active channel-group information. To display the nonactive information, enter the **show pagp** command with a channel-group number.

Examples

This is an example of output from the **show pagp 1 counters** command:

```
Device> show pagp 1 counters
          Information      Flush
Port      Sent   Recv   Sent   Recv
-----
Channel group: 1
  Gi1/0/1   45    42     0     0
  Gi1/0/2   45    41     0     0
```

This is an example of output from the **show pagp dual-active** command:

```
Device> show pagp dual-active
PAgP dual-active detection enabled: Yes
PAgP dual-active version: 1.1

Channel group 1
Dual-Active   Partner           Partner   Partner
Port          Detect Capable   Name      Port      Version
Gi1/0/1       No               Device    Gi3/0/3   N/A
Gi1/0/2       No               Device    Gi3/0/4   N/A

<output truncated>
```

This is an example of output from the **show pagp 1 internal** command:

```
Device> show pagp 1 internal
Flags: S - Device is sending Slow hello.  C - Device is in Consistent state.
      A - Device is in Auto mode.
Timers: H - Hello timer is running.      Q - Quit timer is running.
      S - Switching timer is running.    I - Interface timer is running.

Channel group 1

```

Port	Flags	State	Timers	Hello Interval	Partner Count	PAGP Priority	Learning Method	Group Ifindex
Gi1/0/1	SC	U6/S7	H	30s	1	128	Any	16
Gi1/0/2	SC	U6/S7	H	30s	1	128	Any	16

This is an example of output from the **show pagp 1 neighbor** command:

```
Device> show pagp 1 neighbor

Flags: S - Device is sending Slow hello.  C - Device is in Consistent state.
      A - Device is in Auto mode.          P - Device learns on physical port.

Channel group 1 neighbors

```

Port	Partner Name	Partner Device ID	Partner Port	Age	Partner Flags	Partner Group Cap.
Gi1/0/1	device-p2	0002.4b29.4600	Gi01//1	9s	SC	10001
Gi1/0/2	device-p2	0002.4b29.4600	Gi1/0/2	24s	SC	10001

show platform software fed etherchannel

To display platform-dependent EtherChannel information, use the **show platform software fed etherchannel** command in privileged EXEC mode.

```
show platform software fed etherchannel [switch switch-number] channel-group-number
{group-mask | load-balance mac src-mac dst-mac [ip src-ip dst-ip [port src-port dst-port]]}
```

Syntax Description	
switch <i>switch-number</i>	(Optional) Specifies the stack member.
<i>channel-group-number</i>	Channel group number. The range is 1 to 128.
group-mask	Displays EtherChannel group mask.
load-balance	Tests EtherChannel load-balance hash algorithm.
mac <i>src-mac</i> <i>dst-mac</i>	Specifies the source and destination MAC addresses.
ip <i>src-ip</i> <i>dst-ip</i>	(Optional) Specifies the source and destination IP addresses.
port <i>src-port</i> <i>dst-port</i>	(Optional) Specifies the source and destination layer port numbers.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines Use this command only when you are working directly with a technical support representative while troubleshooting a problem.

Do not use this command unless a technical support representative asks you to do so.

show platform pm

To display platform-dependent port manager information, use the **show platform pm** command in privileged EXEC mode.

show platform pm {**etherchannel** *channel-group-number* **group-mask** | **interface-numbers** | **port-data** *interface-id* | **port-state** | **spi-info** | **spi-req-q**}

Syntax Description		
etherchannel <i>channel-group-number</i> group-mask	Displays the EtherChannel group-mask table for the specified channel group. The range is 1 to 128.	
interface-numbers	Displays interface numbers information.	
port-data <i>interface-id</i>	Displays port data information for the specified interface.	
port-state	Displays port state information.	
spi-info	Displays stateful packet inspection (SPI) information.	
spi-req-q	Displays stateful packet inspection (SPI) maximum wait time for acknowledgment.	
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	<p>Use this command only when you are working directly with your technical support representative while troubleshooting a problem.</p> <p>Do not use this command unless your technical support representative asks you to do so.</p>	

show rep topology

To display REP topology information for a segment or for all segments, including the primary and secondary edge ports in the segment, use the **show rep topology** command in privileged EXEC mode.

show rep topology [**segment** *segment-id*] [**archive**] [**detail**]

Syntax Description		
segment <i>segment-id</i>		(Optional) Specifies the segment for which to display REP topology information. The ID range is from 1 to 1024.
archive		(Optional) Displays the previous topology of the segment. This keyword is useful for troubleshooting a link failure.
detail		(Optional) Displays detailed REP topology information.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.2	This command was introduced

The following is sample output from the show rep topology command.

```
Device# show rep topology

REP Segment 1
BridgeName      PortName      Edge Role
-----
10.64.106.63    Te5/4         Pri  Open
10.64.106.228  Te3/4         Open
10.64.106.228  Te3/3         Open
10.64.106.67   Te4/3         Open
10.64.106.67   Te4/4         Alt
10.64.106.63   Te4/4         Sec  Open

REP Segment 3
BridgeName      PortName      Edge Role
-----
10.64.106.63    Gi50/1        Pri  Open
SVT_3400_2      Gi0/3         Open
SVT_3400_2      Gi0/4         Open
10.64.106.68   Gi40/2        Open
10.64.106.68   Gi40/1        Open
10.64.106.63   Gi50/2        Sec  Alt
```

The following is sample output from the **show rep topology detail** command.

```
Device# show rep topology detail

REP Segment 1
```

```
10.64.106.63, Te5/4 (Primary Edge)
  Open Port, all vlans forwarding
  Bridge MAC: 0005.9b2e.1700
  Port Number: 010
  Port Priority: 000
  Neighbor Number: 1 / [-6]
10.64.106.228, Te3/4 (Intermediate)
  Open Port, all vlans forwarding
  Bridge MAC: 0005.9b1b.1f20
  Port Number: 010
  Port Priority: 000
  Neighbor Number: 2 / [-5]
10.64.106.228, Te3/3 (Intermediate)
  Open Port, all vlans forwarding
  Bridge MAC: 0005.9b1b.1f20
  Port Number: 00E
  Port Priority: 000
  Neighbor Number: 3 / [-4]
10.64.106.67, Te4/3 (Intermediate)
  Open Port, all vlans forwarding
  Bridge MAC: 0005.9b2e.1800
  Port Number: 008
  Port Priority: 000
  Neighbor Number: 4 / [-3]
10.64.106.67, Te4/4 (Intermediate)
  Alternate Port, some vlans blocked
  Bridge MAC: 0005.9b2e.1800
  Port Number: 00A
  Port Priority: 000
  Neighbor Number: 5 / [-2]
10.64.106.63, Te4/4 (Secondary Edge)
  Open Port, all vlans forwarding
  Bridge MAC: 0005.9b2e.1700
  Port Number: 00A
  Port Priority: 000
  Neighbor Number: 6 / [-1]
```

show uddl

To display UniDirectional Link Detection (UDLD) administrative and operational status for all ports or the specified port, use the **show uddl** command in user EXEC mode.

```
show uddl [Auto-Template | Capwap | GigabitEthernet | GroupVI | InternalInterface |
Loopback | Null | Port-channel | TenGigabitEthernet | Tunnel | Vlan] interface_number
show uddl neighbors
```

Syntax Description		
Auto-Template	(Optional) Displays UDLD operational status of the auto-template interface. The range is from 1 to 999.	
Capwap	(Optional) Displays UDLD operational status of the CAPWAP interface. The range is from 0 to 2147483647.	
GigabitEthernet	(Optional) Displays UDLD operational status of the GigabitEthernet interface. The range is from 0 to 9.	
GroupVI	(Optional) Displays UDLD operational status of the group virtual interface. The range is from 1 to 255.	
InternalInterface	(Optional) Displays UDLD operational status of the internal interface. The range is from 0 to 9.	
Loopback	(Optional) Displays UDLD operational status of the loopback interface. The range is from 0 to 2147483647.	
Null	(Optional) Displays UDLD operational status of the null interface.	
Port-channel	(Optional) Displays UDLD operational status of the Ethernet channel interfaces. The range is from 1 to 128.	
TenGigabitEthernet	(Optional) Displays UDLD operational status of the Ten Gigabit Ethernet interface. The range is from 0 to 9.	
Tunnel	(Optional) Displays UDLD operational status of the tunnel interface. The range is from 0 to 2147483647.	
Vlan	(Optional) Displays UDLD operational status of the VLAN interface. The range is from 1 to 4095.	
<i>interface-id</i>	(Optional) ID of the interface and port number. Valid interfaces include physical ports, VLANs, and port channels.	
neighbors	(Optional) Displays neighbor information only.	
Command Default	None	
Command Modes	User EXEC	

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines If you do not enter an interface ID, administrative and operational UDLD status for all interfaces appear.

This is an example of output from the **show udld interface-id** command. For this display, UDLD is enabled on both ends of the link, and UDLD detects that the link is bidirectional. The table that follows describes the fields in this display.

```
Device> show udld gigabitethernet2/0/1
Interface gi2/0/1
---
Port enable administrative configuration setting: Follows device default
Port enable operational state: Enabled
Current bidirectional state: Bidirectional
Current operational state: Advertisement - Single Neighbor detected
Message interval: 60
Time out interval: 5
Entry 1
Expiration time: 146
Device ID: 1
Current neighbor state: Bidirectional
Device name: Switch-A
Port ID: Gi2/0/1
Neighbor echo 1 device: Switch-B
Neighbor echo 1 port: Gi2/0/2
Message interval: 5
CDP Device name: Switch-A
```

Table 26: show udld Field Descriptions

Field	Description
Interface	The interface on the local device configured for UDLD.
Port enable administrative configuration setting	How UDLD is configured on the port. If UDLD is enabled or disabled, the port enable configuration setting is the same as the operational enable state. Otherwise, the enable operational setting depends on the global enable setting.
Port enable operational state	Operational state that shows whether UDLD is actually running on this port.
Current bidirectional state	The bidirectional state of the link. An unknown state appears if the link is down or if it is connected to an UDLD-incapable device. A bidirectional state appears if the link is a normal two-way connection to a UDLD-capable device. All other values mean miswiring.

Field	Description
Current operational state	The current phase of the UDLD state machine. For a normal bidirectional link, the state machine is most often in the Advertisement phase.
Message interval	How often advertisement messages are sent from the local device. Measured in seconds.
Time out interval	The time period, in seconds, that UDLD waits for echoes from a neighbor device during the detection window.
Entry 1	Information from the first cache entry, which contains a copy of echo information received from the neighbor.
Expiration time	The amount of time in seconds remaining before this cache entry is aged out.
Device ID	The neighbor device identification.
Current neighbor state	The neighbor's current state. If both the local and neighbor devices are running UDLD normally, the neighbor state and local state should be bidirectional. If the link is down or the neighbor is not UDLD-capable, no cache entries appear.
Device name	The device name or the system serial number of the neighbor. The system serial number appears if the device name is not set or is set to the default (Switch).
Port ID	The neighbor port ID enabled for UDLD.
Neighbor echo 1 device	The device name of the neighbors' neighbor from which the echo originated.
Neighbor echo 1 port	The port number ID of the neighbor from which the echo originated.
Message interval	The rate, in seconds, at which the neighbor is sending advertisement messages.
CDP device name	The CDP device name or the system serial number. The system serial number appears if the device name is not set or is set to the default (Switch).

This is an example of output from the **show udld neighbors** command:

```
Device# show udld neighbors
Port      Device Name      Device ID  Port-ID  OperState
-----
Gi2/0/1   Switch-A          1          Gi2/0/1  Bidirectional
Gi3/0/1   Switch-A          2          Gi3/0/1  Bidirectional
```

switchport

To put an interface that is in Layer 3 mode into Layer 2 mode for Layer 2 configuration, use the **switchport** command in interface configuration mode. To put an interface in Layer 3 mode, use the **no** form of this command.

switchport
no switchport

Syntax Description This command has no arguments or keywords.

Command Default By default, all interfaces are in Layer 2 mode.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use the **no switchport** command (without parameters) to set the interface to the routed-interface status and to erase all Layer 2 configurations. You must use this command before assigning an IP address to a routed port.



Note This command is not supported on devices running the LAN Base feature set.

Entering the **no switchport** command shuts the port down and then reenables it, which might generate messages on the device to which the port is connected.

When you put an interface that is in Layer 2 mode into Layer 3 mode (or the reverse), the previous configuration information related to the affected interface might be lost, and the interface is returned to its default configuration.



Note If an interface is configured as a Layer 3 interface, you must first enter the **switchport** command to configure the interface as a Layer 2 port. Then you can enter the **switchport access vlan** and **switchport mode** commands.

The **switchport** command is not used on platforms that do not support Cisco-routed ports. All physical ports on such platforms are assumed to be Layer 2-switched interfaces.

You can verify the port status of an interface by entering the **show running-config** privileged EXEC command.

Examples

This example shows how to cause an interface to cease operating as a Layer 2 port and become a Cisco-routed port:

```
Device(config-if)# no switchport
```

This example shows how to cause the port interface to cease operating as a Cisco-routed port and convert to a Layer 2 switched interface:

```
Device(config-if)# switchport
```

switchport access vlan

To configure a port as a static-access port, use the **switchport access vlan** command in interface configuration mode. To reset the access mode to the default VLAN mode for the device, use the **no** form of this command.

switchport access vlan {*vlan-id* | **name** *vlan_name*}
no switchport access vlan

Syntax Description	<i>vlan-id</i>	VLAN ID of the access mode VLAN; the range is 1 to 4094.
	name <i>vlan_name</i>	(Optional) Enter the name of the VLAN. You can enter up to 128 characters.
Command Default	The default access VLAN and trunk interface native VLAN is a default VLAN corresponding to the platform or interface hardware.	
Command Modes	Interface configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
	Cisco IOS XE Denali 16.2.1	The name <i>vlan_name</i> keyword was introduced.

Usage Guidelines

The port must be in access mode before the **switchport access vlan** command can take effect.

If the switchport mode is set to **access vlan** *vlan-id*, the port operates as a member of the specified VLAN. An access port can be assigned to only one VLAN.

The **no switchport access** command resets the access mode VLAN to the appropriate default VLAN for the device.

Examples

This example shows how to change a switched port interface that is operating in access mode to operate in VLAN 2 instead of the default VLAN:

```
Device(config-if)# switchport access vlan 2
```

Examples

This example show how to first populate the VLAN database by associating a VLAN ID with a VLAN name, and then configure the VLAN (using the name) on an interface, in the access mode: You can also verify your configuration by entering the **show interfaces interface-id switchport** in privileged EXEC command and examining information in the Access Mode VLAN: row.

Part 1 - Making the entry in the VLAN database:

```
Device# configure terminal
Device(config)# vlan 33
Device(config-vlan)# name test
Device(config-vlan)# end
Device#
```

Part 2 - Checking the VLAN database

```

Device # show vlan id 33
VLAN Name      Status   Ports
-----
33    test       active

VLAN Type  SAID      MTU    Parent RingNo BridgeNo  Stp  BrdgMode Trans1 Trans2
-----
33    enet    100033    1500   -      -      -      -    -         0      0

Remote SPAN VLAN
-----
Disabled

Primary  Secondary Type          Ports
-----

```

Part 3 - Assigning VLAN to the interface by using the name of the VLAN

```

Device # configure terminal
Device(config)# interface GigabitEthernet3/1/1
Device(config-if)# switchport mode access
Device(config-if)# switchport access vlan name test
Device(config-if)# end
Device#

```

Part 4 - Verifying configuration

```

Device # show running-config interface GigabitEthernet3/1/1
Building configuration...
Current configuration : 113 bytes
!
interface GigabitEthernet3/1/1
switchport access vlan 33
switchport mode access
Switch#

```

Part 5 - Verifying interface switchport

```

Device # show interface GigabitEthernet3/1/1 switchport
Name: Gi3/1/1
Switchport: Enabled
Administrative Mode: static access
Operational Mode: static access
Administrative Trunking Encapsulation: dot1q
Operational Trunking Encapsulation: native
Negotiation of Trunking: Off
Access Mode VLAN: 33 (test)
Trunking Native Mode VLAN: 1 (default)
Administrative Native VLAN tagging: enabled
Voice VLAN: None
Administrative private-vlan host-association: none
Administrative private-vlan mapping: none
Administrative private-vlan trunk native VLAN: none
Administrative private-vlan trunk Native VLAN tagging: enabled
Administrative private-vlan trunk encapsulation: dot1q
Administrative private-vlan trunk normal VLANs: none
Administrative private-vlan trunk associations: none
Administrative private-vlan trunk mappings: none
Operational private-vlan: none
Trunking VLANs Enabled: ALL
Pruning VLANs Enabled: 2-1001
Capture Mode Disabled
Capture VLANs Allowed: ALL
Unknown unicast blocked: disabled

```

```
Unknown multicast blocked: disabled
Appliance trust: none
Switch#
```

switchport mode

To configure the VLAN membership mode of a port, use the **switchport mode** command in interface configuration mode. To reset the mode to the appropriate default for the device, use the **no** form of this command.

```
switchport mode {access | dynamic | {auto | desirable} | trunk}
noswitchport mode {access | dynamic | {auto | desirable} | trunk}
```

Syntax Description		
access	Sets the port to access mode (either static-access or dynamic-access depending on the setting of the switchport access vlan interface configuration command). The port is set to access unconditionally and operates as a nontrunking, single VLAN interface that sends and receives nonencapsulated (non-tagged) frames. An access port can be assigned to only one VLAN.	
dynamic auto	Sets the port trunking mode dynamic parameter to auto to specify that the interface convert the link to a trunk link. This is the default switchport mode.	
dynamic desirable	Sets the port trunking mode dynamic parameter to desirable to specify that the interface actively attempt to convert the link to a trunk link.	
trunk	Sets the port to trunk unconditionally. The port is a trunking VLAN Layer 2 interface. The port sends and receives encapsulated (tagged) frames that identify the VLAN of origination. A trunk is a point-to-point link between two devices or between a device and a router.	

Command Default The default mode is **dynamic auto**.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines A configuration that uses the **access**, or **trunk** keywords takes effect only when you configure the port in the appropriate mode by using the **switchport mode** command. The static-access and trunk configuration are saved, but only one configuration is active at a time.

When you enter **access** mode, the interface changes to permanent nontrunking mode and negotiates to convert the link into a nontrunk link even if the neighboring interface does not agree to the change.

When you enter **trunk** mode, the interface changes to permanent trunking mode and negotiates to convert the link into a trunk link even if the interface connecting to it does not agree to the change.

When you enter **dynamic auto** mode, the interface converts the link to a trunk link if the neighboring interface is set to **trunk** or **desirable** mode.

When you enter **dynamic desirable** mode, the interface becomes a trunk interface if the neighboring interface is set to **trunk**, **desirable**, or **auto** mode.

To autonegotiate trunking, the interfaces must be in the same VLAN Trunking Protocol (VTP) domain. Trunk negotiation is managed by the Dynamic Trunking Protocol (DTP), which is a point-to-point protocol. However, some internetworking devices might forward DTP frames improperly, which could cause misconfigurations. To avoid this problem, configure interfaces connected to devices that do not support DTP to not forward DTP frames, which turns off DTP.

- If you do not intend to trunk across those links, use the **switchport mode access** interface configuration command to disable trunking.
- To enable trunking to a device that does not support DTP, use the **switchport mode trunk** and **switchport nonegotiate** interface configuration commands to cause the interface to become a trunk but to not generate DTP frames.

Access ports and trunk ports are mutually exclusive.

The IEEE 802.1x feature interacts with switchport modes in these ways:

- If you try to enable IEEE 802.1x on a trunk port, an error message appears, and IEEE 802.1x is not enabled. If you try to change the mode of an IEEE 802.1x-enabled port to trunk, the port mode is not changed.
- If you try to enable IEEE 802.1x on a port set to **dynamic auto** or **dynamic desirable**, an error message appears, and IEEE 802.1x is not enabled. If you try to change the mode of an IEEE 802.1x-enabled port to **dynamic auto** or **dynamic desirable**, the port mode is not changed.
- If you try to enable IEEE 802.1x on a dynamic-access (VLAN Query Protocol [VQP]) port, an error message appears, and IEEE 802.1x is not enabled. If you try to change an IEEE 802.1x-enabled port to dynamic VLAN assignment, an error message appears, and the VLAN configuration is not changed.

You can verify your settings by entering the **show interfaces interface-id switchport** privileged EXEC command and examining information in the *Administrative Mode* and *Operational Mode* rows.

Examples

This example shows how to configure a port for access mode:

```
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# switchport mode access
```

This example shows how set the port to dynamic desirable mode:

```
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# switchport mode dynamic desirable
```

This example shows how to configure a port for trunk mode:

```
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# switchport mode trunk
```

switchport nonegotiate

To specify that Dynamic Trunking Protocol (DTP) negotiation packets are not sent on the Layer 2 interface, use the **switchport nonegotiate** command in interface configuration mode. Use the **no** form of this command to return to the default setting.

switchport nonegotiate
no switchport nonegotiate

Syntax Description

This command has no arguments or keywords.

Command Default

The default is to use DTP negotiation to learn the trunking status.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **no switchport nonegotiate** command removes nonegotiate status.

This command is valid only when the interface switchport mode is access or trunk (configured by using the **switchport mode access** or the **switchport mode trunk** interface configuration command). This command returns an error if you attempt to execute it in dynamic (auto or desirable) mode.

Internetworking devices that do not support DTP might forward DTP frames improperly and cause misconfigurations. To avoid this problem, turn off DTP by using the **switchport nonegotiate** command to configure the interfaces connected to devices that do not support DTP to not forward DTP frames.

When you enter the **switchport nonegotiate** command, DTP negotiation packets are not sent on the interface. The device does or does not trunk according to the **mode** parameter: **access** or **trunk**.

- If you do not intend to trunk across those links, use the **switchport mode access** interface configuration command to disable trunking.
- To enable trunking on a device that does not support DTP, use the **switchport mode trunk** and **switchport nonegotiate** interface configuration commands to cause the interface to become a trunk but to not generate DTP frames.

This example shows how to cause a port to refrain from negotiating trunking mode and to act as a trunk or access port (depending on the mode set):

```
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# switchport nonegotiate
```

You can verify your setting by entering the **show interfaces interface-id switchport** privileged EXEC command.

switchport voice vlan

To configure voice VLAN on the port, use the **switchport voice vlan** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

switchport voice vlan {*vlan-id* | **dot1p** | **none** | **untagged** | **name** *vlan_name*}
no switchport voice vlan

Syntax Description		
<i>vlan-id</i>		The VLAN to be used for voice traffic. The range is 1 to 4094. By default, the IP phone forwards the voice traffic with an IEEE 802.1Q priority of 5.
dot1p		Configures the telephone to use IEEE 802.1p priority tagging and uses VLAN 0 (the native VLAN). By default, the Cisco IP phone forwards the voice traffic with an IEEE 802.1p priority of 5.
none		Does not instruct the IP telephone about the voice VLAN. The telephone uses the configuration from the telephone key pad.
untagged		Configures the telephone to send untagged voice traffic. This is the default for the telephone.
name <i>vlan_name</i>	(Optional)	Specifies the VLAN name to be used for voice traffic. You can enter up to 128 characters.

Command Default The default is not to automatically configure the telephone (**none**).
 The telephone default is not to tag frames.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
	Cisco IOS XE Denali 16.2.1	Option to specify a VLAN name for voice VLAN. The ' name ' keyword was added.

Usage Guidelines You should configure voice VLAN on Layer 2 access ports.

You must enable Cisco Discovery Protocol (CDP) on the switch port connected to the Cisco IP phone for the device to send configuration information to the phone. CDP is enabled by default globally and on the interface.

Before you enable voice VLAN, we recommend that you enable quality of service (QoS) on the interface by entering the **trust device cisco-phone** interface configuration command. If you use the auto QoS feature, these settings are automatically configured.

When you enter a VLAN ID, the IP phone forwards voice traffic in IEEE 802.1Q frames, tagged with the specified VLAN ID. The device puts IEEE 802.1Q voice traffic in the voice VLAN.

When you select **dot1p**, **none**, or **untagged**, the device puts the indicated voice traffic in the access VLAN.

In all configurations, the voice traffic carries a Layer 2 IP precedence value. The default is 5 for voice traffic.

When you enable port security on an interface that is also configured with a voice VLAN, set the maximum allowed secure addresses on the port to 2. When the port is connected to a Cisco IP phone, the IP phone requires one MAC address. The Cisco IP phone address is learned on the voice VLAN, but not on the access VLAN. If you connect a single PC to the Cisco IP phone, no additional MAC addresses are required. If you connect more than one PC to the Cisco IP phone, you must configure enough secure addresses to allow one for each PC and one for the Cisco IP phone.

If any type of port security is enabled on the access VLAN, dynamic port security is automatically enabled on the voice VLAN.

You cannot configure static secure MAC addresses in the voice VLAN.

The Port Fast feature is automatically enabled when voice VLAN is configured. When you disable voice VLAN, the Port Fast feature is not automatically disabled.

This example show how to first populate the VLAN database by associating a VLAN ID with a VLAN name, and then configure the VLAN (using the name) on an interface, in the access mode: You can also verify your configuration by entering the **show interfaces interface-id switchport** in privileged EXEC command and examining information in the Voice VLAN: row.

Part 1 - Making the entry in the VLAN database:

```
Device# configure terminal
Device(config)# vlan 55
Device(config-vlan)# name test
Device(config-vlan)# end
Device#
```

Part 2 - Checking the VLAN database:

```
Device# show vlan id 55
VLAN Name Status Ports
-----
55 test active
VLAN Type SAID MTU Parent RingNo BridgeNo Stp BrdgMode Trans1 Trans2
-----
55 enet 100055 1500 - - - - - 0 0
Remote SPAN VLAN
-----
Disabled
Primary Secondary Type Ports
-----
```

Part 3- Assigning VLAN to the interface by using the name of the VLAN:

```
Device# configure terminal
Device(config)# interface gigabitethernet3/1/1
Device(config-if)# switchport mode access
Device(config-if)# switchport voice vlan name test
Device(config-if)# end
Device#
```

Part 4 - Verifying configuration:

```
Device# show running-config
interface gigabitethernet3/1/1
Building configuration...
Current configuration : 113 bytes
!
interface GigabitEthernet3/1/1
switchport voice vlan 55
```

```
switchport mode access
Switch#
```

Part 5 - Also can be verified in interface switchport:

```
Device# show interface GigabitEthernet3/1/1 switchport
Name: Gi3/1/1
Switchport: Enabled
Administrative Mode: static access
Operational Mode: static access
Administrative Trunking Encapsulation: dot1q
Operational Trunking Encapsulation: native
Negotiation of Trunking: Off
Access Mode VLAN: 1 (default)
Trunking Native Mode VLAN: 1 (default)
Administrative Native VLAN tagging: enabled
Voice VLAN: 55 (test)
Administrative private-vlan host-association: none
Administrative private-vlan mapping: none
Administrative private-vlan trunk native VLAN: none
Administrative private-vlan trunk Native VLAN tagging: enabled
Administrative private-vlan trunk encapsulation: dot1q
Administrative private-vlan trunk normal VLANs: none
Administrative private-vlan trunk associations: none
Administrative private-vlan trunk mappings: none
Operational private-vlan: none
Trunking VLANs Enabled: ALL
Pruning VLANs Enabled: 2-1001
Capture Mode Disabled
Capture VLANs Allowed: ALL
Unknown unicast blocked: disabled
Unknown multicast blocked: disabled
Appliance trust: none
Device#
```

udld

To enable aggressive or normal mode in the UniDirectional Link Detection (UDLD) and to set the configurable message timer time, use the **udld** command in global configuration mode. To disable aggressive or normal mode UDLD on all fiber-optic ports, use the **no** form of the command.

```
udld {aggressive | enable | message time message-timer-interval}
no udld {aggressive | enable | message}
```

Syntax Description		
aggressive		Enables UDLD in aggressive mode on all fiber-optic interfaces.
enable		Enables UDLD in normal mode on all fiber-optic interfaces.
message time <i>message-timer-interval</i>		Configures the period of time between UDLD probe messages on ports that are in the advertisement phase and are determined to be bidirectional. The range is 1 to 90 seconds. The default is 15 seconds.

Command Default
UDLD is disabled on all interfaces.
The message timer is set at 15 seconds.

Command Modes
Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines
UDLD supports two modes of operation: normal (the default) and aggressive. In normal mode, UDLD detects unidirectional links due to misconnected interfaces on fiber-optic connections. In aggressive mode, UDLD also detects unidirectional links due to one-way traffic on fiber-optic and twisted-pair links and due to misconnected interfaces on fiber-optic links. For information about normal and aggressive modes, see the *Catalyst 2960-X Switch Layer 2 Configuration Guide*, *Catalyst 2960-XR Switch Layer 2 Configuration Guide*, and *Layer 2/3 Configuration Guide (Catalyst 3650 Switches)*.

If you change the message time between probe packets, you are making a compromise between the detection speed and the CPU load. By decreasing the time, you can make the detection-response faster but increase the load on the CPU.

This command affects fiber-optic interfaces only. Use the **udld** interface configuration command to enable UDLD on other interface types.

You can use these commands to reset an interface shut down by UDLD:

- The **udld reset** privileged EXEC command to reset all interfaces shut down by UDLD.
- The **shutdown** and **no shutdown** interface configuration commands.
- The **no udld enable** global configuration command followed by the **udld {aggressive | enable}** global configuration command to reenables UDLD globally.
- The **no udld port** interface configuration command followed by the **udld port** or **udld port aggressive** interface configuration command to reenables UDLD on the specified interface.

- The **errdisable recovery cause udld** and **errdisable recovery interval** *interval* global configuration commands to automatically recover from the UDLD error-disabled state.

This example shows how to enable UDLD on all fiber-optic interfaces:

```
Device(config)# udld enable
```

You can verify your setting by entering the **show udld** privileged EXEC command.

udld port

To enable UniDirectional Link Detection (UDLD) on an individual interface or to prevent a fiber-optic interface from being enabled by the **udld** global configuration command, use the **udld port** command in interface configuration mode. To return to the **udld** global configuration command setting or to disable UDLD if entered for a nonfiber-optic port, use the **no** form of this command.

udld port [**aggressive**]
no udld port [**aggressive**]

Syntax Description

aggressive (Optional) Enables UDLD in aggressive mode on the specified interface.

Command Default

On fiber-optic interfaces, UDLD is disabled and fiber-optic interfaces enable UDLD according to the state of the **udld enable** or **udld aggressive** global configuration command.

On nonfiber-optic interfaces, UDLD is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

A UDLD-capable port cannot detect a unidirectional link if it is connected to a UDLD-incapable port of another device.

UDLD supports two modes of operation: normal (the default) and aggressive. In normal mode, UDLD detects unidirectional links due to misconnected interfaces on fiber-optic connections. In aggressive mode, UDLD also detects unidirectional links due to one-way traffic on fiber-optic and twisted-pair links and due to misconnected interfaces on fiber-optic links.

To enable UDLD in normal mode, use the **udld port** interface configuration command. To enable UDLD in aggressive mode, use the **udld port aggressive** interface configuration command.

Use the **no udld port** command on fiber-optic ports to return control of UDLD to the **udld enable** global configuration command or to disable UDLD on nonfiber-optic ports.

Use the **udld port aggressive** command on fiber-optic ports to override the setting of the **udld enable** or **udld aggressive** global configuration command. Use the **no** form on fiber-optic ports to remove this setting and to return control of UDLD enabling to the **udld** global configuration command or to disable UDLD on nonfiber-optic ports.

You can use these commands to reset an interface shut down by UDLD:

- The **udld reset** privileged EXEC command resets all interfaces shut down by UDLD.
- The **shutdown** and **no shutdown** interface configuration commands.
- The **no udld enable** global configuration command, followed by the **udld {aggressive | enable}** global configuration command reenables UDLD globally.
- The **no udld port** interface configuration command, followed by the **udld port** or **udld port aggressive** interface configuration command reenables UDLD on the specified interface.

- The **errdisable recovery cause udld** and **errdisable recovery interval** *interval* global configuration commands automatically recover from the UDLD error-disabled state.

This example shows how to enable UDLD on an port:

```
Device(config)# interface gigabitethernet6/0/1
Device(config-if)# udld port
```

This example shows how to disable UDLD on a fiber-optic interface despite the setting of the **udld** global configuration command:

```
Device(config)# interface gigabitethernet6/0/1
Device(config-if)# no udld port
```

You can verify your settings by entering the **show running-config** or the **show udld** *interface* privileged EXEC command.

udld reset

To reset all interfaces disabled by UniDirectional Link Detection (UDLD) and permit traffic to begin passing through them again (though other features, such as spanning tree, Port Aggregation Protocol (PAgP), and Dynamic Trunking Protocol (DTP) still have their normal effects, if enabled), use the **udld reset** command in privileged EXEC mode.

udld reset

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines If the interface configuration is still enabled for UDLD, these ports begin to run UDLD again and are disabled for the same reason if the problem has not been corrected.

This example shows how to reset all interfaces disabled by UDLD:

```
Device# udld reset
1 ports shutdown by UDLD were reset.
```




PART **VIII**

Lightweight Access Point

- [Cisco Lightweight Access Point Commands, on page 469](#)



Cisco Lightweight Access Point Commands

- [ap auth-list ap-policy](#), on page 474
- [ap bridging](#), on page 475
- [ap capwap multicast](#), on page 476
- [ap capwap retransmit](#), on page 477
- [ap capwap timers](#), on page 478
- [ap cdp](#), on page 480
- [ap core-dump](#), on page 481
- [ap country](#), on page 482
- [ap crash-file](#), on page 483
- [ap dot11 24ghz preamble](#), on page 484
- [ap dot11 24ghz dot11g](#), on page 485
- [ap dot11 5ghz channelswitch mode](#), on page 486
- [ap dot11 5ghz power-constraint](#), on page 487
- [ap dot11 beaconperiod](#), on page 488
- [ap dot11 beamforming](#), on page 489
- [ap dot11 cac media-stream](#), on page 490
- [ap dot11 cac multimedia](#), on page 493
- [ap dot11 cac video](#), on page 495
- [ap dot11 cac voice](#), on page 497
- [ap dot11 cleanair](#), on page 501
- [ap dot11 cleanair alarm air-quality](#), on page 502
- [ap dot11 cleanair alarm device](#), on page 503
- [ap dot11 cleanair device](#), on page 505
- [ap dot11 dot11n](#), on page 507
- [ap dot11 dtpc](#), on page 510
- [ap dot11 edca-parameters](#), on page 512
- [ap dot11 rrm group-mode](#), on page 513
- [ap dot11 rrm channel cleanair-event](#), on page 514
- [ap dot11 l2roam rf-params](#), on page 515
- [ap dot11 media-stream](#), on page 517
- [ap dot11 rrm ccx location-measurement](#), on page 519
- [ap dot11 rrm channel dca](#), on page 520
- [ap dot11 rrm group-member](#), on page 522

- [ap dot11 rrm logging, on page 523](#)
- [ap dot11 rrm monitor, on page 525](#)
- [ap dot11 rrm ndp-type, on page 527](#)
- [ap dot11 5ghz dot11lac frame-burst, on page 528](#)
- [ap dot1x max-sessions, on page 529](#)
- [ap dot1x username, on page 530](#)
- [ap ethernet duplex, on page 531](#)
- [ap group, on page 532](#)
- [ap image, on page 533](#)
- [ap ipv6 tcp adjust-mss, on page 534](#)
- [ap led, on page 535](#)
- [ap link-encryption, on page 536](#)
- [ap link-latency, on page 537](#)
- [ap mgmtuser username, on page 538](#)
- [ap name ap-groupname, on page 540](#)
- [ap name antenna band mode, on page 541](#)
- [ap name bhrate, on page 542](#)
- [ap name bridgegroupname, on page 543](#)
- [ap name bridging, on page 544](#)
- [ap name cdp interface, on page 545](#)
- [ap name console-redirect, on page 546](#)
- [ap name capwap retransmit, on page 547](#)
- [ap name command, on page 548](#)
- [ap name core-dump, on page 549](#)
- [ap name country, on page 550](#)
- [ap name crash-file, on page 551](#)
- [ap name dot11 24ghz rrm coverage, on page 552](#)
- [ap name dot11 49ghz rrm profile, on page 554](#)
- [ap name dot11 5ghz rrm channel, on page 556](#)
- [ap name dot11 antenna, on page 557](#)
- [ap name dot11 antenna extantgain, on page 559](#)
- [ap name dot11 cleanair, on page 560](#)
- [ap name dot11 dot11n antenna, on page 561](#)
- [ap name dot11 dual-band cleanair, on page 562](#)
- [ap name dot11 dual-band shutdown, on page 563](#)
- [ap name dot11 rrm ccx, on page 564](#)
- [ap name dot11 rrm profile, on page 565](#)
- [ap name dot11 txpower, on page 567](#)
- [ap name dot1x-user, on page 568](#)
- [ap name ethernet, on page 570](#)
- [ap name ethernet duplex, on page 571](#)
- [ap name key-zeroize , on page 572](#)
- [ap name image, on page 573](#)
- [ap name ipv6 tcp adjust-mss, on page 574](#)
- [ap name jumbo mtu, on page 575](#)
- [ap name lan, on page 576](#)

- ap name led, on page 577
- ap name link-encryption, on page 578
- ap name link-latency, on page 579
- ap name location, on page 580
- ap name mgmtuser, on page 581
- ap name mode, on page 583
- ap name monitor-mode, on page 585
- ap name monitor-mode dot11b, on page 586
- ap name name, on page 587
- ap name no dot11 shutdown, on page 588
- ap name power, on page 589
- ap name shutdown, on page 590
- ap name slot shutdown, on page 591
- ap name sniff, on page 592
- ap name ssh, on page 593
- ap name telnet, on page 594
- ap name power injector, on page 595
- ap name power pre-standard, on page 596
- ap name reset-button, on page 597
- ap name reset, on page 598
- ap name slot, on page 599
- ap name static-ip, on page 601
- ap name stats-timer, on page 602
- ap name syslog host, on page 603
- ap name syslog level, on page 604
- ap name tcp-adjust-mss, on page 605
- ap name tftp-downgrade, on page 606
- ap power injector, on page 607
- ap power pre-standard, on page 608
- ap reporting-period, on page 609
- ap reset-button, on page 610
- service-policy type control subscriber, on page 611
- ap static-ip, on page 612
- ap syslog, on page 613
- **ap name no controller** , on page 614
- ap tcp-adjust-mss size, on page 615
- ap tftp-downgrade, on page 616
- config wireless wps rogue client mse, on page 617
- clear ap name tsm dot11 all, on page 618
- clear ap config, on page 619
- clear ap eventlog-all, on page 620
- clear ap join statistics, on page 621
- clear ap mac-address, on page 622
- clear ap name wlan statistics, on page 623
- debug ap mac-address, on page 624
- show ap cac voice, on page 625

- [show ap capwap](#), on page 627
- [show ap cdp](#), on page 629
- [show ap config dot11](#), on page 630
- [show ap config dot11 dual-band summary](#), on page 631
- [show ap config fnf](#), on page 632
- [show ap config](#), on page 633
- [show ap crash-file](#), on page 634
- [show ap data-plane](#), on page 635
- [show ap dot11 l2roam](#), on page 636
- [show ap dot11 cleanair air-quality](#), on page 637
- [show ap dot11 cleanair config](#), on page 638
- [show ap dot11 cleanair summary](#), on page 640
- [show ap dot11](#), on page 641
- [show ap env summary](#), on page 647
- [show ap ethernet statistics](#), on page 648
- [show ap gps-location summary](#), on page 649
- [show ap groups](#), on page 650
- [show ap groups extended](#), on page 651
- [show ap image](#), on page 652
- [show ap is-supported](#), on page 653
- [show ap join stats summary](#), on page 654
- [show ap link-encryption](#), on page 655
- [show ap mac-address](#), on page 656
- [show ap monitor-mode summary](#), on page 658
- [show ap name auto-rf](#), on page 659
- [show ap name bhmode](#), on page 662
- [show ap name bhrate](#), on page 663
- [show ap name cac voice](#), on page 664
- [show ap name config fnf](#), on page 665
- [show ap name dot11 call-control](#), on page 666
- [show ap name cable-modem](#), on page 667
- [show ap name capwap retransmit](#), on page 668
- [show ap name ccx rm](#), on page 669
- [show ap name cdp](#), on page 670
- [show ap name channel](#), on page 671
- [show ap name config](#), on page 672
- [show ap name config dot11](#), on page 674
- [show ap name config slot](#), on page 678
- [show ap name core-dump](#), on page 682
- [show ap name data-plane](#), on page 683
- [show ap name dot11](#), on page 684
- [show ap name dot11 cleanair](#), on page 687
- [show ap name env](#), on page 688
- [show ap name ethernet statistics](#), on page 689
- [show ap name eventlog](#), on page 690
- [show ap gps-location summary](#), on page 691

- show ap name image, on page 692
- show ap name inventory, on page 693
- show ap name lan port, on page 694
- show ap name link-encryption, on page 695
- show ap name service-policy, on page 696
- show ap name tcp-adjust-mss, on page 697
- show ap name wlan, on page 698
- show ap name wlandot11 service policy, on page 700
- show ap slots, on page 701
- show ap summary, on page 702
- show ap tcp-adjust-mss, on page 703
- show ap universal summary, on page 704
- show ap uptime, on page 705
- show wireless ap summary, on page 706
- show wireless client ap, on page 707
- test ap name, on page 708
- test capwap ap name, on page 709
- trapflags ap, on page 710
- wireless wps rogue ap rldp alarm-only, on page 711
- wireless wps rogue ap rldp auto-contain, on page 712

ap auth-list ap-policy

To configure authorization policy for all Cisco lightweight access points joined to the device, use the **ap auth-list ap-policy** command. To disable authorization policy for all Cisco lightweight access points joined to the device, use the **no** form of this command.

```
ap auth-list ap-policy {authorize-ap | lsc | mic | ssc}
no ap auth-list ap-policy {authorize-ap | lsc | mic | ssc}
```

Syntax Description	authorize-ap Enables the authorization policy.						
	lsc Enables access points with locally significant certificates to connect.						
	mic Enables access points with manufacture-installed certificates to connect.						
	ssc Enables access points with self signed certificates to connect.						
Command Default	None						
Command Modes	Global configuration						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE</td> </tr> <tr> <td></td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE		This command was introduced.
Release	Modification						
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE						
	This command was introduced.						

This example shows how to enable the access point authorization policy:

```
Device(config)# ap auth-list ap-policy authorize-ap
```

This example shows how to enable access points with locally significant certificates to connect:

```
Device(config)# ap auth-list ap-policy lsc
```

This example shows how to enable access points with manufacture-installed certificates to connect:

```
Device(config)# ap auth-list ap-policy mic
```

This example shows how to enable access points with self-signed certificates to connect:

```
Device(config)# ap auth-list ap-policy ssc
```

ap bridging

To enable Ethernet to 802.11 bridging on a Cisco lightweight access point, use the **ap bridging** command. To disable Ethernet to 802.11 bridging on a Cisco lightweight access point, use the **no** form of this command.

ap bridging
no ap bridging

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to enable Ethernet-to-Ethernet bridging on a lightweight access point:

```
Device(config)# ap bridging
```

This example shows how to disable Ethernet-to-Ethernet bridging on a lightweight access point:

```
Device(config)# no ap bridging
```

ap capwap multicast

To configure the multicast address used by all access points to receive multicast traffic when multicast forwarding is enabled and to configure the outer Quality of Service (QoS) level of those multicast packets sent to the access points, use the **ap capwap multicast** command.

ap capwap multicast {*multicast-ip-address* | **service-policy output** *pollicymap-name*}

Syntax Description

<i>multicast-ip-address</i>	Multicast IP address.
service-policy	Specifies the tunnel QoS policy for multicast access points.
output	Assigns a policy map name to the output.
<i>pollicymap-name</i>	Service policy map name.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure a multicast address used by all access points to receive multicast traffic when multicast forwarding is enabled:

```
Device(config)# ap capwap multicast 239.2.2.2
```

This example shows how to configure a tunnel multicast QoS service policy for multicast access points:

```
Device(config)# ap capwap multicast service-policy output tunnmulpolicy
```

Related Topics

[ap capwap retransmit](#), on page 477

[ap capwap timers](#), on page 478

ap capwap retransmit

To configure Control and Provisioning of Wireless Access Points (CAPWAP) control packet retransmit count and control packet retransmit interval, use the **ap capwap retransmit** command.

ap capwap retransmit {**count** *retransmit-count* | **interval** *retransmit-interval*}

Syntax Description	count <i>retransmit-count</i>	Specifies the access point CAPWAP control packet retransmit count. Note The count is from 3 to 8 seconds.
	interval <i>retransmit-interval</i>	Specifies the access point CAPWAP control packet retransmit interval. Note The interval is from 2 to 5 seconds.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to configure the CAPWAP control packet retransmit count for an access point:

```
Device# ap capwap retransmit count 3
```

This example shows how to configure the CAPWAP control packet retransmit interval for an access point:

```
Device# ap capwap retransmit interval 5
```

ap capwap timers

To configure advanced timer settings, use the **ap capwap timers** command.

```
ap capwap timers {discovery-timeout seconds | fast-heartbeat-timeout local seconds |
heartbeat-timeout seconds | primary-discovery-timeout seconds | primed-join-timeout seconds}
```

Syntax	Description
discovery-timeout	Specifies the Cisco lightweight access point discovery timeout. Note The Cisco lightweight access point discovery timeout is how long a Cisco device waits for an unresponsive access point to answer before considering that the access point failed to respond.
<i>seconds</i>	Cisco lightweight access point discovery timeout from 1 to 10 seconds. Note The default is 10 seconds.
fast-heartbeat-timeout local	Enables the fast heartbeat timer that reduces the amount of time it takes to detect a device failure for local or all access points.
<i>seconds</i>	Small heartbeat interval (from 1 to 10 seconds) that reduces the amount of time it takes to detect a device failure. Note The fast heartbeat time-out interval is disabled by default.
heartbeat-timeout	Specifies the Cisco lightweight access point heartbeat timeout. Note The Cisco lightweight access point heartbeat timeout controls how often the Cisco lightweight access point sends a heartbeat keep-alive signal to the Cisco device. This value should be at least three times larger than the fast heartbeat timer.
<i>seconds</i>	Cisco lightweight access point heartbeat timeout value from 1 to 30 seconds. Note The default is 30 seconds.
primary-discovery-timeout	Specifies the access point primary discovery request timer. The timer determines the amount of time taken by an access point to discovery the configured primary, secondary, or tertiary device.
<i>seconds</i>	Access point primary discovery request timer from 30 to 3600 seconds. Note The default is 120 seconds.
primed-join-timeout	Specifies the authentication timeout. Determines the time taken by an access point to determine that the primary device has become unresponsive. The access point makes no further attempts to join the device until the connection to the device is restored.

seconds Authentication response timeout from 120 to 43200 seconds.

Note The default is 120 seconds.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure an access point discovery timeout with the timeout value of 7:

```
Device(config)# ap capwap timers discovery-timeout 7
```

This example shows how to enable the fast heartbeat interval for all access points:

```
Device(config)# ap capwap timers fast-heartbeat-timeout 6
```

This example shows how to configure an access point heartbeat timeout to 20:

```
Device(config)# ap capwap timers heartbeat-timeout 20
```

This example shows how to configure the access point primary discovery request timer to 1200 seconds:

```
Device(config)# ap capwap timers primary-discovery-timeout 1200
```

This example shows how to configure the authentication timeout to 360 seconds:

```
Device(config)# ap capwap timers primed-join-timeout 360
```

Related Topics

[ap capwap multicast](#), on page 476

[ap capwap retransmit](#), on page 477

ap cdp

To enable the Cisco Discovery Protocol (CDP) on a Cisco lightweight access point, use the **ap cdp** command. To disable the Cisco Discovery Protocol (CDP) on a Cisco lightweight access point, use the **no** form of this command.

```
ap cdp [interface {ethernet ethernet-id | radio radio-id}]
no ap cdp [interface {ethernet ethernet-id | radio radio-id}]
```

Syntax Description

interface (Optional) Specifies CDP in a specific interface.

ethernet Specifies CDP for an Ethernet interface.

ethernet-id Ethernet interface number from 0 to 3.

radio Specifies CDP for a radio interface.

radio-id Radio number from 0 to 3.

Command Default

Disabled on all access points.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **no ap cdp** command disables CDP on all access points that are joined to the device and all access points that join in the future. CDP remains disabled on both current and future access points even after the device or access point reboots. To enable CDP, enter the **ap cdp** command.



Note

CDP over Ethernet/radio interfaces is available only when CDP is enabled. After you enable CDP on all access points joined to the device, you can disable and then reenabling CDP on individual access points using the **ap name Cisco-AP cdp** command. After you disable CDP on all access points joined to the device, you can enable and then disable CDP on individual access points.

This example shows how to enable CDP on all access points:

```
Device(config)# ap cdp
```

This example shows how to enable CDP for Ethernet interface number 0 on all access points:

```
Device(config)# ap cdp ethernet 0
```

Related Topics

[show ap cdp](#), on page 629

ap core-dump

To enable a Cisco lightweight access point's memory core dump settings, use the **ap core-dump** command. To disable a Cisco lightweight access point's memory core dump settings, use the **no** form of this command.

```
ap core-dump tftp-ip-addr filename {compress | uncompress}
no ap core-dump
```

Syntax Description	
<i>tftp-ip-addr</i>	IP address of the TFTP server to which the access point sends core dump files.
<i>filename</i>	Name that the access point uses to label the core file.
compress	Compresses the core dump file.
uncompress	Uncompresses the core dump file.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines The access point must be able to reach the TFTP server.

This example shows how to configure and compress the core dump file:

```
Device(config)# ap core-dump 192.0.2.51 log compress
```

Related Topics

[ap crash-file](#), on page 483

[ap name crash-file](#), on page 551

ap country

To configure one or more country codes for a device, use the **ap country** command.

ap country *country-code*

Syntax Description	<i>country-code</i> Two-letter or three-letter country code or several country codes separated by a comma.
---------------------------	--

Command Default	US (country code of the United States of America).
------------------------	--

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	The Cisco device must be installed by a network administrator or qualified IT professional and the installer must select the proper country code. Following installation, access to the unit should be password protected by the installer to maintain compliance with regulatory requirements and to ensure proper unit functionality. See the related product guide for the most recent country codes and regulatory domains.
-------------------------	---

This example shows how to configure country codes on the device to IN (India) and FR (France):

```
Device(config)# ap country IN,FR
```

Related Topics

[ap name country](#), on page 550

ap crash-file

To delete crash and radio core dump files, use the **ap crash-file** command.

```
ap crash-file {clear-all | delete filename}
```

Syntax Description

clear-all Deletes all the crash and radio core dump files.

delete Deletes a single crash and radio core dump file.

filename Name of the file to delete.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to delete all crash files:

```
Device# ap crash-file clear-all
```

This example shows how to delete crash file 1:

```
Device# ap crash-file delete crash-file-1
```

Related Topics

[ap name crash-file](#), on page 551

[ap name core-dump](#), on page 549

ap dot11 24ghz preamble

To enable only a short preamble as defined in subclause 17.2.2.2 , use the **ap dot11 24ghz preamble** command. To enable long preambles (for backward compatibility with pre-802.11b devices, if these devices are still present in your network) or short preambles (recommended unless legacy pre-802.11b devices are present in the network), use the **no** form of this command.

```
ap dot11 24ghz preamble short
no ap dot11 24ghz preamble short
```

Syntax Description	short Specifies the short 802.11b preamble.
---------------------------	--

Command Default	short preambles
------------------------	-----------------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines



Note You must reboot the Cisco device (reset system) with the **Save** command before you can use the **ap dot11 24ghz preamble** command.

This parameter may need to be set to long to optimize this Cisco device for some legacy clients, including SpectraLink NetLink telephones.

This command can be used any time that the CLI interface is active.

This example shows how to enable both long and short preambles:

```
Device(config)# no ap dot11 24ghz preamble short
```

ap dot11 24ghz dot11g

To enable the Cisco wireless LAN solution 802.11g network, use the **ap dot11 24ghz dot11g** command. To disable the Cisco wireless LAN solution 802.11g network, use the **no** form of this command.

```
ap dot11 24ghz dot11g
no ap dot11 24ghz dot11g
```

Syntax Description	This command has no keywords and arguments.	
Command Default	Enabled	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

Before you enter the **ap dot11 24ghz dot11g** command, disable the 802.11 Cisco radio with the **ap dot11 24ghz shutdown** command.

After you configure the support for the 802.11g network, use the **no ap dot11 24ghz shutdown** command to enable the 802.11 2.4 Ghz radio.

This example shows how to enable the 802.11g network:

```
Device(config)# ap dot11 24ghz dot11g
```

Related Topics

[show ap dot11](#), on page 641

ap dot11 5ghz channelswitch mode

To configure a 802.11h channel switch announcement, use the **ap dot11 5ghz channelswitch mode** command. To disable a 802.11h channel switch announcement, use the **no** form of this command.

ap dot11 5ghz channelswitch mode *value*
no ap dot11 5ghz channelswitch mode

Syntax Description

value 802.11h channel announcement value.

Note You can specify anyone of the following two values:

- 0—Indicates that the channel switch announcement is disabled.
- 1—Indicates that the channel switch announcement is enabled.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to enable the 802.11h switch announcement:

```
Device(config)# ap dot11 5ghz channelswitch mode 1
```

ap dot11 5ghz power-constraint

To configure the 802.11h power constraint value, use the **ap dot11 5ghz power-constraint** command. To remove the 802.11h power constraint value, use the **no** form of this command.

```
ap dot11 5ghz power-constraint value
no ap dot11 5ghz power-constraint
```

Syntax Description	<i>value</i> 802.11h power constraint value.	
	Note	The range is from 0 to 30 dBm.
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure the 802.11h power constraint to 5 dBm:

```
Device(config)# ap dot11 5ghz power-constraint 5
```

ap dot11 beaconperiod

To change the beacon period globally for 2.4 GHz or 5 GHz bands, use the **ap dot11 beaconperiod** command.



Note Disable the 802.11 network before using this command. See the “Usage Guidelines” section.

```
ap dot11 {24ghz | 5ghz} beaconperiod time
```

Syntax Description	24ghz	Specifies the settings for 2.4 GHz band.
	5ghz	Specifies the settings for 5 GHz band.
	beaconperiod	Specifies the beacon for a network globally.
	time	Beacon interval in time units (TU). One TU is 1024 microseconds. The range is from 20 to 1000.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines In Cisco wireless LAN 802.11 networks, all Cisco lightweight access point wireless LANs broadcast a beacon at regular intervals. This beacon notifies clients that the wireless service is available and allows the clients to synchronize with the lightweight access point.

Before you change the beacon period, make sure that you have disabled the 802.11 network by using the **ap dot11 {24ghz | 5ghz} shutdown** command. After changing the beacon period, enable the 802.11 network by using the **no ap dot11 {24ghz | 5ghz} shutdown** command.

This example shows how to configure the 5 GHz band for a beacon period of 120 time units:

```
Device(config)# ap dot11 5ghz beaconperiod 120
```

ap dot11 beamforming

To enable beamforming on the network or on individual radios, use the **ap dot11 beamforming** command.

ap dot11 {24ghz | 5ghz} beamforming

Syntax Description	24ghz	Specifies the 2.4 GHz band.
	5ghz	Specifies the 5 GHz band.
	beamforming	Specifies beamforming on the network.
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines When you enable beamforming on the network, it is automatically enabled for all the radios applicable to that network type.

Follow these guidelines for using beamforming:

- Beamforming is supported for legacy orthogonal frequency-division multiplexing (OFDM) data rates (6, 9, 12, 18, 24, 36, 48, and 54 Mbps).



Note Beamforming is not supported for Direct Sequence Spread Spectrum data rates (1 and 2 Mbps) and Complementary-Code Key (CCK) data rates (5.5 and 11 Mbps).

- Beamforming is supported only on access points that support 802.11n (AP1260, AP3500, and AP3600).
- Two or more antennas must be enabled for transmission.
- All three antennas must be enabled for reception.
- OFDM rates must be enabled.

If the antenna configuration restricts operation to a single transmit antenna, or if OFDM rates are disabled, beamforming is not used.

This example shows how to enable beamforming on the 5 GHz band:

```
Device(config)# ap dot11 5ghz beamforming
```

ap dot11 cac media-stream

To configure media stream Call Admission Control (CAC) voice and video quality parameters for 2.4 GHz and 5 GHz bands, use the **ap dot11 cac media-stream** command.

```
ap dot11 {24ghz | 5ghz} cac media-stream multicast-direct {max-retry-percent retryPercent |
min-client-rate {eighteen | eleven | fiftyFour | fivePointFive | fortyEight | nine | oneFifty |
oneFortyFourPointFour | oneThirty | oneThirtyFive | seventyTwoPointTwo | six | sixtyFive | thirtySix |
threeHundred | twelve | twentyFour | two | twoSeventy}}
```

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
multicast-direct	Specifies CAC parameters for multicast-direct media streams.
max-retry-percent	Specifies the percentage of maximum retries that are allowed for multicast-direct media streams.
<i>retryPercent</i>	Percentage of maximum retries that are allowed for multicast-direct media streams. Note The range is from 0 to 100.
min-client-rate	Specifies the minimum transmission data rate to the client for multicast-direct media streams (rate at which the client must transmit in order to receive multicast-direct unicast streams). If the transmission rate is below this rate, either the video will not start or the client may be classified as a bad client. The bad client video can be demoted for better effort QoS or subject to denial.

min-client-rate You can choose the following rates:

- **eighteen**
- **eleven**
- **fiftyFour**
- **fivePointFive**
- **fortyEight**
- **nine**
- **one**
- **oneFifty**
- **oneFortyFourPointFour**
- **oneThirty**
- **oneThirtyFive**
- **seventyTwoPointTwo**
- **six**
- **sixtyFive**
- **thirtySix**
- **threeHundred**
- **twelve**
- **twentyFour**
- **two**
- **twoSeventy**

Command Default

The default value for the maximum retry percent is 80. If it exceeds 80, either the video will not start or the client might be classified as a bad client. The bad client video will be demoted for better effort QoS or is subject to denial.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **wlan *wlan_name* shutdown** command.

- Disable the radio network you want to configure by entering the **ap dot11 {24ghz | 5ghz} shutdown** command.
- Save the new configuration.
- Enable voice or video CAC for the network you want to configure by entering the **ap dot11 {24ghz | 5ghz} cac voice acm** or **ap dot11 {24ghz | 5ghz} cac video acm** commands.

This example shows how to configure the maximum retry percent for multicast-direct media streams as 90 on a 802.11a network:

```
Device(config)# ap dot11 5ghz cac media-stream multicast max-retry-percent 90
```

Related Topics

[ap dot11 cac multimedia](#), on page 493

[ap dot11 cac video](#), on page 495

[ap dot11 cac voice](#), on page 497

ap dot11 cac multimedia

To configure multimedia Call Admission Control (CAC) voice and video quality parameters for 2.4 GHz and 5 GHz bands, use the **ap dot11 cac multimedia** command.

```
ap dot11 {24ghz | 5ghz} cac multimedia max-bandwidth bandwidth
```

Syntax Description	24ghz	Specifies the 2.4 GHz band.
	5ghz	Specifies the 5 GHz band.
	max-bandwidth	Specifies the percentage of maximum bandwidth allocated to Wi-Fi Multimedia (WMM) clients for voice and video applications on the 2.4 GHz or 5 GHz band.
	<i>bandwidth</i>	Percentage of the maximum bandwidth allocated to WMM clients for voice and video applications on the 802.11a or 802.11b/g network. Once the client reaches the specified value, the access point rejects new multimedia flows this radio band. The range is from 5 to 85%.
Command Default	The default value is 75%.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE

Usage Guidelines CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **wlan wlan_name shutdown** command.
- Disable the radio network you want to configure by entering the **ap dot11 {24ghz | 5ghz} shutdown** command.
- Save the new configuration.
- Enable voice or video CAC for the network you want to configure by entering the **ap dot11 {24ghz | 5ghz} cac voice acm** or **ap dot11 {24ghz | 5ghz} cac video acm** commands.

This example shows how to configure the percentage of the maximum bandwidth allocated to WMM clients for voice and video applications on the 5 GHz band:

```
Device(config)# ap dot11 5ghz cac multimedia max-bandwidth 5
```

Related Topics

[ap dot11 cac media-stream](#), on page 490

[ap dot11 cac video](#), on page 495

[ap dot11 cac voice](#), on page 497

ap dot11 cac video

To configure Call Admission Control (CAC) parameters for the video category, use the **ap dot11 cac video** command. To disable the CAC parameters for video category, use the **no** form of this command.

```
ap dot11 {24ghz | 5ghz} cac video {acm | max-bandwidth value | roam-bandwidth value}
no ap dot11 {24ghz | 5ghz} cac video {acm | max-bandwidth value | roam-bandwidth value}
```

Syntax Description		
24ghz		Specifies the 2.4 GHz band.
5ghz		Specifies the 5 GHz band.
acm		Enables bandwidth-based video CAC for the 2.4 GHz or 5 GHz band.
	Note	To disable bandwidth-based video CAC for the 2.4 GHz or 5 GHz band, use the no ap dot11 {24ghz 5ghz} cac video acm command.
max-bandwidth		Sets the percentage of the maximum bandwidth allocated to clients for video applications on the 2.4 GHz or 5 GHz band.
<i>value</i>		Bandwidth percentage value from 5 to 85%.
roam-bandwidth		Sets the percentage of the CAC maximum allocated bandwidth reserved for roaming video clients on the 2.4 GHz or 5 GHz band.
<i>value</i>		Bandwidth percentage value from 0 to 85%.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **wlan wlan_name shutdown** command.
- Disable the radio network you want to configure by entering the **ap dot11 {24ghz | 5ghz} shutdown** command.
- Save the new configuration.
- Enable voice or video CAC for the network you want to configure by entering the **ap dot11 {24ghz | 5ghz} cac voice acm** or **ap dot11 {24ghz | 5ghz} cac video acm** command.

This example shows how to enable the bandwidth-based CAC:

```
Device(config)# ap dot11 24ghz cac video acm
```

This example shows how to specify the percentage of the maximum allocated bandwidth for video applications on the selected radio band:

```
Device(config)# ap dot11 24ghz cac video max-bandwidth 50
```

This example shows how to configure the percentage of the maximum allocated bandwidth reserved for roaming video clients on the selected radio band:

```
Device(config)# ap dot11 24ghz cac video roam-bandwidth 10
```

Related Topics

[ap dot11 cac media-stream](#), on page 490

[ap dot11 cac multimedia](#), on page 493

[ap dot11 cac voice](#), on page 497

ap dot11 cac voice

To configure Call Admission Control (CAC) parameters for the voice category, use the **ap dot11 cac voice** command.

```
ap dot11 {24ghz | 5ghz} cac voice {acm | load-based | max-bandwidth value | roam-bandwidth value
| sip [bandwidth bw] sample-interval value | stream-size x max-streams y |
tspec-inactivity-timeout {enable | ignore}}
```

Syntax Description	
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
acm	Enables bandwidth-based voice CAC for the 2.4 GHz or 5 GHz band. Note To disable bandwidth-based voice CAC for the 2.4 GHz or 5 GHz band, use the no ap dot11 {24ghz 5ghz} cac voice acm command.
load-based	Enable load-based CAC on voice access category. Note To disable load-based CAC on voice access category for the 2.4 GHz or 5 GHz band, use the no ap dot11 {24ghz 5ghz} cac voice load-based command.
max-bandwidth	Sets the percentage of the maximum bandwidth allocated to clients for voice applications on the 2.4 GHz or 5 GHz band.
<i>value</i>	Bandwidth percentage value from 5 to 85%.
roam-bandwidth	Sets the percentage of the CAC maximum allocated bandwidth reserved for roaming voice clients on the 2.4 GHz or 5 GHz band.
<i>value</i>	Bandwidth percentage value from 0 to 85%.
sip	Specifies the CAC codec name and sample interval as parameters and calculates the required bandwidth per call for the 802.11 networks.
bandwidth	(Optional) Specifies bandwidth for a SIP-based call.

<i>bw</i>	Bandwidth in kbps. The following bandwidth values specify parameters for the SIP codecs: <ul style="list-style-type: none"> • 64kbps—Specifies CAC parameters for the SIP G711 codec. • 8kbps—Specifies CAC parameters for the SIP G729 codec. <p>Note The default value is 64 Kbps.</p>
sample-interval	Specifies the packetization interval for SIP codec.
<i>value</i>	Packetization interval in msec. The sample interval for SIP codec value is 20 seconds.
stream-size	Specifies the number of aggregated voice Wi-Fi Multimedia (WMM) traffic specification (TSPEC) streams at a specified data rate for the 2.4 GHz or 5 GHz band.
<i>x</i>	Stream size. The range of the stream size is from 84000 to 92100.
max-streams	Specifies the maximum number of streams per TSPEC.
<i>y</i>	Number (1 to 5) of voice streams. <p>Note The default number of streams is 2 and the mean data rate of a stream is 84 kbps.</p>
tspec-inactivity-timeout	Specifies TSPEC inactivity timeout processing mode. <p>Note Use this keyword to process or ignore the Wi-Fi Multimedia (WMM) traffic specifications (TSPEC) inactivity timeout received from an access point. When the inactivity timeout is ignored, a client TSPEC is not deleted even if the access point reports an inactivity timeout for that client.</p>
enable	Processes the TSPEC inactivity timeout messages.
ignore	Ignores the TSPEC inactivity timeout messages. <p>Note The default is ignore (disabled).</p>

Command Default

None

Command Modes

Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **wlan wlan_name shutdown** command.
- Disable the radio network you want to configure by entering the **ap dot11 {24ghz | 5ghz} shutdown** command.
- Save the new configuration.
- Enable voice or video CAC for the network you want to configure by entering the **ap dot11 {24ghz | 5ghz} cac voice acm** or **ap dot11 {24ghz | 5ghz} cac video acm** commands.

This example shows how to enable the bandwidth-based CAC:

```
Device(config)# ap dot11 24ghz cac voice acm
```

This example shows how to enable the load-based CAC on the voice access category:

```
Device(config)# ap dot11 24ghz cac voice load-based
```

This example shows how to specify the percentage of the maximum allocated bandwidth for voice applications on the selected radio band:

```
Device(config)# ap dot11 24ghz cac voice max-bandwidth 50
```

This example shows how to configure the percentage of the maximum allocated bandwidth reserved for roaming voice clients on the selected radio band:

```
Device(config)# ap dot11 24ghz cac voice roam-bandwidth 10
```

This example shows how to configure the bandwidth and voice packetization interval for the G729 SIP codec on a 2.4 GHz band:

```
Device(config)# ap dot11 24ghz cac voice sip bandwidth 8 sample-interval 40
```

This example shows how to configure the number of aggregated voice traffic specifications stream with a stream size of 85000 and with a maximum of 5 streams:

```
Device(config)# ap dot11 24ghz cac voice stream-size 85000 max-streams 5
```

This example shows how to enable the voice TSPEC inactivity timeout messages received from an access point:

```
Device(config)# ap dot11 24ghz cac voice tspec-inactivity-timeout enable
```

Related Topics

[ap dot11 cac media-stream](#), on page 490

[ap dot11 cac multimedia](#), on page 493

[ap dot11 cac video](#), on page 495

ap dot11 cleanair

To configure CleanAir on 802.11 networks, use the **ap dot11 cleanair** command. To disable CleanAir on 802.11 networks, use the **no** form of this command.

```
ap dot11 {24ghz | 5ghz} cleanair
no ap dot11 {24ghz | 5ghz} cleanair
```

Syntax Description	
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
cleanair	Specifies CleanAir on the 2.4 GHz or 5 GHz band.

Command Default Disabled

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to enable the CleanAir settings on the 2.4 GHz band:

```
Device(config)# ap dot11 24ghz cleanair
```

Related Topics

[ap dot11 cleanair alarm air-quality](#), on page 502

[ap dot11 cleanair alarm device](#), on page 503

[ap dot11 cleanair device](#), on page 505

[ap name dot11 dual-band cleanair](#), on page 562

[ap name dot11 dual-band shutdown](#), on page 563

ap dot11 cleanair alarm air-quality

To configure CleanAir air-quality alarms for Cisco lightweight access points, use the **ap dot11 cleanair alarm air-quality** command.

```
ap dot11 {24ghz | 5ghz} cleanair alarm air-quality [threshold value]
```

Syntax Description	24ghz	Specifies the 2.4 GHz band.
	5ghz	Specifies the 5 GHz band.
	threshold	Specifies the air-quality alarm threshold.
	<i>value</i>	Air quality alarm threshold (1 is bad air quality, and 100 is good air quality).
Command Default	Disabled	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to configure the CleanAir 2.4 GHz air-quality threshold to 90:

```
Device(config)# ap dot11 24ghz cleanair alarm air-quality threshold 90
```

Related Topics

- [ap dot11 cleanair](#), on page 501
- [ap dot11 cleanair alarm device](#), on page 503
- [ap dot11 cleanair device](#), on page 505

ap dot11 cleanair alarm device

To configure the CleanAir interference devices alarms on the 2.4 GHz or 5 GHz bands, use the **ap dot11 cleanair alarm device** command. To disable the CleanAir interference devices alarms on the 802.11 networks, use the **no** form of this command.

```
ap dot11 {24ghz | 5ghz} cleanair alarm device {all | bt-discovery | bt-link | canopy | cont-tx | dect-like
| fh | inv | jammer | mw-oven | nonstd | superag | tdd-tx | video | wimax-fixed | wimax-mobile | xbox |
zigbee}
no ap dot11 {24ghz | 5ghz} cleanair
```

Syntax	Description
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
all	Specifies all the device types at once.
bt-discovery	Specifies the Bluetooth device in discovery mode.
bt-link	Specifies the Bluetooth active link.
canopy	Specifies the Canopy devices.
cont-tx	Specifies the continuous transmitter.
dect-like	Specifies a Digital Enhanced Cordless Communication (DECT)-like phone.
fh	Specifies the frequency hopping devices.
inv	Specifies the devices using spectrally inverted Wi-Fi signals.
jammer	Specifies the jammer.
mw-oven	Specifies the microwave oven devices.
nonstd	Specifies the devices using nonstandard Wi-Fi channels.
superag	Specifies 802.11 SuperAG devices.
tdd-tx	Specifies the TDD transmitter.
video	Specifies video cameras.
wimax-fixed	Specifies a WiMax fixed device.
wimax-mobile	Specifies a WiMax mobile device.
xbox	Specifies the Xbox device.
zigbee	Specifies the ZigBee device.

Command Default Disabled

Command Modes Global configuration

Command History	Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to disable alarms for ZigBee interference detection:

```
Device(config)# no ap dot11 24ghz cleanair alarm device zigbee
```

This example shows how to enable alarms for detection of Bluetooth links:

```
Device(config)# ap dot11 24ghz cleanair alarm device bt-link
```

Related Topics

[ap dot11 cleanair alarm air-quality](#), on page 502

[ap dot11 cleanair](#), on page 501

[ap dot11 cleanair device](#), on page 505

ap dot11 cleanair device

To configure CleanAir interference device types, use the **ap dot11 cleanair device** command.

```
ap dot11 24ghz cleanair device [{all | bt-discovery | bt-link | canopy | cont-tx | dect-like | fh | inv | jammer | mw-oven | nonstd | superag | tdd-tx | video | wimax-fixed | wimax-mobile | xbox | zigbee}]
```

Syntax Description	
all	Specifies all device types.
device	Specifies the CleanAir interference device type.
bt-discovery	Specifies the Bluetooth device in discovery mode.
bt-link	Specifies the Bluetooth active link.
canopy	Specifies the Canopy devices.
cont-tx	Specifies the continuous transmitter.
dect-like	Specifies a Digital Enhanced Cordless Communication (DECT)-like phone.
fh	Specifies the 802.11 frequency hopping devices.
inv	Specifies the devices using spectrally inverted Wi-Fi signals.
jammer	Specifies the jammer.
mw-oven	Specifies the microwave oven devices.
nonstd	Specifies the devices using nonstandard Wi-Fi channels.
superag	Specifies 802.11 SuperAG devices.
tdd-tx	Specifies the TDD transmitter.
video	Specifies video cameras.
wimax-fixed	Specifies a WiMax fixed device.
wimax-mobile	Specifies a WiMax mobile device.
xbox	Specifies the Xbox device.
zigbee	Specifies the ZigBee device.
Command Default	None
Command Modes	Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure the device to monitor ZigBee interferences:

```
Device(config)# ap dot11 24ghz cleanair device zigbee
```

Related Topics

[ap dot11 cleanair alarm air-quality](#), on page 502

[ap dot11 cleanair](#), on page 501

[ap dot11 cleanair alarm device](#), on page 503

ap dot11 dot11n

To configure settings for an 802.11n network, use the **ap dot11 dot11n** command.

```
ap dot11 {24ghz | 5ghz} dot11n {a-mpdu tx priority {priority_value all} | scheduler timeout rt
scheduler_value} | a-msdu tx priority {priority_value all} | guard-interval {any | long} | mcs tx rate
| rifs rx}
```

Syntax	Description
24ghz	Specifies the 2.4-GHz band.
5ghz	Specifies the 5-GHz band.
dot11n	Enables 802.11n support.
a-mpdu tx priority	Specifies the traffic that is associated with the priority level that uses Aggregated MAC Protocol Data Unit (A-MPDU) transmission.
<i>priority_value</i>	Aggregated MAC protocol data unit priority level from 0 to 7.
all	Specifies all of the priority levels at once.
a-msdu tx priority	Specifies the traffic that is associated with the priority level that uses Aggregated MAC Service Data Unit (A-MSDU) transmission.
<i>priority_value</i>	Aggregated MAC protocol data unit priority level from 0 to 7.
all	Specifies all of the priority levels at once.
scheduler timeout rt	Configures the 802.11n A-MPDU transmit aggregation scheduler timeout value in milliseconds.
<i>scheduler_value</i>	The 802.11n A-MPDU transmit aggregation scheduler timeout value from 1 to 10000 milliseconds.
guard-interval	Specifies the guard interval.
any	Enables either a short or a long guard interval.
long	Enables only a long guard interval.
mcs tx rate	Specifies the modulation and coding scheme (MCS) rates at which data can be transmitted between the access point and the client.
<i>rate</i>	Specifies the modulation and coding scheme data rates. Note The range is from 0 to 23.

rifs rx	Specifies the Reduced Interframe Space (RIFS) between data frames.
----------------	--

Command Default By default, priority 0 is enabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Aggregation is the process of grouping packet data frames together rather than transmitting them separately. The two aggregation methods available are:

- A-MPDU—This aggregation is performed in the software.
- A-MSDU—This aggregation is performed in the hardware

Aggregated MAC Protocol Data Unit priority levels assigned per traffic type are as follows:

- 0—Best effort
- 1—Background
- 2—Spare
- 3—Excellent effort
- 4—Controlled load
- 5—Video, less than 100-ms latency and jitter
- 6—Voice, less than 10-ms latency and jitter
- 7—Network control
- all—Configure all of the priority levels at once.



Note Configure the priority levels to match the aggregation method used by the clients.

This example shows how to enable 802.11n support on a 2.4-GHz band:

```
Device(config)# ap dot11 24ghz dot11n
```

This example shows how to configure all the priority levels at once so that the traffic that is associated with the priority level uses A-MSDU transmission:

```
Device(config)# ap dot11 24ghz dot11n a-msdu tx priority all
```

This example shows how to enable only long guard intervals:

```
Device(config)# ap dot11 24ghz dot11n guard-interval long
```

This example shows how to specify MCS rates:

```
Device(config)# ap dot11 24ghz dot11n mcs tx 5
```

This example shows how to enable RIFS:

```
Device(config)# ap dot11 24ghz dot11n rifs rx
```

Related Topics

[ap dot11 dtpc](#), on page 510

ap dot11 dtpc

To configure Dynamic Transmit Power Control (DTPC) settings, Cisco Client eXtension (CCX) version 5 expedited bandwidth request feature, and the fragmentation threshold on an 802.11 network, use the **ap dot11 dtpc** command.

```
ap dot11 {24ghz | 5ghz} {dtpc | exp-bwreq | fragmentation threshold}
```

Syntax Description		
24ghz		Specifies the 2.4 GHz band.
5ghz		Specifies the 5 GHz band.
dtpc		Specifies Dynamic Transport Power Control (DTPC) settings. Note This option is enabled by default.
exp-bwreq		Specifies Cisco Client eXtension (CCX) version 5 expedited bandwidth request feature. Note The expedited bandwidth request feature is disabled by default.
fragmentation threshold		Specifies the fragmentation threshold. Note This option can only be used when the network is disabled using the ap dot11 {24ghz 5ghz} shutdown command.
<i>threshold</i>		Threshold. The range is from 256 to 2346 bytes (inclusive).

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines When the CCX version 5 expedited bandwidth request feature is enabled, the device configures all joining access points for this feature.

This example shows how to enable DTPC for the 5 GHz band:

```
Device(config)# ap dot11 5ghz dtpc
```

This example shows how to enable the CCX expedited bandwidth settings:

```
Device(config)# ap dot11 5ghz exp-bwreq
```

This example shows how to configure the fragmentation threshold on the 5 GHz band with the threshold number of 1500 bytes:

```
Device(config)# ap dot11 5ghz fragmentation 1500
```

Related Topics

[ap dot11 beaconperiod](#), on page 488

ap dot11 edca-parameters

To enable a specific enhanced distributed channel access (EDCA) profile on the 2.4 GHz or 5 GHz bands, use the **ap dot11 edca-parameters** command. To disable an EDCA profile on the 2.4 GHz or 5 GHz bands, use the **no** form of this command.

```
ap dot11 {24ghz | 5ghz} edca-parameters {custom-voice | optimized-video-voice | optimized-voice |
svp-voice | wmm-default}
no ap dot11 {24ghz | 5ghz} edca-parameters {custom-voice | optimized-video-voice | optimized-voice
| svp-voice | wmm-default}
```

Syntax Description		
	24ghz	Specifies the 2.4 GHz band.
	5ghz	Specifies the 5 GHz band.
	edca-parameters	Specifies a specific enhanced distributed channel access (EDCA) profile on the 802.11 networks.
	custom-voice	Enables custom voice EDCA parameters.
	optimized-video-voice	Enables EDCA voice- and video-optimized profile parameters. Choose this option when both voice and video services are deployed on your network.
	optimized-voice	Enables EDCA voice-optimized profile parameters. Choose this option when voice services other than SpectraLink are deployed on your network.
	svp-voice	Enables SpectraLink voice priority parameters. Choose this option if SpectraLink phones are deployed on your network to improve the quality of calls.
	wmm-default	Enables the Wi-Fi Multimedia (WMM) default parameters. Choose this option when voice or video services are not deployed on your network.

Command Default wmm-default

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
	10.3	The custom-voice keyword was removed for Cisco 5700 Series WLC.

This example shows how to enable SpectraLink voice priority parameters:

```
Device(config)# ap dot11 24ghz edca-parameters svp-voice
```

ap dot11 rrm group-mode

To set the 802.11 automatic RF group selection mode on, use the **ap dot11 rrm group-mode** command. To set the 802.11 automatic RF group selection mode off, use the **no** form of this command.

```
ap dot11 {5ghz | 24ghz} rrm group-mode {auto | leader | off | restart}
no ap dot11 {5ghz | 24ghz} rrm group-mode
```

Syntax Description		
5ghz	Specifies the 2.4 GHz band.	
24ghz	Specifies the 5 GHz band.	
auto	Sets the 802.11 RF group selection to automatic update mode.	
leader	Sets the 802.11 RF group selection to static mode, and sets this device as the group leader.	
off	Sets the 802.11 RF group selection to off.	
restart	Restarts the 802.11 RF group selection.	
Command Default	auto	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to turn the auto RF group selection mode on the 5 GHz band:

```
Device(config)# ap dot11 5ghz rrm group-mode auto
```

Related Topics

- [ap dot11 rrm ccx location-measurement](#), on page 519
- [ap dot11 rrm channel cleanair-event](#), on page 514
- [ap dot11 rrm channel dca](#), on page 520
- [ap dot11 rrm group-member](#), on page 522
- [ap dot11 rrm logging](#), on page 523
- [ap dot11 rrm monitor](#), on page 525
- [ap dot11 rrm ndp-type](#), on page 527

ap dot11 rrm channel cleanair-event

To configure CleanAir event-driven Radio Resource Management (RRM) parameters for all 802.11 Cisco lightweight access points, use the **ap dot11 rrm channel cleanair-event** command. When this parameter is configured, CleanAir access points can change their channel when a source of interference degrades the operations, even if the RRM interval has not expired yet.

```
ap dot11 {24ghz | 5ghz} rrm channel {cleanair-event sensitivity value}
```

Syntax Description	24ghz	Specifies the 2.4 GHz band.
	5ghz	Specifies the 5 GHz band.
	sensitivity	Sets the sensitivity for CleanAir event-driven RRM.
	<i>value</i>	Sensitivity value. You can specify any one of the following three optional sensitivity values: <ul style="list-style-type: none"> • low—Specifies low sensitivity. • medium—Specifies medium sensitivity. • high—Specifies high sensitivity.
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to set the high sensitivity for CleanAir event-driven RRM:

```
Device(config)# ap dot11 24ghz rrm channel cleanair-event sensitivity high
```

Related Topics

- [ap dot11 rrm ccx location-measurement](#), on page 519
- [ap dot11 rrm group-mode](#), on page 513
- [ap dot11 rrm channel dca](#), on page 520
- [ap dot11 rrm group-member](#), on page 522
- [ap dot11 rrm logging](#), on page 523
- [ap dot11 rrm monitor](#), on page 525
- [ap dot11 rrm ndp-type](#), on page 527

ap dot11 l2roam rf-params

To configure the 2.4 GHz or 5 GHz Layer 2 client roaming parameters, use the **ap dot11 l2roam rf-params** command.

```
ap dot11 {24ghz | 5ghz} l2roam rf-params custom min-rssi roam-hyst scan-thresh trans-time
```

Syntax Description		
	24ghz	Specifies the 2.4 GHz band.
	5ghz	Specifies the 5 GHz band.
	custom	Specifies custom Layer 2 client roaming RF parameters.
	<i>min-rssi</i>	Minimum received signal strength indicator (RSSI) that is required for the client to associate to the access point. If the client's average received signal power dips below this threshold, reliable communication is usually impossible. Clients must already have found and roamed to another access point with a stronger signal before the minimum RSSI value is reached. The valid range is -80 to -90 dBm, and the default value is -85 dBm.
	<i>roam-hyst</i>	How much greater the signal strength of a neighboring access point must be in order for the client to roam to it. This parameter is intended to reduce the amount of roaming between access points if the client is physically located on or near the border between the two access points. The valid range is 2 to 4 dB, and the default value is 2 dB.
	<i>scan-thresh</i>	Minimum RSSI that is allowed before the client should roam to a better access point. When the RSSI drops below the specified value, the client must be able to roam to a better access point within the specified transition time. This parameter also provides a power-save method to minimize the time that the client spends in active or passive scanning. For example, the client can scan slowly when the RSSI is above the threshold and scan more rapidly when the RSSI is below the threshold. The valid range is -70 to -77 dBm, and the default value is -72 dBm.
	<i>trans-time</i>	Maximum time allowed for the client to detect a suitable neighboring access point to roam to and to complete the roam, whenever the RSSI from the client's associated access point is below the scan threshold. The valid range is 1 to 10 seconds, and the default value is 5 seconds.

Command Default		
	<i>min-rssi</i>	-85
	<i>roam-hyst</i>	2
	<i>scan-thresh</i>	-72
	<i>trans-time</i>	5

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure custom Layer 2 client roaming parameters on an 802.11a network:

```
Device(config)# ap dot11 5ghz l2roam rf-params custom -80 2 -70 7
```

ap dot11 media-stream

To configure media stream multicast-direct and video-direct settings on an 802.11 network, use the **ap dot11 media-stream** command.

```
ap dot11 {24ghz | 5ghz} media-stream {multicast-direct {admission-besteffort | client-maximum value | radio-maximum value} | video-redirect}
```

Syntax Description		
	24ghz	Specifies the 2.4 GHz band.
	5ghz	Specifies the 5 GHz band.
	multicast-direct	Specifies the multicast-direct for the 2.4 GHz or a 5 GHz band.
	admission-besteffort	Admits the media stream to the best-effort queue.
	client-maximum <i>value</i>	Specifies the maximum number of streams allowed on a client.
	radio-maximum <i>value</i>	Specifies the maximum number of streams allowed on a 2.4 GHz or a 5 GHz band.
	video-redirect	Specifies the media stream video-redirect for the 2.4 GHz or a 5 GHz band.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Before you configure the media stream multicast-direct or video-redirect on a 802.11 network, ensure that the network is nonoperational.

This example shows how to enable media stream multicast-direct settings on the 5 GHz band:

```
Device(config)# ap dot11 5ghz media-stream multicast-direct
```

This example shows how to admit the media stream to the best-effort queue if there is not enough bandwidth to prioritize the flow:

```
Device(config)# ap dot11 5ghz media-stream multicast-direct admission-besteffort
```

This example shows how to set the maximum number of streams allowed on a client:

```
Device(config)# ap dot11 5ghz media-stream multicast-direct client-maximum 10
```

This example shows how to enable media stream traffic redirection on the 5 GHz band:

```
Device(config)# ap dot11 5ghz media-stream video-redirect
```

ap dot11 rrm ccx location-measurement

To configure Cisco client Extensions (CCX) client location measurements for 2.4 GHz and 5 GHz bands, use the `ap dot11 rrm ccx location-measurement` command.

```
ap dot11 {24ghz | 5ghz} rrm ccx location-measurement {disableinterval}
```

Syntax Description	24ghz	Specifies the 2.4-GHz band.
	5ghz	Specifies the 5-GHz band.
	disable	Disables support for CCX client location measurements.
	<i>interval</i>	Interval from 10 to 32400.
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to disable support for 2.4 GHz CCX client location measurements:

```
Device(config)# no ap dot11 24ghz rrm ccx location-measurement
```

Related Topics

- [ap dot11 rrm group-mode](#), on page 513
- [ap dot11 rrm channel cleanair-event](#), on page 514
- [ap dot11 rrm channel dca](#), on page 520
- [ap dot11 rrm group-member](#), on page 522
- [ap dot11 rrm logging](#), on page 523
- [ap dot11 rrm monitor](#), on page 525
- [ap dot11 rrm ndp-type](#), on page 527

ap dot11 rrm channel dca

To configure Dynamic Channel Assignment (DCA) algorithm parameters on 802.11 networks, use the **ap dot11 rrm channel dca** command.

```
ap dot11 {24ghz | 5ghz} rrm channel dca {channel_number | anchor-time value | global {auto | once}
| interval value | min-metric value | sensitivity {high | low | medium}}
```

Syntax Description		
24ghz		Specifies the 2.4 GHz band.
5ghz		Specifies the 5 GHz band.
<i>channel_number</i>		Channel number to be added to the DCA list. Note The range is from 1 to 14.
anchor-time		Specifies the anchor time for DCA.
<i>value</i>		Hour of time between 0 and 23. These values represent the hour from 12:00 a.m. to 11:00 p.m.
global		Specifies the global DCA mode for the access points in the 802.11 networks.
auto		Enables auto-RF.
once		Enables one-time auto-RF.
interval		Specifies how often the DCA is allowed to run.
<i>value</i>		Interval between the times when DCA is allowed to run. Valid values are 0, 1, 2, 3, 4, 6, 8, 12, or 24 hours. 0 is 10 minutes (600 seconds). Default value is 0 (10 minutes).
min-metric		Specifies the DCA minimum RSSI energy metric.
<i>value</i>		Minimum RSSI energy metric value from -100 to -60.
sensitivity		Specifies how sensitive the DCA algorithm is to environmental changes (for example, signal, load, noise, and interference) when determining whether or not to change channels.
high		Specifies that the DCA algorithm is not particularly sensitive to environmental changes. See the “Usage Guidelines” section for more information.
low		Specifies that the DCA algorithm is moderately sensitive to environmental changes. See the “Usage Guidelines” section for more information.
medium		Specifies that the DCA algorithm is highly sensitive to environmental changes. See the “Usage Guidelines” section for more information.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The DCA sensitivity thresholds vary by radio band as shown in the table below.

To aid in troubleshooting, the output of this command shows an error code for any failed calls. The table below explains the possible error codes for failed calls.

Table 27: DCA Sensitivity Threshold

Sensitivity	2.4 Ghz DCA Sensitivity Threshold	5 Ghz DCA Sensitivity Threshold
High	5 dB	5 dB
Medium	15 dB	20 dB
Low	30 dB	35 dB

This example shows how to configure the device to start running DCA at 5 pm for the 2.4 GHz band:

```
Device(config)# ap dot11 24ghz rrm channel dca anchor-time 17
```

This example shows how to set the DCA algorithm to run every 10 minutes for the 2.4 GHz band:

```
Device(config)# ap dot11 24ghz rrm channel dca interval 0
```

This example shows how to configure the value of DCA algorithm's sensitivity to low on the 2.4 GHz band:

```
Device(config)# ap dot11 24ghz rrm channel dca sensitivity low
```

Related Topics

- [ap dot11 rrm ccx location-measurement](#), on page 519
- [ap dot11 rrm channel cleanair-event](#), on page 514
- [ap dot11 rrm group-mode](#), on page 513
- [ap dot11 rrm group-member](#), on page 522
- [ap dot11 rrm logging](#), on page 523
- [ap dot11 rrm monitor](#), on page 525
- [ap dot11 rrm ndp-type](#), on page 527

ap dot11 rrm group-member

To configure members in an 802.11 static RF group, use the **ap dot11 rrm group-member** command. To remove members from 802.11 RF group, use the **no** form of this command.

```
ap dot11 {24ghz | 5ghz} rrm group-member controller-name controller-ip
no ap dot11 {24ghz | 5ghz} rrm group-member controller-name controller-ip
```

Syntax Description	24ghz	Specifies the 2.4 GHz band.
	5ghz	Specifies the 5 GHz band.
	<i>controller-name</i>	Name of the device to be added.
	<i>controller-ip</i>	IP address of the device to be added.
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE

This example shows how to add a device in the 5 GHz band RF group:

```
Device(config)# ap dot11 5ghz rrm group-member cisco-controller 192.0.2.54
```

Related Topics

- [ap dot11 rrm ccx location-measurement](#), on page 519
- [ap dot11 rrm channel cleanair-event](#), on page 514
- [ap dot11 rrm channel dca](#), on page 520
- [ap dot11 rrm group-mode](#), on page 513
- [ap dot11 rrm logging](#), on page 523
- [ap dot11 rrm monitor](#), on page 525
- [ap dot11 rrm ndp-type](#), on page 527

ap dot11 rrm logging

To configure report log settings on supported 802.11 networks, use the **ap dot11 rrm logging** command.

```
ap dot11 {24ghz | 5ghz} rrm logging {channel | coverage | foreign | load | noise | performance | txpower}
```

Syntax Description	24ghz	Specifies the 2.4 GHz band.
	5ghz	Specifies the 5 GHz band.
	channel	Turns the channel change logging mode on or off. The default mode is off (Disabled).
	coverage	Turns the coverage profile logging mode on or off. The default mode is off (Disabled).
	foreign	Turns the foreign interference profile logging mode on or off. The default mode is off (Disabled).
	load	Turns the load profile logging mode on or off. The default mode is off (Disabled).
	noise	Turns the noise profile logging mode on or off. The default mode is off (Disabled).
	performance	Turns the performance profile logging mode on or off. The default mode is off (Disabled).
	txpower	Turns the transit power change logging mode on or off. The default mode is off (Disabled).
Command Default	Disabled	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to turn the 5 GHz logging channel selection mode on:

```
Device(config)# ap dot11 5ghz rrm logging channel
```

This example shows how to turn the 5 GHz coverage profile violation logging selection mode on:

```
Device(config)# ap dot11 5ghz rrm logging coverage
```

This example shows how to turn the 5 GHz foreign interference profile violation logging selection mode on:

```
Device(config)# ap dot11 5ghz rrm logging foreign
```

This example shows how to turn the 5 GHz load profile logging mode on:

```
Device(config)# ap dot11 5ghz rrm logging load
```

This example shows how to turn the 5 GHz noise profile logging mode on:

```
Device(config)# ap dot11 5ghz rrm logging noise
```

This example shows how to turn the 5 GHz performance profile logging mode on:

```
Device(config)# ap dot11 5ghz rrm logging performance
```

This example shows how to turn the 5 GHz transmit power change mode on:

```
Device(config)# ap dot11 5ghz rrm logging txpower
```

Related Topics

- [ap dot11 rrm ccx location-measurement](#), on page 519
- [ap dot11 rrm channel cleanair-event](#), on page 514
- [ap dot11 rrm channel dca](#), on page 520
- [ap dot11 rrm group-member](#), on page 522
- [ap dot11 rrm group-mode](#), on page 513
- [ap dot11 rrm monitor](#), on page 525
- [ap dot11 rrm ndp-type](#), on page 527

ap dot11 rrm monitor

To Configure monitor settings on the 802.11 networks, use the **ap dot11 rrm monitor** command.

```
ap dot11 {24ghz | 5ghz} rrm monitor {channel-list | {all | country | dca} | coverage | load | noise | signal} seconds
```

Syntax Description		
24ghz		Specifies the 802.11b parameters.
5ghz		Specifies the 802.11a parameters.
channel-list all		Monitors the noise, interference, and rogue monitoring channel list for all channels.
channel-list country		Monitors the noise, interference, and rogue monitoring channel list for the channels used in the configured country code.
channel-list dca		Monitors the noise, interference, and rogue monitoring channel list for the channels used by automatic channel assignment.
coverage		Specifies the coverage measurement interval.
load		Specifies the load measurement interval.
noise		Specifies the noise measurement interval.
signal		Specifies the signal measurement interval.
rsi-normalization		Configure RRM Neighbor Discovery RSSI Normalization.
<i>seconds</i>		Measurement interval time from 60 to 3600 seconds.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to monitor the channels used in the configured country:

```
Device(config)# ap dot11 24ghz rrm monitor channel-list country
```

This example shows how to set the coverage measurement interval to 60 seconds:

```
Device(config)# ap dot11 24ghz rrm monitor coverage 60
```

Related Topics

[ap dot11 rrm ccx location-measurement](#), on page 519

[ap dot11 rrm channel cleanair-event](#), on page 514
[ap dot11 rrm channel dca](#), on page 520
[ap dot11 rrm group-member](#), on page 522
[ap dot11 rrm logging](#), on page 523
[ap dot11 rrm group-mode](#), on page 513
[ap dot11 rrm ndp-type](#), on page 527

ap dot11 rrm ndp-type

To configure the 802.11 access point radio resource management neighbor discovery protocol type, use the `ap dot11 rrm ndp-type` command.

```
ap dot11 {24ghz | 5ghz} rrm ndp-type {protected | transparent}
```

Syntax Description	24ghz	Specifies the 2.4 GHz band.
	5ghz	Specifies the 5 GHz band.
	protected	Specifies the Tx RRM protected (encrypted) neighbor discovery protocol.
	transparent	Specifies the Tx RRM transparent (not encrypted) neighbor discovery protocol.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines Before you configure the 802.11 access point RRM neighbor discovery protocol type, ensure that you have disabled the network by entering the `ap dot11 {24ghz | 5ghz} shutdown` command.

This example shows how to enable the 802.11a access point RRM neighbor discovery protocol type as protected:

```
Device(config)# ap dot11 5ghz rrm ndp-type protected
```

Related Topics

- [ap dot11 rrm ccx location-measurement](#), on page 519
- [ap dot11 rrm channel cleanair-event](#), on page 514
- [ap dot11 rrm channel dca](#), on page 520
- [ap dot11 rrm group-member](#), on page 522
- [ap dot11 rrm logging](#), on page 523
- [ap dot11 rrm group-mode](#), on page 513
- [ap dot11 rrm monitor](#), on page 525

ap dot11 5ghz dot11ac frame-burst

To configure the 802.11ac Frame Burst use the **apdot115ghzdot11acframe-burst** command. Use the **no** forms to disable the bursting of 802.11ac A-MPDUs.

```
ap dot115ghzdot11acframe-burst
```

```
noap dot115ghzdot11acframe-burst
```

```
ap dot115ghzdot11acframe-burstautomatic
```

```
noap dot115ghzdot11acframe-burstautomatic
```

Syntax Description	5ghz	Configures the 802.11a parameters.
	frame-burst	Configures the bursting of 802.11ac A-MPDUs.
Command Default	No	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.6E	This command was introduced.

Example

This is the example shows how to configure the bursting of 802.11ac A-MPDUs.

```
Device# ap dot11 5ghz
      dot11ac frame-burst
```

ap dot1x max-sessions

To configure the maximum number of simultaneous 802.1X sessions allowed per access point, use the **ap dot1x max-sessions** command.

ap dot1x max-sessions *num-of-sessions*

Syntax Description	<i>num-of-sessions</i> Number of maximum 802.1X sessions initiated per AP at a time. The range is from 0 to 255, where 0 indicates unlimited.				
Command Default	None				
Command Modes	Global configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				
Usage Guidelines	<p>It is required to limit the number of simultaneous 802.1X sessions initiated per access point to protect against flooding attacks caused by using 802.1X messages.</p> <p>This example shows how to configure the maximum number of simultaneous 802.1X sessions:</p> <pre>Device(config)# ap dot1x max-sessions 100</pre>				

ap dot1x username

To configure the 802.1X username and password for all access points that are currently joined to the device and any access points that join the device in the future, use the **ap dot1x username** command. To disable the 802.1X username and password for all access points that are currently joined to the device, use the **no** form of this command.

```
ap dot1x username user-id password{0|8} password-string
no ap dot1x username user-id password{0|8} password-string
```

Syntax Description		
	<i>user-id</i>	Username.
	password	Specifies an 802.1X password for all access points.
	0	Specifies an unencrypted password.
	8	Specifies an AES encrypted password.
	<i>password_string</i>	Password.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You should enter a strong password. Strong passwords have the following characteristics:

- They are at least eight characters long.
- They contain a combination of uppercase and lowercase letters, numbers, and symbols.
- They are not words in any language.

You can set the values for a specific access point.

This example shows how to configure the global authentication username and password for all access points:

```
Device(config)# ap dot1x username cisco123 password 0 cisco2020
```

Related Topics

[show ap summary](#), on page 702

ap ethernet duplex

To configure the Ethernet port duplex and speed settings of the lightweight access points, use the **ap ethernet duplex** command. To disable the Ethernet port duplex and speed settings of lightweight access points, use the **no ap ethernet** form of this command.

```
ap ethernet duplex duplex speed speed
no ap ethernet
```

Syntax Description	<i>duplex</i>	Ethernet port duplex settings. You can specify the following options to configure the duplex settings: <ul style="list-style-type: none"> • auto—Specifies the Ethernet port duplex auto settings. • half—Specifies the Ethernet port duplex half settings. • full—Specifies the Ethernet port duplex full settings.
	speed	Specifies the Ethernet port speed settings.
	<i>speed</i>	Ethernet port speed settings. You can specify the following options to configure the speed settings: <ul style="list-style-type: none"> • auto—Specifies the Ethernet port speed to auto. • 10—Specifies the Ethernet port speed to 10 Mbps. • 100—Specifies the Ethernet port speed to 100 Mbps. • 1000—Specifies the Ethernet port speed to 1000 Mbps.
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure the Ethernet port duplex full settings as 1000 Mbps for all access points:

```
Device(config)# ap ethernet duplex full speed 1000
```

Related Topics

[show ap summary](#), on page 702

ap group

To create a new access point group, use the **ap group** command. To remove an access point group, use the **no** form of this command.

```
ap group group-name
no ap group group-name
```

Syntax Description	<i>group-name</i> Access point group name.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	An error message appears if you try to delete an access point group that is used by at least one access point. Before you can delete an AP group, move all APs in this group to another group. The access points are not moved to the default-group access point group automatically. To see the APs, enter the show ap summary command. To move access points, enter the ap name Cisco-AP ap-groupname Group-Name command.
-------------------------	---

This example shows how to create a new access point group:

```
Device(config)# ap group sampleapgroup
```

Related Topics

[ap name ap-groupname](#), on page 540

ap image

To configure an image on all access points that are associated to the device, use the **ap image** command.

ap image {**predownload** | **reset** | **swap**}

Syntax Description

predownload	Instructs all the access points to start predownloading an image.
reset	Instructs all the access points to reboot.
swap	Instructs all the access points to swap the image.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to predownload an image to all access points:

```
Device# ap image predownload
```

This example shows how to reboot all access points:

```
Device# ap image reset
```

This example shows how to swap the access point's primary and secondary images:

```
Device# ap image swap
```

Related Topics

[show ap image](#), on page 652

ap ipv6 tcp adjust-mss

To configure IPv6 TCP maximum segment size (MSS) value for all Cisco APs, use the **ap ipv6 tcp adjust-mss** command.

```
ap ipv6 tcp adjust-mss size
no ap ipv6 tcp adjust-mss size
```

Syntax Description	
adjust-mss	Configures IPv6 TCP MSS settings for all Cisco APs.
<i>size</i>	MSS value in the range of 500 to 1440.

Command Default	None
-----------------	------

Command Modes	Global configuration.
---------------	-----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	The MSS value must be in the range of 500 to 1440.
------------------	--

This example shows how to configure the IPv6 TCP MSS value to 600 for all Cisco APs:

```
Device(config)# ap ipv6 tcp adjust-mss 600
```

ap led

To enable the LED state for an access point, use the **ap led** command. To disable the LED state for an access point, use the **no** form of this command.

```
ap led
no ap led
```

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to enable the LED state for an access point:

```
Device(config)# ap led
```

ap link-encryption

To enable Datagram Transport Layer Security (DTLS) data encryption for access points, use the **ap link-encryption** command. To disable the DTLS data encryption for access points, use the **no** form of this command.

ap link-encryption
no ap link-encryption

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	Disabled
------------------------	----------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to enable data encryption for all the access points that are joined to the controller:

```
Device(config)# ap link-encryption
```

Related Topics

[ap link-latency](#), on page 537

ap link-latency

To enable link latency for all access points that are currently associated to the device, use the **ap link-latency** command. To disable link latency all access points that are currently associated to the device, use the **no** form of this command.

```
ap link-latency [reset]
no ap link-latency
```

Syntax Description	reset (Optional) Resets all link latency for all access points.						
Command Default	Link latency is disabled by default.						
Command Modes	Global configuration						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE</td> </tr> <tr> <td></td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE		This command was introduced.
Release	Modification						
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE						
	This command was introduced.						

Usage Guidelines This command enables or disables link latency only for those access points that are currently joined to the device. It does not apply to access points that join in the future.

This example shows how to enable the link latency for all access points:

```
Device(config)# ap link-latency
```

Related Topics

[ap link-encryption](#), on page 536

ap mgmtuser username

To configure the username, password, and secret password for access point management, use the **ap mgmtuser username** command.

ap mgmtuser username *username* **password** *password_type* *password* **secret** *secret_type* *secret*

Syntax Description		
<i>username</i>		Specifies the username for access point management.
password		Specifies the password for access point management.
<i>password_type</i>		Password type. You can specify any one of the following two password types: <ul style="list-style-type: none"> • 0—Specifies that an unencrypted password will follow. • 8—Specifies that an AES encrypted password will follow.
<i>password</i>		Access point management password. <p>Note The password does not get encrypted by service-password encryption.</p>
secret		Specifies the secret password for privileged access point management.
<i>secret_type</i>		Secret type. You can specify any one of the following two secret types: <ul style="list-style-type: none"> • 0—Specifies that an unencrypted secret password will follow. • 8—Specifies that an AES encrypted secret password will follow.
<i>secret</i>		Access point management secret password.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines To specify a strong password, the following password requirements should be met:

- The password should contain characters from at least three of the following classes: lowercase letters, uppercase letters, digits, and special characters.

- No character in the password can be repeated more than three times consecutively.
- The password should not contain a management username or the reverse of a username.
- The password should not contain words such as Cisco, oscic, admin, nimda or any variant obtained by changing the capitalization of letters by substituting l, |, or ! or substituting 0 for o or substituting \$ for s.

To specify a strong secret password, the following requirement should be met:

- The secret password should contain characters from at least three of the following classes: lowercase letters, uppercase letters, digits, or special characters.

This example shows how to add a username, password, and secret password for access point management:

```
Device(config)# ap mgmtuser username glbusr password 0 Arc_1234 secret 0 Mid_1234
```

ap name ap-groupname

To add a Cisco lightweight access point to a specific access point group, use the **ap name ap-groupname** command.

ap name *ap-name* **ap-groupname** *group-name*

Syntax Description	
	<i>ap-name</i> Name of the Cisco lightweight access point.
	<i>group-name</i> Descriptive name for the access point group.

Command Default	None
-----------------	------

Command Modes	Any command mode
---------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines	The Cisco lightweight access point must be disabled before changing this parameter.
------------------	---

This example shows how to add the access point AP01 to the access point group superusers:

```
Device# ap name AP01 ap-groupname superusers
```

Related Topics

[ap group](#), on page 532

[show ap summary](#), on page 702

ap name antenna band mode

To configure the antenna mode, use the **ap name**<AP name> **antenna-band-mode**{ **single** | **dual** } command.

```
ap name ap-name antenna-band-mode {single | dual}
```

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
	antenna-band-mode	Instructs the access point to enable the band mode of antenna.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Example

This example shows how to configure the antenna band mode of access point.

```
Device# ap name <ap-name> antenna-band-mode single
```

ap name bhrate

To configure the Cisco bridge backhaul Tx rate, use the **ap name bhrate** command.

ap name *ap-name* **bhrate** *kbps*

Syntax Description	<i>ap-name</i>	Name of the Cisco access point.
	<i>kbps</i>	Cisco bridge backhaul Tx rate in kbps. The valid values are 6000, 12000, 18000, 24000, 36000, 48000, and 54000.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to configure the Cisco bridge backhaul Tx rate to 54000 kbps:

```
Device# ap name AP02 bhrate 54000
```

ap name bridgegroupname

To set a bridge group name on a Cisco lightweight access point, use the **ap name bridgegroupname** command. To delete a bridge group name on a Cisco lightweight access point, use the **no** form of this command.

```
ap name ap-name bridgegroupname bridge_group_name
ap name ap-name no bridgegroupname
```

Syntax Description

ap-name Name of the Cisco lightweight access point.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Only access points with the same bridge group name can connect to each other. Changing the access point bridgegroupname may strand the bridge access point.

This example shows how to set a bridge group name on Cisco access point's bridge group name AP02:

```
Device# ap name AP02 bridgegroupname West
```

This example shows how to delete a bridge group name on Cisco access point's bridge group name AP02:

```
Device# ap name AP02 no bridgegroupname
```

ap name bridging

To enable Ethernet-to-Ethernet bridging on a Cisco lightweight access point, use the **ap name bridging** command. To disable Ethernet-to-Ethernet bridging on a Cisco lightweight access point, use the **no** form of this command.

```
ap name ap-name bridging
ap name ap-name no bridging
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.	
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to enable Ethernet-to-Ethernet bridging on an access point:

```
Device# ap name TSIM_AP2 bridging
```

Related Topics

[ap bridging](#), on page 475

ap name cdp interface

To enable the Cisco Discovery Protocol (CDP) on a Cisco lightweight access point, use the **ap name** command. To disable the Cisco Discovery Protocol (CDP) on a Cisco lightweight access point, use the **no** form of this command.

```
ap name ap-name cdp interface {ethernet ethernet-id | radio radio-id}
ap name ap-name [no] cdp interface {ethernet ethernet-id | radio radio-id}
```

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
	ethernet	Enables CDP on an Ethernet interface.
	<i>ethernet-id</i>	Ethernet interface number from 0 to 3.
	radio	Enables CDP for a radio interface.
	<i>radio-id</i>	Radio ID slot number from 0 to 3.
Command Default	Disabled on all access points.	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	CDP over Ethernet/radio interfaces is available only when CDP is enabled. After you enable CDP on all access points that are joined to the device, you can disable and then reenables CDP on individual access points by using the ap name <i>ap-name</i> cdp interface ethernet <i>ethernet-id</i> cisco_ap command. After you disable CDP on all access points that are joined to the device, you cannot enable and then disable CDP on individual access points.	

This example shows how to enable CDP for Ethernet interface number 0 on an access point:

```
Device# ap name TSIM_AP2 cdp interface ethernet 0
```

ap name console-redirect

To redirect the remote debug output of a Cisco lightweight access point to the console, use the **ap name console-redirect** command. To disable the redirection of the remote debug output of a Cisco lightweight access point to the console, use the **no** form of this command.

```
ap name ap-name console-redirect
ap name ap-name [no] console-redirect
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.	
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to enable redirecting remote debug output of a Cisco access point named AP02 to the console:

```
Device# ap name AP02 console-redirect
```

ap name capwap retransmit

To configure the access point control packet retransmission interval and control packet retransmission count, use the **ap name capwap retransmit** command.

```
ap name ap-name capwap retransmit {count count-value | interval interval-time}
```

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.
count	Sets the number of times control packet will be retransmitted.
<i>count-value</i>	Number of times that the control packet will be retransmitted from 3 to 8.
interval	Sets the control packet retransmission timeout interval.
<i>interval-time</i>	Control packet retransmission timeout from 2 to 5 seconds.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure the retransmission interval for an access point:

```
Device# ap name AP01 capwap retransmit interval 5
```

This example shows how to configure the retransmission retry count for a specific access point:

```
Device# ap name AP01 capwap retransmit count 5
```

ap name command

To execute a command remotely on a specific Cisco access point, use the **ap name command** command.

```
ap name ap-name command "command "
```

Syntax Description	<i>ap-name</i> Name of the Cisco access point.
	<i>command</i> Command to be executed on a Cisco access point.

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE

This example shows how to remotely enter the **show ip interface brief** command on the Cisco access point named TSIM_AP2:

```
Device# ap name AP2 command "show ip interface brief"
```

ap name core-dump

To configure a Cisco lightweight access point's memory core dump, use the **ap name core-dump** command. To disable a Cisco lightweight access point's memory core dump, use the **no** form of this command.

```
ap name ap-name core-dump tftp-ip-addr filename {compress | uncompress}
ap name ap-name [no] core-dump
```

Syntax Description

<i>ap-name</i>	Name of the access point.
<i>tftp-ip-addr</i>	IP address of the TFTP server to which the access point sends core dump files.
<i>filename</i>	Name that the access point used to label the core file.
compress	Compresses the core dump file.
uncompress	Uncompresses the core dump file.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The access point must be able to reach the TFTP server before you can use this command.

This example shows how to configure and compress the core dump file:

```
Device# ap name AP2 core-dump 192.1.1.1 log compress
```

Related Topics

[ap core-dump](#), on page 481

ap name country

To configure the country of operation for a Cisco lightweight access point, use the **ap name country** command.

ap name *ap-name* **country** *country-code*

Syntax Description

ap-name Name of the Cisco lightweight access point.

country-code Two-letter or three-letter country code.

Command Default

None

Command Modes

Any command mode

Command History

Release

Modification

Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE

This command was introduced.

Usage Guidelines

Cisco devices must be installed by a network administrator or qualified IT professional and the installer must select the proper country code. Following installation, access to the unit should be password protected by the installer to maintain compliance with regulatory requirements and to ensure proper unit functionality. See the related product guide for the most recent country codes and regulatory domains. Also, access point regulatory domains are defined during the access point manufacturing process. You can change the access point country code if the new country code matches a country that is valid within the access point regulatory domain. If you try to enter a country that is not valid to the access point regulatory domain, the command fails.

This example shows how to configure the Cisco lightweight access point's country code to DE:

```
Device# ap name AP2 country JP
```

Related Topics

[ap country](#), on page 482

ap name crash-file

To manage crash data and radio core files for the Cisco access point, use the **ap name crash-file** command.

```
ap name ap-name crash-file {get-crash-data | get-radio-core-dump {slot 0 | slot 1}}
```

Syntax Description		
<i>ap-name</i>	Name of the Cisco lightweight access point.	
get-crash-data	Collects the latest crash data for a Cisco lightweight access point.	
get-radio-core-dump	Gets a Cisco lightweight access point's radio core dump	
slot	Slot ID for Cisco access point.	
0	Specifies Slot 0.	
1	Specifies Slot 1.	
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to collect the latest crash data for access point AP3:

```
Device# ap name AP3 crash-file get-crash-data
```

This example shows how to collect the radio core dump for access point AP02 and slot 0:

```
Device# ap name AP02 crash-file get-radio-core-dump slot 0
```

Related Topics

[ap crash-file](#), on page 483

ap name dot11 24ghz rrm coverage

To configure coverage hole detection settings on the 2.4 GHz band, use the **ap name dot11 24ghz rrm coverage** command.

```
ap name ap-name dot11 24ghz rrm coverage {exception value | level value}
```

Syntax Description

<i>ap-name</i>	Name of the Cisco access point.
exception	Specifies the percentage of clients on an access point that are experiencing a low signal level but cannot roam to another access point.
<i>value</i>	Percentage of clients. Valid values are from 0 to 100%. Note The default is 25%.
level	Specifies the minimum number of clients on an access point with a received signal strength indication (RSSI) value at or below the data or voice RSSI threshold.
<i>value</i>	Minimum number of clients. Valid values are from 1 to 75. Note The default is 3.

Command Default

The default for the *exception* parameter is 25% and the default for the *level* parameter is 3.

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

If you enable coverage hole detection, the device automatically determines, based on data that is received from the access points, whether any access points have clients that are potentially located in areas with poor coverage.

If both the number and percentage of failed packets exceed the values that you entered in the **ap dot11 24ghz rrm coverage data packet-count** *count* and **ap dot11 24ghz rrm coverage data fail-percentage** *percentage* commands for a 5-second period, the client is considered to be in a pre-alarm condition. The device uses this information to distinguish between real and false coverage holes and excludes clients with poor roaming logic. A coverage hole is detected if both the number and percentage of failed clients meet or exceed the values entered in the **ap dot11 24ghz rrm coverage exception** and **ap dot11 24ghz rrm coverage level** commands over a 90-second period. The device determines whether the coverage hole can be corrected and, if appropriate, mitigates the coverage hole by increasing the transmit power level for that specific access point.

This example shows how to specify the percentage of clients for an access point 2.4 GHz radio that is experiencing a low signal level:

```
Device# ap name AP2 dot11 24ghz rrm coverage exception 25%
```

This example shows how to specify the minimum number of clients on an 802.11b access point with an RSSI value at or below the RSSI threshold:

```
Device# ap name AP2 dot11 24ghz rrm coverage level 60
```

Related Topics

[ap name dot11 49ghz rrm profile](#), on page 554

[ap name dot11 5ghz rrm channel](#), on page 556

ap name dot11 49ghz rrm profile

To configure Radio Resource Management (RRM) performance profile settings for a Cisco lightweight access point on a 4.9 GHz public safety channel, use the **ap name dot11 49ghz rrm profile** command.

ap name *ap-name* **dot11 49ghz rrm profile** {**clients** *value* | **customize** | **exception** *value* | **foreign** *value* | **level** *value* | **noise** *value* | **throughput** *value* | **utilization** *value*}

Syntax Description

ap-name	Name of the Cisco lightweight access point.
clients	Sets the access point client threshold.
<i>value</i>	Access point client threshold from 1 to 75 clients. Note The default client threshold is 12.
customize	Turns on performance profile customization for an access point. Note Performance profile customization is off by default.
exception <i>value</i>	Sets the 802.11a Cisco access point coverage exception level from 0 to 100 percent.
foreign	Sets the foreign 802.11 transmitter interference threshold.
<i>value</i>	Foreign 802.11 transmitter interference threshold from 0 to 100 percent. Note The default is 10 percent.
level <i>value</i>	Sets the 802.11a Cisco access point client minimum exception level from 1 to 75 clients.
noise	Sets the 802.11 foreign noise threshold.
<i>value</i>	802.11 foreign noise threshold from -127 to 0 dBm. Note The default is -70 dBm.
throughput	Sets the data-rate throughput threshold.
<i>value</i>	802.11 throughput threshold from 1000 to 10000000 bytes per second. Note The default is 1,000,000 bytes per second.
utilization	Sets the RF utilization threshold. Note The operating system generates a trap when this threshold is exceeded.
<i>value</i>	802.11 RF utilization threshold from 0 to 100 percent. Note The default is 80 percent.

Command Default

None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to set the AP1 clients threshold to 75 clients:

```
Device# ap name AP1 dot11 49ghz rrm profile clients 75
```

This example shows how to turn performance on profile customization for Cisco lightweight access point AP1 on the 4.9 GHz channel:

```
Device# ap name AP1 dot11 49ghz rrm profile customize
```

This example shows how to set the foreign transmitter interference threshold for AP1 to 0 percent:

```
Device# ap name AP1 dot11 49ghz rrm profile foreign 0
```

This example shows how to set the foreign noise threshold for AP1 to 0 dBm:

```
Device# ap name AP1 dot11 49ghz rrm profile noise 0
```

This example shows how to set the AP1 data-rate threshold to 10000000 bytes per second:

```
Device# ap name AP1 dot11 49ghz rrm profile throughput 10000000
```

This example shows how to set the RF utilization threshold for AP1 to 100 percent:

```
Device# ap name AP1 dot11 49ghz rrm profile utilization 100
```

Related Topics

[ap name dot11 24ghz rrm coverage](#), on page 552

[ap name dot11 5ghz rrm channel](#), on page 556

ap name dot11 5ghz rrm channel

To configure a new channel using an 802.11h channel announcement, use the **ap name dot11 5ghz rrm channel** command.

ap name *ap-name* **dot11 5ghz rrm channel** *channel*

Syntax Description	
	<i>ap-name</i> Name of the Cisco lightweight access point.
	<i>channel</i> New channel.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to configure a new channel using the 802.11h channel:

```
Device# ap name AP01 dot11 5ghz rrm channel 140
```

Related Topics

- [ap name dot11 24ghz rrm coverage](#), on page 552
- [ap name dot11 49ghz rrm profile](#), on page 554

ap name dot11 antenna

To configure radio antenna settings for Cisco lightweight access points on different 802.11 networks, use the **ap name dot11 antenna** command.

```
ap name ap-name dot11 {24ghz | 5ghz} antenna {ext-ant-gain gain | mode {omni | sectorA | sectorB} | selection {external | internal}}
```

Syntax Description		
<i>ap-name</i>	Name of the Cisco lightweight access point.	
24ghz	Specifies the 2.4 GHz band.	
5ghz	Specifies the 5 GHz band.	
ext-ant-gain	Specifies the external antenna gain for an 802.11 network.	
	Note	Before you enter this command, disable the Cisco radio by using the ap dot11 {24ghz 5ghz} shutdown command. After you enter this command, reenable the Cisco radio by using the no ap dot11 {24ghz 5ghz} shutdown command.
<i>gain</i>	Antenna gain in 0.5 dBm units (for example, 2.5 dBm = 5).	
mode	Specifies that the Cisco lightweight access point is to use one internal antenna for an 802.11 sectorized 180-degree coverage pattern or both internal antennas for an 802.11 360-degree omnidirectional pattern.	
omni	Specifies to use both internal antennas.	
sectorA	Specifies to use only the side A internal antenna.	
sectorB	Specifies to use only the side B internal antenna.	
selection	Selects the internal or external antenna selection for a Cisco lightweight access point on an 802.11 network.	
external	Specifies the external antenna.	
internal	Specifies the internal antenna.	
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure a 5 GHz external antenna gain of 0.5 dBm for AP1:

```
Device# ap name AP1 dot11 5ghz antenna ext-ant-gain 0.5
```

This example shows how to configure access point AP01 antennas for a 360-degree omnidirectional pattern on a 2.4 GHz band:

```
Device# ap name AP01 dot11 24ghz antenna mode omni
```

This example shows how to configure access point AP02 on a 2.4 GHz band to use the internal antenna:

```
Device# ap name AP02 dot11 24ghz antenna selection interval
```

Related Topics

[ap name dot11 antenna extantgain](#), on page 559

ap name dot11 antenna extantgain

To configure radio antenna settings for Cisco lightweight access points on 4.9 GHz and 5.8 GHz public safety channels, use the **ap name dot11 antenna extantgain** command.

```
ap name ap-name dot11 {49ghz | 58ghz} {antenna extantgain gain}
```

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
	49ghz	Specifies 4.9 GHz public safety channel settings.
	58ghz	Specifies 5.8 GHz public safety channel settings.
	<i>gain</i>	Antenna gain in 0.5 dBm units (for example, 2.5 dBm = 5).
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE

Usage Guidelines Before you enter this command, disable the Cisco radio by using the **ap dot11 {24ghz | 5ghz} shutdown** command. After you enter this command, reenable the Cisco radio by using the **no ap dot11 {24ghz | 5ghz} shutdown** command.

This example shows how to configure an external antenna gain of 0.5 dBm for AP1 on a 4.9 GHz public safety channel:

```
Device# ap name AP1 dot11 49ghz antenna extantgain 0.5
```

Related Topics

[ap name dot11 antenna](#), on page 557

ap name dot11 cleanair

To configure CleanAir settings for a specific Cisco lightweight access point on 802.11 networks, use the **ap name dot11 cleanair** command.

ap name *ap-name* **dot11** {**24ghz** | **5ghz**} **cleanair**

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
	24ghz	Specifies the 2.4 GHz band.
	5ghz	Specifies the 5 GHz band.
Command Default	Disabled.	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to enable CleanAir on the 2.4 GHz band:

```
Device# ap name AP01 dot11 24ghz cleanair
```

ap name dot11 dot11n antenna

To configure an access point to use a specific antenna, use the **ap name dot11 dot11n antenna** command.

```
ap name ap-name dot11 {24ghz | 5ghz} dot11n antenna {A | B | C | D}
```

Syntax Description

<i>ap-name</i>	Access point name.
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
A	Specifies antenna port A.
B	Specifies antenna port B.
C	Specifies antenna port C.
D	Specifies antenna port D.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to enable antenna B on access point AP02:

```
Device# ap name AP02 dot11 5ghz dot11n antenna B
```

This example shows how to disable antenna C on access point AP02:

```
Device# ap name AP02 no dot11 5ghz dot11n C
```

ap name dot11 dual-band cleanair

To configure CleanAir for a dual band radio, use the **ap name dot11 dual-band cleanair** command.

```
ap name ap-name dot11 dual-band cleanair
ap name ap-name no dot11 dual-band cleanair
```

Syntax Description	<i>ap-name</i> Name of the Cisco AP.
	cleanair Specifies the CleanAir feature.
Command Default	None
Command Modes	Privileged EXEC
Command History	Release
	Modification
	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to enable CleanAir for a dual band radio of the access point AP01:

```
Device# ap name AP01 dot11 dual-band cleanair
```

Related Topics

- [ap name dot11 dual-band shutdown](#), on page 563
- [show ap dot11 cleanair config](#), on page 638
- [show ap name config dot11](#), on page 674

ap name dot11 dual-band shutdown

To disable dual band radio on a Cisco AP, use the **ap name dot11 dual-band shutdown** command.

```
ap name ap-name dot11 dual-band shutdown
ap name ap-name no dot11 dual-band shutdown
```

Syntax Description	<i>ap-name</i> Name of the Cisco AP.				
	shutdown Disables the dual band radio on the Cisco AP.				
Command Default	None				
Command Modes	Privileged EXEC				
Command History	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE 3.3SE</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

This example shows how to disable dual band radio on the Cisco access point AP01:

```
Device# ap name AP01 dot11 dual-band shutdown
```

ap name dot11 rrm ccx

To configure Cisco Client eXtension (CCX) Radio Resource Management (RRM) settings for specific Cisco lightweight access points on 802.11 networks, use the **ap name dot11 rrm ccx** command.

```
ap name ap-name dot11 {24ghz | 5ghz} rrm ccx {customize | location-measurement interval}
```

Syntax Description		
	<i>ap-name</i>	Name of the Cisco lightweight access point.
	24ghz	Specifies the 2.4 GHz band.
	5ghz	Specifies the 5 GHz band.
	customize	Enables 802.11 CCX options.
	location-measurement	Configures the CCX client location measurements.
	<i>interval</i>	Interval from 10 to 32400.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to configure CCX client location measurements for an access point in the 2.4 GHz band:

```
Device# ap name AP01 dot11 24ghz rrm ccx location-measurement 3200
```

Related Topics

[ap name dot11 rrm profile](#), on page 565

ap name dot11 rrm profile

To configure Radio Resource Management (RRM) performance profile settings for a Cisco lightweight access point, use the **ap name dot11 rrm profile** command.

```
ap name ap-name dot11 {24ghz | 5ghz} rrm profile {clients value | customize | foreign value |
noise value | throughput value | utilization value}
```

Syntax Description

ap-name	Name of the Cisco lightweight access point.
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
clients	Sets the access point client threshold.
<i>value</i>	Access point client threshold from 1 to 75 clients. Note The default client threshold is 12.
customize	Turns on performance profile customization for an access point. Note Performance profile customization is off by default.
foreign	Sets the foreign 802.11 transmitter interference threshold.
<i>value</i>	Foreign 802.11 transmitter interference threshold from 0 to 100 percent. Note The default is 10 percent.
noise	Sets the 802.11 foreign noise threshold.
<i>value</i>	802.11 foreign noise threshold between -127 and 0 dBm. Note The default is -70 dBm.
throughput	Sets the data-rate throughput threshold.
<i>value</i>	802.11 throughput threshold from 1000 to 10000000 bytes per second. Note The default is 1,000,000 bytes per second.
utilization	Sets the RF utilization threshold. Note The operating system generates a trap when this threshold is exceeded.
<i>value</i>	802.11 RF utilization threshold from 0 to 100 percent. Note The default is 80 percent.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to set the AP1 clients threshold to 75 clients:

```
Device# ap name AP1 dot11 24ghz rrm profile clients 75
```

This example shows how to turn performance profile customization on for 802.11a Cisco lightweight access point AP1:

```
Device# ap name AP1 dot11 5ghz rrm profile customize
```

This example shows how to set the foreign 802.11a transmitter interference threshold for AP1 to 0 percent:

```
Device# ap name AP1 dot11 5ghz rrm profile foreign 0
```

This example shows how to set the 802.11a foreign noise threshold for AP1 to 0 dBm:

```
Device# ap name AP1 dot11 5ghz rrm profile noise 0
```

This example shows how to set the AP1 data-rate threshold to 10000000 bytes per second:

```
Device# ap name AP1 dot11 5ghz rrm profile throughput 10000000
```

This example shows how to set the RF utilization threshold for AP1 to 100 percent:

```
Device# ap name AP1 dot11 5ghz rrm profile utilization 100
```

Related Topics

[ap name dot11 rrm ccx](#), on page 564

ap name dot11 txpower

To configure the transmit power level for a single access point in an 802.11 network, use the **ap name dot11 txpower** command.

```
ap name ap-name dot11 {24ghz | 5ghz} {shutdown | txpower {autopower-level}}
```

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
shutdown	Disables the 802.11 networks.
auto	Specifies the power level is automatically set by Radio Resource Management (RRM) for the 802.11 Cisco radio.
<i>power-level</i>	Manual transmit power level number for the access point.

Command Default The command default (txpower auto) is for automatic configuration by RRM.

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to automatically set the 2.4 GHz radio transmit power for access point AP1:

```
Device# ap name AP1 dot11 24ghz txpower auto
```

Related Topics

[show ap config dot11](#), on page 630

ap name dot1x-user

To configure the global authentication username and password for an access point that is currently joined to the device, use the **ap name dot1x-user** command. To disable 802.1X authentication for a specific access point, use the **no** form of this command.

```
ap name ap-name dot1x-user {global-override | username user-id password passwd}
ap name ap-name [no] dot1x-user
```

Syntax Description	<i>ap-name</i>	Name of the access point.
	global-override	Forces the access point to use the device's global authentication settings.
	username	Specifies to add a username.
	<i>user-id</i>	Username.
	password	Specifies to add a password.
	<i>passwd</i>	Password.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines

You should enter a strong password. Strong passwords have the following characteristics:

- They are at least eight characters long.
- They contain a combination of uppercase and lowercase letters, numbers, and symbols.
- They are not words in any language.

You can set the values for a specific access point.

You can disable 802.1X authentication for a specific access point only if global 802.1X authentication is not enabled. If global 802.1X authentication is enabled, you can disable 802.1X for all access points only.

This example shows how to configure a specific username and password for dot1x authentication:

```
Device# ap name AP02 dot1x-user username Cisco123 password Cisco2020
```

This example shows how to disable the authentication for access point cisco_ap1:

```
Device# ap name cisco_ap1 no dot1x-user
```

Related Topics

[show ap summary](#), on page 702

ap name ethernet

To configure ethernet port settings of a Cisco lightweight access point, use the **ap name ethernet** command. To remove configured port settings or set of defaults, use the **no** form of this command.

```
ap name ap-name ethernet intf-number mode {access vlan-id | trunk [{add | delete}]} native-vlan
vlan-id
ap name ap-name no ethernet intf-number mode {access | trunk native-vlan}
```

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
<i>intf-number</i>	Ethernet interface number from 0 to 3.
mode	Configures access or trunk mode.
access	Configures the port in access mode.
<i>vlan-id</i>	VLAN identifier.
trunk	Specifies the port in trunk mode.
add	(Optional) Adds a VLAN or trunk mode.
delete	(Optional) Deletes a VLAN or trunk mode.
native-vlan	Specifies a native VLAN.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure access mode for a Cisco access point.

```
Device# ap name AP2 ethernet 0 mode access 1
```

ap name ethernet duplex

To configure the Ethernet port duplex and speed settings of the lightweight access points, use the **ap name ethernet duplex** command.

```
ap name ap-name ethernet duplex {auto | full | half} speed {10 | 100 | 1000 | auto}
```

Syntax Description	
<i>ap-name</i>	Name of the Cisco access point.
auto	Specifies the Ethernet port duplex auto settings.
full	Specifies the Ethernet port duplex full settings.
half	Specifies the Ethernet port duplex half settings.
speed	Specifies the Ethernet port speed settings.
10	Specifies the Ethernet port speed to 10 Mbps.
100	Specifies the Ethernet port speed to 100 Mbps.
1000	Specifies the Ethernet port speed to 1000 Mbps.
auto	Specifies the Ethernet port setting for all connected access points.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure the Ethernet port to full duplex and 1 Gbps for an access point:

```
Device# ap name AP2 ethernet duplex full 1000
```

Related Topics

[show ap summary](#), on page 702

ap name key-zeroize

To enable the FIPS key-zeroization on an Access Point, use the **ap name**<AP name> **key-zeroize** command.

ap name*ap-name* **key-zeroize**

Syntax Description	<i>ap- name</i>	Name of the Cisco lightweight access point.
	key-zeroize	Instructs the access point to enable the FIPS key-zeroization on AP.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Example

This example shows how to enable FIPS key-zeroization.

```
Device# ap name <AP Name> key-zeroize
```

ap name image

To configure an image on a specific access point, use the **ap name image** command.

```
ap name ap-name image {predownload | swap}
```

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
predownload	Instructs the access point to start the image predownload.
swap	Instructs the access point to swap the image.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to predownload an image to an access point:

```
Device# ap name AP2 image predownload
```

This example shows how to swap an access point's primary and secondary images:

```
Device# ap name AP2 image swap
```

Related Topics

[show ap image](#), on page 652

[ap image](#), on page 533

ap name ipv6 tcp adjust-mss

To configure IPv6 TCP maximum segment size (MSS) value for a Cisco AP, use the **ap name ipv6 tcp adjust-mss** command.

ap name *ap-name* **ipv6 tcp adjust-mss** *size*
ap name *ap-name* **no ipv6 tcp adjust-mss**

Syntax Description	
<i>ap-name</i>	Name of the Cisco AP.
adjust-mss	Configures IPv6 TCP MSS settings for all Cisco APs.
<i>size</i>	MSS value in the range of 500 to 1440.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The MSS value must be in the range of 500 to 1440.

This example shows how to configure the IPv6 TCP MSS value to 600 for a Cisco access point AP01:

```
Device# ap name AP01 ipv6 tcp adjust-mss 600
```

ap name jumbo mtu

To configure the Jumbo MTU support, use the **ap name**<AP name>**jumbo-mtu** command.

```
ap name ap-name {jumbo-mtu | no jumbo-mtu}
```

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
	jumbo-mtu	Instructs the access point to enable the Jumbo MTU support.
	no jumbo-mtu	Instructs the access point to disable the Jumbo MTU support.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Example

This example shows how to configure the Jumbo MTU support.

```
Device# ap name <AP Name> jumbo-mtu
```

ap name lan

To configure LAN port configurations for APs, use the **ap name lan** command. To remove LAN port configurations for APs, use the **ap name no lan** command.

ap name *ap-name* [**no**] **lan** **port-id** *port-id* {**shutdown** | **vlan-access**}

Syntax Description		
	no	Removes LAN port configurations.
	port-id	Configures the port.
	<i>port-id</i>	The ID of the port. The range is 1-4
	shutdown	Disables the Port.
	vlan-access	Enables VLAN access to Port.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.7.0 E	This command was introduced.

This example shows how to enable VLAN access to port:

```
Device# ap name AP1 lan port-id 1 vlan-access
```

ap name led

To enable the LED state for an access point, use the **ap name led** command. To disable the LED state for an access point, use the **no** form of this command.

```
ap name ap-name led
no ap name ap-name [led] led
```

Syntax Description

ap-name Name of the Cisco lightweight access point.

led Enables the access point's LED state.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
	This command was introduced.

This example shows how to enable the LED state for an access point:

```
Device# ap name AP2 led
```

This example shows how to disable the LED state for an access point:

```
Device# ap name AP2 no led
```

ap name link-encryption

To enable Datagram Transport Layer Security (DTLS) data encryption for specific Cisco lightweight access points, use the **ap name link-encryption** command. To disable DTLS data encryption for specific Cisco lightweight access points, use the **no** form of this command.

```
ap name ap-name link-encryption
ap name ap-name no link-encryption
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.	
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to enable data encryption for an access point:

```
Device# ap name AP02 link-encryption
```

ap name link-latency

To enable link latency for a specific Cisco lightweight access point that is currently associated to the device, use the **ap name link-latency** command. To disable link latency for a specific Cisco lightweight access point that is currently associated to the device, use the **no** form of this command.

```
ap name ap-name link-latency
ap name ap-name no link-latency
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.						
Command Default	Link latency is disabled by default.						
Command Modes	Any command mode						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE</td> </tr> <tr> <td></td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE		This command was introduced.
Release	Modification						
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE						
	This command was introduced.						

Usage Guidelines This command enables or disables link latency only for access points that are currently joined to the device. It does not apply to access points that join in the future.

This example shows how to enable link latency on access points:

```
Device# ap name AP2 link-latency
```

ap name location

To modify the descriptive location of a Cisco lightweight access point, use the **ap name location** command.

ap name *ap-name* **location** *location*

Syntax Description

ap-name Name of the Cisco lightweight access point.

location Location name of the access point (enclosed by double quotation marks).

Command Default

None

Command Modes

Any command mode

Command History

Release

Modification

Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE

This command was introduced.

Usage Guidelines

The Cisco lightweight access point must be disabled before changing this parameter.

This example shows how to configure the descriptive location for access point AP1:

```
Device# ap name AP1 location Building1
```

Related Topics

[show ap summary](#), on page 702

ap name mgmtuser

To configure the username, password, and secret password for access point management, use the **ap name mgmtuser** command. To force a specific access point to use the device's global credentials, use the **no** form of this command.

```
ap name ap-name mgmtuser username username password password secret secret
ap name ap-name no mgmtuser
```

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.
username	Specifies the username for access point management.
<i>username</i>	Management username.
password	Specifies the password for access point management.
<i>password</i>	Access point management password.
secret	Specifies the secret password for privileged access point management.
<i>secret</i>	Access point management secret password.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines To specify a strong password, you should adhere to the following requirements:

- The password should contain characters from at least three of the following classes: lowercase letters, uppercase letters, digits, and special characters.
- No character in the password can be repeated more than three times consecutively.
- The password cannot contain a management username or the reverse of a username.
- The password cannot contain words such as Cisco, oscic, admin, nimda or any variant obtained by changing the capitalization of letters by substituting l, |, or ! or substituting 0 for o or substituting \$ for s.

The following requirement is enforced on the secret password:

- The secret password cannot contain characters from at least three of the following classes: lowercase letters, uppercase letters, digits, or special characters.

This example shows how to add a username, password, and secret password for access point management:

```
Device# ap name AP01 mgmtuser username acd password Arc_1234 secret Mid_1234
```

ap name mode

To change a Cisco device communication option for an individual Cisco lightweight access point, use the **ap name mode** command.

```
ap name ap-name mode {local submode {none | wips} | monitor submode {none | wips} | rogue |
se-connect | sniffer}
```

Syntax Description	ap-name	Name of the Cisco lightweight access point.
local		Converts from an indoor mesh access point (MAP or RAP) to a nonmesh lightweight access point (local mode).
submode		Specifies wIPS submode on an access point.
none		Disables the wIPS on an access point.
monitor		Specifies monitor mode settings.
wips		Enables the wIPS submode on an access point.
rogue		Enables wired rogue detector mode on an access point.
se-connect		Enables spectrum expert mode on an access point.
sniffer		Enables wireless sniffer mode on an access point.

Command Default Local

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The sniffer mode captures and forwards all the packets from the clients on that channel to a remote machine that runs AiroPeek or other supported packet analyzer software. It includes information on the timestamp, signal strength, packet size and so on.

This example shows how to set the device to communicate with access point AP01 in local mode:

```
Device# ap name AP01 mode local submode none
```

This example shows how to set the device to communicate with access point AP01 in a wired rogue access point detector mode:

```
Device# ap name AP01 mode rogue
```

This example shows how to set the device to communicate with access point AP02 in wireless sniffer mode:

```
Device# ap name AP02 mode sniffer
```

Related Topics

[show ap monitor-mode summary](#), on page 658

ap name monitor-mode

To configure Cisco lightweight access point channel optimization, use the **ap name monitor-mode** command.

ap name *ap-name* **monitor-mode** {**no-optimization** | **tracking-opt** | **wips-optimized**}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
no-optimization	Specifies no channel scanning optimization for the access point.
tracking-opt	Enables tracking optimized channel scanning for the access point.
wips-optimized	Enables wIPS optimized channel scanning for the access point.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure a Cisco wireless intrusion prevention system (wIPS) monitor mode on access point AP01:

```
Device# ap name AP01 monitor-mode wips
```

Related Topics

[show ap monitor-mode summary](#), on page 658

[show ap config](#), on page 633

ap name monitor-mode dot11b

To configure 802.11b scanning channels for a monitor-mode access point, use the **ap name monitor-mode dot11b** command.

ap name *ap-name* **monitor-mode dot11b fast-channel** *channel1* [*channel2*] [*channel3*] [*channel4*]

Syntax Description	
<i>ap-name</i>	Name of the access point.
fast-channel	Specifies the 2.4 GHz band scanning channel (or channels) for a monitor-mode access point.
<i>channel1</i>	Scanning channel1.
<i>channel2</i>	(Optional) Scanning channel2.
<i>channel3</i>	(Optional) Scanning channel3.
<i>channel4</i>	(Optional) Scanning channel4.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to configure an access point in tracking optimized mode to listen to channels 1, 6, and 11:

```
Device# ap name AP01 monitor-mode dot11b fast-channel 1 6 11
```

Related Topics

[show ap monitor-mode summary](#), on page 658

ap name name

To modify the name of a Cisco lightweight access point, use the **ap name name** command.

```
ap name ap-name name new-name
```

Syntax Description

ap-name Current Cisco lightweight access point name.

new-name Desired Cisco lightweight access point name.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
	This command was introduced.

This example shows how to modify the name of access point AP1 to AP2:

```
Device# ap name AP1 name AP2
```

Related Topics

[show ap config](#), on page 633

ap name no dot11 shutdown

To enable radio transmission for an individual Cisco radio on an 802.11 network, use the **ap name no dot11 shutdown** command.

ap name *ap-name* **no dot11** {24ghz | 5ghz} **shutdown**

Syntax Description

ap-name Name of the Cisco lightweight access point.

24ghz Specifies the 2.4 GHz radios.

5ghz Specifies the 5 GHz radios.

Command Default

The transmission is enabled for the entire network by default.

Command Modes

Any command mode

Command History

Release

Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE

Modification

This command was introduced.

Usage Guidelines



Note

Use this command with the **ap name Cisco-AP dot11 5ghz shutdown** command when configuring 802.11 settings.

This command can be used any time that the CLI interface is active.

This example shows how to enable radio transmission on the 5 GHz band for access point AP1:

```
Device# ap name AP1 no dot11 5ghz shutdown
```

ap name power

To enable the Cisco Power over Ethernet (PoE) feature for access points, use the **ap name power** command. To disable the Cisco PoE feature for access points, use the **no** form of this command.

```
ap name ap-name power {injector | pre-standard}
ap name ap-name no power {injector | pre-standard}
```

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
injector	Specifies the power injector state for an access point.
pre-standard	Enables the inline power Cisco prestandard switch state for an access point.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
	This command was introduced.

This example shows how to enable the power injector state for all access points:

```
Device# ap name AP01 power injector
```

This example shows how to enable the inline power Cisco prestandard switch state for access point AP02:

```
Device# ap name AP02 power pre-standard
```

ap name shutdown

To disable a Cisco lightweight access point, use the **ap name shutdown** command. To enable a Cisco lightweight access point, use the **no** form of this command.

```
ap name ap-name shutdown
ap name ap-name no shutdown
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.	
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to disable a specific Cisco lightweight access point:

```
Device# ap name AP2 shutdown
```

ap name slot shutdown

To disable a slot on a Cisco lightweight access point, use the **ap name slot shutdown** command. To enable a slot on a Cisco lightweight access point, use the **no** form of the command.

```
ap name ap-name slot {0 | 1 | 2 | 3} shutdown
ap name ap-name no slot {0 | 1 | 2 | 3} shutdown
```

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
0	Enables slot number 0 on a Cisco lightweight access point.
1	Enables slot number 1 on a Cisco lightweight access point.
2	Enables slot number 2 on a Cisco lightweight access point.
3	Enables slot number 3 on a Cisco lightweight access point.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to enable slot 0 on a Cisco access point named TSIM_AP2:

```
Device# ap name TSIM_AP2 no slot 0 shutdown
```

ap name sniff

To enable sniffing on an access point, use the **ap name sniff** command. To disable sniffing on an access point, use the **no** form of this command.

```
ap name ap-name sniff {dot11a | dot11b}
ap name ap-name no sniff {dot11a | dot11b}
```

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
dot11a	Specifies the 2.4 GHz band.
dot11b	Specifies the 5 GHz band.
<i>channel</i>	Valid channel to be sniffed. For the 5 GHz band, the range is 36 to 165. For the 2.4 GHz band, the range is 1 to 14.
<i>server-ip-address</i>	IP address of the remote machine running Omnippeek, Airoppeek, AirMagnet, or Wireshark software.

Command Default

Channel 36

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

When the sniffer feature is enabled on an access point, it starts sniffing the signal on the given channel. It captures and forwards all the packets to the remote computer that runs Omnippeek, Airoppeek, AirMagnet, or Wireshark software. It includes information about the timestamp, signal strength, packet size and so on.

Before an access point can act as a sniffer, a remote computer that runs one of the listed packet analyzers must be set up so that it can receive packets that are sent by the access point.

This example shows how to enable the sniffing on the 5 GHz band for an access point on the primary wireless LAN controller:

```
Device# ap name AP2 sniff dot11a 36 192.0.2.54
```

ap name ssh

To enable Secure Shell (SSH) connectivity on a specific Cisco lightweight access point, use the **ap name ssh** command. To disable SSH connectivity on a specific Cisco lightweight access point, use the **no** form of this command.

```
ap name ap-name ssh
ap name ap-name no ssh
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.	
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The Cisco lightweight access point associates with this Cisco device for all network operations and in the event of a hardware reset.

This example shows how to enable SSH connectivity on access point Cisco_ap2:

```
Device# ap name Cisco_ap2 ssh
```

ap name telnet

To enable Telnet connectivity on an access point, use the **ap name telnet** command. To disable Telnet connectivity on an access point, use the **no** form of this command.

```
ap name ap-name telnet
ap name ap-name no telnet
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to disable Telnet connectivity on access point cisco_ap1:

```
Device# ap name cisco_ap1 no telnet
```

ap name power injector

To configure the power injector state for an access point, use the **ap name power injector** command. To disable the Cisco Power over Ethernet (PoE) feature for access points, use the **no** form of this command.

```
ap name ap-name power injector {installed | override | switch-mac-address switch-MAC-address}
ap name ap-name no power injector
```

Syntax Description		
	<i>ap-name</i>	Name of the Cisco lightweight access point.
	installed	Detects the MAC address of the current switch port that has a power injector.
	override	Overrides the safety checks and assumes a power injector is always installed.
	switch-mac-address	Specifies the MAC address of the switch port with an installed power injector.
	<i>switch-MAC-address</i>	MAC address of the switch port with an installed power injector.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to enable the power injector state for an access point:

```
Device# ap name AP01 power injector switch-mac-address aaaa.bbbb.cccc
```

ap name power pre-standard

To enable the inline power Cisco prestandard switch state for an access point, use the **ap name power pre-standard** command. To disable the inline power Cisco prestandard switch state for an access point, use the **no** form of this command.

```
ap name ap-name power pre-standard
ap name ap-name no power pre-standard
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to enable the inline power Cisco prestandard switch state for access point AP02:

```
Device# ap name AP02 power pre-standard
```

This example shows how to disable the inline power Cisco prestandard switch state for access point AP02:

```
Device# ap name AP02 no power pre-standard
```

ap name reset-button

To configure the Reset button for an access point, use the **ap name reset-button** command.

```
ap name ap-name reset-button
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE 3.3SE</td><td>Cisco IOS XE 3.3SE This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to enable the Reset button for access point AP03:

```
Device# ap name AP03 reset-button
```

ap name reset

To reset a specific Cisco lightweight access point, use the **ap name reset** command.

ap name *ap-name* **reset**

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to reset a Cisco lightweight access point named AP2:

```
Device# ap name AP2 reset
```

Related Topics

[show ap config](#), on page 633

ap name slot

To configure various slot parameters, use the **ap name slot** command. To disable a slot on a Cisco lightweight access point, use the **no** form of this command.

```
ap name ap-name slot slot-number {channel {global | number channel-number | width channel-width}
| rtsthreshold value | shutdown | txpower {globalchannel-level}}
ap name ap-name no slot {0 | 1 | 2 | 3} shutdown
```

Syntax Description					
<i>ap-name</i>	Name of the Cisco access point.				
<i>slot-number</i>	Slot downlink radio to which the channel is assigned. You can specify the following slot numbers: <ul style="list-style-type: none"> • 0—Enables slot number 0 on a Cisco lightweight access point. • 1—Enables slot number 1 on a Cisco lightweight access point. • 2—Enables slot number 2 on a Cisco lightweight access point. • 3—Enables slot number 3 on a Cisco lightweight access point. 				
channel	Specifies the channel for the slot.				
global	Specifies channel global properties for the slot.				
number	Specifies the channel number for the slot.				
<i>channel-number</i>	Channel number from 1 to 169.				
width	Specifies the channel width for the slot.				
<i>channel-width</i>	Channel width from 20 to 40.				
rtsthreshold	Specifies the RTS/CTS threshold for an access point.				
<i>value</i>	RTS/CTS threshold value from 0 to 65535.				
shutdown	Shuts down the slot.				
txpower	Specifies Tx power for the slot.				
global	Specifies auto-RF for the slot.				
<i>channel-level</i>	Transmit power level for the slot from 1 to 7.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to enable slot 3 for the access point abc:

```
Device# ap name abc slot 3
```

This example shows how to configure RTS for the access point abc:

```
Device# ap name abc slot 3 rtsthreshold 54
```

ap name static-ip

To configure lightweight access point static IP settings, use the **ap name static-ip** command. To disable the Cisco lightweight access point static IP address, use the **no** form of this command.

```
ap name ap-name static-ip {domain domain-name | ip-address ip-address netmask netmask gateway
gateway | nameserver ip-address}
ap name ap-name no static-ip
```

Syntax Description		
	<i>ap-name</i>	Name of the access point.
	domain	Specifies the Cisco access point domain name.
	<i>domain-name</i>	Domain to which a specific access point belongs.
	ip-address	Specifies the Cisco access point static IP address.
	<i>ip-address</i>	Cisco access point static IP address.
	netmask	Specifies the Cisco access point static IP netmask.
	<i>netmask</i>	Cisco access point static IP netmask.
	gateway	Specifies the Cisco access point gateway.
	<i>gateway</i>	IP address of the Cisco access point gateway.
	nameserver	Specifies a DNS server so that a specific access point can discover the device using DNS resolution.
	<i>ip-address</i>	IP address of the DNS server.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines An access point cannot discover the device using Domain Name System (DNS) resolution if a static IP address is configured for the access point unless you specify a DNS server and the domain to which the access point belongs.

This example shows how to configure an access point static IP address:

```
Device# ap name AP2 static-ip ip-address 192.0.2.54 netmask 255.255.255.0 gateway 192.0.2.1
```

ap name stats-timer

To set the time in seconds that the Cisco lightweight access point sends its DOT11 statistics to the Cisco device, use the **ap name stats-timer** command.

ap name *ap-name* **stats-timer** *timer-value*

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
	<i>timer-value</i>	Time in seconds from 0 to 65535. A zero value disables the timer.
Command Default	0 (Disabled).	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines A value of 0 (zero) means that the Cisco lightweight access point does not send any DOT11 statistics. The acceptable range for the timer is from 0 to 65535 seconds, and the Cisco lightweight access point must be disabled to set this value.

This example shows how to set the stats timer to 600 seconds for access point AP2:

```
Device# ap name AP2 stats-timer 600
```

ap name syslog host

To configure a syslog server for a specific Cisco lightweight access point, use the **ap name syslog host** command.

ap name *ap-name* **syslog host** *syslog-host-ip-address*

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
	<i>syslog-host-ip-address</i>	IP address of the syslog server.
Command Default	255.255.255.255	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines By default, the syslog server IP address for each access point is 255.255.255.255, which indicates that it is not yet set. When the default value is used, the global access point syslog server IP address is pushed to the access point.

This example shows how to configure a syslog server:

```
Device# ap name AP2 syslog host 192.0.2.54
```

Related Topics

[ap syslog](#), on page 613

[show ap config](#), on page 633

[show ap name config](#), on page 672

ap name syslog level

To configure the system logging level, use the **ap name syslog level** command.

```
ap name ap-name syslog level {alert | critical | debug | emergency | errors | information | notification | warning}
```

Syntax Description		
	<i>ap-name</i>	Name of the Cisco lightweight access point.
	alert	Specifies alert level system logging.
	critical	Specifies critical level system logging.
	debug	Specifies debug level system logging.
	emergency	Specifies emergency level system logging.
	errors	Specifies error level system logging.
	information	Specifies information level system logging.
	notification	Specifies notification level system logging.
	warning	Specifies warning level system logging.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure alert level system logging:

```
Device# ap name AP2 syslog level alert
```

ap name tcp-adjust-mss

To enable or disable the TCP maximum segment size (MSS) on a particular access point, use the **ap name tcp-adjust-mss** command. To disable the TCP maximum segment size (MSS) on a particular access point, use the **no** form of this command.

```
ap name ap-name tcp-adjust-mss size size
ap name ap-name no tcp-adjust-mss
```

Syntax Description	<i>ap-name</i> Name of the access point.
	<i>size</i> Maximum segment size, from 536 to 1363 bytes.

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

When you enable this feature, the access point checks for TCP packets to and from wireless clients in its data path. If the MSS of these packets is greater than the value that you configured or greater than the default value for the Control and Provisioning of Wireless Access Points (CAPWAP) tunnel, the access point changes the MSS to the new configured value. If the MSS of these packets is greater than the value that you have configured or greater than the default value for the CAPWAP tunnel, the access point changes the MSS to the newly configured value.

This example shows how to enable the TCP MSS on access point Cisco_ap1:

```
Device# ap name ciscoap tcp-adjust-mss size 1200
```

Related Topics

[show ap name tcp-adjust-mss](#), on page 697

ap name tftp-downgrade

To configure the settings used for downgrading a lightweight access point to an autonomous access point, use the **ap name tftp-downgrade** command.

ap name *ap-name* **tftp-downgrade** *tftp-server-ip* *filename*

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
	<i>tftp-server-ip</i>	IP address of the TFTP server.
	<i>filename</i>	Filename of the access point image file on the TFTP server.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to configure the settings for downgrading access point AP1:

```
Device# ap name Ap01 tftp-downgrade 172.21.12.45 ap3g1-k9w7-tar.124-25d.JA.tar
```

ap power injector

To configure the power injector state for all the Cisco lightweight access points that are joined to the device, use the **ap power injector** command. To delete the power injector state for all access points, use the **no** form of this command.

```
ap power injector {installed | override | switch-mac-address switch-MAC-addr}
no ap power injector
```

Syntax Description		
installed	Detects the MAC address of the current switch port that has a power injector.	
override	Overrides the safety checks and assumes a power injector is always installed.	
switch-mac-address	Specifies the MAC address of the switch port with an installed power injector.	
<i>switch-MAC-address</i>	Specifies the MAC address of the switch port with an installed power injector.	
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to enable the power injector state for all the Cisco lightweight access points that are joined to the device:

```
Device(config)# ap power injector switch-mac-address aaaa.bbbb.cccc
```

ap power pre-standard

To set the Cisco lightweight access points that are joined to the device to be powered by a high-power Cisco switch, use the **ap power pre-standard** command. To disable the pre standard power for all access points, use the **no** form of this command.

```
ap power pre-standard
no ap power pre-standard
```

Syntax Description	This command has no keywords and arguments.	
Command Default	Disabled	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to enable the inline power Cisco prestandard switch state for access point AP02:

```
Controller(config)# ap power pre-standard
```

ap reporting-period

To configure the access point rogue/error reporting period, use the **ap reporting-period** command. To disable the access point rogue/error reporting period, use the **no** form of this command.

ap reporting-period *value*
no ap reporting-period

Syntax Description	<i>value</i> Time period in seconds from 10 to 120.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example show how to configure the access point rogue/error reporting:

```
Device(config)# ap reporting-period 100
```

This example show how to disable the access point rogue/error reporting:

```
Device(config)# no ap reporting-period 100
```

ap reset-button

To configure the Reset button for all Cisco lightweight access points that are joined to the device, use the **ap reset-button** command. To disable the Reset button for all access points, use the **no** form of this command.

```
ap reset-button
no ap reset-button
```

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to configure the Reset button for all access points that are joined to the controller:

```
Device(config)# ap reset-button
```

service-policy type control subscriber

To apply the global subscriber control policy, use the **service-policy type control subscriber** *<subscriber-policy-name>* command.

service-policy type control subscriber *<subscriber-policy-name>*

Syntax Description	service-policy	Instructs the access point to apply global subscriber control policy.
	<i><subscriber-policy-name></i>	Name of the subscriber policy.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Example

This example shows how to disable the global subscriber control policy.

```
Device#no service-policy type control subscriber
```

ap static-ip

To configure Cisco lightweight access point static IP address settings, use the **ap static-ip** command. To disable access point static IP settings, use the **no** form of this command.

```
ap static-ip {domain domain-name | name-server ip-address}
no ap static-ip {domain | name-server}
```

Syntax Description	domain	Specifies the domain to which a specific access point or all access points belong.
	<i>domain-name</i>	Domain name.
	name-server	Specifies a DNS server so that a specific access point or all access points can discover the device using DNS resolution.
	<i>ip-address</i>	DNS server IP address.
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Usage Guidelines	An access point cannot discover the device using Domain Name System (DNS) resolution if a static IP address is configured for the access point, unless you specify a DNS server and the domain to which the access point belongs.	

This example shows how to configure a static IP address for all access points:

```
Device(config)# ap static-ip domain cisco.com
```

ap syslog

To configure the system logging settings for all Cisco lightweight access points that are joined to the device, use the **ap syslog** command.

```
ap syslog {host ipaddress | level{alert | critical | debug | emergency | errors | information | notification | warning}}
```

Syntax Description	host	Specifies a global syslog server for all access points that join the device.
	<i>ipaddress</i>	IP address of the syslog server.
level	Specifies the system logging level for all the access points joined to the device.	
alert	Specifies alert level system logging for all Cisco access points.	
critical	Specifies critical level system logging for all Cisco access points.	
debug	Specifies debug level system logging for all Cisco access points.	
emergency	Specifies emergency level system logging for all Cisco access points.	
errors	Specifies errors level system logging for all Cisco access points.	
information	Specifies information level system logging for all Cisco access points.	
notification	Specifies notification level system logging for all Cisco access points.	
warning	Specifies warning level system logging for all Cisco access points.	

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines By default, the global syslog server IP address for all access points is 255.255.255.255. Make sure that the access points can reach the subnet on which the syslog server resides before configuring the syslog server on the device. If the access points cannot reach this subnet, the access points are unable to send out syslog messages.

This example shows how to configure a global syslog server for all access points:

```
Device(config)# ap syslog host 172.21.34.45
```

ap name no controller

To change the order of configured primary, secondary and tertiary wireless LAN controllers use the following commands.

```
ap name ap-name no controller primary
```

```
ap name ap-name no controller secondary
```

```
ap name ap-name no controller tertiary
```

Syntax Description		
	<i>ap- name</i>	Name of the Cisco lightweight access point.
	no controller primary	Instructs the access point to unconfigure the primary controller.
	no controller secondary	Instructs the access point to unconfigure the secondary controller.
	no controller tertiary	Instructs the access point to unconfigure the tertiary controller.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines If you have the primary, secondary, and tertiary wireless LAN controllers configured for an access point and you require swap the controller names and the corresponding IP addresses you can unconfigure the primary and configure the secondary controller.

Example

This example shows how to unconfigure the primary controller.

```
Device# ap name <AP Name> no controller primary.
```

ap tcp-adjust-mss size

To enable the TCP maximum segment size (MSS) on all Cisco lightweight access points, use the **ap tcp-adjust-mss size** command. To disable the TCP maximum segment size (MSS) on all Cisco lightweight access points **no** form of this command.

ap tcp-adjust-mss size *size*
no ap tcp-adjust-mss

Syntax Description	<i>size</i> Maximum segment size, from 536 to 1363 bytes.				
Command Default	None				
Command Modes	Global configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

Usage Guidelines When you enable this feature, the access point checks for TCP packets to and from wireless clients in its data path. If the MSS of these packets is greater than the value that you configured or greater than the default value for the Control and Provisioning of Wireless Access Points (CAPWAP) tunnel, the access point changes the MSS to the new configured value.

This example shows how to enable the TCP MSS on all access points with a segment size of 1200:

```
Device(config)# ap tcp-adjust-mss 1200
```

Related Topics

[show ap name tcp-adjust-mss](#), on page 697

ap tftp-downgrade

To configure the settings used for downgrading a lightweight access point to an autonomous access point, use the **ap tftp-downgrade** command. To disable the settings used for downgrading a lightweight access point to an autonomous access point, use the **no** form of this command.

```
ap tftp-downgrade tftp-server-ip filename
no ap tftp-downgrade
```

Syntax Description	<i>tftp-server-ip</i> IP address of the TFTP server.				
	<i>filename</i> Filename of the access point image file on the TFTP server.				
Command Default	None				
Command Modes	Global configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

This example shows how to configure the settings for downgrading all access points:

```
Device(config)# ap tftp-downgrade 172.21.23.45 ap3g1-k9w7-tar.124-25d.JA.tar
```

config wireless wps rogue client mse

To configure a rogue MSE client, use **wirelesswps rogueclientmse** command.

To view the summary of the wireless client statistics, use **show wirelessclientclient-statisticssummary** command.

wirelesswpsrogueclientmse

showwirelessclientclient-statisticssummary

Syntax Description	Command	Description
	rogueclient mse	Instructs the access point to enable configuring a rogue MSE client.
	nowireless wps	Instructs the access point to disable the configuring a rogue MSE client.
	client-statisticssummary	Instructs to view the summary of the wireless client statistics.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Example

This example shows how to configure a rogue MSE client.

```
Device# wireless wps rogue client mse
```

clear ap name tsm dot11 all

To clear the traffic stream metrics (TSM) statistics for a particular access point or all the access points, use the **clear ap name tsm dot11 all** command.

```
clear ap name ap-name tsm dot11 {24ghz | 5ghz} all
```

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
all	Specifies all access points.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to clear the TSM statistics for an access point on the 2.4 GHz band:

```
Device# clear ap name AP1 tsm dot11 24ghz all
```

clear ap config

To clear (reset to the default values) a lightweight access point's configuration settings, use the **clear ap config** command.

```
clear ap config ap-name [{eventlog | keep-ip-config}]
```

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
	eventlog	(Optional) Deletes the existing event log and creates an empty event log file for a specific access point or for all access points joined to the device.
	keep-ip-config	(Optional) Specifies not to erase the static IP configuration of the Cisco access point.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE

Usage Guidelines Entering this command does not clear the static IP address of the access point.

This example shows how to clear the access point's configuration settings for the access point named AP01:

```
Device# clear ap config AP01
```

Related Topics

[show ap config](#), on page 633

clear ap eventlog-all

To delete the existing event log and create an empty event log file for all access points, use the **clear ap eventlog-all** command.

clear ap eventlog-all

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to delete the event log for all access points:

```
Device# clear ap eventlog-all
```

clear ap join statistics

To clear the join statistics for all access points or for a specific access point, use the **clear ap join statistics** command.

clear ap join statistics

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to clear the join statistics of all the access points:

```
Device# clear ap join statistics
```

clear ap mac-address

To clear the MAC address for the join statistics for a specific Cisco lightweight access point, use the **clear ap mac-address** command.

clear ap mac-address *mac* **join statistics**

Syntax Description	<i>mac</i>	Access point MAC address.
	join statistics	Clears join statistics.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to clear the join statistics of an access point:

```
Device# clear ap mac-address aaaa.bbbb.cccc join statistics
```

clear ap name wlan statistics

To clear WLAN statistics, use the `clear ap name wlan statistics` command.

```
clear ap name ap-name wlan statistics
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.	
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to clear the WLAN configuration elements of the access point `cisco_ap`:

```
Device# clear ap name cisco_ap wlan statistics
```

debug ap mac-address

To enable debugging of access point on the mac-address, use the **debug ap mac-address** command.

```
debug ap mac-address mac-address
no debug ap mac-address mac-address
```

Syntax Description	<i>mac-address</i> Access point Ethernet MAC address or the MAC address of the 802.11 radio interface.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>10.3Cisco IOS XE 3.3 SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	10.3Cisco IOS XE 3.3 SE	This command was introduced.
Release	Modification				
10.3Cisco IOS XE 3.3 SE	This command was introduced.				

This example shows how to enable debugging mac-address on an AP :

```
Device# debug ap mac-address
ap mac-address debugging is on
```

This example shows how to disable debugging mac-address on an AP :

```
Device# no debug ap mac-address
ap mac-address debugging is off
```

show ap cac voice

To display the list of all access points with brief voice statistics, which include bandwidth used, maximum bandwidth available, and the call information, use the **show ap cac voice** command.

show ap cac voice

Syntax Description	This command has no keywords and arguments.	
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display voice CAC details that correspond to Cisco lightweight access points:

```
controller# show ap cac voice
```

```
1) AP Name: AP01
```

```
=====
```

```
Wireless Bandwidth (In MeanTime mt)
```

Slot#	Radio	Calls	BW-Max	BW-Alloc	Bw-InUse (%age)
1	0	802.11b/g	0	23437	0
2	1	802.11a	0	23437	0

```
Wired Bandwidth (in Kbps)
```

Slot#	Wlan-ID	Wlan-Name	BW-Config	BW-Avail
1	0	1	maria-open	0
2	0	12	24	0
3	1	1	maria-open	0
4	1	12	24	0

```
2) AP Name: AP02
```

```
=====
```

```
Wireless Bandwidth (In MeanTime mt)
```

Slot#	Radio	Calls	BW-Max	BW-Alloc	Bw-InUse (%age)
1	0	802.11b/g	0	23437	0
2	1	802.11a	0	23437	0

```
Wired Bandwidth (in Kbps)
```

Slot#	Wlan-ID	Wlan-Name	BW-Config	BW-Avail
-------	---------	-----------	-----------	----------

show ap cac voice

1	0	1	maria-open	0	0
2	0	12	24	0	0
3	1	1	maria-open	0	0
4	1	12	24	0	0

show ap capwap

To display the Control and Provisioning of Wireless Access Points (CAPWAP) configuration that is applied to all access points, use the **show ap capwap** command.

show ap capwap {retransmit | timers | summary}

Syntax Description	retransmit Displays the access point CAPWAP retransmit parameters.				
	timers Displays the rogue access point entry timers.				
	summary Displays the network configuration of the Cisco device.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.				

This example shows how to display the access point CAPWAP retransmit parameters:

```
Controller# show ap capwap retransmit
```

```
Global control packet retransmit interval : 3
Global control packet retransmit count : 5
```

AP Name	Retransmit Interval	Retransmit Count
AP01	3	5
AP02	3	5
AP03	3	5
AP04	3	5
AP05	3	5
AP07	3	5
AP08	3	5
AP09	3	5
AP10	3	5
AP11	3	5
AP12	3	5

This example shows how to display the rogue access point entry timers:

```
Controller# show ap capwap timers
```

```
AP Discovery timer      : 10
AP Heart Beat timeout   : 30
Primary Discovery timer : 120
Primed Join timeout     : 0
Fast Heartbeat          : Disabled
Fast Heartbeat timeout  : 1
```

This example shows how to display the the network configuration of the Cisco device:

```
Controller# show ap capwap summary
```

```
AP Fallback              : Enabled
AP Join Priority          : Disabled
AP Master                : Disabled
Primary backup Controller Name :
Primary backup Controller IP  : 0.0.0.0
Secondary backup Controller Name :
Secondary backup Controller IP  : 0.0.0.0
```

show ap cdp

To display the Cisco Discovery Protocol (CDP) information for all Cisco lightweight access points that are joined to the device, use the **show ap cdp** command.

```
show ap cdp [neighbors [detail]]
```

Syntax Description	
neighbors	(Optional) Displays neighbors using CDP.
detail	(Optional) Displays details about a specific access point neighbor that is using CDP.

Command Default	None
-----------------	------

Command Modes	Any command mode
---------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to display the CDP status of all access points:

```
Device# show ap cdp
```

This example shows how to display details about all neighbors that are using CDP:

```
Device# show ap cdp neighbors
```

Related Topics

[ap cdp](#), on page 480

show ap config dot11

To display the detailed configuration of 802.11-58G radios on Cisco lightweight access points, use the **show ap config dot11** command.

show ap config dot11 58ghz summary

Syntax Description	
58ghz	Displays the 802.11-58G radios.
summary	Displays a summary of the radios on the access points.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to display the detailed configuration of 802.11a-58G radios on access points:

```
Device# show ap config dot11 58ghz summary
```

show ap config dot11 dual-band summary

To view a summary of configuration settings for dual band radios of Cisco APs, use the **show ap config dot11 dual-band summary** command.

show ap config dot11 dual-band summary

Syntax Description	dual-band Specifies the dual band radio.				
	summary Displays a summary of configuration settings for dual band radios of Cisco APs.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE 3.3SE</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

show ap config fnf

To view Netflow input and output monitors for all Cisco APs, use the **show ap config fnf** command.

show ap config fnf

Syntax Description	fnf Netflow input and output monitors for all Cisco APs.	
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

show ap config

To display configuration settings for all access points that join the device, use the **show ap config** command.

```
show ap config {ethernet | general | global}
```

Syntax Description

ethernet Displays ethernet VLAN tagging information for all Cisco APs.

general Displays common information for all Cisco APs.

global Displays global settings for all Cisco APs.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display global syslog server settings:

```
Device# show ap config global
```

```
AP global system logging host                : 255.255.255.255
```

show ap crash-file

To display the list of both crash and radio core dump files generated by lightweight access points, use the **show ap crash-file** command.

show ap crash-file

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to display the crash file generated by the access point:

```
Device# show ap crash-file
```

Related Topics

[ap crash-file](#), on page 483

show ap data-plane

To display the data plane status, use the **show ap data-plane** command.

show ap data-plane

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example show how to display the data plane status for all access points:

```
Device# show ap data-plane
```

show ap dot11 l2roam

To display 802.11a or 802.11b/g Layer 2 client roaming information, use the **show ap dot11 l2roam** command.

show ap dot11 {24ghz | 5ghz} **l2roam** {**mac-address** *mac-address* **statistics** | **rf-param** | **statistics**}

Syntax Description		
24ghz		Specifies the 2.4 GHz band.
5ghz		Specifies the 5 GHz band.
mac-address <i>mac-address</i> statistics		Specifies the MAC address of a Cisco lightweight access point.
rf-param		Specifies the Layer 2 frequency parameters.
statistics		Specifies the Layer 2 client roaming statistics.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display 802.11b Layer 2 client roaming information:

```
Device# show ap dot11 24ghz l2roam rf-param
```

```
L2Roam 802.11bg RF Parameters
  Config Mode       : Default
  Minimum RSSI      : -85
  Roam Hysteresis   : 2
  Scan Threshold     : -72
  Transition time    : 5
```

show ap dot11 cleanair air-quality

To display the air-quality summary information and air-quality worst information for the 802.11 networks, use the **show ap dot11 cleanair air-quality** command.

```
show ap dot11 {24ghz | 5ghz} cleanair air-quality {summary | worst}
```

Syntax Description	24ghz	Displays the 2.4 GHz band.
	5ghz	Displays the 5 GHz band.
	summary	Displays a summary of 802.11 radio band air-quality information.
	worst	Displays the worst air-quality information for 802.11 networks.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display the worst air-quality information for the 5 GHz band:

```
Device# show ap dot11 5ghz cleanair air-quality worst
```

```
AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
-----
CISCO_AP3500 36      95      70      0          40
```

This example shows how to display the worst air-quality information for the 2.4 GHz band:

```
Device# show ap dot11 24ghz cleanair air-quality worst
```

```
AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
-----
CISCO_AP3500 1       83      57      3          5
```

show ap dot11 cleanair config

To display the CleanAir configuration for the 802.11 networks, use the **show ap dot11 cleanair config** command.

show ap dot11 {24ghz|5ghz} cleanair config

Syntax Description	24ghz Displays the 2.4 GHz band.				
	5ghz Displays the 5 GHz band.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

This example shows how to display the CleanAir configuration for the 2.4 GHz band:

```
Device# show ap dot11 24ghz cleanair config
Clean Air Solution..... : Disabled
Air Quality Settings:
  Air Quality Reporting..... : Disabled
  Air Quality Reporting Period (min)..... : 15
  Air Quality Alarms..... : Enabled
  Air Quality Alarm Threshold..... : 10
Interference Device Settings:
  Interference Device Reporting..... : Enabled
  Bluetooth Link..... : Enabled
  Microwave Oven..... : Enabled
  802.11 FH..... : Enabled
  Bluetooth Discovery..... : Enabled
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  802.15.4..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  Microsoft Device..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
Interference Device Types Triggering Alarms:
  Bluetooth Link..... : Disabled
  Microwave Oven..... : Disabled
  802.11 FH..... : Disabled
  Bluetooth Discovery..... : Disabled
  TDD Transmitter..... : Disabled
  Jammer..... : Disabled
  Continuous Transmitter..... : Disabled
  DECT-like Phone..... : Disabled
```

```
Video Camera..... : Disabled
802.15.4..... : Disabled
WiFi Inverted..... : Enabled
WiFi Invalid Channel..... : Enabled
SuperAG..... : Disabled
Canopy..... : Disabled
Microsoft Device..... : Disabled
WiMax Mobile..... : Disabled
WiMax Fixed..... : Disabled
Interference Device Alarms..... : Enabled
Additional Clean Air Settings:
CleanAir Event-driven RRM State..... : Disabled
CleanAir Driven RRM Sensitivity..... : LOW
CleanAir Persistent Devices state..... : Disabled
```

show ap dot11 cleanair summary

To view CleanAir configurations for all 802.11a Cisco APs, use the **show ap dot11 cleanair summary** command.

show ap dot11 {24ghz | 5ghz} cleanair summary

Syntax Description	24ghz	Specifies the 2.4-GHz band
	5ghz	Specifies the 5-GHz band
	cleanair summary	Summary of CleanAir configurations for all 802.11a Cisco APs
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

show ap dot11

To view 802.11a or 802.11b configuration information, use the **show ap dot11** command.

```
show ap dot11 {24ghz | 5ghz} {channel | coverage | group | load-info | logging | media-stream | monitor | network | profile | receiver | service-policy | summary | txpower | ccx global}
```

Syntax	Description
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
channel	Displays the automatic channel assignment configuration and statistics.
coverage	Displays the configuration and statistics for coverage hole detection.
group	Displays 802.11a or 802.11b Cisco radio RF grouping.
load-info	Displays channel utilization and client count information for all Cisco APs.
logging	Displays 802.11a or 802.11b RF event and performance logging.
media-stream	Display 802.11a or 802.11b Media Resource Reservation Control configurations.
monitor	Displays the 802.11a or 802.11b default Cisco radio monitoring.
network	Displays the 802.11a or 802.11b network configuration.
profile	Displays the 802.11a or 802.11b lightweight access point performance profiles.
receiver	Displays the configuration and statistics of the 802.11a or 802.11b receiver.
service-policy	Displays the Quality of Service (QoS) service policies for 802.11a or 802.11b radio for all Cisco access points.
summary	Displays the 802.11a or 802.11b Cisco lightweight access point name, channel, and transmit level summary.
txpower	Displays the 802.11a or 802.11b automatic transmit power assignment.
ccx global	Displays 802.11a or 802.11b Cisco Client eXtensions (CCX) information for all Cisco access points that are joined to the device.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
	Cisco IOS XE 3.3SE	The load-info parameter was added.

This example shows how to display the automatic channel assignment configuration and statistics:

```

Device# show ap dot11 5ghz channel
Automatic Channel Assignment
Channel Assignment Mode           : AUTO
Channel Update Interval          : 12 Hours
Anchor time (Hour of the day)    : 20
Channel Update Contribution      : SNI.
Channel Assignment Leader        : web (9.9.9.2)
Last Run                         : 13105 seconds ago
DCA Sensitivity Level            : MEDIUM (15 dB)
DCA 802.11n Channel Width        : 40 Mhz
Channel Energy Levels
  Minimum                        : unknown
  Average                       : unknown
  Maximum                       : unknown
Channel Dwell Times
  Minimum                       : unknown
  Average                       : unknown
  Maximum                       : unknown
802.11a 5 GHz Auto-RF Channel List
Allowed Channel List              : 36,40,44,48,52,56,60,64,149,153,1
57,161
Unused Channel List              : 100,104,108,112,116,132,136,140,1
65
802.11a 4.9 GHz Auto-RF Channel List
Allowed Channel List              :
Unused Channel List              : 1,2,3,4,5,6,7,8,9,10,11,12,13,14,
15,16,17,18,19,20,21,22,23,24,25,26
DCA Outdoor AP option            : Disabled

```

This example shows how to display the statistics for coverage hole detection:

```

Device# show ap dot11 5ghz coverage
Coverage Hole Detection
802.11a Coverage Hole Detection Mode : Enabled
802.11a Coverage Voice Packet Count  : 100 packet(s)
802.11a Coverage Voice Packet Percentage : 50 %
802.11a Coverage Voice RSSI Threshold : -80dBm
802.11a Coverage Data Packet Count   : 50 packet(s)
802.11a Coverage Data Packet Percentage : 50 %
802.11a Coverage Data RSSI Threshold : -80dBm
802.11a Global coverage exception level : 25
802.11a Global client minimum exception level : 3 clients

```

This example shows how to display Cisco radio RF group settings:

```

Device# show ap dot11 5ghz group
Radio RF Grouping
802.11a Group Mode                : STATIC

```

```

802.11a Group Update Interval      : 600 seconds
802.11a Group Leader              : web (10.10.10.1)
802.11a Group Member              : web(10.10.10.1)
                                   nb1(172.13.21.45) (*Unreachable)
802.11a Last Run                  : 438 seconds ago

```

Mobility Agents RF membership information

```
-----
No of 802.11a MA RF-members : 0
```

This example shows how to display 802.11a RF event and performance logging:

```

Device# show ap dot11 5ghz logging
RF Event and Performance Logging

Channel Update Logging           : Off
Coverage Profile Logging         : Off
Foreign Profile Logging          : Off
Load Profile Logging             : Off
Noise Profile Logging            : Off
Performance Profile Logging      : Off
TxPower Update Logging          : Off

```

This example shows how to display the 802.11a media stream configuration:

```

Device# show ap dot11 5ghz media-stream
Multicast-direct                 : Disabled
Best Effort                      : Disabled
Video Re-Direct                 : Disabled
Max Allowed Streams Per Radio    : Auto
Max Allowed Streams Per Client   : Auto
Max Video Bandwidth              : 0
Max Voice Bandwidth              : 75
Max Media Bandwidth              : 85
Min PHY Rate (Kbps)              : 6000
Max Retry Percentage              : 80

```

This example shows how to display the radio monitoring for the 802.11b network:

```

Device# show ap dot11 5ghz monitor
Default 802.11a AP monitoring

802.11a Monitor Mode              : Enabled
802.11a Monitor Mode for Mesh AP Backhaul : disabled
802.11a Monitor Channels          : Country channels
802.11a RRM Neighbor Discover Type : Transparent
802.11a AP Coverage Interval      : 180 seconds
802.11a AP Load Interval          : 60 seconds
802.11a AP Noise Interval         : 180 seconds
802.11a AP Signal Strength Interval : 60 seconds

```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```

Device# show ap dot11 5ghz profile
Default 802.11a AP performance profiles
802.11a Global Interference threshold..... 10%
802.11a Global noise threshold..... -70 dBm
802.11a Global RF utilization threshold..... 80%
802.11a Global throughput threshold..... 1000000 bps
802.11a Global clients threshold..... 12 clients
802.11a Global coverage threshold..... 12 dB

```

```
802.11a Global coverage exception level..... 80%
802.11a Global client minimum exception lev..... 3 clients
```

This example shows how to display the network configuration of an 802.11a profile:

```
Device# show ap dot11 5ghz network
```

```
802.11a Network : Enabled
11nSupport : Enabled
  802.11a Low Band : Enabled
  802.11a Mid Band : Enabled
  802.11a High Band : Enabled
```

```
802.11a Operational Rates
```

```
  802.11a 6M : Mandatory
  802.11a 9M : Supported
  802.11a 12M : Mandatory
  802.11a 18M : Supported
  802.11a 24M : Mandatory
  802.11a 36M : Supported
  802.11a 48M : Supported
  802.11a 54M : Supported
```

```
802.11n MCS Settings:
```

```
  MCS 0 : Supported
  MCS 1 : Supported
  MCS 2 : Supported
  MCS 3 : Supported
  MCS 4 : Supported
  MCS 5 : Supported
  MCS 6 : Supported
  MCS 7 : Supported
  MCS 8 : Supported
  MCS 9 : Supported
  MCS 10 : Supported
  MCS 11 : Supported
  MCS 12 : Supported
  MCS 13 : Supported
  MCS 14 : Supported
  MCS 15 : Supported
  MCS 16 : Supported
  MCS 17 : Supported
  MCS 18 : Supported
  MCS 19 : Supported
  MCS 20 : Supported
  MCS 21 : Supported
  MCS 22 : Supported
  MCS 23 : Supported
```

```
802.11n Status:
```

```
  A-MPDU Tx:
    Priority 0 : Enabled
    Priority 1 : Disabled
    Priority 2 : Disabled
    Priority 3 : Disabled
    Priority 4 : Enabled
    Priority 5 : Enabled
    Priority 6 : Disabled
    Priority 7 : Disabled
```

```
  A-MSDU Tx:
```

```
    Priority 0 : Enabled
    Priority 1 : Enabled
    Priority 2 : Enabled
    Priority 3 : Enabled
    Priority 4 : Enabled
    Priority 5 : Enabled
    Priority 6 : Disabled
```

```

Priority 7 : Disabled
Guard Interval : Any
Rifs Rx : Enabled
Beacon Interval : 100
CF Pollable mandatory : Disabled
CF Poll Request Mandatory : Disabled
CFP Period : 4
CFP Maximum Duration : 60
Default Channel : 36
Default Tx Power Level : 1
DTPC Status : Enabled
Fragmentation Threshold : 2346
Pico-Cell Status : Disabled
Pico-Cell-V2 Status : Disabled
TI Threshold : 0
Legacy Tx Beamforming setting : Disabled
Traffic Stream Metrics Status : Disabled
Expedited BW Request Status : Disabled
EDCA profile type check : default-wmm
Call Admission Control (CAC) configuration
Voice AC
  Voice AC - Admission control (ACM) : Disabled
  Voice Stream-Size : 84000
  Voice Max-Streams : 2
  Voice Max RF Bandwidth : 75
  Voice Reserved Roaming Bandwidth : 6
  Voice Load-Based CAC mode : Enabled
  Voice tspec inactivity timeout : Enabled
CAC SIP-Voice configuration
  SIP based CAC : Disabled
  SIP call bandwidth : 64
  SIP call bandwidth sample-size : 20
Video AC
  Video AC - Admission control (ACM) : Disabled
  Video max RF bandwidth : Infinite
  Video reserved roaming bandwidth : 0

```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```

Device# show ap dot11 5ghz receiver
Default 802.11a AP performance profiles
802.11a Global Interference threshold..... 10%
802.11a Global noise threshold..... -70 dBm
802.11a Global RF utilization threshold..... 80%
802.11a Global throughput threshold..... 1000000 bps
802.11a Global clients threshold..... 12 clients
802.11a Global coverage threshold..... 12 dB
802.11a Global coverage exception level..... 80%
802.11a Global client minimum exception lev..... 3 clients

```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```

Device# show ap dot11 5ghz service-policy

```

This example shows how to display a summary of the 802.11b access point settings:

```

Device# show ap dot11 5ghz summary
AP Name MAC Address      Admin State Operation State Channel TxPower
-----
CJ-1240 00:21:1b:ea:36:60  ENABLED    UP              161      1( )
CJ-1130 00:1f:ca:cf:b6:60  ENABLED    UP              56*     1(*)

```

This example shows how to display the configuration and statistics of the 802.11a transmit power cost:

```
Device# show ap dot11 5ghz txpower
Automatic Transmit Power Assignment

Transmit Power Assignment Mode      : AUTO
Transmit Power Update Interval      : 600 seconds
Transmit Power Threshold             : -70 dBm
Transmit Power Neighbor Count       : 3 APs
Min Transmit Power                   : -10 dBm
Max Transmit Power                   : 30 dBm
Transmit Power Update Contribution   : SNI.
Transmit Power Assignment Leader     : web (10.10.10.1)
Last Run                             : 437 seconds ago
```

This example shows how to display the configuration and statistics of the 802.11a transmit power cost:

```
Device# show ap dot11 5ghz ccx global
802.11a Client Beacon Measurements:
  disabled
```

Related Topics

[ap dot11 rrm channel dca](#), on page 520

show ap env summary

To show ap environment summary, use the **show ap env summary** command.

There is no keyword or argument.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.7.0 E	This command was introduced.

This example shows how to show ap environment summary:

```
Device#show ap env summary
```

show ap ethernet statistics

To display Ethernet statistics for all Cisco lightweight access points, use the **show ap ethernet statistics** command.

show ap ethernet statistics

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to display Ethernet statistics for all access points:

```
Device# show ap ethernet statistics
```

show ap gps-location summary

To show GPS location summary of all connected Cisco APs, use the **show ap gps-location summary** command.

There is no keyword or argument.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.7.0 E	This command was introduced.

This example shows how to show GPS location summary of all connected Cisco APs:

```
Device# show ap gps-location summary
```

show ap groups

To display information about all access point groups that are defined in the system, use the **show ap groups** command.

show ap groups

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to display information about all access point groups:

```
Device# show ap groups
```

show ap groups extended

To view information about all AP groups defined in the system in detail, use the **show ap groups extended** command.

show ap groups extended

Syntax Description	extended Displays information about all AP groups defined in the system in detail.				
Command Default	None				
Command Modes	Privileged EXEC				
Command History	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE 3.3SE</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

show ap image

To display the images present on Cisco lightweight access points, use the **show ap image** command.

show ap image

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display images on the access points:

```
Device# show ap image
```

show ap is-supported

To see if an AP model is supported or not, use the **show ap is-supported** command.

show ap is-supported *model-part-number*

Syntax Description	<i>model-part-number</i> Part number of the AP model. For example, AIR-LAP1142N-N-K9.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE 3.7.0E</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE 3.7.0E	This command was introduced.
Release	Modification				
Cisco IOS XE 3.7.0E	This command was introduced.				

This example shows how to check if an AP model is supported or not:

```
Device# show ap is-supported AIR-LAP1142N-N-K9
AP Support: Yes
```

show ap join stats summary

To display the last join error detail for a specific access point, use the **show ap join stats summary** command.

show ap join stats summary

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines	To obtain the MAC address of the 802.11 radio interface, enter the show interface command on the access point.
-------------------------	---

This example shows how to display specific join information for an access point:

```
Device# show ap join stats summary
Number of APs : 1
```

Base MAC	Ethernet MAC	AP Name	IP Address	Status
c8f9.f91a.aa80	0000.0000.0000	N A	0.0.0.0	Not Joined

show ap link-encryption

To display the link encryption status, use the **show ap link-encryption** command.

show ap link-encryption

Syntax Description	This command has no keywords and arguments.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE 3.3SE</td><td>Cisco IOS XE 3.3SE This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example show how to display the link-encryption status:

```
Device# show ap link-encryption
```

show ap mac-address

To display join-related statistics collected and last join error details for access points, use the **show ap mac-address** command.

show ap mac-address *mac-address* **join stats** {**detailed** | **summary**}

Syntax Description	
<i>mac-address</i>	Access point Ethernet MAC address or the MAC address of the 802.11 radio interface.
join stats	Displays join information and statistics for Cisco access points.
detailed	Displays all join-related statistics collected.
summary	Displays the last join error detail.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display join information for a specific access point that is trying to join the device:

```
Device# show ap mac-address d0c2.8267.8b00 join stats detailed

Discovery phase statistics
  Discovery requests received           : 6
  Successful discovery responses sent   : 6
  Unsuccessful discovery request processing : 0
  Reason for last unsuccessful discovery attempt : Not applicable
  Time at last successful discovery attempt : Nov 20 17:25:10.841
  Time at last unsuccessful discovery attempt : Not applicable

Join phase statistics
  Join requests received               : 3
  Successful join responses sent        : 3
  Unsuccessful join request processing  : 0
  Reason for last unsuccessful join attempt : Not applicable
  Time at last successful join attempt  : Nov 20 17:25:20.998
  Time at last unsuccessful join attempt : Not applicable

Configuration phase statistics
  Configuration requests received       : 8
  Successful configuration responses sent : 3
  Unsuccessful configuration request processing : 0
  Reason for last unsuccessful configuration attempt : Not applicable
  Time at last successful configuration attempt : Nov 20 17:25:21.177
  Time at last unsuccessful configuration attempt : Not applicable

Last AP message decryption failure details
  Reason for last message decryption failure : Not applicable

Last AP disconnect details
```

```

Reason for last AP connection failure to the AP has reached maximum : Number of message retransmission
Last join error summary
  Type of error that occurred last : AP got or has been disconnected
Reason for error that occurred last to the AP has reached maximum : Number of message retransmission
Time at which the last join error occurred : Nov 20 17:22:36.438

```

This example shows how to display specific join information for an access point:

```
Device# show ap mac-address d0c2.8267.8b00 join stats detailed
```

```

Is the AP currently connected to controller..... No
Time at which the AP joined this controller last time..... Aug 21 12:50:36:061
Type of error that occurred last..... Lwapp join request
rejected
Reason for error that occurred last..... RADIUS authorization
is pending for the AP
Time at which the last join error occurred..... Aug 21 12:50:34:374

```

show ap monitor-mode summary

To display the current channel-optimized monitor mode settings, use the **show ap monitor-mode summary** command.

show ap monitor-mode summary

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display current channel-optimized monitor mode settings:

```
Device# show ap monitor-mode summary
```

```
AP Name Ethernet MAC      Status   Scanning Channel List
-----
AP_004  xx:xx:xx:xx:xx:xx Tracking 1,6,11, 4
```

show ap name auto-rf

To display the auto-RF settings for a Cisco lightweight access point, use the **show ap name auto-rf** command.

```
show ap name ap-name auto-rf dot11 {24ghz | 5ghz}
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.				
	24ghz Displays the 2.4 GHz band.				
	5ghz Displays the 5 GHz band.				
Command Default	None				
Command Modes	Privileged EXEC.				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to display auto-RF information for an access point:

```
Device# show ap name AP01 auto-rf dot11 24ghz

Number of Slots                : 2
AP Name                        : TSIM_AP-1
MAC Address                    : 0000.2000.02f0
Slot ID                       : 0
Radio Type                    : 802.11b/g
Subband Type                   : All

Noise Information
  Noise Profile                : Failed
  Channel 1                   : 24 dBm
  Channel 2                   : 48 dBm
  Channel 3                   : 72 dBm
  Channel 4                   : 96 dBm
  Channel 5                   : 120 dBm
  Channel 6                   : -112 dBm
  Channel 7                   : -88 dBm
  Channel 8                   : -64 dBm
  Channel 9                   : -40 dBm
  Channel 10                  : -16 dBm
  Channel 11                  : 8 dBm

Interference Information
  Interference Profile        : Passed
  Channel 1                   : -128 dBm @ 0% busy
  Channel 2                   : -71 dBm @ 1% busy
  Channel 3                   : -72 dBm @ 1% busy
  Channel 4                   : -73 dBm @ 2% busy
  Channel 5                   : -74 dBm @ 3% busy
  Channel 6                   : -75 dBm @ 4% busy
  Channel 7                   : -76 dBm @ 5% busy
  Channel 8                   : -77 dBm @ 5% busy
  Channel 9                   : -78 dBm @ 6% busy
```

```

Channel 10                : -79 dBm @ 7% busy
Channel 11                : -80 dBm @ 8% busy

Rogue Histogram (20/40_ABOVE/40_BELOW)
Channel 36                : 27/ 4/ 0
Channel 40                : 13/ 0/ 0
Channel 44                : 5/ 0/ 0
Channel 48                : 6/ 0/ 1
Channel 52                : 4/ 0/ 0
Channel 56                : 5/ 0/ 0
Channel 60                : 1/ 3/ 0
Channel 64                : 3/ 0/ 0
Channel 100               : 0/ 0/ 0
Channel 104               : 0/ 0/ 0
Channel 108               : 0/ 1/ 0

Load Information
Load Profile              : Passed
Receive Utilization      : 10%
Transmit Utilization     : 20%
Channel Utilization      : 50%
Attached Clients         : 0 clients

Coverage Information
Coverage Profile          : Passed
Failed Clients           : 0 clients

Client Signal Strengths
RSSI -100 dBm            : 0 clients
RSSI -92 dBm             : 0 clients
RSSI -84 dBm             : 0 clients
RSSI -76 dBm             : 0 clients
RSSI -68 dBm             : 0 clients
RSSI -60 dBm             : 0 clients
RSSI -52 dBm             : 0 clients

Client Signal to Noise Ratios
SNR 0 dB                 : 0 clients
SNR 5 dB                 : 0 clients
SNR 10 dB                : 0 clients
SNR 15 dB                : 0 clients
SNR 20 dB                : 0 clients
SNR 25 dB                : 0 clients
SNR 30 dB                : 0 clients
SNR 35 dB                : 0 clients
SNR 40 dB                : 0 clients
SNR 45 dB                : 0 clients

Nearby APs
AP 0000.2000.0300 slot 0 : -68 dBm on 11 (10.10.10.1)
AP 0000.2000.0400 slot 0 : -68 dBm on 11 (10.10.10.1)
AP 0000.2000.0600 slot 0 : -68 dBm on 11 (10.10.10.1)

Radar Information

Channel Assignment Information
Current Channel Average Energy : 0 dBm
Previous Channel Average Energy : 0 dBm
Channel Change Count          : 0
Last Channel Change Time      : Wed Oct 17 08:13:36 2012
Recommended Best Channel      : 11

RF Parameter Recommendations
Power Level                   : 1

```

```
RTS/CTS Threshold           : 2347
Fragmentation Threshold     : 2346
Antenna Pattern              : 0
```

```
Persistent Interference Devices
```

show ap name bhmode

To display Cisco bridge backhaul mode, use the **show ap name bhmode** command.

```
show ap name ap-name bhmode
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display Cisco bridge backhaul mode of an access point:

```
Device# show ap name TSIM_AP-1 bhmode
```

show ap name bhrate

To display the Cisco bridge backhaul rate, use the **show ap name bhrate** command.

```
show ap name ap-name bhrate
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE 3.3SE</td><td>Cisco IOS XE 3.3SE This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to display the Cisco bridge backhaul rate for an access point:

```
Device# show ap name AP01 bhrate
```

show ap name cac voice

To display voice call admission control details for a specific Cisco lightweight access point, use the **show ap name cac voice** command.

show ap name *ap-name* cac voice

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to display voice call admission control details for an access point:

Device# **show ap name AP01 cac voice**

1) AP Name: AP01

=====

Wireless Bandwidth (In MeanTime mt)

Slot#	Radio	Calls	BW-Max	BW-Alloc	Bw-InUse (%age)
1	0	802.11b/g	0	23437	0
2	1	802.11a	0	23437	0

Wired Bandwidth (in Kbps)

Slot#	Wlan-ID	Wlan-Name	BW-Config	BW-Avail
1	0	1	maria-open	0
2	0	12	24	0
3	1	1	maria-open	0
4	1	12	24	0

show ap name config fnf

To view the Netflow input and output monitors for a Cisco AP, use the **show ap name config fnf** command.

```
show ap name ap-name config fnf
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point				
	fnf Netflow input and output monitors for a Cisco AP				
Command Default	None				
Command Modes	Any command mode				
Command History	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE 3.3SE</td><td>Cisco IOS XE 3.3SE This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

show ap name dot11 call-control

To display call control information and the metrics for successful calls, use the **show ap name dot11 call-control** command.

```
show ap name ap-name dot11 {24ghz | 5ghz} call-control {call-info | metrics}
```

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point
24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.
call-info	Displays call information.
metrics	Displays call metrics.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display metrics for successful calls for an access point:

```
Device# show ap name AP01 dot11 24ghz call-control metrics
```

```
Slot#   Call Count   Call Duration
-----
0       0             0
```

show ap name cable-modem

To show AP CAPWAP CCX on a specific AP, use the **show ap name cable-modem** command.

show ap name *ap-name* **cable-modem**

Syntax Description	<i>ap-name</i> Name of the specific AP.				
Command Default	None				
Command Modes	Privileged EXEC				
Command History	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE 3.7.0 E</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE 3.7.0 E	This command was introduced.
Release	Modification				
Cisco IOS XE 3.7.0 E	This command was introduced.				

This example shows how to show AP CAPWAP CCX on AP1:

```
Device# show ap name ap1 cable-modem
```

show ap name capwap retransmit

To display Control and Provisioning of Wireless Access Points (CAPWAP) retransmit settings, use the **show ap name capwap retransmit** command.

show ap name *ap-name* capwap retransmit

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to display CAPWAP retransmit settings of an access point:

```
Device# show ap name AP01 capwap retransmit

AP Name      Retransmit Interval Retransmit Count
-----      -
```

AP01	3	5
------	---	---

show ap name ccx rm

To display an access point's Cisco Client eXtensions (CCX) radio management status information, use the **show ap name ccx rm** command.

show ap name *ap-name* ccx rm status

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to display CCX radio management information for an access point:

Device# **show ap name AP01 ccx rm status**

```

802.11b/g Radio
  Beacon Request           : Disabled
  Channel Load Request     : Disabled
  Frame Request            : Disabled
  Noise Histogram Request  : Disabled
  Path Loss Request        : Disabled
  Interval                  : 60
  Iteration                 : 0

802.11a Radio
  Beacon Request           : Disabled
  Channel Load Request     : Disabled
  Frame Request            : Disabled
  Noise Histogram Request  : Disabled
  Path Loss Request        : Disabled
  Interval                  : 60
  Iteration                 : 0

```

show ap name cdp

To display the Cisco Discovery Protocol (CDP) information for an access point, use the **show ap name cdp** command.

show ap name *ap-name* **cdp** [**neighbors** [**detail**]]

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.
neighbors	(Optional) Displays neighbors that are using CDP.
detail	(Optional) Displays details about a specific access point neighbor that is using CDP.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display CDP information for an access point:

```
Device# show ap name AP01 cdp neighbors detail
```

show ap name channel

To display the available channels for a specific mesh access point, use the **show ap name channel** command.

show ap name *ap-name* **channel**

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to display the available channels for a particular access point:

```
Device# show ap name AP01 channel

Slot ID                               : 0
Allowed Channel List                   : 1, 2, 3, 4, 5, 6, 7, 8, 9
                                       10, 11
Slot ID                               : 1
Allowed Channel List                   : 36, 40, 44, 48, 52, 56, 60, 64, 100
                                       104, 108, 112, 116, 132, 136, 140, 149,
                                       153
                                       157, 161
```

show ap name config

To display common information and Ethernet VLAN tagging information for a specific Cisco lightweight access point, use the **show ap name config** command.

```
show ap name ap-name config {ethernet | general}
```

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.
<i>ethernet</i>	Displays Ethernet tagging configuration information for an access point.
<i>general</i>	Displays common information for an access point.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display Ethernet tagging information for an access point:

```
Device# show ap name AP01 config ethernet
```

```
VLAN Tagging Information for AP01
```

This example shows how to display common information for an access point:

```
Device# show ap name AP01 config general
```

```
Cisco AP Name : AP01
Cisco AP Identifier : 5
Country Code : US - United States
Regulatory Domain Allowed by Country : 802.11bg:-A 802.11a:-A
AP Country Code : US - United States
AP Regulatory Domain : Unconfigured
Switch Port Number : Tel1/0/1
MAC Address : 0000.2000.02f0
IP Address Configuration : Static IP assigned
IP Address : 10.10.10.12
IP Netmask : 255.255.0.0
Gateway IP Address : 10.10.10.1
Fallback IP Address Being Used : 10.10.10.12
Domain : Cisco
Name Server : 0.0.0.0
CAPWAP Path MTU : 1485
Telnet State : Enabled
SSH State : Disabled
Cisco AP Location : sanjose
Cisco AP Group Name : default-group
Primary Cisco Controller Name : CAPWAP Controller
Primary Cisco Controller IP Address : 10.10.10.1
Secondary Cisco Controller Name :
Secondary Cisco Controller IP Address : Not Configured
```

```
Tertiary Cisco Controller Name           :
Tertiary Cisco Controller IP Address     : Not Configured
Administrative State                     : Enabled
Operation State                          : Registered
AP Mode                                  : Local
AP Submode                               : Not Configured
Remote AP Debug                           : Disabled
Logging Trap Severity Level              : informational
Software Version                          : 7.4.0.5
Boot Version                              : 7.4.0.5
Stats Reporting Period                   : 180
LED State                                 : Enabled
PoE Pre-Standard Switch                  : Disabled
PoE Power Injector MAC Address           : Disabled
Power Type/Mode                          : Power Injector/Normal Mode
Number of Slots                          : 2
AP Model                                  : 1140AG
AP Image                                  : C1140-K9W8-M
IOS Version                               :
Reset Button                             :
AP Serial Number                          : SIM1140K001
AP Certificate Type                       : Manufacture Installed
Management Frame Protection Validation    : Disabled
AP User Mode                              : Customized
AP User Name                              : cisco
AP 802.1X User Mode                       : Not Configured
AP 802.1X User Name                      : Not Configured
Cisco AP System Logging Host              : 255.255.255.255
AP Up Time                                : 15 days 16 hours 19 minutes 57
seconds
AP CAPWAP Up Time                        : 4 minutes 56 seconds
Join Date and Time                       : 10/18/2012 04:48:56
Join Taken Time                           : 15 days 16 hours 15 minutes 0
seconds
Join Priority                             : 1
Ethernet Port Duplex                     : Auto
Ethernet Port Speed                      : Auto
AP Link Latency                           : Disabled
Rogue Detection                           : Disabled
AP TCP MSS Adjust                         : Disabled
AP TCP MSS Size                           : 6146
```

show ap name config dot11

To display 802.11 configuration information that corresponds to specific Cisco lightweight access points, use the **show ap name config dot11** command.

```
show ap name ap-name config dot11 {24ghz | 49ghz | 58ghz | 5ghz | dual-band}
```

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Displays the 2.4 GHz band.
49ghz	Displays 802.11-4.9G network settings.
58ghz	Displays 802.11-5.8G network settings.
5ghz	Displays the 5 GHz band settings.
dual-band	Displays the dual band radio settings.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
	Cisco IOS XE 3.3SE	The dual-band parameter was added.

This example shows how to display 802.11b configuration information that corresponds to a specific Cisco lightweight access point:

```
Device# show ap name AP01 config dot11 24ghz

Cisco AP Identifier           : 5
Cisco AP Name                 : AP01
Country Code                  : US - United States
Regulatory Domain Allowed by Country : 802.11bg:-A 802.11a:-A
AP Country Code               : US - United States
AP Regulatory Domain          : -A
Switch Port Number            : Tel1/0/1
MAC Address                    : 0000.2000.02f0
IP Address Configuration      : Static IP assigned
IP Address                    : 10.10.10.12
IP Netmask                    : 255.255.0.0
Gateway IP Address            : 10.10.10.1
Fallback IP Address Being Used : 10.10.10.12
Domain                         : Cisco
Name Server                   : 0.0.0.0
CAPWAP Path MTU               : 1485
Telnet State                   : Enabled
SSH State                      : Disabled
Cisco AP Location              : sanjose
Cisco AP Group Name            : default-group
Administrative State           : Enabled
```

```

Operation State                : Registered
AP Mode                        : Local
AP Submode                    : Not Configured
Remote AP Debug               : Disabled
Logging Trap Severity Level   : informational
Software Version              : 7.4.0.5
Boot Version                  : 7.4.0.5
Mini IOS Version              : 3.0.51.0
Stats Reporting Period        : 180
LED State                     : Enabled
PoE Pre-Standard Switch       : Disabled
PoE Power Injector MAC Address : Disabled
Power Type/Mode               : Power Injector/Normal Mode
Number of Slots               : 2
AP Model                      : 1140AG
AP Image                      : C1140-K9W8-M
IOS Version                   :
Reset Button                  :
AP Serial Number              : SIM1140K001
AP Certificate Type           : Manufacture Installed
Management Frame Protection Validation : Disabled
AP User Mode                  : Customized
AP User Name                  : cisco
AP 802.1X User Mode           : Not Configured
AP 802.1X User Name          : Not Configured
Cisco AP System Logging Host  : 255.255.255.255
AP Up Time                    : 15 days 17 hours 9 minutes 41
seconds
AP CAPWAP Up Time             : 54 minutes 40 seconds
Join Date and Time            : 10/18/2012 04:48:56
Join Taken Time               : 15 days 16 hours 15 minutes 0
seconds

Attributes for Slot 0
Radio Type                    : 802.11n - 2.4 GHz
Administrative State          : Enabled
Operation State               : Up
Cell ID                       : 0

Station Configuration
Configuration                  : Automatic
Number of WLANs               : 1
Medium Occupancy Limit        : 100
CFP Period                    : 4
CFP Maximum Duration          : 60
BSSID                         : 000020000200

Operation Rate Set
1000 Kbps                     : MANDATORY
2000 Kbps                     : MANDATORY
5500 Kbps                     : MANDATORY
11000 Kbps                    : MANDATORY
6000 Kbps                     : SUPPORTED
9000 Kbps                     : SUPPORTED
12000 Kbps                    : SUPPORTED
18000 Kbps                    : SUPPORTED
24000 Kbps                    : SUPPORTED
36000 Kbps                    : SUPPORTED
48000 Kbps                    : SUPPORTED
54000 Kbps                    : SUPPORTED

MCS Set
MCS 0                         : SUPPORTED
MCS 1                         : SUPPORTED

```

```

MCS 2 : SUPPORTED
MCS 3 : SUPPORTED
MCS 4 : SUPPORTED
MCS 5 : SUPPORTED
MCS 6 : SUPPORTED
MCS 7 : SUPPORTED
MCS 8 : SUPPORTED
MCS 9 : SUPPORTED
MCS 10 : SUPPORTED
MCS 11 : SUPPORTED
MCS 12 : SUPPORTED
MCS 13 : SUPPORTED
MCS 14 : SUPPORTED
MCS 15 : SUPPORTED
MCS 16 : DISABLED
MCS 17 : DISABLED
MCS 18 : DISABLED
MCS 19 : DISABLED
MCS 20 : DISABLED
MCS 21 : DISABLED
MCS 22 : DISABLED
MCS 23 : DISABLED

Beacon Period : 100
Fragmentation Threshold : 2346
Multi Domain Capability Implemented : True
Multi Domain Capability Enabled : True
Country String : US

Multi Domain Capability
Configuration : Automatic
First Channel : 0
Number of Channels : 0
Country String : US

MAC Operation Parameters
Configuration : Automatic
Fragmentation Threshold : 2346
Packet Retry Limit : 64
Legacy Tx Beamforming Setting : Disabled

Tx Power
Number of Supported Power Levels : 8
Tx Power Level 1 : 20 dBm
Tx Power Level 2 : 17 dBm
Tx Power Level 3 : 14 dBm
Tx Power Level 4 : 11 dBm
Tx Power Level 5 : 8 dBm
Tx Power Level 6 : 5 dBm
Tx Power Level 7 : 2 dBm
Tx Power Level 8 : -1 dBm
Tx Power Configuration : Automatic
Current Tx Power Level : 1

Phy OFDM Parameters
Configuration : Automatic
Current Channel : 11
Extension Channel : None
Channel Width : 20 MHz
Allowed Channel List : 1, 2, 3, 4, 5, 6, 7, 8, 9
                    10, 11
TI Threshold : 0
Antenna Type : Internal
Internal Antenna Gain (in .5 dBi units) : 0

```

```
Diversity : Diversity enabled

802.11n Antennas
Tx : A, B, C
Rx : A, B, C

Performance Profile Parameters
Configuration : Automatic
Interference Threshold : 10%
Noise Threshold : -70 dBm
RF Utilization Threshold : 80%
Data Rate Threshold : 1000000 bps
Client Threshold : 12 clients
Coverage SNR Threshold : 15 dB
Coverage Exception Level : 25%
Client Minimum Exception Level : 3 clients
RTS/CTS Threshold : 2347
Short Retry Limit : 7
Long Retry Limit : 4
Max Tx MSDU Lifetime : 512
Max Rx Lifetime : 512

CleanAir Management Information
CleanAir Capable : Yes
CleanAir Management Admin State : Enabled
CleanAir Management Operation State : Up
Rapid Update Mode : Disabled
Spectrum Expert connection : Disabled
CleanAir NSI Key : 377313C8F290E246E640C4EF177BED
88
Spectrum Expert connections counter : 0
CleanAir Sensor State : Configured

Rogue Containment Information
Containment Count : 0
```

show ap name config slot

To display configuration information for slots on a specific Cisco lightweight access point, use the **show ap name config slot** command.

show ap name *ap-name* **config slot** {0 | 1 | 2 | 3}

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.
0	Displays slot number 0.
1	Displays slot number 1.
2	Displays slot number 2.
3	Displays slot number 3.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display configuration information for slots on an access point:

```
Device# show ap name AP01 config slot 0

Cisco AP Identifier           : 3
Cisco AP Name                : AP01
Country Code                 : US - United States
Regulatory Domain Allowed by Country : 802.11bg:-A      802.11a:-A
AP Country Code              : US - United States
AP Regulatory Domain         : -A
Switch Port Number          : Tel/0/1
MAC Address                  : 0000.2000.02f0
IP Address Configuration     : Static IP assigned
IP Address                   : 10.10.10.12
IP Netmask                   : 255.255.0.0
Gateway IP Address          : 10.10.10.1
Fallback IP Address Being Used : 10.10.10.12
Domain                       : Cisco
Name Server                  : 0.0.0.0
CAPWAP Path MTU              : 1485
Telnet State                 : Enabled
SSH State                    : Disabled
Cisco AP Location            : sanjose
Cisco AP Group Name          : default-group
Administrative State         : Enabled
Operation State              : Registered
AP Mode                      : Local
AP Submode                   : Not Configured
Remote AP Debug              : Disabled
Logging Trap Severity Level  : informational
```

```

Software Version                : 7.4.0.5
Boot Version                    : 7.4.0.5
Mini IOS Version                : 3.0.51.0
Stats Reporting Period         : 180
LED State                      : Enabled
PoE Pre-Standard Switch       : Disabled
PoE Power Injector MAC Address : Disabled
Power Type/Mode                : Power Injector/Normal Mode
Number of Slots                : 2
AP Model                       : 1140AG
AP Image                       : C1140-K9W8-M
IOS Version                    :
Reset Button                   :
AP Serial Number               : SIM1140K001
AP Certificate Type            : Manufacture Installed
Management Frame Protection Validation : Disabled
AP User Mode                   : Customized
AP User Name                   : cisco
AP 802.1X User Mode           : Not Configured
AP 802.1X User Name           : Not Configured
Cisco AP System Logging Host   : 255.255.255.255
AP Up Time                     : 15 days 16 hours 1 minute 19 s
econds
AP CAPWAP Up Time              : 20 hours 21 minutes 37 seconds

Join Date and Time             : 10/17/2012 08:13:36
Join Taken Time                : 14 days 19 hours 39 minutes 41
seconds

Attributes for Slot 0
  Radio Type                   : 802.11n - 2.4 GHz
  Administrative State         : Enabled
  Operation State              : Up
  Cell ID                      : 0

Station Configuration
  Configuration                 : Automatic
  Number of WLANs              : 1
  Medium Occupancy Limit       : 100
  CFP Period                   : 4
  CFP Maximum Duration         : 60
  BSSID                        : 000020000200

Operation Rate Set
  1000 Kbps                    : MANDATORY
  2000 Kbps                    : MANDATORY
  5500 Kbps                    : MANDATORY
  11000 Kbps                   : MANDATORY
  6000 Kbps                    : SUPPORTED
  9000 Kbps                    : SUPPORTED
  12000 Kbps                   : SUPPORTED
  18000 Kbps                   : SUPPORTED
  24000 Kbps                   : SUPPORTED
  36000 Kbps                   : SUPPORTED
  48000 Kbps                   : SUPPORTED
  54000 Kbps                   : SUPPORTED

MCS Set
  MCS 0                        : SUPPORTED
  MCS 1                        : SUPPORTED
  MCS 2                        : SUPPORTED
  MCS 3                        : SUPPORTED
  MCS 4                        : SUPPORTED
  MCS 5                        : SUPPORTED

```

show ap name config slot

```

MCS 6 : SUPPORTED
MCS 7 : SUPPORTED
MCS 8 : SUPPORTED
MCS 9 : SUPPORTED
MCS 10 : SUPPORTED
MCS 11 : SUPPORTED
MCS 12 : SUPPORTED
MCS 13 : SUPPORTED
MCS 14 : SUPPORTED
MCS 15 : SUPPORTED
MCS 16 : DISABLED
MCS 17 : DISABLED
MCS 18 : DISABLED
MCS 19 : DISABLED
MCS 20 : DISABLED
MCS 21 : DISABLED
MCS 22 : DISABLED
MCS 23 : DISABLED

Beacon Period : 100
Fragmentation Threshold : 2346
Multi Domain Capability Implemented : True
Multi Domain Capability Enabled : True
Country String : US

Multi Domain Capability
Configuration : Automatic
First Channel : 0
Number of Channels : 0
Country String : US

MAC Operation Parameters
Configuration : Automatic
Fragmentation Threshold : 2346
Packet Retry Limit : 64

Tx Power
Number of Supported Power Levels : 8
Tx Power Level 1 : 20 dBm
Tx Power Level 2 : 17 dBm
Tx Power Level 3 : 14 dBm
Tx Power Level 4 : 11 dBm
Tx Power Level 5 : 8 dBm
Tx Power Level 6 : 5 dBm
Tx Power Level 7 : 2 dBm
Tx Power Level 8 : -1 dBm
Tx Power Configuration : Automatic
Current Tx Power Level : 1

Phy OFDM Parameters
Configuration : Automatic
Current Channel : 11
Extension Channel : None
Channel Width : 20 MHz
Allowed Channel List : 1, 2, 3, 4, 5, 6, 7, 8, 9
                    10, 11

TI Threshold : 0
Antenna Type : Internal
Internal Antenna Gain (in .5 dBi units) : 0
Diversity : Diversity enabled

802.11n Antennas
Tx : A, B, C
Rx : A, B, C

```

```
Performance Profile Parameters
  Configuration                : Automatic
  Interference Threshold       : 10%
  Noise Threshold              : -70 dBm
  RF Utilization Threshold     : 80%
  Data Rate Threshold         : 1000000 bps
  Client Threshold            : 12 clients
  Coverage SNR Threshold      : 15 dB
  Coverage Exception Level    : 25%
  Client Minimum Exception Level : 3 clients

Rogue Containment Information
  Containment Count           : 0
```

show ap name core-dump

To display the memory core dump information for a lightweight access point, use the **show ap name core-dump** command.

show ap name *ap-name* core-dump

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display the memory core dump information:

```
Device# show ap name 3602a core-dump

TFTP server IP : 172.31.25.21
Memory core dump file : 3602a.dump
Memory core dump file compressed : Disabled
```

Related Topics

[ap name core-dump](#), on page 549

show ap name data-plane

To display the data plane status of a specific Cisco lightweight access point, use the **show ap name data-plane** command.

show ap name *ap-name* data-plane

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display the data plane status of an access point:

Device# **show ap name AP01 data-plane**

AP Name	Min Data Round Trip	Data Round Trip	Max Data Round Trip	Last Update
AP01	0.000s	0.000s	0.000s	00:00:00

show ap name dot11

To display 802.11a or 802.11b configuration information that corresponds to specific Cisco lightweight access points, use the **show ap name dot11** command.

```
show ap name ap-name dot11 {24ghz | 5ghz} {ccx | cdp | profile | service-policy output | stats | tsm
{allclient-mac}}
```

Syntax	Description
<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.
ccx	Displays the Cisco Client eXtensions (CCX) radio management status information.
cdp	Displays Cisco Discovery Protocol (CDP) information.
profile	Displays configuration and statistics of 802.11 profiling.
service-policy output	Displays downstream service policy information.
stats	Displays Cisco lightweight access point statistics.
tsm	Displays 802.11 traffic stream metrics statistics.
all	Displays the list of all access points to which the client has associations.
<i>client-mac</i>	MAC address of the client.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display the service policy that is associated with the access point:

```
Device# show ap name test-ap dot11 24ghz service-policy output

Policy Name : test-ap1
Policy State : Installed
```

This example shows how to display the CCX RRM 802.11 configuration for a specific access point:

```
Device# show ap name AP01 dot11 24ghz ccx
```

This example show how to display CDP information for a specific access point:

```
Device# show ap name AP01 dot11 24ghz cdp
```

```
AP Name          AP CDP State
-----
AP03             Disabled
```

This example show how to display the configuration and statistics of 802.11b profiling for a specific access point:

```
Device# show ap name AP01 dot11 24ghz profile
```

```
802.11b Cisco AP performance profile mode      : GLOBAL
802.11b Cisco AP Interference threshold       : 10 %
802.11b Cisco AP noise threshold              : -70 dBm
802.11b Cisco AP RF utilization threshold     : 80 %
802.11b Cisco AP throughput threshold        : 1000000 bps
802.11b Cisco AP clients threshold           : 12 clients
```

This example show how to display downstream service policy information for a specific access point:

```
Device# show ap name AP01 dot11 24ghz service-policy output
```

```
Policy Name   : def-11gn
Policy State  : Installed
```

This example show how to display statistics for a specific access point:

```
Device# show ap name AP01 dot11 24ghz stats
```

```
Number of Users.....: 0
TxFragmentCount.....: 0
MulticastTxFrameCnt.....: 0
FailedCount.....: 0
RetryCount.....: 0
MultipleRetryCount.....: 0
FrameDuplicateCount.....: 0
RtsSuccessCount.....: 0
RtsFailureCount.....: 0
AckFailureCount.....: 0
RxIncompleteFragment.....: 0
MulticastRxFrameCnt.....: 0
FcsErrorCount.....: 0
TxFrameCount.....: 0
WepUndecryptableCount.....: 0
TxFramesDropped.....: 0

Call Admission Control (CAC) Stats
  Voice Bandwidth in use(% of config bw).....: 0
  Video Bandwidth in use(% of config bw).....: 0
  Total BW in use for Voice(%).....: 0
  Total BW in use for SIP Preferred call(%).....: 0

Load based Voice Call Stats
  Total channel MT free.....: 0
  Total voice MT free.....: 0
  Na Direct.....: 0
  Na Roam.....: 0

WMM TSPEC CAC Call Stats
  Total num of voice calls in progress.....: 0
  Num of roaming voice calls in progress.....: 0
  Total Num of voice calls since AP joined.....: 0
```

```

Total Num of roaming calls since AP joined.....: 0
Total Num of exp bw requests received.....: 0
Total Num of exp bw requests admitted.....: 0
Num of voice calls rejected since AP joined....: 0
Num of roam calls rejected since AP joined.....: 0
Num of calls rejected due to insufficient bw....: 0
Num of calls rejected due to invalid params....: 0
Num of calls rejected due to PHY rate.....: 0
Num of calls rejected due to QoS policy.....: 0

SIP CAC Call Stats
Total Num of calls in progress.....: 0
Num of roaming calls in progress.....: 0
Total Num of calls since AP joined.....: 0
Total Num of roaming calls since AP joined.....: 0
Total Num of Preferred calls received.....: 0
Total Num of Preferred calls accepted.....: 0
Total Num of ongoing Preferred calls.....: 0
Total Num of calls rejected(Insuff BW).....: 0
Total Num of roam calls rejected(Insuff BW)....: 0

Band Select Stats
Num of dual band client .....: 0
Num of dual band client added.....: 0
Num of dual band client expired .....: 0
Num of dual band client replaced.....: 0
Num of dual band client detected .....: 0
Num of suppressed client .....: 0
Num of suppressed client expired.....: 0
Num of suppressed client replaced.....: 0

```

This example show how to display the traffic stream configuration for all clients that correspond to a specific access point:

```
Device# show ap name AP01 dot11 24ghz tsm all
```

show ap name dot11 cleanair

To display CleanAir configuration information that corresponds to an access point, use the **show ap name dot11 cleanair** command.

```
show ap name ap-name dot11 {24ghz | 5ghz} cleanair {air-quality | device}
```

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.
cleanair	Displays CleanAir configuration information.
air-quality	Displays CleanAir air-quality (AQ) data.
device	Displays CleanAir interferers for an access point on the 5 GHz band.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to display CleanAir air-quality information for an access point in the 802.11b network:

```
Device# show ap name AP01 dot11 24ghz cleanair air-quality
```

AQ = Air Quality

DFS = Dynamic Frequency Selection

This example shows how to display CleanAir interferers information for an access point in the 802.11b network:

```
Device# show ap name AP01 dot11 24ghz cleanair device
```

DC = Duty Cycle (%)

ISI = Interference Severity Index (1-Low Interference, 100-High Interference)

RSSI = Received Signal Strength Index (dBm)

DevID = Device ID

```
No ClusterID DevID Type AP Name ISI RSSI DC Channel
```

```
--- -----
```

show ap name env

To show AP environment on a specific AP, use the **show ap name env** command.

show ap name *ap-name* env

Syntax Description	<i>ap-name</i> Name of the specific AP.				
Command Default	None				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.7.0 E</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.7.0 E	This command was introduced.
Release	Modification				
Cisco IOS XE 3.7.0 E	This command was introduced.				

This example shows how to show AP environment on AP1:

```
Device# show ap name ap1 env
```

show ap name ethernet statistics

To display the Ethernet statistics of a specific Cisco lightweight access point, use the **show ap name ethernet statistics** command.

show ap name *ap-name* **ethernet statistics**

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display the Ethernet statistics of an access point:

```
Device# show ap name 3602a ethernet statistics
```

```
Ethernet Stats for AP 3602a
```

Interface Name	Status	Speed	Rx Packets	Tx Packets	Discarded Packets
GigabitEthernet0	UP	1000 Mbps	3793	5036	0

show ap name eventlog

To download and display the event log of a specific Cisco lightweight access point, use the **show ap name eventlog** command.

show ap name *ap-name* **eventlog**

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to display the event log for a specific access point:

```
Device# show ap name AP01 eventlog
```

show ap gps-location summary

To show GPS location summary of all connected Cisco APs, use the **show ap gps-location summary** command.

There is no keyword or argument.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.7.0 E	This command was introduced.

This example shows how to show GPS location summary of all connected Cisco APs:

```
Device# show ap gps-location summary
```

show ap name image

To display the detailed information about the predownloaded image for specified access points, use the **show ap name image** command.

show ap name *ap-name* **image**

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display images present on all access points:

```
Device# show ap name 3602a image
```

```
Total number of APs : 1
```

```
Number of APs
  Initiated           : 0
  Predownloading      : 0
  Completed predownloading : 0
  Not Supported       : 1
  Failed to Predownload : 0
```

AP Name	Primary Image	Backup Image	Predownload Status	Predownload Ver...	Next
Retry Time	Retry Count				
3602a	10.0.1.234	0.0.0.0	Not supported	None	NA
		0			

show ap name inventory

To display inventory information for an access point, use the **show ap name inventory** command.

show ap name *ap-name* inventory

Syntax Description

ap-name Name of the Cisco lightweight access point.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display inventory information for an access point:

```
Device# show ap name 3502b inventory

NAME: Cisco AP      , DESCR: Cisco Wireless Access Point
PID: 1140AG  , VID: V01, SN: SIM1140K001

NAME:      , DESCR:
PID: , VID: , SN:

NAME:      , DESCR:
PID: , VID: , SN:
NAME: Cisco AP      , DESCR: Cisco Wireless Access Point
PID: 3502I  , VID: V01, SN: FTX1525E94A

NAME: Dot11Radio0  , DESCR: 802.11N 2.4GHz Radio
PID: UNKNOWN, VID:  , SN: FOC1522BLNA

NAME: Dot11Radio1  , DESCR: 802.11N 5GHz Radio
PID: UNKNOWN, VID:  , SN: FOC1522BLNA
```

show ap name lan port

To display LAN information, use **show ap name lan port** command.

show ap name lan portsummary | *port-id*

Syntax Description	
summary	Displays brief summary for LAN information.
<i>port-id</i>	Port ID of the port that the LAN information will be displayed.

Command Default	None
-----------------	------

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	Cisco IOS XE 3.7SE	This command was introduced.

This example shows how to display the brief summary for LAN information:

```
Device# show ap name ap1 lan port summary
```

show ap name link-encryption

To display the link-encryption status for a specific Cisco lightweight access point, use the **show ap name link-encryption** command.

show ap name *ap-name* **link-encryption**

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display the link-encryption status for a specific Cisco lightweight access point:

```
Device# show ap name AP01 link-encryption
```

AP Name	Encryption State	Dnstream Count	Upstream Count	Last Update
AP01	Disabled	0	0	Never

show ap name service-policy

To display service-policy information for a specific Cisco lightweight access point, use the **show ap name service-policy** command.

show ap name *ap-name* **service-policy**

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to display service-policy information for a specific Cisco lightweight access point:

```
Device# show ap name 3502b service-policy
```

```
NAME: Cisco AP      , DESCR: Cisco Wireless Access Point
PID: 3502I  , VID: V01, SN: FTX1525E94A
```

```
NAME: Dot11Radio0   , DESCR: 802.11N 2.4GHz Radio
PID: UNKNOWN, VID:  , SN: FOC1522BLNA
```

```
NAME: Dot11Radio1   , DESCR: 802.11N 5GHz Radio
PID: UNKNOWN, VID:  , SN: FOC1522BLNA
```

show ap name tcp-adjust-mss

To display TCP maximum segment size (MSS) for an access point, use the **show ap name tcp-adjust-mss** command.

```
show ap name ap-name tcp-adjust-mss
```

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.	
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display TCP MSS for an access point:

```
Device# show ap name AP01 tcp-adjust-mss
```

```
AP Name                TCP State      MSS Size
-----
AP01                   Disabled      6146
```

show ap name wlan

To display the Basic Service Set Identifier (BSSID) value for each WLAN defined on an access point and to display WLAN statistics, use the **show ap name wlan** command.

```
show ap name ap-name wlan {dot11 {24ghz | 5ghz} | statistic}
```

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
dot11	Displays 802.11 parameters.
24ghz	Displays 802.11b network settings.
5ghz	Displays 802.11a network settings.
statistic	Displays WLAN statistics.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display BSSID information of an access point in an 802.11b network:

```
Device# show ap name AP01 wlan dot11 24ghz

Site Name                : default-group
Site Description         :

WLAN ID  Interface  BSSID
-----
1        default    00:00:20:00:02:00
12       default    00:00:20:00:02:0b
```

This example shows how to display WLAN statistics for an access point:

```
Device# show ap name AP01 wlan statistic

WLAN ID : 1
WLAN Profile Name : maria-open

EAP Id Request Msg Timeouts : 0
EAP Id Request Msg Timeouts Failures : 0
EAP Request Msg Timeouts : 0
EAP Request Msg Timeouts Failures : 0
EAP Key Msg Timeouts : 0
EAP Key Msg Timeouts Failures : 0

WLAN ID : 12
WLAN Profile Name : 24
```

```
EAP Id Request Msg Timeouts           : 0
EAP Id Request Msg Timeouts Failures  : 0
EAP Request Msg Timeouts               : 0
EAP Request Msg Timeouts Failures     : 0
EAP Key Msg Timeouts                   : 0
EAP Key Msg Timeouts Failures         : 0
```

show ap name wlandot11 service policy

To display the QoS policies for each Basic Service Set Identifier (BSSID) for an access point use commands

```
show apnameap -namewlan dot1124ghzservice-policy
```

```
show apnameap -namewlan dot115ghzservice-policy
```

Syntax Description	
<i>ap- name</i>	Name of the Cisco lightweight access point.
<i>service-policy</i>	Service policy information for access point.

Command Default	None
-----------------	------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Example

The following example shows how to display QoS policies for each BSSID.

```
Device#show ap name <ap-name> wlan dot11 24ghz service-policy
```

show ap slots

To display a slot summary of all connected Cisco lightweight access points, use the **show ap slots** command.

show ap slots

Syntax Description	This command has no keywords and arguments.	
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display a slot summary of all connected Cisco lightweight access points:

```
Controller# show ap slots
```

```
AP Name      Slots  AP Model  Slot0      Slot1      Slot2      Slot3
-----
3602a        2      3502I     802.11b/g  802.11a    Unknown    Unknown
```

show ap summary

To display the status summary of all Cisco lightweight access points attached to the device, use the **show ap summary** command.

show ap summary

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	Use this command to display a list that contains each lightweight access point name, number of slots, manufacturer, MAC address, location, and the device port number.
-------------------------	--

This example shows how to display a summary of all connected access points:

```
Controller# show ap summary
```

```
Number of APs: 1
```

```
Global AP User Name: Cisco
```

```
Global AP Dot1x User Name: Not configured
```

AP Name	AP Model	Ethernet MAC	Radio MAC	State
3602a	3502I	003a.99eb.3fa8	d0c2.8267.8b00	Registered

show ap tcp-adjust-mss

To display information about the Cisco lightweight access point TCP Maximum Segment Size (MSS), use the **show ap tcp-adjust-mss** command.

show ap tcp-adjust-mss

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to display information about the access point TCP MSS information:

```
Controller# show ap tcp-adjust-mss
```

AP Name	TCP State	MSS Size
3602a	Disabled	0

show ap universal summary

To show universal summary of all connected Cisco APs, use the **show ap universal summary** command.

There is no keyword or argument.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.7.0 E	This command was introduced.

This example shows how to show universal summary of all connected Cisco APs:

```
Device# show ap universal summary
```

show ap uptime

To display the up time of all connected Cisco lightweight access points, use the **show ap uptime** command.

show ap uptime

Syntax Description	This command has no keywords and arguments.	
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to the display up time of all connected access points:

```
Controller# show ap uptime
```

```
Number of APs : 1
```

```
Global AP User Name : Cisco
```

```
Global AP Dot1x User Name : Not configured
```

```
AP Name Ethernet MAC      AP Up Time                Association Up Time
-----
3602a  003a.99eb.3fa8  5 hours 13 minutes 40 seconds  5 hours 12 minutes 15 seconds
```

show wireless ap summary

To display the status summary of all wireless access points, use the **show wireless apsummary** command.

show wirelessap summary

Syntax Description	This command has no keywords and arguments.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Any command mode
----------------------	------------------

Command History	Release	Modification
	10.4	This command was introduced

This example shows how to display a summary of all wireless access points:

```

Controller# show wireless ap summary
Sub-Domain Access Point Summary

Maximum AP limit: 1010
Total AP Licence Installed: 1000
Total AP Licence Available: 1000
Total AP joined :0

```

show wireless client ap

To display the clients on a Cisco lightweight access point, use the **show wireless client ap** command.

```
show wireless client ap [name ap-name] dot11 {24ghz | 5ghz}
```

Syntax Description

name <i>ap-name</i>	(Optional) Displays the name of the Cisco lightweight access point.
dot11	Displays 802.11 parameters.
24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **show client ap** command might list the status of automatically disabled clients. Use the **show exclusionlist** command to view clients on the exclusion list (blacklisted).

This example shows how to display client information on a specific Cisco lightweight access point in the 2.4 GHz band:

```
Device# show wireless client ap name AP01 dot11 24ghz

MAC Address      AP Id  Status      WLAN Id  Authenticated
-----
xx:xx:xx:xx:xx:xx 1      Associated  1        No
```

test ap name

To enable automatic testing of the path Maximum Transmit Unit (MTU) between the access point and the device, use the **test ap name** command.

```
test ap name ap-name pmtu {disable size size | enable}
```

Syntax Description	
<i>ap-name</i>	Name of the target Cisco lightweight access point.
pmtu	Tests the MTU configuration for the access point.
disable	Disables path MTU testing and manually configures the MTU value in bytes.
size <i>size</i>	Specifies the path MTU size. Note The range is from 576 to 1700.
enable	Enables the path MTU testing for the access point.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to disable the path MTU configuration for all access points associated to the device:

```
Controller# test ap name 3602a pmtu enable
```

test capwap ap name

To test Control and Provisioning of Wireless Access Points (CAPWAP) parameters for a specific Cisco lightweight access points, use the **test capwap ap name** command.

```
test capwap ap name ap-name {encryption {enable | disable} | message token}
```

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.
encryption	Tests the Datagram Transport Layer Security (DTLS) encryption.
enable	Tests if DTLS encryption is enabled.
disable	Tests if DTLS encryption is disabled.
message <i>token</i>	Specifies an RRM neighbor message to send.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to test if DTLS encryption is enabled for a specific access point:

```
Controller# test capwap ap name 3602a encryption enable
```

This example shows how to test if DTLS encryption is disabled for a specific access point:

```
Controller# test capwap ap name 3602a encryption disable
```

trapflags ap

To enable the sending of specific Cisco lightweight access point traps, use the **trapflags ap** command. To disable the sending of Cisco lightweight access point traps, use the **no** form of this command.

```
trapflags ap {register | interfaceup}
no trapflags ap {register | interfaceup}
```

Syntax Description	register	Enables sending a trap when a Cisco lightweight access point registers with a Cisco switch.
	interfaceup	Enables sending a trap when a Cisco lightweight access point interface (A or B) comes up.
Command Default	Enabled	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to prevent traps from sending access point-related traps:

```
Device(config)# no trapflags ap register
```

wireless wps rogue ap rldp alarm-only

To configure an alarm when a rogue is detected, use **wirelesswps rogueaprl dp alarm-only** command. Use the **no** form of the command to disable the alarm.

[no] wireless wps rogue ap rldp alarm-only monitor-ap-only

Syntax Description	monitor-ap-only Perform RLDP only on monitor AP						
Command Default	None						
Command Modes	Global Configuration						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> <tr> <td>Cisco IOS XE 3.7.3E</td> <td>The no form of the command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.	Cisco IOS XE 3.7.3E	The no form of the command was introduced.
Release	Modification						
Cisco IOS XE 3.3SE	This command was introduced.						
Cisco IOS XE 3.7.3E	The no form of the command was introduced.						

Example

This example shows how to configure an alarm for a detected rogue.

```
Device# wireless wps rogue ap rldp alarm-only
```

wireless wps rogue ap rldp auto-contain

To configure RLDP, alarm and auto-contain if rogue is detected, use `wirelesswps rogueap rldp auto-contain` command. Use the **no** form of the command to disable the alarm.

[no] wireless wps rogue ap rldp auto-contain monitor-ap-only

Syntax Description	monitor-ap-only Perform RLDP only on monitor AP
Command Default	None
Command Modes	Global Configuration
Command History	Release Modification
	Cisco IOS XE 3.3SE This command was introduced.
	Cisco IOS XE 3.7.3E The no form of the command was introduced.

Example

This example shows how to configure an alarm for a detected rogue.

```
Device# wireless wps rogue ap rldp auto-contain
```



PART **IX**

Mobility

- [Mobility Commands, on page 715](#)



Mobility Commands

- [mobility anchor](#), on page 716
- [wireless mobility](#), on page 718
- [wireless mobility controller](#), on page 719
- [wireless mobility controller \(ip_address\)](#) , on page 721
- [wireless mobility controller peer-group](#), on page 722
- [wireless mobility group keepalive](#), on page 723
- [wireless mobility group member ip](#), on page 724
- [wireless mobility group name](#) , on page 725
- [wireless mobility load-balance](#), on page 726
- [show wireless mobility](#), on page 727
- [clear wireless mobility statistics](#), on page 728

mobility anchor

To configure mobility sticky anchoring, use the **mobility anchor sticky** command. To disable the sticky anchoring, use the **no** form of the command.

To configure guest anchoring, use the **mobility anchor ip-address** command.

To delete the guest anchor, use the **no** form of the command.

To configure the device as an auto-anchor, use the **mobility anchor** command.

mobility anchor {*ip-address* | **sticky**}

no mobility anchor {*ip-address* | **sticky**}

Syntax Description

sticky The client is anchored to the first switch that it associates.

Note This command is by default enabled and ensures low roaming latency. This ensures that the point of presence for the client does not change when the client joins the mobility domain and roams within the domain.

ip-address Configures the IP address for the guest anchor device to this WLAN.

Command Default

Sticky configuration is enabled by default.

Command Modes

WLAN Configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

- The `wlan_id` or `guest_lan_id` must exist and be disabled.
- Auto-anchor mobility is enabled for the WLAN or wired guest LAN when you configure the first mobility anchor.
- Deleting the last anchor disables the auto-anchor mobility feature and resumes normal mobility for new associations.
- Mobility uses the following ports, that are allowed through the firewall:
 - 16666
 - 16667
 - 16668

This example shows how to enable the sticky mobility anchor:

```
Device(config-wlan)# mobility anchor sticky
```

This example shows how to configure guest anchoring:

```
Device(config-wlan)# mobility anchor 209.165.200.224
```

This example shows how to configure the device as an auto-anchor:

```
Device(config-wlan)# mobility anchor
```

wireless mobility

To configure the inter mobility manager, use the **wireless mobility** command.

```
wireless mobility {dscp value }
```

Syntax Description

dscp *value* Configures the Mobility inter DSCP value.

Command Default

The default DSCP value is 48.

Command Modes

Global Configuration

Command History

Release

Modification

Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE	This command was introduced.
--------------------	--------------------	------------------------------

This example shows how to configure mobility inter DSCP with an value of 20:

```
Device(config)# wireless mobility dscp 20
```

wireless mobility controller

To configure mobility controller settings, use the **wireless mobility controller** command. To remove a mobility controller settings, use the **no** form of the command.

```
wireless mobility controller peer-group peer-group-name [{ bidge-domain-id id | member ip
ip-address [{public-ip public-ip-address }]| multicast ip multicast-address }]
no
wireless mobility controller peer-group peer-group-name [{ bidge-domain-id id | member ip
ip-address [{public-ip public-ip-address }]| multicast ip multicast-address }]
```

Syntax Description		
peer-group <i>peer-group-name</i>		Creates a mobility peer group.
bidge-domain-id <i>id</i>		Configures bridge domain ID for the mobility peer group.
member ip <i>ip-address</i> public-ip <i>public-ip-address</i>		Adds or deletes a peer group member.
	Note	The public-ip <i>public-ip-address</i> is optional and is only when the mobility peer is NATed.
multicast ip <i>multicast-address</i>		Configures multicast settings of a peer group.

Command Default None.

Command Modes Global Configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines In the Converged Access solution, WLANs are mapped to VLANs, and VLANs are usually mapped to subnets. For seamless roaming, the same VLAN configured on two controllers is expected to be mapped to the same subnet. This identical mapping from one controller to the next is important for roaming, because the controllers taking care of the roaming event need to determine if they need:

- To address a Layer 2 roaming event (when WLAN to VLAN and subnet mapping are identical on the anchor and the foreign controller), or
- a Layer 3 roaming event (when WLAN to VLAN and subnet mapping are different between the anchor and the foreign controller).

This determination is made by comparing the WLAN SSID string and the VLAN ID between controllers. In cases where the WLAN SSID and VLAN ID are identical, the expectation is that the subnet associated to the VLAN is identical as well.

There may be cases where this mapping is not identical. For example, suppose that WLAN1 on controller 1 is mapped to VLAN 14, and that VLAN 14 on controller1 is mapped to the subnet 10.10.14.0/24. Also suppose that WLAN 1 on controller2 is mapped to VLAN 14, but that VLAN 14 on controller2 is mapped to this subnet 172.31.24.0/24. Controllers 1 and 2 will compare WLAN1 and the associated VLAN and conclude that they are addressing a Layer 2 roaming event, whereas the roaming even is Layer 3, as VLAN 14 does not have the same Layer 3 significance on both controllers.

When this disconnect between VLANs and their associated subnet occurs, you may want to configure your Converged Access controllers for different bridge domain IDs. Two controllers in the same bridge domain ID are expected to have the same VLAN to subnet mapping. We recommend that you configure the same bridge domain ID on all controllers that share the same VLAN to subnet mapping, and between which roaming is expected.

This example shows how to configure a bridge domain ID.

```
Device (config)# wireless mobility controller peer-group SPG1 bridge-domain-id 111
```

This example shows how to create and configure a peer group with a bridge ID of 111:

```
Device (config)# controller peer-group TestDocPeerGroup bridge-domain-id 111
```

This example shows how to disable a peer group with a bridge ID of 111:

```
Device (config)# no controller peer-group TestDocPeerGroup bridge-domain-id 111
```

This examples shows the configuration for a NATed member (the IP 172.19.13.15 is outside the NAT):

```
Device (config)# wireless mobility group ip 1.4.91.2 public-ip 172.19.13.15
```

This examples shows the configuration of a member when it is not NATed (the IP 1.4.91.2 is inside the NAT):

```
Device (config)# wireless mobility group ip 1.4.91.2
```

wireless mobility controller (ip_address)

To configure the mobility controller, use the **wireless mobility controller** command.

To convert the switch from MC to MA, use the **no wireless mobility controller** form of the command.

To delete the mobility controllers IP address, use the **no wireless mobility controller ip-address**

```
wireless mobility controller [ip ip-address [public-ip public-ip-address ]]
no wireless mobility controller
no wireless mobility controller ip ip-address
```

Syntax Description	<p>ip <i>ip-address</i> IP address of mobility controller.</p> <p>public-ip <i>public-ip-address</i></p>				
Command Default	None.				
Command Modes	Global Configuration.				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				
Usage Guidelines	<p>This command is valid only for the converged access switch.</p> <p>The NATed address is used to establish communication, and the configured Wireless Management interface is used to identify the peer controller during the CAPWAP exchanges.</p> <p>This examples shows how the controller communicates with the wireless management interface :</p> <pre>Device (config)# wireless mobility controller peer-group SPG1 member ip 10.10.20.6</pre> <p>This examples shows how to add a NAT option along with the wireless managed interface, when the target controller uses NAT:</p> <pre>Device (config)# wireless mobility controller peer-group SPG1 member ip 10.10.20.6 public-ip 10.21.21.2</pre>				

wireless mobility controller peer-group

To configure mobility peer groups, use the **wireless mobility controller peer-group** command, to remove the configuration, use the **no** form of this command.

wireless mobility controller peer-group *peer-group* **member IP** *ip-address* **mode centralized**

Syntax Description		
	<i>peer group</i>	Name of the peer group.
	member IP	Adds a peer group member.
	<i>ip-address</i>	IP address of the peer group member to be added.
	mode centralized	Configures the management mode of the peer group member as centrally managed.

Command Default The centralized mode is off.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.7.0 E	This command was introduced.

```
Device enable
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wireless mobility controller peer-group peer1 member ip 10.0.0.1 mode
centralized
```

wireless mobility group keepalive

To configure the mobility group parameter and keep alive its ping parameters, use the **wireless mobility group keepalive** command. To remove a mobility group parameter, use the **no** form of the command.

wireless mobility group keepalive {**count** *number* | **interval** *interval*}

no wireless mobility group keepalive {**count** *number* | **interval** *interval*}

Syntax Description

count <i>number</i>	Number of times that a ping request is sent to a mobility group member before the member is considered unreachable. The range is from 3 to 20. The default is 3.
interval <i>interval</i>	Interval of time between each ping request sent to a mobility group member. The range is from 1 to 30 seconds. The default value is 10 seconds.

Command Default

3 seconds for count and 10 seconds for interval.

Command Modes

Global Configuration.

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

The default values for *interval* is ten seconds and the default for *retries* is set to three.

This example shows how to specify the amount of time between each ping request sent to a mobility group member to 10 seconds:

```
Device(config)# wireless mobility group keepalive count 10
```

wireless mobility group member ip

To add or delete users from mobility group member list, use the **wireless mobility group member ip** command. To remove a member from the mobility group, use the **no** form of the command.

```
wireless mobility group member ip ip-address [public-ip public-ip-address] [group group-name]
no wireless mobility group member ip ip-address
```

Syntax Description	<i>ip-address</i>	The IP address of the member controller.
	public-ip <i>public-ip-address</i>	(Optional) Member controller public IP address. Note This command is used only when the member is behind a NAT. Only static IP NAT is supported.
	group <i>group-name</i>	(Optional) Member controller group name. Note This command is used only when the member added in not in the same group as the local mobility controller.

Command Default None.

Command Modes Global Configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines The mobility group is used when there is more than one Mobility Controller (MC) in a given deployment. The mobility group can be assigned with a name or it can use the default group name. The mobility group members need to be configured on all the members of the group to roam within the group.

This example shows how to add a member in a mobility group:

```
Device(config)# mobility group member ip 10.104.171.101 group TestDocGroup
```

wireless mobility group name

To configure the mobility domain name, use the **wireless mobility group name** command. To remove the mobility domain name, use the **no** form of the command.



Note If you are configuring the mobility group in a network where network address translation (NAT) is enabled, enter the IP address that is sent to the controller from the NAT device rather than the controller's management interface IP address. Otherwise, mobility will fail among controllers in the mobility group.

wireless mobility group name *domain-name*
no wireless mobility group name

Syntax Description *domain-name* Creates a mobility group by entering this command. The domain name can be up to 31 case-sensitive characters.

Command Default Default.

Command Modes Global Configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to configure a mobility domain name lab1:

```
Device(config)# wireless mobility group domain lab1
```

wireless mobility load-balance

This command is used to load-balance the mobile clients on a mobility anchor (MA) from a switch peer group (SPG) that is least loaded and is chosen to act as the point of presence for the mobile client.

To configure the mobility load-balance status, use the **wireless mobility load-balance** command.

To disable the mobility load-balance, use the **no wirelessmobility load-balance** form of the command.

To configure the client load on the switch where mobility load-balance is turned on, use the **no wirelessmobility load-balance** threshold form of the command.

wireless mobility load-balance [**threshold** *threshold*]
 [{no}]**wireless mobility load-balance** [**threshold**]

[{no}]**wireless mobility load-balance**

Syntax Description	threshold <i>threshold</i> Configures the threshold for the number of clients that can be anchored locally.
---------------------------	--

Command Default	Load balance enabled and set at a value of 1000.
------------------------	--

Command Modes	Global Configuration.
----------------------	-----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines	<ul style="list-style-type: none"> • This command is only supported on a mobility agent. • By default, the threshold can accommodate more than fifty percent of the total clients on the node. Any client joining the switch after the reaching the configured threshold value is automatically anchored to the least loaded switch within the same switch peer group.
-------------------------	--

This example shows how to configure the mobility load-balance status with a threshold set at 150.

```
Device(config)# wireless mobility load-balance threshold 150
```

show wireless mobility

To view the wireless mobility summary, use the **show wireless mobility** command.

show wireless mobility { **load-balance summary agent mobility-agent-ip client summary** | **ap-list ip-address ip-address** | **controller client summary** | **dtls connections** | **statistics summary** }

Syntax Description		
load-balance summary		Shows the mobility load-balance properties.
agent mobility-agent-ip client summary		Shows the active clients on a mobility agent.
ap-list ip-address ip-address		Shows the list of Cisco APs known to the mobility group.
controller client summary		Shows the active clients in the subdomain.
dtls connections		Shows the DTLS server status.
statistics		Shows the statistics for the Mobility manager.
summary		Shows the summary of the mobility manager.

Command Default None

Command Modes Global Configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display a summary of the mobility manager:

```
Device (config)# show wireless mobility ap-list
```

AP name	AP radio MAC	Controller IP	Learnt from
TSIM_AP-101	0000.2000.6600	9.9.9.2	Self
TSIM_AP-102	0000.2000.6700	9.9.9.2	Self
TSIM_AP-103	0000.2000.6800	9.9.9.2	Self
TSIM_AP-400	0000.2001.9100	9.9.9.2	Self
TSIM_AP-402	0000.2001.9300	9.9.9.2	Self
TSIM_AP-403	0000.2001.9400	9.9.9.2	Self
TSIM_AP-406	0000.2001.9700	9.9.9.2	Self
TSIM_AP-407	0000.2001.9800	9.9.9.2	Self
TSIM_AP-409	0000.2001.9a00	9.9.9.2	Self

clear wireless mobility statistics

To clear wireless statistics, use the **clear wireless mobility statistics** command.

clear wireless mobility statistics

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

You can clear all the information by using the **clear wireless mobility statistics** command.

This example shows how to clear wireless mobility statistics:

```
Device (config)# clear wireless mobility statistics
```



PART **X**

Network Management

- [Network Management Commands, on page 731](#)



Network Management Commands

- [ip wccp](#), on page 733
- [monitor capture \(interface/control plane\)](#), on page 735
- [monitor capture buffer](#), on page 739
- [monitor capture clear](#), on page 740
- [monitor capture export](#), on page 741
- [monitor capture file](#), on page 742
- [monitor capture limit](#), on page 744
- [monitor capture match](#), on page 745
- [monitor capture start](#), on page 746
- [monitor capture stop](#), on page 747
- [monitor session](#), on page 748
- [monitor session destination](#), on page 750
- [monitor session filter](#), on page 754
- [monitor session source](#), on page 756
- [show ip sla statistics](#), on page 759
- [show monitor](#), on page 761
- [show monitor capture](#), on page 763
- [show platform ip wccp](#), on page 765
- [show platform software swspan](#), on page 766
- [snmp-server enable traps](#), on page 768
- [snmp-server enable traps bridge](#), on page 771
- [snmp-server enable traps bulkstat](#), on page 772
- [snmp-server enable traps call-home](#), on page 773
- [snmp-server enable traps cef](#), on page 774
- [snmp-server enable traps cpu](#), on page 775
- [snmp-server enable traps envmon](#), on page 776
- [snmp-server enable traps errdisable](#), on page 777
- [snmp-server enable traps flash](#), on page 778
- [snmp-server enable traps isis](#), on page 779
- [snmp-server enable traps license](#), on page 780
- [snmp-server enable traps mac-notification](#), on page 781
- [snmp-server enable traps ospf](#), on page 782
- [snmp-server enable traps pim](#), on page 783

- [snmp-server enable traps port-security, on page 784](#)
- [snmp-server enable traps power-ethernet, on page 785](#)
- [snmp-server enable traps snmp, on page 786](#)
- [snmp-server enable traps stackwise, on page 787](#)
- [snmp-server enable traps storm-control, on page 789](#)
- [snmp-server enable traps stpx, on page 790](#)
- [snmp-server enable traps transceiver, on page 791](#)
- [snmp-server enable traps vrfmib, on page 792](#)
- [snmp-server enable traps vstack, on page 793](#)
- [snmp-server engineID, on page 794](#)
- [snmp-server host, on page 795](#)
- [switchport mode access, on page 799](#)
- [switchport voice vlan, on page 800](#)

ip wccp

To enable the web cache service, and specify the service number that corresponds to a dynamic service that is defined by the application engine, use the **ip wccp** global configuration command on the device. Use the **no** form of this command to disable the service.

```
ip wccp {web-cache | service-number} [group-address groupaddress] [group-list access-list]
[redirect-list access-list] [password encryption-number password]
no ip wccp {web-cache | service-number} [group-address groupaddress] [group-list access-list]
[redirect-list access-list] [password encryption-number password]
```

Syntax Description		
web-cache		Specifies the web-cache service (WCCP Version 1 and Version 2).
<i>service-number</i>		Dynamic service identifier, which means the service definition is dictated by the cache. The dynamic service number can be from 0 to 254. The maximum number of services is 256, which includes the web-cache service specified with the web-cache keyword.
group-address <i>groupaddress</i>		(Optional) Specifies the multicast group address used by the devices and the application engines to participate in the service group.
group-list <i>access-list</i>		(Optional) If a multicast group address is not used, specifies a list of valid IP addresses that correspond to the application engines that are participating in the service group.
redirect-list <i>access-list</i>		(Optional) Specifies the redirect service for specific hosts or specific packets from hosts.
password <i>encryption-number</i> <i>password</i>		(Optional) Specifies an encryption number. The range is 0 to 7. Use 0 for not encrypted, and use 7 for proprietary. Also, specifies a password name up to seven characters in length. The device combines the password with the MD5 authentication value to create security for the connection between the device and the application engine. By default, no password is configured, and no authentication is performed.

Command Default WCCP services are not enabled on the device.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines WCCP transparent caching bypasses Network Address Translation (NAT) when Cisco Express Forwarding switching is enabled. To work around this situation, configure WCCP transparent caching in the outgoing direction, enable Cisco Express Forwarding switching on the content engine interface, and specify the **ip wccp web-cache redirect out** command. Configure WCCP in the incoming direction on the inside interface by

specifying the **ip wccp redirect exclude in** command on the router interface facing the cache. This configuration prevents the redirection of any packets arriving on that interface.

You can also include a redirect list when configuring a service group. The specified redirect list will deny packets with a NAT (source) IP address and prevent redirection.

This command instructs a device to enable or disable support for the specified service number or the web-cache service name. A service number can be from 0 to 254. Once the service number or name is enabled, the router can participate in the establishment of a service group.

When the **no ip wccp** command is entered, the device terminates participation in the service group, deallocates space if none of the interfaces still have the service configured, and terminates the WCCP task if no other services are configured.

The keywords following the **web-cache** keyword and the *service-number* argument are optional and may be specified in any order, but only may be specified once.

Example

The following example configures a web cache, the interface connected to the application engine or the server, and the interface connected to the client:

```
Device(config)# ip wccp web-cache
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# no switchport
Device(config-if)# ip address 172.20.10.30 255.255.255.0
Device(config-if)# no shutdown
Device(config-if)# exit
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# no switchport
Device(config-if)#
*Dec 6 13:11:29.507: %LINK-3-UPDOWN: Interface GigabitEthernet1/0/3, changed state to down

Device(config-if)# ip address 175.20.20.10 255.255.255.0
Device(config-if)# no shutdown
Device(config-if)# ip wccp web-cache redirect in
Device(config-if)# ip wccp web-cache group-listen
Device(config-if)# exit
```

Related Topics

[show platform ip wccp](#), on page 765

monitor capture (interface/control plane)

To configure monitor capture points specifying an attachment point and the packet flow direction or add more attachment points to a capture point, use the **monitor capture** command in privileged EXEC mode. To disable the monitor capture with the specified attachment point and the packet flow direction or disable one of multiple attachment points on a capture point, use the **no** form of this command.

monitor capture {*capture-name*} {**interface** *interface-type interface-id* | **control-plane**} {**in** | **out** | **both**}

no monitor capture {*capture-name*} {**interface** *interface-type interface-id* | **control-plane**} {**in** | **out** | **both**}

Syntax Description		
<i>capture-name</i>		The name of the capture to be defined.
interface <i>interface-type interface-id</i>		Specifies an interface with <i>interface-type</i> and <i>interface-id</i> as an attachment point. The arguments have these meanings: <ul style="list-style-type: none"> • GigabitEthernet <i>interface-id</i>—A Gigabit Ethernet IEEE 802.3z interface. • vlan <i>vlan-id</i>—A VLAN. The range for <i>vlan-id</i> is 1 to 4095. • capwap <i>capwap-id</i>—Specifies a Control and Provisioning of Wireless Access Points Protocol (CAPWAP) tunneling interface. For a list of CAPWAP tunnels that can be used as attachment points, use the show capwap summary command. <p>Note This is the only attachment point that can be used for a wireless capture. When using this interface as an attachment point, no other interface types can be used as attachment points on the same capture point.</p>
control-plane		Specifies the control plane as an attachment point.
in out both		Specifies the traffic direction to be captured.

Command Default A Wireshark capture is not configured.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Once an attachment point has been associated with a capture point using this command, the only way to change its direction is to remove the attachment point using the **no** form of the command and reattach the attachment point with the new direction. An attachment point's direction cannot be overridden.

If an attachment point is removed from a capture point and only one attachment point is associated with it, the capture point is effectively deleted.

Multiple attachment points can be associated with a capture point by re-running this command with another attachment point. An example is provided below.

Multiple capture points can be defined, but only one can be active at a time. In other words, you have to stop one before you can start the other.

Packets captured in the output direction of an interface might not reflect the changes made by switch rewrite (includes TTL, VLAN tag, CoS, checksum, MAC addresses, DSCP, precedent, UP, etc.).

No specific order applies when defining a capture point; you can define capture point parameters in any order. The Wireshark CLI allows as many parameters as possible on a single line. This limits the number of commands required to define a capture point.

Neither VRFs, management ports, nor private VLANs can be used as attachment points.

Wireshark cannot capture packets on a destination SPAN port.

When a VLAN is used as a Wireshark attachment point, packets are captured in the input direction only.

Wireless (CAPWAP) Usage Considerations

The only form of wireless capture is a CAPWAP tunnel capture.

When capturing CAPWAP tunnels, no other interface types can be used as attachment points on the same capture point. Also, the only different type of attachment point allowed on the same capture point is the control plane. The combination of control plane and CAPWAP tunnel attachment points should be able to capture all wireless-related traffic.

Capturing multiple CAPWAP tunnels is supported. ACLs for each CAPWAP tunnel will be combined and sent to the switch as a single ACL.

Core filters will not be applied and can be omitted when capturing a CAPWAP tunnel. When control plane and CAPWAP tunnels are mixed, the core filter will not be applied on the control plane packets either.

To capture a CAPWAP non-data tunnel, capture traffic on the management VLAN and apply an appropriate ACL to filter the traffic. Note that this ACL will be combined with the core filter ACL and assigned to the switch as a single ACL.

Examples

To define a capture point using a physical interface as an attachment point:

```
Device# monitor capture mycap interface GigabitEthernet1/0/1 in
Device# monitor capture mycap match ipv4 any any
```



Note

The second command defines the core filter for the capture point. This is required for a functioning capture point unless you are using a CAPWAP tunneling attachment point in your capture point.

If you are using CAPWAP tunneling attachment points in your capture point, you cannot use core filters.

To define a capture point with multiple attachment points:

```
Device# monitor capture mycap interface GigabitEthernet1/0/1 in
Device# monitor capture mycap match ipv4 any any
Device# monitor capture mycap control-plane in
Device# show monitor capture mycap parameter
```

```
monitor capture mycap interface GigabitEthernet1/0/1 in
monitor capture mycap control-plane in
```

To remove an attachment point from a capture point defined with multiple attachment points:

```
Device# show monitor capture mycap parameter
monitor capture mycap interface GigabitEthernet1/0/1 in
monitor capture mycap control-plane in
Device# no monitor capture mycap control-plane
Device# show monitor capture mycap parameter
monitor capture mycap interface GigabitEthernet1/0/1 in
```

To define a capture point with a CAPWAP attachment point:

```
Device# show capwap summary
```

```
CAPWAP Tunnels General Statistics:
```

```
Number of Capwap Data Tunnels      = 1
Number of Capwap Mobility Tunnels   = 0
Number of Capwap Multicast Tunnels = 0
```

Name	APName	Type	PhyPortIf	Mode	McastIf
Ca0	AP442b.03a9.6715	data	Gi3/0/6	unicast	-

Name	SrcIP	SrcPort	DestIP	DstPort	DtlsEn	MTU	Xact
Ca0	10.10.14.32	5247	10.10.14.2	38514	No	1449	0

```
Device# monitor capture mycap interface capwap 0 both
Device# monitor capture mycap file location flash:mycap.pcap
Device# monitor capture mycap file buffer-size 1
Device# monitor capture mycap start
```

```
*Aug 20 11:02:21.983: %BUFCAP-6-ENABLE: Capture Point mycap enabled.on
```

```
Device# show monitor capture mycap parameter
monitor capture mycap interface capwap 0 in
monitor capture mycap interface capwap 0 out
monitor capture mycap file location flash:mycap.pcap buffer-size 1
Device#
Device# show monitor capture mycap
```

```
Status Information for Capture mycap
```

```
Target Type:
Interface: CAPWAP,
  Ingress:
0
  Egress:
0
Status : Active
Filter Details:
  Capture all packets
Buffer Details:
  Buffer Type: LINEAR (default)
File Details:
  Associated file name: flash:mycap.pcap
  Size of buffer(in MB): 1
Limit Details:
  Number of Packets to capture: 0 (no limit)
  Packet Capture duration: 0 (no limit)
  Packet Size to capture: 0 (no limit)
  Packets per second: 0 (no limit)
```

```

Packet sampling rate: 0 (no sampling)
Device#
Device# show monitor capture file flash:mycap.pcap
 1 0.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 2 0.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 3 2.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 4 2.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 5 3.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 6 4.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 7 4.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 8 5.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 9 5.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
10 6.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
11 8.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
12 9.225986 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
13 9.225986 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
14 9.225986 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
15 9.231998 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
16 9.231998 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
17 9.231998 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
18 9.236987 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
19 10.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
20 10.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
21 12.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
22 12.239993 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
23 12.244997 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
24 12.244997 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
25 12.250994 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
26 12.256990 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
27 12.262987 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
28 12.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
29 12.802012 10.10.14.3 -> 10.10.14.255 NBNS Name query NB WPAD.<00>
30 13.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....

```

Related Topics

[monitor capture buffer](#), on page 739

[monitor capture file](#), on page 742

[show monitor capture](#), on page 763

monitor capture buffer

To configure the buffer for monitor capture (WireShark), use the **monitor capture buffer** command in privileged EXEC mode. To disable the monitor capture buffer or change the buffer back to a default linear buffer from a circular buffer, use the **no** form of this command.

```
monitor capture {capture-name} buffer {circular [size buffer-size ] | size buffer-size}
no monitor capture {capture-name} buffer [circular ]
```

Syntax Description	<i>capture-name</i>	The name of the capture whose buffer is to be configured.
	circular	Specifies that the buffer is of a circular type. The circular type of buffer continues to capture data, even after the buffer is consumed, by overwriting the data captured previously.
	size <i>buffer-size</i>	(Optional) Specifies the size of the buffer. The range is from 1 MB to 100 MB.
Command Default	A linear buffer is configured.	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	When you first configure a WireShark capture, a circular buffer of a small size is suggested.	

Example

To configure a circular buffer with a size of 1 MB:

```
Device# monitor capture mycap buffer circular size 1
```

Related Topics

- [monitor capture \(interface/control plane\)](#), on page 735
- [monitor capture file](#), on page 742
- [show monitor capture](#), on page 763

monitor capture clear

To clear the monitor capture (WireShark) buffer, use the **monitor capture clear** command in privileged EXEC mode.

monitor capture {*capture-name*} **clear**

Syntax Description	<i>capture-name</i> The name of the capture whose buffer is to be cleared.
---------------------------	--

Command Default	The buffer content is not cleared.
------------------------	------------------------------------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	Use the monitor capture clear command either during capture or after the capture has stopped either because one or more end conditions has been met, or you entered the monitor capture stop command. If you enter the monitor capture clear command after the capture has stopped, the monitor capture export command that is used to store the contents of the captured packets in a file will have no impact because the buffer has no captured packets.
-------------------------	---

If you have more than one capture that is storing packets in a buffer, clear the buffer before starting a new capture to avoid memory loss.

Example

To clear the buffer contents for capture mycap:

```
Device# monitor capture mycap clear
```

monitor capture export

To export a monitor capture (WireShark) to a file, use the **monitor capture export** command in privileged EXEC mode.

```
monitor capture {capture-name} export file-location : file-name
```

Syntax Description	<i>capture-name</i>	The name of the capture to be exported.
	<i>file-location</i> : <i>file-name</i>	(Optional) Specifies the location and file name of the capture storage file. Acceptable values for <i>file-location</i> : <ul style="list-style-type: none"> • flash—On-board flash storage • (usbflash0:)— USB drive
Command Default	The captured packets are not stored.	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **monitor capture export** command only when the storage destination is a capture buffer. The file may be stored either remotely or locally. Use this command either during capture or after the packet capture has stopped. The packet capture is stopped when one or more end conditions have been met or you entered the **monitor capture stop** command.

When WireShark is used on switches in a stack, packet captures can be stored only on the devices specified for *file-location* above that are connected to the active switch. Example: flash1 is connected to the active switch. flash2 is connected to the secondary switch. Only flash1 can be used to store packet captures.



Note Attempts to store packet captures on unsupported devices or devices not connected to the active switch will probably result in errors.

Example

To export the capture buffer contents to mycap.pcap on a flash drive:

```
Device# monitor capture mycap export flash:mycap.pcap
```

monitor capture file

To configure monitor capture (WireShark) storage file attributes, use the **monitor capture file** command in privileged EXEC mode. To remove a storage file attribute, use the **no** form of this command.

```
monitor capture {capture-name} file{ [ buffer-size temp-buffer-size ] [ location file-location :  
file-name ] [ ring number-of-ring-files ] [ size total-size ] }  
no monitor capture {capture-name} file{ [ buffer-size ] [ location ] [ ring ] [ size ] }
```

Syntax Description		
<i>capture-name</i>		The name of the capture to be modified.
buffer-size <i>temp-buffer-size</i>		(Optional) Specifies the size of the temporary buffer. The range for <i>temp-buffer-size</i> is 1 to 100 MB. This is specified to reduce packet loss.
location <i>file-location</i> : <i>file-name</i>		(Optional) Specifies the location and file name of the capture storage file. Acceptable values for <i>file-location</i> : <ul style="list-style-type: none"> • flash—On-board flash storage • (usbflash0:)— USB drive
ring <i>number-of-ring-files</i>		(Optional) Specifies that the capture is to be stored in a circular file chain and the number of files in the file ring.
size <i>total-size</i>		(Optional) Specifies the total size of the capture files.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use the **monitor capture file** command only when the storage destination is a file. The file may be stored either remotely or locally. Use this command after the packet capture has stopped. The packet capture is stopped when one or more end conditions have been met or you entered the **monitor capture stop** command.

When WireShark is used on switches in a stack, packet captures can be stored only on the devices specified for *file-location* above that are connected to the active switch. Example: flash1 is connected to the active switch. flash2 is connected to the secondary switch. Only flash1 can be used to store packet captures.



Note Attempts to store packet captures on unsupported devices or devices not connected to the active switch will probably result in errors.

Example

To specify that the storage file name is mycap.pcap, stored on a flash drive:

```
Device# monitor capture mycap file location flash:mycap.pcap
```

Related Topics

[monitor capture \(interface/control plane\)](#), on page 735

[monitor capture buffer](#), on page 739

[show monitor capture](#), on page 763

monitor capture limit

To configure capture limits, use the **monitor capture limit** command in privileged EXEC mode. To remove the capture limits, use the **no** form of this command.

```
monitor capture {capture-name} limit { [duration seconds] [packet-length size] [packets num] }
no monitor capture {capture-name} limit [duration] [packet-length] [packets]
```

Syntax Description

<i>capture-name</i>	The name of the capture to be assigned capture limits.
duration <i>seconds</i>	(Optional) Specifies the duration of the capture, in seconds. The range is from 1 to 1000000.
packet-length <i>size</i>	(Optional) Specifies the packet length, in bytes. If the actual packet is longer than the specified length, only the first set of bytes whose number is denoted by the bytes argument is stored.
packets <i>num</i>	(Optional) Specifies the number of packets to be processed for capture.

Command Default

Capture limits are not configured.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Example

To configure a session limit of 60 seconds and a packet segment length of 400 bytes:

```
Device# monitor capture mycap limit duration 60 packet-len 400
```

monitor capture match



Note Do not use this command when capturing a CAPWAP tunnel. Also, when control plane and CAPWAP tunnels are mixed, this command will have no effect.

To define an explicit inline core filter for a monitor (Wireshark) capture, use the **monitor capture match** command in privileged EXEC mode. To remove this filter, use the **no** form of this command.

```
monitor capture {capture-name} match {any | mac mac-match-string | ipv4 {any | host | protocol}{any | host} | ipv6 {any | host | protocol}{any | host}}
```

```
no monitor capture {capture-name} match
```

Syntax Description		
<i>capture-name</i>		The name of the capture to be assigned a core filter.
any		Specifies all packets.
mac <i>mac-match-string</i>		Specifies a Layer 2 packet.
ipv4		Specifies IPv4 packets.
host		Specifies the host.
protocol		Specifies the protocol.
ipv6		Specifies IPv6 packets.

Command Default A core filter is not configured.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Examples

To define a capture point and the core filter for the capture point that matches to any IP version 4 packets on the source or destination:

```
Device# monitor capture mycap interface GigabitEthernet1/0/1 in  
Device# monitor capture mycap match ipv4 any any
```

monitor capture start

To start the capture of packet data at a traffic trace point into a buffer, use the **monitor capture start** command in privileged EXEC mode.

monitor capture {*capture-name*} **start**

Syntax Description	<i>capture-name</i> The name of the capture to be started.
---------------------------	--

Command Default	The buffer content is not cleared.
------------------------	------------------------------------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	Use the monitor capture clear command to enable the packet data capture after the capture point is defined. To stop the capture of packet data, use the monitor capture stop command.
-------------------------	---

Ensure that system resources such as CPU and memory are available before starting a capture.

Example

To start capturing buffer contents:

```
Device# monitor capture mycap start
```

monitor capture stop

To stop the capture of packet data at a traffic trace point, use the **monitor capture stop** command in privileged EXEC mode.

monitor capture { *capture-name* } **stop**

Syntax Description

capture-name The name of the capture to be stopped.

Command Default

The packet data capture is ongoing.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **monitor capture stop** command to stop the capture of packet data that you started using the **monitor capture start** command. You can configure two types of capture buffers: linear and circular. When the linear buffer is full, data capture stops automatically. When the circular buffer is full, data capture starts from the beginning and the data is overwritten.

Example

To stop capturing buffer contents:

```
Device# monitor capture mycap stop
```

monitor session

To create a new Ethernet Switched Port Analyzer (SPAN) or a Remote Switched Port Analyzer (RSPAN) session configuration for analyzing traffic between ports or add to an existing session configuration, use the **monitor session** global configuration command. To clear SPAN or RSPAN sessions, use the **no** form of this command.

monitor session *session-number* {**destination** | **filter** | **source**}

no monitor session {*session-number* [**destination** | **filter** | **source**] | **all** | **local** | **range** *session-range* | **remote**}

Syntax Description

session-number

all

Clears all monitor sessions.

local

Clears all local monitor sessions.

range *session-range*

Clears monitor sessions in the specified range.

remote

Clears all remote monitor sessions.

Command Default

No monitor sessions are configured.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You can verify your settings by entering the **show monitor** privileged EXEC command. You can display SPAN, RSPAN, FSPAN, and FRSPAN configuration on the switch by entering the **show running-config** privileged EXEC command. SPAN information appears near the end of the output.

Example

This example shows how to create a local SPAN session 1 to monitor traffic on Po13 (an EtherChannel port) and limit SPAN traffic in the session only to VLAN 1281. Egress traffic replicates the source; ingress forwarding is not enabled.

```
Device(config)# monitor session 1 source interface Po13
Device(config)# monitor session 1 filter vlan 1281
Device(config)# monitor session 1 destination interface GigabitEthernet2/0/36 encapsulation
replicate
Device(config)# monitor session 1 destination interface GigabitEthernet3/0/36 encapsulation
replicate
```

The following is the output of a **show monitor session all** command after completing these setup instructions:

```
Device# show monitor session all

Session 1
-----
Type                : Local Session
Source Ports        :
  Both              : Po13
Destination Ports   : Gi2/0/36,Gi3/0/36
  Encapsulation     : Replicate
    Ingress         : Disabled
Filter VLANs        : 1281
...
```

Related Topics

- [monitor session destination](#), on page 750
- [monitor session filter](#), on page 754
- [monitor session source](#), on page 756
- [show monitor](#), on page 761

monitor session destination

To start a new Switched Port Analyzer (SPAN) session or Remote SPAN (RSPAN) destination session, to enable ingress traffic on the destination port for a network security device (such as a Cisco IDS Sensor Appliance), and to add or delete interfaces or VLANs to or from an existing SPAN or RSPAN session, use the **monitor session destination** global configuration command. To remove the SPAN or RSPAN session or to remove destination interfaces from the SPAN or RSPAN session, use the **no** form of this command.

```
monitor session session-number destination {interface interface-id [, | -] [encapsulation
{replicate | dot1q} ] {ingress [dot1q | untagged] } | {remote} vlan vlan-id
no monitor session session-number destination {interface interface-id [, | -] [encapsulation
{replicate | dot1q} ] {ingress [dot1q | untagged] } | {remote} vlan vlan-id
```

Syntax Description

session-number

interface *interface-id*

Specifies the destination or source interface for a SPAN or RSPAN session. Valid interfaces are physical ports (including type, stack member, module, and port number). For source interface, port channel is also a valid interface type, and the valid range is 1 to 128.

,

(Optional) Specifies a series of interfaces or VLANs, or separates a range of interfaces or VLANs from a previous range. Enter a space before and after the comma.

-

(Optional) Specifies a range of interfaces or VLANs. Enter a space before and after the hyphen.

encapsulation replicate

(Optional) Specifies that the destination interface replicates the source interface encapsulation method. If not selected, the default is to send packets in native form (untagged).

These keywords are valid only for local SPAN. For RSPAN, the RSPAN VLAN ID overwrites the original VLAN ID; therefore, packets are always sent untagged. The **encapsulation** options are ignored with the **no** form of the command.

encapsulation dot1q

(Optional) Specifies that the destination interface accepts the source interface incoming packets with IEEE 802.1Q encapsulation.

These keywords are valid only for local SPAN. For RSPAN, the RSPAN VLAN ID overwrites the original VLAN ID; therefore, packets are always sent untagged. The **encapsulation** options are ignored with the **no** form of the command.

ingress	Enables ingress traffic forwarding.
dot1q	(Optional) Accepts incoming packets with IEEE 802.1Q encapsulation with the specified VLAN as the default VLAN.
untagged	(Optional) Accepts incoming packets with untagged encapsulation with the specified VLAN as the default VLAN.
isl	Specifies ingress forwarding using ISL encapsulation.
remote	Specifies the remote VLAN for an RSPAN source or destination session. The range is 2 to 1001 and 1006 to 4094. The RSPAN VLAN cannot be VLAN 1 (the default VLAN) or VLAN IDs 1002 to 1005 (reserved for Token Ring and FDDI VLANs).
vlan <i>vlan-id</i>	Sets the default VLAN for ingress traffic when used with only the ingress keyword.

Command Default

No monitor sessions are configured.

If **encapsulation replicate** is not specified on a local SPAN destination port, packets are sent in native form with no encapsulation tag.

Ingress forwarding is disabled on destination ports.

You can specify **all**, **local**, **range *session-range***, or **remote** with the **no monitor session** command to clear all SPAN and RSPAN, all local SPAN, a range, or all RSPAN sessions.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You can set a combined maximum of 8 local SPAN sessions and RSPAN source sessions. You can have a total of 66 SPAN and RSPAN sessions on a switch or switch stack.

A SPAN or RSPAN destination must be a physical port.

You can have a maximum of 64 destination ports on a switch or a switch stack.

Each session can include multiple ingress or egress source ports or VLANs, but you cannot combine source ports and source VLANs in a single session. Each session can include multiple destination ports.

When you use VLAN-based SPAN (VSPAN) to analyze network traffic in a VLAN or set of VLANs, all active ports in the source VLANs become source ports for the SPAN or RSPAN session. Trunk ports are included as source ports for VSPAN, and only packets with the monitored VLAN ID are sent to the destination port.

You can monitor traffic on a single port or VLAN or on a series or range of ports or VLANs. You select a series or range of interfaces or VLANs by using the [, | -] options.

If you specify a series of VLANs or interfaces, you must enter a space before and after the comma. If you specify a range of VLANs or interfaces, you must enter a space before and after the hyphen (-).

EtherChannel ports can be configured as SPAN or RSPAN destination ports. A physical port that is a member of an EtherChannel group can be used as a destination port, but it cannot participate in the EtherChannel group while it is as a SPAN destination.

A port used as a destination port cannot be a SPAN or RSPAN source, nor can a port be a destination port for more than one session at a time.

You can enable IEEE 802.1x authentication on a port that is a SPAN or RSPAN destination port; however, IEEE 802.1x authentication is disabled until the port is removed as a SPAN destination. If IEEE 802.1x authentication is not available on the port, the switch returns an error message. You can enable IEEE 802.1x authentication on a SPAN or RSPAN source port.

If ingress traffic forwarding is enabled for a network security device, the destination port forwards traffic at Layer 2.

Destination ports can be configured to function in these ways:

- When you enter **monitor session** *session_number* **destination interface** *interface-id* with no other keywords, egress encapsulation is untagged, and ingress forwarding is not enabled.
- When you enter **monitor session** *session_number* **destination interface** *interface-id* **ingress**, egress encapsulation is untagged; ingress encapsulation depends on the keywords that follow—**dot1q** or **untagged**.
- When you enter **monitor session** *session_number* **destination interface** *interface-id* **encapsulation replicate** with no other keywords, egress encapsulation replicates the source interface encapsulation; ingress forwarding is not enabled. (This applies to local SPAN only; RSPAN does not support encapsulation replication.)
- When you enter **monitor session** *session_number* **destination interface** *interface-id* **encapsulation replicate ingress**, egress encapsulation replicates the source interface encapsulation; ingress encapsulation depends on the keywords that follow—**dot1q** or **untagged**. (This applies to local SPAN only; RSPAN does not support encapsulation replication.)

You can verify your settings by entering the **show monitor** privileged EXEC command. You can display SPAN, RSPAN, FSPAN, and FRSPAN configuration on the switch by entering the **show running-config** privileged EXEC command. SPAN information appears near the end of the output.

Examples

This example shows how to create a local SPAN session 1 to monitor both sent and received traffic on source port 1 on stack member 1 to destination port 2 on stack member 2:

```
Device(config)# monitor session 1 source interface gigabitethernet1/0/1 both
Device(config)# monitor session 1 destination interface gigabitethernet1/0/2
```

This example shows how to delete a destination port from an existing local SPAN session:

```
Device(config)# no monitor session 2 destination interface gigabitethernet1/0/2
```

This example shows how to configure RSPAN source session 1 to monitor a source interface and to configure the destination RSPAN VLAN 900:

```
Device(config)# monitor session 1 source interface gigabitethernet1/0/1
Device(config)# monitor session 1 destination remote vlan 900
Device(config)# end
```

This example shows how to configure an RSPAN destination session 10 in the switch receiving the monitored traffic:

```
Device(config)# monitor session 10 source remote vlan 900
Device(config)# monitor session 10 destination interface gigabitethernet1/0/2
```

This example shows how to configure the destination port for ingress traffic on VLAN 5 by using a security device that supports IEEE 802.1Q encapsulation. Egress traffic replicates the source; ingress traffic uses IEEE 802.1Q encapsulation.

```
Device(config)# monitor session 2 destination interface gigabitethernet1/0/2 encapsulation
dot1q ingress dot1q vlan 5
```

This example shows how to configure the destination port for ingress traffic on VLAN 5 by using a security device that does not support encapsulation. Egress traffic and ingress traffic are untagged.

```
Device(config)# monitor session 2 destination interface gigabitethernet1/0/2 ingress untagged
vlan 5
```

Related Topics

- [monitor session](#), on page 748
- [monitor session filter](#), on page 754
- [monitor session source](#), on page 756
- [show monitor](#), on page 761

monitor session filter

To start a new flow-based SPAN (FSPAN) session or flow-based RSPAN (FRSPAN) source or destination session, or to limit (filter) SPAN source traffic to specific VLANs, use the **monitor session filter** global configuration command. To remove filters from the SPAN or RSPAN session, use the **no** form of this command.

```
monitor session session-number filter {vlan vlan-id [, | -] }
no monitor session session-number filter {vlan vlan-id [, | -] }
```

Syntax Description	
	<i>session-number</i>
vlan <i>vlan-id</i>	Specifies a list of VLANs as filters on trunk source ports to limit SPAN source traffic to specific VLANs. The <i>vlan-id</i> range is 1 to 4094.
,	(Optional) Specifies a series of VLANs, or separates a range of VLANs from a previous range. Enter a space before and after the comma.
-	(Optional) Specifies a range of VLANs. Enter a space before and after the hyphen.

Command Default No monitor sessions are configured.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You can monitor traffic on a single VLAN or on a series or range of ports or VLANs. You select a series or range of VLANs by using the [, | -] options.

If you specify a series of VLANs, you must enter a space before and after the comma. If you specify a range of VLANs, you must enter a space before and after the hyphen (-).

VLAN filtering refers to analyzing network traffic on a selected set of VLANs on trunk source ports. By default, all VLANs are monitored on trunk source ports. You can use the **monitor session *session_number* filter vlan *vlan-id*** command to limit SPAN traffic on trunk source ports to only the specified VLANs.

VLAN monitoring and VLAN filtering are mutually exclusive. If a VLAN is a source, VLAN filtering cannot be enabled. If VLAN filtering is configured, a VLAN cannot become a source.

You can verify your settings by entering the **show monitor** privileged EXEC command. You can display SPAN, RSPAN, FSPAN, and FRSPAN configuration on the switch by entering the **show running-config** privileged EXEC command. SPAN information appears near the end of the output.

Examples

This example shows how to limit SPAN traffic in an existing session only to specific VLANs:

```
Switch(config)# monitor session 1 filter vlan 100 - 110
```

This example shows how to create a local SPAN session 1 to monitor both sent and received traffic on source port 1 on stack member 1 to destination port 2 on stack member 2 and to filter IPv4 traffic using access list number 122 in an FSPAN session:

```
Switch(config)# monitor session 1 source interface gigabitethernet1/0/1 both
Switch(config)# monitor session 1 destination interface gigabitethernet1/0/2
Switch(config)# monitor session 1 filter ip access-group 122
```

Related Topics

- [monitor session](#), on page 748
- [monitor session destination](#), on page 750
- [monitor session source](#), on page 756
- [show monitor](#), on page 761

monitor session source

To start a new Switched Port Analyzer (SPAN) session or Remote SPAN (RSPAN) source session, or to add or delete interfaces or VLANs to or from an existing SPAN or RSPAN session, use the **monitor session source** global configuration command. To remove the SPAN or RSPAN session or to remove source interfaces from the SPAN or RSPAN session, use the **no** form of this command.

```
monitor session session_number source {interface interface-id [, | -] [both | rx | tx] |
[remote] vlan vlan-id [, | -] [both | rx | tx] }
no monitor session session_number source {interface interface-id [, | -] [both | rx | tx] |
[remote] vlan vlan-id [, | -] [both | rx | tx] }
```

Syntax Description

<i>session_number</i>	
interface <i>interface-id</i>	Specifies the source interface for a SPAN or RSPAN session. Valid interfaces are physical ports (including type, stack member, module, and port number). For source interface, port channel is also a valid interface type, and the valid range is 1 to 48.
,	(Optional) Specifies a series of interfaces or VLANs, or separates a range of interfaces or VLANs from a previous range. Enter a space before and after the comma.
-	(Optional) Specifies a range of interfaces or VLANs. Enter a space before and after the hyphen.
both rx tx	(Optional) Specifies the traffic direction to monitor. If you do not specify a traffic direction, the source interface sends both transmitted and received traffic.
remote	(Optional) Specifies the remote VLAN for an RSPAN source or destination session. The range is 2 to 1001 and 1006 to 4094. The RSPAN VLAN cannot be VLAN 1 (the default VLAN) or VLAN IDs 1002 to 1005 (reserved for Token Ring and FDDI VLANs).
vlan <i>vlan-id</i>	When used with only the ingress keyword, sets default VLAN for ingress traffic.

Command Default

No monitor sessions are configured.

On a source interface, the default is to monitor both received and transmitted traffic.

On a trunk interface used as a source port, all VLANs are monitored.

Command Modes

Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE 3.3SE	This command was introduced.

Usage Guidelines

Traffic that enters or leaves source ports or source VLANs can be monitored by using SPAN or RSPAN. Traffic routed to source ports or source VLANs cannot be monitored.

A source can be a physical port, a port channel, or a VLAN.

Each session can include multiple ingress or egress source ports or VLANs, but you cannot combine source ports and source VLANs in a single session. Each session can include multiple destination ports.

When you use VLAN-based SPAN (VSPAN) to analyze network traffic in a VLAN or set of VLANs, all active ports in the source VLANs become source ports for the SPAN or RSPAN session. Trunk ports are included as source ports for VSPAN, and only packets with the monitored VLAN ID are sent to the destination port.

You can monitor traffic on a single port or VLAN or on a series or range of ports or VLANs. You select a series or range of interfaces or VLANs by using the [,|-] options.

If you specify a series of VLANs or interfaces, you must enter a space before and after the comma. If you specify a range of VLANs or interfaces, you must enter a space before and after the hyphen (-).

You can monitor individual ports while they participate in an EtherChannel, or you can monitor the entire EtherChannel bundle by specifying the **port-channel** number as the RSPAN source interface.

A port used as a destination port cannot be a SPAN or RSPAN source, nor can a port be a destination port for more than one session at a time.

You can enable IEEE 802.1x authentication on a SPAN or RSPAN source port.

You can verify your settings by entering the **show monitor** privileged EXEC command. You can display SPAN, RSPAN, FSPAN, and FRSPAN configuration on the switch by entering the **show running-config** privileged EXEC command. SPAN information appears near the end of the output.

Examples

This example shows how to create a local SPAN session 1 to monitor both sent and received traffic on source port 1 on stack member 1 to destination port 2 on stack member 2:

```
Switch(config)# monitor session 1 source interface gigabitethernet1/0/1 both
Switch(config)# monitor session 1 destination interface gigabitethernet1/0/2
```

This example shows how to configure RSPAN source session 1 to monitor multiple source interfaces and to configure the destination RSPAN VLAN 900.

```
Switch(config)# monitor session 1 source interface gigabitethernet1/0/1
Switch(config)# monitor session 1 source interface port-channel 2 tx
Switch(config)# monitor session 1 destination remote vlan 900
Switch(config)# end
```

Related Topics

[monitor session](#), on page 748

[monitor session destination](#), on page 750

[monitor session filter](#), on page 754

[show monitor](#), on page 761

show ip sla statistics

To display current or aggregated operational status and statistics of all Cisco IOS IP Service Level Agreement (SLA) operations or a specified operation, use the **show ip sla statistics** command in user EXEC or privileged EXEC mode.

show ip sla statistics [*operation-number* [**details**]] | **aggregated** [*operation-number* | **details**]
| **details**]

Syntax Description		
operation-number	(Optional) Number of the operation for which operational status and statistics are displayed. Accepted values are from 1 to 2147483647.	
details	(Optional) Specifies detailed output.	
aggregated	(Optional) Specifies the IP SLA aggregated statistics.	

Command Default Displays output for all running IP SLA operations.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE 3.3SE	This command was introduced.

Usage Guidelines Use the **show ip sla statistics** to display the current state of IP SLA operations, including how much life the operation has left, whether the operation is active, and the completion time. The output also includes the monitoring data returned for the last (most recently completed) operation. This generated operation ID is displayed when you use the **show ip sla** configuration command for the base multicast operation, and as part of the summary statistics for the entire operation.

Enter the **show** command for a specific operation ID to display details for that one responder.

Examples

The following is sample output from the **show ip sla statistics** command:

```
Device# show ip sla statistics

Current Operational State
Entry Number: 3
Modification Time: *22:15:43.000 UTC Sun Feb 11 2001
Diagnostics Text:
Last Time this Entry was Reset: Never
Number of Octets in use by this Entry: 1332
Number of Operations Attempted: 2
Current Seconds Left in Life: 3511
Operational State of Entry: active
Latest Completion Time (milliseconds): 544
Latest Operation Start Time: *22:16:43.000 UTC Sun Feb 11 2001
```

```
Latest Oper Sense: ok
Latest Sense Description: 200 OK
Total RTT: 544
DNS RTT: 12
TCP Connection RTT: 28
HTTP Transaction RTT: 504
HTTP Message Size: 9707
```

show monitor

To display information about all Switched Port Analyzer (SPAN) and Remote SPAN (RSPAN) sessions, use the **show monitor** command in EXEC mode.

show monitor [**session** {*session_number* | **all** | **local** | **range list** | **remote**} [**detail**]]

Syntax Description	
session	(Optional) Displays information about specified SPAN sessions.
<i>session_number</i>	
all	(Optional) Displays all SPAN sessions.
local	(Optional) Displays only local SPAN sessions.
range list	(Optional) Displays a range of SPAN sessions, where <i>list</i> is the range of valid sessions. The range is either a single session or a range of sessions described by two numbers, the lower one first, separated by a hyphen. Do not enter any spaces between comma-separated parameters or in hyphen-specified ranges. Note This keyword is available only in privileged EXEC mode.
remote	(Optional) Displays only remote SPAN sessions.
detail	(Optional) Displays detailed information about the specified sessions.

Command Modes	
	User EXEC
	Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The output is the same for the **show monitor** command and the **show monitor session all** command.

Examples

This is an example of output for the **show monitor** user EXEC command:

```
Device# show monitor
Session 1
-----
```

```

Type : Local Session
Source Ports :
RX Only : Gi4/0/1
Both : Gi4/0/2-3,Gi4/0/5-6
Destination Ports : Gi4/0/20
Encapsulation : Replicate
Ingress : Disabled
Session 2
-----
Type : Remote Source Session
Source VLANs :
TX Only : 10
Both : 1-9
Dest RSPAN VLAN : 105

```

This is an example of output for the **show monitor** user EXEC command for local SPAN source session 1:

```

Device# show monitor session 1
Session 1
-----
Type : Local Session
Source Ports :
RX Only : Gi4/0/1
Both : Gi4/0/2-3,Gi4/0/5-6
Destination Ports : Gi4/0/20
Encapsulation : Replicate
Ingress : Disabled

```

This is an example of output for the **show monitor session all** user EXEC command when ingress traffic forwarding is enabled:

```

Device# show monitor session all
Session 1
-----
Type : Local Session
Source Ports :
Both : Gi4/0/2
Destination Ports : Gi4/0/3
Encapsulation : Native
Ingress : Enabled, default VLAN = 5
Ingress encaps : DOT1Q
Session 2
-----
Type : Local Session
Source Ports :
Both : Gi4/0/8
Destination Ports : Gi4/0/12
Encapsulation : Replicate
Ingress : Enabled, default VLAN = 4
Ingress encaps : Untagged

```

Related Topics

- [monitor session](#), on page 748
- [monitor session destination](#), on page 750
- [monitor session filter](#), on page 754
- [monitor session source](#), on page 756

show monitor capture

To display monitor capture (WireShark) content, use the **show monitor capture file** command in privileged EXEC mode.

show monitor capture [*capture-name* [**buffer**] | **file** *file-location* : *file-name*][**brief** | **detailed** | **display-filter** *display-filter-string*]

Syntax Description	
<i>capture-name</i>	(Optional) Specifies the name of the capture to be displayed.
buffer	(Optional) Specifies that a buffer associated with the named capture is to be displayed.
file <i>file-location</i> : <i>file-name</i>	(Optional) Specifies the file location and name of the capture storage file to be displayed.
brief	(Optional) Specifies the display content in brief.
detailed	(Optional) Specifies detailed display content.
display-filter <i>display-filter-string</i>	Filters the display content according to the <i>display-filter-string</i> .

Command Default Displays all capture content.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines none

Example

To display the capture for a capture called mycap:

```
Device# show monitor capture mycap

Status Information for Capture mycap
  Target Type:
  Interface: CAPWAP,
  Ingress:
  0
  Egress:
  0
  Status : Active
  Filter Details:
    Capture all packets
  Buffer Details:
    Buffer Type: LINEAR (default)
  File Details:
    Associated file name: flash:mycap.pcap
    Size of buffer(in MB): 1
```

Limit Details:

Number of Packets to capture: 0 (no limit)
Packet Capture duration: 0 (no limit)
Packet Size to capture: 0 (no limit)
Packets per second: 0 (no limit)
Packet sampling rate: 0 (no sampling)

Related Topics

[monitor capture \(interface/control plane\)](#), on page 735

[monitor capture buffer](#), on page 739

[monitor capture file](#), on page 742

show platform ip wccp

To display platform-dependent Web Cache Communication Protocol (WCCP) information, use the **show platform ip wccp** privileged EXEC command.

```
show platform ip wccp {cache-engines | interfaces | service-groups} [switch switch-number]
```

Syntax Description	cache-engines	Displays WCCP cache engines.
	interfaces	Displays WCCP interfaces.
	service-groups	Displays WCCP service groups.
	switch	(Optional) Displays WCCP information only for specified <i>switch-number</i> .
	<i>switch-number</i>	

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE/Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use this command only when you are working directly with a technical support representative while troubleshooting a problem. Do not use this command unless a technical support representative asks you to do so.

This command is available only if your device is running the IP Services feature set.

The following example displays WCCP interfaces:

```
Device# show platform ip wccp interfaces

WCCP Interfaces

**** WCCP Interface Gi1/0/3 iif_id:0x104a60000000087 (#SG:1), vrf:0 Ingress
le_handle:0x565dd208 IPv4 Sw-Label:3, Asic-Label:3

* Service group id:0 type: Well-known token:126 vrf:0 (ref count:1)
Open service prot: PROT_TCP l4_type: Dest ports priority: 240
port[0]: 80
```

Related Topics

[ip wccp](#), on page 733

show platform software swspan

To display switched port analyzer (SPAN) information, use the **show platform software swspan** command in privileged EXEC mode.

show platform software swspan {switch} {{{F0 | FP active} counters} | R0 | RP active} {destination sess-id *session-ID* | source sess-id *session-ID*}

Syntax Description

switch	Displays information about the switch.
F0	Displays information about the Embedded Service Processor (ESP) slot 0.
FP	Displays information about the ESP.
active	Displays information about the active instance of the ESP or the Route Processor (RP).
counters	Displays the SWSPAN message counters.
R0	Displays information about the RP slot 0.
RP	Displays information the RP.
destination sess-id <i>session-ID</i>	Displays information about the specified destination session.
source sess-id <i>session-ID</i>	Displays information about the specified source session.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Denali 16.1.1	This command was introduced in a release prior to Cisco IOS XE Denali 16.1.1.

Usage Guidelines

If the session number does not exist or if the SPAN session is a remote destination session, the command output will display the following message "% Error: No Information Available."

Examples

The following is sample output from the **show platform software swspan FP active source** command:

```
Switch# show platform software swspan FP active source sess-id 0
```

```
Showing SPAN source detail info
```

```
Session ID : 0
Intf Type : PORT
Port dpidx : 30
PD Sess ID : 1
Session Type : Local
Direction : Ingress
Filter Enabled : No
ACL Configured : No
AOM Object id : 579
AOM Object Status : Done
Parent AOM object Id : 118
```

```
Parent AOM object Status : Done
```

```
Session ID : 9
Intf Type : PORT
Port dpidx : 8
PD Sess ID : 0
Session Type : Local
Direction : Ingress
Filter Enabled : No
ACL Configured : No
AOM Object id : 578
AOM Object Status : Done
Parent AOM object Id : 70
Parent AOM object Status : Done
```

The following is sample output from the **show platform software swspan RP active destination** command:

```
Switch# show platform software swspan RP active destination
```

```
Showing SPAN destination table summary info
```

```
Sess-id IF-type IF-id Sess-type
-----
1 PORT 19 Remote
```

snmp-server enable traps

To enable the device to send Simple Network Management Protocol (SNMP) notifications for various traps or inform requests to the network management system (NMS), use the **snmp-server enable traps** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps [auth-framework [sec-violation] | bridge | call-home | cluster |
config | config-copy | config-ctid | copy-config | cpu | dot1x | energywise | entity |
envmon | errdisable | event-manager | flash | fru-ctrl | license | mac-notification |
port-security | power-ethernet | rep | snmp | stackwise | storm-control | stpx | syslog
| transceiver | tty | vlan-membership | vlancreate | vlandelete | vstack | vtp ]
no snmp-server enable traps [auth-framework [sec-violation] | bridge | call-home | cluster
| config | config-copy | config-ctid | copy-config | cpu | dot1x | energywise | entity |
envmon | errdisable | event-manager | flash | fru-ctrl | license | mac-notification |
port-security | power-ethernet | rep | snmp | stackwise | storm-control | stpx | syslog
| transceiver | tty | vlan-membership | vlancreate | vlandelete | vstack | vtp ]
```

Syntax Description

auth-framework	(Optional) Enables SNMP CISCO-AUTH-FRAMEWORK-MIB traps.
sec-violation	(Optional) Enables SNMP camSecurityViolationNotif notifications.
bridge	(Optional) Enables SNMP STP Bridge MIB traps.*
call-home	(Optional) Enables SNMP CISCO-CALLHOME-MIB traps.*
cluster	(Optional) Enables SNMP cluster traps.
config	(Optional) Enables SNMP configuration traps.
config-copy	(Optional) Enables SNMP configuration copy traps.
config-ctid	(Optional) Enables SNMP configuration CTID traps.
copy-config	(Optional) Enables SNMP copy-configuration traps.
cpu	(Optional) Enables CPU notification traps.*
dot1x	(Optional) Enables SNMP dot1x traps.*
energywise	(Optional) Enables SNMP energywise traps.*
entity	(Optional) Enables SNMP entity traps.
envmon	(Optional) Enables SNMP environmental monitor traps.*
errdisable	(Optional) Enables SNMP errdisable notification traps.*
event-manager	(Optional) Enables SNMP Embedded Event Manager traps.
flash	(Optional) Enables SNMP FLASH notification traps.*

fru-ctrl	(Optional) Generates entity field-replaceable unit (FRU) control traps. In a device stack, this trap refers to the insertion or removal of a device in the stack.
license	(Optional) Enables license traps.*
mac-notification	(Optional) Enables SNMP MAC Notification traps.*
port-security	(Optional) Enables SNMP port security traps.*
power-ethernet	(Optional) Enables SNMP power Ethernet traps.*
rep	(Optional) Enables SNMP Resilient Ethernet Protocol traps.
snmp	(Optional) Enables SNMP traps.*
stackwise	(Optional) Enables SNMP stackwise traps.*
storm-control	(Optional) Enables SNMP storm-control trap parameters.*
stpx	(Optional) Enables SNMP STPX MIB traps.*
syslog	(Optional) Enables SNMP syslog traps.
transceiver	(Optional) Enables SNMP transceiver traps.*
tty	(Optional) Sends TCP connection traps. This is enabled by default.
vlan-membership	(Optional) Enables SNMP VLAN membership traps.
vlancreate	(Optional) Enables SNMP VLAN-created traps.
vlandelete	(Optional) Enables SNMP VLAN-deleted traps.
vstack	(Optional) Enables SNMP Smart Install traps.*
vtp	(Optional) Enables VLAN Trunking Protocol (VTP) traps.

Command Default

The sending of SNMP traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
	This command was introduced.

Usage Guidelines

The command options marked with an asterisk in the table above have subcommands. For more information on these subcommands, see the Related Commands section below.

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.

When supported, use the **snmp-server enable traps** command to enable sending of traps or informs.



Note Though visible in the command-line help strings, the **fru-ctrl**, **insertion**, and **removal** keywords are not supported on the device. The **snmp-server enable informs** global configuration command is not supported. To enable the sending of SNMP inform notifications, use the **snmp-server enable traps** global configuration command combined with the **snmp-server host *host-addr* informs** global configuration command.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to enable more than one type of SNMP trap:

```
Device(config)# snmp-server enable traps cluster
Device(config)# snmp-server enable traps config
Device(config)# snmp-server enable traps vtp
```

Related Topics

- [snmp-server enable traps bridge](#), on page 771
- [snmp-server enable traps bulkstat](#), on page 772
- [snmp-server enable traps call-home](#), on page 773
- [snmp-server enable traps cef](#), on page 774
- [snmp-server enable traps cpu](#), on page 775
- [snmp-server enable traps envmon](#), on page 776
- [snmp-server enable traps errdisable](#), on page 777
- [snmp-server enable traps flash](#), on page 778
- [snmp-server enable traps isis](#), on page 779
- [snmp-server enable traps license](#), on page 780
- [snmp-server enable traps mac-notification](#), on page 781
- [snmp-server enable traps ospf](#), on page 782
- [snmp-server enable traps pim](#), on page 783
- [snmp-server enable traps port-security](#), on page 784
- [snmp-server enable traps power-ethernet](#), on page 785
- [snmp-server enable traps snmp](#), on page 786
- [snmp-server enable traps stackwise](#), on page 787
- [snmp-server enable traps storm-control](#), on page 789
- [snmp-server enable traps stpx](#), on page 790
- [snmp-server enable traps transceiver](#), on page 791
- [snmp-server enable traps vrfmib](#), on page 792
- [snmp-server enable traps vstack](#), on page 793
- [snmp-server host](#), on page 795

snmp-server enable traps bridge

To generate STP bridge MIB traps, use the **snmp-server enable traps bridge** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps bridge [newroot] [topologychange]
no snmp-server enable traps bridge [newroot] [topologychange]
```

Syntax Description

newroot (Optional) Enables SNMP STP bridge MIB new root traps.

topologychange (Optional) Enables SNMP STP bridge MIB topology change traps.

Command Default

The sending of bridge SNMP traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to send bridge new root traps to the NMS:

```
Device(config)# snmp-server enable traps bridge newroot
```

snmp-server enable traps bulkstat

To enable data-collection-MIB traps, use the **snmp-server enable traps bulkstat** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps bulkstat [collection | transfer]
no snmp-server enable traps bulkstat [collection | transfer]
```

Syntax Description

collection (Optional) Enables data-collection-MIB collection traps.

transfer (Optional) Enables data-collection-MIB transfer traps.

Command Default

The sending of data-collection-MIB traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate data-collection-MIB collection traps:

```
Device(config)# snmp-server enable traps bulkstat collection
```

snmp-server enable traps call-home

To enable SNMP CISCO-CALLHOME-MIB traps, use the **snmp-server enable traps call-home** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps call-home [message-send-fail | server-fail]
no snmp-server enable traps call-home [message-send-fail | server-fail]
```

Syntax Description

message-send-fail (Optional) Enables SNMP message-send-fail traps.

server-fail (Optional) Enables SNMP server-fail traps.

Command Default

The sending of SNMP CISCO-CALLHOME-MIB traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP message-send-fail traps:

```
Device(config)# snmp-server enable traps call-home message-send-fail
```

snmp-server enable traps cef

To enable SNMP Cisco Express Forwarding (CEF) traps, use the **snmp-server enable traps cef** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps cef [inconsistency | peer-fib-state-change | peer-state-change |
resource-failure]
no snmp-server enable traps cef [inconsistency | peer-fib-state-change | peer-state-change |
resource-failure]
```

Syntax Description

inconsistency	(Optional) Enables SNMP CEF Inconsistency traps.
peer-fib-state-change	(Optional) Enables SNMP CEF Peer FIB State change traps.
peer-state-change	(Optional) Enables SNMP CEF Peer state change traps.
resource-failure	(Optional) Enables SNMP CEF Resource Failure traps.

Command Default

The sending of SNMP CEF traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Inform traps are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP CEF inconsistency traps:

```
Device(config)# snmp-server enable traps cef inconsistency
```

snmp-server enable traps cpu

To enable CPU notifications, use the **snmp-server enable traps cpu** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps cpu [threshold]
no snmp-server enable traps cpu [threshold]
```

Syntax Description	threshold (Optional) Enables CPU threshold notification.
---------------------------	---

Command Default	The sending of CPU notifications is disabled.
------------------------	---

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE

Usage Guidelines	Specify the host (NMS) that receives the traps by using the snmp-server host global configuration command. If no trap types are specified, all trap types are sent.
-------------------------	--



Note	Informs are not supported in SNMPv1.
-------------	--------------------------------------

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate CPU threshold notifications:

```
Device(config)# snmp-server enable traps cpu threshold
```

snmp-server enable traps envmon

To enable SNMP environmental traps, use the **snmp-server enable traps envmon** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps envmon [fan] [shutdown] [status] [supply] [temperature]
no snmp-server enable traps envmon [fan] [shutdown] [status] [supply] [temperature]
```

Syntax Description

fan	(Optional) Enables fan traps.
shutdown	(Optional) Enables environmental monitor shutdown traps.
status	(Optional) Enables SNMP environmental status-change traps.
supply	(Optional) Enables environmental monitor power-supply traps.
temperature	(Optional) Enables environmental monitor temperature traps.

Command Default

The sending of environmental SNMP traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Inform traps are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate fan traps:

```
Device(config)# snmp-server enable traps envmon fan
```

snmp-server enable traps errdisable

To enable SNMP notifications of error-disabling, use the **snmp-server enable traps errdisable** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps errdisable [**notification-rate** *number-of-notifications*]
no snmp-server enable traps errdisable [**notification-rate** *number-of-notifications*]

Syntax Description	notification-rate <i>number-of-notifications</i>	(Optional) Specifies number of notifications per minute as the notification rate. Accepted values are from 0 to 10000.
Command Default	The sending of SNMP notifications of error-disabling is disabled.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to set the number SNMP notifications of error-disabling to 2:

```
Device(config)# snmp-server enable traps errdisable notification-rate 2
```

snmp-server enable traps flash

To enable SNMP flash notifications, use the **snmp-server enable traps flash** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps flash [insertion] [removal]
no snmp-server enable traps flash [insertion] [removal]

Syntax Description

insertion (Optional) Enables SNMP flash insertion notifications.

removal (Optional) Enables SNMP flash removal notifications.

Command Default

The sending of SNMP flash notifications is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP flash insertion notifications:

```
Device(config)# snmp-server enable traps flash insertion
```

snmp-server enable traps isis

To enable intermediate system-to-intermediate system (IS-IS) link-state routing protocol traps, use the **snmp-server enable traps isis** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps isis [errors | state-change]
no snmp-server enable traps isis [errors | state-change]
```

Syntax Description

errors (Optional) Enables IS-IS error traps.

state-change (Optional) Enables IS-IS state change traps.

Command Default

The sending of IS-IS traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate IS-IS error traps:

```
Device(config)# snmp-server enable traps isis errors
```

snmp-server enable traps license

To enable license traps, use the **snmp-server enable traps license** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps license [deploy] [error] [usage]
no snmp-server enable traps license [deploy] [error] [usage]
```

Syntax Description

deploy (Optional) Enables license deployment traps.

error (Optional) Enables license error traps.

usage (Optional) Enables license usage traps.

Command Default

The sending of license traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Inform traps are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate license deployment traps:

```
Device(config)# snmp-server enable traps license deploy
```

snmp-server enable traps mac-notification

To enable SNMP MAC notification traps, use the **snmp-server enable traps mac-notification** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps mac-notification [change] [move] [threshold]
no snmp-server enable traps mac-notification [change] [move] [threshold]
```

Syntax Description

change (Optional) Enables SNMP MAC change traps.

move (Optional) Enables SNMP MAC move traps.

threshold (Optional) Enables SNMP MAC threshold traps.

Command Default

The sending of SNMP MAC notification traps is disabled.

Command Modes

Global configuration

Command History

Release

Modification

Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE

This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP MAC notification change traps:

```
Device(config)# snmp-server enable traps mac-notification change
```

snmp-server enable traps ospf

To enable SNMP Open Shortest Path First (OSPF) traps, use the **snmp-server enable traps ospf** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps ospf [cisco-specific | errors | lsa | rate-limit rate-limit-time
max-number-of-traps | retransmit | state-change]
no snmp-server enable traps ospf [cisco-specific | errors | lsa | rate-limit rate-limit-time
max-number-of-traps | retransmit | state-change]
```

Syntax Description

cisco-specific	(Optional) Enables Cisco-specific traps.
errors	(Optional) Enables error traps.
lsa	(Optional) Enables link-state advertisement (LSA) traps.
rate-limit	(Optional) Enables rate-limit traps.
<i>rate-limit-time</i>	(Optional) Specifies window of time in seconds for rate-limit traps. Accepted values are 2 to 60.
<i>max-number-of-traps</i>	(Optional) Specifies maximum number of rate-limit traps to be sent in window time.
retransmit	(Optional) Enables packet-retransmit traps.
state-change	(Optional) Enables state-change traps.

Command Default

The sending of OSPF SNMP traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to enable LSA traps:

```
Device(config)# snmp-server enable traps ospf lsa
```

snmp-server enable traps pim

To enable SNMP Protocol-Independent Multicast (PIM) traps, use the **snmp-server enable traps pim** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps pim [invalid-pim-message] [neighbor-change] [rp-mapping-change]
no snmp-server enable traps pim [invalid-pim-message] [neighbor-change] [rp-mapping-change]
```

Syntax Description

invalid-pim-message (Optional) Enables invalid PIM message traps.

neighbor-change (Optional) Enables PIM neighbor-change traps.

rp-mapping-change (Optional) Enables rendezvous point (RP)-mapping change traps.

Command Default

The sending of PIM SNMP traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to enable invalid PIM message traps:

```
Device(config)# snmp-server enable traps pim invalid-pim-message
```

snmp-server enable traps port-security

To enable SNMP port security traps, use the **snmp-server enable traps port-security** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps port-security [**trap-rate** *value*]
no snmp-server enable traps port-security [**trap-rate** *value*]

Syntax Description	trap-rate <i>value</i>	(Optional) Sets the maximum number of port-security traps sent per second. The range is from 0 to 1000; the default is 0 (no limit imposed; a trap is sent at every occurrence).
Command Default	The sending of port security SNMP traps is disabled.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	Specify the host (NMS) that receives the traps by using the snmp-server host global configuration command. If no trap types are specified, all trap types are sent.	



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to enable port-security traps at a rate of 200 per second:

```
Device(config)# snmp-server enable traps port-security trap-rate 200
```

snmp-server enable traps power-ethernet

To enable SNMP power-over-Ethernet (PoE) traps, use the **snmp-server enable traps power-ethernet** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps power-ethernet {group number | police}
no snmp-server enable traps power-ethernet {group number | police}
```

Syntax Description	group number	Enables inline power group-based traps for the specified group number. Accepted values are from 1 to 9.
	police	Enables inline power policing traps.

Command Default The sending of power-over-Ethernet SNMP traps is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to enable power-over-Ethernet traps for group 1:

```
Device(config)# snmp-server enable traps power-over-ethernet group 1
```

snmp-server enable traps snmp

To enable SNMP traps, use the **snmp-server enable traps snmp** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps snmp [authentication] [coldstart] [linkdown] [linkup] [warmstart]
no snmp-server enable traps snmp [authentication] [coldstart] [linkdown] [linkup]
[ warmstart]
```

Syntax Description

authentication (Optional) Enables authentication traps.

coldstart (Optional) Enables cold start traps.

linkdown (Optional) Enables linkdown traps.

linkup (Optional) Enables linkup traps.

warmstart (Optional) Enables warmstart traps.

Command Default

The sending of SNMP traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to enable a warmstart SNMP trap:

```
Device(config)# snmp-server enable traps snmp warmstart
```

snmp-server enable traps stackwise

To enable SNMP StackWise traps, use the **snmp-server enable traps stackwise** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps stackwise [GLS] [ILS] [SRLS]
[insufficient-power] [invalid-input-current]
[invalid-output-current] [member-removed] [member-upgrade-notification]
[new-master] [new-member] [port-change] [power-budget-warning] [power-invalid-topology]
[power-link-status-changed] [power-oper-status-changed]
[power-priority-conflict] [power-version-mismatch] [ring-redundant]
[stack-mismatch] [unbalanced-power-supplies] [under-budget] [under-voltage]
no snmp-server enable traps stackwise [GLS] [ILS] [SRLS]
[insufficient-power] [invalid-input-current]
[invalid-output-current] [member-removed] [member-upgrade-notification]
[new-master] [new-member] [port-change] [power-budget-warning] [power-invalid-topology]
[power-link-status-changed] [power-oper-status-changed]
[power-priority-conflict] [power-version-mismatch] [ring-redundant]
[stack-mismatch] [unbalanced-power-supplies] [under-budget] [under-voltage]
```

Syntax	Description
GLS	(Optional) Enables StackWise stack power GLS trap.
ILS	(Optional) Enables StackWise stack power ILS trap.
SRLS	(Optional) Enables StackWise stack power SRLS trap.
insufficient-power	(Optional) Enables StackWise stack power unbalanced power supplies trap.
invalid-input-current	(Optional) Enables StackWise stack power invalid input current trap.
invalid-output-current	(Optional) Enables StackWise stack power invalid output current trap.
member-removed	(Optional) Enables StackWise stack member removed trap.
member-upgrade-notification	(Optional) Enables StackWise member to be reloaded for upgrade trap.
new-master	(Optional) Enables StackWise new master trap.
new-member	(Optional) Enables StackWise stack new member trap.
port-change	(Optional) Enables StackWise stack port change trap.
power-budget-warning	(Optional) Enables StackWise stack power budget warning trap.
power-invalid-topology	(Optional) Enables StackWise stack power invalid topology trap.
power-link-status-changed	(Optional) Enables StackWise stack power link status changed trap.
power-oper-status-changed	(Optional) Enables StackWise stack power port oper status changed trap.
power-priority-conflict	(Optional) Enables StackWise stack power priority conflict trap.

power-version-mismatch	(Optional) Enables StackWise stack power version mismatch discovered trap.
ring-redundant	(Optional) Enables StackWise stack ring redundant trap.
stack-mismatch	(Optional) Enables StackWise stack mismatch trap.
unbalanced-power-supplies	(Optional) Enables StackWise stack power unbalanced power supplies trap.
under-budget	(Optional) Enables StackWise stack power under budget trap.
under-voltage	(Optional) Enables StackWise stack power under voltage trap.

Command Default The sending of SNMP StackWise traps is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate StackWise stack power GLS traps:

```
Device(config)# snmp-server enable traps stackwise GLS
```

snmp-server enable traps storm-control

To enable SNMP storm-control trap parameters, use the **snmp-server enable traps storm-control** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps storm-control {trap-rate number-of-minutes}
no snmp-server enable traps storm-control {trap-rate}
```

Syntax Description	trap-rate <i>number-of-minutes</i>	(Optional) Specifies the SNMP storm-control trap rate in minutes. Accepted values are from 0 to 1000.
Command Default	The sending of SNMP storm-control trap parameters is disabled.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to set the SNMP storm-control trap rate to 10 traps per minute:

```
Device(config)# snmp-server enable traps storm-control trap-rate 10
```

snmp-server enable traps stpx

To enable SNMP STPX MIB traps, use the **snmp-server enable traps stpx** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps stpx [**inconsistency**] [**loop-inconsistency**] [**root-inconsistency**]
no snmp-server enable traps stpx [**inconsistency**] [**loop-inconsistency**] [**root-inconsistency**]

Syntax Description

inconsistency (Optional) Enables SNMP STPX MIB inconsistency update traps.

loop-inconsistency (Optional) Enables SNMP STPX MIB loop inconsistency update traps.

root-inconsistency (Optional) Enables SNMP STPX MIB root inconsistency update traps.

Command Default

The sending of SNMP STPX MIB traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP STPX MIB inconsistency update traps:

```
Device(config)# snmp-server enable traps stpx inconsistency
```

snmp-server enable traps transceiver

To enable SNMP transceiver traps, use the **snmp-server enable traps transceiver** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps transceiver {all}
no snmp-server enable traps transceiver {all}
```

Syntax Description

a (Optional) Enables all SNMP transceiver traps.

Command Default

The sending of SNMP transceiver traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to set all SNMP transceiver traps:

```
Device(config)# snmp-server enable traps transceiver all
```

snmp-server enable traps vrfmib

To allow SNMP vrfmib traps, use the **snmp-server enable traps vrfmib** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps vrfmib [**vnet-trunk-down** | **vnet-trunk-up** | **vrf-down** | **vrf-up**]
no snmp-server enable traps vrfmib [**vnet-trunk-down** | **vnet-trunk-up** | **vrf-down** | **vrf-up**]

Syntax Description

vnet-trunk-down (Optional) Enables vrfmib trunk down traps.

vnet-trunk-up (Optional) Enables vrfmib trunk up traps.

vrf-down (Optional) Enables vrfmib vrf down traps.

vrf-up (Optional) Enables vrfmib vrf up traps.

Command Default

The sending of SNMP vrfmib traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate vrfmib trunk down traps:

```
Device(config)# snmp-server enable traps vrfmib vnet-trunk-down
```

snmp-server enable traps vstack

To enable SNMP smart install traps, use the **snmp-server enable traps vstack** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps vstack [addition] [failure] [lost] [operation]
no snmp-server enable traps vstack [addition] [failure] [lost] [operation]
```

Syntax Description

addition (Optional) Enables client added traps.

failure (Optional) Enables file upload and download failure traps.

lost (Optional) Enables client lost trap.

operation (Optional) Enables operation mode change traps.

Command Default

The sending of SNMP smart install traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP Smart Install client-added traps:

```
Device(config)# snmp-server enable traps vstack addition
```

snmp-server engineID

To configure a name for either the local or remote copy of SNMP, use the **snmp-server engineID** command in global configuration mode.

```
snmp-server engineID {local engineid-string | remote ip-address [udp-port port-number]
engineid-string}
```

Syntax Description

local <i>engineid-string</i>	Specifies a 24-character ID string with the name of the copy of SNMP. You need not specify the entire 24-character engine ID if it has trailing zeros. Specify only the portion of the engine ID up to the point where only zeros remain in the value.
remote <i>ip-address</i>	Specifies the remote SNMP copy. Specify the <i>ip-address</i> of the device that contains the remote copy of SNMP.
udp-port <i>port-number</i>	(Optional) Specifies the User Datagram Protocol (UDP) port on the remote device. The default is 162.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

None

Examples

The following example configures a local engine ID of 123400000000000000000000:

```
Device(config)# snmp-server engineID local 1234
```

snmp-server host

To specify the recipient (host) of a Simple Network Management Protocol (SNMP) notification operation, use the **snmp-server host** global configuration command on the device. Use the **no** form of this command to remove the specified host.

```
snmp-server host {host-addr} [vrf vrf-instance] [informs | traps] [version {1 | 2c | 3
{auth | noauth | priv} } ] {community-string [notification-type] }
no snmp-server host {host-addr} [vrf vrf-instance] [informs | traps] [version {1 | 2c |
3 {auth | noauth | priv} } ] {community-string [notification-type] }
```

Syntax Description

<i>host-addr</i>	Name or Internet address of the host (the targeted recipient).
vrf <i>vrf-instance</i>	(Optional) Specifies the virtual private network (VPN) routing instance and name for this host.
informs traps	(Optional) Sends SNMP traps or informs to this host.
version 1 2c 3	(Optional) Specifies the version of the SNMP used to send the traps. 1 —SNMPv1. This option is not available with informs. 2c —SNMPv2C. 3 —SNMPv3. One of the authorization keywords (see next table row) must follow the Version 3 keyword.
auth noauth priv	auth (Optional)—Enables Message Digest 5 (MD5) and Secure Hash Algorithm (SHA) packet authentication. noauth (Default)—The noAuthNoPriv security level. This is the default if the auth noauth priv keyword choice is not specified. priv (Optional)—Enables Data Encryption Standard (DES) packet encryption (also called privacy).
<i>community-string</i>	Password-like community string sent with the notification operation. Though you can set this string by using the snmp-server host command, we recommend that you define this string by using the snmp-server community global configuration command before using the snmp-server host command.
Note	The @ symbol is used for delimiting the context information. Avoid using the @ symbol as part of the SNMP community string when configuring this command.

notification-type (Optional) Type of notification to be sent to the host. If no type is specified, all notifications are sent. The notification type can be one or more of the these keywords:

- **auth-framework**—Sends SNMP CISCO-AUTH-FRAMEWORK-MIB traps.
- **bridge**—Sends SNMP Spanning Tree Protocol (STP) bridge MIB traps.
- **bulkstat**—Sends Data-Collection-MIB Collection notification traps.
- **call-home**—Sends SNMP CISCO-CALLHOME-MIB traps.
- **cef**—Sends SNMP CEF traps.
- **config**—Sends SNMP configuration traps.
- **config-copy**—Sends SNMP config-copy traps.
- **config-ctid**—Sends SNMP config-ctid traps.
- **copy-config**—Sends SNMP copy configuration traps.
- **cpu**—Sends CPU notification traps.
- **cpu threshold**—Sends CPU threshold notification traps.
- **entity**—Sends SNMP entity traps.

-
- **envmon**—Sends environmental monitor traps.
 - **errdisable**—Sends SNMP errdisable notification traps.
 - **event-manager**—Sends SNMP Embedded Event Manager traps.
 - **flash**—Sends SNMP FLASH notifications.
 - **flowmon**—Sends SNMP flowmon notification traps.
 - **ipmulticast**—Sends SNMP IP multicast routing traps.
 - **ipsla**—Sends SNMP IP SLA traps.
 - **license**—Sends license traps.
 - **local-auth**—Sends SNMP local auth traps.
 - **mac-notification**—Sends SNMP MAC notification traps.
 - **pim**—Sends SNMP Protocol-Independent Multicast (PIM) traps.
 - **power-ethernet**—Sends SNMP power Ethernet traps.
 - **snmp**—Sends SNMP-type traps.
 - **storm-control**—Sends SNMP storm-control traps.
 - **stpx**—Sends SNMP STP extended MIB traps.
 - **syslog**—Sends SNMP syslog traps.
 - **transceiver**—Sends SNMP transceiver traps.
 - **tty**—Sends TCP connection traps.
 - **vlan-membership**—Sends SNMP VLAN membership traps.
 - **vlancreate**—Sends SNMP VLAN-created traps.
 - **vlandelete**—Sends SNMP VLAN-deleted traps.
 - **vrfmib**—Sends SNMP vrfmib traps.
 - **vtp**—Sends SNMP VLAN Trunking Protocol (VTP) traps.
 - **wireless**—Sends wireless traps.
-

Command Default

This command is disabled by default. No notifications are sent.

If you enter this command with no keywords, the default is to send all trap types to the host. No informs are sent to this host.

If no **version** keyword is present, the default is Version 1.

If Version 3 is selected and no authentication keyword is entered, the default is the **noauth** (noAuthNoPriv) security level.



Note Though visible in the command-line help strings, the **fru-ctrl** keyword is not supported.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

SNMP notifications can be sent as traps or inform requests. Traps are unreliable because the receiver does not send acknowledgments when it receives traps. The sender cannot determine if the traps were received. However, an SNMP entity that receives an inform request acknowledges the message with an SNMP response PDU. If the sender never receives the response, the inform request can be sent again, so that informs are more likely to reach their intended destinations.

However, informs consume more resources in the agent and in the network. Unlike a trap, which is discarded as soon as it is sent, an inform request must be held in memory until a response is received or the request times out. Traps are also sent only once, but an inform might be retried several times. The retries increase traffic and contribute to a higher overhead on the network.

If you do not enter an **snmp-server host** command, no notifications are sent. To configure the device to send SNMP notifications, you must enter at least one **snmp-server host** command. If you enter the command with no keywords, all trap types are enabled for the host. To enable multiple hosts, you must enter a separate **snmp-server host** command for each host. You can specify multiple notification types in the command for each host.

If a local user is not associated with a remote host, the device does not send informs for the **auth** (authNoPriv) and the **priv** (authPriv) authentication levels.

When multiple **snmp-server host** commands are given for the same host and kind of notification (trap or inform), each succeeding command overwrites the previous command. Only the last **snmp-server host** command is in effect. For example, if you enter an **snmp-server host inform** command for a host and then enter another **snmp-server host inform** command for the same host, the second command replaces the first.

The **snmp-server host** command is used with the **snmp-server enable traps** global configuration command. Use the **snmp-server enable traps** command to specify which SNMP notifications are sent globally. For a host to receive most notifications, at least one **snmp-server enable traps** command and the **snmp-server host** command for that host must be enabled. Some notification types cannot be controlled with the **snmp-server enable traps** command. For example, some notification types are always enabled. Other notification types are enabled by a different command.

The **no snmp-server host** command with no keywords disables traps, but not informs, to the host. To disable informs, use the **no snmp-server host informs** command.

Examples

This example shows how to configure a unique SNMP community string named comaccess for traps and prevent SNMP polling access with this string through access-list 10:

```
Device(config)# snmp-server community comaccess ro 10
Device(config)# snmp-server host 172.20.2.160 comaccess
```

```
Device(config)# access-list 10 deny any
```

This example shows how to send the SNMP traps to the host specified by the name myhost.cisco.com. The community string is defined as comaccess:

```
Device(config)# snmp-server enable traps  
Device(config)# snmp-server host myhost.cisco.com comaccess snmp
```

This example shows how to enable the device to send all traps to the host myhost.cisco.com by using the community string public:

```
Device(config)# snmp-server enable traps  
Device(config)# snmp-server host myhost.cisco.com public
```

You can verify your settings by entering the **show running-config** privileged EXEC command.

Related Topics

[snmp-server enable traps](#)

switchport mode access

To sets the interface as a nontrunking nontagged single-VLAN Ethernet interface , use the **switchport mode access** command in template configuration mode. Use the **no** form of this command to return to the default setting.

```
switchport mode access
no switchport mode access
```

Syntax Description	switchport mode access Sets the interface as a nontrunking nontagged single-VLAN Ethernet interface.	
Command Default	An access port can carry traffic in one VLAN only. By default, an access port carries traffic for VLAN1.	
Command Modes	Template configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Examples

This example shows how to set a single-VLAN interface

```
Device(config-template)# switchport mode access
```

switchport voice vlan

To specify to forward all voice traffic through the specified VLAN, use the **switchport voice vlan** command in template configuration mode. Use the **no** form of this command to return to the default setting.

```
switchport voice vlan vlan_id
no switchport voice vlan
```

Syntax Description	switchport voice vlan <i>vlan_id</i> Specifies to forward all voice traffic through the specified VLAN.
---------------------------	--

Command Default	You can specify a value from 1 to 4094.
------------------------	---

Command Modes	Template configuration
----------------------	------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Examples This example shows how to specify to forward all voice traffic through the specified VLAN.

```
Device(config-template)# switchport voice vlan 20
```



PART **XI**

QoS

- [QoS Commands, on page 803](#)



QoS Commands

- [auto qos classify](#), on page 804
- [auto qos trust](#), on page 810
- [auto qos video](#), on page 817
- [auto qos voip](#), on page 827
- [debug auto qos](#), on page 840
- [show auto qos](#), on page 841
- [class](#), on page 843
- [class-map](#), on page 846
- [match \(class-map configuration\)](#), on page 848
- [match non-client-nrt](#), on page 851
- [match wlan user-priority](#), on page 852
- [policy-map](#), on page 853
- [priority](#), on page 856
- [queue-buffers ratio](#), on page 858
- [queue-limit](#), on page 859
- [qos wireless-default untrust](#), on page 861
- [service-policy \(Wired\)](#), on page 862
- [service-policy \(WLAN\)](#), on page 864
- [set](#), on page 865
- [show ap name service-policy](#), on page 872
- [show ap name dot11](#), on page 873
- [show class-map](#), on page 876
- [show platform hardware fed switch](#), on page 877
- [show platform software fed switch qos](#), on page 880
- [show platform software fed switch qos qsb](#), on page 881
- [show wireless client calls](#), on page 884
- [show wireless client dot11](#), on page 885
- [show wireless client mac-address \(Call Control\)](#), on page 886
- [show wireless client mac-address \(TCLAS\)](#), on page 887
- [show wireless client voice diagnostics](#), on page 888
- [show policy-map](#), on page 889
- [show wlan](#), on page 891
- [trust device](#), on page 894

auto qos classify

To automatically configure quality of service (QoS) classification for untrusted devices within a QoS domain, use the **auto qos classify** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

```
auto qos classify [police]
no auto qos classify [police]
```

Syntax Description	police (Optional) Configure QoS policing for untrusted devices.
---------------------------	--

Command Default	Auto-QoS classify is disabled on the port.
------------------------	--

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines	Use this command to configure the QoS for trusted interfaces within the QoS domain. The QoS domain includes the device, the network interior, and edge devices that can classify incoming traffic for QoS.
-------------------------	--

When auto-QoS is enabled, it uses the ingress packet label to categorize traffic, to assign packet labels, and to configure the ingress and egress queues.

Table 28: Auto-QoS Configuration for the Egress Queues

Egress Queue	Queue Number	CoS-to-Queue Map	Queue Weight (Bandwidth)	Queue (Buffer) Size for Gigabit-Capable Ports	Queue (Buffer) Size for 10/100 Ethernet Ports
Priority (shaped)	1	4, 5	up to 100 percent	25 percent	15 percent
SRR shared	2	2, 3, 6,7	10 percent	25 percent	25 percent
SRR shared	3	0	60 percent	25 percent	40 percent
SRR shared	4	1	20 percent	25 percent	20 percent

Auto-QoS configures the device for connectivity with a trusted interface. The QoS labels of incoming packets are trusted. For nonrouted ports, the CoS value of the incoming packets is trusted. For routed ports, the DSCP value of the incoming packet is trusted.

To take advantage of the auto-QoS defaults, you should enable auto-QoS before you configure other QoS commands. You can fine-tune the auto-QoS configuration *after* you enable auto-QoS.



Note The device applies the auto-QoS-generated commands as if the commands were entered from the command-line interface (CLI). An existing user configuration can cause the application of the generated commands to fail or to be overridden by the generated commands. These actions occur without warning. If all the generated commands are successfully applied, any user-entered configuration that was not overridden remains in the running configuration. Any user-entered configuration that was overridden can be retrieved by reloading the device without saving the current configuration to memory. If the generated commands fail to be applied, the previous running configuration is restored.

After auto-QoS is enabled, do not modify a policy map or aggregate policer that includes *AutoQoS* in its name. If you need to modify the policy map or aggregate policer, make a copy of it, and change the copied policy map or policer. To use the new policy map instead of the generated one, remove the generated policy map from the interface, and apply the new policy map.

To display the QoS configuration that is automatically generated when auto-QoS is enabled, enable debugging before you enable auto-QoS. Use the **debug auto qos** privileged EXEC command to enable auto-QoS debugging.

The following policy maps and class maps are created and applied when running the **auto qos classify** and **auto qos classify police** commands:

Policy maps (For the **auto qos classify police** command):

- AutoQos-4.0-Classify-Police-Input-Policy
- AutoQos-4.0-Output-Policy

Class maps:

- AutoQos-4.0-Multimedia-Conf-Class (match-any)
- AutoQos-4.0-Bulk-Data-Class (match-any)
- AutoQos-4.0-Transaction-Class (match-any)
- AutoQos-4.0-Scavenger-Class (match-any)
- AutoQos-4.0-Signaling-Class (match-any)
- AutoQos-4.0-Default-Class (match-any)
- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

To disable auto-QoS on a port, use the **no auto qos classify** interface configuration command. Only the auto-QoS-generated interface configuration commands for this port are removed. If this is the last port on which auto-QoS is enabled and you enter the **no auto qos classify** command, auto-QoS is considered disabled even though the auto-QoS-generated global configuration commands remain (to avoid disrupting traffic on other ports affected by the global configuration).

Examples

This example shows how to enable auto-QoS classification of an untrusted device and police traffic:

```
Device(config)# interface gigabitEthernet1/0/6
Device(config-if)# auto qos classify police
Device(config-if)# end
Device# show policy-map interface gigabitEthernet1/0/6
GigabitEthernet1/0/6

Service-policy input: AutoQos-4.0-Classify-Police-Input-Policy

Class-map: AutoQos-4.0-Multimedia-Conf-Class (match-any)
  0 packets
Match: access-group name AutoQos-4.0-Acl-MultiEnhanced-Conf
  0 packets, 0 bytes
  5 minute rate 0 bps
QoS Set
  dscp af41
police:
  cir 5000000 bps, bc 156250 bytes
  conformed 0 bytes; actions:
    transmit
  exceeded 0 bytes; actions:
    drop
  conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Bulk-Data-Class (match-any)
  0 packets
Match: access-group name AutoQos-4.0-Acl-Bulk-Data
  0 packets, 0 bytes
  5 minute rate 0 bps
QoS Set
  dscp af11
police:
  cir 10000000 bps, bc 312500 bytes
  conformed 0 bytes; actions:
    transmit
  exceeded 0 bytes; actions:
    set-dscp-transmit dscp table policed-dscp
  conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Transaction-Class (match-any)
  0 packets
Match: access-group name AutoQos-4.0-Acl-Transactional-Data
  0 packets, 0 bytes
  5 minute rate 0 bps
QoS Set
  dscp af21
police:
  cir 10000000 bps, bc 312500 bytes
  conformed 0 bytes; actions:
    transmit
  exceeded 0 bytes; actions:
    set-dscp-transmit dscp table policed-dscp
  conformed 0000 bps, exceed 0000 bps
```

```

Class-map: AutoQos-4.0-Scavenger-Class (match-any)
  0 packets
  Match: access-group name AutoQos-4.0-Acl-Scavenger
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp cs1
  police:
    cir 10000000 bps, bc 312500 bytes
    conformed 0 bytes; actions:
      transmit
    exceeded 0 bytes; actions:
      drop
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Signaling-Class (match-any)
  0 packets
  Match: access-group name AutoQos-4.0-Acl-Signaling
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp cs3
  police:
    cir 32000 bps, bc 8000 bytes
    conformed 0 bytes; actions:
      transmit
    exceeded 0 bytes; actions:
      drop
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Default-Class (match-any)
  0 packets
  Match: access-group name AutoQos-4.0-Acl-Default
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp default
  police:
    cir 10000000 bps, bc 312500 bytes
    conformed 0 bytes; actions:
      transmit
    exceeded 0 bytes; actions:
      set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0
  (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes

```

```

    5 minute rate 0 bps
Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
Priority: 30% (300000 kbps), burst bytes 7500000,

Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
0 packets
Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
Queueing
queue-limit dscp 16 percent 80
queue-limit dscp 24 percent 90
queue-limit dscp 48 percent 100
queue-limit dscp 56 percent 100

(total drops) 0
(bytes output) 0
bandwidth remaining 10%

queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
0 packets
Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
Match: cos 4
    0 packets, 0 bytes
    5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
0 packets
Match: dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
Match: cos 2
    0 packets, 0 bytes
    5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
Match: cos 1

```

```
    0 packets, 0 bytes
    5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
  0 packets
  Match: dscp cs1 (8)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 1%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
  0 packets
  Match: dscp af31 (26) af32 (28) af33 (30)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 25%
  queue-buffers ratio 25
```

You can verify your settings by entering the **show auto qos interface *interface-id*** privileged EXEC command.

auto qos trust

To automatically configure quality of service (QoS) for trusted interfaces within a QoS domain, use the **auto qos trust** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

```
auto qos trust {cos | dscp}
no auto qos trust {cos | dscp}
```

Syntax Description

cos Trusts the CoS packet classification.

dscp Trusts the DSCP packet classification.

Command Default

Auto-QoS trust is disabled on the port.

Command Modes

Interface configuration

Command History

Release

Modification

Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

Use this command to configure the QoS for trusted interfaces within the QoS domain. The QoS domain includes the device, the network interior, and edge devices that can classify incoming traffic for QoS. When auto-QoS is enabled, it uses the ingress packet label to categorize traffic, to assign packet labels, and to configure the ingress and egress queues.

Table 29: Traffic Types, Packet Labels, and Queues

	VOIP Data Traffic	VOIP Control Traffic	Routing Protocol Traffic	STP ⁵ BPDU ⁶ Traffic	Real-Time Video Traffic	All Other Traffic	
DSCP ⁷	46	24, 26	48	56	34	–	
CoS ⁸	5	3	6	7	3	–	
CoS-to-egress queue map	4, 5 (queue 1)	2, 3, 6, 7 (queue 2)			0 (queue 3)	2 (queue 3)	0, 1 (queue 4)

⁵ STP = Spanning Tree Protocol

⁶ BPDU = bridge protocol data unit

⁷ DSCP = Differentiated Services Code Point

⁸ CoS = class of service

Table 30: Auto-QoS Configuration for the Egress Queues

Egress Queue	Queue Number	CoS-to-Queue Map	Queue Weight (Bandwidth)	Queue (Buffer) Size for Gigabit-Capable Ports	Queue (Buffer) Size for 10/100 Ethernet Ports
Priority (shaped)	1	4, 5	Up to 100 percent	25 percent	15 percent
SRR shared	2	2, 3, 6,7	10 percent	25 percent	25 percent
SRR shared	3	0	60 percent	25 percent	40 percent
SRR shared	4	1	20 percent	25 percent	20 percent



Note The device applies the auto-QoS-generated commands as if the commands were entered from the command-line interface (CLI). An existing user configuration can cause the application of the generated commands to fail or to be overridden by the generated commands. These actions occur without warning. If all the generated commands are successfully applied, any user-entered configuration that was not overridden remains in the running configuration. Any user-entered configuration that was overridden can be retrieved by reloading the device without saving the current configuration to memory. If the generated commands fail to be applied, the previous running configuration is restored.

After auto-QoS is enabled, do not modify a policy map or aggregate policer that includes *AutoQoS* in its name. If you need to modify the policy map or aggregate policer, make a copy of it, and change the copied policy map or policer. To use the new policy map instead of the generated one, remove the generated policy map from the interface, and apply the new policy map.

To display the QoS configuration that is automatically generated when auto-QoS is enabled, enable debugging before you enable auto-QoS. Use the **debug auto qos** privileged EXEC command to enable auto-QoS debugging.

The following policy maps and class maps are created and applied when running the **auto qos trust cos** command:

Policy maps:

- AutoQos-4.0-Trust-Cos-Input-Policy
- AutoQos-4.0-Output-Policy

Class maps:

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

The following policy maps and class maps are created and applied when running the **auto qos trust dscp** command:

Policy maps:

- AutoQos-4.0-Trust-Dscp-Input-Policy
- AutoQos-4.0-Output-Policy

Class maps:

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

To disable auto-QoS on a port, use the **no auto qos trust** interface configuration command. Only the auto-QoS-generated interface configuration commands for this port are removed. If this is the last port on which auto-QoS is enabled and you enter the **no auto qos trust** command, auto-QoS is considered disabled even though the auto-QoS-generated global configuration commands remain (to avoid disrupting traffic on other ports affected by the global configuration).

Examples

This example shows how to enable auto-QoS for a trusted interface with specific CoS classification.

```
Device(config)# interface gigabitEthernet1/0/17
Device(config-if)# auto qos trust cos
Device(config-if)# end
Device# show policy-map interface GigabitEthernet1/0/17
GigabitEthernet1/0/7

Service-policy input: AutoQos-4.0-Trust-Cos-Input-Policy

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    cos cos table AutoQos-4.0-Trust-Cos-Table

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0
  (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 5
```

```
    0 packets, 0 bytes
    5 minute rate 0 bps
Priority: 30% (300000 kbps), burst bytes 7500000,

Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
    queue-limit dscp 16 percent 80
    queue-limit dscp 24 percent 90
    queue-limit dscp 48 percent 100
    queue-limit dscp 56 percent 100

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%

  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
  0 packets
  Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 4
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
  0 packets
  Match: dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 2
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
  0 packets
  Match: dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 1
    0 packets, 0 bytes
    5 minute rate 0 bps
```

```

Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
  0 packets, 0 bytes
  5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25

```

This example shows how to enable auto-QoS for a trusted interface with specific DSCP classification.

```

Device(config)# interface GigabitEthernet1/0/18
Device(config-if)# auto qos trust dscp
Device(config-if)# end
Device#show policy-map interface GigabitEthernet1/0/18
GigabitEthernet1/0/18

Service-policy input: AutoQos-4.0-Trust-Dscp-Input-Policy

Class-map: class-default (match-any)
 0 packets
Match: any
  0 packets, 0 bytes
  5 minute rate 0 bps
QoS Set
  dscp dscp table AutoQos-4.0-Trust-Dscp-Table

Service-policy output: AutoQos-4.0-Output-Policy

```

```
queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0
  (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
  Priority: 30% (300000 kbps), burst bytes 7500000,

  Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
  queue-limit dscp 16 percent 80
  queue-limit dscp 24 percent 90
  queue-limit dscp 48 percent 100
  queue-limit dscp 56 percent 100

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%

  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
  0 packets
  Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 4
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
  0 packets
  Match: dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 2
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
```

```

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
 0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 1
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25

```

You can verify your settings by entering the **show auto qos interface *interface-id*** privileged EXEC command.

auto qos video

To automatically configure quality of service (QoS) for video within a QoS domain, use the **auto qos video** command in interface configuration mode. Use the **no** form of this command to return to the default setting.

```
auto qos video {cts | ip-camera | media-player}
no auto qos video {cts | ip-camera | media-player}
```

Syntax Description

cts	Specifies a port connected to a Cisco TelePresence System and automatically configures QoS for video.
ip-camera	Specifies a port connected to a Cisco IP camera and automatically configures QoS for video.
media-player	Specifies a port connected to a CDP-capable Cisco digital media player and automatically configures QoS for video.

Command Default

Auto-QoS video is disabled on the port.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

Use this command to configure the QoS appropriate for video traffic within the QoS domain. The QoS domain includes the device, the network interior, and edge devices that can classify incoming traffic for QoS. When auto-QoS is enabled, it uses the ingress packet label to categorize traffic, to assign packet labels, and to configure the ingress and egress queues. For more information, see the queue tables at the end of this section.

Auto-QoS configures the device for video connectivity to a Cisco TelePresence system, a Cisco IP camera, or a Cisco digital media player.

To take advantage of the auto-QoS defaults, you should enable auto-QoS before you configure other QoS commands. You can fine-tune the auto-QoS configuration *after* you enable auto-QoS.

The device applies the auto-QoS-generated commands as if the commands were entered from the command-line interface (CLI). An existing user configuration can cause the application of the generated commands to fail or to be overridden by the generated commands. These actions occur without warning. If all the generated commands are successfully applied, any user-entered configuration that was not overridden remains in the running configuration. Any user-entered configuration that was overridden can be retrieved by reloading the device without saving the current configuration to memory. If the generated commands fail to be applied, the previous running configuration is restored.

If this is the first port on which you have enabled auto-QoS, the auto-QoS-generated global configuration commands are executed followed by the interface configuration commands. If you enable auto-QoS on another port, only the auto-QoS-generated interface configuration commands for that port are executed.

After auto-QoS is enabled, do not modify a policy map or aggregate policer that includes *AutoQoS* in its name. If you need to modify the policy map or aggregate policer, make a copy of it, and change the copied policy map or policer. To use the new policy map instead of the generated one, remove the generated policy map from the interface, and apply the new policy map.

To display the QoS configuration that is automatically generated when auto-QoS is enabled, enable debugging before you enable auto-QoS. Use the **debug auto qos** privileged EXEC command to enable auto-QoS debugging.

The following policy maps and class maps are created and applied when running the **auto qos video cts** command:

Policy maps:

- AutoQos-4.0-Trust-Cos-Input-Policy
- AutoQos-4.0-Output-Policy

Class maps

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

The following policy maps and class maps are created and applied when running the **auto qos video ip-camera** command:

Policy maps:

- AutoQos-4.0-Trust-Dscp-Input-Policy
- AutoQos-4.0-Output-Policy

Class maps:

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

The following policy maps and class maps are created and applied when running the **auto qos video media-player** command:

Policy maps:

- AutoQos-4.0-Trust-Dscp-Input-Policy
- AutoQos-4.0-Output-Policy

Class maps:

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

To disable auto-QoS on a port, use the **no auto qos video** interface configuration command. Only the auto-QoS-generated interface configuration commands for this port are removed. If this is the last port on which auto-QoS is enabled, and you enter the **no auto qos video** command, auto-QoS is considered disabled even though the auto-QoS-generated global configuration commands remain (to avoid disrupting traffic on other ports affected by the global configuration).

Table 31: Traffic Types, Packet Labels, and Queues

	VOIP Data Traffic	VOIP Control Traffic	Routing Protocol Traffic	STP ⁹ BPDU ¹⁰ Traffic	Real-Time Video Traffic	All Other Traffic	
DSCP ¹¹	46	24, 26	48	56	34	–	
CoS ¹²	5	3	6	7	3	–	
CoS-to-egress queue map	4, 5 (queue 1)	2, 3, 6, 7 (queue 2)	2, 3, 6, 7 (queue 2)	2, 3, 6, 7 (queue 2)	0 (queue 3)	2 (queue 3)	0, 1 (queue 4)

⁹ STP = Spanning Tree Protocol

¹⁰ BPDU = bridge protocol data unit

¹¹ DSCP = Differentiated Services Code Point

¹² CoS = class of service

Table 32: Auto-QoS Configuration for the Egress Queues

Egress Queue	Queue Number	CoS-to-Queue Map	Queue Weight (Bandwidth)	Queue (Buffer) Size for Gigabit-Capable Ports	Queue (Buffer) Size for 10/100 Ethernet Ports
Priority (shaped)	1	4, 5	up to 100 percent	25 percent	15 percent

Egress Queue	Queue Number	CoS-to-Queue Map	Queue Weight (Bandwidth)	Queue (Buffer) Size for Gigabit-Capable Ports	Queue (Buffer) Size for 10/100 Ethernet Ports
SRR shared	2	2, 3, 6, 7	10 percent	25 percent	25 percent
SRR shared	3	0	60 percent	25 percent	40 percent
SRR shared	4	1	20 percent	25 percent	20 percent

Examples

The following is an example of the **auto qos video cts** command and the applied policies and class maps:

```

Device(config)# interface gigabitEthernet1/0/12
Device(config-if)# auto qos video cts
Device(config-if)# end
Device# show policy-map interface gigabitEthernet1/0/12
GigabitEthernet1/0/12

  Service-policy input: AutoQos-4.0-Trust-Cos-Input-Policy

    Class-map: class-default (match-any)
      0 packets
      Match: any
        0 packets, 0 bytes
        5 minute rate 0 bps
      QoS Set
        cos cos table AutoQos-4.0-Trust-Cos-Table

  Service-policy output: AutoQos-4.0-Output-Policy

    queue stats for all priority classes:
      Queueing
        priority level 1

        (total drops) 0
        (bytes output) 0

    Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
      0 packets
      Match: dscp cs4 (32) cs5 (40) ef (46)
        0 packets, 0 bytes
        5 minute rate 0 bps
      Match: cos 5
        0 packets, 0 bytes
        5 minute rate 0 bps
      Priority: 30% (300000 kbps), burst bytes 7500000,
      Priority Level: 1

    Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
      0 packets
      Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
        0 packets, 0 bytes
        5 minute rate 0 bps
      Match: cos 3
        0 packets, 0 bytes
        5 minute rate 0 bps
      Queueing
        queue-limit dscp 16 percent 80

```

```
queue-limit dscp 24 percent 90
queue-limit dscp 48 percent 100
queue-limit dscp 56 percent 100

(total drops) 0
(bytes output) 0
bandwidth remaining 10%

queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
 0 packets
Match: dscp af41 (34) af42 (36) af43 (38)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 4
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
 0 packets
Match: dscp af21 (18) af22 (20) af23 (22)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 2
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
 0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 1
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
```

```

bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25

```

The following is an example of the **auto qos video ip-camera** command and the applied policies and class maps:

```

Device(config)# interface GigabitEthernet1/0/9
Device(config-if)# auto qos video ip-camera
Device(config-if)# end
Device# show policy-map interface GigabitEthernet1/0/9
GigabitEthernet1/0/9

Service-policy input: AutoQos-4.0-Trust-Dscp-Input-Policy

Class-map: class-default (match-any)
 0 packets
Match: any
 0 packets, 0 bytes
 5 minute rate 0 bps
QoS Set
 dscp dscp table AutoQos-4.0-Trust-Dscp-Table

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
Queueing
priority level 1

(total drops) 0
(bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
 0 packets
Match: dscp cs4 (32) cs5 (40) ef (46)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 5
 0 packets, 0 bytes

```

```
    5 minute rate 0 bps
Priority: 30% (300000 kbps), burst bytes 7500000,

Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
  queue-limit dscp 16 percent 80
  queue-limit dscp 24 percent 90
  queue-limit dscp 48 percent 100
  queue-limit dscp 56 percent 100

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%

  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
  0 packets
  Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 4
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
  0 packets
  Match: dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 2
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
  0 packets
  Match: dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 1
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
```

```

    (total drops) 0
    (bytes output) 0
    bandwidth remaining 4%
    queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
  0 packets
  Match: dscp cs1 (8)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

    (total drops) 0
    (bytes output) 0
    bandwidth remaining 1%
    queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
  0 packets
  Match: dscp af31 (26) af32 (28) af33 (30)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

    (total drops) 0
    (bytes output) 0
    bandwidth remaining 10%
    queue-buffers ratio 10

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

    (total drops) 0
    (bytes output) 0
    bandwidth remaining 25%
    queue-buffers ratio 25

```

The following is an example of the **auto qos video media-player** command and the applied policies and class maps.

```

Device(config)# interface GigabitEthernet1/0/7
Device(config-if)# auto qos video media-player
Device(config-if)# end
Device# show policy-map interface GigabitEthernet1/0/7
GigabitEthernet1/0/25

Service-policy input: AutoQos-4.0-Trust-Dscp-Input-Policy

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp dscp table AutoQos-4.0-Trust-Dscp-Table

```

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:

Queueing
priority level 1

(total drops) 0
(bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
0 packets

Match: dscp cs4 (32) cs5 (40) ef (46)
0 packets, 0 bytes
5 minute rate 0 bps

Match: cos 5
0 packets, 0 bytes
5 minute rate 0 bps

Priority: 30% (300000 kbps), burst bytes 7500000,

Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
0 packets

Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
0 packets, 0 bytes
5 minute rate 0 bps

Match: cos 3
0 packets, 0 bytes
5 minute rate 0 bps

Queueing
queue-limit dscp 16 percent 80
queue-limit dscp 24 percent 90
queue-limit dscp 48 percent 100
queue-limit dscp 56 percent 100

(total drops) 0
(bytes output) 0
bandwidth remaining 10%

queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
0 packets

Match: dscp af41 (34) af42 (36) af43 (38)
0 packets, 0 bytes
5 minute rate 0 bps

Match: cos 4
0 packets, 0 bytes
5 minute rate 0 bps

Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
0 packets

Match: dscp af21 (18) af22 (20) af23 (22)
0 packets, 0 bytes
5 minute rate 0 bps

Match: cos 2
0 packets, 0 bytes
5 minute rate 0 bps

```

Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
 0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 1
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25

```

You can verify your settings by entering the **show auto qos video interface *interface-id*** privileged EXEC command.

auto qos voip

To automatically configure quality of service (QoS) for voice over IP (VoIP) within a QoS domain, use the **auto qos voip** command in interface configuration mode. Use the **no** form of this command to return to the default setting.

```
auto qos voip {cisco-phone | cisco-softphone | trust}
no auto qos voip {cisco-phone | cisco-softphone | trust}
```

Syntax Description	
cisco-phone	Specifies a port connected to a Cisco IP phone, and automatically configures QoS for VoIP. The QoS labels of incoming packets are trusted only when the telephone is detected.
cisco-softphone	Specifies a port connected to a device running the Cisco SoftPhone, and automatically configures QoS for VoIP.
trust	Specifies a port connected to a trusted device, and automatically configures QoS for VoIP. The QoS labels of incoming packets are trusted. For nonrouted ports, the CoS value of the incoming packet is trusted. For routed ports, the DSCP value of the incoming packet is trusted.

Command Default Auto-QoS is disabled on the port.

When auto-QoS is enabled, it uses the ingress packet label to categorize traffic, to assign packet labels, and to configure the ingress and egress queues.

Command Default Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines Use this command to configure the QoS appropriate for VoIP traffic within the QoS domain. The QoS domain includes the device, the network interior, and edge devices that can classify incoming traffic for QoS.

Auto-QoS configures the device for VoIP with Cisco IP phones on device and routed ports and for devices running the Cisco SoftPhone application. These releases support only Cisco IP SoftPhone Version 1.3(3) or later. Connected devices must use Cisco Call Manager Version 4 or later.

To take advantage of the auto-QoS defaults, you should enable auto-QoS before you configure other QoS commands. You can fine-tune the auto-QoS configuration *after* you enable auto-QoS.



Note The device applies the auto-QoS-generated commands as if the commands were entered from the command-line interface (CLI). An existing user configuration can cause the application of the generated commands to fail or to be overridden by the generated commands. These actions occur without warning. If all the generated commands are successfully applied, any user-entered configuration that was not overridden remains in the running configuration. Any user-entered configuration that was overridden can be retrieved by reloading the device without saving the current configuration to memory. If the generated commands fail to be applied, the previous running configuration is restored.

If this is the first port on which you have enabled auto-QoS, the auto-QoS-generated global configuration commands are executed followed by the interface configuration commands. If you enable auto-QoS on another port, only the auto-QoS-generated interface configuration commands for that port are executed.

When you enter the **auto qos voip cisco-phone** interface configuration command on a port at the edge of the network that is connected to a Cisco IP phone, the device enables the trusted boundary feature. The device uses the Cisco Discovery Protocol (CDP) to detect the presence of a Cisco IP phone. When a Cisco IP phone is detected, the ingress classification on the port is set to trust the QoS label received in the packet. The device also uses policing to determine whether a packet is in or out of profile and to specify the action on the packet. If the packet does not have a DSCP value of 24, 26, or 46 or is out of profile, the device changes the DSCP value to 0. When a Cisco IP phone is absent, the ingress classification is set to not trust the QoS label in the packet. The policing is applied to those traffic matching the policy-map classification before the device enables the trust boundary feature.

-
- When you enter the **auto qos voip cisco-softphone** interface configuration command on a port at the edge of the network that is connected to a device running the Cisco SoftPhone, the device uses policing to decide whether a packet is in or out of profile and to specify the action on the packet. If the packet does not have a DSCP value of 24, 26, or 46 or is out of profile, the device changes the DSCP value to 0.
- When you enter the **auto qos voip trust** interface configuration command on a port connected to the network interior, the device trusts the CoS value for nonrouted ports or the DSCP value for routed ports in ingress packets (the assumption is that traffic has already been classified by other edge devices).

You can enable auto-QoS on static, dynamic-access, and voice VLAN access, and trunk ports. When enabling auto-QoS with a Cisco IP phone on a routed port, you must assign a static IP address to the IP phone.



Note

When a device running Cisco SoftPhone is connected to a device or routed port, the device supports only one Cisco SoftPhone application per port.

After auto-QoS is enabled, do not modify a policy map or aggregate policer that includes *AutoQoS* in its name. If you need to modify the policy map or aggregate policer, make a copy of it, and change the copied policy map or policer. To use the new policy map instead of the generated one, remove the generated policy map from the interface, and apply the new policy map.

To display the QoS configuration that is automatically generated when auto-QoS is enabled, enable debugging before you enable auto-QoS. Use the **debug auto qos** privileged EXEC command to enable auto-QoS debugging.

The following policy maps and class maps are created and applied when running the **auto qos voip trust** command:

Policy maps:

- AutoQos-4.0-Trust-Cos-Input-Policy
- AutoQos-4.0-Output-Policy

Class maps:

- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)

- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

The following policy maps and class maps are created and applied when running the **auto qos voip cisco-softphone** command:

Policy maps:

- AutoQos-4.0-CiscoSoftPhone-Input-Policy
- AutoQos-4.0-Output-Policy

Class maps:

- AutoQos-4.0-Voip-Data-Class (match-any)
- AutoQos-4.0-Voip-Signal-Class (match-any)
- AutoQos-4.0-Multimedia-Conf-Class (match-any)
- AutoQos-4.0-Bulk-Data-Class (match-any)
- AutoQos-4.0-Transaction-Class (match-any)
- AutoQos-4.0-Scavenger-Class (match-any)
- AutoQos-4.0-Signaling-Class (match-any)
- AutoQos-4.0-Default-Class (match-any)
- class-default (match-any)
- AutoQos-4.0-Output-Priority-Queue (match-any)
- AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
- AutoQos-4.0-Output-Trans-Data-Queue (match-any)
- AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
- AutoQos-4.0-Output-Scavenger-Queue (match-any)
- AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)

The following policy maps and class maps are created and applied when running the **auto qos voip cisco-phone** command:

Policy maps:

- service-policy input AutoQos-4.0-CiscoPhone-Input-Policy

- service-policy output AutoQos-4.0-Output-Policy

Class maps:

- class AutoQos-4.0-Voip-Data-CiscoPhone-Class
- class AutoQos-4.0-Voip-Signal-CiscoPhone-Class
- class AutoQos-4.0-Default-Class

To disable auto-QoS on a port, use the **no auto qos voip** interface configuration command. Only the auto-QoS-generated interface configuration commands for this port are removed. If this is the last port on which auto-QoS is enabled and you enter the **no auto qos voip** command, auto-QoS is considered disabled even though the auto-QoS-generated global configuration commands remain (to avoid disrupting traffic on other ports affected by the global configuration).

The device configures egress queues on the port according to the settings in this table.

Table 33: Auto-QoS Configuration for the Egress Queues

Egress Queue	Queue Number	CoS-to-Queue Map	Queue Weight (Bandwidth)	Queue (Buffer) Size for Gigabit-Capable Ports	Queue (Buffer) Size for 10/100 Ethernet Ports
Priority (shaped)	1	4, 5	Up to 100 percent	25 percent	15 percent
SRR shared	2	2, 3, 6, 7	10 percent	25 percent	25 percent
SRR shared	3	0	60 percent	25 percent	40 percent
SRR shared	4	1	20 percent	25 percent	20 percent

Examples

The following is an example of the **auto qos voip trust** command and the applied policies and class maps:

```
Device(config)# interface gigabitEthernet1/0/31
Device(config-if)# auto qos voip trust
Device(config-if)# end
Device# show policy-map interface GigabitEthernet1/0/31
GigabitEthernet1/0/31

  Service-policy input: AutoQos-4.0-Trust-Cos-Input-Policy

    Class-map: class-default (match-any)
      0 packets
      Match: any
        0 packets, 0 bytes
        5 minute rate 0 bps
      QoS Set
        cos cos table AutoQos-4.0-Trust-Cos-Table

  Service-policy output: AutoQos-4.0-Output-Policy

    queue stats for all priority classes:
      Queueing
      priority level 1
```

```
(total drops) 0
(bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
 0 packets
Match: dscp cs4 (32) cs5 (40) ef (46)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 5
 0 packets, 0 bytes
 5 minute rate 0 bps
Priority: 30% (300000 kbps), burst bytes 7500000,

Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
 0 packets
Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 3
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing
queue-limit dscp 16 percent 80
queue-limit dscp 24 percent 90
queue-limit dscp 48 percent 100
queue-limit dscp 56 percent 100

(total drops) 0
(bytes output) 0
bandwidth remaining 10%

queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
 0 packets
Match: dscp af41 (34) af42 (36) af43 (38)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 4
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
 0 packets
Match: dscp af21 (18) af22 (20) af23 (22)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 2
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
```

```

queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
 0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 1
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25

```

The following is an example of the **auto qos voip cisco-phone** command and the applied policies and class maps:

```

Device(config)# interface gigabitEthernet1/0/5
Device(config-if)# auto qos voip cisco-phone
Device(config-if)# end
Device# show policy-map interface gigabitEthernet1/0/5
GigabitEthernet1/0/5

```

Service-policy input: AutoQos-4.0-CiscoPhone-Input-Policy

```
Class-map: AutoQos-4.0-Voip-Data-CiscoPhone-Class (match-any)
 0 packets
 Match: cos 5
   0 packets, 0 bytes
   5 minute rate 0 bps
 QoS Set
  dscp ef
 police:
   cir 128000 bps, bc 8000 bytes
   conformed 0 bytes; actions:
     transmit
   exceeded 0 bytes; actions:
     set-dscp-transmit dscp table policed-dscp
   conformed 0000 bps, exceed 0000 bps
```

```
Class-map: AutoQos-4.0-Voip-Signal-CiscoPhone-Class (match-any)
 0 packets
 Match: cos 3
   0 packets, 0 bytes
   5 minute rate 0 bps
 QoS Set
  dscp cs3
 police:
   cir 32000 bps, bc 8000 bytes
   conformed 0 bytes; actions:
     transmit
   exceeded 0 bytes; actions:
     set-dscp-transmit dscp table policed-dscp
   conformed 0000 bps, exceed 0000 bps
```

```
Class-map: AutoQos-4.0-Default-Class (match-any)
 0 packets
 Match: access-group name AutoQos-4.0-Acl-Default
   0 packets, 0 bytes
   5 minute rate 0 bps
 QoS Set
  dscp default
```

```
Class-map: class-default (match-any)
 0 packets
 Match: any
   0 packets, 0 bytes
   5 minute rate 0 bps
```

Service-policy output: AutoQos-4.0-Output-Policy

```
queue stats for all priority classes:
 Queueing
  priority level 1

 (total drops) 0
 (bytes output) 0
```

```
Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
 0 packets
 Match: dscp cs4 (32) cs5 (40) ef (46)
   0 packets, 0 bytes
   5 minute rate 0 bps
 Match: cos 5
   0 packets, 0 bytes
   5 minute rate 0 bps
 Priority: 30% (300000 kbps), burst bytes 7500000,
```

```

Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
 0 packets
Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 3
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing
queue-limit dscp 16 percent 80
queue-limit dscp 24 percent 90
queue-limit dscp 48 percent 100
queue-limit dscp 56 percent 100

(total drops) 0
(bytes output) 0
bandwidth remaining 10%

queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
 0 packets
Match: dscp af41 (34) af42 (36) af43 (38)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 4
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
 0 packets
Match: dscp af21 (18) af22 (20) af23 (22)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 2
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
 0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 1
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0

```

```

(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25

```

The following is an example of the **auto qos voip cisco-softphone** command and the applied policies and class maps:

```

Device(config)# interface gigabitEthernet1/0/20
Device(config-if)# auto qos voip cisco-softphone
Device(config-if)# end
Device# show policy-map interface gigabitEthernet1/0/20
GigabitEthernet1/0/21

Service-policy input: AutoQos-4.0-CiscoSoftPhone-Input-Policy

Class-map: AutoQos-4.0-Voip-Data-Class (match-any)
 0 packets
Match: dscp ef (46)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 5
 0 packets, 0 bytes
 5 minute rate 0 bps
QoS Set
 dscp ef
police:

```

```

        cir 128000 bps, bc 8000 bytes
        conformed 0 bytes; actions:
            transmit
        exceeded 0 bytes; actions:
            set-dscp-transmit dscp table policed-dscp
        conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Voip-Signal-Class (match-any)
  0 packets
  Match: dscp cs3 (24)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp cs3
  police:
    cir 32000 bps, bc 8000 bytes
    conformed 0 bytes; actions:
        transmit
    exceeded 0 bytes; actions:
        set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Multimedia-Conf-Class (match-any)
  0 packets
  Match: access-group name AutoQos-4.0-Acl-MultiEnhanced-Conf
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp af41
  police:
    cir 5000000 bps, bc 156250 bytes
    conformed 0 bytes; actions:
        transmit
    exceeded 0 bytes; actions:
        drop
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Bulk-Data-Class (match-any)
  0 packets
  Match: access-group name AutoQos-4.0-Acl-Bulk-Data
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp af11
  police:
    cir 10000000 bps, bc 312500 bytes
    conformed 0 bytes; actions:
        transmit
    exceeded 0 bytes; actions:
        set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Transaction-Class (match-any)
  0 packets
  Match: access-group name AutoQos-4.0-Acl-Transactional-Data
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp af21
  police:
    cir 10000000 bps, bc 312500 bytes

```

```

conformed 0 bytes; actions:
  transmit
exceeded 0 bytes; actions:
  set-dscp-transmit dscp table policed-dscp
conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Scavanger-Class (match-any)
  0 packets
Match: access-group name AutoQos-4.0-Acl-Scavanger
  0 packets, 0 bytes
  5 minute rate 0 bps
QoS Set
  dscp cs1
police:
  cir 10000000 bps, bc 31250 bytes
  conformed 0 bytes; actions:
    transmit
  exceeded 0 bytes; actions:
    drop
  conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Signaling-Class (match-any)
  0 packets
Match: access-group name AutoQos-4.0-Acl-Signaling
  0 packets, 0 bytes
  5 minute rate 0 bps
QoS Set
  dscp cs3
police:
  cir 32000 bps, bc 8000 bytes
  conformed 0 bytes; actions:
    transmit
  exceeded 0 bytes; actions:
    drop
  conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Default-Class (match-any)
  0 packets
Match: access-group name AutoQos-4.0-Acl-Default
  0 packets, 0 bytes
  5 minute rate 0 bps
QoS Set
  dscp default
police:
  cir 10000000 bps, bc 31250 bytes
  conformed 0 bytes; actions:
    transmit
  exceeded 0 bytes; actions:
    set-dscp-transmit dscp table policed-dscp
  conformed 0000 bps, exceed 0000 bps

Class-map: class-default (match-any)
  0 packets
Match: any
  0 packets, 0 bytes
  5 minute rate 0 bps

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0

```

```

(bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
 0 packets
 Match: dscp cs4 (32) cs5 (40) ef (46)
   0 packets, 0 bytes
   5 minute rate 0 bps
 Match: cos 5
   0 packets, 0 bytes
   5 minute rate 0 bps
 Priority: 30% (300000 kbps), burst bytes 7500000,

 Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
 0 packets
 Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
   0 packets, 0 bytes
   5 minute rate 0 bps
 Match: cos 3
   0 packets, 0 bytes
   5 minute rate 0 bps
 Queueing
 queue-limit dscp 16 percent 80
 queue-limit dscp 24 percent 90
 queue-limit dscp 48 percent 100
 queue-limit dscp 56 percent 100

 (total drops) 0
 (bytes output) 0
 bandwidth remaining 10%

 queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
 0 packets
 Match: dscp af41 (34) af42 (36) af43 (38)
   0 packets, 0 bytes
   5 minute rate 0 bps
 Match: cos 4
   0 packets, 0 bytes
   5 minute rate 0 bps
 Queueing

 (total drops) 0
 (bytes output) 0
 bandwidth remaining 10%
 queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
 0 packets
 Match: dscp af21 (18) af22 (20) af23 (22)
   0 packets, 0 bytes
   5 minute rate 0 bps
 Match: cos 2
   0 packets, 0 bytes
   5 minute rate 0 bps
 Queueing

 (total drops) 0
 (bytes output) 0
 bandwidth remaining 10%
 queue-buffers ratio 10

```

```
Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
  0 packets
  Match: dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 1
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 4%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
  0 packets
  Match: dscp cs1 (8)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 1%
  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
  0 packets
  Match: dscp af31 (26) af32 (28) af33 (30)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 25%
  queue-buffers ratio 25
```

You can verify your settings by entering the **show auto qos interface *interface-id*** privileged EXEC command.

debug auto qos

To enable debugging of the automatic quality of service (auto-QoS) feature, use the **debug auto qos** command in privileged EXEC mode. Use the **no** form of this command to disable debugging.

debug auto qos
no debug auto qos

Syntax Description This command has no arguments or keywords.

Command Default Auto-QoS debugging is disabled.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines To display the QoS configuration that is automatically generated when auto-QoS is enabled, enable debugging before you enable auto-QoS. You enable debugging by entering the **debug auto qos** privileged EXEC command.

The **undebug auto qos** command is the same as the **no debug auto qos** command.

When you enable debugging on a device stack, it is enabled only on the active device. To enable debugging on a stack member, you can start a session from the active device by using the **session switch-number** privileged EXEC command. Then enter the **debug** command at the command-line prompt of the stack member. You also can use the **remote command stack-member-number LINE** privileged EXEC command on the active device to enable debugging on a member device without first starting a session.

Examples

This example shows how to display the QoS configuration that is automatically generated when auto-QoS is enabled:

```
Device# debug auto qos
AutoQoS debugging is on
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# auto qos voip cisco-phone
```

show auto qos

To display the quality of service (QoS) commands entered on the interfaces on which automatic QoS (auto-QoS) is enabled, use the **show auto qos** command in privileged EXEC mode.

```
show auto qos [interface [interface-id]]
```

Syntax Description	interface [<i>interface-id</i>]	(Optional) Displays auto-QoS information for the specified port or for all ports. Valid interfaces include physical ports.
---------------------------	---	--

Command Modes	User EXEC Privileged EXEC
----------------------	------------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **show auto qos** command output shows only the **auto qos** command entered on each interface. The **show auto qos interface interface-id** command output shows the **auto qos** command entered on a specific interface. Use the **show running-config** privileged EXEC command to display the auto-QoS configuration and the user modifications.

Beginning in Cisco IOS Release 12.2(40)SE, the **show auto qos** command output shows the service policy information for the Cisco IP phone.

Examples

This is an example of output from the **show auto qos** command after the **auto qos voip cisco-phone** and the **auto qos voip cisco-softphone** interface configuration commands are entered:

```
Device# show auto qos
GigabitEthernet2/0/4
auto qos voip cisco-softphone

GigabitEthernet2/0/5
auto qos voip cisco-phone

GigabitEthernet2/0/6
auto qos voip cisco-phone
```

This is an example of output from the **show auto qos interface interface-id** command when the **auto qos voip cisco-phone** interface configuration command is entered:

```
Device# show auto qos interface gigabitethernet 2/0/5
GigabitEthernet2/0/5
auto qos voip cisco-phone
```

This is an example of output from the **show auto qos interface interface-id** command when the **auto qos voip cisco-phone** interface configuration command is entered:

```
Device# show auto qos interface gigabitethernet1/0/2
GigabitEthernet1/0/2
auto qos voip cisco-phone
```

These are examples of output from the **show auto qos interface *interface-id*** command when auto-QoS is disabled on an interface:

```
Device# show auto qos interface gigabitethernet3/0/1
AutoQoS is disabled
```

class

To define a traffic classification match criteria for the specified class-map name, use the **class** command in policy-map configuration mode. Use the **no** form of this command to delete an existing class map.

```
class {class-map-name | class-default}
no class {class-map-name | class-default}
```

Syntax Description

class-map-name The class map name.

class-default Refers to a system default class that matches unclassified packets.

Command Default

No policy map class-maps are defined.

Command Modes

Policy-map configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Before using the **class** command, you must use the **policy-map** global configuration command to identify the policy map and enter policy-map configuration mode. After specifying a policy map, you can configure a policy for new classes or modify a policy for any existing classes in that policy map. You attach the policy map to a port by using the **service-policy** interface configuration command.

After entering the **class** command, you enter the policy-map class configuration mode. These configuration commands are available:

- **admit**—Admits a request for Call Admission Control (CAC)
- **bandwidth**—Specifies the bandwidth allocated to the class.
- **exit**—Exits the policy-map class configuration mode and returns to policy-map configuration mode.
- **no**—Returns a command to its default setting.
- **police**—Defines a policer or aggregate policer for the classified traffic. The policer specifies the bandwidth limitations and the action to take when the limits are exceeded. For more information about this command, see *Cisco IOS Quality of Service Solutions Command Reference* available on Cisco.com.
- **priority**—Assigns scheduling priority to a class of traffic belonging to a policy map.
- **queue-buffers**—Configures the queue buffer for the class.
- **queue-limit**—Specifies the maximum number of packets the queue can hold for a class policy configured in a policy map.
- **service-policy**—Configures a QoS service policy.
- **set**—Specifies a value to be assigned to the classified traffic. For more information, see [set](#), on page 865
- **shape**—Specifies average or peak rate traffic shaping. For more information about this command, see *Cisco IOS Quality of Service Solutions Command Reference* available on Cisco.com.

To return to policy-map configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

The **class** command performs the same function as the **class-map** global configuration command. Use the **class** command when a new classification, which is not shared with any other ports, is needed. Use the **class-map** command when the map is shared among many ports.

You can configure a default class by using the **class class-default** policy-map configuration command. Unclassified traffic (traffic that does not meet the match criteria specified in the traffic classes) is treated as default traffic.

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Examples

This example shows how to create a policy map called policy1. When attached to the ingress direction, it matches all the incoming traffic defined in class1, sets the IP Differentiated Services Code Point (DSCP) to 10, and polices the traffic at an average rate of 1 Mb/s and bursts at 20 KB. Traffic exceeding the profile is marked down to a DSCP value gotten from the policed-DSCP map and then sent.

```
Device(config)# policy-map policy1
Device(config-pmap)# class class1
Device(config-pmap-c)# set dscp 10
Device(config-pmap-c)# police 1000000 20000 exceed-action policed-dscp-transmit
Device(config-pmap-c)# exit
```

This example shows how to configure a default traffic class to a policy map. It also shows how the default traffic class is automatically placed at the end of policy-map pm3 even though **class-default** was configured first:

```
Device# configure terminal
Device(config)# class-map cm-3
Device(config-cmap)# match ip dscp 30
Device(config-cmap)# exit

Device(config)# class-map cm-4
Device(config-cmap)# match ip dscp 40
Device(config-cmap)# exit

Device(config)# policy-map pm3
Device(config-pmap)# class class-default
Device(config-pmap-c)# set dscp 10
Device(config-pmap-c)# exit

Device(config-pmap)# class cm-3
Device(config-pmap-c)# set dscp 4
Device(config-pmap-c)# exit

Device(config-pmap)# class cm-4
Device(config-pmap-c)# set precedence 5
Device(config-pmap-c)# exit
Device(config-pmap)# exit

Device# show policy-map pm3
Policy Map pm3
  Class cm-3
    set dscp 4
  Class cm-4
    set precedence 5
  Class class-default
```

```
set dscp af11
```

Related Topics

[class-map](#), on page 846

[policy-map](#), on page 853

[show policy-map](#), on page 889

[set](#), on page 865

class-map

To create a class map to be used for matching packets to the class whose name you specify and to enter class-map configuration mode, use the **class-map** command in global configuration mode. Use the **no** form of this command to delete an existing class map and to return to global or policy map configuration mode.

```
class-map [{match-anytype}] class-map-name
no class-map [{match-anytype}] class-map-name
```

Syntax Description	
match-any	(Optional) Perform a logical-OR of the matching statements under this class map. One or more criteria must be matched.
type	(Optional) Configures the CPL class map.
<i>class-map-name</i>	The class map name.

Command Default No class maps are defined.

Command Modes Global configuration
Policy map configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
	Cisco IOS XE 3.3SE	The type keyword was added.

Usage Guidelines Use this command to specify the name of the class for which you want to create or modify class-map match criteria and to enter class-map configuration mode.

The **class-map** command and its subcommands are used to define packet classification, marking, and aggregate policing as part of a globally named service policy applied on a per-port basis.

After you are in quality of service (QoS) class-map configuration mode, these configuration commands are available:

- **description**—Describes the class map (up to 200 characters). The **show class-map** privileged EXEC command displays the description and the name of the class map.
- **exit**—Exits from QoS class-map configuration mode.
- **match**—Configures classification criteria.
- **no**—Removes a match statement from a class map.

If you enter the **match-any** keyword, you can only use it to specify an extended named access control list (ACL) with the **match access-group** class-map configuration command.

To define packet classification on a physical-port basis, only one **match** command per class map is supported.

The ACL can have multiple access control entries (ACEs).

Examples

This example shows how to configure the class map called class1 with one match criterion, which is an access list called 103:

```
Device(config)# access-list 103 permit ip any any dscp 10
Device(config)# class-map class1
Device(config-cmap)# match access-group 103
Device(config-cmap)# exit
```

This example shows how to delete the class map class1:

```
Device(config)# no class-map class1
```

You can verify your settings by entering the **show class-map** privileged EXEC command.

Related Topics

[policy-map](#), on page 853

[show policy-map](#), on page 889

match (class-map configuration)

To define the match criteria to classify traffic, use the **match** command in class-map configuration mode. Use the **no** form of this command to remove the match criteria.

```
match {access-group {name acl-name acl-index} | class-map class-map-name | cos cos-value | dscp
dscp-value | [ip] dscp dscp-list | [ip] precedence ip-precedence-list | precedence
precedence-value1...value4 | qos-group qos-group-value | vlan vlan-id}
no match {access-group {name acl-name acl-index} | class-map class-map-name | cos cos-value | dscp
dscp-value | [ip] dscp dscp-list | [ip] precedence ip-precedence-list | precedence
precedence-value1...value4 | qos-group qos-group-value | vlan vlan-id}
```

Syntax Description		
access-group		Specifies an access group.
name <i>acl-name</i>		Specifies the name of an IP standard or extended access control list (ACL) or MAC ACL.
<i>acl-index</i>		Specifies the number of an IP standard or extended access control list (ACL) or MAC ACL. For an IP standard ACL, the ACL index range is 1 to 99 and 1300 to 1999. For an IP extended ACL, the ACL index range is 100 to 199 and 2000 to 2699.
class-map <i>class-map-name</i>		Uses a traffic class as a classification policy and specifies a traffic class name to use as the match criterion.
cos <i>cos-value</i>		Matches a packet on the basis of a Layer 2 class of service (CoS)/Inter-Switch Link (ISL) marking. The cos-value is from 0 to 7. You can specify up to four CoS values in one match cos statement, separated by a space.
dscp <i>dscp-value</i>		Specifies the parameters for each DSCP value. You can specify a value in the range 0 to 63 specifying the differentiated services code point value.
ip dscp <i>dscp-list</i>		Specifies a list of up to eight IP Differentiated Services Code Point (DSCP) values to match against incoming packets. Separate each value with a space. The range is 0 to 63. You also can enter a mnemonic name for a commonly used value.
ip precedence <i>ip-precedence-list</i>		Specifies a list of up to eight IP-precedence values to match against incoming packets. Separate each value with a space. The range is 0 to 7. You also can enter a mnemonic name for a commonly used value.
precedence <i>precedence-value1...value4</i>		Assigns an IP precedence value to the classified traffic. The range is 0 to 7. You also can enter a mnemonic name for a commonly used value.

qos-group <i>qos-group-value</i>	Identifies a specific QoS group value as a match criterion. The range is 0 to 31.
vlan <i>vlan-id</i>	Identifies a specific VLAN as a match criterion. The range is 1 to 4095.

Command Default

No match criteria are defined.

Command Modes

Class-map configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Cisco IOS XE 3.3SE	The class-map <i>class-map-name</i> , cos <i>cos-value</i> , qos-group <i>qos-group-value</i> , and vlan <i>vlan-id</i> keywords were added.

Usage Guidelines

The **match** command is used to specify which fields in the incoming packets are examined to classify the packets. Only the IP access group or the MAC access group matching to the Ether Type/Len are supported.

If you enter the **class-map match-any***class-map-name* global configuration command, you can enter the following **match** commands:

- **match access-group name** *acl-name*



Note The ACL must be an extended named ACL.

- **match ip dscp** *dscp-list*
- **match ip precedence** *ip-precedence-list*

The **match access-group** *acl-index* command is not supported.

To define packet classification on a physical-port basis, only one **match** command per class map is supported. In this situation, the **match-any** keyword is equivalent.

For the **match ip dscp** *dscp-list* or the **match ip precedence** *ip-precedence-list* command, you can enter a mnemonic name for a commonly used value. For example, you can enter the **match ip dscp af11** command, which is the same as entering the **match ip dscp 10** command. You can enter the **match ip precedence critical** command, which is the same as entering the **match ip precedence 5** command. For a list of supported mnemonics, enter the **match ip dscp ?** or the **match ip precedence ?** command to see the command-line help strings.

Use the **input-interface** *interface-id-list* keyword when you are configuring an interface-level class map in a hierarchical policy map. For the *interface-id-list*, you can specify up to six entries.

Examples

This example shows how to create a class map called class2, which matches all the incoming traffic with DSCP values of 10, 11, and 12:

```
Device(config)# class-map class2
Device(config-cmap)# match ip dscp 10 11 12
```

```
Device(config-cmap) # exit
```

This example shows how to create a class map called class3, which matches all the incoming traffic with IP-precedence values of 5, 6, and 7:

```
Device(config) # class-map class3
Device(config-cmap) # match ip precedence 5 6 7
Device(config-cmap) # exit
```

This example shows how to delete the IP-precedence match criteria and to classify traffic using acl1:

```
Device(config) # class-map class2
Device(config-cmap) # match ip precedence 5 6 7
Device(config-cmap) # no match ip precedence
Device(config-cmap) # match access-group acl1
Device(config-cmap) # exit
```

This example shows how to specify a list of physical ports to which an interface-level class map in a hierarchical policy map applies:

```
Device(config) # class-map match-any class4
Device(config-cmap) # match cos 4
Device(config-cmap) # exit
```

This example shows how to specify a range of physical ports to which an interface-level class map in a hierarchical policy map applies:

```
Device(config) # class-map match-any class4
Device(config-cmap) # match cos 4
Device(config-cmap) # exit
```

You can verify your settings by entering the **show class-map** privileged EXEC command.

match non-client-nrt

To match non-client NRT (non-real-time), use the **match non-client-nrt** command in class-map configuration mode. Use the **no** form of this command to return to the default setting.

match non-client-nrt
no match non-client-nrt

Syntax Description	This command has no arguments or keywords.	
Command Default	None	
Command Modes	Class-map	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	None	

This example show how you can configure non-client NRT:

```
Device(config)# class-map test_1000
Device(config-cmap)# match non-client-nrt
```

match wlan user-priority

To match 802.11 specific values, use the **match wlan user-priority** command in class-map configuration mode. Use the **no** form of this command to return to the default setting.

```
match wlan user-priority wlan-value [wlan-value] [wlan-value] [wlan-value]
no match wlan user-priority wlan-value [wlan-value] [wlan-value] [wlan-value]
```

Syntax Description	<i>wlan-value</i> The 802.11-specific values. Enter the user priority 802.11 TID user priority (0-7). (Optional) Enter up to three user priority values separated by white-spaces.				
Command Default	None				
Command Modes	Class-map				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				
Usage Guidelines	None				

This example show how you can configure user-priority values:

```
Device(config)# class-map test_1000
Device(config-cmap)# match wlan user-priority 7
```

policy-map

To create or modify a policy map that can be attached to multiple physical ports or switch virtual interfaces (SVIs) and to enter policy-map configuration mode, use the **policy-map** command in global configuration mode. Use the **no** form of this command to delete an existing policy map and to return to global configuration mode.

policy-map *policy-map-name*
no policy-map *policy-map-name*

Syntax Description

policy-map-name Name of the policy map.

Command Default

No policy maps are defined.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

After entering the **policy-map** command, you enter policy-map configuration mode, and these configuration commands are available:

- **class**—Defines the classification match criteria for the specified class map.
- **description**—Describes the policy map (up to 200 characters).
- **exit**—Exits policy-map configuration mode and returns you to global configuration mode.
- **no**—Removes a previously defined policy map.
- **sequence-interval**—Enables sequence number capability.

To return to global configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

Before configuring policies for classes whose match criteria are defined in a class map, use the **policy-map** command to specify the name of the policy map to be created, added to, or modified. Entering the **policy-map** command also enables the policy-map configuration mode in which you can configure or modify the class policies for that policy map.

You can configure class policies in a policy map only if the classes have match criteria defined for them. To configure the match criteria for a class, use the **class-map** global configuration and **match** class-map configuration commands. You define packet classification on a physical-port basis.

Only one policy map per ingress port is supported. You can apply the same policy map to multiple physical ports.

You can apply a nonhierarchical policy maps to physical ports. A nonhierarchical policy map is the same as the port-based policy maps in the device.

A hierarchical policy map has two levels in the format of a parent-child policy. The parent policy cannot be modified but the child policy (port-child policy) can be modified to suit the QoS configuration.

In VLAN-based QoS, a service policy is applied to an SVI interface. All physical interfaces belonging to a VLAN policy map then need to be configured to refer to the VLAN-based policy maps instead of the port-based policy map.



Note Not all MQC QoS combinations are supported for wired and wireless ports. For information about these restrictions, see chapters "Restrictions for QoS on Wired Targets" and "Restrictions for QoS on Wireless Targets" in the QoS configuration guide.

Examples

This example shows how to create a policy map called policy1. When attached to the ingress port, it matches all the incoming traffic defined in class1, sets the IP DSCP to 10, and polices the traffic at an average rate of 1 Mb/s and bursts at 20 KB. Traffic less than the profile is sent.

```
Device(config)# policy-map policy1
Device(config-pmap)# class class1
Device(config-pmap-c)# set dscp 10
Device(config-pmap-c)# police 1000000 20000 conform-action transmit
Device(config-pmap-c)# exit
```

This example show you how to configure hierarchical polices:

```
Switch# configure terminal
Device(config)# class-map c1
Device(config-cmap)# exit

Device(config)# class-map c2
Device(config-cmap)# exit

Device(config)# policy-map child
Device(config-pmap)# class c1
Device(config-pmap-c)# priority level 1
Device(config-pmap-c)# police rate percent 20 conform-action transmit exceed action drop
Device(config-pmap-c-police)# exit
Device(config-pmap-c)# exit

Device(config-pmap)# class c2
Device(config-pmap-c)# bandwidth 20000
Device(config-pmap-c)# exit

Device(config-pmap)# class class-default
Device(config-pmap-c)# bandwidth 20000
Device(config-pmap-c)# exit
Device(config-pmap)# exit

Device(config)# policy-map parent
Device(config-pmap)# class class-default
Device(config-pmap-c)# shape average 1000000
Device(config-pmap-c)# service-policy child
Device(config-pmap-c)# end
```

This example shows how to delete a policy map:

```
Device(config)# no policy-map policymap2
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Related Topics

[class](#), on page 843

[class-map](#), on page 846

[service-policy \(Wired\)](#), on page 862

[show policy-map](#), on page 889

priority

To assign priority to a class of traffic belonging to a policy map, use the **priority** command in policy-map class configuration mode. To remove a previously specified priority for a class, use the **no** form of this command.

```
priority [Kbps [burst -in-bytes] ] | level level-value [Kbps [burst -in-bytes] ] | percent
percentage [Kb/s [burst -in-bytes] ] ]
no priority [Kb/s [burst -in-bytes] ] | level level value [Kb/s [burst -in-bytes] ] | percent
percentage [Kb/s [burst -in-bytes] ] ]
```

Syntax Description		
<i>Kb/s</i>	(Optional) Guaranteed allowed bandwidth, in kilobits per second (kbps), for the priority traffic. The amount of guaranteed bandwidth varies according to the interface and platform in use. Beyond the guaranteed bandwidth, the priority traffic will be dropped in the event of congestion to ensure that the nonpriority traffic is not starved. The value must be between 1 and 2,000,000 kbps.	
<i>burst -in-bytes</i>	(Optional) Burst size in bytes. The burst size configures the network to accommodate temporary bursts of traffic. The default burst value, which is computed as 200 milliseconds of traffic at the configured bandwidth rate, is used when the burst argument is not specified. The range of the burst is from 32 to 2000000 bytes.	
level <i>level-value</i>	(Optional) Assigns priority level. Available values for <i>level-value</i> are 1 and 2. Level 1 is a higher priority than Level 2. Level 1 reserves bandwidth and goes first, so latency is very low. Reserve the bandwidth even if you do not use it. Both levels 1 and 2 can reserve bandwidth.	
percent <i>percentage</i>	(Optional) Specifies the amount of guaranteed bandwidth to be specified by the percent of available bandwidth.	

Command Default No priority is set.

Command Modes Policy-map class configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
	Cisco IOS XE 3.3SE	The <i>Kbps</i> , <i>burst -in-bytes</i> , and percent percentage keywords were added.

Usage Guidelines This command configures low latency queuing (LLQ), providing strict priority queuing (PQ) for class-based weighted fair queuing (CBWFQ). Strict PQ allows delay-sensitive data such as voice to be dequeued and sent before packets in other queues are dequeued.



Note You can configure a priority only with a level.

Only one strict priority or priority with levels is allowed in one policy-map. Multiple priorities with same priority levels without kbps/percent are allowed in a policy-map only if all of them are configured with police.

The priority command allows you to set up classes based on a variety of criteria (not just User Datagram Ports [UDP] ports) and assign priority to them, and is available for use on serial interfaces and ATM permanent virtual circuits (PVCs). A similar command, the **ip rtp priority** command, allows you to stipulate priority flows based only on UDP port numbers and is not available for ATM PVCs.

When the device is not congested, the priority class traffic is allowed to exceed its allocated bandwidth. When the device is congested, the priority class traffic above the allocated bandwidth is discarded.

The bandwidth and priority commands cannot be used in the same class, within the same policy map. However, these commands can be used together in the same policy map.

Within a policy map, you can give one or more classes priority status. When multiple classes within a single policy map are configured as priority classes, all traffic from these classes is queued to the same, single, priority queue.

When the policy map containing class policy configurations is attached to the interface to stipulate the service policy for that interface, available bandwidth is assessed. If a policy map cannot be attached to a particular interface because of insufficient interface bandwidth, the policy is removed from all interfaces to which it was successfully attached.

Example

The following example shows how to configure the priority of the class in policy map policy1:

```
Device(config)# class-map cm1
Device(config-cmap)#match precedence 2
Device(config-cmap)#exit

Device(config)#class-map cm2
Device(config-cmap)#match dscp 30
Device(config-cmap)#exit

Device(config)# policy-map policy1
Device(config-pmap)# class cm1
Device(config-pmap-c)# priority level 1
Device(config-pmap-c)# police 1m
Device(config-pmap-c-police)#exit
Device(config-pmap-c)#exit
Device(config-pmap)#exit

Device(config)#policy-map policy1
Device(config-pmap)#class cm2
Device(config-pmap-c)#priority level 2
Device(config-pmap-c)#police 1m
```

queue-buffers ratio

To configure the queue buffer for the class, use the **queue-buffers ratio** command in policy-map class configuration mode. Use the **no** form of this command to remove the ratio limit.

queue-buffers ratio *ratio limit*
no queue-buffers ratio *ratio limit*

Syntax Description	<i>ratio limit</i> (Optional) Configures the queue buffer for the class. Enter the queue buffers ratio limit (0-100).				
Command Default	No queue buffer for the class is defined.				
Command Modes	Policy-map class configuration (config-pmap-c)				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				
Usage Guidelines	<p>Either the bandwidth, shape, or priority command must be used before using this command. For more information about these commands, see <i>Cisco IOS Quality of Service Solutions Command Reference</i> available on Cisco.com</p> <p>The <code>queue-buffers ratio</code> allows you to allocate buffers to queues. If buffers are not allocated, then they are divided equally amongst all queues. You can use the queue-buffer ratio to divide it in a particular ratio. The buffers are soft buffers because Dynamic Threshold and Scaling (DTS) is active on all queues by default.</p>				

Example

The following example sets the queue buffers ratio to 10 percent:

```
Device(config)# policy-map policy_queuebuf01
Device(config-pmap)# class-map class_queuebuf01
Device(config-cmap)# exit
Device(config)# policy policy_queuebuf01
Device(config-pmap)# class class_queuebuf01
Device(config-pmap-c)# bandwidth percent 80
Device(config-pmap-c)# queue-buffers ratio 10
Device(config-pmap)# end
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Related Topics

[show policy-map](#), on page 889

queue-limit

To specify or modify the maximum number of packets the queue can hold for a class policy configured in a policy map, use the **queue-limit** policy-map class configuration command. To remove the queue packet limit from a class, use the **no** form of this command.

```
queue-limit queue-limit-size [{packets}] {cos cos-value | dscp dscp-value} percent percentage-of-packets
no queue-limit queue-limit-size [{packets}] {cos cos-value | dscp dscp-value} percent
percentage-of-packets
```

Syntax Description

<i>queue-limit-size</i>	The maximum size of the queue. The maximum varies according to the optional unit of measure keyword specified (bytes, ms, us, or packets).
cos <i>cos-value</i>	Specifies parameters for each cos value. CoS values are from 0 to 7.
dscp <i>dscp-value</i>	Specifies parameters for each DSCP value. You can specify a value in the range 0 to 63 specifying the differentiated services code point value for the type of queue limit .
percent <i>percentage-of-packets</i>	A percentage in the range 1 to 100 specifying the maximum percentage of packets that the queue for this class can accumulate.

Command Default

None

Command Modes

Policy-map class configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

Although visible in the command line help-strings, the **packets** unit of measure is not supported; use the **percent** unit of measure.



Note

This command is supported only on wired ports in the egress direction.

Weighted fair queuing (WFQ) creates a queue for every class for which a class map is defined. Packets satisfying the match criteria for a class accumulate in the queue reserved for the class until they are sent, which occurs when the queue is serviced by the fair queuing process. When the maximum packet threshold you defined for the class is reached, queuing of any further packets to the class queue causes tail drop.

You use queue limits to configure Weighted Tail Drop (WTD). WTD ensures the configuration of more than one threshold per queue. Each class of service is dropped at a different threshold value to provide for QoS differentiation.

You can configure the maximum queue thresholds for the different subclasses of traffic, that is, DSCP and CoS and configure the maximum queue thresholds for each subclass.

Example

The following example configures a policy map called port-queue to contain policy for a class called dscp-1. The policy for this class is set so that the queue reserved for it has a maximum packet limit of 20 percent:

```
Device(config)# policy-map policy11
Device(config-pmap)# class dscp-1
Device(config-pmap-c)# bandwidth percent 20
Device(config-pmap-c)# queue-limit dscp 1 percent 20
```

qos wireless-default untrust

To configure the default trust behavior to untrust wireless packets, use the **qos wireless-default untrust** command. To configure the default trust behavior of wireless traffic to trust, use the **no** form of the command.

```
qos wireless-default-untrust
no qos wireless-default-untrust
```

Syntax Description

This command has no arguments or keywords.

Command Default

By default, the wireless traffic is trusted.

To check the trust behavior on the device, use the **show running-config | sec qos** or the **show run | include untrust** command.

Command Modes

Configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

The following command changes the default behavior for trusting wireless traffic to untrust.

```
Device(config)# qos wireless-default-untrust
```

service-policy (Wired)

To apply a policy map to a physical port or a switch virtual interface (SVI), use the **service-policy** command in interface configuration mode. Use the **no** form of this command to remove the policy map and port association.

```
service-policy {input | output} policy-map-name
no service-policy {input | output} policy-map-name
```

Syntax Description

input *policy-map-name* Apply the specified policy map to the input of a physical port or an SVI.

output *policy-map-name* Apply the specified policy map to the output of a physical port or an SVI.

Command Default

No policy maps are attached to the port.

Command Modes

WLAN interface configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
	This command was introduced.

Usage Guidelines

A policy map is defined by the **policy map** command.

Only one policy map is supported per port, per direction. In other words, only one input policy and one output policy is allowed on any one port.

You can apply a policy map to incoming traffic on a physical port or on an SVI. *QoS Configuration Guide (Catalyst 3650 Switches)*.



Note

Though visible in the command-line help strings, the **history** keyword is not supported, and you should ignore the statistics that it gathers.

Examples

This example shows how to apply plcmap1 to an physical ingress port:

```
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# service-policy input plcmap1
```

This example shows how to remove plcmap2 from a physical port:

```
Device(config)# interface gigabitethernet2/0/2
Device(config-if)# no service-policy input plcmap2
```

The following example displays a VLAN policer configuration. At the end of this configuration, the VLAN policy map is applied to an interface for QoS:

```
Device# configure terminal
Device(config)# class-map vlan100
Device(config-cmap)# match vlan 100
Device(config-cmap)# exit
Device(config)# policy-map vlan100
Device(config-pmap)# policy-map class vlan100
Device(config-pmap-c)# police 100000 bc conform-action transmit exceed-action drop
Device(config-pmap-c-police)# end
Device# configure terminal
Device(config)# interface gigabitEthernet1/0/5
Device(config-if)# service-policy input vlan100
```

You can verify your settings by entering the **show running-config** privileged EXEC command.

Related Topics

[policy-map](#), on page 853

[show policy-map](#), on page 889

service-policy (WLAN)

To configure the WLAN quality of service (QoS) service policy, use the **service-policy** command. To disable a QoS policy on a WLAN, use the **no** form of this command.

```
service-policy [client] {input | output} policy-name
no service-policy [client] {input | output} policy-name
```

Syntax Description

client	(Optional) Assigns a policy map to all clients in the WLAN.
input	Assigns an input policy map.
output	Assigns an output policy map.
<i>policy-name</i>	The policy name.

Command Default

No policies are assigned and the state assigned to the policy is None.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to configure the input QoS service policy on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# service-policy input policy-test
```

This example shows how to disable the input QoS service policy on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no service-policy input policy-test
```

This example shows how to configure the output QoS service policy on a WLAN to platinum (precious metal policy):

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# service-policy output platinum
```

Related Topics

[wlan](#), on page 1402

set

To classify IP traffic by setting a Differentiated Services Code Point (DSCP) or an IP-precedence value in the packet, use the **set** command in policy-map class configuration mode. Use the **no** form of this command to remove traffic classification.

set

cos | **dscp** | **precedence** | **ip** | **qos-group** | **wlan**

set cos

{*cos-value*} | {**cos** | **dscp** | **precedence** | **qos-group** | **wlan**} [{**table** *table-map-name*}]

set dscp

{*dscp-value*} | {**cos** | **dscp** | **precedence** | **qos-group** | **wlan**} [{**table** *table-map-name*}]

set ip {dscp | precedence}

set precedence {*precedence-value*} | {**cos** | **dscp** | **precedence** | **qos-group**} [{**table** *table-map-name*}]

set qos-group

{*qos-group-value* | **dscp** [{**table** *table-map-name*}] | **precedence** [{**table** *table-map-name*}]}

set wlan user-priority

user-priority-value | **costable** *table-map-name* | **dscptable** *table-map-name* | **qos-grouptable** *table-map-name* | **wlantable** *table-map-name*

Syntax Description**cos**

Sets the Layer 2 class of service (CoS) value or user priority of an outgoing packet. You can specify these values:

- *cos-value*—CoS value from 0 to 7. You also can enter a mnemonic name for a commonly used value.
- Specify a packet-marking category to set the CoS value of the packet. If you also configure a table map for mapping and converting packet-marking values, this establishes the "map from" packet-marking category. Packet-marking category keywords:
 - **cos**—Sets a value from the CoS value or user priority.
 - **dscp**—Sets a value from packet differentiated services code point (DSCP).
 - **precedence**—Sets a value from packet precedence.
 - **qos-group**—Sets a value from the QoS group.
 - **wlan**—Sets the WLAN user priority values.
- (Optional) **table** *table-map-name*—Indicates that the values set in a specified table map are used to set the CoS value. Enter the name of the table map used to specify the CoS value. The table map name can be a maximum of 64 alphanumeric characters.

If you specify a packet-marking category but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the CoS value. For example, if you enter the **set cos precedence** command, the precedence (packet-marking category) value is copied and used as the CoS value.

dscp

Sets the differentiated services code point (DSCP) value to mark IP(v4) and IPv6 packets. You can specify these values:

- *cos-value*—Number that sets the DSCP value. The range is from 0 to 63. You also can enter a mnemonic name for a commonly used value.
- Specify a packet-marking category to set the DSCP value of the packet. If you also configure a table map for mapping and converting packet-marking values, this establishes the "map from" packet-marking category. Packet-marking category keywords:
 - **cos**—Sets a value from the CoS value or user priority.
 - **dscp**—Sets a value from packet differentiated services code point (DSCP).
 - **precedence**—Sets a value from packet precedence.
 - **qos-group**—Sets a value from the QoS group.
 - **wlan**—Sets a value from WLAN.
- (Optional)**table** *table-map-name*—Indicates that the values set in a specified table map will be used to set the DSCP value. Enter the name of the table map used to specify the DSCP value. The table map name can be a maximum of 64 alphanumeric characters.

If you specify a packet-marking category but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the DSCP value. For example, if you enter the **set dscp cos** command, the CoS value (packet-marking category) is copied and used as the DSCP value.

ip

Sets IP values to the classified traffic. You can specify these values:

- **dscp**—Specify an IP DSCP value from 0 to 63 or a packet marking category.
 - **precedence**—Specify a precedence-bit value in the IP header; valid values are from 0 to 7 or specify a packet marking category.
-

precedence

Sets the precedence value in the packet header. You can specify these values:

- *precedence-value*— Sets the precedence bit in the packet header; valid values are from 0 to 7. You also can enter a mnemonic name for a commonly used value.
- Specify a packet marking category to set the precedence value of the packet.
 - **cos**—Sets a value from the CoS or user priority.
 - **dscp**—Sets a value from packet differentiated services code point (DSCP).
 - **precedence**—Sets a value from packet precedence.
 - **qos-group**—Sets a value from the QoS group.
- (Optional) **table** *table-map-name*—Indicates that the values set in a specified table map will be used to set the precedence value. Enter the name of the table map used to specify the precedence value. The table map name can be a maximum of 64 alphanumeric characters.

If you specify a packet-marking category but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the precedence value. For example, if you enter the **set precedence cos** command, the CoS value (packet-marking category) is copied and used as the precedence value.

qos-group

Assigns a QoS group identifier that can be used later to classify packets.

- *qos-group-value*—Sets a QoS value to the classified traffic. The range is 0 to 31. You also can enter a mnemonic name for a commonly used value.
- **dscp**—Sets the original DSCP field value of the packet as the QoS group value.
- **precedence**—Sets the original precedence field value of the packet as the QoS group value.
- (Optional)**table** *table-map-name*—Indicates that the values set in a specified table map will be used to set the DSCP or precedence value. Enter the name of the table map used to specify the value. The table map name can be a maximum of 64 alphanumeric characters.

If you specify a packet-marking category (**dscp** or **precedence**) but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the QoS group value. For example, if you enter the **set qos-group precedence** command, the precedence value (packet-marking category) is copied and used as the QoS group value.

wlan user-priority *wlan-user-priority*

Assigns a WLAN user-priority to the classified traffic. You can specify these values:

- *wlan-user-priority*—Sets a WLAN user priority to the classified traffic. The range is 0 to 7.
- **cos**—Sets the Layer 2 CoS field value as the WLAN user priority.
- **dscp**—Sets the DSCP field value as the WLAN user priority.
- **precedence**—Sets the precedence field value as the WLAN user priority.
- **wlan**—Sets the WLAN user priority field value as the WLAN user priority.
- (Optional)**table** *table-map-name*—Indicates that the values set in a specified table map will be used to set the WLAN user priority value. Enter the name of the table map used to specify the value. The table map name can be a maximum of 64 alphanumeric characters.

If you specify a packet-marking category but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the WLAN user priority. For example, if you enter the **set wlan user-priority cos** command, the cos value (packet-marking category) is copied and used as the WLAN user priority.

Command Default

No traffic classification is defined.

Command Modes

Policy-map class configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Cisco IOS XE 3.3SE	The cos , dscp , qos-group , wlan <i>table-map-name</i> , keywords were added.

Usage Guidelines

For the **set dscp** *dscp-value* command, the **set cos** *cos-value* command, and the **set ip precedence** *precedence-value* command, you can enter a mnemonic name for a commonly used value. For example, you can enter the **set dscp af11** command, which is the same as entering the **set dscp 10** command. You can enter the **set ip precedence critical** command, which is the same as entering the **set ip precedence 5** command. For a list of supported mnemonics, enter the **set dscp ?** or the **set ip precedence ?** command to see the command-line help strings.

When you configure the **set dscp cos** command, note the following: The CoS value is a 3-bit field, and the DSCP value is a 6-bit field. Only the three bits of the CoS field are used.

When you configure the **set dscp qos-group** command, note the following:

- The valid range for the DSCP value is a number from 0 to 63. The valid value range for the QoS group is a number from 0 to 99.
- If a QoS group value falls within both value ranges (for example, 44), the packet-marking value is copied and the packets is marked.
- If QoS group value exceeds the DSCP range (for example, 77), the packet-marking value is not be copied and the packet is not marked. No action is taken.

The **set qos-group** command cannot be applied until you create a service policy in policy-map configuration mode and then attach the service policy to an interface or ATM virtual circuit (VC).

To return to policy-map configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

Examples

This example shows how to assign DSCP 10 to all FTP traffic without any policers:

```
Device(config)# policy-map policy_ftp
Device(config-pmap)# class-map ftp_class
Device(config-cmap)# exit
Device(config)# policy policy_ftp
Device(config-pmap)# class ftp_class
Device(config-pmap-c)# set dscp 10
Device(config-pmap)# exit
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Related Topics

[class](#), on page 843

[policy-map](#), on page 853

[show policy-map](#), on page 889

show ap name service-policy

To display service-policy information for a specific Cisco lightweight access point, use the **show ap name service-policy** command.

show ap name *ap-name* **service-policy**

Syntax Description	<i>ap-name</i> Name of the Cisco lightweight access point.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to display service-policy information for a specific Cisco lightweight access point:

```
Device# show ap name 3502b service-policy

NAME: Cisco AP      , DESCR: Cisco Wireless Access Point
PID: 3502I  , VID: V01, SN: FTX1525E94A

NAME: Dot11Radio0   , DESCR: 802.11N 2.4GHz Radio
PID: UNKNOWN, VID:  , SN: FOC1522BLNA

NAME: Dot11Radio1   , DESCR: 802.11N 5GHz Radio
PID: UNKNOWN, VID:  , SN: FOC1522BLNA
```

show ap name dot11

To display 802.11a or 802.11b configuration information that corresponds to specific Cisco lightweight access points, use the **show ap name dot11** command.

```
show ap name ap-name dot11 {24ghz | 5ghz} {ccx | cdp | profile | service-policy output | stats | tsm}
{allclient-mac}
```

Syntax	Description
<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.
ccx	Displays the Cisco Client eXtensions (CCX) radio management status information.
cdp	Displays Cisco Discovery Protocol (CDP) information.
profile	Displays configuration and statistics of 802.11 profiling.
service-policy output	Displays downstream service policy information.
stats	Displays Cisco lightweight access point statistics.
tsm	Displays 802.11 traffic stream metrics statistics.
all	Displays the list of all access points to which the client has associations.
<i>client-mac</i>	MAC address of the client.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display the service policy that is associated with the access point:

```
Device# show ap name test-ap dot11 24ghz service-policy output

Policy Name : test-ap1
Policy State : Installed
```

This example shows how to display the CCX RRM 802.11 configuration for a specific access point:

```
Device# show ap name AP01 dot11 24ghz ccx
```

This example show how to display CDP information for a specific access point:

```
Device# show ap name AP01 dot11 24ghz cdp
```

```
AP Name          AP CDP State
-----
AP03             Disabled
```

This example show how to display the configuration and statistics of 802.11b profiling for a specific access point:

```
Device# show ap name AP01 dot11 24ghz profile
```

```
802.11b Cisco AP performance profile mode      : GLOBAL
802.11b Cisco AP Interference threshold       : 10 %
802.11b Cisco AP noise threshold             : -70 dBm
802.11b Cisco AP RF utilization threshold     : 80 %
802.11b Cisco AP throughput threshold        : 1000000 bps
802.11b Cisco AP clients threshold           : 12 clients
```

This example show how to display downstream service policy information for a specific access point:

```
Device# show ap name AP01 dot11 24ghz service-policy output
```

```
Policy Name      : def-11gn
Policy State     : Installed
```

This example show how to display statistics for a specific access point:

```
Device# show ap name AP01 dot11 24ghz stats
```

```
Number of Users.....: 0
TxFragmentCount.....: 0
MulticastTxFrameCnt.....: 0
FailedCount.....: 0
RetryCount.....: 0
MultipleRetryCount.....: 0
FrameDuplicateCount.....: 0
RtsSuccessCount.....: 0
RtsFailureCount.....: 0
AckFailureCount.....: 0
RxIncompleteFragment.....: 0
MulticastRxFrameCnt.....: 0
FcsErrorCount.....: 0
TxFrameCount.....: 0
WepUndecryptableCount.....: 0
TxFramesDropped.....: 0

Call Admission Control (CAC) Stats
  Voice Bandwidth in use(% of config bw).....: 0
  Video Bandwidth in use(% of config bw).....: 0
  Total BW in use for Voice(%).....: 0
  Total BW in use for SIP Preferred call(%).....: 0

Load based Voice Call Stats
  Total channel MT free.....: 0
  Total voice MT free.....: 0
  Na Direct.....: 0
  Na Roam.....: 0

WMM TSPEC CAC Call Stats
  Total num of voice calls in progress.....: 0
  Num of roaming voice calls in progress.....: 0
  Total Num of voice calls since AP joined.....: 0
```

```

Total Num of roaming calls since AP joined.....: 0
Total Num of exp bw requests received.....: 0
Total Num of exp bw requests admitted.....: 0
Num of voice calls rejected since AP joined....: 0
Num of roam calls rejected since AP joined.....: 0
Num of calls rejected due to insufficient bw....: 0
Num of calls rejected due to invalid params....: 0
Num of calls rejected due to PHY rate.....: 0
Num of calls rejected due to QoS policy.....: 0

```

SIP CAC Call Stats

```

Total Num of calls in progress.....: 0
Num of roaming calls in progress.....: 0
Total Num of calls since AP joined.....: 0
Total Num of roaming calls since AP joined.....: 0
Total Num of Preferred calls received.....: 0
Total Num of Preferred calls accepted.....: 0
Total Num of ongoing Preferred calls.....: 0
Total Num of calls rejected(Insuff BW).....: 0
Total Num of roam calls rejected(Insuff BW)....: 0

```

Band Select Stats

```

Num of dual band client .....: 0
Num of dual band client added.....: 0
Num of dual band client expired .....: 0
Num of dual band client replaced.....: 0
Num of dual band client detected .....: 0
Num of suppressed client .....: 0
Num of suppressed client expired.....: 0
Num of suppressed client replaced.....: 0

```

This example show how to display the traffic stream configuration for all clients that correspond to a specific access point:

```
Device# show ap name AP01 dot11 24ghz tsm all
```

show class-map

To display quality of service (QoS) class maps, which define the match criteria to classify traffic, use the **show class-map** command in EXEC mode.

```
show class-map [class-map-name | type control subscriber {all | class-map-name}]
```

Syntax Description

class-map-name (Optional) Class map name.

type control subscriber (Optional) Displays information about control class maps.

all (Optional) Displays information about all control class maps.

Command Modes

User EXEC

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Examples

This is an example of output from the **show class-map** command:

```
Device# show class-map
Class Map match-any videowizard_10-10-10-10 (id 2)
  Match access-group name videowizard_10-10-10-10

Class Map match-any class-default (id 0)
  Match any
Class Map match-any dscp5 (id 3)
  Match ip dscp 5
```

Related Topics

[class-map](#), on page 846

show platform hardware fed switch

To display device-specific hardware information, use the **show platform hardware fed switch** *switch_number* command.

This topic elaborates only the QoS-specific options, that is, the options available with the **show platform hardware fed switch** {*switch_num* | **active** | **standby**} **qos** command.

```
show platform hardware fed switch {switch_num | active | standby} qos {afd | {config type type | [{asic
asic_num}] | stats clients {all | bssid id | wlanid id}} | dscp-cos counters {iifd_id id | interface type number}
| le-info | {iifd_id id | interface type number} | policer config {iifd_id id | interface type number} | queue
| {config | {iifd_id id | interface type number | internal port-type type {asic number [{port_num}]}} |
label2qmap | [{aqmrepqostbl | iqslabtable | sqslabtable}] | {asicnumber} | stats | {iifd_id id | interface
type number | internal {cpu policer | port-type type asic number} {asicnumber [{port_num}]}} | resource}
```

Syntax Description

switch {*switch_num* | **active** | **standby**}
active | **standby** } Switch for which you want to display information. You have the following options:

- *switch_num*—ID of the switch.
- **active**—Displays information relating to the active switch.
- **standby**—Displays information relating to the standby switch, if available.

qos Displays QoS hardware information. You must choose from the following options:

- **afd** —Displays Approximate Fair Drop (AFD) information in hardware.
- **dscp-cos**—Displays information dscp-cos counters for each port.
- **leinfo**—Displays logical entity information.
- **policer**—Displays QoS policer information in hardware.
- **queue**—Displays queue information in hardware.
- **resource**—Displays hardware resource information.

afd {**config type** | **stats client** } You must choose from the options under **config type** or **stats client** :

config type:

- **client**—Displays wireless client information
- **port**—Displays port-specific information
- **radio**—Displays wireless radio information
- **ssid**—Displays wireless SSID information

stats client :

- **all**—Displays statistics of all client.
- **bssid**—Valid range is from 1 to 4294967295.
- **wlanid**—Valid range is from to 1 4294967295

asicasic_num	(Optional) ASIC number. Valid range is from 0 to 255.
dscp-cos counters { iif_id <i>id</i> interface <i>type number</i> }	Displays per port dscp-cos counters. You must choose from the following options under dscp-cos counters : <ul style="list-style-type: none"> • iif_id <i>id</i>—The target interface ID. Valid range is from 1 to 4294967295. • interface <i>type number</i>—Target interface type and ID.
leinfo	You must choose from the following options under dscp-cos counters : <ul style="list-style-type: none"> • iif_id <i>id</i>—The target interface ID. Valid range is from 1 to 4294967295. • interface <i>type number</i>—Target interface type and ID.
policer config	Displays configuration information related to policers in hardware. You must choose from the following options: <ul style="list-style-type: none"> • iif_id <i>id</i>—The target interface ID. Valid range is from 1 to 4294967295. • interface <i>type number</i>—Target interface type and ID.
queue { config { iif_id <i>id</i> interface <i>type</i> <i>number</i> internal } label2qmap stats }	Displays queue information in hardware. You must choose from the following options: <ul style="list-style-type: none"> • config—Configuration information. You must choose from the following options: <ul style="list-style-type: none"> • iif_id <i>id</i>—The target interface ID. Valid range is from 1 to 4294967295. • interface <i>type number</i>—Target interface type and ID. • internal—Displays internal queue related information. • label2qmap—Displays hardware label to queue mapping information. You can choose from the following options: <ul style="list-style-type: none"> • (Optional) aqmrepqostbl— AQM REP QoS label table lookup. • (Optional) iqslabeltable—IQS QoS label table lookup. • (Optional) sqslabeltable—SQS and local QoS label table lookup. • stats—Displays queue statistics. You must choose from the following options: <ul style="list-style-type: none"> • iif_id <i>id</i>—The target interface ID. Valid range is from 1 to 4294967295. • interface <i>type number</i>—Target interface type and ID. • internal { cpu policer port_type <i>port_type</i> asic <i>asic_num</i> [port_num <i>port_num</i>] }—Displays internal queue related information.
resource	Displays hardware resource usage information. You must enter the following keyword: usage

Command Modes

User EXEC

Privileged EXEC

Command History

Release

Modification

This command was introduced.

This is an example of output from the `show platform hardware fed switch switch_number qos queue stats internal cpu policer` command

Device#`show platform hardware fed switch 3 qos queue stats internal cpu policer`

QId	PlcIdx	Queue Name	Enabled	(default) Rate	(set) Rate	Drop
0	11	DOT1X Auth	No	1000	1000	0
1	1	L2 Control	No	500	500	0
2	14	Forus traffic	No	1000	1000	0
3	0	ICMP GEN	Yes	200	200	0
4	2	Routing Control	Yes	1800	1800	0
5	14	Forus Address resolution	No	1000	1000	0
6	3	ICMP Redirect	No	500	500	0
7	6	WLESS PRI-5	No	1000	1000	0
8	4	WLESS PRI-1	No	1000	1000	0
9	5	WLESS PRI-2	No	1000	1000	0
10	6	WLESS PRI-3	No	1000	1000	0
11	6	WLESS PRI-4	No	1000	1000	0
12	0	BROADCAST	Yes	200	200	0
13	10	Learning cache ovfl	Yes	100	100	0
14	13	Sw forwarding	Yes	1000	1000	0
15	8	Topology Control	No	13000	13000	0
16	12	Proto Snooping	No	500	500	0
17	16	DHCP Snooping	No	1000	1000	0
18	9	Transit Traffic	Yes	500	500	0
19	10	RPF Failed	Yes	100	100	0
20	15	MCAST END STATION	Yes	2000	2000	0
21	13	LOGGING	Yes	1000	1000	0
22	7	Punt Webauth	No	1000	1000	0
23	10	Crypto Control	Yes	100	100	0
24	10	Exception	Yes	100	100	0
25	3	General Punt	No	500	500	0
26	10	NFL SAMPLED DATA	Yes	100	100	0
27	2	SGT Cache Full	Yes	1800	1800	0
28	10	EGR Exception	Yes	100	100	0
29	16	Show frwd	No	1000	1000	0
30	9	MCAST Data	Yes	500	500	0
31	10	Gold Pkt	Yes	100	100	0

show platform software fed switch qos

To display device-specific software information, use the **show platform hardware fed switch** *switch_number* command.

This topic elaborates only the QoS-specific options available with the **show platform software fed switch** {*switch_num* | **active** | **standby** } **qos** command.

show platform software fed switch{*switch number* | **active** | **standby**}**qos**{**avc** | **internal** | **label2qmap** | **nflqos** | **policer** | **policy** | **qsb** | **tablemap** | **wireless**}

Syntax Description

switch {*switch_num* | **active** | **standby** }
 • *switch_num*—Enter the switch ID. Displays information for the specified switch.
 • **active**—Displays information for the active switch.
 • **standby**—Displays information for the standby switch, if available.

qos Displays QoS software information. Choose one the following options:
 • **avc** —Displays Application Visibility and Control (AVC) QoS information.
 • **internal**—Displays internal queue-related information.
 • **label2qmap**—Displays label to queue map table information.
 • **nflqos**—Displays NetFlow QoS information.
 • **policer**—Displays QoS policer information in hardware.
 • **policy**—Displays QoS policy information.
 • **qsb**—Displays QoS sub-block information.
 • **tablemap**—Displays table mapping information for QoS egress and ingress queues.
 • **wireless**—Displays wireless QoS information.

Command Modes

User EXEC

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Denali 16.1.1	This command was introduced.

show platform software fed switch qos qsb

To display QoS sub-block information, use the **show platform software fed switch *switch_number* qos qsb** command.

```
show platform software fed switch {switch_number | active | standby} qosqsb {brief | [{all | type |
client_id | port port_number | radio_type | ssidssid}]} | iif_idid | interface |
{Auto-Templateinterface_number | BDIinterface_number | Capwapinterface_number |
GigabitEthernetinterface_number | InternalInterfaceinterface_number | Loopbackinterface_number |
Nullinterface_number | Port-channelinterface_number | TenGigabitEthernetinterface_number |
Tunnelinterface_number | Vlaninterface_number}}
```

Syntax Description

switch { <i>switch_num</i> active standby }	The switch for which you want to display information. <ul style="list-style-type: none"> • <i>switch_num</i>—Enter the ID of the switch. Displays information for the specified switch. • active—Displays information for the active switch. • standby—Displays information for the standby switch, if available.
qos qsb	Displays QoS sub-block software information.

**qsb {brief | iif_id | brief
interface}**

- **all**—Displays information for all client.
- **type**—Displays qosb information for the specified target type:
 - **client**—Displays QoS qosb information for wireless clients
 - **port**—Displays port-specific information
 - **radio**—Displays QoS qosb information for wireless radios
 - **ssid**—Displays QoS qosb information for wireless networks

iif_id—Displays information for the iif_ID

interface—Displays QoS qosb information for the specified interface:

- **Auto-Template**—Auto-template interface between 1 and 999.
- **BDI**—Bridge-domain interface between 1 and 16000.
- **Capwap**—CAPWAP interface between 0 and 2147483647.
- **GigabitEthernet**—GigabitEthernet interface between 0 and 9.
- **InternalInterface**—Internal interface between 0 and 9.
- **Loopback**—Loopback interface between 0 and 2147483647.
- **Null**—Null interface 0-0
- **Port-Channel**—Port-channel interface between 1 and 128.
- **TenGigabitEthernet**—TenGigabitEthernet interface between 0 and 9.
- **Tunnel**—Tunnel interface between 0 and 2147483647.
- **Vlan**—VLAN interface between 1 and 4094.

Command Modes

User EXEC

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Denali 16.1.1	This command was introduced.

This is an example of the output for the **show platform software fed switch switch_number qos qsb** command

```
Device#sh pl so fed sw 3 qos qsb interface g3/0/2
```

```
QoS subblock information:
Name:GigabitEthernet3/0/2 iif_id:0x0000000000007b iif_type:ETHER(146)
qsb ptr:0xffd8573350
Port type = Wired port
asic_num:0 is_uplink:false init_done:true
FRU events: Active-0, Inactive-0
```

```

def_qos_label:0 def_le_priority:13
trust_enabled:false trust_type:TRUST_DSCP ifm_trust_type:1
LE priority:13 LE trans_index(in, out): (0,0)
Stats (plc,q) export counters (in/out): 0/0
Policy Info:
  Ingress Policy: pmap::{(0xffd8685180,AutoQos-4.0-CiscoPhone-Input-Policy,1083231504,,)}
    tcg::{0xffd867ad10,GigabitEthernet3/0/2 tgt(0x7b,IN) level:0 num_tccg:4 num_child:0},
status:VALID,SET_INHW
  Egress Policy: pmap::{(0xffd86857d0,AutoQos-4.0-Output-Policy,1076629088,,)}
    tcg::{0xffd8685b40,GigabitEthernet3/0/2 tgt(0x7b,OUT) level:0 num_tccg:8 num_child:0},
status:VALID,SET_INHW
  TCG(in,out):(0xffd867ad10, 0xffd8685b40) le_label_id(in,out):(2, 1)
Policer Info:
  num_ag_policers(in,out)[1r2c,2r3c]: ([0,0],[0,0])
  num_mf_policers(in,out): (0,0)
  num_afd_policers:0
  [ag_plc_handle(in,out) = (0xd8688220,0)]
  [mf_plc_handle(in,out)=(nil),(nil)] num_mf_policers:(0,0)
  base:(0xffffffff,0xffffffff) rc:(0,0)]
Queueing Info:
  def_queueing = 0, shape_rate:0 interface_rate_kbps:1000000
  Port shaper:false
  lbl_to_qmap_index:1
Physical qparams:
  Queue Config: NodeType:Physical Id:0x40000049 parent:0x40000049 qid:0 attr:0x1 defq:0

  PARAMS: Excess Ratio:1 Min Cir:1000000 QBuffer:0
  Queue Limit Type:Single Unit:Percent Queue Limit:44192
  SHARED Queue

```

show wireless client calls

To display the total number of active or rejected calls on the device, use the **show wireless client calls** command in privileged EXEC mode.

show wireless client calls { **active** | **rejected** }

Syntax Description	
active	Displays active calls.
rejected	Displays rejected calls.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **show wireless client calls** command:

```
device# show wireless client calls active
```

```
TSPEC Calls:
```

```
-----
MAC Address      AP Name          Status           WLAN  Authenticated
-----
0000.1515.000f   AP-2             Associated       1    Yes
```

```
SIP Calls:
```

```
-----
Number of Active TSPEC calls on 802.11a and 802.11b/g: 1
Number of Active SIP calls on 802.11a and 802.11b/g: 0
```

show wireless client dot11

To display the total number of active or rejected calls for a specific band (2.4 Ghz or 5 Ghz), use the **show wireless client dot11** command in privileged EXEC mode.

```
show wireless client dot11 {24ghz | 5ghz} calls {active | rejected}
```

Syntax Description		
24ghz	Displays the 802.11b/g network.	
5ghz	Displays the 802.11a network.	
calls	Displays the wireless client calls.	
active	Displays active calls.	
rejected	Displays rejected calls.	

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **show wireless client dot11** command:

```
Device# show wireless client dot11 5ghz calls active

  TSPEC Calls:
  -----

  SIP Calls:
  -----
Number of Active TSPEC calls on 802.11a: 0
Number of Active SIP calls on 802.11a: 0
```

show wireless client mac-address (Call Control)

To view call control information related to clients, use the **show wireless client mac-address** command in privileged EXEC mode.

show wireless client mac-address *mac-address* **call-control call-info**

Syntax Description	
<i>mac-address</i>	The client MAC address.
call-control call-info	Displays the call control and IP-related information about a client.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display call control and IP-related information about a client:

```
Device# show wireless client mac-address 30e4.db41.6157 call-control call-info
Client MAC Address      : 30E4DB416157

Call 1 Statistics

Uplink IP Address      : 209.165.200.225
Downlink IP Address    : 209.165.200.226
Uplink Port            : 29052
Downlink Port          : 27538
Call ID                : c40acb4d-3b3b0.3d27da1e-356bed03
Called Party           : sip:1011
Calling Party          : sip:1012
Priority                : 6
Call On Hold           : false
Call Duration          : 30

Call 2 Statistics

No Active Call
```

show wireless client mac-address (TCLAS)

To view information about TCLAS and user priority, use the **show wireless client mac-address** command in privileged EXEC mode.

show wireless client mac-address *mac-address* **tclas**

Syntax Description	
<i>mac-address</i>	The client MAC address.
tclas	Displays TCLAS and user priority-related information about a client.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display the TCLAS and user priority-related information about a client:

```
Device# show wireless client mac-address 30e4.db41.6157 tclas
MAC Address      UP TID Mask Source IP Addr  Dest IP Addr  SrcPort DstPort Proto
-----
30e4.db41.6157   4  4  95 167838052      2164326668    5060     5060     6
30e4.db41.6157   6  1  31 0              2164326668    0        27538    17
```

show wireless client voice diagnostics

To display wireless client voice diagnostic parameters, use the **show wireless client voice diagnostics** command in privileged EXEC mode.

show wireless client voice diagnostics { qos-map | roam-history | rssi | status | tspec }

Syntax Description

qos-map	Displays information about the QoS and DSCP mapping and packet statistics in each of the four queues: VO, VI, BE, BK. The different DSCP values are also displayed.
roam-history	Displays information about the last 3 roaming histories for each known client. The output contains the timestamp, access point associated with roaming, roaming reason, and if there is a roaming failure, a reason for the roaming failure.
rssi	Displays the client's RSSI values in the last 5 seconds when voice diagnostics are enabled.
status	Displays status of voice diagnostics for clients.
tspec	Displays voice diagnostics that are enabled for TSPEC clients.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

Debug voice diagnostics must be enabled for voice diagnostics to work.

The following is sample output from the **show wireless client voice diagnostics status** command:

```
Device# show wireless client voice diagnostics status
Voice Diagnostics Status: FALSE
```

show policy-map

To display quality of service (QoS) policy maps, which define classification criteria for incoming traffic, use the **show policy-map** command in EXEC mode.

```
show policy-map [{policy-map-name | interface interface-id}]
```

```
show policy-map interface {Auto-template | Capwap | GigabitEthernet | GroupVI |
InternalInterface | Loopback | Lspvif | Null | Port-channel | TenGigabitEthernet | Tunnel
| Vlan | brief | class | input | output}
```

```
show policy-map type control subscriber detail
```

```
show policy-map interface wireless { ap name ap_name | client mac mac_address | radio type {24ghz
| 5ghz} ap name ap_name | ssid name ssid_name { ap name ap_name | radio type {24ghz |
5ghz} ap name ap_name } }
```

Syntax Description		
	<i>policy-map-name</i>	(Optional) Name of the policy-map.
	interface <i>interface-id</i>	(Optional) Displays the statistics and the configurations of the input and output policies that are attached to the interface.
	type control subscriber detail	(Optional) Identifies the type of QoS policy and the statistics.
	ap name <i>ap_name</i>	Displays SSID policy configuration of an access point.
	client mac <i>mac_address</i>	Displays information about the policies for all the client targets.
	radio type { 24ghz 5ghz }	Displays policy configuration of the access point in the specified radio type.
	ssid name <i>ssid_name</i>	Displays policy configuration of an SSID.

Command Modes	
	User EXEC
	Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
	Cisco IOS XE 3.3SE	The interface <i>interface-id</i> keyword was added.

Usage Guidelines	
	Policy maps can include policers that specify the bandwidth limitations and the action to take if the limits are exceeded.



Note	
	Though visible in the command-line help string, the control-plane , session , and type keywords are not supported, and the statistics shown in the display should be ignored.

This is an example of the output for the **show policy-map interface** command.

```
Device# show policy-map interface gigabitethernet1/0/48GigabitEthernet1/0/48

Service-policy output: port_shape_parent

Class-map: class-default (match-any)
  191509734 packets
  Match: any
  Queueing

  (total drops) 524940551420
  (bytes output) 14937264500
  shape (average) cir 250000000, bc 2500000, be 2500000
  target shape rate 250000000

Service-policy : child_trip_play

  queue stats for all priority classes:
    Queueing
    priority level 1

    (total drops) 524940551420
    (bytes output) 14937180648

  queue stats for all priority classes:
    Queueing
    priority level 2

    (total drops) 0
    (bytes output) 0

Class-map: dscp56 (match-any)
  191508445 packets
  Match: dscp cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Priority: Strict,

  Priority Level: 1
  police:
    cir 10 %
    cir 25000000 bps, bc 781250 bytes
    conformed 0 bytes; actions: >>>>counters not supported
    transmit
    exceeded 0 bytes; actions:
    drop
    conformed 0000 bps, exceeded 0000 bps >>>>counters not supported
```

Related Topics

[policy-map](#), on page 853

show wlan

To view WLAN parameters, use the **show wlan** command.

```
show wlan {all | id wlan-id | name wlan-name | summary}
```

Syntax Description	all	Displays a summary of parameters of all configured WLANs. The list is ordered by the ascending order of the WLAN IDs.
	id <i>wlan-id</i>	Specifies the wireless LAN identifier. The range is from 1 to 512.
	name <i>wlan-name</i>	Specifies the WLAN profile name. The name is from 1 to 32 characters.
	summary	Displays a summary of the parameters configured on a WLAN.
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display a summary of the WLANs configured on the device:

```
Device# show wlan summary
Number of WLANs: 1
```

WLAN Profile Name	SSID	VLAN	Status
45 test-wlan	test-wlan-ssid	1	UP

This example shows how to display a summary of parameters configured on a particular WLAN:

```
Device# show wlan name test-wlan
WLAN Identifier           : 45
Profile Name              : test-wlan
Network Name (SSID)      : test-wlan-ssid
Status                    : Enabled
Broadcast SSID            : Enabled
Maximum number of Associated Clients : 0
AAA Policy Override       : Disabled
Network Admission Control
  NAC-State                : Disabled
Number of Active Clients  : 0
Exclusionlist Timeout     : 60
Session Timeout           : 1800 seconds
CHD per WLAN              : Enabled
Webauth DHCP exclusion   : Disabled
Interface                 : default
Interface Status         : Up
```

```

Multicast Interface                : test
WLAN IPv4 ACL                     : test
WLAN IPv6 ACL                     : unconfigured
DHCP Server                       : Default
DHCP Address Assignment Required  : Disabled
DHCP Option 82                   : Disabled
DHCP Option 82 Format             : ap-mac
DHCP Option 82 Ascii Mode        : Disabled
DHCP Option 82 Rid Mode          : Disabled
QoS Service Policy - Input
  Policy Name                     : unknown
  Policy State                    : None
QoS Service Policy - Output
  Policy Name                     : unknown
  Policy State                    : None
QoS Client Service Policy
  Input Policy Name               : unknown
  Output Policy Name              : unknown
WifiDirect                       : Disabled
WMM                               : Disabled
Channel Scan Defer Priority:
  Priority (default)              : 4
  Priority (default)              : 5
  Priority (default)              : 6
Scan Defer Time (msecs)          : 100
Media Stream Multicast-direct    : Disabled
CCX - AironetIe Support          : Enabled
CCX - Gratuitous ProbeResponse (GPR) : Disabled
CCX - Diagnostics Channel Capability : Disabled
Dot11-Phone Mode (7920)         : Invalid
Wired Protocol                   : None
Peer-to-Peer Blocking Action     : Disabled
Radio Policy                     : All
DTIM period for 802.11a radio    : 1
DTIM period for 802.11b radio    : 1
Local EAP Authentication         : Disabled
Mac Filter Authorization list name : Disabled
Accounting list name             : Disabled
802.1x authentication list name  : Disabled
Security
  802.11 Authentication           : Open System
  Static WEP Keys                 : Disabled
  802.1X                          : Disabled
  Wi-Fi Protected Access (WPA/WPA2)
    WPA (SSN IE)                  : Disabled
    WPA2 (RSN IE)                 : Enabled
    TKIP Cipher                   : Disabled
    AES Cipher                     : Enabled
    Auth Key Management
      802.1x                      : Enabled
      PSK                          : Disabled
      CCKM                        : Disabled
  IP Security                     : Disabled
  IP Security Passthru            : Disabled
  L2TP                           : Disabled
  Web Based Authentication        : Disabled
  Conditional Web Redirect        : Disabled
  Splash-Page Web Redirect       : Disabled
  Auto Anchor                     : Disabled
  Sticky Anchoring                : Enabled
  Cranite Passthru                : Disabled
  Fortress Passthru               : Disabled
  PPTP                            : Disabled
  Infrastructure MFP protection   : Enabled

```

```
Client MFP : Optional
Webauth On-mac-filter Failure : Disabled
Webauth Authentication List Name : Disabled
Webauth Parameter Map : Disabled
Tkip MIC Countermeasure Hold-down Timer : 60
Call Snooping : Disabled
Passive Client : Disabled
Non Cisco WGB : Disabled
Band Select : Disabled
Load Balancing : Disabled
IP Source Guard : Disabled
Netflow Monitor : test
    Direction : Input
    Traffic : Datalink

Mobility Anchor List
IP Address
-----
```

trust device

To configure trust for supported devices connected to an interface, use the **trust device** command in interface configuration mode. Use the **no** form of this command to disable trust for the connected device.

```
trust device {cisco-phone | cts | ip-camera | media-player}
no trust device {cisco-phone | cts | ip-camera | media-player}
```

Syntax Description		
cisco-phone	Configures a Cisco IP phone	
cts	Configures a Cisco TelePresence System	
ip-camera	Configures an IP Video Surveillance Camera (IPVSC)	
media-player	Configures a Cisco Digital Media Player (DMP)	
Command Default	Trust disabled	
Command Modes	Interface configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines Use the **trust device** command on the following types of interfaces:

- **Auto**— auto-template interface
- **Capwap**—CAPWAP tunnel interface
- **GigabitEthernet**—Gigabit Ethernet IEEE 802
- **GroupVI**—Group virtual interface
- **Internal Interface**—Internal interface
- **Loopback**—Loopback interface
- **Null**—Null interface
- **Port-channel**—Ethernet Channel interface
- **TenGigabitEthernet**—10-Gigabit Ethernet
- **Tunnel**—Tunnel interface
- **Vlan**—Catalyst VLANs
- **range**—**interface range** command

Example

The following example configures trust for a Cisco IP phone in Interface GigabitEthernet 1/0/1:

```
Device(config)# interface GigabitEthernet1/0/1  
Device(config-if)# trust device cisco-phone
```

You can verify your settings by entering the **show interface status** privileged EXEC command.



PART **XII**

Radio Resource Management

- [Radio Resource Management Commands, on page 899](#)



Radio Resource Management Commands

- [airtime-fairness dot11 mode \(apgroup\)](#), on page 901
- [airtime-fairness dot11 optimization \(apgroup\)](#), on page 902
- [airtime-fairness dot11 policy](#), on page 903
- [airtime-fairness policy \(wlan\)](#), on page 904
- [ap dot11 rrm](#), on page 905
- [ap dot11 rrm ccx](#), on page 908
- [ap dot11 rrm channel](#), on page 909
- [ap dot11 24ghz rrm channel cleanair-event rogue-contribution](#), on page 910
- [ap dot11 24ghz or 5ghz rrm channel dca add](#), on page 911
- [ap dot11 24ghz or 5ghz rrm channel dca remove](#), on page 912
- [ap dot11 5ghz rrm channel dca chan-width-11n](#), on page 913
- [ap dot11 rrm coverage](#), on page 914
- [ap dot11 rrm group-member](#), on page 916
- [ap dot11 rrm monitor](#), on page 917
- [ap dot11 rrm profile](#), on page 918
- [ap dot11 rrm tpc-threshold](#), on page 919
- [ap dot11 rrm txpower](#), on page 920
- [ap dot11 airtime-fairness mode](#), on page 921
- [ap dot11 airtime-fairness policy-name](#), on page 922
- [ap name dot11 airtime-fairness mode](#), on page 924
- [ap name dot11 airtime-fairness optimization](#), on page 925
- [ap name no dot11 airtime-fairness wlan-name policy-name](#), on page 926
- [ap name dot11 airtime-fairness wlan-name policy](#), on page 927
- [no ap dot11 airtime-fairness policy-name](#), on page 928
- [clear wireless airtime-fairness statistics](#), on page 929
- [show ap dot11 24ghz](#), on page 930
- [show ap dot11 5ghz](#), on page 932
- [show ap airtime-fairness \(per radio\)](#), on page 934
- [show ap dot11 airtime-fairness \(radio bands\)](#), on page 935
- [show ap name dot11 airtime-fairness summary](#), on page 936
- [show ap airtime-fairness \(ap\)](#), on page 937
- [show ap airtime-fairness policy \(all\)](#), on page 938
- [show ap name dot11 airtime-fairness policy statistics](#), on page 939

- [show ap airtime-fairness wlan](#), on page 940
- [show ap name dot11 airtime-fairness wlan name statistics](#), on page 941
- [show ap airtime-fairness ap-group](#), on page 942

airtime-fairness dot11 mode (apgroup)

To configure ATF for an AP group, use the **airtime-fairness dot11 mode** command in ap group submode. Use the **no** form of the command to disable ATF for a AP group.

```
airtime-fairness dot11 {24ghz | 5ghz} mode {enforce-policy | monitor}
```

```
no airtime-fairness dot11 {24ghz | 5ghz} mode {enforce-policy | monitor}
```

Syntax Description		
24ghz		Configures 802.11b parameters
5ghz		Configures 802.11a parameters
enforce-policy		Configure airtime-fairness in enforce-policy mode
monitor		Configure airtime-fairness in monitor mode

Command Default None

Command Modes config apgroup

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines None

This example shows how to configure ATF for an AP group.

```
Device#configure terminal
Deviceconfig# ap group testap
Deviceconfig-apgroup# airtime-fairness dot11 24ghz mode monitor
```

airtime-fairness dot11 optimization (apgroup)

To configure ATF optimization for an AP group, use the **airtime-fairness dot11 optimization** command. Use the **no** form of the command to disable ATF for a AP group

airtime-fairness dot11 {24ghz | 5ghz} optimization

no airtime-fairness dot11 {24ghz | 5ghz} optimization

Syntax Description	24ghz	Configures 802.11b parameters
	5ghz	Configures 802.11a parameters
Command Default	None	
Command Modes	config apgroup	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.
Usage Guidelines	None	

This example shows how to configure ATF optimization for an AP group.

```
Device#configure terminal
Deviceconfig# ap group testap
Deviceconfig-apgroup# airtime-fairness dot11 24ghz optimization
```

airtime-fairness dot11 policy

To override a globally applied policy on a WLAN AP group, use the **airtime-fairness dot11 policy** command. Use the **no** form of the command to disable applied policy override.

airtime-fairness dot11 {24ghz | 5ghz} **policy** *policy-name*

no airtime-fairness dot11 {24ghz | 5ghz} **policy** *policy-name*

Syntax Description	24ghz	Configures 2.4 GHz airtime-fairness policy
	5ghz	Configures 5 GHz airtime-fairness policy
	<i>policy-name</i>	name of the airtime-fairness policy to assign

Command Default None

Command Modes config wlan apgroup

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines None

This example shows how to override applied policy on a WLAN AP group.

```
Deviceconfig#ap group testapgroup
Device(config-apgroup)# wlan testwlan
Device(config-wlan-apgroup)# airtime-fairness dot11 24ghz policy testpolicy
```

airtime-fairness policy (wlan)

To configure the ATF policy for a WLAN, use the **airtime-fairness policy** command.

airtime-fairness policy *policy-name*

Syntax Description	<i>policy-name</i>	Enter the policy name
Command Default	None	
Command Modes	config wlan	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.
Usage Guidelines	None	

This example shows how to configure the ATF policy for a WLAN.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#wlan wlan-name
Device(config-wlan)#airtime-fairness policy policy-name
```

ap dot11 rrm

To configure basic and advanced radio resource management settings for 802.11 devices, use the **ap dot11 rrm** command.

```
ap dot11 {24ghz|5ghz} rrm {ccx location-measurement sec | channel {cleanair-event | dca | device
| foreign | load | noise | outdoor-ap-dca} | coverage {data fail-percentage pct | data packet-count
count | data rssi-threshold threshold} | exception global percentage | level global number | voice
{fail-percentage percentage | packet-count number | rssi-threshold threshold}}
```

Syntax Description		
ccx		Configures Advanced (RRM) 802.11 CCX options.
location-measurement		Specifies 802.11 CCX Client Location Measurements in seconds. The range is between 10 and 32400 seconds.
channel		Configure advanced 802.11-channel assignment parameters.
cleanair-event		Configures cleanair event-driven RRM parameters.
dca		Configures 802.11-dynamic channel assignment algorithm parameters.
device		Configures persistent non-WiFi device avoidance in the 802.11-channel assignment.
foreign		Enables foreign AP 802.11-interference avoidance in the channel assignment.
load		Enables Cisco AP 802.11-load avoidance in the channel assignment.
noise		Enables non-802.11-noise avoidance in the channel assignment.
outdoor-ap-dca		Configures 802.11 DCA list option for outdoor AP.
coverage		Configures 802.11 coverage Hole-Detection.

data fail-percentage <i>pct</i>	Configures 802.11 coverage failure-rate threshold for uplink data packets. The range is between 1 and 100
data packet-count <i>count</i>	Configures 802.11 coverage minimum-failure-count threshold for uplinkdata packets.
data rssi-threshold <i>threshold</i>	Configures 802.11 minimum-receive-coverage level for voice packets.
exception global <i>percentage</i>	Configures 802.11 Cisco APs coverage-exception level. The range is between 0 and 100 percent.
level global <i>number</i>	Configures 802.11 Cisco AP client-minimum-exception level between 1 and 75 clients.
voice	Configures 802.11 coverage Hole-Detection for voice packets.
fail-percentage <i>percentage</i>	Configures 802.11 coverage failure rate threshold for uplink voice packets.
packet-count <i>number</i>	Configures 802.11 coverage minimum-uplink-failure count threshold for voice packets.
rssi-threshold <i>threshold</i>	Configures 802.11 minimum receive coverage level for voice packets.

Command Default Disabled

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines This command applies for both 802.11a and 802.11b bands. But the appropriate commands must be chosen for configuring the parameter.

This example shows how to configure various RRM settings.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#ap dot11 5ghz rrm ?
```

ccx	Configure Advanced(RRM) 802.11a CCX options
channel	Configure advanced 802.11a channel assignment parameters
coverage	802.11a Coverage Hole Detection
group-member	Configure members in 802.11a static RF group
group-mode	802.11a RF group selection mode
logging	802.11a event logging
monitor	802.11a statistics monitoring
ndp-type	Neighbor discovery type Protected/Transparent
profile	802.11a performance profile
tpc-threshold	Configures the Tx Power Control Threshold used by RRM for auto power assignment
txpower	Configures the 802.11a Tx Power Level

ap dot11 rrm ccx

To configure radio resource management CCX options for 2.4 GHz and 5GHz devices, use the **ap dot11 rrm ccx** command.

```
ap dot11 {24ghz | 5ghz} rrm ccx location-measurement interval
```

Syntax Description	location-measurement interval Specifies the CCX client-location measurement interval value. The range is between 10 and 32400 seconds.				
Command Default	None.				
Command Modes	Interface configuration.				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				
Usage Guidelines	None.				

This example shows how to set CCX location-measurement interval for a 5-GHz device.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#ap dot11 5ghz rrm ccx location-measurement 10
```

ap dot11 rrm channel

To enable radio resource management channel for 2.4 GHz and 5GHz devices, use the **ap dot11 rrm channel** command. To disable the radio resource management for 2.4 GHz and 5 GHz devices, use the **no** form of the command.

```
ap dot11 {24ghz | 5ghz} rrm channel {cleanair-event | dca | device | foreign | load | noise}
no ap dot11 {24ghz | 5ghz} rrm channel {cleanair-event | dca | device | foreign | load | noise}
```

Syntax Description	Parameter	Description
	cleanair-event	Specifies the cleanair event-driven RRM parameters
	dca	Specifies the 802.11 dynamic channel assignment algorithm parameters
	device	Specifies the persistent non-WiFi device avoidance in the 802.11-channel assignment.
	foreign	Enables foreign AP 802.11-interference avoidance in the channel assignment.
	load	Enables Cisco AP 802.11-load avoidance in the channel assignment.
	noise	Enables non-802.11-noise avoidance in the channel assignment.

Command Default None.

Command Modes Interface configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

This example shows all the parameters available for **Channel**.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#ap dot11 24ghz rrm channel ?
  cleanair-event  Configure cleanair event-driven RRM parameters
  dca             Config 802.11b dynamic channel assignment algorithm
                 parameters
  device         Configure persistent non-WiFi device avoidance in the 802.11b
                 channel assignment
  foreign        Configure foreign AP 802.11b interference avoidance in the
                 channel assignment
  load           Configure Cisco AP 802.11b load avoidance in the channel
                 assignment
  noise          Configure 802.11b noise avoidance in the channel assignment
```

ap dot11 24ghz rrm channel cleanair-event rogue-contribution

To configure cleanair event driven Radio Resource Management (RRM) rogue contribution parameters, use the `ap dot11 24ghz rrm channel cleanair-event rogue-contribution` command.

`ap dot11 24ghz rrm channel cleanair-event rogue-contribution duty-cycle threshold-value`

Syntax Description	Parameter	Description
	<code>duty-cycle</code>	Sets event-driven RRM rogue contribution duty cycle.
	<code>threshold-value</code>	Custom ED-RRM rogue contribution duty cycle threshold value. Valid value ranges from 1 -99 percent.

Command Default The rogue contribution duty cycle is not set.

Command History	Release	Modification
	16.1	This command was introduced.

Usage Guidelines This command sets event-driven RRM rogue contribution duty cycle.

Example

This example shows how to configure cleanair event driven RRM rogue contribution parameters:

```
Cisco Controller(config)# ap dot11 24ghz rrm channel cleanair-event rogue-contribution
duty-cycle 1
```

ap dot11 24ghz or 5ghz rrm channel dca add

To add non-default radio resource management DCA channels to the DCA channel list for 2.4 GHz or 5 GHz devices, use the **ap dot11 {24ghz | 5ghz} rrm channel dca add** command. To remove a default channel from the DCA list, use the **no** form of the command. The DCA channel list contains standard channels matching your country of operation. For example, a regulatory default channel list contains channels 1, 6, and 11.

```
ap dot11 [{24ghz|5ghz}] rrm channel dca add number
no ap dot11 [{24ghz|5ghz}] rrm channel dca add number
```

Syntax Description	<i>number</i>	DCA channel number.
---------------------------	---------------	---------------------

Command Default	None.
------------------------	-------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

This example shows how to add a non-default radio resource management DCA channel to the DCA list for a 2.4 GHz device, using the **ap dot11 24ghz rrm channel dca add 10** command:

```
Device(config)# ap dot11 24ghz rrm channel dca add 10
```

ap dot11 24ghz or 5ghz rrm channel dca remove

To remove a default radio resource management DCA channels from the DCA channel list for 2.4 GHz or 5 GHz devices, use the **ap dot11 {24ghz | 5ghz} rrm channel dca remove *number*** command. To add a default DCA channel back to the DCA channel list, use the **no** form of the command.

```
ap dot11 [{24ghz|5ghz}] rrm channel dca remove number
no ap dot11 [{24ghz|5ghz}] rrm channel dca remove number
```

Syntax Description	<i>number</i>	Specifies the radio resource management DCA channel.
---------------------------	---------------	--

Command Default	None.
------------------------	-------

Command Modes	Global configuration.
----------------------	-----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

This example shows how to remove default radio resource management DCA channel from the DCA list for a 2.4 GHz device, using the **ap dot11 24ghz rrm channel dca remove** command:

```
Device(config)#ap dot11 24ghz rrm channel dca remove 11
```

ap dot11 5ghz rrm channel dca chan-width-11n

To configure DCA channel width for all 802.11n radios in the 5-GHz band, enter the **ap dot11 5ghz rrm channel dca chan-width-11n** *width* command. To disable DCA channel width for all 802.11n radios in the 5-GHz band, use the **no** form of the command.

```
ap dot11 5ghzrrm channel dca chan-width-11n { 20 | 40 }
noap dot11 5ghzrrm channel dca chan-width-11n { 20 | 40 }
```

Syntax Description	chan-width-11n	Specifies DCA channel width for all 802.11n radios in the 5-GHz band.
	20	Sets the channel width for 802.11n radios to 20 MHz.
	40	Sets the channel width for 802.11n radios to 40 MHz.

Command Default The default channel width is 20.

Command Modes Global configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

This example shows how to set the channel width for the 802.11n radios to 40 MHz, using the **ap dot11 5ghz rrm channel dca chan-width-11n** command:

```
Device(config)#ap dot11 5ghz rrm channel dca chan-width-11n 40
```

ap dot11 rrm coverage

To enable 802.11 coverage hole detection, use the **ap dot11 rrm coverage** command.

```
ap dot11 {24ghz | 5ghz} rrm coverage [{data {fail-percentage percentage | packet-count count |
 rssi-threshold threshold} | exceptional global value | level global value | voice {fail-percentage
 percentage | packet-count packet-count | rssi-threshold threshold}]
```

Syntax Description	Parameter	Description
	data	Specifies 802.11 coverage hole-detection data packets.
	fail-percentage <i>percentage</i>	Specifies 802.11 coverage failure-rate threshold for uplink data packets. The range is between 1 and 100
	packet-count <i>count</i>	Specifies 802.11 coverage minimum-failure-count threshold for uplink data packets.
	rssi-threshold <i>threshold</i>	Specifies 802.11 minimum-receive-coverage level for voice packets.
	exceptional global <i>value</i>	Specifies 802.11 Cisco APs coverage-exception level. The range is between 0 and 100 percent.
	level global <i>value</i>	Specifies 802.11 Cisco AP client-minimum-exception level between 1 and 75 clients.
	voice	Specifies 802.11 coverage Hole-Detection for voice packets.
	fail-percentage <i>percentage</i>	Specifies 802.11 coverage failure rate threshold for uplink voice packets.
	packet-count <i>packet-count</i>	Specifies 802.11 coverage minimum-uplink-failure count threshold for voice packets.
	rssi-threshold <i>threshold</i>	Specifies 802.11 minimum receive coverage level for voice packets.

Command Default None.

Command Modes Interface configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines If you enable coverage hole-detection, the device automatically determines, based on data that is received from the access points, whether any access points have clients that are potentially located in areas with poor coverage.

If both the number and percentage of failed packets exceed the values that you entered in the **ap dot11 {24ghz | 5ghz} rrm coverage packet-count** and **ap dot11 {24ghz | 5ghz} rrm coverage fail-percentage** commands for a 5-second period, the client is considered to be in a pre-alarm condition. The device uses this information to distinguish between real and false coverage holes and excludes clients with poor roaming logic. A coverage hole is detected if both the number and percentage of failed clients meet or exceed the values entered in the

ap dot11 {24ghz | 5ghz} rrm coverage level-global and **ap dot11 {24ghz | 5ghz} rrm coverage exceptional-global** commands over a 90-second period. The device determines whether the coverage hole can be corrected and, if appropriate, mitigate the coverage hole by increasing the transmit power level for that specific access point.

This example shows how to set the RSSI-threshold for data in 5-GHz band.

```
Device#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
Device(config)#ap dot11 5ghz rrm coverage data rssi-threshold -80
```

ap dot11 rrm group-member

To configure members in 802.11 static RF group, use the **ap dot11 rrm group-member** command. To remove the member, use the **no** form of the command.

```
ap dot11 {24ghz | 5ghz} rrm group-member controller-name controller-ip
no ap dot11 {24ghz | 5ghz} rrm group-member controller-name controller-ip
```

Syntax Description	<i>controller-name</i>	Specifies the name of the controller to be added.
	<i>controller-ip</i>	Specifies the IP address of the controller to be added.

Command Default None.

Command Modes Interface configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

This example shows how to add a controller in the 5-GHz automatic-RF group

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#ap dot11 5ghz rrm group-member ABC 10.1.1.1
```

ap dot11 rrm monitor

To monitor the 802.11-band statistics, use the **ap dot11 rrm monitor** command. To disable, use the **no** form of the command.

```
ap dot11 {24ghz | 5ghz} rrm monitor {channel-list | {all | country | dca} | coverage | load | noise | signal}
no ap dot11 {24ghz | 5ghz} rrm monitor {channel-list | coverage | load | noise | signal}
```

Syntax Description	channel-list	Sets the 802.11 noise/interference/rogue monitoring channel-list.
	all	Specifies to monitor all the channels.
	country	Specifies to monitor channels used in configured country code
	dca	Specifies to monitor channels used by dynamic channel assignment.
	coverage	Specifies 802.11 coverage measurement interval. The range is between 60 and 3600 in seconds
	load	Specifies 802.11 load measurement interval. The range is between 60 and 3600 in seconds
	noise	Specifies 802.11 noise measurement interval (channel scan interval). The range is between 60 and 3600 in seconds
	signal	Specifies 802.11 signal measurement interval (neighbor packet frequency). The range is between 60 and 3600 in seconds

Command Default None.

Command Modes Interface Configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

This example shows how to enable monitoring all the 5-GHz band channels.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#ap dot11 5ghz rrm monitor channel-list all
```

ap dot11 rrm profile

To configure Cisco lightweight access point profile settings on supported 802.11 networks, use the **ap dot11 rrm profile** command.

```
ap dot11 {24ghz | 5ghz} rrm profile {customize | foreign value | noise value | throughput value | utilization value}
```

Syntax Description

customize	Enables performance profiles.
foreign value	Specifies the 802.11 foreign 802.11 interference threshold value. The range is between 0 and 100 percent.
noise value	Specifies the 802.11 foreign noise threshold value. The range is between -127 and 0 dBm
throughput value	Specifies the 802.11a Cisco AP throughput threshold value. The range is between 1000 and 10000000 bytes per second
utilization value	Specifies the 802.11a RF utilization threshold value. The range is between 0 and 100 percent

Command Default

Disabled.

Command Modes

Interface configuration.

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

None.

This example shows how to set the threshold value for the noise parameter.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#ap dot11 5ghz rrm profile noise -50
```

ap dot11 rrm tpc-threshold

To configure the tx-power control threshold used by RRM for auto power assignment, use the **ap dot11 rrm tpc-threshold** command. To disable, use the **no** form of the command.

```
ap dot11 {24ghz | 5ghz} rrm tpc-threshold value
no ap dot11 {24ghz | 5ghz} rrm tpc-threshold
```

Syntax Description	<i>value</i> Specifies the power value. The range is between -80 and -50.
---------------------------	---

Command Default	None.
------------------------	-------

Command Modes	Interface configuration.
----------------------	--------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

This example shows how to configure the tx-power control threshold used by RRM for auto power assignment.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#ap dot11 5ghz rrm tpc-threshold -60
```

ap dot11 rrm txpower

To configure the 802.11 tx-power level, use the **ap dot11 rrm txpower** command. To disable the 802.11 tx-power level, use the **no** form of the command.

```
ap dot11 {24ghz|5ghz} rrm txpower {auto|max powerLevel|min powerLevel|oncepower-level}
noap dot11 {24ghz|5ghz} rrm txpower {auto|max powerLevel|min powerLevel|oncepower-level}
```

Syntax Description

auto	Enables auto-RF.
max powerLevel	Configures maximum auto-RF tx power. The range is between -10 to -30.
min powerLevel	Configures minimum auto-RF tx power. The range is between -10 to -30.
once	Enables one-time auto-RF.

Command Default

None.

Command Modes

Interface configuration.

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.
Cisco IOS XE 3.3SE	The no form of the command is introduced.

Usage Guidelines

None.

This example shows how to enables auto-RF once.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#ap dot11 5ghz rrm txpower once
```

ap dot11 airtime-fairness mode

To enable AirTime-Fairness in Enforce policy or Monitor mode, use the **ap dot11 airtime-fairness mode** command. To disable Enforce policy or Monitor mode in AirTime Fairness, use the **no** form of the command.

ap dot11 {24ghz | 5ghz} airtime-fairness mode {enforce-policy | monitor}

no ap dot11 {24ghz | 5ghz} airtime-fairness mode {enforce-policy | monitor}

Syntax Description	24ghz	Configures 802.11b parameters
	5ghz	Configures 802.11a parameters
	enforce-policy	Configure airtime-fairness in enforce-policy mode
	monitor	Configure airtime-fairness in monitor mode

Command Default None

Command Modes Global Configuration

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines None

This example shows all the parameters available for **AirTime Fairness mode**.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#ap dot11 24ghz airtime-fairness mode ?
  enforce-policy  Configure airtime-fairness in enforce-policy mode
  monitor         Configure airtime-fairness in monitor mode
```

ap dot11 airtime-fairness policy-name

To create a new Air Time Fairness (ATF) policy, use the **ap dot11 airtime-fairness policy-name** command.

ap dot11 airtime-fairness policy-name *policy-name* *policy-id*

Syntax Description		
	<i>policy-name</i>	Enter the ATF policy name.
	<i>policy-id</i>	Enter ATF policy ID to create new policy.

Command Default None

Command Modes Global Configuration

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines All ATF policies require a policy weight value. To add the policy weight use the **policy weight** command in config-airtime-fairness policy mode. If no policy weight is added, default value of 10 is applied. For more information about adding policy weight, see [policy-weight, on page 922](#).

This example shows .

```
Device#ap dot11 airtime-fairness policy-name testpolicy 12
```

policy-weight

To apply policy weight to an Air Time Fairness (ATF) policy, use the **policy-weight** command.

policy-weight *policy-weight*

Syntax Description		
	<i>policy-weight</i>	Policy weight for ATF policy. The range is from 5 to 100. Default is 10.

Command Default None

Command Modes config-airtime-fairness policy

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines If you do not apply a policy to the WLAN, then the default policy (with ID 0) with the policy weight of 10 is applied automatically. For more information about ATF policy creation, see [ap dot11 airtime-fairness policy-name, on page 922](#).

This example shows how to apply policy weight to an ATF policy.

```
Device#ap dot11 airtime-fairness policy-name testpolicy 12
Device(config-airtime-fairness policy)# policy-weight 35
```

ap name dot11 airtime-fairness mode

To enable Air Time-Fairness in Enforce policy or Monitor mode for a specific AP, use the **ap namedot11 airtime-fairness mode** command. Use **no** form of the command to disable Air Time-Fairness from either of the two modes for a specific AP.

ap name *ap-name* **dot11** {24ghz | 5ghz} **airtime-fairness mode** {enforce-policy | monitor}

ap name *ap-name* **no dot11** {24ghz | 5ghz} **airtime-fairness mode** {enforce-policy | monitor}

Syntax Description		
	<i>ap-name</i>	Enter access point name
	24ghz	Configures 802.11b parameters
	5ghz	Configures 802.11a parameters
	enforce-policy	Configure airtime-fairness in enforce-policy mode
	monitor	Configure airtime-fairness in monitor mode

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines None

This example shows how to disable Air Time-Fairness from either enforce-policy or monitor mode for a specific AP.

```
Device# ap name testap no dot11 24ghz airtime-fairness mode
```

ap name dot11 airtime-fairness optimization

To enable ATF optimization for a specific AP, use the **ap name dot11 airtime-fairness optimization** command. Use **no** to disable ATF optimization for a specific AP.

ap name *ap-name* **dot11** {**24ghz** | **5ghz**} **airtime-fairness optimization**

ap name *ap-name* **no dot11** {**24ghz** | **5ghz**} **airtime-fairness optimization**

Syntax Description	
<i>ap-name</i>	Enter access point name
24ghz	Configures 802.11b parameters
5ghz	Configures 802.11a parameters

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows how to enable ATF optimization for a specific AP.

```
Device#ap name doctestap dot11 24ghz airtime-fairness optimization
```

ap name no dot11 airtime-fairness wlan-name policy-name

To disable the ATF policy override on WLAN specific to a WLAN, use the **ap name no dot11 airtime-fairness wlan-name** command.

ap name *ap-name* **no dot11** {24ghz | 5ghz} **airtime-fairness wlan-name** *wlan-name*

Syntax Description		
	<i>ap-name</i>	Enter access point name
	24ghz	Configures 802.11b parameters
	5ghz	Configures 802.11a parameters
	wlan-name	Configure the airtime-fairness policy for this WLAN under Cisco AP
	<i>wlan-name</i>	Enter the wlan profile name

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines None

This example shows how to disable ATF policy override on WLAN specific to a WLAN .

```
Device#ap name testap no dot11 24ghz airtime-fairness wlan-name testwlan
```

ap name dot11 airtime-fairness wlan-name policy

To override the ATF policy on WLAN specific to one AP, use the **ap name dot11 airtime-fairness wlan-name policy-name** command.

```
ap name ap-name dot11 {24ghz | 5ghz} airtime-fairness wlan-name wlan-name policy-name policy-name
```

Syntax Description		
	<i>ap-name</i>	Access Point name
	24ghz	Configures 802.11b parameters
	5ghz	Configures 802.11a parameters
	wlan-name	Configure the airtime-fairness policy for this wlan under Cisco
	<i>wlan-name</i>	Enter the wlan profile name
	policy-name	Configure airtime-fairness policy
	<i>policy-name</i>	Enter the airtime-fairness profile name

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines None

This example shows how to override the ATF policy on WLAN specific to one AP.

```
Device# ap name testap dot11 24ghz airtime-fairness wlan-name testwlan policy-name testpolicy
```

no ap dot11 airtime-fairness policy-name

To delete a AirTime Fairness policy, use the **no ap dot11 airtime-fairness policy-name** command.

no ap dot11 airtime-fairness policy-name *policy-name*

Syntax Description	<i>policy-name</i>	Enter the airtime-fairness policy name
---------------------------	--------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines	None
-------------------------	------

This example shows how to delete a AirTime Fairness policy.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device# no ap dot11 airtime-fairness policy-name testpol
```

clear wireless airtime-fairness statistics

To clear the wireless airtime-fairness statistics, use the **clear wireless airtime-fairness statistics** command.

clear clear wireless airtime-fairness statistics

Syntax Description	airtime-fairness	Clears the airtime-fairness statistics
---------------------------	-------------------------	--

Command Default	None
------------------------	------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows how to clear the wireless airtime-fairness statistics.

```
Device#clear wireless airtime-fairness statistics
```

show ap dot11 24ghz

To display the 2.4 GHz RRM parameters, use the **show ap dot11 24ghz** command.

show ap dot11 24ghz {**ccx** | **channel** | **coverage** | **group** | **l2roam** | **logging** | **monitor** | **profile** | **receiver** | **summary** | **txpower**}

Syntax Description

ccx	Displays the 802.11b CCX information for all Cisco APs.
channel	Displays the configuration and statistics of the 802.11b channel assignment.
coverage	Displays the configuration and statistics of the 802.11b coverage.
group	Displays the configuration and statistics of the 802.11b grouping.
l2roam	Displays 802.11b l2roam information.
logging	Displays the configuration and statistics of the 802.11b event logging.
monitor	Displays the configuration and statistics of the 802.11b monitoring.
profile	Displays 802.11b profiling information for all Cisco APs.
receiver	Displays the configuration and statistics of the 802.11b receiver.
summary	Displays the configuration and statistics of the 802.11b Cisco APs.
txpower	Displays the configuration and statistics of the 802.11b transmit power control.

Command Default

None.

Command Modes

Global configuration.

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

None.

This example shows how to display configuration and statistics of the 802.11b coverage.

```
Device#show ap dot11 24ghz coverage
```

```
Coverage Hole Detection
 802.11b Coverage Hole Detection Mode      : Enabled
 802.11b Coverage Voice Packet Count      : 100 packet(s)
 802.11b Coverage Voice Packet Percentage : 50%
 802.11b Coverage Voice RSSI Threshold    : -80 dBm
 802.11b Coverage Data Packet Count       : 50 packet(s)
 802.11b Coverage Data Packet Percentage  : 50%
 802.11b Coverage Data RSSI Threshold     : -80 dBm
```

```
802.11b Global coverage exception level      : 25 %  
802.11b Global client minimum exception level : 3 clients
```

show ap dot11 5ghz

To display the 5GHz RRM parameters, use the **show ap dot11 5ghz** command.

show ap dot11 5ghz {ccx | channel | coverage | group | l2roam | logging | monitor | profile | receiver | summary | txpower}

Syntax Description	
ccx	Displays the 802.11a CCX information for all Cisco APs.
channel	Displays the configuration and statistics of the 802.11a channel assignment.
coverage	Displays the configuration and statistics of the 802.11a coverage.
group	Displays the configuration and statistics of the 802.11a grouping.
l2roam	Displays 802.11a l2roam information.
logging	Displays the configuration and statistics of the 802.11a event logging.
monitor	Displays the configuration and statistics of the 802.11a monitoring.
profile	Displays 802.11a profiling information for all Cisco APs.
receiver	Displays the configuration and statistics of the 802.11a receiver.
summary	Displays the configuration and statistics of the 802.11a Cisco APs.
txpower	Displays the configuration and statistics of the 802.11a transmit power control.

Command Default None.

Command Modes Global configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

This example shows configuration and statistics of 802.11a channel assignment.

```
Device#show ap dot11 5ghz channel
```

```
Automatic Channel Assignment
Channel Assignment Mode           : AUTO
Channel Update Interval          : 12 Hours
Anchor time (Hour of the day)    : 20
Channel Update Contribution       : SNI..
Channel Assignment Leader         : web (9.9.9.2)
Last Run                          : 16534 seconds ago
DCA Sensitivity Level             : MEDIUM (15 dB)
DCA 802.11n Channel Width        : 40 Mhz
```

```
Channel Energy Levels
  Minimum           : unknown
  Average           : unknown
  Maximum           : unknown
Channel Dwell Times
  Minimum           : unknown
  Average           : unknown
  Maximum           : unknown
802.11a 5 GHz Auto-RF Channel List
Allowed Channel List      : 36,40,44,48,52,56,60,64,149,153,1
                          57,161
Unused Channel List      : 100,104,108,112,116,132,136,140,1
                          65
802.11a 4.9 GHz Auto-RF Channel List
Allowed Channel List      :
Unused Channel List      : 1,2,3,4,5,6,7,8,9,10,11,12,13,14,
                          15,16,17,18,19,20,21,22,23,24,25,26
DCA Outdoor AP option    : Disabled
```

show ap airtime-fairness (per radio)

To view AP list with Air Time Fairness configuration per radio, use the **show ap airtime-fairness** command.

show ap airtime-fairness

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows AP list with AirTime-Fairness per radio.

```
Device#show ap airtime-fairness
```

show ap dot11 airtime-fairness (radio bands)

To view AP list with ATF configured radio bands, use the `show ap dot11 airtime-fairness` command.

```
show ap dot11 {24ghz | 5ghz} airtime-fairness
```

Syntax Description	24ghz	Show 802.11b configuration
	5ghz	Show 802.11a configuration
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1 This command was introduced.	
Usage Guidelines	None	

This example shows how to view AP list with ATF configured radio bands.

```
Device#show ap dot 24ghz airtime-fairness
```

show ap name dot11 airtime-fairness summary

To view the ATF statistics for a specific AP, use the **show ap name dot11 airtime-fairness summary** command.

show ap name *ap-name* dot11 {24ghz | 5ghz} airtime-fairness summary

Syntax Description		
	<i>ap-name</i>	Display the stats of 24GHz 5GHz airtime-fairness
	24ghz	Show 802.11b configuration
	5ghz	Show 802.11a configuration

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines None

This example shows how to view the ATF statistics for a specific AP.

```
Device#show ap ame testap dot11 24ghz airtime-fairness summary
```

show ap airtime-fairness (ap)

To view ATF configuration for a specific AP, use the **show ap airtime-fairness** command.

show ap name*ap-name* **airtime-fairness**

Syntax Description	<i>ap-name</i>	Enter access point name
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows how to view ATF configuration for a specific AP.

```
Device# show ap name testap airtime-fairness
```

show ap airtime-fairness policy (all)

To view all configured policies, use the **show ap airtime-fairness policy** command.

show ap airtime-fairness policy

Syntax Description	policy	Shows Airtime Fairness policy information
--------------------	--------	---

Command Default	Privileged EXEC
-----------------	-----------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows all the configured airtime-fairness policies.

```
Device#show ap airtime-fairness policy
Policy ID   Policy Name   Weight
-----
23          f             10
12          asd           10
13          pol           10
50          meaw         45
20          pocy         10
0           Default      10
```

show ap name dot11 airtime-fairness policy statistics

To view statistics for each ATF policy, use the `show ap name dot11 airtime-fairness policy statistics` command.

`show ap name ap-name dot11 {24ghz | 5hz} airtime-fairness policy policy-name statistics`

Syntax Description	<i>ap-name</i>	Enter access point name
	24ghz	Show 802.11b configuration
	5hz	Show 802.11a configuration
	<i>policy-name</i>	Enter policy name
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows how to view statistics for each ATF policy.

```
Device#show ap name testap dot11 24ghz airtime-fairness policy testpolicy statistics
```

show ap airtime-fairness wlan

To view the complete list of configured WLANs with Air Time Fairness policies applied, use the **show ap airtime-fairness wlan** command.

show ap airtime-fairness wlan

Syntax Description	wlan	Display airtime-fairness configuration for all wlangs
--------------------	------	---

Command Default	Privileged EXEC
-----------------	-----------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows the complete list of configured WLANs and ATF policies applied.

```
Device#show ap airtime-fairness wlan
```

WLAN ID	Profile Name	ATF Profile Name	Weight
12	doctestlan	Default	10

show ap name dot11 airtime-fairness wlan name statistics

To view ATF statistics per WLAN active on specific AP, use the **show ap name dot11 airtime-fairness wlan name statistics** command.

show ap name dot11 {24ghz | 5ghz} **airtime-fairness wlan name** *wlan-name* **statistics**

Syntax Description	name	Display airtime-fairness stats by profile name
	<i>wlan-name</i>	Enter WLAN name
	statistics	Display the stats of 24GHz 5GHz airtime-fairness
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1 This command was introduced.	

This example shows how to view ATF statistics per WLAN active on specific AP.

```
Device#show ap name testap dot11 24ghz airtime-fairness wlan name testwlan statistics
```

show ap airtime-fairness ap-group

To view ATF configuration for a specific AP group, use the **show ap airtime-fairness ap-group** command.

show ap airtime-fairness ap-group *group-name*

Syntax Description	<i>group-name</i>	Enter AP-group name
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows ATF configuration for a specific AP group .

```
Device#show ap airtime-fairness ap-group ?
Site Description:
Airtime-fairness 2.4GHz Mode:: Disable
Airtime-fairness 2.4GHz Optimization : n/a
Airtime-fairness 5GHz Mode:: Disable
Airtime-fairness 5GHz Optimization : n/a
```

WLAN ID	WLAN Name	Interface	ATF Policy(2.4GHz)	ATF Policy(5GHz)



PART **XIII**

Security

- [Security](#), on page 945



Security

- [aaa accounting](#), on page 947
- [aaa accounting dot1x](#), on page 950
- [aaa accounting identity](#), on page 952
- [aaa authentication dot1x](#), on page 954
- [aaa authorization network](#), on page 955
- [aaa new-model](#), on page 956
- [access-session template monitor](#), on page 958
- [authentication host-mode](#), on page 959
- [authentication mac-move permit](#), on page 961
- [authentication priority](#), on page 962
- [authentication violation](#), on page 965
- [clear errdisable interface vlan](#), on page 967
- [clear mac address-table](#), on page 968
- [deny \(MAC access-list configuration\)](#), on page 970
- [device-role \(IPv6 snooping\)](#), on page 974
- [device-role \(IPv6 nd inspection\)](#), on page 975
- [device-tracking policy](#), on page 976
- [dot1x critical \(global configuration\)](#), on page 978
- [dot1x test eapol-capable](#), on page 979
- [dot1x test timeout](#), on page 980
- [dot1x timeout](#), on page 981
- [epm access-control open](#), on page 983
- [ip admission](#), on page 984
- [ip admission name](#), on page 985
- [ip dhcp snooping database](#), on page 987
- [ip dhcp snooping information option format remote-id](#), on page 989
- [ip dhcp snooping verify no-relay-agent-address](#), on page 990
- [ip http access-class](#), on page 991
- [ip source binding](#), on page 993
- [ip verify source](#), on page 994
- [ipv6 access-list](#), on page 995
- [ipv6 snooping policy](#), on page 997
- [limit address-count](#), on page 998

- mab request format attribute 32, on page 999
- match (access-map configuration), on page 1001
- no authentication logging verbose, on page 1003
- no dot1x logging verbose, on page 1004
- no mab logging verbose, on page 1005
- permit (MAC access-list configuration), on page 1006
- protocol (IPv6 snooping), on page 1010
- radius server, on page 1011
- security level (IPv6 snooping), on page 1013
- server-private (RADIUS), on page 1014
- show aaa clients, on page 1016
- show aaa command handler, on page 1017
- **show aaa local**, on page 1018
- show aaa servers, on page 1019
- show aaa sessions, on page 1020
- show authentication sessions, on page 1021
- show dot1x, on page 1024
- show eap pac peer, on page 1026
- show ip dhcp snooping statistics, on page 1027
- show radius server-group, on page 1030
- show storm-control, on page 1032
- show vlan access-map, on page 1034
- show vlan group, on page 1035
- storm-control, on page 1036
- switchport port-security aging, on page 1039
- switchport port-security mac-address, on page 1041
- switchport port-security maximum, on page 1043
- switchport port-security violation, on page 1045
- tacacs server, on page 1047
- tracking (IPv6 snooping), on page 1048
- trusted-port, on page 1050
- wireless dot11-padding, on page 1051
- wireless security dot1x, on page 1052
- wireless security lsc, on page 1054
- wireless security strong-password, on page 1055
- wireless wps ap-authentication, on page 1056
- wireless wps auto-immune, on page 1057
- wireless wps cids-sensor, on page 1058
- wireless wps client-exclusion, on page 1059
- wireless wps mfp infrastructure, on page 1061
- wireless wps rogue, on page 1062
- wireless wps shun-list re-sync, on page 1063
- vlan access-map, on page 1064
- vlan filter, on page 1066
- vlan group, on page 1067

aaa accounting

To enable authentication, authorization, and accounting (AAA) accounting of requested services for billing or security purposes when you use RADIUS or TACACS+, use the **aaa accounting** command in global configuration mode. To disable AAA accounting, use the **no** form of this command.

```
aaa accounting {auth-proxy | system | network | exec | connections | commands level}
{default | list-name} {start-stop | stop-only | none} [broadcast] group group-name
no aaa accounting {auth-proxy | system | network | exec | connections | commands level}
{default | list-name} {start-stop | stop-only | none} [broadcast] group group-name
```

Syntax Description

auth-proxy	Provides information about all authenticated-proxy user events.
system	Performs accounting for all system-level events not associated with users, such as reloads.
network	Runs accounting for all network-related service requests.
exec	Runs accounting for EXEC shell session. This keyword might return user profile information such as what is generated by the autocommand command.
connection	Provides information about all outbound connections made from the network access server.
commands level	Runs accounting for all commands at the specified privilege level. Valid privilege level entries are integers from 0 through 15.
default	Uses the listed accounting methods that follow this argument as the default list of methods for accounting services.
<i>list-name</i>	Character string used to name the list of at least one of the accounting methods described in
start-stop	Sends a "start" accounting notice at the beginning of a process and a "stop" accounting notice at the end of a process. The "start" accounting record is sent in the background. The requested user process begins regardless of whether the "start" accounting notice was received by the accounting server.
stop-only	Sends a "stop" accounting notice at the end of the requested user process.
none	Disables accounting services on this line or interface.
broadcast	(Optional) Enables sending accounting records to multiple AAA servers. Simultaneously sends accounting records to the first server in each group. If the first server is unavailable, fail over occurs using the backup servers defined within that group.
<i>group groupname</i>	At least one of the keywords described in Table 34: AAA accounting Methods, on page 948

Command Default

AAA accounting is disabled.

Command Modes

Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **aaa accounting** command to enable accounting and to create named method lists defining specific accounting methods on a per-line or per-interface basis.

Table 34: AAA accounting Methods

Keyword	Description
group radius	Uses the list of all RADIUS servers for authentication as defined by the aaa group server radius command.
group tacacs+	Uses the list of all TACACS+ servers for authentication as defined by the aaa group server tacacs+ command.
group group-name	Uses a subset of RADIUS or TACACS+ servers for accounting as defined by the server group group-name.

In [Table 34: AAA accounting Methods, on page 948](#), the **group radius** and **group tacacs+** methods refer to a set of previously defined RADIUS or TACACS+ servers. Use the **radius server** and **tacacs server** commands to configure the host servers. Use the **aaa group server radius** and **aaa group server tacacs+** commands to create a named group of servers.

Cisco IOS software supports the following two methods of accounting:

- **RADIUS**—The network access server reports user activity to the RADIUS security server in the form of accounting records. Each accounting record contains accounting attribute-value (AV) pairs and is stored on the security server.
- **TACACS+**—The network access server reports user activity to the TACACS+ security server in the form of accounting records. Each accounting record contains accounting attribute-value (AV) pairs and is stored on the security server.

Method lists for accounting define the way accounting will be performed. Named accounting method lists enable you to designate a particular security protocol to be used on specific lines or interfaces for particular types of accounting services. Create a list by entering the *list-name* and the *method*, where *list-name* is any character string used to name this list (excluding the names of methods, such as radius or tacacs+) and *method* identifies the methods to be tried in sequence as given.

If the **aaa accounting** command for a particular accounting type is issued without a named method list specified, the default method list is automatically applied to all interfaces or lines (where this accounting type applies) except those that have a named method list explicitly defined. (A defined method list overrides the default method list.) If no default method list is defined, then no accounting takes place.

**Note**

System accounting does not use named accounting lists; you can only define the default list for system accounting.

For minimal accounting, include the **stop-only** keyword to send a stop record accounting notice at the end of the requested user process. For more accounting, you can include the **start-stop** keyword, so that RADIUS

or TACACS+ sends a start accounting notice at the beginning of the requested process and a stop accounting notice at the end of the process. Accounting is stored only on the RADIUS or TACACS+ server. The none keyword disables accounting services for the specified line or interface.

When AAA accounting is activated, the network access server monitors either RADIUS accounting attributes or TACACS+ AV pairs pertinent to the connection, depending on the security method you have implemented. The network access server reports these attributes as accounting records, which are then stored in an accounting log on the security server. For a list of supported RADIUS accounting attributes, refer to the appendix RADIUS Attributes in the *Cisco IOS Security Configuration Guide*. For a list of supported TACACS+ accounting AV pairs, refer to the appendix TACACS+ Attribute-Value Pairs in the *Cisco IOS Security Configuration Guide*.



Note This command cannot be used with TACACS or extended TACACS.

This example defines a default commands accounting method list, where accounting services are provided by a TACACS+ security server, set for privilege level 15 commands with a stop-only restriction:

```
Device(config)# aaa accounting commands 15 default stop-only group TACACS+
```

This example defines a default auth-proxy accounting method list, where accounting services are provided by a TACACS+ security server with a stop-only restriction. The aaa accounting commands activates authentication proxy accounting.

```
Device(config)# aaa new model
Device(config)# aaa authentication login default group TACACS+
Device(config)# aaa authorization auth-proxy default group TACACS+
Device(config)# aaa accounting auth-proxy default start-stop group TACACS+
```

aaa accounting dot1x

To enable authentication, authorization, and accounting (AAA) accounting and to create method lists defining specific accounting methods on a per-line or per-interface basis for IEEE 802.1x sessions, use the **aaa accounting dot1x** command in global configuration mode. To disable IEEE 802.1x accounting, use the **no** form of this command.

```
aaa accounting dot1x {name | default} start-stop {broadcast group {name | radius | tacacs+}
[group {name | radius | tacacs+} ... ] | group {name | radius | tacacs+} [group
{name | radius | tacacs+} ... ]}
no aaa accounting dot1x {name | default}
```

Syntax Description					
name	Name of a server group. This is optional when you enter it after the broadcast group and group keywords.				
default	Specifies the accounting methods that follow as the default list for accounting services.				
start-stop	Sends a start accounting notice at the beginning of a process and a stop accounting notice at the end of a process. The start accounting record is sent in the background. The requested user process begins regardless of whether or not the start accounting notice was received by the accounting server.				
broadcast	Enables accounting records to be sent to multiple AAA servers and sends accounting records to the first server in each group. If the first server is unavailable, the switch uses the list of backup servers to identify the first server.				
group	Specifies the server group to be used for accounting services. These are valid server group names: <ul style="list-style-type: none"> • name — Name of a server group. • radius — Lists of all RADIUS hosts. • tacacs+ — Lists of all TACACS+ hosts. <p>The group keyword is optional when you enter it after the broadcast group and group keywords. You can enter more than optional group keyword.</p>				
radius	(Optional) Enables RADIUS accounting.				
tacacs+	(Optional) Enables TACACS+ accounting.				
Command Default	AAA accounting is disabled.				
Command Modes	Global configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.				

Usage Guidelines

This command requires access to a RADIUS server.

We recommend that you enter the **dot1x reauthentication** interface configuration command before configuring IEEE 802.1x RADIUS accounting on an interface.

This example shows how to configure IEEE 802.1x accounting:

```
Device(config)# aaa new-model  
Device(config)# aaa accounting dot1x default start-stop group radius
```

aaa accounting identity

To enable authentication, authorization, and accounting (AAA) accounting for IEEE 802.1x, MAC authentication bypass (MAB), and web authentication sessions, use the **aaa accounting identity** command in global configuration mode. To disable IEEE 802.1x accounting, use the **no** form of this command.

```
aaa accounting identity {name | default} start-stop {broadcast group {name | radius | tacacs+}
[group {name | radius | tacacs+} ... ] | group {name | radius | tacacs+} [group
{name | radius | tacacs+} ... ]}
no aaa accounting identity {name | default}
```

Syntax Description

name	Name of a server group. This is optional when you enter it after the broadcast group and group keywords.
default	Uses the accounting methods that follow as the default list for accounting services.
start-stop	Sends a start accounting notice at the beginning of a process and a stop accounting notice at the end of a process. The start accounting record is sent in the background. The requested-user process begins regardless of whether or not the start accounting notice was received by the accounting server.
broadcast	Enables accounting records to be sent to multiple AAA servers and send accounting records to the first server in each group. If the first server is unavailable, the switch uses the list of backup servers to identify the first server.
group	Specifies the server group to be used for accounting services. These are valid server group names: <ul style="list-style-type: none"> • name — Name of a server group. • radius — Lists of all RADIUS hosts. • tacacs+ — Lists of all TACACS+ hosts. <p>The group keyword is optional when you enter it after the broadcast group and group keywords. You can enter more than optional group keyword.</p>
radius	(Optional) Enables RADIUS authorization.
tacacs+	(Optional) Enables TACACS+ accounting.

Command Default

AAA accounting is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

To enable AAA accounting identity, you need to enable policy mode. To enable policy mode, enter the **authentication display new-style** command in privileged EXEC mode.

This example shows how to configure IEEE 802.1x accounting identity:

```
Device# authentication display new-style
```

Please note that while you can revert to legacy style configuration at any time unless you have explicitly entered new-style configuration, the following caveats should be carefully read and understood.

- (1) If you save the config in this mode, it will be written to NVRAM in NEW-style config, and if you subsequently reload the router without reverting to legacy config and saving that, you will no longer be able to revert.
- (2) In this and legacy mode, Webauth is not IPv6-capable. It will only become IPv6-capable once you have entered new-style config manually, or have reloaded with config saved in 'authentication display new' mode.

```
Device# configure terminal
```

```
Device(config)# aaa accounting identity default start-stop group radius
```

aaa authentication dot1x

To specify the authentication, authorization, and accounting (AAA) method to use on ports complying with the IEEE 802.1x authentication, use the **aaa authentication dot1x** command in global configuration mode on the switch stack or on a standalone switch. To disable authentication, use the **no** form of this command.

```
aaa authentication dot1x {default} method1
no aaa authentication dot1x {default} method1
```

Syntax Description	default	The default method when a user logs in. Use the listed authentication method that follows this argument.
	<i>method1</i>	Specifies the server authentication. Enter the group radius keywords to use the list of all RADIUS servers for authentication.
	Note	Though other keywords are visible in the command-line help strings, only the default and group radius keywords are supported.

Command Default No authentication is performed.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The **method** argument identifies the method that the authentication algorithm tries in the specified sequence to validate the password provided by the client. The only method that is IEEE 802.1x-compliant is the **group radius** method, in which the client data is validated against a RADIUS authentication server.

If you specify **group radius**, you must configure the RADIUS server by entering the **radius-server host** global configuration command.

Use the **show running-config** privileged EXEC command to display the configured lists of authentication methods.

This example shows how to enable AAA and how to create an IEEE 802.1x-compliant authentication list. This authentication first tries to contact a RADIUS server. If this action returns an error, the user is not allowed access to the network.

```
Device(config)# aaa new-model
Device(config)# aaa authentication dot1x default group radius
```

aaa authorization network

To configure the switch to use user-RADIUS authorization for all network-related service requests, such as IEEE 802.1x VLAN assignment, use the **aaa authorization network** command in global configuration mode. To disable RADIUS user authorization, use the **no** form of this command

aaa authorization network default group radius
no aaa authorization network default

Syntax Description	default group radius Use the list of all RADIUS hosts in the server group as the default authorization list.				
Command Default	Authorization is disabled.				
Command Modes	Global configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

Usage Guidelines Use the **aaa authorization network default group radius** global configuration command to allow the switch to download IEEE 802.1x authorization parameters from the RADIUS servers in the default authorization list. The authorization parameters are used by features such as VLAN assignment to get parameters from the RADIUS servers.

Use the **show running-config** privileged EXEC command to display the configured lists of authorization methods.

This example shows how to configure the switch for user RADIUS authorization for all network-related service requests:

```
Device(config)# aaa authorization network default group radius
```

aaa new-model

To enable the authentication, authorization, and accounting (AAA) access control model, issue the **aaa new-model** command in global configuration mode. To disable the AAA access control model, use the **no** form of this command.

aaa new-model
no aaa new-model

Syntax Description This command has no arguments or keywords.

Command Default AAA is not enabled.

Command Modes Global configuration (config)

Release	Modification
Cisco IOS XE Release 3.3E	This command was implemented on Cisco Catalyst 3650 Series Switches.

Usage Guidelines This command enables the AAA access control system.

If the **login local** command is configured for a virtual terminal line (VTY), and the **aaa new-model** command is removed, you must reload the switch to get the default configuration or the **login** command. If the switch is not reloaded, the switch defaults to the **login local** command under the VTY.



Note We do not recommend removing the **aaa new-model** command.

The following example shows this restriction:

```
Switch(config)# aaa new-model
Switch(config)# line vty 0 15
Switch(config-line)# login local
Switch(config-line)# exit
Switch(config)# no aaa new-model
Switch(config)# exit
Switch# show running-config | b line vty

line vty 0 4
  login local !<=== Login local instead of "login"
line vty 5 15
  login local
!
```

Examples

The following example initializes AAA:

```
Switch(config)# aaa new-model
Switch(config)#
```

Related Commands	Command	Description
	aaa accounting	Enables AAA accounting of requested services for billing or security purposes.
	aaa authentication arap	Enables an AAA authentication method for ARAP using TACACS+.
	aaa authentication enable default	Enables AAA authentication to determine if a user can access the privileged command level.
	aaa authentication login	Sets AAA authentication at login.
	aaa authentication ppp	Specifies one or more AAA authentication method for use on serial interfaces running PPP.
	aaa authorization	Sets parameters that restrict user access to a network.

access-session template monitor

To set the access session template to monitor ports, use the **access-session template monitor** command in global configuration mode. To return to the default setting, use the **no** form of this command.

access-session template monitor

no access-session template monitor

Syntax Description This command has no arguments or keywords.

Command Default This command is not configured.

Command Modes Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines

The **access-session template monitor** command enables session monitoring to create sessions on all ports where authentication configurations are not present, and MAC addresses are known. These sessions have open access ports for traffic, multi-auth host mode to control the number of hosts on a port, and port-control set to auto for sessions to undergo authentication and authorization. The **access-session template monitor** command is enabled by default if the **device classifier** or **autoconf** command is enabled. Session monitoring can be disabled on a per port basis.

This command is available on devices that has Identity-Based Networking Services (IBNS). The equivalent command for **access-session template monitor** command in IBNS **new-style** mode is **access-session monitor**. To switch from IBNS legacy mode to new style mode, use the **authentication convert-to new-style** command.

Examples

The following example shows how to set the access session template to monitor ports:

```
Device(config)# access-session template monitor
```

Related Commands

Command	Description
device classifier	Creates a monitor session for all the MAC addresses learned in the system.
authentication convert-to new-style	Converts all the relevant authentication commands to their CPL control policy-equivalents.

authentication host-mode

To set the authorization manager mode on a port, use the **authentication host-mode** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

authentication host-mode { **multi-auth** | **multi-domain** | **multi-host** | **single-host** }
no authentication host-mode

Syntax Description	multi-auth	multi-domain	multi-host	single-host
	Enables multiple-authorization mode (multi-auth mode) on the port.	Enables multiple-domain mode on the port.	Enables multiple-host mode on the port.	Enables single-host mode on the port.
Command Default	Single host mode is enabled.			
Command Modes	Interface configuration			
Command History	Release	Modification		
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE	This command was introduced.	

Usage Guidelines

Single-host mode should be configured if only one data host is connected. Do not connect a voice device to authenticate on a single-host port. Voice device authorization fails if no voice VLAN is configured on the port.

Multi-domain mode should be configured if data host is connected through an IP phone to the port. Multi-domain mode should be configured if the voice device needs to be authenticated.

Multi-auth mode should be configured to allow devices behind a hub to obtain secured port access through individual authentication. Only one voice device can be authenticated in this mode if a voice VLAN is configured.

Multi-host mode also offers port access for multiple hosts behind a hub, but multi-host mode gives unrestricted port access to the devices after the first user gets authenticated.

This example shows how to enable multi-auth mode on a port:

```
Device(config-if)# authentication host-mode multi-auth
```

This example shows how to enable multi-domain mode on a port:

```
Device(config-if)# authentication host-mode multi-domain
```

This example shows how to enable multi-host mode on a port:

```
Device(config-if)# authentication host-mode multi-host
```

This example shows how to enable single-host mode on a port:

```
Device(config-if)# authentication host-mode single-host
```

You can verify your settings by entering the **show authentication sessions interface *interface* details** privileged EXEC command.

authentication mac-move permit

To enable MAC move on a device, use the **authentication mac-move permit** command in global configuration mode. To disable MAC move, use the **no** form of this command.

authentication mac-move permit
no authentication mac-move permit

Syntax Description This command has no arguments or keywords.

Command Default MAC move is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The command enables authenticated hosts to move between ports on a device. For example, if there is a device between an authenticated host and port, and that host moves to another port, the authentication session is deleted from the first port, and the host is reauthenticated on the new port.

If MAC move is disabled, and an authenticated host moves to another port, it is not reauthenticated, and a violation error occurs.

This example shows how to enable MAC move on a device:

```
Device(config)# authentication mac-move permit
```

authentication priority

To add an authentication method to the port-priority list, use the **authentication priority** command in interface configuration mode. To return to the default, use the **no** form of this command.

```
authentication priority [dot1x | mab] {webauth}
no authentication priority [dot1x | mab] {webauth}
```

Syntax Description	dot1x	(Optional) Adds 802.1x to the order of authentication methods.
	mab	(Optional) Adds MAC authentication bypass (MAB) to the order of authentication methods.
	webauth	Adds web authentication to the order of authentication methods.
Command Default	The default priority is 802.1x authentication, followed by MAC authentication bypass and web authentication.	
Command Modes	Interface configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.
Usage Guidelines	<p>Ordering sets the order of methods that the switch attempts when trying to authenticate a new device is connected to a port.</p> <p>When configuring multiple fallback methods on a port, set web authentication (webauth) last.</p> <p>Assigning priorities to different authentication methods allows a higher-priority method to interrupt an in-progress authentication method with a lower priority.</p>	
 Note	<p>If a client is already authenticated, it might be reauthenticated if an interruption from a higher-priority method occurs.</p> <p>The default priority of an authentication method is equivalent to its position in execution-list order: 802.1x authentication, MAC authentication bypass (MAB), and web authentication. Use the dot1x, mab, and webauth keywords to change this default order.</p> <p>This example shows how to set 802.1x as the first authentication method and web authentication as the second authentication method:</p> <pre>Device(config-if)# authentication priority dotx webauth</pre> <p>This example shows how to set MAB as the first authentication method and web authentication as the second authentication method:</p>	

```
Device(config-if)# authentication priority mab webauth
```

Related Commands	Command	Description
	authentication control-direction	Configures the port mode as unidirectional or bidirectional.
	authentication event fail	Specifies how the Auth Manager handles authentication failures as a result of unrecognized user credentials.
	authentication event no-response action	Specifies how the Auth Manager handles authentication failures as a result of a nonresponsive host.
	authentication event server alive action reinitialize	Reinitializes an authorized Auth Manager session when a previously unreachable authentication, authorization, and accounting server becomes available.
	authentication event server dead action authorize	Authorizes Auth Manager sessions when the authentication, authorization, and accounting server becomes unreachable.
	authentication fallback	Enables a web authentication fallback method.
	authentication host-mode	Allows hosts to gain access to a controlled port.
	authentication open	Enables open access on a port.
	authentication order	Specifies the order in which the Auth Manager attempts to authenticate a client on a port.
	authentication periodic	Enables automatic reauthentication on a port.
	authentication port-control	Configures the authorization state of a controlled port.
	authentication timer inactivity	Configures the time after which an inactive Auth Manager session is terminated.
	authentication timer reauthenticate	Specifies the period of time between which the Auth Manager attempts to reauthenticate authorized ports.
	authentication timer restart	Specifies the period of time after which the Auth Manager attempts to authenticate an unauthorized port.
	authentication violation	Specifies the action to be taken when a security violation occurs on a port.
	mab	Enables MAC authentication bypass on a port.

Command	Description
show authentication registrations	Displays information about the authentication methods that are registered with the Auth Manager.
show authentication sessions	Displays information about current Auth Manager sessions.
show authentication sessions interface	Displays information about the Auth Manager for a given interface.

authentication violation

To configure the violation modes that occur when a new device connects to a port or when a new device connects to a port after the maximum number of devices are connected to that port, use the **authentication violation** command in interface configuration mode.

```
authentication violation { protect | replace | restrict | shutdown }
no authentication violation { protect | replace | restrict | shutdown }
```

Syntax Description	protect	Drops unexpected incoming MAC addresses. No syslog errors are generated.
	replace	Removes the current session and initiates authentication with the new host.
	restrict	Generates a syslog error when a violation error occurs.
	shutdown	Error-disables the port or the virtual port on which an unexpected MAC address occurs.

Command Default Authentication violation shutdown mode is enabled.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use the **authentication violation** command to specify the action to be taken when a security violation occurs on a port.

This example shows how to configure an IEEE 802.1x-enabled port as error-disabled and to shut down when a new device connects it:

```
Device(config-if) # authentication violation shutdown
```

This example shows how to configure an 802.1x-enabled port to generate a system error message and to change the port to restricted mode when a new device connects to it:

```
Device(config-if) # authentication violation restrict
```

This example shows how to configure an 802.1x-enabled port to ignore a new device when it connects to the port:

```
Device(config-if) # authentication violation protect
```

This example shows how to configure an 802.1x-enabled port to remove the current session and initiate authentication with a new device when it connects to the port:

```
Device(config-if)# authentication violation replace
```

You can verify your settings by entering the **show authentication** privileged EXEC command.

clear errdisable interface vlan

To reenoble a VLAN that was error-disabled, use the **clear errdisable interface** command in privileged EXEC mode.

```
clear errdisable interface interface-id vlan [vlan-list]
```

Syntax Description		
	<i>interface-id</i>	Specifies an interface.
	<i>vlan list</i>	(Optional) Specifies a list of VLANs to be reenabled. If a VLAN list is not specified, then all VLANs are reenabled.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You can reenoble a port by using the **shutdown** and **no shutdown** interface configuration commands, or you can clear error-disable for VLANs by using the **clear errdisable** interface command.

This example shows how to reenoble all VLANs that were error-disabled on Gigabit Ethernet port 4/0/2:

```
Device# clear errdisable interface gigabitethernet4/0/2 vlan
```

Related Commands	Command	Description
	errdisable detect cause	Enables error-disabled detection for a specific cause or all causes.
	errdisable recovery	Configures the recovery mechanism variables.
	show errdisable detect	Displays error-disabled detection status.
	show errdisable recovery	Displays error-disabled recovery timer information.
	show interfaces status err-disabled	Displays interface status of a list of interfaces in error-disabled state.

clear mac address-table

To delete from the MAC address table a specific dynamic address, all dynamic addresses on a particular interface, all dynamic addresses on stack members, or all dynamic addresses on a particular VLAN, use the **clear mac address-table** command in privileged EXEC mode. This command also clears the MAC address notification global counters.

clear mac address-table { **dynamic** [**address** *mac-addr* | **interface** *interface-id* | **vlan** *vlan-id*] | **move update** | **notification** }

Syntax Description		
dynamic		Deletes all dynamic MAC addresses.
address <i>mac-addr</i>		(Optional) Deletes the specified dynamic MAC address.
interface <i>interface-id</i>		(Optional) Deletes all dynamic MAC addresses on the specified physical port or port channel.
vlan <i>vlan-id</i>		(Optional) Deletes all dynamic MAC addresses for the specified VLAN. The range is 1 to 4094.
move update		Clears the MAC address table move-update counters.
notification		Clears the notifications in the history table and reset the counters.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You can verify that the information was deleted by entering the **show mac address-table** privileged EXEC command.

This example shows how to remove a specific MAC address from the dynamic address table:

```
Device# clear mac address-table dynamic address 0008.0070.0007
```

Related Commands	Command	Description
	mac address-table notification	Enables the MAC address notification feature.
	mac address-table move update { receive transmit }	Configures MAC address-table move update on the switch.

Command	Description
show mac address-table	Displays the MAC address table static and dynamic entries.
show mac address-table move update	Displays the MAC address-table move update information on the switch.
show mac address-table notification	Displays the MAC address notification settings for all interfaces or on the specified interface when the interface keyword is appended.
snmp trap mac-notification change	Enables the SNMP MAC address notification trap on a specific interface.

deny (MAC access-list configuration)

To prevent non-IP traffic from being forwarded if the conditions are matched, use the **deny** MAC access-list configuration command on the switch stack or on a standalone switch. To remove a deny condition from the named MAC access list, use the **no** form of this command.

```
deny {any | host src-MAC-addr | src-MAC-addr mask} {any | host dst-MAC-addr |
dst-MAC-addr mask} [type mask | aarp | amber | appletalk | dec-spanning | decnet-iv |
diagnostic | dsm | etype-6000 | etype-8042 | lat | larc-sca | lsap lsap mask | mop-console
| mop-dump | msdos | mumps | netbios | vines-echo | vines-ip | xns-idp] [cos cos]
no deny {any | host src-MAC-addr | src-MAC-addr mask} {any | host dst-MAC-addr |
dst-MAC-addr mask} [type mask | aarp | amber | appletalk | dec-spanning | decnet-iv |
diagnostic | dsm | etype-6000 | etype-8042 | lat | larc-sca | lsap lsap mask | mop-console
| mop-dump | msdos | mumps | netbios | vines-echo | vines-ip | xns-idp] [cos cos]
```

Syntax Description

any	Denies any source or destination MAC address.
host <i>src-MAC-addr</i> <i>src-MAC-addr mask</i>	Defines a host MAC address and optional subnet mask. If the source address for a packet matches the defined address, non-IP traffic from that address is denied.
host <i>dst-MAC-addr</i> <i>dst-MAC-addr mask</i>	Defines a destination MAC address and optional subnet mask. If the destination address for a packet matches the defined address, non-IP traffic to that address is denied.
<i>type mask</i>	(Optional) Specifies the EtherType number of a packet with Ethernet II or SNAP encapsulation to identify the protocol of the packet. The type is 0 to 65535, specified in hexadecimal. The mask is a mask of don't care bits applied to the EtherType before testing for a match.
aarp	(Optional) Specifies EtherType AppleTalk Address Resolution Protocol that maps a data-link address to a network address.
amber	(Optional) Specifies EtherType DEC-Amber.
appletalk	(Optional) Specifies EtherType AppleTalk/EtherTalk.
dec-spanning	(Optional) Specifies EtherType Digital Equipment Corporation (DEC) spanning tree.
decnet-iv	(Optional) Specifies EtherType DECnet Phase IV protocol.
diagnostic	(Optional) Specifies EtherType DEC-Diagnostic.

dsm	(Optional) Specifies EtherType DEC-DSM.
etype-6000	(Optional) Specifies EtherType 0x6000.
etype-8042	(Optional) Specifies EtherType 0x8042.
lat	(Optional) Specifies EtherType DEC-LAT.
lavc-sca	(Optional) Specifies EtherType DEC-LAVC-SCA.
lsap <i>lsap-number mask</i>	(Optional) Specifies the LSAP number (0 to 65535) of a packet with 802.2 encapsulation to identify the protocol of the packet. <i>mask</i> is a mask of don't care bits applied to the LSAP number before testing for a match.
mop-console	(Optional) Specifies EtherType DEC-MOP Remote Console.
mop-dump	(Optional) Specifies EtherType DEC-MOP Dump.
msdos	(Optional) Specifies EtherType DEC-MSDOS.
mumps	(Optional) Specifies EtherType DEC-MUMPS.
netbios	(Optional) Specifies EtherType DEC- Network Basic Input/Output System (NetBIOS).
vines-echo	(Optional) Specifies EtherType Virtual Integrated Network Service (VINES) Echo from Banyan Systems.
vines-ip	(Optional) Specifies EtherType VINES IP.
xns-idp	(Optional) Specifies EtherType Xerox Network Systems (XNS) protocol suite (0 to 65535), an arbitrary EtherType in decimal, hexadecimal, or octal.
cos <i>cos</i>	(Optional) Specifies a class of service (CoS) number from 0 to 7 to set priority. Filtering on CoS can be performed only in hardware. A warning message reminds the user if the cos option is configured.

Command Default

This command has no defaults. However, the default action for a MAC-named ACL is to deny.

Command Modes

Mac-access list configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You enter MAC-access list configuration mode by using the **mac access-list extended** global configuration command.

If you use the **host** keyword, you cannot enter an address mask; if you do not use the **host** keyword, you must enter an address mask.

When an access control entry (ACE) is added to an access control list, an implied **deny-any-any** condition exists at the end of the list. That is, if there are no matches, the packets are denied. However, before the first ACE is added, the list permits all packets.

To filter IPX traffic, you use the *type mask* or **lsap lsap mask** keywords, depending on the type of IPX encapsulation being used. Filter criteria for IPX encapsulation types as specified in Novell terminology and Cisco IOS terminology are listed in the table.

Table 35: IPX Filtering Criteria

IPX Encapsulation Type		Filter Criterion
Cisco IOS Name	Novel Name	
arpa	Ethernet II	EtherType 0x8137
snap	Ethernet-snap	EtherType 0x8137
sap	Ethernet 802.2	LSAP 0xE0E0
novell-ether	Ethernet 802.3	LSAP 0xFFFF

This example shows how to define the named MAC extended access list to deny NETBIOS traffic from any source to MAC address 00c0.00a0.03fa. Traffic matching this list is denied.

```
Device(config-ext-macl)# deny any host 00c0.00a0.03fa netbios.
```

This example shows how to remove the deny condition from the named MAC extended access list:

```
Device(config-ext-macl)# no deny any 00c0.00a0.03fa 0000.0000.0000 netbios.
```

This example denies all packets with EtherType 0x4321:

```
Device(config-ext-macl)# deny any any 0x4321 0
```

You can verify your settings by entering the **show access-lists** privileged EXEC command.

Related Commands

Command	Description
mac access-list extended	Creates an access list based on MAC addresses for non-IP traffic.
permit	Permits from the MAC access-list configuration. Permits non-IP traffic to be forwarded if conditions are matched.

Command	Description
show access-lists	Displays access control lists configured on a switch.

device-role (IPv6 snooping)

To specify the role of the device attached to the port, use the **device-role** command in IPv6 snooping configuration mode.

```
device-role { node | switch }
```

Syntax Description	node Sets the role of the attached device to node.
	switch Sets the role of the attached device to switch.

Command Default	The device role is node.
------------------------	--------------------------

Command Modes	IPv6 snooping configuration
----------------------	-----------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	The device-role command specifies the role of the device attached to the port. By default, the device role is node.
-------------------------	--

The **switch** keyword indicates that the remote device is a switch and that the local switch is now operating in multiswitch mode; binding entries learned from the port will be marked with trunk_port preference level. If the port is configured as a trust-port, binding entries will be marked with trunk_trusted_port preference level.

This example shows how to define an IPv6 snooping policy name as policy1, place the device in IPv6 snooping configuration mode, and configure the device as the node:

```
Device(config)# ipv6 snooping policy policy1
Device(config-ipv6-snooping)# device-role node
```

device-role (IPv6 nd inspection)

To specify the role of the device attached to the port, use the **device-role** command in neighbor discovery (ND) inspection policy configuration mode.

device-role { **host** | **monitor** | **router** | **switch** }

Syntax Description	host	Sets the role of the attached device to host.
	monitor	Sets the role of the attached device to monitor.
	router	Sets the role of the attached device to router.
	switch	Sets the role of the attached device to switch.

Command Default The device role is host.

Command Modes ND inspection policy configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The **device-role** command specifies the role of the device attached to the port. By default, the device role is host, and therefore all the inbound router advertisement and redirect messages are blocked. If the device role is enabled using the **router** keyword, all messages (router solicitation [RS], router advertisement [RA], or redirect) are allowed on this port.

When the **router** or **monitor** keyword is used, the multicast RS messages are bridged on the port, regardless of whether limited broadcast is enabled. However, the monitor keyword does not allow inbound RA or redirect messages. When the monitor keyword is used, devices that need these messages will receive them.

The **switch** keyword indicates that the remote device is a switch and that the local switch is now operating in multiswitch mode; binding entries learned from the port will be marked with trunk_port preference level. If the port is configured as a trust-port, binding entries will be marked with trunk_trusted_port preference level.

The following example defines a Neighbor Discovery Protocol (NDP) policy name as policy1, places the device in ND inspection policy configuration mode, and configures the device as the host:

```
Device(config)# ipv6 nd inspection policy policy1
Device(config-nd-inspection)# device-role host
```

device-tracking policy

To configure a Switch Integrated Security Features (SISF)-based IP device tracking policy, use the **device-tracking** command in global configuration mode. To delete a device tracking policy, use the **no** form of this command.

device -tracking policy *policy-name*
no device-tracking policy *policy-name*

Syntax Description	<i>policy-name</i> User-defined name of the device tracking policy. The policy name can be a symbolic string (such as Engineering) or an integer (such as 0).				
Command Default	A device tracking policy is not configured.				
Command Modes	Global configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Denali 16.1.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Denali 16.1.1	This command was introduced.
Release	Modification				
Cisco IOS XE Denali 16.1.1	This command was introduced.				

Usage Guidelines Use the SISF-based **device-tracking policy** command to create a device tracking policy. When the **device-tracking policy** command is enabled, the configuration mode changes to device-tracking configuration mode. In this mode, the administrator can configure the following first-hop security commands:

- (Optional) **device-role** {**node** | **switch**}—Specifies the role of the device attached to the port. Default is **node**.
- (Optional) **limit address-count** *value*—Limits the number of addresses allowed per target.
- (Optional) **no**—Negates a command or sets it to defaults.
- (Optional) **destination-glean** {**recovery** | **log-only**} [**dhcp**]}—Enables binding table recovery by data traffic source address gleaning.
- (Optional) **data-glean** {**recovery** | **log-only**} [**dhcp** | **ndp**]}—Enables binding table recovery using source or data address gleaning.
- (Optional) **security-level** {**glean** | **guard** | **inspect**}—Specifies the level of security enforced by the feature. Default is **guard**.
 - glean**—Gleans addresses from messages and populates the binding table without any verification.
 - guard**—Gleans addresses and inspects messages. In addition, it rejects RA and DHCP server messages. This is the default option.
 - inspect**—Gleans addresses, validates messages for consistency and conformance, and enforces address ownership.
- (Optional) **tracking** {**disable** | **enable**}—Specifies a tracking option.
- (Optional) **trusted-port**—Sets up a trusted port. It disables the guard on applicable targets. Bindings learned through a trusted port have preference over bindings learned through any other port. A trusted port is given preference in case of a collision while making an entry in the table.

This example shows how to configure an a device-tracking policy:

```
Device(config)# device-tracking policy policy1  
Device(config-device-tracking)# trusted-port
```

dot1x critical (global configuration)

To configure the IEEE 802.1X critical authentication parameters, use the **dot1x critical** command in global configuration mode.

dot1x critical eapol

Syntax Description	eapol Specifies that the switch send an EAPOL-Success message when the switch successfully authenticates the critical port.				
Command Default	eapol is disabled				
Command Modes	Global configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

This example shows how to specify that the switch sends an EAPOL-Success message when the switch successfully authenticates the critical port:

```
Device(config)# dot1x critical eapol
```

dot1x test eapol-capable

To monitor IEEE 802.1x activity on all the switch ports and to display information about the devices that are connected to the ports that support IEEE 802.1x, use the **dot1x test eapol-capable** command in privileged EXEC mode on the switch stack or on a standalone switch.

```
dot1x test eapol-capable [interface interface-id]
```

Syntax Description	interface interface-id (Optional) Port to be queried.				
Command Default	There is no default setting.				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

Usage Guidelines Use this command to test the IEEE 802.1x capability of the devices connected to all ports or to specific ports on a switch.

There is not a no form of this command.

This example shows how to enable the IEEE 802.1x readiness check on a switch to query a port. It also shows the response received from the queried port verifying that the device connected to it is IEEE 802.1x-capable:

```
Device# dot1x test eapol-capable interface gigabitethernet1/0/13
```

```
DOT1X_PORT_EAPOL_CAPABLE:DOT1X: MAC 00-01-02-4b-f1-a3 on gigabitethernet1/0/13 is EAPOL capable
```

Related Commands	Command	Description
	dot1x test timeout timeout	Configures the timeout used to wait for EAPOL response to an IEEE 802.1x readiness query.

dot1x test timeout

To configure the timeout used to wait for EAPOL response from a port being queried for IEEE 802.1x readiness, use the **dot1x test timeout** command in global configuration mode on the switch stack or on a standalone switch.

dot1x test timeout *timeout*

Syntax Description	<i>timeout</i>	Time in seconds to wait for an EAPOL response. The range is from 1 to 65535 seconds.
Command Default	The default setting is 10 seconds.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use this command to configure the timeout used to wait for EAPOL response. There is not a no form of this command.

This example shows how to configure the switch to wait 27 seconds for an EAPOL response:

```
Device# dot1x test timeout 27
```

You can verify the timeout configuration status by entering the **show run** privileged EXEC command.

Related Commands	Command	Description
	dot1x test eapol-capable [<i>interface interface-id</i>]	Checks for IEEE 802.1x readiness on devices connected to all or to specified IEEE 802.1x-capable ports.

dot1x timeout

To configure the value for retry timeouts, use the **dot1x timeout** command in global configuration or interface configuration mode. To return to the default value for retry timeouts, use the **no** form of this command.

```
dot1x timeout { auth-period seconds | held-period seconds | quiet-period seconds | ratelimit-period seconds | server-timeout seconds | start-period seconds | supp-timeout seconds | tx-period seconds }
```

Syntax Description	
auth-period <i>seconds</i>	<p>Configures the time, in seconds for which a supplicant will stay in the HELD state (that is, the length of time it will wait before trying to send the credentials again after a failed attempt).</p> <p>The range is from 1 to 65535. The default is 30.</p>
held-period <i>seconds</i>	<p>Configures the time, in seconds for which a supplicant will stay in the HELD state (that is, the length of time it will wait before trying to send the credentials again after a failed attempt).</p> <p>The range is from 1 to 65535. The default is 60</p>
quiet-period <i>seconds</i>	<p>Configures the time, in seconds, that the authenticator (server) remains quiet (in the HELD state) following a failed authentication exchange before trying to reauthenticate the client.</p> <p>The range is from 1 to 65535. The default is 60</p>
ratelimit-period <i>seconds</i>	<p>Throttles the EAP-START packets that are sent from misbehaving client PCs (for example, PCs that send EAP-START packets that result in the wasting of switch processing power).</p> <ul style="list-style-type: none"> The authenticator ignores EAPOL-Start packets from clients that have successfully authenticated for the rate-limit period duration. The range is from 1 to 65535. By default, rate limiting is disabled.
server-timeout <i>seconds</i>	<p>Configures the interval, in seconds, between two successive EAPOL-Start frames when they are being retransmitted.</p> <ul style="list-style-type: none"> The range is from 1 to 65535. The default is 30. <p>If the server does not send a response to an 802.1X packet within the specified period, the packet is sent again.</p>
start-period <i>seconds</i>	<p>Configures the interval, in seconds, between two successive EAPOL-Start frames when they are being retransmitted.</p> <p>The range is from 1 to 65535. The default is 30.</p>
supp-timeout <i>seconds</i>	<p>Sets the authenticator-to-supplicant retransmission time for all EAP messages other than EAP Request ID.</p> <p>The range is from 1 to 65535. The default is 30.</p>

tx-period <i>seconds</i>	Configures the number of seconds between retransmission of EAP request ID packets (assuming that no response is received) to the client. <ul style="list-style-type: none"> • The range is from 1 to 65535. The default is 30. • If an 802.1X packet is sent to the supplicant and the supplicant does not send a response after the retry period, the packet will be sent again.
---------------------------------	---

Command Default Periodic reauthentication and periodic rate-limiting are done.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You should change the default value of this command only to adjust for unusual circumstances such as unreliable links or specific behavioral problems with certain clients and authentication servers.

The **dot1x timeout reauth-period** interface configuration command affects the behavior of the switch only if you have enabled periodic re-authentication by using the **dot1x reauthentication** interface configuration command.

During the quiet period, the switch does not accept or initiate any authentication requests. If you want to provide a faster response time to the user, enter a number smaller than the default.

When the **ratelimit-period** is set to 0 (the default), the switch does not ignore EAPOL packets from clients that have been successfully authenticated and forwards them to the RADIUS server.

The following example shows that various 802.1X retransmission and timeout periods have been set:

```
Device(config)# configure terminal
Device(config)# interface g1/0/3
Device(config-if)# dot1x port-control auto
Device(config-if)# dot1x timeout auth-period 2000
Device(config-if)# dot1x timeout held-period 2400
Device(config-if)# dot1x timeout quiet-period 600
Device(config-if)# dot1x timeout start-period 90
Device(config-if)# dot1x timeout supp-timeout 300
Device(config-if)# dot1x timeout tx-period 60
Device(config-if)# dot1x timeout server-timeout 60
```

epm access-control open

To configure an open directive for ports that do not have an access control list (ACL) configured, use the **epm access-control open** command in global configuration mode. To disable the open directive, use the **no** form of this command.

epm access-control open
no epm access-control open

Syntax Description This command has no arguments or keywords.

Command Default The default directive applies.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines Use this command to configure an open directive that allows hosts without an authorization policy to access ports configured with a static ACL. If you do not configure this command, the port applies the policies of the configured ACL to the traffic. If no static ACL is configured on a port, both the default and open directives allow access to the port.

You can verify your settings by entering the **show running-config** privileged EXEC command.

This example shows how to configure an open directive.

```
Device(config)# epm access-control open
```

Related Commands	Command	Description
	show running-config	Displays the contents of the current running configuration file.

ip admission

To enable web authentication, use the **ip admission** command in interface configuration mode. You can also use this command in fallback-profile configuration mode. To disable web authentication, use the **no** form of this command.

ip admission *rule*
no ip admission *rule*

Syntax Description *rule* IP admission rule name.

Command Default Web authentication is disabled.

Command Modes Interface configuration
 Fallback-profile configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The **ip admission** command applies a web authentication rule to a switch port.

This example shows how to apply a web authentication rule to a switchport:

```
Device# configure terminal
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# ip admission rule1
```

This example shows how to apply a web authentication rule to a fallback profile for use on an IEEE 802.1x enabled switch port.

```
Device# configure terminal
Device(config)# fallback profile profile1
Device(config-fallback-profile)# ip admission rule1
```

ip admission name

To enable web authentication, use the **ip admission name** command in global configuration mode. To disable web authentication, use the **no** form of this command.

```
ip admission name name {consent | proxy http} [absolute timer minutes | inactivity-time
minutes | list {acl | acl-name} | service-policy type tag service-policy-name]
no ip admission name name {consent | proxy http} [absolute timer minutes | inactivity-time
minutes | list {acl | acl-name} | service-policy type tag service-policy-name]
```

Syntax Description

<i>name</i>	Name of network admission control rule.
consent	Associates an authentication proxy consent web page with the IP admission rule specified using the <i>admission-name</i> argument.
proxy http	Configures web authentication custom page.
absolute-timer <i>minutes</i>	(Optional) Elapsed time, in minutes, before the external server times out.
inactivity-time <i>minutes</i>	(Optional) Elapsed time, in minutes, before the external file server is deemed unreachable.
list	(Optional) Associates the named rule with an access control list (ACL).
<i>acl</i>	Applies a standard, extended list to a named admission control rule. The value ranges from 1 through 199, or from 1300 through 2699 for expanded range.
<i>acl-name</i>	Applies a named access list to a named admission control rule.
service-policy type tag	(Optional) A control plane service policy is to be configured.
<i>service-policy-name</i>	Control plane tag service policy that is configured using the policy-map type control tag <i>polycyname</i> command, keyword, and argument. This policy map is used to apply the actions on the host when a tag is received.

Command Default Web authentication is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **ip admission name** command globally enables web authentication on a switch.

After you enable web authentication on a switch, use the **ip access-group in** and **ip admission web-rule** interface configuration commands to enable web authentication on a specific interface.

Examples

This example shows how to configure only web authentication on a switch port:

```
Device# configure terminal
Device(config) ip admission name http-rule proxy http
Device(config) # interface gigabitethernet1/0/1
Device(config-if) # ip access-group 101 in
Device(config-if) # ip admission rule
Device(config-if) # end
```

This example shows how to configure IEEE 802.1x authentication with web authentication as a fallback mechanism on a switch port:

```
Device# configure terminal
Device(config) # ip admission name rule2 proxy http
Device(config) # fallback profile profile1
Device(config) # ip access group 101 in
Device(config) # ip admission name rule2
Device(config) # interface gigabitethernet1/0/1
Device(config-if) # dot1x port-control auto
Device(config-if) # dot1x fallback profile1
Device(config-if) # end
```

Related Commands

Command	Description
dot1x fallback	Configures a port to use web authentication as a fallback method for clients that do not support IEEE 802.1x authentication.
fallback profile	Creates a web authentication fallback profile.
ip admission	Enables web authentication on a port.
show authentication sessions interface <i>interface</i> detail	Displays information about the web authentication session status.
show ip admission	Displays information about NAC cached entries or the NAC configuration.

ip dhcp snooping database

To configure the Dynamic Host Configuration Protocol (DHCP)-snooping database, use the **ip dhcp snooping database** command in global configuration mode. To disable the DHCP-snooping database, use the **no** form of this command.

no ip dhcp snooping database [**timeout** | **write-delay**]

Syntax Description		
flash: <i>url</i>		Specifies the database URL for storing entries using flash.
ftp: <i>url</i>		Specifies the database URL for storing entries using FTP.
http: <i>url</i>		Specifies the database URL for storing entries using HTTP.
https: <i>url</i>		Specifies the database URL for storing entries using secure HTTP (https).
rcp: <i>url</i>		Specifies the database URL for storing entries using remote copy (rcp).
scp: <i>url</i>		Specifies the database URL for storing entries using Secure Copy (SCP).
tftp: <i>url</i>		Specifies the database URL for storing entries using TFTP.
timeout <i>seconds</i>		Specifies the abort timeout interval; valid values are from 0 to 86400 seconds.
write-delay <i>seconds</i>		Specifies the amount of time before writing the DHCP-snooping entries to an external server after a change is seen in the local DHCP-snooping database; valid values are from 15 to 86400 seconds.
Command Default	The DHCP-snooping database is not configured.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You must enable DHCP snooping on the interface before entering this command. Use the **ip dhcp snooping** command to enable DHCP snooping.

This example shows how to specify the database URL using TFTP:

```
Device(config)# ip dhcp snooping database tftp://10.90.90.90/snooping-rp2
```

This example shows how to specify the amount of time before writing DHCP snooping entries to an external server:

```
Device(config)# ip dhcp snooping database write-delay 15
```

ip dhcp snooping information option format remote-id

To configure the option-82 remote-ID suboption, use the **ip dhcp snooping information option format remote-id** command in global configuration mode on the switch to configure the option-82 remote-ID suboption. To configure the default remote-ID suboption, use the **no** form of this command.

```
ip dhcp snooping information option format remote-id {hostname | string string}
no ip dhcp snooping information option format remote-id {hostname | string string}
```

Syntax Description

hostname Specify the switch hostname as the remote ID.

string string Specify a remote ID, using from 1 to 63 ASCII characters (no spaces).

Command Default

The switch MAC address is the remote ID.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You must globally enable DHCP snooping by using the **ip dhcp snooping** global configuration command for any DHCP snooping configuration to take effect.

When the option-82 feature is enabled, the default remote-ID suboption is the switch MAC address. This command allows you to configure either the switch hostname or a string of up to 63 ASCII characters (but no spaces) to be the remote ID.



Note If the hostname exceeds 63 characters, it will be truncated to 63 characters in the remote-ID configuration.

This example shows how to configure the option- 82 remote-ID suboption:

```
Device(config)# ip dhcp snooping information option format remote-id hostname
```

ip dhcp snooping verify no-relay-agent-address

To disable the DHCP snooping feature from verifying that the relay agent address (giaddr) in a DHCP client message matches the client hardware address on an untrusted port, use the **ip dhcp snooping verify no-relay-agent-address** command in global configuration mode. To enable verification, use the **no** form of this command.

ip dhcp snooping verify no-relay-agent-address
no ip dhcp snooping verify no-relay-agent-address

Syntax Description

This command has no arguments or keywords.

Command Default

The DHCP snooping feature verifies that the relay-agent IP address (giaddr) field in DHCP client message on an untrusted port is 0.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

By default, the DHCP snooping feature verifies that the relay-agent IP address (giaddr) field in DHCP client message on an untrusted port is 0; the message is dropped if the giaddr field is not 0. Use the **ip dhcp snooping verify no-relay-agent-address** command to disable the verification. Use the **no ip dhcp snooping verify no-relay-agent-address** to reenable verification.

This example shows how to enable verification of the giaddr in a DHCP client message:

```
Device(config)# no ip dhcp snooping verify no-relay-agent-address
```

ip http access-class

To specify the access list that should be used to restrict access to the HTTP server, use the **ip http access-class** command in global configuration mode. To remove a previously configured access list association, use the **no** form of this command.



Note The existing **ip http access-class** *access-list-number* command is currently supported, but is going to be deprecated. Use the **ip http access-class ipv4** { *access-list-number* | *access-list-name* } and **ip http access-class ipv6** *access-list-name* instead.

```
ip http access-class { access-list-number | ipv4 { access-list-number | access-list-name } |
ipv6 access-list-name }
no ip http access-class { access-list-number | ipv4 { access-list-number | access-list-name }
| ipv6 access-list-name }
```

Syntax Description

ipv4	Specifies the IPv4 access list to restrict access to the secure HTTP server.
ipv6	Specifies the IPv6 access list to restrict access to the secure HTTP server.
<i>access-list-number</i>	Standard IP access list number in the range 0 to 99, as configured by the access-list global configuration command.
<i>access-list-name</i>	Name of a standard IPv4 access list, as configured by the ip access-list command.

Command Default

No access list is applied to the HTTP server.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was modified. The ipv4 and ipv6 keyword were added.
Cisco IOS XE Release 3.3SE	This command was introduced.

Usage Guidelines

If this command is configured, the specified access list is assigned to the HTTP server. Before the HTTP server accepts a connection, it checks the access list. If the check fails, the HTTP server does not accept the request for a connection.

Examples

The following example shows how to define an access list as 20 and assign it to the HTTP server:

```
Device(config)# ip access-list standard 20
Device(config-std-nacl)# permit 209.165.202.130 0.0.0.255
Device(config-std-nacl)# permit 209.165.201.1 0.0.255.255
```

```
Device(config-std-nacl)# permit 209.165.200.225 0.255.255.255
```

```
Device(config-std-nacl)# exit
```

```
Device(config)# ip http access-class 20
```

The following example shows how to define an IPv4 named access list as and assign it to the HTTP server.

```
Device(config)# ip access-list standard Internet_filter
```

```
Device(config-std-nacl)# permit 1.2.3.4
```

```
Device(config-std-nacl)# exit
```

```
Device(config)# ip http access-class ipv4 Internet_filter
```

Related Commands

Command	Description
ip access-list	Assigns an ID to an access list and enters access list configuration mode.
ip http server	Enables the HTTP 1.1 server, including the Cisco web browser user interface.

ip source binding

To add a static IP source binding entry, use the **ip source binding** command. Use the **no** form of this command to delete a static IP source binding entry

```
ip source binding mac-address vlan vlan-id ip-address interface interface-id
no ip source binding mac-address vlan vlan-id ip-address interface interface-id
```

Syntax Description	<i>mac-address</i>	Binding MAC address.
	vlan <i>vlan-id</i>	Specifies the Layer 2 VLAN identification; valid values are from 1 to 4094.
	<i>ip-address</i>	Binding IP address.
	interface <i>interface-id</i>	ID of the physical interface.
Command Default	No IP source bindings are configured.	
Command Modes	Global configuration.	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You can use this command to add a static IP source binding entry only.

The **no** format deletes the corresponding IP source binding entry. It requires the exact match of all required parameter in order for the deletion to be successful. Note that each static IP binding entry is keyed by a MAC address and a VLAN number. If the command contains the existing MAC address and VLAN number, the existing binding entry is updated with the new parameters instead of creating a separate binding entry.

This example shows how to add a static IP source binding entry:

```
Device# configure terminal
Deviceconfig) ip source binding 0100.0230.0002 vlan 11 10.0.0.4 interface gigabitethernet1/0/1
```

ip verify source

To enable IP source guard on an interface, use the **ip verify source** command in interface configuration mode. To disable IP source guard, use the **no** form of this command.

```
ip verify source [mac-check]
no ip verify source
```

Syntax Description

mac-check (Optional) Enables IP source guard with MAC address verification.

Command Default

IP source guard is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

To enable IP source guard with source IP address filtering, use the **ip verify source** interface configuration command.

To enable IP source guard with source IP address filtering and MAC address verification, use the **ip verify source mac-check** interface configuration command.

Examples

This example shows how to enable IP source guard with source IP address filtering on an interface:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# ip verify source
```

This example shows how to enable IP source guard with MAC address verification:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# ip verify source mac-check
```

You can verify your settings by entering the **show ip verify source** privileged EXEC command.

ipv6 access-list

To define an IPv6 access list and to place the device in IPv6 access list configuration mode, use the **ipv6 access-list** command in global configuration mode. To remove the access list, use the **no** form of this command.

ipv6 access-list *access-list-name* | **match-local-traffic** | **log-update threshold** *threshold-in-msgs* | **role-based** *list-name*
no ipv6 access-list *access-list-name* | **client** *permit-control-packets* | **log-update** *threshold* | **role-based** *list-name*

Syntax Description

ipv6 <i>access-list-name</i>	Creates a named IPv6 ACL (up to 64 characters in length) and enters IPv6 ACL configuration mode. <i>access-list-name</i> - Name of the IPv6 access list. Names cannot contain a space or quotation mark, or begin with a numeric.
match-local-traffic	Enables matching for locally-generated traffic.
log-update threshold <i>threshold-in-msgs</i>	Determines how syslog messages are generated after the initial packet match. <i>threshold-in-msgs</i> - Number of packets generated.
role-based <i>list-name</i>	Creates a role-based IPv6 ACL.

Command Default

No IPv6 access list is defined.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Denali 16.3.1	This command was reintroduced. This command was not supported in Cisco IOS XE Denali 16.1.x and Cisco IOS XE Denali 16.2.x

Usage Guidelines

IPv6 ACLs are defined by using the **ipv6 access-list** command in global configuration mode and their permit and deny conditions are set by using the **deny** and **permit** commands in IPv6 access list configuration mode. Configuring the **ipv6 access-list** command places the device in IPv6 access list configuration mode--the device prompt changes to Device(config-ipv6-acl)#. From IPv6 access list configuration mode, permit and deny conditions can be set for the defined IPv6 ACL.



Note

IPv6 ACLs are defined by a unique name (IPv6 does not support numbered ACLs). An IPv4 ACL and an IPv6 ACL cannot share the same name.

IPv6 is automatically configured as the protocol type in **permit any any** and **deny any any** statements that are translated from global configuration mode to IPv6 access list configuration mode.

Every IPv6 ACL has implicit **permit icmp any any nd-na**, **permit icmp any any nd-ns**, and **deny ipv6 any any** statements as its last match conditions. (The former two match conditions allow for ICMPv6 neighbor discovery.) An IPv6 ACL must contain at least one entry for the implicit **deny ipv6 any any** statement to take effect. The IPv6 neighbor discovery process makes use of the IPv6 network layer service; therefore, by default, IPv6 ACLs implicitly allow IPv6 neighbor discovery packets to be sent and received on an interface. In IPv4, the Address Resolution Protocol (ARP), which is equivalent to the IPv6 neighbor discovery process, makes use of a separate data link layer protocol; therefore, by default, IPv4 ACLs implicitly allow ARP packets to be sent and received on an interface.

Use the **ipv6 traffic-filter** interface configuration command with the *access-list-name* argument to apply an IPv6 ACL to an IPv6 interface. Use the **ipv6 access-class** line configuration command with the *access-list-name* argument to apply an IPv6 ACL to incoming and outgoing IPv6 virtual terminal connections to and from the device.

An IPv6 ACL applied to an interface with the **ipv6 traffic-filter** command filters traffic that is forwarded, not originated, by the device.

Examples

The example configures the IPv6 ACL list named list1 and places the device in IPv6 access list configuration mode.

```
Device(config)# ipv6 access-list list1
Device(config-ipv6-acl)#
```

The following example configures the IPv6 ACL named list2 and applies the ACL to outbound traffic on Ethernet interface 0. Specifically, the first ACL entry keeps all packets from the network FEC0:0:0:2::/64 (packets that have the site-local prefix FEC0:0:0:2 as the first 64 bits of their source IPv6 address) from exiting out of Ethernet interface 0. The second entry in the ACL permits all other traffic to exit out of Ethernet interface 0. The second entry is necessary because an implicit deny all condition is at the end of each IPv6 ACL.

```
Device(config)# ipv6 access-list list2 deny FEC0:0:0:2::/64 any
Device(config)# ipv6 access-list list2 permit any any
Device(config)# interface ethernet 0
Device(config-if)# ipv6 traffic-filter list2 out
```

ipv6 snooping policy



Note All existing IPv6 Snooping commands (prior to Cisco IOS XE Denali 16.1.1) now have corresponding SISF-based device-tracking commands that allow you to apply your configuration to both IPv4 and IPv6 address families. For more information, see [device-tracking policy](#)

To configure an IPv6 snooping policy and enter IPv6 snooping configuration mode, use the **ipv6 snooping policy** command in global configuration mode. To delete an IPv6 snooping policy, use the **no** form of this command.

ipv6 snooping policy *snooping-policy*
no ipv6 snooping policy *snooping-policy*

Syntax Description	<i>snooping-policy</i> User-defined name of the snooping policy. The policy name can be a symbolic string (such as Engineering) or an integer (such as 0).
---------------------------	--

Command Default	An IPv6 snooping policy is not configured.
------------------------	--

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines Use the **ipv6 snooping policy** command to create an IPv6 snooping policy. When the **ipv6 snooping policy** command is enabled, the configuration mode changes to IPv6 snooping configuration mode. In this mode, the administrator can configure the following IPv6 first-hop security commands:

- The **device-role** command specifies the role of the device attached to the port.
- The **limit address-count** *maximum* command limits the number of IPv6 addresses allowed to be used on the port.
- The **protocol** command specifies that addresses should be gleaned with Dynamic Host Configuration Protocol (DHCP) or Neighbor Discovery Protocol (NDP).
- The **security-level** command specifies the level of security enforced.
- The **tracking** command overrides the default tracking policy on a port.
- The **trusted-port** command configures a port to become a trusted port; that is, limited or no verification is performed when messages are received.

This example shows how to configure an IPv6 snooping policy:

```
Device(config)# ipv6 snooping policy policy1
Device(config-ipv6-snooping)#
```

limit address-count

To limit the number of IPv6 addresses allowed to be used on the port, use the **limit address-count** command in Neighbor Discovery Protocol (NDP) inspection policy configuration mode or IPv6 snooping configuration mode. To return to the default, use the **no** form of this command.

limit address-count *maximum*
no limit address-count

Syntax Description	<i>maximum</i> The number of addresses allowed on the port. The range is from 1 to 10000.
---------------------------	---

Command Default	The default is no limit.
------------------------	--------------------------

Command Modes	ND inspection policy configuration IPv6 snooping configuration
----------------------	---

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	The limit address-count command limits the number of IPv6 addresses allowed to be used on the port on which the policy is applied. Limiting the number of IPv6 addresses on a port helps limit the binding table size. The range is from 1 to 10000.
-------------------------	---

This example shows how to define an NDP policy name as policy1, place the switch in NDP inspection policy configuration mode, and limit the number of IPv6 addresses allowed on the port to 25:

```
Device(config)# ipv6 nd inspection policy policy1
Device(config-nd-inspection)# limit address-count 25
```

This example shows how to define an IPv6 snooping policy name as policy1, place the switch in IPv6 snooping policy configuration mode, and limit the number of IPv6 addresses allowed on the port to 25:

```
Device(config)# ipv6 snooping policy policy1
Device(config-ipv6-snooping)# limit address-count 25
```

mab request format attribute 32

To enable VLAN ID-based MAC authentication on a switch, use the **mab request format attribute 32 vlan access-vlan** command in global configuration mode. To return to the default setting, use the **no** form of this command.

```
mab request format attribute 32 vlan access-vlan
no mab request format attribute 32 vlan access-vlan
```

Syntax Description	This command has no arguments or keywords.	
Command Default	VLAN-ID based MAC authentication is disabled.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	<p>Use this command to allow a RADIUS server to authenticate a new user based on the host MAC address and VLAN.</p> <p>Use this feature on networks with the Microsoft IAS RADIUS server. The Cisco ACS ignores this command.</p> <p>This example shows how to enable VLAN-ID based MAC authentication on a switch:</p> <pre>Device(config)# mab request format attribute 32 vlan access-vlan</pre>	

Related Commands	Command	Description
	authentication event	Sets the action for specific authentication events.
	authentication fallback	Configures a port to use web authentication as a fallback method for clients that do not support IEEE 802.1x authentication.
	authentication host-mode	Sets the authorization manager mode on a port.
	authentication open	Enables or disables open access on a port.
	authentication order	Sets the order of authentication methods used on a port.
	authentication periodic	Enables or disables reauthentication on a port.
	authentication port-control	Enables manual control of the port authorization state.
	authentication priority	Adds an authentication method to the port-priority list.

Command	Description
authentication timer	Configures the timeout and reauthentication parameters for an 802.1x-enabled port.
authentication violation	Configures the violation modes that occur when a new device connects to a port or when a new device connects to a port with the maximum number of devices already connected to that port.
mab	Enables MAC-based authentication on a port.
mab eap	Configures a port to use the Extensible Authentication Protocol (EAP).
show authentication	Displays information about authentication manager events on the switch.

match (access-map configuration)

To set the VLAN map to match packets against one or more access lists, use the **match** command in access-map configuration mode on the switch stack or on a standalone switch. To remove the match parameters, use the **no** form of this command.

```
match ip address {namenumber} [{namenumber}] [{namenumber}] . . . | mac address {name}
[name] [name] . . . }
no match ip address {namenumber} [{namenumber}] [{namenumber}] . . . | mac address {name}
[name] [name] . . . }
```

Syntax Description	
ip address	Sets the access map to match packets against an IP address access list.
mac address	Sets the access map to match packets against a MAC address access list.
<i>name</i>	Name of the access list to match packets against.
<i>number</i>	Number of the access list to match packets against. This option is not valid for MAC access lists.

Command Default The default action is to have no match parameters applied to a VLAN map.

Command Modes Access-map configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines

You enter access-map configuration mode by using the **vlan access-map** global configuration command.

You must enter one access list name or number; others are optional. You can match packets against one or more access lists. Matching any of the lists counts as a match of the entry.

In access-map configuration mode, use the **match** command to define the match conditions for a VLAN map applied to a VLAN. Use the **action** command to set the action that occurs when the packet matches the conditions.

Packets are matched only against access lists of the same protocol type; IP packets are matched against IP access lists, and all other packets are matched against MAC access lists.

Both IP and MAC addresses can be specified for the same map entry.

This example shows how to define and apply a VLAN access map vmap4 to VLANs 5 and 6 that will cause the interface to drop an IP packet if the packet matches the conditions defined in access list al2:

```
Device(config)# vlan access-map vmap4
Device(config-access-map)# match ip address al2
Device(config-access-map)# action drop
Device(config-access-map)# exit
Device(config)# vlan filter vmap4 vlan-list 5-6
```

You can verify your settings by entering the **show vlan access-map** privileged EXEC command.

Related Topics

[show vlan access-map](#), on page 1034

[vlan access-map](#), on page 1064

no authentication logging verbose

To filter detailed information from authentication system messages, use the **no authentication logging verbose** command in global configuration mode on the switch stack or on a standalone switch.

no authentication logging verbose

Syntax Description

This command has no arguments or keywords.

Command Default

All details are displayed in the system messages.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

This command filters details, such as anticipated success, from authentication system messages. Failure messages are not filtered.

To filter verbose authentication system messages:

```
Device(config)# no authentication logging verbose
```

You can verify your settings by entering the **show running-config** privileged EXEC command.

Related Commands

Command	Description
no authentication logging verbose	Filters details from authentication system messages.
no dot1x logging verbose	Filters details from 802.1x system messages.
no mab logging verbose	Filters details from MAC authentication bypass (MAB) system messages.

no dot1x logging verbose

To filter detailed information from 802.1x system messages, use the **no dot1x logging verbose** command in global configuration mode on the switch stack or on a standalone switch.

no dot1x logging verbose

Syntax Description This command has no arguments or keywords.

Command Default All details are displayed in the system messages.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines This command filters details, such as anticipated success, from 802.1x system messages. Failure messages are not filtered.

To filter verbose 802.1x system messages:

```
Device(config)# no dot1x logging verbose
```

You can verify your settings by entering the **show running-config** privileged EXEC command.

Related Commands	Command	Description
	no authentication logging verbose	Filters details from authentication system messages.
	no dot1x logging verbose	Filters details from 802.1x system messages.
	no mab logging verbose	Filters details from MAC authentication bypass (MAB) system messages.

no mab logging verbose

To filter detailed information from MAC authentication bypass (MAB) system messages, use the **no mab logging verbose** command in global configuration mode on the switch stack or on a standalone switch.

no mab logging verbose

Syntax Description

This command has no arguments or keywords.

Command Default

All details are displayed in the system messages.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

This command filters details, such as anticipated success, from MAC authentication bypass (MAB) system messages. Failure messages are not filtered.

To filter verbose MAB system messages:

```
Device(config)# no mab logging verbose
```

You can verify your settings by entering the **show running-config** privileged EXEC command.

Related Commands

Command	Description
no authentication logging verbose	Filters details from authentication system messages.
no dot1x logging verbose	Filters details from 802.1x system messages.
no mab logging verbose	Filters details from MAC authentication bypass (MAB) system messages.

permit (MAC access-list configuration)

To allow non-IP traffic to be forwarded if the conditions are matched, use the **permit** MAC access-list configuration command on the switch stack or on a standalone switch. To remove a permit condition from the extended MAC access list, use the **no** form of this command.

```
{permit {any | hostsrc-MAC-addr | src-MAC-addr mask} {any | hostdst-MAC-addr |
dst-MAC-addr mask} [type mask | aarp | amber | appletalk | dec-spanning | decnet-iv |
diagnostic | dsm | etype-6000 | etype-8042 | lat | lavc-sca | lsaplsap mask | mop-console
| mop-dump | msdos | mumps | netbios | vines-echo | vines-ip | xns-idp] [coscos]
nopermit {any | host src-MAC-addr | src-MAC-addr mask} {any | host dst-MAC-addr |
dst-MAC-addr mask} [type mask | aarp | amber | appletalk | dec-spanning | decnet-iv |
diagnostic | dsm | etype-6000 | etype-8042 | lat | lavc-sca | lsap lsap mask | mop-console
| mop-dump | msdos | mumps | netbios | vines-echo | vines-ip | xns-idp] [coscos]
```

Syntax Description

any	Denies any source or destination MAC address.
host <i>src-MAC-addr</i> <i>src-MAC-addr mask</i>	Specifies a host MAC address and optional subnet mask. If the source address for a packet matches the defined address, non-IP traffic from that address is denied.
host <i>dst-MAC-addr</i> <i>dst-MAC-addr mask</i>	Specifies a destination MAC address and optional subnet mask. If the destination address for a packet matches the defined address, non-IP traffic to that address is denied.
<i>type mask</i>	(Optional) Specifies the EtherType number of a packet with Ethernet II or SNAP encapsulation to identify the protocol of the packet. <ul style="list-style-type: none"> <i>type</i> is 0 to 65535, specified in hexadecimal. <i>mask</i> is a mask of don't care bits applied to the EtherType before testing for a match.
aarp	(Optional) Specifies EtherType AppleTalk Address Resolution Protocol that maps a data-link address to a network address.
amber	(Optional) Specifies EtherType DEC-Amber.
appletalk	(Optional) Specifies EtherType AppleTalk/EtherTalk.
dec-spanning	(Optional) Specifies EtherType Digital Equipment Corporation (DEC) spanning tree.
decnet-iv	(Optional) Specifies EtherType DECnet Phase IV protocol.
diagnostic	(Optional) Specifies EtherType DEC-Diagnostic.

dsm	(Optional) Specifies EtherType DEC-DSM.
etype-6000	(Optional) Specifies EtherType 0x6000.
etype-8042	(Optional) Specifies EtherType 0x8042.
lat	(Optional) Specifies EtherType DEC-LAT.
lavc-sca	(Optional) Specifies EtherType DEC-LAVC-SCA.
lsap <i>lsap-number mask</i>	(Optional) Specifies the LSAP number (0 to 65535) of a packet with 802.2 encapsulation to identify the protocol of the packet. The <i>mask</i> is a mask of don't care bits applied to the LSAP number before testing for a match.
mop-console	(Optional) Specifies EtherType DEC-MOP Remote Console.
mop-dump	(Optional) Specifies EtherType DEC-MOP Dump.
msdos	(Optional) Specifies EtherType DEC-MSDOS.
mumps	(Optional) Specifies EtherType DEC-MUMPS.
netbios	(Optional) Specifies EtherType DEC- Network Basic Input/Output System (NetBIOS).
vines-echo	(Optional) Specifies EtherType Virtual Integrated Network Service (VINES) Echo from Banyan Systems.
vines-ip	(Optional) Specifies EtherType VINES IP.
xns-idp	(Optional) Specifies EtherType Xerox Network Systems (XNS) protocol suite.
cos <i>cos</i>	(Optional) Specifies an arbitrary class of service (CoS) number from 0 to 7 to set priority. Filtering on CoS can be performed only in hardware. A warning message appears if the cos option is configured.

Command Default This command has no defaults. However, the default action for a MAC-named ACL is to deny.

Command Modes Mac-access list configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Though visible in the command-line help strings, **appletalk** is not supported as a matching condition.

You enter MAC access-list configuration mode by using the **mac access-list extended** global configuration command.

If you use the **host** keyword, you cannot enter an address mask; if you do not use the **any** or **host** keywords, you must enter an address mask.

After an access control entry (ACE) is added to an access control list, an implied **deny-any-any** condition exists at the end of the list. That is, if there are no matches, the packets are denied. However, before the first ACE is added, the list permits all packets.

To filter IPX traffic, you use the *type mask* or **lsap lsap mask** keywords, depending on the type of IPX encapsulation being used. Filter criteria for IPX encapsulation types as specified in Novell terminology and Cisco IOS terminology are listed in the following table.

Table 36: IPX Filtering Criteria

IPX Encapsulation Type		Filter Criterion
Cisco IOS Name	Novell Name	
arpa	Ethernet II	EtherType 0x8137
snap	Ethernet-snap	EtherType 0x8137
sap	Ethernet 802.2	LSAP 0xE0E0
novell-ether	Ethernet 802.3	LSAP 0xFFFF

This example shows how to define the MAC-named extended access list to allow NetBIOS traffic from any source to MAC address 00c0.00a0.03fa. Traffic matching this list is allowed.

```
Device(config-ext-macl)# permit any host 00c0.00a0.03fa netbios
```

This example shows how to remove the permit condition from the MAC-named extended access list:

```
Device(config-ext-macl)# no permit any 00c0.00a0.03fa 0000.0000.0000 netbios
```

This example permits all packets with EtherType 0x4321:

```
Device(config-ext-macl)# permit any any 0x4321 0
```

You can verify your settings by entering the **show access-lists** privileged EXEC command.

Related Commands

Command	Description
deny	Denies from the MAC access-list configuration. Denies non-IP traffic to be forwarded if conditions are matched.
mac access-list extended	Creates an access list based on MAC addresses for non-IP traffic.

Command	Description
show access-lists	Displays access control lists configured on a switch.

protocol (IPv6 snooping)

To specify that addresses should be gleaned with Dynamic Host Configuration Protocol (DHCP) or Neighbor Discovery Protocol (NDP), or to associate the protocol with an IPv6 prefix list, use the **protocol** command. To disable address gleaning with DHCP or NDP, use the **no** form of the command.

```
protocol { dhcp | ndp }
no protocol { dhcp | ndp }
```

Syntax Description

dhcp Specifies that addresses should be gleaned in Dynamic Host Configuration Protocol (DHCP) packets.

ndp Specifies that addresses should be gleaned in Neighbor Discovery Protocol (NDP) packets.

Command Default

Snooping and recovery are attempted using both DHCP and NDP.

Command Modes

IPv6 snooping configuration mode

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

If an address does not match the prefix list associated with DHCP or NDP, then control packets will be dropped and recovery of the binding table entry will not be attempted with that protocol.

- Using the **no protocol** { **dhcp** | **ndp** } command indicates that a protocol will not be used for snooping or gleaning.
- If the **no protocol dhcp** command is used, DHCP can still be used for binding table recovery.
- Data glean can recover with DHCP and NDP, though destination guard will only recovery through DHCP.

This example shows how to define an IPv6 snooping policy name as policy1, place the switch in IPv6 snooping policy configuration mode, and configure the port to use DHCP to glean addresses:

```
Device(config)# ipv6 snooping policy policy1
Device(config-ipv6-snooping)# protocol dhcp
```

radius server



Note Starting from Cisco IOS 15.2(5)E release, the **radius server** command replaces the **radius-server host** command, being used in releases prior to Cisco IOS Release 15.2(5)E. The old command has been deprecated.

Use the **radius server** configuration sub-mode command on the switch stack or on a standalone switch to configure the RADIUS server parameters, including the RADIUS accounting and authentication. Use the **no** form of this command to return to the default settings.

```
radius server name
address {ipv4 | ipv6} ip{address | hostname} auth-port udp-port acct-port udp-port
key string
automate tester name | retransmit value | timeout seconds
no radius server name
```

Syntax Description

address { ipv4 ipv6 }	<i>ip{address hostname}</i>	Specify the IP address of the RADIUS server.
auth-port <i>udp-port</i>		(Optional) Specify the UDP port for the RADIUS authentication server. The range is from 0 to 65536.
acct-port <i>udp-port</i>		(Optional) Specify the UDP port for the RADIUS accounting server. The range is from 0 to 65536.
key <i>string</i>		(Optional) Specify the authentication and encryption key for all RADIUS communication between the switch and the RADIUS daemon. Note The key is a text string that must match the encryption key used on the RADIUS server. Always configure the key as the last item in this command. Leading spaces are ignored, but spaces within and at the end of the key are used. If there are spaces in your key, do not enclose the key in quotation marks unless the quotation marks are part of the key.
automate tester <i>name</i>		(Optional) Enable automatic server testing of the RADIUS server status, and specify the username to be used.
retransmit <i>value</i>		(Optional) Specifies the number of times a RADIUS request is resent when the server is not responding or responding slowly. The range is 1 to 100. This setting overrides the radius-server retransmit global configuration command setting.
timeout <i>seconds</i>		(Optional) Specifies the time interval that the Switch waits for the RADIUS server to reply before sending a request again. The range is 1 to 1000. This setting overrides the radius-server timeout global configuration command setting.
no radius server <i>name</i>		Returns to the default settings

Command Default

- The UDP port for the RADIUS accounting server is 1646.
- The UDP port for the RADIUS authentication server is 1645.
- Automatic server testing is disabled.
- The timeout is 60 minutes (1 hour).
- When the automatic testing is enabled, testing occurs on the accounting and authentication UDP ports.
- The authentication and encryption key (string) is not configured.

Command Modes

Radius server sub-mode configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced to replace the radius-server host command.

Usage Guidelines

- We recommend that you configure the UDP port for the RADIUS accounting server and the UDP port for the RADIUS authentication server to non-default values.
- You can configure the authentication and encryption key by using the **key string** sub-mode configuration command. Always configure the key as the last item in this command.
- Use the **automate-tester name** keywords to enable automatic server testing of the RADIUS server status and to specify the username to be used.

This example shows how to configure 1645 as the UDP port for the authentication server and 1646 as the UDP port for the accounting server, and configure a key string:

```
Device(config)# radius server ISE
Device(config-radius-server)# address ipv4 10.1.1 auth-port 1645 acct-port 1646
Device(config-radius-server)# key cisco123
```

security level (IPv6 snooping)

To specify the level of security enforced, use the **security-level** command in IPv6 snooping policy configuration mode.

security level { **glean** | **guard** | **inspect** }

Syntax Description	glean	Extracts addresses from the messages and installs them into the binding table without performing any verification.
	guard	Performs both glean and inspect. Additionally, RA and DHCP server messages are rejected unless they are received on a trusted port or another policy authorizes them.
	inspect	Validates messages for consistency and conformance; in particular, address ownership is enforced. Invalid messages are dropped.
Command Default	The default security level is guard.	
Command Modes	IPv6 snooping configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to define an IPv6 snooping policy name as policy1, place the device in IPv6 snooping configuration mode, and configure the security level as inspect:

```
Device(config)# ipv6 snooping policy policy1
Device(config-ipv6-snooping)# security-level inspect
```

server-private (RADIUS)

To configure the IP address of the private RADIUS server for the group server, use the **server-private** command in RADIUS server-group configuration mode. To remove the associated private server from the authentication, authorization, and accounting (AAA) group server, use the **no** form of this command.

server-private *ip-address* [{**auth-port** *port-number* | **acct-port** *port-number*}] [**non-standard**] [**timeout** *seconds*] [**retransmit** *retries*] [**key** *string*]

no server-private *ip-address* [{**auth-port** *port-number* | **acct-port** *port-number*}] [**non-standard**] [**timeout** *seconds*] [**retransmit** *retries*] [**key** *string*]

Syntax Description

<i>ip-address</i>	IP address of the private RADIUS server host.
auth-port <i>port-number</i>	(Optional) User Datagram Protocol (UDP) destination port for authentication requests. The default value is 1645.
acct-port <i>port-number</i>	(Optional) UDP destination port for accounting requests. The default value is 1646.
non-standard	(Optional) RADIUS server is using vendor-proprietary RADIUS attributes.
timeout <i>seconds</i>	(Optional) Time interval (in seconds) that the router waits for the RADIUS server to reply before retransmitting. This setting overrides the global value of the radius-server timeout command. If no timeout value is specified, the global value is used.
retransmit <i>retries</i>	(Optional) Number of times a RADIUS request is resent to a server, if that server is not responding or responding slowly. This setting overrides the global setting of the radius-server retransmit command.
key <i>string</i>	(Optional) Authentication and encryption key used between the router and the RADIUS daemon running on the RADIUS server. This key overrides the global setting of the radius-server key command. If no key string is specified, the global value is used. The <i>string</i> can be 0 (specifies that an unencrypted key follows), 6 (specifies that an advanced encryption scheme [AES] encrypted key follows), 7 (specifies that a hidden key follows), or a line specifying the unencrypted (clear-text) server key.

Command Default

If server-private parameters are not specified, global configurations will be used; if global configurations are not specified, default values will be used.

Command Modes

RADIUS server-group configuration (config-sg-radius)

Command History

Release	Modification
Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines

Use the **server-private** command to associate a particular private server with a defined server group. To prevent possible overlapping of private addresses between virtual route forwarding (VRF) instances, private servers (servers with private addresses) can be defined within the server group and remain hidden from other groups, while the servers in the global pool (default "radius" server group) can still be referred to by IP addresses and port numbers. Thus, the list of servers in server groups includes references to the hosts in the global configuration and the definitions of private servers.

**Note**

- If the **radius-server directed-request** command is configured, then a private RADIUS server cannot be used as the group server by configuring the **server-private (RADIUS)** command.
- Creating or updating AAA server statistics record for private RADIUS servers are not supported. If private RADIUS servers are used, then error messages and tracebacks will be encountered, but these error messages or tracebacks do not have any impact on the AAA RADIUS functionality. To avoid these error messages and tracebacks, configure public RADIUS server instead of private RADIUS server.

Use the **password encryption aes** command to configure type 6 AES encrypted keys.

Examples

The following example shows how to define the sg_water RADIUS group server and associate private servers with it:

```
Device> enable
Device# configure terminal
Device(config)# aaa new-model
Device(config)# aaa group server radius sg_water
Device(config-sg-radius)# server-private 10.1.1.1 timeout 5 retransmit 3 key xyz
Device(config-sg-radius)# server-private 10.2.2.2 timeout 5 retransmit 3 key xyz
```

Related Commands

Command	Description
aaa group server	Groups different server hosts into distinct lists and distinct methods.
aaa new-model	Enables the AAA access control model.
password encryption aes	Enables a type 6 encrypted preshared key.
radius-server host	Specifies a RADIUS server host.
radius-server directed-request	Allows users to log in to a Cisco NAS and select a RADIUS server for authentication.

show aaa clients

To show AAA client statistics, use the **show aaa clients** command.

show aaa clients [**detailed**]

Syntax Description	detailed (Optional) Shows detailed AAA client statistics.	
Command Modes	User EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This is an example of output from the **show aaa clients** command:

```
Device# show aaa clients
Dropped request packets: 0
```

show aaa command handler

To show AAA command handler statistics, use the **show aaa command handler** command.

show aaa command handler

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Modes	User EXEC
----------------------	-----------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE

This is an example of output from the **show aaa command handler** command:

```
Device# show aaa command handler

AAA Command Handler Statistics:
  account-logon: 0, account-logoff: 0
  account-query: 0, pod: 0
  service-logon: 0, service-logoff: 0
  user-profile-push: 0, session-state-log: 0
  reauthenticate: 0, bounce-host-port: 0
  disable-host-port: 0, update-rbacl: 0
  update-sgt: 0, update-cts-policies: 0
  invalid commands: 0
  async message not sent: 0
```

show aaa local

To show AAA local method options, use the **show aaa local** command.

show aaa local { **netuser** { *name* | **all** } | **statistics** | **user lockout** }

Syntax Description

netuser	Specifies the AAA local network or guest user database.
<i>name</i>	Network user name.
all	Specifies the network and guest user information.
statistics	Displays statistics for local authentication.
user lockout	Specifies the AAA local locked-out user.

Command Modes

User EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

This is an example of output from the **show aaa local statistics** command:

```
Device# show aaa local statistics

Local EAP statistics

EAP Method          Success      Fail
-----
Unknown              0            0
EAP-MD5               0            0
EAP-GTC               0            0
LEAP                  0            0
PEAP                  0            0
EAP-TLS               0            0
EAP-MSCHAPV2         0            0
EAP-FAST              0            0

Requests received from AAA:          0
Responses returned from EAP:        0
Requests dropped (no EAP AVP):       0
Requests dropped (other reasons):    0
Authentication timeouts from EAP:    0

Credential request statistics
Requests sent to backend:             0
Requests failed (unable to send):    0
Authorization results received

Success:                               0
Fail:                                  0
```

show aaa servers

To shows all AAA servers as seen by the AAA server MIB, use the **show aaa servers** command.

show aaa servers [**private** | **public** | [**detailed**]]

Syntax Description		
	detailed	(Optional) Displays private AAA servers as seen by the AAA Server MIB.
	public	(Optional) Displays public AAA servers as seen by the AAA Server MIB.
	detailed	(Optional) Displays detailed AAA server statistics.
Command Modes	User EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This is an example of output from the **show aaa servers** command:

```
Device# show aaa servers
RADIUS: id 1, priority 1, host 172.20.128.2, auth-port 1645, acct-port 1646
State: current UP, duration 9s, previous duration 0s
Dead: total time 0s, count 0
Quarantined: No
Authen: request 0, timeouts 0, failover 0, retransmission 0
Response: accept 0, reject 0, challenge 0
Response: unexpected 0, server error 0, incorrect 0, time 0ms
Transaction: success 0, failure 0
Throttled: transaction 0, timeout 0, failure 0
Author: request 0, timeouts 0, failover 0, retransmission 0
Response: accept 0, reject 0, challenge 0
Response: unexpected 0, server error 0, incorrect 0, time 0ms
Transaction: success 0, failure 0
Throttled: transaction 0, timeout 0, failure 0
Account: request 0, timeouts 0, failover 0, retransmission 0
Request: start 0, interim 0, stop 0
Response: start 0, interim 0, stop 0
Response: unexpected 0, server error 0, incorrect 0, time 0ms
Transaction: success 0, failure 0
Throttled: transaction 0, timeout 0, failure 0
Elapsed time since counters last cleared: 0m
Estimated Outstanding Access Transactions: 0
Estimated Outstanding Accounting Transactions: 0
Estimated Throttled Access Transactions: 0
Estimated Throttled Accounting Transactions: 0
Maximum Throttled Transactions: access 0, accounting 0
```

show aaa sessions

To show AAA sessions as seen by the AAA Session MIB, use the **show aaa sessions** command.

show aaa sessions

Syntax Description This command has no arguments or keywords.

Command Modes User EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This is an example of output from the **show aaa sessions** command:

```
Device# show aaa sessions
Total sessions since last reload: 7
Session Id: 4007
  Unique Id: 4025
  User Name: *not available*
  IP Address: 0.0.0.0
  Idle Time: 0
  CT Call Handle: 0
```

show authentication sessions

To display information about current Auth Manager sessions, use the **show authentication sessions** command.

```
show authentication sessions [database] [handle handle-id [details]] [interface type number
[details] [mac mac-address [interface type number] [method method-name [interface type number
[details] [session-id session-id [details]]]
```

Syntax Description

database	(Optional) Shows only data stored in session database.
handle <i>handle-id</i>	(Optional) Specifies the particular handle for which Auth Manager information is to be displayed.
details	(Optional) Shows detailed information.
interface <i>type number</i>	(Optional) Specifies a particular interface type and number for which Auth Manager information is to be displayed.
mac <i>mac-address</i>	(Optional) Specifies the particular MAC address for which you want to display information.
method <i>method-name</i>	(Optional) Specifies the particular authentication method for which Auth Manager information is to be displayed. If you specify a method (dot1x , mab , or webauth), you may also specify an interface.
session-id <i>session-id</i>	(Optional) Specifies the particular session for which Auth Manager information is to be displayed.

Command Modes

User EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **show authentication sessions** command to display information about all current Auth Manager sessions. To display information about specific Auth Manager sessions, use one or more of the keywords.

This table shows the possible operating states for the reported authentication sessions.

Table 37: Authentication Method States

State	Description
Not run	The method has not run for this session.
Running	The method is running for this session.
Failed over	The method has failed and the next method is expected to provide a result.

State	Description
Success	The method has provided a successful authentication result for the session.
Authc Failed	The method has provided a failed authentication result for the session.

This table shows the possible authentication methods.

Table 38: Authentication Method States

State	Description
dot1x	802.1X
mab	MAC authentication bypass
webauth	web authentication

The following example shows how to display all authentication sessions on the switch:

```
Device# show authentication sessions
Interface  MAC Address  Method  Domain  Status  Session ID
Gi1/0/48   0015.63b0.f676  dot1x   DATA   Authz Success  0A3462B1000000102983C05C
Gi1/0/5    000f.23c4.a401  mab     DATA   Authz Success  0A3462B10000000D24F80B58
Gi1/0/5    0014.bf5d.d26d  dot1x   DATA   Authz Success  0A3462B10000000E29811B94
```

The following example shows how to display all authentication sessions on an interface:

```
Device# show authentication sessions interface gigabitethernet2/0/47
      Interface: GigabitEthernet2/0/47
      MAC Address: Unknown
      IP Address: Unknown
      Status: Authz Success
      Domain: DATA
      Oper host mode: multi-host
      Oper control dir: both
      Authorized By: Guest Vlan
      Vlan Policy: 20
      Session timeout: N/A
      Idle timeout: N/A
      Common Session ID: 0A3462C80000000000002763C
      Acct Session ID: 0x00000002
      Handle: 0x25000000
Runnable methods list:
      Method  State
      mab     Failed over
      dot1x   Failed over
-----
      Interface: GigabitEthernet2/0/47
      MAC Address: 0005.5e7c.da05
      IP Address: Unknown
      User-Name: 00055e7cda05
      Status: Authz Success
      Domain: VOICE
      Oper host mode: multi-domain
```

```
Oper control dir: both
  Authorized By: Authentication Server
  Session timeout: N/A
  Idle timeout: N/A
Common Session ID: 0A3462C8000000010002A238
  Acct Session ID: 0x00000003
  Handle: 0x91000001
Runnable methods list:
  Method      State
  mab         Authc Success
  dot1x       Not run
```

show dot1x

To display IEEE 802.1x statistics, administrative status, and operational status for the switch or for the specified port, use the **show dot1x** command in user EXEC mode.

show dot1x [**all** [**count** | **details** | **statistics** | **summary**]] [**interface type number** [**details** | **statistics**]] [**statistics**]

Syntax Description		
all	(Optional) Displays the IEEE 802.1x information for all interfaces.	
count	(Optional) Displays total number of authorized and unauthorized clients.	
details	(Optional) Displays the IEEE 802.1x interface details.	
statistics	(Optional) Displays the IEEE 802.1x statistics for all interfaces.	
summary	(Optional) Displays the IEEE 802.1x summary for all interfaces.	
interface type number	(Optional) Displays the IEEE 802.1x status for the specified port.	

Command Modes User EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

This is an example of output from the **show dot1x all** command:

```
Device# show dot1x all
Sysauthcontrol           Enabled
Dot1x Protocol Version   3
```

This is an example of output from the **show dot1x all count** command:

```
Device# show dot1x all count
Number of Dot1x sessions
-----
Authorized Clients       = 0
UnAuthorized Clients     = 0
Total No of Client      = 0
```

This is an example of output from the **show dot1x all statistics** command:

```
Device# show dot1x statistics
Dot1x Global Statistics for
-----
RxStart = 0      RxLogoff = 0      RxResp = 0      RxRespID = 0
RxReq = 0        RxInvalid = 0    RxLenErr = 0
RxTotal = 0
```

```
TxStart = 0      TxLogoff = 0      TxResp = 0
TxReq = 0        ReTxReq = 0        ReTxReqFail = 0
TxReqID = 0      ReTxReqID = 0      ReTxReqIDFail = 0
TxTotal = 0
```

show eap pac peer

To display stored Protected Access Credentials (PAC) for Extensible Authentication Protocol (EAP) Flexible Authentication via Secure Tunneling (FAST) peers, use the **show eap pac peer** command in privileged EXEC mode.

show eap pac peer

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This is an example of output from the **show eap pac peers** privileged EXEC command:

```
Device> show eap pac peers
No PACs stored
```

Related Commands

Command	Description
clear eap sessions	Clears EAP session information for the switch or for the specified port.

show ip dhcp snooping statistics

To display DHCP snooping statistics in summary or detail form, use the **show ip dhcp snooping statistics** command in user EXEC mode.

show ip dhcp snooping statistics [**detail**]

Syntax Description

detail (Optional) Displays detailed statistics information.

Command Modes

User EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

In a switch stack, all statistics are generated on the stack master. If a new active switch is elected, the statistics counters reset.

This is an example of output from the **show ip dhcp snooping statistics** command:

```
Device> show ip dhcp snooping statistics

Packets Forwarded                = 0
Packets Dropped                  = 0
Packets Dropped From untrusted ports = 0
```

This is an example of output from the **show ip dhcp snooping statistics detail** command:

```
Device> show ip dhcp snooping statistics detail

Packets Processed by DHCP Snooping = 0
Packets Dropped Because
  IDB not known                    = 0
  Queue full                       = 0
  Interface is in errdisabled      = 0
  Rate limit exceeded              = 0
  Received on untrusted ports      = 0
  Nonzero giaddr                   = 0
  Source mac not equal to chaddr   = 0
  Binding mismatch                 = 0
  Insertion of opt82 fail          = 0
  Interface Down                   = 0
  Unknown output interface         = 0
  Reply output port equal to input port = 0
  Packet denied by platform        = 0
```

This table shows the DHCP snooping statistics and their descriptions:

Table 39: DHCP Snooping Statistics

DHCP Snooping Statistic	Description
Packets Processed by DHCP Snooping	Total number of packets handled by DHCP snooping, including forwarded and dropped packets.
Packets Dropped Because IDB not known	Number of errors when the input interface of the packet cannot be determined.
Queue full	Number of errors when an internal queue used to process the packets is full. This might happen if DHCP packets are received at an excessively high rate and rate limiting is not enabled on the ingress ports.
Interface is in errdisabled	Number of times a packet was received on a port that has been marked as error disabled. This might happen if packets are in the processing queue when a port is put into the error-disabled state and those packets are subsequently processed.
Rate limit exceeded	Number of times the rate limit configured on the port was exceeded and the interface was put into the error-disabled state.
Received on untrusted ports	Number of times a DHCP server packet (OFFER, ACK, NAK, or LEASEQUERY) was received on an untrusted port and was dropped.
Nonzero giaddr	Number of times the relay agent address field (giaddr) in the DHCP packet received on an untrusted port was not zero, or the no ip dhcp snooping information option allow-untrusted global configuration command is not configured and a packet received on an untrusted port contained option-82 data.
Source mac not equal to chaddr	Number of times the client MAC address field of the DHCP packet (chaddr) does not match the packet source MAC address and the ip dhcp snooping verify mac-address global configuration command is configured.
Binding mismatch	Number of times a RELEASE or DECLINE packet was received on a port that is different than the port in the binding for that MAC address-VLAN pair. This indicates someone might be trying to spoof the real client, or it could mean that the client has moved to another port on the switch and issued a RELEASE or DECLINE. The MAC address is taken from the chaddr field of the DHCP packet, not the source MAC address in the Ethernet header.
Insertion of opt82 fail	Number of times the option-82 insertion into a packet failed. The insertion might fail if the packet with the option-82 data exceeds the size of a single physical packet on the internet.

DHCP Snooping Statistic	Description
Interface Down	Number of times the packet is a reply to the DHCP relay agent, but the SVI interface for the relay agent is down. This is an unlikely error that occurs if the SVI goes down between sending the client request to the DHCP server and receiving the response.
Unknown output interface	Number of times the output interface for a DHCP reply packet cannot be determined by either option-82 data or a lookup in the MAC address table. The packet is dropped. This can happen if option 82 is not used and the client MAC address has aged out. If IPSG is enabled with the port-security option and option 82 is not enabled, the MAC address of the client is not learned, and the reply packets will be dropped.
Reply output port equal to input port	Number of times the output port for a DHCP reply packet is the same as the input port, causing a possible loop. Indicates a possible network misconfiguration or misuse of trust settings on ports.
Packet denied by platform	Number of times the packet has been denied by a platform-specific registry.

show radius server-group

To display properties for the RADIUS server group, use the **show radius server-group** command.

show radius server-group {*name* | **all**}

Syntax Description

name Name of the server group. The character string used to name the group of servers must be defined using the **aaa group server radius** command.

all Displays properties for all of the server groups.

Command Modes

User EXEC

Privileged EXEC

Command History

Release

Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE

Modification

This command was introduced.

Usage Guidelines

Use the **show radius server-group** command to display the server groups that you defined by using the **aaa group server radius** command.

This is an example of output from the **show radius server-group all** command:

```
Device# show radius server-group all
Server group radius
  Sharecount = 1  sg_unconfigured = FALSE
  Type = standard  Memlocks = 1
```

This table describes the significant fields shown in the display.

Table 40: show radius server-group command Field Descriptions

Field	Description
Server group	Name of the server group.
Sharecount	Number of method lists that are sharing this server group. For example, if one method list uses a particular server group, the sharecount would be 1. If two method lists use the same server group, the sharecount would be 2.
sg_unconfigured	Server group has been unconfigured.
Type	The type can be either standard or nonstandard. The type indicates whether the servers in the group accept nonstandard attributes. If all servers within the group are configured with the nonstandard option, the type will be shown as "nonstandard".

Field	Description
Memlocks	An internal reference count for the server-group structure that is in memory. The number represents how many internal data structure packets or transactions are holding references to this server group. Memlocks is used internally for memory management purposes.

show storm-control

To display broadcast, multicast, or unicast storm control settings on the switch or on the specified interface or to display storm-control history, use the **show storm-control** command in user EXEC mode.

show storm-control [*interface-id*] [**broadcast** | **multicast** | **unicast**]

Syntax Description

interface-id (Optional) Interface ID for the physical port (including type, stack member for stacking-capable switches, module, and port number).

broadcast (Optional) Displays broadcast storm threshold setting.

multicast (Optional) Displays multicast storm threshold setting.

unicast (Optional) Displays unicast storm threshold setting.

Command Modes

User EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

When you enter an interface ID, the storm control thresholds appear for the specified interface.

If you do not enter an interface ID, settings appear for one traffic type for all ports on the switch.

If you do not enter a traffic type, settings appear for broadcast storm control.

This is an example of a partial output from the **show storm-control** command when no keywords are entered. Because no traffic-type keyword was entered, the broadcast storm control settings appear.

```
Device> show storm-control
Interface Filter State Upper Lower Current
-----
Gi1/0/1 Forwarding 20 pps 10 pps 5 pps
Gi1/0/2 Forwarding 50.00% 40.00% 0.00%
<output truncated>
```

This is an example of output from the **show storm-control** command for a specified interface. Because no traffic-type keyword was entered, the broadcast storm control settings appear.

```
Device> show storm-control gigabitethernet 1/0/1
Interface Filter State Upper Lower Current
-----
Gi1/0/1 Forwarding 20 pps 10 pps 5 pps
```

The following table describes the fields in the show storm-control display:

Table 41: show storm-control Field Descriptions

Field	Description
Interface	Displays the ID of the interface.

Field	Description
Filter State	Displays the status of the filter: <ul style="list-style-type: none">• Blocking—Storm control is enabled, and a storm has occurred.• Forwarding—Storm control is enabled, and no storms have occurred.• Inactive—Storm control is disabled.
Upper	Displays the rising suppression level as a percentage of total available bandwidth in packets per second or in bits per second.
Lower	Displays the falling suppression level as a percentage of total available bandwidth in packets per second or in bits per second.
Current	Displays the bandwidth usage of broadcast traffic or the specified traffic type (broadcast, multicast, or unicast) as a percentage of total available bandwidth. This field is only valid when storm control is enabled.

show vlan access-map

To display information about a particular VLAN access map or for all VLAN access maps, use the **show vlan access-map** command in privileged EXEC mode.

show vlan access-map [*map-name*]

Syntax Description	<i>map-name</i> (Optional) Name of a specific VLAN access map.	
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This is an example of output from the **show vlan access-map** command:

```
Device# show vlan access-map
Vlan access-map "vmap4" 10
  Match clauses:
    ip address: a12
  Action:
    forward
Vlan access-map "vmap4" 20
  Match clauses:
    ip address: a12
  Action:
    forward
```

Related Topics

[vlan access-map](#), on page 1064

[vlan filter](#), on page 1066

show vlan group

To display the VLANs that are mapped to VLAN groups, use the **show vlan group** command in privileged EXEC mode.

```
show vlan group [{group-name vlan-group-name [user_count]}]
```

Syntax Description	group-name <i>vlan-group-name</i> (Optional) Displays the VLANs mapped to the specified VLAN group.	
	user_count (Optional) Displays the number of users in each VLAN mapped to a specified VLAN group.	
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The **show vlan group** command displays the existing VLAN groups and lists the VLANs and VLAN ranges that are members of each VLAN group. If you enter the **group-name** keyword, only the members of the specified VLAN group are displayed.

This example shows how to display the members of a specified VLAN group:

```
Device# show vlan group group-name group2
vlan group group1 :40-45
```

This example shows how to display number of users in each of the VLANs in a group:

```
Device# show vlan group group-name group2 user_count
VLAN      : Count
-----
40         : 5
41         : 8
42         : 12
43         : 2
44         : 9
45         : 0
```

Related Topics

[vlan group](#), on page 1067

storm-control

To enable broadcast, multicast, or unicast storm control and to set threshold levels on an interface, use the **storm-control** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

```
storm-control {action {shutdown | trap} | {broadcast | multicast | unicast} level {level [level-low] |
bps bps [bps-low] | pps pps [pps-low]}}
no storm-control {action {shutdown | trap} | {broadcast | multicast | unicast} level}
```

Syntax Description

action	Specifies the action taken when a storm occurs on a port. The default action is to filter traffic and to not send an Simple Network Management Protocol (SNMP) trap.
shutdown	Disables the port during a storm.
trap	Sends an SNMP trap when a storm occurs.
broadcast	Enables broadcast storm control on the interface.
multicast	Enables multicast storm control on the interface.
unicast	Enables unicast storm control on the interface.
level	Specifies the rising and falling suppression levels as a percentage of total bandwidth of the port.
<i>level</i>	Rising suppression level, up to two decimal places. The range is 0.00 to 100.00. Block the flooding of storm packets when the value specified for level is reached.
<i>level-low</i>	(Optional) Falling suppression level, up to two decimal places. The range is 0.00 to 100.00. This value must be less than or equal to the rising suppression value. If you do not configure a falling suppression level, it is set to the rising suppression level.
level bps	Specifies the rising and falling suppression levels as a rate in bits per second at which traffic is received on the port.
<i>bps</i>	Rising suppression level, up to 1 decimal place. The range is 0.0 to 10000000000.0. Block the flooding of storm packets when the value specified for bps is reached. You can use metric suffixes such as k, m, and g for large number thresholds.
<i>bps-low</i>	(Optional) Falling suppression level, up to 1 decimal place. The range is 0.0 to 10000000000.0. This value must be equal to or less than the rising suppression value. You can use metric suffixes such as k, m, and g for large number thresholds.
level pps	Specifies the rising and falling suppression levels as a rate in packets per second at which traffic is received on the port.
<i>pps</i>	Rising suppression level, up to 1 decimal place. The range is 0.0 to 10000000000.0. Block the flooding of storm packets when the value specified for pps is reached. You can use metric suffixes such as k, m, and g for large number thresholds.

pps-low (Optional) Falling suppression level, up to 1 decimal place. The range is 0.0 to 1000000000.0. This value must be equal to or less than the rising suppression value.

You can use metric suffixes such as k, m, and g for large number thresholds.

Command Default

Broadcast, multicast, and unicast storm control are disabled.

The default action is to filter traffic and to not send an SNMP trap.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
	This command was introduced.

Usage Guidelines

The storm-control suppression level can be entered as a percentage of total bandwidth of the port, as a rate in packets per second at which traffic is received, or as a rate in bits per second at which traffic is received.

When specified as a percentage of total bandwidth, a suppression value of 100 percent means that no limit is placed on the specified traffic type. A value of **level 0 0** means that all broadcast, multicast, or unicast traffic on that port is blocked. Storm control is enabled only when the rising suppression level is less than 100 percent. If no other storm-control configuration is specified, the default action is to filter the traffic causing the storm and to send no SNMP traps.



Note

When the storm control threshold for multicast traffic is reached, all multicast traffic except control traffic, such as bridge protocol data unit (BDPU) and Cisco Discovery Protocol (CDP) frames, are blocked. However, the switch does not differentiate between routing updates, such as Open Shortest Path First (OSPF) and regular multicast data traffic, so both types of traffic are blocked.

The **trap** and **shutdown** options are independent of each other.

If you configure the action to be taken as shutdown (the port is error-disabled during a storm) when a packet storm is detected, you must use the **no shutdown** interface configuration command to bring the interface out of this state. If you do not specify the **shutdown** action, specify the action as **trap** (the switch generates a trap when a storm is detected).

When a storm occurs and the action is to filter traffic, if the falling suppression level is not specified, the switch blocks all traffic until the traffic rate drops below the rising suppression level. If the falling suppression level is specified, the switch blocks traffic until the traffic rate drops below this level.



Note

Storm control is supported on physical interfaces. You can also configure storm control on an EtherChannel. When storm control is configured on an EtherChannel, the storm control settings propagate to the EtherChannel physical interfaces.

When a broadcast storm occurs and the action is to filter traffic, the switch blocks only broadcast traffic.

For more information, see the software configuration guide for this release.

This example shows how to enable broadcast storm control with a 75.5-percent rising suppression level:

```
Device(config-if)# storm-control broadcast level 75.5
```

This example shows how to enable unicast storm control on a port with a 87-percent rising suppression level and a 65-percent falling suppression level:

```
Device(config-if)# storm-control unicast level 87 65
```

This example shows how to enable multicast storm control on a port with a 2000-packets-per-second rising suppression level and a 1000-packets-per-second falling suppression level:

```
Device(config-if)# storm-control multicast level pps 2k 1k
```

This example shows how to enable the **shutdown** action on a port:

```
Device(config-if)# storm-control action shutdown
```

You can verify your settings by entering the **show storm-control** privileged EXEC command.

switchport port-security aging

To set the aging time and type for secure address entries or to change the aging behavior for secure addresses on a particular port, use the **switchport port-security aging** command in interface configuration mode. To disable port security aging or to set the parameters to their default states, use the **no** form of this command.

```
switchport port-security aging {static | time time | type {absolute | inactivity}}
no switchport port-security aging {static | time | type}
```

Syntax Description	
static	Enables aging for statically configured secure addresses on this port.
time <i>time</i>	Specifies the aging time for this port. The range is 0 to 1440 minutes. If the time is 0, aging is disabled for this port.
type	Sets the aging type.
absolute	Sets absolute aging type. All the secure addresses on this port age out exactly after the time (minutes) specified and are removed from the secure address list.
inactivity	Sets the inactivity aging type. The secure addresses on this port age out only if there is no data traffic from the secure source address for the specified time period.

Command Default	
	The port security aging feature is disabled. The default time is 0 minutes.
	The default aging type is absolute.
	The default static aging behavior is disabled.

Command Modes	
	Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	
	To enable secure address aging for a particular port, set the aging time to a value other than 0 for that port.
	To allow limited time access to particular secure addresses, set the aging type as absolute . When the aging time lapses, the secure addresses are deleted.
	To allow continuous access to a limited number of secure addresses, set the aging type as inactivity . This removes the secure address when it become inactive, and other addresses can become secure.
	To allow unlimited access to a secure address, configure it as a secure address, and disable aging for the statically configured secure address by using the no switchport port-security aging static interface configuration command.

This example sets the aging time as 2 hours for absolute aging for all the secure addresses on the port:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# switchport port-security aging time 120
```

This example sets the aging time as 2 minutes for inactivity aging type with aging enabled for configured secure addresses on the port:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# switchport port-security aging time 2
Device(config-if)# switchport port-security aging type inactivity
Device(config-if)# switchport port-security aging static
```

This example shows how to disable aging for configured secure addresses:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# no switchport port-security aging static
```

switchport port-security mac-address

To configure secure MAC addresses or sticky MAC address learning, use the **switchport port-security mac-address** interface configuration command. To return to the default setting, use the **no** form of this command.

```
switchport port-security mac-address {mac-address [{vlan {vlan-id {access | voice}}]} | sticky
[{mac-address | vlan {vlan-id {access | voice}}]}]
no switchport port-security mac-address {mac-address [{vlan {vlan-id {access | voice}}]} | sticky
[{mac-address | vlan {vlan-id {access | voice}}]}]
```

Syntax Description

mac-address	A secure MAC address for the interface by entering a 48-bit MAC address. You can add additional secure MAC addresses up to the maximum value configured.
vlan vlan-id	(Optional) On a trunk port only, specifies the VLAN ID and the MAC address. If no VLAN ID is specified, the native VLAN is used.
vlan access	(Optional) On an access port only, specifies the VLAN as an access VLAN.
vlan voice	(Optional) On an access port only, specifies the VLAN as a voice VLAN. Note The voice keyword is available only if voice VLAN is configured on a port and if that port is not the access VLAN.
sticky	Enables the interface for sticky learning. When sticky learning is enabled, the interface adds all secure MAC addresses that are dynamically learned to the running configuration and converts these addresses to sticky secure MAC addresses.
mac-address	(Optional) A MAC address to specify a sticky secure MAC address.

Command Default

No secure MAC addresses are configured.
Sticky learning is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

A secure port has the following limitations:

- A secure port can be an access port or a trunk port; it cannot be a dynamic access port.
- A secure port cannot be a routed port.
- A secure port cannot be a protected port.
- A secure port cannot be a destination port for Switched Port Analyzer (SPAN).
- A secure port cannot belong to a Gigabit or 10-Gigabit EtherChannel port group.

- You cannot configure static secure or sticky secure MAC addresses in the voice VLAN.
- When you enable port security on an interface that is also configured with a voice VLAN, set the maximum allowed secure addresses on the port to two. When the port is connected to a Cisco IP phone, the IP phone requires one MAC address. The Cisco IP phone address is learned on the voice VLAN, but is not learned on the access VLAN. If you connect a single PC to the Cisco IP phone, no additional MAC addresses are required. If you connect more than one PC to the Cisco IP phone, you must configure enough secure addresses to allow one for each PC and one for the Cisco IP phone.
- Voice VLAN is supported only on access ports and not on trunk ports.

Sticky secure MAC addresses have these characteristics:

- When you enable sticky learning on an interface by using the **switchport port-security mac-address sticky** interface configuration command, the interface converts all the dynamic secure MAC addresses, including those that were dynamically learned before sticky learning was enabled, to sticky secure MAC addresses and adds all sticky secure MAC addresses to the running configuration.
- If you disable sticky learning by using the **no switchport port-security mac-address sticky** interface configuration command or the running configuration is removed, the sticky secure MAC addresses remain part of the running configuration but are removed from the address table. The addresses that were removed can be dynamically reconfigured and added to the address table as dynamic addresses.
- When you configure sticky secure MAC addresses by using the **switchport port-security mac-address sticky mac-address** interface configuration command, these addresses are added to the address table and the running configuration. If port security is disabled, the sticky secure MAC addresses remain in the running configuration.
- If you save the sticky secure MAC addresses in the configuration file, when the switch restarts or the interface shuts down, the interface does not need to relearn these addresses. If you do not save the sticky secure addresses, they are lost. If sticky learning is disabled, the sticky secure MAC addresses are converted to dynamic secure addresses and are removed from the running configuration.
- If you disable sticky learning and enter the **switchport port-security mac-address sticky mac-address** interface configuration command, an error message appears, and the sticky secure MAC address is not added to the running configuration.

You can verify your settings by using the **show port-security** privileged EXEC command.

This example shows how to configure a secure MAC address and a VLAN ID on a port:

```
Device(config)# interface gigabitethernet 2/0/2
Device(config-if)# switchport mode trunk
Device(config-if)# switchport port-security
Device(config-if)# switchport port-security mac-address 1000.2000.3000 vlan 3
```

This example shows how to enable sticky learning and to enter two sticky secure MAC addresses on a port:

```
Device(config)# interface gigabitethernet 2/0/2
Device(config-if)# switchport port-security mac-address sticky
Device(config-if)# switchport port-security mac-address sticky 0000.0000.4141
Device(config-if)# switchport port-security mac-address sticky 0000.0000.000f
```

switchport port-security maximum

To configure the maximum number of secure MAC addresses, use the **switchport port-security maximum** command in interface configuration mode. To return to the default settings, use the **no** form of this command.

```
switchport port-security maximum value [vlan [{vlan-list} | [{access | voice}]]]
no switchport port-security maximum value [vlan [{vlan-list} | [{access | voice}]]]
```

Syntax Description

value Sets the maximum number of secure MAC addresses for the interface.
The default setting is 1.

vlan (Optional) For trunk ports, sets the maximum number of secure MAC addresses on a VLAN or range of VLANs. If the **vlan** keyword is not entered, the default value is used.

vlan-list (Optional) Range of VLANs separated by a hyphen or a series of VLANs separated by commas. For nonspecified VLANs, the per-VLAN maximum value is used.

access (Optional) On an access port only, specifies the VLAN as an access VLAN.

voice (Optional) On an access port only, specifies the VLAN as a voice VLAN.

Note The **voice** keyword is available only if voice VLAN is configured on a port and if that port is not the access VLAN.

Command Default

When port security is enabled and no keywords are entered, the default maximum number of secure MAC addresses is 1.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The maximum number of secure MAC addresses that you can configure on a switch or switch stack is set by the maximum number of available MAC addresses allowed in the system. This number is determined by the active Switch Database Management (SDM) template. See the **sdm prefer** command. This number represents the total of available MAC addresses, including those used for other Layer 2 functions and any other secure MAC addresses configured on interfaces.

A secure port has the following limitations:

- A secure port can be an access port or a trunk port.
- A secure port cannot be a routed port.
- A secure port cannot be a protected port.
- A secure port cannot be a destination port for Switched Port Analyzer (SPAN).
- A secure port cannot belong to a Gigabit or 10-Gigabit EtherChannel port group.

- When you enable port security on an interface that is also configured with a voice VLAN, set the maximum allowed secure addresses on the port to two. When the port is connected to a Cisco IP phone, the IP phone requires one MAC address. The Cisco IP phone address is learned on the voice VLAN, but is not learned on the access VLAN. If you connect a single PC to the Cisco IP phone, no additional MAC addresses are required. If you connect more than one PC to the Cisco IP phone, you must configure enough secure addresses to allow one for each PC and one for the Cisco IP phone.

Voice VLAN is supported only on access ports and not on trunk ports.

- When you enter a maximum secure address value for an interface, if the new value is greater than the previous value, the new value overrides the previously configured value. If the new value is less than the previous value and the number of configured secure addresses on the interface exceeds the new value, the command is rejected.

Setting a maximum number of addresses to one and configuring the MAC address of an attached device ensures that the device has the full bandwidth of the port.

When you enter a maximum secure address value for an interface, this occurs:

- If the new value is greater than the previous value, the new value overrides the previously configured value.
- If the new value is less than the previous value and the number of configured secure addresses on the interface exceeds the new value, the command is rejected.

You can verify your settings by using the **show port-security** privileged EXEC command.

This example shows how to enable port security on a port and to set the maximum number of secure addresses to 5. The violation mode is the default, and no secure MAC addresses are configured.

```
Device(config)# interface gigabitethernet 2/0/2
Device(config-if)# switchport mode access
Device(config-if)# switchport port-security
Device(config-if)# switchport port-security maximum 5
```

switchport port-security violation

To configure secure MAC address violation mode or the action to be taken if port security is violated, use the **switchport port-security violation** command in interface configuration mode. To return to the default settings, use the **no** form of this command.

```
switchport port-security violation {protect | restrict | shutdown | shutdown vlan}
no switchport port-security violation {protect | restrict | shutdown | shutdown vlan}
```

Syntax Description	protect	Sets the security violation protect mode.
	restrict	Sets the security violation restrict mode.
	shutdown	Sets the security violation shutdown mode.
	shutdown vlan	Sets the security violation mode to per-VLAN shutdown.
Command Default	The default violation mode is shutdown .	
Command Modes	Interface configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Usage Guidelines

In the security violation protect mode, when the number of port secure MAC addresses reaches the maximum limit allowed on the port, packets with unknown source addresses are dropped until you remove a sufficient number of secure MAC addresses to drop below the maximum value or increase the number of maximum allowable addresses. You are not notified that a security violation has occurred.



Note We do not recommend configuring the protect mode on a trunk port. The protect mode disables learning when any VLAN reaches its maximum limit, even if the port has not reached its maximum limit.

In the security violation restrict mode, when the number of secure MAC addresses reaches the limit allowed on the port, packets with unknown source addresses are dropped until you remove a sufficient number of secure MAC addresses or increase the number of maximum allowable addresses. An SNMP trap is sent, a syslog message is logged, and the violation counter increments.

In the security violation shutdown mode, the interface is error-disabled when a violation occurs and the port LED turns off. An SNMP trap is sent, a syslog message is logged, and the violation counter increments. When a secure port is in the error-disabled state, you can bring it out of this state by entering the **errdisable recovery cause psecure-violation** global configuration command, or you can manually re-enable it by entering the **shutdown** and **no shutdown** interface configuration commands.

When the security violation mode is set to per-VLAN shutdown, only the VLAN on which the violation occurred is error-disabled.

A secure port has the following limitations:

- A secure port can be an access port or a trunk port.
- A secure port cannot be a routed port.
- A secure port cannot be a protected port.
- A secure port cannot be a destination port for Switched Port Analyzer (SPAN).
- A secure port cannot belong to a Gigabit or 10-Gigabit EtherChannel port group.

A security violation occurs when the maximum number of secure MAC addresses are in the address table and a station whose MAC address is not in the address table attempts to access the interface or when a station whose MAC address is configured as a secure MAC address on another secure port attempts to access the interface.

When a secure port is in the error-disabled state, you can bring it out of this state by entering the **errdisable recovery cause psecure-violation** global configuration command. You can manually re-enable the port by entering the **shutdown** and **no shutdown** interface configuration commands or by using the **clear errdisable interface** privileged EXEC command.

You can verify your settings by using the **show port-security** privileged EXEC command.

This example show how to configure a port to shut down only the VLAN if a MAC security violation occurs:

```
Device(config)# interface gigabitethernet2/0/2
Device(config)# switchport port-security violation shutdown vlan
```

tacacs server

To configure the TACACS+ server for IPv6 or IPv4 and enter TACACS+ server configuration mode, use the **tacacs server** command in global configuration mode. To remove the configuration, use the **no** form of this command.

```
tacacs server name
no tacacs server
```

Syntax Description	name	Name of the private TACACS+ server host.
--------------------	------	--

Command Default No TACACS+ server is configured.

Command Modes Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The **tacacs server** command configures the TACACS server using the *name* argument and enters TACACS+ server configuration mode. The configuration is applied once you have finished configuration and exited TACACS+ server configuration mode.

Examples

The following example shows how to configure the TACACS server using the name `server1` and enter TACACS+ server configuration mode to perform further configuration:

```
Device(config)# tacacs server server1
Device(config-server-tacacs)#
```

Related Commands	Command	Description
	address ipv6 (TACACS+)	Configures the IPv6 address of the TACACS+ server.
	key (TACACS+)	Configures the per-server encryption key on the TACACS+ server.
	port (TACACS+)	Specifies the TCP port to be used for TACACS+ connections.
	send-nat-address (TACACS+)	Sends a client's post-NAT address to the TACACS+ server.
	single-connection (TACACS+)	Enables all TACACS packets to be sent to the same server using a single TCP connection.
	timeout (TACACS+)	Configures the time to wait for a reply from the specified TACACS server.

tracking (IPv6 snooping)

To override the default tracking policy on a port, use the **tracking** command in IPv6 snooping policy configuration mode.

tracking {**enable** [**reachable-lifetime** {*value* | **infinite**}] | **disable** [**stale-lifetime** {*value* | **infinite**}]}

Syntax Description		
enable		Enables tracking.
reachable-lifetime		(Optional) Specifies the maximum amount of time a reachable entry is considered to be directly or indirectly reachable without proof of reachability. <ul style="list-style-type: none"> The reachable-lifetime keyword can be used only with the enable keyword. Use of the reachable-lifetime keyword overrides the global reachable lifetime configured by the ipv6 neighbor binding reachable-lifetime command.
<i>value</i>		Lifetime value, in seconds. The range is from 1 to 86400, and the default is 300.
infinite		Keeps an entry in a reachable or stale state for an infinite amount of time.
disable		Disables tracking.
stale-lifetime		(Optional) Keeps the time entry in a stale state, which overwrites the global stale-lifetime configuration. <ul style="list-style-type: none"> The stale lifetime is 86,400 seconds. The stale-lifetime keyword can be used only with the disable keyword. Use of the stale-lifetime keyword overrides the global stale lifetime configured by the ipv6 neighbor binding stale-lifetime command.

Command Default The time entry is kept in a reachable state.

Command Modes IPv6 snooping configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The **tracking** command overrides the default tracking policy set by the **ipv6 neighbor tracking** command on the port on which this policy applies. This function is useful on trusted ports where, for example, you may not want to track entries but want an entry to stay in the binding table to prevent it from being stolen.

The **reachable-lifetime** keyword is the maximum time an entry will be considered reachable without proof of reachability, either directly through tracking or indirectly through IPv6 snooping. After the **reachable-lifetime** value is reached, the entry is moved to stale. Use of the **reachable-lifetime** keyword with the tracking command overrides the global reachable lifetime configured by the **ipv6 neighbor binding reachable-lifetime** command.

The **stale-lifetime** keyword is the maximum time an entry is kept in the table before it is deleted or the entry is proven to be reachable, either directly or indirectly. Use of the **reachable-lifetime** keyword with the **tracking** command overrides the global stale lifetime configured by the **ipv6 neighbor binding stale-lifetime** command.

This example shows how to define an IPv6 snooping policy name as policy1, place the switch in IPv6 snooping policy configuration mode, and configure an entry to stay in the binding table for an infinite length of time on a trusted port:

```
Device(config)# ipv6 snooping policy policy1
Device(config-ipv6-snooping)# tracking disable stale-lifetime infinite
```

trusted-port

To configure a port to become a trusted port, use the **trusted-port** command in IPv6 snooping policy mode or ND inspection policy configuration mode. To disable this function, use the **no** form of this command.

trusted-port
no trusted-port

Syntax Description This command has no arguments or keywords.

Command Default No ports are trusted.

Command Modes ND inspection policy configuration
 IPv6 snooping configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines When the **trusted-port** command is enabled, limited or no verification is performed when messages are received on ports that have this policy. However, to protect against address spoofing, messages are analyzed so that the binding information that they carry can be used to maintain the binding table. Bindings discovered from these ports will be considered more trustworthy than bindings received from ports that are not configured to be trusted.

This example shows how to define an NDP policy name as policy1, place the switch in NDP inspection policy configuration mode, and configure the port to be trusted:

```
Device(config)# ipv6 nd inspection policy1
Device(config-nd-inspection)# trusted-port
```

This example shows how to define an IPv6 snooping policy name as policy1, place the switch in IPv6 snooping policy configuration mode, and configure the port to be trusted:

```
Device(config)# ipv6 snooping policy policy1
Device(config-ipv6-snooping)# trusted-port
```

wireless dot11-padding

To enable over-the-air frame padding, use the **wireless dot11-padding** command. To disable, use the **no** form of the command.

wireless dot11-padding
no wireless dot11-padding

Command Default Disabled.

Command Modes config

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

This example shows how to enable over-the-air frame padding

```
Device#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
Device(config)#wireless dot11-padding
```

wireless security dot1x

To configure IEEE 802.1x global configurations, use the **wireless security dot1x** command.

```
wireless security dot1x [{eapol-key {retries retries | timeout milliseconds} | group-key interval
sec | identity-request {retries retries | timeout seconds} | radius [call-station-id] {ap-macaddress |
ap-macaddress-ssid | ipaddress | macaddress} | request {retries retries | timeout seconds} | wep key
{index 0 | index 3}}]
```

Syntax Description

eapol-key	Configures eapol-key related parameters.
retries <i>retries</i>	(Optional) Specifies the maximum number of times (0 to 4 retries) that the controller retransmits an EAPOL (WPA) key message to a wireless client. The default value is 2.
timeout <i>milliseconds</i>	(Optional) Specifies the amount of time (200 to 5000 milliseconds) that the controller waits before retransmitting an EAPOL (WPA) key message to a wireless client using EAP or WPA/WPA-2 PSK. The default value is 1000 milliseconds.
group-key interval <i>sec</i>	Configures EAP-broadcast key renew interval time in seconds (120 to 86400 seconds).
identity-request	Configures EAP ID request related parameters.
retries <i>retries</i>	(Optional) Specifies the maximum number of times (0 to 4 retries) that the controller request the EAP ID. The default value is 2.
timeout <i>seconds</i>	(Optional) Specifies the amount of time (1 to 120 seconds) that the controller waits before retransmitting an EAP Identity Request message to a wireless client. The default value is 30 seconds.
radius	Configures radius messages.
call-station-id	(Optional) Configures Call-Station Id sent in radius messages.
ap-macaddress	Sets Call Station Id Type to the AP's MAC Address.
ap-macaddress-ssid	Sets Call Station Id Type to 'AP MAC address': 'SSID'.
ipaddress	Sets Call Station Id Type to the system's IP Address.
macaddress	Sets Call Station Id Type to the system's MAC Address.
request	Configures EAP request related parameters.

retries <i>retries</i>	(Optional) For EAP messages other than Identity Requests or EAPOL (WPA) key messages, specifies the maximum number of times (0 to 20 retries) that the controller retransmits the message to a wireless client. The default value is 2.
timeout <i>seconds</i>	(Optional) For EAP messages other than Identity Requests or EAPOL (WPA) key messages, specifies the amount of time (1 to 120 seconds) that the controller waits before retransmitting the message to a wireless client. The default value is 30 seconds.
wep key	Configures 802.1x WEP related paramters.
index 0	Specifies the WEP key index value as 0
index 3	Specifies the WEP key index value as 3

Command Default Default for eapol-key-timeout: 1 second.
Default for eapol-key-retries: 2 retries.

Command Modes config

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

This example lists all the commands under **wireless security dot1x**.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#wireless security dot1x ?
  eapol-key          Configure eapol-key related parameters
  group-key          Configures EAP-broadcast key renew interval time in seconds
  identity-request   Configure EAP ID request related parameters
  radius             Configure radius messages
  request            Configure EAP request related parameters
  wep                Configure 802.1x WEP related paramters
  <cr>
```

wireless security lsc

To configure locally significant certificates, use the **wireless security lsc** command.

```
wireless security lsc {ap-provision [{auth-list mac-addr | revert number}] | other-params key-size
| subject-params country state city orgn dept email | trustpoint trustpoint}
```

Syntax Description		
ap-provision		Specifies the access point provision list settings.
auth-list <i>mac-addr</i>		Specifies the provision list authorization settings.
revert <i>number</i>		Specifies the number of times the access point attempts to join the controller using an LSC before reverting to the default certificate. The maximum number of attempts cannot exceed 255.
other-params <i>key-size</i>		Specifies the device certificate key size settings.
subject-params <i>country state city orgn dept email</i>		Specifies the device certificate settings. Country, state, city, organization, department, and email of the certificate authority.
trustpoint <i>trustpoint</i>		Specifies the LSC Trustpoint.

Command Default None

Command Modes config

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines You can configure only one CA server. To configure a different CA server, delete the configured CA server by using the config certificate lsc ca-server delete command, and then configure a different CA server.

If you configure an access point provision list, only the access points in the provision list are provisioned when you enable AP provisioning (in Step 8). If you do not configure an access point provision list, all access points with an MIC or SSC certificate that join the controller are LSC provisioned.

This example shows how to configure locally significant certificate:

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#wireless security lsc ?
  ap-provision      Provisioning the AP's with LSC's
  other-params      Configure Other Parameters for Device Certs
  subject-params    Configure the Subject Parameters for Device Certs
  trustpoint        Configure LSC Trustpoint
  <cr>
```

wireless security strong-password

To configure strong password enforcement options, use the **wireless security strong-password** command. To disable strong password, use the no form of the command.

wireless security strong-password
no wireless security strong-password

Command Default None.

Command Modes config

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

This example shows how to configure a strong-password for wireless security.

```
Device#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
Device(config)#wireless security strong-password
```

wireless wps ap-authentication

To configure the access point neighbor authentication, use the **wireless wps ap-authentication** command. To remove the access point neighbor authentication, use the no form of the command.

wireless wps ap-authentication [**threshold** *value*]

no wireless wps ap-authentication [**threshold**]

Syntax Description	threshold <i>value</i> Specifies that the WMM-enabled clients are on the wireless LAN. Threshold value (1 to 255).
---------------------------	---

Command Default	None.
------------------------	-------

Command Modes	config
----------------------	--------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

This example shows how to set the threshold value for WMM-enabled clients.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#wireless wps ap-authentication threshold 65
```

wireless wps auto-immune

To enable protection from denial of service (DoS) attacks, use the **wireless wps auto-immune** command. To disable, use the no form of the command.

wireless wps auto-immune
no wireless wps auto-immune

Command Default Disabled.

Command Modes config

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

A potential attacker can use specially crafted packets to mislead the Intrusion Detection System (IDS) into treating a legitimate client as an attacker. It causes the controller to disconnect this legitimate client and launch a DoS attack. The auto-immune feature, when enabled, is designed to protect against such attacks. However, conversations using Cisco 792x phones might be interrupted intermittently when the auto-immune feature is enabled. If you experience frequent disruptions when using 792x phones, you might want to disable this feature.

This example shows how to enable protection from denial of service (DoS) attack:

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#wireless wps auto-immune
```

wireless wps cids-sensor

To configure Intrusion Detection System (IDS) sensors for the Wireless Protection System (WPS), use the **wireless wps cids-sensor** command. To remove the Intrusion Detection System (IDS) sensors for the Wireless Protection System (WPS), use the no form of the command.

wireless wps cids-sensor *index* [**ip-address** *ip-addr* **username** *username* **password** *password_type* *password*]

no wireless wps cids-sensor *index*

Syntax Description		
	<i>index</i>	Specifies the IDS sensor internal index.
	ip-address <i>ip-addr</i> username <i>username</i> password <i>password_type</i> <i>password</i>	Specifies the IDS sensor IP address, IDS sensor username, password type and IDS sensor password.

Command Default Disabled.

Command Modes config

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None

This example shows how to configure the Intrusion Detection System with the IDS index, IDS sensor IP address, IDS username and IDS password.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#wireless wps cids-sensor 1 10.0.0.51 Sensor_user0doc1 passowrd01
```

wireless wps client-exclusion

To configure client exclusion policies, use the **wireless wps client-exclusion** command. To remove the client exclusion policies, use the **no** form of the command.

```
wireless wps client-exclusion {all | dot11-assoc | dot11-auth | dot1x-auth | ip-theft | web-auth}
no wireless wps client-exclusion {all | dot11-assoc | dot11-auth | dot1x-auth | ip-theft | web-auth}
```

Syntax Description

dot11-assoc	Specifies that the controller excludes clients on the sixth 802.11 association attempt, after five consecutive failures.
dot11-auth	Specifies that the controller excludes clients on the sixth 802.11 authentication attempt, after five consecutive failures.
dot1x-auth	Specifies that the controller excludes clients on the sixth 802.11X authentication attempt, after five consecutive failures.
ip-theft	Specifies that the control excludes clients if the IP address is already assigned to another device. For more information, see the Usage Guidelines section.
web-auth	Specifies that the controller excludes clients on the fourth web authentication attempt, after three consecutive failures.
all	Specifies that the controller excludes clients for all of the above reasons.

Command Default

Enabled.

Command Modes

config

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

In IP-theft scenarios, there are differences between the older Cisco IOS XE releases and the Cisco IOS XE Denali 16.x releases:

Older Cisco IOS XE Releases	Cisco IOS XE Denali 16.x Releases
<p>Priority wise, wired clients have higher priority over wireless clients, and DHCP IP has higher priority over static IP. The client security type is not checked; security of all client types are treated with same priority.</p> <p>If the existing binding is from a higher priority source, the new binding is ignored and an IP-theft is signaled. If the existing binding has the same source-priority as the new binding, the binding is ignored and an IP-theft is signaled. This ensures that the bindings are not toggled if two hosts send traffic using the same IP. Only the initial binding is retained in the software. If the new binding is from a higher priority source, the existing binding is replaced. This results in an IP-theft notification of existing binding and also a new binding notification.</p>	<p>There is not really a fundamental difference between wired and wireless; what matters is the trust (preflevel) of the entry, which is a function on how it was learnt (ARP, DHCP, ND, and so on) and the policy that is attached to the port. When preflevel is equal, the IP takeover is denied if the old entry is still reachable. IP takeover occurs when the update comes from a trusted port or a new entry gets IP from the DHCP server. Otherwise, you must explicitly grant it. The IP-theft is not reported if an old entry is replaced by a new and a more trusted one.</p>

This example shows how to disable clients on the 802.11 association attempt after five consecutive failures.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#wireless wps client-exclusion dot11-assoc
```

wireless wps mfp infrastructure

To configure Management Frame Protection (MFP), use the **wireless wps mfp infrastructure** command.
To remove the Management Frame Protection (MFP), use the no form of the command.

wireless wps mfp infrastructure
no wireless wps mfp infrastructure

Command Default None.

Command Modes config

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

This example shows how to enable the infrastructure MFP.

```
Device#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
Device(config)#wireless wps mfp infrastructure
```

wireless wps rogue

To configure various rogue parameters, use the **wireless wps rogue** command.

wireless wps rogue {**adhoc** | **client**} [{**alert** *mac-addr* | **contain** *mac-addr no-of-aps*}]

Syntax Description

adhoc	Configures the status of an Independent Basic Service Set (IBSS or ad-hoc) rogue access point.
client	Configures rogue clients
alert <i>mac-addr</i>	Generates an SNMP trap upon detection of the ad-hoc rogue, and generates an immediate alert to the system administrator for further action for the MAC address of the ad-hoc rogue access point.
contain <i>mac-addr no-of-aps</i>	Contains the offending device so that its signals no longer interfere with authorized clients. Maximum number of Cisco access points assigned to actively contain the ad-hoc rogue access point (1 through 4, inclusive).

Command Default

None.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

None.

This example shows how to generate an immediate alert to the system administrator for further action for the MAC address of the ad-hoc rogue access point.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#wireless wps rogue adhoc alert mac_addr
```

wireless wps shun-list re-sync

To force the controller to synchronization with other controllers in the mobility group for the shun list, use the **wireless wps shun-list re-sync** command.

wireless wps shun-list re-sync

Command Default

None.

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

None.

This example shows how to configure the controller to synchronize with other controllers for the shun list.

```
Device#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
Device(config)#wireless wps shun-list re-sync
```

vlan access-map

To create or modify a VLAN map entry for VLAN packet filtering, and change the mode to the VLAN access-map configuration, use the **vlan access-map** command in global configuration mode on the switch stack or on a standalone switch. To delete a VLAN map entry, use the **no** form of this command.

```
vlan access-map name [number]
no vlan access-map name [number]
```



Note

This command is not supported on switches running the LAN Base feature set.

Syntax Description

name Name of the VLAN map.

number (Optional) The sequence number of the map entry that you want to create or modify (0 to 65535). If you are creating a VLAN map and the sequence number is not specified, it is automatically assigned in increments of 10, starting from 10. This number is the sequence to insert to, or delete from, a VLAN access-map entry.

Command Default

There are no VLAN map entries and no VLAN maps applied to a VLAN.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

In global configuration mode, use this command to create or modify a VLAN map. This entry changes the mode to VLAN access-map configuration, where you can use the **match** access-map configuration command to specify the access lists for IP or non-IP traffic to match and use the **action** command to set whether a match causes the packet to be forwarded or dropped.

In VLAN access-map configuration mode, these commands are available:

- **action**—Sets the action to be taken (forward or drop).
- **default**—Sets a command to its defaults.
- **exit**—Exits from VLAN access-map configuration mode.
- **match**—Sets the values to match (IP address or MAC address).
- **no**—Negates a command or set its defaults.

When you do not specify an entry number (sequence number), it is added to the end of the map.

There can be only one VLAN map per VLAN and it is applied as packets are received by a VLAN.

You can use the **no vlan access-map name [number]** command with a sequence number to delete a single entry.

Use the **vlan filter** interface configuration command to apply a VLAN map to one or more VLANs. For more information about VLAN map entries, see the software configuration guide for this release.

This example shows how to create a VLAN map named vac1 and apply matching conditions and actions to it. If no other entries already exist in the map, this will be entry 10.

```
Device(config)# vlan access-map vac1
Device(config-access-map)# match ip address acl1
Device(config-access-map)# action forward
```

This example shows how to delete VLAN map vac1:

```
Device(config)# no vlan access-map vac1
```

Related Topics

- [match \(access-map configuration\)](#), on page 1001
- [show vlan access-map](#), on page 1034
- [vlan filter](#), on page 1066

vlan filter

To apply a VLAN map to one or more VLANs, use the **vlan filter** command in global configuration mode on the switch stack or on a standalone switch. To remove the map, use the **no** form of this command.

```
vlan filter mapname vlan-list {list | all}
no vlan filter mapname vlan-list {list | all}
```



Note This command is not supported on switches running the LAN Base feature set.

Syntax Description

<i>mapname</i>	Name of the VLAN map entry.
vlan-list	Specifies which VLANs to apply the map to.
<i>list</i>	The list of one or more VLANs in the form tt, uu-vv, xx, yy-zz, where spaces around commas and dashes are optional. The range is 1 to 4094.
all	Adds the map to all VLANs.

Command Default

There are no VLAN filters.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

To avoid accidentally dropping too many packets and disabling connectivity in the middle of the configuration process, we recommend that you completely define the VLAN access map before applying it to a VLAN.

For more information about VLAN map entries, see the software configuration guide for this release.

This example applies VLAN map entry map1 to VLANs 20 and 30:

```
Device(config)# vlan filter map1 vlan-list 20, 30
```

This example shows how to delete VLAN map entry mac1 from VLAN 20:

```
Device(config)# no vlan filter map1 vlan-list 20
```

You can verify your settings by entering the **show vlan filter** privileged EXEC command.

Related Topics

- [show vlan access-map](#), on page 1034
- [vlan access-map](#), on page 1064

vlan group

To create or modify a VLAN group, use the **vlan group** command in global configuration mode. To remove a VLAN list from the VLAN group, use the **no** form of this command.

```

vlan group group-name vlan-list vlan-list
no vlan group group-name vlan-list vlan-list

```

Syntax Description	<i>group-name</i>	Name of the VLAN group. The group name may contain up to 32 characters and must begin with a letter.
	vlan-list <i>vlan-list</i>	Specifies one or more VLANs to be added to the VLAN group. The <i>vlan-list</i> argument can be a single VLAN ID, a list of VLAN IDs, or VLAN ID range. Multiple entries are separated by a hyphen (-) or a comma (,).
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

If the named VLAN group does not exist, the **vlan group** command creates the group and maps the specified VLAN list to the group. If the named VLAN group exists, the specified VLAN list is mapped to the group.

The **no** form of the **vlan group** command removes the specified VLAN list from the VLAN group. When you remove the last VLAN from the VLAN group, the VLAN group is deleted.

A maximum of 100 VLAN groups can be configured, and a maximum of 4094 VLANs can be mapped to a VLAN group.

This example shows how to map VLANs 7 through 9 and 11 to a VLAN group:

```
Device(config)# vlan group group1 vlan-list 7-9,11
```

This example shows how to remove VLAN 7 from the VLAN group:

```
Device(config)# no vlan group group1 vlan-list 7
```

Related Topics

[show vlan group](#), on page 1035



PART **XIV**

Stack Manager and High Availability

- [Stack Manager and High Availability Commands, on page 1071](#)



Stack Manager and High Availability Commands

- [debug platform stack-manager](#), on page 1072
- [main-cpu](#), on page 1073
- [mode sso](#), on page 1074
- [policy config-sync prc reload](#), on page 1075
- [redundancy](#), on page 1076
- [redundancy config-sync mismatched-commands](#), on page 1077
- [redundancy force-switchover](#), on page 1079
- [redundancy reload](#), on page 1080
- [reload](#), on page 1081
- [session](#), on page 1083
- [set trace capwap ap ha](#), on page 1084
- [set trace mobility ha](#), on page 1085
- [set trace qos ap ha](#), on page 1087
- [show checkpoint](#), on page 1088
- [show etherchannel summary](#), on page 1095
- [show platform ses](#), on page 1096
- [show platform stack-manager](#), on page 1102
- [show redundancy](#), on page 1103
- [show redundancy config-sync](#), on page 1107
- [show switch](#), on page 1109
- [show trace messages capwap ap ha](#), on page 1113
- [show trace messages mobility ha](#), on page 1114
- [stack-mac persistent timer](#), on page 1115
- [stack-mac update force](#), on page 1117
- [standby console enable](#), on page 1118
- [switch stack port](#), on page 1119
- [switch priority](#), on page 1121
- [switch provision](#), on page 1122
- [switch renumber](#), on page 1124

debug platform stack-manager

To enable debugging of the stack manager software, use the **debug platform stack-manager** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug platform stack-manager {all | rpc | sdp | sim | ssm | trace}
```

```
no debug platform stack-manager {all | rpc | sdp | sim | ssm | trace}
```

Syntax Description

all	Displays all stack manager debug messages.
rpc	Displays stack manager remote procedure call (RPC) usage debug messages.
sdp	Displays the Stack Discovery Protocol (SDP) debug messages.
sim	Displays the stack information module debug messages.
ssm	Displays the stack state-machine debug messages.
trace	Traces the stack manager entry and exit debug messages.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

This command is supported only on stacking-capable switches.

The **undebug platform stack-manager** command is the same as the **no debug platform stack-manager** command.

When you enable debugging on a switch stack, it is enabled only on the stack master. To enable debugging on a stack member, you can start a session from the stack master by using the **session switch-number EXEC** command. Enter the **debug** command at the command-line prompt of the stack member. You also can use the **remote command stack-member-number LINE EXEC** command on the stack master switch to enable debugging on a member switch without first starting a session.

main-cpu

To enter the redundancy main configuration submode and enable the standby switch, use the **main-cpu** command in redundancy configuration mode.

main-cpu

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Redundancy configuration
----------------------	--------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE

Usage Guidelines	From the redundancy main configuration submode, use the standby console enable command to enable the standby switch.
-------------------------	---

This example shows how to enter the redundancy main configuration submode and enable the standby switch:

```
Device(config)# redundancy
Device(config-red)# main-cpu
Device(config-r-mc)# standby console enable
Device#
```

Related Topics

[standby console enable](#), on page 1118

mode sso

To set the redundancy mode to stateful switchover (SSO), use the **mode sso** command in redundancy configuration mode.

mode sso

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Redundancy configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

The **mode sso** command can be entered only from within redundancy configuration mode.

Follow these guidelines when configuring your system to SSO mode:

- You must use identical Cisco IOS images on the switches in the stack to support SSO mode. Redundancy may not work due to differences between the Cisco IOS releases.
- If you perform an online insertion and removal (OIR) of the module, the switch resets during the stateful switchover and the port states are restarted only if the module is in a transient state (any state other than Ready).
- The forwarding information base (FIB) tables are cleared on a switchover. Routed traffic is interrupted until route tables reconverge.

This example shows how to set the redundancy mode to SSO:

```
Device(config)# redundancy
Device(config-red)# mode sso
Device(config-red)#
```

policy config-sync prc reload

To reload the standby switch if a parser return code (PRC) failure occurs during configuration synchronization, use the **policy config-sync reload** command in redundancy configuration mode. To specify that the standby switch is not reloaded if a parser return code (PRC) failure occurs, use the **no** form of this command.

```
policy config-sync {bulk | lbl} prc reload
no policy config-sync {bulk | lbl} prc reload
```

Syntax Description

bulk Specifies bulk configuration mode.

lbl Specifies line-by-line (lbl) configuration mode.

Command Default

The command is enabled by default.

Command Modes

Redundancy configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to specify that the standby switch is not reloaded if a parser return code (PRC) failure occurs during configuration synchronization:

```
Device(config-red) # no policy config-sync bulk prc reload
```

redundancy

To enter redundancy configuration mode, use the **redundancy** command in global configuration mode.

redundancy

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines The redundancy configuration mode is used to enter the main CPU submode, which is used to enable the standby switch.

To enter the main CPU submode, use the **main-cpu** command while in redundancy configuration mode.

From the main CPU submode, use the **standby console enable** command to enable the standby switch.

Use the **exit** command to exit redundancy configuration mode.

This example shows how to enter redundancy configuration mode:

```
Device(config)# redundancy
Device(config-red)#
```

This example shows how to enter the main CPU submode:

```
Device(config)# redundancy
Device(config-red)# main-cpu
Device(config-r-mc)#
```

redundancy config-sync mismatched-commands

To allow the standby switch to join the stack if a configuration mismatch occurs between the active and standby switches, use the **redundancy config-sync mismatched-commands** command in privileged EXEC mode.

redundancy config-sync {ignore | validate} mismatched-commands

Syntax Description	ignore	Ignores the mismatched command list.
	validate	Revalidates the mismatched command list with the modified running-configuration.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Usage Guidelines	<p>If the command syntax check in the running configuration of the active switch fails while the standby switch is booting, use the redundancy config-sync mismatched-commands command to display the Mismatched Command List (MCL) on the active switch and to reboot the standby switch.</p> <p>The following is a log entry example for mismatched commands:</p> <pre>00:06:31: Config Sync: Bulk-sync failure due to Servicing Incompatibility. Please check full list of mismatched commands via: show redundancy config-sync failures mcl 00:06:31: Config Sync: Starting lines from MCL file: interface GigabitEthernet7/7 ! <submode> "interface" - ip address 192.0.2.0 255.255.255.0 ! </submode> "interface"</pre> <p>To display all mismatched commands, use the show redundancy config-sync failures mcl command.</p> <p>To clean the MCL, follow these steps:</p> <ol style="list-style-type: none"> 1. Remove all mismatched commands from the running configuration of the active switch. 2. Revalidate the MCL with a modified running configuration by using the redundancy config-sync validate mismatched-commands command. 3. Reload the standby switch. <p>You can ignore the MCL by doing the following:</p> <ol style="list-style-type: none"> 1. Enter the redundancy config-sync ignore mismatched-commands command. 2. Reload the standby switch; the system changes to SSO mode. 	



Note If you ignore the mismatched commands, the out-of-sync configuration at the active switch and the standby switch still exists.

3. Verify the ignored MCL with the **show redundancy config-sync ignored mcl** command.

If SSO mode cannot be established between the active and standby switches because of an incompatibility in the configuration file, a mismatched command list (MCL) is generated at the active switch and a reload into route processor redundancy (RPR) mode is forced for the standby switch.



Note RPR mode is supported on Catalyst 3850 switches as a fallback in case of errors. It is not configurable.

If you attempt to establish an SSO after removing the offending configuration and rebooting the standby switch with the same image, the C3K_REDUNDANCY-2-`IOS_VERSION_CHECK_FAIL` and ISSU-3-`PEER_IMAGE_INCOMPATIBLE` messages appear because the peer image is listed as incompatible. You can clear the peer image from the incompatible list with the **redundancy config-sync ignore mismatched-commands EXEC** command while the peer is in a standby cold (RPR) state. This action allows the standby switch to boot in a standby hot (SSO) state when it reloads.

This example shows how to revalidate the mismatched command list with the modified configuration:

```
Device# redundancy config-sync validate mismatched-commands
Device#
```

redundancy force-switchover

To force a switchover from the active switch to the standby switch, use the **redundancy force-switchover** command in privileged EXEC mode on a switch stack.

redundancy force-switchover

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines Use the **redundancy force-switchover** command to manually switch over to the redundant switch. The redundant switch becomes the new active switch that runs the Cisco IOS image, and the modules are reset to their default settings.

The old active switch reboots with the new image and joins the stack.

If you use the **redundancy force-switchover** command on the active switch, the switchports on the active switch go down.

If you use this command on a switch that is in a partial ring stack, the following warning message appears:

```
Device# redundancy force-switchover
Stack is in Half ring setup; Reloading a switch might cause stack split
This will reload the active unit and force switchover to standby[confirm]
```

This example shows how to manually switch over from the active to the standby supervisor engine:

```
Device# redundancy force-switchover
Device#
```

redundancy reload

To force a reload of one or all of the switches in the stack, use the **redundancy reload** command in privileged EXEC mode.

redundancy reload {peer | shelf}

Syntax Description	
peer	Reloads the peer unit.
shelf	Reboots all switches in the stack.

Command Default	
	None

Command Modes	
	Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines	
	Before using this command, see the “Performing a Software Upgrade” section of the <i>Stacking Configuration Guide (Catalyst 3650 Switches)</i> for additional information.

Use the **redundancy reload shelf** command to reboot all the switches in the stack.

This example shows how to manually reload all switches in the stack:

```
Device# redundancy reload shelf
Device#
```

reload

To reload the stack member and to apply a configuration change, use the **reload** command in privileged EXEC mode.

```
reload [{/noverify | /verify}] [{LINE | at | cancel | in | slot stack-member-number | standby-cpu}]
```

Syntax Description		
/noverify	(Optional)	Specifies to not verify the file signature before the reload.
/verify	(Optional)	Verifies the file signature before the reload.
<i>LINE</i>	(Optional)	Reason for the reload.
at	(Optional)	Specifies the time in hh:mm for the reload to occur.
cancel	(Optional)	Cancels the pending reload.
in	(Optional)	Specifies a time interval for reloads to occur.
slot	(Optional)	Saves the changes on the specified stack member and then restarts it.
<i>stack-member-number</i>	(Optional)	Stack member number on which to save the changes. The range is 1 to 9.
standby-cpu	(Optional)	Reloads the standby route processor (RP).

Command Default Immediately reloads the stack member and puts a configuration change into effect.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines If there is more than one switch in the switch stack, and you enter the **reload slot *stack-member-number*** command, you are not prompted to save the configuration.

Examples

This example shows how to reload the switch stack:

```
Device# reload
System configuration has been modified. Save? [yes/no]: yes
Reload command is being issued on Active unit, this will reload the whole stack
Proceed with reload? [confirm] yes
```

This example shows how to reload a specific stack member:

```
Device# reload slot 6
Proceed with reload? [confirm] y
```

This example shows how to reload a single-switch switch stack (there is only one member switch):

```
Device# reload slot 3
System configuration has been modified. Save? [yes/no]: y
Proceed to reload the whole Stack? [confirm] y
```

Related Topics

[show switch](#), on page 1109

[switch priority](#), on page 1121

[switch renumber](#), on page 1124

session

To access a specific stack member use the **session** command in privileged EXEC mode on the stack master.

session *stack-member-number*

Syntax Description	<i>stack-member-number</i>	Stack member number to access from the active switchstack master. The range is 1 to 9.
---------------------------	----------------------------	--

Command Default	None
------------------------	------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE

Usage Guidelines

When you access the member, its member number is appended to the system prompt.

Use the **session** command from the master to access a member Device

Use the **session** command with **processor 1** from the master or a standalone switch to access the internal controller. A standalone Device is always member 1.

Examples

This example shows how to access stack member 3:

```
Device# session 3
Device-3#
```

Related Topics

- [reload](#), on page 1081
- [show switch](#), on page 1109
- [switch priority](#), on page 1121
- [switch renumber](#), on page 1124

set trace capwap ap ha

To trace the control and provisioning of wireless access point high availability, use the **set trace capwap ap ha** privileged EXEC command.

```
set trace capwap ap ha [{detail|event|dump | {filter [{none [switch switch]|filter_name
[filter_value [switch switch]]}] | filteredswitchlevel {defaulttrace_level} [switch switch]}}]
```

Syntax Description	Parameter	Description
	detail	(Optional) Specifies the wireless CAPWAP HA details.
	event	(Optional) Specifies the wireless CAPWAP HA events.
	dump	(Optional) Specifies the wireless CAPWAP HA output.
	filter mac	Specifies the MAC address.
	<i>switch switch number</i>	Specifies the switch number.
	none	(Optional) Specifies the no filter option.
	switch switch	(Optional) Specifies the device number.
	<i>filter name</i>	Trace adapted flag filter name.
	<i>filter_value</i>	(Optional) Value of the filter.
	switch switch	(Optional) Specifies the device number.
	filtered	Specifies the filtered traces messages.
	<i>switch</i>	Specifies the switch number.
	level	Specifies the trace level.
	default	Specifies the unset trace level value.
	<i>trace_level</i>	Specifies the trace level.
	switch switch	(Optional) Specifies the device number.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display the wireless CAPWAP HA:

```
Device# set trace capwap ap ha detail filter mac WORD switch number
```

set trace mobility ha

To debug the wireless mobility high availability in the switch, use the **set trace mobility ha** privileged EXEC command.

```
set trace mobility ha [{event | detail | dump}] {filter[mac WORD switch switch number] [{none
[switch switch] | filter_name [filter_value [switch switch]]}] | level {defaulttrace_level} [switch
switch]{filteredswitch}}
```

Syntax	Description
event	(Optional) Specifies the wireless mobility high availability events.
detail	(Optional) Specifies the wireless mobility high availability details.
dump	(Optional) Specifies the wireless mobility high availability output.
filter	Specifies to trace adapted flag filter.
mac	Specifies the MAC address.
<i>WORD switch</i>	Specifies the switch.
<i>switch number</i>	Specifies the switch number. The value ranges from one to four.
none	Specifies no trace adapted flag filter.
switch switch	(Optional) Specifies the device number.
<i>filter_name</i>	Trace adapted flag filter name.
<i>filter_value</i>	Trace adapted flag filter value.
switch switch	Specifies the device number.
level	Specifies the trace level value.
default	Specifies the un-set trace level value.
<i>trace_level</i>	Specifies the trace level value.
switch switch	Specifies the device number.
filtered	Specifies the filtered trace messages.
<i>switch</i>	Specifies the switch.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SECisco IOS XE 3.3SE	This command was introduced.

This example shows how to display wireless mobility high availability details:

```
Device# set trace mobility ha detail filter mac WORD
[08/27/13 10:38:35.349 UTC 1 8135] Invalid src ip: 169.254.1.1
[08/27/13 10:38:35.349 UTC 2 8135] Invalid sysIp: Skip plumbing MC-MA
tunnels.
[08/27/13 10:38:54.393 UTC 3 8135] Mobility version mismatch, v10 received,
or m
sglen mismatch msglen=74 recvBytes=0, dropping
```

set trace qos ap ha

To trace wireless Quality of Service (QoS) high availability, use the **set trace qos ap ha** privileged EXEC command.

```
set trace QOS ap ha [{event|error}] {filter [{MACnone [switch switch]|filter_name [filter_value [switch switch]]}] | level {defaulttrace_level} [switch switch]}
```

Syntax Description		
event	(Optional)	Specifies trace QoS wireless AP event.
event mac		Specifies the MAC address of the AP.
event none		Specifies no MAC address value.
error	(Optional)	Specifies trace QoS wireless AP errors.
error mac		Specifies the MAC address of the AP.
error none		Specifies no value.
filter		Specifies the trace adapted flag filter.
filter mac		Specifies the MAC address of the AP.
filter none		Specifies no value.
switch switch		Specifies the switch number.
<i>filter_name</i>	(Optional)	Specifies the switch filter name.
<i>filter_value</i>	(Optional)	Specifies the switch filter value. Value is one.
switch switch	(Optional)	Specifies the switch number. Value is one.
level		Specifies the trace level.
default		Specifies the trace QoS wireless AP default.
<i>trace_level</i>		Trace level.
switch switch	(Optional)	Specifies the switch number. Value is one.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to trace wireless QoS high availability:

```
Device# set trace QOS ap ha
```

show checkpoint

To display information about the Checkpoint Facility (CF) subsystem, use the **show checkpoint** command.

show checkpoint clients entities statistics

Syntax Description	clients	entities	statistics
	Displays detailed information about checkpoint clients.	Displays detailed information about checkpoint entities.	Displays detailed information about checkpoint statistics.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display all the CF clients.

```

Client residing in process : 8135
-----
Checkpoint client: WCM_MOBILITY
  Client ID                : 24105
  Total DB inserts          : 0
  Total DB updates         : 0
  Total DB deletes         : 0
  Total DB reads           : 0
  Number of tables         : 6
  Client residing in process : 8135
-----
Checkpoint client: WCM_DOT1X
  Client ID                : 24106
  Total DB inserts          : 2
  Total DB updates         : 1312
  Total DB deletes         : 2
  Total DB reads           : 0
  Number of tables         : 1
  Client residing in process : 8135
-----
Checkpoint client: WCM_APFROGUE
  Client ID                : 24107
  Total DB inserts          : 0
  Total DB updates         : 0
  Total DB deletes         : 0
  Total DB reads           : 0
  Number of tables         : 1
  Client residing in process : 8135
-----
Checkpoint client: WCM_CIDS
  Client ID                : 24110
  Total DB inserts          : 0
  Total DB updates         : 0
  Total DB deletes         : 0

```

```

Total DB reads           : 0
Number of tables         : 0
Client residing in process : 8135

```

```

-----
Checkpoint client: WCM_NETFLOW
Client ID                : 24111
Total DB inserts         : 7
Total DB updates         : 0
Total DB deletes         : 0
Total DB reads           : 0
Number of tables         : 1
Client residing in process : 8135

```

```

-----
Checkpoint client: WCM_MCAST
Client ID                : 24112
Total DB inserts         : 0
Total DB updates         : 0
Total DB deletes         : 0
Total DB reads           : 0
Number of tables         : 1
Client residing in process : 8135

```

```

-----
Checkpoint client: wcm_comet
Client ID                : 24150
Total DB inserts         : 0
Total DB updates         : 0
Total DB deletes         : 0
Total DB reads           : 0
Number of tables         : 0
Client residing in process : 8135

```

All iosd checkpoint clients

```

-----
Client Name           Client   Entity   Bundle
                    ID       ID       Mode

```

```

-----
Network RF Client      3       --      Off

```

```

Total API Messages Sent:           0
Total Transport Messages Sent:     0
Length of Sent Messages:           0
Total Blocked Messages Sent:       0
Length of Sent Blocked Messages:   0
Total Non-blocked Messages Sent:   0
Length of Sent Non-blocked Messages: 0
Total Bytes Allocated:             0
Buffers Held:                      0
Buffers Held Peak:                 0
Huge Buffers Requested:            0
Transport Frag Count:              0
Transport Frag Peak:               0
Transport Sends w/Flow Off:        0
Send Errs:                         0
Send Peer Errs:                   0
Rcv Xform Errs:                   0
Xmit Xform Errs:                   0
Incompatible Messages:             0
Client Unbundles to Process Memory: T

```

```

-----
Client Name           Client   Entity   Bundle
                    ID       ID       Mode

```

show checkpoint

```
SNMP CF Client          12          --          Off
```

```
Total API Messages Sent:          0
Total Transport Messages Sent:     0
Length of Sent Messages:           0
Total Blocked Messages Sent:       0
Length of Sent Blocked Messages:   0
Total Non-blocked Messages Sent:   0
Length of Sent Non-blocked Messages: 0
Total Bytes Allocated:             0
Buffers Held:                      0
Buffers Held Peak:                 0
Huge Buffers Requested:            0
Transport Frag Count:              0
Transport Frag Peak:               0
Transport Sends w/Flow Off:        0
Send Errs:                         0
Send Peer Errs:                   0
Rcv Xform Errs:                   0
Xmit Xform Errs:                   0
Incompatible Messages:             0
Client Unbundles to Process Memory: T
```

```
-----
Client Name             Client      Entity      Bundle
                        ID          ID          Mode
-----
```

```
Online Diags HA        14          --          Off
```

```
Total API Messages Sent:          0
Total Transport Messages Sent:     0
Length of Sent Messages:           0
Total Blocked Messages Sent:       0
Length of Sent Blocked Messages:   0
Total Non-blocked Messages Sent:   0
Length of Sent Non-blocked Messages: 0
Total Bytes Allocated:             0
Buffers Held:                      0
Buffers Held Peak:                 0
Huge Buffers Requested:            0
Transport Frag Count:              0
Transport Frag Peak:               0
Transport Sends w/Flow Off:        0
Send Errs:                         0
Send Peer Errs:                   0
Rcv Xform Errs:                   0
Xmit Xform Errs:                   0
Incompatible Messages:             0
Client Unbundles to Process Memory: T
```

```
-----
Client Name             Client      Entity      Bundle
                        ID          ID          Mode
-----
```

```
ARP                    22          --          Off
```

```
Total API Messages Sent:          0
Total Transport Messages Sent:     0
Length of Sent Messages:           0
Total Blocked Messages Sent:       0
Length of Sent Blocked Messages:   0
Total Non-blocked Messages Sent:   0
Length of Sent Non-blocked Messages: 0
Total Bytes Allocated:             0
Buffers Held:                      0
Buffers Held Peak:                 0
```

```

Huge Buffers Requested:          0
Transport Frag Count:           0
Transport Frag Peak:            0
Transport Sends w/Flow Off:     0
Send Errs:                      0
Send Peer Errs:                0
Rcv Xform Errs:                0
Xmit Xform Errs:               0
Incompatible Messages:         0
Client Unbundles to Process Memory: T

```

```

-----
Client Name          Client      Entity      Bundle
                   ID          ID          Mode
-----

```

```

Tableid CF          27          --          Off

```

```

Total API Messages Sent:        0
Total Transport Messages Sent:  0
Length of Sent Messages:       0
Total Blocked Messages Sent:   0
Length of Sent Blocked Messages: 0
Total Non-blocked Messages Sent: 0
Length of Sent Non-blocked Messages: 0
Total Bytes Allocated:         0
Buffers Held:                  0
Buffers Held Peak:             0
Huge Buffers Requested:        0
Transport Frag Count:          0
Transport Frag Peak:           0
Transport Sends w/Flow Off:    0
Send Errs:                     0
Send Peer Errs:               0
Rcv Xform Errs:               0
Xmit Xform Errs:               0
Incompatible Messages:         0
Client Unbundles to Process Memory: T

```

```

-----
Client Name          Client      Entity      Bundle
                   ID          ID          Mode
-----

```

```

Event Manager       33          0          Off

```

```

Total API Messages Sent:        0
Total Transport Messages Sent:  --
Length of Sent Messages:       0
Total Blocked Messages Sent:   0
Length of Sent Blocked Messages: 0
Total Non-blocked Messages Sent: 0
Length of Sent Non-blocked Messages: 0
Total Bytes Allocated:         0
Buffers Held:                  0
Buffers Held Peak:             0
Huge Buffers Requested:        0
Transport Frag Count:          0
Transport Frag Peak:           0
Transport Sends w/Flow Off:    0
Send Errs:                     0
Send Peer Errs:               0
Rcv Xform Errs:               0
Xmit Xform Errs:               0
Incompatible Messages:         0
Client Unbundles to Process Memory: T

```

```

-----
Client Name          Client      Entity      Bundle

```

show checkpoint

```

-----
                ID          ID          Mode
-----
LAN-Switch Port Mana      35          0          Off

Total API Messages Sent:                0
Total Transport Messages Sent:          --
Length of Sent Messages:                 0
Total Blocked Messages Sent:            0
Length of Sent Blocked Messages:        0
Total Non-blocked Messages Sent:        0
Length of Sent Non-blocked Messages:    0
Total Bytes Allocated:                  0
Buffers Held:                           0
Buffers Held Peak:                      0
Huge Buffers Requested:                 0
Transport Frag Count:                   0
Transport Frag Peak:                    0
Transport Sends w/Flow Off:             0
Send Errs:                              0
Send Peer Errs:                        0
Rcv Xform Errs:                        0
Xmit Xform Errs:                       0
Incompatible Messages:                  0
Client Unbundles to Process Memory:      T
-----

Client Name          Client      Entity      Bundle
                   ID          ID          Mode
-----
LAN-Switch PAGP/LACP  36          0          Off

Total API Messages Sent:                0
Total Transport Messages Sent:          --
Length of Sent Messages:                 0
Total Blocked Messages Sent:            0
Length of Sent Blocked Messages:        0
Total Non-blocked Messages Sent:        0
Length of Sent Non-blocked Messages:    0
Total Bytes Allocated:                  0
Buffers Held:                           0
Buffers Held Peak:                      0
Huge Buffers Requested:                 0
Transport Frag Count:                   0
Transport Frag Peak:                    0
Transport Sends w/Flow Off:             0
Send Errs:                              0
Send Peer Errs:                        0
Rcv Xform Errs:                        0
Xmit Xform Errs:                       0
Incompatible Messages:                  0
Client Unbundles to Process Memory:      T
-----

Client Name          Client      Entity      Bundle
                   ID          ID          Mode
-----
LAN-Switch VLANs      39          0          Off

Total API Messages Sent:                0
Total Transport Messages Sent:          --
Length of Sent Messages:                 0
Total Blocked Messages Sent:            0
Length of Sent Blocked Messages:        0
Total Non-blocked Messages Sent:        0
Length of Sent Non-blocked Messages:    0
Total Bytes Allocated:                  0

```

```

Buffers Held:                                0
Buffers Held Peak:                          0
Huge Buffers Requested:                     0
Transport Frag Count:                       0
Transport Frag Peak:                        0
Transport Sends w/Flow Off:                 0
Send Errs:                                  0
Send Peer Errs:                             0
Rcv Xform Errs:                             0

```

This example shows how to display all the CF entities.

```

KATANA_DOC#show checkpoint entities
                        Check Point List of Entities

```

CHKPT on ACTIVE server.

```

-----
Entity ID      Entity Name
-----
          0      CHKPT_DEFAULT_ENTITY

Total API Messages Sent:          0
Total Messages Sent:              0
Total Sent Message Len:           0
Total Bytes Allocated:            0
Total Number of Members:          10

Member(s) of entity 0 are:
  Client ID      Client Name
-----
          168      DHCP Snooping
          167      IGMP Snooping
           41      Spanning-tree
           40      AUTH MGR CHKPT CLIEN
           39      LAN-Switch VLANs
           33      Event Manager
           35      LAN-Switch Port Mana
           36      LAN-Switch PAgP/LACP
          158      Inline Power Checkpoint

```

This example shows how to display the CF statistics.

```

KATANA_DOC#show checkpoint statistics
                        IOSd Check Point Status
CHKPT on ACTIVE server.

Number Of Msgs In Hold Q:          0
CHKPT MAX Message Size:            0
TP MAX Message Size:               65503
CHKPT Pending Msg Timer:           100 ms

FLOW_ON total:                     0
FLOW_OFF total:                    0
Current FLOW status is:             ON
Total API Messages Sent:            0
Total Messages Sent:                0
Total Sent Message Len:             0
Total Bytes Allocated:              0
Rcv Msg Q Peak:                    0
Hold Msg Q Peak:                   0
Buffers Held Peak:                  0

```

show checkpoint

```
Current Buffers Held:          0
Huge Buffers Requested:       0
```

show etherchannel summary

To show details on the ports, port-channel, and protocols in the controller, use the **show etherchannel summary** command.

show ethernet summary

This command has no arguments or keywords.

Command Default	None
------------------------	------

Command Modes	Privileged Mode.
----------------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows the details on the ports, port-channel, and protocols in the controller.

```
controller#show etherchannel summary
Flags: D - down          P - bundled in port-channel
       I - stand-alone  s - suspended
       H - Hot-standby (LACP only)
       R - Layer3       S - Layer2
       U - in use       f - failed to allocate aggregator

       M - not in use, minimum links not met
       u - unsuitable for bundling
       w - waiting to be aggregated
       d - default port
```

```
Number of channel-groups in use: 2
Number of aggregators:          2
```

Group	Port-channel	Protocol	Ports
2	Po2 (SD)	-	
23	Po23 (SD)	-	

show platform ses

To display the platform information - the stack event sequencer in the controller, use the **show platform ses** in the privileged EXEC mode.

show platform ses clients states

Syntax Description	
clients	Displays the SES client list.
states	Displays the SES card states.

Command Default None.

Command Modes Privileged EXEC mode.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use this command in the privileged EXEC mode to view the ses clients and states detail.

This example shows the stack event sequencer states.

```
Card #   Card State
=====  =====
1        NG3K_SES_CARD_ADD_COMPLETED(51)
2        NG3K_SES_CARD_EMPTY(0)
3        NG3K_SES_CARD_EMPTY(0)
4        NG3K_SES_CARD_EMPTY(0)
5        NG3K_SES_CARD_EMPTY(0)
6        NG3K_SES_CARD_EMPTY(0)
7        NG3K_SES_CARD_EMPTY(0)
8        NG3K_SES_CARD_EMPTY(0)
9        NG3K_SES_CARD_EMPTY(0)
```

This example shows all the associated clients of the stack event sequencer.

```
clientID = 5
clientSeq = 5
clientName = "MATM"
clientCallback @ 0xF49F7300
next = 0x909194B4
```

```
clientID = 6
clientSeq = 6
clientName = "L2 CONTROL"
clientCallback @ 0xF49CA3F0
next = 0x915E4E80
```

```
clientID = 7
clientSeq = 7
clientName = "CDP"
clientCallback @ 0xF49C7220
next = 0x915E4F08
```

```
clientID = 8
```

```
clientSeq = 8
clientName = "UDLD"
clientCallback @ 0xF49C75D0
next = 0x91854CA0

clientID = 9
clientSeq = 9
clientName = "LLDP"
clientCallback @ 0xF49E62F0
next = 0x90919F90

clientID = 10
clientSeq = 10
clientName = "L2M"
clientCallback @ 0xF49CE4D0
next = 0x90E35A5C

clientID = 11
clientSeq = 11
clientName = "Storm-Control"
clientCallback @ 0xF4BA8080
next = 0x9089E9B4

clientID = 12
clientSeq = 12
clientName = "Security Utils"
clientCallback @ 0xF466BFB0
next = 0x91855F14

clientID = 13
clientSeq = 13
clientName = "BACKUP-INT"
clientCallback @ 0xF4A191B0
next = 0x91D3511C

clientID = 14
clientSeq = 14
clientName = "SPAN"
clientCallback @ 0xF4A34F30
next = 0x90FFC8C8

clientID = 15
clientSeq = 15
clientName = "NG3K_SES_CLIENT_SECURITY_CTRL"
clientCallback @ 0xF4CD1D80
next = 0x95AE5834

clientID = 16
clientSeq = 16
clientName = "NG3K_SES_CLIENT_DAI"
clientCallback @ 0xF4CD0C50
next = 0x95AE4854

clientID = 17
clientSeq = 17
clientName = "NG3K_SES_CLIENT_DHCPDN"
clientCallback @ 0xF4CA9D30
next = 0x91DF7728

clientID = 18
clientSeq = 18
clientName = "NG3K_SES_CLIENT_IPSG"
clientCallback @ 0xF4CED70
next = 0x9131DCD8
```

```
clientID = 20
clientSeq = 20
clientName = "DTLS"
clientCallback @ 0xF49B2CB0
next = 0x9134508C

clientID = 21
clientSeq = 21
clientName = "STATS"
clientCallback @ 0xF49BD750
next = 0x9134746C

clientID = 22
clientSeq = 22
clientName = "PLATFORM_MGR"
clientCallback @ 0xF4AB2D40
next = 0x91323D20

clientID = 23
clientSeq = 23
clientName = "LEARNING"
clientCallback @ 0xF49F93C0
next = 0x9091D52C

clientID = 24
clientSeq = 24
clientName = "PLATFORM-SPI"
clientCallback @ 0xF4AAD6F0
next = 0x91F2AE14

clientID = 25
clientSeq = 25
clientName = "EEM"
clientCallback @ 0xF5393370
next = 0x913474F4

clientID = 26
clientSeq = 26
clientName = "NG3K_WIRELESS"
clientCallback @ 0xF4B130B0
next = 0x9131D144

clientID = 27
clientSeq = 27
clientName = "NG3K Environment Variables"
clientCallback @ 0xF4C6DA80
next = 0x00000000

KATANA_DOC#
KATANA_DOC#
KATANA_DOC#show platform ses clients
Client list @ 0x915B312C

clientID = 0
clientSeq = 0
clientName = "TM Shim"
clientCallback @ 0xF4C79A90
next = 0x91182F24

clientID = 1
clientSeq = 1
clientName = "EM-HA"
clientCallback @ 0xF52CA730
```

```
next = 0x913245B8

clientID = 2
clientSeq = 2
clientName = "IFM"
clientCallback @ 0xF4A3EB20
next = 0x934B80E4

clientID = 3
clientSeq = 3
clientName = "PORT-MGR"
clientCallback @ 0xF49FD0A0
next = 0x91D36D08

clientID = 4
clientSeq = 4
clientName = "IDEMAN"
clientCallback @ 0xF4AF6040
next = 0x92121224

clientID = 5
clientSeq = 5
clientName = "MATM"
clientCallback @ 0xF49F7300
next = 0x909194B4

clientID = 6
clientSeq = 6
clientName = "L2 CONTROL"
clientCallback @ 0xF49CA3F0
next = 0x915E4E80

clientID = 7
clientSeq = 7
clientName = "CDP"
clientCallback @ 0xF49C7220
next = 0x915E4F08

clientID = 8
clientSeq = 8
clientName = "UDLD"
clientCallback @ 0xF49C75D0
next = 0x91854CA0

clientID = 9
clientSeq = 9
clientName = "LLDP"
clientCallback @ 0xF49E62F0
next = 0x90919F90

clientID = 10
clientSeq = 10
clientName = "L2M"
clientCallback @ 0xF49CE4D0
next = 0x90E35A5C

clientID = 11
clientSeq = 11
clientName = "Storm-Control"
clientCallback @ 0xF4BA8080
next = 0x9089E9B4

clientID = 12
clientSeq = 12
```

```
clientName = "Security Utils"
clientCallback @ 0xF466BFB0
next = 0x91855F14

clientID = 13
clientSeq = 13
clientName = "BACKUP-INT"
clientCallback @ 0xF4A191B0
next = 0x91D3511C

clientID = 14
clientSeq = 14
clientName = "SPAN"
clientCallback @ 0xF4A34F30
next = 0x90FFC8C8

clientID = 15
clientSeq = 15
clientName = "NG3K_SES_CLIENT_SECURITY_CTRL"
clientCallback @ 0xF4CD1D80
next = 0x95AE5834

clientID = 16
clientSeq = 16
clientName = "NG3K_SES_CLIENT_DAI"
clientCallback @ 0xF4CD0C50
next = 0x95AE4854

clientID = 17
clientSeq = 17
clientName = "NG3K_SES_CLIENT_DHCPSN"
clientCallback @ 0xF4CA9D30
next = 0x91DF7728

clientID = 18
clientSeq = 18
clientName = "NG3K_SES_CLIENT_IPSG"
clientCallback @ 0xF4CDED70
next = 0x9131DCD8

clientID = 20
clientSeq = 20
clientName = "DTLS"
clientCallback @ 0xF49B2CB0
next = 0x9134508C

clientID = 21
clientSeq = 21
clientName = "STATS"
clientCallback @ 0xF49BD750
next = 0x9134746C

clientID = 22
clientSeq = 22
clientName = "PLATFORM_MGR"
clientCallback @ 0xF4AB2D40
next = 0x91323D20

clientID = 23
clientSeq = 23
clientName = "LEARNING"
clientCallback @ 0xF49F93C0
next = 0x9091D52C
```

```
clientID = 24
clientSeq = 24
clientName = "PLATFORM-SPI"
clientCallback @ 0xF4AAD6F0
next = 0x91F2AE14

clientID = 25
clientSeq = 25
clientName = "EEM"
clientCallback @ 0xF5393370
next = 0x913474F4

clientID = 26
clientSeq = 26
clientName = "NG3K_WIRELESS"
clientCallback @ 0xF4B130B0
next = 0x9131D144

clientID = 27
clientSeq = 27
clientName = "NG3K Environment Variables"
clientCallback @ 0xF4C6DA80
next = 0x00000000
```

show platform stack-manager

To display platform-dependent switch-stack information, use the **show platform stack-manager** command in privileged EXEC mode.

show platform stack-manager {**oir-states** | **sdp-counters** | **sif-counters**} **switch** *stack-member-number*

Syntax Description		
oir-states		Displays Online Insertion and Removal (OIR) state information
sdp-counters		Displays Stack Discovery Protocol (SDP) counter information.
sif-counters		Displays Stack Interface (SIF) counter information.
switch <i>stack-member-number</i>		Specifies the stack member for which to display stack-manager information.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines Use the **show platform stack-manager** command to collect data and statistics for the switch stack.

Use this command only when you are working directly with your technical support representative while troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.

show redundancy

To display redundancy facility information, use the **show redundancy** command in privileged EXEC mode

```
show redundancy [{clients | config-sync | counters | history [{reload | reverse}]] | slaves[slave-name]
{clients | counters} | states | switchover history [domain default]]]
```

Syntax Description		
clients	(Optional)	Displays information about the redundancy facility client.
config-sync	(Optional)	Displays a configuration synchronization failure or the ignored mismatched command list (MCL). For more information, see show redundancy config-sync, on page 1107 .
counters	(Optional)	Displays information about the redundancy facility counter.
history	(Optional)	Displays a log of past status and related information for the redundancy facility.
history reload	(Optional)	Displays a log of past reload information for the redundancy facility.
history reverse	(Optional)	Displays a reverse log of past status and related information for the redundancy facility.
slaves	(Optional)	Displays all slaves in the redundancy facility.
<i>slave-name</i>	(Optional)	The name of the redundancy facility slave to display specific information for. Enter additional keywords to display all clients or counters in the specified slave.
clients		Displays all redundancy facility clients in the specified slave.
counters		Displays all counters in the specified slave.
states	(Optional)	Displays information about the redundancy facility state, such as disabled, initialization, standby or active.
switchover history	(Optional)	Displays information about the redundancy facility switchover history.
domain default	(Optional)	Displays the default domain as the domain to display switchover history for.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display information about the redundancy facility:

```
Device# show redundancy
Redundant System Information :
```

```

-----
    Available system uptime = 6 days, 9 hours, 23 minutes
Switchovers system experienced = 0
    Standby failures = 0
    Last switchover reason = not known

    Hardware Mode = Simplex
Configured Redundancy Mode = SSO
Operating Redundancy Mode = SSO
    Maintenance Mode = Disabled
    Communications = Down      Reason: Simplex mode

Current Processor Information :
-----
    Active Location = slot 1
    Current Software state = ACTIVE
    Uptime in current state = 6 days, 9 hours, 23 minutes
    Image Version = Cisco IOS Software, IOS-XE Software, Catalyst 3
850 L3 Switch Software (CAT3850-UNIVERSALK9-M), Version 03.08.59.EMD EARLY DEPLO
YMENT ENGINEERING NOVA_WEEKLY BUILD, synced to DSGS_PI2_POSTPC_FLO_DSBU7_NG3K_11
05
Copyright (c) 1986-2012 by Cisco Systems, Inc.
Compiled Sun 16-S
    Configuration register = 0x102

Peer (slot: 0) information is not available because it is in 'DISABLED' state
Device#

```

This example shows how to display redundancy facility client information:

```

Device# show redundancy clients
Group ID = 1
clientID = 20002   clientSeq = 4   EICORE HA Client
clientID = 24100   clientSeq = 5   WCM_CAPWAP
clientID = 24101   clientSeq = 6   WCM_RRM HA
clientID = 24103   clientSeq = 8   WCM_QOS HA
clientID = 24105   clientSeq = 10  WCM_MOBILITY
clientID = 24106   clientSeq = 11  WCM_DOT1X
clientID = 24107   clientSeq = 12  WCM_APFROGUE
clientID = 24110   clientSeq = 15  WCM_CIDS
clientID = 24111   clientSeq = 16  WCM_NETFLOW
clientID = 24112   clientSeq = 17  WCM_MCAST
clientID = 24120   clientSeq = 18  wcm_comet
clientID = 24001   clientSeq = 21  Table Manager Client
clientID = 20010   clientSeq = 24  SNMP SA HA Client
clientID = 20007   clientSeq = 27  Installer HA Client
clientID = 29      clientSeq = 60  Redundancy Mode RF
clientID = 139     clientSeq = 61  IfIndex
clientID = 3300    clientSeq = 62  Persistent Variable
clientID = 25      clientSeq = 68  CHKPT RF
clientID = 20005   clientSeq = 74  IIF-shim
clientID = 10001   clientSeq = 82  QEMU Platform RF

```

<output truncated>

The output displays the following information:

- clientID displays the client's ID number.
- clientSeq displays the client's notification sequence number.
- Current redundancy facility state.

This example shows how to display the redundancy facility counter information:

```
Device# show redundancy counters
Redundancy Facility OMs

      comm link up = 0
      comm link down = 0
      invalid client tx = 0
      null tx by client = 0
      tx failures = 0
      tx msg length invalid = 0

      client not rxing msgs = 0
      rx peer msg routing errors = 0
      null peer msg rx = 0
      errored peer msg rx = 0

      buffers tx = 0
      tx buffers unavailable = 0
      buffers rx = 0
      buffer release errors = 0

      duplicate client registers = 0
      failed to register client = 0
      Invalid client syncs = 0
```

Device#

This example shows how to display redundancy facility history information:

```
Device# show redundancy history
00:00:00 *my state = INITIALIZATION(2) peer state = DISABLED(1)
00:00:00 RF_EVENT_INITIALIZATION(524) op=0 rc=0
00:00:00 *my state = NEGOTIATION(3) peer state = DISABLED(1)
00:00:01 client added: Table Manager Client(24001) seq=21
00:00:01 client added: SNMP SA HA Client(20010) seq=24
00:00:06 client added: WCM_CAPWAP(24100) seq=5
00:00:06 client added: WCM_QOS HA(24103) seq=8
00:00:07 client added: WCM_DOT1X(24106) seq=11
00:00:07 client added: EICORE HA Client(20002) seq=4
00:00:09 client added: WCM_MOBILITY(24105) seq=10
00:00:09 client added: WCM_NETFLOW(24111) seq=16
00:00:09 client added: WCM_APPFROGUE(24107) seq=12
00:00:09 client added: WCM_RRM HA(24101) seq=6
00:00:09 client added: WCM_MCAST(24112) seq=17
00:00:09 client added: WCM_CIDS(24110) seq=15
00:00:09 client added: wcm_comet(24120) seq=18
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) First Slave(0) op=0 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) Slave(6107) op=0 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) Slave(6109) op=0 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) Slave(6128) op=0 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) Slave(8897) op=0 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) Slave(8898) op=0 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) Slave(8901) op=0 rc=0
00:00:22 RF_EVENT_SLAVE_STATUS_DONE(523) First Slave(0) op=405 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) Redundancy Mode RF(29) op=0 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) IfIndex(139) op=0 rc=0
```

<output truncated>

This example shows how to display information about the redundancy facility slaves:

```
Device# show redundancy slaves
Group ID = 1
Slave/Process ID = 6107 Slave Name = [installer]
Slave/Process ID = 6109 Slave Name = [eicored]
Slave/Process ID = 6128 Slave Name = [snmp_subagent]
Slave/Process ID = 8897 Slave Name = [wcm]
Slave/Process ID = 8898 Slave Name = [table_mgr]
Slave/Process ID = 8901 Slave Name = [iosd]
```

Device#

This example shows how to display information about the redundancy facility state:

```
Device# show redundancy states
my state = 13 -ACTIVE
peer state = 1 -DISABLED
Mode = Simplex
Unit ID = 1

Redundancy Mode (Operational) = SSO
Redundancy Mode (Configured) = SSO
Redundancy State = Non Redundant
Manual Swact = disabled (system is simplex (no peer unit))

Communications = Down Reason: Simplex mode

client count = 75
client_notification_TMR = 360000 milliseconds
keep_alive TMR = 9000 milliseconds
keep_alive count = 0
keep_alive threshold = 18
RF debug mask = 0
```

Device#

show redundancy config-sync

To display a configuration synchronization failure or the ignored mismatched command list (MCL), if any, use the **show redundancy config-sync** command in EXEC mode.

```
show redundancy config-sync {failures {bem | mcl | prc} | ignored failures mcl}
```

Syntax Description	failures	Displays MCL entries or best effort method (BEM)/Parser Return Code (PRC) failures.
	bem	Displays a BEM failed command list, and forces the standby switch to reboot.
	mcl	Displays commands that exist in the switch's running configuration but are not supported by the image on the standby switch, and forces the standby switch to reboot.
	prc	Displays a PRC failed command list and forces the standby switch to reboot.
	ignored failures mcl	Displays the ignored MCL failures.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines When two versions of Cisco IOS images are involved, the command sets supported by two images might differ. If any of those mismatched commands are executed on the active switch, the standby switch might not recognize those commands, which causes a configuration mismatch condition. If the syntax check for the command fails on the standby switch during a bulk synchronization, the command is moved into the MCL and the standby switch is reset. To display all the mismatched commands, use the **show redundancy config-sync failures mcl** command.

To clean the MCL, follow these steps:

1. Remove all mismatched commands from the active switch's running configuration.
2. Revalidate the MCL with a modified running configuration by using the **redundancy config-sync validate mismatched-commands** command.
3. Reload the standby switch.

Alternatively, you could ignore the MCL by following these steps:

1. Enter the **redundancy config-sync ignore mismatched-commands** command.
2. Reload the standby switch; the system transitions to SSO mode.



Note If you ignore the mismatched commands, the out-of-synchronization configuration on the active switch and the standby switch still exists.

3. You can verify the ignored MCL with the **show redundancy config-sync ignored mcl** command.

Each command sets a return code in the action function that implements the command. This return code indicates whether or not the command successfully executes. The active switch maintains the PRC after executing a command. The standby switch executes the command and sends the PRC back to the active switch. A PRC failure occurs if these two PRCs do not match. If a PRC error occurs at the standby switch either during bulk synchronization or line-by-line (LBL) synchronization, the standby switch is reset. To display all PRC failures, use the **show redundancy config-sync failures prc** command.

To display best effort method (BEM) errors, use the **show redundancy config-sync failures bem** command.

This example shows how to display the BEM failures:

```
Device> show redundancy config-sync failures bem
BEM Failed Command List
-----

The list is Empty
```

This example shows how to display the MCL failures:

```
Device> show redundancy config-sync failures mcl
Mismatched Command List
-----

The list is Empty
```

This example shows how to display the PRC failures:

```
Device# show redundancy config-sync failures prc
PRC Failed Command List
-----

The list is Empty
```

show switch

To display information that is related to the stack member or the switch stack, use the **show switch** command in EXEC mode.

```
show switch [{stack-member-number | detail | neighbors | stack-ports [{summary}]]
```

Syntax Description	
<i>stack-member-number</i>	(Optional) Number of the stack member. The range is 1 to 9.
detail	(Optional) Displays detailed information about the stack ring.
neighbors	(Optional) Displays the neighbors of the entire switch stack.
stack-ports	(Optional) Displays port information for the entire switch stack.
summary	(Optional) Displays the stack cable length, the stack link status, and the loopback status.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines This command displays these states:

- **Initializing**—A switch has been just added to the stack and it has not completed the basic initialization to go to the ready state.
- **HA Sync in Progress**—After the standby is elected, the corresponding switch remains in this state until the synchronization is completed.
- **Syncing**—A switch that is added to an already existing stack remains in this state until the switch add sequence is complete.
- **Ready**—The member has completed loading the system- and interface-level configurations and can forward traffic.
- **V-Mismatch**—A switch in version mismatch mode. Version-mismatch mode is when a switch that joins the stack has a software version that is incompatible with the active switch.
- **Provisioned**—The state of a preconfigured switch before it becomes an active member of a switch stack. The MAC address and the priority number in the display are always 0 for the provisioned switch.
- **Unprovisioned**—The state of a switch when the provisioned switch number was unprovisioned using the **no switch switch-number provision** command.
- **Removed**—A switch that was present in the stack was removed using the **reload slot** command.

- Sync not started—When multiple switches are added to an existing stack together, the active switch adds them one by one. The switch that is being added is in the Syncing state. The switches that have not been added yet are in the Sync not started state.
- Lic-Mismatch—A switch has a different license level than the active switch.

A typical state transition for a stack member (including an active switch) booting up is Waiting > Initializing > Ready.

A typical state transition for a stack member in version mismatch (VM) mode is Waiting > Ver Mismatch.

You can use the **show switch** command to identify whether the provisioned switch exists in the switch stack. The **show running-config** and the **show startup-config** privileged EXEC commands do not provide this information.

The display also includes stack MAC-persistence wait-time if persistent MAC address is enabled.

Examples

This example shows how to display summary stack information:

```
Device# show switch
Switch/Stack Mac Address : 6400.f124.e900
```

Switch#	Role	Mac Address	Priority	H/W Version	Current State
1	Member	0000.0000.0000	0	0	Provisioned
2	Member	0000.0000.0000	0	0	Removed
*3	Active	6400.f124.e900	2	0	Ready
8	Member	0000.0000.0000	0	0	Unprovisioned

This example shows how to display detailed stack information:

```
Device# show switch detail
Switch/Stack Mac Address : 2037.06ce.3f80 - Local Mac Address
Mac persistency wait time: Indefinite
```

Switch#	Role	Mac Address	Priority	H/W Version	Current State
*1	Active	2037.06ce.3f80	1	0	Ready
2	Member	0000.000.0000	0	0	Provisioned
6	Member	2037.06ce.1e00	1	0	Ready

Switch#	Stack Port Status		Neighbors	
	Port 1	Port 2	Port 1	Port 2
1	Ok	Down	6	None
6	Down	Ok	None	1

This example shows how to display the member 6 summary information:

```
Device# show switch 6
```

Switch#	Role	Mac Address	Priority	State
6	Member	0003.e31a.1e00	1	Ready

This example shows how to display the neighbor information for a stack:

```
Device# show switch neighbors
```

Switch #	Port A	Port B
6	None	8

```

      8          6          None

```

This example shows how to display stack-port information:

```

Device# show switch stack-ports
Switch #   Port A   Port B
-----
      6     Down     Ok
      8     Ok      Down

```

This example shows the output for the **show switch stack-ports summary** command. The table that follows describes the fields in the display.

Table 42: Show switch stack-ports summary Command Output

Field	Description
Switch#/Port#	Member number and its stack port number.
Stack Port Status	Status of the stack port. <ul style="list-style-type: none"> Absent—No cable is detected on the stack port. Down—A cable is detected, but either no connected neighbor is up, or the stack port is disabled. OK—A cable is detected, and the connected neighbor is up.
Neighbor	Switch number of the active member at the other end of the stack cable.
Cable Length	Valid lengths are 50 cm, 1 m, or 3 m. If the switch cannot detect the cable length, the value is <i>no cable</i> . The cable might not be connected, or the link might be unreliable.
Link OK	Whether the stack cable is connected and functional. There may or may not be a neighbor connected on the other end. The <i>link partner</i> is a stack port on a neighbor switch. <ul style="list-style-type: none"> No—There is no stack cable connected to this port or the stack cable is not functional. Yes—There is a functional stack cable connected to this port.
Link Active	Whether a neighbor is connected on the other end of the stack cable. <ul style="list-style-type: none"> No—No neighbor is detected on the other end. The port cannot send traffic over this link. Yes—A neighbor is detected on the other end. The port can send traffic over this link.
Sync OK	Whether the link partner sends valid protocol messages to the stack port. <ul style="list-style-type: none"> No—The link partner does not send valid protocol messages to the stack port. Yes—The link partner sends valid protocol messages to the port.
# Changes to LinkOK	The relative stability of the link. If a large number of changes occur in a short period of time, link flapping can occur.

Field	Description
In Loopback	Whether a stack cable is attached to a stack port on the member. <ul style="list-style-type: none">• No— At least one stack port on the member has an attached stack cable.• Yes—None of the stack ports on the member has an attached stack cable.

Related Topics

- [reload](#), on page 1081
- [session](#), on page 1083
- [stack-mac update force](#), on page 1117
- [switch priority](#), on page 1121
- [switch provision](#), on page 1122
- [switch renumber](#), on page 1124

show trace messages capwap ap ha

To display wireless control and provisioning of wireless access points (CAPWAP) high availability, use the **show trace messages capwap ap ha** privileged EXEC command.

```
show trace messages capwap ap ha [{detail | event | dump}] [switch switch]
```

Syntax Description		
detail	(Optional) Displays wireless CAPWAP high availability details.	
detail <i>switch number</i>	Specifies the device number. Value is one.	
event	(Optional) Displays wireless CAPWAP high availability events.	
event <i>switch number</i>	Specifies the device number. Value is one.	
dump	(Optional) Displays wireless CAPWAP high availability output.	
dump <i>switch number</i>	Specifies the device number. Value is one.	
switch	(Optional) Displays the device number. The value is one.	
switch <i>switch number</i>	Specifies the device number. Value is one.	
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display CAPWAP high availability output:

```
Device# show trace messages mobility ha dump switch 1
| Output modifiers
<cr>
```

show trace messages mobility ha

To display wireless mobility high availability, use the **show trace messages mobility ha** privileged EXEC command.

```
show trace messages mobility ha [{event|detail|dump}] [switch switch]
```

Syntax Description		
event	(Optional) Displays wireless mobility HA events.	
event <i>switch</i>	Specifies the device number. Value is one.	
detail	(Optional) Displays wireless mobility HA details.	
detail <i>switch</i>	Specifies the device number. Value is one.	
dump	(Optional) Displays the wireless mobility HA output debugging.	
dump <i>switch</i>	Specifies the device number. Value is one.	
switch <i>switch</i>	(Optional) Displays the device number.	
switch <i>switch</i>	Specifies the device number. Value is one.	

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to display wireless mobility high availability:

```
Device# show trace messages mobility ha
```

stack-mac persistent timer

To enable the persistent MAC address feature, use the **stack-mac persistent timer** command in global configuration mode on the switch stack or on a standalone switch. To disable the persistent MAC address feature, use the **no** form of this command.

stack-mac persistent timer [*{0time-value}*]
no stack-mac persistent timer

Syntax Description	0 (Optional) Continues using the MAC address of the current active switch indefinitely, even after a new active switch takes over.
	<i>time-value</i> (Optional) Time period in minutes before the stack MAC address changes to that of the new active switchstack master. The range is 1 to 60 minutes.

Command Default Persistent MAC address is disabled. The MAC address of the stack is always that of the first active switchstack master.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines By default, the stack MAC address will always be the MAC address of the first active switch, even if a new active switch takes over. The same behavior occurs when you enter the **stack-mac persistent timer** command or the **stack-mac persistent timer 0** command.

When you enter the **stack-mac persistent timer** command with a *time-value*, the stack MAC address will change to that of the new active switch after the period of time that you entered whenever a new switch becomes the active switch. If the previous active switch rejoins the stack during that time period, the stack retains its MAC address for as long as the switch that has that MAC address is in the stack.

If the whole stack reloads the MAC address of the active switch is the stack MAC address.



Note If you do not change the stack MAC address, Layer 3 interface flapping does not occur. This also means that a foreign MAC address (a MAC address that does not belong to any of the switches in the stack) could be the stack MAC address. If the switch with this foreign MAC address joins another stack as the active switch, two stacks will have the same stack MAC address. You must use the **stack-mac update force** command to resolve the conflict.

Examples

This example shows how to enable a persistent MAC address:

```
Device(config)# stack-mac persistent timer
```

You can verify your settings by entering the **show running-config** privileged EXEC command. If enabled, **stack-mac persistent timer** is shown in the output.

Related Topics

[stack-mac update force](#), on page 1117

stack-mac update force

To update the stack MAC address to the MAC address of the active switch, use the **stack-mac update force** command in EXEC mode on the active switch.

stack-mac update force

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines By default, the stack MAC address is not changed to the MAC address of the new active switch during a high availability (HA) failover. Use the **stack-mac update force** command to force the stack MAC address to change to the MAC address of the new active switch.

If the switch with the same MAC address as the stack MAC address is currently a member of the stack, the **stack-mac update force** command has no effect. (It does not change the stack MAC address to the MAC address of the active switch.)



Note If you do not change the stack MAC address, Layer 3 interface flapping does not occur. It also means that a foreign MAC address (a MAC address that does not belong to any of the switches in the stack) could be the stack MAC address. If the switch with this foreign MAC address joins another stack as the active switch, two stacks will have the same stack MAC address. You must use the **stack-mac update force** command to resolve the conflict.

This example shows how to update the stack MAC address to the MAC address of the active switch:

```
Device> stack-mac update force
Device>
```

You can verify your settings by entering the **show switch** privileged EXEC command. The stack MAC address includes whether the MAC address is local or foreign.

Related Topics

[show switch](#), on page 1109

[stack-mac persistent timer](#), on page 1115

standby console enable

To enable access to the standby console switch, use the **standby console enable** command in redundancy main configuration submode. To disable access to the standby console switch, use the **no** form of this command.

standby console enable
no standby console enable

Syntax Description This command has no arguments or keywords.

Command Default Access to the standby console switch is disabled.

Command Modes Redundancy main configuration submode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines This command is used to collect and review specific data about the standby console. The command is useful primarily for Cisco technical support representatives troubleshooting the switch.

This example shows how to enter the redundancy main configuration submode and enable access to the standby console switch:

```
Device(config)# redundancy
Device(config-red)# main-cpu
Device(config-r-mc)# standby console enable
Device(config-r-mc)#
```

Related Topics

[main-cpu](#), on page 1073

switch stack port

To disable or enable the specified stack port on the member, use the **switch** command in privileged EXEC mode on a stack member.

```
switch stack-member-number stack port port-number {disable | enable}
```

Syntax Description

<i>stack-member-number</i>	Current stack member number. The range is 1 to 9.
stack port <i>port-number</i>	Specifies the stack port on the member. The range is 1 to 2.
disable	Disables the specified port.
enable	Enables the specified port.

Command Default

The stack port is enabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

A stack is in the full-ring state when all members are connected through the stack ports and are in the ready state.

The stack is in the partial-ring state when the following occurs:

- All members are connected through their stack ports but some are not in the ready state.
- Some members are not connected through the stack ports.



Note Be careful when using the **switch** *stack-member-number* **stack port** *port-number* **disable** command. When you disable the stack port, the stack operates at half bandwidth.

If you enter the **switch** *stack-member-number* **stack port** *port-number* **disable** privileged EXEC command and the stack is in the full-ring state, you can disable only one stack port. This message appears:

```
Enabling/disabling a stack port may cause undesired stack changes. Continue?[confirm]
```

If you enter the **switch** *stack-member-number* **stack port** *port-number* **disable** privileged EXEC command and the stack is in the partial-ring state, you cannot disable the port. This message appears:

```
Disabling stack port not allowed with current stack configuration.
```

Examples

This example shows how to disable stack port 2 on member 4:

```
Device# switch 4 stack port 2 disable
```

Related Topics

[show switch](#), on page 1109

switch priority

To change the stack member priority value, use the **switch priority** command in EXEC mode on the active switchstack master.

switch *stack-member-number* **priority** *new-priority-value*

Syntax Description

stack-member-number Current stack member number. The range is 1 to 9.

new-priority-value New stack member priority value. The range is 1 to 15.

Command Default

The default priority value is 1.

Command Modes

User EXEC

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

The new priority value is a factor when a new active switchstack master is elected. When you change the priority value the active switchstack master is not changed immediately.

Examples

This example shows how to change the priority value of stack member 6 to 8:

```
Device# switch 6 priority 8
Changing the Switch Priority of Switch Number 6 to 8
Do you want to continue?[confirm]
```

Related Topics

[reload](#), on page 1081

[session](#), on page 1083

[show switch](#), on page 1109

[switch renumber](#), on page 1124

switch provision

To supply a configuration to a new switch before it joins the switch stack, use the **switch provision** command in global configuration mode on the active switchstack master. To delete all configuration information that is associated with the removed switch (a stack member that has left the stack), use the **no** form of this command.

switch *stack-member-number* **provision** *type*
no switch *stack-member-number* **provision**

Syntax Description	
	<i>stack-member-number</i> Stack member number. The range is 1 to 9.
	<i>type</i> Switch type of the new switch before it joins the stack.

Command Default The switch is not provisioned.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

For *type*, enter the model number of a supported switch that is listed in the command-line help strings.

To avoid receiving an error message, you must remove the specified switch from the switch stack before using the **no** form of this command to delete a provisioned configuration.

To change the switch type, you must also remove the specified switch from the switch stack. You can change the stack member number of a provisioned switch that is physically present in the switch stack if you do not also change the switch type.

If the switch type of the provisioned switch does not match the switch type in the provisioned configuration on the stack, the switch stack applies the default configuration to the provisioned switch and adds it to the stack. The switch stack displays a message when it applies the default configuration.

Provisioned information appears in the running configuration of the switch stack. When you enter the **copy running-config startup-config** privileged EXEC command, the provisioned configuration is saved in the startup configuration file of the switch stack.



Caution When you use the **switch provision** command, memory is allocated for the provisioned configuration. When a new switch type is configured, the previously allocated memory is not fully released. Therefore, do not use this command more than approximately 200 times, or the switch will run out of memory and unexpected behavior will result.

Examples

This example shows how to provision a switch with a stack member number of 2 for the switch stack. The **show running-config** command output shows the interfaces associated with the provisioned switch.

```
Device(config)# switch 2 provision WS-xxxx
Device(config)# end
```

```
Device# show running-config | include switch 2
!
interface GigabitEthernet2/0/1
!
interface GigabitEthernet2/0/2
!
interface GigabitEthernet2/0/3
<output truncated>
```

You also can enter the **show switch** user EXEC command to display the provisioning status of the switch stack.

This example shows how to delete all configuration information about stack member 5 when the switch is removed from the stack:

```
Device(config)# no switch 5 provision
```

You can verify that the provisioned switch is added to or removed from the running configuration by entering the **show running-config** privileged EXEC command.

Related Topics

[show switch](#), on page 1109

switch renumber

To change the stack member number, use the **switch renumber** command in EXEC mode on the active switchstack master.

switch *current-stack-member-number* **renumber** *new-stack-member-number*

Syntax Description	
<i>current-stack-member-number</i>	Current stack member number. The range is 1 to 9.
<i>new-stack-member-number</i>	New stack member number for the stack member. The range is 1 to 9.

Command Default The default stack member number is 1.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines If another stack member is already using the member number that you just specified, the active switchstack master assigns the lowest available number when you reload the stack member.



Note If you change the number of a stack member, and no configuration is associated with the new stack member number, that stack member loses its current configuration and resets to its default configuration.

Do not use the **switch** *current-stack-member-number* **renumber** *new-stack-member-number* command on a provisioned switch. If you do, the command is rejected.

Use the **reload slot** *current stack member number* privileged EXEC command to reload the stack member and to apply this configuration change.

Examples

This example shows how to change the member number of stack member 6 to 7:

```
Device# switch 6 renumber 7
WARNING:Changing the switch number may result in a configuration change for that switch.
The interface configuration associated with the old switch number will remain as a provisioned
configuration.
Do you want to continue?[confirm]
```

Related Topics

- [reload](#), on page 1081
- [session](#), on page 1083
- [show switch](#), on page 1109
- [switch priority](#), on page 1121



PART **XV**

System Management

- [System Management Commands, on page 1127](#)
- [Tracing Commands, on page 1277](#)



System Management Commands

- [ap hyperlocation](#), on page 1130
- [ap ntp ip](#), on page 1131
- [arp](#), on page 1132
- [boot](#), on page 1133
- [cat](#), on page 1134
- [clear location](#), on page 1135
- [clear location statistics](#), on page 1136
- [clear nmsp statistics](#), on page 1137
- [clear wireless ccx statistics](#), on page 1138
- [clear wireless client tsm dot11](#), on page 1139
- [clear wireless location s69 statistics](#), on page 1140
- [copy](#), on page 1141
- [copy startup-config tftp:](#), on page 1142
- [copy tftp: startup-config](#), on page 1143
- [debug call-admission wireless all](#), on page 1144
- [debug rfid](#), on page 1145
- [debug voice diagnostics mac-address](#), on page 1146
- [debug wps mfp](#), on page 1147
- [delete](#), on page 1148
- [dir](#), on page 1149
- [emergency-install](#), on page 1151
- [exit](#), on page 1153
- [flash_init](#), on page 1154
- [help](#), on page 1155
- [ip nbar protocol-discovery](#), on page 1156
- [l2 traceroute](#), on page 1157
- [license right-to-use](#), on page 1158
- [location](#), on page 1160
- [location algorithm](#), on page 1164
- [location expiry](#), on page 1165
- [location notify-threshold](#), on page 1166
- [location plm calibrating](#), on page 1167
- [location rfid](#), on page 1168

- [location rssi-half-life](#), on page 1169
- [mac address-table move update](#), on page 1170
- [mgmt_init](#), on page 1171
- [mkdir](#), on page 1172
- [more](#), on page 1173
- [nmsp notification interval](#), on page 1174
- [no debug all](#), on page 1176
- [readrtc](#), on page 1177
- [rename](#), on page 1178
- [request platform software console attach switch](#), on page 1179
- [request platform software package clean](#), on page 1181
- [request platform software package copy](#), on page 1183
- [request platform software package describe file](#), on page 1184
- [request platform software package expand](#), on page 1190
- [request platform software package install auto-upgrade](#), on page 1192
- [request platform software package install commit](#), on page 1193
- [request platform software package install file](#), on page 1194
- [request platform software package install rollback](#), on page 1197
- [request platform software package install snapshot](#), on page 1199
- [request platform software package verify](#), on page 1201
- [request platform software package uninstall](#), on page 1202
- [reset](#), on page 1203
- [rmdir](#), on page 1204
- [sdm prefer](#), on page 1205
- [set](#), on page 1206
- [show avc client](#), on page 1209
- [show avc wlan](#), on page 1210
- [show cable-diagnostics tdr](#), on page 1211
- [show ap hyperlocation](#), on page 1213
- [show debug](#), on page 1214
- [show env](#), on page 1215
- [show flow monitor](#), on page 1217
- [show license right-to-use](#), on page 1219
- [show location](#), on page 1221
- [show location ap-detect](#), on page 1222
- [show mac address-table move update](#), on page 1224
- [show nmsp](#), on page 1225
- [show sdm prefer](#), on page 1226
- [show tech-support wireless](#), on page 1228
- [show wireless band-select](#), on page 1230
- [show wireless client calls](#), on page 1231
- [show wireless client dot11](#), on page 1232
- [show wireless client location-calibration](#), on page 1233
- [show wireless client probing](#), on page 1234
- [show wireless client summary](#), on page 1235
- [show wireless client timers](#), on page 1236

- [show wireless client voice diagnostics](#), on page 1237
- [show wireless country](#), on page 1238
- [show wireless detail](#), on page 1241
- [show wireless dtls connections](#), on page 1242
- [show wireless flow-control](#), on page 1243
- [show wireless flow-control statistics](#), on page 1244
- [show wireless load-balancing](#), on page 1245
- [show wireless performance](#), on page 1246
- [show wireless pmk-cache](#), on page 1247
- [show wireless probe](#), on page 1248
- [show wireless sip preferred-call-no](#), on page 1249
- [show wireless summary](#), on page 1250
- [shutdown](#), on page 1251
- [system env temperature threshold yellow](#), on page 1252
- [test cable-diagnostics tdr](#), on page 1254
- [traceroute mac](#), on page 1255
- [traceroute mac ip](#), on page 1258
- [trapflags](#), on page 1260
- [trapflags client](#), on page 1261
- [type](#), on page 1262
- [unset](#), on page 1263
- [version](#), on page 1265
- [wireless client](#), on page 1266
- [wireless client mac-address deauthenticate](#), on page 1268
- [wireless client mac-address](#), on page 1269
- [wireless load-balancing](#), on page 1274
- [wireless sip preferred-call-no](#), on page 1275
- [writertc](#), on page 1276

ap hyperlocation

To configure Hyperlocation and related parameters, use the **ap hyperlocation** command. To disable Hyperlocation and related parameter configuration, use the **no** form of the commands.

[no] ap hyperlocation [**threshold** { **detection** *value-in-dBm* } | { **reset** *value-btwn-0-99* } | { **trigger** *value-btwn-1-100* }]

Syntax Description

[no] ap hyperlocation	Enables or disables Hyperlocation.
threshold detection <i>value-in-dBm</i>	Sets threshold to filter out packets with low RSSI.
threshold reset <i>value-btwn-0-99</i>	Resets value in scan cycles after trigger.
threshold trigger <i>value-btwn-1-100</i>	Sets the number of scan cycles before sending a BAR to clients.
Note	Ensure that the Hyperlocation threshold reset value is less than the threshold trigger value.

Command History

Release	Modification
Cisco IOS XE Denali 16.2.1	This command was introduced.

Related Topics

[show ap hyperlocation](#), on page 1213

ap ntp ip

To configure the IPv4 address of the NTP server, directly reachable by the access points, use the **ap ntp ip** command. To remove the IPv4 address that is configured for the NTP server, use the **no** form of the command.

- NTP is mandatory for Hyperlocation to work. If NTP is not defined, Hyperlocation will not be operational.
- NTP server must be reachable from the AP VLAN.
- If **ap ntp** command is not present, globally configured NTP is used.

[no] ap ntp ip *ipv4-addr*

Syntax Description	<i>ipv4-addr</i> IPv4 address of the NTP server
---------------------------	---

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Related Topics

[show ap hyperlocation](#), on page 1213

arp

To display the contents of the Address Resolution Protocol (ARP) table, use the **arp** command in boot loader mode.

```
arp [ip_address]
```

Syntax Description	<i>ip_address</i> (Optional) Shows the ARP table or the mapping for a specific IP address.
---------------------------	--

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	Boot loader
----------------------	-------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines	The ARP table contains the IP-address-to-MAC-address mappings.
-------------------------	--

Examples	This example shows how to display the ARP table:
-----------------	--

```
Device: arp 172.20.136.8
arp'ing 172.20.136.8...
172.20.136.8 is at 00:1b:78:d1:25:ae, via port 0
```

boot

To load and boot an executable image and display the command-line interface (CLI), use the **boot** command in boot loader mode.

```
boot [-post | -n | -p | flag] filesystem:/file-url...
```

Syntax Description	
-post	(Optional) Run the loaded image with an extended or comprehensive power-on self-test (POST). Using this keyword causes POST to take longer to complete.
-n	(Optional) Pause for the Cisco IOS Debugger immediately after launching.
-p	(Optional) Pause for the JTAG Debugger right after loading the image.
<i>filesystem:</i>	Alias for a file system. Use flash: for the system board flash device; use usbflash0: for USB memory sticks.
<i>/file-url</i>	Path (directory) and name of a bootable image. Separate image names with a semicolon.

Command Default No default behavior or values.

Command Modes Boot loader

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

When you enter the **boot** command without any arguments, the device attempts to automatically boot the system by using the information in the BOOT environment variable, if any.

If you supply an image name for the *file-url* variable, the **boot** command attempts to boot the specified image.

When you specify boot loader **boot** command options, they are executed immediately and apply only to the current boot loader session.

These settings are not saved for the next boot operation.

Filenames and directory names are case sensitive.

Example

This example shows how to boot the device using the *new-image.bin* image:

```
Device: set BOOT flash:/new-images/new-image.bin
Device: boot
```

After entering this command, you are prompted to start the setup program.

cat

To display the contents of one or more files, use the **cat** command in boot loader mode.

cat *filesystem:/file-url...*

Syntax Description

filesystem: Specifies a file system.

/file-url Specifies the path (directory) and name of the files to display. Separate each filename with a space.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

Filenames and directory names are case sensitive.

If you specify a list of files, the contents of each file appears sequentially.

Examples

This example shows how to display the contents of an image file:

```
Device: cat flash:image_file_name
version_suffix: universal-122-xx.SEx
version_directory: image_file_name
image_system_type_id: 0x00000002
image_name: image_file_name.bin
ios_image_file_size: 8919552
total_image_file_size: 11592192
image_feature: IP|LAYER_3|PLUS|MIN_DRAM_MEG=128
image_family: family
stacking_number: 1.34
board_ids: 0x00000068 0x00000069 0x0000006a 0x0000006b
info_end:
```

clear location

To clear a specific radio frequency identification (RFID) tag or all of the RFID tags information in the entire database, use the **clear location** command in EXEC mode.

clear location [**mac-address** *mac-address* | **rfid**]

Syntax Description	mac-address <i>mac-address</i>	MAC address of a specific RFID tag.
	rfid	Specifies all of the RFID tags in the database.
Command Default	No default behavior or values.	
Command Modes	User EXEC	
	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to clear information about all of the RFID tags in the database:

```
Device> clear location rfid
```

clear location statistics

To clear radio-frequency identification (RFID) statistics, use the **clear location statistics** command in EXEC mode.

clear location statistics

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **clear location rfid** command and shows how to clear RFID statistics:

```
Device> clear location statistics
```

clear nmsp statistics

To clear the Network Mobility Services Protocol (NMSP) statistics, use the **clear nmsp statistics** command in EXEC mode.

clear nmsp statistics

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes User Exec
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **clear nmsp statistics** command and shows how to clear all statistics about NMSP information exchanged between the controller and the connected Cisco Mobility Services Engine (MSE):

```
Device> clear nmsp statistics
```

clear wireless ccx statistics

To clear CCX statistics, use the **clear wireless ccx statistics** command in EXEC mode.

clear wireless ccx statistics

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

The following is sample output from the **clear wireless ccx statistics** command and shows how to clear all collected statistics about CCX clients:

```
Device> clear wireless ccx statistics
```

clear wireless client tsm dot11

To clear the traffic stream metrics (TSM) statistics for a particular access point or all of the access points to which this client is associated, use the **clear wireless client tsm dot11** command in EXEC mode.

```
clear wireless client tsm dot11 {24ghz | 5ghz} client-mac-addr {all | name ap-name}
```

Syntax Description		
	24ghz	Specifies the 802.11a network.
	5ghz	Specifies the 802.11b network.
	<i>client-mac-addr</i>	MAC address of the client.
	all	Specifies all access points.
	name ap-name	Name of a Cisco lightweight access point.

Command Default No default behavior or values.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **clear wireless client tsm dot11** command and shows how to clear the TSM for the MAC address 00:40:96:a8:f7:98 on all of the access points 5-GHz radios where this client is known:

```
Device> clear wireless client tsm dot11 5ghz 00:40:96:a8:f7:98 all
```

clear wireless location s69 statistics

To clear statistics about S69 exchanges with CCXv5 clients, use the **clear wireless location s69 statistics** command in EXEC mode.

clear wireless location s69 statistics

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines S69 messages are exchanged between CCXv5 clients and the wireless infrastructure. The CCXv5 client uses S69 message to request location information, that is then returned by the wireless infrastructure through a S69 response message.

Example

The following is sample output from the **clear wireless location s69 statistics** command and shows how to clear statistics about S69 exchanges with CCXv5 clients:

```
Device> clear wireless location s69 statistics
```

copy

To copy a file from a source to a destination, use the **copy** command in boot loader mode.

```
copy filesystem:/source-file-url filesystem:/destination-file-url
```

Syntax Description	<i>filesystem:</i>	Alias for a file system. Use usbflash0: for USB memory sticks.
	<i>/source-file-url</i>	Path (directory) and filename (source) to be copied.
	<i>/destination-file-url</i>	Path (directory) and filename of the destination.

Command Default No default behavior or values.

Command Modes Boot loader

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

Filenames and directory names are case sensitive.

Directory names are limited to 127 characters between the slashes (/); the name cannot contain control characters, spaces, deletes, slashes, quotes, semicolons, or colons.

Filenames are limited to 127 characters; the name cannot contain control characters, spaces, deletes, slashes, quotes, semicolons, or colons.

If you are copying a file to a new directory, the directory must already exist.

Examples

This example shows how to copy a file at the root:

```
Device: copy usbflash0:test1.text usbflash0:test4.text
File "usbflash0:test1.text" successfully copied to "usbflash0:test4.text"
```

You can verify that the file was copied by entering the **dir filesystem:** boot loader command.

copy startup-config tftp:

To copy the configuration settings from a switch to a TFTP server, use the **copy startup-config tftp:** command in Privileged EXEC mode.

copy startup-config tftp: *remote host {ip-address}/{name}*

Syntax Description

remote host {ip-address}/{name} Host name or IP-address of Remote host.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Release 16.1	This command was introduced.

Usage Guidelines

To copy your current configurations from the switch, run the command **copy startup-config tftp:** and follow the instructions. The configurations are copied onto the TFTP server.

Then, login to another switch and run the command **copy tftp: startup-config** and follow the instructions. The configurations are now copied onto the other switch.

Examples

This example shows how to copy the configuration settings onto a TFTP server:

```
Device: copy startup-config tftp:
Address or name of remote host []?
```

copy tftp: startup-config

To copy the configuration settings from a TFTP server onto a new switch, use the **copy tftp: startup-config** command in Privileged EXEC mode on the new switch.

```
copy tftp: startup-config remote host {ip-address}/{name}
```

Syntax Description	<i>remote host {ip-address}/{name}</i> Host name or IP-address of Remote host.
---------------------------	--

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE Release 16.1	This command was introduced.

Usage Guidelines	After the configurations are copied, to save your configurations, use write memory command and then either reload the switch or run the copy startup-config running-config command.
-------------------------	---

Examples	This example shows how to copy the configuration settings from the TFTP server onto a switch:
-----------------	---

```
Device: copy tftp: startup-config
Address or name of remote host []?
```

debug call-admission wireless all

To enable debugging of the wireless Call Admission Control (CAC) feature, use the **debug call-admission wireless all** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug call-admission wireless all [*switch switch*]
no debug call-admission wireless all [*switch switch*]

Syntax Description	switch Configures debugging options for all wireless CAC messages associated to a particular switch.				
Command Default	No default behavior or values.				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

The following is sample output from the **debug call-admission wireless switch** command and shows how to enable debugging options for CAC messages:

```
Device# debug call-admission wireless switch 1 all
```

debug rfid

To configure radio-frequency identification (RFID) debug options, use the **debug rfid** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug rfid {debug_leaf_name | all | detail | error | nmsp | receive} [filter | switch switch]
no debug rfid {debug_leaf_name | all | detail | error | nmsp | receive} [filter | switch switch]
```

Syntax Description

<i>debug_leaf_name</i>	Debug leaf name.
all	Configures debugging of all RFID.
detail	Configures debugging of RFID detail.
error	Configures debugging of RFID error messages.
nmsp	Configures debugging of RFID Network Mobility Services Protocol (NMSP) messages.
receive	Configures debugging of incoming RFID tag messages.
<i>filter</i>	Debug flag filter name.
switch <i>switch</i>	Configures RFID debugging for device.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

The following is sample output from the **debug rfid** command and shows how to enable debugging of RFID error messages:

```
Device# debug rfid error switch 1
```

debug voice diagnostics mac-address

To enable debugging of voice diagnostics for voice clients, use the **debug voice diagnostics mac-address** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug voice diagnostics mac-address *mac-address1* **verbose** **mac-address** *mac-address2* **verbose**
no debug voice diagnostics mac-address *mac-address1* **verbose** **mac-address** *mac-address2* **verbose**

Syntax Description		
voice diagnostics		Configures voice debugging for voice clients.
mac-address <i>mac-address1</i> mac-address <i>mac-address2</i>		Specifies MAC addresses of the voice clients.
verbose		Enables verbose mode for voice diagnostics.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **debug voice diagnostics mac-address** command and shows how to enable debugging of voice diagnostics for voice client with MAC address of 00:1f:ca:cf:b6:60:

```
Device# debug voice diagnostics mac-address 00:1f:ca:cf:b6:60
```

debug wps mfp

To enable WPS MFP debugging options, use the **debug wps mfp** command in privileged EXEC mode. To disable debugging, use the no form of this command.

debug wps mfp { **all** | **capwap** | **client** | **detail** | **mm** | **report** } [**switch** *switch*]

Syntax Description	Command	Description
	wps mfp	Configures WPS MFP debugging options.
	all	Displays all WPS MFP debugging messages.
	capwap	Displays MFP messages.
	client	Displays client MFP messages.
	detail	Displays detailed MFP CAPWAP messages.
	mm	Displays MFP mobility (inter-controller) messages.
	report	Displays MFP reports.
	switch <i>switch</i>	Displays the WPS MFP debugging for the device.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to enable WPS MFP debugging options for client:

```
Device# debug wps mfp client switch 1
```

delete

To delete one or more files from the specified file system, use the **delete** command in boot loader mode.

delete *filesystem:/file-url...*

Syntax Description

filesystem: Alias for a file system. Use **usbflash0**: for USB memory sticks.

/file-url... Path (directory) and filename to delete. Separate each filename with a space.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Filenames and directory names are case sensitive.

The device prompts you for confirmation before deleting each file.

Examples

This example shows how to delete two files:

```
Device: delete usbflash0:test2.text usbflash0:test5.text
Are you sure you want to delete "usbflash0:test2.text" (y/n)?y
File "usbflash0:test2.text" deleted
Are you sure you want to delete "usbflash0:test5.text" (y/n)?y
File "usbflash0:test2.text" deleted
```

You can verify that the files were deleted by entering the **dir usbflash0**: boot loader command.

dir

To display the list of files and directories on the specified file system, use the **dir** command in boot loader mode.

dir *filesystem:/file-url*

Syntax Description

filesystem: Alias for a file system. Use **flash:** for the system board flash device; use **usbflash0:** for USB memory sticks.

/file-url (Optional) Path (directory) and directory name that contain the contents you want to display. Separate each directory name with a space.

Command Default

No default behavior or values.

Command Modes

Boot Loader

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

Directory names are case sensitive.

Examples

This example shows how to display the files in flash memory:

```
Device: dir flash:
Directory of flash:/
  2  -rwx      561   Mar 01 2013 00:48:15  express_setup.debug
  3  -rwx    2160256   Mar 01 2013 04:18:48  c2960x-dmon-mz-150-2r.EX
  4  -rwx      1048   Mar 01 2013 00:01:39  multiple-fs
  6  drwx      512   Mar 01 2013 23:11:42  c2960x-universalk9-mz.150-2.EX
645 drwx      512   Mar 01 2013 00:01:11  dc_profile_dir
647 -rwx     4316   Mar 01 2013 01:14:05  config.text
648 -rwx        5   Mar 01 2013 00:01:39  private-config.text

96453632 bytes available (25732096 bytes used)
```

Table 43: dir Field Descriptions

Field	Description
2	Index number of the file.
-rwx	File permission, which can be any or all of the following: <ul style="list-style-type: none"> • d—directory • r—readable • w—writable • x—executable

Field	Description
1644045	Size of the file.
<date>	Last modification date.
env_vars	Filename.

Related Topics

[mkdir](#), on page 1172

[rmdir](#), on page 1204

emergency-install

To perform an emergency installation on your system, use the **emergency-install** command in boot loader mode.

emergency-install *url://<url>*

Syntax Description	<i><url></i> URL and name of the file containing the emergency installation bundle image.				
Command Default	No default behavior or values.				
Command Modes	Boot loader				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				
Usage Guidelines	The boot flash is erased during the installation operation.				

Example

This example shows how to perform the emergency install operation using the contents of an image file:

```
Device: emergency-install tftp:<url>
The bootflash will be erased during install operation, continue (y/n)?y
Starting emergency recovery (tftp:<url> ...
Reading full image into memory.....done
Nova Bundle Image
-----
Kernel Address      : 0x6042d5c8
Kernel Size        : 0x317ccc/3243212
Initramfs Address  : 0x60745294
Initramfs Size     : 0xdc6774/14444404
Compression Format  : .mzip

Bootable image at @ ram:0x6042d5c8
Bootable image segment 0 address range [0x81100000, 0x81b80000] is in range \
[0x80180000, 0x90000000].
#####
File "sda9:c3850-recovery.bin" uncompressed and installed, entry point: 0x811060f0
Loading Linux kernel with entry point 0x811060f0 ...
Bootloader: Done loading app on core_mask: 0xf

### Launching Linux Kernel (flags = 0x5)

Initiating Emergency Installation of bundle \
tftp:<url>

Downloading bundle tftp:<url>...
```

```
Validating bundle tftp:<url>...
Installing bundle tftp:<url>...
Verifying bundle tftp:<url>...
Package cat3k_caa-base.SPA.03.02.00SE.pkg is Digitally Signed
Package cat3k_caa-drivers.SPA.03.02.00.SE.pkg is Digitally Signed
Package cat3k_caa-infra.SPA.03.02.00SE.pkg is Digitally Signed
Package cat3k_caa-iosd-universalk9.SPA.150-1.EX.pkg is Digitally Signed
Package cat3k_caa-platform.SPA.03.02.00.SE.pkg is Digitally Signed
Package cat3k_caa-wcm.SPA.10.0.100.0.pkg is Digitally Signed
Preparing flash...
Syncing device...
Emergency Install successful... Rebooting
Restarting system.\ufffd
```

```
Booting...(use DDR clock 667 MHz)Initializing and Testing RAM
+++@@@###...++@@@+@@+@@+@@+@@+@@+@@+@@+@@+@@+@@done.
Memory Test Pass!
```

```
Base ethernet MAC Address: 20:37:06:ce:25:80
Initializing Flash...
```

```
flashfs[7]: 0 files, 1 directories
flashfs[7]: 0 orphaned files, 0 orphaned directories
flashfs[7]: Total bytes: 6784000
flashfs[7]: Bytes used: 1024
flashfs[7]: Bytes available: 6782976
flashfs[7]: flashfs fsck took 1 seconds....done Initializing Flash.
```

```
The system is not configured to boot automatically. The
following command will finish loading the operating system
software:
```

```
boot
```

exit

To return to the previous mode or exit from the CLI EXEC mode, use the **exit** command.

exit

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
	This command was introduced.

This example shows how to exit the configuration mode:

```
Device(config)# exit
Device#
```

flash_init

To initialize the flash: file system, use the **flash_init** command in boot loader mode.

flash_init

Syntax Description

This command has no arguments or keywords.

Command Default

The flash: file system is automatically initialized during normal system operation.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

During the normal boot process, the flash: file system is automatically initialized.

Use this command to manually initialize the flash: file system. For example, you use this command during the recovery procedure for a lost or forgotten password.

help

To display the available commands, use the **help** command in boot loader mode.

help

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	Boot loader
----------------------	-------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Example

This example shows how to display a list of available boot loader commands:

```
Device:help
? -- Present list of available commands
arp -- Show arp table or arp-resolve an address
boot -- Load and boot an executable image
cat -- Concatenate (type) file(s)
copy -- Copy a file
delete -- Delete file(s)
dir -- List files in directories
emergency-install -- Initiate Disaster Recovery
...
...
...
unset -- Unset one or more environment variables
version -- Display boot loader version
```

ip nbar protocol-discovery

To configure Networked-Based Application Recognition (NBAR) to discover traffic for all protocols known to NBAR on a particular interface, use the **ip nbar protocol-discovery** interface configuration command. To disable traffic discovery, use the no form of this command.

ip nbar protocol-discovery

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Interface configuration mode

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

The following example configures protocol discovery on an GigabitEthernet interface:

```
Device# interface GigabitEthernet 1/0/1
Device(config-if)# ip nbar protocol-discovery
```

l2 traceroute

To enable the Layer 2 traceroute server, use the **l2 traceroute** command in global configuration mode. Use the **no** form of this command to disable the Layer 2 traceroute server.

l2 traceroute
no l2 traceroute

Syntax Description This command has no arguments or keywords.

Command Modes Global configuration (config#)

Command History	Release	Modification
	Cisco IOS XE 3.3SE	The command was introduced.

Usage Guidelines Layer 2 traceroute is enabled by default and opens a listening socket on User Datagram Protocol (UDP) port 2228. To close the UDP port 2228 and disable Layer 2 traceroute, use the **no l2 traceroute** command in global configuration mode.

The following example shows how to configure Layer 2 traceroute using the **l2 traceroute** command.

```
Device# configure terminal  
Device(config)# l2 traceroute
```

license right-to-use

To configure right-to-use access point adder licenses on the device, use the **license right-to-use** command in privileged EXEC mode.

license right-to-use {**activate** | **deactivate**} **apcount** | **ipbase** | **ipservices** | **lanbase**

Syntax Description		
activate		Activates permanent or evaluation ap-count licenses.
deactivate		Deactivates permanent or evaluation ap-count licenses.
apcount <i>count</i>		Specifies the number of ap-count licenses added. You can configure the number of adder licenses from 5 to 50.
ipbase <i>count</i>		Activates ipbase licenses on the switch.
ipservices <i>count</i>		Activates ipservices licenses on the switch.
lanbase <i>count</i>		Activates lanbase licenses on the switch.

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to activate an ap-count evaluation license:

```
Device# license right-to-use activate apcount evaluation
Device# end
```

This example shows how to activate an ap-count permanent license:

```
Device# license right-to-use deactivate apcount evaluation
Device# end
```

This example shows how to add a new ap-count license:

```
Device# license right-to-use activate apcount 500 slot 1
Device# end
```

location

To configure location information for an endpoint, use the **location** command in global configuration mode. To remove the location information, use the **no** form of this command.

```
location {admin-tag string | algorithm | civic-location identifier {hostid} | civic-location identifier
{hostid} | elin-location {string | identifier id} |
expiry {calibrating-clienttimeout-value | clienttimeout-value | rouge-aps timeout-value | tagsttimeout-value}
| geo-location identifier {hostid} | notify-threshold {clientdb | rouge-apsdb | tagsdb | plm {calibrating |
{multiband | uniband} | clientburst-interval} | prefer {cdp weightpriority-value | lldp-med
weightpriority-value | static config weightpriority-value} | rfid {status
| timeoutrfid-timeout-value | vendor-namename} | rssi-half-life {
calibrating-clientseconds | clientseconds | rogue-apsseconds | tagsseconds}
no location {admin-tag string | algorithm | civic-location identifier {hostid} | civic-location identifier
{hostid} | elin-location {string | identifier id} |
expiry {calibrating-clienttimeout-value | clienttimeout-value | rouge-aps timeout-value | tagsttimeout-value}
| geo-location identifier {hostid} | notify-threshold {clientdb | rouge-apsdb | tagsdb | plm {calibrating |
{multiband | uniband} | clientburst-interval} | prefer {cdp weightpriority-value | lldp-med
weightpriority-value | static config weightpriority-value} | rfid {status
| timeoutrfid-timeout-value | vendor-namename} | rssi-half-life {
calibrating-clientseconds | clientseconds | rogue-apsseconds | tagsseconds}
```

Syntax Description		
admin-tag	<i>string</i>	Configures administrative tag or site information. Site or location information in alphanumeric format.
algorithm		Configures the algorithm used to average RSSI and SNR values.
civic-location		Configures civic location information.
identifier		Specifies the name of the civic location, emergency, or geographical location.
host		Defines the host civic or geo-spatial location.
<i>id</i>		Name of the civic, emergency, or geographical location. Note The identifier for the civic location in the LLDP-MED switch TLV is limited to 250 bytes or less. To avoid error messages about available buffer space during switch configuration, be sure that the total length of all civic-location information specified for each civic-location identifier does not exceed 250 bytes.
elin-location		Configures emergency location information (ELIN).

expiry { calibrating-client client rogue-aps tags } <i>timeout-value</i>	Configures the timeout for RSSI values for calibrating clients, clients, rogue access points, and RFID tags. The valid range for the timeout parameter for calibrating clients is 1 to 3600 seconds, and the default value is 5 seconds. The valid range for the timeout parameter for clients, rogue access points, and RFID tags is 5 to 3600 seconds, and the default value is 5 seconds
geo-location	Configures geo-spatial location information.
notify-threshold { client rogue-aps tags } <i>db</i>	Configures the NMSP notification threshold for RSSI measurements. The valid range for the threshold parameter is 0 to 10 dB, and the default value is 0 dB.
calibrating { multiband uniband } client <i>seconds</i>	Configures path loss measurement (CCX S60) request for calibrating clients and burst interval for clients. The valid range for the burst interval parameter is 0 to 3600 seconds.
prefer	Sets location information source priority.
rfd	Configures RFID tag tracking for a location.
rssi-half-life	Configures the RSSI half life for various devices.

Command Default No default behavior or values.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines After entering the **location civic-location identifier** global configuration command, you enter civic location configuration mode. After entering the **location geo-location identifier** global configuration command, you enter geo location configuration mode.

The civic-location identifier must not exceed 250 bytes.

The host identifier configures the host civic or geo-spatial location. If the identifier is not a host, the identifier only defines a civic location or geo-spatial template that can be referenced on the interface.

The **host** keyword defines the device location. The civic location options available for configuration using the **identifier** and the **host** keyword are the same. You can specify the following civic location options in civic location configuration mode:

- **additional-code**—Sets an additional civic location code.
- **additional-location-information**—Sets additional civic location information.
- **branch-road-name**—Sets the branch road name.
- **building**—Sets building information.
- **city**—Sets the city name.
- **country**—Sets the two-letter ISO 3166 country code.

- **county**—Sets the county name.
- **default**—Sets a command to its defaults.
- **division**—Sets the city division name.
- **exit**—Exits from the civic location configuration mode.
- **floor**—Sets the floor number.
- **landmark**—Sets landmark information.
- **leading-street-dir**—Sets the leading street direction.
- **name**—Sets the resident name.
- **neighborhood**—Sets neighborhood information.
- **no**—Negates the specified civic location data and sets the default value.
- **number**—Sets the street number.
- **post-office-box**—Sets the post office box.
- **postal-code**—Sets the postal code.
- **postal-community-name**—Sets the postal community name.
- **primary-road-name**—Sets the primary road name.
- **road-section**—Sets the road section.
- **room**—Sets room information.
- **seat**—Sets seat information.
- **state**—Sets the state name.
- **street-group**—Sets the street group.
- **street-name-postmodifier**—Sets the street name postmodifier.
- **street-name-premodifier**—Sets the street name premodifier.
- **street-number-suffix**—Sets the street number suffix.
- **street-suffix**—Sets the street suffix.
- **sub-branch-road-name**—Sets the sub-branch road name.
- **trailing-street-suffix**—Sets the trailing street suffix.
- **type-of-place**—Sets the type of place.
- **unit**—Sets the unit.

You can specify the following geo-spatial location information in geo-location configuration mode:

- **altitude**—Sets altitude information in units of floor, meters, or feet.
- **latitude**—Sets latitude information in degrees, minutes, and seconds. The range is from -90 degrees to 90 degrees. Positive numbers indicate locations north of the equator.
- **longitude**—Sets longitude information in degrees, minutes, and seconds. The range is from -180 degrees to 180 degrees. Positive numbers indicate locations east of the prime meridian.
- **resolution**—Sets the resolution for latitude and longitude. If the resolution value is not specified, default value of 10 meters is applied to latitude and longitude resolution parameters. For latitude and longitude, the resolution unit is measured in meters. The resolution value can also be a fraction.
- **default**—Sets the geographical location to its default attribute.
- **exit**—Exits from geographical location configuration mode.
- **no**—Negates the specified geographical parameters and sets the default value.

Use the **no lldp med-tlv-select location information** interface configuration command to disable the location TLV. The location TLV is enabled by default.

This example shows how to configure civic location information on the switch:

```
Device(config)# location civic-location identifier 1
Device(config-civic)# number 3550
Device(config-civic)# primary-road-name "Cisco Way"
Device(config-civic)# city "San Jose"
Device(config-civic)# state CA
Device(config-civic)# building 19
Device(config-civic)# room C6
Device(config-civic)# county "Santa Clara"
Device(config-civic)# country US
Device(config-civic)# end
```

You can verify your settings by entering the **show location civic-location** privileged EXEC command.

This example shows how to configure the emergency location information on the switch:

```
Device(config)# location elin-location 14085553881 identifier 1
```

You can verify your settings by entering the **show location elin** privileged EXEC command.

The example shows how to configure geo-spatial location information on the switch:

```
Device(config)# location geo-location identifier host
Device(config-geo)# latitude 12.34
Device(config-geo)# longitude 37.23
Device(config-geo)# altitude 5 floor
Device(config-geo)# resolution 12.34
```

You can use the **show location geo-location identifier** command to display the configured geo-spatial location details.

location algorithm

To configure the algorithm used to average RSSI and SNR values, use the **location algorithm** command in global configuration mode. To remove the algorithm used to average RSSI and SNR values, use the **no** form of this command.

```
location algorithm {rssi-average | simple}
no location algorithm {rssi-average | simple}
```

Syntax Description	rssi-average	Specifies a more accurate algorithm but with more CPU overhead.
	simple	Specifies faster algorithm with smaller CPU overhead but less accuracy.
Command Default	RSSI average	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to configure a more accurate algorithm but with more CPU overhead:

```
Device# configure terminal
Device(config)# location algorithm rssi-average
Device(config)# end
```

location expiry

To configure the timeout for RSSI values, use the **location expiry** command in global configuration mode.

location expiry { **calibrating-client** | **client** | **rogue-aps** | **tags** } *timeout-value*

Syntax Description

calibrating-client	Specifies the RSSI timeout value for calibrating clients.
client	(Optional) Specifies the RSSI timeout value for clients.
rogue-aps	Specifies the RSSI timeout value for rogue access points.
tags	Specifies the RSSI timeout value for RFID tags.
<i>timeout-value</i>	The valid range for the timeout parameter for calibrating clients is 1 to 3600 seconds, and the default value is 5 seconds. The valid range for the timeout parameter for clients, rogue access points, and RFID tags is 5 to 3600 seconds, and the default value is 5 seconds.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to set the RSSI timeout value for wireless clients:

```
Device# configure terminal
Device(config)# location expiry client 1000
Device(config)# end
```

location notify-threshold

To configure the NMSP notification threshold for RSSI measurements, use the **location notify-threshold** command in global configuration mode. To remove the NMSP notification threshold for RSSI measurements, use the **no** form of this command.

```
location notify-threshold {client | rogue-aps | tags } db
no location notify-threshold {client | rogue-aps | tags }
```

Syntax Description	
client	Specifies the NMSP notification threshold (in dB) for clients and rogue clients. The valid range for the threshold parameter is 0 to 10 dB, and the default value is 0 dB.
rogue-aps	Specifies the NMSP notification threshold (in dB) for rogue access points. The valid range for the threshold parameter is 0 to 10 dB, and the default value is 0 dB.
tags	Specifies the NMSP notification threshold (in dB) for RFID tags. The valid range for the threshold parameter is 0 to 10 dB, and the default value is 0 dB.
<i>db</i>	The valid range for the threshold parameter is 0 to 10 dB, and the default value is 0 dB.

Command Default No default behavior or values.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to configure the NMSP notification threshold to 10 dB for clients. A notification NMSP message is sent to MSE as soon as the client RSSI changes by 10 dB:

```
Device# configure terminal
Device(config)# location notify-threshold client 10
Device(config)# end
```

location plm calibrating

To configure path loss measurement (CCX S60) request for calibrating clients, use the **location plm calibrating** command in global configuration mode.

location plm calibrating {multiband | uniband}

Syntax Description	multiband	Specifies the path loss measurement request for calibrating clients on the associated 802.11a or 802.11b/g radio.
	uniband	Specifies the path loss measurement request for calibrating clients on the associated 802.11a/b/g radio.

Command Default No default behavior or values.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines The uniband is useful for single radio clients (even if the radio is a dual band and can operate in the 2.4-GHz and the 5-GHz bands). The multiband is useful for multiple radio clients.

This example shows how to configure the path loss measurement request for calibrating clients on the associated 802.11a/b/g radio:

```
Device# configure terminal
Device(config)# location plm calibrating uniband
Device(config)# end
```

location rfid

To configure RFID tag tracking for a location, use the **location rfid** command in global configuration mode. To remove a RFID tag tracking for a location, use the **no** form of this command.

```
location rfid { status | timeout seconds | vendor-name name}
no location rfid { status | timeout seconds | vendor-name}
```

Syntax Description

status	Enables location tracking for RFID tags. The no location rfid status command disables location tracking for tags.
timeout seconds	Specifies the location RFID timeout value. Determines the amount of time for which a detected RFID location information is considered as valid. Any RSSI change (below the RSSI threshold) in the configured interval do not result in a new location computation and a message is sent to the MSE. The valid timeout range is from 60 through 7200 seconds.
vendor-name name	Specifies the RFID tag vendor name.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

The **no location rfid status** command disables location RFID status. The **no location rfid timeout** command returns to the default timeout value. The **no location rfid vendor-name** disables tracking for a particular vendor.

The example shows how to configure the static RFID tag data timeout:

```
Device# configure terminal
Device(config)# location rfid timeout 1000
Device(config)# end
```

location rssi-half-life

To configure the RSSI half life for various devices, use the **location rssi-half-life** command in global configuration mode. To remove a RSSI half life for various devices, use the **no** form of this command.

```
location rssi-half-life {calibrating-client | client | rogue-aps | tags } seconds
no location rssi-half-life {calibrating-client | client | rogue-aps | tags }
```

Syntax Description

calibrating-client	Specifies the RSSI half life for calibrating clients.
client	Specifies the RSSI half life for clients.
rogue-aps	Specifies the RSSI half life for rogue access points.
tags	Specifies the RSSI half life for RFID tags.
<i>seconds</i>	The valid range for the half-life parameter is 0, 1, 2, 5, 10, 20, 30, 60, 90, 120, 180, or 300 seconds, and the default value is 0 seconds.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to configure the half life value for a client RSSI to 100 seconds:

```
Device# configure terminal
Device(config)# location rssi-half-life client 100
Device(config)# end
```

mac address-table move update

To enable the MAC address table move update feature, use the **mac address-table move update** command in global configuration mode on the switch stack or on a standalone switch. To return to the default setting, use the **no** form of this command.

```
mac address-table move update {receive | transmit}
no mac address-table move update {receive | transmit}
```

Syntax Description	<p>receive Specifies that the switch processes MAC address-table move update messages.</p> <p>transmit Specifies that the switch sends MAC address-table move update messages to other switches in the network if the primary link goes down and the standby link comes up.</p>				
Command Default	By default, the MAC address-table move update feature is disabled.				
Command Modes	Global configuration				
Command History					
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

Usage Guidelines

The MAC address-table move update feature allows the switch to provide rapid bidirectional convergence if a primary (forwarding) link goes down and the standby link begins forwarding traffic.

You can configure the access switch to send the MAC address-table move update messages if the primary link goes down and the standby link comes up. You can configure the uplink switches to receive and process the MAC address-table move update messages.

Examples

This example shows how to configure an access switch to send MAC address-table move update messages:

```
Device# configure terminal
Device(config)# mac address-table move update transmit
Device(config)# end
```

This example shows how to configure an uplink switch to get and process MAC address-table move update messages:

```
Device# configure terminal
Device(config)# mac address-table move update receive
Device(config)# end
```

You can verify your setting by entering the **show mac address-table move update** privileged EXEC command.

mgmt_init

To initialize the Ethernet management port, use the **mgmt_init** command in boot loader mode.

mgmt_init

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

Use the **mgmt_init** command only during debugging of the Ethernet management port.

Examples

This example shows how to initialize the Ethernet management port:

```
Device: mgmt_init
```

mkdir

To create one or more directories on the specified file system, use the **mkdir** command in boot loader mode.

mkdir *filesystem:/directory-url...*

Syntax Description	<i>filesystem:</i> Alias for a file system. Use usbflash0: for USB memory sticks.
	<i>/directory-url...</i> Name of the directories to create. Separate each directory name with a space.

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	Boot loader
----------------------	-------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	<p>Directory names are case sensitive.</p> <p>Directory names are limited to 127 characters between the slashes (/); the name cannot contain control characters, spaces, deletes, slashes, quotes, semicolons, or colons.</p>
-------------------------	---

Example

This example shows how to make a directory called Saved_Configs:

```
Device: mkdir usbflash0:Saved_Configs
Directory "usbflash0:Saved_Configs" created
```

Related Topics

- [dir](#), on page 1149
- [rmdir](#), on page 1204

more

To display the contents of one or more files, use the **more** command in boot loader mode.

more *filesystem:/file-url...*

Syntax Description

filesystem: Alias for a file system. Use **flash**: for the system board flash device.

/file-url... Path (directory) and name of the files to display. Separate each filename with a space.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

Filenames and directory names are case sensitive.

If you specify a list of files, the contents of each file appears sequentially.

Examples

This example shows how to display the contents of a file:

```
Device: more flash:image_file_name
version_suffix: universal-122-xx.SEx
version_directory: image_file_name
image_system_type_id: 0x00000002
image_name: image_file_name.bin
ios_image_file_size: 8919552
total_image_file_size: 11592192
image_feature: IP|LAYER_3|PLUS|MIN_DRAM_MEG=128
image_family: family
stacking_number: 1.34
board_ids: 0x00000068 0x00000069 0x0000006a 0x0000006b
info_end:
```

nmsp notification interval

To modify the Network Mobility Services Protocol (NMSP) notification interval value on the controller to address latency in the network, use the **nmsp notification interval** command in global configuration mode.

```
nmsp notification interval { attachment | location | rssi { clients | rfid | rogues { ap | client } } }
```

Syntax Description

attachment	Specifies the time used to aggregate attachment information.
location	Specifies the time used to aggregate location information.
rssi	Specifies the time used to aggregate RSSI information.
clients	Specifies the time interval for clients.
rfid	Specifies the time interval for rfid tags.
rogues	Specifies the time interval for rogue APs and rogue clients .
ap	Specifies the time used to aggregate rogue APs .
client	Specifies the time used to aggregate rogue clients.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to set the NMSP notification interval for the active RFID tags to 25 seconds:

```
Device# configure terminal
Device(config)# nmsp notification-interval rfid 25
Device(config)# end
```

This example shows how to modify NMSP notification intervals for device attachment (connecting to the network or disconnecting from the network) every 10 seconds:

```
Device# configure terminal
Device(config)# nmsp notification-interval attachment 10
Device(config)# end
```

This example shows how to configure NMSP notification intervals for location parameters (location change) every 20 seconds:

```
Device# configure terminal  
Device(config)# nmosp notification-interval location 20  
Device(config)# end
```

no debug all

To disable debugging on a switch, use the **no debug all** command in Privileged EXEC mode.

no debug all

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Release 16.1	This command was introduced.

Examples

This example shows how to disable debugging on a switch.

```
Device: no debug all
All possible debugging has been turned off.
```

readrtc

To display the current value of the Real Time Clock (RTC) setting, use the **readrtc** command in boot loader mode.

readrtc

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Boot loader

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Examples

This example shows how to display the current RTC setting:

```
Device: readrtc
Wednesday 03-27-13
11:42:38
```

Related Topics

[writerc](#), on page 1276

rename

To rename a file, use the **rename** command in boot loader mode.

```
rename filesystem:/source-file-url filesystem:/destination-file-url
```

Syntax Description	
<i>filesystem:</i>	Alias for a file system. Use usbflash0: for USB memory sticks.
<i>/source-file-url</i>	Original path (directory) and filename.
<i>/destination-file-url</i>	New path (directory) and filename.

Command Default	No default behavior or values.
-----------------	--------------------------------

Command Modes	Boot loader
---------------	-------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines	<p>Filenames and directory names are case sensitive.</p> <p>Directory names are limited to 127 characters between the slashes (/); the name cannot contain control characters, spaces, deletes, slashes, quotes, semicolons, or colons.</p> <p>Filenames are limited to 127 characters; the name cannot contain control characters, spaces, deletes, slashes, quotes, semicolons, or colons.</p>
------------------	--

Examples	<p>This example shows a file named <i>config.text</i> being renamed to <i>config1.text</i>:</p>
----------	---

```
Device: rename usbflash0:config.text usbflash0:config1.text
```

You can verify that the file was renamed by entering the **dir** *filesystem:* boot loader command.

request platform software console attach switch

To start a session on a member switch, use the **request platform software console attach switch** command in privileged EXEC mode.



Note On stacking switches (Catalyst 3650/3850/9300/9500 switches), this command can only be used to start a session on the standby console. You cannot start a session on member switches. By default, all consoles are already active, so a request to start a session on the active console will result in an error.

request platform software console attach switch { *switch-number* | **active** | **standby** } { **0/0** | **R0** }

Syntax Description

switch-number Specifies the switch number. The range is from 1 to 9.

active Specifies the active switch.

standby Specifies the standby switch.

0/0 Specifies that the SPA-Inter-Processor slot is 0, and bay is 0.

Note Do not use this option with stacking switches. It will result in an error.

R0 Specifies that the Route-Processor slot is 0.

Command Default

By default, all switches in the stack are active.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines

To start a session on the standby switch, you must first enable it in the configuration.

Examples

This example shows how to session to the standby switch:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# redundancy
Device(config-red)# main-cpu
Device(config-r-mc)# standby console enable
Device(config-r-mc)# end
Device# request platform software console attach switch standby R0
#
# Connecting to the IOS console on the route-processor in slot 0.
# Enter Control-C to exit.
#
```

```
Device-stby> enable
Device-stby#
```

request platform software package clean

To remove media files that are not required, use the **request platform software package clean** command in privileged EXEC mode.

```
request platform software package clean [{file URL | pattern URL | switch switch-ID {file URL | pattern URL }]
```

Syntax Description	file <i>URL</i>	(Optional) Specifies the URL to the file. The URL contains the file system, directories, and the filename.
	pattern <i>URL</i>	(Optional) Specifies the pattern to clean one or more matching paths.
	switch <i>switch-ID</i>	(Optional) Specifies the switch for provisioning.

Command Default No default behavior or values

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines

Example

The following example shows how to clean unused media files from the device:

```
Device# request platform software package clean
```

```
This operation may take several minutes...
Running command on switch 1
Cleaning up unnecessary package files
No path specified, will use booted path consolidated:packages.conf
Cleaning sw/isos
  Scanning boot directory for packages ... done.
  Preparing packages list to delete ...
    cat3k_caa-guestshell.BLD_V168_THROTTLE_LATEST_20180925_154546_V16_8_1_191_2.SSA.pkg
      File is in use, will not delete.
    cat3k_caa-rpbase.BLD_V168_THROTTLE_LATEST_20180925_154546_V16_8_1_191_2.SSA.pkg
      File is in use, will not delete.
    cat3k_caa-rpcore.BLD_V168_THROTTLE_LATEST_20180925_154546_V16_8_1_191_2.SSA.pkg
      File is in use, will not delete.
    cat3k_caa-srdriver.BLD_V168_THROTTLE_LATEST_20180925_154546_V16_8_1_191_2.SSA.pkg
      File is in use, will not delete.
    cat3k_caa-webui.BLD_V168_THROTTLE_LATEST_20180925_154546_V16_8_1_191_2.SSA.pkg
      File is in use, will not delete.
  packages.conf
```

```
File is in use, will not delete.  
done.
```

```
SUCCESS: No extra package or provisioning files found on media. Nothing to clean.
```

Related Commands

Command	Description
request platform software package install file	Upgrades a consolidated package or sub-package.
request platform software package install rollback	Rolls back a previous software upgrade.

request platform software package copy

To copy a Cisco IOS XE image file, use the **request platform software package copy** command in privileged EXEC mode.

request platform software package copy switch *switch-ID* **file** *file-URL* **to** *file-URL*

Syntax Description

switch <i>switch-ID</i>	Specifies the switch for provisioning.
file <i>file-URL</i>	URL to the consolidated package or sub-package.
to	Specifies the destination URL to where the files are to be copied.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines

Example

The following example shows how to copy an image file to a destination directory:

```
Device# request platform software package copy switch all file
tftp://10.10.11.250/cat3k_caa-universalk9.16.08.05.SPA.bin to
ftp://cat3k_caa-universalk9.16.08.05.SPA.bin
```

Command	Description
request platform software package install file	Upgrades a consolidated package or sub-package.
request platform software package install rollback	Rolls back a previous software upgrade.

request platform software package describe file

To gather descriptive information about an individual module or a Cisco IOS-XE image file, use the **request platform software package describe file** command in privileged EXEC or diagnostic mode.

request platform software package describe file *URL* [**detail**] [**verbose**]

Syntax Description	<i>URL</i>	Specifies the URL to the file. The <i>URL</i> contains the file system, directories, and the filename.
	detail	(Optional) Specifies detailed output.
	verbose	(Optional) Displays verbose information, meaning that all information about the file is displayed on the console.

Command Default No default behavior or values.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines This command can only be used to gather information on individual module and Cisco IOS-XE image files. Using this command to collect information on any other file will generate output, but the generated output is useless.

The output of this command can be used for the following functions:

- To confirm the individual module files that are part of a Cisco IOS-XE image.
- To confirm whether or not a file is bootable.
- To confirm the contexts in which a file must be reloaded or booted.
- To confirm whether or not a file is corrupted.
- To confirm file and header sizes, build dates, and various other general information.

Examples

In the following example, this command is entered to gather information about an individual SIP Base module file on the bootflash: file system.

```
Device# request platform software package describe file
bootflash:cat3k_caa-universalk9_universalk9.16.09.02.SPA.bin

Package: cat3k_caa-universalk9_universalk9.16.09.02.SPA.bin
Size: 36954316
Timestamp: 2018-11-07 15:36:27 UTC
Canonical path: /bootflash/cat3k_caa-universalk9_universalk9.16.09.02.SPA.bin

Raw disk-file SHA1sum:
3ee37cdbe276316968866b16df7d8a5733a1502e
```

```
Computed SHA1sum:
  f2db80416a1245a5b1abf2988088860b38ce7898
Contained SHA1sum:
  f2db80416a1245a5b1abf2988088860b38ce7898
Hashes match. Package is valid.

Header size:      204 bytes
Package type:     10000
Package flags:    0
Header version:   0

Internal package information:
Name: cc
BuildTime: 2018-11-07_05.24
ReleaseDate: Wed 07-Nov-18 01:00
RouteProcessor: rpl
Platform: Cat3XXX
User: mcpre
PackageName: ipbasek9
Build: cat3k_caa-universalk9_universalk9.16.09.02.SPA.bin
```

Package is bootable on SIP when specified
by packages provisioning file.

In the following example, this command is used to gather information about a Cisco IOS-XE image
on the bootflash: file system.

```
Device# request platform software package describe file
bootflash:cat3k_caa-universalk9_universalk9.16.09.02.SPA.bin

Package: cat3k_caa-universalk9_universalk9.16.09.02.SPA.bin
Size: 218783948
Timestamp: 2018-11-07 17:14:09 UTC
Canonical path: /bootflash/cat3k_caa-universalk9_universalk9.16.09.02.SPA.bin

Raw disk-file SHA1sum:
  d2999fc7e27e01344903a42ffacd62c156eba4cc

Computed SHA1sum:
  5f8cda8518d01d8282d80ecd34f7715783f4a813
Contained SHA1sum:
  5f8cda8518d01d8282d80ecd34f7715783f4a813
Hashes match. Package is valid.

Header size:      204 bytes
Package type:     30000
Package flags:    0
Header version:   0

Internal package information:
Name: rp_super
BuildTime: 2018-11-07_05.24
ReleaseDate: Wed 07-Nov-18 01:00
RouteProcessor: rpl
Platform: Cat3XXX
User: mcpre
PackageName: ipbasek9
Build: cat3k_caa-universalk9_universalk9.16.09.02

Package is bootable from media and tftp.
Package contents:
```

```
Package: cat3k_caa-universalk9_universalk9.16.09.02.SPA.bin
Size: 52072652
Timestamp: 2018-11-07 13:33:13 UTC

Raw disk-file SHA1sum:
  flaad6d687256aa327a4efa84deab949fbed12b8

Computed SHA1sum:
  15502fd1b8f9ffd4af4014ad4d8026c837929fe6
Contained SHA1sum:
  15502fd1b8f9ffd4af4014ad4d8026c837929fe6
Hashes match. Package is valid.

Header size:      204 bytes
Package type:     20000
Package flags:    0
Header version:   0

Internal package information:
  Name: fp
  BuildTime: 2018-11-07_05.24
  ReleaseDate: Wed 07-Nov-18 01:00
  RouteProcessor: rp1
  Platform: Cat3XXX
  User: mcpre
  PackageName: ipbasek9
  Build: cat3k_caa-universalk9_universalk9.16.09.02.SPA.bin

Package is bootable on ESP when specified
by packages provisioning file.

Package: cat3k_caa-universalk9_universalk9.16.09.02.SPA.bin
Size: 21844172
Timestamp: 2018-11-07 13:33:01 UTC

Raw disk-file SHA1sum:
  025e6159dd91cef9d254ca9fff2602d8ce065939

Computed SHA1sum:
  ealb358324ba5815b9ea623b453a98800eae1c78
Contained SHA1sum:
  ealb358324ba5815b9ea623b453a98800eae1c78
Hashes match. Package is valid.

Header size:      204 bytes
Package type:     30004
Package flags:    0
Header version:   0

Internal package information:
  Name: ipbasek9
  BuildTime: 2018-11-07_05.24
  ReleaseDate: Wed 07-Nov-07 01:00
  RouteProcessor: rp1
  Platform: Cat3XXXX
  User: mcpre
  PackageName: ipbasek9
  Build: 16.9.20180925:160127

Package is not bootable.
```

```
Package: cat3k_caa-universalk9.16.09.02.SPA.bin
Size: 21520588
Timestamp: 2007-12-04 13:33:06 UTC
```

```
Raw disk-file SHA1sum:
  432dfa61736d8a51baefbb2d70199d712618dcd2
```

```
Computed SHA1sum:
  83c0335a3adcea574bff237a6c8640a110a045d4
```

```
Contained SHA1sum:
  83c0335a3adcea574bff237a6c8640a110a045d4
```

Hashes match. Package is valid.

```
Header size:      204 bytes
Package type:     30001
Package flags:    0
Header version:   0
```

Internal package information:

```
Name: rp_base
BuildTime: 2007-12-04_05.24
ReleaseDate: Tue 04-Dec-07 01:00
RouteProcessor: rp1
Platform: Cat3XXX
User: mcpre
PackageName: ipbasek9
Build: v_16.9.20180925:160127
```

Package is bootable on RP when specified
by packages provisioning file.

```
Package: cat3k_caa-universalk9_universalk9.16.09.02.SPA.bin
Size: 24965324
Timestamp: 2018-11-07 13:33:08 UTC
```

```
Raw disk-file SHA1sum:
  eb964b33d4959c21b605d0989e7151cd73488a8f
```

```
Computed SHA1sum:
  19b58886f97c79f885ab76c1695d1a6f4348674e
```

```
Contained SHA1sum:
  19b58886f97c79f885ab76c1695d1a6f4348674e
```

Hashes match. Package is valid.

```
Header size:      204 bytes
Package type:     30002
Package flags:    0
Header version:   0
```

Internal package information:

```
Name: rp_daemons
BuildTime: 2018-11-07_05.24
ReleaseDate: Wed 07-Nov-07 01:00
RouteProcessor: rp1
Platform: Cat3XXX
User: mcpre
PackageName: ipbasek9
Build: v_16.9.20180925:160127
```

Package is not bootable.

```
Package: cat3k_caa-universalk9.16.09.02.SPA.bin
```

```

Size: 48515276
Timestamp: 2007-12-04 13:33:13 UTC

Raw disk-file SHA1sum:
  bc13462d6a4af7a817a7346a44a0ef7270e3a81b

Computed SHA1sum:
  f1235d703cc422e53bce850c032ff3363b587d70
Contained SHA1sum:
  f1235d703cc422e53bce850c032ff3363b587d70
Hashes match. Package is valid.

```

```

Header size:      204 bytes
Package type:     30003
Package flags:    0
Header version:   0

```

```

Internal package information:
  Name: rp_losd
  BuildTime: 2007-12-04_05.24
  ReleaseDate: Tue 04-Dec-07 01:00
  RouteProcessor: rpl
  Platform: Cat3XXX
  User: mcpre
  PackageName: ipbasek9
  Build: v_16.9.20180925:160127

```

Package is not bootable.

```

Package: cat3k_caa-universalk9.16.09.02.SPA.bin
Size: 36954316
Timestamp: 2007-12-04 13:33:11 UTC

```

```

Raw disk-file SHA1sum:
  3ee37cdbe276316968866b16df7d8a5733a1502e

Computed SHA1sum:
  f2db80416a1245a5b1abf2988088860b38ce7898
Contained SHA1sum:
  f2db80416a1245a5b1abf2988088860b38ce7898
Hashes match. Package is valid.

```

```

Header size:      204 bytes
Package type:     10000
Package flags:    0
Header version:   0

```

```

Internal package information:
  Name: cc
  BuildTime: 2007-12-04_05.24
  ReleaseDate: Tue 04-Dec-07 01:00
  RouteProcessor: rpl
  Platform: Cat3XXX
  User: mcpre
  PackageName: ipbasek9
  Build: v_16.9.20180925:160127

```

Package is bootable on SIP when specified
by packages provisioning file.

```

Package: cat3k_caa-universalk9.16.09.02.SPA.bin
Size: 19933388

```

```

Timestamp: 2007-12-04 13:33:06 UTC

Raw disk-file SHA1sum:
  44b6d15cba31fb0e9b27464665ee8a24b92adfd2

Computed SHA1sum:
  b1d5faf093b183e196c7c8e1023fe1f7aafdd36d
Contained SHA1sum:
  b1d5faf093b183e196c7c8e1023fe1f7aafdd36d
Hashes match. Package is valid.

Header size:      204 bytes
Package type:     10001
Package flags:    0
Header version:   0

Internal package information:
  Name: cc_spa
  BuildTime: 2007-12-04_05.24
  ReleaseDate: Tue 04-Dec-07 01:00
  RouteProcessor: rp1
  Platform: Cat3XXX
  User: mcpre
  PackageName: ipbasek9
  Build: v_16.9.20180925:160127

Package is not bootable.

```

Related Commands

Command	Description
request platform software package install file	Upgrades an individual package or a superpackage file.

request platform software package expand

To extract the individual modules from a Cisco IOS-XE image, use the **request platform software package expand** command in privileged EXEC mode.

request platform software package expand {file *source-URL* | switch *switch-ID* file *source-URL*}[
to *destination-URL*] [**auto-copy**] [**force**] [**overwrite**] [**retain-source-file**] [**verbose**] [**wipe**]

Syntax Description

<i>source-URL</i>	Specifies the URL to the Cisco IOS-XE file that stores the contents that will be extracted.
switch <i>switch-ID</i>	Specifies the switch ID.
to <i>destination-URL</i>	(Optional) Specifies the destination URL where the files that were extracted from the Cisco IOS-XE file are left after the operation is complete. If this option is not entered, the Cisco IOS-XE image file contents are extracted onto the same directory where the Cisco IOS-XE image file is currently stored.
auto-copy	(Optional) Copies packages to provisioning directory.
force	(Optional) Specifies that the operation will be forced, meaning that the upgrade will proceed despite any warning messages.
over-write	(Optional) Overwrites non-identical packages and unused provisioning files.
retain-to-source	(Optional) Retains the source file after expansion.
verbose	(Optional) Displays verbose information, meaning all output that can be displayed on the console during the process will be displayed.
wipe	(Optional) Erases all content on the destination snapshot directory before extracting the files and placing them on the snapshot directory.

Command Default

No default behavior or values

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines

This command only extracts individual module files and a provisioning file from the Cisco IOS-XE image. Additional configuration is needed to configure the router to boot using the provisioning files and run using the individual modules.

When this command is used, copies of each module and the provisioning file within the Cisco IOS-XE image are copied and placed on the destination directory. The Cisco IOS-XE image file is unchanged after the operation is complete.

If the **to destination-URL** option is not entered, the Cisco IOS-XE image contents will be extracted onto the same directory where the Cisco IOS-XE image is currently stored.

If this command is used to extract individual module files onto a directory that already contains individual module files, the files are extracted to an automatically created directory on the destination device.

Examples

The following example shows how to extract individual modules and the provisioning file from a Cisco IOS-XE image that has already been placed in the directory where the user wants to store the individual modules and the provisioning file.

Output of the directory before and after the extraction is given to confirm that files were extracted.

```
Device# dir bootflash:

Directory of bootflash:/
 11  drwx          16384   Dec 4 2018 11:26:07 +00:00  lost+found
14401 drwx           4096   Dec 4 2018 11:27:41 +00:00  .installer
 12  -rw-       218783948   Dec 4 2018 12:12:16 +00:00  cat3k_caa-universalk9.16.09.02.SPA.bin

Device# request platform software package expand file
bootflash:cat3k_caa-universalk9.16.09.02.SPA.bin

Verifying parameters
Validating package type
Copying package files

Device# dir bootflash:

Directory of bootflash:/
 11  drwx          16384   Dec 4 2018 11:26:07 +00:00  lost+found
14401 drwx           4096   Dec 4 2018 11:27:41 +00:00  .installer
 12  -rw-       218783948   Dec 4 2018 12:12:16 +00:00  cat3k_caa-universalk9.16.09.02.SPA.bin
28802 -rw-           7145   Dec 4 2018 12:14:22 +00:00  packages.conf
928833536 bytes total (483700736 bytes free)
```

Related Commands

Command	Description
request platform software package install file	Upgrades an individual module or a Cisco IOS-XE file.

request platform software package install auto-upgrade

To initiate automatic upgrade of software on all incompatible switches, use the **request platform software package install auto-upgrade** command in privileged EXEC mode.

request platform software package install auto-upgrade

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Examples

The following example shows how to automatically upgrade the software:

```
Device# request platform software package install auto-upgrade
```

Related Commands

Command	Description
request platform software package install file	Upgrades a consolidated package or sub-package.
request platform software package install rollback	Rolls back a previous software upgrade.

request platform software package install commit

To cancel the rollback timer and commit a software upgrade, use the **request platform software package install commit** command in privileged EXEC mode.

```
request platform software package install switch switch-ID commit [verbose]
```

Syntax Description	switch <i>switch-ID</i>	Specifies the switch ID.
	verbose	(Optional) Displays verbose information, meaning all information that can be displayed on the console during the process will be displayed.

Command Default No default behavior or values.

Command Modes Privileged EXEC (#)

Release	Modification
Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines This command is entered after the **request platform software package install switch *switch-ID* file auto-rollback** command is used to begin an individual sub-package or a consolidated package upgrade. When the **auto-rollback *minutes*** option is used, a rollback timer that cancels the upgrade after the number of specified *minutes* cancels the upgrade if the **request platform software package install switch *switch-ID* commit** command is not entered to commit the upgrade.

The rollback timer expires and the upgrade does not complete; and the device continues running the previous sub-package or consolidated package.

Examples

The following example shows how to commit an upgrade:

```
Device# request platform software package install switch all commit
```

Related Commands	Command	Description
	request platform software package install file	Upgrades a consolidated package or sub-package.
	request platform software package install rollback	Rolls back a previous software upgrade.

request platform software package install file

To upgrade a consolidated package or an individual sub-package, use the **request platform software package install file** command in privileged EXEC mode.

request platform software package install switch *switch-ID* **file** *file-URL* [**auto-rollback** *minutes*] [**interface-module-delay** *seconds*] [**provisioning-file** *provisioning-file-URL*] [**slot** *slot-number*] [**bay** *bay-number*] [**auto-copy**] [**force**] [**ignore-compact-check**] [**mdr**] [**new**] [**on-reboot**] [**retain-source-file**] [**verbose**]

Syntax Description

switch <i>switch-ID</i>	Specifies the switch for provisioning.
<i>file-URL</i>	URL to the consolidated package or sub-package.
auto-rollback <i>minutes</i>	(Optional) Specifies the setting of a rollback timer, and sets the number of minutes on the rollback timer before the rollback timer expires.
interface-module-delay <i>seconds</i>	(Optional) Specifies the interface module restart timeout delay.
provisioning-file <i>provisioning-file-URL</i>	(Optional) Specifies the URL to the provisioning file. A provisioning file is used for booting only when a device is booted using individual sub-packages.
slot <i>slot-number</i>	(Optional) Specifies the device slot number where a shared port adapter interface processor (SIP) can be installed.
bay <i>bay-number</i>	(Optional) Specifies the shared port adapter (SPA) bay number within a SIP.
auto-copy	(Optional) Specifies that the device will automatically copy packages to provisioning directory.
force	(Optional) Specifies that the operation will be forced, meaning that the upgrade will proceed despite any warning messages.
ignore-compact-check	(Optional) Specifies that the compatibility check is ignored.
mdr	(Optional) Specifies that minimal disruptive restart is used.
new	(Optional) Creates a new package provisioning file.
on-reboot	(Optional) Specifies that the installation will not be completed until the next RP reboot.
retain-source-file	(Optional) Retains the source file after installation.
verbose	(Optional) Displays verbose information, meaning all output that can be displayed on the console during the process will be displayed.

Command Default

If you do not enter the **request platform software package install file** command, the consolidated or sub package upgrades are not initiated on the device.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines This command is used to upgrade consolidated packages and individual sub-packages.

When the **auto-rollback** *minutes* option is used, the **request platform software package install switch** *switch-ID* **commit** command must be entered before the rollback timer expires to complete the upgrade. If this command is not entered, the device rolls back to the previous software version. The rollback timer expires after the number of specified *minutes*. If the **auto-rollback** *minutes* option is not used, the upgrade automatically happens.

In the following example, the **request platform software package install** command is used to upgrade a consolidated package. The **force** option, which forces the upgrade past any prompt (such as, already having the same consolidated package installed), is used in this example.

```
Device# request platform software package install rp 0 file
bootflash:cat3k_caa-universalk9.16.03.05.SPA.bin force

--- Starting installation state synchronization ---
Finished installation state synchronization
--- Starting file path checking ---
Finished file path checking
--- Starting image file verification ---
Checking image file names
Verifying image file locations
Locating image files and validating name syntax
Inspecting image file types
Processing image file constraints
Extracting super package content
Verifying parameters
Validating package type
Copying package files
Checking and verifying packages contained in super package
Creating candidate provisioning file

WARNING:
WARNING: Candidate software will be installed upon reboot
WARNING:

Finished image file verification
--- Starting candidate package set construction ---
Verifying existing software set
Processing candidate provisioning file
Constructing working set for candidate package set
Constructing working set for running package set
Checking command output
Constructing merge of running and candidate packages
Finished candidate package set construction
--- Starting compatibility testing ---
Determining whether candidate package set is compatible
WARNING:
WARNING: Candidate software combination not found in compatibility database
WARNING:
Determining whether installation is valid
Determining whether installation is valid ... skipped
Checking IPC compatibility with running software
```

```

Checking IPC compatibility with running software ... skipped
Checking candidate package set infrastructure compatibility
Checking infrastructure compatibility with running software
Checking infrastructure compatibility with running software ... skipped
Finished compatibility testing
--- Starting commit of software changes ---
Updating provisioning rollback files
Creating pending provisioning file
Committing provisioning file
Finished commit of software changes
SUCCESS: Software provisioned. New software will load on reboot.

```

```
Device# reload
```



Note A reload must be performed to finish this procedure.

Related Commands

Command	Description
request platform software package install commit	Cancels the rollback timer and commits a software upgrade.
request platform software package install rollback	Rolls back a previous software upgrade.
request platform software package install snapshot	Creates a snapshot directory that will contain all the files extracted from a consolidated package.

request platform software package install rollback

To roll back a previous software upgrade, use the **request platform software package install rollback** command in privileged EXEC mode.

request platform software package install switch *switch-ID* **rollback** [{**as-booted** | **provisioning-file** *provisioning-file-URL*}] [**auto-copy**] [**force**] [**ignore-compact-check**] [**new**] [**on-reboot**] [**retain-source-file**] [**verbose**]

Syntax Description		
switch <i>switch-ID</i>		Specifies the switch for provisioning.
as-booted		(Optional) Specifies that the software update will not occur, and that the device will instead boot using the same procedure that it used during the last reboot.
provisioning-file <i>provisioning-file-URL</i>		(Optional) Specifies that the software update will not occur, and that the device will instead boot using the specified provisioning file.
auto-copy		(Optional) Specifies that the device will automatically copy packages to provisioning directory.
force		(Optional) Specifies that the operation will be forced, meaning that the upgrade will proceed despite any warning messages.
ignore-compact-check		(Optional) Specifies that the compatibility check is ignored.
new		(Optional) Creates a new package provisioning file.
on-reboot		(Optional) Specifies that the installation will not be completed until the next reboot.
retain-source-file		(Optional) Retains the source file after installation,
verbose		(Optional) Displays verbose information, meaning all output that can be displayed on the console during the process will be displayed.

Command Default No default behavior or values

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Everest 16.1.1	This command was introduced.

Usage Guidelines This command rolls back a configuration that has an active rollback timer. Active rollback timers are used when the **auto-rollback** option is entered when software is being upgraded using the **request platform software package install file** command.

Examples

The following example shows that an upgrade using a rollback timer is rolled back to the previous configuration:

```
Device# request platform software package install switch all rollback
```

Related Commands

Command	Description
request platform software package install commit	Cancel the rollback timer and commits a software upgrade.
request platform software package install file	Upgrades a consolidated package or an individual sub-package.

request platform software package install snapshot

To create a snapshot directory that contains all the files extracted from a consolidated package, use the **request platform software package install snapshot** command in privileged EXEC mode.

request platform software package install switch *switch-ID* **snapshot to** *URL* [**as** *snapshot-provisioning-filename*] [**force**] [**verbose**] [**wipe**]

Syntax Description		
switch <i>switch-ID</i>		Specifies the switch for provisioning.
snapshot to <i>URL</i>		Creates a directory and extracts all files from the consolidated package into that directory. The directory is named in the command-line as part of the <i>URL_FS</i> . If the <i>URL_FS</i> is specified as a file system, the files in the consolidated package will be extracted onto the file system and not a directory on the file system.
as <i>snapshot-provisioning-filename</i>		(Optional) Renames the provisioning file in the snapshot directory. If this option is not used, the existing provisioning filename of the provisioning file in the consolidated package is used.
wipe		(Optional) Erases all content on the destination snapshot directory before extracting files and placing them on the snapshot directory.
force		(Optional) Specifies that the operation will be forced; meaning that the upgrade will proceed despite any warning messages.
verbose		(Optional) Displays verbose information, meaning all output is displayed on the console during the provisioning process.

Command Default No default behavior or values

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Everest 16.1.1	This command was introduced.

Usage Guidelines This command is used to create a directory at the destination device and extract the individual sub-packages in a consolidated package to that directory.

The **request platform software package expand** command is the only other command that can be used to extract individual sub-packages from a consolidated package.

Examples

In the following example, a snapshot directory named `snapdir1_snap` is created in the bootflash: file system, and the individual sub-package files from the consolidated package are extracted into the snapshot directory.

The second portion of the example first sets up the router to reboot using the files in the snapshot directory (deletes all previous boot system commands, configures the configuration register, then enters a boot system command to boot using the extracted provisioning file), saves the new configuration, then reboots so the device will boot using the extracted provisioning file, which allows the router to run using the extracted individual sub-package files.

```
Device# request platform software package install switch all snapshot to
bootflash:snapdir1_snap

--- Starting active image file snapshot --- Validating snapshot parameters Creating
destination directory
Copying files to destination media
  Copied provisioning file as packages.conf
Moving files into final location Finished active image file snapshot
Device(config)# no boot system
Device(config)# config-register 0x1
Device(config)# boot system harddisk:snapdir1_snap/packages.conf
Device(config)# exit
*May 11 01:31:04.815: %SYS-5-CONFIG_I: Configured from console by con
Device# write memory

Building configuration...
[OK]

Device# reload
```

Related Commands

Command	Description
request platform software package install file	Upgrades a consolidated package or an individual sub-package.

request platform software package verify

To verify the In-Service Software Upgrade (ISSU) software package compatibility, use the **requestplatform software package verify** command in privileged EXEC mode.

```
request platform software package verify switch switch-ID file file-URL [bay bay-number] [slot slot-number] [auto-copy] [force] [mdr]
```

Syntax Description

switch <i>switch-ID</i>	Specifies the switch for provisioning.
<i>file-URL</i>	URL to the consolidated package or sub-package.
bay <i>bay-number</i>	(Optional) Specifies the shared port adapter (SPA) bay number within a SIP.
slot <i>slot-number</i>	(Optional) Specifies the device slot number where a shared port adapter interface processor (SIP) can be installed.
auto-copy	(Optional) Specifies that the device will automatically copy packages to provisioning directory.
force	(Optional) Specifies that the operation will be forced, meaning that the upgrade will proceed despite any warning messages.
mdr	(Optional) Specifies that minimal disruptive restart is used.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Denali 16.1.1	This command was introduced.

Example

The following example shows how to verify Cisco IOS XE image:

```
Device# request platform software package verify switch all file
bootflash:cat3k_caa-universalk9.16.03.05.SPA.bin
```

Related Commands

Command	Description
request platform software package install commit	Cancels the rollback timer and commits a software upgrade.
request platform software package install rollback	Rolls back a previous software upgrade.
request platform software package install snapshot	Creates a snapshot directory that will contain all the files extracted from a consolidated package.

request platform software package uninstall

To uninstall a software package, use the **request platform software package uninstall** command in privileged EXEC mode.

request platform software package uninstall **switch** *switch-ID* **file** *file-URL* [**bay** *bay-number*] [**slot** *slot-number*] [**auto-copy**] [**force**] [**mdr**]

Syntax Description

switch <i>switch-ID</i>	Specifies the switch for provisioning.
<i>file-URL</i>	URL to the consolidated package or sub-package.
bay <i>bay-number</i>	(Optional) Specifies the shared port adapter (SPA) bay number within a SIP.
slot <i>slot-number</i>	(Optional) Specifies the device slot number where a shared port adapter interface processor (SIP) can be installed.
auto-copy	(Optional) Specifies that the device will automatically copy packages to provisioning directory.
force	(Optional) Specifies that the operation will be forced, meaning that the upgrade will proceed despite any warning messages.
mdr	(Optional) Specifies that minimal disruptive restart is used.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Denali 16.1.1	This command was introduced.

Example

The following example shows how to uninstall a software package:

```
Device# request platform software package uninstall
```

Related Commands

Command	Description
request platform software package install commit	Cancels the rollback timer and commits a software upgrade.
request platform software package install rollback	Rolls back a previous software upgrade.
request platform software package install snapshot	Creates a snapshot directory that will contain all the files extracted from a consolidated package.

reset

To perform a hard reset on the system, use the **reset** command in boot loader mode. A hard reset is similar to power-cycling the device; it clears the processor, registers, and memory.

reset

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Boot loader

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Examples

This example shows how to reset the system:

```
Device: reset
Are you sure you want to reset the system (y/n)? y
System resetting...
```

Related Topics

[set](#), on page 1206

[unset](#), on page 1263

rmdir

To remove one or more empty directories from the specified file system, use the **rmdir** command in boot loader mode.

rmdir *filesystem:/directory-url...*

Syntax Description

filesystem: Alias for a file system. Use **usbflash0:** for USB memory sticks.

/directory-url... Path (directory) and name of the empty directories to remove. Separate each directory name with a space.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Directory names are case sensitive and limited to 45 characters between the slashes (/); the name cannot contain control characters, spaces, deletes, slashes, quotes, semicolons, or colons.

Before removing a directory, you must first delete all of the files in the directory.

The device prompts you for confirmation before deleting each directory.

Example

This example shows how to remove a directory:

```
Device: rmdir usbflash0:Test
```

You can verify that the directory was deleted by entering the **dir filesystem:** boot loader command.

Related Topics

[dir](#), on page 1149

[mkdir](#), on page 1172

sdm prefer

To specify the SDM template for use on the switch, use the **sdm prefer** command in global configuration mode.

```
sdm prefer  
{ advanced }
```

Syntax Description	advanced Supports advanced features such as NetFlow.
---------------------------	---

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines	In a device stack, all stack members must use the same SDM template that is stored on the active device. When a new device is added to a stack, the SDM configuration that is stored on the active device overrides the template configured on an individual device.
-------------------------	---

Example

This example shows how to configure the advanced template:

```
Device(config)# sdm prefer advanced  
Device(config)# exit  
Device# reload
```

Related Topics

[show sdm prefer](#), on page 1226

set

To set or display environment variables, use the **set** command in boot loader mode. Environment variables can be used to control the boot loader or any other software running on the device.

set *variable value*

Syntax Description

<i>variable</i> <i>value</i>	<p>Use one of the following keywords for <i>variable</i> and the appropriate value for <i>value</i>:</p> <p>MANUAL_BOOT—Decides whether the device automatically or manually boots.</p> <p>Valid values are 1/Yes and 0/No. If it is set to 0 or No, the boot loader attempts to automatically boot the system. If it is set to anything else, you must manually boot the device from the boot loader mode.</p> <hr/> <p>BOOT <i>filesystem:/file-url</i>—Identifies a semicolon-separated list of executable files to try to load and execute when automatically booting.</p> <p>If the BOOT environment variable is not set, the system attempts to load and execute the first executable image it can find by using a recursive, depth-first search through the flash: file system. If the BOOT variable is set but the specified images cannot be loaded, the system attempts to boot the first bootable file that it can find in the flash: file system.</p> <hr/> <p>ENABLE_BREAK—Allows the automatic boot process to be interrupted when the user presses the Break key on the console.</p> <p>Valid values are 1, Yes, On, 0, No, and Off. If set to 1, Yes, or On, you can interrupt the automatic boot process by pressing the Break key on the console after the flash: file system has initialized.</p> <hr/> <p>HELPER <i>filesystem:/file-url</i>—Identifies a semicolon-separated list of loadable files to dynamically load during the boot loader initialization. Helper files extend or patch the functionality of the boot loader.</p> <hr/> <p>PS1 <i>prompt</i>—Specifies a string that is used as the command-line prompt in boot loader mode.</p> <hr/> <p>CONFIG_FILE flash: <i>/file-url</i>—Specifies the filename that Cisco IOS uses to read and write a nonvolatile copy of the system configuration.</p> <hr/> <p>BAUD <i>rate</i>—Specifies the number of bits per second (b/s) that is used for the baud rate for the console. The Cisco IOS software inherits the baud rate setting from the boot loader and continues to use this value unless the configuration file specifies another setting. The range is from 0 to 128000 b/s. Valid values are 50, 75, 110, 150, 300, 600, 1200, 1800, 2000, 2400, 3600, 4800, 7200, 9600, 14400, 19200, 28800, 38400, 56000, 57600, 115200, and 128000.</p> <p>The most commonly used values are 300, 1200, 2400, 9600, 19200, 57600, and 115200.</p> <hr/> <p>SWITCH_NUMBER <i>stack-member-number</i>—Changes the member number of a stack member.</p> <hr/> <p>SWITCH_PRIORITY <i>priority-number</i>—Changes the priority value of a stack member.</p>
---------------------------------	--

Command Default

The environment variables have these default values:

MANUAL_BOOT: No (0)

BOOT: Null string

ENABLE_BREAK: No (Off or 0) (the automatic boot process cannot be interrupted by pressing the **Break** key on the console).

HELPER: No default value (helper files are not automatically loaded).

PS1 device:

CONFIG_FILE: config.text

BAUD: 9600 b/s

SWITCH_NUMBER: 1

SWITCH_PRIORITY: 1



Note Environment variables that have values are stored in the flash: file system in various files. Each line in the files contains an environment variable name and an equal sign followed by the value of the variable.

A variable has no value if it is not listed in these files; it has a value if it is listed even if the value is a null string. A variable that is set to a null string (for example, “”) is a variable with a value.

Many environment variables are predefined and have default values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

Environment variables are case sensitive and must be entered as documented.

Environment variables that have values are stored in flash memory outside of the flash: file system.

Under typical circumstances, it is not necessary to alter the setting of the environment variables.

The MANUAL_BOOT environment variable can also be set by using the **boot manual** global configuration command.

The BOOT environment variable can also be set by using the **boot system filesystem: /file-url** global configuration command.

The ENABLE_BREAK environment variable can also be set by using the **boot enable-break** global configuration command.

The HELPER environment variable can also be set by using the **boot helper filesystem: /file-url** global configuration command.

The CONFIG_FILE environment variable can also be set by using the **boot config-file flash: /file-url** global configuration command.

The SWITCH_NUMBER environment variable can also be set by using the **switch current-stack-member-number renumber new-stack-member-number** global configuration command.

The SWITCH_PRIORITY environment variable can also be set by using the device *stack-member-number* **priority** *priority-number* global configuration command.

The boot loader prompt string (PS1) can be up to 120 printable characters not including the equal sign (=).

Example

This example shows how to set the SWITCH_PRIORITY environment variable:

```
Device: set SWITCH_PRIORITY 2
```

You can verify your setting by using the **set** boot loader command.

Related Topics

[reset](#), on page 1203

[unset](#), on page 1263

show avc client

To display information about top number of applications, use the **show avc client** command in privileged EXEC mode.

show avc client *client-mac* **top n application** [**aggregate** | **upstream** | **downstream**]

Syntax Description

client *client-mac* Specifies the client MAC address.

top n application Specifies the number of top "N" applications for the given client.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

The following is sample output from the **show avc client** command:

```
Device# sh avc client 0040.96ae.65ec top 10 application aggregate
```

Cumulative Stats:

No.	AppName	Packet-Count	Byte-Count	AvgPkt-Size	usage%
1	skinny	7343	449860	61	94
2	unknown	99	13631	137	3
3	dhcp	18	8752	486	2
4	http	18	3264	181	1
5	tftp	9	534	59	0
6	dns	2	224	112	0

Last Interval (90 seconds) Stats:

No.	AppName	Packet-Count	Byte-Count	AvgPkt-Size	usage%
1	skinny	9	540	60	100

show avc wlan

To display information about top applications and users using the applications, use the **show avc wlan** command in privileged EXEC mode.

show avc wlan ssid top n application [aggregate | upstream | downstream]

Syntax Description	Parameter	Description
	wlan ssid	Specifies the Service Set Identifier (SSID) for WLAN.
	top n application	Specifies the number of top "N" applications.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

The following is sample output from the **show avc wlan** command:

```
Device# show avc wlan Lobby_WLAN top 10 application aggregate
```

Cumulative Stats:

No.	AppName	Packet-Count	Byte-Count	AvgPkt-Size	usage%
1	ssl	10598677	1979525706	997	42
2	vnc	5550900	3764612847	678	14
3	http	3043131	2691327197	884	10
4	unknown	1856297	1140264956	614	4
5	video-over-http	1625019	2063335150	1269	8
6	binary-over-http	1329115	1744190344	1312	6
7	webex-meeting	1146872	540713787	471	2
8	rtp	923900	635650544	688	2
9	unknown	752341	911000213	1210	3
10	youtube	631085	706636186	1119	3

Last Interval(90 seconds) Stats:

No.	AppName	Packet-Count	Byte-Count	AvgPkt-Size	usage%
1	vnc	687093	602731844	877	68
2	video-over-http	213272	279831588	1312	31
3	ssl	6515	5029365	771	1
4	webex-meeting	3649	1722663	472	0
5	http	2634	1334355	506	0
6	unknown	1436	99412	69	0
7	google-services	722	378121	523	0
8	linkedin	655	393263	600	0
9	exchange	432	167390	387	0
10	gtalk-chat	330	17330	52	0

show cable-diagnostics tdr

To display the Time Domain Reflector (TDR) results, use the **show cable-diagnostics tdr** command in privileged EXEC mode.

```
show cable-diagnostics tdr interface interface-id
```

Syntax Description

interface-id Specifies the interface on which TDR is run.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

TDR is supported only on 10/100/100 copper Ethernet ports. It is not supported on 10-Gigabit Ethernet ports and small form-factor pluggable (SFP) module ports.

Examples

This example shows the output from the **show cable-diagnostics tdr interface interface-id** command on a device:

```
Device# show cable-diagnostics tdr interface gigabitethernet1/0/23
TDR test last run on: March 01 00:04:08
Interface Speed Local pair Pair length Remote pair Pair status
-----
Gi1/0/23 1000M Pair A 1 +/- 1 meters Pair A Normal
          Pair B 1 +/- 1 meters Pair B Normal
          Pair C 1 +/- 1 meters Pair C Normal
          Pair D 1 +/- 1 meters Pair D Normal
```

Table 44: Field Descriptions for the show cable-diagnostics tdr Command Output

Field	Description
Interface	The interface on which TDR is run.
Speed	The speed of connection.
Local pair	The name of the pair of wires that TDR is testing on the local interface.

Field	Description
Pair length	The location of the problem on the cable, with respect to your device. TDR can only find the location in one of these cases: <ul style="list-style-type: none"> • The cable is properly connected, the link is up, and the interface speed is 1000 Mb/s. • The cable is open. • The cable has a short.
Remote pair	The name of the pair of wires to which the local pair is connected. TDR can learn about the remote pair only when the cable is properly connected and the link is up.
Pair status	The status of the pair of wires on which TDR is running: <ul style="list-style-type: none"> • Normal—The pair of wires is properly connected. • Not completed—The test is running and is not completed. • Not supported—The interface does not support TDR. • Open—The pair of wires is open. • Shorted—The pair of wires is shorted. • ImpedanceMis—The impedance is mismatched. • Short/Impedance Mismatched—The impedance mismatched or the cable is short. • InProgress—The diagnostic test is in progress.

This example shows the output from the **show interface** *interface-id* command when TDR is running:

```
Device# show interface gigabitethernet1/0/2
gigabitethernet1/0/2 is up, line protocol is up (connected: TDR in Progress)
```

This example shows the output from the **show cable-diagnostics tdr interface** *interface-id* command when TDR is not running:

```
Device# show cable-diagnostics tdr interface gigabitethernet1/0/2
% TDR test was never issued on gigabitethernet1/0/2
```

If an interface does not support TDR, this message appears:

```
% TDR test is not supported on device 1
```

Related Topics

[test cable-diagnostics tdr](#), on page 1254

show ap hyperlocation

To view a summary or detailed information of Hyperlocation configuration, use the **show ap hyperlocation** command.

show ap hyperlocation {**summary** | **detail**}

Syntax Description

summary Shows the overall configuration values and operational values

detail Shows the overall configuration and operation values as well as detailed information of each AP

Command History

Release	Modification
Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows how to view a summary of Hyperlocation configuration:

```
Device# show ap hyperlocation summary

Hyperlocation operational status: Up
Hyperlocation NTP server currently used: 209.165.200.224
Hyperlocation admin status: Enabled
Hyperlocation detection threshold: -100 dBm
Hyperlocation trigger threshold: 10
Hyperlocation reset threshold: 8
```



Note For Hyperlocation to be operational, the following conditions must be met:

- At least one Cisco CMX with Hyperlocation enabled
- Hyperlocation admin state operational
- Either AP NTP or IOS NTP configured

This example shows how to view detailed information about Hyperlocation configuration:

```
Device# show ap hyperlocation detail

Hyperlocation operational status: Up
Hyperlocation NTP server currently used: 209.165.200.224
Hyperlocation admin status: Enabled
Hyperlocation detection threshold: -100 dBm
Hyperlocation trigger threshold: 10
Hyperlocation reset threshold: 8
```

AP Name	Radio MAC	Method	Hyperlocation
AP84b8.0252.b930	84b8.0216.c721	HALO	Enabled
AP84b8.0265.5540	84b8.0243.8796	WSM	Enabled
APf07f.0635.2d40	f07f.0676.3b89	WSM	Enabled
APF4cf.e272.4ed0	f4cf.e223.ba31	HALO	Enabled

show debug

To display all the debug commands available on a switch, use the **show debug** command in Privileged EXEC mode.

show debug

show debug condition *Condition identifier* | *All conditions*

Syntax Description	<i>Condition identifier</i> Sets the value of the condition identifier to be used. Range is between 1 and 1000.
	<i>All conditions</i> Shows all conditional debugging options available.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Release 16.1	This command was introduced.

Usage Guidelines Because debugging output is assigned high priority in the CPU process, it can render the system unusable. For this reason, use debug commands only to troubleshoot specific problems or during troubleshooting sessions with Cisco technical support staff. Moreover, it is best to use debug commands during periods of lower network traffic and fewer users. Debugging during these periods decreases the likelihood that increased debug command processing overhead will affect system use.

Examples This example shows the output of a **show debug** command:

```
Device# show debug condition all
```

To disable debugging, use the **no debug all** command.

show env

To display fan, temperature, and power information for the switch (standalone switch, stack master, or stack member), use the **show env** command in EXEC modes.

```
show env { all | fan | power [all | switch [switch-number]] | stack [stack-number] |
temperature [status] }
```

Syntax Description		
all		Displays fan, temperature and power environmental status.
fan		Displays the switch fan status.
power		Displays the power supply status.
all		(Optional) Displays the status for all power supplies.
switch <i>switch-number</i>		(Optional) Displays the power supply status for a specific switch.
stack <i>switch-number</i>		(Optional) Displays all environmental status for each switch in the stack or for a specified switch. The range is 1 to 9, depending on the switch member numbers in the stack.
temperature		Displays the switch temperature status.
status		(Optional) Displays the temperature status and threshold values.

Command Default No default behavior or values.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines Use the **show env stack** [*switch-number*] command to display information about any switch in the stack from any member switch.

Use the **show env temperature status** command to display the switch temperature states and threshold levels.

Examples

This example shows how to display information about stack member 1 from the master switch:

```
Device> show env stack 1
Device 1:
Device Fan 1 is OK
Device Fan 2 is OK
Device Fan 3 is OK
FAN-PS1 is OK
```

```
FAN-PS2 is NOT PRESENT
Device 1: SYSTEM TEMPERATURE is OK
Temperature Value: 32 Degree Celsius
Temperature State: GREEN
Yellow Threshold : 41 Degree Celsius
Red Threshold : 56 Degree Celsius
```

```
Device>
```

This example shows how to display temperature value, state, and threshold values:

```
Device> show env temperature status
Temperature Value: 32 Degree Celsius
Temperature State: GREEN
Yellow Threshold : 41 Degree Celsius
Red Threshold : 56 Degree Celsius
```

```
Device>
```

Table 45: States in the show env temperature status Command Output

State	Description
Green	The switch temperature is in the <i>normal</i> operating range.
Yellow	The temperature is in the <i>warning</i> range. You should check the external temperature around the switch.
Red	The temperature is in the <i>critical</i> range. The switch might not run properly if the temperature is in this range.

show flow monitor

To display the status and statistics for a flow monitor, use the **show flow monitor** command in privileged EXEC mode.

Syntax Description	name	(Optional) Specifies the name of a flow monitor.
	<i>monitor-name</i>	(Optional) Name of a flow monitor that was previously configured.
	cache	(Optional) Displays the contents of the cache for the flow monitor.
	format	(Optional) Specifies the use of one of the format options for formatting the display output.
	csv	(Optional) Displays the flow monitor cache contents in comma-separated variables (CSV) format.
	record	(Optional) Displays the flow monitor cache contents in record format.
	table	(Optional) Displays the flow monitor cache contents in table format.
	statistics	(Optional) Displays the statistics for the flow monitor.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The **cache** keyword uses the record format by default.

The uppercase field names in the display output of the **show flowmonitor** *monitor-name* **cache** command are key fields that uses to differentiate flows. The lowercase field names in the display output of the **show flow monitor** *monitor-name* **cache** command are nonkey fields from which collects values as additional data for the cache.

Examples

The following example displays the status for a flow monitor:

```
Device# show flow monitor FLOW-MONITOR-1

Flow Monitor FLOW-MONITOR-1:
  Description:      Used for basic traffic analysis
  Flow Record:     flow-record-1
  Flow Exporter:   flow-exporter-1
                  flow-exporter-2

Cache:
  Type:            normal
  Status:         allocated
  Size:           4096 entries / 311316 bytes
  Inactive Timeout: 15 secs
  Active Timeout: 1800 secs
```

This table describes the significant fields shown in the display.

Table 46: show flow monitor monitor-name Field Descriptions

Field	Description
Flow Monitor	Name of the flow monitor that you configured.
Description	Description that you configured or the monitor, or the default description User defined.
Flow Record	Flow record assigned to the flow monitor.
Flow Exporter	Exporters that are assigned to the flow monitor.
Cache	Information about the cache for the flow monitor.
Type	Flow monitor cache type. The value is always normal, as it is the only supported cache type.
Status	Status of the flow monitor cache. The possible values are: <ul style="list-style-type: none"> • allocated—The cache is allocated. • being deleted—The cache is being deleted. • not allocated—The cache is not allocated.
Size	Current cache size.
Inactive Timeout	Current value for the inactive timeout in seconds.
Active Timeout	Current value for the active timeout in seconds.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1:

This table describes the significant fields shown in the display.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1 in a table format:

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-IPv6 (the cache contains IPv6 data) in record format:

The following example displays the status and statistics for a flow monitor:

show license right-to-use

To display detailed information for apcount adder licenses installed on the device, use the **show license right-to-use** command in EXEC modes.

show license right-to-use {**default** | **detail** | **eula** | **mismatch** | **slot** | **summary** | **usage**}

Syntax Description	default	Displays the default license information.
	detail	Displays details of all the licenses in the stack.
	eula	Displays the EULA text.
	mismatch	Displays mismatch license information.
	slot	Specifies the switch number.
	summary	Displays consolidated stack-wide license information.
	usage	Displays the usage details of all licenses.

Command Default No default behavior or values.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **show license right-to-use usage** command and displays all the detailed information:

Device# **show license right-to-use usage**

```

Slot#  License Name      Type      usage-duration(y:m:d)  In-Use  EULA
-----
1      ipservices           permanent  0 :0 :1                yes     yes
1      ipbase               permanent  0 :0 :0                no      no
1      ipbase               evaluation 0 :0 :0                no      no
1      lanbase              permanent  0 :0 :7                no      yes
1      apcount              evaluation 0 :0 :0                no      no
1      apcount              base       0 :0 :0                no      no
1      apcount              adder     0 :0 :0                no      yes

```

Device#

The following is sample output from the **show license right-to-use detail** command and displays the detailed information of licenses:

```
Device# show license right-to-use detail

Index 1: License Name: apcount
         Period left: 16
         License Type: evaluation
         License State: Not Activated
         License Count: 1000
         License Location: Slot 1
Index 2: License Name: apcount
         Period left: Lifetime
         License Type: adder
         License State: Active, In use
         License Count: 125
         License Location: Slot 1
```

The following is sample output from the **show license right-to-use summary** command when the evaluation license is active:

```
Device# show license right-to-use summary
License Name   Type      Count   Period left
-----
apcount       evaluation 1000    50
-----

Evaluation AP-Count: Enabled
Total AP Count Licenses: 1000
AP Count Licenses In-use: 100
AP Count Licenses Remaining: 900
```

The following is sample output from the **show license right-to-use summary** command when the adder licenses are active:

```
Device# show license right-to-use summary
License Name   Type      Count   Period left
-----
apcount       adder      125     Lifetime
-----

Evaluation AP-Count: Disabled
Total AP Count Licenses: 125
AP Count Licenses In-use: 100
AP Count Licenses Remaining: 25
```

show location

To display location information, use the **show location** command in privileged EXEC mode.

```
show location {detail mac-addr | plm | statistics | summary rfid | rfid {client | config | detail MAC-addr | summary}}
```

Syntax Description	
detail <i>mac-addr</i>	Displays detailed location information with the RSSI table for a particular client.
plm	Displays location path loss measurement (CCX S60) configuration.
statistics	Displays location-based system statistics.
summary	Displays location-based system summary information.
rfid	Displays the RFID tag tracking information.
client	Displays the summary of RFID tags that are clients.
config	Displays the configuration options for RFID tag tracking.
detail <i>MAC-addr</i>	Displays the detailed information for one rfid tag.
summary	Displays summary information for all known rfid tags.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

The following is sample output from the **show location plm** command:

```
Device# show location plm
Location Path Loss Configuration

Calbration client      : Disabled, Radio: Multiband
Normal clients         : Disabled
Burst interval        : 60
```

show location ap-detect

To display the location information detected by specified access point, use the **show location ap-detect** command in privileged EXEC mode.

show location ap-detect {**all** | **client** | **rfid** | **rogue-ap** | **rogue-client**} *ap-name*

Syntax Description		
all	Displays information of the client, RFID, rogue access point, and rogue client.	
client	Displays the client information.	
rfid	Displays RFID information.	
rogue-ap	Displays rogue access point information.	
rogue-client	Displays rogue client information.	
<i>ap-name</i>	Specified access point name.	

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **show location ap-detect client** command:

```
Device# show location ap-detect client AP02
Clients

MAC Address           Status           Slot  Antenna  RSSI
-----
2477.0389.96ac       Associated       1     0        -60
2477.0389.96ac       Associated       1     1        -61
2477.0389.96ac       Associated       0     0        -46
2477.0389.96ac       Associated       0     1        -41

RFID Tags

Rogue AP's

Rogue Clients

MAC Address           State           Slot  Rssi
-----
0040.96b3.bce6       Alert           1     -58
586d.8ff0.891a       Alert           1     -72
```


show mac address-table move update

To display the MAC address-table move update information on the device, use the **show mac address-table move update** command in EXEC mode.

show mac address-table move update

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Example

This example shows the output from the **show mac address-table move update** command:

```
Device# show mac address-table move update

Switch-ID : 010b.4630.1780
Dst mac-address : 0180.c200.0010
Vlans/Macs supported : 1023/8320
Default/Current settings: Rcv Off/On, Xmt Off/On
Max packets per min : Rcv 40, Xmt 60
Rcv packet count : 10
Rcv conforming packet count : 5
Rcv invalid packet count : 0
Rcv packet count this min : 0
Rcv threshold exceed count : 0
Rcv last sequence# this min : 0
Rcv last interface : Po2
Rcv last src-mac-address : 0003.fd6a.8701
Rcv last switch-ID : 0303.fd63.7600
Xmt packet count : 0
Xmt packet count this min : 0
Xmt threshold exceed count : 0
Xmt pak buf unavail cnt : 0
Xmt last interface : None
```

show nmosp

To display the Network Mobility Services Protocol (NMSP) configuration settings, use the **show nmosp** command.

```
show nmosp {attachment | {suppress interfaces} | capability | notification interval | statistics
{connection | summary} | status | subscription detail [ip-addr ] | summary}
```

Syntax Description		
attachment suppress interfaces		Displays attachment suppress interfaces.
capability		Displays NMSP capabilities.
notification interval		Displays the NMSP notification interval.
statistics connection		Displays all connection-specific counters.
statistics summary		Displays the NMSP counters.
status		Displays status of active NMSP connections.
subscription detail ip-addr		The details are only for the NMSP services subscribed to by a specific IP address.
subscription summary		Displays details for all of the NMSP services to which the controller is subscribed. The details are only for the NMSP services subscribed to by a specific IP address.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **show nmosp notification interval** command:

```
Device# show nmosp notification interval
NMSP Notification Intervals
-----

RSSI Interval:
  Client           : 2 sec
  RFID             : 2 sec
  Rogue AP         : 2 sec
  Rogue Client     : 2 sec
Attachment Interval : 30 sec
Location Interval  : 30 sec
```

show sdm prefer

To display information about the templates that can be used to maximize system resources for a particular feature, use the **show sdm prefer** command in privileged EXEC mode. To display the current template, use the command without a keyword.

show sdm prefer [**advanced**]

Syntax Description	advanced (Optional) Displays information on the advanced template.
---------------------------	---

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines	If you did not reload the switch after entering the sdm prefer global configuration command, the show sdm prefer privileged EXEC command displays the template currently in use and not the newly configured template.
-------------------------	--

The numbers displayed for each template represent an approximate maximum number for each feature resource. The actual number might vary, depending on the actual number of other features configured. For example, in the default template if your device had more than 16 routed interfaces (subnet VLANs), the number of possible unicast MAC addresses might be less than 6000.

Example

The following is sample output from the **show sdm prefer** command:

```
Device# show sdm prefer

Showing SDM Template Info

This is the Advanced template.
Number of VLANs:                               4094
Unicast MAC addresses:                          32768
Overflow Unicast MAC addresses:                 512
IGMP and Multicast groups:                      8192
Overflow IGMP and Multicast groups:             512
Directly connected routes:                     32768
Indirect routes:                               7680
Security Access Control Entries:                3072
QoS Access Control Entries:                    3072
Policy Based Routing ACEs:                     1024
Netflow ACEs:                                  1024
Input Microflow policer ACEs:                  256
Output Microflow policer ACEs:                 256
Flow SPAN ACEs:                               256
Tunnels:                                       256
Control Plane Entries:                         512
```

```
Input Netflow flows:           8192
Output Netflow flows:         16384
SGT/DGT entries:               4096
SGT/DGT Overflow entries:     512
```

These numbers are typical for L2 and IPv4 features.
Some features such as IPv6, use up double the entry size;
so only half as many entries can be created.

Device#

Related Topics

[sdm prefer](#), on page 1205

show tech-support wireless

To display Cisco wireless LAN controller variables frequently requested by Cisco Technical Assistance Center (TAC), use the **show tech-support wireless** command in privileged EXEC mode.

show tech-support wireless

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **show tech-support wireless** command:

```
Device# show tech-support wireless
*** show ap capwap timers ***
```

```
Cisco AP CAPWAP timers
```

```
AP Discovery timer      : 10
AP Heart Beat timeout   : 30
Primary Discovery timer : 120
Primed Join timeout     : 0
Fast Heartbeat          : Disabled
Fast Heartbeat timeout  : 1
```

```
*** show ap capwap retransmit ***
```

```
Global control packet retransmit interval : 3
Global control packet retransmit count : 5
```

AP Name	Retransmit Interval	Retransmit Count
TSIM_AP-2	3	5
TSIM_AP-3	3	5

```
*** show ap dot11 24ghz cleanair air-quality summary ***
```

```
AQ = Air Quality
DFS = Dynamic Frequency Selection
```

```
*** show ap dot11 24ghz cleanair air-quality worst ***
```

```
AQ = Air Quality
DFS = Dynamic Frequency Selection
```

AP Name	Channel	Avg AQ	Min AQ	Interferers	DFS
	0	0	0	0	No

```
*** show ap dot11 24ghz cleanair config ***
```

```
Clean Air Solution..... : Disabled
Air Quality Settings:
  Air Quality Reporting..... : Disabled
  Air Quality Reporting Period (min)..... : 15
```

```

Air Quality Alarms..... : Enabled
Air Quality Alarm Threshold..... : 10
Interference Device Settings:
  Interference Device Reporting..... : Enabled
    Bluetooth Link..... : Enabled
    Microwave Oven..... : Enabled
    802.11 FH..... : Enabled
    Bluetooth Discovery..... : Enabled
    TDD Transmitter..... : Enabled
    Jammer..... : Enabled
    Continuous Transmitter..... : Enabled
    DECT-like Phone..... : Enabled
    Video Camera..... : Enabled
    802.15.4..... : Enabled
    WiFi Inverted..... : Enabled
    WiFi Invalid Channel..... : Enabled
    SuperAG..... : Enabled
    Canopy..... : Enabled
    Microsoft Device..... : Enabled
    WiMax Mobile..... : Enabled
    WiMax Fixed..... : Enabled
  Interference Device Types Triggering Alarms:
    Bluetooth Link..... : Disabled
    Microwave Oven..... : Disabled
    802.11 FH..... : Disabled
    Bluetooth Discovery..... : Disabled
    TDD Transmitter..... : Disabled
    Jammer..... : Disabled
    Continuous Transmitter..... : Disabled
    DECT-like Phone..... : Disabled
    Video Camera..... : Disabled
    802.15.4..... : Disabled
    WiFi Inverted..... : Enabled
    WiFi Invalid Channel..... : Enabled
    SuperAG..... : Disabled
    Canopy..... : Disabled
    Microsoft Device..... : Disabled
    WiMax Mobile..... : Disabled
    WiMax Fixed..... : Disabled
  Interference Device Alarms..... : Enabled
Additional Clean Air Settings:
  CleanAir Event-driven RRM State..... : Disabled
  CleanAir Driven RRM Sensitivity..... : LOW
  CleanAir Persistent Devices state..... : Disabled

```

show wireless band-select

To display the status of the band-select configuration, use the **show wireless band-select** command in privileged EXEC mode.

show wireless band-select

Syntax Description	This command has no arguments or keywords.	
Command Default	No default behavior or values.	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **show wireless band-select** command:

```
Device# show wireless band-select
Band Select Probe Response      : per WLAN enabling
Cycle Count                     : 2
Cycle Threshold (millisec)     : 200
Age Out Suppression (sec)      : 20
Age Out Dual Band (sec)        : 60
Client RSSI (dBm)              : 80
```

show wireless client calls

To display the total number of active or rejected calls on the device, use the **show wireless client calls** command in privileged EXEC mode.

show wireless client calls {**active** | **rejected**}

Syntax Description	
active	Displays active calls.
rejected	Displays rejected calls.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **show wireless client calls** command:

```
device# show wireless client calls active
```

```
TSPEC Calls:
```

```
-----
MAC Address      AP Name          Status           WLAN  Authenticated
-----
0000.1515.000f   AP-2             Associated       1    Yes
```

```
SIP Calls:
```

```
-----
Number of Active TSPEC calls on 802.11a and 802.11b/g: 1
Number of Active SIP calls on 802.11a and 802.11b/g: 0
```

show wireless client dot11

To display the total number of active or rejected calls for a specific band (2.4 Ghz or 5 Ghz), use the **show wireless client dot11** command in privileged EXEC mode.

```
show wireless client dot11 {24ghz | 5ghz} calls {active | rejected}
```

Syntax Description		
24ghz	Displays the 802.11b/g network.	
5ghz	Displays the 802.11a network.	
calls	Displays the wireless client calls.	
active	Displays active calls.	
rejected	Displays rejected calls.	

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **show wireless client dot11** command:

```
Device# show wireless client dot11 5ghz calls active

  TSPEC Calls:
  -----

  SIP Calls:
  -----
Number of Active TSPEC calls on 802.11a: 0
Number of Active SIP calls on 802.11a: 0
```

show wireless client location-calibration

To display the list of clients currently used to perform location calibration, use the **show wireless client location-calibration** command in privileged EXEC mode.

show wireless client location-calibration

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

The following is sample output from the **show wireless client location-calibration** command:

```
Device# show wireless client location-calibration
```

show wireless client probing

To display the number of probing clients, use the **show wireless client probing** command in privileged EXEC mode.

show wireless client probing

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **show wireless client probing** command:

```
Device# show wireless client probing
MAC Address
-----
000b.cd15.0001
000b.cd15.0002
000b.cd15.0003
000b.cd15.0004
000b.cd15.0005
000b.cd15.0006
```

show wireless client summary

To display a summary of active clients associated with the controller, use the **show wireless client summary** command in privileged EXEC mode.

show wireless client summary

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The following is sample output from the **show wireless client summary** command:
Use the **show wireless exclusionlist** command to display clients on the exclusion list (blacklisted).

```
Device# show wireless client summary
Number of Local Clients : 1
```

MAC Address	AP Name	WLAN	State	Protocol
0000.1515.000f	AP-2	1	UP	11a

show wireless client timers

To display 802.11 system timers, use the **show wireless client timers** command in privileged EXEC mode.

show wireless client timers

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

The following is sample output from the **show wireless client timers** command:

```
Device# show wireless client timers
Authentication Response Timeout (seconds)      : 10
```

show wireless client voice diagnostics

To display wireless client voice diagnostic parameters, use the **show wireless client voice diagnostics** command in privileged EXEC mode.

show wireless client voice diagnostics { qos-map | roam-history | rssi | status | tspec }

Syntax Description	Option	Description
	qos-map	Displays information about the QoS and DSCP mapping and packet statistics in each of the four queues: VO, VI, BE, BK. The different DSCP values are also displayed.
	roam-history	Displays information about the last 3 roaming histories for each known client. The output contains the timestamp, access point associated with roaming, roaming reason, and if there is a roaming failure, a reason for the roaming failure.
	rssi	Displays the client's RSSI values in the last 5 seconds when voice diagnostics are enabled.
	status	Displays status of voice diagnostics for clients.
	tspec	Displays voice diagnostics that are enabled for TSPEC clients.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines Debug voice diagnostics must be enabled for voice diagnostics to work.

The following is sample output from the **show wireless client voice diagnostics status** command:

```
Device# show wireless client voice diagnostics status
Voice Diagnostics Status: FALSE
```


The following is sample output from the **show wireless country configured** command:

```
Device# show wireless country configured
Configured Country.....: US - United States
Configured Country Codes
    US - United States : 802.11a Indoor,Outdoor/ 802.11b / 802.11g
```

The following is sample output from the **show wireless country supported tx-power** command:

```
Device# show wireless country supported tx-power
KEY: ##      = Tx Power in dBm.
     ##*     = Channel supports radar detection .
     .       = Channel is not legal in this country.
     (-)     = Regulatory Domains allowed by this country.
     (-,-)   = (indoor, outdoor) regulatory Domains allowed by this country.
-----:+++++-----
      802.11bg      :
      Channels      :           1 1 1 1 1
                    : 1 2 3 4 5 6 7 8 9 0 1 2 3 4
-----:+++++-----
(-CE , -CE ) AE  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) AL  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -AR ) AR  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -E  ) AT  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -NA ) AU  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -   ) BA  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) BE  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) BG  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -   ) BH  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -A  ) BO  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-A  , -AR ) BR  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -   ) BY  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -ABN) CA  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-A  , -ABN) CA2 : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -E  ) CH  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-AER , -AR ) CL  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) CM  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-CE  , -CE ) CN  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -AR ) CO  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-A  , -AB ) CR  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -E  ) CY  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) CZ  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) DE  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) DK  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -ABN) DO  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -   ) DZ  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -AB ) EC  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -E  ) EE  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) EG  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) ES  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) FI  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) FR  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) GB  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) GI  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) GR  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -NA ) HK  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -   ) HR  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) HU  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -ER ) ID  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) IE  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-EI  , -IE ) IL  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
```

show wireless country

```

(-I , -I ) ILO : . . . . 20 20 20 20 20 20 20 20 20 20 .
(-A , -AN ) IN : 27 27 27 27 27 27 27 27 27 27 . . .
(-E , -E ) IQ : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) IS : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) IT : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-JPU , -JPU ) J2 : 23 23 23 23 23 23 23 23 23 23 23 23 23
(-JPU , -JPU ) J3 : 23 23 23 23 23 23 23 23 23 23 23 23 23
(-JPQU , -PQ ) J4 : 23 23 23 23 23 23 23 23 23 23 23 23 23
(-E , - ) JO : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-JPU , -JPU ) JP : 23 23 23 23 23 23 23 23 23 23 23 23 23
(-ACE , -ACEK) KE : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) KN : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-ACE , -ACEK) KR : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) KW : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) KZ : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) LB : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) LI : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , ) LK : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) LT : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) LU : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) LV : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) MC : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) ME : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) MK : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , ) MO : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) MT : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A , -NA ) MX : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-ACE , -AEC) MY : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) NL : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) NO : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A , -NA ) NZ : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-E , -E ) OM : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A , -AR ) PA : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , -AR ) PE : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , -ABN ) PH : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , -ABN ) PH2 : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-E , -E ) PK : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) PL : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A , -A ) PR : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-E , -E ) PT : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A , -A ) PY : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-E , -E ) QA : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) RO : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) RS : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-AER , -ER ) RU : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-AE , -AE ) SA : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) SE : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -SE ) SG : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) SI : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) SK : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -ER ) TH : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) TN : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-EI , -E ) TR : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A , -ANT ) TW : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-E , -E ) UA : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A , -AB ) US : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , -AB ) US2 : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , -AB ) USL : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , - ) USX : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , -A ) UY : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , -AR ) VE : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-E , -E ) VN : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) ZA : 20 20 20 20 20 20 20 20 20 20 20 20 .

```

show wireless detail

To display the details of the wireless parameters configured, use the **show wireless detail** command in privileged EXEC mode.

show wireless detail

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines The following parameters are displayed:

- The wireless user idle timeout
- The controller configured RF group name
- Fast SSID change

The following is sample output from the **show wireless detail** command:

```
Device# show wireless detail
User Timeout           : 300
RF network             : default
Fast SSID              : Disabled
```

show wireless dtls connections

To display the Datagram Transport Layer Security (DTLS) server status, use the **show wireless dtls connections** command in privileged EXEC mode.

show wireless dtls connections

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **show wireless dtls connections** command:

```
Device# show wireless dtls connections
AP Name          Local Port    Peer IP      Peer Port    Ciphersuite
-----
AP-2             Capwap_Ctrl  10.0.0.16   52346        TLS_RSA_WITH_AES_128_CBC_SHA
AP-3             Capwap_Ctrl  10.0.0.17   52347        TLS_RSA_WITH_AES_128_CBC_SHA
```

show wireless flow-control

To display the information about flow control on a particular channel, use the **show wireless flow-control** command in privileged EXEC mode.

show wireless flow-control *channel-id*

Syntax Description	<i>channel-id</i> Identification number for a channel through which flow control is monitored.				
Command Default	No default behavior or values.				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				

The following is sample output from the **show wireless flow-control** *channel-id* command:

```
Device# show wireless flow-control 3
Channel Name           : CAPWAP
FC State               : Disabled
Remote Server State    : Enabled
Pass-thru Mode        : Disabled
EnQ Disabled          : Disabled
Queue Depth           : 2048
Max Retries           : 5
Min Retry Gap (mSec)  : 3
```

show wireless flow-control statistics

To display the complete information about flow control on a particular channel, use the **show wireless flow-control statistics** command in privileged EXEC mode.

show wireless flow-control *channel-id* **statistics**

Syntax Description	<i>channel-id</i> Identification number for a channel through which flow control is monitored.
---------------------------	--

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

The following is sample output from the **show wireless flow-control** *channel-id* **statistics** command:

```
Device# show wireless flow-control 3 statistics
Channel Name                : CAPWAP
# of times channel went into FC      : 0
# of times channel came out of FC    : 0
Total msg count received by the FC Infra : 1
Pass-thru msgs send count           : 0
Pass-thru msgs fail count           : 0
# of msgs successfully queued        : 0
# of msgs for which queuing failed   : 0
# of msgs sent thru after queuing     : 0
# of msgs sent w/o queuing           : 1
# of msgs for which send failed      : 0
# of invalid EAGAINS received        : 0
Highest watermark reached           : 0
# of times Q hit max capacity        : 0
Avg time channel stays in FC (mSec)  : 0
```

show wireless load-balancing

To display the status of the load-balancing feature, use the **show wireless load-balancing** command in privileged EXEC mode.

show wireless load-balancing

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **show wireless load-balancing** command:

```
> show wireless load-balancing
Aggressive Load Balancing.....: per WLAN enabling
Aggressive Load Balancing Window (clients).....: 5
Aggressive Load Balancing Denial Count.....: 3

Statistics
Total Denied Count (clients).....: 0
Total Denial Sent (messages).....: 0
Exceeded Denial Max Limit Count (times).....: 0
None 5G Candidate Count (times).....: 0
None 2.4G Candidate Count (times).....: 0
```

show wireless performance

To display aggressive load balancing configuration, use the **show wireless performance** command in privileged EXEC mode.

show wireless performance {ap | client} summary

Syntax Description	ap summary	client summary
	Displays aggressive load balancing configuration of access points configured to the controller.	Displays aggressive load balancing configuration details of the clients.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **show wireless performance ap summary** command.

```
Device# show wireless performance ap summary
Number of APs:
```

The following is sample output from the **show wireless performance client summary** command.

```
Device# show wireless performance client summary
Number of Clients:
```

```
MAC Address          AP Name              Status              WLAN/Guest-Lan Auth Protocol Port Wired
-----
```

show wireless pmk-cache

To display information about the pairwise master key (PMK) cache, use the **show wireless pmk-cache** command in privileged EXEC mode.

```
show wireless pmk-cache[mac-address mac-addr]
```

Syntax Description	mac-address mac-addr (Optional) Information about a single entry in the PMK cache.				
Command Default	No default behavior or values.				
Command Modes	Privileged EXEC				
Command History	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE 3.3SE</td><td>Cisco IOS XE 3.3SE This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

The following is sample output from the **show wireless pmk-cache mac-address** command:

```
Device# show wireless pmk-cache mac-address H.H.H  
Number of PMK caches in total : 0
```

show wireless probe

To display the advanced probe request filtering configuration and the number of probes sent to the WLAN controller per access point per client and the probe interval in milliseconds, use the **show wireless probe** command in privileged EXEC mode.

show wireless probe

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

The following is sample output from the **show wireless probe** command:

```
Device# show wireless probe
Probe request filtering           : Enabled
Number of probes per client per radio fwd from AP: 2
Probe request rate-limiting interval : 500 msec
Aggregate probe request interval   : 500 msec
```

show wireless sip preferred-call-no

To display SIP preferred call numbers, use the **show wireless sip preferred-call-no** command in privileged EXEC mode.

show wireless sip preferred-call-no

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

The following is sample output from the **show wireless sip preferred-call-no** command:

```
Device# show wireless sip preferred-call-no
Index Preferred-Number
-----
1      1031
2      1032
4      1034
```

show wireless summary

To display the number of access points, radios and wireless clients known to the controller, use the **show wireless summary** command in privileged EXEC mode.

show wireless summary

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

The following is sample output from the **show wireless summary** command:

```
Device# show wireless summary
```

```
Access Point Summary
```

	Total	Up	Down
802.11a/n	2	2	0
802.11b/g/n	2	2	0
All APs	2	2	0

```
Client Summary
```

```
Current Clients : 1
Excluded Clients: 0
Disabled Clients: 0
```

shutdown

To shut down VLAN switching, use the **shutdown** command in global configuration mode. To disable the configuration set, use the **no** form of this command.

```
shutdown [ vlan vlan-id ]
no shutdown
```

Syntax Description	vlan <i>vlan-id</i>	VLAN ID of VLAN to shutdown.
Command Default	No default behavior or values.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Examples

This example shows how to shutdown a VLAN:

```
Device(config)# vlan open1
Device(config-wlan)# shutdown
```

This example shows that the access point is not shut down:

```
Device# configure terminal
Device(config)# ap name 3602a no shutdown
```

system env temperature threshold yellow

To configure the difference between the yellow and red temperature thresholds that determines the value of yellow threshold, use the **system env temperature threshold yellow** command in global configuration mode. To return to the default value, use the **no** form of this command.

system env temperature threshold yellow *value*
no system env temperature threshold yellow *value*

Syntax Description

value Specifies the difference between the yellow and red threshold values (in Celsius). The range is 10 to 25.

Command Default

These are the default values

Table 47: Default Values for the Temperature Thresholds

Device	Difference between Yellow and Red	Red ¹³
Catalyst 3650	14°C	60°C

¹³ You cannot configure the red temperature threshold.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

You cannot configure the green and red thresholds but can configure the yellow threshold. Use the **system env temperature threshold yellow** *value* global configuration command to specify the difference between the yellow and red thresholds and to configure the yellow threshold. For example, if the red threshold is 66 degrees C and you want to configure the yellow threshold as 51 degrees C, set the difference between the thresholds as 15 by using the **system env temperature threshold yellow 15** command. For example, if the red threshold is 60 degrees C and you want to configure the yellow threshold as 51 degrees C, set the difference between the thresholds as 9 by using the **system env temperature threshold yellow 9** command.



Note

The internal temperature sensor in the device measures the internal system temperature and might vary ± 5 degrees C.

Examples

This example sets 15 as the difference between the yellow and red thresholds:

```
Device(config)# system env temperature threshold yellow 15
Device(config)#
```


test cable-diagnostics tdr

To run the Time Domain Reflector (TDR) feature on an interface, use the **test cable-diagnostics tdr** command in privileged EXEC mode.

```
test cable-diagnostics tdr interface interface-id
```

Syntax Description	<i>interface-id</i> The interface on which to run TDR.
---------------------------	--

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines TDR is supported only on 10/100/100 copper Ethernet ports. It is not supported on 10-Gigabit Ethernet ports or small form-factor pluggable (SFP) module ports.

After you run TDR by using the **test cable-diagnostics tdr interface** *interface-id* command, use the **show cable-diagnostics tdr interface** *interface-id* privileged EXEC command to display the results.

This example shows how to run TDR on an interface:

```
Device# test cable-diagnostics tdr interface gigabitethernet1/0/2
TDR test started on interface Gi1/0/2
A TDR test can take a few seconds to run on an interface
Use 'show cable-diagnostics tdr' to read the TDR results
```

If you enter the **test cable-diagnostics tdr interface** *interface-id* command on an interface that has an link up status and a speed of 10 or 100 Mb/s, these messages appear:

```
Device# test cable-diagnostics tdr interface gigabitethernet1/0/3
TDR test on Gi1/0/9 will affect link state and traffic
TDR test started on interface Gi1/0/3
A TDR test can take a few seconds to run on an interface
Use 'show cable-diagnostics tdr' to read the TDR results.
```

Related Topics

[show cable-diagnostics tdr](#), on page 1211

traceroute mac

To display the Layer 2 path taken by the packets from the specified source MAC address to the specified destination MAC address, use the **traceroute mac** command in privileged EXEC mode.

```
traceroute mac [interface interface-id] source-mac-address [interface interface-id]
destination-mac-address [vlan vlan-id] [detail]
```

Syntax Description

interface <i>interface-id</i>	(Optional) Specifies an interface on the source or destination device.
<i>source-mac-address</i>	The MAC address of the source device in hexadecimal format.
<i>destination-mac-address</i>	The MAC address of the destination device in hexadecimal format.
vlan <i>vlan-id</i>	(Optional) Specifies the VLAN on which to trace the Layer 2 path that the packets take from the source device to the destination device. Valid VLAN IDs are 1 to 4094.
detail	(Optional) Specifies that detailed information appears.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

For Layer 2 traceroute to function properly, Cisco Discovery Protocol (CDP) must be enabled on all of the devices in the network. Do not disable CDP.

When the device detects a device in the Layer 2 path that does not support Layer 2 traceroute, the device continues to send Layer 2 trace queries and lets them time out.

The maximum number of hops identified in the path is ten.

Layer 2 traceroute supports only unicast traffic. If you specify a multicast source or destination MAC address, the physical path is not identified, and an error message appears.

The **traceroute mac** command output shows the Layer 2 path when the specified source and destination addresses belong to the same VLAN.

If you specify source and destination addresses that belong to different VLANs, the Layer 2 path is not identified, and an error message appears.

If the source or destination MAC address belongs to multiple VLANs, you must specify the VLAN to which both the source and destination MAC addresses belong.

If the VLAN is not specified, the path is not identified, and an error message appears.

The Layer 2 traceroute feature is not supported when multiple devices are attached to one port through hubs (for example, multiple CDP neighbors are detected on a port).

When more than one CDP neighbor is detected on a port, the Layer 2 path is not identified, and an error message appears.

This feature is not supported in Token Ring VLANs.

Examples

This example shows how to display the Layer 2 path by specifying the source and destination MAC addresses:

```
Device# tracert mac 0000.0201.0601 0000.0201.0201
Source 0000.0201.0601 found on con6[WS-C3750E-24PD] (2.2.6.6)
con6 (2.2.6.6) :Gi0/0/1 => Gi0/0/3
con5          (2.2.5.5       ) :   Gi0/0/3 => Gi0/0/1
con1          (2.2.1.1       ) :   Gi0/0/1 => Gi0/0/2
con2          (2.2.2.2       ) :   Gi0/0/2 => Gi0/0/1
Destination 0000.0201.0201 found on con2[WS-C3550-24] (2.2.2.2)
Layer 2 trace completed
```

This example shows how to display the Layer 2 path by using the **detail** keyword:

```
Device# tracert mac 0000.0201.0601 0000.0201.0201 detail
Source 0000.0201.0601 found on con6[WS-C3750E-24PD] (2.2.6.6)
con6 / WS-C3750E-24PD / 2.2.6.6 :
      Gi0/0/2 [auto, auto] => Gi0/0/3 [auto, auto]
con5 / WS-C2950G-24-EI / 2.2.5.5 :
      Fa0/3 [auto, auto] => Gi0/1 [auto, auto]
con1 / WS-C3550-12G / 2.2.1.1 :
      Gi0/1 [auto, auto] => Gi0/2 [auto, auto]
con2 / WS-C3550-24 / 2.2.2.2 :
      Gi0/2 [auto, auto] => Fa0/1 [auto, auto]
Destination 0000.0201.0201 found on con2[WS-C3550-24] (2.2.2.2)
Layer 2 trace completed.
```

This example shows how to display the Layer 2 path by specifying the interfaces on the source and destination devices:

```
Device# tracert mac interface fastethernet0/1 0000.0201.0601 interface fastethernet0/3
0000.0201.0201
Source 0000.0201.0601 found on con6[WS-C3750E-24PD] (2.2.6.6)
con6 (2.2.6.6) :Gi0/0/1 => Gi0/0/3
con5          (2.2.5.5       ) :   Gi0/0/3 => Gi0/0/1
con1          (2.2.1.1       ) :   Gi0/0/1 => Gi0/0/2
con2          (2.2.2.2       ) :   Gi0/0/2 => Gi0/0/1
Destination 0000.0201.0201 found on con2[WS-C3550-24] (2.2.2.2)
Layer 2 trace completed
```

This example shows the Layer 2 path when the device is not connected to the source device:

```
Device# tracert mac 0000.0201.0501 0000.0201.0201 detail
Source not directly connected, tracing source ....
Source 0000.0201.0501 found on con5[WS-C3750E-24TD] (2.2.5.5)
con5 / WS-C3750E-24TD / 2.2.5.5 :
      Gi0/0/1 [auto, auto] => Gi0/0/3 [auto, auto]
```

```
con1 / WS-C3550-12G / 2.2.1.1 :
    Gi0/1 [auto, auto] => Gi0/2 [auto, auto]
con2 / WS-C3550-24 / 2.2.2.2 :
    Gi0/2 [auto, auto] => Fa0/1 [auto, auto]
Destination 0000.0201.0201 found on con2[WS-C3550-24] (2.2.2.2)
Layer 2 trace completed.
```

This example shows the Layer 2 path when the device cannot find the destination port for the source MAC address:

```
Device# traceroute mac 0000.0011.1111 0000.0201.0201
Error:Source Mac address not found.
Layer2 trace aborted.
```

This example shows the Layer 2 path when the source and destination devices are in different VLANs:

```
Device# traceroute mac 0000.0201.0601 0000.0301.0201
Error:Source and destination macs are on different vlans.
Layer2 trace aborted.
```

This example shows the Layer 2 path when the destination MAC address is a multicast address:

```
Device# traceroute mac 0000.0201.0601 0100.0201.0201
Invalid destination mac address
```

This example shows the Layer 2 path when source and destination devices belong to multiple VLANs:

```
Device# traceroute mac 0000.0201.0601 0000.0201.0201
Error:Mac found on multiple vlans.
Layer2 trace aborted.
```

Related Topics

[traceroute mac ip](#), on page 1258

tracroute mac ip

To display the Layer 2 path taken by the packets from the specified source IP address or hostname to the specified destination IP address or hostname, use the **tracroute mac ip** command in privileged EXEC mode.

tracroute mac ip {*source-ip-address source-hostname*} {*destination-ip-address destination-hostname*} [**detail**]

Syntax Description

<i>source-ip-address</i>	The IP address of the source device as a 32-bit quantity in dotted-decimal format.
<i>source-hostname</i>	The IP hostname of the source device.
<i>destination-ip-address</i>	The IP address of the destination device as a 32-bit quantity in dotted-decimal format.
<i>destination-hostname</i>	The IP hostname of the destination device.
detail	(Optional) Specifies that detailed information appears.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

For Layer 2 traceroute to function properly, Cisco Discovery Protocol (CDP) must be enabled on each device in the network. Do not disable CDP.

When the device detects a device in the Layer 2 path that does not support Layer 2 traceroute, the device continues to send Layer 2 trace queries and lets them time out.

The maximum number of hops identified in the path is ten.

The **tracroute mac ip** command output shows the Layer 2 path when the specified source and destination IP addresses are in the same subnet.

When you specify the IP addresses, the device uses Address Resolution Protocol (ARP) to associate the IP addresses with the corresponding MAC addresses and the VLAN IDs.

- If an ARP entry exists for the specified IP address, the device uses the associated MAC address and identifies the physical path.
- If an ARP entry does not exist, the device sends an ARP query and tries to resolve the IP address. The IP addresses must be in the same subnet. If the IP address is not resolved, the path is not identified, and an error message appears.

The Layer 2 traceroute feature is not supported when multiple devices are attached to one port through hubs (for example, multiple CDP neighbors are detected on a port).

When more than one CDP neighbor is detected on a port, the Layer 2 path is not identified, and an error message appears.

This feature is not supported in Token Ring VLANs.

Examples

This example shows how to display the Layer 2 path by specifying the source and destination IP addresses and by using the **detail** keyword:

```
Device# traceroute mac ip 2.2.66.66 2.2.22.22 detail
Translating IP to mac .....
2.2.66.66 => 0000.0201.0601
2.2.22.22 => 0000.0201.0201

Source 0000.0201.0601 found on con6[WS-C2950G-24-EI] (2.2.6.6)
con6 / WS-C3750E-24TD / 2.2.6.6 :
    Gi0/0/1 [auto, auto] => Gi0/0/3 [auto, auto]
con5 / WS-C2950G-24-EI / 2.2.5.5 :
    Fa0/3 [auto, auto] => Gi0/1 [auto, auto]
con1 / WS-C3550-12G / 2.2.1.1 :
    Gi0/1 [auto, auto] => Gi0/2 [auto, auto]
con2 / WS-C3550-24 / 2.2.2.2 :
    Gi0/2 [auto, auto] => Fa0/1 [auto, auto]
Destination 0000.0201.0201 found on con2[WS-C3550-24] (2.2.2.2)
Layer 2 trace completed.
```

This example shows how to display the Layer 2 path by specifying the source and destination hostnames:

```
Device# traceroute mac ip con6 con2
Translating IP to mac .....
2.2.66.66 => 0000.0201.0601
2.2.22.22 => 0000.0201.0201

Source 0000.0201.0601 found on con6
con6 (2.2.6.6) :Gi0/0/1 => Gi0/0/3
con5          (2.2.5.5      ) :   Gi0/0/3 => Gi0/1
con1          (2.2.1.1      ) :   Gi0/0/1 => Gi0/2
con2          (2.2.2.2      ) :   Gi0/0/2 => Fa0/1
Destination 0000.0201.0201 found on con2
Layer 2 trace completed
```

This example shows the Layer 2 path when ARP cannot associate the source IP address with the corresponding MAC address:

```
Device# traceroute mac ip 2.2.66.66 2.2.77.77
Arp failed for destination 2.2.77.77.
Layer2 trace aborted.
```

Related Topics

[traceroute mac](#), on page 1255

trapflags

To enable sending rogue access point detection traps, use the **trapflags** command in privileged EXEC mode. To disable sending rogue access point detection traps, use the **no** form of this command.

trapflags rogueap
no trapflags rogueap

Syntax Description	rogueap Enables sending rogue access point detection traps.				
Command Default	Enabled.				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to disable the sending of rogue access point detection traps:

```
Device# configure terminal
Device(config)# no trapflags rogueap
Device(config)# end
```

trapflags client

To enable the sending of client-related DOT11 traps, use the **trapflags client** command in privileged EXEC mode. To disable the sending of client-related DOT11 traps, use the **no** form of this command.

```
trapflags client [{dot11 {assocfail | associate | authfail | deauthenticate | disassociate} | excluded}]
no trapflags client [{dot11 {assocfail | associate | authfail | deauthenticate | disassociate} | excluded}]
```

Syntax Description	dot11	Client-related DOT11 traps.
	assocfail	Enables the sending of Dot11 association fail traps to clients.
	associate	Enables the sending of Dot11 association traps to clients.
	authfail	Enables the sending of Dot11 authentication fail traps to clients.
	deauthenticate	Enables the sending of Dot11 deauthentication traps to clients.
	disassociate	Enables the sending of Dot11 disassociation traps to clients.
	excluded	Enables the sending of excluded trap to clients.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to enable the sending of Dot11 disassociation trap to clients:

```
Device# configure terminal
Device(config)# trapflags client dot11 disassociate
Device(config)# end
```

type

To display the contents of one or more files, use the **type** command in boot loader mode.

type *filesystem:/file-url...*

Syntax Description	<p><i>filesystem:</i> Alias for a file system. Use flash: for the system board flash device; use usbflash0: for USB memory sticks.</p> <p><i>/file-url...</i> Path (directory) and name of the files to display. Separate each filename with a space.</p>				
Command Default	No default behavior or values.				
Command Modes	Boot loader				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.				
Usage Guidelines	<p>Filenames and directory names are case sensitive.</p> <p>If you specify a list of files, the contents of each file appear sequentially.</p>				

Examples

This example shows how to display the contents of a file:

```
Device: type flash:image_file_name
version_suffix: universal-122-xx.SEx
version_directory: image_file_name
image_system_type_id: 0x00000002
image_name: image_file_name.bin
ios_image_file_size: 8919552
total_image_file_size: 11592192
image_feature: IP|LAYER_3|PLUS|MIN_DRAM_MEG=128
image_family: family
stacking_number: 1.34
board_ids: 0x00000068 0x00000069 0x0000006a 0x0000006b
info_end:
```

unset

To reset one or more environment variables, use the **unset** command in boot loader mode.

unset *variable*...

Syntax Description

variable

Use one of these keywords for *variable*:

MANUAL_BOOT—Specifies whether the device automatically or manually boots.

BOOT—Resets the list of executable files to try to load and execute when automatically booting. If the BOOT environment variable is not set, the system attempts to load and execute the first executable image it can find by using a recursive, depth-first search through the flash: file system. If the BOOT variable is set but the specified images cannot be loaded, the system attempts to boot the first bootable file that it can find in the flash: file system.

ENABLE_BREAK—Specifies whether the automatic boot process can be interrupted by using the **Break** key on the console after the flash: file system has been initialized.

HELPER—Identifies the semicolon-separated list of loadable files to dynamically load during the boot loader initialization. Helper files extend or patch the functionality of the boot loader.

PS1—Specifies the string that is used as the command-line prompt in boot loader mode.

CONFIG_FILE—Resets the filename that Cisco IOS uses to read and write a nonvolatile copy of the system configuration.

BAUD—Resets the rate in bits per second (b/s) used for the console. The Cisco IOS software inherits the baud rate setting from the boot loader and continues to use this value unless the configuration file specifies another setting.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release

Modification

Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

Under typical circumstances, it is not necessary to alter the setting of the environment variables.

The **MANUAL_BOOT** environment variable can also be reset by using the **no boot manual** global configuration command.

The **BOOT** environment variable can also be reset by using the **no boot system** global configuration command.

The **ENABLE_BREAK** environment variable can also be reset by using the **no boot enable-break** global configuration command.

The **HELPER** environment variable can also be reset by using the **no boot helper** global configuration command.

The CONFIG_FILE environment variable can also be reset by using the **no boot config-file** global configuration command.

Example

This example shows how to unset the SWITCH_PRIORITY environment variable:

```
Device: unset SWITCH_PRIORITY
```

Related Topics

[set](#), on page 1206

[reset](#), on page 1203

version

To display the boot loader version, use the **version** command in boot loader mode.

version

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Boot loader

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Examples

This example shows how to display the boot loader version on a device:

```
Device: version  
CAT3K_CAA Boot Loader (CAT3K_CAA-HBOOT-M) Version 1.2, RELEASE SOFTWARE (P)  
Compiled Sun Jul 14 20:22:00 PDT 2013 by rel
```

wireless client

To configure client parameters, use the **wireless client** command in global configuration mode.

```
wireless client {association limit assoc-number interval interval | band-select {client-rssi rssi |
cycle-count count | cycle-threshold threshold | expire dual-band timeout | expire suppression timeout}
| max-user-login max-user-login | timers auth-timeout seconds | user-timeout user-timeout}
```

Syntax Description

association limit <i>assoc-number</i> interval <i>interval</i>	Enables association request limit per access point slot at a given interval and configures the association request limit interval. You can configure number of association request per access point slot at a given interval from one through 100. You can configure client association request limit interval from 100 through 10000 milliseconds.
band-select	Configures band select options for the client.
client-rssi <i>rssi</i>	Sets the client received signal strength indicator (RSSI) threshold for band select. Minimum dBm of a client RSSI to respond to probe between -90 and -20.
cycle-count <i>count</i>	Sets the band select probe cycle count. You can configure the cycle count from one through 10.
cycle-threshold <i>threshold</i>	Sets the time threshold for a new scanning cycle. You can configure the cycle threshold from one through 1000 milliseconds.
expire dual-band <i>timeout</i>	Sets the timeout before stopping to try to push a given client to the 5-GHz band. You can configure the timeout from 10 through 300 seconds, and the default value is 60 seconds.
expire suppression <i>timeout</i>	Sets the expiration time for pruning previously known dual-band clients. You can configure the suppression from 10 through 200 seconds, and the default timeout value is 20 seconds.
max-user-login <i>max-user-login</i>	Configures the maximum number of login sessions for a user.
timers auth-timeout <i>seconds</i>	Configures client timers.
user-timeout <i>user-timeout</i>	Configures the idle client timeout.

Command Default No default behavior or values.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to set the probe cycle count for band select to 8:

```
Device# configure terminal  
Device(config)# wireless client band-select cycle-count 8  
Device(config)# end
```

This example shows how to set the time threshold for a new scanning cycle with threshold value of 700 milliseconds:

```
Device# configure terminal  
Device(config)# wireless client band-select cycle-threshold 700  
Device(config)# end
```

This example shows how to suppress dual-band clients from the dual-band database after 70 seconds:

```
Device# configure terminal  
Device(config)# wireless client band-select expire suppression 70  
Device(config)# end
```

wireless client mac-address deauthenticate

To disconnect a wireless client, use the **wireless client mac-address deauthenticate** command in global configuration mode.

wirelessclientmac-address *mac-addr***deauthenticate**

Syntax Description	mac-address <i>mac-addr</i> Wireless client MAC address.	
Command Default	No default behavior or values.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to disconnect a wireless client:

```
Device# configure terminal
Device(config)# wireless client mac-address 00:1f:ca:cf:b6:60 deauthenticate
Device(config)# end
```

wireless client mac-address

To configure the wireless client settings, use the **wireless client mac-address** command in global configuration mode.

```
wireless client mac-address mac-addr ccx {clear-reports | clear-results | default-gw-ping | dhcp-test
| dns-ping | dns-resolve hostname host-name | get-client-capability | get-manufacturer-info |
get-operating-parameters | get-profiles | log-request {roam | rsna | syslog} | send-message message-id
| stats-request measurement-duration {dot11 | security} | test-abort | test-association ssid bssid dot11
channel | test-dot1x [profile-id] bssid dot11 channel | test-profile {anyprofile-id}
```

Syntax Description

<i>mac-addr</i>	MAC address of the client.
ccx	Cisco client extension (CCX).
clear-reports	Clears the client reporting information.
clear-results	Clears the test results on the controller.
default-gw-ping	Sends a request to the client to perform the default gateway ping test.
dhcp-test	Sends a request to the client to perform the DHCP test.
dns-ping	Sends a request to the client to perform the Domain Name System (DNS) server IP address ping test.
dns-resolve hostname <i>host-name</i>	Sends a request to the client to perform the Domain Name System (DNS) resolution test to the specified hostname.
get-client-capability	Sends a request to the client to send its capability information.
get-manufacturer-info	Sends a request to the client to send the manufacturer's information.
get-operating-parameters	Sends a request to the client to send its current operating parameters.
get-profiles	Sends a request to the client to send its profiles.
log-request	Configures a CCX log request for a specified client device.
roam	(Optional) Specifies the request to specify the client CCX roaming log.
rsna	(Optional) Specifies the request to specify the client CCX RSNA log.
syslog	(Optional) Specifies the request to specify the client CCX system log.

wireless client mac-address

send-message *message-id*

Sends a message to the client.

Message type that involves one of the following:

- 1—The SSID is invalid
 - 2—The network settings are invalid.
 - 3—There is a WLAN credibility mismatch.
 - 4—The user credentials are incorrect.
 - 5—Please call support.
 - 6—The problem is resolved.
 - 7—The problem has not been resolved.
 - 8—Please try again later.
 - 9—Please correct the indicated problem.
 - 10—Troubleshooting is refused by the network.
 - 11—Retrieving client reports.
 - 12—Retrieving client logs.
 - 13—Retrieval complete.
 - 14—Beginning association test.
 - 15—Beginning DHCP test.
 - 16—Beginning network connectivity test.
 - 17—Beginning DNS ping test.
 - 18—Beginning name resolution test.
 - 19—Beginning 802.1X authentication test.
 - 20—Redirecting client to a specific profile.
 - 21—Test complete.
 - 22—Test passed.
 - 23—Test failed.
 - 24—Cancel diagnostic channel operation or select a WLAN profile to resume normal operation.
 - 25—Log retrieval refused by the client.
 - 26—Client report retrieval refused by the client.
 - 27—Test request refused by the client.
 - 28—Invalid network (IP) setting.
 - 29—There is a known outage or problem with the network.
-

- 30—Scheduled maintenance period.
- 31—The WLAN security method is not correct.
- 32—The WLAN encryption method is not correct.
- 33—The WLAN authentication method is not correct.

stats-request <i>measurement-duration</i>	Sends a request for statistics.
dot11	(Optional) Specifies dot11 counters.
security	(Optional) Specifies security counters.
test-abort	Sends a request to the client to abort the current test.
test-association <i>ssid bssid</i> <i>dot11 channel</i>	Sends a request to the client to perform the association test.
test-dot1x	Sends a request to the client to perform the 802.1x test.
<i>profile-id</i>	(Optional) Test profile name.
<i>bssid</i>	Basic SSID.
<i>dot11</i>	Specifies the 802.11a, 802.11b, or 802.11g network.
<i>channel</i>	Channel number.
test-profile	Sends a request to the client to perform the profile redirect test.
any	Sends a request to the client to perform the profile redirect test.
<i>profile-id</i>	Test profile name.
	Note The profile ID should be from one of the client profiles for which client reporting is enabled.

Command Default No default behavior or values.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines The **default-gw-ping** test does not require the client to use the diagnostic channel.

This example shows how to clear the reporting information of the client MAC address 00:1f:ca:cf:b6:60:

```
Device# configure terminal
```

```
Device(config)# wireless client mac-address 00:1f:ca:cf:b6:60 ccx clear-reports  
Device(config)# end
```

wireless load-balancing

To globally configure aggressive load balancing on the controller, use the **wireless load-balancing** command in global configuration mode.

wireless load-balancing {**denial** *denial-count* | **window** *client-count*}

Syntax Description

denial <i>denial-count</i>	Specifies the number of association denials during load balancing. Maximum number of association denials during load balancing is from 1 to 10 and the default value is 3.
window <i>client-count</i>	Specifies the aggressive load balancing client window, with the number of clients needed to trigger aggressive load balancing on a given access point. Aggressive load balancing client window with the number of clients is from 0 to 20 and the default value is 5.

Command Default

Disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

Load-balancing-enabled WLANs do not support time-sensitive applications like voice and video because of roaming delays.

When you use Cisco 7921 and 7920 Wireless IP Phones with controllers, make sure that aggressive load balancing is disabled on the voice WLANs for each controller. Otherwise, the initial roam attempt by the phone might fail, causing a disruption in the audio path.

This example shows how to configure association denials during load balancing:

```
Device# configure terminal
Device(config)# wireless load-balancing denial 5
Device(config)# end
```

wireless sip preferred-call-no

To add a new preferred call or configure voice prioritization, use the **wireless sip preferred-call-no** command in global configuration mode. To remove a preferred call, use the **no** form of this command.

```
wireless sip preferred-call-no callIndex call-no
no wireless sip preferred-call-no callIndex
```

Syntax Description

callIndex Call index with valid values between 1 and 6.

call-no Preferred call number that can contain up to 27 characters.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

Before you configure voice prioritization, you must complete the following prerequisites:

- Set WLAN QoS to allow voice calls to pass through.
- Enable ACM for the radio.
- Enable SIP call snooping on the WLAN.

This example shows how to add a new preferred call or configure voice prioritization:

```
Device# configure terminal
Device(config)# wireless sip preferred-call-no 2 0123456789
Device(config)# end
```

writertc

To update the value of the Real Time Clock (RTC) setting, use the **writertc** command in boot loader mode.

```
writertc { year(0-99) | month(1-12) | date(1-31) | hour (0-23) | min(0-59) | sec(0-59) | dayofweek(1-7) }
```

Syntax Description	
<i>year(0-99)</i>	0 to 99. Century value is not used.
<i>month(1-12)</i>	1 to 12. 1 is January.
<i>date(1-31)</i>	1 to 31.
<i>hour(0-23)</i>	0 to 23.
<i>min(0-59)</i>	0 to 59.
<i>sec(0-59)</i>	0 to 59.
<i>dayofweek(1-7)</i>	1 to 7. 1 is Monday.

Command Default No default behavior or values.

Command Modes Boot loader

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Examples

This example shows how to set the current RTC setting as Wednesday 27th August 2013 at 11:45:10:

```
Device: writertc 13 8 27 11 45 10 3
Device:
Device: readrtc
Wednesday 08-27-13
11:45:11
```

Related Topics

[readrtc](#), on page 1177



Tracing Commands

- [Information About Tracing, on page 1278](#)
- [set platform software trace, on page 1280](#)
- [show platform software trace filter-binary, on page 1284](#)
- [show platform software trace message, on page 1285](#)
- [show platform software trace level, on page 1289](#)
- [request platform software trace archive, on page 1292](#)
- [request platform software trace rotate all, on page 1293](#)
- [request platform software trace filter-binary, on page 1294](#)
- [set platform software trace wireless switch active R0 hyperlocation, on page 1295](#)

Information About Tracing

Tracing Overview

The tracing functionality logs internal events. Trace files are automatically created and saved to the `tracelogs` subdirectory under `crashinfo`.

The contents of trace files are useful for the following purposes:

- **Troubleshooting**—If a switch has an issue, the trace file output may provide information that can be used for locating and solving the issue.
- **Debugging**—The trace file outputs helps users get a more detailed view of system actions and operations.

To view the most recent trace information for a specific module, use the **show platform software trace message** command.

To modify the trace level to increase or decrease the amount of trace message output, you can set a new trace level using the **set platform software trace** command. Trace levels can be set for each process using the **all-modules** keyword in the **set platform software trace** command, or per module within a process.

Location of Tracelogs

Each process uses `btrace` infrastructure to log its trace messages. When a process is active, the corresponding in-memory tracelog is found in the directory `/tmp/<FRU>/trace/`, where `<FRU>` refers to the location where the process is running (`rp`, `fp`, or `cc`).

When a tracelog file has reached the maximum file size limit allowed for the process, or if the process ends, it gets rotated into the following directory:

- `/crashinfo/tracelogs`, if the `crashinfo`: partition is available on the switch
- `/harddisk/tracelogs`, if the `crashinfo`: partition is not available on the switch

The tracelog files are compressed before being stored in the directory.

Tracelog Naming Convention

All the tracelogs that are created using `btrace` have the following naming convention:

```
<process_name>_<FRU><SLOT>-<BAY>.<pid>_<counter>.<creation_timestamp>.bin
```

Here, `counter` is a free-running 64-bit counter that gets incremented for each new file created for the process. For example, `wcm_R0-0.1362_0.20151006171744.bin`. When compressed, the files will have the `gz` extension appended to their names

Tracelog size limits and rotation policy

The maximum size limit for a tracelog file is 1MB for each process, and the maximum number of tracelog files that are maintained for a process is 25.

Rotation and Throttling Policy

Initially, all the tracelog files are moved from the initial `/tmp/<FRU>/trace` directory to the `/tmp/<FRU>/trace/stage` staging directory. The `btrace_rotate` script then moves these tracelogs from the staging directory to the `/crashinfo/tracelogs` directory. When the number of files stored in the `/crashinfo/tracelogs` directory per process reaches the maximum limit, the oldest files for the process are deleted, while the newer files are maintained. This is repeated at every 60 minutes under worst-case situations.

There are two other sets of files that are purged from the `/crashinfo/tracelogs` directory:

- Files that do not have the standard naming convention (other than a few exceptions such as `fed_python.log`)
- Files older than two weeks

The throttling policy has been introduced so that a process with errors does not affect the functioning of the switch. Whenever a process starts logging at a very high rate, for example, if there are more than 16 files in a 4-second interval for the process in the staging directory, the process is throttled. The files do not rotate for the process from `/tmp/<FRU>/trace` into `/tmp/<FRU>/trace/stage`, however the files are deleted when they reach the maximum size. Throttling is re-enabled, when the count goes below 8.

Tracing Levels

Tracing levels determine how much information should be stored about a module in the trace buffer or file.

The following table shows all of the tracing levels that are available, and provides descriptions of the message that are displayed with each tracing level.

Table 48: Tracing Levels and Descriptions

Tracing Level	Description
Emergency	The message is regarding an issue that makes the system unusable.
Error	The message is regarding a system error.
Warning	The message is regarding a system warning.
Notice	The message is regarding a significant issue, but the switch is still working normally.
Informational	The message is useful for informational purposes only.
Debug	The message provides debug-level output.
Verbose	All possible trace messages are sent.
Noise	All possible trace messages for the module are logged. The noise level is always equal to the highest possible tracing level. Even if a future enhancement to tracing introduces a higher tracing level, the noise level will become equal to the level of that new enhancement.

set platform software trace

To set the trace level for a specific module within a process, use the **set platform software trace** command in privileged EXEC or user EXEC mode.

set platform software trace *process slot module trace-level*

Syntax Description

process

Process whose tracing level is being set. Options include:

- **chassis-manager**—The Chassis Manager process.
 - **cli-agent**—The CLI Agent process.
 - **dbm**—The Database Manager process.
 - **emd**—The Environmental Monitoring process.
 - **fed**—The Forwarding Engine Driver process.
 - **forwarding-manager**—The Forwarding Manager process.
 - **host-manager**—The Host Manager process.
 - **iomd**—The Input/Output Module daemon (IOMd) process.
 - **ios**—The IOS process.
 - **license-manager**—The License Manager process.
 - **logger**—The Logging Manager process.
 - **platform-mgr**—The Platform Manager process.
 - **pluggable-services**—The Pluggable Services process.
 - **replication-mgr**—The Replication Manager process.
 - **shell-manager**—The Shell Manager process.
 - **smd**—The Session Manager process.
 - **table-manager**—The Table Manager Server.
 - **wireless**—The wireless controller module process.
 - **wireshark**—The Embedded Packet Capture (EPC) Wireshark process.
-

<i>slot</i>	<p>Hardware slot where the process for which the trace level is set, is running. Options include:</p> <ul style="list-style-type: none">• <i>number</i>—Number of the SIP slot of the hardware module where the trace level is set. For instance, if you want to specify the SIP in SIP slot 2 of the switch, enter 2.• <i>SIP-slot / SPA-bay</i>—Number of the SIP switch slot and the number of the shared port adapter (SPA) bay of that SIP. For instance, if you want to specify the SPA in bay 2 of the SIP in switch slot 3, enter 3/2.• F0—The Embedded-Service-Processor in slot 0.• FP active—The active Embedded-Service-Processor.• R0—The route processor in slot 0.• RP active—The active route processor.• switch <number> —The switch with its number specified.• switch active—The active switch.• switch standby—The standby switch.
<i>module</i>	Module within the process for which the tracing level is set.

trace-level

Trace level. Options include:

- **debug**—Debug level tracing. A debug-level trace message is a non-urgent message providing a large amount of detail about the module.
 - **emergency**—Emergency level tracing. An emergency-level trace message is a message indicating that the system is unusable.
 - **error**—Error level tracing. An error-level tracing message is a message indicating a system error.
 - **info**—Information level tracing. An information-level tracing message is a non-urgent message providing information about the system.
 - **noise**—Noise level tracing. The noise level is always equal to the highest tracing level possible and always generates every possible tracing message.

The noise level is always equal to the highest-level tracing message possible for a module, even if future enhancements to this command introduce options that allow users to set higher tracing levels.
 - **notice**—The message is regarding a significant issue, but the switch is still working normally.
 - **verbose**—Verbose level tracing. All possible tracing messages are sent when the trace level is set to verbose.
 - **warning**—Warning messages.
-

Command Default The default tracing level for all modules is **notice**.

Command Modes User EXEC (>)
Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines The *module* options vary by process and by *hardware-module*. Use the ? option when entering this command to see which *module* options are available with each keyword sequence.

Use the **show platform software trace message** command to view trace messages.

Trace files are stored in the tracelogs directory in the harddisk: file system. These files can be deleted without doing any harm to your switch operation.

Trace file output is used for debugging. The trace level is a setting that determines how much information should be stored in trace files about a module.

Examples

This example shows how to set the trace level for all the modules in dbm process:

```
Device# set platform software trace dbm R0 all-modules debug
```

show platform software trace filter-binary

To display the most recent trace information for a specific module, use the **show platform software trace filter-binary** command in privileged EXEC or user EXEC mode.

show platform software trace filter-binary *modules* [**context** *mac-address*]

Syntax Description

context *mac-address*

Represents the context used to filter. Additionally, you can filter based on module names and trace levels. The context keyword accepts either a MAC address or any other argument based on which a trace is tagged.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release

Modification

Cisco IOS XE Denali 16.1.1 This command was introduced.

Usage Guidelines

This command collates and sorts all the logs present in the `/tmp/.../` across all the processes relevant to the module. The trace logs of all the processes relevant to the specified module are printed to the console. This command also generates a file named `collated_log_{system time}` with the same content, in the `/crashinfo/tracelogs` directory.

Examples

This example shows how to display the trace information for a wireless module:

```
Device# show platform software trace filter-binary wireless
```

show platform software trace message

To display the trace messages for a process, use the **set platform software trace** command in privileged EXEC or user EXEC mode.

show platform software trace message *process slot*

Syntax Description*process*

Tracing level that is being set. Options include:

- **chassis-manager**—The Chassis Manager process.
 - **cli-agent**—The CLI Agent process.
 - **cmm**—The CMM process.
 - **dbm**—The Database Manager process.
 - **emd**—The Environmental Monitoring process.
 - **fed**—The Forwarding Engine Driver process.
 - **forwarding-manager**—The Forwarding Manager process.
 - **geo**—The Geo Manager process.
 - **host-manager**—The Host Manager process.
 - **interface-manager**—The Interface Manager process.
 - **iomd**—The Input/Output Module daemon (IOMd) process.
 - **ios**—The IOS process.
 - **license-manager**—The License Manager process.
 - **logger**—The Logging Manager process.
 - **platform-mgr**—The Platform Manager process.
 - **pluggable-services**—The Pluggable Services process.
 - **replication-mgr**—The Replication Manager process.
 - **shell-manager**—The Shell Manager process.
 - **sif**—The Stack Interface (SIF) Manager process.
 - **smd**—The Session Manager process.
 - **stack-mgr**—The Stack Manager process.
 - **table-manager**—The Table Manager Server.
 - **thread-test**—The Multithread Manager process.
 - **virt-manager**—The Virtualization Manager process.
 - **wireless**—The wireless controller module process.
-

slot

Hardware slot where the process for which the trace level is set, is running. Options include:

- *number*—Number of the SIP slot of the hardware module where the trace level is set. For instance, if you want to specify the SIP in SIP slot 2 of the switch, enter 2.
- *SIP-slot / SPA-bay*—Number of the SIP switch slot and the number of the shared port adapter (SPA) bay of that SIP. For instance, if you want to specify the SPA in bay 2 of the SIP in switch slot 3, enter 3/2.
- **F0**—The Embedded Service Processor slot 0.
- **FP active**—The active Embedded Service Processor.
- **R0**—The route processor in slot 0.
- **RP active**—The active route processor.
- **switch <number>** —The switch, with its number specified.
- **switch active**—The active switch.
- **switch standby**—The standby switch.
 - *number*—Number of the SIP slot of the hardware module where the trace level is set. For instance, if you want to specify the SIP in SIP slot 2 of the switch, enter 2.
 - *SIP-slot / SPA-bay*—Number of the SIP switch slot and the number of the shared port adapter (SPA) bay of that SIP. For instance, if you want to specify the SPA in bay 2 of the SIP in switch slot 3, enter 3/2.
 - **F0**—The Embedded Service Processor in slot 0.
 - **FP active**—The active Embedded Service Processor.
 - **R0**—The route processor in slot 0.
 - **RP active**—The active route processor.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Denali 16.1.1	This command was introduced.

Examples

This example shows how to display the trace messages for the Stack Manager and the Forwarding Engine Driver processes:

```

Device# show platform software trace message stack-mgr switch active R0
10/30 09:42:48.767 [btrace] [8974]: (note): Successfully registered module [97] [uiutil]
10/30 09:42:48.762 [btrace] [8974]: (note): Successfully registered module [98]
[tdl_cdlcore_message]
10/29 13:28:19.023 [stack_mgr] [8974]: (note): Examining peer state
10/29 13:28:19.023 [stack_mgr] [8974]: (note): no switch eligible for standby election
presently
10/29 13:28:19.022 [stack_mgr] [8974]: (note): Posting event
stack_fsm_event_wait_standby_elect_timer_expired, curstate stack_fsm_state_active_ready
10/29 13:28:19.022 [stack_mgr] [8974]: (note): Timer HDL - STACK_WAIT_STANDBY_ELECT_TIMER
expired
10/29 13:26:46.584 [btrace] [8974]: (note): Successfully registered module [99]
[tdl_ui_message]
10/29 13:26:46.582 [bipc] [8974]: (note): Pending connection to server 10.129.1.0
10/29 13:26:36.582 [evutil] [8974]: (ERR): Connection attempt for sman-ui-serv (uipeer
uplink to slot 1) failed, invoking disconnect
10/29 13:26:36.582 [evutil] [8974]: (ERR): Asynchronous connect failed for [uipeer uplink
to slot 1] (fd == -1)
10/29 13:26:36.581 [bipc] [8974]: (note): Pending connection to server 10.129.1.0
10/29 13:26:26.581 [evutil] [8974]: (ERR): Connection attempt for sman-ui-serv (uipeer
uplink to slot 1) failed, invoking disconnect

Device# show platform software trace message fed switch active
11/02 10:55:01.832 [btrace]: [11310]: UUID: 0, ra: 0 (note): Successfully registered module
[86] [uiutil]
11/02 10:55:01.848 [btrace]: [11310]: UUID: 0, ra: 0 (note): Single message size is greater
than 1024
11/02 10:55:01.822 [btrace]: [11310]: UUID: 0, ra: 0 (note): Successfully registered module
[87] [tdl_cdlcore_message]
11/01 09:54:41.474 [btrace]: [12312]: UUID: 0, ra: 0 (note): Successfully registered module
[88] [tdl_ngwc_gold_message]
11/01 09:54:11.228 [btrace]: [12312]: UUID: 0, ra: 0 (note): Successfully registered module
[89] [tdl_doppler_iosd_matm_type]
11/01 09:53:37.454 [btrace]: [11310]: UUID: 0, ra: 0 (note): Successfully registered module
[90] [tdl_ui_message]
11/01 09:53:37.382 [bipc]: [11310]: UUID: 0, ra: 0 (note): Pending connection to server
10.129.1.0
11/01 09:53:34.227 [xcvr]: [18846]: UUID: 0, ra: 0 (ERR): FRU hardware authentication Fail,
result = 1.
11/01 09:53:33.775 [ng3k_scc]: [18846]: UUID: 0, ra: 0 (ERR): SMART COOKIE: SCC I2C receive
failed: rc=10
11/01 09:53:33.775 [ng3k_scc]: [18846]: UUID: 0, ra: 0 (ERR):
SMART COOKIE receive failed, try again
11/01 09:53:33.585 [ng3k_scc]: [18846]: UUID: 0, ra: 0 (ERR):

```

show platform software trace level

To view the trace levels for all the modules under a specific process, use the **show platform software trace level** command in privileged EXEC or user EXEC mode.

show platform software trace level *process slot*

Syntax Description

process

Process whose tracing level is being set. Options include:

- **chassis-manager**—The Chassis Manager process.
- **cli-agent**—The CLI Agent process.
- **cmm**—The CMM process.
- **dbm**—The Database Manager process.
- **emd**—The Environmental Monitoring process.
- **fed**—The Forwarding Engine Driver process.
- **forwarding-manager**—The Forwarding Manager process.
- **geo**—The Geo Manager process.
- **host-manager**—The Host Manager process.
- **interface-manager**—The Interface Manager process.
- **iomd**—The Input/Output Module daemon (IOMd) process.
- **ios**—The IOS process.
- **license-manager**—The License Manager process.
- **logger**—The Logging Manager process.
- **platform-mgr**—The Platform Manager process.
- **pluggable-services**—The Pluggable Services process.
- **replication-mgr**—The Replication Manager process.
- **shell-manager**—The Shell Manager process.
- **sif**—The Stack Interface (SIF) Manager process.
- **smd**—The Session Manager process.
- **stack-mgr**—The Stack Manager process.
- **table-manager**—The Table Manager Server.
- **thread-test**—The Multithread Manager process.
- **virt-manager**—The Virtualization Manager process.
- **wireless**—The wireless controller module process.

<i>slot</i>	<p>Hardware slot where the process for which the trace level is set, is running. Options include:</p> <ul style="list-style-type: none"> • <i>number</i>—Number of the SIP slot of the hardware module where the trace level is set. For instance, if you want to specify the SIP in SIP slot 2 of the switch, enter 2. • <i>SIP-slot / SPA-bay</i>—Number of the SIP switch slot and the number of the shared port adapter (SPA) bay of that SIP. For instance, if you want to specify the SPA in bay 2 of the SIP in switch slot 3, enter 3/2. • F0—The Embedded Service Processor in slot 0. • F1—The Embedded Service Processor in slot 1. • FP active—The active Embedded Service Processor. • R0—The route processor in slot 0. • RP active—The active route processor. • switch <number> —The switch, with its number specified. • switch active—The active switch. • switch standby—The standby switch. <ul style="list-style-type: none"> • <i>number</i>—Number of the SIP slot of the hardware module where the trace level is set. For instance, if you want to specify the SIP in SIP slot 2 of the switch, enter 2. • <i>SIP-slot / SPA-bay</i>—Number of the SIP switch slot and the number of the shared port adapter (SPA) bay of that SIP. For instance, if you want to specify the SPA in bay 2 of the SIP in switch slot 3, enter 3/2. • F0—The Embedded Service Processor in slot 0. • FP active—The active Embedded Service Processor. • R0—The route processor in slot 0. • RP active—The active route processor.
-------------	---

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Denali 16.1.1	This command was introduced.

Examples

This example shows how to view the trace level:

```
Device# show platform software trace level dbm switch active R0
```

Module Name	Trace Level
-----	-----
binos	Notice
binos/brand	Notice
bipc	Notice
btrace	Notice
bump_ptr_alloc	Notice
cdllib	Notice
chasfs	Notice
dbal	Informational
dbm	Debug
evlib	Notice
evutil	Notice
file_alloc	Notice
green-be	Notice
ios-avl	Notice
klib	Debug
services	Notice
sw_wdog	Notice
syshw	Notice
tcl_cdlcore_message	Notice
tcl_dbal_root_message	Notice
tcl_dbal_root_type	Notice

request platform software trace archive

To archive all the trace logs relevant to all the processes running on a system since the last reload on the switches and to save this in the specified location, use the **request platform software trace archive** command in privileged EXEC or user EXEC mode.

request platform software trace archive [*last number-of-days* [**days** [**target location**]] | **target location**]

Syntax Description		
last <i>number-of-days</i>		Specifies the number of days for which the trace files have to be archived.
target <i>location</i>		Specifies the location and name of the archive file.

Command Modes	
	User EXEC (>)
	Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines This archive file can be copied from the system, using the tftp or scp commands.

Examples This example shows how to archive all the trace logs of the processes running on the switch since the last 5 days:

```
Device# request platform software trace archive last 5 days target flash:test_archive
```

request platform software trace rotate all

To rotate all the current in-memory trace logs into the crashinfo partition and start a new in-memory trace log for each process, use the **request platform software trace rotate all** command in privileged EXEC or user EXEC mode.

request platform software trace rotate all

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release

Modification

Cisco IOS XE Denali 16.1.1 This command was introduced.

Usage Guidelines

The trace log files are for read-only purpose. Do not edit the contents of the file. If there is a requirement to delete the contents of the file to view certain set of logs, use this command to start a new trace log file.

Examples

This example shows how to rotate all the in-memory trace logs of the processes running on the switch since the last one day:

```
Device# request platform software trace slot switch active R0 archive last 1 days target flash:test
```

request platform software trace filter-binary

To collate and sort all the archived logs present in the `tracelogs` subdirectory, use the **request platform software trace filter-binary** command in privileged EXEC or user EXEC mode.

request platform software trace filter-binary *modules* [**context** *mac-address*]

Syntax Description	context <i>mac-address</i>	Represents the context used to filter. Additionally, you can filter based on module names and trace levels. The context keyword accepts either a MAC address or any other argument based on which a trace is tagged.
---------------------------	-----------------------------------	--

Command Modes	User EXEC (>) Privileged EXEC (#)
----------------------	--------------------------------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines	This command collates and sorts all the archived logs present in the <code>tracelogs</code> subdirectory, across all the processes relevant to the module. This command also generates a file named <code>collated_log_{system time}</code> with the same content, in the <code>/crashinfo/tracelogs</code> directory.
-------------------------	--

Examples	This example shows how to display the trace information for a wireless module:
-----------------	--

```
Device# request platform software trace filter-binary wireless
```

set platform software trace wireless switch active R0 hyperlocation

To trace the Cisco Hyperlocation related messages, use the **set platform software trace wireless switch active R0 hyperlocation** command.

set platform software trace wireless switch active R0 hyperlocation { **debug** | **emergency** | **error** | **info** | **noise** | **notice** | **verbose** | **warning** }

Syntax Description	
debug	Debug messages
emergency	Emergency possible message
error	Error messages
info	Informational messages
noise	Maximum possible message
notice	Notice messages
verbose	Verbose debug messages
warning	Warning messages

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

■ set platform software trace wireless switch active R0 hyperlocation



PART **XVI**

VideoStream

- [VideoStream Commands, on page 1299](#)



VideoStream Commands

- [ap dot11 media-stream multicast-direct](#), on page 1300
- [show ap dot11](#), on page 1301
- [show wireless media-stream group](#), on page 1302
- [wireless media-stream multicast-direct](#), on page 1303
- [wireless media-stream](#), on page 1304

ap dot11 media-stream multicast-direct

To configure multicast-direct for 2.4-GHz/5-GHz band, use the **ap dot11 media-stream multicast-direct** command.

```
ap dot11 {24ghz | 5ghz} media-stream {multicast-direct {admission-besteffort | client-maximum
value | radio-maximum value} | video-redirect}
```

Syntax Description

multicast-direct	Configure multicast-direct for 802.11 band
admission-besteffort	Admits media stream to best-effort queue.
client-maximum <i>value</i>	Specifies the maximum number of streams allowed on a client.
radio-maximum <i>value</i>	Specifies the maximum number of streams allowed on a 2.4-GHz or a 5-GHz band.
video-redirect	Redirect non Multicast-direct video to BestEffort queue over the air.

Command Default

None

Command Modes

config

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Command History

Release	Modification
7.6	This command was introduced in a release earlier than Release 7.6.

Usage Guidelines

Before you configure the media stream multicast-direct parameters on a 802.11 network, ensure that the network is nonoperational.

Examples

The following example shows how to configure multicast-direct for the 2.4-GHz band.

```
(Cisco Controller) >Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#ap dot11 24ghz media-stream multicast-direct
```

Related Topics

[wireless media-stream multicast-direct](#), on page 1303

show ap dot11

To display 802.11 band parameters, use the **show ap dot11** command.

```
show ap dot11 {24ghz | 5ghz} {media-stream rrc | network | profile | summary}
```

Syntax Description

media-stream rrc	Displays Media Stream configurations.
network	Shows network configuration.
profile	Shows profiling information for all Cisco APs.
summary	Shows configuration and statistics of 802.11b and 802.11a Cisco APs.

Command Default

None

Command Modes

User EXEC command mode or Privileged EXEC command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Command History

Release	Modification
7.6	This command was introduced in a release earlier than Release 7.6.

Usage Guidelines

None.

The following is a sample output of the **show ap dot11 24ghz media-stream rrc** command.

```
Device#show ap dot11 24ghz media-stream rrc

Multicast-direct           : Disabled
Best Effort                 : Disabled
Video Re-Direct           : Disabled
Max Allowed Streams Per Radio : Auto
Max Allowed Streams Per Client : Auto
Max Video Bandwidth        : 0
Max Voice Bandwidth        : 75
Max Media Bandwidth        : 85
Min PHY Rate (Kbps)        : 6000
Max Retry Percentage       : 80
```

Related Topics

[wireless media-stream](#), on page 1304

show wireless media-stream group

To display the wireless media-stream group information, use the **show wireless media-stream group** command.

show wireless media-stream group {**detail** *groupName* | **summary**}

Syntax Description

detail <i>groupName</i>	Display media-stream group configuration details of the group mentioned in the command.
summary	Display media-stream group configuration summary

Command Default

None

Command Modes

User EXEC mode or Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Command History

Release	Modification
7.6	This command was introduced in a release earlier than Release 7.6.

Usage Guidelines

None.

The following is a sample output of the **show wireless media-stream group detail GRP1** command.

```
Device#show wireless media-stream group detail GRP1
```

Related Topics

[wireless media-stream](#), on page 1304

wireless media-stream multicast-direct

To configure multicast-direct status, use the **media-stream multicast-direct** command. To remove the multicast-direct status, use the no form of the command.

no wireless media-stream multicast-direct

Command Default None

Command Modes config

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Usage Guidelines Media stream multicast-direct requires load based Call Admission Control (CAC) to run. WLAN quality of service (QoS) needs to be set to either gold or platinum.

Examples

The following example shows how to configure multicast-direct for a wireless LAN media stream.

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#wireless media-stream multicast-direct
```

wireless media-stream

To configure various parameters, use the **wireless media-stream** command.

```
wireless media-stream group groupName [startipAddr endipAddr]
```

```
wireless media-stream group{ avg-packet-size default exit max-bandwidth no
policy qos}
```

```
wireless media-stream {multicast-direct | message [{phone phone | URL URL | Notes Notes | Email
Email}]}
```

Syntax Description		
group <i>groupName</i>		Configure multicast-direct status for a group.
<i>startipAddr</i>		Specifies the start IP Address for the group.
<i>endipAddr</i>		Specifies the End IP Address for the group.
group <i>avg-packet-size</i>		Configure average packet size.
group <i>default</i>		Set a command to its defaults.
group <i>exit</i>		Exit sub-mode.
group <i>max-bandwidth</i>		Configure maximum expected stream bandwidth in Kbps.
group <i>no</i>		Negate a command or set its defaults.
group <i>policy</i>		Configure media stream admission policy.
group <i>qos</i>		Configure over the air QoS class, <'video'> ONLY.
multicast-direct		Configure multicast-direct status.
message		Configure Session Announcement Message.
phone <i>phone</i>		Configure Session Announcement Phone number.
URL <i>URL</i>		Configure Session Announcement URL.
Notes <i>Notes</i>		Configure Session Announcement notes.
Email <i>Email</i>		Configure Session Announcement Email.

Command Default Disabled

Command Modes config

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Usage Guidelines Media-stream multicast-direct requires load-based Call Admission Control (CAC) to run.

Examples

The following example shows how to configure each media stream and its parameters like expected multicast destination addresses, stream bandwidth consumption and stream priority parameters.

```
Device#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
Device(config)#wireless media-stream group GROUP1 231.1.1.1 231.1.1.10
```




PART **XVII**

VLAN

- [VLAN Commands, on page 1309](#)



VLAN Commands

- [client vlan](#), on page 1310
- [clear vtp counters](#), on page 1311
- [debug platform vlan](#), on page 1312
- [debug sw-vlan](#), on page 1313
- [debug sw-vlan ifs](#), on page 1315
- [debug sw-vlan notification](#), on page 1316
- [debug sw-vlan vtp](#), on page 1317
- [interface vlan](#), on page 1319
- [show platform vlan](#), on page 1321
- [show vlan](#), on page 1322
- [show vtp](#), on page 1325
- [show wireless vlan group](#), on page 1331
- [switchport priority extend](#), on page 1332
- [switchport trunk](#), on page 1333
- [vlan](#), on page 1336
- [vlan dot1q tag native](#), on page 1342
- [vtp \(global configuration\)](#), on page 1343
- [vtp \(interface configuration\)](#), on page 1348
- [vtp primary](#), on page 1349
- [wireless broadcast vlan](#), on page 1350

client vlan

To configure a WLAN interface or an interface group, use the **client vlan** command. To disable the WLAN interface, use the **no** form of this command.

client vlan *interface-id-name-or-group-name*
no client vlan

Syntax Description	<i>interface-id-name-or-group-name</i> Interface ID, name, or VLAN group name. The interface ID can also be in digits too.
---------------------------	--

Command Default	The default interface is configured.
------------------------	--------------------------------------

Command Modes	WLAN configuration
----------------------	--------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines	You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.
-------------------------	--

This example shows how to enable a client VLAN on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# client vlan client-vlan1
Device(config-wlan)# end
```

This example shows how to disable a client VLAN on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no client vlan
Device(config-wlan)# end
```

Related Topics

[wlan](#), on page 1402

clear vtp counters

To clear the VLAN Trunking Protocol (VTP) and pruning counters, use the **clear vtp counters** command in privileged EXEC mode.

clear vtp counters

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to clear the VTP counters:

```
Device# clear vtp counters
```

You can verify that information was deleted by entering the **show vtp counters** privileged EXEC command.

Related Topics

[show vtp](#), on page 1325

debug platform vlan

To enable debugging of the VLAN manager software, use the **debug platform vlan** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug platform vlan [{error | event}] [switch switch-number]
no debug platform vlan [{error | event}] [switch switch-number]
```

Syntax Description

error	(Optional) Displays VLAN error debug messages.
event	(Optional) Displays VLAN platform event debug messages.
switch <i>switch-number</i>	(Optional) Specifies the stack member number on which to enable debugging of the VLAN manager software. This keyword is supported only on stacking-capable switches.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The **undebg platform vlan** command is the same as the **no debug platform vlan** command.

This example shows how to display VLAN error debug messages:

```
Device# debug platform vlan error
```

debug sw-vlan

To enable debugging of VLAN manager activities, use the **debug sw-vlan** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug sw-vlan {badpmcookies | cfg-vlan {bootup | cli} | events | ifs | management | mapping | notification
| packets | redundancy | registries | vtp}
no debug sw-vlan {badpmcookies | cfg-vlan {bootup | cli} | events | ifs | management | mapping |
notification | packets | redundancy | registries | vtp}
```

Syntax Description

badpmcookies	Displays debug messages for VLAN manager incidents of bad port manager cookies.
cfg-vlan	Displays VLAN configuration debug messages.
bootup	Displays messages when the switch is booting up.
cli	Displays messages when the command-line interface (CLI) is in VLAN configuration mode.
events	Displays debug messages for VLAN manager events.
ifs	Displays debug messages for the VLAN manager IOS file system (IFS). See debug sw-vlan ifs, on page 1315 for more information.
management	Displays debug messages for VLAN manager management of internal VLANs.
mapping	Displays debug messages for VLAN mapping.
notification	Displays debug messages for VLAN manager notifications. See debug sw-vlan notification, on page 1316 for more information.
packets	Displays debug messages for packet handling and encapsulation processes.
redundancy	Displays debug messages for VTP VLAN redundancy.
registries	Displays debug messages for VLAN manager registries.
vtp	Displays debug messages for the VLAN Trunking Protocol (VTP) code. See debug sw-vlan vtp, on page 1317 for more information.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

The **undebug sw-vlan** command is the same as the **no debug sw-vlan** command.

This example shows how to display debug messages for VLAN manager events:

```
Device# debug sw-vlan events
```

Related Topics

[debug sw-vlan ifs](#), on page 1315

[debug sw-vlan notification](#), on page 1316

[debug sw-vlan vtp](#), on page 1317

[show vlan](#), on page 1322

[show vtp](#), on page 1325

debug sw-vlan ifs

To enable debugging of the VLAN manager IOS file system (IFS) error tests, use the **debug sw-vlan ifs** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug sw-vlan ifs {open {read | write} | read {1 | 2 | 3 | 4} | write}
no debug sw-vlan ifs {open {read | write} | read {1 | 2 | 3 | 4} | write}
```

Syntax Description	open read	Displays VLAN manager IFS file-read operation debug messages.
	open write	Displays VLAN manager IFS file-write operation debug messages.
	read	Displays file-read operation debug messages for the specified error test (1, 2, 3, or 4).
	write	Displays file-write operation debug messages.

Command Default Debugging is disabled.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines The **undebug sw-vlan ifs** command is the same as the **no debug sw-vlan ifs** command.

When selecting the file read operation, Operation **1** reads the file header, which contains the header verification word and the file version number. Operation **2** reads the main body of the file, which contains most of the domain and VLAN information. Operation **3** reads type length version (TLV) descriptor structures. Operation **4** reads TLV data.

This example shows how to display file-write operation debug messages:

```
Device# debug sw-vlan ifs write
```

Related Topics

[show vlan](#), on page 1322

debug sw-vlan notification

To enable debugging of VLAN manager notifications, use the **debug sw-vlan notification** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug sw-vlan notification {accfwdchange | allowedvlanfgchange | fwdchange | linkchange | modechange | pruningcfgchange | statechange}
no debug sw-vlan notification {accfwdchange | allowedvlanfgchange | fwdchange | linkchange | modechange | pruningcfgchange | statechange}
```

Syntax Description

accfwdchange	Displays debug messages for VLAN manager notification of aggregated access interface spanning-tree forward changes.
allowedvlanfgchange	Displays debug messages for VLAN manager notification of changes to the allowed VLAN configuration.
fwdchange	Displays debug messages for VLAN manager notification of spanning-tree forwarding changes.
linkchange	Displays debug messages for VLAN manager notification of interface link-state changes.
modechange	Displays debug messages for VLAN manager notification of interface mode changes.
pruningcfgchange	Displays debug messages for VLAN manager notification of changes to the pruning configuration.
statechange	Displays debug messages for VLAN manager notification of interface state changes.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

The **undebug sw-vlan notification** command is the same as the **no debug sw-vlan notification** command.

This example shows how to display debug messages for VLAN manager notification of interface mode changes:

```
Device# debug sw-vlan notification
```

Related Topics

[show vlan](#), on page 1322

debug sw-vlan vtp

To enable debugging of the VLAN Trunking Protocol (VTP) code, use the **debug sw-vlan vtp** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug sw-vlan vtp {events | packets | pruning [{packets | xmit}] | redundancy | xmit}
no debug sw-vlan vtp {events | packets | pruning | redundancy | xmit}
```

Syntax Description		
	events	Displays debug messages for general-purpose logic flow and detailed VTP messages generated by the VTP_LOG_RUNTIME macro in the VTP code.
	packets	Displays debug messages for the contents of all incoming VTP packets that have been passed into the VTP code from the Cisco IOS VTP platform-dependent layer, except for pruning packets.
	pruning	Displays debug messages generated by the pruning segment of the VTP code.
	packets	(Optional) Displays debug messages for the contents of all incoming VTP pruning packets that have been passed into the VTP code from the Cisco IOS VTP platform-dependent layer.
	xmit	(Optional) Displays debug messages for the contents of all outgoing VTP packets that the VTP code requests the Cisco IOS VTP platform-dependent layer to send.
	redundancy	Displays debug messages for VTP redundancy.
	xmit	Displays debug messages for the contents of all outgoing VTP packets that the VTP code requests the Cisco IOS VTP platform-dependent layer to send, except for pruning packets.

Command Default Debugging is disabled.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines The **undebug sw-vlan vtp** command is the same as the **no debug sw-vlan vtp** command.

If no additional parameters are entered after the **pruning** keyword, VTP pruning debugging messages appear. They are generated by the VTP_PRUNING_LOG_NOTICE, VTP_PRUNING_LOG_INFO, VTP_PRUNING_LOG_DEBUG, VTP_PRUNING_LOG_ALERT, and VTP_PRUNING_LOG_WARNING macros in the VTP pruning code.

This example shows how to display debug messages for VTP redundancy:

```
Device# debug sw-vlan vtp redundancy
```

Related Topics

[show vtp](#), on page 1325

interface vlan

To create or access a dynamic switch virtual interface (SVI) and to enter interface configuration mode, use the **interface vlan** command in global configuration mode. To delete an SVI, use the **no** form of this command.

interface vlan *vlan-id*
no interface vlan *vlan-id*

Syntax Description	<i>vlan-id</i>	VLAN number. The range is 1 to 4094.
Command Default	The default VLAN interface is VLAN 1.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Usage Guidelines	SVIs are created the first time you enter the interface vlan <i>vlan-id</i> command for a particular VLAN. The <i>vlan-id</i> corresponds to the VLAN-tag associated with data frames on an IEEE 802.1Q encapsulated trunk or the VLAN ID configured for an access port.	



Note When you create an SVI, it does not become active until it is associated with a physical port.

If you delete an SVI using the **no interface vlan** *vlan-id* command, it is no longer visible in the output from the **show interfaces** privileged EXEC command.



Note You cannot delete the VLAN 1 interface.

You can reinstate a deleted SVI by entering the **interface vlan** *vlan-id* command for the deleted interface. The interface comes back up, but the previous configuration is gone.

The interrelationship between the number of SVIs configured on a switch or a switch stack and the number of other features being configured might have an impact on CPU utilization due to hardware limitations. You can use the **sdm prefer** global configuration command to reallocate system hardware resources based on templates and feature tables.

You can verify your setting by entering the **show interfaces** and **show interfaces vlan** *vlan-id* privileged EXEC commands.

This example shows how to create a new SVI with VLAN ID 23 and enter interface configuration mode:

```
Device(config)# interface vlan 23
Device(config-if)#
```

Related Topics

[show interfaces](#), on page 183

show platform vlan

To display platform-dependent VLAN information, use the **show platform vlan** privileged EXEC command.

```
show platform vlan [vlan-id] [switch switch-number]
```

Syntax Description		
	<i>vlan-id</i>	(Optional) ID of the VLAN. The range is 1 to 4094.
	switch <i>switch-number</i>	(Optional) Limits the display to VLANs on the specified stack member.

Command Default	None
------------------------	------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines	Use this command only when you are working directly with your technical support representative while troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.
-------------------------	---

This example shows how to display platform-dependent VLAN information:

```
Device# show platform vlan
```

show vlan

To display the parameters for all configured VLANs or one VLAN (if the VLAN ID or name is specified) on the switch, use the **show vlan** command in user EXEC mode.

```
show vlan [{brief | dot1q tag native | group | id vlan-id | mtu | name vlan-name | remote-span | summary}]
```

Syntax Description		
brief	(Optional) Displays one line for each VLAN with the VLAN name, status, and its ports.	
dot1q tag native	(Optional) Displays the IEEE 802.1Q native VLAN tagging status.	
group	(Optional) Displays information about VLAN groups.	
id <i>vlan-id</i>	(Optional) Displays information about a single VLAN identified by the VLAN ID number. For <i>vlan-id</i> , the range is 1 to 4094.	
mtu	(Optional) Displays a list of VLANs and the minimum and maximum transmission unit (MTU) sizes configured on ports in the VLAN.	
name <i>vlan-name</i>	(Optional) Displays information about a single VLAN identified by the VLAN name. The VLAN name is an ASCII string from 1 to 32 characters.	
remote-span	(Optional) Displays information about Remote SPAN (RSPAN) VLANs.	
summary	(Optional) Displays VLAN summary information.	



Note The **ifindex** keyword is not supported, even though it is visible in the command-line help string.

Command Default None

Command Modes User EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines In the **show vlan mtu** command output, the MTU_Mismatch column shows whether all the ports in the VLAN have the same MTU. When yes appears in the column, it means that the VLAN has ports with different MTUs, and packets that are switched from a port with a larger MTU to a port with a smaller MTU might be dropped. If the VLAN does not have an SVI, the hyphen (-) symbol appears in the SVI_MTU column. If the MTU-Mismatch column displays yes, the names of the ports with the MinMTU and the MaxMTU appear.

This is an example of output from the **show vlan** command. See the table that follows for descriptions of the fields in the display.

```
Device> show vlan
VLAN Name                               Status      Ports
-----
1    default                               active     Gi1/0/2, Gi1/0/3, Gi1/0/4
                                           Gi1/0/5, Gi1/0/6, Gi1/0/7
                                           Gi1/0/8, Gi1/0/9, Gi1/0/10
                                           Gi1/0/11, Gi1/0/12, Gi1/0/13
                                           Gi1/0/14, Gi1/0/15, Gi1/0/16
                                           Gi1/0/17, Gi1/0/18, Gi1/0/19
                                           Gi1/0/20, Gi1/0/21, Gi1/0/22
                                           Gi1/0/23, Gi1/0/24, Gi1/0/25
                                           Gi1/0/26, Gi1/0/27, Gi1/0/28
                                           Gi1/0/29, Gi1/0/30, Gi1/0/31
                                           Gi1/0/32, Gi1/0/33, Gi1/0/34
                                           Gi1/0/35, Gi1/0/36, Gi1/0/37
                                           Gi1/0/38, Gi1/0/39, Gi1/0/40
                                           Gi1/0/41, Gi1/0/42, Gi1/0/43
                                           Gi1/0/44, Gi1/0/45, Gi1/0/46
                                           Gi1/0/47, Gi1/0/48

2    VLAN0002                               active
40   vlan-40                                 active
300  VLAN0300                               active
1002 fddi-default                           act/unsup
1003 token-ring-default                    act/unsup
1004 fddinet-default                       act/unsup
1005 trnet-default                         act/unsup

VLAN Type  SAID      MTU   Parent RingNo BridgeNo  Stp  BrdgMode  Trans1  Trans2
-----
1    enet  100001    1500 -     -     -     -     -     0      0
2    enet  100002    1500 -     -     -     -     -     0      0
40   enet  100040    1500 -     -     -     -     -     0      0
300  enet  100300    1500 -     -     -     -     -     0      0
1002 fddi  101002    1500 -     -     -     -     -     0      0
1003 tr   101003    1500 -     -     -     -     -     0      0
1004 fdnet 101004    1500 -     -     -     -     ieee -     0      0
1005 trnet 101005    1500 -     -     -     -     ibm  -     0      0
2000 enet  102000    1500 -     -     -     -     -     0      0
3000 enet  103000    1500 -     -     -     -     -     0      0

Remote SPAN VLANs
-----
2000,3000

Primary Secondary Type          Ports
-----
```

Table 49: show vlan Command Output Fields

Field	Description
VLAN	VLAN number.
Name	Name, if configured, of the VLAN.
Status	Status of the VLAN (active or suspend).
Ports	Ports that belong to the VLAN.

Field	Description
Type	Media type of the VLAN.
SAID	Security association ID value for the VLAN.
MTU	Maximum transmission unit size for the VLAN.
Parent	Parent VLAN, if one exists.
RingNo	Ring number for the VLAN, if applicable.
BrdgNo	Bridge number for the VLAN, if applicable.
Stp	Spanning Tree Protocol type used on the VLAN.
BrdgMode	Bridging mode for this VLAN—possible values are source-route bridging (SRB) and source-route transparent (SRT); the default is SRB.
Trans1	Translation bridge 1.
Trans2	Translation bridge 2.
Remote SPAN VLANs	Identifies any RSPAN VLANs that have been configured.

This is an example of output from the **show vlan dot1q tag native** command:

```
Device> show vlan dot1q tag native
dot1q native vlan tagging is disabled
```

This is an example of output from the **show vlan summary** command:

```
Device> show vlan summary
Number of existing VLANs           : 45
Number of existing VTP VLANs      : 45
Number of existing extended VLANs : 0
```

This is an example of output from the **show vlan id** command:

```
Device# show vlan id 2
VLAN Name                Status    Ports
-----
2    VLAN0200                active    Gi1/0/7, Gi1/0/8
2    VLAN0200                active    Gi2/0/1, Gi2/0/2

VLAN Type  SAID      MTU   Parent RingNo BridgeNo  Stp  BrdgMode  Trans1  Trans2
-----
2    enet    100002   1500  -     -       -     -         -         0       0

Remote SPAN VLANs
-----
Disabled
```

Related Topics

[switchport mode
vlan](#), on page 1336

show vtp

To display general information about the VLAN Trunking Protocol (VTP) management domain, status, and counters, use the **show vtp** command in EXEC mode.

show vtp {**counters** | **devices** [**conflicts**] | **interface** [*interface-id*] | **password** | **status**}

Syntax Description		
counters		Displays the VTP statistics for the device.
devices		Displays information about all VTP version 3 devices in the domain. This keyword applies only if the device is not running VTP version 3.
conflicts		(Optional) Displays information about VTP version 3 devices that have conflicting primary servers. This command is ignored when the device is in VTP transparent or VTP off mode.
interface		Displays VTP status and configuration for all interfaces or the specified interface.
<i>interface-id</i>		(Optional) Interface for which to display VTP status and configuration. This can be a physical interface or a port channel.
password		Displays the configured VTP password (available in privileged EXEC mode only).
status		Displays general information about the VTP management domain status.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines When you enter the **show vtp password** command when the device is running VTP version 3, the display follows these rules:

- If the **password** *password* global configuration command did not specify the **hidden** keyword and encryption is not enabled on the device, the password appears in clear text.
- If the **password** *password* command did not specify the **hidden** keyword and encryption is enabled on the device, the encrypted password appears.
- If the **password** *password* command is included the **hidden** keyword, the hexadecimal secret key is displayed.

This is an example of output from the **show vtp devices** command. A **Yes** in the **Conflict** column indicates that the responding server is in conflict with the local server for the feature; that is, when two devices in the same domain do not have the same primary server for a database.

```
Device# show vtp devices
Retrieving information from the VTP domain. Waiting for 5 seconds.
VTP Database Conf device ID      Primary Server Revision  System Name
-----
VLAN      Yes  00b0.8e50.d000 000c.0412.6300 12354      main.cisco.com
MST       No   00b0.8e50.d000 0004.AB45.6000 24         main.cisco.com
VLAN      Yes  000c.0412.6300=000c.0412.6300 67         qwerty.cisco.com
```

This is an example of output from the **show vtp counters** command. The table that follows describes each field in the display.

```
Device> show vtp counters
VTP statistics:
Summary advertisements received : 0
Subset advertisements received : 0
Request advertisements received : 0
Summary advertisements transmitted : 0
Subset advertisements transmitted : 0
Request advertisements transmitted : 0
Number of config revision errors : 0
Number of config digest errors : 0
Number of V1 summary errors : 0

VTP pruning statistics:

Trunk          Join Transmitted  Join Received      Summary advts received from
-----
Gi1/0/47       0                 0                 0
Gi1/0/48       0                 0                 0
Gi2/0/1        0                 0                 0
Gi3/0/2        0                 0                 0
```

Table 50: show vtp counters Field Descriptions

Field	Description
Summary advertisements received	Number of summary advertisements received by this device on its trunk ports. Summary advertisements contain the management domain name, the configuration revision number, the update timestamp and identity, the authentication checksum, and the number of subset advertisements to follow.
Subset advertisements received	Number of subset advertisements received by this device on its trunk ports. Subset advertisements contain all the information for one or more VLANs.
Request advertisements received	Number of advertisement requests received by this device on its trunk ports. Advertisement requests normally request information on all VLANs. They can also request information on a subset of VLANs.

Field	Description
Summary advertisements transmitted	Number of summary advertisements sent by this device on its trunk ports. Summary advertisements contain the management domain name, the configuration revision number, the update timestamp and identity, the authentication checksum, and the number of subset advertisements to follow.
Subset advertisements transmitted	Number of subset advertisements sent by this device on its trunk ports. Subset advertisements contain all the information for one or more VLANs.
Request advertisements transmitted	Number of advertisement requests sent by this device on its trunk ports. Advertisement requests normally request information on all VLANs. They can also request information on a subset of VLANs.
Number of configuration revision errors	<p>Number of revision errors.</p> <p>Whenever you define a new VLAN, delete an existing one, suspend or resume an existing VLAN, or modify the parameters on an existing VLAN, the configuration revision number of the device increments.</p> <p>Revision errors increment whenever the device receives an advertisement whose revision number matches the revision number of the device, but the MD5 digest values do not match. This error means that the VTP password in the two devices is different or that the devices have different configurations.</p> <p>These errors indicate that the device is filtering incoming advertisements, which causes the VTP database to become unsynchronized across the network.</p>
Number of configuration digest errors	<p>Number of MD5 digest errors.</p> <p>Digest errors increment whenever the MD5 digest in the summary packet and the MD5 digest of the received advertisement calculated by the device do not match. This error usually means that the VTP password in the two devices is different. To solve this problem, make sure the VTP password on all devices is the same.</p> <p>These errors indicate that the device is filtering incoming advertisements, which causes the VTP database to become unsynchronized across the network.</p>

Field	Description
Number of V1 summary errors	Number of Version 1 errors. Version 1 summary errors increment whenever a device in VTP V2 mode receives a VTP Version 1 frame. These errors indicate that at least one neighboring device is either running VTP Version 1 or VTP Version 2 with V2-mode disabled. To solve this problem, change the configuration of the devices in VTP V2-mode to disabled.
Join Transmitted	Number of VTP pruning messages sent on the trunk.
Join Received	Number of VTP pruning messages received on the trunk.
Summary Advts Received from non-pruning-capable device	Number of VTP summary messages received on the trunk from devices that do not support pruning.

This is an example of output from the **show vtp status** command. The table that follows describes each field in the display.

```
Device> show vtp status
VTP Version capable           : 1 to 3
VTP version running          : 1
VTP Domain Name               :
VTP Pruning Mode              : Disabled
VTP Traps Generation          : Disabled
Device ID                     : 2037.06ce.3580
Configuration last modified by 192.168.1.1 at 10-10-12 04:34:02
Local updater ID is 192.168.1.1 on interface LIIN0 (first layer3 interface found
)

Feature VLAN:
-----
VTP Operating Mode            : Server
Maximum VLANs supported locally : 1005
Number of existing VLANs      : 7
Configuration Revision        : 2
MD5 digest                   : 0xA0 0xA1 0xFE 0x4E 0x7E 0x5D 0x97 0x41
                               0x89 0xB9 0x9B 0x70 0x03 0x61 0xE9 0x27
```

Table 51: show vtp status Field Descriptions

Field	Description
VTP Version capable	Displays the VTP versions that are capable of operating on the device.
VTP Version running	Displays the VTP version operating on the device. By default, the device implements Version 1 but can be set to Version 2.
VTP Domain Name	Name that identifies the administrative domain for the device.

Field	Description
VTP Pruning Mode	Displays whether pruning is enabled or disabled. Enabling pruning on a VTP server enables pruning for the entire management domain. Pruning restricts flooded traffic to those trunk links that the traffic must use to access the appropriate network devices.
VTP Traps Generation	Displays whether VTP traps are sent to a network management station.
Device ID	Displays the MAC address of the local device.
Configuration last modified	Displays the date and time of the last configuration modification. Displays the IP address of the device that caused the configuration change to the database.
VTP Operating Mode	<p>Displays the VTP operating mode, which can be server, client, or transparent.</p> <p>Server—A device in VTP server mode is enabled for VTP and sends advertisements. You can configure VLANs on it. The device guarantees that it can recover all the VLAN information in the current VTP database from NVRAM after reboot. By default, every device is a VTP server.</p> <p>Note The device automatically changes from VTP server mode to VTP client mode if it detects a failure while writing the configuration to NVRAM and cannot return to server mode until the NVRAM is functioning.</p> <p>Client—A device in VTP client mode is enabled for VTP, can send advertisements, but does not have enough nonvolatile storage to store VLAN configurations. You cannot configure VLANs on it. When a VTP client starts up, it does not send VTP advertisements until it receives advertisements to initialize its VLAN database.</p> <p>Transparent—A device in VTP transparent mode is disabled for VTP, does not send or learn from advertisements sent by other devices, and cannot affect VLAN configurations on other devices in the network. The device receives VTP advertisements and forwards them on all trunk ports except the one on which the advertisement was received.</p>
Maximum VLANs Supported Locally	Maximum number of VLANs supported locally.
Number of Existing VLANs	Number of existing VLANs.

Field	Description
Configuration Revision	Current configuration revision number on this device.
MD5 Digest	A 16-byte checksum of the VTP configuration.

This is an example of output from the **show vtp status** command for a device running VTP version 3:

```
Device> show vtp status
VTP Version capable : 1 to 3
VTP version running : 3
VTP Domain Name : Cisco
VTP Pruning Mode : Disabled
VTP Traps Generation : Disabled
Device ID : 0021.1bcd.c700

Feature VLAN:
-----
VTP Operating Mode : Server
Number of existing VLANs : 7
Number of existing extended VLANs : 0
Configuration Revision : 0
Primary ID : 0000.0000.0000
Primary Description :
MD5 digest : 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00

Feature MST:
-----
VTP Operating Mode : Client
Configuration Revision : 0
Primary ID : 0000.0000.0000
Primary Description :
MD5 digest : 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00

Feature UNKNOWN:
-----
```

Related Topics

[clear vtp counters](#), on page 1311

show wireless vlan group

To display the detailed list of VLANs in a VLAN group and the status of the DHCP failed vlans, use the **show wireless vlan group** command in privileged EXEC mode.

```
show wireless vlan group group-name
```

Syntax Description	<i>group-name</i> Name of the wireless VLAN group.				
Command Default	None				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

Usage Guidelines Enter this command in the global configuration mode only.

This example shows how to display the summary of a VLAN group:

```
Device# show wireless vlan group grp1
```

```
Member Vlans Configured
```

```
-----
VLAN      VLAN Name      DHCP Failed
100       VLAN0100       No
101       VLAN0101       Yes
102       VLAN0102       No
103       VLAN0103       No
104       VLAN0104       Yes
105       VLAN0105       No
```

switchport priority extend

To set a port priority for the incoming untagged frames or the priority of frames received by the IP phone connected to the specified port, use the **switchport priority extend** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

switchport priority extend {*cos value* | **trust**}
no switchport priority extend

Syntax Description	cos value	trust
	Sets the IP phone port to override the IEEE 802.1p priority received from the PC or the attached device with the specified class of service (CoS) value. The range is 0 to 7. Seven is the highest priority. The default is 0.	Sets the IP phone port to trust the IEEE 802.1p priority received from the PC or the attached device.

Command Default The default port priority is set to a CoS value of 0 for untagged frames received on the port.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

When voice VLAN is enabled, you can configure the device to send the Cisco Discovery Protocol (CDP) packets to instruct the IP phone how to send data packets from the device attached to the access port on the Cisco IP Phone. You must enable CDP on the device port connected to the Cisco IP Phone to send the configuration to the Cisco IP Phone. (CDP is enabled by default globally and on all device interfaces.)

You should configure voice VLAN on device access ports. You can configure a voice VLAN only on Layer 2 ports.

Before you enable voice VLAN, we recommend that you enable quality of service (QoS) on the interface by entering the **trust device cisco-phone** interface configuration command. If you use the auto QoS feature, these settings are automatically configured.

This example shows how to configure the IP phone connected to the specified port to trust the received IEEE 802.1p priority:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# switchport priority extend trust
```

You can verify your settings by entering the **show interfaces interface-id switchport** privileged EXEC command.

switchport trunk

To set the trunk characteristics when the interface is in trunking mode, use the **switchport trunk** command in interface configuration mode. To reset a trunking characteristic to the default, use the **no** form of this command.

```
switchport trunk {allowed vlan vlan-list | native vlan vlan-id | pruning vlan vlan-list}
no switchport trunk {allowed vlan | native vlan | pruning vlan}
```

Syntax Description	
allowed vlan <i>vlan-list</i>	Sets the list of allowed VLANs that can receive and send traffic on this interface in tagged format when in trunking mode. See the Usage Guidelines for the <i>vlan-list</i> choices.
native vlan <i>vlan-id</i>	Sets the native VLAN for sending and receiving untagged traffic when the interface is in IEEE 802.1Q trunking mode. The range is 1 to 4094.
pruning vlan <i>vlan-list</i>	Sets the list of VLANs that are eligible for VTP pruning when in trunking mode. See the Usage Guidelines for the <i>vlan-list</i> choices.

Command Default VLAN 1 is the default native VLAN ID on the port.
The default for all VLAN lists is to include all VLANs.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines The *vlan-list* format is **all** | **none** | [**add** | **remove** | **except**] *vlan-atom* [,*vlan-atom*...]:

- **all** specifies all VLANs from 1 to 4094. This is the default. This keyword is not allowed on commands that do not permit all VLANs in the list to be set at the same time.
- **none** specifies an empty list. This keyword is not allowed on commands that require certain VLANs to be set or at least one VLAN to be set.
- **add** adds the defined list of VLANs to those currently set instead of replacing the list. Valid IDs are from 1 to 1005; extended-range VLANs (VLAN IDs greater than 1005) are valid in some cases.



Note You can add extended-range VLANs to the allowed VLAN list, but not to the pruning-eligible VLAN list.

Separate nonconsecutive VLAN IDs with a comma; use a hyphen to designate a range of IDs.

- **remove** removes the defined list of VLANs from those currently set instead of replacing the list. Valid IDs are from 1 to 1005; extended-range VLAN IDs are valid in some cases.



Note You can remove extended-range VLANs from the allowed VLAN list, but you cannot remove them from the pruning-eligible list.

- **except** lists the VLANs that should be calculated by inverting the defined list of VLANs. (VLANs are added except the ones specified.) Valid IDs are from 1 to 1005. Separate nonconsecutive VLAN IDs with a comma; use a hyphen to designate a range of IDs.
- *vlan-atom* is either a single VLAN number from 1 to 4094 or a continuous range of VLANs described by two VLAN numbers, the lesser one first, separated by a hyphen.

Native VLANs:

- All untagged traffic received on an IEEE 802.1Q trunk port is forwarded with the native VLAN configured for the port.
- If a packet has a VLAN ID that is the same as the sending-port native VLAN ID, the packet is sent without a tag; otherwise, the switch sends the packet with a tag.
- The **no** form of the **native vlan** command resets the native mode VLAN to the appropriate default VLAN for the device.

Allowed VLAN:

- To reduce the risk of spanning-tree loops or storms, you can disable VLAN 1 on any individual VLAN trunk port by removing VLAN 1 from the allowed list. When you remove VLAN 1 from a trunk port, the interface continues to send and receive management traffic, for example, Cisco Discovery Protocol (CDP), Port Aggregation Protocol (PAgP), Link Aggregation Control Protocol (LACP), Dynamic Trunking Protocol (DTP), and VLAN Trunking Protocol (VTP) in VLAN 1.
- The **no** form of the **allowed vlan** command resets the list to the default list, which allows all VLANs.

Trunk pruning:

- The pruning-eligible list applies only to trunk ports.
- Each trunk port has its own eligibility list.
- If you do not want a VLAN to be pruned, remove it from the pruning-eligible list. VLANs that are pruning-ineligible receive flooded traffic.
- VLAN 1, VLANs 1002 to 1005, and extended-range VLANs (VLANs 1006 to 4094) cannot be pruned.

This example shows how to configure VLAN 3 as the default for the port to send all untagged traffic:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# switchport trunk native vlan 3
```

This example shows how to add VLANs 1, 2, 5, and 6 to the allowed list:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# switchport trunk allowed vlan add 1,2,5,6
```

This example shows how to remove VLANs 3 and 10 to 15 from the pruning-eligible list:

```
Device(config)# interface gigabitethernet1/0/2  
Device(config-if)# switchport trunk pruning vlan remove 3,10-15
```

You can verify your settings by entering the **show interfaces** *interface-id* **switchport** privileged EXEC command.

Related Topics

[show interfaces](#), on page 183

[switchport mode](#)

vlan

To add a VLAN and to enter the VLAN configuration mode, use the **vlan** command in global configuration mode. To delete the VLAN, use the **no** form of this command.

vlan *vlan-id*
no vlan *vlan-id*

Syntax Description	<i>vlan-id</i>	ID of the VLAN to be added and configured. The range is 1 to 4094. You can enter a single VLAN ID, a series of VLAN IDs separated by commas, or a range of VLAN IDs separated by hyphens.
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

You can use the **vlan** *vlan-id* global configuration command to add normal-range VLANs (VLAN IDs 1 to 1005) or extended-range VLANs (VLAN IDs 1006 to 4094). Configuration information for normal-range VLANs is always saved in the VLAN database, and you can display this information by entering the **show vlan** privileged EXEC command. If the VTP mode is transparent, VLAN configuration information for normal-range VLANs is also saved in the device running configuration file. VLAN IDs in the extended range are not saved in the VLAN database, but they are stored in the switch running configuration file, and you can save the configuration in the startup configuration file.

VTP version 3 supports propagation of extended-range VLANs. VTP versions 1 and 2 propagate only VLANs 1 to 1005.

When you save the VLAN and VTP configurations in the startup configuration file and reboot the device, the configuration is selected as follows:

- If the VTP mode is transparent in the startup configuration and the VLAN database and the VTP domain name from the VLAN database matches that in the startup configuration file, the VLAN database is ignored (cleared), and the VTP and VLAN configurations in the startup configuration file are used. The VLAN database revision number remains unchanged in the VLAN database.
- If the VTP mode or domain name in the startup configuration do not match the VLAN database, the domain name and VTP mode and configuration for VLAN IDs 1 to 1005 use the VLAN database information.

If you enter an invalid VLAN ID, you receive an error message and do not enter VLAN configuration mode.

Entering the **vlan** command with a VLAN ID enables VLAN configuration mode. When you enter the VLAN ID of an existing VLAN, you do not create a new VLAN, but you can modify VLAN parameters for that

VLAN. The specified VLANs are added or modified when you exit the VLAN configuration mode. Only the **shutdown** command (for VLANs 1 to 1005) takes effect immediately.



Note Although all commands are visible, the only VLAN configuration command that is supported on extended-range VLANs is **remote-span**. For extended-range VLANs, all other characteristics must remain at the default state.

These configuration commands are available in VLAN configuration mode. The **no** form of each command returns the characteristic to its default state:

- **are** *are-number*—Defines the maximum number of all-routes explorer (ARE) hops for this VLAN. This keyword applies only to TrCRF VLANs. The range is 0 to 13. The default is 7. If no value is entered, 0 is assumed to be the maximum.
- **backuperf**—Specifies the backup CRF mode. This keyword applies only to TrCRF VLANs.
 - **enable**—Backup CRF mode for this VLAN.
 - **disable**—Backup CRF mode for this VLAN (the default).
- **bridge** {*bridge-number* | **type**}—Specifies the logical distributed source-routing bridge, the bridge that interconnects all logical rings that have this VLAN as a parent VLAN in FDDI-NET, Token Ring-NET, and TrBRF VLANs. The range is 0 to 15. The default bridge number is 0 (no source-routing bridge) for FDDI-NET, TrBRF, and Token Ring-NET VLANs. The **type** keyword applies only to TrCRF VLANs and is one of these:
 - **srb**—Source-route bridging
 - **srt**—Source-route transparent) bridging VLAN
- **exit**—Applies changes, increments the VLAN database revision number (VLANs 1 to 1005 only), and exits VLAN configuration mode.
- **media**—Defines the VLAN media type and is one of these:



Note The device supports only Ethernet ports. You configure only FDDI and Token Ring media-specific characteristics for VLAN Trunking Protocol (VTP) global advertisements to other devices. These VLANs are locally suspended.

- **ethernet**—Ethernet media type (the default).
- **fd-net**—FDDI network entity title (NET) media type.
- **fdi**—FDDI media type.
- **tokenring**—Token Ring media type if the VTP v2 mode is disabled, or TrCRF if the VTP Version 2 (v) mode is enabled.
- **tr-net**—Token Ring network entity title (NET) media type if the VTP v2 mode is disabled or TrBRF media type if the VTP v2 mode is enabled.

See the table that follows for valid commands and syntax for different media types.

- **name** *vlan-name*—Names the VLAN with an ASCII string from 1 to 32 characters that must be unique within the administrative domain. The default is VLANxxxx where xxxx represents four numeric digits (including leading zeros) equal to the VLAN ID number.
- **no**—Negates a command or returns it to the default setting.
- **parent** *parent-vlan-id*—Specifies the parent VLAN of an existing FDDI, Token Ring, or TrCRF VLAN. This parameter identifies the TrBRF to which a TrCRF belongs and is required when defining a TrCRF. The range is 0 to 1005. The default parent VLAN ID is 0 (no parent VLAN) for FDDI and Token Ring VLANs. For both Token Ring and TrCRF VLANs, the parent VLAN ID must already exist in the database and be associated with a Token Ring-NET or TrBRF VLAN.
- **remote-span**—Configures the VLAN as a Remote SPAN (RSPAN) VLAN. When the RSPAN feature is added to an existing VLAN, the VLAN is first deleted and is then recreated with the RSPAN feature. Any access ports are deactivated until the RSPAN feature is removed. If VTP is enabled, the new RSPAN VLAN is propagated by VTP for VLAN IDs that are lower than 1024. Learning is disabled on the VLAN.



Note The RSPAN feature is supported only on switches running the LAN Base image.

- **ring** *ring-number*—Defines the logical ring for an FDDI, Token Ring, or TrCRF VLAN. The range is 1 to 4095. The default for Token Ring VLANs is 0. For FDDI VLANs, there is no default.
- **said** *said-value*—Specifies the security association identifier (SAID) as documented in IEEE 802.10. The range is 1 to 4294967294, and the number must be unique within the administrative domain. The default value is 100000 plus the VLAN ID number.
- **shutdown**—Shuts down VLAN switching on the VLAN. This command takes effect immediately. Other commands take effect when you exit VLAN configuration mode.
- **state**—Specifies the VLAN state:
 - **active** means the VLAN is operational (the default).
 - **suspend** means the VLAN is suspended. Suspended VLANs do not pass packets.
- **ste** *ste-number*—Defines the maximum number of spanning-tree explorer (STE) hops. This keyword applies only to TrCRF VLANs. The range is 0 to 13. The default is 7.
- **stp type**—Defines the spanning-tree type for FDDI-NET, Token Ring-NET, or TrBRF VLANs. For FDDI-NET VLANs, the default STP type is *ieee*. For Token Ring-NET VLANs, the default STP type is *ibm*. For FDDI and Token Ring VLANs, the default is no type specified.
 - **ieee**—IEEE Ethernet STP running source-route transparent (SRT) bridging.
 - **ibm**—IBM STP running source-route bridging (SRB).
 - **auto**—STP running a combination of source-route transparent bridging (IEEE) and source-route bridging (IBM).
- **tb-vlan1** *tb-vlan1-id* and **tb-vlan2** *tb-vlan2-id*—Specifies the first and second VLAN to which this VLAN is translationally bridged. Translational VLANs translate FDDI or Token Ring to Ethernet, for example. The range is 0 to 1005. If no value is specified, 0 (no transitional bridging) is assumed.

Table 52: Valid Commands and Syntax for Different Media Types

Media Type	Valid Syntax
Ethernet	name <i>vlan-name</i> , media ethernet , state {suspend active}, said <i>said-value</i> , remote-span , tb-vlan1 <i>tb-vlan1-id</i> , tb-vlan2 <i>tb-vlan2-id</i>
FDDI	name <i>vlan-name</i> , media fddi , state {suspend active}, said <i>said-value</i> , ring <i>ring-number</i> , parent <i>parent-vlan-id</i> , tb-vlan1 <i>tb-vlan1-id</i> , tb-vlan2 <i>tb-vlan2-id</i>
FDDI-NET	name <i>vlan-name</i> , media fd-net , state {suspend active}, said <i>said-value</i> , bridge <i>bridge-number</i> , stp type {ieee ibm auto}, tb-vlan1 <i>tb-vlan1-id</i> , tb-vlan2 <i>tb-vlan2-id</i> If VTP v2 mode is disabled, do not set the stp type to auto .
Token Ring	VTP v1 mode is enabled. name <i>vlan-name</i> , media tokenring , state {suspend active}, said <i>said-value</i> , ring <i>ring-number</i> , parent <i>parent-vlan-id</i> , tb-vlan1 <i>tb-vlan1-id</i> , tb-vlan2 <i>tb-vlan2-id</i>
Token Ring concentrator relay function (TrCRF)	VTP v2 mode is enabled. name <i>vlan-name</i> , media tokenring , state {suspend active}, said <i>said-value</i> , ring <i>ring-number</i> , parent <i>parent-vlan-id</i> , bridge type {srb srt}, are <i>are-number</i> , ste <i>ste-number</i> , backupcrf {enable disable}, tb-vlan1 <i>tb-vlan1-id</i> , tb-vlan2 <i>tb-vlan2-id</i>
Token Ring-NET	VTP v1 mode is enabled. name <i>vlan-name</i> , media tr-net , state {suspend active}, said <i>said-value</i> , bridge <i>bridge-number</i> , stp type {ieee ibm}, tb-vlan1 <i>tb-vlan1-id</i> , tb-vlan2 <i>tb-vlan2-id</i>
Token Ring bridge relay function (TrBRF)	VTP v2 mode is enabled. name <i>vlan-name</i> , media tr-net , state {suspend active}, said <i>said-value</i> , bridge <i>bridge-number</i> , stp type {ieee ibm auto}, tb-vlan1 <i>tb-vlan1-id</i> , tb-vlan2 <i>tb-vlan2-id</i>

The following table describes the rules for configuring VLANs:

Table 53: VLAN Configuration Rules

Configuration	Rule
VTP v2 mode is enabled, and you are configuring a TrCRF VLAN media type.	Specify a parent VLAN ID of a TrBRF that already exists in the database. Specify a ring number. Do not leave this field blank. Specify unique ring numbers when TrCRF VLANs have the same parent VLAN ID. Only one backup concentrator relay function (CRF) can be enabled.
VTP v2 mode is enabled, and you are configuring VLANs other than TrCRF media type.	Do not specify a backup CRF.
VTP v2 mode is enabled, and you are configuring a TrBRF VLAN media type.	Specify a bridge number. Do not leave this field blank.
VTP v1 mode is enabled.	No VLAN can have an STP type set to auto. This rule applies to Ethernet, FDDI, FDDI-NET, Token Ring, and Token Ring-NET VLANs.
Add a VLAN that requires translational bridging (values are not set to zero).	The translational bridging VLAN IDs that are used must already exist in the database. The translational bridging VLAN IDs that a configuration points to must also contain a pointer to the original VLAN in one of the translational bridging parameters (for example, Ethernet points to FDDI, and FDDI points to Ethernet). The translational bridging VLAN IDs that a configuration points to must be different media types than the original VLAN (for example, Ethernet can point to Token Ring). If both translational bridging VLAN IDs are configured, these VLANs must be different media types (for example, Ethernet can point to FDDI and Token Ring).

This example shows how to add an Ethernet VLAN with default media characteristics. The default includes a *vlan-name* of VLAN *xxxx*, where *xxxx* represents four numeric digits (including leading zeros) equal to the VLAN ID number. The default media is ethernet; the state is active. The default *said-value* is 100000 plus the VLAN ID; the *mtu-size* variable is 1500; the *stp-type* is ieee. When you enter the **exit** VLAN configuration command, the VLAN is added if it did not already exist; otherwise, this command does nothing.

This example shows how to create a new VLAN with all default characteristics and enter VLAN configuration mode:

```
Device(config)# vlan 200
Device(config-vlan)# exit
Device(config)#
```

This example shows how to create a new extended-range VLAN with all the default characteristics, to enter VLAN configuration mode, and to save the new VLAN in the device startup configuration file:

```
Device(config)# vlan 2000  
Device(config-vlan)# end  
Device# copy running-config startup config
```

This example shows how to create a VLAN group.

```
Device(config)# vlan group xyz vlan-list 50-60
```

This example shows how to remove a VLAN group.

```
Device(config)# no vlan group xyz vlan-list 50-60
```

This example shows how to remove a single VLAN from the VLAN group.

```
Device(config)# no vlan group xyz vlan-list 51
```

This example shows how to remove multiple VLANs from the VLAN group.

```
Device(config)# no vlan group xyz vlan-list 52-55
```

This example shows how to remove both single and multiple VLANs from the VLAN group.

```
Device(config)# no vlan group xyz vlan-list 56, 58-60
```

You can verify your setting by entering the **show vlan** privileged EXEC command.

Related Topics

[show vlan](#), on page 1322

vlan dot1q tag native

To enable tagging of native VLAN frames on all IEEE 802.1Q trunk ports, use the **vlan dot1q tag native** command in global configuration mode. To return to the default setting, use the **no** form of this command.

```
vlan dot1q tag native
no vlan dot1q tag native
```



Note This command is not supported on devices running the LAN Base image.

Syntax Description This command has no arguments or keywords.

Command Default The IEEE 802.1Q native VLAN tagging is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines When enabled, native VLAN packets going out of all IEEE 802.1Q trunk ports are tagged. When disabled, native VLAN packets going out of all IEEE 802.1Q trunk ports are not tagged. For more information about IEEE 802.1Q tunneling, see the software configuration guide for this release.

This example shows how to enable IEEE 802.1Q tagging on native VLAN frames:

```
Device# configure terminal
Device (config)# vlan dot1q tag native
Device (config)# end
```

You can verify your settings by entering the **show vlan dot1q tag native** privileged EXEC command.

Related Topics

[show vlan](#), on page 1322

vtp (global configuration)

To set or modify the VLAN Trunking Protocol (VTP) configuration characteristics, use the **vtp** command in global configuration mode. To remove the settings or to return to the default settings, use the **no** form of this command.

vtp {**domain** *domain-name* | **file** *filename* | **interface** *interface-name* [**only**] | **mode** {**client** | **off** | **server** | **transparent**} [{**mst** | **unknown** | **vlan**}] | **password** *password* [{**hidden** | **secret**}] | **pruning** | **version** *number*}

no vtp {**file** | **interface** | **mode** [{**client** | **off** | **server** | **transparent**}] [{**mst** | **unknown** | **vlan**}] | **password** | **pruning** | **version**}

Syntax Description		
domain <i>domain-name</i>	Specifies the VTP domain name, an ASCII string from 1 to 32 characters that identifies the VTP administrative domain for the device. The domain name is case sensitive.	
file <i>filename</i>	Specifies the Cisco IOS file system file where the VTP VLAN configuration is stored.	
interface <i>interface-name</i>	Specifies the name of the interface providing the VTP ID updated for this device.	
only	(Optional) Uses only the IP address of this interface as the VTP IP updater.	
mode	Specifies the VTP device mode as client, server, or transparent.	
client	Places the device in VTP client mode. A device in VTP client mode is enabled for VTP, and can send advertisements, but does not have enough nonvolatile storage to store VLAN configurations. You cannot configure VLANs on a VTP client. VLANs are configured on another device in the domain that is in server mode. When a VTP client starts up, it does not send VTP advertisements until it receives advertisements to initialize its VLAN database.	
off	Places the device in VTP off mode. A device in VTP off mode functions the same as a VTP transparent device except that it does not forward VTP advertisements on trunk ports.	
server	Places the device in VTP server mode. A device in VTP server mode is enabled for VTP and sends advertisements. You can configure VLANs on the device. The device can recover all the VLAN information in the current VTP database from nonvolatile storage after reboot.	
transparent	Places the device in VTP transparent mode. A device in VTP transparent mode is disabled for VTP, does not send advertisements or learn from advertisements sent by other devices, and cannot affect VLAN configurations on other devices in the network. The device receives VTP advertisements and forwards them on all trunk ports except the one on which the advertisement was received. When VTP mode is transparent, the mode and domain name are saved in the device running configuration file, and you can save them in the device startup configuration file by entering the copy running-config startup config privileged EXEC command.	
mst	(Optional) Sets the mode for the multiple spanning tree (MST) VTP database (only VTP Version 3).	

unknown	(Optional) Sets the mode for unknown VTP databases (only VTP Version 3).
vlan	(Optional) Sets the mode for VLAN VTP databases. This is the default (only VTP Version 3).
password <i>password</i>	Sets the administrative domain password for the generation of the 16-byte secret value used in MD5 digest calculation to be sent in VTP advertisements and to validate received VTP advertisements. The password can be an ASCII string from 1 to 32 characters. The password is case sensitive.
hidden	(Optional) Specifies that the key generated from the password string is saved in the VLAN database file. When the hidden keyword is not specified, the password string is saved in clear text. When the hidden password is entered, you need to reenter the password to issue a command in the domain. This keyword is supported only in VTP Version 3.
secret	(Optional) Allows the user to directly configure the password secret key (only VTP Version 3).
pruning	Enables VTP pruning on the device.
version <i>number</i>	Sets the VTP Version to Version 1, Version 2, or Version 3.

Command Default

The default filename is *flash:vlan.dat*.

The default mode is server mode and the default database is VLAN.

In VTP Version 3, for the MST database, the default mode is transparent.

No domain name or password is defined.

No password is configured.

Pruning is disabled.

The default version is Version 1.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

When you save VTP mode, domain name, and VLAN configurations in the device startup configuration file and reboot the device, the VTP and VLAN configurations are selected by these conditions:

- If the VTP mode is transparent in the startup configuration and the VLAN database and the VTP domain name from the VLAN database matches that in the startup configuration file, the VLAN database is ignored (cleared), and the VTP and VLAN configurations in the startup configuration file are used. The VLAN database revision number remains unchanged in the VLAN database.
- If the VTP mode or domain name in the startup configuration do not match the VLAN database, the domain name and VTP mode and configuration for VLAN IDs 1 to 1005 use the VLAN database information.

The **vtp file** *filename* cannot be used to load a new database; it renames only the file in which the existing database is stored.

Follow these guidelines when configuring a VTP domain name:

- The device is in the no-management-domain state until you configure a domain name. While in the no-management-domain state, the device does not send any VTP advertisements even if changes occur to the local VLAN configuration. The device leaves the no-management-domain state after it receives the first VTP summary packet on any port that is trunking or after you configure a domain name by using the **vtp domain** command. If the device receives its domain from a summary packet, it resets its configuration revision number to 0. After the device leaves the no-management-domain state, it cannot be configured to reenter it until you clear the NVRAM and reload the software.
- Domain names are case-sensitive.
- After you configure a domain name, it cannot be removed. You can only reassign it to a different domain.

Follow these guidelines when setting VTP mode:

- The **no vtp mode** command returns the device to VTP server mode.
- The **vtp mode server** command is the same as **no vtp mode** except that it does not return an error if the device is not in client or transparent mode.
- If the receiving device is in client mode, the client device changes its configuration to duplicate the configuration of the server. If you have devices in client mode, be sure to make all VTP or VLAN configuration changes on a device in server mode, as it has a higher VTP configuration revision number. If the receiving device is in transparent mode, the device configuration is not changed.
- A device in transparent mode does not participate in VTP. If you make VTP or VLAN configuration changes on a device in transparent mode, the changes are not propagated to other devices in the network.
- If you change the VTP or VLAN configuration on a device that is in server mode, that change is propagated to all the devices in the same VTP domain.
- The **vtp mode transparent** command disables VTP from the domain but does not remove the domain from the device.
- In VTP Versions 1 and 2, the VTP mode must be transparent for VTP and VLAN information to be saved in the running configuration file.
- With VTP Versions 1 and 2, you cannot change the VTP mode to client or server if extended-range VLANs are configured on the switch. Changing the VTP mode is allowed with extended VLANs in VTP Version 3.
- The VTP mode must be transparent for you to add extended-range VLANs or for VTP and VLAN information to be saved in the running configuration file.
- VTP can be set to either server or client mode only when dynamic VLAN creation is disabled.
- The **vtp mode off** command sets the device to off. The **no vtp mode off** command resets the device to the VTP server mode.

Follow these guidelines when setting a VTP password:

- Passwords are case sensitive. Passwords should match on all devices in the same domain.
- When you use the **no vtp password** form of the command, the device returns to the no-password state.

- The **hidden** and **secret** keywords are supported only in VTP Version 3. If you convert from VTP Version 2 to VTP Version 3, you must remove the hidden or secret keyword before the conversion.

Follow these guidelines when setting VTP pruning:

- VTP pruning removes information about each pruning-eligible VLAN from VTP updates if there are no stations belonging to that VLAN.
- If you enable pruning on the VTP server, it is enabled for the entire management domain for VLAN IDs 1 to 1005.
- Only VLANs in the pruning-eligible list can be pruned.
- Pruning is supported with VTP Version 1 and Version 2.

Follow these guidelines when setting the VTP version:

- Toggling the Version 2 (v2) mode state modifies parameters of certain default VLANs.
- Each VTP device automatically detects the capabilities of all the other VTP devices. To use Version 2, all VTP devices in the network must support Version 2; otherwise, you must configure them to operate in VTP Version 1 mode.
- If all devices in a domain are VTP Version 2-capable, you only need to configure Version 2 on one device; the version number is then propagated to the other Version-2 capable devices in the VTP domain.
- If you are using VTP in a Token Ring environment, VTP Version 2 must be enabled.
- If you are configuring a Token Ring bridge relay function (TrBRF) or Token Ring concentrator relay function (TrCRF) VLAN media type, you must use Version 2.
- If you are configuring a Token Ring or Token Ring-NET VLAN media type, you must use Version 1.
- In VTP Version 3, all database VTP information is propagated across the VTP domain, not only VLAN database information.
- Two VTP Version 3 regions can only communicate over a VTP Version 1 or VTP Version 2 region in transparent mode.

You cannot save password, pruning, and version configurations in the device configuration file.

This example shows how to rename the filename for VTP configuration storage to vtpfilename:

```
Device(config)# vtp file vtpfilename
```

This example shows how to clear the device storage filename:

```
Device(config)# no vtp file vtpconfig
Clearing device storage filename.
```

This example shows how to specify the name of the interface providing the VTP updater ID for this device:

```
Device(config)# vtp interface gigabitethernet
```

This example shows how to set the administrative domain for the device:

```
Device(config)# vtp domain OurDomainName
```

This example shows how to place the device in VTP transparent mode:

```
Device(config)# vtp mode transparent
```

This example shows how to configure the VTP domain password:

```
Device(config)# vtp password ThisIsOurDomainsPassword
```

This example shows how to enable pruning in the VLAN database:

```
Device(config)# vtp pruning  
Pruning switched ON
```

This example shows how to enable Version 2 mode in the VLAN database:

```
Device(config)# vtp version 2
```

You can verify your settings by entering the **show vtp status** privileged EXEC command.

Related Topics

[show vtp](#), on page 1325

[vtp \(interface configuration\)](#), on page 1348

vtp (interface configuration)

To enable the VLAN Trunking Protocol (VTP) on a per-port basis, use the **vtp** command in interface configuration mode. To disable VTP on the interface, use the **no** form of this command.

vtp
no vtp

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines Enter this command only on interfaces that are in trunking mode.
This command is supported only when the device is running VTP Version 3.

This example shows how to enable VTP on an interface:

```
Device(config-if)# vtp
```

This example shows how to disable VTP on an interface:

```
Device(config-if)# no vtp
```

Related Topics

[switchport trunk](#), on page 1333

[vtp \(global configuration\)](#), on page 1343

vtp primary

To configure a device as the VLAN Trunking Protocol (VTP) primary server, use the **vtp primary** command in privileged EXEC mode.

```
vtp primary [{mst | vlan}] [force]
```

Syntax Description	Parameter	Description
	mst	(Optional) Configures the device as the primary VTP server for the multiple spanning tree (MST) feature.
	vlan	(Optional) Configures the device as the primary VTP server for VLANs.
	force	(Optional) Configures the device to not check for conflicting devices when configuring the primary server.

Command Default The device is a VTP secondary server.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines A VTP primary server updates the database information and sends updates that are honored by all devices in the system. A VTP secondary server can only back up the updated VTP configurations received from the primary server to NVRAM.

By default, all devices come up as secondary servers. Primary server status is needed only for database updates when the administrator issues a takeover message in the domain. You can have a working VTP domain without any primary servers.

Primary server status is lost if the device reloads or domain parameters change.



Note This command is supported only when the device is running VTP Version 3.

This example shows how to configure the device as the primary VTP server for VLANs:

```
Device# vtp primary vlan
Setting device to VTP TRANSPARENT mode.
```

You can verify your settings by entering the **show vtp status** privileged EXEC command.

Related Topics

[show vtp](#), on page 1325

[vtp \(global configuration\)](#), on page 1343

wireless broadcast vlan

To enable broadcast support on a VLAN, use the **wireless broadcast vlan** command in global configuration mode. To disable Ethernet broadcast support, use the **no** form of the command.

wireless broadcast vlan [*vlan-id*]
no wireless broadcast vlan [*vlan-id*]

Syntax Description	<i>vlan-id</i> (Optional) Specifies the VLAN ID to enable broadcast support to that VLAN. The value ranges from 1 to 4095.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE

Usage Guidelines	Use this command in the global configuration mode only.
-------------------------	---

This example shows how to enable broadcasting on VLAN 20:

```
Device(config)# wireless broadcast vlan 20
```



PART XVIII

WLAN

- [WLAN Commands, on page 1353](#)



WLAN Commands

- [aaa-override](#), on page 1355
- [accounting-list](#), on page 1356
- [band-select](#), on page 1357
- [broadcast-ssid](#), on page 1358
- [call-snoop](#), on page 1359
- [channel-scan defer-priority](#), on page 1360
- [channel-scan defer-time](#), on page 1361
- [chd](#), on page 1362
- [client association limit](#), on page 1363
- [client vlan](#), on page 1365
- [ccx aironet-iesupport](#), on page 1366
- [datalink flow monitor](#), on page 1367
- [device-classification](#), on page 1368
- [default](#), on page 1369
- [dtim dot11](#), on page 1372
- [exclusionlist](#), on page 1373
- [exit](#), on page 1374
- [exit \(WLAN AP Group\)](#), on page 1375
- [ip access-group](#), on page 1376
- [ip flow monitor](#), on page 1377
- [ip verify source mac-check](#), on page 1378
- [load-balance](#), on page 1379
- [mobility anchor](#), on page 1380
- [nac](#), on page 1382
- [passive-client](#), on page 1383
- [peer-blocking](#), on page 1384
- [radio](#), on page 1385
- [radio-policy](#), on page 1386
- [roamed-voice-client re-anchor](#), on page 1387
- [security web-auth](#), on page 1388
- [service-policy \(WLAN\)](#), on page 1389
- [session-timeout](#), on page 1390
- [show wlan](#), on page 1391

- [show wireless wlan summary](#), on page 1394
- [shutdown](#), on page 1395
- [sip-cac](#), on page 1396
- [static-ip tunneling](#), on page 1397
- [vlan](#), on page 1398
- [universal-admin](#), on page 1399
- [wgb non-cisco](#), on page 1400
- [wlan \(AP Group Configuration\)](#), on page 1401
- [wlan](#), on page 1402
- [wlan shutdown](#), on page 1403
- [wmm](#), on page 1404

aaa-override

To enable AAA override on the WLAN, use the **aaa-override** command. To disable AAA override, use the **no** form of this command.

aaa-override
no aaa-override

Syntax Description This command has no keywords or arguments.

Command Default AAA is disabled by default.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to enable AAA on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# shutdown
Device(config-wlan)# aaa-override
Device(config-wlan)# no shutdown
Device(config-wlan)# end
```

This example shows how to disable AAA on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# shutdown
Device(config-wlan)# no aaa-override
Device(config-wlan)# no shutdown
Device(config-wlan)# end
```

Related Topics

[wlan](#), on page 1402

accounting-list

To configure RADIUS accounting servers on a WLAN, use the **accounting-list** command. To disable RADIUS server accounting, use the **no** form of this command.

accounting-list *radius-server-acct*
no accounting-list

Syntax Description	<i>radius-server-acct</i> Accounting RADIUS server name.
---------------------------	--

Command Default	RADIUS server accounting is disabled by default.
------------------------	--

Command Modes	WLAN configuration
----------------------	--------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines	You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.
-------------------------	--

This example shows how to configure RADIUS server accounting on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# accounting-list test
Device(config-wlan)# end
```

This example shows how to disable RADIUS server accounting on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no accounting-list test
Device(config-wlan)# end
```

Related Topics

[wlan](#), on page 1402

band-select

To configure band selection on a WLAN, use the **band-select** command. To disable band selection, use the **no** form of this command.

band-select
no band-select

Syntax Description This command has no keywords or arguments.

Command Default Band selection is disabled by default.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines When you enable band select on a WLAN, the access point suppresses client probes on 2.4GHz and moves the dual band clients to the 5-GHz spectrum. The band-selection algorithm directs dual-band clients only from the 2.4-GHz radio to the 5-GHz radio of the same access point, and it only runs on an access point when both the 2.4-GHz and 5-GHz radios are up and running.

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to enable band select on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# band-select
Device(config-wlan)# end
```

This example shows how to disable band selection on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no band-select
Device(config-wlan)# end
```

Related Topics

[wlan](#), on page 1402

broadcast-ssid

To enable a Service Set Identifier (SSID) on a WLAN, use the **broadcast-ssid** command. To disable broadcasting of SSID, use the **no** form of this command.

broadcast-ssid
no broadcast-ssid

Syntax Description This command has no keywords or arguments.

Command Default The SSIDs of WLANs are broadcasted by default.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to enable a broadcast SSID on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# broadcast-ssid
Device(config-wlan)# end
```

This example shows how to disable a broadcast SSID on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no broadcast-ssid
Device(config-wlan)# end
```

Related Topics

[wlan](#), on page 1402

call-snoop

To enable Voice over IP (VoIP) snooping on a WLAN, use the **call-snoop** command. To disable Voice over IP (VoIP), use the **no** form of this command.

call-snoop
no call-snoop

Syntax Description	This command has no keywords or arguments.
Command Default	VoIP snooping is disabled by default.
Command Modes	WLAN configuration
Usage Guidelines	You must disable the WLAN before using this command. See the Related Commands section for more information on how to disable a WLAN.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE

Usage Guidelines The WLAN on which call snooping is configured must be configured with Platinum QoS. You must disable quality of service before using this command. See Related Commands section for more information on configuring QoS service-policy.

This example shows how to enable VoIP on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# call-snoop
Device(config-wlan)# end
```

This example shows how to disable VoIP on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no call-snoop
Device(config-wlan)# end
```

Related Topics

- [service-policy \(WLAN\)](#), on page 864
- [wlan](#), on page 1402

channel-scan defer-priority

To configure the device to defer priority markings for packets that can defer off-channel scanning, use the **channel-scan defer-priority** command. To disable the device to defer priority markings for packets that can defer off-channel scanning, use the **no** form of this command.

channel-scan defer-priority *priority*
no channel-scan defer-priority *priority*

Syntax Description	<i>priority</i> Channel priority value. The range is 0 to 7. The default is 3.				
Command Default	Channel scan defer is enabled.				
Command Modes	WLAN configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to enable channel scan defer priority on a WLAN and set it to a priority value 4:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# channel-scan defer-priority 4
Device(config-wlan)# end
```

This example shows how to disable channel scan defer priority on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no channel-scan defer-priority 4
Device(config-wlan)# end
```

channel-scan defer-time

To assign a channel scan defer time, use the **channel-scan defer-time** command. To disable the channel scan defer time, use the **no** form of this command.

channel-scan defer-time *msecs*
no channel-scan defer-time

Syntax Description	<i>msecs</i> Deferral time in milliseconds. The range is from 0 to 60000. The default is 100.				
Command Default	Channel-scan defer time is enabled.				
Command Modes	WLAN configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				
Usage Guidelines	<p>The time value in milliseconds should match the requirements of the equipment on the WLAN.</p> <p>This example shows how to enable a channel scan on the WLAN and set the scan deferral time to 300 milliseconds:</p> <pre>Device# configure terminal Enter configuration commands, one per line. End with CNTL/Z. Device(config)# wlan wlan1 Device(config-wlan)# channel-scan defer-time 300 Device(config-wlan)# end</pre> <p>This example shows how to disable channel scan defer time on a WLAN:</p> <pre>Device# configure terminal Enter configuration commands, one per line. End with CNTL/Z. Device(config)# wlan wlan1 Device(config-wlan)# no channel-scan defer-time Device(config-wlan)# end</pre>				

chd

To enable coverage hole detection on a WLAN, use the **chd** command. To disable coverage hole detection, use the **no** form of this command.

chd
no chd

Syntax Description This command has no keywords or arguments.

Command Default Coverage hole detection is enabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to enable coverage hole detection on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# chd
Device(config-wlan)# end
```

This example shows how to disable coverage hole detection on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no chd
Device(config-wlan)# end
```

client association limit

To configure the maximum number of client connections on a WLAN, use the **client association limit** command. To disable clients association limit on the WLAN, use the **no** form of this command.

client association limit {*association-limit*}
no client association limit {*association-limit*}

Syntax Description	<i>association-limit</i>	Number of client connections to be accepted. The range is from 0 to 2000. A value of zero (0) indicates no set limit.				
Command Default	The maximum number of client connections is set to 0 (no limit).					
Command Modes	WLAN configuration					
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.	
Release	Modification					
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.					
Usage Guidelines	You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.					

This example shows how to configure a client association limit on a WLAN and configure the client limit to 200:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# shutdown
Device(config-wlan)# client association limit 200
Device(config-wlan)# no shutdown
Device(config-wlan)# end
```

This example shows how to disable a client association limit on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# shutdown
Device(config-wlan)# no client association limit
Device(config-wlan)# no shutdown
Device(config-wlan)# end
```

This example shows how to configure a client association limit per radio on a WLAN and configure the client limit to 200:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# client association limit radio 200
Device(config-wlan)# no shutdown
Device(config-wlan)# end
```

This example shows how to configure a client association limit per AP on a WLAN and configure the client limit to 300::

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# client association limit ap 300
Device(config-wlan)# no shutdown
Device(config-wlan)# end
```

Related Topics

[wlan](#), on page 1402

client vlan

To configure a WLAN interface or an interface group, use the **client vlan** command. To disable the WLAN interface, use the **no** form of this command.

```
client vlan interface-id-name-or-group-name
no client vlan
```

Syntax Description

interface-id-name-or-group-name Interface ID, name, or VLAN group name. The interface ID can also be in digits too.

Command Default

The default interface is configured.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to enable a client VLAN on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# client vlan client-vlan1
Device(config-wlan)# end
```

This example shows how to disable a client VLAN on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no client vlan
Device(config-wlan)# end
```

Related Topics

[wlan](#), on page 1402

ccx aironet-iesupport

To enable Aironet Information Elements (IEs) for a WLAN, use the **ccx aironet-iesupport** command. To disable Aironet Information Elements (IEs), use the **no** form of this command.

ccx aironet-iesupport
no ccx aironet-iesupport

Syntax Description This command has no keywords or arguments.

Command Default Aironet IE support is enabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to enable an Aironet IE for a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# ccx aironet-iesupport
Device(config-wlan)# end
```

This example shows how to disable an Aironet IE on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no ccx aironet-iesupport
Device(config-wlan)# end
```

Related Topics

[wlan](#), on page 1402

datalink flow monitor

To enable NetFlow monitoring in a WLAN, use the **datalink flow monitor** command. To disable NetFlow monitoring, use the **no** form of this command.

```
datalink flow monitor datalink-monitor-name {input | output}
no datalink flow monitor datalink-monitor-name {input | output}
```

Syntax Description	
<i>datalink-monitor-name</i>	Flow monitor name. The datalink monitor name can have up to 31 characters.
input	Specifies the NetFlow monitor for ingress traffic.
output	Specifies the NetFlow monitor for egress traffic.

Command Default None.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to enable NetFlow monitoring on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# datalink flow monitor test output
Device(config-wlan)# end
```

This example shows how to disable NetFlow monitoring on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no datalink flow monitor test output
Device(config-wlan)# end
```

Related Topics

[wlan](#), on page 1402

device-classification

To enable client device classification in a WLAN, use the **device-classification** command. To disable device classification, use the **no** form of this command.

device-classification
no device-classification

Syntax Description	device-classification Enables/Disables Client Device Classification.				
Command Default	None.				
Command Modes	WLAN configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# device-classification
Device(config-wlan)# end
```

default

To set the parameters to their default values, use the **default** command.

default {aaa-override | accounting-list | band-select | broadcast-ssid | call-snoop | ccx | channel-scan | parameters | chd | client | datalink | diag-channel | dtim | exclusionlist | ip | ipv6 | load-balance | local-auth | mac-filtering | media-stream | mfp | mobility | nac | passive-client | peer-blocking | radio | roamed-voice-client | security | service-policy | session-timeout | shutdown | sip-cac | static-ip | uapsd | wgb | wmm }

Syntax Description

aaa-override	Sets the AAA override parameter to its default value.
accounting-list	Sets the accounting parameter and its attributes to their default values.
band-select	Sets the band selection parameter to its default values.
broadcast-ssid	Sets the broadcast Service Set Identifier (SSID) parameter to its default value.
call-snoop	Sets the call snoop parameter to its default value.
ccx	Sets the Cisco client extension (Cisco Aironet IE) parameters and attributes to their default values.
channel-scan	Sets the channel scan parameters and attributes to their default values.
chd	Sets the coverage hold detection parameter to its default value.
client	Sets the client parameters and attributes to their default values.
datalink	Sets the datalink parameters and attributes to their default values.
diag-channel	Sets the diagnostic channel parameters and attributes to their default values.
dtim	Sets the Delivery Traffic Indicator Message (DTIM) parameter to its default value.
exclusionlist	Sets the client exclusion timeout parameter to its default value.
ip	Sets the IP parameters to their default values.
ipv6	Sets the IPv6 parameters and attributes to their default values.
load-balance	Sets the load-balancing parameter to its default value.
local-auth	Sets the Extensible Authentication Protocol (EAP) profile parameters and attributes to their default values.
mac-filtering	Sets the MAC filtering parameters and attributes to their default values.
media-stream	Sets the media stream parameters and attributes to their default values.

mfp	Sets the Management Frame Protection (MPF) parameters and attributes to their default values.
mobility	Sets the mobility parameters and attributes to their default values.
nac	Sets the RADIUS Network Admission Control (NAC) parameter to its default value.
passive-client	Sets the passive client parameter to its default value.
peer-blocking	Sets the peer to peer blocking parameters and attributes to their default values.
radio	Sets the radio policy parameters and attributes to their default values.
roamed-voice-client	Sets the roamed voice client parameters and attributes to their default values.
security	Sets the security policy parameters and attributes to their default values.
service-policy	Sets the WLAN quality of service (QoS) policy parameters and attributes to their default values.
session-timeout	Sets the client session timeout parameter to its default value.
shutdown	Sets the shutdown parameter to its default value.
sip-cac	Sets the Session Initiation Protocol (SIP) Call Admission Control (CAC) parameters and attributes to their default values.
static-ip	Sets the static IP client tunneling parameters and their attributes to their default values.
uapsd	Sets the Wi-Fi Multimedia (WMM) Unscheduled Automatic Power Save Delivery (UAPSD) parameters and attributes to their default values.
wgb	Sets the Workgroup Bridges (WGB) parameter to its default value.
wmm	Sets the WMM parameters and attributes to their default values.

Command Default None.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to set the Cisco Client Extension parameter to its default value:

```
Device(config-wlan)# default ccx aironet-iesupport
```

Related Topics

[wlan](#), on page 1402

dtim dot11

To configure the Delivery Traffic Indicator Message (DTIM) period for a WLAN, use the **dtim dot11** command. To disable DTIM, use the **no** form of this command.

```
dtim dot11 {5ghz | 24ghz} dtim-period
no dtim dot11 {5ghz | 24ghz} dtim-period
```

Syntax Description		
	5ghz	Configures the DTIM period on the 5-GHz band.
	24ghz	Configures the DTIM period on the 2.4-GHz band.
	<i>dtim-period</i>	Value for the DTIM period. The range is from 1 to 255.

Command Default The DTIM period is set to 1.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to enable the DTIM period on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# dtim dot11 24ghz 3
```

This example shows how to disable the DTIM period on a WLAN on the 2.4-GHz band:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no dtim dot11 24ghz 3
```

Related Topics

[wlan](#), on page 1402

exclusionlist

To configure an exclusion list on a wireless LAN, use the **exclusionlist** command. To disable an exclusion list, use the **no** form of this command.

```
exclusionlist [timeout seconds]  
no exclusionlist [timeout]
```

Syntax Description

timeout *seconds* (Optional) Specifies an exclusion list timeout in seconds. The range is from 0 to 2147483647. A value of zero (0) specifies no timeout.

Command Default

The exclusion list is set to 60 seconds.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to configure a client exclusion list for a WLAN:

```
Device# configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
Device(config)# wlan wlan1  
Device(config-wlan)# exclusionlist timeout 345
```

This example shows how to disable a client exclusion list on a WLAN:

```
Device# configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
Device(config)# wlan wlan1  
Device(config-wlan)# no exclusionlist timeout 345
```

exit

To exit the WLAN configuration submode, use the **exit** command.

exit

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to exit the WLAN configuration submode:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# exit
Device(config)#
```

exit (WLAN AP Group)

To exit the WLAN access point group submode, use the **exit** command.

exit

Syntax Description	This command has no keywords or arguments.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	WLAN AP Group configuration
----------------------	-----------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
		This command was introduced.

This example shows how to exit the WLAN AP group submode:

```
Device# configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
Device(config)# ap group test  
Device(config-apgroup)# exit
```

ip access-group

To configure WLAN access control group (ACL), use the **ip access-group** command. To remove a WLAN ACL group, use the **no** form of the command.

```
ip access-group [web] acl-name
no ip access-group [web]
```

Syntax Description	web (Optional) Configures the IPv4 web ACL.				
	acl-name Specify the preauth ACL used for the WLAN with the security type value as webauth.				
Command Default	None				
Command Modes	WLAN configuration				
Usage Guidelines	You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to configure a WLAN ACL:

```
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#wlan wlan1
Device(config-wlan)#ip access-group test-acl
```

This example shows how to configure an IPv4 WLAN web ACL:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# ip access-group web test
Device(config-wlan)#
```

Related Topics

[wlan](#), on page 1402

ip flow monitor

To configure IP NetFlow monitoring, use the **ip flow monitor** command. To remove IP NetFlow monitoring, use the **no** form of this command.

```
ip flow monitor ip-monitor-name {input | output}
no ip flow monitor ip-monitor-name {input | output}
```

Syntax Description

<i>ip-monitor-name</i>	Flow monitor name.
input	Enables a flow monitor for ingress traffic.
output	Enables a flow monitor for egress traffic.

Command Default

None

Command Modes

WLAN configuration

Usage Guidelines

You must disable the WLAN before using this command.

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to configure an IP flow monitor for the ingress traffic:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# ip flow monitor test input
```

This example shows how to disable an IP flow monitor:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no ip flow monitor test input
```

ip verify source mac-check

To enable IPv4 Source Guard (IPSG) on a WLAN, use the **ip verify source mac-check** command. To disable IPSG, use the **no** form of this command.

ip verify source mac-check
no ip verify source mac-check

Syntax Description This command has no keywords or arguments.

Command Default IPSG is disabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use this feature to restrict traffic from a host to a specific interface that is based on the host's IP address. The feature can also be configured to bind the source MAC and IP of a host so that IP spoofing is prevented.

Use this feature to bind the IP and MAC address of a wireless host that is based on information received from DHCP snooping, ARP, and Dataglean. Dataglean is the process of extracting location information such as host hardware address, ports that lead to the host, and so on from DHCP messages as they are forwarded by the DHCP relay agent. If a wireless host tries to send traffic with IP address and MAC address combination that has not been learned by the device, this traffic is dropped in the hardware. IPSG is not supported on DHCP packets. IPSG is not supported for foreign clients in a foreign device.

You must disable the WLAN before using this command.

This example shows how to enable IPSG:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# ip verify source mac-check
```

This example shows how to disable IPSG:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no ip verify source mac-check
```

load-balance

To enable load balancing on a WLAN, use the **load-balance** command. To disable load balancing, use the **no** form of this command.

load-balance
no load-balance

Syntax Description

This command has no keywords or arguments.

Command Default

Load balancing is disabled by default.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	The command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to enable load balancing on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# shutdown
Device(config)# wlan wlan1
Device(config-wlan)# load-balance
Device(config)# no shutdown
Device(config-wlan)# end
```

This example shows how to disable load balancing on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# shutdown
Device(config)# wlan wlan1
Device(config-wlan)# no load-balance
Device(config)# no shutdown
Device(config-wlan)# end
```

Related Topics

[wlan](#), on page 1402

mobility anchor

To configure mobility sticky anchoring, use the **mobility anchor sticky** command. To disable the sticky anchoring, use the **no** form of the command.

To configure guest anchoring, use the **mobility anchor ip-address** command.

To delete the guest anchor, use the **no** form of the command.

To configure the device as an auto-anchor, use the **mobility anchor** command.

mobility anchor {*ip-address* | **sticky**}

no mobility anchor {*ip-address* | **sticky**}

Syntax Description

sticky The client is anchored to the first switch that it associates.

Note This command is by default enabled and ensures low roaming latency. This ensures that the point of presence for the client does not change when the client joins the mobility domain and roams within the domain.

ip-address Configures the IP address for the guest anchor device to this WLAN.

Command Default

Sticky configuration is enabled by default.

Command Modes

WLAN Configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

- The `wlan_id` or `guest_lan_id` must exist and be disabled.
- Auto-anchor mobility is enabled for the WLAN or wired guest LAN when you configure the first mobility anchor.
- Deleting the last anchor disables the auto-anchor mobility feature and resumes normal mobility for new associations.
- Mobility uses the following ports, that are allowed through the firewall:
 - 16666
 - 16667
 - 16668

This example shows how to enable the sticky mobility anchor:

```
Device(config-wlan)# mobility anchor sticky
```

This example shows how to configure guest anchoring:

```
Device(config-wlan)# mobility anchor 209.165.200.224
```

This example shows how to configure the device as an auto-anchor:

```
Device(config-wlan)# mobility anchor
```

nac

To enable RADIUS Network Admission Control (NAC) support for a WLAN, use the **nac** command. To disable NAC out-of-band support, use the **no** form of this command.

nac
no nac

Syntax Description This command has no keywords or arguments.

Command Default NAC is disabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You should enable AAA override before you enable the RADIUS NAC state.

This example shows how to configure RADIUS NAC on the WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# aaa-override
Device(config-wlan)# nac
```

This example shows how to disable RADIUS NAC on the WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no nac
Device(config-wlan)# no aaa-override
```

Related Topics

[aaa-override](#), on page 1355

passive-client

To enable the passive client feature on a WLAN, use the **passive-client** command. To disable the passive client feature, use the **no** form of this command.

passive-client
no passive-client

Syntax Description This command has no keywords or arguments.

Command Default Passive client feature is disabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You must enable the global multicast mode and multicast-multicast mode before entering this command. Both multicast-multicast mode and multicast unicast modes are supported. The multicast-multicast mode is recommended.

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This show how to enable the passive client feature on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wireless multicast
Device(config)# wlan test-wlan
Device(config-wlan)# passive-client
```

This example shows how to disable the passive client feature on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wireless multicast
Device(config)# wlan test-wlan
Device(config-wlan)# no passive-client
```

Related Topics

[wlan](#), on page 1402

peer-blocking

To configure peer-to-peer blocking on a WLAN, use the **peer-blocking** command. To disable peer-to-peer blocking, use the **no** form of this command.

```
peer-blocking {drop | forward-upstream}
no peer-blocking
```

Syntax Description	drop	Specifies the device to discard the packets.
	forward-upstream	Specifies the packets to be forwarded on the upstream VLAN. The device next in the hierarchy to the device decides what action to take regarding the packets.
Command Default	Peer blocking is disabled.	
Command Modes	WLAN configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to enable the drop and forward-upstream options for peer-to-peer blocking:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# peer-blocking drop
Device(config-wlan)# peer-blocking forward-upstream
```

This example shows how to disable the drop and forward-upstream options for peer-to-peer blocking:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no peer-blocking drop
Device(config-wlan)# no peer-blocking forward-upstream
```

Related Topics

[wlan](#), on page 1402

radio

To enable the Cisco radio policy on a WLAN, use the **radio** command. To disable the Cisco radio policy on a WLAN, use the **no** form of this command.

```
radio {all | dot11a | dot11ag | dot11bg | dot11g}
no radio
```

Syntax Description	
all	Configures the WLAN on all radio bands.
dot11a	Configures the WLAN on only 802.11a radio bands.
dot11ag	Configures the WLAN on 802.11a/g radio bands.
dot11bg	Configures the wireless LAN on only 802.11b/g radio bands (only 802.11b if 802.11g is disabled).
dot11g	Configures the wireless LAN on 802.11g radio bands only.

Command Default Radio policy is enabled on all bands.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to configure the WLAN on all radio bands:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# radio all
```

This example shows how to disable all radio bands on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no radio all
```

Related Topics

[wlan](#), on page 1402

radio-policy

To configure the radio policy on a WLAN access point group, use the **radio-policy** command. To disable the radio policy on the WLAN, use the **no** form of this command.

radio-policy {all | dot11a | dot11bg | dot11g}

no radio{all | dot11a | dot11bg | dot11g}

Syntax Description

all	Configures the wireless LAN on all radio bands.
dot11a	Configures the wireless LAN on only 802.11a radio bands.
dot11bg	Configures the wireless LAN on only 802.11b/g (only 802.11b if 802.11g is disabled) radio bands.
dot11g	Configures the wireless LAN on only 802.11g radio bands.

Command Default

Radio policy is enabled on all the bands.

Command Modes

WLAN AP Group configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

The WLAN must be restarted for the changes to take effect. See Related Commands section for more information on how to shutdown a WLAN.

This example shows how to enable the radio policy on the 802.11b band for an AP group:

```
Device(config)# ap group test
Device(config-apgroup)# wlan test-wlan
Device(config-wlan-apgroup)# radio-policy dot11b
```

This example shows how to disable the radio policy on the 802.11b band of an AP group:

```
Device(config)# ap group test
Device(config-apgroup)# wlan test-wlan
Device(config-wlan-apgroup)# no radio-policy dot11bg
```

Related Topics

[wlan](#), on page 1402

[wlan shutdown](#), on page 1403

roamed-voice-client re-anchor

To enable the roamed-voice-client re-anchor feature, use the **roamed-voice-client re-anchor** command. To disable the roamed-voice-client re-anchor feature, use the **no** form of this command.

roamed-voice-client re-anchor
no roamed-voice-client re-anchor

Syntax Description This command has no keywords or arguments.

Command Default Roamed voice client reanchor feature is disabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to enable the roamed voice client re-anchor feature:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# roamed-voice-client re-anchor
```

This example shows how to disable the roamed voice client re-anchor feature:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no roamed-voice-client re-anchor
```

Related Topics

[wlan](#), on page 1402

security web-auth

To change the status of web authentication used on a WLAN, use the **security web-auth** command. To disable web authentication on a WLAN, use the **no** form of the command.

```
security web-auth [{authentication-list authentication-list-name | on-macfilter-failure | parameter-map
parameter-map-name}]
no security web-auth [{authentication-list [authentication-list-name] | on-macfilter-failure |
parameter-map [parameter-name]]}
```

Syntax Description		
authentication-list <i>authentication-list-name</i>	Sets the authentication list for IEEE 802.1x.	
on-macfilter-failure	Enables web authentication on MAC failure.	
parameter-map <i>parameter-map-name</i>	Configures the parameter map.	

Command Default Web authentication is disabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Examples

The following example shows how to configure the authentication-list web authentication on a WLAN:

```
Device(config-wlan)# security web-auth authentication-list test
```

service-policy (WLAN)

To configure the WLAN quality of service (QoS) service policy, use the **service-policy** command. To disable a QoS policy on a WLAN, use the **no** form of this command.

```
service-policy [client] {input | output} policy-name
no service-policy [client] {input | output} policy-name
```

Syntax Description	<p>client (Optional) Assigns a policy map to all clients in the WLAN.</p> <p>input Assigns an input policy map.</p> <p>output Assigns an output policy map.</p> <p><i>policy-name</i> The policy name.</p>				
Command Default	No policies are assigned and the state assigned to the policy is None.				
Command Modes	WLAN configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				
Usage Guidelines	You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.				

Examples

This example shows how to configure the input QoS service policy on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# service-policy input policy-test
```

This example shows how to disable the input QoS service policy on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no service-policy input policy-test
```

This example shows how to configure the output QoS service policy on a WLAN to platinum (precious metal policy):

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# service-policy output platinum
```

Related Topics

[wlan](#), on page 1402

session-timeout

To configure session timeout for clients associated to a WLAN, use the **session-timeout** command. To disable a session timeout for clients that are associated to a WLAN, use the **no** form of this command.

session-timeout seconds
no session-timeout

Syntax Description	<i>seconds</i> Timeout or session duration in seconds. A value of zero (0) is equivalent to no timeout. The range is from 300 to 86400.				
Command Default	The client timeout is set to 1800 seconds for WLANs that are configured with dot1x security. The client timeout is set to 0 for open WLANs.				
Command Modes	WLAN configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>Cisco IOS XE 3.3SE This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.				

This example shows how to configure a session timeout to 300 seconds:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# session-timeout 300
```

This example shows how to disable a session timeout:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no session-timeout
```

show wlan

To view WLAN parameters, use the **show wlan** command.

```
show wlan {all | id wlan-id | name wlan-name | summary}
```

Syntax Description	all	Displays a summary of parameters of all configured WLANs. The list is ordered by the ascending order of the WLAN IDs.
	id <i>wlan-id</i>	Specifies the wireless LAN identifier. The range is from 1 to 512.
	name <i>wlan-name</i>	Specifies the WLAN profile name. The name is from 1 to 32 characters.
	summary	Displays a summary of the parameters configured on a WLAN.
Command Default	None	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to display a summary of the WLANs configured on the device:

```
Device# show wlan summary
Number of WLANs: 1
```

WLAN Profile Name	SSID	VLAN	Status
45 test-wlan	test-wlan-ssid	1	UP

This example shows how to display a summary of parameters configured on a particular WLAN:

```
Device# show wlan name test-wlan
WLAN Identifier           : 45
Profile Name              : test-wlan
Network Name (SSID)      : test-wlan-ssid
Status                    : Enabled
Broadcast SSID           : Enabled
Maximum number of Associated Clients : 0
AAA Policy Override       : Disabled
Network Admission Control
  NAC-State                : Disabled
Number of Active Clients  : 0
Exclusionlist Timeout     : 60
Session Timeout          : 1800 seconds
CHD per WLAN             : Enabled
Webauth DHCP exclusion   : Disabled
Interface                 : default
Interface Status         : Up
```

```

Multicast Interface                : test
WLAN IPv4 ACL                      : test
WLAN IPv6 ACL                      : unconfigured
DHCP Server                        : Default
DHCP Address Assignment Required   : Disabled
DHCP Option 82                    : Disabled
DHCP Option 82 Format               : ap-mac
DHCP Option 82 Ascii Mode          : Disabled
DHCP Option 82 Rid Mode            : Disabled
QoS Service Policy - Input
  Policy Name                       : unknown
  Policy State                       : None
QoS Service Policy - Output
  Policy Name                       : unknown
  Policy State                       : None
QoS Client Service Policy
  Input Policy Name                  : unknown
  Output Policy Name                 : unknown
WifiDirect                         : Disabled
WMM                                 : Disabled
Channel Scan Defer Priority:
  Priority (default)                 : 4
  Priority (default)                 : 5
  Priority (default)                 : 6
Scan Defer Time (msecs)            : 100
Media Stream Multicast-direct       : Disabled
CCX - AironetIe Support             : Enabled
CCX - Gratuitous ProbeResponse (GPR) : Disabled
CCX - Diagnostics Channel Capability : Disabled
Dot11-Phone Mode (7920)            : Invalid
Wired Protocol                     : None
Peer-to-Peer Blocking Action        : Disabled
Radio Policy                        : All
DTIM period for 802.11a radio        : 1
DTIM period for 802.11b radio        : 1
Local EAP Authentication            : Disabled
Mac Filter Authorization list name   : Disabled
Accounting list name                 : Disabled
802.1x authentication list name      : Disabled
Security
  802.11 Authentication              : Open System
  Static WEP Keys                    : Disabled
  802.1X                              : Disabled
  Wi-Fi Protected Access (WPA/WPA2) : Enabled
    WPA (SSN IE)                     : Disabled
    WPA2 (RSN IE)                     : Enabled
    TKIP Cipher                       : Disabled
    AES Cipher                         : Enabled
  Auth Key Management
    802.1x                            : Enabled
    PSK                                : Disabled
    CCKM                               : Disabled
  IP Security                        : Disabled
  IP Security Passthru                : Disabled
  L2TP                                : Disabled
  Web Based Authentication            : Disabled
  Conditional Web Redirect            : Disabled
  Splash-Page Web Redirect            : Disabled
  Auto Anchor                         : Disabled
  Sticky Anchoring                    : Enabled
  Cranite Passthru                    : Disabled
  Fortress Passthru                   : Disabled
  PPTP                                : Disabled
  Infrastructure MFP protection        : Enabled

```

```
Client MFP : Optional
Webauth On-mac-filter Failure : Disabled
Webauth Authentication List Name : Disabled
Webauth Parameter Map : Disabled
Tkip MIC Countermeasure Hold-down Timer : 60
Call Snooping : Disabled
Passive Client : Disabled
Non Cisco WGB : Disabled
Band Select : Disabled
Load Balancing : Disabled
IP Source Guard : Disabled
Netflow Monitor : test
    Direction : Input
    Traffic : Datalink

Mobility Anchor List
IP Address
-----
```

show wireless wlan summary

To display wireless wlan summary, use the **show wireless wlan summary** command.

show wireless wlan summary

Syntax Description	This command has no keywords or arguments.				
Command Default	None				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>15.2(3)E</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	15.2(3)E	This command was introduced.
Release	Modification				
15.2(3)E	This command was introduced.				

The following is a sample output of the **show wireless wlan summary** command.

```
Cisco-Controller# show wireless wlan summary
```

```
Total WLAN Configured: 3
```

```
Total Client Count: 0
```

ID	Profile Name Status	SSID	Security	Radio	VLAN	Client
1	Test1 DOWN	xxx	WPA1/WPA2	All	1	0
2	wlan1 DOWN	wlan2-ssid	WPA1/WPA2	All	1	0
3	wlan3 DOWN	mywlan3	WPA1/WPA2	All	1	0

shutdown

To disable a WLAN, use the **shutdown** command. To enable a WLAN, use the **no** form of this command.

shutdown
no shutdown

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

This example shows how to disable a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan test-wlan
Device(config-wlan)# shutdown
Device(config-wlan)# end
Device# show wlan summary
Number of WLANs: 1
```

WLAN Profile Name	SSID	VLAN	Status
45 test-wlan	test-wlan-ssid	1	DOWN

This example shows how to enable a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan test-wlan
Device(config-wlan)# no shutdown
Device(config-wlan)# end
Device# show wlan summary
Number of WLANs: 1
```

WLAN Profile Name	SSID	VLAN	Status
45 test-wlan	test-wlan-ssid	1	UP

sip-cac

To configure the Session Initiation Protocol (SIP) Call Admission Control (CAC) feature on a WLAN, use the **sip-cac** command. To disable the SIP CAC feature, use the **no** form of this command.

```

sip-cac {disassoc-client | send-486busy}
no sip-cac {disassoc-client | send-486busy}

```

Syntax Description

disassoc-client Enables a client disassociation if a CAC failure occurs.

send-486busy Sends a SIP 486 busy message if a CAC failure occurs.

Command Default

None

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to enable a client disassociation and 486 busy message on a WLAN:

```

Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# sip-cac disassoc-client
Device(config-wlan)# sip-cac send-486busy

```

This example shows how to disable a client association and 486 busy message on a WLAN:

```

Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no sip-cac disassoc-client
Device(config-wlan)# no sip-cac send-486busy

```

Related Topics

[wlan](#), on page 1402

static-ip tunneling

To enable static IP tunneling on a WLAN, use the **static-ip tunneling** command. To disable the static IP tunneling feature, use the **no** form of this command.

static-ip tunneling
no static-ip tunneling

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

This example shows how to enable static-IP tunneling:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# static-ip tunneling
```

This example shows how to disable static-IP tunneling:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no static-ip tunneling
```

vlan

To assign a VLAN to an AP group, use the **vlan** command. To remove a VLAN ID, use the **no** form of this command.

vlan *interface-name*
no vlan

Syntax Description *interface-name* VLAN interface name.

Command Default No VALN is assigned to the AP group. See Related Commands section for more information on how to disable a WLAN.

Command Modes WLAN AP Group configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You must disable the WLAN before using this command.

This example shows how to configure a VLAN on an AP group:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# ap group ap-group-1
Device(config-apgroup)# wlan test-wlan
Device(config-wlan-apgroup)# vlan 3
```

Related Topics

[wlan](#), on page 1402

universal-admin

To configure the WLAN as the universal admin, use the **universal-admin** command. To remove the configuration, use the **no** form of this command.

universal-admin

Command Default

None

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.7.0 E	This command was introduced.

```

Deviceenable
Device#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)#wlan wlan1
Device(config-wlan)#universal-admin
  
```

wgb non-cisco

To enable non-Cisco Workgroup Bridges (WGB) clients on the WLAN, use the **wgb non-cisco** command. To disable support for non-Cisco WGB clients, use the **no** form of this command.

wgb non-cisco
no wgb non-cisco

Syntax Description This command has no keywords or arguments.

Command Default Non-Cisco WGB clients are disabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to enable non-Cisco WGBs on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# shutdown
Device(config-wlan)# wgb non-cisco
Device(config-wlan)# no shutdown
```

This example shows how to disable support for non-Cisco WGB clients on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# shutdown
Device(config-wlan)# no wgb non-cisco
Device(config-wlan)# no shutdown
```

wlan (AP Group Configuration)

To configure WLAN parameters of a WLAN in an access point (AP) group, use the **wlan** command. To remove a WLAN from the AP group, use the **no** form of this command.

wlan *wlan-name*
no wlan *wlan-name*

Syntax Description

wlan-name WLAN profile name. The range is from 1 to 32 alphanumeric characters.

Command Default

WLAN parameters are not configured for an AP group.

Command Modes

AP Group configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to configure WLAN related parameters in the AP group configuration mode:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# ap group test
Device(config-apgroup)# wlan qos-wlan
```

Related Topics

[wlan](#), on page 1402

wlan

To create a wireless LAN, use the **wlan** command. To disable a wireless LAN, use the **no** form of this command.

wlan [{*wlan-name* | *wlan-name wlan-id* | *wlan-name wlan-id wlan-ssid*}]
no wlan [{*wlan-name* | *wlan-name wlan-id* | *wlan-name wlan-id wlan-ssid*}]

Syntax Description

<i>wlan-name</i>	WLAN profile name. The name is from 1 to 32 alphanumeric characters.
<i>wlan-id</i>	Wireless LAN identifier. The range is from 1 to 512.
<i>wlan-ssid</i>	SSID. The range is from 1 to 32 alphanumeric characters.

Command Default

WLAN is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

If you do not specify an SSID, the profile name parameter is used for both the profile name and the SSID. If the management and AP-manager interfaces are mapped to the same port and are members of the same VLAN, you must disable the WLAN before making a port-mapping change to either interface. If the management and AP-manager (Access Point Manager) interfaces are assigned to different VLANs, you do not need to disable the WLAN.

An error message appears if you try to delete a WLAN that is assigned to an access point group. If you proceed, the WLAN is removed from the access point group and from the access point's radio.

This example shows how to create a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config)# wlan test-wlan-cr 67 test-wlan-cr-ssid
```

This example shows how to delete a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config)# no wlan test-wlan-cr 67 test-wlan-cr-ssid
```

wlan shutdown

To disable a WLAN, use the **wlan shutdown** command. To enable a WLAN, use the **no** form of this command.

wlan shutdown
no wlan shutdown

Command Default The WLAN is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to shut down a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# shutdown
```

Related Topics

[wlan](#), on page 1402

wmm

To enable Wi-Fi Multimedia (WMM) on a WLAN, use the **wmm** command. To disable WMM on a WLAN, use the **no** form of this command.

```
wmm {allowed | require}
no wmm
```

Syntax Description

allowed Allows WMM on a WLAN.

require Mandates that clients use WMM on the WLAN.

Command Default

WMM is enabled.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	Cisco IOS XE 3.3SE This command was introduced.

Usage Guidelines

When the device is in Layer 2 mode and WMM is enabled, you must put the access points on a trunk port in order to allow them to join the device.

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

This example shows how to enable WMM on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# wmm allowed
```

This example shows how to disable WMM on a WLAN:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# wlan wlan1
Device(config-wlan)# no wmm
```

Related Topics

[wlan](#), on page 1402



INDEX

A

- aaa-override command [1355](#)
- accounting-list command [1356](#)
- airtime-fairness [926](#)
- ap airtime-fairness policy [934](#)
- ap auth-list ap-policy [474](#)
- ap bridging [475](#)
- ap capwap multicast [476](#)
- ap capwap retransmit [477](#)
- ap capwap timers [478](#)
- ap cdp [480](#)
- ap core-dump [481](#)
- ap country [482](#)
- ap crash-file [483](#)
- ap dot11 2.4 GHz CleanAir alarm device [34](#)
- ap dot11 24ghz [484](#)
- ap dot11 24ghz cleanair [24](#)
- ap dot11 24ghz cleanair command [22, 23, 26, 36](#)
- ap dot11 24ghz dot11g [485](#)
- ap dot11 24ghz or 5ghz rrm channel dca add command [911](#)
- ap dot11 24ghz or 5ghz rrm channel dca remove number [912](#)
- ap dot11 24ghz rrm coverage command [914](#)
- ap dot11 5ghz channelswitch mode [486](#)
- ap dot11 5ghz cleanair [16, 17](#)
- ap dot11 5ghz cleanair command [18, 19, 31](#)
- ap dot11 5ghz power-constraint [487](#)
- ap dot11 5ghz rrm channel dca chan-width-11n [913](#)
- ap dot11 5ghz rrm channel device command [21](#)
- ap dot11 5ghz rrm command [905](#)
- ap dot11 5ghz rrm group-member command [916](#)
- ap dot11 5ghz rrm profile command [918](#)
- ap dot11 5ghz rrm tpc-threshold command [919](#)
- ap dot11 5ghz rrm txpower command [920](#)
- ap dot11 airtime-fairness 24ghz 5ghz device type command [925](#)
- ap dot11 airtime-fairness policy device type command [928, 938](#)
- ap dot11 beaconperiod [488](#)
- ap dot11 beamforming [489](#)
- ap dot11 cac media-stream [490](#)
- ap dot11 cac video [495](#)
- ap dot11 cac voice [497](#)
- ap dot11 cleanair [501](#)
- ap dot11 cleanair alarm air-quality [502](#)
- ap dot11 cleanair alarm device [503](#)
- ap dot11 cleanair device [505](#)
- ap dot11 command [1300](#)
- ap dot11 dot11n [507](#)
- ap dot11 dtpc [510](#)
- ap dot11 dual-band cleanair [562](#)
- ap dot11 edcs-parameters [512](#)
- ap dot11 l2roam rf-params [515](#)
- ap dot11 media-stream [517](#)
- ap dot11 multimedia [493](#)
- ap dot11 rrm ccx command [908](#)
- ap dot11 rrm ccx location-measurement [519](#)
- ap dot11 rrm channel cleanair-event [514](#)
- ap dot11 rrm channel command [20, 28, 29, 909](#)
- ap dot11 rrm channel dca [520](#)
- ap dot11 rrm group-member [522](#)
- ap dot11 rrm group-mode [513](#)
- ap dot11 rrm logging [523](#)
- ap dot11 rrm monitor [525](#)
- ap dot11 rrm monitor mode command [917](#)
- ap dot11 rrm ndp-type [527](#)
- ap dot1x max-sessions [529](#)
- ap dot1x username [530](#)
- ap ethernet duplex [531](#)
- ap group [532](#)
- ap image [533](#)
- ap led [535](#)
- ap link-encryption [536](#)
- ap link-latency [537](#)
- ap mgmtuser username [538](#)
- ap name 49ghz rrm profile [554](#)
- ap name ap-groupname [540](#)
- ap name bhrate [542](#)
- ap name bridgegroupname [543](#)
- ap name bridging [544](#)
- ap name capwap retransmit [547](#)
- ap name command [548](#)
- ap name console-redirect [546](#)
- ap name core-dump [549](#)
- ap name country [550](#)
- ap name crash-file [551](#)
- ap name dot11 24ghz rrm coverage [552](#)
- ap name dot11 5ghz rrm channel [556](#)
- ap name dot11 airtime-fairness wlan command [927](#)
- ap name dot11 antenna [557](#)
- ap name dot11 antenna extantgain [559](#)
- ap name dot11 cleanair [560](#)

ap name dot11 dot11n antenna **561**
 ap name dot11 rrm ccx **564**
 ap name dot11 rrm profile **565**
 ap name dot11 txpower **567**
 ap name dot1xuser **568**
 ap name ethernet **570**
 ap name ethernet duplex **571**
 ap name image **573**
 ap name led **577**
 ap name link-encryption **578**
 ap name link-latency **579**
 ap name location **580**
 ap name mgmtuser **581**
 ap name mode **583**
 ap name monitor-mode **585**
 ap name monitor-mode dot11b **586**
 ap name name **587**
 ap name no cdp interface **545**
 ap name no dot11 shutdown **588**
 ap name no telnet **594**
 ap name power command **589**
 ap name power injector **595**
 ap name power pre-standard **596**
 ap name reset **598**
 ap name reset-button **597**
 ap name shutdown **590**
 ap name slot **599**
 ap name slot shutdown **591**
 ap name sniff **592**
 ap name ssh **593**
 ap name static-ip **601**
 ap name stats-timer **602**
 ap name syslog host **603**
 ap name syslog level **604**
 ap name tcp-adjust-mss **605**
 ap name tftp-downgrade **606**
 ap power injector **607**
 ap power pre-standard **608**
 ap reporting-period **609**
 ap reset-button **610**
 ap static-ip **612**
 ap syslog **613**
 ap tcp-adjust-mss size **615**
 ap tftp-downgrade **616**
 arp command **1132**
 authentication mac-move permit command **961**
 authentication priority command **962**
 auto qos classify command **804**
 auto qos trust command **810**
 auto qos video command **817**
 auto qos voip command **827**
 available power **144**

B

band-select command **1357**
 boot command **1133**
 broadcast-ssid command **1358**
 budgeted power **144**

C

cache command **55**
 cache-memory-max command **319**
 call-snoop command **1359**
 cat command **1134**
 ccx aironet-iesupport command **1366**
 channel-group command **393**
 channel-protocol command **396**
 channel-scan defer-priority command **1360**
 channel-scan defer-time command **1361**
 chd command **1362**
 Cisco Discovery Protocol (CDP) **1332**
 Cisco Mobility Services Engine (MSE) **150**
 class command **843**
 class-map command **846**
 clear ap config **619**
 clear ap eventlog-all **620**
 clear ap join statistics **621**
 clear ap mac-address **622**
 clear ap name tsm dot11 all **618**
 clear ap name wlan statistics **623**
 clear errdisable interface vlan **967**
 clear ip mfib command **320**
 clear ip mroute command **321**
 clear lacp command **397**
 clear location command **1135**
 clear location statistics command **1136**
 clear mac address-table command **968**
 clear nmsp statistics command **1137**
 clear pagp command **398**
 clear spanning-tree counters command **399**
 clear spanning-tree detected-protocols command **400**
 clear vtp counters command **1311**
 clear wireless ccx statistics command **1138**
 clear wireless client tsm dot11 command **1139**
 clear wireless location s69 statistics command **1140**
 clear wireless mobility statistics **728**
 client association limit command **1363**
 client vlan command **123, 1310, 1365**
 collect command **60**
 collect counter command **61**
 collect interface command **62**
 collect timestamp absolute command **63**
 collect transport tcp flags command **64**
 consumed power **144**
 copy command **1141**

D

datalink flow monitor command [65, 1367](#)
 debug ap mac-address [624](#)
 debug auto qos command [840](#)
 debug etherchannel command [401](#)
 debug flow exporter command [66](#)
 debug flow monitor command [67](#)
 debug ilpower command [124](#)
 debug interface command [125](#)
 debug lacp command [402](#)
 debug lldp packets command [126](#)
 debug nmsp command [127](#)
 debug pagp command [403](#)
 debug platform pm command [404](#)
 debug platform poe command [128](#)
 debug platform stack-manager command [1072](#)
 debug platform ulld command [406](#)
 debug platform vlan command [1312](#)
 debug spanning-tree command [407](#)
 debug sw-vlan command [1313](#)
 debug sw-vlan ifs command [1315](#)
 debug sw-vlan notification command [1316](#)
 debug sw-vlan vtp command [1317](#)
 default ap dot11 rrm channel [33](#)
 default ap dot11 rrm channel cleanair-event [32](#)
 default ap dot11 rrm channel command [38](#)
 default command [1369](#)
 delete command [1148](#)
 deny command [970](#)
 description command [70](#)
 destination command [71](#)
 device-classification command [1368](#)
 dir command [1149](#)
 dot1x test timeout [980](#)
 dscp command [72](#)
 dtim dot11 command [1372](#)
 duplex command [129](#)

E

emergency-install command [1151](#)
 epm access-control open command [983](#)
 errdisable detect cause command [131](#)
 errdisable recovery cause command [133](#)
 errdisable recovery interval command [135](#)
 exclusionlist command [1373](#)
 exit command [1153, 1374, 1375](#)
 export-protocol netflow-v9 command [73](#)

F

flash_init command [1154](#)
 flow-based RSPAN (FRSPAN) session [754](#)
 flow-based SPAN (FSPAN) session [754](#)

full-ring state [1119](#)

H

help command [1155](#)

I

interface command [136](#)
 interface port-channel command [409](#)
 interface range command [138](#)
 interface vlan command [1319](#)
 ip access-group command [1376](#)
 ip admission name command [985](#)
 ip dhcp snooping verify no-relay-agent-address [990](#)
 ip flow monitor command [78, 1377](#)
 ip igmp snooping last-member-query-count command [327](#)
 ip mtu command [139, 244](#)
 ip multicast auto-enable command [334](#)
 ip multicast vlan command [335](#)
 ip verify source command [994](#)
 ip verify source mac-check command [1378](#)
 ipv6 flow monitor command [80, 386](#)
 ipv6 mtu command [140](#)
 ipv6 traffic-filter command [387](#)

L

lacp max-bundle command [410](#)
 lacp port-priority command [411](#)
 lacp system-priority command [413](#)
 license right-to-use [1158](#)
 lldp (interface configuration) command [141](#)
 load-balance command [1379](#)
 location algorithm command [1164](#)
 location expiry command [1165](#)
 location notify-threshold command [1166](#)
 location plm calibrating command [1167](#)
 location rfid command [1168](#)
 location rssi-half-life command [1169](#)
 logging event power-inline-status command [142](#)

M

mab request format attribute 32 command [999](#)
 mac address-table move update command [1170](#)
 main-cpu command [1073](#)
 match (access-map configuration) command [1001](#)
 match (class-map configuration) command [848](#)
 match datalink ethernet type command [82](#)
 match datalink mac command [83](#)
 match datalink vlan command [84](#)
 match flow direction command [86](#)
 match interface command [87](#)
 match ipv4 command [88](#)

match ipv4 destination address command **89**
 match ipv4 source address command **90**
 match ipv4 ttl command **91**
 match ipv6 command **92**
 match ipv6 destination address command **93**
 match ipv6 hop-limit command **94**
 match ipv6 source command **95**
 match non-client-nrt command **851**
 match transport command **96**
 match transport icmp ipv4 command **97**
 match transport icmp ipv6 command **98**
 match wlan user-priority command **852**
 maximum transmission unit (MTU) **232, 241**
 mdix auto command **143**
 media-stream multicast-direct command **1303**
 mgmt_init command **1171**
 mkdir command **1172**
 mobility anchor **716, 1380**
 mode (power-stack configuration) command **144**
 mode command **99**
 monitor session command **748, 750**
 monitor session filter command **754**
 monitor session source command **756**
 monitoring command **146**
 more command **1173**

N

nac command **1382**
 network-policy command **148**
 network-policy configuration mode **149**
 network-policy profile (global configuration) command **149**
 network-policy profiles **202**
 nmsp attachment suppress command **150**
 nmsp notification interval command **1174**
 no authentication logging verbose **1003**
 no dot1x logging verbose **1004**
 no mab logging verbose **1005**

O

option command **100**

P

pagp learn-method command **414**
 pagp port-priority command **416**
 partial-ring state **1119**
 passive-client command **1383**
 peer-blocking command **1384**
 permit command **1006**
 persistent MAC address **1115**
 policy config-sync prc reload command **1075**
 policy weight airtime-fairness **922**
 policy-map command **853**

port-channel auto command **418**
 port-channel load-balance command **419**
 port-channel load-balance extended command **421**
 port-channel min-links command **422**
 power efficient-ethernet auto command **151**
 power inline command **154**
 power inline police command **157**
 power stack configuration mode **144**
 power supply command **159**
 power-priority command **152**

Q

queue-limit command **859**

R

radio command **1385**
 radio-policy command **1386**
 readrtc command **1177**
 real-time power consumption policing **157**
 redistribute mdns-sd command **348**
 redundancy command **1076**
 redundancy config-sync mismatched-commands command **1077**
 redundancy force-switchover command **1079**
 redundancy reload command **1080**
 reload command **1081**
 Remote SPAN (RSPAN) sessions **761**
 rename command **1178**
 request platform software console attach switch command **1179**
 request platform software trace archive **1292, 1293**
 request platform software trace filter binary **1294**
 reset command **1203**
 rmdir command **1204**
 roamed-voice-client re-anchor command **1387**
 RSPAN **748, 750, 754, 756**
 sessions **748, 750, 756**
 add interfaces to **748, 750, 756**
 start new **748, 750, 756**

S

sdm prefer command **1205**
 security web-auth command **1388**
 service-list mdns-sd service-list-name command **349**
 service-policy command **352, 862, 864, 1389**
 service-policy-query command **350**
 service-routing mdns-sd command **351**
 session command **1083**
 session-timeout command **1390**
 set command **865, 1206**
 set platform software trace **1280, 1284**
 set trace capwap ap ha command **1084**
 set trace mobility ha command **1085**
 set trace qos ap ha command **1087**

- show airtime-fairness wlan type device command 940
- show ap airtime-fairness ap-group device type command 942
- show ap cac voice 625
- show ap capwap 627
- show ap cdp 629
- show ap config dot11 630
- show ap config fnf 632
- show ap config global 633
- show ap crash-file 634
- show ap data-plane 635
- show ap dot11 637, 638
- show ap dot11 24ghz cleanair device type command 930
- show ap dot11 24ghz cleanair summary command 49
- show ap dot11 24ghz command 1301
- show ap dot11 5ghz 641, 932
- show ap dot11 5ghz cleanair device type command 43
- show ap dot11 cleanair summary 640
- show ap dot11 l2roam 636
- show ap ethernet statistics 648
- show ap groups 650
- show ap image 652
- show ap join stats summary 654
- show ap link-encryption 655
- show ap mac-address 656
- show ap monitor-mode summary 658
- show ap name 692
- show ap name auto-rf 659
- show ap name bhrate 663
- show ap name cac voice 664
- show ap name capwap retransmit 668
- show ap name ccx rm 669
- show ap name cdp neighbors 670
- show ap name channel 671
- show ap name command 662
- show ap name config 672
- show ap name config dot11 674
- show ap name config fnf 665
- show ap name config slot 678
- show ap name core-dump 682
- show ap name data-plane 683
- show ap name dot11 684, 873
- show ap name dot11 call-control 666
- show ap name dot11 cleanair 687
- show ap name ethernet statistics 689
- show ap name eventlog 690
- show ap name inventory 693
- show ap name link-encryption 695
- show ap name service-policy 696, 872
- show ap name tcp-adjust-mss 697
- show ap name wlan 698
- show ap slots 701
- show ap summary 702
- show ap tcp-adjust-mss 703
- show ap uptime 705
- show auto qos command 841
- show avc client command 1209
- show avc wlan command 1210
- show cable-diagnostics tdr command 1211
- show capwap summary 161
- show class-map command 876
- show controller utilization command 173
- show controllers cpu-interface command 162
- show controllers ethernet-controller command 164
- show eap command 1026
- show eee command 175
- show env command 178, 1215
- show errdisable detect command 181
- show errdisable recovery command 182
- show etherchannel command 433
- show flow exporter command 104
- show flow record command 110
- show interfaces command 183
- show interfaces counters command 187
- show interfaces switchport command 189
- show interfaces transceiver command 191
- show ip igmp snooping igmpv2-tracking command 358
- show ip igmp snooping wireless mcast-spi-count command 362
- show ip igmp snooping wireless mgid command 363
- show ip pim autorp command 364
- show ip pim bsr command 366
- show ip pim bsr-router command 365
- show ip pim tunnel command 367
- show ip sla statistics command 759
- show lacp command 437
- show license right-to-use command 1219
- show location ap-detect command 1222
- show location command 1221
- show mac address-table move update command 1224
- show mgmt-infra trace messages ilpower command 198
- show mgmt-infra trace messages ilpower-ha command 200
- show mgmt-infra trace messages platform-mgr-poe command 201
- show mod command 197
- show monitor command 761
- show network-policy profile command 202
- show nmsp command 1225
- show pagp command 441
- show platform capwap summary 203
- show platform etherchannel command 443
- show platform ip multicast command 373
- show platform ip wccp command 765
- show platform pm command 444
- show platform software trace level 1289
- show platform software trace message 1285
- show platform stack-manager command 1102
- show platform vlan command 1321
- show policy-map command 889
- show power inline command 224
- show redundancy command 1103
- show redundancy config-sync command 1107
- show sampler command 111
- show sdm prefer command 1226
- show stack-power command 229, 231

- show storm-control [1032](#)
 - show switch command [1109](#)
 - show system mtu command [232](#)
 - show tech-support command [233](#)
 - show tech-support wireless command [1228](#)
 - show trace messages capwap ap ha command [1113](#)
 - show trace messages mobility ha command [1114](#)
 - show uddl command [447](#)
 - show vlan access-map command [1034](#)
 - show vlan command [1322](#)
 - show vlan group command [1035](#)
 - show vtp command [1325](#)
 - show wireless ap summary [706](#)
 - show wireless band-select command [1230](#)
 - show wireless client ap [707](#)
 - show wireless client calls command [884, 1231](#)
 - show wireless client dot11 command [885, 1232](#)
 - show wireless client location-calibration command [1233](#)
 - show wireless client mac-address command [886, 887](#)
 - show wireless client probing command [1234](#)
 - show wireless client summary command [1235](#)
 - show wireless client timers command [1236](#)
 - show wireless client voice diagnostics command [888, 1237](#)
 - show wireless country command [1238](#)
 - show wireless detail command [1241](#)
 - show wireless dtls connections command [1242](#)
 - show wireless interface summary command [235](#)
 - show wireless ipv6 statistics command [388](#)
 - show wireless load-balancing command [1245](#)
 - show wireless media-stream group command [1302](#)
 - show wireless mobility [727](#)
 - show wireless performance command [1246](#)
 - show wireless pmk-cache command [1247](#)
 - show wireless probe command [1248](#)
 - show wireless sip preferred-call-no command [1249](#)
 - show wireless summary command [1250](#)
 - show wireless vlan group command [1331](#)
 - show wlan command [891, 1391](#)
 - shutdown command [1251, 1395](#)
 - sip-cac command [1396](#)
 - snmp-server enable traps bridge command [771](#)
 - snmp-server enable traps bulkstat command [772](#)
 - snmp-server enable traps call-home command [773](#)
 - snmp-server enable traps cef command [774](#)
 - snmp-server enable traps command [768](#)
 - snmp-server enable traps CPU command [775](#)
 - snmp-server enable traps envmon command [776](#)
 - snmp-server enable traps errdisable command [777](#)
 - snmp-server enable traps flash command [778](#)
 - snmp-server enable traps isis command [779](#)
 - snmp-server enable traps license command [780](#)
 - snmp-server enable traps mac-notification command [781](#)
 - snmp-server enable traps ospf command [782](#)
 - snmp-server enable traps pim command [783](#)
 - snmp-server enable traps port-security command [784](#)
 - snmp-server enable traps power-ethernet command [785](#)
 - snmp-server enable traps snmp command [786](#)
 - snmp-server enable traps stackwise command [787](#)
 - snmp-server enable traps storm-control command [789](#)
 - snmp-server enable traps stpx command [790](#)
 - snmp-server enable traps transceiver command [791](#)
 - snmp-server enable traps vrfmib command [792](#)
 - snmp-server enable traps vstack command [793](#)
 - snmp-server engineID command [794](#)
 - snmp-server host command [795](#)
 - speed command [236](#)
 - stack member number [1124](#)
 - stack member priority [1121](#)
 - stack-mac persistent timer command [1115](#)
 - stack-mac update force command [1117](#)
 - stack-power command [238](#)
 - StackPower [229, 231, 238](#)
 - standby console enable command [1118](#)
 - static-ip tunneling command [1397](#)
 - statistics airtime-fairness [936](#)
 - storm-control command [1036](#)
 - switch priority command [1121](#)
 - switch provision command [1122](#)
 - switch renumber command [1124](#)
 - switch stack port command [1119](#)
 - Switched Port Analyzer (SPAN) sessions [761](#)
 - switchport access vlan command [452](#)
 - switchport block command [240](#)
 - switchport command [450](#)
 - switchport mode access [799, 800](#)
 - switchport mode command [455](#)
 - switchport nonegotiate command [457](#)
 - switchport port-security aging command [1039](#)
 - switchport port-security mac-address command [1041](#)
 - switchport port-security maximum command [1043](#)
 - switchport port-security violation command [1045](#)
 - switchport priority extend command [1332](#)
 - switchport trunk command [1333](#)
 - switchport voice vlan command [458](#)
 - system env temperature threshold yellow command [1252](#)
 - system mtu command [241](#)
- ## T
- template data timeout command [115](#)
 - test ap name [708](#)
 - test cable-diagnostics tdr command [1254](#)
 - test capwap ap name [709](#)
 - test mcu read register command [242](#)
 - traceroute mac command [1255](#)
 - traceroute mac ip command [1258](#)
 - transport command [116](#)
 - trapflags ap [710](#)
 - trapflags client command [1261](#)
 - trapflags command [1260](#)
 - ttl command [117](#)

type command [1262](#)

U

udld command [461](#)
 udld port command [463](#)
 udld reset command [465](#)
 unset command [1263](#)

V

version command [1265](#)
 vlan access-map command [1064](#)
 vlan command [1336, 1398](#)
 vlan dot1q tag native command [1342](#)
 vlan filter command [1066](#)
 vlan group command [1067](#)
 voice vlan command [247](#)
 voice-signaling vlan command [245](#)
 vtp (global configuration) command [1343](#)
 vtp (interface configuration) command [1348](#)
 vtp primary command [1349](#)

W

wgb non-cisco command [1400](#)
 wireless ap-manager interface [249](#)
 wireless broadcast vlan command [1350](#)
 wireless client command [1266](#)

wireless client mac-address command [1269](#)
 wireless dot11-padding command [1051](#)
 wireless exclusionlist command [250](#)
 wireless linktest command [251](#)
 wireless load-balancing command [1274](#)
 wireless management interface command [252](#)
 wireless media-stream command [1304](#)
 wireless mobility [718](#)
 wireless mobility controller [719, 721](#)
 wireless mobility group keepalive [723](#)
 wireless mobility group member ip [724](#)
 wireless mobility group name [725](#)
 wireless mobility load-balance [726](#)
 wireless multicast command [382](#)
 wireless peer-blocking forward-upstream command [253](#)
 wireless security dot1x command [1052](#)
 wireless security lsc command [1054](#)
 wireless security strong-password command [1055](#)
 wireless sip preferred-call-no command [1275](#)
 wireless wps ap-authentication command [1056](#)
 wireless wps auto-immune command [1057](#)
 wireless wps cids-sensor command [1058](#)
 wireless wps client-exclusion command [1059](#)
 wireless wps mfp infrastructure command [1061](#)
 wireless wps rogue command [1062](#)
 wireless wps shun-list re-sync command [1063](#)
 wlan command [1401, 1402](#)
 wlan shutdown command [1403](#)
 wmm command [1404](#)
 writertc command [1276](#)

