



Supervisor Engine 6T Software Configuration Guide, Release 15.4SY

Cisco IOS Release 15.4SY

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Text Part Number:

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)



Preface	i
Audience	i
Related Documentation	i
Conventions	i
Obtaining Documentation, Obtaining Support, and Security Guidelines	ii
Product Overview	1-1
Supervisor Engine 6T Ports	1-1
USB Type A Port	1-1
Console ports	1-2
USB Type B Port	1-2
System Reset Button	1-2
Management Port	1-2
Management Port Operation Modes	1-3
LED Indicators	1-3
Status LED	1-3
System ID LED	1-4
Management Port LED	1-4
Status LED	1-4
System ID LED	1-4
Determining System Hardware Capacity	1-5
Command-Line Interfaces	2-1
Accessing the CLI	2-1
Accessing the CLI through the EIA/TIA-232 Console Interface	2-2
Accessing the CLI through Telnet	2-2
Accessing the CLI through USB	2-3
Performing Command Line Processing	2-3
Performing History Substitution	2-4
Cisco IOS Command Modes	2-4
Displaying a List of Cisco IOS Commands and Syntax	2-6
Securing the CLI	2-7
ROM-Monitor Command-Line Interface	2-7

Smart Port Macros	3-1
Prerequisites for Smart Port Macros	3-1
Restrictions for Smart Port Macros	3-2
Information About Smart Port Macros	3-3
Information about Cisco-Provided Smart Port Macros	3-3
Information about User-Created Smart Port Macros	3-4
Default Settings for Smart Port Macros	3-4
How to Configure Smart Port Macros	3-4
Using the Cisco-Provided Smart Port Macros	3-4
Creating Smart Port Macros	3-13
Verifying the Smart Port Macro Configuration	3-15
Virtual Switching Systems	4-1
Prerequisites for VSS	4-1
Restrictions for VSS	4-2
General VSS Restrictions	4-2
VSL Restrictions	4-2
Multichassis EtherChannel (MEC) Restrictions	4-2
Dual-Active Detection Restrictions	4-3
Information About Virtual Switching Systems	4-4
VSS Overview	4-4
VSS Redundancy	4-12
Multichassis EtherChannels	4-15
Packet Handling	4-18
System Monitoring	4-22
Convert Port Mode	4-23
Dual-Active Detection	4-27
VSS Initialization	4-29
Default Settings for VSS	4-31
How to Configure a VSS	4-31
Configuring Easy VSS	4-31
Converting to a VSS	4-32
Displaying VSS Information	4-38
Converting a VSS to Standalone Chassis	4-39
Configuring VSS Parameters	4-40
Configuring Multichassis EtherChannels	4-49
Configuring Port Load Share Deferral on the Peer Switch	4-49
Configuring Dual-Active Detection	4-50
How to Upgrade a VSS	4-54

Performing a Fast Software Upgrade of a VSS	4-54
Performing an Enhanced Fast Software Upgrade of a VSS	4-55
Enhanced Fast Software Upgrade	5-1
Prerequisites for eFSU	5-2
Restrictions for eFSU	5-2
Information About eFSU	5-3
eFSU Operation	5-3
Outage Time and Support Considerations	5-4
Reserving Module Memory	5-4
Error Handling for eFSU Preload	5-5
Default Settings for eFSU	5-5
How to Perform an eFSU	5-5
eFSU Summarized Procedure	5-6
Preparing for the Upgrade	5-6
Copying the New Software Image	5-8
Loading the New Software onto the Standby Supervisor Engine	5-8
Displaying the Maximum Outage Time for Installed Modules (Optional)	5-10
Forcing a Switchover from Active to Standby	5-10
Accepting the New Software Version and Stopping the Rollback Process (Optional)	5-12
Committing the New Software to the Standby	5-12
Verifying the Software Installation	5-12
Aborting the Upgrade Process	5-13
How to Upgrade a Non-eFSU Image to an eFSU Image	5-14
Fast Software Upgrade	6-1
Stateful Switchover (SSO)	7-1
Prerequisites for SSO	7-1
Restrictions for SSO	7-2
General Restrictions	7-2
Configuration Mode Restrictions	7-2
Switchover Process Restrictions	7-2
Information About SSO	7-3
SSO Overview	7-3
SSO Operation	7-5
Route Processor Synchronization	7-6
SSO Operation	7-8
SSO-Aware Features	7-10
Default Settings for SSO	7-10

How to Configure SSO	7-10
Troubleshooting SSO	7-11
Possible SSO Problem Situations	7-11
SSO Troubleshooting	7-12
Verifying the SSO Configuration	7-12
Verifying that SSO Is Configured	7-12
Verifying that SSO Is Operating on the Device	7-13
Verifying SSO Features	7-13
Configuration Examples for SSO	7-16

Nonstop Forwarding (NSF)	8-1
Prerequisites for NSF	8-1
Restrictions for NSF	8-2
General Restrictions	8-2
Restrictions for BGP NSF	8-2
Restrictions for EIGRP NSF	8-2
Restrictions for OSPF NSF	8-2
Restrictions for IS-IS NSF	8-2
Restrictions for IPv6 NSF	8-3
Information About NSF	8-3
NSF Overview	8-3
Feature Interaction with NSF	8-4
Default Settings for NSF	8-9
How to Configure NSF	8-9
Configuring and Verifying BGP for NSF	8-9
Configuring and Verifying EIGRP NSF	8-10
Configuring and Verifying OSPF NSF	8-12
Configuring and Verifying IS-IS NSF	8-13
Troubleshooting Cisco Nonstop Forwarding	8-14
Configuration Examples for NSF	8-15
Example: Configuring BGP NSF	8-15
Example: Configuring BGP NSF Neighbor Device	8-15
Example: Verifying BGP NSF	8-16
Example: Configuring EIGRP NSF Converge Timer	8-16
Example: EIGRP Graceful-Restart Purge-Time Timer Configuration	8-16
Example: Configuring EIGRP NSF Route-Hold Timer	8-17
Example: Configuring EIGRP NSF Signal Timer	8-17
Example: Verifying EIGRP NSF	8-17
Example: Disabling EIGRP NSF Support	8-18

Example: Configuring OSPF NSF	8-18
Example: Verifying OSPF NSF	8-18
Example: Configuring IS-IS NSF	8-19
Example: Verifying IS-IS NSF	8-19
Route Processor Redundancy (RPR)	9-1
Prerequisites for RPR	9-1
Restrictions for RPR	9-1
General RPR Restrictions	9-2
Hardware Restrictions for RPR	9-2
Information About RPR	9-2
Supervisor Engine Redundancy Overview	9-3
RPR Operation	9-3
Supervisor Engine Configuration Synchronization	9-4
Default Settings for RPR	9-4
How to Configure RPR	9-4
Synchronizing the Supervisor Engine Configurations	9-4
Displaying the Redundancy States	9-4
Copying Files to the RP	9-5
Interface Configuration	10-1
Information About Interface Configuration	10-2
How to Configure a Range of Interfaces	10-2
How to Define and Use Interface-Range Macros	10-2
How to Configure Optional Interface Features	10-3
Configuring Ethernet Interface Speed and Duplex Mode	10-3
Configuring Jumbo Frame Support	10-6
Configuring IEEE 802.3x Flow Control	10-9
Configuring the Port Debounce Timer	10-10
Information About Online Insertion and Removal	10-11
How to Monitor and Maintain Interfaces	10-12
Monitoring Interface Status	10-12
Clearing Counters on an Interface	10-12
Resetting an Interface	10-13
Shutting Down and Restarting an Interface	10-13
How to Check Cable Status with the TDR	10-14
How to Convert Line Card to Operate in 40G Mode	10-14
Overview of Cisco CVR-4SFP10G-QSFP Adapter	10-15
Compatible Line Cards	10-16

UniDirectional Link Detection (UDLD)	11-1
Prerequisites for UDLD	11-1
Restrictions for UDLD	11-1
Information About UDLD	11-2
UDLD Overview	11-2
UDLD Aggressive Mode	11-3
Fast UDLD	11-4
Default Settings for UDLD	11-4
How to Configure UDLD	11-4
Enabling UDLD Globally	11-5
Enabling UDLD on LAN Interfaces	11-5
Disabling UDLD on Nonfiber-Optic LAN Interfaces	11-5
Disabling UDLD on Fiber-Optic LAN Interfaces	11-6
Configuring the UDLD Probe Message Interval	11-6
Configuring Fast UDLD	11-6
Resetting Disabled LAN Interfaces	11-7
Instant Access (IA)	12-1
Prerequisites for Instant Access	12-1
Restrictions for Instant Access	12-2
Information About Instant Access	12-6
Default Settings for Instant Access	12-6
How to Configure Instant Access	12-6
Configure Instant Access Staggered Initialization Mode	12-7
Enable FEX Auto-Config	12-7
Enable IA Client Preprovisioning	12-7
Configure Instant Access Port-Channel Interfaces	12-8
Configure Instant Access Channel Groups	12-9
Identify Connected IA Client Stack Modules	12-9
Renumbering FEX Switch-ID	12-11
Configure IA Clients	12-13
Display or Clear SDP and SRP Traffic	12-13
Upgrade FEX using In-Service Software Upgrade (ISSU) Process	12-13
Configure Optional Parameters for an IA Client	12-14
Configuring EnergyWise	13-1
Power Management	14-1
Power Management Overview	14-1
How to Enable or Disable Power Redundancy	14-2

How to Power Modules Off and On	14-3
How to Display System Power Status	14-3
How to Power Cycle Modules	14-5
Environmental Monitoring	15-1
Environmental Monitoring Overview	15-1
How to Determine Sensor Temperature Thresholds	15-2
How to Monitor the System Environmental Status	15-5
Information About LED Environmental Indications	15-7
Online Diagnostics	16-1
Prerequisites for Online Diagnostics	16-1
Restrictions for Online Diagnostics	16-1
Information About Online Diagnostics	16-2
Default Settings for Online Diagnostics	16-2
How to Configure Online Diagnostics	16-2
Setting Bootup Online Diagnostics Level	16-2
Configuring On-Demand Online Diagnostics	16-4
Scheduling Online Diagnostics	16-6
Configuring Health-Monitoring Diagnostics	16-6
How to Run Online Diagnostic Tests	16-7
Overview of Diagnostic Test Operation	16-8
Starting and Stopping Online Diagnostic Tests	16-8
Running All Online Diagnostic Tests	16-9
Displaying Online Diagnostic Tests and Test Results	16-9
How to Perform Memory Tests	16-29
How to Perform a Diagnostic Sanity Check	16-29
Onboard Failure Logging (OBFL)	17-1
Prerequisites for OBFL	17-1
Restrictions for OBFL	17-2
Information About OBFL	17-2
Overview of OBFL	17-2
Information about Data Collected by OBFL	17-2
Default Settings for OBFL	17-9
Enabling OBFL	17-10
Configuration Examples for OBFL	17-11
Enabling OBFL Message Logging: Example	17-11
OBFL Message Log: Example	17-11

OBFL Component Uptime Report: Example	17-11
OBFL Report for a Specific Time: Example	17-12
Switch Fabric Functionality	18-1
Prerequisites for Switch Fabric Functionality	18-1
Restrictions for Switch Fabric Functionality	18-1
Information About the Switch Fabric Functionality	18-2
Default Settings for Switch Fabric Functionality	18-2
Monitoring the Switch Fabric Functionality	18-2
Cisco IP Phone Support	19-1
Prerequisites for Cisco IP Phone Support	19-1
Restrictions for Cisco IP Phone Support	19-1
Information About Cisco IP Phone Support	19-2
Cisco IP Phone Connections	19-2
Cisco IP Phone Voice Traffic	19-3
Cisco IP Phone Data Traffic	19-4
Other Cisco IP Phone Features	19-4
Default Setting for Cisco IP Phone Support	19-4
How to Configure Cisco IP Phone Support	19-5
Configuring Voice Traffic Support	19-5
Configuring Data Traffic Support	19-6
Power over Ethernet (PoE) Support	20-1
Prerequisites for PoE	20-1
Restrictions for PoE	20-1
Information About PoE	20-2
Device Roles	20-2
PoE Overview	20-2
CPD-Based PoE Management	20-3
Inline Power IEEE Power Classification Override	20-4
LLDP Inline Power Negotiation for PoE+ (IEEE 802.3at)	20-4
How to Configure PoE Support	20-4
Displaying PoE Status	20-5
Configuring Per-Port PoE Support	20-5
Configuring PoE Power Priority	20-6
Configuring PoE Monitoring and Policing	20-8
Disabling LLDP Power Negotiation (IEEE 802.3at)	20-8

LAN Ports for Layer 2 Switching	21-1
Prerequisites for Layer 2 LAN Interfaces	21-1
Restrictions for Layer 2 LAN Interfaces	21-2
Information About Layer 2 Switching	21-2
Information about Layer 2 Ethernet Switching	21-2
Information about VLAN Trunks	21-4
Layer 2 LAN Port Modes	21-4
Default Settings for Layer 2 LAN Interfaces	21-5
How to Configure LAN Interfaces for Layer 2 Switching	21-5
Configuring a LAN Port for Layer 2 Switching	21-6
Enabling Out-of-Band MAC Address Table Synchronization	21-6
Configuring MAC Address Table Notification	21-7
Configuring a Layer 2 Switching Port as a Trunk	21-8
Configuring a LAN Interface as a Layer 2 Access Port	21-14
Configuring a Custom IEEE 802.1Q EtherType Field Value	21-15
Flex Links	22-1
Prerequisites for Flex Links	22-1
Restrictions for Flex Links	22-2
Information About Flex Links	22-2
Default Settings for Flex Links	22-4
How to Configure Flex Links	22-4
Monitoring Flex Links	22-6
EtherChannels	23-1
Prerequisites for EtherChannels	23-1
Restrictions for EtherChannels	23-2
Information About EtherChannels	23-3
EtherChannel Feature Overview	23-3
Information about EtherChannel Configuration	23-3
Information about LACP 1:1 Redundancy	23-6
Information about Port Channel Interfaces	23-7
Information about Load Balancing	23-7
Default Settings for EtherChannels	23-7
How to Configure EtherChannels	23-7
Configuring Port Channel Logical Interfaces	23-8
Configuring Channel Groups	23-9
Configuring the LACP System Priority and System ID	23-11
Configuring EtherChannel Load Balancing	23-11

Configuring the EtherChannel Hash-Distribution Algorithm	23-12
Configuring the EtherChannel Min-Links Feature	23-13
Configuring LACP 1:1 Redundancy	23-14
Configuring Auto Interleaved Port Priority For LACP Port Channels	23-15
Configuring LACP Port-Channel Standalone Disable	23-16
IEEE 802.1ak MVRP and MRP	24-1
Prerequisites for IEEE 802.1ak MVRP and MRP	24-1
Restrictions for IEEE 802.1ak MVRP and MRP	24-2
Information About IEEE 802.1ak MVRP and MRP	24-2
Overview	24-2
Dynamic VLAN Creation	24-4
MVRP Interoperability with VTP	24-4
MVRP Interoperation with Non-Cisco Devices	24-6
MVRP Interoperability with Other Software Features and Protocols	24-6
Default Settings for IEEE 802.1ak MVRP and MRP	24-8
How to Configure IEEE 802.1ak MVRP and MRP	24-8
Enabling MVRP	24-8
Enabling Automatic Detection of MAC Addresses	24-9
Enabling MVRP Dynamic VLAN Creation	24-9
Changing the MVRP Registrar State	24-10
Troubleshooting the MVRP Configuration	24-10
Configuration Examples for IEEE 802.1ak MVRP and MRP	24-11
Enabling MVRP	24-11
Enabling MVRP Automatic Detection of MAC Addresses	24-11
Enabling Dynamic VLAN Creation	24-12
Changing the MVRP Registrar State	24-12
VLAN Trunking Protocol (VTP)	25-1
Prerequisites for VTP	25-1
Restrictions for VTP	25-1
Information About VTP	25-2
VTP Overview	25-3
VTP Domains	25-3
VTP Modes	25-4
VTP Advertisements	25-4
VTP Authentication	25-5
VTP Version 2	25-5
VTP Version 3	25-6

VTP Pruning	25-7
VLAN Interaction	25-9
Default Settings for VTP	25-9
How to Configure VTP	25-10
Configuring VTP Global Parameters	25-10
Configuring the VTP Mode	25-15
Configuring VTP Mode on a Per-Port Basis	25-16
Displaying VTP Statistics	25-17
Virtual Local Area Networks (VLANs)	26-1
Prerequisites for VLANs	26-1
Restrictions for VLANs	26-2
Information About VLANs	26-2
VLAN Overview	26-2
VLAN Ranges	26-2
Default Settings for VLANs	26-3
How to Configure VLANs	26-4
Configurable VLAN Parameters	26-4
VLAN Locking	26-4
Creating or Modifying an Ethernet VLAN	26-5
Assigning a Layer 2 LAN Interface to a VLAN	26-6
Configuring the Internal VLAN Allocation Policy	26-6
Configuring VLAN Translation	26-7
Saving VLAN Information	26-9
Private VLANs	27-1
Prerequisites for Private VLANs	27-1
Restrictions for Private VLANs	27-2
Secondary and Primary VLANs	27-2
Private VLAN Ports	27-4
Limitations with Other Features	27-4
Information About Private VLANs	27-5
Private VLAN Domains	27-5
Private VLAN Ports	27-7
Primary, Isolated, and Community VLANs	27-7
Private VLAN Port Isolation	27-8
IP Addressing Scheme with Private VLANs	27-8
Private VLANs Across Multiple Switches	27-9
Private VLAN Interaction with Other Features	27-9

Default Settings for Private VLANs	27-10
How to Configure Private VLANs	27-10
Configuring a VLAN as a Private VLAN	27-11
Associating Secondary VLANs with a Primary VLAN	27-12
Mapping Secondary VLANs to the Layer 3 VLAN Interface of a Primary VLAN	27-13
Configuring a Layer 2 Interface as a Private VLAN Host Port	27-14
Configuring a Layer 2 Interface as a Private VLAN Promiscuous Port	27-15
Monitoring Private VLANs	27-16
Private Hosts	28-1
Prerequisites for Private Hosts	28-1
Restrictions for Private Hosts	28-1
General Private Host Restrictions	28-2
Private Host ACL Restrictions	28-2
Private Host VLAN on Trunk Port Restrictions	28-3
Private Host Interaction with Other Features	28-3
Private Host Spoofing Protection	28-3
Private Host Multicast Operation	28-4
Information About Private Hosts	28-4
Private Hosts Overview	28-4
Isolating Hosts in a VLAN	28-4
Restricting Traffic Flow (Using Private Hosts Port Mode and PACLs)	28-5
Port ACLs	28-7
Default Settings for Private Hosts	28-8
How to Configure Private Hosts	28-8
Configuration Summary	28-8
Detailed Configuration Steps	28-9
Configuration Examples	28-10
IEEE 802.1Q Tunneling	29-1
Prerequisites for 802.1Q Tunneling	29-1
Restrictions for 802.1Q Tunneling	29-1
Information About 802.1Q Tunneling	29-4
Default Settings for 802.1Q Tunneling	29-5
How to Configure 802.1Q Tunneling	29-6
Configuring 802.1Q Tunnel Ports	29-6
Configuring the Switch to Tag Native VLAN Traffic	29-6

Layer 2 Protocol Tunneling	30-1
Prerequisites for Layer 2 Protocol Tunneling	30-1
Restrictions for Layer 2 Protocol Tunneling	30-1
Information About Layer 2 Protocol Tunneling	30-2
Default Settings for Layer 2 Protocol Tunneling	30-2
How to Configure Layer 2 Protocol Tunneling	30-3
Spanning Tree Protocols	31-1
Prerequisites for Spanning Tree Protocols	31-1
Restrictions for Spanning Tree Protocols	31-2
Information About Spanning Tree Protocols	31-2
Information about STP	31-2
Information about IEEE 802.1w RSTP	31-13
Information about MST	31-18
Detecting Unidirectional Link Failure	31-25
Default Settings for Spanning Tree Protocols	31-25
Default STP Configuration	31-25
Default MST Configuration	31-26
How to Configure Spanning Tree Protocols	31-26
Configuring STP	31-26
Configuring MST	31-37
Optional STP Features	32-1
PortFast	32-2
Information about PortFast	32-2
Enabling PortFast	32-2
Bridge Assurance	32-4
Information about Bridge Assurance	32-4
Enabling Bridge Assurance	32-7
BPDU Guard	32-7
Information about BPDU Guard	32-7
Enabling BPDU Guard	32-7
PortFast Edge BPDU Filtering	32-9
Information about PortFast Edge BPDU Filtering	32-9
Enabling PortFast Edge BPDU Filtering	32-10
UplinkFast	32-11
Information about UplinkFast	32-11
Enabling UplinkFast	32-12
BackboneFast	32-13

Information about BackboneFast	32-13
Enabling BackboneFast	32-15
EtherChannel Guard	32-16
Information about EtherChannel Guard	32-16
Enabling EtherChannel Guard	32-16
Root Guard	32-17
Information about Root Guard	32-17
Enabling Root Guard	32-17
Loop Guard	32-17
Information about Loop Guard	32-17
Enabling Loop Guard	32-19
PVST Simulation	32-20
Information about PVST Simulation	32-20
Configuring PVST Simulation	32-21
Verifying the Optional STP Features	32-21
Using the show spanning-tree Commands	32-22
Examples of the show spanning-tree Commands	32-22
IP Unicast Layer 3 Switching	33-1
Prerequisites for Hardware Layer 3 Switching	33-1
Restrictions for Hardware Layer 3 Switching	33-2
Information About Layer 3 Switching	33-2
Hardware Layer 3 Switching	33-2
Layer 3-Switched Packet Rewrite	33-2
Default Settings for Hardware Layer 3 Switching	33-4
How to Configure Hardware Layer 3 Switching	33-4
Displaying Hardware Layer 3 Switching Statistics	33-5
Policy-Based Routing (PBR)	34-1
Prerequisites for PBR	34-1
Restrictions for PBR	34-2
Information About PBR	34-2
PBR Overview	34-2
PBR Recursive Next Hop for IPv4 Traffic	34-3
Default Settings for PBR	34-3
How to Configure PBR	34-3
Configuring PBR	34-4
Configuring Local PBR	34-5
Configuring PBR Recursive Next Hop	34-5

Configuration Examples for PBR	34-7
Equal Access Example	34-7
Differing Next Hops Example	34-8
Recursive Next-Hop IP Address: Example	34-8
Layer 3 Interfaces	35-1
Restrictions for Layer 3 Interfaces	35-1
How to Configure Subinterfaces on Layer 3 Interfaces	35-3
Unidirectional Ethernet (UDE) and Unidirectional Link Routing (UDLR)	36-1
Prerequisites for UDE and UDLR	36-1
Restrictions for UDE and UDLR	36-2
UDE Restrictions	36-2
UDLR Back-Channel Tunnel Restrictions	36-3
Information About UDE and UDLR	36-3
UDE and UDLR Overview	36-3
Information about UDE	36-3
Information about UDLR	36-4
Default Settings for UDE and UDLR	36-4
How to Configure UDE and UDLR	36-5
Configuring UDE	36-5
Configuring UDLR	36-6
Multiprotocol Label Switching (MPLS)	37-1
Prerequisites for MPLS	37-1
Restrictions for MPLS	37-1
Information About MPLS	37-2
MPLS Overview	37-2
IP to MPLS	37-4
MPLS to MPLS	37-4
MPLS to IP	37-4
MPLS VPN Forwarding	37-5
Recirculation	37-5
Hardware Supported Features	37-5
Supported MPLS Features	37-6
Default Settings for MPLS	37-7
How to Configure MPLS Features	37-7
Configuring MPLS	37-7
Configuring MUX-UNI Support on LAN Cards	37-7

Configuration Examples for MPLS	37-9
MPLS VPN Support	38-1
Prerequisites for MPLS VPN	38-1
Restrictions for MPLS VPN	38-2
Information About MPLS VPN Support	38-2
How to Configure MPLS VPNs	38-3
Configuration Example for MPLS VPNs	38-4
Ethernet over MPLS (EoMPLS)	39-1
Prerequisites for EoMPLS	39-1
Restrictions for EoMPLS	39-2
Information About EoMPLS	39-3
AToM Overview	39-3
EoMPLS Overview	39-3
Default Settings for EoMPLS	39-3
How to Configure EoMPLS	39-4
Configuring VLAN-Based EoMPLS	39-4
Configuring Port-Based EoMPLS	39-6
Configuring A-VPLS	40-1
Prerequisites for A-VPLS	40-1
Restrictions for A-VPLS	40-2
Information About A-VPLS	40-2
How to Configure A-VPLS	40-3
Enabling Load-Balancing with ECMP and FAT Pseudowires	40-3
Enabling Port-Channel Load-Balancing	40-3
Explicitly Specifying the PE Routers As Part of Virtual Ethernet Interface Configuration	40-4
Configuring an MPLS Traffic Engineering Tunnel	40-5
Configuring a GRE Tunnel	40-5
Routed Pseudo-Wire (RPW) and Routed VPLS	40-8
Ethernet Virtual Connections (EVCs)	41-1
Prerequisites for EVCs	41-1
Restrictions for EVCs	41-2
Information About EVCs	41-3
EVC Overview	41-3
Ethernet Flow Points	41-4
Service Instances and EFPs	41-4

Encapsulation (Flexible Service Mapping)	41-5
EFPs and MSTP	41-7
Bridge Domains	41-7
Rewrite Operations	41-9
Layer 3 and Layer 4 ACL Support	41-9
Advanced Frame Manipulation	41-9
Egress Frame Filtering	41-9
Default Settings for EVCs	41-9
How to Configure EVCs	41-10
Monitoring EVCs	41-14
Layer 2 over Multipoint GRE (L2omGRE)	42-1
Prerequisites for L2omGRE	42-1
Restrictions for L2omGRE	42-2
Information About L2omGRE	42-2
Default Settings for L2omGRE	42-3
How to Configure L2omGRE	42-3
Configuring a Loopback Interface	42-3
Configuring an mGRE Tunnel Interface	42-3
Configuring a VLAN Interface	42-4
L2omGRE Configuration Examples	42-5
Verifying the L2omGRE Configuration	42-5
Campus Fabric	43-1
Understanding Fabric Domain Elements	43-1
Campus Fabric Configuration Guidelines	43-2
How to Configure Fabric Overlay	43-2
Configuring Fabric Edge Devices	43-2
Configuring Control-Plane Devices	43-3
Configuring Border Devices	43-4
Example: Configuring Fabric Edge, Border and Control-Plane Devices	43-6
IPv4 Multicast Layer 3 Features	44-1
Prerequisites for IPv4 Multicast Layer 3 Features	44-1
Restrictions for IPv4 Multicast Layer 3 Features	44-1
Information About IPv4 Multicast Layer 3 Features	44-2
IPv4 Multicast Layer 3 Features Overview	44-2
Distributed MRIB and MFIB Infrastructure	44-3
Multicast Layer 3 Hardware Features Entries	44-4

Layer 3-Switched Multicast Statistics	44-4
Layer 3-Switched Multicast Packet Rewrite	44-5
Replication Modes	44-5
Local Egress Replication Mode	44-6
PIM-SM hardware register support	44-6
PIM-SM hardware SPT-switchover support	44-6
Control Plane Policing (CoPP)	44-7
Non-RPF Traffic Processing	44-7
Multicast Boundary	44-7
IPv4 Bidirectional PIM	44-8
Supported Multicast Features	44-8
Default Settings for IPv4 Multicast Layer 3 Features	44-15
How to Configure IPv4 Multicast Layer 3 Features	44-15
Enabling IPv4 Multicast Routing Globally	44-16
Enabling IPv4 PIM on Layer 3 Interfaces	44-16
Enabling IP Multicast Layer 3 Switching on Layer 3 Interfaces	44-16
Enabling IP MFIB forwarding on Layer 3 Interfaces	44-17
Configuring the Replication Mode	44-18
Configuring Multicast Boundary	44-18
Verifying Local Egress Replication	44-19
Displaying IPv4 Multicast PIM-SM register tunnel information	44-20
Displaying the IPv4 Multicast Routing Table	44-20
Displaying IPv4 MRIB Information	44-21
Displaying IPv4 MFIB Information	44-22
Viewing Directly Connected Entries	44-23
Displaying IPv4 Hardware Switching Information	44-24
Displaying IPv4 CoPP Information	44-25
Source-Specific Multicast with IGMPv3, IGMP v3lite, and URD	44-26
Configuring IPv4 Bidirectional PIM	44-26
Enabling IPv4 Bidirectional PIM Globally	44-27
Configuring the Rendezvous Point for IPv4 Bidirectional PIM Groups	44-27
Displaying IPv4 Bidirectional PIM Information	44-27
Using IPv4 Debug Commands	44-31
Redundancy for Multicast Traffic	44-31
IGMP Snooping for IPv4 Multicast Traffic	45-1
Prerequisites for IGMP Snooping	45-1
Restrictions for IGMP Snooping	45-1
General IGMP Snooping Restrictions	45-2
IGMP Snooping Querier Restrictions	45-2

Information About IGMP Snooping	45-2
IGMP Snooping Overview	45-3
Joining a Multicast Group	45-3
Leaving a Multicast Group	45-5
Information about the IGMP Snooping Querier	45-6
Information about IGMP Version 3 Support	45-6
Default Settings for IGMP Snooping	45-8
How to Configure IGMP Snooping	45-8
Enabling the IGMP Snooping Querier	45-9
Enabling IGMP Snooping	45-9
Configuring the IGMP Snooping Lookup Method	45-11
Configuring a Static Connection to a Multicast Receiver	45-11
Configuring a Multicast Router Port Statically	45-12
Configuring the IGMP Snooping Query Interval	45-12
Enabling IGMP Snooping Immediate-Leave Processing	45-13
Configuring IGMPv3 Snooping Explicit Host Tracking	45-13
Displaying IGMP Snooping Information	45-14
 PIM Snooping	 46-1
Prerequisites for PIM Snooping	46-1
Restrictions for PIM Snooping	46-2
Information About PIM Snooping	46-2
Default Settings for PIM Snooping	46-4
How to Configure PIM Snooping	46-5
Enabling PIM Snooping Globally	46-5
Enabling PIM Snooping in a VLAN	46-5
Disabling PIM Snooping Designated-Router Flooding	46-6
 Multicast VLAN Registration (MVR)	 47-1
Restrictions for MVR	47-1
Restrictions for MVR	47-1
Information About MVR	47-2
MVR Overview	47-2
Using MVR in a Multicast Television Application	47-3
Default MVR Configuration	47-5
How to Configure MVR	47-5
Configuring MVR Global Parameters	47-5
Configuring MVR Interfaces	47-6
Clearing MVR Counters	47-8

Displaying MVR Information 47-8

IPv4 IGMP Filtering 48-1

Prerequisites for IGMP Filtering 48-1

Restrictions for IGMP Filtering 48-1

Information About IGMP Filtering 48-2

IGMP Filtering Overview 48-3

IGMP Filter Precedence 48-4

Default Settings for IGMP Filtering 48-4

How to Configure IGMP Filters 48-4

Configuring IGMP Group and Channel Access Control 48-4

Configuring IGMP Group and Channel Limits 48-5

Configuring IGMP Version Filtering 48-5

Clearing IGMP Filtering Statistics 48-6

Verifying the IGMP Filtering Configuration 48-6

Displaying IGMP Filtering Configuration 48-6

Displaying IGMP Filtering Statistics 48-7

Configuration Examples for IGMP Filtering 48-8

IPv4 Router Guard 49-1

Prerequisites for Router Guard 49-1

Restrictions for Router Guard 49-1

Information About Router Guard 49-2

Default Settings for Router Guard 49-2

How to Configure Router Guard 49-2

Enabling Router Guard Globally 49-3

Disabling Router Guard on Ports 49-3

Clearing Router Guard Statistics 49-3

Verifying the Router Guard Configuration 49-4

Displaying Router Guard Configuration 49-4

Displaying Router Guard Interfaces 49-5

IPv4 Multicast VPN Support 50-1

Prerequisites for mVPNs 50-1

Restrictions for mVPNs 50-1

General Restrictions 50-2

mVPN with L3VPN over mGRE Restrictions 50-3

Information About mVPN 50-3

mVPN Overview 50-3

Multicast Routing and Forwarding and Multicast Domains	50-4
Multicast Distribution Trees	50-4
Multicast Tunnel Interfaces	50-7
PE Router Routing Table Support for mVPN	50-8
Multicast Distributed Switching Support	50-8
Hardware-Assisted IPv4 Multicast	50-8
Information About mVPN with L3VPN over mGRE	50-9
Default Settings for mVPNs	50-10
How to Configure mVPNs	50-11
Configuring a Multicast VPN Routing and Forwarding Instance	50-11
Configuring Multicast VRF Routing	50-16
Configuring Interfaces for Multicast Routing to Support mVPN	50-20
Configuring mVPN with L3VPN over mGRE	50-22
Configuration Examples for mVPNs	50-27
mVPN Configuration with Default MDTs Only	50-27
mVPN Configuration with Default and Data MDTs	50-29
Verifying the mVPN with L3VPN over mGRE Configuration	50-32
Configuration Sequence for mVPN with L3VPN over mGRE	50-33
IPv6 Multicast Support	51-1
Prerequisites for IPv6 Multicast	51-1
Restrictions for IPv6 Multicast	51-1
Information About IPv6 Multicast Support	51-2
Hardware-Supported IPv6 Layer 3 Multicast Features	51-2
Partially Hardware-Supported IPv6 Layer 3 Multicast Features	51-3
Software-Supported IPv6 Layer 3 Multicast Features	51-3
Unsupported IPv6 Layer 3 Multicast Features	51-3
How to Configure IPv6 Multicast Support	51-4
Verifying the IPv6 Multicast Layer 3 Configuration	51-4
Verifying MFIB Clients	51-5
Displaying the Switching Capability	51-5
Verifying the (S,G) Forwarding Capability	51-5
Verifying the (*,G) Forwarding Capability	51-5
Verifying the Subnet Entry Support Status	51-5
Verifying the Current Replication Mode	51-5
Displaying the Replication Mode Auto-Detection Status	51-5
Displaying the Replication Mode Capabilities	51-6
Displaying Subnet Entries	51-6
Displaying the IPv6 Multicast Summary	51-6

Displaying the NetFlow Hardware Forwarding Count	51-7
Displaying the FIB Hardware Bridging and Drop Counts	51-7
Displaying the Shared and Well-Known Hardware Adjacency Counters	51-8
IPv6 MLD Snooping	52-1
Prerequisites for MLD Snooping	52-1
Restrictions for MLD Snooping	52-2
General MLD Snooping Restrictions	52-2
MLD Snooping Querier Restrictions	52-2
Information About MLD Snooping	52-3
MLD Snooping Overview	52-3
MLD Messages	52-4
Source-Based Filtering	52-4
Explicit Host Tracking	52-4
MLD Snooping Proxy Reporting	52-5
Joining an IPv6 Multicast Group	52-5
Leaving a Multicast Group	52-7
Information about the MLD Snooping Querier	52-8
Default MLD Snooping Configuration	52-9
How to Configure MLD Snooping	52-9
Enabling the MLD Snooping Querier	52-10
Configuring the MLD Snooping Query Interval	52-10
Enabling MLD Snooping	52-11
Configuring a Static Connection to a Multicast Receiver	52-12
Configuring a Multicast Router Port Statically	52-12
Enabling Fast-Leave Processing	52-12
Enabling SSM Safe Reporting	52-13
Configuring Explicit Host Tracking	52-13
Configuring Report Suppression	52-14
Verifying the MLD Snooping Configuration	52-14
NetFlow Hardware Support	53-1
Prerequisites for NetFlow Hardware Support	53-1
Restrictions for NetFlow Hardware Support	53-1
Information About NetFlow Hardware Support	53-2
Default Settings for NetFlow Hardware Support	53-2
How to Configure NetFlow Hardware Support	53-2
Configuring Inactive Flow Aging	53-3
Configuring Fast Aging	53-3

Configuring Active Flow Aging	53-4
Verifying the NetFlow Table Aging Configuration	53-4
System Event Archive (SEA)	54-1
Information About the System Event Archive	54-1
How to Display the SEA Logging System	54-2
How to Copy the SEA To Another Device	54-3
Backplane Traffic Monitoring	55-1
Prerequisites for Backplane Traffic Monitoring	55-1
Restrictions for Backplane Traffic Monitoring	55-2
Information About Traffic Monitoring	55-2
Default Settings for Backplane Traffic Monitoring	55-2
How to Configure Backplane Traffic Monitoring	55-3
Local SPAN, RSPAN, and ERSPAN	56-1
Prerequisites for Local SPAN, RSPAN, and ERSPAN	56-1
Restrictions for Local SPAN, RSPAN, and ERSPAN	56-2
Feature Incompatibilities	56-2
Local SPAN, RSPAN, and ERSPAN Session Limits	56-3
Local SPAN, RSPAN, and ERSPAN Interface Limits	56-3
General Restrictions for Local SPAN, RSPAN, and ERSPAN	56-3
Restrictions for VSPAN	56-5
Restrictions for RSPAN	56-5
Restrictions for ERSPAN	56-6
Restrictions for Distributed Egress SPAN Mode	56-7
Information About Local SPAN, RSPAN, and ERSPAN	56-7
Local SPAN, RSPAN, and ERSPAN Overview	56-7
Local SPAN, RSPAN, and ERSPAN Sources	56-11
Local SPAN, RSPAN, and ERSPAN Destinations	56-12
Default Settings for Local SPAN, RSPAN, and ERSPAN	56-12
How to Configure Local SPAN, RSPAN, and ERSPAN	56-12
Configuring a Destination as an Unconditional Trunk (Optional)	56-13
Configuring Destination Trunk VLAN Filtering (Optional)	56-13
Configuring Destination Port Permit Lists (Optional)	56-15
Configuring the Egress SPAN Mode (Optional)	56-15
Configuring Local SPAN	56-16
Configuring RSPAN	56-20
Configuring ERSPAN	56-26

Configuring Source VLAN Filtering in Global Configuration Mode	56-30
Verifying the SPAN Configuration	56-31
Configuration Examples for SPAN	56-31
SNMP IfIndex Persistence	57-1
Prerequisites for SNMP IfIndex Persistence	57-1
Restrictions for SNMP IfIndex Persistence	57-1
Information About SNMP IfIndex Persistence	57-2
Default Settings for SNMP IfIndex Persistence	57-2
How to Configure SNMP IfIndex Persistence	57-2
Enabling SNMP IfIndex Persistence Globally	57-2
Disabling SNMP IfIndex Persistence Globally	57-3
Enabling and Disabling SNMP IfIndex Persistence on Specific Interfaces	57-3
Clearing SNMP IfIndex Persistence Configuration from a Specific Interface	57-4
Top-N Reports	58-1
Prerequisites for Top-N Reports	58-1
Restrictions for Top-N Reports	58-1
Information About Top-N Reports	58-2
Top-N Reports Overview	58-2
Top-N Reports Operation	58-2
Default Settings for Top-N Reports	58-3
How to Use Top-N Reports	58-3
Enabling Top-N Reports Creation	58-3
Displaying Top-N Reports	58-4
Clearing Top-N Reports	58-5
Layer 2 Traceroute Utility	59-1
Prerequisites for the Layer 2 Traceroute Utility	59-1
Restrictions for the Layer 2 Traceroute Utility	59-1
Information About the Layer 2 Traceroute Utility	59-2
How to Use the Layer 2 Traceroute Utility	59-3
Mini Protocol Analyzer	60-1
Prerequisites for the Mini Protocol Analyzer	60-1
Restrictions for the Mini Protocol Analyzer	60-1
Information About the Mini Protocol Analyzer	60-2
How to Configure the Mini Protocol Analyzer	60-2
Configuring a Capture Session	60-2

Filtering the Packets to be Captured	60-4
Starting and Stopping a Capture	60-5
Displaying and Exporting the Capture Buffer	60-7
Configuration Examples for the Mini Protocol Analyzer	60-7
General Configuration Examples	60-8
Filtering Configuration Examples	60-9
Operation Examples	60-10
Display Examples	60-10
Restrictions for PFC QoS	61-1
General Guidelines	61-2
PFC and DFC Guidelines	61-4
Class Map Command Restrictions	61-5
Policy Map Class Command Restrictions	61-5
Supported Granularity for CIR and PIR Rate Values	61-5
Supported Granularity for CIR and PIR Token Bucket Sizes	61-6
IP Precedence and DSCP Values	61-7
PFC QoS Overview	62-1
Classification, Marking, and Policing	63-1
Information About Classification, Marking, and Policing Policies	63-1
Classification, Marking, and Policing Policy Overview	63-1
Traffic Classification	63-2
Traffic Marking	63-3
Information about Policing	63-4
How to Configure Classification, Marking, and Policing Policies	63-7
Enabling Distributed Aggregate Policing	63-7
Configuring a Class Map	63-8
Configuring a Policy Map	63-9
Attaching a Policy Map to an Interface	63-17
Configuring Dynamic Per-Session Attachment of a Policy Map	63-19
Policy-Based Queueing	64-1
Prerequisites for Policy-Based Queueing	64-1
Restrictions for Policy-Based Queueing	64-2
Information About Policy-Based Queueing	64-4
Port-Based Queue Types	64-4
Queueing Policies	64-8
How to Configure Policy-Based Queueing	64-10

Configuring a Queuing Policy Class Map	64-11
Verifying a Queuing Policy Class Map	64-11
Configuring Queueing Policy Maps	64-11
Verifying a Queuing Policy Map	64-17
Attaching a Queuing Policy Map to an Interface	64-17
Configuration Examples for Policy-Based Queueing	64-18
Queueing Policy Sample Configuration	64-18
Queueing Policy Commands Supported by Each Queue Type	64-19
Queueing Policy Commands Sample Configurations for Each Queue Type	64-33
Queueing on FEX	64-45
QoS Global and Interface Options	65-1
How to Configure the Ingress LAN Port CoS Value	65-2
How to Configure Egress DSCP Mutation	65-3
Configuring Named DSCP Mutation Maps	65-3
Attaching an Egress DSCP Mutation Map to an Interface	65-4
How to Configure Ingress CoS Mutation on IEEE 802.1Q Tunnel Ports	65-4
Ingress CoS Mutation Configuration Guidelines and Restrictions	65-4
Configuring Ingress CoS Mutation Maps	65-6
Applying Ingress CoS Mutation Maps to IEEE 802.1Q Tunnel Ports	65-6
How to Configure DSCP Value Maps	65-7
Mapping Received CoS Values to Internal DSCP Values	65-7
Mapping Received IP Precedence Values to Internal DSCP Values	65-7
Configuring DSCP Markdown Values	65-8
Mapping Internal DSCP Values to Egress CoS Values	65-9
How to Configure Trusted Boundary with Cisco Device Verification	65-10
Legacy Configuration Procedures for Queueing-Only Mode	65-11
Legacy Configuration Procedures for VLAN-Based PFC QoS on Layer 2 LAN Ports	65-12
Legacy Configuration Procedures for Port Trust State	65-13
Legacy Configuration Procedures for DSCP-Based Queue Mapping	65-14
Enabling DSCP-Based Queue Mapping	65-14
Configuring Ingress DSCP-Based Queue Mapping	65-15
Mapping DSCP Values to Standard Receive-Queue Thresholds	65-15
Mapping DSCP Values to Standard Transmit-Queue Thresholds	65-16
Mapping DSCP Values to the Transmit Strict-Priority Queue	65-18
AutoQoS	66-1
Prerequisites for AutoQoS	66-1
Restrictions for AutoQoS	66-2

Information About AutoQoS	66-2
AutoQoS Support for a Cisco IP Phone	66-3
AutoQoS Support for Cisco IP Communicator	66-3
AutoQoS Support for Marked Traffic	66-4
Default Settings for AutoQoS	66-4
How to Configure AutoQoS	66-4
Configuring AutoQoS Support for a Cisco IP Phone	66-5
Configuring AutoQoS Support for Cisco IP Communicator	66-6
Configuring AutoQoS Support for Marked Traffic	66-7
MPLS QoS	67-1
Terminology	67-2
MPLS QoS Features	67-2
MPLS Experimental Field	67-3
Trust	67-3
Classification	67-3
Policing and Marking	67-3
Preserving IP ToS	67-4
EXP Mutation	67-4
MPLS DiffServ Tunneling Modes	67-4
MPLS QoS Overview	67-4
Specifying the QoS in the IP Precedence Field	67-4
MPLS QoS	67-5
MPLS Topology Overview	67-5
LERs at the Input Edge of an MPLS Network	67-6
LSRs in the Core of an MPLS Network	67-6
LERs at the Output Edge of an MPLS Network	67-7
LERs at the EoMPLS Edge	67-7
LERs at the IP Edge (MPLS, MPLS VPN)	67-8
LSRs at the MPLS Core	67-11
MPLS QoS Default Configuration	67-13
MPLS QoS Commands	67-15
MPLS QoS Restrictions	67-15
How to Configure MPLS QoS	67-16
Enabling Queueing-Only Mode	67-17
Configuring a Class Map to Classify MPLS Packets	67-17
Configuring a Policy Map	67-20
Displaying a Policy Map	67-24
Configuring MPLS QoS Egress EXP Mutation	67-24

Configuring EXP Value Maps	67-25
MPLS DiffServ Tunneling Modes	67-26
Short Pipe Mode	67-27
Uniform Mode	67-28
MPLS DiffServ Tunneling Restrictions and Usage Guidelines	67-30
How to Configure Short Pipe Mode	67-30
Ingress PE Router—Customer Facing Interface	67-30
Configuring Ingress PE Router—P Facing Interface	67-32
Configuring the P Router—Output Interface	67-33
Configuring the Egress PE Router—Customer Facing Interface	67-34
How to Configure Uniform Mode	67-34
Configuring the Ingress PE Router—Customer Facing Interface	67-35
Configuring the Ingress PE Router—P Facing Interface	67-36
Configuring the Egress PE Router—Customer Facing Interface	67-37
PFC QoS Statistics Data Export	68-1
Prerequisites for PFC QoS Statistics Data Export	68-1
Restrictions for PFC QoS Statistics Data Export	68-1
Information About PFC QoS Statistics Data Export	68-2
Default Settings for PFC QoS Statistics Data Export	68-2
How to Configure PFC QoS Statistics Data Export	68-2
Cisco IOS ACL Support	69-1
Restrictions for Cisco IOS ACLs	69-1
Restrictions for Layer 4 Operators in ACLs	69-2
Determining Layer 4 Operation Usage	69-2
Determining Logical Operation Unit Usage	69-3
Information About ACL Support	69-4
Policy-Based ACLs (PBACLs)	69-5
Restrictions for PBACLs	69-6
Information about PBACLs	69-6
How to Configure PBACLs	69-6
MAC ACLs	69-9
How to Configure Protocol-Independent MAC ACL Filtering	69-9
How to Enable VLAN-Based MAC QoS Filtering	69-10
ARP ACLs	69-12
Optimized ACL Logging	69-13
Restrictions for OAL	69-13
Information about OAL	69-13

How to Configure OAL	69-13
Dry Run Support for ACLs	69-15
Restrictions for Dry Run Support	69-15
Information About Dry Run Support	69-16
How to Configure Dry Run Support for ACLs	69-16
Hardware ACL Statistics	69-17
Restrictions for Hardware ACL Statistics	69-17
Information About Hardware ACL Statistics	69-17
How to Configure Hardware ACL Statistics	69-18
Cisco TrustSec (CTS)	70-1
Hardware Supported	70-4
AutoSecure	71-1
Prerequisites for AutoSecure	71-1
Restrictions for AutoSecure	71-2
Information About AutoSecure	71-2
AutoSecure Overview	71-2
Management Plane Security Enabled by AutoSecure	71-3
Forwarding Plane Security Enabled by AutoSecure	71-6
How to Configure AutoSecure	71-7
Configuring AutoSecure Parameters	71-7
Configuring Additional Security	71-8
Verifying AutoSecure	71-8
Examples for AutoSecure Configuration	71-9
MAC Address-Based Traffic Blocking	72-1
Port ACLs (PACLs)	73-1
Prerequisites for PACls	73-1
Restrictions for PACls	73-2
Information About PACls	73-2
PACL Overview	73-2
EtherChannel and PACL Interactions	73-3
Dynamic ACLs (Applies to Merge Mode Only)	73-4
Trunk Ports	73-4
Layer 2 to Layer 3 Port Conversion	73-4
Port-VLAN Association Changes	73-4
PACL and VACL Interactions	73-4
How to Configure PACls	73-7

Configuring IP and MAC ACLs on a Layer 2 Interface	73-7
Configuring Access-group Mode on Layer 2 Interface	73-8
Applying ACLs to a Layer 2 Interface	73-8
Applying ACLs to a Port Channel	73-9
Displaying an ACL Configuration on a Layer 2 Interface	73-9
VLAN ACLs (VACLs)	74-1
Prerequisites for VACLs	74-1
Restrictions for VACLs	74-2
Information About VACLs	74-2
How to Configure VACLs	74-3
Defining a VLAN Access Map	74-3
Configuring a Match Clause in a VLAN Access Map Sequence	74-3
Configuring an Action Clause in a VLAN Access Map Sequence	74-4
Applying a VLAN Access Map	74-4
Verifying VLAN Access Map Configuration	74-5
VLAN Access Map Configuration and Verification Examples	74-5
Configuring a Capture Port	74-6
Configuring VACL Logging	74-7
Policy-Based Forwarding (PBF)	75-1
Prerequisites for PBF	75-1
Restrictions for PBF	75-2
Information About PBF	75-2
Default Settings for PBF	75-2
How to Configure PBF	75-2
Monitoring PBF	75-3
Configuration Examples for PBF	75-3
Denial of Service (DoS) Protection	76-1
Security ACLs and VACLs	76-2
QoS Rate Limiting	76-2
Global Protocol Packet Policing	76-3
Prerequisites for Global Protocol Packet Policing	76-3
Restrictions for Global Protocol Packet Policing	76-3
Information About Global Protocol Packet Policing	76-5
How to Configure Single-Command Global Protocol Packet Policing	76-5
How to Configure Policy-Based Global Protocol Packet Policing	76-6
Unicast Reverse Path Forwarding (uRPF) Check	76-6

Prerequisites for uRPF Check	76-7
Restrictions for uRPF Check	76-7
Information about uRPF Check	76-7
How to Configure Unicast RPF Check	76-8
Configuring Sticky ARP	76-9
Monitoring Packet Drop Statistics	76-10
Prerequisites for Packet Drop Statistics	76-10
Restrictions for Packet Drop Statistics	76-10
Information About Packet Drop Statistics	76-10
How to Monitor Dropped Packets	76-10
Control Plane Policing (CoPP)	77-1
Prerequisites for CoPP	77-1
Restrictions for CoPP	77-2
Information About CoPP	77-3
Default Settings for CoPP	77-3
How to Configure CoPP	77-5
Configuring CoPP	77-5
Defining CoPP Traffic Classification	77-6
Monitoring CoPP	77-9
Dynamic Host Configuration Protocol (DHCP) Snooping	78-1
Prerequisites for DHCP Snooping	78-1
Restrictions for DHCP Snooping	78-2
DHCP Snooping Configuration Restrictions	78-2
DHCP Snooping Configuration Guidelines	78-2
Minimum DHCP Snooping Configuration	78-3
Information About DHCP Snooping	78-3
Overview of DHCP Snooping	78-4
Trusted and Untrusted Sources	78-4
DHCP Snooping Binding Database	78-5
Packet Validation	78-5
DHCP Snooping Option-82 Data Insertion	78-5
Overview of the DHCP Snooping Database Agent	78-7
Default Configuration for DHCP Snooping	78-8
How to Configure DHCP Snooping	78-9
Enabling DHCP Snooping Globally	78-9
Enabling DHCP Option-82 Data Insertion	78-10
Enabling the DHCP Option-82 on Untrusted Port Feature	78-10

Enabling DHCP Snooping MAC Address Verification	78-11
Enabling DHCP Snooping on VLANs	78-11
Configuring the DHCP Trust State on Layer 2 LAN Interfaces	78-12
Configuring Spurious DHCP Server Detection	78-13
Configuring DHCP Snooping Rate Limiting on Layer 2 LAN Interfaces	78-14
The DHCP Snooping Database Agent	78-14
Displaying the DHCP Snooping Binding Table	78-18
IP Source Guard	79-1
Prerequisites for IP Source Guard	79-1
Restrictions for IP Source Guard	79-2
Information About IP Source Guard	79-2
Overview of IP Source Guard	79-2
IP Source Guard Interaction with VLAN-Based Features	79-2
Channel Ports	79-3
Layer 2 and Layer 3 Port Conversion	79-3
IP Source Guard and Voice VLAN	79-3
IP Source Guard and Web-Based Authentication	79-3
Default Settings for IP Source Guard	79-3
How to Configure IP Source Guard	79-3
Displaying IP Source Guard PACL Information	79-5
Displaying IP Source Binding Information	79-6
Dynamic ARP Inspection (DAI)	80-1
Prerequisites for DAI	80-1
Restrictions for DAI	80-2
Information About DAI	80-3
Information about ARP	80-3
ARP Spoofing Attacks	80-3
DAI and ARP Spoofing Attacks	80-4
Interface Trust States and Network Security	80-4
Rate Limiting of ARP Packets	80-5
Relative Priority of ARP ACLs and DHCP Snooping Entries	80-6
Logging of Dropped Packets	80-6
Default Settings for DAI	80-6
How to Configure DAI	80-7
Enabling DAI on VLANs	80-7
Configuring DAI Hardware Acceleration	80-8
Configuring the DAI Interface Trust State	80-8

Applying ARP ACLs for DAI Filtering	80-9
Configuring ARP Packet Rate Limiting	80-10
Enabling DAI Error-Disabled Recovery	80-11
Enabling Additional Validation	80-11
Configuring DAI Logging	80-13
Displaying DAI Information	80-15
Configuration Examples for DAI	80-16
Two Switches Support DAI	80-16
One Switch Supports DAI	80-21
Traffic Storm Control	81-1
Prerequisites for Traffic Storm Control	81-1
Restrictions for Traffic Storm Control	81-2
Information About Traffic Storm Control	81-2
Default Setting for Traffic Storm Control	81-4
How to Enable Traffic Storm Control	81-4
Displaying Traffic Storm Control Settings	81-5
Unknown Unicast and Multicast Flood Control	82-1
Prerequisites for Unknown Traffic Flood Control	82-1
Restrictions for Unknown Traffic Flood Control	82-2
Information About Unknown Traffic Flood Control	82-2
Default Settings for Unknown Traffic Flood Control	82-2
How to Configure Unknown Traffic Flood Control	82-2
How to Configure UUFB or UMFB	82-2
How to Configure UUFRL	82-3
Configuration Examples for Unknown Traffic Flood Control	82-3
83-1	
IEEE 802.1X Port-Based Authentication	83-1
Prerequisites for 802.1X Authentication	83-1
Restrictions for 802.1X Authentication	83-2
802.1X Authentication	83-2
802.1X Host Mode	83-3
VLAN Assignment, Guest VLAN, Restricted VLAN, and Inaccessible Authentication Bypass	83-3
MAC Authentication Bypass	83-5
Web-Based Authentication	83-5
Network Edge Access Topology (NEAT) and Client Information Signalling Protocol (CISP)	83-5
Information About 802.1X Port-Based Authentication	83-6

802.1X Overview	83-6
802.1X Device Roles	83-7
Port-based Authentication Process	83-8
Authentication Initiation and Message Exchange	83-10
Ports in Authorized and Unauthorized States	83-12
802.1X Host Modes	83-13
802.1X Authentication with DHCP Snooping	83-15
802.1X Accounting	83-16
802.1X Authentication with VLAN Assignment	83-17
Multiple VLANs and VLAN User Distribution with VLAN Assignment	83-18
802.1X Authentication with Guest VLAN	83-19
802.1X Authentication with Restricted VLAN	83-20
802.1X Authentication with Inaccessible Authentication Bypass	83-21
802.1X Authentication with Voice VLAN Ports	83-22
802.1X Authentication with Port Security	83-23
802.1X Authentication with ACL Assignments and Redirect URLs	83-23
802.1X Authentication with Port Descriptors	83-26
802.1X Authentication with MAC Authentication Bypass	83-26
Network Admission Control Layer 2 IEEE 802.1X Validation	83-27
802.1X Authentication with Wake-on-LAN	83-28
MAC Move	83-28
MAC Replace	83-29
802.1x Supplicant and Authenticator Switches with Network Edge Access Topology (NEAT)	83-30
Default Settings for 802.1X Port-Based Authentication	83-31
How to Configure 802.1X Port-Based Authentication	83-32
Enabling 802.1X Authentication	83-33
Configuring Switch-to-RADIUS-Server Communication	83-34
Configuring 802.1X Authenticator Host Mode	83-35
Enabling Fallback Authentication	83-36
Enabling Periodic Reauthentication	83-38
Manually Reauthenticating the Client Connected to a Port	83-39
Initializing Authentication for the Client Connected to a Port	83-39
Removing 802.1X Client Information Globally	83-40
Removing 802.1X Client Information from an Interface	83-40
Clearing Authentication Sessions	83-40
Changing 802.1X Timeouts	83-40
Setting the Switch-to-Client Frame Retransmission Number	83-42
Setting the Reauthentication Number	83-43
Configuring IEEE 802.1X Accounting	83-43
Configuring VLAN User Distribution	83-44

Configuring a Guest VLAN	83-45
Configuring a Restricted VLAN	83-46
Configuring the Inaccessible Authentication Bypass Feature	83-47
Configuring MAC Authentication Bypass	83-49
Configuring NAC Layer 2 IEEE 802.1X Validation	83-50
Configuring NAC Agentless Audit Support	83-51
Configuring the Switch for DACLs or Redirect URLs	83-51
Configuring 802.1X Authentication with WoL	83-52
Enabling MAC Move	83-53
Enabling MAC Replace	83-53
Configuring NEAT Authenticator and Supplicant Switches	83-54
Disabling 802.1X Authentication on the Port	83-56
Resetting the 802.1X Configuration to the Default Values	83-57
Displaying Authentication Status and Information	83-57
Displaying 802.1X Status	83-57
Displaying Authentication Methods and Status	83-58
Displaying MAC Authentication Bypass Status	83-61
Web-Based Authentication	84-1
Prerequisites for Web-based Authentication	84-1
Restrictions for Web-based Authentication	84-1
Information About Web-Based Authentication	84-2
Web-Based Authentication Overview	84-2
Device Roles	84-3
Host Detection	84-3
Session Creation	84-4
Authentication Process	84-4
AAA Fail Policy	84-5
Customization of the Authentication Proxy Web Pages	84-5
Web-based Authentication Interactions with Other Features	84-5
Default Web-Based Authentication Configuration	84-7
How to Configure Web-Based Authentication	84-7
Web-based Authentication Configuration Task List	84-8
Configuring the Authentication Rule and Interfaces	84-8
Configuring AAA Authentication	84-9
Configuring Switch-to-RADIUS-Server Communication	84-9
Configuring the HTTP Server	84-11
Configuring an AAA Fail Policy	84-13
Configuring the Web-based Authentication Parameters	84-14

Removing Web-based Authentication Cache Entries	84-14
Displaying Web-Based Authentication Status	84-15
Port Security	85-1
Prerequisites for Port Security	85-1
Restrictions for Port Security	85-1
Information About Port Security	85-2
Port Security with Dynamically Learned and Static MAC Addresses	85-3
Port Security with Sticky MAC Addresses	85-3
Port Security with IP Phones	85-4
Default Port Security Configuration	85-4
How to Configure Port Security	85-4
Enabling Port Security	85-4
Configuring the Port Security Violation Mode on a Port	85-6
Configuring the Maximum Number of Secure MAC Addresses on a Port	85-7
Enabling Port Security with Sticky MAC Addresses on a Port	85-8
Configuring a Static Secure MAC Address on a Port	85-8
Configuring Secure MAC Address Aging on a Port	85-9
Verifying the Port Security Configuration	85-10
Lawful Intercept	86-1
Prerequisites for Lawful Intercept	86-1
Restrictions for Lawful Intercept	86-1
General Configuration Restrictions	86-2
MIB Guidelines	86-3
Information About Lawful Intercept	86-3
Lawful Intercept Overview	86-4
Benefits of Lawful Intercept	86-4
CALEA for Voice	86-5
Network Components Used for Lawful Intercept	86-5
Lawful Intercept Processing	86-7
Lawful Intercept MIBs	86-7
How to Configure Lawful Intercept Support	86-9
Security Considerations	86-9
Accessing the Lawful Intercept MIBs	86-9
Restricting Access to the Lawful Intercept MIBs	86-10
Configuring SNMPv3	86-10
Online Diagnostic Tests	1-1
Global Health-Monitoring Tests	1-2

TestAsicSync	1-2
TestEARLInternalTables	1-3
TestErrorCounterMonitor	1-3
TestFexModeLoopback	1-4
TestIntPortLoopback	1-4
TestL3TcamMonitoring	1-4
TestLtlFpoeMemoryConsistency	1-5
TestMacNotification	1-6
TestPortTxMonitoring	1-6
TestScratchRegister	1-7
TestSnrMonitoring	1-7
TestUnusedPortLoopback	1-8
Per-Port Tests	1-8
TestActiveToStandbyLoopback	1-9
TestCCPLoopback	1-9
TestDataPortLoopback	1-10
TestDCPLoopback	1-10
TestL2CTSLoopback	1-11
TestL3CTSLoopback	1-11
TestLoopback	1-12
TestMediaLoopback	1-12
TestMgmtPortsLoopback	1-13
TestNetflowInlineRewrite	1-13
TestNonDisruptiveLoopback	1-14
TestNPLoopback	1-14
TestTransceiverIntegrity	1-15
PFC Layer 2 Tests	1-15
TestBadBpduTrap	1-15
TestDontConditionalLearn	1-16
TestMatchCapture	1-16
TestNewIndexLearn	1-17
DFC Layer 2 Tests	1-17
TestBadBpdu	1-18
TestCapture	1-18
TestConditionalLearn	1-19
TestDontLearn	1-19
TestIndexLearn	1-20
TestNewLearn	1-20
TestPortSecurity	1-21

TestProtocolMatchChannel	1-21
TestStaticEntry	1-22
TestTrap	1-22
PFC Layer 3 Tests	1-22
TestAclDeny	1-23
TestAclPermit	1-23
TestAclRedirect	1-24
TestDQUP	1-24
TestInbandEdit	1-25
TestIPv4FibShortcut	1-25
TestIPv6FibShortcut	1-26
TestL3Capture2	1-26
TestMPLSFibShortcut	1-27
TestNATFibShortcut	1-27
TestNetflowShortcut	1-28
TestRBAcl	1-28
DFC Layer 3 Tests	1-28
TestAclDeny	1-29
TestAclPermit	1-29
TestAclRedirect	1-30
TestInbandEdit	1-30
TestIPv4FibShortcut	1-31
TestIPv6FibShortcut	1-31
TestL3Capture2	1-32
TestMPLSFibShortcut	1-32
TestNATFibShortcut	1-33
TestNetflowShortcut	1-33
TestRBAcl	1-34
Replication Engine Tests	1-34
TestEgressSpan	1-34
TestIngressSpan	1-35
TestL3VlanMet	1-35
Fabric Tests	1-35
TestFabricCh0Health	1-36
TestFabricCh1Health	1-36
TestFabricExternalSnake	1-37
TestFabricFlowControlStatus	1-37
TestFabricInternalSnake	1-38
TestFabricVlanLoopback	1-38

TestFexFabricLinkStatus	1-39
TestSynchedFabChannel	1-39
Exhaustive Memory Tests	1-39
TestAclQosTcam	1-40
TestAsicMemory	1-40
TestEarlMemOnBootup	1-41
Service Module Tests	1-41
TestPcLoopback	1-41
TestPortASICLoopback	1-42
Stress Tests	1-42
TestEobcStressPing	1-42
TestMicroburst	1-43
TestNVRAMBatteryMonitor	1-43
TestTrafficStress	1-44
General Tests	1-44
ScheduleSwitchover	1-44
TestCFRW	1-45
TestFirmwareDiagStatus	1-45
TestOBFL	1-45
TestRwEngineOverSubscription	1-46
TestVDB	1-46
Critical Recovery Tests	1-46
TestTxPathMonitoring	1-47
ViSN Tests	1-47
TestRslHm	1-47
TestVSActiveToStandbyLoopback	1-48
TestVslBridgeLink	1-48
TestVslLocalLoopback	1-49
TestVslStatus	1-49



Preface

This preface describes who should read the *Supervisor Engine 2T Software Configuration Guide*, Release 15.1SY, and its document conventions.

Audience

This guide is for experienced network administrators who are responsible for configuring and maintaining the switches supported in Cisco IOS Release 15.4SY.

Related Documentation

See the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

For information about MIBs, go to this URL:

<http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>

Conventions

This document uses the following conventions:

Convention	Description
boldface font	Commands, command options, and keywords are in boldface .
<i>italic</i> font	Arguments for which you supply values are in <i>italics</i> .
[]	Elements in square brackets are optional.
{ x y z }	Alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
u <code>etg</code> gp font	Terminal sessions and information the system displays are in u <code>etg</code> gp font.

Convention	Description
boldface screen font	Information you must enter is in boldface screen font .
<i>italic screen font</i>	Arguments for which you supply values are in <i>italic screen font</i> .
→	Vjku"rqkpvgt"jkijnkijvu"cp"korqtvcpv"nkpq"qh"vgzv"kp"cp"gzcorng0
^	The symbol ^ represents the key labeled Control—for example, the key combination ^D in a screen display means hold down the Control key while you press the D key.
< >	Nonprinting characters, such as passwords are in angle brackets.

Notes use the following conventions:



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the publication.

Cautions use the following conventions:



Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Obtaining Documentation, Obtaining Support, and Security Guidelines

For information on obtaining documentation, obtaining support, providing documentation feedback, security guidelines, and also recommended aliases and general Cisco documents, see the monthly *What's New* in Cisco Product Documentation, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>



Product Overview

- [Supervisor Engine 6T Ports, page 1-1](#)
- [LED Indicators, page 1-3](#)
- [Determining System Hardware Capacity, page 1-5](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- For complete information about the supported chassis, modules, and software features, see the *Release Notes for Cisco IOS Release 15.2SY*:
http://www.cisco.com/en/US/docs/switches/lan/catalyst6500/ios/15.1SY/release_notes.html
and see the Catalyst 6500 Series *Switch Supervisor Engine Guide*:



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:
http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html
[Participate in the Technical Documentation Ideas forum](#)

Supervisor Engine 6T Ports

USB Type A Port

The USB Type A port is the only external storage interface for this switch. The port is connected to the route processor, which allows the Cisco IOS software to access the port. The port supports Cisco USB flash drives with capacities from 128 MB to 8 GB (USB devices with port densities of 128 MB, 256 MB, 1 GB, 4 GB, and 8 GB are supported). Cisco IOS software provides standard file system access to the

flash device: read, write, erase, and copy. The software also provides the ability to format the flash device with a FAT file system (FAT32 and FAT16).

Addressing it : disk0:

Console ports

- EIA/TIA-232 (RS-232) port with RJ-45 connector
- USB port

RJ45: The console port is an RJ-45 port that provides universal asynchronous receiver/transmitter (UART) support to access the route processor with a serial console running at 9600 baud rate with 8 bits for data, no parity bit, and 1 stop bit.

USB Type B Port

The USB 2.0 port Type B serves as a second console connection to the route processor. The USB console port connection uses a USB Type A to Type B cable. The USB console interface speeds are the same as the RJ-45 console interface speeds. Windows PCs need a driver for the USB port.

The USB-prefer mode is the default, but it can be overridden using the command-line interface (CLI). When this port is in USB-prefer mode, the RJ-45 console port will be disabled if both ports are connected. For more information on using the CLI to configure the USB console interface, see the Catalyst 6500 software guide.

System Reset Button

This reset access button is used to reset the system. Pressing the button brings down the route processor and all port card modular slots.

Front Panel mode supports

- 10G*8 and 2*40G (Default mode)
- 10G*8 - 10Gigabit * 8 ports (Performance Mode)
- 40G*2 - 40Gigabit * 2 ports (Performance Mode)
- 10G*16 - 10Gigabit * 16 ports (Port Numbers ranging from: 1 to 8 and 11 to 18)

Management Port

The management port is a 10/100/1000 copper Ethernet port directly connected to the route processor. The switch also has a fiber port that can be used as the Ethernet Management port. It supports TFTP/SCP image downloading, network management, SNMP, Telnet, and SSH connections. The management port is isolated from other ports in the system in a dedicated management VRF; it is not part of the EARL forwarding logic. The management port provides direct access to the CPU, even when the system is heavily loaded.

The management port is a Layer 3 port in host mode, and only accepts traffic that terminates on the router. This port does not route packets between itself and other ports. The port processes only the following packet types and properly enqueues them:

- Address Resolution Protocol (ARP)
- IPv4 unicast
- Cisco Discovery Protocol (CDP)
- Link Layer Discovery Protocol (LLDP)

Management Port Operation Modes

The Ethernet management port (mgmt0) can be operated in the following modes:

- RJ45 (Default mode)
- SFP

To change from the default mode to SFP, run the following command:

```
Tqvwgt*eqphki+%kpV"oiOV2
Tqvwgt*eqphki/kh+%ogfkc/v{rg"A
"t167"Wug"TL67"eqppgevgt
"uhr"Wug"UHR"eqppgevgt

Tqvwgt*eqphki/kh+%ogfkc/v{rg"uh
Tqvwgt*eqphki/kh+%ogfkc/v{rg"uhr"
Tqvwgt*eqphki/kh+%
```

If media-type sfp is configured, the rommon variable SFP_MGMT=1 is configured. When the system is in rommon, the SFP operation mode functions.

If no media-type sfp or the default media-type configuration is performed, the rommon variable SFP_MGMT=1 is unconfigured. When the system is in rommon, the RJ45 operation mode functions.



Note

By default, mgmt0 port exists in the “no shutdown” mode.

LED Indicators

You can use the switch LEDs to monitor switch activity and performance. You can also monitor the status of the fan tray assembly, and the power supplies.

Status LED

The status LED indicates the status of the system.

Table 1-1 Status LED Indicator

Color/State	Description
Off	System is not operational.
Green	System is operating normally without alarms.
Amber	System has triggered a minor environmental alarm.
Red	System has triggered a major environmental alarm.

System ID LED

The System ID (blue beacon) LED can be provisioned by the operator to indicate that the switch needs attention.

Color/State	Description
Blinking Blue	The system needs attention.

Management Port LED

This table describes the management port LEDs.

Color/State	Description
Off	Port is not provisioned.
Amber	Port is provisioned, but administratively not operational.
Green	Port is linked up.
Alternating Green and Amber	A port fault is detected, or the port beacon has been provisioned by the operator.

Status LED

The status LED indicates the status of the system.

Color/State	Description
Off	System is not operational.
Green	System is operating normally without alarms.
Amber	System has triggered a minor environmental alarm.
Red	System has triggered a major environmental alarm.

System ID LED

The System ID (blue beacon) LED can be provisioned by the operator to indicate that the switch needs attention.

Color/State	Description
Blinking Blue	The system needs attention.

Determining System Hardware Capacity

You can determine the system hardware capacity by entering the **show platform hardware capacity** command. This command displays the current system utilization of the hardware resources and displays a list of the currently available hardware capacities, including the following:

- Hardware forwarding table utilization
- Switch fabric utilization
- CPU(s) utilization
- Memory device (flash, DRAM, NVRAM) utilization

This example shows how to display EOBC-related statistics for the route processor, the switch processor, and the DFCs:

Router#**show platform hardware capacity eobc**

```
GQDE"Tguqwtugu

"Oqfwng"*****"Rcemgvuluge"*****"Vqvcn"rcemgvu"*****"Ftqrgf"rcemgvu
"3"*****"Tz<"*****"59*****";49:36*****"3
*****"Vz<"*****"5:*****";59;53*****"2
"4"*****"Tz<"*****"43*****"6:3499*****"2
*****"Vz<"*****"43*****"6;3525*****"2
"5"TR*****"Tz<"*****"36:*****"5589;45*****"2
*****"Vz<"*****"368*****"555367:*****"2
"6"TR*****"Tz<"*****"3:*****"6;;879*****"2
*****"Vz<"*****"3:*****"6;928:*****"2
"7"*****"Tz<"*****"4*****"87:3:56*****"2
*****"Vz<"*****"4*****"326977*****"5
"9"*****"Tz<"*****"76*****"3497:88*****"2
*****"Vz<"*****"76*****"34:7427*****"2
```

This example shows how to display the current and peak switching utilization:

Router#**show platform hardware capacity cpu**

```
ERW"Tguqwtugu

"ERW"vwnk | cvkqp<"Oqfwng"*****"7"ugeqpfu"*****"3"okpwvg"*****"7"okpwvgu
*****"3*****";"1"2'*****";*****"32'
*****"4*****"8'"1"2'*****"6'*****"6'
*****"5"TR*****"5'"1"2'*****"6'*****"6'
*****"6"TR*****"3'"1"2'*****"3'*****"3'
*****"7*****"3'"1"3'*****"4'*****"4'
```

```

"9"3"1"2"4'
"Rtqeguqt"ogot{<"Oqfwng""D{vgu<"Vqvcn""Wugf""Wugf
"3"37:539:594"3;6:86242"34'
"4"37:539:594"39;5469:6"33'
"5"TR"458;628394"638769866"3:'
"6"TR"454;879742"598267546"38'
"7"5962:.86"38624;862"39'
"9"37:539:594"369559274";'
"KlQ"ogot{<"Oqfwng""D{vgu<"Vqvcn""Wugf""Wugf
"3"48:657678"56575:62"35'
"4"48:657678"56575:62"35'
"5"TR"68;98426:"4:28684;8"82'
"6"TR"68;98426:"4:28684;8"82'
"9"48:657678"56575;8"35'

```

This example shows how to display information about the total capacity, the bytes used, and the percentage that is used for the flash and NVRAM resources present in the system:

Router#show platform hardware capacity flash

```

HncujlPXTCO"Tguqwtugu
"Wucig<"Oqfwng"Fgxkeg""D{vgu<"Vqvcn""Wugf""Wugf
"3"fhe%3/dqqvfkm<"3233983374"3635;5;4"3'
"4"fhe%4/dqqvfkm<"3233983374"527:.;4:"5'
"5"TR"pxtco<"4924782"58798"3'
"5"TR"eqpuvapxtco<"326:778"82798"8'
"5"TR"dqqvfkm<"5:6:278:54"3228:5998"5'
"6"uncxgpxtco<"4924782"58798"3'
"6"uncxgeqpupapxtco<"326:778"82798"8'
"6"uncxgdqqvfkm<"5:6:278:54";44:4:.2"4'
"7"fhe%7/dqqvhncuj<"37;;29:7"37;;29:6"322'
"9"fhe%9/dqqvfkm<"3246779278"75945358"7'
"

```

This example shows how to display the capacity and utilization of the PFC and DFCs present in the system:

Router#show platform hardware capacity forwarding

N4"Hqtyctfkpi"Tguqwtugu

```

"OCE"Vcdng"wucig<"Oqfwng"Egnnkukqpu"Vqvcn""Wugf""Wugf
"
"3"*G3+"2"353294""3222""3'
"
"3"*G4+"2"353294""3222""3'
"
"4""2"353294""3222""3'
"
"5""2"353294""3222""3'
"
"6""2"353294""3222""3'
"
"7""2"353294""3222""3'
"
"9""2"353294""3222""3'
"

```

N5"Hqtyctfkpi"Tguqwtugu

```

"HKD"VECO"wucig<""Vqvcn""Wugf""Wugf
"94"dkvu"*KRx6"."ORNU"."GqO+""484366""3:"3'
"366"dkvu"*KR"oecuv"."KRx8+""353294""9""3'
"4:":"dkvu"*KRx8"oecuv+""87758""3""3'
"
"fgvckn<""Rtqvqeqn""Wugf""Wugf
"KRx6""38""3'
"ORNU""3""3'
"GqO""3""3'
"
"KRx8""3""3'
"KRx6"oecuv""8""3'
"KRx8"oecuv""3""3'
"

```

This example shows how to display the interface resources:

Kpvgthceg" Tguqwt egu

" "Kpvgthceg"ftqru<

Supervisor Engine 6T Software Configuration Guide, Release 15.4SY



Command-Line Interfaces

- [Accessing the CLI, page 2-1](#)
- [Performing Command Line Processing, page 2-3](#)
- [Performing History Substitution, page 2-4](#)
- [Cisco IOS Command Modes, page 2-4](#)
- [Displaying a List of Cisco IOS Commands and Syntax, page 2-6](#)
- [Securing the CLI, page 2-7](#)
- [ROM-Monitor Command-Line Interface, page 2-7](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Accessing the CLI

- [Accessing the CLI through the EIA/TIA-232 Console Interface, page 2-2](#)
- [Accessing the CLI through Telnet, page 2-2](#)
- [Accessing the CLI through USB, page 2-3](#)

Accessing the CLI through the EIA/TIA-232 Console Interface



Note

EIA/TIA-232 was known as recommended standard 232 (RS-232) before its acceptance as a standard by the Electronic Industries Alliance (EIA) and Telecommunications Industry Association (TIA).

Perform initial configuration over a connection to the EIA/TIA-232 console interface. See the *Catalyst 6500 Series Switch Module Installation Guide* for console interface cable connection procedures.

To make a console connection, perform this task:

	Command	Purpose
Step 1	Press Return.	Brings up the prompt.
Step 2	Tqwgvt@" gpcdng "	Initiates enable mode enable.
Step 3	Rcuuyqtf<" <i>rcuuyqtf</i> " Tqwgvt%"	Completes enable mode enable.
Step 4	Tqwgvt%" swkv "	Exits the session when finished.

After making a console connection, you see this display:

```
Rtguu"Tgvwtp"hgt"Egpugng"rtqorv
```

```
Tqwgvt@"gpcdng"
Rcuuyqtf<
Tqwgvt%"
```

Accessing the CLI through Telnet



Note

Before you can make a telnet connection to the switch, you must configure an IP address.

The switch supports up to eight simultaneous telnet sessions. Telnet sessions disconnect automatically after remaining idle for the period specified with the **exec-timeout** command.

To make a telnet connection to the switch, perform this task:

	Command	Purpose
Step 1	vgnpgv " }jquvpcog"~"kracfft;	Makes a telnet connection from the remote host to the switch you want to access.
Step 2	Rcuuyqtf<" <i>rcuuyqtf</i> " Tqwgvt%"	Initiates authentication. Note If no password has been configured, press Return.
Step 3	Tqwgvt@" gpcdng "	Initiates enable mode enable.
Step 4	Rcuuyqtf<" <i>rcuuyqtf</i> " Tqwgvt%"	Completes enable mode enable.
Step 5	Tqwgvt%" swkv "	Exits the session when finished.

This example shows how to open a Telnet session to the switch:

```
wpkzajquv' "vgnpgv" Tqwvgta3"
Vt{kpi"394042074062000
Eqppgevgf"vq"3940420740620
Guecrg"ejctcevg"ku")'_)0

Wugt"Ceeguu"Xgtkhkecvkqp

Rcuuyqtf<
Tqwvgta3@"gpcdng"
Rcuuyqtf<
Tqwvgta3%"
```


Accessing the CLI through USB

The USB console port connection uses a USB Type A to 5-pin mini-Type B cable. The USB console interface speeds are the same as the RJ-45 console interface speeds.

If you use the USB mini-Type B console port, the Cisco Windows USB device driver must be installed on any PC connected to the console port (for operation with Microsoft Windows). Mac OS X or Linux do not require special drivers.

The 4-pin mini-Type B connector resembles the 5-pin mini-Type B connectors. They are not compatible. Use only the 5-pin mini-Type B.

Figure 2-1 5-pin USB Mini-Type B Port.



With the Cisco Windows USB device driver, you can connect and disconnect the USB cable from the console port without affecting Windows HyperTerminal operations.

The console output always goes to both the RJ-45 and the USB console connectors, but the console input is active on only one of the console connectors at any one time. The USB console takes precedence over the RJ-45 console. When a cable is connected into the USB console port, the RJ-45 console port becomes inactive. Conversely, when the USB cable is disconnected from the USB console port, the RJ-45 port becomes active.

You can use the command-line interface (CLI) to configure an inactivity timeout which reactivates the RJ-45 console if the USB console has been activated and no input activity has occurred on the USB console for a specified time.

After the USB console deactivates due to inactivity, you cannot use the CLI to reactivate it. Disconnect and reconnect the USB cable to reactivate the USB console.

Performing Command Line Processing

Commands are not case sensitive. You can abbreviate commands and parameters if the abbreviations contain enough letters to be different from any other currently available commands or parameters. You can scroll through the last 20 commands stored in the history buffer, and enter or edit the command at the prompt. [Table 2-1](#) lists the keyboard shortcuts for entering and editing commands.

Table 2-1 *Keyboard Shortcuts*

Keystrokes	Purpose
Press Ctrl-B or press the left arrow key	Moves the cursor back one character. Note The arrow keys function only on ANSI-compatible terminals such as VT100s.
Press Ctrl-F or press the right arrow key	Moves the cursor forward one character. Note The arrow keys function only on ANSI-compatible terminals such as VT100s.
Press Ctrl-A	Moves the cursor to the beginning of the command line.
Press Ctrl-E	Moves the cursor to the end of the command line.
Press Esc B	Moves the cursor back one word.
Press Esc F	Moves the cursor forward one word.

Performing History Substitution

The history buffer stores the last 20 commands you entered. History substitution allows you to access these commands without retyping them, by using special abbreviated commands. [Table 2-2](#) lists the history substitution commands.

Table 2-2 *History Substitution Commands*

Command	Purpose
Ctrl-P or the up arrow key.	Recalls commands in the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands. Note The arrow keys function only on ANSI-compatible terminals such as VT100s.
Ctrl-N or the down arrow key.	Returns to more recent commands in the history buffer after recalling commands with Ctrl-P or the up arrow key. Repeat the key sequence to recall successively more recent commands. Note The arrow keys function only on ANSI-compatible terminals such as VT100s.
<code>Tqvwgt%"ujqy"jkuvgt{"</code>	While in EXEC mode, lists the last several commands you have just entered.

Cisco IOS Command Modes


Note

For complete information about Cisco IOS command modes, see the *Cisco IOS Configuration Fundamentals Configuration Guide* at this URL:

http://www.cisco.com/en/US/docs/ios-xml/ios/fundamentals/configuration/15_sy/fundamentals-15-sy-book.html

The Cisco IOS user interface is divided into many different modes. The commands available to you depend on which mode you are currently in. To get a list of the commands in a given mode, type a question mark (?) at the system prompt. See the “[Displaying a List of Cisco IOS Commands and Syntax](#)” section on page 2-6.

When you start a session on the switch, you begin in user mode, often called user EXEC mode. Only a limited subset of the commands are available in EXEC mode. To have access to all commands, you must enter privileged EXEC mode. Normally, you must type in a password to access privileged EXEC mode. From privileged EXEC mode, you can type in any EXEC command or access global configuration mode.

The configuration modes allow you to make changes to the running configuration. If you later save the configuration, these commands are stored across reboots. You must start at global configuration mode. From global configuration mode, you can enter interface configuration mode, subinterface configuration mode, and a variety of protocol-specific modes.



Note

You can enter EXEC mode commands by entering the **do** keyword before the EXEC mode command.

ROM-monitor mode is a separate mode used when the switch cannot boot properly. For example, the switch might enter ROM-monitor mode if it does not find a valid system image when it is booting, or if its configuration file is corrupted at startup. See the “[ROM-Monitor Command-Line Interface](#)” section on page 2-7.

Table 2-3 lists and describes frequently used Cisco IOS modes.

Table 2-3 *Frequently Used Cisco IOS Command Modes*

Mode	Description of Use	How to Access	Prompt
User EXEC	Connect to remote devices, change terminal settings on a temporary basis, perform basic tests, and display system information.	Log in.	Tqwgvt@
Privileged EXEC (enable)	Set operating parameters. The privileged command set includes the commands in user EXEC mode, as well as the configure command. Use this command to access the other command modes.	From the user EXEC mode, enter the enable command and the enable password.	Tqwgvt%
Global configuration	Configure features that affect the system as a whole.	From the privileged EXEC mode, enter the configure terminal command.	Tqwgvt*eqphki+%

Mode	Description of Use	How to Access	Prompt
Interface configuration	Many features are enabled for a particular interface. Interface commands enable or modify the operation of an interface.	From global configuration mode, enter the interface <i>type slot/port</i> command.	Tqvwgt*eqphki/kh+%
Console configuration	From the directly connected console or the virtual terminal used with Telnet, use this configuration mode to configure the console interface.	From global configuration mode, enter the line console 0 command.	Tqvwgt*eqphki/nkpg+%

When you type **exit**, the switch backs out one level. To exit configuration mode completely and return to privileged EXEC mode, press **Ctrl-Z**.

If you are having trouble entering a command, check the system prompt, and enter the question mark (?) for a list of available commands. You might be in the wrong command mode or using incorrect syntax.

Enter **exit** to return to the previous mode. Press **Ctrl-Z** or enter the **end** command in any mode to immediately return to privileged EXEC mode.

Securing the CLI

Securing access to the CLI prevents unauthorized users from viewing configuration settings or making configuration changes that can disrupt the stability of your network or compromise your network security. You can create a strong and flexible security scheme for your switch by configuring one or more of these security features:

- Protecting access to privileged EXEC commands—At a minimum, you should configure separate passwords for the user EXEC and privileged EXEC (enable) IOS command modes. You can further increase the level of security by configuring username and password pairs to limit access to CLI sessions to specific users. For more information, see this publication:

http://www.cisco.com/en/US/docs/ios/security/configuration/guide/sec_cfg_sec_4cli.html

- Controlling switch access with RADIUS, TACACS+, or Kerberos—For a centralized and scalable security scheme, you can require users to be authenticated and authorized by an external security server running either Remote Authentication Dial-In User Service (RADIUS), Terminal Access Controller Access-Control System Plus (TACACS+), or Kerberos. For more information, see this publication:

http://www.cisco.com/en/US/docs/ios-xml/ios/security/config_library/15-sy/secdata-15-sy-library.html

- Configuring a secure connection with SSH or HTTPS—To prevent eavesdropping of your configuration session, you can use a Secure Shell (SSH) client or a browser that supports HTTP over Secure Socket Layer (HTTPS) to make an encrypted connection to the switch. For more information, see this publication:

http://www.cisco.com/en/US/docs/ios-xml/ios/security/config_library/15-sy/secdata-15-sy-library.html

For more information about HTTPS, see “HTTPS - HTTP Server and Client with SSL 3.0” at this URL:

http://www.cisco.com/en/US/docs/ios/sec_user_services/configuration/guide/sec_cfg_sec_4cli.html

- Copying configuration files securely with SCP—To prevent eavesdropping when copying configuration files or image files to or from the switch, you can use the Secure Copy Protocol (SCP) to perform an encrypted file transfer. For more information about SCP, see “Secure Copy” at this URL:

http://www.cisco.com/en/US/docs/ios-xml/ios/sec_usr_ssh/configuration/15-sy/sec-usr-ssh-sec-copy.html

ROM-Monitor Command-Line Interface

The ROM-monitor is a ROM-based program that executes upon platform power-up, reset, or when a fatal exception occurs. The switch enters ROM-monitor mode if it does not find a valid software image, if the NVRAM configuration is corrupted, or if the configuration register is set to enter ROM-monitor mode. From the ROM-monitor mode, you can load a software image manually from flash memory, from a network server file, or from bootflash.

You can also enter ROM-monitor mode by restarting and pressing the **Break** key during the first 60 seconds of startup.

**Note**

The **Break** key is always enabled for 60 seconds after rebooting, regardless of whether the **Break** key is configured to be off by configuration register settings.

To access the ROM-monitor mode through a terminal server, you can escape to the Telnet prompt and enter the **send break** command for your terminal emulation program to break into ROM-monitor mode. Once you are in ROM-monitor mode, the prompt changes to rommon 1>. Enter a question mark (?) to see the available ROM-monitor commands.

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Smart Port Macros

- [Prerequisites for Smart Port Macros, page 3-1](#)
- [Restrictions for Smart Port Macros, page 3-2](#)
- [Information About Smart Port Macros, page 3-3](#)
- [Default Settings for Smart Port Macros, page 3-4](#)
- [How to Configure Smart Port Macros, page 3-4](#)
- [Verifying the Smart Port Macro Configuration, page 3-15](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
 - Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
-



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for Smart Port Macros

None.

Restrictions for Smart Port Macros

- You can display all of the macros on the switch by using the **show parser macro** user EXEC command. Display the contents of a specific macro by using the **show parser macro name macro-name** user EXEC command.
- You cannot edit a macro. If the name following the **macro name** command is an existing macro's name, that macro is replaced by the new macro.
- If a description already exists for a macro, the **macro description** command appends any description that you enter to the existing description; it does not replace it. The entered descriptions are separated by the pipe ("|") character.
- The maximum macro description length is 256 characters. When the description string becomes longer than 256 characters, the oldest descriptions are deleted to make room for new ones.
- User-created recursive macros are not supported. You cannot define a macro that calls another macro.
- Each user-created macro can have up to three keyword-value pairs.
- A macro definition can contain up to 3,000 characters. Line endings count as two characters.
- When creating a macro, do not use the **exit** or **end** commands or change the command mode by using **interface interface-id**. This could cause commands that follow **exit**, **end**, or **interface interface-id** to execute in a different command mode. When creating a macro, all CLI commands should be in the same configuration mode.
- When creating a macro that requires the assignment of unique values, use the **parameter value** keywords to designate values specific to the interface. Keyword matching is case sensitive. All matching occurrences of the keyword are replaced with the corresponding value. Any full match of a keyword, even if it is part of a larger string, is considered a match and is replaced by the corresponding value.
- Macro names are case sensitive. For example, the commands **macro name Sample-Macro** and **macro name sample-macro** will result in two separate macros.
- Some macros might contain keywords that require a parameter value. You can use the **macro global apply macro-name ?** global configuration command or the **macro apply macro-name ?** interface configuration command to display a list of any required values in the macro. If you apply a macro without entering the keyword values, the commands are invalid and are not applied.
- When a macro is applied globally to a switch or to a switch interface, the existing configuration on the interface is retained. This is helpful when applying an incremental configuration.
- If you modify a macro definition by adding or deleting commands, the changes are not reflected on the interface where the original macro was applied. You need to reapply the updated macro on the interface to apply the new or changed commands.
- You can use the **macro global trace macro-name** global configuration command or the **macro trace macro-name** interface configuration command to apply and debug a macro to find any syntax or configuration errors. If a command fails because of a syntax error or a configuration error, the macro continues to apply the remaining commands.
- Some CLI commands are specific to certain interface types. If a macro is applied to an interface that does not accept the configuration, the macro will fail the syntax check or the configuration check, and the switch will return an error message.

- Applying a macro to an interface range is the same as applying a macro to a single interface. When you use an interface range, the macro is applied sequentially to each interface within the range. If a macro command fails on one interface, it is still applied to the remaining interfaces.
- When you apply a macro to a switch or a switch interface, the macro name is automatically added to the switch or interface. You can display the applied commands and macro names by using the **show running-config** user EXEC command.

Information About Smart Port Macros

- [Information about Cisco-Provided Smart Port Macros, page 3-3](#)
- [Information about User-Created Smart Port Macros, page 3-4](#)

Information about Cisco-Provided Smart Port Macros

Use the **show parser macro** user EXEC command to display the Cisco-provided smart port macros and the commands they contain.

Table 3-1 Cisco-Provided Smart Port Macros

Macro Name	Description
cisco-global	Use this global configuration macro to enable load balancing across VLANs, provide rapid convergence of spanning-tree instances and to enable port error recovery.
cisco-desktop	Use this interface configuration macro for increased network security and reliability when connecting a desktop device, such as a PC, to a switch port.
cisco-phone	Use this interface configuration macro when connecting a desktop device such as a PC with a Cisco IP phone to a switch port. This macro is an extension of the cisco-desktop macro and provides the same security and resiliency features, but with the addition of dedicated voice VLANs to ensure proper treatment of delay-sensitive voice traffic.
cisco-switch	Use this interface configuration macro for Layer 2 connections between devices like switches and routers.
cisco-router	Use this interface configuration macro for Layer 3 connections between devices like switches and routers.

Cisco also provides a collection of pretested, Cisco-recommended baseline configuration templates for Catalyst switches. The online reference guide templates provide the CLI commands that you can use to create smart port macros based on the usage of the port. You can use the configuration templates to create smart port macros to build and deploy Cisco-recommended network designs and configurations.

Information about User-Created Smart Port Macros

Smart port macros provide a convenient way to save and share common configurations. You can use smart port macros to enable features and settings based on the location of a switch in the network and for mass configuration deployments across the network.

Each smart port macro is a user-defined set of Cisco IOS CLI commands. When you apply a smart port macro on an interface, the CLI commands within the macro are configured on the interface. When the macro is applied to an interface, the existing interface configurations are not lost. The new commands are added to the interface and are saved in the running configuration file.

Default Settings for Smart Port Macros

This example shows how to list the Cisco-provided smart port macros that are provided by default:

```
Tqwgvt%"ujqy"rctugt"ocetq"dtkgh"
" " " fghcwnv"inqdcn" " "<"ekueq/inqdcn"
" " " fghcwnv"kpvgthceg<"ekueq/fgumvqr"
" " " fghcwnv"kpvgthceg<"ekueq/rjqpg"
" " " fghcwnv"kpvgthceg<"ekueq/uykvej"
" " " fghcwnv"kpvgthceg<"ekueq/tqwgvt"
```

How to Configure Smart Port Macros

- [Using the Cisco-Provided Smart Port Macros, page 3-4](#)
- [Creating Smart Port Macros, page 3-13](#)

Using the Cisco-Provided Smart Port Macros

- [Using the cisco-global Smart Port Macro, page 3-4](#)
- [Using the cisco-desktop Smart Port Macro, page 3-5](#)
- [Using the cisco-phone Smart Port Macro, page 3-7](#)
- [Using the cisco-switch Smart Port Macro, page 3-9](#)
- [Using the cisco-router Smart Port Macro, page 3-11](#)

Using the cisco-global Smart Port Macro

- [Displaying the Contents of the cisco-global Smart Port Macro, page 3-4](#)
- [Applying the cisco-global Smart Port Macro, page 3-5](#)

Displaying the Contents of the cisco-global Smart Port Macro

```
Tqwgvt%"ujqy"rctugt"ocetq"pcog"ekueq/inqdcn"
Ocetq"pcog"<"ekueq/inqdcn
Ocetq"v{rg"<"fghcwnv"inqdcn
%"Gpcdng"f{pcoke"rqtvgttgt"tgeqxt{"hqt"nkpm"uvvcvg
%"hcknwtgu
gttfkucdng"tgeqxt{"ecwug"nkpm/hncr
```

```

gttfkucdng"tgeqxt{"kpvgtxcn"82

%"XVR"tgsuktgu"Vtcpurctgvp"oqfg"hgt"hwvwtg":2403z"Iwguv"XNCP
%"cpf"ewttgvp"Dguv"Rtcevkeg
xvr"fgoackp"]uoctvrqtvu_
xvr"oqfg"vtcpurctgvp"

%"Eqphki"Equ"vq"FUER"ocrrkpiu
rncvhtgo"squ"ocr"equ/fuer"2":38"48"54"68"6:"78"

%"Gpcdng"ciitguukxg"oqfg"WFNF"qp"cnn"hkdgt"wrnkpmu
wfnf"ciitguukxg"

%"Gpcdng"Trkf"RXUV-"cpf"Nqgriwctf
urcpgkpi/vtgg"oqfg"trkf/rxuv"
urcpgkpi/vtgg"nqgriwctf"fgbcwnv"
urcpgkpi/vtgg"gzvgpf"u{uvgo/kf"

```

Applying the cisco-global Smart Port Macro

To apply the cisco-global smart port macro, perform this task:

	Command	Purpose
Step 1	Tqvwgt%"eqphkiwtg"vgtokpcn"	Enters global configuration mode.
Step 2	Tqvwgt*eqphki+%"ocetq"inqdcn"crnn{"ekueq/inqdcn"	Applies the cisco-global smart port macro.
Step 3	Tqvwgt*eqphki+%"gpf"	Returns to privileged EXEC mode.

This example shows how to apply the cisco-global smart port macro and display the name of the applied macro:

```

Tqvwgt%"eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+%"ocetq"inqdcn"crnn{"ekueq/inqdcn"
Ejcpikpi"XVR"fgoackp"pcog"htgo"rtgkqguafgoackp"pcog"vq"]uoctvrqtvu_
Ugvvkpi"fgxkeg"vq"XVR"VTCPUCTGVP"oqfg0
Tqvwgt*eqphki+%"gpf"
Tqvwgt%"ujqy"rctugt"ocetq"fguetkrvkqp"
Inqdcn"Ocetq*u+<"ekueq/inqdcn

Kpvgtgthceg""""Ocetq"fguetkrvkqp*u+
////////////////////////////////////
////////////////////////////////////
Tqvwgt%

```

Using the cisco-desktop Smart Port Macro

- [Displaying the Contents of the cisco-desktop Smart Port Macro, page 3-6](#)
- [Applying the cisco-desktop Smart Port Macro, page 3-6](#)

Displaying the Contents of the cisco-desktop Smart Port Macro

```
Tqvwgt% "ujqy" rctugt "ocetq" pcog "ekueq/fgumvqr"
Ocetq"pcog"<"ekueq/fgumvqr
Ocetq"v{rg"<"fghcwnv"kpvgthceg
%"ocetq"mg{yqt fu"&CXKF
%"Duke"kpvgthceg"/"Gpcdng"fcvc"XNCP"qpn{
%"Tgeqoogpfgf"xcnwg"hqt"ceeguu"xncp"*CXKF+"ujqwnf"pqv"dg"3
uykvejrtv"
uykvejrtv"ceeguu"xncp"&CXKF"
uykvejrtv"oqfg"ceeguu"

%"Gpcdng"rqtv"ugewtkv{"nkokvkpi"rqtv"vq"c"ukping
%"OCE"cfftguu"/"vjcv"qh"fgumvqr
uykvejrtv"rqtv/ugewtkv{"
uykvejrtv"rqtv/ugewtkv{"oczkowo"3"

%"Gpuwtg"rqtv/ugewtkv{"cig"ku"itgcvgt"vjcp"qpg"okpwvg
%"cpf"wug"kpcevkkxv{"vkogt
uykvejrtv"rqtv/ugewtkv{"xkqncvkqp"tguvtkev"
uykvejrtv"rqtv/ugewtkv{"cikpi"vkog"4
%"Eqphkiwtg"rqtv"cu"cp"gfig"pgvyqtm"rqtv
urcppkpi/vtgg"rqtvhcu"
urcppkpi/vtgg"drfwiwctf"gpcdng"
```

Applying the cisco-desktop Smart Port Macro

To apply the cisco-desktop smart port macro, perform this task:

	Command	Purpose
Step 1	Tqvwgt% "eqphkiwtg"vgtokpcn"	Enters global configuration mode.
Step 2	Tqvwgt*eqphki+%" kpvgthceg "type slot/port"	Selects the interface to configure.
Step 3	Tqvwgt*eqphki/kh+%" ocetq"crnn{"ekueq/fgumvqr" &CXKF"access_vlan_ID"	Applies the cisco-desktop smart port macro. The recommended range for <i>access_vlan_ID</i> is 2–4094.
Step 4	Tqvwgt*eqphki/kh+%" gpf "	Returns to privileged EXEC mode.

This example shows how to apply the cisco-desktop smart port macro to Gigabit Ethernet port 1/1 with VLAN 2 specified as the access VLAN and how to verify the result:

```
Tqvwgt% "eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+%"kpvgthceg"ikicdkvgvjgtpgv"313"
Tqvwgt*eqphki/kh+%"ocetq"crnn{"ekueq/fgumvqr"&CXKF"4"
'Yctpkpi<"rqtvhcu"ujqwnf"qpn{"dg"GPCDNGF"qp"rqtvu"eqppgevgf"vq"c"ukping
"jquv0"Eqppgevkpi"jwdu."eqpegpvtcvqtu."uykvejgu."dtkfigu."gve000"vq"vjku
"kpvgthceg"yjpg"rqtvhcu"ku"GPCDNGF."ecp"ecwug"vgorqtct{"dtkfikpi"nqqr0
"Wug"ykvj"ECWVKQP

'Rqtvhcu"jcu"dggp"eqphkiwtgf"qp"Ikicdkvgvjgtpgv313"dwv"yknn"qpn{
"jcxg"ghhgev"yjpg"vjg"kpvgthceg"ku"kp"c"pqp/vtwpmkpi"oqfg0
Tqvwgt*eqphki+%"gpf"
Tqvwgt% "ujqy" rctugt "ocetq" fguetkrvkqp"kpvgthceg"ikicdkvgvjgtpgv"313"
Inqdcn"Ocetq*u+<"ekueq/inqdcn

Kpvgthceg""""Ocetq"fguetkrvkqp*u+
////////////////////////////////////
Ik313""""""ekueq/fgumvqr
////////////////////////////////////
```

```
Tqvwgt%"ujqy"twppkpi/eqphki"kpvgthceg"ikicdkvgvjgtpgv"313"
Dwknfkpi"eqphkiwtcvkqp000

Ewttgpv"eqphkiwtcvkqp"<"529"d{vgu
#
kpvgthceg"Ikicdkvgvjgtpgv313
"uykvejrtv
"uykvejrtv"ceeguu"xncp"4
"uykvejrtv"oqfg"ceeguu
"uykvejrtv"rtv/ugewtkv{
"uykvejrtv"rtv/ugewtkv{"cikpi"vkog"4
"uykvejrtv"rtv/ugewtkv{"xqncvkvqp"tguvtkev
"ujwvfqyp
"ocetq"fguetkrvkvqp"ekueq/fgumvqr
"urcppkpi/vtgg"rtvhcu
"urcppkpi/vtgg"drfwiwctf"gpcdng
gpf

Tqvwgt%
```

Using the cisco-phone Smart Port Macro

- [Displaying the Contents of the cisco-phone Smart Port Macro, page 3-7](#)
- [Applying the cisco-phone Smart Port Macro, page 3-8](#)

Displaying the Contents of the cisco-phone Smart Port Macro

```
Tqvwgt%"ujqy"rctugt"ocetq"pcog"ekueq/rjqpg"
Ocetq"pcog"<"ekueq/rjqpg
Ocetq"v{rg"<"fghcwnv"kpvgthceg
%"ocetq"mg{yqtfu"&CXXF"&XXKF
%"XqKR"gpcdngf"kpvgthceg"/"Gpcdng"fcvc"XNCP
%"cpf"xqkeg"XNCP"*XXKF+
%"Tgeqoogpfgf"xcnwg"hqt"ceeguu"xncp"*XXKF+"ujqwnf"pqv"dg"3
uykvejrtv"
uykvejrtv"ceeguu"xncp"&CXXF"
uykvejrtv"oqfg"ceeguu"

%"Wrfcvq"vjg"Xqkeg"XNCP"*XXKF+"xcnwg"yjkej"ujqwnf"dg
%"fkhgtgtpv"htqo"fcvc"XNCP
%"Tgeqoogpfgf"xcnwg"hqt"xqkeg"xncp"*XXKF+"ujqwnf"pqv"dg"3
uykvejrtv"xqkeg"xncp"&XXKF

%"Gpcdng"rtv"ugewtkv{"nkokvki"rtv"vq"c"5"OCE
%"cfftguuguu"//"Qpg"hqt"fgumvqr"cpf"vyq"hqt"rjqpg
uykvejrtv"rtv/ugewtkv{"
uykvejrtv"rtv/ugewtkv{"oczowo"5

%"Gpuwtg"rtv/ugewtkv{"cig"ku"itgcvgt"vjcp"qpg"okpwwg
%"cpf"wug"kpcevkvkv{"vkogt
uykvejrtv"rtv/ugewtkv{"xqncvkvqp"tguvtkev"
uykvejrtv"rtv/ugewtkv{"cikpi"vkog"4
%"Gpcdng"cwvq/squ"vq"gzvpgf"vtwuv"vq"cvvcejgfg"Ekueq"rjqpg
cwvq"squ"xqkr"ekueq/rjqpg"

%"Eqphkiwtg"rtv"cu"cp"gfif"pgvyqtm"rtv
urcppkpi/vtgg"rtvhcu
urcppkpi/vtgg"drfwiwctf"gpcdng"
```

Applying the cisco-phone Smart Port Macro

To apply the cisco-phone smart port macro, perform this task:

	Command	Purpose
Step 1	<code>Tqwwgt%eqphkiwtg"vgtokpcn"</code>	Enters global configuration mode.
Step 2	<code>Tqwwgt*eqphki+%kpvgtthceg" type slot/port"</code>	Selects the interface to configure.
Step 3	<code>Tqwwgt*eqphki/kh+%ocetq"crn{"ekueq/rjqpq"&CXXKF" access_vlan_ID"&XXKF" voice_vlan_ID"</code>	Applies the cisco-phone smart port macro. The recommended range for <i>access_vlan_ID</i> is 2–4094. The recommended range for <i>voice_vlan_ID</i> is 2–4094.
Step 4	<code>Tqwwgt*eqphki/kh+%gpf"</code>	Returns to privileged EXEC mode.

When applying the cisco-phone smart port macro, note the following information:

- Some of the generated commands are in the category of PFC QoS commands that are applied to **all ports controlled by a port ASIC**. When one of these generated commands is applied, PFC QoS displays the messages caused by application of the command to all the ports controlled by the port ASIC. Depending on the module, these commands are applied to as many as 48 ports. See the “Number of port groups” and “Port ranges per port group” listed for each module in the *Release Notes for Cisco IOS Release 15.2SY*:
http://www.cisco.com/en/US/docs/switches/lan/catalyst6500/ios/15.1SY/release_notes.html
- You might see messages that instruct you to configure other ports to trust CoS. You must do so to enable the generated QoS commands.
- You might not be able to apply the cisco-phone smart port macro and other macros on ports that are controlled by the same port ASIC because of conflicting port trust state requirements.

This example shows how to apply the cisco-phone smart port macro to Gigabit Ethernet port 2/2 with VLAN 2 specified as the access VLAN and how to verify the result:

```
Tqwwgt%eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+%kpvgtthceg"ikicdkvgvjgtpgv"414"
Tqwwgt*eqphki/kh+%ocetq"crn{"ekueq/rjqpq"&CXXKF"4"&XXKF"5"
Jctfyctg"SqU"ku"gpdcngf
Rtqrcicvkpi"equ/ocr"vq"kpdcpf"rqtv
Rtqrcicvkpi"equ/ocr"eqphkiwtcvkqp"vq<"[port list not shown]"
```

[Output for other ports controlled by the same port ASIC omitted]

```
Yctpkpi<"tex"equocr"yknn"pqv"dg"crnkgf"kp"jctfyctg0
"Vq"oqfkh{"tex"equocr"kp"jctfyctg."cnn"qh"vjg"kpvgthcegu"dgnqy
"owuv"dg"rww"kpvg")vtwuv"equ)"uvcvg<
""[port list not shown]"
'Yctpkpi<"rqtvhcuv"ujqwnf"qp{"dg"gpdcngf"qp"rqtvu"eqppgevgf"vq"cu"ukping
"jquv0"Eqppgevkpi"jwdu."eqpegpvtcvqtu."uykvejgu."dtkfigu."gve000"vq"vjku
"kpvgthceg"yjpg"rqtvhcuv"ku"gpdcngf."ecp"ecwug"vgorqtct{"dtkfikpi"nqgru0
"Wug"ykvj"ECWVKQP

'Rqtvhcuv"jcu"dgpp"eqphkiwtgf"qp"ikicdkvgvjgtpgv314"dwv"yknn"qp{
"jcxg"ghhgev"yjpg"vjg"kpvgthceg"ku"kp"cu"pqp/vtwpmkpi"oqfg0
Tqwwgt*eqphki+%gpf"

Tqwwgt%"ujqy"rctugt"ocetq"fguetkrvkqp"kpvgthceg"ikicdkvgvjgtpgv"414"
Inqdcn"Ocetq*u+<"ekueq/inqdcn

Kpvgtthceg" ""Ocetq"fguetkrvkqp*u+
////////////////////////////////////
```



```

Ik414" " " " " "ekueq/rjqpg
////////////////////////////////////

Tqvwgt%"ujqy"twppkpi/eqphki"kpvgthceg"ikicdkvgvjgtpgv"414"
Dwknfkpi"eqphkiwtcvkqp000

Dwknfkpi"eqphkiwtcvkqp000

Ewttgpv"eqphkiwtcvkqp"<"529"d{vgu
#
kpvgthceg"IkicdkvGvjgtpgv314
Dwknfkpi"eqphkiwtcvkqp000

Ewttgpv"eqphkiwtcvkqp"<"3558"d{vgu
#
kpvgthceg"IkicdkvGvjgtpgv414
"uykvejrqtv
"uykvejrqtv"ceeguu"xncp"4
"uykvejrqtv"oqfg"ceeguu
"uykvejrqtv"xqkeg"xncp"5
"uykvejrqtv"rqtv/ugewtkv{
"uykvejrqtv"rqtv/ugewtkv{"oczkowo"5
"uykvejrqtv"rqtv/ugewtkv{"cikpi"vkog"4
"uykvejrqtv"rqtv/ugewtkv{"xkqncvkqp"tguvtkev
"ujwvfqyp

[QoS queuing commands omitted: these vary according to port type]

"rncvhto"squ"vtwuv"equ
"cwvq"squ"xqkr"ekueq/rjqpg"
"ocetq"fquetkrvkqp"ekueq/rjqpg
"urcppkpi/vtgg"rqtvhcuv
"urcppkpi/vtgg"drfwiwctf"gpcdng
gpf

Tqvwgt%

```

Using the cisco-switch Smart Port Macro

- [Displaying the Contents of the cisco-switch Smart Port Macro, page 3-9](#)
- [Applying the cisco-switch Smart Port Macro, page 3-10](#)

Displaying the Contents of the cisco-switch Smart Port Macro

```

Tqvwgt%"ujqy"rctugt"ocetq"pcog"ekueq/uykvej"
Ocetq"pcog"<"ekueq/uykvej
Ocetq"v{rg"<"fghcwnv"kpvgthceg
%"ocetq"mg{yqtfu"&PXXF
%"Fq"pqv"crn{"vq"GvjgtEjcppgn1Rqtv"Itqwr
%"Ceeguu"Wrnkpm"vq"Fkuvtkdvwkqp

%"Fghkpg"wpkswg"Pcvkxg"XNCP"qp"vtwpm"rqtvu
%"Tgeqoogpfgf"xcnwg"ht"pcvkxg"xncp"*PXXF+"ujqwnf"pqv"dg"3
uykvejrqtv"
uykvejrqtv"vtwpm"pcvkxg"xncp"&PXXF"

%"Wrfcvg"vjg"cnnqygf"XNCP"tcpig"*XTCPIG+"uwej"vjcv"kv
%"kpenwfgu"fcvc."xqkeg"cpf"pcvkxg"XNCPu
%"uykvejrqtv"vtwpm"cnnqygf"xncp"XTCPIG

%"Jctfeqfg"vtwpm"cpf"fkucdng"pgiqvkcvcqp"vq

```

```
%"urggf"wr"eqpxgtigpeg
uykvejrtv"vtwpm"gpecruwncvkqp"fqv3s"
uykvejrtv"oqfg"vtwpm"
uykvejrtv"ppggiqvkcvq"

%":2403y"fghkpgu"vjg"nkpm"cu"rv/rv"hgt"tcrkf"eqpxgtigpeg
urcppkpi/vtgg"nkpm/v{rg"rqkp/vq/rqkp"

Tqwvgt%
```

Applying the cisco-switch Smart Port Macro

To apply the cisco-switch smart port macro, perform this task:

	Command	Purpose
Step 1	Tqwvgt%"eqphkiwtg"vgtokpcn"	Enters global configuration mode.
Step 2	Tqwvgt*eqphki+% "kpvgthceg" type slot/port"	Selects the interface to configure.
Step 3	Tqwvgt*eqphki/kh+% "ocetq"crnr{ "ekueq/uykvej " &PXXF native_vlan_ID"	Applies the cisco-switch smart port macro. The recommended range for <i>native_vlan_ID</i> is 2–4094.
Step 4	Tqwvgt*eqphki/kh+% "gpf"	Returns to privileged EXEC mode.

This example shows how to apply the cisco-switch smart port macro to Gigabit Ethernet port 1/4 with VLAN 4 specified as the native VLAN and how to verify the result:

```
Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv"316"
Tqwvgt*eqphki/kh+% "ocetq"crnr{ "ekueq/uykvej " &PXXF "6"
Tqwvgt*eqphki/kh+% "gpf"
Tqwvgt%"ujgy"rctugt "ocetq" fguetkrvkqp "kpvgthceg"ikicdkvgvjgtpgv"316"
Kpvgthceg " " "Ocetq" Fguetkrvkqp*u+
////////////////////////////////////
Ik316" " " "ekueq/uykvej
////////////////////////////////////
Tqwvgt%"ujgy"twppkpi/eqphki "kpvgthceg"ikicdkvgvjgtpgv"316"
Dwknfkpi"eqphkiwtcvkqp000

Ewttgppv"eqphkiwtcvkqp"<"469"d{vgu
#
kpvgthceg"IkicdkvGvjgtpgv316
"uykvejrtv
"uykvejrtv"vtwpm"gpecruwncvkqp"fqv3s
"uykvejrtv"vtwpm"pcvkxg"xncp"6
"uykvejrtv"oqfg"vtwpm
"uykvejrtv"ppggiqvkcvq
"ujwvfqyp
"ocetq" fguetkrvkqp"ekueq/uykvej
"urcppkpi/vtgg"nkpm/v{rg"rqkp/vq/rqkp
gpf

Tqwvgt%"
```

Using the cisco-router Smart Port Macro

- [Displaying the Contents of the cisco-router Smart Port Macro, page 3-11](#)
- [Applying the cisco-router Smart Port Macro, page 3-11](#)

Displaying the Contents of the cisco-router Smart Port Macro

```
Tqwvgt%"ujqy"rctugt"ocetq"pcog"ekueq/tqwvgt"
Ocetq"pcog"<"ekueq/tqwvgt
Ocetq"v{rg"<"fghcwnv"kpvgthceg
%"ocetq"mg{yqtfu"&PXXF
%"Fq"pgv"crn{"vq"GvjgtEjcppgnlRqtv"Itqwr
%"Ceegu"Wrnkpm"vq"Fkuvtkdwvkqp
uykvejrqtv"

%"Fghkpg"wpkswg"Pcvkxg"XNCP"qp"vtwpm"rqtvu
%"Tgeqoogpfgf"xcnwg"hqt"pcvkxg"xncp"*PXXF+"ujqwnf"pgv"dg"3
uykvejrqtv"vtwpm"pcvkxg"xncp"&PXXF"

%"Wrfcvg"vjg"cnnqygf"XNCP"tcpig"*XTCPIG+"uwej"vjcv"kv
%"kpenwfgu"fcvc."xqkeg"cpf"pcvkxg"XNCPu
%"uykvejrqtv"vtwpm"cnnqygf"xncp"XTCPIG

%"Jctfeqfg"vtwpm"cpf"fkucdng"pgiqvkcvcqp"vq
%"urggf"wr"eqpxgtigpeg
uykvejrqtv"vtwpm"gpecruwncvcqp"fqv3s"
uykvejrqtv"oqfg"vtwpm"
uykvejrqtv"pppgiqvcvg"

%"Eqphkiwtg"squ"vq"vtwuv"vjku"kpvgthceg
cwwq"squ"xqkr"vtwuv"
rncvhto"squ"vtwuv"fuer"

%"Gpuwtg"hcu"ceegu"vq"vjg"pgvyqtm"yjgp"gpdcnkpi"vjg"kpvgthceg0
%"Gpuwtg"vjcv"uykvej"fgxkegu"ecppqv"dgeqog"cevkxg"qp"vjg"kpvgthceg0
urcppkpi/vtgg"rqtvhcu"
urcppkpi/vtgg"drfwiwctf"gpdcng"

Tqwvgt%
```

Applying the cisco-router Smart Port Macro

To apply the cisco-router smart port macro, perform this task:

	Command	Purpose
Step 1	Tqwvgt%"eqphkiwtg"vgtokpcn"	Enters global configuration mode.
Step 2	Tqwvgt*eqphki+%"kpvgthceg" type slot/port"	Selects the interface to configure.
Step 3	Tqwvgt*eqphki/kh+%"ocetq"crn{"ekueq/tqwvgt"&PXXF native_vlan_ID"	Applies the cisco-router smart port macro. The recommended range for <i>native_vlan_ID</i> is 2–4094.
Step 4	Tqwvgt*eqphki/kh+%"gpf"	Returns to privileged EXEC mode.

**Note**

The cisco-router smart port macro includes the **auto qos voip trust** command. When entered on a port configured with the **switchport** command, the **auto qos voip trust** command generates and applies the **platform qos trust cos** command to the port, but the cisco-router smart port macro changes the port trust state to trust DSCP with the **platform qos trust dscp** command. When you apply the cisco-router smart port macro, ignore messages that instruct you to enter the **platform qos trust cos** command on other ports controlled by the port ASIC.

This example shows how to apply the cisco-router smart port macro to Gigabit Ethernet port 1/5 and how to verify the result:

```
Tqwvgt% "eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"317"
Tqwvgt*eqphki/kh+%"ocetq"crrn{"ekueq/tqwvgt"&PXXF"7"
Jctfycgtg"SqU"ku"gpdcngf
Rtqrcicvkpi"equ/ocr"vq"kpdcpf"rqtv
Rtqrcicvkpi"equ/ocr"eqphkiwtcvkqp"vq<"[port list not shown]"
```

[Output for other ports controlled by the same port ASIC omitted]

[Output from temporarily applied trust CoS command omitted]

```
'Yctpkpi<"rqtvhcuv"ujqwnf"qpn{"dg"gpdcngf"qp"rqtvu"eqppgevgf"vq"c"ukping
"jqvu0"Eqppgevkpi"jwdu"."eqpegpvtcvqtu"."uykvejgu"."dtkfigu"."gve000"vq"vjku
"kpvgtthceg" "yjpg"rqtvhcuv"ku"gpdcngf"."ecp"ecwug"vgorqct{"dtkfikpi"nqgru0
"Wug"ykvj"ECWVKQP
```

```
'Rqtvhcuv"jcu"dggp"eqphkiwtgf"qp"IkicdkvGvjgtpgv317"dwv"yknn"qpn{
"jcxg"ghhgev"yjgp"vjg"kpvgthceg"ku"kp"c"pqp/vtwpmpki"oqfg0
Tqwvgt*eqphki/kh+%"gpf"
Tqwvgt%"ujqy"rctugt"ocetq"fguetkrvkqp"kpvgthceg"ikicdkvgvjgtpgv"317"
Kpvgtthceg" " "Ocetq"fguetkrvkqp*u+
////////////////////////////////////
Ik317" " " " "ekueq/tqwvgt
////////////////////////////////////
Tqwvgt%"ujqy"twppki/eqphki"kpvgthceg"ikicdkvgvjgtpgv"317"
Dwknfkpi"eqphkiwtcvkqp000
```

```
Ewttgvp"eqphkiwtcvkqp"<"344:"d{vgu
#
kpvgthceg"IkicdkvGvjgtpgv317
"uykvejrqtv
"uykvejrqtv"vtwpm"gpecruwncvkqp"fqv3s
"uykvejrqtv"vtwpm"pcvkxg"xncp"7
"uykvejrqtv"oqfg"vtwpm
"uykvejrqtv"ppgiqvkcvg
"ujwvfqyp
"ytt/swgwg"dcpfykfvj"42"322"422"
```

[QoS queuing commands omitted: these vary according to port type]

```
rncvhqto"squ"vtwuv"fuer
"cwvq"squ"xqkr"vtwuv"
"ocetq"fguetkrvkqp"ekueq/tqwvgt
"urcpgkpi/vtgg"rqtvhcuv
"urcpgkpi/vtgg"drfwiwctf"gpdcng
gpf
```

```
Tqwvgt%
```

Creating Smart Port Macros

- [Creating Smart Port Macros, page 3-13](#)
- [Applying User-Created Smart Port Macros, page 3-14](#)

Creating Smart Port Macros

To create a smart port macro, perform this task:

	Command	Purpose
Step 1	Tqwvgt% "eqphkiwtg"vgtokpcn "	Enters global configuration mode.
Step 2	Tqwvgt*eqphki+% "ocetq"pcog " <i>macro-name</i> "	Creates a macro. Macro names are case sensitive. For example, the commands macro name Sample-Macro and macro name sample-macro will result in two separate macros. A macro definition can contain up to 3,000 characters. Line endings count as two characters. There is no prompt displayed in macro creation mode. Enter the macro commands on separate lines. Use the # character at the beginning of a line to enter a comment within the macro. Use the @ character to end the macro. Do not use the exit or end commands or change the command mode with the interface interface-id in a macro. This could cause any commands following exit , end , or interface interface-id to execute in a different command mode. For best results, all commands in a macro should be in the same configuration mode. Each user-created macro can have up to three keyword-value pairs.
Step 3	% ocetq"mg{yqtfu " <i>keyword1</i> " <i>keyword2</i> " <i>keyword3</i> "	(Optional) You can create a help string to describe the keywords that you define in the macro. You can enter up to three help string comments in a macro.
Step 4	gpf "	Returns to privileged EXEC mode.
Step 5	ujqy"rctugt"ocetq"pcog " <i>macro-name</i> "	Verifies that the macro was created.



Note

The **no** form of the **macro name** global configuration command only deletes the macro definition. It does not affect the configuration of those interfaces on which the macro is already applied.

This example shows how to create a macro that defines the Layer 2 access VLAN and the number of secure MAC addresses and also includes two help string keywords by using # **macro** keywords:

```
Tqvwgt*eqphki+% "ocetq"pcog"vguv"
%ocetq"mg{yqtfu"&XNCPKF"&OCZ"
uykvejrtv"ceeguu"xncp"&XNCPKF"
uykvejrtv"rtv/ugewtkv{ "oczowo"&OCZ"
B"
```

Applying User-Created Smart Port Macros

To apply a smart port macro, perform this task:

	Command	Purpose
Step 1	Tqvwgt% "eqphkiwtg"vgtokpcn"	Enters global configuration mode.
Step 2	Tqvwgt*eqphki+% "fghcwnv"kpvgthceg" interface-id"	(Optional) Clears all configuration from the specified interface.
Step 3	Tqvwgt*eqphki+% "kpvgthceg" kpvgthcegakf"	(Required for interface macros.) Specifies the interface on which to apply the macro and enters interface configuration mode.
Step 4	Tqvwgt*eqphki+% "ocetq"] inqdcn_" } crm{ ~ vtceg; " macro-name"] keyword value_"] keyword value_"] keyword value_"	Applies or traces and applies each individual command defined in the macro. For global macros: - To find any syntax or configuration errors, enter the macro global trace macro-name command to apply and debug the macro. - To display a list of any keyword-value pairs defined in the macro, enter the macro global apply macro-name ? command. For interface macros: - To find any syntax or configuration errors, enter the macro trace macro-name command to apply and debug the macro. - To display a list of any keyword-value pairs defined in the macro, enter the macro apply macro-name ? command. To successfully apply the macro, you must enter any required keyword-value pairs. Keyword matching is case sensitive. In the commands that the macro applies, all matching occurrences of keywords are replaced with the corresponding values.
Step 5	Tqvwgt*eqphki+% "gpf"	Returns to privileged EXEC mode.

You can delete a global macro-applied configuration on a switch only by entering the **no** version of each command that is in the macro. You can delete all configurations on an interface by entering the **default interface interface_id** interface configuration command.

This example shows how to apply the user-created macro called `snmp`, to set the host name address to `test-server` and to set the IP precedence value to 7:

```
Tqwwgt*eqphki+% "ocetq"inqdcn"crnn{"upor"CFFTGUU"vguv/ugtxgt"XCNWG"9"
```

This example shows how to debug the user-created macro called `snmp` by using the **macro global trace** global configuration command to find any syntax or configuration errors in the macro when it is applied to the switch:

```
Tqwwgt*eqphki+% "ocetq"inqdcn"vtceg"upor"XCNWG"9"
Crrn{kpi"eqoocpf000`upor/ugtxgt"GPCDNG"vtcru"rqtV/ugewtkv{'
Crrn{kpi"eqoocpf000`upor/ugtxgt"GPCDNG"vtcru"nkpmwr'
Crrn{kpi"eqoocpf000`upor/ugtxgt"GPCDNG"vtcru"nkpmfgy'
Crrn{kpi"eqoocpf000`upor/ugtxgt"jquv'
'Gttgt"Wpmpgyp"gttqt0
Crrn{kpi"eqoocpf000`upor/ugtxgt"kr"rtgegfgpeg"7'
```

This example shows how to apply the user-created macro called `desktop-config` and to verify the configuration:

```
Tqwwgt*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv314"
Tqwwgt*eqphki/kh+% "ocetq"crnn{"fgumvqr/eqphki"
Tqwwgt*eqphki/kh+% "gpf"
Tqwwgt%"ujqy"rctugt"ocetq"fguetkrvkqp"
Kpvgthceg""""Ocetq"Fguetkrvkqp
////////////////////////////////////
Ik314      "fgumvqr/eqphki
////////////////////////////////////
```

This example shows how to apply the user-created macro called `desktop-config` and to replace all occurrences of `vlan` with VLAN ID 25:

```
Tqwwgt*eqphki/kh+% "ocetq"crnn{"fgumvqr/eqphki"xncp"47"
```

Verifying the Smart Port Macro Configuration

Table 3-2 Commands to Display Smartports Macros

Command	Purpose
<code>ujqy"rctugt"ocetq</code>	Displays all configured macros.
<code>ujqy"rctugt"ocetq"pcog macro-name</code>	Displays a specific macro.
<code>ujqy"rctugt"ocetq"dtkgh</code>	Displays the configured macro names.
<code>ujqy"rctugt"ocetq"fguetkrvkqp"[kpvgthceg interface-id]</code>	Displays the macro description for all interfaces or for a specified interface.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Virtual Switching Systems

- [Prerequisites for VSS, page 4-1](#)
- [Restrictions for VSS, page 4-2](#)
- [Information About Virtual Switching Systems, page 4-4](#)
- [Default Settings for VSS, page 4-31](#)
- [How to Configure a VSS, page 4-31](#)
- [How to Upgrade a VSS, page 4-54](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
 - Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
-



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for VSS

The VSS configurations in the startup-config file must match on both chassis.

Restrictions for VSS

- [General VSS Restrictions, page 4-2](#)
- [VSL Restrictions, page 4-2](#)
- [Multichassis EtherChannel \(MEC\) Restrictions, page 4-2](#)
- [Dual-Active Detection Restrictions, page 4-3](#)

General VSS Restrictions

- VSS mode does not support supervisor engine redundancy within a chassis.
- If you configure a new value for switch priority, the change takes effect only after you save the configuration file and perform a restart.
- Out-of-band MAC address table synchronization among DFC-equipped switching modules (the **mac address-table synchronize** command) is enabled automatically in VSS mode, which is the recommended configuration.
- Because the output of the **show running-config** command on ICS supervisor engines could be out of sync with the active supervisor engine, ICS supervisor engines do not support the **show running-config** command. The active and standby supervisor engines support the **show running-config** command.

VSL Restrictions

- For line redundancy, we recommend configuring at least two ports per switch for the VSL. For module redundancy, the two ports can be on different switching modules in each chassis.
- The **no platform qos channel-consistency** command is automatically applied when you configure the VSL. Do not remove this command.
- VSL ports cannot be Mini Protocol Analyzer sources (the **monitor ... capture** command). Monitor capture sessions cannot be started if a source is the VSL on the port channel of the standby switch. The following message is displayed when a remote VSL port channel on the standby switch is specified and you attempt to start the monitor capture:

```
' "tgoqvg"XUN"rqtv"ku"pqv"cnngygf"cu"ecrvwtg"uqwteg
```

The following message is displayed when a scheduled monitor capture start fails because a source is a remote VSL port channel:

```
Rcemgv"ecrvwtg"uguukqp"3"hcngf"vq"uvctv0"C"uqwteg"rqtv"ku"c"tgoqvg"XUN0
```

Multichassis EtherChannel (MEC) Restrictions

- All links in an MEC must terminate locally on the active or standby chassis of the same virtual domain.
- For an MEC using the LACP control protocol, the *minlinks* command argument defines the minimum number of physical links in each chassis for the MEC to be operational.
- For an MEC using the LACP control protocol, the *maxbundle* command argument defines the maximum number of links in the MEC across the whole VSS.

- MEC supports LACP 1:1 redundancy. For additional information about LACP 1:1 redundancy, refer to the [“Information about LACP 1:1 Redundancy” section on page 23-6](#).
- An MEC can be connected to another MEC in a different VSS domain.
- Ports on the supervisor engines are not stateful and will experience a reset across switchovers (see the [“Switchover Process Restrictions” section on page 7-2](#)).
- With an MEC that includes supervisor engine ports configured on a VSS that supports the VSS Quad-Sup SSO (VS4O) feature, be aware of [CSCuh51005](#).

Dual-Active Detection Restrictions

- If Flex Links are configured on the VSS, use PAgP dual-active detection.
- For dual-active detection link redundancy, configure at least two ports per switch for dual-active detection. For module redundancy, the two ports can be on different switching modules in each chassis, and should be on different modules than the VSL, if feasible.
- When you configure dual-active fast hello mode, all existing configurations are removed automatically from the interface except for these commands:
 - **description**
 - **logging event**
 - **load-interval**
 - **rcv-queue cos-map**
 - **rcv-queue queue-limit**
 - **rcv-queue random-detect**
 - **rcv-queue threshold**
 - **wrr-queue bandwidth**
 - **wrr-queue cos-map**
 - **wrr-queue queue-limit**
 - **wrr-queue random-detect**
 - **wrr-queue threshold**
 - **priority-queue cos-map**
- Only these configuration commands are available on dual-active detection fast hello ports:
 - **default**
 - **description**
 - **dual-active**
 - **exit**
 - **load-interval**
 - **logging**
 - **no**
 - **shutdown**

- ASIC-specific QoS commands are not configurable on dual-active detection fast hello ports directly, but are allowed to remain on the fast hello port if the commands were configured on another non-fast hello port in that same ASIC group. For a list of these commands, see [Chapter 61, “Restrictions for PFC QoS.”](#)

Information About Virtual Switching Systems

- [VSS Overview, page 4-4](#)
- [VSS Redundancy, page 4-13](#)
- [Multichassis EtherChannels, page 4-15](#)
- [Packet Handling, page 4-18](#)
- [System Monitoring, page 4-22](#)
- [Convert Port Mode, page 4-23](#)
- [Dual-Active Detection, page 4-27](#)
- [VSS Initialization, page 4-29](#)

VSS Overview


- [VSS Topology, page 4-4](#)
- [Key Concepts, page 4-5](#)
- [VSS Functionality, page 4-7](#)
- [Hardware Requirements, page 4-10](#)
- [Information about VSL Topology, page 4-12](#)

VSS Topology

Network operators increase network reliability by configuring switches in redundant pairs and by provisioning links to both switches in the redundant pair. [Figure 4-1](#) shows a typical network configuration. Redundant network elements and redundant links can add complexity to network design and operation. Virtual switching simplifies the network by reducing the number of network elements and hiding the complexity of managing redundant switches and links.

VSS mode combines a pair of switches into a single network element. VSS mode manages the redundant links, which externally act as a single port channel.

VSS mode simplifies network configuration and operation by reducing the number of Layer 3 routing neighbors and by providing a loop-free Layer 2 topology.

Figure 4-1 Typical Network Design


Key Concepts

- [Virtual Switching System, page 4-5](#)
- [Active and Standby Chassis, page 4-6](#)
- [Virtual Switch Link, page 4-6](#)
- [Multichassis EtherChannel \(MEC\), page 4-7](#)

Virtual Switching System

A VSS combines a pair of switches into a single network element. For example, a VSS in the distribution layer of the network interacts with the access and core networks as if it were a single switch. See [Figure 4-2](#).

An access switch connects to both chassis of the VSS using one logical port channel. VSS mode manages redundancy and load balancing on the port channel. This capability enables a loop-free Layer 2 network topology. VSS mode also simplifies the Layer 3 network topology because VSS mode reduces the number of routing peers in the network.

Figure 4-2 VSS in the Distribution Network

Active and Standby Chassis


When you create or restart a VSS, the peer chassis negotiate their roles. One chassis becomes the active chassis, and the other chassis becomes the standby.

The active chassis controls the VSS. It runs the Layer 2 and Layer 3 control protocols for the switching modules on both chassis. The active chassis also provides management functions for the VSS, such as module online insertion and removal (OIR) and the console interface.

The active and standby chassis perform packet forwarding for ingress data traffic on their locally hosted interfaces. However, the standby chassis sends all control traffic to the active chassis for processing.

You can defer the traffic load on a multichassis EtherChannel (MEC) chassis to address traffic recovery performance during the standby chassis startup. For example, [Figure 4-3](#) represents network layout where a VSS (active and standby switches) is interacting with an upstream switch (switch 2) and a downstream switch (switch 1).

Figure 4-3 Switch Interconnected Through VSS




Virtual Switch Link

For the two chassis of the VSS to act as one network element, they need to share control information and data traffic.

The virtual switch link (VSL) is a special link that carries control and data traffic between the two chassis of a VSS, as shown in [Figure 4-4](#). The VSL is implemented as an EtherChannel with up to eight links. The VSL gives control traffic higher priority than data traffic so that control messages are never discarded. Data traffic is load balanced among the VSL links by the EtherChannel load-balancing algorithm.

Figure 4-4 Virtual Switch Link



181322


Multichassis EtherChannel (MEC)

An EtherChannel, which is configured on a port channel interface, is two or more physical links that combine to form one logical link. Layer 2 protocols operate on the EtherChannel as a single logical entity.

A MEC is a port channel with member ports on both chassis of the VSS. A connected non-VSS device views the MEC as a standard EtherChannel. See [Figure 4-5](#).

VSS mode supports a maximum of 512 EtherChannels. This limit applies to the combined total of regular EtherChannels and MECs. Because the VSL requires two EtherChannel numbers (one for each chassis), there are 510 user-configurable EtherChannels.

Figure 4-5 VSS with MEC



181323



Note

Ports on the supervisor engines are not stateful and will experience a reset across switchovers (see the [“Switchover Process Restrictions”](#) section on page 7-2).

VSS Functionality

- [Redundancy and High Availability, page 4-8](#)
- [Packet Handling, page 4-8](#)
- [System Management, page 4-8](#)
- [VSS Quad-Sup SSO \(VS4O\), page 4-9](#)
- [Interface Naming Convention, page 4-10](#)
- [Software Features, page 4-10](#)

Redundancy and High Availability

In VSS mode, supervisor engine redundancy operates between the active and standby chassis, using stateful switchover (SSO) and nonstop forwarding (NSF). The peer chassis exchange configuration and state information across the VSL and the standby supervisor engine runs in hot standby mode.

The standby chassis monitors the active chassis using the VSL. If it detects failure, the standby chassis initiates a switchover and takes on the active role. When the failed chassis recovers, it takes on the standby role.

**Note**

Ports on the supervisor engines are not stateful and will experience a reset across switchovers (see the [“Switchover Process Restrictions” section on page 7-2](#)).

If the VSL fails completely, the standby chassis assumes that the active chassis has failed, and initiates a switchover. After the switchover, if both chassis are active, the dual-active detection feature detects this condition and initiates recovery action. For additional information about dual-active detection, see the [“Dual-Active Detection” section on page 4-27](#).

Packet Handling

The active supervisor engine runs the Layer 2 and Layer 3 protocols and features for the VSS and manages the DFC modules for both chassis.

The VSS uses VSL to communicate protocol and system information between the peer chassis and to carry data traffic between the chassis when required.

Both chassis perform packet forwarding for ingress traffic on their interfaces. If possible, ingress traffic is forwarded to an outgoing interface on the same chassis to minimize data traffic that must traverse the VSL.

Because the standby chassis is actively forwarding traffic, the active supervisor engine distributes updates to the standby supervisor engine PFC and all standby chassis DFCs.

System Management

The active supervisor engine acts as a single point of control for the VSS. For example, the active supervisor engine handles OIR of switching modules on both chassis. The active supervisor engine uses VSL to send messages to and from local ports on the standby chassis.

The command console on the active supervisor engine is used to control both chassis. In virtual switch mode, the command console on the standby supervisor engine blocks attempts to enter configuration mode.

The standby chassis runs a subset of system management tasks. For example, the standby chassis handles its own power management.

VSS Quad-Sup SSO (VS4O)


Release 15.1(1)SY1 and later releases support the VSS Quad-Sup SSO (VS4O) feature.

Best Practice for VSL Links Between Supervisors

If there is a VSL link from ICA to ICA supervisor engine, ICS to ICS supervisor engine, and line card to line card, the control link will always be from the line card. The next preferred control link is from ICS to ICS VSL link, and the least preferred control link is from ICA to ICA VSL link.

In case of an ISSU image upgrade, if there is no cross VSL link, the control link will always be from the ICS supervisor engine. If there is a cross VSL link, the control link can be from any of the ICA supervisor engines.

Figure 4-6 Typical VSS Quad-Supervisor Configuration



These are the quad-supervisor VSS roles:

- In-chassis active (ICA) supervisor engines—The VSS active supervisor engine in one chassis and the VSS standby supervisor engine in the other chassis are ICA supervisor engines.

If the VSS active ICA supervisor engine crashes, a switchover to the standby ICA supervisor engine in other chassis occurs. Both VSS chassis remain active. All switching modules remain active.

In the chassis with the previously active ICA supervisor engine, an SSO switchover from the previously active ICA supervisor engine to the ICS standby supervisor engine occurs and the ICS takes over as the ICA. The failed ICA reloads and becomes the ICS.

You can verify the switchover mode of the supervisor engines by entering the **show module** command.

- In-chassis standby (ICS) supervisor engines—The other supervisor engines are ICS supervisor engines. The supervisor engine uplinks ports are available to forward traffic.



Note ICS supervisor engines do not support **show** commands. To avoid tracebacks, do not issue **show** commands on ICS supervisor engines.

If the supervisor engine PFC modes do not match then an ICS supervisor engine is reset to ROMMON. Configure both chassis to run in the same PFC mode.

ICS supervisor engines boot in SSO standby mode, which fully initializes and configures the ICS and maintains stateful feature and user session information.

To verify the switchover mode of the supervisor engines, enter the **show module** command.

When not in VSS quad supervisor engine mode, if you insert a supervisor engine to be an ICS, the supervisor engine resets to update the supervisor engine number and then reboots before going online.

Quad-supervisor SSO (VS4O) supports eFSU upgrades. You can upgrade or downgrade your VSS system using ISSU. See [“How to Upgrade a VSS” section on page 4-54](#) for more information about eFSU upgrades.

Interface Naming Convention

In VSS mode, interfaces are specified using switch number (in addition to slot and port), because the same slot numbers are used on both chassis. For example, the **interface 1/5/4** command specifies port 4 of the switching module in slot 5 of switch 1. The **interface 2/5/4** command specifies port 4 on the switching module in slot 5 of switch 2.

Software Features

With some exceptions, VSS mode has feature parity with non-VSS mode. Major exceptions include:

- VSS mode does not support supervisor engine redundancy within a chassis.
- Port-based QoS and ACLs can be applied to any physical port, except VSL ports. ACLs can be applied to no more than 2,046 ports.

Hardware Requirements

- [Chassis and Modules, page 4-10](#)
- [VSL Hardware Requirements, page 4-11](#)
- [PFC, DFC, and CFC Requirements, page 4-11](#)
- [Multichassis EtherChannel Requirements, page 4-11](#)
- [Service Module Support, page 4-12](#)

Chassis and Modules

Table 4-1 VSS Hardware Requirements

Hardware	Count	Requirements
Chassis	2	All chassis supported with Supervisor Engine 6T in Cisco IOS Release 15.4SY support VSS mode. Note The two chassis need not be identical.
Supervisor Engines	2	Either two C6800-SUP6T or two C6800-SUP6T-XLsupervisor engines. The two supervisor engines must match exactly.
Switching Modules	2+	VSS mode support as shown in the Release Notes. In VSS mode, unsupported switching modules remain powered off.

VSL Hardware Requirements

The VSL EtherChannel supports only 40-Gigabit and 10-Gigabit Ethernet ports. The ports can be located on the supervisor engine (recommended) or on one of the following switching modules:

- WS-X6904-40G-2T
- WS-X6908-10GE
- WS-X6816-10T-2T
- WS-X6816-10G-2T
- C6800-32P-10G and C6800-32P-10G-XL
- C6800-16P-10G and C6800-16P-10G-XL
- C6800-8P-10G and C6800-8P-10G-XL

Use any of the 10-Gigabit or 40-Gigabit Ethernet ports on the supervisor engines to create the VSL between the two chassis.

You can add more physical links to the VSL EtherChannel by using the 40-Gigabit or 10-Gigabit Ethernet ports on switching modules that support the VSL.



Note

- If you use 10-Gigabit Ethernet ports to form VSL, you can bundle a maximum of 8 links to the VSL ether channel.
- If you use 40-Gigabit Ethernet ports to form VSL, you can bundle a maximum of 4 links to the VSL ether channel.
- For switching modules **WS-X6816-10T-2T** and **WS-X6816-10G-2T**, when using the ports on these switching module as VSL links, you must operate the ports in performance mode, not in oversubscription mode. Enter the ***no hw-module switch x slot y oversubscription port-group num*** command when configuring the switching module. If you enter the ***no hw-module switch switch_number slot slot_number oversubscription*** command to configure non-oversubscription mode (performance mode), then only ports 1, 5, 9, and 13 are configurable; the other ports on the module are disabled.
- Port-groups are independent of each other and one or more port-groups can operate in non-oversubscribed mode for VSL with the unused ports administratively shutdown, while the others can still operate in oversubscribed mode.

PFC, DFC, and CFC Requirements

Switching modules with a DFC4, or DFC4XL support VSS mode.

With a PFC4, the VSS will automatically operate in PFC4 mode, even if some of the modules have a DFC4XL. With a PFC4XL, but some modules equipped with a DFC4, you need to configure the VSS to operate in PFC4 mode. The **platform hardware vsl pfc mode non-xl** configuration command sets the system to operate in PFC4 mode after the next restart. See the [“SSO Dependencies” section on page 4-29](#) for further details about this command.

Multichassis EtherChannel Requirements

Physical links from any module with a DFC4, or DFC4XL can be used to implement a Multichassis EtherChannel (MEC).

Service Module Support



Note

Service modules are not supported in Supervisor Engine 6T.

- Application Control Engine (ACE):
 - ACE20-MOD-K9
 - ACE30-MOD-K9
- ASA Services Module: WS-SVC-ASA-SM1-K9
- Firewall Services Module (FWSM): WS-SVC-FWM-1-K9
- Network Analysis Module (NAM):
 - WS-SVC-NAM-1
 - WS-SVC-NAM-2
 - WS-SVC-NAM3-6G-K9
- Wireless Services Module (WiSM):
 - WS-SVC-WISM-1-K9
 - WS-SVC-WISM2



Note

Before deploying a service module in VSS mode, upgrade the module to the minimum supported release in standalone mode. See the service module release notes for information about the minimum required service module software version.

Information about VSL Topology

A VSS is two chassis that communicate using the VSL, which is a special port group. Configure both of the 10-Gigabit Ethernet ports on the supervisor engines as VSL ports. Optionally, you can also configure the VSL port group to contain switching module 40- or 10-Gigabit Ethernet ports. This configuration provides additional VSL capacity. See [Figure 4-7](#) for an example topology.

Figure 4-7 VSL Topology Example

VSS Redundancy

- [Overview, page 4-13](#)
- [RPR and SSO Redundancy, page 4-13](#)
- [Failed Chassis Recovery, page 4-14](#)
- [VSL Failure, page 4-15](#)
- [User Actions, page 4-15](#)

Overview

A VSS operates stateful switchover (SSO) between the active and standby supervisor engines. Compared to standalone mode, VSS mode has the following important differences in its redundancy model:

- The active and standby supervisor engines are hosted in separate chassis and use the VSL to exchange information.
- The active supervisor engine controls both chassis of the VSS. The active supervisor engine runs the Layer 2 and Layer 3 control protocols and manages the switching modules on both chassis.
- The active and standby chassis both perform data traffic forwarding.

If the active supervisor engine fails, the standby supervisor engine initiates a switchover and assumes the active role.

RPR and SSO Redundancy

The VSS normally runs stateful switchover (SSO) between the active and standby supervisor engines (see [Figure 4-8](#)). The VSS determines the role of each supervisor engine during initialization.

Figure 4-8 Chassis Roles in VSS Mode

The VSS uses the VSL link to synchronize configuration data from the active to the standby supervisor engine. Also, protocols and features that support high availability synchronize their events and state information to the standby supervisor engine.

VSS mode operates with stateful switchover (SSO) redundancy if it meets the following requirements:

- Both supervisor engines are running the same software version.
- The VSL-related configuration in the two chassis matches.
- The PFC mode matches.
- SSO and nonstop forwarding (NSF) are configured on both chassis.

See the [“SSO Dependencies” section on page 4-29](#) for additional details about the requirements for SSO redundancy on a VSS. See [Chapter 8, “Nonstop Forwarding \(NSF\)”](#) for information about configuring SSO and NSF.

With SSO redundancy, the supervisor engine in the standby chassis runs in hot standby state and is always ready to assume control following a fault on the active supervisor engine. Configuration, forwarding, and state information are synchronized from the active supervisor engine to the redundant supervisor engine at startup and whenever changes to the active supervisor engine configuration occur. If a switchover occurs, traffic disruption is minimized.

If a VSS does not meet the requirements for SSO redundancy, the VSS uses route processor redundancy (RPR). In RPR mode, the active supervisor engine does not synchronize configuration changes or state information with the standby. The standby supervisor engine is only partially initialized and the switching modules on the standby supervisor are not powered up. If a switchover occurs, the standby supervisor engine completes its initialization and powers up the switching modules. Traffic is disrupted for approximately 2 minutes.

Failed Chassis Recovery

If the active chassis or supervisor engine fails, the VSS initiates a stateful switchover (SSO) and the former standby supervisor engine assumes the active role. The failed chassis performs recovery action by reloading the supervisor engine.

If the standby chassis or supervisor engine fails, no switchover is required. The failed chassis performs recovery action by reloading the supervisor engine.

The VSL links are unavailable while the failed chassis recovers. After the chassis reloads, it becomes the new standby chassis and the VSS reinitializes the VSL links between the two chassis.

The switching modules on the failed chassis are unavailable during recovery, so the VSS operates only with the MEC links that terminate on the active chassis. The bandwidth of the VSS is reduced until the failed chassis has completed its recovery and become operational again. Any devices that are connected only to the failed chassis experience an outage.



Note

The VSS may experience a brief data path disruption when the switching modules in the standby chassis become operational after the SSO.

After the SSO, much of the processing power of the active supervisor engine is consumed in bringing up a large number of ports simultaneously in the standby chassis. As a result, some links might be brought up before the supervisor engine has configured forwarding for the links, causing traffic to those links to be lost until the configuration is complete. This condition is especially disruptive if the link is an MEC link. Two methods are available to reduce data disruption following an SSO:

- You can configure the VSS to activate non-VSL ports in smaller groups over a period of time rather than all ports simultaneously. For information about deferring activation of the ports, see the [“Configuring Deferred Port Activation During Standby Recovery” section on page 4-48](#).

- You can defer the load sharing of the peer switch's MEC member ports during reestablishment of the port connections. See the [“Failed Chassis MEC Recovery” section on page 4-17](#) for details about load share deferral.

VSL Failure

To ensure fast recovery from VSL failures, fast link notification is enabled in virtual switch mode on all port channel members (including VSL ports) whose hardware supports fast link notification.



Note

Fast link notification is not compatible with link debounce mechanisms. In virtual switch mode, link debounce is disabled on all port channel members.

If a single VSL physical link goes down, the VSS adjusts the port group so that the failed link is not selected.

If the standby chassis detects complete VSL link failure, it initiates a stateful switchover (SSO). If the active chassis has failed (causing the VSL links to go down), the scenario is chassis failure, as described in the previous section.

If only the VSL has failed and the active chassis is still operational, this is a dual-active scenario. The VSS detects that both chassis are operating in active mode and performs recovery action. See the [“Dual-Active Detection” section on page 4-27](#) for additional details about the dual-active scenario.

User Actions

From the active chassis command console, you can initiate a VSS switchover or a reload.

If you enter the **reload** command from the command console, the entire VSS performs a reload.

To reload only the VSS standby supervisor engine:

- In a two supervisor VSS setup, use **redundancy reload shelf[1/2]** command.
- In a four supervisor VSS setup, use **redundancy reload peer** command,

To force a switchover from the active to the standby supervisor engine, use the **redundancy force-switchover** command.

Multichassis EtherChannels

- [Overview, page 4-15](#)
- [MEC Failure Scenarios, page 4-16](#)

Overview


A multichassis EtherChannel is an EtherChannel with ports that terminate on both chassis of the VSS (see [Figure 4-9](#)). A VSS MEC can connect to any network element that supports EtherChannel (such as a host, server, router, or switch).

At the VSS, an MEC is an EtherChannel with additional capability: the VSS balances the load across ports in each chassis independently. For example, if traffic enters the active chassis, the VSS will select an MEC link from the active chassis. This MEC capability ensures that data traffic does not unnecessarily traverse the VSL.

Each MEC can optionally be configured to support either PAgP or LACP. These protocols run only on the active chassis. PAgP or LACP control packets destined for an MEC link on the standby chassis are sent across VSL.

An MEC can support up to eight active physical links, which can be distributed in any proportion between the active and standby chassis.

Figure 4-9 MEC Topology



MEC Failure Scenarios

- [Single MEC Link Failure, page 4-16](#)
- [All MEC Links to the Active Chassis Fail, page 4-17](#)
- [All MEC Links to the Standby Chassis Fail, page 4-17](#)
- [All MEC Links Fail, page 4-17](#)
- [Standby Chassis Failure, page 4-17](#)
- [Active Chassis Failure, page 4-17](#)
- [Failed Chassis MEC Recovery, page 4-17](#)



Note

Configure the MEC with at least one link to each chassis. This configuration conserves VSL bandwidth (traffic egress link is on the same chassis as the ingress link), and increases network reliability (if one VSS supervisor engine fails, the MEC is still operational).

Single MEC Link Failure

If a link within the MEC fails (and other links in the MEC are still operational), the MEC redistributes the load among the operational links, as in a regular port.

All MEC Links to the Active Chassis Fail

If all links to the active chassis fail, the MEC becomes a regular EtherChannel with operational links to the standby chassis.

Data traffic terminating on the active chassis reaches the MEC by crossing the VSL to the standby chassis. Control protocols continue to run in the active chassis. Protocol messages reach the MEC by crossing the VSL.

All MEC Links to the Standby Chassis Fail

If all links fail to the standby chassis, the MEC becomes a regular EtherChannel with operational links to the active chassis.

Control protocols continue to run in the active chassis. All control and data traffic from the standby chassis reaches the MEC by crossing the VSL to the active chassis.

All MEC Links Fail

If all links in an MEC fail, the logical interface for the EtherChannel is set to unavailable. Layer 2 control protocols perform the same corrective action as for a link-down event on a regular EtherChannel.

On adjacent switches, routing protocols and Spanning Tree Protocol (STP) perform the same corrective action as for a regular EtherChannel.

Standby Chassis Failure

If the standby chassis fails, the MEC becomes a regular EtherChannel with operational links on the active chassis. Connected peer switches detect the link failures, and adjust their load-balancing algorithms to use only the links to the active chassis.

Active Chassis Failure

Active chassis failure results in a stateful switchover (SSO). See the [“VSS Redundancy” section on page 4-13](#) for details about SSO on a VSS. After the switchover, the MEC is operational on the new active chassis. Connected peer switches detect the link failures (to the failed chassis), and adjust their load-balancing algorithms to use only the links to the new active chassis.

Failed Chassis MEC Recovery

When a failed chassis returns to service as the new standby chassis, protocol messages reestablish the MEC links between the recovered chassis and connected peer switches.

Although the recovered chassis' MEC links are immediately ready to receive unicast traffic from the peer switch, received multicast traffic may be lost for a period of several seconds to several minutes. To reduce this loss, you can configure the port load share deferral feature on MEC port channels of the peer switch. When load share deferral is configured, the peer's deferred MEC port channels will establish with an initial load share of 0. During the configured deferral interval, the peer's deferred port channels are capable of receiving data and control traffic, and of sending control traffic, but are unable to forward data traffic to the VSS. See the [“Configuring Port Load Share Deferral on the Peer Switch” section on page 4-50](#) for details about configuring port load share deferral.

Packet Handling

- [Packet Handling Overview, page 4-18](#)
- [Traffic on the VSL, page 4-18](#)
- [Layer 2 Protocols, page 4-19](#)
- [Layer 3 Protocols, page 4-19](#)
- [SPAN Support with VSS, page 4-21](#)

Packet Handling Overview

In VSS mode, the active supervisor engine runs the Layer 2 and Layer 3 protocols and features for the VSS and manages the DFC modules for both chassis.

The VSS uses the VSL to communicate system and protocol information between the peer chassis and to carry data traffic between the two chassis.

Both chassis perform packet forwarding for ingress traffic on their local interfaces. VSS mode minimizes the amount of data traffic that must traverse the VSL.

Traffic on the VSL

The VSL carries data traffic and in-band control traffic between the two chassis. All frames forwarded over the VSL link are encapsulated with a special 32-byte header, which provides information for the VSS to forward the packet on the peer chassis.

The VSL transports control messages between the two chassis. Messages include protocol messages that are processed by the active supervisor engine, but received or transmitted by interfaces on the standby chassis. Control traffic also includes module programming between the active supervisor engine and switching modules on the standby chassis.

The VSS needs to transmit data traffic over the VSL under the following circumstances:

- Layer 2 traffic flooded over a VLAN (even for dual-homed links).
- Packets processed by software on the active supervisor engine where the ingress interface is on the standby chassis.
- The packet destination is on the peer chassis, such as the following examples:
 - Traffic within a VLAN where the known destination interface is on the peer chassis.
 - Traffic that is replicated for a multicast group and the multicast receivers are on the peer chassis.
 - The known unicast destination MAC address is on the peer chassis.
 - The packet is a MAC notification frame destined for a port on the peer chassis.

VSL also transports system data, such as NetFlow export data and SNMP data, from the standby chassis to the active supervisor engine.

To preserve the VSL bandwidth for critical functions, the VSS uses strategies to minimize user data traffic that must traverse the VSL. For example, if an access switch is dual-homed (attached with an MEC terminating on both VSS chassis), the VSS transmits packets to the access switch using a link on the same chassis as the ingress link.

Traffic on the VSL is load-balanced with the same global hashing algorithms available for EtherChannels (the default algorithm is source-destination IP).

Layer 2 Protocols

- [Layer 2 Protocol Overview, page 4-19](#)
- [Spanning Tree Protocol, page 4-19](#)
- [Virtual Trunk Protocol, page 4-19](#)
- [EtherChannel Control Protocols, page 4-19](#)
- [Multicast Protocols, page 4-19](#)

Layer 2 Protocol Overview

The active supervisor engine runs the Layer 2 protocols (such as STP and VTP) for the switching modules on both chassis. Protocol messages that are transmitted and received on the standby chassis switching modules must traverse the VSL to reach the active supervisor engine.

Spanning Tree Protocol

The active chassis runs Spanning Tree Protocol (STP). The standby chassis redirects STP BPDUs across the VSL to the active chassis.

The STP bridge ID is commonly derived from the chassis MAC address. To ensure that the bridge ID does not change after a switchover, the VSS continues to use the original chassis MAC address for the STP Bridge ID.

Virtual Trunk Protocol

Virtual Trunk Protocol (VTP) uses the IP address of the switch and local current time for version control in advertisements. After a switchover, VTP uses the IP address of the newly active chassis.

EtherChannel Control Protocols

Link Aggregation Control Protocol (LACP) and Port Aggregation Protocol (PAgP) packets contain a device identifier. The VSS defines a common device identifier for both chassis to use.

A new PAgP enhancement has been defined for assisting with dual-active scenario detection. For additional information, see the [“Dual-Active Detection” section on page 4-27](#).

Multicast Protocols

With Release 15.1(1)SY1 and later releases, fast-redirect optimization makes multicast traffic redirection between inter-chassis or intra-chassis line cards faster for Layer 2 trunk and Layer3 multichassis EtherChannel or distributed EtherChannel in case of member port link failure and recovery. This operation occurs mainly when a member port link goes down (port leaves the EtherChannel) and when the member port link goes up (port joins or rejoins the EtherChannel). Fast-redirect does not take effect when you add or remove a member port due to a configuration change or during system boot up.

Layer 3 Protocols

- [Layer 3 Protocol Overview, page 4-20](#)
- [IPv4, page 4-20](#)
- [IPv6, MPLS, and VPLS, page 4-20](#)

- [IPv4 Multicast, page 4-20](#)
- [Software Features, page 4-21](#)

Layer 3 Protocol Overview

The RP on the active supervisor engine runs the Layer 3 protocols and features for the VSS. Both chassis perform packet forwarding for ingress traffic on their interfaces. If possible, ingress traffic is forwarded to an outgoing interface on the same chassis, to minimize data traffic that must traverse the VSL.

Because the standby chassis is actively forwarding traffic, the active supervisor engine distributes updates to the standby supervisor engine PFC and all standby chassis DFCs.

IPv4

The supervisor engine on the active chassis runs the IPv4 routing protocols and performs any required software forwarding.

Routing updates received on the standby chassis are redirected to the active chassis across the VSL.

Hardware forwarding is distributed across all DFCs on the VSS. The supervisor engine on the active chassis sends FIB updates to all local DFCs, remote DFCs, and the standby supervisor engine PFC.

All hardware routing uses the router MAC address assigned by the active supervisor engine. After a switchover, the original MAC address is still used.

The supervisor engine on the active chassis performs all software forwarding (for protocols such as IPX) and feature processing (such as fragmentation and TTL exceed). If a switchover occurs, software forwarding is disrupted until the new active supervisor engine obtains the latest CEF and other forwarding information.

In virtual switch mode, the requirements to support non-stop forwarding (NSF) are the same as in standalone mode. See [Chapter 8, “Nonstop Forwarding \(NSF\).”](#)

From a routing peer perspective, EtherChannels remain operational during a switchover (only the links to the failed chassis are down).

The VSS implements path filtering by storing only local paths (paths that do not traverse the VSL) in the FIB entries. Therefore, IP forwarding performs load sharing among the local paths. If no local paths to a given destination are available, the VSS updates the FIB entry to include remote paths (reachable by traversing the VSL).

IPv6, MPLS, and VPLS

The VSS supports IPv6 unicast, MPLS, and VPLS.

IPv4 Multicast

The IPv4 multicast protocols run on the active supervisor engine. Internet Group Management Protocol (IGMP) and Protocol Independent Multicast (PIM) protocol packets received on the standby supervisor engine are transmitted across VSL to the active chassis.

The active supervisor engine sends IGMP and PIM protocol packets to the standby supervisor engine in order to maintain Layer 2 information for stateful switchover (SSO).

The active supervisor engine distributes multicast FIB and adjacency table updates to the standby supervisor engine and switching module DFCs.

For Layer 3 multicast in the VSS, learned multicast routes are stored in hardware in the standby supervisor engine. After a switchover, multicast forwarding continues, using the existing hardware entries.

**Note**

To avoid multicast route changes as a result of the switchover, we recommend that all links carrying multicast traffic be configured as MEC rather than Equal Cost Multipath (ECMP).

In virtual switch mode, the active chassis does not program the multicast expansion table (MET) on the standby chassis. The standby supervisor engine programs the outgoing interface hardware entries for all local multicast receivers.

If all switching modules on the active chassis and standby chassis are egress capable, the multicast replication mode is set to egress mode; otherwise, the mode is set to ingress mode.

In egress replication mode, replication is distributed to DFCs that have ports in outgoing VLANs for a particular flow. In ingress mode, replication for all outgoing VLANs is done on the ingress DFC.

For packets traversing VSL, all Layer 3 multicast replication occurs on the ingress chassis. If there are multiple receivers on the egress chassis, replicated packets are forwarded over the VSL.

Software Features

Software features run only on the active supervisor engine. Incoming packets to the standby chassis that require software processing are sent across the VSL.

For features supported in hardware, the ACL configuration is sent to the TCAM manager on the active supervisor engine, the standby supervisor engine, and all DFCs.

SPAN Support with VSS

The VSS supports all SPAN features for non-VSL interfaces. The VSS supports SPAN features on VSL interfaces with the following limitations:

- VSL ports cannot be a SPAN destination.
- VSL ports cannot be an RSPAN, ERSPAN, or egress-only SPAN source.
- If a VSL port is configured as a local SPAN source, the SPAN destination interface must be on the same chassis as the source interface.
- SPAN copies are always made on the chassis where the ingress port is located.
- Two VSLs cannot share the same SPAN session.
- A pair of LTL indices are used to avoid duplicate SPAN copies across VSL interfaces.

The number of SPAN sessions available to a VSS is the same as for a single chassis running in standalone mode.

With a VSL port as a SPAN source, the following limitations apply:

- The SPAN destination must be on the same chassis.
- Port channel interfaces cannot be the SPAN destination.

System Monitoring

- [Power Management, page 4-22](#)
- [Environmental Monitoring, page 4-22](#)
- [File System Access, page 4-22](#)
- [Diagnostics, page 4-22](#)
-
- [Network Management, page 4-23](#)

Power Management

You can control power-related functions for the standby chassis from the active chassis. For example, to control power to the modules and slots on the standby chassis, use the following commands:

(no) power enable switch <1/2> module <1-7> for C6807-XL chassis.

(no) power enable switch <1/2> module <1-13> for C6500 E-series chassis.

Use the **show power switch<1/2>** command to see the current power settings and status.

Environmental Monitoring

Environmental monitoring runs on both supervisor engines. The standby chassis reports notifications to the active supervisor engine. The active chassis gathers log messages for both chassis. The active chassis synchronizes the calendar and system clock to the standby chassis.

File System Access

You can access file systems of both chassis from the active chassis. Prefix the device name with the switch number and slot number to access directories on the standby chassis. For example, the command **dir sw2-slot6-disk0:** lists the contents of disk0 on the standby chassis (assuming switch 2 is the standby chassis). You can access the standby chassis file system only when VSL is operational.

Diagnostics

You can use the **diagnostic schedule** and **diagnostic start** commands on a VSS. In virtual switch mode, these commands require an additional parameter, which specifies the chassis to apply the command.

When you configure a VSL port on a switching module or a supervisor engine module, the diagnostics suite incorporates additional tests for the VSL ports.

Use the **show diagnostic content** command to display the diagnostics test suite for a module.

VSL Diagnostics

The following VSL-specific diagnostics tests are disruptive:

- TestVSetActiveToStandbyLoopback
- TestVslBridgeLink
- TestVslLocalLoopback

The following VSL-specific diagnostics test is available for VSL ports on switching modules or the supervisor engine. This test is not disruptive:

- TestVslStatus

Network Management

- [Telnet over SSH Sessions and the Web Browser User Interface, page 4-23](#)
- [SNMP, page 4-23](#)
- [Console Connections, page 4-23](#)

Telnet over SSH Sessions and the Web Browser User Interface

VSS mode supports remote access using Telnet over SSH sessions and the Cisco web browser user interface.

All remote access is directed to the active supervisor engine, which manages the VSS.

A VSS switchover disconnects Telnet over SSH sessions and web browser sessions.

SNMP

The SNMP agent runs on the active supervisor engine. CISCO-VIRTUAL-SWITCH-MIB is the MIB for VSS mode and contains the following main components:

- cvsGlobalObjects — Domain #, Switch #, Switch Mode
- cvsCoreSwitchConfig — Switch Priority
- cvsChassisTable — Chassis Role and Uptime
- cvsVSLConnectionTable — VSL Port Count, Operational State
- cvsVSLStatsTable — Total Packets, Total Error Packets
- cvsVSLPortStatsTable — TX/RX Good, Bad, Bi-dir and Uni-dir Packets

Console Connections

Connect console cables to both supervisor engine console ports. The console on the standby chassis adds the characters “-stdby” to the command line prompt to indicate that the chassis is operating in standby mode. You cannot enter configuration mode on the standby chassis console.

The following example shows the prompt on the standby console:

```
Tqwgvt/uvfd{@"ujqy"uykvej"xktvwn
Uykvej"oqfg"XXXXXXXXXXXXXXXXXXXXXktvwn"Uykvej
Xktvwn"uykvej"fqockp"pwodgt"<"322
Nqecn"uykvej"pwodgt"XXXXXXXXXXXXXktvwn"Uykvej"Uvcdfd{
Rggt"uykvej"pwodgt"XXXXXXXXXXXXXktvwn"Uykvej"Cevkxg
Rggt"uykvej"qrgtcvkqpcn"tqng"<"Xktvwn"Uykvej"Cevkxg
```

Convert Port Mode

Supervisor 6T supports the following port modes:

- Default mode (with 8x10G and 2x40G ports operating in over-subscription mode)

- 16x10G ports in Over-subscription mode
- 8x10G ports in Performance mode
- 2x40G ports in Performance mode

**Note**

- The entire systems reloads after any mode conversion.
- Direct mode conversion from non-default mode to non-default mode is not supported.
- To convert from a non-default mode to another non-default mode, convert a supervisor from non-default to default mode and then default to another non-default mode. For example, to move from 8x10G Performance mode to 2x40G Performance mode, convert 8x10G Performance mode to default mode and then from default mode to 2x40G Performance mode.

Convert to 10G Over-subscription Mode (16x10G Ports)

To configure a SUP from default mode to the 10G over-subscription mode (16x10G Ports), use the following commands.

For non-VSS system:

```
jy/oqfwng"unqv"}uwr"unqv"pq0;"qrgtcvkqp/oqfg"rqtv/itqwr"4"VgpIkiCDkvGvjgtpgv
```

For VSS system:

```
jy/oqfwng"uykvej"}uykvej/kf;"unqv"}uwr"unqv"pq0;"qrgtcvkqp/oqfg"rqtv/itqwr"4"VgpIkiCDkvGvjgtpgv
```

Example

```
Tqwgvt*eqphki+%jy/oqfwng"uykvej"4"unqv"5"qrgtcvkqp/oqfg"rqtv/itqwr"4"VgpIkiCDkvGvjgtpgv
Qrgtcvkqp"oqfg"ejcpig"yknn"tgnqcf"vjg"gpvktg"u{uvgo0"Fq"{qw"ycpv"vq"eqpvkpwgA"}eqphkto_
```

To configure the SUP back to default mode from the 10G over-subscription mode (16x10G Ports), use the following commands.

For non-VSS system:

```
pq1fghcwnv"jy/oqfwng"unqv"}uwr"unqv"pq0;"qrgtcvkqp/oqfg"rqtv/itqwr"4"VgpIkiCDkvGvjgtpgv
```

For VSS system:

```
pq1fghcwnv"jy/oqfwng"uykvej"}uykvej/kf;"unqv"}uwr"unqv"pq0;"qrgtcvkqp/oqfg"rqtv/itqwr"4"VgpIkiCDkvGvjgtpgv
```

Example

```
Tqwgvt*eqphki+%pq"jy/oqfwng"uykvej"4"unqv"5"qrgtcvkqp/oqfg"rqtv/itqwr"4"VgpIkiCDkvGvjgtpgv
Qrgtcvkqp"oqfg"ejcpig"yknn"tgnqcf"vjg"gpvktg"u{uvgo0"Fq"{qw"ycpv"vq"eqpvkpwgA"}eqphkto_
```

Convert to 10G Performance Mode

To configure a SUP from default mode to the 10G performance mode, use the following commands.

For non-VSS system:

```
jy/oqfwng"unqv"}uwr"unqv"pq0;"rgthqtocpeg"VgpIkiCDkvGvjgtpgv
```

For VSS system:

```
jy/oqfwng"uykvej"}uykvej/kf;"unqv"}uwr"unqv"pq0;"rgthqtocpeg"VgpIkiCDkvGvjgtpgv
```


Example

```
Tqvwgt*eqphki+%jy/oqfwng"uykvej"3"unqv"5"rgthqtocepeg"VgpIkiCDkvGvjgtpgv
Rgthqtocepeg"oqfg"ejcpig"yknn"tgnqcf"vjg"gpvktg"u{uvgo0"Fq"{qw"ycpv"vq"eqpvkpwgA"}eqphkto_
```

To configure the SUP back to default mode from the 10G performance mode, use the following commands.

For non-VSS system:

```
pqlfghcwnv"jy/oqfwng"unqv"}uwr"unqv"pq0;"rgthqtocepeg
```

For VSS system:

```
pqlfghcwnv"jy/oqfwng"uykvej"}uykvej/kf;"unqv"}uwr"unqv"pq0;"rgthqtocepeg
```

Example

```
Tqvwgt*eqphki+%pq"jy/oqfwng"uykvej"3"unqv"5"rgthqtocepeg
Rgthqtocepeg"oqfg"ejcpig"yknn"tgnqcf"vjg"gpvktg"u{uvgo0"Fq"{qw"ycpv"vq"eqpvkpwgA"}eqphkto_
```

Convert to 40G Performance Mode

To configure a SUP from default mode to the 40G performance mode, use the following commands.

For non-VSS system:

```
jy/oqfwng"unqv"}uwr"unqv"pq0;"rgthqtocepeg"Hqtv{IkiCDkvGvjgtpgv
```

For VSS system:

```
jy/oqfwng"uykvej"}uykvej/kf;"unqv"}uwr"unqv"pq0;"rgthqtocepeg"Hqtv{IkiCDkvGvjgtpgv
```

Example

```
Tqvwgt*eqphki+%jy/oqfwng"uykvej"3"unqv"6"rgthqtocepeg"Hqtv{IkiCDkvGvjgtpgv
Rgthqtocepeg"oqfg"ejcpig"yknn"tgnqcf"vjg"gpvktg"u{uvgo0"Fq"{qw"ycpv"vq"eqpvkpwgA"}eqphkto_
```

To configure the SUP back to default mode from the 40G performance mode, use the following commands.

For non-VSS system:

```
pqlfghcwnv"jy/oqfwng"unqv"}uwr"unqv"pq0;"rgthqtocepeg
```

For VSS system:

```
pqlfghcwnv"jy/oqfwng"uykvej"}uykvej/kf;"unqv"}uwr"unqv"pq0;"rgthqtocepeg
```

Example

```
Tqvwgt*eqphki+%pq"jy/oqfwng"uykvej"3"unqv"6"rgthqtocepeg
Rgthqtocepeg"oqfg"ejcpig"yknn"tgnqcf"vjg"gpvktg"u{uvgo0"Fq"{qw"ycpv"vq"eqpvkpwgA"}eqphkto_
```

Verifying Supervisor Mode after Conversion

Use the following commands to verify the mode of the SUP.

For non-VSS system:

```
ujqy"jy/oqfwng"unqv"}uwr"unqv"pq0;"qrgtcvkqp"oqfg
ujqy"jy/oqfwng"unqv"}uwr"unqv"pq0;"qxgtuwduetkrvkqp
ujqy"jy/oqfwng"unqv"}uwr"unqv"pq0;"rgtv/itqwr/ocrrkpi
ujqy"kpvgthcegu"uvcvwu"oqfwng"}uwr"unqv"pq0;
```

For VSS system:

```
ujqy"jy/oqfwng"uykvej" }uykvej/kf;"unqv"}uwr"unqv"pq0;"qrgtcvkqp"oqfg
ujqy"jy/oqfwng"uykvej" }uykvej/kf;"unqv"}uwr"unqv"pq0;"qrgtcvkqp"oqfg
ujqy"jy/oqfwng"uykvej" }uykvej/kf;"unqv"}uwr"unqv"pq0;"rqtv/itqwr/ocrrkpi
ujqy"kpvgthcegu"uvcvwu"uykvej" }uykvej/kf;"oqfwng"}uwr"unqv"pq0;
```

Example (16x10G Oversubscription Mode)

```
Tqwvgt%ujqy"jy/oqfwng"uykvej"4"unqv"5"qrgtcvkqp"oqfg"
Uykvej"4"oqfwng"5"rqtv/itqwr"3"ku"twppkpi"kp"VgpIkiCDkvGvjgtpgv"oqfg
Uykvej"4"oqfwng"5"rqtv/itqwr"4"ku"twppkpi"kp"VgpIkiCDkvGvjgtpgv"oqfg
```

```
Tqwvgt%ujqy"jy/oqfwng"uykvej"4"unqv"5"qrgtcvkqp"oqfg"
rqtv/itqwr"qrgtcvkqp"oqfg
3"gcdngf
4"gcdngf
```

```
Tqwvgt%ujqy"jy/oqfwng"uykvej"4"unqv"5"rqtv/itqwr/ocrrkpi"
rqtv/itqwr"rqtvu
3"3."4"."5"."6"."7"."8"."9"." : ."
4"33"."34"."35"."36"."37"."38"."39"."3 : ."
```

```
Tqwvgt%ujqy"kpvgthcegu"uvcvwu"uykvej"4"oqfwng"5
```

```
Rqtv"PCog"Uvcvwu"Xncp"Frngz"Urggf"V{rg
Vg41513"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg41514"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg41515"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg41516"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg41517"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg41518"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg41519"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg4151: "fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg415133"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg415134"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg415135"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg415136"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg415137"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg415138"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg415139"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg41513: "fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
```

Example (8x10G Performance Mode)

```
Tqwvgt%ujqy"jy/oqfwng"uykvej"3"unqv"5"qrgtcvkqp"oqfg"
Uykvej"3"oqfwng"5"rqtv/itqwr"3"ku"twppkpi"kp"VgpIkiCDkvGvjgtpgv"oqfg
Uykvej"3"oqfwng"5"rqtv/itqwr"4"ku"twppkpi"kp"VgpIkiCDkvGvjgtpgv"oqfg
```

```
Tqwvgt%ujqy"jy/oqfwng"uykvej"3"unqv"5"qrgtcvkqp"oqfg"
Oqfwng"ku"kp"rghgtocpeg"oqfg"ht"pcvkxg"rqtv"VgpIkiCDkvGvjgtpgv
```

```
Tqwvgt%ujqy"jy/oqfwng"uykvej"3"unqv"5"rqtv/itqwr/ocrrkpi"
rqtv/itqwr"rqtvu
3"7"."8"."9"." : ."
4"3"."4"."5"."6."
```

```
Tqwvgt%ujqy"kpvgthcegu"uvcvwu"uykvej"3"oqfwng"5
```

```
Rqtv"PCog"Uvcvwu"Xncp"Frngz"Urggf"V{rg
Vg31513"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg31514"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg31515"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
Vg31516"fkucdnf"tqwgf"hwnn"32I"Pq"Eqppgevqt
```

```
Vg31517"fkucdnfg"tqwvgf"hwnn"32I"Pq"Eqppgevqt
Vg31518"fkucdnfg"tqwvgf"hwnn"32I"Pq"Eqppgevqt
Vg31519"fkucdnfg"tqwvgf"hwnn"32I"Pq"Eqppgevqt
Vg3151:"fkucdnfg"tqwvgf"hwnn"32I"Pq"Eqppgevqt
oiov2"fkucdnfg"tqwvgf"c/hwnn"c/322"32132213222DcugV
```

Example (2x40G Performance Mode)

```
Tqvwgt%ujqy"jy/oqfwng"uykvej"3"unqv"6"qrgtcvkqp"oqfg"
Uykvej"3"oqfwng"6"rqtv"itqwr"3"ku"twppkpi"kp"Hqtv{IkiCDkvGvjgtpgv"oqfg
Uykvej"3"oqfwng"6"rqtv"itqwr"4"ku"twppkpi"kp"Hqtv{IkiCDkvGvjgtpgv"oqfg
```

```
Tqvwgt%ujqy"jy/oqfwng"uykvej"3"unqv"6"qxgtuwduetkrvkqp"
Oqfwng"ku"kp"rgthqtocpeg"oqfg"hqt"pcvkxg"rqtv"Hqtv{ikiCDkvGvjgtpgv
```

```
Tqvwgt%ujqy"jy/oqfwng"uykvej"3"unqv"6"rqtv/itqwr/ocrrkpi"
rqtv/itqwr"rqtvu
3"32."
4";."
```

```
Tqvwgt%ujqy"kpvgthcegu"uvcvwu"uykvej"3"oqfwng"6
```

```
Rqtv"Pcog"Uvcvwu"Xncp"Fwrngz"Urggf"V{rg
Hq3161;"fkucdnfg"tqwvgf"hwnn"62I"Pq"Eqppgevqt
Hq316132"fkucdnfg"tqwvgf"hwnn"62I"Pq"Eqppgevqt
```

Dual-Active Detection

- [Dual-Active Detection Overview, page 4-27](#)
- [Dual-Active Detection Using Enhanced PAgP, page 4-28](#)
- [Dual-Active Detection Using Dual-Active Fast Hello Packets, page 4-28](#)
- [Recovery Actions, page 4-28](#)

Dual-Active Detection Overview

If the VSL fails, the standby chassis cannot determine the state of the active chassis. To ensure that switchover occurs without delay, the standby chassis assumes the active chassis has failed and initiates switchover to take over the active role.

If the original active chassis is still operational, both chassis are now active. This situation is called a *dual-active scenario*. A dual-active scenario can have adverse affects on network stability, because both chassis use the same IP addresses, SSH keys, and STP bridge ID. The VSS must detect a dual-active scenario and take recovery action.

The VSS supports these following methods for detecting a dual-active scenario:

- Enhanced PAgP—Uses PAgP messaging over the MEC links to communicate between the two chassis through a neighbor switch.
- dual-active fast-hello—Uses special hello messages over a backup Ethernet connection.
- dual-homed FEX—Uses SDP packets over the dual-homed RSL links to communicate between the two chassis.

You can configure any of the detection methods to be active at the same time.

For line redundancy, we recommend dedicating at least two ports per switch for dual-active detection. For module redundancy, the two ports can be on different switching modules in each chassis, and should be on different modules than the VSL links, if feasible.

Dual-Active Detection Using Enhanced PAgP

If a VSS MEC terminates on a Cisco switch, you can run the port aggregation protocol (PAgP) on the MEC. If enhanced PAgP is running on an MEC between the VSS and another switch running Release 12.2(33)SXH1 or a later release, the VSS can use enhanced PAgP to detect a dual-active scenario.

The MEC must have at least one port on each chassis of the VSS. In VSS mode, PAgP messages include a new type length value (TLV) that contains the ID of the VSS active switch. Only switches in VSS mode send the new TLV.

When the VSS standby chassis detects VSL failure, it initiates SSO and becomes VSS active. Subsequent PAgP messages to the connected switch from the newly VSS active chassis contain the new VSS active ID. The connected switch sends PAgP messages with the new VSS active ID to both VSS chassis.

If the formerly active chassis is still operational, it detects the dual-active scenario because the active ID in the PAgP messages changes. This chassis initiates recovery actions as described in the [“Recovery Actions” section on page 4-28](#).

Dual-Active Detection Using Dual-Active Fast Hello Packets

To use the dual-active fast hello packet detection method, you must provision a direct Ethernet connection between the two VSS chassis. You can dedicate up to four non-VSL links for this purpose.

The two chassis periodically exchange special Layer 2 dual-active hello messages containing information about the switch state. If the VSL fails and a dual-active scenario occurs, each switch recognizes from the peer's messages that there is a dual-active scenario and initiates recovery actions as described in the [“Recovery Actions” section on page 4-28](#). If a switch does not receive an expected dual-active fast hello message from the peer before the timer expires, the switch assumes that the link is no longer capable of dual-active detection. For more information, see the [“Configuring Enhanced PAgP Dual-Active Detection” section on page 4-50](#).

Recovery Actions

An active chassis that detects a dual-active condition shuts down all of its non-VSL interfaces (except interfaces configured to be excluded from shutdown) to remove itself from the network, and waits in recovery mode until the VSL links have recovered. You might need to physically repair the VSL failure. When the shut down chassis detects that VSL is operational again, the chassis reloads and returns to service as the standby chassis.

Loopback interfaces are also shut down in recovery mode. Do not configure loopback interfaces while in recovery mode, because any new loopback interfaces configured in recovery mode will not be shut down.



Note

If the running configuration of the chassis in recovery mode has been changed without saving, the chassis will not automatically reload. In this situation, you must save the running configuration and then reload manually.

VSS Initialization

- [VSS Initialization Overview, page 4-29](#)
- [Virtual Switch Link Protocol, page 4-29](#)
- [SSO Dependencies, page 4-29](#)
- [Initialization Procedure, page 4-30](#)

VSS Initialization Overview

A VSS is formed when the two chassis and the VSL link between them become operational. The peer chassis communicate over the VSL to negotiate the chassis roles.

If only one chassis becomes operational, it assumes the active role. The VSS forms when the second chassis becomes operational and both chassis bring up their VSL interfaces.

Virtual Switch Link Protocol

The Virtual Switch Link Protocol (VSLP) consists of several protocols that contribute to virtual switch initialization. The VSLP includes the following protocols:

- Role Resolution Protocol—The peer chassis use Role Resolution Protocol (RRP) to negotiate the role (active or standby) for each chassis.
- Link Management Protocol—The Link Management Protocol (LMP) runs on all VSL links, and exchanges information required to establish communication between the two chassis. LMP identifies and rejects any unidirectional links. If LMP flags a unidirectional link, the chassis that detects the condition brings the link down and up to restart the VSLP negotiation. VSL moves the control traffic to another port if necessary.

SSO Dependencies

For the VSS to operate with SSO redundancy, the VSS must meet the following conditions:

- Identical software versions—Both supervisor engine modules on the VSS must be running the identical software version.
- VSL configuration consistency—During the startup sequence, the standby chassis sends virtual switch information from the startup-config file to the active chassis. The active chassis ensures that the following information matches correctly on both chassis:
 - Switch virtual domain
 - Switch virtual node
 - Switch priority
 - VSL port channel: switch virtual link identifier
 - VSL ports: channel-group number, shutdown, total number of VSL ports
 - Power redundancy-mode
 - Power enable on VSL modules

If the VSS detects a mismatch, it prints out an error message on the active chassis console and the standby chassis comes up in RPR mode.

After you correct the configuration file, save the file by entering the **copy running-config startup-config** command on the active chassis, and then restart the standby chassis.

- PFC mode check—If both supervisor engines are provisioned with PFC4, the VSS will automatically operate in PFC4 mode, even if some of the switching modules are equipped with DFC4XLs.

However, if the supervisor engines are provisioned with PFC4XL and there is a mixture of DFC4 and DFC4XL switching modules, the system PFC mode will depend on how the DFC4XL and DFC4XL switching modules are distributed between the two chassis.

Each chassis in the VSS determines its system PFC mode. If the supervisor engine of a given chassis is provisioned with PFC4XL and all the switching modules in the chassis are provisioned with DFC4XL, the PFC mode for the chassis is PFC4XL. However, if any of the switching modules is provisioned with DFC4, the chassis PFC mode will be set to PFC4. If there is a mismatch between the PFC modes of two chassis, the VSS will come up in RPR mode instead of SSO mode. You can prevent this situation by using the **platform hardware vsl pfc mode non-xl** command to force the VSS to operate in PFC4 mode after the next reload.

- SSO and NSF enabled—SSO and NSF must be configured and enabled on both chassis. For detailed information on configuring and verifying SSO and NSF, see [Chapter 8, “Nonstop Forwarding \(NSF\).”](#)

If these conditions are not met, the VSS operates in RPR redundancy mode. For a description of SSO and RPR, see the [“VSS Redundancy” section on page 4-13](#).

Initialization Procedure

- [VSL Initialization, page 4-30](#)
- [System Initialization, page 4-30](#)
- [VSL Down, page 4-31](#)

VSL Initialization

A VSS is formed when the two chassis and the VSL link between them become operational. Because both chassis need to be assigned their role (active or standby) before completing initialization, VSL is brought online before the rest of the system is initialized. The initialization sequence is as follows:

1. The VSS initializes all cards with VSL ports, and then initializes the VSL ports.
2. The two chassis communicate over VSL to negotiate their roles (active or standby).
3. The active chassis completes the boot sequence, including the consistency check described in the [“SSO Dependencies” section on page 4-29](#).
4. If the consistency check completed successfully, the standby chassis comes up in SSO standby mode. If the consistency check failed, the standby chassis comes up in RPR mode.
5. The active chassis synchronizes configuration and application data to the standby chassis.

System Initialization

If you boot both chassis simultaneously, the VSL ports become active, and the chassis will come up as active and standby. If priority is configured, the higher priority switch becomes active.

If you boot up only one chassis, the VSL ports remain inactive, and the chassis comes up as active. When you subsequently boot up the other chassis, the VSL links become active, and the new chassis comes up as standby.

VSL Down

If the VSL is down when both chassis try to boot up, the situation is similar to a dual-active scenario. One of the chassis becomes active and the other chassis initiates recovery from the dual-active scenario. For further information, see the [“Configuring Dual-Active Detection” section on page 4-50](#).

Default Settings for VSS

None.

How to Configure a VSS

- [Configuring Easy VSS, page 4-31](#)
- [Converting to a VSS, page 4-32](#)
- [Displaying VSS Information, page 4-38](#)
- [Converting a VSS to Standalone Chassis, page 4-39](#)
- [Configuring VSS Parameters, page 4-40](#)
- [Configuring Multichassis EtherChannels, page 4-49](#)
- [Configuring Port Load Share Deferral on the Peer Switch, page 4-50](#)
- [Configuring Dual-Active Detection, page 4-50](#)
-
- [How to Upgrade a VSS, page 4-54](#)

Configuring Easy VSS

Easy VSS mode allows the conversion of standalone switches into one virtual switching system (VSS) using a single command.

The following prerequisites must be fulfilled for successful configuration of Easy VSS:

- Both the switches must be in standalone mode
- Easy VSS mode must be enabled on both the switches
- CDP should be running between interfaces
- Any manual configurations done using **switch virtual domain** *domain id* command will be lost

To configure Easy VSS mode, perform the following tasks:

Converting to a VSS

- [VSS Conversion Overview, page 4-32](#)
- [Backing Up the Standalone Configuration, page 4-33](#)
- [Configuring SSO and NSF, page 4-33](#)
- [Assigning Virtual Switch Domain and Switch Numbers, page 4-34](#)
- [Configuring the VSL Port Channel, page 4-35](#)
- [Configuring the VSL Ports, page 4-35](#)
- [Verifying the PFC Operating Mode, page 4-36](#)
- [Converting the Chassis to Virtual Switch Mode, page 4-37](#)
- [Auto-Configuring the Standby VSL Information, page 4-37](#)
- [\(Optional\) Configuring Standby Chassis Modules, page 4-38](#)

VSS Conversion Overview

The standalone mode is the default operating mode (a single chassis switch). VSS mode combines two standalone switches into one virtual switching system (VSS), operating in VSS mode.



Note


When you convert two standalone switches into one VSS, all non-VSL configuration settings on the standby chassis revert to default settings.

To convert two standalone chassis into a VSS, perform the following major activities:

- Save the standalone configuration files.
- Configure SSO and NSF on each chassis.
- Configure each chassis as a VSS.
- Convert to a VSS.
- Configure the peer VSL information.

In the procedures that follow, the example commands assume the configuration shown in [Figure 4-10](#).

Figure 4-10 Example VSS



Two chassis, A and B, are converted into a VSS with virtual switch domain 100. 10-Gigabit Ethernet port 5/1 on Switch 1 is connected to 10-Gigabit Ethernet port 5/2 on Switch 2 to form the VSL.

Backing Up the Standalone Configuration

Save the configuration files for both chassis. These files are needed to revert to standalone mode from virtual switch mode.

Switch 1 Task

	Command	Purpose
Step 1	<code>Uykvej/3%eqr{"twppkpi/eqphki"uvctvwr/eqphki</code>	(Optional) Saves the running configuration to startup configuration.
Step 2	<code>Uykvej/3%eqr{"uvctvwr/eqphki" fkum2<qnf/uvctvwr/eqphki</code>	Copies the startup configuration to a backup file.

Switch 2 Task

	Command	Purpose
Step 1	<code>Uykvej/4%eqr{"twppkpi/eqphki"uvctvwr/eqphki</code>	(Optional) Saves the running configuration to the startup configuration file.
Step 2	<code>Uykvej/4%eqr{"uvctvwr/eqphki" fkum2<qnf/uvctvwr/eqphki</code>	Copies the startup configuration to a backup file.

Configuring SSO and NSF

SSO and NSF must be configured and enabled on both chassis.

Switch 1 Task

	Command	Purpose
Step 1	<code>Uykvej/3*eqphki+%tgfwfpcpe{"</code>	Enters redundancy configuration mode.
Step 2	<code>Uykvej/3*eqphki/tgf+%oqfg"uuq"</code>	Configures SSO. When this command is entered, the redundant supervisor engine is reloaded and begins to work in SSO mode.
Step 3	<code>Uykvej/3*eqphki/tgf+%gzkv"</code>	Exits redundancy configuration mode.
Step 4	<code>Uykvej/3*eqphki+%tqwgvt"qurh"processID"</code>	Enables an OSPF routing process, which places the router in router configuration mode.
Step 5	<code>Uykvej/3*eqphki/tqwgvt+%puh"</code>	Enables NSF operations for OSPF.
Step 6	<code>Uykvej/3*eqphki/tqwgvt+%gpf"</code>	Exits to privileged EXEC mode.
Step 7	<code>Uykvej/3%"ujqy"twppkpi/eqphki"</code>	Verifies that SSO and NSF are configured and enabled.
Step 8	<code>Uykvej/3%"ujqy"tgfwfpcpe{"uvcvgu"</code>	Displays the operating redundancy mode.

Switch 2 Task

	Command	Purpose
Step 1	Uykvej/4*eqphki+% "tgfwfcppe{	Enters redundancy configuration mode.
Step 2	Uykvej/4*eqphki/tgf+% "oqfg"uuq	Configures SSO. When this command is entered, the redundant supervisor engine is reloaded and begins to work in SSO mode.
Step 3	Uykvej/4*eqphki/tgf+% "gzkv	Exits redundancy configuration mode.
Step 4	Uykvej/4*eqphki+% "tqwvgt"qurh" <i>processID</i>	Enables an OSPF routing process, which places the router in router configuration mode.
Step 5	Uykvej/4*eqphki/tqwvgt+% "puh"	Enables NSF operations for OSPF.
Step 6	Uykvej/4*eqphki/tqwvgt+% "gpf	Exits to privileged EXEC mode.
Step 7	Uykvej/4%" ujqy"twppkpi/eqphki	Verifies that SSO and NSF are configured and enabled.
Step 8	Uykvej/4%" ujqy"tgfwfcppe{ "uvcvgu	Displays the operating redundancy mode.

For detailed information on configuring and verifying SSO and NSF, see [Chapter 8, “Nonstop Forwarding \(NSF\).”](#)

Assigning Virtual Switch Domain and Switch Numbers

Configure the same virtual switch domain number on both chassis. The virtual switch domain is a number between 1 and 255, and must be unique for each VSS in your network (the domain number is incorporated into various identifiers to ensure that these identifiers are unique across the network). Within the VSS, you must configure one chassis to be switch number 1 and the other chassis to be switch number 2.

Switch 1 Task

	Command	Purpose
Step 1	"Uykvej/3*eqphki+% "uykvej"xktvwn"fqockp"322	Configures the virtual switch domain on Chassis A.
Step 2	"Uykvej/3*eqphki/xu/fqockp+% "uykvej"3	Configures Chassis A as virtual switch number 1.
Step 3	"Uykvej/3*eqphki/xu/fqockp+% "gzkv	Exits config-vs-domain.

Switch 2 Task

	Command	Purpose
Step 1	"Uykvej/4*eqphki+% "uykvej"xktvwn"fqockp"322"	Configures the virtual switch domain on Chassis B.
Step 2	"Uykvej/4*eqphki/xu/fqockp+% "uykvej"4	Configures Chassis B as virtual switch number 2.
Step 3	"Uykvej/4*eqphki/xu/fqockp+% "gzkv	Exits config-vs-domain.

**Note**

The switch number is not stored in the startup or running configuration, because both chassis use the same configuration file (but must not have the same switch number).

Configuring the VSL Port Channel

The VSL is configured with a unique port channel on each chassis. During the conversion, the VSS configures both port channels on the active chassis. If the standby chassis VSL port channel number has been configured for another use, the VSS comes up in RPR mode. To avoid this situation, check that both port channel numbers are available on both of the chassis.

Check the port channel number by using the **show running-config interface port-channel** command. The command displays an error message if the port channel is available for VSL. For example, the following command shows that port channel 20 is available on Switch 1:

```
Uykvej/3"%ujqy"twppkpi/eqphki"kpvgthceg"rqtv/ejcppgn"42
' "Kpxcnkf"kprwv"fgvgevfg"cv") ' ) "octmgt0
```

Switch 1 Task

	Command	Purpose
Step 1	"Uykvej/3*eqphki+% "kpvgthceg"rqtv/ejcppgn"32	Configures port channel 10 on Switch 1.
Step 2	"Uykvej/3*eqphki/kh+% "uykvej "xktvwc n"nkpm"3	Associates Switch 1 as owner of port channel 10.
Step 3	"Uykvej/3*eqphki/kh+% "pq"ujwvfqyp	Activates the port channel.
Step 4	"Uykvej/3*eqphki/kh+% "gzkv	Exits interface configuration.

Switch 2 Task

	Command	Purpose
Step 1	"Uykvej/4*eqphki+% "kpvgthceg"rqtv/ejcppgn"42	Configures port channel 20 on Switch 2.
Step 2	"Uykvej/4*eqphki/kh+% "uykvej "xktvwc n"nkpm"4	Associates Switch 2 as owner of port channel 20.
Step 3	"Uykvej/4*eqphki/kh+% "pq"ujwvfqyp	Activates the port channel.
Step 4	"Uykvej/4*eqphki/kh+% "gzkv	Exits interface configuration mode.

Configuring the VSL Ports

You must add the VSL physical ports to the port channel. In the following example, 10-Gigabit Ethernet ports 3/1 and 3/2 on Switch 1 are connected to 10-Gigabit Ethernet ports 5/2 and 5/3 on Switch 2. For VSL line redundancy, configure the VSL with at least two ports per chassis. For module redundancy, the two ports can be on different switching modules in each chassis.

Switch 1 Task

	Command	Purpose
Step 1	Uykvej/3*eqphki+% "kpvgtbceg"tcpig"vgpikicdkvgvjgtpgv 513/4	Enters configuration mode for interface range tengigabitethernet 3/1-2 on Switch 1.
Step 2	Uykvej/3*eqphki/kh+% "ejcppgn/itqwr"32"oqfg"qp	Adds this interface to channel group 10.
Step 3	Uykvej/3*eqphki/kh+% "pq"ujwvfqyp	Activates the port.

Switch 2 Task

	Command	Purpose
Step 1	Uykvej/4*eqphki+% "kpvgtbceg"tcpig"vgpikicdkvgvjgtpgv"714/5	Enters configuration mode for interface range tengigabitethernet 5/2-3 on Switch 2.
Step 2	Uykvej/4*eqphki/kh+% "ejcppgn/itqwr"42"oqfg"qp	Adds this interface to channel group 10.
Step 3	Uykvej/4*eqphki/kh+% "pq"ujwvfqyp	Activates the port.

Verifying the PFC Operating Mode

Ensure that the PFC operating mode matches on both chassis. Enter the **show platform hardware pfc mode** command on each chassis to display the current PFC mode. If only one of the chassis is in PFC4XL mode, you can configure it to use PFC4 mode with the **platform hardware vsl pfc mode non-xl** command.

Switch 1 Task

	Command	Purpose
Step 1	Uykvej/3% "ujqy"rncvhtqto"jctfyctg"rhe"oqfg"	Ensures that the PFC operating mode matches on both chassis, to ensure that the VSS comes up in SSO redundancy mode.
Step 2	Uykvej/3*eqphki+% "rncvhtqto"jctfyctg"xun"rhe"oqfg"pqp/zn"	(Optional) Sets the PFC operating mode to PFC4 on Chassis A.

Switch 2 Task

	Command	Purpose
Step 3	Uykvej/4% "ujqy"rncvhtqto"jctfyctg"rhe"oqfg"	Ensures that the PFC operating mode matches on both chassis, to ensure that the VSS comes up in SSO redundancy mode.
Step 4	Uykvej/4*eqphki+% "rncvhtqto"jctfyctg"xun"rhe"oqfg"pqp/zn"	(Optional) Sets the PFC operating mode to PFC4 on Chassis B.

Converting the Chassis to Virtual Switch Mode

Conversion to VSS mode requires a restart for both chassis. After the reboot, commands that specify interfaces with *module #/port #* now include the switch number. For example, a port on a switching module is specified by *switch_#/module_#/port_#*.

Before restarting, the VSS converts the startup configuration to use the *switch_#/module_#/port_#* convention. A backup copy of the startup configuration file is saved on the RP. This file is assigned a default name, but you are also prompted to override the default name if you want to change it.

Switch 1 Task

Command	Purpose
<code>Uykvej/3%"uykvej"eqpxgtv"oqfg"xktvwcñ"</code>	Converts Switch 1 to virtual switch mode. After you enter the command, you are prompted to confirm the action. Enter yes. The system creates a converted configuration file, and saves the file to the RP bootflash.

Switch 2 Task

Command	Purpose
<code>Uykvej/4%"uykvej"eqpxgtv"oqfg"xktvwcñ"</code>	Converts Switch 2 to virtual switch mode. After you enter the command, you are prompted to confirm the action. Enter yes. The system creates a converted configuration file, and saves the file to the RP bootflash.

After you confirm the command (by entering **yes** at the prompt), the running configuration is automatically saved as the startup configuration and the chassis reboots. After the reboot, the chassis is in virtual switch mode, so you must specify interfaces with three identifiers (*switch_#/module_#/port_#*).

Auto-Configuring the Standby VSL Information

The two chassis now form a VSS, and the system will auto-configure the standby VSL. After the merge has completed successfully, enter all configuration commands for the VSS on the active chassis. The startup configuration file is automatically synchronized to the standby chassis after the standby chassis reaches the ready state. The VSSmode automatically merges the configuration information on the standby chassis.

All non-VSL interface configurations on the standby chassis revert to the default configuration and non-VSL related configurations are not merged. If you fail to perform any of the required configurations, you will have to repeat the configuration on the active chassis. Auto-configuration merges these commands for the standby chassis:

- **hw-module switch** *number slot number*
- **switch virtual domain** *number*
- **switch** *number priority priority*

- **power redundancy-mode combined switch** *number*
- **no power enable switch** *num module number*
- **interface port-channel** *num switch virtual link number*
- **interface** *type switch_#/slot_#/port_# channel-group number mode on*

(Optional) Configuring Standby Chassis Modules

After the reboot, each chassis contains the module provisioning for its own slots. In addition, the modules from the standby chassis are automatically provisioned on the active chassis with default configuration.

Configurations for the standby chassis modules revert to their default settings (for example, no IP addresses).

You can view the module provisioning information in the configuration file, by entering the **show startup-config** command (after you have saved the configuration).



Note

Do not delete or modify this section of the configuration file. In Cisco IOS Release 12.2(50)SY and later releases, you can no longer add module provisioning entries using the **module provision** CLI command. When a module is not present, the provisioning entry for that module can be cleared using the **no slot** command with the **module provision** CLI command. Note that the VSS setup does not support the **module clear-config** command.

The following example shows the module provisioning information from a configuration file:

```
oqfwng"rtqpkukqp"uykvej"3"
"unqv"3"unqv/v{rg"36:"rqtv/v{rg"82"pwodgt"6:"xktvwn/unqv"39"
"unqv"4"unqv/v{rg"359"rqtv/v{rg"53"pwodgt"38:"xktvwn/unqv"3:"
"unqv"5"unqv/v{rg"449"rqtv/v{rg"82"pwodgt"::"xktvwn/unqv"3;"
"unqv"6"unqv/v{rg"447"rqtv/v{rg"83"pwodgt"6:"xktvwn/unqv"42"
"unqv"7"unqv/v{rg":4"rqtv/v{rg"53"pwodgt"4:"xktvwn/unqv"43"
oqfwng"rtqpkukqp"uykvej"4"
"unqv"3"unqv/v{rg"36:"rqtv/v{rg"82"pwodgt"6:"xktvwn/unqv"55"
"unqv"4"unqv/v{rg"449"rqtv/v{rg"82"pwodgt"::"xktvwn/unqv"56"
"unqv"5"unqv/v{rg"359"rqtv/v{rg"53"pwodgt"38:"xktvwn/unqv"57"
"unqv"6"unqv/v{rg"447"rqtv/v{rg"83"pwodgt"6:"xktvwn/unqv"58"
"unqv"7"unqv/v{rg":4"rqtv/v{rg"53"pwodgt"4:"xktvwn/unqv"59"
```

Displaying VSS Information

These commands display basic information about the VSS:

Command	Purpose
<code>ujqy"uykvej"xktvwn</code>	Displays the virtual switch domain number, and the switch number and role for each of the chassis.
<code>ujqy"uykvej"xktvwn"tqng</code>	Displays the role, switch number, and priority for each of the chassis in the VSS.
<code>ujqy"uykvej"xktvwn"nkpm</code>	Displays the status of the VSL.

The following example shows the information output from these commands:

```
Tqwgvt% "ujqy"uykvej "xktvwn"
Uykvej "oqfg" <"Xktvwn"Uykvej
Xktvwn"uykvej"fqockp"pwodgt" <"322
Nqecn"uykvej"pwodgt" <"3
Nqecn"uykvej"qrgtcvkqpcn"tqng" <"Xktvwn"Uykvej"cevkg
Rgg"uykvej"pwodgt" <"4
Rgg"uykvej"qrgtcvkqpcn"tqng" <"Xktvwn"Uykvej"Uvcpf{

Tqwgvt% "ujqy"uykvej "xktvwn"tqng"
Uykvej "Uykvej"Uvcvwu"Rtggorv"Rtkqtkv{"Tqng"Uguukqp"KF
"pwodgt"Qrgt*Eqph+Qrgt*Eqph+Nqecn"Tgoqvg
////////////////////////////////////
NQECN"3"WR"HCNUG*P+"322*322+"CEVKXG"2"
TGOQVG"4"WR"HCNUG*P+"322*322+"UVCPFD["37:"3";3

Kp"fwcn/cevkg"tgeqxt{"oqfg"Pg

Tqwgvt% "ujqy"uykvej "xktvwn"nkpm"
XUN"Uvcvwu"WR
XUN"Wrvgog"6"jqtu.48"okpwvgu
XUN"UER"Rkpi"Rcuu"QM
XUN"KEE"Rkpi"Rcuu
XUN"Eqvptqn"Nkpm"Vg"31713
```

Converting a VSS to Standalone Chassis

- [Copying the VSS Configuration to a Backup File, page 4-39](#)
- [Converting the Active Chassis to Standalone, page 4-39](#)
- [Converting the Peer Chassis to Standalone, page 4-40](#)

Copying the VSS Configuration to a Backup File

Save the configuration file from the active chassis. You may need this file if you convert to virtual switch mode again. You only need to save the file from the active chassis, because the configuration file on the standby chassis is identical to the file on the active chassis.

	Command	Purpose
Step 1	Uykvej/3% "eqr{"twppkpi/eqphki"uvctvwr/eqphki	(Optional) Saves the running configuration to startup configuration. This step is only required if you there are unsaved changes in the running configuration that you want to preserve.
Step 2	Uykvej/3% "eqr{"uvctvwr/eqphki"fkum2<xu/uvctvwr/eqphki	Copies the startup configuration to a backup file.

Converting the Active Chassis to Standalone

When you convert the active chassis to standalone mode, the active chassis removes the provisioning and configuration information related to VSL links and the peer chassis modules, saves the configuration file, and performs a reload. The chassis comes up in standalone mode with only the provisioning and configuration data relevant to the standalone system.

The standby chassis of the VSS becomes active. VSL links on this chassis are down because the peer is no longer available.

To convert the active chassis to standalone mode, perform this task on the active chassis:

Command	Purpose
<code>Uykvej/3% "uykvej" eqpxgtv"oqfg" uvcpf/cnqpg"</code>	Converts Switch 1 to standalone mode. After you enter the command, you are prompted to confirm the action. Enter yes .

Converting the Peer Chassis to Standalone

When you convert the new active chassis to standalone mode, the chassis removes the provisioning and configuration information related to VSL links and the peer chassis modules, saves the configuration file and performs a reload. The chassis comes up in standalone mode with only its own provisioning and configuration data.

To convert the peer chassis to standalone, perform this task on the standby chassis:

Command	Purpose
<code>Uykvej/4% "uykvej" eqpxgtv"oqfg" uvcpf/cnqpg"</code>	Converts Switch 2 to standalone mode. After you enter the command, you are prompted to confirm the action. Enter yes .

Configuring VSS Parameters

- [Configuring VSL Switch Priority, page 4-41](#)
- [Configuring the PFC Mode, page 4-42](#)
- [Configuring a VSL, page 4-42](#)
- [Configuring VSL Encryption, page 4-43](#)
- [Displaying VSL Information, page 4-45](#)
- [Configuring VSL QoS, page 4-46](#)
- [Subcommands for VSL Port Channels, page 4-46](#)
- [Subcommands for VSL Ports, page 4-47](#)
- [Configuring the Router MAC Address Assignment, page 4-47](#)

Configuring the PFC Mode

If you have a mixture of DFC4 and DFC4XL switching modules in the VSS, set the PFC mode by performing this task:

Command	Purpose
<code>Tqwwgt*eqphki+%"rncvhtqto"jctfyctg"xun"rhe"oqfg"pqp/zn"</code>	Sets the PFC configuration mode for the VSS to PFC4.
	Note This command requires a system reload before it takes effect.

This example shows how to set the PFC configuration mode for the VSS to PFC4. You can wait until the next maintenance window to perform the **reload** command.

```
Tqwwgt*eqphki+%"rncvhtqto"jctfyctg"xun"rhe"oqfg"pqp/zn
Tqwwgt*eqphki+%gpf
Tqwwgt%tgngcf
```

If all the supervisor engines and switching modules in the VSS are XL, the following warning is displayed if you set the PFC mode to PFC4:

```
Tqwwgt*eqphki+%"rncvhtqto"jctfyctg"xun"rhe"oqfg"pqp/zn
RHE"Rtghgttgf"Oqfg<"RHE6ZN0"Vjg"fkuetgrcpe{"dgvyggp"Qrgtcvkpi"Oqfg"cpf
Rtghgttgf"Oqfg"eqwnf"dg"fwg"vq"RHE"oqfg"eqphki0"[qwt"U{uvgo"jcu"cnn"RHE6ZN"oqfwngu0
Tgoqxg")"rncvhtqto"jctfyctg"xun"rhe"oqfg"pqp/zn")"htgo"inqdcn"eqphki0
```

This example shows how to display the operating and configured PFC modes:

```
Tqwwgt%"ujqy"rncvhtqto"jctfyctg"rhe"oqfg
RHE"qrgtcvkpi"oqfg"<"RHE6
Eqphkiwtgf"RHE"qrgtcvkpi"oqfg"<"RHE6
```

Configuring a VSL

To configure a port channel to be a VSL, perform this task:

	Command	Purpose
Step 1	<code>Tqwwgt*eqphki+%"kpvgthceg"rqtv/ejcppgn"<i>channel_num</i></code>	Enters configuration mode for the specified port channel.
Step 2	<code>Tqwwgt*eqphki/kh+%"uykvej"xktvwcen"nkpm"<i>switch_num</i></code>	Assigns the port channel to the virtual link for the specified switch.



Note

We recommend that you configure the VSL prior to converting the chassis into a VSS.

This example shows how to configure the VSL:

```
Uykvej/3*eqphki+%"kpvgthceg"rqtv/ejcppgn"32"
Uykvej/3*eqphki/kh+%"uykvej"xktvwcen"nkpm"3
Uykvej/3*eqphki/kh+%"pq"ujwvfqyp
Uykvej/3*eqphki+%"kpvgthceg"vgpIkiCDkvGvjgtpgv"713
Uykvej/3*eqphki/kh+%"ejcppgn/itqwr"32"oqfg"qp
Uykvej/3*eqphki/kh+%"pq"ujwvfqyp
```

```

Uykvej/4*eqphki+%"kpvgtthceg"rqtv/ejcppgn"47"
Uykvej/4*eqphki/kh+%"uykvej"xktvwn"nkpm"4
Uykvej/4*eqphki/kh+%"pq"ujwvfqyp
Uykvej/4*eqphki/kh+%"kpvgtthceg"vgpIkiCDkvGvjgtpgv"714
Uykvej/4*eqphki/kh+%"ejcppgn/itqwr"47"oqfg"qp
Uykvej/4*eqphki/kh+%"pq"ujwvfqyp

```

Configuring VSL Encryption

- [VSL Encryption Overview, page 4-43](#)
- [VSL Encryption Restrictions, page 4-43](#)
- [Configuring the VSL Encryption Key, page 4-44](#)
- [Enabling VSL Encryption, page 4-44](#)
- [Displaying the VSL Encryption State, page 4-45](#)

VSL Encryption Overview

Cisco IOS Release 15.4SY supports HW-based encryption on a VSL configured on a Supervisor Engine 6T or any VSL capable line cards. VSL encryption uses an encryption key that you manually configure. The encryption key is stored securely.

VSL Encryption Restrictions

- VSL encryption requires a MACSec license on each chassis.
- The chassis must be rebooted to configure an encryption key or enable VSL encryption.
- You enter the encryption key on the active chassis. You cannot enter the encryption key on the standby chassis.
- If it is acceptable to send the key as plain text over the VSL to the other chassis, then you can allow one chassis to send the key to the other chassis. For maximum security, configure the encryption key on each chassis.
- There are no **show** commands that display the encryption key.
- You cannot remove the encryption key while VSL encryption is enabled.
- The following commands take effect after a reboot:
 - To remove the encryption key, enter the **clear switch pmk** EXEC mode command.
 - To disable VSL encryption, enter the **no vsl-encryption** virtual switch domain configuration submode command.
- If the encryption key and VSL encryption state on the two chassis do not match, the VSL does not transition to the link-up state.

- In VSS mode, you cannot configure the FIPS encryption mode without VSL encryption. To avoid a system shutdown, enable VSL encryption before you enable FIPS encryption mode. (CSCts96040, CSCtx58304)

Configuring the VSL Encryption Key

To configure the VSL encryption key, perform this task:

Command	Purpose
<code>Tqwvgt%"uykvej"rom"gp{rvkqpamg{"</code>	Configures the VSL encryption key. <i>encryption_key</i> is a hexadecimal string up to 32 characters (256 bits). - You will be asked if you want to automatically synchronize the encryption key. If you do not automatically synchronize the encryption key, configure the same encryption key on the other chassis.

This example show how to configure a VSL encryption key:

```
Tqwvgt%"uykvej"rom"gp{rvkqpamg{"
Mg{"ghhgevkxg"qpn{"wrqp"tgdaqv"cpf"yknn"qxgttkfg"qnf"XUN"ROM0
Mg{"pggfu"vq"dg"rtqzkukqpgf"qp"dqvj"XUU"uykvejgu0
Yctpkpi"/"Ugpfkpi"vjg"mg{"vq"uvcpfd{"yknn"ecwug"vjg"mg{"vq"dg"ugpv"qxgt"cp"wpgp{rvgf"XUN"
nkp0"
Fq{"qw"ycpv"vq"cwvqocvkecnn{"u{pejtpk|g"vjg"mg{""]{gu1pq_A
```

Enabling VSL Encryption

To enable VSL encryption, perform this task:

	Command	Purpose
Step 1	<code>Tqwvgt*eqphki+%"uykvej"xktvwn"fqockp"fqockpakf"</code>	Enters VSS configuration mode.
Step 2	<code>Tqwvgt*eqphki/xu/fqockp+%"xun/gp{rvkqp"</code>	Enables VSL encryption.

This example shows how to enable VSL encryption:

```
Tqwvgt*eqphki+%"uykvej"xktvwn"fqockp"fqockpakf"
Tqwvgt*eqphki/xu/fqockp+%"xun/gp{rvkqp"
```



- If you manually configure the encryption key on each chassis:
 - Configure the encryption key on the active chassis.
 - Reboot the active chassis; the standby chassis becomes active.
 - Configure the encryption key on new active chassis.
 - Enable VSL encryption.
 - Reboot the entire VSS.
- If you allow the encryption key to be sent to the standby chassis, reboot the entire VSS after configuring the encryption key and enabling VSL encryption on the active chassis.

This example shows how to display the VSL encryption state:

Tqwvgt%"ujqy"uykvej"xktvwc"nkpm"~"kpenwfg"Gpet{rvkqp"
XUN"Gpet{rvkqp"<"Eqphkiwtgf"Oqfg"/"Qp."Qrgtcvkapcn"Oqfg"/"Qp"

To display information about the VSL, perform one of these tasks:

Command	Purpose
Tqvwgt% "ujqy"uykvej "xktvwcn"nkpm"	Displays information about the VSL.
Tqvwgt% "ujqy"uykvej "xktvwcn"nkpm" rqtv/ejcppgn	Displays information about the VSL port channel.
Tqvwgt% "ujqy"uykvej "xktvwcn"nkpm" rqtv	Displays information about the VSL ports.

Tqwgvgt%**"ujqy"uykvej"xktvwcn"nkpm"**
XUN"Uvcvwu"<"WR
XUN"Wrvkog"<"3"fc{."5"jqwtu."5;"okpwvgu
XUN"UER"Rkpi"<"Rcuu
XUN"KEE"Rkpi"<"Rcuu
XUN"Eqpvtn"Nkpm"<"Vg"31713"

Tqvwgt%"ujqy"uykvej"xktvwc n"nkpm"rqt v/ejcppgn
XUN"Rqt v"Ejcppgn"Kphqtocvkqp

```
Hnciu<"F"/"fqyp"*****R"/"dwpfngf"kp"rqtV/ejcppgn
*****K"/"uvcpf/cnppg"u"/"uwurgpfgf
*****J"/"Jqv/uvcpfd{"*NCER"qpn{+
*****T"/"Nc{gt5*****U"/"Nc{gt4
*****W"/"kp"wug*****P"/"pqv"kp"wug."pq"ciitgicvkqp
*****h"/"hckngf"vg"cnngqcvg"ciitgicvqt
```

```

"O"/"pqv"kp"wug."pq"ciitgicvkqp"fwg"vq"okpkowo"nkpmu"pqv"ogv
"o"/"pqv"kp"wug."rqtv"pqv"ciitgicvgf"fwg"vq"okpkowo"nkpmu"pqv"ogv
"w"/"wpuwkvcdng"tgt"dwpfnkpi
"y"/"yckvkpi"vq"dg"ciitgicvgf

```

Itqwr" "Rqtv/ejcppqn" "Rtqvgegn" " " "Rqtvu

Configuring VSL QoS

In Cisco IOS Release 12.2(50)SY and later releases, when the **platform qos 10g-only** command is entered and only one of the two 10-Gigabit Ethernet ports on the supervisor engine is a VSL port, the non-VSL 10-Gigabit Ethernet port can be configured for QoS.

Subcommands for VSL Port Channels

Table 4-2 Interface Subcommands for VSL Port Channels

Subcommand	Description
default	Sets a command to its defaults.
description	Enters a text description for the interface.

Table 4-2 *Interface Subcommands for VSL Port Channels (continued)*

Subcommand	Description
exit	Exits from interface configuration mode.
load-interval	Specifies interval for load calculation for an interface.
logging	Configures logging for interface.
platform	Specifies platform-specific command.
no	Disables a command, or sets the command defaults.
shutdown	Shuts down the selected interface.
switch virtual link	Specifies the switch associated with this port channel.
vslp	Specifies VSLP interface configuration commands.

Subcommands for VSL Ports

If a port is included in a VSL port channel, only a subset of interface subcommands are available in the command console. [Table 4-3](#) describes the available interface subcommands.

Table 4-3 *Interface Subcommands for VSL Ports*

Subcommand	Description
channel-group	Adds the interface to the specified channel group.
default	Sets a command to its defaults.
description	Adds a description to the interface.
exit	Exits from interface configuration mode.
load-interval	Specifies interval for load calculation for an interface.
logging	Configures logging for the interface.
no	Disables a command, or sets the command defaults.
shutdown	Shuts down the selected interface.

Configuring the Router MAC Address Assignment

When the VSS is started for the first time, the initial active supervisor engine assigns a router MAC address for the VSS. By default, the supervisor engine assigns a MAC address from its own chassis. After a switchover to the second chassis, the VSS continues to use the MAC address from the previously active chassis as the router MAC address.

In the rare case where both chassis later become inactive and then start up with the second supervisor engine becoming the initial active supervisor engine, the VSS will start up with a router MAC address from the second chassis. Other Layer 2 hosts that do not respond to GARP and are not directly connected to the VSS will retain the earlier router MAC address of the VSS, and will not be able to communicate

with the VSS. To avoid this possibility, you can configure the VSS to assign a router MAC address from a reserved pool of addresses with the domain ID encoded in the last octet of the MAC address, or you can specify a MAC address.

**Note**

If you change the router MAC address, you must reload the virtual switch for the new router MAC address to take effect.

To specify that the router MAC address is assigned from a reserved pool of domain-based addresses, perform this task:

	Command	Purpose
Step 1	<code>Tqwgvt*eqphki+%"uykvej"xktvwn"fqockp"domain_id</code>	Enters VSS configuration mode.
Step 2	<code>Tqwgvt*eqphki/xu/fqockp+%"oce"cfftguu"wug/xktvwn"</code>	The router MAC address is assigned from a reserved pool of domain-based addresses. Note The no form of this command reverts to the default setting, using a MAC address from the backplane of the initial active chassis.

To specify a router MAC address, perform this task:

	Command	Purpose
Step 1	<code>Tqwgvt*eqphki+%"uykvej"xktvwn"fqockp"domain_id</code>	Enters VSS configuration mode.
Step 2	<code>Tqwgvt*eqphki/xu/fqockp+%"oce"cfftguu"mac_address</code>	The router MAC address is specified in three 2-byte hexadecimal numbers.

This example shows how to configure router MAC address assignment from a reserved pool of domain-based addresses:

```
Tqwgvt*eqphki+%"uykvej"xktvwn"fqockp"477"
Tqwgvt*eqphki/xu/fqockp+%"oce"cfftguu"wug/xktvwn"
```

The following example shows how to specify the router MAC address in hexadecimal format:

```
Tqwgvt*eqphki+%"uykvej"xktvwn"fqockp"477"
Tqwgvt*eqphki/xu/fqockp+%"oce"cfftguu"2345067890:;cd"
```

Configuring Deferred Port Activation During Standby Recovery

Instead of allowing all ports to be activated simultaneously when a failed chassis is restarted as the standby chassis, you can configure the system to defer activation of non-VSL ports and then activate the ports in groups over a period of time.

To specify deferred port activation, perform this task:

Command	Purpose
<code>Tqwwgt *eqphki+% "uykvej "xktvwn"fqockp"3</code>	Enters VSS configuration mode.
<code>Tqwwgt *eqphki/xu/fqockp+% "uvcpdf{ "rqtv"fgnc{ "delay-time</code>	Specifies that the port activation will be initially deferred and then performed in cycles. For <i>delay-time</i> , specify the period in seconds before port activation will begin. The range is 30 to 3600.
<code>Tqwwgt *eqphki/xu/fqockp+% "uvcpdf{ "rqtv"dtkpiwr"number cycle-time</code>	Specifies the number of ports to be activated per cycle and the waiting time between cycles. For <i>number</i> , specify the number of ports to be activated per cycle. The range is 1 to 100. The default value is 1 port. For <i>cycle-time</i> , specify the period in seconds between cycles. The range is 1 to 10. The default value is 1 second.

This example shows how to configure port activation to be deferred by 120 seconds, then activated in groups of 20 ports every 5 seconds:

```
Tqwwgt *eqphki+% "uykvej "xktvwn"fqockp"3 "
Tqwwgt *eqphki/xu/fqockp+% "uvcpdf{ "rqtv"fgnc{ "342
Tqwwgt *eqphki/xu/fqockp+% "uvcpdf{ "rqtv"dtkpiwr"42"7
```

Configuring Multichassis EtherChannels

Configure multichassis EtherChannels (MECs) as you would for a regular EtherChannel. The VSS will recognize that the EtherChannel is an MEC when ports from both chassis are added to the EtherChannel. You can verify the MEC configuration by entering the **show etherchannel** command.

One VSS supports a maximum of 512 port channels.



Note

Releases earlier than Cisco IOS Release 12.2(50)SY support a maximum of 128 port channels.

Configuring Port Load Share Deferral on the Peer Switch

To configure the load share deferral feature for a port channel, perform this task on the switch that is an MEC peer to the VSS:

	Command	Purpose
Step 1	<code>Tqwgvt*eqphki+%"rqtv/ejcppgn"nqcf/fghgt"time</code>	(Optional) Configures the port load share deferral interval for all port channels. <i>time</i>—The time interval during which load sharing is initially 0 for deferred port channels. The range is 1 to 1800 seconds; the default is 120 seconds.
Step 2	<code>Tqwgvt*eqphki+%"kpvgtthceg"rqtv/ejcppgn"channel-num</code>	Enters interface configuration mode for the port channel.
Step 3	<code>Tqwgvt*eqphki/kh+%"rqtv/ejcppgn"rqtv"nqcf/fghgt</code>	Enables port load share deferral on the port channel.

This example shows how to configure the load share deferral feature on port channel 10 of the switch that is an MEC peer to the VSS:

```
Tqwgvt*eqphki+%"rqtv/ejcppgn"nqcf/fghgt"82"
Tqwgvt*eqphki+%"kpvgtthceg"rqtv/ejcppgn"32"
Tqwgvt*eqphki/kh+%"rqtv/ejcppgn"rqtv"nqcf/fghgt"
Vjku"yknn"gpdcng"vjg"nqcf"ujctg"fghgttcn"hgcvtg"qp"vjku"rqtv/ejcppgn0
```



Note

To provide the best support for multicast traffic, configure the load share deferral feature on all EtherChannels that have member ports on more than one module.

Configuring Dual-Active Detection

- [Configuring Enhanced PAgP Dual-Active Detection, page 4-50](#)
- [Configuring Fast Hello Dual-Active Detection, page 4-52](#)
- [Configuring the Exclusion List, page 4-53](#)
- [Displaying Dual-Active Detection, page 4-53](#)

Configuring Enhanced PAgP Dual-Active Detection

If enhanced PAgP is running on the MECs between the VSS and its access switches, the VSS can use enhanced PAgP messaging to detect a dual-active scenario.

By default, PAgP dual-active detection is enabled. However, the enhanced messages are only sent on port channels with trust mode enabled (see the trust mode description below).



Note

Before changing PAgP dual-active detection configuration, ensure that all port channels with trust mode enabled are in administrative down state. Use the **shutdown** command in interface configuration mode for the port channel. Remember to use the **no shutdown** command to reactivate the port channel when you are finished configuring dual-active detection.

To enable or disable PAGP dual-active detection, perform this task:

	Command	Purpose
Step 1	<code>Tqwwgt*eqphki+%uykvej"xktvwn"fqockp"domain_id</code>	Enters virtual switch submode.
Step 2	<code>Tqwwgt*eqphki/xu/fqockp+%fwcn/cevkgx"fgvgevkqp"rcir"</code>	Enables sending of the enhanced PAGP messages.

You must configure trust mode on the port channels that will detect PAGP dual-active detection. By default, trust mode is disabled.



Note

If PAGP dual-active detection is enabled, you must place the port channel in administrative down state before changing the trust mode. Use the **shutdown** command in interface configuration mode for the port channel. Remember to use the **no shutdown** command to reactivate the port channels when you are finished configuring trust mode on the port channel.

To configure trust mode on a port channel, perform this task:

	Command	Purpose
Step 1	<code>Tqwwgt*eqphki+%uykvej"xktvwn"fqockp"domain_id</code>	Enters virtual switch submode.
Step 2	<code>Tqwwgt*eqphki/xu/fqockp+%fwcn/cevkgx"fgvgevkqp"rcir"</code> <code>vtwuv"ejcppgn/itqwr"itqwrapwogdt"</code>	Enables trust mode for the specified port channel.

This example shows how to enable PAGP dual-active detection:

```
Tqwwgt*eqphki+%kpvgtgheg"rqtv/ejcppgn"42
Tqwwgt*eqphki/kh+%ujwvfqyp
Tqwwgt*eqphki/kh+%gzkv
Tqwwgt*eqphki+%uykvej"xktvwn"fqockp"322
Tqwwgt*eqphki/xu/fqockp+%fwcn/cevkgx"fgvgevkqp"rcir"
Tqwwgt*eqphki/xu/fqockp+%fwcn/cevkgx"fgvgevkqp"rcir"vtwuv"ejcppgn/itqwr"42
Tqwwgt*eqphki/xu/fqockp+%gzkv
Tqwwgt*eqphki+%kpvgtgheg"rqtv/ejcppgn"42
Tqwwgt*eqphki/kh+%pq"ujwvfqyp
Tqwwgt*eqphki/kh+%gzkv
```

This example shows the error message if you try to enable PAGP dual-active detection when a trusted port channel is not shut down first:

```
Tqwwgt*eqphki+%uykvej"xktvwn"fqockp"322
Tqwwgt*eqphki/xu/fqockp+%fwcn/cevkgx"fgvgevkqp"rcir"
Vtwuvgf"rqtv/ejcppgn"42"ku"pqv"cfokpkuvtcvkxgn{"fqyp0"
Vq"ejcpig"vjg"rcir"fwcn/cevkgx"eqphkiwtcvkqp"."ujwvfqyp" vjgug"rqtv/ejcppgnu"hktuv0"
Tgogodgt"vq"pq"ujwvfqyp" vjgug"rqtv/ejcppgnu"chvgtyctfu0
```

This example shows the error message if you try to configure trust mode for a port channel that is not shut down first:

```
Tqwwgt*eqphki+%uykvej"xktvwn"fqockp"322
Tqwwgt*eqphki/xu/fqockp+%fwcn/cevkgx"fgvgevkqp"rcir"vtwuv"ejcppgn/itqwr"42
Vtwuvgf"rqtv/ejcppgn"42"ku"pqv"cfokpkuvtcvkxgn{"fqyp0"Vq"ejcpig"vjg"rcir"fwcn/cevkgx"vtwuv"
eqphkiwtcvkqp"."ujwvfqyp" vjg"rqtv/ejcppgn"hktuv0"Tgogodgt"vq"pq"ujwvfqyp" vjg"
rqtv/ejcppgn"chvgtyctfu0
```

Configuring Fast Hello Dual-Active Detection

Fast hello dual-active detection is enabled by default; however, you must configure dual-active interface pairs to act as fast hello dual-active messaging links.

To configure fast hello dual-active detection, perform this task:

	Command	Purpose
Step 1	<code>Tqwgvt*eqphki+%uykvej"xktvwcn"fqockp"domain_id</code>	Enters the virtual switch submode.
Step 2	<code>Tqwgvt*eqphki/xu/fqockp+%fwcn/cevxxg"fgvgevkgp"hcuv/jgnnq</code>	Enables the fast hello dual-active detection method. Fast hello dual-active detection is enabled by default.
Step 3	<code>Tqwgvt*eqphki/xu/fqockp+%gzkv</code>	Exits virtual switch submode.
Step 4	<code>Tqwgvt*eqphki+%kpvgthceg"type switch/slot/port"</code>	Selects the interface to configure. This interface must be directly connected to the other chassis and must not be a VSL link.
Step 5	<code>Tqwgvt*eqphki/kh+%fwcn/cevxxg"hcuv/jgnnq</code>	Enables fast hello dual-active detection on the interface, automatically removes all other configuration from the interface, and restricts the interface to dual-active configuration commands.
Step 6	<code>Tqwgvt*eqphki/kh+%pq"ujwvfqyp</code>	Activates the interface.

When you configure fast hello dual-active interface pairs, note the following information:

- You can configure a maximum of four interfaces on each chassis to connect with the other chassis in dual-active interface pairs.
- Each interface must be directly connected to the other chassis and must not be a VSL link. We recommend using links from a switching module not used by the VSL.
- Each interface must be a physical port. Logical ports such as an SVI are not supported.
- Configuring fast hello dual-active mode will automatically remove all existing configuration from the interface and will restrict the interface to fast hello dual-active configuration commands.
- Unidirectional link detection (UDLD) will be disabled on fast hello dual-active interface pairs.

This example shows how to configure an interface for fast hello dual-active detection:

```
Tqwgvt*eqphki+%uykvej"xktvwcn"fqockp"477
Tqwgvt*eqphki/xu/fqockp+%fwcn/cevxxg"fgvgevkgp"hcuv/jgnnq"
Tqwgvt*eqphki/xu/fqockp+%gzkv
Tqwgvt*eqphki+%kpvgthceg"hcuvgvjgtpgv"314162
Tqwgvt*eqphki/kh+%fwcn/cevxxg"hcuv/jgnnq"
YCTPKPI<"Kpvgthceg"HcuvGvjgtpgv314162"rncegf"kp"tguvtkevgf"eqphki"oqfg0"Cnn"gzvtcpgqwu"
eqphkiu"tgoqxgf#

Tqwgvt*eqphki/kh+%pq"ujwvfqyp
Tqwgvt*eqphki/kh+%gzkv
Tqwgvt*eqphki+%gzkv
Tqwgvt%"ujqy"twp"kpvgthceg"hcuvgvjgtpgv"314162
kpvgthceg"HcuvGvjgtpgv314162
"pq"uykvejrqtv
"pq"kr"cfftguu
"fwcn/cevxxg"hcuv/jgnnq
gpf
```

Configuring the Exclusion List

When a dual-active scenario is detected, part of the recovery action is for the chassis to shut down all of its non-VSL interfaces. You can specify one or more interfaces to be excluded from this action (for example, to exclude the interface you use for remote access to the chassis).

To specify interfaces that are not to be shut down by dual-active recovery, perform this task:

	Command	Purpose
Step 1	<code>Tqwwgt*eqphki+%"uykvej"xktvwn"fqockp"fqockpakf"</code>	Enters virtual switch submode.
Step 2	<code>Tqwwgt*eqphki/xu/fqockp+%"fwcn/cevkgxg"gzewwfg"kpvgthceg" type switch/slot/port"</code>	Specifies an interface to exclude from shutting down in dual-active recovery.

When you configure the exclusion list, note the following information:

- The interface must be a physical port configured with an IP address.
- The interface must not be a VSL port.
- The interface must not be in use for fast hello dual-active detection.

This example shows how to configure an interface as an exclusion:

```
Tqwwgt*eqphki+%"uykvej"xktvwn"fqockp"322"
Tqwwgt*eqphki/xu/fqockp+%"fwcn/cevkgxg"gzewwfg"kpvgthceg"ikicdkvgvjgtpgv"31717"
```

Displaying Dual-Active Detection

To display information about dual-active detection, perform this task:

Command	Purpose
<code>Tqwwgt%"ujqy"uykvej"xktvwn"fwcn/cevkgxg"uwooct{]rcir"~"hcuv/jgnnq"~"uwooct{</code>	Displays information about dual-active detection configuration and status.

This example shows how to display the summary status for dual-active detection:

```
Tqwwgt%"ujqy"uykvej"xktvwn"fwcn/cevkgxg"uwooct{ "
Rcir"fwcn/cevkgxg"fgvgevkqp"gpdcngf<"[gu
Hcuv/jgnnq"fwcn/cevkgxg"fgvgevkqp"gpdcngf<"[gu

Pq"kpvgthcegu"gzewwfgf"htqo"ujwvfqyp"kp"tgeqxt{"oqfg

Kp"fwcn/cevkgxg"tgeqxt{"oqfg<"Pq
```

This example shows how to display information for fast-hello dual-active detection:

```
Tqwwgt%"ujqy"uykvej"xktvwn"fwcn/cevkgxg"hcuv/jgnnq"
Hcuv/jgnnq"fwcn/cevkgxg"fgvgevkqp"gpdcngf<"[gu
"
Hcuv/jgnnq"fwcn/cevkgxg"kpvgthcegu<
Rgtv" " " " "Uvcvg"*ngecn"qpn{+
////////////////////////////////////
Ik316169" " " "Nkpm"fp" "
Ik416169" " " /
```

```

Tqwgvt%"ujqy"rcir"fwcn/cevkgx"fwcn/cevkgx"
RCiR"fwcn/cevkgx"fgvgevkgp"gpdcngf<"[gu
RCiR"fwcn/cevkgx"xgtukqp<"303

Ejcppgn"itqwr"5"fwcn/cevkgx"fgvgev"ecrcdknkv{"y1pdtu"fwcn/cevkgx"vtwuvgf"itqwr<"Pq
"*****fwcn/cevkgx"*****Rctvpgt*****Rctvpgt""Rctvpgt
Rgtv*****Fgvgev"Ecrcdng""Pcog"*****Rgtv*****Xgtukqp
Hc314155""Pq*****Ppg"*****Ppg""P1C

Ejcppgn"itqwr"6
fwcn/cevkgx"vtwuvgf"itqwr<"[gu
Pq"kpvgthcegu"eqphkiwtgf"kp"vjg"ejcppgn"itqwr

Ejcppgn"itqwr"7
fwcn/cevkgx"vtwuvgf"itqwr<"[gu
Ejcppgn"itqwr"7"ku"pqv"rctvkekrvcvki"kp"RCiR

Ejcppgn"itqwr"32"fwcn/cevkgx"fgvgev"ecrcdknkv{"y1pdtu"fwcn/cevkgx"vtwuvgf"itqwr<"[gu
"*****fwcn/cevkgx"*****Rctvpgt*****Rctvpgt""Rctvpgt
Rgtv*****Fgvgev"Ecrcdng""Pcog"*****Rgtv*****Xgtukqp
Ik31813""[gu*****rctvpgt/3*****Ik31713""303
Ik41713""[gu*****rctvpgt/3*****Ik31714""303
*****

Ejcppgn"itqwr"33"fwcn/cevkgx"fgvgev"ecrcdknkv{"y1pdtu"fwcn/cevkgx"vtwuvgf"itqwr<"Pq
"*****fwcn/cevkgx"*****Rctvpgt*****Rctvpgt""Rctvpgt
Rgtv*****Fgvgev"Ecrcdng""Pcog"*****Rgtv*****Xgtukqp
Ik31814""[gu*****rctvpgt/3*****Ik31513""303
Ik41714""[gu*****rctvpgt/3*****Ik31514""303

Ejcppgn"itqwr"34"fwcn/cevkgx"fgvgev"ecrcdknkv{"y1pdtu"fwcn/cevkgx"vtwuvgf"itqwr<"[gu
"*****fwcn/cevkgx"*****Rctvpgt*****Rctvpgt""Rctvpgt
Rgtv*****Fgvgev"Ecrcdng""Pcog"*****Rgtv*****Xgtukqp
Hc314135""[gu*****rctvpgt/3*****Hc314135""303
Hc314136""[gu*****rctvpgt/3*****Hc314136""303
Ik413137""[gu*****rctvpgt/3*****Hc314137""303
Ik413138""[gu*****rctvpgt/3*****Hc314138""303

```



Note

The **show switch virtual dual-active pagp** command displays the same output as the **show pagp dual-active** command.

How to Upgrade a VSS

- Performing a Fast Software Upgrade of a VSS, page 4-54
- Performing an Enhanced Fast Software Upgrade of a VSS, page 4-56

Performing a Fast Software Upgrade of a VSS

The FSU of a VSS is similar to the RPR-based standalone chassis FSU described in [Chapter 6, “Fast Software Upgrade.”](#) While the standalone chassis upgrade is initiated by reloading the standby supervisor engine, the VSS upgrade is initiated by reloading the standby chassis. During the FSU procedure, a software version mismatch between the active and the standby chassis causes the system to boot in RPR redundancy mode, which is stateless and causes a hard reset of the all modules. As a result, the FSU procedure requires system downtime corresponding to the RPR switchover time.



Note VSS mode supports only one supervisor engine in each chassis.

To perform an FSU of a VSS, perform this task:

	Command	Purpose
Step 1	<code>Tqwwgt% "eqr { "vhvr" fkumapcog"</code>	Uses TFTP to copy the new software image to flash memory on the active and standby chassis (disk0: and slavedisk0:). Answer the prompts to identify the name and location of the new software image.
Step 2	<code>Tqwwgt% "eqphki "vgtokpcn"</code>	Enters global configuration mode.
Step 3	<code>Tqwwgt *eqphki+% "pq" dqqv"u { uvgo</code>	Removes any previously assigned boot variables.
Step 4	<code>Tqwwgt *eqphki+% "eqphki/tgikuvgt "2z4324"</code>	Sets the configuration register.
Step 5	<code>Tqwwgt *eqphki+% "dqqv"u { uvgo "hncuj " fgxkeg<hkngapcog"</code>	Configures the chassis to boot the new image.
Step 6	<code>Tqwwgt *eqphki+% "gpf"</code>	Returns to privileged EXEC mode.
Step 7	<code>Tqwwgt% "eqr { "twppkpi/eqphki "uvctvwr/eqphki "</code>	Saves the configuration.
Step 8	<code>Tqwwgt% "tgfwpcfpe { "tgnqcf" rggt</code>	Reloads the standby chassis and brings it back online running the new version of the Cisco IOS software. Due to the software version mismatch between the two chassis, the standby chassis will be in RPR redundancy mode. Note Before reloading the standby chassis, make sure you wait long enough to ensure that all configuration synchronization changes have completed. Note When you perform FSU on a quad-supervisor VSS, you must run the redundancy reload peer command twice. In case of FSU on a dual-supervisor VSS, run the redundancy reload peer command only once.
Step 9	<code>Tqwwgt% "tgfwpcfpe { "hqteg/uykvej qxgt "</code>	Forces the standby chassis to assume the role of the active chassis running the new Cisco IOS image. The modules are reloaded and the module software is downloaded from the new active chassis. The old active chassis reboots with the new image and becomes the standby chassis.

This example shows how to perform an FSU:

```
Tqwwgt% eqphki "vgtokpcn"
Tqwwgt *eqphki+% "pq" dqqv"u { uvgo
Tqwwgt *eqphki+% "eqphki/tgikuvgt "2z4324"
Tqwwgt *eqphki+% "dqqv"u { uvgo "hncuj " fkum2<kocigapcog"
Tqwwgt *eqphki+% "gpf"
Tqwwgt% eqr { "twppkpi/eqphki "uvctvwr/eqphki "
Tqwwgt% "tgfwpcfpe { "tgnqcf" rggt
Tqwwgt% "tgfwpcfpe { "hqteg/uykvej qxgt "
```

Performing an Enhanced Fast Software Upgrade of a VSS

An eFSU uses the same commands and software infrastructure as an in-service software upgrade (ISSU). The eFSU differs from an ISSU in that it resets the modules, which results in a brief traffic interruption. The eFSU sequence for a VSS follows the same logical steps as the single-chassis eFSU described in the [Chapter 5, “Enhanced Fast Software Upgrade,”](#) but the procedure applies to the VSS active and VSS standby supervisor engine in each chassis, instead of two supervisor engines in one chassis. During an eFSU, the VSS standby chassis, including the supervisor engine and modules, is upgraded and brought up in a stateful switchover (SSO) mode. The eFSU process then forces a switchover and performs the same upgrade on the other chassis, which becomes the new VSS standby.



Note

VSS mode supports only one supervisor engine in each chassis. If another supervisor resides in the chassis it will act as the DFC.

This section contains the following topics:

- [eFSU Restrictions and Guidelines, page 4-56](#)
- [eFSU Stages for a VSS Upgrade, page 4-57](#)
- [Configuring and Performing an eFSU Upgrade, page 4-58](#)
- [eFSU Upgrade Example, page 4-60](#)

eFSU Restrictions and Guidelines

When performing an eFSU, note the following guidelines and restrictions:

- There must be at least one VSL link between supervisor engine in each chassis.
- Images from different feature sets, regardless of release, fail the eFSU compatibility check.
- The new image file must reside in the file system of the supervisor engine in each chassis before the eFSU can be initiated. The **issu** commands will accept only global file system names (for example, disk0: or bootdisk:). The **issu** commands will not accept switch number-specific file system names (for example, sw1-slot5-disk0:).
- When preparing for the eFSU, do not change the boot variable. Although a boot variable change is required in the FSU (RPR) procedure, changing the boot variable in the eFSU procedure will cause the CurrentVersion variable to be inconsistent, preventing execution of the eFSU.
- The **issu** commands for a VSS eFSU upgrade are similar to those for a single-chassis (standalone) eFSU, as described in the [Chapter 5, “Enhanced Fast Software Upgrade,”](#) with the following differences:
 - Where the standalone **issu** commands accept an argument of slot number, the VSS **issu** commands accept a switch and slot number, in the format of *switch/slot* (for example, 1/5 refers to switch 1, slot 5).
 - For a normal VSS eFSU, it is not necessary to specify a switch or slot number when entering the VSS **issu** commands.
- You cannot change the rollback timer period during the eFSU process.
- During the eFSU process, do not perform any manual switchover other than those caused by the **issu** commands.
- During the eFSU process, do not perform an online insertion or removal (OIR) of any module.

- During an eFSU downgrade, if the process is aborted (either due to an MCL error or by entering the **abortversion** command) just after executing the **loadversion** command, the SSO VSS standby is reloaded with the original image but the SSO VSS standby's ICS is not because the bootvar of the SSO VSS standby's ICS is not modified during an abort executed after the **loadversion** command.

eFSU Stages for a VSS Upgrade

The eFSU sequence consists of several stages, each explicitly initiated by entering a specific **issu** command in the CLI. At each stage, you can verify the system status or roll back the upgrade before moving to the next stage.

The following sections describe the eFSU stages for a VSS upgrade:

- [Preparation, page 4-57](#)
- [Loadversion Stage, page 4-57](#)
- [Runversion Stage, page 4-57](#)
- [Acceptversion Stage \(Optional\), page 4-58](#)
- [Commitversion Stage, page 4-58](#)
- [Abortversion \(Optional\), page 4-58](#)

Preparation

Before you can initiate the eFSU process, the upgrade image must reside in the file system of the supervisor engine in each chassis; otherwise, the initial command will be rejected. The VSS must be in a stable operating state with one chassis in the VSS active state and the other chassis in the hot VSS standby state.

Loadversion Stage

The eFSU process begins when you enter the **issu loadversion** command specifying the location in memory of the new upgrade images on the VSS active and VSS standby chassis. Although the **issu loadversion** command allows you to specify the switch and slot number of the VSS active and VSS standby chassis, it is not necessary to do so. When you enter the **issu loadversion** command, the entire VSS standby chassis, including the supervisor engine and modules, is reloaded with the new upgrade image. Because the VSS standby chassis modules are unavailable while reloading, the throughput of the VSS is temporarily reduced by 50 percent during this stage. After reloading, the VSS standby chassis boots with the new image and initializes in SSO mode, restoring traffic throughput. In this state, the VSS standby chassis runs a different software version than the VSS active chassis, which requires the VSS active chassis to communicate with modules running different image versions between the two chassis.

Runversion Stage

When the VSS standby chassis is successfully running the new image in SSO mode, you can enter the **issu runversion** command. This command forces a switchover in which the upgraded VSS standby chassis takes over as the new VSS active chassis. The formerly VSS active chassis reloads and initializes as the new VSS standby chassis in SSO mode, running the old image. As in the loadversion stage, the throughput of the VSS is temporarily reduced during the VSS standby chassis reload, and the VSS standby chassis runs a different software version than the VSS active chassis.

Acceptversion Stage (Optional)

When you enter the **issu runversion** command, a switchover to the chassis running the new image occurs, which starts an automatic rollback timer as a safeguard to ensure that the upgrade process does not cause the VSS to be nonoperational. Before the rollback timer expires, you must either accept or commit the new software image. If the timer expires, the upgraded chassis reloads and reverts to the previous software version. To stop the rollback timer, enter the **issu acceptversion** command. Prior to starting the eFSU process, you can disable the rollback timer or configure it to a value up to two hours (the default is 45 minutes).

Operating with an upgraded VSS active chassis, this stage allows you to examine the functionality of the new software image. When you are satisfied that the new image is acceptable, enter the **issu commitversion** command to complete the upgrade process.

Commitversion Stage

To apply the upgrade image to the second chassis, completing the eFSU, enter the **issu commitversion** command. The VSS standby chassis is reloaded and booted with the new upgrade image, initializing again as the VSS standby chassis. As in the loadversion stage, the throughput of the VSS is temporarily reduced while the modules are reloaded and initialized. After the successful reload and reboot of the VSS standby chassis, the VSS upgrade process is complete.

Abortversion (Optional)

At any time before you enter the **issu commitversion** command, you can roll back the upgrade by entering the **issu abortversion** command. The upgrade process also aborts automatically if the software detects a failure. The rollback process depends on the current state. If the eFSU is aborted before you enter the **issu runversion** command, the VSS standby chassis is reloaded with the old image. If the eFSU is aborted after the **issu runversion** command, a switchover is executed. The VSS standby chassis, running the old image, becomes the VSS active chassis. The formerly VSS active chassis is then reloaded with the old image, completing the rollback.

Configuring and Performing an eFSU Upgrade

The following sections describe how to configure and perform an eFSU upgrade:

- [Changing the eFSU Rollback Timer, page 4-59](#)
- [Performing an eFSU Upgrade, page 4-59](#)
- [Aborting an eFSU Upgrade, page 4-60](#)

Changing the eFSU Rollback Timer

To view or change the eFSU rollback timer, perform the following task before beginning an upgrade:

	Command	Purpose
Step 1	<code>Tqwvgt% "eqphki" vgtokpcn</code>	Enters configuration mode.
Step 2	<code>Tqwvgt*eqphki+% "kuuw"ugv"tqnndcem/vkogt }ugeqpfu"~"hh:mm:ss;</code>	(Optional) Sets the rollback timer to ensure that the upgrade process does not leave the VSS nonoperational. If the timer expires, the software image reverts to the previous software image. To stop the timer, you must either accept or commit the new software image. The timer duration can be set with one number (<i>seconds</i>), indicating the number of seconds, or as hours, minutes, and seconds with a colon as the delimiter (<i>hh:mm:ss</i>). The range is 0 to 7200 seconds (2 hours); the default is 2700 seconds (45 minutes). A setting of 0 disables the rollback timer.
Step 3	<code>Tqwvgt*eqphki+% "gzkv"</code>	Returns to privileged EXEC mode.
Step 4	<code>Tqwvgt% "ujqy"kuuw"tqnndcem"vkogt "</code>	Displays the current rollback timer value.

This example shows how to set the eFSU rollback timer to one hour using both command formats:

```
Tqwvgt% "eqphki" vgtokpcn
Tqwvgt*eqphki+% "kuuw"ugv"tqnndcem/vkogt "5822
' "Tqnndcem"vkogt "xcnwg"ugv"vq" ] "5822" _ "ugeqpfu
Tqwvgt*eqphki+% "kuuw"ugv"tqnndcem/vkogt "23<22<22
' "Tqnndcem"vkogt "xcnwg"ugv"vq" ] "5822" _ "ugeqpfu
Tqwvgt*eqphki+% "
```

Performing an eFSU Upgrade

To perform an eFSU upgrade (or downgrade) of a VSS, perform this task:

	Command	Purpose
Step 1	<code>Tqwvgt% "eqr{ "vhvr"fkumapcog"</code>	Uses TFTP to copy the new software image to flash memory on the VSS active and VSS standby chassis (disk0: and slavedisk0:) and to the ICS's, if they exist. Answer the prompts to identify the name and location of the new software image.
Step 2	<code>Tqwvgt% "ujqy"kuuw"uvcvg"] switch/slot_ "] fgvckn_ "</code>	(Optional) Verifies that the VSS is ready to run the eFSU. Note You can use the show issu state command at any stage of the upgrade to verify the progress and status of the upgrade.
Step 3	<code>Tqwvgt% "kuuw"ngcfxgtukqp"] active_switch/slot_ "active-image"] standby_switch/slot_ "standby-image"</code>	Starts the upgrade process by loading the new software image onto the VSS standby chassis. The image name includes the path of the target image to be loaded, in the format <i>devicename:filename</i> . It may take several seconds for the new image to load and for the VSS standby chassis to transition to SSO mode.

	Command	Purpose
Step 4	<code>Tqwgvt% "kuuw" twpvxtukqp "</code>	Forces a switchover, causing the VSS standby chassis to become VSS active and begin running the new software. The previously VSS active chassis becomes VSS standby and boots with the old image.
Step 5	<code>Tqwgvt% "kuuw" ceegrvxtukqp "</code>	(Optional) Halts the rollback timer to ensure that the new software image is not automatically aborted during the upgrade process.
Step 6	<code>Tqwgvt% "kuuw" eqookvxtukqp "</code>	Loads the new software image onto the VSS standby chassis.
Step 7	<code>Tqwgvt% "ujgy" kuuw" uvcvg"] switch/slot_] fgvckn_ "</code>	Verifies the status of the upgrade process. If the upgrade was successful, both the VSS active and VSS standby chassis are running the new software version.

For an example of the eFSU upgrade sequence, see the “[eFSU Upgrade Example](#)” section on page 4-60.

Aborting an eFSU Upgrade

To manually abort the eFSU and roll back the upgrade, perform this task:

Command	Purpose
<code>Tqwgvt% "kuuw" cdqtvxtukqp "</code>	Stops the upgrade process and forces a rollback to the previous software image.

This example shows how to abort an eFSU upgrade for a VSS:

```
Tqwgvt% "kuuw" cdqtvxtukqp "
```

eFSU Upgrade Example

This example shows how to perform and verify an eFSU upgrade for a VSS.

Verify the System Readiness

After copying the new image files into the file systems of the active and VSS standby chassis, enter the **show issu state detail** command and the **show redundancy status** command to check that the VSS is ready to perform the eFSU. One chassis must be in the active state and the other chassis in the hot VSS standby state. Both chassis should be in the ISSU Init state and in SSO redundancy state. In the example, both chassis are running an “oldversion” image.

```
Tqwgvt% "ujgy" kuuw" uvcvg" fgvckn
***** "Unqv" ? "314
***** "TR" Uvcvg" ? "Cevkxg
***** "KUW" Uvcvg" ? "Kpkv
***** "Dqgy" Xctkcdng" ? "fkum2<u94255/qnfxgtukqp0x3.34=
***** "Qrgtcvkpi" Oqfg" ? "uuq
***** "Rtkoct { "Xgtukqp" ? "P1C
***** "Ugeqpft { "Xgtukqp" ? "P1C
***** "Ewttgppv" Xgtukqp" ? "fkum2<u94255/qnfxgtukqp0x3
***** "Xctkcdng" Uvqtg" ? "RtuvXdn

***** "Unqv" ? "419
```

[illegible]

Load the New Image to the VSS Standby Chassis

Enter the **issu loadversion** command to start the upgrade process. In this step, the VSS standby chassis reboots, reloads with the new image, and initializes as the VSS standby chassis in SSO redundancy mode, running the new image. This step is complete when the chassis configuration is synchronized, as indicated by the “Bulk sync succeeded” message.

Tqvwgt% "kuuw"nqcfxgtukqp"fkum2<u94255/pgyxtukqp0x4

222355<"Cwi" "8"38<39<6606:8"RUV<" 'NKPGRTQVQ/7/WRFAQYP<"Nkpg"rtqvqeqn"qp"Kpvgthceg"
VgpIkiCDkvGvjgtpgv31416: "ejcpigf"uvcvg"vq"fqyp

222356<"Cwi" "8"38<39<650729"RUV<" 'NKPGRTQVQ/7/WRFAQYP<"Nkpg"rtqvqeqn"qp"Kpvgthceg"
VgpIkiCDkvGvjgtpgv41916: "ejcpigf"uvcvg"vq"fqyp

222357<"Cwi" "8"38<39<650785"RUV<" 'NKPM/5/WRFAQYP<"Kpvgthceg"VgpIkiCDkvGvjgtpgv41916: "
ejcpigf"uvcvg"vq"fqyp

222358<"Cwi" "8"38<39<660;3;"RUV<" 'NKPM/5/WRFAQYP<"Kpvgthceg"VgpIkiCDkvGvjgtpgv31416: "
ejcpigf"uvcvg"vq"fqyp

(Deleted many interface and protocol down messages)

```
'kuuw"ngcfxgtukqp"gzgewvgf"uweeguuhwnn{."Uvcdfd{"ku"dgkpi"tgngcfgf
```

(Deleted many interface and protocol down messages, then interface and protocol up messages)

```
222236:<"Cwi" "8"38<49<760376"RUV<" 'NKPGRTQVQ/7/WRFQYP<"Nkpg"rtqvqeqn"qp"Kpvgthceg"
VgpIkiCDkvGvjgtpgv31417. "ejcpigf"uvcvg"vq"wr
22236:<"Cwi" "8"38<49<760396"RUV<" 'NKPM/5/WRFQYP<"Kpvgthceg"VgpIkiCDkvGvjgtpgv41917. "
ejcpigf"uvcvg"vq"wr
222372<"Cwi" "8"38<49<7603:8"RUV<" 'NKPGRTQVQ/7/WRFQYP<"Nkpg"rtqvqeqn"qp"Kpvgthceg"
VgpIkiCDkvGvjgtpgv41917. "ejcpigf"uvcvg"vq"wr
222373<"Cwi" "8"38<54<7:0252"RUV<" 'JCaEQPHKiaU[PE/8/DWNMaBHIU[PEaUWEEGGF<"Dwnm"U{pe"
uweeggqgf
```


4-63

Commit the New Image to the VSS Standby Chassis

When the active chassis is successfully running the new image in the SSO redundancy state, you can enter either the **issu acceptversion** command to stop the rollback timer and hold this state indefinitely, or the **issu commitversion** command to continue with the eFSU. To continue, enter the **issu commitversion** command to upgrade the VSS standby chassis and complete the eFSU sequence. The VSS standby chassis reboots, reloads with the new image, and initializes as the VSS standby chassis in the SSO redundancy state, running the new image. This step is complete when the chassis configuration is synchronized, as indicated by the “Bulk sync succeeded” message.

```
Tqwgvt%"kuuw"eqookvxgtukqp
Dwknfkpi"eqphkiwtcvkqp000
]QM_
22236:<"Cwi""8"39<39<4:0489"RUV<"'NKPGRtQVQ/7/WRfQYP<"Nkpg"rtqvqeqn"qp"Kpvgthceg"
VgpIkiCDkvGvjgtpgv41916."ejcpigf"uvcvg"vq"fqyp
22236:<"Cwi""8"39<39<4:04:9"RUV<"'NKPGRtQVQ/7/WRfQYP<"Nkpg"rtqvqeqn"qp"Kpvgthceg"
VgpIkiCDkvGvjgtpgv31416."ejcpigf"uvcvg"vq"fqyp
```

(Deleted many interface and protocol down messages)

```
'kuuw"eqookvxgtukqp"gzgewvgf"uweeguuhwnn{
```

(Deleted many interface and protocol down messages, then interface and protocol up messages)

```
2223:3<"Cwi""8"39<63<7302:8"RUV<"'NKPGRtQVQ/7/WRfQYP<"Nkpg"rtqvqeqn"qp"Kpvgthceg"
VgpIkiCDkvGvjgtpgv31417."ejcpigf"uvcvg"vq"wr
2223:4<"Cwi""8"39<64<7404:2"RUV<"'JCaEQPHKiaU[PE/8/DWNMaEHIU[PEaUWEEGGF<"Dwnm"U{pe"
uweeggfgf
```

Verify That the Upgrade is Complete

You can now enter the **show issu state detail** command and the **show redundancy** command to check the results of the eFSU. In this example, both chassis are now running the “newversion” image, indicating that the eFSU was successful. Because the eFSU has completed, the two chassis will be once again in the ISSU Init Version state, as they were before the eFSU was initiated.

```
Tqwgvt%"ujqy"kuuw"uvcvg"fgvckn
"Unqv"?419
"TR"Uvcvg"?Cevkxg
"KUWU"Uvcvg"?Kpkv
"Dqvy"Xctkcdng"?
fkum2<u94255/pgyxgtukqp0x4.34=fkum2<u94255/qnfxgtukqp0x3.34
"Qrgtcvkpi"Oqfg"?uuq
"Rtkoct{"Xgtukqp"?P1C
"Ugeqpfc{"Xgtukqp"?P1C
"Ewttgppv"Xgtukqp"?fkum2<u94255/pgyxgtukqp0x4
"Xctkcdng"Uvqtg"?RtuvXdn

"Unqv"?314
"TR"Uvcvg"?Uvcpf{
"KUWU"Uvcvg"?Kpkv
"Dqvy"Xctkcdng"?
fkum2<u94255/pgyxgtukqp0x4.34=fkum2<u94255/qnfxgtukqp0x3.34
"Qrgtcvkpi"Oqfg"?uuq
"Rtkoct{"Xgtukqp"?P1C
"Ugeqpfc{"Xgtukqp"?P1C
"Ewttgppv"Xgtukqp"?fkum2<u94255/pgyxgtukqp0x4

Tqwgvt%"ujqy"tgfwfcpce{"uvcvwu
```


[illegible]

Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

Participate in the Technical Documentation Ideas forum



Enhanced Fast Software Upgrade

- [Prerequisites for eFSU, page 5-2](#)
- [Restrictions for eFSU, page 5-2](#)
- [Information About eFSU, page 5-3](#)
- [Default Settings for eFSU, page 5-5](#)
- [How to Perform an eFSU, page 5-5](#)
- [How to Upgrade a Non-eFSU Image to an eFSU Image, page 5-14](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- The



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

For detailed information on 6800IA ISSU upgrade procedure, see the following documents:

<https://www.cisco.com/c/en/us/support/docs/switches/catalyst-6500-series-switches/117564-technote-issu-00.html>

http://www.cisco.com/c/en/us/products/collateral/switches/catalyst-6800ia-switch/white_paper_c11-728265.html

Prerequisites for eFSU

None.

Restrictions for eFSU

- [SX SY EFSU Compatibility Matrix](#)
- The Release 15.0(1)SY no payload encryption (NPE) images do not support the hitless ACL update feature or the **[no] platform hardware acl update-mode hitless** command.

The Release 15.0(1)SY1 and later no payload encryption (NPE) images support hitless ACL update and the **platform hardware acl update-mode hitless** command is configured by default (because it is the default, the command does not appear in the configuration file).

In other releases and images that support the hitless ACL update feature, the **platform hardware acl update-mode hitless** command is configured by default.

With NPE images, to avoid problems when doing a downgrade from Release 15.0(1)SY1 or later to Release 15.0(1)SY, do not disable the hitless ACL update feature (**no platform hardware acl update-mode hitless**), because the CLI does not exist in the Release 15.0(1)SY NPE images, and configuring the nondefault condition causes the CLI to appear in the Release 15.0(1)SY1 configuration file, which then, as an unsupported command, causes problems with Release 15.0(1)SY.

The hitless ACL update feature consumes TCAM resources. If TCAM utilization is high, enabling the hitless ACL update feature to support a downgrade might cause TCAM conflicts with other configured features.

- eFSU requires two supervisor engines, one active and one standby.
- Both the active and standby supervisor engines must have enough flash memory to store both the old and new software images prior to the upgrade process.
- Images from different features sets, regardless of release, fail the eFSU compatibility check.
- When downgrading with eFSU to an earlier version of Cisco IOS Software, the configuration files fail to synchronize and the standby supervisor engine reloads unless you disable any features or functions that are not supported in the earlier version before you start the process. Remove any configuration commands that are not available in the earlier version.
- During an eFSU upgrade, the modules are restarted.
- The switch examines the old and new software images and automatically performs the appropriate process (eFSU) to upgrade the software image:
 - If the module software in the images is different, the modules are restarted or reset during the upgrade process. System downtime depends on whether the modules support eFSU (see the [“Outage Time and Support Considerations”](#) section on page 5-4 for more information).
- The eFSU upgrade feature works with NSF/SSO. Software features that do not support NSF/SSO stop operating until they come back online after the switchover that occurs during the software upgrade.
- All modules that support eFSU preload must have at least 512 MB of memory, with enough memory free to hold the new software image. If there is insufficient free memory, eFSU does not attempt the preload, but instead resets the modules during the switchover.

- Online insertion and replacement (OIR) is not supported during an eFSU. If you attempt to insert a new module in the switch while the upgrade is active, the switch does not provide power for the module. When the upgrade ends, the switch resets the newly inserted module.
- Do not perform a manual switchover between supervisor engines during the upgrade.
- Make sure that the configuration register is set to allow autoboot (the lowest byte of the register should be set to 2).
- Before you enter the **issu abortversion** command (to abort a software upgrade), make sure that the standby supervisor engine is Up (STANDBY HOT [in SSO] or COLD [in RPR]).
- The Fast Software Upgrade (FSU) process supports upgrade from earlier releases. During this process, the module software image is also upgraded on those modules that support eFSU.



Note

eFSU will not proceed in IA systems if **issu runversion fex** command is not executed.

Information About eFSU

- [eFSU Operation, page 5-3](#)
- [Outage Time and Support Considerations, page 5-4](#)
- [Reserving Module Memory, page 5-4](#)
- [Error Handling for eFSU Preload, page 5-5](#)



Note

The switch supports eFSU in VSS mode. See the “[Restrictions for VSS](#)” section on [page 4-2](#) for more information.

eFSU Operation

eFSU is an enhanced software upgrade procedure. Non-eFSU (FSU) software upgrades require system downtime, because a software version mismatch between the active and the standby supervisor engines forces the system to boot in RPR redundancy mode, which is stateless and causes a hard reset of the all modules.

eFSU enables an increase in network availability by reducing the downtime caused by software upgrades. eFSU does this by:

- Bringing up the standby supervisor engine in SSO mode even when the active and the standby supervisor engines have different software versions, or with VSS configured, when the supervisor engines in the two chassis have different software versions.

During an eFSU, new software is loaded onto the standby supervisor engine while the active supervisor engine continues to operate using the previous software. As part of the upgrade, the standby processor reaches the SSO Standby Hot stage, a switchover occurs, and the standby becomes active, running the new software. In previous releases Supervisor Engines running different software versions ran in the Route Processor Redundancy Mode.

You can continue with the upgrade to load the new software onto the other processor, or you can abort the upgrade and resume operation with the old software.

- Preloading new module software into memory on supported modules to avoid a hard reset.

If the new software release contains new module software, eFSU preloads the new module software onto any modules in the switch that support eFSU preload. When the switchover occurs between the active and standby supervisor engines, the modules are restarted with the new software image.

The WS-X67xx modules support eFSU preload. All other modules undergo a hard reset at switchover, and the software image loads after the module restarts.

During a software upgrade, the switch performs the following steps automatically on modules that support eFSU preload:

- Reserves the necessary memory for the new Cisco IOS software image on each module.
- Preloads a new software image onto the modules as part of the **issu loadversion** command.
- Restarts the modules with the new software image when a switchover occurs (**issu runversion**).
- During the restart, the software features and routing protocols are not available.
- If a rollback or abort occurs, to minimize disruption, the switch preloads the original software version onto the module. Once the rollback or abort is completed, the module is restarted with the original software version.



Note

All modules that support eFSU preload must have at least 512 MB of memory, with enough memory free to hold the new software image. If there is insufficient free memory, eFSU does not attempt the preload, but instead resets the modules during the switchover.

Outage Time and Support Considerations

During an eFSU upgrade, modules are restarted or reset after the switchover that occurs between the supervisor engines. Because the modules are restarted or reset, any links attached to the modules go up and down and traffic processing is disrupted until protocols and software features are brought back online. The length of time that module processing is disrupted (outage time) depends on whether the eFSU process was able to preload a new software image onto the module.

- For modules that support eFSU preload, the outage time for an eFSU module warm reload is faster than an RPR mode module reload.
- For modules that do not support eFSU preload, the outage time for module reload is similar to an RPR mode module reload.

Once the new software is loaded (**issu loadversion**), you can use the **show issu outage slot all** command to display the maximum outage time for installed modules. See the [“Displaying the Maximum Outage Time for Installed Modules \(Optional\)”](#) section on page 5-10 for a command example.

Reserving Module Memory

On modules that support eFSU, the supervisor engine automatically reserves memory on the module to store the new software image (decompressed format). The amount of memory needed varies according to the module type.

Although we do not recommend it, you can enter the following command to keep the switch from reserving memory for the software preload (where *slot-num* specifies which slot the module is installed in):

```
pp"oft"fqypnqcf"tgugtsg"ogoot{"kocig"unqv"slot-num"
```

**Note**

All modules that support eFSU preload must have at least 512 MB of memory, with enough memory free to hold the new software image. If there is insufficient free memory, eFSU does not attempt the preload, but instead resets the modules during the switchover.

To display whether or not the memory reservation was successful on a module, use the **show issu outage slot all** command. See the [“Displaying the Maximum Outage Time for Installed Modules \(Optional\)”](#) section on page 5-10 for a command example.

Error Handling for eFSU Preload

If problems occur during eFSU preload, the switch takes the following actions:

- Module crash during loadversion—The module is reset when a switchover occurs.
- Module not active when eFSU started—No power is provided to the module during the software upgrade, and the module is reset when the process ends. The same action is applied to a module that is inserted into the switch after the software upgrade process has begun.
- Module crash during run version or during rollback—The module boots with the software image version that corresponds to the software image that is present on the active supervisor engine.

Default Settings for eFSU

None.

How to Perform an eFSU

- [eFSU Summarized Procedure, page 5-6](#)
- [Preparing for the Upgrade, page 5-6](#)
- [Copying the New Software Image, page 5-8](#)
- [Loading the New Software onto the Standby Supervisor Engine, page 5-8](#)
- [Displaying the Maximum Outage Time for Installed Modules \(Optional\), page 5-10](#)
- [Forcing a Switchover from Active to Standby, page 5-10](#)
- [Accepting the New Software Version and Stopping the Rollback Process \(Optional\), page 5-12](#)
- [Committing the New Software to the Standby, page 5-12](#)
- [Verifying the Software Installation, page 5-12](#)
- [Aborting the Upgrade Process, page 5-13](#)

eFSU Summarized Procedure

This task is a summarized procedure for an eFSU:

	Command	Purpose
Step 1	Tqwgvt@"gpcdng"	Enables privileged EXEC mode. Enter your password if prompted.
Step 2	Tqwgvt%"eqr{"vhvr"fkumapcog"	Uses TFTP to copy the new software image to flash memory on the active and standby supervisor engines (disk0: and slavedisk0:). Answer the prompts to identify the name and location of the new software image.
Step 3	Tqwgvt%"ujqy"xgtukqp"~"kp"kocig" Tqwgvt%"ujqy"dqgvxct" Tqwgvt%"ujqy"tgfwpfcp{" " Tqwgvt%"ujqy"kuuw"uvcvg"] fgvckn_ "	These show commands verify that the switch is ready to run eFSU. The show version and show bootvar commands verify the boot image settings. The show redundancy and show issu state commands verify that redundancy mode is enabled and that SSO and NSF are configured. Note Use the show redundancy and show issu state commands throughout the upgrade to verify the status of the upgrade.
Step 4	Tqwgvt%"kuuw"nqcfxgtukqp active-slot active-image standby-slot standby-image	Starts the upgrade process and loads the new software image onto the standby supervisor engine. It may take several seconds for the new image to load and for the standby supervisor engine to transition to SSO mode.
Step 5	Tqwgvt%"ujqy"kuuw"qwcig"unqv"cnn"	(Optional) Displays the maximum outage time for installed modules. Enter the command on the switch processor of the supervisor engine.
Step 6	Tqwgvt%"kuuw"twpxgtukqp"	Forces a switchover, which causes the standby supervisor engine to become active and begin running the new software. The previously active processor becomes standby and boots with the old image.
Step 7	Tqwgvt%"kuuw"ceegrvxgtukqp"	(Optional) Halts the rollback timer to ensure that the new software image is not automatically aborted during the upgrade process.
Step 8	Tqwgvt%"kuuw"eqookvxgtukqp"	Loads the new software image onto the standby supervisor engine in the specified slot.
Step 9	Tqwgvt%"ujqy"tgfwpfcp{" " Tqwgvt%"ujqy"kuuw"uvcvg"] fgvckn_ "	Verifies the status of the upgrade process. If the upgrade was successful, both the active and standby supervisor engines are running the new software version.

Preparing for the Upgrade

- [Verifying the Boot Image Version and Boot Variable, page 5-7](#)
- [Verifying Redundancy Mode, page 5-7](#)
- [Verifying eFSU State, page 5-8](#)

**Note**

Before attempting to perform a software upgrade, be sure to review the “[Restrictions for eFSU](#)” section on page 5-2.

Verifying the Boot Image Version and Boot Variable

Before starting, enter the **show version** and **show bootvar** commands to verify the boot image version and BOOT environment variable, as shown in the following examples:

```
Tqwwgt% "ujqy" xgtukqp ~ "kp" kocig"
DQQV"xctkcdng"? "fkum2<kocigapcog=
EQPHKIAHKNG"xctkcdng"?
DQQVNFT"xctkcdng"?
Eqphkiwtcvkqp"tgikuvgt"ku"2z4224

Uvcdfd{"ku"wr
Uvcdfd{"jcu"326:798M187758M"d{vgu"qh"ogoot{0

Uvcdfd{"DQQV"xctkcdng"? "fkum2<kocigapcog=
Uvcdfd{"EQPHKIAHKNG"xctkcdng"?
Uvcdfd{"DQQVNFT"xctkcdng"?"
```

Verifying Redundancy Mode

Verify that redundancy mode is enabled and that NSF and SSO are configured. The following command example shows how to verify redundancy:

```
Tqwwgt% "ujqy" tgfwpfcpe{ "
Tgfwpfcpev"U{uvgo"Kphqtocvkqp"<
////////////////////////////////////
" " " " "Cxcnkcdng"u{uvgo"wrvkog"? "67"okpwwgu
Uykvejxqgtu"u{uvgo"gzrgtkgpegf"? "2
" " " " "Uvcdfd{"hcknwtgu"? "2
" " " " "Ncu"uykvejxqgt"tgcup"? "pqp

" " " " "Jctfyctg"Oqfg"? "Fwrngz
" " " "Eqphkiwtgf"Tgfwpfcpe{"Oqfg"? "uuq
" " " "Qrgtcvkpi"Tgfwpfcpe{"Oqfg"? "uuq
" " " " "Ockpvgpcpeg"Oqfg"? "Fkucdngf
" " " " "Eqoowpkcvkqpu"? "Wr

Ewttgvp"Rtgeguqt"Kphqtocvkqp"<
////////////////////////////////////
" " " " "Cevkxg"Ngecvkqp"? "unqv"8
" " " " "Ewttgvp"Uqhvyctg"uvcvg"? "CEVKXG
" " " " "Wrvkog"kp"ewttgvp"uvcvg"? "66"okpwwgu
" " " " "Kocig"Xgtukqp"? "Ekueq"KQU"Uqhvyctg."kocigafgvcknu"
Vgejpkecn"Uwrrqtv<"jvvr<11yy0ekueq0eqo1vgejuwrrqtv
Eqr{tkijv"*e+"3;:8/422;"d{"Ekueq"U{uvgo."Kpe0
Eqorkngf"Ygf"3:/Hgd/2;"34<6;"d{"mejt kuvk
" " " " "DQQV"? "fkum2<kocigapcog=
" " " " "EQPHKIAHKNG"?
" " " " "DQQVNFT"?
" " " " "Eqphkiwtcvkqp"tgikuvgt"? "2z4224

Rggt"Rtgeguqt"Kphqtocvkqp"<
////////////////////////////////////
" " " " "Uvcdfd{"Ngecvkqp"? "unqv"7
" " " " "Ewttgvp"Uqhvyctg"uvcvg"? "UVCPPD["JQV
" " " " "Wrvkog"kp"ewttgvp"uvcvg"? "4:"okpwwgu
```

```

"Kocig"Xgtukqp"? "Ekueq"KQU"Uqhvyctg."kocigafgvcknu"
Vgejpkecn"Uwrrgtv<"jvvr<1lyyy0ekueq0eqo1vgejuwrrgtv
Eqr{tkijv"*e+"3;:8/422;"d{"Ekueq"U{uvvou."Kpe0
Eqorkngf"kocigafgvcknu"
"DQQV"? "fkum2<kocigapcog"=
"EQPHKIAHKNG"?
"DQQVNFT"?
"Eqphkiwtcvkqp"tgikuvgt"? "2z4224

```

Verifying eFSU State

Verify that the the ISSU state is **Init**, rather than an intermediate eFSU upgrade state. Enter this command:

```

Tqwgvt%"ujqy"kuuw"uvcvg"fgvckn"
"Unqv"? "8
"TR"Uvcvg"? "Cevkxg
"KUUV"Uvcvg"? "Nqcf"Xgtukqp
"Dqqv"Xctkcdng"? "fkum2<image_name
"Qrgtcvkpi"Oqfg"? "uuq
"Rtkoct{"Xgtukqp"? "fkum2<ukgttc02439
"Ugeqpfct{"Xgtukqp"? "fkum2<ukgttc02439
"Ewttgpv"Xgtukqp"? "fkum2<ukgttc02439
"Xctkcdng"Uvqtg"? "RtuvXdn
"TOOQPF"EX"? "]"fkum2<kocigapcog_

"Unqv"? "7
"TR"Uvcvg"? "Uvcpdf{
"KUUV"Uvcvg"? "Nqcf"Xgtukqp
"Dqqv"Xctkcdng"? "fkum2<image_name
"Qrgtcvkpi"Oqfg"? "uuq
"Rtkoct{"Xgtukqp"? "fkum2<image_name
"Ugeqpfct{"Xgtukqp"? "fkum2<image_name
"Ewttgpv"Xgtukqp"? "fkum2<image_name

```

Copying the New Software Image

Before starting the eFSU process, copy the new software image to flash memory (disk0: and slavedisk0:) on the active and standby supervisor engines.

Loading the New Software onto the Standby Supervisor Engine

Enter the **issu loadversion** command to start the upgrade process. This command reboots the standby supervisor engine and loads the new software image onto the standby supervisor engine. When the download is complete, you are prompted to enter the **runversion** command.



Note

Do not automatically disable the features that are not common to both images. During the standby initialization, after you enter the **issu loadversion** command, if there are any enabled features that are not supported on the standby supervisor engine, a message is displayed that states that the standby supervisor engine cannot initialize while this feature is enabled, and the standby supervisor engine is forced to RPR (in the load-version state).

```

Tqwgvt%"kuuw"nqcfxgtukqp"fgxkeg<hkngpcog"
'kuuw"nqcfxgtukqp"gzgewvgf"uweeguuhwnn{"Uvcpdf{"ku"dgkpi"tgnqcfgf

```

These examples show how to check the status of the upgrade using the **show redundancy** and **show issue state detail** commands:

Supervisor Engine 6T Software Configuration Guide, Release 15.4SY

```

"KUUW"Uvcvg"? "Nqcf"Xgtukqp
"Dqgy"Xctkcdng"? "fkum2<kocigapcog"
"Qrgtcvkpi"Oqfg"? "uuq
"Rtkoct{"Xgtukqp"? "fkum2<kocigapcog"
"Ugeqpfct{"Xgtukqp"? "fkum2<kocigapcog"
"Ewttgpv"Xgtukqp"? "fkum2<kocigapcog"

```

Displaying the Maximum Outage Time for Installed Modules (Optional)

Once the new software is downloaded, you can enter the **show issu outage slot all** command on the switch processor to display the maximum outage time for the installed modules:

```

Tqwgvt% "ujqy"kuuw"qvwciq"unqv"cnn"
Unqv"% "Ectf"V{rg" "OFT"Oqfg" "Ocz"Qwvcig"Vkog
/////////"/////////"/////////"/////////"/////////"
"3"EGH942": "rqtv"32IG"ykvj" FHE" "YCTOaTGNQCF" "522"ugeu
"4"; 8/rqtv"321322"Odrü"TL67" "TGNQCF" "582"ugeu
"6"EGH942"6: "rqtv"3222od"UHR" "TGNQCF" "582"ugeu

Unqv"% "Tgcuqp" "Gttqt" Pwodgt
/////////"/////////"/////////"/////////"/////////"
"3"RNCVHQTOaKPKV" "5
"4"RNCVHQTOaKPKV" "5
"6"RTGFQYPNQCFaNEaOKOKOWOaOGOQT[aHCKNWTG" "7
Tqwgvt%

```

Forcing a Switchover from Active to Standby

Enter the **issu runversion** command to force a switchover between the active and standby supervisor engines. The standby supervisor engine, which has the new software image loaded, becomes active. The previously active supervisor engine becomes the standby and boots with the old software image (in case the software upgrade needs to be aborted and the old image restored).

```

Tqwgvt% "kuuw"twpxgtukqp"

Vjku"eqoocpf"yknn"tgnqcf"vjpg"Cevkxg"wpkv0" "Rtqeggf"A"]eqphkto_"{"

```

A switchover between the supervisor engines occurs now. The previous standby supervisor engine becomes active and is running the new software version. The previous active supervisor engine, now the standby supervisor engine, boots with the old software.



Note

At this point, the new active supervisor engine is running the new software image and the standby is running the old software image. You should verify the state of the active and standby supervisor engines as shown in the following examples (**show redundancy** and **show issu state detail**).

```

Tqwgvt% "ujqy"tgfwfpcpe{ "
/////////"
" "Cxcnkcdng"u{uvgo"wrvkog"? "3"jgwt. "; "okpwvgu
Uykvejxggtu"u{uvgo"gzrgtkgpegf"? "3
" "Uvcpdf{ "hcknwtgu"? "2
" "Ncuv"uykvejxgt"tgcupq"? "wugt"hgtegf

" "Jctfyctg"Oqfg"? "Fwringz
" "Eqphkiwtgf"tgfwfpcpe{ "Oqfg"? "uuq
" "Qrgtcvkpi"tgfwfpcpe{ "Oqfg"? "uuq

```

```

"Ockpvgpcpeg"Oqfg"? "Fkucdngf
"Eqoowpkcecvkqpu"? "Wr

Ewttgppv"Rtqeguugt "Kphqtocvkqp"<
////////////////////
"Cevekxg"Nqecvkqp"? "unqv" 7
" " "Ewttgppv"Uqhvycvg"uvvcvg"? "CEVKXG
" " "Wrvkog"kp"ewttgppv"uvvcvg"? "9"okpwvgu
" " "Kocig"Xgtukqp"? "Ekueq"KQU"Uqhvycvg. "kocigafgvcknu"
Vgejpkecn"Uwrrqtv<"jvvr<11yyy0ekueq0eqolvgjuwrrqtv
Eqr{tkijv"*e+"3;:8/422;"d{ "Ekueq"U{uvvou. "Kpe0
Eqorkngf"000"
" " "DQQV"? "fkum2<kocigapcog"
" " "EQPHKIAHKNG"?
" " "DQQVNFT"?
" " "Eqphkiwtcvkqp"tgikuvgt"? "2z4224

RggT "Rtqeguugt "Kphqtocvkqp"<
////////////////////
"Uvcvfd{ "Nqecvkqp"? "unqv" 8
" " "Ewttgppv"Uqhvycvg"uvvcvg"? "UVCVFD [ "JQV
" " "Wrvkog"kp"ewttgppv"uvvcvg"? "2"okpwvgu
" " "Kocig"Xgtukqp"? "Ekueq"KQU"Uqhvycvg. "kocigafgvcknu"
Vgejpkecn"Uwrrqtv<"jvvr<11yyy0ekueq0eqolvgjuwrrqtv
Eqr{tkijv"*e+"3;:8/422;"d{ "Ekueq"U{uvvou. "Kpe0
Eqorkngf"Ygf"3:/Hgd/2;"34<6;"d{ "mejt kuvk
" " "DQQV"? "fkum2<kocigapcog"
" " "EQPHKIAHKNG"?
" " "DQQVNFT"?
" " "Eqphkiwtcvkqp"tgikuvgt"? "2z4224

Tqvwgt% "ujqy"kuuw"uvvcvg"fgvckn"
" " "Unqv"? "7
" " "TR"Uvcvg"? "Cevekxg
" " "KUUV"Uvcvg"? "Twp"Xgtukqp
" " "Dqqv"Xctkcdng"? "fkum2<kocigapcog"
" " "Qrgtcvkpi "Oqfg"? "uuq
" " "Rtkoct { "Xgtukqp"? "fkum2<kocigapcog"
" " "Ugeqpfct { "Xgtukqp"? "fkum2<kocigapcog"
" " "Ewttgppv"Xgtukqp"? "fkum2<kocigapcog"
" " "Xctkcdng"Uvqtg"? "RtuvXdn
" " "TQOQP"EX"? " ] fkum2<kocigapcog_

" " "Unqv"? "8
" " "TR"Uvcvg"? "Uvcvfd{
" " "KUUV"Uvcvg"? "Twp"Xgtukqp
" " "Dqqv"Xctkcdng"? "fkum2<kocigapcog"
" " "Qrgtcvkpi "Oqfg"? "uuq
" " "Rtkoct { "Xgtukqp"? "fkum2<kocigapcog"
" " "Ugeqpfct { "Xgtukqp"? "fkum2<kocigapcog"
" " "Ewttgppv"Xgtukqp"? "fkum2<kocigapcog"
"

```

**Note**

To complete the upgrade process, enter the **issu acceptversion** (optional) and **issu commitversion** commands (as described in the following sections).

Accepting the New Software Version and Stopping the Rollback Process (Optional)

You must either accept or commit the new software image, or the rollback timer will expire and stop the upgrade process. If that occurs, the software image reverts to the previous software version. The rollback timer is a safeguard to ensure that the upgrade process does not leave the switch nonoperational.



Note

New features that are not supported by the previous image are allowed to be enabled only after you enter the **issu commitversion** command.

The following command sequence shows how the **issu acceptversion** command stops the rollback timer to enable you to examine the functionality of the new software image. When you are satisfied that the new image is acceptable, enter the **issu commitversion** command to end the upgrade process.

```
Tqwgvt%"ujqy"kuuw"tqnndcem/vkogt "
" " " " " " " " " " "Tqnndcem"Rtqeguu"Uvcvg"? "Kp"rtqitguu
" " " " " " " " " " "Egphkiwtgf" "Tqnndcem"Vkog"? "22<67<22
" " " " " " " " " " "Cwvgocvke" "Tqnndcem"Vkog"? "22<59<4:

Tqwgvt%"kuuw"ceegrvgxtukqp"
/" "Tqnndcem"vkogt"uvgrrgf0"Rngcug"kuuwg"vjg"egookvxgtukqp"egooocpf0
```

View the rollback timer to see that the rollback process has been stopped:

```
Tqwgvt%"ujqy"kuuw"tqnnndcem/vkogt"
" " " " "Tqnnndcem"Rtqeguu"Uvcvg"? "Pqv"kp"rtqitguu
" " " " "Eqphkiwtgf"Tqnnndcem"Vkog"? "22<67<22
```

Committing the New Software to the Standby

Enter the **issu commitversion** command to load the new software image onto the standby supervisor engine and complete the software upgrade process. In the following example, the new image is loaded onto the standby supervisor engine in slot 5:

```
Tqwgvt%"kuuw"eqookvxgtukqp"  
Dwknfkpi"eqphkiwtcvkqp000  
]QM_  
'kuuw"eqookvxgtukqp"gzgwwqf"uweequuhwnn{
```



Note

The software upgrade process is now complete. Both the active and standby supervisor engines are running the new software version.

Verifying the Software Installation

You should verify the status of the software upgrade. If the upgrade was successful, both the active and standby supervisor engines are running the new software version.

```
Tqwgvt% "ujqy"tgfwpfcpf{ "
Tgfwpfcpv"U{uvgo"Kphqtoevkqp"<
////////////////////////////////////
" " " " " "Cxcncdng"u{uvgo"wrvkog"? "3"j qwt. "39"okpwvgu
Uykvejxgtu"u{uvgo"gzrgtkgpegf"? "3
" " " " " " " " " " " "Uvcpfd{ "hcnkwtqu"? "3
```

```

" " " " "NcuV"uykvejxgt"tgcupq"? "wugt" hqtegf

" " " " "Jctfyctg"Oqfg"? "Fwrngz
" " " "Eqphkiwtgf" Tgfwpfcpe{ "Oqfg"? "uuq
" " " "Qrgtcvkpi" Tgfwpfcpe{ "Oqfg"? "uuq
" " " " "Ockpvpgpcpeg"Oqfg"? "Fkucdngf
" " " " "Eqoowpkcevkqpu"? "Wr

Ewttgvp"Rtqeguugt"Kphqtocvkqp"<
////////////////////////////////
" " " " "Cevkxg"Nqecvkqp"? "unqv" 7
" " " " "Ewttgvp"Uqhvyctg"uvcvg"? "CEVKXG
" " " " "Wrvkog"kp"ewttgvp"uvcvg"? "37"okpwwgu
" " " " "Kocig"Xgtukqp"? "Ekueq"KQU"Uqhvyctg."kocigapcog"
Vgejpkecn"Uwrrqtv<"jvvr<1lyy0ekueq0eqolvgjuwrrqtv
Eqr{tkijv"*e+"3;:8/422;"d{"Ekueq"U{uvvou."Kpe0
Eqorkngf"000"
" " " " "DQQV"? "fkum2<kocigapcog"
" " " " "EQPHKIAHKNG"?
" " " " "DQQVNFT"?
" " " " "Eqphkiwtcvkqp"tgikuvgt"? "2z4224

Rggt"Rtqeguugt"Kphqtocvkqp"<
////////////////////////////////
" " " " "Uvcpdf{"Nqecvkqp"? "unqv" 8
" " " " "Ewttgvp"Uqhvyctg"uvcvg"? "UVCPDF["JQV
" " " " "Wrvkog"kp"ewttgvp"uvcvg"? "2"okpwwgu
" " " " "Kocig"Xgtukqp"? "Ekueq"KQU"Uqhvyctg."kocigafgcknu"
Vgejpkecn"Uwrrqtv<"jvvr<1lyy0ekueq0eqolvgjuwrrqtv
Eqr{tkijv"*e+"3;:8/422;"d{"Ekueq"U{uvvou."Kpe0
Eqorkngf"000"
" " " " "DQQV"? "fkum2<kocigapcog"
" " " " "EQPHKIAHKNG"?
" " " " "DQQVNFT"?
" " " " "Eqphkiwtcvkqp"tgikuvgt"? "2z4224

Tqwvgt%"ujqy"kuuw"uvcvg"fgvckn"

" " " " " "Unqv"? "7
" " " " " "TR"Uvcvg"? "Cevkxg
" " " " " "KUUV"Uvcvg"? "Kpkv
" " " " " "Dqqv"Xctkcdng"? "fkum2<kocigapcog"
" " " " " "Qrgtcvkpi"Oqfg"? "uuq
" " " " " "Rtkoct{"Xgtukqp"? "P1C
" " " " " "Ugeqpfct{"Xgtukqp"? "P1C
" " " " " "Ewttgvp"Xgtukqp"? "fkum2<kocigapcog"
" " " " " "Xctkcdng"Uvgtg"? "RtuvXdn
" " " " " "TQOQP"EX"? "]"fkum2<ukocigapcog"_

" " " " " "Unqv"? "8
" " " " " "TR"Uvcvg"? "Uvcpdf{
" " " " " "KUUV"Uvcvg"? "Kpkv
" " " " " "Dqqv"Xctkcdng"? "fkum2<kocigapcog"
" " " " " "Qrgtcvkpi"Oqfg"? "uuq
" " " " " "Rtkoct{"Xgtukqp"? "P1C
" " " " " "Ugeqpfct{"Xgtukqp"? "P1C
" " " " " "Ewttgvp"Xgtukqp"? "fkum2<kocigapcog"

```

Aborting the Upgrade Process

You can manually abort the software upgrade at any stage by entering the **issu abortversion** command. The upgrade process also aborts on its own if the software detects a failure.

If you abort the process after you enter the **issu loadversion** command, the standby supervisor engine is reset and reloaded with the original software.

The following is an example of the **issu abortversion slot image** command that shows how to abort the software upgrade process:

```
Tqwgvt%"kuuw"cdqtvxgtukqp"8"e9822u94255"
```


Note

Before you enter the **issu abortversion** command, make sure that the standby supervisor engine is Up (STANDBY HOT [in SSO] or COLD [in RPR]).

How to Upgrade a Non-eFSU Image to an eFSU Image

If the new Cisco IOS software image does not support eFSU, you must manually upgrade the software image. To do so, you must upgrade the software image on the standby supervisor engine and then perform a manual switchover so that the standby takes over processing with the new image. You can then upgrade the software image on the previously active, and now standby, supervisor engine. For more information, see the “[eFSU Summarized Procedure](#)” section on page 5-6.


Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Fast Software Upgrade



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- Supported only with redundant supervisor engines. Cisco IOS software is upgraded on the standby RP, and a manual switchover is performed. The new Cisco IOS image can then be upgraded on the other RP.
- During the upgrade process, different images will be loaded on the RPs for a very short period of time. If a switchover occurs during this time, the device will recover in RPR mode.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

To upgrade or downgrade the Cisco IOS image, perform this task:

	Command	Purpose
Step 1	<code>Tqvwgt@"gpcdng"</code>	Enables privileged EXEC mode (enter your password if prompted).
Step 2	<code>Tqvwgt%"egr{" }hvr<"~"jvvr<11"~"jvvru<11"~"ter<"~"uer<"~"vhvr< ;" fgxkeg<hkngpcog"</code>	Copies a Cisco IOS image onto the flash device of the active RP.
Step 3	<code>Tqvwgt%"egr{" }hvr<"~"jvvr<11"~"jvvru<11"~"ter<"~"uer<"~"vhvr< ;"uncxgfgxkeg<hkngpcog"</code>	Copies a Cisco IOS image onto the flash device of the standby RP.
Step 4	<code>Tqvwgt% eqphkiwtg"vgtokpcn"</code>	Enters global configuration mode.
Step 5	<code>Tqvwgt*eqphki+%"pq"dqqv"u{uvgo"hncuj"] flash-fs<_] partition-number<_] hkngpcog_ "</code>	(Optional) Clears any existing system flash boot image specification.

	Command	Purpose
Step 6	<code>Tqwgvt*eqphki+%dqqv"u{uvgo<hncuj>"]flash-fs<_]partition-number<_]hkngpcog_"</hncuj></code>	Specifies the filename of stored image in flash memory.
Step 7	<code>Tqwgvt*eqphki+%eqphki/tgikuvgt"2z4324"</code>	Sets the configuration register setting to the default value.
Step 8	<code>Tqwgvt*eqphki+%gzkv"</code>	Exits global configuration mode and returns the router to privileged EXEC mode.
Step 9	<code>Tqwgvt%eqr{"twppkpi/eqphki"uvctvwr/eqphki"</code>	Saves the configuration changes to the startup configuration file.
Step 10	<code>jy/oqfwng"}oqfwng"uvcpfd{aunqv;tgugv"</code>	Resets and reloads the standby processor with the specified Cisco IOS image, and executes the image.
Step 11	<code>tgfwpcfpe{"hqteg/uykvejqxgt"</code>	Forces a switchover to the standby RP.

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Stateful Switchover (SSO)

- [Prerequisites for SSO, page 7-1](#)
- [Restrictions for SSO, page 7-2](#)
- [Information About SSO, page 7-3](#)
- [Default Settings for SSO, page 7-10](#)
- [How to Configure SSO, page 7-10](#)
- [Troubleshooting SSO, page 7-11](#)
- [Verifying the SSO Configuration, page 7-12](#)
- [Configuration Examples for SSO, page 7-16](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- SSO and NSF do not support IPv6 multicast traffic.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for SSO

None.

Restrictions for SSO

- [General Restrictions, page 7-2](#)
- [Configuration Mode Restrictions, page 7-2](#)
- [Switchover Process Restrictions, page 7-2](#)

General Restrictions

- Two RPs must be installed in the chassis, each running the same version of the Cisco IOS software.
- Both RPs must run the same Cisco IOS image. If the RPs are operating different Cisco IOS images, the system reverts to RPR mode even if SSO is configured.
- Configuration changes made through SNMP may not be automatically configured on the standby RP after a switchover occurs.
- Load sharing between dual processors is not supported.
- Enhanced Object Tracking (EOT) is not stateful switchover-aware and cannot be used with HSRP, Virtual Router Redundancy Protocol (VRRP), or Gateway Load Balancing Protocol (GLBP) in SSO mode.
- Multicast is not SSO-aware and restarts after switchover; therefore, multicast tables and data structures are cleared upon switchover.

Configuration Mode Restrictions

- The configuration registers on both RPs must be set the same for the networking device to behave the same when either RP is rebooted.
- During the startup (bulk) synchronization, configuration changes are not allowed. Before making any configuration changes, wait for a message similar to the following:

```
'JC/7/OQFG<Qrgtcvkpi"oqfg"ku"uuq."eqphkiwtgf"oqfg"ku"uuq0
```

Switchover Process Restrictions

- If any changes to the fabric configuration happen simultaneously with an RP switchover, the chassis is reset and all line cards are reset.
- If the switch is configured for SSO mode, and the active RP fails before the standby is ready to switch over, the switch will recover through a full system reset.
- During SSO synchronization between the active and standby RPs, the configured mode will be RPR. After the synchronization is complete, the operating mode will be SSO. If a switchover occurs before the synchronization is complete, the switchover will be in RPR mode.
- If a switchover occurs before the bulk synchronization step is complete, the new active RP may be in inconsistent states. The switch will be reloaded in this case.
- Switchovers in SSO mode will not cause the reset of any line cards.
- Interfaces on the RP itself are not stateful and will experience a reset across switchovers. In particular, the GE interfaces on the RPs are reset across switchovers and do not support SSO.

- Any line cards that are not online at the time of a switchover (line cards not in Cisco IOS running state) are reset and reloaded on a switchover.

Information About SSO

- [SSO Overview, page 7-3](#)
- [SSO Operation, page 7-5](#)
- [Route Processor Synchronization, page 7-6](#)
- [SSO Operation, page 7-8](#)
- [SSO-Aware Features, page 7-10](#)

SSO Overview

The switch supports fault resistance by allowing a redundant supervisor engine to take over if the primary supervisor engine fails. Cisco SSO (frequently used with NSF) minimizes the time a network is unavailable to its users following a switchover while continuing to forward IP packets. The switch supports route processor redundancy (RPR). For more information, see [Chapter 9, “Route Processor Redundancy \(RPR\).”](#)

SSO is particularly useful at the network edge. Traditionally, core routers protect against network faults using router redundancy and mesh connections that allow traffic to bypass failed network elements. SSO provides protection for network edge devices with dual Route Processors (RPs) that represent a single point of failure in the network design, and where an outage might result in loss of service for customers.


SSO has many benefits. Because the SSO feature maintains stateful feature information, user session information is maintained during a switchover, and line cards continue to forward network traffic with no loss of sessions, providing improved network availability. SSO provides a faster switchover than RPR by fully initializing and fully configuring the standby RP, and by synchronizing state information, which can reduce the time required for routing protocols to converge. Network stability may be improved with the reduction in the number of route flaps had been created when routers in the network failed and lost their routing tables.

SSO is required by the Cisco Nonstop Forwarding (NSF) feature (see [Chapter 8, “Nonstop Forwarding \(NSF\)”](#)).

Figure 7-1 illustrates how SSO is typically deployed in service provider networks. In this example, Cisco NSF with SSO is primarily at the access layer (edge) of the service provider network. A fault at this point could result in loss of service for enterprise customers requiring access to the service provider network.

For Cisco NSF protocols that require neighboring devices to participate in Cisco NSF, Cisco NSF-aware software images must be installed on those neighboring distribution layer devices. Additional network availability benefits might be achieved by applying Cisco NSF and SSO features at the core layer of your network; however, consult your network design engineers to evaluate your specific site requirements.


Figure 7-1 Cisco NSF with SSO Network Deployment: Service Provider Networks



72134

Additional levels of availability may be gained by deploying Cisco NSF with SSO at other points in the network where a single point of failure exists. [Figure 7-2](#) illustrates an optional deployment strategy that applies Cisco NSF with SSO at the enterprise network access layer. In this example, each access point in the enterprise network represents another single point of failure in the network design. In the event of a switchover or a planned software upgrade, enterprise customer sessions would continue uninterrupted through the network.

Figure 7-2 Cisco NSF with SSO Network Deployment: Enterprise Networks



SSO Operation

SSO establishes one of the RPs as the active processor while the other RP is designated as the standby processor. SSO fully initializes the standby RP, and then synchronizes critical state information between the active and standby RP.

During an SSO switchover, the line cards are not reset, which provides faster switchover between the processors. The following events cause a switchover:

- A hardware failure on the active supervisor engine
- Clock synchronization failure between supervisor engines
- A manual switchover or shutdown

An SSO switchover does not interrupt Layer 2 traffic. An SSO switchover preserves FIB and adjacency entries and can forward Layer 3 traffic after a switchover. SSO switchover duration is between 0 and 3 seconds.

**Note**

For Catalyst 6500 Series Switches, the maximum supported Adjacency value is 800,000.

Route Processor Synchronization

- [Synchronization Overview, page 7-6](#)
- [Bulk Synchronization During Initialization, page 7-6](#)
- [Synchronization of Startup Configuration, page 7-6](#)
- [Incremental Synchronization, page 7-7](#)

Synchronization Overview

In networking devices running SSO, both RPs must be running the same configuration so that the standby RP is always ready to assume control if the active RP fails. SSO synchronizes the configuration information from the active RP to the standby RP at startup and whenever changes to the active RP configuration occur. This synchronization occurs in two separate phases:

- While the standby RP is booting, the configuration information is synchronized in bulk from the active RP to the standby RP.
- When configuration or state changes occur, an incremental synchronization is conducted from the active RP to the standby RP.

Bulk Synchronization During Initialization

When a system with SSO is initialized, the active RP performs a chassis discovery (discovery of the number and type of line cards and fabric cards, if available, in the system) and parses the startup configuration file.

The active RP then synchronizes this data to the standby RP and instructs the standby RP to complete its initialization. This method ensures that both RPs contain the same configuration information.

Even though the standby RP is fully initialized, it interacts only with the active RP to receive incremental changes to the configuration files as they occur. Executing CLI commands on the standby RP is not supported.

Synchronization of Startup Configuration

During system startup, the startup configuration file is copied from the active RP to the standby RP. Any existing startup configuration file on the standby RP is overwritten.

The startup configuration is a text file stored in the NVRAM of the RP. It is synchronized whenever you perform the following operations:

- CLI command **copy system:running-config nvram:startup-config** is used.
- CLI command **copy running-config startup-config** is used.
- CLI command **write memory** is used.
- CLI command **copy filename nvram:startup-config** is used.
- SNMP SET of MIB variable ccCopyEntry in CISCO_CONFIG_COPY MIB is used.

- System configuration is saved using the **reload** command.
- System configuration is saved following entry of a forced switchover CLI command.

Incremental Synchronization

- [Incremental Synchronization Overview, page 7-7](#)
- [CLI Commands, page 7-7](#)
- [SNMP SET Commands, page 7-7](#)
- [Routing and Forwarding Information, page 7-7](#)
- [Chassis State, page 7-7](#)
- [Line Card State, page 7-8](#)
- [Counters and Statistics, page 7-8](#)

Incremental Synchronization Overview

After both RPs are fully initialized, any further changes to the running configuration or active RP states are synchronized to the standby RP as they occur. Active RP states are updated as a result of processing feature information, external events (such as the interface becoming up or down), or user configuration commands (using CLI commands or Simple Network Management Protocol [SNMP]) or other internal events.

CLI Commands

CLI changes to the running configuration are synchronized from the active RP to the standby RP. In effect, the CLI command is run on both the active and the standby RP.

SNMP SET Commands

Configuration changes caused by an SNMP set operation are synchronized on a case-by-case basis. Currently only two SNMP configuration set operations are supported:

- **shut** and **no-shut** (of an interface)
- **link up/down trap enable/disable**

Routing and Forwarding Information

Routing and forwarding information is synchronized to the standby RP:

- State changes for SSO-aware features (for example, SNMP) are synchronized to the standby RP.
- Cisco Express Forwarding updates to the Forwarding Information Base (FIB) are synchronized to the standby RP.

Chassis State

Changes to the chassis state due to line card insertion or removal are synchronized to the standby RP.

Line Card State

Changes to the line card states are synchronized to the standby RP. Line card state information is initially obtained during bulk synchronization of the standby RP. Following bulk synchronization, line card events, such as whether the interface is up or down, received at the active processor are synchronized to the standby RP.

Counters and Statistics

The various counters and statistics maintained in the active RP are not synchronized because they may change often and because the degree of synchronization they require is substantial. The volume of information associated with statistics makes synchronizing them impractical.

**Note**

Not synchronizing counters and statistics between RPs may create problems for external network management systems that monitor this information.

SSO Operation

- [SSO Conditions, page 7-8](#)
- [Switchover Time, page 7-9](#)
- [Online Removal of the Active RP, page 7-9](#)
- [Fast Software Upgrade, page 7-9](#)
- [Core Dump Operation, page 7-9](#)

SSO Conditions

An automatic or manual switchover may occur under the following conditions:

- A fault condition that causes the active RP to crash or reboot—automatic switchover
- The active RP is declared dead (not responding)—automatic switchover
- The CLI is invoked—manual switchover

The user can force the switchover from the active RP to the standby RP by using a CLI command. This manual procedure allows for a “graceful” or controlled shutdown of the active RP and switchover to the standby RP. This graceful shutdown allows critical cleanup to occur.

**Note**

This procedure should not be confused with the graceful shutdown procedure for routing protocols in core routers—they are separate mechanisms.

**Caution**

The SSO feature introduces a number of new command and command changes, including commands to manually cause a switchover. The **reload** command does not cause a switchover. The **reload** command causes a full reload of the box, removing all table entries, resetting all line cards, and interrupting nonstop forwarding.

Switchover Time

The time required by the device to switch over from the active RP to the standby RP is between zero and three seconds.

Although the newly active processor takes over almost immediately following a switchover, the time required for the device to begin operating again in full redundancy (SSO) mode can be several minutes, depending on the platform. The length of time can be due to a number of factors including the time needed for the previously active processor to obtain crash information, load code and microcode, and synchronize configurations between processors.

On DFC-equipped switching modules, forwarding information is distributed, and packets forwarded from the same line card should have little to no forwarding delay; however, forwarding packets between line cards requires interaction with the RP, meaning that packet forwarding might have to wait for the switchover time.

Online Removal of the Active RP

Online removal of the active RP automatically forces a stateful switchover to the standby RP.

Fast Software Upgrade

You can use Fast Software Upgrade (FSU) to reduce planned downtime. With FSU, you can configure the system to switch over to a standby RP that is preloaded with an upgraded Cisco IOS software image. FSU reduces outage time during a software upgrade by transferring functions to the standby RP that has the upgraded Cisco IOS software preinstalled. You can also use FSU to downgrade a system to an older version of Cisco OS or have a backup system loaded for downgrading to a previous image immediately after an upgrade.

SSO must be configured on the networking device before performing FSU.



Note

During the upgrade process, different images will be loaded on the RPs for a short period of time. During this time, the device will operate in RPR mode.

Core Dump Operation

In networking devices that support SSO, the newly active primary processor runs the core dump operation after the switchover has taken place. Not having to wait for dump operations effectively decreases the switchover time between processors.

Following the switchover, the newly active RP will wait for a period of time for the core dump to complete before attempting to reload the formerly active RP. The time period is configurable. For example, on some platforms an hour or more may be required for the formerly active RP to perform a coredump, and it might not be site policy to wait that much time before resetting and reloading the formerly active RP. In the event that the core dump does not complete within the time period provided, the standby is reset and reloaded regardless of whether it is still performing a core dump.

The core dump process adds the slot number to the core dump file to identify which processor generated the file content.

**Note**

Core dumps are generally useful only to your technical support representative. The core dump file, which is a very large binary file, must be transferred using the TFTP, FTP, or remote copy protocol (rcp) server and subsequently interpreted by a Cisco Technical Assistance Center (TAC) representative that has access to source code and detailed memory maps.

SSO-Aware Features

A feature is SSO-aware if it maintains, either partially or completely, undisturbed operation through an RP switchover. State information for SSO-aware features is synchronized from active to standby to achieve stateful switchover for those features.

The dynamically created state of SSO-unaware features is lost on switchover and must be reinitialized and restarted on switchover.

The output of the **show redundancy clients** command displays the SSO-aware features (see the [“Verifying SSO Features” section on page 7-14](#)).

Default Settings for SSO

None.

How to Configure SSO

**Note**

See [Chapter 6, “Fast Software Upgrade,”](#) for information about how to copy images onto the switch. During the upgrade process, different images will be loaded on the RPs for a very short period of time. If a switchover occurs during this time, the device will recover in RPR mode.

Either the SSO or RPR redundancy mode is always configured. The SSO redundancy mode is configured by default. To revert to the default SSO redundancy mode from the RPR redundancy mode, perform this task:

	Command	Purpose
Step 1	Tqvwgt@ gpcdng "	Enables privileged EXEC mode (enter your password if prompted).
Step 2	Tqvwgt% eqphkiwtg "vgtokpcn"	Enters global configuration mode.
Step 3	Tqvwgt*eqphki+%" tgfwfcpce {"	Enters redundancy configuration mode.
Step 4	Tqvwgt*eqphki+%" oqfg "uuq"	Sets the redundancy configuration mode to SSO on both the active and standby RP.
		Note After configuring SSO mode, the standby RP will automatically reset.

	Command	Purpose
Step 5	<code>Tqwgvt*eqphki/tgf+% "gpf"</code>	Exits redundancy configuration mode and returns the switch to privileged EXEC mode.
Step 6	<code>Tqwgvt%"eqr{ "twppkpi/eqphki"uvctvwr/eqphki"</code>	Saves the configuration changes to the startup configuration file.

This example shows how to configure the SSO redundancy mode:

```
Tqwgvt@"gpcdng"
Tqwgvt%"eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+% "tgfwfcpce{ "
Tqwgvt*eqphki+% "oqfg"uuq"
Tqwgvt*eqphki/tgf+% "gpf"
Tqwgvt%"eqr{ "twppkpi/eqphki"uvctvwr/eqphki"
Tqwgvt%"
```

Troubleshooting SSO

- [Possible SSO Problem Situations, page 7-11](#)
- [SSO Troubleshooting, page 7-12](#)

Possible SSO Problem Situations

- The standby RP was reset, but there are no messages describing what happened—To display a log of SSO events and clues as to why a switchover or other event occurred, enter the **show redundancy history** command on the newly active RP:

```
Tqwgvt%"ujqy"tgfwfcpce{ "jkuvqt{ "
```

- The **show redundancy states** command shows an operating mode that is different than what is configured on the networking device—On certain platforms the output of the **show redundancy states** command displays the actual operating redundancy mode running on the device, and not the configured mode as set by the platform. The operating mode of the system can change depending on system events. For example, SSO requires that both RPs on the networking device be running the same software image; if the images are different, the device will not operate in SSO mode, regardless of its configuration.

For example, during the upgrade process different images will be loaded on the RPs for a short period of time. If a switchover occurs during this time, the device will recover in RPR mode.

- Reloading the device disrupts SSO operation—The SSO feature introduces a number of commands, including commands to manually cause a switchover. The reload command is not an SSO command. This command causes a full reload of the box, removing all table entries, resetting all line cards, and thereby interrupting network traffic forwarding. To avoid reloading the box unintentionally, use the **redundancy force-switchover** command.
- During a software upgrade, the networking device appears to be in a mode other than SSO—During the software upgrade process, the show redundancy command indicates that the device is running in a mode other than SSO.

This is normal behavior. Until the FSU procedure is complete, each RP will be running a different software version. While the RPs are running different software versions, the mode will change to either RPR. The device will change to SSO mode once the upgrade has completed.

- The previously active processor is being reset and reloaded before the core dump completes—Use the **crashdump-timeout** command to set the maximum time that the newly active processor waits before resetting and reloading the previously active processor.
- Issuing a “send break” does not cause a system switchover—This is normal operation. Using “send break” to break or pause the system is not recommended and may cause unpredictable results. To initiate a manual switchover, use the **redundancy force-switchover** command.

In Cisco IOS software, you can enter ROM monitor mode by restarting the switch and then pressing the Break key or issuing a “send break” command from a telnet session during the first 60 seconds of startup. The send break function can be useful for experienced users or for users under the direction of a Cisco Technical Assistance Center (TAC) representative to recover from certain system problems or to evaluate the cause of system problems.

SSO Troubleshooting

The following commands may be used as needed to troubleshoot the SSO feature. These commands do not have to be entered in any particular order.

Command	Purpose
<code>Tqwwgt*eqphki/tgfi+"etcu jfwor/vkogqvw"]mm ~"jj<oo_"</code>	Sets the longest time that the newly active RP will wait before reloading the formerly active RP.
<code>Tqwwgt%"fgdwi"tgfwfpcpe{" }cnn"~"wk"~"enm"~"jwdi"</code>	Debugs redundancy on the networking device.
<code>Tqwwgt%"ujqy"fkci"]slot-number"~"ejcuuku"~"uwdunqvunqvl uwdunqv_"]fgvcknu"~"uwooct{"_"</code>	Displays hardware information.
<code>Tqwwgt%"ujqy"tgfwfpcpe{"]enkppvu"~"eqwpvgtu"~"fgdwi/nqi"~"jcpfqxgt"~"jkuvqt{"~"uykvej qxgt"jkuvqt{"~"uvcvgu"~"kpvgt/fgxkeg_"</code>	Displays the redundancy configuration mode of the RP. Also displays information about the number of switchovers, system uptime, processor uptime, and redundancy state, and reasons for any switchovers.
<code>Tqwwgt%"ujqy"xgtukqp"</code>	Displays image information for each RP.

Verifying the SSO Configuration

- [Verifying that SSO Is Configured](#)
- [Verifying that SSO Is Operating on the Device](#)
- [Verifying SSO Features](#)

Verifying that SSO Is Configured

In the following example, the **show redundancy** command is used to verify that SSO is configured on the device.

```
Tqwwgt@"gpcdnq"
Tqwwgt%"ujqy"tgfwfpcpe{"
Tgfwfpcpv"U{uvgo"Kphqto cvkqp"<
////////////////////////////////
" " " " " "Cxcnkcdng"u{uvgo"wrvkog"? "5"fc{u."6"jqwtu."57"okpwwgu
Uykvej qxgtu"u{uvgo"gzrgtkgpegf"? "2
" " " " " " " " " " " "Uvcpdf{"hcknwtgu"? "3
```

```

" " " " "NcuV"uykvejxgt"tgcup?"pqp
" " " " "Jctfycyg"Oqfg?"Fwrngz
" " " "Eqphkiwtgf"tgfwfcp{"Oqfg?"uuq
" " " "Qrgtcvkpi"tgfwfcp{"Oqfg?"uuq
" " " " "OckpvGPCpeg"Oqfg?"Fkucdnf
" " " " "Eqoowpkcvkqpu?"Wr

Ewttgvp"Rtqeguugt"Kphqtocvkqp"<
////////////////////////////////
" " " " "Cevkxg"Nqecvkqp?"unqv"7
" " " " "Ewttgvp"Uqhvyctg"uvcvg?"CEVKXG
" " " " "Wrvkog"kp"ewttgvp"uvcvg?"5"fc{u."6"jqwtu."57"okpwwgu
" " " " "Kocig"Xgtukqp?"Ekueq"KQU"Uqhvyctg."u4v76"Uqhvyctg"000"
U{pegf"vq"000"
Eqr{tkijv"*e+"3;:8/4233"d{"Ekueq"U{uvvou."Kpe0
Eqorkngf"000"
" " " " "DQQV?"fkum2<2948ae6.34
" " " " "EQPHKIAHKNG?"
" " " " "DQQVNFT?"
" " " " "Eqphkiwtcvkqp"tgikuvgt?"2z4324

Rggt"Rtqeguugt"Kphqtocvkqp"<
////////////////////////////////
" " " " "Uvcdfd{"Nqecvkqp?"unqv"8
" " " " "Ewttgvp"Uqhvyctg"uvcvg?"UVCDFD["JQV"
" " " " "Wrvkog"kp"ewttgvp"uvcvg?"5"jqwtu."77"okpwwgu
" " " " "Kocig"Xgtukqp?"Ekueq"KQU"Uqhvyctg."u4v76"Uqhvyctg"000"
U{pegf"vq"000"
Eqr{tkijv"*e+"3;:8/4233"d{"Ekueq"U{uvvou."Kpe0
Eqorkngf"000"
" " " " "DQQV?"fkum2<2948ae6.34
" " " " "EQPHKIAHKNG?"
" " " " "DQQVNFT?"
" " " " "Eqphkiwtcvkqp"tgikuvgt?"2z4324

Tqwwgt%

```

Verifying that SSO Is Operating on the Device

In the following example, the **show redundancy** command with the **states** keyword is used to verify that SSO is configured on the device.

```
Tqwwgt%"ujqy"tgfwfcp{"uvcvgu"
```

[illegible]

Verifying SSO Features

Enter the **show redundancy clients** command to display the list of features that have registered as SSO features.

[illegible]


```

"enkgrpVKF"?723""""enkgrpVUs"?349""""NCP/Uykvej "XVR"XNCP""
"enkgrpVKF"?735""""enkgrpVUs"?34: """"NCP/Uykvej "KFDJCN""""
"enkgrpVKF"?93""""enkgrpVUs"?34; """"ZFT"TR"TH"Enkgrp""""
"enkgrpVKF"?46""""enkgrpVUs"?352""""EGH"TR"TH"Enkgrp""""
"enkgrpVKF"?368""""enkgrpVUs"?354""""DHF"TH"Enkgrp""""
"enkgrpVKF"?523""""enkgrpVUs"?357""""OTKD"TR"TH"Enkgrp""""
"enkgrpVKF"?528""""enkgrpVUs"?35; """"OHKD"TR"TH"Enkgrp""""
"enkgrpVKF"?3726""""enkgrpVUs"?368""""Ecv8m"EYCP"Kpvgthceg""
"enkgrpVKF"?3729""""enkgrpVUs"?369""""EYCP"NVN"Oit"JC"TH"E""
"enkgrpVKF"?742""""enkgrpVUs"?373""""THU"TH""""
"enkgrpVKF"?432""""enkgrpVUs"?374""""Cwvj"Oit""""
"enkgrpVKF"?7""""enkgrpVUs"?375""""Eqphki"U{pe"TH"enkgrp""
"enkgrpVKF"?35: """"enkgrpVUs"?377""""OFT"UO""""
"enkgrpVKF"?352: """"enkgrpVUs"?378""""Ecv8m"Nqecn"Vct igv"N""
"enkgrpVKF"?3573""""enkgrpVUs"?379""""TH"XU"Enkgrp""""
"enkgrpVKF"?357: """"enkgrpVUs"?37: """"Ecv8m"XUnqv""""
"enkgrpVKF"?724""""enkgrpVUs"?384""""NCP/Uykvej "Rqtv"OcpC""
"enkgrpVKF"?736""""enkgrpVUs"?385""""UYKVEJaXNCPaJC""""
"enkgrpVKF"?3535""""enkgrpVUs"?387""""Ecv8m"Rncvhtqto""""
"enkgrpVKF"?353: """"enkgrpVUs"?388""""Ecv8m"Rqygt""""
"enkgrpVKF"?45""""enkgrpVUs"?393""""Htcog"tgnc{ """"
"enkgrpVKF"?6; """"enkgrpVUs"?394""""JFNE""""
"enkgrpVKF"?94""""enkgrpVUs"?395""""NUF"JC"Rtqe""""
"enkgrpVKF"?335""""enkgrpVUs"?396""""OHK"UVCVKE"JC"Rtqe""""
"enkgrpVKF"?3557""""enkgrpVUs"?3: 2""""E8M"GHR"TH"enkgrp""""
"enkgrpVKF"?422""""enkgrpVUs"?3: 3""""GVJGTPGV"QCO"TH""""
"enkgrpVKF"?429""""enkgrpVUs"?3: 5""""GEHO"TH""""
"enkgrpVKF"?424""""enkgrpVUs"?3: 6""""GVJGTPGV"NOK"TH""""
"enkgrpVKF"?42: """"enkgrpVUs"?3: 8""""NNFR""""
"enkgrpVKF"?42""""enkgrpVUs"?3: 5""""KRTQWVKPI"PUH"TH"enk""
"enkgrpVKF"?43""""enkgrpVUs"?3: 9""""RRR"TH""""
"enkgrpVKF"?3574""""enkgrpVUs"?423""""E8Martqxxkukqpathaenk""
"enkgrpVKF"?3529""""enkgrpVUs"?424""""Ecv8m"KFRTQO""""
"enkgrpVKF"?96""""enkgrpVUs"?428""""ORNU"XRP"JC"Enkgrp""""
"enkgrpVKF"?56""""enkgrpVUs"?42: """"UPOR"TH"Enkgrp""""
"enkgrpVKF"?3724""""enkgrpVUs"?42; """"EYCP"CRU"JC"TH"Enkgrp""
"enkgrpVKF"?74""""enkgrpVUs"?432""""CVO""""
"enkgrpVKF"?357""""enkgrpVUs"?43; """"Jkuvqt{ "TH"Enkgrp""""
"enkgrpVKF"?2""""enkgrpVUs"?453""""TUXR"JC"Ugtxkegu""""
"enkgrpVKF"?472""""enkgrpVUs"?465""""GGO"Ugtxgt "TH"ENKGPV""
"enkgrpVKF"?474""""enkgrpVUs"?467""""GGO"RQNKEL /FKT"TH"EN""
"enkgrpVKF"?76""""enkgrpVUs"?469""""UPOR"JC"TH"Enkgrp""""
"enkgrpVKF"?95""""enkgrpVUs"?46: """"NFR"JC""""
"enkgrpVKF"?98""""enkgrpVUs"?46; """"KRTO""""
"enkgrpVKF"?79""""enkgrpVUs"?472""""CTR""""
"enkgrpVKF"?72""""enkgrpVUs"?479""""HJaTHaGxgpvaFgvgevt ""
"enkgrpVKF"?372: """"enkgrpVUs"?485""""EYCP"NVN"UR"TH"Enkgrp""
"enkgrpVKF"?3526""""enkgrpVUs"?489""""Ecv8m"Gje""""
"enkgrpVKF"?3527""""enkgrpVUs"?493""""Ecv8m"RCiRlNCER""""
"enkgrpVKF"?725""""enkgrpVUs"?494""""Urcppkpi/Vtgg"Rtqvqe""
"enkgrpVKF"?352; """"enkgrpVUs"?495""""EOTR"TH"Enkgrp""""
"enkgrpVKF"?3533""""enkgrpVUs"?497""""Ecv8m"N5"OcpCigt""""
"enkgrpVKF"?3539""""enkgrpVUs"?498""""Ecv8m"ECRK""""
"enkgrpVKF"?3728""""enkgrpVUs"?499""""EYCP"UTR"TH"Enkgrp""""
"enkgrpVKF"?5""""enkgrpVUs"?4: 6""""CE"TH"Enkgrp""""
"enkgrpVKF"?367""""enkgrpVUs"?4: 7""""XHk"Oit""""
"enkgrpVKF"?6""""enkgrpVUs"?4: 8""""CVQO"ocpcigt""""
"enkgrpVKF"?7""""enkgrpVUs"?4: 9""""UUO""""
"enkgrpVKF"?9""""enkgrpVUs"?4: 3""""UND"TH"Enkgrp""""
"enkgrpVKF"?726""""enkgrpVUs"?4: 6""""Uykvej "URCP"enkgrp""""
"enkgrpVKF"?729""""enkgrpVUs"?4: 7""""Uykvej "Dcemwr"Kpvgth""
"enkgrpVKF"?327""""enkgrpVUs"?4; : """"FJER"Upqqrkpi""""
"enkgrpVKF"?3732""""enkgrpVUs"?526""""Ecnn/Jqog"TH""""
"enkgrpVKF"?425""""enkgrpVUs"?529""""OXTR"TH""""

```

```

"enkppvKF"? "373" "" "enkppvÜgs"? "532" "" "" "KR"Vwppgn"TH" "" "" "" "" ""
"enkppvKF"? "6" "" "" "" "enkppvÜgs"? "533" "" "" "" "Eqphki"Xgtkh{ "TH"enk"
"enkppvKF"? "738" "" "" "" "enkppvÜgs"? "536" "" "" "" "Gpgti{Ykug"th"enkppv"
"enkppvKF"? "72:" "" "" "" "enkppvÜgs"? "538" "" "" "" "Rqtv"Ugewtkv{ "Enkppv"
"enkppvKF"? "72;" "" "" "" "enkppvÜgs"? "539" "" "" "" "NCP/Uykvej"KR"Jquv"V"
"enkppvKF"? "737" "" "" "" "enkppvÜgs"? "53:" "" "" "" "UKUH"vcdng" "" "" "" "" ""
"enkppvKF"? "357" "" "" "" "enkppvÜgs"? "544" "" "" "" "KMG"TH"Enkppv" "" "" "" "" ""
"enkppvKF"? "358" "" "" "" "enkppvÜgs"? "545" "" "" "" "KRUGE"TH"Enkppv" "" "" "" "" ""
"enkppvKF"? "352" "" "" "" "enkppvÜgs"? "546" "" "" "" "ET[RVQ"TH" "" "" "" "" "" ""
"enkppvKF"? "622" "" "" "" "enkppvÜgs"? "548" "" "" "" "KR"Cfokuukqp"TH"Enkg"
"enkppvKF"? "52;" "" "" "" "enkppvÜgs"? "557" "" "" "" "KUUV"rtqeguu" "" "" "" "" ""
"enkppvKF"? "6227" "" "" "" "enkppvÜgs"? "55:" "" "" "" "KUUV"Vguv"Enkppv" "" "" "" "" ""
"enkppvKF"? "5" "" "" "" "enkppvÜgs"? "564" "" "" "" "Pgyvqtm"TH"4"Enkppv" "" "" "" "" ""
"enkppvKF"? "3542" "" "" "" "enkppvÜgs"? "565" "" "" "" "Ecv8m"RHaONaTR" "" "" "" "" ""
"enkppvKF"? "732" "" "" "" "enkppvÜgs"? "567" "" "" "" "NCP/Uykvej"RCiR1NCER"
"enkppvKF"? "733" "" "" "" "enkppvÜgs"? "568" "" "" "" "NCP/Uykvej"Rtkxcvg"X"
"enkppvKF"? "3543" "" "" "" "enkppvÜgs"? "569" "" "" "" "RO"UR"enkppv" "" "" "" "" ""
"enkppvKF"? "3544" "" "" "" "enkppvÜgs"? "56:" "" "" "" "XNCP"Ocrkpi" "" "" "" "" ""
"enkppvKF"? "3537" "" "" "" "enkppvÜgs"? "572" "" "" "" "Ecv8m"Engct"Eqwvpgt" "" "" "" "" ""
"enkppvKF"? "363" "" "" "" "enkppvÜgs"? "574" "" "" "" "FCVC"FGUETKRVQT"TH"E"
"enkppvKF"? "3222" "" "" "" "enkppvÜgs"? "583" "" "" "" "EVU"JC" "" "" "" "" "" ""
"enkppvKF"? "3223" "" "" "" "enkppvÜgs"? "584" "" "" "" "Mg{uvqtg" "" "" "" "" "" ""
"enkppvKF"? "5372" "" "" "" "enkppvÜgs"? "585" "" "" "" "UKC"UF"TH"ENKGPV" "" "" "" "" ""
"enkppvKF"? "5373" "" "" "" "enkppvÜgs"? "586" "" "" "" "UKC"UD"TH"ENKGPV" "" "" "" "" ""
"enkppvKF"? "5374" "" "" "" "enkppvÜgs"? "587" "" "" "" "UKC"UEN"TH"ENKGPV" "" "" "" "" ""
"enkppvKF"? "5375" "" "" "" "enkppvÜgs"? "588" "" "" "" "UKC"UXG"TH"ENKGPV" "" "" "" "" ""
"enkppvKF"? "5376" "" "" "" "enkppvÜgs"? "589" "" "" "" "UKC"VER"TH"ENKGPV" "" "" "" "" ""
"enkppvKF"? "3554" "" "" "" "enkppvÜgs"? "595" "" "" "" "RENE" "" "" "" "" "" ""
"enkppvKF"? "3589" "" "" "" "enkppvÜgs"? "597" "" "" "" "Ecv8m"KVCUECaTR" "" "" "" "" ""
"enkppvKF"? "6254" "" "" "" "enkppvÜgs"? "59;" "" "" "" "CEN"jcpfng"TH"Enkppv"
"enkppvKF"? "6242" "" "" "" "enkppvÜgs"? "5:3" "" "" "" "KQU"Eqphki"CTEJKXG" "" "" "" "" ""
"enkppvKF"? "6243" "" "" "" "enkppvÜgs"? "5:4" "" "" "" "KQU"Eqphki"TONNDCEM" "" "" "" "" ""
"enkppvKF"? "355;" "" "" "" "enkppvÜgs"? "626" "" "" "" "Ecv8m"dnwg"dgceqp"TH"
"enkppvKF"? "3584" "" "" "" "enkppvÜgs"? "627" "" "" "" "XU"JC" "" "" "" "" "" ""
"enkppvKF"? "739" "" "" "" "enkppvÜgs"? "628" "" "" "" "NCP/Uykvej"KFDJCN4" "" "" "" "" ""
"enkppvKF"? "3558" "" "" "" "enkppvÜgs"? "637" "" "" "" "Ecv8m"PVK"UWR"UK"uyk"
"enkppvKF"? "87222" "" "" "" "enkppvÜgs"? "638" "" "" "" "THANCUVaENKGPV" "" "" "" "" ""

```

Configuration Examples for SSO

This example configures the SSO redundancy mode :

```

Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+%"tgfwpfcp{"
Tqwvgt*eqphki/tgf+%"oqfg"uuq"
Tqwvgt*eqphki/tgf+%"gzkv"
Tqwvgt%"eqr{"twppkpi/eqphki"uvctvwr/eqphki"

```



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

Participate in the Technical Documentation Ideas forum



Nonstop Forwarding (NSF)

- [Prerequisites for NSF, page 8-1](#)
- [Restrictions for NSF, page 8-2](#)
- [Information About NSF, page 8-3](#)
- [Default Settings for NSF, page 8-9](#)
- [How to Configure NSF, page 8-9](#)
- [Configuration Examples for NSF, page 8-15](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- Stateful switchover (SSO) and nonstop forwarding (NSF) do not support IPv6 multicast traffic.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for NSF

None.

Restrictions for NSF

- [General Restrictions, page 8-2](#)
- [Restrictions for BGP NSF, page 8-2](#)
- [Restrictions for EIGRP NSF, page 8-2](#)
- [Restrictions for OSPF NSF, page 8-2](#)
- [Restrictions for IS-IS NSF, page 8-2](#)
- [Restrictions for IPv6 NSF, page 8-3](#)

General Restrictions

- NSF requires SSO (see [Chapter 7, “Stateful Switchover \(SSO\)”](#)).
- The Hot Standby Routing Protocol (HSRP) is not supported with Cisco Nonstop Forwarding with Stateful Switchover. Do not use HSRP with Cisco Nonstop Forwarding with Stateful Switchover.

Restrictions for BGP NSF

- All neighboring devices participating in BGP NSF must be NSF-capable, having been configured for BGP graceful restart as described in the [“Configuring and Verifying BGP for NSF”](#) section on [page 8-9](#).

Restrictions for EIGRP NSF

- All neighboring devices participating in EIGRP NSF operation must be NSF-capable or NSF-aware.
- An NSF-aware router cannot support two NSF-capable peers performing an NSF restart operation at the same time. However, both neighbors will reestablish peering sessions after the NSF restart operation is complete.

Restrictions for OSPF NSF

- OSPF NSF for virtual links is not supported.
- All OSPF networking devices on the same network segment must be NSF-aware (that is, running an NSF software image).
- OSPF NSF for sham links is not supported.

Restrictions for IS-IS NSF

- For IETF IS-IS, all neighboring devices must be running an NSF-aware software image.

Restrictions for IPv6 NSF

- IPv6 must be enabled on your router for IPv6 NSF to be supported.

Information About NSF

- [NSF Overview, page 8-3](#)
- [Feature Interaction with NSF, page 8-4](#)

NSF Overview

NSF works with SSO to minimize the amount of time a network is unavailable to its users following a switchover. The main objective of Cisco NSF is to continue forwarding IP packets following a route processor (RP) switchover.

Usually, when a networking device restarts, all routing peers of that device detect that the device went down and then came back up. This transition results in what is called a routing flap, which could spread across multiple routing domains. Routing flaps caused by routing restarts create routing instabilities, which are detrimental to the overall network performance. Cisco NSF helps to suppress routing flaps in SSO-enabled devices, thus reducing network instability.

Cisco NSF allows for the forwarding of data packets to continue along known routes while the routing protocol information is being restored following a switchover. With Cisco NSF, peer networking devices do not experience routing flaps. Data traffic is forwarded through intelligent line cards while the standby RP assumes control from the failed active RP during a switchover. The ability of line cards to remain up through a switchover and to be kept current with the Forwarding Information Base (FIB) on the active RP is key to Cisco NSF operation.

The Cisco NSF feature has several benefits, including the following:

- Improved network availability—NSF continues forwarding network traffic and application state information so that user session information is maintained after a switchover.
- Overall network stability—Network stability may be improved with the reduction in the number of route flaps that had been created when routers in the network failed and lost their routing tables.
- Neighboring routers do not detect link flapping—Because the interfaces remain up across a switchover, neighboring routers do not detect a link flap (that is, the link does not go down and come back up).
- Prevents routing flaps—Because SSO continues forwarding network traffic in the event of a switchover, routing flaps are avoided.
- No loss of user sessions—User sessions established prior to the switchover are maintained.

A networking device is NSF-aware if it is running NSF-compatible software. A device is NSF-capable if it has been configured to support NSF and would rebuild routing information from NSF-aware or NSF-capable neighbors.

CEF is always enabled on the switch and cannot be disabled. The routing protocols depend on CEF to continue forwarding packets during switchover while the routing protocols rebuild the Routing Information Base (RIB) tables. Once the routing protocols have converged, CEF updates the FIB table and removes stale route entries and CEF updates the line cards with the new FIB information.

Feature Interaction with NSF

- [Cisco Express Forwarding, page 8-4](#)
- [Routing Protocol Operation, page 8-4](#)
- [BGP Operation, page 8-5](#)
- [EIGRP Operation, page 8-5](#)
- [IS-IS Operation, page 8-6](#)
- [OSPF Operation, page 8-7](#)
- [IPv6 Routing Protocol Operation, page 8-8](#)

Cisco Express Forwarding

A key element of NSF is packet forwarding. In a Cisco networking device, packet forwarding is provided by CEF. CEF is always enabled on the switch and cannot be disabled. CEF maintains the FIB, and uses the FIB information that was current at the time of the switchover to continue forwarding packets during a switchover. This feature reduces traffic interruption during the switchover.

During normal NSF operation, CEF on the active RP synchronizes its current FIB and adjacency databases with the FIB and adjacency databases on the standby RP. Upon switchover of the active RP, the standby RP initially has FIB and adjacency databases that are mirror images of those that were current on the active RP. For platforms with intelligent line cards, the line cards will maintain the current forwarding information over a switchover; for platforms with forwarding engines, CEF will keep the forwarding engine on the standby RP current with changes that are sent to it by CEF on the active RP. In this way, the line cards or forwarding engines will be able to continue forwarding after a switchover as soon as the interfaces and a data path are available.

As the routing protocols start to repopulate the RIB on a prefix-by-prefix basis, the updates in turn cause prefix-by-prefix updates to CEF, which it uses to update the FIB and adjacency databases. Existing and new entries will receive the new version (“epoch”) number, indicating that they have been refreshed. The forwarding information is updated on the line cards or forwarding engine during convergence. The RP signals when the RIB has converged. The software removes all FIB and adjacency entries that have an epoch older than the current switchover epoch. The FIB now represents the newest routing protocol forwarding information.

Routing Protocol Operation

The routing protocols run only on the active RP, and they receive routing updates from their neighbor routers. Routing protocols do not run on the standby RP. Following a switchover, the routing protocols request that the NSF-aware neighbor devices send state information to help rebuild the routing tables. Alternately, the IS-IS protocol can be configured to synchronize state information from the active to the standby RP to help rebuild the routing table on the NSF-capable device in environments where neighbor devices are not NSF-aware.

For NSF operation, the routing protocols depend on CEF to continue forwarding packets while the routing protocols rebuild the routing information.

BGP Operation

When a NSF-capable router begins a BGP session with a BGP peer, it sends an OPEN message to the peer. Included in the message is a declaration that the NSF-capable device has “graceful restart capability.” Graceful restart is the mechanism by which BGP routing peers avoid a routing flap following a switchover. If the BGP peer has received this capability, it is aware that the device sending the message is NSF-capable. Both the NSF-capable router and its BGP peer(s) need to exchange the graceful restart capability in their OPEN messages, at the time of session establishment. If both the peers do not exchange the graceful restart capability, the session will not be graceful restart capable.

If the BGP session is lost during the RP switchover, the NSF-aware BGP peer marks all the routes associated with the NSF-capable router as stale; however, it continues to use these routes to make forwarding decisions for a set period of time. This functionality means that no packets are lost while the newly active RP is waiting for convergence of the routing information with the BGP peers.

After an RP switchover occurs, the NSF-capable router reestablishes the session with the BGP peer. In establishing the new session, it sends a new graceful restart message that identifies the NSF-capable router as having restarted.

At this point, the routing information is exchanged between the two BGP peers. Once this exchange is complete, the NSF-capable device uses the routing information to update the RIB and the FIB with the new forwarding information. The NSF-aware device uses the network information to remove stale routes from its BGP table. Following that, the BGP protocol is fully converged.

If a BGP peer does not support the graceful restart capability, it will ignore the graceful-restart capability in an OPEN message but will establish a BGP session with the NSF-capable device. This function will allow interoperability with non-NSF-aware BGP peers (and without NSF functionality), but the BGP session with non-NSF-aware BGP peers will not be graceful restart capable.



Note

BGP support in NSF requires that neighbor networking devices be NSF-aware; that is, the devices must have the graceful restart capability and advertise that capability in their OPEN message during session establishment. If an NSF-capable router discovers that a particular BGP neighbor does not have graceful restart capability, it will not establish an NSF-capable session with that neighbor. All other neighbors that have graceful restart capability will continue to have NSF-capable sessions with this NSF-capable networking device.

EIGRP Operation

EIGRP NSF capabilities are exchanged by EIGRP peers in hello packets. The NSF-capable router notifies its neighbors that an NSF restart operation has started by setting the restart (RS) bit in a hello packet. When an NSF-aware router receives notification from an NSF-capable neighbor that an NSF-restart operation is in progress, the NSF-capable and NSF-aware routers immediately exchange their topology tables. The NSF-aware router sends an end-of-table (EOT) update packet when the transmission of its topology table is complete. The NSF-aware router then performs the following actions to assist the NSF-capable router:

- The EIGRP hello hold timer is expired to reduce the time interval set for hello packet generation and transmission. This allows the NSF-aware router to reply to the NSF-capable router more quickly reducing the amount of time required for the NSF-capable router to rediscover neighbors and rebuild the topology table.
- The route-hold timer is started. This timer is used to set the period of time that the NSF-aware router will hold known routes for the NSF-capable neighbor. This timer is configured with the **timers nsf route-hold** command. The default time period is 240 seconds.

- The NSF-aware router notes in the peer list that the NSF-capable neighbor is restarting, maintains adjacency, and holds known routes for the NSF-capable neighbor until the neighbor signals that it is ready for the NSF-aware router to send its topology table or the route-hold timer expires. If the route-hold timer expires on the NSF-aware router, the NSF-aware router will discard held routes and treat the NSF-capable router as a new router joining the network and reestablishing adjacency accordingly.
- The NSF-aware router will continue to send queries to the NSF-capable router which is still in the process of converging after switchover, effectively extending the time before a stuck-in-active (SIA) condition can occur.

When the switchover operation is complete, the NSF-capable router notifies its neighbors that it has reconverged and has received all of their topology tables by sending an EOT update packet to the assisting routers. The NSF-capable then returns to normal operation. The NSF-aware router will look for alternate paths (go active) for any routes that are not refreshed by the NSF-capable (restarting router). The NSF-aware router will then return to normal operation. If all paths are refreshed by the NSF-capable router, the NSF-aware router will immediately return to normal operation.

**Note**

NSF-aware routers are completely compatible with non-NSF aware or capable neighbors in an EIGRP network. A non-NSF aware neighbor will ignore NSF capabilities and reset adjacencies and otherwise maintain the peering sessions normally.

IS-IS Operation

The IS-IS protocol can be configured to use state information that has been synchronized between the active and the standby RP to recover route information following a switchover instead of information received from peer devices.

When an IS-IS NSF-capable router performs an RP switchover, it must perform two tasks in order to resynchronize its Link State Database with its IS-IS neighbors. First, it must relearn the available IS-IS neighbors on the network without causing a reset of the neighbor relationship. Second, it must reacquire the contents of the Link State Database for the network.

The IS-IS NSF feature offers two options when configuring NSF:

- Internet Engineering Task Force (IETF) IS-IS
- Cisco IS-IS

If neighbor routers on a network segment are NSF-aware, meaning that neighbor routers are running a software version that supports the IETF Internet draft for router restartability, they will assist an IETF NSF router which is restarting. With IETF, neighbor routers provide adjacency and link-state information to help rebuild the routing information following a switchover. A benefit of IETF IS-IS configuration is operation between peer devices based on a proposed standard.

**Note**

If you configure IETF on the networking device, but neighbor routers are not IETF-compatible, NSF will abort following a switchover.

If the neighbor routers on a network segment are not NSF-aware, you must use the Cisco configuration option. The Cisco IS-IS configuration transfers both protocol adjacency and link-state information from the active to the standby RP. A benefit of Cisco configuration is that it does not rely on NSF-aware neighbors.

IETF IS-IS Configuration

Using the IETF IS-IS configuration, as quickly as possible after an RP switchover, the NSF-capable router sends IS-IS NSF restart requests to neighboring NSF-aware devices. Neighbor networking devices recognize this restart request as a cue that the neighbor relationship with this router should not be reset, but that they should initiate database resynchronization with the restarting router. As the restarting router receives restart request responses from routers on the network, it can begin to rebuild its neighbor list.

Once this exchange is complete, the NSF-capable device uses the link-state information to remove stale routes, update the RIB, and update the FIB with the new forwarding information. IS-IS is then fully converged.

The switchover from one RP to the other happens within seconds. IS-IS reestablishes its routing table and resynchronizes with the network within a few additional seconds. At this point, IS-IS waits for a specified interval before it will attempt a second NSF restart. During this time, the new standby RP will boot up and synchronize its configuration with the active RP. The IS-IS NSF operation waits for a specified interval to ensure that connections are stable before attempting another restart of IS-IS NSF. This functionality prevents IS-IS from attempting back-to-back NSF restarts with stale information.

Cisco IS-IS Configuration

Using the Cisco configuration option, full adjacency and LSP information is saved, or “checkpointed,” to the standby RP. Following a switchover, the newly active RP maintains its adjacencies using the checkpointed data, and can quickly rebuild its routing tables.



Note

Following a switchover, Cisco IS-IS NSF has complete neighbor adjacency and LSP information; however, it must wait for all interfaces that had adjacencies prior to the switchover to come up. If an interface does not come up within the allocated interface wait time, the routes learned from these neighbor devices are not considered in routing table recalculation. IS-IS NSF provides a command to extend the wait time for interfaces that, for whatever reason, do not come up in a timely fashion.

The switchover from one RP to the other happens within seconds. IS-IS reestablishes its routing table and resynchronizes with the network within a few additional seconds. At this point, IS-IS waits for a specified interval before it will attempt a second NSF restart. During this time, the new standby RP will boot up and synchronize its configuration with the active RP. Once this synchronization is completed, IS-IS adjacency and LSP data is checkpointed to the standby RP; however, a new NSF restart will not be attempted by IS-IS until the interval time expires. This functionality prevents IS-IS from attempting back-to-back NSF restarts.

OSPF Operation

When an OSPF NSF-capable router performs an RP switchover, it must perform two tasks in order to resynchronize its Link State Database with its OSPF neighbors. First, it must relearn the available OSPF neighbors on the network without causing a reset of the neighbor relationship. Second, it must re-acquire the contents of the Link State Database for the network.

As quickly as possible after an RP switchover, the NSF-capable router sends an OSPF NSF signal to neighboring NSF-aware devices. Neighbor networking devices recognize this signal as a cue that the neighbor relationship with this router should not be reset. As the NSF-capable router receives signals from other routers on the network, it can begin to rebuild its neighbor list.

Once neighbor relationships are reestablished, the NSF-capable router begins to resynchronize its database with all of its NSF-aware neighbors. At this point, the routing information is exchanged between the OSPF neighbors. Once this exchange is complete, the NSF-capable device uses the routing information to remove stale routes, update the RIB, and update the FIB with the new forwarding information. The OSPF protocols are then fully converged.

**Note**

OSPF NSF requires that all neighbor networking devices be NSF-aware. If an NSF-capable router discovers that it has non-NSF-aware neighbors on a particular network segment, it will disable NSF capabilities for that segment. Other network segments composed entirely of NSF-capable or NSF-aware routers will continue to provide NSF capabilities.

The OSPF RFC 3623 Graceful Restart feature allows you to configure IETF NSF in multivendor networks. For more information, see the [OSPF RFC 3623 Graceful Restart](#) document.

IPv6 Routing Protocol Operation

IPv6 support for NSF includes the following features:

- [Nonstop Forwarding and Graceful Restart for MP-BGP IPv6 Address Family, page 8-8](#)
- [Nonstop Forwarding for IPv6 RIP, page 8-8](#)
- [Nonstop Forwarding for IPv6 Static Routes, page 8-8](#)

Nonstop Forwarding and Graceful Restart for MP-BGP IPv6 Address Family

The switch supports the graceful restart capability for IPv6 BGP unicast and VPNv6 address families, enabling Cisco NSF functionality for BGP IPv6. The BGP graceful restart capability allows the BGP routing table to be recovered from peers without keeping the TCP state.

NSF continues forwarding packets while routing protocols converge, therefore avoiding a route flap on switchover. Forwarding is maintained by synchronizing the FIB between the active and standby RP. On switchover, forwarding is maintained using the FIB. The RIB is not kept synchronized; therefore, the RIB is empty on switchover. The RIB is repopulated by the routing protocols and subsequently informs FIB about RIB convergence by using the NSF_RIB_CONVERGED registry call. The FIB tables are updated from the RIB, removing any stale entries. The RIB starts a failsafe timer during RP switchover, in case the routing protocols fail to notify the RIB of convergence.

The Cisco BGP address family identifier (AFI) model is modular and scalable, and supports multiple AFIs and subsequent address family identifier (SAFI) configurations.

For information about how to configure the IPv6 BGP graceful restart capability, see the “[Implementing Multiprotocol BGP for IPv6](#)” document.

Nonstop Forwarding for IPv6 RIP

RIP registers as an IPv6 NSF client. Doing so has the benefit of using RIP routes installed in the Cisco Express Forwarding table until RIP has converged on the standby.

Nonstop Forwarding for IPv6 Static Routes

Cisco NSF supports IPv6 static routes.

Default Settings for NSF

None.

How to Configure NSF

- [Configuring and Verifying BGP for NSF, page 8-9](#) (optional)
- [Configuring and Verifying EIGRP NSF, page 8-10](#) (optional)
- [Configuring and Verifying OSPF NSF, page 8-12](#) (optional)
- [Configuring and Verifying IS-IS NSF, page 8-13](#) (optional)
- [Troubleshooting Cisco Nonstop Forwarding, page 8-14](#) (optional)

Configuring and Verifying BGP for NSF

- [Configuring BGP for NSF, page 8-9](#)
- [Verifying NSF for BGP, page 8-10](#)

Configuring BGP for NSF

Perform this task to configure BGP for NSF. Repeat this task on each BGP NSF peer device:

	Command	Purpose
Step 1	Tqwvgt@ gpcdng "	Enables privileged EXEC mode (enter your password if prompted).
Step 2	Tqwvgt%" eqphkiwtg "vgtokpcn"	Enters global configuration mode.
Step 3	Tqwvgt*eqphki+% tqwvgt "dir" <i>autonomous-system-number</i> "	Enables a BGP routing process, and enters router configuration mode.
Step 4	Tqwvgt*eqphki/tqwvgt+% dir "itceghwn/tguvctv"]tguvctv/vkog" <i>ugeqpfu</i> "~" uvcngrcvj / vkog " <i>ugeqpfu</i> _"	Enables the BGP graceful restart capability, which starts NSF for BGP.

This example shows how to configure BGP for NSF:

```
Tqwvgt@"gpcdng"
Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+%tqwvgt"dir"342"
Tqwvgt*eqphki/tqwvgt+%dir"itceghwn/tguvctv"
```

Verifying NSF for BGP

Perform this task to verify that the graceful restart function is configured on the SSO-enabled networking device and on the neighbor devices:

	Command	Purpose
Step 1	Tqwgvt@ gpcdng"	Enables privileged EXEC mode (enter your password if prompted).
Step 2	Tqwgvt% "ujqy"twppkpi/eqphki"	Displays the contents of the current running configuration file. Verify that the phrase "bgp graceful-restart" appears in the BGP configuration of the SSO-enabled router. Repeat this step on each of the BGP neighbors.
Step 3	Tqwgvt% "ujqy"kr"dir"pgkijdtu"] ip-address"] cfxgtvkugf/tqwgvtu"~"fcorgpgf/tqwgvtu"~"hncr/uvckuvkeu" ~"rcvju"] reg-exp_ " ~ "tgegkxgf"rtghkz/hknvgt " ~ " tgegkxgf/tqwgvtu" ~ "tqwgvtu" ~ "rqnke{ "] fgvcnk_ "	Displays information about BGP and TCP connections to neighbors. On the SSO device and the neighbor device, this command verifies that the graceful restart function is shown as both advertised and received, and confirms the address families that have the graceful restart capability. If no address families are listed, then BGP NSF also will not occur.

This example shows how to NSF for BGP:

```
Tqwgvt@"gpcdng"
Tqwgvt%"eqphkiwtg"vgtokpcn"
Tqwgvt%"ujqy"twppkpi/eqphki"
Tqwgvt%"ujqy"kr"dir"pgkijdtu"
```

Configuring and Verifying EIGRP NSF

- [Configuring EIGRP for NSF, page 8-10](#)
- [Verifying EIGRP for NSF, page 8-11](#)

Configuring EIGRP for NSF



Note

- An NSF-aware router must be completely converged with the network before it can assist an NSF-capable router in an NSF restart operation.
- Distributed platforms that run a supporting version of Cisco IOS software can support full NSF capabilities. These routers can perform a restart operation and can support other NSF capable peers.
- Single processor platforms that run a supporting version of Cisco IOS software support only NSF awareness. These routers maintain adjacency and hold known routes for the NSF-capable neighbor until it signals that it is ready for the NSF-aware router to send its topology table or the route-hold timer expires.

Perform this task to configure EIGRP for NSF. Repeat this procedure on each EIGRP NSF peer device:

	Command	Purpose
Step 1	Tqvwgt@ gpdcng "	Enables privileged EXEC mode (enter your password if prompted).
Step 2	Tqvwgt% eqphkiwtg "vgtokpcn"	Enters global configuration mode.
Step 3	Tqvwgt*eqphki+% tqvwgt "gkitr" <i>as-number</i> "	Enables an EIGRP routing process, and enters router configuration mode.
Step 4	Tqvwgt*eqphki/tqvwgt+% puh] } ekueq "~"kgvh; "~"kpvgthceg yckv "ugeqpfu"~"kpvgtxcn" <i>minutes</i> ~"v5"] cflcegpe { "~" ocpwc "ugeqpfu_"	(Optional) Enables EIGRP NSF support on an NSF capable router. Enter this command on only NSF-capable routers. NSF awareness is enabled by default when a supporting version of Cisco IOS software is installed on a router that supports NSF capability or NSF awareness.
Step 5	Tqvwgt*eqphki/tqvwgt+% vkogtu "puh" eqpxgtig "ugeqpfu	Adjusts the maximum time that restarting router will wait for the EOT notification from an NSF-capable or NSF-aware peer.
Step 6	Tqvwgt*eqphki/tqvwgt+% vkogtu "puh" tqwvg/jqnf "ugeqpfu"	Sets the route-hold timer to determine how long an NSF-aware router that is running EIGRP will hold routes for an inactive peer.
Step 7	Tqvwgt*eqphki/tqvwgt+% vkogtu "puh" ukipcn "ugeqpfu"	Adjusts the maximum time for the initial restart period.

This example shows how to configure EIGRP for NSF:

```
Tqvwgt@"gpdcng"
Tqvwgt%"eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+%tqvwgt"gkitr"32;"
Tqvwgt*eqphki/tqvwgt+%puh"
Tqvwgt*eqphki/tqvwgt+%vkogtu"puh"eqpxgtig"82"
Tqvwgt*eqphki/tqvwgt+%vkogtu"puh"tqwvg/jqnf"342"
Tqvwgt*eqphki/tqvwgt+%vkogtu"puh"ukipcn"ugeqpfu"
```

Verifying EIGRP for NSF

Perform this task to verify that NSF awareness or capability or both are enabled on the SSO-enabled networking device and on the neighbor devices.

	Command	Purpose
Step 1	Tqvwgt@ gpdcng "	Enables privileged EXEC mode (enter your password if prompted).
Step 2	Tqvwgt%" ujqy "kr" rtqvqegnu "	Displays the parameters and current state of the active routing protocol process. Repeat this step on each of the EIGRP neighbors.

This example shows how to verify EIGRP for NSF:

```
Tqvwgt@"gpdcng"
Tqvwgt%"ujqy"kr"rtqvqegnu"
```

Configuring and Verifying OSPF NSF

- [Configuring OSPF for NSF, page 8-12](#)
- [Verifying OSPF for NSF, page 8-12](#)

Configuring OSPF for NSF


Note

All peer devices participating in OSPF NSF must be made OSPF NSF aware; NSF awareness is enabled by default when a supporting version of Cisco IOS software is installed on a router that supports NSF capability or NSF awareness.

Perform this task to configure OSPF for NSF:

	Command	Purpose
Step 1	Tqwvgt@ gpcdng "	Enables privileged EXEC mode (enter your password if prompted).
Step 2	Tqwvgt%" eqphkiwtg " vgtokpcn "	Enters global configuration mode.
Step 3	Tqwvgt*eqphki+% "tqwvgt"qurh " <i>process-id</i>] xth " <i>vpn-name</i> _"	Enables an OSPF routing process, and places the router in router configuration mode.
Step 4	Tqwvgt*eqphki/tqwvgt+% puh "} ekueq "~" kgvh "; "~" kpvgthceg yckv " <i>ugeqpfu</i> "~" kpvgtxcn " <i>minutes</i> ~" v5 "] cflcegpe {"~" ocpwc n" <i>ugeqpfu</i> _"	Enables EIGRP NSF support on an NSF capable router. • Enter this command on NSF-capable routers only.

This example shows how to configure OSPF for NSF:

```
Tqwvgt@"gpcdng"
Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+%"tqwvgt"qurh"34"
```

Verifying OSPF for NSF

Perform this task to verify OSPF for NSF:

	Command	Purpose
Step 1	Tqwvgt@ gpcdng "	Enables privileged EXEC mode (enter your password if prompted).
Step 2	Tqwvgt%" ujqy " kr " qurh "] <i>process-id</i> _	Displays general information about OSPF routing processes.

This example shows how to verify OSPF for NSF:

```
Tqwvgt@"gpcdng"
Tqwvgt%"ujqy"kr"qurh"
```

Configuring and Verifying IS-IS NSF

- [Configuring NSF for IS-IS, page 8-13](#)
- [Verifying NSF for IS-IS, page 8-14](#)

Configuring NSF for IS-IS

Perform this task to configure NSF for IS-IS:

	Command	Purpose
Step 1	Tqwvgt@ gpcdng "	Enables privileged EXEC mode (enter your password if prompted).
Step 2	Tqwvgt% "eqphkiwtg"vgtokpcn "	Enters global configuration mode.
Step 3	Tqwvgt*eqphki+% "tqwvgt"kuku"area-tag "	Enables the IS-IS routing protocol to specify an IS-IS process, and places the router in router configuration mode.
Step 4	Tqwvgt*eqphki/tqwvgt+% "puh"] } ekueq"~"kgvh; "~"kpvgtthceg yckv"seconds ~"kpvgtxcn minutes ~"v5"] cflcegepe{ "~"ocpwcnugeqpfu_ "	Enables NSF operation for IS-IS. • ietf—Enables IS-IS in homogeneous network where adjacencies with networking devices supporting IETF draft-based restartability is guaranteed. • cisco—Runs IS-IS in heterogeneous networks that might not have adjacencies with NSF-aware networking devices.
Step 5	Tqwvgt*eqphki/tqwvgt+% "puh kpvgtxcn okpwwgu "	Configures the minimum time between Cisco NSF restart attempts.
Step 6	Tqwvgt*eqphki/tqwvgt+% "puh v5" } ocpwcnu seconds ~ cflcegepe{ ; "	Specifies the methodology used to determine how long IETF Cisco NSF will wait for the link-state packet (LSP) database to synchronize before generating overloaded link-state information for itself and flooding that information out to its neighbors.
Step 7	Tqwvgt*eqphki/tqwvgt+% "puh kpvgtthceg"yckv ugeqpfu "	Specifies how long a Cisco NSF restart will wait for all interfaces with IS-IS adjacencies to come up before completing the restart.

This example shows how to configure NSF for IS-IS:

```
Tqwvgt@"gpcdng"
Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+%tqwvgt"kuku"ekueq3
Tqwvgt*eqphki/tqwvgt+%puh"kgvh
Tqwvgt*eqphki/tqwvgt+%puh"kpvgtxcn"4
Tqwvgt*eqphki/tqwvgt+%puh"v5"ocpwcnu"62
Tqwvgt*eqphki/tqwvgt+%puh"kpvgtthceg"yckv"37
```

Verifying NSF for IS-IS

Perform this task to verify NSF for IS-IS:

	Command	Purpose
Step 1	Tqwvgt@ gpcdng"	Enables privileged EXEC mode (enter your password if prompted).
Step 2	Tqwvgt%"ujqy"twppkpi/eqphki"	Displays the contents of the current running configuration file.
Step 3	Tqwvgt%"ujqy"kuku"puh"	Displays current state information regarding IS-IS NSF.

This example shows how to verify NSF for IS-IS:

```
Tqwvgt@"gpcdng"
Tqwvgt%"ujqy"twppkpi/eqphki"
Tqwvgt%"ujqy"kuku"puh"
```

Troubleshooting Cisco Nonstop Forwarding

To troubleshoot Cisco Nonstop Forwarding, use the following commands as needed:

Command	Purpose
Tqwvgt%"fgdwi"gkitr"puh"	Displays notifications and information about NSF events for an EIGRP routing process.
Tqwvgt%"fgdwi"kr"gkitr"pqvkhkecvkqpu"	Displays information and notifications for an EIGRP routing process. This output includes NSF notifications and events.
Tqwvgt%"fgdwi"kuku"puh"] fgvckn_ "	Displays information about the IS-IS state during a Cisco NSF restart.
Tqwvgt%"fgdwi"qurh"puh"] fgvckn_ "	Displays debugging messages related to OSPF Cisco NSF commands.
Tqwvgt%"ujqy"egh"puh"	Displays the current NSF state of CEF on both the active and standby RPs.
Tqwvgt%"ujqy"egh"uvcvg"	Displays the CEF state on a networking device.
Tqwvgt%"ujqy"enpu"pgkijdtu"	Display both end-system and intermediate system neighbors.
Tqwvgt%"ujqy"kr"dir"	Displays entries in the BGP routing table.
Tqwvgt%"ujqy"kr"dir"pgkijdtu"	Displays information about the TCP and BGP connections to neighbor devices.\
Tqwvgt%"ujqy"kr"egh"	Displays entries in the FIB that are unresolved, or displays a FIB summary.
Tqwvgt%"ujqy"kr"gkitr"pgkijdtu"] interface-type ~" as-number ~"uvcvke" ~" fgvckn_ "	To display detailed information about neighbors discovered by EIGRP.
Tqwvgt%"ujqy"kr"qurh"	Displays general information about OSPF routing processes.
Tqwvgt%"ujqy"kr"qurh"pgkijdtu"] fgvckn_ "	Displays OSPF-neighbor information on a per-interface basis.

Command	Purpose
<code>Tqvwgt% "ujqy"kr"rtqvqeqnu"</code>	Displays the parameters and current state of the active routing protocol process. The status of EIGRP NSF configuration and support is displayed in the output.
<code>Tqvwgt% "ujqy"kuku"fcvedcug"] fgvcckn_</code>	Displays the IS-IS link-state database.
<code>Tqvwgt% "ujqy"kuku"puh"</code>	Displays the current state information regarding IS-IS Cisco NSF.

Configuration Examples for NSF

- [Example: Configuring BGP NSF, page 8-15](#)
- [Example: Configuring BGP NSF Neighbor Device, page 8-15](#)
- [Example: Verifying BGP NSF, page 8-16](#)
- [Example: Configuring EIGRP NSF Converge Timer, page 8-16](#)
- [Example: EIGRP Graceful-Restart Purge-Time Timer Configuration, page 8-16](#)
- [Example: Configuring EIGRP NSF Route-Hold Timer, page 8-17](#)
- [Example: Configuring EIGRP NSF Signal Timer, page 8-17](#)
- [Example: Disabling EIGRP NSF Support, page 8-18](#)
- [Example: Verifying EIGRP NSF, page 8-17](#)
- [Example: Configuring OSPF NSF, page 8-18](#)
- [Example: Verifying OSPF NSF, page 8-18](#)
- [Example: Configuring IS-IS NSF, page 8-19](#)
- [Example: Verifying IS-IS NSF, page 8-19](#)

Example: Configuring BGP NSF

The following example shows how to configure BGP NSF on a networking device.

```
Tqvwgt% "eqphkiwtg"vgtokpcn
Tqvwgt*eqphki+% "tqvwgt"dir"7;2
Tqvwgt*eqphki/tqvwgt+% "dir"itceghwn/tguvctv
```

Example: Configuring BGP NSF Neighbor Device

The following example shows how to configure BGP NSF on a neighbor router. All devices supporting BGP NSF must be NSF-aware, meaning that these devices recognize and advertise graceful restart capability.

```
Tqvwgt% "eqphkiwtg"vgtokpcn
Tqvwgt*eqphki+% "tqvwgt"dir"992
Tqvwgt*eqphki/tqvwgt+% "dir"itceghwn/tguvctv
```

Example: Verifying BGP NSF

Verify that “bgp graceful-restart” appears in the BGP configuration of the SSO-enabled router by entering the **show running-config** command.

```
Tqwgvt% "ujgy"twppkpi/eqphki

tqwgvt"dir"342
dir"itceghwn/tguvctv
"pgkijdt"32040404"tgoqvg/cu"522
```

On the SSO device and the neighbor device, verify that the graceful restart function is shown as both advertised and received, and confirm the address families that have the graceful restart capability. If no address families are listed, then BGP NSF also will not occur.

```
Tqwgvt%  ujgy"kr"dir"pgkijdtu"z0z0z0z

DIR"pgkijdt"ku"3;4038:0404."tgoqvg"CU"[[."gzvgtpcn"nkpm
"DIR"xgtukqp"6."tgoqvg"tqwgvt"KF"3;4038:0404
"DIR"uvvvg"? "Guvcdnkujgf."wr"hqt"22<23<3:
"Ncuvt"tgcf"22<22<39."jqnf"vkog"ku"3:2."mggrenkxg"kpvgtxcn"ku"82"ugeqpfu
"Pgkijdt"ecrcdknkvgu<
" " "Tqwgvt"tghtguj<cfxgtvkugf"cpf"tgegkxgf*pgy+
Cfftguu"hcokn{"KRx6"Wpkecuv<cfxgtvkugf"cpf"tgegkxgf
" " "Cfftguu"hcokn{"KRx6"Ownvkecuv<cfxgtvkugf"cpf"tgegkxgf
" " "Itceghwn"Tguvctv"Ecrcdknv{<cfxgtvkugf"cpf"tgegkxgf
" " " "Tgoqvg"Tguvctv"vkogt"ku"342"ugeqpfu
" " " "Cfftguu"hcoknkgu"rtgugtugf"d{"rggt<
" " " " "KRx6"Wpkecuv."KRx6"Ownvkecuv
" "Tgegkxgf"375;"oguucigu."2"pqvkhkecvkqpu."2"kp"swgwg
" "Ugppv"3766"oguucigu."2"pqvkhkecvkqpu."2"kp"swgwg
" "Fghcwnv"okpkowo"vkog"dgvyggp"cfxgtvkugogppv"twpv"ku"52"ugeqpfu
```

Example: Configuring EIGRP NSF Converge Timer

The **timers nsf converge** command is used to adjust the maximum time that a restarting router will wait for the EOT notification from an NSF-capable or NSF-aware peer. The following example shows how to set the converge timer to one minute.

```
Tqwgvt% eqphkiwtg"vgtokpcn
Tqwgvt*eqphki+% tqwgvt"gkitr"323"
Tqwgvt*eqphki/tqwgvt+% vkogtu"puh"eqpxgtig"82
```

Example: EIGRP Graceful-Restart Purge-Time Timer Configuration

The **timers graceful-restart purge-time** command is used to set the route-hold timer that determines how long an NSF-aware router that is running EIGRP will hold routes for an inactive peer. The following example shows how to set the route-hold timer to two minutes:

```
Tqwgvt*eqphki/tqwgvt+% vkogtu"itceghwn/tguvctv"rwtig/vkog"342
```

Example: Configuring EIGRP NSF Route-Hold Timer

The **timers nsf route-hold** command is used to set the maximum period of time that an NSF-aware router will hold known routes for an NSF-capable neighbor during a switchover operation. The following example shows how to set the route-hold timer to two minutes.

```
Tqwvgt% eqphkiwtg"vgtokpcn
Tqwvgt*eqphki+% tqwvgt"gkitr"323"
Tqwvgt*eqphki/tqwvgt+% vkogtu"puh"tqwvg/jqnf"342
```

Example: Configuring EIGRP NSF Signal Timer

The **timers nsf signal** command is used to adjust the maximum time for the initial restart period. The following example shows how to set the signal timer to 10 seconds.

```
Tqwvgt% eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+% tqwvgt"gkitr"323"
Tqwvgt*eqphki/tqwvgt+% vkogtu"puh"ukipcn"32"
```

Example: Verifying EIGRP NSF

Verify that EIGRP NSF support is present in the installed Cisco IOS software image by entering the **show ip protocols** command. “EIGRP NSF-aware route hold timer is...” is displayed in the output when either NSF awareness or capability is supported. This line displays the default or user-defined value for the route-hold timer. “EIGRP NSF...” is displayed in the output only when the NSF capability is supported. This line will also print “disabled” or “enabled” depending on the status of the EIGRP NSF feature.

```
Tqwvgt% ujgy"kr"rtqvgegnu"

Tqwvkpi"Rtqvgegn"ku"$gkitr"322$
"Qwviqkpi"wrfcvg"hknvgt"nkuv"hqt"cnk"kpvgthcegu"ku"pqv"ugv
"Kpegokpi"wrfcvg"hknvgt"nkuv"hqt"cnk"kpvgthcegu"ku"pqv"ugv
"Fghcwnv"pgvyqtmu"hnciigf"kp"qvwikpi"wrfcvgu
"Fghcwnv"pgvyqtmu"ceegrvgf"htqo"kpegokpi"wrfcvgu
"GKITR"ogvtke"ygkijv"M3?3."M4?2."M5?3."M6?2."M7?2
"GKITR"oczkwow"jgreqwpv"322
"GKITR"oczkwow"ogvtke"xctkcpeg"3
"Tgfkuvtkdwvkpi<"gkitr"322
"GKITR"PUH/cyctg"tqwvg"jqnf"vkogt"ku"462u"
"GKITR"PUH"gpdcngf"
" " " "PUH"ukipcn"vkogt"ku"42u"
" " " "PUH"eqpxgtig"vkogt"ku"342u"
"Cwvqocvke"pgvyqtm"uwoock|cvkqp"ku"kp"ghhgev
"Oczkwow"rcvj<"6
"Tqwvkpi"htq"Pgvyqtmu<
" " "32060;02146
"Tqwvkpi"Kphqtocvkqp"Uqwtegu<
" " "Icvgyc{ " " " " "Fkuvcepg" " " " "Ncuw"Wrfcvg
"Fkuvcepg<"kpvgtpcn";2"gzvgtpcn"392
```

Example: Disabling EIGRP NSF Support

EIGRP NSF capability is enabled by default on distributed platforms that run a supporting version of Cisco IOS software. The **nsf** command used to enable or disable the EIGRP NSF capability. The following example shows how to disable NSF capability:

```
Tqwgvt% eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+% tqwgvt"gkitr"323"
Tqwgvt*eqphki/tqwgvt+% pq"puh"
```

Example: Configuring OSPF NSF

The following example shows how to configure OSPF NSF on a networking device:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+% "tqwgvt"qurh"622"
Tqwgvt*eqphki/tqwgvt+% "puh"
```

Example: Verifying OSPF NSF

To verify NSF for OSPF, you must check that the NSF function is configured on the SSO-enabled networking device. Verify that “nsf” appears in the OSPF configuration of the SSO-enabled device by entering the **show running-config** command:

```
Tqwgvt%"ujqy"twppkpi/eqphki"

tqwgvt"qurh"342
nqi/cflcegepe{/ejcpigu
puh
pgvyqtm"3;4038:04202"202020477"ctgc"2
pgvyqtm"3;4038:05202"202020477"ctgc"3"
pgvyqtm"3;4038:06202"202020477"ctgc"4"
```

Next, use the **show ip ospf** command to verify that NSF is enabled on the device.

```
Tqwgvt@"ujqy"kr"qurh"

Tqgwvkpi"Rtqeguu"$qurh"3$"ykvj"KF"3;4038:0403"cpf"Fqockp"KF"2020203
Uwrrqtvu"qpn{"ukping"VQU*VQU2+"tqwgvtu
Uwrrqtvu"qrcswg"NUC
URH"uejgfwng"fgnc{"7"ugeu."Jqnf"vkog"dgvyggp"vyq"URHu"32"ugeu
Okpkowo"NUC"kpvgtxcn"7"ugeu0"Okpkowo"NUC"cttkxcn"3"ugeu
Pwodgt"qh"gzvgtpcn"NUC"20"Ejgemuwo"Uwo"2z2
Pwodgt"qh"qrcswg"CU"NUC"20"Ejgemuwo"Uwo"2z2
Pwodgt"qh"FEdkvnguu"gzvgtpcn"cpf"qrcswg"CU"NUC"2
Pwodgt"qh"FqPqVCig"gzvgtpcn"cpf"qrcswg"CU"NUC"2
Pwodgt"qh"ctgcu"kp"vjku"tqwgvt"ku"30"3"pqtoen"2"uvwd"2"puuc
Gzvgtpcn"hnqqf"nkuv"ngpi"vj"2
Pqp/Uvqr"Hqtyctfkpi"gpdcngf."ncuv"PUH"tguvctv"22<24<28"ciq"*vqqm"66"ugeu+
Ctgc"DCEMDQPG*2+
Pwodgt"qh"kpvgthcegu"kp"vjku"ctgc"ku"3"*2"nqqrdecem+
"Ctgc"jcu"pq"cwvjgpvkecvkqp
"URH"cnigtkvjo"gzgewvgf"5"vkogu
```

Example: Configuring IS-IS NSF

The following example shows how to configure Cisco proprietary IS-IS NSF operation on a networking device:

```
Tqvwgt% "eqphkiwtg"vgtokpcn
Tqvwgt *eqphki+% "tqvwgt" "kuku"
Tqvwgt *eqphki/tqvwgt+% "puh"ekueq
```

The following example shows how to configure IS-IS NSF for IETF operation on a networking device:

```
Tqvwgt% "eqphkiwtg"vgtokpcn
Tqvwgt *eqphki+% "tqvwgt" "kuku"
Tqvwgt *eqphki/tqvwgt+% "puh"kgvh
```

Example: Verifying IS-IS NSF

Verify that NSF appears in the IS-IS configuration of the SSO-enabled device by entering the **show running-config** command. The display will show either Cisco IS-IS or IETF IS-IS configuration. The following example indicates that the device uses the Cisco implementation of IS-IS NSF:

```
Tqvwgt% "ujqy"twppkpi/eqphki"
tqvwgt "kuku"
puh"ekueq
```

If the NSF configuration is set to **cisco**, use the **show isis nsf** command to verify that NSF is enabled on the device. Using the Cisco configuration, the display output will be different on the active and standby RPs. The following example shows output for the Cisco configuration on the active RP. In this example, note the presence of the phrase “NSF restart enabled”:

```
Tqvwgt% "ujqy" "kuku" "puh"
PUH"ku"GPCDNGF. "oqfg") ekueq)
TR"ku"CEVKXG. "uvcvfd{ "tgc{f{ . "dwnm"u{pe"eqorngvg
PUH"kpvgtxcn"vkogt "gzrktgf" *PUH"tguvctv"gpcdngf+
Ejgemrqpvpkpi "gpcdngf. "pq"gttqtu
Nqecn"uvcvg<CEVKXG. " "Rggt"uvcvg<UVCPPFD [ "JQV. " "Oqfg<UUQ
```

The following example shows sample output for the Cisco configuration on the standby RP. In this example, note the presence of the phrase “NSF restart enabled”:

```
Tqvwgt% "ujqy" "kuku" "puh"
PUH"gpcdngf. "oqfg") ekueq)
TR"ku"UVCPPFD [ . "ejmrv"oui "tgegkxg"eqwpv<CFL"4. "NUR"9
PUH"kpvgtxcn"vkogt "pqvkhkecvkqp"tgegkxgf" *PUH"tguvctv"gpcdngf+
Ejgemrqpvpkpi "gpcdngf. "pq"gttqtu
Nqecn"uvcvg<UVCPPFD [ "JQV. " "Rggt"uvcvg<CEVKXG. " "Oqfg<UUQ
```

The following example shows sample output for the IETF IS-IS configuration on the networking device:

```
Tqvwgt% "ujqy" "kuku" "puh"
PUH"ku"GPCDNGF. "oqfg" KGVH"
PUH"rfd"uvcvg<Kpcevkg
PUH"N3"cevkg"kpvgthcegu<2
PUH"N3"cevkg"NURu<2
PUH"kpvgthcegu"cyckvkpi "N3" EUPR<2
Cyckvkpi "N3" NURu<
```

```

PUH"N4"cevkgxg"kpvgthcegu<2
PUH"N4"cevkgxg"NURu<2
PUH"kpvgthcegu"cyckvkpi"N4"EUPR<2
Cyckvkpi"N4"NURu<
Kpvgthcegu<Ugtkcn51214
" " " "PUH"N3"Tguvctv"uvcvg<Twppkpi
" " " "PUH"r4r"Tguvctv"tgvtcpuokuukqpu<2
" " " "Oczkowo"N3"PUH"Tguvctv"tgvtcpuokuukqpu<5
" " " "N3"PUH"CEM"tgswguvvf<HCNUG
" " " "N3"PUH"EUPR"tgswguvvf<HCNUG
" " " "PUH"N4"Tguvctv"uvcvg<Twppkpi
" " " "PUH"r4r"Tguvctv"tgvtcpuokuukqpu<2
" " " "Oczkowo"N4"PUH"Tguvctv"tgvtcpuokuukqpu<5
" " " "N4"PUH"CEM"tgswguvvf<HCNUG
Kpvgthcegu<IkicdkvGvjgtpgv41212
" " " "PUH"N3"Tguvctv"uvcvg<Twppkpi
" " " "PUH"N3"Tguvctv"tgvtcpuokuukqpu<2
" " " "Oczkowo"N3"PUH"Tguvctv"tgvtcpuokuukqpu<5
" " " "N3"PUH"CEM"tgswguvvf<HCNUG
" " " "N3"PUH"EUPR"tgswguvvf<HCNUG
" " " "PUH"N4"Tguvctv"uvcvg<Twppkpi
" " " "PUH"N4"Tguvctv"tgvtcpuokuukqpu<2
" " " "Oczkowo"N4"PUH"Tguvctv"tgvtcpuokuukqpu<5
" " " "N4"PUH"CEM"tgswguvvf<HCNUG
" " " "N4"PUH"EUPR"tgswguvvf<HCNUG
Kpvgthcegu<Nqqrdecem3
" " " "PUH"N3"Tguvctv"uvcvg<Twppkpi
" " " "PUH"N3"Tguvctv"tgvtcpuokuukqpu<2
" " " "Oczkowo"N3"PUH"Tguvctv"tgvtcpuokuukqpu<5
" " " "N3"PUH"CEM"tgswguvvf<HCNUG
" " " "N3"PUH"EUPR"tgswguvvf<HCNUG
" " " "PUH"N4"Tguvctv"uvcvg<Twppkpi
" " " "PUH"N4"Tguvctv"tgvtcpuokuukqpu<2
" " " "Oczkowo"N4"PUH"Tguvctv"tgvtcpuokuukqpu<5
" " " "N4"PUH"CEM"tgswguvvf<HCNUG
" " " "N4"PUH"EUPR"tgswguvvf<HCNUG

```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Route Processor Redundancy (RPR)

- [Prerequisites for RPR, page 9-1](#)
- [Restrictions for RPR, page 9-1](#)
- [Information About RPR, page 9-2](#)
- [Default Settings for RPR, page 9-4](#)
- [How to Configure RPR, page 9-4](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- In route processor redundancy (RPR) redundancy mode, the ports on a supervisor engine in standby mode are disabled.
- RPR supports IPv6 multicast traffic.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for RPR

None.

Restrictions for RPR

- [General RPR Restrictions, page 9-2](#)

- [Hardware Restrictions for RPR, page 9-2](#)

General RPR Restrictions

- When a redundant supervisor engine is in standby mode, the two Gigabit Ethernet interfaces on the standby supervisor engine are always active.
- Supervisor engine redundancy does not provide supervisor engine mirroring or supervisor engine load balancing. Only one supervisor engine is active.
- Configuration changes made through SNMP are not synchronized to the standby supervisor engine. After you configure the switch through SNMP, copy the running-config file to the startup-config file on the active supervisor engine to trigger synchronization of the startup-config file on the standby supervisor engine.
- Supervisor engine switchover takes place after the failed supervisor engine completes a core dump. A core dump can take up to 15 minutes. To get faster switchover time, disable core dump on the supervisor engines.
- You cannot perform configuration changes during the startup (bulk) synchronization. If you attempt to make configuration changes during this process, the following message is generated:

```
Eqphki "oqfg"nqemgf "qvv"vknn"uvcpdf{"kpkvkonk|gu
```
- If configuration changes occur at the same time as a supervisor engine switchover, these configuration changes are lost.

Hardware Restrictions for RPR

- Cisco IOS supports redundant configurations where the supervisor engines are identical. If they are not identical, one will boot first and become active and hold the other supervisor engine in a reset condition.
- Each supervisor engine must have the resources to run the switch on its own, which means all supervisor engine resources are duplicated, including all flash devices.
- Make separate console connections to each supervisor engine. Do not connect a Y cable to the console ports.
- Except during an FSU, both supervisor engines must have the same system image (see the [“Copying Files to the RP” section on page 9-5](#)).
- The configuration register must be set to 0x2102 (`eqphki/tgikuvgt"2z4324`).



Note

There is no support for booting from the network.

Information About RPR

- [Supervisor Engine Redundancy Overview, page 9-3](#)
- [RPR Operation, page 9-3](#)
- [Supervisor Engine Configuration Synchronization, page 9-4](#)

Supervisor Engine Redundancy Overview

The switch supports fault resistance by allowing a standby supervisor engine to take over if the primary supervisor engine fails. RPR supports a switchover time of 2 or more minutes.

The following events cause a switchover:

- A hardware failure on the active supervisor engine
- Clock synchronization failure between supervisor engines
- A manual switchover

RPR Operation

RPR supports the following features:

- Auto-startup and bootvar synchronization between active and standby supervisor engines
- Hardware signals that detect and decide the active or standby status of supervisor engines
- Clock synchronization every 60 seconds from the active to the standby supervisor engine
- A standby supervisor engine that is booted but not all subsystems are up: if the active supervisor engine fails, the standby supervisor engine become fully operational
- An operational supervisor engine present in place of the failed unit becomes the standby supervisor engine
- Support for fast software upgrade (FSU) (see [Chapter 6, “Fast Software Upgrade”](#).)

When the switch is powered on, RPR runs between the two supervisor engines. The supervisor engine that boots first becomes the RPR active supervisor engine. The route processor (RP) and Policy Feature Card (PFC) become fully operational. The RP and PFC on the standby supervisor engine come out of reset but are not operational.

In a switchover, the standby supervisor engine become fully operational and the following occurs:

- All switching modules power up again
- Remaining subsystems on the RP (including Layer 2 and Layer 3 protocols) are brought up
- Access control lists (ACLs) are reprogrammed into supervisor engine hardware



Note

In a switchover, there is a disruption of traffic because some address states are lost and then restored after they are dynamically redetermined.

Supervisor Engine Configuration Synchronization



Note

Configuration changes made through SNMP are not synchronized to the standby supervisor engine. After you configure the switch through SNMP, copy the running-config file to the startup-config file on the active supervisor engine to trigger synchronization of the startup-config file on the standby supervisor engine.

During RPR mode operation, the startup-config files and the config-register configurations are synchronized by default between the two supervisor engines. In a switchover, the new active supervisor engine uses the current configuration.

Default Settings for RPR

None.

How to Configure RPR

- [Synchronizing the Supervisor Engine Configurations, page 9-4](#)
- [Displaying the Redundancy States, page 9-4](#)
- [Copying Files to the RP, page 9-5](#)

Synchronizing the Supervisor Engine Configurations

During normal operation, the startup-config and config-registers configuration are synchronized by default between the two supervisor engines. In a switchover, the new active supervisor engine uses the current configuration.



Note

Do not change the default auto-sync configuration.

Displaying the Redundancy States

To display the redundancy states, perform this task:

Command	Purpose
<code>Tqwgvt% "ujqy"tgfwpfcp{ "uvcvgu"</code>	Displays the redundancy states.

This example shows how to display the redundancy states:

```
Tqwgvt% "ujqy"tgfwpfcp{ "uvcvgu"
o{ "uvcvg"? "35"/CEVKXG
" "" "rggt "uvcvg"? " " /UVCDFD [ "JQV
" "" "" "" "Oqfg"? "Fwngz
" "" "" "" "Wpkv"? "Rtkoct {
```




Interface Configuration

- [Information About Interface Configuration, page 10-2](#)
- [How to Configure a Range of Interfaces, page 10-2](#)
- [How to Define and Use Interface-Range Macros, page 10-2](#)
- [How to Configure Optional Interface Features, page 10-3](#)
- [Information About Online Insertion and Removal, page 10-11](#)
- [How to Monitor and Maintain Interfaces, page 10-11](#)
- [How to Check Cable Status with the TDR, page 10-14](#)
- [How to Convert Line Card to Operate in 40G Mode, page 10-14](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Information About Interface Configuration

Many features in the software are enabled on a per-interface basis. When you enter the **interface** command, you must specify the following information:

- Interface type:
 - Fast Ethernet (use the **fastethernet** keyword)
 - Gigabit Ethernet (use the **gigabitethernet** keyword)
 - 10-Gigabit Ethernet (use the **tengigabitethernet** keyword)
 - 40-Gigabit Ethernet (use the **fortygigabitethernet** keyword)
- Slot number—The slot in which the module is installed. On switches supported by Cisco IOS Release 15.4SY, slots are numbered starting with 1 from top to bottom.
- Port number—The physical port number on the module. On switches supported by Cisco IOS Release 15.4SY, the port numbers always begin with 1. When facing the rear of the switch, ports are numbered from the left to the right.

You can identify ports from the physical location. You also can use **show** commands to display information about a specific port, or all the ports.

See this document for information about the **interface** command:

<http://www.cisco.com/en/US/docs/ios-xml/ios/interface/command/ir-il.html#GUID-0D6BDFCD-3FBB-4D26-A274-C1221F8592DF>

How to Configure a Range of Interfaces

The interface-range configuration mode allows you to configure multiple interfaces with the same configuration parameters. After you enter the interface-range configuration mode, all command parameters you enter are attributed to all interfaces within that range until you exit out of the interface-range configuration mode. See this document for information about the **interface range** command:

<http://www.cisco.com/en/US/docs/ios-xml/ios/interface/command/ir-il.html#GUID-8EC4EF91-F929-45F8-95CA-E4C9A9724FFF>

How to Define and Use Interface-Range Macros

You can define an interface-range macro to automatically select a range of interfaces for configuration. Before you can use the **macro** keyword in the **interface range macro** command string, you must define the macro.

To define an interface-range macro, perform this task:

Command	Purpose
Tqwwgt*eqphki+% fghkpg "kpvgt <hceg tcpig"ocetqapcog"<br=""></hceg> } xncp vlan_ID / vlan_IDi "~"}v{rg"slot/port / rqtv_i"]." }v{rg"slot/port / rqtv_i_"	Defines the interface-range macro and save it in NVRAM.

This example shows how to define an interface-range macro named `enet_list` to select Gigabit Ethernet ports 1/1 through 1/4:

```
Tqwvgt*eqphki+% "fghkpg"kpvgthceg/tcpig"ggpvankuv"ikicdkvgvjgtpgv"313"/"6"
```

To show the defined interface-range macro configuration, perform this task:

Command	Purpose
Tqwvgt%"ujqy"twppkpi/eqphki"	Shows the defined interface-range macro configuration.

This example shows how to display the defined interface-range macro named `enet_list`:

```
Tqwvgt%"ujqy"twppkpi/eqphki"~"kpenwfg"fghkpg"
fghkpg"kpvgthceg/tcpig"ggpvankuv"Ikicdkvgvjgtpgv313"/"6
Tqwvgt%
```

To use an interface-range macro in the **interface range** command, perform this task:

Command	Purpose
Tqwvgt*eqphki+% "kpvgthceg"tcpig"ocetq"ocetqapcog"	Selects the interface range to be configured using the values saved in a named interface-range macro.

This example shows how to change to the interface-range configuration mode using the interface-range macro `enet_list`:

```
Tqwvgt*eqphki+% "kpvgthceg"tcpig"ocetq"ggpvankuv"
Tqwvgt*eqphki/kh+%"
```

How to Configure Optional Interface Features

- [Configuring Ethernet Interface Speed and Duplex Mode, page 10-3](#)
- [Configuring Jumbo Frame Support, page 10-6](#)
- [Configuring IEEE 802.3x Flow Control, page 10-9](#)
- [Configuring the Port Debounce Timer, page 10-10](#)

Configuring Ethernet Interface Speed and Duplex Mode

- [Speed and Duplex Mode Configuration Guidelines, page 10-4](#)
- [Configuring the Ethernet Interface Speed, page 10-4](#)
- [Setting the Interface Duplex Mode, page 10-5](#)
- [Configuring Link Negotiation on Gigabit Ethernet Ports, page 10-5](#)
- [Displaying the Speed and Duplex Mode Configuration, page 10-6](#)

Speed and Duplex Mode Configuration Guidelines

You usually configure Ethernet port speed and duplex mode parameters to auto and allow ports to negotiate the speed and duplex mode. If you decide to configure the port speed and duplex modes manually, consider the following information:

- You cannot set the Ethernet port speed to auto (the **no speed** command) if the duplex mode is not set to auto (the **no duplex** command).
- If you configure an Ethernet port speed to a value other than auto (for example, 10, 100, or 1000 Mbps), configure the connecting port to match. Do not configure the connecting port to negotiate the speed.
- If you manually configure the Ethernet port speed to either 10 Mbps or 100 Mbps, the switch prompts you to also configure the duplex mode on the port.



Note

A LAN port cannot automatically negotiate Ethernet port speed and duplex mode if the connecting port is configured to a value other than auto.



Caution

Changing the Ethernet port speed and duplex mode configuration might shut down and reenable the interface during the reconfiguration.

Configuring the Ethernet Interface Speed



Note

If you configure the Ethernet port speed to **auto** on a 10/100/1000-Mbps Ethernet port, both speed and duplex are autonegotiated. 10-Gigabit Ethernet ports do not support autonegotiation.

To configure the port speed for a 10/100/1000-Mbps Ethernet port, perform this task:

	Command	Purpose
Step 1	<code>Tqvwgt*eqphki+%"kpvgtbceg"ikicdkvgvjgtpgv" slot/port"</code>	Selects the Ethernet port to be configured.
Step 2	<code>Tqvwgt*eqphki/kh+%"urggf"}32"~"322"~"3222"~" }cwvq]32"322"]3222__i i"</code>	Configures the speed of the Ethernet interface.

When configuring the port speed for a 10/100/1000-Mbps Ethernet port, note the following:

- Enter the **auto 10 100** keywords to restrict the negotiated speed to 10-Mbps or 100-Mbps.
- The **auto 10 100 1000** keywords have the same effect as the **auto** keyword by itself.

This example shows how to configure the speed to 100 Mbps on the Gigabit Ethernet port 1/4:

```
Tqvwgt*eqphki+%"kpvgtbceg"ikicdkvgvjgtpgv"316
Tqvwgt*eqphki/kh+%"urggf"322
```


Setting the Interface Duplex Mode



Note

- 10-Gigabit Ethernet and Gigabit Ethernet are full duplex only. You cannot change the duplex mode on 10-Gigabit Ethernet or Gigabit Ethernet ports or on a 10/100/1000-Mbps port configured for Gigabit Ethernet.
- If you set the port speed to auto on a 10/100/1000-Mbps Ethernet port, both speed and duplex are autonegotiated. You cannot change the duplex mode of autonegotiation ports.

To set the duplex mode of an Ethernet or Gigabit Ethernet port, perform this task:

	Command	Purpose
Step 1	<code>Tqwgvt*eqphki+% "kpvgtthceg" ikicdkvgvjgtpgv "slot/port"</code>	Selects the Ethernet port to be configured.
Step 2	<code>Tqwgvt*eqphki/kh+% "fwrngz"] cwvq " ~ "hwnn" ~ "jcnh_ "</code>	Sets the duplex mode of the Ethernet port.

This example shows how to set the duplex mode to full on Gigabit Ethernet port 1/4:

```
Tqwgvt*eqphki+% "kpvgtthceg" ikicdkvgvjgtpgv "316
Tqwgvt*eqphki/kh+% "fwrngz" hwnn
```

Configuring Link Negotiation on Gigabit Ethernet Ports



Note

Link negotiation does not negotiate port speed.

On Gigabit Ethernet ports, link negotiation exchanges flow-control parameters, remote fault information, and duplex information. Link negotiation is enabled by default.

The ports on both ends of a link must have the same setting. The link will not come up if the ports at each end of the link are set inconsistently (link negotiation enabled on one port and disabled on the other port).

[Table 10-1](#) shows the four possible link negotiation configurations and the resulting link status for each configuration.

Table 10-1 Link Negotiation Configuration and Possible Link Status

Link Negotiation State		Link Status	
Local Port	Remote Port	Local Port	Remote Port
Off	Off	Up	Up
On	On	Up	Up
Off	On	Up	Down
On	Off	Down	Up

To configure link negotiation on a port, perform this task:

	Command	Purpose
Step 1	<code>Tqwvgt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv "slot/port"</code>	Selects the port to be configured.
Step 2	<code>Tqwvgt*eqphki/kh+% "urggf" ppggiqvkcvg</code>	Disables link negotiation.

This example shows how to enable link negotiation on Gigabit Ethernet port 1/4:

```
Tqwvgt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv "316"
Tqwvgt*eqphki/kh+% "pq" urggf "ppggiqvkcvg"
```

Displaying the Speed and Duplex Mode Configuration

To display the speed and duplex mode configuration for a port, perform this task:

Command	Purpose
<code>Tqwvgt% "ujqy" kpvgthcegu "v{rg" slot/port"} vtcpuegkxgt "rtqrgtvkgu_</code>	Displays the speed and duplex mode configuration. To display autonegotiation status for speed and duplex, add the transceiver properties option.

Configuring Jumbo Frame Support

- [Information about Jumbo Frame Support, page 10-6](#)
- [Configuring MTU Sizes, page 10-8](#)

Information about Jumbo Frame Support

- [Jumbo Frame Support Overview, page 10-6](#)
- [Nondefault MTU Sizes on Ethernet Ports, page 10-7](#)
- [VLAN Interfaces, page 10-8](#)

Jumbo Frame Support Overview

A jumbo frame is a frame larger than the default Ethernet size. You enable jumbo frame support by configuring a larger-than-default maximum transmission unit (MTU) size on a port or VLAN interface and configuring the global LAN port MTU size.



Note

- Jumbo frame support fragments routed traffic in software on the route processor (RP).
- Jumbo frame support does not fragment bridged traffic.

Bridged and Routed Traffic Size Check at Ingress 10/100, and 100 Mbps Ethernet and 10-Gigabit Ethernet Ports

Jumbo frame support compares ingress traffic size with the global LAN port MTU size at ingress 10/100, and 100 Mbps Ethernet and 10-Gigabit Ethernet LAN ports that have a nondefault MTU size configured. The port drops traffic that is oversized. You can configure the global LAN port MTU size (see the [“Configuring the Global Egress LAN Port MTU Size” section on page 10-9](#)).

Bridged and Routed Traffic Size Check at Ingress Gigabit Ethernet Ports

Gigabit Ethernet LAN ports configured with a nondefault MTU size accept frames containing packets of any size larger than 64 bytes. With a nondefault MTU size configured, Gigabit Ethernet LAN ports do not check for oversize ingress frames.

Routed Traffic Size Check on the PFC

For traffic that needs to be routed, Jumbo frame support on the PFC compares traffic sizes to the configured MTU sizes and provides Layer 3 switching for jumbo traffic between interfaces configured with MTU sizes large enough to accommodate the traffic. Between interfaces that are not configured with large enough MTU sizes, if the “do not fragment bit” is not set, the PFC sends the traffic to the RP to be fragmented and routed in software. If the “do not fragment bit” is set, the PFC drops the traffic.

Bridged and Routed Traffic Size Check at Egress 10, 10/100, and 100 Mbps Ethernet Ports

10, 10/100, and 100 Mbps Ethernet LAN ports configured with a nondefault MTU size transmit frames containing packets of any size larger than 64 bytes. With a nondefault MTU size configured, 10, 10/100, and 100 Mbps Ethernet LAN ports do not check for oversize egress frames.

Bridged and Routed Traffic Size Check at Egress Gigabit Ethernet and 10-Gigabit Ethernet Ports

Jumbo frame support compares egress traffic size with the global egress LAN port MTU size at egress Gigabit Ethernet and 10-Gigabit Ethernet LAN ports that have a nondefault MTU size configured. The port drops traffic that is oversized. You can configure the global LAN port MTU size (see the [“Configuring the Global Egress LAN Port MTU Size” section on page 10-9](#)).

Nondefault MTU Sizes on Ethernet Ports

- [Ethernet Port Overview, page 10-7](#)
- [Layer 3 Ethernet Ports, page 10-7](#)
- [Layer 2 Ethernet Ports, page 10-8](#)

Ethernet Port Overview

Configuring a nondefault MTU size on a 10, 10/100, or 100 Mbps Ethernet port limits ingress packets to the global LAN port MTU size and permits egress traffic of any size larger than 64 bytes.

Configuring a nondefault MTU size on a Gigabit Ethernet port permits ingress packets of any size larger than 64 bytes and limits egress traffic to the global LAN port MTU size.

Configuring a nondefault MTU size on a 10-Gigabit Ethernet port limits ingress and egress packets to the global LAN port MTU size.

You can configure the MTU size on any Ethernet port.

Layer 3 Ethernet Ports

On a Layer 3 port, you can configure an MTU size on each Layer 3 Ethernet port that is different than the global LAN port MTU size.



Note

Traffic through a Layer 3 Ethernet LAN port that is configured with a nondefault MTU size is also subject to the global LAN port MTU size (see the [“Configuring the Global Egress LAN Port MTU Size” section on page 10-9](#)).

Layer 2 Ethernet Ports

On a Layer 2 port, you can only configure an MTU size that matches the global LAN port MTU size (see the [“Configuring the Global Egress LAN Port MTU Size” section on page 10-9](#)).

VLAN Interfaces

You can configure a different MTU size on each Layer 3 VLAN interface. Configuring a nondefault MTU size on a VLAN interface limits traffic to the nondefault MTU size. You can configure the MTU size on VLAN interfaces to support jumbo frames.

Configuring MTU Sizes

- [Configuring the MTU Size, page 10-8](#)
- [Configuring the Global Egress LAN Port MTU Size, page 10-9](#)

Configuring the MTU Size

To configure the MTU size, perform this task:

	Command	Purpose
Step 1	<code>Tqwwgt*eqphki+%kpvgthceg}}xmcp"vlan_ID;"~" }}type slot/port;"~"rqtv/ejcppgn" rqtvaejcppgnapwodgt;"slot/port;"</code>	Selects the interface to configure.
Step 2	<code>Tqwwgt*eqphki/kh+%ovw"ovwauk/g"</code>	Configures the MTU size.
Step 3	<code>Tqwwgt*eqphki/kh+%gpf"</code>	Exits configuration mode.

When configuring the MTU size, note the following information:

- For VLAN interfaces and Layer 3 Ethernet ports, supported MTU values are from 64 to 9216 bytes.



Note

For Cisco Catalyst C6840 Series switches the supported MTU values are from 64 to 9154 bytes.

- For Layer 2 Ethernet ports, you can configure only the global egress LAN port MTU size (see the [“Configuring the Global Egress LAN Port MTU Size” section on page 10-9](#)).
- MTU size on a Layer 2 interface is always set to maximum. If you reconfigure the MTU size to enable jumbo frame support, MTU size does not get updated in the MTU hardware table for L2 interface at the egress. The interface (L2) MTU size check happens only at the ingress port.

This example shows how to configure the MTU size on Gigabit Ethernet port 1/2:

```
Tqwwgt%"eqphkiwtg"vgtokpcn"
```

```
Tqvwgt*eqphki+% "kpvgt hceg" ikicdkvgvjgtpgv"314"
Tqvwgt*eqphki/kh+% "ovw";438
Tqvwgt*eqphki/kh+% "gpf"
```

This example shows how to verify the configuration:

```
Tqvwgt% "ujqy" kpvgt hceg" ikicdkvgvjgtpgv"314
IkicdkvGvjgtpgv314"ku"cfokpkuvtcvkxgn{ "fqyp. "nkpq"rtqvqeqn"ku"fqyp
" "Jctfyctg"ku"E8m"32220d":2405. "cfftguu"ku"22520;84;0;h: : " *dkc"22520;84;0;h: : +
" "OVW";438"d{vgu. "DY"3222222"Mdkv. "FN["32"wuge.
>000Qwvrvw"Vtwpevcvgf000@
Tqvwgt%
```

Configuring the Global Egress LAN Port MTU Size

To configure the global egress LAN port MTU size, perform this task:

	Command	Purpose
Step 1	Tqvwgt*eqphki+% "u{uvgo"lwodgovw"ovwauk/g"	Configures the global egress LAN port MTU size. Note Because it would change all the interface MTU sizes to the default (1500), rather than to any configured nondefault interface MTU size, do not use the system jumbomtu command to set the MTU size to 1500. (CSCtq52016)
Step 2	Tqvwgt*eqphki+% "gpf"	Exits configuration mode.

Configuring IEEE 802.3x Flow Control

Gigabit Ethernet and 10-Gigabit Ethernet ports use flow control to stop the transmission of frames to the port for a specified time; other Ethernet ports use flow control to respond to flow-control requests.

If a Gigabit Ethernet or 10-Gigabit Ethernet port receive buffer becomes full, the port can be configured to transmit an IEEE 802.3x pause frame that requests the remote port to delay sending frames for a specified time. All Ethernet ports can be configured to respond to IEEE 802.3x pause frames from other devices.

To configure flow control on an Ethernet port, perform this task:

	Command	Purpose
Step 1	Tqvwgt*eqphki+% "kpvgt hceg" type slot/port"	Selects the port to configure.
Step 2	Tqvwgt*eqphki/kh+% "hnqyeqpvtn" } tgegkxg" ~ "ugpf;" } fguktgf" ~ "qhh" ~ "qp;"	Configures a port to send or respond to pause frames.

When configuring flow control, note the following information:

- Because auto negotiation does not work on 10 Gigabit Ethernet fiber optic ports, they respond to pause frames by default. On 10 Gigabit Ethernet fiber optic ports, the flow-control operational mode is always the same as administrative mode.
- When configuring how a port responds to pause frames, note the following information:

- For a Gigabit Ethernet port, when the configuration of a remote port is unknown, you can use the **receive desired** keywords to configure the Gigabit Ethernet port to respond to received pause frames. (Supported only on Gigabit Ethernet ports.)
- Use the **receive on** keywords to configure a port to respond to received pause frames.
- Use the **receive off** keywords to configure a port to ignore received pause frames.
- When configuring transmission of pause frames on a port, note the following information:
 - For a Gigabit Ethernet port, when the configuration of the remote ports is unknown, you can use the **send desired** keywords to configure the Gigabit Ethernet port to send pause frames. (Supported only on Gigabit Ethernet ports.)
 - Use the **send on** keywords to configure a port to send pause frames.
 - Use the **send off** keywords to configure a port not to send pause frames.

This example shows how to turn on receive flow control and how to verify the flow-control configuration:

```
Tqvwgt%eqphkiwtg"vgtokpcn
Tqvwgt*eqphki+%kpvgtthceg"ikicdkvgvjgtpgv"314
Tqvwgt*eqphki/kh+%hnqyeqpvtn"tgegkxg"qp
Tqvwgt*eqphki/kh+%gpf
Tqvwgt%"ujgy"kpvgthcegu"hnqyeqpvtn

Kpvgtthceg"Ugpf""""""Tgegkxg
Ik313""""Fguktgf""""QHH
Ik314""""Fguktgf""""QP
>qwvrvv"vtwpecvgf@
```

Configuring the Port Debounce Timer

The port debounce timer delays notification of a link change, which can decrease traffic loss due to network reconfiguration. You can configure the port debounce timer separately on each LAN port.



Caution

Enabling the port debounce timer causes link down detections to be delayed, resulting in loss of traffic during the debouncing period. This situation might affect the convergence and reconvergence of some Layer 2 and Layer 3 protocols.

To configure the debounce timer on a port, perform this task:

	Command	Purpose
Step 1	<code>Tqvwgt*eqphki+%kpvgtthceg" type slot/port"</code>	Selects the port to configure.
Step 2	<code>Tqvwgt*eqphki/kh+%nkpm"fgdqwpeg"</code> <code>]vkog fgdqwpegavkog_</code>	Configures the debounce timer.

When configuring the debounce timer on a port, note the following information:

- The **time** keyword is supported only on fiber 1000 Mbps or faster Ethernet ports.
- You can increase the port debounce timer value in increments of 100 milliseconds up to 5000 milliseconds on ports operating at 1000 Mbps over copper media.
- The debounce timer recognizes 10-Gbps copper media and detects media-only changes.

Table 10-2 lists the time delay that occurs before notification of a link change.

Port Type	Debounce Timer Disabled	Debounce Timer Enabled
Ports operating at 10 Mbps or 100 Mbps:	300 milliseconds	3100 milliseconds
Ports operating at 1000 Mbps or 10 Gbps over copper media:	300 milliseconds	3100 milliseconds
Ports operating at 1000 Mbps or 10 Gbps over fiber media:	10 milliseconds	100 milliseconds

Note The show interfaces debounce command does not display the default value for 10-GigabitEthernet ports when the port debounce timer is disabled.



This example shows how to enable the port debounce timer on Gigabit Ethernet port 1/12:

This example shows how to display the port debounce timer settings:

Information About Online Insertion and Removal

Note

If the replacement module is different from the removed module, you must configure it before the switch can bring it online.

Layer 2 MAC addresses are stored in an EEPROM, which allows modules to be replaced online without requiring the system to update switching tables and data structures. Regardless of the types of modules installed, the Layer 2 MAC addresses do not change unless you replace the supervisor engine. If you do replace the supervisor engine, the Layer 2 MAC addresses of *all* ports change to those specified in the address allocator on the new supervisor engine.

How to Monitor and Maintain Interfaces

- [Monitoring Interface Status, page 10-12](#)
- [Clearing Counters on an Interface, page 10-12](#)
- [Resetting an Interface, page 10-13](#)
- [Shutting Down and Restarting an Interface, page 10-13](#)

Monitoring Interface Status

The software contains commands that you can enter at the EXEC prompt to display information about the interface including the version of the software and the hardware and statistics about interfaces. The following table lists some of the interface monitoring commands. (You can display the complete list of **show** commands by using the **show ?** command at the EXEC prompt.) These commands are described in the *Cisco IOS Interface Command Reference* publication.

To display information about the interface, perform these tasks:

Command	Purpose
<code>Tqwvgt% "ujqy" kde</code>	Displays current internal status information.
<code>Tqwvgt% "ujqy" gqde</code>	Displays current internal out-of-band information.
<code>Tqwvgt% "ujqy" kpvgt hcegu] type slot/port_</code>	Displays the status and configuration of all or a specific interface.
<code>Tqwvgt% "ujqy" twppkpi /eqphki "</code>	Displays the currently running configuration.
<code>Tqwvgt% "ujqy" tkh</code>	Displays the current contents of the routing information field (RIF) cache.
<code>Tqwvgt% "ujqy" rtqvqegnu] type slot/port_ "</code>	Displays the global (system-wide) and interface-specific status of any configured protocol.
<code>Tqwvgt% "ujqy" xgtukqp</code>	Displays the hardware configuration, software version, the names and sources of configuration files, and the boot images.

Clearing Counters on an Interface

To clear the interface counters shown with the **show interfaces** command, perform this task:

Command	Purpose
<code>Tqwvgt% "engct "eqwpvgtu" } } xncp "vlan_ID; "~" } type slot/port; "~" } rqt v/ejcppgn "channel_ID; ;</code>	Clears interface counters.

This example shows how to clear and reset the counters on Gigabit Ethernet port 1/5:

```
Tqvwgt%engct"eqwpvgtu"ikicdkvgvjgtpgv"317"
Engct"$ujqy"kpvgthceg$eqwpvgtu"qp"vjku"kpvgthceg"]eqphkto_"{"
,Ugr"52"2:<64<77<"'ENGCT/7/EQWPVGtu"<Engct"eqwpvgt"qp"kpvgthceg"IkicdkvGvjgtpgv317
```

The **clear counters** command clears all the current counters from the interface unless the optional arguments specify a specific interface.



Note

The **clear counters** command clears counters displayed with the EXEC **show interfaces** command, not counters retrieved using SNMP.

Resetting an Interface

To reset an interface, perform this task:

Command	Purpose
Tqvwgt%engct"kpvgthceg" type slot/port"	Resets an interface.

This example shows how to reset Gigabit Ethernet port 1/5:

```
Tqvwgt%engct"kpvgthceg"ikicdkvgvjgtpgv"317"
```

Shutting Down and Restarting an Interface

You can shut down an interface, which disables all functions on the specified interface and shows the interface as unavailable on all monitoring command displays. This information is communicated to other network servers through all dynamic routing protocols. The interface is not included in any routing updates.

To shut down an interface and then restart it, perform this task:

	Command	Purpose
Step 1	Tqvwgt*eqphki+% "kpvgthceg" } }xncp"vlan_IDi"~" }type slot/port;"~"}rqtv/ejcppgn"channel_IDi i	Selects the interface to be configured.
Step 2	Tqvwgt*eqphki/kh+% "ujwvfqyp"	Shuts down the interface.
Step 3	Tqvwgt*eqphki/kh+% "pq"ujwvfqyp"	Reenables the interface.

This example shows how to shut down Gigabit Ethernet port 1/5:

```
Tqvwgt*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv"317"
Tqvwgt*eqphki/kh+% "ujwvfqyp"
Tqvwgt*eqphki/kh+%
```



Note

The link state messages (LINK-3-UPDOWN and LINEPROTO-5-UPDOWN) are disabled by default. Enter the **logging event link status** command on each interface where you want the messages enabled.

This example shows how to reenabling Gigabit Ethernet port 1/5:

```
Tqwgvt*eqphki/kh+%"pq"ujwvfqyp"
Tqwgvt*eqphki/kh+%
```

To check if an interface is disabled, enter the EXEC **show interfaces** command. An interface that has been shut down is shown as administratively down in the **show interfaces** command display.

How to Check Cable Status with the TDR

You can check the status of copper cables using the time domain reflectometer (TDR). The TDR detects a cable fault by sending a signal through the cable and reading the signal that is reflected back to it. All or part of the signal can be reflected back by any number of cable defects or by the end of the cable itself.

Use the TDR to determine if the cabling is at fault if you cannot establish a link. This test is especially important when replacing an existing switch, upgrading to Gigabit Ethernet, or installing new cables.



Note

- TDR can test cables up to a maximum length of 115 meters.
- TDR results are not meaningful for a link that is operating successfully.
- The port must be up before running the TDR test. If the port is down, you cannot enter the **test cable-diagnostics tdr** command successfully, and the following message is displayed:

```
Tqwgvt%"vguv"ecdng/fkciqquvkeu"vft"kpvgthceg"ikicdkvgvjgtpgv4134"
' "Kpvgthceg" Ik4134 "ku"cfokpkuvtcvkxgn{ "fqyp
' "Wug" )pq"ujwvfqyp) "vq"gpcedng"kpvgthceg"dghqtg"VFT"vguv"uvctv0
```

To start or stop the TDR test, perform this task:

Command	Purpose
vguv"ecdng/fkciqquvkeu vft kpvgthceg"}kpvgthceg" kpvgthcegapwodgt;	Starts or stops the TDR test.

This example shows how to run the TDR-cable diagnostics:

```
Tqwgvt%"vguv"ecdng/fkciqquvkeu"vft"kpvgthceg"ikicdkvgvjgtpgv413"
VFT"vguv"uvctvgf"qp"kpvgthceg"Ik413"
C"VFT"vguv"ecp"vcmg"c"hy"ugeqpfu"vq"twp"qp"cp"kpvgthceg"
Wug" )ujqy"ecdng/fkciqquvkeu"vft) "vq"tgcf"vjg"VFT"tguwnvu0
Tqwgvt "%
```



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

How to Convert Line Card to Operate in 40G Mode

You can configure C6800-x10G cards to operate in 10G mode and 40G mode. The ports are natively 10G but can support 40G by adding a CVR-4SFP10G-QSFP adapter. These cards need to be converted to 40G mode to support 40G interfaces. The cards can support both 10G and 40G interfaces on different port-groups.



Note

Converting the line card to 40G mode will reset the module.

To configure a module to operate in 40G mode, perform the following task:

Command	Purpose
<code>Tqwgvt*eqphki+% "jy/oqfwng"}unqv"/"unqv/pq"; " qrgtcvkqp/oqfg"}rqtv/itqwr"/"rqtv/itqwr"; " hgtv{IkicdkvGvjgtpgv</code>	Configures the slot port-group to 40G Mode.

To show the module operation mode, run the following command:


Command	Purpose
<code>Tqwgvt%"ujqy"jy/oqfwng"}unqv"/"unqv/pq"; " qrgtcvkqp/oqfg</code>	Shows the operation mode on slot per port-group.

Overview of Cisco CVR-4SFP10G-QSFP Adapter

The Cisco CVR-4SFP10G-QSFP Adapter converts four SFP+ ports into a QSFP+ port. With this adapter, you have the flexibility to use a QSFP+ module to connect to a 40 Gigabit Ethernet port on the other end of the link. This flexibility allows a cost-effective transition to 40 Gigabit Ethernet by maximizing the use of existing or new 10 Gigabit Ethernet SFP+ platforms.


For more information, see the Cisco 4 x SFP10G to QSFP Reverse Adapter Data Sheet.

Figure 10-1 Cisco CVR-4SFP10G-QSFP Adapter and QSFP+ Module



354671

Figure 10-2 Cisco CVR-4SFP10G-QSFP Adapter with QSFP+ Module Plugged In



354672

Compatible Line Cards

All Catalyst 6800 series line cards support CVR-4SFP10G-QSFP Adapter. Due to power limitations on line card, one port per port-group can be operated on 40G and connected to CVR-4SFP10G-QSFP Adapter.

Table 10-3 40G Ports supported on port groups

Line Card	Port-group Mapping	40G Ports – Physical Port Mapping	Supported 40G Ports per Port-Group
C6800-32P10G	PG1 – 1,3,5,7,9,11,13,15	Port 33 – 1,3,5,7 & Port 35 – 9,11,13,15	PG1 – Port 33
	PG2 – 2,4,6,8,10,12,14,16	Port 34 – 2,4,6,8 & Port 36 – 10,12,14,16	PG2 – Port 34
	PG3 – 17,19,21,23,25,27,29,31	Port 37 – 17,19,21,23 & Port 39 – 25,27,29,31	PG3 – Port 37
	PG4 – 18,20,22,24,26,28,30,32	Port 38 – 18,20,22,24 & Port 40 – 26,28,30,32	PG4 – Port 38
C6800-16P10G	PG1 – 1,2,3,4,5,6,7,8	Port 17 – 1,2,3,4 & Port 18 – 5,6,7,8	PG1 – Port 17
	PG2 – 9,10,11,12,13,14,15,16	Port 19 – 9,10,11,12 & Port 20 – 13,14,15,16	PG2 – Port 19
C6800-8P10G	PG1 – 1,2,3,4	Port 9 – 1,2,3,4	PG1 – Port 9
	PG2 – 5,6,7,8	Port 10 – 5,6,7,8	PG2 – Port 10

**Note**

40G mode conversion on line card is per port-group, ports in the non-converted port-groups will continue to operate in 10G mode and no ports are disabled.



UniDirectional Link Detection (UDLD)

- [Prerequisites for UDLD, page 11-1](#)
- [Restrictions for UDLD, page 11-1](#)
- [Information About UDLD, page 11-2](#)
- [Default Settings for UDLD, page 11-4](#)
- [How to Configure UDLD, page 11-4](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for UDLD

None.

Restrictions for UDLD

None.

Information About UDLD

- [UDLD Overview, page 11-2](#)
- [UDLD Aggressive Mode, page 11-3](#)
- [Fast UDLD, page 11-4](#)

UDLD Overview

The Cisco-proprietary UDLD protocol allows devices connected through fiber-optic or copper (for example, Category 5 cabling) Ethernet cables connected to LAN ports to monitor the physical configuration of the cables and detect when a unidirectional link exists. When a unidirectional link is detected, UDLD shuts down the affected LAN port and alerts the user. Unidirectional links can cause a variety of problems, including spanning tree topology loops.

UDLD is a Layer 2 protocol that works with the Layer 1 protocols to determine the physical status of a link. At Layer 1, autonegotiation takes care of physical signaling and fault detection. UDLD performs tasks that autonegotiation cannot perform, such as detecting the identities of neighbors and shutting down misconnected LAN ports. When you enable both autonegotiation and UDLD, Layer 1 and Layer 2 detections work together to prevent physical and logical unidirectional connections and the malfunctioning of other protocols.


A unidirectional link occurs whenever traffic transmitted by the local device over a link is received by the neighbor but traffic transmitted from the neighbor is not received by the local device. If one of the fiber strands in a pair is disconnected, as long as autonegotiation is active, the link does not stay up. In this case, the logical link is undetermined, and UDLD does not take any action. If both fibers are working normally at Layer 1, then UDLD at Layer 2 determines whether those fibers are connected correctly and whether traffic is flowing bidirectionally between the correct neighbors. This check cannot be performed by autonegotiation, because autonegotiation operates at Layer 1.

LAN ports with UDLD enabled periodically transmit UDLD packets to neighbor devices. If the packets are echoed back within a specific time frame and they are lacking a specific acknowledgment (echo), the link is flagged as unidirectional and the LAN port is shut down. Devices on both ends of the link must support UDLD in order for the protocol to successfully identify and disable unidirectional links.

**Note**

By default, UDLD is locally disabled on copper LAN ports to avoid sending unnecessary control traffic on this type of media since it is often used for access ports.

[Figure 11-1](#) shows an example of a unidirectional link condition. Switch B successfully receives traffic from Switch A on the port. However, Switch A does not receive traffic from Switch B on the same port. UDLD detects the problem and disables the port.

Figure 11-1 Unidirectional Link

18720

UDLD Aggressive Mode

UDLD aggressive mode is disabled by default. Configure UDLD aggressive mode only on point-to-point links between network devices that support UDLD aggressive mode. With UDLD aggressive mode enabled, when a port on a bidirectional link that has a UDLD neighbor relationship established stops receiving UDLD packets, UDLD tries to reestablish the connection with the neighbor. After eight failed retries, the port is disabled.

To prevent spanning tree loops, nonaggressive UDLD with the default interval of 15 seconds is fast enough to shut down a unidirectional link before a blocking port transitions to the forwarding state (with default spanning tree parameters).

When you enable UDLD aggressive mode, you receive additional benefits in the following situations:

- One side of a link has a port stuck (both Tx and Rx)
- One side of a link remains up while the other side of the link has gone down

In these cases, UDLD aggressive mode disables one of the ports on the link, which prevents traffic from being discarded.



Note

In UDLD normal mode, when a unidirectional error is detected, the port is not disabled. In UDLD aggressive mode, when a unidirectional error is detected, the port is disabled.

Fast UDLD

Release 15.0(1)SY1 and later releases support fast UDLD.

Fast UDLD is a per-port configuration option that supports UDLD message time intervals between 200 and 1000 milliseconds. Fast UDLD can be configured to provide subsecond unidirectional link detection. (Without fast UDLD, the message time intervals are 7 through 90 seconds).

When configuring fast UDLD, note the following guidelines and restrictions:

- Fast UDLD is disabled by default.
- Normal and aggressive mode both support fast UDLD.
- Fast UDLD ports do not support the **link debounce** command.
- Fast UDLD supports only point-to-point with at least two links between network devices that support fast UDLD.
- Fast UDLD does not report a unidirectional link if the same error occurs simultaneously on more than one link to the same neighbor device.
- Fast UDLD cannot detect unidirectional links when the CPU utilization exceeds 60 percent.
- Fast UDLD is supported on 60 ports with a Supervisor Engine 6T.

Default Settings for UDLD

Feature	Default Value
UDLD global enable state	Globally disabled.
UDLD aggressive mode	Disabled.
UDLD per-port enable state for fiber-optic media	Enabled on all Ethernet fiber-optic LAN ports.
UDLD per-port enable state for twisted-pair (copper) media	Disabled on all Ethernet 10/100 and 1000BASE-TX LAN ports.
Fast UDLD	Disabled.
Fast UDLD error reporting	Disabled.

How to Configure UDLD

- [Enabling UDLD Globally, page 11-5](#)
- [Enabling UDLD on LAN Interfaces, page 11-5](#)
- [Disabling UDLD on Nonfiber-Optic LAN Interfaces, page 11-5](#)
- [Disabling UDLD on Fiber-Optic LAN Interfaces, page 11-6](#)
- [Configuring the UDLD Probe Message Interval, page 11-6](#)
- [Configuring Fast UDLD, page 11-6](#)
- [Resetting Disabled LAN Interfaces, page 11-7](#)

Enabling UDLD Globally

To enable UDLD globally on all fiber-optic LAN ports, perform this task:

Command	Purpose
<code>Tqwvgt*eqphki+%wfnf" }gpcdng"~"ciitguukxg; "</code>	Enables UDLD globally on fiber-optic LAN ports. Note This command only configures fiber-optic LAN ports. Individual LAN port configuration overrides the setting of this command.

Enabling UDLD on LAN Interfaces

To enable UDLD on a LAN port, perform this task:

	Command	Purpose
Step 1	<code>Tqwvgt*eqphki+%kpvgthceg"type slot/port"</code>	Selects the LAN port to configure.
Step 2	<code>Tqwvgt*eqphki/kh+% wfnf"rqtv"]ciitguukxg_ "</code>	Enables UDLD on a LAN port. - Enter the aggressive keyword to enable aggressive mode. - On a fiber-optic LAN port, this command overrides the udld enable global configuration command setting. - On fiber-optic LAN ports, the no udld port command reverts the LAN port configuration to the udld enable global configuration command setting.

Disabling UDLD on Nonfiber-Optic LAN Interfaces

To disable UDLD on a nonfiber-optic LAN port., perform this task:

	Command	Purpose
Step 1	<code>Tqwvgt*eqphki+%kpvgthceg"type slot/port"</code>	Selects the LAN port to configure.
Step 2	<code>Tqwvgt*eqphki/kh+% pq"wfnf"rqtv"]ciitguukxg_ "</code>	Disables UDLD on a nonfiber-optic LAN port.

Disabling UDLD on Fiber-Optic LAN Interfaces

To disable UDLD on individual fiber-optic LAN ports, perform this task:

Command	Purpose
<code>Tqvwgt*eqphki+%"kpvgt hceg" type slot/port</code>	Selects the LAN port to configure.
<code>Tqvwgt*eqphki/kh+%"wfnf" rqtv"fkucdng"</code>	Disables UDLD on a fiber-optic LAN port. Note The no form of this command, which reverts to the udld enable global configuration command setting, is only supported on fiber-optic LAN ports.

Configuring the UDLD Probe Message Interval

To configure the time between UDLD probe messages on ports that are in advertisement mode and are currently determined to be bidirectional, perform this task:

Command	Purpose
<code>Tqvwgt*eqphki+%"wfnf"oguucig"vkog" kpvgtxcn</code>	Configures the time between UDLD probe messages on ports that are in advertisement mode and are currently determined to be bidirectional; valid values are from 7 to 90 seconds.

Configuring Fast UDLD

Release 15.0(1)SY1 and later releases support fast UDLD. These sections describe how to configure fast UDLD:

- [Configuring Fast UDLD on a Port, page 11-7](#)
- [Enabling Fast UDLD Error Reporting, page 11-7](#)



Note

You can configure fast UDLD on ports where UDLD is not enabled, but fast UDLD is active only when UDLD is enabled on the port.

Configuring Fast UDLD on a Port

To configure fast UDLD on a port, perform this task:

	Command	Purpose
Step 1	<code>Tqvwgt*eqphki/kh+%wfnf"hcuv/jgnnq" kpvgtxcn</code>	Configures the fast UDLD probe message interval on a port. - See the guidelines and restrictions in the “Fast UDLD” section on page 11-4. - When selecting the value, follow these guidelines: - Valid values are from 200 to 1000 milliseconds. - Adjust the fast UDLD probe message interval to the longest interval possible that will provide the desired link failure detection time. A shorter message interval increases the likelihood that UDLD will falsely report link failures under stressful conditions.
Step 2	<code>Tqvwgt% ujqy"wfnf"hcuv/jgnnq"</code>	Displays fast UDLD configuration and operational state.
Step 3	<code>Tqvwgt% ujqy"wfnf"hcuv/jgnnq" type³ slot/number</code>	Verifies the per-port fast UDLD configuration and operational state.

1. *type* = fastethernet, gigabitethernet, tengigabitethernet, or fortygigabitethernet

Enabling Fast UDLD Error Reporting

By default, fast UDLD error-disables ports with unidirectional links. You can globally enable fast UDLD to report unidirectional links with a message displayed on the console instead of error-disabling ports with unidirectional links.



Note

When fast UDLD error reporting is enabled, you must manually take the action appropriate for the state of the link.

To globally enable fast UDLD error reporting, perform this task:

Command	Purpose
<code>Tqvwgt*eqphki+%wfnf"hcuv/jgnnq"gttqt/tgrqtvkpi"</code>	Enables fast UDLD error reporting.

Resetting Disabled LAN Interfaces

To reset all LAN ports that have been shut down by UDLD, perform this task:

Command	Purpose
<code>Tqvwgt% wfnf"tgugv"</code>	Resets all LAN ports that have been shut down by UDLD.

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Instant Access (IA)

- [Prerequisites for Instant Access, page 12-1](#)
- [Restrictions for Instant Access, page 12-2](#)
- [Information About Instant Access, page 12-6](#)
- [Default Settings for Instant Access, page 12-6](#)
- [How to Configure Instant Access, page 12-7](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.

Prerequisites for Instant Access

- An IA parent—A VSS-mode Catalyst 6800 switch or a VSS-mode Cisco Catalyst 6880-X switch or a VSS-mode Catalyst 6500 switch equipped with a [Supervisor Engine 2T](#) and one or more [WS-X6904-40G-2T](#), [C6800-32P10G/XL](#), [C6800-16P10G/XL](#), and [C6800-8P10G/XL](#) switching modules, configured to support 1/10GE links.
- IA clients—[Catalyst 6800ia access switches](#)
See this publication for more information:
http://www.cisco.com/en/US/prod/collateral/switches/ps10902/ps715/ps13198/data_sheet_c78-728230.html
- See this publication for more information about Instant Access:
http://www.cisco.com/en/US/prod/collateral/switches/ps10902/ps715/ps13198/white_paper_c11-728265.html

- For image download during ISSU upgrade, remove **ip tftp source-interface** config on IA Parent, and add a static route to copy the image through **mgmt** interface.

Restrictions for Instant Access

- The IA parent must operate in VSS mode.



Note

- You can enable VSS mode on a single chassis to support IA clients.
- The VSS Quad-Sup SSO (VS4O) feature is supported with IA clients from Release 15.1(2)SY2.

- The IA parent-client connection is supported on links between WS-X6904-40G-2T, C6800-32P10G/XL, C6800-16P10G/XL, and C6800-8P10G/XL switching modules 1/10GE ports and Catalyst 6800ia access switches 10GE ports.
 - You can use up to 8 IA client 10GE ports in the IA parent-client link. See this document for information about the port configuration for WS-X6904-40G-2T, C6800-32P10G/XL, C6800-16P10G/XL, and C6800-8P10G/XL switching modules:
http://www.cisco.com/en/US/prod/collateral/switches/ps5718/ps708/white_paper_c11-696669.html
 - IA client 10-Gigabit Ethernet ports require no configuration.
 - UDLD, LLDP, and CDP are not supported on the IA parent-client link.
 - IA does not use STP on the IA parent-client connection.
 - Use only XL based modules for scale FEX QoS configuration to prevent issues with TCAM (ternary content-addressable memory) utilization. When QoS policy is configured on 1500 FEX host ports, the first 511 interfaces share the TCAM utilization. But, remaining ports will start using new TCAM entries for each interface and will exhaust non-XL TCAM utilization.
- IA client maximum values:

Value Description:	Maximum Value
Maximum IA client ports	2016 ports across 42 Catalyst 6800ia access switches Note The Supervisor Engine 2T module can support only up to 1200 FEX host ports with 15.2(1)SY and 15.2(1)SY0a and up to 1500 FEX host ports with 15.2(1)SY1 and later.
Maximum IA client switches	42 (defined by IA client FEX number 1–42 range.) Note The Supervisor Engine 2T module can support only up to 25 IA client switches with 15.2(1)SY and 15.2(1)SY0a and up to 32 IA client switches with 15.2(1)SY1 and later.

Value Description:	Maximum Value
Maximum Catalyst 6800ia access switches per IA client stack	5 • An IA client stack acts as single switch unit. • Instant access only supports connection with stacking cables to form a stack. • With an IA client that has multiple Catalyst 6800ia access switches, the switches in the stack assign incrementing switch numbers to themselves (automatic stacking capability). • If you add Catalyst 6800ia access switches to a configured IA client, the additional switches assign incrementing switch numbers to themselves. • The IA client configuration does not persist if the access switch number changes.
Maximum number of VLANs per IA client stack	You can set upto 1,000 VLANs, we recommend to set not more than 20 VLANs per FEX.
Maximum Number of Port Channels	512

- IA client ports do not support these features:
 - Configuring EtherChannels with a combination of FEX Ports using different FEX-IDs or a combination of FEX host port and an IA parent linecard port is not supported. However, FEX host port channel from the same FEX is supported.
 - FEX host port EtherChannel load balancing is not supported.
 - Port debounce timer
 - UDLR tunnel ARP and IGMP proxy
 - Uni-Directional Link Routing (UDLR)
 - IEEE 802.1Q tunneling
 - VLAN Mapping
 - VLAN Translation
 - IEEE 802.1Q custom ethertypes
 - L2PT - Layer 2 protocol tunneling
 - L2PT - Layer 2 protocol tunneling on trunk ports
 - 802.1ad tunneling
 - Port security on 802.1Q tunnel ports
 - Private VLANs (PVLAN)
 - VACL capture
 - Per-VLAN load balancing for Advanced QinQ service mapping
 - Cisco TrustSec NDAC (Network Device Admission Control)
 - Cisco TrustSec confidentiality and integrity with MACsec (IEEE 802.1AE)
 - Cisco TrustSec identity port mapping
 - Network edge authentication topology (NEAT)

- AutoQoS
- MQC queuing policy support
- QoS aggregated DSCP values for WRED
- QoS aggregated precedence values for WRED
- Class based weighted fair queuing (CBWFQ)
- Class-based shaping
- DiffServ-compliant dWRED
- Diffserv-compliant WRED
- Selective packet discard (SPD)
- Weighted fair queueing (WFQ)
- Weighted RED (WRED)
- QoS policer rate increase to 256G
- Ethernet over MPLS (EoMPLS) - IEEE 802.1q Tag Stacking
- H-VPLS N-PE redundancy for QinQ access
- Connectivity fault management (CFM)
- Ethernet connectivity fault management (E-CFM)
- Ethernet local management interface (LMI) at provider edge (PE)
- Ethernet operations, administration, and Maintenance (OAM)
- Ethernet-OAM 3.0: CFM over BD, Untagged
- IEEE 802.1ag - D8.1 standard Compliant CFM, Y.1731 multicast LBM / AIS / RDI / LCK, IP SLA for Ethernet
- IEEE 802.1ag Compliant CFM (D8.1)
- To use an IA client port as a SPAN destination, add the IA client port VLAN to the SPAN allowed VLAN list with the **switchport trunk allowed vlan** command.
- When FEX IA parent-client link portchannel is configured as SPAN source in Tx direction or both directions, the SPAN destination should not be on the same FEX. This is applicable for both stacked and standalone FEX.
- IA client port QoS:

- Configure ingress QoS on the IA parent port-channel interface.
- The egress QoS configuration on IA client ports is not configurable.
- Port architecture (Rx/Tx): 1p3q3t

1p3q3t strict-priority egress queue (queue 1)		CoS	Not supported
		DSCP	32, 33, 40–47
		Tail-drop	100% (nonconfigurable)
		WRED-drop	Not supported
1p3q3t standard egress queue 2 (high priority)	Threshold 1	CoS	Not supported
		DSCP	16–23, 26–31, 34–39
		Tail-drop	Disabled; 100%
		WRED-drop	Not supported
	Thresholds 2	CoS	Not supported
		DSCP	24
		Tail-drop	Disabled; 100%
		WRED-drop	Not supported
	Thresholds 3	CoS	Not supported
		DSCP	48–63
		Tail-drop	Disabled; 100%
		WRED-drop	Not supported
1p3q3t standard egress queue 3 (medium priority)	Threshold 1	CoS	Not supported
		DSCP	25
		Tail-drop	Disabled; 70%
		WRED-drop	Not supported
	Threshold 2	CoS	Not supported
		DSCP	None.
		Tail-drop	Disabled; 100%
		WRED-drop	Not supported
	Thresholds 3	CoS	Not supported
		DSCP	0–7
		Tail-drop	Disabled; 100%
		WRED-drop	Not supported

1p3q3t standard egress queue 4 (lowest priority)	Threshold 1	CoS	Not supported
		DSCP	8, 9, 11, 13, 15
		Tail-drop	Disabled; 70%
		WRED-drop	Not supported
	Threshold 2	CoS	Not supported
		DSCP	10, 12, 14
		Tail-drop	Disabled; 100%
		WRED-drop	Not supported
	Threshold 3	CoS	Not supported
		DSCP	None.
		Tail-drop	Disabled; 100%
		WRED-drop	Not supported

- Maximum dot1x hosts supported with IBNS 1.0 configuration is 1000.

Information About Instant Access

The Instant Access (IA) feature supports multiple Catalyst 6800ia access switches that function as clients of the IA parent switch. The IA parent and client switches form a single extended switch with a single management domain, managed by the IA parent.

The IA parent uses the Satellite Discovery Protocol (SDP) and the Satellite Registration Protocol (SRP) to automatically discover IA clients when they connect and monitor the IA client-parent link. The IA parent upgrades the IA client software image if it is not the same as the parent FEX Image Bundle.

The IA parent features are applied to IA client FEX ports. The IA clients do not perform any local packet forwarding. All traffic originating from IA client ports are sent to the IA parent, which makes all the switching and forwarding decisions.

The IA client switches support the following online diagnostic tests:

- [TestFexModeLoopback, page 1-4](#)
- [TestFexFabricLinkStatus, page 1-39](#)

Default Settings for Instant Access

None.

How to Configure Instant Access

- [Configure Instant Access Staggered Initialization Mode, page 12-7](#)
- [Enable FEX Auto-Config, page 12-7](#)
- [Enable IA Client Preprovisioning, page 12-8](#)
- [Configure Instant Access Port-Channel Interfaces, page 12-8](#)
- [Configure Instant Access Channel Groups, page 12-9](#)
- [Identify Connected IA Client Stack Modules, page 12-9](#)
- [Configure IA Clients, page 12-13](#)
- [Display or Clear SDP and SRP Traffic, page 12-13](#)
- [Upgrade FEX using In-Service Software Upgrade \(ISSU\) Process, page 12-13](#)
- [Configure Optional Parameters for an IA Client, page 12-14](#)

Configure Instant Access Staggered Initialization Mode

Instant Access staggered initialization mode avoids any excessively high CPU utilization that might occur if multiple IA clients attempt to initialize simultaneously. To configure Instant Access staggered initialization mode, perform this task:

Command	Purpose
<code>Tqwwgt*eqphki+%hgz uvciigt <i>fgnc{axcnwg}</i></code>	Configures Instant Access staggered initialization mode. The <i>delay_value</i> can be 0 through 500. Note The recommended <i>delay_value</i> is 120.

This example shows how to configure Instant Access staggered mode:

```
Tqwwgt%eqphkiwtg"vgtokpcn"  
Tqwwgt*eqphki+%hgz"uvciigt"342"
```

Enable FEX Auto-Config

FEX Auto-config mode allows increased scalability with reduced configuration. Configuration using Auto-config includes FEX ID selection, Port-channel ID selection, converting RSL port to FEX-fabric mode, and RSL port bundling.

To enable FEX auto-config, perform this task:

Command	Purpose
<code>Tqwwgt*eqphki+%hgz"cwvq/eqphki</code>	Enable FEX auto-config support globally.

This example shows how to configure FEX auto-config mode:

```
Tqwwgt%eqphkiwtg"vgtokpcn"  
Tqwwgt*eqphki+%hgz"cwvq/eqphki
```

Enable IA Client Preprovisioning

To allow IA client port configuration before the IA client is connected, perform this task:

Command	Purpose
<pre>Tqvwgt% oqfwng rtqpkukqp etgcvg"hgz hgzapwodgt" v{rg }E8:22KC/6:HRF ~ E8:22KC/6:VF"~"E8:22KC/6:HRFT"~" YU/E5782EZ/34RF/U"~"YU/E5782EZ/:ZRF/U; "]unqv uykvejapwodgt_</pre>	Enables IA client port configuration before the IA client is connected. Enter the slot switch_number keyword and argument to enable configuration of a specific IA client stack member or an additional stack member before it is added to the IA client stack.

WS-C3560CX-8XPD-S and WS-C3560CX-12PD-S will undergo a number of reloads as FEX client before coming online based on the following conditions:

- Reload1: To convert itself from switch mode to FEX mode on receiving the SDP packet from controller
- Reload2: If a mismatch of IOS version occurs between FEX controller and FEX client, the FEX client downloads the image from controller and boots up.
- Reload3: If a mismatch of MTU occurs between FEX controller and FEX client, the FEX client reloads again to change the MTU of FEX host ports.

Configure Instant Access Port-Channel Interfaces

To create a port channel interface to support IA clients, perform this task:

	Command	Purpose
Step 1	<pre>Tqvwgt*eqphki+% kpvgtthceg rqtv/ejcppgn itqwrapwodgt"</pre>	Creates the port channel interface. The <i>group_number</i> can be 1 through 512, up to a maximum of 512 port-channel interfaces (42 port-channel interfaces can be used to support IA clients). Note If desired, you can configure the <i>group_number</i> to match the IA client FEX number.
Step 2	<pre>Tqvwgt*eqphki/kh+% "uykvejrgtv"</pre>	Configures the port channel interface for Layer 2 switching.
Step 3	<pre>Tqvwgt*eqphki/kh+% "uykvejrgtv"oqfg"hgz/hcdtke"</pre>	Configures the port channel interface to support IA clients.
Step 4	<pre>Tqvwgt*eqphki/kh+% "hgz"cuugekcvgt" hgzapwodgt"</pre>	Configures the IA client FEX number. • The valid value range is 101–199. • Maximum of 42 IA client FEX numbers.

This example shows how to create port channel interface 1 and configure it to support IA FEX number 118:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+% "kpvgtthceg"rqtv/ejcppgn"33: "
Tqvwgt*eqphki/kh+% "uykvejrgtv"
```

```
Tqvwgt*eqphki/kh+% "uykvejrgtv"oqfg"hgz/hcdtke"
Tqvwgt*eqphki/kh+% "hgz"cuuqekcvg"33: "
```

Configure Instant Access Channel Groups

To configure channel groups to support IA clients, perform this task for the 10 Gigabit Ethernet LAN ports that connect to IA clients:

	Command	Purpose
Step 1	<code>Tqvwgt*eqphki+% kpvgtthceg tcpig first_10ge_port, last_10ge_port</code>	Selects the ports to configure.
Step 2	<code>Tqvwgt*eqphki/kh+% "uykvejrgtv"</code>	Configures the port channel interface for Layer 2 switching.
Step 3	<code>Tqvwgt*eqphki/kh+% "uykvejrgtv"oqfg"hgz/hcdtke"</code>	Configures the port channel interface to support IA clients.
Step 4	<code>Tqvwgt*eqphki/kh+% "ejcppgn/itqwr"itqwrapwodgt"oqfg"qp"</code>	Configures the LAN port in an IA Client port channel and configures the mode as on .



Note

More links can be added to the channel group at any time.

This example shows how to configure 10 Gigabit Ethernet ports 1/2/5 and 2/2/5 into port channel 118 with mode **on**:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+% "kpvgtthceg"tcpig"vgpikicdkvgvjgtpgv"31417. "41417
Tqvwgt*eqphki/kh+% "uykvejrgtv"
Tqvwgt*eqphki/kh+% "uykvejrgtv"oqfg"hgz/hcdtke"
Tqvwgt*eqphki/kh+% "ejcppgn/itqwr"33: "oqfg"qp"
Tqvwgt*eqphki/kh+% "gpf"
```

This example shows how to verify the IA configuration when the IA client is connected:

```
Tqvwgt%"ujqy"hgz"33: "fgvckn"
HGZ<"33: "Fguetkrvkqp<"HGZ233: "uvcvg<"qpnkpg"
HGZ"xgtukqp<"xgtukqpauvtkpi"
Gzvpgfgt"Oqfgn<"E8:22KC/6:VF. "Gzvpgfgt"Ugtkcn<"ugtkcnapwodgt"
HER"tgcf{<"{gu"
Kocig"Xgtukqp"Ejgem<"gphqtegf"
Hcdtke"Rqtvejcppgn"Rqtvu<"4"
Hcdtke"rqtv"hqt"eqpvtqn"vtchhke<"Vg31417"
Hcdtke"kpvgtthceg"uvcvg<"
Rq42"/"Kpvgtthceg"Wr0"
Vg31417"/"Kpvgtthceg"Wr0"uvcvg<"dqwpf"
Vg41417"/"Kpvgtthceg"Wr0"uvcvg<"dqwpf"
```

Identify Connected IA Client Stack Modules

- [Identify IA Client Stack Modules by Serial Number, page 12-10](#)
- [Identify IA Client Modules by Beacon LED, page 12-10](#)
- [Easy FEX, page 12-10](#)

Renumbering FEX Switch-ID

The renumbering of IA clients can be managed using switch-id allocation from controller, after stack boot up. Also, a priority can be assigned to the FEX members.

The following conditions must exist for successful execution of FEX switch-id allocation:

- For renumbering the source slot should be online and the target slot should be offline.
- If the source slot FEX type is different than target slot FEX type, you would lose the interface configurations if you proceed with renumbering.
- Same target slot cannot be used for multiple source slot renumbering.
- You can enter multiple renumbering entries along with different swapping scenarios.
- When priority is modified for a member IA, the whole stack will reload.

To renumber FEX switch-id, perform this task:

	Command	Purpose
Step 1	<code>Tqwwgt% oqfwng"rtqpkukqp"wrfcvg"hgz" fex_id</code>	Enters into switch renumber sub-mode.
Step 2	<code>Tqwwgt*gzge/hgz/wrfcvg+% "tgpwodgt" uqwtegaunqv"vq" target_slot</code>	Renumbers <i>source_slot</i> to <i>target_slot</i>
Step 3	<code>Tqwwgt*gzge/hgz/wrfcvg+% "rtkqtkv{ "source_slot value number</code>	Assigns the mentioned priority <i>number</i> to the <i>source_slot</i> .
Step 4	<code>Tqwwgt*gzge/hgz/wrfcvg+% "eqookv</code>	Commits all entries entered under <i>exec-fex-update</i> sub-mode.

To renumber FEX switch-id when scale is set to maximum FEX slots, perform this task:

	Command	Purpose
Step 5	<code>Tqwwgt% oqfwng"rtqpkukqp"wrfcvg"hgz" hgzakf" vgor/xunqv/cnnqy" gpcdng</code>	When maximum vslots are already allocated, temp-vslot-allow will enable the temporary vslot module to come online.
Step 1	<code>Tqwwgt% oqfwng"rtqpkukqp"wrfcvg"hgz" fex_id</code>	Enters into switch renumber sub-mode.
Step 2	<code>Tqwwgt*gzge/hgz/wrfcvg+% "tgpwodgt" uqwtegaunqv"vq" target_slot</code>	Renumbers <i>source_slot</i> to <i>target_slot</i>
Step 3	<code>Tqwwgt*gzge/hgz/wrfcvg+% "rtkqtkv{ "source_slot value number</code>	Assigns the mentioned priority <i>number</i> to the <i>source_slot</i> .
Step 4	<code>Tqwwgt*gzge/hgz/wrfcvg+% "eqookv</code>	Commits all entries entered under <i>exec-fex-update</i> sub-mode.
Step 5	<code>Tqwwgt% oqfwng"rtqpkukqp"wrfcvg"hgz" hgzakf" vgor/xunqv/cnnqy" fkucdng</code>	Disables the temporary vslot module to go offline.

This example shows how to identify when a particular temporary FEX vslot is online:

```

VGF%"ujqy"hgzu{uvgo"rnevqhto"wucig"
HGZ"kf"wucig"fgvcknu
" "HgZ/kfu"kpwwg<"372

```

```

""HgZ/kfu"qpnkpg<"372
""Vqvcn""""Wugf""""Htgg
""////////""""////////
""64""""3""""63"
HGZ"unqv"wucig"fvgcknu
""HGZ/kf""""Uykvej/kf""""Xunqv""Runqv""Uvcvwu
""////////""""////////""""////////
""""372""""5""""73""""4""""Kp/wug""""
""""372""""5""""74""""5""""Kp/wug""""
""""372""""5""""75""""7""""Tgugtvgf""""
""""372""""5""""77""""6""""Kp/wug""""
""""372""""5"""";4""""3""""Vgor/Kp/wug"
"Vqvcn""""Wugf""""Tgugtvgf""Vgor/Wug1Htgg""Htgg
"////////""""////////""""////////
"69""""5""""3""""316""""64""
Ewttgppv"Vgor"xunqv"cnnqygf"HGZu<"372
Ewttgppv"Vgor"XUNQV"wucig<
////////
"HGZ"372"oqfwng"3
""""
HGZ"rqtvu"wucig"fvgcknu
""HGZ/kf""""Uykvej/kf""""Rqtvu
""////////""""////////
""""372""""5""""3;4
""Vqvcn""""Wugf""""Htgg
""////////""""////////
""4238""""3;4""""3:46
""""
Uvcem"ogodgtu"wucig"fvgcknu
""HGZ/kf""""Uykvej/kf""""Wugf""""Htgg

```

This example verifies the active entries under sub-mode and also the FEX IDs on which "temp-vslot-allow" is enabled.

```

Tqwvgt*gzge/hgz/wrfcvg+%ujqy
Ewttgppv"oqfwng"tgpwodgt"ocrrkpiu"hqt"HGZ"323
////////
""tgpwodgt"3"vg"4"
Ewttgppv"oqfwng"Rtkqtkv{"ocrrkpiu"hqt"HGZ"323
////////
""rtkqtkv{"3"xcnwg"37
Vgor"xunqv"cnnqygf<[GU
Ewttgppv"Vgor"xunqv"cnnqygf"HGZu<323
VGTO/XUU/HGZ*gzge/hgz/wrfcvg+%

```

Configure IA Clients

The configuration for IA clients can be entered on the IA parent before or after the IA clients are connected. IA client 10-Gigabit Ethernet ports require no configuration. IA client Gigabit Ethernet ports use this format:

gigabitethernet/fex_number/access_switch_number/0/port_number

- *fex_number*—The IA client FEX number:
 - Maximum of 42 IA FEX numbers.
 - The valid value range is 101–199.
- *access_switch_number*—The access switch number:
 - The valid value range is 1-5.
 - Multiple-switch stacks assign incrementing switch numbers to themselves.
 - See the [“Identify Connected IA Client Stack Modules”](#) section on page 12-9.
- The third interface parameter is always zero.
- The *port_number* valid value range is 1–48.



Note

- IA client configuration does not persist if the access switch number changes.
- The interface-range configuration mode supports IA clients ports (see [“How to Configure a Range of Interfaces”](#) section on page 10-2)

Display or Clear SDP and SRP Traffic

To display the counters that record the SDP packet traffic on IA client 118, enter the following command:

```
Tqwgvt% "ujqy"hgz"33 : "rtqvqeqn" ~ "kpen"UFR "
" " " 352 "UFR"rmvu"ugpv
" " " 34 ; "UFR"rmvu"tgegkxgf
" " " 352 "UFR"rmvu"ugpv
" " " 34 ; "UFR"rmvu"tgegkxgf
```



Note

The command displays a sent and received value for each link in the IA channel group.

To clear the protocol counters, enter the **clear fex_fex_number {sdp | srp}** command.

Upgrade FEX using In-Service Software Upgrade (ISSU) Process

To upgrade the software image of the FEX hosts using ISSU process, perform the following steps:

	Command	Purpose
Step 1	Tqwgvt% kuuw"nqcfxgtukqp <i>device:filename</i>	Initiates the ISSU process.
Step 2	Tqwgvt% kuuw"twpxgtukqp	Forces a switchover.

	Command	Purpose
Step 3	<code>Tqwvgt% "kuuw" ceegrvxgtukqp</code>	Stops the rollback timer and ensures that the software upgrade is not automatically aborted during the ISSU process.
Step 4	<code>Tqwvgt% "kuuw" twpxgtukqp "hgz" > "fex-id all"@</code>	Forces a switchover of the active to the standby processor and starts the image download and upgrade procedure on the FEX (6800IA). The FEX initiates the image download from the new software bundle of the Sup2T. If you are using FEX stacks, the stack master initiates the image download for its members.
Step 5	<code>Tqwvgt% "kuuw" eqookvxgtukqp</code>	Upgrades the VSS standby chassis and completes the ISSU process.
Step 6	<code>Tqwvgt% "ujqy" "kuuw" uvvcvg "fgvckn</code>	Displays the state and the current version of the RPs after the ISSU process.

Configure Optional Parameters for an IA Client

- [Enter the IA Client Configuration Mode, page 12-14](#)
- [Configure a Description, page 12-14](#)
- [Configure the Custom Location Type Feature, page 12-15](#)
- [Configure MTU, page 12-15](#)

Enter the IA Client Configuration Mode

To enter the IA client configuration mode, perform this task:

Command	Purpose
<code>Tqwvgt*eqphki+% "hgz" fex_number</code>	Enters IA client configuration mode. Note Sets the IA client description to FEX <i>fex_number</i> .

Configure a Description

To configure a description for the IA client or for each module in the IA client stack, perform this task:

Command	Purpose
<code>Tqwvgt*eqphki/hgz+% "]" oqfwng" oqfwngapwodgt_ "fguetkrvkqp" fguetkrvkqpauvtkpi"</code>	Configures a description for the IA FEX number or for a module in the IA client stack.

Configure the Custom Location Type Feature

You can configure the custom location type feature for the IA client in IA client configuration mode. See these publications for information about the **location** command:

<http://www.cisco.com/en/US/docs/ios-xml/ios/cether/command/ce-cr-book.html>

<http://www.cisco.com/en/US/docs/ios-xml/ios/cether/command/ce-el.html>



Note

The **location** commands support the optional **fex-location** keyword for IA clients.

Configure MTU

You can configure MTU on the IA FEX using the **mtu** command in fex config mode. In an IA client stack, the configured MTU value is applied to all the host members in the stack.

To configure MTU for an IA client, perform this task:

Command	Purpose
Tqwwgt% eqphkiwtg vgtokpcn	Enters the global configuration mode.
Tqwwgt*eqphki+% hgz 332	Enters IA client configuration mode.
Tqwwgt*eqphki/hgz+% ovw 4222	Resets the MTU value for the FEX system. All the FEX ports will be set to use the new MTU value. The default MTU value for a FEX host port is 9216. Note For Cisco Catalyst C6840 series switch, the maximum supported MTU for native interface is 9154. The default MTU value is 1500. If the MTU of peer (Catalyst 6880 or Sup2T) is configured higher than 9154, the packet will not be processed. When using existing configuration from a Catalyst 6880 or Sup2T, ensure that the MTU is reset or removed.
Tqwwgt% gpf	Exits the global configuration mode. Note Reload the FEX for the MTU change to take effect.

If you want to avoid reloading the FEX, you can configure an explicit connectionless network service (CLNS) MTU size on the IA client and peer ports as shown in the following example:

```
Tqwwgt%eqphkiwtgvgtokpcn"
Tqwwgt*eqphki+%kpvgthceg"kpvgthceg"lki33:131213"
Tqwwgt*eqphki/kh+%kr"tqwwgt"kuku"
Tqwwgt*eqphki/kh+%enpu"ovw"36;9"
```




Configuring EnergyWise

EnergyWise is a Cisco energy management architecture that provides a common approach to configuring, reporting and managing the power consumed by Cisco switches and attached devices. With Cisco EnergyWise, power can be managed on a network, sub-network or network element level.

Release	Feature Modification
12.2(33)SX14	EnergyWise Phase 2 introduced on Catalyst 6500 Series switches
15.0(1)SY1	EnergyWise Phase 2.6 introduced on Catalyst 6500 Series switches
15.1(1)SY1	EnergyWise Phase 2.7 introduced on Catalyst 6500 Series switches

For hardware compatibility matrices, new feature information, and to understand EnergyWise release numbering, see the Cisco EnergyWise release notes:

http://www.cisco.com/en/US/products/ps10195/prod_release_notes_list.html

EnergyWise configuration guides and EnergyWise orchestrator configuration guides are located at the following URL:

http://www.cisco.com/en/US/products/ps10195/products_installation_and_configuration_guides_list.html

Additional Cisco EnergyWise documents, such as White Papers, Data Sheets, FAQs, and are located at the following URL:

<http://www.cisco.com/en/US/products/ps10195/>



Power Management

- [Power Management Overview, page 14-1](#)
- [How to Enable or Disable Power Redundancy, page 14-2](#)
- [How to Power Modules Off and On, page 14-3](#)
- [How to Display System Power Status, page 14-3](#)
- [How to Power Cycle Modules, page 14-5](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Power Management Overview

In systems with redundant power supplies, both power supplies must be of the same wattage. The Catalyst 6500 series switches allow you to use both AC-input and DC-input power supplies in the same chassis. For detailed information on supported power supply configurations, see the *Catalyst 6500 Series Switch Installation Guide*.

The modules have different power requirements, and some configurations require more power than a single power supply can provide. The power management feature allows you to power all installed modules with two power supplies. However, redundancy is not supported in this configuration because the total power drawn from both power supplies is at no time greater than the capability of one supply. Redundant and nonredundant power configurations are described in the following sections.

How to Enable or Disable Power Redundancy

To disable or enable redundancy (redundancy is enabled by default) from global configuration mode, enter the **power redundancy-mode combined | redundant** commands. You can change the configuration of the power supplies to redundant or nonredundant at any time.

To disable redundancy, use the **combined** keyword. In a nonredundant configuration, the power available to the system is the combined power capability of both power supplies. The system powers up as many modules as the combined capacity allows. However, if one power supply fails and there is not enough power for all of the previously powered-up modules, the system powers down those modules.

To enable redundancy, use the **redundant** keyword. In a redundant configuration, the total power drawn from both power supplies is not greater than the capability of one power supply. If one supply malfunctions, the other supply can take over the entire system load. When you install and power up two power supplies, each concurrently provides approximately half of the required power to the system. Load sharing and redundancy are enabled automatically; no software configuration is required.

To view the current state of modules and the total power available for modules, enter the **show power** command (see the “[How to Display System Power Status](#)” section on page 14-3).

Table 14-1 describes how the system responds to changes in the power supply configuration.

Table 14-1 Effects of Power Supply Configuration Changes

Configuration Change	Effect
Redundant to nonredundant	- System log and syslog messages are generated. - System power is increased to the combined power capability of both power supplies. - Modules marked <i>power-deny</i> in the show power oper state field are brought up if there is sufficient power.
Nonredundant to redundant (both power supplies must be of equal wattage)	- System log and syslog messages are generated. - System power is decreased to the power capability of one supply. - If there is not enough power for all previously powered-up modules, some modules are powered down and marked as <i>power-deny</i> in the show power oper state field.
Equal wattage power supply is inserted with redundancy enabled	- System log and syslog messages are generated. - System power equals the power capability of one supply. - No change in module status because the power capability is unchanged.
Equal wattage power supply is inserted with redundancy disabled	- System log and syslog messages are generated. - System power is increased to the combined power capability of both power supplies. - Modules marked <i>power-deny</i> in the show power oper state field are brought up if there is sufficient power.
Higher or lower wattage power supply is inserted with redundancy enabled	- System log and syslog messages are generated. - The system will operate in a non-redundant combined mode.

Table 14-1 Effects of Power Supply Configuration Changes (continued)

Configuration Change	Effect
Higher or lower wattage power supply is inserted with redundancy disabled	- System log and syslog messages are generated. - System power is increased to the combined power capability of both power supplies. - Modules marked <i>power-deny</i> in the show power oper state field are brought up if there is sufficient power.
Power supply is removed with redundancy enabled	- System log and syslog messages are generated. - No change in module status because the power capability is unchanged.
Power supply is removed with redundancy disabled	- System log and syslog messages are generated. - System power is decreased to the power capability of one supply. - If there is not enough power for all previously powered-up modules, some modules are powered down and marked as <i>power-deny</i> in the show power oper state field.
System is booted with power supplies of different wattage installed and redundancy enabled	- System log and syslog messages are generated. - The system does not allow you to have power supplies of different wattage installed in a redundant configuration. The lower wattage supply shuts down.
System is booted with power supplies of equal or different wattage installed and redundancy disabled	- System log and syslog messages are generated. - System power equals the combined power capability of both power supplies. - The system powers up as many modules as the combined capacity allows.

How to Power Modules Off and On

To power modules off and on from the CLI, perform this task:

	Command	Purpose
Step 1	<code>Tqvvgt% "eqphkiwtg"vgtokpcn</code>	Enters global configuration mode.
Step 2	<code>Tqvvgt*eqphki+% "rqygt"gpdcng"oqfwng" unqvapwodgt"</code>	Powers a module on.
Step 3	<code>Tqvvgt*eqphki+% "pq"rqygt"gpdcng"oqfwng" unqvapwodgt"</code>	Powers a module off.



Note

When you enter the **no power enable module slot** command to power down a module, the module's configuration is not saved.

This example shows how to power on the module in slot 3:

```
Tqvvgt% "eqphkiwtg"vgtokpcn
Tqvvgt*eqphki+% "rqygt"gpdcng"oqfwng"5"
```



```

uykvej "3" rdygt/urrrn{ "3<"
"rdygt/urrrn{ "3"hcp/hckn<"QM
"rdygt/urrrn{ "3"rdygt/kprwv<"CE"jkij
"rdygt/urrrn{ "3"rdygt/qwvrvw/oqfg<"jkij
"rdygt/urrrn{ "3"kpeqorcvkdng"ykvj"hcp<"QM
"rdygt/urrrn{ "3"rdygt/qwvrvw/hckn<"QM
Tqwvgt%"ujqy"gpdktpogpv"uvvuw"rdygt/urrrn{ "4
uykvej "3" rdygt/urrrn{ "4<"
"rdygt/urrrn{ "4"hcp/hckn<"QM
"rdygt/urrrn{ "4"rdygt/kprwv<"CE"jkij
"rdygt/urrrn{ "4"rdygt/qwvrvw/oqfg<"jkij
"rdygt/urrrn{ "4"kpeqorcvkdng"ykvj"hcp<"QM
"rdygt/urrrn{ "4"rdygt/qwvrvw/hckn<"QM

```

How to Power Cycle Modules

```

[qw"ecp"rdygt"e{eng"*tgugv+"c"nkpq"ectf"oqfwng"d{"gpvgtkpi"vjg"jy/oqfwng"oqfwng"}oqf"%i"
tgugv"eqoocpf0"Vjg"oqfwng"rdygtu"qhh"hqt"7"ugeqpfu."cpf"vjgp"rdygtu"qp0

```



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Environmental Monitoring

- [Environmental Monitoring Overview, page 15-1](#)
- [How to Determine Sensor Temperature Thresholds, page 15-2](#)
- [How to Monitor the System Environmental Status, page 15-5](#)
- [Information About LED Environmental Indications, page 15-7](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Environmental Monitoring Overview

Environmental monitoring of chassis components provides early-warning indications of possible component failures, which ensures a safe and reliable system operation and avoids network interruptions. This section describes the monitoring of these critical system components, which allows you to identify and rapidly correct hardware-related problems in your system.

How to Determine Sensor Temperature Thresholds

The system sensors set off alarms based on different temperature threshold settings. Use the **show environment alarm threshold** command to display the sensor temperature thresholds:

```
Tqwgvt@"ujqy"gpcktqpgpv"cncto"vjtgujqnf"
gpcktqpgpvcn"cncto"vjtgujqnf<

rqtygt/uwrn{"3"hcp/hckn<"QM
"vjtgujqnf"%3"hqt"rqtygt/uwrn{"3"hcp/hckn<"
"*ugpuqt"xcnwg"#?"HCNUG"+"ku"u{uvgo"okpgt"cncto
rqtygt/uwrn{"3"rqtygt/qwvrwv/hckn<"QM
"vjtgujqnf"%3"hqt"rqtygt/uwrn{"3"rqtygt/qwvrwv/hckn<"
"*ugpuqt"xcnwg"#?"HCNUG"+"ku"u{uvgo"okpgt"cncto
rqtygt/uwrn{"3"rqtygt/qwvrwv/oqfg<"jkij
"vjtgujqnf"%3"hqt"rqtygt/uwrn{"3"rqtygt/qwvrwv/oqfg<"
"*ugpuqt"xcnwg">"3"+"ku"u{uvgo"okpgt"cncto
rqtygt/uwrn{"3"kpeqorcvkdng"ykvj"hcp<"QM
"vjtgujqnf"%3"hqt"rqtygt/uwrn{"3"kpeqorcvkdng"ykvj"hcp<"
"*ugpuqt"xcnwg"#?"HCNUG"+"ku"u{uvgo"okpgt"cncto
rqtygt/uwrn{"4"hcp/hckn<"QM
"vjtgujqnf"%3"hqt"rqtygt/uwrn{"4"hcp/hckn<"
"*ugpuqt"xcnwg"#?"HCNUG"+"ku"u{uvgo"okpgt"cncto
rqtygt/uwrn{"4"rqtygt/qwvrwv/hckn<"QM
"vjtgujqnf"%3"hqt"rqtygt/uwrn{"4"rqtygt/qwvrwv/hckn<"
"*ugpuqt"xcnwg"#?"HCNUG"+"ku"u{uvgo"okpgt"cncto
rqtygt/uwrn{"4"rqtygt/qwvrwv/oqfg<"jkij
"vjtgujqnf"%3"hqt"rqtygt/uwrn{"4"rqtygt/qwvrwv/oqfg<"
"*ugpuqt"xcnwg">"3"+"ku"u{uvgo"okpgt"cncto
rqtygt/uwrn{"4"kpeqorcvkdng"ykvj"hcp<"QM
"vjtgujqnf"%3"hqt"rqtygt/uwrn{"4"kpeqorcvkdng"ykvj"hcp<"
"*ugpuqt"xcnwg"#?"HCNUG"+"ku"u{uvgo"okpgt"cncto
hcp/vtc{"3"hcp/hckn<"QM
"vjtgujqnf"%3"hqt"hcp/vtc{"3"hcp/hckn<"
"*ugpuqt"xcnwg"??"3"+"ku"u{uvgo"okpgt"cncto
qrgtcvkpi"engem"eqwpv<"4
"vjtgujqnf"%3"hqt"qrgtcvkpi"engem"eqwpv<"
"*ugpuqt"xcnwg">"4"+"ku"u{uvgo"okpgt"cncto
"vjtgujqnf"%4"hqt"qrgtcvkpi"engem"eqwpv<"
"*ugpuqt"xcnwg">"3"+"ku"u{uvgo"oclt"cncto
qrgtcvkpi"XVV"eqwpv<"5
"vjtgujqnf"%3"hqt"qrgtcvkpi"XVV"eqwpv<"
"*ugpuqt"xcnwg">"5"+"ku"u{uvgo"okpgt"cncto
"vjtgujqnf"%4"hqt"qrgtcvkpi"XVV"eqwpv<"
"*ugpuqt"xcnwg">"4"+"ku"u{uvgo"oclt"cncto
qrgtcvkpi"hcp"eqwpv<"3
"vjtgujqnf"%3"hqt"qrgtcvkpi"hcp"eqwpv<"
"*ugpuqt"xcnwg">"3"+"ku"u{uvgo"okpgt"cncto
XVV"3"qwnvgv"vgorgtcvwtg<"59E
"vjtgujqnf"%3"hqt"XVV"3"qwnvgv"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"322E+"ku"u{uvgo"okpgt"cncto
"vjtgujqnf"%4"hqt"XVV"3"qwnvgv"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"337E+"ku"u{uvgo"oclt"cncto
XVV"3"QM<"QM
"vjtgujqnf"%3"hqt"XVV"3"QM<"
"*ugpuqt"xcnwg"#?"HCNUG"+"ku"u{uvgo"okpgt"cncto
XVV"4"qwnvgv"vgorgtcvwtg<"5;E
"vjtgujqnf"%3"hqt"XVV"4"qwnvgv"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"322E+"ku"u{uvgo"okpgt"cncto
"vjtgujqnf"%4"hqt"XVV"4"qwnvgv"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"337E+"ku"u{uvgo"oclt"cncto
XVV"4"QM<"QM
"vjtgujqnf"%3"hqt"XVV"4"QM<"
```



```

" *ugpuqt "xcnwg" #? "HCNUG" + "ku" u { uvgo "okpqt "cncto
XVV" 5 "qwnvgv" vgorgtcvwtg< "64E
"vjtgujqnf" %3 "hqt "XVV" 5 "qwnvgv" vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 322E+ "ku" u { uvgo "okpqt "cncto
"vjtgujqnf" %4 "hqt "XVV" 5 "qwnvgv" vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 337E+ "ku" u { uvgo "ocltq" "cncto
XVV" 5 "QM< "QM
"vjtgujqnf" %3 "hqt "XVV" 5 "QM< "
" *ugpuqt "xcnwg" #? "HCNUG" + "ku" u { uvgo "okpqt "cncto
enqem" 3 "QM< "QM
"vjtgujqnf" %3 "hqt "enqem" 3 "QM< "
" *ugpuqt "xcnwg" #? "HCNUG" + "ku" u { uvgo "okpqt "cncto
enqem" 4 "QM< "QM
"vjtgujqnf" %3 "hqt "enqem" 4 "QM< "
" *ugpuqt "xcnwg" #? "HCNUG" + "ku" u { uvgo "okpqt "cncto
oqfwng" 3 "rqygt /qvwrvw /hckn< "QM
"vjtgujqnf" %3 "hqt "oqfwng" 3 "rqygt /qvwrvw /hckn< "
" *ugpuqt "xcnwg" #? "HCNUG" + "ku" u { uvgo "okpqt "cncto
oqfwng" 3 "qwnvgv" vgorgtcvwtg< "78E
"vjtgujqnf" %3 "hqt "oqfwng" 3 "qwnvgv" vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 97E+ "ku" u { uvgo "okpqt "cncto
"vjtgujqnf" %4 "hqt "oqfwng" 3 "qwnvgv" vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " ; 2E+ "ku" u { uvgo "ocltq" "cncto
oqfwng" 3 "kpngv" vgorgtcvwtg< "63E
"vjtgujqnf" %3 "hqt "oqfwng" 3 "kpngv" vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 72E+ "ku" u { uvgo "okpqt "cncto
"vjtgujqnf" %4 "hqt "oqfwng" 3 "kpngv" vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 97E+ "ku" u { uvgo "ocltq" "cncto
oqfwng" 3 "fgxkeg /3 "vgorgtcvwtg< "85E
"vjtgujqnf" %3 "hqt "oqfwng" 3 "fgxkeg /3 "vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 97E+ "ku" u { uvgo "okpqt "cncto
"vjtgujqnf" %4 "hqt "oqfwng" 3 "fgxkeg /3 "vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " ; 2E+ "ku" u { uvgo "ocltq" "cncto
oqfwng" 3 "fgxkeg /4 "vgorgtcvwtg< "67E
"vjtgujqnf" %3 "hqt "oqfwng" 3 "fgxkeg /4 "vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 72E+ "ku" u { uvgo "okpqt "cncto
"vjtgujqnf" %4 "hqt "oqfwng" 3 "fgxkeg /4 "vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 97E+ "ku" u { uvgo "ocltq" "cncto
oqfwng" 3 "cwz /3 "vgorgtcvwtg< "79E
"vjtgujqnf" %3 "hqt "oqfwng" 3 "cwz /3 "vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 97E+ "ku" u { uvgo "okpqt "cncto
"vjtgujqnf" %4 "hqt "oqfwng" 3 "cwz /3 "vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " ; 2E+ "ku" u { uvgo "ocltq" "cncto
oqfwng" 3 "cwz /4 "vgorgtcvwtg< "68E
"vjtgujqnf" %3 "hqt "oqfwng" 3 "cwz /4 "vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 72E+ "ku" u { uvgo "okpqt "cncto
"vjtgujqnf" %4 "hqt "oqfwng" 3 "cwz /4 "vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 97E+ "ku" u { uvgo "ocltq" "cncto
oqfwng" 3 "kpuwhhkekgpv" eqqnkpi< "QM
"vjtgujqnf" %3 "hqt "oqfwng" 3 "kpuwhhkekgpv" eqqnkpi< "
" *ugpuqt "xcnwg" #? "HCNUG" + "ku" u { uvgo "ocltq" "cncto
oqfwng" 3 "cuke /3 "vgorgtcvwtg< "83E
"vjtgujqnf" %3 "hqt "oqfwng" 3 "cuke /3 "vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 332E+ "ku" u { uvgo "okpqt "cncto
"vjtgujqnf" %4 "hqt "oqfwng" 3 "cuke /3 "vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 347E+ "ku" u { uvgo "ocltq" "cncto
oqfwng" 3 "cuke /4 "vgorgtcvwtg< "83E
"vjtgujqnf" %3 "hqt "oqfwng" 3 "cuke /4 "vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 332E+ "ku" u { uvgo "okpqt "cncto
"vjtgujqnf" %4 "hqt "oqfwng" 3 "cuke /4 "vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 347E+ "ku" u { uvgo "ocltq" "cncto
oqfwng" 3 "cuke /5 "vgorgtcvwtg< "83E
"vjtgujqnf" %3 "hqt "oqfwng" 3 "cuke /5 "vgorgtcvwtg< "
" *ugpuqt "xcnwg" @? " 332E+ "ku" u { uvgo "okpqt "cncto

```

```

"vjtgujqnf"%4"hqt"oqfwng"3"cuke/5"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"347E+"ku"u{uvgo"oclt"cncto
oqfwng"3"cuke/6"vgorgtcvwtg<"85E
"vjtgujqnf"%3"hqt"oqfwng"3"cuke/6"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"332E+"ku"u{uvgo"okpqt"cncto
"vjtgujqnf"%4"hqt"oqfwng"3"cuke/6"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"347E+"ku"u{uvgo"oclt"cncto
oqfwng"5"rqygt/qwvrwv/hckn<"QM
"vjtgujqnf"%3"hqt"oqfwng"5"rqygt/qwvrwv/hckn<"
"*ugpuqt"xcnwg"##?"HCNUG"+"ku"u{uvgo"okpqt"cncto
oqfwng"5"oqfwng"qwnvgv/3"vgorgtcvwtg<"5;E
"vjtgujqnf"%3"hqt"oqfwng"5"oqfwng"qwnvgv/3"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"92E+"ku"u{uvgo"okpqt"cncto
"vjtgujqnf"%4"hqt"oqfwng"5"oqfwng"qwnvgv/3"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"7E+"ku"u{uvgo"oclt"cncto
oqfwng"5"oqfwng"kpngv/3"vgorgtcvwtg<"59E
"vjtgujqnf"%3"hqt"oqfwng"5"oqfwng"kpngv/3"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"77E+"ku"u{uvgo"okpqt"cncto
"vjtgujqnf"%4"hqt"oqfwng"5"oqfwng"kpngv/3"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"92E+"ku"u{uvgo"oclt"cncto
oqfwng"5"oqfwng"qwnvgv/4"vgorgtcvwtg<"72E
"vjtgujqnf"%3"hqt"oqfwng"5"oqfwng"qwnvgv/4"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"92E+"ku"u{uvgo"okpqt"cncto
"vjtgujqnf"%4"hqt"oqfwng"5"oqfwng"qwnvgv/4"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"7E+"ku"u{uvgo"oclt"cncto
oqfwng"5"oqfwng"kpngv/4"vgorgtcvwtg<"65E
"vjtgujqnf"%3"hqt"oqfwng"5"oqfwng"kpngv/4"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"77E+"ku"u{uvgo"okpqt"cncto
"vjtgujqnf"%4"hqt"oqfwng"5"oqfwng"kpngv/4"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"92E+"ku"u{uvgo"oclt"cncto
oqfwng"5"kpwwhkekgpv"eqqnkpi<"QM
"vjtgujqnf"%3"hqt"oqfwng"5"kpwwhkekgpv"eqqnkpi<"
"*ugpuqt"xcnwg"##?"HCNUG"+"ku"u{uvgo"oclt"cncto
oqfwng"5"hcp/writcfg"tgswtgfg<"QM
"vjtgujqnf"%3"hqt"oqfwng"5"hcp/writcfg"tgswtgfg<"
"*ugpuqt"xcnwg"##?"HCNUG"+"ku"u{uvgo"oclt"cncto
oqfwng"5"cuke/3"vgorgtcvwtg<"7:E
"vjtgujqnf"%3"hqt"oqfwng"5"cuke/3"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"332E+"ku"u{uvgo"okpqt"cncto
"vjtgujqnf"%4"hqt"oqfwng"5"cuke/3"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"347E+"ku"u{uvgo"oclt"cncto
oqfwng"5"cuke/4"vgorgtcvwtg<"78E
"vjtgujqnf"%3"hqt"oqfwng"5"cuke/4"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"332E+"ku"u{uvgo"okpqt"cncto
"vjtgujqnf"%4"hqt"oqfwng"5"cuke/4"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"347E+"ku"u{uvgo"oclt"cncto
oqfwng"5"cuke/5"vgorgtcvwtg<"77E
"vjtgujqnf"%3"hqt"oqfwng"5"cuke/5"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"332E+"ku"u{uvgo"okpqt"cncto
"vjtgujqnf"%4"hqt"oqfwng"5"cuke/5"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"347E+"ku"u{uvgo"oclt"cncto
oqfwng"3"GCTN"3"fgxkeg/3"vgorgtcvwtg<"4E
"vjtgujqnf"%3"hqt"oqfwng"3"GCTN"3"fgxkeg/3"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"332E+"ku"u{uvgo"okpqt"cncto
"vjtgujqnf"%4"hqt"oqfwng"3"GCTN"3"fgxkeg/3"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"347E+"ku"u{uvgo"oclt"cncto
oqfwng"3"GCTN"3"fgxkeg/4"vgorgtcvwtg<"3E
"vjtgujqnf"%3"hqt"oqfwng"3"GCTN"3"fgxkeg/4"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"332E+"ku"u{uvgo"okpqt"cncto
"vjtgujqnf"%4"hqt"oqfwng"3"GCTN"3"fgxkeg/4"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"347E+"ku"u{uvgo"oclt"cncto
oqfwng"3"GCTN"4"fgxkeg/3"vgorgtcvwtg<"3E
"vjtgujqnf"%3"hqt"oqfwng"3"GCTN"4"fgxkeg/3"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"332E+"ku"u{uvgo"okpqt"cncto

```

```

"vjtgujqnf"%4"hqt"oqfwng"3"GCTN"4"fgxkeg/3"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"347E+"ku"u{uvgo"oc1qt"cncto
oqfwng"3"GCTN"4"fgxkeg/4"vgorgtcvwtg<" :2E
"vjtgujqnf"%3"hqt"oqfwng"3"GCTN"4"fgxkeg/4"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"332E+"ku"u{uvgo"okpqt"cncto
"vjtgujqnf"%4"hqt"oqfwng"3"GCTN"4"fgxkeg/4"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"347E+"ku"u{uvgo"oc1qt"cncto
oqfwng"5"GCTN"qwnvgv/3"vgorgtcvwtg<"95E
"vjtgujqnf"%3"hqt"oqfwng"5"GCTN"qwnvgv/3"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"332E+"ku"u{uvgo"okpqt"cncto
"vjtgujqnf"%4"hqt"oqfwng"5"GCTN"qwnvgv/3"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"347E+"ku"u{uvgo"oc1qt"cncto
oqfwng"5"GCTN"kpngv/3"vgorgtcvwtg<"95E
"vjtgujqnf"%3"hqt"oqfwng"5"GCTN"kpngv/3"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"332E+"ku"u{uvgo"okpqt"cncto
"vjtgujqnf"%4"hqt"oqfwng"5"GCTN"kpngv/3"vgorgtcvwtg<"
"*ugpuqt"xcnwg"@?"347E+"ku"u{uvgo"oc1qt"cncto
rqtygt/eqpxgtvgt"3"<"505X"Qwvrwv<"QM
"vjtgujqnf"%3"hqt"rqtygt/eqpxgtvgt"3"<"505X"Qwvrwv<"
"*ugpuqt"xcnwg"#?"3"+"ku"u{uvgo"okpqt"cncto
rqtygt/eqpxgtvgt"4"<"505X"Qwvrwv<"QM
"vjtgujqnf"%3"hqt"rqtygt/eqpxgtvgt"4"<"505X"Qwvrwv<"
"*ugpuqt"xcnwg"#?"3"+"ku"u{uvgo"okpqt"cncto

```

How to Monitor the System Environmental Status

To display system status information, enter the **show environment [alarm | cooling | status | temperature]** command. The keywords display the following information:

- **alarm**—Displays environmental alarms.
 - **status**—Displays alarm status.
 - **thresholds**—Displays alarm thresholds.
- **cooling**—Displays fan tray status, chassis cooling capacity, ambient temperature, and per-slot cooling capacity.
- **status**—Displays field-replaceable unit (FRU) operational status and power and temperature information.
- **temperature**—Displays FRU temperature information.

To view the system status information, enter the **show environment** command:

```

Tqvwgt%"ujqy"gp xktqpgpv"
gp xktqpgpvcn"cnctou<
"pq"cnctou

Tqvwgt%"ujqy"gp xktqpgpv"cncto"
gp xktqpgpvcn"cnctou<
"pq"cnctou

Tqvwgt%"ujqy"gp xktqpgpv"eqqnkpi
hcp/vtc{"3"<
"hcp/vtc{"3"v{rg<"E8:29/ZN/HCP
"hcp/vtc{"3"oqfg<"Jkij/rqtygt
"hcp/vtc{"3"hcp/hckn<"QM
ejcuuku"rgt"unqv"eqqnkpi"ecrcekv{<";9"eho
"oqfwng"3"eqqnkpi"tgswnktgogpv<" :6"eho
"oqfwng"5"eqqnkpi"tgswnktgogpv<" :6"eho

Tqvwgt%"ujqy"gp xktqpgpv"uvcvwu"

```

```

uykvej "3"dcemrncpg<"
"qrgtcvkpi"enqem"eqwpv<"4
"qrgtcvkpi"XVV"eqwpv<"5
"qrgtcvkpi"hcp"eqwpv<"3

uykvej "3"hcp/vtc{"3<"
"uykvej "3"hcp/vtc{"3"v{rg<"E8:29/ZN/HCP
"uykvej "3"hcp/vtc{"3"oqfg<"Jki j/rqygt
"uykvej "3"hcp/vtc{"3"hcp/hckn<"QM
uykvej "3"XVV"3<"
"uykvej "3"XVV"3"QM<"QM
"uykvej "3"XVV"3"qwnvgv"vgorgtcvwtg<"58E
uykvej "3"XVV"4<"
"uykvej "3"XVV"4"QM<"QM
"uykvej "3"XVV"4"qwnvgv"vgorgtcvwtg<"5:E
uykvej "3"XVV"5<"
"uykvej "3"XVV"5"QM<"QM
"uykvej "3"XVV"5"qwnvgv"vgorgtcvwtg<"63E
uykvej "3"enqem"3<"
"uykvej "3"enqem"3"QM<"QM."uykvej "3"enqem"3"enqem/kpwug<"kp/wug
uykvej "3"enqem"4<"
"uykvej "3"enqem"4"QM<"QM."uykvej "3"enqem"4"enqem/kpwug<"pqv/kp/wug
uykvej "3"rqygt/uwrn{"3<"
"uykvej "3"rqygt/uwrn{"3"hcp/hckn<"QM
"uykvej "3"rqygt/uwrn{"3"rqygt/kprwv<"CE"jki j
"uykvej "3"rqygt/uwrn{"3"rqygt/qwvrwv/oqfg<"jki j
"uykvej "3"rqygt/uwrn{"3"kpqorcvkdng"ykvj"hcp<"QM
"uykvej "3"rqygt/uwrn{"3"rqygt/qwvrwv/hckn<"QM

uykvej "3"rqygt/uwrn{"4<"
"uykvej "3"rqygt/uwrn{"4"hcp/hckn<"QM
"uykvej "3"rqygt/uwrn{"4"rqygt/kprwv<"CE"jki j
"uykvej "3"rqygt/uwrn{"4"rqygt/qwvrwv/oqfg<"jki j
"uykvej "3"rqygt/uwrn{"4"kpqorcvkdng"ykvj"hcp<"QM
"uykvej "3"rqygt/uwrn{"4"rqygt/qwvrwv/hckn<"QM

uykvej "3"rqygt/eqpxgtvgt"3<"
"uykvej "3"rqygt/eqpxgtvgt"3"<"505X"Qwvrwv<"QM
uykvej "3"rqygt/eqpxgtvgt"4<"
"uykvej "3"rqygt/eqpxgtvgt"4"<"505X"Qwvrwv<"QM
uykvej "3"oqfwng"3<"
"uykvej "3"oqfwng"3"rqygt/qwvrwv/hckn<"QM
"uykvej "3"oqfwng"3"qwnvgv"vgorgtcvwtg<"75E
"uykvej "3"oqfwng"3"kpngv"vgorgtcvwtg<"62E
"uykvej "3"oqfwng"3"fgxkeg/3"vgorgtcvwtg<"82E
"uykvej "3"oqfwng"3"fgxkeg/4"vgorgtcvwtg<"67E
"uykvej "3"oqfwng"3"cwz/3"vgorgtcvwtg<"77E
"uykvej "3"oqfwng"3"cwz/4"vgorgtcvwtg<"67E
"uykvej "3"oqfwng"3"cuke/3"vgorgtcvwtg<"7:E
"uykvej "3"oqfwng"3"cuke/4"vgorgtcvwtg<"7;E
"uykvej "3"oqfwng"3"cuke/5"vgorgtcvwtg<"82E
"uykvej "3"oqfwng"3"cuke/6"vgorgtcvwtg<"83E
"uykvej "3"oqfwng"3"GCTN"3"fgxkeg/3"vgorgtcvwtg<"9:E
"uykvej "3"oqfwng"3"GCTN"3"fgxkeg/4"vgorgtcvwtg<"99E
"uykvej "3"oqfwng"3"GCTN"4"fgxkeg/3"vgorgtcvwtg<"99E
"uykvej "3"oqfwng"3"GCTN"4"fgxkeg/4"vgorgtcvwtg<"99E
uykvej "3"oqfwng"5<"
"uykvej "3"oqfwng"5"rqygt/qwvrwv/hckn<"QM
"uykvej "3"oqfwng"5"oqfwng"qwnvgv/3"vgorgtcvwtg<"5:E
"uykvej "3"oqfwng"5"oqfwng"kpngv/3"vgorgtcvwtg<"58E
"uykvej "3"oqfwng"5"oqfwng"qwnvgv/4"vgorgtcvwtg<"6;E
"uykvej "3"oqfwng"5"oqfwng"kpngv/4"vgorgtcvwtg<"65E
"uykvej "3"oqfwng"5"cuke/3"vgorgtcvwtg<"78E
"uykvej "3"oqfwng"5"cuke/4"vgorgtcvwtg<"78E

```

```
"uykvej"3"oqfwng"5"cuqe/5"vgorgtcvwtg<"76E  
"uykvej"3"oqfwng"5"GCTN"qvwngv/3"vgorgtcvwtg<"94E  
"uykvej"3"oqfwng"5"GCTN"kpngv/3"vgorgtcvwtg<"93E
```

Information About LED Environmental Indications

The LEDs can indicate two alarm types: major and minor. Major alarms indicate a critical problem that could lead to the system being shut down. Minor alarms are for informational purposes only, giving you notice of a problem that could turn critical if corrective action is not taken.

When the system has an alarm (major or minor), that indicates an overtemperature condition, the alarm is not canceled nor is any action taken (such as module reset or shutdown) for 5 minutes. If the temperature falls 5°C (41°F) below the alarm threshold during this period, the alarm is canceled.

[Table 15-1](#) lists the environmental indicators for the supervisor engine and switching modules.



Note

See the *Catalyst 6500 Series Switch Module Installation Guide* for additional information on LEDs, including the supervisor engine SYSTEM LED.

Table 15-1 Environmental Monitoring for Supervisor Engine and Switching Modules

Component	Alarm Type	LED Indication	Action
Supervisor engine temperature sensor exceeds major threshold	Major	STATUS LED red	Generates syslog message and an SNMP trap. If there is a redundancy situation, the system switches to a redundant supervisor engine and the active supervisor engine shuts down. If there is no redundancy situation and the overtemperature condition is not corrected, the system shuts down after 5 minutes.
Note - Temperature sensors monitor key supervisor engine components including daughter cards. - A STATUS LED is located on the supervisor engine front panel and all module front panels. - The STATUS LED is red on the failed supervisor engine. If there is no redundant supervisor, the SYSTEM LED is red also.			
Supervisor engine temperature sensor exceeds minor threshold	Minor	STATUS LED orange	Generates syslog message and an SNMP trap. Monitors the condition.
Redundant supervisor engine temperature sensor exceeds major or minor threshold	Major	STATUS LED red	Generates syslog message and an SNMP trap. If a major alarm is generated and the overtemperature condition is not corrected, the system shuts down after 5 minutes.
	Minor	STATUS LED orange	Monitors the condition if a minor alarm is generated.
Switching module temperature sensor exceeds major threshold	Major	STATUS LED red	Generates syslog message and SNMP. Powers down the module (see the “ How to Power Modules Off and On ” section on page 14-3 for instructions).
Switching module temperature sensor exceeds minor threshold	Minor	STATUS LED orange	Generates syslog message and an SNMP trap. Monitors the condition.

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Online Diagnostics

- [Prerequisites for Online Diagnostics, page 16-1](#)
- [Restrictions for Online Diagnostics, page 16-1](#)
- [Information About Online Diagnostics, page 16-2](#)
- [Default Settings for Online Diagnostics, page 16-2](#)
- [How to Configure Online Diagnostics, page 16-2](#)
- [How to Run Online Diagnostic Tests, page 16-7](#)
- [How to Perform Memory Tests, page 16-29](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for Online Diagnostics

None.

Restrictions for Online Diagnostics

None.

Information About Online Diagnostics

With online diagnostics, you can test and verify the hardware functionality of the switch while the switch is connected to a live network.

The online diagnostics contain packet switching tests that check different hardware components and verify the data path and control signals. Disruptive online diagnostic tests, such as the built-in self-test (BIST) and the disruptive loopback test, and nondisruptive online diagnostic tests, such as packet switching, run during bootup, module online insertion and removal (OIR), and system reset. The nondisruptive online diagnostic tests run as part of background health monitoring. Either disruptive or nondisruptive tests can be run at the user's request (on-demand).

The online diagnostics detect problems in the following areas:

- Hardware components
- Interfaces (GBICs, Ethernet ports, and so forth)
- Connectors (loose connectors, bent pins, and so forth)
- Solder joints
- Memory (failure over time)

Online diagnostics is one of the requirements for the high availability feature. High availability is a set of quality standards that seek to limit the impact of equipment failures on the network. A key part of high availability is detecting hardware failures and taking corrective action while the switch runs in a live network. Online diagnostics in high availability detect hardware failures and provide feedback to high availability software components to make switchover decisions.

Online diagnostics are categorized as bootup, on-demand, schedule, or health-monitoring diagnostics. Bootup diagnostics run during bootup; on-demand diagnostics run from the CLI; schedule diagnostics run at user-designated intervals or specified times when the switch is connected to a live network; and health-monitoring runs in the background.

Default Settings for Online Diagnostics

See the default information for each test in [Appendix 1, “Online Diagnostic Tests.”](#)

How to Configure Online Diagnostics

- [Setting Bootup Online Diagnostics Level, page 16-2](#)
- [Configuring On-Demand Online Diagnostics, page 16-4](#)
- [Scheduling Online Diagnostics, page 16-6](#)

Setting Bootup Online Diagnostics Level

You can set the bootup diagnostics level as minimal or complete or you can bypass the bootup diagnostics entirely. Enter the **complete** keyword to run all diagnostic tests; enter the **minimal** keyword to run only EARL tests and loopback tests for all ports in the switch. Enter the **no** form of the command to bypass all diagnostic tests. The default bootup diagnostics level is minimal.

To set the bootup diagnostic level, perform this task:

Command	Purpose
<code>Tqwvgt*eqphki+%fkciqquvke"dqqvwr"ngxgn"}okpkocn"~"eqorngvg;"</code>	Sets the bootup diagnostic level.

This example shows how to set the bootup online diagnostic level:

```
Tqwvgt*eqphki+%fkciqquvke"dqqvwr"ngxgn"eqorngvg"
Tqwvgt*eqphki+%
```

This example shows how to display the bootup online diagnostic level:

```
Tqwvgt*eqphki+%ujqyfkciqquvke"dqqvwr"ngxgn"
Ewttgpv"dqqvwr"fkciqquvke"ngxgn<"eqorngvg"

Tqwvgt*eqphki+%
```

Combined Legacy Diagnostic Tests

The following legacy diagnostic tests have been combined:

TestAclRedirectRBacl

The legacy tests **TestRBacl** and **TestAclRedirect** have been merged into this test.

The combined test will verify both the ACL redirect feature and the Role based ACL feature of the Layer 3 forwarding engine.

TestQosDQUP

The legacy tests **TestQos** and **TestDQUP** have been merged into this test.

The combined test will verify both the QoS input/output TCAM functionality and that DQUP/PUP packets can be generated when diagnostic packets hit QoS entry.

TestIngressEgressSpan

The legacy tests **TestIngressSpan** and **TestEgressSpan** have been merged into this test.

This combined test will ensure the port ASIC will be able to tag packets for ingress span and verify the egress span replication functionality of the ingress module replication engine.

New Diagnostic Tests

TestEobcStressPing

This test is designed to stress test the EOBC link of a line card with the supervisor.

In this test a large number (20,000) of ICMP packets are sent from the Supervisor to the line card along with varying the size of the ICMP packet. The test is declared pass when all the ICMP packets are responded to within the timeout (2 seconds).

The test can be run on-demand or scheduled as it is a disruptive test. It is possible the test will fail if the EOBC was already under heavy load and all packets are not responded to. No corrective action is needed.

TestVSActiveToStandbyLoopback

This test is a VSS system wide test and only permitted in on-demand mode.

During this test, the standby VSS supervisor's uplink port is configured in loopback mode and a VLAN flood packet is sent from the Active VSS's inband port to the standby VSS's uplink port.

This is a disruptive test that can be run on-demand only. It doesn't require a VSL link from Active to Standby supervisor. The uplink port cannot be specified. The test cannot be run on the Active Supervisor.

TestVslBridgeLink

This test verifies the bridge link data path between two fabric channel and rewrite engine based data path complexes for VSL configurable Supervisor or line card.

The packet is sent across the bridge link from the inband port on one data path complex to a good loopback port on another data path complex.

TestVslLocalLoopback

This test verifies the hardware functionality of each port on a VSL card before any VSL member link in the VSL port-channel group is up.

A diagnostic packet is sent from the local inband port of the VSL card to each port to run a loopback test.

TestVslStatus

This test reports the status change of the link detected by VSLP protocol.

If any link problem is detected by VSLP, the link status and result are updated. The loopback test to check the hardware status, as requested by VSLP is also triggered.

TestFabricLinkStatus

This test monitors the FEX fabric link on the FEX controller.

It will report failure if the fabric link port has lost connection to the associated FEX.

Configuring On-Demand Online Diagnostics

You can run the on-demand online diagnostic tests from the CLI. You can set the execution action to either stop or continue the test when a failure is detected or to stop the test after a specific number of failures occur by using the failure count setting. You can configure a test to run multiple times using the iteration setting.

You should run packet-switching tests before memory tests.



Note

Do not use the **diagnostic start all** command until all of the following steps are completed.

Because some on-demand online diagnostic tests can affect the outcome of other tests, you should perform the tests in the following order:

1. Run the nondisruptive tests.
2. Run all tests in the relevant functional area.
3. Run the TestTrafficStress test.
4. Run the TestEobcStressPing test.
5. Run the exhaustive-memory tests.

To run on-demand online diagnostic tests, perform this task:

Step 1 Run the nondisruptive tests.

To display the available tests and their attributes, and determine which commands are in the nondisruptive category, enter the **show diagnostic content** command.

Step 2 Run all tests in the relevant functional area.

Packet-switching tests fall into specific functional areas. When a problem is suspected in a particular functional area, run all tests in that functional area. If you are unsure about which functional area you need to test, or if you want to run all available tests, enter the **complete** keyword.

Step 3 Run the TestTrafficStress test.

This is a disruptive packet-switching test. This test switches packets between pairs of ports at line rate for the purpose of stress testing. During this test all of the ports are shut down, and you may see link flaps. The link flaps will recover after the test is complete. The test takes several minutes to complete.

Disable all health-monitoring tests before running this test by using the **no diagnostic monitor module number test all** command.

Step 4 Run the TestEobcStressPing test.

This is a disruptive test and tests the Ethernet over backplane channel (EOBC) connection for the module. The test takes several minutes to complete. You cannot run any of the packet-switching tests described in previous steps after running this test. However, you can run tests described in subsequent steps after running this test.

Disable all health-monitoring tests before running this test by using the **no diagnostic monitor module number test all** command. The EOBC connection is disrupted during this test and will cause the health-monitoring tests to fail and take recovery action.

Step 5 Run the exhaustive-memory tests.

Before running the exhaustive-memory tests, all health-monitoring tests should be disabled because the tests will fail with health monitoring enabled and the switch will take recovery action. Disable the health-monitoring diagnostic tests by using the **no diagnostic monitor module number test all** command.

Perform the exhaustive-memory tests in the following order:

1. TestFibTcamSSRAM
2. TestAclQosTcam
3. TestNetFlowTcam
4. TestAsicMemory
5. TestAsicMemory

You must reboot the after running the exhaustive-memory tests before it is operational again. You cannot run any other tests on the switch after running the exhaustive-memory tests. Do not save the configuration when rebooting as it will have changed during the tests. After the reboot, reenale the health-monitoring tests using the **diagnostic monitor module number test all** command.

To set the bootup diagnostic level, perform this task:

Command	Purpose
<code>Tqvwgt% "fkci pquvke" qpfgocpf } kvgtcvkqp "kvgtcvkqpaeqwpv i" ~ " } cev kqp / qp / gttqt " } eqpvkpwg ~ " uvqr i "] gttqtaeqwpv _ i</code>	Configures on-demand diagnostic tests to run, how many times to run (iterations), and what action to take when errors are found.

This example shows how to set the on-demand testing iteration count:

```
Tqwgvt%"fkciqquvke"qpfgoqpf"kvgtcvkqp"5
Tqwgvt%
```

This example shows how to set the execution action when an error is detected:

```
Tqwgvt%"fkciqquvke"qpfgoqpf"cevkqp/qp/gttqt"eqpvkpwg"4
Tqwgvt%
```

Scheduling Online Diagnostics

You can schedule online diagnostics to run at a designated time of day or on a daily, weekly, or monthly basis. You can schedule tests to run only once or to repeat at an interval. Use the **no** form of this command to remove the scheduling.

To schedule online diagnostics, perform this task:

Command	Purpose
<pre>Tqwgvt*eqphki+%"fkciqquvke"uejgfwng"oqfwng"pwodgt" vguv"}vguvakf"~"vguvakfatcpig"~"cnn;"rqtvt"}pwo"~" pwoatcpig"~"cnn;"qp oo ff {{{{"jj<oo;"~"}fckn{" jj<oo;"~"}yggmn{"fc{aqhayygm"jj<oo;</pre>	Schedules on-demand diagnostic tests on the specified module for a specific date and time, how many times to run (iterations), and what action to take when errors are found.

This example shows how to schedule diagnostic testing on a specific date and time for a specific port on module 1:

```
Tqwgvt*eqphki+%"fkciqquvke"uejgfwng"oqfwng"3"vguv"3.4.7/;"rqtvt"5"qp"lcpwct{"5"4225"45<54
Tqwgvt*eqphki+%
```

This example shows how to schedule diagnostic testing to occur daily at a certain time for a specific port:

```
Tqwgvt*eqphki+%"fkciqquvke"uejgfwng"oqfwng"3"vguv"3.4.7/;"rqtvt"5"fckn{"34<56
Tqwgvt*eqphki+%
```

This example shows how to schedule diagnostic testing to occur weekly on a certain day for a specific port:

```
Tqwgvt*eqphki+%"fkciqquvke"uejgfwng"oqfwng"3"vguv"3.4.7/;"rqtvt"5"yggmn{"htkfc{"2;<45
Tqwgvt*eqphki+%
```

Configuring Health-Monitoring Diagnostics

You can configure health-monitoring diagnostic testing while the switch is connected to a live network. You can configure the execution interval for each health-monitoring test, the generation of a system message upon test failure, or the enabling or disabling an individual test. Use the **no** form of this command to disable testing.

To configure health-monitoring diagnostic testing, perform this task:

	Command	Purpose
Step 1	<code>Tqvwgt*eqphki+%fkcipquvke"oqpkvqt"kpvgtxcn"oqfwng" number vguv" }vguvakf"~"vguvakfatcpig"~"cnn;"]jqwt" jj_"]okp"oo_"]ugeqpf"uu_"]oknnkuge"ou_"]fc{"fc{"</code>	Configures the health-monitoring interval of the specified tests. The no form of this command will change the interval to the default interval, or zero.
Step 2	<code>Tqvwgt*eqphki+%]pq "fkcipquvke"oqpkvqt"oqfwng" number vguv" }vguvakf"~"vguvakfatcpig"~"cnn;</code>	Enables or disables health-monitoring diagnostic tests.

This example shows how to configure the specified test to run every two minutes on module 1:

```
Tqvwgt*eqphki+%fkcipquvke"oqpkvqt"kpvgtxcn"oqfwng"3vguv"3okp"4
Tqvwgt*eqphki+%
```

This example shows how to run the test if health monitoring has not previously been enabled:

```
Tqvwgt*eqphki+%fkcipquvke"oqpkvqt"oqfwng"3vguv"3
```

This example shows how to enable the generation of a syslog message when any health-monitoring test fails:

```
Tqvwgt*eqphki+%fkcipquvke"oqpkvqt"u{unqi
Tqvwgt*eqphki+%
```

How to Run Online Diagnostic Tests

- [Overview of Diagnostic Test Operation, page 16-8](#)
- [Starting and Stopping Online Diagnostic Tests, page 16-8](#)
- [Running All Online Diagnostic Tests, page 16-9](#)
- [Displaying Online Diagnostic Tests and Test Results, page 16-9](#)

Overview of Diagnostic Test Operation

After you configure online diagnostics, you can start or stop diagnostic tests or display the test results. You can also see which tests are configured and what diagnostic tests have already run.

- Enable the logging console/monitor to see all warning messages before you enable any online diagnostics tests.
- When you are running disruptive tests, run the tests when connected through the console. When disruptive tests are complete, a warning message on the console recommends that you reload the system to return to normal operation. Strictly follow this warning.
- While tests are running, all ports are shut down because a stress test is being performed with ports configured to loop internally; external traffic might alter the test results. The switch must be rebooted to bring the switch to normal operation. When you issue the command to reload the switch, the system will ask you if the configuration should be saved. Do not save the configuration.
- If you are running the tests on a supervisor engine, after the test is initiated and complete, you must reload or power down and then power up the entire system.
- If you are running the tests on a switching module, rather than the supervisor engine, after the test is initiated and complete, you must reset the switching module.

Starting and Stopping Online Diagnostic Tests

After you configure diagnostic tests to run, you can use the **start** and **stop** to begin or end a diagnostic test. To start or stop an online diagnostic command, perform one of these tasks:

Command	Purpose
<code>Tqwwgt% fkcipquvke uvctv oqfwng pwodgt vguv } vguvakf ~"vguvakfatcpig"~"okpkocn"~"eqornvgvg"~"dcuke"~"rgt/rqtv"~"pqp/fkutwrvkxg"~"cnn;" } rgtv } pwo ~"port#_range"~"cnn;"</code>	Starts a diagnostic test on a port or range of ports on the specified module.
<code>Tqwwgt% fkcipquvke uvqr oqfwng pwodgt</code>	Stops a diagnostic test on the specified module.

This example shows how to start a diagnostic test on module 1:

```
Tqwwgt% fkcipquvke uvctv oqfwng 3 vguv 7
Oqfwng 3 < Twppkpi vguv * u + " 7 " oc { " fcutwrv " pqtocn " u { uvgo " qrgtcvkqp
Fq { qw " ycpv " vq " twp " fcutwrvkxg " vguvuA " } pq { gu
22<6 : < 36 < ' Twppkpi " QpFgocpf " Fkcipquvkeu " } Kvgtcvkqp " % 3 _ " 000
22<6 : < 36 < ' FKCI / UR / 8 / VGUVaTWPPKPI < Oqfwng " 3 < Twppkpi " VguvPgyNgctp } KF? 7 i " 000
22<6 : < 36 < ' FKCI / UR / 8 / VGUVaQM < Oqfwng " 3 < VguvPgyNgctp } KF? 7 i " jcu " eqornvgvgf " uweeguuhwnn {
22<6 : < 36 < ' Twppkpi " QpFgocpf " Fkcipquvkeu " } Kvgtcvkqp " % 4 _ " 000
22<6 : < 36 < ' FKCI / UR / 8 / VGUVaTWPPKPI < Oqfwng " 3 < Twppkpi " VguvPgyNgctp } KF? 7 i " 000
22<6 : < 36 < ' FKCI / UR / 8 / VGUVaQM < Oqfwng " 3 < VguvPgyNgctp } KF? 7 i " jcu " eqornvgvgf " uweeguuhwnn {
Tqwwgt%
```

This example shows how to stop a diagnostic test:

```
Tqwwgt% fkcipquvke uvqr oqfwng 3
Tqwwgt%
```

You can run all diagnostic tests, disruptive and nondisruptive, at once with a single command. In this case, all test dependencies will be handled automatically.

Note

- Running all online diagnostic tests will disrupt normal system operation. Reset the system after the **diagnostic start system test all** command has completed.
- Do not insert, remove, or power down modules or the supervisor while the system test is running.
- Do not issue any diagnostic command other than the **diagnostic stop system test all** command while the system test is running.
- Make sure no traffic is running in background.

To start or stop all online diagnostic tests, perform one of these tasks:

Command	Purpose
Tqwwgt% "fkci pquvke "uvctv"u{uvgo"vguv"cn n	Executes all online diagnostic tests.
Tqwwgt% "fkci pquvke "uvqr"u{uvgo"vguv"cn n	Stops the execution of all online diagnostic tests.

This example shows how to start all online diagnostic tests:

[illegible]

You can display the online diagnostic tests that are configured and check the results of the tests using the following **show** commands:

- **show diagnostic content**
- **show diagnostic health**

	Purpose

This example shows how to display the online diagnostics that are configured on switch 1 module 5:

Uykvej "3 "Oqfwng"7<"Uwrgtxkuqt "Gpikpg"8V"32IG"y1 "EVU"*Cevkxg+

For Engine 6T Software Configuration Guide, Release 15.4SY


```

"4;+"VguvN5VecOgpkvqtkpi"//////////@" , , , P , , , K , , , "222"22<22<37022"32
"52+"VguvHkdVecO"//////////@" , , , F , Z , , K T , , , "pqv"eqphkiwtgf"p1c
"53+"VguvCenSquVecO"//////////@" , , , F , Z , , K T , , , "pqv"eqphkiwtgf"p1c
"54+"VguvGctnOgoQpDqqvwr"//////////@" O , , P , Z , , K , , , "pqv"eqphkiwtgf"p1c
"55+"VguvCukeOgoqt{"//////////@" , , , F , Z , , K T , , , "pqv"eqphkiwtgf"p1c
"56+"VguvGqdeUvtguuRkpi"//////////@" , , , F , Z , , K , , , "pqv"eqphkiwtgf"p1c
"57+"VguvHktoyctgFkciUvcvwu"//////////@" O , , P , , , K , , , "222"22<22<37022"32
"58+"VguvCukeU{pe"//////////@" , , , P , , , K , , , "222"22<22<37022"32
"59+"VguvWpwugfRqtvNqgrdcem"//////////@" , , , R P , , , K , , , "222"22<23<22022"32
"5;+"VguvPqpFkutwrvkxgNqgrdcem"//////////@" , , , R P , , , K , , , "222"22<22<32022"32
"5;+"VguvHcdtkeHngyEqpvtqnUvcvwu"//////////@" , , , P , , , K , , , "222"22<22<37022"32
"62+"VguvRqtvVzOgpkvqtkpi"//////////@" , , , R P , , , K , , , "222"22<23<37022"7
"63+"VguvQDHN"//////////@" O , , P , , , K , , , "222"22<22<37022"32
"64+"VguvEHTY"//////////@" O , X P , Z , , K , , , "pqv"eqphkiwtgf"p1c
"65+"VguvNvnHrqqOgoqt{Eqpukuvgpe{"//////////@" , , , P , , , K , , , "222"22<22<52022"3
"66+"VguvTyGpikpgQxgtUwduetkrvkqp"//////////@" , , , P , , , K , , , "222"22<22<23022"32
"67+"VguvGttqtEqwpgvtOgpkvqt"//////////@" , , , P , , , K , , , "222"22<22<52022"32
"68+"VguvXunDtkfigNkpm"//////////@" O , , F , Z , , K , , , "pqv"eqphkiwtgf"p1c
"69+"VguvXunNqecnNqgrdcem"//////////@" O , R F , Z , , K , , , "pqv"eqphkiwtgf"p1c
"6;+"VguvXunUvcvwu"//////////@" O , R F , Z , , K , , , "pqv"eqphkiwtgf"p1c
"6;+"VguvGCTNKpvgtpcnVcdngu"//////////@" , , , P , , , K , , , "222"22<27<22022"3
"72+"VguvPXTCODcvvgt{Ogpkvqt"//////////@" , , , P , , H , K , , , "222"23<22<22022"94
"73+"VguvOgfkcnNqgrdcem"//////////@" , , , R F , Z , , K , , , "pqv"eqphkiwtgf"p1c
"74+"VguvOketqdwuv"//////////@" , , , R P , , , K , , , "222"22<22<27022"32
"75+"VguvHGZHcdtkeNkpmUvcvwu"//////////@" , , , R P , , , K , , , "222"22<22<25022"5

```

Tqvwgt%

This example shows how to display the online diagnostic results for module 6:

```
Tqwgvt%"ujqy"fkcipquvke"tguwnv"uykvej"3"oqfwng"7"

Ewttgtpv"dqqvwr"fkcipquvke"ngxgn<"eqornrgvg

Uykvej"3"Oqfwng"7<"Uwrgtxkuqt"Gpikpg"8V"32IG"y1"EVU"*Cevkxg+"UgtkcnPq"<"UCN3;49LGNE

"Qxgtcnn"Fkcipquvke"tguwnv"hqt"Uykvej"3"Oqfwng"7"<"RCUU
"Fkcipquvke"ngxgn"cv"ectf"dqqvwr<"eqornrgvg

"Vguv"tguwnvu<"*0"? "Rcuu."H"? "Hckn."W"? "Wpvguvvgf+

"3+"VguvVtcpuegkxgtKpvgitkv{<

"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3:"3;"42
"////////////////////////
"W"W"W"W"0"0"0"W"0"0"W"W"W"W"W"W"W"W"W"W

"4+"VguvNqgrdcem<

"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3:"3;"42
"////////////////////////
"0"0"0"0"0"W"W"0"0"0"W"W"W"W"W"W"W"W"W"W

"5+"VguvHgzoqfgNqgrdcem<

"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3:"3;"42
"////////////////////////
"0"0"0"0"0"W"W"0"0"0"W"W"W"W"W"W"W"W"W"W

"6+"VguvXUCevkxgVqUvcpgd{Nqgrdcem"///@"W
"7+"VguvN4EVUNqgrdcem<

"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3:"3;"42
"////////////////////////
"0"0"0"0"0"W"W"0"0"0"W"W"W"W"W"W"W"W"W"W

"8+"VguvN5EVUNqgrdcem<

"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3:"3;"42
"////////////////////////
"0"0"0"0"0"W"W"0"0"0"W"W"W"W"W"W"W"W"W"W

"9+"VguvUetcjejTgikuvgt"////////////////@W
":+"VguvPgyKpfgzNgctp"////////////////@0
";+"VguvFgvpEqpfkvkqpcnNgctp"////////@0
"32+"VguvDrfwVtcr"////////////////@0
"33+"VguvOcvejEcrvwtg"////////////////@0
"34+"VguvRtqvqeqnOcvejEjcpagn"////////@W
"35+"VguvRqtvUgewtkv{"////////////////@0
"36+"VguvKRx6HkdUjqtviewv"////////@0
"37+"VguvN5Ecrvwtg4"////////@0
"38+"VguvKRx8HkdUjqtviewv"////////@0
"39+"VguvORNUHkdUjqtviewv"////////@0
"3:+"VguvPCVHkdUjqtviewv"////////@0
"3;+"VguvCenRgtokv"////////@0
"42+"VguvCenFgp{"////////////////@0
"43+"VguvCenTgftkgevtDCen"////////@0
```

```

"44+"VguvSquFSWR"////////////////////@ "0
"45+"VguvN5XncpOgy"////////////////////@ "0
"46+"VguvKp itguuGitguuUrcp"////////////////@ "0
"47+"VguvPgvhnqyUjqtviewv"////////////////@ "0
"48+"VguvKpdcpfGfkv"////////////////////@ "0
"49+"VguvHcdtkeXncpNqqrdecem"////////////////@ "0
"4:+"VguvVtchhkeUvtguu"////////////////////@ "W
"4;+"VguvN5VecoOqpkvqtkpi"////////////////@ "W
"52+"VguvHkdVeco"////////////////////@ "W
"53+"VguvCenSquVeco"////////////////////@ "W
"54+"VguvGctnOgoQpDqgvwr"////////////////@ "0
"55+"VguvCukeOgoqt{"////////////////////@ "W
"56+"VguvGqdeUvtguuRkpi"////////////////////@ "W
"57+"VguvHktoyctgFkciUvcvwu"////////////////@ "0
"58+"VguvCukeU{pe"////////////////////@ "W
"59+"VguvWpwugfRqtvNqqrdecem<

"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3: "3; "42
"////////////////////////
"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W

"5:+"VguvPqpFkutwrvkxgNqqrdecem<

"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3: "3; "42
"////////////////////////
"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W

"5;+"VguvHcdtkeHnqyEqpvtqnUvcvwu"////@ "W
"62+"VguvRqtvVzOqpkvqtkpi<

"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3: "3; "42
"////////////////////////
"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W

"63+"VguvQDHN"////////////////////@ "0
"64+"VguvEHTY<

"Fxkxeg"3
"////////
"W

"65+"VguvNvnHrqqOgoqt{Eqpukuvgpe{"////@ "W
"66+"VguvTyGpikpgQxgtUwduetkrvkqp"////@ "W
"67+"VguvGttqtEqwpvgtoqpkvgt"////////@ "W
"68+"VguvXunDtkfigNkpm"////////////////@ "0
"69+"VguvXunNqecnNqqrdecem<

"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3: "3; "42
"////////////////////////
"0"0"0"0"0"0"0"0"0"0"W"W"W"W"W"W"W"W"W"W

"6:+"VguvXunUvcvwu<

"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3: "3; "42
"////////////////////////
"W"W"W"W"W"W"0"0"W"W"W"W"W"W"W"W"W"W"W"W"W

"6;+"VguvGCTNKpvgtpcnVcdngu"////////@ "W

```

```

"72+"VguvPXTCODcuvgt{Oqpkvqt"////////@W
"73+"VguvOgfkNqgrdcem<

"Rqtv"3"4"5"6"7"8"9": ";"32"33"34"35"36"37"38"39"3:"3;"42
"//////////
"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W
"74+"VguvOketqdwuv<

"Rqtv"3"4"5"6"7"8"9": ";"32"33"34"35"36"37"38"39"3:"3;"42
"//////////
"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W
"75+"VguvHGZHcdtkeNkpmUvcvwu<

"Rqtv"3"4"5"6"7"8"9": ";"32"33"34"35"36"37"38"39"3:"3;"42
"//////////
"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W
Tqwvgt%

```

```

1qgwvgT% "ujqy"fkciPquvke"tguwnv"uykvej"3"Oqfwng"7"fgvckn"
EwtTgpv"dqqvwr"fkciPquvke"ngxgn<"eqorngvg
Uykvej"3"Oqfwng"7<"Uwrgtxkuqt"Gpikpg"8V"32IG"y1"EVU"*Cevkxg+"UgtkcnPq"<"UCN3;49LGNE
"Qxgtcnn"FkciPquvke"Tguwnv"hqt"Uykvej"3"Oqfwng"7"<"RCUU
"FkciPquvke"ngxgn"cv"ectf"dqqvwr<"eqorngvg
"Vguv"tguwnvu<"*0"? "Rcuu. "H"? "Hckn. "W"? "Wpvguvgf+
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa
"3+"VguvVtcpuEgkxgtKpvgitkv{<
"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3: "3; "42
"////////////////////////
"W"W"W"W"0"0"W"0"0"W"W"W"W"W"W"W"W"W"W
"Gttqt"eqfg"////////////////////////@"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"////////////////////////@"7
"NcuV"vguv"vguvkpi"v{rg"////////@"QpFgocpf
"NcuV"vguv"gzgEwvkqp"vkog"////////@"Crt"29"4238"32<5;<2;
"Hktuv"vguv"hcknwtg"vkog"////////@"p1c
"NcuV"vguv"hcknwtg"vkog"////////@"p1c
"NcuV"vguv"rcuu"vkog"////////@"Crt"29"4238"32<5;<2;
"Vqvcn"hcknwtg"eqwpv"////////////////////////@"2
"EqpugEwvkxg"hcknwtg"eqwpv"////////@"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa
"4+"VguvNqqrDcem<
"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3: "3; "42
"////////////////////////
"0"0"0"0"0"W"W"0"0"0"W"W"W"W"W"W"W"W"W"W
"Gttqt"eqfg"////////////////////////@"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"////////////////////////@"3
"NcuV"vguv"vguvkpi"v{rg"////////@"Dqqvwr
"NcuV"vguv"gzgEwvkqp"vkog"////////@"Crt"29"4238"32<5:<64
"Hktuv"vguv"hcknwtg"vkog"////////@"p1c
"NcuV"vguv"hcknwtg"vkog"////////@"p1c
"NcuV"vguv"rcuu"vkog"////////@"Crt"29"4238"32<5:<64
"Vqvcn"hcknwtg"eqwpv"////////////////////////@"2
"EqpugEwvkxg"hcknwtg"eqwpv"////////@"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa
"5+"VguvHgZ0qfgNqqrDcem<
"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3: "3; "42
"////////////////////////
"0"0"0"0"0"W"W"0"0"0"W"W"W"W"W"W"W"W"W"W
"Gttqt"eqfg"////////////////////////@"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"////////////////////////@"3
"NcuV"vguv"vguvkpi"v{rg"////////@"Dqqvwr
"NcuV"vguv"gzgEwvkqp"vkog"////////@"Crt"29"4238"32<5:<69
"Hktuv"vguv"hcknwtg"vkog"////////@"p1c
"NcuV"vguv"hcknwtg"vkog"////////@"p1c

```

```

"NcuV"vguV"rcuu"vkog"/////////@"Crt"29"4238"32<5:<69
"Vqvcn"hcknwtg"eqwpv"/////////@"2
"Eqpugewvkxg"hcknwtg"eqwpv"///@"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"6+"VguvXUCevkxgVqUvcpdf{Nqgrdcem"///@"W

"Gttqt"eqfg"/////////@"5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"/////////@"2
"NcuV"vguV"vguvkpi"v{rg"/////"p1c
"NcuV"vguV"gzgewvkqp"vkog"/////"p1c
"Hktuv"vguV"hcknwtg"vkog"/////"p1c
"NcuV"vguV"hcknwtg"vkog"/////"p1c
"NcuV"vguV"rcuu"vkog"/////////@"p1c
"Vqvcn"hcknwtg"eqwpv"/////////@"2
"Eqpugewvkxg"hcknwtg"eqwpv"///@"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"7+"VguvN4EVUNqgrdcem<

"Rqtv"3"4"5"6"7"8"9";;"32"33"34"35"36"37"38"39"3:"3;"42
"/////////
"0"0"0"0"0"W"W"0"0"0"W"W"W"W"W"W"W"W"W"

"Gttqt"eqfg"/////////@"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"/////////@"3
"NcuV"vguV"vguvkpi"v{rg"/////"Dqqvwr
"NcuV"vguV"gzgewvkqp"vkog"/////"Crt"29"4238"32<5:<6;
"Hktuv"vguV"hcknwtg"vkog"/////"p1c
"NcuV"vguV"hcknwtg"vkog"/////"p1c
"NcuV"vguV"rcuu"vkog"/////////@"Crt"29"4238"32<5:<6;
"Vqvcn"hcknwtg"eqwpv"/////////@"2
"Eqpugewvkxg"hcknwtg"eqwpv"///@"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"8+"VguvN5EVUNqgrdcem<

"Rqtv"3"4"5"6"7"8"9";;"32"33"34"35"36"37"38"39"3:"3;"42
"/////////
"0"0"0"0"0"W"W"0"0"0"W"W"W"W"W"W"W"W"W"

"Gttqt"eqfg"/////////@"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"/////////@"3
"NcuV"vguV"vguvkpi"v{rg"/////"Dqqvwr
"NcuV"vguV"gzgewvkqp"vkog"/////"Crt"29"4238"32<5:<74
"Hktuv"vguV"hcknwtg"vkog"/////"p1c
"NcuV"vguV"hcknwtg"vkog"/////"p1c
"NcuV"vguV"rcuu"vkog"/////////@"Crt"29"4238"32<5:<74
"Vqvcn"hcknwtg"eqwpv"/////////@"2
"Eqpugewvkxg"hcknwtg"eqwpv"///@"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"9+"VguvUetcvejTgikuvgt"/////////@"W

"Gttqt"eqfg"/////////@"5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"/////////@"2
"NcuV"vguV"vguvkpi"v{rg"/////"p1c
"NcuV"vguV"gzgewvkqp"vkog"/////"p1c
"Hktuv"vguV"hcknwtg"vkog"/////"p1c
"NcuV"vguV"hcknwtg"vkog"/////"p1c
"NcuV"vguV"rcuu"vkog"/////////@"p1c
"Vqvcn"hcknwtg"eqwpv"/////////@"2

```

```

"Eqpugewvkxg"hcknwtg"eqwpv"///@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

":+"VguvPgyKpfgzNgctp"//////////@0

"Gttqt"eqfg"//////////@2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"//////////@3
"Ncuv"vguv"vguvkpi"v{rg"////////@Dqqvwr
"Ncuv"vguv"gzegwvkqp"vkog"///@Crt"29"4238"32<5:<78
"Hktuv"vguv"hcknwtg"vkog"////////@p1c
"Ncuv"vguv"hcknwtg"vkog"////////@p1c
"Ncuv"vguv"rcuu"vkog"////////@Crt"29"4238"32<5:<78
"Vqvcn"hcknwtg"eqwpv"////////@2
"Eqpugewvkxg"hcknwtg"eqwpv"///@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

";+"VguvFqpVEqpfkvkqpcnNgctp"//////////@0

"Gttqt"eqfg"//////////@2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"//////////@3
"Ncuv"vguv"vguvkpi"v{rg"////////@Dqqvwr
"Ncuv"vguv"gzegwvkqp"vkog"///@Crt"29"4238"32<5:<78
"Hktuv"vguv"hcknwtg"vkog"////////@p1c
"Ncuv"vguv"hcknwtg"vkog"////////@p1c
"Ncuv"vguv"rcuu"vkog"////////@Crt"29"4238"32<5:<78
"Vqvcn"hcknwtg"eqwpv"////////@2
"Eqpugewvkxg"hcknwtg"eqwpv"///@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"32+"VguvDrfwVtcr"//////////@0

"Gttqt"eqfg"//////////@2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"//////////@3
"Ncuv"vguv"vguvkpi"v{rg"////////@Dqqvwr
"Ncuv"vguv"gzegwvkqp"vkog"///@Crt"29"4238"32<5:<78
"Hktuv"vguv"hcknwtg"vkog"////////@p1c
"Ncuv"vguv"hcknwtg"vkog"////////@p1c
"Ncuv"vguv"rcuu"vkog"////////@Crt"29"4238"32<5:<78
"Vqvcn"hcknwtg"eqwpv"////////@2
"Eqpugewvkxg"hcknwtg"eqwpv"///@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"33+"VguvOcvejEcrvwtg"//////////@0

"Gttqt"eqfg"//////////@2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"//////////@3
"Ncuv"vguv"vguvkpi"v{rg"////////@Dqqvwr
"Ncuv"vguv"gzegwvkqp"vkog"///@Crt"29"4238"32<5:<78
"Hktuv"vguv"hcknwtg"vkog"////////@p1c
"Ncuv"vguv"hcknwtg"vkog"////////@p1c
"Ncuv"vguv"rcuu"vkog"////////@Crt"29"4238"32<5:<78
"Vqvcn"hcknwtg"eqwpv"////////@2
"Eqpugewvkxg"hcknwtg"eqwpv"///@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"34+"VguvRtqvqeqnOcvejEjcppgn"//////////@W

"Gttqt"eqfg"//////////@57:"*FKCIaUMKRRGFaRQTVaNQQRDCeMaPQVaCNNQYGF+
"Vqvcn"twp"eqwpv"//////////@2
"Ncuv"vguv"vguvkpi"v{rg"////////@p1c
"Ncuv"vguv"gzegwvkqp"vkog"///@p1c
"Hktuv"vguv"hcknwtg"vkog"////////@p1c
"Ncuv"vguv"hcknwtg"vkog"////////@p1c
"Ncuv"vguv"rcuu"vkog"////////@p1c

```

Supervisor Engine 6T Software Configuration Guide, Release 15.4SY


```

"NcuV"vguv"rcuu"vkog"/////////"Crt"29"4238"32<5:<79
"Vqvcn"hcknwtg"eqwpv"/////////"2
"Eqpugewvkg"hcknwtg"eqwpv"/////////"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"3;+"VguvPCVHkdUjqtviewv"/////////"0

"Gttqt"eqfg"/////////"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"/////////"3
"NcuV"vguv"vguvkpi"v{rg"/////////"Dqqvwr
"NcuV"vguv"gzgewvkqp"vkog"/////////"Crt"29"4238"32<5:<79
"Hktuv"vguv"hcknwtg"vkog"/////////"p1c
"NcuV"vguv"hcknwtg"vkog"/////////"p1c
"NcuV"vguv"rcuu"vkog"/////////"Crt"29"4238"32<5:<79
"Vqvcn"hcknwtg"eqwpv"/////////"2
"Eqpugewvkg"hcknwtg"eqwpv"/////////"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"3;+"VguvCenRgtokv"/////////"0

"Gttqt"eqfg"/////////"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"/////////"3
"NcuV"vguv"vguvkpi"v{rg"/////////"Dqqvwr
"NcuV"vguv"gzgewvkqp"vkog"/////////"Crt"29"4238"32<5:<79
"Hktuv"vguv"hcknwtg"vkog"/////////"p1c
"NcuV"vguv"hcknwtg"vkog"/////////"p1c
"NcuV"vguv"rcuu"vkog"/////////"Crt"29"4238"32<5:<79
"Vqvcn"hcknwtg"eqwpv"/////////"2
"Eqpugewvkg"hcknwtg"eqwpv"/////////"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"42+"VguvCenFgp{"/////////"0

"Gttqt"eqfg"/////////"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"/////////"3
"NcuV"vguv"vguvkpi"v{rg"/////////"Dqqvwr
"NcuV"vguv"gzgewvkqp"vkog"/////////"Crt"29"4238"32<5:<79
"Hktuv"vguv"hcknwtg"vkog"/////////"p1c
"NcuV"vguv"hcknwtg"vkog"/////////"p1c
"NcuV"vguv"rcuu"vkog"/////////"Crt"29"4238"32<5:<79
"Vqvcn"hcknwtg"eqwpv"/////////"2
"Eqpugewvkg"hcknwtg"eqwpv"/////////"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"43+"VguvCenTgfkTgeVTDcen"/////////"0

"Gttqt"eqfg"/////////"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"/////////"3
"NcuV"vguv"vguvkpi"v{rg"/////////"Dqqvwr
"NcuV"vguv"gzgewvkqp"vkog"/////////"Crt"29"4238"32<5:<79
"Hktuv"vguv"hcknwtg"vkog"/////////"p1c
"NcuV"vguv"hcknwtg"vkog"/////////"p1c
"NcuV"vguv"rcuu"vkog"/////////"Crt"29"4238"32<5:<79
"Vqvcn"hcknwtg"eqwpv"/////////"2
"Eqpugewvkg"hcknwtg"eqwpv"/////////"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"44+"VguvSquFSWR"/////////"0

"Gttqt"eqfg"/////////"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"/////////"3
"NcuV"vguv"vguvkpi"v{rg"/////////"Dqqvwr
"NcuV"vguv"gzgewvkqp"vkog"/////////"Crt"29"4238"32<5:<79
"Hktuv"vguv"hcknwtg"vkog"/////////"p1c

```

```

"NcuV"vguV"hcknwtg"vkog"////@p1c
"NcuV"vguV"rcuu"vkog"////@Crt"29"4238"32<5:<79
"Vqvcn"hcknwtg"eqwpv"////@2
"Eqpugewvkxg"hcknwtg"eqwpv"//@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"45+"VguvN5XncpOgv"////@0

"Gttqt"eqfg"////@2"FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"////@3
"NcuV"vguV"vguvkpi"v{rg"////@Dqqvwr
"NcuV"vguV"gzgewvkqp"vkog"////@Crt"29"4238"32<5:<79
"Hktuv"vguV"hcknwtg"vkog"////@p1c
"NcuV"vguV"hcknwtg"vkog"////@p1c
"NcuV"vguV"rcuu"vkog"////@Crt"29"4238"32<5:<79
"Vqvcn"hcknwtg"eqwpv"////@2
"Eqpugewvkxg"hcknwtg"eqwpv"//@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"46+"VguvKpitguuGitguuUrcp"////@0

"Gttqt"eqfg"////@2"FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"////@3
"NcuV"vguV"vguvkpi"v{rg"////@Dqqvwr
"NcuV"vguV"gzgewvkqp"vkog"////@Crt"29"4238"32<5:<7:
"Hktuv"vguV"hcknwtg"vkog"////@p1c
"NcuV"vguV"hcknwtg"vkog"////@p1c
"NcuV"vguV"rcuu"vkog"////@Crt"29"4238"32<5:<7:
"Vqvcn"hcknwtg"eqwpv"////@2
"Eqpugewvkxg"hcknwtg"eqwpv"//@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"47+"VguvPgvhngyUjqtviewv"////@0

"Gttqt"eqfg"////@2"FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"////@3
"NcuV"vguV"vguvkpi"v{rg"////@Dqqvwr
"NcuV"vguV"gzgewvkqp"vkog"////@Crt"29"4238"32<5:<7;
"Hktuv"vguV"hcknwtg"vkog"////@p1c
"NcuV"vguV"hcknwtg"vkog"////@p1c
"NcuV"vguV"rcuu"vkog"////@Crt"29"4238"32<5:<7;
"Vqvcn"hcknwtg"eqwpv"////@2
"Eqpugewvkxg"hcknwtg"eqwpv"//@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"48+"VguvKpdcpfGfkv"////@0

"Gttqt"eqfg"////@2"FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"////@3
"NcuV"vguV"vguvkpi"v{rg"////@Dqqvwr
"NcuV"vguV"gzgewvkqp"vkog"////@Crt"29"4238"32<5:<7;
"Hktuv"vguV"hcknwtg"vkog"////@p1c
"NcuV"vguV"hcknwtg"vkog"////@p1c
"NcuV"vguV"rcuu"vkog"////@Crt"29"4238"32<5:<7;
"Vqvcn"hcknwtg"eqwpv"////@2
"Eqpugewvkxg"hcknwtg"eqwpv"//@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"49+"VguvHcdtkeXncpNqqrdecem"////@0

"Gttqt"eqfg"////@2"FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"////@3
"NcuV"vguV"vguvkpi"v{rg"////@Dqqvwr
"NcuV"vguV"gzgewvkqp"vkog"////@Crt"29"4238"32<5:<7;

```

```

"Hktuv"vguv"hcknwtg"vkog"////@p1c
"Ncu"vguv"hcknwtg"vkog"////@p1c
"Ncu"vguv"rcuu"vkog"////////@Crt"29"4238"32<5:<7;
"Vqvcn"hcknwtg"eqwpv"////////@2
"Eqpugewvkxg"hcknwtg"eqwpv"///@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"4:+"VguvVtchhkeUvtguu"////////@W

"Gttqt"eqfg"////////@5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"////////@2
"Ncu"vguv"vguvkpi"v{rg"////@p1c
"Ncu"vguv"gzgewvkqp"vkog"////@p1c
"Hktuv"vguv"hcknwtg"vkog"////@p1c
"Ncu"vguv"hcknwtg"vkog"////@p1c
"Ncu"vguv"rcuu"vkog"////////@p1c
"Vqvcn"hcknwtg"eqwpv"////////@2
"Eqpugewvkxg"hcknwtg"eqwpv"///@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"4;+"VguvN5VecoOqpkvqtkpi"////////@W

"Gttqt"eqfg"////////@5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"////////@2
"Ncu"vguv"vguvkpi"v{rg"////@p1c
"Ncu"vguv"gzgewvkqp"vkog"////@p1c
"Hktuv"vguv"hcknwtg"vkog"////@p1c
"Ncu"vguv"hcknwtg"vkog"////@p1c
"Ncu"vguv"rcuu"vkog"////////@p1c
"Vqvcn"hcknwtg"eqwpv"////////@2
"Eqpugewvkxg"hcknwtg"eqwpv"///@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"52+"VguvHkdVeco"////////@W

"Gttqt"eqfg"////////@5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"////////@2
"Ncu"vguv"vguvkpi"v{rg"////@p1c
"Ncu"vguv"gzgewvkqp"vkog"////@p1c
"Hktuv"vguv"hcknwtg"vkog"////@p1c
"Ncu"vguv"hcknwtg"vkog"////@p1c
"Ncu"vguv"rcuu"vkog"////////@p1c
"Vqvcn"hcknwtg"eqwpv"////////@2
"Eqpugewvkxg"hcknwtg"eqwpv"///@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"53+"VguvCenSquVeco"////////@W

"Gttqt"eqfg"////////@5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"////////@2
"Ncu"vguv"vguvkpi"v{rg"////@p1c
"Ncu"vguv"gzgewvkqp"vkog"////@p1c
"Hktuv"vguv"hcknwtg"vkog"////@p1c
"Ncu"vguv"hcknwtg"vkog"////@p1c
"Ncu"vguv"rcuu"vkog"////////@p1c
"Vqvcn"hcknwtg"eqwpv"////////@2
"Eqpugewvkxg"hcknwtg"eqwpv"///@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"54+"VguvGctnOgoQpDqqvwr"////////@0

"Gttqt"eqfg"////////@2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"////////@3
"Ncu"vguv"vguvkpi"v{rg"////@Dqqvwr

```

```

"NcuV"vguV"gzgewvkqp"vkog"////@ "Crt "29"4238"32<5:<7;
"Hktuv"vguv"hcknwtg"vkog"////@ "p1c
"NcuV"vguV"hcknwtg"vkog"////@ "p1c
"NcuV"vguV"rcuu"vkog"////@ "Crt "29"4238"32<5:<7;
"Vqvcn"hcknwtg"eqwpv"////@ "2
"Eqpugewvkxg"hcknwtg"eqwpv"//@ "2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"55+"VguvCukeOgoqt { "//////////@ "W

"Gttqt"eqfg"//////////@ "5" *FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"//////////@ "2
"NcuV"vguV"vguvkpi"v{rg"////@ "p1c
"NcuV"vguV"gzgewvkqp"vkog"////@ "p1c
"Hktuv"vguv"hcknwtg"vkog"////@ "p1c
"NcuV"vguV"hcknwtg"vkog"////@ "p1c
"NcuV"vguV"rcuu"vkog"////@ "p1c
"Vqvcn"hcknwtg"eqwpv"//////////@ "2
"Eqpugewvkxg"hcknwtg"eqwpv"//@ "2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"56+"VguvGqdeUvtguuRkpi"//////////@ "W

"Gttqt"eqfg"//////////@ "5" *FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"//////////@ "2
"NcuV"vguV"vguvkpi"v{rg"////@ "p1c
"NcuV"vguV"gzgewvkqp"vkog"////@ "p1c
"Hktuv"vguv"hcknwtg"vkog"////@ "p1c
"NcuV"vguV"hcknwtg"vkog"////@ "p1c
"NcuV"vguV"rcuu"vkog"////@ "p1c
"Vqvcn"hcknwtg"eqwpv"//////////@ "2
"Eqpugewvkxg"hcknwtg"eqwpv"//@ "2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"57+"VguvHktoyctgFkciUvcvwu"//////////@ "0

"Gttqt"eqfg"//////////@ "2" *FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"//////////@ "3
"NcuV"vguV"vguvkpi"v{rg"////@ "Dqqvwr
"NcuV"vguV"gzgewvkqp"vkog"////@ "Crt "29"4238"32<5:<7;
"Hktuv"vguv"hcknwtg"vkog"////@ "p1c
"NcuV"vguV"hcknwtg"vkog"////@ "p1c
"NcuV"vguV"rcuu"vkog"////@ "Crt "29"4238"32<5:<7;
"Vqvcn"hcknwtg"eqwpv"//////////@ "2
"Eqpugewvkxg"hcknwtg"eqwpv"//@ "2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"58+"VguvCukeU{pe"//////////@ "W

"Gttqt"eqfg"//////////@ "5" *FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"//////////@ "2
"NcuV"vguV"vguvkpi"v{rg"////@ "p1c
"NcuV"vguV"gzgewvkqp"vkog"////@ "p1c
"Hktuv"vguv"hcknwtg"vkog"////@ "p1c
"NcuV"vguV"hcknwtg"vkog"////@ "p1c
"NcuV"vguV"rcuu"vkog"////@ "p1c
"Vqvcn"hcknwtg"eqwpv"//////////@ "2
"Eqpugewvkxg"hcknwtg"eqwpv"//@ "2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"59+"VguvWpwugfRqtvNqgrdcem<

"Rqtv"3"4"5"6"7"8"9";";"32"33"34"35"36"37"38"39"3:"3;"42
"//////////

```

```

"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W

```

```

"Gttqt"eqfg"/////////////////@"5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"/////////////////@"2
"Ncuv"vguv"vguvkpi"v{rg"/////////@"p1c
"Ncuv"vguv"gzgewvkqp"vkog"/////////@"p1c
"Hktuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"rcuu"vkog"/////////@"p1c
"Vqvcn"hcknwtg"eqwpv"/////////@"2
"Eqpugewvkxg"hcknwtg"eqwpv"/////////@"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"5:+"VguvPqpFkutwrvkxgNqgrdcem<

"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3: "3; "42
"//////////////////////////
"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W

```

```

"Gttqt"eqfg"/////////////////@"5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"/////////////////@"2
"Ncuv"vguv"vguvkpi"v{rg"/////////@"p1c
"Ncuv"vguv"gzgewvkqp"vkog"/////////@"p1c
"Hktuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"rcuu"vkog"/////////@"p1c
"Vqvcn"hcknwtg"eqwpv"/////////@"2
"Eqpugewvkxg"hcknwtg"eqwpv"/////////@"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"5;+"VguvHcdtkeHnqyEqpvtqnUvcvwu"/////////@"W

"Gttqt"eqfg"/////////////////@"5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"/////////////////@"2
"Ncuv"vguv"vguvkpi"v{rg"/////////@"p1c
"Ncuv"vguv"gzgewvkqp"vkog"/////////@"p1c
"Hktuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"rcuu"vkog"/////////@"p1c
"Vqvcn"hcknwtg"eqwpv"/////////@"2
"Eqpugewvkxg"hcknwtg"eqwpv"/////////@"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"62+"VguvRqtvVzOqpkvqtkpi<

"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3: "3; "42
"//////////////////////////
"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W

```

```

"Gttqt"eqfg"/////////////////@"5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"/////////////////@"2
"Ncuv"vguv"vguvkpi"v{rg"/////////@"p1c
"Ncuv"vguv"gzgewvkqp"vkog"/////////@"p1c
"Hktuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"rcuu"vkog"/////////@"p1c
"Vqvcn"hcknwtg"eqwpv"/////////@"2
"Eqpugewvkxg"hcknwtg"eqwpv"/////////@"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"63+"VguvQDHN"/////////////////@"0

```

```
"Gttqt"eqfg"/////////////////@"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"/////////////////@3
"Ncu"v"vguv"vguvkpi"v{rg"/////////@Dqqvwr
"Ncu"v"vguv"gzgewvkqp"vkog"/////////@Crt"29"4238"32<5:<7;
"Hktuv"vguv"hcknwtg"vkog"/////////@p1c
"Ncu"v"vguv"hcknwtg"vkog"/////////@p1c
"Ncu"v"vguv"rcuu"vkog"/////////@Crt"29"4238"32<5:<7;
"Vqvcn"hcknwtg"eqwpv"/////////////////@2
"Eqpugewvkxg"hcknwtg"eqwpv"/////////@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa
```

```
"64+"VguyEHTY<
```

```
"Fgxkeg"3
"////////
"W
```

```
"Gttqt"eqfg"/////////////////@"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"/////////////////@3
"Ncu"v"vguv"vguvkpi"v{rg"/////////@Dqqvwr
"Ncu"v"vguv"gzgewvkqp"vkog"/////////@Crt"29"4238"32<5:<7;
"Hktuv"vguv"hcknwtg"vkog"/////////@p1c
"Ncu"v"vguv"hcknwtg"vkog"/////////@p1c
"Ncu"v"vguv"rcuu"vkog"/////////@Crt"29"4238"32<5:<7;
"Vqvcn"hcknwtg"eqwpv"/////////////////@2
"Eqpugewvkxg"hcknwtg"eqwpv"/////////@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa
```

```
"65+"VguyNvnHrqqOgoqt{Eqpukuvgpe{"/////////@"W
```

```
"Gttqt"eqfg"/////////////////@"5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"/////////////////@2
"Ncu"v"vguv"vguvkpi"v{rg"/////////@p1c
"Ncu"v"vguv"gzgewvkqp"vkog"/////////@p1c
"Hktuv"vguv"hcknwtg"vkog"/////////@p1c
"Ncu"v"vguv"hcknwtg"vkog"/////////@p1c
"Ncu"v"vguv"rcuu"vkog"/////////@p1c
"Vqvcn"hcknwtg"eqwpv"/////////////////@2
"Eqpugewvkxg"hcknwtg"eqwpv"/////////@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa
```

```
"66+"VguyTyGpikpgQxgtUwduetkrvkqp"/////////@"W
```

```
"Gttqt"eqfg"/////////////////@"5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"/////////////////@2
"Ncu"v"vguv"vguvkpi"v{rg"/////////@p1c
"Ncu"v"vguv"gzgewvkqp"vkog"/////////@p1c
"Hktuv"vguv"hcknwtg"vkog"/////////@p1c
"Ncu"v"vguv"hcknwtg"vkog"/////////@p1c
"Ncu"v"vguv"rcuu"vkog"/////////@p1c
"Vqvcn"hcknwtg"eqwpv"/////////////////@2
"Eqpugewvkxg"hcknwtg"eqwpv"/////////@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa
```

```
"67+"VguyGttqtEqwpvgtOqpkvqt"/////////@"W
```

```
"Gttqt"eqfg"/////////////////@"5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"/////////////////@2
"Ncu"v"vguv"vguvkpi"v{rg"/////////@p1c
"Ncu"v"vguv"gzgewvkqp"vkog"/////////@p1c
"Hktuv"vguv"hcknwtg"vkog"/////////@p1c
"Ncu"v"vguv"hcknwtg"vkog"/////////@p1c
```

```

"Ncuv"vguv"rcuu"vkog"/////////@"p1c
"Vqvcn"hcknwtg"eqwpv"/////////@"2
"Eqpugewvkxg"hcknwtg"eqwpv"///@"2
"Gttqt"Tgeqtfu"/////////@"p1c
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"68+"VguvXunDtkfigNkpm"/////////@"0

"Gttqt"eqfg"/////////@"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"/////////@"3
"Ncuv"vguv"vguvkpi"v{rg"/////////@"Dqqvwr
"Ncuv"vguv"gzgewvkqp"vkog"///@"Crt"29"4238"32<5:<7;
"Hktuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"rcuu"vkog"/////////@"Crt"29"4238"32<5:<7;
"Vqvcn"hcknwtg"eqwpv"/////////@"2
"Eqpugewvkxg"hcknwtg"eqwpv"///@"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"69+"VguvXunNqecnNqqrdecem<

"Rgtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3: "3; "42
"/////////
"0"0"0"0"0"0"0"0"0"0"W"W"W"W"W"W"W"W"W

"Gttqt"eqfg"/////////@"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"/////////@"3
"Ncuv"vguv"vguvkpi"v{rg"/////////@"Dqqvwr
"Ncuv"vguv"gzgewvkqp"vkog"///@"Crt"29"4238"32<5;<22
"Hktuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"rcuu"vkog"/////////@"Crt"29"4238"32<5;<22
"Vqvcn"hcknwtg"eqwpv"/////////@"2
"Eqpugewvkxg"hcknwtg"eqwpv"///@"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"6:+"VguvXunUvcvwu<

"Rgtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3: "3; "42
"/////////
"W"W"W"W"W"0"0"W"W"W"W"W"W"W"W"W"W"W"W

"Gttqt"eqfg"/////////@"2"*FKCIaUWEEGUU+
"Vqvcn"twp"eqwpv"/////////@"4
"Ncuv"vguv"vguvkpi"v{rg"/////////@"Jgcnvj"Oqpkvqtkpi
"Ncuv"vguv"gzgewvkqp"vkog"///@"Crt"29"4238"34<28<48
"Hktuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"rcuu"vkog"/////////@"Crt"29"4238"34<28<48
"Vqvcn"hcknwtg"eqwpv"/////////@"2
"Eqpugewvkxg"hcknwtg"eqwpv"///@"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"6:+"VguvGCTNkpvgtpcnVcdngu"/////////@"W

"Gttqt"eqfg"/////////@"5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"/////////@"2
"Ncuv"vguv"vguvkpi"v{rg"/////////@"p1c
"Ncuv"vguv"gzgewvkqp"vkog"///@"p1c
"Hktuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"hcknwtg"vkog"/////////@"p1c
"Ncuv"vguv"rcuu"vkog"/////////@"p1c

```

```

"Vqvcn"hcknwtg"eqwpv"/////////@"2
"Eqpugewvkxg"hcknwtg"eqwpv"/////////@"2

"CIG"ITQWR
"Vqvcn"EE"twp"eqwpv"/////////@"2
"Vcdng"uk|g"/////////@"2
"Vqvcn"hckn"eqwpv"/////////@"2
"Vqvcn"eqttgevkqp"eqwpv"/////////@"2
"NcuV"eqorngvkkp"vkog"/////////@"Crt"29"4238"32<55<6;
"NcuV"tguwnv"/////////@"WPMPQYP
"NcuV"hckn"eqwpv"/////////@"2
"NcuV"eqttgevkqp"eqwpv"/////////@"2
"NcuV"gpvtkgu"ejgemgt"/////////@"2
"Eqpukuvgpe{"ejgemgt"/////////@"QHH

"DWPFNG"RQTV"OCR
"Vqvcn"EE"twp"eqwpv"/////////@"2
"Vcdng"uk|g"/////////@"2
"Vqvcn"hckn"eqwpv"/////////@"2
"Vqvcn"eqttgevkqp"eqwpv"/////////@"2
"NcuV"eqorngvkkp"vkog"/////////@"Crt"29"4238"32<55<6;
"NcuV"tguwnv"/////////@"WPMPQYP
"NcuV"hckn"eqwpv"/////////@"2
"NcuV"eqttgevkqp"eqwpv"/////////@"2
"NcuV"gpvtkgu"ejgemgt"/////////@"2
"Eqpukuvgpe{"ejgemgt"/////////@"QHH

"DWPFNG"GZVGPUPKQP"OCR
"Vqvcn"EE"twp"eqwpv"/////////@"2
"Vcdng"uk|g"/////////@"2
"Vqvcn"hckn"eqwpv"/////////@"2
"Vqvcn"eqttgevkqp"eqwpv"/////////@"2
"NcuV"eqorngvkkp"vkog"/////////@"Crt"29"4238"32<55<6;
"NcuV"tguwnv"/////////@"WPMPQYP
"NcuV"hckn"eqwpv"/////////@"2
"NcuV"eqttgevkqp"eqwpv"/////////@"2
"NcuV"gpvtkgu"ejgemgt"/////////@"2
"Eqpukuvgpe{"ejgemgt"/////////@"QHH

"XNCP"CEEGUU"QOFG"OGOQT[
"Vqvcn"EE"twp"eqwpv"/////////@"2
"Vcdng"uk|g"/////////@"2
"Vqvcn"hckn"eqwpv"/////////@"2
"Vqvcn"eqttgevkqp"eqwpv"/////////@"2
"NcuV"eqorngvkkp"vkog"/////////@"Crt"29"4238"32<55<6;
"NcuV"tguwnv"/////////@"WPMPQYP
"NcuV"hckn"eqwpv"/////////@"2
"NcuV"eqttgevkqp"eqwpv"/////////@"2
"NcuV"gpvtkgu"ejgemgt"/////////@"2
"Eqpukuvgpe{"ejgemgt"/////////@"QHH
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"72+"VguyPXTCODcvvgt{Oqpkvqt"/////////@"W

"Gttqt"eqfg"/////////@"5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"/////////@"2
"NcuV"vguv"vguvkpi"v{rg"/////////@"p1c
"NcuV"vguv"gzgewvkkp"vkog"/////////@"p1c
"Hktuy"vguv"hcknwtg"vkog"/////////@"p1c
"NcuV"vguv"hcknwtg"vkog"/////////@"p1c
"NcuV"vguv"rcuu"vkog"/////////@"p1c
"Vqvcn"hcknwtg"eqwpv"/////////@"2
"Eqpugewvkxg"hcknwtg"eqwpv"/////////@"2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

```



```

"73+"VguvOgfkcNqqrdcem<

"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3: "3; "42
"////////////////////////
"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W

"Gttqt"eqfg"////////////////@ "5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"////////////////@ "2
"Ncuv"vguv"vguvkpi"v{rg"////////@ "p1c
"Ncuv"vguv"gzgewvkqp"vkog"////////@ "p1c
"Hktuv"vguv"hcknwtg"vkog"////////@ "p1c
"Ncuv"vguv"hcknwtg"vkog"////////@ "p1c
"Ncuv"vguv"rcuu"vkog"////////@ "p1c
"Vqvcn"hcknwtg"eqwpv"////////@ "2
"Eqpugewvkxg"hcknwtg"eqwpv"///@ "2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"74+"VguvOketqdwutuv<

"Rqtv"3"4"5"6"7"8"9": "; "32"33"34"35"36"37"38"39"3: "3; "42
"////////////////////////
"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W

"Gttqt"eqfg"////////////////@ "5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"////////////////@ "2
"Ncuv"vguv"vguvkpi"v{rg"////////@ "p1c
"Ncuv"vguv"gzgewvkqp"vkog"////////@ "p1c
"Hktuv"vguv"hcknwtg"vkog"////////@ "p1c
"Ncuv"vguv"hcknwtg"vkog"////////@ "p1c
"Ncuv"vguv"rcuu"vkog"////////@ "p1c
"Vqvcn"hcknwtg"eqwpv"////////@ "2
"Eqpugewvkxg"hcknwtg"eqwpv"///@ "2

"Eqpugewvkxg"oketqdwutuv"eqwpv"///@ "2
"Ncuv"oketqdwutuv"gxgpv"vkog"////////@ "p1c
"Ncuv"oketqdwutuv"rqtvu"////////@ "p1c
"Rqtv"3<
"Kpitguu"Ftqr"Eqwpv"////////@ "p1c
"Gitguu"Ftqr"Eqwpv"////////@ "p1c

"Rqtv"4<
"Kpitguu"Ftqr"Eqwpv"////////@ "p1c
"Gitguu"Ftqr"Eqwpv"////////@ "p1c

"Rqtv"5<
"Kpitguu"Ftqr"Eqwpv"////////@ "p1c
"Gitguu"Ftqr"Eqwpv"////////@ "p1c

"Rqtv"6<
"Kpitguu"Ftqr"Eqwpv"////////@ "p1c
"Gitguu"Ftqr"Eqwpv"////////@ "p1c

"Rqtv"7<
"Kpitguu"Ftqr"Eqwpv"////////@ "p1c
"Gitguu"Ftqr"Eqwpv"////////@ "p1c

"Rqtv"8<
"Kpitguu"Ftqr"Eqwpv"////////@ "p1c
"Gitguu"Ftqr"Eqwpv"////////@ "p1c

"Rqtv"9<

```

```

"Kpitguu"Ftqr"Eqwpv"/////////@"p1c
"Gitguu"Ftqr"Eqwpv"/////////@"p1c

"Rqtv":<
"Kpitguu"Ftqr"Eqwpv"/////////@"p1c
"Gitguu"Ftqr"Eqwpv"/////////@"p1c

"Rqtv";<
"Kpitguu"Ftqr"Eqwpv"/////////@"p1c
"Gitguu"Ftqr"Eqwpv"/////////@"p1c

"Rqtv"32<
"Kpitguu"Ftqr"Eqwpv"/////////@"p1c
"Gitguu"Ftqr"Eqwpv"/////////@"p1c

"Rqtv"33<
"Kpitguu"Ftqr"Eqwpv"/////////@"p1c
"Gitguu"Ftqr"Eqwpv"/////////@"p1c

"Rqtv"34<
"Kpitguu"Ftqr"Eqwpv"/////////@"p1c
"Gitguu"Ftqr"Eqwpv"/////////@"p1c

"Rqtv"35<
"Kpitguu"Ftqr"Eqwpv"/////////@"p1c
"Gitguu"Ftqr"Eqwpv"/////////@"p1c

"Rqtv"36<
"Kpitguu"Ftqr"Eqwpv"/////////@"p1c
"Gitguu"Ftqr"Eqwpv"/////////@"p1c

"Rqtv"37<
"Kpitguu"Ftqr"Eqwpv"/////////@"p1c
"Gitguu"Ftqr"Eqwpv"/////////@"p1c

"Rqtv"38<
"Kpitguu"Ftqr"Eqwpv"/////////@"p1c
"Gitguu"Ftqr"Eqwpv"/////////@"p1c

"Rqtv"39<
"Kpitguu"Ftqr"Eqwpv"/////////@"p1c
"Gitguu"Ftqr"Eqwpv"/////////@"p1c

"Rqtv"3:<
"Kpitguu"Ftqr"Eqwpv"/////////@"p1c
"Gitguu"Ftqr"Eqwpv"/////////@"p1c

"Rqtv"3;<
"Kpitguu"Ftqr"Eqwpv"/////////@"p1c
"Gitguu"Ftqr"Eqwpv"/////////@"p1c

"Rqtv"42<
"Kpitguu"Ftqr"Eqwpv"/////////@"p1c
"Gitguu"Ftqr"Eqwpv"/////////@"p1c

"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa

"75+"VguvHGZHcdtkeNkpmUvcvwu<

"Rqtv"3"4"5"6"7"8"9";;"32"33"34"35"36"37"38"39"3:"3;"42
"////////////////////////////////////
"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"W"

```

```
"Gttqt"eqfg"////////////////////@5"*FKCIaUMKRRGF+
"Vqvcn"twp"eqwpv"////////////////////@2
"Ncuv"vguv"vguvkpi"v{rg"////////@p1c
"Ncuv"vguv"gzgewvkqp"vkog"////@p1c
"Hktuv"vguv"hcknwtg"vkog"////@p1c
"Ncuv"vguv"hcknwtg"vkog"////////@p1c
"Ncuv"vguv"rcuu"vkog"////////@p1c
"Vqvcn"hcknwtg"eqwpv"////////////////////@2
"Eqpugewvkxg"hcknwtg"eqwpv"////@2
"aaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaaa
```

Tqwvgt%

This example shows how to display the output for the health checks performed:

```
Tqwvgt%"ujqy"fkciqquvke"jgcenvj"
Pqp/|gtq"rqtv"eqwpvgtu"hqt"816"/
350"nkpmEjcpig"?":752
```

```
Pqp/|gtq"rqtv"eqwpvgtu"hqt"817"/
350"nkpmEjcpig"?":752
```

Tqwvgt%

How to Perform Memory Tests

Most online diagnostic tests do not need any special setup or configuration. However, the memory tests, which include the TestFibTcamSSRAM and TestLinecardMemory tests, have some required tasks and some recommended tasks that you should complete before running them.

Before you run any of the online diagnostic memory tests, perform the following tasks:

- Required tasks
 - Isolate network traffic by disabling all connected ports.
 - Do not send test packets during a memory test.
 - Reset the system before returning the system to normal operating mode.
- Turn off all background health-monitoring tests using the **no diagnostic monitor module number test all** command.

How to Perform a Diagnostic Sanity Check

You can run the diagnostic sanity check in order to see potential problem areas in your network. The sanity check runs a set of predetermined checks on the configuration with a possible combination of certain system states to compile a list of warning conditions. The checks are designed to look for anything that seems out of place and are intended to serve as an aid for maintaining the system sanity.

To run the diagnostic sanity check, perform this task:

Command	Purpose
ujqy"fkciqquvke"ucpkv{	Runs a set of tests on the configuration and certain system states.

This example displays samples of the messages that could be displayed with the **show diagnostic sanity** command:

```
Tqwvgt%"ujqy"fkcipquvke"ucpkv{
Rkpikpi"fghcwnv"icvgye{"3208036303"0000
V{rg"guecrg"ugswgpeg"vq"cdqtv0
Ugpfkpi"7"."322/d{vg"KEOR"Gejqu"vq"3208036303"."vkogqvv"ku"4"ugeqpfu<
00##0
Uweeguu"tcvg"ku"2"rgtegpv"*217+

KIOR"upqqrkpi"fkucdngf"rngcug"gpdcng"kv"hqt"qrvkowo"eqphki0

KIOR"upqqrkpi"fkucdngf"dwv"TIOR"gpdcngf"qp"vjg"hqnnqykpi"kpvgthcegu.
rngcug"gpdcng"KIOR"hqt"rtqrgt"eqphki"<"
Xncp3"."Xncp4"."IkicdkvGvjgtpgv313

Ownvkecuv"tqwkpi"ku"gpdcngf"inqdcnn{"dwv"pqv"gpdcngf"qp"vjg"hqnnqykpi"
kpvgthcegu<
IkicdkvGvjgtpgv313"."IkicdkvGvjgtpgv314

C"rtqitcookpi"cnigtkvjo"okuocvej"ycu"hwqpf"qp"vjg"fgxkeg"dqqvhncuj<
Hqtocvvkpi"vjg"fgxkeg"ku"tgeqoogpfgf0

Vjg"dqqvhncuj<"fqqg"pqv"jcxg"gpqwij"htgg"urceg"vq"ceeqoqfcvg"vjg"etcujkphq"hkng0"

Rngcug"ejgem"{qwt"eqphtgi"xcnwg"<"2z20

Rngcug"ejgem"{qwt"eqphtgi"xcnwg"qp"uvcpfd{<"2z20

Vjg"dqqv"uvtkpi"ku"gorv{0"Rngcug"gpvgv"q"xcnkf"dqqv"uvtkpi"0
Eqwnf"pqv"xgtkh{"dqqv"kocig"$fkum2<$"urgekhkgf"kp"vjg"dqqv"uvtkpi"qp"vjg
uncxg0

Kpxcnkf"dqqv"kocig"$dqqvhncuj<cuvcuf"$urgekhkgf"kp"vjg"dqqv"uvtkpi"qp"vjg
uncxg0

Rngcug"ejgem">{qwt"dqqv"uvtkpi"qp"vjg"uncxg0

WFNF"jcu"dggp"fkucdngf"inqdcnn{"rqtvtv/ngxgn"WFNF"ucpkv{"ejgemu"ctg"
dgkpi"d{rcuugf0
QT
}
Vjg"hqnnqykpi"rqtvtv"jcxg"WFNF"fkucdngf0"Rngcug"gpdcng"WFNF"hqt"qrvkowo
eqphki<
Ik3144

Vjg"hqnnqykpi"rqtvtv"jcxg"cp"wpmpqyp"WFNF"nkpm"uvvcvg0"Rngcug"gpdcng"WFNF
qp"dqvj"ukfgu"qh"vjg"nkpm<
Ik3144

—

Vjg"hqnnqykpi"rqtvtv"jcxg"rqtvhcuv"gpdcngf<
Ik3142"."Ik3144

Vjg"hqnnqykpi"rqtvtv"jcxg"vtwpm"oqfg"ugv"vq"qp<
Ik313"."Ik3135

Vjg"hqnnqykpi"vtwpmu"jcxg"oqfg"ugv"vq"cwvq<
Ik314"."Ik315

Vjg"hqnnqykpi"rqtvtv"ykvj"oqfg"ugv"vq"fguktcdng"ctg"pqv"vtwpmkpi<
Ik315"."Ik316
```

```
Vjg"hqnnqykpi"vtwpm"rqtvu"jcxg"pgiqvkcvgf"vq"jcnh/fwrngz<
Ik315."Ik316
```

```
Vjg"hqnnqykpi"rqtvu"ctg"eqphkiwtgf"hqt"ejcppgn"oqfg"qp<
Ik313."Ik314."Ik315."Ik316
```

```
Vjg"hqnnqykpi"rqtvu."pqv"ejcppgnkpi"ctg"eqphkiwtgf"hqt"ejcppgn"oqfg
fguktcnng<
Ik3136
```

```
Vjg"hqnnqykpi"xncp*u+"jcxg"c"urcppkpi"vtgg"tqqv"qh"5498:<
3
```

```
Vjg"hqnnqykpi"xncp*u+"jcxg"ocz"dig"qp"vjg"urcppkpi"vtgg"tqqv"fkhhgtgppv"htqo
vjg"fghcwnv<
3/4
```

```
Vjg"hqnnqykpi"xncp*u+"jcxg"htyctf"fgnc{"qp"vjg"urcppkpi"vtgg"tqqv"fkhhgtgppv
htqo"vjg"fghcwnv<
3/4
```

```
Vjg"hqnnqykpi"xncp*u+"jcxg"jgnnq"vkog"qp"vjg"urcppkpi"vtgg"tqqv"fkhhgtgppv
htqo"vjg"fghcwnv<
3/4
```

```
Vjg"hqnnqykpi"xncp*u+"jcxg"ocz"dig"qp"vjg"dtkfig"fkhhgtgppv"htqo"vjg
fghcwnv<
3/4
```

```
Vjg"hqnnqykpi"xncp*u+"jcxg"hyf"fgnc{"qp"vjg"dtkfig"fkhhgtgppv"htqo"vjg
fghcwnv<
3/4
```

```
Vjg"hqnnqykpi"xncp*u+"jcxg"jgnnq"vkog"qp"vjg"dtkfig"fkhhgtgppv"htqo"vjg
fghcwnv<
3/4
```

```
Vjg"hqnnqykpi"xncp*u+"jcxg"c"fkhhgtgppv"rqtv"rtkqtkv{"vjcp"vjg"fghcwnv"
qp"vjg"rqtv"ikicdkvGvjgtpgv313
3/4
```

```
Vjg"hqnnqykpi"rqtvu"jcxg"tgekxg"hnqy"eqpvtqn"fkucdnngf<
Ik3142."Ik3144
```

```
Vjg"hqnnqykpi"kpnkpg"rpygt"rqtvu"jcxg"rpygt/fgp{lhcnv{"uvcvuw<
Ik313."Ik314
```

```
Vjg"hqnnqykpi"rqtvu"jcxg"pgiqvkcvgf"vq"jcnh/fwrngz<
Ik3144
```

```
Vjg"hqnnqykpi"xncpu"jcxg"c"fwrngz"okuocvej<
Iki"3144"
"
```

```
Vjg"hqnnqykpi"kpvgthcegu"jcxg"c"pcvkxg"xncp"okuocvej<
kpvgthceg"*pcvkxg"xncp"/"pgkijdt"xncp+
Iki"3144"*3"/"86+""
```

```
Vjg"xcnwg"hqt"Egoowpkv{/Ceeguu"qp"tgcf/qpn{"qrgtcvkqpu"hqt"UPOR"ku"vjg"ucog"
cu"fghcwnv0"Rngcug"xgtkh{"vjcv"vjku"ku"vjg"dguv"xcnwg"htqo"c"ugewtkv{"rqkpv"
qh"xkgy0
```

```
Vjg"xcnwg"hqt"Egoowpkv{/Ceeguu"qp"ytkgv/qpn{"qrgtcvkqpu"hqt"UPOR"ku"vjg"ucog
cu"fghcwnv0"Rngcug"xgtkh{"vjcv"vjku"ku"vjg"dguv"xcnwg"htqo"c"ugewtkv{"rqkpv
qh"xkgy0
```

```
Vjg"xcnwg"hqt"Egoowpkv{/Ceeguu"qp"tgcf/ytkgv"qrgtcvkqpu"hqt"UPOR"ku"vjg"ucog
cu"fghcwnv0"Rngcug"xgtkh{"vjcv"vjku"ku"vjg"dguv"xcnwg"htqo"c"ugewtkv{"rqkpv
qh"xkgy0
```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Onboard Failure Logging (OBFL)

- [Prerequisites for OBFL, page 17-1](#)
- [Restrictions for OBFL, page 17-2](#)
- [Information About OBFL, page 17-2](#)
- [Default Settings for OBFL, page 17-9](#)
- [Enabling OBFL, page 17-10](#)
- [Configuration Examples for OBFL, page 17-11](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for OBFL

None.

Restrictions for OBFL

- **Software Restrictions**—If a device (router or switch) intends to use *linear* flash memory as its OBFL storage media, Cisco IOS software must reserve a minimum of two physical sectors (or physical blocks) for the OBFL feature. Because an erase operation for a linear flash device is done on per-sector (or per-block) basis, one extra physical sector is needed. Otherwise, the minimum amount of space reserved for the OBFL feature on any device must be at least 8 KB.
- **Firmware Restrictions**—If a line card or port adapter runs an operating system or firmware that is different from the Cisco IOS operating system, the line card or port adapter must provide device driver level support or an interprocess communications (IPC) layer that allows the OBFL file system to communicate to the line card or port adapter. This requirement is enforced to allow OBFL data to be recorded on a storage device attached to the line card or port adapter.
- **Hardware Restrictions**—To support the OBFL feature, a device must have at least 8 KB of nonvolatile memory space reserved for OBFL data logging.

Information About OBFL

- [Overview of OBFL, page 17-2](#)
- [Information about Data Collected by OBFL, page 17-2](#)

Overview of OBFL

The Onboard Failure Logging (OBFL) feature collects data such as operating temperatures, hardware uptime, interrupts, and other important events and messages from system hardware installed in a Cisco router or switch. The data is stored in nonvolatile memory and helps technical personnel diagnose hardware problems.

Information about Data Collected by OBFL

- [OBFL Data Overview, page 17-2](#)
- [Temperature, page 17-3](#)
- [Operational Uptime, page 17-4](#)
- [Interrupts, page 17-8](#)
- [Message Logging, page 17-9](#)

OBFL Data Overview

The OBFL feature records operating temperatures, hardware uptime, interrupts, and other important events and messages that can assist with diagnosing problems with hardware cards (or *modules*) installed in a Cisco router or switch. Data is logged to files stored in nonvolatile memory. When the onboard hardware is started up, a first record is made for each area monitored and becomes a base value for subsequent records. The OBFL feature provides a circular updating scheme for collecting continuous records and archiving older (historical) records, ensuring accurate data about the system. Data is recorded in one of two formats: continuous information that displays a snapshot of measurements and

samples in a continuous file, and summary information that provides details about the data being collected. The data is displayed using the **show logging onboard** command. The message “No historical data to display” is seen when historical data is not available.

Temperature

Temperatures surrounding hardware modules can exceed recommended safe operating ranges and cause system problems such as packet drops. Higher than recommended operating temperatures can also accelerate component degradation and affect device reliability. Monitoring temperatures is important for maintaining environmental control and system reliability. Once a temperature sample is logged, the sample becomes the base value for the next record. From that point on, temperatures are recorded either when there are changes from the previous record or if the maximum storage time is exceeded. Temperatures are measured and recorded in degrees Celsius.

Temperature Example

```
Tqwgvt% "ujqy"nqiikpi"qpdaqctf"uykvej"3"oqfwng"5"vgo
```

TEMPERATURE SUMMARY INFORMATION

Number of sensors : 9

Sampling frequency : 5 minutes

Maximum time of storage : 120 minutes

Sensor | ID | Maximum Temperature 0C

MB-Out1 1190201 39

MB-In1 1190202 38

MB-Out2 1190203 52

MB-In2 1190204 44

Aludra0 1340301 78

Aludra1 1340301 76

Kunlun0-3 1340301 58

Kunlun1-3 1340301 58

SM15 1340301 58

Temp Sensor ID

0C 1 2 3 4 5 6 7 8 9

No historical data to display

```
////////////////////////////////////  
VGORGTCVWTG"EQPVKQWU"KPHQTOCVKQP
```

```

////////////////////////////////////
Ugput " " " " "KF" " "
////////////////////////////////////
OD/Qwv " " " " " " ; :2423 "
OD/Kp " " " " " " ; :2424 "
OD " " " " " " ; :2425 "
OD " " " " " " ; :2426 "
GCTN/Qwv " " " " " " ; :32423 "
GCTN/Kp " " " " " " ; :32424 "
UUC "3 " " " " " " ; :2523 "
UUC "4 " " " " " " ; :2524 "
LCPWU "3 " " " " " " ; :2525 "
LCPWU "4 " " " " " " ; :2526 "
IGOKPK "3 " " " " " " ; :2527 "
IGOKPK "4 " " " " " " ; :2528 "

////////////////////////////////////
" " " " "Vkog" "Uvcor" " " " " "Ugput" "Vgorgtcvwtg" "2E"
001FF1 [ [ [ [ "JJ<OO<UU" " " "3 " " "4 " " "5 " " "6 " " "7 " " "8 " " "9 " " " : " " " ; " " "32 " " "33 " " "34
////////////////////////////////////
2512814229 "44<54<73 " " "53 " " "48 " " "49 " " " "PC" " " "PC" " " "55 " " "54 " " "52 " " "4 ; " " "PC" " " "PC"
2512814229 "44<59<73 " " "65 " " "4 : " " "4 ; " " "5 : " " "PC" " " "PC" " " "5 : " " "58 " " "58 " " "57 " " "PC" " " "PC"
////////////////////////////////////

```

To interpret this data:

- Number of sensors is the total number of temperature sensors that will be recorded. A column for each sensor is displayed with temperatures listed under the number of each sensor, as available.
- Sampling frequency is the time between measurements.
- Maximum time of storage determines the maximum amount of time, in minutes, that can pass when the temperature remains unchanged and the data is not saved to storage media. After this time, a temperature record will be saved even if the temperature has not changed.
- The Sensor column lists the name of the sensor.
- The ID column lists an assigned identifier for the sensor.
- Maximum Temperature 0C shows the highest recorded temperature per sensor.
- Temp indicates a recorded temperature in degrees Celsius in the historical record. Columns following show the total time each sensor has recorded that temperature.
- Sensor ID is an assigned number, so that temperatures for the same sensor can be stored together.

Operational Uptime

The operational uptime tracking begins when the module is powered on, and information is retained for the life of the module.

Operational Uptime Example

Router#show logging onboard switch 1 module 5 up

```

-----
UPTIME SUMMARY INFORMATION
-----

```

First customer power on : 09/04/2015 15:14:59

Total uptime : 0 years 50 weeks 5 days 12 hours 0 minutes

Total downtime : 0 years 8 weeks 1 days 17 hours 13 minutes

Number of resets : 859

Number of slot changes : 6

Current reset reason : 0x44

Current reset timestamp : 04/07/2016 10:38:34

Current slot : 5

Current uptime : 0 years 0 weeks 0 days 13 hours 0 minutes

Reset | | Reset |

Code | Count | Reason|

0X44 211 Cold Power-on

0X45 172 Reload

0XA1 476 Unknown

Last 5 Boot-up Records

Record | Boot-up Time Stamp | Slot | Reset | Software | Firmware |

Number | MM/DD/YYYY HH:MM:SS | Number | Reason | Version | Version |

#1 04/07/2016 10:38:34 5 0X44 15.3(1)SY 15.3(04

#2 04/07/2016 07:32:56 5 0X44 15.3(1)SY 15.3(04

#3 04/07/2016 06:12:41 5 0X44 15.3(1)SY 15.3(04

#4 04/06/2016 20:54:26 5 0X44 15.3(1)SY 15.3(04

#5 04/06/2016 20:06:27 5 0X44 15.3(1)IE10 15.3(04

The operational uptime application tracks the following events:

- Date and time the customer first powered on a component.
- Total uptime and downtime for the component in years, weeks, days, hours, and minutes.
- Total number of component resets.
- Total number of slot (module) changes.
- Current reset timestamp to include the date and time.
- Current slot (module) number of the component.
- Current uptime in years, weeks, days, hours, and minutes.
- Reset reason; see [Table 17-1](#) to translate the numbers displayed.
- Count is the number of resets that have occurred for each reset reason.

Table 17-1 *Reset Reason Codes and Explanations*

Reset Reason Code (in hex)	Component/Explanation
0x01	Chassis on
0x02	Line card hot plug in
0x03	Supervisor requests line card off or on
0x04	Supervisor requests hard reset on line card
0x05	Line card requests Supervisor off or on
0x06	Line card requests hard reset on Supervisor
0x07	Line card self reset using the internal system register
0x08	—
0x09	—
0x0A	Momentary power interruption on the line card
0x0B	—
0x0C	—
0x0D	—
0x0E	—
0x0F	—
0x10	—
0x11	Off or on after Supervisor non-maskable interrupts (NMI)
0x12	Hard reset after Supervisor NMI
0x13	Soft reset after Supervisor NMI
0x14	—
0x15	Off or on after line card asks Supervisor NMI
0x16	Hard reset after line card asks Supervisor NMI
0x17	Soft reset after line card asks Supervisor NMI
0x18	—
0x19	Off or on after line card self NMI
0x1A	Hard reset after line card self NMI
0x1B	Soft reset after line card self NMI
0x21	Off or on after spurious NMI
0x22	Hard reset after spurious NMI
0x23	Soft reset after spurious NMI
0x24	—
0x25	Off or on after watchdog NMI
0x26	Hard reset after watchdog NMI
0x27	Soft reset after watchdog NMI
0x28	—

Table 17-1 *Reset Reason Codes and Explanations*

Reset Reason Code (in hex)	Component/Explanation
0x29	Off or on after parity NMI
0x2A	Hard reset after parity NMI
0x2B	Soft reset after parity NMI
0x31	Off or on after system fatal interrupt
0x32	Hard reset after system fatal interrupt
0x33	Soft reset after system fatal interrupt
0x34	—
0x35	Off or on after application-specific integrated circuit (ASIC) interrupt
0x36	Hard reset after ASIC interrupt
0x37	Soft reset after ASIC interrupt
0x38	—
0x39	Off or on after unknown interrupt
0x3A	Hard reset after unknown interrupt
0x3B	Soft reset after unknown interrupt
0x41	Off or on after CPU exception
0x42	Hard reset after CPU exception
0x43	Soft reset after CPU exception
0xA1	Reset data converted to generic data

Interrupts

Interrupts are generated by system components that require attention from the CPU such as ASICs and NMIs. Interrupts are generally related to hardware limit conditions or errors that need to be corrected.

The continuous format records each time a component is interrupted, and this record is stored and used as base information for subsequent records. Each time the list is saved, a timestamp is added. Time differences from the previous interrupt are counted, so that technical personnel can gain a complete record of the component's operational history when an error occurs.

Interrupts Example

```
Tqwgvt%ujqy"nqiikpi"qpdqctf"uykvej"3"oqfwng"7"kpvgttwrv
////////////////////////////////////
KPVGTTWRV"UWOOC["KPHQTOCVKQP
////////////////////////////////////
Pcog"~"KF"~"Qhhugv"~"DkvNkuv"~"Eqwgv
////////////////////////////////////
"PC"2"2z2222"339:79246
"PC"2"2z2222"4;58362:
"PC"2"2z2222"9;54894
"PC"2"2z2322"7342"7;8:
"PC"2"2z2222"339:79246
////////////////////////////////////

Tqwgvt%"
```

To interpret this data:

- Name is a description of the component including its position in the device.
- ID is an assigned field for data storage.
- Offset is the register offset from a component register's base address.
- Bit is the interrupt bit number recorded from the component's internal register.
- The timestamp shows the date and time that an interrupt occurred down to the millisecond.

Message Logging

The OBFL feature logs standard system messages. Instead of displaying the message to a terminal, the message is written to and stored in a file, so the message can be accessed and read at a later time. System messages range from level 1 alerts to level 7 debug messages, and these levels can be specified in the **hw module logging onboard** command.

Error Message Log Example

```

////////////////////////////////////
GTTQT"OGUUCIG"UWOOC["KPHQTOCVKQP
////////////////////////////////////
Hceknkv{/Ugx/Pcog"~~~~~"Eqw~"Rgtukuv~"Hnci
OO1FF1[[["JJ<OO<UU
////////////////////////////////////
Pq"jkuvqtkecn"fvcv"vq"fkurnc{
////////////////////////////////////
GTTQT"OGUUCIG"EQPVKPQWU"KPHQTOCVKQP
////////////////////////////////////
OO1FF1[[["JJ<OO<UU"Hceknkv{/Ugx/Pcog
////////////////////////////////////
2512814229"44<55<57" 'IQNFaQDHN/5/IQNF"<"Fkcipquvke"QDHN<"Fkcipquvke"QDHN"vguvkpi

```

To interpret this data:

- A timestamp shows the date and time the message was logged.
- Facility-Sev-Name is a coded naming scheme for a system message, as follows:
 - The Facility code consists of two or more uppercase letters that indicate the hardware device (facility) to which the message refers.
 - Sev is a single-digit code from 1 to 7 that reflects the severity of the message.
 - Name is one or two code names separated by a hyphen that describe the part of the system from where the message is coming.
- The error message follows the Facility-Sev-Name codes. For more information about system messages, see the [Cisco IOS System and Error Messages](#) guide.
- Count indicates the number of instances of this message that is allowed in the history file. Once that number of instances has been recorded, the oldest instance will be removed from the history file to make room for new ones.
- The Persistence Flag gives a message priority over others that do not have the flag set.

Default Settings for OBFL

The OBFL feature is enabled by default. Because of the valuable information this feature offers technical personnel, it should not be disabled.

Enabling OBFL

To enable OBFL, perform this task:

	Command or Action	Purpose
Step 1	Tqwvgt@"gpcdng"	Enables privileged EXEC mode (enter your password if prompted).
Step 2	Tqwvgt%"eqphkiwtg"vgtokpcn"	Enters global configuration mode.
Step 3	Tqwvgt*eqphki+% "jy/oqfwng"uykvej"switch-number" oqfwng module-number nqiikpi"qpdaqctf"]ogauucig" ngxgn"}3/9i_"	Enables OBFL on the specified hardware module. Note By default, all system messages sent to a device are logged by the OBFL feature. You can define a specific message level (only level 1 messages, as an example) to be logged using the message level keywords.
Step 4	Tqwvgt*eqphki+% "gpf"	Ends global configuration mode.

OBFL Report for a Specific Time: Example

The following example shows how to display continuous reports for all components during a specific time period:

```
Tqwgvt%"ujqy"nqiikpi"qpdqctf"oqfwng"5"eqpvkpwqwu"uvctv"37<23<79"3"Oct"4229"gpf"37<26<79"5"
Oct"4229
```

```
RKF<"YU/Z896:/IG/VZ""". "XKF<""". "UP<"UCN2;285D:7
```

```
////////////////////////////////////
WRVKOG"EQPVKPWQWU"KPHQTOCVKQP
////////////////////////////////////
Vkog"Uvcor""""""""~"Tgugv""~"Wrvkog"
001FF1 [ [ [ "JJ<OO<UU"~"Tgcuqp"~" {gctu"yggmu"fc{u"jqwtu"okpwvgu"
////////////////////////////////////
2512314229"37<23<79""2zC3""""2""""2""""2""""32""""2"
2512514229"24<4;<4;""2zC3""""2""""2""""2""""7""""2"
////////////////////////////////////

////////////////////////////////////
VGORGTCTVWTG"EQPVKPWQWU"KPHQTOCVKQP
////////////////////////////////////
Ugput """"""""~""KF""~"
////////////////////////////////////
OD/Qwv"""""""";52423"
OD/Kp"""""""";52424"
OD"""""""";52425"
OD"""""""";52426"
GCTN/Qwv"""""""";32423"
GCTN/Kp"""""""";32424"
UUC"3"""""""";52523"
UUC"4"""""""";52524"
LCPWU"3"""""""";52525"
LCPWU"4"""""""";52526"
IGOKPK"3"""""""";52527"
IGOKPK"4"""""""";52528"
////////////////////////////////////
""""""Vkog"Uvcor""~Ugput"Vgorgtcvwtg"2E"
001FF1 [ [ [ "JJ<OO<UU"~""3""4""5""6""7""8""9""": """; ""32""33""34
////////////////////////////////////
2512314229"37<23<79""48""48""PC""PC""PC""PC""2""2""2""2""2""2"
2512314229"37<28<79""5; ""49""PC""PC""PC""PC""5; ""59""58""4; ""54""54"
2512314229"37<33<24""62""49""PC""PC""PC""PC""62""5: ""59""52""54""54"
2512314229"39<28<28""62""49""PC""PC""PC""PC""62""5: ""59""52""54""54"
2512314229"3;<23<2; ""62""49""PC""PC""PC""PC""62""5: ""59""52""54""54"
2512514229"24<4;<52""47""48""PC""PC""PC""PC""2""2""2""2""2""2"
2512514229"24<56<52""5: ""48""PC""PC""PC""PC""5; ""59""58""4; ""53""53"
2512514229"26<4;<55""62""49""PC""PC""PC""PC""62""5: ""58""52""54""54"
2512514229"28<46<59""62""49""PC""PC""PC""PC""62""5: ""58""4; ""54""54"
2512514229"2:<3;<62""62""49""PC""PC""PC""PC""62""5: ""58""4; ""54""54"
2512514229"32<36<66""62""49""PC""PC""PC""PC""62""5: ""58""52""54""54"
2512514229"34<2;<69""62""49""PC""PC""PC""PC""62""5: ""58""52""54""54"
2512514229"36<26<73""62""49""PC""PC""PC""PC""62""5: ""58""52""54""54"
////////////////////////////////////
EQPVKPWQWU"KPVGTTRV"KPHQTOCVKQP
////////////////////////////////////
001FF1 [ [ [ "JJ<OO<UU"ooo"~"Pcog""""""""~""KF""~"Qhugv"~"Dkv
////////////////////////////////////
2512314229"37<23<7; "572""Rqtv/CUKE"%2""""""""9""2z22G9""8
2512514229"24<4;<56"872""Rqtv/CUKE"%2""""""""9""2z22G9""8
////////////////////////////////////
```

```

////////////////////////////////////
GTTQT"OGUUCIG"EQPVKPWQU"KPHQTOCVKQP
////////////////////////////////////
001FF1 [ [ [ "JJ<OO<UU"Hceknkv{/Ugx/Pcog
////////////////////////////////////
2512314229"37<24<37"" ' IQNFaQDHN/5/IQNF"<"Fkcipquvke"QDHN<"Fkcipquvke"QDHN"vguvkpi
2512514229"24<4;<73"" ' IQNFaQDHN/5/IQNF"<"Fkcipquvke"QDHN<"Fkcipquvke"QDHN"vguvkpi
////////////////////////////////////

```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Switch Fabric Functionality

- [Prerequisites for Switch Fabric Functionality, page 18-1](#)
- [Restrictions for Switch Fabric Functionality, page 18-1](#)
- [Information About the Switch Fabric Functionality, page 18-2](#)
- [Default Settings for Switch Fabric Functionality, page 18-2](#)
-
- [Monitoring the Switch Fabric Functionality, page 18-3](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for Switch Fabric Functionality

None.

Restrictions for Switch Fabric Functionality

None.

Information About the Switch Fabric Functionality

- [Switch Fabric Functionality Overview, page 18-2](#)
- [Forwarding Decisions for Layer 3-Switched Traffic, page 18-2](#)

Switch Fabric Functionality Overview

The switch fabric functionality is built into the supervisor engine and creates a dedicated connection between fabric-enabled modules and provides uninterrupted transmission of frames between these modules. In addition to the direct connection between fabric-enabled modules provided by the switch fabric functionality, fabric-enabled modules also have a direct connection to the forwarding bus.

Forwarding Decisions for Layer 3-Switched Traffic

Either a PFC or a Distributed Feature Card makes the forwarding decision for Layer 3-switched traffic as follows:

- A PFC makes all forwarding decisions for each packet that enters the switch through a module without a DFC.
- A DFC makes all forwarding decisions for each packet that enters the switch on a DFC-equipped module in these situations:
 - If the egress port is on the same module as the ingress port, the DFC forwards the packet locally (the packet never leaves the module).
 - If the egress port is on a different fabric-enabled module, the DFC sends the packet to the egress module, which sends it out the egress port.

Default Settings for Switch Fabric Functionality

Traffic is forwarded to and from modules in one of the following modes:

- Compact mode—The switch uses this mode for all traffic when only fabric-enabled modules are installed. In this mode, a compact version of the DBus header is forwarded over the switch fabric channel, which provides the best possible performance.
- Truncated mode—The switch uses this mode for traffic between fabric-enabled modules when there are both fabric-enabled and nonfabric-enabled modules installed. In this mode, the switch sends a truncated version of the traffic (the first 64 bytes of the frame) over the switch fabric channel.



Note

- When a port is defined by a non-fabric enabled line card where fabric functionality is configured, the ingress traffic towards the remote site gets punted to the CPU which causes heavy load on the CPU. You can avoid heavy load on CPU by making sure there are no ports defined by a non-fabric enabled line card with fabric functionality configured.
- Traffic drops when there is ingress through a non-fabric enabled card and egress from a Switch Virtual Interface (SVI) where VLAN fabric is enabled. You can avoid the traffic drop by making sure there is no traffic flow through the non-fabric enabled card.

Monitoring the Switch Fabric Functionality

- [Displaying the Switch Fabric Redundancy Status, page 18-3](#)
- [Displaying Fabric Channel Switching Modes, page 18-3](#)
- [Displaying the Fabric Status, page 18-3](#)
- [Displaying the Fabric Utilization, page 18-4](#)
- [Displaying Fabric Errors, page 18-4](#)

Displaying the Switch Fabric Redundancy Status

To display the switch fabric redundancy status, perform this task:

Command	Purpose
Tqwwgt% "ujqy" hcdtke "cevkxg"	Displays switch fabric redundancy status.

```
Tqwwgt% "ujqy" hcdtke "cevkxg"
Cevkxg "hcdtke" ectf "kp" unqv "8
Dcemwr "hcdtke" ectf "kp" unqv "7
Tqwwgt%
```

Displaying Fabric Channel Switching Modes

To display the fabric channel switching mode of one or all modules, perform this task:

Command	Purpose
Tqwwgt% "ujqy" hcdtke "uykvej kpi / oqfg"] oqfwng " } slot_number " ~ " cnn "	Displays fabric channel switching mode of one or all modules.

This example shows how to display the fabric channel switching mode of all modules:

```
Tqwwgt% "ujqy" hcdtke "uykvej kpi / oqfg" oqfwng "cnn"
Oqfwng "Unqv"      Uykvej kpi "Oqfg
" 3 "              fEGH
" 6 "              fEGH
" 7 "              fEGH
" 8 "              fEGH
Tqwwgt%
```

Displaying the Fabric Status

To display the fabric status of one or all switching modules, perform this task:

Command	Purpose
Tqwwgt% "ujqy" hcdtke "uvcvwu"] unqvapwodgt " ~ " cnn "	Displays fabric status.

This example shows how to display the fabric status of all modules:

```
Tqwgvt%"ujqy"hcdtke"uvcvwu"
"unqv""ejcppgn""urggf""oqfwng""hcdtke
""uvcvwu""uvcvwu
""3""2"":I""QM""QM
""7""2"":I""QM""Wr/"Vkogqvw
""8""2""42I""QM""Wr/"DwhGttqt
"":""2"":I""QM""QM
"":""3"":I""QM""QM
";""2"":I""Fqyp/"FFTu{pe""QM
Tqwgvt%
```

Displaying the Fabric Utilization

To display the fabric utilization of one or all modules, perform this task:

Command	Purpose
Tqwgvt%"ujqy"hcdtke"vvknk cvkqp"] unqvapwodgt"~"cnn_	Displays fabric utilization.

This example shows how to display the fabric utilization of all modules:

```
Tqwgvt%"ujqy"hcdtke"vvknk|cvkqp"cnn
unqv"ejcppgn"urggf"Kpitguu""Gitguu"
"3"2"62I"2"2
"3"3"62I"2"2
"4"2"62I"2"2
"4"3"62I"2"2
"5"2"62I"2"2
"5"3"62I"2"2
"6"2"62I"2"2
"6"3"62I"2"2
"7"2"62I"2"2
"7"4"62I"2"2
"8"2"42I"2"2
"8"3"42I"2"2
"8"4"42I"2"2
"8"5"42I"2"2"
Tqwgvt%
```

Displaying Fabric Errors

To display fabric errors of one or all modules, perform this task:

Command	Purpose
Tqwgvt%"ujqy"hcdtke"gttqtu"] unqvapwodgt"~"cnn_	Displays fabric errors.

This example shows how to display fabric errors on all modules:

```
Tqwgvt%"ujqy"hcdtke"gttqtu"

Oqfwng"gttqtu<
unqv"ejcppgn"ete"jdgcv"u{pe"FFT"u{pe
"3"2"2"2"2"2
"3"3"2"2"2"2
"6"2"2"2"2"2
```



```

"6"3"2"2"2"2
"7"2"2"2"2"2
"7"4"2"2"2"2
"8"2"2"2"2"2
"8"3"2"2"2"2
"8"4"2"2"2"2
"8"5"2"2"2"2

Hcdtke"gttqtu<
unqv"ejcppgn"u{pe"dwhhgt"vkogqvw
"3"2"2"2"2
"3"3"2"2"2
"6"2"2"2"2
"6"3"2"2"2
"7"2"2"2"2
"7"4"2"2"2
"8"2"2"2"2
"8"3"2"2"2
"8"4"2"2"2
"8"5"2"2"2
Tqwvgt%

```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Cisco IP Phone Support

- [Prerequisites for Cisco IP Phone Support, page 19-1](#)
- [Restrictions for Cisco IP Phone Support, page 19-1](#)
- [Information About Cisco IP Phone Support, page 19-2](#)
- [Default Setting for Cisco IP Phone Support, page 19-4](#)
- [How to Configure Cisco IP Phone Support, page 19-5](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for Cisco IP Phone Support

None.

Restrictions for Cisco IP Phone Support

- The information in this publication may be helpful in configuring support for non-Cisco IP phones, but we recommend that you see the manufacturer's documentation for those devices.
- You must enable the Cisco Discovery Protocol (CDP) on the port connected to the Cisco IP phone to send configuration information to the Cisco IP phone.

- You can configure a voice VLAN only on a Layer 2 LAN port.
- The following conditions indicate that the Cisco IP phone and a device attached to the Cisco IP phone are in the same VLAN and must be in the same IP subnet:
 - If they both use 802.1p or untagged frames
 - If the Cisco IP phone uses 802.1p frames and the device uses untagged frames
 - If the Cisco IP phone uses untagged frames and the device uses 802.1p frames
 - If the Cisco IP phone uses 802.1Q frames and the voice VLAN is the same as the access VLAN
- The Cisco IP phone and a device attached to the Cisco IP phone cannot communicate if they are in the same VLAN and subnet but use different frame types, because traffic between devices in the same subnet is not routed (routing would eliminate the frame type difference).
- You cannot use Cisco IOS software commands to configure the frame type used by traffic sent from a device attached to the access port on the Cisco IP phone.
- If you enable port security on a port configured with a voice VLAN and if there is a PC connected to the Cisco IP phone, set the maximum allowed secure addresses on the port to at least 2.
- You cannot configure static secure MAC addresses in the voice VLAN.
- Ports configured with a voice VLAN can be secure ports (see [Chapter 56, “Port Security”](#)).
- In all configurations, the voice traffic carries a Layer 3 IP precedence value (the default is 5 for voice traffic and 3 for voice control traffic).

Information About Cisco IP Phone Support


- [Cisco IP Phone Connections, page 19-2](#)
- [Cisco IP Phone Voice Traffic, page 19-3](#)
- [Cisco IP Phone Data Traffic, page 19-4](#)
- [Other Cisco IP Phone Features, page 19-4](#)

Cisco IP Phone Connections

The Cisco IP phone contains an integrated 3-port 10/100 switch. The ports are dedicated connections to these devices:

- Port 1 connects to the switch.
- Port 2 is an internal 10/100 interface that carries the Cisco IP phone traffic.
- Port 3 connects to a PC or other device.

[Figure 19-1](#) shows a Cisco IP phone connected between a switch and a PC.

Figure 19-1 Cisco IP Phone Connected to a Switch

Cisco IP Phone Voice Traffic

The Cisco IP phone transmits voice traffic with Layer 3 IP precedence and Layer 2 CoS values, which are both set to 5 by default. The sound quality of a Cisco IP phone call can deteriorate if the voice traffic is transmitted unevenly.

You can configure Layer 2 access ports on the switch to send Cisco Discovery Protocol (CDP) packets that configure an attached Cisco IP phone to transmit voice traffic to the switch in any of the following ways:

- In the voice VLAN, tagged with a Layer 2 CoS priority value
- In the access VLAN, tagged with a Layer 2 CoS priority value
- In the access VLAN, untagged (no Layer 2 CoS priority value)



Note

In all configurations, the voice traffic carries a Layer 3 IP precedence value (the default is 5 for voice traffic and 3 for voice control traffic).

To provide more predictable voice traffic flow, you can configure QoS on the switch to trust the Layer 3 IP precedence or Layer 2 CoS value in the received traffic (see [Chapter 32, “PFC QoS Overview”](#)).

The trusted boundary device verification feature configures ports on the switch to apply configured [QoS port trust commands](#) only when the Cisco Discovery Protocol (CDP) verifies that the device attached to the port is a Cisco IP phone. See the [“How to Configure Trusted Boundary with Cisco Device Verification” section on page 36-10](#).

You can configure a Layer 2 access port with an attached Cisco IP phone to use one VLAN for voice traffic and another VLAN for data traffic from a device attached to the Cisco IP phone.

Cisco IP Phone Data Traffic

**Note**

- The ability to either trust or mark tagged data traffic from the device attached to the access port on the Cisco IP phone is called the “trusted boundary (extended trust for CDP devices)” feature.
- You cannot use Cisco IOS software commands to configure the frame type used by data traffic sent from a device attached to the access port on the Cisco IP phone.
- Untagged data traffic from the device attached to the Cisco IP phone passes through the Cisco IP phone unchanged, regardless of the trust state of the access port on the Cisco IP phone.

To process tagged data traffic (traffic in 802.1Q or 802.1p frame types) from the device attached to the access port on the Cisco IP phone (see [Figure 19-1](#)), you can configure Layer 2 access ports on the switch to send CDP packets that instruct an attached Cisco IP phone to configure the access port on the Cisco IP phone to either of these two modes:

- Trusted mode—All traffic received through the access port on the Cisco IP phone passes through the Cisco IP phone unchanged.
- Untrusted mode—All traffic in 802.1Q or 802.1p frames received through the access port on the Cisco IP phone is marked with a configured Layer 2 CoS value. The default Layer 2 CoS value is 0. Untrusted mode is the default.

Most IP phones have no ability to notify the switch of link state changes on the IP phone’s access port. When a device attached to the access port is disconnected or disabled administratively, the switch is unaware of the change. Some Cisco IP phones can send a CDP message containing a host presence type length value (TLV) indicating the changed state of the access port link.

Other Cisco IP Phone Features

The switch provides support for authentication, authorization, and accounting (AAA) for Cisco IP phones, as described in [Chapter 54, “IEEE 802.1X Port-Based Authentication.”](#)

The switch also supports automatic tracking for Cisco Emergency Responder (Cisco ER) to help you manage emergency calls in your telephony network. For further information, see this URL:

http://www.cisco.com/en/US/products/sw/voicesw/ps842/tsd_products_support_series_home.html

Default Setting for Cisco IP Phone Support

- Cisco IP phone support is disabled by default.
- When the voice VLAN feature is enabled, all untagged traffic is sent with the default CoS priority of the port.
- CoS values are not trusted for 802.1P or 802.1Q tagged traffic.

How to Configure Cisco IP Phone Support

- [Configuring Voice Traffic Support, page 19-5](#)
- [Configuring Data Traffic Support, page 19-6](#)

Configuring Voice Traffic Support

To configure the way in which the Cisco IP phone transmits voice traffic, perform this task:

	Command	Purpose
Step 1	<code>Tqvwgt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv "slot/port"</code>	Selects the port to configure.
Step 2	<code>Tqvwgt*eqphki/kh+% "uykvejrgtv"</code>	Configures the LAN port for Layer 2 switching. Note You must enter the switchport command once without any keywords to configure the LAN port as a Layer 2 port before you can enter additional switchport commands with keywords.
Step 3	<code>Tqvwgt*eqphki/kh+% "uykvejrgtv"xqkeg"xncp" }voice_vlan_ID"~"fqv3r"~"pqp"~"wpvciiigf;</code>	Configures the way in which the Cisco IP phone transmits voice traffic.
Step 4	<code>Tqvwgt*eqphki+% "gpf"</code>	Exits configuration mode.

When configuring the way in which the Cisco IP phone transmits voice traffic, note the following information:

- Enter a voice VLAN ID to send CDP packets that configure the Cisco IP phone to transmit voice traffic in 802.1Q frames, tagged with the voice VLAN ID and a Layer 2 CoS value (the default is 5). Valid VLAN IDs are from 1 to 4094. The switch puts the 802.1Q voice traffic into the voice VLAN.
- Enter the **dot1p** keyword to send CDP packets that configure the Cisco IP phone to transmit voice traffic in 802.1p frames, tagged with VLAN ID 0 and a Layer 2 CoS value (the default is 5 for voice traffic and 3 for voice control traffic). The switch puts the 802.1p voice traffic into the access VLAN.
- Enter the **untagged** keyword to send CDP packets that configure the Cisco IP phone to transmit untagged voice traffic. The switch puts the untagged voice traffic into the access VLAN.
- Enter the **none** keyword to allow the Cisco IP phone to use its own configuration and transmit untagged voice traffic. The switch puts the untagged voice traffic into the access VLAN.
- In all configurations, the voice traffic carries a Layer 3 IP precedence value (the default is 5).
- See [Chapter 32, “PFC QoS Overview,”](#) for information about how to configure QoS.
- See the [“Configuring a LAN Interface as a Layer 2 Access Port”](#) section on page 11-13 for information about how to configure the port as a Layer 2 access port and configure the access VLAN.

This example shows how to configure Gigabit Ethernet port 5/1 to send CDP packets that tell the Cisco IP phone to use VLAN 101 as the voice VLAN:

```
Tqvwgt*eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv "713"
Tqvwgt*eqphki/kh+% "uykvejrgtv"xqkeg"xncp"323"
Tqvwgt*eqphki/kh+% "gzkv"
```

This example shows how to verify the configuration of Gigabit Ethernet port 5/1:

```
Tqwgvt% "ujqy"kpvgthcegu"ikicdkvgvjgtpgv"713"uykvejrgtv"
Pcog<"Ik713
Uykvejrgtv<"Gpcdnfg
Cfokpkuvtcvkxg"Oqfg<"ceeguu
Qrgtcvkqpcn"Oqfg<"ceeguu
Cfokpkuvtcvkxg"Vtwpmkpi"Gpecruwncvkqp<"fqv3s
Qrgtcvkqpcn"Vtwpmkpi"Gpecruwncvkqp<"fqv3s
Pgiqvcvkqpcn"qh"Vtwpmkpi<"qhh
Ceeguu"Oqfg"XNCP<"322
Xqkeg"XNCP<"323
Vtwpmkpi"Pcvkxg"Oqfg"XNCP<"3"*fghcwnv+
Cfokpkuvtcvkxg"rtkxcvg/xncp"jquv/cuuqekcvkqp<"pgpg"
Cfokpkuvtcvkxg"rtkxcvg/xncp"ocrrkpi<" ; 22"***Kpcevkxg++" ; 23"***Kpcevkxg++"
Qrgtcvkqpcn"rtkxcvg/xncp<"pgpg"
Vtwpmkpi"XNCPu"Gpcdnfg<"CNN
Rtwpkpi"XNCPu"Gpcdnfg<"4/3223
Ecrvwtg"Oqfg"fkucdnfg
Ecrvwtg"XNCPu"Cnnqygf<"CNN
```

Configuring Data Traffic Support



Note

The trusted boundary feature is implemented with the **platform qos trust extend** command.

To configure the way in which an attached Cisco IP phone transmits data traffic, perform this task:

Command	Purpose
Step 1 Tqwgvt*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv" slot/port"	Selects the port to configure.
Step 2 Tqwgvt*eqphki/kh+% "rncvhqto"sqv"vtwuv"gzvgpf"]equ equaxcnwg_	Configures the way in which an attached Cisco IP phone transmits data traffic.
Step 3 Tqwgvt*eqphki+% "gpf"	Exits configuration mode.

When configuring the way in which an attached Cisco IP phone transmits data traffic, note the following information:

- To send CDP packets that configure an attached Cisco IP phone to trust tagged traffic received from a device connected to the access port on the Cisco IP phone, do not enter the **cos** keyword and CoS value.
- To send CDP packets that configure an attached Cisco IP phone to mark tagged ingress traffic received from a device connected to the access port on the Cisco IP phone, enter the **cos** keyword and CoS value (valid values are 0 through 7).
- You cannot use Cisco IOS software commands to configure whether or not traffic sent from a device attached to the access port on the Cisco IP phone is tagged.

This example shows how to configure Gigabit Ethernet port 5/1 to send CDP packets that tell the Cisco IP phone to configure its access port as untrusted and to mark all tagged traffic received from a device connected to the access port on the Cisco IP phone with CoS 3:

```
Tqwgvt% "eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv"713 "
```



```
Tqvwgt *eqphki /kh+% "rncvhqto" squ "vtwuv" gzvgpf "equ" 5 "
```

This example shows how to configure Gigabit Ethernet port 5/1 to send CDP packets that tell the Cisco IP phone to configure its access port as trusted:

```
Tqvwgt % "eqphkiwtg" vgtokpcn "
Tqvwgt *eqphki+% "kpvgtthceg" ikicdkvgvjgtpgv "713 "
Tqvwgt *eqphki /kh+% "rncvhqto" squ "vtwuv" gzvgpf "
```

This example shows how to verify the configuration on Gigabit Ethernet port 5/1:

```
Tqvwgt % "ujqy" swgwgkpi "kpvgtthceg" ikicdkvgvjgtpgv "713 " ~ "kpenwfg" Gzvgpf "
" "Gzvgpf" vtwuv" uvcvg< " vtwuvvgf
```



Note

In addition to CDP, you can also use LLDP MED on the port connecting to the Cisco IP Phone to detect and configure it.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Power over Ethernet (PoE) Support

- [Prerequisites for PoE, page 20-1](#)
- [Restrictions for PoE, page 20-1](#)
- [Information About PoE, page 20-2](#)
- [How to Configure PoE Support, page 20-4](#)



Note

- For information about switching modules that support PoE, see the *Release Notes for Cisco IOS Release 15.2SY* publication at this URL:

http://www.cisco.com/en/US/docs/switches/lan/catalyst6500/ios/15.1SY/release_notes.html

- For complete syntax and usage information for the commands used in this chapter, see these publications:

http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for PoE

None.

Restrictions for PoE

PoE is supported only on Layer 2 switchports.

Information About PoE

- [Device Roles, page 20-2](#)
- [PoE Overview, page 20-2](#)
- [CPD-Based PoE Management, page 20-3](#)
- [Inline Power IEEE Power Classification Override, page 20-4](#)
- [LLDP Inline Power Negotiation for PoE+ \(IEEE 802.3at\), page 20-4](#)

Device Roles

- Power sourcing equipment (PSE)—A device that provides power through a twisted-pair Ethernet connection. The switch, through switching modules equipped with Power over Ethernet (PoE) daughtercards, functions in the PSE role.
- Powered device (PD)—A device powered by a PSE (for example, IP phones, IP cameras, and wireless access points).

**Note**

Not all PoE-capable devices are powered from the switch. There are two sources of local power for PoE-capable devices:

- A power supply connected to the device.
- A power supply through a patch panel over the Ethernet connection to the device.

When a locally powered PoE-capable device is present on a switching module port, the switching module itself cannot detect its presence. If the device supports CDP, the supervisor engine can discover a locally powered PoE-capable device through CDP messaging with the device. If a locally powered PoE-capable device loses local power, the switching module can discover and supply power to the IP phone if the inline power mode is set to **auto**.

PoE Overview

Cisco PoE daughtercards support one or more PoE implementation:

- IEEE 802.3at standard, shown in Cisco Feature Navigator as “PoE Plus (PoE+, PoEP) support”.
 - Supported only with the PoE daughtercard on the WS-X6148E-GE-45AT switching module.
 - These features are supported for IEEE 802.3at-compliant class 4 PDs:
 - Class 4: 30.00 W at the PSE (12.95 W to 25.50 W at the PD).
 - Optionally, [LLDP Inline Power Negotiation for PoE+](#).
 - With releases earlier than Release 15.1(1)SY, maximum 16.8 W at the PSE (ePoE for 45 ports maximum).
- IEEE 802.3af standard.
 - Supported with the WS-F6K-48-AF PoE daughtercard and the PoE daughtercard on the WS-X6148E-GE-45AT switching module.
 - Maximum 16.80 W at the PSE.

- The IEEE 802.3af PoE standard defines a method to sense a PD and to immediately classify the power requirement of the PD into these per port power ranges at the PSE:
 - Class 0: Up to 15.4 W (0.44–12.95 W at the PD; default classification)
 - Class 1: Up to 4 W (0.44–3.84 W at the PD)
 - Class 2: Up to 7 W (3.84–6.49 W at the PD)
 - Class 3: Up to 15.4 W (6.49–12.95 W at the PD)
- Cisco prestandard inline power—10 W at the PSE.

With a PoE daughtercard installed, a switching module can automatically detect and provision a PoE-capable device that adheres to a PoE implementation supported by the PoE daughtercard. The switching module can supply power to devices supporting other PoE implementations only through manual configuration.

Only a PD connected directly to the switch port can be powered from the switch. If a second PD is daisy-chained from the PD that is connected to the switch port, the second PD cannot be powered by the switch.

Each PD requires power to be allocated from the chassis power budget. Because each PD can have unique power requirements, more devices can be supported if the system's power management software can intelligently allocate the necessary power on a per-port basis.

You can configure ports to allocate power at a level based on the following:

- If a PD is detected, with auto mode configured:
 - Information sensed from the device
 - A default level
 - A configured maximum level
- Whether or not a PD is present on the port, with static mode configured:
 - A default level
 - A configured level

CPD-Based PoE Management

When a switching module port detects an unpowered PD, the default-allocated power is provided to the port. When the correct amount of power is determined through CDP messaging with the PD, the supervisor engine reduces or increases the allocated power, up to the hardware limit of the installed PoE daughtercard.



Caution

When a PD cable is plugged into a port and the power is turned on, the supervisor engine has a 4-second timeout waiting for the link to go up on the line. During those 4 seconds, if the IP phone cable is unplugged and a network device is plugged in, the network device could be damaged. We recommend that you wait at least 10 seconds between unplugging a network device and plugging in another network device.

Inline Power IEEE Power Classification Override

The IEEE 802.3af standard contains no provision for adjustment of the power allocation. 802.3af-compliant PDs that support CDP can use CDP to override the IEEE 802.3af power classification.

The WS-F6K-48-AF PoE daughtercard or the PoE daughtercard on the WS-X6148E-GE-45AT switching module support these inline power IEEE 802.3af power classification override features:

- Power use measurement—The ability to accurately measure the power provided by the port to the powered device.
- Power policing—The ability to monitor power usage on a port.

With power measurement and policing, you can safely override the IEEE 802.3af power classification of a device that requires a power level at the lower end of its IEEE power classification range.

PoE monitoring and policing compares the power consumption on ports with the administrative maximum value (either a configured maximum value or the port's default value). If the power consumption on a monitored port exceeds the administrative maximum value, the following actions occur:

- A syslog message is issued.
- The monitored port is shut down and error-disabled.
- The allocated power is freed.

LLDP Inline Power Negotiation for PoE+ (IEEE 802.3at)

The PoE daughtercard on the WS-X6148E-GE-45AT switching module supports [IEEE 802.3at](#)-compliant LLDP PoE power negotiation, which supports additional negotiation that can reduce power usage.



Note

- Enabled by default.
- The LLDP TLV used is DTE Power-via-MDI TLV.
- When a PD that performs power negotiation using multiple protocols (CDP and LLDP 802.3at) is connected to a switch, the switch locks to the first protocol packet (CDP or LLDP) that contains the power negotiation TLV. If you need to use any single protocol for power negotiation each time, you must administratively disable the other power negotiation protocols on the switch interface.
- See this publication for other the Link Layer Discovery Protocol (LLDP) configuration procedures: http://www.cisco.com/en/US/docs/ios/cether/configuration/guide/ce_lldp-med.html

How to Configure PoE Support

- [Displaying PoE Status, page 20-5](#)
- [Configuring Per-Port PoE Support, page 20-5](#)
- [Configuring PoE Power Priority, page 20-6](#)
- [Configuring PoE Monitoring and Policing, page 20-8](#)

- Disabling LLDP Power Negotiation (IEEE 802.3at), page 20-8

Displaying PoE Status

This example shows how to display the PoE status on switch:

[illegible]

Configuring Per-Port PoE Support

To configure per-port PoE support, perform this task:

	Command	Purpose
Step 1	<code>Tqvwgt*eqphki/kh+%rqygt"kpnkpg"}cwvq~"uvcvke"~"pgxgt;ocz milliwatts_</code>	Configures per-port PoE support and optionally specifies a maximum inline power level in milliwatts for the port.
Step 2	<code>Tqvwgt%"ujqy"rqygt"kpnkpg"}type slot/port ~"ogfwng slot;fgvckn_"</code>	Verifies the configuration.

When configuring inline power support with the **power inline** command, note the following information:

- To configure auto-detection of a PD and PoE auto-allocation, enter the **auto** keyword.
- To configure auto-detection of a PD but reserve a fixed PoE allocation, enter the **static** keyword.
- To specify the maximum power to allocate to a port, enter either the **auto** or **static** keyword followed by the **max** keyword and the power level in milliwatts.
- When the **auto** keyword is entered and CDP is enabled on the port, a PD that supports CDP can negotiate a different power level.
- To disable auto-detection of a PD, enter the **never** keyword.

- With a WS-F6K-GE48-AF, WS-F6K-48-AF, or the PoE daughtercard on the WS-X6148E-GE-45AT switching module:
 - The configurable range of maximum power using the **max** keyword is 4000 to 16800 milliwatts. If no maximum power level is configured, the default maximum power is 15400 milliwatts.

**Note**

To support a large number of inline-powered ports using power levels above 15400 milliwatts on an inline power card, we recommend using the **static** keyword so that the power budget is deterministic.

- When the **auto** keyword is entered and CDP is enabled on the port, an inline-powered device that supports CDP can negotiate a power level up to 16800 milliwatts unless a lower maximum power level is configured.

This example shows how to disable inline power on GigabitEthernet port 2/10:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"4132"
Tqwgvt*eqphki/kh+%"rpygt"kpnpkg"pgxgt"
```

This example shows how to enable inline power on GigabitEthernet port 2/10:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"4132"
Tqwgvt*eqphki/kh+%"rpygt"kpnpkg"cwvg"
```

This example shows how to verify the inline power configuration on GigabitEthernet port 2/10:

```
Tqwgvt%"ujqy"rpygt"kpnpkg"ikicdkvgvjgtpgv"4132"
Kpvgtthceg"Cfokp"Rtkqtkv{"Qrgt""Rpygt*Ycvvu+""Fgxkeg""Encuu
""*gpcdnf"+"Htqo"RU"Vq"RF
//////////////////////////////////////////
Ik4132""cwvg""nqy""qp""3607""3503"Ekueq"KR"Rjqp";;93""6

Kpvgtthceg"CfokpRpygtOcz"Rqnkeg"CevEqpuworvkqp
""*Ycvvu+
//////////////////////////////////////////
Ik4132""5202"qp""809
```

Configuring PoE Power Priority

You can configure how the switch responds if a power shortage occurs by setting the priority of ports providing PoE. The priority determines the order in which PoE is removed from ports if a power shortage occurs: low-priority, then high-priority, with power maintained for critical-priority ports as long as possible. These sections describe how to configure PoE power priority:

- [Setting the PoE Power Priority Global Enable State, page 20-7](#)
- [Configuring PoE Port Power Priority, page 20-7](#)

With the WS-F6K-48-AF PoE daughtercard or the PoE daughtercard on the WS-X6148E-GE-45AT switching module, to configure PoE monitoring and policing, perform this task:

```
"NNFR"Ngice{"OFK"VNX""""""""""// "Texf"htqo"RF"//
"" "OFK"rqygt"uwrrqgtv"<""""""""2"
"" "rug"rqygt"rckt"<""""""""2"
"" "OFK"rqygt"encuu"<""""""""2"
```

This example shows how to disable LLDP power negotiation on interface GigabitEthernet 2/10:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpgo""Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%"kpvgt hceg"ikicdkvgvjgtpgv"4132"
Tqvwgt*eqphki/kh+%"pq"nnfr"vnx/ugngev"rqygt/ocpcigogpv"
```



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

Participate in the Technical Documentation Ideas forum



LAN Ports for Layer 2 Switching

- [Prerequisites for Layer 2 LAN Interfaces, page 21-1](#)
- [Restrictions for Layer 2 LAN Interfaces, page 21-2](#)
- [Information About Layer 2 Switching, page 21-2](#)
- [Default Settings for Layer 2 LAN Interfaces, page 21-5](#)
- [How to Configure LAN Interfaces for Layer 2 Switching, page 21-5](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- To configure Layer 3 interfaces, see [Chapter 35, “Layer 3 Interfaces.”](#)



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for Layer 2 LAN Interfaces

None.

Restrictions for Layer 2 LAN Interfaces

- When connecting Cisco switches through an 802.1q trunk, make sure the native VLAN for an 802.1Q trunk is the same on both ends of the trunk link. If the native VLAN on one end of the trunk is different from the native VLAN on the other end, spanning tree loops might result.
- Disabling spanning tree on the native VLAN of an 802.1Q trunk without disabling spanning tree on every VLAN in the network can cause spanning tree loops. We recommend that you leave spanning tree enabled on the native VLAN of an 802.1Q trunk. If this is not possible, disable spanning tree on every VLAN in the network. Make sure your network is free of physical loops before disabling spanning tree.
- When you connect two Cisco switches through 802.1Q trunks, the switches exchange spanning tree BPDUs on each VLAN allowed on the trunks. The BPDUs on the native VLAN of the trunk are sent untagged to the reserved IEEE 802.1d spanning tree multicast MAC address (01-80-C2-00-00-00). The BPDUs on all other VLANs on the trunk are sent tagged to the reserved Cisco Shared Spanning Tree (SSTP) multicast MAC address (01-00-0c-cc-cc-cd).
- Non-Cisco 802.1Q switches maintain only a single instance of spanning tree (the Mono Spanning Tree, or MST) that defines the spanning tree topology for all VLANs. When you connect a Cisco switch to a non-Cisco switch through an 802.1Q trunk, the MST of the non-Cisco switch and the native VLAN spanning tree of the Cisco switch combine to form a single spanning tree topology known as the Common Spanning Tree (CST).
- Because Cisco switches transmit BPDUs to the SSTP multicast MAC address on VLANs other than the native VLAN of the trunk, non-Cisco switches do not recognize these frames as BPDUs and flood them on all ports in the corresponding VLAN. Other Cisco switches connected to the non-Cisco 802.1q cloud receive these flooded BPDUs. This allows Cisco switches to maintain a per-VLAN spanning tree topology across a cloud of non-Cisco 802.1Q switches. The non-Cisco 802.1Q cloud separating the Cisco switches is treated as a single broadcast segment between all switches connected to the non-Cisco 802.1q cloud through 802.1q trunks.
- Make certain that the native VLAN is the same on all of the 802.1q trunks connecting the Cisco switches to the non-Cisco 802.1q cloud.
- If you are connecting multiple Cisco switches to a non-Cisco 802.1q cloud, all of the connections must be through 802.1q trunks. You cannot connect Cisco switches to a non-Cisco 802.1q cloud through access ports. Doing so causes the switch to place the access port into the spanning tree “port inconsistent” state and no traffic will pass through the port.

Information About Layer 2 Switching

- [Information about Layer 2 Ethernet Switching, page 21-2](#)
- [Information about VLAN Trunks, page 21-4](#)
- [Layer 2 LAN Port Modes, page 21-4](#)

Information about Layer 2 Ethernet Switching

- [Layer 2 Ethernet Switching Overview, page 21-3](#)
- [Building the MAC Address Table, page 21-3](#)

Layer 2 Ethernet Switching Overview

Layer 2 Ethernet ports on Cisco switches support simultaneous, parallel connections between Layer 2 Ethernet segments. Switched connections between Ethernet segments last only for the duration of the packet. New connections can be made between different segments for the next packet.

Layer 2 LAN switching (hardware-supported bridging) avoids congestion by assigning each connected device to its own collision domain. Because each LAN port connects to a separate Ethernet collision domain, attached devices in a properly configured switched environment achieve full access to network bandwidth.

Building the MAC Address Table

- [Overview of the MAC Address Table, page 21-3](#)
- [Synchronization and Sharing of the Address Table, page 21-3](#)
- [Notification of Address Table Changes, page 21-3](#)

Overview of the MAC Address Table

When stations connected to different LAN ports need to communicate, the switch forwards frames from one LAN port to the other at wire speed to ensure that each session receives full bandwidth.

To switch frames between LAN ports efficiently, the switch maintains a MAC address table. When a frame enters the switch, it associates the MAC address of the sending network device with the LAN port on which it was received.

The MAC address table is built by using the source MAC address of the frames received. When the switch receives a frame for a destination MAC address not listed in its MAC address table, it floods the frame to all LAN ports of the same VLAN except the port that received the frame. When the destination station replies, the switch adds its relevant source MAC address and port ID to the MAC address table. The switch then forwards subsequent frames to a single LAN port without flooding to all LAN ports.

The MAC address table can store at least 128,000 address entries without flooding any entries. The switch uses an aging mechanism, configured by the **mac address-table aging-time** command, so if an address remains inactive for a specified number of seconds, it is removed from the address table.

Synchronization and Sharing of the Address Table

With distributed switching, each DFC-equipped switching module learns MAC addresses, maintains an address table, and ages table entries. MAC address table synchronization over the Ethernet Out of Band Channel (EOBC) synchronizes address tables among the PFC and all DFCs, eliminating the need for flooding by a DFC for an address that is active on another module. MAC synchronization is enabled by default.

Notification of Address Table Changes

You can configure the switch to maintain a history of dynamic additions and removals of address table entries associated with a particular LAN port. The change history can be sent as an SNMP trap notification or it can be read manually from the SNMP MIB.

Information about VLAN Trunks

**Note**

For information about VLANs, see [Chapter 26, “Virtual Local Area Networks \(VLANs\).”](#)

A trunk is a point-to-point link between the switch and another networking device. Trunks carry the traffic of multiple VLANs over a single link and allow you to extend VLANs across an entire network.

802.1Q, an industry-standard trunking encapsulation, is available on all Ethernet ports.

You can configure a trunk on a single Ethernet port or on an EtherChannel. For more information about EtherChannel, see [Chapter 23, “EtherChannels.”](#)

Ethernet trunk ports support several trunking modes (see [Table 21-1 on page 21-4](#)).

The Dynamic Trunking Protocol (DTP) manages trunk autonegotiation on LAN ports.

To autonegotiate trunking, the LAN ports must be in the same VTP domain. Use the **trunk** or **nonegotiate** keywords to force LAN ports in different domains to trunk. For more information on VTP domains, see [Chapter 25, “VLAN Trunking Protocol \(VTP\).”](#)

Layer 2 LAN Port Modes

Table 21-1 Layer 2 LAN Port Modes

Mode	Function
switchport mode access	Puts the LAN port into permanent nontrunking mode and negotiates to convert the link into a nontrunk link. The LAN port becomes a nontrunk port even if the neighboring LAN port does not agree to the change.
switchport mode dynamic desirable	Makes the LAN port actively attempt to convert the link to a trunk link. The LAN port becomes a trunk port if the neighboring LAN port is set to trunk , desirable , or auto mode. This is the default mode for all LAN ports.
switchport mode dynamic auto	Makes the LAN port willing to convert the link to a trunk link. The LAN port becomes a trunk port if the neighboring LAN port is set to trunk or desirable mode.
switchport mode trunk	Puts the LAN port into permanent trunking mode and negotiates to convert the link into a trunk link. The LAN port becomes a trunk port even if the neighboring port does not agree to the change.
switchport nonegotiate	Puts the LAN port into permanent trunking mode but prevents the port from generating DTP frames. You must configure the neighboring port manually as a trunk port to establish a trunk link.

**Note**

DTP is a point-to-point protocol. However, some internetworking devices might forward DTP frames improperly. To avoid this problem, ensure that LAN ports connected to devices that do not support DTP are configured with the **access** keyword if you do not intend to trunk across those links. To enable trunking to a device that does not support DTP, use the **nonegotiate** keyword to cause the LAN port to become a trunk but not generate DTP frames.

Default Settings for Layer 2 LAN Interfaces

Feature	Default
Interface mode: - Before entering the switchport command - After entering the switchport command	Layer 3 (unconfigured) switchport mode dynamic desirable
Allowed VLAN range	VLANs 1 to 4094, except reserved VLANs (see Table 26-1 on page 26-3)
VLAN range eligible for pruning	VLANs 2 to 1001
Default access VLAN	VLAN 1
Native VLAN (for 802.1Q trunks)	VLAN 1
Spanning Tree Protocol (STP)	Enabled for all VLANs
STP port priority	128
STP port cost	100 for 10-Mbps Ethernet LAN ports 19 for 10/100-Mbps Fast Ethernet LAN ports 19 for 100-Mbps Fast Ethernet LAN ports 4 for 1,000-Mbps Gigabit Ethernet LAN ports 2 for 10,000-Mbps 10-Gigabit Ethernet LAN ports

How to Configure LAN Interfaces for Layer 2 Switching

- [Configuring a LAN Port for Layer 2 Switching, page 21-6](#)
- [Enabling Out-of-Band MAC Address Table Synchronization, page 21-6](#)
- [Configuring MAC Address Table Notification, page 21-7](#)
- [Configuring a Layer 2 Switching Port as a Trunk, page 21-8](#)
- [Configuring a LAN Interface as a Layer 2 Access Port, page 21-14](#)
- [Configuring a Custom IEEE 802.1Q EtherType Field Value, page 21-15](#)



Note

Use the **default interface** {**fastethernet** | **gigabitethernet** | **tengigabitethernet**} *slot/port* command to revert an interface to its default configuration.

Configuring a LAN Port for Layer 2 Switching

To configure a LAN port for Layer 2 switching, perform this task:

	Command	Purpose
Step 1	<code>Tqwvgt*eqphki+%"kpvgt hceg" type slot/port</code>	Selects the LAN port to configure.
Step 2	<code>Tqwvgt*eqphki/kh+%"ujwvfqyp"</code>	(Optional) Shuts down the interface to prevent traffic flow until configuration is complete.
Step 3	<code>Tqwvgt*eqphki/kh+%"uykvejrgtv"</code>	Configures the LAN port for Layer 2 switching. Note You must enter the switchport command once without any keywords to configure the LAN port as a Layer 2 port before you can enter additional switchport commands with keywords.
Step 4	<code>Tqwvgt*eqphki/kh+%"pq"ujwvfqyp"</code>	Activates the interface. (Required only if you shut down the interface.)
Step 5	<code>Tqwvgt*eqphki/kh+%"gpf"</code>	Exits configuration mode.

After you enter the **switchport** command, the default mode is **switchport mode dynamic desirable**. If the neighboring port supports trunking and is configured to allow trunking, the link becomes a Layer 2 trunk when you enter the **switchport** command.



Note

When using the **switchport** command, if a port configured for Layer 3 is now configured for Layer 2, the configuration for Layer 3 is retained in the memory but not in the running configuration and is applied to the port whenever the port switches back to Layer 3. Also, if a port configured for Layer 2 is now configured for Layer 3, the configuration for Layer 2 is retained in the memory but not in the running configuration and is applied to the port whenever the port switches back to Layer 2. To restore the default configuration of the port in the memory and in the running configuration, use the **default interface** command. To avoid potential issues while changing the role of a port using the **switchport** command, shut down the interface before applying the **switchport** command.

Enabling Out-of-Band MAC Address Table Synchronization

To enable the out-of-band MAC address table synchronization feature, perform this task:

Command	Purpose
<code>Tqwvgt*eqphki+%"oce" cfftguu/vcdng"u{pej tqp k g"</code> <code>]cevkxkv{/vkog"ugeqpfu_"</code>	Enables out-of-band synchronization of MAC address tables among DFC-equipped switching modules. activity-time seconds—(Optional) Specifies the activity timer interval.

When configuring out-of-band MAC address table synchronization, note the following information:

- By default, out-of-band MAC address table synchronization is disabled.
- Out-of-band MAC address table synchronization is enabled automatically if a WS-6708-10G switching module is installed in the switch.
- The activity timer interval can be configured as 160, 320, and 640 seconds. The default is 160 seconds.

This example shows how to enable out-of-band MAC address table synchronization:

```
Tqvwgt%eqphkiwtg"vgtokpcn"  
Gpvg"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpgo""Gpf"Ykvj"EPVN1\0  
Tqvwgt*eqphki+%"oce"cfftguu/vcdng"u{pejtqpk|g"cevkxkv{/vkog"542"
```

Configuring MAC Address Table Notification



Note

- Complete the steps in the [“Configuring a LAN Port for Layer 2 Switching” section on page 21-6](#) before performing the tasks in this section.
- To send SNMP trap notifications using this feature, you must also enable the global MAC trap flag, using the **snmp-server enable mac-notification change** command.

To configure the MAC address table notification feature, perform this task:

	Command	Purpose
Step 1	<code>Tqvwgt*eqphki+%"oce"cfftguu/vcdng"pqvkhkecvkqp" ejcpig"]kpvgtxcn"xcnwg_"</code>	Enables sending notification of dynamic changes to MAC address table. (Optional) Sets the minimum change-sending interval in seconds. Note The no form of the command reverts to the default without sending any change information.
Step 2	<code>Tqvwgt*eqphki+%"oce"cfftguu/vcdng"pqvkhkecvkqp" ejcpig"]jkuvgt{"uk/g_</code>	Enables sending notification of dynamic changes to MAC address table. (Optional) Sets the number of entries in the history buffer. Note The no form of the command reverts to the default without sending any change information.
Step 3	<code>Tqvwgt*eqphki+%"kpvgthceg"type slot/port"</code>	Selects the LAN port to configure.
Step 4	<code>Tqvwgt*eqphki/kh+%"upor"vtcr"oce/pqvkhkecvkqp" ejcpig"]cfftgf"~"tgoqxf_</code>	For MAC addresses that are associated with this LAN port, enable SNMP trap notification when MAC addresses are added to or removed from the address table. (Optional) To notify only when a MAC address is added to the table, use the added option. To notify only when a MAC address is removed, use the removed option.
Step 5	<code>Tqvwgt*eqphki/kh+%"gpf"</code>	Exits interface configuration mode.

When configuring the notification parameters, note the following information:

- The **interval** *value* parameter can be configured from 0 seconds (immediate) to 2,147,483,647 seconds. The default is 1 second.
- The **history** *size* parameter can be configured from 0 entries to 500 entries. The default is 1 entry.

This example shows how to configure the SNMP notification of dynamic additions to the MAC address table of addresses on the Gigabit Ethernet ports 5/7 and 5/8. Notifications of changes will be sent no more frequently than 5 seconds, and up to 25 changes can be stored and sent in that interval:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpq0""Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%"oce"cfftgau/vcdng"pqvkhkecvkqp"ejcpig"kpvgtxcn"7"
Tqvwgt*eqphki+%"oce"cfftgau/vcdng"pqvkhkecvkqp"ejcpig"jkuvqt{"47"
Tqvwgt*eqphki+%"kpvgthceg"ikicdkvgvjgtpgv"719"
Tqvwgt*eqphki/kh+%"upor"vtcr"oce/pqvkhkecvkqp"ejcpig"cffgf
Tqvwgt*eqphki/kh+%"gpf"
Tqvwgt*eqphki+%"kpvgthceg"ikicdkvgvjgtpgv"71:"
Tqvwgt*eqphki/kh+%"upor"vtcr"oce/pqvkhkecvkqp"ejcpig"cffgf
Tqvwgt*eqphki/kh+%"gpf"
Tqvwgt%"gzkv"
```

Configuring a Layer 2 Switching Port as a Trunk

- [Configuring the Layer 2 Switching Port as an 802.1Q Trunk, page 21-8](#)
- [Configuring the Layer 2 Trunk to Use DTP, page 21-9](#)
- [Configuring the Layer 2 Trunk Not to Use DTP, page 21-9](#)
- [Configuring the Access VLAN, page 21-10](#)
- [Configuring the 802.1Q Native VLAN, page 21-11](#)
- [Configuring the List of VLANs Allowed on a Trunk, page 21-11](#)
- [Configuring the List of Prune-Eligible VLANs, page 21-12](#)
- [Completing Trunk Configuration, page 21-13](#)
- [Verifying Layer 2 Trunk Configuration, page 21-13](#)
- [Configuration and Verification Examples, page 21-13](#)

Configuring the Layer 2 Switching Port as an 802.1Q Trunk



Note

- Complete the steps in the [“Configuring a LAN Port for Layer 2 Switching”](#) section on page 21-6 before performing the tasks in this section.
- When you enter the **switchport** command with no other keywords ([Step 3](#) in the previous section), the default mode is **switchport mode dynamic desirable**.

To configure the Layer 2 switching port as an 802.1Q trunk, perform this task:

Command	Purpose
<code>Tqvwgt*eqphki/kh+% "uykvejxqtv"vtwpm"gpecruwmcvkqp" fqv3s"</code>	(Optional) Configures the encapsulation as 802.1Q.

To support the **switchport mode trunk** command, you must configure the encapsulation as 802.1Q.



Note

Complete the steps in the [“Completing Trunk Configuration” section on page 21-13](#) after performing the tasks in this section.

Configuring the Layer 2 Trunk to Use DTP



Note

Complete the steps in the [“Configuring a LAN Port for Layer 2 Switching” section on page 21-6](#) before performing the tasks in this section.

To configure the Layer 2 trunk to use DTP, perform this task:

Command	Purpose
<code>Tqvwgt*eqphki/kh+% "uykvejxqtv"oqfg"f{pcoke"}cwvq"~ " fguktcdng;"</code>	(Optional) Configures the trunk to use DTP. Note The no form of the command reverts to the default trunk trunking mode (switchport mode dynamic desirable).

When configuring the Layer 2 trunk to use DTP, note the following information:

- Required only if the interface is a Layer 2 access port or to specify the trunking mode.
- See [Table 21-1 on page 21-4](#) for information about trunking modes.



Note

Complete the steps in the [“Completing Trunk Configuration” section on page 21-13](#) after performing the tasks in this section.

Configuring the Layer 2 Trunk Not to Use DTP



Note

Complete the steps in the [“Configuring a LAN Port for Layer 2 Switching” section on page 21-6](#) before performing the tasks in this section.

To configure the Layer 2 trunk not to use DTP, perform this task:

	Command	Purpose
Step 1	<code>Tqwvgt*eqphki/kh+%uykvejrgtv"oqfg"vtwpm"</code>	(Optional) Configures the port to trunk unconditionally.
Step 2	<code>Tqwvgt*eqphki/kh+%uykvejrgtv"pqqgiqvkcvg"</code>	(Optional) Configures the trunk not to use DTP. Note The no form of the command enables DTP on the port.

When configuring the Layer 2 trunk not to use DTP, note the following information:

- Before entering the **switchport mode trunk** command, you must configure the encapsulation (see the “[Configuring the Layer 2 Switching Port as an 802.1Q Trunk](#)” section on page 21-8).
- To support the **switchport nonegotiate** command, you must enter the **switchport mode trunk** command.
- Enter the **switchport mode dynamic trunk** command. See [Table 21-1 on page 21-4](#) for information about trunking modes.
- Before entering the **switchport nonegotiate** command, you must configure the encapsulation (see the “[Configuring the Layer 2 Switching Port as an 802.1Q Trunk](#)” section on page 21-8) and configure the port to trunk unconditionally with the **switchport mode trunk** command (see the “[Configuring the Layer 2 Trunk to Use DTP](#)” section on page 21-9).



Note

Complete the steps in the “[Completing Trunk Configuration](#)” section on page 21-13 after performing the tasks in this section.

Configuring the Access VLAN



Note

Complete the steps in the “[Configuring a LAN Port for Layer 2 Switching](#)” section on page 21-6 before performing the tasks in this section.

To configure the access VLAN, perform this task:

Command	Purpose
<code>Tqwvgt*eqphki/kh+%uykvejrgtv"ceeguu"xncp"vlan_ID"</code>	(Optional) Configures the access VLAN, which is used if the interface stops trunking. The <i>vlan_ID</i> value can be 1 through 4094, except reserved VLANs (see Table 26-1 on page 26-3). Note • If VLAN locking is enabled, enter the VLAN name instead of the VLAN number. For more information, see the “VLAN Locking” section on page 26-4. • The no form of the command reverts to the default VLAN (VLAN 1).

**Note**

Complete the steps in the [“Completing Trunk Configuration” section on page 21-13](#) after performing the tasks in this section.

Configuring the 802.1Q Native VLAN

**Note**

Complete the steps in the [“Configuring a LAN Port for Layer 2 Switching” section on page 21-6](#) before performing the tasks in this section.

To configure the 802.1Q native VLAN, perform this task:

Command	Purpose
<code>Tqwgvt*eqphki/kh+% "uykvejrgtv"vtwpm"pcvkxg"xncp" vlan_ID"</code>	(Optional) Configures the 802.1Q native VLAN. Note If VLAN locking is enabled, enter the VLAN name instead of the VLAN number. For more information, see the “VLAN Locking” section on page 26-4 .

When configuring the native VLAN, note the following information:

- The `vlan_ID` value can be 1 through 4094, except reserved VLANs (see [Table 26-1 on page 26-3](#)).
- The access VLAN is not automatically used as the native VLAN.

**Note**

Complete the steps in the [“Completing Trunk Configuration” section on page 21-13](#) after performing the tasks in this section.

Configuring the List of VLANs Allowed on a Trunk

**Note**

Complete the steps in the [“Configuring a LAN Port for Layer 2 Switching” section on page 21-6](#) before performing the tasks in this section.

To configure the list of VLANs allowed on a trunk, perform this task:

Command	Purpose
<code>Tqwgvt*eqphki/kh+% "uykvejrgtv"vtwpm"cnnqygf"xncp"] cff ~"gzegrv"~"pqpg"~"tgoqyg_"xncp"] .xncp] .xncp] .000__"</code>	(Optional) Configures the list of VLANs allowed on the trunk. Note • If VLAN locking is enabled, enter VLAN names instead of VLAN numbers. For more information, see the “VLAN Locking” section on page 26-4. • The no form of the command reverts to the default value (all VLANs allowed).

When configuring the list of VLANs allowed on a trunk, note the following information:

- The *vlan* parameter is either a single VLAN number from 1 through 4094, or a range of VLANs described by two VLAN numbers, the lesser one first, separated by a dash. Do not enter any spaces between comma-separated *vlan* parameters or in dash-specified ranges.
- If VLAN locking is enabled, enter VLAN names instead of VLAN numbers. When entering a range of VLAN names, you must leave spaces between the VLAN names and the dash.
- All VLANs are allowed by default.
- You can remove VLAN 1. If you remove VLAN 1 from a trunk, the trunk interface continues to send and receive management traffic, for example, Cisco Discovery Protocol (CDP), VLAN Trunking Protocol (VTP), Port Aggregation Protocol (PAgP), and DTP in VLAN 1.



Note

Complete the steps in the [“Completing Trunk Configuration” section on page 21-13](#) after performing the tasks in this section.

Configuring the List of Prune-Eligible VLANs



Note

Complete the steps in the [“Configuring a LAN Port for Layer 2 Switching” section on page 21-6](#) before performing the tasks in this section.

To configure the list of prune-eligible VLANs on the Layer 2 trunk, perform this task:

Command	Purpose
<pre>Tqvwgt*eqphki/kh+%uykvejrqtv"vtwpm"rtwkpki"xncp" }pqpq"~}}cfff"~"gzegrv"~"tgoqxgi" xncp].xncp].xncp].000__i;i"</pre>	(Optional) Configures the list of prune-eligible VLANs on the trunk (see the “VTP Pruning” section on page 25-7). Note The no form of the command reverts to the default value (all VLANs prune-eligible).

When configuring the list of prune-eligible VLANs on a trunk, note the following information:

- The *vlan* parameter is either a single VLAN number from 1 through 4094, except reserved VLANs (see [Table 26-1 on page 26-3](#)), or a range of VLANs described by two VLAN numbers, the lesser one first, separated by a dash. Do not enter any spaces between comma-separated *vlan* parameters or in dash-specified ranges.
- The default list of VLANs allowed to be pruned contains all VLANs.
- Network devices in VTP transparent mode do not send VTP Join messages. On trunk connections to network devices in VTP transparent mode, configure the VLANs used by the transparent-mode network devices or that need to be carried across the transparent-mode network devices as pruning ineligible.



Note

Complete the steps in the [“Completing Trunk Configuration” section on page 21-13](#) after performing the tasks in this section.

Completing Trunk Configuration

To complete Layer 2 trunk configuration, perform this task:

	Command	Purpose
Step 1	<code>Tqwwgt*eqphki/kh+%pq"ujwvfqyp"</code>	Activates the interface. (Required only if you shut down the interface.)
Step 2	<code>Tqwwgt*eqphki/kh+%gpf"</code>	Exits configuration mode.

Verifying Layer 2 Trunk Configuration

To verify Layer 2 trunk configuration, perform this task:

	Command	Purpose
Step 1	<code>Tqwwgt%"ujqy"twppkpi/eqphki"kpvgthceg"type slot/port"</code>	Displays the running configuration of the interface.
Step 2	<code>Tqwwgt%"ujqy"kpvgthcegu]type slot/port_ uykvejrgtv"</code>	Displays the switch port configuration of the interface.
Step 3	<code>Tqwwgt%"ujqy"kpvgthcegu]type slot/port_ "vtwpm"</code>	Displays the trunk configuration of the interface.

Configuration and Verification Examples

This example shows how to configure the Gigabit Ethernet port 5/8 as an 802.1Q trunk. This example assumes that the neighbor port is configured to support 802.1Q trunking:

```
Tqwwgt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpq"rgt"nkpq0"Gpf"ykvj"EPVN1\0
Tqwwgt*eqphki+%kpvgthceg"ikicdkvgvjgtpgv"71:"
Tqwwgt*eqphki/kh+%ujwvfqyp"
Tqwwgt*eqphki/kh+%uykvejrgtv"
Tqwwgt*eqphki/kh+%uykvejrgtv"oqfg"f{pcoke"fguktcdng"
Tqwwgt*eqphki/kh+%uykvejrgtv"vtwpm"gpecruwncvkqp"fqv3s"
Tqwwgt*eqphki/kh+%pq"ujwvfqyp"
Tqwwgt*eqphki/kh+%gpf"
Tqwwgt%"gzkv"
```

This example shows how to verify the configuration:

```
Tqwwgt%"ujqy"twppkpi/eqphki"kpvgthceg"ikicdkvgvjgtpgv"71:"
Dwknfkpi"eqphkiwtcvkqp000
Ewtgtpv"eqphkiwtcvkqp<
#
kpvgthceg"IkicdkvGvjgtpgv71:
"pq"kr"cfftgau
"uykvejrgtv
"uykvejrgtv"vtwpm"gpecruwncvkqp"fqv3s
gpf

Tqwwgt%"ujqy"kpvgthcegu"ikicdkvgvjgtpgv"71:"uykvejrgtv"
Pcog<"Ik71:
Uykvejrgtv<"Gpcdnfg
Cfokpkuvtcvkxg"Oqfg<"f{pcoke"fguktcdng
Qrgtcvkqpcn"Oqfg<"vtwpm
Cfokpkuvtcvkxg"Vtwpmkpi"gpecruwncvkqp<"pgiqvkcvg
Qrgtcvkqpcn"Vtwpmkpi"gpecruwncvkqp<"fqv3s
Pgiqvkcvkqp"qh"Vtwpmkpi<"Gpcdnfg
Ceeguu"Oqfg"XNCP<"3"*fghcwnv+
```

Vtwpmkpi"Pcvkxg"Oqfg"XNCP<"3"*fghcwnv+
Vtwpmkpi"XNCPu"Gpcdngf<"CNN
Rtwpkpi"XNCPu"Gpcdngf<"CNN

Tqwvgt%"ujqy"kpvgthcegu"ikicdkvgvjgtpgv"71:"vtwpm"

Rqtv""""Oqfg""""Gpecruwncvkqp""Uvcvwu""""Pcvkxg"xncp
Ik71:"""fguktcdng""p/:2403s""""vtwpmkpi""""3

Rqtv""""Xncpu"cnnqygf"qp"vtwpm
Ik71:"3/3227

Rqtv""""Xncpu"cnnqygf"cpf"cevkxg"kp"ocpcioggpv"fqockp
Ik71:"3/8.32.42.72.322.374.422.522.525/527.56;/573.622.722.743.746.792.:23/
24.:72.;39.;;.3224/3227

Rqtv""""Xncpu"kp"urcppkpi"vtgg"hqtyctfkpi"uvcvg"cpf"pqv"rtwpgf
Ik71:"3/8.32.42.72.322.374.422.522.525/527.56;/573.622.722.743.746.792.:23/
24.:72.;39.;;.3224/3227

Tqwvgt%"

Configuring a LAN Interface as a Layer 2 Access Port



Note

If you assign a LAN port to a VLAN that does not exist, the port is shut down until you create the VLAN in the VLAN database (see the [“Creating or Modifying an Ethernet VLAN”](#) section on page 26-5).

To configure a LAN port as a Layer 2 access port, perform this task:

	Command	Purpose
Step 1	<code>Tqwvgt*eqphki+%"kpvgthceg" type slot/port</code>	Selects the LAN port to configure.
Step 2	<code>Tqwvgt*eqphki/kh+%"ujwvfqyp"</code>	(Optional) Shuts down the interface to prevent traffic flow until configuration is complete.
Step 3	<code>Tqwvgt*eqphki/kh+%"uykvejrqtv"</code>	Configures the LAN port for Layer 2 switching. Note You must enter the switchport command once without any keywords to configure the LAN port as a Layer 2 port before you can enter additional switchport commands with keywords.
Step 4	<code>Tqwvgt*eqphki/kh+%"uykvejrqtv"oqfg"ceeguu"</code>	Configures the LAN port as a Layer 2 access port.
Step 5	<code>Tqwvgt*eqphki/kh+%"uykvejrqtv"ceeguu"xncp"vlan_ID"</code>	Places the LAN port in a VLAN. The <i>vlan_ID</i> value can be 1 through 4094, except reserved VLANs (see Table 26-1 on page 26-3). Note If VLAN locking is enabled, enter the VLAN name instead of the VLAN number. For more information, see the “VLAN Locking” section on page 26-4 .
Step 6	<code>Tqwvgt*eqphki/kh+%"pq"ujwvfqyp"</code>	Activates the interface. (Required only if you shut down the interface.)
Step 7	<code>Tqwvgt*eqphki/kh+%"gpf"</code>	Exits configuration mode.

This example shows how to configure the Gigabit Ethernet port 5/6 as an access port in VLAN 200:

```
Tqvwgt% "eqphkiwtg"vgtokpcn"
Gpvgt "eqphkiwtcvkqp"eqoocpfu. "qpg"rgt"nkp00" "Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"718"
Tqvwgt*eqphki/kh+%"ujwvfqyp"
Tqvwgt*eqphki/kh+%"uykvejrgtv"
Tqvwgt*eqphki/kh+%"uykvejrgtv"oqfg"ceeguu"
Tqvwgt*eqphki/kh+%"uykvejrgtv"ceeguu"xncp"422"
Tqvwgt*eqphki/kh+%"pq"ujwvfqyp"
Tqvwgt*eqphki/kh+%"gpf"
Tqvwgt% "gzkv"
```

This example shows how to verify the configuration:

```
Tqvwgt% "ujqy"twppkpi/eqphki"kpvgtthceg"ikicdkvgvjgtpgv"718"
Dwknfkpi "eqphkiwtcvkqp000
#
Ewtgtpv"eqphkiwtcvkqp<
kpvgtthceg"Ikicdkvgvjgtpgv718
"pq"kr"cfftgau
"uykvejrgtv"ceeguu"xncp"422
"uykvejrgtv"oqfg"ceeguu
gpf

Tqvwgt% "ujqy"kpvgtthcegu"ikicdkvgvjgtpgv"718"uykvejrgtv"
Pcog<"Ik718
Uykvejrgtv<"Gpcdngf
Cfokpkuvtcvkxg"Oqfg<"uvcvke"ceeguu
Qrgtcvkqpcn"Oqfg<"uvcvke"ceeguu
Cfokpkuvtcvkxg"Vtwpmkpi"Gpecruwncvkqp<"pgiqvkcvg
Qrgtcvkqpcn"Vtwpmkpi"Gpecruwncvkqp<"pcvkxg
Pgiqvkcvkqp"qh"Vtwpmkpi<"Gpcdngf
Ceeguu"Oqfg"XNCP<"422"*XNCP2422+
Vtwpmkpi"Pcvkxg"Oqfg"XNCP<"3"*fghcwnv+
Vtwpmkpi"XNCPu"Gpcdngf<"CNN
Rtwpkpi"XNCPu"Gpcdngf<"CNN

Tqvwgt% "
```

Configuring a Custom IEEE 802.1Q EtherType Field Value

You can configure a custom EtherType field value on a port to support network devices that do not use the standard 0x8100 EtherType field value on 802.1Q-tagged or 802.1p-tagged frames.

To configure a custom value for the EtherType field, perform this task:

Command	Purpose
Tqvwgt*eqphki/kh+%"uykvejrgtv"fqv3s"gvjgtv{rg" value	Configures the 802.1Q EtherType field value for the port.

When configuring a custom EtherType field value, note the following information:

- To use a custom EtherType field value, all network devices in the traffic path across the network must support the custom EtherType field value.
- You can configure a custom EtherType field value on trunk ports, access ports, and tunnel ports.
- You can configure a custom EtherType field value on the member ports of an EtherChannel.
- You cannot configure a custom EtherType field value on a port-channel interface.

- Each port supports only one EtherType field value. A port that is configured with a custom EtherType field value does not recognize frames that have any other EtherType field value as tagged frames. For example, a trunk port that is configured with a custom EtherType field value does not recognize the standard 0x8100 EtherType field value on 802.1Q-tagged frames and cannot put the frames into the VLAN to which they belong.

**Caution**

A port that is configured with a custom EtherType field value considers frames that have any other EtherType field value to be untagged frames. A trunk port with a custom EtherType field value places frames with any other EtherType field value into the native VLAN. An access port or tunnel port with a custom EtherType field value places frames that are tagged with any other EtherType field value into the access VLAN. If you misconfigure a custom EtherType field value, frames might be placed into the wrong VLAN.

- See the *Release Notes for Cisco IOS Release 15.2SY* for a list of the modules that support custom IEEE 802.1Q EtherType field values:

http://www.cisco.com/en/US/docs/switches/lan/catalyst6500/ios/15.1SY/release_notes.html

This example shows how to configure the EtherType field value to 0x1234:

```
Tqwgvt " *eqphki /kh+%"uykvejrgtv"fqv3s"gvjgtv{rg"3456
Tqwgvt " *eqphki /kh+%
```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Flex Links

- [Prerequisites for Flex Links, page 22-1](#)
- [Restrictions for Flex Links, page 22-2](#)
- [Information About Flex Links, page 22-2](#)
- [Default Settings for Flex Links, page 22-4](#)
- [How to Configure Flex Links, page 22-4](#)
- [Monitoring Flex Links, page 22-6](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for Flex Links

None.

Restrictions for Flex Links

- You can configure only one Flex Links backup link for any active link, and it must be a different interface from the active interface.
- An interface can belong to only one Flex Links pair. An interface can be a backup link for only one active link. An active link cannot belong to another Flex Links pair.
- Neither of the links can be a port that belongs to an EtherChannel. However, you can configure two port channels (EtherChannel logical interfaces) as Flex Links, and you can configure a port channel and a physical interface as Flex Links, with either the port channel or the physical interface as the active link.
- A backup link does not have to be the same type as the active link (Fast Ethernet, Gigabit Ethernet, or port channel). However, you should configure both Flex Links with similar characteristics so that there are no loops or changes in operation if the standby link becomes active.
- STP is disabled on Flex Links ports. If STP is disabled on the switch, be sure that there are no Layer 2 loops in the network topology.
- Do not configure any STP features (for example, PortFast, BPDU Guard, and so forth) on Flex Links ports or the ports to which the links connect.
- Local administrative shut down or a link that starts forwarding again due to preemption is not considered a link failure. In those cases, the feature flushes the dynamic hosts and does not move them.
- Static MAC addresses that are configured on the primary link are not moved to the standby link.
- Static MAC addresses configured on a flex links port are restored when it starts forwarding again.


Information About Flex Links

Flex Links are a pair of Layer 2 interfaces (ports or port channels), where one interface is configured to act as a backup to the other. Flex Links are typically configured in service-provider or enterprise networks where customers do not want to run STP. Flex Links provide link-level redundancy that is an alternative to Spanning Tree Protocol (STP). STP is automatically disabled on Flex Links interfaces.

Release 15.2SY supports a maximum of 16 Flex Links. Flex Links are supported only on Layer 2 ports and port channels, not on VLANs or on Layer 3 ports.

To configure the Flex Links feature, you configure one Layer 2 interface as the standby link for the link that you want to be primary. With Flex Links configured for a pair of interfaces, only one of the interfaces is in the linkup state and is forwarding traffic. If the primary link shuts down, the standby link starts forwarding traffic. When the inactive link comes back up, it goes into standby mode.

In [Figure 22-1](#), ports 1 and 2 on switch A are connected to uplink switches B and C. Because they are configured as Flex Links, only one of the interfaces is forwarding traffic and the other one is in standby mode. If port 1 is the active link, it begins forwarding traffic between port 1 and switch B; the link between port 2 (the backup link) and switch C is not forwarding traffic. If port 1 goes down, port 2 comes up and starts forwarding traffic to switch C. When port 1 comes back up, it goes into standby mode and does not forward traffic; port 2 continues to forward traffic.

Figure 22-1 Flex Links Configuration Example

If a primary (forwarding) link goes down, a trap notifies the network management stations. If the standby link goes down, a trap notifies the users. When a primary link fails, the feature takes these actions:


- Detects the failure.
- Moves any dynamic unicast MAC addresses that are learned on the primary link to the standby link.
- Moves the standby link to a forwarding state.
- Transmits dummy multicast packets over the new active interface. The dummy multicast packet format is:
 - Destination: 01:00:0c:cd:cd:cd
 - Source: MAC address of the hosts or ports on the newly active Flex Link port.

In [Figure 22-2](#), ports 1 and 2 on switch A are connected to switches B and D through a Flex Link pair. Port 1 is forwarding traffic, and port 2 is in the blocking state. Traffic from the PC to the server is forwarded from port 1 to port 3. The MAC address of the PC has been learned on port 3 of switch C. Traffic from the server to the PC is forwarded from port 3 to port 1.

If port 1 shuts down, port 2 starts forwarding traffic. If there is no traffic from the PC to the server after failover to port 2, switch C does not learn the MAC address of the PC on port 4, and because of that, switch C keeps forwarding traffic from the server to the PC out of port 3. There is traffic loss from the server to the PC because port 1 is down. To alleviate this problem, the feature sends out a dummy multicast packet with the source MAC address of the PC over port 2. Switch C learns the PC MAC address on port 4 and start forwarding traffic from the server to the PC out of port 4. One dummy multicast packet is sent out for every MAC address.

Flex links interface preemption specifies one of the ports in a flex links pair as preferred for traffic forwarding. The preference can be unconditional or it can be based on bandwidth availability. See the [“How to Configure Flex Links”](#) section on page 22-4.

Figure 22-2 Flexlink Dummy Multicast Packets Example



Default Settings for Flex Links

- Flex links: not configured.
- Flex links interface preemption: not configured.
- Flex links interface preemption delay: 35 seconds.

How to Configure Flex Links

To configure Flex Links, perform this task:

	Command	Purpose
Step 1	<code>Tqwwgt% "eqphkiwtg" vgtokpcn</code>	Enters global configuration mode.
Step 2	<code>Tqwwgt*eqph+% "kpvgthceg" }} type slot/rqtv i "~" }rqtv/ejcppgn "pwodgt i i "</code>	Specifies a Layer 2 interface.

Monitoring Flex Links

To monitor the Flex Links configuration, perform this task:

Command	Purpose
<code>show flex-links backup interface <i>slot/port</i> [type <i>slot/port</i>] [state <i>active/standby</i>]</code>	Displays the Flex Links backup interface configured for an interface, or displays all Flex Links configured on the switch and the state of each active and backup interface (up or standby mode).



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



EtherChannels

- [Prerequisites for EtherChannels, page 23-1](#)
- [Restrictions for EtherChannels, page 23-2](#)
- [Information About EtherChannels, page 23-3](#)
- [Default Settings for EtherChannels, page 23-7](#)
- [How to Configure EtherChannels, page 23-7](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for EtherChannels

None.

Restrictions for EtherChannels

- LACP EtherChannels and the [802.1ad provider-bridge mode](#) are mutually exclusive. LACP EtherChannels cannot transmit traffic when the 802.1ad provider-bridge mode is enabled.
- LACP does not support half-duplex links. Half-duplex links in an LACP EtherChannel are put in the suspended state.

**Caution**

Serious traffic problems can result from mixing manual mode with LACP mode, or by connecting an EtherChannel member port to a port not configured as part of the EtherChannel. For example, if a port configured in **on** mode is connected to another port configured in **desirable** mode, or to a port not configured as a member of the EtherChannel, a bridge loop is created and a broadcast storm can occur. If one end uses the **on** mode, the other end must also.

- When EtherChannel interfaces are configured improperly, they are disabled automatically to avoid network loops and other problems.
- Frames with SAP/SNAP encapsulation are load-balanced as Layer 2 traffic.
- The commands in this chapter can be used on all Layer 2 Ethernet ports, including the ports on the supervisor engine and a redundant supervisor engine.
- All Layer 2 Ethernet ports on all modules, including those on a redundant supervisor engine, support EtherChannels (maximum of eight LAN ports) with no requirement that the LAN ports be physically contiguous or on the same module.
- Configure all LAN ports in an EtherChannel to use the same EtherChannel protocol; you cannot run two EtherChannel protocols in one EtherChannel.
- Configure all LAN ports in an EtherChannel to operate at the same speed and in the same duplex mode.
- Enable all LAN ports in an EtherChannel. If you shut down a LAN port in an EtherChannel, it is treated as a link failure and its traffic is transferred to one of the remaining ports in the EtherChannel.
- An EtherChannel will not form if any of the LAN ports is a Switched Port Analyzer (SPAN) destination port.
- For Layer 3 EtherChannels, assign Layer 3 addresses to the port channel logical interface, not to the LAN ports in the channel.
- For Layer 2 EtherChannels:
 - Assign all LAN ports in the EtherChannel to the same VLAN or configure them as trunks.
 - If you configure an EtherChannel from trunking LAN ports, verify that the trunking mode is the same on all the trunks. LAN ports in an EtherChannel with different trunk modes can operate unpredictably.
 - An EtherChannel supports the same allowed range of VLANs on all the LAN ports in a trunking Layer 2 EtherChannel. If the allowed range of VLANs is not the same, the LAN ports do not form an EtherChannel.
 - LAN ports with different STP port path costs can form an EtherChannel as long they are compatibly configured with each other. If you set different STP port path costs, the LAN ports are not incompatible for the formation of an EtherChannel.
 - An EtherChannel will not form if protocol filtering is set differently on the LAN ports.

- Configure static MAC addresses on the EtherChannel only and not on physical member ports of the EtherChannel.
- After you configure an EtherChannel, the configuration that you apply to the port channel interface affects the EtherChannel. The configuration that you apply to the LAN ports affects only the LAN port where you apply the configuration.
- Cisco IOS Release 15.4SY does not support ISL trunk encapsulation. If a non-trunking Layer 2 EtherChannel includes member ports that are not capable of ISL trunk encapsulation, the **switchport trunk encapsulation dot1q** command is added to the port-channel interface. The command has no affect when the switchport mode is “access” (CSCta45114).
- When QoS is enabled, enter the **no platform qos channel-consistency** port-channel interface command to support EtherChannels that have ports with and without strict-priority queues.

Information About EtherChannels

- [EtherChannel Feature Overview, page 23-3](#)
- [Information about EtherChannel Configuration, page 23-3](#)
- [Information about Port Channel Interfaces, page 23-7](#)
- [Information about LACP 1:1 Redundancy, page 23-6](#)
- [Information about Load Balancing, page 23-7](#)

EtherChannel Feature Overview

An EtherChannel bundles individual Ethernet links into a single logical link that provides the aggregate bandwidth of up to eight physical links.

Cisco IOS Release 15.4SY supports a maximum of 512 EtherChannels. You can form an EtherChannel with up to eight compatibly configured LAN ports on any switching module. All LAN ports in each EtherChannel must be the same speed and must all be configured as either Layer 2 or Layer 3 LAN ports.



Note

The network device to which a switch is connected may impose its own limits on the number of ports in an EtherChannel.

If a segment within an EtherChannel fails, traffic previously carried over the failed link switches to the remaining segments within the EtherChannel. When a failure occurs, the EtherChannel feature sends a trap that identifies the switch, the EtherChannel, and the failed link. Inbound broadcast and multicast packets on one segment in an EtherChannel are blocked from returning on any other segment of the EtherChannel.

Information about EtherChannel Configuration

- [EtherChannel Configuration Overview, page 23-4](#)
- [Information about Manual EtherChannel Configuration, page 23-5](#)
- [Information about PAGP EtherChannel Configuration, page 23-5](#)
- [Information about IEEE 802.3ad LACP EtherChannel Configuration, page 23-5](#)

EtherChannel Configuration Overview

You can configure EtherChannels manually or you can use the Port Aggregation Control Protocol (PAgP) or the Link Aggregation Control Protocol (LACP) to form EtherChannels. The EtherChannel protocols allow ports with similar characteristics to form an EtherChannel through dynamic negotiation with connected network devices. PAgP is a Cisco-proprietary protocol and LACP is defined in IEEE 802.3ad.

PAgP and LACP do not interoperate with each other. Ports configured to use PAgP cannot form EtherChannels with ports configured to use LACP. Ports configured to use LACP cannot form EtherChannels with ports configured to use PAgP. Neither interoperates with ports configured manually.

[Table 23-1](#) lists the user-configurable EtherChannel modes.

[Table 23-2](#) lists the EtherChannel member port states.

Table 23-1 *EtherChannel Modes*

Mode	Description
on	Mode that forces the LAN port to channel unconditionally. In the on mode, a usable EtherChannel exists only when a LAN port group in the on mode is connected to another LAN port group in the on mode. Because ports configured in the on mode do not negotiate, there is no negotiation traffic between the ports. You cannot configure the on mode with an EtherChannel protocol. If one end uses the on mode, the other end must also.
auto	PAgP mode that places a LAN port into a passive negotiating state, in which the port responds to PAgP packets it receives but does not initiate PAgP negotiation. (Default)
desirable	PAgP mode that places a LAN port into an active negotiating state, in which the port initiates negotiations with other LAN ports by sending PAgP packets.
passive	LACP mode that places a port into a passive negotiating state, in which the port responds to LACP packets it receives but does not initiate LACP negotiation. (Default)
active	LACP mode that places a port into an active negotiating state, in which the port initiates negotiations with other ports by sending LACP packets.

Table 23-2 *EtherChannel Member Port States*

Port States	Description
bundled	The port is part of an EtherChannel and can send and receive BPDUs and data traffic.
suspended	The port is not part of an EtherChannel. The port can receive BPDUs but cannot send them. Data traffic is blocked.
standalone	The port is not bundled in an EtherChannel. The port functions as a standalone data port. The port can send and receive BPDUs and data traffic. Note When one end of an EtherChannel has more members than the other, the unmatched ports enter the standalone state. In a topology that is not protected from Layer 2 loops by the spanning tree protocol (STP), a port in the standalone state can cause significant network errors. You can enter the port-channel standalone-disable interface configuration mode command to put ports into the suspended state instead of the standalone state. See the “Configuring LACP Port-Channel Standalone Disable” section on page 23-16.

Information about Manual EtherChannel Configuration

Manually configured EtherChannel ports do not exchange EtherChannel protocol packets. A manually configured EtherChannel forms only when you configure all ports in the EtherChannel compatibly.

Information about PAgP EtherChannel Configuration

PAgP supports the automatic creation of EtherChannels by exchanging PAgP packets between LAN ports. PAgP packets are exchanged only between ports in **auto** and **desirable** modes.

The protocol learns the capabilities of LAN port groups dynamically and informs the other LAN ports. Once PAgP identifies correctly matched Ethernet links, it facilitates grouping the links into an EtherChannel. The EtherChannel is then added to the spanning tree as a single bridge port.

Both the **auto** and **desirable** modes allow PAgP to negotiate between LAN ports to determine if they can form an EtherChannel, based on criteria such as port speed and trunking state. Layer 2 EtherChannels also use VLAN numbers.

LAN ports can form an EtherChannel when they are in different PAgP modes if the modes are compatible. For example:

- A LAN port in **desirable** mode can form an EtherChannel successfully with another LAN port that is in **desirable** mode.
- A LAN port in **desirable** mode can form an EtherChannel with another LAN port in **auto** mode.
- A LAN port in **auto** mode cannot form an EtherChannel with another LAN port that is also in **auto** mode, because neither port will initiate negotiation.

Information about IEEE 802.3ad LACP EtherChannel Configuration

LACP supports the automatic creation of EtherChannels by exchanging LACP packets between LAN ports. LACP packets are exchanged only between ports in **passive** and **active** modes.

The protocol learns the capabilities of LAN port groups dynamically and informs the other LAN ports. Once LACP identifies correctly matched Ethernet links, it facilitates grouping the links into an EtherChannel. The EtherChannel is then added to the spanning tree as a single bridge port.

Both the **passive** and **active** modes allow LACP to negotiate between LAN ports to determine if they can form an EtherChannel, based on criteria such as port speed and trunking state. Layer 2 EtherChannels also use VLAN numbers.

LAN ports can form an EtherChannel when they are in different LACP modes as long as the modes are compatible. For example:

- A LAN port in **active** mode can form an EtherChannel successfully with another LAN port that is in **active** mode.
- A LAN port in **active** mode can form an EtherChannel with another LAN port in **passive** mode.
- A LAN port in **passive** mode cannot form an EtherChannel with another LAN port that is also in **passive** mode, because neither port will initiate negotiation.

LACP uses the following parameters:

- LACP system priority—You must configure an LACP system priority on each switch running LACP. The system priority can be configured automatically or through the CLI (see the [“Configuring the LACP System Priority and System ID” section on page 23-11](#)). LACP uses the system priority with the switch MAC address to form the system ID and also during negotiation with other systems.



Note The LACP system ID is the combination of the LACP system priority value and the MAC address of the switch.

- LACP port priority—You must configure an LACP port priority on each port configured to use LACP. The port priority can be configured automatically or through the CLI (see the [“Configuring Channel Groups” section on page 23-9](#)). LACP uses the port priority with the port number to form the port identifier. LACP uses the port priority to decide which ports should be put in standby mode when there is a hardware limitation that prevents all compatible ports from aggregating.
- LACP administrative key—LACP automatically configures an administrative key value equal to the channel group identification number on each port configured to use LACP. The administrative key defines the ability of a port to aggregate with other ports. A port’s ability to aggregate with other ports is determined by these factors:
 - Port physical characteristics, such as data rate, duplex capability, and point-to-point or shared medium
 - Configuration restrictions that you establish

On ports configured to use LACP, LACP tries to configure the maximum number of compatible ports in an EtherChannel, up to the maximum allowed by the hardware (eight ports). If LACP cannot aggregate all the ports that are compatible (for example, the remote system might have more restrictive hardware limitations), then all the ports that cannot be actively included in the channel are put in hot standby state and are used only if one of the channeled ports fails. You can configure an additional 8 standby ports (total of 16 ports associated with the EtherChannel).

Information about LACP 1:1 Redundancy

The LACP 1:1 redundancy feature supports an EtherChannel configuration with one active link and fast switchover to a hot standby link. The link connected to the port with the lower port priority number (and therefore a higher priority) will be the active link, and the other link will be in a hot standby state. If the active link goes down, LACP performs fast switchover to the hot standby link to keep the EtherChannel up. When the failed link becomes operational again, LACP performs another fast switchover to revert to the original active link.

To allow the higher priority port to stabilize when it becomes active again after a higher-priority to lower-priority switchover, the LACP 1:1 hot standby dampening feature configures a timer that delays switchover back to the higher priority port after it becomes active.

See the [“Configuring LACP 1:1 Redundancy” section on page 23-14](#).

Information about Port Channel Interfaces

Each EtherChannel has a numbered port channel interface. You can configure a maximum of 128 port-channel interfaces, numbered from 1 to 256. The configuration that you apply to the port channel interface affects all LAN ports assigned to the port channel interface.

After you configure an EtherChannel, the configuration that you apply to the port channel interface affects the EtherChannel; the configuration that you apply to the LAN ports affects only the LAN port where you apply the configuration. To change the parameters of all ports in an EtherChannel, apply the configuration commands to the port channel interface, for example, Spanning Tree Protocol (STP) commands or commands to configure a Layer 2 EtherChannel as a trunk.

Information about Load Balancing

An EtherChannel balances the traffic load across the links in an EtherChannel by reducing part of the binary pattern formed from the addresses in the frame to a numerical value that selects one of the links in the channel.

EtherChannel load balancing can use MAC addresses or IP addresses. EtherChannel load balancing can also use Layer 4 port numbers. EtherChannel load balancing can use either source or destination or both source and destination addresses or ports. The selected mode applies to all EtherChannels configured on the switch. EtherChannel load balancing can use MPLS Layer 2 information.

Use the option that provides the balance criteria with the greatest variety in your configuration. For example, if the traffic on an EtherChannel is going only to a single MAC address and you use the destination MAC address as the basis of EtherChannel load balancing, the EtherChannel always chooses the same link in the EtherChannel; using source addresses or IP addresses might result in better load balancing.

Default Settings for EtherChannels

None.

How to Configure EtherChannels

- [Configuring Port Channel Logical Interfaces, page 23-8](#)
- [Configuring Channel Groups, page 23-9](#)
- [Configuring the LACP System Priority and System ID, page 23-11](#)
- [Configuring EtherChannel Load Balancing, page 23-11](#)
- [Configuring the EtherChannel Hash-Distribution Algorithm, page 23-12](#)
- [Configuring the EtherChannel Min-Links Feature, page 23-13](#)
- [Configuring LACP 1:1 Redundancy, page 23-14](#)

- [Configuring Auto Interleaved Port Priority For LACP Port Channels, page 23-15](#)
- [Configuring LACP Port-Channel Standalone Disable, page 23-16](#)

**Note**

Make sure that the LAN ports are configured correctly (see the [“Restrictions for EtherChannels” section on page 23-2](#)).

Configuring Port Channel Logical Interfaces

**Note**

To move an IP address from a Layer 3 LAN port to an EtherChannel, you must delete the IP address from the Layer 3 LAN port before configuring it on the port channel logical interface.

To create a port channel interface for a Layer 3 EtherChannel, perform this task:

	Command	Purpose
Step 1	<code>Tqwvgt*eqphki+%"kpvgtthceg"rqtvejcppgn"itqwrapwodgt"</code>	Creates the port channel interface.
Step 2	<code>Tqwvgt*eqphki/kh+%"kr"cfftgau"ip_address mask"</code>	Assigns an IP address and subnet mask to the EtherChannel.
Step 3	<code>Tqwvgt*eqphki/kh+%"gpf"</code>	Exits configuration mode.

The *group_number* can be 1 through 256, up to a maximum of 256 port-channel interfaces in standalone mode. In VSS-mode the group number can be through 1 through 512, up to a maximum of 512 port channel-interfaces. This example shows how to create port channel interface 1:

```
Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+%"kpvgtthceg"rqtvejcppgn"3"
Tqwvgt*eqphki/kh+%"kr"cfftgau"394054074032"4770477047702"
Tqwvgt*eqphki/kh+%"gpf"
```

This example shows how to verify the configuration of port channel interface 1:

```
Tqwvgt%"ujqy"twppkpi/eqphki"kpvgtthceg"rqtvejcppgn"3"
Dwknfkpi"eqphkiwtcvkqp000

Ewttgvp"eqphkiwtcvkqp<
#
kpvgtthceg"Rqtvejcppgn3
"kr"cfftgau"394054074032"4770477047702
"pq"kr"fkgtgevgf/dtqcfeuv
gpf
Tqwvgt%
```

Configuring Channel Groups



Note

For Cisco IOS to create port channel interfaces for Layer 2 EtherChannels, the Layer 2 LAN ports must be connected and functioning.

To configure channel groups, perform this task for each LAN port:

	Command	Purpose
Step 1	<code>Tqwwgt*eqphki+%kpvgthceg"type slot/port"</code>	Selects a LAN port to configure.
Step 2	<code>Tqwwgt*eqphki/kh+%pq"kr"cfftgauu"</code>	Ensures that there is no IP address assigned to the LAN port.
Step 3	<code>Tqwwgt*eqphki/kh+%ejcppgn/rtqvqeqn"*ncer"~"rcir;</code>	(Optional) On the selected LAN port, restricts the channel-group command to the EtherChannel protocol configured with the channel-protocol command.
Step 4	<code>Tqwwgt*eqphki/kh+%ejcppgn/itqwr"itqwrapwodgt" oqfg" }cev~~k~~xg"~"cwvq"~"fguktcđng"~"qp"~"rcuukxg;"</code>	Configures the LAN port in a port channel and specifies the mode (see Table 23-1 on page 23-4). PAGP supports only the auto and desirable modes. LACP supports only the active and passive modes.
Step 5	<code>Tqwwgt*eqphki/kh+%ncer"rqtv/rtkqtkv{ " priority_value</code>	(Optional for LACP) Valid values are 1 through 65535. Higher numbers have lower priority. The default is 32768.
Step 6	<code>Tqwwgt*eqphki/kh+%fq"ujqy"kpvgthceg"rqtv/ejcppgn" itqwrapwodgt</code>	(Optional) Displays the interface configuration information of the specified port channel. Note: The output of this command shows that the newly created port channel interface will be in shutdown state.
Step 7	<code>Tqwwgt*eqphki/kh+%pq"ujwvfqyp"</code>	Brings the port channel and its members up and all the configuration changes that you apply to the port channel is applied to every member interface of that port channel.
Step 8	<code>Tqwwgt*eqphki/kh+%gpf"</code>	Exits configuration mode.

This example shows how to configure Gigabit Ethernet ports 5/6 and 5/7 into port channel 2 with PAGP mode **desirable**:

```
Tqwwgt%eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+%kpvgthceg"tcpig"ikicđkvvgjgtpgv"718"/9"
Tqwwgt*eqphki/kh+%ejcppgn/itqwr"4"oqfg"fguktcđng
Tqwwgt*eqphki/kh+%pq"ujwvfqyp
Tqwwgt*eqphki/kh+%gpf"
```



Note

See the [“How to Configure a Range of Interfaces”](#) section on [page 10-2](#) for information about the **range** keyword.

This example shows how to verify the configuration of port channel interface 2:

```
Tqwwgt%ujqy"twppkpi/eqphki"kpvgthceg"rqtv/ejcppgn"4"
Dwknfkpi"eqphkiwtcvkqp000

Ewttgpv"eqphkiwtcvkqp<
#
```

```

kpvgtgthceg"Rqtv/ejcppgn4
"pq"kr"cfftguu
"uykvejrqtv
"uykvejrqtv"ceeguu"xncp"32
"uykvejrqtv"oqfg"ceeguu
gpf
Tqwvgt%"

```

This example shows how to verify the configuration of Gigabit Ethernet port 5/6:

```

Tqwvgt%"ujqy"twppkpi/eqphki"kpvgthceg"ikicdkvgvjgtpgv"718"
Dwknfkpi"eqphkiwtcvkqp000

Ewttgvp"eqphkiwtcvkqp<
#
kpvgtgthceg"IkicdkvGvjgtpgv718
"pq"kr"cfftguu
"uykvejrqtv
"uykvejrqtv"ceeguu"xncp"32
"uykvejrqtv"oqfg"ceeguu
"ejcppgn/itqwr"4"oqfg"fguktdng
gpf
Tqwvgt%"ujqy"kpvgthcegu"ikicdkvgvjgtpgv"718"gvjgtejcppgn"
Rqtv"uvcvg" ""?"Fgyp"Pqv/kp/Dpfn"
Ejcppgn"itqwr"?"34""""""""""Oqfg"?"Fguktdng/Un""""Ieejcpig"?"2
Rqtv/ejcppgn"?"pwnn" """"""""IE" ""?"2z2222222""""""""Rugwfq"rqt/ejcppgn"?"Rq3
4
Rqtv"kpfgz" ""?"2""""""""Nqcf"?"2z22""""""Rtqvgeqn"?" ""RCiR

Hnciu<"U"/"Fgxkeg"ku"ugpfkpi"Unqy"jgnnq0""E"/"Fgxkeg"ku"kp"Eqpukuvgpv"uvcvg0
""""""""C"/"Fgxkeg"ku"kp"Cwvq"oqfg0""""""R"/"Fgxkeg"ngctpu"qp"rj{ukecn"rqt0
""""""f"/"RCiR"ku"fgypp0
Vkogtu<"J"/"Jgnnq"vkogt"ku"twppkpi0""""""S"/"Swkv"vkogt"ku"twppkpi0
""""""U"/"Uykvejki"vkogt"ku"twppkpi0""""K"/"Kpvgtgthceg"vkogt"ku"twppkpi0

Nqecn"kphqtocvkqp<
""""""""""""""""""""Jgnnq""""Rctvpgt""RCiR""""Ngctpkpi"itqwr
Rqtv""""Hnciu"Uvcvg""Vkogtu"Kpvgtxcn"Eqwpv""Rtkqtkv{ ""Ogvjqf"Khkpfgz
Ik714""""f""""W31U3""""""3u""""""2""""""34: """"""Cp{ """"2

Cig"qh"vjg"rqtvp"kp"vjg"ewttgvp"uvcvg<"26f<3:j<79o<3;u

```

This example shows how to verify the configuration of port channel interface 2 after the LAN ports have been configured:

```

Tqwvgt%"ujqy"gvjgtejcppgn"34"rqt/ejcppgn"
""""""""""Rqtv/ejcppgnu"kp"vjg"itqwr<
""""""""""////////////////////////////////

Rqtv/ejcppgn<"Rq34
////////////////////////////////

Cig"qh"vjg"Rqtv/ejcppgn" ""?"26f<3:j<7:o<72u
Nqikecn"unqv1rqt""?"3613""""""""Pwodgt"qh"rqtvu"?"2
IE""""""""""?"2z2222222""""JqvUvcpfD{"rqt"?"pwnn
Rqtv"uvcvg" """"""""Rqtv/ejcppgn"Ci/Pqv/Kpwug"
Rtqvgeqn""""""""?" ""RCiR

Tqwvgt%"

```

Configuring the LACP System Priority and System ID

The LACP system ID is the combination of the LACP system priority value and the MAC address of the switch.

To configure the LACP system priority and system ID, perform this task:

	Command	Purpose
Step 1	<code>Tqwgvt*eqphki+% "ncer"u{uvgo/rtkqtkv{ "value</code>	(Optional for LACP) Valid values are 1 through 65535. Higher numbers have lower priority. The default is 32768.
Step 2	<code>Tqwgvt*eqphki+% "gpf"</code>	Exits configuration mode.

This example shows how to configure the LACP system priority:

```
Tqwgvt% "eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+% "ncer"u{uvgo/rtkqtkv{ "45678
Tqwgvt*eqphki+% "gpf"
Tqwgvt*eqphki+% "
```

This example shows how to verify the configuration:

```
Tqwgvt% "ujqy"ncer"u{u/kf"
45678.227205g:f08622
Tqwgvt% "
```

The system priority is displayed first, followed by the MAC address of the switch.

Configuring EtherChannel Load Balancing

To configure EtherChannel load balancing, perform this task:

	Command	Purpose
Step 1	<code>Tqwgvt*eqphki+% "rqtv/ejcppgn"rgt/oqfwng"nqcf/dcnpeg"</code>	(Optional) Enables the ability to specify the load-balancing method on a per-module basis.
Step 2	<code>Tqwgvt*eqphki+% "rqtv/ejcppgn"nqcf/dcnpeg"]cnn ~ hgz"hgzapwodgt_"ogvjqf"]oqfwng"unqv_</code>	Configures the EtherChannel load-balancing method. The <i>method</i> is globally applied to all port channels. Optionally, you can configure the load-balancing method for a specific module. The default method is src-dst-ip . A configurable load balancing method is only applicable for unicast traffic. For multicast traffic the load balancing method used is always src-dst-ip . Note - If you configure EtherChannel load balancing on a switch that is not in VSS mode, traffic is disrupted while the EtherChannel member ports transition through the shutdown and then no shutdown states. - There is no disruption on switches in VSS mode.
Step 3	<code>Tqwgvt*eqphki+% "gpf"</code>	Exits configuration mode.

The load-balancing *method* keywords indicate the following information:

- **dst-ip**—Destination IP addresses
- **dst-mac**—Destination MAC addresses
- **dst-mixed-ip-port**—Destination IP address and TCP/UDP port
- **dst-port**—Destination Layer 4 port
- **mpls**—Load balancing for MPLS packets
- **src-dst-ip**—(Default) Source and destination IP addresses
- **src-dst-mac**—Source and destination MAC addresses
- **src-dst-mixed-ip-port**—Source and destination IP address and TCP/UDP port
- **src-dst-port**—Source and destination Layer 4 port
- **src-ip**—Source IP addresses
- **src-mac**—Source MAC addresses
- **src-mixed-ip-port**—Source IP address and TCP/UDP port
- **src-port**—Source Layer 4 port
- **vlan-dst-ip**—VLAN number and destination IP address
- **vlan-dst-mixed-ip-port**—VLAN number and destination IP address and TCP/UDP port
- **vlan-src-dst-ip**—VLAN number and source and destination IP address
- **vlan-src-dst-mixed-ip-port**—VLAN number and source and destination IP address and TCP/UDP port
- **vlan-src-ip**—VLAN number and source IP address
- **vlan-src-mixed-ip-port**—VLAN number and source IP address and TCP/UDP port

The optional **module** keyword allows you to specify the load-balancing method for a specific module. This capability is supported only on DFC-equipped switching modules. You must enable per-module load balancing globally before configuring the feature on a module.

This example shows how to configure EtherChannel to use source and destination IP addresses:

```
Tqwgvt% "eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+% "rqtv/ejcppgn"nqcf/dncpeg"ute/fuv/kr"
Tqwgvt*eqphki+% "gpf"
Tqwgvt*eqphki+% "
```

This example shows how to verify the configuration:

```
Tqwgvt% "ujqy"gvjgtejcppgn"nqcf/dncpeg"
Uqwteq"ZQT" Fguvkpcvkqp"KR" cfftguu"
```

Configuring the EtherChannel Hash-Distribution Algorithm

When you add a port to an EtherChannel or delete a port from an EtherChannel, the fixed algorithm updates the port ASIC for each port in the EtherChannel, which causes a short outage on each port.

The default adaptive algorithm does not need to update the port ASIC for existing member ports. You can configure a global value for the adaptive algorithm. You can also specify the algorithm for individual port channels.

When you change the algorithm, the change is applied at the next member link event (link down, link up, addition, deletion, no shutdown, and shutdown). When you enter the command to change the algorithm, the command console issues a warning that the command does not take effect until the next member link event.

**Note**

- Some external devices require the fixed algorithm. For example, the service control engine (SCE) requires incoming and outgoing packets to use the same port.
- If you change the load-balancing method, EtherChannel ports on DFC-equipped switching modules or on an active supervisor engine in a dual supervisor engine configuration will flap.

Configuring the Hash-Distribution Algorithm Globally

To configure the load-sharing algorithm globally, perform this task:

	Command	Purpose
Step 1	<code>Tqwvgt*eqphki+%"rqtv/ejcppgn"jcu j/fkuvtkdvwkqp"}cfcrvkxg ~ hkzgf;</code>	Sets the hash distribution algorithm to adaptive or fixed.
Step 2	<code>Tqwvgt*eqphki+%"gpf"</code>	Exits configuration mode.

This example shows how to globally set the hash distribution to adaptive:

```
Tqwvgt*eqphki+%"rqtv/ejcppgn"jcu j/fkuvtkdvwkqp"}cfcrvkxg
```

Configuring the Hash-Distribution Algorithm for a Port Channel

To configure the hash-distribution algorithm for a specific port channel, perform this task:

	Command	Purpose
Step 1	<code>Tqwvgt*eqphki+%"kpvgtthceg"rqtv/ejcppgn"channel-num</code>	Enters interface configuration mode for the port channel.
Step 2	<code>Tqwvgt*eqphki/kh+%"rqtv/ejcppgn"rqtv"jcu j/fkuvtkdvwkqp"}cfcrvkxg ~ hkzgf;</code>	Sets the hash distribution algorithm for this interface
Step 3	<code>Tqwvgt*eqphki/kh+%"gpf"</code>	Exits interface configuration mode.

This example shows how to set the hash distribution algorithm to adaptive on port channel 10:

```
Tqwvgt"*eqphki+%"kpvgtthceg"rqtv/ejcppgn"32
Tqwvgt"*eqphki/kh+%"rqtv/ejcppgn"rqtv"jcu j/fkuvtkdvwkqp"}cfcrvkxg
```

Configuring the EtherChannel Min-Links Feature

The EtherChannel min-links feature is supported on [LACP](#) EtherChannels. This feature allows you to configure the minimum number of member ports that must be in the link-up state and bundled in the EtherChannel for the port channel interface to transition to the link-up state. You can use the EtherChannel min-links feature to prevent low-bandwidth LACP EtherChannels from becoming active. This feature also causes LACP EtherChannels to become inactive if they have too few active member

ports to supply your required minimum bandwidth. In addition, when LACP max-bundle values are specified in conjunction with min-links, the configuration is verified and an error message is returned if the min-links value is not compatible with (equal to or less than) the max-bundle value.

To configure the EtherChannel min-links feature, perform this task:

	Command	Purpose
Step 1	<code>Tqwwgt*eqphki+%"kpvgtthceg"rqtv/ejcppgn"itqwrapwodgt"</code>	Selects an LACP port channel interface.
Step 2	<code>Tqwwgt*eqphki/kh+%"rqtv/ejcppgn"okp/nkpmu"pwodgt"</code>	Configures the minimum number of member ports that must be in the link-up state and bundled in the EtherChannel for the port channel interface to transition to the link-up state.
Step 3	<code>Tqwwgt*eqphki/kh+%"gpf"</code>	Exits configuration mode.

**Note**

Although the EtherChannel min-links feature works correctly when configured only on one end of an EtherChannel, for best results, configure the same number of minimum links on both ends of the EtherChannel.

This example shows how to configure port channel interface 1 to be inactive if fewer than two member ports are active in the EtherChannel:

```
Tqwwgt*"eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+%"kpvgtthceg"rqtv/ejcppgn"3"
Tqwwgt*eqphki/kh+%"rqtv/ejcppgn"okp/nkpmu"4"
Tqwwgt*eqphki/kh+%"gpf"
```

Configuring LACP 1:1 Redundancy

To configure the [LACP 1:1 redundancy feature](#), perform this task:

	Command	Purpose
Step 1	<code>Tqwwgt*eqphki+%"kpvgtthceg"rqtv/ejcppgn"itqwrapwodgt"</code>	Selects an LACP port channel interface.
Step 2	<code>Tqwwgt*eqphki/kh+%"ncer"hcuv/uykvejxqgt"</code>	Enables the LACP 1:1 redundancy feature on the EtherChannel.
Step 3	<code>Tqwwgt*eqphki/kh+%"ncer"ocz/dwpfng"3"</code>	Sets the maximum number of active member ports to be one. The only value supported with LACP 1:1 redundancy is "1".
Step 4	<code>Tqwwgt*eqphki/kh+%"ncer"hcuv/uykvejxqgt"fcorgpkpi"ugeqpfu"</code>	(Optional) Enables the LACP 1:1 hot standby dampening feature for this EtherChannel. The range for the time parameter is 35 through 180 seconds.
Step 5	<code>Tqwwgt*eqphki/kh+%"gpf"</code>	Exits configuration mode.

**Note**

LACP 1:1 redundancy must be enabled at both ends of the LACP EtherChannel.

This example shows how to configure an LACP EtherChannel with 1:1 redundancy. Because Gigabit Ethernet port 5/6 is configured with a higher port priority number (and therefore a lower priority) than the default of 32768, it will be the standby port.

```
Tqwwgt% "eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+% "ncer"u{uvgo/rtkqtkv{ "55222
Tqwwgt*eqphki+% "kpvgthceg"tcpig"ikicdkvgvjgtpgv"718"/9"
Tqwwgt*eqphki/kh+% "ejcppgn/rtqvgeqn"ncer
Tqwwgt*eqphki/kh+% "ejcppgn/itqwr"3"oqfg"cevkxg"
Tqwwgt*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv"718"
Tqwwgt*eqphki/kh+% "ncer"rqtv/rtkqtkv{ "55222
Tqwwgt*eqphki+% "kpvgthceg"rqtv/ejcppgn"3"
Tqwwgt*eqphki/kh+% "ncer"hcuv/uykvejxgt"
Tqwwgt*eqphki/kh+% "ncer"ocz/dwpfng"3"
Tqwwgt*eqphki/kh+% "ncer"hcuv/uykvejxgt"fcorgpkpi"52"
Tqwwgt*eqphki/kh+% "gpf"
```

Configuring Auto Interleaved Port Priority For LACP Port Channels

To configure auto interleaved port priority for LACP on a port channel, perform this task on the port channel interface:

	Command	Purpose
Step 1	Tqwwgt*eqphki+% "kpvgthceg"rqtv/ejcppgn <i>channel-group</i>	Selects a port channel interface to configure.
Step 2	Tqwwgt*eqphki/kh+% "ncer"cevkxg/rqtv"fkuvtkdvwkqp" cwvqocvke	Configures the port channel to use interleaved port priority.
		
	Note	You need to perform a shutdown and no shutdown for interleaved port priority to be enabled.
Step 3	Tqwwgt*eqphki/kh+% "ujwvfqyp"	Disables the interface.
Step 4	Tqwwgt*eqphki/kh+% "pq"ujwvfqyp"	Enables the interface.
Step 5	Tqwwgt*eqphki/kh+% "gpf"	Exits configuration mode.
Step 6	Tqwwgt%"ujqy"gvjgtejcppgn" channel-group" rqtv/ejcppgn" Tqwwgt%"ujqy"gvjgtejcppgn" channel-group"uwooct{	Verifies the configuration.

This example shows how to configure auto interleaved port priority on a port channel:

```
Tqwwgt*eqphki+% "kpvgthceg"rqtv/ejcppgn45"
Tqwwgt*eqphki/kh+% "ncer"cevkxg/rqtv"fkuvtkdvwkqp"cwvqocvke
Rngcug"ujwvlpq"ujwv"vjg"rqtv/ejcppgn"hqt"eqphkiwtcvkqp"vq"vcmg"ghhgev"koogfkcvgn{ 0
Tqwwgt*eqphki/kh+% "ujwvfqyp"
Tqwwgt*eqphki/kh+% "pq"ujwvfqyp"

Tqwwgt*eqphki/kh+% "gpf"
```

This example shows how to verify the configuration of port channel interface 23:

```
Tqwwgt%"ujqy"twppkpi"kpvgthcegu"rqtv/ejcppgn45"
Dwknfkpi"eqphkiwtcvkqp000"

Ewttgpv"eqphkiwtcvkqp"<" :3"d{vgu"
```

```
Hnciu<"F"/"fqyp""""R"/"dwpfngf"kp"rqtv/ejcppgn"
""K"/"uvcpf/cnqpg"u"/"uwurgpfgf"
""J"/"Jqv/uvcpfd{"*NCER"qp{+"
""T"/"Nc{gt5""U"/"Nc{gt4"
""W"/"kp"wug""P"/"pqv"kp"wug."pq"ciitgicvkqp"
""h"/"hckngf"vq"cnnqecvg"ciitgicvtq"

""O"/"pqv"kp"wug."pq"ciitgicvkqp"fwg"vq"okpkowo"nkpmu"pqv"ogv"
""o"/"pqv"kp"wug."rqtv"pqv"ciitgicvgf"fwg"vq"okpkowo"nkpmu"pqv"ogv"
""w"/"wpukvcndng"hqt"dwpfnkpi"
""f"/"fghcwvn"rqtv"

""y"/"yckvkpi"vq"dq"ciitgicvgf"
Pwodgt"qh"ejcppgn/itqrwu"kp"wug<";"
Pwodgt"qh"ciitgicvtqu<"""""""""";

Itqrw"Rqtv/ejcppgn"Rtqvqeqn""Rqtvu"
////////-////////-////////-/////////////////////"
45""Rq45*TW+""NCER""Ik313143*R+""Ik313144*R+""Ik313145*J
""Ik313146*J+""Ik413139*R+""Ik41313:*R
""Ik41313;*J+""Ik413142*J+"
```



Note

The above example shows that the four bundled ports are distributed 2 per chassis and slot.

Configuring LACP Port-Channel Standalone Disable

To disable the standalone EtherChannel member port state on a port channel (see [Table 23-2 on page 23-4](#)), perform this task on the port channel interface:

	Command	Purpose
Step 1	<code>Tqvwgt*eqphki+%"kpvgtgheg"rqtv/ejcppgn channel-group</code>	Selects a port channel interface to configure.
Step 2	<code>Tqvwgt*eqphki/kh+%"rqtv/ejcppgn"uvcpfcngpg/fkucdng</code>	Disables the standalone mode on the port-channel interface.
Step 3	<code>Tqvwgt*eqphki/kh+%"gpf"</code>	Exits configuration mode.
Step 4	<code>Tqvwgt%"ujqy"gvjgtejcppgn channel-group</code> <code>Tqvwgt%"ujqy"gvjgtejcppgn channel-group</code> "fgvckn"	Verifies the configuration.

This example shows how to disable the standalone EtherChannel member port state on port channel 42:

Tqvwgt*eqphki+%**"kpvgt hceg"rqt v/ejcppgn** *channel-group*
Tqvwgt*eqphki/kh+%**"rqt v/ejcppgn"uvcpfcngpq/fkucdnq**

This example shows how to verify the configuration:

```
Tqwgvt% "ujqy"gvjgtejcppgn"64"rqtv/ejcppgn"~"kpenwfg"Uvcpfcnqpg"  
Uvcpfcnqpg"Fkucdng" "? "gpcdnfg"  
Tqwgvt% "ujqy"gvjgtejcppgn"64"fgvckn"~"kpenwfg"Uvcpfcnqpg"  
Uvcpfcnqpg"Fkucdng" "? "gpcdnfg"
```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



IEEE 802.1ak MVRP and MRP

- [Prerequisites for IEEE 802.1ak MVRP and MRP, page 24-1](#)
- [Restrictions for IEEE 802.1ak MVRP and MRP, page 24-2](#)
- [Information About IEEE 802.1ak MVRP and MRP, page 24-2](#)
- [Default Settings for IEEE 802.1ak MVRP and MRP, page 24-8](#)
- [How to Configure IEEE 802.1ak MVRP and MRP, page 24-8](#)
- [Troubleshooting the MVRP Configuration, page 24-10](#)
- [Configuration Examples for IEEE 802.1ak MVRP and MRP, page 24-11](#)



Note

- This feature appears in Cisco Feature navigator as “IEEE 802.1ak - MVRP and MRP.”
- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for IEEE 802.1ak MVRP and MRP

None.

Restrictions for IEEE 802.1ak MVRP and MRP

- In releases where CSCta96338 is not resolved, a physical port with an MVRP configuration and enable state that differs from what is configured on a port-channel interface cannot become an active member of that EtherChannel.
- In releases where CSCta96338 is resolved, a physical port with an MVRP configuration and enable state that differs from what is configured on a port-channel interface can become an active member of the EtherChannel because the physical port will use the port-channel interface MVRP configuration and enable state.
- A non-Cisco device can interoperate with a Cisco device only through 802.1Q trunks.
- MVRP runs on ports where it is enabled. VTP pruning can run on ports where MVRP is not enabled.
- MVRP can be configured on both physical interfaces and EtherChannel interfaces, but is not supported on EtherChannel member ports.
- MVRP dynamic VLAN creation is not supported when the device is running in VTP server or client mode.
- MVRP and Connectivity Fault Management (CFM) can coexist but if the module does not have enough MAC address match registers to support both protocols, the MVRP ports on those modules are put in the error-disabled state. To use the ports that have been shut down, disable MVRP on the ports, and then enter **shutdown** and **no shutdown** commands.
- 802.1X authentication and authorization takes place after the port becomes active and before the Dynamic Trunking Protocol (DTP) negotiations start prior to MVRP running on the port.
- Do not enable MVRP automatic MAC address learning on edge switches that are configured with access ports. Enable MVRP automatic MAC address learning only on core switches where all the trunk interfaces are running MVRP.
- MVRP is supported only on Layer 2 trunks. MVRP is not supported on subinterfaces.

Information About IEEE 802.1ak MVRP and MRP

- [Overview, page 24-2](#)
- [Dynamic VLAN Creation, page 24-4](#)
- [MVRP Interoperability with VTP, page 24-4](#)
- [MVRP Interoperation with Non-Cisco Devices, page 24-6](#)
- [MVRP Interoperability with Other Software Features and Protocols, page 24-6](#)


Overview

The IEEE 802.1ak Multiple VLAN Registration Protocol (MVRP) supports dynamic registration and deregistration of VLANs on ports in a VLAN bridged network. IEEE 802.1ak uses more efficient Protocol Data Units (PDUs) and protocol design to provide better performance than the Generic VLAN Registration Protocol (GARP) VLAN Registration Protocol (GVRP) and GARP Multicast Registration Protocol (GMRP) protocols.

A VLAN-bridged network usually restricts unknown unicast, multicast, and broadcast traffic to those links that the traffic uses to access the appropriate network devices. In a large network, localized topology changes can affect the service over a much larger portion of the network. IEEE 802.1ak replaces GARP with the Multiple Registration Protocol (MRP), which provides improved resource utilization and bandwidth conservation.

With the 802.1ak MRP attribute encoding scheme, MVRP only needs to send one PDU that includes the state of all 4094 VLANs on a port. MVRP also transmits Topology Change Notifications (TCNs) for individual VLANs. This is an important feature for service providers because it allows them to localize topology changes. Figure 24-1 illustrates MVRP deployed in a provider network on provider and customer bridges.

Figure 24-1 MVRP Deployed on Provider and Customer Bridges




Because most providers do not wish to filter traffic by destination MAC addresses, a pruning protocol like MVRP is important in a Metro Ethernet provider network, which often uses thousands of VLANs.

Figure 24-2 displays redundant links that are configured between the access switch and two distribution switches on the cloud. When the link with VLAN 104 fails over, MVRP needs to send only one TCN for VLAN 104. Without MVRP, an STP TCN would need to be sent out for the whole MST region (VLANs 1-1000), which could cause unnecessary network interruption.

STP sets the `tcDetected` variable to signal MVRP that MVRP must decide whether to send an MVRP TCN. MVRP can flush filtering database entries rapidly on a per-VLAN basis following a topology change because when a port receives an attribute declaration marked as new, any entries in the filtering database for that port and for that VLAN are removed.

Figure 24-2 MVRP TCN Application



Dynamic VLAN Creation

Virtual Trunking Protocol (VTP) is a Cisco proprietary protocol that distributes VLAN configuration information across multiple devices within a VTP domain. When VTP is running on MVRP-aware devices, all of the VLANs allowed on the Cisco bridged LAN segments are determined by VTP.

Only the VTP transparent mode supports MVRP dynamic VLAN creation. When dynamic VLAN creation is disabled, the MVRP trunk ports can register and propagate the VLAN messages only for existing VLANs. MVRP PDUs and MVRP messages for the nonexistent VLANs are discarded.

For a switch to be configured in full compliance with the MVRP standard, the switch VTP mode must be transparent and MVRP dynamic VLAN creation must be enabled.

MVRP Interoperability with VTP

- [Overview, page 24-5](#)
- [VTP in Transparent or Off Mode, page 24-5](#)
- [VTP in Server or Client Mode and VTP Pruning is Disabled, page 24-5](#)
- [VTP in Server or Client Mode and VTP Pruning is Enabled, page 24-5](#)

Overview

The VLAN Trunking Protocol (VTP) is a Cisco proprietary protocol that distributes VLAN configuration information across multiple devices within a VTP domain. VTP pruning is an extension of VTP. It has its own Join message that can be exchanged with VTP PDUs. VTP PDUs can be transmitted on both 802.1Q trunks and ISL trunks. A VTP-capable device is in one of the VTP modes: server, client, transparent, or off.

When VTP Pruning and MVRP are both enabled globally, MVRP runs on trunks where it is enabled and VTP Pruning runs on other trunks. MVRP or VTP pruning can be enabled on a trunk, but not both.

VTP in Transparent or Off Mode

When VTP is in transparent or off mode, VTP pruning is not supported and VTP PDUs are not processed.

When a port receives an MVRP join message for a VLAN, the port transmits broadcast, multicast, and unknown unicast frames in that VLAN and adds the traffic definition to the MRP Attribute Propagation (MAP) port configured for that VLAN. The mapping is removed when the VLAN is no longer registered on the port.

For each interface that is forwarding in each VLAN, MVRP issues a join request to each MRP Attribute Declaration (MAD) instance and an MVRP Join message is sent out on each corresponding MVRP port.

MVRP dynamic VLAN creation can be enabled in VTP transparent or off mode. If it is enabled and the VLAN registered by a join message does not exist in the VLAN database in the device, then the VLAN will be created.

VTP in Server or Client Mode and VTP Pruning is Disabled

MVRP functions like VTP in transparent or off mode, except that MVRP dynamic VLAN creation is not allowed.

VTP in Server or Client Mode and VTP Pruning is Enabled

MVRP and VTP with pruning disabled can be supported on the same port and these two protocols need to communicate and exchange pruning information.

When VTP receives a VTP join message on a VTP trunk, MVRP is notified so that join request can be posted to the MVRP port MAD instances, and MVRP join messages are out on the MVRP ports to the MVRP network.

When VTP pruning removes a VLAN from a VTP trunk, MVRP sends a leave request to all the MAD instances and the MAD instances send a leave or empty message from the MVRP ports to indicate that the VLAN is not configured on the device.

When an MVRP port received an MVRP join message, MVRP propagates the event to other MVRP ports in the same MAP context, and notifies VTP so that VTP pruning can send a VTP join message from the VTP trunk ports.

If MVRP learns that a VLAN is no longer declared by the neighboring devices, MVRP sends a withdrawal event to VTP and then VTP pruning verifies that it should continue sending VTP join messages.

For VLANs that are configured as VTP pruning non-eligible on the VTP trunks, the VTP pruning state variables are set to joined for the VLANs. MVRP join requests are sent to those VLANs through the MVRP ports.

MVRP Interoperation with Non-Cisco Devices

Non-Cisco devices can interoperate with a Cisco device only through 802.1q trunks.

MVRP Interoperability with Other Software Features and Protocols

- [802.1x and Port Security, page 24-6](#)
- [DTP, page 24-6](#)
- [EtherChannel, page 24-7](#)
- [Flex Links, page 24-7](#)
- [High Availability, page 24-7](#)
- [ISSU and eFSU, page 24-7](#)
- [L2PT, page 24-7](#)
- [SPAN, page 24-7](#)
- [Unknown Unicast and Multicast Flood Control, page 24-7](#)
- [STP, page 24-7](#)
- [UDLR, page 24-7](#)
- [VLANs with MVRP, page 24-8](#)

802.1x and Port Security

802.1x authenticates and authorizes a port after it transitions to the link-up state, but before DTP negotiation occurs and MVRP runs on a port. Port security works independently of MVRP.



Note

When MVRP is globally enabled, the MVRP MAC address auto detect and provision feature is disabled by default (**mvrp mac-learning auto**). In some situations, MVRP MAC address auto detect and provision can disable MAC address learning and prevent correct port security operation. For example, on ports where port security is configured, when the number of streams exceeds the configured maximum number of MAC addresses, no port security violation occurs because MAC address learning is disabled, which prevents updates to port security about the streams coming into the port. To avoid incorrect port security operation, use caution when enabling the MVRP MAC address auto detect and provision feature on ports where port security is configured.

DTP

DTP negotiation occurs after ports transition to the link-up state and before transition to the forwarding state. If MVRP is administratively enabled globally and enabled on a port, it becomes operational when the port starts trunking.

EtherChannel

An EtherChannel port-channel interface can be configured as an MVRP participant. The EtherChannel member ports cannot be MVRP participants. MVRP learns the STP state of EtherChannel port-channel interfaces. The MAP context applies to the EtherChannel port-channel interfaces, but not to the EtherChannel member ports.

Flex Links

MVRP declares VLANs on STP forwarding ports but not on ports in the blocking state. On flex links ports, MVRP declares VLANs on the active ports but not on the standby ports. When a standby port takes over and an active port transitions to the link-down state, MVRP declares the VLANs on the newly active port.

High Availability

State Switchover (SSO) and ISSU supports MVRP.

ISSU and eFSU

Enhanced Fast Software Upgrade (EFSU) is an enhanced software upgrade procedure. MVRP is serviced by the ISSU client identified as `ISSU_MVRP_CLIENT_ID`.

L2PT

Layer 2 Protocol Tunneling (L2PT) does not support MVRP PDUs on 802.1Q tunnel ports.

SPAN

MVRP ports can be configured as either Switched Port Analyzer (SPAN) sources or destinations.

Unknown Unicast and Multicast Flood Control

MVRP and the Unknown Unicast and Multicast Flood Control feature, configured with the **switchport block** command, cannot be configured on the same port.

STP

An STP mode change causes forwarding ports to leave the forwarding state until STP reconverges in the newly configured mode. The reconvergence might cause an MVRP topology change because join messages might be received on different forwarding ports, and leave timers might expire on other ports.

UDLR

MVRP and unidirectional link routing (UDLR) cannot be configured on the same port.

VLANs with MVRP

- [VLAN Translation, page 24-8](#)
- [802.1Q Native VLAN Tagging, page 24-8](#)
- [Private VLANs, page 24-8](#)

VLAN Translation

VLAN translation and MVRP cannot be configured on the same port.

802.1Q Native VLAN Tagging

Other MVRP participants might not be able to accept tagged MVRP PDUs in the 802.1Q native VLAN. Compatibility between MVRP and 802.1Q native VLAN tagging depends on the specific network configuration.

Private VLANs

Private VLAN ports cannot support MVRP.

Default Settings for IEEE 802.1ak MVRP and MRP

None.

How to Configure IEEE 802.1ak MVRP and MRP

- [Enabling MVRP, page 24-8](#)
- [Enabling Automatic Detection of MAC Addresses, page 24-9](#)
- [Enabling MVRP Dynamic VLAN Creation, page 24-9](#)
- [Changing the MVRP Registrar State, page 24-10](#)

Enabling MVRP

MVRP must be enabled globally and on trunk ports. To enable MVRP, perform this task:

	Command or Action	Purpose
Step 1	<code>Tqwgvt@"gpcdng"</code>	Enables privileged EXEC mode (enter your password if prompted).
Step 2	<code>Tqwgvt%"eqphkiwtg"vgtokpcn"</code>	Enters global configuration mode.
Step 3	<code>Tqwgvt*eqphki+%"oxtr inqdcn"</code>	Globally enables MVRP.

	Command or Action	Purpose
Step 4	Tqwvgt*eqphki+% kpvgthceg "v{rg"pwodgt"	Specifies a trunk port and enters interface configuration mode.
Step 5	Tqwvgt*eqphki/kh+% oxtr "	Enables MVRP on the interface. Note If MVRP is not successfully enabled on the port, the port is put in the errdisabled state. Enter the no mvrp command on the interface or the no mvrp global command to clear the errdisabled state.

This example shows how to enable MVRP globally and on an interface:

```
Tqwvgt@"gpcdng"
Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+%oxtr"inqdcn"
Tqwvgt*eqphki+%kpvgthceg"HcuvGvjgtpgv"413"
Tqwvgt*eqphki/kh+%oxtr"
```

Enabling Automatic Detection of MAC Addresses

MVRP automatic detection of MAC addresses is disabled by default. To enable MVRP automatic detection of MAC addresses on VLANs, perform this task:

	Command or Action	Purpose
Step 1	Tqwvgt@"gpcdng"	Enables privileged EXEC mode (enter your password if prompted).
Step 2	Tqwvgt%"eqphkiwtg"vgtokpcn"	Enters global configuration mode.
Step 3	Tqwvgt*eqphki+% oxtr oce-ngctpkpi cwvq "	Enables MAC address learning.

This example shows how to enable automatic MAC address learning:

```
Tqwvgt@"gpcdng"
Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+%oxtr"oce/ngctpkpi"cwvq"
```

Enabling MVRP Dynamic VLAN Creation

To enable MVRP dynamic VLAN creation, perform this task:

	Command or Action	Purpose
Step 1	Tqwvgt@"gpcdng"	Enables privileged EXEC mode (enter your password if prompted).
Step 2	Tqwvgt%"eqphkiwtg"vgtokpcn"	Enters global configuration mode.
Step 3	Tqwvgt*eqphki+% xvr "oqfg"vtcpurctgpv"	Sets VTP mode to transparent. Note Required for MVRP dynamic VLAN creation.
Step 4	Tqwvgt*eqphki+% oxtr "xnep"etgcvkqp"	Enables MVRP dynamic VLAN creation.

This example shows how to enable MVRP dynamic VLAN creation:

```
Tqwgvt@"gpcdng"
Tqwgvt%"eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+%"xvr"oqfg"vtcpurctgpy"
Tqwgvt*eqphki+%"oxtr"xncp"etgcvq"
```

Changing the MVRP Registrar State

The MRP protocol allows one participant per application in an end station, and one per application per port in a bridge. To set the MVRP registrar state, perform this task:

	Command or Action	Purpose
Step 1	Tqwgvt@"gpcdng"	Enables privileged EXEC mode (enter your password if prompted).
Step 2	Tqwgvt%"eqphkiwtg"vgtokpcn"	Enters global configuration mode.
Step 3	Tqwgvt*eqphki+%"kpvgtthceg"v{rg"pwodgt"	Specifies and interface and enters interface configuration mode.
Step 4	Tqwgvt*eqphki/kh+%"oxtr"tgikuvtcvkqp"]pqtocn"~"hkzgf"~"hgtdkffgp_"	Registers MVRP with the MAD instance.

This example shows how to set the MVRP registrar state to normal:

```
Tqwgvt@"gpcdng"
Tqwgvt%"eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+%"kpvgtthceg"HcuvGvjgtpgv"413"
Tqwgvt*eqphki/kh+%"oxtr"tgikuvtcvkqp"]pqtocn"
```

Troubleshooting the MVRP Configuration

Use the **show mvrp summary** and **show mvrp interface** commands to display configuration information and interface states, and the **debug mvrp** command to enable all or a limited set of output messages related to an interface.

To troubleshoot the MVRP configuration, perform this task:

	Command or Action	Purpose
Step 1	Tqwgvt@"gpcdng"	Enables privileged EXEC mode (enter your password if prompted).
Step 2	Tqwgvt%"ujqy"oxtr"uwooct{ "	Displays the MVRP configuration.
Step 3	Tqwgvt%"ujqy"oxtr"kpvgtthceg"interface-type"rgtv1ungv"	Displays the MVRP interface states for the specified interface.
Step 4	Tqwgvt% fgdwi"oxtr"	Displays MVRP debugging information.
Step 5	Tqwgvt%"engct"oxtr"uvcvkuvkeu"	Clears MVRP statistics on all interfaces.

The following is sample output from the **show mvrp summary** command. This command can be used to display the MVRP configuration at the device level.

```
Tqwgvt%"ujqy"oxtr"uwooct{
```

```

OxTR"inqdcn"uvcvg" "<"gpcdnfg
OxTR"XNCP"etgcvkqp" "<"fkucdnfg
XNCPu"etgcvgf"xkc"OxTR" "<"42/67."5223/5272
Ngctpkpi"fkucdnfg"qp"XNCPu" "<"pppg

```

The following is sample output from the **show mvrp interface** command. This command can be used to display MVRP interface details of the administrative and operational MVRP states of all or one particular trunk port in the device.

```

Tqvwgt%"ujqy"oxtr"kpvgthceg

Rqtv" ""Uvcvwu""Tgikuvttc"Uvcvg
Hc513" ""qhh""pqtoen

Rqtv" ""Lqkp"Vkogqvw""Ngcxg"Vkogqvw""Ngcxgcnn"Vkogqvw
Hc513" ""423""822""922""3222

Rqtv" ""Xncpu"fgentgf
Hc513" ""pppg

Rqtv" ""Xncpu"tgikuvgtgf
Hc513" ""pppg

Rqtv" ""Xncpu"tgikuvgtgf"cpf"kp"Urcppkpi"Vtgg"Hqtyctfkpi"Uvcvg
Hc513" ""pppg

```

Configuration Examples for IEEE 802.1ak MVRP and MRP

- [Enabling MVRP, page 24-11](#)
- [Enabling MVRP Automatic Detection of MAC Addresses, page 24-11](#)
- [Enabling Dynamic VLAN Creation, page 24-12](#)
- [Changing the MVRP Registrar State, page 24-12](#)

Enabling MVRP

The following example shows how to enable MVRP:

```

Tqvwgt@"gpcdnfg
Tqvwgt%"eqphkiwtg"vgtokpcn
Tqvwgt*eqphki+%"oxtr"inqdcn
Tqvwgt*eqphki+%"kpvgthceg"hcuvgvjgtpgv413
Tqvwgt*eqphki/kh+%"oxtr"

```

Enabling MVRP Automatic Detection of MAC Addresses

The following example shows how to enable MAC address learning:

```

Tqvwgt@"gpcdnfg
Tqvwgt%"eqphkiwtg"vgtokpcn
Tqvwgt*eqphki+%"oxtr"oce/ngctpkpi"cwvg

```

Enabling Dynamic VLAN Creation

The following example shows how to enable dynamic VLAN creation:

```
Tqwgvt@"gpcdng
Tqwgvt%"eqphkiwtg"vgtokpcn
Tqwgvt*eqphki+% xvr"oqfg"vtcpurctgpv
Tqwgvt*eqphki+% "oxtr"xncp"etgcvg
```

Changing the MVRP Registrar State

The following example shows how to change the MVRP registrar state:

```
Tqwgvt@"gpcdng
Tqwgvt%"eqphkiwtg"vgtokpcn
Tqwgvt*eqphki+% "oxtr"tgikuvtcvkqp"pqtocn
```



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



VLAN Trunking Protocol (VTP)

- [Prerequisites for VTP, page 25-1](#)
- [Restrictions for VTP, page 25-1](#)
- [Information About VTP, page 25-2](#)
- [Default Settings for VTP, page 25-9](#)
- [How to Configure VTP, page 25-10](#)



Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:
http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for VTP

None.

Restrictions for VTP

- Supervisor engine redundancy does not support nondefault VLAN data filenames or locations. Do not enter the **vtp file file_name** command on a switch that has a redundant supervisor engine.
- Before installing a redundant supervisor engine, enter the **no vtp file** command to return to the default configuration.

- All network devices in a VTP domain must run the same VTP version.
- You must configure a password on each network device in the management domain when in secure mode.

**Caution**

If you configure VTP in secure mode, the management domain will not function properly if you do not assign a management domain password to each network device in the domain.

- A VTP version 2-capable network device can operate in the same VTP domain as a network device that runs VTP version 1 if VTP version 2 is disabled on the VTP version 2-capable network device (VTP version 2 is disabled by default).
- Do not enable VTP version 2 on a network device unless all of the network devices in the same VTP domain are version 2-capable. When you enable VTP version 2 on a network device, all of the version 2-capable network devices in the domain enable VTP version 2.
- In a Token Ring environment, you must enable VTP version 2 for Token Ring VLAN switching to function properly.
- When you enable or disable VTP pruning on a VTP server, VTP pruning for the entire management domain is enabled or disabled.
- The pruning-eligibility configuration applies globally to all trunks on the switch. You cannot configure pruning eligibility separately for each trunk.
- When you configure VLANs as pruning eligible or pruning ineligible, pruning eligibility for those VLANs is affected on that switch only, not on all network devices in the VTP domain.
- VTP version 1 and VTP version 2 do not propagate configuration information for extended-range VLANs (VLAN numbers 1006 to 4094). You must configure extended-range VLANs manually on each network device.
- VTP version 3 supports extended-range VLANs (VLAN numbers 1006 to 4094). If you convert from VTP version 3 to VTP version 2, the VLANs in the range 1006 to 4094 are removed from VTP control.
- VTP version 3 supports propagation of any database in a domain by allowing you to configure a primary and secondary server.
- The network administrator has to manually configure VTP version 3 on the switches that need to run VTP version 3.
- VTP version 3 is not supported on private VLAN (PVLAN) ports.
- Prior to configuring VTP version 3, you must ensure that the **spanning-tree extend system-id** command has been enabled.
- If there is insufficient DRAM available for use by VTP, the VTP mode changes to transparent.
- Network devices in VTP transparent mode do not send VTP Join messages. On trunk connections to network devices in VTP transparent mode, configure the VLANs that are used by the transparent-mode network devices or that need to be carried across trunks as pruning ineligible. For information about configuring prune eligibility, see the [“Configuring the List of Prune-Eligible VLANs” section on page 21-12](#).

Information About VTP

- [VTP Overview, page 25-3](#)
- [VTP Domains, page 25-3](#)

- [VTP Modes, page 25-4](#)
- [VTP Advertisements, page 25-4](#)
- [VTP Authentication, page 25-5](#)
- [VTP Version 2, page 25-5](#)
- [VTP Version 3, page 25-6](#)
- [VTP Pruning, page 25-7](#)
- [VLAN Interaction, page 25-9](#)

**Note**

For complete information on configuring VLANs, see [Chapter 26, “Virtual Local Area Networks \(VLANs\).”](#)

VTP Overview

VTP is a Layer 2 messaging protocol that maintains VLAN configuration consistency by managing the addition, deletion, and renaming of VLANs within a VTP domain. A VTP domain (also called a VLAN management domain) is made up of one or more network devices that share the same VTP domain name and that are interconnected with trunks. VTP minimizes misconfigurations and configuration inconsistencies that can result in a number of problems, such as duplicate VLAN names, incorrect VLAN-type specifications, and security violations. Before you create VLANs, you must decide whether to use VTP in your network. With VTP, you can make configuration changes centrally on one or more network devices and have those changes automatically communicated to all the other network devices in the network.

VTP Domains

A VTP domain (also called a VLAN management domain) is made up of one or more interconnected network devices that share the same VTP domain name. A network device can be configured to be in one and only one VTP domain. You make global VLAN configuration changes for the domain using either the command-line interface (CLI) or Simple Network Management Protocol (SNMP).

VTP server mode is the default and the switch is in the no-management domain state until it receives an advertisement for a domain over a trunk link or you configure a management domain.

If the switch receives a VTP advertisement over a trunk link, it inherits the management domain name and the VTP configuration revision number. The switch ignores advertisements with a different management domain name or an earlier configuration revision number.

If you configure the switch as VTP transparent, you can create and modify VLANs but the changes affect only the individual switch. The valid VLAN ranges are as follows:

- VTP version 1 and version 2 support VLANs 1 to 1000 only.
- VTP version 3 supports the entire VLAN range (VLANs 1 to 4094).
- The pruning of VLANs still applies to VLANs 1 to 1000 only.
- Extended-range VLANs are supported only in VTP version 3. If converting from VTP version 3 to VTP version 2, VLANs in the range 1006 to 4094 are removed from VTP control.

By default, all devices come up as secondary servers. You can enter the **vtp primary** privileged EXEC mode command to specify a primary server.

When using VTP version 1 and version 2, a VTP server is used to back up the database to the NVRAM and allows you to change the database information.

In VTP version 3, there is a VTP-primary server and a VTP-secondary server. A primary server allows you to alter the database information and the database updates sent out are honored by all the devices in the system. A secondary server can only back up the updated VTP configuration received from the primary server in the NVRAMs. The status of the primary and secondary servers is a runtime status and is not configurable.

VTP maps VLANs dynamically across multiple LAN types with unique names and internal index associations. Mapping eliminates excessive device administration required from network administrators.

VTP Modes

You can configure any one of these VTP modes:

- **Server**—In VTP server mode, you can create, modify, and delete VLANs and specify other configuration parameters (such as VTP version and VTP pruning) for the entire VTP domain. VTP servers advertise their VLAN configuration to other network devices in the same VTP domain and synchronize their VLAN configuration with other network devices based on advertisements received over trunk links. VTP server is the default mode.
- **Client**—VTP clients behave the same way as VTP servers, but you cannot create, change, or delete VLANs on a VTP client.
- **Transparent**—VTP transparent network devices do not participate in VTP. A VTP transparent network device does not advertise its VLAN configuration and does not synchronize its VLAN configuration based on received advertisements. However, in VTP version 2, a transparent network device will forward received VTP advertisements from its trunking LAN ports. In VTP version 3, a transparent network device is specific to an instance.
- **Off**—In VTP off mode, a network device functions in the same manner as a VTP transparent device except that it does not forward VTP advertisements.



Note

The VTP server mode automatically changes from VTP server mode to VTP client mode if the switch detects a failure while writing configuration to NVRAM. If this happens, the switch cannot be returned to VTP server mode until the NVRAM is functioning.

VTP Advertisements

Each network device in the VTP domain sends periodic advertisements out each trunking LAN port to a reserved multicast address. VTP advertisements are received by neighboring network devices, which update their VTP and VLAN configurations as necessary.

The following global configuration information is distributed in VTP version 1 and version 2 advertisements:

- VLAN IDs.
- Emulated LAN names (for ATM LANE).
- 802.10 SAID values (FDDI).
- VTP domain name.

- VTP configuration revision number.
- VLAN configuration, including the maximum transmission unit (MTU) size for each VLAN.
- Frame format.

In VTP version 3, the information distributed in VTP version 1 and version 2 advertisements are supported, as well as the following information:

- A primary server ID.
- An instance number.
- A start index.
- An advertisement request is sent by a Client or a Server in these situations:
 - On a trunk coming up on a switch with an invalid database.
 - On all trunks when the database of a switch becomes invalid as a result of a configuration change or a takeover message.
 - On a specific trunk where a superior database has been advertised.
- VTP version 3 adds the following fields to the subset advertisement request:
 - A primary server ID.
 - An instance number.
 - A window size.
 - A start index.

VTP Authentication

When VTP authentication is not configured, the secret that is used to validate the received VTP updates is visible in plain text in the **show** commands and the NVRAM file, `const_nvram:vlan.dat`. In the event that a device in a VTP domain is compromised, the administrator must change the VTP secret across all the devices in the VTP domain.

With VTP version 3, you can configure the authentication password to be hidden using the **vtp password** command. When you configure the authentication password to be hidden, it does not appear in plain text in the configuration. Instead, the secret associated with the password is saved in hexadecimal format in the running configuration. The *password-string* argument is an ASCII string from 8 to 64 characters identifying the administrative domain for the device.

VTP Version 2

VTP version 2 supports the following features not supported in version 1:

- Token Ring support—VTP version 2 supports Token Ring LAN switching and VLANs (Token Ring Bridge Relay Function [TrBRF] and Token Ring Concentrator Relay Function [TrCRF]). For more information about Token Ring VLANs, see the [“Information About VLANs” section on page 26-2](#).
- Unrecognized Type-Length-Value (TLV) Support—A VTP server or client propagates configuration changes to its other trunks, even for TLVs that it is not able to parse. The unrecognized TLV is saved in NVRAM.

- **Version-Dependent Transparent Mode**—In VTP version 1, a VTP transparent network device inspects VTP messages for the domain name and version and forwards a message only if the version and domain name match. Because only one domain is supported, VTP version 2 forwards VTP messages in transparent mode without checking the version.
- **Consistency Checks**—In VTP version 2, VLAN consistency checks (such as VLAN names and values) are performed only when you enter new information through the CLI or SNMP. Consistency checks are not performed when new information is obtained from a VTP message, or when information is read from NVRAM. If the digest on a received VTP message is correct, its information is accepted without consistency checks.

VTP Version 3

VTP version 3 supports all the features in version 1 and version 2. VTP version 3 also supports the following features not supported in version 1 and version 2:

- **Enhanced authentication**—In VTP version 3, you can configure the authentication password to be hidden using the **vtp password** command. When you configure the authentication password to be hidden, it does not appear in plain text in the configuration. Instead, the secret associated with the password is saved in hexadecimal format in the running configuration. The *password-string* argument is an ASCII string from 8 to 64 characters identifying the administrative domain for the device.

The **hidden** and **secret** keywords for VTP password are supported only in VTP version 3. If converting to VTP version 2 from VTP version 3, you must remove the **hidden** or **secret** keyword prior to the conversion.
- **Support for extended range VLAN database propagation**—VTP version 1 and version 2 support VLANs 1 to 1000 only. In VTP version 3, the entire VLAN range is supported (VLANs 1 to 4094). The pruning of VLANs still applies to VLANs 1 to 1000 only. Extended-range VLANs are supported in VTP version 3 only. Private VLANs are supported in VTP version 3. If you convert from VTP version 3 to VTP version 2, the VLANs in the range 1006 to 4094 are removed from VTP control.
- **VLANs 1002 to 1005 are reserved VLANs** in VTP version 1, version 2, and version 3.
- **Support for propagation of any database in a domain**—In VTP version 1 and version 2, a VTP server is used to back up the database to the NVRAM and allows you to change the database information.



Note

VTP version 3 supports Multiple Spanning Tree (802.1s) (MST) database propagation separate from the VLAN database only. In the MST database propagation, there is a VTP primary server and a VTP econdary server. A primary server allows you to alter the database information, and the database updates sent out are honored by all the devices in the system. A secondary server can only back up the updated VTP configuration received from the primary server in the NVRAMs. The status of the primary and secondary servers is a runtime status and is not configurable.

By default, all devices come up as secondary servers. You can enter the **vtp primary** privileged EXEC mode command to specify a primary server.

The primary-server status is needed only when database changes have to be performed and is obtained when the administrator issues a takeover message in the domain. The primary-server status is lost when you reload, switch over, or the domain parameters change. The secondary servers back up the configuration and continue to propagate the database. You can have a working VTP domain without any primary servers. Primary and secondary servers may exist on an instance in the domain.

In VTP version 3, there is no longer a restriction to propagate only VLAN database information. You can use VTP version 3 to propagate any database information across the VTP domain. A separate instance of the protocol is running for each application that uses VTP.

Two VTP version 3 regions can only communicate over a VTP version 1 or VTP version 2 region in transparent mode.

- CLI to turn off/on VTP on a per-trunk basis—You can enable VTP on a per-trunk basis using the **vtp** interface configuration mode command. You can disable VTP on a per-trunk basis using the **no** form of this command. When you disable VTP on the trunking port, all the VTP instances for that port are disabled. You will not be provided with the option of setting VTP to OFF for the MST database and ON for the VLAN database.

VTP on a global basis—When you set VTP mode to OFF globally, this applies to all the trunking ports in the system. Unlike the per-port configuration, you can specify the OFF option on a per-VTP instance basis. For example, the system could be configured as VTP-server for the VLAN database and as VTP-off for the MST database. In this case, VLAN databases are propagated by VTP, MST updates are sent out on the trunk ports in the system, and the MST updates received by the system are discarded.

VTP Pruning

VTP pruning enhances network bandwidth use by reducing unnecessary flooded traffic, such as broadcast, multicast, unknown, and flooded unicast packets. VTP pruning increases available bandwidth by restricting flooded traffic to those trunk links that the traffic must use to access the appropriate network devices. By default, VTP pruning is disabled.

In VTP versions 1 and 2, when you enable or disable pruning, it is propagated to the entire domain and accepted by all the devices in that domain. In VTP version 3, the domain administrator must manually enable or disable VTP pruning explicitly on each device.

For VTP pruning to be effective, all devices in the management domain must support VTP pruning. On devices that do not support VTP pruning, you must manually configure the VLANs allowed on trunks.

[Figure 25-1](#) shows a switched network without VTP pruning enabled. Interface 1 on network Switch 1 and port 2 on Switch 4 are assigned to the Red VLAN. A broadcast is sent from the host connected to Switch 1. Switch 1 floods the broadcast, and every network device in the network receives it, even though Switches 3, 5, and 6 have no ports in the Red VLAN.

You enable pruning globally on the switch (see the [“Enabling VTP Pruning”](#) section on page 25-12). You configure pruning on Layer 2 trunking LAN ports (see the [“Configuring a Layer 2 Switching Port as a Trunk”](#) section on page 21-8).



Figure 25-1 *Flooding Traffic without VTP Pruning*

Figure 25-2 shows the same switched network with VTP pruning enabled. The broadcast traffic from Switch 1 is not forwarded to Switches 3, 5, and 6 because traffic for the Red VLAN has been pruned on the links indicated (port 5 on Switch 2 and port 4 on Switch 4).

Figure 25-2 *Flooding Traffic with VTP Pruning*

Enabling VTP pruning on a VTP server enables pruning for the entire management domain. VTP pruning takes effect several seconds after you enable it. By default, VLANs 2 through 1000 are pruning eligible. VTP pruning does not prune traffic from pruning-ineligible VLANs. VLAN 1 is always pruning ineligible; traffic from VLAN 1 cannot be pruned.

To configure VTP pruning on a trunking LAN port, use the **switchport trunk pruning vlan** command (see the “[Configuring a Layer 2 Switching Port as a Trunk](#)” section on page 21-8). VTP pruning operates when a LAN port is trunking. You can set VLAN pruning eligibility when VTP pruning is enabled or disabled for the VTP domain, when any given VLAN exists or not, and when the LAN port is currently trunking or not.

VLAN Interaction

This section describes the VLAN interaction between devices with different VTP versions:

- [Interaction Between VTP Version 3 and VTP Version 2 Devices, page 25-9](#)
- [Interaction Between VTP Version 3 and VTP Version 1 Devices, page 25-9](#)

Interaction Between VTP Version 3 and VTP Version 2 Devices

When a VTP version 3 device on a trunk port receives messages from a VTP version 2 device, the VTP version 3 device sends a scaled-down version of the VLAN database on that particular trunk in a VTP version 2 format. A VTP version 3 device does not send out VTP version 2-formatted packets on a trunk port unless it first receives VTP version 2 packets on that trunk. If the VTP version 3 device does not receive VTP version 2 packets for an interval of time on the trunk port, the VTP version 3 device stops transmitting VTP version 2 packets on that trunk port.

Even when a VTP version 3 device detects a VTP version 2 device on a trunk port, the VTP version 3 device continues to send VTP version 3 packets in addition to VTP version 2 packets, to allow two kinds of neighbors to coexist on the trunk. VTP version 3 sends VTP version 3 and VTP version 2 updates on VTP version 2-detected trunks.

A VTP version 3 device does not accept configuration from a VTP version 2 (or VTP version 1) device.

Unlike in VTP version 2, when you configure the VTP version to be version 3, version 3 does not configure all the VTP version 3-capable devices in the domain to start behaving as VTP version 3 systems.

Interaction Between VTP Version 3 and VTP Version 1 Devices

When a VTP version 1 device that is capable of VTP version 2 or VTP version 3 receives a VTP version 3 packet, it will be configured as a VTP version 2 device if VTP version 2 conflicts do not exist.

VTP version 1-only capable devices cannot interoperate with VTP version 3 devices.

Default Settings for VTP

Feature	Default Value
VTP domain name	Null
VTP version 1 and version 2 mode	Server
VTP version 3 mode	The VTP version 3 VLAN database mode is the same as the VLAN database mode in VTP version 1 or 2 after the conversion from VTP version 1 or 2 to VTP version 3. For example, the VTP version 1 or 2 VLAN database mode is carried over to VTP version 3 VLAN database mode.
MST database mode	Transparent
VTP version 3 server type	Secondary
VTP version 2 state	Version 2 is disabled

Feature	Default Value
VTP password	None
VTP pruning	Disabled

How to Configure VTP

- [Configuring VTP Global Parameters, page 25-10](#)
- [Configuring the VTP Mode, page 25-15](#)
- [Configuring VTP Mode on a Per-Port Basis, page 25-16](#)
- [Displaying VTP Statistics, page 25-17](#)

Configuring VTP Global Parameters

- [Configuring VTP Version 1 and Version 2 Passwords, page 25-10](#)
- [Configuring VTP Version 3 Password, page 25-11](#)
- [Enabling VTP Pruning, page 25-12](#)
- [Enabling VTP Version 2, page 25-13](#)
- [Enabling VTP Version 3, page 25-13](#)



Note

You can enter the VTP global parameters in either global configuration mode or in EXEC mode.

Configuring VTP Version 1 and Version 2 Passwords

To configure the VTP version 1 and version 2 global parameters, perform this task:

Command	Purpose
<code>Tqwgvt*eqphki+%xvr"rcuuyqtf"<i>password-string</i></code>	Sets a password, which can be from 8 to 64 characters long, for the VTP domain.
<code>Tqwgvt*eqphki+%pq"xvr"rcuuyqtf"</code>	Clears the password.

This example shows one way to configure a VTP password in global configuration mode:

```
Tqwgvt%eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+%xvr"rcuuyqtf"YCVGT
Ugvvkpi"fgxkeg"XNCP"fcvdcug"rcuuyqtf"vq"YCVGT0
Tqwgvt%
```

This example shows how to configure a VTP password in EXEC mode:

```
Tqwgvt%xvr"rcuuyqtf"YCVGT
Ugvvkpi"fgxkeg"XNCP"fcvdcug"rcuuyqtf"vq"YCVGT0
Tqwgvt%
```



Note

The password is not stored in the running-config file.

Configuring VTP Version 3 Password

To configure the VTP version 3 password, perform this task:

Command	Purpose
<code>Tqvwgt*eqphki+%"xvr"rcuuyqtf"password-string"]jkffgp"</code> <code>~"ugetgv_</code>	Configures a password, which can be from 8 to 64 characters long or in 32-digit hexadecimal format, for the VTP domain. Note When entering the secret keyword, the <i>password-string</i> must be entered in 32-digit hexadecimal format.
<code>Tqvwgt*eqphki+%"pq"xvr"rcuuyqtf"</code>	Clears the password.

This example shows one way to configure a VTP password in global configuration mode:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+%"xvr"rcuuyqtf"ycvgt"
Ugvvkpi"fgxkeg"XVR"rcuuyqtf"vq"ycvgt0
Tqvwgt%
```



Note

If you configure a VTP password in EXEC mode, the password is not stored in the running-config file.

This example shows one way to configure the password with a hidden key saved in hexadecimal format in the running configuration:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+%"xvr"rcuuyqtf":4436862E7F;2:8:D8C2F:325879C943"jkffgp
Ugvvkpi"fgxkeg"XVR"rcuuyqtf
Tqvwgt%
```

This example shows how you configure the password secret key in hexadecimal format:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+%"xvr"rcuuyqtf"522H282C4D2823257523242329232423"ugetgv
Ugvvkpi"fgxkeg"XVR"rcuuyqtf
Tqvwgt%
```

Configuring VTP Version 3 Server Type

To specify a primary server, perform this task:

Command	Purpose
<code>Tqvwgt%"xvr"rtkocf{ [xncp ouv] [hqteg]</code>	Configure this device as the primary server.

The **vtp primary** command does not have a **no** form. To return to the secondary server status, one of the following conditions must be met:

- System reload.
- Switchover between redundant supervisors.
- Takeover from another server.

- ```
Tqvwgt%"xvr"rtkoc{ "ouv"hqteg
Gpvg{"XVR"rcuuyqt f< "ycvgt3
Vjku"uykvej "ku"dgeqokpi "Rtkoc{ "ugtxtg" hgt "ouv"hgcvwtg"kp"vjg"XVR"fgockp
XVR"Fvcducg"Egph"Yykvej "KF"" "" "" "" "Rtkoc{ "Ugtxtg"Txkkukqp"U{uvgo"Pcog"
/////////////////////////////////////
XNCPFD"" "" "" "" [gu]"22f2022d:03622?22f2022d:03622"3"" "" "" "" "uvr9"
Fq{qw"ycpv"vq"eqpvkpwg"*{1p+"} p_A"{
Tawvat%
```

This example shows how to verify the configuration:

```
Tqwwgt% "ujqy"xvr"uvcvwu"~"kpenwfg"Rtwpkpi
XVR"Rtwpkpi"Oqfg<"Gpcdnfg
Tqwwgt%
```

For information about configuring prune eligibility, see the [“Configuring the List of Prune-Eligible VLANs”](#) section on page 21-12.

## Enabling VTP Version 2

VTP version 2 is disabled by default on VTP version 2-capable network devices. When you enable VTP version 2 on a network device, every VTP version 2-capable network device in the VTP domain enables version 2.



### Caution

VTP version 1 and VTP version 2 are not interoperable on network devices in the same VTP domain. Every network device in the VTP domain must use the same VTP version. Do not enable VTP version 2 unless every network device in the VTP domain supports version 2.



### Note

In a Token Ring environment, you must enable VTP version 2 for Token Ring VLAN switching to function properly on devices that support Token Ring interfaces.

To enable VTP version 2, perform this task:

| Command                           | Purpose                |
|-----------------------------------|------------------------|
| Tqwwgt *eqphki+% "xvr"xgtukqp 4 " | Enables VTP version 2. |

This example shows one way to enable VTP version 2:

```
Tqwwgt% "eqphkiwtg"vgtokpcn"
Tqwwgt *eqphki+% "xvr"xgtukqp 4 "
X4 "oqfg"gpcdnfg0
Tqwwgt *eqphki+% "
```

This example shows how to enable VTP version 2 with any release:

```
Tqwwgt% "xvr"xgtukqp 4 "
X4 "oqfg"gpcdnfg0
Tqwwgt%
```

This example shows how to verify the configuration:

```
Tqwwgt% "ujqy"xvr"uvcvwu"~"kpenwfg"X4 "
XVR"X4 "Oqfg<"Gpcdnfg
Tqwwgt%
```

## Enabling VTP Version 3

VTP version 3 is disabled by default. You can enable version 3 in global configuration mode only. The network administrator has to manually configure VTP version 3 on the switches that need to run VTP version 3.

**Note**

Prior to configuring VTP version 3, you must ensure that the **spanning-tree extend system-id** command has been enabled.

**Caution**

In VTP version 3, both the primary and secondary servers may exist on an instance in the domain.

To enable VTP version 3, perform this task:

| Command                                       | Purpose                |
|-----------------------------------------------|------------------------|
| <code>Tqwvgt *eqphki+% "xvr"xgtukqp 5"</code> | Enables VTP version 3. |

This example shows one way to enable VTP version 3:

```
Tqwvgt% "eqphkiwtg"vgtokpcn"
Tqwvgt *eqphki+% "xvr"xgtukqp 5"
Tqwvgt *eqphki+% "
```

This example shows how to verify the configuration:

```
Tqwvgt% "ujqy"xvr"uvcvwu
XVR"Xgtukqp"ecrcdng" <"3"vq"5
XVR"xgtukqp"twppkpi" <"5
XVR"Fgockp"Pcog" <"ncdauykvej
XVR"Rtwpkpi"Oqfg" <"Fkucdngf
XVR"Vtcru"Igpgtcvkqp" <"Fkucdngf
Fgxkeg"KF" <"22370e94602262

Hgcvtg"XNCP<
//////////
XVR"Qrgtcvkpi"Oqfg" <"Ugtxgt
Pwodgt"qh"gzkuvkpi"XNCPu" <"8
Pwodgt"qh"gzkuvkpi"gzvgpf"XNCPu" <"2
Eqphkiwtcvkqp"Txkukqp" <"2
Rtkoct{"KF" <"222202220222
Rtkoct{"Fguetkrvkqp" <
OF7"fkiguv" <"2z22"2z22"2z22"2z22"2z22"2z22"2z22"2z22
"2z22"2z22"2z22"2z22"2z22"2z22"2z22"2z22

Hgcvtg"OUV<
//////////
XVR"Qrgtcvkpi"Oqfg" <"Vtcpurctgpv

Hgcvtg"WPMPQYP<
//////////
XVR"Qrgtcvkpi"Oqfg" <"Vtcpurctgpv
Tqwvgt% "
```

## Configuring the VTP Mode

To configure the VTP mode, perform this task:

|        | Command                                                                                                    | Purpose                                                                                                                                                                                                                                                                                                                |
|--------|------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>xvr</b>"oqfg"}enkgpv"~"ugtugt"~"vtcpurctgppv"~"qhh;" }xncp"~"ouv"~"wpmpqyp;</code> | Configures the VTP mode.                                                                                                                                                                                                                                                                                               |
| Step 2 | <code>Tqwvgt*eqphki+%<b>xvr</b>"fqockp"domain-name"</code>                                                 | (Optional for server mode) Defines the VTP domain name, which can be up to 32 characters long. VTP server mode requires a domain name. If the switch has a trunk connection to a VTP domain, the switch learns the domain name from the VTP server in the domain.<br><br><b>Note</b> You cannot clear the domain name. |
| Step 3 | <code>Tqwvgt*eqphki+%<b>gpf</b>"</code>                                                                    | Exits VLAN configuration mode.                                                                                                                                                                                                                                                                                         |



### Note

When VTP is disabled, you can enter VLAN configuration commands in configuration mode instead of the VLAN database mode and the VLAN configuration is stored in the startup configuration file.

This example shows how to configure the switch as a VTP server:

```
Tqwvgt%"eqphkiwtcvkqp"vgtokpcn
Tqwvgt*eqphki+%xvr"oqfg"ugtugt
Ugvvkpi"fgxkeg"vq"XVR"UGTXGT"oqfg0
Tqwvgt*eqphki+%xvr"fqockp"ncdapgvvyqtm
Ugvvkpi"XVR"fqockp"pcog"vq"ncdapgvvyqtm
Tqwvgt*eqphki+%gpf
Tqwvgt%
```

This example shows how to configure the switch as a VTP client:

```
Tqwvgt%"eqphkiwtcvkqp"vgtokpcn
Tqwvgt*eqphki+%xvr"oqfg"enkgpv
Ugvvkpi"fgxkeg"vq"XVR"ENKGPV"oqfg0
Tqwvgt*eqphki+%gzkv
Tqwvgt%
```

This example shows how to disable VTP on the switch:

```
Tqwvgt%"eqphkiwtcvkqp"vgtokpcn
Tqwvgt*eqphki+%xvr"oqfg"vtcpurctgppv
Ugvvkpi"fgxkeg"vq"XVR"VTCPURCTGPV"oqfg0
Tqwvgt*eqphki+%gpf
Tqwvgt%
```

This example shows how to disable VTP on the switch and to disable VTP advertisement forwarding:

```
Tqwvgt%"eqphki"vgtokpcn
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpq0""Gpf"ykvj"EPVN1\0
Tqwvgt*eqphki+%xvr"oqfg"qhh
Ugvvkpi"fgxkeg"vq"XVR"QHH"oqfg0
Tqwvgt*eqphki+%gzkv
Tqwvgt%
```

This example shows how to verify the configuration:

```
Tqwgvt%"ujgy"xvr"uvcvwu"
XVR"Xgtukqp"ecrcdng"3"vq"5
XVR"xgtukqp"twppkpi"5
XVR"Fqockp"Pcog"ncdapgyvqtm
XVR"Rtwpkpi"Oqfg"Fkucdngf
XVR"Vtcru"Igpgtcvkqp"Fkucdngf
Fgxkeg"KF"22370e94602262

Hgcvtg"XNCP<
//////////
XVR"Qrgtcvkpi"Oqfg"Ugtxgt
Pwodgt"qh"gzkuvkpi"XNCPu"8
Pwodgt"qh"gzkuvkpi"gzvgpfgf"XNCPu"<2
Eqphkiwtcvkqp"Txkukqp"<2
Rtkoct{"KF"22220222202222
Rtkoct{"Fguetkrvkqp"<
OF7"fkiguv"2z22"2z22"2z22"2z22"2z22"2z22"2z22"2z22
"2z22"2z22"2z22"2z22"2z22"2z22"2z22"2z22

Hgcvtg"OUV<
//////////
XVR"Qrgtcvkpi"Oqfg"Vtcpurctgpv

Hgcvtg"WMPQYP<
//////////
XVR"Qrgtcvkpi"Oqfg"Vtcpurctgpv

Tqwgvt%"
```

# Configuring VTP Mode on a Per-Port Basis

You can configure VTP mode on a per-port basis. The VTP enable value will be applied only when a port becomes switched port in trunk mode. Incoming and outgoing vtp pdus are blocked; *not* forwarded. In VTP version 3, you can also configure VTP mode on a per-trunk basis. To configure VTP mode, perform this task:

|        | Command                                                 | Purpose                             |
|--------|---------------------------------------------------------|-------------------------------------|
| Step 1 | Tqwgvt*eqphki+% <b>kpvgt</b> hceg <i>type slot/port</i> | Selects an interface to configure.  |
| Step 2 | Tqwgvt*eqphki/kh+% <b>xvr</b>                           | Enables VTP on the specified port.  |
| Step 3 | Tqwgvt*eqphki/kh+% <b>gpf</b>                           | Exits interface configuration mode. |

This example shows how to configure VTP mode on a port:

```
Tqwgvt%"eqphki"vgtokpcn
Gpvgvt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+%kpvgthceg"ikicdkvgvgjgtpgv"517
Tqwgvt*eqphki/kh+%xvr
Tqwgvt*eqphki/kh+%gpf
Tqwgvt%
```



This example shows how to disable VTP mode on a port:

```
Tqwwgt%"eqphki"vgtokpcn
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp00""Gpf"ykvj"EPVN1\0
Tqwwgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"517
Tqwwgt*eqphki/kh+%"pq"xvr
Tqwwgt*eqphki/kh+%"gpf
Tqwwgt%
```

This example shows how to verify the configuration change:

```
Tqwwgt%"ujqy"xvr"kpvgtthceg"ikicdkvgvjgtpgv"517

"Kpvgtthceg"XXXXXXXXXXXXXXXXXXXX"XVR"Uvcvwu
//
"IkicdkvGvjgtpgv517"XXXXXXXX"fkucdnfg
Tqwwgt%
```

This example shows how to verify the interface:

```
Tqwwgt%"ujqy"xvr"kpvgtthceg

"Kpvgtthceg"XXXXXXXXXXXXXXXXXXXX"XVR"Uvcvwu
//
"IkicdkvGvjgtpgv513"XXXXXXXX"gpdcnfg
"IkicdkvGvjgtpgv514"XXXXXXXX"gpdcnfg
"IkicdkvGvjgtpgv515"XXXXXXXX"gpdcnfg
"IkicdkvGvjgtpgv516"XXXXXXXX"gpdcnfg
"IkicdkvGvjgtpgv517"XXXXXXXX"fkucdnfg
"IkicdkvGvjgtpgv518"XXXXXXXX"gpdcnfg
"000
```

## Displaying VTP Statistics

To display VTP statistics, including VTP advertisements sent and received and VTP errors, perform this task:

| Command                            | Purpose                  |
|------------------------------------|--------------------------|
| Tqwwgt% <b>"ujqy"xvr"eqwpvgtu"</b> | Displays VTP statistics. |

This example shows how to display VTP statistics:

```
Tqwwgt%"ujqy"xvr"eqwpvgtu
XVR"uvcvkuvkeu<
Uwooct{"cfxgtvkugogpvu"tgegkxgf" "<"9
Uwdugv"cfxgtvkugogpvu"tgegkxgf" "<"7
Tgswguv"cfxgtvkugogpvu"tgegkxgf" "<"2
Uwooct{"cfxgtvkugogpvu"vtcpuokvvvf"<" ;9
Uwdugv"cfxgtvkugogpvu"vtcpuokvvvf" "<"35
Tgswguv"cfxgtvkugogpvu"vtcpuokvvvf"<"5
Pwodgt"qh"eqphki"tgxkukqp"gttqtu" "<"2
Pwodgt"qh"eqphki"fkiguv"gttqtu" "<"2
Pwodgt"qh"X3"Uwooct{"gttqtu" "<"2
```

[illegible]

Participate in the Technical Documentation Ideas forum



## Virtual Local Area Networks (VLANs)

- [Prerequisites for VLANs, page 26-1](#)
- [Restrictions for VLANs, page 26-2](#)
- [Information About VLANs, page 26-2](#)
- [Default Settings for VLANs, page 26-3](#)
- [How to Configure VLANs, page 26-4](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for VLANs

The following recommendations apply to Fabric Extender (FEX) VLANs:

- FEX-configurable VLAN range—1000 VLANs of any 4K VLANs
- Total number of VLANs—Not to exceed 20 VLANs per FEX
- Maximum number of trunks—Not to exceed 4 trunks

## Restrictions for VLANs

- If the switch is in VTP server or transparent mode (see the [“How to Configure VTP” section on page 25-10](#)), you can configure VLANs in global and config-vlan configuration modes. When you configure VLANs in global and config-vlan configuration modes, the VLAN configuration is saved in the vlan.dat files. To display the VLAN configuration, enter the **show vlan** command.

If the switch is in VLAN transparent mode, use the copy **running-config startup-config** command to save the VLAN configuration to the startup-config file. After you save the running configuration as the startup configuration, use the **show running-config** and **show startup-config** commands to display the VLAN configuration.

- When the switch boots, if the VTP domain name and the VTP mode in the startup-config file and vlan.dat files do not match, the switch uses the configuration in the vlan.dat file.
- You can configure extended-range VLANs only in global configuration mode.
- Supervisor engine redundancy does not support nondefault VLAN data file names or locations. Do not enter the **vtp file file\_name** command on a switch that has a redundant supervisor engine.
- Before installing a redundant supervisor engine, enter the **no vtp file** command to return to the default configuration.
- Before you can create a VLAN, the switch must be in VTP server mode or VTP transparent mode. For information on configuring VTP, see [Chapter 25, “VLAN Trunking Protocol \(VTP\).”](#)
- The VLAN configuration is stored in the vlan.dat file, which is stored in nonvolatile memory. You can cause inconsistency in the VLAN database if you manually delete the vlan.dat file.
- To do a complete backup of your configuration, include the vlan.dat file in the backup.

## Information About VLANs

- [VLAN Overview, page 26-2](#)
- [VLAN Ranges, page 26-2](#)

### VLAN Overview

A VLAN is a group of end stations with a common set of requirements, independent of physical location. VLANs have the same attributes as a physical LAN but allow you to group end stations even if they are not located physically on the same LAN segment.

VLANs are usually associated with IP subnetworks. For example, all the end stations in a particular IP subnet belong to the same VLAN. Traffic between VLANs must be routed. LAN port VLAN membership is assigned manually on an port-by-port basis.

### VLAN Ranges



#### Note

You must enable the extended system ID to use 4094 VLANs (see the [“Information about the Bridge ID” section on page 31-3](#)).

Cisco IOS Release 15.4SY supports 4094 VLANs in accordance with the IEEE 802.1Q standard. These VLANs are organized into several ranges; you use each range slightly differently. Some of these VLANs are propagated to other switches in the network when you use the VLAN Trunking Protocol (VTP). The extended-range VLANs are not propagated, so you must configure extended-range VLANs manually on each network device.

Table 26-1 describes the VLAN ranges.

**Table 26-1**      *VLAN Ranges*

| VLANs     | Range     | Usage                                                                      | Propagated by VTP |
|-----------|-----------|----------------------------------------------------------------------------|-------------------|
| 0, 4095   | Reserved  | For system use only. You cannot see or use these VLANs.                    | —                 |
| 1         | Normal    | Cisco default. You can use this VLAN but you cannot delete it.             | Yes               |
| 2–1001    | Normal    | For Ethernet VLANs; you can create, use, and delete these VLANs.           | Yes               |
| 1002–1005 | Normal    | Cisco defaults for FDDI and Token Ring. You cannot delete VLANs 1002–1005. | Yes               |
| 1006–4094 | Extended  | For Ethernet VLANs only.                                                   | No                |
| 3968–4031 | MET VLANs | Reserved for internal usage.                                               | —                 |

The following information applies to VLAN ranges:

- Layer 3 LAN ports, WAN interfaces and subinterfaces, and some software features use internal VLANs in the extended range. You cannot use an extended range VLAN that has been allocated for internal use.
- To display the VLANs used internally, enter the **show vlan internal usage** command. With earlier releases, enter the **show vlan internal usage** and **show cwan vlans** commands.
- You can configure ascending internal VLAN allocation (from 1006 and up) or descending internal VLAN allocation (from 4094 and down).
- You must enable the extended system ID to use extended range VLANs (see the [“Information about the Bridge ID” section on page 31-3](#)).

## Default Settings for VLANs

- VLAN ID: 1; range: 1–4094
- VLAN name:
  - VLAN 1: “default”
  - Other VLANs: “VLANvlan\_ID”
- 802.1Q SAID: 10vlan\_ID; range: 100001–104094
- MTU size: 1500; range: 1500–18190
- Translational bridge 1: 0; range: 0–1005
- Translational bridge 2: 0; range: 0–1005
- VLAN state: active: active, suspend

- Pruning eligibility:
  - VLANs 2–1001 are pruning eligible
  - VLANs 1006–4094 are pruning eligible

## How to Configure VLANs

- [Configurable VLAN Parameters, page 26-4](#)
- [VLAN Locking, page 26-4](#)
- [Creating or Modifying an Ethernet VLAN, page 26-5](#)
- [Assigning a Layer 2 LAN Interface to a VLAN, page 26-6](#)
- [Configuring the Internal VLAN Allocation Policy, page 26-6](#)
- [Configuring VLAN Translation, page 26-7](#)
- [Saving VLAN Information, page 26-9](#)

## Configurable VLAN Parameters



### Note

- Ethernet VLAN 1 uses only default values.
- Except for the VLAN name, Ethernet VLANs 1006 through 4094 use only default values.
- You can configure the VLAN name for Ethernet VLANs 1006 through 4094.

You can configure the following parameters for VLANs 2 through 1001:

- VLAN name
- VLAN type (Ethernet, FDDI, FDDI network entity title [NET], TrBRF, or TrCRF)
- VLAN state (active or suspended)
- Security Association Identifier (SAID)
- Bridge identification number for TrBRF VLANs
- Ring number for FDDI and TrCRF VLANs
- Parent VLAN number for TrCRF VLANs
- Spanning Tree Protocol (STP) type for TrCRF VLANs

## VLAN Locking

The VLAN locking feature provides an extra level of verification to ensure that you have configured the intended VLAN. When VLAN locking is enabled, you need to specify the VLAN name when you change a port from one VLAN to another. This feature affects **switchport** commands (in interface configuration mode) that specify the VLANs or private VLANs for access and trunk ports.

For additional information about how to configure access and trunk ports with VLAN locking enabled, see the [“How to Configure LAN Interfaces for Layer 2 Switching” section on page 21-5](#).

For additional information about how to configure ports in private VLANs with VLAN locking enabled, see the [“How to Configure Private VLANs” section on page 27-10](#).

By default, the VLAN locking is disabled. To enable VLAN locking, perform this task:

| Command                                                   | Purpose               |
|-----------------------------------------------------------|-----------------------|
| <code>Tqwgvt*eqphki+%<b>xncp</b>"rqtv"rtqzkukqpkpi</code> | Enables VLAN locking. |

## Creating or Modifying an Ethernet VLAN

User-configured VLANs have unique IDs from 1 to 4094, except for reserved VLANs (see [Table 26-1 on page 26-3](#)). Enter the **vlan** command with an unused ID to create a VLAN. Enter the **vlan** command for an existing VLAN to modify the VLAN (you cannot modify an existing VLAN that is being used by a Layer 3 port or a software feature).

See the [“Default Settings for VLANs” section on page 26-3](#) for the list of default parameters that are assigned when you create a VLAN. If you do not specify the VLAN type with the **media** keyword, the VLAN is an Ethernet VLAN.

To create or modify a VLAN, perform this task:

|               | Command                                                                    | Purpose                                                                                                                                                         |
|---------------|----------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | <code>Tqwgvt%<b>eqphkiwtg</b>"vgtokpcn"</code>                             | Enters configuration mode.                                                                                                                                      |
| <b>Step 2</b> | <code>Tqwgvt*eqphki+%<b>xncp</b>"vlan_ID}] / vlan_ID_~] . vlan_ID_+</code> | Creates or modifies an Ethernet VLAN, a range of Ethernet VLANs, or several Ethernet VLANs specified in a comma-separated list (do not enter space characters). |
| <b>Step 3</b> | <code>Tqwgvt*eqphki/xncp+%<b>gpf</b>"</code>                               | Updates the VLAN database and returns to privileged EXEC mode.                                                                                                  |

When you create or modify an Ethernet VLAN, note the following information:

- Because Layer 3 ports and some software features require internal VLANs allocated from 1006 and up, configure extended-range VLANs starting with 4094.
- You can configure extended-range VLANs only in global configuration mode. You cannot configure extended-range VLANs in VLAN database mode.
- Layer 3 ports and some software features use extended-range VLANs. If the VLAN you are trying to create or modify is being used by a Layer 3 port or a software feature, the switch displays a message and does not modify the VLAN configuration.

When deleting VLANs, note the following information:

- You cannot delete the default VLANs for the different media types: Ethernet VLAN 1 and FDDI or Token Ring VLANs 1002 to 1005.
- When you delete a VLAN, any LAN ports configured as access ports assigned to that VLAN become inactive. The ports remain associated with the VLAN (and inactive) until you assign them to a new VLAN.

This example shows how to create an Ethernet VLAN in global configuration mode and verify the configuration:

```
Tqwgvt%eqphkiwtg"vgtokpcn"
```

[illegible]

## Assigning a Layer 2 LAN Interface to a VLAN

A VLAN created in a management domain remains unused until you assign one or more LAN ports to the VLAN.



### Note

Make sure you assign LAN ports to a VLAN of the appropriate type. Assign Ethernet ports to Ethernet-type VLANs.

To assign one or more LAN ports to a VLAN, complete the procedures in the [“How to Configure LAN Interfaces for Layer 2 Switching”](#) section on page 21-5.

## Configuring the Internal VLAN Allocation Policy

For more information about VLAN allocation, see the “VLAN Ranges” section on page 26-2.



### Note

The internal VLAN allocation policy is applied only following a reload.

To configure the internal VLAN allocation policy, perform this task:

|        | Command                                                                                                        | Purpose                                                                                                                                                                                                                                                                  |
|--------|----------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqwvgt*eqphki+% <b>"xncp"</b> kpvgtpcn"cnngcevkg <b>p"</b> rqnke{ " <b>}cuegpfkpi"</b> ~" <b>fguegpfkpi</b> ;" | Configures the internal VLAN allocation policy.                                                                                                                                                                                                                          |
| Step 2 | Tqwvgt*eqphki+% <b>"gpf"</b>                                                                                   | Exits configuration mode.                                                                                                                                                                                                                                                |
| Step 3 | Tqwvgt% <b>"tgnqcf"</b>                                                                                        | Applies the new internal VLAN allocation policy.                                                                                                                                                                                                                         |
|        |                                                                                                                | <div>  <div> <b>Caution</b> <p>You do not need to enter the <b>reload</b> command immediately. Enter the <b>reload</b> command during a planned maintenance window.</p> </div> </div> |

When you configure the internal VLAN allocation policy, note the following information:

- Enter the **ascending** keyword to allocate internal VLANs from 1006 and up.
- Enter the **descending** keyword to allocate internal VLAN from 4094 and down.



This example shows how to configure descending as the internal VLAN allocation policy:

```
Tqvwgt% "eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+% "xncp"kpvgtpcn"cnnqecvkqp"rqnke{ "fguegpfkpi"
```

## Configuring VLAN Translation

- [VLAN Translation Guidelines and Restrictions, page 26-7](#)
- [Configuring VLAN Translation on a Trunk Port, page 26-8](#)
- [Enabling VLAN Translation on Other Ports in a Port Group, page 26-9](#)



### Note

- To avoid spanning tree loops, be careful not to misconfigure the VLAN translation feature.
- On trunk ports, you can translate one VLAN number to another VLAN number, which transfers all traffic received in one VLAN to the other VLAN.

## VLAN Translation Guidelines and Restrictions

When translating VLANs, follow these guidelines and restrictions:

- A VLAN translation configuration is inactive if it is applied to ports that are not Layer 2 trunks.
- Do not configure translation of ingress native VLAN traffic on an 802.1Q trunk. Because 802.1Q native VLAN traffic is untagged, it cannot be recognized for translation. You can translate traffic from other VLANs to the native VLAN of an 802.1Q trunk.
- Do not remove the VLAN to which you are translating from the trunk.
- The VLAN translation configuration applies to all ports in a port group. VLAN translation is disabled by default on all ports in a port group. Enable VLAN translation on ports as needed.
- Cisco IOS Release 15.4SY supports only IEEE 802.1Q trunking.

**Table 26-2**      *Module Support for VLAN Translation*

| Product Number                    | Number of Ports                                     | Number of Port Groups | Port Ranges per Port Group                           | Translations per Port Group |
|-----------------------------------|-----------------------------------------------------|-----------------------|------------------------------------------------------|-----------------------------|
| C6800-SUP6T-XL<br>C6800-SUP6T     | Depends on the operational port mode of the Sup6T.* | 2                     | Depends on the operational port mode of the Sup6T..* | 16                          |
| WS-X6904-40G-2T                   | See the <a href="#">Release Notes</a> .             |                       |                                                      | 16                          |
| WS-X6908-10GE                     | 8                                                   | 8                     | 1 port in each group                                 | 16                          |
| WS-X6816-10T-2T,<br>WS-X6716-10T  | 16                                                  | 16                    | 1 port in each group                                 | 16                          |
| WS-X6816-10G-2T,<br>WS-X6716-10GE | 16                                                  | 16                    | 1 port in each group                                 | 16                          |
| WS-X6704-10GE                     | 4                                                   | 4                     | 1 port in each group                                 | 128                         |

**Table 26-2** *Module Support for VLAN Translation (continued)*

| Product Number                    | Number of Ports | Number of Port Groups | Port Ranges per Port Group                           | Translations per Port Group |
|-----------------------------------|-----------------|-----------------------|------------------------------------------------------|-----------------------------|
| WS-X6848-TX-2T,<br>WS-X6748-GE-TX | 48              | 4                     | 1–12<br>13–24<br>25–36<br>37–48                      | 128                         |
| WS-X6848-SFP-2T,<br>WS-X6748-SFP  | 48              | 4                     | 1–23, odd<br>2–24, even<br>25–47, odd<br>26–48, even | 128                         |
| WS-X6824-SFP-2T,<br>WS-X6724-SFP  | 24              | 2                     | 1–12<br>13–24                                        | 128                         |

**Note**

To configure a port as a trunk, see the [“Configuring a Layer 2 Switching Port as a Trunk”](#) section on [page 21-8](#).

\*Following are the different combinations based on the operational port mode on Supervisor Engine 6T:

- Default mode: port-group1 had 4 ports and port-group2 has 2 ports
- 16x10G Over-subscription mode: both port-group1 & port-group2 has 8 ports each.
- 8x10G Performance mode: both port-group1 & port-group2 has 4 ports each.
- 2x40G Performance mode: both port-group1 & port-group2 has 1 port each.

## Configuring VLAN Translation on a Trunk Port

To translate VLANs on a trunk port, perform this task:

|               | Command                                                                                                        | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------|----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | <code>Tqwvgt*eqphki+%<b>kpvgthceg</b>"type slot/port"</code>                                                   | Selects the Layer 2 trunk port to configure.                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Step 2</b> | <code>Tqwvgt*eqphki/kh+%<b>uykvejrgtv"xncp"ocrrkpi"gpcdng"</b></code>                                          | Enables VLAN translation.                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Step 3</b> | <code>Tqwvgt*eqphki/kh+%<b>uykvejrgtv"xncp"ocrrkpi"</b><br/><i>original_vlan_ID"translated_vlan_ID"</i></code> | Translates a VLAN to another VLAN. The valid range is 1 to 4094.<br><br>When you configure a VLAN mapping from the original VLAN to the translated VLAN on a port, traffic arriving on the original VLAN gets mapped or translated to the translated VLAN at the ingress of the switch port, and the traffic internally tagged with the translated VLAN gets mapped to the original VLAN before leaving the switch port. This method of VLAN mapping is a two-way mapping. |
| <b>Step 4</b> | <code>Tqwvgt*eqphki/kh+%<b>gpf"</b></code>                                                                     | Exits configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

This example shows how to map VLAN 1649 to VLAN 755 Gigabit Ethernet port 5/2:

```
Tqwvgt%"eqphkiwtg"vgtokpcn"
```

```
Tqwgvt% "ujqr"kpvgthceg"ikicdkvgvjgtpgv"714"xncp"ocrrkpi"
Uvcvg<"gpcdnf
Qtikipcn"XNCP"Vtcpuvcvgf"XNCP
/////////////////"////////////////
""386;""""""""""977"
```

## Enabling VLAN Translation on Other Ports in a Port Group

To enable VLAN translation on other ports in a port group, perform this task:

|        | Command                                                            | Purpose                            |
|--------|--------------------------------------------------------------------|------------------------------------|
| Step 1 | Tqvwgt*eqphki+% <b>kpvgthceg</b> "type slot/port"                  | Selects the LAN port to configure. |
| Step 2 | Tqvwgt*eqphki/kh+% <b>uykvejrqtv</b> "xncp"ocrrkpi <b>"gpcdng"</b> | Enables VLAN translation.          |
| Step 3 | Tqvwgt*eqphki/kh+% <b>gpf</b> "                                    | Exits configuration mode.          |

This example shows how to enable VLAN translation on a port:

Tqvwgt%**"eqphkiwtg"vgtokpcn"**  
Tqvwgt\*eqphki+%**"kpvgtgceg"ikicdkvgvjgtpgv"714"**  
Tqvwgt\*eqphki/kh+%**"uykvejrgtv"xnep"ocrrkpi"gpdcng"**  
Tqvwgt\*eqphki/kh+%**"gpf"**

## Saving VLAN Information

The VLAN database is stored in the `vlan.dat` file. You should create a backup of the `vlan.dat` file in addition to backing up the `running-config` and `startup-config` files. If you replace the existing supervisor engine, copy the `startup-config` file as well as the `vlan.dat` file to restore the system. The `vlan.dat` file is read on bootup and you will have to reload the supervisor engine after uploading the file. To view the file location, use the **`dir vlan.dat`** command. To copy the file (binary), use the **`copy vlan.dat tftp`** command.



**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

Participate in the [Technical Documentation Ideas forum](#)





## Private VLANs

---

- [Prerequisites for Private VLANs, page 27-1](#)
- [Restrictions for Private VLANs, page 27-2](#)
- [Information About Private VLANs, page 27-5](#)
- [Default Settings for Private VLANs, page 27-10](#)
- [How to Configure Private VLANs, page 27-10](#)
- [Monitoring Private VLANs, page 27-16](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for Private VLANs

None.

# Restrictions for Private VLANs

- [Secondary and Primary VLANs, page 27-2](#)
- [Private VLAN Ports, page 27-4](#)
- [Limitations with Other Features, page 27-4](#)

## Secondary and Primary VLANs

- After you configure a private VLAN and set VTP to transparent mode, you are not allowed to change the VTP mode to client or server. For information about VTP, see [Chapter 25, “VLAN Trunking Protocol \(VTP\).”](#)
- After you have configured private VLANs, use the **copy running-config startup config** privileged EXEC command to save the VTP transparent mode configuration and private VLAN configuration in the startup-config file. If the switch resets it must default to VTP transparent mode to support private VLANs.
- In VTP versions 1 and 2, VTP does not propagate a private VLAN configuration and you must configure private VLANs on each device where you want private VLAN ports. In VTP version 3, VTP does propagate private VLAN configurations automatically.
- You cannot configure VLAN 1 or VLANs 1002 to 1005 as primary or secondary VLANs. Extended VLANs (VLAN IDs 1006 to 4094) cannot belong to private VLANs. Only Ethernet VLANs can be private VLANs.
- A primary VLAN can have one isolated VLAN and multiple community VLANs associated with it. An isolated or community VLAN can have only one primary VLAN associated with it.
- When a secondary VLAN is associated with the primary VLAN, the STP parameters of the primary VLAN, such as bridge priorities, are propagated to the secondary VLAN. However, STP parameters do not necessarily propagate to other devices. You should manually check the STP configuration to ensure that the primary, isolated, and community VLANs' spanning tree topologies match so that the VLANs can properly share the same forwarding database.
- If you enable MAC address reduction on the switch, we recommend that you enable MAC address reduction on all the devices in your network to ensure that the STP topologies of the private VLANs match.
- In a network where private VLANs are configured, if you enable MAC address reduction on some devices and disable it on others (mixed environment), use the default bridge priorities to make sure that the root bridge is common to the primary VLAN and to all its associated isolated and community VLANs. Be consistent with the ranges employed by the MAC address reduction feature regardless of whether it is enabled on the system. MAC address reduction allows only discrete levels and uses all intermediate values internally as a range. You should disable a root bridge with private VLANs and MAC address reduction, and configure the root bridge with any priority higher than the highest priority range used by any nonroot bridge.
- You cannot apply VACLs to secondary VLANs. (See [Chapter 74, “VLAN ACLs \(VACLs\)”](#).)
- You can enable DHCP snooping on private VLANs. When you enable DHCP snooping on the primary VLAN, it is propagated to the secondary VLANs. If you configure DHCP on a secondary VLAN, the configuration does not take effect if the primary VLAN is already configured.
- We recommend that you prune the private VLANs from the trunks on devices that carry no traffic in the private VLANs.

- You can apply different quality of service (QoS) configurations to primary, isolated, and community VLANs. (See [Chapter 62, “PFC QoS Overview”](#).)
- When you configure private VLANs, sticky Address Resolution Protocol (ARP) is enabled by default, and ARP entries learned on Layer 3 private VLAN interfaces are sticky ARP entries. For security reasons, private VLAN port sticky ARP entries do not age out. For information about configuring sticky ARP, see the [“Configuring Sticky ARP” section on page 76-9](#).
- We recommend that you display and verify private VLAN interface ARP entries.
- Sticky ARP prevents MAC address spoofing by ensuring that ARP entries (IP address, MAC address, and source VLAN) do not age out. You can configure sticky ARP on a per-interface basis. For information about configuring sticky ARP, see the [“Configuring Sticky ARP” section on page 76-9](#). The following guidelines and restrictions apply to private VLAN sticky ARP:
  - ARP entries learned on Layer 3 private VLAN interfaces are sticky ARP entries.
  - Connecting a device with a different MAC address but with the same IP address generates a message and the ARP entry is not created.
  - Because the private VLAN port sticky ARP entries do not age out, you must manually remove private VLAN port ARP entries if a MAC address changes. You can add or remove private VLAN ARP entries manually as follows:

```
Tqvwgt *eqphki+% "pq"ctr"330305052"
KR"CTR<Fgngvkpi"Uvkem{"CTR"gpvt{"330305052

Tqvwgt *eqphki+% "ctr"330305052"22220762504578"ctrc"
KR"CTR<Qxgtytkvkpi"Uvkem{"CTR"gpvt{"330305052."jy<22f20dd2;0488g"d{"
jy<22220762504578
```

- You can configure VLAN maps on primary and secondary VLANs. (See the [“Applying a VLAN Access Map” section on page 74-4](#).) However, we recommend that you configure the same VLAN maps on private VLAN primary and secondary VLANs.
- When a frame is Layer 2 forwarded within a private VLAN, the same VLAN map is applied at the ingress side and at the egress side. When a frame is routed from inside a private VLAN to an external port, the private VLAN map is applied at the ingress side.
  - For frames going upstream from a host port to a promiscuous port, the VLAN map configured on the secondary VLAN is applied.
  - For frames going downstream from a promiscuous port to a host port, the VLAN map configured on the primary VLAN is applied.

To filter out specific IP traffic for a private VLAN, you should apply the VLAN map to both the primary and secondary VLANs.

- To apply Cisco IOS output ACLs to all outgoing private VLAN traffic, configure them on the Layer 3 VLAN interface of the primary VLAN. (See [Chapter 72, “MAC Address-Based Traffic Blocking”](#).)
- Cisco IOS ACLs applied to the Layer 3 VLAN interface of a primary VLAN automatically apply to the associated isolated and community VLANs.
- Do not apply Cisco IOS ACLs to isolated or community VLANs. Cisco IOS ACL configuration applied to isolated and community VLANs is inactive while the VLANs are part of the private VLAN configuration.
- Although private VLANs provide host isolation at Layer 2, hosts can communicate with each other at Layer 3.

- Private VLANs support these Switched Port Analyzer (SPAN) features:
  - You can configure a private VLAN port as a SPAN source port.
  - You can use VLAN-based SPAN (VSPAN) on primary, isolated, and community VLANs or use SPAN on only one VLAN to separately monitor egress or ingress traffic.
  - For more information about SPAN, see [Chapter 56, “Local SPAN, RSPAN, and ERSPAN.”](#)

## Private VLAN Ports

- Use only the private VLAN configuration commands to assign ports to primary, isolated, or community VLANs. Layer 2 access ports assigned to the VLANs that you configure as primary, isolated, or community VLANs are inactive while the VLAN is part of the private VLAN configuration. Layer 2 trunk interfaces remain in the STP forwarding state.
- Do not configure ports that belong to a PAGP or LACP EtherChannel as private VLAN ports. While a port is part of the private VLAN configuration, any EtherChannel configuration for it is inactive.
- Enable PortFast and BPDU guard on isolated and community host ports to prevent STP loops due to misconfigurations and to speed up STP convergence. (See [Chapter 32, “Optional STP Features”](#).) When enabled, STP applies the BPDU guard feature to all PortFast-configured Layer 2 LAN ports. Do not enable PortFast and BPDU guard on promiscuous ports.
- If you delete a VLAN used in the private VLAN configuration, the private VLAN ports associated with the VLAN become inactive.
- Private VLAN ports can be on different network devices if the devices are trunk-connected and the primary and secondary VLANs have not been removed from the trunk.
- All primary, isolated, and community VLANs associated within a private VLAN must maintain the same topology across trunks. You are highly recommended to configure the same STP bridge parameters and trunk port parameters on all associated VLANs in order to maintain the same topology.

## Limitations with Other Features

- VTP version 3 is not supported on private VLAN (PVLAN) ports.
- In some cases, the configuration is accepted with no error messages, but the commands have no effect.
- Do not configure fallback bridging on switches with private VLANs.
- A port is only affected by the private VLAN feature if it is currently in private VLAN mode and its private VLAN configuration indicates that it is a primary, isolated, or community port. If a port is in any other mode, such as Dynamic Trunking Protocol (DTP), it does not function as a private port.
- Do not configure private VLAN ports on interfaces configured for these other features:
  - Port Aggregation Protocol (PAgP)
  - Link Aggregation Control Protocol (LACP)
  - Voice VLAN
- You can configure IEEE 802.1x port-based authentication on a private VLAN port, but do not configure 802.1x with port security, voice VLAN, or per-user ACL on private VLAN ports.



- Do not configure a remote SPAN (RSPAN) VLAN as a private VLAN primary or secondary VLAN. For more information about SPAN, see [Chapter 56, “Local SPAN, RSPAN, and ERSPAN.”](#)
- A private VLAN host or promiscuous port cannot be a SPAN destination port. If you configure a SPAN destination port as a private VLAN port, the port becomes inactive.
- A destination SPAN port should not be an isolated port. (However, a source SPAN port can be an isolated port.) VSPAN could be configured to span both primary and secondary VLANs or, alternatively, to span either one if the user is interested only in ingress or egress traffic.
- If using the shortcuts between different VLANs (if any of these VLANs is private) consider both primary and isolated and community VLANs. The primary VLAN should be used both as the destination and as the virtual source, because the secondary VLAN (the real source) is always remapped to the primary VLAN in the Layer 2 FID table.
- If you configure a static MAC address on a promiscuous port in the primary VLAN, you must add the same static address to all associated secondary VLANs. If you configure a static MAC address on a host port in a secondary VLAN, you must add the same static MAC address to the associated primary VLAN. When you delete a static MAC address from a private VLAN port, you must remove all instances of the configured MAC address from the private VLAN.



**Note** Dynamic MAC addresses learned in one VLAN of a private VLAN are replicated in the associated VLANs. For example, a MAC address learned in a secondary VLAN is replicated in the primary VLAN. When the original dynamic MAC address is deleted or aged out, the replicated addresses are removed from the MAC address table.

- Do not configure private VLAN ports as EtherChannels. A port can be part of the private VLAN configuration, but any EtherChannel configuration for the port is inactive.

## Information About Private VLANs

- [Private VLAN Domains, page 27-5](#)
- [Private VLAN Ports, page 27-7](#)
- [Primary, Isolated, and Community VLANs, page 27-7](#)
- [Private VLAN Port Isolation, page 27-8](#)
- [IP Addressing Scheme with Private VLANs, page 27-8](#)
- [Private VLANs Across Multiple Switches, page 27-9](#)
- [Private VLAN Interaction with Other Features, page 27-9](#)

## Private VLAN Domains


The private VLAN feature addresses two problems that service providers encounter when using VLANs:

- The switch supports up to 4096 VLANs. If a service provider assigns one VLAN per customer, the number of customers that service provider can support is limited.
- To enable IP routing, each VLAN is assigned a subnet address space or a block of addresses, which can result in wasting the unused IP addresses and creating IP address management problems.

Using private VLANs solves the scalability problem and provides IP address management benefits for service providers and Layer 2 security for customers.

The private VLAN feature partitions the Layer 2 broadcast domain of a VLAN into subdomains. A subdomain is represented by a pair of private VLANs: a primary VLAN and a secondary VLAN. A private VLAN domain can have multiple private VLAN pairs, one pair for each subdomain. All VLAN pairs in a private VLAN domain share the same primary VLAN. The secondary VLAN ID differentiates one subdomain from another (see [Figure 27-1](#)).

**Figure 27-1** Private VLAN Domain



A private VLAN domain has only one primary VLAN. Every port in a private VLAN domain is a member of the primary VLAN. In other words, the primary VLAN is the entire private VLAN domain. Secondary VLANs provide Layer 2 isolation between ports within the same private VLAN domain. There are two types of secondary VLANs:

- Isolated VLANs—Ports within an isolated VLAN cannot communicate with each other at the Layer 2 level.
- Community VLANs—Ports within a community VLAN can communicate with each other but cannot communicate with ports in other communities at the Layer 2 level.

## Private VLAN Ports

There are three types of private VLAN ports:

- **Promiscuous**—A promiscuous port belongs to the primary VLAN and can communicate with all interfaces, including the community and isolated host ports that belong to the secondary VLANs that are associated with the primary VLAN.
- **Isolated**—An isolated port is a host port that belongs to an isolated secondary VLAN. This port has complete Layer 2 isolation from other ports within the same private VLAN domain, except for the promiscuous ports. Private VLANs block all traffic to isolated ports except traffic from promiscuous ports. Traffic received from an isolated port is forwarded only to promiscuous ports.
- **Community**—A community port is a host port that belongs to a community secondary VLAN. Community ports communicate with other ports in the same community VLAN and with promiscuous ports. These interfaces are isolated at Layer 2 from all other interfaces in other communities and from isolated ports within their private VLAN domain.

**Note**

Because trunks can support the VLANs carrying traffic between isolated, community, and promiscuous ports, isolated and community port traffic might enter or leave the switch through a trunk interface.

## Primary, Isolated, and Community VLANs

Primary VLANs and the two types of secondary VLANs, isolated VLANs and community VLANs, have these characteristics:

- **Primary VLAN**— The primary VLAN carries unidirectional traffic downstream from the promiscuous ports to the (isolated and community) host ports and to other promiscuous ports.
- **Isolated VLAN** —A private VLAN domain has only one isolated VLAN. An isolated VLAN is a secondary VLAN that carries unidirectional traffic upstream from the hosts toward the promiscuous ports and the gateway.
- **Community VLAN**—A community VLAN is a secondary VLAN that carries upstream traffic from the community ports to the promiscuous port gateways and to other host ports in the same community. You can configure multiple community VLANs in a private VLAN domain.

A promiscuous port can serve only one primary VLAN, one isolated VLAN, and multiple community VLANs. Layer 3 gateways are connected typically to the switch through a promiscuous port. With a promiscuous port, you can connect a wide range of devices as access points to a private VLAN. For example, you can use a promiscuous port to monitor or back up all the private VLAN servers from an administration workstation.

In a switched environment, you can assign an individual private VLAN and associated IP subnet to each individual or common group of end stations. The end stations need to communicate only with a default gateway to communicate outside the private VLAN.

## Private VLAN Port Isolation

You can use private VLANs to control access to end stations in these ways:

- Configure selected interfaces connected to end stations as isolated ports to prevent any communication at Layer 2. For example, if the end stations are servers, this configuration prevents Layer 2 communication between the servers.
- Configure interfaces connected to default gateways and selected end stations (for example, backup servers) as promiscuous ports to allow all end stations access to a default gateway.

You can extend private VLANs across multiple devices by trunking the primary, isolated, and community VLANs to other devices that support private VLANs. To maintain the security of your private VLAN configuration and to avoid other use of the VLANs configured as private VLANs, configure private VLANs on all intermediate devices, including devices that have no private VLAN ports.

## IP Addressing Scheme with Private VLANs

When you assign a separate VLAN to each customer, an inefficient IP addressing scheme is created as follows:


- Assigning a block of addresses to a customer VLAN can result in unused IP addresses.
- If the number of devices in the VLAN increases, the number of assigned addresses might not be large enough to accommodate them.

These problems are reduced by using private VLANs, where all members in the private VLAN share a common address space, which is allocated to the primary VLAN. Hosts are connected to secondary VLANs, and the DHCP server assigns them IP addresses from the block of addresses allocated to the primary VLAN. Subsequent IP addresses can be assigned to customer devices in different secondary VLANs, but in the same primary VLAN. When new devices are added, the DHCP server assigns them the next available address from a large pool of subnet addresses.

## Private VLANs Across Multiple Switches

As with regular VLANs, private VLANs can span multiple switches. A trunk port carries the primary VLAN and secondary VLANs to a neighboring switch. The trunk port deals with the private VLAN as any other VLAN. A feature of private VLANs across multiple switches is that traffic from an isolated port in switch A does not reach an isolated port on Switch B. (See [Figure 27-2](#).)

**Figure 27-2** Private VLANs Across Switches



VLAN 100 = Primary VLAN  
 VLAN 201 = Secondary isolated VLAN  
 VLAN 202 = Secondary community VLAN

Because VTP versions 1 and 2 do not support private VLANs, you must manually configure private VLANs on all switches in the Layer 2 network. If you do not configure the primary and secondary VLAN association in some switches in the network, the Layer 2 databases in these switches are not merged. This situation can result in unnecessary flooding of private VLAN traffic on those switches.

VTP version 3 does support private VLANs, so you do not need to manually configure private VLANs on all switches in the Layer 2 network.

## Private VLAN Interaction with Other Features

- [Private VLANs and Unicast, Broadcast, and Multicast Traffic, page 27-10](#)
- [Private VLANs and SVIs, page 27-10](#)

## Private VLANs and Unicast, Broadcast, and Multicast Traffic

In regular VLANs, devices in the same VLAN can communicate with each other at the Layer 2 level, but devices connected to interfaces in different VLANs must communicate at the Layer 3 level. In private VLANs, the promiscuous ports are members of the primary VLAN, while the host ports belong to secondary VLANs. Because the secondary VLAN is associated to the primary VLAN, members of the these VLANs can communicate with each other at the Layer 2 level.

In a regular VLAN, broadcasts are forwarded to all ports in that VLAN. Private VLAN broadcast forwarding depends on the port sending the broadcast:

- An isolated port sends a broadcast only to the promiscuous ports or trunk ports.
- A community port sends a broadcast to all promiscuous ports, trunk ports, and ports in the same community VLAN.
- A promiscuous port sends a broadcast to all ports in the private VLAN (other promiscuous ports, trunk ports, isolated ports, and community ports).

Multicast traffic is routed or bridged across private VLAN boundaries and within a single community VLAN. Multicast traffic is not forwarded between ports in the same isolated VLAN or between ports in different secondary VLANs.

## Private VLANs and SVIs

A switch virtual interface (SVI) is the Layer 3 interface of a Layer 2 VLAN. Layer 3 devices communicate with a private VLAN only through the primary VLAN and not through secondary VLANs. Configure Layer 3 VLAN SVIs only for primary VLANs. Do not configure Layer 3 VLAN interfaces for secondary VLANs. SVIs for secondary VLANs are inactive while the VLAN is configured as a secondary VLAN.

- If you try to configure a VLAN with an active SVI as a secondary VLAN, the configuration is not allowed until you disable the SVI.
- If you try to create an SVI on a VLAN that is configured as a secondary VLAN, and the secondary VLAN is already mapped at Layer 3, the SVI is not created, and an error is returned. If the SVI is not mapped at Layer 3, the SVI is created, but it is automatically shut down.

When the primary VLAN is associated with and mapped to the secondary VLAN, any configuration on the primary VLAN is propagated to the secondary VLAN SVIs. For example, if you assign an IP subnet to the primary VLAN SVI, this subnet is the IP subnet address of the entire private VLAN.

## Default Settings for Private VLANs

None.

## How to Configure Private VLANs

- [Configuring a VLAN as a Private VLAN, page 27-11](#)
- [Associating Secondary VLANs with a Primary VLAN, page 27-12](#)
- [Mapping Secondary VLANs to the Layer 3 VLAN Interface of a Primary VLAN, page 27-13](#)
- [Configuring a Layer 2 Interface as a Private VLAN Host Port, page 27-14](#)

- 

If the VLAN is not defined already, the private VLAN configuration process defines it.

To configure a VLAN as a private VLAN, perform this task:

```
Tqwwgt%"eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+% "xncp"662"
Tqwwgt*eqphki/xncp+% "rtkxcvg/xncp"kuqncvgf "
Tqwwgt*eqphki/xncp+% "gpf"
Tqwwgt%"ujqy"xncp"rtkxcvg/xncp"

Rtkoct{"Ugeqpfct{"V{rg"Kpvgthcegu
/////////"/////////"/////////"/////////
424"rtkoc{
"525"eqoowpkv{"
"662"kuqncvgf"
```





## Mapping Secondary VLANs to the Layer 3 VLAN Interface of a Primary VLAN



Note

Isolated and community VLANs are both called secondary VLANs.

To map secondary VLANs to the Layer 3 VLAN interface of a primary VLAN to allow Layer 3 switching of private VLAN ingress traffic, perform this task:

|        | Command                                                                                                                                                                                                                                                                                        | Purpose                                                                                                                              |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%<b>kpvgthceg</b>"xncp"<i>primary_vlan_ID</i></code>                                                                                                                                                                                                                       | Enters interface configuration mode for the primary VLAN.                                                                            |
| Step 2 | <code>Tqvwgt*eqphki/kh+%<b>rtkxcvg/xncp</b>"ocrrkpi"<br/>}ugeqpfct{axncp<span style="color:blue">ankuv</span>"~"<b>cff</b>"ugeqpfct{axncp<span style="color:blue">ankuv</span>"~"<br/><b>tgoq<span style="color:red">xg</span></b>"ugeqpfct{axncp<span style="color:blue">ankuv</span>;</code> | Maps the secondary VLANs to the Layer 3 VLAN interface of a primary VLAN to allow Layer 3 switching of private VLAN ingress traffic. |
|        | <code>Tqvwgt*eqphki/kh+%<b>]</b><b>pq</b>_<b>rtkxcvg/xncp</b>"ocrrkpi"</code>                                                                                                                                                                                                                  | Clears the mapping between the secondary VLANs and the primary VLAN.                                                                 |
| Step 3 | <code>Tqvwgt*eqphki/kh+%<b>gpf</b>"</code>                                                                                                                                                                                                                                                     | Exits configuration mode.                                                                                                            |

When you map secondary VLANs to the Layer 3 VLAN interface of a primary VLAN, note the following information:

- The **private-vlan mapping** interface configuration command only affects private VLAN ingress traffic that is Layer 3-switched.
- The *secondary\_vlan\_list* parameter cannot contain spaces. It can contain multiple comma-separated items. Each item can be a single private VLAN ID or a hyphenated range of private VLAN IDs.
- Enter a *secondary\_vlan\_list* parameter or use the **add** keyword with a *secondary\_vlan\_list* parameter to map the secondary VLANs to the primary VLAN.
- Use the **remove** keyword with a *secondary\_vlan\_list* parameter to clear the mapping between secondary VLANs and the primary VLAN.

This example shows how to permit routing of secondary VLAN ingress traffic from private VLANs 303 through 307, 309, and 440 and verify the configuration:

```
Tqvwgt%eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+%kpvgthceg"xncp"424"
Tqvwgt*eqphki/kh+%rtkxcvg/xncp"ocrrkpi"cff"525/529.52;.662"
Tqvwgt*eqphki/kh+%gpf"
Tqvwgt%ujqy"kpvgthcegu"rtkxcvg/xncp"ocrrkpi"
KpvgthcegUgeqpfct{"XNCP"V{rg
/////////"/////////"/////////"/////////"
xncp424""525""""""""eqoowpkv{
xncp424""526""""""""eqoowpkv{
xncp424""527""""""""eqoowpkv{
xncp424""528""""""""eqoowpkv{
xncp424""529""""""""eqoowpkv{
xncp424""52;.662""""""eqoowpkv{
xncp424""662""""""kuqncvgf

Tqvwgt%
```

## Configuring a Layer 2 Interface as a Private VLAN Host Port

To configure a Layer 2 interface as a private VLAN host port, perform this task:

|        | Command                                                                                                          | Purpose                                                                                                                                                                                                                                                                                                                                                                                                    |
|--------|------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "kpvgthceg" type slot/port</code>                                                          | Selects the LAN port to configure.                                                                                                                                                                                                                                                                                                                                                                         |
| Step 2 | <code>Tqwvgt*eqphki/kh+% "uykvejrgtv"</code>                                                                     | Configures the LAN port for Layer 2 switching. <ul style="list-style-type: none"> <li>You must enter the <b>switchport</b> command once without any keywords to configure the LAN port as a Layer 2 interface before you can enter additional <b>switchport</b> commands with keywords.</li> <li>Required only if you have not entered the <b>switchport</b> command already for the interface.</li> </ul> |
| Step 3 | <code>Tqwvgt*eqphki/kh+% "uykvejrgtv" oqfg"rtkxcvg/xncp" }jquv"~"rtqokuewgwu;</code>                             | Configures the Layer 2 port as a private VLAN host port.                                                                                                                                                                                                                                                                                                                                                   |
| Step 4 | <code>Tqwvgt*eqphki/kh+% "uykvejrgtv" rtkxcvg/xncp" jquv/cuuqekcvkqp" primary_vlan_ID" secondary_vlan_ID"</code> | Associates the Layer 2 port with a private VLAN. <p><b>Note</b> If VLAN locking is enabled, enter the VLAN name instead of the VLAN number. For more information, see the <a href="#">“VLAN Locking” section on page 26-4</a>.</p>                                                                                                                                                                         |
| Step 5 | <code>Tqwvgt*eqphki/kh+% "gpf"</code>                                                                            | Exits configuration mode.                                                                                                                                                                                                                                                                                                                                                                                  |

This example shows how to configure interface GigabitEthernet 5/1 as a private VLAN host port and verify the configuration:

```
Tqwvgt% "eqphkiwtg" vgtokpcn"
Tqwvgt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv"713"
Tqwvgt*eqphki/kh+% "uykvejrgtv" oqfg"rtkxcvg/xncp"jquv"
Tqwvgt*eqphki/kh+% "uykvejrgtv" rtkxcvg/xncp"jquv/cuuqekcvkqp"424"525"
Tqwvgt*eqphki/kh+% "gpf"
Tqwvgt% "ujqy"kpvgthcegu" ikicdkvgvjgtpgv"713"uykvejrgtv"~"kpenwfg"rtkxcvg/xncp"
Cfokpkuvtcvkxg"Oqfg<" rtkxcvg/xncp"jquv
Cfokpkuvtcvkxg"rtkxcvg/xncp"jquv/cuuqekcvkqp<"424"*XNCP2424+"525"*XNCP2525+"
Cfokpkuvtcvkxg"rtkxcvg/xncp"ocrrkpi<"pppg"
Qrgtcvkqpcn"rtkxcvg/xncp<"pppg"
```

## Configuring a Layer 2 Interface as a Private VLAN Promiscuous Port

To configure a Layer 2 interface as a private VLAN promiscuous port, perform this task:

|        | Command                                                                                                                                                                                                                                                | Purpose                                                                                                                                                                                                                                                                                                                                                                                                              |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+% "kpvgthceg" v{rg" slot/port"</code>                                                                                                                                                                                              | Selects the LAN interface to configure.                                                                                                                                                                                                                                                                                                                                                                              |
| Step 2 | <code>Tqwwgt*eqphki/kh+% "uykvejrgtv"</code>                                                                                                                                                                                                           | Configures the LAN interface for Layer 2 switching: <ul style="list-style-type: none"> <li>You must enter the <b>switchport</b> command once without any keywords to configure the LAN interface as a Layer 2 interface before you can enter additional <b>switchport</b> commands with keywords.</li> <li>Required only if you have not entered the <b>switchport</b> command already for the interface.</li> </ul> |
| Step 3 | <code>Tqwwgt*eqphki/kh+% "uykvejrgtv" oqfg" rtkxcvg/xncp" }jqv" ~ "rtqokuewqwu;</code>                                                                                                                                                                 | Configures the Layer 2 port as a private VLAN promiscuous port.                                                                                                                                                                                                                                                                                                                                                      |
| Step 4 | <code>Tqwwgt*eqphki/kh+% "uykvejrgtv" rtkxcvg/xncp" ocrkpi "primary_vlan_ID" }ugeqpfct {axncpankuv" ~ "cfff" ugeqpfct {axncpankuv" ~ "tgoqyg" ugeqpfct {axncpankuv;</code><br><br><code>Tqwwgt*eqphki/kh+% "pq"uykvejrgtv" rtkxcvg/xncp" ocrkpi</code> | Maps the private VLAN promiscuous port to a primary VLAN and to selected secondary VLANs.<br><br><b>Note</b> If VLAN locking is enabled, enter the VLAN name instead of the VLAN number. For more information, see the <a href="#">“VLAN Locking” section on page 26-4</a> .<br><br>Clears all mapping between the private VLAN promiscuous port and the primary VLAN and any secondary VLANs.                       |
| Step 5 | <code>Tqwwgt*eqphki/kh+% "gpf"</code>                                                                                                                                                                                                                  | Exits configuration mode.                                                                                                                                                                                                                                                                                                                                                                                            |

When you configure a Layer 2 interface as a private VLAN promiscuous port, note the following information:

- The *secondary\_vlan\_list* parameter cannot contain spaces. It can contain multiple comma-separated items. Each item can be a single private VLAN ID or a hyphenated range of private VLAN IDs.
- If VLAN locking is enabled, enter VLAN names instead of VLAN numbers in the *secondary\_vlan\_list*. When entering a range of VLAN names, you must leave spaces between the VLAN names and the dash.
- Enter a *secondary\_vlan\_list* value or use the **add** keyword with a *secondary\_vlan\_list* value to map the secondary VLANs to the private VLAN promiscuous port.
- Use the **remove** keyword with a *secondary\_vlan\_list* value to clear the mapping between secondary VLANs and the private VLAN promiscuous port.

This example shows how to configure interface GigabitEthernet 5/2 as a private VLAN promiscuous port and map it to a private VLAN:

```
Tqwwgt% "eqphkiwtg" vgtokpcn"
Tqwwgt*eqphki+% "kpvgthceg" iki cdkvgvjgtpgv" 714 "
Tqwwgt*eqphki/kh+% "uykvejrgtv" oqfg" rtkxcvg/xncp" rtqokuewqwu"
Tqwwgt*eqphki/kh+% "uykvejrgtv" rtkxcvg/xncp" ocrkpi "424" 525.662 "
Tqwwgt*eqphki/kh+% "gpf"
```

Tqwgvtg%**"ujqy"kpvgthcegu"ikicdkvgvjgtpgv"714"uykvejrgtv"~"kpenwfg"rtkxcvg/xncp"**  
Cfokpkuvtcvkxg"Oqfg<"rtkxcvg/xncp"rtqokuewqwu  
Cfokpkuvtcvkxg"rtkxcvg/xncp"jquv/cuudekcvkqp<"pppg"\*Kpcevkgxg++  
Cfokpkuvtcvkxg"rtkxcvg/xncp"ocrrkpi<"424"\*XNCP2424+"525"\*XNCP2525+"662"\*XNCP2662+"  
Qrgtcvkqpcn"rtkxcvg/xncp<"pppg"

Table 27-1 shows the privileged EXEC commands for monitoring private VLAN activity.

| Command                                    | Purpose                                                                      |
|--------------------------------------------|------------------------------------------------------------------------------|
| <b>show interfaces status</b>              | Displays the status of interfaces, including the VLANs to which they belong. |
| <b>show vlan private-vlan [type]</b>       | Displays the private VLAN information for the switch.                        |
| <b>show interface switchport</b>           | Displays private VLAN configuration on interfaces.                           |
| <b>show interface private-vlan mapping</b> | Displays information about the private VLAN mapping for VLAN SVIs.           |

```
Uykvej*eqphki+%"ujqy"xncp"rtkxcvg/xncp"
Rtkoct{"Ugeqpfct{"V{rg"////////////////////
////////////////////
32"723"kuqncvgf"Ik413."Ik513."Ik514
32"724"eqoowpkv{"Ik4133."Ik513."Ik516
32"725"pqp/grgtcvkqpcn
```



Participate in the Technical Documentation Ideas forum



## Private Hosts

---

- [Prerequisites for Private Hosts, page 28-1](#)
- [Restrictions for Private Hosts, page 28-1](#)
- [Information About Private Hosts, page 28-4](#)
- [How to Configure Private Hosts, page 28-8](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for Private Hosts

None.

## Restrictions for Private Hosts

- [General Private Host Restrictions, page 28-2](#)
- [Private Host ACL Restrictions, page 28-2](#)
- [Private Host VLAN on Trunk Port Restrictions, page 28-3](#)
- [Private Host Interaction with Other Features, page 28-3](#)
- [Private Host Spoofing Protection, page 28-3](#)

- [Private Host Multicast Operation, page 28-4](#)

## General Private Host Restrictions

- Private hosts and private VLANs cannot both be configured on the same port (interface). Both features can coexist on the switch, but each feature must be configured on different ports.
- Private hosts is an end-to-end feature. You must enable the feature on all of the switches between the DSLAMs and an upstream device such as a BRAS or a multicast server.
- Only trusted ports can be configured as isolated ports.
- The private hosts feature is supported on Layer 2 interfaces that are configured as trunking switch ports.
- The private hosts feature is supported on port-channel interfaces (EtherChannel, Fast EtherChannel, and Gigabit EtherChannel). You must enable private hosts on the port-channel interface; you cannot enable the feature on member ports.
- DAI and DHCP snooping cannot be enabled on a private hosts port unless all of the VLANs on the port are configured for snooping.

## Private Host ACL Restrictions

- This release of the private hosts feature uses protocol-independent MAC ACLs.  
Do not apply IP-based ACLs to any port configured for private hosts or you will defeat the private hosts feature (because the switch will not be able to apply a private hosts MAC ACL to the port).
- You can configure the following interface types for protocol-independent MAC ACL filtering:
  - VLAN interfaces with no IP address
  - Physical LAN ports that support EoMPLS
  - Logical LAN subinterfaces that support EoMPLS
- Protocol-independent MAC ACL filtering applies MAC ACLs to all ingress traffic types (for example, IPv4 traffic, IPv6 traffic, and MPLS traffic, in addition to MAC-layer traffic).
- Ingress traffic that is permitted or denied by a protocol-independent MAC ACL is processed by egress interfaces as MAC-layer traffic. You cannot apply egress IP ACLs to traffic permitted or denied by a MAC ACL on an interface configured for protocol-independent MAC ACL filtering.
- Do not configure protocol-independent MAC ACL filtering on VLAN interfaces where you have configured an IP address.
- Do not configure protocol-independent MAC ACL filtering with microflow policing when the permitted traffic would be bridged or Layer 3 switched in hardware by the PFC or a DFC.
- Protocol-independent MAC ACL filtering supports microflow policing when the permitted traffic is routed in software.
- To prevent any existing VLAN ACLs (VACLs) and routing ACLs (RACLs) from interfering with the PACL on the trunk port, configure the access group mode of the trunk port interface as prefer port mode. Do not apply any VACLs or RACLs to a port configured for private hosts.

## Private Host VLAN on Trunk Port Restrictions

- You can enable IGMP snooping on VLANs that use trunk ports configured for private hosts.
- You cannot enable IP multicast on a VLAN that uses a trunk port that is configured for private hosts.
- Because PACLS operate in override mode on trunk ports, you cannot apply VLAN-based features to switch ports.
- The Multicast VLAN Registration (MVR) feature can coexist with private hosts as long as the multicast source exists on a promiscuous port.

## Private Host Interaction with Other Features

- Private hosts do not affect Layer 2-based services such as MAC limiting, unicast flood protection (UFP), or unknown unicast flood blocking (UUFB).
- The private hosts features does not affect IGMP snooping. However, if IGMP snooping is globally disabled, IGMP control packets will be subject to ACL checks. To permit IGMP control packets, the private hosts software adds a multicast permit statement to the PACLS for isolated hosts. This operation occurs automatically and no user intervention is required.
- Port security can be enabled on isolated ports to provide added security to those ports.
- When enabled on promiscuous or mixed-mode ports, the port security feature may restrict a change in source port for an upstream device (such as a BRAS or a multicast server).
- When enabled on an access port, 802.1X is not affected by the private hosts feature.

## Private Host Spoofing Protection

The private hosts feature prevents MAC address spoofing but does not validate the customer MAC or IP address. To prevent MAC address spoofing, the private hosts feature does the following:

- Uses a static MAC address for a BRAS or a multicast server.
- Disables learning in the Layer 2 forwarding table.
- Alerts the switch software when a BRAS or multicast server moves from one source port to another. The software then validates the move and updates the Layer 2 forwarding table.

## Private Host Multicast Operation

Multicast traffic that originates from an upstream device (such as a BRAS or a multicast server) is always permitted. In addition, the private hosts PACLs are not applied to multicast control packets (such as IGMP query and join requests). This operation allows isolated hosts to participate in multicast groups, respond to IGMP queries, and receive traffic from any groups of interest.

Multicast traffic that originates from a host is dropped by the private hosts PACLs. However, if other hosts need to receive multicast traffic originating from a host, the private hosts feature adds a *multicast permit* entry to the PACLs.

## Information About Private Hosts

- [Private Hosts Overview, page 28-4](#)
- [Isolating Hosts in a VLAN, page 28-4](#)
- [Restricting Traffic Flow \(Using Private Hosts Port Mode and PACLs\), page 28-5](#)
- [Port ACLs, page 28-7](#)

## Private Hosts Overview

Service providers typically deliver triple-play services (voice, video, and data) using three different VLANs over a single physical interface for each end user. The service infrastructure would be simpler and more scalable if the service provider could deploy a single set of VLANs to multiple end users for the same set of services, but the service provider must be able to isolate traffic between the users (hosts) at Layer 2. The private hosts feature provides this isolation, allowing VLAN sharing among multiple end users.

The private hosts feature provides these key benefits:

- Isolates traffic among hosts (subscribers) that share the same VLAN ID.
- Reuses VLAN IDs across different subscribers, which improves VLAN scalability by making better use of the 4096 VLANs allowed.
- Prevents media access control (MAC) address spoofing to prevent denial of service (DOS) attacks.

The private hosts feature uses protocol-independent port-based access control lists (PACLs) to provide Layer 2 isolation between hosts on trusted ports within a strictly Layer 2 domain. The PACLs isolate the hosts by imposing Layer 2 forwarding constraints on the switch ports.

## Isolating Hosts in a VLAN

By isolating the hosts, a service provider can use a single set of VLANs to deliver the same set of broadband or metro Ethernet services to multiple end users while ensuring that none of the hosts in the VLAN can communicate directly with each other. For example, VLAN 10 can be used for voice traffic, VLAN 20 for video traffic, and VLAN 30 for data traffic.


When the switch is used as a Digital Subscriber Line Access Multiplexer (DSLAM) gigabit Ethernet aggregator, the DSLAM is connected to the switch through a trunk port that can carry data for multiple VLANs. The service provider uses a single physical port and a single set of VLANs to deliver the same set of services to different end users (isolated hosts). A separate VLAN is used for each service (voice, video, and data).



Figure 28-1 shows an example of triple-play services being delivered from the switch to multiple end users attached to a DSLAM. In the figure, note the following:

- A single trunk link between the switch and the DSLAM carries traffic for all three VLANs.
- Virtual circuits (VCs) deliver the VLAN traffic from the DSLAM to individual end users.

Figure 28-1 VC to VLAN Mapping



|   |                                                                                                                       |   |                                                                                      |
|---|-----------------------------------------------------------------------------------------------------------------------|---|--------------------------------------------------------------------------------------|
| 1 | The trunk link carries:                                                                                               | 2 | The DSLAM maps voice, video, and data traffic between VLANs and VCs.                 |
|   |                                                                                                                       | 3 | Individual VCs carry voice, video, and data traffic between the DSLAM and each host. |
|   | <ul style="list-style-type: none"> <li>• One voice VLAN</li> <li>• One video VLAN</li> <li>• One data VLAN</li> </ul> |   |                                                                                      |

## Restricting Traffic Flow (Using Private Hosts Port Mode and PACLs)

The private hosts feature uses PACLs to restrict the type of traffic that is allowed to flow through each of the ports configured for private hosts. A port's mode (specified when you enable private hosts on the port) determines what type of PACL is applied to the port. Each type of PACL restricts the traffic flow for a different type of traffic (for example, from content servers to isolated hosts, from isolated hosts to servers, and traffic between isolated hosts).

The following list describes the port modes used by the private hosts feature (see Figure 28-2):

- **Isolated**—Ports connected to the DSLAMs that the end users (isolated hosts) are connected to. The hosts on the VLANs on these ports need to be isolated from each other. Hosts connected through these ports are allowed to pass unicast traffic to upstream devices only.
- **Promiscuous**—Ports that face the core network or the Broadband Remote Access Server (BRAS) devices and multicast servers that are providing the broadband services.


- **Mixed**—Ports that interconnect switches. These ports can function as either isolated ports or promiscuous ports, depending on Spanning Tree Protocol (STP) topology changes. These ports allow unicast traffic to upstream devices (such as a BRAS or multicast server) only.

The private hosts feature restricts traffic flow in these ways:

- Broadcast traffic at the ingress of the service provider network is redirected to BRAS and multicast servers (such as video servers).
- All unicast traffic between access switches (switches connected to each other) is blocked except for traffic directed toward a BRAS or a multicast server.
- The unknown unicast flood blocking (UUFb) feature is used to block unknown unicast traffic on DSLAM-facing ports.

Figure 28-2 shows the different types of port modes (isolated, promiscuous, and mixed) used in a private hosts configuration.

**Figure 28-2** Private Hosts Port Types (Modes)



|                                                                                                                                                                                                                          |                   |                                                                                                                                                                                                                                              |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1                                                                                                                                                                                                                        | Promiscuous ports | Permit all traffic from a BRAS to hosts.                                                                                                                                                                                                     |
| 2                                                                                                                                                                                                                        | Mixed ports       | Permit broadcast traffic from a BRAS.<br>Redirect broadcast traffic from hosts to promiscuous and mixed-mode ports.<br>Permit traffic from a BRAS to hosts and from hosts to a BRAS.<br>Deny all other host to host traffic.                 |
| 3                                                                                                                                                                                                                        | Isolated ports    | Permit unicast traffic from host to a BRAS only; block unicast traffic between ports.<br>Redirect all broadcast traffic from host to a BRAS.<br>Deny traffic from a BRAS (to prevent spoofing).<br>Permit multicast traffic (IPv4 and IPv6). |
| <b>Note</b> In this description of port types, the term BRAS represents an upstream devices such as a BRAS, a multicast server (such as a video server), or a core network device that provides access to these devices. |                   |                                                                                                                                                                                                                                              |

## Port ACLs

The private hosts feature creates several types of port ACLs (PACLs) to impose Layer 2 forwarding constraints on switch ports. The software creates PACLs for the different types of private hosts ports based on the MAC addresses of the content servers providing broadband services and the VLAN IDs of the isolated hosts to deliver those services to. You specify the mode in which each private hosts port is to operate and the software applies the appropriate PACL to the port based on the port's mode (isolated, promiscuous, or mixed).

The following are examples of the different types of PACLs that are used by the private hosts feature.

### Isolated Hosts PACL

This example shows a PACL for isolated ports:

```
fgp{"jquv"DTCUaOCE"cp{"
rgtokv"cp{"jquv"DTCUaOCE"
tgfktgev"cp{"jquv"HHHH0HHHH0HHHH"vq"NVNKpfgz"8"
rgtokv"cp{"232207G2202222122220229H0HHHH"
rgtokv"cp{"5555022220222212220HHHH0HHHH"
fgp{"cp{"cp{"
```

### Promiscuous Port PACL

This example shows a PACL for promiscuous ports:

```
rgtokv"jquv"DTCUaOCE"cp{
fgp{"cp{"cp{"
```

### Mixed Port PACL

This example shows a PACL for mixed ports:

```
rgtokv"jquv"DTCUaOCE"hhhh0hhhh0hhhh"
tgfktgev"cp{"jquv"HHHH0HHHH0HHHH"vq"NVNKpfgz"8"
```

```
rgtokv"jqv"DTCUaOCE"cp{ "
rgtokv"cp{ "jqv"DTCUaOCE"
fgp{ "cp{ "cp{
```

## Default Settings for Private Hosts

None.

## How to Configure Private Hosts

- [Configuration Summary, page 28-8](#)
- [Detailed Configuration Steps, page 28-9](#)
- [Configuration Examples, page 28-11](#)

### Configuration Summary

1. Determine which switch ports (interfaces) to use for the private hosts feature. You can configure the feature on trunking switch ports or port-channel interfaces. Private hosts must be enabled on the port-channel interface; you cannot enable the feature on member ports.
2. Configure each port (interface) for normal, non-private hosts service. Configure the access group mode of the port as prefer port mode. You can configure the VLANs at this step or later.
3. Determine which VLAN or set of VLANs will be used to deliver broadband services to end users. The private hosts feature will provide Layer 2 isolation among the hosts in these VLANs.
4. Identify the MAC addresses of all of the BRASs and multicast servers that are being used to provide broadband services to end users (isolated hosts).




---

**Note** If a server is not connected directly to the switch, determine the MAC address of the core network device that provides access to the server.

---

5. (Optional) If you plan to offer different types of broadband service to different sets of isolated hosts, create multiple MAC and VLAN lists.
  - Each MAC address list identifies a server or set of servers providing a particular type of service.
  - Each VLAN list identifies the isolated hosts to deliver that service to.
6. Configure promiscuous ports and specify a MAC and VLAN list to identify the server and receiving hosts for a particular type of service.




---

**Note** You can specify multiple MAC and VLAN combinations to allow different types of services to be delivered to different sets of hosts. For example, the BRAS at xxxx.xxxx.xxxx could be used to deliver a basic set of services over VLANs 20, 25, and 30, and the BRAS at yyyy.yyyy.yyyy could be used to deliver a premium set of services over VLANs 5, 10, and 15.

---

7. Globally enable private hosts.

8. Enable private hosts on individual ports (interfaces) and specify the mode in which the port is to operate. To determine port mode, you need to know if the port faces upstream (toward content servers or core network), faces downstream (toward DSLAM and isolated hosts), or is connected to another switch (typically, in a ring topology). See the “[Restricting Traffic Flow \(Using Private Hosts Port Mode and PACLs\)](#)” section on page 28-5.

After you enable the feature on individual ports, the switch is ready to run the private hosts feature. The private hosts software uses the MAC and VLAN lists you defined to create the isolated, promiscuous, and mixed-mode PACLs for your configuration. The software then applies the appropriate PACL to each private hosts port based on the port's mode.

## Detailed Configuration Steps

To configure the private hosts feature, perform the following steps. These steps assume that you have already configured the Layer 2 interfaces that you plan for private hosts.



**Note**

You can configure private hosts only on trunking switch ports or EtherChannel ports. In addition, you must enable private hosts on all of the switches between the DSLAMs and upstream devices.

|        | Command or Action                                                                                                       | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------|-------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt% "eqphkiwtg"vgtokpcn"</code>                                                                               | Enters global configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Step 2 | <code>Tqwvgt*eqphki+% "rtkxcvg/jquvu"<br/>oce/nkuv oceankuvapcog"oceacfftguu"<br/>]tgocm device-name"~"eqoogpv_"</code> | <p>Creates a list of MAC addresses that identify the BRAS and multicast servers providing broadband services.</p> <ul style="list-style-type: none"> <li><code>mac_list_name</code> specifies a name to assign to this list of content servers.</li> <li><code>mac_address</code> identifies the BRAS or multicast server (or set of servers) providing a particular broadband service or set of services.</li> <li><b>remark</b> allows you to specify an optional device name or comment to assign to this MAC list.</li> </ul> <p>Specify the MAC address of every content server being used to deliver services. If you plan to offer different types of services to different sets of hosts, create a separate MAC list for each server or set of servers providing a particular service.</p> <p><b>Note</b> If a server is not directly connected to the switch, specify the MAC address of the core network device that provides access to the server.</p> |
| Step 3 | <code>Tqwvgt*eqphki+% "rtkxcvg/jquvu"xncp/nkuv"<br/>vlan-IDs"</code>                                                    | <p>Creates a list of the VLANs (<i>vlan-IDs</i>) whose hosts need to be isolated so that the hosts can receive broadband services.</p> <p>Create separate VLAN lists if you plan to offer particular services to different sets of hosts. Otherwise, all of the broadband services will be delivered to all isolated hosts.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

|        | Command or Action                                                                               | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|--------|-------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 4 | <code>Tqwgvt*eqphki+% "rtkxcvg/jquvu"rtqokuewqwu"<br/>mac-list-name"]xncp/nkuv"vlan-IDs_</code> | <p>Identifies the content servers for broadband services and the end users (isolated hosts) to which to deliver the services.</p> <ul style="list-style-type: none"> <li><i>mac-list-name</i> specifies the name of the MAC address lists that identifies the BRAS or multicast server (or set of servers) providing a particular type of broadband service or set of services.</li> <li><i>vlan-IDs</i> identifies the VLAN or set of VLANs whose hosts are to receive services from the above servers. If no VLAN list is specified, the software uses the global VLAN list (configured in Step 3).</li> </ul> <p><b>Note</b> You can enter this command multiple times to configure multiple MAC and VLAN combinations, each defining the server and receiving hosts for a particular type of service.</p> |
| Step 5 | <code>Tqwgvt*eqphki+% "rtkxcvg/jquvu"</code>                                                    | Globally enables private hosts on the switch.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Step 6 | <code>Tqwgvt*eqphki+% "kpvgtthceg" kpvgtthceg"</code>                                           | Selects the trunking switch port or EtherChannel to enable for private hosts.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Step 7 | <code>Tqwgvt*eqphki/kh+% "ceeguu/itqwr"oqfg"rtghgt"<br/>rqtv</code>                             | <p>Specifies that any existing VACLs or RACLs on the trunk port will be ignored.</p> <p> <b>Note</b> If a PACL is configured on a Layer 2 interface, the PACL takes effect and overwrites the effect of other ACLs (Cisco IOS ACL and VACL). To prevent any existing VLAN ACLs (VACLs) and Routing ACLs (RACLs) from interfering with the PACL on the trunk port, configure the access group mode of the trunk port interface as prefer port mode.</p>                                                                                                                                                                                                                                                                      |
| Step 8 | <code>Tqwgvt*eqphki/kh+% "rtkxcvg/jquvu"oqfg"<br/>}rtqokuewqwu"~"kuqncvgf"~"okzgf;"</code>      | <p>Enables private hosts on the port. Use one of the following keywords to define the mode that the port is to operate in:</p> <ul style="list-style-type: none"> <li><b>promiscuous</b>—Upstream-facing ports that connect to broadband servers (BRAS, multicast, or video) or to core network devices providing access to the servers.</li> <li><b>isolated</b>—Ports that connect to DSLAMs.</li> <li><b>mixed</b>—Ports that connect to other switches, typically in a ring topology.</li> </ul> <p><b>Note</b> You must perform this step on each port being used for private hosts.</p>                                                                                                                                                                                                                 |
| Step 9 | <code>Tqwgvt*eqphki/kh+% "gpf"</code>                                                           | Exits interface and global configuration modes and returns to privileged EXEC mode. Private Hosts configuration is complete.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

## Configuration Examples

The following example creates a MAC address list and a VLAN list and isolates the hosts in VLANs 10, 12, 15, and 200 through 300. The BRAS-facing port is made promiscuous and two host-connected ports are made isolated:

```
Tqvvgt% "eqphkiwtg"vgtokpcn"
Tqvvgt*eqphki+% "rtkxcvg/jquvu"oce/nkuv"DTCUankuv"22220333303333"tgocm"DTCUaUcpLqug
Tqvvgt*eqphki+% "rtkxcvg/jquvu"xncp/nkuv"32.34.37.422/522
Tqvvgt*eqphki+% "rtkxcvg/jquvu"rtqokuewqwu"DTCUankuv"xncp/nkuv"32.34.37.422/522
Tqvvgt*eqphki+% "rtkxcvg/jquvu"
Tqvvgt*eqphki+% "kpvgtthceg"iki"614"
Tqvvgt*eqphki/kh+% "rtkxcvg/jquvu"oqfg"rtqokuewqwu"
Tqvvgt*eqphki/kh+% "gzkv"
Tqvvgt*eqphki+% "kpvgtthceg"iki"714"
Tqvvgt*eqphki/kh+% "rtkxcvg/jquvu"oqfg"kuqncvgf"
Tqvvgt*eqphki/kh+% "gzkv"
Tqvvgt*eqphki+% "kpvgtthceg"iki"715"
Tqvvgt*eqphki/kh+% "rtkxcvg/jquvu"oqfg"kuqncvgf"
Tqvvgt*eqphki/kh+% "gpf"
Tqvvgt%
```

The following example shows the interface configuration of a private hosts isolated port:

```
Tqvvgt% "ujqy"twp"kpvgtthceg"iki"714"
Dwknfkpi "eqphkiwtcvkqp000

Ewttgvp"eqphkiwtcvkqp"<"422"d{vgu
#
kpvgtthceg"IkicdkvGvjgtpgv714
 uykvejrtv
 uykvejrtv"vtwpm"gpecruwncvkqp"fqv3s
 uykvejrtv"oqfg"vtwpm
 ceeguu/itqwr"oqfg"rtghgt"rqtv
 rtkxcvg/jquvu"oqfg"kuqncvgf
gpf
```

The following example shows the interface configuration of a private hosts promiscuous port:

```
Tqvvgt% "ujqy"twp"kpvgtthceg"iki"614"
Dwknfkpi "eqphkiwtcvkqp000

Ewttgvp"eqphkiwtcvkqp"<"3:; "d{vgu
#
kpvgtthceg"IkicdkvGvjgtpgv614
 uykvejrtv
 uykvejrtv"ceeguu"xncp"422
 uykvejrtv"oqfg"ceeguu
 rtkxcvg/jquvu"oqfg"rtqokuewqwu
gpf

rtkxcvg/jquvu
rtkxcvg/jquvu"xncp/nkuv"422
rtkxcvg/jquvu"rtqokuewqwu"dtcu/nkuv
rtkxcvg/jquvu"oce/nkuv"dtcu/nkuv"22220333303333"tgocm"DTCU/UGTXGT
```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





# IEEE 802.1Q Tunneling

- [Prerequisites for 802.1Q Tunneling, page 29-1](#)
- [Restrictions for 802.1Q Tunneling, page 29-1](#)
- [Information About 802.1Q Tunneling, page 29-4](#)
- [Default Settings for 802.1Q Tunneling, page 29-5](#)
- [How to Configure 802.1Q Tunneling, page 29-6](#)



## Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for 802.1Q Tunneling

None.

## Restrictions for 802.1Q Tunneling

- Use asymmetrical links to put traffic into a tunnel or to remove traffic from a tunnel.
- Configure tunnel ports only to form an asymmetrical link.
- Dedicate one VLAN for each tunnel.

- Assign only tunnel ports to VLANs used for tunneling.
- Trunks require no special configuration to carry tunnel VLANs.
- Tunnel ports are not trunks. Any commands to configure trunking are inactive while the port is configured as a tunnel port.
- Tunnel ports learn customer MAC addresses.
- We recommend that you use ISL trunks to carry tunnel traffic between devices that do not have tunnel ports. Because of the 802.1Q native VLAN feature, using 802.1Q trunks requires that you be very careful when you configure tunneling: a mistake might direct tunnel traffic to a non-tunnel port.
- By default, the native VLAN traffic of a dot1q trunk is sent untagged, which cannot be double-tagged in the service provider network. Because of this situation, the native VLAN traffic might not be tunneled correctly. Be sure that the native VLAN traffic is always sent tagged in an asymmetrical link. To tag the native VLAN egress traffic and drop all untagged ingress traffic, enter the global **vlan dot1q tag native** command.
- Configure jumbo frame support on tunnel ports:
  - See the [“Configuring Jumbo Frame Support” section on page 10-6](#).
  - Take note of the modules listed in the “Configuring Jumbo Frame Support” section that do not support jumbo frames.
- Jumbo frames can be tunneled as long as the jumbo frame length combined with the 802.1Q tag does not exceed the maximum frame size.
- Because tunnel traffic has the added ethertype and length field and retains the 802.1Q tag within the switch, the following restrictions exist:
  - The Layer 3 packet within the Layer 2 frame cannot be identified in tunnel traffic.
  - Layer 3 and higher parameters cannot be identified in tunnel traffic (for example, Layer 3 destination and source addresses).
  - Because the Layer 3 addresses cannot be identified within the packet, tunnel traffic cannot be routed.
  - The switch can provide only MAC-layer filtering for tunnel traffic (VLAN IDs and source and destination MAC addresses).
  - The switch can provide only MAC-layer access control and QoS for tunnel traffic.
  - QoS cannot detect the received CoS value in the 802.1Q 2-byte Tag Control Information field.
- On an asymmetrical link, the Cisco Discovery Protocol (CDP) reports a native VLAN mismatch if the VLAN of the tunnel port does not match the native VLAN of the 802.1Q trunk. The 802.1Q tunnel feature does not require that the VLANs match. Ignore the messages if your configuration requires nonmatching VLANs.
- Asymmetrical links do not support the Dynamic Trunking Protocol (DTP) because only one port on the link is a trunk. Configure the 802.1Q trunk port on an asymmetrical link to trunk unconditionally.
- The 802.1Q tunneling feature cannot be configured on ports configured to support private VLANs.
- The 802.1Q tunneling feature cannot be configured on ports configured to support EVCs.
- The following Layer 2 protocols work between devices connected by an asymmetrical link:
  - CDP
  - UniDirectional Link Detection (UDLD)
  - Port Aggregation Protocol (PAgP)
  - Link Aggregation Control Protocol (LACP)

- PortFast BPDU filtering is enabled automatically on tunnel ports.
- CDP is automatically disabled on tunnel ports.
- VLAN Trunk Protocol (VTP) does not work between the following devices:
  - Devices connected by an asymmetrical link
  - Devices communicating through a tunnel



**Note** VTP works between tunneled devices if Layer 2 protocol tunneling is enabled. See [Chapter 30, “Layer 2 Protocol Tunneling,”](#) for configuration details.

- To configure an EtherChannel as an asymmetrical link, all ports in the EtherChannel must have the same tunneling configuration. Because the Layer 3 packet within the Layer 2 frame cannot be identified, you must configure the EtherChannel to use MAC-address-based frame distribution.

The following configuration guidelines are *required* for your Layer 2 protocol tunneling configuration:

- On all the service provider edge switches, PortFast BPDU filtering must be enabled on the 802.1Q tunnel ports as follows:

```
Tqvwgt*eqphki/kh+% "urcappkpi/vtgg"drfwhknvgt"gpdcng"
Tqvwgt*eqphki/kh+% "urcappkpi/vtgg"rqtvhcuv
```



**Note** PortFast BPDU filtering is enabled automatically on tunnel ports.

- At least one VLAN must be available for native VLAN tagging (**vlan dot1q tag native** option). If you use all the available VLANs and then try to enable the **vlan dot1q tag native** option, the option will not be enabled.
- On all the service provider core switches, tag native VLAN egress traffic and drop untagged native VLAN ingress traffic by entering the following command:

```
Tqvwgt*eqphki+% "xnep"fqv3s"vci"pcvkxg
```

- On all the customer switches, *either* enable or disable the global **vlan dot1q tag native** option.



**Note** If this option is enabled on one switch and disabled on another switch, all traffic is dropped; all customer switches must have this option configured the same on each switch.

The following configuration guidelines are *optional* for your Layer 2 protocol tunneling configuration:

- Because all the BPDUs are being dropped, spanning tree PortFast can be enabled on Layer 2 protocol tunnel ports as follows:

```
Tqvwgt*eqphki/kh+% "urcappkpi/vtgg"rqtvhcuv"vtwpm
```

- If the service provider does not want the customer to see its switches, CDP should be disabled on the 802.1Q tunnel port as follows:

```
Tqvwgt*eqphki/kh+% "pq"efr"gpdcng"
```

## Information About 802.1Q Tunneling

802.1Q tunneling enables service providers to use a single VLAN to support customers who have multiple VLANs, while preserving customer VLAN IDs and keeping traffic in different customer VLANs segregated.

A port configured to support 802.1Q tunneling is called a tunnel port. When you configure tunneling, you assign a tunnel port to a VLAN that you dedicate to tunneling, which then becomes a tunnel VLAN. To keep customer traffic segregated, each customer requires a separate tunnel VLAN, but that one tunnel VLAN supports all of the customer's VLANs.

802.1Q tunneling is not restricted to point-to-point tunnel configurations. Any tunnel port in a tunnel VLAN is a tunnel entry and exit point. An 802.1Q tunnel can have as many tunnel ports as are needed to connect customer switches.

The customer switches are trunk connected, but with 802.1Q tunneling, the service provider switches only use one service provider VLAN to carry all the customer VLANs, instead of directly carrying all the customer VLANs.

With 802.1Q tunneling, tagged customer traffic comes from an 802.1Q trunk port on a customer device and enters the service-provider edge switch through a tunnel port. The link between the 802.1Q trunk port on a customer device and the tunnel port is called an asymmetrical link because one end is configured as an 802.1Q trunk port and the other end is configured as a tunnel port. You assign the tunnel port to an access VLAN ID unique to each customer. See [Figure 29-1 on page 29-4](#) and [Figure 29-2 on page 29-5](#).

**Figure 29-1 IEEE 802.1Q Tunnel Ports in a Service-Provider Network**





Figure 29-2 Untagged, 802.1Q-Tagged, and Double-Tagged Ethernet Frames



When a tunnel port receives tagged customer traffic from an 802.1Q trunk port, it does not strip the received 802.1Q tag from the frame header; instead, the tunnel port leaves the 802.1Q tag intact, adds a 2-byte Ethertype field (0x8100) followed by a 2-byte field containing the priority (CoS) and the VLAN. The received customer traffic is then put into the VLAN to which the tunnel port is assigned. This Ethertype 0x8100 traffic, with the received 802.1Q tag intact, is called tunnel traffic.

A VLAN carrying tunnel traffic is an 802.1Q tunnel. The tunnel ports in the VLAN are the tunnel's ingress and egress points.

The tunnel ports do not have to be on the same network device. The tunnel can cross other network links and other network devices before reaching the egress tunnel port. A tunnel can have as many tunnel ports as required to support the customer devices that need to communicate through the tunnel.

An egress tunnel port strips the 2-byte Ethertype field (0x8100) and the 2-byte length field and transmits the traffic with the 802.1Q tag still intact to an 802.1Q trunk port on a customer device. The 802.1Q trunk port on the customer device strips the 802.1Q tag and puts the traffic into the appropriate customer VLAN.



Note

Tunnel traffic carries a second 802.1Q tag only when it is on a trunk link between service-provider network devices, with the outer tag containing the service-provider-assigned VLAN ID and the inner tag containing the customer-assigned VLAN IDs.

## Default Settings for 802.1Q Tunneling

None.

# How to Configure 802.1Q Tunneling

- [Configuring 802.1Q Tunnel Ports, page 29-6](#)
- [Configuring the Switch to Tag Native VLAN Traffic, page 29-6](#)



## Caution

Ensure that only the appropriate tunnel ports are in any VLAN used for tunneling and that one VLAN is used for each tunnel. Incorrect assignment of tunnel ports to VLANs can forward traffic inappropriately.

## Configuring 802.1Q Tunnel Ports

To configure 802.1Q tunneling on a port, perform this task:

|        | Command                                                        | Purpose                                                                                                                                                                                                                                                                                                                                                                                                        |
|--------|----------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "kpvgthceg" type slot/port</code>        | Selects the LAN port to configure.                                                                                                                                                                                                                                                                                                                                                                             |
| Step 2 | <code>Tqwgvt*eqphki/kh+% "uykvejrgtv"</code>                   | Configures the LAN port for Layer 2 switching. <ul style="list-style-type: none"> <li>• You must enter the <b>switchport</b> command once without any keywords to configure the LAN port as a Layer 2 interface before you can enter additional <b>switchport</b> commands with keywords.</li> <li>• Required only if you have not entered the <b>switchport</b> command already for the interface.</li> </ul> |
| Step 3 | <code>Tqwgvt*eqphki/kh+% "uykvejrgtv" oqfg fqv3s/vwppgn</code> | Configures the Layer 2 port as a tunnel port.                                                                                                                                                                                                                                                                                                                                                                  |
| Step 4 | <code>Tqwgvt*eqphki/kh+% "pq" nnfr "vtcpuokv"</code>           | (Required on PE ports) Disables LLDP.<br><b>Note</b> CDP is automatically disabled.                                                                                                                                                                                                                                                                                                                            |
| Step 5 | <code>Tqwgvt*eqphki/kh+% "gpf"</code>                          | Exits configuration mode.                                                                                                                                                                                                                                                                                                                                                                                      |

This example shows how to configure tunneling on port 4/1 and verify the configuration:

```
Tqwgvt% "eqphkiwtg" vgtokpcn
Tqwgvt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv "613"
Tqwgvt*eqphki/kh+% "uykvejrgtv" oqfg fqv3s/vwppgn
Tqwgvt*eqphki/kh+% "pq" nnfr "vtcpuokv"
Tqwgvt*eqphki/kh+% "gpf"
Tqwgvt% "ujqy" fqv3s/vwppgn kpvgthceg
```

## Configuring the Switch to Tag Native VLAN Traffic

- [Configuring the Switch to Tag Native VLAN Traffic Globally, page 29-7](#)
- [Configuring Ports Not to Tag Native VLAN Traffic, page 29-7](#)

## Configuring the Switch to Tag Native VLAN Traffic Globally

To configure the switch to tag traffic in the native VLAN globally, perform this task:

|        | Command                                              | Purpose                                                                                                                                                                                                                                                                                                                                                                                   |
|--------|------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "xncp"fqv3s"vci"pcvkxg"</code> | Configures the switch to tag native VLAN traffic globally, and admit only 802.1Q tagged frames on 802.1Q trunks, dropping any untagged traffic, including untagged traffic in the native VLAN.<br><br><b>Note</b> On ports where you enter the <b>no switchport trunk native vlan tag</b> interface command, the function of the <b>vlan dot1q tag native</b> global command is disabled. |
| Step 2 | <code>Tqwgvt*eqphki+% "gpf"</code>                   | Exits configuration mode.                                                                                                                                                                                                                                                                                                                                                                 |

This example shows how to configure the switch to tag native VLAN traffic and verify the configuration:

```
Tqwgvt*"eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+% "xncp"fqv3s"vci"pcvkxg"
Tqwgvt*eqphki+% "gpf"
Tqwgvt*"ujqy"xncp"fqv3s"vci"pcvkxg"~"kpenwfg"inqdcnn{ "
fqv3s"pcvkxg"xncp"vciikpi"ku"gpdcngf"inqdcnn{
Tqwgvt*eqphki+% "
```

## Configuring Ports Not to Tag Native VLAN Traffic

To configure a port not to tag traffic in the native VLAN, perform this task:

|        | Command                                                               | Purpose                                                                                                                                                                                                                                                                                                                                                                                               |
|--------|-----------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "kpvgtgheg" type slot/port"</code>              | Selects the LAN port to configure.                                                                                                                                                                                                                                                                                                                                                                    |
| Step 2 | <code>Tqwgvt*eqphki/kh+% "uykvejrqtv"</code>                          | Configures the LAN port for Layer 2 switching. <ul style="list-style-type: none"> <li>You must enter the <b>switchport</b> command once without any keywords to configure the LAN port as a Layer 2 interface before you can enter additional <b>switchport</b> commands with keywords.</li> <li>Required only if you have not entered the <b>switchport</b> command already for the port.</li> </ul> |
| Step 3 | <code>Tqwgvt*eqphki/kh+% "pq"uykvejrqtv"vtwpm"pcvkxg"xncp"vci"</code> | When the switch is configured to tag native VLAN traffic globally, configures the Layer 2 port not to tag native VLAN traffic.                                                                                                                                                                                                                                                                        |
| Step 4 | <code>Tqwgvt*eqphki/kh+% "gpf"</code>                                 | Exits configuration mode.                                                                                                                                                                                                                                                                                                                                                                             |



### Note

The **switchport trunk native vlan tag** interface command does not enable native VLAN tagging unless the switch is configured to tag native VLAN traffic globally.

This example shows how to configure Gigabit Ethernet port 1/4 to tag traffic in the native VLAN and verify the configuration:

```
Tqwgvt% "eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"316"
Tqwgvt*eqphki/kh+%"uykvejrrqtv"vtwpm"pcvkxg"xncp"vci"
Tqwgvt*eqphki/kh+%"gpf"
Tqwgvt%"ujqy"kpvgthceg"ikicdkvgvjgtpgv"316"uykvejrrqtv"~"kpenwfg"vciikpi"
Cfokpkuvtecvkxg"Pcvkxg"XNCP"vciikpi<"gpcdnfg
Qrgtcvkqpcn"Pcvkxg"XNCP"vciikpi<"fkucdnfg
Tqwgvt%"
```



#### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





## Layer 2 Protocol Tunneling

---

- [Prerequisites for Layer 2 Protocol Tunneling, page 30-1](#)
- [Restrictions for Layer 2 Protocol Tunneling, page 30-1](#)
- [Information About Layer 2 Protocol Tunneling, page 30-2](#)
- [Default Settings for Layer 2 Protocol Tunneling, page 30-2](#)
- [How to Configure Layer 2 Protocol Tunneling, page 30-3](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for Layer 2 Protocol Tunneling

None.

## Restrictions for Layer 2 Protocol Tunneling

None.


## Information About Layer 2 Protocol Tunneling

Layer 2 protocol tunneling allows Layer 2 protocol data units (PDUs) (CDP, STP, and VTP) to be tunneled through a network. This section uses the following terminology:

- Edge switch—The switch connected to the customer switch and placed on the boundary of the service provider network (see [Figure 30-1](#)).
- Layer 2 protocol tunnel port—A port on the edge switch on which a specific tunneled protocol can be encapsulated or deencapsulated. The Layer 2 protocol tunnel port is configured through CLI commands.
- Tunneled PDU—A CDP, STP, or VTP PDU.

Without Layer 2 protocol tunneling, tunnel ports drop STP and VTP packets and process CDP packets. This handling of the PDUs creates different spanning tree domains (different spanning tree roots) for the customer switches. For example, STP for a VLAN on switch 1 (see [Figure 30-1](#)) builds a spanning tree topology on switches 1, 2, and 3 without considering convergence parameters based on switches 4 and 5. To provide a single spanning tree domain for the customer, a generic scheme to tunnel BPDUs was created for control protocol PDUs (CDP, STP, and VTP). This process is referred to as Generic Bridge PDU Tunneling (GBPT).

**Figure 30-1** Layer 2 Protocol Tunneling Network Configuration



GBPT provides a scalable approach to PDU tunneling by software encapsulating the PDUs in the ingress edge switches and then multicasting them in hardware. All switches inside the service provider network treat these encapsulated frames as data packets and forward them to the other end. The egress edge switch listens for these special encapsulated frames and deencapsulates them; they are then forwarded out of the tunnel.

The encapsulation involves rewriting the destination media access control (MAC) address in the PDU. An ingress edge switch rewrites the destination MAC address of the PDUs received on a Layer 2 tunnel port with the Cisco proprietary multicast address (01-00-0c-cd-cd-d0). The PDU is then flooded to the native VLAN of the Layer 2 tunnel port. If you enable Layer 2 protocol tunneling on a port, PDUs of an enabled protocol are not sent out. If you disable Layer 2 protocol tunneling on a port, the disabled protocols function the same way they were functioning before Layer 2 protocol tunneling was enabled on the port.

## Default Settings for Layer 2 Protocol Tunneling

None.

# How to Configure Layer 2 Protocol Tunneling



## Note

- Encapsulated PDUs received by an 802.1Q tunnel port are transmitted from other tunnel ports in the same VLAN on the switch.
- Configure jumbo frame support on Layer 2 protocol tunneling ports:
  - See the [“Configuring Jumbo Frame Support” section on page 10-6](#).
  - Take note of the modules listed in the “Configuring Jumbo Frame Support” section that do not support jumbo frames.

To configure Layer 2 protocol tunneling on a port, perform this task:

|        | Command                                                                                                                                        | Purpose                                                                                                                                                                                                                                                                                                                                                                                                    |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%<b>kpvgthceg</b>"type slot/port"</code>                                                                                   | Selects the LAN port to configure.                                                                                                                                                                                                                                                                                                                                                                         |
| Step 2 | <code>Tqwgvt*eqphki/kh+%<b>uykvejrgtv</b>"</code>                                                                                              | Configures the LAN port for Layer 2 switching. <ul style="list-style-type: none"> <li>You must enter the <b>switchport</b> command once without any keywords to configure the LAN port as a Layer 2 interface before you can enter additional <b>switchport</b> commands with keywords.</li> <li>Required only if you have not entered the <b>switchport</b> command already for the interface.</li> </ul> |
| Step 3 | <code>Tqwgvt*eqphki/kh+%<b>n4rtqvqeqn/vwppgn</b>"] efr"~<b>nnfr</b>"~<b>uvr</b>"~<b>xvr</b>_</code>                                            | Configures the Layer 2 port as a Layer 2 protocol tunnel port for all protocols or only the specified protocol.                                                                                                                                                                                                                                                                                            |
| Step 4 | <code>Tqwgvt*eqphki/kh+%<b>n4rtqvqeqn/vwppgn</b><b>ftqr/vjtgujqnf</b>"}] efr"~<b>nnfr</b>"~<b>uvr</b>"~<b>xvr</b>_ "<i>rcemgvu</i>;</code>     | (Optional) Configures the port as a Layer 2 protocol tunnel port and sets a drop threshold for all protocols or only the specified protocol.                                                                                                                                                                                                                                                               |
| Step 5 | <code>Tqwgvt*eqphki/kh+%<b>n4rtqvqeqn/vwppgn</b><b>ujwvfqyp/vjtgujqnf</b>"}] efr"~<b>nnfr</b>"~<b>uvr</b>"~<b>xvr</b>_ "<i>rcemgvu</i>;</code> | (Optional) Configures the port as a Layer 2 protocol tunnel port and sets a shutdown threshold for all protocols or only the specified protocol.                                                                                                                                                                                                                                                           |
| Step 6 | <code>Tqwgvt*eqphki/kh+%<b>pq</b>"<b>nnfr</b>"<b>vtcpuokv</b>"</code>                                                                          | (Required on PE ports) Disables LLDP.<br><b>Note</b> CDP is automatically disabled.                                                                                                                                                                                                                                                                                                                        |
| Step 7 | <code>Tqwgvt*eqphki+%<b>gpf</b>"</code>                                                                                                        | Exits configuration mode.                                                                                                                                                                                                                                                                                                                                                                                  |

When you configure a Layer 2 port as a Layer 2 protocol tunnel port, note the following information:

- Optionally, you may specify a drop threshold for the port. The drop threshold value, from 1 to 4096, determines the number of packets to be processed for that protocol on that interface in one second. When the drop threshold is exceeded, PDUs for the specified protocol are dropped for the remainder of the one-second period. If a drop threshold is not specified, the value is 0 (drop threshold disabled).
- Optionally, you may specify a shutdown threshold for the port. The shutdown threshold value, from 1 to 4096, determines the number of packets to be processed for that protocol on that interface in one second. When the shutdown threshold is exceeded, the port is put in errdisable state. If a shutdown threshold is not specified, the value is 0 (shutdown threshold disabled).

- If you specify both a drop threshold and a shutdown threshold for the port, packets exceeding the drop threshold will not be forwarded but will be counted toward the shutdown threshold.

**Note**

The commands support the **l2ptguard** keyword:

- **errdisable detect cause**
- **errdisable recovery**

This example shows how to configure Layer 2 protocol tunneling and drop and shutdown thresholds on port 5/1 for CDP, STP, and VTP, and verify the configuration:

```
Tqwgvt%eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+%kpvgtthceg"ikicdkvgvjgtpgv"713"
Tqwgvt*eqphki/kh+%uykvejrtv
Tqwgvt*eqphki/kh+%n4rtqvqeqn/vwppgn"ujwvfqyp/vjtgujqnf"efr"622"
Tqwgvt*eqphki/kh+%n4rtqvqeqn/vwppgn"ujwvfqyp/vjtgujqnf"uvr"622"
Tqwgvt*eqphki/kh+%n4rtqvqeqn/vwppgn"ujwvfqyp/vjtgujqnf"xvr"622"
Tqwgvt*eqphki/kh+%n4rtqvqeqn/vwppgn"ftqr/vjtgujqnf"xvr"422"
Tqwgvt*eqphki/kh+%pq"nnfr"vtcpuokv"
Tqwgvt*eqphki/kh+%gpf
Tqwgvt%"ujqy"n4rtqvqeqn/vwppgn"uwooct{
EQU"hqt"Gpecruwncvgf"Rcemgvu<"7
Ftqr"Vjtgujqnf"hqt"Gpecruwncvgf"Rcemgvu<"2

Rqtv""""Rtqvqeqn""Ujwvfqyp""""Ftqr""""Uvcvwu
""""Vjtgujqnf""""Vjtgujqnf""""
""""*efrlnnfrluvr1xvr+""*efrlnnfrluvr1xvr+
/////////"/////////"/////////"/////////"/////////
Ik713""""/"/////////"6221///1"6221"622"///1///1///1"422""fgyq*vtwpm+

Tqwgvt%
```

This example shows how to display counter information for port 5/1:

```
Tqwgvt%"ujqy"n4rtqvqeqn/vwppgn"kpvgthceg"ikicdkvgvjgtpgv"713
EQU"hqt"Gpecruwncvgf"Rcemgvu<"7

Rqtv""""Rtqvqeqn"Vjtgujqnf""""Eqwpgvtu
""""Ujwvfqyp""Ftqr""""Gpecr""""Fgcr""""Ftqr
/////////"/////////"/////////"/////////"/////////"/////////

Tqwgvt%
```

This example shows how to clear the Layer 2 protocol tunneling configuration from port 5/1:

```
Tqwgvt*eqphki/kh+%pq"n4rtqvqeqn/vwppgn"ujwvfqyp/vjtgujqnf"efr"622
Tqwgvt*eqphki/kh+%pq"n4rtqvqeqn/vwppgn"ujwvfqyp/vjtgujqnf"uvr"622
Tqwgvt*eqphki/kh+%pq"n4rtqvqeqn/vwppgn"ujwvfqyp/vjtgujqnf"xvr"622
Tqwgvt*eqphki/kh+%pq"n4rtqvqeqn/vwppgn"ftqr/vjtgujqnf"xvr"422"
Tqwgvt*eqphki/kh+%pq"n4rtqvqeqn/vwppgn"efr
Tqwgvt*eqphki/kh+%pq"n4rtqvqeqn/vwppgn"uvr
Tqwgvt*eqphki/kh+%pq"n4rtqvqeqn/vwppgn"xvr
Tqwgvt*eqphki/kh+%nnfr"vtcpuokv"
Tqwgvt*eqphki/kh+%gpf
Tqwgvt%"ujqy"n4rtqvqeqn/vwppgn"uwooct{
EQU"hqt"Gpecruwncvgf"Rcemgvu<"7
Ftqr"Vjtgujqnf"hqt"Gpecruwncvgf"Rcemgvu<"2

Rqtv""""Rtqvqeqn""Ujwvfqyp""""Ftqr""""Uvcvwu
""""Vjtgujqnf""""Vjtgujqnf""""
```

```

*****efrlnnfrluvr1xvr+*****efrlnnfrluvr1xvr+
/////////"/////////"/////////"/////////"/////////

Tqvvgt%

```

This example shows how to clear Layer 2 protocol tunneling port counters:

```

Tqvvgt%engct"n4rtqvqeqn/vwppgn"eqwpvgtu
Tqvvgt%

```



#### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





## Spanning Tree Protocols

---

- [Prerequisites for Spanning Tree Protocols, page 31-1](#)
- [Restrictions for Spanning Tree Protocols, page 31-2](#)
- [Information About Spanning Tree Protocols, page 31-2](#)
- [Default Settings for Spanning Tree Protocols, page 31-25](#)
- [How to Configure Spanning Tree Protocols, page 31-26](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
  - Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
  - This chapter describes the Spanning Tree Protocol (STP) and Multiple Spanning Tree (MST) protocol. For information on configuring the PortFast, UplinkFast, and BackboneFast STP enhancements, see [Chapter 32, “Optional STP Features.”](#)
- 



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

---

## Prerequisites for Spanning Tree Protocols

None.

## Restrictions for Spanning Tree Protocols

- The 802.1s MST standard allows up to 65 MST instances. You can map an unlimited number of VLANs to an MST instance.
- Rapid PVST+ and MST are supported, but only one version can be active at any time.
- VTP does not propagate the MST configuration. You must manually configure the MST configuration (region name, revision number, and VLAN-to-instance mapping) on each switch within the MST region through the command-line interface (CLI) or SNMP.
- For load balancing across redundant paths in the network to work, all VLAN-to-instance mapping assignments must match; otherwise, all traffic flows on a single link.
- All MST boundary ports must be forwarding for load balancing between a PVST+ and an MST cloud or between a rapid-PVST+ and an MST cloud. For this to occur, the CIST regional root of the MST cloud must be the root of the CST. If the MST cloud consists of multiple MST regions, one of the MST regions must contain the CST root, and all of the other MST regions must have a better path to the root contained within the MST cloud than a path through the rapid-PVST+ cloud.
- Partitioning the network into a large number of regions is not recommended. However, if this situation is unavoidable, we recommend that you partition the switched LAN into smaller LANs interconnected by non-Layer 2 devices.
- Adding or removing VLANs to an existing MST instance will trigger spanning tree recalculation for that MST instance, and the traffic of all the VLANs for that MST instance will be disrupted.
- The **show vlan virtual-port** command displays the number of virtual interfaces. The maximum numbers of virtual interfaces supported on stand-alone switch/VSS system limits are as follows:
  - MST: 100,000 total
  - RPVST+: 12,000 total
  - PVST+: 15,000 total



**Note** Cisco IOS software displays a message if you exceed the maximum number of virtual interfaces.

## Information About Spanning Tree Protocols

- [Information about STP, page 31-2](#)
- [Information about IEEE 802.1w RSTP, page 31-13](#)
- [Information about MST, page 31-18](#)
- [Detecting Unidirectional Link Failure, page 31-25](#)

## Information about STP

- [STP Overview, page 31-3](#)
- [Information about the Bridge ID, page 31-3](#)
- [Information about Bridge Protocol Data Units, page 31-5](#)
- [Election of the Root Bridge, page 31-5](#)



- [STP Protocol Timers, page 31-6](#)
- [Creating the Spanning Tree Topology, page 31-6](#)
- [STP Port States, page 31-6](#)
- [STP and IEEE 802.1Q Trunks, page 31-12](#)

## STP Overview

STP, the IEEE 802.1D bridge protocol, is a Layer 2 link-management protocol that provides path redundancy while preventing undesirable loops in the network. For a Layer 2 Ethernet network to function properly, only one active path can exist between any two stations. STP operation is transparent to end stations, which cannot detect whether they are connected to a single LAN segment or a switched LAN of multiple segments.

In an extension known as per-VLAN spanning tree (PVST), Layer 2 Ethernet ports can use STP on all VLANs. Rapid-PVST+, enabled by default on each configured VLAN (provided you do not manually disable it), uses RSTP to provide faster convergence. Independent VLANs run their own RSTP instance.

With rapid-PVST+, dynamic entries are flushed immediately on a per-port basis upon receiving a topology change. UplinkFast and BackboneFast configurations are ignored in rapid-PVST+ mode; both features are included in RSTP. Rapid-PVST+ mode supports unidirectional link failure detection as described in the [“Detecting Unidirectional Link Failure” section on page 31-25](#).

When you create fault-tolerant internetworks, you must have a loop-free path between all nodes in a network. The STP algorithm calculates the best loop-free path throughout a switched Layer 2 network. Layer 2 LAN ports send and receive STP frames at regular intervals. Network devices do not forward these frames, but use the frames to construct a loop-free path.

Multiple active paths between end stations cause loops in the network. If a loop exists in the network, end stations might receive duplicate messages and network devices might learn end station MAC addresses on multiple Layer 2 LAN ports. These conditions result in an unstable network.

STP defines a tree with a root bridge and a loop-free path from the root to all network devices in the Layer 2 network. STP forces redundant data paths into a standby (blocked) state. If a network segment in the spanning tree fails and a redundant path exists, the STP algorithm recalculates the spanning tree topology and activates the standby path.

When two Layer 2 LAN ports on a network device are part of a loop, the STP port priority and port path cost setting determine which port is put in the forwarding state and which port is put in the blocking state. The STP port priority value represents the location of a port in the network topology and how efficiently that location allows the port to pass traffic. The STP port path cost value represents media speed.

## Information about the Bridge ID

- [Bridge Priority Value, page 31-4](#)
- [Extended System ID, page 31-4](#)
- [STP MAC Address Allocation, page 31-4](#)

## Bridge Priority Value

Each VLAN on each network device has a unique 64-bit bridge ID consisting of a bridge priority value, an extended system ID, and an STP MAC address allocation. The bridge priority is a 4-bit value when the extended system ID is enabled (see [Table 31-1 on page 31-4](#) and the “[Configuring the Bridge Priority of a VLAN](#)” section on page 31-34).

## Extended System ID

A 12-bit extended system ID field is part of the bridge ID (see [Table 31-1 on page 31-4](#)). Chassis that support only 64 MAC addresses always use the 12-bit extended system ID. On chassis that support 1,024 MAC addresses, you can enable use of the extended system ID.

The extended system ID is enabled by default under the following conditions:

- Chassis that support only 64 MAC addresses
- When the STP mode is MST

STP uses the VLAN ID as the extended system ID. See the “[Enabling the Extended System ID](#)” section on page 31-28.

*Table 31-1 Bridge Priority Value and Extended System ID with the Extended System ID Enabled*

| Bridge Priority Value |        |        |        | Extended System ID (Set Equal to the VLAN/MST Instance ID) |        |        |       |       |       |       |       |       |       |       |       |
|-----------------------|--------|--------|--------|------------------------------------------------------------|--------|--------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| Bit 16                | Bit 15 | Bit 14 | Bit 13 | Bit 12                                                     | Bit 11 | Bit 10 | Bit 9 | Bit 8 | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 |
| 32768                 | 16384  | 8192   | 4096   | 2048                                                       | 1024   | 512    | 256   | 128   | 64    | 32    | 16    | 8     | 4     | 2     | 1     |

## STP MAC Address Allocation

The chassis has either 64 or 1024 MAC addresses available to support software features such as STP. To view the MAC address range on your chassis, enter the **show catalyst6000 chassis-mac-address** command.

For chassis with 64 MAC addresses, STP uses the extended system ID plus a MAC address to make the bridge ID unique for each VLAN.

When the extended system ID is not enabled, STP uses one MAC address per VLAN to make the bridge ID unique for each VLAN.

If you have a network device in your network with the extended system ID enabled, you should also enable the extended system ID on all other Layer 2 connected network devices to avoid undesirable root bridge election and spanning tree topology issues.

When the extended system ID is enabled, the root bridge priority becomes a multiple of 4096 plus the VLAN ID. With the extended system ID enabled, a switch bridge ID (used by the spanning tree algorithm to determine the identity of the root bridge, the lowest being preferred) can only be specified as a multiple of 4096. Only the following values are possible: 0, 4096, 8192, 12288, 16384, 20480, 24576, 28672, 32768, 36864, 40960, 45056, 49152, 53248, 57344, and 61440.

If another bridge in the same spanning tree domain does not have the extended system ID enabled, it could win root bridge ownership because of the finer granularity in the selection of its bridge ID.

## Information about Bridge Protocol Data Units

Bridge protocol data units (BPDUs) are transmitted in one direction from the root bridge. Each network device sends configuration BPDUs to communicate and compute the spanning tree topology. Each configuration BPDU contains the following minimal information:

- The unique bridge ID of the network device that the transmitting network device believes to be the root bridge
- The STP path cost to the root
- The bridge ID of the transmitting bridge
- Message age
- The identifier of the transmitting port
- Values for the hello, forward delay, and max-age protocol timers

When a network device transmits a BPDU frame, all network devices connected to the LAN on which the frame is transmitted receive the BPDU. When a network device receives a BPDU, it does not forward the frame but instead uses the information in the frame to calculate a BPDU, and, if the topology changes, initiate a BPDU transmission.

A BPDU exchange results in the following:

- One network device is elected as the root bridge.
- The shortest distance to the root bridge is calculated for each network device based on the path cost.
- A designated bridge for each LAN segment is selected. This is the network device closest to the root bridge through which frames are forwarded to the root.
- A root port is selected. This is the port providing the best path from the bridge to the root bridge.
- Ports included in the spanning tree are selected.

## Election of the Root Bridge

For each VLAN, the network device with the highest-priority bridge ID (the lowest numerical ID value) is elected as the root bridge. If all network devices are configured with the default priority (32768), the network device with the lowest MAC address in the VLAN becomes the root bridge. The bridge priority value occupies the most significant bits of the bridge ID.

When you change the bridge priority value, you change the probability that the switch will be elected as the root bridge. Configuring a higher-priority value increases the probability; a lower-priority value decreases the probability.

The STP root bridge is the logical center of the spanning tree topology in a Layer 2 network. All paths that are not needed to reach the root bridge from anywhere in the Layer 2 network are placed in STP blocking mode.

BPDUs contain information about the transmitting bridge and its ports, including bridge and MAC addresses, bridge priority, port priority, and path cost. STP uses this information to elect the root bridge for the Layer 2 network, to elect the root port leading to the root bridge, and to determine the designated port for each Layer 2 segment.


## STP Protocol Timers

| Variable            | Description                                                                                             |
|---------------------|---------------------------------------------------------------------------------------------------------|
| Hello timer         | Determines how often the network device broadcasts hello messages to other network devices.             |
| Forward delay timer | Determines how long each of the listening and learning states last before the port begins forwarding.   |
| Maximum age timer   | Determines the amount of time protocol information received on an port is stored by the network device. |

## Creating the Spanning Tree Topology

In [Figure 31-1](#), Switch A is elected as the root bridge because the bridge priority of all the network devices is set to the default (32768) and Switch A has the lowest MAC address. However, due to traffic patterns, number of forwarding ports, or link types, Switch A might not be the ideal root bridge. By increasing the priority (lowering the numerical value) of the ideal network device so that it becomes the root bridge, you force an STP recalculation to form a new spanning tree topology with the ideal network device as the root.

**Figure 31-1** Spanning Tree Topology



RP = Root Port  
DP = Designated Port

When the spanning tree topology is calculated based on default parameters, the path between source and destination end stations in a switched network might not be ideal. For instance, connecting higher-speed links to a port that has a higher number than the current root port can cause a root-port change. The goal is to make the fastest link the root port.

For example, assume that one port on Switch B is a fiber-optic link, and another port on Switch B (an unshielded twisted-pair [UTP] link) is the root port. Network traffic might be more efficient over the high-speed fiber-optic link. By changing the STP port priority on the fiber-optic port to a higher priority (lower numerical value) than the root port, the fiber-optic port becomes the new root port.

## STP Port States

- [STP Port State Overview, page 31-7](#)
- [Blocking State, page 31-8](#)
- [Listening State, page 31-9](#)

- [Learning State, page 31-10](#)
- [Forwarding State, page 31-11](#)
- [Disabled State, page 31-12](#)

## STP Port State Overview

Propagation delays can occur when protocol information passes through a switched LAN. As a result, topology changes can take place at different times and at different places in a switched network. When a Layer 2 LAN port transitions directly from nonparticipation in the spanning tree topology to the forwarding state, it can create temporary data loops. Ports must wait for new topology information to propagate through the switched LAN before starting to forward frames. They must allow the frame lifetime to expire for frames that have been forwarded using the old topology.

Each Layer 2 LAN port using STP exists in one of the following five states:


- Blocking—The Layer 2 LAN port does not participate in frame forwarding.
- Listening—First transitional state after the blocking state when STP determines that the Layer 2 LAN port should participate in frame forwarding.
- Learning—The Layer 2 LAN port prepares to participate in frame forwarding.
- Forwarding—The Layer 2 LAN port forwards frames.
- Disabled—The Layer 2 LAN port does not participate in STP and is not forwarding frames.

A Layer 2 LAN port moves through these five states as follows:

- From initialization to blocking
- From blocking to listening or to disabled
- From listening to learning or to disabled
- From learning to forwarding or to disabled
- From forwarding to disabled

Figure 31-2 illustrates how a Layer 2 LAN port moves through the five states.

**Figure 31-2** STP Layer 2 LAN Interface States



When you enable STP, every port, VLAN, and network goes through the blocking state and the transitory states of listening and learning at power up. If properly configured, each Layer 2 LAN port stabilizes to the forwarding or blocking state.


When the STP algorithm places a Layer 2 LAN port in the forwarding state, the following process occurs:

1. The Layer 2 LAN port is put into the listening state while it waits for protocol information that suggests it should go to the blocking state.
2. The Layer 2 LAN port waits for the forward delay timer to expire, moves the Layer 2 LAN port to the learning state, and resets the forward delay timer.
3. In the learning state, the Layer 2 LAN port continues to block frame forwarding as it learns end station location information for the forwarding database.
4. The Layer 2 LAN port waits for the forward delay timer to expire and then moves the Layer 2 LAN port to the forwarding state, where both learning and frame forwarding are enabled.

## Blocking State

A Layer 2 LAN port in the blocking state does not participate in frame forwarding, as shown in [Figure 31-3](#). After initialization, a BPDU is sent out to each Layer 2 LAN port. A network device initially assumes it is the root until it exchanges BPDUs with other network devices. This exchange establishes which network device in the network is the root or root bridge. If only one network device is in the network, no exchange occurs, the forward delay timer expires, and the ports move to the listening state. A port always enters the blocking state following initialization.

**Figure 31-3** Interface 2 in Blocking State




A Layer 2 LAN port in the blocking state performs as follows:

- Discards frames received from the attached segment.
- Discards frames switched from another port for forwarding.
- Does not incorporate end station location into its address database. (There is no learning on a blocking Layer 2 LAN port, so there is no address database update.)
- Receives BPDUs and directs them to the system module.
- Does not transmit BPDUs received from the system module.
- Receives and responds to network management messages.

## Listening State

The listening state is the first transitional state a Layer 2 LAN port enters after the blocking state. The Layer 2 LAN port enters this state when STP determines that the Layer 2 LAN port should participate in frame forwarding. [Figure 31-4](#) shows a Layer 2 LAN port in the listening state.

**Figure 31-4** Interface 2 in Listening State



A Layer 2 LAN port in the listening state performs as follows:


- Discards frames received from the attached segment.
- Discards frames switched from another LAN port for forwarding.
- Does not incorporate end station location into its address database. (There is no learning at this point, so there is no address database update.)

- Receives BPDUs and directs them to the system module.
- Receives, processes, and transmits BPDUs received from the system module.
- Receives and responds to network management messages.

## Learning State

A Layer 2 LAN port in the learning state prepares to participate in frame forwarding. The Layer 2 LAN port enters the learning state from the listening state. [Figure 31-5](#) shows a Layer 2 LAN port in the learning state.

**Figure 31-5** Interface 2 in Learning State



A Layer 2 LAN port in the learning state performs as follows:


- Discards frames received from the attached segment.
- Discards frames switched from another port for forwarding.
- Incorporates end station location into its address database.
- Receives BPDUs and directs them to the system module.
- Receives, processes, and transmits BPDUs received from the system module.
- Receives and responds to network management messages.



## Forwarding State

A Layer 2 LAN port in the forwarding state forwards frames, as shown in [Figure 31-6](#). The Layer 2 LAN port enters the forwarding state from the learning state.

**Figure 31-6**      *Interface 2 in Forwarding State*




A Layer 2 LAN port in the forwarding state performs as follows:

- Forwards frames received from the attached segment.
- Forwards frames switched from another port for forwarding.
- Incorporates end station location information into its address database.
- Receives BPDUs and directs them to the system module.
- Processes BPDUs received from the system module.
- Receives and responds to network management messages.

## Disabled State

A Layer 2 LAN port in the disabled state does not participate in frame forwarding or STP, as shown in Figure 31-7. A Layer 2 LAN port in the disabled state is virtually nonoperational.

Figure 31-7 Interface 2 in Disabled State



A disabled Layer 2 LAN port performs as follows:

- Discards frames received from the attached segment.
- Discards frames switched from another port for forwarding.
- Does not incorporate end station location into its address database. (There is no learning, so there is no address database update.)
- Does not receive BPDUs.
- Does not receive BPDUs for transmission from the system module.

## STP and IEEE 802.1Q Trunks

802.1Q trunks impose some limitations on the STP strategy for a network. In a network of Cisco network devices connected through 802.1Q trunks, the network devices maintain one instance of STP for each VLAN allowed on the trunks. However, non-Cisco 802.1Q network devices maintain only one instance of STP for all VLANs allowed on the trunks.

When you connect a Cisco network device to a non-Cisco device through an 802.1Q trunk, the Cisco network device combines the STP instance of the 802.1Q VLAN of the trunk with the STP instance of the non-Cisco 802.1Q network device. However, all per-VLAN STP information is maintained by Cisco network devices separated by a cloud of non-Cisco 802.1Q network devices. The non-Cisco 802.1Q cloud separating the Cisco network devices is treated as a single trunk link between the network devices.

For more information on 802.1Q trunks, see [Chapter 21, “LAN Ports for Layer 2 Switching.”](#)

## Information about IEEE 802.1w RSTP

- [RSTP Overview, page 31-13](#)
- [Port Roles and the Active Topology, page 31-13](#)
- [Rapid Convergence, page 31-14](#)
- [Synchronization of Port Roles, page 31-15](#)
- [Bridge Protocol Data Unit Format and Processing, page 31-16](#)
- [Topology Changes, page 31-17](#)

### RSTP Overview

RSTP, which is enabled by default, takes advantage of point-to-point wiring and provides rapid convergence of the spanning tree. Reconfiguration of the spanning tree can occur in less than 1 second (in contrast to 50 seconds with the default settings in the 802.1D spanning tree).

### Port Roles and the Active Topology

The RSTP provides rapid convergence of the spanning tree by assigning port roles and by learning the active topology. The RSTP builds upon the 802.1D STP to select the switch with the highest switch priority (lowest numerical priority value) as the root bridge as described in the [“Election of the Root Bridge” section on page 31-5](#). The RSTP then assigns one of these port roles to individual ports:

- Root port—Provides the best path (lowest cost) when the switch forwards packets to the root bridge.
- Designated port—Connects to the designated switch, which incurs the lowest path cost when forwarding packets from that LAN to the root bridge. The port through which the designated switch is attached to the LAN is called the designated port.
- Alternate port—Offers an alternate path toward the root bridge to that provided by the current root port.
- Backup port—Acts as a backup for the path provided by a designated port toward the leaves of the spanning tree. A backup port can exist only when two ports are connected in a loopback by a point-to-point link or when a switch has two or more connections to a shared LAN segment.
- Disabled port—Has no role within the operation of the spanning tree.

A port with the root or a designated port role is included in the active topology. A port with the alternate or backup port role is excluded from the active topology.

In a stable topology with consistent port roles throughout the network, the RSTP ensures that every root port and designated port immediately transition to the forwarding state while all alternate and backup ports are always in the discarding state (equivalent to blocking in 802.1D). The port state controls the operation of the forwarding and learning processes. [Table 31-2](#) provides a comparison of 802.1D and RSTP port states.

Table 31-2 Port State Comparison

| Operational Status | STP Port State (IEEE 802.1D) | RSTP Port State | Is Port Included in the Active Topology? |
|--------------------|------------------------------|-----------------|------------------------------------------|
| Enabled            | Blocking                     | Discarding      | No                                       |
| Enabled            | Listening                    | Discarding      | No                                       |
| Enabled            | Learning                     | Learning        | Yes                                      |
| Enabled            | Forwarding                   | Forwarding      | Yes                                      |
| Disabled           | Disabled                     | Discarding      | No                                       |

To be consistent with Cisco STP implementations, this guide defines the port state as *blocking* instead of *discarding*. Designated ports start in the listening state.

## Rapid Convergence

The RSTP provides for rapid recovery of connectivity following the failure of a switch, a switch port, or a LAN. It provides rapid convergence for edge ports, new root ports, and ports connected through point-to-point links as follows:

- **Edge ports**—If you configure a port as an edge port on an RSTP switch by using the **spanning-tree portfast** interface configuration command, the edge port immediately transitions to the forwarding state. An edge port is the same as a Port Fast-enabled port, and you should enable it only on ports that connect to a single end station.
- **Root ports**—If the RSTP selects a new root port, it blocks the old root port and immediately transitions the new root port to the forwarding state.
- **Point-to-point links**—If you connect a port to another port through a point-to-point link and the local port becomes a designated port, it negotiates a rapid transition with the other port by using the proposal-agreement handshake to ensure a loop-free topology.


As shown in [Figure 31-8](#), switch A is connected to switch B through a point-to-point link, and all of the ports are in the blocking state. Assume that the priority of switch A is a smaller numerical value than the priority of switch B. Switch A sends a proposal message (a configuration BPDU with the proposal flag set) to switch B, proposing itself as the designated switch.

After receiving the proposal message, switch B selects as its new root port the port from which the proposal message was received, forces all nonedge ports to the blocking state, and sends an agreement message (a BPDU with the agreement flag set) through its new root port.

After receiving switch B's agreement message, switch A also immediately transitions its designated port to the forwarding state. No loops in the network are formed because switch B blocked all of its nonedge ports and because there is a point-to-point link between switches A and B.

When switch C is connected to switch B, a similar set of handshaking messages are exchanged. Switch C selects the port connected to switch B as its root port, and both ends immediately transition to the forwarding state. With each iteration of this handshaking process, one more switch joins the active topology. As the network converges, this proposal-agreement handshaking progresses from the root toward the leaves of the spanning tree.

The switch learns the link type from the port duplex mode: a full-duplex port is considered to have a point-to-point connection and a half-duplex port is considered to have a shared connection. You can override the default setting that is controlled by the duplex setting by using the **spanning-tree link-type** interface configuration command.

**Figure 31-8** Proposal and Agreement Handshaking for Rapid Convergence

## Synchronization of Port Roles


When the switch receives a proposal message on one of its ports and that port is selected as the new root port, the RSTP forces all other ports to synchronize with the new root information.

The switch is synchronized with superior root information received on the root port if all other ports are synchronized. An individual port on the switch is synchronized if:

- That port is in the blocking state.
- It is an edge port (a port configured to be at the edge of the network).

If a designated port is in the forwarding state and is not configured as an edge port, it transitions to the blocking state when the RSTP forces it to synchronize with new root information. In general, when the RSTP forces a port to synchronize with root information and the port does not satisfy any of the above conditions, its port state is set to blocking.

After ensuring that all of the ports are synchronized, the switch sends an agreement message to the designated switch corresponding to its root port. When the switches connected by a point-to-point link are in agreement about their port roles, the RSTP immediately transitions the port states to forwarding. The sequence of events is shown in [Figure 31-9](#).

**Figure 31-9** Sequence of Events During Rapid Convergence

## Bridge Protocol Data Unit Format and Processing

- [BPDU Format and Processing Overview, page 31-16](#)
- [Processing Superior BPDU Information, page 31-17](#)
- [Processing Inferior BPDU Information, page 31-17](#)

### BPDU Format and Processing Overview

The RSTP BPDU format is the same as the 802.1D BPDU format except that the protocol version is set to 2. A new 1-byte Version 1 Length field is set to zero, which means that no Version 1 protocol information is present. [Table 31-3](#) describes the RSTP flag fields.

**Table 31-3** RSTP BPDU Flags

| Bit  | Function                              |
|------|---------------------------------------|
| 0    | Topology change (TC)                  |
| 1    | Proposal                              |
| 2–3: | Port role:                            |
| 00   | Unknown                               |
| 01   | Alternate port or backup port         |
| 10   | Root port                             |
| 11   | Designated port                       |
| 4    | Learning                              |
| 5    | Forwarding                            |
| 6    | Agreement                             |
| 7    | Topology change acknowledgement (TCA) |

The sending switch sets the proposal flag in the RSTP BPDU to propose itself as the designated switch on that LAN. The port role in the proposal message is always set to the designated port.

The sending switch sets the agreement flag in the RSTP BPDU to accept the previous proposal. The port role in the agreement message is always set to the root port.

The RSTP does not have a separate TCN BPDU. It uses the topology change (TC) flag to show the topology changes. However, for interoperability with 802.1D switches, the RSTP switch processes and generates TCN BPDUs.

The learning and forwarding flags are set according to the state of the sending port.

### Processing Superior BPDU Information

A superior BPDU is a BPDU with root information (such as lower switch ID or lower path cost) that is superior to what is currently stored for the port.

If a port receives a superior BPDU, the RSTP triggers a reconfiguration. If the port is proposed and is selected as the new root port, RSTP forces all the other ports to synchronize.

If the BPDU received is an RSTP BPDU with the proposal flag set, the switch sends an agreement message after all of the other ports are synchronized. If the BPDU is an 802.1D BPDU, the switch does not set the proposal flag and starts the forward-delay timer for the port. The new root port requires twice the forward-delay time to transition to the forwarding state.

If the superior information received on the port causes the port to become a backup port or an alternate port, RSTP sets the port to the blocking state and sends an agreement message. The designated port continues sending BPDUs with the proposal flag set until the forward-delay timer expires, at which time the port transitions to the forwarding state.

### Processing Inferior BPDU Information

An inferior BPDU is a BPDU with root information (such as higher switch ID or higher path cost) that is inferior to what is currently stored for the port.

If a designated port receives an inferior BPDU, it immediately replies with its own information.

## Topology Changes

These are the differences between the RSTP and the 802.1D in handling spanning tree topology changes:

- **Detection**—Unlike 802.1D in which *any* transition between the blocking and the forwarding state causes a topology change, *only* transitions from the blocking to the forwarding state cause a topology change with RSTP (only an increase in connectivity is considered a topology change). State changes on an edge port do not cause a topology change. When an RSTP switch detects a topology change, it deletes the learned information on all of its nonedge ports except on those from which it received the TC notification.
- **Notification**—The RSTP does not use TCN BPDUs, unlike 802.1D. However, for 802.1D interoperability, an RSTP switch processes and generates TCN BPDUs.
- **Acknowledgement**—When an RSTP switch receives a TCN message on a designated port from an 802.1D switch, it replies with an 802.1D configuration BPDU with the TCA bit set. However, if the TC-while timer (the same as the TC timer in 802.1D) is active on a root port connected to an 802.1D switch and a configuration BPDU with the TCA set is received, the TC-while timer is reset.

This method of operation is only required to support 802.1D switches. The RSTP BPDUs never have the TCA bit set.

- **Propagation**—When an RSTP switch receives a TC message from another switch through a designated or root port, it propagates the change to all of its nonedge, designated ports and to the root port (excluding the port on which it is received). The switch starts the TC-while timer for all such ports and flushes the information learned on them.
- **Protocol migration**—For backward compatibility with 802.1D switches, RSTP selectively sends 802.1D configuration BPDUs and TCN BPDUs on a per-port basis.

When a port is initialized, the migrate-delay timer is started (specifies the minimum time during which RSTP BPDUs are sent), and RSTP BPDUs are sent. While this timer is active, the switch processes all BPDUs received on that port and ignores the protocol type.

If the switch receives an 802.1D BPDU after the port migration-delay timer has expired, it assumes that it is connected to an 802.1D switch and starts using only 802.1D BPDUs. However, if the RSTP switch is using 802.1D BPDUs on a port and receives an RSTP BPDU after the timer has expired, it restarts the timer and starts using RSTP BPDUs on that port.

## Information about MST

- [MST Overview, page 31-18](#)
- [MST Regions, page 31-19](#)
- [IST, CIST, and CST, page 31-19](#)
- [Hop Count, page 31-22](#)
- [Boundary Ports, page 31-22](#)
- [Standard-Compliant MST Implementation, page 31-23](#)
- [Interoperability with IEEE 802.1D-1998 STP, page 31-24](#)

## MST Overview

MST maps multiple VLANs into a spanning tree instance, with each instance having a spanning tree topology independent of other spanning tree instances. This architecture provides multiple forwarding paths for data traffic, enables load balancing, and reduces the number of spanning tree instances required to support a large number of VLANs. MST improves the fault tolerance of the network because a failure in one instance (forwarding path) does not affect other instances (forwarding paths).

The most common initial deployment of MST is in the backbone and distribution layers of a Layer 2 switched network. This deployment provides the kind of highly available network that is required in a service-provider environment.

MST provides rapid spanning tree convergence through explicit handshaking, which eliminates the 802.1D forwarding delay and quickly transitions root bridge ports and designated ports to the forwarding state.

MST improves spanning tree operation and maintains backward compatibility with these STP versions:

- Original 802.1D spanning tree
- Existing Cisco-proprietary Multiple Instance STP (MISTP)
- Existing Cisco per-VLAN spanning tree plus (PVST+)
- Rapid per-VLAN spanning tree plus (rapid PVST+)



**Note**

- IEEE 802.1w defined the Rapid Spanning Tree Protocol (RSTP) and was incorporated into IEEE 802.1D.
- IEEE 802.1s defined MST and was incorporated into IEEE 802.1Q.

## MST Regions

For switches to participate in MST instances, you must consistently configure the switches with the same MST configuration information. A collection of interconnected switches that have the same MST configuration comprises an MST region as shown in [Figure 31-10 on page 31-21](#).

The MST configuration controls to which MST region each switch belongs. The configuration includes the name of the region, the revision number, and the MST VLAN-to-instance assignment map.

A region can have one or multiple members with the same MST configuration; each member must be capable of processing RSTP bridge protocol data units (BPDUs). There is no limit to the number of MST regions in a network, but each region can support up to 65 spanning tree instances. Instances can be identified by any number in the range from 0 to 4094. You can assign a VLAN to only one spanning tree instance at a time.

## IST, CIST, and CST

- [IST, CIST, and CST Overview, page 31-19](#)
- [Spanning Tree Operation Within an MST Region, page 31-20](#)
- [Spanning Tree Operations Between MST Regions, page 31-20](#)
- [IEEE 802.1s Terminology, page 31-21](#)

### IST, CIST, and CST Overview

Unlike other spanning tree protocols, in which all the spanning tree instances are independent, MST establishes and maintains internal spanning tree (IST), common and internal spanning tree (CIST), and common spanning tree (CST) instances:

- An IST is the spanning tree that runs in an MST region.

Within each MST region, MST maintains multiple spanning tree instances. Instance 0 is a special instance for a region, known as the IST. All other MST instances are numbered from 1 to 4094.

The IST is the only spanning tree instance that sends and receives BPDUs. All of the other spanning tree instance information is contained in MSTP records (M-records), which are encapsulated within MST BPDUs. Because the MST BPDU carries information for all instances, the number of BPDUs that need to be processed to support multiple spanning tree instances is significantly reduced.

All MST instances within the same region share the same protocol timers, but each MST instance has its own topology parameters, such as root bridge ID, root path cost, and so forth. By default, all VLANs are assigned to the IST.

An MST instance is local to the region; for example, MST instance 1 in region A is independent of MST instance 1 in region B, even if regions A and B are interconnected.

- A CIST is a collection of the ISTs in each MST region.
- The CST interconnects the MST regions and single spanning trees.

The spanning tree computed in a region appears as a subtree in the CST that encompasses the entire switched domain. The CIST is formed by the spanning tree algorithm running among switches that support the 802.1w, 802.1s, and 802.1D standards. The CIST inside an MST region is the same as the CST outside a region.

For more information, see the [“Spanning Tree Operation Within an MST Region” section on page 31-20](#) and the [“Spanning Tree Operations Between MST Regions” section on page 31-20](#).

### Spanning Tree Operation Within an MST Region

The IST connects all the MST switches in a region. When the IST converges, the root of the IST becomes the CIST regional root (called the *IST master* before the implementation of the 802.1s standard) as shown in [Figure 31-10 on page 31-21](#). The CIST regional root is also the CIST root if there is only one region in the network. If the CIST root is outside the region, one of the MST switches at the boundary of the region is selected as the CIST regional root.

When an MST switch initializes, it sends BPDUs that identify itself as the root of the CIST and the CIST regional root, with both of the path costs to the CIST root and to the CIST regional root set to zero. The switch also initializes all of its MST instances and claims to be the root for all of them. If the switch receives superior MST root information (lower switch ID, lower path cost, and so forth) than currently stored for the port, it relinquishes its claim as the CIST regional root.

During initialization, a region might have many subregions, each with its own CIST regional root. As switches receive superior IST information from a neighbor in the same region, they leave their old subregions and join the new subregion that contains the true CIST regional root, which causes all subregions to shrink except for the one that contains the true CIST regional root.


For correct operation, all switches in the MST region must agree on the same CIST regional root. Therefore, any two switches in the region only synchronize their port roles for an MST instance if they converge to a common CIST regional root.

### Spanning Tree Operations Between MST Regions

If there are multiple regions or 802.1D switches within the network, MST establishes and maintains the CST, which includes all MST regions and all 802.1D STP switches in the network. The MST instances combine with the IST at the boundary of the region to become the CST.

The IST connects all the MST switches in the region and appears as a subtree in the CIST that encompasses the entire switched domain. The root of the subtree is the CIST regional root. The MST region appears as a virtual switch to adjacent STP switches and MST regions.

[Figure 31-10](#) shows a network with three MST regions and an 802.1D switch (D). The CIST regional root for region 1 (A) is also the CIST root. The CIST regional root for region 2 (B) and the CIST regional root for region 3 (C) are the roots for their respective subtrees within the CIST.

**Figure 31-10** MST Regions, CIST Regional Roots, and CST Root

Only the CST instance sends and receives BPDUs, and MST instances add their spanning tree information into the BPDUs to interact with neighboring switches and compute the final spanning tree topology. Because of this, the spanning tree parameters related to BPDU transmission (for example, hello time, forward time, max-age, and max-hops) are configured only on the CST instance but affect all MST instances. Parameters related to the spanning tree topology (for example, switch priority, port VLAN cost, and port VLAN priority) can be configured on both the CST instance and the MST instance.

MST switches use Version 3 BPDUs or 802.1D STP BPDUs to communicate with 802.1D switches. MST switches use MST BPDUs to communicate with MST switches.

### IEEE 802.1s Terminology

Some MST naming conventions used in the prestandard implementation have been changed to include identification of some *internal* and *regional* parameters. These parameters are used only within an MST region, compared to external parameters that are used throughout the whole network. Because the CIST is the only spanning tree instance that spans the whole network, only the CIST parameters require the external qualifiers and not the internal or regional qualifiers.

- The CIST root is the root bridge for the CIST, which is the unique instance that spans the whole network.
- The CIST external root path cost is the cost to the CIST root. This cost is left unchanged within an MST region. Remember that an MST region looks like a single switch to the CIST. The CIST external root path cost is the root path cost calculated between these virtual switches and switches that do not belong to any region.

- The CIST regional root was called the IST master in the prestandard implementation. If the CIST root is in the region, the CIST regional root is the CIST root. Otherwise, the CIST regional root is the closest switch to the CIST root in the region. The CIST regional root acts as a root bridge for the IST.
- The CIST internal root path cost is the cost to the CIST regional root in a region. This cost is only relevant to the IST, instance 0.

Table 31-4 compares the IEEE standard and the Cisco prestandard terminology.

**Table 31-4**      *Prestandard and Standard Terminology*

| IEEE Standard Definition     | Cisco Prestandard Implementation | Cisco Standard Implementation |
|------------------------------|----------------------------------|-------------------------------|
| CIST regional root           | IST master                       | CIST regional root            |
| CIST internal root path cost | IST master path cost             | CIST internal path cost       |
| CIST external root path cost | Root path cost                   | Root path cost                |
| MSTI regional root           | Instance root                    | Instance root                 |
| MSTI internal root path cost | Root path cost                   | Root path cost                |

## Hop Count

MST does not use the message-age and maximum-age information in the configuration BPDU to compute the spanning tree topology. Instead, they use the path cost to the root and a hop-count mechanism similar to the IP time-to-live (TTL) mechanism.

By using the **spanning-tree mst max-hops** global configuration command, you can configure the maximum hops inside the region and apply it to the IST and all MST instances in that region. The hop count achieves the same result as the message-age information (triggers a reconfiguration). The root bridge of the instance always sends a BPDU (or M-record) with a cost of 0 and the hop count set to the maximum value. When a switch receives this BPDU, it decrements the received remaining hop count by one and propagates this value as the remaining hop count in the BPDUs it generates. When the count reaches zero, the switch discards the BPDU and ages the information held for the port.

The message-age and maximum-age information in the RSTP portion of the BPDU remain the same throughout the region, and the same values are propagated by the region-designated ports at the boundary.

## Boundary Ports

In the Cisco prestandard implementation, a boundary port connects an MST region to one of these STP regions:

- A single spanning tree region running RSTP
- A single spanning tree region running PVST+ or rapid PVST+
- Another MST region with a different MST configuration

A boundary port also connects to a LAN, the designated switch of which is either a single spanning tree switch or a switch with a different MST configuration.

There is no definition of a boundary port in the 802.1s standard. The 802.1Q-2002 standard identifies two kinds of messages that a port can receive: internal (coming from the same region) and external. When a message is external, it is received only by the CIST. If the CIST role is root or alternate, or if

the external BPDU is a topology change, it could have an impact on the MST instances. When a message is internal, the CIST part is received by the CIST, and each MST instance receives its respective M-record. The Cisco prestandard implementation treats a port that receives an external message as a boundary port, which means a port cannot receive a mix of internal and external messages.

An MST region includes both switches and LANs. A segment belongs to the region of its designated port. Therefore, a port in a different region from the designated port for a segment is a boundary port. This definition allows two ports internal to a region to share a segment with a port belonging to a different region, creating the possibility of receiving both internal and external messages on a port.

The primary change from the Cisco prestandard implementation is that a designated port is not defined as boundary unless it is running in an STP-compatible mode.

**Note**

---

If there is an 802.1D STP switch on the segment, messages are always considered external.

---

The other change from the prestandard implementation is that the CIST regional root bridge ID field is now inserted where an RSTP or legacy 802.1s switch has the sender switch ID. The whole region performs like a single virtual switch by sending a consistent sender switch ID to neighboring switches. In this example, switch C would receive a BPDU with the same consistent sender switch ID of root, whether or not A or B is designated for the segment.

## Standard-Compliant MST Implementation

- [Changes in Port-Role Naming, page 31-23](#)
- [Spanning Tree Interoperation Between Legacy and Standard-Compliant Switches, page 31-23](#)

**Note**

---

The standard-compliant MST implementation includes features required to meet the standard, as well as some of the desirable prestandard functionality that is not yet incorporated into the published standard.

---

### Changes in Port-Role Naming

The boundary role was deleted from the final MST standard, but this boundary concept is maintained in the standard-compliant implementation. However, an MST instance (MSTI) port at a boundary of the region might not follow the state of the corresponding CIST port. The following two situations currently exist:

- The boundary port is the root port of the CIST regional root—When the CIST instance port is proposed and is synchronized, it can send back an agreement and move to the forwarding state only after all the corresponding MSTI ports are synchronized (and thus forwarding). The MSTI ports now have a special *master* role.
- The boundary port is not the root port of the CIST regional root—The MSTI ports follow the state and role of the CIST port. The standard provides less information, and it might be difficult to understand why an MSTI port can be alternately blocking when it receives no BPDUs (M-records). In this situation, although the boundary role no longer exists, when you enter the **show** commands, they identify a port as boundary in the *type* column of the output.


### Spanning Tree Interoperation Between Legacy and Standard-Compliant Switches

Because automatic detection of prestandard switches can fail, you can use an interface configuration command to identify prestandard ports. A region cannot be formed between a standard and a prestandard switch, but they can interoperate before using the CIST. Only the capability of load balancing over

different instances is lost in this specific situation. The CLI displays different flags depending on the port configuration when the port receives prestandard BPDUs. A syslog message also appears the first time a switch receives a prestandard BPDU on a port that has not been configured for prestandard BPDU transmission.

Figure 31-11 illustrates a standard-compliant switch connected to a prestandard switch. Assume that A is the standard-compliant switch and B is a prestandard switch, both configured to be in the same region. A is the root bridge for the CIST, and so B has a root port (BX) on segment X and an alternate port (BY) on segment Y. If segment Y flaps, and the port on BY becomes the alternate before sending out a single prestandard BPDU, AY cannot detect that a prestandard switch is connected to Y and continues to send standard BPDUs. The port BY is fixed in a boundary, and no load balancing is possible between A and B. The same problem exists on segment X, but B might transmit topology changes.

**Figure 31-11** Standard-Compliant and Prestandard Switch Interoperation



**Note**

We recommend that you minimize the interaction between standard and prestandard MST implementations.

## Interoperability with IEEE 802.1D-1998 STP

A switch running MST supports a built-in protocol migration feature that enables it to interoperate with 802.1D switches. If this switch receives an 802.1D configuration BPDU (a BPDU with the protocol version set to 0), it sends only 802.1D BPDUs on that port. An MST switch also can detect that a port is at the boundary of a region when it receives an 802.1D BPDU, an MST BPDU (Version 3) associated with a different region, or an RSTP BPDU (Version 2).

However, the switch does not automatically revert to the MST mode if it no longer receives 802.1D BPDUs because it cannot detect whether the 802.1D switch has been removed from the link unless the 802.1D switch is the designated switch. A switch might also continue to assign a boundary role to a port when the switch to which this switch is connected has joined the region. To restart the protocol migration process (force the renegotiation with neighboring switches), use the **clear spanning-tree detected-protocols** privileged EXEC command.

If all the 802.1D switches on the link are RSTP switches, they can process MST BPDUs as if they are RSTP BPDUs. Therefore, MST switches send either a Version 0 configuration and topology change notification (TCN) BPDUs or Version 3 MST BPDUs on a boundary port. A boundary port connects to a LAN, the designated switch of which is either a single spanning tree switch or a switch with a different MST configuration.


## Detecting Unidirectional Link Failure

Using the dispute mechanism included in the IEEE 802.1D-2004 RSTP and IEEE 802.1Q-2005 MSTP standard, the switch checks the consistency of the port role and state in the received BPDUs to detect unidirectional link failures that could cause bridging loops.

When a designated port detects a conflict, it keeps its role, but reverts to a discarding (blocking) state because disrupting connectivity in case of inconsistency is preferable to opening a bridging loop.

Figure 31-12 illustrates a unidirectional link failure that typically creates a bridging loop. Switch A is the root bridge, and its BPDUs are lost on the link leading to switch B. RSTP and MST BPDUs include the role and state of the sending port. With this information, switch A can detect that switch B does not react to the superior BPDUs it sends and that switch B is the designated, not root bridge. As a result, switch A blocks (or keeps blocking) its port, thus preventing the bridging loop.

**Figure 31-12** Detecting Unidirectional Link Failure



## Default Settings for Spanning Tree Protocols

- [Default STP Configuration, page 31-25](#)
- [Default MST Configuration, page 31-26](#)

### Default STP Configuration

| Feature                                                                                                       | Default Value         |     |
|---------------------------------------------------------------------------------------------------------------|-----------------------|-----|
| Mode                                                                                                          | Rapid PVST+           |     |
| Enable state                                                                                                  | Enabled for all VLANs |     |
| Bridge priority                                                                                               | 32768                 |     |
| STP port priority (configurable on a per-port basis—used on LAN ports configured as Layer 2 access ports)     | 128                   |     |
| STP port cost (configurable on a per-port basis—used on LAN ports configured as Layer 2 access ports)         | 10-Gigabit Ethernet:  | 2   |
|                                                                                                               | Gigabit Ethernet:     | 4   |
|                                                                                                               | Fast Ethernet:        | 19  |
|                                                                                                               | Ethernet:             | 100 |
| STP VLAN port priority (configurable on a per-VLAN basis—used on LAN ports configured as Layer 2 trunk ports) | 128                   |     |

| Feature                                                                                                   | Default Value        |     |
|-----------------------------------------------------------------------------------------------------------|----------------------|-----|
| STP VLAN port cost (configurable on a per-VLAN basis—used on LAN ports configured as Layer 2 trunk ports) | 10-Gigabit Ethernet: | 2   |
|                                                                                                           | Gigabit Ethernet:    | 4   |
|                                                                                                           | Fast Ethernet:       | 19  |
|                                                                                                           | Ethernet:            | 100 |
| Hello time                                                                                                | 2 seconds            |     |
| Forward delay time                                                                                        | 15 seconds           |     |
| Maximum aging time                                                                                        | 20 seconds           |     |

## Default MST Configuration

| Feature                                                                        | Default Setting                  |           |
|--------------------------------------------------------------------------------|----------------------------------|-----------|
| Spanning tree mode                                                             | Rapid PVST+<br>(MST is disabled) |           |
| Switch priority<br>(configurable on a per-MST port basis)                      | 32768                            |           |
| Spanning tree port priority<br>(configurable on a per-MST instance port basis) | 128                              |           |
| Spanning tree port cost<br>(configurable on a per-MST instance port basis)     | 10-Gigabit Ethernet:             | 2,000     |
|                                                                                | Gigabit Ethernet:                | 20,000    |
|                                                                                | Fast Ethernet:                   | 200,000   |
|                                                                                | Ethernet:                        | 2,000,000 |
| Hello time                                                                     | 2 seconds                        |           |
| Forward-delay time                                                             | 15 seconds                       |           |
| Maximum-aging time                                                             | 20 seconds                       |           |
| Maximum hop count                                                              | 20 hops                          |           |

## How to Configure Spanning Tree Protocols

- [Configuring STP, page 31-26](#)
- [Configuring MST, page 31-37](#)

### Configuring STP

- [Enabling STP, page 31-27](#)
- [Enabling the Extended System ID, page 31-28](#)
- [Configuring the Root Bridge, page 31-29](#)
- [Configuring a Secondary Root Bridge, page 31-30](#)



- [Configuring STP Port Priority, page 31-31](#)
- [Configuring STP Port Cost, page 31-32](#)
- [Configuring the Bridge Priority of a VLAN, page 31-34](#)
- [Configuring the Hello Time, page 31-35](#)
- [Configuring the Forward-Delay Time for a VLAN, page 31-35](#)
- [Configuring the Maximum Aging Time for a VLAN, page 31-36](#)
- [Enabling Rapid-PVST+, page 31-36](#)

**Note**

The STP commands described in this chapter can be configured on any LAN port, but they are in effect only on LAN ports configured with the **switchport** keyword.

**Caution**

We do not recommend disabling spanning tree, even in a topology that is free of physical loops. Spanning tree serves as a safeguard against misconfigurations and cabling errors. Do not disable spanning tree in a VLAN without ensuring that there are no physical loops present in the VLAN.

## Enabling STP

**Note**

STP is enabled by default on VLAN 1 and on all newly created VLANs.

You can enable STP on a per-VLAN basis. The switch maintains a separate instance of STP for each VLAN (except on VLANs on which you disable STP).

To enable STP on a per-VLAN basis, perform this task:

|        | Command                                                            | Purpose                                                                                                                                                                          |
|--------|--------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "urcpgkpi/vtgg"xncp" vlan_ID"</code>         | Enables STP on a per-VLAN basis. The <i>vlan_ID</i> value can be 1 through 4094, except reserved VLANs (see <a href="#">“Default STP Configuration” section on page 31-25</a> ). |
|        | <code>Tqwgvt*eqphki+% "fghcwnv"urcpgkpi/vtgg"xncp" vlan_ID"</code> | Reverts all STP parameters to default values for the specified VLAN.                                                                                                             |
|        | <code>Tqwgvt*eqphki+% "pq"urcpgkpi/vtgg"xncp" vlan_ID"</code>      | Disables STP on the specified VLAN; see the following Cautions for information regarding this command.                                                                           |
| Step 2 | <code>Tqwgvt*eqphki+% "gpf"</code>                                 | Exits configuration mode.                                                                                                                                                        |

**Caution**

Do not disable spanning tree on a VLAN unless all switches and bridges in the VLAN have spanning tree disabled. You cannot disable spanning tree on some switches and bridges in a VLAN and leave it enabled on other switches and bridges in the VLAN. This action can have unexpected results because switches and bridges with spanning tree enabled will have incomplete information regarding the physical topology of the network.

**Caution**

We do not recommend disabling spanning tree, even in a topology that is free of physical loops. Spanning tree serves as a safeguard against misconfigurations and cabling errors. Do not disable spanning tree in a VLAN without ensuring that there are no physical loops present in the VLAN.

This example shows how to enable STP on VLAN 200:

```
Tqwgvt%eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+%"urcppkpi/vtgg"xncp"422"
Tqwgvt*eqphki+%"gpf"
Tqwgvt%
```

**Note**

Because STP is enabled by default, entering a **show running** command to view the resulting configuration does not display the command you entered to enable STP.

This example shows how to verify the configuration:

```
Tqwgvt%ujqy"urcppkpi/vtgg"xncp"422"

XNCP2422
 "Urcppkpi"vtgg"gpdcngf"rtqvqeqn"kggg
 "Tqgy"KF""Rtkqtkv{"5498:
 "Cfftguu""22f2022d:036e:
 "Vjku"dtkfig"ku"vjg"tqqv
 "Jgnnq"Vkog""4"uge"Ocz"Cig"42"uge" "Hqtyctf"fgnc{"37"uge

 "Dtkfig"KF""Rtkqtkv{"5498:
 "Cfftguu""22f2022d:036e:
 "Jgnnq"Vkog""4"uge"Ocz"Cig"42"uge" "Hqtyctf"fgnc{"37"uge
 "Cikpi"Vkog"522

Kpvgthceg""Tqng"Uvu"Equv""Rtkq0Pdt"Uvcvwu
////////////////////////////////////
Ik316""Fgui"HYF"422222""34:03;8"R4r"
Ik317""Dcem"DNM"422222""34:03;9"R4r"

Tqwgvt%
```

**Note**

You must have at least one interface that is active in VLAN 200 to create a VLAN 200 spanning tree. In this example, two interfaces are active in VLAN 200.

## Enabling the Extended System ID

**Note**

- The extended system ID is enabled permanently on chassis that support 64 MAC addresses.
- You must enable the extended system ID to configure extended range VLANs (1006-4094).
- You must enable the extended system ID if it is enabled on any switches in the VTP domain.

You can enable the extended system ID on chassis that support 1024 MAC addresses (see the [“Information about the Bridge ID” section on page 31-3](#)).

To enable the extended system ID, perform this task:

|        | Command                                                       | Purpose                                                                                                                                                                                                                              |
|--------|---------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+% "urcppkpi/vtgg"gzvgpf"u{uvgo/kf"</code> | Enables the extended system ID.<br><br><b>Note</b> You cannot disable the extended system ID on chassis that support 64 MAC addresses or when you have configured extended range VLANs (see the “VLAN Ranges” section on page 26-2). |
| Step 2 | <code>Tqwwgt*eqphki+% "gpf"</code>                            | Exits configuration mode.                                                                                                                                                                                                            |

**Note**

When you enable or disable the extended system ID, the bridge IDs of all active STP instances are updated, which might change the spanning tree topology.

This example shows how to enable the extended system ID:

```
Tqwwgt% "eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+% "urcppkpi/vtgg"gzvgpf"u{uvgo/kf"
Tqwwgt*eqphki+% "gpf"
Tqwwgt%
```

This example shows how to verify the configuration:

```
Tqwwgt% "ujqy"urcppkpi/vtgg"uwooct { "~"kpenwfg"Gzvgpf"gf
Gzvgpf"gf"u{uvgo"KF"ku"gpdcngf0
```

## Configuring the Root Bridge

The switches supported by Cisco IOS Release 15.4SY maintain a separate instance of STP for each active VLAN. A bridge ID, consisting of the bridge priority and the bridge MAC address, is associated with each instance. For each VLAN, the network device with the lowest bridge ID becomes the root bridge for that VLAN.

To configure a VLAN instance to become the root bridge, enter the **spanning-tree vlan *vlan\_ID* root** command to modify the bridge priority from the default value (32768) to a significantly lower value.

When you enter the **spanning-tree vlan *vlan\_ID* root** command, the switch checks the bridge priority of the current root bridges for each VLAN. With the extended system ID enabled, the switch sets the bridge priority for the specified VLANs to 24576 if this value will cause the switch to become the root for the specified VLANs.

With the extended system ID enabled, if any root bridge for the specified VLANs has a bridge priority lower than 24576, the switch sets the bridge priority for the specified VLANs to 4096 less than the lowest bridge priority. (4096 is the value of the least significant bit of a 4-bit bridge priority value; see [Table 31-1 on page 31-4](#).)

**Note**

The **spanning-tree vlan *vlan\_ID* root** command fails if the value required to be the root bridge is less than 1.

With the extended system ID enabled, if all network devices in, for example, VLAN 20 have the default priority of 32768, entering the **spanning-tree vlan 20 root primary** command on the switch sets the bridge priority to 24576, which causes the switch to become the root bridge for VLAN 20.

**Caution**

The root bridge for each instance of STP should be a backbone or distribution switch. Do not configure an access switch as the STP primary root.

Use the **diameter** keyword to specify the Layer 2 network diameter (that is, the maximum number of bridge hops between any two end stations in the Layer 2 network). When you specify the network diameter, the switch automatically selects an optimal hello time, forward delay time, and maximum age time for a network of that diameter, which can significantly reduce the STP convergence time. You can use the **hello** keyword to override the automatically calculated hello time.

**Note**

To preserve a stable STP topology, we recommend that you avoid configuring the hello time, forward delay time, and maximum age time manually after configuring the switch as the root bridge.

To configure the switch as the root bridge, perform this task:

|        | Command                                                                                                            | Purpose                                                                                                                                                                                   |
|--------|--------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "urcppkpi/vtgg"xncp"vlan_ID"tqqv"rtkcoct{" ] fkcogvgt" jqrux" ] jgnnq/vkog"ugeqpfu__"</code> | Configures the switch as the root bridge. The <i>vlan_ID</i> value can be 1 through 4094, except reserved VLANs (see <a href="#">“Default STP Configuration” section on page 31-25</a> ). |
|        | <code>Tqwvgt*eqphki+% "pq"urcppkpi/vtgg"xncp"vlan_ID"tqqv"</code>                                                  | Clears the root bridge configuration.                                                                                                                                                     |
| Step 2 | <code>Tqwvgt*eqphki+% "gpf"</code>                                                                                 | Exits configuration mode.                                                                                                                                                                 |

This example shows how to configure the switch as the root bridge for VLAN 10, with a network diameter of 4:

```
Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+% "urcppkpi/vtgg"xncp"32"tqqv"rtkcoct{" fkcogvgt"6"
Tqwvgt*eqphki+% "gpf"
Tqwvgt%
```

## Configuring a Secondary Root Bridge

When you configure a switch as the secondary root, the STP bridge priority is modified from the default value (32768) so that the switch is likely to become the root bridge for the specified VLANs if the primary root bridge fails (assuming the other network devices in the network use the default bridge priority of 32768).

With the extended system ID is enabled, STP sets the bridge priority to 28672.

You can run this command on more than one switch to configure multiple backup root bridges. Use the same network diameter and hello time values as you used when configuring the primary root bridge.

To configure the switch as the secondary root bridge, perform this task:

|        | Command                                                                                                                  | Purpose                                                                                                                                                                                             |
|--------|--------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+%]pq"urcpgkpi/vtgg"xncp"vlan_ID"<br/>tqqv"ugeqpfct{"fkcgvgvt"jgru"]jgnnq/vkog"<br/>ugeqpfu__"</code> | Configures the switch as the secondary root bridge. The <i>vlan_ID</i> value can be 1 through 4094, except reserved VLANs (see <a href="#">“Default STP Configuration” section on page 31-25</a> ). |
|        | <code>Tqwwgt*eqphki+%pq"urcpgkpi/vtgg"xncp"vlan_ID"<br/>tqqv"</code>                                                     | Clears the root bridge configuring.                                                                                                                                                                 |
| Step 2 | <code>Tqwwgt*eqphki+%gpf"</code>                                                                                         | Exits configuration mode.                                                                                                                                                                           |

This example shows how to configure the switch as the secondary root bridge for VLAN 10, with a network diameter of 4:

```
Tqwwgt%eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+%urcpgkpi/vtgg"xncp"32tqqv"ugeqpfct{"fkcgvgvt"6"
Tqwwgt*eqphki+%gpf"
Tqwwgt%
```

## Configuring STP Port Priority

If a loop occurs, STP considers port priority when selecting a LAN port to put into the forwarding state. You can assign higher priority values to LAN ports that you want STP to select first and lower priority values to LAN ports that you want STP to select last. If all LAN ports have the same priority value, STP puts the LAN port with the lowest LAN port number in the forwarding state and blocks other LAN ports. The possible priority range is 0 through 240 (default 128), configurable in increments of 16.

Cisco IOS uses the port priority value when the LAN port is configured as an access port and uses VLAN port priority values when the LAN port is configured as a trunk port.

To configure the STP port priority of a Layer 2 LAN interface, perform this task:

|        | Command                                                                                                                                               | Purpose                                                                                                                                                                                                                                                |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+%kpvgtthceg"<br/>}}hcuvgvjgtpgv ~ ikicdkvgvjgtpgv~"vgpikicdkvgvjgtpgv;"<br/>unqvlrqtv~"}rqtv/ejcppgn"rqtvaejcppgnapwodgt;"</code> | Selects an interface to configure.                                                                                                                                                                                                                     |
| Step 2 | <code>Tqwwgt*eqphki/kh+%urcpgkpi/vtgg"rqtv/rtkqtkv{"<br/>rqtvartkqtkv{"</code>                                                                        | Configures the port priority for the LAN interface. The <i>port_priority</i> value can be from 1 to 252 in increments of 4.                                                                                                                            |
| Step 3 | <code>Tqwwgt*eqphki/kh+%urcpgkpi/vtgg"xncp"vlan_ID"<br/>rqtv/rtkqtkv{"rqtvartkqtkv{"</code>                                                           | Configures the VLAN port priority for the LAN interface. The <i>port_priority</i> value can be from 1 to 252 in increments of 4. The <i>vlan_ID</i> value can be 1 through 4094, except reserved VLANs (see <a href="#">Table 26-1 on page 26-3</a> ). |
| Step 4 | <code>Tqwwgt*eqphki/kh+%gpf"</code>                                                                                                                   | Exits configuration mode.                                                                                                                                                                                                                              |

This example shows how to configure the STP port priority of Gigabit Ethernet port 1/4:

```
Tqwwgt%eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+%kpvgtthceg"ikicdkvgvjgtpgv 316
Tqwwgt*eqphki/kh+%urcpgkpi/vtgg"rqtv/rtkqtkv{"382"
Tqwwgt*eqphki/kh+%gpf"
Tqwwgt%
```

```
Tqwgvt%"ujqy"urcppkpi/vtgg"kpvgt hceg"ikicdkvgvjgtpgv 316"
Xncp" " " " " " " " " "Tqng"Uvu"Equv" " " " "Rtkq0Pdt"Uvcvwu
////////////////////////////////////
XNCP2223" " " " " " " " "Dcem"DNM"422222" " " "38203;8""R4r"
XNCP2228" " " " " " " " "Dcem"DNM"422222" " " "38203;8""R4r"
000
XNCP23;:" " " " " " " " "Dcem"DNM"422222" " " "38203;8""R4r"
XNCP23;;" " " " " " " " "Dcem"DNM"422222" " " "38203;8""R4r"
XNCP2422" " " " " " " " "Dcem"DNM"422222" " " "38203;8""R4r"
Tqwgvt%
```



The **show spanning-tree interface** command only displays information if the port is connected and operating. If this condition is not met, enter a **show running-config interface** command to verify the configuration.

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpg0""Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv 316"
Tqvwgt*eqphki/kh+%"urcppkpi/vtgg"xncp"422"rqtv/rtkqtkv{"86"
Tqvwgt*eqphki/kh+%"gpf"
Tqvwgt%
```

```
Tqwgvt%"ujqy"urcppkpi/vtgg"kpvgt hceg"ikicdkvgvjgtpgv 316
Xncp" " " " " " " " " "Tqng"Uvu"Equv" " " " "Rtkq0Pdt"Uvcvwu
//////////////////////////////////////
XNCP2223" " " " " " " " " "Dcem"DNM"422222" " " "38203;8""R4r"
XNCP2228" " " " " " " " " "Dcem"DNM"422222" " " "38203;8""R4r"
000
XNCP23;;" " " " " " " " " "Dcem"DNM"422222" " " "38203;8""R4r"
XNCP2422" " " " " " " " " "Fgui"HYF"422222" " " "8603;8""R4r"

Tqwgvt%
```

[illegible]

The STP port path cost default value is determined from the media speed of a LAN interface. If a loop occurs, STP considers port cost when selecting a LAN interface to put into the forwarding state. You can assign lower cost values to LAN interfaces that you want STP to select first and higher cost values to LAN interfaces that you want STP to select last. If all LAN interfaces have the same cost value, STP puts the LAN interface with the lowest LAN interface number in the forwarding state and blocks other LAN interfaces. The possible cost range is 0 through 200000000 (the default is media specific).

STP uses the port cost value when the LAN interface is configured as an access port and uses VLAN port cost values when the LAN interface is configured as a trunk port.

To configure the STP port cost of a Layer 2 LAN interface, perform this task:

|        | Command                                                                                                                                                        | Purpose                                                                                                                                                                                                                                                                         |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "kpvgthceg"<br/>}}hcuvgvjgtpgv ~ ikicdkvgvjgtpgv~"vgpikicdkvgvjgtpgv;<br/>unqvlrgtv"~"}rqtv/ejcppgn" rgtvaejcppgnapwodgt;</code>         | Selects an interface to configure.                                                                                                                                                                                                                                              |
| Step 2 | <code>Tqvwgt*eqphki/kh+% "urcppkpi/vtgg"equiv" rgtvaequv"</code><br><br><code>Tqvwgt*eqphki/kh+% "pq"urcppkpi/vtgg"equiv"</code>                               | Configures the port cost for the LAN interface. The <i>port_cost</i> value can be from 1 to 200000000.<br><br>Reverts to the default port cost.                                                                                                                                 |
| Step 3 | <code>Tqvwgt*eqphki/kh+% "urcppkpi/vtgg"xncp"vlan_ID"equiv"<br/>rgtvaequv"</code><br><br><code>Tqvwgt*eqphki/kh+% "pq"urcppkpi/vtgg"xncp"vlan_ID"equiv"</code> | Configures the VLAN port cost for the LAN interface. The <i>port_cost</i> value can be from 1 to 200000000. The <i>vlan_ID</i> value can be 1 through 4094, except reserved VLANs (see <a href="#">Table 26-1 on page 26-3</a> ).<br><br>Reverts to the default VLAN port cost. |
| Step 4 | <code>Tqvwgt*eqphki/kh+% "gpf"</code>                                                                                                                          | Exits configuration mode.                                                                                                                                                                                                                                                       |

This example shows how to change the STP port cost of Gigabit Ethernet port 1/4:

```
Tqvwgt% "eqphkiwtg"vgtokpcn
Gpvgt "eqphkiwtcvkqp"eqoocpfu. "qpg"rgt "nkp0" "Gpf"ykvj "EPVN1\0
Tqvwgt*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv 316
Tqvwgt*eqphki/kh+% "urcppkpi/vtgg"equiv"3222"
Tqvwgt*eqphki/kh+% "gpf"
Tqvwgt%
```

This example shows how to verify the configuration:

```
Tqvwgt% "ujqy"urcppkpi/vtgg"kpvgthceg"ikicdkvgvjgtpgv 316
Xncp " " " " "Tqng"Uvu"Equv" " " "Rtkq0Pdt"Uvcvwu
//////////////////////////////////////
XNCP2223 " " " " "Dcem"DNM"3222 " " "38203;8" "R4r"
XNCP2228 " " " " "Dcem"DNM"3222 " " "38203;8" "R4r"
XNCP2229 " " " " "Dcem"DNM"3222 " " "38203;8" "R4r"
XNCP222: " " " " "Dcem"DNM"3222 " " "38203;8" "R4r"
XNCP222; " " " " "Dcem"DNM"3222 " " "38203;8" "R4r"
XNCP2232 " " " " "Dcem"DNM"3222 " " "38203;8" "R4r"
Tqvwgt%
```

This example shows how to configure the port priority at an individual port VLAN cost for VLAN 200:

```
Tqvwgt% "eqphkiwtg"vgtokpcn
Gpvgt "eqphkiwtcvkqp"eqoocpfu. "qpg"rgt "nkp0" "Gpf"ykvj "EPVN1\0
Tqvwgt*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv 316
Tqvwgt*eqphki/kh+% "urcppkpi/vtgg"xncp"422"equiv"4222"
Tqvwgt*eqphki/kh+% "gpf"
Tqvwgt%
```

This example shows how to verify the configuration:

```
Tqvwgt% "ujqy"urcppkpi/vtgg"xncp"422"kpvgthceg"ikicdkvgvjgtpgv 316
Kpvgthceg " " " " "Tqng"Uvu"Equv" " " "Rtkq0Pdt"Uvcvwu
//////////////////////////////////////
Ik316 " " " " "Fgui"HYF"4222 " " "8603;8" "R4r"
```



## Note

In the following output other VLANs (VLAN 1 for example) have not been affected by this configuration.

```
Tqwgvt% "ujqy"urcppkpi/vtgg"xncp"3"kpvgtghecg"iki cdkvgvjgtpgv 316"
Kpvgtghecg" "" "" "" ""Tqng"Uvu"Eguv" "" ""Rtkg0Pd"Uvcvwu
////////////////////////////////////
Ik316" "" "" "" ""Dcem"DNM"3222" "" ""38203;8""R4r"
Tqwgvt%
```



### Note

The **show spanning-tree** command only displays information for ports that are in link-up operative state and are appropriately configured for DTP. If these conditions are not met, you can enter a **show running-config** command to confirm the configuration.

## Configuring the Bridge Priority of a VLAN



### Note

Be careful when using this command. For most situations, we recommend that you enter the **spanning-tree vlan *vlan\_ID* root primary** and the **spanning-tree vlan *vlan\_ID* root secondary** commands to modify the bridge priority.

To configure the STP bridge priority of a VLAN, perform this task:

|        | Command                                                                                                                                                                                                    | Purpose                                                                                                                                                                                                |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "urcppkpi/vtgg"xncp"vlan_ID"<br/>rtkqtkv{"}2"~"62;8"~":3;4"~"344::"~"385:6"~"426:2"<br/>~"46798"~"4:894"~"5498:"~"58:86"~"62;82"~"67278"~"<br/>6;374"~"7546:"~"79566"~"83662;</code> | Configures the bridge priority of a VLAN when the extended system ID is enabled. The <i>vlan_ID</i> value can be 1 through 4094, except reserved VLANs (see <a href="#">Table 26-1 on page 26-3</a> ). |
| Step 2 | <code>Tqwgvt*eqphki+% "gp f"</code>                                                                                                                                                                        | Exits configuration mode.                                                                                                                                                                              |

This example shows how to configure the bridge priority of VLAN 200 to 33792 when the extended system ID is disabled:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+%urcppkpi/vtgg"xncp"422"rtkqtkv{"5498:"
Tqwgvt*eqphki+%gpf"
Tqwgvt%
```

This example shows how to verify the configuration:

```
Tqwgvt%"ujqy"urcpgkpi/vtgg"xncp"422"dtkfig"
#####Jgnnq'Ocz'"Hyf
Xncp"#####Dtkfig"KF"#####Vkog'"Cig"Fgnc{"Rtgvgqn
/////////////////////////"/////////////////////////"/////////////////////////
XNCP422"#####5498:"227205g:f086e:""4""42""37""kggg
Tqwgvt%"
```



## Configuring the Hello Time



### Note

Be careful when using this command. For most situations, we recommend that you use the **spanning-tree vlan *vlan\_ID* root primary** and **spanning-tree vlan *vlan\_ID* root secondary** commands to modify the hello time.

To configure the STP hello time of a VLAN, perform this task:

|        | Command                                                                                       | Purpose                                                                                                                                                                                                             |
|--------|-----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+% "urcpgkpi/vtgg"xncp" <i>vlan_ID</i>"<br/>jgnng/vkog" jgnngavkog"</code> | Configures the hello time of a VLAN. The <i>hello_time</i> value can be from 1 to 10 seconds. The <i>vlan_ID</i> value can be 1 through 4094, except reserved VLANs (see <a href="#">Table 26-1 on page 26-3</a> ). |
| Step 2 | <code>Tqwwgt*eqphki+% "gpf"</code>                                                            | Exits configuration mode.                                                                                                                                                                                           |

This example shows how to configure the hello time for VLAN 200 to 7 seconds:

```
Tqwwgt% "eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+% "urcpgkpi/vtgg"xncp"422"jgnng/vkog"9"
Tqwwgt*eqphki+% "gpf"
Tqwwgt%
```

This example shows how to verify the configuration:

```
Tqwwgt% "ujqy"urcpgkpi/vtgg"xncp"422"dtkfig"
*****Jgnng"Ocz"Hyf
Xncp*****Dtkfig"KF"*****Vkog"Cig"Fgnc{" "Rtqvgeqn
/////////////////////////"/////////////////////////"/////////////////////////"
XNCP422"*****6;374"227205g:f086e:"""9""42""37""kggg
Tqwwgt%
```

## Configuring the Forward-Delay Time for a VLAN

To configure the STP forward delay time for a VLAN, perform this task:

|        | Command                                                                                           | Purpose                                                                                                                                                                                                                 |
|--------|---------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+% "urcpgkpi/vtgg"xncp" <i>vlan_ID</i>"<br/>hqtyctf/vkog" hqtyctfavkog"</code> | Configures the forward time of a VLAN. The <i>forward_time</i> value can be from 4 to 30 seconds. The <i>vlan_ID</i> value can be 1 through 4094, except reserved VLANs (see <a href="#">Table 26-1 on page 26-3</a> ). |
|        | <code>Tqwwgt*eqphki+% "pq"urcpgkpi/vtgg"xncp" <i>vlan_ID</i>"<br/>hqtyctf/vkog"</code>            | Reverts to the default forward time.                                                                                                                                                                                    |
| Step 2 | <code>Tqwwgt*eqphki+% "gpf"</code>                                                                | Exits configuration mode.                                                                                                                                                                                               |

This example shows how to configure the forward delay time for VLAN 200 to 21 seconds:

```
Tqwwgt% "eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+% "urcpgkpi/vtgg"xncp"422"hqtyctf/vkog"43"
Tqwwgt*eqphki+% "gpf"
Tqwwgt%
```

This example shows how to verify the configuration:

```
Tqwgvt%"ujqy"urcppkpi/vtgg"xncp"422"dtkfig"
"Jgnnq"Ocz"Hyf
Xncp"Dtkfig"KF"Vkog"Cig"Fgnc{"Rtqvgeqn
//
XNCP422"6;374"227205g:f086e:"4"42"43"kggg
Tqwgvt%
```

## Configuring the Maximum Aging Time for a VLAN

To configure the STP maximum aging time for a VLAN, perform this task:

|        | Command                                                                  | Purpose                                                                                                                                                                                                                  |
|--------|--------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%"urcppkpi/vtgg"xncp"vlan_ID"ocz/cig"oczacig"</code> | Configures the maximum aging time of a VLAN. The <i>max_age</i> value can be from 6 to 40 seconds. The <i>vlan_ID</i> value can be 1 through 4094, except reserved VLANs (see <a href="#">Table 26-1 on page 26-3</a> ). |
| Step 2 | <code>Tqwgvt*eqphki+%"gpf"</code>                                        | Exits configuration mode.                                                                                                                                                                                                |

This example shows how to configure the maximum aging time for VLAN 200 to 36 seconds:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+%"urcppkpi/vtgg"xncp"422"ocz/cig"58"
Tqwgvt*eqphki+%"gpf"
Tqwgvt%
```

This example shows how to verify the configuration:

```
Tqwgvt%"ujqy"urcppkpi/vtgg"xncp"422"dtkfig"
"Jgnnq"Ocz"Hyf
Xncp"Dtkfig"KF"Vkog"Cig"Fgnc{"Rtqvgeqn
//
XNCP422"6;374"227205g:f086e:"4"58"37"kggg
Tqwgvt%
```

## Enabling Rapid-PVST+

- [Rapid-PVST+ Overview, page 31-36](#)
- [Specifying the Link Type, page 31-37](#)
- [Restarting Protocol Migration, page 31-37](#)



### Note

Rapid-PVST+ is enabled by default. Use the procedures to reenble Rapid-PVST+.

## Rapid-PVST+ Overview

Rapid-PVST+ uses the existing PVST+ framework for configuration and interaction with other features. It also supports some of the PVST+ extensions.

To enable Rapid-PVST+ mode on the switch, enter the **spanning-tree mode rapid-pvst** command in privileged mode. To configure the switch in Rapid-PVST+ mode, see the [“Configuring STP” section on page 31-26](#).

## Specifying the Link Type

Rapid connectivity is established only on point-to-point links. Spanning tree views a point-to-point link as a segment connecting only two switches running the spanning tree algorithm. Because the switch assumes that all full-duplex links are point-to-point links and that half-duplex links are shared links, you can avoid explicitly configuring the link type. To configure a specific link type, enter the **spanning-tree linktype** command.

## Restarting Protocol Migration

A switch running both MSTP and RSTP supports a built-in protocol migration process that enables the switch to interoperate with legacy 802.1D switches. If this switch receives a legacy 802.1D configuration BPDU (a BPDU with the protocol version set to 0), it sends only 802.1D BPDUs on that port. An MSTP switch can also detect that a port is at the boundary of a region when it receives a legacy BPDU, or an MST BPDU (version 3) associated with a different region, or an RST BPDU (version 2).

However, the switch does not automatically revert to the MSTP mode if it no longer receives 802.1D BPDUs because it cannot determine whether the legacy switch has been removed from the link unless the legacy switch is the designated switch. A switch also might continue to assign a boundary role to a port when the switch to which it is connected has joined the region.

To restart the protocol migration process (force the renegotiation with neighboring switches) on the entire switch, you can use the **clear spanning-tree detected-protocols** privileged EXEC command. To restart the protocol migration process on a specific interface, enter the **clear spanning-tree detected-protocols interface *interface-id*** privileged EXEC command.

## Configuring MST

- [Default MST Configuration, page 31-26](#)
- [Specifying the MST Region Configuration and Enabling MST, page 31-38](#) (required)
- [Configuring the Root Bridge, page 31-39](#) (optional)
- [Configuring a Secondary Root Bridge, page 31-30](#) (optional)
- [Configuring STP Port Priority, page 31-31](#) (optional)
- [Configuring Path Cost, page 31-42](#) (optional)
- [Configuring the Switch Priority, page 31-43](#) (optional)
- [Configuring the Hello Time, page 31-44](#) (optional)
- [Configuring the Transmit Hold Count, page 31-45](#) (optional)
- [Configuring the Maximum-Aging Time, page 31-45](#) (optional)
- [Configuring the Maximum-Hop Count, page 31-46](#) (optional)
- [Specifying the Link Type to Ensure Rapid Transitions, page 31-46](#) (optional)
- [Designating the Neighbor Type, page 31-46](#) (optional)
- [Restarting the Protocol Migration Process, page 31-47](#) (optional)
- [Displaying the MST Configuration and Status, page 31-47](#)

## Specifying the MST Region Configuration and Enabling MST

For two or more switches to be in the same MST region, they must have the same VLAN-to-instance mapping, the same configuration revision number, and the same MST name.

A region can have one member or multiple members with the same MST configuration; each member must be capable of processing RSTP BPDUs. There is no limit to the number of MST regions in a network, but each region can only support up to 65 spanning tree instances. You can assign a VLAN to only one spanning tree instance at a time.

To specify the MST region configuration and enable MST, perform this task:

|        | Command                                                                      | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|--------|------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt%<b>"eqphkiwtg"vgtokpcn</b></code>                               | Enters global configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Step 2 | <code>Tqwgvt*eqphki+%<b>"urcppkpi/vtgg"ouv"eqphkiwtcvkqp</b></code>          | Enters MST configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Step 3 | <code>Tqwgvt*eqphki/ouv+%<b>"kpuvcpeg"kpucpegakf"xncp"xnccatcpig"</b></code> | Maps VLANs to an MST instance. <ul style="list-style-type: none"> <li>For <i>instance_id</i>, the range is 0 to 4094.</li> <li>For <b>vlan vlan_range</b>, the range is 1 to 4094.</li> </ul> <p>When you map VLANs to an MST instance, the mapping is incremental, and the VLANs specified in the command are added to or removed from the VLANs that were previously mapped.</p> <p>To specify a VLAN range, use a hyphen; for example, <b>instance 1 vlan 1-63</b> maps VLANs 1 through 63 to MST instance 1.</p> <p>To specify a VLAN series, use a comma; for example, <b>instance 1 vlan 10, 20, 30</b> maps VLANs 10, 20, and 30 to MST instance 1.</p> |
| Step 4 | <code>Tqwgvt*eqphki/ouv+%<b>"pcog"</b>instance_name</code>                   | Specifies the instance name. The <i>name</i> string has a maximum length of 32 characters and is case sensitive.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Step 5 | <code>Tqwgvt*eqphki/ouv+%<b>"tgxkukqp"</b>version</code>                     | Specifies the configuration revision number. The range is 0 to 65535.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Step 6 | <code>Tqwgvt*eqphki/ouv+%<b>"ujqy"rgpfkpi</b></code>                         | Verifies your configuration by displaying the pending configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Step 7 | <code>Tqwgvt*eqphki+%<b>"gzkv"</b></code>                                    | Applies all changes, and return to global configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Step 8 | <code>Tqwgvt*eqphki+%<b>"urcppkpi/vtgg"oqfg"ouv"</b></code>                  | Enables MST and RSTP. <div>  <p><b>Caution</b> Changing the spanning tree mode can disrupt traffic because all spanning tree instances are stopped for the previous mode and restarted in the new mode.</p> </div> <p>You cannot run both MST and rapid PVST+ at the same time.</p>                                                                                                                                                                                                                                                                                         |
| Step 9 | <code>Tqwgvt*eqphki+%<b>"gpf"</b></code>                                     | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |

To return to defaults, do the following:

- To return to the default MST region configuration, use the **no spanning-tree mst configuration** global configuration command.
- To return to the default VLAN-to-instance map, use the **no instance** *instance\_id* [**vlan** *vlan\_range*] MST configuration command.
- To return to the default name, use the **no name** MST configuration command.
- To return to the default revision number, use the **no revision** MST configuration command.

This example shows how to enter MST configuration mode, map VLANs 10 to 20 to MST instance 1, name the region *region1*, set the configuration revision to 1, display the pending configuration, apply the changes, and return to global configuration mode:

```
Tqvwgt*eqphki+% "urcpgkpi/vtgg"ouv"eqphkiwtcvkqp
Tqvwgt*eqphki/ouv+% "kpuvcpeg"3"xncp"32/42
Tqvwgt*eqphki/ouv+% "pcog"tgikqp3
Tqvwgt*eqphki/ouv+% "tgxkukqp"3
Tqvwgt*eqphki/ouv+% "ujgy"rgpfkpi
Rgpfkpi"OUV"eqphkiwtcvkqp
Pcog""]tgikqp3_
Tgxkukqp"3
Kpuvcpegu"eqphkiwtgf"4
Kpuvcpeg Xncpu"Ocrrgf
/////////"//////////
2"3/;.43/62;6
3"32/42
//////////

Tqvwgt*eqphki/ouv+% "gzkv
Tqvwgt*eqphki+%
```

## Configuring the Root Bridge

The switch maintains a spanning tree instance for the group of VLANs mapped to it. A switch ID, consisting of the switch priority and the switch MAC address, is associated with each instance. For a group of VLANs, the switch with the lowest switch ID becomes the root bridge.

To configure a switch to become the root bridge, use the **spanning-tree mst instance\_id root** global configuration command to modify the switch priority from the default value (32768) to a significantly lower value so that the switch becomes the root bridge for the specified spanning tree instance. When you enter this command, the switch checks the switch priorities of the root bridges. Because of extended system ID support, the switch sets its own priority for the specified instance to 24576 if this value will cause this switch to become the root bridge for the specified spanning tree instance.

If any root bridge for the specified instance has a switch priority lower than 24576, the switch sets its own priority to 4096 less than the lowest switch priority. (4096 is the value of the least-significant bit of a 4-bit switch priority value as shown in [Table 31-1 on page 31-4](#).)

If your network consists of switches that both do and do not support the extended system ID, it is unlikely that the switch with the extended system ID support will become the root bridge. The extended system ID increases the switch priority value every time the VLAN number is greater than the priority of the connected switches running older software.

The root bridge for each spanning tree instance should be a backbone or distribution switch. Do not configure an access switch as the spanning tree primary root bridge.

Use the **diameter** keyword, which is available only for MST instance 0, to specify the Layer 2 network diameter (that is, the maximum number of Layer 2 hops between any two end stations in the Layer 2 network). When you specify the network diameter, the switch automatically sets an optimal hello time,

forward-delay time, and maximum-age time for a network of that diameter, which can significantly reduce the convergence time. You can use the **hello** keyword to override the automatically calculated hello time.

**Note**

With the switch configured as the root bridge, do not manually configure the hello time, forward-delay time, and maximum-age time with the **spanning-tree mst hello-time**, **spanning-tree mst forward-time**, and **spanning-tree mst max-age** global configuration commands.

To configure a switch as the root bridge, perform this task:

|        | Command                                                                                                                                | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|--------|----------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "eqphkiwtg"vgtokpcn</code>                                                                                       | Enters global configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Step 2 | <code>Tqwgvt*eqphki/eqphki+% "urcppkpi/vtgg"ouv"<br/>instance_id tqqv"rtkoc{ "[ fkcogvgt"pgvafkcogvgt<br/>[jgnnq/vkog"ugeqpfu]]</code> | (Optional) Configures a switch as the root bridge. <ul style="list-style-type: none"> <li>For <i>instance_id</i>, you can specify a single instance, a range of instances separated by a hyphen, or a series of instances separated by a comma. The range is 0 to 4094.</li> <li>(Optional) For <b>diameter</b> <i>net_diameter</i>, specify the maximum number of Layer 2 hops between any two end stations. The range is 2 to 7. This keyword is available only for MST instance 0.</li> <li>(Optional) For <b>hello-time</b> <i>seconds</i>, specify the interval in seconds between the generation of configuration messages by the root bridge. The range is 1 to 10 seconds; the default is 2 seconds.</li> </ul> |
| Step 3 | <code>Tqwgvt*eqphki/eqphki+% "gpf</code>                                                                                               | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |

## Configuring a Secondary Root Bridge

When you configure a switch with the extended system ID support as the secondary root, the switch priority is modified from the default value (32768) to 28672. The switch is then likely to become the root bridge for the specified instance if the primary root bridge fails. This is assuming that the other network switches use the default switch priority of 32768 and therefore are unlikely to become the root bridge.

You can execute this command on more than one switch to configure multiple backup root bridges. Use the same network diameter and hello-time values that you used when you configured the primary root bridge with the **spanning-tree mst instance\_id root primary** global configuration command.

To configure a switch as the secondary root bridge, perform this task:

|        | Command                                                                                                                                                       | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt%<b>"eqphkiwtg"vgtokpcn</b></code>                                                                                                                | Enters global configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Step 2 | <code>Tqwwgt*eqphki+%"<b>urcppkpi/vtgg</b>"ouv" kpuvcpegakf"<br/>tqqv"ugeqpfct{"[<b>fkco</b>gvgt"<b>pgvafkco</b>gvgt [<b>jgnnq/vkog</b>"<br/>ugeqpfu]]</code> | <p>(Optional) Configures a switch as the secondary root bridge.</p> <ul style="list-style-type: none"> <li>For <i>instance_id</i>, you can specify a single instance, a range of instances separated by a hyphen, or a series of instances separated by a comma. The range is 0 to 4094.</li> <li>(Optional) For <b>diameter</b> <i>net_diameter</i>, specify the maximum number of switches between any two end stations. The range is 2 to 7. This keyword is available only for MST instance 0.</li> <li>(Optional) For <b>hello-time</b> <i>seconds</i>, specify the interval in seconds between the generation of configuration messages by the root bridge. The range is 1 to 10 seconds; the default is 2 seconds.</li> </ul> <p>Use the same network diameter and hello-time values that you used when configuring the primary root bridge. See the <a href="#">“Configuring the Root Bridge” section on page 31-39</a>.</p> |
| Step 3 | <code>Tqwwgt*eqphki+%"<b>gpf</b></code>                                                                                                                       | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |

## Configuring Port Priority

If a loop occurs, MST uses the port priority when selecting an interface to put into the forwarding state. You can assign higher priority values (lower numerical values) to interfaces that you want selected first and lower priority values (higher numerical values) that you want selected last. If all interfaces have the same priority value, MST puts the interface with the lowest interface number in the forwarding state and blocks the other interfaces.

To configure the MST port priority of an interface, perform this task:

|        | Command                                                                                                                                                                                    | Purpose                                                                                  |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt%<b>"eqphkiwtg"vgtokpcn</b></code>                                                                                                                                             | Enters global configuration mode.                                                        |
| Step 2 | <code>Tqwwgt*eqphki+%"<b>kpv</b>gthceg"<br/>}}<b>hcuv</b>gvjgtpgv ~ <b>ikicdk</b>vgvjgtpgv"~"<b>vgpikicdk</b>vgvjgtpgv;"<br/><b>ungv</b>lrgtv"~"}<b>rgtv</b>/ej<b>cppgn</b>"pwodgt;</code> | (Optional) Specifies an interface to configure, and enters interface configuration mode. |

|        | Command                                                                                                                              | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|--------|--------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 3 | <pre>Tqwgvt*eqphki/kh+% "urc p p k p i / v t g g " o u v " k p u v c p e g a k f " r q t v / r t k q t k v { " p r i o r i t y</pre> | Configures the port priority. <ul style="list-style-type: none"> <li>For <i>instance_id</i>, you can specify a single instance, a range of instances separated by a hyphen, or a series of instances separated by a comma. The range is 0 to 4094.</li> <li>For <i>priority</i>, the range is 0 to 240 in increments of 16. The default is 128. The lower the number, the higher the priority.</li> </ul> <p>The priority values are 0, 16, 32, 48, 64, 80, 96, 112, 128, 144, 160, 176, 192, 208, 224, and 240. All other values are rejected.</p> |
| Step 4 | <pre>Tqwgvt*eqphki/kh+% "g p f</pre>                                                                                                 | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

**Note**

The **show spanning-tree mst interface *interface\_id*** privileged EXEC command displays information only if the port is in a link-up operative state. Otherwise, you can use the **show running-config interface** privileged EXEC command to confirm the configuration.

## Configuring Path Cost

The MST path cost default value is derived from the media speed of an interface. If a loop occurs, MST uses cost when selecting an interface to put in the forwarding state. You can assign lower cost values to interfaces that you want selected first and higher cost values that you want selected last. If all interfaces have the same cost value, MST puts the interface with the lowest interface number in the forwarding state and blocks the other interfaces.

To configure the MST cost of an interface, perform this task:

|        | Command                                                                                                                                                                                                                      | Purpose                                                                                  |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|
| Step 1 | <pre>Tqwgvt% "e q p h k i w t g " v g t o k p c n</pre>                                                                                                                                                                      | Enters global configuration mode.                                                        |
| Step 2 | <pre>Tqwgvt*eqphki+% "k p v g t h c e g " }} h c u v g v j g t p g v ~ i k i c d k v g v j g t p g v " ~ " v g p i k i c d k v g v j g t p g v ; " u n q v l r q t v " ~ " } r q t v / e j c p p g n " p w o d g t ; ;</pre> | (Optional) Specifies an interface to configure, and enters interface configuration mode. |



|        | Command                                                                    | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|--------|----------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 3 | <code>Tqvwgt*eqphki/kh+% "urcppkpi/vtgg"ouv" kpuvcpegakf"equv" cost</code> | Configures the cost.<br><br>If a loop occurs, MST uses the path cost when selecting an interface to place into the forwarding state. A lower path cost represents higher-speed transmission. <ul style="list-style-type: none"> <li>For <i>instance_id</i>, you can specify a single instance, a range of instances separated by a hyphen, or a series of instances separated by a comma. The range is 0 to 4094.</li> <li>For <i>cost</i>, the range is 1 to 200000000; the default value is derived from the media speed of the interface.</li> </ul> |
| Step 4 | <code>Tqvwgt*eqphki/kh+% "gpf</code>                                       | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |

**Note**

The **show spanning-tree mst interface *interface\_id*** privileged EXEC command displays information only for ports that are in a link-up operative state. Otherwise, you can use the **show running-config** privileged EXEC command to confirm the configuration.

## Configuring the Switch Priority

You can configure the switch priority so that it is more likely that a switch is chosen as the root bridge.

**Note**

Exercise care when using this command. For most situations, we recommend that you use the **spanning-tree mst *instance\_id* root primary** and the **spanning-tree mst *instance\_id* root secondary** global configuration commands to modify the switch priority.

To configure the switch priority, perform this task:

|        | Command                                 | Purpose                           |
|--------|-----------------------------------------|-----------------------------------|
| Step 1 | <code>Tqvwgt%"eqphkiwtg"vgtokpcn</code> | Enters global configuration mode. |

|        | Command                                                                           | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|--------|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 2 | <code>Tqwvgt*eqphki+% "urcppkpi/vtgg"ouv"instance_id<br/>rtkqtkv{"priority</code> | (Optional) Configures the switch priority. <ul style="list-style-type: none"> <li>For <i>instance_id</i>, you can specify a single instance, a range of instances separated by a hyphen, or a series of instances separated by a comma. The range is 0 to 4094.</li> <li>For <i>priority</i>, the range is 0 to 61440 in increments of 4096; the default is 32768. The lower the number, the more likely the switch will be chosen as the root bridge.</li> </ul> <p>Priority values are 0, 4096, 8192, 12288, 16384, 20480, 24576, 28672, 32768, 36864, 40960, 45056, 49152, 53248, 57344, and 61440. All other values are rejected.</p> |
| Step 3 | <code>Tqwvgt*eqphki+% "gpf</code>                                                 | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

## Configuring the Hello Time

You can configure the interval between the generation of configuration messages by the root bridge by changing the hello time.



### Note

Exercise care when using this command. For most situations, we recommend that you use the **spanning-tree mst instance\_id root primary** and the **spanning-tree mst instance\_id root secondary** global configuration commands to modify the hello time.

To configure the hello time for all MST instances, perform this task:

|        | Command                                                                 | Purpose                                                                                                                                                                                                                                                                           |
|--------|-------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt%"eqphkiwtg"vgtokpcn</code>                                 | Enters global configuration mode.                                                                                                                                                                                                                                                 |
| Step 2 | <code>Tqwvgt*eqphki+% "urcppkpi/vtgg"ouv"jgnnq/vkog"<br/>seconds</code> | (Optional) Configures the hello time for all MST instances. The hello time is the interval between the generation of configuration messages by the root bridge. These messages mean that the switch is alive.<br><br>For <i>seconds</i> , the range is 1 to 10; the default is 2. |
| Step 3 | <code>Tqwvgt*eqphki+% "gpf</code>                                       | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                  |

## Configuring the Forwarding-Delay Time

To configure the forwarding-delay time for all MST instances, perform this task:

|        | Command                                                                              | Purpose                                                                                                                                                                                                                                                                                  |
|--------|--------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt%<b>"eqphkiwtg"vgtokpcn</b></code>                                       | Enters global configuration mode.                                                                                                                                                                                                                                                        |
| Step 2 | <code>Tqwvgt*eqphki+%<b>"urcppkpi/vtgg"ouv"htyctf/vkog"</b></code><br><i>seconds</i> | (Optional) Configures the forward time for all MST instances. The forward delay is the number of seconds a port waits before changing from its spanning-tree learning and listening states to the forwarding state.<br><br>For <i>seconds</i> , the range is 4 to 30; the default is 15. |
| Step 3 | <code>Tqwvgt*eqphki+%<b>"gpf"</b></code>                                             | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                         |

## Configuring the Transmit Hold Count

To configure the transmit hold count for all MST instances, perform this task:

|        | Command                                                                                             | Purpose                                                                                                                                |
|--------|-----------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt%<b>"eqphkiwtg"vgtokpcn</b></code>                                                      | Enters global configuration mode.                                                                                                      |
| Step 2 | <code>Tqwvgt*eqphki+%<b>"urcppkpi/vtgg"vtcpuokv"jqnf/eqwvpv"</b></code><br><i>jqnfaeqwpvaxcnwg"</i> | Configures the transmit hold count for all MST instances.<br><br>For <i>hold_count_value</i> , the range is 1 to 20; the default is 6. |
| Step 3 | <code>Tqwvgt*eqphki+%<b>"gpf"</b></code>                                                            | Returns to privileged EXEC mode.                                                                                                       |

## Configuring the Maximum-Aging Time

To configure the maximum-aging time for all MST instances, perform this task:

|        | Command                                                                       | Purpose                                                                                                                                                                                                                                                                                             |
|--------|-------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt%<b>"eqphkiwtg"vgtokpcn</b></code>                                | Enters global configuration mode.                                                                                                                                                                                                                                                                   |
| Step 2 | <code>Tqwvgt*eqphki+%<b>"urcppkpi/vtgg"ouv"ocz/cig"</b></code> <i>seconds</i> | (Optional) Configures the maximum-aging time for all MST instances. The maximum-aging time is the number of seconds a switch waits without receiving spanning-tree configuration messages before attempting a reconfiguration.<br><br>For <i>seconds</i> , the range is 6 to 40; the default is 20. |
| Step 3 | <code>Tqwvgt*eqphki+%<b>"gpf"</b></code>                                      | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                    |

## Configuring the Maximum-Hop Count

To configure the maximum-hop count for all MST instances, perform this task:

|        | Command                                                                            | Purpose                                                                                                                                                                                                |
|--------|------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt%<b>eqphkiwtg</b>"vgtokpcn</code>                                      | Enters global configuration mode.                                                                                                                                                                      |
| Step 2 | <code>Tqwgvt*eqphki+%<b>urcppkpi/vtgg</b>"ouv"ocz/jqru"</code><br><i>hop_count</i> | (Optional) Specifies the number of hops in a region before the BPDU is discarded, and the information held for a port is aged.<br><br>For <i>hop_count</i> , the range is 1 to 255; the default is 20. |
| Step 3 | <code>Tqwgvt*eqphki+%<b>gpf</b></code>                                             | Returns to privileged EXEC mode.                                                                                                                                                                       |

## Specifying the Link Type to Ensure Rapid Transitions

If you connect a port to another port through a point-to-point link and the local port becomes a designated port, the RSTP negotiates a rapid transition with the other port by using the proposal-agreement handshake to ensure a loop-free topology as described in the [“Rapid Convergence” section on page 31-14](#).

By default, the link type is controlled from the duplex mode of the interface: a full-duplex port is considered to have a point-to-point connection; a half-duplex port is considered to have a shared connection. If you have a half-duplex link physically connected point-to-point to a single port on a remote switch running MST, you can override the default setting of the link type and enable rapid transitions to the forwarding state.

To override the default link-type setting, perform this task:

|        | Command                                                                                                                                                                                                          | Purpose                                                                                  |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt%<b>eqphkiwtg</b>"vgtokpcn</code>                                                                                                                                                                    | Enters global configuration mode.                                                        |
| Step 2 | <code>Tqwgvt*eqphki+%<b>kpvgthceg</b>"</code><br><code>}}<b>hcuvgvjgtpgv</b> ~ <b>ikicdkvgvjgtpgv</b>"~"<b>vgpikicdkvgvjgtpgv</b>;</code><br><code><b>unqvlrqtv</b>"~"}<b>rqtv/ejcppgn</b>"<b>pwodgt</b>;</code> | (Optional) Specifies an interface to configure, and enters interface configuration mode. |
| Step 3 | <code>Tqwgvt*eqphki+%<b>urcppkpi/vtgg</b>"nkpm/v{<b>rg</b>"<b>rqkpv/vq/rqkpv</b>"</code>                                                                                                                         | Specifies that the link type of a port is point-to-point.                                |
| Step 4 | <code>Tqwgvt*eqphki+%<b>gpf</b></code>                                                                                                                                                                           | Returns to privileged EXEC mode.                                                         |

## Designating the Neighbor Type

A topology could contain both prestandard and 802.1s standard compliant devices. By default, ports can automatically detect prestandard devices, but they can still receive both standard and prestandard BPDUs. When there is a mismatch between a device and its neighbor, only the CIST runs on the interface.

You can choose to set a port to send only prestandard BPDUs. The prestandard flag appears in all the **show** commands, even if the port is in STP compatibility mode.

To override the default link-type setting, perform this task:

|        | Command                                                                                                                                                                                        | Purpose                                                                                  |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt%<b>"eqphkiwtg"vgtokpcn</b></code>                                                                                                                                                 | Enters global configuration mode.                                                        |
| Step 2 | <code>Tqwgvt*eqphki+%<b>"kpvgtthceg"</b></code><br><code>}}<b>hcuvgvjgtpgv ~ ikicdkvgvjgtpgv"~"vgpikicdkvgvjgtpgv;</b></code><br><code><b>unqv1rqtv"~"</b> }<b>rqtv/ejcppgn"pwodgt;</b></code> | (Optional) Specifies an interface to configure, and enters interface configuration mode. |
| Step 3 | <code>Tqwgvt*eqphki+%<b>"urcppkpi/vtgg"ouv"rtg/uvcpfctf</b></code>                                                                                                                             | Specifies that the port can send only prestandard BPDUs.                                 |
| Step 4 | <code>Tqwgvt*eqphki+%<b>"gpf"</b></code>                                                                                                                                                       | Returns to privileged EXEC mode.                                                         |

## Restarting the Protocol Migration Process

A switch running MST supports a built-in protocol migration feature that enables it to interoperate with 802.1D switches. If this switch receives an 802.1D configuration BPDU (a BPDU with the protocol version set to 0), it sends only 802.1D BPDUs on that port. An MST switch also can detect that a port is at the boundary of a region when it receives an 802.1D BPDU, an MST BPDU (Version 3) associated with a different region, or an RST BPDU (Version 2).

However, the switch does not automatically revert to the MST mode if it no longer receives 802.1D BPDUs because it cannot detect whether the 802.1D switch has been removed from the link unless the 802.1D switch is the designated switch. A switch also might continue to assign a boundary role to a port when the switch to which it is connected has joined the region.

To restart the protocol migration process (force the renegotiation with neighboring switches) on the switch, use the **clear spanning-tree detected-protocols** privileged EXEC command.

To restart the protocol migration process on a specific interface, use the **clear spanning-tree detected-protocols interface** *interface\_id* privileged EXEC command.

## Displaying the MST Configuration and Status

To display the spanning-tree status, use one or more of the privileged EXEC commands that are described in [Table 31-5](#).

**Table 31-5** Commands for Displaying MST Status

| Command                                                           | Purpose                                                |
|-------------------------------------------------------------------|--------------------------------------------------------|
| <code>ujqy"<b>urcppkpi/vtgg"ouv"eqphkiwtcvkqp</b></code>          | Displays the MST region configuration.                 |
| <code>ujqy"<b>urcppkpi/vtgg"ouv"eqphkiwtcvkqp"fkiguv</b></code>   | Displays the MD5 digest included in the current MSTCI. |
| <code>ujqy"<b>urcppkpi/vtgg"ouv"instance_id</b></code>            | Displays MST information for the specified instance.   |
| <code>ujqy"<b>urcppkpi/vtgg"ouv"kpvgthceg"interface_id</b></code> | Displays MST information for the specified interface.  |

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## Optional STP Features

---

- [PortFast, page 32-2](#)
- [Bridge Assurance, page 32-4](#)
- [BPDU Guard, page 32-7](#)
- [PortFast Edge BPDU Filtering, page 32-9](#)
- [UplinkFast, page 32-11](#)
- [BackboneFast, page 32-13](#)
- [EtherChannel Guard, page 32-16](#)
- [Root Guard, page 32-17](#)
- [Loop Guard, page 32-17](#)
- [PVST Simulation, page 32-20](#)
- [Verifying the Optional STP Features, page 32-21](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- For information on configuring the Spanning Tree Protocol (STP), see [Chapter 31, “Spanning Tree Protocols.”](#)



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

# PortFast

- [Information about PortFast, page 32-2](#)
- [Enabling PortFast, page 32-2](#)

## Information about PortFast

STP PortFast causes a Layer 2 LAN port configured as an access port to enter the forwarding state immediately, bypassing the listening and learning states. You can use PortFast on Layer 2 access ports connected to a single workstation or server to allow those devices to connect to the network immediately, instead of waiting for STP to converge. Interfaces connected to a single workstation or server should not receive bridge protocol data units (BPDUs). When configured for PortFast, a port is still running the spanning tree protocol. A PortFast enabled port can immediately transition to the blocking state if necessary (this could happen on receipt of a superior BPDU). PortFast can be enabled on trunk ports. PortFast can have an operational value that is different from the configured value.

You can specifically configure a port as either an edge port, a network port, or a normal port. An edge port, which is connected to a Layer 2 host, can be either an access port or a trunk port. A network port is connected only to a Layer 2 switch or bridge.

## Enabling PortFast

- [Configuring the PortFast Default State, page 32-2](#)
- [Enabling PortFast on a Layer 2 Port, page 32-3](#)

**Tip**

Configure STP BPDU Guard along with STP PortFast to shut down STP PortFast-enabled ports if they receive a BPDU.

## Configuring the PortFast Default State

To configure the default PortFast state, perform this task:

|        | Command                                                                                       | Purpose                                                                                                                                                           |
|--------|-----------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "urcppkpi/vtgg"rqtvhcuv"] gfig" ~ "pgvyqtm" ~ "pqtocn_ "fghcwnv"</code> | Configures the default state for all switch access ports to be edge, network, or normal. Bridge Assurance will be enabled on all network access ports by default. |
| Step 2 | <code>Tqwvgt*eqphki+% "gpf"</code>                                                            | Exits configuration mode.                                                                                                                                         |



**Note**

- The default spanning tree port type is normal, meaning only that its topology is not specified.
- If you configure a port connected to a Layer 2 switch or bridge as an edge port, you might create a bridging loop.
- If you mistakenly configure a port that is connected to a Layer 2 host as a spanning tree network port, the port will automatically move into the blocking state.

This example shows how to configure the default switch access port state to be edge:

```
Tqwwgt% "eqphkiwtg"vgtokpcn"
Gpvgt "eqphkiwtcvkqp"eqoocpfu. "qpg"rgt "nkp0" "Gpf"ykvj "EPVN1\0
Tqwwgt*eqphki+% "urcpgkpi/vtgg"rqtvhcuv"gfig" fghcwnv"
```

## Enabling PortFast on a Layer 2 Port

- [Enabling PortFast on a Layer 2 Access Port, page 32-3](#)
- [Enabling PortFast on a Layer 2 Network Port, page 32-4](#)

### Enabling PortFast on a Layer 2 Access Port

**Caution**

Enter the **spanning-tree portfast edge [trunk]** command only on ports that are connected to end host devices that terminate VLANs and from which the port should never receive STP BPDUs, such as:

- Workstations.
- Servers.
- Ports on routers that are not configured to support bridging.

To enable PortFast on a Layer 2 access port, perform this task:

|        | Command                                                                                  | Purpose                                                                                                                                            |
|--------|------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqwwgt*eqphki+% "kpvgthceg"} type slot/port; "~"<br>} rqtv/ejcppgn" rqtvaejcppgnapwodgt; | Selects a port to configure.                                                                                                                       |
| Step 2 | Tqwwgt*eqphki/kh+% "urcpgkpi/vtgg"rqtvhcuv"gfig"] vtwpn_                                 | Enables edge behavior on a Layer 2 access port connected to a single workstation or server. Enter the <b>trunk</b> keyword if the link is a trunk. |
| Step 3 | Tqwwgt*eqphki/kh+% "gpf"                                                                 | Exits configuration mode.                                                                                                                          |

This example shows how to enable and verify PortFast on an interface:

```
Tqwwgt% "eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv"71:"
Tqwwgt*eqphki/kh+% "urcpgkpi/vtgg"rqtvhcuv"gfig
Tqwwgt*eqphki/kh+% "gpf"
Tqwwgt%
Tqwwgt% "ujqy"twppkpi/eqphki"kpvgthceg"ikicdkvgvjgtpgv"71:"
Dwknfkpi"eqphkiwtcvkqp000

Ewtgtpv"eqphkiwtcvkqp<
#
kpvgthceg"Ikicdkvgvjgtpgv71:
"pg"kr"cfftgau
```

```

"uykvejrtv
"uykvejrtv"ceeguu"xncp"422
"uykvejrtv"oqfg"ceeguu
"urcppkpi/vtgg"rqtvhcuv"gfig
gpf
Tqwvgt%

```

## Enabling PortFast on a Layer 2 Network Port

To enable PortFast on a Layer 2 network port, perform this task:

|        | Command                                                                                                               | Purpose                                                                                                    |
|--------|-----------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"kpvgtthceg"</b>}type slot/port;"~"</code><br><code>}rqtv/ejcppgn"rqtvaejcppgnapwodgt;</code> | Selects a port to configure.                                                                               |
| Step 2 | <code>Tqwvgt*eqphki/kh+%<b>"urcppkpi/vtgg"rqtvhcuv"pgvyqtm"</b></code>                                                | Configures the port as a network port. Bridge Assurance, if enabled globally, will be enabled on the port. |
| Step 3 | <code>Tqwvgt*eqphki/kh+%<b>"gpf"</b></code>                                                                           | Exits configuration mode.                                                                                  |

This example shows how to enable and verify PortFast on an interface:

```

Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"71:"
Tqwvgt*eqphki/kh+%"urcppkpi/vtgg"rqtvhcuv"gfig"
Tqwvgt*eqphki/kh+%"gpf"
Tqwvgt%
Tqwvgt%"ujqy"twppkpi/eqphki"kpvgtthceg"ikicdkvgvjgtpgv"71:"
Dwknfkpi"eqphkiwtcvkqp000

Ewttgvp"eqphkiwtcvkqp<
#
kpvgtthceg"IkicdkvGvjgtpgv71:
"pq"kr"cfftguu
"uykvejrtv
"uykvejrtv"ceeguu"xncp"422
"uykvejrtv"oqfg"ceeguu
"urcppkpi/vtgg"rqtvhcuv"gfig
gpf
Tqwvgt%

```

# Bridge Assurance

- [Information about Bridge Assurance, page 32-4](#)
- [Enabling Bridge Assurance, page 32-7](#)

## Information about Bridge Assurance

You can use Bridge Assurance to protect against certain problems that can cause bridging loops in the network. Specifically, you use Bridge Assurance to protect against a unidirectional link failure or other software failure and a device that continues to forward data traffic when it is no longer running the spanning tree algorithm.

Bridge Assurance is enabled by default and can only be disabled globally. Also, Bridge Assurance is enabled only on spanning tree network ports that are point-to-point links. Finally, both ends of the link must have Bridge Assurance enabled. If the device on one side of the link has Bridge Assurance enabled and the device on the other side either does not support Bridge Assurance or does not have this feature enabled, the connecting port is blocked.

With Bridge Assurance enabled, BPDUs are sent out on all operational network ports, including alternate and backup ports, for each hello time period. If the port does not receive a BPDU for a specified period, the port moves into an inconsistent state (blocking), and is not used in the root port calculation. Once that port receives a BPDU, it resumes the normal spanning tree transitions.

Figure 32-1 shows a normal STP topology, and Figure 32-2 demonstrates a potential network problem when the device fails and you are not running Bridge Assurance.

**Figure 32-1** Network with Normal STP Topology




**Figure 32-2** Network Problem without Running Bridge Assurance






Figure 32-3 shows the network with Bridge Assurance enabled, and the STP topology progressing normally with bidirectional BPDUs issuing from every STP network port. Figure 32-4 shows how the potential network problem shown in Figure 32-2 does not happen when you have Bridge Assurance enabled on your network.

Figure 32-3 Network STP Topology Running Bridge Assurance



186526

Figure 32-4 Network Problem Averted with Bridge Assurance Enabled



```
%STP-2-BRIDGE_ASSURANCE_BLOCK: Bridge Assurance blocking port Ethernet2/48 VLAN0700.
switch# sh spanning vl 700 | in -i bkn
Eth2/48 Altn BKN*4 128.304 Network P2p *BA_Inc
switch#
```

186411

When using Bridge Assurance, follow these guidelines:

- Bridge Assurance runs only on point-to-point spanning tree network ports. You must configure each side of the link for this feature.
- We recommend that you enable Bridge Assurance throughout your network.

## Enabling Bridge Assurance

By default, Bridge Assurance is enabled on all network ports on the switch. Disabling Bridge Assurance causes all configured network ports to behave as normal spanning tree ports. To enable or disable Bridge Assurance globally, perform this task:

| Command                                                      | Purpose                                                      |
|--------------------------------------------------------------|--------------------------------------------------------------|
| <code>Tqwgvt*eqphki+% "urcppkpi/vtgg"dtkfig"cuuwtcpeg</code> | Enables Bridge Assurance on all network ports on the switch. |

This example shows how to enable PortFast Bridge Assurance on all network ports on the switch, and how to configure a network port:

```
Tqwgvt*eqphki+% "urcppkpi/vtgg"dtkfig"cuuwtcpeg"
Tqwgvt*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv"71: "
Tqwgvt*eqphki/kh+% "urcppkpi/vtgg"rqtvhcuv"pgvyqtm"
Tqwgvt*eqphki/kh+% "gzkv"
```

## BPDU Guard

- [Information about BPDU Guard, page 32-7](#)
- [Enabling BPDU Guard, page 32-7](#)

## Information about BPDU Guard

When enabled on a port, BPDU Guard shuts down a port that receives a BPDU. When configured globally, BPDU Guard is only effective on ports in the operational PortFast (edge) state. In a valid configuration, PortFast Layer 2 LAN interfaces (edge ports) do not receive BPDUs. Reception of a BPDU by a PortFast Layer 2 LAN interface signals an invalid configuration, such as connection of an unauthorized device. BPDU Guard provides a secure response to invalid configurations, because the administrator must manually put the Layer 2 LAN interface back in service. BPDU Guard can be configured at the interface level. When configured at the interface level, BPDU Guard shuts the port down as soon as the port receives a BPDU, regardless of the PortFast configuration.



### Note

When enabled globally, BPDU Guard applies to all interfaces that are in an operational PortFast (edge) state.

## Enabling BPDU Guard

- [Enabling BPDU Guard Globally, page 32-8](#)
- [Enabling BPDU Guard on a Port, page 32-8](#)

## Enabling BPDU Guard Globally

To enable BPDU Guard globally, perform this task:

|        | Command                                                                       | Purpose                                                                 |
|--------|-------------------------------------------------------------------------------|-------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "urcppkpi/vtgg" rqtvhcuv"gfig"drfwiwctf"fghcwnv"</code> | Enables BPDU Guard globally by default on all edge ports of the switch. |
| Step 2 | <code>Tqwgvt*eqphki+% "gpf"</code>                                            | Exits configuration mode.                                               |

This example shows how to enable BPDU Guard:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+% "urcppkpi/vtgg" rqtvhcuv"gfig"drfwiwctf"fghcwnv"
Tqwgvt*eqphki+% "gpf"
```

This example shows how to verify the configuration:

```
Tqwgvt%"ujqy"urcppkpi/vtgg"uwooct{ "vqvcnu"
Tqqv"dtkfig" hqt<"Dtkfig"XNCP2247
GvjgtEjcppgn"okueqphkiwtcvkqp"iwctf"ku"gpdcngf
Gzvpgpfgf"u{uvgo"KF"ku"gpdcngf
RqtvHcuv"Gfig"DRFW"iwctf"fgcwnv"ku"gpdcngf
Rqtvhcuv"Gfig"DRFW"Hknvgt"fgcwnv"ku"fkucdngf
Rqtvhcuv"fgcwnv"ku"gfig
Dtkfig"Cuuwtcpeg"ku"gpdcngf
Nqgriwctf"ku"fkucdngf
WrnkpmHcuv"ku"fkucdngf
DcemdpggHcuv"ku"fkucdngf
Rcvjequv"ogvjgf"wugf"ku"nqpi

Pcog"Dngemkpi"Nkuvgpki"Ngctpkpi"Hqtyctfkpi"UVR"Cevkxg
////////////////////////////////////
4"xncpu"2"2"2"5"5"
```

## Enabling BPDU Guard on a Port

To enable BPDU Guard on a port, perform this task:

|        | Command                                                                                                          | Purpose                         |
|--------|------------------------------------------------------------------------------------------------------------------|---------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "kpvgthceg"}type slot/port; "~"</code><br><code>}rqtv/ejcppgn" rqtvaejcppgnapwodgt;</code> | Selects a port to configure.    |
| Step 2 | <code>Tqwgvt*eqphki/kh+% "urcppkpi/vtgg"drfwiwctf"gpdcng"</code>                                                 | Enables BPDU Guard on the port. |
| Step 3 | <code>Tqwgvt*eqphki/kh+% "gpf"</code>                                                                            | Exits configuration mode.       |

This example shows how to enable BPDU Guard:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+% "urcppkpi/vtgg" rqtvhcuv"gfig"drfwiwctf"fghcwnv"
Tqwgvt*eqphki+% "gpf"
```

# PortFast Edge BPDU Filtering

- [Information about PortFast Edge BPDU Filtering, page 32-9](#)
- [Enabling PortFast Edge BPDU Filtering, page 32-10](#)

## Information about PortFast Edge BPDU Filtering

PortFast edge BPDU filtering allows the administrator to prevent the system from sending or even receiving BPDUs on specified ports.

When configured globally, PortFast edge BPDU filtering applies to all operational PortFast (edge) ports. Ports in an operational PortFast state are supposed to be connected to hosts, which typically drop BPDUs. If an operational PortFast port receives a BPDU, it immediately loses its operational PortFast status and becomes a normal port. In that case, PortFast edge BPDU filtering is disabled on this port and STP resumes sending BPDUs on this port.

PortFast edge BPDU filtering can also be configured on a per-port basis. When PortFast edge BPDU filtering is explicitly configured on a port, it does not send any BPDUs and drops all BPDUs it receives.



### Caution

Explicitly configuring PortFast edge BPDU filtering on a port that is not connected to a host can result in bridging loops, as the port will ignore any BPDU it receives and will go to a forwarding state.

When you enable PortFast edge BPDU filtering globally and set the port configuration as the default for PortFast edge BPDU filtering (see the [“Enabling PortFast Edge BPDU Filtering” section on page 32-10](#)), then PortFast enables or disables PortFast edge BPDU filtering.

If the port configuration is not set to default, then the PortFast configuration will not affect PortFast edge BPDU filtering. [Table 32-1](#) lists all the possible PortFast edge BPDU filtering combinations. PortFast edge BPDU filtering allows access ports to move directly to the forwarding state as soon as the end hosts are connected.

**Table 32-1** PortFast Edge BPDU Filtering Port Configurations

| Per-Port Configuration | Global Configuration | PortFast State | PortFast BPDU Filtering State                                                                                                                             |
|------------------------|----------------------|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Default                | Enable               | Enable         | Enable<br><b>Note</b> The port transmits at least 10 BPDUs. If this port receives any BPDUs, then PortFast and PortFast edge BPDU filtering are disabled. |
| Default                | Enable               | Disable        | Disable                                                                                                                                                   |
| Default                | Disable              | Not applicable | Disable                                                                                                                                                   |
| Disable                | Not applicable       | Not applicable | Disable                                                                                                                                                   |
| Enable                 | Not applicable       | Not applicable | Enable                                                                                                                                                    |

## Enabling PortFast Edge BPDU Filtering

- [Enabling PortFast Edge BPDU Filtering Globally, page 32-10](#)
- [Enabling PortFast Edge BPDU Filtering on a Nontrunking Port, page 32-11](#)

### Enabling PortFast Edge BPDU Filtering Globally

To enable PortFast edge BPDU filtering globally, perform this task:

|        | Command                                                                      | Purpose                                                                                                                                                                    |
|--------|------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "urcpgkpi/vtgg"rqtvhcuv"gfig"drfwhknvgt"fghcwnv</code> | Enables BPDU filtering globally by default on all edge ports of the switch. Use the <b>no</b> prefix to disable BPDU filtering by default on all edge ports of the switch. |
| Step 2 | <code>Tqwgvt*eqphki+% "gpf</code>                                            | Exits configuration mode.                                                                                                                                                  |

BPDU filtering is set to default on each edge port. This example shows how to enable PortFast edge BPDU filtering on the port and verify the configuration in **PVST+** mode:

```
Tqwgvt*eqphki+% "urcpgkpi/vtgg"rqtvhcuv"gfig"drfwhknvgt"fghcwnv"
Tqwgvt*eqphki+% "gzkv"
```

```
Tqwgvt% "ujqy"urcpgkpi/vtgg"uwooct { "vqvcnu"
Tqqv"dtkfig"htq<"Dtkfig"XNCP2247
GvjgtEjcppgn"okueqphkiwtcvkqp"iwctf"ku"gpdcngf
Gzvpgfgf"u{uvgo"KF"ku"gpdcngf
Rqtvhcuv"Gfig"DRFW"Iwctf"Fghcwnv""ku"fkucdngf
Rqtvhcuv"Gfig"DRFW"Hknvgt"Fghcwnv""ku"gpdcngf
Rqtvhcuv"Fghcwnv""ku"gfig
Dtkfig"Cuuwtcpeg""ku"gpdcngf
Nqqriwctf""ku"fkucdngf
WrnkpmHcuv""ku"fkucdngf
DcemdppgHcuv""ku"fkucdngf
Rcvjequv"ogvjqf"wugf"ku"nqpi
```

```
Pcog""Dnqemkpi"Nkuvgpki"Ngctpkpi"Hqtyctfkpi"UVR"Cevkxg
/////////"/////////"/////////"/////////"/////////"/////////"
4"xncpu""2""2""2""5""
Tqwgvt%
```



## Enabling PortFast Edge BPDU Filtering on a Nontrunking Port

To enable or disable PortFast edge BPDU filtering on a nontrunking port, perform this task:

|        | Command                                                                                          | Purpose                                         |
|--------|--------------------------------------------------------------------------------------------------|-------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%<b>"kpvgtthceg"</b>}type slot/port;</code>                                  | Selects the interface to configure.             |
| Step 2 | <code>Tqwgvt*eqphki/kh+%<b>"urcppkpi/vtgg"</b>drfwhknvgt"<b>]gpcdng"</b>~"<b>fkucdng</b>_</code> | Enables or disables BPDU filtering on the port. |
| Step 3 | <code>Tqwgvt*eqphki/kh+%<b>"gpf"</b></code>                                                      | Exits configuration mode.                       |

This example shows how to enable PortFast edge BPDU filtering on a nontrunking port:

```
Tqwgvt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"616
Tqwgvt*eqphki/kh+%"urcppkpi/vtgg"drfwhknvgt"]gpcdng"
Tqwgvt*eqphki/kh+%"\

Tqwgvt%"ujqy"urcppkpi/vtgg"kpvgthceg"ikicdkvgvjgtpgv"616

Xncp"#####Tqng"Uvu"Equv"#####Rtkq0Pdt"Uvcvwu
//
XNCP2232"#####Fgui"HYF"3222"#####38203;8"Gfig"R4r"

Tqwgvt%"ujqy"urcppkpi/vtgg"kpvgthceg"ikicdkvgvjgtpgv"616"fgvckn"
"Rqtv"3;8*"IkicdkvGvjgtpgv616+"qh"XNCP2232"ku"hqtyctfkpi"
""Rqtv"rcvj"equv"3222."Rqtv"rtkqtkv{"382."Rqtv"Kfgpvkhkgt"38203;80
""Fgukipcvgf"tqgv"jcu"rtkqtkv{"5498:."cfftguu"22f2022d:0362c
""Fgukipcvgf"dtkfig"jcu"rtkqtkv{"5498:."cfftguu"22f2022d:0362c
""Fgukipcvgf"rqtv"kf"ku"38203;8."fgukipcvgf"rcvj"equv"2
""Vkogtu<oguucig"dig"2."hqtyctf"fgnc{"2."jqnf"2
""Pwodgt"qh"vtcpukvkqpu"vq"hqtyctfkpi"uvcvg<3
""Vjg"rqtv"ku"kp"vjg"rqtvhcu"oqfg"d{"rqtvhcu"vtwpm"eqphkiwtcvkqp
""Nkpm"v{rg"ku"rqkpv/vq/rqkpv"d{"fghcwnv
""Drfw"hnvgt"ku"gpdcngf
""DRFW<ugpv"2."tgegkxgf"2
Tqwgvt%
```

## UplinkFast

- [Information about UplinkFast, page 32-11](#)
- [Enabling UplinkFast, page 32-12](#)

## Information about UplinkFast

UplinkFast provides fast convergence after a direct link failure and achieves load balancing between redundant Layer 2 links using uplink groups. An uplink group is a set of Layer 2 LAN interfaces (per VLAN), only one of which is forwarding at any given time. Specifically, an uplink group consists of the root port (which is forwarding) and a set of blocked ports, except for self-looping ports. The uplink group provides an alternate path in case the currently forwarding link fails.




### Note

UplinkFast is most useful in wiring-closet switches. This feature may not be useful for other types of applications.


Figure 32-5 shows an example topology with no link failures. Switch A, the root bridge, is connected directly to Switch B over link L1 and to Switch C over link L2. The Layer 2 LAN interface on Switch C that is connected directly to Switch B is in the blocking state.

Figure 32-5 UplinkFast Example Before Direct Link Failure



If Switch C detects a link failure on the currently active link L2 on the root port (a *direct* link failure), UplinkFast unblocks the blocked port on Switch C and transitions it to the forwarding state without going through the listening and learning states, as shown in Figure 32-6. This switchover takes approximately one to five seconds.

Figure 32-6 UplinkFast Example After Direct Link Failure



## Enabling UplinkFast

UplinkFast increases the bridge priority to 49152 and adds 3000 to the STP port cost of all Layer 2 LAN ports on the switch, decreasing the probability that the switch will become the root bridge. UplinkFast cannot be enabled on VLANs that have been configured for bridge priority. To enable UplinkFast on a VLAN with bridge priority configured, restore the bridge priority on the VLAN to the default value by entering a **no spanning-tree vlan *vlan\_ID* priority** command in global configuration mode.



### Note

When you enable UplinkFast, it affects all VLANs on the switch. You cannot configure UplinkFast on an individual VLAN.

To enable UplinkFast, perform this task:

|        | Command                                                                                                   | Purpose                                            |
|--------|-----------------------------------------------------------------------------------------------------------|----------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "urcppkpi/vtgg"wrnkpmhcuv</code>                                                    | Enables UplinkFast.                                |
|        | <code>Tqvwgt*eqphki+% "urcppkpi/vtgg"wrnkpmhcuv</code><br><code>]ocz/wrfcvg/tcvg"oczawrfcvgatcvg_"</code> | Enables UplinkFast with an update rate in seconds. |
| Step 2 | <code>Tqvwgt*eqphki+% "gpf"</code>                                                                        | Exits configuration mode.                          |

This example shows how to enable UplinkFast:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+% "urcppkpi/vtgg"wrnkpmhcuv
Tqvwgt*eqphki+% "gzkv"
```

This example shows how to enable UplinkFast with an update rate of 400 packets per second:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+% "urcppkpi/vtgg"wrnkpmhcuv
Tqvwgt*eqphki+% "urcppkpi/vtgg"wrnkpmhcuv"ocz/wrfcvg/tcvg"622"
Tqvwgt*eqphki+% "gzkv"
```

This example shows how to verify that UplinkFast is enabled:

```
Tqvwgt%"ujqy"urcppkpi/vtgg"wrnkpmhcuv"
WrnkpmHcuv"ku"gpcdngf
```

## BackboneFast

- [Information about BackboneFast, page 32-13](#)
- [Enabling BackboneFast, page 32-15](#)

## Information about BackboneFast

BackboneFast is initiated when a root port or blocked port on a network device receives inferior BPDUs from its designated bridge. An inferior BPDU identifies one network device as both the root bridge and the designated bridge. When a network device receives an inferior BPDU, it indicates that a link to which the network device is not directly connected (an *indirect* link) has failed (that is, the designated bridge has lost its connection to the root bridge). Under normal STP rules, the network device ignores inferior BPDUs for the configured maximum aging time, as specified by the STP **max-age** command.


The network device tries to determine if it has an alternate path to the root bridge. If the inferior BPDU arrives on a blocked port, the root port and other blocked ports on the network device become alternate paths to the root bridge. (Self-looped ports are not considered alternate paths to the root bridge.) If the inferior BPDU arrives on the root port, all blocked ports become alternate paths to the root bridge. If the inferior BPDU arrives on the root port and there are no blocked ports, the network device assumes that it has lost connectivity to the root bridge, causes the maximum aging time on the root to expire, and becomes the root bridge according to normal STP rules.

If the network device has alternate paths to the root bridge, it uses these alternate paths to transmit a new kind of Protocol Data Unit (PDU) called the Root Link Query PDU. The network device sends the Root Link Query PDU out all alternate paths to the root bridge. If the network device determines that it still has an alternate path to the root, it causes the maximum aging time to expire on the ports on which it received the inferior BPDU. If all the alternate paths to the root bridge indicate that the network device

has lost connectivity to the root bridge, the network device causes the maximum aging times on the ports on which it received an inferior BPDU to expire. If one or more alternate paths can still connect to the root bridge, the network device makes all ports on which it received an inferior BPDU its designated ports and moves them out of the blocking state (if they were in the blocking state), through the listening and learning states, and into the forwarding state.


Figure 32-7 shows an example topology with no link failures. Switch A, the root bridge, connects directly to Switch B over link L1 and to Switch C over link L2. The Layer 2 LAN interface on Switch C that connects directly to Switch B is in the blocking state.

Figure 32-7 BackboneFast Example Before Indirect Link Failure




If link L1 fails, Switch C cannot detect this failure because it is not connected directly to link L1. However, because Switch B is directly connected to the root bridge over L1, it detects the failure and elects itself the root and begins sending BPDUs to Switch C indicating itself as the root. When Switch C receives the inferior BPDUs from Switch B, Switch C infers that an indirect failure has occurred. At that point, BackboneFast allows the blocked port on Switch C to move immediately to the listening state without waiting for the maximum aging time for the port to expire. BackboneFast then transitions the Layer 2 LAN interface on Switch C to the forwarding state, providing a path from Switch B to Switch A. This switchover takes approximately 30 seconds, twice the Forward Delay time if the default Forward Delay time of 15 seconds is set. Figure 32-8 shows how BackboneFast reconfigures the topology to account for the failure of link L1.

Figure 32-8 BackboneFast Example After Indirect Link Failure



If a new network device is introduced into a shared-medium topology as shown in Figure 32-9, BackboneFast is not activated because the inferior BPDUs did not come from the recognized designated bridge (Switch B). The new network device begins sending inferior BPDUs that indicate that it is the root bridge. However, the other network devices ignore these inferior BPDUs and the new network device learns that Switch B is the designated bridge to Switch A, the root bridge.

Figure 32-9 Adding a Network Device in a Shared-Medium Topology



11245

## Enabling BackboneFast



Note

BackboneFast operates correctly only when enabled on all network devices in the network. BackboneFast is not supported on Token Ring VLANs. This feature is supported for use with third-party network devices.

To enable BackboneFast, perform this task:

|        | Command                                                   | Purpose                   |
|--------|-----------------------------------------------------------|---------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "urcppkpi/vtgg"dcemdqpghcuv"</code> | Enables BackboneFast.     |
| Step 2 | <code>Tqvwgt*eqphki+% "gpf"</code>                        | Exits configuration mode. |

This example shows how to enable BackboneFast:

```
Tqvwgt% "eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+% "urcppkpi/vtgg"dcemdqpghcuv"
Tqvwgt*eqphki+% "gpf"
```

This example shows how to verify that BackboneFast is enabled:

```
Tqvwgt% "ujqy"urcppkpi/vtgg"dcemdqpghcuv"
Dcemdqpghcuv"ku"gpdcngf

Dcemdqpghcuv"uvcvkuvkeu
```

```

//////////
Pwodgt "qh"vtcpukvkqp"xkc"dcemdpggHcuv"*cnn"XNCPu+"<"2
Pwodgt "qh"kphgtkqt"DRFWu"tgegkxgf"*cnn"XNCPu+" ""<"2
Pwodgt "qh"TNS"tgswguy"RFWu"tgegkxgf"*cnn"XNCPu+" ""<"2
Pwodgt "qh"TNS"tgurqpug"RFWu"tgegkxgf"*cnn"XNCPu+"<"2
Pwodgt "qh"TNS"tgswguy"RFWu"ugpv"*cnn"XNCPu+" ""<"2
Pwodgt "qh"TNS"tgurqpug"RFWu"ugpv"*cnn"XNCPu+" ""<"2

```

## EtherChannel Guard

- [Information about EtherChannel Guard, page 32-16](#)
- [Enabling EtherChannel Guard, page 32-16](#)

## Information about EtherChannel Guard

EtherChannel guard detects a misconfigured EtherChannel when interfaces on the switch are configured as an EtherChannel while interfaces on the other device are not or when not all the interfaces on the other device are in the same EtherChannel.

In response to misconfiguration detected on the other device, EtherChannel guard puts interfaces on the switch into the errdisabled state.

## Enabling EtherChannel Guard

To enable EtherChannel guard, perform this task:

|        | Command                                                                    | Purpose                     |
|--------|----------------------------------------------------------------------------|-----------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "urcpgkpi/vtgg"gvjgtejcppgn"iwctf" okueqphki"</code> | Enables EtherChannel guard. |
| Step 2 | <code>Tqwvgt*eqphki+% "gpf"</code>                                         | Exits configuration mode.   |

This example shows how to enable EtherChannel guard:

```

Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+% "urcpgkpi/vtgg"gvjgtejcppgn"iwctf"okueqphki"
Tqwvgt*eqphki+% "gpf"

```

This example shows how to verify the configuration:

```

Tqwvgt%"ujqy"urcpgkpi/vtgg"uwooct{"~"kpenwfg"gvjgtejcppgn
Gvjgtejcppgn"okueqphkiwtcvkqp"iwctf"ku"gpdcngf

```

To display the interfaces that are in the errdisable state, enter the **show interface status err-disable** command.

After the misconfiguration has been cleared, interfaces in the errdisable state might automatically recover. To manually return a port to service, enter a **shutdown** and then a **no shutdown** command for the interface.

# Root Guard

- [Information about Root Guard, page 32-17](#)
- [Enabling Root Guard, page 32-17](#)

## Information about Root Guard

The STP root guard feature prevents a port from becoming root port or blocked port. If a port configured for root guard receives a superior BPDU, the port immediately goes to the root-inconsistent (blocked) state.

## Enabling Root Guard

To enable root guard, perform this task:

|        | Command                                                                                                                      | Purpose                      |
|--------|------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+%<b>"kpvgthceg"</b>}type slot/port; "~"</code><br><code>}<b>rqtv/ejcppgn</b>"rqtvaejcppgnapwodgt;</code> | Selects a port to configure. |
| Step 2 | <code>Tqwwgt*eqphki/kh+%<b>"urcppkpi/vtgg"iwctf"tqqv"</b></code>                                                             | Enables root guard.          |
| Step 3 | <code>Tqwwgt*eqphki/kh+%<b>"gpf"</b></code>                                                                                  | Exits configuration mode.    |

To display ports that are in the root-inconsistent state, enter the **show spanning-tree inconsistentports** command.

# Loop Guard

- [Information about Loop Guard, page 32-17](#)
- [Enabling Loop Guard, page 32-19](#)


## Information about Loop Guard

Loop guard helps prevent bridging loops that could occur because of a unidirectional link failure on a point-to-point link. When enabled globally, the loop guard applies to all point-to-point ports on the system. Loop guard detects root ports and blocked ports and ensures that they keep receiving BPDUs from their designated port on the segment. If a loop guard enabled root or blocked port stop a receiving BPDUs from its designated port, it transitions to the loop-inconsistent blocking state, assuming there is a physical link error on this port. The port recovers from this loop-inconsistent state as soon as it receives a BPDU.

You can enable loop guard on a per-port basis. When you enable loop guard, it is automatically applied to all of the active instances or VLANs to which that port belongs. When you disable loop guard, it is disabled for the specified ports. Disabling loop guard moves all loop-inconsistent ports to the listening state.

If you enable loop guard on a channel and the first link becomes unidirectional, loop guard blocks the entire channel until the affected port is removed from the channel. [Figure 32-10](#) shows loop guard in a triangle switch configuration.

**Figure 32-10** Triangle Switch Configuration with Loop Guard



[Figure 32-10](#) illustrates the following configuration:

- Switches A and B are distribution switches.
- Switch C is an access switch.
- Loop guard is enabled on ports 3/1 and 3/2 on Switches A, B, and C.

Enabling loop guard on a root switch has no effect but provides protection when a root switch becomes a nonroot switch.

When using loop guard, follow these guidelines:

- You cannot enable loop guard on PortFast-enabled ports.
- You cannot enable loop guard if root guard is enabled.

Loop guard interacts with other features as follows:

- Loop guard does not affect the functionality of UplinkFast or BackboneFast.
- Enabling loop guard on ports that are not connected to a point-to-point link will not work.
- Root guard forces a port to be always designated as the root port. Loop guard is effective only if the port is a root port or an alternate port. You cannot enable loop guard and root guard on a port at the same time.
- Loop guard uses the ports known to spanning tree. Loop guard can take advantage of logical ports provided by the Port Aggregation Protocol (PAgP). However, to form a channel, all the physical ports grouped in the channel must have compatible configurations. PAgP enforces uniform configurations of root guard or loop guard on all the physical ports to form a channel.

These caveats apply to loop guard:

- Spanning tree always chooses the first operational port in the channel to send the BPDUs. If that link becomes unidirectional, loop guard blocks the channel, even if other links in the channel are functioning properly.



- If a set of ports that are already blocked by loop guard are grouped together to form a channel, spanning tree loses all the state information for those ports and the new channel port may obtain the forwarding state with a designated role.
- If a channel is blocked by loop guard and the channel breaks, spanning tree loses all the state information. The individual physical ports may obtain the forwarding state with the designated role, even if one or more of the links that formed the channel are unidirectional.

**Note**

You can enable UniDirectional Link Detection (UDLD) to help isolate the link failure. A loop may occur until UDLD detects the failure, but loop guard will not be able to detect it.

- Loop guard has no effect on a disabled spanning tree instance or a VLAN.

## Enabling Loop Guard

To enable loop guard globally on the switch, perform this task:

|        | Command                                                                        | Purpose                                    |
|--------|--------------------------------------------------------------------------------|--------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+%<b>urc</b>ppkpi/vtgg<b>nq</b>qriwctf<b>fgh</b>cwnv</code> | Enables loop guard globally on the switch. |
| Step 2 | <code>Tqwwgt*eqphki+%<b>gp</b>f</code>                                         | Exits configuration mode.                  |

This example shows how to enable loop guard globally:

```
Tqwwgt%eqphkiwtg"vgtokpcn
```

```
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpgo"Gpf"ykvj"EPVN1\0
Tqwwgt*eqphki+%urcppkpi/vtggnqqriwctffghcwnv"
Tqwwgt*eqphki+%gzkv"
```

```
Tqwwgt%ujqy"urc"ppkpi/vtgg"kpvgthceg"ikicdkvgvjgtpgv"616fgvcnk"
"Rgtv"3;8"*IkicdkvGvjgtpgv616+"qh"XNCP2232"ku"hqtyctfkpi"
""Rgtv"rcvj"equv"3222."Rgtv"rtkqtkv{"382."Rgtv"Kfgpvkhkgt"38203;80
""Fgukipcvgf"tqqv"jcu"rtkqtkv{"5498:."cfftguu"22f2022d:0362c
""Fgukipcvgf"dtkfig"jcu"rtkqtkv{"5498:."cfftguu"22f2022d:0362c
""Fgukipcvgf"rgtv"kf"ku"38203;8."fgukipcvgf"rcvj"equv"2
""Vkogtu<oguucig"cig"2."hqtyctf"fgnc{"2."jqnf"2
""Pwodgt"qh"vtcpukvkqpu"vq"hqtyctfkpi"uvcvg<3
""Vjg"rgtv"ku"kp"vjg"rgtvhcuv"oqfg"d{"rgtvhcuv"vtwpm"eqphkiwtcvkqp
""Nkpm"v{"rg"ku"rqkp/vq/rqkp"d{"fghcwnv
""Drfw"hknvgt"ku"gpdcngf
""Nqqr"iwctf"ku"gpdcngf"d{"fghcwnv"qp"vjg"rgtv
""DRFW<ugpv"2."tgegkxgf"2
```

To enable loop guard on a port, perform this task:

|        | Command                                                                                                                   | Purpose                      |
|--------|---------------------------------------------------------------------------------------------------------------------------|------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+%<b>kpvgthceg</b>"<i>type slot/port</i>;"~"<br/><b>rgtv</b>/<b>ejc</b>ppgn"rgtvaejcpnnapwodgt;</code> | Selects a port to configure. |
| Step 2 | <code>Tqwwgt*eqphki/kh+%<b>urc</b>ppkpi/vtgg<b>i</b>wctf<b>nq</b>qr</code>                                                | Configures loop guard.       |
| Step 3 | <code>Tqwwgt*eqphki+%<b>gp</b>f</code>                                                                                    | Exits configuration mode.    |

This example shows how to enable loop guard:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"616"
Tqwgvt*eqphki/kh+%"urcppkpi/vtgg"iwctf"nqqr"
Tqwgvt*eqphki/kh+%"gzkv"
```

This example shows how to verify the configuration:

```
Tqwgvt%"ujgy"urcppkpi/vtgg"kpvgthceg"ikicdkvgvjgtpgv"616"fgvckn"
"Rqtv"3;8"*IkicdkvGvjgtpgv616+"qh"XNCP2232"ku"hqtyctfkpi"
""Rqtv"rcvj"equiv"3222."Rqtv"rtkqtkv{"382."Rqtv"Kfgpvkhkgt"38203;80
""Fgukipcvgf"tqqv"jcu"rtkqtkv{"5498:."cfftguu"22f2022d:0362c
""Fgukipcvgf"dkfig"jcu"rtkqtkv{"5498:."cfftguu"22f2022d:0362c
""Fgukipcvgf"qtv"kf"ku"38203;8."fgukipcvgf"rcvj"equiv"2
""Vkogtu<oguucig"cig"2."hqtyctf"fgnc{"2."jqnf"2
""Pwogdt"qh"vtcpukvkqpu"vq"hqtyctfkpi"uvcvg<3
""Vjg"qtv"ku"kp"vjg"qtvhcu"oqfg"d{"qtvhcu"vtwpm"eqphkiwtcvkqp
""Nkpm"v{rg"ku"rqkp/vq/rqkp"d{"fghcwnv
""Drfw"hknvgt"ku"gpdcngf
""Nqqr"iwctf"ku"gpdcngf"qp"vjg"qtv
""DRFW<ugpv"2."tgegkxgf"2
```

## PVST Simulation

- [Information about PVST Simulation, page 32-20](#)
- [Configuring PVST Simulation, page 32-21](#)

## Information about PVST Simulation

MST interoperates with Rapid PVST+ with no need for user configuration. The PVST simulation feature enables this seamless interoperability.



### Note

PVST simulation is enabled by default when you enable MST. That is, by default, all interfaces on the device interoperate between MST and Rapid PVST+.

You may want to control the connection between MST and Rapid PVST+ to protect against accidentally connecting an MST-enabled port to a port enabled to run Rapid PVST+. Because Rapid PVST+ is the default STP mode, you may encounter many Rapid PVST+ connections.

Disabling Rapid PVST+ simulation, which can be done per port or globally for the entire device, moves the MST-enabled port to the PVST peer inconsistent (blocking) state once it detects it is connected to a Rapid PVST+-enabled port. This port remains in the inconsistent state until the port stops receiving Shared Spanning Tree Protocol (SSTP) BPDUs, and then the port resumes the normal STP transition process.

The root bridge for all STP instances must all be in either the MST region or the Rapid PVST+ side. If the root bridge for all STP instances are not on one side or the other, the software moves the port into a PVST simulation-inconsistent state.



### Note

We recommend that you put the root bridge for all STP instances in the MST region.

## Configuring PVST Simulation



### Note

PVST simulation is enabled by default so that all interfaces on the device interoperate between MST and Rapid PVST+.

To prevent an accidental connection to a device that does not run MST as the default STP mode, you can disable PVST simulation. If you disable PVST simulation, the MST-enabled port moves to the blocking state once it detects it is connected to a Rapid PVST+-enabled port. This port remains in the inconsistent state until the port stops receiving BPDUs, and then the port resumes the normal STP transition process.

To enable or disable PVST simulation globally, enter the command using the **global** keyword, as shown in the following task:

| Command                                                              | Purpose                                                                                                                                                                                                  |
|----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqvwgt*eqphki+% "urcpgkpi/vtgg"ouv"ukowncvg"rxuv"inqdcn</code> | Enables all ports to automatically interoperate with a connected device that is running in Rapid PVST+ mode. The default is enabled; all interfaces will operate seamlessly between Rapid PVST+ and MST. |

To override the global PVST simulation setting for a port, enter the command in the interface command mode, as shown in the following task:

|        | Command                                                          | Purpose                                                                                                           |
|--------|------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "kpvgtthceg"}type slot/port;</code>        | Selects a port to configure.                                                                                      |
| Step 2 | <code>Tqvwgt*eqphki/kh+% "urcpgkpi/vtgg"ouv"ukowncvg"rxuv</code> | Enables this interface to automatically interoperate with a connected device that is running in Rapid PVST+ mode. |

This example shows how to prevent the switch from automatically interoperating with a connecting device that is running Rapid PVST+:

```
Tqvwgt*eqphki+% "pq"urcpgkpi/vtgg"ouv"ukowncvg"rxuv"inqdcn"
```

This example shows how to prevent a port from automatically interoperating with a connecting device that is running Rapid PVST+:

```
Tqvwgt*eqphki+% "kpvgtthceg"ik5135 "
Tqvwgt*eqphki/kh+% "urcpgkpi/vtgg"ouv"ukowncvg"rxuv"fkucdng"
```

## Verifying the Optional STP Features

- [Using the show spanning-tree Commands, page 32-22](#)
- [Examples of the show spanning-tree Commands, page 32-22](#)

## Using the show spanning-tree Commands

You can view spanning tree status and configuration information, both global and port-level, using the **show spanning-tree** commands described in this section. To view spanning tree status and configuration information, enter one of the following commands:

| Command                                                              | Purpose                                                                                             |
|----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| Tqwwgt% "ujqy"urcppedi/vtgg"                                         | Displays information about the spanning tree, including protocol type and port types.               |
| Tqwwgt% "ujqy"urcppedi/vtgg"uwoot{ "                                 | Displays a summary of the spanning tree feature settings and the spanning tree states of the VLANs. |
| Tqwwgt% "ujqy"urcppedi/vtgg"uwoot{ "vqvnu"                           | Displays a summary of the spanning tree feature settings and totals of the VLAN states.             |
| Tqwwgt% "ujqy"urcppedi/vtgg"kpvgthceg"}type slot/port;"fgvkn"        | Displays the spanning tree status details of an interface.                                          |
| Tqwwgt% "ujqy"urcppedi/vtgg"kpvgthceg"}type slot/port;"rqtvhcu"gfif" | Displays the spanning tree portfast edge interface operational state for all the instances.         |

## Examples of the show spanning-tree Commands

This example displays the spanning-tree status with Bridge Assurance enabled but in the inconsistent state:

```
Tqwgvt%"ujgy"urcpgkpi/vtgg
XNCP2232
"Urcpgkpi"vtgg"gpdcngf"rtqvqeqn"tuvr
"Tqqv"KF""Rtkqtkv{"5499:
"Cfftguu""22240394e0h622
"Vjku"dtkfig"ku"vjg"tqqv
"Jgnnq"Vkog""4"uge"Ocz"Cig"42"uge"
Hqtyctf"Fgnc{"37"uge
"Dtkfig"KF"Rtkqtkv{"5499:"*rtkqtkv{"5498:"u{u/kf/gzv"32+
"Cfftguu""22240394e0h622
"Jgnnq"Vkog""4"uge"Ocz"Cig"42"uge"
Hqtyctf"Fgnc{"37"uge
"Cikpi"Vkog"522
Kpvgthceg""Tqng"Uvu"Equv""Rtkq0Pdt"V{rg
/////////////////////////
Ik5136""Fgui"DMP,6""34:0492""Pgvyqtm."R4r",DCaKpe
Tqwgvt%
```

The following inconsistency messages can be appended to the Type field:

- **\*BA\_Inc**—Indicates that Bridge Assurance is in the inconsistent state.
- **\*PVST\_Peer\_Inc**—Indicates that the port is in a peer type Inconsistent state.
- **Dispute**—Indicates that a dispute condition is detected.

This example shows the spanning-tree configuration summary:

```
Tqvwgt%"ujqy"urcppkpi/vtgg"uwooct{"
Uykvej "ku"kp"tcrkf/rxuv"oqfg
Tqqv"dtkfig"hqt<"Dtkfig"XNCP2247
GvjgtEjcppgn"okueqphkiwtcvkqp"iwctf"ku"gpdcngf
Gzvpgfgf"u{uvgo"KF"ku"gpdcngf
Rqtvhcuv"Gfig"DRFW"Iwctf"Fghcwnv"ku"fkucdngf
Rqtvhcuv"Gfig"DRFW"Hknvgt"Fghcwnv"ku"fkucdngf
Rqtvhcuv"Fghcwnv"ku"gfig"
Dtkfig"Cuuwtcpeg"ku"gpdcngf"
Nqgriwctf"ku"fkucdngf
WrnkpmHcuv"ku"fkucdngf
DcemdpgHcuv"ku"fkucdngf
Rcvjequv"ogvjgf"wugf"ku"ujgtv
RXUV"Ukowncvkqp"Fghcwnv"ku"gpdcngf"

Pcog" "Dngemkpi"Nkuvgpkpi"Ngctpkpi"Hqtyctfkpi"UVR"Cevkxg
/////////"/////////"/////////"/////////"/////////"/////////
XNCP2247"2"2"2"3"
XNCP2252"2"2"2"4"4"
/////////"/////////"/////////"/////////"/////////"/////////
4"xncpu"2"2"2"5"5"
```

Possible states for the Bridge Assurance field are as follows:

- is enabled
- is disabled
- is enabled but not active in the PVST mode

This example shows the spanning tree summary when PVST simulation is disabled in any STP mode:

```
Tqvwgt%"ujqy"urcppkpi/vtgg"uwooct{"
Uykvej "ku"kp"ouv"oqfg"*KGGG"Uvcpfctf+
Tqqv"dtkfig"hqt<"OUV2
GvjgtEjcppgn"okueqphki"iwctf"ku"gpdcngf
Gzvpgfgf"u{uvgo"KF"ku"gpdcngf
Rqtvhcuv"Fghcwnv"ku"fkucdngf
Rqtvhcuv"DRFW"Iwctf"Fghcwnv"ku"fkucdngf
Rqtvhcuv"DRFW"Hknvgt"Fghcwnv"ku"fkucdngf
Nqgriwctf"Fghcwnv"ku"fkucdngf
WrnkpmHcuv"ku"fkucdngf
DcemdpgHcuv"ku"fkucdngf
Rcvjequv"ogvjgf"wugf"ku"nqpi
RXUV"Ukowncvkqp"Fghcwnv"ku"fkucdngf"

Pcog" "Dngemkpi"Nkuvgpkpi"Ngctpkpi"Hqtyctfkpi"UVR"Cevkxg
/////////"/////////"/////////"/////////"/////////"/////////
OUV2"4"2"2"2"4"
/////////"/////////"/////////"/////////"/////////"/////////
3"ouv"4"2"2"2"4"
```

Possible states for the PVST Simulation Default field are as follows:

- is enabled
- is disabled
- is enabled but not active in rapid-PVST mode

This example shows the spanning tree summary totals:

```
Tqwgvt% "ujgy"urcppkpi/vtgg"uwooct{"vqvcnu"
Tqqv"dtkfig" hqt<"Dtkfig"XNCP2247
GvjgtEjcppgn"okueqphkiwtcvkqp"iwctf"ku"gpdcngf
Gzvpgfgf"u{uvgo"KF"ku"gpdcngf
RqtvHcuv"Gfig"DRFW"iwctf"Fghcwnv"ku"gpdcngf
RqtvHcuv"Gfig"DRFW"Hknvgt"Fghcwnv"ku"fkucdngf
RqtvHcuv"Fghcwnv"ku"gfig"
Dtkfig"Cuuwtcpeg"ku"gpdcngf"
Nqqrriwctf"ku"fkucdngf
WrnkpmHcuv"ku"fkucdngf
DcemdpggHcuv"ku"fkucdngf
Rcvjequv"ogvjgf" wugf"ku"nqpi

Pcog" "Dngemkpi"Nkuvgpkipi"Ngctpkpi"Hqtyctfkpi"UVR"Cevkxg
/////////"/////////"/////////"/////////"/////////"/////////"
4"xncpu"2"2"2"5"5"
Tqwgvt%
```

This example shows the spanning-tree configuration details of an edge port:

```
Tqwgvt% "ujgy"urcppkpi/vtgg"kpvgthceg"ik5135"fgvckn"
Rqtv"48;"*IkicdkvGvjgtpgv5135+"qh"XNCP2224"ku"hqtyctfkpi"
"Rqtv"rcvj"equiv"6."Rqtv"rtkqtkv{"34:."Rqtv"Kfgpvkhkgt"34:048;0
"Fgukipcvvgf"tqqv"jcu"rtkqtkv{"54992."cfftguu"22240394e0h622
"Fgukipcvvgf"dtkfig"jcu"rtkqtkv{"54992."cfftguu"22240394e0h622
"Fgukipcvvgf"rqtv"kf"ku"34:048;. "fgukipcvvgf"rcvj"equiv"2
"Vkogtu<"oguucig"cig"2."hqtyctf"fgnc{"2."jqnf"2
"Pwodgt"qh"vtcpukvkqpu"vq"hqtyctfkpi"uvcvg<"3
"Nkpm"v{rg"ku"rqkp/vq/rqkp"d{"fghcwnv
"Nqqr"iwctf"ku"gpdcngf"d{"fghcwnv"qp"vjg"rqtv
"Vjg"rqtv"ku"kp"vjg"rqtvhcuv"gfig"oqfg"d{"fghcwnv
"DRFW<"ugpv"43:5."tgegkxgf"2
```

This example shows the spanning-tree configuration details of a trunk port:

```
Tqwgvt*eqphki/kh+% "urcppkpi/vtgg"rqtvhcuv"gfig"vtwpm"
'Yctpkpi<rqtvhcuv"ujqwnf"qpn{"dg"gpdcngf"qp"rqtvu"eqppgevgf"vq"c"ukping
"jqvu"Eqppgevkpi"jwdu."eqpegpvtcvgtu."uykvejgu."dtkfigu."gve000"vq"vjku
"kpvgthceg"yjgp"rqtvhcuv"ku"gpdcngf."ecp"ecwug"vgorqtct{"dtkfikpi"nqgru0
"Wug"ykvj"ECWVKQP
```

```
Tqwgvt*eqphki/kh+% "gzkv"
```

```
Tqwgvt% "ujgy"urcppkpi/vtgg"kpvgthceg"ik5135"fgvckn"
Rqtv"48;"*IkicdkvGvjgtpgv5135+"qh"XNCP2224"ku"hqtyctfkpi"
"Rqtv"rcvj"equiv"6."Rqtv"rtkqtkv{"34:."Rqtv"Kfgpvkhkgt"34:048;0
"Fgukipcvvgf"tqqv"jcu"rtkqtkv{"54992."cfftguu"22240394e0h622
"Fgukipcvvgf"dtkfig"jcu"rtkqtkv{"54992."cfftguu"22240394e0h622
"Fgukipcvvgf"rqtv"kf"ku"34:048;. "fgukipcvvgf"rcvj"equiv"2
"Vkogtu<"oguucig"cig"2."hqtyctf"fgnc{"2."jqnf"2
"Pwodgt"qh"vtcpukvkqpu"vq"hqtyctfkpi"uvcvg<"3
"Nkpm"v{rg"ku"rqkp/vq/rqkp"d{"fghcwnv
"Nqqr"iwctf"ku"gpdcngf"d{"fghcwnv"qp"vjg"rqtv
"Vjg"rqtv"ku"kp"vjg"rqtvhcuv"gfig"vtwpm"oqfg
"DRFW<"ugpv"43:5."tgegkxgf"2
```

This example shows the spanning-tree configuration details of an edge port when a dispute condition has been detected:

```
Tqwgvt% "ujgy"urcppkpi/vtgg"kpvgthceg"ik5135"fgvckn"
Rqtv"48;"*IkicdkvGvjgtpgv5135+"qh"XNCP2224"ku"fgukipcvvgf"dnqemkpi"*fkurwvg+
"Rqtv"rcvj"equiv"6."Rqtv"rtkqtkv{"34:."Rqtv"Kfgpvkhkgt"34:04;90
"Fgukipcvvgf"tqqv"jcu"rtkqtkv{"5498;. "cfftguu"223507h42023e2
```

```

" " "Fgukipcvgf"dtkfig"jcu"rtkqtkv{"5498;. "cfftguu"223507h42023e2
" " "Fgukipcvgf"rqtv"kf"ku"34:04;9. "fgukipcvgf"rcvj"equiv"2
" " "Vkogtu<"oguucig"dig"2. "hqtyctf"fgnc{"2. "jqnf"2
" " "Pwodgt"qh"vtcpukvkqpu"vq"hqtyctfkpi"uvcvg<"3
" " "Nkpm"v{rg"ku"rqkpv/vq/rqkpv"d{ "fghcwnv
" " "DRFW<"ugpv"354. "tgegkxgf"3

```

This example shows the spanning tree portfast edge interface operational state for all the instances:

```

Tqwvgt% "ujqy"urcpgkpi/vtgg"kpvgthceg"ik513"rqtvhcuv"gfig"
OUV2 " " "fkucdnf
OUV3 " " "fkucdnf

```



#### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)







## IP Unicast Layer 3 Switching

---

- [Prerequisites for Hardware Layer 3 Switching, page 33-1](#)
- [Restrictions for Hardware Layer 3 Switching, page 33-2](#)
- [Information About Layer 3 Switching, page 33-2](#)
- [Default Settings for Hardware Layer 3 Switching, page 33-4](#)
- [How to Configure Hardware Layer 3 Switching, page 33-4](#)
- [Displaying Hardware Layer 3 Switching Statistics, page 33-5](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
  - Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
  - For information about IP multicast Layer 3 switching, see [Chapter 44, “IPv4 Multicast Layer 3 Features.”](#)
- 



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

---

## Prerequisites for Hardware Layer 3 Switching

None.

# Restrictions for Hardware Layer 3 Switching

- Hardware Layer 3 switching supports the following ingress and egress encapsulations:
  - Ethernet V2.0 (ARPA)
  - 802.3 with 802.2 with 1 byte control (SAP1)

## Information About Layer 3 Switching

- [Hardware Layer 3 Switching, page 33-2](#)
- [Layer 3-Switched Packet Rewrite, page 33-2](#)

## Hardware Layer 3 Switching

Hardware Layer 3 switching allows the PFC and DFCs, instead of the RP, to forward IP unicast traffic between subnets. Hardware Layer 3 switching provides wire-speed forwarding on the PFC and DFCs, instead of in software on the RP. Hardware Layer 3 switching requires minimal support from the RP. The RP routes any traffic that cannot be hardware Layer 3 switched.

Hardware Layer 3 switching supports the routing protocols configured on the RP. Hardware Layer 3 switching does not replace the routing protocols configured on the RP.

Hardware Layer 3 switching runs equally on the PFC and DFCs to provide IP unicast Layer 3 switching locally on each module. Hardware Layer 3 switching provides the following functions:

- Hardware access control list (ACL) switching for policy-based routing (PBR)
- Hardware flow-based switching for TCP intercept and reflexive ACL forwarding decisions
- Hardware Cisco Express Forwarding (CEF) switching for all other IP unicast traffic

Hardware Layer 3 switching on the PFC supports modules that do not have a DFC. The RP forwards traffic that cannot be Layer 3 switched.

Traffic is hardware Layer 3 switched after being processed by access lists and quality of service (QoS).

Hardware Layer 3 switching makes a forwarding decision locally on the ingress-port module for each packet and sends the rewrite information for each packet to the egress port, where the rewrite occurs when the packet is transmitted from the switch.

Hardware Layer 3 switching generates flow statistics for Layer 3-switched traffic. Hardware Layer 3 flow statistics can be used for NetFlow. (See [Chapter 53, “NetFlow Hardware Support”](#).)

## Layer 3-Switched Packet Rewrite

When a packet is Layer 3 switched from a source in one subnet to a destination in another subnet, the switch performs a packet rewrite at the egress port based on information learned from the RP so that the packets appear to have been routed by the RP.

Packet rewrite alters five fields:

- Layer 2 (MAC) destination address
- Layer 2 (MAC) source address
- Layer 3 IP Time to Live (TTL)

- Layer 3 checksum
- Layer 2 (MAC) checksum (also called the frame checksum or FCS)

**Note**

Packets are rewritten with the encapsulation appropriate for the next-hop subnet.

If Source A and Destination B are in different subnets and Source A sends a packet to the RP to be routed to Destination B, the switch recognizes that the packet was sent to the Layer 2 (MAC) address of the RP.

To perform Layer 3 switching, the switch rewrites the Layer 2 frame header, changing the Layer 2 destination address to the Layer 2 address of Destination B and the Layer 2 source address to the Layer 2 address of the RP. The Layer 3 addresses remain the same.

In IP unicast and IP multicast traffic, the switch decrements the Layer 3 TTL value by 1 and recomputes the Layer 3 packet checksum. The switch recomputes the Layer 2 frame checksum and forwards (or, for multicast packets, replicates as necessary) the rewritten packet to Destination B's subnet.

A received IP unicast packet is formatted (conceptually) as follows:

| Layer 2 Frame Header |                     | Layer 3 IP Header       |                    |          |                     | Data | FC S |
|----------------------|---------------------|-------------------------|--------------------|----------|---------------------|------|------|
| Destination          | Source              | Destination             | Source             | TTL      | Checksum            |      |      |
| <i>RP MAC</i>        | <i>Source A MAC</i> | <i>Destination B IP</i> | <i>Source A IP</i> | <i>n</i> | <i>calculation1</i> |      |      |

After the switch rewrites an IP unicast packet, it is formatted (conceptually) as follows:


| Layer 2 Frame Header     |               | Layer 3 IP Header       |                    |            |                     | Data | FC S |
|--------------------------|---------------|-------------------------|--------------------|------------|---------------------|------|------|
| Destination              | Source        | Destination             | Source             | TTL        | Checksum            |      |      |
| <i>Destination B MAC</i> | <i>RP MAC</i> | <i>Destination B IP</i> | <i>Source A IP</i> | <i>n-1</i> | <i>calculation2</i> |      |      |

### Hardware Layer 3 Switching Examples

[Figure 33-1 on page 33-4](#) shows a simple network topology. In this example, Host A is on the Sales VLAN (IP subnet 171.59.1.0), Host B is on the Marketing VLAN (IP subnet 171.59.3.0), and Host C is on the Engineering VLAN (IP subnet 171.59.2.0).

When Host A initiates an HTTP file transfer to Host C, Hardware Layer 3 switching uses the information in the local forwarding information base (FIB) and adjacency table to forward packets from Host A to Host C.

Figure 33-1 Hardware Layer 3 Switching Example Topology



# Default Settings for Hardware Layer 3 Switching

| Feature                                 | Default Value                |
|-----------------------------------------|------------------------------|
| Hardware Layer 3 switching enable state | Enabled (cannot be disabled) |
| Cisco IOS CEF enable state on RP        | Enabled (cannot be disabled) |
| Cisco IOS dCEF enable state on RP       | Enabled (cannot be disabled) |

# How to Configure Hardware Layer 3 Switching

Note

For information on configuring unicast routing on the RP, see [Chapter 35, “Layer 3 Interfaces.”](#)

Hardware Layer 3 switching is permanently enabled. No configuration is required.  
To display information about Layer 3-switched traffic, perform this task:

| Command                                                                                       | Purpose                                         |
|-----------------------------------------------------------------------------------------------|-------------------------------------------------|
| <code>Tqvwgt%"ujqy"kpvgthceg"}type slot/port;"~"<br/>}rqtv/ejcpngn"pwodgt;"~"dgikp"N5"</code> | Displays a summary of Layer 3-switched traffic. |

This example shows how to display information about hardware Layer 3-switched traffic on Gigabit Ethernet port 3/3:

```
Tqvwgt%ujqy"kpvgtthceg"ikicdkvgvjgtpgv"515"~"dgikp"N5"
"N5"kp"Uykvejgf<"wecuv<"2"rmv."2"d{vgu"/"oecuv<"34"rmv."99:"d{vgu"oecuv
"N5"qvw"Uykvejgf<"wecuv<"2"rmv."2"d{vgu"/"oecuv<"2"rmv."2"d{vgu"
""""62685;;"rcemgvu"kprwv."56;59225;"d{vgu."2"pq"dwhhgt
""""Tgegkxgf"59;7477"dtqcfecuvu."4"twpvu."2"ikcpvu."2"vj tqvvnqu
>000qvwrvw"vtwpecvgf000@
Tqvwgt%
```



Note

The Layer 3 switching packet count is updated approximately every five seconds.

Cisco IOS CEF and dCEF are permanently enabled. No configuration is required to support hardware Layer 3 switching.

With a PFC (and DFCs, if present), hardware Layer 3 switching uses per-flow load balancing based on IP source and destination addresses. Per-flow load balancing avoids the packet reordering that can be necessary with per-packet load balancing. For any given flow, all PFC- and DFC-equipped switches make exactly the same load-balancing decision, which can result in nonrandom load balancing.

The Cisco IOS CEF **ip load-sharing per-packet**, **ip cef accounting per-prefix**, and **ip cef accounting non-recursive** commands on the RP apply only to traffic that is CEF-switched in software on the RP. The commands do not affect traffic that is hardware Layer 3 switched on the PFC or on DFC-equipped switching modules.

## Displaying Hardware Layer 3 Switching Statistics

Hardware Layer 3 switching statistics are obtained on a per-VLAN basis.

To display hardware Layer 3 switching statistics, perform this task:

| Command                                                                                          | Purpose                                         |
|--------------------------------------------------------------------------------------------------|-------------------------------------------------|
| Tqvwgt% <b>ujqy</b> "kpvgtthcegu" type slot/port; ~" } <b>rqtv</b> /e <b>jcppgn</b> "pwodgt; i " | Displays hardware Layer 3 switching statistics. |

This example shows how to display hardware Layer 3 switching statistics:

```
Tqvwgt%ujqy"kpvgtthcegu"ikicdkvgvjgtpgv";17"~"kpenwfg"Uykvejgf"
N4"Uykvejgf<"wecuv<":3;;"rmv."3584282"d{vgu"/"oecuv<"8;:2"rmv."593;74"d{vgu
N5"kp"Uykvejgf<"wecuv<"2"rmv."2"d{vgu"/"oecuv<"2"rmv."2"d{vgu"oecuv
N5"qvw"Uykvejgf<"wecuv<"2"rmv."2"d{vgu"/"oecuv<"2"rmv."2"d{vgu"
```

To display adjacency table information, perform this task:

| Command                                                                                                                                                  | Purpose                                                                                                                                          |
|----------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| Tqvwgt% <b>ujqy</b> "cflcegepe{" } type slot/port; ~" } <b>rqtv</b> /e <b>jcppgn</b> "pwodgt; i ~" <b>fgvckn</b> ~" <b>kpvgtpcn</b> ~" <b>uwooct</b> { _ | Displays adjacency table information. The optional <b>detail</b> keyword displays detailed adjacency information, including Layer 2 information. |

This example shows how to display adjacency statistics, which are updated approximately every 60 seconds:

```
Tqvwgt%"ujqy"cflecege{"ikicdkvgvjgtpgv";17"fgvckn"
Rtqvgeqn"Kpvgthceg"*****"Cfftguu
KR*****"IkicdkvGvjgtpgv;17*****"3940420750428*33+
*****"726"rcemgvu."8332"d{vgu
*****"22827E:87D:4
*****"222386H:5HC72:22
*****"CTR*****"25<6;<53"
```


**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## Policy-Based Routing (PBR)

---

- [Prerequisites for PBR, page 34-1](#)
- [Restrictions for PBR, page 34-2](#)
- [Information About PBR, page 34-2](#)
- [Default Settings for PBR, page 34-3](#)
- [How to Configure PBR, page 34-3](#)
- [Configuration Examples for PBR, page 34-7](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for PBR

None.

## Restrictions for PBR

The PFC and any DFCs provide the hardware support for the following:

- These IPv4 PBR commands:
  - **match ip address**
  - **match length**
  - **set ip next-hop** (2,000 instances)
  - **set ip default next-hop**
  - **set interface null0**
  - **set default interface null0**
  - **set ip vrf**
  - **set ip default vrf**
- If the RP address falls within the range of a PBR ACL, traffic addressed to the RP is policy routed in hardware instead of being forwarded to the RP. To prevent policy routing of traffic addressed to the RP, configure PBR ACLs to deny traffic addressed to the RP.
- Local PBR.
- IPv4 PBR recursive next-hop with load balancing.
- IPv6 PBR is supported in software.
- IPv6 PBR recursive next-hop is not supported.
- If a PBR route map sequence does not have any set clauses configured, then all the packets matching the entry are punted to the CPU and processed in software.

## Information About PBR

- [PBR Overview, page 34-2](#)
- [PBR Recursive Next Hop for IPv4 Traffic, page 34-3](#)

## PBR Overview

PBR is an alternative to routing protocols and allows you to configure a policy for unicast traffic flows, which provides more control over routing than a routing protocol does and avoids the need to configure interface-level traffic classification. PBR can route unicast traffic along a different path than a routing protocol would use. PBR can provide:

- Equal access
- Protocol-sensitive routing
- Source-sensitive routing
- Routing based on interactive rather than batch traffic
- Routing based on dedicated links



PBR route maps can be configured to do the following:

- Allow or deny paths based on the identity of a particular end system, an application protocol, or the size of packets or a combination of these values.
- Classify traffic based on extended access list criteria.
- Set IP precedence bits.
- Route packets to specific paths.

PBR applies a route map to all ingress unicast traffic received on a PBR-enabled interface. PBR cannot be applied to egress traffic or to multicast traffic.

If the ingress unicast traffic does not match any route map statements, the route map applies all the configured set clauses. Routing protocols forward traffic that matches a route-map deny statement and traffic that does not match any route-map permit statements.

## PBR Recursive Next Hop for IPv4 Traffic

The PBR Recursive Next Hop feature enables configuration of a recursive next-hop address in a PBR route map. The recursive next-hop address is installed in the routing table and can be a subnet that is not directly connected. If the recursive next-hop address is not available, traffic is routed using a default route.

## Default Settings for PBR

None.

## How to Configure PBR

- [Configuring PBR](#)
- [Configuring Local PBR](#)
- [Configuring PBR Recursive Next Hop](#)



### Note

For information about Multi-VRF Selection Using Policy Based Routing (PBR VRF), see this document: [http://www.cisco.com/en/US/docs/ios/mps/configuration/guide/mp\\_mltvrf\\_slct\\_pbr.html](http://www.cisco.com/en/US/docs/ios/mps/configuration/guide/mp_mltvrf_slct_pbr.html)

## Configuring PBR

To configure PBR on an interface, use the following commands beginning in global configuration mode:

|        | Command                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% <b>tqwvg/ocr</b>"map-tag"]<b>rgtokv</b>"~"<b>fgp</b>{_<br/>]sequence-number_</code>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Defines a route map to control where packets are output. This command puts the router into route-map configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Step 2 | <code>Tqwvgt*eqphki/tqwvg/ocr+% <b>ocvej</b>"ngpivj"<i>min max</i><br/><br/>Tqwvgt*eqphki/tqwvg/ocr+% <b>ocvej</b>"kr"<b>cfftguu</b>"<br/>}access-list-number"~"<i>pcog</i>;"]. . .access-list-number"~"<i>pcog</i>_</code>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Specifies the match criteria.<br><br>Although there are many route-map matching options, here you can specify only length and/or ip address. <ul style="list-style-type: none"> <li><b>length</b> matches the Level 3 length of the packet.</li> <li><b>ip address</b> matches the source or destination IP address that is permitted by one or more standard or extended access lists.</li> </ul> <p>If you do not specify a <b>match</b> command, the route map applies to <i>all</i> packets.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Step 3 | <code>Tqwvgt*eqphki/tqwvg/ocr+% <b>ugv</b>"kr"<b>rtgegfgpeg</b>]"<i>pwdgt</i>"<br/>~"<i>pcog</i>_</code><br><br><code>Tqwvgt*eqphki/tqwvg/ocr+% <b>ugv</b>"kr"<b>fh</b></code><br><br><code>Tqwvgt*eqphki/tqwvg/ocr+% <b>ugv</b>"kr"<b>xth</b>"<i>xthaname</i></code><br><br><code>Tqwvgt*eqphki/tqwvg/ocr+% <b>ugv</b>"kr"<b>pgzv/jqr</b>"<i>ip-address</i>"<br/>]000"<i>ip-address</i>_</code><br><br><code>Tqwvgt*eqphki/tqwvg/ocr+% <b>ugv</b>"kr"<b>pgzv/jqr</b>"<b>tgewtukxg</b>"<br/><i>ip-address</i>"]000"<i>ip-address</i>_</code><br><br><code>Tqwvgt*eqphki/tqwvg/ocr+% <b>ugv</b>"<b>kpvgtthceg</b><br/><i>interface-type interface-number</i>"]000 <i>type number</i>_</code><br><br><code>Tqwvgt*eqphki/tqwvg/ocr+% <b>ugv</b>"kr"<b>fghcwnv</b>"<b>pgzv/jqr</b>"<br/><i>ip-address</i>"]000"<i>ip-address</i>_</code><br><br><code>Tqwvgt*eqphki/tqwvg/ocr+% <b>ugv</b>"<b>fghcwnv</b>"<b>kpvgtthceg</b><br/><i>interface-type interface-number</i>"]000 <i>type</i> . . .<i>number</i>_</code> | Specifies the action(s) to take on the packets that match the criteria. You can specify any or all of the following: <ul style="list-style-type: none"> <li><b>precedence</b>: Sets precedence value in the IP header. You can specify either the precedence number or name.</li> <li><b>df</b>: Sets the ‘Don’t Fragment’ (DF) bit in the ip header.</li> <li><b>vrf</b>: Sets the VPN Routing and Forwarding (VRF) instance.</li> <li><b>next-hop</b>: Sets next hop to which to route the packet.</li> <li><b>next-hop recursive</b>: Sets next hop to which to route the packet if the hop is to a router which is not adjacent.</li> <li><b>interface</b>: Sets output interface for the packet.</li> <li><b>default next-hop</b>: Sets next hop to which to route the packet if there is no explicit route for this destination.</li> <li><b>default interface</b>: Sets output interface for the packet if there is no explicit route for this destination.</li> </ul> |

|        | Command                                                                                     | Purpose                                                                                                                                                                                                                                                                                                        |
|--------|---------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 4 | <code>Tqwgvt*eqphki/tqwgvg/ocr+% kpvgt<h1>hceg" interface-type interface-number</h1></code> | Specifies the interface, and puts the router into interface configuration mode.                                                                                                                                                                                                                                |
| Step 5 | <code>Tqwgvt*eqphki/kh+% kr"rqnke{"tqwgvg/ocr"map-tag</code>                                | Identifies the route map to use for PBR. One interface can have only one route map tag; but you can have several route map entries, each with its own sequence number. Entries are evaluated in order of their sequence numbers until the first match occurs. If no match occurs, packets are routed as usual. |

The **set** commands can be used in conjunction with each other. They are evaluated in the order shown in Step 3 in the previous task table. A usable next hop implies an interface. Once the local router finds a next hop and a usable interface, it routes the packet.

## Configuring Local PBR

To configure PBR for all traffic that originates on the switch, perform this task:

| Command                                                         | Purpose                                        |
|-----------------------------------------------------------------|------------------------------------------------|
| <code>Tqwgvt*eqphki+% kr"nqecn"rqnke{"tqwgvg/ocr"map-tag</code> | Identifies the route map to use for local PBR. |



### Note

- Local PBR traffic is processed in software on the RP.
- Use the **show ip local policy** command to display the route map used for local PBR.

## Configuring PBR Recursive Next Hop

- [Setting the Recursive Next-Hop IP Address, page 34-5](#)
- [Verifying the Recursive Next-Hop Configuration, page 34-6](#)

### Setting the Recursive Next-Hop IP Address



### Note

PBR supports only one recursive next-hop IP address per route-map entry.

|        | Command or Action                                                                                                                                                           | Purpose                                                                                                                                                                                                             |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <b>gpcdng</b><br><br><b>Example:</b><br>Tqwvgt@"gpcdng                                                                                                                      | Enables privileged EXEC mode.<br><ul style="list-style-type: none"><li>Enter your password if prompted.</li></ul>                                                                                                   |
| Step 2 | <b>eqphkiwtg"vgtokpcn</b><br><br><b>Example:</b><br>Tqwvgt%"eqphkiwtg"vgtokpcn                                                                                              | Enters global configuration mode.                                                                                                                                                                                   |
| Step 3 | <b>ceeguu/nkuv"rgtokv"source</b><br><br><b>Example:</b><br>Tqwvgt*eqphki+%"ceeguu/nkuv"323"rgtokv"<br>320820202"20204770477                                                 | Configures an access list. The example configuration permits any source IP address that falls within the 10.60.0.0. 0.0.255.255 subnet.                                                                             |
| Step 4 | <b>tqwvg/ocr"map-tag</b><br><br><b>Example:</b><br>Tqwvgt*eqphki+%"tqwvg/ocr"cdeeqor                                                                                        | Enables policy routing and enters route-map configuration mode.                                                                                                                                                     |
| Step 5 | <b>ugv"kr"pgzv/jqr"ip-address</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/tqwvg/ocr+%"ugv"kr"pgzv/jqr"<br>320320303                                                         | Sets a next-hop router IP address.<br><b>Note</b> Set this IP address separately from the next-hop recursive router configuration.                                                                                  |
| Step 6 | <b>ugv"kr"pgzv/jqr"}ip-address"]...ip-address_"~"<br/>tgewtukxg"kr/cfftguu;</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/tqwvg/ocr+%"ugv"kr"pgzv/jqr"<br>tgewtukxg"320420505 | Sets a recursive next-hop IP address.<br><b>Note</b> This configuration does not ensure that packets get routed using the recursive IP address if an intermediate IP address is a shorter route to the destination. |
| Step 7 | <b>ocvej"kr"cfftguu"access-list-number</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/tqwvg/ocr+%"ocvej"kr"cfftguu"323                                                         | Sets an access list to be matched.                                                                                                                                                                                  |
| Step 8 | <b>gpf</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/tqwvg/ocr+%"gpf                                                                                                          | Exits route-map configuration mode and returns to privileged EXEC mode.                                                                                                                                             |

## Verifying the Recursive Next-Hop Configuration

To verify the recursive next-hop configuration, perform the following steps.

### Step 1 show running-config | begin abccomp

Use this command to verify the IP addresses for a next-hop and recursive next-hop IP address, for example:

```
Tqvwgt%"ujqy"twppkpi/eqphki"~"dgikp"cdeeqor

tqwvg/ocr"cdeeqor"rgtokv"32
ocvej"kr"cfftguu"323"#Fghkpgu"vjg"ocvej"etkvgtkc"hqt"cp"ceeguu"nkuv0
ugv"kr"pgzv/jqr"tgewtukxg"32050505"#Kh"vjg"ocvej"etkvgtkc"ctg"ogv."vjg"tgewtukxg"KR"
cfftguu"ku"ugv0
ugv"kr"pgzv/jqr"32030303"32040404"32060606
```

### Step 2 **show route-map** *map-name*

Use this command to display the route maps, for example:

```
Tqvwgt%"ujqy"tqwvg/ocr"cdeeqor

tqwvg/ocr"cdeeqor"."rgtokv"."ugswgpeg"32
Ocvej"encwugu<
kr"cfftguu"*ceeguu/nkuvu+<"323"
Ugv"encwugu<
kr"pgzv/jqr"tgewtukxg"32050505
kr"pgzv/jqr"32030303"32040404"32060606
Rqnke{"tqwvkpi"ocvejgu<"2"rcemgvu."2"d{vgu
```

## Configuration Examples for PBR

- [Equal Access Example](#)
- [Differing Next Hops Example](#)
- [Recursive Next-Hop IP Address: Example](#)



### Note

The examples shown below involve the use of the **access-list** command (ACL). The log keyword should not be used with this command in policy-based routing (PBR) because logging is not supported at the interrupt level for ACLs.

## Equal Access Example

The following example provides two sources with equal access to two different service providers. Packets arriving on asynchronous interface 1 from the source 209.165.200.225 are sent to the router at 209.165.200.228 if the router has no explicit route for the destination of the packet. Packets arriving from the source 209.165.200.226 are sent to the router at 209.165.200.229 if the router has no explicit route for the destination of the packet. All other packets for which the router has no explicit route to the destination are discarded.

```
ceeguu/nkuv"3"rgtokv"42;038704220447
ceeguu/nkuv"4"rgtokv"42;038704220448
#
kpvgtchceg"cu{pe"3
kr"rqnke{"tqwvg/ocr"gswn/ceeguu
#
tqwvg/ocr"gswn/ceeguu"rgtokv"32
ocvej"kr"cfftguu"3
ugv"kr"fghcwnv"pgzv/jqr"42;03870422044:
tqwvg/ocr"gswn/ceeguu"rgtokv"42
ocvej"kr"cfftguu"4
ugv"kr"fghcwnv"pgzv/jqr"42;03870422044;
```

```
tqwvg/ocr"gswn/ceeguu"rgtokv"52
ugv"fghcwnv"kpvgthceg"pwnn2
```

## Differing Next Hops Example

The following example illustrates how to route traffic from different sources to different places (next hops), and how to set the Precedence bit in the IP header. Packets arriving from source 209.165.200.225 are sent to the next hop at 209.165.200.227 with the Precedence bit set to priority; packets arriving from source 209.165.200.226 are sent to the next hop at 209.165.200.228 with the Precedence bit set to critical.

```
ceeguu/nkuv"3"rgtokv"42;038704220447
ceeguu/nkuv"4"rgtokv"42;038704220448
#
kpvgthceg"gvjgtpgv"3
"kr"rqnke{"tqwvg/ocr"Vgzcu
#
tqwvg/ocr"Vgzcu"rgtokv"32
"ocvej"kr"cfftgau"3
"ugv"kr"rtgegfgpeg"rtkqtkv{
"ugv"kr"pgzv/jqr"42;038704220449
#
tqwvg/ocr"Vgzcu"rgtokv"42
"ocvej"kr"cfftgau"4
"ugv"kr"rtgegfgpeg"etkvkecn
"ugv"kr"pgzv/jqr"42;03870422044:
```

## Recursive Next-Hop IP Address: Example

The following example shows the configuration of IP address 10.3.3.3 as the recursive next-hop router:

```
tqwvg/ocr"cdeeqor
ugv"kr"pgzv/jqr"32030303
ugv"kr"pgzv/jqr"32040404
ugv"kr"pgzv/jqr"tgewtukxg"32050505
ugv"kr"pgzv/jqr"32060606
```



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## Layer 3 Interfaces

- [Restrictions for Layer 3 Interfaces, page 35-1](#)
- [How to Configure Subinterfaces on Layer 3 Interfaces, page 35-3](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Restrictions for Layer 3 Interfaces

When configuring Layer 3 interfaces, follow these guidelines and restrictions:

- We recommend that you configure no more than 2,000 Layer 3 VLAN interfaces.
- The **ip unnumbered** command is supported on Layer 3 VLAN interfaces.
- To support VLAN interfaces, create and configure VLANs and assign VLAN membership to Layer 2 LAN ports. For more information, see [Chapter 26, “Virtual Local Area Networks \(VLANs\)”](#) and [Chapter 25, “VLAN Trunking Protocol \(VTP\).”](#)
- Use bridge groups on VLAN interfaces, sometimes called fall-back bridging, to bridge nonrouted protocols. Bridge groups on VLAN interfaces are supported in software on the route processor (RP).
- Cisco IOS Release 15.4SY does not support the IEEE bridging protocol for bridge groups. Configure bridge groups to use the VLAN-bridge or the DEC spanning-tree protocol.
- The PFC supports these features on LAN port Layer 3 subinterfaces:
  - IPv4 unicast forwarding, including MPLS VPN

- IPv4 multicast forwarding, including MPLS VPN
  - 6PE
  - EoMPLS
  - IPv4 unnumbered
  - Counters for subinterfaces in MIBS and with the **show vlans** command
  - iBGP and eBGP
  - OSPF
  - EIGRP
  - RIPv1/v2
  - RIPv2
  - ISIS
  - Static routing
  - Unidirectional link routing (UDLR)
  - IGMPv1, IGMPv2, IGMPv3
  - PIMv1, PIMv2
  - SSM IGMPv3lite and URD
  - IGMP join
  - IGMP static group
  - Multicast routing monitor (MRM)
  - Multicast source discovery protocol (MSDP)
  - SSM
  - IPv4 Ping
  - IPv6 Ping
- Always use the **native** keyword when the VLAN ID is the ID of the IEEE 802.1Q native VLAN. Do not configure encapsulation on the native VLAN of an IEEE 802.1Q trunk without the **native** keyword.
  - The VLAN IDs used for Layer 2 VLANs and Layer 3 VLAN interfaces are separate from any VLAN IDs configured on Layer 3 subinterfaces. You can configure the same VLAN ID on a Layer 2 VLAN or Layer 3 VLAN interface and on a Layer 3 subinterface.
  - You can configure subinterfaces with any normal range or extended range VLAN ID in VTP transparent mode. Because VLAN IDs 1 to 1005 are global in the VTP domain and can be defined on other network devices in the VTP domain, you can use only extended range VLANs with subinterfaces in VTP client or server mode. In VTP client or server mode, normal range VLANs are excluded from subinterfaces.




---

**Note** If you configure normal range VLANs on subinterfaces, you cannot change the VTP mode from transparent.

---

- Ensure that the Logical Interface Database (LDB) Manager does not pre-allocate the entire range of 4096 LDB Logical Interfaces (LIFs) for ports with Layer 3 subinterfaces, failing which results in a system-wide LDB exhaustion.



# How to Configure Subinterfaces on Layer 3 Interfaces

To configure a subinterface, perform this task:

|        | Command                                                                                                                    | Purpose                                                          |
|--------|----------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------|
| Step 1 | Tqwwgt@"gpcdng"                                                                                                            | Enters privileged EXEC mode.                                     |
| Step 2 | Tqwwgt%"eqphkiwtg"vgtokpcn"                                                                                                | Enters global configuration mode.                                |
| Step 3 | Tqwwgt*eqphki+% "kpvgtthceg" }} type slot1rqtv0uwdkpvgtthceg; "~"<br>}rqtv/ejcppgn" rqtvaejcppgnapwodgt0uwdkpvgtthceg; ; " | Selects an interface and enters subinterface configuration mode. |
| Step 4 | Tqwwgt*eqphki/uwdkh+% "gpecruwncvkqp"fqv3s"vlan_ID"]pcvkxg_ "                                                              | Configures 802.1Q encapsulation for the subinterface.            |
| Step 5 | Tqwwgt*eqphki/kh+% "gzkv"                                                                                                  | Returns to global configuration mode.                            |



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





## Unidirectional Ethernet (UDE) and Unidirectional Link Routing (UDLR)

---

- [Prerequisites for UDE and UDLR, page 36-1](#)
- [Restrictions for UDE and UDLR, page 36-2](#)
- [Information About UDE and UDLR, page 36-3](#)
- [Default Settings for UDE and UDLR, page 36-4](#)
- [How to Configure UDE and UDLR, page 36-5](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- Cisco IOS Release 15.4SY supports unidirectional Ethernet (UDE) and unidirectional link routing (UDLR) only on the WS-X6704-10GE 4-port 10-Gigabit Ethernet switching module.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)  
[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for UDE and UDLR

None.

# Restrictions for UDE and UDLR

- [UDE Restrictions, page 36-2](#)
- [UDLR Back-Channel Tunnel Restrictions, page 36-3](#)

## UDE Restrictions

- STP cannot prevent Layer 2 loops in topologies that include unidirectional links.
- Send-only ports always transition to the STP forwarding state, because send-only ports never receive BPDUs.
- Receive-only ports cannot send BPDUs.
- Unidirectional ports do not support any features or protocols that require negotiation with the port at the other end of the link, including these:
  - Speed and duplex mode autonegotiation
  - Link negotiation
  - IEEE 802.3Z flow control
  - Dynamic trunking protocol (DTP)

You must manually configure the parameters that are typically controlled by Layer 2 protocols.

- A topology that includes unidirectional links only supports the VLAN Trunking Protocol (VTP) when the VTP server can send VTP frames to all switches in the VTP domain.
- Disable VTP pruning on switches that have send-only ports, because VTP pruning depends on a bidirectional exchange of information.
- Unidirectional EtherChannels cannot support PAgP or LACP. To create a unidirectional EtherChannel, you must configure the EtherChannel “on” mode.
- You can configure software-based UDE on the physical ports in an EtherChannel. You cannot configure software-based UDE on any nonphysical interfaces (for example, port-channel interfaces).
- When you implement hardware-based UDE on a port or configure software-based UDE on a port, UDLD is automatically disabled on the port.
- CDP sends CDP frames from send-only ports and receives CDP frames from receive-only ports, which means that the switch on the send-only side of a unidirectional link never receives CDP information.
- SPAN does not restrict configuration of unidirectional ports as sources or destinations.
  - Send-only ports can be SPAN destinations.
  - Receive-only ports can be SPAN sources.
- Unidirectional ports do not support IEEE 802.1X port-based authentication.
- IGMP snooping does not support topologies where there are unidirectional links between the switch and the hosts that are receiving multicast traffic.
- Configure UDLR with UDE to support communication over unidirectional links between IGMP snooping on the switch and a multicast router.
- Unidirectional links do not support ARP.

## UDLR Back-Channel Tunnel Restrictions

- The PFC does not provide hardware support for UDLR back-channel tunnels. UDLR back-channel tunnels are supported in software.
- Configure a UDLR back-channel tunnel for each unidirectional link.
- On UDE send-only interfaces, configure the UDLR back-channel tunnel interface to receive.
- On UDE receive-only interfaces, configure the UDLR back-channel tunnel interface to send.
- You must configure IPv4 addresses on UDLR back-channel tunnel interfaces.
- You must configure source and destination IPv4 addresses on UDLR back-channel tunnel interfaces.
- The UDLR back-channel tunnel default mode is GRE.
- UDLR back-channel tunnels do not support IPv6 or MPLS.

## Information About UDE and UDLR

- [UDE and UDLR Overview, page 36-3](#)
- [Information about UDE, page 36-3](#)
- [Information about UDLR, page 36-4](#)

## UDE and UDLR Overview

Routing protocols support unidirectional links only if the unidirectional links emulate bidirectional links because routing protocols expect to send and receive traffic through the same interface.

Unidirectional links are advantageous because when you transmit mostly unacknowledged unidirectional high-volume traffic (for example, a video broadcast stream) over a high-capacity full-duplex bidirectional link, you use both the link from the source to the receiver and the equally high-capacity reverse-direction link, called the “back channel,” that carries the few acknowledgements from the receiver back to the source.

UDE and UDLR support use of a high-capacity unidirectional link for the high-volume traffic without consuming a similar high-capacity link for the back channel. UDE provides a high-capacity unidirectional link. UDLR provides the back channel through a tunnel that is configured over a regular-capacity link, and also provides bidirectional link emulation by transparently making the back channel appear to be on the same interface as the high-capacity unidirectional link.

## Information about UDE

- [UDE Overview, page 36-4](#)
- [Hardware-Based UDE, page 36-4](#)
- [Software-Based UDE, page 36-4](#)

## UDE Overview

You can implement UDE with hardware or in software. Hardware-based UDE and software-based UDE both use only one strand of fiber instead of the two strands of fiber required by bidirectional traffic.

The supported unidirectional transceiver (WDM-XENPAK-REC) provides receive-only UDE. You can configure software-based UDE as either transmit-only or receive-only. You do not need to configure software-based UDE on ports where you implement hardware-based UDE.

## Hardware-Based UDE

You can create a unidirectional link by using a unidirectional transceiver. Unidirectional transceivers are less expensive than bidirectional transceivers. The supported unidirectional transceiver is WDM-XENPAK-REC.

## Software-Based UDE

You can create a unidirectional link by configuring ports equipped with bidirectional transceivers to unidirectionally transmit or receive traffic. You can use software-based UDE when there is no appropriate unidirectional transceiver available. For example, with no supported transmit-only transceivers, you must configure transmit-only links with software-based UDE.

## Information about UDLR

UDLR provides a unidirectional tunnel as the back channel of a unidirectional high-capacity link, and transparently emulates a single bidirectional link for unicast and multicast traffic.

UDLR intercepts packets that need to be sent on receive-only interfaces and sends them on UDLR back-channel tunnels. When routers receive these packets over UDLR back-channel tunnels, UDLR makes the packets appear as if received on send-only interfaces.

UDLR back-channel tunnels support these IPv4 features:

- Address Resolution Protocol (ARP)
- Next Hop Resolution Protocol (NHRP)
- Emulation of a bidirectional link for all IPv4 traffic (as opposed to only broadcast and multicast control traffic)
- IPv4 GRE multipoint at a receive-only tunnels



Note

---

UDLR back-channel tunnels do not support IPv6 or MPLS.

---

## Default Settings for UDE and UDLR

None.

## Note

```
Tqwvgt*eqphki/kh+%gpf
```

```
Yctpkpi#
```

```
Gpcdng"rqtv"wpkfktgevkqpcn"oqfg"yknn"cwvgocvkecnn{"fkucdng"rqtv"wnf0"[qw"owuv"ocpwcnn{"gpuwtg"vjcv"vjg"wpkfktgevkqpcn"nkpm"fqgu"pqv"etgcvg"c"urcppkpi"vtgg"nqqr"kp"vjg"pgvyqtm0
```

```
Gpcdng"n5"rqtv"wpkfktgevkqpcn"oqfg"yknn"cwvgocvkecnn{"fkucdng"kr"tqwkpi"qp"vjg"rqtv0"[qw"owuv"ocpwcnn{"eqphkiwtg"uvcvke"kr"tqwvg"cpf"ctr"gpvt{"kp"qtfgt"vq"tqwvg"kr"vtchhke0
```

This example shows how to configure 10-Gigabit Ethernet port 1/2 as a UDE receive-only port:

```
Tqwvgt%"eqphkiwtg"vgtokpcn"
```

```
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
```

```
Tqwvgt*eqphki+%kpvgthceg"vgpikicdkvgvjgtpgv"314"
```

```
Tqwvgt*eqphki/kh+%wpkfktgevkqpcn"tgegkxg/qpn{
```

```
Tqwvgt*eqphki/kh+%gpf
```

```
Yctpkpi#
```

```
Gpcdng"rqtv"wpkfktgevkqpcn"oqfg"yknn"cwvgocvkecnn{"fkucdng"rqtv"wnf0"[qw"owuv"ocpwcnn{"gpuwtg"vjcv"vjg"wpkfktgevkqpcn"nkpm"fqgu"pqv"etgcvg"c"urcppkpi"vtgg"nqqr"kp"vjg"pgvyqtm0
```

```
Gpcdng"n5"rqtv"wpkfktgevkqpcn"oqfg"yknn"cwvgocvkecnn{"fkucdng"kr"tqwkpi"qp"vjg"rqtv0"[qw"owuv"ocpwcnn{"eqphkiwtg"uvcvke"kr"tqwvg"cpf"ctr"gpvt{"kp"qtfgt"vq"tqwvg"kr"vtchhke0
```

This example shows how to verify the configuration:

```
Tqwvgt@"ujqy"kpvgthceg"vgpikicdkvgvjgtpgv"313"wpkfktgevkqpcn
```

```
Wpkfktgevkqpcn"eqphkiwtcvkqp"oqfg<"ugpf"qpn{
```

```
" "EFR"pgkijdwgt"wpkfktgevkqpcn"eqphkiwtcvkqp"oqfg<"tgegkxg"qpn{
```

This example shows how to disable UDE on 10-Gigabit Ethernet interface 1/1:

```
Tqwvgt%"eqphkiwtg"vgtokpcn"
```

```
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
```

```
Tqwvgt*eqphki+%kpvgthceg"vgpikicdkvgvjgtpgv"313"
```

```
Tqwvgt*eqphki/kh+%pq"wpkfktgevkqpcn
```

```
Tqwvgt*eqphki/kh+%gpf
```

This example shows the result of entering the **show interface** command for a port that does not support unidirectional Ethernet:

```
Tqwvgt%"ujqy"kpvgthceg"ikicdkvgvjgtpgv"813"wpkfktgevkqpcn"
```

```
Wpkfktgevkqpcn"Gvjgtpgv"ku"pqv"uwrrqtvvf"qp"IkicdkvGvjgtpgv813
```

## Configuring UDLR

- [Configuring a Receive-Only Tunnel Interface for a UDE Send-Only Port, page 36-7](#)
- [Configuring a Send-Only Tunnel Interface for a UDE Receive-Only Port, page 36-7](#)



## Configuring a Receive-Only Tunnel Interface for a UDE Send-Only Port

To configure a receive-only tunnel interface for a UDE send-only port, perform this task:

|        | Command                                                                          | Purpose                                                                   |
|--------|----------------------------------------------------------------------------------|---------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% kpvgt hceg"vwppgn"pwodgt"</code>                           | Selects the tunnel interface.                                             |
| Step 2 | <code>Tqwvgt*eqphki/kh+% vwppgn"wfmt"tgegkxg/qpn{" wfgatgegkxgaqpn{arqtv"</code> | Associates the tunnel receive-only interface with the UDE send-only port. |
| Step 3 | <code>Tqwvgt*eqphki/kh+% kr"cfftguu"ipv4_address"</code>                         | Configures the tunnel IPv4 address.                                       |
| Step 4 | <code>Tqwvgt*eqphki/kh+% vwppgn"uqwteg" }ipv4_address"~"type number;</code>      | Configures the tunnel source.                                             |
| Step 5 | <code>Tqwvgt*eqphki/kh+% vwppgn"fguvkcpcvkqp" }jquvpcog"~"ipv4_address;</code>   | Configures the tunnel destination.                                        |

## Configuring a Send-Only Tunnel Interface for a UDE Receive-Only Port

To configure a send-only tunnel interface for a UDE receive-only port, perform this task:

|        | Command                                                                        | Purpose                                                                   |
|--------|--------------------------------------------------------------------------------|---------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% kpvgt hceg"vwppgn"pwodgt"</code>                         | Selects the tunnel interface.                                             |
| Step 2 | <code>Tqwvgt*eqphki/kh+% vwppgn"wfmt"ugpf/qpn{" wfgatgegkxgaqpn{arqtv"</code>  | Associates the tunnel send-only interface with the UDE receive-only port. |
| Step 3 | <code>Tqwvgt*eqphki/kh+% kr"cfftguu"ipv4_address"</code>                       | Configures the tunnel IPv4 address.                                       |
| Step 4 | <code>Tqwvgt*eqphki/kh+% vwppgn"uqwteg" }ipv4_address"~"type number;</code>    | Configures the tunnel source.                                             |
| Step 5 | <code>Tqwvgt*eqphki/kh+% vwppgn"fguvkcpcvkqp" }jquvpcog"~"ipv4_address;</code> | Configures the tunnel destination.                                        |
| Step 6 | <code>Tqwvgt*eqphki/kh+% vwppgn"wfmt" cfftguu/tguqnwvkqp"</code>               | Enables ARP and NHRP.                                                     |

In the following UDE and UDLR sample configuration:

- On Router A:
  - Open Shortest Path First (OSPF) and PIM are configured.
  - 10-Gigabit Ethernet port 1/1 is a send-only UDE port.
  - The UDLR back-channel tunnel is configured as receive only and is associated with 10-Gigabit Ethernet port 1/1.
- On Router B:
  - OSPF and PIM are configured.
  - 10-Gigabit Ethernet port 1/2 is a receive-only UDE port.
  - The UDLR back-channel tunnel is configured as send-only and is associated with 10-Gigabit Ethernet port 1/2.
  - ARP and NHRP are enabled.

**Router A Configuration**

```

kr"ownvkecuv/tqwkpi
#
#"vgpikicdkvgvjgtpgv"313"ku"ugpf/qpn{ "
#
kpvgtthceg"vgpikicdkvgvjgtpgv"313"
 wpkfkktgevkqpcn"ugpf/qpn{
 kr"cfftguu"32030203"47704770202
 kr"rko"urctug/fgpug/oqfg
#
#"Eqphkiwtg"vwppgn"cu"tgegkxg/qpn{ "WFNT"vwppgn0
#
kpvgtthceg"vwppgn"2
 vwppgn"ugwteg"33020203
 vwppgn"fguvkpcvkqp"33020204
 vwppgn"wfnt"tgegkxg/qpn{ "vgpikicdkvgvjgtpgv"313"
#
#"Eqphkiwtg"QURH0
#
tqwvgt"qurh">rkf@
pgvyqtm"32020202"2047704770477"ctgc"2

```

**Router B Configuration**

```

kr"ownvkecuv/tqwkpi
#
#"vgpikicdkvgvjgtpgv"314"ku"tgegkxg/qpn{ "
#
kpvgtthceg"vgpikicdkvgvjgtpgv"314"
 wpkfkktgevkqpcn"tgegkxg/qpn{
 kr"cfftguu"32030204"47704770202
 kr"rko"urctug/fgpug/oqfg
#
#"Eqphkiwtg"vwppgn"cu"ugpf/qpn{ "WFNT"vwppgn0
#
kpvgtthceg"vwppgn"2
 vwppgn"ugwteg"33020204
 vwppgn"fguvkpcvkqp"33020203
 vwppgn"wfnt"ugpf/qpn{ "vgpikicdkvgvjgtpgv"314
 vwppgn"wfnt"cfftguu/tguqnwvkqp
#
#"Eqphkiwtg"QURH0
#
tqwvgt"qurh">rkf@
pgvyqtm"32020202"2047704770477"ctgc"2

```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



# Multiprotocol Label Switching (MPLS)

- [Prerequisites for MPLS, page 37-1](#)
- [Restrictions for MPLS, page 37-1](#)
- [Information About MPLS, page 37-2](#)
- [Default Settings for MPLS, page 37-7](#)
- [How to Configure MPLS Features, page 37-7](#)
- [Configuration Examples for MPLS, page 37-9](#)



## Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for MPLS

None.

## Restrictions for MPLS

- The PFC and DFCs supports up to 16 load-shared paths (Cisco IOS releases for other platforms support only 8 load-shared paths).
- MTU size checking is supported in hardware.

- Fragmentation is supported in software, including traffic that ingresses as IP and egresses as MPLS. To prevent excessive CPU utilization, you can rate-limit the traffic being sent to the RP for fragmentation with the **platform rate-limit all mtu-failure** command.
- MPLS supports these commands:
  - **mpls ip default route**
  - **mpls ip propagate-ttl**
  - **mpls ip ttl-expiration pop**
  - **mpls label protocol**
  - **mpls label range**
  - **mpls ip**
  - **mpls label protocol**
  - **mpls mtu**

For information about these commands, see these publications:

[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)

Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.

## Information About MPLS

- [MPLS Overview, page 37-2](#)
- [IP to MPLS, page 37-4](#)
- [MPLS to MPLS, page 37-4](#)
- [MPLS to IP, page 37-4](#)
- [MPLS VPN Forwarding, page 37-5](#)
- [Recirculation, page 37-5](#)
- [Hardware Supported Features, page 37-5](#)
- [Supported MPLS Features, page 37-6](#)

## MPLS Overview


MPLS uses label switching to forward packets over Ethernet. Labels are assigned to packets based on groupings or forwarding equivalence classes (FECs). The label is added between the Layer 2 and the Layer 3 header.

In an MPLS network, the label edge router (LER) performs a label lookup of the incoming label, swaps the incoming label with an outgoing label, and sends the packet to the next hop at the label switch router (LSR). Labels are imposed (pushed) on packets only at the ingress edge of the MPLS network and are removed (popped) at the egress edge. The core network LSRs (provider, or P routers) read the labels, apply the appropriate services, and forward the packets based on the labels.

Incoming labels are aggregate or nonaggregate. The aggregate label indicates that the arriving MPLS packet must be switched through an IP lookup to find the next hop and the outgoing interface. The nonaggregate label indicates that the packet contains the IP next hop information.

Figure 37-1 shows an MPLS network of a service provider that connects two sites of a customer network.


Figure 37-1 MPLS Network



The route processor (RP) performs Layer 3 control-plane functions, including address resolution and routing protocols. The RP processes information from the Routing and Label Distribution Protocols and builds the IP forwarding (FIB) table and the label forwarding (LFIB) table. The RP distributes the information in both tables to the PFC and DFCs.

The PFC and DFCs receive the information and create their own copies of the FIB and LFIB tables. Together, these tables comprise the FIB TCAM. The PFC and DFCs look up incoming IP packets and labeled packets against the FIB TCAM table. The lookup result is the pointer to a particular adjacency entry. It is the adjacency entry that contains appropriate information for label pushing (for IP to MPLS path), label swapping (for MPLS to MPLS path), label popping (for MPLS to IP path), and encapsulation.

Figure 37-2 shows the various functional blocks that support MPLS. Routing protocol generates a routing information base (RIB) that is used for forwarding IP and MPLS data packets. For Cisco Express Forwarding (CEF), necessary routing information from the RIB is extracted and built into a forwarding information base (FIB). The label distribution protocol (LDP) obtains routes from the RIB and distributes the label across a label switch path to build a label forwarding information base (LFIB) in each of the LSRs and LERs.

**Figure 37-2** *MPLS Forwarding, Control and Data Planes*

## IP to MPLS

At the ingress to the MPLS network, the PFC examines the IP packets and performs a route lookup in the FIB TCAM. The lookup result is the pointer to a particular adjacency entry. The adjacency entry contains the appropriate information for label pushing (for IP to MPLS path) and encapsulation. The PFC generates a result containing the imposition label(s) needed to switch the MPLS packet.

## MPLS to MPLS

At the core of an MPLS network, the PFC uses the topmost label to perform a lookup in the FIB TCAM. The successful lookup points to an adjacency that swaps the top label in the packet with a new label as advertised by the downstream label switch router (LSR). If the router is the penultimate hop LSR router (the upstream LSR next to the egress LER), the adjacency instructs the PFCBXL to pop the topmost label, resulting in either an MPLS packet with the remaining label for any VPN or AToM use or a native IP packet.

## MPLS to IP

At the egress of the MPLS network there are several possibilities.

For a native IP packet (when the penultimate router has popped the label), the PFC performs a route lookup in the FIB TCAM.

For a MPLS VPN packet, after the Interior Gateway Protocol (IGP) label is popped at penultimate router, the VPN label remains. The operation that the PFC performs depends on the VPN label type. Packets carrying aggregate labels require a second lookup based on the IP header after popping the aggregate label. For a nonaggregate label, the PFC performs a route lookup in the FIB TCAM to obtain the IP next hop information.

For the case of a packet with an IGP label and a VPN label, when there is no penultimate hop popping (PHP), the packet carries the explicit-null label on top of the VPN label. The PFC looks up the top label in the FIB TCAM and recirculates the packet. Then the PFC handles the remaining label as described in the preceding paragraph, depending on whether it is an aggregate or nonaggregate label.

Packets with the explicit-null label for the cases of EoMPLS, MPLS, and MPLS VPN an MPLS are handled the same way.

## MPLS VPN Forwarding

There are two types of VPN labels: aggregate labels for directly connected network or aggregate routes, and nonaggregate labels. Packets carrying aggregate labels require a second lookup based on the IP header after popping the aggregate label. The VPN information (VPN-IPv4 address, extended community, and label) is distributed through the Multiprotocol-Border Gateway Protocol (MP-BGP).

## Recirculation

In certain cases, the PFC provides the capability to recirculate the packets. Recirculation can be used to perform additional lookups in the ACL or QoS TCAMs, the NetFlow table, or the FIB TCAM table. Recirculation is necessary in these situations:

- To push more than three labels on imposition
- To pop more than two labels on disposition
- To pop an explicit null top label
- When the VPN Routing and Forwarding (VRF) number is more than 511
- For IP ACL on the egress interface (for nonaggregate (per-prefix) labels only)

Packet recirculation occurs only on a particular packet flow; other packet flows are not affected. The rewrite of the packet occurs on the modules; the packets are then forwarded back to the PFC for additional processing.

## Hardware Supported Features

The following features are supported in hardware:

- Label operation—Any number of labels can be pushed or popped, although for best results, up to three labels can be pushed, and up to two labels can be popped in the same operation.
- IP to MPLS path—IP packets can be received and sent to the MPLS path.
- MPLS to IP path—Labeled packets can be received and sent to the IP path.
- MPLS to MPLS path—Labeled packets can be received and sent to the label path.
- MPLS Traffic Engineering (MPLS TE)—Enables an MPLS backbone to replicate and expand the traffic engineering capabilities of Layer 2 ATM and Frame Relay networks.
- Time to live (TTL) operation—At the ingress edge of the MPLS network, the TTL value in the MPLS frame header can be received from either the TTL field of the IP packet header or the user-configured value from the adjacency entry. At the egress of the MPLS network, the final TTL equals the minimum (label TTL and IP TTL)-1.

**Note**

With the Uniform mode, the TTL is taken from the IP TTL; with the Pipe mode, a value of 255, taken from the hardware register, is used for the outgoing label.

- QoS—Information on Differentiated Services (DiffServ) and ToS from IP packets can be mapped to MPLS EXP field.
- MPLS/VPN Support—Up to 1024 VRFs can be supported (over 511 VRFs requires recirculation).
- Ethernet over MPLS—The Ethernet frame can be encapsulated at the ingress to the MPLS domain and the Ethernet frame can be decapsulated at the egress.
- Packet recirculation—The PFC provides the capability to recirculate the packets. See the “Recirculation” section on page 37-5.
- Configuration of MPLS switching is supported on VLAN interfaces with the **mpls ip** command.

## Supported MPLS Features

- MPLS features:
  - Basic MPLS
  - MPLS TE
  - MPLS TE DiffServ Aware (DS-TE)
  - MPLS TE Forwarding Adjacency
  - MPLS TE Interarea Tunnels
  - MPLS virtual private networks (VPNs)
  - MPLS VPN Carrier Supporting Carrier (CSC)
  - MPLS VPN Carrier Supporting Carrier IPv4 BGP Label Distribution
  - MPLS VPN Interautonomous System (InterAS) Support
  - MPLS VPN Inter-AS IPv4 BGP label distribution

See these publications for more information:

[http://www.cisco.com/en/US/docs/ios-xml/ios/mps/config\\_library/15-sy/mp-15-sy-library.html](http://www.cisco.com/en/US/docs/ios-xml/ios/mps/config_library/15-sy/mp-15-sy-library.html)

[http://www.cisco.com/en/US/tech/tk436/tk428/technologies\\_configuration\\_example09186a0080093feb.shtml](http://www.cisco.com/en/US/tech/tk436/tk428/technologies_configuration_example09186a0080093feb.shtml)

[http://www.cisco.com/en/US/tech/tk436/tk428/technologies\\_configuration\\_example09186a0080093fd0.shtml](http://www.cisco.com/en/US/tech/tk436/tk428/technologies_configuration_example09186a0080093fd0.shtml)

- HSRP Support for MPLS VPNs—See this publication:  
[http://www.cisco.com/en/US/docs/ios-xml/ios/ipapp\\_fhrp/configuration/15-sy/fhrp-15-sy-book.html](http://www.cisco.com/en/US/docs/ios-xml/ios/ipapp_fhrp/configuration/15-sy/fhrp-15-sy-book.html)
- OSPF Sham-Link Support for MPLS VPN—See this publication:  
[http://www.cisco.com/en/US/docs/ios-xml/ios/iproute\\_ospf/configuration/15-sy/iro-sham-link.html](http://www.cisco.com/en/US/docs/ios-xml/ios/iproute_ospf/configuration/15-sy/iro-sham-link.html)



- Multi-VPN Routing and Forwarding (VRF) for CE Routers (VRF Lite)—VRF Lite is supported with the following features:
  - IPv4 forwarding between VRFs interfaces
  - IPv4 ACLs
  - IPv4 HSRP

See this publication:

[http://www.cisco.com/en/US/products/hw/routers/ps259/prod\\_bulletin09186a00800921d7.html](http://www.cisco.com/en/US/products/hw/routers/ps259/prod_bulletin09186a00800921d7.html)

## Default Settings for MPLS

None.

## How to Configure MPLS Features

- [Configuring MPLS, page 37-7](#)
- [Configuring MUX-UNI Support on LAN Cards, page 37-7](#)

## Configuring MPLS

Use these publications to configure MPLS:

[http://www.cisco.com/en/US/docs/ios-xml/ios/mpls/config\\_library/15-sy/mp-15-sy-library.html](http://www.cisco.com/en/US/docs/ios-xml/ios/mpls/config_library/15-sy/mp-15-sy-library.html)

## Configuring MUX-UNI Support on LAN Cards

A User Network Interface (UNI) is the point where the customer edge (CE) equipment connects to the ingress PE and an attachment VLAN is a VLAN on a UNI port.

The MUX-UNI support on LAN cards feature provides the ability to partition a physical port on an attachment VLAN to provide multiple Layer 2 and Layer 3 services over a single UNI.

To configure MUX-UNI support on LAN cards, perform this task on the provider edge (PE) routers.

|        | Command                                                                      | Purpose                                                                                                                           |
|--------|------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt%<b>"eqphkiwtg"vgtokpcn</b>"</code>                              | Enters global configuration mode.                                                                                                 |
| Step 2 | <code>Tqwvgt*eqphki+%"<b>interface</b> type number</code>                    | Selects an interface to configure and enters interface configuration mode; valid only for Ethernet ports.                         |
| Step 3 | <code>Tqwvgt*eqphki/kh+%"<b>uykvejrqtv</b></code>                            | Puts an interface that is in Layer 3 mode into Layer 2 mode for Layer 2 configuration.                                            |
| Step 4 | <code>Tqwvgt*eqphki/kh+%"<b>uykvejrqtv"vtwpm"gpecruwncvkqp"fqv3s"</b></code> | Configures the port to support 802.1Q encapsulation.<br>You must configure each end of the link with the same encapsulation type. |
| Step 5 | <code>Tqwvgt*eqphki/kh+%"<b>uykvejrqtv"oqfg"vtwpm"</b></code>                | Configures the port as a VLAN trunk.                                                                                              |

|                |                                                                                     |                                                                                                                                                                                                                                                                                                                      |
|----------------|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 6</b>  | <code>Tqwgvt*eqphki/kh+% "uykvej rqtv" vtwpm" cnnqygf "xncp" vlan-list"</code>      | By default, all VLANs are allowed. Use this command to explicitly allow VLANs; valid values for <i>vlan-list</i> are from 1 to 4094.<br><br><b>Note</b> Avoid overlapping VLAN assignments between main and subinterfaces. VLAN assignments between the main interface and subinterfaces must be mutually exclusive. |
| <b>Step 7</b>  | <code>Tqwgvt*eqphki/kh+% "gzkv"</code>                                              | Exits interface configuration mode.                                                                                                                                                                                                                                                                                  |
| <b>Step 8</b>  | <code>Tqwgvt*eqphki+% "kpvgthceg" type slot/port.subinterface-number"</code>        | Selects a subinterface to configure and enters interface configuration mode; valid only for Ethernet ports.                                                                                                                                                                                                          |
| <b>Step 9</b>  | <code>Tqwgvt*eqphki/kh+% "gpecruwncvkqp" fqv3s" xncpakf"</code>                     | Enables the subinterface to accept 802.1Q VLAN packets.<br><br>The subinterfaces between the CE and PE routers that are running Ethernet over MPLS must be in the same subnet. All other subinterfaces and backbone routers do not need to be on the same subnet.                                                    |
| <b>Step 10</b> | <code>Tqwgvt*eqphki/kh+% "zeqppgev" peer_router_id vcid gpecruwncvkqp" ornu"</code> | Binds the attachment circuit to a pseudowire VC. The syntax for this command is the same as for all other Layer 2 transports.                                                                                                                                                                                        |

This example shows a physical trunk port used as UNI:

```
Tqwgvt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv" 513
Tqwgvt*eqphki/kh+% "uykvej rqtv
Tqwgvt*eqphki/kh+% "uykvej rqtv" gpecruwncvkqp" fqv3s
Tqwgvt*eqphki/kh+% "uykvej rqtv" oqfg" vtwpm
Tqwgvt*eqphki/kh+% "uykvej rqtv" vtwpm" cnnqygf "xncp" 422/472
Tqwgvt*eqphki/kh+% "gzkv

Tqwgvt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv" 513032
Tqwgvt*eqphki/kh+% "gpecr" fqv3s" 5222
Tqwgvt*eqphki/kh+% "zeqppgev" 32020203 "5222" gpecruwncvkqp" ornu
Tqwgvt*eqphki/kh+% "gzkv
```

This example shows a Layer 2 port channel used as UNI:

```
Tqwgvt*eqphki+% "kpvgthceg" rqtv/ejcppgn" 322
Tqwgvt*eqphki/kh+% "uykvej rqtv
Tqwgvt*eqphki/kh+% "uykvej rqtv" vtwpm" gpecruwncvkqp" fqv3s
Tqwgvt*eqphki/kh+% "uykvej rqtv" vtwpm" cnnqygf "xncp" 322/422
Tqwgvt*eqphki/kh+% "uykvej rqtv" oqfg" vtwpm
Tqwgvt*eqphki/kh+% "pq" kr" cfftguu
Tqwgvt*eqphki/kh+% "gzkv

Tqwgvt*eqphki+% "kpvgthceg" rqtv/ejcppgn" 32203
Tqwgvt*eqphki/kh+% "gpecruwncvkqp" fqv3s" 5322
Tqwgvt*eqphki/kh+% "zeqppgev" 320202052 "322" gpecruwncvkqp" ornu
Tqwgvt*eqphki/kh+% "gzkv
```

This example shows Layer 3 termination and VRF for muxed UNI ports:

```
Tqwgvt*eqphki+% "xncp" 422. "522. " 622
Tqwgvt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv" 513
Tqwgvt*eqphki/kh+% "uykvej rqtv
```

```

Tqvwgt*eqphki/kh+% "uykvejrgtv" gpecruwncvkqp" fqv3s
Tqvwgt*eqphki/kh+% "uykvejrgtv" oqfg"vtwpm
Tqvwgt*eqphki/kh+% "uykvejrgtv"vtwpm"cnngygf"xncp"422/722
Tqvwgt*eqphki/kh+% "gzkv

Tqvwgt*eqphki+% "kpvgtthceg"ikiCDkvGvjgtpgv"513032
Tqvwgt*eqphki/kh+% "gpecr" fqv3s"5222
Tqvwgt*eqphki/kh+% "zeqppgev"32020203"5222" gpecruwncvkqp"ornu
Tqvwgt*eqphki/kh+% "gzkv

Tqvwgt*eqphki+% "kpvgtthceg"xncp"422
Tqvwgt*eqphki/kh+% "kr" cfftguu"32030305
Tqvwgt*eqphki/kh+% "gzkv

Tqvwgt*eqphki+% "kpvgtthceg"xncp"522
Tqvwgt*eqphki/kh+% "kr" xrp"XTH"C
Tqvwgt*eqphki/kh+% "kr" cfftguu"5050503
Tqvwgt*eqphki/kh+% "gzkv

Tqvwgt*eqphki+% "kpvgtthceg"xncp"622
Tqvwgt*eqphki/kh+% "kr" cfftguu"6060603
Tqvwgt*eqphki/kh+% "kr" qurh"pgvyqtm"dtqcfecuv
Tqvwgt*eqphki/kh+% "ornu"ncdgn"rtqvqeqn"nfr
Tqvwgt*eqphki/kh+% "ornu"kr
Tqvwgt*eqphki/kh+% "gzkv

```

## Configuration Examples for MPLS

The following is an example of a basic MPLS configuration:

```

' ' ' '
Duke"ORNU
' ' ' '

KR"kpitguu"kpvgthceg<

Tqvwgt%"ornu"ncdgn"rtqvqeqn"nfr"

kpvgthceg"IkiCDkvGvjgtpgv814
"kr" cfftguu"970209903"4770477047702
"ogfkC/v{rg"t167
"urggf"3222
gpf

Ncdgn"gitguu"kpvgthceg<

kpvgthceg"IkiCDkvGvjgtpgv9137
"ovw";438
"kr" cfftguu"970208904"4770477047702
"nqiikpi"gxgpv"nkpm/uvCvwu
"ornu"kr

Tqvwgt%"ujqy"kr"tqwvg"3::020202"
Tqvwkpi"gpvt{"hqt"3::020202146."3"mpgyp"uwdpgvu

Q"KC""3::020202"]33213_"xkc"970209904."22<22<32."IkiCDkvGvjgtpgv814

Tqvwgt%"ujqy"kr"tqvwkpi"::020202"

```

```

Tqwwkpi"gpvt{"hqt": :020202146."3"mpqyp"uwdpgvu

Q"G4""": :020202]33212_"xkc"970208903."22<22<46."IkicdkvGvjgtpgv9137
""""""""""]33212_"xkc"970204304."22<22<46."IkicdkvGvjgtpgv9138
Tqwwgt%"ujqy"ornu"hqtyctfkpi/vcdng": :020202"
Nqecn""Qwviqkpi""Rtghkz""""""""D{vgu"vci""Qwviqkpi""Pgzv"Jqr"
vci""vci"qt"XE""qt"Vwppgn"Kf""""""uykvejgf""kpvgtthceg"
52""""72""""": :020202146""""2""""Ik9137""""970208903"
""""72""""": :020202146""""2""""Ik9138""""970204304"

Tqwwgt%"ujqy"rncvhqto"egh": :020202"fgvckn"

Eqfgu<"O"/"ocum"gpvt{."X"/"xcnwg"gpvt{."C"/"cflcege{"kpfgz."R"/"rtkqtkv{"dkv
""""""F"/"hwnn"fqpv"uykvej."o"/"nqcf"dcncpekpi"oqfpwodgt."D"/"DIR"Dwemgv"ugn
""""X2"/"Xncp"2.E2"/"fqpv"eqor"dkv"2.X3"/"Xncp"3.E3"/"fqpv"eqor"dkv"3
""""TXVGP"/"TRH"Xncp"vcdng"gpdcng."TXVUGN"/"TRH"Xncp"vcdng"ugngev
Hqtocv<"KRX6aFC"/"~";"~"zvci"xrp"rk"et"tgekter"vqu"rtghkz+
Hqtocv<"KRX6aUC"/"~";"~"zvci"xrp"rk"et"tgekter"rtghkz+
O*5445""+<"G~"3"HHH""2"2"2""4770477047702
X*5445""+<:"~"3"2""2"2"2""": :020202""""""*C<566327".R<3.F<2.O<3".D<2"+
O*5445""+<"G~"3"HHH""2"2"2"4770477047702
X*5445""+<:"~"3"2""2"2"2": :020202""*X2<2""".E2<2".X3<2""".E3<2".TXVGP<2".TXVUGN<2""+
Tqwwgt%"ujqy"rncvhqto"egh"cfl"gpv"566327"

Kpfgz<"566327""uoc<"22270;c5;0c6:2."foce<"222c0:cf:04562
""""""""ovw<"456."xncp<"3253."fkpfgz<"2z2."n5tyaxnf<"3
""""""""rcemgvu<"32;69:482."d{vgu<"922882:862

Tqwwgt%"ujqy"rncvhqto"egh"cfl"gpv"566327"fgvckn"

Kpfgz<"566327""uoc<"22270;c5;0c6:2."foce<"222c0:cf:04562
""""""""ovw<"456."xncp<"3253."fkpfgz<"2z2."n5tyaxnf<"3
""""""""hqtocv<"ORNU."hnciu<"2z322222:63:"
""""""""ncdgn2<"2."gzzr<"2."qxt<"2
""""""""ncdgn3<"2."gzzr<"2."qxt<"2
""""""""ncdgn4<"72."gzzr<"2."qxt<"2
""""""""qr<"RWUJaNCdGN4
""""""""rcemgvu<"33456663;. "d{vgu<"93;2264:38

```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



# MPLS VPN Support

---

- [Prerequisites for MPLS VPN, page 38-1](#)
- [Restrictions for MPLS VPN, page 38-2](#)
- [Information About MPLS VPN Support, page 38-2](#)
- [How to Configure MPLS VPNs, page 38-3](#)
- [Configuration Example for MPLS VPNs, page 38-4](#)



## Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for MPLS VPN

None.

## Restrictions for MPLS VPN

- When configuring MPLS VPN, note that VPNs are recirculated when the number of VPNs is over 511.
- MPLS VPN supports these commands:
  - **address-family**
  - **exit-address-family**
  - **import map**
  - **ip route vrf**
  - **ip route forwarding**
  - **ip vrf**
  - **neighbor activate**
  - **rd**
  - **route-target**

For information about these commands, see these publications:

[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)


Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.

## Information About MPLS VPN Support

The IP VPN feature for MPLS allows a Cisco IOS network to deploy scalable IP Layer 3 VPN backbone services to multiple sites deployed on a shared infrastructure while also providing the same access or security policies as a private network. VPN based on MPLS technology provides the benefits of routing isolation and security, as well as simplified routing and better scalability. See this publication for more information about MPLS VPNs:

[http://www.cisco.com/en/US/docs/ios-xml/ios/mpls/config\\_library/15-sy/mp-15-sy-library.html](http://www.cisco.com/en/US/docs/ios-xml/ios/mpls/config_library/15-sy/mp-15-sy-library.html)

Figure 38-1 VPNs with MPLS Service Provider Backbone



At the ingress PE, the PFC makes a forwarding decision based on the packet headers. The PFC contains a table that maps VLANs to VPNs. In the switch architecture, all physical ingress interfaces in the system are associated with a specific VPN. The PFC looks up the IP destination address in the CEF table but only against prefixes that are in the specific VPN. (The table entry points to a specific set of adjacencies and one is chosen as part of the load-balancing decision if multiple parallel paths exist.)

The table entry contains the information on the Layer 2 header that the packet needs, as well as the specific MPLS labels to be pushed onto the frame. The information to rewrite the packet goes back to the ingress module where it is rewritten and forwarded to the egress line interface.

VPN traffic is handled at the egress from the PE based upon the per-prefix labels or aggregate labels. If per-prefix labels are used, then each VPN prefix has a unique label association; this allows the PE to forward the packet to the final destination based upon a label lookup in the FIB.

**Note**

The PFC allocates only one aggregate label per VRF.

If aggregate labels are used for disposition in an egress PE, many prefixes on the multiple interfaces may be associated with the label. In this case, the PFC must perform an IP lookup to determine the final destination. The IP lookup may require recirculation.

## How to Configure MPLS VPNs

For information on configuring MPLS VPN, see this publication:

[http://www.cisco.com/en/US/docs/ios-xml/ios/mppls/config\\_library/15-sy/mp-15-sy-library.html](http://www.cisco.com/en/US/docs/ios-xml/ios/mppls/config_library/15-sy/mp-15-sy-library.html)

**Note**

If you use a Layer 3 VLAN interface as the MPLS uplink through a Layer 2 port peering with another MPLS device, then you can use another Layer 3 VLAN interface as the VRF interface.

# Configuration Example for MPLS VPNs

This sample configuration shows LAN CE-facing interfaces. MPLS switching configuration in Cisco IOS Release 15.4SY is identical to configuration in other releases.

```
#kr"xth"dnwgu
"tf"322<32
"tqwvg/vctigv"gzrqtv"322<3
"tqwvg/vctigv"korqtv"322<3
#
ornu"ncdgn"rtqvgeqn"nfr
ornu"nfr"nqiikpi"pgkijdt/ejcpigu
#
kpvgtthceg"Nqgrdcem2
"kr"cfftgau"32060606"477047704770477
#
kpvgtthceg"IkicdkvGvjgtpgv614
"fguetkrvkqp"Ecvcn{uv"nkpm"vq"R4"
"pq"kr"cfftgau
#
kpvgtthceg"IkicdkvGvjgtpgv614064
"gpecruwncvkqp"fqv3S"64
"kr"cfftgau"32020504"4770477047702
"vci/uykvejkipi"kr
#"
kpvgtthceg"IkicdkvGvjgtpgv915
"fguetkrvkqp"Ecvcn{uv"nkpm"vq"EG4
"pq"kr"cfftgau
#
kpvgtthceg"IkicdkvGvjgtpgv915095
"gpecruwncvkqp"fqv3S"95
"kr"xth"hqtyctfkpi"dnwgu
"kr"cfftgau"3203;0903"4770477047702
#
tqwvgt"qurh"322
"nqi/cflcegepe{/ejcpigu
"pgvyqtm"32060606"2020202"ctgc"2
"pgvyqtm"32020202"20204770477"ctgc"2
#
tqwvgt"qurh"87222"xth"dnwgu
"nqi/cflcegepe{/ejcpigu
"tgfkuvtkdwvg"dir"322"uwdpgvu
"pgvyqtm"3203;0202"20204770477"ctgc"2
#
tqwvgt"dir"322
"pq"u{pejtqpk|cvkqp
"dir"nqi/pgkijdt/ejcpigu
"pgkijdt"32050505"tgoqvg/cu"322
"pgkijdt"32050505"fguetkrvkqp"OR/DIR"vq"RG3
"pgkijdt"32050505"wrfcvg/uqwtg"Nqgrdcem2
"pq"cwvq/uwooct{
"#
"cfftgau/hcokn{"xrp6
"pgkijdt"32050505"cevkxcvg
"pgkijdt"32050505"ugpf/eqoowpkv{"gzvgpfvgf
"gzkv/cfftgau/hcokn{
"#
"cfftgau/hcokn{"krx6"xth"dnwgu
"tgfkuvtkdwvg"eqppgevgf
"tgfkuvtkdwvg"qurh"87222"ocvej"kpvgtpcn"gzvgtpcn"3"gzvgtpcn"4
"pq"cwvq/uwooct{
"pq"u{pejtqpk|cvkqp
"gzkv/cfftgau/hcokn{
```



#





## Ethernet over MPLS (EoMPLS)

---

- [Prerequisites for EoMPLS, page 39-1](#)
- [Restrictions for EoMPLS, page 39-2](#)
- [Information About EoMPLS, page 39-3](#)
- [Default Settings for EoMPLS, page 39-3](#)
- [How to Configure EoMPLS, page 39-4](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for EoMPLS

Before you configure EoMPLS, ensure that the network is configured as follows:

- Configure IP routing in the core so that the PE routers can reach each other through IP.
- Configure MPLS in the core so that a label switched path (LSP) exists between the PE routers.

## Restrictions for EoMPLS

- EoMPLS in Cisco IOS Release 15.4SY does not support load balancing at the tunnel ingress; only one Interior Gateway Protocol (IGP) path is selected even if multiple IGP paths are available, but load balancing is available at the MPLS core.
- Ensure that the maximum transmission unit (MTU) of all intermediate links between endpoints is sufficient to carry the largest Layer 2 packet received.
- EoMPLS supports VLAN packets that conform to the IEEE 802.1Q standard. The 802.1Q specification establishes a standard method for inserting VLAN membership information into Ethernet frames.
- When the QoS is enabled on a Layer 2 port, either 802.1q P bits or IP precedence bits can be preserved with the trusted configuration. However, by default the unpreserved bits are overwritten by the value of preserved bits. For instance, if you preserve the P bits, the IP precedence bits are overwritten with the value of the P bits. To preserve the IP precedence bits, use the **no platform qos rewrite ip dscp** command. The **no platform qos rewrite ip dscp** command is not compatible with the MPLS and MPLS VPN features.
- EoMPLS is not supported with private VLANs.
- The following restrictions apply to using trunks with EoMPLS:
  - To support Ethernet spanning tree bridge protocol data units (BPDUs) across an EoMPLS cloud, you must disable spanning tree for the Ethernet-over-MPLS VLAN. This ensures that the EoMPLS VLANs are carried only on the trunk to the customer switch. Otherwise, the BPDUs are not directed to the EoMPLS cloud.
  - The native VLAN of a trunk must not be configured as an EoMPLS VLAN.
- In Cisco IOS Release 15.4SY, all protocols (for example, CDP, VTP, BPDUs) are tunneled across the MPLS cloud without conditions.
- Unique VLANs are required across interfaces. You cannot use the same VLAN ID on different interfaces.
- EoMPLS tunnel destination route in the routing table and the CEF table must be a /32 address (host address where the mask is 255.255.255.255) to ensure that there is a label-switched path (LSP) from PE to PE.
- For a particular EoMPLS connection, both the ingress EoMPLS interface on the ingress PE and the egress EoMPLS interface on the egress PE have to be subinterfaces with dot1Q encapsulation or neither is a subinterface.
- 802.1Q in 802.1Q over EoMPLS is supported if the outgoing interface connecting to MPLS network is a port on an Layer 2 card.
- Shaping EoMPLS traffic is not supported if the egress interface connecting to an MPLS network is a Layer 2 LAN port (a mode known as PFC-based EoMPLS).
- EoMPLS based on a PFC does not perform any Layer 2 lookup to determine if the destination MAC address resides on the local or remote segment and does not perform any Layer 2 address learning (as traditional LAN bridging does).
- The AToM control word is not supported.
- Ethernet packets with hardware-level cyclic redundancy check (CRC) errors, framing errors, and runt packets are discarded on input.
- You must configure VLAN-based EoMPLS on subinterfaces.

- Port-based EoMPLS and VLAN-based EoMPLS are mutually exclusive. If you enable a main interface for port-to-port transport, you also cannot enter commands on a subinterface.
- EoMPLS is not supported on Layer 3 VLAN interfaces.
- Point-to-point EoMPLS works with a physical interface and subinterfaces.

## Information About EoMPLS

- [AToM Overview, page 39-3](#)
- [EoMPLS Overview, page 39-3](#)

### AToM Overview

Any Transport over MPLS (AToM) transports Layer 2 packets over an MPLS backbone. AToM uses a directed Label Distribution Protocol (LDP) session between edge routers for setting up and maintaining connections. Forwarding occurs through the use of two level labels that provide switching between the edge routers. The external label (tunnel label) routes the packet over the MPLS backbone to the egress PE at the ingress PE. The VC label is a demuxing label that determines the connection at the tunnel endpoint (the particular egress interface on the egress PE as well as the VLAN identifier for an Ethernet frame).

### EoMPLS Overview

EoMPLS is one of the AToM transport types. EoMPLS works by encapsulating Ethernet PDUs in MPLS packets and forwarding them across the MPLS network. Each PDU is transported as a single packet. Cisco IOS Release 15.4SY supports two EoMPLS modes:

- VLAN mode—Transports Ethernet traffic from a source 802.1Q VLAN to a destination 802.1Q VLAN through a single VC over an MPLS network. VLAN mode uses VC type 5 as default (no dot1q tag) and VC type 4 (transport dot1 tag) if the remote PE does not support VC type 5 for subinterface (VLAN) based EoMPLS.
- Port mode—Allows all traffic on a port to share a single VC across an MPLS network. Port mode uses VC type 5.

**Note**

For both VLAN mode and port mode, EoMPLS in Cisco IOS Release 15.4SY does not allow local switching of packets between interfaces unless you use loopback interfaces.

LAN ports can receive Layer 2 traffic, impose labels, and switch the frames into the MPLS core.

## Default Settings for EoMPLS

None.

# How to Configure EoMPLS

- [Configuring VLAN-Based EoMPLS, page 39-4](#)
- [Configuring Port-Based EoMPLS, page 39-6](#)

## Configuring VLAN-Based EoMPLS

To configure VLAN-based EoMPLS, perform this task on the provider edge (PE) routers:

|        | Command                                                                                            | Purpose                                                                                                                                                                                                                                                                                                                   |
|--------|----------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt%<b>"eqphkiwtg"vgtokpcn</b>"</code>                                                    | Enters global configuration mode.                                                                                                                                                                                                                                                                                         |
| Step 2 | <code>Tqvwgt*eqphki+%"<b>kpvgtthceg"ikicdkvgvjgtpgv</b>"<br/>slot/interface.subinterface"</code>   | Specifies the Gigabit Ethernet subinterface. Make sure that the subinterface on the adjoining CE router is on the same VLAN as this PE router.                                                                                                                                                                            |
| Step 3 | <code>Tqvwgt*eqphki/kh+%"<b>gpecruwncvkqp"fqv3s"xncpakf</b>"</code>                                | Enables the subinterface to accept 802.1Q VLAN packets. <ul style="list-style-type: none"> <li>• The subinterfaces between the CE and PE routers that are running Ethernet over MPLS must be in the same subnet.</li> <li>• All other subinterfaces and backbone routers do not need to be on the same subnet.</li> </ul> |
| Step 4 | <code>Tqvwgt*eqphki/kh+%"<b>zeqppgev</b>"peer_router_id vcid<br/><b>gpecruwncvkqp"ornu</b>"</code> | Binds the attachment circuit to a pseudowire VC. The syntax for this command is the same as for all other Layer 2 transports.                                                                                                                                                                                             |

This is a VLAN-based EoMPLS configuration sample:

```
kpvgtthceg"IkicdkvGvjgtpgv91604
gpecruwncvkqp"fqv3S"5
zeqppgev"35035035035"5"gpecruwncvkqp"ornu
pq"ujwv
```



### Note

The IP address is configured on subinterfaces of the CE devices.

To verify and display the configuration of Layer 2 VLAN transport over MPLS tunnels, perform the following:

- To display a single line for each VLAN, naming the VLAN, status, and ports, enter the **show vlan brief** command.

```
Tqvwgt%"ujqy"xncp"dtkgh
```

```
XNCP"Pcog"Uvcvwu""Rgtvu
//////
3""fghcwnv""cevkxg""
4""XNCP2224""cevkxg""
5""XNCP2225""cevkxg""
3224"hffk/fghcwnv""cevlwpuwr"
3225"vqmgp/tpki/fghcwnv""cevlwpuwr"
3226"hffkpgv/fghcwnv""cevlwpuwr"
3227"vtpgv/fghcwnv""cevlwpuwr"
```

- To verify that the PE router endpoints have discovered each other, enter the **show mpls ldp discovery** command. When an PE router receives an LDP hello message from another PE router, it considers that router and the specified label space to be “discovered.”

```
Tqvwgt%ujqy"ornu"nfr"fkueqxt{
"Nqecn"NFR"Kfgpvkhkgt<
""35035035035<2
""Fkueqxt{"Uqwtegu<
""Kpvgthcegu<
""IG/YCP515"*nfr+<"zokvltgex
""NFR"Kf<"34034034034<2
""Vctigvgf"Jgnnqu<
""35035035035"/@"33033033033"*nfr+<"cevkxglrcuukxg."zokvltgex
""NFR"Kf<"33033033033<2
```

- To verify that the label distribution session has been established, enter the **show mpls ldp neighbor** command. The third line of the output shows that the state of the LDP session is operational and shows that messages are being sent and received.

```
Tqvwgt%ujqy"ornu"nfr"pgkijdt
""Rrgt"NFR"Kfgpv<"34034034034<2="Nqecn"NFR"Kfgpv"35035035035<2
""VER"eqppgevkqp<"340340340340868"/"35035035035033232
""Uvcvg<"Qrgt="Ouiu"ugpvltexf<"386;13862="Fqypvutgco
""Wr"vkog<"45<64<67
""NFR"fkueqxt{"uqwtegu<
""IG/YCP515."Ute"KR"cff<"56020204
""Cfftguugu"dqwpf"vq"rggt"NFR"Kfgpv<
""450403036""59020204""34034034034""56020204""
"";020203""
""Rrgt"NFR"Kfgpv<"33033033033<2="Nqecn"NFR"Kfgpv"35035035035<2
""VER"eqppgevkqp<"330330330330868"/"35035035035033235
""Uvcvg<"Qrgt="Ouiu"ugpvltexf<"387213875="Fqypvutgco
""Wr"vkog<"45<64<4;
""NFR"fkueqxt{"uqwtegu<
""Vctigvgf"Jgnnq"35035035035"/@"33033033033."cevkxg."rcuukxg
""Cfftguugu"dqwpf"vq"rggt"NFR"Kfgpv<
""33033033033""59020203""450403035"
```

- To verify that the label forwarding table is built correctly, enter the **show mpls forwarding-table** command to verify that a label has been learned for the remote PE and that the label is going from the correct interface to the correct next-hop.

```
Tqvwgt%ujqy"ornu"hqtyctfkpi/vcdng
Nqecn"Qwviqkpi""Rtghkz""D{vgu"vci"Qwviqkpi""Pgzv"Jqr""
vci""vci"qt"XE""qt"Vwppgn"Kf""uykvejgf""kpvgtthceg""
38""Wpvciihf""445047704760476154""^
""2""Ik413""45040203""
42""Wpvciihf""n4emv*4+""3552;5""Xn4""rqp4rqp""
43""Wpvciihf""n4emv*5+""3:76;9""Xn5""rqp4rqp""
46""Rqr"vci""590202021: ""2""IG515""56020204""
47""39""33033033033154""2""IG515""56020204""
48""Rqr"vci""34034034034154""2""IG515""56020204""
```

The output shows the following data:

- Local tag—Label assigned by this router.
- Outgoing tag or VC—Label assigned by next hop.
- Prefix or Tunnel Id—Address or tunnel to which packets with this label are going.
- Bytes tag switched—Number of bytes switched out with this incoming label.
- Outgoing interface—Interface through which packets with this label are sent.

- Next Hop—IP address of neighbor that assigned the outgoing label.
- To display the state of the currently routed VCs, enter the **show mpls l2transport vc** command.

```
Tqwgvt%"ujqy"ornu"n4vtcpurqtv"xe
```

```
Nqecn"kpvh" "" "Nqecn"ektewkv" "" "" "Fguv"cffftguu" "" "XE"KF" "" "" "Uvcvwu" "" ""
/////////" ///////////////" ///////////////" ///////////////" ///////////////
Xn4" "" "" "Gvj"XNCP"4" "" "" "" "33033033033" "" "" "4" "" "" "" "WR" "" "" ""
Xn5" "" "" "Gvj"XNCP"5" "" "" "" "33033033033" "" "" "5" "" "" "" "WR"
```

To display detailed information about each VC, add the keyword **detail**.

```
Tqwgvt%"ujqy"ornu"n4vtcpurqtv"xe"fgvckn
```

```
Nqecn"kpvgthceg<"Xn4"wr."nkpq"rtqvgeqn"wr."Gvj"XNCP"4"wr
" "Fguvkcpcvkqp"cffftguu<"33033033033."XE"KF<"4."XE"uvcvwu<"wr
" "" "Vwppgn"ncdgn<"39."pgzv"jqr"56020204
" "" "Qwvrvw"kpvgthceg<"IG515."korqugf"ncdgn"uvcem"}39"3;i
" "Etgcvg"vkog<"23<46<66."ncuv"uvcvwu"ejcpig"vkog<"22<32<77
" "Ukipcnkpi"rtqvgeqn<"NFR."rggt"33033033033<2"wr
" "" "ORNU"XE"ncdgnu<"nqecn"42."tgoqvg"3:
" "" "Itqwr"KF<"nqecn"93."tgoqvg":;
" "" "OVW<"nqecn"3722."tgoqvg"3722
" "" "Tgoqvg"kpvgthceg"fguetkrvkqp<"
" "Ugswgpekpi<"tgegkxg"fkucdnfg."ugpf"fkucdnfg
" "XE"uvcvkuvkeu<
" "" "rcemgv"vqvcnu<"tgegkxg"322;."ugpf"323;
" "" "d{vg"vqvcnu<" "tgegkxg"3552;5."ugpf"35:2;
" "" "rcemgv"ftqru<"tgegkxg"2."ugpf"2
```

```
Nqecn"kpvgthceg<"Xn5"wr."nkpq"rtqvgeqn"wr."Gvj"XNCP"5"wr
" "Fguvkcpcvkqp"cffftguu<"33033033033."XE"KF<"5."XE"uvcvwu<"wr
" "" "Vwppgn"ncdgn<"39."pgzv"jqr"56020204
" "" "Qwvrvw"kpvgthceg<"IG515."korqugf"ncdgn"uvcem"}39"3;i
" "Etgcvg"vkog<"23<46<5:."ncuv"uvcvwu"ejcpig"vkog<"22<32<77
" "Ukipcnkpi"rtqvgeqn<"NFR."rggt"33033033033<2"wr
" "" "ORNU"XE"ncdgnu<"nqecn"43."tgoqvg"3;
" "" "Itqwr"KF<"nqecn"94."tgoqvg";2
" "" "OVW<"nqecn"3722."tgoqvg"3722
" "" "Tgoqvg"kpvgthceg"fguetkrvkqp<"
" "Ugswgpekpi<"tgegkxg"fkucdnfg."ugpf"fkucdnfg
" "XE"uvcvkuvkeu<
" "" "rcemgv"vqvcnu<"tgegkxg"3628."ugpf"3636
" "" "d{vg"vqvcnu<" "tgegkxg"3:76;9."ugpf"3;3;39
" "" "rcemgv"ftqru<"tgegkxg"2."ugpf"2
```

## Configuring Port-Based EoMPLS

To support 802.1Q-in-802.1Q traffic and Ethernet traffic over EoMPLS in Cisco IOS Release 15.4SY, configure port-based EoMPLS by performing this task:

|        | Command                     | Purpose                           |
|--------|-----------------------------|-----------------------------------|
| Step 1 | Tqwgvt%"eqphkiwtg"vgtokpcn" | Enters global configuration mode. |



|        | Command                                                                                            | Purpose                                                                                                                                  |
|--------|----------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| Step 2 | <code>Tqwvgt*eqphki+%<b>"kpvgthceg"</b>ikicdkvgvjgtpgv"<br/>slot/interface"</code>                 | Specifies the Gigabit Ethernet interface. Make sure that the interface on the adjoining CE router is on the same VLAN as this PE router. |
| Step 3 | <code>Tqwvgt*eqphki/kh+%<b>"zeqppgev"</b>peer_router_id vcid<br/>gpecruwncvkqp<b>"ornu"</b></code> | Binds the attachment circuit to a pseudowire VC. The syntax for this command is the same as for all other Layer 2 transports.            |

The following is an example of a port-based configuration:

```
Tqwvgt%"ujqy"ornu"n4vtcpurqtv"xe"
```

```
Nqecn"kpvh""Nqecn"ektewkv""Fguv"cfftgau""XE"KF""Uvcvwu""
//////////////////////////
Ik:16:"Gvjgtpgv""970209:03""3""WR"
Ik913304222""Gvj"XNCP"4222""970209:03""4222""WR"
```

```
Tqwvgt%"ujqy"twp"kpvgthceg"ikicdkvgvjgtpgv":16:
Dwknfkpi"eqphkiwtcvkqp000
```

```
Ewtgtpv"eqphkiwtcvkqp"<:8"d{vgu

kpvgthceg"IkicdkvGvjgtpgv:16:
"pq"kr"cfftgau
"zeqppgev"970209:03"3"gpecruwncvkqp"ornu
gpf
```

```
Tqwvgt%"ujqy"twp"kpvgthceg"ikicdkvgvjgtpgv"9133
Dwknfkpi"eqphkiwtcvkqp000
```

```
Ewtgtpv"eqphkiwtcvkqp"<"33:"d{vgu

kpvgthceg"IkicdkvGvjgtpgv9133
"fguetkrvkqp"Vtchhke/Ipgtcvqt
"pq"kr"cfftgau
"ngiikpi"gxgpn"nkpm/uvvwu
"urggf"pqpgiqvkcvg
gpf
```

```
Tqwvgt%"ujqy"twp"kpvgthceg"ikicdkvgvjgtpgv"913304222
Dwknfkpi"eqphkiwtcvkqp000
```

```
Ewtgtpv"eqphkiwtcvkqp"<"334"d{vgu

kpvgthceg"IkicdkvGvjgtpgv913304222
"gpecruwncvkqp"fqv3S"4222
"zeqppgev"970209:03"4222"gpecruwncvkqp"ornu
gpf
```

```
Tqwvgt%"ujqy"ornu"n4vtcpurqtv"xe"3"fgvckn"
Nqecn"kpvgthceg<"Ik9169"wr."nkpj"rtqvgeq"wr."Gvjgtpgv"wr
"Fguvkcpcvkqp"cfftgau<"97020:203."XE"KF<"3."XE"uvvwu<"wr
""Vwppgn"ncdgn<"7926."pgzv"jqr"97020:503
""Qwvrvw"kpvgthceg<"Vg:15."korqugf"ncdgn"uvcem"}7926"3225:
"Etgcvg"vkog<"22<52<55."ncuv"uvvwu"ejcpig"vkog<"22<22<65
"Ukipcnkpi"rtqvgeq<"NFR."rggt"97020:203<2"wr
""ORNU"XE"ncdgnu<"nqecn"3279;."tgoqvg"3225:
""Itqwr"KF<"nqecn"377."tgoqvg"338
""OVW<"nqecn"3722."tgoqvg"3722
""Tgoqvg"kpvgthceg"fguetkrvkqp<"
""Ugswgpekpi<"tgegkxg"fkucdngf."ugpf"fkucdngf
```

```
"XE"uvcvkuvkeu<
""rcemgv"vqvcnu<"tgegkxg"48."ugpf"2
""d{vg"vqvcnu<""tgegkxg"35768."ugpf"2
""rcemgv"ftqru<""tgegkxg"2."ugpf"2
```

To display the VC type:

```
Tqwvgt%"tgoqvg"eqoocpf"uykvej"ujqy"ornu"n4vtcpurqtv"xe"3"fg
```

```
Nqecn"kpvgthceg<"IkicdkvGvjgtpgv9169."Gvjgtpgv
"Fguvkpcvkqp"cfftgau<"97020:203."XE"KF<"3
"XE"uvcvwu<"tgegkxg"WR."ugpf"FQYP
"XE"v{rg<"tgegkxg"7."ugpf"7
""Vwppgn"ncdgn<"pqv"tgcf{."fguvkpcvkqp"pqv"kp"NHKD
""Qwvrwv"kpvgthceg<"wmpqyp"."korqugf"ncdgn"uvcem"};
""ORNU"XE"ncdgn<"nqecn"3279;."tgoqvg"3225:
"Nkpgectf"XE"uvcvkuvkeu<
""rcemgv"vqvcnu<""tgegkxg<"2""ugpf<"2
""d{vg"vqvcnu<""tgegkxg<"2""ugpf<"2
""rcemgv"ftqru<""tgegkxg<"2""ugpf<"2
"Eqpvtqn"hnciu<
""tgegkxg"3."ugpf<"53
#
```

To verify and display the configuration of Layer 2 VLAN transport over MPLS tunnels, perform the following:

- To display a single line for each VLAN, naming the VLAN, status, and ports, enter the **show vlan brief** command.

```
Tqwvgt%"ujqy"xncp"dtkgh
```

```
XNCP"Pcog""""Uvcvwu""Rqtvu
//////
3""fghcwnv""cevkxg""
4""XNCP2224""cevkxg""Ik316
3224"hffk/fghcwnv""cevlwpuwr"
3225"vqmgp/tpki/fghcwnv""cevlwpuwr"
3226"hffkpgv/fghcwnv""cevlwpuwr"
3227"vtpgv/fghcwnv""cevlwpuwr"
```

- To verify that the PE router endpoints have discovered each other, enter the **show mpls ldp discovery** command. When a PE router receives an LDP Hello message from another PE router, it considers that router and the specified label space to be “discovered.”

```
Tqwvgt%"ujqy"ornu"nfr"fkueqxt{
"Nqecn"NFR"Kfgpvkhkgt<
""35035035035<2
""Fkueqxt{"Uqwtegu<
""Kpvgthcegu<
""IG/YCP515"*nfr+<"zokvltgex
""NFR"Kf<"34034034034<2
""Vctigvgf"Jgnnqu<
""35035035035"/@"33033033033"*nfr+<"cevkxglrcuukxg"."zokvltgex
""NFR"Kf<"33033033033<2
```

- To verify that the label distribution session has been established, enter the **show mpls ldp neighbor** command. The third line of the output shows that the state of the LDP session is operational and shows that messages are being sent and received.

```
Tqwvgt%"ujqy"ornu"nfr"pgkijdt
""Rggt"NFR"Kfgpv<"34034034034<2="Nqecn"NFR"Kfgpv"35035035035<2
""VER"eqppgevkqp<"340340340340868"/"35035035035033232
""Uvcvg<"Qrgt="Ouiu"ugpvltexf<"393713928="Fqypvgtgco
""Wr"vkog<"3f22j
```

```
" " " " "NFR"fkueqxt{"uqwtegu<
" " " " "IG/YCP515."Ute"KR"cfft"<"56020204
" " " " "Cffftguugu"dqwpf"vq"rggt"NFR"Kfgpv<
" " " " "450403036" " " " "59020204" " " " "34034034034" " " " "56020204" " " " " "
" " " " " ; , 020203" " " " " "
" " " "Rggt"NFR"Kfgpv"<"33033033033<2="Ngecn"NFR"Kfgpv"35035035035<2
" " " " "VER"eqppgevkqp<"330330330330868"/"35035035035033235
" " " " "Üvcvg<"Qrgt="Ouiu"ugpvItexf<"394613952="Fqypuvtgco
" " " " "Wr"vkog<"3f22j
" " " " "NFR"fkueqxt{"uqwtegu<
" " " " "Vctigvgf"Jgnnq"35035035035"/@"33033033033."cevkxg"."rcuukxg
" " " " "Cffftguugu"dqwpf"vq"rggt"NFR"Kfgpv<
" " " " "33033033033" " " " "59020203" " " " "450403035"
```

- To verify that the label forwarding table is built correctly, enter the **show mpls forwarding-table** command.

```
Tqwgvt%"ujqy"ornu"htqyctfkpi/vcdng
Nqecn"Qwviqkpi""Rtghkz""D{vgu"vci""Qwviqkpi""Pgzv"Jqr""vci""vci"qt"XE""qt"Vwppgn"Kf""uykvejgf""kpvgtchceg"
38""Wpvciigf""445047704760476154""^
"2""Ik413""45040203"
42""Wpvciigf""n4emv*4+""773687:2""Xn4""rqkpv4rqkpv"
46""Rqr"vci""590202021:""2""IG515""56020204"
47""39""33033033033154""2""IG515""56020204"
48""Rqr"vci""34034034034154""2""IG515""56020204"
```

- The output displays the following data:
  - Local tag—Label assigned by this router.
  - Outgoing tag or VC—Label assigned by next hop.
  - Prefix or Tunnel Id—Address or tunnel to which packets with this label are going.
  - Bytes tag switched— Number of bytes switched out with this incoming label.
  - Outgoing interface—Interface through which packets with this label are sent.
  - Next Hop—IP address of neighbor that assigned the outgoing label.
- To display the state of the currently routed VCs, enter the **show mpls l2transport vc** command:

```
Tqvwgt% "ujqy"ornu"n4vtcpurqtv"xe

Nqecn"kpvh"" "" "Nqecn"ektewkv"" "" "" "Fguv"cffftguu"" "" "XE"KF"" "" "" "Uvcvwu"" ""
//////////////////////////////////////
Xn4"" "" "" "" "Gvj"XNCP"4"" "" "" "" "" "33033033033"" "" "" "4"" "" "" "" "" "WR"
```



**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

Participate in the Technical Documentation Ideas forum





## Configuring A-VPLS

---

- [Prerequisites for A-VPLS, page 40-1](#)
- [Restrictions for A-VPLS, page 40-2](#)
- [Information About A-VPLS, page 40-2](#)
- [How to Configure A-VPLS, page 40-3](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
  - Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- 



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

---

## Prerequisites for A-VPLS

None.

## Restrictions for A-VPLS

- These are the supported configurations:
  - MPLS core with configuration of PE routers through the **neighbor** command under transport vpls mode.
  - MPLS core with configuration of PE routers through MPLS traffic engineering tunnels using explicit paths.
  - IP core with configuration of PE routers through MPLS over GRE tunnels.

Other configuration methods, including use of the **route-via** command, BGP autodiscovery, or explicit VLAN assignment to a PE egress port, are not supported.

- A-VPLS supports the following:
  - Up to 32 EtherChannel port-channel interfaces.
  - Up to 60 VPLS neighbors, minus the number of neighbors configured with the **load-balance flow** command.
- A-VPLS requires nonstop forwarding and stateful switchover.
- A-VPLS works with following:
  - MPLS Traffic Engineering tunnels that are configured with explicit paths.
  - Generic Routing Encapsulation (GRE tunnels) that are configured with static routes to the tunnel destination.

For information about MPLS traffic engineering and GRE tunnels, see the following documents:

- [MPLS Traffic Engineering and Enhancements](#)
- [Implementing Tunnels](#)
- The **ping** and **traceroute** commands that support the Any Transport over MPLS Virtual Circuit Connection Verification (VCCV) feature are not supported over FAT pseudowires.
- The VPLS Autodiscovery feature is not supported with A-VPLS.
- Load-balancing is not supported in the core routers when the core uses IP to transport packets.

## Information About A-VPLS

A-VPLS introduces the following enhancements to VPLS:

- Ability to load-balance traffic at the provider edge (PE) among multiple equal-cost core-facing paths and at core interfaces using flow labels.
- Support for redundant PE routers.

A-VPLS uses the Flow Aware Transport (FAT) Pseudowire feature to achieve PE redundancy and load-balancing on both PE and core routers. FAT pseudowires are used to load-balance traffic in the core when equal cost multipaths are used. The PE router adds an additional MPLS Label to the each packet (the flow label). Each flow has a unique flow label. For more information about FAT pseudowires, see PWE3 Internet-Draft [Flow Aware Transport of MPLS Pseudowires](#) (draft-bryant-filsfils-fat-pw).

**Note**

AToM Control-word is supported for Ethernet frames and C-bit is enabled by default in Supervisor Engine 2T, Supervisor Engine 6T, Catalyst 6880 and, Catalyst 6848x. It requires remote side is signaling (with C-bit =0) to disable control-word in the L2 binding.

## How to Configure A-VPLS

- [Enabling Load-Balancing with ECMP and FAT Pseudowires, page 40-3](#) (Required)
- [Enabling Port-Channel Load-Balancing, page 40-4](#) (Required)
- [Explicitly Specifying the PE Routers As Part of Virtual Ethernet Interface Configuration, page 40-4](#) (Optional)
- [Configuring an MPLS Traffic Engineering Tunnel, page 40-5](#) (Optional)
- [Configuring a GRE Tunnel, page 40-6](#) (Optional)

## Enabling Load-Balancing with ECMP and FAT Pseudowires

The following steps explain how to configure load-balancing on the provider edge (PE) routers, which enables it on the core P routers. No configuration is required on the core P routers.

To enable load-balancing on the edge routers, issue the **load-balance flow** command. The load-balancing rules are configured through the **port-channel load-balance** command parameters (see the [“Enabling Port-Channel Load-Balancing”](#) section on page 40-4).

To enable core load-balancing, issue the **flow-label enable** command on both PE routers. You must issue the **load-balance flow** command with the **flow-label enable** command.

|        | Command                                 | Purpose                                                                                                     |
|--------|-----------------------------------------|-------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqwvgt@"gpcdng"                         | Enables privileged EXEC mode (enter your password if prompted).                                             |
| Step 2 | Tqwvgt%"eqphkiwtg"vgtokpcn"             | Enters global configuration mode.                                                                           |
| Step 3 | Tqwvgt*eqphki+% "rugwfqyktg/encuu"pcog" | Establishes a pseudowire class with a name that you specify and enters pseudowire class configuration mode. |
| Step 4 | Tqwvgt*eqphki/ry+% "gpecruwncvkqp"ornu" | Specifies the MPLS tunneling encapsulation type.                                                            |
| Step 5 | Tqwvgt*eqphki/ry+% "nqcf/dncpeg"hnqy"   | Enables load-balancing on ECMPs.                                                                            |
| Step 6 | Tqwvgt*eqphki/ry+% "hnqy/ncdgn"gpcdng"  | Enables the imposition and disposition of flow labels for the pseudowire.                                   |
| Step 7 | Tqwvgt*eqphki/ry+% "gpf"                | Exits pseudowire class configuration mode and enters privileged EXEC mode.                                  |

## Enabling Port-Channel Load-Balancing

The following task explains how to enable port channel load-balancing, which sets the load-distribution method among the ports in the bundle. If the **port-channel load-balance** command is not configured, load-balancing occurs with default parameters.

|        | Command                                           | Purpose                                                             |
|--------|---------------------------------------------------|---------------------------------------------------------------------|
| Step 1 | Tqvwgt@"gpcdng"                                   | Enables privileged EXEC mode. Enter your password if prompted.      |
| Step 2 | Tqvwgt%"eqphkiwtg"vgtokpcn"                       | Enters global configuration mode.                                   |
| Step 3 | Tqvwgt*eqphki+%"rqtv/ejcppgn"nqcf/dcncepg"ogvjqf" | Specifies the load distribution method among the ports in a bundle. |
| Step 4 | Tqvwgt*eqphki+%"gzkv"                             | Exits global configuration mode and enters privileged EXEC mode.    |

## Explicitly Specifying the PE Routers As Part of Virtual Ethernet Interface Configuration

There are several ways to specify the route through which traffic should pass.

- Explicitly specify the PE routers as part of the virtual Ethernet interface configuration
- Configure an MPLS Traffic Engineering tunnel
- Configure a GRE tunnel

The following task explains how to explicitly specify the PE routers as part of the virtual Ethernet interface configuration.

|        | Command                                                                             | Purpose                                                                               |
|--------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Step 1 | Tqvwgt@"gpcdng"                                                                     | Enables privileged EXEC mode. Enter your password if prompted.                        |
| Step 2 | Tqvwgt%"eqphkiwtg"vgtokpcn"                                                         | Enters global configuration mode.                                                     |
| Step 3 | Tqvwgt*eqphki+%"kpvgtthceg"xktvwn/gvjgtpgv"pwo"                                     | Creates a virtual Ethernet interface and enters interface configuration mode.         |
| Step 4 | Tqvwgt*eqphki/kh+%"vtcpurqtv"xrn"oguj"                                              | Create a full mesh of pseudowires and enters VPLS transport mode.                     |
| Step 5 | Tqvwgt*eqphki/kh/vtcpurqtv+%"pgkijdqt"<br>remote-router-id]ry/encuu"ry/encuu/pcog_" | Specifies the PE routers to be used in the pseudowire.                                |
| Step 6 | Tqvwgt*eqphki/kh/vtcpurqtv+%"gzkv"                                                  | Exits VPLS transport configuration mode and enters interface configuration mode.      |
| Step 7 | Tqvwgt*eqphki/kh+%"uykvej rqtv"                                                     | Configures the port for Layer 2 switching.                                            |
| Step 8 | Tqvwgt*eqphki/kh+%"uykvej rqtv"oqfg"vtwpm"                                          | Enables permanent trunking mode and negotiates to convert the link into a trunk link. |



|         | Command                                                                                                                                             | Purpose                                                             |
|---------|-----------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------|
| Step 9  | <code>Tqwgvt*eqphki/kh+% "uykvej rqt v" vtwpm "cnnqygf" xncp"<br/>} cff " ~ "gzegrv" ~ "pqpg" ~ "tgoqgx;" xncp"<br/>] .xncp] .xncp] .000__ "</code> | Configures the list of VLANs allowed on the trunk.                  |
| Step 10 | <code>Tqwgvt*eqphki+% "gzkv"</code>                                                                                                                 | Exits interface configuration mode and enters privileged EXEC mode. |

## Configuring an MPLS Traffic Engineering Tunnel

There are several ways to specify the route through which traffic should pass.

- Explicitly specify the PE routers as part of the virtual Ethernet interface configuration
- Configure an MPLS Traffic Engineering tunnel
- Configure a GRE tunnel

The following task explains how to configure an MPLS Traffic Engineering tunnel. For more information about MPLS Traffic Engineering tunnels, see [MPLS Traffic Engineering and Enhancements](#).

|        | Command                                                                                                                                                                        | Purpose                                                                                                                                                                                                     |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt@"gpcdng"</code>                                                                                                                                                   | Enables privileged EXEC mode (enter your password if prompted).                                                                                                                                             |
| Step 2 | <code>Tqwgvt%"eqphkiwtg"vgtokpcn"</code>                                                                                                                                       | Enters global configuration mode.                                                                                                                                                                           |
| Step 3 | <code>Tqwgvt*eqphki+% "kpvgthceg"vwppgn"pwodgt"</code>                                                                                                                         | Configures an interface type and enters interface configuration mode.                                                                                                                                       |
| Step 4 | <code>Tqwgvt*eqphki/kh+% "kr"wpowodgtgf" type number"</code>                                                                                                                   | Assigns an IP address to the tunnel interface. An MPLS traffic engineering tunnel interface should be unnumbered because it represents a unidirectional link.                                               |
| Step 5 | <code>Tqwgvt*eqphki/kh+% "vwppgn"fguvkpcvkqp" ip-address"</code>                                                                                                               | Specifies the destination for a tunnel. The <i>ip-address</i> keyword is the IP address of the host destination expressed in dotted decimal notation.                                                       |
| Step 6 | <code>Tqwgvt*eqphki/kh+% "vwppgn"oqfg"ornu"vtchhke/gpi"</code>                                                                                                                 | Configures the tunnel encapsulation mode to MPLS traffic engineering.                                                                                                                                       |
| Step 7 | <code>Tqwgvt*eqphki/kh+% "vwppgn"ornu"vtchhke/gpi"<br/>cwvtqwgvg"cppqwgpeg"</code>                                                                                             | Configures the IGP to use the tunnel in its enhanced SPF calculation.                                                                                                                                       |
| Step 8 | <code>Tqwgvt*eqphki/kh+% "vwppgn"ornu"vtchhke/gpi"<br/>rcvj/qrvkqp"pwodgt" } f {pcoke" ~ "gzrnkekv" } pcog"<br/>path-name;" ~ "kfgpvkhkgt" path-number;" ] nqemfgyyp_ "</code> | Configures the tunnel to use a named IP explicit path or a path dynamically calculated from the traffic engineering topology database. A dynamic path is used if an explicit path is currently unavailable. |
| Step 9 | <code>Tqwgvt*eqphki/kh+% "gzkv"</code>                                                                                                                                         | Exits interface configuration mode and returns to privileged EXEC mode.                                                                                                                                     |

## Configuring a GRE Tunnel

There are several ways to specify the route through which traffic should pass.

- Explicitly specify the PE routers as part of the virtual Ethernet interface configuration
- Configure an MPLS Traffic Engineering tunnel
- Configure a GRE tunnel

The following task explains how to configure a GRE tunnel. For more information on GRE tunnels, see [Implementing Tunnels](#).

|        | Command                                                                                     | Purpose                                                                                                                                                                                                                                                                                                                                                                      |
|--------|---------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt@"gpcdng"</code>                                                                | Enables privileged EXEC mode. Enter your password if prompted.                                                                                                                                                                                                                                                                                                               |
| Step 2 | <code>Tqwgvt%"eqphkiwtg"vgtokpcn"</code>                                                    | Enters global configuration mode.                                                                                                                                                                                                                                                                                                                                            |
| Step 3 | <code>Tqwgvt*eqphki+%"kpvgtchceg" type number"</code>                                       | Specifies the interface type and number and enters interface configuration mode. To configure a tunnel, use <b>tunnel</b> for the type argument.                                                                                                                                                                                                                             |
| Step 4 | <code>Tqwgvt*eqphki/kh+%"vwppgn"oqfg"}itg"kr"~"itg"ownvkrqkpv;"</code>                      | Specifies the encapsulation protocol to be used in the tunnel.                                                                                                                                                                                                                                                                                                               |
| Step 5 | <code>Tqwgvt*eqphki/kh+%"ornu"kr"</code>                                                    | Enables MPLS on the tunnel.                                                                                                                                                                                                                                                                                                                                                  |
| Step 6 | <code>qwgvt*eqphki/kh+%"vwppgn"uqwtg"}ip-address"~"interface-type"interface-number;"</code> | Configures the tunnel source. <ul style="list-style-type: none"> <li>• Use the <i>ip-address</i> argument to specify the source IP address.</li> <li>• Use the <i>interface-type</i> and <i>interface-number</i> arguments to specify the interface to use.</li> </ul> <p><b>Note</b> The tunnel source and destination IP addresses must be defined on both PE routers.</p> |
| Step 7 | <code>Tqwgvt*eqphki/kh+%"vwppgn"fguvkcpcvkqp"}jqvpcog"~"ip-address;"</code>                 | Configures the tunnel destination. <ul style="list-style-type: none"> <li>• Use the <i>hostname</i> argument to specify the name of the host destination.</li> <li>• Use the <i>ip-address</i> argument to specify the IP address of the host destination.</li> </ul> <p><b>Note</b> The tunnel source and destination IP addresses must be defined on both PE routers.</p>  |
| Step 8 | <code>Tqwgvt*eqphki/kh+%"gzkv"</code>                                                       | Exits interface configuration mode and returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                      |
| Step 9 | <code>Tqwgvt*eqphki+%"kr"tqwgvg"ip-address"tunnel num"</code>                               | Creates a static route.                                                                                                                                                                                                                                                                                                                                                      |

These examples show the three supported methods of configuring A-VPLS.

### Explicitly Specifying Peer PE Routers

The following example shows how to create two VPLS domains under VLANs 10 and 20. Each VPLS domain includes two pseudowires to peer PE routers 10.2.2.2 and 10.3.3.3. Load-balancing is enabled through the **load-balance flow** and **flow-label enable** commands.

```

rugwfqyktg/encuu"en3"
" "gpecr"ornu"
 nqcf/dcnpeg"hnqy"
 hnqy/ncdgn"gpcdng"
#
rqtv/ejcppgn"nqcf/dcnpeg"ute/oce"
#
kpvgtgthceg"xktvwcg/gvjgtpgv"3
" "vtcpurqtv"xrnu"oguj
" " "pgkijdqt"32040404"ry/encuu"en3"
" " "pgkijdqt"32050505"ry/encuu"en3"
 uykvejrqtv
" "uykvejrqtv"oqfg"vtwpm
" "uykvejrqtv"vtwpm"cnnqygf"xncp"32."42

```

### Using MPLS Traffic Engineering Tunnels

The following example shows the creation of two VPLS domains and uses MPLS Traffic Engineering tunnels to specify the explicit path.

```

rugwfqyktg/encuu"en3"
" "gpecr"ornu"
 nqcf/dcnpeg"hnqy"
 hnqy/ncdgn"gpcdng"
#
rqtv/ejcppgn"nqcf/dcnpeg"ute/oce"
#
kpvgtgthceg"Vwppgn3
" "kr"wppwodgtgf"Nqqrdecem2
" "vwppgn"oqfg"ornu"vtchhke/gpi
" "vwppgn"fguvkpcvkqp"3;4038:0303
" "vwppgn"ornu"vtchhke/gpi"cwvtqwg"cppqwpeg
" "vwppgn"ornu"vtchhke/gpi"rcvj/qrvkqp"3"gzrnkekv"pcog"NUR3
#
kr"gzrnkekv/rcvj"pcog"NUR3"gpcdng
" "pgzv/cfftguu"3;4038:0404
" "pgzv/cfftguu"nqqug"3;4038:0303
#
kpvgtgthceg"Vwppgn4
" "kr"wppwodgtgf"Nqqrdecem2
" "vwppgn"oqfg"ornu"vtchhke/gpi
" "vwppgn"fguvkpcvkqp"3940380303
" "vwppgn"ornu"vtchhke/gpi"cwvtqwg"cppqwpeg
" "vwppgn"ornu"vtchhke/gpi"rcvj/qrvkqp"3"gzrnkekv"pcog"NUR4
#
kr"gzrnkekv/rcvj"pcog"NUR4"gpcdng
" "pgzv/cfftguu"3940380404
" "pgzv/cfftguu"nqqug"3940380303
#
kpvgtgthceg"xktvwcg/gvjgtpgv"3
 vtcpurqtv"xrnu"oguj"
" " "pgkijdqt"32040404"ry/encuu"en3"
" " "pgkijdqt"32050505"ry/encuu"en3"
 uykvejrqtv
" "uykvejrqtv"oqfg"vtwpm
 uykvejrqtv"vtwpm"cnnqygf"xncp"32.42

```

### Using MPLS over GRE Tunnels

The following example shows the creation of two VPLS domains under VLANs 10 and 20. Each VPLS domain includes two pseudowires to peer PEs 10.2.2.2 and 10.3.3.3. The pseudowires are MPLS over GRE tunnels because the core is IP.

```

rugwfqyktg/encuu"en3"
" " "gpecr"ornu
 nqcf/dcncepg"hnqy
#
rqtv/ejcppgn"nqcf/dcncepg"ute/oce"
#
kpvgtthceg"vwppgn"3
" " "vwppgn"oqfg"itg"kr
" " "ornu"kr"
" " "vwppgn"uqwtg"32030303
" " "vwppgn"fguvkpcvkqp"32040404
#
kpvgtthceg"vwppgn"4
" " "vwppgn"oqfg"itg"kr
" " "ornu"kr"
" " "vwppgn"uqwtg"32030303
" " "vwppgn"fguvkpcvkqp"32050505
#
kpvgtthceg"xktvwn/gvjgtpgv"3
 vtcpurqtv"xynu"oguj"
" " " "pgkijdt"32040404"ry/encuu"en3"
" " " "pgkijdt"32050505"ry/encuu"en3"
 uykvejrtv"
" " "uykvejrtv"oqfg"vtwpm
" " "uykvejrtv"vtwpm"cnnqygf"xncp"32. "42

kr"tqwvg"32040404"477047704770477"vwppgn3
kr"tqwvg"32050505"477047704770477"vwppgn4

```

## Routed Pseudo-Wire (RPW) and Routed VPLS

RPW and Routed VPLS can route Layer 3 traffic as well as switch Layer 2 frames for pseudowire connections between provider edge (PE) devices. Both point-to-point PE connections, in the form of Ethernet over MPLS (EoMPLS), and Virtual Private LAN Services (VPLS) multipoint PE connections are supported. The ability to route frames to and from these interfaces supports termination of a pseudowire into a Layer 3 network (VPN or global) on the same switch, or to tunnel Layer 3 frames over a Layer 2 tunnel (EoMPLS or VPLS). The feature supports faster network convergence in the event of a physical interface or device failure through the MPLS Traffic Engineering (MPLS-TE) and Fast Reroute (FRR) features. In particular, the feature enables MPLS TE-FRR protection for Layer 3 multicast over a VPLS domain.



#### Note

When the RPW is configured in A-VPLS mode, TE/FRR is not supported because A-VPLS runs over ECMP and the ECMP convergence is comparable to TE/FRR.

To configure routing support for the pseudowire, configure an IP address and other Layer 3 features for the Layer 3 domain (VPN or global) in the virtual LAN (VLAN) interface configuration. The following example assigns the IP address 10.10.10.1 to the VLAN 100 interface, and enables Multicast PIM. (Layer 2 forwarding is defined by the VFI VFI100.)

```
kpvgtgthceg"xncp"322"
 zeqppggev"xhk"XHK322"
 kr"cfftguu"3203203203"4770477047702"
 kr"rko"urctug/oqfg"
```

The following example assigns an IP address 20.20.20.1 of the VPN domain VFI200. (Layer 2 forwarding is defined by the VFI VFI200.)

```
kpvgtgthceg"xncp"422"
 zeqppggev"xhk"XHK422"
 kr"xth"hqtyctfkpi"XHK422"
 kr"cfftguu"4204204203"4770477047702"
```





## Ethernet Virtual Connections (EVCs)

---

- [Prerequisites for EVCs, page 41-1](#)
- [Restrictions for EVCs, page 41-2](#)
- [Information About EVCs, page 41-3](#)
- [Default Settings for EVCs, page 41-9](#)
- [How to Configure EVCs, page 41-10](#)
- [Monitoring EVCs, page 41-14](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
  - Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- 



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

---

## Prerequisites for EVCs

None.

## Restrictions for EVCs

- LACP EtherChannels and the 802.1ad provider-bridge mode are mutually exclusive. LACP EtherChannels cannot transmit traffic when the 802.1ad provider-bridge mode is enabled.
- Maximum EFPs per switch: 10K.
- Maximum EFPs per bridge domain: 124.
- Maximum EFPs per interface: 4K.
- Maximum bridge domains per switch: 4K.
- Bridge domain configuration is supported only as part of the EVC service instance configuration.
- EVC support requires the following:
  - The spanning tree mode must be MST.
  - The **dot1ad** global configuration mode command must be configured.
- Service instances can be configured only on ports configured to trunk unconditionally with the **switchport nonegotiate** command.
- You can configure PFC QoS to support EVC ports.
- IGMP snooping and MLD snooping must be disabled while configuring an EVC and 802.1ad in order to allow neighbour discovery messages and IPv6 traffic to pass through the device. Run the **no igmp snooping** and **no ipv6 mld snooping** commands in interface configuration mode or VLAN configuration mode for S-VLAN to disable snooping.
- These are the supported EVC features:
  - Service instances—You create, delete, and modify EFP service instances on Ethernet interfaces.
  - Ethernet service protection on EVCs:
    - Ethernet Operations, Administration, and Maintenance (EOAM)
    - Connectivity fault management (CFM)
    - Ethernet Local Management Interface (E-LMI)
  - IPv6 access control lists (ACLs).
  - Encapsulation—You can map traffic to EFPs based on 802.1Q VLANs (a single VLAN or a list or range of VLANs).
  - You can configure EFPs as members of a bridge domain.
  - Bridge domains support push symmetric only: the supported rewrite configuration implies egress pushing (adding a tag)
  - Bridge domains support ingress rewrite
  - EVC forwarding
  - MAC address learning and aging
  - EVCs on EtherChannels
  - EVC MAC address security
  - Bridging between switchports and EFPs
  - MSTP (MST on EVC bridge domain)
  - EFP statistics (packets and bytes)
  - QoS aware EVC/EFP per service instance



- These Layer 2 port-based features can run with EVC configured on a port:
  - PAGP
  - LACP
  - UDLD
  - LLDP
  - CDP
  - MSTP
- These features are not supported on EVCs:
  - Layer 2 multicast frame flooding
  - Layer 2 protocol tunneling
  - QinQ tagging
  - VLAN Translation
  - EoMPLS
  - Bridge domain routing
  - Split horizon
  - Service instance groups; also called Ethernet flow point (EFP) groups
  - IPv6 access control lists (ACLs)

## Information About EVCs

- [EVC Overview, page 41-3](#)
- [Ethernet Flow Points, page 41-4](#)
- [Service Instances and EFPs, page 41-4](#)
- [Encapsulation \(Flexible Service Mapping\), page 41-5](#)
- [EFPs and MSTP, page 41-7](#)
- [Bridge Domains, page 41-7](#)
- [Rewrite Operations, page 41-9](#)
- [Layer 3 and Layer 4 ACL Support, page 41-9](#)
- [Advanced Frame Manipulation, page 41-9](#)
- [Egress Frame Filtering, page 41-9](#)

## EVC Overview

Ethernet virtual circuits (EVCs) define a Layer 2 bridging architecture that supports Ethernet services. An EVC is defined by the Metro-Ethernet Forum (MEF) as an association between two or more user network interfaces that identifies a point-to-point or multipoint-to-multipoint path within the service provider network. An EVC is a conceptual service pipe within the service provider network. A bridge domain is a local broadcast domain that exists separately from VLANs.

## Ethernet Flow Points

An Ethernet flow point (EFP) service instance is a logical interface that connects a bridge domain to a physical port or to an EtherChannel. Configuring a service instance on a Layer 2 port creates a pseudoport or EFP on which you configure EVC features. Each service instance has a unique number per interface, but you can use the same number on different interfaces because service instances on different ports are not related.

An EFP classifies frames from the same physical port to one of the multiple service instances associated with that port, based on user-defined criteria. Each EFP can be associated with different forwarding actions and behavior.

The three major characteristics (or parameters) of an EFP are

- Encapsulation
- Rewrite Information
- Forwarding instance or method (bridge-domain or xconnect)

An EVC broadcast domain is determined by a bridge domain and the EFPs that are attached to it. An incoming frame is matched against EFP matching criteria on the interface, learned on the matching EFP, and forwarded to one or more EFPs in the bridge domain. If there are no matching EFPs, the frame is dropped.

You can use EFPs to configure VLAN translation. For example, if there are two EFPs egressing the same interface, each EFP can have a different VLAN rewrite operation, which is more flexible than the traditional switch port VLAN translation model.

When an EFP is created, the initial state is UP. The state changes to DOWN under the following circumstances:

- The EFP is explicitly shut down by a user.
- The main interface to which the EFP is associated is down or removed.
- If the EFP belongs to a bridge domain, the bridge domain is down.
- The EFP is forced down as an error-prevention measure of certain features.

## Service Instances and EFPs

Configuring a service instance on a Layer 2 port or EtherChannel creates a pseudoport or Ethernet flow point (EFP) on which you configure EVC features. Each service instance has a unique number per interface, but you can use the same number on different interfaces because service instances on different ports are not related.

If you have defined an EVC by entering the **ethernet evc *evc-id*** global configuration command, you can associate the EVC with the service instance (optional). There is no default behavior for a service instance. You can configure a service instance only on trunk ports with no allowed VLANs. Any other configuration is not allowed. After you have configured a service instance on an interface, switchport commands are not allowed on the interface. You can also configure a service instance on an EtherChannel group.

Use the **service instance number ethernet** [*name*] interface configuration command to create an EFP on a Layer 2 interface or EtherChannel and to enter service instance configuration mode. You use service instance configuration mode to configure all management and control data plane attributes and parameters that apply to the service instance on a per-interface basis.

- The **service instance number** is the EFP identifier, an integer from 1 to 4000.
- The optional **ethernet name** is the name of a previously configured EVC. You do not need to enter an EVC *name*, but you must enter **ethernet**. Different EFPs can share the same name when they correspond to the same EVC. EFPs are tied to a global EVC through the common name.

When you enter service instance configuration mode, you can configure these options:

- **default**—Sets a command to its defaults
- **description**—Adds a service instance specific description
- **encapsulation**—Configures Ethernet frame match criteria
- **errdisable**—Configures error disable
- **ethernet**—Configures Ethernet-lmi parameters
- **exit**—Exits from service instance configuration mode
- **l2protocol**—Configures Layer 2 control protocol processing
- **mac**—Commands for MAC address-based features
- **no**—Negates a command or sets its defaults
- **service-policy**—Attaches a policy-map to an EFP
- **shutdown**—Takes the service instance out of service

Enter the [**no**] **shutdown** service-instance configuration mode to shut down or bring up a service instance.

On a Layer 2 port with no service instance configured, multiple **switchport** commands are available (**access**, **backup**, **block**, **host**, **mode**, and **trunk**). When one or more service instances are configured on a Layer 2 port, no **switchport** commands are accepted on that interface.

## Encapsulation (Flexible Service Mapping)

Encapsulation defines the matching criteria that map any of these in any combination to a service instance:

- A VLAN
- A range of VLANs
- The class of service (CoS) bits
- The Ethertype

VLAN tags and CoS can be a single value, a range, or a list. Ethertype can be a single type or a list of types. These are the encapsulation types:

- default
- dot1q
- priority-tagged
- untagged

Priority-tagged frames are always single-tagged. All Ethernet traffic is supported. The encapsulation classification options are:

- inner tag CoS
- inner tag VLAN

When you configure an encapsulation method, you enable flexible service mapping, which allows you to map an incoming packet to an EFP based on the configured encapsulation.

The default behavior for flexible service mapping based on the outer 802.1q VLAN tag value is nonexact, meaning that when the EFP encapsulation configuration does not explicitly specify an inner (second) VLAN tag matching criterion, the software maps both single-tagged and double-tagged frames to the EFP as long as the frames fulfill the criteria of outer VLAN tag values. The command-line interface (CLI) does allow you to specify exact mapping with the **exact** keyword. If this keyword is specified, the EFP is designated as single-tagged-frame-only and double-tagged frames are not classified to that EFP.

Using the CLI **encapsulation** command in service-instance configuration mode, you can set encapsulation criteria. You must configure one encapsulation command per EFP (service instance). After you have configured an encapsulation method, these commands are available in service instance configuration mode:

- **bridge-domain**—Configures a bridge domain.
- **rewrite**—Configures Ethernet rewrite criteria.

**Table 41-1** Supported Encapsulation Types

| Command                                                                                          | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|--------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>encapsulation dot1q</b> { <b>any</b>   <i>vlan-id</i> [ <i>,vlan-id</i> [- <i>vlan-id</i> ]]} | <p>Defines the matching criteria to be used to map 802.1q frames ingressing on an interface to the appropriate EFP. The options are a single VLAN, a range of VLANs, or lists of VLANs or VLAN ranges. VLAN IDs are 1 to 4094.</p> <ul style="list-style-type: none"> <li>• Enter the <b>any</b> keyword to match or all VLANs (1-4094)</li> <li>• Enter a single VLAN ID for an exact match of the outermost tag.</li> <li>• Enter a VLAN range for a ranged outermost match.</li> </ul> |
| <b>encapsulation dot1q</b> <i>vlan-id</i> <b>cos</b> <i>cos-value</i>                            | <p>CoS value encapsulation defines match criteria after including the CoS for the C-Tag. The CoS value is a single digit between 1 and 7.</p> <p>You cannot configure CoS encapsulation with the <b>encapsulation untagged</b> command, but you can configure it with the <b>encapsulation priority-tagged</b> command. The result is an exact outermost VLAN and CoS match. You can also use VLAN ranges.</p>                                                                            |
| <b>encapsulation untagged</b>                                                                    | <p>Matching criteria to be used to map untagged Ethernet frames entering an interface to the appropriate EFP.</p> <p>Only one EFP per port can have untagged encapsulation. However, a port that hosts EFP matching untagged traffic can also host other EFPs that match tagged frames.</p> <p><b>Note</b> Not supported with the <b>encapsulation priority-tagged</b> command.</p>                                                                                                       |

Table 41-1 Supported Encapsulation Types (continued)

| Command                              | Description                                                                                                                                                                                                                                                                                                                   |
|--------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>encapsulation priority-tagged</b> | Specifies priority-tagged frames. A priority-tagged packet has VLAN ID 0 and a CoS value of 0 to 7.<br><br><b>Note</b> Not supported with the <b>encapsulation untagged</b> command.                                                                                                                                          |
| <b>encapsulation default</b>         | Configures the default EFP on a port, which matches all otherwise unmatched packets. If the default EFP is the only one configured on a port, it matches all ingress frames on that port.<br><br>If you configure the default EFP on a port, you cannot configure any other EFP on the same port with the same bridge domain. |

If a packet entering a port does not match any of the encapsulations on that port, the packet is dropped, resulting in filtering of the packet. The encapsulation must match the packet on the wire to determine filtering criteria. On the wire refers to packets ingressing the switch before any rewrites and to packets egressing the switch after all rewrites.

## EFPs and MSTP

EFP bridge domains are supported by the Multiple Spanning Tree Protocol (MSTP). These restrictions apply when running STP with bridge domains.

- All incoming VLANs (outer-most or single) mapped to a bridge domain must belong to the same MST instance or loops could occur.
- For all EFPs that are mapped to the same MST instance, you must configure backup EFPs on every redundant path to prevent loss of connectivity due to STP blocking a port.
- When STP mode is PVST+ or PVRST, EFP information is not passed to the protocol. EVC only supports only MSTP.
- Changing STP mode from MST to PVST+ or PVRST for a multicast port is not allowed.

## Bridge Domains

- [Bridge Domain Overview, page 41-7](#)
- [Ethernet MAC Address Learning, page 41-8](#)
- [Flooding of Layer 2 Frames for Unknown MAC and Broadcast Addresses, page 41-8](#)
- [Layer 2 Destination MAC Address-Based Forwarding, page 41-8](#)
- [MAC Address Aging, page 41-8](#)
- [MAC Address Table, page 41-8](#)

## Bridge Domain Overview

A bridge domain defines a broadcast domain internal to a platform and allows the decoupling of a broadcast domain from a VLAN. This decoupling enables per-port VLAN significance, thus removing the scalability limitations associated with a single per-device VLAN ID space. Frames received from one of the EFPs participating in a bridge domain matches are bridged.

A service instance must be attached to a bridge domain. Flooding and communication behavior of a bridge domain is similar to that of a VLAN domain. Bridge-domain membership is determined by which service instances have joined it (based on encapsulation criteria), while VLAN domain membership is determined by the VLAN tag in the packet.

**Note**

You must configure encapsulation before you can configure the bridge domain.

IGMP snooping is enabled by default on the switch and on all VLANs but is automatically disabled on a VLAN when you configure a bridge domain under 4094. The switches support up to 124 bridge domains.

## Ethernet MAC Address Learning

MAC address learning is always enabled and cannot be disabled.

## Flooding of Layer 2 Frames for Unknown MAC and Broadcast Addresses

A Layer 2 frame with an unknown unicast or broadcast destination MAC address is flooded to all the EFPs in the bridge domain except to the originating EFP.

Replication of frames involves recirculating the frame several times. Recirculation negatively affect forwarding performance and reduce the packet forwarding rate for all features.

## Layer 2 Destination MAC Address-Based Forwarding

When bridging is configured, a unicast frame received from an EFP is forwarded based on the destination Layer 2 MAC address. If the destination address is known, the frame is forwarded only to the EFP/NNI associated with the destination address.

Because the bridge and EFP configurations are interrelated, bridging is supported only on EFPs. To support multiple bridge domains, MAC address entries are associated with the bridge domain of the EFP. Only unicast MAC addresses need to be dynamically learned.

The EVC infrastructure does not modify frame contents.

## MAC Address Aging

The dynamically learned MAC address entries in the MAC table are periodically aged out and entries that are inactive for longer than the configured time period are removed from the table. The supported range of aging-time values, in seconds, is 5 through 1000000, with a granularity of 1. The default is 8 minutes. The **aging-time** parameter can be configured per bridge domain and is a relative value. The value is the aging time relative to the time a frame was received with that MAC address.

## MAC Address Table

The MAC address table is used to forward frames based on Layer 2 destination MAC addresses. The table consists of static MAC addresses downloaded from the route processor (RP) and the MAC addresses dynamically learned by the data path.

While the MAC Learning feature is enabled, an entry is added to the MAC table when a new unique MAC address is learned on the data path and an entry is deleted from the table when it is aged out.

## Rewrite Operations

The **rewrite** command pushes the 802.1ad tag onto ingress packets to forward the packet on the 802.1ad cloud.

Enter the **rewrite ingress tag push dot1ad *vlan-id* symmetric** service-instance configuration mode command to specify the encapsulation of additional dot1ad tag on the frame ingress to the EFP.



Note

The **symmetric** keyword is required to complete rewrite to configuration.

When you enter the **symmetric** keyword, the egress counterpart performs the inverse action and pushes (adds) the encapsulation VLAN.

## Layer 3 and Layer 4 ACL Support

Configuring an ACL on an EFP is the same as configuring an ACL on other types of interfaces.



Note

ACLs are not supported for packets prefixed with a Multiprotocol Label Switching (MPLS) header, including when an MPLS packet contains either Layer 3 or Layer 4 headers of supported protocols.

## Advanced Frame Manipulation

The Advanced Frame Manipulation feature supports a PUSH operation that adds one VLAN tag to both the incoming and outgoing frames of an EFP.

When a VLAN tag exists and a new one is added, the CoS field of the new tag is set to the same value as the CoS field of the existing VLAN tag; otherwise, the CoS field is set to a default of 0. Using QoS marking configuration commands, you can change the CoS marking.

## Egress Frame Filtering

Egress frame filtering is performed to ensure that frames exiting an EFP contain a Layer 2 header that matches the encapsulation characteristics associated with the EFP. This filtering is done primarily to prevent unintended frame leaks and is always enabled on EFPs.

## Default Settings for EVCs

None.

# How to Configure EVCs

Configuring a service instance on a Layer 2 port creates an EFP on which you can configure EVC features. Perform this task to configure an EFP.

|         | Command or Action                                                              | Purpose                                                                                                                                                                                                                                                                                                                                                                        |
|---------|--------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1  | Tqwgvt@"gpcdng"                                                                | Enables privileged EXEC mode. Enter your password if prompted.                                                                                                                                                                                                                                                                                                                 |
| Step 2  | Tqwgvt%"eqphkiwtg"vgtokpcn"                                                    | Enters global configuration mode.                                                                                                                                                                                                                                                                                                                                              |
| Step 3  | Tqwgvt*eqphki+%"fqv3cf"                                                        | Enables 802.1ad provider-bridge mode.<br><br><b>Note</b> LACP EtherChannels and the 802.1ad provider-bridge mode are mutually exclusive. LACP EtherChannels cannot transmit traffic when the 802.1ad provider-bridge mode is enabled.                                                                                                                                          |
| Step 4  | Tqwgvt*eqphki+%"kpvgtthceg" type number"                                       | Enters interface configuration mode.                                                                                                                                                                                                                                                                                                                                           |
| Step 5  | Tqwgvt*eqphki/kh+%"uykvejrqtv"                                                 | Configures the port for Layer 2 switching.<br><br><b>Note</b> You must enter the <b>switchport</b> command once without any keywords to configure the LAN port as a Layer 2 port before you can enter additional <b>switchport</b> commands with keywords.                                                                                                                     |
| Step 6  | Tqwgvt*eqphki/kh+%"uykvejrqtv"oqfg"vtwpm"                                      | Configures the port to trunk unconditionally.                                                                                                                                                                                                                                                                                                                                  |
| Step 7  | Tqwgvt*eqphki/kh+%"uykvejrqtv"pqpgiqvkcvq"                                     | Configures the trunk not to use DTP.                                                                                                                                                                                                                                                                                                                                           |
| Step 8  | Tqwgvt*eqphki/kh+%"uykvejrqtv"vtwpm" gpecruwncvkqp"fqv3s"                      | Configures the trunk encapsulation as 802.1Q.                                                                                                                                                                                                                                                                                                                                  |
| Step 9  | Tqwgvt*eqphki/kh+%"uykvejrqtv"vtwpm"cnnqygf" xncp"xncp"] .xncp] .xncp] .000__" | Configures the list of VLANs allowed on the trunk.<br><br><b>Note</b> If VLAN locking is enabled, enter VLAN names instead of VLAN numbers. For more information, see the “VLAN Locking” section on page 26-4.                                                                                                                                                                 |
| Step 10 | Tqwgvt*eqphki/kh+%"fqv3cf"wpk"                                                 | Configures the port as an 802.1ad provider-bridge user-to-network interface (UNI) port.<br><br><b>Note</b> The <b>dot1ad uni</b> interface mode command imposes some <a href="#">SPAN restrictions</a> (see “Feature Incompatibilities” section on page 56-2).                                                                                                                 |
| Step 11 | Tqwgvt*eqphki/kh+%"pq"efr"gpcdng"                                              | Disables CPD on the port.                                                                                                                                                                                                                                                                                                                                                      |
| Step 12 | Tqwgvt*eqphki/kh+%"pq"nnfr"vtcpuokv"                                           | (Required on PE ports) Disables LLDP.                                                                                                                                                                                                                                                                                                                                          |
| Step 13 | Tqwgvt*eqphki/kh+%"urcppkpi/vtgg"drfwhknvgt" gpcdng"                           | Enables BPDU filtering on the port.                                                                                                                                                                                                                                                                                                                                            |
| Step 14 | Tqwgvt*eqphki/kh+%"ugtckeg"kpucvpeg"pwodgt" gvjgtpgv"]pcog_                    | Configures an Ethernet service instance (EFP) and enters service instance configuration mode.<br><br><ul style="list-style-type: none"> <li>The <i>number</i> is the EFP identifier, an integer from 1 through 4000.</li> <li>(Optional) <b>ethernet name</b> is the name of a previously configured EVC. You do not need to use an EVC name in a service instance.</li> </ul> |



|         | Command or Action                                                                                             | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------|---------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 15 | <code>Tqvwgt*eqphki/kh+% "kr"ceeguu/itqwr"<br/>access-list-number"~"access-list-name;"<br/>}kp ~ qvv;"</code> | (Optional) Applies an IP access list or object group access control list (OGACL) to an interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Step 16 | <code>Tqvwgt*eqphki/kh/utx+% "gpecruwncvkqp"<br/>encapsulation-type"vlan-id"] equ"equaxcnwg_"</code>          | Configures the encapsulation type for the service instance. <ul style="list-style-type: none"> <li><b>default</b>—Configures matching for all otherwise unmatched packets.</li> <li><b>dot1q</b>—Configures 802.1Q encapsulation. See <a href="#">Table 41-1</a> for more information.</li> <li><b>priority-tagged</b>—Specify priority-tagged frames, VLAN-ID 0 and CoS value of 0 to 7.</li> <li><b>untagged</b>—Map to untagged VLANs. Only one EFP per port can have untagged encapsulation.</li> <li>The CoS value defines match criterion, an integer from 1 through 7.</li> </ul> |
| Step 17 | <code>Tqvwgt*eqphki/kh/utx+% "tgytkvg"kpitguu"vci"rwuj"<br/>fqv3cf"vlan-id"] u{oogvtke_"</code>               | (Optional) Specifies the encapsulation adjustment to be performed on a frame ingressing a service instance.                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Step 18 | <code>Tqvwgt*eqphki/kh/utx+% "dtkfig/fqockp"bridge-id"</code>                                                 | Configures the bridge domain.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Step 19 | <code>Tqvwgt*eqphki/kh/utx+% "gpf"</code>                                                                     | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

### Configuring Multiple Service Instances

```
Tqvwgt*eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv313 "
Tqvwgt*eqphki/kh+% "uykvejrgtv"oqfg"vtwpm"
Tqvwgt*eqphki/kh+% "uykvejrgtv"ppggiqvkcvg"
Tqvwgt*eqphki/kh+% "ugtckeg"kpucvpeg"3"gvjgtpgv"gx3 "
Tqvwgt*eqphki/kh/utx+% "gpecruwncvkqp"fqv3s"423"equ"3 "
Tqvwgt*eqphki/kh/utx+% "tgytkvg"kpitguu"vci"rwuj"fqv3cf"522"u{oogvtke"
Tqvwgt*eqphki/kh/utx+% "dtkfig/fqockp"522 "
Tqvwgt*eqphki/kh/utx+% "gpf"
Tqvwgt*eqphki/kh+% "ugtckeg"kpucvpeg"4"gvjgtpgv"gx4 "
Tqvwgt*eqphki/kh/utx+% "gpecruwncvkqp"fgncwnv"
Tqvwgt*eqphki/kh/utx+% "tgytkvg"kpitguu"vci"rwuj"fqv3cf"523"u{oogvtke"
Tqvwgt*eqphki/kh/utx+% "dtkfig/fqockp"523 "
Tqvwgt*eqphki/kh/utx+% "gpf"
Tqvwgt*eqphki/kh+% "ugtckeg"kpucvpeg"5"gvjgtpgv"gx5 "
Tqvwgt*eqphki/kh/utx+% "gpecruwncvkqp"rtkqtkv{/vciigf"equ"3 "
Tqvwgt*eqphki/kh/utx+% "tgytkvg"kpitguu"vci"rwuj"fqv3cf"524"u{oogvtke"
Tqvwgt*eqphki/kh/utx+% "dtkfig/fqockp"524 "
```

### Configuring a Service Instance

```
Tqvwgt*eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv313 "
Tqvwgt*eqphki/kh+% "uykvejrgtv"oqfg"vtwpm"
Tqvwgt*eqphki/kh+% "uykvejrgtv"ppggiqvkcvg"
Tqvwgt*eqphki/kh+% "uykvejrgtv"vtwpm"cnngygf"xncp"ppg"
Tqvwgt*eqphki/kh+% "ugtckeg"kpucvpeg"44"gvjgtpgv"gx3 "
Tqvwgt*eqphki/kh/utx+% "gpecruwncvkqp"fqv3s"322 "
Tqvwgt*eqphki/kh/utx+% "tgytkvg"kpitguu"vci"rwuj"fqv3cf"32"u{oogvtke"
Tqvwgt*eqphki/kh/utx+% "dtkfig/fqockp"32 "
```

### Encapsulation Using a VLAN Range

```
Tqvwgt*eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv313 "
Tqvwgt*eqphki/kh+% "ugtckeg"kpucvpeg"3"gvjgtpgv"
Tqvwgt*eqphki/kh/utx+% "gpecruwncvkqp"fqv3s"44/66"equ"3 "
```

```
Tqwgvt*eqphki/kh/utx+%tgytkvg"kpitguu"vci"rwuj"fqv3cf"32"u{oogvtke"
Tqwgvt*eqphki/kh/utx+%dtkfig/fqockp"32"
```

## Two Service Instances Joining the Same Bridge Domain

In this example, service instance 1 on interfaces Gigabit Ethernet 1/1 and 1/2 can bridge between each other.

```
Tqwgvt*eqphki+%kpvgtthceg"ikicdkvgvjgtpgv313"
Tqwgvt*eqphki/kh+%ugtckeg"kpucpeg"3"Gvjgtpgv"
Tqwgvt*eqphki/kh/utx+%gpecruwncvkqp"fqv3s"32"
Tqwgvt*eqphki/kh/utx+%tgytkvg"kpitguu"vci"rwuj"fqv3cf"32"u{oogvtke"
Tqwgvt*eqphki/kh/utx+%dtkfig/fqockp"32"
```

```
Tqwgvt*eqphki+%kpvgtthceg"ikicdkvgvjgtpgv314"
Tqwgvt*eqphki/kh+%ugtckeg"kpucpeg"3"Gvjgtpgv"
Tqwgvt*eqphki/kh/utx+%gpecruwncvkqp"fqv3s"32"
Tqwgvt*eqphki/kh/utx+%tgytkvg"kpitguu"vci"rwuj"fqv3cf"32"u{oogvtke"
Tqwgvt*eqphki/kh/utx+%dtkfig/fqockp"32"
```

## Bridge Domains and VLAN Encapsulation

Use the VLAN ID configured with the **rewrite ingress tag push dot1ad** command as the bridge-domain number, rather than the VLAN ID configured with the **encapsulation dot1q** command, which can be the same or a different value.

```
Tqwgvt*eqphki+%kpvgtthceg"ikicdkvgvjgtpgv313"
Tqwgvt*eqphki/kh+%ugtckeg"kpucpeg"3"gvjgtpgv"gx3"
Tqwgvt*eqphki/kh/utx+%gpecruwncvkqp"fqv3s"32"
Tqwgvt*eqphki/kh/utx+%tgytkvg"kpitguu"vci"rwuj"fqv3cf"6222"u{oogvtke"
Tqwgvt*eqphki/kh/utx+%dtkfig/fqockp"6222"
```

```
Tqwgvt*eqphki+%kpvgtthceg"ikicdkvgvjgtpgv314"
Tqwgvt*eqphki/kh+%ugtckeg"kpucpeg"3"gvjgtpgv"gx3"
Tqwgvt*eqphki/kh/utx+%gpecruwncvkqp"fqv3s"32"
Tqwgvt*eqphki/kh/utx+%tgytkvg"kpitguu"vci"rwuj"fqv3cf"6222"u{oogvtke"
Tqwgvt*eqphki/kh/utx+%dtkfig/fqockp"6222"
```

Traffic cannot be forwarded if the the VLAN ID configured with the **encapsulation dot1q** commands do not match in a bridge domain. In this example, the service instances on Gigabit Ethernet 1/1 and 1/2 cannot forward between each other, because the encapsulation VLAN IDs do not match (filtering criteria). You can use the **rewrite** command to allow communication between these two.

```
Tqwgvt*eqphki+%kpvgtthceg"ikicdkvgvjgtpgv313"
Tqwgvt*eqphki/kh+%ugtckeg"kpucpeg"3"gvjgtpgv"gx3"
Tqwgvt*eqphki/kh/utx+%gpecruwncvkqp"fqv3s"32"
Tqwgvt*eqphki/kh/utx+%tgytkvg"kpitguu"vci"rwuj"fqv3cf"6222"u{oogvtke"
Tqwgvt*eqphki/kh/utx+%dtkfig/fqockp"6222"
```

```
Tqwgvt*eqphki+%kpvgtthceg"ikicdkvgvjgtpgv314"
Tqwgvt*eqphki/kh+%ugtckeg"kpucpeg"3"gvjgtpgv"gx3"
Tqwgvt*eqphki/kh/utx+%gpecruwncvkqp"fqv3s";;"
Tqwgvt*eqphki/kh/utx+%tgytkvg"kpitguu"vci"rwuj"fqv3cf"6222"u{oogvtke"
Tqwgvt*eqphki/kh/utx+%dtkfig/fqockp"6222"
```

## Rewrite

In this example, the VLAN ID configured in the **rewrite ingress tag push dot1ad** command (4000 in the example) is pushed onto packets that match the VLAN ID configured in the **encapsulation dot1q** command (10 in the example). The symmetric keyword enables the inverse action on packets in the reverse direction: packets that egress from this service instance with VLAN ID 4000 are deencapsulated, resulting in VLAN ID 10 with cos 1.

```
Tqvwgt*eqphki+%"kpvgt

hceg"ikicdkvgvjgtpgv313"

Tqvwgt*eqphki/kh+%"ugt

xkeg"kpuncpeg"3"gvjgtpgv"

Tqvwgt*eqphki/kh/utx+%"gpecruwncvkqp"fqv3s"32"equ"3"
Tqvwgt*eqphki/kh/utx+%"tgytkvg"kpitguu"vci"rwuj"fqv3cf"6222"u{oogvtke"
Tqvwgt*eqphki/kh/utx+%"dtkfig/fqockp"6222"
```

# Monitoring EVCs

Table 41-2 Supported show Commands

| Command                                                                                                                             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>ujqy"gvjgtpgv"ugtckeg"gx"kf"evc-id ~"kpvgtcheg"knterface-id_"fgvckn_</code>                                                   | Displays information about all EVCs, or a specific EVC when you enter an EVC ID, or all EVCs on an interface when you enter an interface ID. The <b>detail</b> option provides additional information about the EVC.                                                                                                                                                                                                                                                                                                                                                                                       |
| <code>ujqy"gvjgtpgv"ugtckeg"kpuvcpeg" ]kf instance-id kpvgtcheg"knterface-id" ~"kpvgtcheg knterface-id_" }fgvckn_ ~ ]uvcvu_i</code> | Displays information about one or more service instance (EFPs). If you specify an EFP ID and interface, only data pertaining to that particular EFP is displayed. If you specify only an interface ID, data is displayed for all EFPs on the interface.                                                                                                                                                                                                                                                                                                                                                    |
| <code>ujqy"dtkfig/fqockp"]p_"</code>                                                                                                | When you enter <i>n</i> , this command displays all the members of the specified bridge-domain, if a bridge-domain with the specified number exists.<br><br>If you do not enter <i>n</i> , the command displays all the members of all bridge-domains in the system.                                                                                                                                                                                                                                                                                                                                       |
| <code>ujqy"gvjgtpgv"ugtckeg"kpuvcpeg"fgvckn"</code>                                                                                 | This command displays detailed service instance information, including Layer 2 protocol information. This is an example of the output:<br><br><b>Tqvwgt%ujqy"gvjgtpgv"ugtckeg"kpuvcpeg"fgvckn"</b><br>Ugtckeg"Kpuvcpeg"KF<"4<br>Cuuqekcvgf"Kpvgtcheg<"IkiCDkvGvjgtpgv914<br>Cuuqekcvgf"GXE<"gx4<br>N4rtqvgeqn"ftqr<br>EG/Xncpu<"<br>Gpecruwncvkqp<"fqv3s"4"xncp"rtqvgeqn"v{rg"2z:322<br>Tgytkvg<"kpitguu"vci"rwuj"fqv3cf"4"xncp/v{rg"2z::C:"u{oogvtke<br>Kpvgtcheg"Fqv3s"Vwppgn"Gvjgtv{rg<"2z:322<br>Uvcvg<"Wr<br>GHR"Uvcvkuvkeu<<br>" "Rmvu"Kp" "D{vgu"Kp" "Rmvu"Qwv" "D{vgu"Qwv<br>" " "2 " "2 " "2 " "2 |
| <code>ujqy"oce"cfftgau/vcdng"</code>                                                                                                | This command displays dynamically learned or statically configured MAC security addresses.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## Layer 2 over Multipoint GRE (L2omGRE)

---

- [Prerequisites for L2omGRE, page 42-1](#)
- [Restrictions for L2omGRE, page 42-2](#)
- [Information About L2omGRE, page 42-2](#)
- [Default Settings for L2omGRE, page 42-3](#)
- [How to Configure L2omGRE, page 42-3](#)
- [Verifying the L2omGRE Configuration, page 42-5](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
  - Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- 



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

---

## Prerequisites for L2omGRE

None.


## Restrictions for L2omGRE

- The L2omGRE feature is supported in VSS mode.
- The VLAN interface used to support L2omGRE cannot also be configured to support any Layer 3 features.
- You can configure QoS to police (rate limit) Layer 2 traffic that is flooded in a VLAN because it is addressed to a currently unlearned MAC-Layer destination address (see **match l2 miss** in the “Traffic Classification” section on page 63-2).

## Information About L2omGRE

The L2omGRE feature provides Layer 2 connectivity between multiple separate network sites by extending the topology of a Layer 2 broadcast domain through an mGRE tunnel (see [Figure 42-1](#)).

**Figure 42-1** L2omGRE Topology



330528

The L2omGRE feature associates a VLAN interface with an mGRE tunnel interface. mGRE tunnel interfaces configured to support the L2omGRE feature function like Layer 2 LAN ports to provide Layer 2 switching (bridging) for traffic of all types in the VLAN, so that the tunnel only carries traffic addressed to devices accessible through the mGRE tunnel (see the “[Information about Layer 2 Ethernet Switching](#)” section on page 21-2). The switch will learn MAC addresses that are accessible through mGRE tunnels and the **show mac address-table** command displays the learned addresses.

The PFC and any DFCs support bridging and mGRE tunnel encapsulation and decapsulation in hardware.

Each tunnel can carry multiple L2omGRE-connected VLANs. The tunnel encapsulation includes the VLAN ID. When the tunneled traffic is decapsulated, the VLAN ID in the tunneled traffic is used to select the correct VLAN for the traffic.

# Default Settings for L2omGRE

None.

## How to Configure L2omGRE

- [Configuring a Loopback Interface, page 42-3](#)
- [Configuring an mGRE Tunnel Interface, page 42-3](#)
- [Configuring a VLAN Interface, page 42-4](#)
- [L2omGRE Configuration Examples, page 42-5](#)

## Configuring a Loopback Interface

To configure a loopback interface to support L2omGRE, perform this task:

|        | Command or Action                           | Purpose                                                                                                                                    |
|--------|---------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqwvgt@"gpcdng"                             | Enables privileged EXEC mode. Enter your password if prompted.                                                                             |
| Step 2 | Tqwvgt%"eqphkiwtg"vgtokpcn"                 | Enters global configuration mode.                                                                                                          |
| Step 3 | Tqwvgt*eqphki+%"kpvgthceg"nqgrdcem"pwodgt"  | Creates the loopback interface and enters interface configuration mode.                                                                    |
| Step 4 | Tqwvgt*eqphki/kh+%"kr"cfftguu"address mask" | Configures an IP address on the interface.<br><br><b>Note</b> Tunnel interfaces on other switches refer to this IP address on this switch. |
| Step 5 | Tqwvgt*eqphki/kh+%"gpf"                     | Returns to global configuration mode.                                                                                                      |

## Configuring an mGRE Tunnel Interface

To configure an mGRE tunnel interface, perform this task:

|        | Command or Action                           | Purpose                                                                                                                                            |
|--------|---------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqwvgt*eqphki+%"kpvgthceg"vwppgn"pwodgt"    | Creates a tunnel interface and enters interface configuration mode.<br><br><b>Note</b> VLAN interfaces on this switch refer to this tunnel number. |
| Step 2 | Tqwvgt*eqphki/kh+%"kr"cfftguu"address mask" | Configures an IP address on the interface.                                                                                                         |

|        | Command or Action                                                                 | Purpose                                                                                                                                                                                                                                                                                                                                                                                               |
|--------|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 3 | <code>Tqwvgt*eqphki/kh+%"kr"pjtr"ocr" tunnel_address<br/>nqgrdcemacfftguu"</code> | Configures the IP-to-nonbroadcast multiaccess (NBMA) address mapping to the loopback interface IP addresses configured on the other switches with L2omGRE tunnel interfaces. <ul style="list-style-type: none"> <li>Enter the <i>tunnel_address loopback_address</i> values configured on the other L2omGRE switches.</li> <li>Repeat this command for each of the other L2omGRE switches.</li> </ul> |
| Step 4 | <code>Tqwvgt*eqphki/kh+%"kr"pjtr"pgvyqtm/kf" ID"</code>                           | Enables the Next Hop Resolution Protocol (NHRP) for the mGRE tunnels. Use the same ID value on all of the L2omGRE tunnel interfaces.                                                                                                                                                                                                                                                                  |
| Step 5 | <code>Tqwvgt*eqphki/kh+%"vwppgn"uqwtg"nqgrdcem" number"</code>                    | Associates this tunnel interface with the <a href="#">loopback interface</a> .                                                                                                                                                                                                                                                                                                                        |
| Step 6 | <code>Tqwvgt*eqphki/kh+%"vwppgn"oqfg"itg"ownvkrqkp"</code>                        | Configures multipoint GRE as the tunnel mode.                                                                                                                                                                                                                                                                                                                                                         |
| Step 7 | <code>Tqwvgt*eqphki/kh+%"gpf"</code>                                              | Returns to global configuration mode.                                                                                                                                                                                                                                                                                                                                                                 |

## Configuring a VLAN Interface

To configure a VLAN interface to support L2omGRE, perform this task:

|        | Command or Action                                                            | Purpose                                                             |
|--------|------------------------------------------------------------------------------|---------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%"kpvgtchceg"xncp"pwodgt"</code>                         | Creates the VLAN interface and enters interface configuration mode. |
| Step 2 | <code>Tqwvgt*eqphki/kh+%"pq"kr"cfftguu"</code>                               | Ensures that no IP address is configured on the interface.          |
| Step 3 | <code>Tqwvgt*eqphki/kh+%"rncvhtgo"zeqppgev"n4itg"<br/>vwppgn" number"</code> | Associates the VLAN interface with an L2omGRE tunnel interface.     |
| Step 4 | <code>Tqwvgt*eqphki/kh+%"gpf"</code>                                         | Returns to global configuration mode.                               |



## L2omGRE Configuration Examples

The L2omGRE configuration commands must be coordinated as follows:

- The **ip nhrp map** commands on each switch point to the tunnel and loopback IP addresses on each of the other switches.
- On each switch, the **tunnel source loopback** command points to the loopback interface configured on that switch.
- On each switch, the **platform xconnect l2gre tunnel** command points to the L2omGRE tunnel interface on that switch.

Enter the **show platform l2transport gre summary** command to display information about the L2omGRE configuration on a switch.

| Switch One                                                                                                                                                                                                                                                                                                                                                             | Switch Two                                                                                                                                                                                                                                                                                                                                                             | Switch Three                                                                                                                                                                                                                                                                                                                                                       |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <pre>kpvgtgthceg"nqgrdcem"3 "kr"cfftguu"32030303"477047704770477 kpvgtgthceg"vwppgn"32 "kr"cfftguu"3203203203"4770477047702 "pq"kr"tgfktgevu "kr"pjtr"ocr"3204204204"32040404 "kr"pjtr"ocr"3205205205"32050505 "kr"pjtr"pgvyqtm/kf"32 "vwppgn"uqwtg"nqgrdcem"3 "vwppgn"oqfg"itg"ownvkrqkpv kpvgtgthceg"xncp"32 "pq"kr"cfftguu "rncvhqto"zeqppgev"n4itg"vwppgn"32</pre> | <pre>kpvgtgthceg"nqgrdcem"3 "kr"cfftguu"32040404"477047704770477 kpvgtgthceg"vwppgn"32 "kr"cfftguu"3204204204"4770477047702 "pq"kr"tgfktgevu "kr"pjtr"ocr"3203203203"32030303 "kr"pjtr"ocr"3205205205"32050505 "kr"pjtr"pgvyqtm/kf"32 "vwppgn"uqwtg"nqgrdcem"3 "vwppgn"oqfg"itg"ownvkrqkpv kpvgtgthceg"xncp"32 "pq"kr"cfftguu "rncvhqto"zeqppgev"n4itg"vwppgn"32</pre> | <pre>kpvgtgthceg"nqgrdcem"3 "kr"cfftguu"32050505"477047704770477 kpvgtgthceg"vwppgn"32 "kr"cfftguu"3205205205"4770477047702 "pq"kr"tgfktgevu kr"pjtr"ocr"3203203203"32030303 kr"pjtr"ocr"3204204204"32040404 kr"pjtr"pgvyqtm/kf"32 "vwppgn"uqwtg"nqgrdcem3 "vwppgn"oqfg"itg"ownvkrqkpv kpvgtgthceg"xncp"32 "pq"kr"cfftguu "rncvhqto"zeqppgev"n4itg"vwppgn"32</pre> |

## Verifying the L2omGRE Configuration

Enter the **show platform l2transport gre** command to display information about L2omGRE, including traffic statistics.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





## Campus Fabric

---

Campus Fabric provides the basic infrastructure for building virtual networks based on policy-based segmentation constructs. Fabric Overlay provides services such as host mobility and enhanced security, which are additional to normal switching and routing capabilities.

Campus Fabric Overlay provisioning consists of three main components:

- Control-Plane
- Data-Plane
- Policy-Plane

## Understanding Fabric Domain Elements

The following section describes the elements that make up the fabric domain.

- **Fabric Edge Devices** — Provide connectivity to users and devices that connect to the fabric domain. Fabric edge devices identify and authenticate endpoints, and register endpoint ID information in the fabric host-tracking database. They encapsulate at ingress and decapsulate at egress, to forward traffic to and from endpoints connected to the fabric domain.
- **Fabric Control-Plane Devices** — Provide overlay reachability information and endpoints-to-routing-locator mapping, in the host-tracking database. The control-plane device receives registrations from fabric edge devices with local endpoints, and resolves requests from edge devices to locate remote endpoints.
- **Fabric Border Devices** — Connect traditional Layer 3 networks or different fabric domains to the local domain, and translate reachability and policy information, such as VRF and SGT information, from one domain to another.
- **Virtual Contexts** — Provide virtualization at the device level, using virtual routing and forwarding (VRF) to create multiple instances of Layer 3 routing tables. Contexts or VRFs provide segmentation across IP addresses, allowing for overlapped address space and traffic separation.
- **Host-Pools** — Group endpoints in the fabric domain into IP pools, and identify them with a VLAN ID and an IP subnet.

## Campus Fabric Licensing

This section describes command-line interface (CLI) commands for managing Campus Fabric licensing.

To activate licensing, use the following commands:

```
l pq_ "nkegpug" dqqv "ngxgn" cffqp "fpc/guugpvkcnu
l pq_ "nkegpug" dqqv "ngxgn" cffqp "fpc/cfxcpvcig
```

To accept end-user license agreement (EULA), use the following command:

```
l pq_ "nkegpug" ceegrv "gpf" wugt "citggogpv" hqteg
```

Example:

```
tqwgvt%uj "twp" ~ "k" nkegpug
nkegpug "dqqv" ngxgn "cffqp" fpc/cfxcpvcig
nkegpug "ceegrv" gpf "wugt" citggogpv "hqteg
tqwgvt%
```

## Example: Show commands for license right-to-use

All the examples listed in this section are based on the following configuration:

```
tqwgvt%uj "twp" ~ "k" nkegpug
nkegpug "dqqv" ngxgn "cffqp" fpc/cfxcpvcig
nkegpug "ceegrv" gpf "wugt" citggogpv "hqteg
tqwgvt%
```

### show license right-to-use

```
tqwgvt%uj "nkegpug" tkijv/vq/wug
unqv " " " " "Nkegpug" Pcog " " " " "V{rg " " " " "Rgtkqf" nghv
////////////////////////////////////
Cevkxg "uwr" " " "Cfxcpvgf" Gpvgtrtkug "Ugtxkegu" "rgtccpgpv" " " "Nkhgvmkog
Cevkxg "uwr" " " "fpc/cfxcpvcig" " " " " "Uwduetkrvkqp" "EUUO" Ocpicgf
Uvcpgfd{ "uwr" " " "Cfxcpvgf" Gpvgtrtkug "Ugtxkegu" "rgtccpgpv" " " "Nkhgvmkog
Uvcpgfd{ "uwr" " " "fpc/cfxcpvcig" " " " " "Uwduetkrvkqp" "EUUO" Ocpicgf
```

show license right-to-use default

```
tqwgvt%uj "nkegpug" tkijv/vq/wug "fghcwnv
unqv " " " " "Nkegpug" Pcog " " " " "V{rg
////////////////////////////////////
Cevkxg "uwr" " " "Cfxcpvgf" Gpvgtrtkug "Ugtxkegu" "rgtccpgpv
Uvcpgfd{ "uwr" " " "Cfxcpvgf" Gpvgtrtkug "Ugtxkegu" "rgtccpgpv
```

show license right-to-use detail

```
tqwgvt%uj "nkegpug" tkijv/vq/wug "fgvckn
Kpfgz" 3
" " "Nkegpug" Pcog " " " " "Cfxcpvgf" Gpvgtrtkug "Ugtxkegu
" "Rgtkqf" nghv " " " " "Nkhgvmkog
" "Nkegpug" V{rg " " " " "rgtccpgpv
" "Nkegpug" Uvcpg " " " " "Cevkxg . "Kp" wug

Kpfgz" 4
" " "Nkegpug" Pcog " " " " "fpc/guugpvkcnu
" "Rgtkqf" nghv " " " " "EUUO" Ocpicgf
" "Nkegpug" V{rg " " " " "Uwduetkrvkqp
```

" "Nkegpug"Uvcvg" " "&lt;"Pqv"Cevkxcvgf

Kpfgz"5  
 ""Nkegpug"Pcog""<"fpc/cfxcpvcig  
 ""Rgtkqf"nghv""<"EUUO"Ocp cigf  
 ""Nkegpug"V{rg""<"Uwduetkrvkqp  
 ""Nkegpug"Uvcvq""<"Cevkxq."Kp"wug

show license right-to-use summary

```
tqvwgt$uj"nkegpug"tkijv/vq/wug"uwooct{
Nkegpug"Pcoq"V"rg"Rgtkqf"nghv
////////////////////////////////////
Cfxcpegf"Gpvgrtkug"Ugtxkegu"rgtccpgpv""Nkhgwkog
fpc/cfxcpvcig"Uwduetkrvkqp"EUUO"Opcpigf
////////////////////////////////////

Nkegpug"Ngxgn"Kp"Wug<"Cfxcpegf"Gpvgrtkug"Ugtxkegu"cffqp<"fpc/cfxcpvcig
Nkeqpuq"Naxan"qp"Taqqav<"Cfxcpegf"Gpvgrtkug"Ugtxkegu"cffqp<"fpc/cfxcpvcig
```

show license right-to-use usage

```
tqwgvt%uj"nkegpug"tkijv/vq/wug"wucig
unqv""Nkegpug"Pcog""{rg""Kp/wug""GWNC
////////////////////////////////////
Cevkxg"uwr""Cfxcpegf"Gpvgttrtkug"Ugtxkegu""rgtocpgpv""{}gu""{}gu
Cevkxg"uwr""fpc/guugpvkcnu""Uwduetkrvkqp""pq""{}gu
Cevkxg"uwr""fpc/cfxcpvcig""Uwduetkrvkqp""gu""{}gu
////////////////////////////////////
Uvcpdf{"uwr""Cfxcpegf"Gpvgttrtkug"Ugtxkegu""rgtocpgpv""{}gu""{}gu
Uvcpdf{"uwr""fpc/guugpvkcnu""Uwduetkrvkqp""pq""{}gu
Uvcpdf{"uwr""fpc/cfxcpvcig""Uwduetkrvkqp""gu""{}gu
////////////////////////////////////
```

show license right-to-use eula

```
tqvwgt%uj"nkepgug"tkijv/vq/wug"gwnc"A
"rgtocpgpv" " " "Fkurnc{u"GWNC"hqt"rgtocpgpv"nkepgug0
"uwduetkrvkqp" "Fkurnc{u"GWNC"hqt"vjg"uwduetkrvkqp"nkepgug0
```

# Campus Fabric Configuration Guidelines

Consider the following guidelines and limitations when configuring campus fabric elements:

- Catalyst 6500 switch can act as a border router or control plane device.
- If RBACL enforcement is not done on the border router, then the user needs to configure SGT caching on the border and transport the SGT via SXP to a further upstream router.
- Configure no more than 512 virtual contexts for unicast and 100 virtual contexts for multicast, in each fabric border node.
- IPv6 layer 3 mobility is not supported.

# How to Configure Fabric Overlay

## Configuring Fabric Edge Devices

For detailed instructions, see this publication:

[http://www.cisco.com/c/en/us/td/docs/switches/lan/catalyst3850/software/release/16-3/configuration\\_guide/b\\_163\\_consolidated\\_3850\\_cg/b\\_163\\_consolidated\\_3850\\_cg\\_chapter\\_010100010.html](http://www.cisco.com/c/en/us/td/docs/switches/lan/catalyst3850/software/release/16-3/configuration_guide/b_163_consolidated_3850_cg/b_163_consolidated_3850_cg_chapter_010100010.html)

## Configuring Control-Plane Devices Using IPv4

To configure control-plane devices using IPv4, use the following LISP commands:

### Before You Begin

Configure a loopback IP address for the control-plane device to ensure that the device is reachable.

|        | Command                                                                                                                                                                                                                                                                                                 | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>gpcdng"<br/>Gzcorng&lt;<br/>Fgxkeg@"gpcdng</code>                                                                                                                                                                                                                                                 | Enables privileged EXEC mode. Enter your password if prompted.                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Step 2 | <code>eqphkiwtg"vgtokpcn"<br/>Gzcorng&lt;<br/>Fgxkeg%"eqphkiwtg"vgtokpcn</code>                                                                                                                                                                                                                         | Enters the global configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Step 3 | <code>tqwvgt"nkur"<br/>Gzcorng&lt;<br/>Fgxkeg*eqphki+%"tqwvgt"nkur</code>                                                                                                                                                                                                                               | Enters Locator ID/Separation Protocol (LISP) configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Step 4 | <code>ukvg"ukvg/pcog<br/>Gzcorng&lt;<br/>Fgxkeg*eqphki/tqwvgt/nkur+%"ukvg"HFaFghcwnv</code>                                                                                                                                                                                                             | Configures a LISP site on a control-plane device and enters LISP site configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Step 5 | <code>cwvjgppvkecvkqp/mg{"mg{<br/>Gzcorng&lt;<br/>Fgxkeg*eqphki/tqwvgt/nkur/ukvg+%"<br/>cwvjgppvkecvkqp/mg{"gzcorngmg{</code>                                                                                                                                                                           | Configures the password used to create the Hash-based Message Authentication Code (HMAC) Secure Hash Algorithm (SHA-1) hash for authenticating the map-register messages sent by edge devices when registering with the control-plane device.                                                                                                                                                                                                                                                                      |
| Step 6 | <code>gkf/rtghkz"kpuvcpeg/kf"&gt;xcnwg@"&gt;rtghkz@"<br/>ceegr/v/oqtg/urgehkeu<br/>Gzcorng&lt;<br/>Fgxkeg*eqphki/tqwvgt/nkur/ukvg+%"gkf/rtghkz"<br/>32030202138"ceegr/v/oqtg/urgehkeu<br/><br/>Fgxkeg*eqphki/tqwvgt/nkur/ukvg+%"gkf/rtghkz"<br/>kpuvcpeg/kf"32"32030202138"ceegr/v/oqtg/urgehkeu</code> | Configures a host-pool or a list of endpoint identifier (EID) prefixes that are allowed in a map-register message sent by the edge device when registering with the control-plane device. Specifies that an EID prefix that is more specific than the EID prefix configured is accepted and tracked. The instance-id keyword includes the specified instance ID (the instance ID used by the context you want to include in the host-pool) with the host-pool when it is registered with the control-plane device. |
| Step 7 | <code>gzkv<br/>Gzcorng&lt;<br/>Fgxkeg*eqphki/tqwvgt/nkur/ukvg+%"gzkv</code>                                                                                                                                                                                                                             | Exits LISP site configuration mode and returns to LISP configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                         |

|         | Command                                                                                          | Purpose                                                                                                                                                                |
|---------|--------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 8  | <code>Tgrgcv"Uvgr"6"vq"Uvgr"9"vq"eqphkiwtg"cpqvjgt"NKUR"ukvg0"</code>                            |                                                                                                                                                                        |
| Step 9  | <code>krx6"ocr/ugtugt<br/>Gzcorng&lt;<br/>Fgxkeg*eqphki/tqvwgt/nkur+%"krx6"ocr/ugtugt</code>     | Configures a device to act as an IPv4 control-plane device.                                                                                                            |
| Step 10 | <code>krx6"ocr/tguqnxgt<br/>Gzcorng&lt;<br/>Fgxkeg*eqphki/tqvwgt/nkur+%"krx6"ocr/tguqnxgt</code> | In the fabric domain, the control-plane device acts as the map-server and the map-resolver. Enables the control-plane device with IPv4 LISP map resolver capabilities. |
| Step 11 | <code>gpf<br/>Gzcorng&lt;<br/>Fgxkeg*eqphki/tqvwgt/nkur+%"gpf</code>                             | Exits LISP configuration mode and returns to privileged EXEC mode.                                                                                                     |

## Configuring Control-Plane Devices Using IPv6

To configure control-plane devices using IPv6, use the following LISP commands:

### Before You Begin

Configure a loopback IP address for the control-plane device to ensure that the device is reachable.

|        | Command                                                                                                                     | Purpose                                                                                                                                                                                                                                       |
|--------|-----------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>gpcdng"<br/>Gzcorng&lt;<br/>Fgxkeg@"gpcdng</code>                                                                     | Enables privileged EXEC mode. Enter your password if prompted.                                                                                                                                                                                |
| Step 2 | <code>eqphkiwtg"vgtokpcn"<br/>Gzcorng&lt;<br/>Fgxkeg%"eqphkiwtg"vgtokpcn</code>                                             | Enters the global configuration mode.                                                                                                                                                                                                         |
| Step 3 | <code>tqvwgt"nkur"<br/>Gzcorng&lt;<br/>Fgxkeg*eqphki+%"tqvwgt"nkur</code>                                                   | Enters Locator ID/Separation Protocol (LISP) configuration mode.                                                                                                                                                                              |
| Step 4 | <code>ukvg"ukvg/pcog<br/>Gzcorng&lt;<br/>Fgxkeg*eqphki/tqvwgt/nkur+%"ukvg"HFaFghcwnv</code>                                 | Configures a LISP site on a control-plane device and enters LISP site configuration mode.                                                                                                                                                     |
| Step 5 | <code>cwvjgpvkecvkqp/mg{"mg{<br/>Gzcorng&lt;<br/>Fgxkeg*eqphki/tqvwgt/nkur/ukvg+%"<br/>cwvjgpvkecvkqp/mg{"gzcorngmg{</code> | Configures the password used to create the Hash-based Message Authentication Code (HMAC) Secure Hash Algorithm (SHA-1) hash for authenticating the map-register messages sent by edge devices when registering with the control-plane device. |

|         | Command                                                                                                                                                                                                                | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|---------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 6  | <pre>gkf/rtghkz"kpuvcepg/kf"&gt;xcnwg@&gt;krx8artghkz@ Gzcorng&lt; Fgxkeg*eqphki/tqvwgt/nkur/ukvg+%gkf/rtghkz" 32&lt;3&lt;&lt;186  Fgxkeg*eqphki/tqvwgt/nkur/ukvg+%gkf/rtghkz" kpuvcepg/kf"32"32&lt;3&lt;&lt;186</pre> | Configures a host-pool or a list of endpoint identifier (EID) prefixes that are allowed in a map-register message sent by the edge device when registering with the control-plane device. Specifies that an EID prefix that is more specific than the EID prefix configured is accepted and tracked. The instance-id keyword includes the specified instance ID (the instance ID used by the context you want to include in the host-pool) with the host-pool when it is registered with the control-plane device. |
| Step 7  | <pre>gzkv Gzcorng&lt; Fgxkeg*eqphki/tqvwgt/nkur/ukvg+%gzkv</pre>                                                                                                                                                       | Exits LISP site configuration mode and returns to LISP configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Step 8  | <pre>Tgrgcv"Uvgr"6"vq"Uvgr"9"vq"eqphkiwtg"cpqvjgt"NKUR" ukvg0"</pre>                                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Step 9  | <pre>krx8"ocr/ugtugt Gzcorng&lt; Fgxkeg*eqphki/tqvwgt/nkur+%krx8"ocr/ugtugt</pre>                                                                                                                                      | Configures a device to act as an IPv6 control-plane device.                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Step 10 | <pre>krx8"ocr/tguqnxgt Gzcorng&lt; Fgxkeg*eqphki/tqvwgt/nkur+%krx8"ocr/tguqnxgt</pre>                                                                                                                                  | In the fabric domain, the control-plane device acts as the map-server and the map-resolver. Enables the control-plane device with IPv6 LISP map resolver capabilities.                                                                                                                                                                                                                                                                                                                                             |
| Step 11 | <pre>gpf Gzcorng&lt; Fgxkeg*eqphki/tqvwgt/nkur+%gpf</pre>                                                                                                                                                              | Exits LISP configuration mode and returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

## Configuring Border Devices Using IPv4

To configure a border device using IPv4, use the following LISP commands.

### Before You Begin

Configure a loopback IP address for the border device to ensure that the device is reachable.

|        | Command                                                               | Purpose                                                        |
|--------|-----------------------------------------------------------------------|----------------------------------------------------------------|
| Step 1 | <pre>gpcdng" Gzcorng&lt; Fgxkeg@"gpcdng</pre>                         | Enables privileged EXEC mode. Enter your password if prompted. |
| Step 2 | <pre>eqphkiwtg"vgtokpcn" Gzcorng&lt; Fgxkeg%"eqphkiwtg"vgtokpcn</pre> | Enters the global configuration mode.                          |
| Step 3 | <pre>tqvwgt"nkur" Gzcorng&lt; Fgxkeg*eqphki+%tqvwgt"nkur</pre>        | Enters LISP configuration mode.                                |



|         | Command                                                                                                                                 | Purpose                                                                                                                                                                                                                                                                                |
|---------|-----------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 4  | <pre>gpecruwncvkqp"xnzncp Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%gpecruwncvkqp"xnzncp</pre>                                             | Specifies VXLAN-based encapsulation.                                                                                                                                                                                                                                                   |
| Step 5  | <pre>gkf/vcdng"xth"&gt;xthapcog@"kpuvcpeg/kf"&gt;xcnwg@ Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%gkf/vcdng"xth"cdef" kpuvcpeg/kf"32</pre> | Associates the non-default EID table with the specified instance ID.                                                                                                                                                                                                                   |
| Step 6  | <pre>gkf/vcdng"fghcwnv"kpuvcpeg/kf"kpuvcpeg/kf Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%gkf/vcdng"fghcwnv" kpuvcpeg/kf"2"</pre>           | Associates the default EID table with the specified instance ID.<br><br>Control-plane device messages include this instance ID along with the associated EID prefixes.                                                                                                                 |
| Step 7  | <pre>ocr/ecejg"gkf/rtghkz"ocr/tgswguv Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%ocr/ecejg"32030302146" ocr/tgswguv"</pre>                  | Configures a static IPv4 EID-to-RLOC mapping relationship by adding a map-cache with action send-map-request for the specified dynamic EID or host pool.                                                                                                                               |
| Step 8  | <pre>krx6"uiv Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%krx6"uiv</pre>                                                                     | Enables the transport of Security Group Tags (SGT) in the fabric . For more information on SGTs, see Cisco TrustSec Configuration Guide.                                                                                                                                               |
| Step 9  | <pre>krx6"rtqz{/gvt Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%krx6"rtqz{/gvt</pre>                                                         | Enables the border device service in the fabric domain.                                                                                                                                                                                                                                |
| Step 10 | <pre>krx6"rtqz{/kvt"krx6"cfftguu Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%krx6"rtqz{/kvt" 32030303</pre>                                  | Configures the device to operate as an IPv4 proxy ingress tunnel router (PITR), and configures the interface IP address used as a source address for encapsulation of data packets. The IPv4 locator address is used as the source address for data packets or a map-request messages. |
| Step 11 | <pre>krx6"kvt"ocr/tguqnxgt"krx6"cfftguu Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%krx6"kvt"ocr/tguqnxgt" 32030304</pre>                    | Configures the map-resolver IP from where it needs to query the RLOC corresponding to destination EID IP                                                                                                                                                                               |
| Step 12 | <pre>gzkv Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%gzkv</pre>                                                                             | Exits LISP configuration mode and enters global configuration mode.                                                                                                                                                                                                                    |
| Step 13 | <pre>kr"tqwvg"krx6/rtghkz"pgzv/jqr Gzcorng&lt; Fgxkeg*eqphki+%kr"tqwvg"2020202"2020202" 3203203203</pre>                                | Configures an IPv4 static route.                                                                                                                                                                                                                                                       |
| Step 14 | <pre>gzkv Gzcorng&lt; Fgxkeg*eqphki+%gzkv</pre>                                                                                         | Exits global configuration mode and returns to privileged EXEC mode.                                                                                                                                                                                                                   |

## Configuring Border Devices Using IPv6

To configure a border device using IPv6, use the following LISP commands.

## Before You Begin

Configure a loopback IP address for the border device to ensure that the device is reachable.

|         | Command                                                                                                                                                       | Purpose                                                                                                                                                                                                                                                                                |
|---------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1  | <pre>gpcdng" Gzcorng&lt; Fgxkeg@"gpcdng</pre>                                                                                                                 | Enables privileged EXEC mode. Enter your password if prompted.                                                                                                                                                                                                                         |
| Step 2  | <pre>eqphkiwtg"vgtokpcn" Gzcorng&lt; Fgxkeg%"eqphkiwtg"vgtokpcn</pre>                                                                                         | Enters the global configuration mode.                                                                                                                                                                                                                                                  |
| Step 3  | <pre>tqwvgt"nkur" Gzcorng&lt; Fgxkeg*eqphki+%"tqwvgt"nkur</pre>                                                                                               | Enters LISP configuration mode.                                                                                                                                                                                                                                                        |
| Step 4  | <pre>gpecruwncvkqp"xznpc Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%"gpecruwncvkqp"xznpc</pre>                                                                    | Specifies VXLAN-based encapsulation.                                                                                                                                                                                                                                                   |
| Step 5  | <pre>gkf/vcdng"xth"&gt;xthapcog@"kpuvcpeg/kf"&gt;xcnwg@ Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%"gkf/vcdng"xth"cdef" kpuvcpeg/kf"32</pre>                      | Associates the non-default EID table with the specified instance ID.                                                                                                                                                                                                                   |
| Step 6  | <pre>gkf/vcdng"fghcwnv"kpucvpeg/kf"kpucvpeg/kf Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%"gkf/vcdng"fghcwnv" kpucvpeg/kf"2"</pre>                                | <p>Associates the default EID table with the specified instance ID.</p> <p>Control-plane device messages include this instance ID along with the associated EID prefixes.</p>                                                                                                          |
| Step 7  | <pre>ocr/ecejg"gkf/rtghkz"krx8"cfftguuluwdpgv"ocum" ocr/tgswguv Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%"ocr/ecejg"32&lt;3&lt;3&lt;&lt;186" ocr/tgswguv"</pre> | Configures a static IPv6 EID-to-RLOC mapping relationship by adding a map-cache with action send-map-request for the specified dynamic EID or host pool.                                                                                                                               |
| Step 8  | <pre>krx8"uiv Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%"krx8"uiv</pre>                                                                                          | Enables the transport of Security Group Tags (SGT) in the fabric . For more information on SGTs, see Cisco TrustSec Configuration Guide.                                                                                                                                               |
| Step 9  | <pre>krx8"rtqz{/gvt Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%"krx8"rtqz{/gvt</pre>                                                                              | Enables the border device service in the fabric domain.                                                                                                                                                                                                                                |
| Step 10 | <pre>krx8"rtqz{/kvt"krx8"cfftguu Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%"krx8"rtqz{/kvt" 32030303</pre>                                                       | Configures the device to operate as an IPv6 proxy ingress tunnel router (PITR), and configures the interface IP address used as a source address for encapsulation of data packets. The IPv6 locator address is used as the source address for data packets or a map-request messages. |
| Step 11 | <pre>krx8"kv"ocr/tguqnxgt"krx8"cfftguu Gzcorng&lt; Fgxkeg*eqphki/tqwvgt/nkur+%"krx8"kv"ocr/tguqnxgt" 32030304</pre>                                           | Configures the map-resolver IP from where it needs to query the RLOC corresponding to destination EID IP                                                                                                                                                                               |

|         | Command                                             | Purpose                                                              |
|---------|-----------------------------------------------------|----------------------------------------------------------------------|
| Step 12 | gzkv<br>Gzcorng<<br>Fgxkeg*eqphki/tqwvgt/nkur+%gzkv | Exits LISP configuration mode and enters global configuration mode.  |
| Step 13 | gzkv<br>Gzcorng<<br>Fgxkeg*eqphki+%gzkv             | Exits global configuration mode and returns to privileged EXEC mode. |

## Example: Configuring Fabric Border and Control-Plane Devices

### Fabric Border Router Using IPv4

```

xth" fghkpkvkqp" cdef
tf" 3<3
#
cfftguu/hcokn{"krx6
gzkv/cfftguu/hcokn{
#
kpvgtthceg"Nqqrdecem32
"kr" cfftguu"3050505"477047704770477
#
kpvgtthceg"VgpIkiCDkvGvjgtpgv41:">"/////////"Pqtvj" wruvtgco" hcekpi
kr" cfftguu"33;030303"4770477047702
gpf
#
kpvgtthceg"VgpIkiCDkvGvjgtpgv41;">"/////////"Pqtvj" wruvtgco" hcekpi
xth" hqtyctfkpi" cdef
kr" cfftguu"3;030303"4770477047702
gpf
#
kpvgtthceg"VgpIkiCDkvGvjgtpgv"6134">"/////////"Uqvwj" TNQE" hcekpi
kr" cfftguu"363030304"4770477047702
kr"nkur"uqwtg/nqecvqt"Nqqrdecem32
#
tqwvgt"nkur
gpecruwncvkqp"xznpcp
nqecvqt/ugv"ugv3
" "3050505"rtkqtkv{"3"ygkijv"322
" "gzkv
#
gkf/vcdng" fghcwnv" kpuvcpeg/kf"2
ocr/ecejg"342030302146"ocr/tgswguv">/////////"GKF" uwdpgv" cv" hcdtke" gfig
" "gzkv
#
gkf/vcdng"xth" cdef" kpuvcpeg/kf"3
ocr/ecejg"42030302146"ocr/tgswguv">/////////"GKF" uwdpgv" cv" hcdtke" gfig
gzkv
#
krx6"uiv
krx6"rtqz{/gvt
krx6"rtqz{/kvt"3050505
krx6"kv"ocr/tguqnxgt"3060606
gzkv
"

```

## Fabric Border Router Using IPv6

```
xth"fghkpkvkqp"cdef
tf"3<3
#
cfftguu/hcokn{"krx6
gzkv/cfftguu/hcokn{
#
cfftguu/hcokn{"krx8
gzkv/cfftguu/hcokn{
#
kpvgtthceg"Nqgrdcem32
kr"cfftguu"3050505"477047704770477
#
kpvgtthceg"VgpIkiCDkvGvjgtpgv41:">"/////////"Pqtvj"wruvtgco"hcekpI
krx8"cfftguu"33;<3<3<3186
gpf
#
kpvgtthceg"VgpIkiCDkvGvjgtpgv41:">"/////////"Pqtvj"wruvtgco"hcekpI
xth"hqtyctfki"cdef
kr"cfftguu"3;<3<3<3186
gpf
#
kpvgtthceg"VgpIkiCDkvGvjgtpgv"6134">"/////////"Uqvwj"TNQE"hcekpI
kr"cfftguu"363030304"4770477047702
kr"nkur"ugwteg/nqecvgt"Nqgrdcem32
#
tqvwgt"nkur
gpecruwncvkqp"xznpc
nqecvgt/ugv"ugv3
3050505"rtkqtkv{"3"ygkijv"322
gzkv
#
gkf/vcdng"fghcwnv"kpucpeg/kf"2
ocr/ecejg"342<3<3<186"ocr/tgswguv">/////////"GKF"uwdpgv"cv"hcdtke"gfig
gzkv
#
gkf/vcdng"xth"cdef"kpucpeg/kf"3
ocr/ecejg"42<3<3<186"ocr/tgswguv">/////////"GKF"uwdpgv"cv"hcdtke"gfig
gzkv
#
Krx8"uiv
Krx8"rtqz{/gvt
Krx8"rtqz{/kvt"3050505
Krx8"kvt"ocr/tguqnxgt"3060606
gzkv"
```

## Control Plane Using IPv4

```
kpvgtthceg"Nqgrdcem32
kr"cfftguu"3060606"477047704770477
#
tqvwgt"nkur
gpecruwncvkqp"xznpc
nqecvgt/ugv"ugv3
"3060606"rtkqtkv{"3"ygkijv"322
"gzkv
#
ukvg"ukvg3
"cwvgpvpkecvkqp/mg{"mg{3
"gf/rtghkz"342030302146"ceegrvoqtg/urgekhkeu
"gf/rtghkz"kpucpeg/kf"3"42030302146"ceegrvoqtg/urgekhkeu
```

```
"gzkv
#
krx6"ocr/ugtxgt
krx6"ocr/tguqnxgt
"gzkv
```

## Control Plane Using IPv6

```
kpvgtthceg"Nqgrdcem32
kr"cfftguu"3060606"477047704770477
#
tgwvgt"nkur
gpecruwncvkqp"xznpc
ngecvqt/ugv"ugv3
3060606"rtkgtkv{"3"ygkijv"322
gzkv
#
ukvg"ukvg3
cwvjgpvkecvkqp/mg{"mg{3
gkf/rtghkz"342<3<3<<186
gkf/rtghkz"kpuvcpeg/kf"3"42<3<3<<186
gzkv
#
Krx8"ocr/ugtxgt
Krx8"ocr/tguqnxgt
gzkv
```





## IPv4 Multicast Layer 3 Features

- [Prerequisites for IPv4 Multicast Layer 3 Features, page 44-1](#)
- [Restrictions for IPv4 Multicast Layer 3 Features, page 44-1](#)
- [Information About IPv4 Multicast Layer 3 Features, page 44-2](#)
- [Default Settings for IPv4 Multicast Layer 3 Features, page 44-15](#)
- [How to Configure IPv4 Multicast Layer 3 Features, page 44-15](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for IPv4 Multicast Layer 3 Features

None.

## Restrictions for IPv4 Multicast Layer 3 Features

IP multicast Layer 3 switching is not provided for an IP multicast flow in the following situations:

- For IP multicast groups that fall into the range 224.0.0.\* (where \* is in the range 0 to 255), which is used by routing protocols. Layer 3 switching is supported for groups 225.0.0.\* through 239.0.0.\* and 224.128.0.\* through 239.128.0.\*.

**Note**

Groups in the 224.0.0.\* range are reserved for routing control packets and must be flooded to all forwarding ports of the VLAN. These addresses map to the multicast MAC address range 01-00-5E-00-00-xx, where xx is in the range 0–0xFF.

- For PIM auto-RP multicast groups (IP multicast group addresses 224.0.1.39 and 224.0.1.40).
- For packets with IP options. However, packets in the flow that do not specify IP options are hardware switched.
- If a (S,G) entry for sparse mode does not have the SPT-bit, RPT-bit, or Pruned flag set.
- A (\*,G) entry is not hardware switched if at least one (S,G) entry has an RPF different from the (\*,G) entry's RPF and the (S,G) is not hardware switched.
- If the ingress interface of a (S,G) or (\*,G) entry is null, except if the (\*,G) entry is a IPv4 bidirectional PIM entry and the switch is the RP for the group.
- If you enable IP multicast Layer 3 switching, IP accounting for Layer 3 interfaces does not report accurate values. The **show ip accounting** command is not supported.

## Information About IPv4 Multicast Layer 3 Features

- [IPv4 Multicast Layer 3 Features Overview, page 44-2](#)
- [Distributed MRIB and MFIB Infrastructure, page 44-3](#)
- [Multicast Layer 3 Hardware Features Entries, page 44-4](#)
- [Layer 3-Switched Multicast Statistics, page 44-4](#)
- [Layer 3-Switched Multicast Packet Rewrite, page 44-5](#)
- [Replication Modes, page 44-5](#)
- [Local Egress Replication Mode, page 44-6](#)
- [PIM-SM hardware register support, page 44-6](#)
- [PIM-SM hardware SPT-switchover support, page 44-6](#)
- [Control Plane Policing \(CoPP\), page 44-7](#)
- [Non-RPF Traffic Processing, page 44-7](#)
- [Multicast Boundary, page 44-7](#)
- [IPv4 Bidirectional PIM, page 44-8](#)
- [Supported Multicast Features, page 44-8](#)

## IPv4 Multicast Layer 3 Features Overview

Multicast Layer 3 switching on a Supervisor Engine 6T uses application-specific integrated circuits (ASICs) to provide hardware-supported forwarding for IP multicast data packet flows between IP subnets, which offloads processor-intensive multicast forwarding and replication from the route processor.



The Policy Feature Card (PFC) and Distributed Forwarding Cards (DFCs) use the forwarding information base (FIB) and adjacency table to switch IP Multicast flows in hardware. The FIB table provides support for different entry and mask values; for example, (S/32, G/32) and (\*/0, G/32). The RPF RAM is used to identify packets arriving on a directly connected subnet.

The result of a FIB lookup is an adjacency, which provides the replication list for the entry. Different from earlier supervisor engines, the Supervisor Engine 6T performs packet rewrite after replication, which provides enhanced sharing capabilities for outgoing interfaces.

Also different from earlier supervisor engines, the Supervisor Engine 6T performs Layer 2 and Layer 3 forwarding decisions separately. For a routed interface, the final LTL for a packet is determined based only on Layer 3 information. For VLAN interfaces, the LTL for the packet is determined based only on the Layer 2 lookup.

## Distributed MRIB and MFIB Infrastructure

The Supervisor Engine 6T uses an MRIB- and MFIB-based software model for IPv4 multicast traffic. The MRIB/MFIB infrastructure supports multiple Layer 3 multicast protocols (for example, PIM Sparse-mode, SSM, and bidirectional PIM) for both IPv4 and IPv6 flows and provides consistent CLI for both IPv4 and IPv6 addresses.

The Multicast Routing Information Base (MRIB) is a collection of multicast entries keyed on source, group, and group mask. The multicast control plane programs the entries. An entry can have one or more associated interfaces with different flags indicating the role of the interface in the forwarding plane. On the Supervisor Engine 6T, the PFC and each DFC has an instance of the Multicast Forwarding Information Base (MFIB), which registers as a client of the MRIB. The MFIB registers its interest with the MRIB for the entries and associated flags, and maintains a local database keyed on source, group, and group mask based on MRIB updates.

Without hardware support, the MFIB would forward the multicast traffic. On the Supervisor Engine 6T, in addition to any required software forwarding, the MFIB also sends multicast route updates for the Layer 3 switching hardware tables. The communication between the MRIB, MFIB, and the Layer 3 switching hardware tables is based on the following:

- Multicast entries
- Flags set on multicast entries
- Interfaces associated with multicast entries



### Note

With other supervisor engines, some flows are switched partially in hardware and partially in software. With a Supervisor Engine 6T, multicast flows are switched either in software or in hardware.

Examples of mroute, MRIB, and MFIB information:

```
Tqvwgt% "ujqy"kr"otqwg"
*322030305. "45;040303+. "22<22<75122<24<2: . "hnciu<"uVK
" "Kpeqokpi"kpvgthceg<"VgpIkiCDkvGvjgtpgv512. "TRH"pdt"2020202
" "Qwviqkpi"kpvgthceg"nkuv<
" " "VgpIkiCDkvGvjgtpgv513. "Hqtyctf1Urtug/Fgpug. "22<22<73122<24<2:
" " "VgpIkiCDkvGvjgtpgv514. "Hqtyctf1Urtug/Fgpug. "22<22<73122<24<2:
" " "VgpIkiCDkvGvjgtpgv515. "Hqtyctf1Urtug/Fgpug. "22<22<73122<24<2:

Tqvwgt% "ujqy"kr"otkd"tqwg"
*322030305.45;040303+
" "VgpIkiCDkvGvjgtpgv513 "Hnciu<"C
" "VgpIkiCDkvGvjgtpgv514 "Hnciu<"H
```

```

"VgpIkiCdkvGvjgtpgv515"Hnciu<"H
"VgpIkiCdkvGvjgtpgv516"Hnciu<"H

Tqvwgt%"ujqy"kr"ohkd"
*322030305.45;040303+"Hnciu<
""UY"Hqtyctfkpi<"2121212."Qvjgt<"21212
""VgpIkiCdkvGvjgtpgv513"Hnciu<"C
""""Rmvu<"212
""VgpIkiCdkvGvjgtpgv514"Hnciu<"H
""""Rmvu<"212
""VgpIkiCdkvGvjgtpgv515"Hnciu<"H
""""Rmvu<"212
""VgpIkiCdkvGvjgtpgv516"Hnciu<"H
""""Rmvu<"212

```

## Multicast Layer 3 Hardware Features Entries

This section describes how the PFC and the DFCs maintain Layer 3 switching information in hardware tables.

The PFC and DFC populate the (S,G) or (\*,G) flows in the hardware FIB table with the appropriate masks; for example, (S/32, G/32) and (\*,G/32). The RPF interface and the adjacency pointer information is also stored in each entry. The adjacency table contains the rewrite and a pointer to the replication entries. If a flow matches a FIB entry, the RPF check compares the incoming interface/VLAN with the entry. A mismatch is an RPF failure, which can be rate limited if this feature is enabled. In the event of a forwarding information database (FIB) fatal error, the default error action is for the system to reset and the FIB to reload.

The PFC and any DFCs run an MFIB client, which registers as a client to the MRIB on the RP. The hardware tables are programmed based on MFIB updates to install or delete entries for a traffic flow, or the addition and deletion of outgoing interfaces to an existing hardware entry.

These commands affect the Layer 3 switching entries:

- When you clear the multicast routing table using the **clear ip mroute** command, all multicast Layer 3 switching cache entries are cleared.
- When you disable IP multicast routing on the RP using the **no ip multicast-routing** command, all multicast Layer 3 switching cache entries on the PFC are purged.
- When you disable hardware-supported multicast Layer 3 switching on an interface with the **no platform multicast forwarding ip** interface mode command, flows that use the interface as the RPF interface are routed only by the RP in software.
- When you disable MFIB forwarding on an individual interface basis using the **no ip mfib forwarding ip** command, flows that use this interface as the RPF interface will not be forwarded in hardware or by MFIB.

## Layer 3-Switched Multicast Statistics

While a flow is being switched in hardware, the entry is kept alive in software on the basis of the packet forwarding statistics for the flow. The MFIB entry on the PFC periodically pulls and aggregates the entry statistics from the PFC and every DFC. The statistics increment the hardware forwarding counters for an entry. A software or hardware forwarding counter increment resets the expiration timer for that multicast route.

**Note**

A (\*,G) state is created on the PIM-RP or for PIM-dense mode but is not used for forwarding the flows, and Layer 3 switching entries are not created for these flows.

## Layer 3-Switched Multicast Packet Rewrite

When a multicast packet is Layer 3 switched from a multicast source to a destination multicast group, the PFC and the DFCs perform a packet rewrite that is based on information learned from the RP and stored in the adjacency table.

For example, Server A sends a multicast packet addressed to IP multicast group G1. If there are members of group G1 on VLANs other than the source VLAN, the PFC must perform a packet rewrite when it replicates the traffic to the other VLANs (the switch also bridges the packet in the source VLAN).

When the PFC receives the multicast packet, it is (conceptually) formatted as follows:

| Layer 2 Frame Header                                                |                     | Layer 3 IP Header  |                    |          |                     | Data | FC |
|---------------------------------------------------------------------|---------------------|--------------------|--------------------|----------|---------------------|------|----|
| Destination                                                         | Source              | Destination        | Source             | TTL      | Checksum            |      | S  |
| <i>Group G1 MAC</i>                                                 | <i>Source A MAC</i> | <i>Group G1 IP</i> | <i>Source A IP</i> | <i>n</i> | <i>calculation1</i> |      |    |
| <b>Note</b> In this example, Destination B is a member of Group G1. |                     |                    |                    |          |                     |      |    |

The PFC rewrites the packet as follows:

- Changes the source MAC address in the Layer 2 frame header from the MAC address of the host to the MAC address of the RP (This is the burned-in MAC address of the system. This MAC address will be the same for all outgoing interfaces and cannot be modified. This MAC address can be displayed using the **show platform multicast statistics** command.)
- Decrements the IP header Time to Live (TTL) by one and recalculates the IP header checksum

The result is a rewritten IP multicast packet that appears to have been routed. The PFC replicates the rewritten packet onto the appropriate destination VLANs, where it is forwarded to members of IP multicast group G1.

After the PFC performs the packet rewrite, the packet is (conceptually) formatted as follows:

| Frame Header        |               | IP Header          |                    |            |                     | Data | FC |
|---------------------|---------------|--------------------|--------------------|------------|---------------------|------|----|
| Destination         | Source        | Destination        | Source             | TTL        | Checksum            |      | S  |
| <i>Group G1 MAC</i> | <i>RP MAC</i> | <i>Group G1 IP</i> | <i>Source A IP</i> | <i>n-1</i> | <i>calculation2</i> |      |    |

## Replication Modes

The Supervisor Engine 6T supports these replication modes:

- Ingress mode—The ingress module performs the replication for the egress interfaces on all modules.
- Egress mode (default)—Ingress multicast traffic is distributed over the fabric to the egress modules. The egress modules perform the replication for the egress interfaces.

The Supervisor Engine 6T performs egress-mode replication for ingress-only legacy switching modules, so that the presence of an ingress-only legacy switching module does not force a replication mode change.



**Note**

---

Intranet and extranet MVPN are supported in egress and ingress replication mode.

---

## Local Egress Replication Mode

DFC-equipped modules with dual switch-fabric connections host two packet replication engines, one per fabric connection. Each replication engine is responsible for forwarding packets to and from the interfaces associated with the switch-fabric connections. The interfaces that are associated with a switch-fabric connection are considered to be “local” from the perspective of the packet replication engine. Without local egress replication mode, both replication engines have the complete outgoing interface list for all modules, and the replication engines process and then drop traffic for nonlocal interfaces. The Supervisor Engine 6T provides local egress replication for CFC-equipped switching modules.

Local egress replication mode limits the outgoing interface list to only the local interfaces that each replication engine supports, which prevents unnecessary processing of multicast traffic.

In Cisco IOS Release 15.4SY, local egress replication mode is enabled by default.

## PIM-SM hardware register support

The PIM-SM protocol requires the first-hop router for a multicast source to send a register packet to the Rendezvous Point (RP) when the source starts sending packets. On the Supervisor Engine 6T, the PIM control-plane uses the MFIB infrastructure to represent the PIM register tunnel as an interface and adds it to the outgoing interface list when PIM register packets are sent. When a new PIM RP is configured or learned, a PIM register tunnel interface is created and used for PIM register packets. The interface is deleted when a register-stop packet is received. On the RP, an additional interface is created and used to decapsulate the PIM register packet when it is received.

The Supervisor Engine 6T supports PIM register packet transmission and reception in hardware. PIM register packets are sent to the RP for the PIM registration process. CoPP can rate limit the PIM register packets sent to the RP for the PIM registration process.

## PIM-SM hardware SPT-switchover support

SPT-switchover occurs in a PIM-SM network when the shortest path to the source diverges from the shortest path to the RP for a multicast group. During the transition from the shortest path tree to a source based tree, packets are received on both the shared and source tree and the multicast entry must be programmed to accept packets from two interfaces.

Hardware support is implemented with a multicast FIB dual-RPF mode. When a multicast FIB entry is programmed with a dual-RPF, packets received on the RPF towards the RP are forwarded and packets received on the RPF towards the source are sent to be processed in software for the PIM protocol to complete the SPT-switchover. After switching to the source tree, the multicast entry transitions back to a single RPF interface. To avoid excessive CPU utilization during the switchover process, you can configure CoPP to rate limit multicast packets sent to the RP during SPT-switchover.

## Control Plane Policing (CoPP)

You can configure CoPP to protect the CPU from unnecessary or DoS traffic. With Cisco IOS Release 15.4SY, CoPP is configured and enabled by default. CoPP provides hardware rate limiting for the packets sent to the CPU for processing in software. Although multicast rate-limiters are still supported, CoPP is more efficient.




**Note**

For any particular type of traffic, configure CoPP or a rate limiter, not both.

## Non-RPF Traffic Processing

In a redundant configuration where multiple routers connect to the same LAN segment, only one router forwards the multicast traffic from the source to the receivers on the outgoing interfaces (see [Figure 44-1](#)). In this kind of topology, only the PIM designated router (PIM DR) forwards the data in the common VLAN, but the non-PIM DR receives the forwarded multicast traffic. The redundant router (non-PIM DR) must drop this traffic because it has arrived on the wrong interface and fails the RPF check. Traffic that fails the RPF check is called non-RPF traffic.

**Figure 44-1** Redundant Multicast Router Configuration in a Stub Network



Non-RPF protection, which is enabled by default, keeps the CPU from being overwhelmed with non-RPF traffic while still allowing some packets to reach the CPU to support correct multicast routing protocol operation. The non-RPF protection feature uses a leak and drop mechanism: a non-RPF packet is leaked to the CPU, and subsequent non-RPF packets are dropped. The sequence repeats periodically.

Multicast RPF-fail packets that conform to the configured CoPP policy reach the CPU. Nonconforming packets are dropped. Rate limiting is configured in the CoPP policy.

## Multicast Boundary

The multicast boundary feature allows you to configure an administrative boundary for multicast group addresses. By restricting the flow of multicast data packets, you can reuse the same multicast group address in different administrative domains.

You configure the multicast boundary on an interface. A multicast data packet is blocked from flowing across the interface if the packet's multicast group address matches the access control list (ACL) associated with the multicast boundary feature.

Multicast boundary ACLs can be processed in hardware by the Policy Feature Card (PFC), a Distributed Forwarding Card (DFC), or in software by the RP. The multicast boundary ACLs are programmed to match the destination address of the packet. These ACLs are applied to traffic on the interface in both directions (input and output).

To support multicast boundary ACLs in hardware, the switch creates new ACL TCAM entries or modifies existing ACL TCAM entries (if other ACL-based features are active on the interface). To verify TCAM resource utilization, enter the **show tcam counts ip** command.

If you configure the **filter-autorp** keyword, the administrative boundary also examines auto-RP discovery and announcement messages and removes any auto-RP group range announcements from the auto-RP packets that are denied by the boundary ACL.

## IPv4 Bidirectional PIM

The PFC and DFCs support hardware forwarding of IPv4 bidirectional PIM groups. To support IPv4 bidirectional PIM groups, the PFC and DFCs support the designated forwarder (DF) mode. The designated forwarder is the router elected to forward packets to and from a segment for a IPv4 bidirectional PIM group. In DF mode, the switch accepts packets from the RPF and from the DF interfaces.

When the switch is forwarding IPv4 bidirectional PIM groups, the RPF interface is always included in the outgoing interface list of (\*,G) entry, and the DF interfaces are included depending on IGMP/PIM joins.

If the route to the RP becomes unavailable, the group is changed to dense mode. Should the RPF link to the RP become unavailable, the IPv4 bidirectional PIM flow is removed from the hardware FIB.

For information on configuring IPv4 bidirectional PIM, see the [“Configuring IPv4 Bidirectional PIM” section on page 44-26](#).

## Supported Multicast Features

- [Hardware-Supported IPv4 Layer 3 Features, page 44-9](#)
- [Unsupported IPv4 Layer 3 Features, page 44-10](#)
- [Hardware-Supported IPv6 Layer 3 Multicast Features, page 44-11](#)
- [Partially Hardware-Supported IPv6 Layer 3 Multicast Features, page 44-11](#)
- [Software-Supported IPv6 Layer 3 Multicast Features, page 44-11](#)

- [Unsupported IPv6 Layer 3 Multicast Features, page 44-12](#)
- [Hardware-Supported Layer 2 Common Multicast Features, page 44-12](#)
- [Unsupported Layer 2 Common Multicast Features, page 44-12](#)
- [Hardware-Supported Layer 2 Enterprise Multicast Features, page 44-13](#)
- [Unsupported Layer 2 Enterprise Multicast Features, page 44-13](#)
- [Hardware-Supported Layer 2 Metro Multicast Features, page 44-13](#)
- [Unsupported Layer 2 Metro Multicast Features, page 44-13](#)
- [Unsupported MPLS Multicast Features, page 44-14](#)
- [Hardware-Supported Security Multicast Features, page 44-14](#)
- [Software-Supported Security Multicast Features, page 44-14](#)
- [Unsupported Security Multicast Features, page 44-14](#)

## Hardware-Supported IPv4 Layer 3 Features

- Control plane policing (CoPP)
- Egress forced replication mode
- Egress replication local
- Egress replication mode
- HW assisted SPT switchover
- Input ACL logging
- Input and output ACL filtering
- IPv4 multicast over multipoint IPv4 GRE tunnel
- IPv4 multicast over P2P IPv4 GRE tunnel
- IPv4 multicast over P2P IPv4 GRE tunnel with tunnel endpoints in VRF
- IPv4 multicast over P2P IPv4 VRF GRE tunnel
- Load-Balancing of multicast packets on port-channels
- Multicast boundary
- Multicast Layer 3 forwarding on routed ports
- Multicast Layer 3 forwarding on subinterfaces
- Multicast Layer 3 forwarding on SVI
- Multicast load-splitting across parallel links
- Multicast VPN for IPv4 extranet support
- Multicast VPN for IPv4 intranet support
- Multicast VRF-lite
- MVPN over P2P IPv4 GRE tunnel
- Netflow accounting
- Non-RPF protection
- PIM Register decapsulation over IPv4

- PIM Register encapsulation over IPv4
- PIM-SM (S,G) and (\*,G) forwarding
- PIM-SSM
- QoS policing for ingress mode
- Rate limiters
- Statistics
- UDLR - unidirectional link routing
- URD - URL rendezvous directory
- Partially Hardware-Supported IPv4 Layer 3 Features
- Egress replication mode and QoS marking
- QoS marking for ingress mode
- Software-Supported IPv4 Layer 3 Features
- IGMPv3/v2/v1
- MET sharing
- MRM/mrinfo/mmon
- MSDP/MBGP
- Mtrace/Mping
- PGM router assist
- PGM router assist in VRF
- Platform Dependent MIB support
- Platform Independent MIB support
- SSM Mapping
- SSO/NSF

## Unsupported IPv4 Layer 3 Features

- 6PE IPv6 over IPv4 infrastructure (using MDT tunnels)
- Destination IP NAT multicast
- MTR multicast ToS-based lookup
- Multicast stub (Supported in 12.2SX)
- Partial shortcut (Supported in 12.2SX)
- Service reflect
- Source IP NAT multicast
- Egress replication mode and QoS policing
- Output ACL logging
- QoS ingress or egress shaping
- QoS marking for multicast bridged frames undergoing routing
- DVMRP interoperability (supported in Release 12.2SX)



- ISSU/MDR
- MFIB consistency checker
- MFIB to HW consistency checker
- MTR multicast: separate RPF table for group range
- MTR multicast: separate URIB RPF table
- Multicast helper map (supported in Release 12.2SX)
- RPF change tracking
- PIM-DM (S,G) forwarding
- The **ip multicast rate-limit** command (supported in Release 12.2SX)
- The **ip multicast ttl-threshold** command (supported in Release 12.2SX)

## Hardware-Supported IPv6 Layer 3 Multicast Features

- Control plane policing (CoPP)
- Egress forced replication mode
- Egress replication local
- Egress replication mode
- HW assisted SPT switchover
- Input ACL logging
- Input and output ACL filtering
- IPv6 Multicast over P2P IPv4 GRE/IP-in-IP tunnel (6over4)
- Load-Balancing of multicast packets on port-channels
- Multicast Layer 3 forwarding on routed ports
- Multicast Layer 3 forwarding on subinterfaces
- Multicast Layer 3 forwarding on SVI
- Multicast load-splitting across parallel links
- Netflow accounting
- Non-RPF protection
- PIM register decapsulation over IPv6
- PIM register encapsulation over IPv6
- PIM-SM (S,G) and (\*,G) forwarding
- PIM-SSM
- QoS ingress mode marking
- QoS ingress mode policing
- Rate limiters
- Scope checking
- Statistics

## Partially Hardware-Supported IPv6 Layer 3 Multicast Features

- Egress replication mode and QoS marking

## Software-Supported IPv6 Layer 3 Multicast Features

- SSM mapping
- MET sharing
- MLDv1/v2

## Unsupported IPv6 Layer 3 Multicast Features

- BIDIR PIM over P2P GRE tunnel
- Destination IP NAT multicast
- IPv4 multicast over P2P IPv6 GRE tunnel (4over6)
- IPv6 multicast over multipoint IPv4 GRE tunnel (6over4 mGRE)
- IPv6 multicast over multipoint IPv6 GRE tunnel
- IPv6 multicast over P2P IPv6 GRE tunnel
- IPv6 multicast over P2P IPv6 GRE tunnel with tunnel endpoints in VRF
- IPv6 multicast over P2P IPv6 VRF GRE tunnel
- MTR multicast: TOS based lookup
- Multicast VPN for IPv6 extranet support
- Multicast VPN for IPv6 intranet support
- Multicast VRF-lite
- MVPN over P2P IPv6 GRE tunnel
- PIM-DM (S,G) forwarding
- Source IP NAT multicast
- Egress replication mode and QoS policing
- QoS ingress and egress: shaping support
- MIB support
- Multicast boundary
- Multicast helper map
- Output ACL logging
- PGM router assist
- PGM router assist in VRF
- PIM-BIDIR
- QoS Marking for multicast bridged frames undergoing routing

## Hardware-Supported Layer 2 Common Multicast Features

- NSF/SSO support for IGMP/PIM/MLD snooping

## Unsupported Layer 2 Common Multicast Features

- ISSU/MDR support for IGMP/PIM/MLD snooping
- MIB support

## Hardware-Supported Layer 2 Enterprise Multicast Features

- IGMPv2/v1 snooping - IP based constrain
- IGMPv2/v1 snooping - MAC based constrain
- IGMPv3 snooping with S,G constrain
- MLD v1 snooping - IP based constrain
- MLD v1 snooping - MAC based constrain
- MLD v2 snooping - IP based constrain
- MLD v2 snooping - MAC based constrain
- Multicast support for PVLAN over BD
- Optimized flooding for unknown IP multicast frames
- PIM snooping - IP based constrain
- PIM snooping - MAC based constrain
- IGMP snooping querier
- IGMPv3 snooping Explicit tracking
- MLD snooping querier
- PIM snooping - DR flooding

## Unsupported Layer 2 Enterprise Multicast Features

- RGMP
- Source-Only detection
- Multicast Flood Protection
- CGMP compatibility mode for IGMP snooping
- CGMP redirect suppression

## Hardware-Supported Layer 2 Metro Multicast Features

- Multicast VLAN Registration (MVR)

## Unsupported Layer 2 Metro Multicast Features

- MLD v1/v2 snooping over Q-in-Q tagged frames
- Optimized VPLS multicast constrains on LAN ports
- PIM snooping over Q-in-Q
- IGMPv3/v2/v1 snooping over Q-in-Q tagged frames
- MTP multicast optimization
- Multicast routing for BD with EOM

## Unsupported MPLS Multicast Features

- Inter-AS IPv4 Multicast VPN using mLDP
- Inter-AS IPv6 Multicast VPN using mLDP
- IPv4 Multicast Traffic at the Edge (via Global routing table) using mLDP
- IPv4 Multicast Traffic at the Edge (via Global routing table) over a P2MP RSVP TE LSP
- IPv4 Multicast Traffic in a VRF over a P2MP RSVP TE LSP
- IPv4 Multicast Traffic in a VRF using mLDP
- IPv6 Multicast Traffic at the Edge (via Global routing table) using mLDP
- IPv6 Multicast Traffic at the edge (via Global routing table) over a P2MP RSVP TE LSP
- IPv6 Multicast Traffic in a VRF over a P2MP RSVP TE LSP
- IPv6 Multicast Traffic in a VRF using mLDP
- ISSU Support
- Link protection for P2MP TE LSPs (500 msec)
- Node protection for P2MP TE LSPs (500 msec)
- SSO/NSF Support
- Carrier Supporting Carrier (CSC) for IPv4 Multicast VPN using mLDP
- Carrier Supporting Carrier (CSC) for IPv6 Multicast VPN using mLDP
- Extranet support for IPv4 Multicast VPN for Label Switched Multicast
- Extranet support for IPv6 Multicast VPN for Label Switched Multicast
- Link protection for mLDP trees (500 msec)
- Node protection for mLDP trees (500 msec)
- MIB support

## Hardware-Supported Security Multicast Features

- Multicast and service blade interaction
- P2P GRE tunnel and VPN/SM/IPSEC SPA module interaction

## Software-Supported Security Multicast Features

- IGMP Snooping filtering

## Unsupported Security Multicast Features

- CTS LinkSecurity for multicast
- RBACL and IPv4/IPv6 multicast data packets
- CTS implicit tunnel for multicast
- GDOI key distribution

## Default Settings for IPv4 Multicast Layer 3 Features

- Multicast routing: disabled globally.
- PIM routing: disabled on all interfaces.
- IP multicast Layer 3 switching: enabled when multicast routing is enabled and PIM is enabled on the interface.
- IP MFIB forwarding: enabled when PIM is enabled on the interface.

Internet Group Management Protocol (IGMP) snooping is enabled by default on all VLAN interfaces. If you disable IGMP snooping on an interface, multicast Layer 3 flows are still switched by the hardware. Bridging of the flow on an interface with IGMP snooping disabled causes flooding to all forwarding interfaces of the VLAN. For details on configuring IGMP snooping, see [Chapter 45, “IGMP Snooping for IPv4 Multicast Traffic.”](#)

## How to Configure IPv4 Multicast Layer 3 Features

- [Enabling IPv4 Multicast Routing Globally, page 44-16](#)
- [Enabling IPv4 PIM on Layer 3 Interfaces, page 44-16](#)
- [Enabling IP Multicast Layer 3 Switching on Layer 3 Interfaces, page 44-16](#)
- [Enabling IP MFIB forwarding on Layer 3 Interfaces, page 44-17](#)
- [Configuring the Replication Mode, page 44-18](#)
- [Configuring Multicast Boundary, page 44-18](#)
- [Verifying Local Egress Replication, page 44-19](#)
- [Displaying IPv4 Multicast PIM-SM register tunnel information, page 44-20](#)
- [Displaying the IPv4 Multicast Routing Table, page 44-20](#)
- [Displaying IPv4 MRIB Information, page 44-21](#)
- [Displaying IPv4 MFIB Information, page 44-22](#)
- [Viewing Directly Connected Entries, page 44-23](#)
- [Displaying IPv4 Hardware Switching Information, page 44-24](#)
- [Displaying IPv4 CoPP Information, page 44-25](#)

- [Source-Specific Multicast with IGMPv3, IGMP v3lite, and URD, page 44-26](#)
- [Configuring IPv4 Bidirectional PIM, page 44-26](#)
- [Enabling IPv4 Bidirectional PIM Globally, page 44-27](#)
- [Configuring the Rendezvous Point for IPv4 Bidirectional PIM Groups, page 44-27](#)
- [Displaying IPv4 Bidirectional PIM Information, page 44-27](#)
- [Using IPv4 Debug Commands, page 44-31](#)
- [Redundancy for Multicast Traffic, page 44-31](#)

## Enabling IPv4 Multicast Routing Globally

You must enable IP multicast routing globally before you can enable IP multicast Layer 3 switching on Layer 3 interfaces.

To enable IP multicast routing globally, perform this task:

| Command                                                 | Purpose                                |
|---------------------------------------------------------|----------------------------------------|
| <code>Tqwgvt*eqphki+%<b>"kr"ownvkecuv/tqwkpi</b></code> | Enables IP multicast routing globally. |

This example shows how to enable multicast routing globally:

```
Tqwgvt*eqphki+%"kr"ownvkecuv/tqwkpi
Tqwgvt*eqphki+%"
```

## Enabling IPv4 PIM on Layer 3 Interfaces

You must enable PIM on the Layer 3 interfaces before IP multicast Layer 3 switching functions on those interfaces.

To enable IP PIM on a Layer 3 interface, perform this task:

|        | Command                                                                                     | Purpose                                |
|--------|---------------------------------------------------------------------------------------------|----------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%<b>"kpvgtthceg"</b>}}<b>xncp</b>"vlan_ID;"~"}type slot/port;i;"</code> | Selects an interface to configure.     |
| Step 2 | <code>Tqwgvt*eqphki/kh+%<b>"kr"rko"</b>}fgpug/oqfg"~"urctug/oqfg"~"urctug/fgpug/oqfg</code> | Enables IP PIM on a Layer 3 interface. |

This example shows how to enable PIM on an interface using the default mode (**sparse-dense-mode**):

```
Tqwgvt*eqphki/kh+%"kr"rko
```

This example shows how to enable PIM sparse mode on an interface:

```
Tqwgvt*eqphki/kh+%"kr"rko"urctug/oqfg
```

**Note**

- You must enable PIM on all participating Layer 3 interfaces before IP multicast Layer 3 switching will function. For information on configuring PIM on Layer 3 interfaces, see the [“Enabling IPv4 PIM on Layer 3 Interfaces”](#) section on page 44-16.
- PIM can be enabled on any Layer 3 interface, including VLAN interfaces.

## Enabling IP Multicast Layer 3 Switching on Layer 3 Interfaces

IP multicast Layer 3 switching is enabled by default on the Layer 3 interface when you enable PIM on the interface. Perform this task only if you disabled IP multicast Layer 3 switching on the interface and you want to reen able it.

To enable IP multicast Layer 3 switching on a Layer 3 interface, perform this task:

|        | Command                                                                               | Purpose                                                                     |
|--------|---------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+% "kpvgtthceg" } }xncp"vlan_ID;" ~"<br/>}type slot/port;i"</code> | Selects an interface to configure.                                          |
| Step 2 | <code>Tqwwgt*eqphki/kh+% "rncvhtqto"ownvkecuv"hqtyctfkpi"kr"</code>                   | Enables IP multicast Layer 3 switching on a Layer 3 interface.              |
| Step 3 | <code>Tqwwgt*eqphki/kh+% "gzkv"</code>                                                | Returns you to global configuration mode.                                   |
| Step 4 | <code>Tqwwgt"% "rncvhtqto"kr"ownvkecuv"u{unqi"</code>                                 | (Optional) Enables display of multicast related syslog messages on console. |

This example shows how to enable IP multicast Layer 3 switching on a Layer 3 interface:

```
Tqwwgt*eqphki/kh+% "rncvhtqto"ownvkecuv"hqtyctfkpi"kr"
Tqwwgt*eqphki/kh+% "
```

## Enabling IP MFIB forwarding on Layer 3 Interfaces

Disabling MFIB forwarding on the interface is another way to disable IP multicast Layer 3 switching for an interface. By default MFIB forwarding in and out are enabled by when PIM is enabled on the interface. To enable MFIB forwarding on a Layer 3 interface, perform this task:

|        | Command                                                                                | Purpose                                                                     |
|--------|----------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+% "kpvgtthceg" } }xncp"<br/>xncpaKF;" ~"}v{rg" unqvlrqtvi;"</code> | Selects an interface to configure.                                          |
| Step 2 | <code>Tqwwgt*eqphki/kh+% "kr"ohkd"hqtyctfkpi"kp</code>                                 | Enables MFIB forwarding on a Layer 3 interface.                             |
| Step 3 | <code>Tqwwgt*eqphki/kh+% "gzkv"</code>                                                 | Returns you to global configuration mode.                                   |
| Step 4 | <code>Tqwwgt"% "]pq_"rncvhtqto"kr"ownvkecuv"<br/>u{unqi"</code>                        | (Optional) Enables display of multicast related syslog messages on console. |

This example shows how to enable MFIB forwarding on a Layer 3 interface:

```
Tqwwgt*eqphki/kh+% "kr"ohkd"hqtyctfkpi"kp"
```

Tqwvgt\*eqphki/kh+%"

# Configuring the Replication Mode

The default for Cisco IOS Release 15.4SY is egress replication mode. Egress replication mode is always supported because the Supervisor Engine 6T provides egress replication for ingress-only legacy switching modules. Modules installed or added do not constrain the replication mode. You can change the configured replication mode.

To configure the replication mode, perform this task:

| Command                                                                           | Purpose                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Tqwvgt*eqphki+%] <b>pq_</b> "rncvhto"kr"ownvkecuv"tqwvkpi"<br>tgrnkecvkqp"gitguu" | Configures the replication mode. <ul style="list-style-type: none"> <li>The <b>platform multicast routing replication egress</b> command configures egress replication mode.</li> <li>The <b>no platform multicast routing replication egress</b> command configures ingress replication mode.</li> <li>Changing the replication mode might interrupt traffic.</li> </ul> |

This example shows how to configure ingress replication mode:

Tqwvgt\*eqphki+%**"pq"**rncvhto"ownvkecuv"tqwvkpi"tgrnkecvkqp"gitguu"

This example shows how to display the replication mode:

```
Tqwvgt%"ujqy"rncvhto""ownvkecuv"tqwvkpi"tgrnkecvkqp"
Ewttgvp"oqfg"qh"tgrnkecvkqp"ku"Kpitguu
Eqphkiwtgf"oqfg"qh"tgrnkecvkqp"ku"Kpitguu

Unqv""""""""""Owvnvkecuv"tgrnkecvkqp"ecrcdknk{
"4""""""""""Gitguu
"7""""""""""Gitguu
```

# Configuring Multicast Boundary

To configure a multicast boundary, perform this task:

|        | Command                                                                                                                | Purpose                                                                                                                                                                                                                                                                                                                       |
|--------|------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqwvgt*eqphki+% <b>"kpvgtthceg"</b> }} <b>xncp</b> "vlan_ID;"~"<br>}type slot/port;"~"} <b>rgtv/ejcppgn</b> "pwodgt; ; | Selects an interface to configure.                                                                                                                                                                                                                                                                                            |
| Step 2 | Tqwvgt*eqphki/kh+% <b>"kr"</b> ownvkecuv" <b>dqwpfct</b> { "<br>access_list ] <b>hknvgt/cwvqtr_</b>                    | Enables an administratively scoped boundary on an interface. <ul style="list-style-type: none"> <li>For <i>access_list</i>, specify the access list that you have configured to filter the traffic at this boundary.</li> <li>(Optional) Specify <b>filter-autorp</b> to filter auto-RP messages at this boundary.</li> </ul> |





### Note

If you configure the **filter-autorp** keyword, the administrative boundary examines auto-RP discovery and announcement messages and removes any auto-RP group range announcements from the auto-RP packets that are denied by the boundary ACL. An auto-RP group range announcement is permitted and passed by the boundary only if all addresses in the auto-RP group range are permitted by the boundary ACL. If any address is not permitted, the entire group range is filtered and removed from the auto-RP message before the auto-RP message is forwarded.

The following example sets up a multicast boundary for all administratively scoped addresses:

```
Tqvwgt*%egphki+%ceeguu/nkuv"3"fpg{"45;020202"2047704770477"
Tqvwgt*%egphki+%ceeguu/nkuv"3"rgtokv"446020202"37047704770477"
Tqvwgt*%egphki+%kpvgtthceg"ikicdkvgvjgtpgv"714"
Tqvwgt*%egphki/kh+%kr"ownvkecuv"dqwpfct{"3"
```

## Verifying Local Egress Replication

DFC-equipped modules with dual switch-fabric connections host two packet replication engines, one per fabric connection. Each replication engine is responsible for forwarding packets to and from the interfaces associated with the switch-fabric connections. The interfaces that are associated with a switch-fabric connection are considered to be “local” from the perspective of the packet replication engine. When local egress replication mode is not enabled, both replication engines have the complete outgoing interface list for all modules, and the replication engines process and then drop traffic for nonlocal interfaces.

Local egress replication mode limits the outgoing interface list to only the local interfaces that each replication engine supports, which prevents unnecessary processing of multicast traffic.

Local egress replication is supported with the following software configuration and hardware:

- Egress replication mode.
- Dual fabric-connection DFC-equipped modules.
- CFC-equipped modules (functionality provided by the Supervisor Engine 6T).
- Members of Layer 3 EtherChannels and VLAN interfaces.

This example shows how to verify the replication engine selected for local egress replication:

Tqwgvt%**"ujqy"rncvhtgo"ownvkecuv"tqwvkpi"tgrnkecvkqp"**  
Ewttgvp"oqfg"qh"tgrnkecvkqp"ku"Kpitu  
Eqghkiwtgf"oqfg"qh"tgrnkecvkqp"ku"Kpitu

```
Unqv"Ovnvkecuvtgrnkecvkqp"ecrcdknkv{
"4"Gitguu
"7"Gitguu
```

## Displaying IPv4 Multicast PIM-SM register tunnel information

To view the register tunnel interfaces associated with a PIM RP, enter the **show ip pim tunnel** command.

| Command                                        | Purpose                                                                                                                                    |
|------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwvgt% "ujqy"kr"rko"tr"ocrrkpi "</code> | Displays PIM RP information.                                                                                                               |
| <code>Tqwvgt% "ujqy"kr"rko"vwppgn "</code>     | Displays PIM register encapsulation tunnel information on all routers.<br>Displays additional PIM register decapsulation tunnel on the RP. |

This example shows how to display the PIM register tunnel information:

```
Tqwvgt% "ujqy"kr"rko"tr"ocrrkpi "
RKO" Itqwr/vq/TR"Ocrrkpiu
```

```
Itqwr*u+<"44602020216. "Uvcvke
" " "TR<"33030303" *A+
```

```
Tqwvgt% "ujqy"kr"rko"vwppgn "
Vwppgn2 "
" "V{ rg" "<"RKO"Gpecr
" "TR" " "<"33030303,
" "Uqwtg<"33030303
Vwppgn3, "
" "V{ rg" "<"RKO"Fgecr
" "TR" " "<"33030303,
" "Uqwtg<" /
```

## Displaying the IPv4 Multicast Routing Table

To view a mroute entry, enter the **show ip mroute** command.

| Command                                                          | Purpose                                  |
|------------------------------------------------------------------|------------------------------------------|
| <code>Tqwvgt% "ujqy"kr"otqwvg" ]jqvupcog"~" itqwrapwodgt_</code> | Displays the IP multicast routing table. |

This example shows how to display the IP multicast routing table:

```
Tqwvgt% "ujqy"kr"otqwvg"447030303 "
KR"Ownvkecuv" Tqwvkpi "Vcdng
Hnciu<"F"/"Fgpug. "U"/"Urctug. "D"/"Dkft" Itqwr. "u"/"UUO" Itqwr. "E"/"Eqppgevgf.
" " " " "N"/"Nqecn. "R"/"Rtwpgf. "T"/"TR/dkv"ugv. "H"/"Tgikuvgt" hnci.
" " " " "V"/"URV/dkv"ugv. "L"/"Lqkp"URV. "O"/"OUFR"etgcvgf"gpvt{. "G"/"Gzvtcpgv.
" " " " "Z"/"Rtqz{ "Lqkp"Vkogt"Twppkpi. "C"/"Ecpfkfcvg" hqt "OUFR" Cfxgtvkugogpv.
" " " " "W"/"WTF. "K"/"Tgegkxgf"Uqwtg"Urgekhke"Jquv" Tgrqtv. "
" " " " " \"/"Ownvkecuv"Vwppgn. " | "/"OFV/fcvc" itqwr"ugpfgt. "
" " " " " ["/"Lqkpgf"OFV/fcvc" itqwr. " { "/"Ugpfkpi"vq"OFV/fcvc" itqwr. "
" " " " " I"/"Tgegkxgf"DIR"E/Otqwvg. "i"/"Ugpv"DIR"E/Otqwvg. "
" " " " " S"/"Tgegkxgf"DIR"U/C" Tqwvg. "s"/"Ugpv"DIR"U/C" Tqwvg. "
" " " " " X"/"TF" ("Xgevgt. "x"/"Xgevgt
Qwviqkpi"kpvgthceg" hnciu<"J"/"Jctfyctg"uykvejgf. "C"/"Cuugt"v"ykppgt
"Vkogtu<"Wrvkog1Gzrktgu
"Kpvgthceg" uvcvg<"Kpvgthceg. "Pgzv/Jqr"qt" XEF. "Uvcvg10qfg
```

```
* , . "447030303+ . "22<47<57122<24<74 . "TR"33030303 . "hnciu<"ULE
" "Kpeqokpi"kpvgthceg<"Pwnn . "TRH"pdt"2020202
" "Qwviqkpi"kpvgthceg"nkuv<
" " " "IkicdkvGvjgtpgv316 . "Hqtyctf1Urctug/Fgpug . "22<43<65122<24<74
" " " "Xncp768 . "Hqtyctf1Urctug/Fgpug . "22<47<58122<24<73

*44040403 . "447030303+ . "22<47<58122<23<6 ; . "hnciu<"V
" "Kpeqokpi"kpvgthceg<"Xncp768 . "TRH"pdt"2020202
" "Qwviqkpi"kpvgthceg"nkuv<
" " " "IkicdkvGvjgtpgv316 . "Hqtyctf1Urctug/Fgpug . "22<43<68122<25<46
```

## Displaying IPv4 MRIB Information

The **show ip mrib** command displays detailed information about IP MRIB. To display detailed MRIB information, perform one of these tasks:

| Command                                                                                            | Purpose                                    |
|----------------------------------------------------------------------------------------------------|--------------------------------------------|
| Tqvwgt% <b>"ujqy"kr"otkd"enkgpv"</b>                                                               | Displays the clients registered with MRIB. |
| Tqvwgt% <b>"ujqy"kr"otkd"tqwvg"</b><br>]jqvupcog ~ itqwrapwodgt"~"uwooct{"~"tgugt <del>xgf</del> _ | Displays the MRIB route information.       |

To view the MRIB clients, enter the **show ip mrib** client command. MFIB running on the PFC and each DFC must present as clients of the MRIB. This example shows how to display the MRIB clients:

```
Tqvwgt%"ujqy"kr"otkd"enkgpv"
KR"OTKD"enkgpv/eqppgevkqpu
OTKD"Vtcpu"hgt"OXTH"%2" " " " "vcdng<656" " " " " " *eqppgevkqp"kf"3+
KRx6aohkd*2z79F576E: +<80864" " " " " " *eqppgevkqp"kf"4+
KRx6aohkd*2z777HE9F: +<30584" " " " " " *eqppgevkqp"kf"5+
```

This example shows how to display the MRIB table:

```
Tqvwgt%"ujqy"kr"otkd"tqwvg"447030303"
KR"Ownvkecuv"tqwvkpi"Kphqtocvkqp"Dcug
Gpvt{"hnciu<"N"/"Fqockp/Nqecn"Uqwteg . "G"/"Gzvgtpcn"Uqwteg"vq"vjg"Fqockp .
" " " "E"/"Fktgevn{/Eqppgevgf"Ejgem . "U"/"Ukipcn . "KC"/"Kpjgtkv"Ceegr . "F"/"Ftqr
" " " "GV"/"Fcv"TCvg"Gzeggf"Vjtgujqnf . M"/"Mggrcnkxg . FFG"/"Fcv"Ftkxgp"Gxgpv
Kpvgthceg"hnciu<"H"/"Hqtyctf . "C"/"Ceegr . "KE"/"Kpvgtpcn"Eqr{ .
" " " "PU"/"Pgicvg"Ukipcn . "FR"/"Fqp)v"Rtgugtxg . "UR"/"Ukipcn"Rtgugpv .
" " " "KK"/"Kpvgtpcn"Kpvgtguv . "KF"/"Kpvgtpcn"fkupvgtguv . "NK"/"Nqecn"Kpvgtguv .
" " " "NF"/"Nqecn"fkupvgtguv . "OF"/"oECE"fgpkgf

* , . 447030303+"TRH"pdt<"2020202"Hnciu<"E
" "Vwppgn3"Hnciu<"C
" "IkicdkvGvjgtpgv316"Hnciu<"H"PU
" "Xncp768"Hnciu<"H"PU

*44040403 . 447030303+"TRH"pdt<"2020202"Hnciu<
" "Xncp768"Hnciu<"C
" "IkicdkvGvjgtpgv316"Hnciu<"H"PU
```

## Displaying IPv4 MFIB Information

The **show ip mfib** command displays detailed information about IP MFIB. To display detailed MFIB information, perform one of these tasks:

| Command                                                                              | Purpose                              |
|--------------------------------------------------------------------------------------|--------------------------------------|
| Tqwwgt% <b>"ujqy"kr"ohkd"kpvgthceg"</b> ] type name_                                 | Displays MFIB interface information  |
| Tqwwgt% <b>"ujqy"kr"ohkd"</b> ] jquvpkog"~"itqwrapwodgt"~" <b>inqdcn ~"xgtdqug_"</b> | Displays the MFIB route information. |
| Tqwwgt% <b>"ujqy"kr"ohkd"uwooct { "</b>                                              | Displays a summary of MFIB state     |
| Tqwwgt% <b>"ujqy"kr"ohkd"uvcvwu"</b>                                                 | Displays MFIB status                 |
| Tqwwgt% <b>"ujqy"kr"ohkd"eqwpv"</b>                                                  | Displays route and packet count data |

This example shows how to display the MFIB interface information:

```
Tqvwgt%"ujqy"kr"ohkd"kpvgthceeg"
KRx6"OwnvkecuV"Hqtyctfkpi"*OHKD+"uvcvwu<
""""Eqphkiwtcvkqp"Uvcvwu<"gpcdngf
""""Qrgtcvkapcn"Uvcvwu<"twppkpi
""""Kpkvkcnk|cvkqp"Uvcvg<"Twppkpi
""""Vqvcn"ukipcnkpi"rcemgu"swgwf<"2
""""Rtqeguu"Uvcvwu<"oc{"gpcdng"/"5"/"rkf"864
""""Vcdngu"31312"*cevxgslotkd1kq+
```

This example shows how to display the MFIB table:

```
Tqwgvt% "ujgy"kr"ohkd"447030303"
Gpvt{ "Hnciu<" "E"/"Fktgevn{"Eqppgevfgf."U"/"Ukipcn."KC"/"Kpjgtkv"C"hnci.
"GV"/"Fcvc"TCvg"Gzeggfufjtgugjnf."M"/"Mggrcnkxg
"FFG"/"Fcvc"Ftkxgp"Gxgpv."JY"/"Jctfyctg"Kpuvcnngf
KlQ"Kvgo"Hnciu<"KE"/"Kpgvtpcn"Eqr{."PR"/"Pqv"xncvhqto"uykvejgf.
"PU"/"Pgicvg"Ukipcnnkpi."UR"/"Ukipcn"Rtgugpv.
"C"/"Ceegr.v."H"/"Hqtyctf."TC"/"OTKD"Ceegr.v."TH"/"OTKD"Hqtyctf.
"OC"/"OHKD"Ceegr.v
Hqtyctfkpi"Eqwpvu<"Rmv"EqwplRmvu"rgt"ugeqpf1Cxi"Rmv"Uk|glMdkvu"rgt"ugeqpf
Qvjgt"eqwpvu<" "VqvcnlTRH"hckngflQvjgt"ftqru
KlQ"Kvgo"Eqwpvu<" "HU"Rmv"EqwplRU"Rmv"Eqwvpv
Fghcwnv
"* ,.447030303+"Hnciu<"E"JY
" "UY"Hqtyctfkpi<"2121212."Qvjgt<"21212
" "JY"Hqtyctfkpi<" "2121212."Qvjgt<"21212
" "Vwppgn3"Hnciu<"C
" "IkicdkvGvjgtpgv316"Hnciu<"H"PU
" " "Rmvu<"212
" "Xncp768"Hnciu<"H"PU
" " "Rmvu<"212
"*44040403.447030303+"Hnciu<"JY
" "UY"Hatyctfkpi<"2121212."Ovjgt<"5912159
```

```
" "JY"Hqtyctfkpi<" "75886;84:1456;8617341;5;:7:."Qvjgt<"21212
" "Xncp768"Hnciu<"C
" "IkicdkvGvjgtpgv316"Hnciu<"H"PU
" " "Rmvu<"212
```

This example shows how to display the MFIB summary:

```
Tqwvgt%"ujqy"kr"ohkd"uwooct{ "
Fghcwnv
"433"rtghkzgu"*4331212"hyflpqp/hyflfgngvgf+
"565"kqkvvgou"*5651212"hyflpqp/hyflfgngvgf+
"Hqtyctfkpi"rtghkzgu<"J323"*U.I+."32:"*,.I+."4"*,.Ilo+_
"Vcdng"kf"2z2."kpuvcpeg"2z79F576E:
"Fcvcdcug<"grqej"4
```

This example shows how to display the MFIB status:

```
Tqwvgt%"ujqy"kr"ohkd"uvcvwu"
KRx6"Ownvkecuv"Hqtyctfkpi"*OHKD+"uvcvwu<
" " "Eqphkiwtcvkqp"Uvcvwu<"gpcdngf
" " "Qrgtcvkgqpcn"Uvcvwu<"twppkpi
" " "Kpkvkcnc|cvkqp"Uvcvg<"Twppkpi
" " "Vqvcn"ukipcnnkpi"rcemgvu"swgwgf<"2
" " "Rtqeguu"Uvcvwu<"oc{"gpcdng"/"5"/"rkf"864
" " "Vcdngu"31312"*cevkxg1otkd1kq+
```

This example shows how to display the MFIB count:

```
Tqwvgt%"ujqy"kr"ohkd"eqwpv"
Hqtyctfkpi"Eqwpvu<"Rmv"Eqwpv1Rmvu"rgt"ugeqpf1Cxi"Rmv"Uk|g1Mknqdkvu"rgt"ugeqpf
Qvjgt"eqwpvu<" " " "Vqvcn1TRH"hckngf1Qvjgt"ftqru*QKH/pwnn."tcvg/nkokv"gve+
Fghcwnv
"433"tqwvgu."32:"*,.I+u."4"*,.Ilo+u
Itqwr<"44602020216
"TR/vtgg.
" "UY"Hqtyctfkpi<"2121212."Qvjgt<"21212
" "JY"Hqtyctfkpi<" "2121212."Qvjgt<"21212
Itqwr<"4460203062
"TR/vtgg.
" "UY"Hqtyctfkpi<"2121212."Qvjgt<"21212
Itqwr<"447030303
"TR/vtgg.
" "UY"Hqtyctfkpi<"2121212."Qvjgt<"21212
" "JY"Hqtyctfkpi<" "2121212."Qvjgt<"21212
" "Uqwteg<"44040403.
" "UY"Hqtyctfkpi<"2121212."Qvjgt<"5912159
" "JY"Hqtyctfkpi<" "5;:924::;641456;8317341;5;:69."Qvjgt<"21212
" "Vqvcnu"/"Uqwteg"eqwpv<"3."Rcemgv"eqwpv<"5;:924::;64"
```

## Viewing Directly Connected Entries

This example shows how to display the directly connected subnet entries:

```
Tqwvgt%"ujqy"rncvhtqto""jctfyctg""egh"~"kpenwfg"tgegkxg"
446" " "2020202154" " " " "tgegkxg
447" " "477047704770477154" " " " "tgegkxg
448" " "44040404154" " " " " "tgegkxg
449" " "44040402154" " " " " "tgegkxg
44:" " "4404040477154" " " " " "tgegkxg
44;" " "32032032032154" " " " " "tgegkxg
452" " "33030303154" " " " " "tgegkxg
453" " "33030302154" " " " " "tgegkxg
454" " "3303030477154" " " " " "tgegkxg
```

```
5422""446020202146""tgegkxg
3;:655"44602020216""tgegkxg
```

## Displaying IPv4 Hardware Switching Information

The **show platform hardware multicast routing ip** command displays detailed information about IP multicast Layer 3 switching. To display detailed IP multicast Layer 3 switching information, perform one of these tasks:

| Command                                                                                                                         | Purpose                                                             |
|---------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------|
| <code>Tqwvgt%"ujqy"rncvhqto"jctfyctg"ownvkecuv"tqwkpi"kr"eqpvtqn"</code>                                                        | Displays Layer 3 IP multicast control entries.                      |
| <code>Tqwvgt%"ujqy"rncvhqto"jctfyctg"ownvkecuv"tqwkpi"kr"<br/>]uqwteg kracfftguu_" ]itqwr"kracfftguu" ]fgvckn"~"xgtdqg__</code> | Displays IP multicast Layer 3 switching details for all interfaces. |
| <code>Tqwvgt%"ujqy"rncvhqto"kr"ownvkecuv"uwooct{"</code>                                                                        | Displays a summary of IP multicast Layer 3 switching information.   |

This example shows how to display the Layer 3 IP multicast control entries:

```
Tqwvgt%"ujqy"rncvhqto"jctfyctg"ownvkecuv"tqwkpi"kr"eqpvtqn"
KRx6"Ownvkecuv"EGH"Gpvtkgu"hqt"XRP%2
Hnciu<"E"/"Eqpvtqn"."D"/"Dkfmt"."e"/"EqRR"GNKH"."S"/"SqU"GNKH"."p"/"Pqp/rtkoc{"Kprwv
Uqwteg""Fguvkcpcvkqpllocum""TRH1FH""Hnciu""%rcemgvu""%d{vgu""
Qwvrwv"NKHu1Kphq""
-////////////////-////////////////-////////////////-////////////////-
//-////////////////-
, ""446020202146""/""E""/""
, ""446020305;154""/""E""/""
, ""4460203062154""/""E""/""
Hqwpf"5"gpvtkgu0
```

This example shows how to display the Layer 3 IP multicast switching information:

```
Tqwvgt%"ujqy"rncvhqto"jctfyctg"ownvkecuv"tqwkpi"kr"uqwteg"44040403"itqwr"447030303"fg"
KRx6"Ownvkecuv"EGH"Gpvtkgu"hqt"XRP%2

*44040403."447030303154+
"HKDCfft<"2z42"KQUXRP<"2"TrhV{rg<"UinTrhEjm"UteTrh<"Xn768
"ERz<"2"uauvctartk<"3"pqp/trh"ftqr<"2

"RKCF1Rvt<"2z3E223"Hqto cv<"KR"tfv<"qhh"gnkh<"2zE762;
"hnvt agp<"qhh"kfzaugn1dpfnagp<"2"fgeavvn<"qp"ovwakfz<"4*373:+
"RX<"3"tyv{rg<"OECUVaN5aTGYTKVG
"ogv5<"2z:222"ogv4<"2z2
"Rcemgvu<"2""D{vgu<"2""

"PRKCF1Rvt<"2z3E224"Hqto cv<"KR"tfv<"qhh"gnkh<"2zE762;
"hnvt agp<"qhh"kfzaugn1dpfnagp<"2"fgeavvn<"qhh
"RX<"2"tyv{rg<"PQaTGYTKVG
"uoc eatyv<"2"kravqaoce<"3
"Rcemgvu<"2""D{vgu<"2""
"OGV"qh hugv<"2z:222
""QKH""CflRvt""Gnkh""ET
""-////////////////-////////////////-////////////////-
""GFV/4E223""2z4E223""2z:622C""8V31V4
Hqwpf"3"gpvtkgu0
```

```
Tqwgvtg%"ujqy"rncvhtgo""jctfyctg"ownvkecuvtqwvkpi"kr"uwooct{"
KRx6"OwnvkecuvtEGH"Gpvtkgu"Uwooct{"hgt"XRPz2
"Unqv""""%ujewt""""""%U.I+""""""%,.I+""""""%,.Il0+""""""%Evtn
-////-/////////-/////////-/////////-/////////-/////////-/////////-
"8""""""425""""""323""""""323""""""3""""""5
```

The following commands can be used to check the multicast CoPP information:

This example shows how to display CoPP information:

Supervisor Engine 6T Software Configuration Guide, Release 15.4SY

```
Tqwgvt%"ujqy"rqnke{/ocr"eqpvtqn/rncpg"kprwv"encuu"encuu/eqrr/ocvej/kior"

"Eqpvtqn"Rncpg"Kpvgthceg"

"Ugtxkeg/rqnke{"kprwv<"rqnke{/fghcwnv/cwvqeqr

"Jctfyctg"Eqwpvgtu<"

""encuu/ocr<"encuu/eqrr/ocvej/kior"*ocvej/cp{+
""""Ocvej<"ceegu/itqwr"pcog"cen/eqrr/ocvej/kior
""""rqnkeg<
""""32222"rru"32222"nkokv"32222"gzvgpfgf"nkokv
""""Gctn"kp"unqv"8"<
""""2"rcemgvu
""""7"okpwwg"qhhtgfg"tcvg"2"rru
""""ciitgicvg/hqtyctfgf"2"rcemgvu
""""cevkqp<"ugv/fkuectf/encuu/vtcpuokv
""""gzegfgf"2"rcemgvu"cevkqp<"vtcpuokv
""""ciitgicvg/hqtyctf"2"rru"gzegfgf"2"rru"

"Ughvyctg"Eqwpvgtu<"

""Encuu/ocr<"encuu/eqrr/ocvej/kior"*ocvej/cp{+
""""935:"rcemgvu"."4892:6"d{vgu
""""7"okpwwg"qhhtgfg"tcvg"2222"dru"."ftqr"tcvg"2222"dru
""""Ocvej<"ceegu/itqwr"pcog"cen/eqrr/ocvej/kior
""""935:"rcemgvu"."4892:6"d{vgu
""""7"okpwwg"tcvg"2"dru
""""rqnkeg<
""""tcvg"32222"rru"."dwtuv"32222"rcemgvu
""""eqphqtogf"935:"rcemgvu"."935:"d{vgu="cevkqp<
""""ugv/fkuectf/encuu/vtcpuokv"6:
""""gzegfgf"2"rcemgvu"."2"d{vgu="cevkqp<
""""vtcpuokv"
""""eqphqtogf"2"rru"."gzegfgf"2"rru
```

## Source-Specific Multicast with IGMPv3, IGMP v3lite, and URD

For complete information and procedures about source-specific multicast (SSM) with IGMPv3, IGMP v3lite, and URL Rendezvous Directory (URD), see this URL:

[http://www.cisco.com/en/US/docs/ios-xml/ios/ipmulti\\_igmp/configuration/15-sy/imc-igmp-15-sy-book.html](http://www.cisco.com/en/US/docs/ios-xml/ios/ipmulti_igmp/configuration/15-sy/imc-igmp-15-sy-book.html)

## Configuring IPv4 Bidirectional PIM

- [Enabling IPv4 Bidirectional PIM Globally, page 44-27](#)
- [Configuring the Rendezvous Point for IPv4 Bidirectional PIM Groups, page 44-27](#)
- [Displaying IPv4 Bidirectional PIM Information, page 44-27](#)



## Enabling IPv4 Bidirectional PIM Globally

To enable IPv4 bidirectional PIM, perform this task:

| Command                                            | Purpose                                                |
|----------------------------------------------------|--------------------------------------------------------|
| <code>Tqwwgt*eqphki+% "kr"rko"dkfkt/gpcdng"</code> | Enables IPv4 bidirectional PIM globally on the switch. |

This example shows how to enable IPv4 bidirectional PIM on the switch:

```
Tqwwgt*eqphki+% "kr"rko"dkfkt/gpcdng"
Tqwwgt*eqphki+%
```

## Configuring the Rendezvous Point for IPv4 Bidirectional PIM Groups

To statically configure the rendezvous point for an IPv4 bidirectional PIM group, perform this task:

|        | Command                                                                                                                                       | Purpose                                                                                                                                                       |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+% "kr"rko"tr/cftguu" ip_address ceeguankuv"] qxgttkfg_</code>                                                             | Statically configures the IP address of the rendezvous point for the group. When you specify the <b>override</b> option, the static rendezvous point is used. |
| Step 2 | <code>Tqwwgt*eqphki+% "ceeguu/nkuv"access-list"] rgtokv"~" fgp{_"kracfftguu"</code>                                                           | Configures an access list.                                                                                                                                    |
| Step 3 | <code>Tqwwgt*eqphki+% "kr"rko"ugpf/tr/cppqwppeg" type pwodgt"ueqrg" vvnaxcnwg"] itqwr/nkuv"ceeguu/nkuv_" ] kpvgtxcn"ugeqpfu_" ] dkfkt_</code> | Configures the system to use auto-RP to configure groups for which the router will act as a rendezvous point (RP).                                            |
| Step 4 | <code>Tqwwgt*eqphki+% "kr"ceeguu/nkuv"uvcpfctf" access-list-name rgtokv"~" fgp{ "kracfftguu"</code>                                           | Configures a standard IP access list.                                                                                                                         |
| Step 5 | <code>Tqwwgt*eqphki+% "rncvhtqto"kr"ownvkecuv"</code>                                                                                         | Enables hardware-supported IP multicast.                                                                                                                      |

This example shows how to configure a static rendezvous point for an IPv4 bidirectional PIM group:

```
Tqwwgt*eqphki+% "kr"rko"tr/cfftguu"32020203"32"dkfkt"qxgttkfg"
Tqwwgt*eqphki+% "ceeguu/nkuv"32"rgtokv"446030202"20204770477"
Tqwwgt*eqphki+% "kr"rko"ugpf/tr/cppqwppeg"Nqqrddcem2"ueqrg"38"itqwr/nkuv"e43/tr/nkuv/2"dkfkt"
Tqwwgt*eqphki+% "kr"ceeguu/nkuv"uvcpfctf"e43/tr/nkuv/2"rgtokv"45205305303"20204770477"
```

## Displaying IPv4 Bidirectional PIM Information

To display IPv4 bidirectional PIM information, perform one of these tasks:

| Command                                                            | Purpose                                                                                                |
|--------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|
| <code>Tqwwgt%"ujqy"kr"rko"tr"ocrrkpi"] kp/wug_</code>              | Displays mappings between PIM groups and rendezvous points and shows learned rendezvous points in use. |
| <code>Tqwwgt%"ujqy"kr"ohkd"</code>                                 | Displays MFIB information for bidirectional PIM.                                                       |
| <code>Tqwwgt%"ujqy"rncvhtqto"jctfyctg"ownvkecuv"tqwwkpi"kr"</code> | Displays IP multicast Layer 3 switching details.                                                       |

| Command                                                              | Purpose                                                           |
|----------------------------------------------------------------------|-------------------------------------------------------------------|
| Tqwgvt% <b>"ujqy"rncvhtqto"uqhvyctg"ownvkecuv"tqwwkpi"eotr"kphq"</b> | Displays information about the DF indices and DF masks allocated. |
| Tqwgvt% <b>"ujqy"rncvhtqto"kr"ownvkecuv"dkfkt"</b>                   | Displays IPv4 bidirectional PIM information.                      |

This example shows how to display information about the PIM group and rendezvous point mappings:

```
Tqwgvt%"ujqy"kr"rko"tr"ocrrkpi"
RKO"Itqwr/vq/TR"Ocrckpiu
Vjku"u{uvgo"ku"cp"TR"*Cwvq/TR+
Vjku"u{uvgo"ku"cp"TR/ocrrkpi"cgpv
Itqwr*u+"4520530202138
"TR"820202082"*A+."x4x3"."dkfkt
"Kphq"uqwtg<820202082"*A+."gngvfgf"xkc"Cwvq/TR
"Wrvtgco<22<25<69"."gzrktgu<22<24<33
"TR"720202072"*A+."x4x3"."dkfkt
"Kphq"uqwtg<720202072"*A+."xkc"Cwvq/TR
"Wrvtgco<22<25<26"."gzrktgu<22<24<77
"TR"620202062"*A+."x4x3"."dkfkt
"Kphq"uqwtg<620202062"*A+."xkc"Cwvq/TR
"Wrvtgco<22<26<3;"."gzrktgu<22<24<5:
```

This example shows how to display information in the IP multicast routing table that is related to IPv4 bidirectional PIM:

```
Tqwgvt%"ujqy"kr"otqwg"dkfktgevkqpcn"
*,.44602020216+."22<39<3:1/."TR"42040404."hnciu<"D
"Dkfkf/Wrvvtgco<"Nqqrdecem4."TRH"pdt<"42040404
"Kpegokpi"kpvgthceg"nkuv<
"VgpiKicdkvGvjgtpgv51:."Ceegrkpi1Urctug/Fgpug
"VgpiKicdkvGvjgtpgv519."Ceegrkpi1Urctug/Fgpug
"IKicdkvGvjgtpgv3134."Ceegrkpi1Fgpug
"IKicdkvGvjgtpgv313."Ceegrkpi1Urctug/Fgpug
"Rqtve/cppgn4."Ceegrkpi1Urctug/Fgpug
"Nqqrdecem322."Ceegrkpi1Urctug/Fgpug
"Nqqrdecem32."Ceegrkpi1Urctug/Fgpug
"Nqqrdecem4."Ceegrkpi1Urctug/Fgpug

*,.446030303+."22<39<3:122<24<48."TR"42040404."hnciu<"DE
"Dkfkf/Wrvvtgco<"Pwnn."TRH"pdt"2020202
"Qwviqkpi"kpvgthceg"nkuv<
"VgpiKicdkvGvjgtpgv51:."Hqtyctf1Urctug/Fgpug."22<39<39122<24<48
```

This example shows how to display the MFIB table related to IPv4 bidirectional PIM:

```
Tqwgvt%"ujqy"kr"ohkd"
Gpvt{"Hnciu<"E"/"Fktgevn{"Eqppgevgf."U"/"Ukipcn."KC"/"Kpjgkvc"Chnci.
"GV"/"Fvcv"Tvvg"Gzeggf"Vjtgujqnf."M"/"Mggrenkxg
"FFG"/"Fvcv"Ftkxgp"Gxgpv."JY"/"Jctfyctg"Kpuvcnngf
K1Q"Kvgo"Hnciu<"KE"/"Kpvgtpcn"Eqv{"PR"/"Pqv"rncvhtqto"uykvejgf.
"PU"/"Pgicvg"Ukipcnkpi."UR"/"Ukipcn"Rtgugpv.
"C"/"Ceegr."H"/"Hqtyctf."TC"/"OTKD"Ceegr."TH"/"OTKD"Hqtyctf.
"OC"/"OHKD"Ceegr
Hqtyctfkpi"Eqwpvu<"Rmv"Eqwpv1Rmvu"rgt"ugeqpf1Cxi"Rmv"Uk|g1Mdkvu"rgt"ugeqpf
Qvjgt"eqwpvu<"Vqvcn1TRH"hcngf1Qvjgt"ftqru
K1Q"Kvgo"Eqwpvu<"HU"Rmv"Eqwpv1RU"Rmv"Eqwpv
Fghcwnv
",.44602020216+"Hnciu<"JY""A/"Kpfkecvgu"vjcv"Gpvt{"ku"kpucnngf"kp"jctfyctg
"UY"Hqtyctfkpi<"2121212."Qvjgt<"21212
"JY"Hqtyctfkpi<"2121212."Qvjgt<"21212
"IKicdkvGvjgtpgv313"Hnciu<"C
```

```

" " "IkidckvGvjgtpgv3134"Hnciu<"C
" " "VgpIkidckvGvjgtpgv519"Hnciu<"C
" " "VgpIkidckvGvjgtpgv51:"Hnciu<"C
" " "Rqtv/ejcppgn4"Hnciu<"C
" " "Nqqrdcem322"Hnciu<"C
" " "Nqqrdcem32"Hnciu<"C
" " "Nqqrdcem4"Hnciu<"C"H
" " " "Rmvu<"212
" " "Pwnn2"Hnciu<"C
" " *,.446030303+"Hnciu<"KC"JY
" " "UY"Hqtyctfkpi<"2121212."Qvjgt<"51512
" " "JY"Hqtyctfkpi<" "557938:15222132214565."Qvjgt<"21212"A// "Jy"Hqtyctfkpi"Uvcvkuvkeu"
" " "VgpIkidckvGvjgtpgv519"Hnciu<"H
" " " "Rmvu<"212
" " "VgpIkidckvGvjgtpgv51:"Hnciu<"H
" " " "Rmvu<"212

```

This example shows how to display the hardware-switching table related to IPv4 bidirectional PIM:

```
Tqvwgt%"ujyq"rncvhqto"jctfyctg"ownvkecuvtqwvkpi"kr"itqwr"44602020216"
KRx6"OwnvkecuvtEGH"Gpvtkgu"hqt"XRP%2
Hnciu<"E"/"Eqpvtqn."D"/"Dkfkt."e"/"EqRR"GNKH."S"/"SqU"GNKH."p"/"Pqp/rtkoc{"Kprwv
Ugwteg"*****Fguvpkcvcqplocum*****TRHlFH*****Hnciu"%rcemgvu*****%d{vgu*****
Qwrvw"NKHuIkPhq"*****
-/////////-/////////-////-////////-/////////
//-////////-
, "*****44602020216*****"2*****D*****"2*****
, "*****446030303154*****"2*****D*****875;223*****875;22322*****
Vg519."Vg51:"]4"gkh*u+_
Hqwpf"4"gpvtkgu0"
```

This example shows how to display the DF-index and DF mask information related to IPv4 bidirectional PIM:

Tqvwgt% "ujgy" rncvhqto "ughvyctg" ownvkecuv "tqwvkpi" eotr "kphq"

```
Tgrnkecvkqp"Oqfg"Kphqtoevkqp<
????????????????????????????
"tgrnaoqfg<"Kpitguu="rgpfkpiatgrnaoqfg<"Kpitguu=
"pqvkh{atgrnaoqfg<"Kpitguu="tgrnaoqfgaejpiakpqtqi<"2=
"tgrnaoqfgapqvkqhargpfpki<"2
```

```
Tguqwt eg"Kphqtocvkqp<
????????????????????
" "hkdahwnnaocum<"2z2="cflahwnnaocum<"2z2=
" "ogvahwnnaocum<"2z2="ogvawpcxcknaocum<"2z2
```

```
Inqdcn"JC"Kphqtocvkqp<
????????????????????
"tgeqpuvtwevakpartqi<"2="tgeqpuvtwevaneaocum<"2z2
```

```
Xth"PCog<"T="Xth"KF<"5="Fh"Kfz"Cnnqecvgf<" := "ohkdauyggraocum<"2z2
??
" "FH"Kfz"Kphq"hqt"fhakfz<"2
" "????????????????????????????????
" "eqnnaqdl<"2z7526;5EE="ch<krx6="fhauvcvg<"WUGF
" " "FH"Egnngevkqp"Qdl"Kphq
" " "????????????????????????????
" " "tghaewpvc<"3="kfaewpvc<"6="crrafcvc<"2z3;F3F3C:="xthakf<"5="fhakfz<"2="engcpwr<"2
" " "FH"Ugv
" " "????????
" " "Vw322"*2z542226294+. "Vw32: "*2z54222629C+. "Pw2"*2z54222629D+. "Vw5"*2z54222629H+. "
```

```

"FH"Kfz"Kphq"hqt"fhakfz<"3
"????????????????????????????
"eqnnaqdl<"2z7526;5GE="ch<krx6="fhauvcvg<"WUGF
"FH"Eqnngdevkqp"Qdl"Kphq
"????????????????????????
"tghaeqwpv<"3="kfaeqwpv<"6="crrafcvc<"2z3;E5E962="xthakf<"5="fhakfz<"3="engcpwr<"2
"FH"Ugv
"????????
"Vw323"*2z542226295+. "Vw32:"*2z54222629C+. "Pw2"*2z54222629D+. "Vw5"*2z54222629H+. "
"FH"Kfz"Kphq"hqt"fhakfz<"4
"????????????????????????
"eqnnaqdl<"2z7526;58E="ch<krx6="fhauvcvg<"WUGF
"FH"Eqnngdevkqp"Qdl"Kphq
"????????????????????????
"tghaeqwpv<"3="kfaeqwpv<"6="crrafcvc<"2z3;F6F;5="xthakf<"5="fhakfz<"4="engcpwr<"2
"FH"Ugv
"????????
"Vw324"*2z542226296+. "Vw32:"*2z54222629C+. "Pw2"*2z54222629D+. "Vw5"*2z54222629H+. "
"FH"Kfz"Kphq"hqt"fhakfz<"5
"????????????????????????
"eqnnaqdl<"2z7526;4GE="ch<krx6="fhauvcvg<"WUGF
"FH"Eqnngdevkqp"Qdl"Kphq
"????????????????????????
"tghaeqwpv<"3="kfaeqwpv<"6="crrafcvc<"2z3;EG855="xthakf<"5="fhakfz<"5="engcpwr<"2
"FH"Ugv
"????????
"Vw325"*2z542226297+. "Vw32:"*2z54222629C+. "Pw2"*2z54222629D+. "Vw5"*2z54222629H+. "
"FH"Kfz"Kphq"hqt"fhakfz<"6
"????????????????????????
"eqnnaqdl<"2z7526;52E="ch<krx6="fhauvcvg<"WUGF
"FH"Eqnngdevkqp"Qdl"Kphq
"????????????????????????
"tghaeqwpv<"3="kfaeqwpv<"6="crrafcvc<"2z7E2;4;6="xthakf<"5="fhakfz<"6="engcpwr<"2
"FH"Ugv
"????????
"Vw326"*2z542226298+. "Vw32:"*2z54222629C+. "Pw2"*2z54222629D+. "Vw5"*2z54222629H+. "
"FH"Kfz"Kphq"hqt"fhakfz<"7
"????????????????????????
"eqnnaqdl<"2z7526;5CE="ch<krx6="fhauvcvg<"WUGF
"FH"Eqnngdevkqp"Qdl"Kphq
"????????????????????????
"tghaeqwpv<"3="kfaeqwpv<"6="crrafcvc<"2z3;F6F9HE="xthakf<"5="fhakfz<"7="engcpwr<"2
"FH"Ugv
"????????
"Vw327"*2z542226299+. "Vw32:"*2z54222629C+. "Pw2"*2z54222629D+. "Vw5"*2z54222629H+. "
"FH"Kfz"Kphq"hqt"fhakfz<"8
"????????????????????????
"eqnnaqdl<"2z7526;56E="ch<krx6="fhauvcvg<"WUGF
"FH"Eqnngdevkqp"Qdl"Kphq
"????????????????????????
"tghaeqwpv<"3="kfaeqwpv<"6="crrafcvc<"2z3;F6FE7="xthakf<"5="fhakfz<"8="engcpwr<"2
"FH"Ugv
"????????
"Vw328"*2z54222629;+. "Vw32:"*2z54222629C+. "Pw2"*2z54222629D+. "Vw5"*2z54222629H+. "
"FH"Kfz"Kphq"hqt"fhakfz<"9
"????????????????????????
"eqnnaqdl<"2z7526;5:E="ch<krx6="fhauvcvg<"WUGF
"FH"Eqnngdevkqp"Qdl"Kphq
"????????????????????????
"tghaeqwpv<"3="kfaeqwpv<"6="crrafcvc<"2z7E2;CF86="xthakf<"5="fhakfz<"9="engcpwr<"2
"FH"Ugv
"????????
"Vw329"*2z54222629;+. "Vw32:"*2z54222629C+. "Pw2"*2z54222629D+. "Vw5"*2z54222629H+.

```

## Using IPv4 Debug Commands

Table 44-1 describes IPv4 multicast Layer 3 switching debug commands that you can use to troubleshoot IP multicast Layer 3 switching problems.

Table 44-1 IP Multicast Layer 3 Switching Debug Commands

| Command                                                                                                                                                                              | Description                                                                                                   |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
| <code>]pq "fgdwi"rncvqhcto"ughvyctg"ownvkecuv"tqvwkpi"eotr"}gxgpv"~"gttqt;"</code><br><code>]xgtdqug_"</code>                                                                        | Debug CMRP related events and errors.                                                                         |
| <code>]pq "fgdwi"rncvqhcto"ughvyctg"ownvkecuv"tqvwkpi"gfe"ugtuxt"</code><br><code>]gxgpv ~ gttqt_"</code>                                                                            | Debug errors and events for the egress distribution server component.                                         |
| <code>]pq "fgdwi"rncvqhcto"ughvyctg"ownvkecuv"tqvwkpi"gfe"enkgpv"</code><br><code>]gxgpv ~ gttqt_"</code>                                                                            | Debug errors and events for the egress distribution client component.                                         |
| <code>]pq "fgdwi"rncvqhcto"ughvyctg"ownvkecuv"tqvwkpi"jcn"]gxgpv ~ gttqt_"</code>                                                                                                    | Debug errors and events for the multicast hardware abstraction layer.                                         |
| <code>]pq "fgdwi"rncvqhcto"ughvyctg"ownvkecuv"tqvwkpi"eohkd"]gxgpv"~"gttqt_"</code>                                                                                                  | Debug errors and events for the Constellation MFIB component.                                                 |
| <code>]pq "fgdwi"rncvqhcto"ughvyctg"ogv"]gxgpv"~"gttqt"~"fgvckn"~"cnn_"</code>                                                                                                       | Debug errors and events for MET manager.                                                                      |
| <code>]pq "fgdwi"rncvqhcto"ughvyctg"hknvgt"hknvgtakf"</code><br><code>]kr }fguvkpcvkqp ~ uqwtg;"kracfftguu"]ocum_"</code><br><code>~ uvtkpi }gzenwfg ~ kpenwfg;"vgzvauvtkpi;"</code> | Turns on filtering for debug messages based on IPv4 destination address or source address or an input string. |

## Redundancy for Multicast Traffic

Redundancy for multicast traffic requires the following conditions:

- Unicast routing protocol such as OSPF or EIGRP:  
PIM uses RPF checks on the unicast routing table to determine the proper paths for multicast data to traverse. If a unicast routing path changes, PIM relies upon the unicast routing protocol (OSPF) to properly converge, so that the RPF checks used by PIM continue to work and show valid unicast paths to and from the source IP address of the server sourcing the multicast stream.
- PIM configured on all related Layer 3 interfaces:  
The unicast routing table is used to do path selection for PIM. PIM uses RPF checks to ultimately determine the shortest path tree (SPT) between the client (receiver VLAN) and the source (multicast VLAN). Therefore, the objective of PIM is to find the shortest unicast path between the receiver subnet and the source subnet. You do not need to configure anything else for multicast when the unicast routing protocol is working as expected and PIM is configured on all the Layer 3 links associated with the unicast routing protocol.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





# IGMP Snooping for IPv4 Multicast Traffic

- [Prerequisites for IGMP Snooping, page 45-1](#)
- [Restrictions for IGMP Snooping, page 45-1](#)
- [Information About IGMP Snooping, page 45-2](#)
- [Default Settings for IGMP Snooping, page 45-8](#)
- [How to Configure IGMP Snooping, page 45-8](#)



## Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- To constrain IPv6 Multicast traffic, see [Chapter 52, “IPv6 MLD Snooping.”](#)



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for IGMP Snooping

None.

## Restrictions for IGMP Snooping

- [General IGMP Snooping Restrictions, page 45-2](#)
- [IGMP Snooping Querier Restrictions, page 45-2](#)

## General IGMP Snooping Restrictions

- Multicast packets are not bridged in a VLAN to local receivers that send IGMP joins when PIM snooping is enabled in the VLAN and IGMP snooping is disabled in the VLAN. ([CSCta03980](#))
- For more information on IP multicast and IGMP, see RFC 1112 and RFC 2236.
- IGMP snooping supports private VLANs. Private VLANs do not impose any restrictions on IGMP snooping.
- IGMP snooping constrains traffic in MAC multicast groups 0100.5e00.0001 to 0100.5eff.ffff.
- IGMP snooping does not constrain Layer 2 multicasts generated by routing protocols.

## IGMP Snooping Querier Restrictions

- The IGMP snooping querier does not support querier elections. Enable the IGMP snooping querier on only one switch in the VLAN. ([CSCsk48795](#))
- Configure the VLAN in global configuration mode (see [Chapter 26, “Virtual Local Area Networks \(VLANs\)”](#)).
- Configure an IP address on the VLAN interface (see [Chapter 35, “Layer 3 Interfaces”](#)). When enabled, the IGMP snooping querier uses the IP address as the query source address.
- If there is no IP address configured on the VLAN interface, the IGMP snooping querier does not start. The IGMP snooping querier disables itself if the IP address is cleared. When enabled, the IGMP snooping querier restarts if you configure an IP address.
- The IGMP snooping querier sends IGMPv3 querier messages. Although the IGMP version of the querier messages is not configurable, the querier is compatible with IGMPv2 hosts.
- When enabled, the IGMP snooping querier starts after 60 seconds with no IGMP traffic detected from a multicast router. If IGMP traffic from a multicast router, or from another IGMP snooping querier in the VLAN, is detected after the IGMP snooping querier has started, the querier will disable itself.
- QoS does not support IGMP packets when IGMP snooping is enabled.
- With Release 15.1(1)SY1 and later releases, IGMP snooping and PIM snooping constrain VPLS multicast traffic.

## Information About IGMP Snooping

- [IGMP Snooping Overview, page 45-3](#)
- [Joining a Multicast Group, page 45-3](#)
- [Leaving a Multicast Group, page 45-5](#)
- [Information about the IGMP Snooping Querier, page 45-6](#)
- [Information about IGMP Version 3 Support, page 45-6](#)



## IGMP Snooping Overview

IGMP snooping allows switches to examine IGMP packets and make forwarding decisions based on their content. You can configure the switch to use IGMP snooping in subnets that receive IGMP queries from either IGMP or the IGMP snooping querier. IGMP snooping constrains IPv4 multicast traffic at Layer 2 by configuring Layer 2 LAN ports dynamically to forward IPv4 multicast traffic only to those ports that want to receive it.

Some applications use a single unicast cluster IP address and multicast cluster MAC address. Multicast traffic addressed to a unicast cluster IP address is forwarded to the last-hop router that is configured with the shared multicast MAC address. To support cluster-addressed multicast traffic, assign a static multicast MAC address for the destination IP address of the end host or cluster.

You can configure the IGMP snooping lookup method for each VLAN. Layer 3 IGMP snooping lookup uses destination IP addresses in the Layer 2 multicast table (this is the default). Layer 2 IGMP snooping lookup uses destination MAC addresses in the Layer 2 multicast table.

**Note**

Changing the lookup mode is disruptive. Multicast forwarding is not optimal until all multicast entries are programmed with the new lookup mode. Also, if 32 IP addresses are mapped to a single MAC address, forwarding on the device might be suboptimal.

IGMP, which runs at Layer 3 on a multicast router, generates Layer 3 IGMP queries in subnets where the multicast traffic needs to be routed.

You can configure the IGMP snooping querier on the switch to support IGMP snooping in subnets that do not have any multicast router interfaces. For more information about the IGMP snooping querier, see the [“Enabling the IGMP Snooping Querier” section on page 45-9](#).

IGMP (on a multicast router) or, locally, the IGMP snooping querier, sends out periodic general IGMP queries that the switch forwards through all ports in the VLAN and to which hosts respond. IGMP snooping monitors the Layer 3 IGMP traffic.

**Note**

If a multicast group has only sources and no receivers in a VLAN, IGMP snooping constrains the multicast traffic to only the multicast router ports.

## Joining a Multicast Group


Hosts join multicast groups either by sending an unsolicited IGMP join message or by sending an IGMP join message in response to a general query from a multicast router (the switch forwards general queries from multicast routers to all ports in a VLAN).

In response to an IGMP join request, the switch creates an entry in its Layer 2 forwarding table for the VLAN on which the join request was received. When other hosts that are interested in this multicast traffic send IGMP join requests, the switch adds them to the existing Layer 2 forwarding table entry. The switch creates only one entry per VLAN in the Layer 2 forwarding table for each multicast group for which it receives an IGMP join request.

IGMP snooping suppresses all but one of the host join messages per multicast group and forwards this one join message to the multicast router.

The switch forwards multicast traffic for the multicast group specified in the join message to the interfaces where join messages were received (see [Figure 45-1](#)).

**Figure 45-1**      **Initial IGMP Join Message**




If IP-based is configured, IGMP snooping forwarding table has the following entry. The switch engine matches on the destination IP address of multicast data packets. If they are 224.1.2.3, send them to the host that has joined the group and multicast routers.

If MAC-based is configured, the entry is as follows. In this case, the switch engine matches on the destination MAC address of the packets. The packets with 0100.5e01.0203 are sent to the host that has joined the group and multicast routers.

Supervisor Engine 6T Software Configuration Guide, Release 15.4SY

If another host (for example, Host 4) sends an unsolicited IGMP join message for the same group (Figure 45-2), the CPU receives that message and adds the port number of Host 4 to the forwarding table. Because the forwarding table directs IGMP messages only to the CPU, the message is not flooded to other ports. Any known multicast traffic is forwarded to the group and not to the CPU.

Figure 45-2 Second Host Joining a Multicast Group



## Leaving a Multicast Group

- [Normal Leave Processing, page 45-5](#)
- [Immediate-Leave Processing, page 45-6](#)

### Normal Leave Processing

Interested hosts must continue to respond to the periodic general IGMP queries. As long as at least one host in the VLAN responds to the periodic general IGMP queries, the multicast router continues forwarding the multicast traffic to the VLAN. When hosts want to leave a multicast group, they can either ignore the periodic general IGMP queries (called a “silent leave”), or they can send a group-specific IGMPv2 leave message.

When IGMP snooping receives a group-specific IGMPv2 leave message from a host, it sends out a MAC-based general query to determine if any other devices connected to that interface are interested in traffic for the specific multicast group. If IGMP snooping does not receive an IGMP Join message in response to the general query, it assumes that no other devices connected to the interface are interested in receiving traffic for this multicast group, and it removes the interface from its Layer 2 forwarding table entry for that multicast group. If the leave message was from the only remaining interface with hosts interested in the group and IGMP snooping does not receive an IGMP Join in response to the

general query, it removes the group entry and relays the IGMP leave to the multicast router. If the multicast router receives no reports from a VLAN, the multicast router removes the group for the VLAN from its IGMP cache.

The interval for which the switch waits before updating the table entry is called the “last member query interval.” To configure the interval, enter the **ip igmp snooping last-member-query-interval** *interval* command.

## Immediate-Leave Processing

IGMP snooping immediate-leave processing allows IGMP snooping to remove a Layer 2 LAN interface from the forwarding-table entry without first sending out IGMP group-specific queries to the interface. Upon receiving a group-specific IGMPv2 leave message, IGMP snooping immediately removes the interface from the Layer 2 forwarding table entry for that multicast group, unless a multicast router was learned on the port. Immediate-leave processing improves bandwidth management for all hosts on a switched network.



### Note

Use immediate-leave processing only on VLANs where only one host is connected to each Layer 2 LAN port. If immediate-leave is enabled in VLANs where more than one host is connected to a Layer 2 LAN port, some hosts might be dropped inadvertently. Immediate-leave processing is supported only with IGMP version 2 and 3 hosts.

## Information about the IGMP Snooping Querier

Use the IGMP snooping querier to support IGMP snooping in a VLAN where PIM and IGMP are not configured because the multicast traffic does not need to be routed.

In a network where IP multicast routing is configured, the IP multicast router acts as the IGMP querier. If the IP-multicast traffic in a VLAN only needs to be Layer 2 switched, an IP-multicast router is not required, but without an IP-multicast router on the VLAN, you must configure another switch as the IGMP querier so that it can send queries.

When enabled, the IGMP snooping querier sends out periodic IGMPv3 queries that trigger IGMP report messages from the switch that wants to receive IP multicast traffic. IGMP snooping listens to these IGMP reports to establish appropriate forwarding.

Configure one switch as the IGMP snooping querier in each VLAN that is supported on switches that use IGMP to report interest in IP multicast traffic.

You can configure a switch to generate IGMP queries on a VLAN regardless of whether or not IP multicast routing is enabled.

## Information about IGMP Version 3 Support

- [IGMP Version 3 Support Overview, page 45-7](#)
- [IGMPv3 Immediate-Leave Processing, page 45-7](#)
- [Proxy Reporting, page 45-7](#)
- [Explicit Host Tracking, page 45-8](#)



reports from all hosts to each group or channel (S,G). Only the first report to the discovered multicast routers is forwarded; the rest of the reports are suppressed. For IGMPv1 and IGMPv2, the time of suppression is the report response time indicated in the general query message. For IGMPv3, suppression occurs for the entire general query interval.

**Note**

The states are maintained only in software and used for explicit host tracking and statistics collection.

## Explicit Host Tracking

IGMPv3 supports explicit tracking of membership information on any port. The explicit-tracking database is used for immediate-leave processing for IGMPv3 hosts, proxy reporting, and statistics collection. When explicit tracking is enabled on a VLAN, the IGMP snooping software processes the IGMPv3 report it receives from a host and builds an explicit-tracking database that contains the following information:

- The port connected to the host
- The channels reported by the host
- The filter mode for each group reported by the host
- The list of sources for each group reported by the hosts
- The router filter mode of each group
- For each group, the list of hosts requesting the source

**Note**

- When explicit tracking is enabled and the switch is working in proxy-reporting mode, the router may not be able to track all the hosts behind a VLAN interface.

## Default Settings for IGMP Snooping

None.

## How to Configure IGMP Snooping

- [Enabling the IGMP Snooping Querier, page 45-9](#)
- [Enabling IGMP Snooping, page 45-9](#)
- [Configuring the IGMP Snooping Lookup Method, page 45-11](#)
- [Configuring a Static Connection to a Multicast Receiver, page 45-11](#)
- [Configuring a Multicast Router Port Statically, page 45-12](#)
- [Configuring the IGMP Snooping Query Interval, page 45-12](#)
- [Enabling IGMP Snooping Immediate-Leave Processing, page 45-13](#)
- [Configuring IGMPv3 Snooping Explicit Host Tracking, page 45-13](#)
- [Displaying IGMP Snooping Information, page 45-14](#)

**Note**

To use IGMP snooping, configure a Layer 3 interface in the subnet for multicast routing (see [Chapter 44, “IPv4 Multicast Layer 3 Features”](#)) or enable the IGMP snooping querier in the subnet (see the “Enabling the IGMP Snooping Querier” section on page 45-9).

## Enabling the IGMP Snooping Querier

Use the IGMP snooping querier to support IGMP snooping in a VLAN where PIM and IGMP are not configured because the multicast traffic does not need to be routed. To enable the IGMP snooping querier in a VLAN, perform this task:

|        | Command                                                                                | Purpose                                        |
|--------|----------------------------------------------------------------------------------------|------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "kr"kior"upqqrkpi"swgtkgt "</code>                               | Enables the IGMP snooping querier globally.    |
| Step 2 | <code>Tqvwgt*eqphki+% "xncp"eqphkiwtcvkqp"vlan_ID"</code>                              | Selects a VLAN.                                |
| Step 3 | <code>Tqvwgt*eqphki/xncp/eqphki+% "kr"kior"upqqrkpi"swgtkgt "cfftguu"ip_address</code> | Assigns the IP address.                        |
| Step 4 | <code>Tqvwgt*eqphki/xncp/eqphki+% "kr"kior"upqqrkpi"swgtkgt "</code>                   | Enables the IGMP snooping querier on the VLAN. |
| Step 5 | <code>Tqvwgt*eqphki/xncp/eqphki+% "gpf"</code>                                         | Exits configuration mode.                      |

This example shows how to enable the IGMP snooping querier on VLAN 200 and verify the configuration:

```
Tqvwgt*eqphki+% "kr"kior"upqqrkpi"swgtkgt "
Tqvwgt*eqphki+% "xncp"eqphkiwtcvkqp"422 "
Tqvwgt*eqphki/xncp/eqphki+% "kr"kior"upqqrkpi"swgtkgt "cfftguu"32030303 "
Tqvwgt*eqphki/xncp/eqphki+% "kior"upqqrkpi"swgtkgt "
Tqvwgt*eqphki/xncp/eqphki+% "gpf"
```

## Enabling IGMP Snooping

- [Enabling IGMP Snooping Globally, page 45-9](#)
- [Enabling IGMP Snooping in a VLAN, page 45-10](#)

### Enabling IGMP Snooping Globally

To enable IGMP snooping globally, perform this task:

|        | Command                                         | Purpose                   |
|--------|-------------------------------------------------|---------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "kr"kior"upqqrkpi"</code> | Enables IGMP snooping.    |
| Step 2 | <code>Tqvwgt*eqphki+% "gpf"</code>              | Exits configuration mode. |

This example shows how to enable IGMP snooping globally and verify the configuration:

```
Tqvwgt*eqphki+% "kr"kior"upqqrkpi"
Tqvwgt*eqphki+% "gpf"
Tqvwgt% "ujqy"kr"kior"kpvgthceg"xncp"422 "~"kpenwfg"inqdcnn{ "
```

```
"KIOR"upqqrkpi"ku"inqdcnn{"gpcdnfg
Tqwvgt%
```

## Enabling IGMP Snooping in a VLAN

To enable IGMP snooping in a VLAN, perform this task:

|        | Command                                                           | Purpose                   |
|--------|-------------------------------------------------------------------|---------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"xncp"eqphkiwtcvkqp</b>"vlan_ID"</code>   | Selects a VLAN.           |
| Step 2 | <code>Tqwvgt*eqphki/xncp/eqphki+%<b>"kr"kior"upqqrkpi"</b></code> | Enables IGMP snooping.    |
| Step 3 | <code>Tqwvgt*eqphki/xncp/eqphki+%<b>"gpf"</b></code>              | Exits configuration mode. |

This example shows how to enable IGMP snooping on VLAN 25 and verify the configuration:

```
Tqwvgt%"xncp"eqphkiwtcvkqp"47"
Tqwvgt*eqphki/xncp/eqphki+%"kr"kior"upqqrkpi"
Tqwvgt*eqphki/xncp/eqphki+%"gpf"
Tqwvgt%"ujgy"kr"kior"upqqrkpi"xncp"47
Inqdcn"KIOR"Upqqrkpi"eqphkiwtcvkqp<
////////////////////////////////////
KIOR"upqqrkpi"Qrgt"Uvcvg" <"Gpcdnfg
KIORx5"upqqrkpi" <"Gpcdnfg
Tgrqtv"uwrrtguukqp" <"Fkucdnfg
GJV"FD"nkokvlegwpv" <"3222214
VEP"uqnkekv"swgt{ " <"Fkucdnfg
Tqdwuvpguu"xctkcdng" <"4
Ncuv"ogodgt"swgt{ "eqwpv" <"5
Ncuv"ogodgt"swgt{ "kpvgtxcn" <"3222
Ejgem"VVN?3" <"Pq
Ejgem"Tqwvgt/Cngtv/Qrvkqp" <"Pq

Xncp"47<
////////
KIOR"upqqrkpi"Cfokp"Uvcvg" <"Gpcdnfg
KIOR"upqqrkpi"Qrgt"Uvcvg" <"Gpcdnfg
KIORx4"koogfkcv"ngcxg" <"Fkucdnfg
Gzrnkekv"jquv"vtcemkpi" <"Gpcdnfg
Tgrqtv"uwrrtguukqp" <"Gpcdnfg
Tqdwuvpguu"xctkcdng" <"4
Ncuv"ogodgt"swgt{ "eqwpv" <"4
Ncuv"ogodgt"swgt{ "kpvgtxcn" <"3222
GJV"FD"nkokvlegwpv" <"3222214
Ejgem"VVN?3" <"[gu
Ejgem"Tqwvgt/Cngtv/Qrvkqp" <"[gu
Swgt{ "Kpvgtxcn" <"322
Ocz"tgurqpug"Vkog" <"32222
Tqwvgt%
```



## Configuring the IGMP Snooping Lookup Method

To configure the IGMP snooping lookup method for a VLAN, perform this task:

| Command                                                                          | Purpose                                                                                                                                                                                                                                                                                       |
|----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwgvt*eqphki/xncp/eqphki+% "ownvkecu"upqqrkpi "nqgmwr" }kr"~"oce;"</code> | Configures the IGMP snooping lookup method for the VLAN. <ul style="list-style-type: none"> <li>Enter the <b>ip</b> keyword to use IP addresses to forward multicast traffic.</li> <li>Enter the <b>mac</b> keyword to use destination MAC addresses to forward multicast traffic.</li> </ul> |



### Note

Changing the lookup mode is disruptive. Multicast forwarding is not optimal until all multicast entries are programmed with the new lookup mode. Also, if 32 IP addresses are mapped to a single MAC address, forwarding on the device might be suboptimal.

## Configuring a Static Connection to a Multicast Receiver

To configure a static connection to a multicast receiver, perform this task:

| Command                                                                                                                    | Purpose                                                 |
|----------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------|
| <code>Tqwgvt*eqphki+% "oce"cfftgau/vcdng"uvcvke"oceacfft"xncp" xncpakf"kpvgthceg" type slot/port"]fkucdng/upqqrkpi_</code> | Configures a static connection to a multicast receiver. |

When you configure a static connection, enter the **disable-snooping** keyword to prevent multicast traffic addressed to the statically configured multicast MAC address from also being sent to other ports in the same VLAN.

This example shows how to configure a static connection to a multicast receiver:

```
Tqwgvt*eqphki+% "oce"cfftgau/vcdng"uvcvke"227205g:f08622"xncp"34"kpvgthceg"ikicdkvgvjgtpgv"719"
```

The above static mac command can be used when the lookup type in the VLAN is MAC-base. Irrespective of lookup type, the following commands can be used to configure static connection to a multicast receiver for a group or a group and from a specific source.

```
Tqwgvt*eqphki+% "xncp"eqphkiwtcvkqp"422
Tqwgvt*eqphki/xncp/eqphki+% "kr"kior"upqqrkpi"uvcvke"446030405"kpvgthceg"i5133
Tqwgvt*eqphki/xncp/eqphki+% "kr"kior"upqqrkpi"uvcvke"446030405"uqwtg"42030303"kpvgthceg"1k5134
```

## Configuring a Multicast Router Port Statically

To configure a static connection to a multicast router, perform this task:

|        | Command                                                                                                   | Purpose                                               |
|--------|-----------------------------------------------------------------------------------------------------------|-------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki/xncp/eqphki+%<b>"kr"kior"upqqrkpi"</b>otqwgvt<b>"kpvgtthceg"</b>type slot/port</code> | Configures a static connection to a multicast router. |
| Step 2 | <code>Tqwgvt*eqphki/xncp/eqphki+%<b>"gpf"</b></code>                                                      | Exits configuration mode.                             |

The interface to the router must be in the VLAN where you are entering the command, the interface must be administratively up, and the line protocol must be up.

This example shows how to configure a static connection to a multicast router:

```
Tqwgvt*eqphki/kh+%"kr"kior"upqqrkpi"otqwgvt"kpvgtthceg"ikicdkvgvjgtpgv"718"
```

## Configuring the IGMP Snooping Query Interval

You can configure the interval for which the switch waits after sending a group-specific query to determine if hosts are still interested in a specific multicast group.



### Note

When both IGMP immediate-leave processing and the IGMP query interval are configured, immediate-leave processing takes precedence.

To configure the interval for the IGMP snooping queries sent by the switch, perform this task:

|        | Command                                                                                              | Purpose                                                                                                                                |
|--------|------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%<b>"xncp"eqphkiwtcvkqp"</b>vlan_ID</code>                                       | Selects a VLAN.                                                                                                                        |
| Step 2 | <code>Tqwgvt*eqphki/xncp/eqphki+%<b>"kr"kior"upqqrkpi"</b>ncuv/ogodgt/swgt{/kpvgtxcn"kpvgtxcn</code> | Configures the interval for the IGMP snooping queries sent by the switch. Default is 1 second. Valid range is 100 to 999 milliseconds. |

This example shows how to configure the IGMP snooping query interval:

```
Tqwgvt*eqphki/xncp/eqphki+%"kr"kior"upqqrkpi"ncuv/ogodgt/swgt{/kpvgtxcn"422
Tqwgvt*eqphki/xncp/eqphki+%"gzkv"
Tqwgvt%"ujqy"kr"kior"kpvgthceg"xncp"422"~"kpenwfg"ncuv"
 KIOR"upqqrkpi"ncuv"ogodgt"swgt{"kpvgtxcn"qp"vjku"kpvgthceg"ku"422"ou
```

## Enabling IGMP Snooping Immediate-Leave Processing

Fast-leave configuration applies to IGMP version 2 hosts only. To enable IGMP snooping fast-leave processing in a VLAN, perform this task:

|        | Command                                                                                      | Purpose                                                                                                  |
|--------|----------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%<b>"xncp"eqphkiwtcvkqp</b>"vlan_ID"</code>                              | Selects a VLAN.                                                                                          |
| Step 2 | <code>Tqvwgt*eqphki/xncp/eqphki+%<b>"kr"kior"upqqrkpi"</b></code>                            | Enables IGMP snooping. This step is only necessary if IGMP snooping is not already enabled on this VLAN. |
| Step 3 | <code>Tqvwgt*eqphki/xncp/eqphki+%<b>"kr"kior"upqqrkpi"</b><br/><b>koogfkcvg/ngcxg</b></code> | Enables IGMP immediate-leave processing in the VLAN.                                                     |

This example shows how to enable IGMP snooping immediate-leave processing for IGMP version 2 hosts on the VLAN 200 interface, and how to verify the configuration:

```
Tqvwgt%"kpvgtthceg"xncp"422"
Tqvwgt*eqphki/xncp/eqphki+%"kr"kior"upqqrkpi"
Tqvwgt*eqphki/xncp/eqphki+%"kr"kior"upqqrkpi"koogfkcvg/ngcxg"
Eqphkiwtkpi"koogfkcvg"ngcxgqp"xncp"422
Tqvwgt*eqphki/xncp/eqphki+%"gpf"
Tqvwgt%"ujqy"kr"kior"kpvgtthceg"xncp"422"~"kpenwfg"koogfkcvg/ngcxg"
KIOR"upqqrkpi"koogfkcvg/ngcxg"ku"gpdcngf"qp"vjku"kpvgthceg"
```

## Configuring IGMPv3 Snooping Explicit Host Tracking

To enable IGMPv3 snooping explicit host tracking on a VLAN, perform this task:

|        | Command                                                                                                     | Purpose                                                  |
|--------|-------------------------------------------------------------------------------------------------------------|----------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%<b>"xncp"eqphkiwtcvkqp</b>"vlan_ID"</code>                                             | Selects a VLAN.                                          |
| Step 2 | <code>Tqvwgt*eqphki/xncp/eqphki+%<b>"kr"kior"upqqrkpi"</b><br/><b>gznrkekv/vtcmekpi"nkokv"nkokv"</b></code> | Enable IGMPv3 snooping explicit host tracking in a VLAN. |

This example shows how to enable IGMPv3 snooping explicit host tracking:

```
Tqvwgt*eqphki/xncp/eqphki+%"kr"kior"upqqrkpi"gznrkekv/vtcmekpi"nkokv"622"
Tqvwgt%"ujqy"kr"kior"upqqrkpi"xncp"422"
Inqdcn"KIOR"Upqqrkpi"eqphkiwtcvkqp<
////////////////////////////////////
KIOR"upqqrkpi"Qrgt"Uvcvg" <"Gpdcngf
KIORx5"upqqrkpi" <"Gpdcngf
Tgrqtv"uwrtguukqp" <"Fkucdngf
GJV"FD"nkokvlegwpv" <"32222214
VEP"uqnkekv"swgt{" <"Fkucdngf
Tqdwuvpguu"xctkcdng" <"4
Ncuv"ogodgt"swgt{"eqwpv" <"5
Ncuv"ogodgt"swgt{"kpvgtxcn" <"3222
Ejgem"VVN?3" <"Pq
Ejgem"Tqvwgt/Cngtv/Qrvkqp" <"Pq

Xncp"422<
////////
KIOR"upqqrkpi"Cfokp"Uvcvg" <"Gpdcngf
KIOR"upqqrkpi"Qrgt"Uvcvg" <"Gpdcngf
```

```

KIORx4 "koogfkcv"ngcxg" "<"Fkucdngf
Gzrnkekv"jquv"vtcemkpi" "<"Gpcdngf
Tgrqtv"uwrrtguukqp" "<"Gpcdngf
Tqdwuvpguu"xctkcdng" "<"4
Ncuv"ogodgt"swgt{"eqwpy" "<"4
Ncuv"ogodgt"swgt{"kpvgtxcn"<"3222
GJV"FD"nkokvleqwpv" "<"32222214
Ejgem"VVN?3" "<"[gu
Ejgem"Tqvwgt/Cngtv/Qrvkqp" "<"[gu
Swgt{"Kpvgtxcn" "<"322
Ocz"Tgurqpug"Vkog" "<"32222
Tqvwgt*eqphki/xncp/eqphki+"kr"kior"upqqrkpi"uvcvke"446030405"uqwtg"32030303"kpvgthceg"Ik5133
Tqvwgt%"ujqy"kr"kior"upqqrkpi"itqwruxncp"422
Hnciu<"K"// "KIOR"upqqrkpi."U"// "Uvcvke."R"// "RKO"upqqrkpi."C"// "CUO"oqfg
Xncp" Itqwrлуqwtg" V{rg" Xgtukqp" Rgtv"Nkuv
////////////////////////////////////
422" 446030405" x5"
132030303" U" Ik5133
Tqvwgt%

```

## Displaying IGMP Snooping Information

- [Displaying Multicast Router Interfaces, page 45-14](#)
- [Displaying MAC Address Multicast Entries, page 45-15](#)
- [Displaying IGMP Snooping Information for a VLAN Interface, page 45-15](#)

## Displaying Multicast Router Interfaces

When you enable IGMP snooping, the switch automatically learns to which interface the multicast routers are connected. To display multicast router interfaces, perform this task:

| Command                                     | Purpose                               |
|---------------------------------------------|---------------------------------------|
| Tqvwgt%"ujqy"kr"kior"upqqrkpi"xncp"vlan_ID" | Displays multicast router interfaces. |

This example shows how to display the multicast router interfaces in VLAN 1:

```

Tqvwgt%"ujqy"kr"kior"upqqrkpi"xncp"422"
Inqdcn"KIOR"Upqqrkpi"eqphkiwtcvkqp<
////////////////////////////////////
KIOR"upqqrkpi"Qrgt"Uvcvg" "<"Gpcdngf
KIORx5"upqqrkpi" "<"Gpcdngf
Tgrqtv"uwrrtguukqp" "<"Fkucdngf
GJV"FD"nkokvleqwpv" "<"32222214
VEP"uqnkekv"swgt{" "<"Fkucdngf
Tqdwuvpguu"xctkcdng" "<"4
Ncuv"ogodgt"swgt{"eqwpy" "<"5
Ncuv"ogodgt"swgt{"kpvgtxcn" "<"3222
Ejgem"VVN?3" "<"Pq
Ejgem"Tqvwgt/Cngtv/Qrvkqp" "<"Pq

Xncp"422<
////////////////////////////////
KIOR"upqqrkpi"Cfokp"Uvcvg" "<"Gpcdngf
KIOR"upqqrkpi"Qrgt"Uvcvg" "<"Gpcdngf
KIORx4"koogfkcv"ngcxg" "<"Fkucdngf
Gzrnkekv"jquv"vtcemkpi" "<"Gpcdngf

```

```
Tgrqtv"uwrrtguukqp" "<"Gpcdngf
Tgdwuvpguu"xctkcdng" "<"4
Ncuv"ogodgt"swgt{"eqwpy" "<"4
Ncuv"ogodgt"swgt{"kpvgtxcn"<"3222
GJV"FD"nkokvleqwpv" "<"32222214
Ejgem"VVN?3" "<"[gu
Ejgem"Tqvwgt/Cngtv/Qrvkqp" "<"[gu
Swgt{"Kpvgtxcn" "<"322
Ocz"Tgurqpug"Vkog" "<"32222
Tqvwgt%
```

## Displaying MAC Address Multicast Entries

To display MAC address multicast entries for a VLAN, perform this task:

| Command                                                      | Purpose                                            |
|--------------------------------------------------------------|----------------------------------------------------|
| Tqvwgt%"ujqy"oce"cfftguu/vcdng"ownvkecuv"vlan_ID"<br>]eqwpy_ | Displays MAC address multicast entries for a VLAN. |

This example shows how to display MAC address multicast entries for VLAN 1:

```
Tqvwgt%"ujqy"oce"cfftguu/vcdng"ownvkecuv"xncp"3
xncp""oce"cfftguu""""v{rg""""squ""""""""""rqtvu
////////-////////-///-////////-////////-////////-////////-////////-////////-////////-
"3""232207g2402425"uvcvke""""/"Ik313.Ik413.Ik516:.Tqvwgt
"3""232207g2202349"uvcvke""""/"Ik313.Ik413.Ik516:.Tqvwgt
"3""232207g220234:"uvcvke""""/"Ik313.Ik413.Ik516:.Tqvwgt
"3""232207g2202223"uvcvke""""/"Ik313.Ik413.Ik516:.Tqvwgt.Uykvej
Tqvwgt%
```

This example shows how to display a total count of MAC address entries for a VLAN:

```
Tqvwgt%"ujqy"oce"cfftguu/vcdng"ownvkecuv"3"eqwpy

Ownvkecuv"OCE"Gpvtkgu"hgt"xncp"3<""""6
Tqvwgt%
```

## Displaying IGMP Snooping Information for a VLAN Interface

To display IGMP snooping information for a VLAN interface, perform this task:

| Command                                 | Purpose                                                 |
|-----------------------------------------|---------------------------------------------------------|
| Tqvwgt%"ujqy"kr"kior"kpvgthceg"vlan_ID" | Displays IGMP snooping information on a VLAN interface. |

This example shows how to display IGMP snooping information on the VLAN 200 interface:

```
Tqvwgt%"ujqy"kr"kior"kpvgthceg"xncp"65"
Xncp65"ku"wr."nkpq"rtqvgeqn"ku"wr
"Kpvgtpgv"cfftguu"ku"65020203146
"KIOR"ku"gpdcngf"qp"kpvgthceg
"Ewttgpy"KIOR"jquv"xgtukqp"ku"4
"Ewttgpy"KIOR"tqvwgt"xgtukqp"ku"4
"KIOR"swgt{"kpvgtxcn"ku"82"ugeqpfu
"KIOR"swgtkgt"vkogqvw"ku"342"ugeqpfu
```

```

"KIOR"ocz"swgt{"tgurqpug"vkog"ku"32"ugeqpfu
"Ncuv"ogodgt"swgt{"eqwpv"ku"4
"Ncuv"ogodgt"swgt{"tgurqpug"kpvgtxcn"ku"3222"ou
"Kpdqwpf"KIOR"ceeguu"itqwr"ku"pqv"ugv
"KIOR"cevkxkv{<3"lqkpu."2"ngcxgu
"Ownvkecuv"tqvwkpi"ku"gpdcngf"qp"kpvgthceg
"Ownvkecuv"VVN"vjtgujqnf"ku"2
"Ownvkecuv"fgukipcvgf"tqwvgt"*FT+"ku"65020203"*vjku"u{uvgo+
"KIOR"swgt{"kpi"tqwvgt"ku"65020203"*vjku"u{uvgo+
"Ownvkecuv"itqwru"lqkpgf"d{"vjku"u{uvgo"*pwodgt"qh"wugtu+<
""""4460203062*3+
"KIOR"upqqrkpi"ku"inqdcnn{"gpdcngf
"KIOR"upqqrkpi"ku"gpdcngf"qp"vjku"kpvgthceg"
"KIOR"upqqrkpi"koogfkcvg/ngcxg"ku"fkucdngf"cpf"swgtkgt"ku"fkucdngf"
"KIOR"upqqrkpi"gzrnkekv/vtcmkpi"ku"gpdcngf"qp"vjku"kpvgthceg"
"KIOR"upqqrkpi"ncuv"ogodgt"swgt{"kpvgtxcn"qp"vjku"kpvgthceg"ku"3222"ou"
Tqwvgt%"

```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## PIM Snooping

---

- [Prerequisites for PIM Snooping, page 46-1](#)
- [Restrictions for PIM Snooping, page 46-2](#)
- [Information About PIM Snooping, page 46-2](#)
- [Default Settings for PIM Snooping, page 46-4](#)
- [How to Configure PIM Snooping, page 46-5](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for PIM Snooping

None.

## Restrictions for PIM Snooping

- Multicast packets are not bridged in a VLAN to local receivers that send IGMP joins when PIM snooping is enabled in the VLAN and IGMP snooping is disabled in the VLAN. (CSCta03980)
- When you use the PIM-sparse mode (PIM-SM) feature, downstream routers only see traffic if they previously indicated interest through a PIM join or prune message. An upstream router only sees traffic if it was used as an upstream router during the PIM join or prune process.
- Join or prune messages are not flooded on all router ports but are sent only to the port corresponding to the upstream router mentioned in the payload of the join or prune message.
- Directly connected sources are supported for bidirectional PIM groups. Traffic from directly connected sources is forwarded to the designated router and designated forwarder for a VLAN. In some cases, a nondesignated router (NDR) can receive a downstream (S, G) join. For source-only networks, the initial unknown traffic is flooded only to the designated routers and designated forwarders.
- Dense group mode traffic is seen as unknown traffic and is dropped.
- The AUTO-RP groups (224.0.1.39 and 224.0.1.40) are always flooded.
- The switch snoops on designated forwarder election and maintains a list of all designated forwarder routers for various RPs for the VLAN. All traffic is sent to all designated forwarders which ensures that bidirectional functionality works properly.
- PIM snooping and IGMP snooping can be enabled at the same time in a VLAN. Either RGMP or PIM snooping can be enabled in a VLAN but not both.
- Any non-PIMv2 multicast router will receive all traffic.
- You can enable or disable PIM snooping on a per-VLAN basis.
- All mroute and router information is timed out based on the hold-time indicated in the PIM hello and join/prune control packets. All mroute state and neighbor information is maintained per VLAN.
- With Release 15.1(1)SY1 and later releases, IGMP snooping and PIM snooping constrain VPLS multicast traffic.

## Information About PIM Snooping

In networks where a Layer 2 switch interconnects several routers, such as an Internet exchange point (IXP), the switch floods IP multicast packets on all multicast router ports by default, even if there are no multicast receivers downstream. With PIM snooping enabled, the switch restricts multicast packets for each IP multicast group to only those multicast router ports that have downstream receivers joined to that group. When you enable PIM snooping, the switch learns which multicast router ports need to receive the multicast traffic within a specific VLAN by listening to the PIM hello messages, PIM join and prune messages, and bidirectional PIM designated forwarder-election messages.



### Note

To use PIM snooping, you must enable IGMP snooping on the switch. IGMP snooping restricts multicast traffic that exits through the LAN ports to which hosts are connected. IGMP snooping does not restrict traffic that exits through the LAN ports to which one or more multicast routers are connected.

The following illustrations show the flow of traffic and flooding that results in networks without PIM snooping enabled and the flow of traffic and traffic restriction when PIM snooping is enabled.



Figure 46-1 shows the flow of a PIM join message without PIM snooping enabled. In the figure, the switches flood the PIM join message intended for Router B to all connected routers.

Figure 46-1 PIM Join Message Flow without PIM Snooping




Figure 46-2 shows the flow of a PIM join message with PIM snooping enabled. In the figure, the switches restrict the PIM join message and forward it only to the router that needs to receive it (Router B).

Figure 46-2 PIM Join Message Flow with PIM Snooping




Figure 46-3 shows the flow of data traffic without PIM snooping enabled. In the figure, the switches flood the data traffic intended for Router A to all connected routers.



**Figure 46-3** Data Traffic Flow without PIM Snooping

Figure 46-4 shows the flow of data traffic with PIM snooping enabled. In the figure, the switches forward the data traffic only to the router that needs to receive it (Router A).

**Figure 46-4** Data Traffic Flow with PIM Snooping

## Default Settings for PIM Snooping

PIM snooping is disabled by default.

# How to Configure PIM Snooping

- [Enabling PIM Snooping Globally, page 46-5](#)
- [Enabling PIM Snooping in a VLAN, page 46-5](#)
- [Disabling PIM Snooping Designated-Router Flooding, page 46-6](#)

## Enabling PIM Snooping Globally

To enable PIM snooping globally, perform this task:

|        | Command                                              | Purpose                   |
|--------|------------------------------------------------------|---------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%<b>"kr"rko"upqqrkpi"</b></code> | Enables PIM snooping.     |
| Step 2 | <code>Tqwgvt*eqphki+%<b>"gpf"</b></code>             | Exits configuration mode. |

This example shows how to enable PIM snooping globally and verify the configuration:

```
Tqwgvt*eqphki+%"kr"rko"upqqrkpi"
Tqwgvt*eqphki+%"gpf"
Tqwgvt%"ujqy"kr"rko"upqqrkpi"
Inqdcn"twpvkog"oqfg<"Gpcdnfg
Inqdcn"cfokp"oqfg" "<"Gpcdnfg
Pwodgt"qh"wgut"gpdcngf"XNCPu<"3
Wugt"gpdcngf"XNCPu<"32
Tqwgvt%
```



### Note

You do not need to configure an IP address or IP PIM in order to run PIM snooping.

## Enabling PIM Snooping in a VLAN

To enable PIM snooping in a VLAN, perform this task:

|        | Command                                                          | Purpose                   |
|--------|------------------------------------------------------------------|---------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%<b>"xncp"eqphkiwtcvkqp"</b>vlan_ID</code>   | Selects a VLAN.           |
| Step 2 | <code>Tqwgvt*eqphki/xncp/eqphki+%<b>"kr"rko"upqqrkpi"</b></code> | Enables PIM snooping.     |
| Step 3 | <code>Tqwgvt*eqphki/xncp/eqphki+%<b>"gpf"</b></code>             | Exits configuration mode. |

This example shows how to enable PIM snooping on VLAN 10 and verify the configuration:

```
Tqwgvt%"xncp"eqphkiwtcvkqp"32"
Tqwgvt*eqphki/xncp/eqphki+%"kr"rko"upqqrkpi"
Tqwgvt*eqphki/xncp/eqphki+%"gpf"
Tqwgvt%"ujqy"kr"rko"upqqrkpi"xncp"32"
5"pgkijdqtu"*2"FT"rtkqtkv{"kpecredng."2"Dk/fkt"kpecredng+"
8"otqwgvu."5"oce"gpvtkgu"
FT"ku"3203203206"
TR"FH"Ugv
Tqwgvt%
```

# Disabling PIM Snooping Designated-Router Flooding



**Note** Do not disable designated-router flooding on switches in a Layer 2 broadcast domain that supports multicast sources.

By default, switches that have PIM snooping enabled will flood multicast traffic to the designated router (DR). This method of operation can send unnecessary multicast packets to the designated router. The network must carry the unnecessary traffic, and the designated router must process and drop the unnecessary traffic.

To reduce the traffic sent over the network to the designated router, disable designated-router flooding. With designated-router flooding disabled, PIM snooping only passes to the designated-router traffic that is in multicast groups for which PIM snooping receives an explicit join from the link towards the designated router.

To disable PIM snooping designated-router flooding, perform this task:

|        | Command                                                    | Purpose                                           |
|--------|------------------------------------------------------------|---------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "pq"kr"rko"upqqrkpi"ft/hnqqf"</code> | Disables PIM snooping designated-router flooding. |
| Step 2 | <code>Tqwgvt*eqphki+% "gpf"</code>                         | Exits configuration mode.                         |

This example shows how to disable PIM snooping designated-router flooding:

```
Tqwgvt*eqphki+% "pq"kr"rko"upqqrkpi"ft/hnqqf"
Tqwgvt*eqphki+% "gpf"
```



**Tip** For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## Multicast VLAN Registration (MVR)

---

- [Restrictions for MVR, page 47-1](#)
- [Restrictions for MVR, page 47-1](#)
- [Information About MVR, page 47-2](#)
- [Default MVR Configuration, page 47-5](#)
- [How to Configure MVR, page 47-5](#)
- [Displaying MVR Information, page 47-8](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Restrictions for MVR

None.

## Restrictions for MVR

- Only one MVR VLAN can be present in a switch, and you should configure the same VLAN as the MVR VLAN for all the switches in the same network.
- Source ports must be in the MVR VLAN.

- Receiver ports on a switch can be in different VLANs, but must not be in the MVR VLAN.
- Receiver ports can only be access ports; they cannot be trunk ports.
- When using private VLANs, you cannot configure a secondary VLAN as the MVR VLAN.
- Do not connect a multicast router to a receiver port.
- The MVR VLAN must not be a reverse path forwarding (RPF) interface for any multicast route.
- MVR data received on an MVR receiver port is not forwarded to MVR source ports.
- The maximum number of multicast entries (MVR group addresses) that can be configured on a switch (that is, the maximum number of television channels that can be received) is 8000.
- MVR is available only on native systems.
- VTP pruning should be disabled if the MVR VLAN number is between 1 and 1000.
- MVR can coexist with IGMP snooping on a switch.
- MVR supports IGMPv3 messages.

## Information About MVR

- [MVR Overview, page 47-2](#)
- [Using MVR in a Multicast Television Application, page 47-3](#)

## MVR Overview

MVR is designed for applications that use wide-scale deployment of multicast traffic across an Ethernet ring-based service-provider network (for example, the broadcast of multiple television channels over a service-provider network). MVR allows a subscriber on a port to subscribe and unsubscribe to a multicast stream on the network-wide multicast VLAN. It allows the single multicast VLAN to be shared in the network while subscribers remain in separate VLANs. MVR provides the ability to continuously send multicast streams in the multicast VLAN, but to isolate the streams from the subscriber VLANs for bandwidth and security reasons.

MVR assumes that subscriber ports subscribe and unsubscribe (join and leave) these multicast streams by sending out IGMP join and leave messages. These messages can originate from an IGMP Version-2-compatible host with an Ethernet connection. Although MVR operates on the underlying mechanism of IGMP snooping, the two features operate independently of each other. One feature can be enabled or disabled without affecting the operation of the other feature. However, if IGMP snooping and MVR are both enabled, MVR reacts only to join and leave messages from multicast groups configured under MVR. Join and leave messages from all other multicast groups are managed by IGMP snooping.

MVR does the following:

- Identifies the MVR IP multicast streams and their associated IP multicast group in the Layer 2 forwarding table.
- Intercepts the IGMP messages.
- Modifies the Layer 2 forwarding table to include or remove the subscriber as a receiver of the multicast stream, even though the receivers might be in a different VLAN from the source.

This forwarding behavior selectively allows traffic to cross between different VLANs.


The switch will forward multicast data for MVR IP multicast streams only to MVR ports on which hosts have joined, either by IGMP reports or by MVR static configuration. The switch will forward IGMP reports received from MVR hosts only to the source (uplink) port. This eliminates using unnecessary bandwidth on MVR data port links.

Only Layer 2 ports participate in MVR. You must configure ports as MVR receiver ports. Only one MVR multicast VLAN per switch.

## Using MVR in a Multicast Television Application

In a multicast television application, a PC or a television with a set-top box can receive the multicast stream. Multiple set-top boxes or PCs can be connected to one subscriber port, which is a switch port configured as an MVR receiver port. [Figure 47-1](#) is an example configuration. DHCP assigns an IP address to the set-top box or the PC. When a subscriber selects a channel, the set-top box or PC sends an IGMP report to Switch A to join the appropriate multicast. If the IGMP report matches one of the configured IP multicast group addresses, the switch modifies the hardware address table to include this receiver port and VLAN as a forwarding destination of the specified multicast stream when it is received from the multicast VLAN. Uplink ports that send and receive multicast data to and from the multicast VLAN are called MVR source ports.

Figure 47-1 Multicast VLAN Registration Example



When a subscriber changes channels or turns off the television, the set-top box sends an IGMP leave message for the multicast stream. The switch sends a MAC-based general query through the receiver port VLAN. If there is another set-top box in the VLAN still subscribing to this group, that set-top box must respond within the maximum response time specified in the query. If the CPU does not receive a response, it eliminates the receiver port as a forwarding destination for this group.

Unless the Immediate Leave feature is enabled, when the switch receives an IGMP leave message from a subscriber on a receiver port, it sends out an IGMP query on that port and waits for IGMP group membership reports. If no reports are received in a configured time period, the receiver port is removed from multicast group membership. With the Immediate Leave feature enabled, an IGMP query is not sent from the receiver port on which the IGMP leave was received. As soon as the leave message is received, the receiver port is removed from multicast group membership, which speeds up leave latency. Enable the Immediate Leave feature only on receiver ports to which a single receiver device is connected.

MVR eliminates the need to duplicate television-channel multicast traffic for subscribers in each VLAN. Multicast traffic for all channels is only sent around the VLAN trunk once—only on the multicast VLAN. The IGMP leave and join messages are in the VLAN to which the subscriber port is assigned.



These messages dynamically register for streams of multicast traffic in the multicast VLAN on the Layer 3 device, Switch B. The access layer switch, Switch A, modifies the forwarding behavior to allow the traffic to be forwarded from the multicast VLAN to the subscriber port in a different VLAN, selectively allowing traffic to cross between two VLANs.

IGMP reports are sent to the same IP multicast group address as the multicast data. The Switch A CPU must capture all IGMP join and leave messages from receiver ports and forward them to the multicast VLAN of the source (uplink) port.

## Default MVR Configuration

- MVR: Disabled globally and per interface
- Multicast addresses: None configured
- Query response time: 1 second
- Multicast VLAN: VLAN 1
- Interface (per port) default: Neither a receiver nor a source port
- Immediate Leave: Disabled on all ports

## How to Configure MVR

- [Configuring MVR Global Parameters, page 47-5](#)
- [Configuring MVR Interfaces, page 47-6](#)
- [Displaying MVR Information, page 47-8](#)
- [Clearing MVR Counters, page 47-8](#)

## Configuring MVR Global Parameters

To configure the MVR global parameters, perform this task:

|        | Command                                                         | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------|-----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt%<b>"eqphkiwtg"vgtokpcn</b></code>                  | Enters global configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                |
| Step 2 | <code>Tqwvgt*eqphki+%"<b>oxt</b>"</code>                        | Enables MVR on the switch.                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Step 3 | <code>Tqwvgt*eqphki+%"<b>oxt"ocz/itqwr</b>"max-groups"</code>   | Specifies the maximum number of MVR groups. The range is 1 to 8000. The default is 1000.                                                                                                                                                                                                                                                                                                                                                         |
| Step 4 | <code>Tqwvgt*eqphki+%"<b>oxt"itqwr</b>"ip-address"]eqwv_</code> | Configures an IP multicast address on the switch or uses the <i>count</i> parameter to configure a contiguous series of MVR group addresses (the range for <i>count</i> is 1 to 256; the default is 1). Any multicast data sent to this address is sent to all source ports on the switch and all receiver ports that have elected to receive data on that multicast address. Each multicast address would correspond to one television channel. |

|        | Command                                              | Purpose                                                                                                                                                                                                                                                              |
|--------|------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 5 | <code>Tqwgvt*eqphki+% "oxt" swgt {vkog" value</code> | (Optional) Defines the maximum time to wait for IGMP report memberships on a receiver port before removing the port from multicast group membership. The value is in units of tenths of a second. The range is 1 to 100, and the default is 10 tenths or one second. |
| Step 6 | <code>Tqwgvt*eqphki+% "oxt" xncp" vlan-id</code>     | (Optional) Specifies the VLAN in which multicast data is received; all source ports must belong to this VLAN. The VLAN range is 1 to 1001 and 1006 to 4094. The default is VLAN 1.                                                                                   |
| Step 7 | <code>Tqwgvt*eqphki+% "gpf"</code>                   | Returns to privileged EXEC mode.                                                                                                                                                                                                                                     |

You do not need to set the optional MVR parameters if you choose to use the default settings. Before changing the default parameters (except for the MVR VLAN), you must first enable MVR.

To return the switch to its default settings, use the **no mvr** [**group ip-address** | **querytime** | **vlan**] global configuration command.

This example shows how to enable MVR, configure the group address, set the query time to 1 second (10 tenths), and specify the MVR multicast VLAN as VLAN 22:

```
Tqwgvt*eqphki+% "oxt
Tqwgvt*eqphki+% "oxt" itqwr"44:0304506
Tqwgvt*eqphki+% "oxt" swgt {vkog"32
Tqwgvt*eqphki+% "oxt" xncp"44"
Tqwgvt*eqphki+% "gpf"
```

You can use the **show mvr groups** privileged EXEC command to verify the MVR multicast group addresses on the switch.

## Configuring MVR Interfaces

To configure Layer 2 MVR interfaces, perform this task:

|        | Command                                                | Purpose                                                                           |
|--------|--------------------------------------------------------|-----------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt%"eqphkiwtg"vgtokpcn</code>                | Enters global configuration mode.                                                 |
| Step 2 | <code>Tqwgvt*eqphki+% "oxt"</code>                     | Enables MVR on the switch.                                                        |
| Step 3 | <code>Tqwgvt*eqphki+% "kpvgtthceg interface-id"</code> | Specifies the Layer 2 port to configure, and enters interface configuration mode. |

|        | Command                                                        | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|--------|----------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 4 | <code>Tqwvgt*eqphki/kh+% "oxt"v{rg"}uqwtæg"~"tgegkxgt ;</code> | <p>Configures an MVR port as one of these types of ports:</p> <ul style="list-style-type: none"> <li>• <b>source</b>—Configures uplink ports that receive and send multicast data as source ports. Subscribers cannot be directly connected to source ports. All source ports on a switch belong to the single multicast VLAN.</li> <li>• <b>receiver</b>—Configures a port as a receiver port if it is a subscriber port and should only receive multicast data. It does not receive data unless it becomes a member of the multicast group, either statically or by using IGMP leave and join messages. Receiver ports cannot belong to the multicast VLAN.</li> </ul> <p>If you attempt to configure a non-MVR port with MVR characteristics, the operation fails. The default configuration is as a non-MVR port.</p> |
| Step 5 | <code>Tqwvgt*eqphki/kh+% "oxt"koogfkcvg</code>                 | <p>(Optional) Enables the Immediate Leave feature of MVR on the port. The Immediate Leave feature is disabled by default.</p> <p><b>Note</b> This command applies to only receiver ports and should only be enabled on receiver ports to which a single receiver device is connected.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Step 6 | <code>Tqwvgt*eqphki/kh+% "gpf</code>                           | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

To return the interface to its default settings, use the **no mvr [type | immediate]** interface configuration commands.

This example shows how to configure a source port and a receiver port and to configure Immediate Leave on the receiver port:

```

Tqwvgt*eqphki+% "oxt
Tqwvgt*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv"516:
Tqwvgt*eqphki/kh+% "uykvejrgtv
Tqwvgt*eqphki/kh+% "uykvejrgtv"ceeguu"xncp"44
Tqwvgt*eqphki/kh+% "oxt"v{rg"}uqwtæg"
Tqwvgt*eqphki/kh+% "gzkv
Tqwvgt*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv"5169
Tqwvgt*eqphki/kh+% "uykvejrgtv
Tqwvgt*eqphki/kh+% "uykvejrgtv"ceeguu"xncp"52
Tqwvgt*eqphki/kh+% "oxt"v{rg"}tgegkxgt "
Tqwvgt*eqphki/kh+% "oxt"koogfkcvg
Tqwvgt*eqphki/kh+% "gzkv

```

## Clearing MVR Counters

You can clear MVR join counters for the switch, for source or receiver ports, or for a specified interface. To clear MVR counters, perform this task:

| Command                                                                                           | Purpose                                                                                                           |
|---------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| <code>Tqwwgt%engct"oxt"eqwpgvtu"] tgegkxgt/rqtvu"~"<br/>uqwtg/rqtvu_" ] type module/port__</code> | Clears the join counters of all the MVR ports, or source or receiver ports, or of a specified MVR interface port. |

This example clears the join counters for the receiver port on GigabitEthernet port 1/7:

```
Tqwwgt%engct"oxt"tgegkxgt/rqtvu"IkicdkvGvjgtpgv"319
Tqwwgt%"ujqy"oxt"tgegkxgt/rqtvu"IkicdkvGvjgtpgv"319
Lqkpu<"x3.x4.x5"eqwpgvt"ujqyu"vqvcn"KIOR"lqkpu
" " " " "x5"eqwpgvt"ujqyu"KIOR"lqkpu"tgegkxgf"ykvj"dqvj"OXT"cpf"pqp/OXT"itqwrw
Rqtv XNCP"Uvcvwu Koogfkcvg Lqkpu
 Ngcxg *x3.x4.x5+" " " " *x5+
//// ////"////////// ////////// //////////
Ik319 "424"KPCEVKXG1WR GPCDNGF" 2 "2
```

## Displaying MVR Information

You can display MVR information for the switch or for a specified interface. To display MVR configurations, perform one or more of these tasks:

| Command                                                                        | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|--------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwwgt%"ujqy"oxt</code>                                                  | Displays MVR status and these values for the switch: whether MVR is enabled or disabled, the multicast VLAN, the configured maximum and current number of multicast groups, and the query response time.                                                                                                                                                                                                                                                                                                                                                     |
| <code>Tqwwgt%"ujqy"oxt"itqwrw</code>                                           | Displays the MVR group configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <code>Tqwwgt%"ujqy"oxt"kpvgthceg"] type module/port__</code>                   | Displays all MVR interfaces and their MVR configurations.<br>When a specific interface is entered, displays this information: <ul style="list-style-type: none"> <li>Type—Receiver or Source</li> <li>Status—One of these: <ul style="list-style-type: none"> <li>Active—At least one IGMP join has been received for an MVR group on the port.</li> <li>Inactive—The port is not participating in any MVR groups.</li> <li>Up/Down—The port is forwarding (Up) or nonforwarding (Down).</li> </ul> </li> <li>Immediate Leave—Enabled or Disabled</li> </ul> |
| <code>Tqwwgt%"ujqy"oxt"ogodgtu"] ] xncp"vlan-id_"~"] type module/port__</code> | Displays details of all MVR members or MVR members on a specified VLAN or port.                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

| Command                                                                                 | Purpose                                                                                                                                                                                                  |
|-----------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Tqwwgt% <b>"ujqy"ox</b> t                                                               | Displays MVR status and these values for the switch: whether MVR is enabled or disabled, the multicast VLAN, the configured maximum and current number of multicast groups, and the query response time. |
| Tqwwgt% <b>"ujqy"ox</b> t <b>"itqrw</b>                                                 | Displays the MVR group configuration.                                                                                                                                                                    |
| Tqwwgt% <b>"ujqy"ox</b> t <b>"ogodgtu"] ]xn</b> cp"vlan-id_~"] type module/port__"eqwpv | Displays number of MVR members in all active MVR groups, or on a specified VLAN or port.                                                                                                                 |
| Tqwwgt% <b>"ujqy"ox</b> t"}tgegkxgt/rqtvu"~"uqwteg/rqtvu;" ] type module/port_          | Displays all receiver or source ports that are members of any IP multicast group or those on the specified interface port.                                                                               |

This example displays MVR status and values for the switch:

```
Tqwgvt%"ujqy"oxt"
OXT"Twppkpi<"VTWG"
OXT"ownvkecuv"xncp<"44"
OXT"Ocz"Ownvkecuv"Itqwruc<"3222""
OXT"Ewttgpv"ownvkecuv"itqwruc<"478""
OXT"Ingdcn"swgt{"tgurgpug"vkog<"32"*vgpvju"qh"uge+
```

This example displays the MVR group configuration:

[illegible]

This example displays all MVR interfaces and their MVR configurations:

```
Tqwgvtq"ujay"oxT"kpvgthceg
RqtV XNCP V{rg"Ujvcvwu"Xoogfkcvg"Ngcxg
//// //// "////////////////////////
Ik3142 4 TEGGXGT""CEVKXG1WR""FKUCDNGF""
Ik3143 4 UQWTEG""CEVKXG1WR""FKUCDNGF""
```

This example displays all MVR members on VLAN 2:

|                                      |          |                      |
|--------------------------------------|----------|----------------------|
| Tqvwgt% "ujqy" oxt "ogodgtu" xncp "4 |          |                      |
| OXT" Itqwr"KR                        | Uvcvwu   | Ogodgtu              |
| ////////                             | //////// | ////////             |
| 446022202230223                      | CEVKXG   | Ik3142*w+. Ik3143*w+ |
| 446022202230224                      | CEVKXG   | Ik514*f+. Ik3134*w+  |

This example displays the number of MVR members on all MVR VLANs:

Tqwvgt% "ujgy" oxt "ogodgtu" eqwpv

Eqwpv"qh"cevkxg"OXT"itqwru<  
Xncp"6;2<"622

```
Xncp"822<"622
Xncp"922<"2
Xncp";72<"2
```

This example displays all receiver ports that are members of any IP multicast group:

```
Tqwgvt%"ujqy"oxT"tgegkxgt/rqtvu
Lqkpu<"x3.x4.x5"eqwpvgT"ujqyu"vqvcn"KIOR"lqkpu
" " " " " "x5"eqwpvgT"ujqyu"KIOR"lqkpu"tgegkxgf"ykvj"dqvj"OXT"cpf"pqp/OXT"itqwru
Rqtv XNCP"Uvcvwu KoogfkcvG Lqkpu
Ngcxg *x3.x4.x5+" " " " *x5+
//// //"/"////////// //"/"////////// //"/"//////////
Ik319 "424"KPCEVKXG1WR GPCDNGF" 527558 "2
Ik31: "424"CEVKXG1WR FKUCDNGF" 6227 "2
Ik31; "425"KPCEVKXG1FQYP FKUCDNGF" 75229 "2
Ik3132 "425"CEVKXG1WR FKUCDNGF" 8426 "2
Ik3133 "426"CEVKXG1WR FKUCDNGF" 2 " ;62
Ik3134 "427"KPCEVKXG1WR GPCDNGF" :845 "2
```



#### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

Participate in the Technical Documentation Ideas forum



## IPv4 IGMP Filtering

---

- Prerequisites for IGMP Filtering, page 48-1
- Restrictions for IGMP Filtering, page 48-1
- Information About IGMP Filtering, page 48-2
- Default Settings for IGMP Filtering, page 48-4
- How to Configure IGMP Filters, page 48-4
- Verifying the IGMP Filtering Configuration, page 48-6
- Configuration Examples for IGMP Filtering, page 48-8



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for IGMP Filtering

None.

## Restrictions for IGMP Filtering

None.

# Information About IGMP Filtering

- [IGMP Filtering Overview, page 48-3](#)
- [IGMP Filter Precedence, page 48-4](#)



## IGMP Filtering Overview

**Note**

IGMP, which runs at Layer 3 on a multicast router, generates Layer 3 IGMP queries in subnets where the multicast traffic needs to be routed. For information about IGMP, see [Chapter 44, “Information About IPv4 Multicast Layer 3 Features.”](#)

IGMP snooping is a protocol that learns and maintains multicast group membership at the Layer 2 level. IGMP snooping looks at IGMP traffic to decide which ports should be allowed to receive multicast traffic from certain sources and for certain groups. This information is used to forward multicast traffic to only interested ports. The main benefit of IGMP snooping is to reduce flooding of packets. For information about IGMP snooping, see [“Information About IGMP Filtering” section on page 48-2](#).

IGMP filtering allows users to configure filters on a switch virtual interface (SVI), a per-port, or a per-port per-VLAN basis to control the propagation of IGMP traffic through the network. By managing the IGMP traffic, IGMP filtering provides the capability to manage IGMP snooping, which in turn controls the forwarding of multicast traffic.

When an IGMP packet is received, IGMP filtering uses the filters configured by the user to determine whether the IGMP packet should be discarded or allowed to be processed by the existing IGMP snooping code. With a IGMP version 1 or version 2 packet, the entire packet is discarded. With a IGMPv3 packet, the packet is rewritten to remove message elements that were denied by the filters.

The IGMP filtering feature is SSO compliant.

IGMP traffic filters control the access of a port to multicast traffic. Access can be restricted based on the following:

- Which multicast groups or channels can be joined on a port. Channels are joined by IGMPv3 hosts that specify both the group and the source of the multicast traffic.
- Maximum number of groups or channels allowed on a specific port or interface (regardless of the number of hosts requesting service).
- IGMP protocol versions (for example, disallow all IGMPv1 messages).

When you enter an IGMP filtering command, a user policy is applied to a Layer 3 SVI interface, a Layer 2 port, or a particular VLAN on a Layer 2 trunk port. The Layer 2 port may be an access port or a trunk port. The IGMP filtering features will work only if IGMP snooping is enabled (either on the interface or globally).

IGMP filtering is typically used in access switches connected to end-user devices.

There are three different types of IGMP filters: IGMP group and channel access control, several IGMP groups and channels limit, and an IGMP minimum version. These filters are configurable and operate differently on different types of ports:

- Per SVI
- Per port
- Per VLAN basis on a trunk port

You can configure filters separately for each VLAN passing through a trunk port.

## IGMP Filter Precedence

- [Access Mode, page 48-4](#)
- [Trunk Mode, page 48-4](#)

### Access Mode

In access mode, filters can be configured on both the port and the SVI. When an IGMP packet is received on a port in access mode, the port filter is checked first. If the port filter exists, it is applied and the SVI filter is ignored. If no per-port filter exists, the SVI filter is used.

This hierarchy is applied separately for each type of filter. For example, a limit filter configured on the port overrides the default limit filter on the SVI, but has no affect on any of the other filters.

### Trunk Mode

With ports in trunk mode, a filter can be configured for an SVI corresponding to one of the VLANs on the trunk port, another filter configured on the trunk port itself, and a third filter configured on one of the Layer 2 VLANs passing through the trunk. When an IGMP packet is received, the trunk-per-VLAN specific filter will be checked first. If this filter exists, it is applied. The main trunk port filter and SVI filter will be ignored. If no trunk-per-VLAN filter exists, the main trunk port filter will be used. If neither of these filters exist, the SVI filter for the VLAN will be used as a final default for ports in trunk mode.

## Default Settings for IGMP Filtering

None.

## How to Configure IGMP Filters

- [Configuring IGMP Group and Channel Access Control, page 48-4](#)
- [Configuring IGMP Group and Channel Limits, page 48-5](#)
- [Configuring IGMP Version Filtering, page 48-5](#)
- [Clearing IGMP Filtering Statistics, page 48-6](#)

## Configuring IGMP Group and Channel Access Control

Filtering on the IGMP group or channel allows the user to control which IGMP groups or channels can be joined on a port or on a per VLAN basis on a trunk port.

To configure filtering on the IGMP group or channel use the following CLI command:

```
kr"ki or"upqqrkpi"ceegu/itqwr"cen"]xncp"xncpakf_
```

To allow or deny several groups or channels, you must configure multiple access control entries in the access control list. Depending on whether the ACL is configured as permit or deny, the corresponding group or channel is allowed or denied. The ACL specified may be either a simple or extended ACL.

Filtering by IGMP group or channel is configurable on a Layer 3 SVI as a default filter for all ports in access mode under that SVI and for the corresponding VLAN on all trunk ports carrying that VLAN. This filter is also configurable on a Layer 2 port. If the port is in access mode, this filter will override any default SVI filter. If the port is in trunk mode, this filter will act as a default for all VLANs on that trunk and will override the SVI filter for each corresponding VLAN.

The **vlan** keyword can apply the filter only to IGMP packets arriving on the specified Layer 2 VLAN if the port is a trunk port. This per-VLAN filter (configured using the **vlan** keyword) will override any interface level filter and any SVI filter for the same VLAN.

## Configuring IGMP Group and Channel Limits

Limiting the number of IGMP groups or channels allows you to control how many IGMP groups or channels can be joined on a port or on a per-VLAN basis on a trunk port.

To limit the number of IGMP groups or channels, use the following interface command CLI:

```
kr"kior"upqqrkpi"nkokv"p"]gzegrv"cen_"]xnep"xncpakf_
```

A maximum of *n* groups or channels are allowed on the port or interface. The **except** keyword allows you to specify groups or channels that are exempt from the configured limit. The ACL used with the **except** keyword may be either a simple or extended ACL.

If joins are received for (\*,G1) and (S1,G1) on the same interface, these are counted as two separate joins. If the limit on an interface has been set to 2, and joins are received for (\*,G1) and (S1,G1), all other joins (for groups or channels different from these two) will then be discarded.

This filter is configurable on a Layer 3 SVI as a default filter for all ports in access mode under that SVI and for the corresponding VLAN on all trunk ports carrying that VLAN. This filter is also configurable on a Layer 2 port. If the Layer 2 port is in access mode, this filter will override any default SVI filter. If the Layer 2 switch port is in trunk mode, this filter will act as a default for all VLANs on that trunk and will override the SVI filter for each corresponding VLAN. The **vlan** keyword allows the user to apply the filter only to IGMP packets arriving on the specified Layer 2 VLAN if the Layer 2 switch port is a trunk port. This per-VLAN filter, configured using the **vlan** keyword, will override any interface level filter and any SVI filter for the same VLAN.

## Configuring IGMP Version Filtering

Filtering on the IGMP protocol allows you to configure the minimum version of IGMP hosts allowed on the SVI. For example, you may want to disallow all IGMPv1 hosts (such as, allow a minimum IGMP version of 2) or all IGMPv1 and IGMPv2 hosts (such as, allow a minimum IGMP version of 3). This filtering applies only to membership reports.

To configure filtering on the IGMP protocol, use the following CLI command:

```
kr"kior"upqqrkpi"okpkowo/xgtukqp"4"~"5
```

This filter is only configurable on a Layer 3 SVI as a default filter for all ports in access mode under that SVI and for the corresponding VLAN on all trunk ports.

## Clearing IGMP Filtering Statistics

To clear IGMP filtering statistics, perform one of these tasks:

| Command                                                                                            | Purpose                                                                                         |
|----------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|
| <code>Tqwvgt%engct"kr"kior"upqqrkpi"hknvgt"uvcvkuvkeu</code>                                       | Clears IGMP filtering statistics for all access ports and for all VLANs on all trunk ports.     |
| <code>Tqwvgt%engct"kr"kior"upqqrkpi"hknvgt"uvcvkuvkeu"kpvgthceg"interface_name</code>              | Clears statistics for one particular access port or for all VLANs on one particular trunk port. |
| <code>Tqwvgt%engct"kr"kior"upqqrkpi"hknvgt"uvcvkuvkeu"kpvgthceg"kpvgthcegapcog"xncp"vlan_ID</code> | Clears statistics for one particular VLAN on a trunk port.                                      |

## Verifying the IGMP Filtering Configuration

- [Displaying IGMP Filtering Configuration, page 48-6](#)
- [Displaying IGMP Filtering Statistics, page 48-7](#)

## Displaying IGMP Filtering Configuration

To display IGMP filtering rules, perform this task:

| Command                                                                                        | Purpose                                                      |
|------------------------------------------------------------------------------------------------|--------------------------------------------------------------|
| <code>Tqwvgt*eqphki/kh+%ujqy"kr"kior"upqqrkpi"hknvgt"kpvgthceg"interface-name"]fgvcknu_</code> | Displays the filters configured for the specified interface. |

This example shows how to display the default filters configured on the SVI:

```
Tqwvgt%"ujqy"kr"kior"upqqrkpi"hknvgt"kpvgthceg"xncp"42
Ceeguu/Itqwr<"Ejcppgn3/Cen
ItqwrulEjcppgnu"Nkokv<322"*Gzegrvkqp"Nkuv<"Ejcppgn8/Cen+
KIOR"Okpkowo/Xgtukqp<Pqv"Eqphkiwtgf
```

This example shows how to display the filters configured for all ports in access mode under this SVI and for all trunk ports carrying the corresponding VLAN:

```
Tqwvgt%"ujqy"kr"kior"upqqrkpi"hknvgt"kpvgthceg"i516:
"Ceeguu/Itqwr<"Ejcppgn6/Cen"
"ItqwrulEjcppgnu"Nkokv<32"*Gzegrvkqp"Nkuv<"Ejcppgn5/Cen+
```

This example shows how to display the filters configured for all ports in access mode under this SVI:

```
Tqwvgt%"ujqy"kr"kior"upqqrkpi"hknvgt"kpvgthceg"xncp"42"fgvckn
IkicdkvGvjgtpgv5169"<
"Ceeguu/Itqwr<"Pqv"Eqphkiwtgf"
"ItqwrulEjcppgnu"Nkokv<"Pqv"Eqphkiwtgf"
IkicdkvGvjgtpgv516:"" "<
"Ceeguu/Itqwr<"Ejcppgn6/CEN"
"ItqwrulEjcppgnu"Nkokv<"32"" ""*Gzegrvkqp/nkuv<"Ejcppgn5/Cen+
```

This example shows how to display the default trunk port filters:

```
Tqwvgt%"ujqy"kr"kior"upqqrkpi"hknvgt"kpvgthceg"g3/46
```

"Ceeguu/Itqwr<"Ejcppgn3/Cen  
"ItqwrulEjcppgnu"Nkokv<"32"\*Gzegrvkqp"Nkuv<"Ejcppgn5/Cen+

This example shows how to display the per-VLAN filters for all VLANs on this trunk:

```
Tqwgvt% "ujqy"kr"kior"upqqrkpi"hknvgt"kpvgthceg"i5168"fgvckn
Xncp"32""<
""CeeguU/Itgwr<"Pqv"Eaphkiwtgf"
""ItgwrulEjcppgnu"Nkokv<"Pqv"Eaphkiwtgf"
Xncp"42""<
""CeeguU/Itgwr<"Pqv"Eaphkiwtgf" "" "" "" "" "" "" "" ""
"" "" "" "" "" ItgwrulEjcppgnu"Nkokv<": "*Gzegrvkqp"Nkuv<"Ejcppgn6/Cen+
```

This example shows how to display the per-VLAN filters for a specific VLAN on this trunk:

Tgwgvtg%**"ujqy"kr"kior"upqqrkpi"hknvgt"kpvgthceg"i5168"xncp"42**  
 "Ceeguu/Itqwr<"Pqv"Eqphkiwtgf  
 "ItqwrulEjcppgnu"Nkokv<":\*Gzegrvkqp"Nkuv<"Ejcppgn6/Cen+



### Note

If the port is in the shutdown state, filter status will not be displayed because it cannot be determined whether the port is in trunk mode or access mode. In this situation, you can use the **show running-config interface *xxxx*** command to view the configuration.

## Displaying IGMP Filtering Statistics

Statistics are maintained on an interface basis for ports in access mode and on a per-VLAN basis for ports in trunk mode.

To display IGMP filtering statistics, perform this task:

| Command                                                                                                   | Purpose                                                                 |
|-----------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|
| <code>Uykvej*eqphki/kh+%<b>"ujqy"kr"kior"upqqrkpi"hknvgt"kpvgthceg"</b>interface-name] uvcvkuvkeu_</code> | Displays the filtering statistic collected for the specified interface. |

This example shows how to display statistics for each port in access mode under the SVI:

```
Tqwgvt% "ujqv"kr"kior"upqqrkpi"hknvgt"kpvgt,hceg"xncp"42"uvcvkvkeu
IkiCDkvGvjgtpgv5169""""<
""KIOR"Hknvgtu"ctg"pqv"eqphkiwtgf"

IkiCDkvGvjgtpgv516:"""<
""Ceeguu/itqwr"fgrpkgf"<"2"
""Nkokv"fgrpkgf"<"4"
""Nkokv"ucvwu"<"2"cevkxg"qwv"qh"4"ocz
""Okpkowo/xqtukqp"fgrpkgf"<"2"
```

This example shows how to display statistics for a specific port in access mode:

```
Tqwvgwt% "ujqy"kr"ki or"upqqrkpi" hknvgt"kpvgthceg"i516: "uvcvkuvkeu
" "Ceeguu/itqwr" fgpgkf" <"2"
" "Nkokv" fgpgkf" <"4"
" "Nkokv"uvcvwu" <"2"cevkxg" qwv"qh"4"ocz
" "Okpkowo/xqtukap" fgpkqf" <"2"
```

This example shows how to display statistics for Gigabit Ethernet port 3/47 in access mode with no default SVI filter and no port filter:

Tawvqt%"ujay"kr"kior"upqgrkpi"hknvqt"kpvtqhceq"i5169"uvcvkuvkeu

```
KIOR"Hknvgtu"ctg"pqv"eqphkiwtgf
```

This example shows how to display statistics for all VLANs under a trunk:

```
Tqwvgt%"ujqy"kr"kior"upqqrkpi"hknvgt"kpvgthceg"i5168"uvcvkuvkeu
Xncp"32""<
KIOR"Hknvgtu"ctg"pqv"eqphkiwtgf"
```

```
Xncp"42""<
" "Ceeguu/itqwr"fgpkgf"<"2"
" "Nkokv"fgpkgf"<"2"
" "Okpkowo/xgtukqp"fgpkgf"<"2"
```

This example shows how to display statistics for a specific VLAN under a trunk:

```
Tqwvgt%"ujqy"kr"kior"upqqrkpi"hknvgt"kpvgthceg"i5168"xncp"42"uvcvkuvkeu
" "Ceeguu/itqwr"fgpkgf"<"2"
" "Nkokv"fgpkgf"<"2"
" "Okpkowo/xgtukqp"fgpkgf"<"2"
```

This example shows how to display statistics for a specific VLAN under a trunk port with no trunk and no VLAN filter:

```
Tqwvgt%"ujqy"kr"kior"upqqrkpi"hknvgt"kpvgthceg"i5168"xncp"32"uvcvkuvkeu
KIOR"Hknvgtu"ctg"pqv"eqphkiwtgf
```



#### Note

If the port is in the shutdown state, filter statistics will not be displayed because it cannot be determined whether the port is in trunk mode or access mode.

## Configuration Examples for IGMP Filtering

This example shows the filter hierarchy. The following configuration of SVI VLAN 100 contains three access ports g1/1, g1/2, and g1/3:

VLAN 100:

```
Tqwvgt*eqphki/kh+%"kr"kior"upqqrkpi"nkokv"42
```

Port g1/1:

```
Tqwvgt*eqphki/kh+%"kr"kior"upqqrkpi"nkokv"57
```

Port g1/2:

```
Tqwvgt*eqphki/kh+%"pq"nkokv"hknvgt
```

Port g1/3:

```
Tqwvgt*eqphki/kh+%"pq"nkokv"hknvgt
```

In this example, the limit value for g1/1 is 35, the limit value for g1/2 is 20, and the limit value for g1/3 is also 20.

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)







## IPv4 Router Guard

---

- [Prerequisites for Router Guard, page 49-1](#)
- [Restrictions for Router Guard, page 49-1](#)
- [Information About Router Guard, page 49-2](#)
- [Default Settings for Router Guard, page 49-2](#)
- [How to Configure Router Guard, page 49-2](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for Router Guard

None.

## Restrictions for Router Guard

None.

## Information About Router Guard

The Router Guard feature allows you to designate a specified port only as a multicast host port and not as a multicast router port. Multicast router control packets received on this port are dropped.

Any port can become a multicast router port if the switch receives one of the multicast router control packets, such as IGMP general query, PIM hello, or CGMP hello. When a port becomes a multicast router port, all multicast traffic (both known and unknown source traffic) is sent to all multicast router ports. This cannot be prevented without Router Guard.

When configured, the Router Guard feature makes the specified port a host port only. The port is prevented from becoming a router port, even if a multicast router control packets are received.

In addition, any control packets normally received from multicast routers, such as IGMP queries and PIM joins, will also be discarded by this filter.

A Router Guard command applies a user policy to a Layer 3 SVI interface, a Layer 2 port, or a particular VLAN on a Layer 2 trunk port. The Layer 2 port may be an access port or a trunk port.

The Router Guard feature does not require IGMP snooping to be enabled.

Router Guard is implemented only for IPv4.

Router Guard is typically used in access switches connected to end-user boxes in Ethernet-to-home deployment scenarios.

The IPv4 multicast Router Guard feature is SSO-compliant.

The following packet types are discarded if they are received on a port that has Router Guard enabled:

- IGMP query messages
- IPv4 PIMv2 messages
- IGMP PIM messages (PIMv1)
- IGMP DVMRP messages
- RGMP messages
- CGMP messages

When these packets are discarded, statistics are updated indicating that packets are being dropped due to Router Guard.

Router Guard can be configured globally and per-interface. The global configuration initiates Router Guard for all Layer 2 ports, which can be modified with the interface configuration commands, for example, on ports where multicast routers are connected.

## Default Settings for Router Guard

None.

## How to Configure Router Guard

- [Enabling Router Guard Globally, page 49-3](#)
- [Disabling Router Guard on Ports, page 49-3](#)
- [Clearing Router Guard Statistics, page 49-3](#)

- [Displaying Router Guard Configuration, page 49-4](#)
- [Displaying Router Guard Interfaces, page 49-5](#)

## Enabling Router Guard Globally

To enable Router Guard globally, perform this task:

| Command                                                     | Purpose                        |
|-------------------------------------------------------------|--------------------------------|
| <code>Tqwwgt% "tqwwgt/iwctf"kr"ownvkecu"uykvejrgtvtu</code> | Enables Router Guard globally. |

## Disabling Router Guard on Ports

To disable Router Guard on a Layer 2 port to which a multicast router is connected, perform this task:

| Command                                                                     | Purpose                                                                                                                                                                          |
|-----------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwwgt*eqphki/kh+% "pq"tqwwgt/iwctf"kr"ownvkecu"]xncp"xncpakf_</code> | Disables Router Guard on a Layer 2 port.                                                                                                                                         |
|                                                                             | <b>Note</b> The <b>vlan</b> keyword is effective only if the port is in trunk mode. You can use this keyword to override Router Guard only for specific VLANs on the trunk port. |

This example shows how to allow multicast router messages on trunk port Gigabit Ethernet 3/46, VLAN 20:

```
Tqwwgt% "eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv"5168"
Tqwwgt*eqphki/kh+% "pq"tqwwgt/iwctf"kr"ownvkecu"xncp"42"
```

## Clearing Router Guard Statistics

To clear Router Guard statistics, perform one of these tasks:

| Command                                                                                                | Purpose                                                                      |
|--------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------|
| <code>Tqwwgt*eqphki+% "engct"tqwwgt/iwctf"kr"ownvkecu"uvckuvkeu</code>                                 | Clears statistics for all access ports and for all VLANs on all trunk ports. |
| <code>Tqwwgt*eqphki+% "engct"tqwwgt/iwctf"kr"ownvkecu"uvckuvkeu"kpvgthceg" interface_name</code>       | Clears statistics for an access port and for all VLANs on a trunk port.      |
| <code>Tqwwgt*eqphki+% "engct"tqwwgt/iwctf"kr"ownvkecu"uvckuvkeu"kpvgthceg"kpvgthcegapcog"xncp"v</code> | Clears statistics for one particular VLAN on a trunk port.                   |

This example shows how to clear statistics for one particular VLAN on a trunk port:

```
Tqwwgt% "engct"tqwwgt/iwctf"kr"ownvkecu"uvckuvkeu"kpvgthceg"kpvgthcegapcog"xncp"v
```

# Verifying the Router Guard Configuration

- [Displaying Router Guard Configuration, page 49-4](#)
- [Displaying Router Guard Interfaces, page 49-5](#)

## Displaying Router Guard Configuration

To display the global Router Guard configuration and the Router Guard configuration for a specific interface, perform these tasks:

| Command                                                                        | Purpose                                                           |
|--------------------------------------------------------------------------------|-------------------------------------------------------------------|
| <code>Tqwwgt%<b>"ujqy"tqwvgt/iwctf"</b></code>                                 | Displays the global Router Guard configuration.                   |
| <code>Tqwwgt%<b>"ujqy"tqwvgt/iwctf"kpvgthceg"</b> <i>interface_name</i></code> | Displays the Router Guard configuration for a specific interface. |

This example shows how to display the interface command output for a port in access mode with Router Guard not active:

```
Tqwwgt%"ujqy"tqwvgt/iwctf"kpvgthceg" i516 :
" "Tqwwgt "Iwctf" hqt "KR" Ownvkecuv<
Inqdcnn{ "gpcdnf" hqt "cnn" uykvej "rqtvu
Gpcdnf" qp"vjku"kpvgthceg
Rcemgvu"fgpkgf<
" "KIOR"Swgtkgu<
" "RKOx4"Oguucigu<
" "RKOx3"Oguucigu<
" "FXOTR"Oguucigu<
" "TIOR"Oguucigu<
" "EIOR"Oguucigu<
```

This example shows how to display the interface command output for a port in trunk mode:

```
Tqwwgt%"ujqy"tqwvgt/iwctf"kpvgthceg" i516 :
" "Tqwwgt "Iwctf" hqt "KR" Ownvkecuv<
Inqdcnn{ "gpcdnf" hqt "cnn" uykvej "rqtvu
Fkucdnf" qp"vjku"kpvgthceg
```

This example shows how to verify that a trunk port is carrying VLANs 10 and 20:

```
Tqwwgt%"ujqy"tqwvgt/iwctf"kpvgthceg" i5168
" "Tqwwgt "Iwctf" hqt "KR" Ownvkecuv<
Inqdcnn{ "gpcdnf" hqt "cnn" uykvej "rqtvu
Fghcwnv< "Gpcdnf" hqt "cnn" XNCPu"qp"vjku"kpvgthceg
XNCP"32<
Gpcdnf" qp"vjku"XNCP
Rcemgvu"fgpkgf<
" "KIOR"Swgtkgu<
" "RKOx4"Oguucigu<
" "RKOx3"Oguucigu<
" "FXOTR"Oguucigu<
" "TIOR"Oguucigu<
" "EIOR"Oguucigu<
XNCP"42"<
Fkucdnf" qp"vjku"XNCP
```

**Note**

If the port is in the shutdown state, the status will not be displayed because it cannot be determined whether the port is in trunk mode or access mode. You can use the **show running-config interface xxxx** command to display the Router Guard configuration.

## Displaying Router Guard Interfaces

To display a list of all interfaces for which Router Guard is disabled, perform this task:

| Command                                                                                                                                                                                                | Purpose                                                               |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------|
| <pre>Tqwgvt% "ujqy"tqwgvt/iwctf"kpvgthceg Tqwgvt "Iwctf" hqt "KR"Ownvkecuv&lt; Inqdcnn{ "gpcdngf" hqt "cnn"uykvej rqtvu  Kpvgthcegu&lt; Ik5168&lt; "Fkucdngf"qp"vjku" rqt v" hqt "XNCPU&lt; "CNN</pre> | Displays a list of all interfaces for which Router Guard is disabled. |

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





## IPv4 Multicast VPN Support

---

- [Prerequisites for mVPNs, page 50-1](#)
- [Restrictions for mVPNs, page 50-1](#)
- [Information About mVPN, page 50-3](#)
- [Default Settings for mVPNs, page 50-10](#)
- [How to Configure mVPNs, page 50-11](#)
- [Configuration Examples for mVPNs, page 50-27](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
  - Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- 



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

---

## Prerequisites for mVPNs

None.

## Restrictions for mVPNs

- [General Restrictions, page 50-2](#)
- [mVPN with L3VPN over mGRE Restrictions, page 50-3](#)

## General Restrictions

- All PE routers in the multicast domain need to be running a Cisco IOS software image that supports the mVPN feature. There is no requirement for mVPN support on the P and CE routers.
- Support for IPv4 multicast traffic must be enabled on all backbone routers.
- The Border Gateway Protocol (BGP) routing protocol must be configured and operational on all routers supporting multicast traffic. In addition, BGP extended communities must be enabled (using the **neighbor send-community both** or **neighbor send-community extended** command) to support the use of MDTs in the network.
- When the switch is acting as a PE, and receives a multicast packet from a customer router with a time-to-live (TTL) value of 2, it drops the packet instead of encapsulating it and forwarding it across the mVPN link. Because such packets would normally be dropped by the PE at the other end of the mVPN link, this does not affect traffic flow.
- If the core multicast routing uses SSM, then the data and default multicast distribution tree (MDT) groups must be configured within the SSM range of IPv4 addresses.
- The update source interface for the BGP peerings must be the same for all BGP peerings configured on the router in order for the default MDT to be configured properly. If you use a loopback address for BGP peering, then PIM sparse mode must be enabled on the loopback address.
- The **ip mroute-cache** command must be enabled on the loopback interface used as the BGP peering interface in order for distributed multicast switching to function on the platforms that support it. The **no ip mroute-cache** command must *not* be present on these interfaces.
- Data MDTs are not created for VRF PIM dense mode multicast streams because of the flood and prune nature of dense mode multicast flows and the resulting periodic bring-up and tear-down of such data MDTs.
- Data MDTs are not created for VRF PIM bidirectional mode because source information is not available.
- mVPN does not support multiple BGP peering update sources, and configuring them can break mVPN RPF checking. The source IPv4 address of the mVPN tunnels is determined by the highest IPv4 address used for the BGP peering update source. If this IPv4 address is not the IPv4 address used as the BGP peering address with the remote PE router, mVPN will not function properly.
- MDT tunnels do not carry unicast traffic.
- If mVPN uses the infrastructure of an MPLS VPN network, you cannot apply MPLS tags or labels to multicast traffic over the VPNs.
- Each mVRF that is configured with a default MDT uses three hidden VLANs (one each for encapsulation, decapsulation, and interface), in addition to external, user-visible VLANs. This means that an absolute maximum of 1,000 mVRFs are supported on each router. (mVRFs without a configured MDT still use one internal VLAN, so unused mVRFs should be deleted to conserve VLAN allocation.)
- If your MPLS VPN network already contains a network of VRFs, you do not need to delete them or recreate them to be able to support mVRF traffic. Instead, configure the **mdt default** and **mdt data** commands, as listed in the following procedure, to enable multicast traffic over the VRF.
- The same mVRF must be configured on each PE router that is to support a particular VPN connection.
- Each PE router that supports a particular mVRF must be configured with the same **mdt default** command.



## mVPN with L3VPN over mGRE Restrictions

- In releases earlier than Release 15.1(1)SY, With mVPN with L3VPN over mGRE configured, do not configure IPv4 routing on the supervisor engine ports or on ports on switching modules that have a CFC. ([CSCtr05033](#))
- Ensure that the unicast path to the RP does not use any supervisor engine ports; additionally, in VSS mode, ensure that the unicast path to the RP does not use any ports on switching modules that have a CFC. ([CSCts43614](#))
- When a GRE tunnel has the same destination address and source address as the mGRE tunnel, the GRE tunnel is route-cache switched.
- Packets that require fragmentation are route cache-switched.
- When an L3VPN profile is removed and added back, you should clear the Border Gateway Protocol (BGP) using the **clear ip bgp neighbor\_ip\_address soft** command.
- When an mGRE tunnel is created, a dummy tunnel is also created.
- The loopback or IP address used in the update source of the BGP configuration should be the same as that of the transport source of the L3VPN profile.
- mGRE is not stateful switchover (SSO) compliant. However, both mGRE and SSO coexist.
- Not all GRE options are supported in hardware (for example, the GRE extended header and GRE key).
- Checking identical VLANs (Internet Control Message Protocol [ICMP] redirect) is not supported on the tunnels.
- Features such as unicast reverse path forwarding (uRPF) and BGP policy accounting are not supported on the tunnels.

## Information About mVPN

- [mVPN Overview, page 50-3](#)
- [Multicast Routing and Forwarding and Multicast Domains, page 50-4](#)
- [Multicast Distribution Trees, page 50-4](#)
- [Multicast Tunnel Interfaces, page 50-7](#)
- [PE Router Routing Table Support for mVPN, page 50-8](#)
- [Multicast Distributed Switching Support, page 50-8](#)
- [Hardware-Assisted IPv4 Multicast, page 50-8](#)
- [Information About mVPN with L3VPN over mGRE, page 50-9](#)

## mVPN Overview

mVPN is a standards-based feature that transmits IPv4 multicast traffic across across a virtualized provider network (for example, MPLS or mGRE tunnels). mVPN uses the IPv4 multicast traffic PFC hardware support to forward multicast traffic over VPNs at wire speeds. mVPN adds support for IPv4 multicast traffic over Layer 3 IPv4 VPNs to the existing IPv4 unicast support.

mVPN routes and forwards multicast packets for each individual VPN routing and forwarding (VRF) instance, as well as transmitting the multicast packets through VPN tunnels across the service provider backbone.

mVPN is an alternative to full-mesh point-to-point GRE tunnels, which is not a readily scalable solution and are limited in the granularity they provide to customers.

## Multicast Routing and Forwarding and Multicast Domains

mVPN adds multicast routing information to the VPN routing and forwarding table. When a provider-edge (PE) router receives multicast data or control packets from a customer-edge (CE) router, forwarding is performed according to the information in the multicast VRF (mVRF).

Each mVRF maintains the routing and forwarding information that is needed for its particular VRF instance. An mVRF is created and configured in the same way as existing VRFs, except multicast routing is also enabled on each mVRF.

A multicast domain constitutes the set of hosts that can send multicast traffic to each other within the MPLS network. For example, the multicast domain for a customer that wanted to send certain types of multicast traffic to all global employees would consist of all CE routers associated with that enterprise.

## Multicast Distribution Trees

The mVPN feature establishes at least one multicast distribution tree (MDT) for each multicast domain. The MDT provides the information needed to interconnect the same mVRFs that exist on the different PE routers.

mVPN supports two MDT types:

- **Default MDT**—The default MDT is a permanent channel for PIM control messages and low-bandwidth streams between all PE routers in a particular multicast domain. All multicast traffic in the default MDT is replicated to every other PE router in the domain. Each PE router is logically seen as a PIM neighbor (one hop away) from every other PE router in the domain.
- **Data MDT**—Data MDTs are optional. If enabled, they are dynamically created to provide optimal paths for high-bandwidth transmissions, such as full-motion video, that do not need to be sent to every PE router. This allows for on-demand forwarding of high-bandwidth traffic between PE routers, so as to avoid flooding every PE router with every high-bandwidth stream that might be created.

To create data MDTs, each PE router that is forwarding multicast streams to the backbone periodically examines the traffic being sent in each default MDT as follows:

1. Each PE router periodically samples the multicast traffic (approximately every 10 seconds for software switching, and 90 seconds for hardware switching) to determine whether a multicast stream has exceeded the configured threshold. (Depending on when the stream is sampled, this means that in a worst-case scenario, it could take up to 180 seconds before a high-bandwidth stream is detected.)



**Note**

Data MDTs are created only for (S, G) multicast route entries within the VRF multicast routing table. They are not created for (\*, G) entries.

2. If a particular multicast stream exceeds the defined threshold, the sending PE router dynamically creates a data MDT for that particular multicast traffic.

3. The sending PE router then transmits a DATA-MDT JOIN request (which is a User Datagram Protocol (UDP) message to port 3232) to the other PE routers, informing them of the new data MDT.
4. Receiving PE routers examine their VRF routing tables to determine if they have any customers interested in receiving this data stream. If so, they use the PIM protocol to transmit a PIM JOIN message for this particular data MDT group (in the global table PIM instance) to accept the stream. Routers that do not currently have any customers for this stream still cache the information, in case any customers request it later on.
5. Three seconds after sending the DATA-MDT JOIN message, the sending PE router removes the high-bandwidth multicast stream from the default MDT and begins transmitting it over the new data MDT.
6. The sending PE router continues to send a DATA-MDT JOIN message every 60 seconds, as long as the multicast stream continues to exceed the defined threshold. If the stream falls below the threshold for more than 60 seconds, the sending PE router stops sending the DATA-MDT JOIN messages, and moves the stream back to the default MDT.
7. Receiving routers age out the cache information for the default MDT when they do not receive a DATA-MDT JOIN message for more than three minutes.


Data MDTs allow for high-bandwidth sources inside the VPN while still ensuring optimal traffic forwarding in the MPLS VPN core.

In the following example, a service provider has a multicast customer with offices in San Jose, New York, and Dallas. The San Jose site is transmitting a one-way multicast presentation. The service provider network supports all three sites associated with this customer, in addition to the Houston site of a different enterprise customer.

The default MDT for the enterprise customer consists of provider routers P1, P2, and P3 and their associated PE routers. Although PE4 is interconnected to these other routers in the MPLS core, PE4 is associated with a different customer and is therefore not part of the default MDT.


Figure 50-1 shows the situation in this network when no one outside of San Jose has joined the multicast broadcast, which means that no data is flowing along the default MDT. Each PE router maintains a PIM relationship with the other PE routers over the default MDT, as well as a PIM relationship with its directly attached PE routers.

**Figure 50-1** Default Multicast Distribution Tree Overview



If an employee in New York joins the multicast session, the PE router associated for the New York site sends a join request that flows across the default MDT for the multicast domain. The PE router associated with the multicast session source (PE1) receives the request. Figure 50-2 shows how the PE router forwards the request to the CE router associated with the multicast source (CE1a).

**Figure 50-2** *Initializing the Data MDT*



The CE router (CE1a) starts sending the multicast data to the associated PE router (PE1), which recognizes that the multicast data exceeds the bandwidth threshold at which a data MDT should be created. PE1 then creates a data MDT and sends a message to all routers using the default MDT that contains information about the data MDT.

Approximately three seconds later, PE1 begins sending the multicast data for that particular stream using the data MDT. Because only PE2 has receivers who are interested in this source, only PE2 joins the data MDT and receives traffic on it.

## Multicast Tunnel Interfaces

The PE router creates a multicast tunnel interface (MTI) for each multicast VRF (mVRF) in the multicast domain. The mVRF uses the tunnel interface to access the multicast domain to provide a conduit that connects an mVRF and the global mVRF.

On the router, the MTI is a tunnel interface (created with the **interface tunnel** command) with a class D multicast address. All PE routers that are configured with a default MDT for this mVRF create a logical network in which each PE router appears as a PIM neighbor (one hop away) to every other PE router in the multicast domain, regardless of the actual physical distance between them.

The MTI is automatically created when an mVRF is configured. The BGP peering address is assigned as the MTI interface source address, and the PIM protocol is automatically enabled on each MTI.

When the router receives a multicast packet from the customer side of the network, it uses the incoming interface's VRF to determine which mVRFs should receive it. The router then encapsulates the packet using GRE encapsulation. When the router encapsulates the packet, it sets the source address to that of the BGP peering interface and sets the destination address to the multicast address of the default MDT, or to the source address of the data MDT if configured. The router then replicates the packet as needed for forwarding on the appropriate number of MTI interfaces.

When the router receives a packet on the MTI interface, it uses the destination address to identify the appropriate default MDT or data MDT, which in turn identifies the appropriate mVRF. It then decapsulates the packet and forwards it out the appropriate interfaces, replicating it as many times as are necessary.

**Note**

- Unlike other tunnel interfaces that are commonly used on Cisco routers, the mVPN MTI is classified as a LAN interface, not a point-to-point interface. The MTI interface is not configurable, but you can use the **show interface tunnel** command to display its status.
- The MTI interface is used exclusively for multicast traffic over the VPN tunnel.
- The tunnel does not carry unicast routed traffic.

## PE Router Routing Table Support for mVPN

Each PE router that supports the mVPN feature uses the following routing tables to ensure that the VPN and mVPN traffic is routed correctly:

- Default routing table—Standard routing table used in all Cisco routers. This table contains the routes that are needed for backbone traffic and for non-VPN unicast and multicast traffic (including Generic Routing Encapsulation (GRE) multicast traffic).
- VPN routing/forwarding (VRF) table—Routing table created for each VRF instance. Responsible for routing the unicast traffic between VPNs in the provider network.
- Multicast VRF (mVRF) table—Multicast routing table and multicast routing protocol instance created for each VRF instance. Responsible for routing the multicast traffic in the multicast domain of the network. This table also includes the multicast tunnel interfaces that are used to access the multicast domain.

## Multicast Distributed Switching Support

mVPN supports multicast distributed switching (MDS) for multicast support on a per-interface and a per-VRF basis. When configuring MDS, you must make sure that no interface (including loopback interfaces) has the **no ip mroute-cache** command configured.

## Hardware-Assisted IPv4 Multicast

Cisco IOS Release 15.4SY supports hardware acceleration for IPv4 multicast over VPN traffic, which forwards multicast traffic to the appropriate VPNs at wire speed without increased RP CPU utilization.

In a customer VRF, PFC hardware acceleration supports multicast traffic in PIM dense, PIM sparse, PIM bidirectional, and PIM Source Specific Multicast (SSM) modes.

In the service provider core, PFC hardware acceleration supports multicast traffic in PIM sparse, PIM bidirectional, and PIM SSM modes. In the service provider core, PFC hardware acceleration does not support multicast traffic in PIM dense mode.

## Information About mVPN with L3VPN over mGRE

- [Overview, page 50-9](#)
- [Route Maps, page 50-9](#)
- [Tunnel Endpoint Discovery and Forwarding, page 50-10](#)
- [Tunnel Decapsulation, page 50-10](#)
- [Tunnel Source, page 50-10](#)

**Note**

See the [“Configuring mVPN with L3VPN over mGRE” section on page 50-22](#) for more information.

## Overview

Release 15.0(1)SY1 and later releases support multicast virtual private network with Layer 3 virtual private network over multipoint generic routing encapsulation (mVPN with L3VPN over mGRE). mVPN with L3VPN over mGRE provides VPN connectivity between networks that are connected by standards-based IP-only networks. mGRE tunnels overlay the IP network and connect PE devices to transport VPNs that support deployment of L3 PE-based VPN services over the IP core.

**Note**

- Because mGRE is a point-to-multipoint model, fully meshed GRE tunnels are not required to interconnect PE devices.
- Multicast and unicast traffic use separate tunnels, MDT for multicast and mGRE for unicast.

## Route Maps

By default, VPN unicast traffic is sent using an LSP. The mVPN with L3VPN over mGRE feature uses user-defined route maps to determine which VPN prefixes are reachable over an mGRE tunnel and which VPN prefixes are reachable using an LSP. The route map is applied to advertisements for VPNv4 and VPNv6 address families. The route map uses a next hop tunnel table to determine the encapsulation method for the VPN traffic.

Traffic routed over an mGRE tunnel uses an alternative address space; all next hops are reached by encapsulating the traffic in an mGRE tunnel. To configure a specific route to use an mGRE tunnel, requires configuration of an entry for that route to the route map. The new entry remaps the Network Layer Reachability Information (NLRI) of the route to the alternative address space. If there is no remap entry in the route map for a route, then traffic on that route is forwarded over an LSP.

The mVPN with L3VPN over mGRE feature automatically provisions the alternative address space, normally held in the tunnel-encapsulated virtual routing and forwarding (VRF) instance. To ensure that all traffic reachable through the address space is encapsulated in an mGRE tunnel, the feature installs a single default route out of a tunnel. The feature also creates a default tunnel on the route map. The default route map can be attached to the appropriate BGP updates.

## Tunnel Endpoint Discovery and Forwarding

The mVPN with L3VPN over mGRE feature must be able to discover the remote PEs in the network and construct tunnel forwarding information for the remote PEs. The feature must be able to detect when a remote PE is no longer valid and remove the tunnel forwarding information for that PE.

If an ingress PE receives a VPN advertisement over BGP, it uses the route target attributes (which it inserts into the VRF) and the MPLS VPN label from the advertisement, to associate the prefixes with the appropriate customer. The next hop of the inserted route is set to the NLRI of the advertisement.

The advertised prefixes contain information about remote PEs in the system (in the form of NLRIs), and the PE uses this information to notify the system when an NLRI becomes active or inactive. The system uses this notification to update the PE forwarding information.

When the feature receives notification of a new remote PE, it adds the information to the tunnel endpoint database and creates an adjacency associated with the tunnel interface. The adjacency description includes information on the encapsulation and other processing required to send encapsulated packets to the new remote PE.

The feature places the adjacency information into the tunnel encapsulated VRF. When a VPN NLRI is remapped to a route in the VRF (using the route map), the feature links the NLRI to the adjacency, which links the VPN to the tunnel.

## Tunnel Decapsulation

When the egress PE receives a packet from a tunnel interface that uses the mVPN with L3VPN over mGRE feature, the PE decapsulates the packet to create a VPN label tagged packet, and forwards the packet.

## Tunnel Source

The mVPN with L3VPN over mGRE feature uses a single tunnel configured as an mGRE tunnel to configure a system with a large number of endpoints (remote PEs). To identify the origin of tunnel-encapsulated packets, the system uses the tunnel source information.

At the transmitting (ingress) PE, when a VPN packet is sent to a tunnel, the tunnel destination is the NLRI. At a receiving (egress) PE, the tunnel source is the address that the packets encapsulated in the mGRE tunnel are received on. Therefore, at the egress PE the packet destination must match the NLRI from the local PE.

# Default Settings for mVPNs

None.



- [Configuring a Multicast VPN Routing and Forwarding Instance, page 50-11](#)
- [Configuring Multicast VRF Routing, page 50-16](#)
- [Configuring Interfaces for Multicast Routing to Support mVPN, page 50-20](#)
- [Configuring mVPN with L3VPN over mGRE, page 50-22](#)



These configuration tasks assume that BGP is already configured and operational on all routers that are sending or receiving the multicast traffic. In addition, BGP extended communities must be enabled (using the **neighbor send-community both** or **neighbor send-community extended** command) to support the use of MDTs in the network.

- [Configuring a VRF Entry, page 50-11](#)
- [Configuring the Route Distinguisher, page 50-12](#)
- [Configuring the Route-Target Extended Community, page 50-12](#)
- [Configuring the Default MDT, page 50-13](#)
- [Configuring Data MDTs \(Optional\), page 50-13](#)
- [Enabling Data MDT Logging, page 50-14](#)
- [Sample Configuration, page 50-14](#)
- [Displaying VRF Information, page 50-15](#)

|        | Command                                        | Purpose                                                                                                                  |
|--------|------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqwwgt% "eqphkiwtg"vgtokpcn"                   | Enters global configuration mode.                                                                                        |
| Step 2 | Tqwwgt*eqphki+% "kr"xth" xthapcog"             | Configures a VRF routing table entry and a Cisco Express Forwarding (CEF) table entry and enters VRF configuration mode. |
| Step 3 | Tqwwgt*eqphki/xth+% "fq"ujqy"kr"xth" xthapcog" | Verifies the configuration.                                                                                              |

```
Tqwgvt%"eqphkiwtg"vgtokpcn
Tqwgvt*eqphki+%"kr"xth"dnwg"
Tqwgvt*eqphki/xth+%"fq"ujqy"kr"xth"dnwg"
Pcog"dnwg"*****Fghcwnv"TF*****"Kpvgthcegu
*****>pgv"uqv@"
```

## Configuring the Route Distinguisher

To configure the route distinguisher, perform this task:

|        | Command                                                                                     | Purpose                                                  |
|--------|---------------------------------------------------------------------------------------------|----------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki/xth+%<b>tf</b>"<i>tqwvga</i>fkuvkpiwkujgt"</code>                       | Specifies the route distinguisher for a VPN IPv4 prefix. |
| Step 2 | <code>Tqwvgt*eqphki/xth+%<b>fq</b>"<i>ujqy</i>"<b>kr</b>"<i>xth</i>"<i>xthapcog</i>"</code> | Verifies the configuration.                              |

When configuring the route distinguisher, enter the route distinguisher in one of the following formats:

- 16-bit AS number:your 32-bit number (101:3)
- 32-bit IPv4 address:your 16-bit number (192.168.122.15:1)

This example show how to configure 55:1111 as the route distinguisher and verify the configuration:

```
Tqwvgt*eqphki/xth+%tf"77<3333"
Tqwvgt*eqphki/xth+%fq"ujqy"kr"xth"dnwg"
Pcog"*****Fghcwnv"TF*****Kpvgthcegu
dnwg"*****77<3333"
```

## Configuring the Route-Target Extended Community

To configure the route-target extended community, perform this task:

|        | Command                                                                                                                      | Purpose                                                   |
|--------|------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki/xth+%<b>tqwvg/vctigv</b>]korqtv"~"<b>gzrqtv</b>"~"<b>dqvj</b>_"<i>tqwvgavctigvagzvaeqoowpkv</i>{"</code> | Configures a route-target extended community for the VRF. |
| Step 2 | <code>Tqwvgt*eqphki/xth+%<b>fq</b>"<i>ujqy</i>"<b>kr</b>"<i>xth</i>"<b>fgvckn</b>"</code>                                    | Verifies the configuration.                               |

When configuring the route-target extended community, note the following information:

- **import**—Imports routing information from the target VPN extended community.
- **export**—Exports routing information to the target VPN extended community.
- **both**—Imports and exports.
- **route\_target\_ext\_community**—Adds the 48-bit route-target extended community to the VRF. Enter the number in one of the following formats:
  - 16-bit AS number:your 32-bit number (101:3)
  - 32-bit IPv4 address:your 16-bit number (192.168.122.15:1)

This example shows how to configure 55:1111 as the import and export route-target extended community and verify the configuration:

```
Tqvwgt*eqphki/xth+%"tqwvg/vctigv"dqvj"77<3333"
Tqvwgt*eqphki/xth+%"fq"ujqy"kr"xth"fgvckn"
XTH"dnwg="fghcwnv"TF"77<3333="fghcwnv"XRPKF">pqv"ugv@
XTH"Vcdng"KF"? "3
" "Pq"kpvgthcegu
" "Eqppgevgf"cfftgugu"ctg"pqv"kp"inqdcn"tqwvkpi"vcdng
" "Gzrqtv"XRP"tqwvg/vctigv"eqoowpkvkgu
" "TV<77<3333"
" "Korqtv"XRP"tqwvg/vctigv"eqoowpkvkgu
" "TV<77<3333"
" "Pq"korqtv"tqwvg/ocr
" "Pq"gzrqtv"tqwvg/ocr
EUE"ku"pqv"eqphkiwtgf0
```

## Configuring the Default MDT

To configure the default MDT, perform this task:

| Command                                                     | Purpose                     |
|-------------------------------------------------------------|-----------------------------|
| <code>Tqvwgt*eqphki/xth+%"ofv"fghcwnv"itqwracfftguu"</code> | Configures the default MDT. |

When configuring the default MDT, note the following information:

- The *group\_address* is the multicast IPv4 address of the default MDT group. This address serves as an identifier for the mVRF community, because all provider-edge (PE) routers configured with this same group address become members of the group, which allows them to receive the PIM control messages and multicast traffic that are sent by other members of the group.
- This same default MDT must be configured on each PE router to enable the PE routers to receive multicast traffic for this particular mVRF.

This example shows how to configure 239.1.1.1 as the default MDT:

```
Tqvwgt*eqphki/xth+%"ofv"fghcwnv"45;030303"
```

## Configuring Data MDTs (Optional)

To configure optional data MDTs, perform this task:

| Command                                                                                                                        | Purpose                                                                           |
|--------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
| <code>Tqvwgt*eqphki/xth+%"ofv"fcvc"group_address<br/>yknfectfadkvu"]vjtgujqnf"vjtgujqnfaxcnwg_" ]nkuv"<br/>ceeguankuv_"</code> | (Optional) Configures a data MDTs for the specified range of multicast addresses. |

When configuring optional data MDTs, note the following information:

- *group\_address1*—Multicast group address. The address can range from 224.0.0.1 to 239.255.255.255, but cannot overlap the address that has been assigned to the default MDT.
- *wildcard\_bits*—Wildcard bit mask to be applied to the multicast group address to create a range of possible addresses. This allows you to limit the maximum number of data MDTs that each mVRF can support.

- **threshold** *threshold\_value*—(Optional) Defines the threshold value in kilobits, at which multicast traffic should be switched from the default MDT to the data MDT. The *threshold\_value* parameter can range from 1 through 4294967 kilobits.
- **list** *access\_list*—(Optional) Specifies an access list name or number to be applied to this traffic.

This example shows how to configure a data MDT:

```
Tqwgvt*eqphki/xth+% "ofv"fcvc"45;030402"2020205"vjtgujqnf"32"
```

## Enabling Data MDT Logging

To enable data MDT logging, perform this task:

| Command                             | Purpose                                                                                                                                                                                                                                                                                                                    |
|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Tqwgvt*eqphki/xth+% "ofv"nqi/tgwug" | (Optional) Enables the recording of data MDT reuse information, by generating a SYSLOG message whenever a data MDT is reused. Frequent reuse of a data MDT might indicate a need to increase the number of allowable data MDTs by increasing the size of the wildcard bitmask that is used in the <b>mdt data</b> command. |

This example shows how to enable data MDT logging:

```
Tqwgvt*eqphki/xth+% "ofv"nqi/tgwug"
```

## Sample Configuration

The following excerpt from a configuration file shows typical VRF configurations for a range of VRFs. To simplify the display, only the starting and ending VRFs are shown.

```
#
kr"xth"oxrp/ewu3
"tf"422<3
"tqwvg/vctigv"gzrqtv"422<3
"tqwvg/vctigv"korqtv"422<3
"ofv"fghcwnv"45;030303
#
kr"xth"oxrp/ewu4
"tf"422<4
"tqwvg/vctigv"gzrqtv"422<4
"tqwvg/vctigv"korqtv"422<4
"ofv"fghcwnv"45;030304
#
kr"xth"oxrp/ewu5
"tf"422<5
"tqwvg/vctigv"gzrqtv"422<5
"tqwvg/vctigv"korqtv"422<5
"ofv"fghcwnv"45;030305
#
000

kr"xth"oxrp/ewu46;
"tf"422<46;
"tqwvg/vctigv"gzrqtv"422<46;
"tqwvg/vctigv"korqtv"422<46;
"ofv"fghcwnv"45;0303046;
"ofv"fcvc"45;0303034;"2020209"
```



```

""""""""Z"/"Rtqz{"Lqkp"Vkogt"Twppkpi"."C"/"Ecpfkfcvg"hqt"OUFR"Cfxgtvkugogpv.
""""""""W"/"WTF"."K"/"Tgegkxgf"Uqwteg"Urgekhke"Jquv"Trgrtv."\"/"Ownvkecuv"Vwppgn
""""""""["/"Lqkpgf"OFV/fcvc"itqwr."{"/"Ugpfkpi"vq"OFV/fcvc"itqwr
Qwviqkpi"kpvgthceg"hnciu<"J"/"Jctfyctg"uykvejgf
"Vkogtu<"Wrvkog1Gzrktgu
"Kpvgthceg"uvcvg<"Kpvgthceg"."Pgzv/Jqr"qt"XEF"."Uvcvg1Oqfg
*,".44:030203+."22<38<471uvqrrgf"."TR"32032032034."hnciu<"ULEH
""Kpegokpi"kpvgthceg<"Vwppgn3"."TRH"pdt"32032032034"."Rctvkcnu/UE
""Qwviqkpi"kpvgthceg"nkuv<
""""IkicdkvGvjgtpgv51305223"."Hqtyctf1Urctug/Fgpug"."22<38<47122<24<6;."J
*80;020322"."44:030203+."22<36<35122<25<4;."hnciu<"HV
""Kpegokpi"kpvgthceg<"IkicdkvGvjgtpgv51305223"."TRH"pdt"2020202"."TRH/OHF
""Qwviqkpi"kpvgthceg"nkuv<
""""Vwppgn3"."Hqtyctf1Urctug/Fgpug"."22<36<35122<24<68"."J

```

Tqwvgt%"



#### Note

In this example, the **show ip mroute vrf** command shows that Tunnel1 is the MDT tunnel interface (MTI) being used by this VRF.

## Configuring Multicast VRF Routing

- [Enabling IPv4 Multicast Routing Globally, page 50-16](#)
- [Enabling IPv4 Multicast VRF Routing, page 50-17](#)
- [Specifying the PIM VRF RP Address, page 50-17](#)
- [Configuring a PIM VRF Register Message Source Address \(Optional\), page 50-18](#)
- [Configuring an MSDP Peer \(Optional\), page 50-18](#)
- [Configuring the Maximum Number of Multicast Routes \(Optional\), page 50-18](#)
- [Sample Configuration, page 50-19](#)
- [Displaying IPv4 Multicast VRF Routing Information, page 50-20](#)



#### Note

BGP should be already configured and operational on all routers that are sending or receiving multicast traffic. In addition, BGP extended communities must be enabled (using the **neighbor send-community both** or **neighbor send-community extended** command) to support the use of MDTs in the network.

## Enabling IPv4 Multicast Routing Globally

To enable IPv4 multicast routing globally, perform this task:

|        | Command                               | Purpose                                  |
|--------|---------------------------------------|------------------------------------------|
| Step 1 | Tqwvgt%"eqphkiwtg"vgtokpcn"           | Enters global configuration mode.        |
| Step 2 | Tqwvgt*eqphki+%"kr"ownvkecuv/tqwvkpi" | Enables IPv4 multicast routing globally. |

This example show how to enable IPv4 multicast routing globally:

```

Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+%"kr"ownvkecuv/tqwvkpi"

```

## Enabling IPv4 Multicast VRF Routing

To enable IPv4 multicast VRF routing, perform this task:

| Command                                                                                         | Purpose                             |
|-------------------------------------------------------------------------------------------------|-------------------------------------|
| <code>Tqwvgt*eqphki+%<b>kr</b>"ownvkecuv/tqwvkpi"<b>xth</b>"xthapcog"<br/>]fkuvtkdwvgf_"</code> | Enables IPv4 multicast VRF routing. |

When enabling IPv4 multicast VRF routing, note the following information:

- **vrf\_name**—Specifies a particular VRF for multicast routing. The **vrf\_name** should see a VRF that has been previously created, as specified in the [“Configuring a Multicast VPN Routing and Forwarding Instance”](#) section on page 50-11.
- **distributed**—(Optional) Enables Multicast Distributed Switching (MDS).

This example show how to enable IPv4 multicast VRF routing:

```
Tqwvgt%eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+%kr"ownvkecuv/tqwvkpi"xth"dnwg"
```

## Specifying the PIM VRF RP Address

To specify the PIM VRF rendezvous point (RP) address, perform this task:

| Command                                                                                                                                            | Purpose                                                                     |
|----------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
| <code>Tqwvgt*eqphki+%<b>kr</b>"rko"<b>xth</b>"xthapcog"<b>tr</b>/<b>cfftguu</b>"<br/>tracfftguu"]ceeguankuv_"<b>q</b>xgttkfg_"<b>dkfkt</b>"</code> | Specifies the PIM RP IPv4 address for a (required for sparse PIM networks): |

When specifying the PIM VRF RP address, note the following information:

- **vrf vrf\_name**—(Optional) Specifies a particular VRF instance to be used.
- **rp\_address**—Unicast IP address for the PIM RP router.
- **access\_list**—(Optional) Number or name of an access list that defines the multicast groups for the RP.
- **override**—(Optional) In the event of conflicting RP addresses, this particular RP overrides any RP that is learned through Auto-RP.
- **bidir**—(Optional) Specifies that the multicast groups specified by the **access\_list** argument are to operate in bidirectional mode. If this option is not specified, the groups operate in PIM sparse mode.
- Use bidirectional mode whenever possible, because it offers better scalability.

This example show how to specify the PIM VRF RP address:

```
Tqwvgt*eqphki+%kr"rko"xth"dnwg"tr/cfftguu"3;:03;80322055"
```

## Configuring a PIM VRF Register Message Source Address (Optional)

To configure a PIM VRF register message source address, perform this task:

| Command                                                                                                      | Purpose                                                                                                                                         |
|--------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwvgt*eqphki+%<b>"kr"rko"xth"</b>xthapcog"tgikuvgt/uqwtg"<br/>interface_type interface_number"</code> | (Optional) Configures a PIM VRF register message source address. You can configure a loopback interface as the source of the register messages. |

This example show how to configure a PIM VRF register message source address:

```
Tqwvgt*eqphki+%"kr"rko"xth"dnwg"tgikuvgt/uqwtg"nqgrdcem"5"
```

## Configuring an MSDP Peer (Optional)

To configure a multicast source discovery protocol (MSDP) peer, perform this task:

| Command                                                                                                                                                            | Purpose                             |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|
| <code>Tqwvgt*eqphki+%<b>"kr"oufr"xth"</b>vrf_name rggt"}rggtapcog"<br/>~"rggtacfftguu;"]eqppgev/uqwtg"kpvgthcegav{rg"<br/>kpvgthcegawodgt_"}tgoqvg/cu"ASN_"</code> | (Optional) Configures an MSDP peer. |

When configuring an MSDP peer, note the following information:

- **vrf vrf\_name**—Specifies a particular VRF instance to be used.
- **{peer\_name | peer\_address}**—Domain Name System (DNS) name or IP address of the MSDP peer router.
- **connect-source interface\_type interface\_number**—Interface name and number for the interface whose primary address is used as the source IP address for the TCP connection.
- **remote-as ASN**—(Optional) Autonomous system number of the MSDP peer. This is for display-only purposes.

This example show how to configure an MSDP peer:

```
Tqwvgt*eqphki+%"kr"oufr"rggt"tqwvgt0ekueq0eqo"eqppgev/uqwtg"ikicdkvgvjgtpgv"313"tgoqvg/cu"
32;"
```

## Configuring the Maximum Number of Multicast Routes (Optional)

To configure the maximum number of multicast routes, perform this task:

| Command                                                                                           | Purpose                                                                                               |
|---------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------|
| <code>Tqwvgt*eqphki+%<b>"kr"ownvkecuv"xth"</b>vrf_name tqwvg/nkokv"<br/>nkokv"]vjtgujqnf_"</code> | (Optional) Configures the maximum number of multicast routes that can be added for multicast traffic. |



When configuring the maximum number of routes, note the following information:

- **vrf vrf\_name**— Enables route limiting for the specified VRF.
- **limit**—The number of multicast routes that can be added. The range is from 1 to 2147483647, with a default of 2147483647.
- **threshold**—(Optional) Number of multicast routes that can be added before a warning message occurs. The valid range is from 1 to the value of the *limit* parameter.

This example show how to configure the maximum number of multicast routes:

```
Tqwgvt*eqphki+% "kr"ownvkecuv"xth"dnwg"tqwg/nkokv"422222"42222"
```

## Configuring IPv4 Multicast Route Filtering (Optional)

To configure IPV4 multicast route filtering, perform this task:

| Command                                                     | Purpose                                                                                                                                                |
|-------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| Tqwgvt*eqphki+% "kr"ownvkecuv"otkphq/hknvgt"<br>ceeguankuv" | (Optional) Configures IPV4 multicast route filtering with an access list. The <i>access_list</i> parameter can be the name or number of a access list. |

This example show how to configure IPV4 multicast route filtering:

```
Tqwgvt*eqphki+% "kr"ownvkecuv"otkphq/hknvgt" 323 "
```

## Sample Configuration

The following excerpt from a configuration file shows the minimum configuration that is needed to support multicast routing for a range of VRFs. To simplify the display, only the starting and ending VRFs are shown.

```
#
kr"ownvkecuv/tqgvkpi"
kr"ownvkecuv/tqgvkpi"xth"nkvgt"
kr"ownvkecuv/tqgvkpi"xth"xrp423"
kr"ownvkecuv/tqgvkpi"xth"xrp424"

000

kr"ownvkecuv/tqgvkpi"xth"xrp46;"
kr"ownvkecuv/tqgvkpi"xth"xrp472"

000

kr"rko"tr/cfftguu"3;4020303
kr"rko"xth"nkvgt"tr/cfftguu"326030304
kr"rko"xth"xrp423"tr/cfftguu"3;404220303
kr"rko"xth"xrp424"tr/cfftguu"3;404220403

000

kr"rko"xth"xrp46;"tr/cfftguu"3;4042206;08
kr"rko"xth"xrp472"tr/cfftguu"3;4042207208
000"
```

## Displaying IPv4 Multicast VRF Routing Information

To display the known PIM neighbors for a particular mVRF, use the **show ip pim vrf neighbor** command:

```
Tqwgvt% "ujqy"kr"rko"xth"; : "pgkijdt"

RKO"Pgkijdt"Vcdng
Pgkijdt"Kpvgthceg"Wrvmog1Gzrktgu""Xgt""FT
Cfftguu""Rtkq1Oqfg
6208202033""Vwppgn;8""22<22<53122<23<35"x4""3"1"U
6207202033""Vwppgn;8""22<22<76122<22<72"x4""3"1"U

Tqwgvt%
```

## Configuring Interfaces for Multicast Routing to Support mVPN

- [Multicast Routing Configuration Overview, page 50-20](#)
- [Configuring PIM on an Interface, page 50-21](#)
- [Configuring an Interface for IPv4 VRF Forwarding, page 50-21](#)
- [Sample Configuration, page 50-22](#)

## Multicast Routing Configuration Overview

Protocol Independent Multicast (PIM) must be configured on all interfaces that are being used for IPv4 multicast traffic. In a VPN multicast environment, you should enable PIM on at least all of the following interfaces:

- Physical interface on a provider edge (PE) router that is connected to the backbone.
- Loopback interface that is used for BGP peering.
- Loopback interface that is used as the source for the sparse PIM rendezvous point (RP) router address.

In addition, you must also associate mVRFs with those interfaces over which they are going to forward multicast traffic.

BGP should be already configured and operational on all routers that are sending or receiving multicast traffic. In addition, BGP extended communities must be enabled (using the **neighbor send-community both** or **neighbor send-community extended** command) to support the use of MDTs in the network.

## Configuring PIM on an Interface

To configure PIM on an interface, perform this task:

|        | Command                                                                   | Purpose                                                          |
|--------|---------------------------------------------------------------------------|------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt% "eqphkiwtg" vgtokpcn</code>                                 | Enters global configuration mode.                                |
| Step 2 | <code>Tqwvgt *eqphki+%"kpvgthceg" v{rg} slot/port "~" pwodgti "</code>    | Enters interface configuration mode for the specified interface. |
| Step 3 | <code>Tqwvgt *eqphki/kh+%"kr"rko" }fgpug/oqfg" ~" urctug/oqfg "i "</code> | Enables PIM on the interface.                                    |

When configuring PIM on an interface, note the following information:

- You can use one of these interface types:
  - A physical interface on a provider edge (PE) router that is connected to the backbone.
  - A loopback interface that is used for BGP peering.
  - A loopback interface that is used as the source for the sparse PIM network rendezvous point (RP) address.
- These are the PIM modes:
  - dense-mode**—Enables dense mode of operation.
  - sparse-mode**—Enables sparse mode of operation.
  - sparse-dense-mode**—Enables sparse mode if the multicast group has an RP router defined, or enables dense mode if an RP router is not defined.
- Use **sparse-mode** for the physical interfaces of all PE routers that are connected to the backbone, and on all loopback interfaces that are used for BGP peering or as the source for RP addressing.

This example shows how to configure PIM sparse mode on a physical interface:

```
Tqwvgt% "eqphkiwtg" vgtokpcn
Tqwvgt *eqphki+%"kpvgthceg" iki cdkvgvjgtpgv "3213"
Tqwvgt *eqphki/kh+%"kr"rko" urctug/oqfg "
```

This example shows how to configure PIM sparse mode on a loopback interface:

```
Tqwvgt% "eqphkiwtg" vgtokpcn
Tqwvgt *eqphki+%"kpvgthceg" nqgrdcem "4"
Tqwvgt *eqphki/kh+%"kr"rko" urctug/oqfg "
```

## Configuring an Interface for IPv4 VRF Forwarding

To configure an interface for IPv4 VRF forwarding, perform this task:

| Command                                                        | Purpose                                                                                                                                                                                                                                                                                       |
|----------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwvgt *eqphki/kh+%"kr"xth" hqtyctfkpi "xthapcog"</code> | (Optional) Associates the specified VRF routing and forwarding tables with the interface. If this is not specified, the interface defaults to using the global routing table.<br><br><b>Note</b> Entering this command on an interface removes the IP address, so reconfigure the IP address. |

This example shows how to configure the interface for VRF blue forwarding:

```
Tqwgvt*eqphki/kh+%"kr"xth"htyctfkpi"dnwg"
```

## Sample Configuration

The following excerpt from a configuration file shows the interface configuration, along with the associated mVRF configuration, to enable multicast traffic over a single mVRF:

```
kr"ownvkecuv/tqwkpi"xth"dnwg"
kr"ownvkecuv/tqwkpi

kr"xth"dnwg"
"tf"322<49
"tqwg/vctigv"gzrqt"322<49
"tqwg/vctigv"korqt"322<49
"ofv"fgbcwnv"45;03;403204

kpvgtbceg"IkicdkvGvjgtpgv313
"fguetkrvkqp"dnwg"eqppgevkqp
"kr"xth"htyctfkpi"dnwg"
"kr"cfftgau"3;4038:04048"4770477047702
"kr"rko"urctug/oqfg

kpvgtbceg"IkicdkvGvjgtpgv3137
"fguetkrvkqp"Dcemdqp"eqppgevkqp
"kr"cfftgau"320:0604"4770477047702
"kr"rko"urctug/oqfg

kr"rko"xth"dnwg"tr/cfftgau"3;40904703
kr"rko"tr/cfftgau"32030303"
```

## Configuring mVPN with L3VPN over mGRE

- [Configuring an L3VPN Encapsulation Profile, page 50-22](#) (required)
- [Configuring BGP and Route Maps, page 50-23](#) (required)



### Note

See the [“Information About mVPN with L3VPN over mGRE”](#) section on [page 50-9](#) for more information.

## Configuring an L3VPN Encapsulation Profile



### Note

Transport protocols such as IPv6, MPLS, IP, and Layer 2 Tunneling Protocol version 3 (L2TPv3) can also be used in this configuration.

|        | Command or Action                                                                                                                                                             | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <b>gpcdng</b><br><br><b>Example:</b><br>Tqwvgt@"gpcdng                                                                                                                        | Enables privileged EXEC mode.<br><ul style="list-style-type: none"><li>Enter your password if prompted.</li></ul>                                                                                                                                                                                                                                                                                                                                                                                   |
| Step 2 | <b>eqphkiwtg"vgtokpcn</b><br><br><b>Example:</b><br>Tqwvgt%"eqphkiwtg"vgtokpcn                                                                                                | Enters global configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Step 3 | <b>n5xrp"gpecruwncvkqp"kr" <i>profile-name</i></b><br><br><b>Example:</b><br>Tqwvgt*eqphki+%"n5xrp"gpecruwncvkqp"kr"vwppgn"<br>gpecr                                          | Enters L3 VPN encapsulation configuration mode to create the tunnel.                                                                                                                                                                                                                                                                                                                                                                                                                                |
| Step 4 | <b>vtcpurqtv"krx6"]uqwtg" <i>interface-type</i><br/><i>interface-number_</i></b><br><br><b>Example:</b><br>Tqwvgt*eqphki/n5xrp/gpecr/kr+%"vtcpurqtv"krx6"<br>uqwtg"nqgrdcem"2 | (Optional) Specifies IPv4 transport source mode and defines the transport source interface.<br><ul style="list-style-type: none"><li>If you use the <b>transport ipv4 source <i>interface-type interface-number</i></b> command, make sure that the specified source address is used as the next hop in BGP updates advertised by the PE.</li><li>If you do not use this command, the <b>bgp update source</b> or <b>bgp next-hop</b> command is automatically used as the tunnel source.</li></ul> |
| Step 5 | <b>rtqvqeqn"itg"]mg{" <i>gre-key_</i></b><br><br><b>Example:</b><br>Tqwvgt*eqphki/n5xrp/gpecr/kr+%"rtqvqeqn"itg"mg{"<br>3456                                                  | Specifies GRE as the tunnel mode and sets the GRE key.                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Step 6 | <b>gpf</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/n5xrp/gpecr/kr+%"gpf                                                                                                       | Exits L3 VPN encapsulation configuration mode and returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Step 7 | <b>ujqy"n5xrp"gpecruwncvkqp"kr" <i>profile-name</i></b><br><br><b>Example:</b><br>Tqwvgt%"ujqy"n5xrp"gpecruwncvkqp"kr"vwppgn"<br>gpecr                                        | (Optional) Displays the profile health and the underlying tunnel interface.                                                                                                                                                                                                                                                                                                                                                                                                                         |

## Configuring BGP and Route Maps

Perform this task to configure BGP and route maps. The following steps also enable you to link the route map to the application template and set up the BGP VPNv4 and VPNv6 exchange so that the updates are filtered through the route map.

|         | Command or Action                                                                                                                                         | Purpose                                                                                                                                                                                                                                             |
|---------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1  | <b>gpcdn</b><br><br><b>Example:</b><br>Tqwgvt@"gpcdn                                                                                                      | Enables privileged EXEC mode.<br><ul style="list-style-type: none"><li>Enter your password if prompted.</li></ul>                                                                                                                                   |
| Step 2  | <b>eqphkiwtg"vgtokpcn"</b><br><br><b>Example:</b><br>Tqwgvt%"eqphkiwtg"vgtokpcn                                                                           | Enters global configuration mode.                                                                                                                                                                                                                   |
| Step 3  | <b>tqwgvt"dir"as-number</b><br><br><b>Example:</b><br>Tqwgvt*eqphki+%"tqwgvt"dir"322                                                                      | Specifies the number of an autonomous system that identifies the router to other BGP routers and tags the routing information passed along, and enters router configuration mode.                                                                   |
| Step 4  | <b>dir"nqi/pgkijdt/ejcpigu</b><br><br><b>Example:</b><br>Tqwgvt*eqphki/tqwgvt+%"dir"nqi/pgkijdt/ejcpigu                                                   | Enables logging of BGP neighbor resets.                                                                                                                                                                                                             |
| Step 5  | <b>pgkijdt"ip-address"tgoqvg/cu"as-number</b><br><br><b>Example:</b><br>Tqwgvt*eqphki/tqwgvt+%"pgkijdt"42;038704220447"<br>tgoqvg/cu"322                  | Adds an entry to the BGP or multiprotocol BGP neighbor table.                                                                                                                                                                                       |
| Step 6  | <b>pgkijdt"ip-address"wrfcvg/uqwtg"interface name</b><br><br><b>Example:</b><br>Tqwgvt*eqphki/tqwgvt+%"pgkijdt"42;038704220447"<br>wrfcvg/uqwtg"nqrdcem"2 | Allows BGP sessions to use any operational interface for TCP connections.                                                                                                                                                                           |
| Step 7  | <b>cfftguu/hcokn{"krx6"</b><br><br><b>Example:</b><br>Tqwgvt*eqphki/tqwgvt+%"cfftguu/hcokn{"krx6                                                          | Enters address family configuration mode to configure routing sessions that use IPv4 address prefixes.                                                                                                                                              |
| Step 8  | <b>pq"u{pejtqpk cvkqp</b><br><br><b>Example:</b><br>Tqwgvt*eqphki/tqwgvt/ch+%"pq"u{pejtqpk cvkqp                                                          | Enables the Cisco IOS software to advertise a network route without waiting for an IGP.                                                                                                                                                             |
| Step 9  | <b>tgfkuvtkdwvg"eqppgevgf</b><br><br><b>Example:</b><br>Tqwgvt*eqphki/tqwgvt/ch+%"tgfkuvtkdwvg"<br>eqppgevgf                                              | Redistributes routes from one routing domain into another routing domain and allows the target protocol to redistribute routes learned by the source protocol and connected prefixes on those interfaces over which the source protocol is running. |
| Step 10 | <b>pgkijdt"ip-address"cevkxcvg</b><br><br><b>Example:</b><br>Tqwgvt*eqphki/tqwgvt/ch+%"pgkijdt"<br>42;038704220447"cevkxcvg                               | Enables the exchange of information with a BGP neighbor.                                                                                                                                                                                            |

|         | Command or Action                                                                                                                                                        | Purpose                                                                                                                        |
|---------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| Step 11 | <b>pg"cwvg/uwooct{</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/tqwvgt/ch+%"pg"cwvg/uwooct{                                                                               | Disables automatic summarization and sends subprefix routing information across classful network boundaries.                   |
| Step 12 | <b>gzkv</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/tqwvgt/ch+%"gzkv                                                                                                     | Exits address family configuration mode.                                                                                       |
| Step 13 | <b>cfftguu/hcokn{"xrpx6"</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/tqwvgt+%"cfftguu/hcokn{"xrpx6                                                                       | Enters address family configuration mode to configure routing sessions, such as BGP, that use standard VPNv4 address prefixes. |
| Step 14 | <b>pgkijdt"ip-address"cevkxcvg</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/tqwvgt/ch+%"pgkijdt"<br>42;038704220447"cevkxcvg                                              | Enables the exchange of information with a BGP neighbor.                                                                       |
| Step 15 | <b>pgkijdt"ip-address"ugpf/eqoowpkv{"dqvj</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/tqwvgt/ch+%"pgkijdt"<br>42;038704220447"ugpf/eqoowpkv{"dqvj                        | Specifies that a communities attribute, for both standard and extended communities, should be sent to a BGP neighbor.          |
| Step 16 | <b>pgkijdt"ip-address"tqwvg/ocr"map-name kp</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/tqwvgt/ch+%"pgkijdt"<br>42;038704220447"tqwvg/ocr"<br>UGNGEVaWRFCVGaHQTaN5XRP"kp | Applies the named route map to the incoming route.                                                                             |
| Step 17 | <b>gzkv</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/tqwvgt/ch+%"gzkv                                                                                                     | Exits address family configuration mode.                                                                                       |
| Step 18 | <b>cfftguu/hcokn{"xrpx8</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/tqwvgt+%"cfftguu/hcokn{"xrpx8                                                                        | Enters address family configuration mode to configure routing sessions, such as BGP, that use VPNv6 address prefixes.          |
| Step 19 | <b>pgkijdt"ip-address"cevkxcvg</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/tqwvgt/ch+%"pgkijdt"<br>42;038704220474"cevkxcvg                                              | Enables the exchange of information with a BGP neighbor.                                                                       |
| Step 20 | <b>pgkijdt"ip-address"ugpf/eqoowpkv{"dqvj</b><br><br><b>Example:</b><br>Tqwvgt*eqphki/tqwvgt/ch+%"pgkijdt"<br>42;038704220474"ugpf/eqoowpkv{"dqvj                        | Specifies that a communities attribute, for both standard and extended communities, should be sent to a BGP neighbor.          |

|         | Command or Action                                                                                                                                                                                                      | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 21 | <p><b>pgkijdqdt</b> <i>ip-address</i> <b>tqwvg/ocr</b> <i>map-name</i> <b>kp</b></p> <p><b>Example:</b><br/> Tqwvgt*eqphki/tqwvgt/ch+%"pgkijdqdt"<br/> 42;038704220474"tqwvg/ocr"<br/> UGNGEVaWRFVCVGaHQTaN5XRP"kp</p> | Applies the named route map to the incoming route.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Step 22 | <p><b>gzkv</b></p> <p><b>Example:</b><br/> Tqwvgt*eqphki/tqwvgt/ch+%"gzkv</p>                                                                                                                                          | Exits address family configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Step 23 | <p><b>tqwvg/ocr</b> <i>map-tag</i> <b>rgtokv</b> <i>position</i></p> <p><b>Example:</b><br/> Tqwvgt*eqphki/tqwvgt+%"tqwvg/ocr"<br/> UGNGEVaWRFVCVGaHQTaN5XRP"rgtokv"32</p>                                             | <p>Enters route-map configuration mode and defines the conditions for redistributing routes from one routing protocol into another.</p> <ul style="list-style-type: none"> <li>The <b>redistribute</b> router configuration command uses the specified map tag to reference this route map. Multiple route maps may share the same map tag name.</li> <li>If the match criteria are met for this route map, the route is redistributed as controlled by the set actions.</li> <li>If the match criteria are not met, the next route map with the same map tag is tested. If a route passes none of the match criteria for the set of route maps sharing the same name, it is not redistributed by that set.</li> <li>The <i>position</i> argument indicates the position a new route map will have in the list of route maps already configured with the same name.</li> </ul> |
| Step 24 | <p><b>ugv</b> <i>kr</i> <b>pgzv/jqr</b> <b>gpecruwncvg</b> <b>n5xrp</b> <i>profile-name</i></p> <p><b>Example:</b><br/> Tqwvgt*eqphki/tqwvg/ocr+%"ugv"kr"pgzv/jqr"<br/> gpecruwncvg"n5xrp"o{ "rtqhkng</p>              | Indicates that output IPv4 packets that pass a match clause of the route map are sent to the VRF for tunnel encapsulation.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Step 25 | <p><b>ugv</b> <b>krx8</b> <b>pgzv/jqr</b> <b>gpecruwncvg</b> <b>n5xrp</b> <i>profile-name</i></p> <p><b>Example:</b><br/> Tqwvgt*eqphki/tqwvg/ocr+%"ugv"kr"pgzv/jqr"<br/> gpecruwncvg"n5xrp"vwppgn"gpecr</p>           | Indicates that output IPv6 packets that pass a match clause of the route map are sent to the VRF for tunnel encapsulation.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Step 26 | <p><b>gzkv</b></p> <p><b>Example:</b><br/> Tqwvgt*eqphki/tqwvg/ocr+%"gzkv</p>                                                                                                                                          | Exits route-map configuration mode and enters global configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Step 27 | <p><b>gzkv</b></p> <p><b>Example:</b><br/> Tqwvgt*eqphki+%"gzkv</p>                                                                                                                                                    | Exits global configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |



# Configuration Examples for mVPNs

- [mVPN Configuration with Default MDTs Only, page 50-27](#)
- [mVPN Configuration with Default and Data MDTs, page 50-29](#)
- [Verifying the mVPN with L3VPN over mGRE Configuration, page 50-32](#)
- [Configuration Sequence for mVPN with L3VPN over mGRE, page 50-33](#)

## mVPN Configuration with Default MDTs Only

The following excerpt from a configuration file shows the lines that are related to the mVPN configuration for three mVRFs. (The required BGP configuration is not shown.)

```
#
ugtckeg"vkoguvcoru"fgdwi"fcvgvkog"ouge
ugtckeg"vkoguvcoru"nqi"fcvgvkog"ouge
ugtckeg"rcuuyqtf/gpet{rvkqp
ugtckeg"eqortguu/eqphki
#
jquvpcog"OXRPTqwgvt"
#
dqqv"u{uvgo"hncuj"unqv2<
nqiikpi"upor/cwvjhckn
#
kr"uwdpgv/|gtq
#
pq"kr"fqockp/nqqmwr
kr"jquv"vhvr"44504770476045:
#
kr"xth"oxrp/ewu3
"tf"422<3
"tqwg/vctigv"gzrqtvt"422<3
"tqwg/vctigv"korqtvt"422<3
"ofv"fghcwnv"45;030303
#
kr"xth"oxrp/ewu4
"tf"422<4
"tqwg/vctigv"gzrqtvt"422<4
"tqwg/vctigv"korqtvt"422<4
"ofv"fghcwnv"45;030304
#
kr"xth"oxrp/ewu5
"tf"422<5
"tqwg/vctigv"gzrqtvt"422<5
"tqwg/vctigv"korqtvt"422<5
"ofv"fghcwnv"45;030305
#
kr"ownvkecuv/tqgvkpi"
kr"ownvkecuv/tqgvkpi"xth"oxrp/ewu3"
kr"ownvkecuv/tqgvkpi"xth"oxrp/ewu4"
kr"ownvkecuv/tqgvkpi"xth"oxrp/ewu5"
kr"ownvkecuv"ownvkrcvj
htcog/tgnc{"uykvejkipi
ornu"ncdgn"tcpig"6334"484365
ornu"ncdgn"rtqvqegn"nfr
ornu"nfr"nqiikpi"pgkijdt/ejcpigu
ornu"nfr"gzrnkekv/pwnn
ornu"vtchhke/gpi"vwppgnu
ornu"vfr"fkueqxt{"fktgevgf/jgnnq"ceegrvt"htqo"3
```

```

ornu"vfr"tqwvgt/kf"Nqqrdcem2"hqteg
rncvqhcto"hnqy"kr"fguvkpcvkqp
pq"rncvqhcto"hnqy"krx8
rncvqhcto"tcvg/nkokv"wpkecuv"egh"ingcp"32"32
rncvqhcto"squ
rncvqhcto"egh"gttqt"cevkqp"htgg|g

000

xncp"kpvgthpcn"cnnqecvkqp"rqnke{"cuegpfkpi
xncp"ceeguu/nqi"tcvgnkokv"4222
#
xncp"4223/4323.5723/5922.6223.6273/62:2.62;5"
#
#
#
kpvgthceg"Nqqrdcem2
"kr"cfftguu"423047403036"477047704770477
"kr"rko"urctug/fgpug/oqfg
#
kpvgthceg"Nqqrdcem3
"kr"cfftguu"42;04770477036"477047704770477
#
kpvgthceg"Nqqrdcem32
"kr"xth"hqtyctfkpi"oxrp/ewu3
"kr"cfftguu"43203230477036"477047704770477
#
kpvgthceg"Nqqrdcem33
"kr"xth"hqtyctfkpi"oxrp/ewu3
"kr"cfftguu"43203330477036"477047704770477
"kr"rko"urctug/fgpug/oqfg
#
kpvgthceg"Nqqrdcem34
"kr"xth"hqtyctfkpi"oxrp/ewu3
"kr"cfftguu"43203340477036"477047704770477

000

#
kpvgthceg"IkicdkvGvjgtpgv515
"ovw";438
"kr"xth"hqtyctfkpi"oxrp/ewu5
"kr"cfftguu"39403203603"4770477047702
"kr"rko"urctug/fgpug/oqfg
#

000

#
kpvgthceg"IkicdkvGvjgtpgv513;
"kr"xth"hqtyctfkpi"oxrp/ewu4
"kr"cfftguu"3;40380603"4770477047702
"kr"rko"urctug/fgpug/oqfg
"kr"kior"uvcvke/itqwr"44;030303
"kr"kior"uvcvke/itqwr"44;030304
"kr"kior"uvcvke/itqwr"44;030306
#
kpvgthceg"IkicdkvGvjgtpgv5142
"kr"xth"hqtyctfkpi"oxrp/ewu3
"kr"cfftguu"3;40380303"4770477047702
"kr"rko"urctug/fgpug/oqfg
#

000

```

## mVPN Configuration with Default and Data MDTs

The following sample configuration includes three mVRFs that have been configured for both default and data MDTs. Only the configuration that is relevant to the mVPN configuration is shown.

```
000
#
kr"xth"x3"
"tf"3<3
"tqwvg/vctigv"gzrqtvtv"3<3
"tqwvg/vctigv"korqtvtv"3<3
"ofv"fgbcwnv"448030303
"ofv"fcvc"4480303034:"2020209"vjtgujqnf"3
#
kr"xth"x4
"tf"4<4
"tqwvg/vctigv"gzrqtvtv"4<4
"tqwvg/vctigv"korqtvtv"4<4
"ofv"fgbcwnv"448040403
"ofv"fcvc"4480404034:"2020209
#
kr"xth"x5
"tf"5<5
"tqwvg/vctigv"gzrqtvtv"5<5
"tqwvg/vctigv"korqtvtv"5<5
"ofv"fgbcwnv"448050503
"ofv"fcvc"4480505034:"2020209
#
kr"xth"x6
"tf"3770477047703<6
"tqwvg/vctigv"gzrqtvtv"3770477047703<6
"tqwvg/vctigv"korqtvtv"3770477047703<6
"ofv"fgbcwnv"448060603
"ofv"fcvc"4480606034:"2020209
#
kr"ownvkecuv/tqwkpi"
kr"ownvkecuv/tqwkpi"xth"x3"
kr"ownvkecuv/tqwkpi"xth"x4"
kr"ownvkecuv/tqwkpi"xth"x5"
kr"ownvkecuv/tqwkpi"xth"x6"
ornu"ncdgn"rtqvqeqn"nfr
ornu"nfr"nqiikpi"pgkijdt/ejcpigu
ornu"vfr"tqwvgt/kf"Nqgrdcem3
rncvhtqto"kr"ownvkecuv"tgrnkecvkqp/oqfg"kpitguu
rncvhtqto"kr"ownvkecuv"dkfkt"io/uecp/kpvgtxcn"32
pq"rncvhtqto"hnqy"kr
pq"rncvhtqto"hnqy"krx8
rncvhtqto"egh"gttqt"cevkqp"htgg|g
#

000

xncp"kpvgtpcn"cnnqecvkqp"rqnke{"cuegpfkpi
xncp"ceeguu/nqi"tcvgnkokv"4222
#
#
kpvgthceg"Nqgrdcem3
"kr"cfftguu"3770477047703"477047704770477
"kr"rko"urctug/oqfg
#
kpvgthceg"Nqgrdcem33
"kr"xth"hgtyctfkpi"x3
"kr"cfftguu"37704770477033"477047704770477
```

```

"kr"rko"urctug/fgpug/oqfg
#
kpvgtthceg"Nqgrdcem44
"kr"xth"hqtyctfkpi"x4
"kr"cfftgau"37704770477044"477047704770477
"kr"rko"urctug/oqfg
#
kpvgtthceg"Nqgrdcem55
"kr"xth"hqtyctfkpi"x5
"kr"cfftgau"37704770477055"477047704770477
"kr"rko"urctug/oqfg
#
kpvgtthceg"Nqgrdcem66
"kr"xth"hqtyctfkpi"x6
"kr"cfftgau"37704770606"477047704770477
"kr"rko"urctug/oqfg
#
kpvgtthceg"Nqgrdcem333
"kr"xth"hqtyctfkpi"x3
"kr"cfftgau"32030303"477047704770474
"kr"rko"urctug/fgpug/oqfg
"kr"qurh"pgvyqtm"rqkpv/vq/rqkpv
#
kpvgtthceg"IkicdkvGvjgtpgv313
"fguetkrvkqp"Ik313"/"377072030377"4770477047702"/"rggt"fwv72"/"ornu
"ovw";438
"kr"cfftgau"377072030377"4770477047702
"kr"rko"urctug/oqfg
"ornu"kr
#
kpvgtthceg"IkicdkvGvjgtpgv314
"kr"xth"hqtyctfkpi"x3
"kr"cfftgau"37703040476"4770477047702
"kr"rko"urctug/oqfg
#
kpvgtthceg"IkicdkvGvjgtpgv315
"fguetkrvkqp"Ik315"/"3:70377030377146"/"xth"x3"uvwd"rggt"3:70Ik315
"kr"xth"hqtyctfkpi"x3
"kr"cfftgau"3:70377030377"4770477047702
"kr"rko"urctug/oqfg
#

000

#
kpvgtthceg"IkicdkvGvjgtpgv316:
"kr"xth"hqtyctfkpi"x3
"kr"cfftgau"3790377030377"4770477047702
"kr"rko"dut/dqtfgt
"kr"rko"urctug/fgpug/oqfg
#
kpvgtthceg"IkicdkvGvjgtpgv813
"pq"kr"cfftgau
"ujwvfqyp
#
kpvgtthceg"IkicdkvGvjgtpgv814
"kr"cfftgau";030320377"4770477047702
"ogfkcv{rg"tl67
#
kpvgtthceg"Xncp3
"pq"kr"cfftgau
"ujwvfqyp
#
tqwgvt"qurh"33"xth"x3

```

```

"tqwvgt/kf"37704770477033
"nqi/cflcegepe{/ejcpigu
"tgfkuvtkdwvg"eqppgevgf"uwdpgvu"vci"377
"tgfkuvtkdwvg"dir"3"uwdpgvu"vci"377
"pgvyqtm"32030302"2020205"ctgc"377
"pgvyqtm"37704770477033"2020202"ctgc"377
"pgvyqtm"377020202"2047704770477"ctgc"377
"pgvyqtm"37903770302"202020477"ctgc"2
#
tqwvgt"qurh"44"xth"x4
"tqwvgt/kf"37704770477044
"nqi/cflcegepe{/ejcpigu
"pgvyqtm"37704770477044"2020202"ctgc"377
"pgvyqtm"377020202"2047704770477"ctgc"377
"pgvyqtm"37903770302"202020477"ctgc"2
#
tqwvgt"qurh"55"xth"x5
"tqwvgt/kf"37704770477055
"nqi/cflcegepe{/ejcpigu
"pgvyqtm"37704770477055"2020202"ctgc"377
#
tqwvgt"qurh"3
"nqi/cflcegepe{/ejcpigu
"pgvyqtm"3770720302"202020477"ctgc"2
"pgvyqtm"3770477047703"2020202"ctgc"377
#
tqwvgt"dir"3
"dir"tqwvgt/kf"3770477047703
"pq"dir"fghcwnv"krx6/wpkecuv
"dir"nqi/pgkijdqt/ejcpigu
"pgkijdqt"3970477047703"tgoqvg/cu"3
"pgkijdqt"3970477047703"wrfcvg/uqwtg"Nqqrdecem3
"pgkijdqt"3:70477047703"tgoqvg/cu"3
"pgkijdqt"3:70477047703"wrfcvg/uqwtg"Nqqrdecem3
#
"cfftguu/hcokn{"xrp6
"pgkijdqt"3970477047703"cevkxcvg
"pgkijdqt"3970477047703"ugpf/eqoowpkv{"gzvgpfgf
"pgkijdqt"3:70477047703"cevkxcvg
"pgkijdqt"3:70477047703"ugpf/eqoowpkv{"gzvgpfgf
"gzkv/cfftguu/hcokn{
#
"cfftguu/hcokn{"krx6"xth"x6
"pq"cwvq/uwooct{
"pq"u{pejtpk|cvkqp
"gzkv/cfftguu/hcokn{
#
"cfftguu/hcokn{"krx6"xth"x5
"tgfkuvtkdwvg"qurh"55
"pq"cwvq/uwooct{
"pq"u{pejtpk|cvkqp
"gzkv/cfftguu/hcokn{
#
"cfftguu/hcokn{"krx6"xth"x4
"tgfkuvtkdwvg"qurh"44
"pq"cwvq/uwooct{
"pq"u{pejtpk|cvkqp
"gzkv/cfftguu/hcokn{
#
"cfftguu/hcokn{"krx6"xth"x3
"tgfkuvtkdwvg"qurh"33
"pq"cwvq/uwooct{
"pq"u{pejtpk|cvkqp
"gzkv/cfftguu/hcokn{

```

```
#
kr"encuunguu
kr"tqvgv";0477047603"477047704770477";030320476
pq"kr"jvvr"ugtugt
kr"rko"dkfkt/gpcdng
kr"rko"tr/cfftguu"7204770404"OECUV00XRP00FV0x4"qxgttkfg"dkfkt
kr"rko"tr/cfftguu"7204770505"OECUV00XRP00FV0x5"qxgttkfg"dkfkt
kr"rko"tr/cfftguu"7204770303"OECUV00XRP00FV0x3"qxgttkfg"dkfkt
kr"rko"xth"x3"urv/vjtgujgnf"kphkpkv{
kr"rko"xth"x3"ugpf/tr/cppqwpeg"Nqgrdcem33"ueqrg"38"itqwr/nkuv"OECUV0ITQWR0DKFKT"dkfkt
kr"rko"xth"x3"ugpf/tr/fkueqxt{"Nqgrdcem33"ueqrg"38
kr"rko"xth"x3"dut/ecpfkfcvg"Nqgrdcem333"2
kr"oufr"xth"x3"rggt"3:704770477033"eqppgev/uqwtg"Nqgrdcem33
kr"oufr"xth"x3"eejg/uc/ucvg
#
#
kr"ceeguu/nkuv"uvcpfctf"OECUV0CP[ECUV0EG
"rgtokv"4040404
kr"ceeguu/nkuv"uvcpfctf"OECUV0CP[ECUV0RG
"rgtokv"32030303
kr"ceeguu/nkuv"uvcpfctf"OECUV0DQWPFCT[0XTH0x3
"fgp{" " "44803;40303
"rgtokv"cp{
kr"ceeguu/nkuv"uvcpfctf"OECUV0ITQWR0DKFKT
"rgtokv"44803;40202"20204770477
kr"ceeguu/nkuv"uvcpfctf"OECUV0ITQWR0URCTUG
"rgtokv"44803;50202"20204770477
kr"ceeguu/nkuv"uvcpfctf"OECUV00XRP0DQWPFCT[0FCVC00FV
"fgp{" " "4480303034:
"rgtokv"cp{
kr"ceeguu/nkuv"uvcpfctf"OECUV00XRP00FV0x3
"rgtokv"448030202"20204770477
kr"ceeguu/nkuv"uvcpfctf"OECUV00XRP00FV0x4
"rgtokv"448040202"20204770477
kr"ceeguu/nkuv"uvcpfctf"OECUV00XRP00FV0x5
"rgtokv"448050202"20204770477
kr"ceeguu/nkuv"uvcpfctf"OECUV00XRP0TR0x6
"rgtokv"449020202"2047704770477
#
ceeguu/nkuv"3"rgtokv"448030303
ceeguu/nkuv"4"fgp{" " "448030303
ceeguu/nkuv"4"rgtokv"cp{
000
```

## Verifying the mVPN with L3VPN over mGRE Configuration

Use the following examples to verify that the configuration is working properly:

### Endpoint Creation

You can verify the tunnel endpoint that has been created:

```
Tqvgvt%"ujqy"vwppgn"gpfrqkpvu"vwppgn"2"
"Vwppgn2"twppkpi"kp"ownvk/ITG1KR"oqfg
"Gpfrqkpv"vtcpurqtv"42;038704220473"Tgheqwpv"5"Dcug"2z4CG;5H2"Etgcvg"Vkog"22<22<64
" "qxgtnc{" "42;038704220476"Tgheqwpv"4"Rctgpv"2z4CG;5H2"Etgcvg"Vkog"22<22<64
```

### Adjacency

You can verify that the corresponding adjacency has been created:

```
Tqwvgt%"ujqy"cf1cegpe{"vwppgn"2
""Rtqvqeqn"Kpvgthceg""Cfftguu
""KR""Vwppgn2""42;038704220473*6+
""VCI""Vwppgn2""42;038704220473*5+
```

### Profile Health

You can use **show l3vpn encapsulation profile-name** command to get information on the basic state of the application. The output of this command provides you details on the references to the underlying tunnel.

```
Tqwvgt%"ujqy"n5xrp"gpecruwncvkqp"kr"vwppgn"gpecr
Rtqhknq<"vwppgn"gpecr
vtcpurqtv"krx6"uqwteg"Cwvq<"Nqqrdecem2
rtqvqeqn"itg
""Vwppgn"Vwppgn2"Etgcvgf"]QM_
""Vwppgn"Nkpguvcvg"]QM_
""Vwppgn"Vtcpurqtv"Uqwteg"*Cwvq+"Nqqrdecem2"]QM_
```

## Configuration Sequence for mVPN with L3VPN over mGRE

This example shows the configuration sequence for mVPN with L3VPN over mGRE:

```
xth"fghkpkvkqp"Ewuvqogt"C
"tf"322<332
"tqwvg/vctigv"gzrqtvt"322<3222
"tqwvg/vctigv"korqtv"322<3222
"#
"cfftguu/hcokn{"krx6
"gzkv/cfftguu/hcokn{
"#
"cfftguu/hcokn{"krx8
"gzkv/cfftguu/hcokn{
#
#
krx8"wpkecuv/tqwvkpi
#
n5xrp"gpecruwncvkqp"kr"ucorngartqhknqapcog"
"vtcpurqtv"krx6"uqwteg"nqqrdecem"2"
#
#
"kpvgthceg"Nqqrdecem2
""kr"cfftguu"42;038704220474"477047704770446
""kr"tqwvgt"kuku"
#
kpvgthceg"ikicdkvgvjgtpgv"313
"xth"hqtyctfkpi"Ewuvqogt"C
"kr"cfftguu"42;038704220475"477047704770446
"krx8"cfftguu"5HHG<3223<<186"gw/86
#
tqwvgt"dir"322
"dir"nqi/pgkijdt/ejcpigu
"pgkijdt"42;038704220476"tgoqvg/cu"322
"pgkijdt"42;038704220476"wrfcvg/uqwteg"Nqqrdecem2
"#
"cfftguu/hcokn{"krx6
""pq"u{pejtpk|cvkqp
""tgfkuvtkdwvg"eqppgevgf
""pgkijdt"42;038704220476"cevkxcvg
```

```

"pq"cwvg/uwooct{
"gzkv/cfftguu/hcokn{
"#
"cfftguu/hcokn{"xrp6
"pgkijdt"42;038704220476"cevkxcvg
"pgkijdt"42;038704220476"ugpf/eqoowpkv{"dqvj
"pgkijdt"42;038704220476"tqwg/ocr"UGNGEVaWRFCVGaHQTa5XRP"kp
"gzkv/cfftguu/hcokn{
"#
"cfftguu/hcokn{"xrp8
"pgkijdt"42;038704220476"cevkxcvg
"pgkijdt"42;038704220476"ugpf/eqoowpkv{"dqvj
"pgkijdt"42;038704220476"tqwg/ocr"UGNGEVaWRFCVGaHQTa5XRP"kp
"gzkv/cfftguu/hcokn{
"#
"cfftguu/hcokn{"krx6"xth"Ewuvqogt"C
"pq"u{pejtqpk|cvkqp
"tgfkuvtkdwvg"eqppgevgf
"gzkv/cfftguu/hcokn{
"#
"cfftguu/hcokn{"krx8"xth"Ewuvqogt"C
"tgfkuvtkdwvg"eqppgevgf
"pq"u{pejtqpk|cvkqp
"gzkv/cfftguu/hcokn{
#
#
tqwg/ocr"UGNGEVaWRFCVGaHQTa5XRP"rgtokv"32
ugv"kr"pgzv/jqr"gpecruwncvg"ucorngartqhkgapcog"
ugv"krx8"pgzv/jqr"gpecruwncvg"ucorngartqhkgapcog"

```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





# IPv6 Multicast Support

- [Prerequisites for IPv6 Multicast, page 51-1](#)
- [Restrictions for IPv6 Multicast, page 51-1](#)
- [Information About IPv6 Multicast Support, page 51-2](#)
- [How to Configure IPv6 Multicast Support, page 51-4](#)
- [Verifying the IPv6 Multicast Layer 3 Configuration, page 51-4](#)



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for IPv6 Multicast

None.

## Restrictions for IPv6 Multicast

- The PFC and DFCs provide hardware support for the following:
  - Completely switched IPv6 multicast flows
  - IPv6 PIM-Sparse Mode (PIM-SM) (S,G) and (\*,G) forwarding
  - Multicast RPF check for IPv6 PIM-SM (S,G) traffic using the NetFlow table
  - Rate limiting of IPv6 PIM-SM (S,G) traffic that fails the multicast RPF check
  - Static IPv6 multicast routes
  - SSM Mapping for IPv6 (PIM-SSM)
  - IPv6 multicast forwarding information base (MFIB) using the NetFlow table
  - IPv6 distributed MFIB (dMFIB) using the NetFlow table
  - Link-local and link-global IPv6 multicast scopes

- Egress multicast replication with the **ipv6 mfib hardware-switching** command
- Ingress interface statistics for multicast routes (egress interface statistics not available)
- RPR and RPR+ redundancy mode (see [Chapter 9, “Route Processor Redundancy \(RPR\)”](#))
- Ingress and egress PFC QoS (see [Chapter 62, “PFC QoS Overview”](#))
- Input and output Cisco access-control lists (ACLs)
- The PFC and DFCs do not provide hardware support for the following:
  - Partially switched IPv6 multicast flows
  - Multicast RPF check for PIM-SM (\*,G) traffic
  - Multicast helper maps
  - Site-local multicast scopes
  - Manually configured IPv6 over IPv4 tunnels
  - IPv6 multicast 6to4 tunnels
  - IPv6 multicast automatic tunnels
  - IPv6 over GRE tunnels
  - IPv6-in-IPv6 PIM register tunnels
  - IPv6 multicast basic ISATAP tunnels
  - ISATAP tunnels with embedded 6to4 tunnels

## Information About IPv6 Multicast Support

- [Hardware-Supported IPv6 Layer 3 Multicast Features, page 51-2](#)
- [Partially Hardware-Supported IPv6 Layer 3 Multicast Features, page 51-3](#)
- [Software-Supported IPv6 Layer 3 Multicast Features, page 51-3](#)
- [Unsupported IPv6 Layer 3 Multicast Features, page 51-3](#)

## Hardware-Supported IPv6 Layer 3 Multicast Features

- Control plane policing (CoPP)
- Egress forced replication mode
- Egress replication local
- Egress replication mode
- HW assisted SPT switchover
- Input ACL logging
- Input and output ACL filtering
- IPv6 Multicast over P2P IPv4 GRE/IP-in-IP tunnel (6over4)
- Load-Balancing of multicast packets on port-channels
- Multicast Layer 3 forwarding on routed ports
- Multicast Layer 3 forwarding on subinterfaces

- Multicast Layer 3 forwarding on SVI
- Multicast load-splitting across parallel links
- Netflow accounting
- Non-RPF protection
- PIM register decapsulation over IPv6
- PIM register encapsulation over IPv6
- PIM-SM (S,G) and (\*,G) forwarding
- PIM-SSM
- QoS ingress mode marking
- QoS ingress mode policing
- Rate limiters
- Scope checking
- Statistics

## Partially Hardware-Supported IPv6 Layer 3 Multicast Features

- Egress replication mode and QoS marking

## Software-Supported IPv6 Layer 3 Multicast Features

- SSM mapping
- MET sharing
- MLDv1/v2

## Unsupported IPv6 Layer 3 Multicast Features

- BIDIR PIM over P2P GRE tunnel
- Destination IP NAT multicast
- IPv4 multicast over P2P IPv6 GRE tunnel (4over6)
- IPv6 multicast over multipoint IPv4 GRE tunnel (6over4 mGRE)
- IPv6 multicast over multipoint IPv6 GRE tunnel
- IPv6 multicast over P2P IPv6 GRE tunnel
- IPv6 multicast over P2P IPv6 GRE tunnel with tunnel endpoints in VRF
- IPv6 multicast over P2P IPv6 VRF GRE tunnel
- MTR multicast: TOS based lookup
- Multicast VPN for IPv6 extranet support
- Multicast VPN for IPv6 intranet support
- Multicast VRF-lite

- MVPN over P2P IPv6 GRE tunnel
- PIM-BIDIR
- PIM-DM (S,G) forwarding
- Source IP NAT multicast
- Egress replication mode and QoS policing
- QoS ingress and egress: shaping support
- MIB support
- Multicast boundary
- Multicast helper map
- Output ACL logging
- PGM router assist
- PGM router assist in VRF
- QoS Marking for multicast bridged frames undergoing routing

## How to Configure IPv6 Multicast Support

The PFC and DFCs provide hardware support for IPv6 multicast traffic. Use these publications to configure IPv6 multicast in Cisco IOS Release 15.4SY:

- The *Cisco IOS IPv6 Configuration Library*, “Implementing IPv6 Multicast”:  
<http://www.cisco.com/en/US/docs/ios-xml/ios/ipv6/configuration/15-2mt/ip6-15-2mt-book.html>
- The *Cisco IOS IPv6 Command Reference*:  
[http://www.cisco.com/en/US/docs/ios/ipv6/command/reference/ipv6\\_book.html](http://www.cisco.com/en/US/docs/ios/ipv6/command/reference/ipv6_book.html)

## Verifying the IPv6 Multicast Layer 3 Configuration

- [Verifying MFIB Clients, page 51-5](#)
- [Displaying the Switching Capability, page 51-5](#)
- [Verifying the \(S,G\) Forwarding Capability, page 51-5](#)
- [Verifying the \(\\*,G\) Forwarding Capability, page 51-5](#)
- [Verifying the Subnet Entry Support Status, page 51-5](#)
- [Verifying the Current Replication Mode, page 51-5](#)
- [Displaying the Replication Mode Auto-Detection Status, page 51-5](#)
- [Displaying the Replication Mode Capabilities, page 51-6](#)
- [Displaying Subnet Entries, page 51-6](#)
- [Displaying the IPv6 Multicast Summary, page 51-6](#)
- [Displaying the NetFlow Hardware Forwarding Count, page 51-7](#)
- [Displaying the FIB Hardware Bridging and Drop Counts, page 51-7](#)
- [Displaying the Shared and Well-Known Hardware Adjacency Counters, page 51-8](#)

## Verifying MFIB Clients

This example shows the complete output of the **show ipv6 mrib client** command:

```
Tqvwgt% "ujqy"krx8"otkd"enkqpv"
```

## Displaying the Switching Capability

This example displays the complete output of the **show platform software ipv6-multicast capability** command:

```
Tqvwgt% "ujqy"rncvhtqto"ughvyctg"krx8/ownvkecuv"ecrcdknk{ "
```

## Verifying the (S,G) Forwarding Capability

This example shows how to verify the (S,G) forwarding:

```
Tqvwgt% "ujqy"rncvhtqto"ughvyctg"krx8/ownvkecuv"ecrcdknk{ "~"kpenwfg"*U.I+"
*U.I+"hqtyctfkpi"hqt"KRx8"ku"uwrrqtvfg"wukpi"Pgvhnqy
```

## Verifying the (\*,G) Forwarding Capability

This example shows how to verify the (\*,G) forwarding:

```
Tqvwgt% "ujqy"rncvhtqto"ughvyctg"krx8/ownvkecuv"ecrcdknk{ "~"kpenwfg"*^,.I+"
*,.I+"dtkfikpi"hqt"KRx8"ku"uwrrqtvfg"wukpi"HKD
```

## Verifying the Subnet Entry Support Status

This example shows how to verify the subnet entry support status:

```
Tqvwgt% "ujqy"rncvhtqto"ughvyctg"krx8/ownvkecuv"ecrcdknk{ "~"kpenwfg"gpvtkgu"
Fktgevn{/eqppgevgf"gpvtkgu"hqt"KRx8"ku"uwrrqtvfg"wukpi"CEN/VECO0
```

## Verifying the Current Replication Mode

This example shows how to verify the current replication mode:

```
Tqvwgt% "ujqy"rncvhtqto"ughvyctg"krx8/ownvkecuv"ecrcdknk{ "~"kpenwfg"Ewttgqv"
Ewttgqv"U{uvgo"JY"Tgrnkecvkqp"Oqfg"<"Kpitguu
```



**Note**

Enter the **no ipv6 mrib hardware-switching replication-mode ingress** command to enable replication mode auto-detection.

## Displaying the Replication Mode Auto-Detection Status

This example shows how to display the replication mode auto-detection status:

```
Tqvwgt% "ujqy"rncvhtqto"ughvyctg"krx8/ownvkecuv"ecrcdknk{ "~"kpenwfg"fgvgevkqp"
Cwvq/fgvgevkqp"qh"Tgrnkecvkqp"Oqfg"<"QP
```

## Displaying the Replication Mode Capabilities

This example shows how to display the replication mode capabilities of the installed modules:

```
Tqwgvt%"ujqy"rncvhtqto"uqhvyctg"krx8/ownvkecuv"ecrcdknk{ "~"dgikp" `Unqv"
Unqv"Tgrnkecvkqp/Ecrcdknk{"Tgrnkecvkqp/Oqfg
""3"Kpitguu""""""Kpitguu"
""4"Gitguu""""""Kpitguu"
""8"Gitguu""""""Kpitguu"
"": "Kpitguu""""""Kpitguu"
```

## Displaying Subnet Entries

This example shows how to display subnet entries:

```
Tqwgvt%"ujqy"rncvhtqto"uqhvyctg"krx8/ownvkecuv"eqppgevgf"
KRx8"Ownvkecuv"Uwdpgv"gpvtkgu
Hnciu"<"J"/"Kpuvcnngf"kp"CEN/VECO
""""""Z"/"Pqv"kpucnngf"kp"CEN/VECO"fwg"vq
""""""ncdgn/hwnn"gzgrvkqp
Kpvgthceg<"Xncp42"] "J" _
""""""U<42<<3" I<HH22<<
Kpvgthceg<"Xncp32"] "J" _
""""""U<32<<3" I<HH22<<
```



**Note** In this example, there are subnet entries for VLAN 10 and VLAN 20.

## Displaying the IPv6 Multicast Summary

This example shows how to display the IPv6 multicast summary:

```
Tqwgvt%"ujqy"rncvhtqto"uqhvyctg"krx8/ownvkecuv"uwooct{ "
KRx8"Ownvkecuv"Pgvhnqy"UE"uwooct{ "qp"Unqv] 3_<
Ujqtvevw"V{rg""""""Ujqtvevw"eqwpv
////////////////-////////////////
*U."I+""""""322
*,."I+""""""2
KRx8"Ownvkecuv"HKD"UE"uwooct{ "qp"Unqv] 3_<
Ujqtvevw"V{rg""""""Ujqtvevw"eqwpv
////////////////-////////////////
*,."I134:+""""""32
*,."I10+""""""69

KRx8"Ownvkecuv"Pgvhnqy"UE"uwooct{ "qp"Unqv] 8_<
Ujqtvevw"V{rg""""""Ujqtvevw"eqwpv
////////////////-////////////////
*U."I+""""""322
*,."I+""""""2
KRx8"Ownvkecuv"HKD"UE"uwooct{ "qp"Unqv] 8_<
Ujqtvevw"V{rg""""""Ujqtvevw"eqwpv
////////////////-////////////////
*,."I134:+""""""32
*,."I10+""""""69
```









## IPv6 MLD Snooping

---

- [Prerequisites for MLD Snooping, page 52-1](#)
- [Restrictions for MLD Snooping, page 52-2](#)
- [Information About MLD Snooping, page 52-3](#)
- [Default MLD Snooping Configuration, page 52-9](#)
- [How to Configure MLD Snooping, page 52-9](#)
- [Verifying the MLD Snooping Configuration, page 52-14](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- To constrain IPv4 multicast traffic, see [Chapter 45, “IGMP Snooping for IPv4 Multicast Traffic.”](#)
- All PFC modes support Multicast Listener Discovery (MLD) version 1 (MLDv1) and MLD version 2 (MLDv2).



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for MLD Snooping

None.

# Restrictions for MLD Snooping

- [General MLD Snooping Restrictions, page 52-2](#)
- [MLD Snooping Querier Restrictions, page 52-2](#)

## General MLD Snooping Restrictions

- All PFC modes support MLD version 1 (MLDv1) and MLD version 2 (MLDv2).
- MLD is derived from Internet Group Management Protocol version 3 (IGMPv3). MLD protocol operations and state transitions, host and router behavior, query and report message processing, message forwarding rules, and timer operations are exactly same as IGMPv3. See draft-vida-ml-d-02.txt for detailed information on MLD protocol.
- MLD protocol messages are Internet Control Message Protocol version 6 (ICMPv6) messages.
- MLD message formats are almost identical to IGMPv3 messages.
- IPv6 multicast for Cisco IOS software uses MLD version 2. This version of MLD is fully backward-compatible with MLD version 1 (described in RFC 2710). Hosts that support only MLD version 1 interoperate with a router running MLD version 2. Mixed LANs with both MLD version 1 and MLD version 2 hosts are supported.
- MLD snooping supports private VLANs. Private VLANs do not impose any restrictions on MLD snooping.
- MLD snooping constrains traffic in MAC multicast groups 0100.5e00.0001 to 0100.5eff.ffff.
- MLD snooping does not constrain Layer 2 multicasts generated by routing protocols.

## MLD Snooping Querier Restrictions

- Configure an IPv6 address on the VLAN interface (see [Chapter 35, “Layer 3 Interfaces”](#)). When enabled, the MLD snooping querier uses the IPv6 address as the query source address.
- If there is no IPv6 address configured on the VLAN interface, the MLD snooping querier does not start. The MLD snooping querier disables itself if the IPv6 address is cleared. When enabled, the MLD snooping querier restarts if you configure an IPv6 address.
- When enabled, the MLD snooping querier does not start if it detects MLD traffic from an IPv6 multicast router.
- When enabled, the MLD snooping querier starts after 60 seconds with no MLD traffic detected from an IPv6 multicast router.
- When enabled, the MLD snooping querier disables itself if it detects MLD traffic from an IPv6 multicast router.
- QoS does not support MLD packets when MLD snooping is enabled.
- You can enable the MLD snooping querier on all the switches in the VLAN that support it. One switch is elected as the querier.

- To configure redundant MLD snooping queriers, complete the tasks in the “[Enabling the MLD Snooping Querier](#)” section on page 52-10 on more than one switch in the VLAN.

When multiple MLD snooping queriers are enabled in a VLAN, the querier with the lowest IP address in the VLAN is elected as the active MLD snooping querier.

An MLD snooping querier election occurs if the active MLD snooping querier goes down or if there is an IP address change on any of the queriers.



---

**Note** To avoid unnecessary active querier time outs, configure the **ipv6 mld snooping last-member-query-interval** command with the same value on all queriers in a VLAN.

---

## Information About MLD Snooping

- [MLD Snooping Overview, page 52-3](#)
- [MLD Messages, page 52-4](#)
- [Source-Based Filtering, page 52-4](#)
- [Explicit Host Tracking, page 52-4](#)
- [MLD Snooping Proxy Reporting, page 52-5](#)
- [Joining an IPv6 Multicast Group, page 52-5](#)
- [Leaving a Multicast Group, page 52-7](#)
- [Information about the MLD Snooping Querier, page 52-8](#)

## MLD Snooping Overview

MLD snooping allows the switch to examine MLD packets and make forwarding decisions based on their content.

You can configure the switch to use MLD snooping in subnets that receive MLD queries from either MLD or the MLD snooping querier. MLD snooping constrains IPv6 multicast traffic at Layer 2 by configuring Layer 2 LAN ports dynamically to forward IPv6 multicast traffic only to those ports that want to receive it.

MLD, which runs at Layer 3 on a multicast router, generates Layer 3 MLD queries in subnets where the multicast traffic needs to be routed. For information about MLD, see this publication:

<http://www.cisco.com/en/US/docs/ios-xml/ios/ipv6/configuration/15-2mt/ip6-multicast.html>

You can configure the MLD snooping querier on the switch to support MLD snooping in subnets that do not have any multicast router interfaces. For more information about the MLD snooping querier, see the “[Enabling the MLD Snooping Querier](#)” section on page 52-10.

MLD (on a multicast router) or, locally, the MLD snooping querier, sends out periodic general MLD queries that the switch forwards through all ports in the VLAN, and to which hosts respond. MLD snooping monitors the Layer 3 MLD traffic.



**Note**

---

If a multicast group has only sources and no receivers in a VLAN, MLD snooping constrains the multicast traffic to only the multicast router ports.

---

## MLD Messages

- Multicast listener queries
  - General query—Sent by a multicast router to learn which multicast addresses have listeners.
  - Multicast address specific query—Sent by a multicast router to learn if a particular multicast address has any listeners.
  - Multicast address and source specific query—Sent by a multicast router to learn if any of the sources from the specified list for the particular multicast address has any listeners.
- Multicast listener reports
  - Current state record (solicited)—Sent by a host in response to a query to specify the INCLUDE or EXCLUDE mode for every multicast group in which the host is interested.
  - Filter mode change record (unsolicited)—Sent by a host to change the INCLUDE or EXCLUDE mode of one or more multicast groups.
  - Source list change record (unsolicited)—Sent by a host to change information about multicast sources.

## Source-Based Filtering

MLD uses source-based filtering, which enables hosts and routers to specify which multicast sources should be allowed or blocked for a specific multicast group. Source-based filtering either allows or blocks traffic based on the following information in MLD messages:

- Source lists
- INCLUDE or EXCLUDE mode

Because the Layer 2 table is (MAC-group, VLAN) based, with MLD hosts it is preferable to have only a single multicast source per MAC-group.

**Note**

---

Source-based filtering is not supported in hardware. The states are maintained only in software and used for explicit host tracking and statistics collection.

---

## Explicit Host Tracking

MLD supports explicit tracking of membership information on any port. The explicit-tracking database is used for fast-leave processing, proxy reporting, and statistics collection. When explicit tracking is enabled on a VLAN, the MLD snooping software processes the MLD report it receives from a host and builds an explicit-tracking database that contains the following information:

- The port connected to the host
- The channels reported by the host
- The filter mode for each group reported by the host
- The list of sources for each group reported by the hosts
- The router filter mode of each group
- For each group, the list of hosts requesting the source

**Note**

- Disabling explicit host tracking disables fast-leave processing and proxy reporting.
- When explicit tracking is enabled and the switch is in report-suppression mode, the multicast router might not be able to track all the hosts accessed through a VLAN interface.

## MLD Snooping Proxy Reporting

Because MLD does not have report suppression, all the hosts send their complete multicast group membership information to the multicast router in response to queries. The switch snoops these responses, updates the database and forwards the reports to the multicast router. To prevent the multicast router from becoming overloaded with reports, MLD snooping does proxy reporting.

Proxy reporting forwards only the first report for a multicast group to the router and suppresses all other reports for the same multicast group.

Proxy reporting processes solicited and unsolicited reports. Proxy reporting is enabled and cannot be disabled.

**Note**

Disabling explicit host tracking disables fast-leave processing and proxy reporting.

## Joining an IPv6 Multicast Group


Hosts join IPv6 multicast groups either by sending an unsolicited MLD report or by sending an MLD report in response to a general query from an IPv6 multicast router (the switch forwards general queries from IPv6 multicast routers to all ports in a VLAN). The switch snoops these reports.

In response to a snooped MLD report, the switch creates an entry in its Layer 2 forwarding table for the VLAN on which the report was received. When other hosts that are interested in this multicast traffic send MLD reports, the switch snoops their reports and adds them to the existing Layer 2 forwarding table entry. The switch creates only one entry per VLAN in the Layer 2 forwarding table for each multicast group for which it snoops an MLD report.

MLD snooping suppresses all but one of the host reports per multicast group and forwards this one report to the IPv6 multicast router.

The switch forwards multicast traffic for the multicast group specified in the report to the interfaces where reports were received (see [Figure 52-1](#)).

Layer 2 multicast groups learned through MLD snooping are dynamic. However, you can statically configure Layer 2 multicast groups using the **mac address-table static** command. When you specify group membership for a multicast group address statically, the static setting supersedes any MLD snooping learning. Multicast group membership lists can consist of both static and MLD snooping-learned settings.

**Figure 52-1** Initial MLD Listener Report

Multicast router A sends an MLD general query to the switch, which forwards the query to ports 2 through 5 (all members of the same VLAN). Host 1 wants to join an IPv6 multicast group and multicasts an MLD report to the group with the equivalent MAC destination address of 0x0100.5E01.0203. When the switch snoops the MLD report multicast by Host 1, the switch uses the information in the MLD report to create a forwarding-table entry.

**Table 52-1** MLD Snooping Forwarding Table

| Destination MAC Address | Type of Packet | Ports |
|-------------------------|----------------|-------|
| 0100.5exx.xxxx          | MLD            | 0     |
| 0100.5e01.0203          | !MLD           | 1, 2  |

The switch hardware can distinguish MLD information packets from other packets for the multicast group. The first entry in the table indicates that only MLD packets should be sent to the CPU, which prevents the switch from becoming overloaded with multicast frames. The second entry indicates that frames addressed to the 0x0100.5E01.0203 multicast MAC address that are not MLD packets (!MLD) should be sent to the multicast router and to the host that has joined the group.

If another host (for example, Host 4) sends an unsolicited MLD report for the same group ([Figure 52-2](#)), the switch snoops that message and adds the port number of Host 4 to the forwarding table as shown in [Table 52-2](#). Because the forwarding table directs MLD messages only to the switch, the message is not flooded to other ports. Any known multicast traffic is forwarded to the group and not to the switch.

Figure 52-2 Second Host Joining a Multicast Group




Table 52-2 Updated MLD Snooping Forwarding Table

| Destination MAC Address | Type of Packet | Ports   |
|-------------------------|----------------|---------|
| 0100.5exx.xxxx          | MLD            | 0       |
| 0100.5e01.0203          | !MLD           | 1, 2, 5 |

## Leaving a Multicast Group

- [Normal Leave Processing, page 52-7](#)
- [Fast-Leave Processing, page 52-8](#)

### Normal Leave Processing

Interested hosts must continue to respond to the periodic MLD general queries. As long as at least one host in the VLAN responds to the periodic MLD general queries, the multicast router continues forwarding the multicast traffic to the VLAN. When hosts want to leave a multicast group, they can either ignore the periodic MLD general queries (called a “silent leave”), or they can send an MLD filter mode change record.

When MLD snooping receives a filter mode change record from a host that configures the EXCLUDE mode for a group, MLD snooping sends out a MAC-addressed general query to determine if any other hosts connected to that interface are interested in traffic for the specified multicast group.

If MLD snooping does not receive an MLD report in response to the general query, MLD snooping assumes that no other hosts connected to the interface are interested in receiving traffic for the specified multicast group, and MLD snooping removes the interface from its Layer 2 forwarding table entry for the specified multicast group.

If the filter mode change record was from the only remaining interface with hosts interested in the group, and MLD snooping does not receive an MLD report in response to the general query, MLD snooping removes the group entry and relays the MLD filter mode change record to the multicast router. If the multicast router receives no reports from a VLAN, the multicast router removes the group for the VLAN from its MLD cache.

The interval for which the switch waits before updating the table entry is called the “last member query interval.” To configure the interval, enter the **ipv6 mld snooping last-member-query-interval** *interval* command.

## Fast-Leave Processing

Fast-leave processing is enabled by default. To disable fast-leave processing, turn off explicit-host tracking.

Fast-leave processing is implemented by maintaining source-group based membership information in software while also allocating LTL indexes on a MAC GDA basis.

When fast-leave processing is enabled, hosts send BLOCK\_OLD\_SOURCES{src-list} messages for a specific group when they no longer want to receive traffic from that source. When the switch receives such a message from a host, it parses the list of sources for that host for the given group. If this source list is exactly the same as the source list received in the leave message, the switch removes the host from the LTL index and stops forwarding this multicast group traffic to this host.

If the source lists do not match, the switch does not remove the host from the LTL index until the host is no longer interested in receiving traffic from any source.



### Note

---

Disabling explicit host tracking disables fast-leave processing and proxy reporting.

---

## Information about the MLD Snooping Querier

Use the MLD snooping querier to support MLD snooping in a VLAN where PIM and MLD are not configured because the multicast traffic does not need to be routed.

In a network where IP multicast routing is configured, the IP multicast router acts as the MLD querier. If the IP-multicast traffic in a VLAN only needs to be Layer 2 switched, an IP-multicast router is not required, but without an IP-multicast router on the VLAN, you must configure another switch as the MLD querier so that it can send queries.

When enabled, the MLD snooping querier sends out periodic MLD queries that trigger MLD report messages from the switch that wants to receive IP multicast traffic. MLD snooping listens to these MLD reports to establish appropriate forwarding.

You can enable the MLD snooping querier on all the switches in the VLAN, but for each VLAN that is connected to switches that use MLD to report interest in IP multicast traffic, you must configure at least one switch as the MLD snooping querier.

You can configure a switch to generate MLD queries on a VLAN regardless of whether or not IP multicast routing is enabled.



## Default MLD Snooping Configuration

- MLD snooping querier: disabled
- MLD snooping: enabled
- Multicast routers: none configured
- MLD report suppression: enabled
- MLD snooping router learning method: learned automatically through PIM or MLD packets
- Fast-Leave Processing: enabled
- MLD Explicit Host Tracking: enabled

## How to Configure MLD Snooping

- [Enabling the MLD Snooping Querier, page 52-10](#)
- [Configuring the MLD Snooping Query Interval, page 52-10](#)
- [Enabling MLD Snooping, page 52-11](#)
- [Configuring a Static Connection to a Multicast Receiver, page 52-12](#)
- [Configuring a Multicast Router Port Statically, page 52-12](#)
- [Enabling Fast-Leave Processing, page 52-12](#)
- [Enabling SSM Safe Reporting, page 52-13](#)
- [Configuring Explicit Host Tracking, page 52-13](#)
- [Configuring Report Suppression, page 52-14](#)



### Note

- To use MLD snooping, configure a Layer 3 interface in the subnet for IPv6 multicast routing or enable the MLD snooping querier in the subnet (see the [“Enabling the MLD Snooping Querier” section on page 52-10](#)).
- Except for the global enable command, all MLD snooping commands are supported only on VLAN interfaces.

## Enabling the MLD Snooping Querier

Use the MLD snooping querier to support MLD snooping in a VLAN where PIM and MLD are not configured because the multicast traffic does not need to be routed. To enable the MLD snooping querier in a VLAN, perform this task:

|        | Command                                                                             | Purpose                                 |
|--------|-------------------------------------------------------------------------------------|-----------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"xncp"eqphkiwtcvkqp</b>"vlan_ID"</code>                     | Selects a VLAN.                         |
| Step 2 | <code>Tqwvgt*eqphki/xncp/eqphki+%<b>"krx8"cfftgauu</b>"rtghkzlrtghkzangpivj"</code> | Configures the IPv6 address and subnet. |
| Step 3 | <code>Tqwvgt*eqphki/xncp/eqphki+%<b>"krx8"onf"upqqrkpi"swgtkgt</b>"</code>          | Enables the MLD snooping querier.       |
| Step 4 | <code>Tqwvgt*eqphki/xncp/eqphki+%<b>"gpf"</b></code>                                | Exits configuration mode.               |

This example shows how to enable the MLD snooping querier on VLAN 200 and verify the configuration:

```
Tqwvgt%"xncp"eqphkiwtcvkqp"422"
Tqwvgt*eqphki/xncp/eqphki+%"krx8"cfftgauu"4223<2FD:<2<3<<186"gwK/86"
Tqwvgt*eqphki/xncp/eqphki+%"krx8"onf"upqqrkpi"swgtkgt"
Tqwvgt*eqphki/xncp/eqphki+%"gpf"
Tqwvgt%"ujqy"krx8"onf"kpvgthceg"xncp"422"~"kpenwfg"swgtkgt"
ONF"upqqrkpi"hcuv/ngcxg"ku"gpcdngf"cpf"swgtkgt"ku"gpcdngf"
```

## Configuring the MLD Snooping Query Interval

You can configure the interval for which the switch waits after sending a group-specific query to determine if hosts are still interested in a specific multicast group.



### Note

When both MLD snooping fast-leave processing and the MLD snooping query interval are configured, fast-leave processing takes precedence.

To configure the interval for the MLD snooping queries sent by the switch, perform this task:

|        | Command                                                                                               | Purpose                                                                                                                         |
|--------|-------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"xncp"eqphkiwtcvkqp</b>"vlan_ID"</code>                                       | Selects a VLAN.                                                                                                                 |
| Step 2 | <code>Tqwvgt*eqphki/xncp/eqphki+%<b>"krx8"onf"upqqrkpi"</b>ncuv/ogodgt/swgt{/kpvgtxcn"kpvgtxcn</code> | Configures the interval for the IGMP queries sent by the switch. Default is 1 second. Valid range is 1000 to 9990 milliseconds. |

This example shows how to configure the MLD snooping query interval:

```
Tqwvgt*eqphki/xncp/eqphki+%"krx8"onf"upqqrkpi"ncuv/ogodgt/swgt{/kpvgtxcn"3222"
Tqwvgt*eqphki/xncp/eqphki+%"gzkv"
Tqwvgt%"ujqy"krx8"onf"kpvgthceg"xncp"422"~"kpenwfg"ncuv"
ONF"upqqrkpi"ncuv"ogodgt"swgt{"tgurqpug"kpvgtxcn"ku"3222"ou"
```

## Enabling MLD Snooping

- [Enabling MLD Snooping Globally, page 52-11](#)
- [Enabling MLD Snooping in a VLAN, page 52-11](#)

### Enabling MLD Snooping Globally

To enable MLD snooping globally, perform this task:

|        | Command                                           | Purpose                   |
|--------|---------------------------------------------------|---------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "krx8"onf "upqqrkpi"</code> | Enables MLD snooping.     |
| Step 2 | <code>Tqwgvt*eqphki+% "gpf"</code>                | Exits configuration mode. |

This example shows how to enable MLD snooping globally and verify the configuration:

```
Tqwgvt*eqphki+% "krx8"onf "upqqrkpi"
Tqwgvt*eqphki+% "gpf"
Tqwgvt% "ujqy"krx8"onf "kpvgtthceg"xncp"422"~ "kpenwfg"inqdcnn{ "
 ONF"upqqrkpi"ku"inqdcnn{ "gpcdnfgf
Tqwgvt%
```

### Enabling MLD Snooping in a VLAN

To enable MLD snooping in a VLAN, perform this task:

|        | Command                                                       | Purpose                   |
|--------|---------------------------------------------------------------|---------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "xncp"eqphkiwtcvkqp"vlan_ID"</code>     | Selects a VLAN.           |
| Step 2 | <code>Tqwgvt*eqphki/xncp/eqphki+% "krx8"onf "upqqrkpi"</code> | Enables MLD snooping.     |
| Step 3 | <code>Tqwgvt*eqphki/xncp/eqphki+% "gpf"</code>                | Exits configuration mode. |

This example shows how to enable MLD snooping on VLAN 25 and verify the configuration:

```
Tqwgvt% "xncp"eqphkiwtcvkqp"47"
Tqwgvt*eqphki/xncp/eqphki+% "krx8"onf "upqqrkpi"
Tqwgvt*eqphki/xncp/eqphki+% "gpf"
Tqwgvt% "ujqy"krx8"onf "kpvgtthceg"xncp"47"~ "kpenwfg"upqqrkpi"
 ONF"upqqrkpi"ku"inqdcnn{ "gpcdnfgf
 ONF"upqqrkpi"ku"gpcdnfgf"qp"vjku"kpvgthceg"
 ONF"upqqrkpi"hcuv/ngcxg"ku"gpcdnfgf"cpf"swgtkgt"ku"gpcdnfgf
 ONF"upqqrkpi"gzrnkekv/vtcmkpi"ku"gpcdnfgf
 ONF"upqqrkpi"ncuv"ogodgt"swgt{ "tgurqpug"kpvgtxcn"ku"3222"ou
 ONF"upqqrkpi"tgrqtv/uwrtrtguakqp"ku"fkucdnfgf
Tqwgvt%
```

## Configuring a Static Connection to a Multicast Receiver

To configure a static connection to a multicast receiver, perform this task:

|        | Command                                                                                                                              | Purpose                                                 |
|--------|--------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "oce"cfftgau/vcdng"uvcvke"oceacfft"<br/>xncp"xncpakf"kpvgthceg" type slot/port"<br/>l fkucdng/upqqrkpi_</code> | Configures a static connection to a multicast receiver. |
| Step 2 | <code>Tqwgvt*eqphki+% "gpf"</code>                                                                                                   | Exits configuration mode.                               |

When you configure a static connection, enter the **disable-snooping** keyword to prevent multicast traffic addressed to the statically configured multicast MAC address from also being sent to other ports in the same VLAN.

This example shows how to configure a static connection to a multicast receiver:

```
Tqwgvt*eqphki+% "oce"cfftgau/vcdng"uvcvke"227205g:f08622"xncp"34"kpvgthceg"ikicdkvgvjgtpgv"719"
```

## Configuring a Multicast Router Port Statically

To configure a static connection to a multicast router, perform this task:

|        | Command                                                                                            | Purpose                                               |
|--------|----------------------------------------------------------------------------------------------------|-------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "xncp"eqphkiwtcvkqp"vlan_ID"</code>                                          | Selects a VLAN.                                       |
| Step 2 | <code>Tqwgvt*eqphki/xncp/eqphki+% "krx8"onf"upqqrkpi"<br/>otqwgvt"kpvgthceg" type slot/port</code> | Configures a static connection to a multicast router. |
| Step 3 | <code>Tqwgvt*eqphki/xncp/eqphki+% "gpf"</code>                                                     | Exits configuration mode.                             |

The interface to the router must be in the VLAN where you are entering the command, the interface must be administratively up, and the line protocol must be up.

This example shows how to configure a static connection to a multicast router:

```
Tqwgvt*eqphki/xncp/eqphki+% "krx8"onf"upqqrkpi"otqwgvt"kpvgthceg"ikicdkvgvjgtpgv"718"
Tqwgvt*eqphki/xncp/eqphki+%
```

## Enabling Fast-Leave Processing

To enable fast-leave processing in a VLAN, perform this task:

|        | Command                                                                     | Purpose                                    |
|--------|-----------------------------------------------------------------------------|--------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "xncp"eqphkiwtcvkqp"vlan_ID"</code>                   | Selects a VLAN.                            |
| Step 2 | <code>Tqwgvt*eqphki/xncp/eqphki+% "krx8"onf"upqqrkpi"<br/>hcuv/ngcxg</code> | Enables fast-leave processing in the VLAN. |

This example shows how to enable fast-leave processing on the VLAN 200 interface and verify the configuration:

```
Tqvwgt%"xncp"eqphkiwtcvkqp"422"
Tqvwgt*eqphki/xncp/eqphki+%"krx8"onf"upqqrkpi"hcuv/ngcxg"
Eqphkiwtkpi"hcuv/ngcxg"qp"xncp"422
Tqvwgt*eqphki/xncp/eqphki+%"gpf"
Tqvwgt%"ujqy"krx8"onf"kpvgthceg"xncp"422"~"kpenwfg"hcuv/ngcxg"
ONF"upqqrkpi"hcuv/ngcxg"ku"gpdcngf"cpf"swgtkgt"ku"gpdcngf
Tqvwgt%
```

## Enabling SSM Safe Reporting

To enable source-specific multicast (SSM) safe reporting, perform this task:

|        | Command                                                                   | Purpose                     |
|--------|---------------------------------------------------------------------------|-----------------------------|
| Step 1 | Tqvwgt*eqphki+%" <b>xncp"eqphkiwtcvkqp"vlan_ID"</b>                       | Selects a VLAN.             |
| Step 2 | Tqvwgt*eqphki/xncp/eqphki+%" <b>krx8"onf"upqqrkpi"uuo/uchg/tgrqtvkpi"</b> | Enables SSM safe reporting. |

This example shows how to SSM safe reporting:

```
Tqvwgt*eqphki+%"xncp"eqphkiwtcvkqp"32"
Tqvwgt*eqphki/xncp/eqphki+%"krx8"onf"upqqrkpi"uuo/uchg/tgrqtvkpi"
```

## Configuring Explicit Host Tracking



### Note

Disabling explicit host tracking disables fast-leave processing and proxy reporting.

To enable explicit host tracking on a VLAN, perform this task:

|        | Command                                                                   | Purpose                         |
|--------|---------------------------------------------------------------------------|---------------------------------|
| Step 1 | Tqvwgt*eqphki+%" <b>xncp"eqphkiwtcvkqp"vlan_ID"</b>                       | Selects a VLAN.                 |
| Step 2 | Tqvwgt*eqphki/xncp/eqphki+%" <b>krx8"onf"upqqrkpi"gzrnkekv/vtciemkpi"</b> | Enables explicit host tracking. |

This example shows how to enable explicit host tracking:

```
Tqvwgt*eqphki+%"xncp"eqphkiwtcvkqp"47"
Tqvwgt*eqphki/xncp/eqphki+%"krx8"onf"upqqrkpi"gzrnkekv/vtciemkpi"
Tqvwgt*eqphki/xncp/eqphki+%"gpf"
Tqvwgt%"ujqy"krx8"onf"upqqrkpi"gzrnkekv/vtciemkpi"xncp"47"
UqwteglItqr"Kpvgthceg"~"Tgrqtvgt"~"Hknvgtaoqfg
////////////////////////////////////
320303031448040404"Xn47<314"380490405"KPENWFG"
320404041448040404"Xn47<314"380490405"KPENWFG"
```



```
Tqvwgt% "ujqy"oce"cfftgau/vcdng"ownvkecu"xnpc"3
xnpc""oce"cfftgau""""v{rg""""squ""""""""""rqtvu
////////////////////////////////-////////////////////////////////
""3""232207g2402425""uvcvke""""/"Ik313.Ik413.Ik516:.Tqvwgt
""3""232207g2202349""uvcvke""""/"Ik313.Ik413.Ik516:.Tqvwgt
""3""232207g220234: ""uvcvke""""/"Ik313.Ik413.Ik516:.Tqvwgt
""3""232207g2202223""uvcvke""""/"Ik313.Ik413.Ik516:.Tqvwgt.Uykvej
Tqvwgt%
```

Tqvwgt%"ujqy"oce"cfftguu/vcdng"ownvkecu"3"eqwv  
Ownvkecu"OCE"Gpytkgu"hgt"xncp"3<" " " "6  
Tqvwgt%

To display MLD snooping information for a VLAN interface, perform this task:

| Command                                                                                                          | Purpose                                                |
|------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------|
| <code>Tqwgvt%<b>"ujqy"krx8"onf"upqqrkpi"}}</b>ogodgtujkr<b>"xncp"vlan_IDi;~"}otqwgvt"]xncp"vlan_ID_i"</b></code> | Displays MLD snooping information on a VLAN interface. |

```
IqwwvgT%"ujqy"krx8"onf"upqqrkpi"ogodgtujkr"xncp":::
Upqqrkpi"Ogodgtujkr"Uwooct{"hqt"Xncp":::
////////////////////////////////////
Vqvcn"pwodgt"qh"ejcppgnu<"5
Vqvcn"pwodgt"qh"jquvu""<"3
"
UqwteglItqwr"Kpvgthceg"Tgrgtvgt"Wrvkog"Ncuu/LqkplNcuu/Ngcxg
////////////////////////////////////
"
<<1HH29<<4"Vg614"HG:2<<422<HH<HGH4<346E"22<22<33"22<22<23"1
%%
/
<<1HH29<<5"Vg614"HG:2<<422<HH<HGH4<346E"22<22<33"2<22<23"1
%%
/
<<1HH29<<6"Vg614"HG:2<<422<HH<HGH4<346E"22<22<33"22<22<23"1
```

[illegible]

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





## NetFlow Hardware Support

---

- [Prerequisites for NetFlow Hardware Support, page 53-1](#)
- [Restrictions for NetFlow Hardware Support, page 53-1](#)
- [Information About NetFlow Hardware Support, page 53-2](#)
- [Default Settings for NetFlow Hardware Support, page 53-2](#)
- [How to Configure NetFlow Hardware Support, page 53-2](#)
- [Verifying the NetFlow Table Aging Configuration, page 53-4](#)



### Note

In Cisco IOS Release 15.4SY, the Flexible NetFlow feature provides statistics collection and data export. See these publications:

<http://www.cisco.com/en/US/docs/ios-xml/ios/fnetflow/command/fnf-cr-book.html>



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for NetFlow Hardware Support

None.

## Restrictions for NetFlow Hardware Support

- Cisco IOS Release 15.4SY and later releases do not support NetFlow version 7 or NetFlow version 8. Flexible NetFlow has limited support for NetFlow version 5.
- No statistics are available for flows that are forwarded when the NetFlow table is full.

- If the NetFlow table utilization exceeds the recommended utilization levels, there is an increased probability that there will be insufficient room to store statistics. [Table 53-1](#) lists the recommended maximum utilization levels.

**Table 53-1** *NetFlow Table Utilization*

| PFC Mode | Effective NetFlow Table Utilization |                | Total NetFlow Table Capacity          |                |
|----------|-------------------------------------|----------------|---------------------------------------|----------------|
|          | Ingress entries                     | Egress entries | Ingress entries                       | Egress entries |
| PFC4XL   | 506,184                             | 506,184        | 524,288 (512k)                        | 524,288 (512k) |
| PFC4     | 515,032 ingress+egress entries      |                | 524,288 (512k) ingress+egress entries |                |

- If a flow is destined to an address in the PBR range or is sourced from an address in the PBR range, the input and output interface will be the default route (if configured) or be null.

## Information About NetFlow Hardware Support

The NetFlow table on the PFC and any DFCs captures data for flows forwarded in hardware. These are some of the features that use the NetFlow table:

- Flexible NetFlow
- Network address translation (NAT)
- QoS microflow policing
- Reflexive ACLS
- WCCP

To limit NetFlow CPU usage, you can configure aging timers to identify stale flows that can be deleted from the table. NetFlow deletes the stale entries to clear table space for new entries.

## Default Settings for NetFlow Hardware Support

- Inactive Flow Aging: enabled (300 seconds)
- Fast Aging: disabled
- Active Flow Aging: enabled (1920 seconds)

## How to Configure NetFlow Hardware Support

- [Configuring Inactive Flow Aging, page 53-3](#)
- [Configuring Fast Aging, page 53-3](#)
- [Configuring Active Flow Aging, page 53-4](#)

**Note**

- NetFlow table aging keeps the NetFlow table size below the recommended utilization. If the number of NetFlow table entries exceeds the recommended utilization (see the [“Restrictions for NetFlow Hardware Support” section on page 53-1](#)), only adjacency statistics might be available for some flows.
- Network events (for example, routing changes or a link state change) can also purge NetFlow table entries.

## Configuring Inactive Flow Aging

To configure inactive flow aging, perform this task:

| Command                                                                          | Purpose                                                                                                                                                                                                                                                             |
|----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwgvt*eqphki+%<b>hnqy</b>"rncvhtqto"ecejg"vkogqvw"kpcevkg"ugeqpfu"</code> | Configures the aging time for NetFlow table entries that have been inactive longer than the configured time value. <ul style="list-style-type: none"> <li>• Default: enabled; value: 300 seconds.</li> <li>• Range for the <i>seconds</i> value: 32–512.</li> </ul> |

This example displays how to configure the aging time for NetFlow table entries that have been inactive longer than the configured time value:

```
Tqwgvt%eqphkiwtg"vgtokpcn"
Gpvgvt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpgo""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+%hnqy"rncvhtqto"ecejg"vkogqvw"kpcevkg"522"
```

## Configuring Fast Aging

To configure fast aging, perform this task:

| Command                                                                                                        | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwgvt*eqphki+%<b>hnqy</b>"rncvhtqto"ecejg"vkogqvw"hcuv"<br/>llvkog ugeqpfu_]vjtgujqnf rcemgvu__"</code> | Configures an aging time for NetFlow table entries that have been inactive longer than the configured time value and that have forwarded fewer packets than the configured threshold value. <ul style="list-style-type: none"> <li>• Default: disabled.</li> <li>• Default if <b>time</b> <i>seconds</i> not entered: 32 seconds; range for the <i>seconds</i> value: 60–4092.</li> <li>• Default if <b>threshold</b> <i>packets</i> not entered: 100 packets range for the <i>packets</i> value: 1–4000.</li> </ul> |

**Note**

If you enable fast aging, initially set the value to 128 seconds. If the size of the NetFlow table continues to grow over the recommended utilization, decrease the setting until the table size stays below the recommended utilization. If the table continues to grow over the recommended utilization, decrease the inactive NetFlow table aging time.

This example displays how to configure the NetFlow table aging time:

```
Tqwgvt% "eqphkiwtg"vgtokpcn"
Gpvgt "eqphkiwtcvkqp"eqoocpfu. "qpg"rgt "nkp0" "Gpf"ykvj "EPVN1\0
Tqwgvt*eqphki+% "hnqy"rncvhtqto"ecejg"vkogqvw"hcuv"vkog"54"vjtgujqnf"322"
```

## Configuring Active Flow Aging

To configure active flow aging, perform this task:

| Command                                                       | Purpose                                                                                                                                                                                                                                                                                           |
|---------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Tqwgvt*eqphki+% "hnqy"rncvhtqto"ecejg"vkogqvw"cevkxg"ugeqpfu" | Configures the aging time for NetFlow table entries regardless of packet activity, which can prevent counter wraparound and inaccurate statistics. <ul style="list-style-type: none"> <li>Default: enabled; value: 1920 seconds.</li> <li>Range for the <i>seconds</i> value: 60–4092.</li> </ul> |

This example displays how to configure active flow aging:

```
Tqwgvt% "eqphkiwtg"vgtokpcn"
Gpvgt "eqphkiwtcvkqp"eqoocpfu. "qpg"rgt "nkp0" "Gpf"ykvj "EPVN1\0
Tqwgvt*eqphki+% "hnqy"rncvhtqto"ecejg"vkogqvw"cevkxg"3;42"
```

## Verifying the NetFlow Table Aging Configuration

To display the NetFlow table aging configuration, perform this task:

| Command                             | Purpose                                         |
|-------------------------------------|-------------------------------------------------|
| Tqwgvt% "ujqy"rncvhtqto"hnqy"cikpi" | Displays the NetFlow table aging configuration. |

This example shows how to display the NetFlow table aging-time configuration:

```
Tqwgvt% "ujqy"rncvhtqto"hnqy"cikpi"
Cikpi"uejgog""Gpcdnf""Vkogqvw""Rcemgv"vjtgujqnf
////////// -////////// -////////// -//////////
" "HcuV" " "Pg" " "54" " "322
" "KpcevKxg" " " [gu" " "522" " "P1C
" " "CevKxg" " " [gu" " "3;42" " "P1C
```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





## System Event Archive (SEA)

- [Information About the System Event Archive, page 54-1](#)
- [How to Display the SEA Logging System, page 54-2](#)
- [How to Copy the SEA To Another Device, page 54-3](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Information About the System Event Archive

The primary method of discovering the cause of system failure is system messages. When system messages do not provide the information needed to determine the cause of a failure, you can enable debug traces and attempt to recreate the failure. However, there are several situations in which neither of the above methods provides an optimum solution:

- Reviewing a large number of system messages can be an inefficient method of determining the cause of a failure.
- Debug trace is usually not configured by default.
- You cannot recreate the failure while using debug trace.
- Using debug trace is not an option if the switch on which the failure has occurred is part of your critical network.

The SEA enables each of the CPUs on a switch to report events to the management processor using an out-of-band interface. Each event is logged in nonvolatile memory with a time stamp. You can retrieve the event log by accessing the bootflash on the device, or you can copy the log to another location such as a removable storage device.

The SEA maintains two files in the bootdisk, using up to 32 MB. These files contain the most recent messages recorded to the log:

- `sea_log.dat`—Applications store the most recent system events in this file.
- `sea_console.dat`—The most recent console messages are stored in this file.

These files are for system use and should not be removed.

## How to Display the SEA Logging System

To display the SEA logging system, perform this task:

| Command                                                 | Purpose                                                                                                                                                                                              |
|---------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwwgt% "ujqy"nqiikpi"u{uvgo}"fkum"~"uk g_</code> | Displays the contents of the SEA.<br><br>(Optional) Use the keyword <b>disk</b> to display the location where the SEA is stored. Use the keyword <b>size</b> to display the current size of the SEA. |
| <code>Tqwwgt% "engct"nqiikpi"u{uvgo</code>              | Removes the event records stored in the SEA.                                                                                                                                                         |

The following example shows how to display the SEA:

```
Tqwwgt% "ujqy"nqiikpi"u{uvgo
UGS<"001FF1 [["JJ<00<UU"OQF1UWD<"UGX. "EQOR. " " " "OGUUCIG
??"
"
3<"23146129"37<5:<62" " "81/3"<"OCL. "IQNF. "u{pfkciU{peRkppceng"hckngf"kp"unqv"8
"
4<"23146129"37<5:<62" " "81/3"<"OCL. "IQNF. "swgt{J{rgtkqpU{pejgf}8_<"J{rgtkqp"qvw"qh"u{pe"kp"uyaoqfg"3
"
5<"23146129"37<5:<62" " "81/3"<"OCL. "IQNF. "swgt{J{rgtkqpU{pejgf}8_<"J{rgtkqp"qvw"qh"u{pe"kp"uyaoqfg"3
"
6<"23146129"37<5:<62" " "81/3"<"OCL. "IQNF. "swgt{J{rgtkqpU{pejgf}8_<"J{rgtkqp"qvw"qh"u{pe"kp"uyaoqfg"3
"
7<"23146129"37<5:<62" " "81/3"<"OCL. "IQNF. "swgt{J{rgtkqpU{pejgf}8_<"J{rgtkqp"qvw"qh"u{pe"kp"uyaoqfg"3
"
8<"23146129"37<5:<62" " "81/3"<"OCL. "IQNF. "swgt{J{rgtkqpU{pejgf}8_<"J{rgtkqp"qvw"qh"u{pe"kp"uyaoqfg"3
"
9<"23146129"37<5:<5; " " "81/3"<"OCL. "IQNF. "swgt{J{rgtkqpU{pejgf}8_<"J{rgtkqp"qvw"qh"u{pe"kp"uyaoqfg"3
```

The following example shows how to display the SEA logging system disk:

```
Tqwwgt% "ujqy"nqiikpi"u{uvgo"fkum
UGC"nqi"fkum<"dqgvfkum<
```

The following example shows how to display the current size of the SEA:

```
Tqwwgt% "ujqy"nqiikpi"u{uvgo"uk|g
UGC"nqi"uk|g<"55776654"d{vgu
```



The following example shows how to clear the SEA:

```
Tqwvgt%engct"nqiikpi"u{uvgo
Engct"nqiikpi"u{uvgo"qrgtcvkqp"yknn"vcmg"c"yjkng0
Fq"{qw"ycpv"vq"eqpvkpwgA"]pq_<"{gu
Tqwvgt%
```

# How to Copy the SEA To Another Device

To copy the SEA to another device, such as a removeable memory device, perform this task:

| Command                                                   | Purpose                                                                             |
|-----------------------------------------------------------|-------------------------------------------------------------------------------------|
| Tqwvgt% <b>eqr</b> {"nqiikpi"u{uvgo" <i>hkngau</i> {uvgo" | Copies the contents of the SEA to the specified destination file system or process. |

The valid values for *file\_system* are:

- **bootflash:**
- **disk0:**
- **disk1:**
- **ftp:**
- **http:**
- **https:**
- **rcp:**
- **slavebootflash:**
- **slavedisk0:**
- **slavedisk1:**
- **slavebootdisk:**
- **slavebootflash:**
- **bootdisk:**
- **bootflash:**
- **tftp:**

The following example shows how to copy the SEA to the disk0 file system:

```
Tqwvgt%eqr{"nqiikpi"u{uvgo"fkum2<
Fguvkcpcvkqp"hkngpcog"]ugcanqi0fcv_A"
Eqr{"kp"
rtqitguu000EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE
EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE
EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE
EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE
EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE
EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE
55776654"d{vgu"eqrkpf"kp"3340762"ugeu"*4;:378"d{vguluge+
```

The following example shows how to copy the SEA using the remote file copy function (rcp):

```
Tqwvgt%"eqr{"nqiikpi"u{uvgo"ter<
Cfftguu"qt"pcog"qh"tgoqvg"jquv"]_A"3;4020403
Fguvkpcvkqp"wugtpcog"]Tqwvgt_A"wugtpcog3
Fguvkpcvkqp"hknqpcog"]ugcanqi0fcv_A"1cwvq1vhvrdqqv/wugt1wugtpcog31ugcanqi0fcv
#####
#####
#####
#####
#####
#####
55776654"d{vgu"eqrkgf"kp"6:0394"ugeu"*8;8777"d{vguluge+
```



#### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## Backplane Traffic Monitoring

---

- [Prerequisites for Backplane Traffic Monitoring, page 55-1](#)
- [Restrictions for Backplane Traffic Monitoring, page 55-2](#)
- [Information About Traffic Monitoring, page 55-2](#)
- [Default Settings for Backplane Traffic Monitoring, page 55-2](#)
- [How to Configure Backplane Traffic Monitoring, page 55-3](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for Backplane Traffic Monitoring

None.

## Restrictions for Backplane Traffic Monitoring

The syslog message buffer is limited in size. To reduce false alarms and the number of syslog messages, use the following guidelines:

- Traffic can occur in bursts. If a small number of bursts occur in a monitoring interval, it does not represent a capacity overload issue for the system; the hardware buffers are able to absorb the effects and not cause packet drops. For an example, if you set a monitoring interval to 10 seconds and the threshold to 80 percent, there are a total of 10 traffic utilization readings. Assume only 2 of the readings reached 90 percent and the other 8 readings are 20 percent. If the peak threshold of 90 percent is used to compare with the threshold, an unwanted warning syslog message is generated. It is better to use the average 34 percent of the 10 readings to compare with the threshold and not generate warning messages in this case. If the peak value comparison is really needed, you can set the interval to 1 second. Setting the interval to 1 second compares the reading directly with the threshold.
- The number of syslog messages that generate syslog messages are from below the threshold and above the threshold.

## Information About Traffic Monitoring

Backplane Traffic Monitoring can monitor the backplane and fabric-channel traffic utilization at a configured interval and threshold.

Traffic monitoring allows the switch to monitor the backplane and fabric channel traffic utilization at a configured interval and threshold. Syslog messages are generated when the traffic utilization is above or below the configured threshold. The following examples show several types of syslog messages:

- 00:08:03: %TRAFFIC\_UTIL-SP-4-MONITOR\_BACKPLANE\_REACH\_THR: Backplane traffic utilization is 26%, reached threshold(20%) within 10 second interval
- 00:08:13: %TRAFFIC\_UTIL-SP-4-MONITOR\_BACKPLANE\_BELOW\_THR: Backplane traffic utilization is 18%, below threshold(20%) within 10 second interval
- 00:08:44: %TRAFFIC\_UTIL-SP-4-MONITOR\_FABRIC\_IG\_REACH\_THR: Module 1, Channel 0 ingress traffic utilization is 5%, reached threshold(3%) within 30 second interval
- 00:08:44: %TRAFFIC\_UTIL-SP-4-MONITOR\_FABRIC\_EG\_REACH\_THR: Module 1, Channel 0 egress traffic utilization is 5%, reached threshold(3%) within 30 second interval
- 00:09:14: %TRAFFIC\_UTIL-SP-4-MONITOR\_FABRIC\_IG\_BELOW\_THR: Module 1, Channel 0 ingress traffic utilization is 1%, below threshold(3%) within 30 second interval
- 00:09:14: %TRAFFIC\_UTIL-SP-4-MONITOR\_FABRIC\_EG\_BELOW\_THR: Module 1, Channel 0 egress traffic utilization is 1%, below threshold(3%) within 30 second interval

## Default Settings for Backplane Traffic Monitoring

- The default threshold is 80 percent.
- Traffic monitor is off by default.

# How to Configure Backplane Traffic Monitoring

To configure the Backplane Traffic Monitoring feature, perform one or more of the following tasks:

| Command                                                                                                                                                                                  | Purpose                                                                                                                         |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwvgt*eqphki+% "oqpkvgt"vtchhke/wvkn"dcemrncpg"kpvgtxcn"kpvgtxcn"vjtgujqnf"percentage</code>                                                                                      | Configures the backplane utilization traffic monitoring.                                                                        |
| <code>Tqwvgt*eqphki+% "oqpkvgt"vtchhke/wvkn"hcdtke"oqfwng" }mod-num"~"cnn;" }ejcppgn" }2~3~dqvj;" }fktgevkqp" }gitguu"~"kpitguu"~"dqvj;" ]kpvgtxcn"kpvgtxcn"vjtgujqnf rgtegpvcig_</code> | Configures the fabric channel utilization traffic monitoring.                                                                   |
| <code>Tqwvgt*eqphki+% "oqpkvgt"vtchhke/wvkn"hcdtke"nqiikpi"kpvgtxcn"ugeqpf"</code>                                                                                                       | Configures the fabric channel utilization traffic monitor SYSLOG interval when the traffic utilization is in the crossed state. |
| <code>Tqwvgt*eqphki+% "oqpkvgt"vtchhke/wvkn"dcemrncpg"nqiikpi"kpvgtxcn"ugeqpf"</code>                                                                                                    | Configures the traffic monitor backplane SYSLOG interval when the traffic utilization is in the crossed state.                  |
| <code>Tqwvgt%"ujqy"ecvnc{uv8222"vtchhke/ogvgt</code>                                                                                                                                     | Displays the percentage of the backplane (shared bus) utilization and traffic monitor status information.                       |

When configuring a range of interfaces, you can enter the *mod-num* as a list or a range. Separate each entry with a comma and each range with a hyphen (-). For example, 1,3,5-9,12.

The following example shows how to enable backplane traffic utilization monitoring:

```
Tqwvgt*eqphki+% "oqpkvgt"vtchhke/wvkn"dcemrncpg"nqiikpi"kpvgtxcn"72"vjtgujqnf"322
```

The following example shows how to disable backplane traffic utilization monitoring:

```
Tqwvgt*eqphki+% "pq"oqpkvgt"vtchhke/wvkn"dcemrncpg
```

The following example shows how to specify the fabric channel traffic utilization monitor interval and threshold for a fabric channel on a specific module:

```
Tqwvgt*eqphki+% "oqpkvgt"vtchhke/wvkn"hcdtke"oqfwng": "ejcppgn"dqvj" fktgevkqp"dqvj"kpvgtxcn"72"vjtgujqnf"82
```

The following example shows how to specify the fabric channel traffic utilization monitor threshold for a specific fabric channel and for egress traffic only:

```
Tqwvgt*eqphki+% "oqpkvgt"vtchhke/wvkn"hcdtke"oqfwng"8"ejcppgn"2"fktgevkqp"gitguu"kpvgtxcn"322"vjtgujqnf";2
```



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





## Local SPAN, RSPAN, and ERSPAN

---

- Prerequisites for Local SPAN, RSPAN, and ERSPAN, page 56-1
- Restrictions for Local SPAN, RSPAN, and ERSPAN, page 56-2
- Information About Local SPAN, RSPAN, and ERSPAN, page 56-7
- Default Settings for Local SPAN, RSPAN, and ERSPAN, page 56-12
- How to Configure Local SPAN, RSPAN, and ERSPAN, page 56-12
- Verifying the SPAN Configuration, page 56-31
- Configuration Examples for SPAN, page 56-31



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for Local SPAN, RSPAN, and ERSPAN

None.

# Restrictions for Local SPAN, RSPAN, and ERSPAN

- [Feature Incompatibilities, page 56-2](#)
- [Local SPAN, RSPAN, and ERSPAN Session Limits, page 56-3](#)
- [Local SPAN, RSPAN, and ERSPAN Interface Limits, page 56-3](#)
- [General Restrictions for Local SPAN, RSPAN, and ERSPAN, page 56-3](#)
- [Restrictions for VSPAN, page 56-5](#)
- [Restrictions for RSPAN, page 56-5](#)
- [Restrictions for ERSPAN, page 56-6](#)
- [Restrictions for Distributed Egress SPAN Mode, page 56-7](#)

## Feature Incompatibilities

- [Egress SPAN](#) is not supported in egress multicast mode. (CSCsa95965)
- Unknown unicast flood blocking (UUFB) ports cannot be RSPAN or local SPAN egress-only destinations. (CSCsj27695)
- A port-channel interface (an EtherChannel) can be a SPAN source, but you cannot configure active member ports of an EtherChannel as SPAN source ports. Inactive member ports of an EtherChannel can be configured as SPAN sources but they are put into the suspended state and carry no traffic.
- These features are incompatible with SPAN destinations:
  - Private VLANs
  - IEEE 802.1X port-based authentication
  - Port security
  - Spanning Tree Protocol (STP) and related features (PortFast, PortFast BPDU filtering, BPDU Guard, UplinkFast, BackboneFast, EtherChannel Guard, Root Guard, Loop Guard)
  - VLAN trunk protocol (VTP)
  - Dynamic trunking protocol (DTP)
  - IEEE 802.1Q tunneling
- The **dot1ad uni** command (see [Chapter 41, “Ethernet Virtual Connections \(EVCs\)”](#)) imposes these SPAN restrictions:
  - The **dot1ad uni** command does not restrict [egress SPAN](#) configuration.
  - The **dot1ad uni** command does not restrict RSPAN [ingress SPAN](#) source port configuration, but source VLAN filtering does not get applied to traffic from RSPAN ingress SPAN source ports that are configured with the **dot1ad uni** command.
  - Ports that are configured with the **dot1ad uni** command cannot be used as local SPAN or ERSPAN ingress SPAN source ports.



**Note**

- SPAN destinations can participate in IEEE 802.3Z flow control.
- IP multicast switching using egress packet replication is not compatible with SPAN. In some cases, egress replication can result in multicast packets not being sent to the SPAN destination port. If you are using SPAN and your switching modules are capable of egress replication, enter the **platform ip multicast replication-mode ingress** command to force ingress replication.

## Local SPAN, RSPAN, and ERSPAN Session Limits

|                | Local and Source Sessions                                         |                        | Destination Sessions |        |
|----------------|-------------------------------------------------------------------|------------------------|----------------------|--------|
|                | Local SPAN, RSPAN Source, ERSPAN Source Ingress or Egress or Both | Local SPAN Egress-Only | RSPAN                | ERSPAN |
| Total Sessions |                                                                   |                        |                      |        |
| 80             | 2                                                                 | 14                     | 64                   | 23     |

## Local SPAN, RSPAN, and ERSPAN Interface Limits

|                                              | In Each Local SPAN Session | In Each RSPAN Source Session | In Each ERSPAN Source Session | In Each RSPAN Destination Session | In Each ERSPAN Destination Session |
|----------------------------------------------|----------------------------|------------------------------|-------------------------------|-----------------------------------|------------------------------------|
| Egress or “both” sources                     | 128                        | 128                          | 128                           | —                                 | —                                  |
| Ingress sources                              | 128                        | 128                          | 128                           | —                                 | —                                  |
| RSPAN and ERSPAN destination session sources | —                          | —                            | —                             | 1 RSPAN VLAN                      | 1 IP address                       |
| Destinations per session                     | 64                         | 1 RSPAN VLAN                 | 1 IP address                  | 64                                | 64                                 |

## General Restrictions for Local SPAN, RSPAN, and ERSPAN

- A SPAN destination that is copying traffic from a single egress SPAN source port sends only egress traffic to the network analyzer. If you configure more than one egress SPAN source port, the traffic that is sent to the network analyzer also includes these types of ingress traffic that were received from the egress SPAN source ports:
  - Any unicast traffic that is flooded on the VLAN
  - Broadcast and multicast traffic

This situation occurs because an egress SPAN source port receives these types of traffic from the VLAN but then recognizes itself as the source of the traffic and drops it instead of sending it back to the source from which it was received. Before the traffic is dropped, SPAN copies the traffic and sends it to the SPAN destination. (CSCds22021)

- Entering additional **monitor session** commands does not clear previously configured SPAN parameters. You must enter the **no monitor session** command to clear configured SPAN parameters.
- Connect a network analyzer to the SPAN destinations.
- Within a SPAN session, all of the SPAN destinations receive all of the traffic from all of the SPAN sources, except when source-VLAN filtering is configured on the SPAN source.
- You can configure destination trunk VLAN filtering to select which traffic is transmitted from the SPAN destination.
- You can configure both Layer 2 LAN ports (LAN ports configured with the **switchport** command) and Layer 3 LAN ports (LAN ports not configured with the **switchport** command) as sources or destinations.
- You cannot mix individual source ports and source VLANs within a single session.
- If you specify multiple ingress source ports, the ports can belong to different VLANs.
- Within a session, you cannot configure both VLANs as SPAN sources and do source VLAN filtering. You can configure VLANs as SPAN sources or you can do source VLAN filtering of traffic from source ports and EtherChannels, but not both in the same session.
- You cannot configure source VLAN filtering for internal VLANs.
- When enabled, local SPAN, RSPAN, and ERSPAN use any previously entered configuration.
- When you specify sources and do not specify a traffic direction (ingress, egress, or both), “both” is used by default.
- SPAN copies Layer 2 Ethernet frames, but SPAN does not copy source trunk port 802.1Q tags. You can configure destinations as trunks to send locally tagged traffic to the traffic analyzer.



**Note** A destination configured as a trunk tags traffic from a Layer 3 LAN source with the [internal VLAN](#) used by the Layer 3 LAN source.

- Local SPAN sessions, RSPAN source sessions, and ERSPAN source sessions do not copy locally sourced RSPAN VLAN traffic from source trunk ports that carry RSPAN VLANs.
- Local SPAN sessions, RSPAN source sessions, and ERSPAN source sessions do not copy locally sourced ERSPAN GRE-encapsulated traffic from source ports.
- A port or EtherChannel can be a SPAN destination for only one SPAN session. SPAN sessions cannot share destinations.
- SPAN destinations cannot be SPAN sources.
- Destinations never participate in any spanning tree instance. Local SPAN includes BPDUs in the monitored traffic, so any BPDUs seen on the destination are from the source. RSPAN does not support BPDU monitoring.
- All packets forwarded through the switch for transmission from a port that is configured as an egress SPAN source are copied to the SPAN destination, including packets that do not exit the switch through the egress port because STP has put the egress port into the blocking state, or on an egress trunk port because STP has put the VLAN into the blocking state on the trunk port.
- Local-Tx span with fex host port as span destination will not work due to hardware limitation.

## Restrictions for VSPAN

**Note**

Local SPAN, RSPAN, and ERSPAN all support [VSPAN](#).

- VSPAN sessions do not support source VLAN filtering.
- For VSPAN sessions with both ingress and egress configured, two packets are forwarded from the destination to the analyzer if the packets get switched on the same VLAN (one as ingress traffic from the ingress port and one as egress traffic from the egress port).
- VSPAN only monitors traffic that leaves or enters Layer 2 ports in the VLAN.
  - If you configure a VLAN as an ingress source and traffic gets routed into the monitored VLAN, the routed traffic is not monitored because it never appears as ingress traffic entering a Layer 2 port in the VLAN.
  - If you configure a VLAN as an egress source and traffic gets routed out of the monitored VLAN, the routed traffic is not monitored because it never appears as egress traffic leaving a Layer 2 port in the VLAN.

## Restrictions for RSPAN

- All participating switches must be connected by Layer 2 trunks.
- Any network device that supports RSPAN VLANs can be an RSPAN intermediate device.
- Networks impose no limit on the number of RSPAN VLANs that the networks carry.
- Intermediate network devices might impose limits on the number of RSPAN VLANs that they can support.
- You must configure the RSPAN VLANs in all source, intermediate, and destination network devices. If enabled, the VLAN Trunking Protocol (VTP) can propagate configuration of VLANs numbered 1 through 1024 as RSPAN VLANs. You must manually configure VLANs numbered higher than 1024 as RSPAN VLANs on all source, intermediate, and destination network devices.
- If you enable VTP and VTP pruning, RSPAN traffic is pruned in the trunks to prevent the unwanted flooding of RSPAN traffic across the network.
- RSPAN VLANs can be used only for RSPAN traffic.
- Do not configure a VLAN used to carry management traffic as an RSPAN VLAN.
- Do not assign access ports to RSPAN VLANs. RSPAN puts access ports in an RSPAN VLAN into the suspended state.
- Do not configure any ports in an RSPAN VLAN except trunk ports selected to carry RSPAN traffic.
- MAC address learning is disabled in the RSPAN VLAN.
- You can use output access control lists (ACLs) on the RSPAN VLAN in the RSPAN source switch to filter the traffic sent to an RSPAN destination.
- RSPAN does not support BPDU monitoring.
- Do not configure RSPAN VLANs as sources in VSPAN sessions.
- You can configure any VLAN as an RSPAN VLAN as long as all participating network devices support configuration of RSPAN VLANs and you use the same RSPAN VLAN for each RSPAN session in all participating network devices.

## Restrictions for ERSPAN

- For ERSPAN packets, the “protocol type” field value in the GRE header is 0x88BE.
- The payload of a Layer 3 ERSPAN packet is a copied Layer 2 Ethernet frame, excluding any 802.1Q tags.
- ERSPAN adds a 50-byte header to each copied Layer 2 Ethernet frame and replaces the 4-byte cyclic redundancy check (CRC) trailer.
- ERSPAN supports jumbo frames that contain Layer 3 packets of up to 9,202 bytes. If the length of the copied Layer 2 Ethernet frame is greater than 9,170 (9,152-byte Layer 3 packet), ERSPAN truncates the copied Layer 2 Ethernet frame to create a 9,202-byte ERSPAN Layer 3 packet.



### Note

The Layer 3 IP header in truncated packets retains the nontruncated Layer 3 packet size. The length consistency check between the Layer 2 frame and the Layer 3 packet on ERSPAN destinations that are switches drops truncated ERSPAN packets unless you configure the **no platform verify ip length consistent** global configuration command on the ERSPAN destination switch.

- Regardless of any configured MTU size, ERSPAN creates Layer 3 packets that can be as long as 9,202 bytes. ERSPAN traffic might be dropped by any interface in the network that enforces an MTU size smaller than 9,202 bytes.
- With the default MTU size (1,500 bytes), if the length of the copied Layer 2 Ethernet frame is greater than 1,468 bytes (1,450-byte Layer 3 packet), the ERSPAN traffic is dropped by any interface in the network that enforces the 1,500-byte MTU size.



### Note

The **mtu** interface command and the **system jumbomtu** command (see the [“Configuring Jumbo Frame Support” section on page 10-6](#)) set the maximum Layer 3 packet size (default is 1,500 bytes, maximum is 9,216 bytes).

- All participating switches must be connected at Layer 3 and the network path must support the size of the ERSPAN traffic.
- ERSPAN does not support packet fragmentation. The “do not fragment” bit is set in the IP header of ERSPAN packets. ERSPAN destination sessions cannot reassemble fragmented ERSPAN packets.
- ERSPAN traffic is subject to the traffic load conditions of the network. You can set the ERSPAN packet IP precedence or DSCP value to prioritize ERSPAN traffic for QoS.
- The only supported destination for ERSPAN traffic is an ERSPAN destination session.
- All ERSPAN source sessions on a switch must use the same origin IP address, configured with the **origin ip address** command (see the [“Configuring ERSPAN Source Sessions” section on page 56-26](#)).
- All ERSPAN destination sessions on a switch must use the same IP address on the same destination interface. You enter the destination interface IP address with the **ip address** command (see the [“Configuring ERSPAN Destination Sessions” section on page 56-28](#)).
- The ERSPAN source session’s destination IP address, which must be configured on an interface on the destination switch, is the source of traffic that an ERSPAN destination session sends to the destinations. You configure the same address in both the source and destination sessions with the **ip address** command.

- The ERSPAN ID differentiates the ERSPAN traffic arriving at the same destination IP address from various different ERSPAN source sessions.

## Restrictions for Distributed Egress SPAN Mode

Some switching modules have ASICs that do not support distributed egress SPAN mode for ERSPAN sources.

Enter the **show monitor session egress replication-mode | include Distributed.\*Distributed.\*Centralized** command to display the slot number of any switching modules that do not support distributed egress SPAN mode for ERSPAN sources.

Enter the **show ASIC-version slot *slot\_number*** command to display the versions of the ASICs on the switching module in the slot where distributed egress SPAN mode is not supported for ERSPAN sources.

Hyperion ASIC revision levels 5.0 and higher and all versions of the Metropolis ASIC support distributed egress SPAN mode for ERSPAN sources. Switching modules with Hyperion ASIC revision levels lower than 5.0 do not support distributed egress SPAN mode for ERSPAN sources.

## Information About Local SPAN, RSPAN, and ERSPAN

- [Local SPAN, RSPAN, and ERSPAN Overview, page 56-7](#)
- [Local SPAN, RSPAN, and ERSPAN Sources, page 56-11](#)
- [Local SPAN, RSPAN, and ERSPAN Destinations, page 56-12](#)

## Local SPAN, RSPAN, and ERSPAN Overview

- [SPAN Operation, page 56-7](#)
- [Local SPAN Overview, page 56-8](#)
- [RSPAN Overview, page 56-8](#)
- [ERSPAN Overview, page 56-9](#)
- [Traffic Monitored at SPAN Sources, page 56-10](#)

### SPAN Operation

SPAN copies traffic from one or more ports, one or more EtherChannels, or one or more VLANs, and sends the copied traffic to one or more destinations for analysis by a network analyzer such as a SwitchProbe device or other Remote Monitoring (RMON) probe. Traffic can also be sent to the processor for packet capture by the Mini Protocol Analyzer, as described in [Chapter 60, “Mini Protocol Analyzer.”](#)

SPAN does not affect the switching of traffic on sources. You must dedicate the destination for SPAN use. The SPAN-generated copies of traffic compete with user traffic for switch resources.

## Local SPAN Overview


A local SPAN session is an association of source ports and source VLANs with one or more destinations. You configure a local SPAN session on a single switch. Local SPAN does not have separate source and destination sessions.

Local SPAN sessions do not copy locally sourced RSPAN VLAN traffic from source trunk ports that carry RSPAN VLANs. Local SPAN sessions do not copy locally sourced RSPAN GRE-encapsulated traffic from source ports.

Each local SPAN session can have either ports or VLANs as sources, but not both.

Local SPAN copies traffic from one or more source ports in any VLAN or from one or more VLANs to a destination for analysis (see [Figure 56-1](#)). For example, as shown in [Figure 56-1](#), all traffic on Ethernet port 5 (the source port) is copied to Ethernet port 10. A network analyzer on Ethernet port 10 receives all traffic from Ethernet port 5 without being physically attached to Ethernet port 5.

**Figure 56-1** Example SPAN Configuration



S6884

## RSPAN Overview

RSPAN supports source ports, source VLANs, and destinations on different switches, which provides remote monitoring of multiple switches across your network (see [Figure 56-2](#)). RSPAN uses a Layer 2 VLAN to carry SPAN traffic between switches.

RSPAN consists of an RSPAN source session, an RSPAN VLAN, and an RSPAN destination session. You separately configure RSPAN source sessions and destination sessions on different switches. To configure an RSPAN source session on one switch, you associate a set of source ports or VLANs with an RSPAN VLAN. To configure an RSPAN destination session on another switch, you associate the destinations with the RSPAN VLAN.


The traffic for each RSPAN session is carried as Layer 2 nonroutable traffic over a user-specified RSPAN VLAN that is dedicated for that RSPAN session in all participating switches. All participating switches must be trunk-connected at Layer 2.

RSPAN source sessions do not copy locally sourced RSPAN VLAN traffic from source trunk ports that carry RSPAN VLANs. RSPAN source sessions do not copy locally sourced RSPAN GRE-encapsulated traffic from source ports.

Each RSPAN source session can have either ports or VLANs as sources, but not both.

The RSPAN source session copies traffic from the source ports or source VLANs and switches the traffic over the RSPAN VLAN to the RSPAN destination session. The RSPAN destination session switches the traffic to the destinations.

**Figure 56-2 RSPAN Configuration**



## ERSPAN Overview

ERSPAN supports source ports, source VLANs, and destinations on different switches, which provides remote monitoring of multiple switches across your network (see [Figure 56-3](#)). ERSPAN uses a GRE tunnel to carry traffic between switches.

ERSPAN consists of an ERSPAN source session, routable ERSPAN GRE-encapsulated traffic, and an ERSPAN destination session. You separately configure ERSPAN source sessions and destination sessions on different switches.

To configure an ERSPAN source session on one switch, you associate a set of source ports or VLANs with a destination IP address, ERSPAN ID number, and optionally with a VRF name. To configure an ERSPAN destination session on another switch, you associate the destinations with the source IP address, ERSPAN ID number, and optionally with a VRF name.

ERSPAN source sessions do not copy locally sourced RSPAN VLAN traffic from source trunk ports that carry RSPAN VLANs. ERSPAN source sessions do not copy locally sourced ERSPAN GRE-encapsulated traffic from source ports.

Each ERSPAN source session can have either ports or VLANs as sources, but not both.

The ERSPAN source session copies traffic from the source ports or source VLANs and forwards the traffic using routable GRE-encapsulated packets to the ERSPAN destination session. The ERSPAN destination session switches the traffic to the destinations.

*Figure 56-3 ERSPAN Configuration*

## Traffic Monitored at SPAN Sources

- [Monitored Traffic Direction, page 56-10](#)
- [Monitored Traffic Type, page 56-11](#)
- [Duplicate Traffic, page 56-11](#)

### Monitored Traffic Direction

You can configure local SPAN sessions, RSPAN source sessions, and ERSPAN source sessions to monitor the following traffic:

- Ingress traffic
  - Called ingress SPAN.
  - Copies traffic received by the sources (ingress traffic).
  - Ingress traffic is sent to the supervisor engine SPAN ASIC to be copied.
- Egress traffic
  - Called egress SPAN.
  - Copies traffic transmitted from the sources (egress traffic).
  - Distributed egress SPAN mode—On some fabric-enabled switching modules, egress traffic can be copied locally by the switching module SPAN ASIC and then sent to the SPAN destinations. See the [“Restrictions for Distributed Egress SPAN Mode” section on page 56-7](#) for information about switching modules that support distributed egress SPAN mode.
  - Centralized egress SPAN mode—On all other switching modules, egress traffic is sent to the supervisor engine SPAN ASIC to be copied and is then sent to the SPAN destinations.
- Both
  - Copies both the received traffic and the transmitted traffic (ingress and egress traffic).
  - Both ingress traffic and egress traffic is sent to the supervisor engine SPAN ASIC to be copied.



## Monitored Traffic Type

By default, local SPAN and ERSPAN monitor all traffic, including multicast and bridge protocol data unit (BPDU) frames. RSPAN does not support BPDU monitoring.

## Duplicate Traffic

In some configurations, SPAN sends multiple copies of the same source traffic to the destination. For example, in a configuration with a bidirectional SPAN session (both ingress and egress) for two SPAN sources, called s1 and s2, to a SPAN destination, called d1, if a packet enters the switch through s1 and is sent for egress from the switch to s2, ingress SPAN at s1 sends a copy of the packet to SPAN destination d1 and egress SPAN at s2 sends a copy of the packet to SPAN destination d1. If the packet was Layer 2 switched from s1 to s2, both SPAN packets would be the same. If the packet was Layer 3 switched from s1 to s2, the Layer 3 rewrite would alter the source and destination Layer 2 addresses, in which case the SPAN packets would be different.

## Local SPAN, RSPAN, and ERSPAN Sources

- [Source Ports and EtherChannels, page 56-11](#)
- [Source VLANs, page 56-11](#)

## Source Ports and EtherChannels

A source port or EtherChannel is a port or EtherChannel monitored for traffic analysis. You can configure both Layer 2 and Layer 3 ports and EtherChannels as SPAN sources. SPAN can monitor one or more source ports or EtherChannels in a single SPAN session. You can configure ports or EtherChannels in any VLAN as SPAN sources. Trunk ports or EtherChannels can be configured as sources and mixed with nontrunk sources.



### Note

SPAN does not copy the encapsulation from trunk sources. You can configure SPAN destinations as trunks to tag the monitored traffic before it is transmitted for analysis.

## Source VLANs

A source VLAN is a VLAN monitored for traffic analysis. VLAN-based SPAN (VSPAN) uses a VLAN as the SPAN source. All the ports and EtherChannels in the source VLANs become sources of SPAN traffic.



### Note

Layer 3 VLAN interfaces on source VLANs are not sources of SPAN traffic. Traffic that enters a VLAN through a Layer 3 VLAN interface is monitored when it is transmitted from the switch through an egress port or EtherChannel that is in the source VLAN.

## Local SPAN, RSPAN, and ERSPAN Destinations

A SPAN destination is a Layer 2 port, Layer 3 port, or an EtherChannel, to which local SPAN, RSPAN, or ERSPAN sends traffic for analysis. When you configure a port or EtherChannel as a SPAN destination, it is dedicated for use only by the SPAN feature.

Destination EtherChannels do not support the Port Aggregation Control Protocol (PAgP) or Link Aggregation Control Protocol (LACP) EtherChannel protocols; only the on mode is supported, with all EtherChannel protocol support disabled.

There is no requirement that the member links of a destination EtherChannel be connected to a device that supports EtherChannels. For example, you can connect the member links to separate network analyzers. See [Chapter 23, “EtherChannels,”](#) for more information about EtherChannel.

Destinations, by default, cannot receive any traffic. You can configure Layer 2 destinations to receive traffic from any attached devices.

Destinations, by default, do not transmit anything except SPAN traffic. Layer 2 destinations that you have configured to receive traffic can be configured to learn the Layer 2 address of any devices attached to the destination and transmit traffic that is addressed to the devices.

You can configure trunks as destinations, which allows trunk destinations to transmit encapsulated traffic. You can use allowed VLAN lists to configure destination trunk VLAN filtering.

## Default Settings for Local SPAN, RSPAN, and ERSPAN

- Local SPAN: disabled
- RSPAN: disabled
- ERSPAN: disabled
- Default operating mode for egress SPAN sessions: centralized

## How to Configure Local SPAN, RSPAN, and ERSPAN

- [Configuring a Destination as an Unconditional Trunk \(Optional\), page 56-13](#)
- [Configuring Destination Trunk VLAN Filtering \(Optional\), page 56-13](#)
- [Configuring Destination Port Permit Lists \(Optional\), page 56-15](#)
- [Configuring the Egress SPAN Mode \(Optional\), page 56-15](#)
- [Configuring Local SPAN, page 56-16](#)
- [Configuring RSPAN, page 56-20](#)
- [Configuring ERSPAN, page 56-26](#)
- [Configuring Source VLAN Filtering in Global Configuration Mode, page 56-30](#)

## Configuring a Destination as an Unconditional Trunk (Optional)

To configure the destination as a trunk so that the monitored traffic is tagged as it leaves the destination, perform this task:

|        | Command                                                                          | Purpose                                                                                                                          |
|--------|----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphkiwtg"vgtokpcn</code>                                           | Enters global configuration mode.                                                                                                |
| Step 2 | <code>Tqvwgt*eqphki+% "kpvgthceg" }type slot/port"~" rqtv/ejcppgn"pwodgt;</code> | Selects the interface to configure.                                                                                              |
| Step 3 | <code>Tqvwgt*eqphki/kh+% "uykvej rqtv"</code>                                    | Configures the interface for Layer 2 switching (required only if the interface is not already configured for Layer 2 switching). |
| Step 4 | <code>Tqvwgt*eqphki/kh+% "uykvej rqtv"vtpm"gpccruwncvkqp" fqv3s"</code>          | Configures the encapsulation, which configures the interface as an 802.1Q trunk.                                                 |
| Step 5 | <code>Tqvwgt*eqphki/kh+% "uykvej rqtv"oqfg"vtpm"</code>                          | Configures the interface to trunk unconditionally.                                                                               |

This example shows how to configure a port as an unconditional IEEE 802.1Q trunk:

```
Tqvwgt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv"7134 "
Tqvwgt*eqphki/kh+% "uykvej rqtv"
Tqvwgt*eqphki/kh+% "uykvej rqtv"vtpm"gpccruwncvkqp" fqv3s"
Tqvwgt*eqphki/kh+% "uykvej rqtv"oqfg"vtpm"
```

## Configuring Destination Trunk VLAN Filtering (Optional)



### Note

- In addition to filtering VLANs on a trunk, you can also apply the allowed VLAN list to access ports.
- Destination trunk VLAN filtering is applied at the destination. Destination trunk VLAN filtering does not reduce the amount of traffic being sent from the SPAN sources to the SPAN destinations.

When a destination is a trunk, you can use the list of VLANs allowed on the trunk to filter the traffic transmitted from the destination. (CSCeb01318)

Destination trunk VLAN filtering removes the restriction that, within a SPAN session, all destinations receive all the traffic from all the sources. Destination trunk VLAN filtering allows you to select, on a per-VLAN basis, the traffic that is transmitted from each destination trunk to the network analyzer.

To configure destination trunk VLAN filtering on a destination trunk, perform this task:

|        | Command                                                                                                                           | Purpose                                            |
|--------|-----------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphkiwtg"vgtokpcn</code>                                                                                            | Enters global configuration mode.                  |
| Step 2 | <code>Tqwvgt*eqphki+%"kpvgtthceg" type slot/port"</code>                                                                          | Selects the destination trunk port to configure.   |
| Step 3 | <code>Tqwvgt*eqphki/kh+%"uykvejrgtv"vtwpm"cnnqygf"xncp"<br/>}cff"~"gzegrv"~"pqp"~"tgoqxi"<br/>xncp ] .xncp] .xncp] .000__"</code> | Configures the list of VLANs allowed on the trunk. |

- The *vlan* parameter is either a single VLAN number from 1 through 4094, or a range of VLANs described by two VLAN numbers, the lesser one first, separated by a dash. Do not enter any spaces between comma-separated *vlan* parameters or in dash-specified ranges.
- All VLANs are allowed by default.
- To remove all VLANs from the allowed list, enter the **switchport trunk allowed vlan none** command.
- To add VLANs to the allowed list, enter the **switchport trunk allowed vlan add** command.
- You can modify the allowed VLAN list without removing the SPAN configuration.

This example shows the configuration of a local SPAN session that has several VLANs as sources and several trunk ports as destinations, with destination trunk VLAN filtering that filters the SPAN traffic so that each destination trunk port transmits the traffic from one VLAN:

```
kpvgtthceg" IkicdkvGvjgtpgv313
fguetkrvkqp"URCP"fguvkpcvkqp"kpvgthceg"hqt"XNCP"32
pq"kr"cfftguu
uykvejrgtv
uykvejrgtv"vtwpm"gpecruwncvkqp"fqv3s
uykvejrgtv"vtwpm"cnnqygf"xncp"32
uykvejrgtv"oqfg"vtwpm
uykvejrgtv"pqpqiqlkcvq
#
kpvgtthceg" IkicdkvGvjgtpgv314
fguetkrvkqp"URCP"fguvkpcvkqp"kpvgthceg"hqt"XNCP"33
pq"kr"cfftguu
uykvejrgtv
uykvejrgtv"vtwpm"gpecruwncvkqp"fqv3s
uykvejrgtv"vtwpm"cnnqygf"xncp"33
uykvejrgtv"oqfg"vtwpm
uykvejrgtv"pqpqiqlkcvq
#
kpvgtthceg" IkicdkvGvjgtpgv315
fguetkrvkqp"URCP"fguvkpcvkqp"kpvgthceg"hqt"XNCP"34
pq"kr"cfftguu
uykvejrgtv
uykvejrgtv"vtwpm"gpecruwncvkqp"fqv3s
uykvejrgtv"vtwpm"cnnqygf"xncp"34
uykvejrgtv"oqfg"vtwpm
uykvejrgtv"pqpqiqlkcvq
#
kpvgtthceg" IkicdkvGvjgtpgv316
fguetkrvkqp"URCP"fguvkpcvkqp"kpvgthceg"hqt"XNCP"35
pq"kr"cfftguu
uykvejrgtv
uykvejrgtv"vtwpm"gpecruwncvkqp"fqv3s
uykvejrgtv"vtwpm"cnnqygf"xncp"35
uykvejrgtv"oqfg"vtwpm
uykvejrgtv"pqpqiqlkcvq
```

```
#
oqpkvqt "uguukqp" 3 "uqwt eg" xncp "32" / "35
oqpkvqt "uguukqp" 3 "fguvkpcvkqp" kpvgt hceg "Ik313" - 4
```

## Configuring Destination Port Permit Lists (Optional)

To prevent accidental configuration of ports as destinations, you can create a permit list of the ports that are valid for use as destinations. With a destination port permit list configured, you can only configure the ports in the permit list as destinations.

To configure a destination port permit list, perform this task:

|        | Command                                                                                                                 | Purpose                                                                                        |
|--------|-------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|
| Step 1 | Tqwvgt % "eqphkiwtg" vgtokpcn                                                                                           | Enters global configuration mode.                                                              |
| Step 2 | Tqwvgt *eqphki+ % "oqpkvqt" rgtokv/nkuv                                                                                 | Enables use of the destination port permit list.                                               |
| Step 3 | Tqwvgt *eqphki+ % "oqpkvqt" rgtokv/nkuv "fguvkpcvkqp" kpvgt hceg "v{rg" slot/port } / rgtv_ "]. v{rg" slot/port / rgtv_ | Configures a destination port permit list or adds to an existing destination port permit list. |

This example shows how to configure a destination port permit list that includes Gigabit Ethernet ports 5/1 through 5/4 and 6/1:

```
Tqwvgt % "eqphkiwtg" vgtokpcn
Tqwvgt *eqphki+ % "oqpkvqt" rgtokv/nkuv
Tqwvgt *eqphki+ % "oqpkvqt" rgtokv/nkuv "fguvkpcvkqp" kpvgt hceg "ikicdkvgvjgtpgv" 713/6 . "
ikicdkvgvjgtpgv" 813 "
```

This example shows how to verify the configuration:

```
Tqwvgt *eqphki+ % "fq" ujqy "oqpkvqt" rgtokv/nkuv
"URCP" Rgtokv/nkuv " " " " " " <Cfokp "Gpcdnfg
"Rgtokv/nkuv" rgtvu " " " " " " <Ik713/6 . Ik813
```

## Configuring the Egress SPAN Mode (Optional)

Centralized egress SPAN mode is the default. See the [“Restrictions for Distributed Egress SPAN Mode” section on page 56-7](#) for information about switching modules that support distributed egress SPAN mode.

To configure the egress SPAN mode, perform this task:

|        | Command                                                                     | Purpose                                                                                                                                                                          |
|--------|-----------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqwvgt % "eqphkiwtg" vgtokpcn                                               | Enters global configuration mode.                                                                                                                                                |
| Step 2 | Tqwvgt *eqphki+ % "oqpkvqt" uguukqp "gitguu" tgrnkecvkqp/oqfg "fkuvtkdwvgf" | Enables distributed egress SPAN mode.<br><br><b>Note</b> Enter the <b>no monitor session egress replication-mode distributed</b> command to enable centralized egress SPAN mode. |
| Step 3 | Tqwvgt *eqphki+ % "gpf"                                                     | Exits configuration mode.                                                                                                                                                        |

This example shows how to enable distributed egress SPAN mode:

```
Tqwvgt% "eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+% "oqpkvqt"uguukqp"gitguu"tgrnkecvkqp/oqfg"fkuvtkdwvgf"
Tqwvgt*eqphki+% "gp f"
```

This example shows how to disable distributed egress SPAN mode:

```
Tqwvgt% "eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+% "oqpkvqt"uguukqp"gitguu"tgrnkecvkqp/oqfg"egpvtcnk|gf"
Tqwvgt*eqphki+% "gp f"
```

This example shows how to display the configured egress SPAN mode:

```
Tqwvgt% "ujqy"oqpkvqt "uguukqp"gitguu"tgrnkecvkqp/oqfg"~"kpenwfg"Eqphkiwtgf"
Eqphkiwtgf "oqfg" "<"Egpvtcnk|gf
```

# Configuring Local SPAN

- [Configuring Local SPAN \(SPAN Configuration Mode\), page 56-16](#)
- [Configuring Local SPAN \(Global Configuration Mode\), page 56-18](#)

## Configuring Local SPAN (SPAN Configuration Mode)



**Note**

To tag the monitored traffic as it leaves a destination, you must configure the destination to trunk unconditionally before you configure it as a destination (see the [“Configuring a Destination as an Unconditional Trunk \(Optional\)”](#) section on page 56-13).

To configure a local SPAN session in SPAN configuration mode, perform this task:

|        | Command                                                                                | Purpose                                                                                                                                                                                                                                                                                                                                                                   |
|--------|----------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqwvgt% "eqphkiwtg"vgtokpcn"                                                           | Enters global configuration mode.                                                                                                                                                                                                                                                                                                                                         |
| Step 2 | Tqwvgt*eqphki+% "oqpkvqt"uguukqp"<br>local_SPAN_session_number"v{rg"}nqecn"~"nqecn/vz_ | Configures a local SPAN session number and enters local SPAN session configuration mode.<br><br><b>Note</b> <ul style="list-style-type: none"> <li>• Enter the <b>local</b> keyword to configure <a href="#">ingress or egress or both</a> SPAN sessions.</li> <li>• Enter the <b>local-tx</b> keyword to configure <a href="#">egress-only</a> SPAN sessions.</li> </ul> |
| Step 3 | Tqwvgt*eqphki/oqp/nqecn+% "fguetkrvkqp"<br>uguukqpafguetkrvkqp"                        | (Optional) Describes the local SPAN session.                                                                                                                                                                                                                                                                                                                              |

| Command                                                                                                                                                                                                                                                 | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 4</b><br><pre>Tqwvgt*eqphki/oqp/nqecn+%<b>"uqwtteg"</b>}ukpingakpvgthceg"~" kpvgtthcegankuv"~"kpvgtthcegatcpig"~" okzgfakpvgthcegankuv"~"ukpingaxncp"~"xncpankuv"~" xncpatcpig"~"okzgfaxncpankuv;" ]<b>tz</b>"~"<b>vz</b>"~"<b>dqvj_</b>"</pre> | Associates the local SPAN session number with the source ports or VLANs, and selects the traffic direction to be monitored.<br><br><b>Note</b> <ul style="list-style-type: none"> <li>When you enter the <b>local-tx</b> keyword, the <b>rx</b> and <b>both</b> keywords are not available and the <b>tx</b> keyword is required.</li> <li>To make best use of the available SPAN sessions, it is always preferable to configure <b>local-tx</b> sessions instead of <b>local</b> sessions with the <b>tx</b> keyword.</li> </ul> |
| <b>Step 5</b><br><pre>Tqwvgt*eqphki/oqp/nqecn+%<b>"hknvgt"</b>ukpingaxncp"~" xncpankuv"~"xncpatcpig"~"okzgfaxncpankuv"</pre>                                                                                                                            | (Optional) Configures source VLAN filtering when the local SPAN source is a trunk port.                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Step 6</b><br><pre>Tqwvgt*eqphki/oqp/nqecn+%<b>"fguvkpcvkqp"</b> }ukpingakpvgthceg"~"kpvgtthcegankuv"~"kpvgtthcegatcpig" ~"okzgfakpvgthcegankuv;" ]<b>kpitguu ]ngctpkpi_</b></pre>                                                                   | Associates the local SPAN session number with the destinations.                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Step 7</b><br><pre>Tqwvgt*eqphki/oqp/nqecn+%<b>"pq"ujwvfqyp"</b></pre>                                                                                                                                                                               | Activates the local SPAN session.<br><br><b>Note</b> The <b>no shutdown</b> command and <b>shutdown</b> commands are not supported for local-tx egress-only SPAN sessions.                                                                                                                                                                                                                                                                                                                                                        |
| <b>Step 8</b><br><pre>Tqwvgt*eqphki/oqp/nqecn+%<b>"gpf"</b></pre>                                                                                                                                                                                       | Exits configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

- session\_description* can be up to 240 characters and cannot contain special characters. The description can contain spaces.



**Note** You can enter 240 characters after the **description** command.

- local\_span\_session\_number* can range from 1 to 80.
- single\_interface* is as follows:
  - interface type slot/port**; *type* is **fastethernet**, **gigabitethernet**, or **tengigabitethernet**.
  - interface port-channel number**



**Note** Destination port channel interfaces must be configured with the **channel-group group\_num mode on** command and the **no channel-protocol** command. See the [“How to Configure EtherChannels”](#) section on page 23-7.

- interface\_list* is *single\_interface* , *single\_interface* , *single\_interface* ...



**Note** In lists, you must enter a space before and after the comma. In ranges, you must enter a space before and after the dash.

- interface\_range* is **interface type slot/first\_port - last\_port**.
- mixed\_interface\_list* is, in any order, *single\_interface* , *interface\_range* , ...

- *single\_vlan* is the ID number of a single VLAN.
- *vlan\_list* is *single\_vlan* , *single\_vlan* , *single\_vlan* ...
- *vlan\_range* is *first\_vlan\_ID* - *last\_vlan\_ID*.
- *mixed\_vlan\_list* is, in any order, *single\_vlan* , *vlan\_range* , ...
- Enter the **ingress** keyword to configure destinations to receive traffic from attached devices.
- Enter the **learning** keyword to enable MAC address learning from the destinations, which allows the switch to transmit traffic that is addressed to devices attached to the destinations.

When configuring destinations with the **ingress** and **learning** keywords, note the following:

- Configure the destinations for Layer 2 switching. See the [“How to Configure LAN Interfaces for Layer 2 Switching” section on page 21-5](#).
- If the destination is a trunk and the attached device transmits untagged traffic back to the switch, use 802.1Q trunking with the native VLAN configured to accept the traffic from the attached device.
- Do not configure the destinations with Layer 3 addresses. Use a VLAN interface to route traffic to and from devices attached to destinations.
- Destinations are held in the down state. To route the traffic to and from attached devices, configure an additional active Layer 2 port in the VLAN to keep the VLAN interface up.

This example shows how to configure session 1 to monitor ingress traffic from Gigabit Ethernet port 1/1 and configure Gigabit Ethernet port 1/2 as the destination:

```
Tqwgvt*eqphki+% "oqpkvqt"uguukqp"3"v{rg"nqecn"
Tqwgvt*eqphki/oqp/nqecn+% "uqwtg"kpvgthceg"ikicdkvgvjgtpgv"313"tz"
Tqwgvt*eqphki/oqp/nqecn+% "fguvkpcvkqp"kpvgthceg"ikicdkvgvjgtpgv"314"
```

For additional examples, see the [“Configuration Examples for SPAN” section on page 56-31](#).

## Configuring Local SPAN (Global Configuration Mode)



### Note

- To tag the monitored traffic as it leaves a destination, you must configure the destination to trunk unconditionally before you configure it as a destination (see the [“Configuring a Destination as an Unconditional Trunk \(Optional\)” section on page 56-13](#)).
- You can configure up to two local SPAN sessions in global configuration mode.
- You can use SPAN configuration mode for all SPAN configuration tasks.
- You must use SPAN configuration mode to configure the supported maximum number of SPAN sessions.



Local SPAN does not use separate source and destination sessions. To configure a local SPAN session, configure local SPAN sources and destinations with the same session number. To configure a local SPAN session, perform this task:

|        | Command                                                                                                                                                                                                                                                     | Purpose                                                                                                                           |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt%eqphkiwtg"vgtokpcn"</code>                                                                                                                                                                                                                     | Enters global configuration mode.                                                                                                 |
| Step 2 | <code>Tqwwgt*eqphki+%"oqpkvgt"uguukqp"<br/>ngecnaurcpauguukqpapwodgt"uqwtg"}ukpingakpvgthceg"~"<br/>kpvgtthcegankuv"~"kpvgtthcegatcpig"~"okzgfakpvgthcegankuv"<br/>~"ukpingaxncp"~"xncpankuv"~"xncpatcpig"~"<br/>okzgfaxncpankuv;" ]tz"~"vz"~"dqvj_"</code> | Associates the local SPAN source session number with the source ports or VLANs and selects the traffic direction to be monitored. |
| Step 3 | <code>Tqwwgt*eqphki+%"oqpkvgt"uguukqp"<br/>ngecnaurcpauguukqpapwodgt"fguvkpcvkqp"}ukpingakpvgthceg"<br/>~"kpvgtthcegankuv"~"kpvgtthcegatcpig"~"<br/>okzgfakpvgthcegankuv;" ]kpitguu" ]ngctpkpi_</code>                                                      | Associates the local SPAN session number and the destinations.                                                                    |

- *local\_span\_session\_number* can range from 1 to 80.
- *single\_interface* is as follows:
  - **interface type slot/port**; *type* is **fastethernet**, **gigabitethernet**, or **tengigabitethernet**.
  - **interface port-channel number**



**Note** Destination port channel interfaces must be configured with the **channel-group group\_num mode on** command and the **no channel-protocol** command. See the [“How to Configure EtherChannels” section on page 23-7](#).

- *interface\_list* is *single\_interface* , *single\_interface* , *single\_interface* ...



**Note** In lists, you must enter a space before and after the comma. In ranges, you must enter a space before and after the dash.

- *interface\_range* is **interface type slot/first\_port - last\_port**.
- *mixed\_interface\_list* is, in any order, *single\_interface* , *interface\_range* , ...
- *single\_vlan* is the ID number of a single VLAN.
- *vlan\_list* is *single\_vlan* , *single\_vlan* , *single\_vlan* ...
- *vlan\_range* is *first\_vlan\_ID - last\_vlan\_ID*.
- *mixed\_vlan\_list* is, in any order, *single\_vlan* , *vlan\_range* , ...
- Enter the **ingress** keyword to configure destinations to receive traffic from attached devices.
- Enter the **learning** keyword to enable MAC address learning from the destinations, which allows the switch to transmit traffic that is addressed to devices attached to the destinations.

When configuring destinations with the **ingress** and **learning** keywords, note the following:

- Configure the destinations for Layer 2 switching. See the [“How to Configure LAN Interfaces for Layer 2 Switching” section on page 21-5](#).
- If the destination is a trunk and the attached device transmits untagged traffic back to the switch, use 802.1Q trunking with the native VLAN configured to accept the traffic from the attached device.

- Do not configure the destinations with Layer 3 addresses. Use a VLAN interface to route traffic to and from devices attached to destinations.
- Destinations are held in the down state. To route the traffic to and from attached devices, configure an additional active Layer 2 port in the VLAN to keep the VLAN interface up.

This example shows how to configure Gigabit Ethernet port 5/1 as a bidirectional source for session 1:

```
Tqwvgt*eqphki+% "oqpkvqt"uguukqp"3"uqwteg"kpvgthceg"ikicdkvgvjgtpgv"713"
```

This example shows how to configure Gigabit Ethernet port 5/48 as the destination for SPAN session 1:

```
Tqwvgt*eqphki+% "oqpkvqt"uguukqp"3"fguvkpcvkqp"kpvgthceg"ikicdkvgvjgtpgv"716:"
```

For additional examples, see the [“Configuration Examples for SPAN” section on page 56-31](#).

## Configuring RSPAN

- [Configuring RSPAN VLANs, page 56-20](#)
- [Configuring RSPAN Sessions \(SPAN Configuration Mode\), page 56-20](#)
- [Configuring RSPAN Sessions \(Global Configuration Mode\), page 56-23](#)

### Configuring RSPAN VLANs

To configure a VLAN as an RSPAN VLAN, perform this task:

|        | Command                                                        | Purpose                                                                                                                                                         |
|--------|----------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt% "eqphkiwtg"vgtokpcn</code>                       | Enters global configuration mode.                                                                                                                               |
| Step 2 | <code>Tqwvgt*eqphki+% "xncp"vlan_ID] } / ~ . ; vlan_ID_</code> | Creates or modifies an Ethernet VLAN, a range of Ethernet VLANs, or several Ethernet VLANs specified in a comma-separated list (do not enter space characters). |
| Step 3 | <code>Tqwvgt*eqphki/xncp+% "tgoqvg/urcp"</code>                | Configures the VLAN as an RSPAN VLAN.                                                                                                                           |
| Step 4 | <code>Tqwvgt*eqphki/xncp+% "gpf"</code>                        | Updates the VLAN database and returns to privileged EXEC mode.                                                                                                  |

### Configuring RSPAN Sessions (SPAN Configuration Mode)

- [Configuring RSPAN Source Sessions in SPAN Configuration Mode, page 56-21](#)
- [Configuring RSPAN Destination Sessions in SPAN Configuration Mode, page 56-22](#)

## Configuring RSPAN Source Sessions in SPAN Configuration Mode

To configure an RSPAN source session in SPAN configuration mode, perform this task:

|        | Command                                                                                                                                                                                                                           | Purpose                                                                                                                       |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt% "eqphkiwtg"vgtokpcn</code>                                                                                                                                                                                          | Enters global configuration mode.                                                                                             |
| Step 2 | <code>Tqwwgt*eqphki+% "oqpkvgt"uguukqp"<br/>RSPAN_source_session_number"v{rg"turcp/uqwtg"</code>                                                                                                                                  | Configures an RSPAN source session number and enters RSPAN source session configuration mode for the session.                 |
| Step 3 | <code>Tqwwgt*eqphki/oqp/turcp/ute+% "<br/>fguetkrvkqp uguukqpa fguetkrvkqp"</code>                                                                                                                                                | (Optional) Describes the RSPAN source session.                                                                                |
| Step 4 | <code>Tqwwgt*eqphki/oqp/turcp/ute+% "uqwtg"<br/>}ukpingakpvgthceg"~"kpvgt hcegankuv"~"<br/>kpvgt hcegatcpig"~"okzgfakpvgthcegankuv"~"<br/>ukpingaxncp"~"xncpankuv"~"xncpatcpig"~"<br/>okzgfaxncpankuv;" ] tz ~ vz"~"dqvj_"</code> | Associates the RSPAN source session number with the source ports or VLANs, and selects the traffic direction to be monitored. |
| Step 5 | <code>Tqwwgt*eqphki/oqp/turcp/ute+% "hknvgt"ukpingaxncp"<br/>~"xncpankuv"~"xncpatcpig"~"okzgfaxncpankuv"</code>                                                                                                                   | (Optional) Configures source VLAN filtering when the RSPAN source is a trunk port.                                            |
| Step 6 | <code>Tqwwgt*eqphki/oqp/turcp/ute+% "fguvkpcvkqp"<br/>tgoqvg xncp" rspan_vlan_ID"</code>                                                                                                                                          | Associates the RSPAN source session number session number with the RSPAN VLAN.                                                |
| Step 7 | <code>Tqwwgt*eqphki/oqp/turcp/ute+% "pq"ujwvfqyp"</code>                                                                                                                                                                          | Activates the RSPAN source session.                                                                                           |
| Step 8 | <code>Tqwwgt*eqphki/oqp/turcp/ute+% "gpf"</code>                                                                                                                                                                                  | Exits configuration mode.                                                                                                     |

- *session\_description* can be up to 240 characters and cannot contain special characters. The description can contain spaces.



**Note** You can enter 240 characters after the **description** command.

- *RSPAN\_source\_span\_session\_number* can range from 1 to 80.
- *single\_interface* is as follows:
  - **interface type slot/port**; *type* is **fastethernet**, **gigabitethernet**, or **tengigabitethernet**.
  - **interface port-channel number**
- *interface\_list* is *single\_interface* , *single\_interface* , *single\_interface* ...



**Note** In lists, you must enter a space before and after the comma. In ranges, you must enter a space before and after the dash.

- *interface\_range* is **interface type slot/first\_port - last\_port**.
- *mixed\_interface\_list* is, in any order, *single\_interface* , *interface\_range* , ...
- *single\_vlan* is the ID number of a single VLAN.
- *vlan\_list* is *single\_vlan* , *single\_vlan* , *single\_vlan* ...
- *vlan\_range* is *first\_vlan\_ID - last\_vlan\_ID*.
- *mixed\_vlan\_list* is, in any order, *single\_vlan* , *vlan\_range* , ...

- See the [“Configuring RSPAN VLANs”](#) section on page 56-20 for information about the RSPAN VLAN ID.

This example shows how to configure session 1 to monitor bidirectional traffic from Gigabit Ethernet port 1/1:

```
Tqwgvt*eqphki+% "oqpkvgt "uguukqp"3 "v{rg"turcp/uqwtg"
Tqwgvt*eqphki/oqp/turcp/ute+% "uqwtg"kpvgthceg"ikicdkvgvjgtpgv"313"
Tqwgvt*eqphki/oqp/turcp/ute+% "fguvkpcvkqp"tgoqvg xncp"4"
```

For additional examples, see the [“Configuration Examples for SPAN”](#) section on page 56-31.

## Configuring RSPAN Destination Sessions in SPAN Configuration Mode



### Note

- To tag the monitored traffic, you must configure the port to trunk unconditionally before you configure it as a destination (see the [“Configuring a Destination as an Unconditional Trunk \(Optional\)”](#) section on page 56-13).
- You can configure an RSPAN destination session on the RSPAN source session switch to monitor RSPAN traffic locally.

To configure an RSPAN destination session, perform this task:

|        | Command                                                                                                                                                                       | Purpose                                                                                                                 |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt% "eqphkiwtg"vgtokpcn</code>                                                                                                                                      | Enters global configuration mode.                                                                                       |
| Step 2 | <code>Tqwgvt*eqphki+% "oqpkvgt "uguukqp"<br/>RSPAN_destination_session_number"v{rg"<br/>turcp/fguvkpcvkqp"</code>                                                             | Configures an RSPAN destination session number and enters RSPAN destination session configuration mode for the session. |
| Step 3 | <code>Tqwgvt*eqphki/oqp/turcp/fuv+% "fguetkrvkqp"<br/>uguukqpafguetkrvkqp"</code>                                                                                             | (Optional) Describes the RSPAN destination session.                                                                     |
| Step 4 | <code>Tqwgvt*eqphki/oqp/turcp/fuv+% "uqwtg"tgoqvg"xncp"<br/>rspan_vlan_ID"</code>                                                                                             | Associates the RSPAN destination session number with the RSPAN VLAN.                                                    |
| Step 5 | <code>Tqwgvt*eqphki/oqp/turcp/fuv+% "fguvkpcvkqp"<br/>}ukpingakpvgtgthceg"~"kpvgthcegankuv"~"<br/>kpvgthcegatcpig"~"okzg fakpvgtgthcegankuv;"<br/>]kpitguu ]ngctpkpi__</code> | Associates the RSPAN destination session number with the destinations.                                                  |
| Step 6 | <code>Tqwgvt*eqphki/oqp/turcp/fuv+% "gpf"</code>                                                                                                                              | Exits configuration mode.                                                                                               |

- *RSPAN\_destination\_span\_session\_number* can range from 1 to 80.
- *single\_interface* is as follows:
  - **interface** *type slot/port*; *type* is **fastethernet**, **gigabitethernet**, or **tengigabitethernet**.
  - **interface** *port-channel number*



### Note

Destination port channel interfaces must be configured with the **channel-group group\_num mode on** command and the **no channel-protocol** command. See the [“How to Configure EtherChannels”](#) section on page 23-7.

- *interface\_list* is *single\_interface* , *single\_interface* , *single\_interface* ...



**Note** In lists, you must enter a space before and after the comma. In ranges, you must enter a space before and after the dash.

- *interface\_range* is **interface** type *slot/first\_port - last\_port*.
- *mixed\_interface\_list* is, in any order, *single\_interface* , *interface\_range* , ...
- Enter the **ingress** keyword to configure destinations to receive traffic from attached devices.
- Enter the **learning** keyword to enable MAC address learning from the destinations, which allows the switch to transmit traffic that is addressed to devices attached to the destinations.

When configuring destinations with the **ingress** and **learning** keywords, note the following:

- Configure the destinations for Layer 2 switching. See the [“How to Configure LAN Interfaces for Layer 2 Switching”](#) section on page 21-5.
- If the destination is a trunk and the attached device transmits untagged traffic back to the switch, use 802.1Q trunking with the native VLAN configured to accept the traffic from the attached device.
- Do not configure the destinations with Layer 3 addresses. Use a VLAN interface to route traffic to and from devices attached to destinations.
- Destinations are held in the down state. To route the traffic to and from attached devices, configure an additional active Layer 2 port in the VLAN to keep the VLAN interface up.
- The **no shutdown** command and **shutdown** commands are not supported for RSPAN destination sessions.

This example shows how to configure RSPAN VLAN 2 as the source for session 1 and Gigabit Ethernet port 1/2 as the destination:

```
Tqvwgt*eqphki+% "oqpkvqt" ugwukqp "3" v{rg"turcp/fguvkpcvkqp"
Tqvwgt*eqphki/turcp/fuv+% "uqwtg" tgoqvg"xncp"4"
Tqvwgt*eqphki/turcp/fuv+% "fguvkpcvkqp" kpvgthceg"ikicdkvgvjgtpgv"314"
```

For additional examples, see the [“Configuration Examples for SPAN”](#) section on page 56-31.

## Configuring RSPAN Sessions (Global Configuration Mode)

- [Configuring RSPAN Source Sessions in Global Configuration Mode, page 56-24](#)
- [Configuring RSPAN Destination Sessions in Global Configuration Mode, page 56-25](#)

## Configuring RSPAN Source Sessions in Global Configuration Mode

To configure an RSPAN source session in global configuration mode, perform this task:

|        | Command                                                                                                                                                                                                                                                            | Purpose                                                                                                                       |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt%eqphkiwtg"vgtokpcn</code>                                                                                                                                                                                                                             | Enters global configuration mode.                                                                                             |
| Step 2 | <code>Tqwgvt*eqphki+%oqpkvqt"uguukqp"<br/>RSPAN_source_session_number"uqwteg"<br/>}ukpingakpvgthceg"~"kpvgtthcegankuv"~"<br/>kpvgtthcegatcpig"~"okzgfakpvgthcegankuv"~"<br/>ukpingaxncp"~"xncpankuv"~"xncpatcpig"~"<br/>okzgfaxncpankuv;" ]tz"~"vz"~"dqvj_"</code> | Associates the RSPAN source session number with the source ports or VLANs, and selects the traffic direction to be monitored. |
| Step 3 | <code>Tqwgvt*eqphki+%oqpkvqt"uguukqp"<br/>RSPAN_source_session_number"fguvkpcvkqp"<br/>tgoqvg xncp"rspan_vlan_ID"</code>                                                                                                                                           | Associates the RSPAN source session session number with the RSPAN VLAN.                                                       |

- To configure RSPAN VLANs, see the [“Configuring RSPAN VLANs” section on page 56-20](#).
- `RSPAN_source_span_session_number` can range from 1 to 80.
- `single_interface` is as follows:
  - `interface type slot/port`; `type` is `fastethernet`, `gigabitethernet`, or `tengigabitethernet`.
  - `interface port-channel number`
- `interface_list` is `single_interface` , `single_interface` , `single_interface` ...



**Note** In lists, you must enter a space before and after the comma. In ranges, you must enter a space before and after the dash.

- `interface_range` is `interface type slot/first_port - last_port`.
- `mixed_interface_list` is, in any order, `single_interface` , `interface_range` , ...
- `single_vlan` is the ID number of a single VLAN.
- `vlan_list` is `single_vlan` , `single_vlan` , `single_vlan` ...
- `vlan_range` is `first_vlan_ID - last_vlan_ID`.
- `mixed_vlan_list` is, in any order, `single_vlan` , `vlan_range` , ...
- See the [“Configuring RSPAN VLANs” section on page 56-20](#) for information about the RSPAN VLAN ID.

This example shows how to configure Gigabit Ethernet port 5/2 as the source for session 2:

```
Tqwgvt*eqphki+%oqpkvqt"uguukqp"4"uqwteg"kpvgthceg"ikicdkvgvjgtpgv"714"
```

This example shows how to configure RSPAN VLAN 200 as the destination for session 2:

```
Tqwgvt*eqphki+%oqpkvqt"uguukqp"4"fguvkpcvkqp"tgoqvg xncp"422"
```

For additional examples, see the [“Configuration Examples for SPAN” section on page 56-31](#).

## Configuring RSPAN Destination Sessions in Global Configuration Mode

**Note**

- To tag the monitored traffic, you must configure the port to trunk unconditionally before you configure it as a destination (see the [“Configuring a Destination as an Unconditional Trunk \(Optional\)”](#) section on page 56-13).
- You can configure an RSPAN destination session on the RSPAN source session switch to monitor RSPAN traffic locally.

To configure an RSPAN destination session in global configuration mode, perform this task:

|        | Command                                                                                                                                                                                                                      | Purpose                                                                |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt% "eqphkiwtg" vgtokpcn</code>                                                                                                                                                                                    | Enters global configuration mode.                                      |
| Step 2 | <code>Tqwvgt*eqphki+% "ogpkvgt" uguukqp "<br/>RSPAN_destination_session_number" uqwtg "tgoqvg" "<br/>xncp" rspan_vlan_ID"</code>                                                                                             | Associates the RSPAN destination session number with the RSPAN VLAN.   |
| Step 3 | <code>Tqwvgt*eqphki+% "ogpkvgt" uguukqp "<br/>RSPAN_destination_session_number" fguvkpcvkqp "<br/>}ukpingakpvgthceg" ~" kpvgtthcegankuv" ~" "<br/>kpvgthcegatcpig" ~" okzgfakpvgthcegankuv; "<br/>]kpitguu ]ngctpkpi_</code> | Associates the RSPAN destination session number with the destinations. |

- RSPAN\_destination\_span\_session\_number* can range from 1 to 80.
- See the [“Configuring RSPAN VLANs”](#) section on page 56-20 for information about the RSPAN VLAN ID.
- single\_interface* is as follows:
  - interface** *type slot/port*; *type* is **fastethernet**, **gigabitethernet**, or **tengigabitethernet**.
  - interface** **port-channel** *number*

**Note**

Destination port channel interfaces must be configured with the **channel-group group\_num mode on** command and the **no channel-protocol** command. See the [“How to Configure EtherChannels”](#) section on page 23-7.

- interface\_list* is *single\_interface* , *single\_interface* , *single\_interface* ...

**Note**

In lists, you must enter a space before and after the comma. In ranges, you must enter a space before and after the dash.

- interface\_range* is **interface** *type slot/first\_port - last\_port*.
- mixed\_interface\_list* is, in any order, *single\_interface* , *interface\_range* , ...
- Enter the **ingress** keyword to configure destinations to receive traffic from attached devices.
- Enter the **learning** keyword to enable MAC address learning from the destinations, which allows the switch to transmit traffic that is addressed to devices attached to the destinations.

When configuring destinations with the **ingress** and **learning** keywords, note the following:

- Configure the destinations for Layer 2 switching. See the [“How to Configure LAN Interfaces for Layer 2 Switching”](#) section on page 21-5.
- If the destination is a trunk and the attached device transmits untagged traffic back to the switch, use 802.1Q trunking with the native VLAN configured to accept the traffic from the attached device.
- Do not configure the destinations with Layer 3 addresses. Use a VLAN interface to route traffic to and from devices attached to destinations.
- Destinations are held in the down state. To route the traffic to and from attached devices, configure an additional active Layer 2 port in the VLAN to keep the VLAN interface up.

This example shows how to configure RSPAN VLAN 200 as the source for session 3:

```
Tqwwgt*eqphki+% "oqpkvgt"uguukqp"5"uqwtegtgoqvg xncp"422"
```

This example shows how to configure Gigabit Ethernet port 5/47 as the destination for session 3:

```
Tqwwgt*eqphki+% "oqpkvgt"uguukqp"5"fguvkpcvkqp"kpvgthceg"ikiedkvvgjgtpgv"7169"
```

For additional examples, see the [“Configuration Examples for SPAN”](#) section on page 56-31.

## Configuring ERSPAN

- [Configuring ERSPAN Source Sessions, page 56-26](#)
- [Configuring ERSPAN Destination Sessions, page 56-28](#)

### Configuring ERSPAN Source Sessions

To configure an ERSPAN source session, perform this task:

|        | Command                                                                                                                                                                                                          | Purpose                                                                                                                        |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqwwgt% "eqphkiwtg"vgtokpcn                                                                                                                                                                                      | Enters global configuration mode.                                                                                              |
| Step 2 | Tqwwgt*eqphki+% "oqpkvgt"uguukqp"<br>ERSPAN_source_session_number"v{rg"gturcp/uqwtegt                                                                                                                            | Configures an ERSPAN source session number and enters ERSPAN source session configuration mode for the session.                |
| Step 3 | Tqwwgt*eqphki/oqp/gturcp/ute+% "fguetkrvkqp"<br>uguukqpafguetkrvkqp"                                                                                                                                             | (Optional) Describes the ERSPAN source session.                                                                                |
| Step 4 | Tqwwgt*eqphki/oqp/gturcp/ute+% "uqwtegt"<br>{ukpingakpvgtthceg"~"kpvgthcegankuv"~"kpvgthcegatcpig"<br>~"okzgfakpvgtthcegankuv"~"ukpingaxncp"~"xncpankuv"~"<br>xncpatcpig"~"okzgfaxncpankuv;" ] tz"~"vz"~"dqvj_;" | Associates the ERSPAN source session number with the source ports or VLANs, and selects the traffic direction to be monitored. |
| Step 5 | Tqwwgt*eqphki/oqp/gturcp/ute+% "hknvgt"ukpingaxncp"~"<br>xncpankuv"~"xncpatcpig"~"okzgfaxncpankuv"                                                                                                               | (Optional) Configures source VLAN filtering when the ERSPAN source is a trunk port.                                            |
| Step 6 | Tqwwgt*eqphki/oqp/gturcp/ute+% "fguvkpcvkqp"                                                                                                                                                                     | Enters ERSPAN source session destination configuration mode.                                                                   |



|         | Command                                                                                            | Purpose                                                                                                                                                                                                                                                                                      |
|---------|----------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 7  | <code>Tqwvgt*eqphki/oqp/gturcp/ute/fuv+%<b>"kr"cffftguu</b>"<br/>kracffftguu"</code>               | Configures the ERSPAN flow destination IP address, which must also be configured on an interface on the destination switch and be entered in the ERSPAN destination session configuration (see the <a href="#">“Configuring ERSPAN Destination Sessions”</a> section on page 56-28, Step 6). |
| Step 8  | <code>Tqwvgt*eqphki/oqp/gturcp/ute/fuv+%<b>"gturcp/kf"</b><br/>ERSPAN_flow_id"</code>              | Configures the ID number used by the source and destination sessions to identify the ERSPAN traffic, which must also be entered in the ERSPAN destination session configuration (see the <a href="#">“Configuring ERSPAN Destination Sessions”</a> section on page 56-28, Step 7).           |
| Step 9  | <code>Tqwvgt*eqphki/oqp/gturcp/ute/fuv+%<b>"gtkikp"kr"cffftguu"</b><br/>kracffftguu"]hqteg_</code> | Configures the IP address used as the source of the ERSPAN traffic.                                                                                                                                                                                                                          |
| Step 10 | <code>Tqwvgt*eqphki/oqp/gturcp/ute/fuv+%<b>"kr"vvn"vvnaxcnwg"</b></code>                           | (Optional) Configures the IP time-to-live (TTL) value of the packets in the ERSPAN traffic.                                                                                                                                                                                                  |
| Step 11 | <code>Tqwvgt*eqphki/oqp/gturcp/ute/fuv+%<b>"kr"rtge"krxaxcnwg"</b></code>                          | (Optional) Configures the IP precedence value of the packets in the ERSPAN traffic.                                                                                                                                                                                                          |
| Step 12 | <code>Tqwvgt*eqphki/oqp/gturcp/ute/fuv+%<b>"kr"fuer"</b><br/>fueraxcnwg"</code>                    | (Optional) Configures the IP DSCP value of the packets in the ERSPAN traffic.                                                                                                                                                                                                                |
| Step 13 | <code>Tqwvgt*eqphki/oqp/gturcp/ute/fuv+%<b>"xth"xthapcog"</b></code>                               | (Optional) Configures the VRF name to use instead of the global routing table.                                                                                                                                                                                                               |
| Step 14 | <code>Tqwvgt*eqphki/oqp/gturcp/ute+%<b>"pq"ujwvfqyp"</b></code>                                    | Activates the ERSPAN source session.                                                                                                                                                                                                                                                         |
| Step 15 | <code>Tqwvgt*eqphki/oqp/gturcp/ute/fuv+%<b>"gpf"</b></code>                                        | Exits configuration mode.                                                                                                                                                                                                                                                                    |

- *session\_description* can be up to 240 characters and cannot contain special characters. The description can contain spaces.



**Note** You can enter 240 characters after the **description** command.

- *ERSPAN\_source\_span\_session\_number* can range from 1 to 80.
- *single\_interface* is as follows:
  - **interface** *type slot/port*; *type* is **fastethernet**, **gigabitethernet**, or **tengigabitethernet**.
  - **interface** **port-channel** *number*



**Note** Port channel interfaces must be configured with the **channel-group** *group\_num* **mode on** command and the **no channel-protocol** command. See the [“How to Configure EtherChannels”](#) section on page 23-7.

- *interface\_list* is *single\_interface* , *single\_interface* , *single\_interface* ...



**Note** In lists, you must enter a space before and after the comma. In ranges, you must enter a space before and after the dash.

- *interface\_range* is **interface type slot/first\_port - last\_port**.
- *mixed\_interface\_list* is, in any order, *single\_interface* , *interface\_range* , ...
- *single\_vlan* is the ID number of a single VLAN.
- *vlan\_list* is *single\_vlan* , *single\_vlan* , *single\_vlan* ...
- *vlan\_range* is *first\_vlan\_ID - last\_vlan\_ID*.
- *mixed\_vlan\_list* is, in any order, *single\_vlan* , *vlan\_range* , ...
- *ERSPAN\_flow\_id* can range from 1 to 1023.
- All ERSPAN source sessions on a switch must use the same source IP address. Enter the **origin ip address ip\_address force** command to change the origin IP address configured in all ERSPAN source sessions on the switch.
- *ttl\_value* can range from 1 to 255.
- *ipp\_value* can range from 0 to 7.
- *dscp\_value* can range from 0 to 63.

This example shows how to configure session 3 to monitor bidirectional traffic from Gigabit Ethernet port 4/1:

```
Tqwwgt*eqphki+% "oqpkvgt"uguukqp"5"v{rg"gturcp/uqwtg"
Tqwwgt*eqphki/oqp/gturcp/ute+% "uqwtg"kpvgthceg"ikicdkvgvjgtpgv"613"
Tqwwgt*eqphki/oqp/gturcp/ute+% "fguvkpcvkqp"
Tqwwgt*eqphki/oqp/gturcp/ute/fuv+% "kr"cfftgau"32030303"
Tqwwgt*eqphki/oqp/gturcp/ute/fuv+% "qtkikp"kr"cfftgau"42030303"
Tqwwgt*eqphki/oqp/gturcp/ute/fuv+% "gturcp/kf"323"
```

For additional examples, see the “Configuration Examples for SPAN” section on page 56-31.

## Configuring ERSPAN Destination Sessions



**Note** You cannot monitor ERSPAN traffic locally.

To configure an ERSPAN destination session, perform this task:

|        | Command                                                                                                                                                      | Purpose                                                                                                                   |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqwwgt% "eqphkiwtg"vgtokpcn                                                                                                                                  | Enters global configuration mode.                                                                                         |
| Step 2 | Tqwwgt*eqphki+% "oqpkvgt"uguukqp"<br>ERSPAN_destination_session_number"v{rg"<br>gturcp/fguvkpcvkqp"                                                          | Configures an ERSPAN destination session number and enters ERSPAN destination session configuration mode for the session. |
| Step 3 | Tqwwgt*eqphki/oqp/gturcp/fuv+% "fguetkrvkqp"<br>uguukqpafguetkrvkqp"                                                                                         | (Optional) Describes the ERSPAN destination session.                                                                      |
| Step 4 | Tqwwgt*eqphki/oqp/gturcp/fuv+% "fguvkpcvkqp"<br>}ukpingakpvgtgthceg"~"kpvgthcegankuv"~"<br>kpvgthcegatcpig"~"okzgfakpvgtgthcegankuv;"<br>]kpitguu ]ngctpkpi_ | Associates the ERSPAN destination session number with the destinations.                                                   |
| Step 5 | Tqwwgt*eqphki/oqp/gturcp/fuv+% "uqwtg"                                                                                                                       | Enters ERSPAN destination session source configuration mode.                                                              |

|         | Command                                                                         | Purpose                                                                                                                                                                                                                                        |
|---------|---------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 6  | <code>Tqwvgt*eqphki/oqp/gturcp/fuv/ute+%"kr"cffftguu"kracffftguu"]hqteq_</code> | Configures the ERSPAN flow destination IP address. This must be an address on a local interface and match the address that you entered in the “ <a href="#">Configuring ERSPAN Source Sessions</a> ” section on page 56-26, Step 7.            |
| Step 7  | <code>Tqwvgt*eqphki/oqp/gturcp/fuv/ute+%"gturcp/kf"ERSPAN_flow_id"</code>       | Configures the ID number used by the destination and destination sessions to identify the ERSPAN traffic. This must match the ID that you entered in the “ <a href="#">Configuring ERSPAN Source Sessions</a> ” section on page 56-26, Step 8. |
| Step 8  | <code>Tqwvgt*eqphki/oqp/gturcp/fuv/ute+%"xth"xthapcog"</code>                   | (Optional) Configures the VRF name used instead of the global routing table.                                                                                                                                                                   |
| Step 9  | <code>Tqwvgt*eqphki/oqp/gturcp/fuv+%"pq"ujwvfqyp"</code>                        | Activates the ERSPAN destination session.                                                                                                                                                                                                      |
| Step 10 | <code>Tqwvgt*eqphki/oqp/gturcp/fuv/ute+%"gpf"</code>                            | Exits configuration mode.                                                                                                                                                                                                                      |

- *ERSPAN\_destination\_span\_session\_number* can range from 1 to 80.
- *single\_interface* is as follows:
  - **interface** *type slot/port*; *type* is **fastethernet**, **gigabitethernet**, or **tengigabitethernet**.
  - **interface** **port-channel** *number*



**Note** Destination port channel interfaces must be configured with the **channel-group group\_num mode on** command and the **no channel-protocol** command. See the “[How to Configure EtherChannels](#)” section on page 23-7.

- *interface\_list* is *single\_interface* , *single\_interface* , *single\_interface* ...



**Note** In lists, you must enter a space before and after the comma. In ranges, you must enter a space before and after the dash.

- *interface\_range* is **interface** *type slot/first\_port - last\_port*.
- *mixed\_interface\_list* is, in any order, *single\_interface* , *interface\_range* , ...
- All ERSPAN destination sessions on a switch must use the same IP address on the same destination interface. Enter the **ip address ip\_address force** command to change the IP address configured in all ERSPAN destination sessions on the switch.



**Note** You must also change all ERSPAN source session destination IP addresses (see the “[Configuring ERSPAN Source Sessions](#)” section on page 56-26, Step 7).

- *ERSPAN\_flow\_id* can range from 1 to 1023.
- Enter the **ingress** keyword to configure destinations to receive traffic from attached devices.

- Enter the **learning** keyword to enable MAC address learning from the destinations, which allows the switch to transmit traffic that is addressed to devices attached to the destinations.

When configuring destinations with the **ingress** and **learning** keywords, note the following:

- Configure the destinations for Layer 2 switching. See the “[How to Configure LAN Interfaces for Layer 2 Switching](#)” section on page 21-5.
- If the destination is a trunk and the attached device transmits untagged traffic back to the switch, use 802.1Q trunking with the native VLAN configured to accept the traffic from the attached device.
- Do not configure the destinations with Layer 3 addresses. Use a VLAN interface to route traffic to and from devices attached to destinations.
- Destinations are held in the down state. To route the traffic to and from attached devices, configure an additional active Layer 2 port in the VLAN to keep the VLAN interface up.

This example shows how to configure an ERSPAN destination session to send ERSPAN ID 101 traffic arriving at IP address 10.1.1.1 to Gigabit Ethernet port 2/1:

```
Tqwgvt*eqphki+% "oqpkvqt "uguukqp" 5 "v{rg"gturcp/fguvkpcvkqp"
Tqwgvt*eqphki/gturcp/fuv+% "fguvkpcvkqp"kpvgthceg"ikicdkvgvjgtpgv"413"
Tqwgvt*eqphki/gturcp/fuv+% "uqwteq"
Tqwgvt*eqphki/gturcp/fuv/ute+% "kr"cfftgau"32030303"
Tqwgvt*eqphki/gturcp/fuv/ute+% "gturcp/kf"323"
```

For additional examples, see the “[Configuration Examples for SPAN](#)” section on page 56-31.

## Configuring Source VLAN Filtering in Global Configuration Mode



Note

- To configure source VLAN filtering in SPAN configuration mode, see these sections:
  - [Configuring Local SPAN \(SPAN Configuration Mode\)](#), page 56-16
  - [Configuring RSPAN Source Sessions in SPAN Configuration Mode](#), page 56-21
  - [Configuring ERSPAN](#), page 56-26
- Source VLAN filtering reduces the amount of traffic that is sent from SPAN sources to SPAN destinations.

Source VLAN filtering monitors specific VLANs when the source is a trunk port.

To configure source VLAN filtering when the local SPAN or RSPAN source is a trunk port, perform this task:

|        | Command                                                                                                                  | Purpose                                                                               |
|--------|--------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Step 1 | Tqwgvt% "eqphkiwtg"vgtokpcn                                                                                              | Enters global configuration mode.                                                     |
| Step 2 | Tqwgvt*eqphki+% "oqpkvqt "uguukqp" uguukqpapwodgt" hknvgt "ukpingaxncp" ~ "xncpankuv" ~ "xncpatcpig" ~ "okzgfxnncpankuv" | Configures source VLAN filtering when the local SPAN or RSPAN source is a trunk port. |

- *single\_vlan* is the ID number of a single VLAN.
- *vlan\_list* is *single\_vlan* , *single\_vlan* , *single\_vlan* ...

- *vlan\_range* is *first\_vlan\_ID* - *last\_vlan\_ID*.
- *mixed\_vlan\_list* is, in any order, *single\_vlan* , *vlan\_range* , ...

This example shows how to monitor VLANs 1 through 5 and VLAN 9 when the source is a trunk port:

```
Tqwwgt*eqphki+% "oqpkvqt" "uguukqp" 4 "hknvgt" "xnep" 3 "/" 7 "." ; "
```

## Verifying the SPAN Configuration

To verify the configuration, enter the **show monitor session** command.

This example shows how to verify the configuration of session 2:

```
Tqwwgt% "ujqy" oqpkvqt "uguukqp" 4
Uguukqp 4
//////////
V{rg "<" Tgoqvg "Uqwt eg" Uguukqp

Uqwt eg "Rqtvu<
" " " "TZ" Qpn{ "<" " " " " " " " " Ik513
Fguv "TURCP" "XNCP" "<" " " " " ; 23
Tqwwgt%
```

This example shows how to display the full details of session 2:

```
Tqwwgt% "ujqy" oqpkvqt "uguukqp" 4 "fgvckn"
Uguukqp 4
//////////
V{rg "<" Tgoqvg "Uqwt eg" Uguukqp

Uqwt eg "Rqtvu<
" " " "TZ" Qpn{ "<" " " " " " " " " Ik313/5
" " " "VZ" Qpn{ "<" " " " " " " " " Pqpg
" " " "Dqvj<" " " " " " " " " " " " " " " Pqpg
Uqwt eg "XNCPu<
" " " "TZ" Qpn{ "<" " " " " " " " " Pqpg
" " " "VZ" Qpn{ "<" " " " " " " " " Pqpg
" " " "Dqvj<" " " " " " " " " " " " " " " Pqpg
Uqwt eg "TURCP" "XNCP" "<" " " " " " " " " Pqpg
Fguvkpcvkqp "Rqtvu<" " " " " " " " " Pqpg
Hknvgt "XNCPu<" " " " " " " " " Pqpg
Fguv "TURCP" "XNCP" "<" " " " " " " " " ; 23
```

## Configuration Examples for SPAN

This example shows the configuration of RSPAN source session 2:

```
Tqwwgt*eqphki+% "oqpkvqt" "uguukqp" 4 "uqwt eg" "kpvgt hceg" "ikicdkvgvjgtpgv" 313 "/" 5 "tz"
Tqwwgt*eqphki+% "oqpkvqt" "uguukqp" 4 "fguvkpcvkqp" "tgoqvg" "xnep" ; 23
```

This example shows how to clear the configuration for sessions 1 and 2:

```
Tqwwgt*eqphki+% "pq" oqpkvqt "uguukqp" "tcpig" 3/4 "
```

This example shows the configuration of an RSPAN source session with multiple sources:

```
Tqwwgt*eqphki+% "oqpkvqt" "uguukqp" 4 "uqwt eg" "kpvgt hceg" "ikicdkvgvjgtpgv" 7137 "." 915 "tz"
Tqwwgt*eqphki+% "oqpkvqt" "uguukqp" 4 "uqwt eg" "kpvgt hceg" "ikicdkvgvjgtpgv" 314 "vz"
Tqwwgt*eqphki+% "oqpkvqt" "uguukqp" 4 "uqwt eg" "kpvgt hceg" "rqt v/ejcppgn" 324 "
Tqwwgt*eqphki+% "oqpkvqt" "uguukqp" 4 "uqwt eg" "hknvgt" "xnep" 4 "/" 5 "
```

```
Tqwvgt*eqphki+% "oqpkvqt "uguukqp"4 "fguvkpcvkqp"tgoqvg"xncp";23"
```

This example shows how to remove sources for a session:

```
Tqwvgt*eqphki+% "pq"oqpkvqt "uguukqp"4 "uqwteg"kpvgthceg"ikicdkvgvjgtpgv"7137"."915"
```

This example shows how to remove options for sources for a session:

```
Tqwvgt*eqphki+% "pq"oqpkvqt "uguukqp"4 "uqwteg"kpvgthceg"ikicdkvgvjgtpgv"314"
```

```
Tqwvgt*eqphki+% "pq"oqpkvqt "uguukqp"4 "uqwteg"kpvgthceg"rqtv/ejcppgn"324"vz"
```

This example shows how to remove source VLAN filtering for a session:

```
Tqwvgt*eqphki+% "pq"oqpkvqt "uguukqp"4 "hknvgt"xncp"5"
```

This example shows the configuration of RSPAN destination session 8:

```
Tqwvgt*eqphki+% "oqpkvqt "uguukqp": "uqwteg"tgoqvg"xncp";23"
```

```
Tqwvgt*eqphki+% "oqpkvqt "uguukqp": "fguvkpcvkqp"kpvgthceg"ikicdkvgvjgtpgv"314"."415"
```

This example shows the configuration of ERSPAN source session 12:

```
oqpkvqt "uguukqp"34"v{rg"gturcp/uqwteg
"fguetkrvkqp"UQWTEGaUGUUKQPaHQTaXTHaITC[
"uqwteg"kpvgthceg"Ik:16:"tz
"fguvkpcvkqp
"gturcp/kf"342
"kr"cfftguu"320:0304
"qtkikp"kr"cfftguu"54030303
"xth"itc{
```

This example shows the configuration of ERSPAN destination session 12:

```
oqpkvqt "uguukqp"34"v{rg"gturcp/fguvkpcvkqp
"fguetkrvkqp"FGUVaUGUUKQPaHQTaXTHaITC[
"fguvkpcvkqp"kpvgthceg"Ik616:
"uqwteg
"gturcp/kf"342
"kr"cfftguu"320:0304
"xth"itc{
```

This example shows the configuration of ERSPAN source session 13:

```
oqpkvqt "uguukqp"35"v{rg"gturcp/uqwteg
"uqwteg"kpvgthceg"Ik813"vz
"fguvkpcvkqp
"gturcp/kf"352
"kr"cfftguu"320330303
"qtkikp"kr"cfftguu"54030303
```

This example shows the configuration of ERSPAN destination session 13:

```
oqpkvqt "uguukqp"35"v{rg"gturcp/fguvkpcvkqp
"fguvkpcvkqp"kpvgthceg"Ik813
"uqwteg
"gturcp/kf"352
"kr"cfftguu"320330303
```



#### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## SNMP IfIndex Persistence

---

- [Prerequisites for SNMP IfIndex Persistence, page 57-1](#)
- [Restrictions for SNMP IfIndex Persistence, page 57-1](#)
- [Information About SNMP IfIndex Persistence, page 57-2](#)
- [Default Settings for SNMP IfIndex Persistence, page 57-2](#)
- [How to Configure SNMP IfIndex Persistence, page 57-2](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
  - Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- 



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

---

## Prerequisites for SNMP IfIndex Persistence

None.

## Restrictions for SNMP IfIndex Persistence

None.

## Information About SNMP IfIndex Persistence

The SNMP ifIndex persistence feature provides an interface index (ifIndex) value that is retained and used when the switch reboots. The ifIndex value is a unique identifying number associated with a physical or logical interface.

There is no requirement in the relevant RFCs that the correspondence between particular ifIndex values and their interfaces be maintained when the switch reboots, but many applications (for example, device inventory, billing, and fault detection) require maintenance of this correspondence.

You can poll the switch at regular intervals to correlate the interfaces to the ifIndexes, but it is not practical to poll constantly. The SNMP ifIndex persistence feature provides permanent ifIndex values, which eliminates the need to poll interfaces.

The following definitions are based on RFC 2233, “The Interfaces Group MIB using SMIV2.” The following terms are values in the Interfaces MIB (IF-MIB):

- **ifIndex**—A unique number (greater than zero) that identifies each interface for SNMP identification of that interface.
- **ifName**—The text-based name of the interface, for example, “ethernet 3/1.”
- **ifDescr**—A description of the interface. Recommended information for this description includes the name of the manufacturer, the product name, and the version of the interface hardware and software.

## Default Settings for SNMP IfIndex Persistence

SNMP ifIndex persistence is disabled by default.

## How to Configure SNMP IfIndex Persistence

- [Enabling SNMP IfIndex Persistence Globally, page 57-2](#)
- [Enabling and Disabling SNMP IfIndex Persistence on Specific Interfaces, page 57-3](#)

### Enabling SNMP IfIndex Persistence Globally

To globally enable SNMP ifIndex persistence, perform this task:

| Command                                                  | Purpose                                    |
|----------------------------------------------------------|--------------------------------------------|
| <code>Tqwgvt*eqphki+% upor/ugtugt"khkpfgz"rgtukuv</code> | Globally enables SNMP ifIndex persistence. |

In the following example, SNMP ifIndex persistence is enabled for all interfaces:

```
tqwgvt*eqphki+% "upor/ugtugt"khkpfgz"rgtukuv
```



## Disabling SNMP IfIndex Persistence Globally

To globally disable SNMP ifIndex persistence after enabling it, perform this task:

| Command                                                       | Purpose                                     |
|---------------------------------------------------------------|---------------------------------------------|
| <code>Tqwvgt*eqphki+% "pq"upor/ugtugt "khkpfgz"rgtukuv</code> | Globally disables SNMP ifIndex persistence. |

In the following example, SNMP ifIndex persistence is disabled for all interfaces:

```
tqwvgt*eqphki+% "pq"upor/ugtugt "khkpfgz"rgtukuv
```

## Enabling and Disabling SNMP IfIndex Persistence on Specific Interfaces

To enable SNMP ifIndex persistence only on a specific interface, perform this task:

|        | Command                                                                                                                  | Purpose                                                      |
|--------|--------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "kpvgthceg" }xncp "vlan_ID;" ~"<br/>}type slot/port;" ~"}rqtv/ejcppgn" rqtvaejcppgnapwodgt;</code> | Selects an interface to configure.                           |
| Step 2 | <code>Tqwvgt*eqphki/kh+% upor "khkpfgz"rgtukuv</code>                                                                    | Enables SNMP ifIndex persistence on the specified interface. |
| Step 3 | <code>Tqwvgt*eqphki/kh+% gzkv</code>                                                                                     | Exits interface configuration mode.                          |



### Note

The **[no] snmp ifindex persistence** interface command cannot be used on subinterfaces. A command applied to an interface is automatically applied to all the subinterfaces associated with that interface.

In the following example, SNMP ifIndex persistence is enabled for Ethernet interface 3/1 only:

```
tqwvgt*eqphki+% "kpvgthceg"gvjgtpgv"513
tqwvgt*eqphki/kh+% "upor"khkpfgz"rgtukuv
tqwvgt*eqphki/kh+% "gzkv
```

In the following example, SNMP ifIndex persistence is disabled for Ethernet interface 3/1 only:

```
tqwvgt*eqphki+% "kpvgthceg"gvjgtpgv"513
tqwvgt*eqphki/kh+% "pq"upor"khkpfgz"rgtukuv
tqwvgt*eqphki/kh+% "gzkv
```

# Clearing SNMP IfIndex Persistence Configuration from a Specific Interface

To clear the interface-specific SNMP ifIndex persistence setting and configure the interface to use the global configuration setting, perform this task:

|        | Command                                                         | Purpose                                                                                                                                                           |
|--------|-----------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% kpvgt<h2>hceg" type slot/port</h2></code> | Enters interface configuration mode for the specified interface. Note that the syntax of the interface command will vary depending on the platform you are using. |
| Step 2 | <code>Tqwvgt*eqphki/kh+% upor"khkpfgz"engct</code>              | Clears any interface-specific SNMP ifIndex persistence configuration for the specified interface and returns to the global configuration setting.                 |
| Step 3 | <code>Tqwvgt*eqphki/kh+% gzkv</code>                            | Exits interface configuration mode.                                                                                                                               |

In the following example, any previous setting for SNMP ifIndex persistence on Ethernet interface 3/1 is removed from the configuration. If SNMP ifIndex persistence is globally enabled, SNMP ifIndex persistence will be enabled for Ethernet interface 3/1. If SNMP ifIndex persistence is globally disabled, SNMP ifIndex persistence will be disabled for Ethernet interface 3/1.

```
tqwvgt*eqphki+%"kpvgt

hceg"gvjgtpgv"513

tqwvgt*eqphki/kh+%"upor"khkpfgz"engct
tqwvgt*eqphki/kh+%"gzkv
```



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:  
[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)  
[Participate in the Technical Documentation Ideas forum](#)



## Top-N Reports

---

- [Prerequisites for Top-N Reports, page 58-1](#)
- [Restrictions for Top-N Reports, page 58-1](#)
- [Information About Top-N Reports, page 58-2](#)
- [Default Settings for Top-N Reports, page 58-3](#)
- [How to Use Top-N Reports, page 58-3](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)


[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for Top-N Reports

None.

## Restrictions for Top-N Reports

None.



## Top-N Reports

- [Top-N Reports Overview, page 58-2](#)
- [Top-N Reports Operation, page 58-2](#)

### Top-N Reports Overview

Top-N reports allows you to collect and analyze data for each physical port on a switch. When Top-N reports start, they obtain statistics from the appropriate hardware counters and then go into sleep mode for a user-specified interval. When the interval ends, the reports obtain the current statistics from the same hardware counters, compare the current statistics from the earlier statistics, and store the difference. The statistics for each port are sorted by one of the statistic types that are listed in [Table 58-1](#).

**Table 58-1**      *Valid Top-N Statistic Types*

| Statistic Type | Definition                               |
|----------------|------------------------------------------|
| broadcast      | Number of input/output broadcast packets |
| bytes          | Number of input/output bytes             |
| errors         | Number of input errors                   |
| multicast      | Number of input/output multicast packets |
| overflow       | Number of buffer overflows               |
| packets        | Number of input/output packets           |
| utilization    | Utilization                              |



**Note**

When calculating the port utilization, Top-N reports bundles the Tx and Rx lines into the same counter and also looks at the full-duplex bandwidth when calculating the percentage of utilization. For example, a Gigabit Ethernet port would be 2000-Mbps full duplex.

### Top-N Reports Operation

When you enter the **collect top** command, processing begins and the system prompt reappears immediately. When processing completes, the reports are not displayed immediately on the screen; the reports are saved for later viewing. The Top-N reports notify you when the reports are complete by sending a syslog message to the screen.

To view the completed reports, enter the **show top counters interface report** command. Only completed reports are displayed. For reports that are not completed, there is a short description of the process information.

To terminate a Top-N reports process, enter the **clear top counters interface report** command. Pressing **Ctrl-C** does not terminate Top-N reports processes. The completed reports remain available for viewing until you remove them by entering the **clear top counters interface report {all | report\_num}** command.

## Default Settings for Top-N Reports

None.

## How to Use Top-N Reports

- [Enabling Top-N Reports Creation, page 58-3](#)
- [Displaying Top-N Reports, page 58-4](#)
- [Clearing Top-N Reports, page 58-5](#)

## Enabling Top-N Reports Creation

To enable Top-N reports creation, perform this task:

| Command                                                                                                                                                                | Purpose                         |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|
| <code>Tqvwgt% "eqnngv"vqr"] pwodgtaqharqtvu_ "eqwpvgtu" kpvgtthceg" } v{rg" ~ "cnn" ~ "nc{gt/4" ~ "nc{gt/5;" ] uqtv/d{ " uvcvkuvkeav{rg_" ] kpvgtxcn" ugeqpfu_"</code> | Enables Top-N reports creation. |

When enabling Top-N reports creation, note the following information:

- You can specify the number of busiest ports for which to create reports (the default is 20).
- You can specify the statistic type by which ports are determined to be the busiest (the default is utilization). The supported values for *statistic\_type* are **broadcast**, **bytes**, **errors**, **multicast**, **overflow**, **packets**, and **utilization**.
- You can specify the interval over which statistics are collected (range: 0 through 999; the default is 30 seconds).
- Except for a utilization report (configured with the **sort-by utilization** keywords), you can specify an interval of zero to create a report that displays the current counter values instead of a report that displays the difference between the start-of-interval counter values and the end-of-interval counter values.

This example shows how to enable Top-N reports creation for an interval of 76 seconds for the four ports with the highest utilization:

```
Tqvwgt% "eqnngv"vqr"6"eqwpvgtu" kpvgtthceg" cnn"uqtv/d{ "vvknk| cvkqp" kpvgtxcn"98"
VqrP"eqnngv kqp" uvctvgf0
```



## Clearing Top-N Reports

To clear Top-N reports, perform one of these tasks:

| Command                                                                   | Purpose                                                            |
|---------------------------------------------------------------------------|--------------------------------------------------------------------|
| <code>Tqwwgt% "engct"vqr"eqwpgvtu"kpvgthceg"tgrqtv"</code>                | Clears all the Top-N reports that have a status of done.           |
| <code>Tqwwgt% "engct"vqr"eqwpgvtu"kpvgthceg"tgrqtv"] tgrqtvapwo_ "</code> | Clears Top-N report number <i>report_num</i> regardless of status. |

This example shows how to remove all reports that have a status of done:

```
Tqwwgt% "engct"vqr"eqwpgvtu"kpvgthceg"tgrqtv"
26<22<28<"'VQRPaEQWPVGtu/7/FGNGVGF<"VqrP"tgrqtv"3"fngvgf"d{"vjg"eqpuqng
26<22<28<"'VQRPaEQWPVGtu/7/FGNGVGF<"VqrP"tgrqtv"4"fngvgf"d{"vjg"eqpuqng
26<22<28<"'VQRPaEQWPVGtu/7/FGNGVGF<"VqrP"tgrqtv"5"fngvgf"d{"vjg"eqpuqng
26<22<28<"'VQRPaEQWPVGtu/7/FGNGVGF<"VqrP"tgrqtv"6"fngvgf"d{"vjg"eqpuqng
```

This example shows how to remove a report number 4:

```
Tqwwgt% "engct"vqr"eqwpgvtu"kpvgthceg"tgrqtv"6"
26<74<34<"'VQRPaEQWPVGtu/7/MKNGGF<"VqrP"tgrqtv"6"mkngf"d{"vjg"eqpuqng
```



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)







## Layer 2 Traceroute Utility

---

- [Prerequisites for the Layer 2 Traceroute Utility, page 59-1](#)
- [Restrictions for the Layer 2 Traceroute Utility, page 59-1](#)
- [Information About the Layer 2 Traceroute Utility, page 59-2](#)
- [How to Use the Layer 2 Traceroute Utility, page 59-3](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
  - Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- 



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

---

## Prerequisites for the Layer 2 Traceroute Utility

None.

## Restrictions for the Layer 2 Traceroute Utility

- Cisco Discovery Protocol (CDP) must be enabled on all the devices in the network. For the Layer 2 traceroute utility to function properly, do not disable CDP. If any devices in the Layer 2 path are transparent to CDP, the Layer 2 traceroute utility cannot identify these devices on the path.

- A switch is defined as reachable from another switch when you can test connectivity by using the **ping** privileged EXEC command. All devices in the Layer 2 path must be mutually reachable. To verify the ping connectivity you need to use the IP address that the CDP advertises on its Layer 2 interfaces.
- The maximum number of hops identified in the path is ten.
- You can enter the **traceroute mac** or the **traceroute mac ip** privileged EXEC command on a switch that is not in the Layer 2 path from the source device to the destination device. All devices in the path must be reachable from this switch.
- The **traceroute mac** command output shows the Layer 2 path only when the specified source and destination MAC addresses belong to the same VLAN. If you specify source and destination MAC addresses that belong to different VLANs, the Layer 2 path is not identified, and an error message appears.
- If you specify a multicast source or destination MAC address, the path is not identified, and an error message appears.
- If the source or destination MAC address belongs to multiple VLANs, you must specify the VLAN to which both the source and destination MAC addresses belong. If the VLAN is not specified, the path is not identified, and an error message appears.
- The **traceroute mac ip** command output shows the Layer 2 path when the specified source and destination IP addresses belong to the same subnet. When you specify the IP addresses, the Layer 2 traceroute utility uses the Address Resolution Protocol (ARP) to associate the IP addresses with the corresponding MAC addresses and the VLAN IDs.
  - If an ARP entry exists for the specified IP address, the Layer 2 traceroute utility uses the associated MAC address and identifies the Layer 2 path.
  - If an ARP entry does not exist, the Layer 2 traceroute utility sends an ARP query and tries to resolve the IP address. If the IP address is not resolved, the path is not identified, and an error message appears.
- When multiple devices are attached to one port through hubs (for example, multiple CDP neighbors are detected on a port), the Layer 2 traceroute utility terminates at that hop and displays an error message.
- The Layer 2 traceroute utility is not supported in Token Ring VLANs.
- Layer 2 traceroute opens a listening socket on the User Datagram Protocol (UDP) port 2228 that can be accessed remotely with any IPv4 address, and does not require any authentication. This UDP socket allows to read VLAN information, links, presence of particular MAC addresses, and CDP neighbor information, from the device. This information can be used to eventually build a complete picture of the Layer 2 network topology.
- Layer 2 traceroute is enabled by default and can be disabled by running the **no l2 traceroute** command in global configuration mode. To re-enable Layer 2 traceroute, use the **l2 traceroute** command in global configuration mode.

## Information About the Layer 2 Traceroute Utility

The Layer 2 traceroute utility identifies the Layer 2 path that a packet takes from a source device to a destination device. Layer 2 traceroute supports only unicast source and destination MAC addresses. The utility determines the path by using the MAC address tables of the switches in the path. When the Layer 2 traceroute utility detects a device in the path that does not support Layer 2 traceroute, it continues to send Layer 2 trace queries and allows them to time out.

The Layer 2 traceroute utility can only identify the path from the source device to the destination device. The utility cannot identify the path that a packet takes from the source host to the source device or from the destination device to the destination host.

## How to Use the Layer 2 Traceroute Utility

To display the Layer 2 path that a packet takes from a source device to a destination device, perform one of these tasks in privileged EXEC mode:

| Command                                                                                                                                                                                                | Purpose                                                                     |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
| <pre>Tqwwgt%<b>"vtcegtqwg"oce"</b> ]kpvgt<b>hceg</b> type interface_number source_mac_address" ]kpvgt<b>hceg</b> type interface_number_ fguvkpcvkqpaoceacfftguu"]<b>xncp</b>"xncpakf_" ]fgvckn_"</pre> | Uses MAC addresses to trace the path that packets take through the network. |
| <pre>Tqwwgt%<b>"vtcegtqwg"oce"kr"</b>}uqwt<b>egakracfftguu</b>"~" uqwt<b>egajquvpcog</b>"}fguvkpcvkqpakracfftguu"~" fguvkpcvkqpajquvpcog"}]fgvckn_"</pre>                                              | Uses IP addresses to trace the path that packets take through the network.  |

These examples show how to use the **traceroute mac** and **traceroute mac ip** commands to display the physical path a packet takes through the network to reach its destination:

```
Tqwwgt%"vtcegtqwg"oce"22220242302823"22220242302423
```

```
Uqwteg"22220242302823"hgwpf"qp"eqp8]YU/E4;72I/46/GK_"*4040808+
eqp8"*4040808+<Hc213"?@Hc215
eqp7"*****4040707*****+<""Hc215"?@Ik213
eqp3"*****4040303*****+<""Ik213"?@Ik214
eqp4"*****4040404*****+<""Ik214"?@Hc213
Fguvkpcvkqp"22220242302423"hgwpf"qp"eqp4]YU/E5772/46_"*4040404+
Nc{gt"4"vtceg"eqorngvgf
Tqwwgt%
Tqwwgt%"vtcegtqwg"oce"22230222202426"22230222202526"fgvckn"
Uqwteg"22230222202426"hgwpf"qp"XC[W]YU/E872;_"*40303032+
3"XC[W"1"YU/E872;"1"40303032"<
*****Ik813"]hwnn."32220_"?@"Rq322"]cwvq."cwvq_
4"RCPK"1"YU/E872;"1"40303034"<
*****Rq322"]cwvq."cwvq_"?@"Rq332"]cwvq."cwvq_
5"DWOK"1"YU/E872;"1"40303035"<
*****Rq332"]cwvq."cwvq_"?@"Rq342"]cwvq."cwvq_
6"CIPK"1"YU/E872;"1"40303033"<
*****Rq342"]cwvq."cwvq_"?@"Ik:134"]hwnn."32220_"Fguvkpcvkqp"22230222202526"
hgwpf"qp"CIPK]YU/E872;_"*40303033+Nc{gt"4"vtceg"eqorngvgf0
Tqwwgt%
```



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





## Mini Protocol Analyzer

---

- [Prerequisites for the Mini Protocol Analyzer, page 60-1](#)
- [Restrictions for the Mini Protocol Analyzer, page 60-1](#)
- [Information About the Mini Protocol Analyzer, page 60-2](#)
- [How to Configure the Mini Protocol Analyzer, page 60-2](#)
- [Configuration Examples for the Mini Protocol Analyzer, page 60-7](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
  - Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- 



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

---

## Prerequisites for the Mini Protocol Analyzer

None.

## Restrictions for the Mini Protocol Analyzer

The PFC and any DFCs provide hardware support for analysis of IPv4 traffic. Analysis of low volume IPv6 traffic is supported in software.

## Information About the Mini Protocol Analyzer

The Mini Protocol Analyzer captures network traffic from a SPAN session and stores the captured packets in a local memory buffer. Using the provided filtering options, you can limit the captured packets to:

- Packets from selected VLANs, ACLs, or MAC addresses.
- Packets of a specific EtherType.
- Packets of a specified packet size.

You can start and stop the capture using immediate commands, or you can schedule the capture to begin at a specified date and time.

The captured data can be displayed on the console, stored to a local file system, or exported to an external server using normal file transfer protocols. The format of the captured file is libpcap, which is supported by many packet analysis and sniffer programs. Details of this format can be found at the following URL:

<http://www.tcpdump.org/>

By default, only the first 68 bytes of each packet are captured.

## How to Configure the Mini Protocol Analyzer

- [Configuring a Capture Session, page 60-2](#)
- [Filtering the Packets to be Captured, page 60-4](#)
- [Starting and Stopping a Capture, page 60-5](#)
- [Displaying and Exporting the Capture Buffer, page 60-7](#)

### Configuring a Capture Session

To configure a capture session using the Mini Protocol Analyzer, perform this task:

|        | Command                                                                        | Purpose                                                                                                                                                                                                               |
|--------|--------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt%<b>"eqphkiwtg"</b>vgtokpcn</code>                                 | Enters global configuration mode.                                                                                                                                                                                     |
| Step 2 | <code>Tqwvgt*eqphki+%<b>"]pq_ "oqpkvgt "uguukqp"pwodgt"v{rg"ecrvwtg</b></code> | Configures a SPAN session number with packets directed to the processor for capture. Enters capture session configuration mode. The session number range is 1 to 80.<br><br>The <b>no</b> prefix removes the session. |
| Step 3 | <code>Tqwvgt*eqphki/oqp/ecrvwtg+%<b>"dwhhgt/uk g" dwhauk/g"</b></code>         | (Optional) Sets the size in KB of the capture buffer. The range is 32-65535 KB; the default is 2048 KB.                                                                                                               |

|        | Command                                                                                                                                                                                                                                                                                                                    | Purpose                                                                                                                                                                                                      |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 4 | <code>Tqwvgt*eqphki/oqp/ecrvwtg+%<b>f</b>guetkrvkqp"<br/>uguukqpafguetkrvkqp"</code>                                                                                                                                                                                                                                       | (Optional) Describes the capture session. The description can be up to 240 characters and cannot contain special characters. If the description contains spaces, it must be enclosed in quotation marks(""). |
| Step 5 | <code>Tqwvgt*eqphki/oqp/ecrvwtg+%<b>t</b>cvg/<b>n</b>kokv"pps</code>                                                                                                                                                                                                                                                       | (Optional) Sets a limit on the number of packets per second ( <i>pps</i> ) that can be captured. The range is 10-100000 packets per seconds; the default is 10000 packets per second.                        |
| Step 6 | <code>Tqwvgt*eqphki/oqp/ecrvwtg+%<b>u</b>qwteg"}<b>k</b>pvgthceg"<br/>}ukpingakpvgthceg"~"kpvgthcegankuv"~"kpvgthcegatcpig"~"<br/>okzgfakpvgthcegankuv;"~"<b>r</b>qtv/<b>e</b>jcppgn"ejcppgnakf;"~"<br/>}<b>x</b>ncp"}vlan_ID"~"xncpankuv"~"xncpatcpig"~"<br/>okzgfxnncpankuv;]<b>t</b>z"~"<b>v</b>z"~"<b>d</b>qvj_</code> | Associates the capture session with source ports or VLANs, and selects the traffic direction to be monitored. The default traffic direction is both.                                                         |
| Step 7 | <code>Tqwvgt*eqphki/oqp/ecrvwtg+%<b>g</b>zkv</code>                                                                                                                                                                                                                                                                        | Exits the capture session configuration mode.                                                                                                                                                                |

- Only one capture session is supported; multiple simultaneous capture sessions cannot be configured.
- The **source interface** command argument is either a single interface, or a range of interfaces described by two interface numbers (the lesser one first, separated by a dash), or a comma-separated list of interfaces and ranges.



**Note** When configuring a source interface list, you must enter a space before and after the comma. When configuring a source interface range, you must enter a space before and after the dash.

- The **source vlan** command argument is either a single VLAN number from 1 through 4094 (except reserved VLANs), or a range of VLANs described by two VLAN numbers (the lesser one first, separated by a dash), or a list of VLANs and ranges.



**Note** When configuring a source VLAN list, do not enter a space before or after the comma. When configuring a source VLAN range, do not enter a space before or after the dash. Note that this requirement differs from the requirement for source interface lists and ranges.

- Data capture does not begin when the capture session is configured. The capture is started by the **monitor capture start** or **monitor capture schedule** command described in the [“Starting and Stopping a Capture”](#) section on page 60-5.
- Although the capture buffer is linear by default, it can be made circular as a run-time option in the **monitor capture start** or **monitor capture schedule** command.
- When no hardware rate limit registers are available, the capture session is disabled.
- The source VLAN cannot be changed if a VLAN filter is configured. Remove any VLAN filters before changing the source VLAN.

## Filtering the Packets to be Captured

To filter the packets to be captured by the Mini Protocol Analyzer, perform this task in capture session configuration mode:

|        | Command                                                                                                              | Purpose                                                                                                                                                                                                                                                                                                      |
|--------|----------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki/oqp/ecrvwtg+%<b>"hknvgt"ceeguu/itqwr</b>"<br/>}cenapwodgt"~"cenapcog;</code>                     | (Optional) Captures only packets from the specified ACL.                                                                                                                                                                                                                                                     |
| Step 2 | <code>Tqvwgt*eqphki/oqp/ecrvwtg+%<b>"hknvgt"xncp"</b>}vlan_ID"<br/>~"xncpankuv"~"xncpatcpig"~"okzgfxncpankuv;</code> | (Optional) Captures only packets from the specified source VLAN or VLANs.                                                                                                                                                                                                                                    |
| Step 3 | <code>Tqvwgt*eqphki/oqp/ecrvwtg+%<b>"hknvgt"gvjgtv{rg" type</b></code>                                               | (Optional) Captures only packets of the specified EtherType. The <i>type</i> can be specified in decimal, hex, or octal.<br><br><b>Note</b> Configure <i>type</i> as <b>0x86dd</b> to filter IPv6 traffic. Analysis of low volume IPv6 traffic is supported in software.                                     |
| Step 4 | <code>Tqvwgt*eqphki/oqp/ecrvwtg+%<b>"hknvgt"ngpivj"min_len</b><br/>]oczangp_</code>                                  | (Optional) Captures only packets whose size is between <i>min_len</i> and <i>max_len</i> , inclusive. If <i>max_len</i> is not specified, only packets of exactly size <i>min_len</i> will be captured. The range for <i>min_len</i> is 0 to 9216 bytes and the range for <i>max_len</i> is 1 to 9216 bytes. |
| Step 5 | <code>Tqvwgt*eqphki/oqp/ecrvwtg+%<b>"hknvgt"oce/cfftguu"</b><br/>mac_addr</code>                                     | (Optional) Captures only packets from the specified MAC address.                                                                                                                                                                                                                                             |
| Step 6 | <code>Tqvwgt*eqphki/oqp/ecrvwtg+%<b>"gpf"</b></code>                                                                 | Exits the configuration mode.                                                                                                                                                                                                                                                                                |

- Several options are provided for filtering the packets to be captured. Filtering by ACL and VLAN is performed in hardware before any rate-limiting is applied; all other filters are executed in software. Software filtering can decrease the capture rate.
- The **filter vlan** argument is either a single VLAN number from 1 through 4094 (except reserved VLANs), or a range of VLANs described by two VLAN numbers (the lesser one first, separated by a dash), or a list of VLANs and ranges.



### Note

When configuring a filter VLAN list, you must enter a space before and after the comma. When configuring a filter VLAN range, you must enter a space before and after the dash. Note that this requirement differs from the requirement for source VLAN lists and ranges described in the preceding section.

- To enter an EtherType as a decimal number, enter the number (1 to 65535) with no leading zero. To enter a hexadecimal number, precede four hexadecimal characters with the prefix 0x. To enter an octal number, enter numeric digits (0 to 7) with a leading zero. For example, the 802.1Q EtherType can be entered in decimal notation as 33024, in hexadecimal as 0x8100, or in octal as 0100400.



- Enter a MAC address as three 2-byte values in dotted hexadecimal format. An example is 0123.4567.89ab.
- The **no** keyword removes the filter.



**Note** After removing a VLAN filter using the **no** keyword, you must exit configuration mode, reenter the capture configuration mode, and issue the **source vlan** command before making other capture configuration changes.

- When you configure a VLAN filter, the capture source or destination must be a VLAN. When you configure a port filter, the capture source or destination must be a port.

## Starting and Stopping a Capture

The commands to start and stop a capture are not stored as configuration settings. These commands are executed from the console in EXEC mode. You can start a capture immediately or you can set a future date and time for the capture to start. The capture ends when one of the following conditions occurs:

- A stop or clear command is entered from the console.
- The capture buffer becomes full, unless it is configured as a circular buffer.
- The optionally specified number of seconds has elapsed.
- The optionally specified number of packets has been captured.

When the capture stops, the SPAN session is ended and no further capture session packets are forwarded to the processor.

When starting a packet capture, you have the option to override some configured settings.

To start, stop, or cancel a capture, perform this task:

|        | Command                                                                                                                                                                                                        | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt% "oqpkvgt"ecrvwtg"]dwhhgt"uk g" dwhauk/g_]ngpivj"<br/>ecrangp_]nkpqct "~"ektewnct_]hknvgt"cenapwodgt"~"<br/>cenapcog_]uvctv"]hgt"count *rcemgvu"~"ugeqpfu;_ "~"<br/>uejgfwng"cv"time date;</code> | <p>Starts a capture with optional run-time configuration changes. The capture can start immediately or it can start at a specified time and date.</p> <ul style="list-style-type: none"> <li>The <b>buffer size</b> option overrides the configured or default capture buffer size.</li> <li>The <b>length</b> option determines the number of bytes that will be captured from each packet. The range for <i>cap_len</i> is 0 to 9216 bytes; the default is 68 bytes. A value of 0 causes the entire packet to be captured.</li> <li>The <b>circular</b> option specifies that the capture buffer will overwrite earlier entries once it fills. The <b>linear</b> option specifies that the capture will stop when the buffer fills. The default is <b>linear</b>.</li> <li>The <b>filter</b> option applies the specified ACL.</li> <li>The <b>for</b> option specifies that the capture will end after the specified number of seconds has elapsed or the specified number of packets has been captured.</li> </ul> |
| Step 2 | <code>Tqwvgt% "oqpkvgt"ecrvwtg"uvqr</code>                                                                                                                                                                     | Stops the capture.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Step 3 | <code>Tqwvgt% "oqpkvgt"ecrvwtg engct"]hknvgt_</code>                                                                                                                                                           | Clears any run-time configuration settings, clears any pending scheduled capture, and clears the capture buffer. The <b>filter</b> option clears only the run-time filter settings.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

When using these commands, note the following information:

- The format for *time* and *date* is hh:mm:ss dd mmm yyyy. The hour is specified in 24-hour notation, and the month is specified by a three-letter abbreviation. For example, to set a capture starting time of 7:30 pm on October 31, 2006, use the notation 19:30:00 31 oct 2006. The time zone is GMT.
- When you specify a capture filter ACL in the start command, the new ACL will not override any configured ACLs. The new ACL will execute in software.

## Displaying and Exporting the Capture Buffer

To display the captured packets or information about the capture session, or to export the captured packets for analysis, perform this task:

|        | Command                                                                                                                                             | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt% "ujqy"oqpkvqt "ecrvwtg</code>                                                                                                         | Displays the capture session configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Step 2 | <code>Tqwvgt% "ujqy"oqpkvqt "ecrvwtg"uvcvwu</code>                                                                                                  | Displays the capture session state, mode, and packet statistics.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Step 3 | <code>Tqwvgt% "ujqy"oqpkvqt "ecrvwtg"dwhhgt"] uvctv"] gpf__<br/>] fgvckn_] fwor"] pgytcr"] fworangpivj__<br/>] cen" cenapwodgt"~" cenapcog__</code> | Displays the capture buffer contents. <ul style="list-style-type: none"> <li>The <b>start</b> and <b>end</b> parameters specify packet number indices in the capture buffer. When a <b>start</b> index is specified with no <b>end</b> index, only the single packet at the <b>start</b> index is displayed. When both the <b>start</b> and <b>end</b> indices are specified, all packets between these indices are displayed. The range is 1 to 4294967295.</li> <li>The <b>detail</b> option adds expanded and formatted protocol and envelope information for each packet, including the packet arrival time.</li> <li>The <b>dump</b> option displays the hexadecimal contents of the packet. If <b>nowrap</b> is specified with <b>dump_length</b>, one line of hexadecimal packet content of <b>dump_length</b> characters will be displayed for each packet. If <b>dump_length</b> is not specified, a line of 72 characters will be displayed. The range of <b>dump_length</b> is 14 to 256.</li> <li>The <b>acl</b> option causes the display of only those packets that match the specified ACL.</li> </ul> |
| Step 4 | <code>Tqwvgt% "ujqy"oqpkvqt "ecrvwtg"dwhhgt"] uvctv"] gpf__ "dtkgh"<br/>] cen" cenapwodgt"~" cenapcog__</code>                                      | Displays only packet header information.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Step 5 | <code>Tqwvgt% "oqpkvqt "ecrvwtg"gzrqtv"dwhhgt" url</code>                                                                                           | Copies the contents of the capture buffer to the specified file system or file transfer mechanism.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

## Configuration Examples for the Mini Protocol Analyzer

- [General Configuration Examples, page 60-8](#)
- [Filtering Configuration Examples, page 60-9](#)
- [Operation Examples, page 60-10](#)
- [Display Examples, page 60-10](#)

## General Configuration Examples

This example shows how to minimally configure the Mini Protocol Analyzer:

```
Tqwvgt%
Tqwvgt%"eqphkiwtg"vgtokpcn
Gpvg"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0" "Gpf"ykvj"EPVN1\0
Tqwvgt*eqphki+%"oqpkvqt"uguukqp"3"v{rg"ecrvwtg
Tqwvgt*eqphki/oqp/ecrvwtg+%"gpf
```

```
Tqwvgt%"ujqy"oqp"ecr
Ecrvwtg"kpuvcpeg"]3_"<
????????????????????
Ecrvwtg"Uguukqp"KF"<"3
Uguukqp"uvcvwu" "" ""<"wr
tcvg/nkokv"xcnwg" "" ""<"32222
tgfktgev"kpfgz" "" ""<"2z:29
dwhhgt/uk|g" "" "" ""<"42;9374
ecrvwtg"uvcvg" "" "" ""<"QHH
ecrvwtg"oqfg" "" "" ""<"Nkpgct
ecrvwtg"ngpivj" "" "" ""<"8:
```

```
Tqwvgt%
```

This example shows how to configure the buffer size, session description, and rate limit:

```
Tqwvgt%"eqphkiwtg"vgtokpcn
Gpvg"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0" "Gpf"ykvj"EPVN1\0
Tqwvgt*eqphki+%"oqpkvqt"uguukqp"3"v{rg"ecrvwtg
Tqwvgt*eqphki/oqp/ecrvwtg+%"dwhhgt/uk|g"62;8
Tqwvgt*eqphki/oqp/ecrvwtg+%"fguetkrvkqp" "Ecrvwtg"htqo"rqtvu."pq"hknvgtkpi0"
Tqwvgt*eqphki/oqp/ecrvwtg+%"tcvg/nkokv"42222
Tqwvgt*eqphki/oqp/ecrvwtg+%"gpf
Tqwvgt%"
Tqwvgt%"ujqy"oqpkvqt"ecrvwtg
Ecrvwtg"kpuvcpeg"]3_"<
????????????????????
Ecrvwtg"Uguukqp"KF"<"3
Uguukqp"uvcvwu" "" "" ""<"wr
tcvg/nkokv"xcnwg" "" ""<"42222
tgfktgev"kpfgz" "" "" ""<"2z:29
dwhhgt/uk|g" "" "" "" ""<"63;6526
ecrvwtg"uvcvg" "" "" "" ""<"QHH
ecrvwtg"oqfg" "" "" "" ""<"Nkpgct
ecrvwtg"ngpivj" "" "" "" ""<"8:

Tqwvgt%"
```

This example shows how to configure the source as a mixed list of ports:

```
Tqwvgt*eqphki/oqp/ecrvwtg+%"uqwteg"kpvgthceg"iki"513"/"5"."iki"517
```

This example shows how to configure the source as a mixed list of VLANs:

```
Tqwvgt*eqphki/oqp/ecrvwtg+%"uqwteg"xncp"345.456/467"
```

## Filtering Configuration Examples

This example shows how to configure for capturing packets with the following attributes:

- The packets belong to VLANs 123 or 234 through 245
- The packets are of 802.1Q EtherType (hexadecimal 0x8100, decimal 33024)
- The packet size is exactly 8192 bytes
- The source MAC address is 01:23:45:67:89:ab
- The packets conform to ACL number 99

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkgp0""Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%"oqpkvqt"uguukqp"3"v{rg"ecrvwtg
Tqvwgt*eqphki/oqp/ecrvwtg+%"uqwtg"xncp"345.456/467
Tqvwgt*eqphki/oqp/ecrvwtg+%"hknvgt"gvjgtv{rg"2z:322
Tqvwgt*eqphki/oqp/ecrvwtg+%"hknvgt"ngpivj":3;4
Tqvwgt*eqphki/oqp/ecrvwtg+%"hknvgt"oce/cfftguu"2345067890:;cd
Tqvwgt*eqphki/oqp/ecrvwtg+%"hknvgt"ceeguu/itqwr";;
Tqvwgt*eqphki/oqp/ecrvwtg+%"gpf
```

```
Tqvwgt%"ujqy"oqpkvqt"ecrvwtg
Ecrvwtg"kpucvpeg"]3_ "<
????????????????????
Ecrvwtg"Uguukqp"KF"<"3
Uguukqp"uvcvwu""""<"wr
tcvg/nkokv"xcnwg""""<"42222
tgfktgev"kpfgz""""<"2z9G29
Ecrvwtg"xncp""""<"323;
dwhhgt/uk|g""""<"63;6526
ecrvwtg"uvcvg""""<"QHH
ecrvwtg"oqfg""""<"Nkpgct
ecrvwtg"ngpivj""""<"8:
Uy"Hknvgtu""""<
""""gvjgtv{rg""""<"55246
""""ute"oce""""<"2345067890:;cd
""Jy"cen""""<" ;;
```

```
Tqvwgt%"ujqy"oqpkvqt"uguukqp"3
Uguukqp"3
/////////
V{rg""""<"Ecrvwtg"Uguukqp
Fguetkrvkqp""""<"ecrvwtg"htqo"rgtvu
Uqwtg"XNCPu""""<
""""Dqvj""""<"345.456/467
Ecrvwtg"dwhhgt"uk|g""""<"62;8"MD
Ecrvwtg"tcvg/nkokv
""""xcnwg""""<"42222
Ecrvwtg"hknvgtu""""<"
""""gvjgtv{rg""""<"55246
""""ute"oce""""<"2345067890:;cd
""""cen""""<" ;;
```

```
Gitguu"URCP"Tgrnkecvkqp"Uvcvg<
Qrgtcvkqpcn"oqfg""""<"Egpvtcnk|gf
Eqphkiwtgf"oqfg""""<"Fkuvtkdwvgf"*fghcwnv+
```

```
Tqvwgt%
```

This example shows how to capture packets whose size is less than 128 bytes:

```
Tqwgvt*eqphki/opp/ecrvwtg+%"hknvgt"ngpivj"2"34:
```

This example shows how to capture packets whose size is more than 256 bytes:

```
Tqwgvt*eqphki/opp/ecrvwtg+%"hknvgt"ngpivj"478";438
```

## Operation Examples

This example shows how to start and stop a capture:

```
Tqwgvt%"oqpkvgt"ecrvwtg"uvctv
Tqwgvt%"oqpkvgt"ecrvwtg"uvqr
Tqwgvt%
```

This example shows how to start a capture to end after 60 seconds:

```
Tqwgvt%"oqpkvgt"ecrvwtg"uvctv"hgt"82"ugeqpfu
Tqwgvt%
```

This example shows how to start a capture at a future date and time:

```
Tqwgvt%"oqpkvgt"ecrvwtg"uejgfwng"cv"33<44<55"52"lwp"422:
ecrvwtg"yknn"uvctv"cv"<">33<44<55"WVE"Oqp"Lwp"52"422:@""chvgt"54687:47"ugeu
Tqwgvt%
```

This example shows how to start a capture with options to override the buffer size and to change to a circular buffer:

```
Tqwgvt%"oqpkvgt"ecrvwtg"dwhhgt"uk|g"87757"ektewnct"uvctv
Tqwgvt%
```

This example shows how to export the capture buffer to an external server and a local disk:

```
Tqwgvt%"oqpkvgt"ecrvwtg"gzrqtv"dwhhgt"vhvr<11ugt<11ugt1ecrvwtgahkng0ecr
Tqwgvt%"oqpkvgt"ecrvwtg"gzrqtv"dwhhgt"fkum3<ecrvwtgahkng0ecr
```

## Display Examples

- [Displaying the Configuration, page 60-10](#)
- [Displaying the Capture Session Status, page 60-11](#)
- [Displaying the Capture Buffer Contents, page 60-12](#)

### Displaying the Configuration

To display the capture session configuration, enter the **show monitor capture** command.

```
Tqwgvt%"ujqy"oqpkvgt"ecrvwtg
Ecrvwtg"kpuvcpeg"]3_"<
????????????????????
Ecrvwtg"Uguukqp"KF"<"3
Uguukqp"uvcvwu""""<"wr
tcvg/nkokv"xcnwg""""<"32222
tgfktgev"kpfgz""""<"2z:29
dwhhgt/uk|g""""""<"42;9374
ecrvwtg"uvcvg""""<"QHH
ecrvwtg"oqfg""""<"Nkpgct
```

```
ecrvwtg"ngpivj" "<"8:
```

This example shows how to display more details using the **show monitor session *n*** command:

```
Tqvwgt%"ujqy"oqpkvqt"uguukqp"3
Uguukqp"3
/////////
V{rg" "<"Ecrvwtg"Uguukqp
Uqwtg"Rqtvu" "<"
""""Dqvj" "<"Ik513/5.Ik517
Ecrvwtg"dwhhgt"uk|g" "<"54"MD
Ecrvwtg"hknvgtu" "<"Pqpg

Gitguu"URCP"Tgrnkecvkqp"Uvcvg<
Qrgtcvkqpcn"oqfg" "<"Egpvtcnk|gf
Eqphkiwtgf"oqfg" "<"Fkuvtkdwvgf"*fghcwnv+
```

This example shows how to display the full details using the **show monitor session *n* detail** command:

```
Tqvwgt%"ujqy"oqpkvqt"uguukqp"3"fgvckn
Uguukqp"3
/////////
V{rg" "<"Ecrvwtg"Uguukqp
Fguetkrvkqp" "<"/
Uqwtg"Rqtvu" "<"
""""TZ"Qpn{ " "<"Pqpg
""""VZ"Qpn{ " "<"Pqpg
""""Dqvj" "<"Ik513/5.Ik517
Uqwtg"XNCPu" "<"
""""TZ"Qpn{ " "<"Pqpg
""""VZ"Qpn{ " "<"Pqpg
""""Dqvj" "<"Pqpg
Uqwtg"URCP"XNCP" "<"Pqpg
Fguvkpcvkqp"Rqtvu" "<"Pqpg
Hknvgt"XNCPu" "<"Pqpg
Fguv"URCP"XNCP" "<"Pqpg
Uqwtg"KR"Cfftguu" "<"Pqpg
Uqwtg"KR"XTH" "<"Pqpg
Uqwtg"GTURCP"KF" "<"Pqpg
Fguvkpcvkqp"KR"Cfftguu" "<"Pqpg
Fguvkpcvkqp"KR"XTH" "<"Pqpg
Fguvkpcvkqp"GTURCP"KF" "<"Pqpg
Qtkikp"KR"Cfftguu" "<"Pqpg
KR"SQU"RTGE" "<"2
KR"VVN" "<"477
Ecrvwtg"fuvaerwakf" "<"3
Ecrvwtg"xncp" "<"2
Ecrvwtg"dwhhgt"uk|g" "<"54"MD
Ecrvwtg"tcvg/nkokv
""""""""""xcnwg" "<"32222
Ecrvwtg"hknvgtu" "<"Pqpg

Gitguu"URCP"Tgrnkecvkqp"Uvcvg<
Qrgtcvkqpcn"oqfg" "<"Egpvtcnk|gf
Eqphkiwtgf"oqfg" "<"Fkuvtkdwvgf"*fghcwnv+
```

## Displaying the Capture Session Status

To display the capture session status, enter the **show monitor capture status** command.

```
Tqvwgt%"ujqy"oqpkvqt"ecrvwtg"uvcvwu
ecrvwtg"uvcvg" "<"QP
```

```
ecrvwtg"oqfg"*****"<"Nkpgct
Pwodgt" "qh"rcemgvu
*****"tgegkxgf"<"475
*****"ftqrrgf"<"2
*****"ecrvwtgf"<" ;2
```

## Displaying the Capture Buffer Contents

To display the capture session contents, enter the **show monitor capture buffer** command. These examples show the resulting display using several options of this command:

Tqvwgt%"ujqy"oqpkvqt"ecrvwtg"dwhhgt"  
 "3""""KR<"u?320340207". "f?4460202032. "ngp"82  
 "4""""568""""23:20e4220222g"2234066f:07222""":EE"242929748H9  
 "5""""82""""23:20e42202222""22260e2; ;028e7""2248"64642522222  
 "6""""82""""hhhh0hhhh0hhhh"2234066f:07222""2:28"22232:22282  
 "7""""KR<"u?9020:6045". "f?446020207. "ngp"338  
 "8""""KR<"u?320340203". "f?4460202032. "ngp"82

```
Tqvwgt%"ujqy"oqpkvqt"ecrvwtg"dwhhgt"fgvckn"*****
"3*****Cttkxcn"vkog"<"2;<66<52"WVE"Htk"Pqx"39"4228
*****"Rcemgv"Ngpivj"<"96"."Ecrvwtg"Ngpivj"<"8:
*****"Gvjgtpgv"KK"<"232207g220222c"222:0c6e:0e25:""2:22"
*****"KR<"u?320340207".f?4460202032.".ngp"82.".rtqvq?::
"4*****Cttkxcn"vkog"<"2;<66<53"WVE"Htk"Pqx"39"4228
*****"Rcemgv"Ngpivj"<"568"."Ecrvwtg"Ngpivj"<"8:
568""23:20e4220222g"22334066f:07222""::EE"242929748H979685253
```

```
Tqvwgt%"ujqy"oqpkvqt"ecrvwtg"dwhhgt"fwor"
"3""""KR<"u?320340207". "f?4460202032. "ngp"82
2:285:32<"2322"7G22222C""""00`000
2:285:42<"222:C6E":E25:2:22"67E2225E"2222222""00&JB:00GB0>0000
2:285:52<"247:EF:H"2C2E2227"G222222C"2427GG8C""0Z000000b00000p1
2:285:62<"22222222"22222222"22222222"22222286""0000000000000000f
2:285:72<"2223222E"23222322"2222222H"2226""""00000000000000""
"4""""568""23:20e4220222g""2234066f:07222""":EE"242929748H979687942637
"5""""82""23:20e42202222""22260e2";028e7""2248"646425222222222:22222
"6""""82""""hhhh0hhhh0hhhh""2234066f:07222""2:28"22232:2228262223223466
"7""""KR<"u?9020:6045". "f?446020207. "ngp"338
2:28HED2<"2322"7G222227""""00`000
2:28HEE2<"2237E9F9"CE222:22"67E22296"2222222""00IY.000GB0v0000
2:28HEF2<"237;9F77"29227639"G2222227"2423224E"0[;W00V0b000000.
2:28HBG2<"26262626"22222222"22222224"22222232""0000000000000000
2:28HEH2<"677F:C32"HHHH22222222C3423"2222""""G 000000000000""
```

Tqvwgt% "ujqy"oqpkvqt "ecrvwtg"dwhtgt "fwor"pqytc  
 "3 "" "" "" "96 "" "" "" "232207g220222c" "222:0c6e:0e25: "" "2:22" 67E2225E222222  
 "4 "" "" "" "568 "" "" "" "23:20e4220222g" "2234066f:072222" ":.EE" 242929748H9796  
 "5 "" "" "" "82 "" "" "" "23:20e4220222" "22260e2; ;028e7" "2248" 64642522222222  
 "6 "" "" "" "82 "" "" "" "hhhhh0hhhh0hhhh" "2234066f:072222" "2:28" 22232:22282622



**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





## Restrictions for PFC QoS

---

- General Guidelines, page 61-2
- PFC and DFC Guidelines, page 61-4
- Class Map Command Restrictions, page 61-5
- Policy Map Class Command Restrictions, page 61-5
- Supported Granularity for CIR and PIR Rate Values, page 61-5
- Supported Granularity for CIR and PIR Token Bucket Sizes, page 61-6
- IP Precedence and DSCP Values, page 61-7



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:

[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)

- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## General Guidelines

- With Release 15.0(1)SY1 and later releases, you can increase the supported number of QoS TCAM entries:

|                                                                                                                                                                                                                                                                                                | TCAM Banks | QoS TCAM Entries |             |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|------------------|-------------|
|                                                                                                                                                                                                                                                                                                |            | PFC4 Mode        | PFC4XL Mode |
| Release 15.0(1)SY <ul style="list-style-type: none"> <li>Not configurable in Release 15.0(1)SY.</li> <li>Default for 15.0(1)SY1 and later releases.</li> <li>Command in Release 15.0(1)SY1 and later releases:               <pre>rncvhtqto"jctfyctg"cen"tgugtxg"squ/dcpmu"3</pre> </li> </ul> | 1          | 16K              | 64K         |
| Release 15.0(1)SY1 and later releases. Command: <pre>rncvhtqto"jctfyctg"cen"tgugtxg"squ/dcpmu"4</pre>                                                                                                                                                                                          | 2          | 32K              | 128K        |

Changes to the supported number of QoS TCAM entries take effect after a reload. Enter the **show platform hardware acl global-config** command to display the QoS TCAM entry configuration:

```
Tqwvgt%"ujqy"rncvhtqto"jctfyctg"cen"inqdcn/eqphki"~"kpenwfg"]Dd_cpmu"
Tgugtxgf"SqU"Dcpmu<
"Ewttgpy"3"dcpmu
"Ncvguv"ugv"3"dcpmu
"Chvgt"pgzv"tgnqcf"3"dcpmu
Tqwvgt%
```

Enter the **show platform hardware pfc mode** command to display the PFC mode.

- PFC QoS supports IGMP, MLD, and PIM traffic.
- The **match ip precedence** and **match ip dscp** commands filter only IPv4 traffic.
- The **match precedence** and **match dscp** commands filter IPv4 and IPv6 traffic.
- The **set ip dscp** and **set ip precedence** commands are saved in the configuration file as **set dscp** and **set precedence** commands.
- PFC QoS supports the **set dscp** and **set precedence** policy map class commands for IPv4 and IPv6 traffic.
- The flowmask requirements of QoS, NetFlow, and NetFlow data export (NDE) might conflict, especially if you configure microflow policing.
- With egress ACL support for remarked DSCP and VACL capture both configured on an interface, VACL capture might capture two copies of each packet, and the second copy might be corrupt.
- You cannot configure egress ACL support for remarked DSCP on tunnel interfaces.
- Egress ACL support for remarked DSCP supports IP unicast traffic.
- Egress ACL support for remarked DSCP is not relevant to multicast traffic. PFC QoS applies ingress QoS changes to multicast traffic before applying [egress QoS](#).
- NetFlow and NetFlow data export (NDE) do not support interfaces where egress ACL support for remarked DSCP is configured.

- When egress ACL support for remarked DSCP is configured on any interface, you must configure an interface-specific flowmask to enable NetFlow and NDE support on interfaces where egress ACL support for remarked DSCP is not configured. Enter either the **platform flow ip interface-destination-source** or the **platform flow ip interface-full** global configuration mode command.
- Interface counters are not accurate on interfaces where egress ACL support for remarked DSCP is configured.
- You cannot apply microflow policing to traffic that has been permitted by egress ACL support for remarked DSCP.
- Traffic that has been permitted by egress ACL support for remarked DSCP cannot be tagged as MPLS traffic. (The traffic can be tagged as MPLS traffic on another network device.)
- When you apply both ingress policing and egress policing to the same traffic, both the input policy and the output policy must either mark down traffic or drop traffic. PFC QoS does not support ingress markdown with egress drop or ingress drop with egress markdown. (CSCea23571)
- If traffic is both aggregate and microflow policed, then the aggregate and microflow policers must both be in the same policy-map class and each must use the same **conform-action** and **exceed-action** keyword option: **drop**, **set-dscp-transmit**, **set-prec-transmit**, or **transmit**.
- You cannot configure PFC QoS features on tunnel interfaces.
- PFC QoS does not rewrite the payload ToS byte in tunnel traffic.
- PFC QoS filters only by ACLs, dscp values, or IP precedence values.
- For these commands, PFC QoS applies identical configuration to all LAN ports controlled by the same application-specific integrated circuit (ASIC):
  - **rcv-queue cos-map**
  - **wrr-queue cos-map**
- Except for WS-X6904-40G-2T, WS-X6908-10GE, WS-X6816-10T-2T, WS-X6716-10T, WS-X6816-10G-2T, WS-X6716-10GE, WS-X6704-10GE, WS-X6848-SFP-2T, WS-X6748-SFP, WS-X6824-SFP-2T, WS-X6724-SFP, WS-X6848-TX-2T, WS-X6748-GE-TX modules, PFC QoS applies identical configuration to all LAN ports controlled by the same application-specific integrated circuit (ASIC) for these commands:
  - **rcv-queue random-detect**
  - **rcv-queue queue-limit**
  - **wrr-queue queue-limit**
  - **wrr-queue bandwidth**
  - **priority-queue cos-map**
  - **wrr-queue threshold**
  - **rcv-queue threshold**
  - **wrr-queue random-detect**
  - **wrr-queue random-detect min-threshold**
  - **wrr-queue random-detect max-threshold**
- Configure these commands only on physical ports. Do not configure these commands on logical interfaces:
  - **priority-queue cos-map**
  - **wrr-queue cos-map**
  - **wrr-queue random-detect**
  - **wrr-queue random-detect max-threshold**
  - **wrr-queue random-detect min-threshold**

- **wrr-queue threshold**
- **wrr-queue queue-limit**
- **wrr-queue bandwidth**
- **rcv-queue cos-map**
- **rcv-queue bandwidth**
- **rcv-queue random-detect**
- **rcv-queue random-detect max-threshold**
- **rcv-queue random-detect min-threshold**
- **rcv-queue queue-limit**
- **rcv-queue cos-map**
- **rcv-queue threshold**

**Note**

IP multicast switching using egress packet replication is not compatible with QoS. In some cases, egress replication can result in the incorrect COS or DSCP marking of packets. If you are using QoS and your switching modules are capable of egress replication, enter the **platform ip multicast replication-mode ingress** command to force ingress replication.

## PFC and DFC Guidelines

- The PFC and DFCs support QoS for IPv6 unicast and multicast traffic.
- To display information about IPv6 PFC QoS, enter the **show platform qos ipv6** command.
- The QoS features implemented in the port ASICs (queue architecture and dequeuing algorithms) support IPv4 and IPv6 traffic.
- The PFC and DFCs support IPv6 named extended ACLs and named standard ACLs.
- The PFC and DFCs support the **match protocol ipv6** command.
- With egress ACL support for remarked DSCP configured, the PFC and DFCs do not provide hardware-assistance for these features:
  - Cisco IOS reflexive ACLs
  - Network Address Translation (NAT)
- You cannot apply microflow policing to ARP traffic.
- The PFC and DFCs do not apply egress policing to traffic that is being bridged to the RP.
- The PFC and DFCs do not apply egress policing or egress DSCP mutation to multicast traffic from the RP.
- PFC QoS does not rewrite the ToS byte in bridged multicast traffic.
- The PFC and DFCs support up to 1022 aggregate policers, but some PFC QoS commands other than the **police** command will be included in this count. By default, any policy using a **set** or **trust** command will be included in the aggregate policer count. You can disable the addition of the **set** or **trust** commands to the aggregate policer count by entering the **no platform qos marking statistics** command, but you will then be unable to collect statistics for the classmaps associated with these commands. You can view the aggregate policer count in the QoS Policer Resources section of the output of the **show platform hardware capacity qos** command.

## Class Map Command Restrictions

- PFC QoS supports a single **match** command in **class-map match-all** class maps, except that the **match protocol** command can be configured in a class map with the **match dscp** or **match precedence** command.
- PFC QoS supports multiple **match** commands in **class-map match-any** class maps.



**Note** PFC QoS supports a maximum of 9 commands that match DSCP or IP precedence values in class maps and ACLs.

- PFC QoS does not support these class map commands:
  - **match classmap**
  - **match destination-address**
  - **match input-interface**
  - **match source-address**

## Policy Map Class Command Restrictions

PFC QoS does not support these policy map class commands:

- **set qos-group**
- **service-policy**

## Supported Granularity for CIR and PIR Rate Values

| CIR and PIR Rate Value Range       | Granularity        |
|------------------------------------|--------------------|
| 32768 to 2097152 (2 Mbs)           | 32768 (32 Kb)      |
| 2097153 to 4194304 (4 Mbs)         | 65536 (64 Kb)      |
| 4194305 to 8388608 (8 Mbs)         | 131072 (128 Kb)    |
| 8388609 to 16777216 (16 Mbs)       | 262144 (256 Kb)    |
| 16777217 to 33554432 (32 Mbs)      | 524288 (512 Kb)    |
| 33554433 to 67108864 (64 Mbs)      | 1048576 (1 Mb)     |
| 67108865 to 134217728 (128 Mbs)    | 2097152 (2 Mb)     |
| 134217729 to 268435456 (256 Mbs)   | 4194304 (4 Mb)     |
| 268435457 to 536870912 (512 Mbs)   | 8388608 (8 Mb)     |
| 536870913 to 1073741824 (1 Gbs)    | 16777216 (16 Mb)   |
| 1073741825 to 2147483648 (2 Gbs)   | 33554432 (32 Mb)   |
| 2147483649 to 4294967296 (4 Gbs)   | 67108864 (64 Mb)   |
| 4294967297 to 8589934592 (8 Gbs)   | 134217728 (128 Mb) |
| 8589934593 to 17179869184 (16 Gbs) | 268435456 (256 Mb) |

| CIR and PIR Rate Value Range        | Granularity          |
|-------------------------------------|----------------------|
| 17179869185 to 34359738368 (32 Gbs) | 536870912 (512 Mb)   |
| 34359738369 to 68719476736 (64 Gbs) | 1073741824 (1024 Mb) |

Within each range, PFC QoS programs the PFC with rate values that are multiples of the granularity values.

## Supported Granularity for CIR and PIR Token Bucket Sizes

| CIR and PIR Token Bucket Size Range | Granularity     |
|-------------------------------------|-----------------|
| 1 to 32768 (32 KB)                  | 1024 (1 KB)     |
| 32769 to 65536 (64 KB)              | 2048 (2 KB)     |
| 65537 to 131072 (128 KB)            | 4096 (4 KB)     |
| 131073 to 262144 (256 KB)           | 8196 (8 KB)     |
| 262145 to 524288 (512 KB)           | 16392 (16 KB)   |
| 524289 to 1048576 (1 MB)            | 32768 (32 KB)   |
| 1048577 to 2097152 (2 MB)           | 65536 (64 KB)   |
| 2097153 to 4194304 (4 MB)           | 131072 (128 KB) |
| 4194305 to 8388608 (8 MB)           | 262144 (256 KB) |
| 8388609 to 16777216 (16 MB)         | 524288 (512 KB) |
| 16777217 to 33554432 (32 MB)        | 1048576 (1 MB)  |

Within each range, PFC QoS programs the PFC with token bucket sizes that are multiples of the granularity values.



# IP Precedence and DSCP Values

| 3-bit IP<br>Precedence | 6 most significant bits of<br>ToS |   |   |   |   |   | 6-bit<br>DSCP |
|------------------------|-----------------------------------|---|---|---|---|---|---------------|
|                        | 8                                 | 7 | 6 | 5 | 4 | 3 |               |
| 0                      | 0                                 | 0 | 0 | 0 | 0 | 0 | 0             |
|                        | 0                                 | 0 | 0 | 0 | 0 | 1 | 1             |
|                        | 0                                 | 0 | 0 | 0 | 1 | 0 | 2             |
|                        | 0                                 | 0 | 0 | 0 | 1 | 1 | 3             |
|                        | 0                                 | 0 | 0 | 1 | 0 | 0 | 4             |
|                        | 0                                 | 0 | 0 | 1 | 0 | 1 | 5             |
|                        | 0                                 | 0 | 0 | 1 | 1 | 0 | 6             |
|                        | 0                                 | 0 | 0 | 1 | 1 | 1 | 7             |
| 1                      | 0                                 | 0 | 1 | 0 | 0 | 0 | 8             |
|                        | 0                                 | 0 | 1 | 0 | 0 | 1 | 9             |
|                        | 0                                 | 0 | 1 | 0 | 1 | 0 | 10            |
|                        | 0                                 | 0 | 1 | 0 | 1 | 1 | 11            |
|                        | 0                                 | 0 | 1 | 1 | 0 | 0 | 12            |
|                        | 0                                 | 0 | 1 | 1 | 0 | 1 | 13            |
|                        | 0                                 | 0 | 1 | 1 | 1 | 0 | 14            |
|                        | 0                                 | 0 | 1 | 1 | 1 | 1 | 15            |
| 2                      | 0                                 | 1 | 0 | 0 | 0 | 0 | 16            |
|                        | 0                                 | 1 | 0 | 0 | 0 | 1 | 17            |
|                        | 0                                 | 1 | 0 | 0 | 1 | 0 | 18            |
|                        | 0                                 | 1 | 0 | 0 | 1 | 1 | 19            |
|                        | 0                                 | 1 | 0 | 1 | 0 | 0 | 20            |
|                        | 0                                 | 1 | 0 | 1 | 0 | 1 | 21            |
|                        | 0                                 | 1 | 0 | 1 | 1 | 0 | 22            |
|                        | 0                                 | 1 | 0 | 1 | 1 | 1 | 23            |
| 3                      | 0                                 | 1 | 1 | 0 | 0 | 0 | 24            |
|                        | 0                                 | 1 | 1 | 0 | 0 | 1 | 25            |
|                        | 0                                 | 1 | 1 | 0 | 1 | 0 | 26            |
|                        | 0                                 | 1 | 1 | 0 | 1 | 1 | 27            |
|                        | 0                                 | 1 | 1 | 1 | 0 | 0 | 28            |
|                        | 0                                 | 1 | 1 | 1 | 0 | 1 | 29            |
|                        | 0                                 | 1 | 1 | 1 | 1 | 0 | 30            |
|                        | 0                                 | 1 | 1 | 1 | 1 | 1 | 31            |

| 3-bit IP<br>Precedence | 6 most significant bits of<br>ToS |   |   |   |   |   | 6-bit<br>DSCP |
|------------------------|-----------------------------------|---|---|---|---|---|---------------|
|                        | 8                                 | 7 | 6 | 5 | 4 | 3 |               |
| 4                      | 1                                 | 0 | 0 | 0 | 0 | 0 | 32            |
|                        | 1                                 | 0 | 0 | 0 | 0 | 1 | 33            |
|                        | 1                                 | 0 | 0 | 0 | 1 | 0 | 34            |
|                        | 1                                 | 0 | 0 | 0 | 1 | 1 | 35            |
|                        | 1                                 | 0 | 0 | 1 | 0 | 0 | 36            |
|                        | 1                                 | 0 | 0 | 1 | 0 | 1 | 37            |
|                        | 1                                 | 0 | 0 | 1 | 1 | 0 | 38            |
|                        | 1                                 | 0 | 0 | 1 | 1 | 1 | 39            |
| 5                      | 1                                 | 0 | 1 | 0 | 0 | 0 | 40            |
|                        | 1                                 | 0 | 1 | 0 | 0 | 1 | 41            |
|                        | 1                                 | 0 | 1 | 0 | 1 | 0 | 42            |
|                        | 1                                 | 0 | 1 | 0 | 1 | 1 | 43            |
|                        | 1                                 | 0 | 1 | 1 | 0 | 0 | 44            |
|                        | 1                                 | 0 | 1 | 1 | 0 | 1 | 45            |
|                        | 1                                 | 0 | 1 | 1 | 1 | 0 | 46            |
|                        | 1                                 | 0 | 1 | 1 | 1 | 1 | 47            |
| 6                      | 1                                 | 1 | 0 | 0 | 0 | 0 | 48            |
|                        | 1                                 | 1 | 0 | 0 | 0 | 1 | 49            |
|                        | 1                                 | 1 | 0 | 0 | 1 | 0 | 50            |
|                        | 1                                 | 1 | 0 | 0 | 1 | 1 | 51            |
|                        | 1                                 | 1 | 0 | 1 | 0 | 0 | 52            |
|                        | 1                                 | 1 | 0 | 1 | 0 | 1 | 53            |
|                        | 1                                 | 1 | 0 | 1 | 1 | 0 | 54            |
|                        | 1                                 | 1 | 0 | 1 | 1 | 1 | 55            |
| 7                      | 1                                 | 1 | 1 | 0 | 0 | 0 | 56            |
|                        | 1                                 | 1 | 1 | 0 | 0 | 1 | 57            |
|                        | 1                                 | 1 | 1 | 0 | 1 | 0 | 58            |
|                        | 1                                 | 1 | 1 | 0 | 1 | 1 | 59            |
|                        | 1                                 | 1 | 1 | 1 | 0 | 0 | 60            |
|                        | 1                                 | 1 | 1 | 1 | 0 | 1 | 61            |
|                        | 1                                 | 1 | 1 | 1 | 1 | 0 | 62            |
|                        | 1                                 | 1 | 1 | 1 | 1 | 1 | 63            |


**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

Participate in the [Technical Documentation Ideas forum](#)





## PFC QoS Overview

This chapter provides an overview of quality of service (QoS) as implemented on the Policy Feature Card (PFC) and Distributed Forwarding Cards (DFCs) in Cisco IOS Release 15.4SY. The term “PFC QoS” refers to hardware accelerated QoS. PFC QoS is implemented on various switch components in addition to the PFC and any DFCs.



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- For information about AutoQoS, see [Chapter 66, “AutoQoS.”](#)
- For information about QoS and MPLS, see [Chapter 67, “MPLS QoS.”](#)
- QoS in Cisco IOS Release 15.4SY (PFC QoS) uses some Cisco IOS modular QoS CLI (MQC). Because PFC QoS is implemented in hardware, it supports only a subset of the MQC syntax.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)  
[Participate in the Technical Documentation Ideas forum](#)

QoS makes network performance more predictable and bandwidth utilization more effective. Without QoS, networks operate on a *best-effort* delivery basis, which means that all traffic has equal priority and an equal chance of being delivered in a timely manner. When congestion occurs, all traffic has an equal chance of being dropped. QoS minimizes the chance that priority traffic would be dropped.

PFC QoS has these capabilities:

- Classification
- Marking
- Policing

- Congestion avoidance
- Mutation

You can configure two types of policies:

- Policies that define any combination of egress DSCP mutation, egress EXP mutation, classification, marking, and policing.
- Policies that define queueing.

Queueing configuration and classification, marking, and policing configuration are all optional.

Queueing configuration and classification, marking, and policing configuration have no common parameters or commands.

You configure QoS policies with the following commands:

- **class-map**—Defines a traffic class based on packet-matching criteria. Class maps are referenced in policy maps.
- **table-map**—Defines mapping from one set of traffic field values to another set of traffic fields values. Table maps are referenced in policy maps. Not used in queueing policies.
- **policy-map**—Defines or uses any combination of the following:
  - Class maps for classification
  - Table maps for marking and mutation
  - Policy trust mode
  - Policing
  - Queueing (cannot be combined with classification, marking, trust mode, or policing)
- **service-policy**—Applies policies to interfaces.

These chapters describe QoS:

- [Restrictions for PFC QoS, page 61-1](#)
- [Classification, Marking, and Policing, page 63-1](#)
- [Policy-Based Queueing, page 64-1](#)
- [QoS Global and Interface Options, page 65-1](#)



**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



# Classification, Marking, and Policing

- [Information About Classification, Marking, and Policing Policies](#), page 63-1
- [How to Configure Classification, Marking, and Policing Policies](#), page 63-7



## Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Information About Classification, Marking, and Policing Policies

- [Classification, Marking, and Policing Policy Overview](#), page 63-1
- [Traffic Classification](#), page 63-2
- [Traffic Marking](#), page 63-3
- [Information about Policing](#), page 63-4

## Classification, Marking, and Policing Policy Overview

The classification, marking, and policing configuration is defined by the policies attached to an interface. Classification, marking, and policing are unaffected by any QoS commands configured on ingress interfaces or by queueing policies.

## Traffic Classification

Traffic classification allows the network to recognize traffic as it falls into classes that you have configured. Network traffic must be classified to apply specific QoS to it.

Classification can be inclusive (for example, all of the traffic in a Layer 2 VLAN or all of the traffic passing through an interface) or classification can be very specific (for example, you can use a class map with **match** commands that recognize specific aspects of the traffic).

You can classify and apply QoS (for example, marking) and then, on another interface or network device, classify again based on the marked value and apply other QoS.

The PFC and any DFCs supports a single **match** command in **class-map match-all** class maps, except that the **match protocol** command can be configured in a class map with the **match dscp** or **match precedence** command.

The PFC and any DFCs supports multiple **match** commands in **class-map match-any** class maps.



### Note

PFC QoS supports a maximum of 9 commands that match DSCP or IP precedence values in class maps and ACLs.

Class maps can use the **match** commands listed in [Table 63-1](#) to configure a traffic class that is based on the match criteria.

**Table 63-1** Traffic Classification Class Map match Commands and Match Criteria

| match Commands                                                                                                                                          | Direction | Match Criteria                                                                                                             |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----------------------------------------------------------------------------------------------------------------------------|
| <b>match access-group</b> { <i>access_list_number</i>   <b>name</b> <i>access_list_name</i> }                                                           | Both      | Access control list (ACL).<br><br><b>Note</b> Use ACLs to match the following:<br>—CoS value<br>—VLAN ID<br>—Packet length |
| <b>match any</b>                                                                                                                                        | Both      | Any match criteria.                                                                                                        |
| <b>match cos</b>                                                                                                                                        | Ingress   | CoS value.                                                                                                                 |
| <b>match discard-class</b>                                                                                                                              | Both      | Discard class value.                                                                                                       |
| <b>match dscp</b><br><br><b>Note</b> The <b>match protocol</b> command can be configured in a class map with the <b>match dscp</b> command.             | Both      | DSCP value.                                                                                                                |
| <b>match l2 miss</b>                                                                                                                                    | Ingress   | Layer 2 traffic flooded in a VLAN because it is addressed to a currently unlearned MAC-Layer destination address.          |
| <b>match mpls experimental topmost</b>                                                                                                                  | Both      | MPLS EXP value in the topmost label.                                                                                       |
| <b>match precedence</b><br><br><b>Note</b> The <b>match protocol</b> command can be configured in a class map with the <b>match precedence</b> command. | Both      | IP precedence values.                                                                                                      |

Table 63-1 Traffic Classification Class Map match Commands and Match Criteria (continued)

| match Commands                                                                                                                                | Direction | Match Criteria |
|-----------------------------------------------------------------------------------------------------------------------------------------------|-----------|----------------|
| <b>match protocol</b> {arp   ip   ipv6}                                                                                                       | Both      | Protocol.      |
| <b>Note</b> The <b>match protocol</b> command can be configured in a class map with the <b>match dscp</b> or <b>match precedence</b> command. |           |                |
| <b>match qos-group</b>                                                                                                                        | Both      | QoS group ID.  |

The PFC and any DFCs supports these ACL types for use with the **match access group** command:

| Protocol  | Numbered ACLs                   | Extended ACLs                      | Named ACLs |
|-----------|---------------------------------|------------------------------------|------------|
| IPv4      | Yes:<br>1 to 99<br>1300 to 1999 | Yes:<br>100 to 199<br>2000 to 2699 | Yes        |
| IPv6      | Not applicable                  | Yes (named)                        | Yes        |
| MAC Layer | Not applicable                  | Not applicable                     | Yes        |
| ARP       | Not applicable                  | Not applicable                     | Yes        |

## Traffic Marking



### Note

Policing can also mark traffic.

Marking network traffic allows you to set or modify the attributes for a specific class of traffic, which allows class-based QoS features to recognize traffic classes based on the marking. There are two traffic marking methods:

- You can apply a configured value with a policy-map **set** command. [Table 63-2](#) lists the available policy-map **set** commands and the corresponding attribute.

Table 63-2 Configured-Value Policy-Map Commands

| set Commands                                  | Traffic Attribute                                                                                | Ingress ? | Egress ? |
|-----------------------------------------------|--------------------------------------------------------------------------------------------------|-----------|----------|
| <b>set cos</b> <i>cos_value</i>               | Layer 2 CoS value                                                                                | Y         | Y        |
| <b>set dscp</b> <i>dscp_value</i>             | Layer 3 DSCP value                                                                               | Y         | Y        |
| <b>set precedence</b> <i>precedence_value</i> | Layer 3 IP precedence value                                                                      | Y         | Y        |
| <b>set dscp tunnel</b> <i>dscp_value</i>      | Layer 3 DSCP value in the tunnel header of a Generic Routing Encapsulation (GRE) tunneled packet | Y         | Y        |
| <b>set discard-class</b> <i>discard_value</i> | Discard-class value                                                                              | Y         | Y        |
| <b>set qos-group</b> <i>group_id</i>          | QoS group ID                                                                                     | Y         | Y        |

Table 63-2 Configured-Value Policy-Map Commands (continued)

| set Commands                                             | Traffic Attribute                                          | Ingress? | Egress? |
|----------------------------------------------------------|------------------------------------------------------------|----------|---------|
| <b>set mpls experimental imposition</b> <i>exp_value</i> | MPLS experimental (EXP) field on all imposed label entries | Y        | Y       |
| <b>set mpls experimental topmost</b> <i>exp_value</i>    | MPLS experimental (EXP) field on all topmost label entries | Y        | Y       |

- You can apply a map to received values with a policy-map **set** command. [Table 63-3](#) lists the available policy-map **set** commands and the corresponding attribute.

Table 63-3 Mapped-Value Policy-Map Commands

| set Commands               | Map Name                   | Traffic Attribute  | Ingress? | Egress? |
|----------------------------|----------------------------|--------------------|----------|---------|
| <b>set dscp cos</b>        | <b>dscp-cos-map</b>        | Layer 3 DSCP value | Y        | N       |
| <b>set dscp precedence</b> | <b>dscp-precedence-map</b> | Layer 3 DSCP value | Y        | N       |

## Information about Policing

- [Overview of Policing, page 63-4](#)
- [Per-Interface Policers, page 63-5](#)
- [Aggregate Policers, page 63-5](#)
- [Microflow Policers, page 63-6](#)

## Overview of Policing

You can configure policers to do the following:

- Mark traffic
- Limit bandwidth utilization and mark traffic

Policers can be applied to ingress and egress interfaces. Ingress policing is applied first, followed by egress policing.

Policing can rate limit incoming and outgoing traffic so that it adheres to the traffic forwarding rules defined by the QoS configuration. Sometimes these configured rules for how traffic should be forwarded through the system are referred to as a contract. If the traffic does not adhere to this contract, it is marked down to a lower DSCP value or dropped.

Policing does not buffer out-of-profile packets. As a result, policing does not affect transmission delay. In contrast, traffic shaping works by buffering out-of-profile traffic, which moderates traffic bursts. (PFC QoS does not support shaping.)

The PFC and DFCs support ingress and egress PFC QoS, which includes ingress and egress policing. Policers act on ingress traffic per-port or per-VLAN. For egress traffic, the policers act per-VLAN only.

Policing uses the Layer 2 frame size. You specify the bandwidth utilization limit as a committed information rate (CIR). You can also specify a higher peak information rate (PIR). Packets that exceed a rate are “out of profile” or “nonconforming.”



In each policer, you specify if out-of-profile packets are to be dropped or to have a new DSCP value applied to them (applying a new DSCP value is called “markdown”). Because out-of-profile packets do not retain their original priority, they are not counted as part of the bandwidth consumed by in-profile packets.

If you configure a PIR, the PIR out-of-profile action cannot be less severe than the CIR out-of-profile action. For example, if the CIR out-of-profile action is to mark down the traffic, then the PIR out-of-profile action cannot be to transmit the traffic.

For all policers, PFC QoS uses a configurable global table that maps the internal DSCP value to a marked-down DSCP value. When markdown occurs, PFC QoS gets the marked-down DSCP value from the table. You cannot specify marked-down DSCP values in individual policers.

**Note**

- By default, the markdown table is configured so that no markdown occurs: the marked-down DSCP values are equal to the original DSCP values. To enable markdown, configure the table appropriately for your network.
- When you apply both ingress policing and egress policing to the same traffic, both the input policy and the output policy must either mark down traffic or drop traffic. PFC QoS does not support ingress markdown with egress drop or ingress drop with egress markdown.

## Per-Interface Policers

PFC QoS applies the bandwidth limits specified in a per-interface policer to matched traffic. For example, if you configure a per-interface policer to allow 1 Mbps for all matched TFTP traffic, it limits the TFTP traffic to 1 Mbps.

You define per-interface policers in a policy map class with the **police** command. If you attach per-interface policers to multiple ingress ports, each one polices the matched traffic on each ingress port separately.

## Aggregate Policers

- [Aggregate Policer Overview, page 63-5](#)
- [Distributed Aggregate Policers, page 63-5](#)
- [Nondistributed Aggregate Policers, page 63-6](#)

### Aggregate Policer Overview

PFC QoS applies the bandwidth limits specified in an aggregate policer cumulatively to all flows in matched traffic. For example, if you configure an aggregate policer to allow 1 Mbps for all TFTP traffic flows on VLAN 1 and VLAN 3, it limits the TFTP traffic for all flows combined on VLAN 1 and VLAN 3 to 1 Mbps.

You create named aggregate policers with the **platform qos aggregate-policer** command. If you attach a named aggregate policer to multiple ingress ports, it polices the matched traffic from all the ingress ports to which it is attached.

You can configure up to 1,023 aggregate policers; the configured aggregate policers can be applied to interfaces to configure up to 16,384 policer instances.

## Distributed Aggregate Policers

When distributed aggregate policing is enabled, aggregate policers synchronize policing on interfaces supported by different DFC-equipped switching modules or the PFC. Distributed aggregate policing applies to the first 4,096 aggregate policer instances of these types:

- Aggregate policers applied to VLAN, tunnel, or port channel interfaces.
- Shared aggregate policers.
- Aggregate policers in egress policies.

With distributed aggregate policing enabled, aggregate policers in excess of the hardware-supported capacity function as nondistributed aggregate policers.

## Nondistributed Aggregate Policers

Nondistributed aggregate policing works independently on each DFC-equipped switching module and independently on the PFC, which supports any non-DFC-equipped switching modules. Aggregate policing does not combine flow statistics from different DFC-equipped switching modules. You can display aggregate policing statistics for each DFC-equipped switching module and for the PFC and any non-DFC-equipped switching modules supported by the PFC.

Each PFC or DFC polices independently, which might affect QoS features being applied to traffic that is distributed across the PFC and any DFCs. Examples of these QoS features are:

- Policers applied to a port channel interface.
- Policers applied to a switched virtual interface.
- Egress policers applied to either a Layer 3 interface or an SVI.

Policers affected by this restriction deliver an aggregate rate that is the sum of all the independent policing rates.

## Microflow Policers

PFC QoS applies the bandwidth limit specified in a microflow policer separately to each flow in matched traffic. For example, if you configure a microflow policer to limit the TFTP traffic to 1 Mbps on VLAN 1 and VLAN 3, then 1 Mbps is allowed for each flow in VLAN 1 and 1 Mbps for each flow in VLAN 3. In other words, if there are three flows in VLAN 1 and four flows in VLAN 3, the microflow policer allows each of these flows 1 Mbps.

You can configure PFC QoS to apply the bandwidth limits in a microflow policer as follows:

- You can create microflow policers with up to 127 different rate and burst parameter combinations.
- You create microflow policers in a policy map class with the **police flow** command.
- You can configure a microflow policer to use only source addresses, which applies the microflow policer to all traffic from a source address regardless of the destination addresses.
- You can configure a microflow policer to use only destination addresses, which applies the microflow policer to all traffic to a destination address regardless of the source addresses.

- For MAC-Layer microflow policing, PFC QoS considers MAC-Layer traffic with the same protocol and the same source and destination MAC-Layer addresses to be part of the same flow, including traffic with different EtherTypes. You can configure MAC ACLs to filter IPX traffic.
- You cannot apply microflow policing to ARP traffic.
- Release 15.1(1)SY1 and later releases support Egress Microflow Destination-Only Policing. [Egress policing is per-VLAN](#), applied on either a Layer 3 interface or an SVI. With releases earlier than Release 15.1(1)SY1, policies attached with the **output** keyword do not support microflow policing.

You can include both an aggregate policer and a microflow policer in each policy map class to police a flow based on both its own bandwidth utilization and on its bandwidth utilization combined with that of other flows.

**Note**

If traffic is both aggregate and microflow policed, then the aggregate and microflow policers must both be in the same policy-map class and each must use the same **conform-action** and **exceed-action** keyword option: **drop**, **set-dscp-transmit**, **set-prec-transmit**, or **transmit**.

For example, you could create a microflow policer with a bandwidth limit suitable for individuals in a group, and you could create a named aggregate policer with bandwidth limits suitable for the group as a whole. You could include both policers in policy map classes that match the group's traffic. The combination would affect individual flows separately and the group aggregately.

For policy map classes that include both an aggregate and a microflow policer, PFC QoS responds to an out-of-profile status from either policer and, as specified by the policer, applies a new DSCP value or drops the packet. If both policers return an out-of-profile status, then if either policer specifies that the packet is to be dropped, it is dropped; otherwise, PFC QoS applies a marked-down DSCP value.

## How to Configure Classification, Marking, and Policing Policies

- [Enabling Distributed Aggregate Policing, page 63-7](#)
- [Configuring a Class Map, page 63-8](#)
- [Configuring a Policy Map, page 63-9](#)
- [Attaching a Policy Map to an Interface, page 63-17](#)
- [Configuring Dynamic Per-Session Attachment of a Policy Map, page 63-19](#)

## Enabling Distributed Aggregate Policing

To enable distributed aggregate policing, perform this task:

| Command                                                                         | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwgvt*eqphki+% "rncvhqto"squ"rqnkeg"fkuvtkdwvgf"}uvtkev"~"nqqug;"</code> | <p>Enables distributed aggregate policing.</p> <ul style="list-style-type: none"> <li>The <b>strict</b> keyword prevents application of aggregate policers to interfaces that would exceed available hardware acceleration resources.</li> <li>The <b>loose</b> keyword allows application of aggregate policers as nondistributed to interfaces that would exceed available hardware acceleration resources.</li> </ul> |

This example shows how to enable strict distributed aggregate policing globally:

```
Tqwgvt*eqphki+% "rncvhqto"squ"rqnkeg"fkuvtkdwvgf"uvtkev"
Tqwgvt*eqphki+%
```

This example shows how to disable distributed aggregate policing globally:

```
Tqwgvt*eqphki+% "pq"rncvhqto"squ"rqnkeg"fkuvtkdwvgf"
Tqwgvt*eqphki+%
```

## Configuring a Class Map

- [Creating a Class Map, page 63-8](#)
- [Configuring Filtering in a Class Map, page 63-8](#)
- [Verifying Class Map Configuration, page 63-8](#)

### Creating a Class Map

To create a class map, perform this task:

| Command                                                                        | Purpose                                                                                                                     |
|--------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwgvt*eqphki+% "encuu/ocr"] ocvej/cnn"~"ocvej/cp{"_ "encuuapcog"</code> | <p>Creates a class map.</p> <p><b>Note</b> If you do not enter a <b>match</b> keyword, the default is <b>match-all</b>.</p> |

## Configuring Filtering in a Class Map

To configure filtering in a class map, enter match commands as described in [Table 63-1, “Traffic Classification Class Map match Commands and Match Criteria”](#).

## Verifying Class Map Configuration

To verify class map configuration, perform this task:

|        | Command                                           | Purpose                     |
|--------|---------------------------------------------------|-----------------------------|
| Step 1 | <code>Tqvwgt *eqphki/eocr+% "gpf"</code>          | Exits configuration mode.   |
| Step 2 | <code>Tqvwgt %"ujqy"encuu/ocr" encuuapcog"</code> | Verifies the configuration. |

This example shows how to create a class map named **ipp5** and how to configure filtering to match traffic with IP precedence 5:

```
Tqvwgt %"eqphkiwtg"vgtokpcn"
Gpvg "eqphkiwtcvkqp"eqoocpfu. "qpg"rgt "nkpq0" "Gpf"ykvj "EPVN1\0
Tqvwgt *eqphki+% "encuu/ocr"krr7"
Tqvwgt *eqphki/eocr+% "ocvej"kr"rtgegfgpeg"7"
Tqvwgt *eqphki/eocr+% "gpf"
```

This example shows how to verify the configuration:

```
Tqvwgt %"ujqy"encuu/ocr"krr7"
"Encuu"Ocr"ocvej/cnn"krr7" *kf"3+
" " "Ocvej"kr"rtgegfgpeg"7
```

## Configuring a Policy Map

- [Policy Map Overview, page 63-9](#)
- [Creating a Policy Map, page 63-9](#)
- [Policy Map Class Configuration Guidelines and Restrictions, page 63-9](#)
- [Creating a Policy Map Class and Configuring Filtering, page 63-9](#)
- [Configuring Policy Map Class Actions, page 63-10](#)
- [Verifying Policy Map Configuration, page 63-16](#)

## Policy Map Overview

Policy maps can contain one or more policy map classes, each with different policy map commands.

Configure a separate policy map class in the policy map for each type of traffic that an interface receives. Put all commands for each type of traffic in the same policy map class. PFC QoS does not attempt to apply commands from more than one policy map class to matched traffic.

## Creating a Policy Map

To create a policy map, perform this task:

| Command                                                | Purpose               |
|--------------------------------------------------------|-----------------------|
| <code>Tqvwgt*eqphki+% "rqnke{/ocr" rqnke{apcog"</code> | Creates a policy map. |

## Policy Map Class Configuration Guidelines and Restrictions

- PFC QoS does not support the **class class\_name destination-address**, **class class\_name input-interface**, **class class\_name qos-group**, and **class class\_name source-address** policy map commands.
- PFC QoS supports the **class default** policy map command.
- PFC QoS does not detect the use of unsupported commands until you attach a policy map to an interface.
- PFC QoS does not support multiple ACL matches per class.

## Creating a Policy Map Class and Configuring Filtering

To create a policy map class and configure it to filter with a class map, perform this task:

| Command                                               | Purpose                                                                             |
|-------------------------------------------------------|-------------------------------------------------------------------------------------|
| <code>Tqvwgt*eqphki/rocr+% "encuu" encuuapcog"</code> | Creates a policy map class and configures it to filter with a class map.            |
|                                                       | <b>Note</b> PFC QoS supports class maps that contain a single <b>match</b> command. |

## Configuring Policy Map Class Actions

- [Policy Map Class Action Restrictions, page 63-10](#)
- [Configuring Policy Map Class Marking, page 63-11](#)
- [Configuring the Policy Map Class Trust State, page 63-11](#)
- [Configuring Policy Map Class Policing, page 63-11](#)

### Policy Map Class Action Restrictions

- Policy maps can contain one or more policy map classes.
- Put all commands for each type of traffic in the same policy map class.
- PFC QoS only applies commands from one policy map class to traffic. After traffic has matched the filtering in one policy map class, QoS does not apply the filtering configured in other policy map classes.
- For hardware-switched traffic, PFC QoS does not support the **bandwidth**, **priority**, **queue-limit**, or **random-detect** policy map class commands. You can configure these commands because they can be used for software-switched traffic.

- PFC QoS does not support the **set qos-group** policy map class commands.
- PFC QoS supports the **set ip dscp** and **set ip precedence** policy map class commands for IPv4 traffic.
  - You can use the **set ip dscp** and **set ip precedence** commands on non-IP traffic to mark the internal DSCP value, which is the basis of the egress Layer 2 CoS value.
  - The **set ip dscp** and **set ip precedence** commands are saved in the configuration file as **set dscp** and **set precedence** commands.
- PFC QoS supports the **set dscp** and **set precedence** policy map class commands for IPv4 and IPv6 traffic.
- You cannot do all three of the following in a policy map class:
  - Mark traffic with the **set** commands
  - Configure the trust state
  - Configure policing

In a policy map class, you can either mark traffic with the **set** commands or do one or both of the following:

- Configure the trust state
- Configure policing



**Note** When configure policing, you can mark traffic with policing keywords.

## Configuring Policy Map Class Marking

PFC QoS supports policy map class marking for all traffic with **set** policy map class commands. To configure policy map class marking, perform this task:

| Command                                                                                             | Purpose                                                                                                  |
|-----------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| <code>Tqvwgt*eqphki/rocr/e+%"ugv"} fuer" fueraxcnwg" ~"<br/>rtgegfgpeg" krartgegfgpegaxcnwg;</code> | Configures the policy map class to mark matched traffic with the configured DSCP or IP precedence value. |

## Configuring the Policy Map Class Trust State



**Note** You cannot attach a policy map that configures a trust state with the **service-policy output** command.

To configure the policy map class trust state, perform this task:

| Command                                                                         | Purpose                                                                                                                                  |
|---------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqvwgt*eqphki/rocr/e+%"vtwuv"} equ" ~" fuer" ~"<br/>kr/rtgegfgpeg;</code> | Configures the policy map class trust state, which selects the value that PFC QoS uses as the source of the initial internal DSCP value. |

When configuring the policy map class trust state, note the following information:

- Enter the **no trust** command to use the trust state configured on the ingress port (this is the default).

- With the **cos** keyword, PFC QoS sets the internal DSCP value from received or ingress port CoS.
- With the **dscp** keyword, PFC QoS uses received DSCP.
- With the **ip-precedence** keyword, PFC QoS sets DSCP from received IP precedence.

## Configuring Policy Map Class Policing

- [Policy Map Class Policing Restrictions, page 63-12](#)
- [Using a Named Aggregate Policier, page 63-12](#)
- [Configuring a Per-Interface Policier, page 63-13](#)
- [Configuring a Per-Interface Microflow Policier, page 63-14](#)

### Policy Map Class Policing Restrictions

- PFC QoS does not support the **set-qos-transmit** policer keyword.
- PFC QoS does not support the **set-dscp-transmit** or **set-prec-transmit** keywords as arguments to the **exceed-action** keyword.
- PFC QoS does not detect the use of unsupported keywords until you attach a policy map to an interface.
- Policing with the **conform-action transmit** keywords sets the port trust state of matched traffic to trust DSCP or to the trust state configured by a **trust** command in the policy map class.

### Using a Named Aggregate Policier

To use a named aggregate policier, perform this task:

| Command                                                              | Purpose                                                                               |
|----------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| <code>Tqvwgt*eqphki/rocr/e+%"rqnkeg"ciitgicvg"ciitgicvgapcog"</code> | Configures the policy map class to use a previously defined named aggregate policier. |

- When distributed aggregate policing is enabled, note the following information:
  - Distributed aggregate policers synchronize policing on interfaces supported by different DFC-equipped switching modules or the PFC. Distributed aggregate policing applies to the first 4,096 aggregate policers of these types:
    - Aggregate policers applied to VLAN, tunnel, or port channel interfaces.
    - Shared aggregate policers.
    - Aggregate policers in egress policies.
  - Distributed aggregate policers in excess of the hardware-supported capacity function as nondistributed aggregate policers.



- When distributed aggregate policing is not enabled, note the following information:
  - Aggregate policing works independently on each DFC-equipped switching module and independently on the PFC, which supports any non-DFC-equipped switching modules. Aggregate policing does not combine flow statistics from different DFC-equipped switching modules. You can display aggregate policing statistics for each DFC-equipped switching module and for the PFC and any non-DFC-equipped switching modules supported by the PFC.
  - Each PFC or DFC polices independently, which might affect QoS features being applied to traffic that is distributed across the PFC and any DFCs. Examples of these QoS feature are:
    - Policers applied to a port channel interface.
    - Policers applied to a switched virtual interface.
    - Egress policers applied to either a Layer 3 interface or an SVI.
  - Policers affected by this restriction deliver an aggregate rate that is the sum of all the independent policing rates.

### Configuring a Per-Interface Policer

To configure a per-interface policer, perform this task:

| Command                                                                                                                                                                                                                                                                                                                                  | Purpose                                                                        |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------|
| <pre>Tqwgvt*eqphki/rocr/e+%"rqnkeg"bits_per_second normal_burst_bytes" ]oczkwoadwtuvad{vgu_"]rkt rgcmatcvgadru_"[]]eqphqto/cevkqp"}ftqr"~" ugv/fuer/vtcpuokv"dscp_value ~"ugv/rtge/vtcpuokv" ip_precedence_value ~"vtcpuokv_i_"gzeggf/cevkqp"}ftqr"~"rqnkegf/fuer" ~"vtcpuokv_i_"xkqncvg/cevkqp"}ftqr"~"rqnkegf/fuer"~"vtcpuokv_i_</pre> | Creates a per-interface policer and configures the policy-map class to use it. |

- When you apply both ingress policing and egress policing to the same traffic, both the input policy and the output policy must either mark down traffic or drop traffic. PFC QoS does not support ingress markdown with egress drop or ingress drop with egress markdown.
- Policing uses the Layer 2 frame size.
- See the “[Restrictions for PFC QoS](#)” section on page 61-1 for information about rate and burst size granularity.
- The valid range of values for the CIR *bits\_per\_second* parameter is as follows:
  - Minimum—32 kilobits per second, entered as 32000
  - Maximum—256 gigabits per second, entered as 256000000000
- The *normal\_burst\_bytes* parameter sets the CIR token bucket size.
- The *maximum\_burst\_bytes* parameter sets the PIR token bucket size.
- When configuring the size of a token bucket, note the following information:
  - Because the token bucket must be large enough to hold at least one frame, configure the token bucket size to be larger than the maximum size of the traffic being policed.
  - For TCP traffic, configure the token bucket size as a multiple of the TCP window size, with a minimum value at least twice as large as the maximum size of the traffic being policed.
  - The *maximum\_burst\_bytes* parameter must be set larger than the *normal\_burst\_bytes* parameter.
  - To sustain a specific rate, set the token bucket size to be at least the rate value divided by 2000.
  - The minimum token bucket size is 1 byte, entered as 1.

- The maximum token bucket size is 512 megabytes, entered as 512000000.
- The valid range of values for the **pir** *bits\_per\_second* parameter is as follows:
  - Minimum—32 kilobits per second, entered as 32000 (the value cannot be smaller than the CIR *bits\_per\_second* parameters)
  - Maximum—256 gigabits per second, entered as 256000000000
- (Optional) You can specify a conform action for matched in-profile traffic as follows:
  - The default conform action is **transmit**, which sets the policy map class trust state to *trust DSCP* unless the policy map class contains a **trust** command.
  - To set PFC QoS labels in untrusted traffic, you can enter the **set-dscp-transmit** keyword to mark matched untrusted traffic with a new DSCP value or enter the **set-prec-transmit** keyword to mark matched untrusted traffic with a new IP precedence value. The **set-dscp-transmit** and **set-prec-transmit** keywords are only supported for IP traffic. PFC QoS sets egress ToS and CoS from the configured value.
  - You can enter the **drop** keyword to drop all matched traffic.
  - Ensure that aggregate and microflow policers that are applied to the same traffic each specify the same conform-action behavior.
- (Optional) For traffic that exceeds the CIR, you can specify an exceed action as follows:
  - For marking without policing, you can enter the **transmit** keyword to transmit all matched out-of-profile traffic.
  - The default exceed action is **drop**, except with a *maximum\_burst\_bytes* parameter (**drop** is not supported with a *maximum\_burst\_bytes* parameter).



**Note** When the exceed action is **drop**, PFC QoS ignores any configured violate action.

- You can enter the **policed-dscp-transmit** keyword to cause all matched out-of-profile traffic to be marked down as specified in the markdown map.



**Note** When you create a policer that does not use the **pir** keyword and the *maximum\_burst\_bytes* parameter is equal to the *normal\_burst\_bytes* parameter (which is the case if you do not enter the *maximum\_burst\_bytes* parameter), the **exceed-action** **policed-dscp-transmit** keywords cause PFC QoS to mark traffic down as defined by the **policed-dscp max-burst** markdown map.

- (Optional) for traffic that exceeds the PIR, you can specify a violate action as follows:
  - For marking without policing, you can enter the **transmit** keyword to transmit all matched out-of-profile traffic.
  - The default violate action is equal to the exceed action.
  - You can enter the **policed-dscp-transmit** keyword to cause all matched out-of-profile traffic to be marked down as specified in the markdown map.

This example shows how to create a policy map named **max-pol-ipp5** that uses the class-map named **ipp5**, which is configured to trust received IP precedence values and is configured with a maximum-capacity aggregate policer and with a microflow policer:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpq0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+%"rqnke{/ocr"ocz/rqn/krr7"
```

```
Tqvwgt*eqphki/rocr/e+"encuu"kr7"
Tqvwgt*eqphki/rocr/e+"vtwuv"kr/rtgegfgepeg"
Tqvwgt*eqphki/rocr/e+"rqnkeg"422222222"4222222"eqphqto/cevkqp"ugv/rtge/vtcpuokv"8"
gzeggf/cevkqp"rqnkegf/fuer/vtcpuokv"
Tqvwgt*eqphki/rocr/e+"rqnkeg"hnqy"32222222"32222"eqphqto/cevkqp"ugv/rtge/vtcpuokv"8"
gzeggf/cevkqp"rqnkegf/fuer/vtcpuokv"
Tqvwgt*eqphki/rocr/e+"gpf"
```

### Configuring a Per-Interface Microflow Policer

To configure a per-interface microflow policer, perform this task:

| Command                                                                                                                                                                                                                                                                                                                                        | Purpose                                                                                  |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|
| <pre>Tqvwgt*eqphki/rocr/e+"rqnkeg"hnqy"]ocum }ute/qpn{ ~ fguv/qpn{ ~ hwnn/hnqy_i_" bits_per_second normal_burst_bytes"[]]eqphqto/cevkqp"}ftqr ~" ugv/fuer/vtcpuokv dscp_value ~"ugv/rtge/vtcpuokv ip_precedence_value ~ vtcpuokv_i_"gzeggf/cevkqp"}ftqr"~"rqnkegf/fuer"~"vtcpuokv_i_" xkqncvg/cevkqp }ftqr"~"rqnkegf/fuer"~"vtcpuokv_i_"</pre> | Creates a per-interface microflow policer and configures the policy-map class to use it. |

- When you apply both ingress policing and egress policing to the same traffic, both the input policy and the output policy must either mark down traffic or drop traffic. PFC QoS does not support ingress markdown with egress drop or ingress drop with egress markdown.
- Policing uses the Layer 2 frame size.
- See the “[Restrictions for PFC QoS](#)” section on page 61-1 for information about rate and burst size granularity.
- You can enter the **mask src-only** keywords to base flow identification only on source addresses, which applies the microflow policer to all traffic from each source address. PFC QoS supports the **mask src-only** keywords for both IP traffic and MAC traffic.
- You can enter the **mask dest-only** keywords to base flow identification only on destination addresses, which applies the microflow policer to all traffic to each source address. PFC QoS supports the **mask dest-only** keywords for both IP traffic and MAC traffic. Release 15.1(1)SY1 and later releases support Egress Microflow Destination-Only Policing. [Egress policing is per-VLAN](#), applied on either a Layer 3 interface or an SVI.
- By default and with the **mask full-flow** keywords, PFC QoS bases IP flow identification on source IP address, destination IP address, the Layer 3 protocol, and Layer 4 port numbers.
- PFC QoS considers MAC-Layer traffic with the same protocol and the same source and destination MAC-Layer addresses to be part of the same flow, including traffic with different EtherTypes.
- Microflow policers do not support the *maximum\_burst\_bytes* parameter, the **pir bits\_per\_second** keyword and parameter, or the **violate-action** keyword.



**Note** The flowmask requirements of microflow policing, NetFlow, and NetFlow data export (NDE) might conflict.

- The valid range of values for the CIR *bits\_per\_second* parameter is as follows:
  - Minimum—32 kilobits per second, entered as 32000
  - Maximum—256 gigabits per second, entered as 256000000000
- The *normal\_burst\_bytes* parameter sets the CIR token bucket size.
- When configuring the size of a token bucket, note the following information:

- Because the token bucket must be large enough to hold at least one frame, configure the token bucket size to be larger than the maximum size of the traffic being policed.
- For TCP traffic, configure the token bucket size as a multiple of the TCP window size, with a minimum value at least twice as large as the maximum size of the traffic being policed.
- The *maximum\_burst\_bytes* parameter must be set larger than the *normal\_burst\_bytes* parameter.
- To sustain a specific rate, set the token bucket size to be at least the rate value divided by 2000.
- The minimum token bucket size is 1 byte, entered as 1.
- The maximum token bucket size is 512 megabytes, entered as 512000000.
- (Optional) You can specify a conform action for matched in-profile traffic as follows:
  - The default conform action is **transmit**, which sets the policy map class trust state to *trust DSCP* unless the policy map class contains a **trust** command.
  - To set PFC QoS labels in untrusted traffic, you can enter the **set-dscp-transmit** keyword to mark matched untrusted traffic with a new DSCP value or enter the **set-prec-transmit** keyword to mark matched untrusted traffic with a new IP precedence value. The **set-dscp-transmit** and **set-prec-transmit** keywords are only supported for IP traffic. PFC QoS sets egress ToS and CoS from the configured value.
  - You can enter the **drop** keyword to drop all matched traffic.
  - Ensure that aggregate and microflow policers that are applied to the same traffic each specify the same conform-action behavior.
- (Optional) For traffic that exceeds the CIR, you can specify an exceed action as follows:
  - For marking without policing, you can enter the **transmit** keyword to transmit all matched out-of-profile traffic.
  - The default exceed action is **drop**, except with a *maximum\_burst\_bytes* parameter (**drop** is not supported with a *maximum\_burst\_bytes* parameter).




---

**Note** When the exceed action is **drop**, PFC QoS ignores any configured violate action.

---

- You can enter the **policed-dscp-transmit** keyword to cause all matched out-of-profile traffic to be marked down as specified in the markdown map.




---

**Note** When you create a policer that does not use the **pir** keyword and the *maximum\_burst\_bytes* parameter is equal to the *normal\_burst\_bytes* parameter (which is the case if you do not enter the *maximum\_burst\_bytes* parameter), the **exceed-action policed-dscp-transmit** keywords cause PFC QoS to mark traffic down as defined by the **policed-dscp max-burst** markdown map.

---

## Verifying Policy Map Configuration

To verify policy map configuration, perform this task:

|        | Command                                                                        | Purpose                                                                                                                                              |
|--------|--------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki/rocr/e+%"<b>gpf</b>"</code>                                | Exits policy map class configuration mode.<br><br><b>Note</b> Enter additional <b>class</b> commands to create additional classes in the policy map. |
| Step 2 | <code>Tqvwgt%"<b>ujqy</b>"<b>rqnke</b>{/ocr" <i>rqnke</i>{<i>apcog</i>"</code> | Verifies the configuration.                                                                                                                          |

This example shows how to verify the configuration:

```
Tqvwgt%"ujqy"rqnke{/ocr"ocz/rqn/krr7"
"Rqnke{"Ocr"ocz/rqn/krr7
"encuu" "krr7

"encuu" krr7
" " " "rqnkeg"hnqy"32222222"32222"eqphqto/cevkqp"ugv/rtge/vtcpuokv"8"gzeggf/cevkqp"
rqnkegf/fuer/vtcpuokv
" " " "vtwuv"rtgegfgpeg
" " " "rqnkeg"422222222"4222222"4222222"eqphqto/cevkqp"ugv/rtge/vtcpuokv"8"gzeggf/cevkqp"
rqnkegf/fuer/vtcpuokv

Tqvwgt%"
```

## Attaching a Policy Map to an Interface

To attach a policy map to an interface, perform this task:

|        | Command                                                                                                                                                         | Purpose                                 |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%"<b>kpvgt</b>hceg"}<b>xncp</b>"vlan_ID;"~" }type slot/port]0uwdkpvgt hceg_i"~" }<b>rqt</b>v/<b>ejcppgn</b> pwodgt]0uwdkpvgt hceg_i;</code> | Selects the interface to configure.     |
| Step 2 | <code>Tqvwgt*eqphki/kh+%"<b>ugt</b>xkeg/<b>rqnke</b>{"]<b>kprwv</b>"~"<b>qvwrvw</b>_"<i>rqnke</i>{<i>aocrapcog</i>"</code>                                      | Attaches a policy map to the interface. |
| Step 3 | <code>Tqvwgt*eqphki/kh+%"<b>gpf</b>"</code>                                                                                                                     | Exits configuration mode.               |

- Do not attach a service policy to a port that is a member of an EtherChannel.
- PFC QoS supports the **output** keyword only on Layer 3 interfaces (either LAN ports configured as Layer 3 interfaces or VLAN interfaces). You can attach both an input and an output policy map to a Layer 3 interface.
- VLAN-based or port-based PFC QoS on Layer 2 ports is not relevant to policies attached to Layer 3 interfaces with the **output** keyword.
- Release 15.1(1)SY1 and later releases support Egress Microflow Destination-Only Policing. [Egress policing is per-VLAN](#), applied on either a Layer 3 interface or an SVI. With releases earlier than Release 15.1(1)SY1, policies attached with the **output** keyword do not support microflow policing.
- You cannot attach a policy map that configures a trust state with the **service-policy output** command.

- Filtering based on IP precedence or DSCP in policies attached with the **output** keyword uses the received IP precedence or DSCP values. Filtering based on IP precedence or DSCP in policies attached with the **output** keyword is not based on any IP precedence or DSCP changes made by ingress QoS.
- A shared aggregate policer cannot be applied in both ingress and egress directions.
- When distributed aggregate policing is enabled, aggregate policers synchronize policing on interfaces supported by different DFC-equipped switching modules or the PFC. Distributed aggregate policing applies to the first 4,096 aggregate policer instances of these types:
  - Aggregate policers applied to VLAN, tunnel, or port channel interfaces.
  - Shared aggregate policers.
  - Aggregate policers in egress policies.

With distributed aggregate policing enabled, aggregate policers in excess of the hardware-supported capacity function as nondistributed aggregate policers.

- Nondistributed aggregate policing works independently on each DFC-equipped switching module and independently on the PFC, which supports any non-DFC-equipped switching modules. Aggregate policing does not combine flow statistics from different DFC-equipped switching modules. You can display aggregate policing statistics for each DFC-equipped switching module and for the PFC and any non-DFC-equipped switching modules supported by the PFC.

Each PFC or DFC polices independently, which might affect QoS features being applied to traffic that is distributed across the PFC and any DFCs. Examples of these QoS feature are:

- Policers applied to a port channel interface.
- Policers applied to a switched virtual interface.
- Egress policers applied to either a Layer 3 interface or an SVI.

Policers affected by this restriction deliver an aggregate rate that is the sum of all the independent policing rates.

- For nonaggregate policers, each PFC or DFC polices independently, which might affect QoS features being applied to traffic that is distributed across the PFC and any DFCs. Examples of these QoS feature are:
  - Policers applied to a port channel interface.
  - Policers applied to a switched virtual interface.
  - Egress policers applied to either a Layer 3 interface or an SVI.

Policers affected by this restriction deliver an aggregate rate that is the sum of all the independent policing rates.

- When you apply both ingress policing and egress policing to the same traffic, both the input policy and the output policy must either mark down traffic or drop traffic. PFC QoS does not support ingress markdown with egress drop or ingress drop with egress markdown.

This example shows how to attach the policy map named **pmap1** to gigabit Ethernet port 5/36:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Gpvgvt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0" "Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"7158"
Tqwgvt*eqphki/kh+%"ugtxkeg/rqnke{"kprwv"rocr3"
Tqwgvt*eqphki/kh+%"gpf"
```

This example shows how to verify the configuration:

```
Tqwgvt%"ujqy"rqnke{/ocr"kpvgthceg"ikicdkvgvjgtpgv"7158"
"ikicdkvgvjgtpgv7158"
```

```

"ugtxkeg/rqnke{"kprvw<"rocr3
""encuu/ocr<"eocr3"*ocvej/cnn+
""""2"rcemgvu."2"d{vgu
""""7"okpwwg"tcvg"2"dru
""""ocvej<"kr"rtgegfgpeg"7
"encuu"eocr3
""""rqnkeg":222":222"eqphqto/cevkqp"vtcpuokv"gzeggf/cevkqp"ftqr
""""encuu/ocr<"eocr4"*ocvej/cp{+
""""2"rcemgvu."2"d{vgu
""""7"okpwwg"tcvg"2"dru
""""ocvej<"kr"rtgegfgpeg"4
""""2"rcemgvu."2"d{vgu
""""7"okpwwg"tcvg"2"dru
"encuu"eocr4
""""rqnkeg":222"32222"eqphqto/cevkqp"vtcpuokv"gzeggf/cevkqp"ftqr
Tqvwgt%

```

## Configuring Dynamic Per-Session Attachment of a Policy Map

- [Policy Map Dynamic Per-Session Attachment Prerequisites](#), page 63-19
- [Defining and Associating Policy Maps](#), page 63-19

### Policy Map Dynamic Per-Session Attachment Prerequisites

- Define the ingress and [egress QoS](#) policy maps to be assigned when users are authenticated.
- Configure identity policies to specify the policy maps to be assigned.
- In the user profiles on the RADIUS server, configure the Cisco vendor-specific attributes (VSAs) to specify which ingress and egress QoS policy maps will be assigned to each user.

### Defining and Associating Policy Maps

To define the policy maps and associate them with an identity policy, follow these steps:

|        | Command                                                                                    | Purpose                                                                       |
|--------|--------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%"rqnke{/ocr" kparqnke{apcog"</code>                                   | Configures an ingress QoS policy map.                                         |
| Step 2 | <code>Tqvwgt*eqphki/rocr+%"encuu" class_map_name 000</code>                                | Configures policy map class.                                                  |
| Step 3 | <code>Tqvwgt*eqphki/rocr/e+%"gzkv</code>                                                   | Exits policy map class configuration submenu.                                 |
| Step 4 | <code>Tqvwgt*eqphki+%"rqnke{/ocr out_policy_name"</code>                                   | Configures an egress QoS policy map.                                          |
| Step 5 | <code>Tqvwgt*eqphki/rocr+%"encuu" class_map_name 000</code>                                | Configures policy map class.                                                  |
| Step 6 | <code>Tqvwgt*eqphki/rocr/e+%"gzkv</code>                                                   | Exits policy map class configuration submenu.                                 |
| Step 7 | <code>Tqvwgt*eqphki+%"kfgpvkv{"rqnke{"policy1"</code>                                      | Creates an identity policy, and enters identity policy configuration submenu. |
| Step 8 | <code>Tqvwgt*eqphki/kfgpvkv{/rqnke{+%"ugtxkeg/rqnke{"v{rg"squ" kprvw in_policy_name</code> | Associates the ingress QoS policy map with this identity.                     |

|         | Command                                                                                                   | Purpose                                                                          |
|---------|-----------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------|
| Step 9  | <code>Tqwvgt*eqphki/kfgpvkv{/rqnke{+% "ugt<del>x</del>keg/rqnke{ " v{rg"squ"qwvrwv out_policy_name</code> | Associates the egress QoS policy map with this identity.                         |
| Step 10 | <code>Tqwvgt*eqphki/kfgpvkv{/rqnke{+% "gpf</code>                                                         | Exits identity policy configuration submode and returns to privileged EXEC mode. |

To remove the identity policy, use the **no identity policy** *policy\_name* command.

After the policy maps have been defined, configure the Cisco AV pair attributes in each user profile on the RADIUS server using the policy map names:

- cisco-avpair = "ip:sub-policy-In=*in\_policy\_name*"
- cisco-avpair = "ip:sub-policy-Out=*out\_policy\_name*"

To set the Cisco AV pair attributes on the RADIUS server, perform the following task:

| Command or Action                                                              | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>uwd/rqnke{/Kp?kparqnke{apcog"<br/>uwd/rqnke{/Qwv?qwvarqnke{apcog"</code> | <p>Enters the two Cisco AV pairs for service policy on the RADIUS server in the user file. When the switch requests the policy name, this information in the user file is supplied.</p> <p>A RADIUS user file contains an entry for each user that the RADIUS server will authenticate. Each entry, which is also referred to as a <i>user profile</i>, establishes an attribute the user can access.</p> <p>In this example, you have configured a service policy that attaches a QoS policy map to the interface and specifies the direction (inbound for data packets traveling into the interface or outbound for data packets leaving the interface).</p> <p>The policy map applied in the inbound direction is <code>example_in_qos</code> and the outbound policy map is <code>example_out_qos</code>.</p> |

This example shows the configuration in the user file on the RADIUS server:

```
wugtkf Rcuuyqtf"?$ekueq$
 Ugtxkeg/V{rg"? "Htcogf .
 Htcogf/Rtqvgeqn"? "RRR .
 ekueq/cxrckt"? "$uwd/rqnke{/Kp?gzcorngakpasqu$.
 ekueq/cxrckt"? "$uwd/rqnke{/Qwv?gzcornaqwasqu$
```

This example shows the output of the **show epm session summary** command when a session is active:

```
Tqwvgt%"ujqy"gro"uguukqp"uwooct{

GRO"Uguukqp"Kphqtocvkqp
//////////
Vqvcn"uguukqpu"uggp"uq"hct"<"7
Vqvcn"cevkxg"uguukqpu" "" ""<"3
Uguukqp"KR"Cfftguu" "" "" ""<"3;4020403
//////////
```

This example shows the output of the **show epm session ip** *ip\_addr* command when a session is active on the interface with IP address 192.0.2.1:

```
Tqwvgt%"ujqy"gro"uguukqp"kr"3;4020403

Cfokuukqp"hgcvtg" "" "" ""<"CWVJRTQZ [
CCC"Rqnkekgu" "" "" "" "" ""<
Kprwv"Ugtxkeg"Rqnke{ "" "" ""<"kparqnke{apcog
Qwvrwv"Ugtxkeg"Rqnke{ "" "" ""<"qwvarqnke{apcog
```



**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## Policy-Based Queueing

---

- [Prerequisites for Policy-Based Queueing, page 64-1](#)
- [Restrictions for Policy-Based Queueing, page 64-2](#)
- [Information About Policy-Based Queueing, page 64-4](#)
- [How to Configure Policy-Based Queueing, page 64-10](#)
- [Configuration Examples for Policy-Based Queueing, page 64-18](#)
- [Queuing on FEX, page 64-45](#)



### Note

- Queueing is optional. Use the commands described in this section to configure queueing on ports that serve congested links.
- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for Policy-Based Queueing

None.

## Restrictions for Policy-Based Queueing

- Ports on the WS-X6904-40G-2T switching modules can be configured with two priority queues (2p6q4t). Priority queue 1 has higher priority than priority queue 2.
- The WS-X6904-40G-2T egress queues support QoS shaping.
  - Shaping buffers traffic that exceeds the total egress port bandwidth. You can configure shaping on the egress queues and for egress traffic on the port.
  - You configure shaping as a percentage of the total egress port bandwidth.
  - Shaping can be configured only on the egress queues of WS-X6904-40G-2T ports. You cannot configure shaping on a port-channel interface.
  - Ports with shaping configured can be members of an EtherChannel, but shaping can cause the egress traffic rate to vary significantly and cause significant differences between the member ports.
  - You configure shaping with the **shape average percent** command. The **show running-configuration** command displays the **shape average percent** command, but the **show policy-map type lan-queueing** command displays the shaping configuration with the **cir percentage** command under the heading “Average Rate Traffic Shaping” heading.

See the “[Configuring Policy-Based Queueing on WS-X6904-40G-2T Ports](#)” section on page 64-12.

- DSCP-based queueing is supported on 8q4t, 1p7q2t, 2p6q4t, and 1p7q4t ports. The Supervisor Engine 2T-10GE ports are 8q4t/1p7q4t with the **platform qos 10g-only** global configuration command configured, which disables the Gigabit Ethernet ports on the supervisor engine.
- The presence of a **match dscp** command or a **match precedence** command in a class map that is used in a queueing policy attached to a port enables DSCP-based queueing on the port in the direction that the queueing policy is attached.
- CoS-based queueing is always used for non-IP traffic, IP multicast traffic, and IP unknown unicast flood traffic.
- Class maps that are used in queueing policies can contain any combination and number of **match dscp**, **match precedence**, or **match cos** commands.
- You can attach one input and one output queueing policy to an interface, in addition to policies that configure marking or policing. To support per-queue shaping on WS-X6904-40G-2T egress nonprioritynonpriority queues, the output queueing policy on WS-X6904-40G-2T port egress queues supports child policies.
- To support migration from Cisco IOS Release 12.2SX configurations, Cisco IOS Release 15.4SY supports global configuration mode and interface configuration mode queueing commands.
  - When you attach an ingress or egress queueing policy to a port, all interface configuration mode queueing commands on the port are deleted.
  - An attached ingress or egress queueing policy supercedes the effect of any configured global configuration mode queueing commands.
  - If you attach a queueing policy in only one direction, the queueing configuration of the other direction is either the defaults or is defined by any configured global configuration mode queueing commands.
  - You cannot configure any interface configuration mode queueing commands on a port that has a queueing policy attached.

- Policy-based queueing is supported on all modules that Cisco IOS Release 15.4SY supports with the Supervisor Engine 2T-10GE.
- Queueing policies are specific to particular port types because a queueing policy cannot contain any commands that are not supported by the port to which it will be attached (see the [“Configuration Examples for Policy-Based Queueing”](#) section on page 64-18). Commands not supported on a port are not ignored. You cannot successfully apply a policy with unsupported commands to a port.
- For clarity, configure queueing policy names that correspond to the port type it supports; for example **1q2t\_1q8t\_ingress**.
- Queueing policies can contain multiple class maps; each class map configures a queue.
- A policy-map class defined by a **class** command that uses a class map and that contains the policy-map class **priority** command configures the priority queue. (The priority queue is the highest-numbered queue.) The class-map filters the QoS values (CoS or DSCP) it is configured with to the priority queue.
- Enabling SRR on a port disables the priority queue.
- A policy-map class defined by a **class** command that uses a class map and that does not contain the policy-map class **priority** command configures the highest-numbered nonpriority queue. (If the port has a priority queue, the highest-numbered nonpriority queue is numbered one less than the priority queue. If the port does not have a priority queue, the highest-numbered queue is a nonpriority queue.) Subsequent such commands define the configuration of the remaining nonpriority queues in reverse numerical order. You cannot skip a queue, but configuration of all queues is not required. The class-map filters the QoS values it is configured with to the nonpriority queue being configured.
- A **class** command that uses the **class-default** keywords configures queue 1. The **class-default** keywords filter all remaining QoS values to queue 1.
- For each nonpriority queue, policy-map class **queue-buffers** or **random-detect** commands assign QoS values (CoS or DSCP) to thresholds within a queue. Thresholds are configured in numerical order. You cannot skip a threshold, but configuration of all threshold is not required. QoS values that are to be applied to the thresholds must be from the group of values that the class-map filters to the queue.
  - The first **queue-buffers** or **random-detect** command assigns QoS values to the first threshold, and configures the percentage value applied to it.
  - Subsequent **queue-buffers** or **random-detect** commands that are configured with the same percentage value assign additional QoS values to the first threshold.
  - The next **queue-buffers** or **random-detect** command that is configured with a different percentage value assigns QoS values to the numerically next threshold, and configures the percentage value applied to it.
  - Subsequent **queue-buffers** or **random-detect** commands that are configured with the same percentage value assign additional QoS values to the numerically next threshold.
  - Each **queue-buffers** or **random-detect** command with a different percentage defines the next unconfigured threshold and any subsequent commands that repeat a percentage value assign additional QoS values to a configured threshold.
  - All unconfigured thresholds are at 100%.
  - All unassigned QoS labels are assigned to the highest-numbered threshold.

# Information About Policy-Based Queueing

- [Port-Based Queue Types, page 64-4](#)
- [Queueing Policies, page 64-8](#)

## Port-Based Queue Types

- [Ingress and Egress Buffers and Queues, page 64-4](#)
- [Ingress Queue Types, page 64-5](#)
- [Egress Queue Types, page 64-6](#)
- [Module to Queue Type Mappings, page 64-7](#)

## Ingress and Egress Buffers and Queues

**Note**

The WS-X6904-40G-2T egress queues support QoS [shaping](#).

The Ethernet port ASICs have buffers that are divided into a fixed number of queues. When congestion avoidance is enabled, PFC QoS uses the traffic's Layer 2 CoS value or, on some port types, the Layer 3 DSCP values, to assign traffic to the queues. The buffers and queues store frames temporarily as they transit the switch. PFC QoS allocates the port ASIC memory as buffers for each queue on each port.

The Ethernet ports support the following types of queues:

- Nonpriority queues
- Priority queues

The Ethernet ports support the following types of scheduling algorithms between queues:

- Shaped round robin (SRR)—SRR allows a queue to use only the allocated bandwidth.
- Deficit weighted round robin (DWRR)—DWRR keeps track of any lower-priority queue under-transmission caused by traffic in a higher-priority queue and compensates in the next round.
- Weighted Round Robin (WRR)—WRR does not explicitly reserve bandwidth for the queues. Instead, the amount of bandwidth assigned to each queue is user configurable. The percentage or weight allocated to a queue defines the amount of bandwidth allocated to the queue.
- Priority queueing—Strict priority queueing allows delay-sensitive data such as voice to be dequeued and sent before packets in other queues are dequeued, giving delay-sensitive data preferential treatment over other traffic. The switch services traffic in the strict-priority transmit queue before servicing the nonpriority queues. After transmitting a packet from a nonpriority queue, the switch checks for traffic in the strict-priority queue. If the switch detects traffic in the strict-priority queue, it suspends its service of the nonpriority queue and completes service of all traffic in the strict-priority queue before returning to the nonpriority queue.

The Ethernet ports provide congestion avoidance with these types of thresholds within a queue:

- Weighted Random Early Detection (WRED)—On ports with WRED drop thresholds, frames with a given QoS label are admitted to the queue based on a random probability designed to avoid buffer congestion. The probability of a frame with a given QoS label being admitted to the queue or discarded depends on the weight and threshold assigned to that QoS label.

For example, if CoS 2 is assigned to queue 1, threshold 2, and the threshold 2 levels are 40 percent (low) and 80 percent (high), then frames with CoS 2 will not be dropped until queue 1 is at least 40 percent full. As the queue depth approaches 80 percent, frames with CoS 2 have an increasingly higher probability of being discarded rather than being admitted to the queue. Once the queue is over 80 percent full, all CoS 2 frames are dropped until the queue is less than 80 percent full. The frames the switch discards when the queue level is between the low and high thresholds are picked out at random, rather than on a per-flow basis or in a FIFO manner. This method works well with protocols such as TCP that can adjust to periodic packet drops by backing off and adjusting their transmission window size.

- Tail-drop thresholds—On ports with tail-drop thresholds, frames with a given QoS label are admitted to the queue until the drop threshold associated with that QoS label is exceeded; subsequent frames of that QoS label are discarded until the threshold is no longer exceeded. For example, if CoS 1 is assigned to queue 1, threshold 2, and the threshold 2 watermark is 60 percent, then frames with CoS 1 will not be dropped until queue 1 is 60 percent full. All subsequent CoS 1 frames will be dropped until the queue is less than 60 percent full. With some port types, you can configure the nonpriority receive queue to use both a tail-drop and a WRED-drop threshold by mapping a CoS value to the queue or to the queue and a threshold. The switch uses the tail-drop threshold for traffic carrying CoS values mapped only to the queue. The switch uses WRED-drop thresholds for traffic carrying CoS values mapped to the queue and a threshold. All LAN ports of the same type use the same drop-threshold configuration.



#### Note

- You can enable DSCP-based queues and thresholds on 8q4t, 1p7q2t, and 1p7q4t ports (see the [“Module to Queue Type Mappings” section on page 64-7](#)), either in a queueing policy or with legacy interface commands (see the [“Legacy Configuration Procedures for DSCP-Based Queue Mapping” section on page 36-14](#)).
- DSCP-based queueing is supported on 8q4t, 1p7q2t, and 1p7q4t ports. The Supervisor Engine 2T-10GE ports are 8q4t/1p7q4t with the **platform qos 10g-only** global configuration command configured. To configure DSCP-based queue mapping on Supervisor Engine 2T ports, you must enter **shutdown** interface configuration mode commands for the Supervisor Engine 2T Gigabit Ethernet ports, and then enter the **platform qos 10g-only** global configuration command, which disables the Gigabit Ethernet ports on the Supervisor Engine 2T.

The switch provides congestion avoidance with the combination of multiple queues and the scheduling algorithms associated with each queue.

## Ingress Queue Types

To see the queue structure of a LAN port, enter the **show queueing interface type slot/port | include type** command. The command displays one of the following architectures:

- **1q2t** indicates one nonpriority queue with one configurable tail-drop threshold and one nonconfigurable tail-drop threshold.
- **2q4t** indicates two nonpriority queues, each with four configurable tail-drop thresholds.
- **2q8t** indicates two nonpriority queues, each with eight configurable tail-drop thresholds.
- **8q4t** indicates eight nonpriority queues, each with four thresholds, each configurable as either WRED-drop or tail-drop, with support for DSCP-based queueing.
- **8q8t** indicates eight nonpriority queues, each with eight thresholds, each configurable as either WRED-drop or tail-drop.

- **1p1q4t** indicates:
  - One strict-priority queue
  - One nonpriority queue with four configurable tail-drop thresholds.
- **1p7q2t** indicates the following:
  - One strict-priority queue
  - Seven nonpriority queues, each with two thresholds, each threshold configurable as either WRED-drop or tail-drop
  - Supports DSCP-based queueing
- **2p6q4t** indicates the following:
  - Two strict-priority queues
  - Six nonpriority queues, each with four thresholds, each threshold configurable as either WRED-drop or tail-drop
  - Supports DSCP-based queueing
- **1p7q4t** indicates the following:
  - One strict-priority queue
  - Seven nonpriority queues, each with four thresholds, each threshold configurable as either WRED-drop or tail-drop
  - Supports DSCP-based queueing

## Egress Queue Types

To see the queue structure of an egress LAN port, enter the **show queueing interface type slot/port | include type** command. The command displays one of the following architectures:

- **1p3q8t** indicates the following:
  - One strict-priority queue
  - Three nonpriority queues, each with eight thresholds, each threshold configurable as either WRED-drop or tail-drop
- **2p6q4t** indicates the following:
  - Two strict-priority queues
  - Six nonpriority queues, each with four thresholds, each threshold configurable as either WRED-drop or tail-drop
  - Supports DSCP-based queueing
  - [Supports per-queue shaping and per-port shaping](#)
- **1p7q4t** indicates the following:
  - One strict-priority queue
  - Seven nonpriority queues, each with four thresholds, each threshold configurable as either WRED-drop or tail-drop
  - Supports DSCP-based queueing
  - [On WS-X6904-40G-2T, supports per-queue shaping and per-port shaping](#)

- **1p7q8t** indicates the following:
  - One strict-priority queue
  - Seven nonpriority queues, each with eight thresholds, each threshold configurable as either WRED-drop or tail-drop

## Module to Queue Type Mappings

- [Table 64-1—Supervisor Engine Module QoS Queue Structures](#)
- [Table 64-2—40-Gigabit Ethernet Modules](#)
- [Table 64-3—10-Gigabit Ethernet Modules](#)
- [Table 64-4—Gigabit and 10/100/1000 Ethernet Modules](#)

**Table 64-1** *Supervisor Engine Module QoS Queue Structures*

| Supervisor Engines                   | Ingress Queue and Drop Thresholds                                                 | Ingress Queue Scheduler | Egress Queue and Drop Thresholds | Egress Queue Scheduler | Total Buffer Size | Ingress Buffer Size | Egress Buffer Size |
|--------------------------------------|-----------------------------------------------------------------------------------|-------------------------|----------------------------------|------------------------|-------------------|---------------------|--------------------|
| VS-S2T-10G-XL, VS-S2T-10G            |                                                                                   |                         |                                  |                        |                   |                     |                    |
| With Gigabit Ethernet ports enabled  | 2q4t                                                                              | WRR                     | 1p3q4t                           | DWRR or SRR            |                   | 128 MB              | 112 MB             |
|                                      | Does not support DSCP-based queueing.                                             |                         |                                  |                        |                   |                     |                    |
| With Gigabit Ethernet ports disabled | 8q4t                                                                              | WRR                     | 1p7q4t                           | DWRR or SRR            |                   |                     |                    |
|                                      | <ul style="list-style-type: none"> <li>• Supports DSCP-based queueing.</li> </ul> |                         |                                  |                        |                   |                     |                    |

**Table 64-2** *40-Gigabit Ethernet Modules*

| Modules                                                                                                           | Ingress Queue and Drop Thresholds                                                                                                                                                                        | Ingress Queue Scheduler | Egress Queue and Drop Thresholds | Egress Queue Scheduler | Total Buffer Size                                         | Ingress Buffer Size | Egress Buffer Size |
|-------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|----------------------------------|------------------------|-----------------------------------------------------------|---------------------|--------------------|
| WS-X6904-40G-2TXL, WS-X6904-40G-2T (supports DSCP-based queueing; supports egress queue <a href="#">shaping</a> ) | 1p7q4t or 2p6q4t                                                                                                                                                                                         | DWRR                    | 1p7q4t or 2p6q4t                 | DWRR                   | See the <a href="#">Catalyst 6900 Series data sheet</a> . |                     |                    |
|                                                                                                                   | <b>Note</b> On WS-X6904-40G-2T ports, the <b>bandwidth</b> command must be configured if you configure any nondefault values for any other queueing commands on the port. ( <a href="#">CSCtz05347</a> ) |                         |                                  |                        |                                                           |                     |                    |



Table 64-3 10-Gigabit Ethernet Modules

| Modules                                                                                     | Ingress Queue and Drop Thresholds | Ingress Queue Scheduler | Egress Queue and Drop Thresholds | Egress Queue Scheduler | Total Buffer Size | Ingress Buffer Size | Egress Buffer Size  |
|---------------------------------------------------------------------------------------------|-----------------------------------|-------------------------|----------------------------------|------------------------|-------------------|---------------------|---------------------|
| WS-X6908-10GE<br>(supports DSCP-based queuing)                                              | 8q4t                              | DWRR                    | 1p7q4t                           | DWRR SRR               | 200 MB            | 108 MB              | 90 MB               |
| WS-X6816-10T-2T, WS-X6716-10T, WS-X6816-10G-2T, WS-X6716-10GE (supports DSCP-based queuing) |                                   |                         |                                  |                        |                   |                     |                     |
| Performance mode                                                                            | 8q4t                              | DWRR                    | 1p7q4t                           | DWRR SRR               | 198 MB            | 108 MB per port     | 90 MB per port      |
| Oversubscription mode                                                                       | 1p7q2t                            | DWRR                    | 1p7q4t                           | DWRR SRR               | 91 MB             | 90 MB per port      | 1 MB per port group |
| WS-X6704-10GE                                                                               | 8q8t                              | WRR                     | 1p7q8t                           | DWRR                   | 16 MB             | 2 MB                | 14 MB               |

Table 64-4 Gigabit and 10/100/1000 Ethernet Modules

| Modules                                                                                        | Ingress Queue and Drop Thresholds | Ingress Queue Scheduler | Egress Queue and Drop Thresholds | Egress Queue Scheduler | Total Buffer Size | Ingress Buffer Size | Egress Buffer Size |
|------------------------------------------------------------------------------------------------|-----------------------------------|-------------------------|----------------------------------|------------------------|-------------------|---------------------|--------------------|
| WS-X6848-TX-2T , WS-X6748-GE-TX , WS-X6848-SFP-2T, WS-X6748-SFP, WS-X6824-SFP-2T, WS-X6724-SFP |                                   |                         |                                  |                        |                   |                     |                    |
|                                                                                                | 2q8t                              | WRR                     | 1p3q8t                           | DWRR                   | 1.3 MB            | 166 KB              | 1.2 MB             |

## Queueing Policies

Queueing policies use class-maps with **match** commands (see [Table 64-5](#)) and policy maps with scheduling and congestion management commands (see [Table 64-6](#)).

*Table 64-5 Queueing Policy Class Map match Commands and Match Criteria*

| match Commands                                 | Match Criteria     |
|------------------------------------------------|--------------------|
| <b>match cos</b> <i>cos_list</i>               | CoS values.        |
| <b>match dscp</b> <i>dscp_list</i>             | DSCP values.       |
| <b>match precedence</b> <i>precedence_list</i> | Precedence values. |

**Note**

- The presence of a **match dscp** command or a **match precedence** command in a class map that is used in a queueing policy attached to a port configures DSCP-based queueing in the direction of the policy (ingress or egress) on that port.
- CoS-based queueing is always used for non-IP traffic, IP multicast traffic, and IP unknown unicast flood traffic.
- Class maps that are used in queueing policies can contain both **match dscp** commands and **match cos** commands.

Table 64-6 Queueing Policy-Map Class Commands

| Queueing Commands                                                               | Description                                                                                                                                                                                                                                                                                                                            |
|---------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>dcpfykfvj"]tgockpkpi_"rtegpv"rtgpgvcig"</code>                            | Allocates bandwidth between nonpriority queues. The <b>remaining</b> keyword is required on ports that have a priority queue.                                                                                                                                                                                                          |
| <code>ujcrg"cxgtcig"rtegpv"rtgpgvcig"</code>                                    | On WS-X6904-40G-2T ports, configures <b>shaping</b> on egress priority queues.<br><br>Enables SRR on other ports, which allocates limited bandwidth between nonpriority egress queues (see “SRR” in the “Module to Queue Type Mappings” section on page 64-7).                                                                         |
| <code>rtkqtkv{ "</code>                                                         | Applies a policy-map class to a priority queue.                                                                                                                                                                                                                                                                                        |
| <code>rtkqtkv{ "ngxgn" }3~4; "]"rtegpv"rtgpgvcig_"</code>                       | (Required to configure multiple priority queues or shaping.)<br>On WS-X6904-40G-2T ports, applies a policy-map class to one of the priority queues. Priority queue 1 has higher priority than priority queue 2.<br><br>The optional <b>percent percentage</b> keyword and argument configure <b>shaping</b> on egress priority queues. |
| <code>swgwg/dwhhgtu"tcvkq"ygkijv"</code>                                        | Sets the queue size.                                                                                                                                                                                                                                                                                                                   |
| <code>swgwg/nkokv"ownvkrng/v{rg/dcugf"</code>                                   | Enables application of CoS, precedence, and DSCP values to a tail-drop threshold.                                                                                                                                                                                                                                                      |
| <code>swgwg/nkokv"equ"equaxcnwg"rtegpv"rtgpgvaqhasuk/g"</code>                  | Applies one CoS value to a tail-drop threshold and configures the threshold percentage.                                                                                                                                                                                                                                                |
| <code>swgwg/nkokv"fuer"fueraxcnwg"rtegpv"rtgpgvaqhasuk/g"</code>                | Applies one DSCP value to a tail-drop threshold and configures the threshold percentage.                                                                                                                                                                                                                                               |
| <code>swgwg/nkokv"rtgfggpeg"rtgfggpegaxcnwg"rtegpv rtgpgvaqhasuk/g"</code>      | Applies one precedence value to a tail-drop threshold and configures the threshold percentage.                                                                                                                                                                                                                                         |
| <code>swgwg/nkokv"equ"xcnwg"equankuv"rtegpv rtgpgvaqhasuk/g"</code>             | Applies multiple CoS values to a tail-drop threshold and configures the threshold percentage.                                                                                                                                                                                                                                          |
| <code>swgwg/nkokv"fuer"xcnwg"fuerankuv"rtegpv rtgpgvaqhasuk/g"</code>           | Applies multiple DSCP values to a tail-drop threshold and configures the threshold percentage.                                                                                                                                                                                                                                         |
| <code>swgwg/nkokv"rtgfggpeg"xcnwg"rtgfggpegankuv"rtegpv rtgpgvaqhasuk/g"</code> | Applies multiple precedence values to a tail-drop threshold and configures the threshold percentage.                                                                                                                                                                                                                                   |

Table 64-6 Queueing Policy-Map Class Commands (continued)

| Queueing Commands                                                                                  | Description                                                                                                                                              |
|----------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>tcpfqo/fgvgev"equ/dcugf"]ciitgicvg_</code>                                                   | Enables application of CoS values to a WRED-drop threshold. The <b>aggregate</b> keyword enables use of the <b>values</b> keyword.                       |
| <code>tcpfqo/fgvgev"fuer/dcugf"]ciitgicvg_</code>                                                  | Enables application of DSCP values to a WRED-drop threshold. The <b>aggregate</b> keyword enables use of the <b>values</b> keyword.                      |
| <code>tcpfqo/fgvgev"rtgegfgpeg/dcugf"]ciitgicvg_</code>                                            | Enables application of precedence values to a WRED-drop threshold. The <b>aggregate</b> keyword enables use of the <b>values</b> keyword.                |
| <code>tcpfqo/fgvgev"ownvkrng/v{rg/dcugf"]ciitgicvg_</code>                                         | Enables application of CoS, precedence, and DSCP values to a WRED-drop threshold. The <b>aggregate</b> keyword enables use of the <b>values</b> keyword. |
| <code>tcpfqo/fgvgev"equ"equaxcnwg"<br/>rgtegpv min_percent max_percent"</code>                     | Applies one CoS value to a WRED-drop threshold and configures the threshold percentages.                                                                 |
| <code>tcpfqo/fgvgev"fuer"fueraxcnwg"<br/>rgtegpv min_percent max_percent"</code>                   | Applies one DSCP value to a WRED-drop threshold and configures the threshold percentages.                                                                |
| <code>tcpfqo/fgvgev"rtgegfgpeg"rtgegfgpegaxcnwg"<br/>rgtegpv min_percent max_percent"</code>       | Applies one DSCP value to a WRED-drop threshold and configures the threshold percentages.                                                                |
| <code>tcpfqo/fgvgev"equ"xcnwgu"equankuv"<br/>rgtegpv min_percent max_percent"</code>               | Applies multiple CoS values to a WRED-drop threshold and configures the threshold percentages; requires the <b>aggregate</b> keyword.                    |
| <code>tcpfqo/fgvgev"fuer"xcnwgu"fuerankuv"<br/>rgtegpv min_percent max_percent"</code>             | Applies multiple DSCP values to a WRED-drop threshold and configures the threshold percentages; requires the <b>aggregate</b> keyword.                   |
| <code>tcpfqo/fgvgev"rtgegfgpeg"xcnwgu"rtgegfgpegankuv"<br/>rgtegpv min_percent max_percent"</code> | Applies multiple precedence values to a WRED-drop threshold and configures the threshold percentages.                                                    |

## How to Configure Policy-Based Queueing

- [Configuring a Queueing Policy Class Map, page 64-11](#)
- [Verifying a Queueing Policy Class Map, page 64-11](#)
- [Configuring Queueing Policy Maps, page 64-11](#)
- [Verifying a Queueing Policy Map, page 64-17](#)
- [Attaching a Queueing Policy Map to an Interface, page 64-17](#)



### Note

See the “[Configuration Examples for Policy-Based Queueing](#)” section on [page 64-18](#) for detailed information about which queueing commands are supported by each queue type.

## Configuring a Queueing Policy Class Map

To configure a queueing policy class map, perform this task:

|        | Command                                                                                                                            | Purpose                                                                                                                                                                                                                                   |
|--------|------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%<b>encuu/ocr</b>"v{rg"ncp/swgwkpi<br/>ocvej/cp{"encuuapcog"</code>                                            | Creates a class map. Create a class map for the thresholds on each type of queue that you are configuring. Give the class map a name that allows you to easily associate it with the queue type and threshold for which you configure it. |
| Step 2 | <code>Tqwgvt"*eqphki/eocr+%<b>ocvej"equ</b>"cos_value1"<br/>]cos_value2"000"]cos_valueN__"</code>                                  | (Optional) Configures the queueing policy class map to filter based on CoS values. You can enter multiple commands.                                                                                                                       |
| Step 3 | <code>Tqwgvt"*eqphki/eocr+%<b>ocvej"fu</b>er"dscp_value1"<br/>]dscp_value2"000"]dscp_valueN__"</code>                              | (Optional) Configures the queueing policy class map to filter based on DSCP values and enables DSCP-based queueing on the port in the direction that the queueing policy is attached. You can enter multiple commands.                    |
| Step 4 | <code>Tqwgvt"*eqphki/eocr+%<b>ocvej"rtgegfgpeg"</b><br/>precedence_value1"]precedence_value2"000"<br/>]precedence_valueN__"</code> | (Optional) Configures the queueing policy class map to filter based on precedence values and enables DSCP-based queueing on the port in the direction that the queueing policy is attached. You can enter multiple commands.              |
| Step 5 | <code>Tqwgvt"*eqphki/eocr+%<b>gpf</b>"</code>                                                                                      | Exits configuration mode.                                                                                                                                                                                                                 |

This example shows how to create a class map named **cos5** and how to configure filtering to match traffic with CoS 5:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Gpvgvt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpg0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+%encuu/ocr"equ7"
Tqwgvt*eqphki/eocr+%ocvej"equ"7"
Tqwgvt*eqphki/eocr+%gpf"
```

## Verifying a Queueing Policy Class Map

To verify the queueing policy class map, perform this task:

| Command                                                | Purpose                     |
|--------------------------------------------------------|-----------------------------|
| <code>Tqwgvt%"ujqy"<b>encuu/ocr</b>"encuuapcog"</code> | Verifies the configuration. |

## Configuring Queueing Policy Maps

- [Configuring Policy-Based Queueing on WS-X6904-40G-2T Ports, page 64-12](#)
- [Creating a Queueing Policy, page 64-13](#)
- [Configuring a Priority Queue, page 64-14](#)

- [Configuring Nonpriority Queues, page 64-14](#)
- [Configuring Thresholds, page 64-15](#)

**Note**

- You can attach one input queueing policy map and one output queueing policy map to an interface.
- Queueing policy maps contain one policy-map class for each queue.
- Each policy-map class configures a queue.

### Configuring Policy-Based Queueing on WS-X6904-40G-2T Ports

- [Configuring WS-X6904-40G-2T Nonpriority Egress Queue Shaping \(Except class-default\), page 64-12](#)
- [Configuring WS-X6904-40G-2T Multiple Priority Queues or Egress Priority-Queue Shaping, page 64-13](#)
- [Configuring WS-X6904-40G-2T Class-Default Egress Shaping, page 64-13](#)

**Note**

Use the procedures in these sections to configure the WS-X6904-40G-2T nonpriority ingress queues and single priority queues (ingress or egress) without shaping:

- [Creating a Queueing Policy, page 64-13](#)
- [Configuring a Priority Queue, page 64-14](#)
- [Configuring Nonpriority Queues, page 64-14](#)

Configure thresholds as described in the “[Configuring Thresholds](#)” section on page 64-15.

#### Configuring WS-X6904-40G-2T Nonpriority Egress Queue Shaping (Except class-default)

The first **class** *class\_map\_name* command that you enter configures the highest numbered nonpriority queue. Subsequent **class** *class\_map\_name* commands configure the remaining nonpriority queues in reverse numerical order (highest-numbered to queue #2). To configure shaping on a nonpriority egress queue, perform this task:

|        | Command                                                                                                 | Purpose                                                                              |
|--------|---------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%"<b>rqnke</b>{/ocr"v{rg"ncp/swgwkpi <i>child_policy_name</i>"</code>               | Creates a child policy map for the nonpriority queues.                               |
| Step 2 | <code>Tqwgvt*eqphki/rocr+%"<b>encuu</b>"<i>encuuaoacrapcog</i>"</code>                                  | Creates a policy map class for a nonpriority egress queue numbered greater than one. |
| Step 3 | <code>Tqwgvt*eqphki/rocr/e+%"<b>dcpfykf</b>vj"tgo<b>ckp</b>kpi"rgte<b>gp</b>v"rgte<b>gp</b>vcig"</code> | Allocates DWRR bandwidth.                                                            |
| Step 4 | <code>Tqwgvt*eqphki/rocr/e+%"<b>ujcrg</b>"cxgt<b>cig</b>"rgte<b>gp</b>v <i>rgtegpvcig</i>"</code>       | Configures shaping.                                                                  |
| Step 5 | <code>Tqwgvt*eqphki/rocr/e+%"<b>swgwg</b>/dwhhgtu"tcvkq"ygkijv"</code>                                  | (Optional) Sets queue buffer size.                                                   |
| Step 6 | <code>Tqwgvt*eqphki/rocr/e+%"<b>gpf</b>"</code>                                                         | (Optional) Exits policy map class configuration mode.                                |

### Configuring WS-X6904-40G-2T Multiple Priority Queues or Egress Priority-Queue Shaping

To enable the WS-X6904-40G-2T 2p6q4t port architecture (two priority queues) or to configure egress priority-queue shaping, perform this task:

|        | Command                                                                                               | Purpose                                                                                                                                                                              |
|--------|-------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki/rocr+%<b>"encuu"</b> encuuaoacrapcog</code>                                       | Creates a policy map class.                                                                                                                                                          |
| Step 2 | <code>Tqwvgt*eqphki/rocr/e+%<b>"rtkqtkv{ "ngxgn" }3~4 ; "</b><br/>l<b>rgtegpv"rgtegpvcig_"</b></code> | Applies the class map to one of the priority queues. Priority queue 1 has higher priority than priority queue 2. Optionally, for egress queues, configures <a href="#">shaping</a> . |
| Step 3 | <code>Tqwvgt*eqphki/rocr/e+%<b>"swgwg/dwhhgtu"tcvkq"ygkijv"</b></code>                                | (Optional) Sets queue buffer size.                                                                                                                                                   |
| Step 4 | <code>Tqwvgt*eqphki/rocr/e+%<b>"gpf"</b></code>                                                       | (Optional) Exits policy map class configuration mode.                                                                                                                                |

### Configuring WS-X6904-40G-2T Class-Default Egress Shaping

The **class class-default** command configures queue #1. To configure class-default egress shaping, perform this task:

|        | Command                                                                                                                                                                              | Purpose                                               |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"rqnke{/ocr"v{rg"ncp/swgwkpi<br/>rctgpvarqnke{apcog"</b></code>                                                                                              | Creates the parent policy map for the port.           |
| Step 2 | <code>Tqwvgt*eqphki/rocr+%<b>"encuu"encuu/fghcwnv"</b></code>                                                                                                                        | Configures the class-default policy map class.        |
| Step 3 | <code>Tqwvgt*eqphki/rocr/e+%<b>"ujcrg"cxgtcig"</b><br/><b>rgtegpv rgtegpvcig"</b><br/>qt"<br/>Tqwvgt*eqphki/rocr/e+%<b>"ujcrg"cxgtcig"&lt;value<br/>(absolute number)&gt;</b></code> | Configures shaping.                                   |
| Step 4 | <code>Tqwvgt*eqphki/rocr/e+%<b>"swgwg/dwhhgtu"tcvkq"ygkijv"</b></code>                                                                                                               | (Optional) Sets queue buffer size.                    |
| Step 5 | <code>Tqwvgt*eqphki/rocr/e+%<b>"gpf"</b></code>                                                                                                                                      | (Optional) Exits policy map class configuration mode. |

### Creating a Queueing Policy

To create a queueing policy, perform this task:

|        | Command                                                                          | Purpose                                               |
|--------|----------------------------------------------------------------------------------|-------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"rqnke{/ocr"v{rg"ncp/swgwkpi<br/>rqnke{apcog"</b></code> | Creates a policy map.                                 |
| Step 2 | <code>Tqwvgt*eqphki/rocr+%<b>"gpf"</b></code>                                    | (Optional) Exits policy map class configuration mode. |

## Configuring a Priority Queue

1p1q4t, 1p1q8t, 1p7q2t, 1p3q8t, 1p7q8t, and 1p7q4t ports have priority queues. To configure the priority queue, perform this task:

|        | Command                                                               | Purpose                                                                                                                |
|--------|-----------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki/rocr+%<b>encuu</b>"encuuaocrapcog"</code>         | Creates a policy map class.                                                                                            |
| Step 2 | <code>Tqvwgt*eqphki/rocr/e+%<b>rtkqtkv</b>{ "</code>                  | Applies the class map to the priority queue.<br><br><b>Note</b> The priority queue is not supported if SRR is enabled. |
| Step 3 | <code>Tqvwgt*eqphki/rocr/e+%<b>swgwg/dwhhgtu"tcvkq"ygkijv</b>"</code> | (Optional) Sets queue buffer size.                                                                                     |
| Step 4 | <code>Tqvwgt*eqphki/rocr/e+%<b>gpf</b>"</code>                        | (Optional) Exits policy map class configuration mode.                                                                  |

## Configuring Nonpriority Queues

The first **class** *class\_map\_name* command that you enter that is not followed by the **priority** keyword configures the highest numbered nonpriority queue. Subsequent **class** *class\_map\_name* commands configure the remaining nonpriority queues in reverse numerical order (highest-numbered to queue #2). The **class** *class-default* command configures queue #1. To configure a nonpriority queue, perform this task:

|        | Command                                                                                                         | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|--------|-----------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki/rocr+%<b>encuu</b>"<i>encuuaocrapcog</i>"~"<br/><b>encuu/fghcwnv</b>;</code>                | Creates a policy map class.<br><br><b>Note</b> <ul style="list-style-type: none"> <li>Enter a class map name to configure nonpriority queues numbered greater than one.</li> <li>Enter the <b>encuu/fghcwnv</b> keyword to configure queue #1.</li> </ul>                                                                                                                                                                                   |
| Step 2 | <code>Tqvwgt*eqphki/rocr/e+%<b>dcpfykfjv</b>"]<b>tgoackpkipi_</b>"<br/><b>rgtegpv</b>"<i>rgtegpvcig</i>"</code> | Allocates WRR or DWRR bandwidth.<br><br><b>Note</b> <ul style="list-style-type: none"> <li>On WS-X6904-40G-2T ports, the <b>bandwidth</b> command must be configured if you configure any nondefault values for any other queueing commands on the port. (<a href="#">CSCtz05347</a>)</li> <li>Not required on ports that have one queue.</li> <li>The <b>remaining</b> keyword is required on ports that have a priority queue.</li> </ul> |
| Step 3 | <code>Tqvwgt*eqphki/rocr/e+%<b>ujcrg</b>"<i>cxgtcig</i>"<br/><b>rgtegpv</b>"<i>rgtegpvcig</i>"</code>           | (Egress queues only) Enables SRR (not supported on WS-X6904-40G-2T ports), which allocates limited bandwidth between nonpriority egress queues. <ul style="list-style-type: none"> <li>See “SRR” in the “<a href="#">Module to Queue Type Mappings</a>” section on page 64-7).</li> <li>Configuring SRR disables the priority queue.</li> </ul>                                                                                             |



|        | Command                                             | Purpose                                                |
|--------|-----------------------------------------------------|--------------------------------------------------------|
| Step 4 | Tqwvgt*eqphki/rocr/e+% "swgwg/dwhhgtu"tcvkq"ygkijv" | (Optional) Sets queue buffer size.                     |
|        |                                                     | <b>Note</b> Not required on ports that have one queue. |
| Step 5 | Tqwvgt*eqphki/rocr/e+% "gpf"                        | (Optional) Exits policy map class configuration mode.  |

## Configuring Thresholds

- [Threshold Configuration Guidelines and Restrictions, page 64-15](#)
- [Configuring a Threshold as Tail-Drop with CoS-Based Queueing, page 64-15](#)
- [Configuring a Threshold as WRED-Drop with CoS-Based Queueing, page 64-16](#)
- [Configuring a Threshold as Tail-Drop with DSCP-Based Queueing, page 64-16](#)
- [Configuring a Threshold as WRED-Drop with DSCP-Based Queueing, page 64-17](#)

### Threshold Configuration Guidelines and Restrictions

- To configure tail drop thresholds, enter **queue-limit** commands.
- For ports that support configuration as either tail-drop or WRED drop:
  - Enter **queue-limit** commands to configure a threshold as tail drop.
  - Enter **random-detect** commands to configure a threshold as WRED drop.
- The first **queue-limit cos**, **queue-limit dscp**, **random-detect cos**, or **random-detect dscp** command that you enter configures threshold #1.
- Subsequent commands with different threshold percentage values configure the remaining thresholds in numerical order (from threshold #2 to the highest-numbered threshold).
- Subsequent commands with an already configured threshold percentage value apply addition QoS values to the threshold indicated by the percentage value.
- Ports configured for DSCP-based queueing use CoS-based queueing for non-IP traffic, IP multicast traffic, and IP unknown unicast flood traffic. In queueing policies that configure DSCP-based queueing, configure CoS-based queueing to provide specific QoS for non-IP traffic, IP multicast traffic, and IP unknown unicast flood traffic.

### Configuring a Threshold as Tail-Drop with CoS-Based Queueing

To configure a threshold as tail-drop with CoS-based queueing, perform this task:

|        | Command                                                                                       | Purpose                                                                       |
|--------|-----------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------|
| Step 1 | Tqwvgt*eqphki/rocr/e+% "swgwg/nkokv"equ"}qpgaxcnwg" ~"xcnwg" value_list} rgtegpv" rgtegpvcig" | Applies CoS to a tail-drop threshold and configures the threshold percentage. |
| Step 2 | Tqwvgt*eqphki/rocr/e+% "gpf"                                                                  | (Optional) Exits policy map class configuration mode.                         |

### Configuring a Threshold as WRED-Drop with CoS-Based Queuing

To configure a threshold as WRED-drop with CoS-based queuing, perform this task:

|        | Command                                                                                                                                           | Purpose                                                                                                                                                                          |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki/rocr/e+%<b>"tcpfqo/fgvgev"equ/dcugf</b><br/>]ciitgicvg_</code>                                                                | Enables application of CoS values to a WRED-drop threshold. Enter the <b>aggregate</b> keyword to configure multiple CoS values on the threshold with the <b>values</b> keyword. |
| Step 2 | <code>Tqvwgt*eqphki/rocr/e+%<b>"tcpfqo/fgvgev"equ</b><br/>}qpgaxcnwg~<b>"xcnwg"xcnwgankuv</b>;rttegpv<sup>min_</sup>%<br/><sup>max_</sup>%</code> | Applies CoS to a WRED-drop threshold and configures the threshold percentage.                                                                                                    |
| Step 3 | <code>Tqvwgt*eqphki/rocr/e+%<b>gpf</b></code>                                                                                                     | (Optional) Exits policy map class configuration mode.                                                                                                                            |

### Configuring a Threshold as Tail-Drop with DSCP-Based Queueing

To configure a threshold as tail-drop with DSCP-based queuing, perform this task:

|        | Command                                                                                                                                                              | Purpose                                                                                     |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki/rocr/e+%<b>"swgwg/nkokv"ownvkrng/v{rg/dcugf</b></code>                                                                                           | (Optional) Enables application of CoS, DSCP, or precedence values to a tail-drop threshold. |
| Step 2 | <code>Tqvwgt*eqphki/rocr/e+%<b>"swgwg/nkokv"</b><br/><b>}equ ~ fuer ~ rtgegfgpeg;</b><br/><b>}qpgaxcnwg ~ xcnwgu value_list} rttegpv<sup>rgtegpvcig</sup></b></code> | Applies QoS values to a tail-drop threshold and configures the threshold percentage.        |
| Step 3 | <code>Tqvwgt*eqphki/rocr/e+%<b>gpf</b></code>                                                                                                                        | (Optional) Exits policy map class configuration mode.                                       |

### Configuring a Threshold as WRED-Drop with DSCP-Based Queueing

To configure a threshold as WRED-drop with DSCP-based queueing, perform this task:

|        | Command                                                                                                                                | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|--------|----------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <pre>Tqwvgt*eqphki/rocr/e+%<b>"tcpfqo/fgvgev"</b> }fuer/dcugf ~ rtgegfgpeg/dcugf ~ ownvkrng/v{rg/dcugf; " ]ciitgicvg_"</pre>           | <p>Enables application of QoS values to a WRED-drop threshold.</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>Enter the <b>dscp-based</b> keyword to enable application of DSCP values to a WRED-drop threshold.</li> <li>Enter the <b>precedence-based</b> keyword to enable application of precedence values to a WRED-drop threshold.</li> <li>Enter the <b>multiple-type-based</b> keyword to enable application of both CoS, DSCP, or precedence values to a WRED-drop threshold.</li> <li>Enter the <b>aggregate</b> keyword to configure multiple QoS values on the threshold with the <b>values</b> keyword.</li> </ul> |
| Step 2 | <pre>Tqwvgt*eqphki/rocr/e+%<b>"tcpfqo/fgvgev"</b> }equ ~ fuer ~ rtgegfgpeg;" ]qpgaxcnwg ~ xcnwgu xcnwgankuv;"rtegpv"min_%"max_%"</pre> | Applies QoS values to a WRED-drop threshold and configures the threshold percentage.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Step 3 | <pre>Tqwvgt*eqphki/rocr/e+%<b>"gpf"</b></pre>                                                                                          | (Optional) Exits policy map class configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

## Verifying a Queueing Policy Map

Use the **show policy-map *policy\_name*** to verify the configuration.

## Attaching a Queueing Policy Map to an Interface

To attach a queueing policy to an interface, perform this task:

|        | Command                                                                                                  | Purpose                                      |
|--------|----------------------------------------------------------------------------------------------------------|----------------------------------------------|
| Step 1 | <pre>Tqwvgt*eqphki+%<b>"kpvgtthceg"</b> type slot/port"</pre>                                            | Selects the interface to configure.          |
| Step 2 | <pre>Tqwvgt*eqphki/kh+%<b>"ugtckeg/rqnke{ "v{rg"ncp/swgwkpi"</b> ]kprwv ~ qwvrvv_"rqnke{aocrapcog"</pre> | Attaches a queueing policy to the interface. |
| Step 3 | <pre>Tqwvgt*eqphki/kh+%<b>"gpf"</b></pre>                                                                | Exits configuration mode.                    |

Use the **show policy-map interface** command to verify the configuration.

# Configuration Examples for Policy-Based Queueing

- [Queueing Policy Sample Configuration, page 64-18](#)
- [Queueing Policy Commands Supported by Each Queue Type, page 64-19](#)
- [Queueing Policy Commands Sample Configurations for Each Queue Type, page 64-33](#)

## Queueing Policy Sample Configuration

### Without comments:

```
rqnke{/ocr"v{rg"ncp/swgwkpi"r3"
"encuu"equ7"
" " "rtkqtkv{ "
"encuu"equ345"
" " " "dcpfykfvj"tgockpkpi"rtegpv"47"
" " " "swgw/nkokv"equ"4"rtegpv"42"
" " " "swgw/nkokv"equ"5"rtegpv"52"
"encuu"encuu/fghcwnv"
" " " "swgw/nkokv"equ"8"rtegpv"82"
```

### With comments:

```
rqnke{/ocr"v{rg"ncp/swgwkpi"r3"#Hqt"3r5s:v"
"encuu"equ7"#Eqphkiwtgf"vq"hknvgt"EqU"7"
#Vjg"hknvgtkpi"eqphkiwtgf"kp"vjg"encuu"ocr"ugngevu"vjg"xcnwgu"vjcv"iq"vq"vjg"swgw"
#
" " "rtkqtkv{ "#Crrnkgu"vjg"encuu"ocr"vq"vjg"rtkqtkv{ "swgw" *%6+
#
#
#Hktuv"pqp/rtkqtkv{ "encuu"crrnkgu"vq"jkijguv/pwodgtgf"pqp/rtkqtkv{ "swgw" *%5+
"encuu"equ345"#Eqphkiwtgf"vq"hknvgt"EqU"3."4."cpf"5"
#Vjg"hknvgtkpi"eqphkiwtgf"kp"vjg"encuu"ocr"ugngevu"vjg"xcnwgu"vjcv"iq"vq"vjg"swgw"
#
#
#)tgockpkpi)"mg{yqtf"tgswtgf"qp"rqtvu"vjcv"jcxg"c"rtkqtkv{ "swgw"
" " " "dcpfykfvj"tgockpkpi"rtegpv"47
#
#
#Hktuv"swgw/nkokv"eqoocpf"cuukipu"EqU"4"vq"vjtgujqnf"%3"cpf"eqphkiwtgu"kv"cv"42' "
" " " "swgw/nkokv"equ"4"rtegpv"42
#Cp{ "qvjgt"swgw/nkokv"eqoocpf"ykvj"vjg"ucog"rtegpvcig"
#crrnkgu"cfkvkqpcn"eqphkiwtcvkqp"vq"vjku"vjtgujqnf
#
#Pgzv"swgw/nkokv"eqoocpf"ykvj"fkhhgtgpv"rtegpvcig"xcnw"eqphkiwtgu"vjg"pgzv"vjtgujqnf"
#Cuukipu"EqU"5"vq"vjtgujqnf"%4"cpf"eqphkiwtgu"kv"cv"52' "
" " " "swgw/nkokv"equ"5"rtegpv"52
#Cp{ "qvjgt"swgw/nkokv"eqoocpf"ykvj"vjg"ucog"rtegpvcig"
#crrnkgu"cfkvkqpcn"eqphkiwtcvkqp"vq"vjku"vjtgujqnf
#
#Vjtgujqnfu"5/: "ctg"wpeqphkiwtgf
#Cnn"wpeqphkiwtgf"vjtgujqnfu"ctg"cv"322'
#Pg"gzrnekv"eqphkiwtcvkqp"rtqkfgf"hqt"EqU"3<"fghcwnv"vq"ncuv"vjtgujqnf"
#
#Gpf"qh"swgw"5"eqphkiwtcvkqp
#
#Swgw"4"ku"wpeqphkiwtgf
#
"encuu"encuu/fghcwnv"#crrnkgu"vq"swgw"%3
#)encuu/fghcwnv"igvu"cnn"tgockpkpi"EqU"xcnwgu<
```

```
#2."6"."8"."cpf"9
#
#
#Vjtgujqnf"3"ku"gzrnkekv{"eqphkiwtgf<"
""""swgw/nkokv"equ"8"rgtegpv"72"
#
#Tgockpkpi"vjtgujqnfu"*4/:"+ctg"pqv"eqphkiwtgf"d{"vjg"swgwgpki"rqnke{
#cpf"ecppqv"dg"eqphkiwtgf"d{"cp{vjkipi"gnug
#Pq"gzrnkekv"eqphkiwtcvkqp"rtqxkfgf"hqt"EqU"2"."6"."cpf"9<
#EqU"xcnwgu"pqv"gzrnkekv{"eqphkiwtgf"fghcwnv"vq"vjg"ncuv"vjtgujqnf
```

## Queueing Policy Commands Supported by Each Queue Type

- [1q2t, 1q8t Ingress Queue Supported Commands, page 64-20](#)
- [2q8t Ingress Queue Supported Commands, page 64-21](#)
- [8q4t Ingress Queue Supported Commands, page 64-22](#)
- [8q8t Ingress Queue Supported Commands, page 64-23](#)
- [1p1q4t Ingress Queue Supported Commands, page 64-24](#)
- [1p1q8t Ingress Queue Supported Commands, page 64-25](#)
- [1p7q2t Ingress Queue Supported Commands, page 64-26](#)
- [1p3q8t Egress Queue Supported Commands, page 64-27](#)
- [1p7q8t Egress Queue Supported Commands, page 64-28](#)
- [1p7q4t, 2p6q4t Ingress or Egress Queue Supported Commands, page 64-29](#)
- [WS-X6904-40G-2T 1p7q4t, 2p6q4t Egress Queue Supported Commands, page 64-31](#)

## 1q2t, 1q8t Ingress Queue Supported Commands



### Note

- Supports CoS-based queueing with tail-drop thresholds.
- Unsupported commands are included in this section as comments.

```
rqnke{/ocr"v{rg"ncp/swgwkpi"rqnke{aocrapcog"#"Hqt"3s4v."3s:v"
```

- Nonpriority queue 1 policy commands:

```
encuu"encuu/fgwcwnv"#"Tgegkxgu"cnn"EqU"xcnwgu0
#"dcpfykfvj"rttegpv"rttegpvcig"#"YTT"qt"FYTT"dcpfykfvj"cnnqecvkqp0
#"swgw/dwhhgtu"tcvkq"ygkijv"#"Swgw/dwhhgt"uk|g0
```

- Nonpriority queue threshold configuration (repeat to configure sequential thresholds):

```
#"swgw/nkokv"ownvkrng/v{rg/dcugf"
#"Gpcdngu"crnkecvkqp"qh"EqU."rtgegfgpeg."cpf"FUER"xcnwgu
#"vq"c"vckn/ftqr"vjtgujqnf0"

swgw/nkokv"equ"}qpgaxcnwg"~"xcnwgu"value_list}rttegpv"rttegpvcig"

#"swgw/nkokv"fuer"}qpgaxcnwg"~"xcnwgu"value_list}rttegpvrttegpvcig"
#"Crrnkgu"qpg"FUER"xcnwgvq"c"vckn/ftqr"vjtgujqnf
#"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcig

#"tcpfqo/fgvgev"equ/dcugf"}ciitgicvg_"
#"Gpcdngu"crnkecvkqp"qh"EqU"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"

#"tcpfqo/fgvgev"fuer/dcugf"}ciitgicvg_"
#"Gpcdngu"crnkecvkqp"qh"FUER"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"

#"tcpfqo/fgvgev"rtgegfgpeg/dcugf"}ciitgicvg_"
#"Gpcdngu"crnkecvkqp"qh"rtgegfgpeg"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"

#"tcpfqo/fgvgev"ownvkrng/v{rg/dcugf"}ciitgicvg_"
#"Gpcdngu"crnkecvkqp"qh"EqU."rtgegfgpeg."cpf"FUER"xcnwgu
#"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"

#"tcpfqo/fgvgev"equ"}qpgaxcnwg"~"xcnwgu"xcnwgankuv;"rttegpv"min_%"max_%"
#"Crrnkgu"EqU"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcigu0"

#"tcpfqo/fgvgev"fuer"}qpgaxcnwg"~"xcnwgu"xcnwgankuv;"rttegpv"min_%"max_%"
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcigu0"

! random-detect {precedence one_value | values precedence value_list} percent min_ % max_ %
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcigu0"
```

## 2q8t Ingress Queue Supported Commands



### Note

- Supports CoS-based queueing with tail-drop thresholds.
- Unsupported commands are included in this section as comments.

```
rqnke{ /ocr"v{rg"ncp/swgwkpi"rqnke{aocrapcog"#"Hqt"4s:v.":s:v
```

- Class commands for nonpriority queues numbered higher than 1—Configures queues in reverse numerical order; repeat to configure the next queue:

```
encuu"encuuaocrapcog"#"Tgegkxgu"EqU"xcnwgu"hknvgtgf"d{"encuuaocrapcog
```

- Class command for queue #1:

```
encuu"encuu/fghcwnv"#"Tgegkxgu"cnn"tgoockpkpi"EqU"xcnwgu0
```

- Nonpriority queue configuration commands:

```
dcpfykfvj"rgtegpv"rgtegpvcig"#"YTT"qt"FYTT"dcpfykfvj"cnnqecvkqp0
```

```
swgwg/dwhhgtu"tcvkq"ygkijv"#"Swgwg"dwhhgt"uk|g0
```

- Nonpriority queue threshold configuration—Repeat to configure sequential thresholds in each queue:

```
#"swgwg/nkokv"ownvkrng/v{rg/dcugf"
#"Enables application of CoS, precedence, and DSCP values to a tail-drop threshold."
```

```
swgwg/nkokv"equ"}qpgaxcnwg"~"xcnwgu"value_list}rgtegpv"rgtegpvcig"
#"Crrnkgu"EqU"vq"c"vckn/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rgtegpvcig
```

```
#"swgwg/nkokv"fuer"}qpgaxcnwg"~"xcnwgu"value_list}rgtegpv"rgtegpvcig"
#"Crrnkgu"qpg"FUER"xcnw"vq"c"vckn/ftqr"vjtgujqnf"
#"cpf"eqphkiwtgu"vjg"vjtgujqnf"rgtegpvcig
```

```
#"tcpfqo/fgvgev"equ/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"EqU"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
```

```
#"tcpfqo/fgvgev"fuer/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"FUER"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
```

```
#"tcpfqo/fgvgev"rtgegfgpeg/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"rtgegfgpeg"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
```

```
#"tcpfqo/fgvgev"ownvkrng/v{rg/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"EqU."rtgegfgpeg."cpf"FUER"xcnwgu"
#"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
```

```
#"tcpfqo/fgvgev"equ"}qpgaxcnwg"~"xcnwgu"xcnwgankuv;"rgtegpv"min_%"max_%"
#"Crrnkgu"EqU"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rgtegpvcigu0"
```

```
#"tcpfqo/fgvgev"fuer"}qpgaxcnwg"~"xcnwgu"xcnwgankuv;"rgtegpv"min_%"max_%"
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rgtegpvcigu0"
```

```
! random-detect {precedence one_value | values precedence value_list} percent min_%"max_%"
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rgtegpvcigu0"
```

## 8q4t Ingress Queue Supported Commands



### Note

- Supports CoS-based, DSCP-based, and precedence-based queueing with tail-drop and WRED-drop thresholds.
- Unsupported commands are included in this section as comments.

```
rqnke{/ocr"v{rg"ncp/swgwkpi"rqnke{aocrapcog"#Hqt":s6v"
```

- Class commands for nonpriority queues numbered higher than 1—Configures queues in reverse numerical order; repeat to configure the next queue:

```
encuu"encuuaocrapcog"
#"Tgegkxgu"SqU"xcnwgU"*EqU."FUER."rtgegfgpeg+"xcnwgU"hknvgtgf"d{"encuuaocrapcog0
```

- Class command for queue #1:

```
encuu"encuu/fghcwnv"#Tgegkxgu"cnn"tgockpkpi"SqU"xcnwgU"*EqU."FUER."rtgegfgpeg+0
```

- Nonpriority queue configuration commands:

```
dcpfykfvj"rtgegpv"rtgegpvcig"#YTT"qt"FYTT"dcpfykfvj"cnnqecvkqp0
```

```
swgwg/dwhhgtu"tcvkq"ygkijv"#Swgwg/dwhhgt"uk|g0
```

- Nonpriority queue threshold configuration—Repeat to configure sequential thresholds in each queue:

```
swgwg/nkokv"ownvkrng/v{rg/dcugf"
#"Enables application of CoS, precedence, and DSCP values to a tail-drop threshold."
```

```
swgwg/nkokv"equ"}qpgaxcnwg"~"xcnwgU"value_list}rtgegpv"rtgegpvcig"
#"Crrnkgu"EqU"vq"c"vckn/ftqr"vjtgujgnf"cpf"eqphkiwtgu"vjg"vjtgujgnf"rtgegpvcig
```

```
swgwg/nkokv"fuer"}qpgaxcnwg"~"xcnwgU"value_list}rtgegpv"rtgegpvcig"
#"Crrnkgu"qpg"FUER"xcnwg"vq"c"vckn/ftqr"vjtgujgnf"
#"cpf"eqphkiwtgu"vjg"vjtgujgnf"rtgegpvcig
```

```
tcpfqo/fgvgev"equ/dcugf"]ciitgicvg_"
#"Gpcdnгу"crnkecvkqp"qh"EqU"xcnwgU"vq"c"YTGF/ftqr"vjtgujgnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgU)"mg{yqtf"
```

```
tcpfqo/fgvgev"fuer/dcugf"]ciitgicvg_"
#"Gpcdnгу"crnkecvkqp"qh"FUER"xcnwgU"vq"c"YTGF/ftqr"vjtgujgnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgU)"mg{yqtf"
```

```
tcpfqo/fgvgev"rtgegfgpeg/dcugf"]ciitgicvg_"
#"Gpcdnгу"crnkecvkqp"qh"rtgegfgpeg"xcnwgU"vq"c"YTGF/ftqr"vjtgujgnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgU)"mg{yqtf"
```

```
tcpfqo/fgvgev"ownvkrng/v{rg/dcugf"]ciitgicvg_"
#"Enables application of CoS, precedence, and DSCP values to a WRED-drop threshold."
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgU)"mg{yqtf"
```

```
tcpfqo/fgvgev"equ"}qpgaxcnwg"~"xcnwgU"xcnwgankuv;"rtgegpv"min_%"max_%"
#"Crrnkgu"EqU"vq"c"YTGF/ftqr"vjtgujgnf"cpf"eqphkiwtgu"vjg"vjtgujgnf"rtgegpvcigu0"
```

```
tcpfqo/fgvgev"fuer"}qpgaxcnwg"~"xcnwgU"xcnwgankuv;"rtgegpv"min_%"max_%"
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujgnf"cpf"eqphkiwtgu"vjg"vjtgujgnf"rtgegpvcigu0"
```

```
random-detect {precedence one_value | values precedence value_list} percent min_%"max_%"
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujgnf"cpf"eqphkiwtgu"vjg"vjtgujgnf"rtgegpvcigu0"
```



## 8q8t Ingress Queue Supported Commands



### Note

- Supports CoS-based queuing with tail-drop or WRED-drop thresholds.
- Unsupported commands are included in this section as comments.

```
rqnke{ /ocr"v{rg"ncp/swgwkpi"rqnke{aocrapcog#"Hqt"3r3s:v"
```

- Priority queue:

```
encuu"encuuaoocrapcog#"Tgegkxgu"EqU"xcnwgu"hknvgtgf"d{"encuuaoocrapcog0"
rtkqtkv{"#"Crrnkgu"vjg"encuu"ocr"vq"vjg"rtkqtkv{"swgwg
```

- Nonpriority queue policy commands:

```
encuu"encuu/fgwcwnv#"Tgegkxgu"cnn"tgockpkpi"EqU"xcnwgu0
#"dcpfykfvj"tgockpkpi"rttegpv"rttegpvcig#"YTT"qt"FYTT"dcpfykfvj"cnnqecvkqp0
#"swgwg/dwhhgtu"tcvkq"ygkijv#"Swgwg"dwhhgt"uk|g0
```

- Nonpriority queue threshold configuration—Repeat to configure sequential thresholds:

```
#"swgwg/nkokv"ownvkrng/v{rg/dcugf"
#"Enables application of CoS, precedence, and DSCP values to a tail-drop threshold."
#
swgwg/nkokv"equ"}qpgaxcnwg"~"xcnwgu"value_list}rttegpv"rttegpvcig"
#"Crrnkgu"EqU"vq"c"vckn/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcig
#
#"swgwg/nkokv"fuer"}qpgaxcnwg"~"xcnwgu"value_list}rttegpv"rttegpvcig"
#"Crrnkgu"qpg"FUER"xcnwgu"vq"c"vckn/ftqr"vjtgujqnf
#"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcig
#
tcpfqo/fgvgev"equ/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"EqU"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
#"tcpfqo/fgvgev"fuer/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"FUER"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
#"tcpfqo/fgvgev"rtgegfgpeg/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"rtgegfgpeg"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
#"tcpfqo/fgvgev"ownvkrng/v{rg/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"EqU."rtgegfgpeg."cpf"FUER"xcnwgu
#"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
tcpfqo/fgvgev"equ"}qpgaxcnwg"~"xcnwgu"xcnwgankuv;"rttegpv"min_%max_%"
#"Crrnkgu"EqU"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcigu0"
#
#"tcpfqo/fgvgev"fuer"}qpgaxcnwg"~"xcnwgu"xcnwgankuv;"rttegpv"min_%max_%"
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcigu0"
#
! random-detect {precedence one_value | values precedence value_list} percent min_% max_%
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcigu0"
```

## 1p1q4t Ingress Queue Supported Commands



Note

- Supports CoS-based queueing with tail-drop thresholds.
- Unsupported commands are included in this section as comments.

```
rqnke{/ocr"v{rg"ncp/swgwkpi"rqnke{aocrapcog"#Hqt"3r3s6v"
```

- Priority queue:

```
encuu"encuuaocrapcog"#Tgegkxgu"EqU"xcnwgu"hknvgtgf"d{"encuuaocrapcog0"
rtkqtkv{"#Crrnkgu"vjpg"encuu"ocr"vq"vjpg"rtkqtkv{"swgwg
```

- Nonpriority queue policy commands:

```
encuu"encuu/fghcwnv"#Tgegkxgu"cnn"tgockpkpi"EqU"xcnwgu0
#dcpfykfvj"tgockpkpi"rgtegpv"rgtegpvcig"#YTT"qt"FYTT"dcpfykfvj"cnnqecvkqp0
#swgwg/dwhhgtu"tcvkq"ygkijv"#Swgwg/dwhhgt"uklg0
```

- Nonpriority queue threshold configuration—Repeat to configure sequential thresholds:

```
#swgwg/nkokv"ownvkrng/v{rg/dcugf"
#Gpcdngu"crnkecvkqp"qh"EqU."rtgegfgpeg."cpf"FUER"xcnwgu
#vq"c"vckn/ftqr"vjtgujqnf0"
#
swgwg/nkokv"equ"}qpgaxcnwg~"xcnwgu"value_list}rgtegpv"rgtegpvcig"
#Crrnkgu"EqU"vq"c"vckn/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjpg"vjtgujqnf"rgtegpvcig
#
#swgwg/nkokv"fuer"}qpgaxcnwg~"xcnwgu"value_list}rgtegpv"rgtegpvcig"
#Crrnkgu"qpg"FUER"xcnwgu"vq"c"vckn/ftqr"vjtgujqnf
#cpf"eqphkiwtgu"vjpg"vjtgujqnf"rgtegpvcig
#
#tcpfqo/fgvgev"equ/dcugf"]ciitgicvg_"
#"Gpcdngu"crnkecvkqp"qh"EqU"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjpg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjpg)"xcnwgu)"mg{yqtf"
#
#"tcpfqo/fgvgev"fuer/dcugf"]ciitgicvg_"
#"Gpcdngu"crnkecvkqp"qh"FUER"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjpg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjpg)"xcnwgu)"mg{yqtf"
#
#"tcpfqo/fgvgev"rtgegfgpeg/dcugf"]ciitgicvg_"
#"Gpcdngu"crnkecvkqp"qh"rtgegfgpeg"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjpg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjpg)"xcnwgu)"mg{yqtf"
#
#"tcpfqo/fgvgev"ownvkrng/v{rg/dcugf"]ciitgicvg_"
#"Gpcdngu"crnkecvkqp"qh"EqU."rtgegfgpeg."cpf"FUER"xcnwgu
#vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjpg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjpg)"xcnwgu)"mg{yqtf"
#
#"tcpfqo/fgvgev"equ"}qpgaxcnwg~"xcnwgu"xcnwgankuv;"rgtegpv"min_%max_%"
#Crrnkgu"EqU"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjpg"vjtgujqnf"rgtegpvcigu0"
#
#"tcpfqo/fgvgev"fuer"}qpgaxcnwg~"xcnwgu"xcnwgankuv;"rgtegpv"min_%max_%"
#Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjpg"vjtgujqnf"rgtegpvcigu0"
#
! random-detect {precedence one_value | values precedence value_list} percent min_% max_%
#Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjpg"vjtgujqnf"rgtegpvcigu0"
```

## 1p1q8t Ingress Queue Supported Commands



### Note

- Supports CoS-based queueing with tail-drop or WRED-drop thresholds.
- Unsupported commands are included in this section as comments.

```
rqnke{/ocr"v{rg"ncp/swgwkpi"rqnke{aocrapcog#"Hqt"3r3s:v"
```

- Priority queue:

```
encuu"encuuaocrapcog#"Tgegkxgu"EqU"xcnwgu"hknvgtgf"d{"encuuaocrapcog0"
rtkqtkv{"#"Crrnkgu"vjg"encuu"ocr"vq"vjg"rtkqtkv{"swgwg
```

- Nonpriority queue policy commands:

```
encuu"encuu/fgwcwnv#"Tgegkxgu"cnn"tgockpkpi"EqU"xcnwgu0
#"dcpfykfvj"tgockpkpi"rtegpv"rtegpvcig#"YTT"qt"FYTT"dcpfykfvj"cnnqecvkqp0
#"swgwg/dwhhgtu"tcvkq"ygkijv#"Swgwg/dwhhgt"uk|g0
```

- Nonpriority queue threshold configuration—Repeat to configure sequential thresholds:

```
#"swgwg/nkokv"ownvkrng/v{rg/dcugf"
#"Enables application of CoS, precedence, and DSCP values to a tail-drop threshold."
#
swgwg/nkokv"equ"}qpgaxcnwg"~"xcnwgu"value_list}rtegpv"rtegpvcig"
#"Crrnkgu"EqU"vq"c"vckn/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rtegpvcig"
#
#"swgwg/nkokv"fuer"}qpgaxcnwg"~"xcnwgu"value_list}rtegpv"rtegpvcig"
#"Crrnkgu"qpg"FUER"xcnwgu"vq"c"vckn/ftqr"vjtgujqnf"
#"cpf"eqphkiwtgu"vjg"vjtgujqnf"rtegpvcig"
#
tcpfqo/fgvgev"equ/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"EqU"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
#"tcpfqo/fgvgev"fuer/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"FUER"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
#"tcpfqo/fgvgev"rtgegfgpeg/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"rtgegfgpeg"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
#"tcpfqo/fgvgev"ownvkrng/v{rg/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"EqU."rtgegfgpeg."cpf"FUER"xcnwgu
#"vq"c"YTGF/ftqr"vjtgujqnf0"
#
tcpfqo/fgvgev"equ"}qpgaxcnwg"~"xcnwgu"xcnwgankuv;"rtegpv"min_%"max_%"
#"Crrnkgu"EqU"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rtegpvcigu0"
#
#"tcpfqo/fgvgev"fuer"}qpgaxcnwg"~"xcnwgu"xcnwgankuv;"rtegpv"min_%"max_%"
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rtegpvcigu0"
#
! random-detect {precedence one_value | values precedence value_list} percent min_%"max_%"
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rtegpvcigu0"
```

## 1p7q2t Ingress Queue Supported Commands



### Note

- Supports CoS-based, DSCP-based, and precedence-based queueing with tail-drop and WRED-drop thresholds.
- Unsupported commands are included in this section as comments.

```
rqnke{/ocr"v{rg"ncp/swgwkpi"rqnke{aocrapcog"#Hqt"3r9s4v"
```

- Priority queue:

```
encuu"encuuaocrapcog"
#"Tgegkxgu"SqU"xcnwgU"*EqU."FUER."rtgegfgpeg+"xcnwgU"hknvgtgf"d{"encuuaocrapcog0"
rtkqtkv{"#"Crrnkgu"vjg"encuu"ocr"vq"vjg"rtkqtkv{"swgwg
```

- Class commands for nonpriority queues numbered higher than 1—Configures queues in reverse numerical order; repeat to configure the next queue:

```
encuu"encuuaocrapcog"
#"Tgegkxgu"SqU"xcnwgU"*EqU."FUER."rtgegfgpeg+"xcnwgU"hknvgtgf"d{"encuuaocrapcog0
```

- Class command for queue #1:

```
encuu"encuu/Fghcwnv#"Tgegkxgu"cnn"tgockpkpi"SqU"xcnwgU"*EqU."FUER."rtgegfgpeg+0
```

- Nonpriority queue configuration commands:

```
dcpfykfvy"rtegpv"rttegpvcig"#YTT"qt"FYTT"dcpfykfvy"cnnqecvkqp0"
#
swgwg/dwhhgtu"tcvkq"ygkijv#"Swgwg"dwhhgt"uk|g0
```

- Nonpriority queue threshold configuration—Repeat to configure sequential thresholds in each queue:

```
swgwg/nkokv"ownvkrng/v{rg/dcugf"
#"Enables application of CoS, precedence, and DSCP values to a tail-drop threshold."
#
swgwg/nkokv"equ"}qpgaxcnwg~"xcnwgU"value_list}rttegpv"rttegpvcig"
#"Crrnkgu"EqU"vq"vckn/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcig
#
swgwg/nkokv"fuer"}qpgaxcnwg~"xcnwgU"value_list}rttegpvrttegpvcig"
#"Crrnkgu"qpg"FUER"xcnwg"vq"vckn/ftqr"vjtgujqnf
#"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcig
#
tcpfqo/fgvgev"equ/dcugf"]ciitgicvg_"
#"Gpcdngu"crnkecvkqp"qh"EqU"xcnwgU"vq"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgU)"mg{yqtf"
#
tcpfqo/fgvgev"fuer/dcugf"]ciitgicvg_"
#"Gpcdngu"crnkecvkqp"qh"FUER"xcnwgU"vq"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgU)"mg{yqtf"
#
tcpfqo/fgvgev"rtgegfgpeg/dcugf"]ciitgicvg_"
#"Gpcdngu"crnkecvkqp"qh"rtgegfgpeg"xcnwgU"vq"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgU)"mg{yqtf"
#
tcpfqo/fgvgev"ownvkrng/v{rg/dcugf"]ciitgicvg_"
#"Enables application of CoS, precedence, and DSCP values to a WRED-drop threshold."
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgU)"mg{yqtf"
#
tcpfqo/fgvgev"equ"}qpgaxcnwg~"xcnwgU"xcnwgankuv;rttegpv"min_%"max_%"
```

```
#"Crrnkgu"EqU"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjpg"vjtgujqnf"rteggpvcigu0"
#
tcpfqo/fgvgev"fuer"}qpgaxcnwg"~"xcnwgu"xcnwgankuv;"rteggpv"min_%"max_%"
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjpg"vjtgujqnf"rteggpvcigu0"
#
tcpfqo/fgvgev"}rtgegfgpeg"qpgaxcnwg"~"xcnwgu"rtgegfgpeg"xcnwgankuv;"rteggpv min_%"
max_%"
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjpg"vjtgujqnf"rteggpvcigu0"
```

## 1p3q8t Egress Queue Supported Commands



### Note

- Supports CoS-based queuing with tail-drop and WRED-drop thresholds.
- Unsupported commands are included in this section as comments.

```
rqnke{/ocr"v{rg"ncp/swgwkpi"rqnke{aocrapcog"#Hqt"3r5s:v"
```

- Priority queue:

```
encuu"encuuaoocrapcog"#Tgegkxgu"EqU"xcnwgu"hknvgtgf"d{"encuuaoocrapcog"
rtkqtkv{"#"Crrnkgu"vjpg"encuu"ocr"vq"vjpg"rtkqtkv{"swgwg
```

- Class commands for nonpriority queues numbered higher than 1—Configures queues in reverse numerical order; repeat to configure the next queue:

```
encuu"encuuaoocrapcog"#Tgegkxgu"EqU"xcnwgu"hknvgtgf"d{"encuuaoocrapcog
```

- Class command for queue #1:

```
encuu"encuu/fghcwnv"#Tgegkxgu"cnn"tgockpkpi"EqU"xcnwgu0
```

- Nonpriority queue configuration commands:

```
dcpfykfvj"rteggpv"rteggpvcig"#YTT"qt"FYTT"dcpfykfvj"cnnqecvkqp0
#
#"ujcrg"cxgtcig"rteggpv"rteggpvcig"#UTT"dcpfykfvj"cnnqecvkqp0
#
swgwg/dwhhgtu"tcvkq"ygkijv"#Swgwg"dwhhgt"uk|g0
```

- Nonpriority queue threshold configuration—Repeat to configure sequential thresholds:

```
#"swgwg/nkokv"ownvkrng/v{rg/dcugf"
#"Enables application of CoS, precedence, and DSCP values to a tail-drop threshold."
#
swgwg/nkokv"equ"}qpgaxcnwg"~"xcnwgu"value_list}rteggpv"rteggpvcig"
#"Crrnkgu"EqU"vq"c"vckn/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjpg"vjtgujqnf"rteggpvcig"
#
#"swgwg/nkokv"fuer"}qpgaxcnwg"~"xcnwgu"value_list}rteggpv"rteggpvcig"
#"Crrnkgu"qpg"FUER"xcnwgu"vq"c"vckn/ftqr"vjtgujqnf"
#"cpf"eqphkiwtgu"vjpg"vjtgujqnf"rteggpvcig"
#
tcpfqo/fgvgev"equ/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"EqU"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjpg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjpg")xcnwgu)"mg{yqtf"
#
#"tcpfqo/fgvgev"fuer/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"FUER"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjpg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjpg")xcnwgu)"mg{yqtf"
#
#"tcpfqo/fgvgev"rtgegfgpeg/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"rtgegfgpeg"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
```

```
#"Vjg") ciitgicvg) "mg{yqtf"cnngyu"wug"qh"vjg")xcnwg) "mg{yqtf"
#
#"tcpfqo/fgvgev"ownvkrng/v{rg/dcugf"}ciitgicvg_"
#"Gpcdngu"crnkcecvkqp"qh"EqU"."rtgegfgpeg"."cpf"FUER"xcnwg
#"vq"c"YTGF/ftqr"vjtgujgnf0"
#"Vjg") ciitgicvg) "mg{yqtf"cnngyu"wug"qh"vjg")xcnwg) "mg{yqtf"
#
tcpfqo/fgvgev"equ"}qpgaxcnwg"~"xcnwg"xcnwgankuv;"rtegpv"min_%"max_%"
#"Crrnkgu"EqU"vq"c"YTGF/ftqr"vjtgujgnf"cpf"eqphkiwtgu"vjg"vjtgujgnf"rtegpvcigu0"
#
#"tcpfqo/fgvgev"fuer"}qpgaxcnwg"~"xcnwg"xcnwgankuv;"rtegpv"min_%"max_%"
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujgnf"cpf"eqphkiwtgu"vjg"vjtgujgnf"rtegpvcigu0"
#
#"tcpfqo/fgvgev"rtgegfgpeg"qpgaxcnwg"~"xcnwg"rtgegfgpeg"xcnwgankuv;"
rtegpv min_%"max_%"
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujgnf"cpf"eqphkiwtgu"vjg"vjtgujgnf"rtegpvcigu0"
```

## 1p7q8t Egress Queue Supported Commands



### Note

- Supports CoS-based queueing with tail-drop and WRED-drop thresholds.
- Unsupported commands are included in this section as comments.

```
rqnke{/ocr"v{rg"ncp/swgwkpi" rqnke{aocrapcog"#Hqt"3r9s:v"
```

- Priority queue:

```
encuu"encuuaocrapcog"#Tgegkxgu"EqU"xcnwg"hnkvgtgf"d{"encuuaocrapcog0"
rtkqtkv{"#"Crrnkgu"vjg"encuu"ocr"vq"vjg"rtkqtkv{"swgwg
```

- Class commands for nonpriority queues numbered higher than 1—Configures queues in reverse numerical order; repeat to configure the next queue:

```
encuu"encuuaocrapcog"#Tgegkxgu"EqU"xcnwg"hnkvgtgf"d{"encuuaocrapcog0
```

- Class command for queue #1:

```
encuu"encuu/fghcwnv"#Tgegkxgu"cnntgockpkpi"EqU"xcnwg0
```

- Nonpriority queue configuration commands:

```
dcpfykfvj"rtegpv"rtegpvcig"#YTT"qt"FYTT"dcpfykfvj"cnqecvkqp0
#
#"ujcrg"cxgtcig"rtegpv"rtegpvcig"#UTT"dcpfykfvj"cnqecvkqp0
#
swgwg/dwhhgtu"tcvkq"ygkijv"#Swgwg"dwhhgt"uk|g0
```

- Nonpriority queue threshold configuration—Repeat to configure sequential thresholds:

```
#"swgwg/nkokv"ownvkrng/v{rg/dcugf"
#"Enables application of CoS, precedence, and DSCP values to a tail-drop threshold."
#
swgwg/nkokv"equ"}qpgaxcnwg"~"xcnwg"value_list} rtegpv"rtegpvcig"
#"Crrnkgu"EqU"vq"c"vckn/ftqr"vjtgujgnf"cpf"eqphkiwtgu"vjg"vjtgujgnf"rtegpvcig
#
#"swgwg/nkokv"fuer"}qpgaxcnwg"~"xcnwg"value_list} rtegpv rtegpvcig"
#"Crrnkgu"qpg"FUER"xcnwg"vq"c"vckn/ftqr"vjtgujgnf
#"cpf"eqphkiwtgu"vjg"vjtgujgnf"rtegpvcig
#
tcpfqo/fgvgev"equ/dcugf"}ciitgicvg_"
#"Gpcdngu"crnkcecvkqp"qh"EqU"xcnwg"vq"c"YTGF/ftqr"vjtgujgnf0"
#"Vjg") ciitgicvg) "mg{yqtf"cnngyu"wug"qh"vjg")xcnwg) "mg{yqtf"
```

```
#
"tcpfqo/fgvgev" fuer/dcugf"] ciitgicvg_"
"Gpcdngu" crrnkecvkqp"qh" FUEr"xcnwgu"vq" c"YTGF/ftqr"vjtgujqnf0"
"Vjg") ciitgicvg) "mg{yqtf"cnngyu"wug"qh"vjg")xcnwgu) "mg{yqtf"
#
"tcpfqo/fgvgev" rtgegfgpeg/dcugf"] ciitgicvg_"
"Gpcdngu" crrnkecvkqp"qh" rtgegfgpeg"xcnwgu"vq" c"YTGF/ftqr"vjtgujqnf0"
"Vjg") ciitgicvg) "mg{yqtf"cnngyu"wug"qh"vjg")xcnwgu) "mg{yqtf"
#
"tcpfqo/fgvgev" ownvkrng/v{rg/dcugf"] ciitgicvg_"
"Gpcdngu" crrnkecvkqp"qh" EqU. "rtgegfgpeg. "cpf" FUEr"xcnwgu
"vq" c"YTGF/ftqr"vjtgujqnf0"
"Vjg") ciitgicvg) "mg{yqtf"cnngyu"wug"qh"vjg")xcnwgu) "mg{yqtf"
#
tcpfqo/fgvgev"equ"} qpgaxcnwg"~"xcnwgu"xcnwgankuv;"rtgegpv"min_%"max_%"
"Crrnkgu"EqU"vq" c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rtgegpvcigu0"
#
"tcpfqo/fgvgev" fuer"} qpgaxcnwg"~"xcnwgu"xcnwgankuv;"rtgegpv"min_%"max_%"
"Crrnkgu" FUEr"vq" c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rtgegpvcigu0"
#
"tcpfqo/fgvgev"} rtgegfgpeg" qpgaxcnwg"~"xcnwgu"rtgegfgpeg"xcnwgankuv;"
rtgegpv min_%"max_%"
"Crrnkgu" FUEr"vq" c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rtgegpvcigu0"
```

## 1p7q4t, 2p6q4t Ingress or Egress Queue Supported Commands



### Note

- Supports CoS-based, DSCP-based, and precedence-based queueing with tail-drop and WRED-drop thresholds. Supports SRR (except WS-X6904-40G-2T) or DWRR dequeuing.
- WS-X6904-40G-2T supports [shaping](#). See the [“WS-X6904-40G-2T 1p7q4t, 2p6q4t Egress Queue Supported Commands”](#) section on page 64-31.
- Unsupported commands are included in this section as comments.

- Priority queue except WS-X6904-40G-2T with multiple priority queues:

```
encuu" encuuaoacrapcog"
"Tgegkxgu" SqU"xcnwgu"*EqU. "FUEr. "rtgegfgpeg+"xcnwgu"hknvgtgf"d{ "encuuaoacrapcog0"
rtkqtkv{ "Crrnkgu"vjg"encuu"ocr"vq"vjg"rtkqtkv{ "swgwg
"Pqv"uwrrqtvvf"kh"UTT"oqfg"ku"gpdcngf0"
#
swgwg/dwhhgtu"tcvkq"ygkijv"# "Swgwg"dwhhgt"uk|g0
#
```

- WS-X6904-40G-2T priority queues:

```
encuu" encuuaoacrapcog"
"Tgegkxgu" SqU"xcnwgu"*EqU. "FUEr. "rtgegfgpeg+"xcnwgu"hknvgtgf"d{ "encuuaoacrapcog0"
rtkqtkv{ "ngxgn"} "3"~"4i_"
"Crrnkgu"vjg"encuu"ocr"vq"qpg"qh"vjg"rtkqtkv{ "swgwg"
#
swgwg/dwhhgtu"tcvkq"ygkijv"# "Swgwg"dwhhgt"uk|g0
#
```

- Class commands for nonpriority queues numbered higher than 1—Configures queues in reverse numerical order; repeat to configure the next queue:

```
encuu" encuuaoacrapcog"
"Tgegkxgu" SqU"xcnwgu"*EqU. "FUEr. "rtgegfgpeg+"xcnwgu"hknvgtgf"d{ "encuuaoacrapcog0"
```

- Class command for queue #1:

```
encuu"encuu/fghcwnv"#"Tgegkxgu"cnn"tgockpkpi"SqU"xcnwgU"*EqU."FUER."rtgegfgpeg+0
```

- Nonpriority queue configuration commands:

```
ujcrg"cxgtcig"rtegpv"rtegpvcig"
#"Gpcdngu"UTT"qp"pqprtkqtkv{"gitguu"swgwgU0"
```

```
dcpfykfvj"tgockpkpi"rtegpv"rtegpvcig"
#"FYTT"dcpfykfvj"cnnqecvkqp0
```



**Note** On WS-X6904-40G-2T ports, the **bandwidth** command must be configured if you configure any nondefault values for any other queuing commands on the port. (CSCtz05347)

```
#
swgwg/dwhhgtu"tcvkq"ygkijv"#"Swgwg"dwhhgt"uk|g0
#
```

- Nonpriority queue threshold configuration—Repeat to configure sequential thresholds in each queue:

```
swgwg/nkokv"ownvkrng/v{rg/dcugf"
#"Enables application of CoS, precedence, and DSCP values to a tail-drop threshold."
#
swgwg/nkokv"equ"}qpgaxcnwg"~"xcnwgU"value_list} rtegpv"rtegpvcig"
#"Crrnkgu"EqU"vq"~"vckn/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjq"vjtgujqnf"rtegpvcig"
#
swgwg/nkokv"fuer"}qpgaxcnwg"~"xcnwgU"value_list} rtegpv rtegpvcig"
#"Crrnkgu"qpg"FUER"xcnwg"vq"~"vckn/ftqr"vjtgujqnf"
#"cpf"eqphkiwtgu"vjq"vjtgujqnf"rtegpvcig"
#
tcpfqo/fgvgev"equ/dcugf"]ciitgicvg_"
#"Gpcdngu"crnkcecvkqp"qh"EqU"xcnwgU"vq"~"YTGF/ftqr"vjtgujqnf0"
#"Vjq")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjq")xcnwgU)"mg{yqtf"
#
tcpfqo/fgvgev"fuer/dcugf"]ciitgicvg_"
#"Gpcdngu"crnkcecvkqp"qh"FUER"xcnwgU"vq"~"YTGF/ftqr"vjtgujqnf0"
#"Vjq")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjq")xcnwgU)"mg{yqtf"
#
tcpfqo/fgvgev"rtgegfgpeg/dcugf"]ciitgicvg_"
#"Gpcdngu"crnkcecvkqp"qh"rtgegfgpeg"xcnwgU"vq"~"YTGF/ftqr"vjtgujqnf0"
#"Vjq")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjq")xcnwgU)"mg{yqtf"
#"Vjq")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjq")xcnwgU)"mg{yqtf"
#
tcpfqo/fgvgev"ownvkrng/v{rg/dcugf"]ciitgicvg_"
#"Enables application of CoS, precedence, and DSCP values to a WRED-drop threshold."
#"Vjq")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjq")xcnwgU)"mg{yqtf"
#
tcpfqo/fgvgev"equ"}qpgaxcnwg"~"xcnwgU"xcnwgankuv;"rtegpv"min_%"max_%"
#"Crrnkgu"EqU"vq"~"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjq"vjtgujqnf"rtegpvcigu0"
#
tcpfqo/fgvgev"fuer"}qpgaxcnwg"~"xcnwgU"xcnwgankuv;"rtegpv"min_%"max_%"
#"Crrnkgu"FUER"vq"~"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjq"vjtgujqnf"rtegpvcigu0"
#
random-detect {precedence one_value | values precedence value_list} percent min_%"max_%"
#"Crrnkgu"FUER"vq"~"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjq"vjtgujqnf"rtegpvcigu0"
```



## WS-X6904-40G-2T 1p7q4t, 2p6q4t Egress Queue Supported Commands



### Note

- Supports CoS-based, DSCP-based, and precedence-based queueing with tail-drop and WRED-drop thresholds. Supports DWRR dequeuing.
- Unsupported commands are included in this section as comments.
- You configure shaping with a child policy map for the nonpriority queues that you apply to a class-default parent policy map.
- Without shaping, you configure all policy-map class commands in one policy map.

- (For shaping) Child policy map command for nonpriority queues numbered higher than 1:

```
rqnke{/ocr"v{rg"ncp/swgwkpi"ejknfarqnke{apcog"
```

- Policy map class commands for nonpriority queues numbered higher than 1—Configures nonpriority queues in reverse numerical order; repeat to configure the next queue:

```
encuu"encuuaocrapcog"
#"Tgegkxgu"SqU"xcnwgu"*EqU."FUER."rtgegfgpeg+"xcnwgu"hknvgtgf"d{"encuuaocrapcog0
```

- Configuration commands for nonpriority queues numbered higher than 1:

```
ujcrg"cxgtcig"rgtegpv"rgtegpvcig"
#"Eqphkiwtgu"ujcrkpi"qp"gitguu"pqrptkqtkv{"swgwgu0"
```

```
dcpfykfvj"tgockpkpi"rgtegpv"rgtegpvcig"
#"FYTT"dcpfykfvj"cnnqecvkqp0
```



### Note

On WS-X6904-40G-2T ports, the **bandwidth** command must be configured if you configure any nondefault values for any other queueing commands on the port. ([CSCtz05347](#))

```
#
swgw/dwhhgtu"tcvkq"ygkijv"#"Swgw/dwhhgt"uk|g0
#
```

- Nonpriority queue threshold configuration—Repeat to configure sequential thresholds in each queue:

```
swgw/nkokv"ownvkrng/v{rg/dcugf"
#"Enables application of CoS, precedence, and DSCP values to a tail-drop threshold."
#
swgw/nkokv"equ"}qpgaxcnwg"~"xcnwgu"value_list} rgtegpv"rgtegpvcig"
#"Crrnkgu"EqU"vq"c"vckn/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rgtegpvcig
#
swgw/nkokv"fuer"}qpgaxcnwg"~"xcnwgu"value_list} rgtegpv rgtegpvcig"
#"Crrnkgu"qpg"FUER"xcnwgu"vq"c"vckn/ftqr"vjtgujqnf
#"cpf"eqphkiwtgu"vjg"vjtgujqnf"rgtegpvcig
#
tcpfqo/fgvgev"equ/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"EqU"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
tcpfqo/fgvgev"fuer/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"FUER"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
tcpfqo/fgvgev"rtgegfgpeg/dcugf"]ciitgicvg_"
#"Gpcdngu"crrnkecvkqp"qh"rtgegfgpeg"xcnwgu"vq"c"YTGF/ftqr"vjtgujqnf0"
```

```
#Vjg) ciitgicvg) "mg{yqtf"cnngyu"wug"qh"vjg")xcnwg) "mg{yqtf"
#"Vjg) ciitgicvg) "mg{yqtf"cnngyu"wug"qh"vjg")xcnwg) "mg{yqtf"
#
tcpfqo/fgvgev"ownvkrng/v{rg/dcugf"}ciitgicvg_"
#"Enables application of CoS, precedence, and DSCP values to a WRED-drop threshold."
#"Vjg) ciitgicvg) "mg{yqtf"cnngyu"wug"qh"vjg")xcnwg) "mg{yqtf"
#
tcpfqo/fgvgev"equ"}qpgaxcnwg"~"xcnwg"xcnwgankuv;"rtegpv"min_%"max_%"
#"Crrnkgu"EqU"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rtegpvcigu0"
#
tcpfqo/fgvgev"fuer"}qpgaxcnwg"~"xcnwg"xcnwgankuv;"rtegpv"min_%"max_%"
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rtegpvcigu0"
#
random-detect {precedence one_value | values precedence value_list} percent min_% max_%
#"Crrnkgu"FUER"vq"c"YTGF/ftqr"vjtgujqnf"cpf"eqphkiwtgu"vjg"vjtgujqnf"rtegpvcigu0"
```

- Single priority queue without shaping:

```
encuu"encuuaocrapcog"
#"Tgegkxgu"SqU"xcnwg"*EqU."FUER."rtgegfgpeg+"xcnwg"hknvgtgf"d{"encuuaocrapcog0"
rtkqtkv{"#"Crrnkgu"vjg"encuu"ocr"vq"vjg"rtkqtkv{"swgw"
#
swgw/dwhhgtu"tcvkq"ygkijv#"Swgw"dwhhgt"uk|g0
#
```

- Multiple priority queues without shaping:

```
encuu"encuuaocrapcog"
#"Tgegkxgu"SqU"xcnwg"*EqU."FUER."rtgegfgpeg+"xcnwg"hknvgtgf"d{"encuuaocrapcog0"
rtkqtkv{"ngxgn"}"3"~"4;"
#"Crrnkgu"vjg"encuu"ocr"vq"qpg"qh"vjg"rtkqtkv{"swgw"
#
swgw/dwhhgtu"tcvkq"ygkijv#"Swgw"dwhhgt"uk|g0
#
```

- Egress priority queues (single or multiple) with shaping:

```
encuu"encuuaocrapcog"
#"Tgegkxgu"SqU"xcnwg"*EqU."FUER."rtgegfgpeg+"xcnwg"hknvgtgf"d{"encuuaocrapcog0"
rtkqtkv{"ngxgn"}"3"~"4;"rtegpv"rtegpvcig"
#"Crrnkgu"vjg"encuu"ocr"vq"qpg"qh"vjg"rtkqtkv{"swgw"
#"Eqphkiwtgu"ujcrkpi"qp"vjg"swgw"
#
swgw/dwhhgtu"tcvkq"ygkijv#"Swgw"dwhhgt"uk|g0
#
```

- (For shaping) Parent policy map command for queue #1 (class-default):

```
rqnke{/ocr"v{rg"ncp/swgwkpi"rctgpvarqnke{apcog"
```

- Class command for queue #1 (class-default):

```
encuu"encuu/fghcwnv#"Tgegkxgu"cnn"tgockpkpi"SqU"xcnwg"*EqU."FUER."rtgegfgpeg+0
ujcrg"cxgtcig"rtegpv"rtegpvcig"
#"Eqphkiwtgu"ujcrkpi"qp"gitguu"pqprtkqtkv{"swgw0"

dcpfykfvj"tgockpkpi"rtegpv"rtegpvcig"
#"FYTT"dcpfykfvj"cnqecvqkp0
```



**Note** On WS-X6904-40G-2T ports, the **bandwidth** command must be configured if you configure any nondefault values for any other queuing commands on the port. (CSCt05347)

```
#
```

```
swgwg/dwhhgtu"tcvkq"ygkijv"#Swgwg"dwhhgt"uk|g0
#
ugtckeg/rqnke{"ejknfaugtckegarqnke{"
#"Kh"ujcrkpi"ku"eqphkiwtgf"qp"vjg"qvjgt"pqprtkqtkv{"swgwg"}
```

To configure class-default thresholds, see the [“Nonpriority queue threshold configuration” information](#).

## Queueing Policy Commands Sample Configurations for Each Queue Type

- [1q2t Ingress Queue Sample Configuration](#), page 64-33
- [1q8t Ingress Queue Sample Configuration](#), page 64-33
- [2q8t Ingress Queue Sample Configuration](#), page 64-34
- [8q4t, 8q8t Ingress Queue Sample Configuration \(CoS-Based Queueing\)](#), page 64-35
- [8q4t Ingress Queue Sample Configuration \(DSCP-Based Queueing\)](#), page 64-35
- [1p1q4t Ingress Queue Sample Configuration](#), page 64-38
- [1p1q8t Ingress Queue Sample Configuration](#), page 64-38
- [1p3q8t Egress Queue Sample Configuration](#), page 64-39
- [1p7q8t Egress Queue Sample Configuration](#), page 64-40
- [1p7q4t Ingress or Egress Queue Sample Configuration \(CoS-Based Queueing\)](#), page 64-41
- [1p7q4t Ingress or Egress Queue Sample Configuration \(DSCP-Based Queueing\)](#), page 64-42



Note

These sample configurations approximate the default queueing enabled by the **auto qos default** and **platform qos queueing-only** global configuration commands.

### 1q2t Ingress Queue Sample Configuration



Note

Supports CoS-based queueing with tail-drop thresholds.

```
rqnke{/ocr"v{rg"ncp/swgwkpi"raocra3s4v"
encuu"encuu/fghcwnv"#Tgegkxgu"cnn"EqU"xcnwgU0
#
#"Eqphkiwtgu"vjtgujqnf"%3<"
swgwg/nkokv"equ"xcnwgU"2"3"5"6"rgtegpv":2"
#"Crrnkgu"EqU"xcnwgU"vq"vjtgujqnf"3"cpf"eqphkiwtgu"vjg"vjtgujqnf"rgtegpvcig
#
#"Qvjgt"vjtgujqnfu"wpeqphkiwtgf="fghcwnv"vq"322' "
#"Tgockpkpi"EqU"xcnwgU"ctg"pqv"gzrnkekv{"eqphkiwtgf<
#"fghcwnv"vq"vjtgujqnf": "cv"322'}
```

### 1q8t Ingress Queue Sample Configuration



Note

Supports CoS-based queueing with tail-drop thresholds.

```

rqnke{ /ocr"v{rg"ncp/swgwkpi"raocra3s:v"
 encuu"encuu/fghcwnv#"Tgegkxgu"cnn"EqU"xcnwgu0
 #
 #"Eqphkiwtgu"vjtgujgnf"%3<"
 swgwg/nkokv"equ"2"rgtegpv"72"
 #"Crrnkgu"EqU"2"vq"vjtgujgnf"3"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcig
 #
 #"Eqphkiwtgu"vjtgujgnf"%4<"
 swgwg/nkokv"equ"xcnwgu"3"4"5"6"rgtegpv"82"
 #"Crrnkgu"EqU"3"."4"."5"."6"vq"vjtgujgnf"4"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcig
 #
 #"Eqphkiwtgu"vjtgujgnf"%5<"
 swgwg/nkokv"equ"xcnwgu"8"9"rgtegpv":2"
 #"Crrnkgu"EqU"8"cpf"9"vq"vjtgujgnf"5"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcig
 #
 #"Qvjgt"vjtgujgnfu"wpeqphkiwtgf="fghcwnv"vq"322'"
 #"EqU"7"ku"pqv"gzrnkekn{"eqphkiwtgf<"fghcwnv"vq"vjtgujgnf": "cv"322'

```

## 2q8t Ingress Queue Sample Configuration



Note

Supports CoS-based queueing with tail-drop thresholds.

```

encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocraequa7"
 ocvej"equ"7"
#
rqnke{ /ocr"v{rg"ncp/swgwkpi"raocra4s:v#"Hqt"4s:v
#
 #"Eqphkiwtgu"swgwg"%4<"
 encuu"eaocraequa7"
 #"Tgegkxgu"SqU"xcnwgu"*EqU"."FUER"."rtgegfgpeg+"xcnwgu"hknvgtgf"d{"eaocraequa70
 #
 dcpfykfvj"rgtegpv"32#"YTT"dcpfykfvj"cnnqecvkqp0
 swgwg/dwhhgtu"tcvkq"42#"Swgwg"dwhhgt"uk|g0
 #
 swgwg/nkokv"equ"7"rgtegpv"322"
 #"Crrnkgu"EqU"7"vq"vjtgujgnf"3"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcig
 #
 #"Eqphkiwtgu"swgwg"%3<"
 encuu"encuu/fghcwnv#"Tgegkxgu"cnn"tgoekpkpi"EqU"xcnwgu0
 #
 dcpfykfvj"rgtegpv";2#"YTT"dcpfykfvj"cnnqecvkqp0
 #
 swgwg/dwhhgtu"tcvkq"42#"Swgwg"dwhhgt"uk|g0
 #
 #"Eqphkiwtgu"vjtgujgnf"%3<"
 swgwg/nkokv"equ"xcnwgu"2"3"rgtegpv"92"
 #"Crrnkgu"EqU"2"3"vq"vjtgujgnf"3"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcig
 #
 #"Eqphkiwtgu"vjtgujgnf"%4<"
 swgwg/nkokv"equ"xcnwgu"4"5"rgtegpv":2"
 #"Crrnkgu"EqU"4"5"vq"vjtgujgnf"4"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcig
 #
 #"Eqphkiwtgu"vjtgujgnf"%5<"
 swgwg/nkokv"equ"6"rgtegpv";2"
 #"Crrnkgu"EqU"6"vq"vjtgujgnf"5"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcig
 #
 #"EqU"8"cpf"9"fghcwnv"vq"vjtgujgnf"6"cv"322'

```

## 8q4t, 8q8t Ingress Queue Sample Configuration (CoS-Based Queueing)



### Note

- Supports CoS-based, DSCP-based, and precedence-based queueing with tail-drop and WRED-drop thresholds. This sample configures CoS-based queueing.

```
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocraequa7"
ocvej"equ"7"
#
rqnke{/ocr"v{rg"ncp/swgwkpi"raocra:s6vaequa:s:v#"Hqt":s6v"EqU/dcugf"swgwkpi"cpf":s:v

#"Eqphkiwtgu"swgw"%:<"
encuu"eaocraequa7"#"Tgegkxgu"EqU"xcnwgu"xcnwgu"hknvgtgf"d{"eaocraequa70
#
dcpfykfvj"rgtegpv";2#"YTT"dcpfykfvj"cnnqecvkqp0
swgw/dwhhgtu"tcvkq"42#"Swgw"dwhhgt"uk|g0
#
#"EqU"7"fghcwnvu"vq"vjtgujqnf"6"cv"322' "
#
#"Eqphkiwtgu"swgw"%3<"
encuu"encuu/fghcwnv
#"Tgegkxgu"cnn"tgockpkpi"EqU"xcnwgu0"
#
dcpfykfvj"rgtegpv"32#"YTT"dcpfykfvj"cnnqecvkqp0
swgw/dwhhgtu"tcvkq":2#"Swgw"dwhhgt"uk|g0
#
#"Eqphkiwtgu"vjtgujqnf"%3<"
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
tcpfqo/fgvgev"equ"xcnwgu"2"3"rgtegpv"62"92"
#
#"Eqphkiwtgu"vjtgujqnf"%4<"
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
tcpfqo/fgvgev"equ"xcnwgu"4"5"rgtegpv"62":2"
#
#"Eqphkiwtgu"vjtgujqnf"%5<"
tcpfqo/fgvgev"equ/dcugf"
#
tcpfqo/fgvgev"equ"xcnwgu"6"rgtegpv"72";2"
#
#"Eqphkiwtgu"vjtgujqnf"%6<"
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
tcpfqo/fgvgev"equ"xcnwgu"8"9"rgtegpv"72"322"
```

## 8q4t Ingress Queue Sample Configuration (DSCP-Based Queueing)



### Note

- Supports CoS-based, DSCP-based, and precedence-based queueing with tail-drop and WRED-drop thresholds. This sample configures DSCP-based queueing.

```

encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocraequa7afuera62a68"
 ocvej"equ"7"
 #
 ocvej"fuer"62"68"
 #NOTE: Enables DSCP-based queueing on the port in the direction of the queueing policy.
#
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocrafuera6:/85"
 ocvej"fuer"6:"6;"72"73"74"75"76"77"
 ocvej"fuer"78"79"7:"7;"82"83"84"85"

 #NOTE: Enables DSCP-based queueing on the port in the direction of the queueing policy.
#
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocrafuera54a56/5:"
 ocvej"fuer"54"56"57"58"59"5:"
 #NOTE: Enables DSCP-based queueing on the port in the direction of the queueing policy.
#"
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocrafuera46a48a4:a52"
 ocvej"fuer"46"48"4:"52"
 #NOTE: Enables DSCP-based queueing on the port in the direction of the queueing policy.
#
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocrafuera3:a42a44"
 ocvej"fuer"3:"42"44"
 #NOTE: Enables DSCP-based queueing on the port in the direction of the queueing policy.
#
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocrafuera32a34a36"
 ocvej"fuer"32"34"36"
 #NOTE: Enables DSCP-based queueing on the port in the direction of the queueing policy.
#
rqnke{/ocr"v{rg"ncp/swgwkpi"raocra:s6vafuer"#Hqt":s6v"FUER/dcugf"swgwkpi

 #Eqphkiwtgu"swgwg"%:<"
 encuu"eaocraequa7afuera62a68"
 #Tgegkxgu"SqU"xcnwgu"*EqU."FUER."rtgegfgpeg+"xcnwgu"hknvgtgf"d{"eaocraequa70
 #
 dcpfykfvj"rttegpv";2#"YTT"dcpfykfvj"cnnqecvkqp0
 swgwg/dwhhgtu"tcvkq"42#"Swgwg"dwhhgt"uk|g0
 #
 #EqU"7"cpf"FUER"62."68"fghcwnv"vq"vjtgujqnf"6"cv"322' "
 #
 #Eqphkiwtgu"swgwg"%9<
 encuu"eaocrafuera6:/85"
 #Tgegkxgu"SqU"xcnwgu"*EqU."FUER."rtgegfgpeg+"xcnwgu"hknvgtgf"d{"eaocrafuera6:/850
 #
 dcpfykfvj"tgockpkpi"rttegpv"32#"YTT"dcpfykfvj"cnnqecvkqp0
 swgwg/dwhhgtu"tcvkq"32#"Swgwg"dwhhgt"uk|g0
 #
 #FUER"6:/85"fghcwnv"vq"vjtgujqnf"6"cv"322' "
 #
 #Eqphkiwtgu"swgwg"%8<
 encuu"eaocrafuera54a56/5:"
 #Tgegkxgu"SqU"xcnwgu"*EqU."FUER."rtgegfgpeg+"xcnwgu"hknvgtgf"d{"eaocrafuera54a56/5:0
 #
 dcpfykfvj"tgockpkpi"rttegpv"32#"YTT"dcpfykfvj"cnnqecvkqp0
 swgwg/dwhhgtu"tcvkq"32#"Swgwg"dwhhgt"uk|g0
 #
 #FUER"54."56/5:"fghcwnv"vq"vjtgujqnf"6"cv"322' "
 #
 #Eqphkiwtgu"swgwg"%7<
 encuu"eaocrafuera46a48a4:a52"
 ! Receives QoS values (CoS, DSCP, precedence) values filtered by c_map_dscp_24_26_28_30."
 #
 dcpfykfvj"tgockpkpi"rttegpv"32#"YTT"dcpfykfvj"cnnqecvkqp0
 swgwg/dwhhgtu"tcvkq"32#"Swgwg"dwhhgt"uk|g0

```

```

#
"FUER"46."48."4:."52"fghcwnv"vq"vjtgujqnf"6"cv"322' "
#
"Eqphkiwtgu"swgw "%6<
encuu"eaocrafuera3:a42a44"
"Tgegkxgu"SqU"xcnwgu"*EqU."FUER."rtgegfgpeg+"xcnwgu"hknvgtgf"d{"eaocrafuera3:a42a440"
#
dcpfykfvj"tgoackpki"rtegpv"32"#"YTT"dcpfykfvj"cnnqecvkqp0
swgw/dwhhgtu"tcvkq"32"#"Swgw"dwhhgt"uk|g0
#
"Eqphkiwtgu"vjtgujqnf"%3<"
tcpfqo/fgvgev"fuer/dcugf"
tcpfqo/fgvgev"fuer"42"rtegpv"92"322"
tcpfqo/fgvgev"fuer"44"rtegpv"92"322"
tcpfqo/fgvgev"fuer"3:"rtegpv"92"322"
#
"Eqphkiwtgu"swgw "%5<
encuu"eaocrafuera32a34a36"
"Tgegkxgu"SqU"xcnwgu"*EqU."FUER."rtgegfgpeg+"xcnwgu"hknvgtgf"d{"eaocrafuera32a34a360"
#
dcpfykfvj"tgoackpki"rtegpv"32"#"YTT"dcpfykfvj"cnnqecvkqp0
swgw/dwhhgtu"tcvkq"32"#"Swgw"dwhhgt"uk|g0
#
"Eqphkiwtgu"vjtgujqnf"%3<"
tcpfqo/fgvgev"fuer/dcugf"
tcpfqo/fgvgev"fuer"36"rtegpv"92"322"
tcpfqo/fgvgev"fuer"34"rtegpv"92"322"
tcpfqo/fgvgev"fuer"32"rtegpv"92"322"
#
"Eqphkiwtgu"swgw "%3<"
encuu"encuu/fghcwnv
"Tgegkxgu"cnn"tgoackpki"SqU"xcnwgu"*EqU."FUER."rtgegfgpeg+0"
#
dcpfykfvj"rtegpv"32"#"YTT"dcpfykfvj"cnnqecvkqp0
swgw/dwhhgtu"tcvkq":2"#"Swgw"dwhhgt"uk|g0
#
"Eqphkiwtgu"vjtgujqnf"%3<"
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
tcpfqo/fgvgev"equ"xcnwgu"2"3"rtegpv"62"92"
#
"Eqphkiwtgu"vjtgujqnf"%4<"
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
tcpfqo/fgvgev"equ"xcnwgu"4"5"rtegpv"62":2"
#
"Eqphkiwtgu"vjtgujqnf"%5<"
tcpfqo/fgvgev"equ/dcugf"
tcpfqo/fgvgev"equ"xcnwgu"6"rtegpv"72":2"
#
"Eqphkiwtgu"vjtgujqnf"%6<
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
tcpfqo/fgvgev"equ"xcnwgu"8"9"rtegpv"72"322"
"FUER"xcnwgu"fghcwnv"vq"vjku"vjtgujqnf
#"2/;."33."35."37/39."3;."43."45."47."49."4;."53."55."5;."63/67."69

```

## 1p1q4t Ingress Queue Sample Configuration

**Note**

Supports CoS-based queueing with tail-drop thresholds.

```
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocraequa7"
 ocvej"equ"7"
#
rqnke{/ocr"v{rg"ncp/swgwkpi"raocra3r3s6v#"Hqt"3r3s6v
#
#"Eqphkiwtgu"vjpg"rtkqtkv{"swgwg<
encuu"eaocraequa7#"Tgegkxgu"EqU"xcnwgu"hknvgtgf"d{"eaocraequa70
 rtkqtkv{"#"Crrnkgu"vjpg"encuu"ocr"vq"vjpg"rtkqtkv{"swgwg
#
#"Eqphkiwtgu"swgwg"%3<
encuu"encuu/fghcwnv#"Tgegkxgu"cnn"tgockpkpi"EqU"xcnwgu0
#
#"Eqphkiwtgu"vjtgujqnf"%3
swgwg/nkokv"equ"xcnwgu"2"3"rgtegpv"92"
#"Crrnkgu"EqU"2"3"vq"vjtgujqnf"3"cpf"eqphkiwtgu"vjpg"vjtgujqnf"rgtegpvcig
#
#"Eqphkiwtgu"vjtgujqnf"%4
swgwg/nkokv"equ"xcnwgu"4"5"rgtegpv":2"
#"Crrnkgu"EqU"4"5"vq"vjtgujqnf"4"cpf"eqphkiwtgu"vjpg"vjtgujqnf"rgtegpvcig
#
#"Eqphkiwtgu"vjtgujqnf"%5
swgwg/nkokv"equ"6"rgtegpv";2"
#"Crrnkgu"EqU"6"vq"vjtgujqnf"5"cpf"eqphkiwtgu"vjpg"vjtgujqnf"rgtegpvcig
#
#"EqU"8"cpf"9"fghcwnv"vq"vjtgujqnf"6"cv"322'
```

## 1p1q8t Ingress Queue Sample Configuration

**Note**

Supports CoS-based queueing with tail-drop or WRED-drop thresholds.

```
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocraequa7"
 ocvej"equ"7"
#
rqnke{/ocr"v{rg"ncp/swgwkpi"raocra3r3s:v#"Hqt"3r3s:v
#
#"Eqphkiwtgu"vjpg"rtkqtkv{"swgwg<
encuu"eaocraequa7#"Tgegkxgu"EqU"xcnwgu"hknvgtgf"d{"eaocraequa70
 rtkqtkv{"#"Crrnkgu"vjpg"encuu"ocr"vq"vjpg"rtkqtkv{"swgwg
#
encuu"encuu/fghcwnv#"Tgegkxgu"cnn"tgockpkpi"EqU"xcnwgu0
#
tcpfqo/fgvgev"equ/dcugf"
#"Gpcdngu"crrnkecvkqp"qh"EqU"xcnwgu"vq"c"YTFG/ftqr"vjtgujqnf0"
#
#"Eqphkiwtgu"vjtgujqnf"%3
tcpfqo/fgvgev"equ"2"rgtegpv"62"92"
#"Crrnkgu"EqU"vq"YTFG/ftqr"vjtgujqnf"3"cpf"eqphkiwtgu"vjpg"vjtgujqnf"rgtegpvcigu0"
#
#"Eqphkiwtgu"vjtgujqnf"%4
tcpfqo/fgvgev"equ"3"rgtegpv"62"92"
#"Crrnkgu"EqU"vq"YTFG/ftqr"vjtgujqnf"4"cpf"eqphkiwtgu"vjpg"vjtgujqnf"rgtegpvcigu0"
#
```



```
#"Eqphkiwtgu"vjtgujgnf"%5
tcpfqo/fgvgev"equ"4"rgtegpv"72":2"
#"Crrnkgu"EqU"vq"YTFG/ftqr"vjtgujgnf"5"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcigu0"
#
#"Eqphkiwtgu"vjtgujgnf"%6
tcpfqo/fgvgev"equ"5"rgtegpv"72":2"
#"Crrnkgu"EqU"vq"YTFG/ftqr"vjtgujgnf"6"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcigu0"
#
#"Eqphkiwtgu"vjtgujgnf"%7
tcpfqo/fgvgev"equ"6"rgtegpv"82":2"
#"Crrnkgu"EqU"vq"YTFG/ftqr"vjtgujgnf"7"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcigu0"
#
#"Eqphkiwtgu"vjtgujgnf"%8
tcpfqo/fgvgev"equ"8"rgtegpv"82":2"
#"Crrnkgu"EqU"vq"YTFG/ftqr"vjtgujgnf"8"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcigu0"
#
#"Eqphkiwtgu"vjtgujgnf"%9
tcpfqo/fgvgev"equ"9"rgtegpv"92"322"
#"Crrnkgu"EqU"vq"YTFG/ftqr"vjtgujgnf"9"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcigu0"
```

## 1p3q8t Egress Queue Sample Configuration



### Note

Supports CoS-based queuing with tail-drop and WRED-drop thresholds.

```
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocraequa4a5a6"
 ocvej"equ"4"5"6
#
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocraequa7"
 ocvej"equ"7"
#
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocraequa8a9"
 ocvej"equ"8"9
#
rqnke{/ocr"v{rg"ncp/swgwkpi"raocra3r5s:v"
#
#"Eqphkiwtgu"vjpg"rtkqtkv{"swgwg<
encuu"eaocraequa7"#"Tgegkxgu"EqU"xcnwgu"hknvgtgf"d{"eaocraequa70
 rtkqtkv{"#"Crrnkgu"vjpg"encuu"ocr"vq"vjpg"rtkqtkv{"swgwg
#
#"Eqphkiwtgu"swgwg"%5"hqt"3r5s:v<"
encuu"eaocraequa8a9"
#"Tgegkxgu"EqU"xcnwgu"xcnwgu"hknvgtgf"d{"eaocraequa8a90
#
 dcpfykfvj"tgockpki"rgtegpv"62"#"YTT"dcpfykfvj"cnnqecvkqp0
 swgwg/dwhhgtu"tcvkq"37"#"Swgwg"dwhhgt"uk|g0
#
#"Eqphkiwtgu"vjtgujgnf"%3<"
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
#"Vjpg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjpg")xcnwgu)"mg{yqtf"
#
 tcpfqo/fgvgev"equ"xcnwgu"8"9"rgtegpv"92"322
#
#"Eqphkiwtgu"swgwg"%4"hqt"3r5s:v<"
encuu"eaocraequa4a5a6"
#"Tgegkxgu"EqU"xcnwgu"xcnwgu"hknvgtgf"d{"eaocraequa4a5a60
#
 dcpfykfvj"tgockpki"rgtegpv"52"#"YTT"dcpfykfvj"cnnqecvkqp0
 swgwg/dwhhgtu"tcvkq"42"#"Swgwg"dwhhgt"uk|g0
#
#"Eqphkiwtgu"vjtgujgnf"%3<"
```

```

tcpfqo/fgvgev"equ/dcugf"
#
tcpfqo/fgvgev"equ"4"rttegpv"62"92
#"Crrnkgu"EqU"vq"YTFG/ftqr"vjtgujqnf"3"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcigu0"
#
#"Eqphkiwtgu"vjtgujqnf"%4<"
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
tcpfqo/fgvgev"equ"xcnwgu"5"6"rttegpv"92"322"
#"Crrnkgu"EqU"vq"YTFG/ftqr"vjtgujqnf"4"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcigu0"
#
#"Eqphkiwtgu"swgw%"%3<"
encuu"encuu/fghcwnv
#"Tgegkxgu"cnn"tgockpkpi"EqU"xcnwgu0"
#
dcpfykfvj"tgockpkpi"rttegpv"47"#"YTT"dcpfykfvj"cnnqecvkqp0
swgw/dwhhgtu"tcvkq"42"#"Swgw"dwhhgt"uk|g0
#
#"Eqphkiwtgu"vjtgujqnf"%3<"
tcpfqo/fgvgev"equ/dcugf"
#
tcpfqo/fgvgev"equ"2"rttegpv"62"92"
#"Crrnkgu"EqU"vq"YTFG/ftqr"vjtgujqnf"3"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcigu0"
#
#"Eqphkiwtgu"vjtgujqnf"%4<"
tcpfqo/fgvgev"equ/dcugf"
#
tcpfqo/fgvgev"equ"3"rttegpv"92"322"
#"Crrnkgu"EqU"vq"YTFG/ftqr"vjtgujqnf"4"cpf"eqphkiwtgu"vjg"vjtgujqnf"rttegpvcigu0"

```

## 1p7q8t Egress Queue Sample Configuration



### Note

Supports CoS-based queueing with tail-drop and WRED-drop thresholds.

```

encuu/ocr"v{rg"ncp/swgwkp"ocvej/cp{"eaocraequa4a5a6"
ocvej"equ"4"5"6
#
encuu/ocr"v{rg"ncp/swgwkp"ocvej/cp{"eaocraequa7"
ocvej"equ"7"
#
encuu/ocr"v{rg"ncp/swgwkp"ocvej/cp{"eaocraequa8a9"
ocvej"equ"8"9
#
rqnke{/ocr"v{rg"ncp/swgwkp"raocra3r9s:v"
#
#"Eqphkiwtgu"vjg"rtkqtkv{"swgw<
encuu"eaocraequa7"#"Tgegkxgu"EqU"xcnwgu"hknvgtgf"d{"eaocraequa70
rtkqtkv{"#"Crrnkgu"vjg"encuu"ocr"vq"vjg"rtkqtkv{"swgw
#
#"Eqphkiwtgu"swgw%"%9<"
encuu"eaocraequa8a9"
#"Tgegkxgu"EqU"xcnwgu"xcnwgu"hknvgtgf"d{"eaocraequa8a90
#
dcpfykfvj"tgockpkpi"rttegpv"62"#"YTT"dcpfykfvj"cnnqecvkqp0
swgw/dwhhgtu"tcvkq"37"#"Swgw"dwhhgt"uk|g0
#
#"Eqphkiwtgu"vjtgujqnf"%3<"
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"

```

```
#
 tcpfqo/fgvgev"equ"xcnwgu"8"9"rgtegpv"92"322
#
#"Eqphkiwtgu"swgw%"8"hqt"3r9s:v<"
encuu"eaocraequa4a5a6"
#"Tgegkxgu"EqU"xcnwgu"xcnwgu"hknvgtgf"d{"eaocraequa4a5a60
#
 dcpfykfvj"tgockpkpi"rgtegpv"52"#"YTT"dcpfykfvj"cnnqecvkqp0
 swgw/dwhhgtu"tcvkq"42"#"Swgw"dwhhgt"uk|g0
#
#"Eqphkiwtgu"vjtgujgnf"%3<"
 tcpfqo/fgvgev"equ/dcugf"
#
 tcpfqo/fgvgev"equ"4"rgtegpv"62"92
#"Crrnkgu"EqU"vq"YTGF/ftqr"vjtgujgnf"3"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcigu0"
#
#"Eqphkiwtgu"vjtgujgnf"%4<"
 tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjpg)"xcnwgu)"mg{yqtf"
#
 tcpfqo/fgvgev"equ"xcnwgu"5"6"rgtegpv"92"322"
#"Crrnkgu"EqU"vq"YTGF/ftqr"vjtgujgnf"4"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcigu0"
#
#"Eqphkiwtgu"swgw%"3<"
encuu"encuu/fghcwnv
#"Tgegkxgu"cnn"tgockpkpi"EqU"xcnwgu0"
#
 dcpfykfvj"tgockpkpi"rgtegpv"47"#"YTT"dcpfykfvj"cnnqecvkqp0
 swgw/dwhhgtu"tcvkq"72"#"Swgw"dwhhgt"uk|g0
#
#"Eqphkiwtgu"vjtgujgnf"%3<"
 tcpfqo/fgvgev"equ/dcugf"
#
 tcpfqo/fgvgev"equ"2"rgtegpv"62"92"
#"Crrnkgu"EqU"vq"YTGF/ftqr"vjtgujgnf"3"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcigu0"
#
#"Eqphkiwtgu"vjtgujgnf"%4<"
 tcpfqo/fgvgev"equ/dcugf"
#
 tcpfqo/fgvgev"equ"3"rgtegpv"92"322
#"Crrnkgu"EqU"vq"YTGF/ftqr"vjtgujgnf"4"cpf"eqphkiwtgu"vjpg"vjtgujgnf"rgtegpvcigu0"
```

## 1p7q4t Ingress or Egress Queue Sample Configuration (CoS-Based Queueing)



### Note

Supports CoS-based, DSCP-based, and precedence-based queueing with tail-drop and WRED-drop thresholds. Supports SRR (except WS-X6904-40G-2T) or DWRR dequeueing. This sample configures CoS-based queueing.

```
encuu/ocr"v{rg"ncp/swgwkp"ocvej/cp{"eaocraequa7"
 ocvej"equ"7"
#
rqnke{/ocr"v{rg"ncp/swgwkp"raocra3r9s6vaequ

#"Eqphkiwtgu"vjpg"rtkqtkv{"swgw<
encuu"eaocraequa7"#"Tgegkxgu"EqU"xcnwgu"hknvgtgf"d{"eaocraequa70
 rtkqtkv{"#"Crrnkgu"vjpg"encuu"ocr"vq"vjpg"rtkqtkv{"swgw
#
#"Eqphkiwtgu"swgw%"3<"
encuu"encuu/fghcwnv
#"Tgegkxgu"cnn"tgockpkpi"EqU"xcnwgu0"
```

```
#
dcpfykfvj"tgoackpi"rtgepv":7#"YTT"dcpfykfvj"cnnqecvkqp0
```



**Note** On WS-X6904-40G-2T ports, the **bandwidth** command must be configured if you configure any nondefault values for any other queuing commands on the port. (CSCtz05347)

```
swgw/dwhhgtu"tcvkq"32#"Swgw"dwhhgt"uk|g0
#
#"Eqphkiwtgu"vjtgujgnf"%3<"
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
tcpfqo/fgvgev"equ"xcnwgu"2"3"rtgepv"62"92"
#
#"Eqphkiwtgu"vjtgujgnf"%4<"
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
tcpfqo/fgvgev"equ"xcnwgu"4"5"rtgepv"62":2"
#
#"Eqphkiwtgu"vjtgujgnf"%5<"
tcpfqo/fgvgev"equ/dcugf"
#
tcpfqo/fgvgev"equ"xcnwgu"6"rtgepv"72";2"
#
#"Eqphkiwtgu"vjtgujgnf"%6<"
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
#"Vjg")ciitgicvg)"mg{yqtf"cnnqyu"wug"qh"vjg")xcnwgu)"mg{yqtf"
#
tcpfqo/fgvgev"equ"xcnwgu"8"9"rtgepv"72"322"
```

## 1p7q4t Ingress or Egress Queue Sample Configuration (DSCP-Based Queuing)



**Note**

Supports CoS-based, DSCP-based, and precedence-based queueing with tail-drop and WRED-drop thresholds. Supports SRR (except WS-X6904-40G-2T) or DWRR dequeuing. This sample configures DSCP-based queueing.

```
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocraequa7afuera62a68"
ocvej"equ"7"
#
ocvej"fuer"62"68"
#"NOTE: Enables DSCP-based queueing on the port in the direction of the queueing policy.
#
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocrafuera6:/85"
ocvej"fuer"6:"6;"72"73"74"75"76"77"
ocvej"fuer"78"79"7:"7;"82"83"84"85"
#"NOTE: Enables DSCP-based queueing on the port in the direction of the queueing policy.
#
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocrafuera54a56/5:"
ocvej"fuer"54"56"57"58"59"5:"
#"NOTE: Enables DSCP-based queueing on the port in the direction of the queueing policy.
#"
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocrafuera46a48a4:a52"
ocvej"fuer"46"48"4:"52"
#"NOTE: Enables DSCP-based queueing on the port in the direction of the queueing policy.
#
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocrafuera3:a42a44"
```

```

ocvej"fuer"3:"42"44"
#NOTE: Enables DSCP-based queueing on the port in the direction of the queueing policy.
#
encuu/ocr"v{rg"ncp/swgwkpi"ocvej/cp{"eaocrafuera32a34a36"
ocvej"fuer"32"34"36"
#NOTE: Enables DSCP-based queueing on the port in the direction of the queueing policy.
#
rqnke{/ocr"v{rg"ncp/swgwkpi"raocra3r9s6vafuer"

#Eqphkiwtgu"vjg"rtkqtkv{"swgwg<
encuu"eaocraequa7afuera62a68"#Tgegkxgu"EqU"xcnwgu"hknvgtgf"d{"eaocraequa7afuera62a680
rtkqtkv{"#Crrnkgu"vjg"encuu"ocr"vq"vjg"rtkqtkv{"swgwg
#
#"Eqphkiwtgu"swgwg"%9<
encuu"eaocrafuera6:/85"
#"Tgegkxgu"SqU"xcnwgu"*EqU."FUER."rtgegfgpeg+"xcnwgu"hknvgtgf"d{"eaocrafuera6:/850
#
dcpfykfvj"tgockpkpi"rgtegpv"32"#YTT"dcpfykfvj"cnnqecvkqp0

```




---

**Note** On WS-X6904-40G-2T ports, the **bandwidth** command must be configured if you configure any nondefault values for any other queueing commands on the port. (CSCtz05347)

---

```

swgwg/dwhhgtu"tcvkq"32"#Swgwg"dwhhgt"uk|g0
#
#"FUER"6:/85"fghcwnv"vq"vjtgujqnf"6"cv"322' "
#
#"Eqphkiwtgu"swgwg"%8<
encuu"eaocrafuera54a56/5:"
#"Tgegkxgu"SqU"xcnwgu"*EqU."FUER."rtgegfgpeg+"xcnwgu"hknvgtgf"d{"eaocrafuera54a56/5:0
#
dcpfykfvj"tgockpkpi"rgtegpv"32"#YTT"dcpfykfvj"cnnqecvkqp0
swgwg/dwhhgtu"tcvkq"32"#Swgwg"dwhhgt"uk|g0
#
#"FUER"54."56/5:"fghcwnv"vq"vjtgujqnf"6"cv"322' "
#
#"Eqphkiwtgu"swgwg"%7<
encuu"eaocrafuera46a48a4:a52"
#"Tgegkxgu"SqU"xcnwgu"*EqU."FUER."rtgegfgpeg+"xcnwgu"
#"hknvgtgf"d{"eaocrafuera46a48a4:a520"
#
dcpfykfvj"tgockpkpi"rgtegpv"32"#YTT"dcpfykfvj"cnnqecvkqp0
swgwg/dwhhgtu"tcvkq"32"#Swgwg"dwhhgt"uk|g0
#
#"Eqphkiwtgu"vjtgujqnf"%3
swgwg/nkokv"fuer"xcnwgu"46"52"rgtegpv"322"
#
#"Eqphkiwtgu"vjtgujqnf"%4
swgwg/nkokv"fuer"4:"rgtegpv"322"
#
#"Eqphkiwtgu"vjtgujqnf"%5
swgwg/nkokv"fuer"48"rgtegpv"322"
#
#"Eqphkiwtgu"swgwg"%6<
encuu"eaocrafuera3:a42a44"
#"Tgegkxgu"SqU"xcnwgu"*EqU."FUER."rtgegfgpeg+"xcnwgu"hknvgtgf"d{"eaocrafuera3:a42a440"
#
dcpfykfvj"tgockpkpi"rgtegpv"32"#YTT"dcpfykfvj"cnnqecvkqp0
swgwg/dwhhgtu"tcvkq"32"#Swgwg"dwhhgt"uk|g0
#
#"Eqphkiwtgu"vjtgujqnf"%3<"
tcpfqo/fgvgev"fuer/dcugf"

```

```

tcpfqo/fgvgev"fuer"42"rgtegpv"92"322"
#
#"Eqphkiwtgu"vjtgujqnf"%4<"
tcpfqo/fgvgev"fuer/dcugf"
tcpfqo/fgvgev"fuer"44"rgtegpv"92"322"
#
#"Eqphkiwtgu"vjtgujqnf"%5<"
tcpfqo/fgvgev"fuer/dcugf"
tcpfqo/fgvgev"fuer"3:"rgtegpv"92"322"
#
#"Eqphkiwtgu"swgwg"%5<"
encuu"eaocrafuera32a34a36"
! Receives QoS values (CoS, DSCP, precedence) values filtered by ! c_map_dscp_10_12_14."
#
dcpfykfvj"tgockpki"rgtegpv"32"#"YTT"dcpfykfvj"cnnqecvkqp0
swgwg/dwhhgtu"tcvkq"32"#"Swgwg"dwhhgt"uk|g0
#
#"Eqphkiwtgu"vjtgujqnf"%3<"
tcpfqo/fgvgev"fuer/dcugf"
tcpfqo/fgvgev"fuer"36"rgtegpv"92"322"
tcpfqo/fgvgev"fuer"34"rgtegpv"92"322"
tcpfqo/fgvgev"fuer"32"rgtegpv"92"322"
#
#"Eqphkiwtgu"swgwg"%3<"
encuu"encuu/fghcwnv
#"Tgegkxgu"cnn"tgockpki"SqU"xcnwgu"*EqU."FUER."rtgefgpeg+0"
#
dcpfykfvj"tgockpki"rgtegpv"47"#"YTT"dcpfykfvj"cnnqecvkqp0
swgwg/dwhhgtu"tcvkq"32"#"Swgwg"dwhhgt"uk|g0
#
#"Eqphkiwtgu"vjtgujqnf"%3<"
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
tcpfqo/fgvgev"equ"xcnwgu"2"3"rgtegpv"62"92"
#
#"Eqphkiwtgu"vjtgujqnf"%4<"
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
tcpfqo/fgvgev"equ"xcnwgu"4"5"rgtegpv"62":2"
#
#"Eqphkiwtgu"vjtgujqnf"%5<"
tcpfqo/fgvgev"equ/dcugf"
tcpfqo/fgvgev"equ"xcnwgu"6"rgtegpv"72";2"
#
#"Eqphkiwtgu"vjtgujqnf"%6<"
#"Tgockpki"FUER"xcnwgu"fghcwnv"vq"vjku"vjtgujqnf
#"2/;. "33."35."37/39."3;. "43."45."47."49."4;. "53."55."5;. "63/67."69
#
tcpfqo/fgvgev"equ/dcugf"ciitgicvg"
tcpfqo/fgvgev"equ"xcnwgu"8"9"rgtegpv"72"322"

```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

Participate in the [Technical Documentation Ideas forum](#)

# Queuing on FEX

QoS on FEX host ports is enabled by default with default queuing configuration. Queuing on FEX provides the facility to configure your own queuing model on FEX ports. Queuing is supported in the egress direction only. The queuing features are configurable through the `lan-queuing` policies and do not support any legacy queuing commands. Priority queue configuration is optional. Queuing on FEX is supported in DSCP mode only. When applied to an interface the configuration will be propagated to all the interfaces of a member FEX, in case of a stack.

DoD certification mandates the queuing configuration for supported features. These features are as follows:

- Priority queuing
- Queue bandwidth
- DSCP to queue map
- Queue buffer

## Priority Queuing

This example shows how to configure priority queuing:

```
Tqwgvt% "ujqy"rqnke{ /ocr"v{rg"ncp/swgwkpi"nvguv
" "Rqnke{ "Ocr"v{rg"ncp/swgwkpi"nvguv
" " "Encuu"nvguv
" " " "dcpfykfvj"tgoackpki"32"*' +
" " " "Encuu"nvguv3
" " " "rtkgtkv{
" " " "Encuu"encuu/fghcwnv
```

## Queue Bandwidth

This example shows how to configure queue bandwidth percentage:

```
Tqwgvt% "ujqy"rqnke{ /ocr"v{rg"ncp/swgwkpi"nvguv
" "Rqnke{ "Ocr"v{rg"ncp/swgwkpi"nvguv
" " "Encuu"nvguv
" " " "dcpfykfvj"tgoackpki"32"*' +
" " " "Cxtgicg"tvcg"Vtchhke"Ujcrkpi
" " " "ekt"52'
" " " "Encuu"nvguv3
" " " "rtkgtkv{
" " " "Encuu"encuu/fghcwnv
, Fge"37"2: <5; <640757<"242<"22"22"22"86"22"26"23"86"22"22"22"86"22"27"23"86"
000f000f000f000f
, Fge"37"2: <5; <640757<"252<"22"22"22"86"
```

## DSCP to Queue Map

The ability to map a DSCP to a particular queue is provided.

## Queue Buffer

This example shows how to configure buffer per queue:

```

Tqwvgt%"ujqy"rqnke{/ocr"v{rg"ncp/swgwkpi"nvguv
"Rqnke{"Ocr"v{rg"ncp/swgwkpi"nvguv
""""Encuu"nvguv
""""dcpfykfjvj"tgockpkpi"32"*'+
""""swgwg/dwhhgtu"tcvkq"52
""""Encuu"nvguv3
""""rtkqtkv{
""""swgwg/dwhhgtu"tcvkq"62
""""Encuu"encuu/fghcwnv

```





## QoS Global and Interface Options

---

- [How to Configure the Ingress LAN Port CoS Value, page 65-2](#)
- [How to Configure Egress DSCP Mutation, page 65-3](#)
- [How to Configure Ingress CoS Mutation on IEEE 802.1Q Tunnel Ports, page 65-4](#)
- [How to Configure DSCP Value Maps, page 65-7](#)
- [How to Configure Trusted Boundary with Cisco Device Verification, page 65-10](#)
- [Legacy Configuration Procedures for Queueing-Only Mode, page 65-11](#)
- [Legacy Configuration Procedures for VLAN-Based PFC QoS on Layer 2 LAN Ports, page 65-12](#)
- [Legacy Configuration Procedures for Port Trust State, page 65-13](#)
- [Legacy Configuration Procedures for DSCP-Based Queue Mapping, page 65-14](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

# How to Configure the Ingress LAN Port CoS Value



## Note

A service policy applied to a port overrides any commands configured on the port.

Whether or not PFC QoS uses the CoS value applied with the **platform qos cos** command depends on the trust state of the port and the trust state of the traffic received through the port. The **platform qos cos** command does not configure the trust state of the port or the trust state of the traffic received through the port.

To use the CoS value applied with the **platform qos cos** command as the basis of internal DSCP:

- On a port that receives only untagged ingress traffic, configure the ingress port as trusted or configure a trust CoS policy map that matches the ingress traffic.
- On a port that receives tagged ingress traffic, configure a trust CoS policy map that matches the ingress traffic.
- The original ingress CoS value remains known.
  - By default, for IPv4 and IPv6 traffic, the ingress CoS value is overwritten by the DSCP value.
  - By default, for other traffic that is not tagged, the ingress CoS value is used, rather than the configured port CoS value.
  - Use the **platform qos cos override** interface command to use the value configured with the **platform qos cos** interface command instead of the original ingress CoS value.

You can configure the CoS value that PFC QoS assigns to untagged frames from ingress LAN ports configured as trusted and to all frames from ingress LAN ports configured as untrusted.

To configure the CoS value for an ingress LAN port, perform this task:

|        | Command                                                                                        | Purpose                                    |
|--------|------------------------------------------------------------------------------------------------|--------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+%<b>"kpvgtthceg"</b>}}type slot/port;~"<br/>}rqtv/ejcppgn"pwodgt; "</code> | Selects the interface to configure.        |
| Step 2 | <code>Tqwwgt*eqphki/kh+%<b>"rncvhqto"squ"equ"</b>rqtvaequ"</code>                              | Configures the ingress LAN port CoS value. |
| Step 3 | <code>Tqwwgt*eqphki/kh+%<b>"gpf"</b></code>                                                    | Exits configuration mode.                  |

This example shows how to configure the CoS value 5 on Fast Ethernet port 5/24 and verify the configuration:

```
Tqwwgt%"eqphkiwtg"vgtokpcn"
GpvgT"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp00""Gpf"ykvj"EPVN1\0
Tqwwgt*eqphki+%"kpvgtthceg"hcuvvgjgtpgv"7146"
Tqwwgt*eqphki/kh+%"rncvhqto"squ"equ"7"
Tqwwgt*eqphki/kh+%"gpf"
Tqwwgt%"ujqy"swgwgkpi"kpvgthceg"hcuvvgjgtpgv"7146"~"kpenwfg"Fghcwnv"EQU"
 "Fghcwnv"EQU"ku"7
Tqwwgt%
```



## Attaching an Egress DSCP Mutation Map to an Interface

To attach an egress DSCP mutation map to an interface, perform this task:

|        | Command                                                                                                                                                                                   | Purpose                                                |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+%<b>"kpvgtthceg"</b>}}<b>xncp</b>"vlan_IDi"~"</code><br><code>}type slot/port]0uwdkpvgtthceg_i"~"</code><br><code>}<b>rgtv/ejcppgn</b> pwodgt]0uwdkpvgtthceg_i</code> | Selects the interface to configure.                    |
| Step 2 | <code>Tqwwgt*eqphki/kh+%<b>"rncvhtgo"squ"fuier/owvcvkqp"</b></code><br><code>owvcvkqpaocrapcog"</code>                                                                                    | Attaches an egress DSCP mutation map to the interface. |
| Step 3 | <code>Tqwwgt*eqphki/kh+%<b>"gpf"</b></code>                                                                                                                                               | Exits configuration mode.                              |

This example shows how to attach the egress DSCP mutation map named mutmap1 to Fast Ethernet port 5/36:

```
Tqwwgt*eqphkiwtg"vgtokpcn"
Gpvg"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpg0"Gpf"ykvj"EPVN1\0
Tqwwgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"7158"
Tqwwgt*eqphki/kh+%"rncvhtgo"squ"fuier/owvcvkqp"owvoc3"
Tqwwgt*eqphki/kh+%"gpf"
```

## How to Configure Ingress CoS Mutation on IEEE 802.1Q Tunnel Ports

- [Ingress CoS Mutation Configuration Guidelines and Restrictions, page 65-4](#)
- [Configuring Ingress CoS Mutation Maps, page 65-6](#)
- [Applying Ingress CoS Mutation Maps to IEEE 802.1Q Tunnel Ports, page 65-6](#)



### Note

- IEEE 802.1Q tunnel ports configured to trust received CoS support ingress CoS mutation (see the [“Applying Ingress CoS Mutation Maps to IEEE 802.1Q Tunnel Ports”](#) section on page 65-6 for the list of supported modules).

When you configure ingress CoS mutation on an IEEE 802.1Q tunnel port that you have configured to trust received CoS, PFC QoS uses the mutated CoS value instead of the received CoS value in the ingress drop thresholds and for any trust CoS marking and policing.

## Ingress CoS Mutation Configuration Guidelines and Restrictions

- Ports that are not configured as IEEE 802.1Q tunnel ports do not support ingress CoS mutation.
- Ports that are not configured to trust received CoS do not support ingress CoS mutation.
- Ingress CoS mutation does not change the CoS value carried by the customer frames. When the customer traffic exits the 802.1Q tunnel, the original CoS is intact.
- These switching modules support ingress CoS mutation:
  - WS-X6704-10GE

- WS-X6848-SFP-2T, WS-X6748-SFP
  - WS-X6824-SFP-2T, WS-X6724-SFP
  - WS-X6848-TX-2T, WS-X6748-GE-TX
- Ingress CoS mutation configuration applies to all ports in a port group. The port groups are:
  - WS-X6704-10GE:  
4 ports, 4 port groups, 1 port in each group
  - WS-X6848-SFP-2T, WS-X6748-SFP:  
48 ports, 4 port groups: ports 1–12, 13–24, 25–36, and 37–48
  - WS-X6824-SFP-2T, WS-X6724-SFP:  
24 ports, 2 port groups: ports 1–12 and 13–24
  - WS-X6848-TX-2T, WS-X6748-GE-TX:  
48 ports, 4 port groups: ports 1–12, 13–24, 25–36, and 37–48
- To avoid ingress CoS mutation configuration failures, only create EtherChannels where all member ports support ingress CoS mutation or where no member ports support ingress CoS mutation. Do not create EtherChannels with mixed support for ingress CoS mutation.
- If you configure ingress CoS mutation on a port that is a member of an EtherChannel, the ingress CoS mutation is applied to the port-channel interface.
- You can configure ingress CoS mutation on port-channel interfaces.
- With ingress CoS mutation configured on a port-channel interface, the following occurs:
  - The ingress CoS mutation configuration is applied to the port groups of all member ports of the EtherChannel. If any member port cannot support ingress CoS mutation, the configuration fails.
  - If a port in the port group is a member of a second EtherChannel, the ingress CoS mutation configuration is applied to the second port-channel interface and to the port groups of all member ports of the second EtherChannel. If any member port of the second EtherChannel cannot support ingress CoS mutation, the configuration fails on the first EtherChannel. If the configuration originated on a nonmember port in a port group that has a member port of the first EtherChannel, the configuration fails on the nonmember port.
  - The ingress CoS mutation configuration propagates without limit through port groups, member ports, and port-channel interfaces, regardless of whether or not the ports are configured to trust CoS or are configured as IEEE 802.1Q tunnel ports.
- An EtherChannel where you want to configure ingress CoS mutation must not have member ports that are in port groups containing member ports of other EtherChannels that have member ports that do not support ingress CoS mutation. (This restriction extends without limit through all port-group-linked member ports and port-channel-interface-linked ports.)
- A port where you want to configure ingress CoS mutation must not be in a port group that has a member port of an EtherChannel that has members that do not support ingress CoS mutation. (This restriction extends without limit through all port-group-linked member ports and port-channel-interface-linked ports.)
- There can be only be one ingress CoS mutation configuration applied to all port-group-linked member ports and port-channel-interface-linked ports.

## Configuring Ingress CoS Mutation Maps

To configure an ingress CoS mutation map, perform this task:

|        | Command                                                                                                                                                                                                    | Purpose                                                                                                                           |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"rncvhtqto"squ"ocr"equ/owvcvkqp"</b><br/>mutation_map_name mutated_cos1 mutated_cos2<br/>mutated_cos3 mutated_cos4 mutated_cos5<br/>mutated_cos6 mutated_cos7 mutated_cos8"</code> | Configures an ingress CoS mutation map. You must enter 8 mutated CoS values to which PFC QoS maps ingress CoS values 0 through 7. |
| Step 2 | <code>Tqwvgt*eqphki+%<b>"gpf"</b></code>                                                                                                                                                                   | Exits configuration mode.                                                                                                         |

This example shows how to configure a CoS mutation map named testmap:

```
Tqwvgt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpq0""Gpf"ykvj"EPVN1\0
Tqwvgt*eqphki+%"rncvhtqto"squ"ocr"equ/owvcvkqp"vguvocr"6"7"8"9"2"3"4"5"
Tqwvgt*eqphki+%"gpf"
Tqwvgt%
```

This example shows how to verify the map configuration:

```
Tqwvgt*eqphki+%"ujqy"rncvhtqto"squ"ocr"equ/owvcvkqp"
EQU"owvcvkqp"ocr"vguvocr"
equ/kp"<"2"3"4"5"6"7"8"9"
////////////////////////////////////
equ/qvw"<"6"7"8"9"2"3"4"5"
Tqwvgt%
```

## Applying Ingress CoS Mutation Maps to IEEE 802.1Q Tunnel Ports

To attach an ingress CoS mutation map to an IEEE 802.1Q tunnel port, perform this task:

|        | Command                                                                                        | Purpose                                                |
|--------|------------------------------------------------------------------------------------------------|--------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"kpvgtthceg"</b>}}type slot/port;"~"<br/>}rqtv/ejcppgn"pwodgt;i</code> | Selects the interface to configure.                    |
| Step 2 | <code>Tqwvgt*eqphki/kh+%<b>"rncvhtqto"squ"equ/owvcvkqp"</b><br/>owvcvkqpaocrpcog"</code>       | Attaches an ingress CoS mutation map to the interface. |
| Step 3 | <code>Tqwvgt*eqphki/kh+%<b>"gpf"</b></code>                                                    | Exits configuration mode.                              |

This example shows how to attach the ingress CoS mutation map named testmap to Gigabit Ethernet port 1/1:

```
Tqwvgt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpq0""Gpf"ykvj"EPVN1\0
Tqwvgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"313"
Tqwvgt*eqphki/kh+%"rncvhtqto"squ"equ/owvcvkqp"vguvocr"
Tqwvgt*eqphki/kh+%"gpf"
Tqwvgt%""ujqy"rncvhtqto"squ"ocr"equ/owvcvkqp"
EQU"owvcvkqp"ocr"vguvocr"
equ/kp"<"2"3"4"5"6"7"8"9"
////////////////////////////////////
equ/qvw"<"6"7"8"9"2"3"4"5"

vguvocr"ku"cvvcejgf"qp"vjg"hqnnqykpi"kpvgthcegu
Ik313"
Tqwvgt%
```

# How to Configure DSCP Value Maps

- [Mapping Received CoS Values to Internal DSCP Values, page 65-7](#)
- [Mapping Received IP Precedence Values to Internal DSCP Values, page 65-7](#)
- [Configuring DSCP Markdown Values, page 65-8](#)
- [Mapping Internal DSCP Values to Egress CoS Values, page 65-9](#)

## Mapping Received CoS Values to Internal DSCP Values

To configure the mapping of received CoS values to the DSCP value that PFC QoS uses internally on the PFC, perform this task:

|        | Command                                                                                                                   | Purpose                                                                                                                      |
|--------|---------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%<b>"vcdng/ocr"equ/fkuectf/encuu/ocr"</b><br/>dscp1 dscp2 dscp3 dscp4 dscp5 dscp6 dscp7 dscp8"</code> | Configures the received CoS to internal DSCP map. You must enter 8 DSCP values to which PFC QoS maps CoS values 0 through 7. |
| Step 2 | <code>Tqvwgt*eqphki+%<b>"gpf"</b></code>                                                                                  | Exits configuration mode.                                                                                                    |

This example shows how to configure the received CoS to internal DSCP map:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
GpvgT"eqphkiwtcvkqp"eqoocpfu."qpq"rgt"nkpq0""Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%"vcdng/ocr"equ/fkuectf/encuu/ocr"2"3"4"5"6"7"8"9"
Tqvwgt*eqphki+%"gpf"
Tqvwgt%
```

This example shows how to verify the configuration:

```
Tqvwgt%"ujqy"rncvhtqto"squ"ocr"equ/fkuectf/encuu"
Tqvwgt%
```

## Mapping Received IP Precedence Values to Internal DSCP Values

To configure the mapping of received IP precedence values to the DSCP value that PFC QoS uses internally on the PFC, perform this task:

|        | Command                                                                                                                                     | Purpose                                                                                                                                                            |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%<b>"vcdng/ocr"</b><br/><b>rtgegfgpeg/fkuectf/encuu/ocr"</b>dscp1 dscp2 dscp3<br/>dscp4 dscp5 dscp6 dscp7 dscp8"</code> | Configures the received IP precedence to internal DSCP map. You must enter 8 internal DSCP values to which PFC QoS maps received IP precedence values 0 through 7. |
| Step 2 | <code>Tqvwgt*eqphki+%<b>"gpf"</b></code>                                                                                                    | Exits configuration mode.                                                                                                                                          |

This example shows how to configure the received IP precedence to internal DSCP map:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
GpvgT"eqphkiwtcvkqp"eqoocpfu."qpq"rgt"nkpq0""Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%"vcdng/ocr"rtgegfgpeg/fkuectf/encuu/ocr"2"3"4"5"6"7"8"9"
Tqvwgt*eqphki+%"gpf"
```

Tqwvgt% "ujgy" rncvhqto "squ" ocru "rtgegfgpeg/fkuectf/encuu"  
Tqwvgt%

To configure the mapping of DSCP markdown values used by policers, perform this task:

- You can enter the **normal-burst** keyword to configure the markdown map used by the **exceed-action policed-dscp-transmit** keywords.
- You can enter the **max-burst** keyword to configure the markdown map used by the **violate-action policed-dscp-transmit** keywords.



- To avoid out-of-sequence packets, configure the markdown maps so that conforming and nonconforming traffic uses the same queue.
- You can enter up to 8 DSCP values that map to a marked-down DSCP value.
- You can enter multiple commands to map additional DSCP values to a marked-down DSCP value.
- You can enter a separate command for each marked-down DSCP value.



```
Tqwvgt%"eqphkiwtg"vgtokpcn"
Gpvgt%"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0g0"
Gpf"ykvj"EPVN\0
Tqwvgt*eqphki+%"vcdng/ocr"rqnkegf/fkuectf/encuu"pqtocn/dwtuv"3"vq"2"
Tqwvgt*eqphki+%"gpf"
Tqwvgt%"
```

```
Tqwgvtg% "ujqy"vcdng/ocr"rqncegf/fkuectf/encuu/pgtocr/dwtuv/ocr"
"" "Pgtoen"Dwtuv"Rqncegf/fuer"ocr< "***** *fuer?"f3f4+
*****f3< ""f4"2""3""4""5""6""7""8""9"" : "" :
```





In the Policed-dscp displays, the marked-down DSCP values are shown in the body of the matrix; the first digit of the original DSCP value is in the column labeled d1 and the second digit is in the top row. In the example shown, DSCP 41 maps to DSCP 41.

To configure the mapping of the DSCP value that PFC QoS uses internally on the PFC to the CoS value used for egress LAN port scheduling and congestion avoidance, perform this task:

- You can enter up to 8 DSCP values that PFC QoS maps to a CoS value.
- You can enter multiple commands to map additional DSCP values to a CoS value.
- You can enter a separate command for each CoS value.

Tqwvgt%**"eqphkiwtg"vgtokpcn"**  
GpvgT"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp00"**Gpf**"ykvj"EPVN1\0  
Tqwvgt\*eqphki+%"**vcđng/ocr"fkuctf/encuu/equ/ocr"2**":**38"46"54"62"6**:"**76"vq"2**"  
Tqwvgt\*eqphki+%"**gpf**"  
Tqwvgt% "

```
Tqvwgt%"ujqy"vcdng/ocr"fkuectf/encuu/equ/ocr"
""Fuer/equ"ocr<"*****fuer?"f3f4+
""f3"<"f4"2"3"4"5"6"7"8"9"":";
""/////////
""2"<""22"22"22"22"22"22"22"22"22"23"
""3"<""23"23"23"23"23"23"22"24"24"24"
""4"<""24"24"24"24"22"25"25"25"25"25"
""5"<""25"25"22"26"26"26"26"26"26"26"
""6"<""22"27"27"27"27"27"27"27"22"28"
""7"<""28"28"28"28"22"28"29"29"29"29"
""8"<""29"29"29"29
Tqvwgt%
```

**Note**

In the `Fuer/egu"ocr` display, the CoS values are shown in the body of the matrix; the first digit of the DSCP value is in the column labeled d1 and the second digit is in the top row. In the example shown, DSCP values 41 through 47 all map to CoS 05.

## How to Configure Trusted Boundary with Cisco Device Verification

The trusted boundary with Cisco device verification feature configures Ethernet LAN ports to use CDP to detect whether or not a Cisco IP phone is attached to the port.

- If CDP detects a Cisco IP phone, QoS applies a configured **mls qos trust dscp**, **mls qos trust ip-precedence**, or **mls qos trust cos** interface command.
- If CDP does not detect a Cisco IP phone, QoS ignores any configured nondefault trust state.

To configure trusted boundary with Cisco device verification, perform this task:

|        | Command                                                                                       | Purpose                                                     |
|--------|-----------------------------------------------------------------------------------------------|-------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "kpvgthceg" }} type slot/port; "~"<br/>} rqtv/ejcppgn" pwodgt; ;</code> | Selects the interface to configure.                         |
| Step 2 | <code>Tqwvgt*eqphki/kh+% "rncvhqto" squ"vtwuv" fgxkeg"<br/>ekueq/rjqpg"</code>                | Configures trusted boundary with Cisco device verification. |
| Step 3 | <code>Tqwvgt*eqphki/kh+% "gpf"</code>                                                         | Exits configuration mode.                                   |

When configuring trusted boundary with Cisco device verification, CDP must be enabled on the port to use trusted boundary with Cisco device verification.

This example shows how to configure trusted boundary with Cisco device verification on Gigabit Ethernet port 1/1:

```
Tqwvgt% "eqphkiwtg" vgtokpcn"
Gpvgt "eqphkiwtcvkqp" eqoocpfu. "qpg" rgt "nkpq0" "Gpf" ykvj "EPVN1\0
Tqwvgt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv"313"
Tqwvgt*eqphki/kh+% "onu" squ"vtwuv" fgxkeg" ekueq/rjqpg"
Tqwvgt*eqphki/kh+% "gpf"
Tqwvgt%
```

This example shows how to verify the configuration on a port configured to trust CoS, but that does not have a Cisco IP phone attached:

```
Tqwvgt% "ujqy" swgwgkpi "kpvgthceg" ikicdkvgvjgtpgv"313" ~ "kpenwfg"] Vv_twuv"
Vtwuv" dqwpfct { "gpcdnf
" "Rqtv" ku" wpv twuvgf
" "Gzv gpf" vtwuv" uv cvg< "pqv" vtwuvgf"] EQU" ? "2_
Tqwvgt%
```

# Legacy Configuration Procedures for Queueing-Only Mode

**Note**

You can configure the queueing-only functionality with service policies.

To enable queueing-only mode on the switch, perform this task:

|        | Command                                                     | Purpose                                   |
|--------|-------------------------------------------------------------|-------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+% "rncvhtqto"squ"swgwgkpi/qpn{ "</code> | Enables queueing-only mode on the switch. |
| Step 2 | <code>Tqwwgt*eqphki+% "gpf"</code>                          | Exits configuration mode.                 |

When you enable queueing-only mode, the following actions occur:

- Except on ports configured with service policies, disables policing and marking (preserves all ingress QoS labels).
- Configures ingress queueing on ports to which an ingress queueing policy is not attached. Configures egress queueing on ports to which an egress queueing policy is not attached.
- Configures all ports to trust Layer 2 CoS.

**Note**

The switch applies the port CoS value to untagged ingress traffic and to traffic that is received through ports that cannot be configured to trust CoS.

This example shows how to enable queueing-only mode:

```
Tqwwgt% "eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+% "rncvhtqto"squ"swgwgkpi/qpn{ "
Tqwwgt*eqphki+% "gpf"
Tqwwgt%
```

# Legacy Configuration Procedures for VLAN-Based PFC QoS on Layer 2 LAN Ports



## Note

- You can attach policy maps to Layer 3 interfaces for application of PFC QoS to egress traffic. VLAN-based or port-based PFC QoS on Layer 2 ports is not relevant to application of PFC QoS to egress traffic on Layer 3 interfaces.
- By default, PFC QoS uses policy maps attached to LAN ports. For ports configured as Layer 2 LAN ports with the **switchport** keyword, you can configure PFC QoS to use policy maps attached to a VLAN. Ports not configured with the **switchport** keyword are not associated with a VLAN.

To enable VLAN-based PFC QoS on a Layer 2 LAN port, perform this task:

|        | Command                                                                                                       | Purpose                                                                     |
|--------|---------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"kpvgtthceg"</b>}}type slot/port; "~"</code><br><code>}rqtv/ejcppgn"pwodgt; i"</code> | Selects the interface to configure.                                         |
| Step 2 | <code>Tqwvgt*eqphki/kh+%<b>"rncvhtqto"squ"xncp/dcugf"</b></code>                                              | Enables VLAN-based PFC QoS on a Layer 2 LAN port or a Layer 2 EtherChannel. |
| Step 3 | <code>Tqwvgt*eqphki/kh+%<b>"gpf"</b></code>                                                                   | Exits configuration mode.                                                   |

- The configured port trust state does not affect marking when the **platform qos vlan-based** interface command is configured.
- A service policy attached to the Layer 3 VLAN interface defines QoS for ports where the **platform qos vlan-based** interface command is configured.
- Service policies attached to ports configured with the **platform qos vlan-based** interface command are ignored.
- Configuring a Layer 2 LAN port for VLAN-based PFC QoS preserves the policy map port configuration. The **no platform qos vlan-based** port command reenables any previously configured port commands.

This example shows how to enable VLAN-based PFC QoS on Fast Ethernet port 5/42:

```
Tqwvgt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqwvgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"7164"
Tqwvgt*eqphki/kh+%"rncvhtqto"squ"xncp/dcugf"
Tqwvgt*eqphki/kh+%"gpf"
```

This example shows how to verify the configuration:

```
Tqwvgt%"ujqy"rncvhtqto"squ"~"dgikp"SqU"ku"xncp/dcugf"
" "SqU"ku"xncp/dcugf"qp"vjg"hqnnqykpi"kpvgthcegu<
" ""Hc7164
>000Qwvrwv"Vtwpecvgf000@
```

# Legacy Configuration Procedures for Port Trust State

To configure a port to which a service policy is not attached as untrusted, perform this task:

|        | Command                                                                                         | Purpose                                                          |
|--------|-------------------------------------------------------------------------------------------------|------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+%<b>kpvgthceg</b>"} type slot/port; ~"<br/>}rqtv/ejcppgn"pwodgt; i "</code> | Selects the interface to configure.                              |
| Step 2 | <code>Tqwwgt*eqphki/kh+%<b>rncvhtgo</b>"squ"vtwuv"pqpg"tgoctm"</code>                           | Configures the port as untrusted and marks all non-MPLS traffic. |
| Step 3 | <code>Tqwwgt*eqphki/kh+%<b>gpf</b>"</code>                                                      | Exits configuration mode.                                        |

To configure a port to which a service policy is not attached to trust CoS or IP precedence, perform this task:

|        | Command                                                                                         | Purpose                                                                            |
|--------|-------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+%<b>kpvgthceg</b>"} type slot/port; ~"<br/>}rqtv/ejcppgn"pwodgt; i "</code> | Selects the interface to configure.                                                |
| Step 2 | <code>Tqwwgt*eqphki/kh+%<b>rncvhtgo</b>"squ"vtwuv"<br/>]rtgegfgpeg ~"equ_ "</code>              | Configures the trust state of the port.<br><b>Note</b> DSCP is trusted by default. |
| Step 3 | <code>Tqwwgt*eqphki/kh+%<b>gpf</b>"</code>                                                      | Exits configuration mode.                                                          |



## Note

The trust state of a port is unrelated to enables ingress queueing. To avoid dropping traffic because of inconsistent CoS values, configure ports to trust CoS only when the received traffic carries CoS values that you know to be consistent with network policy.

This example shows how to configure Gigabit Ethernet port 1/1 with the **trust cos** keywords:

```
Tqwwgt%"eqphkiwtg"vgtokpcn"
Gpvg "eqphkiwtcvkqp"eqoocpfu. "qpg"rgt"nkpgo "Gpf"ykvj "EPVN1\0
Tqwwgt*eqphki+%kpvgthceg"ikicdkvgvjgtpgv"313 "
Tqwwgt*eqphki/kh+%rncvhtgo"squ"vtwuv"equ"
Tqwwgt*eqphki/kh+%gpf"
Tqwwgt%
```

This example shows how to verify the configuration:

```
Tqwwgt%"ujqy"swgwgkpi"kpvgthceg"ikicdkvgvjgtpgv"313 "~"kpenwfg"vtwuv"
" "Vtwuv"uvcvg<"vtwuv"EQU
Tqwwgt%
```

# Legacy Configuration Procedures for DSCP-Based Queue Mapping

- [Configuring Ingress DSCP-Based Queue Mapping, page 65-15](#)
- [Mapping DSCP Values to Standard Transmit-Queue Thresholds, page 65-16](#)
- [Mapping DSCP Values to the Transmit Strict-Priority Queue, page 65-18](#)



**Note**

- Do not use the procedures in this section if you have policy-based queueing configured.
- You can enable DSCP-based queues and thresholds on 8q4t, 1p7q2t, and 1p7q4t ports (see the [“Module to Queue Type Mappings”](#) section on page 35-7)
- DSCP-based queueing is supported on 8q4t, 1p7q2t, and 1p7q4t ports. The Supervisor Engine 6T-10GE ports are 8q4t/1p7q4t with the **platform qos 10g-only** global configuration command configured. To configure DSCP-based queue mapping on Supervisor Engine 6T ports, you must enter **shutdown** interface configuration mode commands for the Supervisor Engine 6T Gigabit Ethernet ports, and then enter the **platform qos 10g-only** global configuration command, which disables the Gigabit Ethernet ports on the Supervisor Engine 6T.
- In releases where [CSCts82932](#) is not resolved, do not use the default DSCP-based queue mapping for 8q4t ingress queues unless you configure supporting bandwidth and queue limits.

## Enabling DSCP-Based Queue Mapping

To enable DSCP-based queue mapping, perform this task:

|        | Command                                                                      | Purpose                             |
|--------|------------------------------------------------------------------------------|-------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"kpvgtthceg"vgpikicdkvgvjgtpgv"</b>slot/port"</code> | Selects the interface to configure. |
| Step 2 | <code>Tqwvgt*eqphki/kh+%<b>"rncvhqto"squ"swgwg/oqfg"oqfg/fuer"</b></code>    | Enables DSCP-based queue mapping.   |
| Step 3 | <code>Tqwvgt*eqphki/kh+%<b>"gpf"</b></code>                                  | Exits configuration mode.           |

This example shows how to enable DSCP-based queue mapping on 10-Gigabit Ethernet port 6/1:

```
Tqwvgt%"eqphkiwtg"vgtokpcn"
GpvgT"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0" "Gpf"ykvj"EPVN1\0
Tqwvgt*eqphki+%"kpvgtthceg"vgpikicdkvgvjgtpgv"813"
Tqwvgt*eqphki/kh+%"rncvhqto"squ"swgwg/oqfg"oqfg/fuer"
Tqwvgt*eqphki/kh+%"gpf"
```

This example shows how to verify the configuration:

```
Tqwvgt%"ujqy"swgwgkpi"kpvgthceg"vgpikicdkvgvjgtpgv"813"~"kpenwfg"Swgwgkpi"Oqfg"
Swgwgkpi"Oqfg"Kp"Vz"fktgevkqp<"oqfg/fuer
Swgwgkpi"Oqfg"Kp"Vz"fktgevkqp<"oqfg/fuer
```

## Configuring Ingress DSCP-Based Queue Mapping

- [Enabling DSCP-Based Queue Mapping, page 65-14](#)
- [Mapping DSCP Values to Standard Receive-Queue Thresholds, page 65-15](#)



**Note**

Ingress DSCP-to-queue mapping is supported only on ports configured to trust DSCP.

## Mapping DSCP Values to Standard Receive-Queue Thresholds

To map DSCP values to the standard receive-queue thresholds, perform this task:

|        | Command                                                                                                                                                  | Purpose                                                    |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%<b>kpvgthceg</b>"vgpikicdkvgvjgtpgv"<br/>slot/port</code>                                                                           | Selects the interface to configure.                        |
| Step 2 | <code>Tqwgvt*eqphki/kh+%<b>tex/swgwg</b>"fuer/ocr"queue_#<br/>threshold_# dscp1"] dscp2"] dscp3"] dscp4"] dscp5"<br/>] dscp6"] dscp7"] dscp8_____</code> | Maps DSCP values to the standard receive queue thresholds. |
| Step 3 | <code>Tqwgvt*eqphki/kh+%<b>gpf</b>"</code>                                                                                                               | Exits configuration mode.                                  |

When mapping DSCP values, note the following information:

- You can enter up to 8 DSCP values that map to a queue and threshold.
- You can enter multiple commands to map additional DSCP values to the queue and threshold.
- You must enter a separate command for each queue and threshold.

This example shows how to map the DSCP values 0 and 1 to threshold 1 in the standard receive queue for 10-Gigabit Ethernet port 6/1 port 6/1:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Gpvgvt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpg0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+%kpvgthceg"vgpikicdkvgvjgtpgv"813"
Tqwgvt*eqphki/kh+%tex/swgwg"fuer/ocr"3"3"2"3"
Tqwgvt*eqphki/kh+%gpf"
Tqwgvt%
```



This example shows how to verify the configuration:

## Mapping DSCP Values to Standard Transmit-Queue Thresholds

To map DSCP values to standard transmit-queue thresholds, perform this task:

|        | Command                                                                                                                                                              | Purpose                                                  |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------|
| Step 1 | Tqwvgt*eqphki+% <b>kpvgthceg"vgpikicdkvgvjgtpgv"</b><br><i>slot/port</i> "                                                                                           | Selects the interface to configure.                      |
| Step 2 | Tqwvgt*eqphki/kh+% <b>ytt/swgwg"fuer/ocr"</b><br><i>transmit_queue_# threshold_# dscp1"] dscp2"] dscp3"</i><br><i>] dscp4"] dscp5"] dscp6"] dscp7"] dscp8_____</i> " | Maps DSCP values to a standard transmit-queue threshold. |
| Step 3 | Tqwvgt*eqphki/kh+% <b>gpf</b> "                                                                                                                                      | Exits configuration mode.                                |





## Mapping DSCP Values to the Transmit Strict-Priority Queue

To map DSCP values to the transmit strict-priority queue, perform this task:

|        | Command                                                                                                                                                       | Purpose                                                                                                                                                                             |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%<b>kpvgthceg</b>"vgpikicdkvgvjgtpgv"<br/>slot/port</code>                                                                                | Selects the interface to configure.                                                                                                                                                 |
| Step 2 | <code>Tqvwgt*eqphki/kh+%<b>rtkqtkv</b>{/swgwg"fu<del>er</del>"ocr"<br/>queue_# dscp1"] dscp2"] dscp3"] dscp4"] dscp5"] dscp6"<br/>] dscp7"] dscp8_____</code> | Maps DSCP values to the transmit strict-priority queue. You can enter multiple <b>priority-queue dscp-map</b> commands to map more than 8 DSCP values to the strict-priority queue. |
| Step 3 | <code>Tqvwgt*eqphki/kh+%<b>gpf</b>"</code>                                                                                                                    | Exits configuration mode.                                                                                                                                                           |

- The queue number is always 1.
- You can enter up to 8 DSCP values to map to the queue.
- You can enter multiple commands to map additional DSCP values to the queue.

This example shows how to map DSCP value 7 to the strict-priority queue on 10 Gigabit Ethernet port 6/1:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%kpvgthceg"vgpikicdkvgvjgtpgv"813"
Tqvwgt*eqphki/kh+%rtkqtkv{/swgwg"fuer"ocr"3"9"
Tqvwgt*eqphki/kh+%gpf"
Tqvwgt%"
```



### Note

The strict priority queue is queue 8 in the output of the **show queueing interface** command.

This example shows how to verify the configuration:

```
"Tqvwgt%"ujqy"swgwgkpi"kpvgthceg"vgpikicdkvgvjgtpgv"813"~"dgikp"swgwg"vjtguj"fuer"ocr"
""""swgwg"vjtguj"fuer"ocr
""""//
>000Qwvrvw"Vtwpecvgf000@
""": """"3""""9"62"68"
>000Qwvrvw"Vtwpecvgf000@
Tqvwgt%"
```



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



# AutoQoS

---

- [Prerequisites for AutoQoS, page 66-1](#)
- [Restrictions for AutoQoS, page 66-2](#)
- [Information About AutoQoS, page 66-2](#)
- [Default Settings for AutoQoS, page 66-4](#)
- [How to Configure AutoQoS, page 66-4](#)



## Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
  - Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- 



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

---

## Prerequisites for AutoQoS

None.

## Restrictions for AutoQoS

- AutoQoS generates commands for the port and adds the generated commands to the running configuration.
- The generated QoS commands are applied as if you were entering them from the CLI. An existing configuration might cause the application of the generated commands to fail or an existing configuration might be overridden by the generated commands. These actions occur without warning. If the generated commands are successfully applied, any configuration that was not overridden remains in the running configuration. Any commands that were overridden might still exist in the startup-config file.
- Some of the generated commands are the type of PFC QoS commands that are applied to [all ports controlled by a port ASIC](#). When one of these commands is applied, PFC QoS displays the messages caused by application of the command to all the ports controlled by the port ASIC. Depending on the module, these commands are applied to as many as 48 ports. See the “Number of port groups” and “Port ranges per port group” listed for each module in the *Release Notes for Cisco IOS Release 15.2SY*.
- You might not be able to configure support for Cisco IP phones and the other autoQoS options on ports that are controlled by the same port ASIC because of conflicting port trust state requirements.
- If application of the generated commands fails, the previous running configuration is restored.
- Enable autoQoS before you configure other QoS commands. If necessary, you can modify the QoS configuration after the autoQoS configuration completes.
- AutoQoS cannot attach a policy map to an interface if there is already a policy map attached.
- Do not modify a policy map or class map that includes AUTOQOS in its name.
- You cannot configure autoQoS on the following:
  - Port-channel interfaces
  - VLAN interfaces (also known as switch virtual interfaces or SVIs)
  - Tunnel interfaces
  - Loopback interfaces
  - Subinterfaces on any type of interface

## Information About AutoQoS

- [AutoQoS Support for a Cisco IP Phone, page 66-3](#)
- [AutoQoS Support for Cisco IP Communicator, page 66-3](#)
- [AutoQoS Support for Marked Traffic, page 66-4](#)

**Note**

AutoQoS is a macro that applies the recommended Architecture for Voice, Video, and Integrated Data (AVVID) QoS settings to a port.

## AutoQoS Support for a Cisco IP Phone

Cisco IP phones are usually connected directly to ports. Optionally, you can attach a PC to the phone and use the phone as a hop to the switch.

The traffic that comes from the phone can be marked with an 802.1Q or 802.1p tag. The tag contains a VLAN ID and CoS value. When you configure the port to trust the CoS value that comes from the phone, the switch uses the CoS value to prioritize the phone traffic.

There is a three-port switch built into Cisco IP phones that forwards the traffic that comes from the PC, the phone, and the switch port. Cisco IP phones have trust and classification capabilities that you need to configure (see the [“How to Configure Cisco IP Phone Support” section on page 19-5](#)).

AutoQoS supports Cisco IP phones with the **auto qos voip cisco-phone** interface configuration command. When you enter the **auto qos voip cisco-phone** interface configuration command on a port that is configured to support an IP phone and to which an IP phone is connected, the autoQoS feature does the following:

- If QoS was not already enabled, enables QoS globally.
- If VLAN-based QoS was configured for the port, reverts to the default port-based QoS (done for all ports on switching modules with **1p1q0t/1p3q1t** ports).
- Sets the port trust state to trust CoS.
- Creates and applies a trust-CoS QoS policy to ports on switching modules with non-Gigabit Ethernet **1q4t/2q2t** ports, which do not support port trust.

## AutoQoS Support for Cisco IP Communicator

The Cisco IP Communicator program runs on a PC and emulates a Cisco IP phone. The Cisco IP Communicator marks its voice traffic with a DSCP value instead of a CoS value. When you configure the port to trust the DSCP value that comes from the Cisco IP Communicator, the switch uses the DSCP value to prioritize the Cisco IP Communicator traffic.

AutoQoS supports the Cisco IP Communicator program with the **auto qos voip cisco-softphone** interface configuration command. When you enter the **auto qos voip cisco-softphone** interface configuration command on a port that is connected to a device running the Cisco IP Communicator program, the autoQoS feature does the following:

- If QoS was not already enabled, enables QoS globally.
- If VLAN-based QoS was configured for the port, reverts to the default port-based QoS (done for all ports on switching modules with **1p1q0t/1p3q1t** ports).
- If a trust state was configured for the port, reverts to the default untrusted state.
- Creates and applies ingress policers to trust DSCP 46 and remark DSCP 26 packets to DSCP 24. Packets with other DSCP values or out-of-profile packets are remarked with DSCP 0.

## AutoQoS Support for Marked Traffic

Ports that connect to the interior of your network might receive traffic that has already been marked with QoS labels that are consistent with your network QoS policies, and which do not need to be changed. You can use the QoS trust feature to process the marked traffic using the received QoS values.

AutoQoS supports marked traffic with the **auto qos voip trust** interface configuration command. When you enter the **auto qos voip trust** interface configuration command, the autoQoS feature does the following:

- If QoS was not already enabled, enables QoS globally.
- If VLAN-based QoS was configured for the port, reverts to the default port-based QoS (done for all ports on switching modules with **1p1q0t/1p3q1t** ports).
- If the port is configured with the **switchport** command, sets the port trust state to trust CoS.
- If the port is not configured with the **switchport** command, sets the port trust state to trust DSCP.
- Creates and applies a trust-CoS or trust-DSCP QoS policy to ports on switching modules with non-Gigabit Ethernet **1q4t/2q2t** ports, which do not support port trust.

## Default Settings for AutoQoS

None.

## How to Configure AutoQoS

- [Configuring AutoQoS Support for a Cisco IP Phone, page 66-5](#)
- [Configuring AutoQoS Support for Cisco IP Communicator, page 66-6](#)
- [Configuring AutoQoS Support for Marked Traffic, page 66-7](#)

**Note**

AutoQoS generates commands that are appropriate for the QoS port architecture of the port on which you enter an **auto qos voip** command. For each of the different **auto qos voip** commands, autoQoS generates different QoS commands for each of these QoS port architectures:

- 1p1q0t/1p3q1t
- 1p1q4t/1p2q2t
- 1p1q4t/1p3q8t
- 1p1q8t/1p2q1t
- 1q2t/1p2q2t
- 1q2t/1p3q8t
- 1q4t/2q2t
- 1q8t/1p3q8t
- 1q8t/1p7q8t
- 2q8t/1p3q8t
- 8q4t/1p7q4t
- 8q8t/1p7q8t

The procedures in the following sections include the commands that you need to enter to display the generated commands, but the specific commands that autoQoS generates are not listed in this document.

## Configuring AutoQoS Support for a Cisco IP Phone

**Note**

Complete the configuration procedures in the [“How to Configure Cisco IP Phone Support”](#) section on [page 19-5](#) before you configure autoQoS for a Cisco IP phone.

To configure autoQoS for a Cisco IP phone, perform this task:

|        | Command                                                           | Purpose                                  |
|--------|-------------------------------------------------------------------|------------------------------------------|
| Step 1 | <code>Tqwvgt%<b>"eqphkiwtg"vgtokpcn</b>"</code>                   | Enters global configuration mode.        |
| Step 2 | <code>Tqwvgt*eqphki+%"<b>kpvgt hceg</b>" type slot/port"</code>   | Selects the interface to configure.      |
| Step 3 | <code>Tqwvgt*eqphki/kh+%"<b>cwvq"sq" xqkr"ekueq/rjqpg</b>"</code> | Configures autoQoS for a Cisco IP phone. |
| Step 4 | <code>Tqwvgt*eqphki/kh+%"<b>gpf</b>"</code>                       | Returns to privileged EXEC mode.         |

When configuring autoQoS for a Cisco IP phone, note the following information:

- To disable autoQoS on an interface, use the **no auto qos voip** interface configuration command.



**Note** The **no auto qos voip** interface configuration command does not delete the received CoS to internal DSCP map created by autoQoS.

- You might see messages that instruct you to configure other ports to trust CoS. You must do so to enable the autoQoS generated commands.

This example shows how to enable autoQoS on Gigabit Ethernet interface 1/1:

```
Tqwgvt*eqphki+% "kpvgtthceg" ikicdkvgvjgtpgv "313"
Tqwgvt*eqphki/kh+% "cwvq" squ"xqkr"ekueq/rjqpgg"
```

Displays the generated [received CoS to internal DSCP map](#).

```
Tqwgvt%"ujqy"twppkpi/eqphki"~"kpenwfg" squ"ocr"equ/fuer"
```

## Configuring AutoQoS Support for Cisco IP Communicator

To configure autoQoS for Cisco IP Communicator, perform this task:

|        | Command                                              | Purpose                                       |
|--------|------------------------------------------------------|-----------------------------------------------|
| Step 1 | Tqwgvt%"eqphkiwtg"vgtokpcn"                          | Enters global configuration mode.             |
| Step 2 | Tqwgvt*eqphki+% "kpvgtthceg" type slot/port"         | Selects the interface to configure.           |
| Step 3 | Tqwgvt*eqphki/kh+% "cwvq" squ"xqkr"ekueq/ughvrjqpgg" | Configures autoQoS for Cisco IP Communicator. |
| Step 4 | Tqwgvt*eqphki/kh+% "gpf"                             | Returns to privileged EXEC mode.              |

- To disable autoQoS on an interface, use the **no auto qos voip** interface configuration command.



**Note** The **no auto qos voip** interface configuration command does not delete the policy, class, and DSCP markdown maps created by autoQoS.

- You cannot configure support for Cisco IP Communicator on ports that are configured with the **switchport** keyword.
- PFC QoS supports 1023 aggregate policers and each use of the **auto qos voip cisco-softphone** command on a port uses two aggregate policers.

This example shows how to enable autoQoS on Gigabit Ethernet interface 1/1:

```
Tqwgvt*eqphki+% "kpvgtthceg" ikicdkvgvjgtpgv "313"
Tqwgvt*eqphki/kh+% "cwvq" squ"xqkr"ekueq/ughvrjqpgg"
```

Displays the configured autoQoS commands.

```
Tqwgvt%"ujqy"cwvq" squ" kpvgtthceg" type slot/port"
```

Displays the policy map and policers created by autoQoS.

```
Tqwgvt%"ujqy"rqnke{/ocr"CWVQSQU/EKUEQ/UQHVRJQPGG"
```



Displays the class maps created by autoQoS.

```
Tqvwgt% "ujqy" encuu/ocr "CWVQSQU/EKUEQ/UQHVRJQPG/UKIPCN"
Tqvwgt% "ujqy" encuu/ocr "CWVQSQU/EKUEQ/UQHVRJQPG/FCVC"
```

Displays the **DSCP markdown maps** created by autoQoS.

```
Tqvwgt% "ujqy" twppkpi/eqphki "~" kpenwfg "squ" ocr "rqnkegf/fuer"
```

## Configuring AutoQoS Support for Marked Traffic

To configure autoQoS for marked traffic, perform this task:

|        | Command                                                     | Purpose                                |
|--------|-------------------------------------------------------------|----------------------------------------|
| Step 1 | <code>Tqvwgt% "eqphkiwtg" vgtokpcn</code>                   | Enters global configuration mode.      |
| Step 2 | <code>Tqvwgt *eqphki + % "kpvgt hceg" type slot/port</code> | Selects the interface to configure.    |
| Step 3 | <code>Tqvwgt *eqphki /kh + % "cwvq" squ "xqkr" vtwuv</code> | Configures autoQoS for marked traffic. |
| Step 4 | <code>Tqvwgt *eqphki /kh + % "gpf"</code>                   | Returns to privileged EXEC mode.       |

When configuring autoQoS to trust marked traffic, note the following information:

- To disable autoQoS on an interface, use the **no auto qos voip** interface configuration command.



**Note** The **no auto qos voip** interface configuration command does not delete the **received CoS to internal DSCP map** created by autoQoS.

- For ports configured with the **switchport** command, you might see messages that instruct you to configure other ports to trust CoS. You must do so to enable the autoQoS generated commands.

This example shows how to enable autoQoS on Gigabit Ethernet interface 1/1:

```
Tqvwgt *eqphki + % "kpvgt hceg" iki cdkvgvjgtpgv "313"
Tqvwgt *eqphki /kh + % "cwvq" squ "xqkr" vtwuv
```

Displays the configured autoQoS commands.

```
Tqvwgt% "ujqy" cwvq "squ" kpvgt hceg "type slot/port"
```

For ports configured with the **switchport** command, displays the generated **received CoS to internal DSCP map**.

```
Tqvwgt% "ujqy" twppkpi/eqphki "~" kpenwfg "squ" ocr "equ/fuer"
```



**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





# MPLS QoS

---

- Terminology, page 67-2
- MPLS QoS Features, page 67-2
- MPLS QoS Overview, page 67-4
- MPLS QoS, page 67-5
- MPLS QoS Default Configuration, page 67-13
- MPLS QoS Commands, page 67-15
- MPLS QoS Restrictions, page 67-15
- How to Configure MPLS QoS, page 67-16
- MPLS DiffServ Tunneling Modes, page 67-26
- How to Configure Short Pipe Mode, page 67-30
- How to Configure Uniform Mode, page 67-34



## Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- MPLS QoS extends to MPLS traffic the PFC QoS features described in [Chapter 62, “PFC QoS Overview.”](#)
- This chapter provides supplemental information on MPLS QoS features. Be sure that you understand the PFC QoS features before you read this chapter.



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

# Terminology

- *Class of Service* (CoS) refers to three bits in an 802.1Q header that are used to indicate the priority of the Ethernet frame as it passes through a switched network. The CoS bits in the 802.1Q header are commonly referred to as the 802.1p bits. To maintain QoS when a packet traverses both Layer 2 and Layer 3 domains, the type of service (ToS) and CoS values can be mapped to each other.
- *Classification* is the process used for selecting traffic to be marked for QoS.
- *Differentiated Services Code Point* (DSCP) is the first six bits of the ToS byte in the IP header. DSCP is only present in an IP packet.
- *E-LSP* is a label switched path (LSP) on which nodes infer the QoS treatment for MPLS packets exclusively from the experimental (EXP) bits in the MPLS header. Because the QoS treatment is inferred from the EXP (both class and drop precedence), several classes of traffic can be multiplexed onto a single LSP (use the same label). A single LSP can support up to eight classes of traffic because the EXP field is a 3-bit field. The maximum number of classes would be less after reserving some values for control plane traffic or if some of the classes have a drop precedence associated with them.
- *EXP bits* define the QoS treatment (per-hop behavior) that a node should give to a packet. It is the equivalent of the DiffServ Code Point (DSCP) in the IP network. A DSCP defines a class and drop precedence. The EXP bits are generally used to carry all the information encoded in the IP DSCP. In some cases, however, the EXP bits are used exclusively to encode the dropping precedence.
- *Frames* carry traffic at Layer 2. Layer 2 frames carry Layer 3 packets.
- *IP precedence* is the three most significant bits of the ToS byte in the IP header.
- *QoS tags* are prioritization values carried in Layer 3 packets and Layer 2 frames. A Layer 2 CoS label can have a value ranging between zero for low priority and seven for high priority. A Layer 3 IP precedence label can have a value ranging between zero for low priority and seven for high priority. IP precedence values are defined by the three most significant bits of the 1-byte ToS byte. A Layer 3 DSCP label can have a value between 0 and 63. DSCP values are defined by the six most significant bits of the 1-byte IP ToS field.
- *LERs* (label edge routers) are devices that impose and dispose of labels upon packets; also referred to as Provider Edge (PE) routers.
- *LSRs* (label switching routers) are devices that forward traffic based upon labels present in a packet; also referred to as Provider (P) routers.
- *Marking* is the process of setting a Layer 3 DSCP value in a packet. Marking is also the process of choosing different values for the MPLS EXP field to mark packets so that they have the priority that they require during periods of congestion.
- *Packets* carry traffic at Layer 3.
- *Policing* is limiting bandwidth used by a flow of traffic. Policing can mark or drop traffic.

## MPLS QoS Features

- [MPLS Experimental Field, page 67-3](#)
- [Trust, page 67-3](#)
- [Classification, page 67-3](#)
- [Policing and Marking, page 67-3](#)

- [Preserving IP ToS, page 67-4](#)
- [EXP Mutation, page 67-4](#)
- [MPLS DiffServ Tunneling Modes, page 67-4](#)

## MPLS Experimental Field

Setting the MPLS experimental (EXP) field value satisfies the requirement of service providers who do not want the value of the IP precedence field modified within IP packets transported through their networks.

By choosing different values for the MPLS EXP field, you can mark packets so that packets have the priority that they require during periods of congestion.

By default, the IP precedence value is copied into the MPLS EXP field during imposition. You can mark the MPLS EXP bits with an MPLS QoS policy.

## Trust

For received Layer 3 MPLS packets, the PFC usually trusts the EXP value in the received topmost label. None of the following have any effect on MPLS packets:

- Interface trust state
- Port CoS value
- Policy-map **trust** command

For received Layer 2 MPLS packets, the PFC can either trust the EXP value in the received topmost label or apply port trust or policy trust to the MPLS packets for CoS and egress queuing purposes.

## Classification

Classification is the process that selects the traffic to be marked. Classification accomplishes this by partitioning traffic into multiple priority levels, or classes of service. Traffic classification is the primary component of class-based QoS provisioning. The PFC makes classification decisions based on the EXP bits in the received topmost label of received MPLS packets (after a policy is installed). See the [“Configuring a Class Map to Classify MPLS Packets” section on page 67-17](#) for information.

## Policing and Marking

Policing causes traffic that exceeds the configured rate to be discarded or marked down to a higher drop precedence. Marking is a way to identify packet flows to differentiate them. Packet marking allows you to partition your network into multiple priority levels or classes of service.

The MPLS QoS policing and marking features that you can implement depend on the received traffic type and the forwarding operation applied to the traffic. See [“Configuring a Policy Map” section on page 67-20](#) for information.

## Preserving IP ToS

The PFC automatically preserves the IP ToS during all MPLS operations including imposition, swapping, and disposition. You do not need to enter a command to save the IP ToS.

## EXP Mutation

You can configure up to eight egress EXP mutation maps to mutate the internal EXP value before it is written as the egress EXP value. You can attach egress EXP mutation maps to these interface types:

- LAN port subinterfaces
- Layer 3 VLAN interfaces
- Layer 3 LAN ports

You cannot attach EXP mutation maps to Layer 2 LAN ports (ports configured with the **switchport** command).

For configuration information, see the [“Configuring MPLS QoS Egress EXP Mutation” section on page 67-24](#).

## MPLS DiffServ Tunneling Modes

The PFC uses MPLS DiffServ tunneling modes. Tunneling provides QoS transparency from one edge of a network to the other edge of the network. See the [“MPLS DiffServ Tunneling Modes” section on page 67-26](#) for information.

## MPLS QoS Overview

MPLS QoS enables network administrators to provide differentiated types of service across an MPLS network. Differentiated service satisfies a range of requirements by supplying for each transmitted packet the service specified for that packet by its QoS. Service can be specified in different ways, for example, using the IP precedence bit settings in IP packets.

## Specifying the QoS in the IP Precedence Field

When you send IP packets from one site to another, the IP precedence field (the first three bits of the DSCP field in the header of an IP packet) specifies the QoS. Based on the IP precedence marking, the packet is given the treatment configured for that quality of service. If the service provider network is an MPLS network, then the IP precedence bits are copied into the MPLS EXP field at the edge of the network. However, the service provider might want to set QoS for an MPLS packet to a different value determined by the service offering.

In that case, the service provider can set the MPLS EXP field. The IP header remains available for the customer’s use; the QoS of an IP packet is not changed as the packet travels through the MPLS network.


For more information, see the [“MPLS DiffServ Tunneling Modes” section on page 67-26](#).

# MPLS QoS

- [MPLS Topology Overview, page 67-5](#)
- [LERs at the Input Edge of an MPLS Network, page 67-6](#)
- [LSRs in the Core of an MPLS Network, page 67-6](#)
- [LERs at the Output Edge of an MPLS Network, page 67-7](#)
- [LERs at the EoMPLS Edge, page 67-7](#)
- [LERs at the IP Edge \(MPLS, MPLS VPN\), page 67-8](#)
- [LSRs at the MPLS Core, page 67-11](#)

## MPLS Topology Overview

**Figure 67-1** *MPLS Network Connecting Two Sites of a Customer's IP Network*



- Networks are bidirectional, but for the purpose of this overview, the packets move left to right.
- CE1—Customer equipment 1
- PE1—Service provider ingress label edge router (LER)
- P1—Label switch router (LSR) within the core of the network of the service provider
- P2—LSR within the core of the network of the service provider
- PE2—service provider egress LER
- CE2—Customer equipment 2
- PE1 and PE2 are at the boundaries between the MPLS network and the IP network.

MPLS QoS supports IP QoS. For MPLS packets, the EXP value is mapped into an internal DSCP so that the PFC can apply non-MPLS QoS marking and policing.

For both the ingress and egress policies, MPLS QoS marking and policing decisions are made on a per-interface basis at an ingress PFC. The ingress interfaces are physical ports, subinterfaces, or VLANs.

The QoS policy ACLs are programmed in QoS TCAM separately for ingress and egress lookup. The ternary content addressable memory (TCAM) egress lookup takes place after the IP forwarding table (FIB) and NetFlow lookups are completed.

The results of each QoS TCAM lookup yield an index into RAM that contains policer configuration and policing counters. Additional RAM contains the microflow policer configuration; the microflow policing counters are maintained in the respective NetFlow entries that match the QoS ACL.

The results of ingress and egress aggregate and microflow policing are combined into a final policing decision. The out-of-profile packets can be either dropped or marked down in the DSCP.

## LERs at the Input Edge of an MPLS Network



### Note

Incoming labels are aggregate or nonaggregate. The aggregate label indicates that the arriving MPLS or MPLS VPN packet must be switched through an IP lookup to find the next hop and the outgoing interface. The nonaggregate label indicates that the packet contains the IP next hop information.

This section describes how edge LERs can operate at either the ingress or the egress side of an MPLS network.

At the ingress side of an MPLS network, LERs process packets as follows:

1. Layer 2 or Layer 3 traffic enters the edge of the MPLS network at the edge LER (PE1).
2. The PFC receives the traffic from the input interface and uses the 802.1p bits or the IP ToS bits to determine the EXP bits and to perform any classification, marking, and policing. For classification of incoming IP packets, the input service policy can also use access control lists (ACLs).
3. For each incoming packet, the PFC performs a lookup on the IP address to determine the next-hop router.
4. The appropriate label is pushed (imposition) into the packet, and the EXP value resulting from the QoS decision is copied into the MPLS EXP field in the label header.
5. The PFC forwards the labeled packets to the appropriate output interface for processing.
6. The PFC also forwards the 802.1p bits or the IP ToS bits to the output interface.
7. At the output interface, the labeled packets are differentiated by class for marking or policing. For LAN interfaces, egress classification is still based on IP, not on MPLS.
8. The labeled packets (marked by EXP) are sent to the core MPLS network.

## LSRs in the Core of an MPLS Network

This section describes how LSRs used at the core of an MPLS network process packets:

1. Incoming MPLS-labeled packets (and 802.1p bits or IP ToS bits) from an edge LER (or other core device) arrive at the core LSR.
2. The PFC receives the traffic from the input interface and uses the EXP bits to perform classification, marking, and policing.
3. The PFC or DFCs perform a table lookup to determine the next-hop LSR.
4. An appropriate label is placed (swapped) into the packet and the MPLS EXP bits are copied into the label header.
5. The PFC forwards the labeled packets to the appropriate output interface for processing.
6. The PFC also forwards the 802.1p bits or the IP ToS bits to the output interface.
7. The outbound packet is differentiated by the MPLS EXP field for marking or policing.



8. The labeled packets (marked with EXP) are sent to another LSR in the core MPLS network or to an LER at the output edge.

**Note**

Within the service provider network, there is no IP precedence field for the queueing algorithm to use because the packets are MPLS packets. The packets remain MPLS packets until they arrive at PE2, the provider edge router.

## LERs at the Output Edge of an MPLS Network

At the egress side of an MPLS network, LERs process packets as follows:

1. MPLS-labeled packets (and 802.1p bits or IP ToS bits) from a core LSR arrive at the egress LER (PE2) from the MPLS network backbone.
2. The PFC pops the MPLS labels (disposition) from the packets. Aggregate labels are classified using the original 802.1p bits or the IP ToS bits. Nonaggregate labels are classified with the EXP value by default.
3. For aggregate labels, the PFC performs a lookup on the IP address to determine the packet's destination; the PFC then forwards the packet to the appropriate output interface for processing. For non-aggregate labels, forwarding is based on the label. By default, non-aggregate labels are popped at the penultimate-hop router (next to last), not the egress PE router.
4. The PFC also forwards the 802.1p bits or the IP ToS bits to the output interface.
5. The packets are differentiated according to the 802.1p bits or the IP ToS bits and treated accordingly.

**Note**

The MPLS EXP bits allow you to specify the QoS for an MPLS packet. The IP precedence and DSCP bits allow you to specify the QoS for an IP packet.

## LERs at the EoMPLS Edge

This section summarizes the Ethernet over MPLS (EoMPLS) QoS features that function on the LERs. EoMPLS QoS support is similar to IP-to-MPLS QoS:

- For EoMPLS, if the port is untrusted, the CoS trust state is automatically configured for VC type 4 (VLAN mode), not for VC type 5 (port mode). 802.1q CoS preservation across the tunnel is similar.
- Packets received on tunnel ingress are treated as untrusted for EoMPLS interfaces, except for VC Type 4 where trust CoS is automatically configured on the ingress port and policy marking is not applied.
- If the ingress port is configured as trusted, packets received on an EoMPLS interface are never marked by QoS policy in the original IP packet header (marking by IP policy works on untrusted ports).
- 802.1p CoS is preserved from entrance to exit, if available through the 802.1q header.
- After exiting the tunnel egress, queueing is based on preserved 802.1p CoS if 1p tag has been tunneled in the EoMPLS header (VC type 4); otherwise, queueing is based on the CoS derived from the QoS decision.

## LERs at the IP Edge (MPLS, MPLS VPN)

This section provides information about QoS features for LERs at the ingress (CE-to-PE) and egress (PE-to-CE) edges for MPLS and MPLS VPN networks. Both MPLS and MPLS VPN support general MPLS QoS features. See the [“MPLS VPN” section on page 67-11](#) for additional MPLS VPN-specific QoS information.

### IP to MPLS

- [IP to MPLS Overview, page 67-8](#)
- [Classification for IP-to-MPLS, page 67-8](#)
- [Classification for IP-to-MPLS Mode MPLS QoS, page 67-9](#)
- [Classification at IP-to-MPLS Ingress Port, page 67-9](#)
- [Classification at IP-to-MPLS Egress Port, page 67-9](#)

#### IP to MPLS Overview

The PFC provides the following MPLS QoS capabilities at the IP-to-MPLS edge:

- Assigning an EXP value based on the **platform qos trust** or **policy-map** command
- Marking an EXP value using a policy
- Policing traffic using a policy

This section provides information about the MPLS QoS classification that the PFC supports at the IP-to-MPLS edge. Additionally, this section provides information about the capabilities provided by the ingress and egress interface modules. For Ethernet to MPLS, the ingress interface, MPLS QoS, and egress interface features are similar to corresponding features for IP to MPLS.

#### Classification for IP-to-MPLS

The PFC ingress and egress policies for IP traffic classify traffic on the original received IP using **match** commands for IP precedence, IP DSCP, and IP ACLs. Egress policies do not classify traffic on the imposed EXP value nor on a marking done by an ingress policy.

After the PFC applies the port trust and QoS policies, it assigns the internal DSCP. The PFC then assigns the EXP value based on the internal DSCP-to-EXP global map for the labels that it imposes. If more than one label is imposed, the EXP value is the same in each label. The PFC preserves the original IP ToS when the MPLS labels are imposed.

The PFC assigns the egress CoS based on the internal DSCP-to-CoS global map. If the default internal DSCP-to-EXP and the internal DSCP-to-CoS maps are consistent, then the egress CoS has the same value as the imposed EXP.

If the ingress port receives both IP-to-IP and IP-to-MPLS traffic, classification should be used to separate the two types of traffic. For example, if the IP-to-IP and IP-to-MPLS traffic have different destination address ranges, you can classify traffic on the destination address, and then apply IP ToS policies to the IP-to-IP traffic and apply a policy (that marks or sets the EXP value in the imposed MPLS header) to the IP-to-MPLS traffic. See the following two examples:

- A PFC policy to mark IP ToS sets the internal DSCP—If it is applied to all traffic, then for IP-to-IP traffic, the egress port will rewrite the CoS (derived from the internal DSCP) to the IP ToS byte in the egress packet. For IP-to-MPLS traffic, the PFC will map the internal DSCP to the imposed EXP value.
- A PFC policy to mark MPLS EXP sets the internal DSCP—If it is applied to all traffic, then for IP-to-IP traffic, the egress port rewrites the IP ToS according to the ingress IP policy (or trust). The CoS is mapped from the ToS. For IP-to-MPLS traffic, the PFC will map the internal DSCP to the imposed EXP value.

### Classification for IP-to-MPLS Mode MPLS QoS

MPLS QoS at the ingress to PE1 supports:

- Matching on IP precedence or DSCP values or filtering with an access group
- The **set mpls experimental imposition** and **police** commands

MPLS QoS at the egress of PE1 supports the **mpls experimental topmost** command.

### Classification at IP-to-MPLS Ingress Port

Classification for IP-to-MPLS is the same as for IP-to-IP. LAN port classification is based on the received Layer 2 802.1Q CoS value.

### Classification at IP-to-MPLS Egress Port

LAN port classification is based on the received EXP value and the egress CoS values is mapped from that value.

If the egress port is a trunk, the LAN ports copy the egress CoS into the egress 802.1Q field.

## MPLS to IP

- [MPLS to IP Overview, page 67-9](#)
- [Classification for MPLS-to-IP, page 67-10](#)
- [Classification for MPLS-to-IP MPLS QoS, page 67-10](#)
- [Classification at MPLS-to-IP Ingress Port, page 67-10](#)
- [Classification at MPLS-to-IP Egress Port, page 67-11](#)

### MPLS to IP Overview

MPLS QoS supports these capabilities at the MPLS-to-IP edge:

- Option to propagate EXP value into IP DSCP on exit from an MPLS domain per egress interface
- Option to use IP service policy on the MPLS-to-IP egress interface

This section provides information about the MPLS-to-IP MPLS QoS classification. Additionally, this section provides information about the capabilities provided by the ingress and egress modules.

For MPLS to Ethernet, the ingress interface, MPLS QoS, and egress interface features are similar to corresponding features for MPLS to IP except for the case of EoMPLS decapsulation where egress IP policy cannot be applied (packets can be classified as MPLS only).

### Classification for MPLS-to-IP

The PFC assigns the internal DSCP (internal priority that the PFC assigns to each frame) based on the QoS result. The QoS result is affected by the following:

- Default trust EXP value
- Label type (per-prefix or aggregate)
- Number of VPNs
- Explicit NULL use
- QoS policy

There are three different classification modes:

- Regular MPLS classification—For nonaggregate labels, in the absence of MPLS recirculation, the PFC classifies the packet based on MPLS EXP ingress or egress policy. The PFC queues the packet based on COS derived from EXP-to-DSCP-to-CoS mapping. The underlying IP DSCP is either preserved after egress decapsulation, or overwritten from the EXP (through the EXP-to-DSCP map).
- IP classification for aggregate label hits in VPN CAM—The PFC does one of the following:
  - Preserves the underlying IP ToS
  - Rewrites the IP ToS by a value derived from the EXP-to-DSCP global map
  - Changes the IP ToS to any value derived from the egress IP policy

In all cases, egress queueing is based on the final IP ToS from the DSCP-to-CoS map.

- IP classification with aggregate labels not in VPN CAM—After recirculation, the PFC differentiates the MPLS-to-IP packets from the regular IP-to-IP packets based on the ingress reserved VLAN specified in the MPLS decapsulation adjacency. The reserved VLAN is allocated per VRF both for VPN and non-VPN cases. The ingress ToS after recirculation can be either the original IP ToS value, or derived from the original EXP value. The egress IP policy can overwrite this ingress ToS to an arbitrary value.



#### Note

For information about recirculation, see the [“Recirculation” section on page 37-5](#).

For incoming MPLS packets on the PE-to-CE ingress, the PFC supports MPLS classification only. Ingress IP policies are not supported. PE-to-CE traffic from the MPLS core is classified or policed on egress as IP.

### Classification for MPLS-to-IP MPLS QoS

MPLS QoS at the ingress to PE2 supports matching on the EXP value and the **police** command.

MPLS QoS at the egress of PE2 supports matching on IP precedence or DSCP values or filtering with an access group and the **police** command.

### Classification at MPLS-to-IP Ingress Port

LAN port classification is based on the EXP value. The **match mpls experimental** command matches on the EXP value in the received topmost label.

## Classification at MPLS-to-IP Egress Port

Classification for MPLS-to-IP is the same as it is for IP-to-IP.

The LAN interface classification is based on the egress CoS.

If the egress port is a trunk, the LAN ports copy the egress CoS into the egress 802.1Q field.



**Note**

For MPLS to IP, egress IP ACL or QoS is not effective on the egress interface if the egress interface has MPLS IP (or tag IP) enabled. The exception is a VPN CAM hit, in which case the packet is classified on egress as IP.

## MPLS VPN

The following PE MPLS QoS features are supported for MPLS VPN:

- Classification, policing, or marking of CE-to-PE IP traffic through the VPN subinterface
- Per-VPN QoS (per-port, per-VLAN, or per-subinterface)

For customer edge (CE)-to-PE traffic, or for CE-to-PE-to-CE traffic, the subinterface support allows you to apply IP QoS ingress or egress policies to subinterfaces and to physical interfaces. Per-VPN policing is also provided for a specific interface or subinterface associated with a given VPN on the CE side.

In situations when there are multiple interfaces belonging to the same VPN, you can perform per-VPN policing aggregation using the same shared policer in the ingress or egress service policies for all similar interfaces associated with the same PFC.

For aggregate VPN labels, the EXP propagation in recirculation case may not be supported because MPLS adjacency does not know which egress interface the final packet will use.



**Note**

For information on recirculation, see the [“Recirculation” section on page 37-5](#).

The PFC propagates the EXP value if all interfaces in the VPN have EXP propagation enabled.

The following PE MPLS QoS features are supported:

- General MPLS QoS features for IP packets
- Classification, policing, or marking of CE-to-PE IP traffic through the VPN subinterface
- Per-VPN QoS (per-port, per-VLAN, or per-subinterface)

## LSRs at the MPLS Core

This section provides information about MPLS QoS features for LSRs at the core (MPLS-to-MPLS) for MPLS and MPLS VPN networks. Ingress features, egress interface, and PFC features for Carrier Supporting Carrier (CsC) QoS features are similar to those used with MPLS to MPLS described in the next section. A difference between CsC and MPLS to MPLS is that with CsC labels can be imposed inside the MPLS domain.

## MPLS to MPLS

- [Classification for MPLS-to-MPLS, page 67-12](#)
- [Classification for MPLS-to-MPLS MPLS QoS, page 67-13](#)

- [Classification at MPLS-to-MPLS Ingress Port, page 67-13](#)
- [Classification at MPLS-to-MPLS Egress Port, page 67-13](#)

## MPLS to MPLS Overview

MPLS QoS at the MPLS core supports the following:

- Per-EXP policing based on a service policy
- Copying the input topmost EXP value into the newly imposed EXP value
- Optional EXP mutation (changing of EXP values on an interface edge between two neighboring MPLS domains) on the egress boundary between MPLS domains
- Microflow policing based on individual label flows for a particular EXP value
- Optional propagation of topmost EXP value into the underlying EXP value when popping the topmost label from a multi-label stack.

The following section provides information about MPLS-to-MPLS MPLS QoS classification. Additionally, the section provides information about the capabilities provided by the ingress and egress modules.

## Classification for MPLS-to-MPLS

For received MPLS packets, the PFC ignores the port trust state, the ingress CoS, and any policy-map **trust** commands. Instead, the PFC trusts the EXP value in the topmost label.



### Note

The MPLS QoS ingress and egress policies for MPLS traffic classify traffic on the EXP value in the received topmost label when you enter the **match mpls experimental** command.

MPLS QoS maps the EXP value to the internal DSCP using the EXP-to-DSCP global map. What the PFC does next depends on whether it is swapping labels, imposing a new label, or popping a label:

- Swapping labels—When swapping labels, the PFC preserves the EXP value in the received topmost label and copies it to the EXP value in the outgoing topmost label. The PFC assigns the egress CoS using the internal DSCP-to-CoS global map. If the DSCP global maps are consistent, then the egress CoS is based on the EXP in the outgoing topmost label.

The PFC can mark down out-of-profile traffic using the **police** command's **exceed** and **violate** actions. It does not mark in-profile traffic, so the **conform** action must be transmitted and the **set** command cannot be used. If the PFC is performing a markdown, it uses the internal DSCP as an index into the internal DSCP markdown map. The PFC maps the result of the internal DSCP markdown to an EXP value using the internal DSCP-to-EXP global map. The PFC rewrites the new EXP value to the topmost outgoing label and does not copy the new EXP value to the other labels in the stack. The PFC assigns the egress CoS using the internal DSCP-to-CoS global map. If the DSCP maps are consistent, then the egress CoS is based on the EXP value in the topmost outgoing label.

- Imposing an additional label—When imposing a new label onto an existing label stack, the PFC maps the internal DSCP to the EXP value in the imposed label using the internal DSCP-to-EXP map. It then copies the EXP value in the imposed label to the underlying swapped label. The PFC assigns the egress CoS using the internal DSCP-to-CoS global map. If the DSCP maps are consistent, the egress CoS is based on the EXP value in the imposed label.

The PFC can mark in-profile and mark down out-of-profile traffic. After it marks the internal DSCP, the PFC uses the internal DSCP-to-EXP global map to map the internal DSCP to the EXP value in the newly imposed label. The PFC then copies the EXP in the imposed label to the underlying swapped label. The PFC assigns the egress CoS using the internal DSCP-to-CoS global map. Therefore, the egress CoS is based on the EXP in the imposed label.

- Popping a label—When popping a label from a multi-label stack, the PFC preserves the EXP value in the exposed label. The PFC assigns the egress CoS using the internal DSCP-to-CoS global map. If the DSCP maps are consistent, then the egress CoS is based on the EXP value in the popped label.
- If EXP propagation is configured for the egress interface, the PFC maps the internal DSCP to the EXP value in the exposed label using the DSCP-to-EXP global map. The PFC assigns the egress CoS using the internal DSCP-to-CoS global map. If the DSCP maps are consistent, the egress CoS is based on the EXP value in the exposed label.

### Classification for MPLS-to-MPLS MPLS QoS

MPLS QoS at the ingress to P1 or P2 supports the following:

- Matching with the **mpls experimental topmost** command
- The **set mpls experimental imposition, police**, and **police** with **set imposition** commands

MPLS QoS at the egress of P1 or P2 supports matching with the **mpls experimental topmost** command.

### Classification at MPLS-to-MPLS Ingress Port

LAN port classification is based on the egress CoS from the PFC. The **match mpls experimental** command matches on the EXP value in the received topmost label.

### Classification at MPLS-to-MPLS Egress Port

LAN port classification is based on the egress CoS value from the PFC. The **match mpls experimental** command matches on the egress CoS; it does not match on the EXP in the topmost label. If the egress port is a trunk, the LAN ports copy the egress CoS into the egress 802.1Q field.

## MPLS QoS Default Configuration

| Feature                     | Default Value                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PFC QoS global enable state | With all other PFC QoS parameters at default values, default EXP is mapped from IP precedence.<br><br>With PFC QoS enabled and all other PFC QoS parameters at default values, PFC QoS sets Layer 3 DSCP to zero ( <b>untrusted</b> ports only), Layer 2 CoS to zero, the imposed EXP to zero in all traffic transmitted from LAN ports (default is untrusted). For trust CoS, the default EXP value is mapped from CoS; for trust DSCP, the default EXP value is mapped from IP precedence. |
| PFC QoS port enable state   | Enabled when PFC QoS is globally enabled                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Port CoS value              | 0                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Microflow policing          | Enabled                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

| Feature                                                           | Default Value                                                                                                                                                                                                                      |
|-------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| IntraVLAN microflow policing                                      | Disabled                                                                                                                                                                                                                           |
| Port-based or VLAN-based PFC QoS                                  | Port-based                                                                                                                                                                                                                         |
| EXP to DSCP map<br>(DSCP set from EXP values)                     | EXP 0 = DSCP 0<br>EXP 1 = DSCP 8<br>EXP 2 = DSCP 16<br>EXP 3 = DSCP 24<br>EXP 4 = DSCP 32<br>EXP 5 = DSCP 40<br>EXP 6 = DSCP 48<br>EXP 7 = DSCP 56                                                                                 |
| IP precedence to DSCP map<br>(DSCP set from IP precedence values) | IP precedence 0 = DSCP 0<br>IP precedence 1 = DSCP 8<br>IP precedence 2 = DSCP 16<br>IP precedence 3 = DSCP 24<br>IP precedence 4 = DSCP 32<br>IP precedence 5 = DSCP 40<br>IP precedence 6 = DSCP 48<br>IP precedence 7 = DSCP 56 |
| DSCP to EXP map<br>(EXP set from DSCP values)                     | DSCP 0–7 = EXP 0<br>DSCP 8–15 = EXP 1<br>DSCP 16–23 = EXP 2<br>DSCP 24–31 = EXP 3<br>DSCP 32–39 = EXP 4<br>DSCP 40–47 = EXP 5<br>DSCP 48–55 = EXP 6<br>DSCP 56–63 = EXP 7                                                          |
| Marked-down DSCP from DSCP map                                    | Marked-down DSCP value equals original DSCP value<br>(no mark down)                                                                                                                                                                |
| EXP mutation map                                                  | No mutation map by default                                                                                                                                                                                                         |
| Policers                                                          | None                                                                                                                                                                                                                               |
| Policy maps                                                       | None                                                                                                                                                                                                                               |
| MPLS flow mask in NetFlow table                                   | Label + EXP value                                                                                                                                                                                                                  |



| Feature             | Default Value                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| MPLS core QoS       | <p>There are four possibilities at the MPLS core QoS:</p> <ul style="list-style-type: none"> <li>Swapping—Incoming EXP field is copied to outgoing EXP field.</li> <li>Swapping + imposition—Incoming EXP field is copied to both the swapped EXP field and the imposed EXP field.</li> </ul> <p><b>Note</b> If there is a service policy with a set for EXP field, its EXP field will be placed into the imposed label and also into the swapped label.</p> <ul style="list-style-type: none"> <li>Disposition of topmost label—Exposed EXP field is preserved.</li> <li>Disposition of only label—Exposed IP DSCP is preserved.</li> </ul> |
| MPLS to IP edge QoS | Preserve the exposed IP DSCP                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

## MPLS QoS Commands

MPLS QoS supports the following MPLS QoS commands:

- **match mpls experimental topmost**
- **set mpls experimental imposition**
- **police**
- **platform qos map exp-dscp**
- **platform qos map dscp-exp**
- **platform qos map exp-mutation**
- **platform qos exp-mutation**
- **show platform qos mpls**
- **no platform qos mpls trust exp**



**Note**

For information about supported non-MPLS QoS commands, see [Chapter 62, “PFC QoS Overview.”](#)

The following commands are not supported:

- **set qos-group**
- **set discard-class**

## MPLS QoS Restrictions

When configuring MPLS QoS, follow these guidelines and restrictions:

- For IP-to-MPLS or EoMPLS imposition when the received packet is an IP packet:

- When QoS is disabled, the EXP value is based on the received IP ToS.
- When QoS is queuing only, the EXP value is based on the received IP ToS.
- For EoMPLS imposition when the received packet is a non-IP packet:
  - When QoS is disabled, the EXP value is based on the ingress CoS.
  - When QoS is queuing only, the EXP value is based on the received IP ToS.
- For MPLS-to-MPLS operations:
  - Swapping when QoS is disabled, the EXP value is based on the original EXP value (in the absence of EXP mutation).
  - Swapping when QoS is queuing only, the EXP value is based on the original EXP value (in the absence of EXP mutation).
  - Imposing additional label when QoS is disabled, the EXP value is based on the original EXP value (in the absence of EXP mutation).
  - Imposing an additional label when QoS is queuing only, the EXP value is based on the original EXP value (in the absence of EXP mutation).
  - Popping one label when QoS is disabled, the EXP value is based on the underlying EXP value.
  - Popping one label when QoS is queuing only, the EXP value is based on the underlying EXP value.
- EXP value is irrelevant to MPLS-to-IP disposition.
- The **no platform qos rewrite ip dscp** command is incompatible with MPLS. The default **platform qos rewrite ip dscp** command must remain enabled in order for the PFC to assign the correct EXP value for the labels that it imposes.
- The **no platform qos mpls trust exp** command allows you to treat MPLS packets similarly to Layer 2 packets for CoS and egress queueing purposes by applying port trust or policy trust instead of the default EXP value.

## How to Configure MPLS QoS

- [Enabling Queueing-Only Mode, page 67-17](#)
- [Configuring a Class Map to Classify MPLS Packets, page 67-17](#)
- [Configuring a Policy Map, page 67-20](#)
- [Displaying a Policy Map, page 67-24](#)
- [Configuring MPLS QoS Egress EXP Mutation, page 67-24](#)
- [Configuring EXP Value Maps, page 67-25](#)

## Enabling Queueing-Only Mode

To enable queueing-only mode, perform this task:

|        | Command                                                     | Purpose                     |
|--------|-------------------------------------------------------------|-----------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "rncvhtqto"squ"swgwgkpi/qpn{ "</code> | Enables queueing-only mode. |
| Step 2 | <code>Tqvwgt*eqphki+% "gpf"</code>                          | Exits configuration mode.   |

When you enable queueing-only mode, the router does the following:

- Disables marking and policing globally
- Configures all ports to trust Layer 2 CoS



**Note** The switch applies the port CoS value to untagged ingress traffic and to traffic that is received through ports that cannot be configured to trust CoS.

This example shows how to enable queueing-only mode:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+% "rncvhtqto"squ"swgwgkpi/qpn{ "
Tqvwgt*eqphki+% "gpf"
Tqvwgt%
```

## Restrictions and Usage Guidelines

If QoS is disabled (**no platform qos**) for the PFC, the EXP value is determined as follows:

- For IP-to-MPLS or EoMPLS imposition when the received packet is an IP packet when QoS is queueing only (**platform qos queueing-only**), the EXP value is based on the received IP ToS.
- For EoMPLS imposition when the received packet is a non-IP packet when QoS is queueing only, the EXP value is based on the received IP ToS.
- For MPLS-to-MPLS operations:
  - Swapping when QoS is queueing only, the EXP value is based on the original EXP value (in the absence of EXP mutation).
  - Imposing additional label when QoS is queueing only, the EXP value is based on the original EXP value (in the absence of EXP mutation).
  - Popping one label when QoS is queueing only, the EXP value is based on the underlying EXP value.
- The EXP value is irrelevant to MPLS-to-IP disposition.

## Configuring a Class Map to Classify MPLS Packets

You can use the **match mpls experimental topmost** command to define traffic classes inside the MPLS domain by packet EXP values. This allows you to define service policies to police the EXP traffic on a per-interface basis by using the **police** command.

To configure a class map, perform this task beginning in global configuration mode:

|        | Command                                                                         | Purpose                                                                 |
|--------|---------------------------------------------------------------------------------|-------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"encuu/ocr"</b>encuuapcog"</code>                       | Specifies the class map to which packets will be matched.               |
| Step 2 | <code>Tqwvgt*eqphki/eocr+%<b>"ocvej"ornu"gzrgtkogpvcn"vqroquv"xcnwg"</b></code> | Specifies the packet characteristics that will be matched to the class. |
| Step 3 | <code>Tqwvgt*eqphki/eocr+%<b>"gzkv"</b></code>                                  | Exits class-map configuration mode.                                     |

This example shows that all packets that contain MPLS experimental value 3 are matched by the traffic class named exp3:

```

Tqwvgt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpq0""Gpf"ykvj"EPVN1\0
Tqwvgt*eqphki+%"encuu/ocr"gzr5"
Tqwvgt*eqphki/eocr+%"ocvej"ornu"gzrgtkogpvcn"vqroquv"5"
Tqwvgt*eqphki/eocr+%"gzkv"
Tqwvgt*eqphki+%"rqnke{/ocr"gzr5"
Tqwvgt*eqphki/rocr+%"encuu"gzr5"
Tqwvgt*eqphki/rocr/e+%"rqnkeg"322222":22222"eqphqto/cevkqp"vtcpuokv"gzeggf/cevkqp"ftqr"
Tqwvgt*eqphki/rocr/e+%"gzkv"
Tqwvgt*eqphki/rocr+%"gpf"
Tqwvgt%"ujqy"encuu"gzr5"
"Encuu"Ocr"ocvej/cnn"gzr5"*kf"83+
""Ocvej"ornu"gzrgtkogpvcn"vqroquv"5
Tqwvgt%"ujqy"rqnke{/ocr"gzr5"
""Rqnke{"Ocr"gzr5
""Encuu"gzr5
""""rqnkeg"ekt"322222"de":22222"dg":22222"eqphqto/cevkqp"vtcpuokv"gzeggf/cevkqp"ftqr
Tqwvgt%"ujqy"twppkpi/eqphki"kpvgthceg"ikicdkvgvjgtpgv"5149"
Dwknfkpi"eqphkiwtcvkqp000

Ewttgvpv"eqphkiwtcvkqp"<"395"d{vgu
#
kpvgthceg"IkicdkvGvjgtpgv5149
""kr"cfftguu"69020203"477020202
""vci/uykvejkpi"kr
"gpff

Tqwvgt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpq0""Gpf"ykvj"EPVN1\0
Tqwvgt*eqphki+%"kpvgthceg"ikicdkvgvjgtpgv"5149"
Tqwvgt*eqphki/kh+%"ugtxkeg/rqnke{"kprwv"gzr5"
Tqwvgt*eqphki/kh+%
Tqwvgt%
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpq0""Gpf"ykvj"EPVN1\0
Tqwvgt%"ujqy"twppkpi/eqphki"kpvgthceg"ikicdkvgvjgtpgv"5149"
Dwknfkpi"eqphkiwtcvkqp000

Ewttgvpv"eqphkiwtcvkqp"<"395"d{vgu
#
kpvgthceg"IkicdkvGvjgtpgv5149
""kr"cfftguu"69020203"477020202
""vci/uykvejkpi"kr
""ugtxkeg/rqnke{"kprwv"gzr5
"gpff

Tqwvgt%
3y6f<"'U[U/7/EQPHKIaK<"Eqphkiwtgf"htqo"eqpuqng"d{"eqpuqng
Tqwvgt%"ujqy"rncvhtqo"squ"ornu"
"SqU"Uwooct{"ORNU_<""""""""*,"/ujctgf"ciitgicvgu."Oqf"/"uykvej"oqfwng+

```

```

""""Kpv"Oqf"Fkt"Encuu/ocr"FUER"Cii"Vtuvw"Hn"CiHqtyctf/D{"CiRqnkegf/D{
""""Kf""""Kf
////////////////////////////////////
""""Ik5149""7""Kp""""gxr5""2""4""fuerr""2""""2""""2

""""Cnn""7""/""Fghcwnv""2""2, ""Pq""2""""5688362645""""2
Tqvwgt%"ujqy"rqnke{/ocr"kpvgthceg"ikicdkvgvjgtpgv"5149"
IkicdkvGvjgtpgv5149

"Ugtxkeg/rqnke{"kprwv<"gxr5

""encuu/ocr<"gxr5"*ocvej/cnn+
""""Ocvej<"ornu"gzrgtkogpvcn"vqroquv"5
""""rqnkeg"<
""""322222"dru":222222"nkokv":222222"gzvgpfgf"nkokv
""""Gctn"kp"unqv"7"<
""""2"d{vgu
""""7"okpwwg"qhhgtgf"tcvg"2"dru
""""ciitgicvg/hqtyctfgf"2"d{vgu"cevkqp<"vtcpuokv
""""gzegfgf"2"d{vgu"cevkqp<"ftqr
""""ciitgicvg/hqtyctf"2"dru"gzeggf"2"dru

""Encuu/ocr<"encuu/fghcwnv"*ocvej/cp{+
""""2"rcemgvu."2"d{vgu
""""7"okpwwg"qhhgtgf"tcvg"2"dru."ftqr"tcvg"2"dru
""""Ocvej<"cp{

Tqvwgt%"eqphkiwtg"vgtokpcn"
GpvgT"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpgo""Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+"kpvgthceg"ikicdkvgvjgtpgv"5149"
Tqvwgt*eqphki/kh+"ugtxkeg/rqnke{"qvwrvw"kr4vci"
Tqvwgt*eqphki/kh+"gpf"
Tqvwgt%"ujqy"rncvhtqto"squ"kr"
"SqU"Uwooct{"]RX6_<""""*,"/ujctgf"ciitgicvgu."Oqf"/"uykvej"oqfwng+

""""Kpv"Oqf"Fkt"Encuu/ocr"FUER"Cii"Vtuvw"Hn"CiHqtyctf/D{"CiRqnkegf/D{
""""Kf""""Kf
////////////////////////////////////
""""Xn522""7""Kp""""z""66""3""Pq""2""""2""""2
""""Ik5149""7""Qwv""""krver""46""4""""/""2""""2""""2

""""Cnn""7""/""Fghcwnv""2""2, ""Pq""2""""568832963""""2

```

## Restrictions and Usage Guidelines

- The **match mpls experimental** command specifies the name of an EXP field value to be used as the match criterion against which packets are checked to determine if they belong to the class specified by the class map.
- To use the **match mpls experimental** command, you must first enter the **class-map** command to specify the name of the class whose match criteria you want to establish. After you identify the class, you can use the **match mpls experimental** command to configure its match criteria.
- If you specify more than one command in a class map, only the last command entered applies. The last command overrides the previously entered commands.

## Configuring a Policy Map

You can attach only one policy map to an interface. Policy maps can contain one or more policy map classes, each with different policy map commands.

Configure a separate policy map class in the policy map for each type of traffic that an interface receives. Put all commands for each type of traffic in the same policy map class. MPLS QoS does not attempt to apply commands from more than one policy map class to matched traffic.

## Configuring a Policy Map to Set the EXP Value on All Imposed Labels

To set the value of the MPLS EXP field on all imposed label entries, use the **set mpls experimental imposition** command in QoS policy-map class configuration mode. To disable the setting, use the **no** form of this command.



Note

The **set mpls experimental imposition** command replaces the **set mpls experimental** command.

|        | Command                                                                                                                                                                      | Purpose                                                                           |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%<b>rqnke</b>{/ocr"rqnke{apcog"</code>                                                                                                                   | Creates a policy map.                                                             |
| Step 2 | <code>Tqwgvt*eqphki/rocr+%<b>encuu/ocr</b>"pcog"]ocvej/cnn"~"<b>ocvej/cp</b>{_"</code>                                                                                       | Accesses the QoS class-map configuration mode to configure QoS class maps.        |
| Step 3 | <code>Tqwgvt*eqphki/rocr/e+%<b>ugv</b>"ornu"<b>gzrgtkogpvcn</b>"<b>korqukvkqp</b>"}<b>mpls-exp-value</b> ~"from-field"]<b>vcang</b>"<br/><code>table-map-name_</code></code> | Sets the value of the MPLS experimental (EXP) field on all imposed label entries. |
| Step 4 | <code>Tqwgvt*eqphki/rocr/e+%<b>gzkv</b></code>                                                                                                                               | Exits class-map configuration mode.                                               |

The following example sets the MPLS EXP imposition value according to the DSCP value defined in the MPLS EXP value 3:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+%ceeguu/n"323"r"ver"cp{ "cp{
Tqwgvt*eqphki+%encuu/ocr"krver
Tqwgvt*eqphki/eocr+%ocvej"cee"323
Tqwgvt*eqphki/eocr+%gzkv
Tqwgvt*eqphki+%
Tqwgvt*eqphki/eocr+%rqnke{/ocr"kr4vci
Tqwgvt*eqphki/rocr+%encuu"krver
Tqwgvt*eqphki/rocr/e+%ugv"ornu"gxr"korqukvkqp"5
Tqwgvt*eqphki/rocr/e+%gzkv
Tqwgvt*eqphki/rocr+%gzkv
Tqwgvt*eqphki+%
Tqwgvt%
3y6f<"'U[U/7/EQPHKIaK<"Eqphkiwtgf"htqo"eqpuqng"d{"eqpuqng
Tqwgvt%
Tqwgvt%"ujqy"rqnke{/ocr"kr4vci
" "Rqnke{"Ocr"kr4vci
" " "Encuu"krver
" " " "ugv"ornu"gzrgtkogpvcn"korqukvkqp"5
Tqwgvt%"ujqy"encuu"krver
"Encuu"Ocr"ocvej/cnn"krver"*kf"84+
" " "Ocvej"ceeguu/itqwr323
```

```

Tqvwgt%"eqphkiwtg"vgtokpcn"
Gpvg"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0" "Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%"kpvgtgceg"ikicdkvgvjgtpgv"5149
Tqvwgt*eqphki/kh+%"ugt"kp"kr4vci
Tqvwgt*eqphki/kh+%
Tqvwgtu
3y6f<"'U[U/7/EQPHKIaK<"Eqphkiwtgf"htqo"eqpuqng"d{"eqpuqng
Tqvwgt%"ujqy"rqn"kr4vci
" "Rqnke{"Ocr"kr4vci
" " "Encuu"krver
" " " "ugv"ornu"gzrgtkogpvcn"korqukvkqp"5
Tqvwgt%"ujqy"encuu/ocr"krver
"Encuu"Ocr"ocvej/cnn"krver"*kf"84+
" " "Ocvej"ceeguu/itqwr" "323

Tqvwgt%"ujqy"ceeguu/n"323
Gzvgpfgf"KR"ceeguu"nkuv"323
" " "32"rgtokv"ver"cp{"cp{
Tqvwgt%"ujqy"rqnke{/ocr"kpvgthceg"ikicdkvgvjgtpgv"5149
"IkicdkvGvjgtpgv5149

" "Ugtxkeg/rqnke{"kprwv<"kr4vci

" " "encuu/ocr<"krver"*ocvej/cnn+
" " " "Ocvej<"ceeguu/itqwr"323
" " " "ugv"ornu"gzrgtkogpvcn"5<
" " " "Gctn"kp"unqv"7"<
" " " " "2"d{vgu
" " " " "7"okpwwg"qhhgtgf"tcvg"2"dru
" " " " "ciitgicvg/hqtyctfgf"2"d{vgu

" " "encuu/ocr<"encuu/fghcwnv"*ocvej/cp{+
" " " "Ocvej<"cp{

" " "Encuu/ocr<"encuu/fghcwnv"*ocvej/cp{+
" " " "2"rcemgvu."2"d{vgu
" " " "7"okpwwg"qhhgtgf"tcvg"2"dru."ftqr"tcvg"2"dru
" " " "Ocvej<"cp{

```

This example shows how to verify the configuration:

```

Tqvwgt%"ujqy"rqnke{"ocr"kr4vci
" "Rqnke{"Ocr"kr4vci
" " "Encuu"krver
" " " "ugv"ornu"gzrgtkogpvcn"korqukvkqp"5

```

## EXP Value Imposition Guidelines and Restrictions

When setting the EXP value on all imposed labels, follow these guidelines and restrictions:

- Use the **set mpls experimental imposition** command during label imposition. This command sets the MPLS EXP field on all imposed label entries.
- The **set mpls experimental imposition** command is supported only on input interfaces (imposition).
- The **set mpls experimental imposition** command does not mark the EXP value directly; instead, it marks the internal DSCP that is mapped to EXP through the internal DSCP-to-EXP global map.
- It is important to note that classification (based on the original received IP header) and marking (done to the internal DSCP) do not distinguish between IP-to-IP traffic and IP-to-MPLS traffic. The commands that you use to mark IP ToS and mark EXP have the same result as when you mark the internal DSCP.

- To set the pushed label entry value to a value different from the default value during label imposition, use the **set mpls experimental imposition** command.
- You optionally can use the **set mpls experimental imposition** command with the IP precedence, DSCP field, or QoS IP ACL to set the value of the MPLS EXP field on all imposed label entries.
- When imposing labels onto the received IP traffic with the PFC, you can mark the EXP field using the **set mpls experimental imposition** command.

## Configuring a Policy Map Using the Police Command

Policing is a function in the PFC hardware that provides the ability to rate limit a particular traffic class to a specific rate. The PFC supports aggregate policing and microflow policing.

Aggregate policing meters all traffic that ingresses into a port, regardless of different source, destination, protocol, source port, or destination port. Microflow policing meters all traffic that ingresses into a port, on a per flow (per source, destination, protocol, source port, and destination port). For additional information on aggregate and microflow policing, see [Chapter 63, “Classification, Marking, and Policing.”](#)

|        | Command                                                                                                                                                               | Purpose                                                                    |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"rqnke{/ocr" rqnke{apcog"</b></code>                                                                                                          | Creates a policy map.                                                      |
| Step 2 | <code>Tqwvgt*eqphki/rocr+%<b>"encuu/ocr"pcog"]ocvej/cnn"~"</b><br/><b>ocvej/cp{_"</b></code>                                                                          | Accesses the QoS class map configuration mode to configure QoS class maps. |
| Step 3 | <code>Tqwvgt*eqphki/rocr/e+%<b>"rqnkeg"}ciitgicvg"pcog;"</b></code>                                                                                                   | Adds the class to a shared aggregate policer.                              |
| Step 4 | <code>Tqwvgt*eqphki/rocr/e+%<b>"rqnkeg"bps burst_normal</b><br/><b>dwtuvaocz"eqphqto/cevkqp"cevkqp"gzeggf/cevkqp"</b><br/><b>cevkqp"zkqncvg/cevkqp"cevkqp"</b></code> | Creates a per-class-per-interface policer.                                 |
| Step 5 | <code>Tqwvgt*eqphki/rocr/e+%<b>"rqnkeg"hnqy"}dru"</b><br/><b>]dwtuvapgtocn_"~"]eqphqto/cevkqp"cevkqp_"</b><br/><b>]gzeggf/cevkqp"cevkqp_"</b></code>                  | Creates an ingress flow policer. (Not supported in egress policy.)         |
| Step 6 | <code>Tqwvgt*eqphki/rocr/e+%<b>"gzkv"</b></code>                                                                                                                      | Exits class-map configuration mode.                                        |

This is an example of creating a policy map with a policer:

```
Tqwvgt*eqphki+%"rqnke{/ocr"kr4vci
Tqwvgt*eqphki/rocr+%"encuu"krver
Tqwvgt*eqphki/rocr/e+%"pg"ugv"ornu"gzr"vqroquv"5
Tqwvgt*eqphki/rocr/e+%"rqnkeg"3222222"3222222"e"ugv/ornu/gzrA
ugv/ornu/gzr/korqukvkqp/vtcpuokv

Tqwvgt*eqphki/rocr/e+%"rqnkeg"3222222"3222222"e"ugv/ornu/gzr/korqukv"5"g"f
Tqwvgt*eqphki/rocr/e+%"gzkv"
Tqwvgt*eqphki/rocr+%"gzkv"
Tqwvgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"5149
Tqwvgt*eqphki/kh+%"ugt"kp"kr4vci
Tqwvgt*eqphki/kh+%
```

This is an example of verifying the configuration:

```
Tqwvgt%"ujqy"rqn"kr4vci
""Rqnke{"Ocr"kr4vci
""Encuu"krver
""rqnkeg"ekt"3222222"de"3222222"dg"3222222"eqphqto/cevkqp"
ugv/ornu/gzr/korqukvkqp/vtcpuokv"5"gzeggf/cevkqp"ftqr
Tqwvgt%"ujqy"twppkpi/eqphki"kpvgtthceg"ikicdkvgvjgtpgv"5149
```



```

Dwknfkpi"eqphkiwtcvkqp000

Ewttgpn"eqphkiwtcvkqp"<"424"d{vgu
#
kpvgtthceg"IkicdkvGvjgtpgv5149
"nqiikpi"gxgpn"nkpm/uvvuwu
"ugttxkeg/rqnke{"kprwv"kr4vci
gpf

Tqvwgt%"ujqy"rqnke{"kpvgtthceg"ikicdkvgvjgtpgv"5149
"IkicdkvGvjgtpgv5149

"Ugttxkeg/rqnke{"kprwv<"kr4vci

""encuu/ocr<"krver"*ocvej/cnn+
""""Ocvej<"ceeguu/itqwr"323
""""rqnkeg"<
""""3222222"dru"3222222"nkokv"3222222"gzvgpfgf"nkokv
""""Gctn"kp"unqy"7"<
""""2"d{vgu
""""7"okpwvg"qhhgtgf"tcvg"2"dru
""""ciitgicvg/hqtyctfgf"2"d{vgu"cevkqp<"ugv/ornu/gzr/korqukvkqp/vtcpuokv
""""gzeggfgf"2"d{vgu"cevkqp<"ftqr
""""ciitgicvg/hqtyctf"2"dru"gzeggf"2"dru

""""encuu/ocr<"encuu/fghcwnv"*ocvej/cp{+
""""Ocvej<"cp{

""""Encuu/ocr<"encuu/fghcwnv"*ocvej/cp{+
""""2"rcemgvu."2"d{vgu
""""7"okpwvg"qhhgtgf"tcvg"2"dru."ftqr"tcvg"2"dru
""""Ocvej<"cp{

```

## Restrictions and Usage Guidelines

The following restrictions and guidelines apply when using the **police** command to configure a policy map:

- With MPLS, the **exceed-action** *action* command and the **violate-action** *action* command work similarly to IP usage. The packet may get dropped or the EXP value is marked down.
- With MPLS, the **set-dscp transmit** *action* command and the **set-prec-transmit** *action* command set the internal DSCP that is mapped into the CoS bits, which affects queueing, however, they do not change the EXP value, except for imposition.
- When swapping labels for received MPLS traffic with the PFC, you can mark down out-of-profile traffic using the **police** command **exceed-action policed-dscp-transmit** and **violate-action policed-dscp-transmit** keywords. The PFC does not mark in-profile traffic; when marking down out-of-profile traffic, the PFC marks the outgoing topmost label. The PFC does not propagate the marking down through the label stack.
- With MPLS, the flow key is based on the label and EXP value; there is no flowmask option. Otherwise, flow key operation is similar to IP-to-IP.
- You can use the **police** command to set the pushed label entry value to a value different from the default value during label imposition.
- When imposing labels onto the received IP traffic with the PFC, you can mark the EXP field using the **conform-action set-mpls-exp-imposition-transmit** keywords.
- During IP-to-MPLS imposition, IP ToS marking is not supported. If you configure a policy to mark IP ToS, the PFC marks the EXP value.

## Displaying a Policy Map

You can display a policy map with an interface summary for MPLS QoS classes or with the configuration of all classes configured for all service policies on the specified interface.

## Displaying the Configuration of All Classes

To display the configuration of all classes configured for all service policies on the specified interface, perform this task:

| Command                                                                                   | Purpose                                                                                              |
|-------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------|
| <code>Tqwgvt%<b>"ujqy"rqnke{"kpvgtthceg" interface_type</b><br/>kpvgtthcegapwodgt"</code> | Displays the configuration of all classes configured for all policy maps on the specified interface. |

This example shows the configurations for all classes on Gigabit Ethernet interface 3/27:

```
Tqwgvt%"ujqy"rqnke{"kpvgtthceg"ikicdkvgvjgtpgv"5149
IkicdkvGvjgtpgv5149

"Ugtxkeg/rqnke{"kprwv<"kr4vci

""encuu/ocr<"krver"*ocvej/cnn+
""""Ocvej<"ceegu/itqwr"323
""""rqnkeg"<
""""""322222"dru"322222"nkokv"322222"gzvgpfgf"nkokv
""""Gctn"kp"unqv"7"<
""""""2"d{vgu
""""""7"okpwwg"qhhgtgf"tcvg"2"dru
""""""ciitgicvg/hqtyctfgf"2"d{vgu"cevkqp<"ugv/ornu/gzr/korqukvkqp/vtcpuokv
""""""gzegggfgf"2"d{vgu"cevkqp<"ftqr
""""""ciitgicvg/hqtyctf"2"dru"gzegggf"2"dru

""encuu/ocr<"encuu/fghcwnv"*ocvej/cp{+
""""Ocvej<"cp{

""Encuu/ocr<"encuu/fghcwnv"*ocvej/cp{+
""""2"rcemgvu."2"d{vgu
""""7"okpwwg"qhhgtgf"tcvg"2"dru."ftqr"tcvg"2"dru
""""Ocvej<"cp{
```

## Configuring MPLS QoS Egress EXP Mutation

- [Configuring Named EXP Mutation Maps, page 67-25](#)
- [Attaching an Egress EXP Mutation Map to an Interface, page 67-25](#)

## Configuring Named EXP Mutation Maps

To configure a named EXP mutation map, perform this task:

|        | Command                                                                                                                                                                                                                          | Purpose                              |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%<b>"rncvhtqto"squ"ocr"gzr/owvcvkqp"</b></code><br><code>name mutated_exp1 mutated_exp2 mutated_exp3</code><br><code>mutated_exp4 mutated_exp5 mutated_exp6</code><br><code>mutated_exp7 mutated_exp8</code> | Configures a named EXP mutation map. |
| Step 2 | <code>Tqvwgt*eqphki+%<b>"gpf"</b></code>                                                                                                                                                                                         | Exits configuration mode.            |

When configuring a named EXP mutation map, note the following information:

- You can enter up to eight input EXP values that map to a mutated EXP value.
- You can enter multiple commands to map additional EXP values to a mutated EXP value.
- You can enter a separate command for each mutated EXP value.
- You can configure 15 ingress EXP mutation maps to mutate the internal EXP value before it is written as the ingress EXP value. You can attach ingress EXP mutation maps to any interface that PFC QoS supports.
- PFC QoS derives the egress EXP value from the internal DSCP value. If you configure ingress EXP mutation, PFC QoS does not derive the ingress EXP value from the mutated EXP value.

## Attaching an Egress EXP Mutation Map to an Interface

To attach an egress EXP mutation map to an interface, perform this task:

|        | Command                                                                                                                                                                              | Purpose                                               |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%<b>"kpvgtthceg"}}</b>xncp"vlan_IDi"~"</code><br><code>}type slot/port]0uwdkpvgtthceg_i"~"}<b>rgtv/ejcppgn"</b></code><br><code>pwodgt]0uwdkpvgtthceg_i i</code> | Selects the interface to configure.                   |
| Step 2 | <code>Tqvwgt*eqphki/kh+%<b>"rncvhtqto"squ"gzr/owvcvkqp"</b></code><br><code>exp-mutation-table-name</code>                                                                           | Attaches an egress EXP mutation map to the interface. |
| Step 3 | <code>Tqvwgt*eqphki/kh+%<b>"gpf"</b></code>                                                                                                                                          | Exits configuration mode.                             |

This example shows how to attach the egress EXP mutation map named mutemap2:

```
Tqvwgt*eqphki+%"kpvgtthceg"ikiCDkvvgvjgtpgv"5148"
Tqvwgt*eqphki/kh+%"rncvhtqto"squ"gzr/owvcvkqp"owvgocr4"
Tqvwgt*eqphki/kh+%"gpf"
```

## Configuring EXP Value Maps

- [Configuring an Ingress-EXP to Internal-DSCP Map, page 67-26](#)
- [Configuring a Named Egress-DSCP to Egress-EXP Map, page 67-26](#)

## Configuring an Ingress-EXP to Internal-DSCP Map

To configure an ingress-EXP to internal-DSCP map, perform this task:

|        | Command                                                              | Purpose                                                                                                                                                 |
|--------|----------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%<i>"rncvhto"squ"ocr"gzr/fuer"xcnwgu"</i></code> | Configures the ingress-EXP value to internal-DSCP map. You must enter eight DSCP values corresponding to the EXP values. Valid values are 0 through 63. |
| Step 2 | <code>Tqvwgt*eqphki+%<i>"gpf"</i></code>                             | Exits configuration mode.                                                                                                                               |

This example shows how to configure an ingress-EXP to internal-DSCP map:

```
Tqvwgt*eqphki+%"rncvhto"squ"ocr"gzr/fuer"65"65"65"65"65"65"65"65"
Tqvwgt*eqphki+%
```

This example shows how to verify the configuration:

```
Tqvwgt*eqphki+%"ujqy"rncvhto"squ"ocr"gzr/fuer
"Gzr/fuer"ocr<
"gzr<"2"3"4"5"6"7"8"9"
"//////////"
"fuer<"65"65"65"65"65"65"65"65"
```

## Configuring a Named Egress-DSCP to Egress-EXP Map

To configure a named egress-DSCP to egress-EXP map, perform this task:

|        | Command                                                                                                        | Purpose                                                                                                                                                  |
|--------|----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%<i>"rncvhto"squ"ocr"fuer/gzr"</i></code><br><code><i>fueraxcnwgu"vq"gzrxcnwgu"</i></code> | Configures a named egress-DSCP to egress-EXP map. You can enter up to eight DSCP values at one time to a single EXP value. Valid values are 0 through 7. |
| Step 2 | <code>Tqvwgt*eqphki+%<i>"gpf"</i></code>                                                                       | Exits configuration mode.                                                                                                                                |

This example shows how to configure a named egress-DSCP to egress-EXP map:

```
Tqvwgt*eqphki+%"rncvhto"squ"ocr"fuer/gzr"42"47"vq"5"
Tqvwgt*eqphki+%
```

## MPLS DiffServ Tunneling Modes

Tunneling provides QoS the ability to be transparent from one edge of a network to the other edge of the network. A tunnel starts where there is label imposition. A tunnel ends where there is label disposition; that is, where the label is removed from the stack, and the packet goes out as an MPLS packet with a different per-hop behavior (PHB) layer underneath or as an IP packet with the IP PHB layer.

For the PFC, there are two ways to forward packets through a network:

- Short Pipe mode—In Short Pipe mode, the egress PE router uses the original packet marking instead of the marking used by the intermediate provider (P) routers. EXP marking does not propagate to the packet ToS byte.

For a description of this mode, see the [“Short Pipe Mode” section on page 67-27](#).

For the configuration information, see the “How to Configure Short Pipe Mode” section on page 67-30.

- Uniform mode—In Uniform mode, the marking in the IP packet may be manipulated to reflect the service provider’s QoS marking in the core. This mode provides consistent QoS classification and marking throughout the network including CE and core routers. EXP marking is propagated to the underlying ToS byte.

For a description, see the “Uniform Mode” section on page 67-28.

For the configuration procedure, see the “How to Configure Uniform Mode” section on page 67-34.

Both tunneling modes affect the behavior of edge and penultimate label switching routers (LSRs) where labels are put onto packets and removed from packets. They do not affect label swapping at intermediate routers. A service provider can choose different types of tunneling modes for each customer.

For additional information, see “MPLS DiffServ Tunneling Modes” at this URL:

[http://www.cisco.com/en/US/docs/ios-xml/ios/mp\\_te\\_diffserv/configuration/15-mt/mp-diffserv-tun-mode.html](http://www.cisco.com/en/US/docs/ios-xml/ios/mp_te_diffserv/configuration/15-mt/mp-diffserv-tun-mode.html).

## Short Pipe Mode

Short pipe mode is used when the customer and service provider are in different DiffServ domains. It allows the service provider to enforce its own DiffServ policy while preserving customer DiffServ information, which provides a DiffServ transparency through the service provider network.


QoS policies implemented in the core do not propagate to the packet ToS byte. The classification based on MPLS EXP value ends at the customer-facing egress PE interface; classification at the customer-facing egress PE interface is based on the original IP packet header and not the MPLS header.



**Note**

The presence of an egress IP policy (based on the customer’s PHB marking and not on the provider’s PHB marking) automatically implies the Short Pipe mode.

**Figure 67-2 Short Pipe Mode Operation with VPNs**



Short Pipe mode functions as follows:

1. CE1 transmits an IP packet to PE1 with an IP DSCP value of 1.
2. PE1 sets the MPLS EXP field to 5 in the imposed label entries.
3. PE1 transmits the packet to P1.
4. P1 sets the MPLS EXP field value to 5 in the swapped label entry.
5. P1 transmits the packet to P2.
6. P2 pops the IGP label entry.
7. P2 transmits the packet to PE2.
8. PE2 pops the BGP label.
9. PE2 transmits the packet to CE2, but does QoS based on the IP DSCP value.

For additional information, see “MPLS DiffServ Tunneling Modes” at this URL:

[http://www.cisco.com/en/US/docs/ios-xml/ios/mp\\_te\\_diffserv/configuration/15-mt/mp-diffserv-tun-mode.html](http://www.cisco.com/en/US/docs/ios-xml/ios/mp_te_diffserv/configuration/15-mt/mp-diffserv-tun-mode.html)


## Short Pipe Mode Restrictions

Short Pipe mode is not supported if the MPLS-to-IP egress interface is EoMPLS (the adjacency has the end of marker (EOM) bit set).

## Uniform Mode

In Uniform mode, packets are treated uniformly in the IP and MPLS networks; that is, the IP precedence value and the MPLS EXP bits always correspond to the same PHB. Whenever a router changes or recolors the PHB of a packet, that change must be propagated to all encapsulation markings. The propagation is performed by a router only when a PHB is added or exposed due to label imposition or disposition on any router in the packet's path. The color must be reflected everywhere at all levels. For example, if a packet's QoS marking is changed in the MPLS network, the IP QoS marking reflects that change.

Figure 67-3 Uniform Mode Operation



\*In both the MPLS-to-MPLS and the MPLS-to-IP cases, the PHBs of the topmost popped label is copied into the new top label or the IP DSCP if no label remains

The procedure varies according to whether IP precedence bit markings or DSCP markings are present.

The following actions occur if there are IP precedence bit markings:

1. IP packets arrive in the MPLS network at PE1, the service provider edge router.
2. A label is copied onto the packet.
3. If the MPLS EXP field value is recolors (for example, if the packet becomes out-of-rate because too many packets are being transmitted), that value is copied to the IGP label. The value of the BGP label is not changed.
4. At the penultimate hop, the IGP label is removed. That value is copied into the next lower level label.
5. When all MPLS labels have been removed from the packet that is sent out as an IP packet, the IP precedence or DSCP value is set to the last changed EXP value in the core.

The following is an example when there are IP precedence bit markings:

1. At CE1 (customer equipment 1), the IP packet has an IP precedence value of 3.
2. When the packet arrives in the MPLS network at PE1 (the service provider edge router), the IP precedence value of 3 is copied to the imposed label entries of the packet.
3. The MPLS EXP field in the IGP label header might be changed within the MPLS core (for example, at P1) by a mark down.



#### Note

Because the IP precedence bits are 3, the BGP label and the IGP label also contain 3 because in Uniform mode, the labels always are identical. The packet is treated uniformly in the IP and MPLS networks.

## Uniform Mode Restrictions

If the egress IP ACLs or service policies are configured on the MPLS-to-IP exit point, the Uniform mode is always enforced because of recirculation.

## MPLS DiffServ Tunneling Restrictions and Usage Guidelines

The MPLS DiffServ tunneling restrictions and usage guidelines are as follows:

- One label-switched path (LSP) can support up to eight classes of traffic (that is, eight PHBs) because the MPLS EXP field is a 3-bit field.
- MPLS DiffServ tunneling modes support E-LSPs. An E-LSP is an LSP on which nodes determine the QoS treatment for MPLS packet exclusively from the EXP bits in the MPLS header.

The following features are supported with the MPLS differentiated service (DiffServ) tunneling modes:

- MPLS per-hop behavior (PHB) layer management. (Layer management is the ability to provide an additional layer of PHB marking to a packet.)
- Improved scalability of the MPLS layer management by control on managed customer edge (CE) routers.
- MPLS can tunnel a packet's QoS (that is, the QoS is transparent from edge to edge). With QoS transparency, the IP marking in the IP packet is preserved across the MPLS network.
- The MPLS EXP field can be marked differently and separately from the PHB marked in the IP precedence or DSCP field.

## How to Configure Short Pipe Mode

- [Ingress PE Router—Customer Facing Interface, page 67-30](#)
- [Configuring Ingress PE Router—P Facing Interface, page 67-32](#)
- [Configuring the P Router—Output Interface, page 67-33](#)
- [Configuring the Egress PE Router—Customer Facing Interface, page 67-34](#)



### Note

- The steps that follow show one way, but not the only way, to configure Short Pipe mode.
- The Short Pipe mode on the egress PE (or PHP) is automatically configured when you attach to the interface an egress service policy that includes an IP class.

## Ingress PE Router—Customer Facing Interface

This procedure configures a policy map to set the MPLS EXP field in the imposed label entries.

To set the EXP value, the ingress LAN port must be untrusted.

For MPLS and VPN, the ingress PE supports all ingress PFC IP policies.



To configure a policy map to set the MPLS EXP field in the imposed label entries, perform this task:

|        | Command                                                                                                                                                          | Purpose                                                                                                                                                                                                                                                                                                                                           |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "ceeguu/nkuv"3"rgtokv"cp{<br/>ipv4_acl_number_or_name</code>                                                                               | Creates an IPv4 access list.                                                                                                                                                                                                                                                                                                                      |
| Step 2 | <code>Tqvwgt*eqphki+% "encuu/ocr"encuuapcog"</code>                                                                                                              | Creates a class map.                                                                                                                                                                                                                                                                                                                              |
| Step 3 | <code>Tqvwgt*eqphki/eocr+% "ocvej"ceeguu/itqwr"3<br/>ipv4_acl_number_or_name</code>                                                                              | Configures the class map to filter with the ACL created in step 1.                                                                                                                                                                                                                                                                                |
| Step 4 | <code>Tqvwgt*eqphki+% "rqnke{/ocr"rqnke{aocrapcog"</code>                                                                                                        | Creates a named QoS policy.                                                                                                                                                                                                                                                                                                                       |
| Step 5 | <code>Tqvwgt*eqphki/rocr+% "encuu"encuuapcog"</code>                                                                                                             | Configures the policy to use the class map created in step 2.                                                                                                                                                                                                                                                                                     |
| Step 6 | <code>Tqvwgt*eqphki/rocr/e+% "rqnkeg"dkvuargtaugeqpf"<br/>]pqtocnadwtuvad{vgu_"eqphqto/cevkqp"<br/>ugv/ornu/gzr/vtcpuokv"gzrxcnwg"gzeggf/cevkqp"<br/>ftqr</code> | Configures policing, including the following: <ul style="list-style-type: none"> <li>Action to take on packets that conform to the rate limit specified in the service level agreement (SLA).</li> <li>Action to take on packets that exceed the rate limit specified in the SLA.</li> </ul> <p>The <i>exp_value</i> sets the MPLS EXP field.</p> |
| Step 7 | <code>Tqvwgt*eqphki+% "kpvgtthceg" type slot/port"</code>                                                                                                        | Selects an interface to configure.                                                                                                                                                                                                                                                                                                                |
| Step 8 | <code>Tqvwgt*eqphki/kh+% "pq"rncvhqto"squ"vtwuv"</code>                                                                                                          | Configures the interface as untrusted.                                                                                                                                                                                                                                                                                                            |
| Step 9 | <code>Tqvwgt*eqphki/kh+% "ugttxkeg/rqnke{ "kprwv"<br/>rqnke{aocrapcog"</code>                                                                                    | Attaches the policy map created in step 4 to the interface as an input service policy.                                                                                                                                                                                                                                                            |

### Configuration Example

This example shows how to configure a policy map to set the MPLS EXP field in the imposed label entries:

```
Tqvwgt*eqphki+% "ceeguu/nkuv"3"rgtokv"cp{
Tqvwgt*eqphki+% "encuu/ocr"EWUVQOGT/C
Tqvwgt*eqphki/eocr+% "ocvej"ceeguu/itqwr"3
Tqvwgt*eqphki+% "rqnke{/ocr"ugv/ORNU/RJD
Tqvwgt*eqphki/rocr+% "encuu"EWUVQOGT/C
Tqvwgt*eqphki/rocr/e+% "rqnkeg"72222222"eqphqto/cevkqp"ugv/ornu/gzr/vtcpuokv"6"
gzeggf/cevkqp"ftqr
Tqvwgt*eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv"513
Tqvwgt*eqphki/kh+% "pq"rncvhqto"squ"vtwuv
Tqvwgt*eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv"513053
Tqvwgt*eqphki/kh+% "ugttxkeg/rqnke{ "kprwv"ugv/ORNU/RJD
```

## Configuring Ingress PE Router—P Facing Interface

This procedure classifies packets based on their MPLS EXP field and provides appropriate discard and scheduling treatments.

To classify packets based on their MPLS EXP field and provide appropriate discard and scheduling treatments, perform this task:

|        | Command                                                                                             | Purpose                                                                                                                                                                      |
|--------|-----------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"encuu/ocr"</b> encuuapcog"</code>                                          | Specifies the class map to which packets will be mapped (matched). Creates a traffic class.                                                                                  |
| Step 2 | <code>Tqwvgt*eqphki/e/ocr+%<b>"ocvej"</b> ornu"gzrgtkogpvcn" gzrankuv"</code>                       | Specifies the MPLS EXP field values used as a match criteria against which packets are checked to determine if they belong to the class.                                     |
| Step 3 | <code>Tqwvgt*eqphki+%<b>"rqnke{ /ocr"</b> pcog"</code>                                              | Configures the QoS policy for packets that match the class or classes.                                                                                                       |
| Step 4 | <code>Tqwvgt*eqphki/r/ocr+%<b>"encuu"</b> encuuapcog"</code>                                        | Associates the traffic class with the service policy.                                                                                                                        |
| Step 5 | <code>Tqwvgt*eqphki/r/ocr/e+%<b>"dcpfykfvyj"</b> } dcpfykfvyamdru"~<b>"rgtegpv"</b> rgtegpv;</code> | Specifies the minimum bandwidth guarantee to a traffic class. You can specify the minimum bandwidth guarantee in kilobits per second or by percent of the overall bandwidth. |
| Step 6 | <code>Tqwvgt*eqphki/r/ocr+%<b>"encuu"</b> encuu/fghcwnv</code>                                      | Specifies the default class so that you can configure or modify its policy.                                                                                                  |
| Step 7 | <code>Tqwvgt*eqphki/r/ocr/e+%<b>"tcpfqo/fgvgev"</b></code>                                          | Enables a WRED drop policy for a traffic class that has a bandwidth guarantee.                                                                                               |
| Step 8 | <code>Tqwvgt*eqphki+%<b>"kpvgtthceg"</b> type slot/port"</code>                                     | Selects an interface to configure.                                                                                                                                           |
| Step 9 | <code>Tqwvgt*eqphki/kh+%<b>"ugtckeg/rqnke{ "qvwrvw"</b> pcog"</code>                                | Attaches a QoS policy to an interface and specifies that policies should be applied on packets leaving the interface.                                                        |



### Note

The **bandwidth** command and **random-detect** command are not supported on LAN ports.

## Configuration Example

This example shows how to classify packets based on their MPLS EXP field and provide appropriate discard and scheduling treatments:

```
Tqwvgt*eqphki+%"encuu/ocr" ORNU/GZR/6
Tqwvgt*eqphki/e/ocr+%"ocvej" ornu"gzrgtkogpvcn" 6
Tqwvgt*eqphki+%"rqnke{ /ocr" qvwrvw/squ
Tqwvgt*eqphki/r/ocr+%"encuu" ORNU/GZR/6
Tqwvgt*eqphki/r/ocr/e+%"dcpfykfvyj" rgtegpv" 62
Tqwvgt*eqphki/r/ocr+%"encuu" encuu/fghcwnv
Tqwvgt*eqphki/r/ocr/e+%"tcpfqo/fgvgev"
Tqwvgt*eqphki+%"kpvgtthceg" rqu" 613
Tqwvgt*eqphki/kh+%"ugtckeg/rqnke{ "qvwrvw" qvwrvw/squ
```

## Configuring the P Router—Output Interface

To classify packets based on their MPLS EXP field and provide appropriate discard and scheduling treatments, perform this task:

|        | Command                                                                                                    | Purpose                                                                                                                                                                      |
|--------|------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>encuu</b>/ocr"<i>encuuapcog</i>"</code>                                            | Specifies the class map to which packets will be mapped (matched). Creates a traffic class.                                                                                  |
| Step 2 | <code>Tqwvgt*eqphki/e/ocr+%<b>ocvej</b>"<i>ornu</i>"gzrgtkogpvcn"<i>gzrankuv</i>"</code>                   | Specifies the MPLS EXP field values used as a match criteria against which packets are checked to determine if they belong to the class.                                     |
| Step 3 | <code>Tqwvgt*eqphki+%<b>rqnke</b>{/ocr"<i>pcog</i>"</code>                                                 | Configures the QoS policy for packets that match the class or classes.                                                                                                       |
| Step 4 | <code>Tqwvgt*eqphki/r/ocr+%<b>encuu</b>"<i>encuuapcog</i>"</code>                                          | Associates the traffic class with the service policy.                                                                                                                        |
| Step 5 | <code>Tqwvgt*eqphki/r/ocr/e+%<b>dcpfykfvj</b>"<i>dcpfykfvjamdr</i>u"~"<b>rgtegpv</b>"<i>rgtegpv</i></code> | Specifies the minimum bandwidth guarantee to a traffic class. You can specify the minimum bandwidth guarantee in kilobits per second or by percent of the overall bandwidth. |
| Step 6 | <code>Tqwvgt*eqphki/r/ocr+%<b>encuu</b>"<i>encuu</i>/<b>fghcwnv</b>"</code>                                | Specifies the default class so that you can configure or modify its policy.                                                                                                  |
| Step 7 | <code>Tqwvgt*eqphki/r/ocr/e+%<b>tcpfqo</b>/<b>fgvgev</b>"</code>                                           | Applies WRED to the policy based on the IP precedence or the MPLS EXP field value.                                                                                           |
| Step 8 | <code>Tqwvgt*eqphki+%<b>kpvgt</b>hceg"<i>type slot/port</i>"</code>                                        | Selects an interface to configure.                                                                                                                                           |
| Step 9 | <code>Tqwvgt*eqphki/kh+%<b>ugt</b>xkeg/<b>rqnke</b>{ "<i>qwvrwv</i>"<i>pcog</i>"</code>                    | Attaches a QoS policy to an interface and specifies that policies should be applied on packets leaving the interface.                                                        |



### Note

The **bandwidth** command and **random-detect** command are not supported on LAN ports.

## Configuration Example

This example shows how to classify packets based on their MPLS EXP field and provide appropriate discard and scheduling treatments:

```
Tqwvgt*eqphki+%encuu/ocr"ORNU/GZR/6"
Tqwvgt*eqphki/e/ocr+%ocvej"ornu"gzrgtkogpvcn"6
Tqwvgt*eqphki+%rqnke{/ocr"qwvrwv/squ
Tqwvgt*eqphki/r/ocr+%encuu"ORNU/GZR/6
Tqwvgt*eqphki/r/ocr/e+%dcpfykfvj"rgtegpv"62
Tqwvgt*eqphki/r/ocr+%encuu"encuu/fghcwnv
Tqwvgt*eqphki/r/ocr/e+%tcpfqo/fgvgev
Tqwvgt*eqphki+%kpvgthceg"rqu"413
Tqwvgt*eqphki/kh+%ugtxkeg/rqnke{ "qwvrwv"qwvrwv/squ
```

## Configuring the Egress PE Router—Customer Facing Interface

To classify a packet based on its IP DSCP value and provide appropriate discard and scheduling treatments, perform this task:

|        | Command                                                                                                | Purpose                                                                                                                                                                      |
|--------|--------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"encuu/ocr"</b>encuuapcog"</code>                                              | Specifies the class map to which packets will be mapped (matched). Creates a traffic class.                                                                                  |
| Step 2 | <code>Tqwvgt*eqphki/e/ocr+%<b>"ocvej"</b>kr<b>"fuer"</b>fueraxcnwgu"</code>                            | Uses the DSCP values as the match criteria.                                                                                                                                  |
| Step 3 | <code>Tqwvgt*eqphki+%<b>"rqnke{"</b>/ocr<b>"pcog"</b></code>                                           | Configures the QoS policy for packets that match the class or classes.                                                                                                       |
| Step 4 | <code>Tqwvgt*eqphki/r/ocr+%<b>"encuu"</b>encuuapcog"</code>                                            | Associates the traffic class with the service policy.                                                                                                                        |
| Step 5 | <code>Tqwvgt*eqphki/r/ocr/e+%<b>"dcpfykfvej"</b><br/>}dcpfykfvejamdru"~<b>"rgtegpv"</b>rgtegpv;</code> | Specifies the minimum bandwidth guarantee to a traffic class. You can specify the minimum bandwidth guarantee in kilobits per second or by percent of the overall bandwidth. |
| Step 6 | <code>Tqwvgt*eqphki/r/ocr+%<b>"encuu"</b>encuu/fghcwnv</code>                                          | Specifies the default class so that you can configure or modify its policy.                                                                                                  |
| Step 7 | <code>Tqwvgt*eqphki/r/ocr/e+%<b>"tcpfqo/fgvgev"</b><br/><b>fuer/dcugf"</b></code>                      | Enables a WRED drop policy for a traffic class that has a bandwidth guarantee.                                                                                               |
| Step 8 | <code>Tqwvgt*eqphki+%<b>"kpvgtthceg"</b>type slot/port"</code>                                         | Selects an interface to configure.                                                                                                                                           |
| Step 9 | <code>Tqwvgt*eqphki/kh+%<b>"ugtckeg/rqnke{"</b>"qvwrvv"<b>"pcog"</b></code>                            | Attaches a QoS policy to an interface and specifies that policies should be applied on packets leaving the interface.                                                        |

### Configuration Example

This example shows how to classify a packet based on its IP DSCP value and provide appropriate discard and scheduling treatments:

```
Tqwvgt*eqphki+%"encuu/ocr"KR/RTGE/6
Tqwvgt*eqphki/e/ocr+%"ocvej"kr"rtgefegpeg"6
Tqwvgt*eqphki+%"rqnke{"/ocr"qvwrvv/squ
Tqwvgt*eqphki/r/ocr+%"encuu"KR/RTGE/6
Tqwvgt*eqphki/r/ocr/e+%"dcpfykfvej"rgtegpv"62
Tqwvgt*eqphki/r/ocr+%"encuu"encuu/fghcwnv
Tqwvgt*eqphki/r/ocr/e+%"tcpfqo/fgvgev"
Tqwvgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"514054
Tqwvgt*eqphki/kh+%"ugtckeg/rqnke{""qvwrvv""qvwrvv/squ
```

## How to Configure Uniform Mode

- [Configuring the Ingress PE Router—Customer Facing Interface, page 67-35](#)
- [Configuring the Ingress PE Router—P Facing Interface, page 67-36](#)
- [Configuring the Egress PE Router—Customer Facing Interface, page 67-37](#)



#### Note

The steps that follow show one way, but not the only way, to configure the Uniform mode.

## Configuring the Ingress PE Router—Customer Facing Interface

For Uniform mode, setting the trust state to IP precedence or IP DSCP allows the PFC to copy the IP PHB into the MPLS PHB.



**Note**

This description applies to PFC QoS for LAN ports.

To configure a policy map to set the MPLS EXP field in imposed label entries, perform this task:

|        | Command                                                                                                                               | Purpose                                                                                                                                                                                                                                                            |
|--------|---------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "ceeguu/nkuv"3"rgtokv"cp{<br/>ipv4_acl_number_or_name</code>                                                    | Creates an IPv4 access list.                                                                                                                                                                                                                                       |
| Step 2 | <code>Tqwvgt*eqphki+% "encuu/ocr" encuuapcog"</code>                                                                                  | Creates a class map.                                                                                                                                                                                                                                               |
| Step 3 | <code>Tqwvgt*eqphki/eocr+% "ocvej"ceeguu/itqwr"<br/>ipv4_acl_number_or_name</code>                                                    | Configures the class map to filter with the ACL created in Step 1.                                                                                                                                                                                                 |
| Step 4 | <code>Tqwvgt*eqphki+% "rqnke{/ocr"rqnke{aocrapcog"</code>                                                                             | Creates a named QoS policy.                                                                                                                                                                                                                                        |
| Step 5 | <code>Tqwvgt*eqphki/rocr+% "encuu" encuuapcog"</code>                                                                                 | Configures the policy to use the class map created in step 2.                                                                                                                                                                                                      |
| Step 6 | <code>Tqwvgt*eqphki/rocr/e+% "rqnkeg"dkvuargtaugeqpf"<br/>]pgtocnadwtuvad{vgu_"eqphqto/cevkqp"vtcpuokv"<br/>gzeggf/cevkqp"ftqr</code> | Configures policing, including the following: <ul style="list-style-type: none"> <li>Action to take on packets that conform to the rate limit specified in the SLA.</li> <li>Action to take on packets that exceed the rate limit specified in the SLA.</li> </ul> |
| Step 7 | <code>Tqwvgt*eqphki+% "kpvgtthceg" type slot/port"</code>                                                                             | Selects an interface to configure.                                                                                                                                                                                                                                 |
| Step 8 | <code>Tqwvgt*eqphki/kh+% "rncvhqto"squ"vtwuv"fuer"</code>                                                                             | Configures received DSCP as the basis of the internal DSCP for all the port's ingress traffic.                                                                                                                                                                     |
| Step 9 | <code>Tqwvgt*eqphki/kh+% "ugtxkeg/rqnke{ "kprwv"<br/>rqnke{aocrapcog"</code>                                                          | Attaches the policy map created in step 4 to the interface as an input service policy.                                                                                                                                                                             |

### Configuration Example

This example shows how to configure a policy map to set the MPLS EXP field in imposed label entries:

```
Tqwvgt*eqphki+% "ceeguu/nkuv"3"rgtokv"cp{
Tqwvgt*eqphki+% "encuu/ocr"EWUVQOGT/C
Tqwvgt*eqphki/eocr+% "ocvej"ceeguu/itqwr"3
Tqwvgt*eqphki+% "rqnke{/ocr"UNC/C
Tqwvgt*eqphki/rocr+% "encuu"EWUVQOGT/C
Tqwvgt*eqphki/rocr/e+% "rqnkeg"72222222"eqphqto/cevkqp"vtcpuokv"gzeggf/cevkqp"ftqr
Tqwvgt*eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv"513
Tqwvgt*eqphki/kh+% "rncvhqto"squ"vtwuv"fuer
Tqwvgt*eqphki/kh+% "kpvgtthceg"ikicdkvgvjgtpgv"513053
Tqwvgt*eqphki/kh+% "ugtxkeg/rqnke{ "kprwv"UNC/C
```

## Configuring the Ingress PE Router—P Facing Interface

To classify packets based on their MPLS EXP field and provide appropriate discard and scheduling treatments, perform this task:

|        | Command                                                                                                    | Purpose                                                                                                                                                                      |
|--------|------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"encuu/ocr"</b> encuuapcog</code>                                                  | Specifies the class map to which packets will be mapped (matched). Creates a traffic class.                                                                                  |
| Step 2 | <code>Tqwvgt*eqphki/e/ocr+%<b>"ocvej"</b> ornu"gzrgtkogpvcn"<br/>gzrankuv</code>                           | Specifies the MPLS EXP field values used as a match criteria against which packets are checked to determine if they belong to the class.                                     |
| Step 3 | <code>Tqwvgt*eqphki+%<b>"rqnke{ /ocr"</b> pcog</code>                                                      | Configures the QoS policy for packets that match the class or classes.                                                                                                       |
| Step 4 | <code>Tqwvgt*eqphki/r/ocr+%<b>"encuu"</b> encuuapcog</code>                                                | Associates the traffic class with the service policy.                                                                                                                        |
| Step 5 | <code>Tqwvgt*eqphki/r/ocr/e+%<b>"dcpfykfjv"</b> "<br/>} dcpfykfjvjamdru" ~"<b>rgtegpv"</b> rgtegpv;</code> | Specifies the minimum bandwidth guarantee to a traffic class. You can specify the minimum bandwidth guarantee in kilobits per second or by percent of the overall bandwidth. |
| Step 6 | <code>Tqwvgt*eqphki/r/ocr+%<b>"encuu"</b> encuu/fghcwnv</code>                                             | Specifies the default class so that you can configure or modify its policy.                                                                                                  |
| Step 7 | <code>Tqwvgt*eqphki/r/ocr/e+%<b>"tcpfqo/fgvgev"</b></code>                                                 | Enables a WRED drop policy for a traffic class that has a bandwidth guarantee.                                                                                               |
| Step 8 | <code>Tqwvgt*eqphki+%<b>"kpvgtthceg"</b> type slot/port</code>                                             | Selects an interface to configure.                                                                                                                                           |
| Step 9 | <code>Tqwvgt*eqphki/kh+%<b>"ugtckeg/rqnke{ "</b> qvrvw" pcog</code>                                        | Attaches a QoS policy to an interface and specifies that policies should be applied on packets leaving the interface.                                                        |



### Note

The **bandwidth** command and **random-detect** command are not supported on LAN ports.

### Configuration Example

This example shows how to classify packets based on their MPLS EXP field and provide appropriate discard and scheduling treatments:

```
Tqwvgt*eqphki+%"encuu/ocr" ORNU/GZR/5
Tqwvgt*eqphki/e/ocr+%"ocvej" ornu"gzrgtkogpvcn" 5
Tqwvgt*eqphki+%"rqnke{ /ocr" qvrvw/squ
Tqwvgt*eqphki/r/ocr+%"encuu" ORNU/GZR/5
Tqwvgt*eqphki/r/ocr/e+%"dcpfykfjv" "rgtegpv" 62
Tqwvgt*eqphki/r/ocr+%"encuu" encuu/fghcwnv
Tqwvgt*eqphki/r/ocr/e+%"tcpfqo/fgvgev"
Tqwvgt*eqphki+%"kpvgtthceg" rqu" 613
Tqwvgt*eqphki/kh+%"ugtckeg/rqnke{ " qvrvw" qvrvw/squ
```

## Configuring the Egress PE Router—Customer Facing Interface

To configure the egress PE router at the customer-facing interface, perform this task:

|         | Command                                                                                             | Purpose                                                                                                                                                                      |
|---------|-----------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1  | <code>Tqwvgt*eqphki+%<b>encuu/ocr</b>"encuuapcog"</code>                                            | Specifies the class map to which packets will be mapped (matched). Creates a traffic class.                                                                                  |
| Step 2  | <code>Tqwvgt*eqphki/e/ocr+%<b>ocvej</b>"kr"rtgegfgpeg"<br/><i>precedence-value</i></code>           | Identifies IP precedence values as match criteria.                                                                                                                           |
| Step 3  | <code>Tqwvgt*eqphki+%<b>rqnke</b>{/ocr"pcog"</code>                                                 | Configures the QoS policy for packets that match the class or classes.                                                                                                       |
| Step 4  | <code>Tqwvgt*eqphki/r/ocr+%<b>encuu</b>"encuuapcog"</code>                                          | Associates the traffic class with the service policy.                                                                                                                        |
| Step 5  | <code>Tqwvgt*eqphki/r/ocr/e+%<b>dcpfykfvj</b>"<br/>}dcpfykfvjamdru"~"<b>rgtegpv</b>"rgtegpv;</code> | Specifies the minimum bandwidth guarantee to a traffic class. You can specify the minimum bandwidth guarantee in kilobits per second or by percent of the overall bandwidth. |
| Step 6  | <code>Tqwvgt*eqphki/r/ocr+%<b>encuu</b>"encuu/fghcwnv"</code>                                       | Specifies the default class so that you can configure or modify its policy.                                                                                                  |
| Step 7  | <code>Tqwvgt*eqphki/r/ocr/e+%<b>tcpfqo</b>/fgvgev</code>                                            | Applies WRED to the policy based on the IP precedence or the MPLS EXP field value.                                                                                           |
| Step 8  | <code>Tqwvgt*eqphki+%<b>kpvgthceg</b>"v{rg"unqvlrgtv"</code>                                        | Selects an interface to configure.                                                                                                                                           |
| Step 9  | <code>Tqwvgt*eqphki/kh+%<b>ornu</b>"rtqrcicvg/equ"</code>                                           | Enables propagation of EXP value into the underlying IP DSCP at the MPLS domain exit LER egress port.                                                                        |
| Step 10 | <code>Tqwvgt*eqphki/kh+%<b>ugtckeg</b>/rqnke{ "<b>qwvrwv</b>"pcog"</code>                           | Attaches a QoS policy to an interface and specifies that policies should be applied on packets coming into the interface.                                                    |



Note

The **bandwidth** command and **random-detect** command are not supported on LAN ports.

### Configuration Example

This example shows how to configure the egress PE router at the customer-facing interface:

```
Tqwvgt*eqphki+%encuu/ocr"KR/RTGE/6
Tqwvgt*eqphki/e/ocr+%ocvej"kr"rtgegfgpeg"6
Tqwvgt*eqphki+%rqnke{/ocr"qwvrwv/squ
Tqwvgt*eqphki/r/ocr+%encuu"KR/RTGE/6
Tqwvgt*eqphki/r/ocr/e+%dcpfykfvj"rgtegpv"62
Tqwvgt*eqphki/r/ocr+%encuu"encuu/fghcwnv
Tqwvgt*eqphki/r/ocr/e+%tcpfqo/fgvgev
Tqwvgt*eqphki+%kpvgthceg"ikicdkvgvjgtpgv"514054
Tqwvgt*eqphki/kh+%ornu"rtqrcicvg/equ
Tqwvgt*eqphki/kh+%ugtckeg/rqnke{ "qwvrwv"qwvrwv/squ
```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





# PFC QoS Statistics Data Export

- [Prerequisites for PFC QoS Statistics Data Export, page 68-1](#)
- [Restrictions for PFC QoS Statistics Data Export, page 68-1](#)
- [Information About PFC QoS Statistics Data Export, page 68-2](#)
- [Default Settings for PFC QoS Statistics Data Export, page 68-2](#)
- [How to Configure PFC QoS Statistics Data Export, page 68-2](#)



## Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for PFC QoS Statistics Data Export

None.

## Restrictions for PFC QoS Statistics Data Export

None.

## Information About PFC QoS Statistics Data Export

The PFC QoS statistics data export feature generates per-LAN-port and per-aggregate policer utilization information and forwards this information in UDP packets to traffic monitoring, planning, or accounting applications. You can enable PFC QoS statistics data export on a per-LAN-port or on a per-aggregate policer basis. The statistics data generated per port consists of counts of the input and output packets and bytes. The aggregate policer statistics consist of counts of allowed packets and counts of packets exceeding the policed rate.

The PFC QoS statistics data collection occurs periodically at a fixed interval, but you can configure the interval at which the data is exported. PFC QoS statistics collection is enabled by default, and the data export feature is disabled by default for all ports and all configured aggregate policers.



### Note

The PFC QoS statistics data export feature is completely separate from NetFlow Data Export and does not interact with it.

## Default Settings for PFC QoS Statistics Data Export

| Feature                                         | Default Value        |
|-------------------------------------------------|----------------------|
| Global PFC QoS data export                      | Disabled             |
| Per port PFC QoS data export                    | Disabled             |
| Per named aggregate policer PFC QoS data export | Disabled             |
| Per class map policer PFC QoS data export       | Disabled             |
| PFC QoS data export time interval               | 300 seconds          |
| Export destination                              | Not configured       |
| PFC QoS data export field delimiter             | Pipe character (   ) |

## How to Configure PFC QoS Statistics Data Export

- [Enabling PFC QoS Statistics Data Export Globally, page 68-3](#)
- [Enabling PFC QoS Statistics Data Export for a Port, page 68-3](#)
- [Enabling PFC QoS Statistics Data Export for a Named Aggregate Policar, page 68-4](#)
- [Enabling PFC QoS Statistics Data Export for a Class Map, page 68-5](#)
- [Setting the PFC QoS Statistics Data Export Time Interval, page 68-6](#)
- [Configuring PFC QoS Statistics Data Export Destination Host and UDP Port, page 68-7](#)
- [Setting the PFC QoS Statistics Data Export Field Delimiter, page 68-8](#)

## Enabling PFC QoS Statistics Data Export Globally

To enable PFC QoS statistics data export globally, perform this task:

|        | Command                                                             | Purpose                                          |
|--------|---------------------------------------------------------------------|--------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+%<b>"rncvhqto"</b>squ"uvcvkuvkeu/gzrqtv"</code> | Enables PFC QoS statistics data export globally. |
| Step 2 | <code>Tqwwgt*eqphki+%<b>"gpf"</b></code>                            | Exits configuration mode.                        |

This example shows how to enable PFC QoS statistics data export globally and verify the configuration:

```
Tqwwgt%"eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+%"rncvhqto"squ"uvcvkuvkeu/gzrqtv"
Tqwwgt*eqphki+%"gpf"
' "Yctpkpi<"Gzrqtv"fguvkpcvkqp"pqv"ugv0
' "Wug") rncvhqto"squ"uvcvkuvkeu/gzrqtv"fguvkpcvkqp) "eqoocpf"vq"eqphkiwtg"vjg"gzrqtv"
fguvkpcvkqp
Tqwwgt%"ujqy""rncvhqto"squ"uvcvkuvkeu/gzrqtv""kphq"
SqU"Uvcvkuvkeu"Fcvc"Gzrqtv"Uvcvwu"cpf"Eqphkiwtcvkqp"kphqto cvkqp
////////////////////////////////////
Gzrqtv"Uvcvwu"<"gpcdnf
Gzrqtv"Kpvgtxcn"<"522"ugeqpfu
Gzrqtv"Fgnkokvgt"<"~
Gzrqtv"Fguvkpcvkqp"<"Pqv"eqphkiwtgf
Tqwwgt%
```



### Note

You must enable PFC QoS statistics data export globally for other PFC QoS statistics data export configuration to take effect.

## Enabling PFC QoS Statistics Data Export for a Port

To enable PFC QoS statistics data export for a port, perform this task:

|        | Command                                                                | Purpose                                              |
|--------|------------------------------------------------------------------------|------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+%<b>"kpvgtthceg"</b>type slot/port</code>          | Selects the interface to configure.                  |
| Step 2 | <code>Tqwwgt*eqphki/kh+%<b>"rncvhqto"</b>squ"uvcvkuvkeu/gzrqtv"</code> | Enables PFC QoS statistics data export for the port. |
| Step 3 | <code>Tqwwgt*eqphki+%<b>"gpf"</b></code>                               | Exits configuration mode.                            |

This example shows how to enable PFC QoS statistics data export on GigabitEthernet port 5/24 and verify the configuration:

```
Tqwwgt%"eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"7146"
Tqwwgt*eqphki/kh+%"rncvhqto"squ"uvcvkuvkeu/gzrqtv"
Tqwwgt*eqphki/kh+%"gpf"
Tqwwgt%"ujqy""rncvhqto"squ"uvcvkuvkeu/gzrqtv""kphq"
SqU"Uvcvkuvkeu"Fcvc"Gzrqtv"Uvcvwu"cpf"Eqphkiwtcvkqp"kphqto cvkqp
////////////////////////////////////
Gzrqtv"Uvcvwu"<"gpcdnf
Gzrqtv"Kpvgtxcn"<"522"ugeqpfu
Gzrqtv"Fgnkokvgt"<"~
Gzrqtv"Fguvkpcvkqp"<"Pqv"eqphkiwtgf

SqU"Uvcvkuvkeu"Fcvc"Gzrqtv"ku"gpcdnf"qp"hnngykpi"rqtvu<
```

```

////////////////////////////////////
IkicdkvGvjgtpgv7146
Tqwvgt%

```

When enabled on a port, PFC QoS statistics data export contains the following fields, separated by the delimiter character:

- Export type (“1” for a port)
- Slot/port
- Number of ingress packets
- Number of ingress bytes
- Number of egress packets
- Number of egress bytes
- Time stamp

## Enabling PFC QoS Statistics Data Export for a Named Aggregate Policer

To enable PFC QoS statistics data export for a named aggregate policer, perform this task:

|        | Command                                                                                               | Purpose                                                               |
|--------|-------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "rncvhto"squ"uvcvkuvkeu/gzrqtv"ciitgicvg/rqnkegt"ciitgicvgarqnkegtapcog"</code> | Enables PFC QoS statistics data export for a named aggregate policer. |
| Step 2 | <code>Tqwvgt*eqphki+% "gpf"</code>                                                                    | Exits configuration mode.                                             |

This example shows how to enable PFC QoS statistics data export for an aggregate policer named `aggr1M` and verify the configuration:

```

Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+% "rncvhto"squ"uvcvkuvkeu/gzrqtv"ciitgicvg/rqnkegt"ciit30"
Tqwvgt*eqphki+% "gpf"
Tqwvgt%"ujqy"rncvhto"squ"uvcvkuvkeu/gzrqtv"kphq"
SqU"Uvcvkuvkeu"Fcvc"Gzrqtv"Uvcvwu"cpf"Eqphkiwtcvkqp"kphqto cvkqp
////////////////////////////////////
Gzrqtv"Uvcvwu"<"gpcdnfg
Gzrqtv"Kpvgtxcn"<"522"ugeqpfu
Gzrqtv"Fgnkokvgt"<"~
Gzrqtv"Fguvkpcvkqp"<"Pqv"eqphkiwtgf

SqU"Uvcvkuvkeu"Fcvc"Gzrqtv"ku"gpcdnfg"qp"hqnnqykpi"rqtvu<
////////////////////////////////////
IkicdkvGvjgtpgv7146

SqU"Uvcvkuvkeu"Fcvc"gzrqtv"ku"gpcdnfg"qp"hqnnqykpi"ujctgf"ciitgicvg"rqnkegtu<
////////////////////////////////////
ciit30
Tqwvgt%

```

When enabled for a named aggregate policer, PFC QoS statistics data export contains the following fields, separated by the delimiter character:

- Export type (“3” for an aggregate policer)
- Aggregate policer name
- Direction (“in”)

- PFC or DFC slot number
- Number of in-profile bytes
- Number of bytes that exceed the CIR
- Number of bytes that exceed the PIR
- Time stamp

## Enabling PFC QoS Statistics Data Export for a Class Map

To enable PFC QoS statistics data export for a class map, perform this task:

|        | Command                                                                                  | Purpose                                                 |
|--------|------------------------------------------------------------------------------------------|---------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "rncvhtqto"squ"uvcvkuvkeu/gzrqtv" encuu/ocr" encuuocrapcog"</code> | Enables PFC QoS statistics data export for a class map. |
| Step 2 | <code>Tqvwgt*eqphki+% "gpf"</code>                                                       | Exits configuration mode.                               |

This example shows how to enable PFC QoS statistics data export for a class map named class3 and verify the configuration:

```
Tqvwgt% "eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+% "rncvhtqto"squ"uvcvkuvkeu/gzrqtv" encuu/ocr" encuu5 "
Tqvwgt*eqphki+% "gpf"
Tqvwgt% "ujgy"rncvhtqto"squ"uvcvkuvkeu/gzrqtv" kphq"
SqU"Uvcvkuvkeu"Fcvc"Gzrqtv"Uvcvwu"cpf"Eqphkiwtcvkqp" kphqto cvkqp
////////////////////////////////////
Gzrqtv"Uvcvwu"<"gpcdnfg
Gzrqtv"Kpvgtxcn"<"522"ugeqpfu
Gzrqtv"Fgnkokvg"t"<"~
Gzrqtv"Fguvkpcvkqp"<"Pqv"eqphkiwtg"

SqU"Uvcvkuvkeu"Fcvc"Gzrqtv"ku"gpcdnfg"qp"hgnnqykpi"rqtvu<
////////////////////////////////////
IkiCDkvGvjgtpgv7146

SqU"Uvcvkuvkeu"Fcvc"gzrqtv"ku"gpcdnfg"qp"hgnnqykpi"ujctgf"ciitgievg"rqnkegtu<
////////////////////////////////////
ciit30

SqU"Uvcvkuvkeu"Fcvc"Gzrqtv"ku"gpcdnfg"qp"hgnnqykpi" encuu/ocr" encuu5
////////////////////////////////////
encuu5
Tqvwgt%
```

When enabled for a class map, PFC QoS statistics data export contains the following fields, separated by the delimiter character:

- For data from a physical port:
  - Export type (“4” for a classmap and port)
  - Class map name
  - Direction (“in”)
  - Slot/port
  - Number of in-profile bytes
  - Number of bytes that exceed the CIR

- Number of bytes that exceed the PIR
- Time stamp
- For data from a VLAN interface:
  - Export type (“5” for a class map and VLAN)
  - Classmap name
  - Direction (“in”)
  - PFC or DFC slot number
  - VLAN ID
  - Number of in-profile bytes
  - Number of bytes that exceed the CIR
  - Number of bytes that exceed the PIR
  - Time stamp
- For data from a port channel interface:
  - Export type (“6” for a class map and port channel)
  - Class map name
  - Direction (“in”)
  - PFC or DFC slot number
  - Port channel ID
  - Number of in-profile bytes
  - Number of bytes that exceed the CIR
  - Number of bytes that exceed the PIR
  - Time stamp

## Setting the PFC QoS Statistics Data Export Time Interval

To set the time interval for the PFC QoS statistics data export, perform this task:

|        | Command                                                                                      | Purpose                                                                                                                                                                                                                                                                                                                 |
|--------|----------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "rncvhtqto"squ"uvcvkuvkeu/gzrqtv" kpvgtxcn" kpvgtxcnkpaugeqpfu"</code> | Sets the time interval for the PFC QoS statistics data export.<br><br><b>Note</b> The interval needs to be short enough to avoid counter wraparound with the activity in your configuration, but because exporting PFC QoS statistic creates a significant load on the switch, be careful when decreasing the interval. |
| Step 2 | <code>Tqwvgt*eqphki+% "gpf"</code>                                                           | Exits configuration mode.                                                                                                                                                                                                                                                                                               |

This example shows how to set the PFC QoS statistics data export interval and verify the configuration:

```
Tqwvgt*"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+% "rncvhtqto"squ"uvcvkuvkeu/gzrqtv" kpvgtxcn"472"
Tqwvgt*eqphki+% "gpf"
Tqwvgt*"ujqy"rncvhtqto"squ"uvcvkuvkeu/gzrqtv" kphq"
```

```

SqU"Uvcvkuvkeu"Fcv"Gzrqtv"Uvcvwu"cpf"Eqphkiwtcvkqp"kphqtocvkqp
////////////////////////////////////
Gzrqtv"Uvcvwu"<"gpcdnf
Gzrqtv"Kpvgtxcn"<"472"ugeqpfu
Gzrqtv"Fgnkokvgt"<"~
Gzrqtv"Fgukpvcvkqp"<"Pqv"eqphkiwtgf

SqU"Uvcvkuvkeu"Fcv"Gzrqtv"ku"gpcdnf"qp"hqnnqykpi"rqtvu<
////////////////////////////////////
IkiCDkvGvjgtpgv7146

SqU"Uvcvkuvkeu"Fcv"Gzrqtv"ku"gpcdnf"qp"hqnnqykpi"ujctgf"ciitgicvg"rqnkegtu<
////////////////////////////////////
ciit30

SqU"Uvcvkuvkeu"Fcv"Gzrqtv"ku"gpcdnf"qp"hqnnqykpi"encuu/ocru<
////////////////////////////////////
encuu5
Tqvwgt%

```

## Configuring PFC QoS Statistics Data Export Destination Host and UDP Port

To configure the PFC QoS statistics data export destination host and UDP port number, perform this task:

|        | Command                                                                                                                                                                               | Purpose                                                                             |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| Step 1 | <pre>Tqvwgt*eqphki+% "rncvqhgt"sqU"uvcvkuvkeu/gzrqtv" fguvkpcvkqp"}jquvapcog"~"jquvakracfftguu;" }rqtvrqtvapwodgt"~"u{unqi" ]hceknkv{ hceknkv{apcog_ ]ugxgtkv{ ugxgtkv{axcnwg_;</pre> | Configures the PFC QoS statistics data export destination host and UDP port number. |
| Step 2 | <pre>Tqvwgt*eqphki+% "gpf"</pre>                                                                                                                                                      | Exits configuration mode.                                                           |



### Note

When the PFC QoS data export destination is a syslog server, the exported data is prefaced with a syslog header.

**Table 68-1 Supported PFC QoS Data Export Facility Parameter Values**

| Name   | Definition                       | Name   | Definition             |
|--------|----------------------------------|--------|------------------------|
| kern   | kernel messages                  | cron   | cron/at subsystem      |
| user   | random user-level messages       | local0 | reserved for local use |
| mail   | mail system                      | local1 | reserved for local use |
| daemon | system daemons                   | local2 | reserved for local use |
| auth   | security/authentication messages | local3 | reserved for local use |
| syslog | internal syslogd messages        | local4 | reserved for local use |
| lpr    | line printer subsystem           | local5 | reserved for local use |
| news   | netnews subsystem                | local6 | reserved for local use |
| uucp   | uucp subsystem                   | local7 | reserved for local use |

Table 68-2 Supported PFC QoS Data Export Severity Parameter Values

| Severity Parameter |        |                                  |
|--------------------|--------|----------------------------------|
| Name               | Number | Definition                       |
| emerg              | 0      | system is unusable               |
| alert              | 1      | action must be taken immediately |
| crit               | 2      | critical conditions              |
| err                | 3      | error conditions                 |
| warning            | 4      | warning conditions               |
| notice             | 5      | normal but significant condition |
| info               | 6      | informational                    |
| debug              | 7      | debug-level messages             |

This example shows how to configure 172.20.52.3 as the destination host and syslog as the UDP port number and verify the configuration:

```
Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+%"rncvhtqto"squ"uvcvkuvkeu/gzrqtv"fguvkpcvkqp"39404207405"u{unqi"
Tqwvgt*eqphki+%"gp f"
Tqwvgt%"ujqy"rncvhtqto"squ"uvcvkuvkeu/gzrqtv"kphq"
SqU"Uvcvkuvkeu"Fcvc"Gzrqtv"Uvcvwu"cpf"Eqphkiwtcvkqp"kphqtocvkqp
////////////////////////////////////
Gzrqtv"Uvcvwu"<"gpcdnfg
Gzrqtv"Kpvgtxcn"<"472"ugeqpfu
Gzrqtv"Fgnkokvgt"<"~
Gzrqtv"Fguvkpcvkqp"<"39404207405"."WFR"rqtv"736"Hceknkv{"nqecn8"."Ugxgtkv{"fgdwi

SqU"Uvcvkuvkeu"Fcvc"Gzrqtv"ku"gpcdnfg"qp"hqnnqykpi"rqtvu<
////////////////////////////////////
IkicdkvGvjgtpgv7146

SqU"Uvcvkuvkeu"Fcvc"gzrqtv"ku"gpcdnfg"qp"hqnnqykpi"ujctgf"ciitgicvg"rqnkegtu<
////////////////////////////////////
ciit30

SqU"Uvcvkuvkeu"Fcvc"Gzrqtv"ku"gpcdnfg"qp"hqnnqykpi"encuu/ocru<
////////////////////////////////////
encuu5
```

## Setting the PFC QoS Statistics Data Export Field Delimiter

To set the PFC QoS statistics data export field delimiter, perform this task:

|        | Command                                                                                           | Purpose                                                  |
|--------|---------------------------------------------------------------------------------------------------|----------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"rncvhtqto"squ"uvcvkuvkeu/gzrqtv"fgnkokvgt"fgnkokvgtaejctcevg"</b></code> | Sets the PFC QoS statistics data export field delimiter. |
| Step 2 | <code>Tqwvgt*eqphki+%<b>"gp f"</b></code>                                                         | Exits configuration mode.                                |



This example shows how to set the PFC QoS statistics data export field delimiter and verify the configuration:

```
Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+%"rncvhtqto"squ"uvcvkuvkeu/gzrqtv"fgnkokvgt". "
Tqwvgt*eqphki+%"gpf"
Tqwvgt%"ujqy"rncvhtqto"squ"uvcvkuvkeu/gzrqtv"kphq"
SqU"Uvcvkuvkeu"Fvcv"Gzrqtv"Uvcvwu"cpf"Eqphkiwtcvkqp"kphqtocvkqp
////////////////////////////////////
Gzrqtv"Uvcvwu"<"gpcdnfg
Gzrqtv"Kpvgtxcn"<"472"ugeqpfu
Gzrqtv"Fgnkokvgt"<".
Gzrqtv"Fguvkpcvkqp"<"39404207405"."WFR"rtv"736"Hceknkv{"nqecn8"."Ugxgtkv{"fgdwi

SqU"Uvcvkuvkeu"Fvcv"Gzrqtv"ku"gpcdnfg"qp"hqnnqykpi"rtvu<
////////////////////////////////////
IkiCDkvGvjgtpgv7146

SqU"Uvcvkuvkeu"Fvcv"Gzrqtv"ku"gpcdnfg"qp"hqnnqykpi"ujctgf"ciitgicvg"rqnkegtu<
////////////////////////////////////
ciit30

SqU"Uvcvkuvkeu"Fvcv"Gzrqtv"ku"gpcdnfg"qp"hqnnqykpi"encuu/ocru<
////////////////////////////////////
encuu5
```



#### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

Participate in the Technical Documentation Ideas forum





## Cisco IOS ACL Support

---

- Restrictions for Cisco IOS ACLs, page 69-2
- Restrictions for Layer 4 Operators in ACLs, page 69-2
- Information About ACL Support, page 69-4
- Policy-Based ACLs (PBACLs), page 69-6
- IPv6 Object Group-Based ACLs (IPv6 OG ACLs), page 69-8
- MAC ACLs, page 69-11
- ARP ACLs, page 69-15
- Optimized ACL Logging, page 69-15
- Dry Run Support for ACLs, page 69-17
- Hardware ACL Statistics, page 69-19



### Note

- For complete information about configuring Cisco IOS ACLs, see this publication:  
[http://www.cisco.com/en/US/docs/ios-xml/ios/sec\\_data\\_acl/configuration/15-sy/sec-data-acl-15-sy-book.html](http://www.cisco.com/en/US/docs/ios-xml/ios/sec_data_acl/configuration/15-sy/sec-data-acl-15-sy-book.html)
- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Restrictions for Cisco IOS ACLs

- You can apply Cisco IOS ACLs directly to Layer 3 ports and to VLAN interfaces.
- You can apply VLAN ACLs and port ACLs to Layer 2 interfaces and VLANs (see [Chapter 73, “Port ACLs \(PACLs\)”](#) and [Chapter 74, “VLAN ACLs \(VACLs\)”](#)).
- Each type of ACL (IP, IPX, and MAC) filters only traffic of the corresponding type. A Cisco IOS MAC ACL never matches IP or IPX traffic unless the **mac packet-classify** configuration command is enabled. By default, the **mac packet-classify** configuration command is disabled.
- When you enter the **mac packet-classify** configuration command, MAC ACLs will be applied to all protocol traffic.
- The PFC does not provide hardware support for Cisco IOS IPX ACLs. Cisco IOS IPX ACLs are supported in software on the route processor (RP).
- By default, the RP sends Internet Control Message Protocol (ICMP) unreachable messages when a packet is denied by an access group.

With the **ip unreachable** command enabled (which is the default), the switch drops most of the denied packets in hardware and sends only a small number of packets to the RP to be dropped in software, which generates ICMP-unreachable messages.

The **ip unreachable** command does not impact the hardware behavior for ACL drop packets and the leaking of ACL deny packets is enabled by default. You can enter the **no ip unreachable** interface configuration command to disable ICMP unreachable messages.

- ICMP unreachable messages are not sent if a packet is denied by a VACL or a PACL.
- Use named ACLs (instead of numbered ACLs) because this causes less CPU usage when creating or modifying ACL configurations and during system restarts. When you create ACL entries (or modify existing ACL entries), the software performs a CPU-intensive operation called an ACL merge to load the ACL configurations into the PFC hardware. An ACL merge also occurs when the startup configuration is applied during a system restart.

With named ACLs, the ACL merge is triggered only when the user exits the **named-acl** configuration mode. However, with numbered ACLs, the ACL merge is triggered for every ACE definition and results in a number of intermediate merges during ACL configuration.

- Global default results are used when the Hitless update does not succeed or when features are not configured on a given interface.

## Restrictions for Layer 4 Operators in ACLs

- [Determining Layer 4 Operation Usage, page 69-2](#)
- [Determining Logical Operation Unit Usage, page 69-3](#)

## Determining Layer 4 Operation Usage

You can specify these types of operations:

- gt (greater than)
- lt (less than)
- neq (not equal)

- eq (equal)
- range (inclusive range)

We recommend that you do not specify more than *ten different* operations on the same ACL. If you exceed this number, each new operation might cause the affected ACE to be translated into more than one ACE.

Use the following two guidelines to determine Layer 4 operation usage:

- Layer 4 operations are considered different if the operator or the operand differ. For example, in this ACL there are three different Layer 4 operations (“gt 10” and “gt 11” are considered two different Layer 4 operations):

```
000"iv"32"rgtokv
000"nv";"fgp{
000"iv"33"fgp{
```



**Note** There is no limit to the use of “eq” operators as the “eq” operator does not use a logical operator unit (LOU) or a Layer 4 operation bit. See the [“Determining Logical Operation Unit Usage” section on page 69-3](#) for a description of LOUs.

- Layer 4 operations are considered different if the same operator/operand couple applies once to a source port and once to a destination port. For example, in this ACL there are two different Layer 4 operations because one ACE applies to the source port and one applies to the destination port.

```
000"Ute"iv"32"000
000"Fuv"iv"32
```

## Determining Logical Operation Unit Usage

Logical operation units (LOUs) are registers that store operator-operand couples. All ACLs use LOUs. There can be up to 104 LOUs and each LOU can store two different operator-operand couples, making the total number of LOU registers to be 208. LOU usage per Layer 4 operation is as follows:

- gt uses 1/2 LOU
- lt uses 1/2 LOU
- neq uses 1/2 LOU
- range uses 1 LOU
- eq does not require a LOU

For example, this ACL would use a single LOU to store two different operator-operand couples:

```
000"Ute"iv"32"000
000"Fuv"iv"32
```

A more detailed example follows:

```
CEN3
000"*fuv"rqtv+"iv"32"rgtokv
000"*fuv"rqtv+"nv";"fgp{
000"*fuv"rqtv+"iv"33"fgp{
000"*fuv"rqtv+"pgs"8"rgtokv
000"*ute"rqtv+"pgs"8"fgp{
000"*fuv"rqtv+"iv"32"fgp{

CEN4
000"*fuv"rqtv+"iv"42"fgp{
```

```
000"*ute"rqtv+"nv";"fgp{
000"*ute"rqtv+"tcpig"33"35"fgp{
000"*fuv"rqtv+"pgs"8"rgtokv
```

The Layer 4 operations and LOU usage is as follows:

- ACL1 Layer 4 operations: 5
- ACL2 Layer 4 operations: 4
- LOUs: 4

An explanation of the LOU usage follows:

- LOU 1 stores “gt 10” and “lt 9”
- LOU 2 stores “gt 11” and “neq 6”
- LOU 3 stores “gt 20” (with space for one more)
- LOU 4 stores “range 11 13” (range needs the entire LOU)

## Information About ACL Support

ACLs can be processed in hardware by the Policy Feature Card (PFC), any Distributed Forwarding Cards (DFCs), or in software by the route processor (RP):

- ACL flows that match a “deny” statement in standard and extended ACLs (input and output) are dropped in hardware if “ip unreachable” is disabled.
- ACL flows that match a “permit” statement in standard and extended ACLs (input and output) are processed in hardware.
- VLAN ACL (VACL) and port ACL (PACL) flows are processed in hardware. If a field that is specified in a VACL or PACL is not supported by hardware processing, then that field is ignored (for example, the **log** keyword in an ACL), or the whole configuration is rejected (for example, a VACL containing IPX ACL parameters).
- IPv6 ACLs use 32 bit encoding.
- VACL logging is processed in software.
- VACL is not supported for IPX access lists.
- VACL supports only deny packet logging.
- Dynamic ACL flows are processed in hardware.
- Idle timeout is processed in software.




---

**Note** Idle timeout is not configurable. Cisco IOS Release 15.4SY does not support the **access-enable host timeout** command.

---

- Except on MPLS interfaces, reflexive ACL flows are processed in hardware after the first packet in a session is processed in software on the RP.
- Reflexive ACL flows are not accelerated in hardware for traffic from IP to various tags and traffic from various tags to IP. Reflexive ACL flows are also not accelerated in hardware for any traffic coming in and going out of all tunnel interfaces.

- IP accounting for an ACL access violation on a given port is supported only for the ACL packets that are deny leaked, by forwarding all denied packets for that port to the RP for software processing without impacting other flows.
- MAC ACLs are supported in hardware on switch ports (MAC PACLS) or on VLANs as part of VACLs.
- The PFC does not provide hardware support for Cisco IOS IPX ACLs. Cisco IOS IPX ACLs are supported in software on the RP.
- Extended name-based MAC address ACLs are supported in hardware.
- The following ACL types are processed in software:
  - Internetwork Packet Exchange (IPX) access lists
  - Standard XNS access list
  - Extended XNS access list
  - DECnet access list
  - Protocol type-code access list

**Note**

IP packets with a header length of less than five will not be access controlled.

- Unless you configure optimized ACL logging (OAL), flows that require logging are processed in software without impacting nonlogged flow processing in hardware (see the [“Optimized ACL Logging” section on page 69-15](#)).
- The forwarding rate for software-processed flows is substantially less than for hardware-processed flows.
- With the hardware statistics feature enabled, when you enter the **show ip access-list** command, the match count displayed includes packets processed in hardware.
- When you enter the **ip unreachable config** command on the PFC interface, the hardware behavior remains unaltered.
- The Hitless TCAM update for IPv4 and IPv6 provides the capability to apply existing features to the incoming traffic while updating new features in the TCAM. The Hitless feature update is mandatory for IPv6 traffic where any changes in the IPv6 ACL on a given interface would trigger a reprogramming of all the IPv6 features on all the interfaces.
- Hitless update is enabled by default. To disable the Hitless update, enter the **no platform hardware acl update-mode hitless** command.

**Note**

See the [“Restrictions for eFSU” section on page 5-2](#) for information about some release-specific restrictions.

- With the Hitless update enabled, when the FM (Feature Manager) or the switch is making updates to the recently modified ACL, a copy of each TCAM entry will be programmed in hardware. If the ACLs are not modified, the TCAM space reserved for hitless update will equal the number of TCAM entries used by the largest ACL.

# Policy-Based ACLs (PBACLs)

- [Restrictions for PBACLs, page 69-6](#)
- [Information about PBACLs, page 69-6](#)
- [How to Configure PBACLs, page 69-6](#)

## Restrictions for PBACLs

- PBACLs are supported on Layer 3 interfaces (such as routed interfaces and VLAN interfaces).
- The PBACL feature only supports IPv4 ACEs.
- The PBACL feature supports only Cisco IOS ACLs. It is not supported with any other features. The keywords **reflexive** and **evaluate** are not supported.
- The PBACL feature supports only named Cisco IOS ACLs. It does not support numbered ACLs.
- Feature interactions for policy-based ACLs are the same as for Cisco IOS ACLs.

## Information about PBACLs

PBACLs provide the capability to apply access control policies across object groups. An object group is a group of users or servers.

You define an object group as a group of IP addresses or as a group of protocol ports. You then create access control entries (ACEs) that apply a policy (such as permit or deny) to the object group. For example, a policy-based ACE can permit a group of users to access a group of servers.

An ACE defined using a group name is equivalent to multiple ACEs (one applied to each entry in the object group). The system expands the PBACL ACE into multiple Cisco IOS ACEs (one ACE for each entry in the group) and populates the ACEs in the TCAM. Therefore, the PBACL feature reduces the number of entries you need to configure but does not reduce TCAM usage.

If you make changes in group membership, or change the contents of an ACE that uses an access group, the system updates the ACEs in the TCAM. The following types of changes trigger the update:

- Adding a member to a group
- Deleting a member from a group
- Modifying the policy statements in an ACE that uses an access group

You configure a PBACL using extended Cisco IOS ACL configuration commands. As with regular ACEs, you can associate the same access policy with one or more interfaces.

When you configure an ACE, you can use an object group to define the source, the destination, or both.

## How to Configure PBACLs

- [Configuring a PBACL IP Address Object Group, page 69-7](#)
- [Configuring a PBACL Protocol Port Object Group, page 69-7](#)
- [Configuring ACLs with PBACL Object Groups, page 69-8](#)
- [Configuring PBACL on an Interface, page 69-8](#)



## Configuring a PBACL IP Address Object Group

To create or modify a PBACL IP address object group, perform this task:

|        | Command                                                                                         | Purpose                                                                                                                                                       |
|--------|-------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%qdlgev/itqwr"kr"cfftguu"<br/>qdlgevaitqwrapcog"</code>                     | Defines object group name and enters IP-address object-group configuration mode.                                                                              |
| Step 2 | <code>Tqvwgt*eqphki/krcfft/qitqwr+%"}ip_address mask;"~"<br/>{jqv"}name ~"kracfftguu;"i"</code> | Configures a member of the group. The member is either a network address plus mask or a host (identified by host name or IP address).                         |
| Step 3 | <code>Tqvwgt*eqphki/krcfft/qitqwr+%"}gpf;"~"}gzkv;</code>                                       | To leave the configuration mode, enter the <b>end</b> command.<br><br>To leave the IP-address object-group configuration mode, enter the <b>exit</b> command. |

The following example creates an object group with three hosts and a network address:

```
Tqvwgt*eqphki+%qdlgev/itqwr"kr"cfftguu"o{CI
Tqvwgt*eqphki/krcfft/ritqwr+%"}jqv"3204204203"
Tqvwgt*eqphki/krcfft/ritqwr+%"}jqv"3204204207"
Tqvwgt*eqphki/krcfft/ritqwr+%"}320520202"47704770202"
```

## Configuring a PBACL Protocol Port Object Group

To create or modify a PBACL protocol port object group, perform this task:

| Command                                                                                                                       | Purpose                                                                                                                                                             |
|-------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqvwgt*eqphki+%qdlgev/itqwr"kr"rqtv"<br/>qdlgevaitqwrapcog"</code>                                                      | Defines object group name and enters port object-group configuration mode.                                                                                          |
| <code>Tqvwgt*eqphki/rqtv/qitqwr+%"}gs"pwodgt;"~"}iv"pwodgt;"<br/>~"}nv"pwodgt;"~"}pgs"pwodgt;"~"}tcpig"number number;"</code> | Configures a member of the group. The member is either equal to or not equal to a port number, less than or greater than a port number, or a range of port numbers. |
| <code>Tqvwgt*eqphki/rqtv/qitqwr+%"}gpf;"~"}gzkv</code>                                                                        | To leave the configuration mode, enter the <b>end</b> command.<br><br>To leave the port object-group configuration mode, enter the <b>exit</b> command.             |

The following example creates a port object group that matches protocol port 100 and any port greater than 200, except 300:

```
Tqvwgt*eqphki+%qdlgev/itqwr"kr"rqtv"o{RI
Tqvwgt*eqphki/rqtv/ritqwr+%"}gs"322"
Tqvwgt*eqphki/rqtv/ritqwr+%"}iv"422"
Tqvwgt*eqphki/rqtv/ritqwr+%"}pgs"522"
```

## Configuring ACLs with PBACL Object Groups

To configure an ACL to use a PBACL object group, perform this task:

|        | Command                                                                                                                    | Purpose                                                                                                                             |
|--------|----------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%<b>kr</b>"ceeguu/nkuv"gzvgpf"cenapcog"</code>                                                         | Defines an extended ACL with the specified name and enters extended-ACL configuration mode.                                         |
| Step 2 | <code>Tqvwgt*eqphki/gzv/pcen+%<b>rgtokv</b>"ver"<b>cfftitqwr</b>"<br/>object_group_name cfftitqwr"object_group_name</code> | Configures an ACE for TCP traffic using IP address object group as the source policy and an object group as the destination policy. |
| Step 3 | <code>Tqvwgt*eqphki/gzv/pcen+%<b>gzkv</b></code>                                                                           | Exits extended ACL configuration mode.                                                                                              |

The following example creates an access list that permits packets from the users in myAG if the protocol ports match the ports specified in myPG:

```
Tqvwgt*eqphki+%kr"ceeguu/nkuv"gzvgpf"o{/rdcen/rqnke{
Tqvwgt*eqphki/gzv/pcen+%rgtokv"ver"cfftitqwr"o{CI"rqtvitqwr"o{RI"cp{
Tqvwgt*eqphki/gzv/pcen+%fgp{"ver"cp{"cp{
Tqvwgt*eqphki/gzv/pcen+%gzkv
Tqvwgt*eqphki+%gzkv
Tqvwgt%ujqy"kr"ceeguu/nkuv"o{/rdcen/rqnke{
Gzvgpf"KR"ceeguu/nkuv"o{/rdcen/rqnke{
32 rgtokv"ver"cfftitqwr"CI"rqtvitqwr"RI"cp{
42 rgtokv"ver"cp{"cp{
Tqvwgt%ujqy"kr"ceeguu/nkuv"o{/rdcen/rqnke{"gzrcpf
Gzvgpf"KR"ceeguu/nkuv"o{/rdcen/rqnke{"gzrcpf
42"rgtokv"ver"jquv"3204204203"gs"322"cp{
42"rgtokv"ver"jquv"3204204203"iv"422"cp{
42"rgtokv"ver"jquv"3204204203"pgs"522"cp{
42"rgtokv"ver"jquv"3204204207"gs"322"cp{
42"rgtokv"ver"jquv"3204204207"iv"422"cp{
42"rgtokv"ver"jquv"3204204207"pgs"522"cp{
42"rgtokv"ver"320520202"47704770202"gs"322"cp{
42"rgtokv"ver"320520202"47704770202"iv"422"cp{
42"rgtokv"ver"320520202"47704770202"pgs"522"cp{
```

## Configuring PBACL on an Interface

To configure a PBACL on an interface, use the **ip access-group** command. The command syntax and usage is the same as for Cisco IOS ACLs. For additional information, see the [“Restrictions for Cisco IOS ACLs” section on page 69-2](#).

The following example shows how to associate access list my-pbacl-policy with VLAN 100:

```
Tqvwgt*eqphki+%kp"xmcp"322
Tqvwgt*eqphki/kh+%kr"ceeguu/itqwr"or/rdcen/rqnke{"kp
```

## IPv6 Object Group-Based ACLs (IPv6 OG ACLs)

- [Restrictions for IPv6 OG ACLs, page 69-9](#)
- [Information about IPv6 OG ACLs, page 69-9](#)
- [How to Configure IPv6 OG ACLs, page 69-9](#)

## Restrictions for IPv6 OG ACLs

- IPv6 OG ACLs are supported on Layer 3 interfaces (such as routed interfaces and VLAN interfaces).
- The IPv6 OG ACLs feature supports only Cisco IOS ACLs. It is not supported with any other features. The keywords **reflexive** and **evaluate** are not supported.
- The IPv6 OG ACLs feature supports only named Cisco IOS ACLs. It does not support numbered ACLs.
- Feature interactions for IPv6 OG ACLs are the same as for Cisco IOS ACLs.
- The highest number of object group-based ACEs supported in an IPv6 OG ACL is 2048.

## Information about IPv6 OG ACLs

IPv6 OG ACLs provide the capability to apply access control policies across object groups. An object group is a group of users or servers.

You define an object group as a group of IPv6 addresses or as a group of protocol ports. You then create access control entries (ACEs) that apply a policy (such as permit or deny) to the object group. For example, a policy-based ACE can permit a group of users to access a group of servers.

An ACE defined using a group name is equivalent to multiple ACEs (one applied to each entry in the object group). The system expands the IPv6 OG ACL ACE into multiple Cisco IOS ACEs (one ACE for each entry in the group) and populates the ACEs in the TCAM. Therefore, the IPv6 OG ACL feature reduces the number of entries you need to configure but does not reduce TCAM usage.

If you make changes in group membership, or change the contents of an ACE that uses an access group, the system updates the ACEs in the TCAM. The following types of changes trigger the update:

- Adding a member to a group
- Deleting a member from a group
- Modifying the policy statements in an ACE that uses an access group

You configure a IPv6 OG ACL using extended Cisco IOS ACL configuration commands. As with regular ACEs, you can associate the same access policy with one or more interfaces.

When you configure an ACE, you can use an object group to define the source, the destination, or both.

## How to Configure IPv6 OG ACLs

- [Configuring a IPv6 Address Object Group, page 69-9](#)
- [Configuring a IPv6 Protocol Object Group, page 69-10](#)
- [Configuring ACLs with IPv6 Object Groups, page 69-11](#)
- [Configuring IPv6 OG ACL on an Interface, page 69-11](#)

## Configuring a IPv6 Address Object Group

To create or modify a IPv6 OG ACL IPv6 address object group, perform this task:

|        | Command                                                                         | Purpose                                                                                                                                                         |
|--------|---------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%qdlgev/itqwr"x8/pgvyqtm"<br/>qdlgevaitqwrapcog"</code>     | Defines object group name and enters IPv6-address object-group configuration mode.                                                                              |
| Step 2 | <code>Tqvwgt*eqphki/x8pgvyqtm/itqwr+%}<br/>}jquv"}name ~"kracfftguu;" ;"</code> | Configures a member of the group. The member is either a network address plus mask or a host (identified by host name or IPv6 address).                         |
| Step 3 | <code>Tqvwgt*eqphki/x8pgvyqtm/itqwr+%}<br/>}gpf ; "~" }gzkv ;</code>            | To leave the configuration mode, enter the <b>end</b> command.<br><br>To leave the IPv6-address object-group configuration mode, enter the <b>exit</b> command. |

The following example creates an object group with hosts and a network address:

```
Tqvwgt*eqphki+%qdlgev/itqwr"x8/pgvyqtm"o{CI
Tqvwgt*eqphki/x8pgvyqtm/itqwr+%}jquv"4223<<3
Tqvwgt*eqphki/x8pgvyqtm/itqwr+%}4224<<3186
Tqvwgt*eqphki/x8pgvyqtm/itqwr+%}gzkv"
```

## Configuring a IPv6 Protocol Object Group

To create or modify a IPv6 OG ACL protocol object group, perform this task:

| Command                                                                                                     | Purpose                                                                                                                                                     |
|-------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqvwgt*eqphki+%qdlgev/itqwr"x8/ugtxkeg"<br/>qdlgevaitqwrapcog"</code>                                 | Defines object group name and enters protocol object-group configuration mode.                                                                              |
| <code>Tqvwgt*eqphki/x8ugtxkeg/itqwr+%}<br/>}cjr ; "~" }gur ; "~"<br/>}krx8 ; "~" }rer ; "~" }ver ; "</code> | Configures a member of the group.                                                                                                                           |
| <code>Tqvwgt*eqphki/rqtv/qitqwr+%}gpf "~" }gzkv</code>                                                      | To leave the configuration mode, enter the <b>end</b> command.<br><br>To leave the protocol object-group configuration mode, enter the <b>exit</b> command. |

The following example creates a protocol object group:

```
Tqvwgt*eqphki+%qdlgev/itqwr"x8/ugtxkeg"o{RI
Tqvwgt*eqphki/x8ugtxkeg/itqwr+%}gur"
Tqvwgt*eqphki/x8ugtxkeg/itqwr+%}jd
Tqvwgt*eqphki/x8ugtxkeg/itqwr+%}gzkv"
```

## Configuring ACLs with IPv6 Object Groups

To configure an ACL to use a IPv6 OG ACL object group, perform this task:

|        | Command                                                                                                       | Purpose                                                                                                                               |
|--------|---------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "krx8"ceeguu/nkuv"qi/cen</code>                                                         | Defines an object group ACL with the specified name and enters IPv6-ACL configuration mode.                                           |
| Step 2 | <code>Tqvwgt*eqphki/krx8/cen+% "rgtokv"ver"qdlgev/itqwr"</code><br><code>&gt;object_group_name&gt; any</code> | Configures an ACE for TCP traffic using IPv6 address object group as the source policy and an object group as the destination policy. |
| Step 3 | <code>Tqvwgt*eqphki/gzv/pcen+% "gzkv</code>                                                                   | Exits IPv6-ACL configuration mode.                                                                                                    |

The following example creates an access list that permits packets from the users in myAG if the protocol ports match the ports specified in myPG:

```
Tqvwgt*eqphki+% "kr"ceeguu/nkuv"qi/cen
Tqvwgt*eqphki/krx8/cen+% "rgtokv"ver"qdlgev/itqwr
Tqvwgt*eqphki/krx8/cen+% "fgp{ "ver"cp{ "cp{
Tqvwgt*eqphki/krx8/cen+% "gzkv
Tqvwgt*eqphki+% "gzkv
```

## Configuring IPv6 OG ACL on an Interface

To configure a IPv6 OG ACL on an interface, use the **ipv6 traffic-filter access-list-name** {in | out} command in interface mode. The command syntax and usage is the same as for Cisco IOS ACLs. For additional information, see the [“Restrictions for Cisco IOS ACLs”](#) section on page 69-2.

## MAC ACLs

- [How to Configure Protocol-Independent MAC ACL Filtering](#), page 69-11
- [How to Enable VLAN-Based MAC QoS Filtering](#), page 69-13
- [Configuring MAC ACLs](#), page 69-13



### Note

You can use MAC ACLs with VLAN ACLs (VACLs). For more information, see [Chapter 74, “VLAN ACLs \(VACLs\).”](#)

## How to Configure Protocol-Independent MAC ACL Filtering

Protocol-independent MAC ACL filtering applies MAC ACLs to all ingress traffic types (for example, IPv4 traffic, IPv6 traffic, and MPLS traffic, in addition to MAC-layer traffic).

You can configure these interface types for protocol-independent MAC ACL filtering:

- VLAN interfaces
- Routed interfaces
- Physical LAN ports

- Logical LAN subinterfaces

Ingress traffic permitted or denied by a MAC ACL on an interface configured for protocol-independent MAC ACL filtering is processed by egress interfaces as MAC-layer traffic. You cannot apply egress IP ACLs to traffic that was permitted or denied by a MAC ACL on an interface configured for protocol-independent MAC ACL filtering.

To configure protocol-independent MAC ACL filtering, perform this task:

|        | Command                                                                                                                                      | Purpose                                                                                                                                        |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <pre>Tqwvgt*eqphki+% "kpvgtthceg" } }xncp "vlan_ID;" ~" }type slot/port] 0uwdkpvgtthceg_;" ~" }rqtv/ejcppgn pwodgt] 0uwdkpvgtthceg_;"</pre>  | Selects the interface to configure.                                                                                                            |
| Step 2 | <pre>Tqwvgt*eqphki/kh+%] pq_ "oce"rcemgv/encuukh{ " }kprwv" ~"qvwrvw" ~"wug" }egaequ" }kprwv" ~"qvwrvw;" ~" fuer" }kprwv" ~"qvwrvw;" ;</pre> | Enables protocol-independent MAC ACL filtering on the interface. By default, the <b>mac packet-classify</b> configuration command is disabled. |

- Do not configure protocol-independent MAC ACL filtering on VLAN interfaces where you have configured an IP address.
- When the mac acl filtering is enabled, all other protocol features such as RACL, microflow policing will be ignored in the hardware.

This example shows how to configure VLAN interface 4018 for protocol-independent MAC ACL filtering and how to verify the configuration:

```
Tqwvgt*eqphki+% "kpvgtthceg"xncp "623:"
Tqwvgt*eqphki/kh+% "oce"rcemgv/encuukh{ "
Tqwvgt*eqphki/kh+% "gpf"
Tqwvgt% "ujqy"twppkpi/eqphki "kpvgtthceg"xncp "623:" ~"dgikp "623:"
kpvgtthceg "Xncp623:
ovw";438
krx8"gpdcng
oce"rcemgv/encuukh{
gpf
```

This example shows how to configure Gigabit Ethernet interface 6/1 for protocol-independent MAC ACL filtering and how to verify the configuration:

```
Tqwvgt*eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv"813"
Tqwvgt*eqphki/kh+% "oce"rcemgv/encuukh{ "
Tqwvgt*eqphki/kh+% "gpf"
Tqwvgt% "ujqy"twppkpi/eqphki "kpvgtthceg"ikicdkvgvjgtpgv"813" ~"dgikp "813"
kpvgtthceg "IkicdkvGvjgtpgv813
ovw";438
pq"kr"cfftgau
oce"rcemgv/encuukh{
ornu"n4vtcpurqtv"tqwvg"6060606"62;6
gpf
```

This example shows how to configure Gigabit Ethernet interface 3/24, subinterface 4000, for protocol-independent MAC ACL filtering and how to verify the configuration:

```
Tqwvgt*eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv"514606222"
Tqwvgt*eqphki/kh+% "oce"rcemgv/encuukh{ "
Tqwvgt*eqphki/kh+% "gpf"
Tqwvgt% "ujqy"twppkpi/eqphki "kpvgtthceg"ikicdkvgvjgtpgv"514606222" ~"dgikp "514606222"
kpvgtthceg "IkicdkvGvjgtpgv514606222
gpecruwncvkqp"fqv3S"6222
oce"rcemgv/encuukh{
```

## How to Enable VLAN-Based MAC QoS Filtering

To enable VLAN-based QoS filtering in MAC ACLs, perform this task:

To disable VLAN-based QoS filtering in MAC ACLs, perform this task:

## Configuring MAC ACLs

You can configure MAC ACLs that do VLAN-based filtering or CoS-based filtering or both.

You can globally enable or disable VLAN-based QoS filtering in MAC ACLs (disabled by default).

To configure a MAC ACL, perform this task:

- Cisco IOS Release 15.4SY supports the **vlan** and **cos** keywords.
- The **vlan** keyword for VLAN-based QoS filtering in MAC ACLs can be globally enabled or disabled and is disabled by default.
- You can enter MAC addresses as three 2-byte values in dotted hexadecimal format. For example, 0030.9629.9f84.

- You can enter MAC address masks as three 2-byte values in dotted hexadecimal format. Use 1 bits as wildcards. For example, to match an address exactly, use 0000.0000.0000 (can be entered as 0.0.0).
- You can enter an EtherType and an EtherType mask as hexadecimal values.
- Entries without a protocol parameter match any protocol.
- ACL entries are scanned in the order you enter them. The first matching entry is used. To improve performance, place the most commonly used entries near the beginning of the ACL.
- An implicit **deny any any** entry exists at the end of an ACL unless you include an explicit **permit any any** entry at the end of the list.
- All new entries to an existing list are placed at the end of the list. You cannot add entries to the middle of a list.
- This list shows the EtherType values and their corresponding protocol keywords:
  - 0x0600—xns-idp—Xerox XNS IDP
  - 0x0BAD—vines-ip—Banyan VINES IP
  - 0x0baf—vines-echo—Banyan VINES Echo
  - 0x6000—etype-6000—DEC unassigned, experimental
  - 0x6001—mop-dump—DEC Maintenance Operation Protocol (MOP) Dump/Load Assistance
  - 0x6002—mop-console—DEC MOP Remote Console
  - 0x6003—decnet-iv—DEC DECnet Phase IV Route
  - 0x6004—lat—DEC Local Area Transport (LAT)
  - 0x6005—diagnostic—DEC DECnet Diagnostics
  - 0x6007—lavc-sca—DEC Local-Area VAX Cluster (LAVC), SCA
  - 0x6008—amber—DEC AMBER
  - 0x6009—mumps—DEC MUMPS
  - 0x0800—ip—Malformed, invalid, or deliberately corrupt IP frames
  - 0x8038—dec-spanning—DEC LANBridge Management
  - 0x8039—dsm—DEC DSM/DDP
  - 0x8040—netbios—DEC PATHWORKS DECnet NETBIOS Emulation
  - 0x8041—msdos—DEC Local Area System Transport
  - 0x8042—etype-8042—DEC unassigned
  - 0x809B—appletalk—Kinetics EtherTalk (AppleTalk over Ethernet)
  - 0x80F3—arp—Kinetics AppleTalk Address Resolution Protocol (ARP)

This example shows how to create a MAC-Layer ACL named `mac_layer` that denies dec-phase-iv traffic with source address 0000.4700.0001 and destination address 0000.4700.0009, but permits all other traffic:

```
Tqwgvt*eqphki+% "oce"ceeguu/nkuv"gzvgpf"gf"oceanc{gt "
Tqwgvt*eqphki/gzv/ocen+% "fgp{"22220692202223"20202"2222069220222;"20202" fge/rjcug/kx"
Tqwgvt*eqphki/gzv/ocen+% "rgtokv"cp{"cp{"
```



# ARP ACLs

This section describes how to configure ARP ACLs. You can configure named ACLs that filter ARP traffic (EtherType 0x0806). To configure an ARP ACL, perform this task:

|        | Command                                                                                                                                     | Purpose                                                 |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "ctr"ceeguu/nkuv"nkuvapcog"</code>                                                                                    | Configures an ARP ACL.                                  |
| Step 2 | <code>Tqvwgt*eqphki/ctr/pcen+% "rgtokv"~"fgp{ ; " }kr" }cp{ "<br/>~"jqv"ugpfgtakr"~"sender_ip<br/>ugpfgtakrayknfectfocum; "oce"cp{ "</code> | Configures an access control entry (ACE) in an ARP ACL. |

- This publication describes the ARP ACL syntax that is supported in hardware by the PFC. Any other ARP ACL syntax displayed by the CLI help when you enter a question mark (“?”) is not supported and cannot be used to filter ARP traffic for QoS.
- ACLs entries are scanned in the order you enter them. The first matching entry is used. To improve performance, place the most commonly used entries near the beginning of the ACL.
- An implicit **deny ip any mac any** entry exists at the end of an ACL unless you include an explicit **permit ip any mac any** entry at the end of the list.
- All new entries to an existing list are placed at the end of the list. You cannot add entries to the middle of a list.
- The PFC does not apply IP ACLs to ARP traffic.
- You cannot apply microflow policing to ARP traffic.

This example shows how to create an ARP ACL named `arp_filtering` that only permits ARP traffic from IP address 10.1.1.1:

```
Tqvwgt*eqphki+% "ctr"ceeguu/nkuv"ctrahknvgtkpi "
Tqvwgt*eqphki/ctr/pcen+% "rgtokv"kr"jqv"32030303 "oce"cp{ "
```

## Optimized ACL Logging

- [Restrictions for OAL, page 69-15](#)
- [Information about OAL, page 69-16](#)
- [How to Configure OAL, page 69-16](#)

## Restrictions for OAL

- OAL and VACL capture are incompatible. Do not configure both features on the switch. With OAL configured, use SPAN to capture traffic.
- OAL checks for conflicts with other features using capture like VACL capture, Lawful Intercept (LI), and IPv6 learning.
- OAL supports only IPv4 unicast packets.
- OAL is not supported with port ACLs (PACLs).

- OAL does not provide hardware support for the following:
  - Reflexive ACLs
  - ACLs used to filter traffic for other features (for example, QoS)
  - ACLs for unicast reverse path forwarding (uRPF) check exceptions
  - Exception packets (for example, TTL failure and MTU failure)
  - Packets with IP options
  - Packets addressed at Layer 3 to the router
  - Packets sent to the RP to generate ICMP unreachable messages
  - Packets being processed by features not accelerated in hardware

## Information about OAL

OAL provides hardware support for ACL logging. Unless you configure OAL, packets that require logging are processed completely in software on the RP. OAL permits or drops packets in hardware on the PFC or DFC and uses an optimized routine to send information to the RP to generate the logging messages.

## How to Configure OAL

- [Configuring OAL Global Parameters, page 69-16](#)
- [Configuring OAL on an Interface, page 69-17](#)
- [Displaying OAL Information, page 69-17](#)
- [Clearing Cached OAL Entries, page 69-17](#)

## Configuring OAL Global Parameters

To configure global OAL parameters, perform this task:

| Command                                                                                                                                                                                    | Purpose                     |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------|
| <code>Tqvwgt*eqphki+% "nqiikpi"kr"ceegu/nkuv"ecejg" } }gpvtkgu" pwodgtaqhagpvtkgu; "~" }kpvgtxcn"ugeqpfu; "~" }tcvg/nkokv" pwodgtaqharcemgvu; "~" }vjtgujqnf"pwodgtaqharcemgvu; i "</code> | Sets OAL global parameters. |

- **entries** *number\_of\_entries*
  - Sets the maximum number of entries cached.
  - Range: 0–1,048,576 (entered without commas).
  - Default: 8192.
- **interval** *seconds*
  - Sets the maximum time interval before an entry is sent to be logged. Also if the entry is inactive for this duration it is removed from the cache.
  - Range: 5–86,400 (1440 minutes or 24 hours, entered without commas).

- Default: 300 seconds (5 minutes).
- **rate-limit** *number\_of\_packets*
  - Sets the number of packets logged per second in software.
  - Range: 10–1,000,000 (entered without commas).
  - Default: 0 (rate limiting is off and all packets are logged).
- **threshold** *number\_of\_packets*
  - Sets the number of packet matches before an entry is logged.
  - Range: 1–1,000,000 (entered without commas).
  - Default: 0 (logging is not triggered by the number of packet matches).

## Configuring OAL on an Interface

To configure OAL on an interface, perform this task:

|        | Command                                                                  | Purpose                                           |
|--------|--------------------------------------------------------------------------|---------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+%<b>"kpvgthceg"</b>}} type slot/port;</code>         | Specifies the interface to configure.             |
| Step 2 | <code>Tqwwgt*eqphki/kh+%<b>"nqiikpi"kr"ceeguu/nkuv"ecejg"kp"</b></code>  | Enables OAL for ingress traffic on the interface. |
| Step 3 | <code>Tqwwgt*eqphki/kh+%<b>"nqiikpi"kr"ceeguu/nkuv"ecejg"qvw"</b></code> | Enables OAL for egress traffic on the interface.  |

## Displaying OAL Information

To display OAL information, perform this task:

| Command                                                        | Purpose                   |
|----------------------------------------------------------------|---------------------------|
| <code>Tqwwgt%<b>"ujqy"nqiikpi"kr"ceeguu/nkuv"ecejg"</b></code> | Displays OAL information. |

## Clearing Cached OAL Entries

To clear cached OAL entries, perform this task:

| Command                                                         | Purpose                    |
|-----------------------------------------------------------------|----------------------------|
| <code>Tqwwgt%<b>"engct"nqiikpi"kr"ceeguu/nkuv"ecejg"</b></code> | Clears cached OAL entries. |

# Dry Run Support for ACLs

- [Restrictions for Dry Run Support, page 69-18](#)
- [Information About Dry Run Support, page 69-18](#)
- [How to Configure Dry Run Support for ACLs, page 69-18](#)

## Restrictions for Dry Run Support

- Dry Run is supported only for IPv4 RACLs and can only be applied on interfaces.
- Dry Run is supported only with named ACLs (Standard or Extended) and not with numbered ACLs.
- Only one Dry Run session is allowed at a time with a single ACL or multiple ACLs in the Dry Run session.
- The Dry Run session ACL or ACLs are removed when an ACL or ACLs are changed under configuration mode.
- Exiting the Dry Run session does not clear the existing configuration. Clear the existing session before starting a new configuration.
- The validation process may abort if there are configuration or hardware changes made during the validation process.
- Dry Run mode does not support committing the changes to the running configuration.
- Dry Run is not supported for ACLs used in QoS policies.
- Dry Run is not supported for ACLs having hardware statistics enabled.
- You can access the switch using another Telnet session while a Dry Run session is in progress.

## Information About Dry Run Support

In other releases, when a new feature is applied on an interface configured along with other features, and if the new feature does not fit in the TCAM, then existing features are also affected and removed from the TCAM. To incrementally update the feature and see whether the feature fits into the TCAM without installing it, the switch provides a Dry Run support, where applications can send regular requests to test whether the request can be programmed successfully or not. The switch receives the dry run request and calculates the total TCAM resources required for the request and compares those resources against the available free resources. If the request fits in successfully, then the switch returns a success, else the switch returns a failure. The Dry Run support helps applications make intelligent decisions.

## How to Configure Dry Run Support for ACLs

To configure the Dry Run support, perform this task:

|        | Command                                                                                                    | Purpose                                                     |
|--------|------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------|
| Step 1 | <code>Tqwgvt%<b>"eqphkiwtg"uguukqp</b> session_name</code>                                                 | Creates a configuration session and enters the dry run mode |
| Step 2 | <code>Tqwgvt*ft{/twp/eqphki+%}<b>"kr"ceeguu/nkuv</b>"gzvpgfgf"TCEN32M</code><br><code>xcnkfcvgi</code>     | Choose the option to configure the dry run session          |
| Step 3 | <code>Tqwgvt*ft{/twp/eqphki+%<b>"kr"ceeguu/nkuv</b>"gzvpgfgf"~"</code><br><code>uvcpfctfi;"acl_name</code> | Choose the type of ACL                                      |

The following example configures the dry run support for a session with an existing ACL RACL10K:

```
Tqwgvt%"eqphkiwtg"uguukqp"vguv
Tqwgvt*ft{/twp/eqphki+%"kr"ceeguu/nkuv"gzvpgfgf"TCEN32M
Tqwgvt*ft/eqphki/gzv/pcen+%"rgtokv"ver"jquv"320420203"jquv"330420203
Tqwgvt*ft/eqphki/gzv/pcen+%"rgtokv"ver"jquv"320420204"jquv"330420204
```

```

Tqvwgt*ft/eqphki/gzv/pcen+%"rgtokv"ver"jquv"320420205"jquv"330420205
Tqvwgt*ft/eqphki/gzv/pcen+%"rgtokv"ver"jquv"320420206"jquv"330420206
Tqvwgt*ft/eqphki/gzv/pcen+%"rgtokv"ver"jquv"320420207"jquv"330420207

Tqvwgt*ft/eqphki/gzv/pcen+%"gzkv

Tqvwgt*ft{/twp/eqphki+%"xcnkfcvg

Tqvwgt*ft{/twp/eqphki+%"gzkv
Tqvwgt%
0Hgd"45"4232"35<68<74074:<"Xcnkfcvkqp"ku"kp"rtqitguu"##
0Hgd"45"4232"35<68<74074:<"Rngcug"vt{"cickp"ncvgt0
0Hgd"45"4232"35<68<750358<"'HO/8/UGUUKQPaXCnkFCVKQPaTGUWNVaKPHQ<"Uguukqp"Xcnkfcvkqp"Tguwnv"
<"$Xcnkfcvkqp"Egorngvgf"Uweguuhwnn{0$
0"Rngcug"wug")ujgy"eqphki"uguukqp"vguv"uvcvwu)"vq"igv"oqtg"fgvcknu"qh"vjg"eqphki"
xcnkfcvkqp"uvcvwu

Tqvwgt%"ujgy"eqphkiwtcvkqp"uguukqp"vguv"uvcvwu
????????????????????????????????????
Uvcvwu"qh"ncuv"eqphki"xcnkfcvkqp<"
Vkoguvcor<"4232/24/45B35<68<73
????????????????????????????????????
UNQV"? "J 3 _ " " " "Tguwnv"? "Eqphkiwtcvkqp"yknn"hkv"kp"VECO
UNQV"? "J 4 _ " " " "Tguwnv"? "Eqphkiwtcvkqp"yknn"hkv"kp"VECO
UNQV"? "J 7 _ " " " "Tguwnv"? "Eqphkiwtcvkqp"yknn"hkv"kp"VECO

Tqvwgt%"engct"eqphkiwtcvkqp"uguukqp"vguv

Tqvwgt%"eqphkiwtg"vgtokpcn
Gpvg"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpgo" "Gpf"ykvj"EPVN1\0

Tqvwgt*eqphki+%"kr"ceeguu/nkuv"gzvgpfgf"TCEN32M
Tqvwgt*eqphki/gzv/pcen+%"rgtokv"ver"jquv"320420203"jquv"330420203
Tqvwgt*eqphki/gzv/pcen+%"rgtokv"ver"jquv"320420204"jquv"330420204
Tqvwgt*eqphki/gzv/pcen+%"rgtokv"ver"jquv"320420205"jquv"330420205
Tqvwgt*eqphki/gzv/pcen+%"rgtokv"ver"jquv"320420206"jquv"330420206
Tqvwgt*eqphki/gzv/pcen+%"rgtokv"ver"jquv"320420207"jquv"330420207
Tqvwgt*eqphki/gzv/pcen+%"gpf

Tqvwgt%"

```

## Hardware ACL Statistics

- [Restrictions for Hardware ACL Statistics, page 69-19](#)
- [Information About Hardware ACL Statistics, page 69-20](#)
- [How to Configure Hardware ACL Statistics, page 69-20](#)

## Restrictions for Hardware ACL Statistics

- Hardware ACL statistics are supported for IPv4 and IPv6 RACLs in both ingress and egress directions.
- In IPv4, hardware ACL statistics are supported for both numbered and named ACLs.
- The hardware statistics is retrieved by polling the hardware once every 60 seconds.
- The hardware statistics is lost after SSO (Stateful Switchover).

- The hardware statistics is maintained on an ACL basis. If there are multiple interfaces using the same ACL, the statistics will be aggregated.
- Hardware statistics is disabled when ODM (Order Dependent Merge) optimizations are enabled.

## Information About Hardware ACL Statistics

Using the hardware ACL statistics, the hardware counters for a given ACL are gathered, aggregated, and displayed in the IOS access-list output.

The ACE hit count is retrieved from the hardware and can be viewed using the following commands:

**show ip access-list** and **show ipv6 access-list**

Hardware statistics is disabled by default. To enable or disable hardware statistics, enter the command for hardware statistics.

## How to Configure Hardware ACL Statistics

The following example enables hardware statistics for ACL racl1:

```
Tqwvgt*eqphki+% "kr" ceeguu/nkuv"gzvgpfgf"tcen3
Tqwvgt*eqphki/gzv/pcen+% "jpq_" jctfyctg"uvcvkuvkeu
Tqwvgt*eqphki/gzv/pcen+% "rgtokv"kr"jquv"32030303"jquv"4040404
Tqwvgt*eqphki/gzv/pcen+% "rgtokv"kr"jquv"5050505"jquv"6060606
Tqwvgt*eqphki/gzv/pcen+% "fgp{ "kr"cp{ "cp{
Tqwvgt*eqphki/gzv/pcen+% "gpf"
```

The following example displays the hardware statistics for ACL racl1:

```
Tqwvgt%"ujqy"kr"ceeguu/nkuvu"tcen3
Gzvgpfgf"KR"ceeguu"nkuv"tcen3"
 jctfyctg"uvcvkuvkeu
 32"rgtokv"kr"jquv"32030303"jquv"4040404
cen"jy"jkv"eqwpv"7
 42"rgtokv"kr"jquv"5050505"jquv"6060606
cen"jy"jkv"eqwpv"42
 52"fgp{ "kr"cp{ "cp{
```

The hardware statistics for each ACE is seen after the **acl hw hit count** string and indicates the number of packets switched in hardware.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## Cisco TrustSec (CTS)

---

Cisco TrustSec is an umbrella term for security improvements to Cisco network devices based on the capability to strongly identify users, hosts and network devices within a network. TrustSec provides topology independent and scalable access controls by uniquely classifying data traffic for a particular role. TrustSec ensures data confidentiality and integrity by establishing trust among authenticated peers and encrypting links with those peers.

The key component of Cisco TrustSec is the [Cisco Identity Services Engine](#). It is typical for the Cisco ISE to provision switches with TrustSec Identities and Security Group ACLs (SGACLs), though these may be configured manually.

To configure Cisco Trustsec on the switch, see the publication, “*Cisco TrustSec Switch Configuration Guide*” at the following URL:

<http://www.cisco.com/en/US/docs/switches/lan/trustsec/configuration/guide/trustsec.html>

Release Notes for Cisco TrustSec General Availability releases are at the following URL:

[http://www.cisco.com/en/US/docs/switches/lan/trustsec/release/notes/rn\\_cts\\_crossplat.html](http://www.cisco.com/en/US/docs/switches/lan/trustsec/release/notes/rn_cts_crossplat.html)

Additional information on the Cisco TrustSec Solution, including overviews, datasheets, and case studies, is available at:

<http://www.cisco.com/en/US/netsol/ns1051/index.html>

[Table 1](#) lists the TrustSec features to be eventually implemented on TrustSec-enabled Cisco switches. Successive general availability releases of TrustSec will expand the number of switches supported and the number of TrustSec features supported per switch.

See the section, “[Hardware Supported](#)” for information on TrustSec features supported on switching modules.

**Table 1** Cisco TrustSec Key Features—TrustSec 1.0 General Availability 2010 Release

| Cisco TrustSec Feature                     | Description                                                                                                                                                                                                                                                                                                                                                                                                                              |
|--------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 802.1AE Tagging (MACSec)                   | <p>Protocol for IEEE 802.1AE-based wire-rate hop-to-hop layer 2 encryption.</p> <p>Between MACSec-capable devices, packets are encrypted on egress from the transmitting device, decrypted on ingress to the receiving device, and in the clear within the devices.</p> <p>This feature is only available between TrustSec hardware-capable devices.</p>                                                                                 |
| Endpoint Admission Control (EAC)           | <p>EAC is an authentication process for an endpoint user or a device connecting to the TrustSec domain. Usually EAC takes place at the access level switch. Successful authentication and authorization in the EAC process results in Security Group Tag assignment for the user or device. Currently EAC can be 802.1X, MAC Authentication Bypass (MAB), and Web Authentication Proxy (WebAuth).</p>                                    |
| Network Device Admission Control (NDAC)    | <p>NDAC is an authentication process where each network device in the TrustSec domain can verify the credentials and trustworthiness of its peer device. NDAC utilizes an authentication framework based on IEEE 802.1X port-based authentication and uses EAP-FAST as its EAP method. Successful authentication and authorization in NDAC process results in Security Association Protocol negotiation for IEEE 802.1AE encryption.</p> |
| Security Group Access Control List (SGACL) | <p>A Security Group Access Control List (SGACL) associates a Security Group Tag with a policy. The policy is enforced upon SGT-tagged traffic egressing the TrustSec domain.</p>                                                                                                                                                                                                                                                         |
| Security Association Protocol (SAP)        | <p>After NDAC authentication, the Security Association Protocol (SAP) automatically negotiates keys and the cipher suite for subsequent MACSec link encryption between TrustSec peers. SAP is defined in IEEE 802.11i.</p>                                                                                                                                                                                                               |
| Security Group Tag (SGT)                   | <p>An SGT is a 16-bit single label indicating the security classification of a source in the TrustSec domain. It is appended to an Ethernet frame or an IP packet.</p>                                                                                                                                                                                                                                                                   |
| SGT Exchange Protocol (SXP)                | <p>Security Group Tag Exchange Protocol (SXP). Devices that are not TrustSec-hardware capable can, with SXP, receive from the Cisco ACS, SGT attributes for authenticated users or devices then forward the sourceIP-to-SGT binding to a TrustSec-hardware capable device for tagging and SGACL enforcement.</p>                                                                                                                         |

## Flexible MACsec Replay Protection

Flexible MACsec replay protection feature provides flexible and configurable out-of-order mode replay protection window on CTS links. You can configure MACsec window size, as defined by the number of out-of-order frames that are accepted. This value is used while installing the security associations in the MACsec. A value of 0 means that frames are accepted only in the correct order.



**Note**

The MACsec replay protection window configuration change will come into affect during a shut/no-shut or link flap.

The *macsec replay-protection window-size* command would be visible on all CTS supported ports, however value range option would be restricted to <0-0> for non-supported cases.

To configure MACsec replay protection window size, perform this task:

|                                                                               |                                                                                                                                                |
|-------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| <i>switch1(config-if)# macsec<br/>replay-protection window-size<br/>value</i> | Enables replay protection, and configure the window size in number of frames. The range is from 0 to 4294967295. The default window size is 0. |
|-------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|

This example shows how to verify whether MACsec replay protection is supported on your switch:

```
uykvej3*eqphki/kh+% "oceuge"tgrnc{/rtqvgevkqp"ykpfaqy/uk|g"A
>^>2/64;6;894;7@"ykpfaqy"ku"vjg"pwodgt"qh"htcogu"*rcemgvu+
```

This example shows how to fis the MACsec replay protection window size:

```
uykvej3*eqphki/kh+% "oceuge"tgrnc{/rtqvgevkqp"ykpfaqy/uk|g"4222"*****"
Vgto3%uj"twppkpi/eqphki"kpvgthceg"v613
Dwknfkpi"eqphkiwtcvkqp000
#
kpvgthceg"VgpIkiCDkvGvjgtpgv613
"kr"cfftguu"6030303"4770477047702
"oceuge"tgrnc{/rtqvgevkqp"ykpfaqy/uk|g"4222
"evu"fqv3z
gpf
```

## Hardware Supported

Table 70-2 lists the level of Cisco TrustSec supported switching modules.

**Table 70-2** *Switching Module Support Levels for Cisco TrustSec*

| Cisco TrustSec Support Level                                                                                                                                                                                                                               | Description                                                                                                                                                                                                                                                                        | Line Card                                                                                                                                                                                                        |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Cisco TrustSec Capable<br><br><b>Note</b> Only the Security Association Protocol (SAP) for key negotiation in the CTS manual mode is supported on Cisco TrustSec Capable. | Supports full Cisco TrustSec capabilities with hardware acceleration for Security Group Tag imposition and IEEE 802.1AE MACsec                                                                                                                                                     | Supervisor Engine 6T, and all 6900 Series line cards                                                                                                                                                             |
| Cisco TrustSec Aware                                                                                                                                                                                                                                       | Does not support Security Group Tag imposition or IEEE 802.1AE MACsec. These line cards are capable of understanding forwarding decisions, which include the Security Group Tag information. This allows them to forward traffic to a Cisco TrustSec capable line card for egress. | <ul style="list-style-type: none"> <li>WS-X6816-10T-2T, WS-X6716-10T</li> <li>WS-X6816-10G-2T, WS-X6716-10GE</li> </ul>                                                                                          |
| Not Capable of Using Cisco TrustSec                                                                                                                                                                                                                        | Do not support Security Group Tag imposition or IEEE 802.1AE MACsec, nor can they interpret forwarding decisions with Security Group Tag information.                                                                                                                              | <ul style="list-style-type: none"> <li>WS-X6824-SFP-2T WS-X6724-SFP</li> <li>WS-X6848-SFP-2T WS-X6748-SFP</li> <li>WS-X6848-TX-2T WS-X6748-GE-TX</li> <li>WS-X6704-10G</li> <li>WS-X6148 series (all)</li> </ul> |

For all Cisco TrustSec hardware platform and feature support information, please see TrustSec Product Bulletins at the following URL:

<http://www.cisco.com/en/US/netsol/ns1051/index.html>



# AutoSecure

---

- [Prerequisites for AutoSecure, page 71-1](#)
- [Restrictions for AutoSecure, page 71-2](#)
- [Information About AutoSecure, page 71-2](#)
- [How to Configure AutoSecure, page 71-7](#)
- [Examples for AutoSecure Configuration, page 71-9](#)



## Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for AutoSecure

Be ready to answer these questions:

- Is the device going to be connected to the Internet?
- How many interfaces are connected to the Internet?
- What are the names of the interfaces connected to the Internet?
- What will be your local username and password?
- What will be the switch hostname and domain name?

## Restrictions for AutoSecure

- Because there is no command to undo configuration changes made by AutoSecure, always save your running configuration before configuring AutoSecure.
- The AutoSecure configuration can be configured at run time or setup time. If any related configuration is modified after AutoSecure has been enabled, the AutoSecure configuration may not be fully effective.
- After AutoSecure has been enabled, tools that use SNMP to monitor or configure a device will be unable to communicate with the device using SNMP.
- If your device is managed by a network management (NM) application, securing the management plane could turn off some services such as HTTP server and disrupt the NM application support.
- If you are using Security Device Manager (SDM), you must manually enable the HTTP server using the **ip http server** command.
- NM applications that use CDP to discover network topology will not be able to perform discovery.

## Information About AutoSecure

- [AutoSecure Overview, page 71-2](#)
- [Management Plane Security Enabled by AutoSecure, page 71-3](#)
- [Forwarding Plane Security Enabled by AutoSecure, page 71-6](#)

**Caution**

Although AutoSecure helps to secure a switch, it does not guarantee the complete security of the switch.

## AutoSecure Overview

- [AutoSecure Benefits, page 71-2](#)
- [Simplified Switch Security Configuration, page 71-3](#)
- [Enhanced Password Security Enabled by AutoSecure, page 71-3](#)
- [System Logging Message Support, page 71-3](#)

## AutoSecure Benefits

Use the AutoSecure feature to secure the switch without understanding all the security features. AutoSecure is a simple security configuration process that disables nonessential system services and enables a basic set of recommended security policies to ensure secure networking services.

## Simplified Switch Security Configuration

AutoSecure automates a thorough configuration of security features of the switch. AutoSecure disables certain features that are enabled by default that could be exploited for security holes. You can execute AutoSecure in either of two modes, depending on your individual needs:

- Interactive mode—Prompts with options to enable and disable services and other security features, suggesting a default setting for each option.
- Noninteractive mode—Automatically executes the recommended Cisco default settings.

## Enhanced Password Security Enabled by AutoSecure

- You can specify a required minimum password length, which can eliminate weak passwords that are prevalent on most networks, such as “lab” and “cisco.”

To configure a minimum password length, use the **security passwords min-length** command.

- You can cause a syslog message to be generated after the number of unsuccessful login attempts exceeds the configured threshold.

To configure the number of allowable unsuccessful login attempts (the threshold rate), use the **security authentication failure rate** command.

## System Logging Message Support

System logging messages capture any subsequent changes to the AutoSecure configuration that are applied on the running configuration. As a result, a more detailed audit trail is provided when AutoSecure is executed.

## Management Plane Security Enabled by AutoSecure

- [Management Plane Security Overview, page 71-3](#)
- [Global Services Disabled by AutoSecure, page 71-4](#)
- [Per-Interface Services Disabled by AutoSecure, page 71-4](#)
- [Global Services Enabled by AutoSecure, page 71-5](#)
- [Switch Access Secured by AutoSecure, page 71-5](#)
- [Logging Options Enabled by AutoSecure, page 71-6](#)



### Caution

If your device is managed by a network management (NM) application, securing the management plane could turn off some services such as the HTTP server and disrupt the NM application support.

## Management Plane Security Overview

AutoSecure provides protection for the switch management interfaces (the management plane) and the data routing and switching functions (the forwarding plane, described in the [“Forwarding Plane Security Enabled by AutoSecure” section on page 71-6.](#)) Securing the management plane is done by turning off certain global and interface services that can be potentially exploited for security attacks and turning on global services that help minimize the threat of attacks. Secure access and secure logging are also configured for the switch.

## Global Services Disabled by AutoSecure

- Finger—Collects information about the system (reconnaissance) before an attack.
- PAD—Enables all packet assembler and disassembler (PAD) commands and connections between PAD devices and access servers.
- Small servers—Causes TCP and User Datagram Protocol (UDP) diagnostic port attacks: a sender transmits a volume of fake requests for UDP diagnostic services on the switch, consuming all CPU resources.
- Bootp server—Bootp is an insecure protocol that can be exploited for an attack.
- HTTP server—Without secure-HTTP or authentication embedded in the HTTP server with an associated ACL, the HTTP server is insecure and can be exploited for an attack. (If you must enable the HTTP server, you will be prompted for the proper authentication or access list.)



**Note** If you are using Security Device Manager (SDM), you must manually enable the HTTP server using the **ip http server** command.

- Identification service—An unsecure protocol (defined in RFC 1413) that allows an external host to query a TCP port for identification. An attacker can access private information about the user from the ID server.
- CDP—If a large number of Cisco Discovery Protocol (CDP) packets are sent to the switch, the available memory of the switch can be consumed, which causes the switch to crash.



**Note** NM applications that use CDP to discover network topology will not be able to perform discovery.

- NTP—Without authentication or access control, Network Time Protocol (NTP) is insecure and can be used by an attacker to send NTP packets to crash or overload the switch.

If you require NTP, you must configure NTP authentication using Message Digest 5 (MD5) and the **ntp access-group** command. If NTP is enabled globally, disable it on all interfaces on which it is not needed.

- Source routing—Source routing is provided only for debugging purposes, and should be disabled in all other cases. Otherwise, packets may avoid some of the access control mechanisms of the switch.

## Per-Interface Services Disabled by AutoSecure

- ICMP redirects—Disabled on all interfaces. Does not add a useful functionality to a correctly configured network, but could be used by attackers to exploit security holes.
- ICMP unreachable—Disabled on all interfaces. Internet Control Management Protocol (ICMP) unreachable are a known method for some ICMP-based denial of service (DoS) attacks.
- ICMP mask reply messages—Disabled on all interfaces. ICMP mask reply messages can give an attacker the subnet mask for a particular subnetwork in the internetwork.
- Proxy-arp—Disabled on all interfaces. Proxy-arp requests are a known method for DoS attacks because the available bandwidth and resources of the switch can be consumed in an attempt to respond to the repeated requests sent by an attacker.
- Directed broadcast—Disabled on all interfaces. Potential cause of SMURF attacks for DoS.

- Maintenance Operations Protocol (MOP) service—Disabled on all interfaces.

## Global Services Enabled by AutoSecure

- The **service password-encryption** command—Prevents passwords from being visible in the configuration.
- The **service tcp-keepalives-in** and **service tcp-keepalives-out** commands—Ensures that abnormally terminated TCP sessions are removed.

## Switch Access Secured by AutoSecure



### Caution

If your device is managed by an NM application, securing access to the switch could turn off vital services and may disrupt the NM application support.

- If a text banner does not exist, you will be prompted to add a banner. This feature provides the following sample banner:  

```
CwvjqtK|gf"ceeguu"qpn{
 Vjku"u{uvgo"ku"vjg"rtqrgtv{"qh"CDE"Gpvgrtrtkug
 FkueqppgeV"KOOGFKCVGN["kh"{qw"ctg"pqv"cp"cwvjqtK|gf"wugt#
 Eqpvcev"cdeBgzcornq0eqo"-3"62:"7773434"hqt"jgnr0
```
- The login and password (preferably a secret password, if supported) are configured on the console, AUX, vty, and tty lines. The **transport input** and **transport output** commands are also configured on all of these lines. (Telnet and secure shell (SSH) are the only valid transport methods.) The **exec-timeout** command is configured on the console and AUX as 10.
- When the image on the device is a crypto image, AutoSecure enables SSH and secure copy (SCP) for access and file transfer to and from the switch. The **timeout seconds** and **authentication-retries integer** options for the **ip ssh** command are configured to a minimum number. (Telnet and FTP are not affected by this operation and remain operational.)
- If the user specifies that the switch does not use Simple Network Management Protocol (SNMP), one of the following functionalities will occur:
  - In interactive mode, the user is asked whether to disable SNMP regardless of the values of the community strings, which act like passwords to regulate access to the agent on the switch.
  - In noninteractive mode, SNMP will be disabled if the community string is public or private.



### Note

After AutoSecure has been enabled, tools that use SNMP to monitor or configure a device will be unable to communicate with the device using SNMP.

- If authentication, authorization, and accounting (AAA) is not configured, AutoSecure configures local AAA. AutoSecure will prompt the user to configure a local username and password on the switch.

## Logging Options Enabled by AutoSecure

- Sequence numbers and time stamps for all debug and log messages. This option is useful when auditing logging messages.
- Logging messages for login-related events. For example, the message “Blocking Period when Login Attack Detected” will be displayed when a login attack is detected and the switch enters quiet mode. (Quiet mode means that the switch will not allow any login attempts using Telnet, HTTP, or SSH.)
- The **logging console critical** command, which sends system logging (syslog) messages to all available TTY lines and limits messages based on severity.
- The **logging buffered** command, which copies logging messages to an internal buffer and limits messages logged to the buffer based on severity.
- The **logging trap debugging** command, which allows all commands with a severity higher than debugging to be sent to the logging server.

## Forwarding Plane Security Enabled by AutoSecure

- Strict Unicast Reverse Path Forwarding (uRPF) can be configured to help mitigate problems that are caused by the introduction of forged (spoofed) IP source addresses. uRPF discards IP packets that lack a verifiable IP source address.
- Hardware rate limiting—AutoSecure will enable hardware rate-limiting of the following types of traffic without prompting the user:
  - IP errors
  - RPF failures
  - ICMP no-route messages
  - ICMP acl-drop messages
  - IPv4 multicast FIB miss messages
  - IPv4 multicast partially switch flow messages

AutoSecure will provide the option for hardware rate-limiting of the following types of traffic:

- ICMP redirects
- TTL failures
- MTU failures
- IP unicast options
- IP multicast options
- Ingress and egress ACL bridged packets



**Note**

Rate-limiting of ingress and egress ACL bridged packets can interfere with ACL logging and can increase session setup rates for hardware accelerated features such as TCP intercept, NAT, and Layer 3 WCCP.



# How to Configure AutoSecure

- [Configuring AutoSecure Parameters, page 71-7](#)
- [Configuring Additional Security, page 71-8](#)
- [Verifying AutoSecure, page 71-8](#)

## Configuring AutoSecure Parameters

The **auto secure** command guides you through a semi-interactive session (also known as the AutoSecure session) to secure the management and forwarding planes. You can use this command to secure just the management plane or the forwarding plane; if neither option is selected in the command line, you can choose to configure one or both planes during the session.

This command also allows you to go through all noninteractive configuration portions of the session before the interactive portions. The noninteractive portions of the session can be enabled by selecting the optional **no-interact** keyword.

At any prompt you may enter a question mark (?) for help or Ctrl-C to abort the session.

In interactive mode, you will be asked at the end of the session whether to commit the generated configuration to the running configuration of the switch. In noninteractive mode, the changes will be automatically applied to the running configuration.



### Note

There is no undo command for configuration changes made by AutoSecure. You should always save the running configuration before executing the **auto secure** command.

To execute the AutoSecure configuration process, beginning in privileged EXEC mode, perform this task:

| Command                                                                                 | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-----------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqvwgt% "cwvq"ugewtg"] ocpcigogpv"~"hqtyctfkpi_"<br/>]pq/kpvgtccev"~"hwnn_</code> | <p>Executes the AutoSecure session for configuring one or both planes of the switch.</p> <ul style="list-style-type: none"> <li>• <b>management</b>—Only the management plane will be secured.</li> <li>• <b>forwarding</b>—Only the forwarding plane will be secured.</li> <li>• <b>no-interact</b>—The user will not be prompted for any interactive configurations.</li> <li>• <b>full</b>—The user will be prompted for all interactive questions. This is the default.</li> </ul> |

For an example of the AutoSecure session, see the [“Examples for AutoSecure Configuration”](#) section on page 71-9.

## Configuring Additional Security

After completing the AutoSecure configuration, you can further enhance the security of management access to your switch by performing this task:

|        | Command or Action                                                                                   | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                     |
|--------|-----------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt%eqphkiwtg"vgtokpcn"</code>                                                             | Enters global configuration mode.                                                                                                                                                                                                                                                                                                                                                                                           |
| Step 2 | <code>Tqwwgt*eqphki+%ugewtkv{"rcuuyqtf"okp/ngpivj"length</code>                                     | Ensures that all configured passwords are at least a specified length. <ul style="list-style-type: none"> <li><i>length</i>—Minimum length of a configured password. The range is 0 to 16 characters.</li> </ul>                                                                                                                                                                                                            |
| Step 3 | <code>Tqwwgt*eqphki+%gpcdng"rcuuyqtf"}rcuuyqtf"~"           <br/>]encryption-type_"password}</code> | Sets a local password to control access to various privilege levels. <ul style="list-style-type: none"> <li><i>encryption-type</i>—A value of 0 indicates that an unencrypted password follows. A value of 7 indicates that a hidden password follows.</li> </ul> <p><b>Note</b> You usually will not enter an encryption type unless you enter a password that has already been encrypted by a Cisco router or switch.</p> |
| Step 4 | <code>Tqwwgt*eqphki+%ugewtkv{"cwvjgpkvkecvkqp"hcknwtg"tcvg"threshold-rate nqi</code>                | Configures the number of allowable unsuccessful login attempts. <ul style="list-style-type: none"> <li><i>threshold-rate</i>—Number of allowable unsuccessful login attempts. The range is 1 to 1024.</li> <li><b>log</b>—Syslog authentication failures if the number of failures in one minute exceeds the threshold.</li> </ul>                                                                                          |

The following example shows how to configure the switch for a minimum password length of 10 characters and a threshold of 3 password failures in one minute. The example also shows how to set a hidden local password.

```
Tqwwgt%eqphkiwtg"vgtokpcn
Tqwwgt*eqphki+%ugewtkv{"rcuuyqtf"okp/ngpivj"32
Tqwwgt*eqphki+%ugewtkv{"cwvjgpkvkecvkqp"hcknwtg"tcvg"5
Tqwwgt*eqphki+%gpcdng"rcuuyqtf"9"gngrjcpv345
```

## Verifying AutoSecure

To verify that the AutoSecure feature has executed successfully, perform this task:

| Command                                      | Purpose                                                                                                                                                        |
|----------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwwgt%"ujqy"cwvg"ugewtg"eqphki</code> | Displays all configuration commands that have been added as part of the AutoSecure configuration. The output is the same as the configuration generated output |



```

"Vjku"u{uvgo"ku"vjg"rtqrgtv{"qh">Pcog"qh"Gpvgtrtkug@0
"WPCWVJQTK\GF"CEEGUU"VQ"VJKU"FGXKEG"KU"RTQJKDKVGF0
" [qw"owuv"jcxg"gzrnkekv"rgtokuukqp"vq"ceeguu"vjku
"fgxkeg0"Cnn"cevkxkvkgu"rgthqtogf"qp"vjku"fgxkeg
"ctg"nqiigf0"Cp{"xkqncvkgpu"qh"ceeguu"rqnke{"yknn"tguwnv
"kp"fkuernkpcpct{"cevkqp0

Gpvg"vjg"ugewtkv{"dcpvg"Rwv"vjg"dcpvg"dgvyggp
m"cpf"m."yjgtg"m"ku"cp{"ejctcevg"i<
m
dcpvg" " " " "
m
Gpvg"vjg"pgy"gpdcng"ugetgv<"
Eqphkto"vjg"gpdcng"ugetgv"<"
Gpdcng"rcuuyqtf"ku"pqv"eqphkiwtgf"qt"kvu"ngpivj
ku"nguu"vjcp"okpkowo"pq0"qh"ejctcevgtueqphkiwtgf
Gpvg"vjg"pgy"gpdcng"rcuuyqtf<"
Eqphkto"vjg"gpdcng"rcuuyqtf<"

Eqphkiwtcvkqp"qh"nqecn"wugt"fcvdcug
Gpvg"vjg"wugtpcog<"ekueq
Gpvg"vjg"rcuuyqtf<"
Eqphkto"vjg"rcuuyqtf<"
Eqphkiwtkpi"CCC"nqecn"cwvjgpkcvkqp
Eqphkiwtkpi"Eqpuqng"."Cwz"cpf"XV["nkpgu"hqt
nqecn"cwvjgpkcvkqp"."gzge/vkogqvw"."cpf"vtcpurqtv
Ugewtkpi"fgxkeg"ckcpuv"Nqikp"Cvvcemu
Eqphkiwtg"vjg"hqnnqykpi"rtcogvgtu

Dnqemkpi"Rgtkqf"yjgp"Nqikp"Cvvcem"fgvgevfg"*kp"ugeqpfu+<"7

Oczkwo"Nqikp"hcknwtgu"ykvj"vjg"fgxkeg<"5

Oczkwo"vkog"rgtkqf"hqt"etquukpi"vjg"hckngf"nqikp"cvvgorvu"*kp"ugeqpfu+<"A
' "C"fgekocn"pwodgt"dgvyggp"3"cpf"549890

Oczkwo"vkog"rgtkqf"hqt"etquukpi"vjg"hckngf"nqikp"cvvgorvu"*kp"ugeqpfu+<"7

Eqphkiwtg"UUJ"ugtsgtA"]{gu_<"pq

Eqphkiwtkpi"kpvgthceg"urkehke"CwvqUgewtg"ugtскеgu
Fkucdnkpi"oqr"qp"Gvjgtpgv"kpvgthcegu

Ugewtkpi"Hqtyctfkpi"rncpg"ugtскеgu000

Gpdcnkpi"wpkecuv"trh"qp"cnn"kpvgthcegu"eqppgevfg
vq"kpvgtpgv

Vjg"hqnnqykpi"tcvg/nkokvgtu"ctg"gpdcngf"d{"fghcwnv<
" "000

Yqwnf{"qw"nkmg"vq"gpdcng"vjg"hqnnqykpi"tcvg/nkokvgtu"cnua
000

Gpdcng"vjg"cdqsg"tcvg/nkokvgtu"cnua"]{gulpq_<"{gu

Yqwnf{"qw"nkmg"vq"gpdcng"vjg"tcvg/nkokvgtu"hqt"KpitguulGitguuCEN"dtkfigf"rcemgvu"cnua
PQVG<"Gpdcnkpi"vjg"CEN"kp1qvw"tcvg/nkokvgtu"ecp"chhgev"CEN"nqiikpi
" " " " "cpf"uguukqp"ugvwr"tcvg"hqt"jctfyctg"ceegngtcvgf"hgcvwtgu"uwej
" " " " "cu"PCV."Nc{gt"5"YEER"cpf"VER"Kpvgtegrv
000

Gpdcng"vjg"CEN"kp1qvw"tcvg/nkokvgtu"cnua"]{gulpq_<"pq

```

```

Vjku"ku"vjg"eqphkiwtcvkqp"igpgtcvgf<

pq"ugtxkeg"hkpigt
pq"ugtxkeg"rcf
pq"ugtxkeg"wfr/uocnn/ugtxgtu
pq"ugtxkeg"ver/uocnn/ugtxgtu
ugtxkeg"rcuuyqtf/gpet{rvkqp
ugtxkeg"ver/mggrcnkxgu/kp
ugtxkeg"ver/mggrcnkxgu/qwv
pq"efr"twp
pq"kr"dqqvr"ugtxgt
pq"kr"jvvr"ugtxgt
pq"kr"hkpigt
pq"kr"uqwtg/tqwg
pq"kr"itcvkwvqwu/ctru
pq"kr"kfgpvf
dcppt "m
dcppt
m
ugewtkv{"rcuuyqtfu"okp/ngpivj"8
ugewtkv{"cwvjgpkvkecvkqp"hcknwtg"tcvg"32"nqi
gpcdng"ugetgv"7"&3&52mR&h0MFpf[R|1Jx10{VnLUvP1
gpcdng"rcuuyqtf"9"2:426G6F2F6:796668
wugtpcog"ekueq"rcuuyqtf"9"2:426G6F2F6:796668
ccc"pgy/oqfgn
ccc"cwvjgpkvkecvkqp"nqikp"nqecnacwvj"nqecn
nkpg"egpuqng"2
"nqikp"cwvjgpkvkecvkqp"nqecnacwvj
"gzge/vkogqvw"7"2
"vtcpurqtv"qvwrv"vgnpgv
nkpg"xv{"2"37
"nqikp"cwvjgpkvkecvkqp"nqecnacwvj
"vtcpurqtv"kprrv"vgnpgv
nqikp"dnqem/hqt"7"cvvgorvu"5"ykvj"kp"7
ugtxkeg"vkoguvcoru"fgdwi"fcvgvkog"ouge"nqecnvkog"ujqy/vkog|qpg
ugtxkeg"vkoguvcoru"nqi"fcvgvkog"ouge"nqecnvkog"ujqy/vkog|qpg
nqiikpi"hceknkv{"nqecn4
nqiikpi"vtcr"fgdwiikpi
ugtxkeg"ugswgpeg/pwodgtu
nqiikpi"egpuqng"etkvkecn
nqiikpi"dwhhgtgf
kpv"Xncp3
"pq"kr"tgfktgevu
"pq"kr"rtqz{/ctr
"pq"kr"wptgcejcdngu
"pq"kr"fktgevgf/dtqcfecev
"pq"kr"ocum/tgrn{
"pq"okr"gpdcngf
kpv"Xncp99
"pq"kr"tgfktgevu
"pq"kr"rtqz{/ctr
"pq"kr"wptgcejcdngu
"pq"kr"fktgevgf/dtqcfecev
"pq"kr"ocum/tgrn{
"pq"okr"gpdcngf
kpv"IkicdkvGvjgtpgv813
"pq"kr"tgfktgevu
"pq"kr"rtqz{/ctr
"pq"kr"wptgcejcdngu
"pq"kr"fktgevgf/dtqcfecev
"pq"kr"ocum/tgrn{
"pq"okr"gpdcngf
kpv"IkicdkvGvjgtpgv814
"pq"kr"tgfktgevu

```

```

"pq"kr"rtqz{/ctr
"pq"kr"wptgcejcdngu
"pq"kr"fktgevgf/dtqcfecuv
"pq"kr"ocum/tgrn{
"pq"ogr"gcdngf
kpvgtgceg"Xncp99
"kr"xgtkh{"wpkecuv"uqwteg"tgcejcdng/xkc"tz
000
#
gpf

Crrn{"vjku"eqphkiwtcvkqp"vq"twppkpi/eqphkiA"]{gu_<"{gu
Crrn{kpi"vjg"eqphki"igpgtcvgf"vq"twppkpi/eqphki
Tqvwgt%

```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

Participate in the Technical Documentation Ideas forum



## MAC Address-Based Traffic Blocking



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.

To block all traffic to or from a MAC address in a specified VLAN, perform this task:

| Command                                                                                  | Purpose                                                                         |
|------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------|
| <pre>Tqvwgt*eqphki+% "oce"cfftgau/vcdng"uvcvke"oceacfftgau"<br/>xnep"vlan_ID"ftqr"</pre> | Blocks all traffic to or from the configured MAC address in the specified VLAN. |

This example shows how to block all traffic to or from MAC address 0050.3e8d.6400 in VLAN 12:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+% "oce"cfftgau/vcdng"uvcvke"227205g:f08622"xnep"34"ftqr"
```



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)







## Port ACLs (PACLs)

---

- [Prerequisites for PACLs, page 73-1](#)
- [Restrictions for PACLs, page 73-2](#)
- [Information About PACLs, page 73-2](#)
- [How to Configure PACLs, page 73-7](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- Port ACLs do not support the access-list keywords **log** or **reflexive**. These keywords in the access list are ignored. OAL does not support PACLs.
- PACLs are not supported on private VLANs.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for PACLs

None.

## Restrictions for PACLS

- There can be at most one IP access list and one MAC access list applied to the same Layer 2 interface per direction.
- PACLS are not applied to MPLS or ARP messages.
- An IP access list filters only IPv4 and IPv6 packets. For IP access lists, you can define a standard, extended, or named access-list.
- A MAC access list filters ingress packets that are of an unsupported type (not IP, ARP, or MPLS packets) based on the fields of the Ethernet datagram. A MAC access list is not applied to IP, MPLS, or ARP messages. You can define only named MAC access lists.
- The number of ACLs and ACEs that can be configured as part of a PACL are bounded by the hardware resources on the switch. Those hardware resources are shared by various ACL features (such as VACLs) that are configured on the system. If there are insufficient hardware resources to program a PACL in hardware, the PACL is not applied.
- PACL does not support the access-list **log** and **reflect/evaluate** keywords. These keywords are ignored if you add them to the access list for a PACL.
- OAL does not support PACLS.
- The access group mode can change the way PACLS interact with other ACLs. To maintain consistent behavior across Cisco platforms, use the default access group mode (merge mode).
- PACLS cannot filter Physical Link Protocols and Logical Link Protocols, such as CDP, VTP, DTP, PAgP, UDLD, and STP, because the protocols are redirected to the RP before the ACL takes effect. You can apply CoPP or QoS to Physical Link Protocol and Logical Link Protocol traffic.

## Information About PACLS

- [PACL Overview, page 73-2](#)
- [EtherChannel and PACL Interactions, page 73-3](#)
- [Dynamic ACLs \(Applies to Merge Mode Only\), page 73-4](#)
- [Trunk Ports, page 73-4](#)
- [Layer 2 to Layer 3 Port Conversion, page 73-4](#)
- [Port-VLAN Association Changes, page 73-4](#)

## PACL Overview

PACLs filter incoming traffic on Layer 2 interfaces, using Layer 3 information, Layer 4 header information, or non-IP Layer 2 information.

The PACL feature uses standard or extended IP ACLs or named MAC-extended ACLs that you want to apply to the port.

Port ACLs perform access control on all traffic entering the specified Layer 2 port.

PACLs and VACLs can provide access control based on the Layer 3 addresses (for IP protocols) or Layer 2 MAC addresses (for non-IP protocols).

The port ACL (PACL) feature provides the ability to perform access control on specific Layer 2 ports. A Layer 2 port is a physical LAN or trunk port that belongs to a VLAN. Port ACLs are applied only on the ingress traffic. The port ACL feature is supported only in hardware (port ACLs are not applied to any packets routed in software).

When you create a port ACL, an entry is created in the ACL TCAM. You can use the **show team counts** command to see how much TCAM space is available.

The PACL feature does not affect Layer 2 control packets received on the port.

You can use the **access-group mode** command to change the way that PACLs interact with other ACLs.

PACLs use the following modes:

- Prefer port mode—If a PACL is configured on a Layer 2 interface, the PACL takes effect and overwrites the effect of other ACLs (Cisco IOS ACL and VACL). If no PACL feature is configured on the Layer 2 interface, other features applicable to the interface are merged and are applied on the interface.
- Merge mode—In this mode, the PACL, VACL, and Cisco IOS ACLs are merged in the ingress direction following the logical serial model shown in [Figure 73-2](#). This is the default access group mode.

You configure the **access-group mode** command on each interface. The default is merge mode.

**Note**

A PACL can be configured on a trunk port only after prefer port mode has been selected. Trunk ports do not support merge mode.

To illustrate access group mode, assume a physical port belongs to VLAN100, and the following ACLs are configured:

- Cisco IOS ACL R1 is applied on routed interface VLAN100.
- VACL (VLAN filter) V1 is applied on VLAN100.
- PACL P1 is applied on the physical port.

In this situation, the following ACL interactions occur:

- In prefer port mode, Cisco IOS ACL R1 and VACL V1 are ignored.
- In merge mode, Cisco IOS ACL R1, VACL V1 and PACL P1 are merged and applied on the port.

**Note**

The CLI syntax for creating a PACL is identical to the syntax for creating a Cisco IOS ACL. An instance of an ACL that is mapped to a Layer 2 port is called a PACL. An instance of an ACL that is mapped to a Layer 3 interface is called a Cisco IOS ACL. The same ACL can be mapped to both a Layer 2 port and a Layer 3 interface.

The PACL feature supports MAC ACLs, IPv4, and IPv6 ACLs. The PACL feature does not support ACLs for ARP or Multiprotocol Label Switching (MPLS) traffic.

## EtherChannel and PACL Interactions

This section describes the guidelines for the EtherChannel and PACL interactions:

- PACLs are supported on the main Layer 2 channel interface but not on the port members. A port that has a PACL configured on it may not be configured as an EtherChannel member port. The EtherChannel configuration commands are unavailable on ports that are configured with a PACL.

- Changing the configuration on the logical port affects all the ports in the channel. When an ACL is mapped to the logical port belonging to a channel, it is mapped to all ports in the channel.

## Dynamic ACLs (Applies to Merge Mode Only)

Dynamic ACLs are VLAN-based and are used by two features: CBAC and GWIP. The merge mode *does not* support the merging of the dynamic ACLs with the PACLs. In merge mode, the following configurations are not allowed:

- Attempting to apply a PACL on a port where its corresponding VLAN has a dynamic ACL mapped. In this case, the PACL is not applied to traffic on the port.
- Configuring a dynamic ACL on a VLAN where one of its constituent ports has a PACL installed. In this case, the dynamic ACL is not applied.

## Trunk Ports

To configure a PACL on a trunk port, you must first configure port prefer mode. The configuration commands to apply a PACL on a trunk or dynamic port will not be available until you configure the port in port prefer mode by entering the **access-group mode prefer port** interface command. Trunk ports do not support merge mode.

## Layer 2 to Layer 3 Port Conversion

If you reconfigure a port from Layer 2 to Layer 3, any PACL configured on the port becomes inactive but remains in the configuration. If you subsequently configure the port as Layer 2, any PACL configured on the port becomes active again.

## Port-VLAN Association Changes

You can enter port configuration commands that alter the port-VLAN association, which triggers an ACL remerge.

Unmapping and then mapping a PACL, VACL, or Cisco IOS ACL automatically triggers a remerge.

In merge mode, online insertion or removal of a switching module also triggers a remerge, if ports on the module have PACLs configured.

## PACL and VACL Interactions

- [PACL Interaction with VACLs and Cisco IOS ACLs, page 73-5](#)
- [Bridged Packets, page 73-5](#)
- [Routed Packets, page 73-5](#)
- [Multicast Packets, page 73-6](#)

## PACL Interaction with VACLs and Cisco IOS ACLs

This section describes the guidelines for the PACL interaction with the VACLs and Cisco IOS ACLs.

For an incoming packet on a physical port, the PACL is applied first. If the packet is permitted by the PACL, the VACL on the ingress VLAN is applied next. If the packet is Layer 3 forwarded and is permitted by the VACL, it is filtered by the Cisco IOS ACL on the same VLAN. The same process happens in reverse in the egress direction. However, there is currently no hardware support for output PACLs.

The PACLs override both the VACLs and Cisco IOS ACLs when the port is configured in prefer port mode. The one exception to this rule is when the packets are forwarded in the software by the route processor (RP). The RP applies the ingress Cisco IOS ACL regardless of the PACL mode. Two examples where the packets are forwarded in the software are as follows:


- Packets that are egress bridged (due to logging or features such as NAT)
- Packets with IP options

## Bridged Packets

Figure 73-1 shows a PACL and a VACL applied to bridged packets. In merge mode, the ACLs are applied in the following order:

1. PACL for the ingress port
2. VACL for the ingress VLAN
3. VACL for the egress VLAN

**Figure 73-1** Applying ACLs on Bridged Packets



In prefer port mode, only the PACL is applied to the ingress packets (the input VACL is not applied).


## Routed Packets

Figure 73-2 shows how ACLs are applied on routed and Layer 3-switched packets. In merge mode, the ACLs are applied in the following order:

1. PACL for the ingress port
2. VACL for the ingress VLAN
3. Input Cisco IOS ACL
4. Output Cisco IOS ACL
5. VACL for the egress VLAN

In prefer port mode, only the PACL is applied to the ingress packets (the input VACL and Cisco IOS ACL are not applied).

**Figure 73-2** Applying ACLs on Routed Packets




## Multicast Packets

Figure 73-3 shows how ACLs are applied on packets that need multicast expansion. For packets that need multicast expansion, the ACLs are applied in the following order:

1. Packets that need multicast expansion:
  - a. PACL for the ingress port
  - b. VACL for the ingress VLAN
  - c. Input Cisco IOS ACL
2. Packets after multicast expansion:
  - a. Output Cisco IOS ACL
  - b. VACL for the egress VLAN
3. Packets originating from router:
  - a. Output Cisco IOS ACL
  - b. VACL for the egress VLAN

In prefer port mode, only the PACL is applied to the ingress packets (the input VACL and Cisco IOS ACL are not applied).

Figure 73-3 Applying ACLs on Multicast Packets



## How to Configure PACLS

- [Configuring IP and MAC ACLs on a Layer 2 Interface, page 73-7](#)
- [Configuring Access-group Mode on Layer 2 Interface, page 73-8](#)
- [Applying ACLs to a Layer 2 Interface, page 73-8](#)
- [Applying ACLs to a Port Channel, page 73-9](#)
- [Displaying an ACL Configuration on a Layer 2 Interface, page 73-9](#)

## Configuring IP and MAC ACLs on a Layer 2 Interface

IP and MAC ACLs can be applied to Layer 2 physical interfaces. Standard (numbered, named) and Extended (numbered, named) IP ACLs, and Extended Named MAC ACLs are supported.

To apply IP or MAC ACLs on a Layer 2 interface, perform this task:

|        | Command                                                                                       | Purpose                                                   |
|--------|-----------------------------------------------------------------------------------------------|-----------------------------------------------------------|
| Step 1 | <code>Uykvej% "eqphkiwtg" vgtokpcn</code>                                                     | Enters global configuration mode.                         |
| Step 2 | <code>Uykvej*eqphki+% "kpvgtthceg" kpvgtthceg</code>                                          | Enters interface configuration mode for a Layer 2 port.   |
| Step 3 | <code>Uykvej*eqphki/kh+% "kr" ~ "oce" ; "ceeguu/itqwr" }pcog ~ "pwodgt" ~ "kp" ~ "qvv"</code> | Applies a numbered or named ACL to the Layer 2 interface. |
| Step 4 | <code>Uykvej*eqphki+% "ujqy" twppkpi/eqphki</code>                                            | Displays the access list configuration.                   |

This example shows how to configure the Extended Named IP ACL simple-ip-acl to permit all TCP traffic and implicitly deny all other IP traffic:

```
Uykvej*eqphki+%"kr"ceeguu/nkuv"gzvgpfgf"ukornng/kr/cen"
Uykvej*eqphki/gzv/pcen+%"rgtokv"ver"cp{"cp{"
Uykvej*eqphki/gzv/pcen+%"gpf"
```

This example shows how to configure the Extended Named MAC ACL simple-mac-acl to permit source host 000.000.011 to any destination host:

```
Uykvej*eqphki+%"oce"ceeguu/nkuv"gzvgpfgf"ukornng/oce/cen"
Uykvej*eqphki/gzv/ocen+%"rgtokv"jquv"22202220233"cp{"
Uykvej*eqphki/gzv/ocen+%"gpf"
```

## Configuring Access-group Mode on Layer 2 Interface

To configure the access mode on a Layer 2 interface, perform this task:

|        | Command                                                                            | Purpose                                                                                                             |
|--------|------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
| Step 1 | Uykvej% <b>"eqphkiwtg"vgtokpcn</b>                                                 | Enters global configuration mode.                                                                                   |
| Step 2 | Uykvej*eqphki+% <b>"kpvgtthceg"interface</b>                                       | Enters interface configuration mode for a Layer 2 port.                                                             |
| Step 3 | Uykvej*eqphki/kh+% <b>]pq_ "ceeguu/itqwr"oqfg"</b><br><b>}rtghgt rgtv"~"ogtig;</b> | Sets the mode for this Layer 2 interface. The <b>no</b> prefix sets the mode to the default value (which is merge). |
| Step 4 | Uykvej*eqphki+% <b>"ujqy"twppkpi/eqphki</b>                                        | Displays the access list configuration.                                                                             |

This example shows how to configure an interface to use prefer port mode:

```
Uykvej%"eqphkiwtg"vgtokpcn
Uykvej*eqphki+%"kpvgtthceg"ikicdkvGvjgtpgv"813
Uykvej*eqphki/kh+%"ceeguu/itqwr"oqfg"rtghgt"rgtv"
```

This example shows how to configure an interface to use merge mode:

```
Uykvej%"eqphkiwtg"vgtokpcn
Uykvej*eqphki+%"kpvgtthceg"ikicdkvGvjgtpgv"813
Uykvej*eqphki/kh+%"ceeguu/itqwr"oqfg"ogtig"
```

## Applying ACLs to a Layer 2 Interface

To apply IP and MAC ACLs to a Layer 2 interface, perform one of these tasks:

| Command                                                 | Purpose                                     |
|---------------------------------------------------------|---------------------------------------------|
| Uykvej*eqphki/kh+% <b>"kr"ceeguu/itqwr"ip-acl"kp"</b>   | Applies an IP ACL to the Layer 2 interface. |
| Uykvej*eqphki/kh+% <b>"oce"ceeguu/itqwr"mac-acl"kp"</b> | Applies a MAC ACL to the Layer 2 interface. |

This example applies the extended named IP ACL simple-ip-acl to interface GigabitEthernet 6/1 ingress traffic:

```
Uykvej%"eqphkiwtg"v
Uykvej*eqphki+%"kpvgtthceg"ikicdkvGvjgtpgv"813
Uykvej*eqphki/kh+%"kr"ceeguu/itqwr"ukornng/kr/cen"kp"
```



This example applies the extended named MAC ACL simple-mac-acl to interface GigabitEthernet 6/1 ingress traffic:

```
Uykvej%eqphkiwtg"v
Uykvej*eqphki+%kpvgtthceg"ikicdkvGvjgtpgv"813
Uykvej*eqphki/kh+%oce"ceeguu/itqwr"ukorng/oc/cen"kp
```

## Applying ACLs to a Port Channel

To apply IP and MAC ACLs to a port channel logical interface, perform this task:

| Command                                              | Purpose                                          |
|------------------------------------------------------|--------------------------------------------------|
| Uykvej*eqphki/kh+%kpvgtthceg"rqtv/ejcppgn"number     | Enters configuration mode for the port channel.  |
| Uykvej*eqphki/kh+%kr"ceeguu/itqwr"ip-acl"kp"~"qvw;   | Applies an IP ACL to the port channel interface. |
| Uykvej*eqphki/kh+%oce"ceeguu/itqwr"mac-acl"kp"~"qvw; | Applies a MAC ACL to the port channel interface. |

This example applies the extended named IP ACL simple-ip-acl to port channel 3 ingress traffic:

```
Uykvej%eqphkiwtg"v
Uykvej*eqphki+%kpvgtthceg"rqtv/ejcppgn"5
Uykvej*eqphki/kh+%kr"ceeguu/itqwr"ukorng/kr/cen"kp
```

## Displaying an ACL Configuration on a Layer 2 Interface

To display information about an ACL configuration on Layer 2 interfaces, perform one of these tasks:

| Command                                                    | Purpose                                                     |
|------------------------------------------------------------|-------------------------------------------------------------|
| Uykvej%"ujqy"kr"ceeguu/nkuvu"]kpvgtthceg"interface-name_   | Shows the IP access group configuration on the interface.   |
| Uykvej%"ujqy"oce"ceeguu/itqwr"]kpvgtthceg"interface-name_  | Shows the MAC access group configuration on the interface.  |
| Uykvej%"ujqy"ceeguu/itqwr"oqfg"]kpvgtthceg"interface-name_ | Shows the access group mode configuration on the interface. |

This example shows that the IP access group simple-ip-acl is configured on the inbound direction of interface fa6/1:

```
Uykvej%"ujqy"kr"kpvgtthceg"ikicdkvgvjgtpgv"813
IkicdkvGvjgtpgv813"ku"wr."nkpq"rtqvqeqn"ku"wr
""Kpdqwpf""ceeguu"nkuv"ku"ukorng/kr/cen
""Qwviqkpi"ceeguu"nkuv"ku"pqv"ugv
```

This example shows that MAC access group simple-mac-acl is configured on the inbound direction of interface Gigabit Ethernet 6/1:

```
Uykvej%"ujqy"oce"ceeguu/itqwr"kpvgtthceg"ikicdkvgvjgtpgv"813
Kpvgtthceg"IkicdkvGvjgtpgv813<
""Kpdqwpf""ceeguu"nkuv"ku"ukorng/oc/cen""
""Qwvdqwpf""ceeguu"nkuv"ku"pqv"ugv
```

This example shows that access group merge is configured on interface Gigabit Ethernet 6/1:

```
Uykvej%"ujqy"ceeguu/itqwr"oqfg"kpvgthceg"ikicdkvgvjgtpgv"813
Kpvgthceg"IkicdkvGvjgtpgv813<
""Ceeguu"itqwr"oqfg"ku<"ogtig
```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## VLAN ACLs (VACLs)

---

- [Prerequisites for VACLs, page 74-1](#)
- [Restrictions for VACLs, page 74-2](#)
- [Information About VACLs, page 74-2](#)
- [How to Configure VACLs, page 74-3](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- Optimized ACL logging (OAL) and VACL capture are incompatible. Do not configure both features on the switch. With OAL configured (see the [“Optimized ACL Logging” section on page 69-15](#)), use SPAN to capture traffic.
- Also see the [“PACL Interaction with VACLs and Cisco IOS ACLs” section on page 73-5](#).



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for VACLs

None.

## Restrictions for VACLs

- VACLs use standard and extended Cisco IOS IP and MAC layer-named ACLs (see [“MAC ACLs” section on page 69-11](#)) and VLAN access maps.
- IGMP packets are not checked against VACLs.
- VLAN access maps can be applied to VLANs for VACL capture.
- Each VLAN access map can consist of one or more map sequences; each sequence has a match clause and an action clause. The match clause specifies IP or MAC ACLs for traffic filtering and the action clause specifies the action to be taken when a match occurs. When a flow matches a permit ACL entry, the associated action is taken and the flow is not checked against the remaining sequences. When a flow matches a deny ACL entry, it will be checked against the next ACL in the same sequence or the next sequence. If a flow does not match any ACL entry and at least one ACL is configured for that packet type, the packet is denied.
- To apply access control to both bridged and routed traffic, you can use VACLs alone or a combination of VACLs and ACLs. You can define ACLs on the VLAN interfaces to apply access control to both the ingress and egress routed traffic. You can define a VACL to apply access control to the bridged traffic.
- The following caveats apply to ACLs when used with VACLs:
  - Packets that require logging on the outbound ACLs are not logged if they are denied by a VACL.
  - VACLs are applied on packets before NAT translation. If the translated flow is not subject to access control, the flow might be subject to access control after the translation because of the VACL configuration.
- VACLs check for conflicts with other features using capture like OAL, Lawful Intercept (LI), and IPv6 learning.
- When VACL capture is configured with Policy Based Routing (PBR) on the same interface, do not select BDD as the ACL merge algorithm.
- When VACL capture is configured on an egress interface together with another egress feature that requires software processing of the traffic, packets of the overlapping traffic may be captured twice.
- The action clause in a VACL can be forward, drop, capture, or redirect. Traffic can also be logged.

**Note**

- VACLs have an implicit deny at the end of the map; a packet is denied if it does not match any ACL entry, and at least one ACL is configured for the packet type.
- If an empty or undefined ACL is specified in a VACL, any packets will match the ACL, and the associated action is taken.

## Information About VACLs

VLAN ACLs (VACLs) can provide access control for all packets that are bridged within a VLAN or that are routed into or out of a VLAN for VACL capture. Unlike Cisco IOS ACLs that are applied on routed packets only, VACLs apply to all packets and can be applied to any VLAN. VACLs are processed in the ACL TCAM hardware. VACLs ignore any Cisco IOS ACL fields that are not supported in hardware.

You can configure VACLs for IP and MAC-layer traffic.

If a VACL is configured for a packet type, and a packet of that type does not match the VACL, the default action is to deny the packet.

Packets can either enter the VLAN through a Layer 2 port or through a Layer 3 port after being routed. You can also use VACLs to filter traffic between devices in the same VLAN.

Starting with the Cisco IOS 15.4SY1 release, the rate-limiter for VACL capture will no longer be disabled by default. The VACL CAP2 rate-limit will be enabled with a default value of 200 pps. Use the **platform feature-manager capture rate-limit** command to change the value of the capture rate-limit or to disable the VACL CAP2 rate-limiter. Any modification to the default rate-limit using the **platform feature-manager capture rate-limit** command will cause the new CAP2 rate-limit value to take effect. CAP2 rate-limit can be disabled using the **no platform feature-manager capture rate-limit** command. The Nonvolatile Generation (NVGEN) process is invoked upon running the **platform feature-manager capture rate-limit** and **no platform feature-manager capture rate-limit** commands. The CAP2 rate-limit value can be reverted to the default value using the default version of the command.

## How to Configure VACLs

- [Defining a VLAN Access Map, page 74-3](#)
- [Configuring a Match Clause in a VLAN Access Map Sequence, page 74-4](#)
- [Configuring an Action Clause in a VLAN Access Map Sequence, page 74-4](#)
- [Applying a VLAN Access Map, page 74-5](#)
- [Verifying VLAN Access Map Configuration, page 74-5](#)
- [VLAN Access Map Configuration and Verification Examples, page 74-5](#)
- [Configuring a Capture Port, page 74-6](#)
- [Configuring VACL Logging, page 74-7](#)

### Defining a VLAN Access Map

To define a VLAN access map, perform this task:

| Command                                                               | Purpose                                                                                       |
|-----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|
| <code>Tqwwgt*eqphki+%<b>xncp</b>"ceeguu/ocr"ocrapcog"]2/87757_</code> | Defines the VLAN access map. Optionally, you can specify the VLAN access map sequence number. |

- To insert or modify an entry, specify the map sequence number.
- If you do not specify the map sequence number, a number is automatically assigned.
- You can specify only one match clause and one action clause per map sequence.
- Use the **no** keyword with a sequence number to remove a map sequence.
- Use the **no** keyword without a sequence number to remove the map.

See the “[VLAN Access Map Configuration and Verification Examples](#)” section on [page 74-5](#).

## Configuring a Match Clause in a VLAN Access Map Sequence

To configure a match clause in a VLAN access map sequence, perform this task:

| Command                                                                                                                           | Purpose                                                    |
|-----------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------|
| <code>Tqwwgt*eqphki/ceeguu/ocr+%"ocvej"}]kr ~ krx8 "cfftguu"<br/>}3/3;;;"~"3522/48;;;"~"cenapcog;"~"}oce cfftguu cenapcog;</code> | Configures the match clause in a VLAN access map sequence. |

- Release 15.0(1)SY1 and later releases support IPv6 ACLs.
- You can select one or more ACLs.
- Use the **no** keyword to remove a match clause or specified ACLs in the clause.
- For information about named MAC-Layer ACLs, see [“MAC ACLs” section on page 69-11](#).
- For information about Cisco IOS ACLs, see [Chapter 69, “Cisco IOS ACL Support”](#) and the [“VLAN Access Map Configuration and Verification Examples” section on page 74-5](#).

## Configuring an Action Clause in a VLAN Access Map Sequence

To configure an action clause in a VLAN access map sequence, perform this task:

| Command                                                                                                                                                                                                                    | Purpose                                                     |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------|
| <code>Tqwwgt*eqphki/ceeguu/ocr+%"cevkqp"}]ftqr"]nqi_;"~"<br/>}hqtyctf"]ecrvwtg"~"xnep"vlan_ID_;"~"}tgfktgev"<br/>}}hcuvgvjgtpgv ~ ikicdkvgvjgtpgv"~"vgpikicdkvgvjgtpgv;"<br/>unqvlrgtv;"~"}rgtv/ejcppgn"ejcppgnakf;</code> | Configures the action clause in a VLAN access map sequence. |

- You can set the action to drop, forward, forward capture, or redirect packets.
- Forwarded packets are still subject to any configured Cisco IOS security ACLs.
- The **capture** action sets the capture bit for the forwarded packets so that ports with the capture function enabled can receive the packets. Only forwarded packets can be captured. For more information about the **capture** action, see the [“Configuring a Capture Port” section on page 74-6](#).
- The **forward vlan** action implements Policy-Based Forwarding (PBF), bridging between VLANs.
- When the **log** action is specified, dropped packets are logged in software. Only dropped IP packets can be logged.
- The **redirect** action allows you to specify up to five interfaces, which can be physical interfaces or EtherChannels. You cannot specify packets to be redirected to an EtherChannel member or a VLAN.
- The redirect interface must be in the VLAN for which the VACL access map is configured.
- If a VACL is redirecting traffic to an egress SPAN source port, SPAN does not copy the VACL-redirected traffic.
- SPAN and RSPAN destination ports transmit VACL-redirected traffic.
- Use the **no** keyword to remove an action clause or specified redirect interfaces.

See the [“VLAN Access Map Configuration and Verification Examples” section on page 74-5](#).

## Applying a VLAN Access Map

To apply a VLAN access map, perform this task:

| Command                                                                       | Purpose                                             |
|-------------------------------------------------------------------------------|-----------------------------------------------------|
| <code>Tqwgvt*eqphki+%<b>"xn cp"</b>hknvgt"ocrapcog"<b>"xn cp/nkuv"</b></code> | Applies the VLAN access map to the specified VLANs. |

- You can apply the VLAN access map to one or more VLANs.
- The *vlan\_list* parameter can be a single VLAN ID or a comma-separated list of VLAN IDs or VLAN ID ranges (*vlan\_ID-vlan\_ID*).
- You can apply only one VLAN access map to each VLAN.
- VACLs applied to VLANs are active only for VLANs with a Layer 3 VLAN interface configured. Applying a VLAN access map to a VLAN without a Layer 3 VLAN interface creates an administratively down Layer 3 VLAN interface to support the VLAN access map.
- VACLs applied to VLANs are inactive if the Layer 2 VLAN does not exist or is not operational.
- You cannot apply a VACL to a secondary private VLAN. VACLs applied to primary private VLANs also apply to secondary private VLANs.
- Use the **no** keyword to clear VLAN access maps from VLANs.

See the [“VLAN Access Map Configuration and Verification Examples”](#) section on page 74-5.

## Verifying VLAN Access Map Configuration

To verify VLAN access map configuration, perform this task:

| Command                                                                                     | Purpose                                                                                    |
|---------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|
| <code>Tqwgvt%<b>"uj qy"</b>xn cp"ceeguu/ocr"]ocrapcog_"</code>                              | Verifies VLAN access map configuration by displaying the content of a VLAN access map.     |
| <code>Tqwgvt%<b>"uj qy"</b>xn cp"hknvgt"]ceeguu/ocr"ocrapcog"~<b>"xn cp"</b>xncpakf_</code> | Verifies VLAN access map configuration by displaying the mappings between VACLs and VLANs. |

## VLAN Access Map Configuration and Verification Examples

Assume IP-named ACL **net\_10** and **any\_host** are defined as follows:

```
Tqwgvt%"uj qy"kr"ceeguu/nkuvu"pgva32
Gzvpgpfgf"KR"ceeguu"nkuv"pgva32
" " "rgtokv"kr"32020202"2047704770477"cp{

Tqwgvt%"uj qy"kr"ceeguu/nkuvu"cp{ajquv
Uvcpfctf"KR"ceeguu"nkuv"cp{ajquv
" " "rgtokv"cp{
```

This example shows how to define and apply a VLAN access map to forward IP packets. In this example, IP traffic matching **net\_10** is forwarded and all other IP packets are dropped due to the default drop action. The map is applied to VLAN 12 to 16.

```
Tqwgvt*eqphki+%"xn cp"ceeguu/ocr"vjqt"32
```

```
Tqwgvt*eqphki/ceeguu/ocr+% "ocvej"kr"cfftgau"pgva32
Tqwgvt*eqphki/ceeguu/ocr+% "cevkqp"htyctf"
Tqwgvt*eqphki/ceeguu/ocr+% "gzkv"
Tqwgvt*eqphki+% "xnep"hnvgt"vjqt"xnep/nkuv"34/38"
```

This example shows how to define and apply a VLAN access map to drop and log IP packets. In this example, IP traffic matching net\_10 is dropped and logged and all other IP packets are forwarded:

```
Tqwgvt*eqphki+% "xnep"ceeguu/ocr"icp{ogfg"32
Tqwgvt*eqphki/ceeguu/ocr+% "ocvej"kr"cfftgau"pgva32
Tqwgvt*eqphki/ceeguu/ocr+% "cevkqp"ftqr"nqi
Tqwgvt*eqphki/ceeguu/ocr+% "gzkv
Tqwgvt*eqphki+% "xnep"ceeguu/ocr"icp{ogfg"42
Tqwgvt*eqphki/ceeguu/ocr+% "ocvej"kr"cfftgau"cp{ajquv
Tqwgvt*eqphki/ceeguu/ocr+% "cevkqp"htyctf
Tqwgvt*eqphki/ceeguu/ocr+% "gzkv
Tqwgvt*eqphki+% "xnep"hnvgt"icp{ogfg"xnep/nkuv"9/;"
```

This example shows how to define and apply a VLAN access map to forward and capture IP packets. In this example, IP traffic matching net\_10 is forwarded and captured and all other IP packets are dropped:

```
Tqwgvt*eqphki+% "xnep"ceeguu/ocr"oqftgfg"32"
Tqwgvt*eqphki/ceeguu/ocr+% "ocvej"kr"cfftgau"pgva32
Tqwgvt*eqphki/ceeguu/ocr+% "cevkqp"htyctf"ecrvwtg
Tqwgvt*eqphki/ceeguu/ocr+% "gzkv
Tqwgvt*eqphki+% "xnep"hnvgt"oqftgfg"xnep/nkuv"4."6/8"
```

## Configuring a Capture Port



### Note

- A port configured to capture VACL-filtered traffic is called a capture port.
- To apply IEEE 802.1Q tags to the captured traffic, configure the capture port to trunk unconditionally (see the “[Configuring the Layer 2 Switching Port as an 802.1Q Trunk](#)” section on page 21-8 and the “[Configuring the Layer 2 Trunk Not to Use DTP](#)” section on page 21-9).

To configure a capture port, perform this task:

|        | Command                                                                                                           | Purpose                                                                                              |
|--------|-------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "kpvgthceg" }} type slot/port;</code>                                                       | Specifies the interface to configure.                                                                |
| Step 2 | <code>Tqwgvt*eqphki/kh+% "uykvejrgtv"ecrvwtg"cnngygf" xnep" } cff ~ "cnn" ~ "gzegrv" ~ "tgoqgx;" vlan_list</code> | (Optional) Filters the captured traffic on a per-destination-VLAN basis. The default is <b>all</b> . |
| Step 3 | <code>Tqwgvt*eqphki/kh+% "uykvejrgtv"ecrvwtg"</code>                                                              | Configures the port to capture VACL-filtered traffic.                                                |

- You can configure any port as a capture port.
- The `vlan_list` parameter can be a single VLAN ID or a comma-separated list of VLAN IDs or VLAN ID ranges (`vlan_ID–vlan_ID`).
- To encapsulate captured traffic, configure the capture port with the **switchport trunk encapsulation** command (see the “[Configuring a Layer 2 Switching Port as a Trunk](#)” section on page 21-8) before you enter the **switchport capture** command.



- For unencapsulated captured traffic, configure the capture port with the **switchport mode access** command (see the “[Configuring a LAN Interface as a Layer 2 Access Port](#)” section on page 21-14) before you enter the **switchport capture** command.
- The capture port supports only egress traffic. No traffic can enter the switch through a capture port.

This example shows how to configure a Gigabit Ethernet interface 5/1 as a capture port:

```
Tqvwgt*eqphki+%"kpvgt hceg"iki cdkvGvjgtpgv"713 "
Tqvwgt*eqphki/kh+%"uykvej rgtv"ecrvwtg"
Tqvwgt*eqphki/kh+%"gpf"
```

This example shows how to display VLAN access map information:

```
Tqvwgt%"ujqy"xncp"ceeguu/ocr"o{ocr"
Xncp"ceeguu/ocr"$o{ocr$"32
"ocvej<"kr"cfftgau"pgva32
"cevkqp<"hqtyctf"ecrvwtg
Tqvwgt%"
```

This example shows how to display mappings between VACLs and VLANs. For each VACL map, there is information about the VLANs that the map is configured on and the VLANs that the map is active on. A VACL is not active if the VLAN does not have an interface.

```
Tqvwgt%"ujqy"xncp"hknvgt"
XNCP"Ocr"oqtf tgf<
"Eqphkiwtgf"qp"XNCPu<"4.6/8
"Cevkxg"qp"XNCPu<"4.6/8
Tqvwgt%"
```

## Configuring VACL Logging

When you configure VACL logging, IP packets that are denied generate log messages in these situations:

- When the first matching packet is received
- For any matching packets received during the last 5-minute interval
- If the threshold is reached before the 5-minute interval

Log messages are generated on a per-flow basis. A flow is defined as packets with the same IP addresses and Layer 4 (UDP or TCP) port numbers. When a log message is generated, the timer and packet count is reset.

These restrictions apply to VACL logging:

- Because of the rate-limiting function for redirected packets, VACL logging counters may not be accurate.
- Only denied IP packets are logged.

To configure VACL logging, use the **action drop log** command action in VLAN access map submode (see the “[Configuring an Action Clause in a VLAN Access Map Sequence](#)” section on page 74-4) and perform this task in global configuration mode to specify the global VACL logging parameters:

|        | Command                                                                      | Purpose                                                                                                                                                                                                                                             |
|--------|------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%<b>"xncp"ceeguu/nqi"oczhnqy"</b><br/>oczapwodgt"</code> | Sets the log table size. The content of the log table can be deleted by setting the maxflow number to 0. The default is 500 with a valid range of 0 to 2048. When the log table is full, logged packets from new flows are dropped by the software. |

|        | Command                                                                  | Purpose                                                                                                                                                                                          |
|--------|--------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 2 | <code>Tqwvgt*eqphki+%<b>"xncp"</b>ceeguu/nqi"tcvgnkokv"rru"</code>       | Sets the maximum redirect VACL logging packet rate. The default packet rate is 2000 packets per second with a valid range of 0 to 5000. Packets exceeding the limit are dropped by the hardware. |
| Step 3 | <code>Tqwvgt*eqphki+%<b>"xncp"</b>ceeguu/nqi"vjtgujqnf"rmvaeqwpv"</code> | Sets the logging threshold. A logging message is generated if the threshold for a flow is reached before the 5-minute interval. By default, no threshold is set.                                 |
| Step 4 | <code>Tqwvgt*eqphki+%<b>"gzkv"</b></code>                                | Exits VLAN access map configuration mode.                                                                                                                                                        |

This example shows how to configure global VACL logging in hardware:

```
Tqwvgt*eqphki+%"xncp"ceeguu/nqi"oczhnqy":22"
Tqwvgt*eqphki+%"xncp"ceeguu/nqi"tcvgnkokv"4422"
Tqwvgt*eqphki+%"xncp"ceeguu/nqi"vjtgujqnf"6222"
```

Displays the configured VACL logging properties.

```
Tqwvgt%"ujqy""xncp"ceeguu/nqi"eqphki"
```

Displays the content of the VACL log table.

```
Tqwvgt%"ujqy""xncp"ceeguu/nqi"hnqy"rtqvqeqn"}}src_addr src_mask;"~"cp{"~"}jquv"jquvpcog"~"
jquvakr;i;i"}}dst_addr dst_mask;"~"cp{"~"}jquv"jquvpcog"~"jquvakr;i;i
]xncp"xncpakf_"
```

Displays packet and message counts and other statistics.

```
Tqwvgt%"ujqy""xncp"ceeguu/nqi"uvcvkuvkeu"
```



#### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## Policy-Based Forwarding (PBF)

---

- [Prerequisites for PBF, page 75-1](#)
- [Restrictions for PBF, page 75-2](#)
- [Information About PBF, page 75-2](#)
- [Default Settings for PBF, page 75-2](#)
- [How to Configure PBF, page 75-2](#)
- [Monitoring PBF, page 75-3](#)
- [Configuration Examples for PBF, page 75-3](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- Optimized ACL logging (OAL) and VACL capture are incompatible. Do not configure both features on the switch. With OAL configured (see the [“Optimized ACL Logging” section on page 69-15](#)), use SPAN to capture traffic.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for PBF

None.

## Restrictions for PBF

- PBF is performed in software, with optional rate limiters to control CPU usage.
- PBF is applied only to ingress traffic.
- To allow traffic in both directions between two VLANs, you must configure PBF in both VLANs.
- You can configure PBF between hosts in different switches.
- By default, PBF hosts in the same VLAN cannot communicate with each other. To allow local communication, use the **local** keyword.
- When configuring the **vlan filter** command, specify only one VLAN after the **vlan-list** keyword. If you specify more than one VLAN, PBF will ignore all but the last VLAN in the list.
- Layer 2 port ACLs (PACLs) take precedence over PBF.
- If the sending VLAN is shut down, PBF will still function. Shutting down a VLAN disables Layer 3 functionality, but PBF is a Layer 2 function.

## Information About PBF

PBF is a MAC-address VACL that bridges packets between VLANs. PBF forwards packets based solely on the source and destination MAC addresses, ignoring any information above Layer 2.

## Default Settings for PBF

None.

## How to Configure PBF

To configure PBF, perform this task on each source VLAN:

|        | Command                                                                    | Purpose                                                                                                                                                    |
|--------|----------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "oce"jqvu"my_host mac_addr</code>                    | (Optional) Assigns a name to the MAC address of the source host.                                                                                           |
| Step 2 | <code>Tqwvgt*eqphki+% "oce"ceeguu/nkuv"gzvgpfgf"ocenapcog"</code>          | Configures a MAC ACL.                                                                                                                                      |
| Step 3 | <code>Tqwvgt*eqphki/gzv/ocen+% "rgtokv"jqvu"my_host cp{</code>             | Configures an access control entry (ACE) to permit traffic from the named host to any other address. Hosts can be specified by a name or by a MAC address. |
| Step 4 | <code>Tqwvgt*eqphki/gzv/ocen+% "rgtokv"jqvu"my_host jqvu"other_host</code> | Configures an ACE to permit traffic from the named host to one other host.                                                                                 |
| Step 5 | <code>Tqwvgt*eqphki/gzv/ocen+% "gzkv"</code>                               | Exits ACL configuration.                                                                                                                                   |
| Step 6 | <code>Tqwvgt*eqphki+% "xncp"ceeguu/ocr"ocrapcog"</code>                    | Defines a VLAN access map.                                                                                                                                 |
| Step 7 | <code>Tqwvgt*eqphki/ceeguu/ocr+% "ocvej"oce"cfftggu"mac_l_name</code>      | Applies the MAC ACL to this VLAN access map.                                                                                                               |

|         | Command                                                                           | Purpose                                                                                                                                                                                                                        |
|---------|-----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 8  | <code>Tqwgvt*eqphki/ceeguu/ocr+%"cevkqp"hqtyctf"xncp"other_vlan_ID"]nqecn_</code> | Forwards matching traffic to the other VLAN.<br><br><b>Note</b> By default, PBF-specified devices on the same VLAN cannot communicate with each other. To allow local communication by the host, use the <b>local</b> keyword. |
| Step 9  | <code>Tqwgvt*eqphki/ceeguu/ocr+%"gzkv</code>                                      | Exits access map configuration.                                                                                                                                                                                                |
| Step 10 | <code>Tqwgvt*eqphki+%"xncp"hknvgt"ocrapcog"xncp/nkuv"my_vlan_ID</code>            | Applies the VLAN access map to the specified VLAN.                                                                                                                                                                             |
| Step 11 | <code>Tqwgvt*eqphki+%"kpvgtthceg"xncp"my_vlan_ID</code>                           | Enters interface configuration mode for the VLAN.                                                                                                                                                                              |
| Step 12 | <code>Tqwgvt*eqphki/kh+%"oce"rcemgv/encuukh{</code>                               | Classifies incoming or outgoing Layer 3 packets on this VLAN as Layer 2 packets.                                                                                                                                               |
| Step 13 | <code>Tqwgvt*eqphki/kh+%"gzkv</code>                                              | Exits interface configuration mode.                                                                                                                                                                                            |
| Step 14 | <code>Tqwgvt*eqphki+%"gzkv</code>                                                 | Exits global configuration mode.                                                                                                                                                                                               |

## Monitoring PBF

- The output of the **show vlan mac-pbf config** command displays the following fields for configured PBF paths:
  - Rcv Vlan — The number of the VLAN to which packets are forwarded by PBF.
  - Snd Vlan — The number of the VLAN which will forward packets by PBF.
  - DMAC — The MAC address of the destination host on the receiving VLAN.
  - SMAC — The MAC address of the source host on the sending VLAN.
  - (Local) — Displays 1 if the **local** keyword is configured in the **action forward vlan** command on the sending VLAN; displays 0 if the **local** keyword is not configured.
  - (Packet counter) — The number of packets that have been forwarded from the sending VLAN to the receiving VLAN. To clear this counter, enter the **clear vlan mac-pbf counters** command.
  - Pkts dropped — The number of packets that have been dropped by the sending VLAN. To clear this counter, enter the **clear vlan mac-pbf counters** command.

## Configuration Examples for PBF

This example shows how to configure and display PBF to allow two hosts in separate VLANs (“red” VLAN 100 and “blue” VLAN 200) on the same switch to exchange packets:

```
Tqwgvt*eqphki+%"oce"jquv"jquvatgf5"22230222402225
Tqwgvt*eqphki+%"oce"ceeguu/nkuv"gzvgpfgf"ocenatgf"
Tqwgvt*eqphki/gzv/ocen+%"rgtokv"jquv"jquvatgf"jquv"jquvadnwg
Tqwgvt*eqphki/gzv/ocen+%"gzkv"
Tqwgvt*eqphki+%"xncp"ceeguu/ocr"tgfavqadnwg"
Tqwgvt*eqphki/ceeguu/ocr+%"ocvej"oce"cfftgau"ocenatgf"
Tqwgvt*eqphki/ceeguu/ocr+%"cevkqp"hqtyctf"xncp"422"nqecn
Tqwgvt*eqphki/ceeguu/ocr+%"gzkv"
Tqwgvt*eqphki+%"xncp"hknvgt"tgfavqadnwg"xncp/nkuv"322
Tqwgvt*eqphki+%"kpvgtthceg"xncp"322
Tqwgvt*eqphki/kh+%"oce"rcemgv/encuukh{
```

```

Tqwgvt*eqphki/kh+% "gzkv"
Tqwgvt*eqphki+%
Tqwgvt*eqphki+% "oce"jqv"jqvadnwg7"22230222402227
Tqwgvt*eqphki+% "oce"ceeguu/nkuv"gzvgpfgf"ocenadnwg"
Tqwgvt*eqphki/gzv/ocen+% "rgtokv"jqv"jqvadnwg"jqv"jqvatg
Tqwgvt*eqphki/gzv/ocen+% "gzkv"
Tqwgvt*eqphki+% "xnep"ceeguu/ocr"dnwgavqatgf"
Tqwgvt*eqphki/ceeguu/ocr+% "ocvej"oce"cfftgau"ocenadnwg
Tqwgvt*eqphki/ceeguu/ocr+% "cevkqp"hgtyctf"xnep"322"
Tqwgvt*eqphki/ceeguu/ocr+% "gzkv"
Tqwgvt*eqphki+% "xnep"hknvgt"dnwgavqatgf"xnep/nkuv"422
Tqwgvt*eqphki+% "kpvgtthceg"xnep"422
Tqwgvt*eqphki/kh+% "oce"rcemg/encuukh{
Tqwgvt*eqphki/kh+% "gzkv"
Tqwgvt%
Tqwgvt% "ujqy"xnep"oce/rdh"eqphki"
"Tex"Xnep"322. "Upf"Xnep"422. "FOCE"22230222402225. "UOCE"22230222402227"3"37"
"Tex"Xnep"422. "Upf"Xnep"322. "FOCE"22230222402227. "UOCE"22230222402225"2"45"
"Rmvu"ftqrrgf"2
Tqwgvt%

```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## Denial of Service (DoS) Protection

---

- [Security ACLs and VACLs, page 76-2](#)
- [QoS Rate Limiting, page 76-2](#)
- [Global Protocol Packet Policing, page 76-3](#)
- [Unicast Reverse Path Forwarding \(uRPF\) Check, page 76-6](#)
- [Configuring Sticky ARP, page 76-9](#)
- [Monitoring Packet Drop Statistics, page 76-10](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- Also see:
  - [Chapter 72, “MAC Address-Based Traffic Blocking”](#)
  - [Chapter 81, “Traffic Storm Control”](#)
  - [Chapter 77, “Control Plane Policing \(CoPP\)”](#)
  - [http://www.cisco.com/en/US/docs/ios-xml/ios/security/config\\_library/15-sy/secdata-15-sy-library.html](http://www.cisco.com/en/US/docs/ios-xml/ios/security/config_library/15-sy/secdata-15-sy-library.html)



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Security ACLs and VACLs

If the network is under a DoS attack, ACLs can be an efficient method for dropping the DoS packets before they reach the intended target. Use security ACLs if an attack is detected from a particular host.

In this example, the host 10.1.1.10 and all traffic from that host is denied:

```
Tqwgvt*eqphki+% "ceeguu/nkuv"323"fqp{"kr"jqv"320303032"cp{
Tqwgvt*eqphki+% "ceeguu/nkuv"323"rgtokv"kr"cp{"cp{
```

Security ACLs also protect against the spoofing of addresses. For example, assume that a source address A is on the inside of a network and a switch interface that is pointing to the Internet. You can apply an inbound ACL on the switch Internet interface that denies all addresses with a source of A (the inside address). This action stops attacks where the attackers spoof inside source addresses. When the packet arrives at the switch interface, it matches on that ACL and drops the packet before it causes damage.

When the switch is used with a Cisco Intrusion Detection Module (CIDM), you can dynamically install the security ACL as a response to the detection of the attack by the sensing engine.

VACLs are a security enforcement tool based on Layer 2, Layer 3, and Layer 4 information. The result of a VACL lookup against a packet can be a permit, a deny, a permit and capture, or a redirect. When you associate a VACL with a particular VLAN, all traffic must be permitted by the VACL before the traffic is allowed into the VLAN. VACLs are enforced in hardware, so there is no performance penalty for applying VACLs to a VLAN.

See [Chapter 69, “Cisco IOS ACL Support,”](#) and [Chapter 74, “VLAN ACLs \(VACLs\).”](#)

## QoS Rate Limiting

QoS ACLs limit the amount of a particular type of traffic that is processed by the RP. If a DoS attack is initiated against the RP, QoS ACLs can prevent the DoS traffic from reaching the RP data path and congesting it. The PFC and DFCs perform QoS in hardware, which offers an efficient means of limiting DoS traffic (once that traffic has been identified) to protect the switch from impacting the RP.

For example, if the network is experiencing ping-of-death or smurf attacks, the administrator should rate limit the ICMP traffic to counteract the DoS attack and still allow legitimate traffic through the processor, or allow it to be forwarded to the RP or host. This rate limiting configuration must be done for each flow that should be rate limited and the rate-limiting policy action should be applied to the interface.

In the following example, the access-list 101 permits and identifies ping (echo) ICMP messages from any source to any destination as traffic. Within the policy map, a policing rule defines a specified committed information rate (CIR) and burst value (96000 bps and 16000 bps) to rate limit the ping (ICMP) traffic through the chassis. The policy map then is applied to an interface or VLAN. If the ping traffic exceeds the specified rate on the VLAN or interface where the policy map is applied, it is dropped as specified in the markdown map (the markdown map for the normal burst configurations is not shown in the example).

```
Tqwgvt*eqphki+% "ceeguu/nkuv"323"rgtokv"keor"cp{"cp{"gejq"
Tqwgvt*eqphki+% "encuu/ocr"ocvej/cp{"keoraencuu"
Tqwgvt*eqphki/eocr+% "ocvej"ceeguu/itqwr"323"
Tqwgvt*eqphki/eocr+% "gzkv"
Tqwgvt*eqphki+% "rqnke{/ocr"keorarnqkegt"
Tqwgvt*eqphki/rocr+% "encuu"keoraencuu"
Tqwgvt*eqphki/rocr/e+% "rqnkeg";8222"38222"eqphqto/cevkgp"vtcpuokv"gzeggf/cevkgp"
rqnkegf/fuer/vtcpuokv"ftqr"
```



```
Tqvwgt*eqphki/rocr/e+%"gzkv"
Tqvwgt*eqphki/rocr+%"gzkv"
```

See [Chapter 63, “Classification, Marking, and Policing.”](#)

## Global Protocol Packet Policing

- [Prerequisites for Global Protocol Packet Policing, page 76-3](#)
- [Restrictions for Global Protocol Packet Policing, page 76-3](#)
- [Information About Global Protocol Packet Policing, page 76-5](#)
- [How to Configure Single-Command Global Protocol Packet Policing, page 76-5](#)
- [How to Configure Policy-Based Global Protocol Packet Policing, page 76-6](#)

## Prerequisites for Global Protocol Packet Policing

None.

## Restrictions for Global Protocol Packet Policing

- The minimum values supported by the **platform qos protocol arp police** command are too small for use in production networks.
- ARP packets are approximately 40 bytes long and ARP reply packets are approximately 60 bytes long. The policer rate value is in bits per second. The burst value is in bytes per second. Together, an ARP request and reply are approximately 800 bits.
- The configured rate limits are applied separately to the PFC and each DFC. The RP CPU will receive the configured value times the number of forwarding engines.
- Policy-based protocol packet policing is applied per-forwarding engine (PFC and any DFCs).
- With Supervisor Engine 6T, policy-based protocol packet policing supports distributed aggregate policing (see the [“Enabling Distributed Aggregate Policing”](#) section on page 63-8).
- The protocol packet policing mechanism effectively protects the RP CPU against attacks such as line-rate ARP attacks, but it polices both routing protocols and ARP packets to the switch and also polices traffic through the switch with less granularity than CoPP.
- The policing mechanism shares the root configuration with a policing-avoidance mechanism. The policing-avoidance mechanism lets the routing protocol and ARP packets flow through the network when they reach a QoS policer. This mechanism can be configured using the **platform qos protocol protocol\_name pass-through** command.
- Policy-based protocol packet policing does not support microflow policers.
- Only ingress Policy-based protocol packet policing is supported.
- Policy-based protocol packet policing does not support Layer 4 ACL operators (see the [“Restrictions for Layer 4 Operators in ACLs”](#) section on page 69-2), which imposes these subsequent restrictions:
  - For IPv4 or IPv6 traffic, no support for UDP or TCP port range matching
  - For IPv6 traffic, no support for precedence or DSCP matching

- Protocol packet policing policies can share an aggregate policer with QoS policies.
- An aggregate policer cannot be applied to both ingress and egress traffic.
- With Supervisor Engine 6T, policy-based protocol packet policing supports a maximum of 1,000 global TCAM entries.
- Policy-based protocol packet policing supports the **class default** and **permit protocol\_name any any** commands, but traffic flow might be affected significantly because the protocol packet policing policy processes all matched traffic.
- With Supervisor Engine 6T, policy-based protocol packet policing works with any configured port trust state.
- You can configure both single-command protocol packet policing and policy-based protocol packet policing. Single-command protocol packet policing is applied first and then policy-based protocol packet policing.

**Note**

The software does not detect or attempt to resolve any configuration conflicts between single-command protocol packet policing and policy-based protocol packet policing.

- You can configure both policy-based protocol packet policing and control plane policing (see [Chapter 77, “Control Plane Policing \(CoPP\)”](#)). Policy-based protocol packet policing is applied first and then CoPP.
- Single-command protocol packet policing programs the configured protocol-specific action for ingress traffic and automatically programs a corresponding egress-traffic pass-through action to preserve the ingress result egress traffic.
- Policy-based protocol packet policing does not automatically preserve the ingress policing result in egress traffic.
  - To preserve the ingress policing result in egress traffic with policy-based protocol packet policing, configure an appropriate output policy. To pass egress traffic through unchanged, duplicate each ingress class in the output policy and configure **trust dscp** as the class-map action.
  - Without an output policy-map, egress traffic is processed by any configured interface-based policy-map and ingress global policy result will be overwritten.
- The PFC and any DFCs supports a single **match** command in **class-map match-all** class maps, except that the **match protocol** command can be configured in a class map with the **match dscp** or **match precedence** command.
- The PFC and any DFCs supports multiple **match** commands in **class-map match-any** class maps.
- Class maps can use the **match** commands listed in [Table 76-1](#) to configure a traffic class that is based on the match criteria.

Table 76-1 Traffic Classification Class Map match Commands and Match Criteria

| match Commands                                                                                                                                                                           | Direction | Match Criteria                                                                                                         |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|------------------------------------------------------------------------------------------------------------------------|
| <b>match access-group</b> { <i>access_list_number</i>   <b>name</b> <i>access_list_name</i> }                                                                                            | Ingress   | Access control list (ACL).<br><b>Note</b> Use ACLs to match the following:<br>—CoS value<br>—VLAN ID<br>—Packet length |
| <b>match any</b>                                                                                                                                                                         | Ingress   | Any match criteria.                                                                                                    |
| <b>match cos</b>                                                                                                                                                                         | Ingress   | CoS value.                                                                                                             |
| <b>match discard-class</b>                                                                                                                                                               | Ingress   | Discard class value.                                                                                                   |
| <b>match dscp</b><br><b>Note</b> The <b>match protocol</b> command can be configured in a class map with the <b>match dscp</b> command.                                                  | Ingress   | DSCP value.                                                                                                            |
| <b>match l2 miss</b>                                                                                                                                                                     | Ingress   | Layer 2 traffic flooded in a VLAN because it is addressed to a currently unlearned MAC-Layer destination address.      |
| <b>match mpls experimental topmost</b>                                                                                                                                                   | Ingress   | MPLS EXP value in the topmost label.                                                                                   |
| <b>match precedence</b><br><b>Note</b> The <b>match protocol</b> command can be configured in a class map with the <b>match precedence</b> command.                                      | Ingress   | IP precedence values.                                                                                                  |
| <b>match protocol</b> {arp   ip   ipv6}<br><b>Note</b> The <b>match protocol</b> command can be configured in a class map with the <b>match dscp</b> or <b>match precedence</b> command. | Ingress   | Protocol.                                                                                                              |
| <b>match qos-group</b>                                                                                                                                                                   | Ingress   | QoS group ID.                                                                                                          |

The PFC and any DFCs supports these ACL types for use with the **match access group** command:

| Protocol  | Numbered ACLs                   | Extended ACLs                      | Named ACLs |
|-----------|---------------------------------|------------------------------------|------------|
| IPv4      | Yes:<br>1 to 99<br>1300 to 1999 | Yes:<br>100 to 199<br>2000 to 2699 | Yes        |
| IPv6      | Not applicable                  | Yes (named)                        | Yes        |
| MAC Layer | Not applicable                  | Not applicable                     | Yes        |
| ARP       | Not applicable                  | Not applicable                     | Yes        |

## Information About Global Protocol Packet Policing

Attackers may try to overwhelm the RP CPU with routing protocol control packets (for example, ARP packets). Protocol packet policing rate limits this traffic in hardware. Release 15.1(1)SY1 and later releases support policy-based global protocol packet policing, shown in Cisco Feature Navigator as the Global QoS Policy feature.

## How to Configure Single-Command Global Protocol Packet Policing

Enter the **rncvqhcto"squ"rtqvqeqn"A** to display the supported routing protocols.

The **platform qos protocol arp police** command rate limits ARP packets. This example shows how to allow 200 ARP requests and replies per second:

```
Tqwvgt*eqphki+%"rncvqhcto"squ"rtqvqeqn"ctr"rqnkeg"422222"8222"
```

This example shows how to display the available protocols to use with protocol packet policing:

```
Tqwvgt*eqphki+%"rncvqhcto"squ"rtqvqeqn"A
"kuku"
"gkitr"
"nfr"
"qurh"
"tkr"
"dir"
"qurhx5"
"dirx4"
"tkrpi"
"pgkij/fkueqxgt"
"yneer"
"ctr"
```

This example shows how to display the available keywords to use with the **platform qos protocol** command:

```
Tqwvgt*eqphki+%"rncvqhcto"squ"rtqvqeqn"rtqvqeqnapcog"A
"rcuu/vjtgwij"rcuu/vjtgwij"mg{yqtf
"rqnkeg"rqnkeg"mg{yqtf
"rtgegfgpeg"ejcpig"kr/rtgegfgpeg*wugf"vq"ocr"vjg"fuer"vq"equ"xcnwg+
```

## How to Configure Policy-Based Global Protocol Packet Policing

Use these QoS sections and the global protocol packet policing policy map configuration section:

- [Configuring a Class Map, page 63-8](#)
- [Configuring a Policy Map, page 63-9](#)
- [Configuring a Global Protocol Packet Policing Policy Map, page 76-6](#)

## Configuring a Global Protocol Packet Policing Policy Map

To configure a global protocol packet policing policy map, perform this task:

| Command                                                                               | Purpose                                                                                                     |
|---------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|
| <code>Tqwgvt*eqphki+% "rncvhtgo"sq"ugtxkeg/rqnke{ "kprwv"<br/>rqnke{aocrapcog"</code> | Configures a global protocol packet policing policy map.<br><b>Note</b> You can configure one input policy. |

## Unicast Reverse Path Forwarding (uRPF) Check

- [Prerequisites for uRPF Check, page 76-7](#)
- [Restrictions for uRPF Check, page 76-7](#)
- [Information about uRPF Check, page 76-7](#)
- [Configuring the Unicast RPF Check Mode, page 76-8](#)
- [Enabling Self-Pinging, page 76-9](#)

### Prerequisites for uRPF Check

None.

### Restrictions for uRPF Check

- Unicast RPF does not provide complete protection against spoofing. Spoofed packets can enter a network through unicast RPF-enabled interfaces if an appropriate return route to the source IP address exists.
- You can configure a unicast RPF mode on each interface.
- The “allow default” options of the unicast RPF modes do not offer significant protection against spoofing.
  - Strict unicast RPF Check with Allow Default—Received IP traffic that is sourced from a prefix that exists in the routing table passes the unicast RPF check if the prefix is reachable through the input interface. If a default route is configured, any IP packet with a source prefix that is not in the routing table passes the unicast RPF check if the ingress interface is a reverse path for the default route.
  - Loose unicast RPF Check with Allow Default—If a default route is configured, any IP packet passes the unicast RPF check.
- Unicast RPF Strict Mode—The unicast RPF strict mode provides the greatest security against spoofed traffic. If, on all unicast RPF-check enabled interfaces, the switch receives valid IP traffic through interfaces that are reverse paths for the traffic, then strict mode is an option.
- Unicast RPF Loose Mode—The unicast RPF loose mode provides less protection than strict mode, but it is an option on switches that receive valid IP traffic on interfaces that are not reverse paths for the traffic. The unicast RPF loose mode verifies that received traffic is sourced from a prefix that exists in the routing table, regardless of the interface on which the traffic arrives.

# Information about uRPF Check

The unicast RPF check verifies that the source address of received IP packets is reachable. The unicast RPF check discards IP packets that lack a verifiable IP source prefix (route), which helps mitigate problems that are caused by traffic with malformed or forged (spoofed) IP source addresses.

The PFC4 and DFC4s provide hardware support for the unicast RPF check on up to 16 paths, both with and without ACL filtering, for both IPv4 and IPv6 traffic.

To ensure that no more than 16 reverse-path interfaces exist in the routing table for each prefix, enter the **maximum-paths 16** command in config-router mode when configuring OSPF, EIGRP, or BGP.

## How to Configure Unicast RPF Check

- [Configuring the Unicast RPF Check Mode, page 76-8](#)
- [Enabling Self-Pinging, page 76-9](#)



Note

The following commands exist in the CLI, but have no function:

- platform ip cef rpf interface-group**
- platform ip cef rpf multipath interface-group**
- platform ip cef rpf multipath pass**
- platform ip cef rpf multipath punt**

## Configuring the Unicast RPF Check Mode

To configure unicast RPF check mode, perform this task:

|        | Command                                                                                                 | Purpose                                                                                                                                                                                 |
|--------|---------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <pre>Tqwvgt*eqphki+%"kpvgtthceg"} }xncp"vlan_ID;"~" }type slot/port;"~"}rqtvt/ejcppgn"pwodgt;"</pre>    | Selects an interface to configure.<br><br><b>Note</b> Based on the input port, unicast RPF check verifies the best return path before forwarding the packet on to the next destination. |
| Step 2 | <pre>Tqwvgt*eqphki/kh+%"kr"xgtkh{"wpkecuv"uqwteg" tgcejcdng/xkc"}tz"~"cp{"cnngy/fghcwnv_"nkuv_"</pre>   | Configures the IPv4 unicast RPF check mode.                                                                                                                                             |
| Step 3 | <pre>Tqwvgt*eqphki/kh+%"krx8"xgtkh{"wpkecuv"uqwteg" tgcejcdng/xkc"}tz"~"cp{"cnngy/fghcwnv_"nkuv_"</pre> | Configures the IPv6 unicast RPF check mode.                                                                                                                                             |
| Step 4 | <pre>Tqwvgt*eqphki/kh+%"gzkv"</pre>                                                                     | Exits interface configuration mode.                                                                                                                                                     |
| Step 5 | <pre>Tqwvgt%"ujqy"rncvhtqto"jctfyctg"egh"kr"trh"</pre>                                                  | Verifies the IPv4 configuration.                                                                                                                                                        |
| Step 6 | <pre>Tqwvgt%"ujqy"rncvhtqto"jctfyctg"egh"krx8"trh"</pre>                                                | Verifies the IPv6 configuration.                                                                                                                                                        |

- Use the **rx** keyword to enable strict check mode.
- Use the **any** keyword to enable exist-only check mode.
- Use the **allow-default** keyword to allow use of the default route for RPF verification.

- Use the *list* option to identify an access list.
  - If the access list denies network access, denied packets are dropped at the port.
  - If the access list permits network access, packets are forwarded to the destination address. Forwarded packets are counted in the interface statistics.
  - If the access list includes the logging action, information about the packets is sent to the log server.

This example shows how to enable unicast RPF exist-only check mode on Gigabit Ethernet port 4/1:

```
Tqvwgt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv"613 "
Tqvwgt*eqphki/kh+% "krx8" xgtkh{ "wpkecuv" uqwteg"tgcejcdng/xkc" cp{ "
Tqvwgt*eqphki/kh+% "kr" xgtkh{ "wpkecuv" uqwteg"tgcejcdng/xkc" cp{ "
Tqvwgt*eqphki/kh+% "gpf"
Tqvwgt%
```

This example shows how to enable unicast RPF strict check mode on Gigabit Ethernet port 4/2:

```
Tqvwgt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv"614 "
Tqvwgt*eqphki/kh+% "krx8" xgtkh{ "wpkecuv" uqwteg"tgcejcdng/xkc" tz"
Tqvwgt*eqphki/kh+% "kr" xgtkh{ "wpkecuv" uqwteg"tgcejcdng/xkc" tz"
Tqvwgt*eqphki/kh+% "gpf"
Tqvwgt%
```

## Enabling Self-Pinging

With unicast RPF check enabled, by default the switch cannot ping itself. To enable self-pinging, perform this task:

|        | Command                                                                                                           | Purpose                                                   |
|--------|-------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "kpvgthceg" } } xncp" vlan_ID; "~" } type slot/port; "~" } rgtv/ejcppgn" pwodgt; ; "</code> | Selects the interface to configure.                       |
| Step 2 | <code>Tqvwgt*eqphki/kh+% "kr" xgtkh{ "wpkecuv" uqwteg" tgcejcdng/xkc" cp{ "cnnqy/ugnh/rkpi"</code>                | Enables the switch to ping itself or a secondary address. |
| Step 3 | <code>Tqvwgt*eqphki/kh+% "gzkv"</code>                                                                            | Exits interface configuration mode.                       |

This example shows how to enable self-pinging:

```
Tqvwgt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv"613 "
Tqvwgt*eqphki/kh+% "kr" xgtkh{ "wpkecuv" uqwteg"tgcejcdng/xkc" cp{ "cnnqy/ugnh/rkpi"
Tqvwgt*eqphki/kh+% "gpf"
```

## Configuring Sticky ARP

Sticky ARP prevents MAC address spoofing by ensuring that ARP entries (IP address, MAC address, and source VLAN) do not get overridden. The switch maintains ARP entries in order to forward traffic to end devices or other switches. ARP entries are usually updated periodically or modified when ARP broadcasts are received. During an attack, ARP broadcasts are sent using a spoofed MAC address (with a legitimate IP address) so that the switch learns the legitimate IP address with the spoofed MAC address

and begins to forward traffic to that MAC address. With sticky ARP enabled, the switch learns the ARP entries and does not accept modifications received through ARP broadcasts. If you attempt to override the sticky ARP configuration, you will receive an error message.

To configure sticky ARP on a Layer 3 interface, perform this task:

|        | Command                                                                     | Purpose                                               |
|--------|-----------------------------------------------------------------------------|-------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"kpvgtthceg"</b> type<sup>3</sup> slot/port"</code> | Selects the interface on which sticky ARP is applied. |
| Step 2 | <code>Tqwvgt*eqphki/kh+%<b>"kr"uvkem{/ctr"</b></code>                       | Enables sticky ARP.                                   |
| Step 3 | <code>Tqwvgt*eqphki/kh+%<b>"kr"uvkem{/ctr"kipgtg"</b></code>                | Disables sticky ARP.                                  |

1. *type* = *fastethernet*, *gigabitethernet*, or *tengigabitethernet*

This example shows how to enable sticky ARP on interface 5/1:

```
Tqwvgt%"eqphkiwtg"vgtokpcn"
Tqwvgt*eqphki+%"kpvgtthceg"ikicdkvgvgtpgv"713"
Tqwvgt*eqphki/kh+%"kr"uvkem{/ctr"
Tqwvgt*eqphki/kh+%"gpf"
Tqwvgt%"
```

# Monitoring Packet Drop Statistics

- [Prerequisites for Packet Drop Statistics, page 76-10](#)
- [Restrictions for Packet Drop Statistics, page 76-10](#)
- [Information About Packet Drop Statistics, page 76-10](#)
- [How to Monitor Dropped Packets, page 76-10](#)

## Prerequisites for Packet Drop Statistics

None.

## Restrictions for Packet Drop Statistics

- The incoming captured traffic is not filtered.
- The incoming captured traffic is not rate limited to the capture destination.

## Information About Packet Drop Statistics

You can use show commands to display packet drop statistics. You can capture the traffic on an interface and send a copy of this traffic to a traffic analyzer connected to a port, which can aggregate packet drop statistics.



## How to Monitor Dropped Packets

- [Using show Commands, page 76-10](#)
- [Using SPAN, page 76-11](#)
- [Using VACL Capture, page 76-12](#)

### Using show Commands

The PFC and DFCs support ACL hit counters in hardware. You can use the **show platform hardware acl entry interface** command to display each entry in the ACL TCAM. You can also use the TTL and IP options counters to monitor the performance of the Layer 3 forwarding engine.

This example shows how to use the **show platform hardware acl entry interface** command to display packet statistics and errors associated with the Layer 3 forwarding engine:

```
Tqvwgt%ujqy"rncvhtqto"jctfyctg"uvcvkuvkeu"

///"Jctfyctg"Uvcvkuvkeu"hgt"Oqfwng"8"///"

N4"Hqtyctfkpi"Gpikpg
""""Uykvejgf"kp"N4"<"7;846"B"9"rru

N5"Hqtyctfkpi"Gpikpg
""""Rtqeguugf"kp"N5"<"7;846"B"9"rru
""""Uykvejgf"kp"N5"<"35"B"2"rru

""""Dtkfigf""""<"6824
""""HKD"Uykvejgf
""""KRx6"Wecuv"<"9
""""KRx8"Wecuv"<"3
""""GqORNU""""<"3
""""ORNU""""<"3
""""*U".",+""""<"2
""""KIOR"ONF""""<"2
""""KRx6"Oecuv"<"4
""""KRx8"Oecuv"<"2
""""Oecuv"Ngcm"<"2
""""CEN"Tqvwgf
""""Kprwv""""<"3
""""Qwvrwv""""<"73:
""""Pgvhngy"Uykvejgf
""""Kprwv""""<"4
""""Qwvrwv""""<"2
""""Gzegrvkqp"Tgfkgtgevgf
""""Kprwv""""<"2
""""Qwvrwv""""<"3
""""Oecuv"Dtkfig"Fkucdng"("Pq"Tgfkgtgev
""""<"2
""""Vqvcn"rcemgvu"ykvj"VQU"Ejcpigf""""<"5
""""Vqvcn"rcemgvu"ykvj"VE"Ejcpigf""""<"2
""""Vqvcn"rcemgvu"ykvj"EQU"Ejcpigf""""<"86
""""Vqvcn"rcemgvu"ykvj"GZR"Ejcpigf""""<"2
""""Vqvcn"rcemgvu"ykvj"SQU"Vwppgn"Gpecr"Ejcpigf"<"3
""""Vqvcn"rcemgvu"ykvj"SQU"Vwppgn"Fgecr"Ejcpigf"<"3
""""Vqvcn"rcemgvu"ftqrrgf"d{"CEN""""<"3
""""Vqvcn"rcemgvu"ftqrrgf"d{"Rqnkekpi""""<"2
Gttqtu
""""OCE1KR"ngpivj"kpqppukuvgpekgu""""<"2
""""Ujqtv"KR"rcemgvu"tgegkxgf""""<"2
```

```

""""KR"jgcfgt"ejgemuwo"gttqtu""""""""""<"2
""""VVN"hcknwtgu""""""""""<"2
""""OVW"hcknwtgu""""""""""<"2

Vqvcn"rcemgvu"N5"Rtqeguugf"d{"cnn"Oqfwngu<"7;846"B"9"rru

```

## Using SPAN

This example shows how to use the **monitor session** command to capture and forward traffic to an external interface:

```

Tqwvgt%"eqphkiwtg"vgtokpcn
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqwvgt*eqphki+%"oqpkvqt"uguukqp"3"uqwtg"xncp"66"dqvj"
Tqwvgt*eqphki+%"oqpkvqt"uguukqp"3"fguvkpcvkqp"kpvgthceg"i;13"
Tqwvgt*eqphki+%"gpf"
Tqwvgt%

```

This example shows how to use the **show monitor session** command to display the destination port:

```

Tqwvgt%"ujqy"oqpkvqt"uguukqp"3"
Uguukqp"3
////////
Uqwtg"Rqtvu<
""""TZ"Qpn{<""""""Pqpg
""""VZ"Qpn{<""""""Pqpg
""""Dqvj<""""""Pqpg
Uqwtg"XNCPu<
""""TZ"Qpn{<""""""Pqpg
""""VZ"Qpn{<""""""Pqpg
""""Dqvj<""""""66
Fguvkpcvkqp"Rqtvu<"Ik;13
Hknvgt"XNCPu<""""""Pqpg

```

For more information, see [Chapter 56, “Local SPAN, RSPAN, and ERSPAN.”](#)

## Using VACL Capture

The VACL capture feature allows you to direct traffic to ports configured to forward captured traffic. The capture action sets the capture bit for the forwarded packets so that ports with the capture function enabled can receive the packets. Only forwarded packets can be captured.

You can use VACL capture to assign traffic from each VLAN to a different interface.

VACL capture does not allow you to send one type of traffic, such as HTTP, to one interface and another type of traffic, such as DNS, to another interface. Also, VACL capture granularity is only applicable to traffic switched locally; you cannot preserve the granularity if you direct traffic to a remote switch.

For more information, see [Chapter 74, “VLAN ACLs \(VACLs\).”](#)



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## Control Plane Policing (CoPP)

---

- [Prerequisites for CoPP, page 77-1](#)
- [Restrictions for CoPP, page 77-2](#)
- [Information About CoPP, page 77-3](#)
- [Default Settings for CoPP, page 77-3](#)
- [How to Configure CoPP, page 77-5](#)
- [Monitoring CoPP, page 77-9](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- For more information about CoPP, see this document:  
[http://www.cisco.com/en/US/prod/collateral/switches/ps5718/ps708/white\\_paper\\_c11-663623.html](http://www.cisco.com/en/US/prod/collateral/switches/ps5718/ps708/white_paper_c11-663623.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for CoPP

None.

## Restrictions for CoPP

- The PFC and DFC provide hardware support for classes that match multicast traffic.
- CoPP is not supported in hardware for broadcast packets. The combination of ACLs, traffic storm control, and CoPP software protection provides protection against broadcast DoS attacks.
- CoPP does not support non-IP classes except for the default non-IP class. ACLs can be used instead of non-IP classes to drop non-IP traffic, and the default non-IP CoPP class can be used to limit to non-IP traffic that reaches the RP CPU.
- Do not use the **log** keyword in CoPP policy ACLs.
- If you have a large QoS configuration, the system may run out of TCAM space. If this is the case, CoPP may be performed in software.
- When there is a large QoS configuration for other interfaces, you can run out of TCAM space. When this situation occurs, CoPP may be performed entirely in software and result in performance degradation and CPU cycle consumption.
- You must ensure that the CoPP policy does not filter critical traffic such as routing protocols or interactive access to the switches. Filtering this traffic could prevent remote access to the switch, requiring a console connection.
- The PFC and DFCs support built-in special-case rate limiters, which are useful for situations where an ACL cannot be used (for example, TTL, MTU, and IP options). When you enable the special-case rate limiters, you should be aware that the special-case rate limiters will override the CoPP policy for packets matching the rate-limiter criteria.
- Neither egress CoPP nor silent mode is supported. CoPP is only supported on ingress (service-policy output CoPP cannot be applied to the control plane interface).
- ACE hit counters in hardware are only for ACL logic. You can rely on software ACE hit counters and the **show access-list**, **show policy-map control-plane**, and **show platform ip qos** commands to troubleshoot evaluate CPU traffic.
- CoPP is performed on a per-forwarding-engine basis and software CoPP is performed on an aggregate basis.
- CoPP does not support ACEs with the **log** keyword.
- CoPP uses hardware QoS TCAM resources. Enter the **show tcam utilization** command to verify the TCAM utilization.
- To avoid matching the filtering and policing that are configured in a subsequent class, configure policing in each class. CoPP does not apply the filtering in a class that does not contain a police command. A class without a police command matches no traffic.
- The ACLs used for classification are QoS ACLs. The supported QoS ACLs are IP standard, extended, and named.
- These are the only match types supported:
  - **ip precedence**
  - **ip dscp**
  - **access-group**
- Only IP ACLs are supported in hardware.
- MAC-based matching is done in software only.
- You can enter one **match** command in a single class map only.

- When defining the service policy, the **police** policy-map action is the only supported action.
- When applying the service policy to the control plane, the **input** direction is only supported.

## Information About CoPP

The traffic managed by the RP is divided into three functional components or *planes*:

- Data plane
- Management plane
- Control plane

The control plane policing (CoPP) feature increases security on the switch by protecting the RP from unnecessary or DoS traffic and giving priority to important control plane and management traffic. The PFC and DFCs provide hardware support for CoPP. CoPP works with the hardware rate limiters.

The PFC and DFCs support the built-in “special case” rate limiters that can be used when an ACL cannot classify particular scenarios, such as IP options cases, TTL and MTU failure cases, packets with errors, and multicast packets. When enabling the special-case rate limiters, the special-case rate limiters override the CoPP policy for packets matching the rate-limiter criteria.

The majority of traffic managed by the RP is handled by way of the control and management planes. You can use CoPP to protect the control and management planes, and ensure routing stability, reachability, and packet delivery. CoPP uses a dedicated control plane configuration through the modular QoS CLI (MQC) to provide filtering and rate-limiting capabilities for the control plane packets.

You must first identify the traffic to be classified by defining a class map. The class map defines packets for a particular traffic class. After you have classified the traffic, you can create policy maps to enforce policy actions for the identified traffic.

## Default Settings for CoPP

CoPP is enabled by default. To disable the default CoPP configuration, enter the **no service-policy input policy-default-autocopp** control plane configuration mode command.

These are the default CoPP class maps:

```
encuu/ocr"ocvej/cp{"encuu/eqrr/keor/tgfkgtgev/wptgcejcdng
encuu/ocr"ocvej/cnn"encuu/eqrr/ingcp
encuu/ocr"ocvej/cnn"encuu/eqrr/tgegkxg
encuu/ocr"ocvej/cnn"encuu/eqrr/qrvkqpu
encuu/ocr"ocvej/cnn"encuu/eqrr/dtqcfeuv
encuu/ocr"ocvej/cnn"encuu/eqrr/oecuv/cen/dtkfigf
encuu/ocr"ocvej/cnn"encuu/eqrr/und
encuu/ocr"ocvej/cnn"encuu/eqrr/ovw/hckn
encuu/ocr"ocvej/cnn"encuu/eqrr/vvn/hckn
encuu/ocr"ocvej/cnn"encuu/eqrr/ctr/upqqrkpi
encuu/ocr"ocvej/cp{"encuu/eqrr/oecuv/eqr{
encuu/ocr"ocvej/cp{"encuu/eqrr/kr/eqppgevgf
encuu/ocr"ocvej/cp{"encuu/eqrr/ocvej/kior
"ocvej"ceguu/itqwr"pcog"cen/eqrr/ocvej/kior
encuu/ocr"ocvej/cnn"encuu/eqrr/wmpqyp/rtqvqegn
encuu/ocr"ocvej/cp{"encuu/eqrr/xcen/nqi
encuu/ocr"ocvej/cnn"encuu/eqrr/oecuv/krx8/eqpvtqn
encuu/ocr"ocvej/cp{"encuu/eqrr/ocvej/rkox8/fcvc
"ocvej"ceguu/itqwr"pcog"cen/eqrr/ocvej/rkox8/fcvc
encuu/ocr"ocvej/cp{"encuu/eqrr/oecuv/rwpv
```

```

encuu/ocr"ocvej/cnn"encuu/eqrr/wpuwrr/tgytkvg
encuu/ocr"ocvej/cnn"encuu/eqrr/wecuv/gitguu/cen/dtkfigf
encuu/ocr"ocvej/cnn"encuu/eqrr/kr/cfokuukqp
encuu/ocr"ocvej/cnn"encuu/eqrr/ugtckeg/kpugtvmqp
encuu/ocr"ocvej/cnn"encuu/eqrr/oce/rdh
encuu/ocr"ocvej/cp{"encuu/eqrr/ocvej/onf
"ocvej"ceegu/itqwr"pcog"cen/eqrr/ocvej/onf
encuu/ocr"ocvej/cnn"encuu/eqrr/wecuv/kpitguu/cen/dtkfigf
encuu/ocr"ocvej/cnn"encuu/eqrr/fjer/upqqrkpi
encuu/ocr"ocvej/cnn"encuu/eqrr/yeer
encuu/ocr"ocvej/cnn"encuu/eqrr/pf
encuu/ocr"ocvej/cp{"encuu/eqrr/krx8/eqppgevgf
encuu/ocr"ocvej/cnn"encuu/eqrr/oecuv/trh/hckn
encuu/ocr"ocvej/cp{"encuu/eqrr/wecuv/trh/hckn
encuu/ocr"ocvej/cnn"encuu/eqrr/oecuv/kr/eqpvtqn
encuu/ocr"ocvej/cp{"encuu/eqrr/ocvej/rko/fcvc
"ocvej"ceegu/itqwr"pcog"cen/eqrr/ocvej/rko/fcvc
encuu/ocr"ocvej/cp{"encuu/eqrr/ocvej/pfx8
"ocvej"ceegu/itqwr"pcog"cen/eqrr/ocvej/pfx8
encuu/ocr"ocvej/cp{"encuu/eqrr/oecuv/x6/fcvc/qp/tqwgfRqtv
encuu/ocr"ocvej/cp{"encuu/eqrr/oecuv/x8/fcvc/qp/tqwgfRqtv

```

This is the default CoPP policy map:

```

rqnke{/ocr"rqnke{/fghcnv/cwvqeqrr
"encuu"encuu/eqrr/oecuv/x6/fcvc/qp/tqwgfRqtv
"rqnke"tcvg"32"rru"dwuv"3"rcemgvu"
 eqphqto/cevkqp"ftqr"
 gzeggf/cevkqp"ftqr"
"encuu"encuu/eqrr/oecuv/x8/fcvc/qp/tqwgfRqtv
"rqnke"tcvg"32"rru"dwuv"3"rcemgvu"
 eqphqto/cevkqp"ftqr"
 gzeggf/cevkqp"ftqr"
"encuu"encuu/eqrr/keor/tgfkge/vwptgcejcdng
"rqnke"tcvg"322"rru"dwuv"32"rcemgvu"
 eqphqto/cevkqp"vtcpuokv"
 gzeggf/cevkqp"ftqr"
"encuu"encuu/eqrr/wecuv/trh/hckn
"rqnke"tcvg"322"rru"dwuv"32"rcemgvu"
 eqphqto/cevkqp"vtcpuokv"
 gzeggf/cevkqp"ftqr"
"encuu"encuu/eqrr/xcen/nqi
"rqnke"tcvg"4222"rru"dwuv"3"rcemgvu"
 eqphqto/cevkqp"vtcpuokv"
 gzeggf/cevkqp"ftqr"
"encuu"encuu/eqrr/oecuv/rwpv
"rqnke"tcvg"3222"rru"dwuv"478"rcemgvu"
 eqphqto/cevkqp"vtcpuokv"
 gzeggf/cevkqp"ftqr"
"encuu"encuu/eqrr/oecuv/eqr{
"rqnke"tcvg"3222"rru"dwuv"478"rcemgvu"
 eqphqto/cevkqp"vtcpuokv"
 gzeggf/cevkqp"ftqr"
"encuu"encuu/eqrr/kr/eqppgevgf
"rqnke"tcvg"3222"rru"dwuv"478"rcemgvu"
 eqphqto/cevkqp"vtcpuokv"
 gzeggf/cevkqp"ftqr"
"encuu"encuu/eqrr/krx8/eqppgevgf
"rqnke"tcvg"3222"rru"dwuv"478"rcemgvu"
 eqphqto/cevkqp"vtcpuokv"
 gzeggf/cevkqp"ftqr"
"encuu"encuu/eqrr/ocvej/rko/fcvc

```

```

" " "rqnkeg"tcvg"3222"rru"dwtuv"3222"rcemgvu"
 eqphqto/cevkqp"vtcpuokv"
 gzeeggf/cevkqp"ftqr"
" "encuu"encuu/eqrr/ocvej/rkox8/fcvc
" " "rqnkeg"tcvg"3222"rru"dwtuv"3222"rcemgvu"
 eqphqto/cevkqp"vtcpuokv"
 gzeeggf/cevkqp"ftqr"
" "encuu"encuu/eqrr/ocvej/onf
" " "rqnkeg"tcvg"7222"rru"dwtuv"7222"rcemgvu"
 eqphqto/cevkqp"ugv/fkuectf/encuu/vtcpuokv"6:"
 gzeeggf/cevkqp"vtcpuokv"
" "encuu"encuu/eqrr/ocvej/kior
" " "rqnkeg"tcvg"7222"rru"dwtuv"7222"rcemgvu"
 eqphqto/cevkqp"ugv/fkuectf/encuu/vtcpuokv"6:"
 gzeeggf/cevkqp"vtcpuokv"
" "encuu"encuu/eqrr/ocvej/pfx8
" " "rqnkeg"tcvg"3222"rru"dwtuv"3222"rcemgvu"
 eqphqto/cevkqp"ugv/fkuectf/encuu/vtcpuokv"6:"
 gzeeggf/cevkqp"ftqr"

```

**Note**

The default policer rate for the MLD and IGMP classes has been updated to 5000 pps from the previous default value of 10000 pps. If the default policer rate for the MLD and IGMP classes is not set to 5000 pps, change the value manually by running the **no policy-map policy-default-autocopp** and **platform qos auto-copp** commands in global configuration mode.

## How to Configure CoPP

- [Configuring CoPP, page 77-5](#)
- [Defining CoPP Traffic Classification, page 77-6](#)

### Configuring CoPP

To configure CoPP, perform this task:

|        | Command                                                                                                                                                                                                                                                  | Purpose                                                                                                                                                                                                                                                                          |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%"kr"ceeguu/nkuv"gzvpgfgf"<br/>ceeguuanukuvapcog"</code>                                                                                                                                                                             | Creates an extended ACL.<br><br><b>Note</b> You must configure ACLs in most cases to identify the important or unimportant traffic.                                                                                                                                              |
| Step 2 | <code>Tqwvgt*eqphki/gzv/pcen+%" }rgtokv"~"fgp{ i"rtqvqeqn"<br/>uqwtteg"uqwtgayknfectf"fguvkpcvkqp"<br/>fguvkpcvkqpayknfectf"]rtgegfgpeg"rtgegfgpeg_<br/>]vqu"vqu_" ]guvcdnkujgf_" ]nqi"~"nqi/kprwv_<br/>]vkog/tcpig"vkogatcpigapcog_" ]htciogpvu_</code> | Configures filtering in the ACL:<br><ul style="list-style-type: none"><li>• <b>permit</b> sets the conditions under which a packet passes a named IP access list.</li><li>• <b>deny</b> sets the conditions under which a packet does not pass a named IP access list.</li></ul> |
| Step 3 | <code>Tqwvgt*eqphki+%"encuu/ocr"traffic_class_name</code>                                                                                                                                                                                                | Creates a class map.                                                                                                                                                                                                                                                             |
| Step 4 | <code>Tqwvgt*eqphki/eocr+%"ocvej"}kr"rtgegfgpeg"~"<br/>kr fuer"~"ceeguuaaitqwr;"</code>                                                                                                                                                                  | Configures matching in the class map.                                                                                                                                                                                                                                            |
| Step 5 | <code>Tqwvgt*eqphki+%"rqnke{/ocr"service-policy-name"</code>                                                                                                                                                                                             | Defines a service policy map.                                                                                                                                                                                                                                                    |
| Step 6 | <code>Tqwvgt*eqphki/rocr+%"encuu"vtchhkeaencuuapcog"</code>                                                                                                                                                                                              | Creates a policy map class.                                                                                                                                                                                                                                                      |

|        | Command                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Purpose                                                                                                                                                                                                                                                                                                                                |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 7 | <pre> Tqwvgt*eqphki/rocr/e+%"<b>rqnkeg</b>"<i>bits_per_second</i> ]pqtocnadwtuvad{vgu"}oczkwoadwtuvad{vgu__" ]rkt rgcmatcvgadru_" ]]<b>eqphqto/cevkqp</b> <i>ugngevgfacevkqp_"</i> <b>gzeggf/cevkqp</b> <i>ugngevgfacevkqp_"</i> <b>xkqncvg/cevkqp</b> <i>ugngevgfacevkqp_"</i>  Tqwvgt*eqphki/rocr/e+%"<b>rqnkeg</b>"<b>tcvg</b>"<i>wpkvu</i>"<b>dru</b>" ]dwtuv"dwttuvad{vgu"}<b>d{vgu_</b>" ]rgcm/tcvg" rgcmatcvgadru"dru_" ]rgcm/dwtuv rgcmadwtuvad{vgu" d{vgu_"}<b>eqphqto/cevkqp</b> <i>ugngevgfacevkqp_"</i> ] <b>gzeggf/cevkqp</b> <i>ugngevgfacevkqp_"</i> ] <b>xkqncvg/cevkqp</b> <i>ugngevgfacevkqp_"</i>  Tqwvgt*eqphki/rocr/e+%"<b>rqnkeg</b>"<b>tcvg</b>"<i>wpkvu</i>"<b>rru</b>" ]dwtuv dwttuvarcemgvu <b>rcemgvu</b>_" ]rgcm/tcvg rgcmatcvgaru"<b>rru_</b>" ]rgcm/dwtuv rgcmadwtuvarcemgvu"<b>rcemgvu_</b>" ] <b>eqphqto/cevkqp</b> <i>ugngevgfacevkqp_"</i> ] <b>gzeggf/cevkqp</b> <i>ugngevgfacevkqp_"</i> ] <b>xkqncvg/cevkqp</b> <i>ugngevgfacevkqp_"</i>  Tqwvgt*eqphki/rocr/e+%"<b>rqnkeg</b>"<b>hnqy</b>" ]ocum }ute/qpn{ ~ fguv/qpn{ ~ hwnn/hnqy;_" <i>bits_per_second normal_burst_bytes</i> ]]<b>eqphqto/cevkqp</b>" }ftqr ~" ugv/fuer/vtcpuokv <i>dscp_value</i> ~" ugv/rtge/vtcpuokv <i>ip_precedence_value</i> ~ vtcpuokv;_"<b>gzeggf/cevkqp</b>" }ftqr" ~"<b>rqnkegf/fuer</b>" ~" vtcpuokv;_"<b>xkqncvg/cevkqp</b> }ftqr" ~"<b>rqnkegf/fuer</b>" ~" vtcpuokv;_" </pre> | <p>Configures policing in the service policy map. You can configure any of the following:</p> <ul style="list-style-type: none"> <li>• Byte-based policing.</li> <li>• Packet-based policing.</li> <li>• Flow-based policing.</li> </ul> <p>See the <a href="#">“Configuring Policy Map Class Policing”</a> section on page 63-12.</p> |
| Step 8 | Tqwvgt*eqphki+%" <b>eqpvtqn/rncpg</b> "                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Enters the control plane configuration mode.                                                                                                                                                                                                                                                                                           |
| Step 9 | Tqwvgt*eqphki/er+%" <b>ugt<del>x</del>keg/rqnke</b> { " <b>kprwv</b> "<br><i>service-policy-name</i> "                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Applies the QoS service policy to the control plane.                                                                                                                                                                                                                                                                                   |

## Defining CoPP Traffic Classification

- [Traffic Classification Overview](#), page 77-6
- [Traffic Classification Restrictions](#), page 77-7
- [Sample Basic ACLs for CoPP Traffic Classification](#), page 77-8

### Traffic Classification Overview

You can define any number of classes, but typically traffic is grouped into classes that are based on relative importance. The following provides a sample grouping:

- Border Gateway Protocol (BGP)—Traffic that is crucial to maintaining neighbor relationships for BGP routing protocol, for example, BGP keepalives and routing updates. Maintaining BGP routing protocol is crucial to maintaining connectivity within a network or to a service provider. Sites that do not run BGP do not need to use this class.



- **Interior Gateway Protocol (IGP)**—Traffic that is crucial to maintaining IGP routing protocols, for example, open shortest path first OSPF, enhanced interior gateway routing protocol (EIGRP), and routing information protocol (RIP). Maintaining IGP routing protocols is crucial to maintaining connectivity within a network.
- **Management**—Necessary, frequently used traffic that is required during day-to-day operations. For example, traffic used for remote network access, and Cisco IOS image upgrades and management, such as Telnet, secure shell (SSH), network time protocol (NTP), simple network management protocol (SNMP), terminal access controller access control system (TACACS), hypertext transfer protocol (HTTP), trivial file transfer protocol (TFTP), and file transfer protocol (FTP).
- **Reporting**—Traffic used for generating network performance statistics for the purpose of reporting. For example, using Cisco IOS IP service level agreements (SLAs) to generate ICMP with different DSCP settings in order to report on response times within different QoS data classes.
- **Monitoring**—Traffic used for monitoring a switch. Traffic should be permitted but should never be a risk to the switch; with CoPP, this traffic can be permitted but limited to a low rate. For example, ICMP echo request (ping) and traceroute.
- **Critical Applications**—Critical application traffic that is specific and crucial to a particular customer environment. Traffic included in this class should be tailored specifically to the required application requirements of the user (in other words, one customer may use multicast, while another uses IPsec or generic routing encapsulation (GRE). For example, GRE, hot standby router protocol (HSRP), virtual router redundancy protocol (VRRP), session initiation protocol (SIP), data link switching (DLSw), dynamic host configuration protocol (DHCP), multicast source discovery protocol (MSDP), Internet group management protocol (IGMP), protocol independent multicast (PIM), multicast traffic, and IPsec.
- **Layer 2 Protocols**—Traffic used for address resolution protocol (ARP). Excessive ARP packets can potentially monopolize RP resources, starving other important processes; CoPP can be used to rate limit ARP packets to prevent this situation. ARP is the only Layer 2 protocol that can be specifically classified using the match protocol classification criteria.
- **Undesirable**—Explicitly identifies bad or malicious traffic that should be unconditionally dropped and denied access to the RP. The undesirable classification is particularly useful when known traffic destined for the switch should always be denied and not placed into a default category. If you explicitly deny traffic, then you can enter **show** commands to collect approximate statistics on the denied traffic and estimate its rate.
- **Default**—All remaining traffic destined for the RP that has not been identified. MQC provides the default class, so the user can specify the treatment to be applied to traffic not explicitly identified in the other user-defined classes. This traffic has a highly reduced rate of access to the RP. With a default classification in place, statistics can be monitored to determine the rate of otherwise unidentified traffic destined for the control plane. After this traffic is identified, further analysis can be performed to classify it and, if needed, the other CoPP policy entries can be updated to accommodate this traffic.

After you have classified the traffic, the ACLs build the classes of traffic that are used to define the policies. For sample basic ACLs for CoPP classification, see the [“Sample Basic ACLs for CoPP Traffic Classification” section on page 77-8](#).

## Traffic Classification Restrictions

- Before you develop the actual CoPP policy, you must identify and separate the required traffic into different classes. Traffic is grouped into nine classes that are based on relative importance. The actual number of classes needed might differ and should be selected based on your local requirements and security policies.

- You do not have to define policies that match bidirectionally. You only need to identify traffic unidirectionally (from the network to the RP) since the policy is applied on ingress only.

## Sample Basic ACLs for CoPP Traffic Classification

This section shows sample basic ACLs for CoPP classification. In the samples, the commonly required traffic is identified with these ACLs:

- ACL 120—Critical traffic
- ACL 121—Important traffic
- ACL 122—Normal traffic
- ACL 123—Explicitly denies unwanted traffic
- ACL 124—All other traffic

This example shows how to define ACL 120 for critical traffic:

```
Tqwgvt*eqphki+% "ceeguu/nkuv"342"tgoctm"EqRR"CEN"hqt"etkvkecn"vtchhke
```

This example shows how to allow BGP from a known peer to this switch's BGP TCP port:

```
Tqwgvt*eqphki+% "ceeguu/nkuv"342"rgtokv"ver"jquv"69030303"jquv"320;0;0;"gs"dir
```

This example shows how to allow BGP from a peer's BGP port to this switch:

```
Tqwgvt*eqphki+% "ceeguu/nkuv"342"rgtokv"ver"jquv"69030303"gs"dir"jquv"320;0;0;
Tqwgvt*eqphki+% "ceeguu/nkuv"342"rgtokv"ver"jquv"320:803:50342"jquv"320;0;0;"gs"dir
Tqwgvt*eqphki+% "ceeguu/nkuv"342"rgtokv"ver"jquv"320:803:50342"gs"dir"jquv"320;0;0;
```

This example shows how to define ACL 121 for the important class:

```
Tqwgvt*eqphki+% "ceeguu/nkuv"343"tgoctm"EqRR"Korqtvcpv"vtchhke
```

This example shows how to permit return traffic from TACACS host:

```
Tqwgvt*eqphki+% "ceeguu/nkuv"343"rgtokv"ver"jquv"32030303"jquv"320;0;0;"guvcdnkujgf
```

This example shows how to permit SSH access to the switch from a subnet:

```
Tqwgvt*eqphki+% "ceeguu/nkuv"343"rgtokv"ver"32020202"202020477"jquv"320;0;0;"gs"44
```

This example shows how to allow full access for Telnet to the switch from a host in a specific subnet and police the rest of the subnet:

```
Tqwgvt*eqphki+% "ceeguu/nkuv"343"fgp{"ver"jquv"320:803:505"cp{"gs"vgnpgv
Tqwgvt*eqphki+% "ceeguu/nkuv"343"rgtokv"ver"320:803:502"202020477"cp{"gs"vgnpgv
```

This example shows how to allow SNMP access from the NMS host to the switch:

```
Tqwgvt*eqphki+% "ceeguu/nkuv"343"rgtokv"wfr"jquv"32030304"jquv"320;0;0;"gs"upor
```

This example shows how to allow the switch to receive NTP packets from a known clock source:

```
Tqwgvt*eqphki+% "ceeguu/nkuv"343"rgtokv"wfr"jquv"32030305"jquv"320;0;0;"gs"pvr
```

This example shows how to define ACL 122 for the normal traffic class:

```
Tqwgvt*eqphki+% "ceeguu/nkuv"344"tgoctm"EqRR"pqtoen"vtchhke
```

This example shows how to permit switch-originated traceroute traffic:

```
Tqwgvt*eqphki+% "ceeguu/nkuv"344"rgtokv"keor"cp{"cp{"vvn/gzeggf
Tqwgvt*eqphki+% "ceeguu/nkuv"344"rgtokv"keor"cp{"cp{"rqtv/wptgcejcdng
```

This example shows how to permit receipt of responses to the switch that originated the pings:

```
Tqwnvgt*eqphki+%ceeguu/nkuv"344"rgtokv"keor"cp{"cp{"gejq/tgrn{"
```

This example shows how to allow pings to the switch:

```
Tqwnvgt*eqphki+%ceeguu/nkuv"344"rgtokv"keor"cp{"cp{"gejq
```

This example shows how to define ACL 123 for the undesirable class.

```
Tqwnvgt*eqphki+%ceeguu/nkuv"345"tgoctm"gzrnkekv{"fghkpgf"$wpfguktcdng$"vtchhke
```



#### Note

In the following example, ACL 123 is a permit entry for classification and monitoring purposes, and traffic is dropped as a result of the CoPP policy.

This example shows how to permit all traffic destined to UDP 1434 for policing:

```
Tqwnvgt*eqphki+%ceeguu/nkuv"345"rgtokv"wfr"cp{"cp{"gs"3656
```

This example shows how to define ACL 124 for all other traffic:

```
Tqwnvgt*eqphki+%ceeguu/nkuv"346"tgoctm"tguv"qh"vjg"KR"vtchhke"hqt"EqRR
Tqwnvgt*eqphki+%ceeguu/nkuv"346"rgtokv"kr"cp{"cp{"
```

## Monitoring CoPP

You can enter the **show policy-map control-plane** command for developing site-specific policies, monitoring statistics for the control plane policy, and troubleshooting CoPP. This command displays dynamic information about the actual policy applied, including rate information and the number of bytes (and packets) that conformed or exceeded the configured policies both in hardware and in software.

The output of the **show policy-map control-plane** command is as follows:

```
Tqwnvgt%"ujqy"rqnke{/ocr"eqpvtqn/rncpg"
Eqpvtqn"Rncpg"Kpvgthceg
"Ugtxkeg"rqnke{"EqRR/pqtoen
Jctfycgtg"Eqwpvgtu<
encuu/ocr<"EqRR/pqtoen"*ocvej/cnn+
"Ocvej<"ceeguu/itqwr"352
"rqnkeg"<
";8222"dru"5222"nkokv"5222"gzvgpfgf"nkokv
"Gctn"kp"unqv"5"<
"2"d{vgu
"7"okpwvg"qhhgtgf"tcvg"2"dru
"ciitgicvg/hqtyctfgf"2"d{vgu"cevkqp<"vtcpuokv
"gzegfgf"2"d{vgu"cevkqp<"ftqr
"ciitgicvg/hqtyctf"2"dru"gzegfg"2"dru"
"Gctn"kp"unqv"7"<
"2"d{vgu
"7"okpwvg"qhhgtgf"tcvg"2"dru
"ciitgicvg/hqtyctfgf"2"d{vgu"cevkqp<"vtcpuokv
"gzegfgf"2"d{vgu"cevkqp<"ftqr
"ciitgicvg/hqtyctf"2"dru"gzegfg"2"dru"

Ughvyctg"Eqwpvgtu<
"Encuu/ocr<"EqRR/pqtoen"*ocvej/cnn+"2"rcemgvu."2"d{vgu
"7"okpwvg"qhhgtgf"tcvg"2"dru."ftqr"tcvg"2"dru
"Ocvej<"ceeguu/itqwr"352
"rqnkeg<
";8222"dru."5347"nkokv."5347"gzvgpfgf"nkokv
```

```
" "" "" "" "" "eqphqtogf"2"rcemgvu."2"d{vgu="cevkqp<"vtcpuokv

" "" "" "" "" "gzegfgf"2"rcemgvu."2"d{vgu="cevkqp<"ftqr

" "" "" "" "" "eqphqtogf"2"dru."gzegfgf"2"dru."xqncvg"2"dru"

Tawvat%
```

To display the hardware counters for bytes dropped and forwarded by the policy, enter the **show platform qos ip** command:

```
Tqwgvt%"ujqy"rnvqhcto"squ"kr"
"SQU"Uwooct{" "]KR_<""""""""","/"ujctgf"ciitgicvgu."Oqf"/"uykvej"oqfwng+

Kpv"Oqf"Fkt""Encuu/ocr"FUER"Cii""Vtwuv"Hn""CiHqtyctf/D{" ""CiRqnkegf/D{
""""""""""""""""""""""""""""""""Kf""""""""""Kf""""""""""""""""""""""""""""""""
//
ERR""7""Kp"EgRR/pqtoen""""2""""3""""fuer""2""""""""""72762:"""""""":5:44494
ERR"";""Kp"EgRR/pqtoen""""2""""6""""fuer""2""""""""""2""""""""""""""""""""2
Tqwgvt%
```

To display the CoPP access list information, enter the **show access-lists coppacl-bgp** command:

```
Tqvwgt%"ujqy"ceeguu/nkuvu"eqrrcen/dir"
Gzvgpfgf"KR"ceeguu"nkuv"eqrrcen/dir
32"rgtokv"ver"jqvu"69030303"jqvu"320;0;0;"gs"dir"*6"ocvejgu+
42"rgtokv"ver"jqvu"69030303"gs"dir"jqvu"320;0;0;
52"rgtokv"ver"jqvu"320:803:50342"jqvu"320;0;0;"gs"dir"*3"ocvej+
62"rgtokv"ver"jqvu"320:803:50342"gs"dir"jqvu"320;0;0;
```



**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

Participate in the [Technical Documentation Ideas forum](#)



# Dynamic Host Configuration Protocol (DHCP) Snooping

- [Prerequisites for DHCP Snooping, page 78-1](#)
- [Restrictions for DHCP Snooping, page 78-2](#)
- [Information About DHCP Snooping, page 78-3](#)
- [Default Configuration for DHCP Snooping, page 78-8](#)
- [How to Configure DHCP Snooping, page 78-9](#)



## Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for DHCP Snooping

None.

## Restrictions for DHCP Snooping

- [DHCP Snooping Configuration Restrictions, page 78-2](#)
- [DHCP Snooping Configuration Guidelines, page 78-2](#)
- [Minimum DHCP Snooping Configuration, page 78-3](#)

## DHCP Snooping Configuration Restrictions

- The DHCP snooping database stores at least 12,000 bindings.
- When DHCP snooping is enabled, these Cisco IOS DHCP commands are not available on the switch:
  - **ip dhcp relay information check** global configuration command
  - **ip dhcp relay information policy** global configuration command
  - **ip dhcp relay information trust-all** global configuration command
  - **ip dhcp relay information option** global configuration command
  - **ip dhcp relay information trusted** interface configuration command

If you enter these commands, the switch returns an error message, and the configuration is not applied.

## DHCP Snooping Configuration Guidelines

- DHCP snooping is not active until you enable the feature on at least one VLAN, and enable DHCP globally on the switch.
- Before globally enabling DHCP snooping on the switch, make sure that the devices acting as the DHCP server and the DHCP relay agent are configured and enabled.
- For DHCP server configuration information, see this publication:  
[http://www.cisco.com/en/US/docs/ios-xml/ios/ipaddr\\_dhcp/configuration/15-sy/dhcp-15-sy-book.html](http://www.cisco.com/en/US/docs/ios-xml/ios/ipaddr_dhcp/configuration/15-sy/dhcp-15-sy-book.html)
- If a Layer 2 LAN port is connected to a DHCP server, configure the port as trusted by entering the **ip dhcp snooping trust** interface configuration command.
- If a Layer 2 LAN port is connected to a DHCP client, configure the port as untrusted by entering the **no ip dhcp snooping trust** interface configuration command.
- You can enable DHCP snooping on private VLANs:
  - If DHCP snooping is enabled, any primary VLAN configuration is propagated to its associated secondary VLANs.
  - If DHCP snooping is configured on the primary VLAN and you configure DHCP snooping with different settings on an associated secondary VLAN, the configuration on the secondary VLAN does not take effect.
  - If DHCP snooping is not configured on the primary VLAN and you configure DHCP snooping on a secondary VLAN, the configuration takes affect only on the secondary VLAN.
  - When you manually configure DHCP snooping on a secondary VLAN, this message appears:

```
FJER"Upqqrkpi"eqphkiwtcvkqp"oc{"pqv"vcmg"ghhgev"qp"ugeqpfct{"xncp"ZZZ
```

- The **show ip dhcp snooping** command displays all VLANs (both primary and secondary) that have DHCP snooping enabled.

## Minimum DHCP Snooping Configuration

1. Define and configure the DHCP server. See this publication:  
[http://www.cisco.com/en/US/docs/ios-xml/ios/ipaddr\\_dhcp/configuration/15-sy/dhcp-15-sy-book.html](http://www.cisco.com/en/US/docs/ios-xml/ios/ipaddr_dhcp/configuration/15-sy/dhcp-15-sy-book.html)
2. Enable DHCP snooping on at least one VLAN.  
By default, DHCP snooping is inactive on all VLANs. See the “[Enabling DHCP Snooping on VLANs](#)” section on page 78-11
3. Ensure that DHCP server is connected through a trusted interface.  
By default, the trust state of all interfaces is untrusted. See the “[Configuring the DHCP Trust State on Layer 2 LAN Interfaces](#)” section on page 78-12
4. Configure the DHCP snooping database agent.  
This step ensures that database entries are restored after a restart or switchover. See the “[The DHCP Snooping Database Agent](#)” section on page 78-14
5. Enable DHCP snooping globally.  
The feature is not active until you complete this step. See the “[Enabling DHCP Snooping Globally](#)” section on page 78-9

If you are configuring the switch for DHCP relay, the following additional steps are required:

1. Define and configure the DHCP relay agent IP address.  
If the DHCP server is in a different subnet from the DHCP clients, configure the server IP address in the helper address field of the client side VLAN.
2. Configure DHCP option-82 on untrusted port.  
See the “[Enabling the DHCP Option-82 on Untrusted Port Feature](#)” section on page 78-10

## Information About DHCP Snooping

- [Overview of DHCP Snooping, page 78-4](#)
- [Trusted and Untrusted Sources, page 78-4](#)
- [DHCP Snooping Binding Database, page 78-5](#)
- [Packet Validation, page 78-5](#)
- [DHCP Snooping Option-82 Data Insertion, page 78-5](#)
- [Overview of the DHCP Snooping Database Agent, page 78-7](#)

## Overview of DHCP Snooping

DHCP snooping is a security feature that acts like a firewall between untrusted hosts and trusted DHCP servers. The DHCP snooping feature performs the following activities:

- Validates DHCP messages received from untrusted sources and filters out invalid messages.
- Rate-limits DHCP traffic from trusted and untrusted sources.
- Builds and maintains the DHCP snooping binding database, which contains information about untrusted hosts with leased IP addresses.
- Utilizes the DHCP snooping binding database to validate subsequent requests from untrusted hosts.

Other security features, such as dynamic ARP inspection (DAI), also use information stored in the DHCP snooping binding database.

DHCP snooping is enabled on a per-VLAN basis. By default, the feature is inactive on all VLANs. You can enable the feature on a single VLAN or a range of VLANs.

The DHCP snooping feature is implemented in software on the route processor (RP). Therefore, all DHCP messages for enabled VLANs are intercepted in the PFC and directed to the RP for processing.

## Trusted and Untrusted Sources

The DHCP snooping feature determines whether traffic sources are trusted or untrusted. An untrusted source may initiate traffic attacks or other hostile actions. To prevent such attacks, the DHCP snooping feature filters messages and rate-limits traffic from untrusted sources.

In an enterprise network, devices under your administrative control are trusted sources. These devices include the switches, routers, and servers in your network. Any device beyond the firewall or outside your network is an untrusted source. Host ports and unknown DHCP servers are generally treated as untrusted sources.

A DHCP server that is on your network without your knowledge on an untrusted port is called a *spurious DHCP server*. A spurious DHCP server is any piece of equipment that is loaded with DHCP server enabled. Some examples are desktop systems and laptop systems that are loaded with DHCP server enabled, or wireless access points honoring DHCP requests on the wired side of your network. If spurious DHCP servers remain undetected, you will have difficulties troubleshooting a network outage. You can detect spurious DHCP servers by sending dummy DHCPDISCOVER packets out to all of the DHCP servers so that a response is sent back to the switch.

In a service provider environment, any device that is not in the service provider network is an untrusted source (such as a customer switch). Host ports are untrusted sources.

In the switch, you indicate that a source is trusted by configuring the trust state of its connecting interface.

The default trust state of all interfaces is untrusted. You must configure DHCP server interfaces as trusted. You can also configure other interfaces as trusted if they connect to devices (such as switches or routers) inside your network. You usually do not configure host port interfaces as trusted.



### Note

For DHCP snooping to function properly, all DHCP servers must be connected to the switch through trusted interfaces, as untrusted DHCP messages will be forwarded only to trusted interfaces.



## DHCP Snooping Binding Database

The DHCP snooping binding database is also referred to as the DHCP snooping binding table.

The DHCP snooping feature dynamically builds and maintains the database using information extracted from intercepted DHCP messages. The database contains an entry for each untrusted host with a leased IP address if the host is associated with a VLAN that has DHCP snooping enabled. The database does not contain entries for hosts connected through trusted interfaces.

The DHCP snooping feature updates the database when the switch receives specific DHCP messages. For example, the feature adds an entry to the database when the switch receives a DHCPACK message from the server. The feature removes the entry in the database when the IP address lease expires or the switch receives a DHCPRELEASE message from the host.

Each entry in the DHCP snooping binding database includes the MAC address of the host, the leased IP address, the lease time, the binding type, and the VLAN number and interface information associated with the host.

## Packet Validation

The switch validates DHCP packets received on the untrusted interfaces of VLANs with DHCP snooping enabled. The switch forwards the DHCP packet unless any of the following conditions occur (in which case the packet is dropped):

- The switch receives a packet (such as a DHCPOFFER, DHCPACK, DHCPNAK, or DHCPLEASEQUERY packet) from a DHCP server outside the network or firewall.
- The switch receives a packet on an untrusted interface, and the source MAC address and the DHCP client hardware address do not match. This check is performed only if the DHCP snooping MAC address verification option is turned on.
- The switch receives a DHCPRELEASE or DHCPDECLINE message from an untrusted host with an entry in the DHCP snooping binding table, and the interface information in the binding table does not match the interface on which the message was received.
- The switch receives a DHCP packet that includes a relay agent IP address that is not 0.0.0.0.

To support trusted edge switches that are connected to untrusted aggregation-switch ports, you can enable the DHCP option-82 on untrusted port feature, which enables untrusted aggregation-switch ports to accept DHCP packets that include option-82 information. Configure the port on the edge switch that connects to the aggregation switch as a trusted port.

**Note**


With the DHCP option-82 on untrusted port feature enabled, use dynamic ARP inspection on the aggregation switch to protect untrusted input interfaces.

## DHCP Snooping Option-82 Data Insertion

In residential, metropolitan Ethernet-access environments, DHCP can centrally manage the IP address assignments for a large number of subscribers. When the DHCP snooping option-82 feature is enabled on the switch, a subscriber device is identified by the switch port through which it connects to the network (in addition to its MAC address). Multiple hosts on the subscriber LAN can be connected to the same port on the access switch and are uniquely identified.

Figure 78-1 is an example of a metropolitan Ethernet network in which a centralized DHCP server assigns IP addresses to subscribers connected to the switch at the access layer. Because the DHCP clients and their associated DHCP server do not reside on the same IP network or subnet, a DHCP relay agent is configured with a helper address to enable broadcast forwarding and to transfer DHCP messages between the clients and the server.

**Figure 78-1** DHCP Relay Agent in a Metropolitan Ethernet Network



When you enable the DHCP snooping information option-82 on the switch, this sequence of events occurs:

- The host (DHCP client) generates a DHCP request and broadcasts it on the network.
- When the switch receives the DHCP request, it adds the option-82 information in the packet. The option-82 information contains the switch MAC address (the remote ID suboption) and the port identifier, vlan-mod-port, from which the packet is received (the circuit ID suboption).
- If IEEE 802.1X port-based authentication is enabled, the switch will also add the host's 802.1X authenticated user identity information (the RADIUS attributes suboption) to the packet. See the [“802.1X Authentication with DHCP Snooping”](#) section on page 83-15.
- If the IP address of the relay agent is configured, the switch adds the IP address in the DHCP packet.
- The switch forwards the DHCP request that includes the option-82 field to the DHCP server.
- The DHCP server receives the packet. If the server is option-82 capable, it can use the remote ID, or the circuit ID, or both to assign IP addresses and implement policies, such as restricting the number of IP addresses that can be assigned to a single remote ID or circuit ID. The DHCP server then echoes the option-82 field in the DHCP reply.
- The DHCP server unicasts the reply to the switch if the request was relayed to the server by the switch. When the client and server are on the same subnet, the server broadcasts the reply. The switch verifies that it originally inserted the option-82 data by inspecting the remote ID and possibly the circuit ID fields. The switch removes the option-82 field and forwards the packet to the switch port that connects to the DHCP client that sent the DHCP request.

When the previously described sequence of events occurs, the values in these fields in Figure 78-2 do not change:


- Circuit ID suboption fields
  - Suboption type
  - Length of the suboption type

- Circuit ID type
- Length of the circuit ID type
- Remote ID suboption fields
  - Suboption type
  - Length of the suboption type
  - Remote ID type
  - Length of the circuit ID type

Figure 78-2 shows the packet formats for the remote ID suboption and the circuit ID suboption. The switch uses the packet formats when DHCP snooping is globally enabled and when the **ip dhcp snooping information option** global configuration command is entered. For the circuit ID suboption, the module field is the slot number of the module.

Figure 78-2 Suboption Packet Formats

#### Circuit ID Suboption Frame Format



#### Remote ID Suboption Frame Format



## Overview of the DHCP Snooping Database Agent

To retain the bindings across reloads, you must use the DHCP snooping database agent. Without this agent, the bindings established by DHCP snooping are lost upon reload, and connectivity is lost as well.

The database agent stores the bindings in a file at a configured location. Upon reload, the switch reads the file to build the database for the bindings. The switch keeps the file current by writing to the file as the database changes.

The format of the file that contains the bindings is as follows:

```
>kpkvkc n/ e j g e m u w o @
V [RG" FJER/UPQQRKPI
XGTUKQP" 3
DGIKP
>gpvt { /3@" > e j g e m u w o /3@
```

```
>gpvt{/4@>ejgemuwo/3/4@
000
000
>gpvt{/p@>ejgemuwo/3/4/00/p@
GPF
```

Each entry in the file is tagged with a checksum that is used to validate the entries whenever the file is read. The <initial-checksum> entry on the first line helps distinguish entries associated with the latest write from entries that are associated with a previous write.

This is a sample bindings file:

```
5gdg373:
V[RG"FJER/UPQQRKPI
XGTUKQP"3
DGIKP
32030303"734"22230222302227"5GDG4::3"Ik313""g7g3g955
32030303"734"22230222302224"5GDG4::3"Ik313""6d56:8ge
32030303"3758"22230222302226"5GDG4::3"Ik313""h2g24:94
32030303"3246"22230222302225"5GDG4::3"Ik313""ce63cfh;
32030303"3"22230222302223"5GDG4::3"Ik313""56d5495g
GPF
```

Each entry holds an IP address, VLAN, MAC address, lease time (in hex), and the interface associated with a binding. At the end of each entry is a checksum that is based on all the bytes from the start of the file through all the bytes associated with the entry. Each entry consists of 72 bytes of data, followed by a space, followed by a checksum.

Upon bootup, when the calculated checksum equals the stored checksum, the switch reads entries from the file and adds the bindings to the DHCP snooping database. If the calculated checksum does not equal the stored checksum, the entry read from the file is ignored and so are all the entries following the failed entry. The switch also ignores all those entries from the file whose lease time has expired. (This is possible because the lease time might indicate an expired time.) An entry from the file is also ignored if the interface referred to in the entry no longer exists on the system, or if it is a router port or a DHCP snooping-trusted interface.

When the switch learns of new bindings or when it loses some bindings, the switch writes the modified set of entries from the snooping database to the file. The writes are performed with a configurable delay to batch as many changes as possible before the actual write happens. Associated with each transfer is a timeout after which a transfer is aborted if it is not completed. These timers are referred to as the write delay and abort timeout.

## Default Configuration for DHCP Snooping

| Option                                   | Default Value/State |
|------------------------------------------|---------------------|
| DHCP snooping                            | Disabled            |
| DHCP snooping information option         | Enabled             |
| DHCP option-82 on untrusted port feature | Disabled            |
| DHCP snooping limit rate                 | None                |
| DHCP snooping trust                      | Untrusted           |
| DHCP snooping vlan                       | Disabled            |

| Option                                  | Default Value/State |
|-----------------------------------------|---------------------|
| DHCP snooping spurious server detection | Disabled            |
| DHCP snooping detect spurious interval  | 30 minutes          |

## How to Configure DHCP Snooping

- [Enabling DHCP Snooping Globally, page 78-9](#)
- [Enabling DHCP Option-82 Data Insertion, page 78-10](#)
- [Enabling the DHCP Option-82 on Untrusted Port Feature, page 78-10](#)
- [Enabling DHCP Snooping MAC Address Verification, page 78-11](#)
- [Enabling DHCP Snooping on VLANs, page 78-11](#)
- [Configuring the DHCP Trust State on Layer 2 LAN Interfaces, page 78-12](#)
- [Configuring Spurious DHCP Server Detection, page 78-13](#)
- [Configuring DHCP Snooping Rate Limiting on Layer 2 LAN Interfaces, page 78-14](#)
- [The DHCP Snooping Database Agent, page 78-14](#)
- [Configuration Examples for the Database Agent, page 78-15](#)
- [Displaying the DHCP Snooping Binding Table, page 78-18](#)

## Enabling DHCP Snooping Globally



### Note

Configure this command as the last configuration step (or enable the DHCP feature during a scheduled maintenance period) because after you enable DHCP snooping globally, the switch drops DHCP requests until you configure the ports.

To enable DHCP snooping globally, perform this task:

|        | Command                                                                  | Purpose                         |
|--------|--------------------------------------------------------------------------|---------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "kr"fjer"upqqrkpi"</code>                          | Enables DHCP snooping globally. |
| Step 2 | <code>Tqwvgt*eqphki+% "fq"ujqy"kr"fjer"upqqrkpi"~"kpenwfg"Uykvej"</code> | Verifies the configuration.     |

This example shows how to enable DHCP snooping globally:

```
Tqwvgt%"eqphkiwtg"vgtokpcn"
GpvgT"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkpg0""Gpf"ykvj"EPVN1\0
Tqwvgt*eqphki+% "kr"fjer"upqqrkpi"
Tqwvgt*eqphki+% "fq"ujqy"kr"fjer"upqqrkpi"~"kpenwfg"Uykvej"
Uykvej"FJER"upqqrkpi"ku"gpdcngf
Tqwvgt*eqphki+% "
```

**Note**

When DHCP snooping is disabled and DAI is enabled, the switch shuts down all the hosts because all ARP entries in the ARP table will be checked against a nonexistent DHCP database. When DHCP snooping is disabled or in non-DHCP environments, use ARP ACLs to permit or to deny ARP packets.

## Enabling DHCP Option-82 Data Insertion

To enable DHCP option-82 data insertion, perform this task:

|        | Command                                                               | Purpose                                |
|--------|-----------------------------------------------------------------------|----------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "kr"fjer"upqqrkpi" kphqto cvkqp "qrvkqp"</code> | Enables DHCP option-82 data insertion. |
| Step 2 | <code>Tqvwgt*eqphki+% "fq"ujqy"kr"fjer"upqqrkpi"~" kpenwfg":4"</code> | Verifies the configuration.            |

This example shows how to disable DHCP option-82 data insertion:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
GpvgT"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0" "Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+% "pq"kr"fjer"upqqrkpi" kphqto cvkqp "qrvkqp"
Tqvwgt*eqphki+% "fq"ujqy"kr"fjer"upqqrkpi"~" kpenwfg":4"
Kpugt vkqp"qh"qrvkqp":4"ku"fkucdngf
Tqvwgt*eqphki+%
```

This example shows how to enable DHCP option-82 data insertion:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
GpvgT"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0" "Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+% "kr"fjer"upqqrkpi" kphqto cvkqp "qrvkqp"
Tqvwgt*eqphki+% "fq"ujqy"kr"fjer"upqqrkpi"~" kpenwfg":4"
Kpugt vkqp"qh"qrvkqp":4"ku"gpdcngf
Tqvwgt*eqphki+%
```

## Enabling the DHCP Option-82 on Untrusted Port Feature

**Note**

With the DHCP option-82 on untrusted port feature enabled, the switch does not drop DHCP packets that include option-82 information that are received on untrusted ports. Do not enter the **ip dhcp snooping information option allowed-untrusted** command on an aggregation switch to which any untrusted devices are connected.

To enable untrusted ports to accept DHCP packets that include option-82 information, perform this task:

|        | Command                                                                                | Purpose                                                                                                                            |
|--------|----------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "kr"fjer"upqqrkpi" kphqto cvkqp "qrvkqp" cnnqy/wpvtwuvfg"</code> | (Optional) Enables untrusted ports to accept incoming DHCP packets with option-82 information.<br>The default setting is disabled. |
| Step 2 | <code>Tqvwgt*eqphki+% "fq"ujqy"kr"fjer"upqqrkpi"</code>                                | Verifies the configuration.                                                                                                        |

This example shows how to enable the DHCP option-82 on untrusted port feature:

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpq"rgt"nkpq0""Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%"kr"fjer"upqqrkpi"kphqtoocvkqp"qrvkqp"cnngy/wpvtwuvvf"
Tqvwgt*eqphki+%
```

## Enabling DHCP Snooping MAC Address Verification

With DHCP snooping MAC address verification enabled, DHCP snooping verifies that the source MAC address and the client hardware address match in DHCP packets that are received on untrusted ports. The source MAC address is a Layer 2 field associated with the packet, and the client hardware address is a Layer 3 field in the DHCP packet.

To enable DHCP snooping MAC address verification, perform this task:

|        | Command                                                                        | Purpose                                         |
|--------|--------------------------------------------------------------------------------|-------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%"<b>kr"fjer"upqqrkpi"xgtkh{"oce/cfftguu"</b></code>       | Enables DHCP snooping MAC address verification. |
| Step 2 | <code>Tqvwgt*eqphki+%"<b>fq"ujqy"kr"fjer"upqqrkpi"~"kpenwfg"jycfft"</b></code> | Verifies the configuration.                     |

This example shows how to disable DHCP snooping MAC address verification:

```
Tqvwgt*eqphki+%"pq"kr"fjer"upqqrkpi"xgtkh{"oce/cfftguu"
Tqvwgt*eqphki+%"fq"ujqy"kr"fjer"upqqrkpi"~"kpenwfg"jycfft"
Xgtkhkecvkqp"qh"jycfft"hkgnf"ku"fkucdngf
Tqvwgt*eqphki+%
```

This example shows how to enable DHCP snooping MAC address verification:

```
Tqvwgt*eqphki+%"kr"fjer"upqqrkpi"xgtkh{"oce/cfftguu"
Tqvwgt*eqphki+%"fq"ujqy"kr"fjer"upqqrkpi"~"kpenwfg"jycfft"
Xgtkhkecvkqp"qh"jycfft"hkgnf"ku"gpdcngf
Tqvwgt*eqphki+%
```

## Enabling DHCP Snooping on VLANs

By default, the DHCP snooping feature is inactive on all VLANs. You may enable the feature on a single VLAN or a range of VLANs.

When enabled on a VLAN, the DHCP snooping feature creates four entries in the VACL table in the MFC3. These entries cause the PFC or DFC to intercept all DHCP messages on this VLAN and send them to the RP. The DHCP snooping feature is implemented in software on the RP.

To enable DHCP snooping on VLANs, perform this task:

|        | Command                                                                                                                         | Purpose                                        |
|--------|---------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%"<b>kr"fjer"upqqrkpi"xncp"}}</b><code> }vlan_ID"</code><br/><code>]vlan_ID_1"~"}xncpatcpig1"</code></code> | Enables DHCP snooping on a VLAN or VLAN range. |
| Step 2 | <code>Tqvwgt*eqphki+%"<b>fq"ujqy"kr"fjer"upqqrkpi"</b></code>                                                                   | Verifies the configuration.                    |

You can configure DHCP snooping for a single VLAN or a range of VLANs:

- To configure a single VLAN, enter a single VLAN number.
- To configure a range of VLANs, enter a beginning and an ending VLAN number or a dash-separated pair of VLAN numbers.
- You can enter a comma-separated list of VLAN numbers and dash-separated pairs of VLAN numbers.

This example shows how to enable DHCP snooping on VLANs 10 through 12:

```
Tqwgvt% "eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+% "kr"fjer"upqqrkpi"xncp"32"34 "
Tqwgvt*eqphki+% "
```

This example shows another way to enable DHCP snooping on VLANs 10 through 12:

```
Tqwgvt% "eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+% "kr"fjer"upqqrkpi"xncp"32/34 "
```

This example shows another way to enable DHCP snooping on VLANs 10 through 12:

```
Tqwgvt% "eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+% "kr"fjer"upqqrkpi"xncp"32.33.34 "
```

This example shows how to enable DHCP snooping on VLANs 10 through 12 and VLAN 15:

```
Tqwgvt% "eqphkiwtg"vgtokpcn"
Tqwgvt*eqphki+% "kr"fjer"upqqrkpi"xncp"32/34.37 "
```

This example shows how to verify the configuration:

```
Tqwgvt*eqphki+% "fq"ujqy"kr"fjer"upqqrkpi "
Uykvej "FJER"upqqrkpi "ku"gpdcngf
FJER"upqqrkpi "ku"eqphkiwtgf"qp"hqnnqykpi "XNCPu<
32/34.37
FJER"upqqrkpi "ku"qrgtcvkqpcn"qp"hqnnqykpi "XNCPu<
pqp9
FJER"upqqrkpi "ku"eqphkiwtgf"qp"vjg"hqnnqykpi "Kpvgthcegu<

Kpugtvkqp"qh"qrvkqp":4"ku"gpdcngf
Xgtkhkecvkqp"qh"jycfft"hkgnf"ku"gpdcngf
Kpvgthceg"Vtwuvf"nkokv"*rru+
////////////////////////////////////
Tqwgvt% "
```

## Configuring the DHCP Trust State on Layer 2 LAN Interfaces

To configure DHCP trust state on a Layer 2 LAN interface, perform this task:

|        | Command                                                                | Purpose                                                                                                                                                        |
|--------|------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqwgvt*eqphki+% "kpvgthceg"}type slot/port"~"<br>rgtv/ejcppgn"pwodgt;" | Selects the interface to configure.<br><br><b>Note</b> Select only LAN ports configured with the <b>switchport</b> command or Layer 2 port-channel interfaces. |
| Step 2 | Tqwgvt*eqphki/kh+% "kr"fjer"upqqrkpi"vtwuv"                            | Configures the interface as trusted.                                                                                                                           |
| Step 3 | Tqwgvt*eqphki/kh+% "fq"ujqy"kr"fjer"upqqrkpi"~"<br>dgikp"rru"          | Verifies the configuration.                                                                                                                                    |



This example shows how to configure Gigabit Ethernet port 5/12 as trusted:

```
Tqvwgt% "eqphkiwtg"vgtokpcn"
Tqvwgt *eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv"7134"
Tqvwgt *eqphki/kh+% "kr"fjer"upqqrkpi"vtwuv"
Tqvwgt *eqphki/kh+% "fq"ujqy"kr"fjer"upqqrkpi"~"dgikp"rru"
Kpvgtthceg"Vtwuvvf" "Tcvg"nkokv"*rru+
//
IkicdkvGvjgtpgv7134" {gu" "wpnkokvgf
Tqvwgt%
```

This example shows how to configure Gigabit Ethernet port 5/12 as untrusted:

```
Tqvwgt% "eqphkiwtg"vgtokpcn"
Tqvwgt *eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv"7134"
Tqvwgt *eqphki/kh+% "pq"kr"fjer"upqqrkpi"vtwuv"
Tqvwgt *eqphki/kh+% "fq"ujqy"kr"fjer"upqqrkpi"~"dgikp"rru"
Kpvgtthceg"Vtwuvvf" "Tcvg"nkokv"*rru+
//
IkicdkvGvjgtpgv7134" "pq" "wpnkokvgf
Tqvwgt%
```

## Configuring Spurious DHCP Server Detection

To detect and locate spurious DHCP servers, perform this task:

|        | Command                                                                    | Purpose                                                               |
|--------|----------------------------------------------------------------------------|-----------------------------------------------------------------------|
| Step 1 | Tqvwgt *eqphki+% "kr"fjer"upqqrkpi"fgvgev"urwtkqwu" <b>xncp</b> "tcpig"    | Enables detection of spurious DHCP servers on a specified VLAN range. |
| Step 2 | Tqvwgt *eqphki+% "kr"fjer"upqqrkpi"fgvgev"urwtkqwu" <b>kpvgtxcn</b> "time" | Sets the interval time, the default is 30 minutes.                    |
| Step 3 | Tqvwgt% "ujqy"kr"fjer"upqqrkpi"fgvgev"urwtkqwu"                            | Verifies spurious DHCP server detection.                              |

This example shows how to configure DHCP spurious server detection on VLANs 20 to 25 and set the interval to 50 minutes:

```
Tqvwgt% "eqphkiwtg"vgtokpcn"
Tqvwgt *eqphki+% "kr"fjer"upqqrkpi"fgvgev"urwtkqwu"xncp"42/47
Tqvwgt *eqphki+% "kr"fjer"upqqrkpi"fgvgev"urwtkqwu"kpvgtxcn"72
Tqvwgt% "fq"ujqy"kr"fjer"upqqrkpi"fgvgev"urwtkqwu
Urwtkqwu" FJER"ugt xgt" fgvgevkqp"ku"gp dngf0

Fgvgevkqp"XNCP"nkuv"<"42/47
Fgvgevkqp"kpvgtxcn"<"72"okpwvgu
Tqvwgt%
```

## Configuring DHCP Snooping Rate Limiting on Layer 2 LAN Interfaces

To configure DHCP snooping rate limiting on a Layer 2 LAN interface, perform this task:

|        | Command                                                                                              | Purpose                                                                                                                                                               |
|--------|------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"kpvgt hceg"</b>} type slot/port"~<b>"rqt v/ejcppgn"</b><br/>pwodgt;"</code> | <p>Selects the interface to configure.</p> <p><b>Note</b> Select only LAN ports configured with the <b>switchport</b> command or Layer 2 port-channel interfaces.</p> |
| Step 2 | <code>Tqwvgt*eqphki/kh+%<b>"kr"fjer"</b>upqqrkpi"<b>"nkokv"</b>tcvg" tcvg"</code>                    | Configures DHCP packet rate limiting.                                                                                                                                 |
| Step 3 | <code>Tqwvgt*eqphki/kh+%<b>"fq"ujqy"</b>kr"fjer"upqqrkpi"~<b>"dgikp"</b>rru"</code>                  | Verifies the configuration.                                                                                                                                           |

When configuring DHCP snooping rate limiting on a Layer 2 LAN interface, note the following information:

- We recommend an untrusted rate limit of not more than 100 packets per second (pps).
- If you configure rate limiting for trusted interfaces, you might need to increase the rate limit on trunk ports carrying more than one VLAN on which DHCP snooping is enabled.
- DHCP snooping puts ports where the rate limit is exceeded into the error-disabled state.

This example shows how to configure DHCP packet rate limiting to 100 pps on Gigabit Ethernet port 5/12:

```
Tqwgvtg%"eqphkiwtg"vgtokpcn"
Tqwgvtg*eqphki+%"kpvgtchceg"ikicdkvgvjgtpgv"7134"
Tqwgvtg*eqphki/kh+%"kr"fjer"upqqrkpi"nkokv"tcvg"322"
Tqwgvtg*eqphki/kh+%"fq"ujqy"kr"fjer"upqqrkpi"~"dgikp"rru"
Kpvgtchceg"~~~~~Vtwuvfg"~~~~Tcvg"nkokv"*rru+
////////////////////////~/////////////////////////
Ikicdkvgvjgtpgv7134"~~~~~pq"~~~~~322"
Tqwgvtg%"
```

## The DHCP Snooping Database Agent

- [Prerequisites for the DHCP Snooping Database Agent, page 78-14](#)
- [Restrictions for the DHCP Snooping Database Agent, page 78-14](#)
- [Default Settings for the DHCP Snooping Database Agent, page 78-15](#)
- [How to Configure the DHCP Snooping Database Agent, page 78-15](#)
- [Configuration Examples for the Database Agent, page 78-15](#)

## Prerequisites for the DHCP Snooping Database Agent

None.

## Restrictions for the DHCP Snooping Database Agent

- The DHCP snooping database stores at least 8,000 bindings.
- Store the file on a TFTP server to avoid consuming storage space on the switch storage devices.

- When a switchover occurs, if the file is stored in a remote location accessible through TFTP, the newly active supervisor engine can use the binding list.
- Network-based URLs (such as TFTP and FTP) require that you create an empty file at the configured URL before the switch can write the set of bindings for the first time.

## Default Settings for the DHCP Snooping Database Agent

None.

## How to Configure the DHCP Snooping Database Agent

To configure the DHCP snooping database agent, perform one or more of the following tasks:

| Command                                                                                                                     | Purpose                                                                                                  |
|-----------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| <code>Tqwwgt*eqphki+% kr"fjer"upqqrkpi"fcvdcug"}"awtn"~"ytkvg/fgnc{"ugeqpfu"~"vkogqvw"ugeqpfu";"</code>                     | Configures a URL for the database agent (or file) and the related timeout values.                        |
| <code>Tqwwgt% ujgy"kr"fjer"upqqrkpi"fcvdcug"]fgvckn_"</code>                                                                | Displays the current operating state of the database agent and statistics associated with the transfers. |
| <code>Tqwwgt% engct"kr"fjer"upqqrkpi"fcvdcug"uvcvkuvkeu"</code>                                                             | Clears the statistics associated with the database agent.                                                |
| <code>Tqwwgt% tggpy"kr"fjer"upqqrkpi"fcvdcug"]xcnkfcvkqp"pqp_g_" ] wtn_"</code>                                             | Requests the read entries from a file at the given URL.                                                  |
| <code>Tqwwgt% kr"fjer"upqqrkpi"dkpfkpi"oceacfftguu"xncp"vlan_ID ip_address"kpvgthceg"khpcog"gzrkt{"ngcugakpaugeqpfu"</code> | Adds bindings to the snooping database.                                                                  |

## Configuration Examples for the Database Agent

- [Example 1: Enabling the Database Agent, page 78-15](#)
- [Example 2: Reading Binding Entries from a TFTP File, page 78-17](#)
- [Example 3: Adding Information to the DHCP Snooping Database, page 78-18](#)

### Example 1: Enabling the Database Agent

The following example shows how to configure the DHCP snooping database agent to store the bindings at a given location and to view the configuration and operating state:

```
Tqwwgt%eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+%kr"fjer"upqqrkpi"fcvdcug"vhvr<11320303031fktgevqt{1hkng"
Tqwwgt*eqphki+%gpff"
Tqwwgt%ujgy"kr"fjer"upqqrkpi"fcvdcug"fgvckn"
Cigpv"WTN"<"vhvr<11320303031fktgevqt{1hkng
Ytkvg"fgnc{"Vkogt"<"522"ugeqpfu
Cdqtv"Vkogt"<"522"ugeqpfu

Cigpv"Twppkpi"<"Pq
Fgnc{"Vkogt"Gzrkt{"<"9"*22<22<29+
Cdqtv"Vkogt"Gzrkt{"<"Pqv"Twppkpi

Ncuv"Uweegfgf"Vkog"<"Pqpg
Ncuv"Hckngf"Vkog"<"39<36<47"WVE"Ucv"Lwn"9"4223
Ncuv"Hckngf"Tgcup"<"Wpcdng"vq"ceegu"WTN0
```

```

Vqvcn"Cvvgorvu" "<" "43" "Uvctvwr"Hcknwtgu" "<" "2
Uweeguuhwn"Vtcpuhtgu" "<" "2" "Hckngf"Vtcpuhtgu" "<" "43
Uweeguuhwn"Tgcfu" "<" "2" "Hckngf"Tgcfu" "<" "2
Uweeguuhwn"Ytkvgu" "<" "2" "Hckngf"Ytkvgu" "<" "43
OgfkC"Hcknwtgu" "<" "2

Hktuv"uweeguuhwn"ceegu<"Tgcf

Ncuv"kipqgtgf"dkpfkpiu"eqwpgvtu<
Dkpfkpi"Eqnnkukqpu" "<" "2" "Gzrktgf"ngcugu" "<" "2
Kpxcnkf"kpvgthcegu" "<" "2" "Wpuwrrqtvgf"xncpu" "<" "2
Rctug"hcknwtgu" "<" "2
Ncuv"Kipqgtgf"Vkog" "<" "Pqpg

Vqvcn"kipqgtgf"dkpfkpiu"eqwpgvtu<
Dkpfkpi"Eqnnkukqpu" "<" "2" "Gzrktgf"ngcugu" "<" "2
Kpxcnkf"kpvgthcegu" "<" "2" "Wpuwrrqtvgf"xncpu" "<" "2
Rctug"hcknwtgu" "<" "2

Tqwgvt%
```

The first three lines of output show the configured URL and related timer-configuration values. The next three lines show the operating state and the amount of time left for expiry of write delay and abort timers.

Among the statistics shown in the output, startup failures indicate the number of attempts to read or create the file that failed on bootup.



#### Note

Create a temporary file on the TFTP server with the **touch** command in the TFTP server daemon directory. With some UNIX implementations, the file should have full read and write access permissions (777).

DHCP snooping bindings are keyed on the MAC address and VLAN combination. If an entry in the remote file has an entry for a given MAC address and VLAN set for which the switch already has a binding, the entry from the remote file is ignored when the file is read. This condition is referred to as the *binding collision*.

An entry in a file may no longer be valid because the lease indicated by the entry may have expired by the time it is read. The expired leases counter indicates the number of bindings that are ignored because of this condition. The Invalid interfaces counter refers to the number of bindings that have been ignored when the interface referred by the entry either does not exist on the system or is a router or DHCP snooping trusted interface (if it exists) when the read happened. Unsupported VLANs refers to the number of entries that have been ignored because the indicated VLAN is not supported on the system. The Parse failures counter provides the number of entries that have been ignored when the switch is unable to interpret the meaning of the entries from the file.

The switch maintains two sets of counters for these ignored bindings. One provides the counters for a read that has at least one binding ignored by at least one of these conditions. These counters are shown as the “Last ignored bindings counters.” The total ignored bindings counters provides a sum of the number of bindings that have been ignored because of all the reads since the switch bootup. These two sets of counters are cleared by the **clear** command. The total counter set may indicate the number of bindings that have been ignored since the last clear.



```

//
22<23<22<23<22<27""32030303""""""6;:32""""fjer/upqqrkpi""734""IkicdkvGvjgtpgv313
22<23<22<23<22<24""32030303""""""6;:32""""fjer/upqqrkpi""734""IkicdkvGvjgtpgv313
22<23<22<23<22<26""32030303""""""6;:32""""fjer/upqqrkpi""3758""IkicdkvGvjgtpgv313
22<23<22<23<22<25""32030303""""""6;:32""""fjer/upqqrkpi""3246""IkicdkvGvjgtpgv313
22<23<22<23<22<23""32030303""""""6;:32""""fjer/upqqrkpi""3""IkicdkvGvjgtpgv313
Tqwgvt%"engct"kr"fjer"upqqr"dkpf"
Tqwgvt%"ujqy"kr"fjer"upqqr"dkpf""
OceCfftguu""""""KrCfftguu""""""Ngcug*uge+""V{rg""""""XNCP""Kpvgthceg
//
Tqwgvt%

```

### Example 3: Adding Information to the DHCP Snooping Database

To manually add a binding to the DHCP snooping database, perform this task:

|        | Command                                                                                                      | Purpose                                                          |
|--------|--------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt%"ujqy"kr"fjer"upqqrkpi"dkpfkpi"</code>                                                          | Views the DHCP snooping database.                                |
| Step 2 | <code>Tqwgvt%"kr"fjer"upqqrkpi"dkpfkpi"dkpfkpiakf"xncp"xncpakf"kpvgthceg"kpvgthceg"gzrkt{"ngcugavkog"</code> | Adds the binding using the <b>ip dhcp snooping exec</b> command. |
| Step 3 | <code>Tqwgvt%"ujqy"kr"fjer"upqqrkpi"dkpfkpi"</code>                                                          | Checks the DHCP snooping database.                               |

This example shows how to manually add a binding to the DHCP snooping database:

```

Tqwgvt%"ujqy"kr"fjer"upqqrkpi"dkpfkpi"
OceCfftguu""""""KrCfftguu""""""Ngcug*uge+""V{rg""""""XNCP""Kpvgthceg
//
Tqwgvt%
Tqwgvt%"kr"fjer"upqqrkpi"dkpfkpi"30303"xncp"3"32030303"kpvgthceg"ik313"gzrkt{"3222"

Tqwgvt%"ujqy"kr"fjer"upqqrkpi"dkpfkpi"
OceCfftguu""""""KrCfftguu""""""Ngcug*uge+""V{rg""""""XNCP""Kpvgthceg
//
22<23<22<23<22<23""32030303"""""";4""""fjer/upqqrkpi""3""IkicdkvGvjgtpgv313
Tqwgvt%

```

## Displaying the DHCP Snooping Binding Table

The DHCP snooping binding table for each switch contains binding entries that correspond to untrusted ports. The table does not contain information about hosts interconnected with a trusted port because each interconnected switch will have its own DHCP snooping binding table.

This example shows how to display the DHCP snooping binding information for a switch:

```

Tqwgvt%"ujqy"kr"fjer"upqqrkpi"dkpfkpi"
OceCfftguu""""""KrCfftguu""""""Ngcug*uge+""V{rg""""""XNCP""Kpvgthceg
//
22<24<D5<5H<5D<;""77070704""""""8;65""""fjer/upqqrkpi""32""IkicdkvGvjgtpgv8132

```

Table 78-1 describes the fields in the **show ip dhcp snooping binding** command output.

**Table 78-1** *show ip dhcp snooping binding Command Output*

| Field           | Description                                                                             |
|-----------------|-----------------------------------------------------------------------------------------|
| MAC Address     | Client hardware MAC address                                                             |
| IP Address      | Client IP address assigned from the DHCP server                                         |
| Lease (seconds) | IP address lease time                                                                   |
| Type            | Binding type: dynamic binding learned by DHCP snooping or statically-configured binding |
| VLAN            | VLAN number of the client interface                                                     |
| Interface       | Interface that connects to the DHCP client host                                         |

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)







## IP Source Guard

---

- [Prerequisites for IP Source Guard, page 79-1](#)
- [Restrictions for IP Source Guard, page 79-2](#)
- [Information About IP Source Guard, page 79-2](#)
- [Default Settings for IP Source Guard, page 79-3](#)
- [How to Configure IP Source Guard, page 79-3](#)
- [Displaying IP Source Guard PACL Information, page 79-5](#)
- [Displaying IP Source Binding Information, page 79-6](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for IP Source Guard

None.

## Restrictions for IP Source Guard

Because the IP source guard feature is supported only in hardware, IP source guard is not applied if there are insufficient hardware resources available. These hardware resources are shared by various other ACL features that are configured on the system. The following restrictions apply to IP source guard:

- Supported only on ingress Layer 2 ports.
- Supported only in hardware; not applied to any traffic that is processed in software.
- Does not support filtering of traffic based on MAC address.
- Is not supported on private VLANs.

## Information About IP Source Guard

- [Overview of IP Source Guard, page 79-2](#)
- [IP Source Guard Interaction with VLAN-Based Features, page 79-2](#)
- [Channel Ports, page 79-3](#)
- [Layer 2 and Layer 3 Port Conversion, page 79-3](#)
- [IP Source Guard and Voice VLAN, page 79-3](#)
- [IP Source Guard and Web-Based Authentication, page 79-3](#)

## Overview of IP Source Guard

IP source guard provides source IP address filtering on a Layer 2 port to prevent a malicious host from impersonating a legitimate host by assuming the legitimate host's IP address. The feature uses dynamic DHCP snooping and static IP source binding to match IP addresses to hosts on untrusted Layer 2 access ports.

Initially, all IP traffic on the protected port is blocked except for DHCP packets. After a client receives an IP address from the DHCP server, or after static IP source binding is configured by the administrator, all traffic with that IP source address is permitted from that client. Traffic from other hosts is denied. This filtering limits a host's ability to attack the network by claiming a neighbor host's IP address. IP source guard is a port-based feature that automatically creates an implicit port access control list (PACL).

## IP Source Guard Interaction with VLAN-Based Features

Use the **access-group mode** command to specify how IP source guard interacts with VLAN-based features (such as VACL and Cisco IOS ACL and RACL).

In prefer port mode, if IP source guard is configured on an interface, IP source guard overrides other VLAN-based features. If IP source guard is not configured on the interface, other VLAN-based features are merged in the ingress direction and applied on the interface.

In merge mode, IP source guard and VLAN-based features are merged in the ingress direction and applied on the interface. This is the default access-group mode.

## Channel Ports

IP source guard is supported on Layer 2 port-channel interfaces but not on the port members. When IP source guard is applied to a Layer 2 port-channel channel interface, it is applied to all the member ports in the EtherChannel.

## Layer 2 and Layer 3 Port Conversion

When an IP source guard policy is configured on a Layer 2 port, if the port is reconfigured as a Layer 3 port, the IP source guard policy no longer functions but is still present in the configuration. If the port is reconfigured as a Layer 2 port, the IP source guard policy becomes effective again.

## IP Source Guard and Voice VLAN

IP source guard is supported on a Layer 2 port that belongs to a voice VLAN. For IP source guard to be active on the voice VLAN, DHCP snooping must be enabled on the voice VLAN. In merge mode, the IP source guard feature is merged with VACL and Cisco IOS ACL configured on the access VLAN.

## IP Source Guard and Web-Based Authentication

You can configure IP source guard and web-based authentication (see [Chapter 84, “Web-Based Authentication”](#)) on the same interface. Other VLAN-based features are not supported when IP Source Guard and web-based authentication are combined.

## Default Settings for IP Source Guard

None.

## How to Configure IP Source Guard

To enable IP source guard, perform this task:

|        | Command                                                                 | Purpose                                                            |
|--------|-------------------------------------------------------------------------|--------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%"kr"fjer"upqqrkpi"</code>                          | Enables DHCP snooping globally.                                    |
| Step 2 | <code>Tqwvgt*eqphki+%"kr"fjer"upqqrkpi"xncp"pwodgt"<br/>lpwodgt_</code> | Enables DHCP snooping on your VLANs.                               |
| Step 3 | <code>Tqwvgt*eqphki+%"kpvgtthceg"interface-name</code>                  | Selects the interface to be configured.                            |
| Step 4 | <code>Tqwvgt*eqphki/kh+%"pq"kr"fjer"upqqrkpi"vtwuv</code>               | Use the <b>no</b> keyword to configure the interface as untrusted. |



The static IP source binding can only be configured on a Layer 2 port. If you enter the **ip source binding vlan interface** command on a Layer 3 port, you receive this error message:

The **no** keyword deletes the corresponding IP source binding entry. This command requires an exact match of all the required parameters in order for the deletion to be successful.

```
Tqvwgt%"eqphkiwtg"vgtokpcn
Gpvgt%"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%"kr"fjer"upqqrkpi
Tqvwgt*eqphki+%"kr"fjer"upqqrkpi"xncp"32"42
Tqvwgt*eqphki+%"kpvgthceg"ikicdkvgvjgtpgv"813
Tqvwgt*eqphki/kh+%"uykvejrgtv"oqfg"ceeguu
Tqvwgt*eqphki/kh+%"uykvejrgtv"ceeguu"xncp"32
Tqvwgt*eqphki/kh+%"pq"kr"fjer"upqqrkpi"vtwuv
Tqvwgt*eqphki/kh+%"kr"xgtk{ "uqwteg"xncp"fjer/upqqrkpi
Tqvwgt*eqphki/kh+%"gp f
Tqvwgt%"ujqy"kr"xgtk{ "uqwteg"kpvgthceg"ikicdkvgvjgtpgv"813
Kpvgthceg%"Hknvgt/v{ rg"Hknvgt/oqfg"KR/cfftguu" ""Oce/cfftguu" ""Xncp
//////////////////////////
Ik813" ""kr" ""cevkgxg" ""32020203" ""32"
Ik813" ""kr" ""cevkgxg" ""fcp{ /cnn" ""33/42"
Tqvwgt%
```

This example shows how to configure an interface to use prefer port mode:

This example shows how to configure an interface to use merge mode:

Supervisor Engine 6T Software Configuration Guide, Release 15.4SY

```
Tqvwgt*eqphki/kh+% "ceeguu/itqwr"oqfg"ogtig
```

## Displaying IP Source Guard PACL Information

To display IP source guard PACL information for all interfaces on a switch, perform this task:

| Command                                                                         | Purpose                                                                                                |
|---------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|
| <code>Tqvwgt% "ujqy"kr"xgtkh{ "uqwtg" } kpvgtgthceg"<br/>interface-name_</code> | Displays IP source guard PACL information for all interfaces on a switch or for a specified interface. |

This example shows that DHCP snooping is enabled on VLAN 10 through 20, interface fa6/1 is configured for IP filtering, and there is an existing IP address binding 10.0.01 on VLAN 10:

```
Tqvwgt% "ujqy"kr"xgtkh{ "uqwtg" } kpvgtgthceg"hc813
Kpvgtgthceg" "Hknvgt/v{rg" "Hknvgt/oqfg" "KR/cfftguu" "Oce/cfftguu" "Xncp
/////////" "/////////" "/////////" "/////////" "/////////" "/////////"
hc813" "kr" "cevkxg" "32020203" "32
hc813" "kr" "cevkxg" "fgp{/cnn" "33/42
```



### Note

The second entry shows that a default PACL (deny all IP traffic) is installed on the port for those snooping-enabled VLANs that do not have a valid IP source binding.

This example shows the displayed PACL information for a trusted port:

```
Kpvgtgthceg" "Hknvgt/v{rg" "Hknvgt/oqfg" "KR/cfftguu" "Oce/cfftguu" "Xncp
/////////" "/////////" "/////////" "/////////" "/////////" "/////////"
hc814" "kr" "kpcevkg/vtuvw/rqtv
```

This example shows the displayed PACL information for a port in a VLAN not configured for DHCP snooping:

```
Kpvgtgthceg" "Hknvgt/v{rg" "Hknvgt/oqfg" "KR/cfftguu" "Oce/cfftguu" "Xncp
/////////" "/////////" "/////////" "/////////" "/////////" "/////////"
hc815" "kr" "kpcevkg/pq/upqqrkpi/xncp
```

This example shows the displayed PACL information for a port with multiple bindings configured for an IP/MAC filtering:

```
Kpvgtgthceg" "Hknvgt/v{rg" "Hknvgt/oqfg" "KR/cfftguu" "Oce/cfftguu" "Xncp
/////////" "/////////" "/////////" "/////////" "/////////" "/////////"
hc816" "kr" "cevkxg" "32020204" "cccc0ddd0eeee" "32
hc816" "kr" "cevkxg" "33020203" "cccc0ddd0eeef" "33
hc816" "kr" "cevkxg" "fgp{/cnn" "fgp{/cnn" "34/42
```

This example shows the displayed PACL information for a port configured for IP/MAC filtering but not for port security:

```
Kpvgtgthceg" "Hknvgt/v{rg" "Hknvgt/oqfg" "KR/cfftguu" "Oce/cfftguu" "Xncp
/////////" "/////////" "/////////" "/////////" "/////////" "/////////"
hc817" "kr" "cevkxg" "32020205" "rgtokv/cnn" "32
hc817" "kr" "cevkxg" "fgp{/cnn" "rgtokv/cnn" "33/42
```



### Note

The MAC address filter shows permit-all because port security is not enabled, so the MAC filter cannot apply to the port/VLAN and is effectively disabled. Always enable port security first.

This example shows an error message when you enter the **show ip verify source** command on a port that does not have an IP source filter mode configured:

```
Tqwgvt% "ujqy"kr"xgtkh{ "uqwteg"kpvgthceg"hc818
KR"Uqwteg"Twctf"ku"pqv"eqphkiwtgf"qp"vjg"kpvgthceg"hc8180
```

This example shows how to display all interfaces on the switch that have IP source guard enabled:

```
Tqwgvt% "ujqy"kr"xgtkh{ "uqwteg
Kpvgthceg" "Hknvgt/v{rg" "Hknvgt/oqfg" "KR/cfftguu" "Oce/cfftguu" "Xncp
////////////////////////////////////
hc813" "kr" "cevkxg" "32020203" "32
hc813" "kr" "cevkxg" "fgp{/cnn" "33/42
hc814" "kr" "kpcevkxg/vtwuv/rqtv
hc815" "kr" "kpcevkxg/pq/upqqrkpi/xncp
hc816" "kr" "cevkxg" "32020204" "cccc0ddd0eeee" "32
hc816" "kr" "cevkxg" "33020203" "cccc0ddd0eeef" "33
hc816" "kr" "cevkxg" "fgp{/cnn" "fgp{/cnn" "34/42
hc817" "kr" "cevkxg" "32020205" "rgtokv/cnn" "32
hc817" "kr" "cevkxg" "fgp{/cnn" "rgtokv/cnn" "33/42
```

## Displaying IP Source Binding Information

To display all IP source bindings configured on all interfaces on a switch, perform this task:

| Command                                                                                                                                  | Purpose                                                                                                                                                                               |
|------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Tqwgvt% "ujqy"kr"uqwteg"dkpfkpi" ]kracfftguu_"<br>]oceacfftguu_" ]fjer/upqqrkpi"~"uvcvke_"<br>]xncp"xncpakf_" ]kpvgthceg"kpvgthcegapcog_ | Displays IP source bindings using the optional specified display filters.<br><br>The <b>dhcp-snooping</b> filter displays all VLANs on the interface that have DHCP snooping enabled. |

This example shows how to display all IP source bindings configured on all interfaces on the switch.

```
Tqwgvt% "ujqy"kr"uqwteg"dkpfkpi
OceCfftguu" "KrCfftguu" "Ngcug*uge+" "v{rg" "XNCP" "Kpvgthceg
////////////////////////////////////
22<24<D5<5D<; ; "77070704" "8744" "fjer/upqqrkpi" "32" "IkicdkvGvjgtpgv8132
22<22<22<2C<22<2D" "33020203" "kphkpkvg" "uvcvke" "32" "IkicdkvGvjgtpgv8132
Tqwgvt%
```

Table 79-1 describes the fields in the **show ip source binding** command output.

**Table 79-1** *show ip source binding Command Output*

| Field           | Description                                                                                     |
|-----------------|-------------------------------------------------------------------------------------------------|
| MAC Address     | Client hardware MAC address                                                                     |
| IP Address      | Client IP address assigned from the DHCP server                                                 |
| Lease (seconds) | IP address lease time                                                                           |
| Type            | Binding type; static bindings configured from CLI to dynamic binding learned from DHCP snooping |
| VLAN            | VLAN number of the client interface                                                             |
| Interface       | Interface that connects to the DHCP client host                                                 |

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)







## Dynamic ARP Inspection (DAI)

---

- [Prerequisites for DAI, page 80-1](#)
- [Restrictions for DAI, page 80-2](#)
- [Information About DAI, page 80-3](#)
- [Default Settings for DAI, page 80-6](#)
- [How to Configure DAI, page 80-7](#)
- [Configuration Examples for DAI, page 80-16](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
  - Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
  - The PFC and any DFCs support DAI in hardware.
- 



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

---

## Prerequisites for DAI

None.

# Restrictions for DAI

- Hardware-accelerated DAI is enabled by default.
- When DAI is hardware-accelerated, you can configure CoPP to rate limit ARP traffic that would be processed by the RP (for example, packets with a broadcast destination MAC address or the MAC address of the RP; see [Chapter 77, “Control Plane Policing \(CoPP\)”](#)).
- [DAI logging](#), including both ACL logging and DHCP logging, is not compatible with DAI hardware acceleration. When DAI is hardware-accelerated, DAI logging is disabled.



**Note** Regardless of the enable state of DAI hardware acceleration, DAI configured to use an ARP ACL with the [acl-match matchlog](#) keywords is processed in software and supports logging.

- Because DAI is an ingress security feature, it does not perform any egress checking.
- DAI is not effective for hosts connected to switches that do not support DAI or that do not have this feature enabled. Because man-in-the-middle attacks are limited to a single Layer 2 broadcast domain, separate the domain with DAI checks from the one with no checking. This action secures the ARP caches of hosts in the domain enabled for DAI.
- DAI depends on the entries in the DHCP snooping binding database to verify IP-to-MAC address bindings in incoming ARP requests and ARP responses. Make sure to enable DHCP snooping to permit ARP packets that have dynamically assigned IP addresses. For configuration information, see [Chapter 78, “Dynamic Host Configuration Protocol \(DHCP\) Snooping.”](#)
- When DHCP snooping is disabled or in non-DHCP environments, use ARP ACLs to permit or to deny packets.
- DAI is supported on access ports, trunk ports, EtherChannel ports, and private VLAN ports.
- A physical port can join an EtherChannel port channel only when the trust state of the physical port and the channel port match. When you change the trust state on the port channel, the switch configures a new trust state on all the physical ports that comprise the channel.
- The operating rate for the port channel is cumulative across all the physical ports within the channel. For example, if you configure the port channel with an ARP rate limit of 400 pps, all the interfaces combined on the channel receive an aggregate 400 pps. The rate of incoming ARP packets on EtherChannel ports is equal to the sum of the incoming rate of packets from all the channel members. Configure the rate limit for EtherChannel ports only after examining the rate of incoming ARP packets on the channel-port members.

The rate of incoming packets on a physical port is checked against the port-channel configuration rather than the physical-ports configuration. The rate-limit configuration on a port channel is independent of the configuration on its physical ports.

If the EtherChannel receives more ARP packets than the configured rate, the channel (including all physical ports) is placed in the error-disabled state.


- Make sure to limit the rate of ARP packets on incoming trunk ports. Configure trunk ports with higher rates to reflect their aggregation and to handle packets across multiple DAI-enabled VLANs. You also can use the **ip arp inspection limit none** interface configuration command to make the rate unlimited. A high rate-limit on one VLAN can cause a denial-of-service attack to other VLANs when the software places the port in the error-disabled state.

- Information about ARP, page 80-3
- ARP Spoofing Attacks, page 80-3
- DAI and ARP Spoofing Attacks, page 80-4
- Interface Trust States and Network Security, page 80-4
- Rate Limiting of ARP Packets, page 80-5
- Relative Priority of ARP ACLs and DHCP Snooping Entries, page 80-6
- Logging of Dropped Packets, page 80-6

ARP provides IP communication within a Layer 2 broadcast domain by mapping an IP address to a MAC address. For example, Host B wants to send information to Host A but does not have the MAC address of Host A in its ARP cache. Host B generates a broadcast message for all hosts within the broadcast domain to obtain the MAC address associated with the IP address of Host A. All hosts within the broadcast domain receive the ARP request, and Host A responds with its MAC address.

ARP spoofing attacks and ARP cache poisoning can occur because ARP allows a gratuitous reply from a host even if an ARP request was not received. After the attack, all traffic from the device under attack flows through the attacker's computer and then to the router, switch, or host.

An ARP spoofing attack can target hosts, switches, and routers connected to your Layer 2 network by poisoning the ARP caches of systems connected to the subnet and by intercepting traffic intended for other hosts on the subnet. [Figure 80-1](#) shows an example of ARP cache poisoning.



Hosts A, B, and C are connected to the switch on interfaces A, B and C, all of which are on the same subnet. Their IP and MAC addresses are shown in parentheses; for example, Host A uses IP address IA and MAC address MA. When Host A needs to communicate to Host B at the IP layer, it broadcasts an ARP request for the MAC address associated with IP address IB. When the switch and Host B receive the ARP request, they populate their ARP caches with an ARP binding for a host with the IP address IA and a MAC address MA; for example, IP address IA is bound to MAC address MA. When Host B responds, the switch and Host A populate their ARP caches with a binding for a host with the IP address IB and the MAC address MB.

Host C can poison the ARP caches of the switch for Host A, and Host B by broadcasting forged ARP responses with bindings for a host with an IP address of IA (or IB) and a MAC address of MC. Hosts with poisoned ARP caches use the MAC address MC as the destination MAC address for traffic intended for IA or IB. This means that Host C intercepts that traffic. Because Host C knows the true MAC addresses associated with IA and IB, it can forward the intercepted traffic to those hosts by using the correct MAC address as the destination. Host C has inserted itself into the traffic stream from Host A to Host B, which is the topology of the classic *man-in-the middle* attack.

## DAI and ARP Spoofing Attacks

The PFC and any DFCs provide hardware support for DAI. DAI is a security feature that validates ARP packets in a network. DAI intercepts, logs, and discards ARP packets with invalid IP-to-MAC address bindings. This capability protects the network from some man-in-the-middle attacks.

DAI ensures that only valid ARP requests and responses are relayed. The switch performs these activities:

- Intercepts all ARP requests and responses on untrusted ports
- Verifies that each of these intercepted packets has a valid IP-to-MAC address binding before updating the local ARP cache or before forwarding the packet to the appropriate destination
- Drops invalid ARP packets

DAI determines the validity of an ARP packet based on valid IP-to-MAC address bindings stored in a trusted database, the DHCP snooping binding database. This database is built by DHCP snooping if DHCP snooping is enabled on the VLANs and on the switch. If the ARP packet is received on a trusted interface, the switch forwards the packet without any checks. On untrusted interfaces, the switch forwards the packet only if it is valid.

DAI can validate ARP packets against user-configured ARP access control lists (ACLs) for hosts with statically configured IP addresses (see [“Applying ARP ACLs for DAI Filtering” section on page 80-9](#)). The switch logs dropped packets (see the [“Logging of Dropped Packets” section on page 80-6](#)).

You can configure DAI to drop ARP packets when the IP addresses in the packets are invalid or when the MAC addresses in the body of the ARP packets do not match the addresses specified in the Ethernet header (see the [“Enabling Additional Validation” section on page 80-11](#)).

## Interface Trust States and Network Security

DAI associates a trust state with each interface on the switch. Packets arriving on trusted interfaces bypass all DAI validation checks, and those arriving on untrusted interfaces undergo the DAI validation process.

In a typical network configuration, you configure all switch ports connected to host ports as untrusted and configure all switch ports connected to switches as trusted. With this configuration, all ARP packets entering the network from a given switch bypass the security check. No other validation is needed at any other place in the VLAN or in the network. You configure the trust setting by using the **ip arp inspection trust** interface configuration command.




### Caution

Use the trust state configuration carefully. Configuring interfaces as untrusted when they should be trusted can result in a loss of connectivity.

In [Figure 80-2](#), assume that both Switch A and Switch B are running DAI on the VLAN that includes Host 1 and Host 2. If Host 1 and Host 2 acquire their IP addresses from the DHCP server connected to Switch A, only Switch A binds the IP-to-MAC address of Host 1. Therefore, if the interface between Switch A and Switch B is untrusted, the ARP packets from Host 1 are dropped by Switch B. Connectivity between Host 1 and Host 2 is lost.

**Figure 80-2** ARP Packet Validation on a VLAN Enabled for DAI



Configuring interfaces to be trusted when they are actually untrusted leaves a security hole in the network. If Switch A is not running DAI, Host 1 can easily poison the ARP cache of Switch B (and Host 2, if the link between the switches is configured as trusted). This condition can occur even though Switch B is running DAI.

DAI ensures that hosts (on untrusted interfaces) connected to a switch running DAI do not poison the ARP caches of other hosts in the network. However, DAI does not prevent hosts in other portions of the network from poisoning the caches of the hosts that are connected to a switch running DAI.

In cases in which some switches in a VLAN run DAI and other switches do not, configure the interfaces connecting such switches as untrusted. However, to validate the bindings of packets from switches where DAI is not configured, configure ARP ACLs on the switch running DAI. When you cannot determine such bindings, isolate switches running DAI at Layer 3 from switches not running DAI. For configuration information, see the [“One Switch Supports DAI”](#) section on [page 80-21](#).



#### Note

Depending on the setup of the DHCP server and the network, it might not be possible to validate a given ARP packet on all switches in the VLAN.

## Rate Limiting of ARP Packets

The switch performs DAI validation checks, which rate limits incoming ARP packets to prevent a denial-of-service attack. By default, the rate for untrusted interfaces is 15 packets per second (pps). Trusted interfaces are not rate limited. You can change this setting by using the **ip arp inspection limit** interface configuration command.

When the rate of incoming ARP packets exceeds the configured limit, the switch places the port in the error-disabled state. The port remains in that state until you intervene. You can use the **errdisable recovery** global configuration command to enable error disable recovery so that ports automatically emerge from this state after a specified timeout period.

For configuration information, see the [“Configuring ARP Packet Rate Limiting” section on page 80-10](#).

## Relative Priority of ARP ACLs and DHCP Snooping Entries

DAI uses the DHCP snooping binding database for the list of valid IP-to-MAC address bindings.

ARP ACLs take precedence over entries in the DHCP snooping binding database. The switch uses ACLs only if you configure them by using the **ip arp inspection filter** global configuration command. The switch first compares ARP packets to user-configured ARP ACLs. If the ARP ACL denies the ARP packet, the switch also denies the packet even if a valid binding exists in the database populated by DHCP snooping.

## Logging of Dropped Packets

When the switch drops a packet, it places an entry in the log buffer and then generates system messages on a rate-controlled basis. After the message is generated, the switch clears the entry from the log buffer. Each log entry contains flow information, such as the receiving VLAN, the port number, the source and destination IP addresses, and the source and destination MAC addresses.

You use the **ip arp inspection log-buffer** global configuration command to configure the number of entries in the buffer and the number of entries needed in the specified interval to generate system messages. You specify the type of packets that are logged by using the **ip arp inspection vlan logging** global configuration command. For configuration information, see the [“Configuring DAI Logging” section on page 80-13](#).

## Default Settings for DAI

| Feature                            | Default Setting                                                                                                                                                                                                                                                  |
|------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DAI                                | Disabled on all VLANs.                                                                                                                                                                                                                                           |
| Interface trust state              | All interfaces are untrusted.                                                                                                                                                                                                                                    |
| Rate limit of incoming ARP packets | The rate is 15 pps on untrusted interfaces, assuming that the network is a Layer 2-switched network with a host connecting to as many as 15 new hosts per second.<br><br>The rate is unlimited on all trusted interfaces.<br><br>The burst interval is 1 second. |
| ARP ACLs for non-DHCP environments | No ARP ACLs are defined.                                                                                                                                                                                                                                         |
| Validation checks                  | No checks are performed.                                                                                                                                                                                                                                         |
| Log buffer                         | When DAI is enabled, all denied or dropped ARP packets are logged.<br><br>The number of entries in the log is 32.<br><br>The number of system messages is limited to 5 per second.<br><br>The logging-rate interval is 1 second.                                 |
| Per-VLAN logging                   | All denied or dropped ARP packets are logged.                                                                                                                                                                                                                    |

- Enabling DAI on VLANs, page 80-7
- Configuring DAI Hardware Acceleration, page 80-8
- Configuring the DAI Interface Trust State, page 80-8
- Applying ARP ACLs for DAI Filtering, page 80-9
- Configuring ARP Packet Rate Limiting, page 80-10
- Enabling DAI Error-Disabled Recovery, page 80-11
- Enabling Additional Validation, page 80-11
- Configuring DAI Logging, page 80-13
- Displaying DAI Information, page 80-15

To enable DAI on VLANs, perform this task:

|        | Command                                                                                 | Purpose                           |
|--------|-----------------------------------------------------------------------------------------|-----------------------------------|
| Step 1 | Tqwwgt%"eqphkiwtg"vgtokpcn                                                              | Enters global configuration mode. |
| Step 2 | Tqwwgt*eqphki+%"kr"ctr"kpurgevkqp"xncp }vlan_ID"~"xncpatcpig;"                          | Enables DAI on VLANs.             |
| Step 3 | Tqwwgt*eqphki/kh+%"fq"ujqy"kr"ctr"kpurgevkqp"xncp" }vlan_ID"~"xncpatcpig;"~"dgikp"Xncp" | Verifies the configuration.       |

- To enable a single VLAN, enter a single VLAN number.
- To enable a range of VLANs, enter a dash-separated pair of VLAN numbers.
- You can enter a comma-separated list of VLAN numbers and dash-separated pairs of VLAN numbers.

Tqvwgt%"eqphkiwtg"vgtokpcn"  
Tqvwgt\*eqphki+%"kr"ctr"kpurgvkkp"xncp"32/34"

```
Tqvwgt%"eqphkiwtg"vgtokpcn"
Tqvwgt*eqphki+%"kr"ctr"kpurgevkqp"xncp"32.33.34"
```

Tqvwgt%"eqphkiwtg"vgtokpcn"  
Tqvwgt\*eqphki+%"kr"ctr"kpurgevkqp"xncp"32/34.37"

[illegible]

```

""33""Gpcdnfg""Kpcevkgxg"
""34""Gpcdnfg""Kpcevkgxg"
""37""Gpcdnfg""Kpcevkgxg"

"Xncp""CEN"Nqikpi""FJER"Nqikpi
"////""////////""////////"
""32""Fgp{ ""Fgp{ "
""33""Fgp{ ""Fgp{ "
""34""Fgp{ ""Fgp{ "
""37""Fgp{ ""Fgp{ "

```

## Configuring DAI Hardware Acceleration

When DAI is enabled, by default DAI hardware acceleration is also enabled. To configure the DAI hardware acceleration state, perform this task:

|        | Command                                                                                                       | Purpose                             |
|--------|---------------------------------------------------------------------------------------------------------------|-------------------------------------|
| Step 1 | <code>Tqwvgt%<b>"eqphkiwtg"vgtokpcn</b></code>                                                                | Enters global configuration mode.   |
| Step 2 | <code>Tqwvgt*eqphki+%<b>"kr"ctr"kpurgevkqp"ceegngtcvg"</b></code>                                             | Enables DAI hardware acceleration.  |
|        | <code>Tqwvgt*eqphki+%<b>"pq"kr"ctr"kpurgevkqp"ceegngtcvg"</b></code>                                          | Disables DAI hardware acceleration. |
| Step 3 | <code>Tqwvgt*eqphki+%<b>"fq"ujqy"kr"ctr"kpurgevkqp"~"</b></code><br><code><b>kpenwfg"Ceegngtcvkqp"</b></code> | Verifies the configuration.         |

This example shows how to reenabling DAI hardware acceleration:

```

Tqwvgt%"eqphkiwtg"vgtokpcn
Tqwvgt*eqphki+%"kr"ctr"kpurgevkqp"ceegngtcvg"
Tqwvgt*eqphki+%"fq"ujqy"kr"ctr"kpurgevkqp"~"kpenwfg"Ceegngtcvkqp"
Jctfyctg"Ceegngtcvkqp"Oqfg"<"Gpcdnfg
Tqwvgt*eqphki+%

```

## Configuring the DAI Interface Trust State

The switch forwards ARP packets that it receives on a trusted interface, but does not check them.

On untrusted interfaces, the switch intercepts all ARP requests and responses. It verifies that the intercepted packets have valid IP-to-MAC address bindings before updating the local cache and before forwarding the packet to the appropriate destination. The switch drops invalid packets and logs them in the log buffer according to the logging configuration specified with the **ip arp inspection vlan logging** global configuration command. For more information, see the [“Configuring DAI Logging” section on page 80-13](#).

To configure the DAI interface trust state, perform this task:

|        | Command                                                                                                         | Purpose                                                                                      |
|--------|-----------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt%<b>"eqphkiwtg"vgtokpcn</b></code>                                                                  | Enters global configuration mode.                                                            |
| Step 2 | <code>Tqwvgt*eqphki+%<b>"kpvgtthceg"}</b>type slot/port"~"</code><br><code><b>rqtvt/ejcppgn"pwodgt;"</b></code> | Specifies the interface connected to another switch, and enter interface configuration mode. |



|        | Command                                                              | Purpose                                                |
|--------|----------------------------------------------------------------------|--------------------------------------------------------|
| Step 3 | <code>Tqwwgt*eqphki/kh+%kr"ctr"kpurgevkqp"vtwuv"</code>              | Configures the connection between switches as trusted. |
| Step 4 | <code>Tqwwgt*eqphki/kh+%fq"ujqy"kr"ctr"kpurgevkqp"kpvgthcegu"</code> | Verifies the DAI configuration.                        |

This example shows how to configure Gigabit Ethernet port 5/12 as trusted:

```
Tqwwgt%eqphkiwtg"vgtokpcn"
Gpvg"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqwwgt*eqphki+%kpvgthceg"ikicdkvgvjgtpgv"7134"
Tqwwgt*eqphki/kh+%kr"ctr"kpurgevkqp"vtwuv"
Tqwwgt*eqphki/kh+%fq"ujqy"kr"ctr"kpurgevkqp"kpvgthcegu"~"kpenwfg"Kpv~//~7134"
Kpvgthceg""""""Vtwuv"Uvcvg""""Tcvg"*rru+""""Dwtuv"Kpvgtxcn
"/////////////////"/////////////////"/////////////////"/////////////////
"Ik7134""""""Vtwuvgf""""""Pqpg""""""P1C
```

## Applying ARP ACLs for DAI Filtering

To apply an ARP ACL, perform this task:

|        | Command                                                                                         | Purpose                           |
|--------|-------------------------------------------------------------------------------------------------|-----------------------------------|
| Step 1 | <code>Tqwwgt%eqphkiwtg"vgtokpcn"</code>                                                         | Enters global configuration mode. |
| Step 2 | <code>Tqwwgt%"kr"ctr"kpurgevkqp"hknvgt"ctracenapcog"xncp"}vlan_ID"~"xncpatcpig;"]uvcvke_</code> | Applies the ARP ACL to a VLAN.    |
| Step 3 | <code>Tqwwgt*eqphki+%fq"ujqy"kr"ctr"kpurgevkqp"xncp"}vlan_ID"~"xncpatcpig;"</code>              | Verifies your entries.            |

- See the command reference for information about the **arp access-list** command.
- For `vlan_range`, you can specify a single VLAN or a range of VLANs:
  - To specify a single VLAN, enter a single VLAN number.
  - To specify a range of VLANs, enter a dash-separated pair of VLAN numbers.
  - You can enter a comma-separated list of VLAN numbers and dash-separated pairs of VLAN numbers.

- (Optional) Specify **static** to treat implicit denies in the ARP ACL as explicit denies and to drop packets that do not match any previous clauses in the ACL. DHCP bindings are not used.

If you do not specify this keyword, it means that there is no explicit deny in the ACL that denies the packet, and DHCP bindings determine whether a packet is permitted or denied if the packet does not match any clauses in the ACL.

- ARP packets containing only IP-to-MAC address bindings are compared against the ACL. Packets are permitted only if the access list permits them.

This example shows how to apply an ARP ACL named `example_arp_acl` to VLANs 10 through 12 and VLAN 15:

```
Tqwwgt%eqphkiwtg"vgtokpcn"
Gpvg"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqwwgt*eqphki+%kr"ctr"kpurgevkqp"hknvgt"gzcornagactracen"xncp"32/34.37"
Tqwwgt*eqphki+%fq"ujqy"kr"ctr"kpurgevkqp"xncp"32/34.37"~"dgikp"xncp"
"xncp""""Eqphkiwtcvkqp""""Qrgtcvkqp""""CEN"Ocvj""""Uvcvke"CEN
"/////////////////"/////////////////"/////////////////"/////////////////
""32""""Gpcdnf""""Kpcevkg""""gzcornagactracen""Pq"
```

```

""33""Gpcdnfgf""Kpcevkgxg""gzcornagactracen""Pq"
""34""Gpcdnfgf""Kpcevkgxg""gzcornagactracen""Pq"
""37""Gpcdnfgf""Kpcevkgxg""gzcornagactracen""Pq"
Xncp""CEN"Nqikiipi""FJER"Nqikiipi
""32""Fgp{""Fgp{""
""33""Fgp{""Fgp{""
""34""Fgp{""Fgp{""
""37""Fgp{""Fgp{""

```

## Configuring ARP Packet Rate Limiting



### Note

When DAI is hardware-accelerated, you can configure CoPP to rate limit ARP traffic that would be processed by the RP (for example, packets with a broadcast destination MAC address or the MAC address of the RP; see [Chapter 77, “Control Plane Policing \(CoPP\)”](#)).

When nonaccelerated DAI is enabled, the switch performs ARP packet validation checks, which makes the switch vulnerable to an ARP-packet denial-of-service attack. ARP packet rate limiting can prevent an ARP-packet denial-of-service attack.

To configure ARP packet rate limiting on a port, perform this task:

|        | Command                                                                                                                          | Purpose                                         |
|--------|----------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------|
| Step 1 | <code>Tqvwgt%<b>"eqphkiwtg"vgtokpcn</b></code>                                                                                   | Enters global configuration mode.               |
| Step 2 | <code>Tqvwgt*eqphki+%<b>"kpvgtthceg"</b>}type slot/port"~"</code><br><code><b>"rqtv/ejcppgn"</b>pwdgti"</code>                   | Selects the interface to be configured.         |
| Step 3 | <code>Tqvwgt*eqphki/kh+%<b>"kr"ctr"kpurgevkqp"nkokv"</b>}tcvg"</code><br><code><b>"rru"]dwtuv"kpvgtxcn"ugeqfu_"~"</b>ppgi</code> | (Optional) Configures ARP packet rate limiting. |
| Step 4 | <code>Tqvwgt*eqphki/kh+%<b>"fq"ujqy"kr"ctr"kpurgevkqp"</b></code><br><code><b>"kpvgtthcegu"</b></code>                           | Verifies the configuration.                     |

- The default rate is 15 pps on untrusted interfaces and unlimited on trusted interfaces.
- For **rate pps**, specify an upper limit for the number of incoming packets processed per second. The range is 0 to 2048 pps.
- The **rate none** keywords specify that there is no upper limit for the rate of incoming ARP packets that can be processed.
- (Optional) For **burst interval seconds** (default is 1), specify the consecutive interval, in seconds, over which the interface is monitored for a high rate of ARP packets. The range is 1 to 15.
- When the rate of incoming ARP packets exceeds the configured limit, the switch places the port in the error-disabled state. The port remains in the error-disabled state until you enable error-disabled recovery, which allows the port to emerge from the error-disabled state after a specified timeout period.
- Unless you configure a rate-limiting value on an interface, changing the trust state of the interface also changes its rate-limiting value to the default value for the configured trust state. After you configure the rate-limiting value, the interface retains the rate-limiting value even when you change its trust state. If you enter the **no ip arp inspection limit** interface configuration command, the interface reverts to its default rate-limiting value.



The additional validations do the following:

- **dst-mac**—Checks the destination MAC address in the Ethernet header against the target MAC address in ARP body. This check is performed for ARP responses. When enabled, packets with different MAC addresses are classified as invalid and are dropped.
- **ip**—Checks the ARP body for invalid and unexpected IP addresses. Addresses include 0.0.0.0, 255.255.255.255, and all IP multicast addresses. Sender IP addresses are checked in all ARP requests and responses, and target IP addresses are checked only in ARP responses.
- **src-mac**—Checks the source MAC address in the Ethernet header against the sender MAC address in the ARP body. This check is performed on both ARP requests and responses. When enabled, packets with different MAC addresses are classified as invalid and are dropped.

When enabling additional validation, note the following information:

- You must specify at least one of the keywords.
- Each **ip arp inspection validate** command overrides the configuration from any previous commands. If an **ip arp inspection validate** command enables **src-mac** and **dst-mac** validations, and a second **ip arp inspection validate** command enables IP validation only, the **src-mac** and **dst-mac** validations are disabled as a result of the second command.

This example shows how to enable **src-mac** additional validation:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+%"kr"ctr"kpurgevkqp"xcnkfcvg"ute/oce"
Tqwgvt*eqphki+%"fq"ujqy"kr"ctr"kpurgevkqp"~"kpenwfg"cdngf&
Uqwtg"Oce"Xcnkfcvkqp""""<"Gpcdngf
Fguvkpcvkqp"Oce"Xcnkfcvkqp"<"Fkucdngf
KR"Cfftguu"Xcnkfcvkqp""""<"Fkucdngf
```

This example shows how to enable **dst-mac** additional validation:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+%"kr"ctr"kpurgevkqp"xcnkfcvg"fuv/oce"
Tqwgvt*eqphki+%"fq"ujqy"kr"ctr"kpurgevkqp"~"kpenwfg"cdngf&
Uqwtg"Oce"Xcnkfcvkqp""""<"Fkucdngf
Fguvkpcvkqp"Oce"Xcnkfcvkqp"<"Gpcdngf
KR"Cfftguu"Xcnkfcvkqp""""<"Fkucdngf
```

This example shows how to enable **ip** additional validation:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+%"kr"ctr"kpurgevkqp"xcnkfcvg"kr"
Tqwgvt*eqphki+%"fq"ujqy"kr"ctr"kpurgevkqp"~"kpenwfg"cdngf&
Uqwtg"Oce"Xcnkfcvkqp""""<"Fkucdngf
Fguvkpcvkqp"Oce"Xcnkfcvkqp"<"Fkucdngf
KR"Cfftguu"Xcnkfcvkqp""""<"Gpcdngf
```

This example shows how to enable **src-mac** and **dst-mac** additional validation:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+%"kr"ctr"kpurgevkqp"xcnkfcvg"ute/oce"fuv/oce"
Tqwgvt*eqphki+%"fq"ujqy"kr"ctr"kpurgevkqp"~"kpenwfg"cdngf&
Uqwtg"Oce"Xcnkfcvkqp""""<"Gpcdngf
Fguvkpcvkqp"Oce"Xcnkfcvkqp"<"Gpcdngf
KR"Cfftguu"Xcnkfcvkqp""""<"Fkucdngf
```

This example shows how to enable **src-mac**, **dst-mac**, and **ip** additional validation:

```
Tqvwgt%"eqphkiwtg"vgtokpcn
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%"kr"ctr"kpurgevkqp"xcnkfcvg"ute/oce"fuw/oce"kr"
Tqvwgt*eqphki+%"fq"ujgy"kr"ctr"kpurgevkqp"~"kpenwfg"cdngf&
Ugwteg"Oce"Xcnkfcvkqp""""<"Gpcdnfg
Fguvkpcvkqp"Oce"Xcnkfcvkqp"<"Gpcdnfg
KR"Cffftguu"Xcnkfcvkqp""""<"Gpcdnfg
```

## Configuring DAI Logging

- [DAI Logging Overview, page 80-13](#)
- [DAI Logging Restrictions, page 80-13](#)
- [Configuring the DAI Logging Buffer Size, page 80-13](#)
- [Configuring the DAI Logging System Messages, page 80-14](#)
- [Configuring DAI Log Filtering, page 80-15](#)

### DAI Logging Overview

When DAI drops a packet, it places an entry in the log buffer and then generates system messages on a rate-controlled basis. After the message is generated, DAI clears the entry from the log buffer. Each log entry contains flow information, such as the receiving VLAN, the port number, the source and destination IP addresses, and the source and destination MAC addresses.

A log-buffer entry can represent more than one packet. For example, if an interface receives many packets on the same VLAN with the same ARP parameters, DAI combines the packets as one entry in the log buffer and generates a single system message for the entry.

If the log buffer overflows, it means that a log event does not fit into the log buffer, and the display for the **show ip arp inspection log** privileged EXEC command is affected. Two dashes (“--”) appear instead of data except for the packet count and the time. No other statistics are provided for the entry. If you see this entry in the display, increase the number of entries in the log buffer or increase the logging rate.

### DAI Logging Restrictions

DAI logging, including both ACL logging and DHCP logging, is not compatible with DAI hardware acceleration. When DAI is hardware-accelerated, DAI logging is disabled. Regardless of the enable state of DAI hardware acceleration, DAI configured to use an ARP ACL with the [acl-match matchlog](#) keywords is processed in software and supports logging.

### Configuring the DAI Logging Buffer Size

To configure the DAI logging buffer size, perform this task:

|        | Command                            | Purpose                           |
|--------|------------------------------------|-----------------------------------|
| Step 1 | Tqvwgt% <b>"eqphkiwtg"vgtokpcn</b> | Enters global configuration mode. |

|        | Command                                                                     | Purpose                                                      |
|--------|-----------------------------------------------------------------------------|--------------------------------------------------------------|
| Step 2 | <code>Tqwgvt*eqphki+% "kr"ctr"kpurgevkqp"nqi/dwhhgt"gpvtkgu"pwodgt"</code>  | Configures the DAI logging buffer size (range is 0 to 1024). |
| Step 3 | <code>Tqwgvt*eqphki+% "fq"ujqy"kr"ctr"kpurgevkqp"nqi"~"kpenwfg"Uk g"</code> | Verifies the configuration.                                  |

This example shows how to configure the DAI logging buffer for 64 messages:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkgp0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+% "kr"ctr"kpurgevkqp"nqi/dwhhgt"gpvtkgu"86"
Tqwgvt*eqphki+% "fq"ujqy"kr"ctr"kpurgevkqp"nqi"~"kpenwfg"Uk|g"
Vqvcn"Nqi"Dwhhgt"Uk|g"<"86
```

## Configuring the DAI Logging System Messages

To configure the DAI logging system messages, perform this task:

|        | Command                                                                                                        | Purpose                            |
|--------|----------------------------------------------------------------------------------------------------------------|------------------------------------|
| Step 1 | <code>Tqwgvt%"eqphkiwtg"vgtokpcn</code>                                                                        | Enters global configuration mode.  |
| Step 2 | <code>Tqwgvt*eqphki+% "kr"ctr"kpurgevkqp"nqi/dwhhgt"nqiu"pwodgtaqhaoguucigu"kpvgtxcn"ngpivjakpaugeqpfu"</code> | Configures the DAI logging buffer. |
| Step 3 | <code>Tqwgvt*eqphki+% "fq"ujqy"kr"ctr"kpurgevkqp"nqi"</code>                                                   | Verifies the configuration.        |

- For **logs** *number\_of\_messages* (default is 5), the range is 0 to 1024. A 0 value means that the entry is placed in the log buffer, but a system message is not generated.
- For **interval** *length\_in\_seconds* (default is 1), the range is 0 to 86400 seconds (1 day). A 0 value means that a system message is immediately generated (and the log buffer is always empty). An interval setting of 0 overrides a log setting of 0.
- System messages are sent at the rate of *number\_of\_messages* per *length\_in\_seconds*.

This example shows how to configure DAI logging to send 12 messages every 2 seconds:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkgp0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+% "kr"ctr"kpurgevkqp"nqi/dwhhgt"nqiu"34"kpvgtxcn"4"
Tqwgvt*eqphki+% "fq"ujqy"kr"ctr"kpurgevkqp"nqi"~"kpenwfg"U{unqi"
U{unqi"tcvg"<"34"gpvtkgu"rgt"4"ugeqpfu0
```

This example shows how to configure DAI logging to send 20 messages every 60 seconds.

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkgp0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+% "kr"ctr"kpurgevkqp"nqi/dwhhgt"nqiu"42"kpvgtxcn"82"
Tqwgvt*eqphki+% "fq"ujqy"kr"ctr"kpurgevkqp"nqi"~"kpenwfg"U{unqi"
U{unqi"tcvg"<"42"gpvtkgu"rgt"82"ugeqpfu0
```

## Configuring DAI Log Filtering

To configure DAI log filtering, perform this task:

|        | Command                                                                                                                                               | Purpose                                 |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------|
| Step 1 | <code>Tqwvgt% "eqphkiwtg"vgtokpcn"</code>                                                                                                             | Enters global configuration mode.       |
| Step 2 | <code>Tqwvgt*eqphki+% "kr"ctr"kpurgevkqp"xncp"xncpatcpig"<br/>nqiikpi"}cen/ocvej"}ocvejnqi"~"pqpq;"~"<br/>fjer/dkpfkpiu"}cnn"~"pqpq"~"rgtokv;"</code> | Configures log filtering for each VLAN. |
| Step 3 | <code>Tqwvgt*eqphki+% "fq"ujqy"twppkpi/eqphki"~"kpenwfg"<br/>kr"ctr"kpurgevkqp"xncp"xncpatcpig"</code>                                                | Verifies the configuration.             |

- By default, all denied packets are logged.
- For *vlan\_range*, you can specify a single VLAN or a range of VLANs:
  - To specify a single VLAN, enter a single VLAN number.
  - To specify a range of VLANs, enter a dash-separated pair of VLAN numbers.
  - You can enter a comma-separated list of VLAN numbers and dash-separated pairs of VLAN numbers.
- **acl-match matchlog**—Logs packets based on the DAI ACL configuration. If you specify the **matchlog** keyword in this command and the **log** keyword in the **permit** or **deny** ARP access-list configuration command, ARP packets permitted or denied by the ACL are logged.
- **acl-match none**—Does not log packets that match ACLs.
- **dhcp-bindings all**—Logs all packets that match DHCP bindings.
- **dhcp-bindings none**—Does not log packets that match DHCP bindings.
- **dhcp-bindings permit**—Logs DHCP-binding permitted packets.

This example shows how to configure the DAI log filtering for VLAN 100 not to log packets that match ACLs:

```
Tqwvgt% "eqphkiwtg"vgtokpcn"
Gpvgt "eqphkiwtcvkqp"eqoocpfu."qpq"rgt"nkpq0" "Gpf"ykvj"EPVN1\0
Tqwvgt*eqphki+% "kr"ctr"kpurgevkqp"xncp"322"nqiikpi"cen/ocvej"pqpq"
Tqwvgt*eqphki+% "fq"ujqy"twppkpi/eqphki"~"kpenwfg"kr"ctr"kpurgevkqp"xncp"322"
kr"ctr"kpurgevkqp"xncp"322"nqiikpi"cen/ocvej"pqpq
```

## Displaying DAI Information

| Command                                                       | Description                                                                                                                                                                                            |
|---------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>show arp access-list [acl_name]</code>                  | Displays detailed information about ARP ACLs.                                                                                                                                                          |
| <code>show ip arp inspection interfaces [interface_id]</code> | Displays the trust state and the rate limit of ARP packets for the specified interface or all interfaces.                                                                                              |
| <code>show ip arp inspection vlan vlan_range</code>           | Displays the configuration and the operating state of DAI for the specified VLAN. If no VLANs are specified or if a range is specified, displays information only for VLANs with DAI enabled (active). |

| Command                                                             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|---------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>show ip arp inspection statistics</b> [ <i>vlan vlan_range</i> ] | Displays statistics for forwarded, dropped, MAC validation failure, IP validation failure, ACL permitted and denied, and DHCP permitted and denied packets for the specified VLAN. If no VLANs are specified or if a range is specified, displays information only for VLANs with DAI enabled (active).<br><br>The switch increments the number of forwarded packets for each ARP request and response packet on a trusted DAI port. The switch increments the number of ACL-permitted or DHCP-permitted packets for each packet that is denied by source MAC, destination MAC, or IP validation checks, and the switch increments the appropriate failure count. |
| <b>show ip arp inspection log</b>                                   | Displays the configuration and contents of the DAI log buffer.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

## Configuration Examples for DAI

- [Two Switches Support DAI, page 80-16](#)
- [One Switch Supports DAI, page 80-21](#)

### Two Switches Support DAI

- [Overview, page 80-16](#)
- [Configuring Switch A, page 80-17](#)
- [Configuring Switch B, page 80-18](#)

### Overview

This procedure shows how to configure DAI when two switches support this feature. Host 1 is connected to Switch A, and Host 2 is connected to Switch B as shown in [Figure 80-2 on page 80-5](#). Both switches are running DAI on VLAN 1 where the hosts are located. A DHCP server is connected to Switch A. Both hosts acquire their IP addresses from the same DHCP server. Switch A has the bindings for Host 1 and Host 2, and Switch B has the binding for Host 2. Switch A Gigabit Ethernet port 6/3 is connected to the Switch B Gigabit Ethernet port 3/3.



#### Note

- DAI depends on the entries in the DHCP snooping binding database to verify IP-to-MAC address bindings in incoming ARP requests and ARP responses. Make sure to enable DHCP snooping to permit ARP packets that have dynamically assigned IP addresses. For configuration information, see [Chapter 78, “Dynamic Host Configuration Protocol \(DHCP\) Snooping.”](#)
- This configuration does not work if the DHCP server is moved from Switch A to a different location.
- To ensure that this configuration does not compromise security, configure Gigabit Ethernet port 6/3 on Switch A and Gigabit Ethernet port 3/3 on Switch B as trusted.



## Configuring Switch A

To enable DAI and configure Gigabit Ethernet port 6/3 on Switch A as trusted, follow these steps:

### Step 1 Verify the connection between switches Switch A and Switch B:

```
UykvejC% "ujqy"efr"pgkijdqtu
Ecrdcknk{ "Eqfgu<"T"/"Tqwgvt. "V"/"Vtcpu"Dtkfig. "D"/"Uqwteg"Twvgv"Dtkfig
"U"/"Uykvej. "J"/"Jquv. "K"/"KIOR. "t"/"Tgrgcvt. "R"/"Rjqpg

Fgxkeg"KF""Ngecn"Kpvtgheg""Jqnfvg""Ecrdcknk{ ""Rncvhqto""Rqtv"KF
UykvejD""Hcu"815""399""T"U"K""YU/E8728""Hcu"515
UykvejC%
```

### Step 2 Enable DAI on VLAN 1 and verify the configuration:

```
UykvejC% "eqphkiwtg"vgtokpcn
Gpvg"eqphkiwtcvkqp"eqoocpfu. "qpg"rgt"nkp0" "Gpf"ykvj"EPVN1\0
UykvejC*eqphki+% "kr"ctr"kpurgevkqp"xnep"3
UykvejC*eqphki+% "gpf
UykvejC% "ujqy"kr"ctr"kpurgevkqp"xnep"3 "

Uqwteg"Oce"Xcnkfcvkqp" "<"Fkucngf
Fguvkcpcvkqp"Oce"Xcnkfcvkqp"<"Fkucngf
KR"Cffftguu"Xcnkfcvkqp" "<"Fkucngf

"Xncp""Eqphkiwtcvkqp""Qrgtcvkqp""CEN"Ocvj""Uvcvke"CEN
"/////////"/////////"/////////"/////////"/////////"
""3""Gpcdngf""Cevkxg""

"Xncp""CEN"Nqikpi""FJER"Nqikpi
"/////////"/////////"
""3""Fgp{ ""Fgp{ ""
UykvejC%
```

### Step 3 Configure Gigabit Ethernet port 6/3 as trusted:

```
UykvejC% "eqphkiwtg"vgtokpcn
Gpvg"eqphkiwtcvkqp"eqoocpfu. "qpg"rgt"nkp0" "Gpf"ykvj"EPVN1\0
UykvejC*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv"815
UykvejC*eqphki/kh+% "kr"ctr"kpurgevkqp"vtwuv"
UykvejC*eqphki/kh+% "gpf
UykvejC% "ujqy"kr"ctr"kpurgevkqp"kpvgthcegu"ikicdkvgvjgtpgv"815

Kpvgthceg""Vtwuv"Uvcvg""Tcvg"*rru+
"/////////"/////////"/////////"
"Ik815""Vtwuvgf""Pqpg
UykvejC%
```

### Step 4 Verify the bindings:

```
UykvejC% "ujqy"kr"fjer"upqqrkpi"dkpfkpi"
OceCffftguu""KrCffftguu""Ngcug*uge+"V{rg""XNCP"Kpvgthceg
/////////"/////////"/////////"/////////"/////////"
22<24<22<24<22<24""32030304""6;;5""fjer/upqqrkpi"3""Ikicdkvgvjgtpgv816
UykvejC%
```

### Step 5 Check the statistics before and after DAI processes any packets:

```
UykvejC% "ujqy"kr"ctr"kpurgevkqp"uvcvkuvkeu"xnep"3

Xncp""Hqtyctfgf""Ftqrrgf""FJER"Ftgru""CEN"Ftgru"
"/////////"/////////"/////////"/////////"/////////"
""3""2""2""2""2"
```

```
"Xncp" "FJER"Rgtokvu" "CEN"Rgtokvu" "Uqwteg"OCE"Hcknwtgu
"////" "/////" "/////" "/////" "/////" "/////"
"3" "2" "2" "2"
```

```
"Xncp" "Fguv"OCE"Hcknwtgu" "KR"Xcnkfcvkqp"Hcknwtgu
"////" "/////" "/////" "/////" "/////" "/////"
"3" "2" "2" "2"
UykvejC%
```

If Host 1 then sends out two ARP requests with an IP address of 10.1.1.2 and a MAC address of 0002.0002.0002, both requests are permitted, as reflected in the following statistics:

```
UykvejC% "ujqy"kr"ctr"kpurgevkqp"uvcvkuvkeu"xncp"3
```

```
"Xncp" "Hqtyctfgf" "Ftqrrgf" "FJER" Ftgru" "CEN" Ftgru"
"////" "/////" "/////" "/////" "/////" "/////"
"3" "4" "2" "2"
```

```
"Xncp" "FJER"Rgtokvu" "CEN"Rgtokvu" "Uqwteg"OCE"Hcknwtgu
"////" "/////" "/////" "/////" "/////" "/////"
"3" "4" "2" "2"
```

```
"Xncp" "Fguv"OCE"Hcknwtgu" "KR"Xcnkfcvkqp"Hcknwtgu
"////" "/////" "/////" "/////" "/////" "/////"
"3" "2" "2" "2"
UykvejC%
```

If Host 1 then tries to send an ARP request with an IP address of 10.1.1.3, the packet is dropped and an error message is logged:

```
22<34<2:<"UYaFCK/6/FJERaUPQQRKPIaFGP [<"4"Kpxcnkf"CTRu"*Tgs+"qp"Ik816."xncp"
30*] 22240222402224132030305122220222022212020202124<64<57"WVE"Vwg"Lwn"32"4223_+
UykvejC% "ujqy"kr"ctr"kpurgevkqp"uvcvkuvkeu"xncp"3
UykvejC%
```

The statistics will display as follows:

```
Xncp" "Hqtyctfgf" "Ftqrrgf" "FJER" Ftgru" "CEN" Ftgru"
"////" "/////" "/////" "/////" "/////" "/////"
"3" "4" "4" "4"
```

```
"Xncp" "FJER"Rgtokvu" "CEN"Rgtokvu" "Uqwteg"OCE"Hcknwtgu
"////" "/////" "/////" "/////" "/////" "/////"
"3" "4" "2" "2"
```

```
"Xncp" "Fguv"OCE"Hcknwtgu" "KR"Xcnkfcvkqp"Hcknwtgu
"////" "/////" "/////" "/////" "/////" "/////"
"3" "2" "2" "2"
UykvejC%
```

## Configuring Switch B

To enable DAI and configure Gigabit Ethernet port 3/3 on Switch B as trusted, follow these steps:

### Step 1 Verify the connectivity:

```
UykvejC% "ujqy"efr"pgkijdqtu"
Bcrcdknk{ "Eqfgu<"T"/"Tqvvgt. "V"/"Vtcpu"Dtkfig. "D"/"Uqwteg" Tqwvg"Dtkfig
"U"/"Uykvej. "J"/"Jquv. "K"/"KIOR. "t"/"Tgrgcvg. "R"/"Rjqpg
```

```
Fgxkeg"KF""""""Nqecn"Kpvt heg""""Jqnf vog""""Ecrcdknk v{"Rncvhqto""Rqtv"KF
UykvejD""""""Hcu"515""""""342""""""T"U"K""""YU/E8728""Hcu"815
UykvejD%
```

### Step 2 Enable DAI on VLAN 1, and verify the configuration:

```
UykvejD%"eqphkiwtg"vgtokpcn
Gpvg t"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp g0""Gpf"ykvj"EPVN1\0
UykvejD*eqphki+% "kr"ctr"kpurgevkqp"xncp"3
UykvejD*eqphki+% "gpf
UykvejD%"ujqy"kr"ctr"kpurgevkqp"xncp"3

Uqwt eg"Oce"Xcnkf cvkqp""""<"Fkucdngf
Fguvkpcvkqp"Oce"Xcnkf cvkqp"<"Fkucdngf
KR"Cfftguu"Xcnkf cvkqp""""<"Fkucdngf

"Xncp""""Eqphkiwtcvkqp""""Qrgtcvkqp""CEN"Ocvej""""Uvcvke"CEN
"////////////////////////""////////////////////////""////////////////////////
""3""Gpcdngf""Cevkxg""

"Xncp""""CEN"Nqiikpi""""FJER"Nqiikpi
"////////////////////////""////////////////////////
""3""Fgp{"Fgp{"
UykvejD%
```

### Step 3 Configure Gigabit Ethernet port 3/3 as trusted:

```
UykvejD%"eqphkiwtg"vgtokpcn
Gpvg t"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp g0""Gpf"ykvj"EPVN1\0
UykvejD*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv"515
UykvejD*eqphki/kh+% "kr"ctr"kpurgevkqp"vtwuv
UykvejD*eqphki/kh+% "gpf
UykvejD%"ujqy"kr"ctr"kpurgevkqp"kpvgthcegu
```

```
Kpvgthceg""""Vtwuv"Uvcvg""""Tcvg"*rru+
"////////////////////////""////////////////////////
Ik313""Wpvtwuvgf""37
Ik314""Wpvtwuvgf""37
Ik513""Wpvtwuvgf""37
Ik514""Wpvtwuvgf""37
Ik515""Vtwuvgf""Pqpg
Ik516""Wpvtwuvgf""37
Ik517""Wpvtwuvgf""37
Ik518""Wpvtwuvgf""37
Ik519""Wpvtwuvgf""37

>qwvrwv"vtwpecvgf@
UykvejD%
```

### Step 4 Verify the list of DHCP snooping bindings:

```
UykvejD%"ujqy"kr"fjer"upqqrkpi"dkpfkpi
OceCfftguu""""KRCfftguu""""Ngcug*uge+"V{rg""""XNCP""Kpvgthceg
////////////////////////""////////////////////////""////////////////////////
22<23<22<23<23""32030303""6;;7""fjer/upqqrkpi"3""Ikicdkvgvjgtpgv516
UykvejD%
```

### Step 5 Check the statistics before and after DAI processes any packets:

```
UykvejD%"ujqy"kr"ctr"kpurgevkqp"uvcvkuvkeu"xncp"3

Xncp""""Hqtyctfgf""""Ftqrrgf""""FJER"Ftqru""""CEN"Ftqru"
"////////////////////////""////////////////////////
"////////////////////////
```









# Traffic Storm Control

---

- [Prerequisites for Traffic Storm Control, page 81-1](#)
- [Restrictions for Traffic Storm Control, page 81-2](#)
- [Information About Traffic Storm Control, page 81-2](#)
- [Default Setting for Traffic Storm Control, page 81-4](#)
- [How to Enable Traffic Storm Control, page 81-4](#)
- [Displaying Traffic Storm Control Settings, page 81-5](#)



## Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
  - Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.
- 



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

---

## Prerequisites for Traffic Storm Control

None.

## Restrictions for Traffic Storm Control

- The following LAN switching modules do not support traffic storm control:
  - WS-X6148A-GE-45AF
  - WS-X6148A-GE-TX
- The switch supports multicast and unicast traffic storm control on WS-X6148A-RJ-45, Gigabit Ethernet, and 10-Gigabit Ethernet LAN ports.
- The switch supports broadcast traffic storm control on all LAN ports except on those modules previously noted.
- Except for BPDUs, traffic storm control does not differentiate between control traffic and data traffic.
- When multicast suppression is enabled, traffic storm control suppresses BPDUs when the multicast suppression threshold is exceeded on these modules:
  - WS-X6848-SFP-2T, WS-X6748-SFP
  - WS-X6824-SFP-2T, WS-X6724-SFP
  - WS-X6848-TX-2T, WS-X6748-GE-TX
  - WS-X6704-10GE

When multicast suppression is enabled on the listed modules, do not configure traffic storm control on STP-protected ports that need to receive BPDUs.

Except on the listed modules, traffic storm control does not suppress BPDUs.

## Information About Traffic Storm Control

A traffic storm occurs when packets flood the LAN, creating excessive traffic and degrading network performance. The traffic storm control feature prevents LAN ports from being disrupted by a broadcast, multicast, or unicast traffic storm on physical interfaces.

Traffic storm control (also called traffic suppression) monitors incoming traffic levels over a 1-second traffic storm control interval and, during the interval, compares the traffic level with the traffic storm control level that you configure. The traffic storm control level is a percentage of the total available bandwidth of the port. Each port has a single traffic storm control level that is used for all types of traffic (broadcast, multicast, and unicast).

Traffic storm control monitors the level of each traffic type for which you enable traffic storm control in 1-second traffic storm control intervals. Within an interval, when the ingress traffic for which traffic storm control is enabled reaches the traffic storm control level that is configured on the port, traffic storm control drops the traffic until the traffic storm control interval ends.


By default, within an interval, when the ingress traffic for which traffic storm control is enabled reaches the traffic storm control level that is configured on the port, traffic storm control drops the traffic until the traffic storm control interval ends. These are the configurable traffic storm control optional actions:

- Shutdown—When a traffic storm occurs, traffic storm control puts the port into the error-disabled state. To reen able ports, use the error-disable detection and recovery feature or the **shutdown** and **no shutdown** commands.
- Trap—When a traffic storm occurs, traffic storm control generates an SNMP trap.



Figure 81-1 shows the broadcast traffic patterns on a LAN interface over a given interval. In this example, traffic storm control occurs between times T1 and T2 and between T4 and T5. During those intervals, the amount of broadcast traffic exceeded the configured threshold.

**Figure 81-1 Broadcast Suppression**



The traffic storm control threshold numbers and the time interval combination make the traffic storm control algorithm work with different levels of granularity. A higher threshold allows more packets to pass through.

Traffic storm control is implemented in hardware. The traffic storm control circuitry monitors packets passing from a LAN interface to the switching bus. Using the Individual/Group bit in the packet destination address, the traffic storm control circuitry determines if the packet is unicast or broadcast, keeps track of the current count of packets within the 1-second interval, and when a threshold is reached, filters out subsequent packets.

Because hardware traffic storm control uses a bandwidth-based method to measure traffic, the most significant implementation factor is setting the percentage of total available bandwidth that can be used by controlled traffic. Because packets do not arrive at uniform intervals, the 1-second interval during which controlled traffic activity is measured can affect the behavior of traffic storm control.

The following are examples of traffic storm control behavior:

- If you enable broadcast traffic storm control, and broadcast traffic exceeds the level within a 1-second traffic storm control interval, traffic storm control drops all broadcast traffic until the end of the traffic storm control interval.
- If you enable broadcast and multicast traffic storm control, and the combined broadcast and multicast traffic exceeds the level within a 1-second traffic storm control interval, traffic storm control drops all broadcast and multicast traffic until the end of the traffic storm control interval.
- If you enable broadcast and multicast traffic storm control, and broadcast traffic exceeds the level within a 1-second traffic storm control interval, traffic storm control drops all broadcast and multicast traffic until the end of the traffic storm control interval.
- If you enable broadcast and multicast traffic storm control, and multicast traffic exceeds the level within a 1-second traffic storm control interval, traffic storm control drops all broadcast and multicast traffic until the end of the traffic storm control interval.

# Default Setting for Traffic Storm Control

None.

## How to Enable Traffic Storm Control

To enable traffic storm control, perform this task:

|        | Command                                                                                                                                                                                                    | Purpose                                                                                                                                                                                                        |
|--------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"kpvgthceg"</b>}}type slot/port;~"<br/>}rqtv/ejcppgn"pwodgt; ;</code>                                                                                                              | Selects an interface to configure.                                                                                                                                                                             |
| Step 2 | <code>Tqwvgt*eqphki/kh+%<b>"uvqto/eqpvtqn"dtqcfecuv"ngxgn"</b><br/>ngxgn] 0ngxgn_ "</code>                                                                                                                 | Enables broadcast traffic storm control on the interface, configures the traffic storm control level, and applies the traffic storm control level to all traffic storm control modes enabled on the interface. |
| Step 3 | <code>Tqwvgt*eqphki/kh+%<b>"uvqto/eqpvtqn"ownvkecuv"ngxgn"</b><br/>ngxgn] 0ngxgn_ "</code><br><br><b>Note</b> The <b>storm-control multicast</b> command is supported only on Gigabit Ethernet interfaces. | Enables multicast traffic storm control on the interface, configures the traffic storm control level, and applies the traffic storm control level to all traffic storm control modes enabled on the interface. |
| Step 4 | <code>Tqwvgt*eqphki/kh+%<b>"uvqto/eqpvtqn"wpkecuv"ngxgn"</b><br/>ngxgn] 0ngxgn_ "</code><br><br><b>Note</b> The <b>storm-control unicast</b> command is supported only on Gigabit Ethernet interfaces.     | Enables unicast traffic storm control on the interface, configures the traffic storm control level, and applies the traffic storm control level to all traffic storm control modes enabled on the interface.   |
| Step 5 | <code>Tqwvgt*eqphki/kh+%<b>"gpf"</b></code>                                                                                                                                                                | Exits configuration mode.                                                                                                                                                                                      |

- You can configure traffic storm control on port channel interfaces.
- Do not configure traffic storm control on ports that are members of an EtherChannel. Configuring traffic storm control on ports that are configured as members of an EtherChannel puts the ports into a suspended state.
- Specify the level as a percentage of the total interface bandwidth:
  - The level can be from 0 to 100.
  - The optional fraction of a level can be from 0 to 99.
  - 100 percent means no traffic storm control.
  - 0.0 percent suppresses all traffic.
- On these modules, these levels suppress all traffic:
  - WS-X6704-10GE: 0.33 percent or less
  - WS-X6824-SFP-2T, WS-X6724-SFP 10Mbps ports: 0.33 percent or less
  - WS-X6848-SFP-2T, WS-X6748-SFP 100Mbps ports: 0.03 percent or less
  - WS-X6848-TX-2T, WS-X6748-GE-TX 100Mbps ports: 0.03 percent or less
  - WS-X6816-10G-2T, WS-X6716-10G  
Oversubscription Mode: 0.29 percent or less

This example shows how to enable multicast traffic storm control on Gigabit Ethernet interface 3/16 and how to configure the traffic storm control level at 70.5 percent:

This example shows how the traffic storm control level configured for one mode affects all other modes that are already configured on the Gigabit Ethernet interface 4/10:

```
Tqwvgt%"ujgy"twp"kpvgt%iki6132
Dwnfkpi"eqphkiwtcvkqp000

Ewttgvp"eqphkiwtcvkqp"<"398"d{vgu

Tqwvgt%"kpvgthceg"IkicdkvGvjgtpgv6132
Tqwvgt%"uykjejrqt
Tqwvgt%"uykjejrqtv"oqfg"ceeguu
Tqwvgt%"uvqto/eqpvtqn"dtqcfecev"ngxgn"92022
Tqwvgt%"uvqto/eqpvtqn"ownvkecev"ngxgn"92022
Tqwvgt%"urcphpki/vtgg"rqtvhcev"gfig
Tqwvgt%"gpf

Tqwvgt%"eqphkiwtg"vgtokpcn
Tqwvgt*eqphki+% "kpvgthceg"ikicdkvgvjgtpgv"6132
Tqwvgt*eqphki/kh+% "uvqto/eqpvtqn"wpkecev"ngxgn"42
Tqwvgt*eqphki/kh+%"gpf

Tqwvgt%"ujgy"kpvgtthcegu"ikicdkvgvjgtpgv"6132"eqwpvgtu"uvqto/eqpvtqn

Rqtv"" "" "WecuvUwrr"/ "" "" "OecuvUwrr"/ "" "" "DecuvUwrr"/ "" "VqvcnUwrrFkuectfu
Ik6132"" "" "" "42022"" "" "" "" "42022"" "" "" "" "42022"" "" "" "" "" "2

Tqwvgt%
```

| Command                                                                                                          | Purpose                                                                                                                                    |
|------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwvgt% "ujqy"kpvgthcegu"} type slot/port; "~"<br/>} rqtv/ejcppgn pwodgt;_ "uykvej rqtv</code>             | Displays the administrative and operational status of all Layer 2 LAN ports or the specified Layer 2 LAN port.                             |
| <code>Tqwvgt% "ujqy"kpvgthcegu"} type slot/port; "~"<br/>} rqtv/ejcppgn pwodgt;_ "eqwpvgtu"uvqto/eqpvtqn"</code> | Displays the total number of packets discarded for all three traffic storm control modes, on all interfaces or on the specified interface. |
| <code>Tqwvgt% "ujqy"kpvgthcegu"eqwpvgtu"uvqto/eqpvtqn"] oqfwng"<br/>unqvapwodgt;_</code>                         |                                                                                                                                            |

### Note

The **show interfaces** [*{interface\_type slot/port}*] **counters** command does not display the discard count. You must enter the **storm-control** keyword to display the discard count.

**Tip**

---

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

---



# Unknown Unicast and Multicast Flood Control

---

- [Prerequisites for Unknown Traffic Flood Control, page 82-1](#)
- [Restrictions for Unknown Traffic Flood Control, page 82-2](#)
- [Information About Unknown Traffic Flood Control, page 82-2](#)
- [Default Settings for Unknown Traffic Flood Control, page 82-2](#)
- [How to Configure Unknown Traffic Flood Control, page 82-2](#)
- [Configuration Examples for Unknown Traffic Flood Control, page 82-3](#)



## Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for Unknown Traffic Flood Control

None.

# Restrictions for Unknown Traffic Flood Control

- Entering the **switchport block multicast** command on nonreceiver (router) ports of the VLAN could disrupt routing protocols. This command could also disrupt ARP functionality and other protocols, such as Network Time Protocol (NTP), that make use of local subnetwork multicast control groups in the 224.0.0.0/24 range.
- When unknown unicast flood rate-limiting (UUFRL) is enabled, per-VLAN learning must be enabled on all the Layer 3 routed ports, otherwise, any unicast flooded packet coming into a routed port will also be rate-limited by UUFRL.

# Information About Unknown Traffic Flood Control

By default, unknown unicast and multicast traffic is flooded to all Layer 2 ports in a VLAN. You can use the unknown unicast flood blocking (UUFB), unknown multicast flood blocking (UMFB), and unknown unicast flood rate-limiting (UUFRL) features to prevent or limit this traffic.

The UUFB and UMFB features block unknown unicast and multicast traffic flooding at a specific port, only permitting egress traffic with MAC addresses that are known to exist on the port. The UUFB and UMFB features are supported on all ports that are configured with the **switchport** command, including private VLAN (PVLAN) ports.

The UUFRL feature globally rate limits unknown unicast traffic on all VLANs.

# Default Settings for Unknown Traffic Flood Control

None.

# How to Configure Unknown Traffic Flood Control

- [How to Configure UUFB or UMFB, page 82-2](#)
- [How to Configure UUFRL, page 82-3](#)

# How to Configure UUFB or UMFB

To configure UUFB or UFMB, perform this task:

|        | Command                                                                                       | Purpose                                                          |
|--------|-----------------------------------------------------------------------------------------------|------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt%<b>"eqphkiwtg"vgtokpcn</b></code>                                                | Enters global configuration mode.                                |
| Step 2 | <code>Tqwgvt*eqphki+%<b>"kpvgthceg"</b>}}type slot/port;~"<br/>}rqtv/ejcppgn"pwodgt; "</code> | Selects the interface to configure.                              |
| Step 3 | <code>Tqwgvt*eqphki/kh+%<b>"uykvejrqtv"</b></code>                                            | Configures the port for Layer 2 switching.                       |
| Step 4 | <code>Tqwgvt*eqphki/kh+%<b>"uykvejrqtv"dnqem"</b>}wpkecuv"~"<br/>ownvkecuv; "</code>          | Enables unknown unicast or multicast flood blocking on the port. |

## How to Configure UUFRL

To configure UUFRL, perform this task:

|        | Command                                                                                                                        | Purpose                                                                                   |
|--------|--------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt%<b>"eqphkiwtg"vgtokpcn</b>"</code>                                                                                | Enters global configuration mode.                                                         |
| Step 2 | <code>Tqwwgt*eqphki+%<b>"rncvhtgo"tcvg/nkokv"nc{gt4"wpmpqyp"</b></code><br><code><i>rate-in-pps</i> <i>burst-size_</i>"</code> | Enables UUFRL and sets the maximum packet rate.<br>(Optional) Specify a burst size limit. |
| Step 3 | <code>Tqwwgt*eqphki+%<b>"gzkv"</b></code>                                                                                      | Exits configuration mode.                                                                 |

When you configure UUFRL, note the following information:

- For the *rate-in-pps* value:
  - The range is 10 through 1,000,000 (entered as 1000000).
  - There is no default value.
  - Values lower than 1,000 (entered as 1000) should offer sufficient protection.
- For the *burst-size* value:
  - The range is 1 through 255.
  - The default is 10.
  - The default value should provide sufficient protection.

## Configuration Examples for Unknown Traffic Flood Control

This example shows how to configure UUFRL on Gigabit Ethernet port 5/12 and how to verify the configuration:

```
Tqwwgt%"eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"7134"
Tqwwgt*eqphki/kh+%"uykvejrgtv"dnqem"wpkecuv"
Tqwwgt*eqphki/kh+%"fq"ujqy"kpvgthceg"ikicdkvgvjgtpgv"7134"uykvejrgtv"~"kpenwfg"wpmpqyp"
Wpmpqyp"wpkecuv"dnqemgf<"gpcdnf
```

This example shows how to configure UUFRL with a rate limit of 1000 pps with a burst of 20 packets:

```
Tqwwgt%"eqphkiwtg"vgtokpcn"
Tqwwgt*eqphki+%"rncvhtgo"tcvg/nkokv"nc{gt4"wpmpqyp"3222"42"
Tqwwgt*eqphki+%"gzkv"
```



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)







---

## IEEE 802.1X Port-Based Authentication

---

- [Prerequisites for 802.1X Authentication, page 83-1](#)
- [Restrictions for 802.1X Authentication, page 83-2](#)
- [Information About 802.1X Port-Based Authentication, page 83-6](#)
- [Default Settings for 802.1X Port-Based Authentication, page 83-31](#)
- [How to Configure 802.1X Port-Based Authentication, page 83-32](#)
- [Displaying Authentication Status and Information, page 83-57](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for 802.1X Authentication

None.

# Restrictions for 802.1X Authentication

- [802.1X Authentication, page 83-2](#)
- [VLAN Assignment, Guest VLAN, Restricted VLAN, and Inaccessible Authentication Bypass, page 83-3](#)
- [MAC Authentication Bypass, page 83-5](#)
- [Web-Based Authentication, page 83-5](#)
- [Network Edge Access Topology \(NEAT\) and Client Information Signalling Protocol \(CISP\), page 83-5](#)

## 802.1X Authentication

- When 802.1X authentication is enabled, ports are authenticated before any other Layer 2 or Layer 3 features are enabled.
- If you try to change the mode of an 802.1X-enabled port (for example, from access to trunk), an error message appears, and the port mode is not changed.
- Although not recommended, you can configure port security and 802.1X port-based authentication on the same port.




---

**Note** 802.1X authentication is not compatible with port security with sticky MAC addresses or static secure MAC addresses. With Release 15.1(1)SY1 and later, you cannot configure 802.1X authentication with port security with sticky MAC addresses or static secure MAC addresses.

---

- If the VLAN to which an 802.1X-enabled port is assigned changes, this change is transparent and does not affect the switch. For example, this change occurs if a port is assigned to a RADIUS server-assigned VLAN and is then assigned to a different VLAN after reauthentication.  
If the VLAN to which an 802.1X port is assigned to shut down, disabled, or removed, the port becomes unauthorized. For example, the port is unauthorized after the access VLAN to which a port is assigned shuts down or is removed.
- The 802.1X protocol is supported on Layer 2 static-access ports, voice VLAN ports, and Layer 3 routed ports, but it is not supported on these port types:
  - Trunk port—If you try to enable 802.1X authentication on a trunk port, an error message appears, and 802.1X authentication is not enabled. If you try to change the mode of an 802.1X-enabled port to trunk, an error message appears, and the port mode is not changed.
  - Dynamic ports—A port in dynamic mode can negotiate with its neighbor to become a trunk port. If you try to enable 802.1X authentication on a dynamic port, an error message appears, and 802.1X authentication is not enabled. If you try to change the mode of an 802.1X-enabled port to dynamic, an error message appears, and the port mode is not changed.
  - Dynamic-access ports—If you try to enable 802.1X authentication on a dynamic-access (VLAN Query Protocol [VQP]) port, an error message appears, and 802.1X authentication is not enabled. If you try to change an 802.1X-enabled port to dynamic VLAN assignment, an error message appears, and the VLAN configuration is not changed.
  - EtherChannel port—Do not configure a port that is an active or a not-yet-active member of an EtherChannel as an 802.1X port. If you try to enable 802.1X authentication on an EtherChannel port, an error message appears, and 802.1X authentication is not enabled.

- Switched Port Analyzer (SPAN) and Remote SPAN (RSPAN) destination ports—You can enable 802.1X authentication on a port that is a SPAN or RSPAN destination port. However, 802.1X authentication is disabled until the port is removed as a SPAN or RSPAN destination port. You can enable 802.1X authentication on a SPAN or RSPAN source port.
- Before globally enabling 802.1X authentication on a switch by entering the **dot1x system-auth-control** global configuration command, remove the EtherChannel configuration from the interfaces on which 802.1X authentication and EtherChannel are configured.
- Because all traffic from unauthenticated hosts is forwarded to the switch processor, we recommend that you apply rate limiting to this traffic.

## 802.1X Host Mode

- In most cases when the host mode is changed on a port, any existing 802.1X authentications on that port are deleted. Exceptions are when changing from the single-host mode to any other mode, and when changing from multidomain mode to multiauth mode. In these two cases, existing 802.1X authentications are retained.
- If you enter the **authentication open** interface configuration command, any new MAC address detected on the port will be allowed unrestricted Layer 2 access to the network even before any authentication has succeeded. If you use this command, you should use static default ACLs to restrict Layer 3 traffic. For additional details, see the [“Pre-Authentication Open Access” section on page 83-15](#).
- When configuring multiple-hosts mode, if the multiple-hosts port becomes unauthorized (reauthentication fails or an EAPOL-logoff message is received), all attached clients are denied access to the network.
- When configuring MDA host mode, A third-party IP phone’s MAC address will initially be assigned to the data VLAN. When tagged voice packets are observed, the device will be removed from the data VLAN and placed on the voice VLAN.
- When configuring multiauth host mode, note the following guidelines:
  - If one client on a multiauth port becomes unauthorized (reauthentication fails or an EAPOL-logoff message is received from that client), the authorization status of the other attached clients is not changed.
  - RADIUS-assigned VLANs are not supported on multiauth ports, which can have only one data VLAN. If the authentication server sends VLAN-related attributes, the authentication will succeed but the VLAN assignment will be ignored.
  - Although multiple hosts are allowed on the data VLAN, only one host is allowed on the voice VLAN. When one IP phone has been authenticated, further IP phones on the same port will be denied authentication.
  - A multiauth port does not support a guest VLAN, authentication-fail VLAN, or a critical VLAN.

## VLAN Assignment, Guest VLAN, Restricted VLAN, and Inaccessible Authentication Bypass

- When 802.1X authentication is enabled on a port, you cannot configure a port VLAN that is equal to a voice VLAN.

- The 802.1X authentication with VLAN assignment feature is not supported on trunk ports, dynamic ports, or with dynamic-access port assignment through a VMPS.
- You can configure any VLAN except an RSPAN VLAN, a private primary PVLAN, or a voice VLAN as an 802.1X guest VLAN. The guest VLAN feature is not supported on internal VLANs (routed ports) or trunk ports; it is supported only on access ports.
- After you configure a guest VLAN for an 802.1X port to which a DHCP client is connected, you might need to get a host IP address from a DHCP server. You can change the settings for restarting the 802.1X authentication process on the switch before the DHCP process on the client times out and tries to get a host IP address from the DHCP server. Decrease the settings for the 802.1X authentication process (**dot1x timeout quiet-period** and **dot1x timeout tx-period** interface configuration commands). The amount to decrease the settings depends on the connected 802.1X client type.
- When configuring the 802.1X VLAN user distribution feature, follow these guidelines:
  - A maximum of 100 VLAN groups can be configured, and a maximum of 4094 VLANs can be mapped to a VLAN group.
  - A VLAN can be mapped to more than one VLAN group.
  - A guest VLAN, a critical VLAN, or a restricted VLAN can be mapped to a VLAN group.
  - A VLAN group name cannot be specified as a guest VLAN, a critical VLAN, or a restricted VLAN.
  - You can modify a VLAN group by adding or removing a VLAN, but at least one VLAN must be mapped to the VLAN group. If you remove the last VLAN from the VLAN group, the VLAN group is deleted.
  - Removing an existing VLAN from the VLAN group name does not revoke the authentication status of the ports in the VLAN, but the mappings are removed from the existing VLAN group.
  - Deleting an existing VLAN group name does not revoke the authentication status of the ports in any VLAN within the group, but the VLAN mappings to the VLAN group are removed.
- When configuring the inaccessible authentication bypass feature, follow these guidelines:
  - The inaccessible authentication bypass feature is supported on 802.1X ports in single-host mode, multiple-hosts mode, and MDA mode.
  - If the client is running Windows XP and the port to which the client is connected is in the critical-authentication state, Windows XP might report that the interface is not authenticated.
  - If the Windows XP client is configured for DHCP and has an IP address from the DHCP server, receiving an EAP-Success message on a critical port might not reinitiate the DHCP configuration process.
  - You can configure the inaccessible authentication bypass feature and the critical VLAN on an 802.1X port. If the switch tries to reauthenticate a critical port in a critical VLAN and all the RADIUS servers are unavailable, the switch changes the port state to the critical authentication state and the port remains in the critical VLAN.
  - You can configure the inaccessible bypass feature and port security on the same port.
- You can configure any VLAN except an RSPAN VLAN or a voice VLAN as an 802.1X restricted VLAN. The restricted VLAN feature is not supported on internal VLANs (routed ports) or trunk ports; it is supported only on access ports.

## MAC Authentication Bypass

- Unless otherwise stated, the MAC authentication bypass guidelines are the same as the 802.1X authentication guidelines. For more information, see the [“802.1X Authentication” section on page 83-2](#).
- If you disable MAC authentication bypass from a port after the port has been authorized with its MAC address, the session will be removed.
- When MAC authentication bypass with EAP has been enabled on an interface, it is not disabled by a subsequent **default interface** command on the interface.
- If the port is in the unauthorized state and the client MAC address is not the authentication-server database, the port remains in the unauthorized state. However, if the client MAC address is added to the database, the switch can use MAC authentication bypass to reauthorize the port.
- If the port is in the authorized state, the port remains in this state until reauthorization occurs.
- To use MAC authentication bypass on a routed port, make sure that MAC address learning is enabled on the port.
- You can optionally configure a timeout period for hosts that are connected by MAC authentication bypass but are inactive. The range is 1 to 65535 seconds, but should be set to a value less than the reauthentication timeout. You must enable port security before configuring a timeout value. For more information, see the [“How to Configure Port Security” section on page 85-4](#).

## Web-Based Authentication

- Fallback to web-based authentication is configured on switch ports in access mode. Ports in trunk mode are not supported.
- Fallback to web-based authentication is not supported on EtherChannels or EtherChannel members.
- Although fallback to web-based authentication is an interface-specific configuration, the web-based authentication fallback behavior is defined in a global fallback profile. If the global fallback configuration changes, the new profile will not be used until the next instance of authentication fallback.

For detailed information on configuring web-based authentication, see [Chapter 84, “Web-Based Authentication.”](#)

## Network Edge Access Topology (NEAT) and Client Information Signalling Protocol (CISP)

- You can configure NEAT ports with the same configurations as the other authentication ports. When the supplicant switch authenticates, the port mode is changed from *access* to *trunk* based on the switch vendor-specific attributes (VSAs). (device-traffic-class=switch).
- The VSA changes the authenticator switch port mode from access to trunk and enables 802.1x trunk encapsulation and the access VLAN if any would be converted to a native trunk VLAN. VSA does not change any of the port configurations on the supplicant
- Starting Release 15.2(1)SY1 NEAT support is available on FEX ports.

# Information About 802.1X Port-Based Authentication

- [802.1X Overview, page 83-6](#)
- [802.1X Device Roles, page 83-7](#)
- [Port-based Authentication Process, page 83-8](#)
- [Authentication Initiation and Message Exchange, page 83-10](#)
- [Ports in Authorized and Unauthorized States, page 83-12](#)
- [802.1X Host Modes, page 83-13](#)
- [802.1X Authentication with DHCP Snooping, page 83-15](#)
- [802.1X Accounting, page 83-16](#)
- [802.1X Authentication with VLAN Assignment, page 83-17](#)
- [Multiple VLANs and VLAN User Distribution with VLAN Assignment, page 83-18](#)
- [802.1X Authentication with Guest VLAN, page 83-19](#)
- [802.1X Authentication with Restricted VLAN, page 83-20](#)
- [802.1X Authentication with Inaccessible Authentication Bypass, page 83-21](#)
- [802.1X Authentication with Voice VLAN Ports, page 83-22](#)
- [802.1X Authentication with Port Security, page 83-23](#)
- [802.1X Authentication with ACL Assignments and Redirect URLs, page 83-23](#)
- [802.1X Authentication with Port Descriptors, page 83-26](#)
- [802.1X Authentication with MAC Authentication Bypass, page 83-26](#)
- [Network Admission Control Layer 2 IEEE 802.1X Validation, page 83-27](#)
- [802.1X Authentication with Wake-on-LAN, page 83-28](#)

## 802.1X Overview

This section describes the role of 802.1X port-based authentication as a part of a system of authentication, authorization, and accounting (AAA). The IEEE 802.1X standard defines a client and server-based access control and authentication protocol that restricts unauthorized clients from connecting to a LAN through publicly accessible ports. The authentication server authenticates each client connected to a switch port and assigns the port to a VLAN before making available any services offered by the switch or the LAN.

Until the client is authenticated, 802.1X access control allows only Extensible Authentication Protocol over LAN (EAPOL) traffic through the port to which the client is connected. After authentication is successful, normal traffic can pass through the port.

## 802.1X Device Roles

With 802.1X port-based authentication, the devices in the network have specific roles as shown in [Figure 83-1](#).

*Figure 83-1 802.1X Device Roles*

The specific roles shown in [Figure 83-1](#) are as follows:

- *Client*—The device (workstation) that requests access to the LAN and switch services and responds to requests from the switch. The workstation must be running 802.1X-compliant client software such as that offered in the Microsoft Windows XP operating system. (The client is the *supplicant* in the IEEE 802.1X specification.)



**Note** To resolve Windows XP network connectivity and 802.1X port-based authentication issues, read the Microsoft Knowledge Base article at this URL:  
<http://support.microsoft.com/kb/q303597/>

- *Authentication server*—Performs the actual authentication of the client. The authentication server validates the identity of the client and notifies the switch whether or not the client is authorized to access the LAN and switch services. Because the switch acts as the proxy, the authentication service is transparent to the client. The Remote Authentication Dial-In User Service (RADIUS) security system with Extensible Authentication Protocol (EAP) extensions is the only supported authentication server; it is available in Cisco Secure Access Control Server (ACS), version 3.0. RADIUS uses a client-server model in which secure authentication information is exchanged between the RADIUS server and one or more RADIUS clients.
- *Switch* (also called the *authenticator* and *back-end authenticator*)—Controls the physical access to the network based on the authentication status of the client. The switch acts as an intermediary (proxy) between the client and the authentication server, requesting identity information from the client, verifying that information with the authentication server, and relaying a response to the client. The switch includes the RADIUS client, which is responsible for encapsulating and decapsulating the EAP frames and interacting with the authentication server.

When the switch receives EAPOL frames and relays them to the authentication server, the Ethernet header is stripped and the remaining EAP frame is reencapsulated in the RADIUS format. The EAP frames are not modified or examined during encapsulation, and the authentication server must support EAP within the native frame format. When the switch receives frames from the authentication server, the server's frame header is removed, leaving the EAP frame, which is then encapsulated for Ethernet and sent to the client.

## Port-based Authentication Process

When 802.1X port-based authentication is enabled, these events occur:

- If the client supports 802.1X-compliant client software and the client's identity is valid, the 802.1X authentication succeeds and the switch grants the client access to the network.
- If 802.1X authentication times out while waiting for an EAPOL message exchange, the switch can use a fallback authentication method, such as MAC authentication bypass (MAB) or web-based authentication (webauth), if either or both are enabled:
  - If MAC authentication bypass is enabled, the switch relays the client's MAC address to the AAA server for authorization. If the client's MAC address is valid, the authorization succeeds and the switch grants the client access to the network.
  - If web-based authentication is enabled, the switch sends an HTTP login page to the client. The switch relays the client's username and password to the AAA server for authorization. If the login succeeds, the switch grants the client access to the network.

**Note**

---

The default order for authentication methods is 802.1X, and then MAB, then web-based authentication. You can change the order, and you can disable any of these methods.

---

- If fallback authentication methods are not enabled or are not successful, and if a guest VLAN is configured, the switch assigns the client to a guest VLAN that provides limited services.
- If the switch receives an invalid identity from an 802.1X-capable client and a restricted VLAN is specified, the switch can assign the client to a restricted VLAN that provides limited services.
- If the RADIUS authentication server is unavailable (down) and inaccessible authentication bypass is enabled, the switch grants the client access to the network by putting the port in the critical-authentication state in the user-specified critical VLAN.

**Note**


---

Inaccessible authentication bypass is also referred to as critical authentication or the AAA fail policy.

---



Figure 83-2 Authentication Flowchart



1 = This occurs if the switch does not detect EAPOL packets from the client.

The switch reauthenticates a client when one of these situations occurs:

- Periodic reauthentication is enabled, and the reauthentication timer expires.

You can configure the reauthentication timer to use a switch-specific value or to be based on values from the RADIUS server.

After 802.1X authentication using a RADIUS server is configured, the switch uses timers based on the Session-Timeout RADIUS attribute (Attribute[27]) and the Termination-Action RADIUS attribute (Attribute [29]).

The Session-Timeout RADIUS attribute (Attribute[27]) specifies the time after which reauthentication occurs.

The Termination-Action RADIUS attribute (Attribute [29]) specifies the action to take during reauthentication. The actions are Initialize and ReAuthenticate. When the Initialize action is set (the attribute value is DEFAULT), the 802.1X session ends, and connectivity is lost during reauthentication. When the ReAuthenticate action is set (the attribute value is RADIUS-Request), the session is not affected during reauthentication.

- You manually reauthenticate the client by entering the **dot1x re-authenticate interface type slot/port** privileged EXEC command.

## Authentication Initiation and Message Exchange

The switch or the client can initiate authentication. If you enable authentication on a port by using the **dot1x pae authenticator** and **authentication port-control auto** interface configuration commands, the switch must initiate authentication when it determines that the port link state transitions from down to up. The switch then sends an EAP-request/identity frame to the client to request its identity (typically, the switch sends an initial identity/request frame followed by one or more requests for authentication information). When the client receives the frame, it responds with an EAP-response/identity frame.

If the client does not receive an EAP-request/identity frame from the switch during bootup, the client can initiate authentication by sending an EAPOL-start frame, which prompts the switch to request the client's identity.




### Note

If 802.1X is not enabled or supported on the network access device, any EAPOL frames from the client are dropped. If the client does not receive an EAP-request/identity frame after three attempts to start authentication, the client transmits frames as if the port is in the authorized state. A port in the authorized state effectively means that the client has been successfully authenticated. For more information, see the [“Ports in Authorized and Unauthorized States” section on page 83-12](#).

When the client supplies its identity, the switch begins its role as the intermediary, passing EAP frames between the client and the authentication server until authentication succeeds or fails. If the authentication succeeds, the port becomes authorized. If the authentication fails, authentication can be retried, the port might be assigned to a VLAN that provides limited services, or network access is not granted. For more information, see the [“Ports in Authorized and Unauthorized States” section on page 83-12](#).


The specific exchange of EAP frames depends on the authentication method being used. [Figure 83-3](#) shows a message exchange initiated by the client using the One-Time-Password (OTP) authentication method with a RADIUS server.

**Figure 83-3** Message Exchange



If 802.1X authentication times out while waiting for an EAPOL message exchange, and MAC authentication bypass is enabled, the switch can authorize the client when the switch detects an Ethernet packet from the client. The switch uses the MAC address of the client as its identity and includes this information in the RADIUS-access/request frame that is sent to the RADIUS server. After the server sends the switch the RADIUS-access/accept frame (authorization is successful), the port becomes authorized. If MAB authorization fails and a guest VLAN is specified, the switch assigns the port to the guest VLAN. If the switch detects an EAPOL packet while waiting for an Ethernet packet, the switch stops the MAC authentication bypass process and starts 802.1X authentication.

Figure 83-4 Message Exchange During MAC Authentication Bypass



## Ports in Authorized and Unauthorized States

The switch port state determines whether or not the client is granted access to the network. The port starts in the *unauthorized* state. While in this state, the port disallows all ingress and egress traffic except for 802.1X protocol packets. When a client is successfully authenticated, the port transitions to the *authorized* state, allowing all traffic for the client to flow normally.

If a client that does not support 802.1X authentication connects to an unauthorized 802.1X port, the switch requests the client's identity. In this situation, the client does not respond to the request, the port remains in the unauthorized state, and the client is not granted access to the network.

In contrast, when an 802.1X-enabled client connects to a port that is not running the 802.1X protocol, the client initiates the authentication process by sending the EAPOL-start frame. When no response is received, the client sends the request for a fixed number of times. Because no response is received, the client begins sending frames as if the port is in the authorized state.

You control the port authorization state by using the **authentication port-control** interface configuration command and these keywords:

- **force-authorized**—Disables 802.1X port-based authentication and causes the port to transition to the authorized state without any authentication exchange required. The port transmits and receives normal traffic without 802.1X-based authentication of the client. This is the default setting.
- **force-unauthorized**—Causes the port to remain in the unauthorized state, ignoring all attempts by the client to authenticate. The switch cannot provide authentication services to the client through the interface.
- **auto**—Enables 802.1X port-based authentication and causes the port to begin in the unauthorized state, allowing only EAPOL frames to be sent and received through the port. The authentication process begins when the link state of the port transitions from down to up or when an EAPOL-start frame is received. The switch requests the identity of the client and begins relaying authentication messages between the client and the authentication server. Each client attempting to access the network is uniquely identified by the switch by using the client's MAC address.

If the client is successfully authenticated (receives an Accept frame from the authentication server), the port state changes to authorized, and all frames from the authenticated client are allowed through the port. If the authentication fails, the port remains in the unauthorized state, but authentication can be retried. If the authentication server cannot be reached, the switch can retransmit the request. If no response is received from the server after the specified number of attempts, authentication fails, and network access is not granted.

When a client logs off, it sends an EAPOL-logoff message, causing the switch port to transition to the unauthorized state.

If the link state of a port transitions from up to down, or if an EAPOL-logoff frame is received, the port returns to the unauthorized state.

## 802.1X Host Modes

- [Host Mode Overview, page 83-13](#)
- [Single-Host Mode, page 83-13](#)
- [Multiple-Hosts Mode, page 83-13](#)
- [Multidomain Authentication Mode, page 83-14](#)
- [Multi-Auth VLAN Assignment, page 83-14](#)
- [Multiauthentication Mode, page 83-15](#)
- [Pre-Authentication Open Access, page 83-15](#)

### Host Mode Overview

The 802.1X port's host mode determines whether more than one client can be authenticated on the port and how authentication will be enforced. You can configure an 802.1X port to use any of the four host modes described in the following sections. In addition, each mode may be modified to allow pre-authentication open access.


### Single-Host Mode

In single-host mode (see [Figure 83-1 on page 83-7](#)), only one client can be connected to the 802.1X-enabled port. The switch detects the client by sending an EAPOL frame when the port link state changes to the up state. If a client leaves or is replaced with another client, the switch changes the port link state to down, and the port returns to the unauthorized state.

### Multiple-Hosts Mode

In multiple-hosts mode, you can attach multiple hosts to a single 802.1X-enabled port. [Figure 83-5](#) shows 802.1X port-based authentication in a wireless LAN. In this mode, only one of the attached clients must be authorized for all clients to be granted network access. If the port becomes unauthorized (reauthentication fails or an EAPOL-logoff message is received), the switch denies network access to all of the attached clients. In this topology, the wireless access point is responsible for authenticating the clients attached to it, and it also acts as a client to the switch.


With the multiple-hosts mode enabled, you can use 802.1X authentication to authenticate the port and you can use port security to manage network access for all MAC addresses, including the client's MAC address.

**Figure 83-5 Multiple Host Mode Example**

## Multidomain Authentication Mode

Multidomain authentication (MDA) mode allows an IP phone (Cisco or third-party) and a single host behind the IP phone to authenticate independently, using 802.1X, MAC authentication bypass (MAB), or (for the host only) web-based authentication. In this application, multidomain refers to two domains — data and voice — and only two MAC addresses are allowed per port. The switch can place the host in the data VLAN and the IP phone in the voice VLAN, though they appear on the same switch port. The data VLAN assignment can be obtained from the vendor-specific attributes (VSAs) received from the authentication, authorization, and accounting (AAA) server during authentication.

Figure 83-6 shows a typical MDA application with a single host behind an IP phone connected to the 802.1X-enabled port. Because the client is not directly connected to the switch, the switch cannot detect a loss of port link if the client is disconnected. To prevent the possibility of another device using the established authentication of the disconnected client, later Cisco IP phones send a Cisco Discovery Protocol (CDP) host presence type length value (TLV) to notify the switch of changes in the attached client's port link state.

**Figure 83-6 Multidomain Authentication Mode Example**

## Multi-Auth VLAN Assignment

Multi-auth VLAN assignment uses existing commands to support the assignment of a RADIUS server-supplied VLAN in multiauth mode when these conditions occur:

- The host is the first host authorized on the port, and the RADIUS server supplies VLAN information.
- Subsequent hosts are authorized with a VLAN that matches the operational VLAN.
- A host is authorized on the port with no VLAN assignment, and subsequent hosts either have no VLAN assignment, or their VLAN information matches the operational VLAN.

- The first host authorized on the port has a group VLAN assignment, and subsequent hosts either have no VLAN assignment, or their group VLAN matches the group VLAN on the port. Subsequent hosts must use the same VLAN from the VLAN group as the first host. If a VLAN list is used, all hosts are subject to the conditions specified in the VLAN list.
- After a VLAN is assigned to a host on the port, subsequent hosts must have matching VLAN information or be denied access to the port.
- The behavior of the critical-auth VLAN is not changed for multiauth mode. When a host tries to authenticate and the server is not reachable, all authorized hosts are reinitialized in the configured VLAN.

**Note**

- Only one voice VLAN is supported on a multiauth port.
- You cannot configure a guest VLAN or an auth-fail VLAN in multiauth mode.

## Multiauthentication Mode

Multiauthentication (multiauth) mode allows one 802.1X/MAB client on the voice VLAN and multiple authenticated 802.1X/MAB/webauth clients on the data VLAN. When a hub or access point is connected to an 802.1X port, as in [Figure 83-5](#), multiauth mode provides enhanced security over multiple-hosts mode by requiring authentication of each connected client. For non-802.1X devices, MAB or web-based authentication can be used as the fallback method for individual host authentications, allowing different hosts to be authenticated through different methods on a single port.

Multiauth also supports MDA functionality on the voice VLAN by assigning authenticated devices to either a data or voice VLAN depending on the VSAs received from the authentication server.

## Pre-Authentication Open Access

Any of the four host modes may be additionally configured to allow a device to gain network access before authentication. This pre-authentication open access is useful in an application such as the Pre-boot eXecution Environment (PXE), where a device must access the network to download a bootable image containing an authentication client.

Pre-authentication open access is enabled by entering the **authentication open** command after host mode configuration, and acts as an extension to the configured host mode. For example, if pre-authentication open access is enabled with single-host mode, then the port will allow only one MAC address. When pre-authentication open access is enabled, initial traffic on the port is restricted only by whatever other access restriction, independent of 802.1X, is configured on the port. If no access restriction other than 802.1X is configured on the port, then a client device will have full access on the configured VLAN.

## 802.1X Authentication with DHCP Snooping

When the Dynamic Host Configuration Protocol (DHCP) snooping option-82 with data insertion feature is enabled, the switch can insert a client's 802.1X authenticated user identity information into the DHCP discovery process, allowing the DHCP server to assign IP addresses from different IP address pools to different classes of end users. This feature allows you to secure the IP addresses given to the end users for accounting purposes and to allow services based on Layer 3 criteria.

After a successful 802.1X authentication between a supplicant and the RADIUS server, the switch puts the port in the forwarding state and stores the attributes that it receives from the RADIUS server. While performing DHCP snooping, the switch acts as a DHCP relay agent, receiving DHCP messages and regenerating those messages for transmission on another interface. When a client, after 802.1X authentication, sends a DHCP discovery message, the switch receives the packet. The switch adds to the packet a RADIUS attributes suboption section containing the stored RADIUS attributes of the client. The switch then submits the discovery broadcast again. The DHCP server receives the modified DHCP discovery packet and can, if configured to do so, use the authenticated user identity information when creating the IP address lease. The mapping of user-to-IP address can be on a one-to-one, one-to-many, or many-to-many basis. The one-to-many mapping allows the same user to authenticate through the 802.1X hosts on multiple ports.

The switch will automatically insert the authenticated user identity information when 802.1X authentication and DHCP snooping option-82 with data insertion features are enabled. To configure DHCP snooping option-82 with data insertion, see the [“DHCP Snooping Option-82 Data Insertion” section on page 78-5](#).

For information about the data inserted in the RADIUS attributes suboption, see RFC 4014, “Remote Authentication Dial-In User Service (RADIUS) Attributes Suboption for the Dynamic Host Configuration Protocol (DHCP) Relay Agent Information Option.”

## 802.1X Accounting

The IEEE 802.1X standard defines how users are authorized and authenticated for network access but does not keep track of network usage. IEEE 802.1X accounting is disabled by default. You can enable 802.1X accounting to monitor the following activities on 802.1X-enabled ports:

- User successfully authenticates.
- User logs off.
- Link-down occurs.
- Reauthentication successfully occurs.
- Reauthentication fails.

The switch does not log IEEE 802.1X accounting information. Instead, it sends this information to the RADIUS server, which must be configured to log accounting messages.

The information sent to the RADIUS server is represented in the form of Attribute-Value (AV) pairs. These AV pairs provide data for different applications. (For example, a billing application might require information that is in the Acct-Input-Octets or the Acct-Output-Octets attributes of a RADIUS packet.)

AV pairs are automatically sent by a switch that is configured for 802.1X accounting. Three types of RADIUS accounting packets are sent by a switch:

- START—Sent when a new user session starts.
- INTERIM—Sent during an existing session for updates.
- STOP—Sent when a session terminates.



Table 83-1 lists the AV pairs and indicates when they are sent by the switch.

**Table 83-1 Accounting AV Pairs**

| Attribute Number | AV Pair Name                                                                     | START  | INTERIM                                                                                                                                 | STOP      |
|------------------|----------------------------------------------------------------------------------|--------|-----------------------------------------------------------------------------------------------------------------------------------------|-----------|
| Attribute[1]     | User-Name                                                                        | Always | Always                                                                                                                                  | Always    |
| Attribute[4]     | NAS-IP-Address                                                                   | Always | Always                                                                                                                                  | Always    |
| Attribute[5]     | NAS-Port                                                                         | Always | Always                                                                                                                                  | Always    |
| Attribute[8]     | Framed-IP-Address                                                                | Never  | Sometimes                                                                                                                               | Sometimes |
|                  |                                                                                  |        | <b>Note</b> The Framed-IP-Address AV pair is sent only if a valid DHCP binding exists for the host in the DHCP snooping bindings table. |           |
| Attribute[25]    | Class                                                                            | Always | Always                                                                                                                                  | Always    |
| Attribute[26]    | Vendor-Specific                                                                  | —      | —                                                                                                                                       | —         |
|                  | <b>Note</b> Vendor-specific attributes (VSAs) are used by other 802.1X features. |        |                                                                                                                                         |           |
| Attribute[30]    | Called-Station-ID                                                                | Always | Always                                                                                                                                  | Always    |
| Attribute[31]    | Calling-Station-ID                                                               | Always | Always                                                                                                                                  | Always    |
| Attribute[40]    | Acct-Status-Type                                                                 | Always | Always                                                                                                                                  | Always    |
| Attribute[41]    | Acct-Delay-Time                                                                  | Always | Always                                                                                                                                  | Always    |
| Attribute[42]    | Acct-Input-Octets                                                                | Never  | Never                                                                                                                                   | Always    |
| Attribute[43]    | Acct-Output-Octets                                                               | Never  | Never                                                                                                                                   | Always    |
| Attribute[44]    | Acct-Session-ID                                                                  | Always | Always                                                                                                                                  | Always    |
| Attribute[45]    | Acct-Authentic                                                                   | Always | Always                                                                                                                                  | Always    |
| Attribute[46]    | Acct-Session-Time                                                                | Never  | Never                                                                                                                                   | Always    |
| Attribute[49]    | Acct-Terminate-Cause                                                             | Never  | Never                                                                                                                                   | Always    |
| Attribute[61]    | NAS-Port-Type                                                                    | Always | Always                                                                                                                                  | Always    |

You can view the AV pairs that are being sent by the switch by entering the **debug radius accounting** privileged EXEC command. For more information about AV pairs, see RFC 3580, “IEEE 802.1X Remote Authentication Dial In User Service (RADIUS) Usage Guidelines.”

## 802.1X Authentication with VLAN Assignment

After successful 802.1X authentication of a port, the RADIUS server sends the VLAN assignment to configure the port. The RADIUS server database maintains the username-to-VLAN mappings, assigning the VLAN based on the username of the client connected to the port. You can use this feature to limit network access for certain users.

When configured on the switch and the RADIUS server, 802.1X authentication with VLAN assignment has these characteristics:

- If 802.1X authentication is enabled on a port, and if all information from the RADIUS server is valid, the port is placed in the RADIUS server-assigned VLAN after authentication.

- If the multiple-hosts mode is enabled on an 802.1X port, all hosts on the port are placed in the same RADIUS server-assigned VLAN as the first authenticated host.
- If the multiauth mode is enabled on an 802.1X port, the VLAN assignment will be ignored.
- If no VLAN number is supplied by the RADIUS server, the port is configured in its access VLAN after successful authentication. An access VLAN is a VLAN assigned to an access port. All packets sent from or received on this port belong to this VLAN.
- If 802.1X authentication is enabled but the VLAN information from the RADIUS server is not valid, the port returns to the unauthorized state and remains in the configured access VLAN. This prevents ports from appearing unexpectedly in an inappropriate VLAN because of a configuration error.  
Configuration errors could include specifying a VLAN for a routed port, a malformed VLAN ID, a nonexistent or internal (routed port) VLAN ID, or an attempted assignment to a voice VLAN ID.
- If 802.1X authentication is disabled on the port, the port is returned to the configured access VLAN.
- The Radius VLAN assignment is supported for both DATA clients and VOICE clients.

When the port is in the force-authorized, force-unauthorized, unauthorized, or shutdown state, the port is put into the configured access VLAN.

If an 802.1X port is authenticated and put in the RADIUS server-assigned VLAN, any change to the port access VLAN configuration does not take effect.

The 802.1X authentication with VLAN assignment feature is not supported on trunk ports, dynamic ports, or with dynamic-access port assignment through a VLAN Membership Policy Server (VMPS).

To configure VLAN assignment, perform this task:

- 
- |               |                                                                                                                                                                                                                                                                                                                  |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Enable AAA authorization by using the <b>network</b> keyword to allow interface configuration from the RADIUS server.                                                                                                                                                                                            |
| <b>Step 2</b> | Enable 802.1X authentication.                                                                                                                                                                                                                                                                                    |
| <b>Step 3</b> | The VLAN assignment feature is automatically enabled when you configure 802.1X authentication on an access port.                                                                                                                                                                                                 |
| <b>Step 4</b> | Assign vendor-specific tunnel attributes in the RADIUS server. The RADIUS server must return these attributes to the switch: <ul style="list-style-type: none"> <li>• [64] Tunnel-Type = VLAN</li> <li>• [65] Tunnel-Medium-Type = 802</li> <li>• [81] Tunnel-Private-Group-ID = VLAN name or VLAN ID</li> </ul> |
- 

Attribute [64] must contain the value *VLAN* (type 13). Attribute [65] must contain the value *802* (type 6). Attribute [81] specifies the *VLAN name* or *VLAN ID* assigned to the 802.1X-authenticated user.

---

## Multiple VLANs and VLAN User Distribution with VLAN Assignment

The RADIUS-supplied VLAN assignment can provide load balancing by distributing 802.1X-authenticated users among multiple VLANs.

In earlier releases, the RADIUS server can supply a single VLAN name or ID for the assignment of an authenticating user. The RADIUS server can supply multiple VLAN names and IDs or the name of a VLAN group that contains multiple VLANs. Use either of the following two methods to load balance the users between the different VLANs:

- Configure the RADIUS server to send more than one VLAN ID or VLAN name as part of the response to the authenticating user. The 802.1X VLAN user group feature tracks the users in a particular VLAN and achieves load balancing by placing newly authenticated users in the least populated VLAN of the RADIUS-supplied VLAN IDs.

Perform the steps shown in the [“802.1X Authentication with VLAN Assignment” section on page 83-17](#) with the following exception:

Attribute [81] Tunnel-Private-Group-ID specifies multiple VLAN names or VLAN IDs

- Define a VLAN group that contains multiple VLANs. Configure the RADIUS server to supply the VLAN group name instead of a VLAN ID as part of the response to the authenticating user. If the supplied VLAN group name is found among the VLAN group names that you have defined, the newly authenticated user is placed in the least populated VLAN within the VLAN group.

Perform the steps shown in the [“802.1X Authentication with VLAN Assignment” section on page 83-17](#) with the following exception:

Attribute [81] Tunnel-Private-Group-ID specifies a defined VLAN group name

For more information, see the [“Configuring VLAN User Distribution” section on page 83-44](#).

## 802.1X Authentication with Guest VLAN

You can configure a guest VLAN for each 802.1X port on the switch to provide limited services to non-802.1X-compliant clients, such as for downloading the 802.1X client software. These clients might be upgrading their system for 802.1X authentication, and some hosts, such as Windows 98 systems, might not be 802.1X-capable.

When you enable a guest VLAN on an 802.1X port, the switch assigns clients to a guest VLAN when the switch does not receive a response to its EAP request/identity frame or when EAPOL packets are not sent by the client and no fallback authentication methods are enabled.

In addition, the switch maintains the EAPOL packet history. If an EAPOL packet is detected on the interface during the lifetime of the link, the switch determines that the device connected to that interface is an 802.1X-capable supplicant, and the interface will not change to the guest VLAN state. The EAPOL packet history is cleared if the interface link status goes down.

Use the **dot1x guest-vlan supplicant** global configuration command to allow an interface to change to the guest VLAN state regardless of the EAPOL packet history. That is, a host that is not 802.1X-capable will be assigned to the guest VLAN even if a previous host on that interface was 802.1X-capable.



### Note

If an EAPOL packet is detected after the interface has changed to the guest VLAN, the interface reverts to an unauthorized state, and 802.1X authentication restarts.

Any number of 802.1X-incapable clients are allowed access when the port is moved to the guest VLAN. If an 802.1X-capable client joins the same port on which the guest VLAN is configured, the port is put into the unauthorized state in the user-configured access VLAN, and authentication is restarted.

When operating as an 802.1X guest VLAN, a port functions in multiple-hosts mode regardless of the configured host mode of the port.

You can configure any active VLAN except an RSPAN VLAN, a private primary PVLAN, or a voice VLAN as an 802.1X guest VLAN. The guest VLAN feature is not supported on internal VLANs (routed ports) or trunk ports; it is supported only on access ports.

The switch supports MAC authentication bypass. When MAC authentication bypass is enabled on an 802.1X port, the switch can authorize clients based on the client MAC address when 802.1X authentication times out while waiting for an EAPOL message exchange. After detecting a client on an 802.1X port, the switch waits for an Ethernet packet from the client. The switch sends the authentication server a RADIUS-access/request frame with a username and password based on the MAC address. If authorization succeeds, the switch grants the client access to the network. If authorization fails, the switch assigns the port to the guest VLAN if one is specified.

For more information, see the [“802.1X Authentication with MAC Authentication Bypass” section on page 83-26](#) and the [“Configuring a Guest VLAN” section on page 83-45](#).

## 802.1X Authentication with Restricted VLAN

You can configure a restricted VLAN (also referred to as an *authentication failed VLAN*) for each 802.1X port on a switch to provide limited services to clients that failed authentication and cannot access the guest VLAN. These clients are 802.1X-compliant and cannot access another VLAN because they fail the authentication process. A restricted VLAN allows users without valid credentials in an authentication server (typically, visitors to an enterprise) to access a limited set of services. The administrator can control the services available to the restricted VLAN.



### Note

You can configure a VLAN to be both the guest VLAN and the restricted VLAN if you want to provide the same services to both types of users.

Without this feature, the client attempts and fails authentication indefinitely, and the port remains in the spanning-tree blocking state. With this feature, you can configure the port to be in the restricted VLAN after a specified number of authentication attempts.

The authenticator counts the failed authentication attempts for the client. The failed attempt count increments when the RADIUS server replies with either an Access-Reject EAP failure or an empty response without an EAP packet. When this count exceeds the configured maximum number of authentication attempts, the port moves to the restricted VLAN, the failed attempt counter resets, and subsequent EAPOL-start messages from the failed client are ignored.

Users who fail authentication remain in the restricted VLAN until the next switch-initiated reauthentication attempt. A port in the restricted VLAN tries to reauthenticate at configured intervals (the default is 60 seconds). If reauthentication fails, the port remains in the restricted VLAN. If reauthentication is successful, the port moves either to the configured VLAN or to a VLAN sent by the RADIUS server. You can disable reauthentication. If you do this, the only way to restart the authentication process is for the port to receive a link down or EAP logoff event. We recommend that you keep reauthentication enabled if a client might connect through a hub. When a client disconnects from the hub, the port might not receive the link down or EAP logoff event.

When operating as an 802.1X restricted VLAN, a port functions in single-host mode regardless of the configured host mode of the port. Only the client that failed authentication is allowed access on the port. An exception is that a port configured in MDA mode can still authenticate a voice supplicant from the restricted VLAN.

You can configure any active VLAN except an RSPAN VLAN or a voice VLAN as an 802.1X restricted VLAN. The restricted VLAN feature is not supported on routed or trunk ports; it is supported only on access ports.

This feature works with port security. As soon as the port is authorized, a MAC address is provided to port security. If port security does not permit the MAC address or if the maximum secure address count is reached, the port becomes unauthorized and error disabled.

Other port security features such as dynamic ARP Inspection, DHCP snooping, and IP source guard can be configured independently on a restricted VLAN.

For more information, see the [“Configuring a Restricted VLAN” section on page 83-46](#).

## 802.1X Authentication with Inaccessible Authentication Bypass

When the switch cannot reach the configured RADIUS servers and hosts cannot be authenticated, you can configure the switch to allow network access to the hosts connected to critical ports. A critical port is enabled for the inaccessible authentication bypass feature, also referred to as critical authentication or the AAA fail policy.

When this feature is enabled, the switch checks the status of the configured RADIUS servers whenever the switch tries to authenticate a host connected to a critical port. If a server is available, the switch can authenticate the host. However, if all the RADIUS servers are unavailable, the switch grants network access to the host and puts the port in the critical-authentication state, which is a special case of the authentication state.

The behavior of the inaccessible authentication bypass feature depends on the authorization state of the port:

- If the port is unauthorized when a host connected to a critical port tries to authenticate and all servers are unavailable, the switch puts the port in the critical-authentication state in the user-specified critical VLAN.
- If the port is already authorized and reauthentication occurs, the switch puts the critical port in the critical-authentication state in the current VLAN, which might be the one previously assigned by the RADIUS server.
- If the RADIUS server becomes unavailable during an authentication exchange, the current exchanges times out, and the switch puts the critical port in the critical-authentication state during the next authentication attempt.

When a RADIUS server that can authenticate the host is available, all critical ports in the critical-authentication state are automatically reauthenticated.

Inaccessible authentication bypass interacts with these features:

- Guest VLAN—Inaccessible authentication bypass is compatible with guest VLAN. When a guest VLAN is enabled on 802.1x port, the features interact as follows:
  - If at least one RADIUS server is available, the switch assigns a client to a guest VLAN when the switch does not receive a response to its EAP request/identity frame or when EAPOL packets are not sent by the client.
  - If all the RADIUS servers are not available and the client is connected to a critical port, the switch authenticates the client and puts the critical port in the critical-authentication state in the user-specified critical VLAN.
  - If all the RADIUS servers are not available and the client is not connected to a critical port, the switch might not assign clients to the guest VLAN if one is configured.
  - If all the RADIUS servers are not available and if a client is connected to a critical port and was previously assigned to a guest VLAN, the switch keeps the port in the guest VLAN.

- **Restricted VLAN**—If the port is already authorized in a restricted VLAN and the RADIUS servers are unavailable, the switch puts the critical port in the critical-authentication state in the restricted VLAN.
- **802.1X accounting**—Accounting is not affected if the RADIUS servers are unavailable.
- **Private VLAN**—You can configure inaccessible authentication bypass on a private VLAN host port. The access VLAN must be a secondary private VLAN.
- **Voice VLAN**—Inaccessible authentication bypass is compatible with voice VLAN, but the RADIUS-configured or user-specified access VLAN and the voice VLAN must be different.
- **Remote Switched Port Analyzer (RSPAN)**—Do not configure an RSPAN VLAN as the RADIUS-configured or user-specified access VLAN for inaccessible authentication bypass.

## 802.1X Authentication with Voice VLAN Ports

A Multi-VLAN Access Port (MVAP) is a port that belongs to two VLANs. A voice VLAN port is an MVAP that allows separating a port's voice traffic and data traffic on different VLANs. A voice VLAN port is associated with two VLAN identifiers:

- **Voice VLAN identifier (VVID)** to carry voice traffic to and from the IP phone. The VVID is used to configure the IP phone connected to the port.
- **Port VLAN identifier (PVID)** to carry the data traffic to and from the workstation connected to the switch through the IP phone. The PVID is the native VLAN of the port.

The IP phone uses the VVID for its voice traffic, regardless of the authorization state of the port. This allows the phone to work independently of 802.1X authentication.

In single-host mode, only the IP phone is allowed on the voice VLAN. In multiple-hosts mode, additional clients can send traffic on the voice VLAN after a supplicant is authenticated on the PVID. When multiple-hosts mode is enabled, the supplicant authentication affects both the PVID and the VVID.

In order to recognize an IP phone, the switch will allow CDP traffic on a port regardless of the authorization state of the port. A voice VLAN port becomes active when there is a link, and the device MAC address appears after the first CDP message from the IP phone. Cisco IP phones do not relay CDP messages from other devices. As a result, if several IP phones are connected in series, the switch recognizes only the one directly connected to it. When 802.1X authentication is enabled on a voice VLAN port, the switch drops packets from unrecognized IP phones more than one hop away.

When 802.1X authentication is enabled on a port, you cannot configure a port VLAN that is equal to a voice VLAN.



### Note

If you enable 802.1X authentication on an access port on which a voice VLAN is configured and to which a Cisco IP phone is connected, the Cisco IP phone loses connectivity to the switch for up to 30 seconds.

For voice VLAN configuration information, see [Chapter 19, “Cisco IP Phone Support.”](#)

## 802.1X Authentication with Port Security

You can configure an 802.1X port with port security in either single-host or multiple-hosts mode. (You also must configure port security on the port by using the **switchport port-security** interface configuration command.) When you enable port security and 802.1X authentication on a port, 802.1X authentication authenticates the port, and port security manages network access for all MAC addresses, including that of the client. You can then limit the number or group of clients that can access the network through an 802.1X port.

These are some examples of the interaction between 802.1X authentication and port security on the switch:

- When a client is authenticated, and the port security table is not full, the client MAC address is added to the port security list of secure hosts. The port then proceeds to come up normally.

When a client is authenticated and manually configured for port security, it is guaranteed an entry in the secure host table.

A security violation occurs if the client is authenticated, but the port security table is full. This can happen if the maximum number of secure hosts has been statically configured or if the client ages out of the secure host table. If the client address is aged, its place in the secure host table can be taken by another host.

If a security violation is caused by any host, the port becomes error-disabled and immediately shuts down.

The port security violation modes determine the action for security violations. For more information, see the [“Configuring the Port Security Violation Mode on a Port” section on page 85-6](#).

- When you manually remove an 802.1X client address from the port security table by using the **no switchport port-security mac-address mac\_address** interface configuration command, you should reauthenticate the 802.1X client by using the **dot1x re-authenticate interface type slot/port** privileged EXEC command.
- When an 802.1X client logs off, the port changes to an unauthenticated state, and all dynamic entries in the secure host table are cleared, including the entry for the client. Normal authentication then takes place.
- If the port is administratively shut down, the port becomes unauthenticated, and all dynamic entries are removed from the secure host table.
- Port security and a voice VLAN can be configured simultaneously on an 802.1X port that is in either single-host or multiple-hosts mode. Port security applies to both the voice VLAN identifier (VVID) and the port VLAN identifier (PVID).

For more information about enabling port security on your switch, see the [“How to Configure Port Security” section on page 85-4](#).

## 802.1X Authentication with ACL Assignments and Redirect URLs

- [Overview, page 83-24](#)
- [Downloadable ACLs Using the Cisco Secure ACS, page 83-24](#)
- [Filter-ID ACLs, page 83-25](#)
- [Redirect URLs, page 83-25](#)
- [Static Sharing of ACLs, page 83-25](#)

## Overview

Per-host policies such as ACLs and redirect URLs can be downloaded to the switch from the authentication server (AS) in a RADIUS Access-Accept packet at the end of an 802.1X, MAB, or web-based authentication exchange.

Per-host policies are activated during authentication as follows:

- Downloadable ACLs (DACLS) are defined in the Cisco Secure ACS and downloaded from the ACS to the switch using VSAs.
- Filter-ID ACLs are defined on the switch, and only the ACL name is downloaded from the AS to the switch using the RADIUS Filter-ID attribute.
- A redirection URL and an ACL name are downloaded from the ACS to the switch using VSAs. The redirection ACL is defined on the switch.

For information about configuring per-host policies, see the [“Configuring the Switch for DACLS or Redirect URLs” section on page 83-51](#).

## Downloadable ACLs Using the Cisco Secure ACS

Following a successful host authentication, the Cisco Secure ACS can use a VSA to download an ACL to the switch. The switch combines the DACL with the default ACL on the port to which the host has connected. Because the DACL definition resides on the authentication server, this feature allows for centralized policy management.

Two methods are provided in the Cisco Secure ACS for configuring DACLS:

- Downloadable IP ACL  
Downloading of the DACL is enabled by selecting Assign IP ACL in the ACS configuration, and the DACL is defined in the Downloadable IP ACL Content menu of the ACS. There is no restriction on the size of the DACL.
- Per-user ACL

The ACS can use the CiscoSecure-Defined-ACL [009\001 cisco-av-pair] VSAs to deliver the DACL. Because the entire DACL is delivered in a single RADIUS packet, the maximum size is limited by the 4096-byte maximum size for a RADIUS packet. The DACL must be defined on the ACS using the following format:

*protocol:inacl#sequence\_number=ace*

as shown in this example:

```
kr<kpcen%32?rgtokv"kr"cp{"89040402"202020477"
```

These guidelines apply when using DACLS:

- The source address for all ACEs must be defined as ANY.
- When the 802.1X host mode of the port is MDA or multiauth, the DACL will be modified to use the authenticated host's IP address as the source address. When the host mode is either single-host or multiple-host, the source address will be configured as ANY, and the downloaded ACLs or redirects will apply to all devices on the port.
- If no DACLS are provided during the authentication of a host, the static default ACL configured on the port will be applied to the host. On a voice VLAN port, only the static default ACL of the port will be applied to the phone.



## Filter-ID ACLs

Following a successful host authentication, the authentication server can use the RADIUS Filter-ID attribute (Attribute[11]) rather than a VSA to deliver only the name of an extended ACL to the switch in the following format:

*acl\_name.in*

The suffix “.in” indicates that the ACL should be applied in the inbound direction.

In this method, the ACL must be already defined on the switch. The switch matches the Filter-ID attribute value to a locally configured ACL that has the same name or number as the Filter-ID (for example, Filter-ID=101.in will match the extended numbered ACL 101, and Filter-ID= guest.in will match the extended named ACL “guest”). The specified ACL is then applied to the port. Because the ACL definition resides on the switch, this feature allows for local variation in a policy.

These guidelines apply when using Filter-ID ACLs:

- The guidelines for using DACLs also apply to Filter-ID ACLs.
- The Filter-ID attribute may be a number (100 to 199, or 2000 to 2699) or a name.

## Redirect URLs

Following a successful host authentication, the Cisco Secure ACS can use a VSA to download information to the switch for intercepting and redirecting HTTP or HTTPS requests from the authenticated host. The ACS downloads a redirection ACL and URL. When an HTTP or HTTPS request from the host matches the downloaded ACL, the host’s web browser is redirected to the downloaded redirection URL.

The ACS uses these cisco-av-pair VSAs to configure the redirection:

- url-redirect-acl

This AV pair contains the name or number of an ACL that specifies the HTTP or HTTPS traffic to be redirected. The ACL must be defined on the switch, and the source address must be defined as ANY. Traffic that matches a permit entry in the redirect ACL will be redirected.

- url-redirect

This AV pair contains the HTTP or HTTPS URL to which the web browser will be redirected.

## Static Sharing of ACLs

When a number of interfaces have the same PACL and VLAN-based features, the static sharing feature stores one copy of the PACL and inherited VLAN-based feature ACLs in the TCAM for all ports that use the same ACL set, freeing TCAM space for more ACLs. The switch automatically evaluates all configured or enabled interfaces for static sharing when any of these events occur:

- When an interface is configured.
- When a state change occurs on an interface.

Consider the following guidelines and restrictions:

- Static sharing is not supported for interfaces configured to support IPv6.
- Static sharing is supported only on switch ports in access mode with NAC or 802.1X DACL features configured.
- Static sharing is not supported on switch ports enabled with QoS, with the exception of VLAN-based QoS.

- When 802.1X is used with DACL, we recommend entering the **platform hardware acl dynamic setup static** command to avoid triggering a static sharing evaluation when the port is dynamically configured by the authentication server response. The static sharing evaluation may adversely affect the port/host linkup time.
- 802.1X interfaces with fallback authentication as active cannot form a static sharing group with interfaces on which fallback is not enabled or is not active.

## 802.1X Authentication with Port Descriptors

You can associate descriptive text with an 802.1X client's authentication information by configuring the Cisco vendor-specific attribute (VSA) **aaa:supplicant-name** on the RADIUS server. During a successful 802.1X authentication of the client on the port, the switch will receive the descriptive information from the RADIUS server as part of the Access-Accept packet and will display the information when the **show interface users** command is entered for the port. If the port is in a mode supporting multiple authenticated hosts, identity information for all the authenticated hosts will be displayed with the port description.

## 802.1X Authentication with MAC Authentication Bypass

You can configure the switch to authorize clients based on the client MAC address (see [Figure 83-4 on page 83-12](#)) by using the MAC authentication bypass feature. For example, you can enable this feature on 802.1X ports connected to devices such as printers.

If 802.1X authentication times out while waiting for an EAPOL response from the client, the switch tries to authorize the client by using MAC authentication bypass.

When the MAC authentication bypass feature is enabled on an 802.1X port, the switch uses the MAC address as the client identity. The authentication server has a database of client MAC addresses that are allowed network access. After detecting a client on an 802.1X port, the switch waits for an Ethernet packet from the client. The switch sends the authentication server a RADIUS-access/request frame with a username and password based on the MAC address. If authorization succeeds, the switch grants the client access to the network. If authorization fails, the switch assigns the port to the guest VLAN if one is configured.

If an EAPOL packet is detected on the interface during the lifetime of the link, the switch determines that the device connected to that interface is an 802.1X-capable supplicant and uses 802.1X authentication (not MAC authentication bypass) to authorize the interface. EAPOL history is cleared if the interface link status goes down.

If the switch already authorized a port by using MAC authentication bypass and detects an 802.1X supplicant, the switch does not unauthorize the client connected to the port. When reauthentication occurs, the switch uses 802.1X authentication as the preferred reauthentication process if the previous session ended because the Termination-Action RADIUS attribute value is DEFAULT.

Clients that were authorized with MAC authentication bypass can be reauthenticated. The reauthentication process is the same as that for clients that were authenticated with 802.1X. During reauthentication, the port remains in the previously assigned VLAN. If reauthentication is successful, the switch keeps the port in the same VLAN. If reauthentication fails, the switch assigns the port to the guest VLAN, if one is configured.

If reauthentication is based on the Session-Timeout RADIUS attribute (Attribute[27]) and the Termination-Action RADIUS attribute (Attribute [29]) and if the Termination-Action RADIUS attribute (Attribute [29]) action is Initialize, (the attribute value is DEFAULT), the MAC authentication bypass session ends, and connectivity is lost during reauthentication. If MAC authentication bypass is enabled

and the 802.1X authentication times out, the switch uses the MAC authentication bypass feature to initiate reauthorization. For more information about these AV pairs, see RFC 3580, “IEEE 802.1X Remote Authentication Dial In User Service (RADIUS) Usage Guidelines.”

MAC authentication bypass interacts with the features:

- 802.1X authentication—You can enable MAC authentication bypass only if 802.1X authentication is enabled on the port.
- Guest VLAN—If a client has an invalid MAC address identity, the switch assigns the client to a guest VLAN if one is configured.
- Restricted VLAN—This feature is not supported when the client connected to an 802.1x port is authenticated with MAC authentication bypass.
- Port security—See the “[802.1X Authentication with Port Security](#)” section on page 83-23.
- Voice VLAN—See the “[802.1X Authentication with Voice VLAN Ports](#)” section on page 83-22.
- VLAN Membership Policy Server (VMPS)—802.1X and VMPS are mutually exclusive.
- Private VLAN—You can assign a client to a private VLAN.
- Network admission control (NAC) Layer 2 IP validation—This feature takes effect after an 802.1X port is authenticated with MAC authentication bypass, including hosts in the exception list.

## Network Admission Control Layer 2 IEEE 802.1X Validation

Network Admission Control (NAC) Layer 2 IEEE 802.1X validation checks the antivirus condition or *posture* of endpoint systems or clients before granting the devices network access. NAC Layer 2 IEEE 802.1X validation performs policy enforcement by assigning the authenticated port into a specified VLAN, which provides segmentation and quarantine of poorly postured hosts at Layer 2.

Configuring NAC Layer 2 IEEE 802.1X validation is similar to configuring 802.1X port-based authentication except that you must configure a posture token on the RADIUS server. You can view the NAC posture token, which shows the posture of the client, by using the **show dot1x** privileged EXEC command. For information about configuring NAC Layer 2 IEEE 802.1X validation, see the “[Configuring NAC Layer 2 IEEE 802.1X Validation](#)” section on page 83-50.

For more information about NAC, see the *Network Admission Control Software Configuration Guide*.

## NAC Agentless Audit Support

MAB support is added for the Cisco NAC Audit Architecture, which uses an external audit server to check the antivirus posture of clients that do not run a Cisco Trust Agent (CTA) and cannot respond to NAC queries. To audit and report an agentless client’s antivirus posture, the NAC audit server must possess the client’s IP address and a unique session identifier for the client’s connection to the switch. To support the NAC audit architecture for agentless clients, the switch must snoop the client’s IP address, create and assign a unique session identifier for the agentless client, and pass this information to the RADIUS server for sharing with the NAC audit server.

Because MAB operates at Layer 2, the MAB authenticator does not normally know the IP address of the supplicant, and the supplicant might not have an IP address when it first contacts the authenticator. A supplicant that requires a DHCP-assigned IP address must be allowed access to a DHCP server before authentication. You must enable ARP and DHCP snooping on the switch to allow the MAB authenticator to learn the IP address of the supplicant. To allow the IP address and unique session identifier information to be shared with the NAC audit server, you must enable the sending of certain RADIUS attributes. See the “[Configuring NAC Agentless Audit Support](#)” section on page 83-51.

The client IP address and unique session identifier are shared in RADIUS Access-Requests and Access-Accepts using the following RADIUS *cisco-av-pair* vendor-specific attributes (VSAs):

- Cisco-AVPair="identity-request=*ip-address*"  
*ip-address* is the client IP address obtained by the switch through ARP or DHCP snooping.
- Cisco-AVPair="audit-session-id=*audit session id string*"  
*audit session id string* is a UTF-8 encoding of a unique 96-bit identifier derived by the switch from the network access server (NAS) IP address, a session count, and the session start timestamp.

## 802.1X Authentication with Wake-on-LAN

The 802.1X authentication with wake-on-LAN (WoL) feature allows dormant PCs to be powered up when the switch receives a specific Ethernet frame, known as the *magic packet*. You can use this feature in environments where administrators need to connect to systems that have been powered down.

When a host that uses WoL is attached through an 802.1X port and the host powers off, the 802.1X port becomes unauthorized. The port can only receive and send EAPOL packets, and WoL magic packets cannot reach the host. When the PC is powered off, it is not authorized, and the switch port is not opened.

When the switch uses 802.1X authentication with WoL, the switch forwards traffic to unauthorized 802.1X ports, including magic packets. While the port is unauthorized, the switch continues to block ingress traffic other than EAPOL packets. The host can receive packets but cannot send packets to other devices in the network.



### Note

If PortFast is not enabled on the port, the port is forced to the bidirectional state.

When you configure a port as unidirectional by using the **authentication control-direction in** interface configuration command, the port changes to the spanning-tree forwarding state. The port can send packets to the host but cannot receive packets from the host.

When you configure a port as bidirectional by using the **authentication control-direction both** interface configuration command, the port is access-controlled in both directions. The port does not receive packets from or send packets to the host.

## MAC Move

When a MAC address is authenticated on one switch port, that address is not allowed on another authentication manager-enabled port of the switch. If the switch detects that same MAC address on another authentication manager-enabled port, the address is not allowed.

There are situations where a MAC address might need to move from one port to another on the same switch. For example, when there is another device (for example a hub or an IP phone) between an authenticated host and a switch port, you might want to disconnect the host from the device and connect it directly to another port on the same switch.

You can globally enable MAC move so the device is reauthenticated on the new port. When a host moves to a second port, the session on the first port is deleted, and the host is reauthenticated on the new port.

When a MAC address moves from one port to another, the switch terminates the authenticated session on the original port and initiates a new authentication sequence on the new port. Port security behavior remains the same when you configure MAC move.

**Note**

- MAC move is supported in all host modes. (The authenticated host can move to any port on the switch, no matter which host mode is enabled on the port.)
- MAC move is supported with port security.
- The MAC move feature applies to both voice and data hosts.
- In open authentication mode, a MAC address is immediately moved from the original port to the new port, with no requirement for authorization on the new port.

For more information see the [“Enabling MAC Move” section on page 83-53](#).

## MAC Replace

The MAC replace feature can be configured to address the violation that occurs when a host attempts to connect to a port where another host was previously authenticated.

**Note**

- The Mac replace feature is not supported on ports in multiauth mode, because violations are not triggered in that mode.
- The Mac replace feature is not supported on ports in multiple host mode, because in that mode, only the first host requires authentication.

If you configure the **authentication violation** interface configuration command with the **replace** keyword, the authentication process on a port in multi-domain mode is:

- A new MAC address is received on a port with an existing authenticated MAC address.
- The authentication manager replaces the MAC address of the current data host on the port with the new MAC address.
- The authentication manager initiates the authentication process for the new MAC address.
- If the authentication manager determines that the new host is a voice host, the original voice host is removed.

If a port is in open authentication mode, any new MAC address is immediately added to the MAC address table.

For more information see the [“Enabling MAC Replace” section on page 83-53](#).

# 802.1x Supplicant and Authenticator Switches with Network Edge Access Topology (NEAT)

NEAT extends identity to areas outside the wiring closet (such as conference rooms). This allows any type of device to authenticate on the port.

- 802.1x switch supplicant: You can configure a switch to act as a supplicant to another switch by using the 802.1x supplicant feature. This configuration is helpful in a scenario, where, for example, a switch is outside a wiring closet and is connected to an upstream switch through a trunk port. A switch configured with the 802.1x switch supplicant feature authenticates with the upstream switch for secure connectivity.

Once the supplicant switch authenticates successfully the port mode changes from access to trunk.


- If the access VLAN is configured on the authenticator switch, it becomes the native VLAN for the trunk port after successful authentication.

You can enable MDA or multiauth mode on the authenticator switch interface that connects to one more supplicant switches. On the authenticator switch interface, multihost mode is not supported and in MDA mode voice client is not supported.

Use the **dot1x supplicant force-multicast** global configuration command on the supplicant switch for Network Edge Access Topology (NEAT) to work in all host modes.

- Host Authorization: Ensures that only traffic from authorized hosts (connecting to the switch with supplicant) is allowed on the network. The switches use Client Information Signalling Protocol (CISP) to send the MAC addresses connecting to the supplicant switch to the authenticator switch, as shown in Figure 83-7.
- Auto enablement: Automatically enables trunk configuration on the authenticator switch, allowing user traffic from multiple VLANs coming from supplicant switches. Configure the cisco-av-pair as *device-traffic-class=switch* at the ACS. (You can configure this under the *group* or the *user* settings.)

Figure 83-7 Authenticator and Supplicant Switch using CISP



|   |                        |   |                                           |
|---|------------------------|---|-------------------------------------------|
| 1 | Workstations (clients) | 2 | Supplicant switch (outside wiring closet) |
| 3 | Authenticator switch   | 4 | Access control server (ACS)               |
| 5 | Trunk port             |   |                                           |

For more information, see the “Configuring NEAT Authenticator and Supplicant Switches” section on page 83-54.

## Default Settings for 802.1X Port-Based Authentication

| Feature                                                                                                                  | Default Setting                                                                                                                                                                        |
|--------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Switch 802.1X enable state                                                                                               | Disabled.                                                                                                                                                                              |
| Per-port 802.1X enable state                                                                                             | Disabled (force-authorized).<br>The port sends and receives normal traffic without 802.1X-based authentication of the client.                                                          |
| AAA                                                                                                                      | Disabled.                                                                                                                                                                              |
| RADIUS server <ul style="list-style-type: none"> <li>IP address</li> <li>UDP authentication port</li> <li>Key</li> </ul> | <ul style="list-style-type: none"> <li>None specified.</li> <li>1812.</li> <li>None specified.</li> </ul>                                                                              |
| Host mode                                                                                                                | Single-host mode.                                                                                                                                                                      |
| Control direction                                                                                                        | Bidirectional control.                                                                                                                                                                 |
| Periodic reauthentication                                                                                                | Disabled.                                                                                                                                                                              |
| Number of seconds between reauthentication attempts                                                                      | 3600 seconds.                                                                                                                                                                          |
| Reauthentication number                                                                                                  | 2 times (number of times that the switch restarts the authentication process before the port changes to the unauthorized state).                                                       |
| Quiet period                                                                                                             | 60 seconds (number of seconds that the switch remains in the quiet state following a failed authentication exchange with the client).                                                  |
| Retransmission time                                                                                                      | 30 seconds (number of seconds that the switch should wait for a response to an EAP request/identity frame from the client before retransmitting the request).                          |
| Maximum retransmission number                                                                                            | 2 times (number of times that the switch will send an EAP-request/identity frame before restarting the authentication process).                                                        |
| Client timeout period                                                                                                    | 30 seconds (when relaying a request from the authentication server to the client, the amount of time the switch waits for a response before retransmitting the request to the client). |
| Authentication server timeout period                                                                                     | 30 seconds (when relaying a response from the client to the authentication server, the amount of time the switch waits for a reply before retransmitting the response to the server).  |
| Inactivity timeout                                                                                                       | Disabled.                                                                                                                                                                              |
| Guest VLAN                                                                                                               | None specified.                                                                                                                                                                        |
| Inaccessible authentication bypass                                                                                       | Disabled.                                                                                                                                                                              |
| Restricted VLAN                                                                                                          | None specified.                                                                                                                                                                        |

| Feature                     | Default Setting                                                                                                                                                                              |
|-----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Authenticator (switch) mode | None specified.                                                                                                                                                                              |
| MAC authentication bypass   | Disabled.<br><br><b>Note</b> When MAC authentication bypass with EAP has been enabled on an interface, it is not disabled by a subsequent <b>default interface</b> command on the interface. |

## How to Configure 802.1X Port-Based Authentication

- [Enabling 802.1X Authentication, page 83-33](#)
- [Configuring Switch-to-RADIUS-Server Communication, page 83-34](#)
- [Configuring 802.1X Authenticator Host Mode, page 83-35](#)
- [Enabling Fallback Authentication, page 83-36](#)
- [Enabling Periodic Reauthentication, page 83-38](#)
- [Manually Reauthenticating the Client Connected to a Port, page 83-39](#)
- [Initializing Authentication for the Client Connected to a Port, page 83-39](#)
- [Removing 802.1X Client Information Globally, page 83-40](#)
- [Removing 802.1X Client Information from an Interface, page 83-40](#)
- [Clearing Authentication Sessions, page 83-40](#)
- [Changing 802.1X Timeouts, page 83-40](#)
- [Setting the Switch-to-Client Frame Retransmission Number, page 83-42](#)
- [Setting the Reauthentication Number, page 83-43](#)
- [Configuring IEEE 802.1X Accounting, page 83-43](#)
- [Configuring VLAN User Distribution, page 83-44](#)
- [Configuring a Guest VLAN, page 83-45](#)
- [Configuring a Restricted VLAN, page 83-46](#)
- [Configuring the Inaccessible Authentication Bypass Feature, page 83-47](#)
- [Configuring MAC Authentication Bypass, page 83-49](#)
- [Configuring NAC Layer 2 IEEE 802.1X Validation, page 83-50](#)
- [Configuring NAC Agentless Audit Support, page 83-51](#)
- [Configuring the Switch for DACLs or Redirect URLs, page 83-51](#)
- [Configuring 802.1X Authentication with WoL, page 83-52](#)
- [Enabling MAC Move, page 83-53](#)
- [Enabling MAC Replace, page 83-53](#)
- [Configuring NEAT Authenticator and Supplicant Switches, page 83-54](#)
- [Disabling 802.1X Authentication on the Port, page 83-56](#)
- [Resetting the 802.1X Configuration to the Default Values, page 83-57](#)



## Enabling 802.1X Authentication

To enable 802.1X port-based authentication, you must enable AAA and specify the authentication method list.

A method list describes the sequence and authentication methods to be queried to authenticate a user. The software uses the first method listed to authenticate users; if that method fails to respond, the software selects the next authentication method in the method list. This process continues until there is successful communication with a listed authentication method or until all defined methods are exhausted. If authentication fails at any point in this cycle, the authentication process stops, and no other authentication methods are attempted.

To allow VLAN assignment, you must enable AAA authorization to configure the switch for all network-related service requests.

The 802.1X AAA process is as follows:

1. A user connects to a port on the switch.
2. Authentication is performed.
3. VLAN assignment is enabled, as appropriate, based on the RADIUS server configuration.
4. The switch sends a start message to an accounting server.
5. Reauthentication is performed, as necessary.
6. The switch sends an interim accounting update to the accounting server that is based on the result of reauthentication.
7. The user disconnects from the port.
8. The switch sends a stop message to the accounting server.

To configure 802.1X port-based authentication, perform this task:

|        | Command                                                                                    | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|--------|--------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "ccc"pgy/oqfgn"</code>                                               | Enables AAA.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Step 2 | <code>Tqwvgt*eqphki+% "ccc"cwvjgppvkecvkqp"fqv3z"<br/>}fghcwnv;"method1]method2..._</code> | Creates an 802.1X port-based authentication method list.<br><br>To create a default list that is used when a named list is <i>not</i> specified in the <b>aaa authentication</b> command, use the <b>default</b> keyword followed by the method that is to be used in default situations. The default method list is automatically applied to all ports.<br><br>For <i>method1</i> , enter the <b>group radius</b> keywords to use the list of all RADIUS servers for authentication.<br><br>Though other keywords are visible in the command-line help string, only the <b>group radius</b> keywords are supported. |
| Step 3 | <code>Tqwvgt*eqphki+% "fqv3z"u{uvgo/cwvj/eqpvtqn"</code>                                   | Globally enables 802.1X port-based authentication.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Step 4 | <code>Tqwvgt*eqphki+% "ccc"cwvjqtk cvkqp"pgvyqtm"<br/>}fghcwnv;"itqwr"tcfkwu</code>        | (Optional) Configures the switch to use user-RADIUS authorization for all network-related service requests such as VLAN assignment.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Step 5 | <code>Tqwvgt*eqphki+% "tcfkwu/ugtxgt"jqv"ip-address</code>                                 | Specifies the IP address of the RADIUS server.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

|         | Command                                                             | Purpose                                                                                                                                       |
|---------|---------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| Step 6  | <code>Tqwvgt*eqphki+% "tcfkwu/ugtxgt"mg{ "string</code>             | Specifies the authentication and encryption key used between the switch and the RADIUS daemon running on the RADIUS server.                   |
| Step 7  | <code>Tqwvgt*eqphki+% "kpvgtthceg" type slot/port"</code>           | Enters interface configuration mode and specifies the interface to be enabled for 802.1X authentication.                                      |
| Step 8  | <code>Tqwvgt*eqphki/kh+% "uykvejrgtv"oqfg"ceeguu</code>             | Sets the port to access mode only if you configured the RADIUS server in previous steps.                                                      |
| Step 9  | <code>Tqwvgt*eqphki/kh+% "cwvjgppvkecvkqp"rgtv/eqpvtqn"cwvq"</code> | Enables port-based authentication on the interface.<br>The <b>no</b> form of the command disables port-based authentication on the interface. |
| Step 10 | <code>Tqwvgt*eqphki/kh+% "fqv3z"rcg"cwvjgppvkecvqt"</code>          | Enables 802.1X authentication on the interface.                                                                                               |
| Step 11 | <code>Tqwvgt*eqphki+% "gpf"</code>                                  | Returns to privileged EXEC mode.                                                                                                              |

This example shows how to enable AAA and 802.1X on Gigabit Ethernet port 5/1:

```
Tqwvgt*eqphki+% "ccc"pgy/oqfgn
Tqwvgt*eqphki+% "ccc"cwvjgppvkecvkqp"fqv3z"fghcwnv"itqwr"tcfkwu
Tqwvgt*eqphki+% "fqv3z"u{uvgo/cwvj/eqpvtqn"
Tqwvgt*eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv"713
Tqwvgt*eqphki/kh+% "cwvjgppvkecvkqp"rgtv/eqpvtqn"cwvq
Tqwvgt*eqphki/kh+% "fqv3z"rcg"cwvjgppvkecvqt"
Tqwvgt*eqphki/kh+% "gpf"
```

This example shows how to verify the configuration:

```
Tqwvgt%"ujqy"fqv3z"cnn

U{ucwvjepvtqn"Gpcdngf
Fqv3z"Rtqvqeqn"Xgtukqp"4

Fqv3z"Kphq"hqt"Ikicdkvgvjgtpgv319
////////////////////////////////////
RCG"?"CWVJGPPVKECVQT
RgtvEqpvtqn"?"CWVQ
EqpvtqnFktgevkqp"?"Dqvj"
JquvOqfg"?"UKPINGaJQUV
SwkgvRgtkqf"?"82
UgtxgtVkogqvw"?"52
UwrrVkogqvw"?"52
TgCwvjOcz"?"4
OczTgs"?"4
VzRgtkqf"?"52
```

## Configuring Switch-to-RADIUS-Server Communication

RADIUS security servers are identified by any of the following:

- Host name
- Host IP address
- Host name and specific UDP port numbers
- IP address and specific UDP port numbers

The combination of the IP address and UDP port number creates a unique identifier, which enables RADIUS requests to be sent to multiple UDP ports on a server at the same IP address. If two different host entries on the same RADIUS server are configured for the same service (for example, authentication) the second host entry configured acts as the failover backup to the first one. The RADIUS host entries are tried in the order that they were configured.

To configure the RADIUS server parameters, perform this task:

|        | Command                                                                  | Purpose                                                                                                                                      |
|--------|--------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "kr"tcfkwu"uqwtg/kpvgthceg"kpvgthcegapcog"</code>  | Specifies that the RADIUS packets have the IP address of the indicated interface.                                                            |
| Step 2 | <code>Tqvwgt*eqphki+% "tcfkwu/ugtxgt"jquv"}jquvpcog"~"kracfftguu;</code> | Configures the RADIUS server host name or IP address on the switch.<br><br>If you want to use multiple RADIUS servers, reenter this command. |
| Step 3 | <code>Tqvwgt*eqphki+% "tcfkwu/ugtxgt"mg{ "string</code>                  | Configures the authorization and encryption key used between the switch and the RADIUS daemon running on the RADIUS server.                  |

- For *hostname* or *ip\_address*, specify the host name or IP address of the remote RADIUS server.
- Specify the **key string** on a separate command line.
- For **key string**, specify the authentication and encryption key used between the switch and the RADIUS daemon running on the RADIUS server. The key is a text string that must match the encryption key used on the RADIUS server.
- When you specify the **key string**, spaces within and at the end of the key are used. If you use spaces in the key, do not enclose the key in quotation marks unless the quotation marks are part of the key. This key must match the encryption used on the RADIUS daemon.
- You can globally configure the timeout, retransmission, and encryption key values for all RADIUS servers by using the **radius-server host** global configuration command. If you want to configure these options on a per-server basis, use the **radius-server timeout**, **radius-server retransmit**, and the **radius-server key** global configuration commands.



#### Note

You also need to configure some settings on the RADIUS server. These settings include the IP address of the switch and the key string to be shared by both the server and the switch. For more information, see the RADIUS server documentation.

This example shows how to configure the RADIUS server parameters on the switch:

```
Tqvwgt*eqphki+% "kr"tcfkwu"uqwtg/kpvgthceg"Xncp:2
Tqvwgt*eqphki+% "tcfkwu/ugtxgt"jquv"3940n4205;068
Tqvwgt*eqphki+% "tcfkwu/ugtxgt"mg{ "tcf345
```

## Configuring 802.1X Authenticator Host Mode

An 802.1X-enabled port can grant access to a single client or multiple clients as described in the [“802.1X Host Modes” section on page 83-13](#).

To configure the host mode of an 802.1X-authorized port, perform this task:

|        | Command                                                               | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------|-----------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "kpvgthceg type slot/port"</code>               | Specifies the port to be configured, and enters interface configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Step 2 | <code>Tqvwgt*eqphki/kh+% "cwvjgpvkecvkqp" rqtv/eqpvtqn "cwvq"</code>  | Enables port-based authentication on the interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Step 3 | <code>Tqvwgt*eqphki/kh+% "fqv3z" rcg "cwvjgpvkecvqt"</code>           | Enables 802.1X authentication on the interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Step 4 | <code>Tqvwgt*eqphki/kh+% "cwvjgpvkecvkqp" jquv/oqfg "jquvaofg"</code> | Configures the host mode. The values for <i>host_mode</i> are: <ul style="list-style-type: none"> <li>• <b>single-host</b>—Allows a single authenticated host (client) on an authorized port.</li> <li>• <b>multi-host</b>—Allows multiple clients on an authorized port when one client is authenticated.</li> <li>• <b>multi-domain</b>—Allows a single IP phone and a single data client to independently authenticate on an authorized port.</li> <li>• <b>multi-auth</b>—Allows a single IP phone and multiple data clients to independently authenticate on an authorized port.</li> </ul> |
| Step 5 | <code>Tqvwgt*eqphki/kh+% "cwvjgpvkecvkqp" qrgp</code>                 | (Optional) Enables pre-authentication open access.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Step 6 | <code>Tqvwgt*eqphki/kh+% "gpf"</code>                                 | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

This example shows how to enable 802.1X on Gigabit Ethernet interface 5/1 and to allow multiple hosts:

```
Tqvwgt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv "713
Tqvwgt*eqphki/kh+% "cwvjgpvkecvkqp" rqtv/eqpvtqn "cwvq
Tqvwgt*eqphki/kh+% "fqv3z" rcg "cwvjgpvkecvqt"
Tqvwgt*eqphki/kh+% "cwvjgpvkecvkqp" jquv/oqfg "ownvk/jquv
```

## Enabling Fallback Authentication

On a port in multiauth mode, either or both of MAB and web-based authentication can be configured as fallback authentication methods for non-802.1X hosts (those that do not respond to EAPOL). You can configure the order and priority of the authentication methods.

For detailed configuration information for MAB, see the [“Configuring MAC Authentication Bypass” section on page 83-49](#).

For detailed configuration information for web-based authentication, see [Chapter 84, “Web-Based Authentication.”](#)

To enable fallback authentication, perform this task:

|        | Command                                                                     | Purpose                                                         |
|--------|-----------------------------------------------------------------------------|-----------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "kr" cfokuukqp "pcog" rule-name "rtqz{ " jvvr"</code> | Configures an authentication rule for web-based authentication. |
| Step 2 | <code>Tqvwgt*eqphki+% "hcnnndcem" rtqhkng "profile-name"</code>             | Creates a fallback profile for web-based authentication.        |

|         | Command                                                                                             | Purpose                                                                                                                                                                                                                                                                                                                                                                                            |
|---------|-----------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 3  | <code>Tqvwgt*eqphki/hcnndcem/rtqhkng+%<b>"kr"</b>ceeguu/itqwr"<br/>rule-name kp</code>              | Specifies the default ACL to apply to network traffic before web-based authentication.                                                                                                                                                                                                                                                                                                             |
| Step 4  | <code>Tqvwgt*eqphki/hcnndcem/rtqhkng+%<b>"kr"</b>cfokuukqp"<br/>pcog"rule-name</code>               | Associates an IP admission rule with the profile, and specifies that a client connecting by web-based authentication uses this rule.                                                                                                                                                                                                                                                               |
| Step 5  | <code>Tqvwgt*eqphki/hcnndcem/rtqhkng+%<b>"gzkv"</b></code>                                          | Returns to global configuration mode.                                                                                                                                                                                                                                                                                                                                                              |
| Step 6  | <code>Tqvwgt*eqphki+%<b>"kpvgtthceg</b> type slot/port"</code>                                      | Specifies the port to be configured, and enters interface configuration mode.                                                                                                                                                                                                                                                                                                                      |
| Step 7  | <code>Tqvwgt*eqphki/kh+%<b>"cwvjgpvkecvkqp"</b>rqtv/eqpvtqn"<br/>cwvq</code>                        | Enables authentication on the port.                                                                                                                                                                                                                                                                                                                                                                |
| Step 8  | <code>Tqvwgt*eqphki/kh+%<b>"cwvjgpvkecvkqp"</b>qtfgt"method1"<br/>]method2_" ]method3_</code>       | (Optional) Specifies the fallback order of authentication methods to be used. The three values of <i>method</i> , in the default order, are <b>dot1x</b> , <b>mab</b> , and <b>webauth</b> . The specified order also determines the relative priority of the methods for reauthentication, from highest to lowest.                                                                                |
| Step 9  | <code>Tqvwgt*eqphki/kh+%<b>"cwvjgpvkecvkqp"</b>rtkqtkv{ "<br/>method1"]method2_" ]method3_</code>   | (Optional) Overrides the relative priority of authentication methods to be used. The three values of <i>method</i> , in the default order of priority, are <b>dot1x</b> , <b>mab</b> , and <b>webauth</b> .                                                                                                                                                                                        |
| Step 10 | <code>Tqvwgt*eqphki/kh+%<b>"cwvjgpvkecvkqp"</b>gxgvp" hckn"<br/>cevkqp"pgzv/ogvjqf"</code>          | Specifies that the next configured authentication method will be used if authentication fails.                                                                                                                                                                                                                                                                                                     |
| Step 11 | <code>Tqvwgt*eqphki/kh+%<b>"ocd"</b>]gcr_</code>                                                    | Enables MAC authentication bypass. The optional <b>eap</b> keyword specifies that the EAP extension is used during RADIUS authentication.                                                                                                                                                                                                                                                          |
| Step 12 | <code>Tqvwgt*eqphki/kh+%<b>"cwvjgpvkecvkqp"</b>hcnndcem"<br/>profile-name</code>                    | Enables web-based authentication using the specified profile.                                                                                                                                                                                                                                                                                                                                      |
| Step 13 | <code>Tqvwgt*eqphki/kh+%<b>"cwvjgpvkecvkqp"</b>xkqncvkqp"<br/>]ujwvfqyp"~"tguvtkev_</code>          | (Optional) Configures the disposition of the port if a security violation occurs. The default action is to shut down the port. If the <b>restrict</b> keyword is configured, the port will not be shutdown, but trap entries will be installed for the violating MAC address, and traffic from that MAC address will be dropped.                                                                   |
| Step 14 | <code>Tqvwgt*eqphki/kh+%<b>"cwvjgpvkecvkqp"</b>vkogt "<br/>kpcvkv{xkv{ " }ugeqpfu"~"ugtugt i</code> | (Optional) Configures the inactivity timeout value for MAB and 802.1X. By default, inactivity aging is disabled for a port. <ul style="list-style-type: none"> <li><i>seconds</i>—Specifies inactivity timeout period. The range is from 1 to 65535 seconds.</li> <li><i>server</i>—Specifies that the inactivity timeout period value will be obtained from the authentication server.</li> </ul> |
| Step 15 | <code>Tqvwgt*eqphki/kh+%<b>"cwvjgpvkecvkqp"</b>vkogt "tguvtcv"<br/>seconds</code>                   | (Optional) Specifies a period after which the authentication process will restart in an attempt to authenticate an unauthorized port. <ul style="list-style-type: none"> <li><i>seconds</i>—Specifies the restart period. The range is from 1 to 65535 seconds.</li> </ul>                                                                                                                         |
| Step 16 | <code>Tqvwgt*eqphki/kh+%<b>"gzkv"</b></code>                                                        | Returns to global configuration mode.                                                                                                                                                                                                                                                                                                                                                              |

|         | Command                                          | Purpose                                                                               |
|---------|--------------------------------------------------|---------------------------------------------------------------------------------------|
| Step 17 | <code>Tqvwgt*eqphki+% "kr"fgxkeg"vtcemkpi</code> | Enables the IP device tracking table, which is required for web-based authentication. |
| Step 18 | <code>Tqvwgt*eqphki+% "gzkv</code>               | Returns to privileged EXEC mode.                                                      |

This example shows how to enable 802.1X fallback to MAB, and then to enable web-based authentication, on an 802.1X-enabled port:

```
Tqvwgt*eqphki+% "kr"cfokuukqp"pcog"twng3"rtqz{"jvvr
Tqvwgt*eqphki+% "hcndcem"rtqhkng"hcndcem3
Tqvwgt*eqphki/hcndcem/rtqhkng+% "kr"ceeguu/itqwr"fghcwnv/rqnke{"kp"
Tqvwgt*eqphki/hcndcem/rtqhkng+% "kr"cfokuukqp"twng3"
Tqvwgt*eqphki/hcndcem/rtqhkng+% "gzkv
Tqvwgt*eqphki+% "kpvgtthceg"ikicdkv313
Tqvwgt*eqphki/kh+% "uykvejrqtv"oqfg"ceeguu"
Tqvwgt*eqphki/kh+% "cwvjgpvkecvkqp"rgtv/eqpvtqn"cwvg"
Tqvwgt*eqphki/kh+% "fqv3z"rcg"cwvjgpvkecvqt"
Tqvwgt*eqphki/kh+% "cwvjgpvkecvkqp"qtfgt"fqv3z"ocd"ygdccwvj
Tqvwgt*eqphki/kh+% "ocd"gcr
Tqvwgt*eqphki/kh+% "cwvjgpvkecvkqp"hcndcem"hcndcem3"
Tqvwgt*eqphki/kh+% "gzkv
Tqvwgt*eqphki+% "kr"fgxkeg"vtcemkpi
Tqvwgt*eqphki+% "gzkv
```

## Enabling Periodic Reauthentication

You can enable periodic 802.1X client reauthentication and specify how often it occurs. You can specify the reauthentication period manually or you can use the session-timeout period specified by the RADIUS server. If you enable reauthentication without specifying a time period, the number of seconds between reauthentication attempts is 3600.

To enable periodic reauthentication of the client and to configure the number of seconds between reauthentication attempts, perform this task:

|        | Command                                                                                     | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|--------|---------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+% "kpvgtthceg" type slot/port"</code>                                   | Specifies the port to be configured, and enters interface configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Step 2 | <code>Tqvwgt*eqphki/kh+% "cwvjgpvkecvkqp"rgtkqfke</code>                                    | Enables periodic reauthentication of the client, which is disabled by default.                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Step 3 | <code>Tqvwgt*eqphki/kh+% "cwvjgpvkecvkqp"vkogt" tgccwvjgpvkecvg"] seconds ~"ugtugt_"</code> | Specifies the number of seconds between reauthentication attempts using these keywords: <ul style="list-style-type: none"> <li><b>seconds</b>—Sets the number of seconds from 1 to 65535; the default is 3600 seconds.</li> <li><b>server</b>—Sets the number of seconds based on the value of the Session-Timeout RADIUS attribute (Attribute[27]) and the Termination-Action RADIUS attribute (Attribute [29]).</li> </ul> This command affects the operation of the switch only if periodic reauthentication is enabled. |
| Step 4 | <code>Tqvwgt*eqphki/kh+% "gpf</code>                                                        | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

This example shows how to enable periodic reauthentication and set the number of seconds between reauthentication attempts to 4000:

```
Tqvwgt *eqphki+% "kpvgt hceg" iki cdkvgvjgtpgv"713
Tqvwgt *eqphki/kh+% "cwvjgpvkcevkqp" rgtkqfke
Tqvwgt *eqphki/kh+% "cwvjgpvkcevkqp" vkogt "tgcwvjgpvkcevg"6222
```

Verifies your entries.

```
Tqvwgt% "ujqy" fqv3z "kpvgt hceg" type slot/port
```

## Manually Reauthenticating the Client Connected to a Port

To manually reauthenticate the client connected to a port, perform this task:

| Command                                                     | Purpose                                                                                 |
|-------------------------------------------------------------|-----------------------------------------------------------------------------------------|
| Tqvwgt% "fqv3z"tg/cwvjgpvkcevg" kpvgt hceg" type slot/port" | Manually reauthenticates the client connected to a port.                                |
|                                                             | <b>Note</b> Reauthentication does not disturb the status of an already authorized port. |

This example shows how to manually reauthenticate the client connected to Gigabit Ethernet port 5/1:

```
Tqvwgt% "fqv3z"tg/cwvjgpvkcevg" kpvgt hceg" iki cdkvgvjgtpgv"713
```

Verifies your entries.

```
Tqvwgt% "ujqy" fqv3z "cnn
```

## Initializing Authentication for the Client Connected to a Port

To initialize the authentication for the client connected to a port, perform this task:

| Command                                                 | Purpose                                                                                                                              |
|---------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|
| Tqvwgt% "fqv3z" kpkvkcnk  g" kpvgt hceg type slot/port" | Initializes the authentication for the client connected to a port.                                                                   |
|                                                         | <b>Note</b> Initializing authentication disables any existing authentication before authenticating the client connected to the port. |

This example shows how to initialize the authentication for the client connected to Gigabit Ethernet port 5/1:

```
Tqvwgt% "fqv3z" kpkvkcnk |g" kpvgt hceg" iki cdkvgvjgtpgv"713
```

Verifies your entries.

```
Tqvwgt% "ujqy" fqv3z "cnn
```

## Removing 802.1X Client Information Globally

To completely delete all existing supplicants from all the interfaces on the switch, perform this task:

| Command                             | Purpose                                                                   |
|-------------------------------------|---------------------------------------------------------------------------|
| <code>Tqwgvt%engct"fqv3z"cnn</code> | Removes 802.1X client information for all clients connected to all ports. |

This example shows how to remove 802.1X client information for all clients connected to all ports:

```
Tqwgvt%engct"fqv3z"cnn
```

## Removing 802.1X Client Information from an Interface

To completely delete all existing supplicants from an interface or from all the interfaces on the switch, perform this task:

| Command                                                  | Purpose                                                                           |
|----------------------------------------------------------|-----------------------------------------------------------------------------------|
| <code>Tqwgvt%engct"fqv3z"kpvgthceg type slot/port</code> | Removes 802.1X client information for the client connected to the specified port. |

This example shows how to remove 802.1X client information for the client connected to Gigabit Ethernet port 5/1:

```
Tqwgvt%engct"fqv3z"kpvgthceg"ikicdkvgvjgtpgv"713
```

## Clearing Authentication Sessions

To clear all or selected authentication sessions, perform this task:

| Command                                                                                                                | Purpose                                                                                                                                                                                                  |
|------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwgvt%engct"cwvjgvpvkecvkqp"uguukqpu"]jcpfng jcpfng_"<br/>]kpvgthceg"kpvgthceg_"]oce oce_"ogvjqf ogvjqf_</code> | Clears current authentication sessions. With no options specified, all current active sessions will be cleared. The keywords can be added and combined to clear specific sessions or subset of sessions. |

This example shows how to clear all MAB authentication sessions connected to Gigabit Ethernet port 5/1:

```
Tqwgvt%engct"cwvjgvpvkecvkqp"uguukqpu"kpvgthceg"ikicdkvgvjgtpgv"713"ogvjqf"ocd
```

## Changing 802.1X Timeouts

You can change several 802.1X timeout attributes using the **dot1x timeout {attribute} seconds** command form in the interface configuration mode. This section shows in detail how to change the quiet period timeout, followed by descriptions of how to change other 802.1X timeouts using the same command form.



## Setting the Quiet Period

When the switch cannot authenticate the client, the switch remains idle for a set period of time and then tries again. The **dot1x timeout quiet-period** interface configuration command controls the idle period. A failed authentication of the client might occur because the client provided an invalid password. You can provide a faster response time to the user by entering a number smaller than the default.

To change the quiet period, perform this task:

|        | Command                                                                  | Purpose                                                                                                                                                                                      |
|--------|--------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%<b>kpvgthceg</b> type slot/port"</code>             | Specifies the port to be configured, and enters interface configuration mode.                                                                                                                |
| Step 2 | <code>Tqvwgt*eqphki/kh+%<b>fqv3z"vkogqvw"swkgv/rgtkqf"</b>seconds</code> | Sets the number of seconds that the switch remains in the quiet state following a failed authentication exchange with the client.<br><br>The range is 0 to 65535 seconds; the default is 60. |
| Step 3 | <code>Tqvwgt*eqphki/kh+%<b>gpf</b></code>                                | Returns to privileged EXEC mode.                                                                                                                                                             |

This example shows how to set the quiet period on the switch to 30 seconds:

```
Tqvwgt*eqphki+%kpvgthceg"ikicdkvgvjgtpgv"713
Tqvwgt*eqphki/kh+%fqv3z"vkogqvw"swkgv/rgtkqf"52
```

## Setting the Switch-to-Client Retransmission Time

The client responds to the EAP-request/identity frame from the switch with an EAP-response/identity frame. If the switch does not receive this response, it waits a set period of time (known as the retransmission time), and then retransmits the frame.



### Note

You should change the default value of this command only to adjust for unusual circumstances such as unreliable links or specific operational problems with certain clients and authentication servers.

To change the amount of time that the switch waits for a response to an EAP-request/identity frame from the client before retransmitting the request, use the **dot1x timeout tx-period seconds** command in the interface configuration mode. The range is 1 to 65535 seconds; the default is 30. To return to the default retransmission time, use the **no dot1x timeout tx-period** command.

This example shows how to set 60 as the number of seconds that the switch waits for a response to an EAP-request/identity frame from the client before retransmitting the request:

```
Tqvwgt*eqphki+%kpvgthceg"ikicdkvgvjgtpgv"713
Tqvwgt*eqphki/kh+%fqv3z"vkogqvw"vz/rgtkqf"82
```

## Setting the Switch-to-Client Retransmission Time for EAP-Request Frames

The client notifies the switch that it received the EAP-request frame. If the switch does not receive this notification, the switch waits a set period of time, and then retransmits the frame.

To set the amount of time that the switch waits for notification, use the **dot1x timeout supp-timeout seconds** command in the interface configuration mode. The range is 1 to 65535 seconds; the default is 30. To return to the default retransmission time, use the **no dot1x supp-timeout** command.

This example shows how to set the switch-to-client retransmission time for the EAP-request frame to 25 seconds:

```
Tqvwgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"713
Tqvwgt*eqphki/kh+%"fqv3z"vkogqvw"uwrr/vkogqvw"47
```

## Setting the Switch-to-Authentication-Server Retransmission Time for Layer 4 Packets

The authentication server notifies the switch each time it receives a Layer 4 packet. If the switch does not receive a notification after sending a packet, the switch waits a set period of time and then retransmits the packet.

To set the value for the retransmission of Layer 4 packets from the switch to the authentication server, perform this task:

|        | Command                                                                     | Purpose                                                                                                                                                                       |
|--------|-----------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqvwgt*eqphki+% <b>"kpvgtthceg"</b> <i>type slot/port</i>                   | Specifies the port to be configured, and enters interface configuration mode.                                                                                                 |
| Step 2 | Tqvwgt*eqphki/kh+% <b>"fqv3z"</b> vkogqvw"ugtugt/vkogqvw"<br><i>ugeqpfu</i> | Sets the value for the retransmission of Layer 4 packets from the switch to the authentication server. The range for <i>seconds</i> is 1 to 65535 seconds; the default is 30. |
| Step 3 | Tqvwgt*eqphki/kh+% <b>"gpf"</b>                                             | Returns to privileged EXEC mode.                                                                                                                                              |

This example shows how to set the switch-to-authentication-server retransmission time for Layer 4 packets to 25 seconds:

```
Tqvwgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"713
Tqvwgt*eqphki/kh+%"fqv3z"vkogqvw"ugtugt/vkogqvw"47
```

## Setting the Switch-to-Client Frame Retransmission Number

In addition to changing the switch-to-client retransmission time, you can change the number of times that the switch sends an EAP-request/identity frame (assuming no response is received) to the client before restarting the authentication process.



### Note

You should change the default value of this command only to adjust for unusual circumstances such as unreliable links or specific operational problems with certain clients and authentication servers.

To set the switch-to-client frame retransmission number, perform this task:

|        | Command                                                   | Purpose                                                                                                                                                                          |
|--------|-----------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqvwgt*eqphki+% <b>"kpvgtthceg"</b> <i>type slot/port</i> | Specifies the port to be configured, and enters interface configuration mode.                                                                                                    |
| Step 2 | Tqvwgt*eqphki/kh+% <b>"fqv3z"</b> ocz/tgs" <i>count</i>   | Sets the number of times that the switch sends an EAP-request/identity frame to the client before restarting the authentication process. The range is 1 to 10; the default is 2. |
| Step 3 | Tqvwgt*eqphki/kh+% <b>"gpf"</b>                           | Returns to privileged EXEC mode.                                                                                                                                                 |

This example shows how to set 5 as the number of times that the switch sends an EAP-request/identity request before restarting the authentication process:

```
Tqvwgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"713
Tqvwgt*eqphki/kh+%"fqv3z"ocz/tgs"7
```

## Setting the Reauthentication Number

You can also change the number of times that the switch restarts the authentication process before the port changes to the unauthorized state.



### Note

You should change the default value of this command only to adjust for unusual circumstances such as unreliable links or specific operational problems with certain clients and authentication servers.

To set the reauthentication number, perform this task:

|        | Command                                                            | Purpose                                                                                                                                                                 |
|--------|--------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqvwgt*eqphki+%<b>"kpvgtthceg" type slot/port</b>"</code>    | Specifies the port to be configured, and enters interface configuration mode.                                                                                           |
| Step 2 | <code>Tqvwgt*eqphki/kh+%<b>"fqv3z"ocz/tgcwvj/tgs</b>" count</code> | Sets the number of times that the switch restarts the authentication process before the port changes to the unauthorized state. The range is 0 to 10; the default is 2. |
| Step 3 | <code>Tqvwgt*eqphki/kh+%<b>gpf</b></code>                          | Returns to privileged EXEC mode.                                                                                                                                        |

This example shows how to set 4 as the number of times that the switch restarts the authentication process before the port changes to the unauthorized state:

```
Tqvwgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"713
Tqvwgt*eqphki/kh+%"fqv3z"ocz/tgcwvj/tgs"6
```

## Configuring IEEE 802.1X Accounting

Enabling AAA system accounting with 802.1X accounting allows system reload events to be sent to the accounting RADIUS server for logging. The server then can determine that all active 802.1X sessions are closed.

Because RADIUS uses the unreliable UDP transport protocol, accounting messages might be lost due to poor network conditions. If the switch does not receive the accounting response message from the RADIUS server after a configurable number of retransmissions of an accounting request, this system message appears:

```
Ceeqwpvkpi"oguucig" 'u'hqt"uguukqp" 'u'hckngf"vq"tgegkxg"Ceeqwpvkpi"Tgurqpug0
```

When the stop message is not sent successfully, this message appears:

```
22<2;<77<"'TCFKWU/5/PQCEEQWPVKPITGURQPUG<"Ceeqwpvkpi"oguucig"Uvctv"hqt"uguukqp"
3940420720367"uco"33128125"29<23<38"33222224"hckngf"vq"tgegkxg"Ceeqwpvkpi"Tgurqpug0
```

**Note**

You must configure the RADIUS server to perform accounting tasks, such as logging start, stop, and interim-update messages and time stamps. To turn on these functions, enable logging of “Update/Watchdog packets from this AAA client” in your RADIUS server Network Configuration tab. Next, enable “CVS RADIUS Accounting” in your RADIUS server System Configuration tab.

To configure 802.1X accounting after AAA is enabled on your switch, perform this task:

|        | Command                                                                              | Purpose                                                                                                                                                    |
|--------|--------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "ccc"ceeqwpvkpi"fqv3z"fghcwnv"uvctv/uvqr"itqwr"tcfkwu</code>   | Enables 802.1X accounting using the list of all RADIUS servers.                                                                                            |
| Step 2 | <code>Tqwgvt*eqphki+% "ccc"ceeqwpvkpi"u{uvgo"fghcwnv"uvctv/uvqr"itqwr"tcfkwu"</code> | (Optional) Enables system accounting (using the list of all RADIUS servers) and generates system accounting reload event messages when the switch reloads. |
| Step 3 | <code>Tqwgvt*eqphki+% "gpf</code>                                                    | Returns to privileged EXEC mode.                                                                                                                           |
| Step 4 | <code>Tqwgvt%"ujqy"twppkpi/eqphki</code>                                             | Verifies your entries.                                                                                                                                     |

Use the **show radius statistics** privileged EXEC command to display the number of RADIUS messages that do not receive the accounting response message.

This example shows how to configure 802.1X accounting. The first command configures the RADIUS server, specifying 1813 as the UDP port for accounting:

```
Tqwgvt*eqphki+% "tcfkwu/ugtxgt"jqv"394034205;068"cwvj/rqtv"3:34"ceev/rqtv"3:35"mg{ "tcf345
Tqwgvt*eqphki+% "ccc"ceeqwpvkpi"fqv3z"fghcwnv"uvctv/uvqr"itqwr"tcfkwu
Tqwgvt*eqphki+% "ccc"ceeqwpvkpi"u{uvgo"fghcwnv"uvctv/uvqr"itqwr"tcfkwu
```

## Configuring VLAN User Distribution

You can define a VLAN group that contains multiple VLANs. For VLAN load balancing, you can then configure the RADIUS server to supply a VLAN group name as part of the response to a user during 802.1X authentication. If the supplied VLAN group name is found among the VLAN group names that you have defined, the newly authenticated user is placed in the least populated VLAN within the VLAN group.

To configure a VLAN group, perform this task:

| Command                                                                  | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|--------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwgvt*eqphki+% "xnep"itqwr"group-name"xnep/nkuv"vlan-list"</code> | <p>Creates a VLAN group or adds VLANs to an existing VLAN group.</p> <ul style="list-style-type: none"> <li><i>group-name</i>—The name of the VLAN group. The name may contain up to 32 characters and must begin with a letter.</li> <li><b>vlan-list</b> <i>vlan-list</i>—The VLANs that belong to the VLAN group. Group members can be specified as a single VLAN ID, a list of VLAN IDs, or a VLAN ID range. Multiple entries are separated by a hyphen (-) or a comma (,).</li> </ul> |

This example shows how to map VLANs 7 through 9 and 11 to a VLAN group:

```
Tqwwgt*eqphki+% "xnep"itqwr"icp{ogfg"xnep/nkuv"9/;.33"
```

## Configuring a Guest VLAN

When you configure a guest VLAN, clients that are not 802.1X-capable are put into the guest VLAN when the server does not receive a response to its EAP request/identity frame. Clients that are 802.1X-capable but that fail authentication are not granted network access. When operating as a guest VLAN, a port functions in multiple-hosts mode regardless of the configured host mode of the port.

To configure a guest VLAN, perform this task:

|        | Command                                                                                             | Purpose                                                                                                                                                                                                                    |
|--------|-----------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+% "kpvgtthceg type slot/port"</code>                                            | Specifies the port to be configured, and enters interface configuration mode.                                                                                                                                              |
| Step 2 | <code>Tqwwgt*eqphki/kh+% "uykvejrtv"ogfg" }ceeguu"~"<br/>rtkxcvg/xnep"jqv;"</code>                  | Sets the port to access mode or as a private VLAN host port. Routed and trunk ports do not support a guest VLAN.                                                                                                           |
| Step 3 | <code>Tqwwgt*eqphki/kh+% "cwvjgpkvckqp"rtv/eqpvtqn"<br/>cwvg</code>                                 | Enables authentication on the port.                                                                                                                                                                                        |
| Step 4 | <code>Tqwwgt*eqphki/kh+% "cwvjgpkvckqp"gxgpv"<br/>pq/tgurqpug"cevckqp"cwvjqtk g"xnep"vlan-id</code> | Specifies an active VLAN as a guest VLAN. The range is 1 to 4094.<br><br>You can configure any active VLAN except an internal VLAN (routed port), an RSPAN VLAN, a private primary PVLAN, or a voice VLAN as a guest VLAN. |
| Step 5 | <code>Tqwwgt*eqphki/kh+% " }fqv3z"rcg"cwvjgpkvckvqt"~"ocd;</code>                                   | Specifies whether the port authentication method is 802.1X or MAC address bypass.                                                                                                                                          |
| Step 6 | <code>Tqwwgt*eqphki/kh+% "gpf</code>                                                                | Returns to privileged EXEC mode.                                                                                                                                                                                           |

This example shows how to enable VLAN 2 as an 802.1X guest VLAN:

```
Tqwwgt*eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv"713
Tqwwgt*eqphki/kh+% "cwvjgpkvckqp"rtv/eqpvtqn"cwvg
Tqwwgt*eqphki/kh+% "cwvjgpkvckqp"gxgpv"pq/tgurqpug"cevckqp"cwvjqtk|g"xnep"4
Tqwwgt*eqphki/kh+% "fqv3z"rcg"cwvjgpkvckvqt
```

This example shows how to set 3 seconds as the client notification timeout on the switch, to set 15 as the number of seconds that the switch waits for a response to an EAP-request/identity frame from the client before resending the request, and to enable VLAN 2 as an 802.1X guest VLAN when an 802.1X port is connected to a DHCP client:

```
Tqwwgt*eqphki/kh+% "fqv3z"vkogqvw"uwrr/vkogqvw"5
Tqwwgt*eqphki/kh+% "fqv3z"vkogqvw"vz/rgtkqf"37
Tqwwgt*eqphki/kh+% "cwvjgpkvckqp"gxgpv"pq/tgurqpug"cevckqp"cwvjqtk|g"xnep"4
Tqwwgt*eqphki/kh+% "fqv3z"rcg"cwvjgpkvckvqt
```

## Configuring a Restricted VLAN

When you configure a restricted VLAN on a switch, clients that are 802.1X-compliant are moved into the restricted VLAN when the authentication server does not receive a valid username and password. When operating as a restricted VLAN, a port functions in single-host mode regardless of the configured host mode of the port.

To configure a restricted VLAN, perform this task:

|        | Command                                                                                                                                     | Purpose                                                                                                                                                                                                                                 |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%<b>"kpvgtthceg type slot/port"</b></code>                                                                              | Specifies the port to be configured, and enters interface configuration mode.                                                                                                                                                           |
| Step 2 | <code>Tqwgvt*eqphki/kh+%<b>"uykvej rqtv"oqfg"</b> } ceeguu "~"</code><br><code><b>rtkxcvg/xncp"j quv;"</b></code>                           | Sets the port to access mode or as a private VLAN host port. Routed and trunk ports do not support a guest VLAN.                                                                                                                        |
| Step 3 | <code>Tqwgvt*eqphki/kh+%<b>"cwvjgpvkecvkqp"rqtv/eqpvtqn"</b></code><br><code><b>cwvq</b></code>                                             | Enables port-based authentication on the port.                                                                                                                                                                                          |
| Step 4 | <code>Tqwgvt*eqphki/kh+%<b>"cwvjgpvkecvkqp"gxgvp"hc kn"</b></code><br><code><b>] tgv t{ "tgvtkgu_"cevkqp"cwvjqt k g"xncp"vlan-id</b></code> | Specifies an active VLAN as a restricted VLAN. The range for <i>vlan-id</i> is 1 to 4094.<br><br>(Optional) The <b>retry</b> keyword specifies a number of authentication attempts to allow before a port moves to the restricted VLAN. |
| Step 5 | <code>Tqwgvt*eqphki/kh+%<b>"gpf"</b></code>                                                                                                 | Returns to privileged EXEC mode.                                                                                                                                                                                                        |

To disable and remove the restricted VLAN, use the **no** form of the **authentication event fail** command or the **dot1x auth-fail** command. The port returns to the unauthorized state.

You can configure the maximum number of authentication attempts allowed before a user is assigned to the restricted VLAN. You can set the number of attempts by using the **retry** keyword in the **authentication event fail [retry retries] action authorize vlan** command. The range of *retries* (allowable authentication attempts) is 1 to 5. The default is 2 attempts.

This example shows how to enable VLAN 2 as a restricted VLAN, with assignment of a host after 3 failed attempts:

```
Tqwgvt*eqphki+%"kpvgtthceg"iki cdkvgvjgtpgv"713
Tqwgvt*eqphki/kh+%"cwvjgpvkecvkqp"rqtv/eqpvtqn"cwvq
Tqwgvt*eqphki/kh+%"cwvjgpvkecvkqp"gxgvp"hc kn"tgvt{ "5"cevkqp"cwvjqt k|g"xncp"4
Tqwgvt*eqphki/kh+%"fqv3z"rcg"cwvjgpvkecvqt
```

## Configuring the Inaccessible Authentication Bypass Feature

You can configure the inaccessible bypass feature, also referred to as critical authentication or the AAA fail policy.

To configure the port as a critical port and enable the inaccessible authentication bypass feature, perform this task:

|        | Command                                                                       | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------|-------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%tcfkwu/ugtxgt"fgcf/etkvgtkc"vkog"vkog"vtkgu"tries</code> | <p>(Optional) Sets the conditions that are used to decide when a RADIUS server is considered unavailable or <i>dead</i>.</p> <p>The range for <i>time</i> is from 1 to 120 seconds. The switch dynamically determines the default <i>seconds</i> value that is 10 to 60 seconds.</p> <p>The range for <i>tries</i> is from 1 to 100. The switch dynamically determines the default <i>tries</i> parameter that is 10 to 100.</p> |
| Step 2 | <code>Tqwgvt*eqphki+%tcfkwu/ugtxgt"fgcfvkog"minutes</code>                    | (Optional) Sets the number of minutes that a RADIUS server is not sent requests. The range is from 0 to 1440 minutes (24 hours). The default is 0 minutes.                                                                                                                                                                                                                                                                       |

|        | Command                                                                                                                                                                                            | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 3 | <pre>Tqwvgt*eqphki+%<b>"tcfkwu/ugtxgt"jqvu</b>"ip-address" ]ceev/rqtv"udp-port_"cwvj/rqtv"udp-port_"mg{ " uvtkpi_"vguv"wugtpcog"pcog"]kfng/vkog"vkog_" ]kipqtg/ceev/rqtv_"kipqtg/cwvj/rqtv__</pre> | <p>(Optional) Configures the RADIUS server parameters by using these keywords:</p> <ul style="list-style-type: none"> <li>• <b>acct-port</b> <i>udp-port</i>—Specifies the UDP port for the RADIUS accounting server. The range for the UDP port number is from 0 to 65536. The default is 1646.</li> <li>• <b>auth-port</b> <i>udp-port</i>—Specifies the UDP port for the RADIUS authentication server. The range for the UDP port number is from 0 to 65536. The default is 1645.</li> </ul> <p><b>Note</b> You should configure the UDP port for the RADIUS accounting server and the UDP port for the RADIUS authentication server to nondefault values.</p> <ul style="list-style-type: none"> <li>• <b>key</b> <i>string</i>—Specifies the authentication and encryption key for all RADIUS communication between the switch and the RADIUS daemon.</li> </ul> <p><b>Note</b> You can also configure the authentication and encryption key by using the <b>radius-server key</b> {<i>0 string</i>   <i>7 string</i>   <i>string</i>} global configuration command.</p> <ul style="list-style-type: none"> <li>• <b>test username</b> <i>name</i>—Enables automated testing of the RADIUS server status, and specify the username to be used.</li> <li>• <b>idle-time</b> <i>time</i>—Sets the interval of time in minutes after which the switch sends test packets to the server. The range is from 1 to 35791 minutes. The default is 60 minutes (1 hour).</li> <li>• <b>ignore-acct-port</b>—Disables testing on the RADIUS server accounting port.</li> <li>• <b>ignore-auth-port</b>—Disables testing on the RADIUS server authentication port.</li> </ul> |
| Step 4 | <pre>Tqwvgt*eqphki+%<b>"fqv3z"etkvekcn"gcrcn</b></pre>                                                                                                                                             | <p>(Optional) Specifies that the switch sends an EAPOL-Success message when the switch successfully authenticates the critical port.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Step 5 | <pre>Tqwvgt*eqphki/kh+%<b>"cwvjgpykecvkqp"etkvekcn" tgeqxtg{ "fgnc{ milliseconds</b></pre>                                                                                                         | <p>(Optional) Sets the recovery delay period during which the switch waits to reinitialize a critical port when a RADIUS server that was unavailable becomes available. The range is from 1 to 10000 milliseconds. The default is 1000 milliseconds (a port can be reinitialized every second).</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Step 6 | <pre>Tqwvgt*eqphki+%<b>"kpvgtthceg</b> type slot/port"</pre>                                                                                                                                       | <p>Specifies the port to be configured, and enters interface configuration mode.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |



|        | Command                                                                                                      | Purpose                                                                                                                                                                                                                                                                   |
|--------|--------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 7 | <code>Tqwwgt*eqphki/kh+% "cwvjgppvkecvkqp" gxgppv "ugtxgt" fgcf "cevkqp" cwvjqt   g ] xncp "vlan-id_"</code> | Enables the inaccessible authentication bypass feature, authorizing ports on the specified VLAN when the AAA server is unreachable. If no VLAN is specified, the access VLAN will be used.<br><br><b>Note</b> The <b>vlan</b> keyword is only available on a switch port. |
| Step 8 | <code>Tqwwgt*eqphki/kh+% "cwvjgppvkecvkqp" gxgppv "ugtxgt" cnkxg "cevkqp" tgtkpvkcnk   g</code>              | Configures the inaccessible authentication bypass recovery feature, specifying that the recovery action is to authenticate the port when an authentication server becomes available.                                                                                      |
| Step 9 | <code>Tqwwgt*eqphki/kh+% "gpf</code>                                                                         | Returns to privileged EXEC mode.                                                                                                                                                                                                                                          |

To return to the RADIUS server default settings, use the **no radius-server dead-criteria**, the **no radius-server deadtime**, and the **no radius-server host** global configuration commands. To return to the default settings of inaccessible authentication bypass, use the **no dot1x critical eapol** global configuration command. To disable inaccessible authentication bypass, use the **no authentication event server dead action authorize** (or **no dot1x critical**) interface configuration command.

This example shows how to configure the inaccessible authentication bypass feature:

```
Tqwwgt*eqphki+% "tcfkwu/ugtxgt" fgcf/etkvgtkc "vkog" 52 "vtkgu" 42
Tqwwgt*eqphki+% "tcfkwu/ugtxgt" fgcfvkog" 82
Tqwwgt*eqphki+% "tcfkwu/ugtxgt" jquv" 32030304 "ceev/rqtv" 3772 "cwvj/rqtv" 3782 "mg{ "cde3456"vguv"
wugtpcog" wugt3 "kfng/vkog" 52
Tqwwgt*eqphki+% "fqv3z" etkvkecn "gcrqn
Tqwwgt*eqphki+% "cwvjgppvkecvkqp" etkvkecn "tgeqxt { "fgnc{ "4222
Tqwwgt*eqphki+% "kpvgtthceg" ikicdkvgvjgtpgv" 213
Tqwwgt*eqphki/kh+% "cwvjgppvkecvkqp" gxgppv "ugtxgt" fgcf "cevkqp" cwvjqt | g] xncp" 345
Tqwwgt*eqphki/kh+% "cwvjgppvkecvkqp" gxgppv "ugtxgt" cnkxg "cevkqp" tgtkpvkcnk | g
```

## Configuring MAC Authentication Bypass

To configure MAC authentication bypass on an interface, perform this task:

|        | Command                                                                                                                 | Purpose                                                                                                                                                                                                                                                                                                                                             |
|--------|-------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwwgt*eqphki+% "kpvgtthceg type slot/port"</code>                                                                | Specifies the port to be configured, and enters interface configuration mode.                                                                                                                                                                                                                                                                       |
| Step 2 | <code>Tqwwgt*eqphki/kh+% "cwvjgppvkecvkqp" rqtv/eqpvtqn" }cwvq" ~ "hqtæg/cwvjqt   gf" ~ "hqtæg/wpcwvjqt   gf ; "</code> | Enables 802.1X authentication on the port.<br><br>The keywords have these meanings: <ul style="list-style-type: none"> <li><b>auto</b>—Allows only EAPOL traffic until successful authentication.</li> <li><b>force-authorized</b>—Allows all traffic, requires no authentication.</li> <li><b>force-unauthorized</b>—Allows no traffic.</li> </ul> |

|        | Command                                   | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|--------|-------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 3 | <code>Tqwgvt*eqphki/kh+%"ocd"]gcr_</code> | Enables MAC authentication bypass on the interface. <ul style="list-style-type: none"> <li>(Optional) Use the <b>eap</b> keyword to configure the switch to use EAP for authorization.</li> <li>When MAC authentication bypass with EAP has been enabled on an interface, it is not disabled by a subsequent <b>default interface</b> command on the interface.</li> <li>To use MAC authentication bypass on a routed port, make sure that MAC address learning is enabled on the port.</li> </ul> |
| Step 4 | <code>Tqwgvt*eqphki/kh+%"gpf</code>       | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

This example shows how to enable MAC authentication bypass on a port:

```
Tqwgvt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"713
Tqwgvt*eqphki/kh+%"cwvjgpvkecvkqp"rqtvt/eqpvtqn"cwvg
Tqwgvt*eqphki/kh+%"ocd
```

## Configuring NAC Layer 2 IEEE 802.1X Validation

You can configure NAC Layer 2 IEEE 802.1X validation, which is also referred to as 802.1X authentication with a RADIUS server. NAC Layer 2 IEEE 802.1X configuration is the same as 802.1X configuration with the additional step of configuring the RADIUS server with a posture token and VLAN assignment.

To configure NAC Layer 2 IEEE 802.1X validation, perform this task:

|        | Command                                                                                   | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|--------|-------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%"kpvgtthceg type slot/port"</code>                                   | Specifies the port to be configured, and enters interface configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Step 2 | <code>Tqwgvt*eqphki/kh+%"cwvjgpvkecvkqp"rqtvt/eqpvtqn"cwvg"</code>                        | Enables port-based authentication on the interface.                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Step 3 | <code>Tqwgvt*eqphki/kh+%"cwvjgpvkecvkqp"rgtkqfke"</code>                                  | Enables periodic reauthentication of the client, which is disabled by default.                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Step 4 | <code>Tqwgvt*eqphki/kh+%"cwvjgpvkecvkqp"vkogt "tgcwvjgpvkecvg"] seconds ~"ugttxgt_</code> | Specifies the number of seconds between reauthentication attempts using these keywords: <ul style="list-style-type: none"> <li><i>seconds</i>—Sets the number of seconds from 1 to 65535; the default is 3600 seconds.</li> <li><b>server</b>—Sets the number of seconds based on the value of the Session-Timeout RADIUS attribute (Attribute[27]) and the Termination-Action RADIUS attribute (Attribute [29]).</li> </ul> This command affects the operation of the switch only if periodic reauthentication is enabled. |
| Step 5 | <code>Tqwgvt*eqphki/kh+%"gpf</code>                                                       | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

This example shows how to configure NAC Layer 2 IEEE 802.1X validation:

```
Tqwgvt*eqphki+% "kpvgt hceg" iki cdkvgvjgtpgv"713
Tqwgvt*eqphki+% "cwvjgpvkecvkqp" rgtv/eqpvtqn"cwvg
Tqwgvt*eqphki/kh+% "cwvjgpvkecvkqp" rgtkqfke
Tqwgvt*eqphki/kh+% "cwvjgpvkecvkqp" vkogt "tgcwvjgpvkecvg" ugtxgt
```

## Configuring NAC Agentless Audit Support

To support the NAC audit architecture for agentless clients, the switch must snoop an authenticating 802.1X client's IP address, create and assign a unique session identifier for the agentless client, and pass this information to the RADIUS server for sharing with the NAC audit server. To allow the switch to obtain and share this information, you must enable ARP and DHCP snooping on the switch and you must enable the sending of certain RADIUS attributes.

To configure the RADIUS and tracking settings to support NAC agentless audit, perform this task:

|        | Command                                                               | Purpose                                                                                                                                                                                                        |
|--------|-----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqwgvt*eqphki+% "tcfkwu/ugtxgt" cvvtdkdwvg" : " kpenwfg/kp/ceeguu/tgs | Configures the switch to send the Framed-IP-Address RADIUS attribute (Attribute[8]) in access-request or accounting-request packets.                                                                           |
| Step 2 | Tqwgvt*eqphki+% "tcfkwu/ugtxgt" xuc"ugpf" cwvjgpvkecvkqp              | Configures the network access server to recognize and use vendor-specific attributes (VSAs) (specifically audit-session-id) in RADIUS Access-Requests generated by the switch during the authentication phase. |
| Step 3 | Tqwgvt*eqphki+% "tcfkwu/ugtxgt" xuc"ugpf" ceeqwpvkpi                  | Allows VSAs to be included in subsequent RADIUS Accounting-Requests.                                                                                                                                           |
| Step 4 | Tqwgvt*eqphki+% "kr" fgxkeg" vtcecmkpi                                | Enables the IP device tracking table.                                                                                                                                                                          |

## Configuring the Switch for DACLs or Redirect URLs

To configure switch ports to accept DACLs or redirect URLs from the RADIUS server during authentication of an attached host, perform this task:

|        | Command                                                   | Purpose                                                                                                                                                                                                                                                                                                                       |
|--------|-----------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqwgvt% "eqphki" vgtokpcn"                                | Enters global configuration mode.                                                                                                                                                                                                                                                                                             |
| Step 2 | Tqwgvt*eqphki+% "tcfkwu/ugtxgt" xuc"ugpf" cwvjgpvkecvkqp" | Configures the network access server to recognize and use vendor-specific attributes (VSAs) in RADIUS Access-Requests generated by the switch during the authentication phase.<br><br><b>Note</b> This step is necessary only with redirect URLs or when DACLs are downloaded using VSAs rather than the Filter-ID attribute. |
| Step 3 | Tqwgvt*eqphki+% "kr" fgxkeg" vtcecmkpi"                   | Enables the IP device tracking table.                                                                                                                                                                                                                                                                                         |

|         | Command                                                          | Purpose                                                                                                                                                                                      |
|---------|------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 4  | <code>Tqwvgt*eqphki+% "kr"ceeguu/nkuv"gzvgpfgf" dacl-name</code> | Configures an ACL that will be referenced by the VSA or Filter-ID attribute.<br><br><b>Note</b> This step is not necessary for DACLs defined on the RADIUS server and downloaded using VSAs. |
| Step 5  | <code>Tqwvgt*eqphki/uvf/pcen+% " }rgtokv"~"fgp{ ; "000</code>    | Defines the ACL.<br><br><b>Note</b> The source address must be ANY.                                                                                                                          |
| Step 6  | <code>Tqwvgt*eqphki/uvf/pcen+% "gzkv"</code>                     | Returns to global configuration mode.                                                                                                                                                        |
| Step 7  | <code>Tqwvgt*eqphki+% "kr"ceeguu/nkuv"gzvgpfgf" acl-name</code>  | Configures a default ACL for the ports.                                                                                                                                                      |
| Step 8  | <code>Tqwvgt*eqphki/uvf/pcen+% " }rgtokv"~"fgp{ ; "000</code>    | Defines the ACL.                                                                                                                                                                             |
| Step 9  | <code>Tqwvgt*eqphki/uvf/pcen+% "gzkv"</code>                     | Returns to global configuration mode.                                                                                                                                                        |
| Step 10 | <code>Tqwvgt*eqphki+% "kpvgthceg type slot/port"</code>          | Specifies the port to be configured, and enters interface configuration mode.                                                                                                                |
| Step 11 | <code>Tqwvgt*eqphki/kh+% "gzkv"</code>                           | Returns to global configuration mode.                                                                                                                                                        |

This example shows how to configure a switch for a downloadable policy:

```
Tqwvgt*"eqphki"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0"Gpf"ykvj"EPVN1\0
Tqwvgt*eqphki+% "tcfkwu/ugtxgt"xuc"ugpf"cwvjgpvkecvkqp"
Tqwvgt*eqphki+% "kr"fgxkeg"vtcemkpi"
Tqwvgt*eqphki+% "kr"ceeguu/nkuv"gzvgpfgf"o{afcen"
Tqwvgt*eqphki/gzv/pcen+% "rgtokv"ver"cp{ "jquv"32040506"
Tqwvgt*eqphki/gzv/pcen+% "gzkv"
Tqwvgt*eqphki+% "kr"ceeguu/nkuv"gzvgpfgf"fghcwnvacen"
Tqwvgt*eqphki/gzv/pcen+% "rgtokv"kr"cp{ "cp{ "
Tqwvgt*eqphki/gzv/pcen+% "gzkv"
Tqwvgt*eqphki+% "kpvgthceg"hcuvGvjgtpgv"4135"
Tqwvgt*eqphki/kh+% "kr"ceeguu/itqwr"fghcwnvacen"kp"
Tqwvgt*eqphki/kh+% "gzkv"
```

## Configuring 802.1X Authentication with WoL

To enable 802.1X authentication with wake-on-LAN (WoL), perform this task:

|        | Command                                                 | Purpose                                                                       |
|--------|---------------------------------------------------------|-------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "kpvgthceg type slot/port"</code> | Specifies the port to be configured, and enters interface configuration mode. |

|        | Command                                                                                 | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------|-----------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 2 | <code>Tqwvgt*eqphki/kh+% "cwvjgpvkecvkqp"<br/>eqpvtqn/fktgevkqp" }dqvj "~"kp i "</code> | Enables 802.1X authentication with WoL on the port, and uses these keywords to configure the port as bidirectional or unidirectional. <ul style="list-style-type: none"> <li><b>both</b>—Sets the port as bidirectional. The port cannot receive packets from or send packets to the host. By default, the port is bidirectional.</li> <li><b>in</b>—Sets the port as unidirectional. The port can send packets to the host but cannot receive packets from the host.</li> </ul> |
| Step 3 | <code>Tqwvgt*eqphki/kh+% "gpf"</code>                                                   | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

To disable 802.1X authentication with WoL, use the **no authentication control-direction** (or the **no dot1x control-direction**) interface configuration command.

This example shows how to enable 802.1X authentication with WoL and set the port as bidirectional:

```
Tqwvgt*eqphki+% "kpvgthceg" ikicdkvgvjgtpgv"713
Tqwvgt*eqphki/kh+% "cwvjgpvkecvkqp"eqpvtqn/fktgevkqp"dqvj
```

## Enabling MAC Move

To globally enable MAC move on the switch, perform this task:

|        | Command                                                       | Purpose                                                  |
|--------|---------------------------------------------------------------|----------------------------------------------------------|
| Step 1 | <code>Tqwvgt%"eqphkiwtg"vgtokpcn"</code>                      | Enters global configuration mode.                        |
| Step 2 | <code>Tqwvgt*eqphki+% "cwvjgpvkecvkqp"oce/oqxg"rgtokv"</code> | Enables MAC move on the switch.                          |
| Step 3 | <code>Tqwvgt*eqphki+% "gpf"</code>                            | Returns to privileged EXEC mode.                         |
| Step 4 | <code>Tqwvgt%"ujqy"twppkpi/eqphki "</code>                    | (Optional) Verifies your entries.                        |
| Step 5 | <code>Tqwvgt%"eqr{ "twppkpi/eqphki "uvctvwr/eqphki "</code>   | (Optional) Saves your entries in the configuration file. |

This example shows how to globally enable MAC move on a switch:

```
Tqwvgt*eqphki+% "cwvjgpvkecvkqp"oce/oqxg"rgtokv"
```

## Enabling MAC Replace

To enable MAC replace on an interface, perform this task:

|        | Command                                                | Purpose                                                                      |
|--------|--------------------------------------------------------|------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt%"eqphkiwtg"vgtokpcn"</code>               | Enters global configuration mode.                                            |
| Step 2 | <code>Tqwvgt*eqphki+% "kpvgthceg" interface-id"</code> | Specifies the port to be configured, and enter interface configuration mode. |

|        | Command                                                                                           | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|--------|---------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 3 | <pre>Tqwgvt*eqphki/kh+%"cwvjgpvkecvkqp"xlqncvkqp" }rtqvgev"~"tgrnceg"~"tguvtkev"~"ujwvfqyp;</pre> | <p>Uses the <b>replace</b> keyword to enable MAC replace on the interface. The port removes the current session and initiates authentication with the new host.</p> <p>The other keywords have these effects:</p> <ul style="list-style-type: none"> <li>• <b>protect</b>: the port drops packets with unexpected MAC addresses without generating a system message.</li> <li>• <b>restrict</b>: violating packets are dropped by the CPU and a system message is generated.</li> <li>• <b>shutdown</b>: the port is error disabled when it receives an unexpected MAC address.</li> </ul> |
| Step 4 | <pre>Tqwgvt*eqphki+%"gpf"</pre>                                                                   | Returns to privileged EXEC mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Step 5 | <pre>Tqwgvt%"ujqy"twppkpi/eqphki"</pre>                                                           | Verifies your entries.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Step 6 | <pre>Tqwgvt%"eqr{"twppkpi/eqphki"uvctvwr/eqphki"</pre>                                            | (Optional) Saves your entries in the configuration file.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

This example shows how to enable MAC replace on an interface:

```
Tqwgvt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv414"
Tqwgvt*eqphki/kh+%"cwvjgpvkecvkqp"xlqncvkqp"tgrnceg"
```

## Configuring NEAT Authenticator and Supplicant Switches

- [NEAT Authenticator Configuration, page 83-54](#)
- [NEAT Supplicant Configuration, page 83-55](#)



### Note

- NEAT requires one switch to be configured as a supplicant and to be connected to an authenticator switch.
- For overview information, see the “802.1x Supplicant and Authenticator Switches with Network Edge Access Topology (NEAT)” section on page 83-30.
- The cisco-av-pairs value must be configured as “device-traffic-class=switch” on the ACS, which sets the interface as a trunk after the supplicant is successfully authenticated.

## NEAT Authenticator Configuration

To configure a switch as an authenticator, perform this task:

|        | Command                                              | Purpose                                                                       |
|--------|------------------------------------------------------|-------------------------------------------------------------------------------|
| Step 1 | <pre>Tqwgvt%"eqphkiwtg"vgtokpcn"</pre>               | Enters global configuration mode.                                             |
| Step 2 | <pre>Tqwgvt*eqphki+%"ekur"gpccng"</pre>              | Enables CISP.                                                                 |
| Step 3 | <pre>Tqwgvt*eqphki+%"kpvgtthceg" interface-id"</pre> | Specifies the port to be configured, and enters interface configuration mode. |

|         | Command                                                               | Purpose                                                                         |
|---------|-----------------------------------------------------------------------|---------------------------------------------------------------------------------|
| Step 4  | <code>Tqwwgt*eqphki/kh+% "uykvej rqtv" oqfg "ceeguu"</code>           | Sets the port mode to <b>access</b> .                                           |
| Step 5  | <code>Tqwwgt*eqphki/kh+% "cwvjgppvkecvkqp" rqtv/eqpvtqn "cwvq"</code> | Sets the port-authentication mode to <b>auto</b> .                              |
| Step 6  | <code>Tqwwgt*eqphki/kh+% "fqv3z" rcg "cwvjgppvkecvqt"</code>          | Configures the interface as a port access entity (PAE) authenticator.           |
| Step 7  | <code>Tqwwgt*eqphki/kh+% "urcpgkpi/vtgg" rqtvhcuv"</code>             | Enables PortFast on an access port connected to a single workstation or server. |
| Step 8  | <code>Tqwwgt*eqphki/kh+% "gpf"</code>                                 | Returns to privileged EXEC mode.                                                |
| Step 9  | <code>Tqwwgt*"ujqy" twppkpi/eqphki "kpvgtthceg" interface-id"</code>  | Verifies your configuration.                                                    |
| Step 10 | <code>Tqwwgt*"egr{ "twppkpi/eqphki "uvctvwr/eqphki"</code>            | (Optional) Saves your entries in the configuration file.                        |

This example shows how to configure a switch as an 802.1x authenticator:

```
Tqwwgt*"eqphkiwtg" vgtokpcn
Tqwwgt*eqphki+% "ekur" gpcdng
Tqwwgt*eqphki+% "kpvgtthceg" ikicdkvgvjgtpgv313
Tqwwgt*eqphki/kh+% "uykvej rqtv" oqfg "ceeguu"
Tqwwgt*eqphki/kh+% "cwvjgppvkecvkqp" rqtv/eqpvtqn "cwvq"
Tqwwgt*eqphki/kh+% "fqv3z" rcg "cwvjgppvkecvqt"
Tqwwgt*eqphki/kh+% "urcpgkpi/vtgg" rqtvhcuv "vtwpm"
```

## NEAT Supplicant Configuration

To configure a switch as a supplicant, perform this task:

|         | Command                                                                    | Purpose                                                                                                                                                                                   |
|---------|----------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1  | <code>Tqwwgt*"eqphkiwtg" vgtokpcn"</code>                                  | Enters global configuration mode.                                                                                                                                                         |
| Step 2  | <code>Tqwwgt*eqphki+% "ekur" gpcdng"</code>                                | Enables CISP.                                                                                                                                                                             |
| Step 3  | <code>Tqwwgt*eqphki+% "fqv3z" etgfgpvkcnu "rtqhkng"</code>                 | Creates 802.1x credentials profile. This must be attached to the port that is configured as supplicant.                                                                                   |
| Step 4  | <code>Tqwwgt*eqphki+% "wugtpcog" uwrruykvej"</code>                        | Creates a username.                                                                                                                                                                       |
| Step 5  | <code>Tqwwgt*eqphki+% "rcuuyqtf" rcuuyqtf"</code>                          | Creates a password for the new username.                                                                                                                                                  |
| Step 6  | <code>Tqwwgt*eqphki+% "fqv3z" uwrrnkecpv "hqteg/ownvkecv"</code>           | Forces the switch to send <i>only</i> multicast EAPOL packets when it receives either unicast or multicast packets, which allows NEAT to work on the supplicant switch in all host modes. |
| Step 7  | <code>Tqwwgt*eqphki+% "kpvgtthceg interface-id"</code>                     | Specifies the port to be configured, and enters interface configuration mode.                                                                                                             |
| Step 8  | <code>Tqwwgt*eqphki/kh+% "uykvej rqtv" vtwpm "gpecruwncvkqp" fqv3s"</code> | Sets the port to trunk mode.                                                                                                                                                              |
| Step 9  | <code>Tqwwgt*eqphki/kh+% "uykvej rqtv" oqfg "vtwpm"</code>                 | Configures the interface as a VLAN trunk port.                                                                                                                                            |
| Step 10 | <code>Tqwwgt*eqphki/kh+% "fqv3z" rcg "uwrrnkecpv"</code>                   | Configures the interface as a port access entity (PAE) supplicant.                                                                                                                        |
| Step 11 | <code>Tqwwgt*eqphki/kh+% "fqv3z" etgfgpvkcnu "profile-name"</code>         | Attaches the 802.1x credentials profile to the interface.                                                                                                                                 |
| Step 12 | <code>Tqwwgt*eqphki/kh+% "gpf"</code>                                      | Returns to privileged EXEC mode.                                                                                                                                                          |

|         | Command                                                              | Purpose                                                  |
|---------|----------------------------------------------------------------------|----------------------------------------------------------|
| Step 13 | <code>Tqwgvt% "ujqy" twppkpi/eqphki "kpvgtthceg" interface-id</code> | Verifies your configuration.                             |
| Step 14 | <code>Tqwgvt% "eqr{ " twppkpi/eqphki "uvctvwr/eqphki "</code>        | (Optional) Saves your entries in the configuration file. |

This example shows how to configure a switch as a supplicant:

```
Tqwgvt% "eqphkiwtg" vgtokpcn"
Tqwgvt*eqphki+% "ekur" gpcdng"
Tqwgvt*eqphki+% "fqv3z" etgfgpvkcnu "vguv"
Tqwgvt*eqphki+% "wugtpcog" uwrruykvej "
Tqwgvt*eqphki+% "rcuuyqtf" o{uykvej "
Tqwgvt*eqphki+% "fqv3z" uwrrnkecpv "hqteg/ownvkecuv"
Tqwgvt*eqphki+% "kpvgtthceg" ikicdkvgvjgtpgv313 "
Tqwgvt*eqphki/kh+% "uykvej rqtv" vtwpm "gpecruwncvkqp" fqv3s"
Tqwgvt*eqphki/kh+% "uykvej rqtv" oqfg "vtwpm"
Tqwgvt*eqphki/kh+% "fqv3z" rcg "uwrrnkecpv"
Tqwgvt*eqphki/kh+% "fqv3z" etgfgpvkcnu "vguv"
Tqwgvt*eqphki/kh+% "gpf"
```

## Disabling 802.1X Authentication on the Port

You can disable 802.1X authentication on the port by using the **no dot1x pae** interface configuration command.

To disable 802.1X authentication on the port, perform this task:

|        | Command                                                         | Purpose                                                                       |
|--------|-----------------------------------------------------------------|-------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "kpvgtthceg type slot/port"</code>        | Specifies the port to be configured, and enters interface configuration mode. |
| Step 2 | <code>Tqwgvt*eqphki/kh+% "pq" fqv3z "rcg" cwvjgppvkecvqt</code> | Disables 802.1X authentication on the port.                                   |
| Step 3 | <code>Tqwgvt*eqphki/kh+% "gpf"</code>                           | Returns to privileged EXEC mode.                                              |

To configure the port as an 802.1X port access entity (PAE) authenticator, which enables 802.1X on the port but does not allow clients connected to the port to be authorized, use the **dot1x pae authenticator** interface configuration command.

This example shows how to disable 802.1X authentication on the port:

```
Tqwgvt*eqphki+% "kpvgtthceg" ikicdkvgvjgtpgv"713
Tqwgvt*eqphki/kh+% "pq" fqv3z "rcg" cwvjgppvkecvqt
```



## Resetting the 802.1X Configuration to the Default Values

To reset the 802.1X configuration to the default values, perform this task:

|        | Command                                                       | Purpose                                                                       |
|--------|---------------------------------------------------------------|-------------------------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+%<b>"kpvgthceg type slot/port"</b></code> | Specifies the port to be configured, and enters interface configuration mode. |
| Step 2 | <code>Tqwgvt*eqphki/kh+%<b>"fqv3z" fghcwnv"</b></code>        | Resets the configurable 802.1X parameters to the default values.              |
| Step 3 | <code>Tqwgvt*eqphki/kh+%<b>"gpf"</b></code>                   | Returns to privileged EXEC mode.                                              |

This example shows how to reset a port's 802.1X authentication settings to the default values:

```
Tqwgvt*eqphki+%"kpvgthceg" ikicdkvgvjgtpgv"5149
Tqwgvt*eqphki/kh+%"fqv3z" fghcwnv"
```

## Displaying Authentication Status and Information

- [Displaying 802.1X Status, page 83-57](#)
- [Displaying Authentication Methods and Status, page 83-58](#)
- [Displaying MAC Authentication Bypass Status, page 83-61](#)

### Displaying 802.1X Status

To display the global 802.1X administrative and operational status for the switch or the 802.1X settings for individual ports, perform this task:

| Command                                                                  | Purpose                                                                                                                                                                                                                                                                                                                                               |
|--------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwgvt%<b>"ujqy"fqv3z"]cnn"~"kpvgthceg type slot/port_"</b></code> | Displays the global 802.1X administrative and operational status for the switch.<br><br>(Optional) Use the <b>all</b> keyword to display the global 802.1X status and the 802.1X settings for all interfaces using 802.1X authentication.<br><br>(Optional) Use the <b>interface</b> keyword to display the 802.1X settings for a specific interface. |

This example shows how to view only the global 802.1X status:

```
Tqwgvt%"ujqy"fqv3z"
U{ucwvjegpvtqn"*****"Fkucdnf
Fqv3z"Rtqvqeqn"Xgtukqp"*****4
Etkvkecn"Tgeqxt{"Fgnc{"*****"322
Etkvkecn"GCRQN"*****"Fkucdnf

Tqwgvt%
```

```
Tqwgvt%"ujqy"fqv3z"cnn"
U{ucwvjeqpvtqn"*****Fkucdngf
Fqv3z"Rtqvqeqn"Xgtukqp"*****4
Etkvkecn"Tgeqxtg{"Fgnc{"*****322
Etkvkecn"GCRQN"*****Fkucdngf

Fqv3z"Kphq"hqt"IkicdkvGvjgtpgv5149
////////////////////////////////////
RCG"*****?"CWVJGPVKECVQT
RqtvEqpvtqn"*****?"HQTEGaCWVJQTK\GF
EqpvtqnFktgevkqp"*****?"Dqvj"
JquvOqfg"*****?"UKPINGaJQUV
TgCwvjgppvkecvkqp"*****?"Fkucdngf
SwkgvRgtkqf"*****?"82
UgtxgtVkogqgwv"*****?"52
UwrrVkogqgwv"*****?"52
TgCwvjRgtkqf"*****?"5822"*Nqecnn{"eqphkiwtgf+
TgCwvjOcz"*****?"4
OczTgs"*****?"4
VzRgtkqf"*****?"52
TcvgNkockvRgtkqf"*****?"2

Tqwgvt%
```

To display the authentication methods and status, perform any of these tasks:

**Table 83-2      Authentication Session States**

| State         | Description                                                               |
|---------------|---------------------------------------------------------------------------|
| Idle          | The session has been initialized and no methods have run yet.             |
| Running       | A method is running for this session.                                     |
| No methods    | No method has provided a result for this session.                         |
| Authc Success | A method has provided a successful authentication result for the session. |

**Table 83-2 Authentication Session States (continued)**

| State         | Description                                                           |
|---------------|-----------------------------------------------------------------------|
| Authc Failed  | A method has provided a failed authentication result for the session. |
| Authz Success | All features have been successfully applied for this session.         |
| Authz Failed  | A feature has failed to be applied for this session.                  |

**Table 83-3 Authentication Method States**

| State        | Description                                                                 |
|--------------|-----------------------------------------------------------------------------|
| Not run      | The method has not run for this session                                     |
| Running      | The method is running for this session.                                     |
| Failed over  | The method has failed and the next method is expected to provide a result.  |
| Success      | The method has provided a successful authentication result for the session. |
| Authc Failed | The method has provided a failed authentication result for the session.     |

This example shows how to display the registered authentication methods:

```
Tqwvgt%"ujqy"cwvjgppvkecvkqp"tgikuvtcvkqpu"
Cwvj "Ogvjqfu"tgikuvgtgf"ykvj"vjg"Cwvj"Ocpigt<
"Jcpfng"Rtkqtkv{"Pcog
"5"2"fqv3z
"4"3"ocd
"3"4"ygdcwvj
```

This example shows how to display the authentication details for a given interface:

```
Tqwvgt%"ujqy"cwvjgppvkecvkqp"kpvgthceg"ikicdkvgvjgtpgv"3145
Enkgpv"nkuv<
"OCE"Cfftguu""Fgockp""Uvcvwu""Jcpfng""Kpvgthceg
"2345067890cdef""FCVC""Cwvj|"Uweeguu""2zG222222""Ikicdkvgvjgtpgv3145

Cxckncdng"ogvjqfu"nkuv<
"Jcpfng"Rtkqtkv{"Pcog
"5"2"fqv3z
"4"3"ocd
Twppcdng"ogvjqfu"nkuv<
"Jcpfng"Rtkqtkv{"Pcog
"4"2"ocd
"5"3"fqv3z
```

This example shows how to display all authentication sessions on the switch:

```
Tqwvgt%"ujqy"cwvjgppvkecvkqp"uguukqpu"

Kpvgthceg"OCE"Cfftguu""Ogvjqf""Fgockp""Uvcvwu""Uguukqp"KF
Ik316:"2237085d20h898""fqv3z""FCVC""Cwvj|"Uweeguu""2C5684D322222324;:5E27E
Ik317:"222h045e60c623""ocd""FCVC""Cwvj|"Uweeguu""2C5684D3222222F46H:2D7:
Ik317:"22360dh7f0f48f""fqv3z""FCVC""Cwvj|"Uweeguu""2C5684D3222222G4;:33D;6
```

This example shows how to display sessions authorized using a specified authentication method:

```
Tqwgvt% "ujqy"cwvjgppvkecvkqp"ogvjqf"fqv3z
Kpvgthceg"OCE"Cfftguu""Ogvjqf""Fqockp""Uvcvwu""""Uguukqp"KF
Ik316:"""2237085d20h898""fqv3z""FCVC""Cwvj|"Uweeguu"2C5684D322222324;:5E27E
Ik317:"""22360dh7f0f48f""fqv3z""FCVC""Cwvj|"Uweeguu"2C5684D3222222G4;:33D;6
```

This example shows how to display all authentication sessions on an interface:

```
Tqwgvt% "ujqy"cwvjgppvkecvkqp"uguukqpu"kpvgthceg"ikicdkvgvjgtpgv"3169"
```

```
Kpvgthceg<"IkicdkvGvjgtpgv3169
""""OCE"Cfftguu<"Wmpqyp
""""KR"Cfftguu<"Wmpqyp
""""Uvcvwu<"Cwvj|"Uweeguu
""""Fqockp<"FCVC
""""Qrgt"jquv"oqfg<"ownvk/jquv
""""Qrgt"eqpvtqn"fkt<"dqvj
""""Cwvjqt|gf"D{<"Iwguv"Xncp
""""Xncp"Rqnke{<"42
""""Uguukqp"vkogqvw<"P1C
""""Kfng"vkogqvw<"P1C
""Egoqpp"Uguukqp"KF<"2C5684E:2222222224985E
""Ceev"Uguukqp"KF<"2z22222224
""Jcpfng<"2z47222222
```

```
Twppcdng"ogvjqfu"nkuv<
""""Ogvjqf""Uvcvg
""""ocd""""Hckngf"qxgt
""""fqv3z""""Hckngf"qxgt
```

```
////////////////////////////////////
```

```
""""Kpvgthceg<"IkicdkvGvjgtpgv3169
""""OCE"Cfftguu<"222707g9e0fc27
""""KR"Cfftguu<"Wmpqyp
""""Wugt/Pcog<"22277g9efc27
""""Uvcvwu<"Cwvj|"Uweeguu
""""Fqockp<"XQKEG
""""Qrgt"jquv"oqfg<"ownvk/fqockp
""""Qrgt"eqpvtqn"fkt<"dqvj
""""Cwvjqt|gf"D{<"Cwvjgppvkecvkqp"Ugtxgt
""""Uguukqp"vkogqvw<"P1C
""""Kfng"vkogqvw<"P1C
""Egoqpp"Uguukqp"KF<"2C5684E:22222232224C45:
""Ceev"Uguukqp"KF<"2z22222225
""Jcpfng<"2z;3222223
```

```
Twppcdng"ogvjqfu"nkuv<
""""Ogvjqf""Uvcvg
""""ocd""""Cwvje"Uweeguu
""""fqv3z""""Pqv"twp
```

This example shows how to display the authentication session for a specified session ID:

```
Tqwgvt% "ujqy"cwvjgppvkecvkqp"uguukqpu"uguukqp/kf"2D2323E9222226H4GF7743:
```

```
Kpvgthceg<"IkicdkvGvjgtpgv;14
""""OCE"Cfftguu<"2220222202233
""""KR"Cfftguu<"42020209
""""Wugtpcog<"1qjpfqg
""""Uvcvwu<"Cwvj|"Uweeguu
""""Fqockp<"FCVC
""""Qrgt"jquv"oqfg<"ownvk/jquv
""""Qrgt"eqpvtqn"fkt<"dqvj
```



```
Oce/Cwvj/D{rcuu"?????????"Gpcdnf
Kpcevkkv{"Vkogwv"?????????"Pqpg

OCD"Enkpv"Nkuv
//////////
Enkpv"OCE"?????????????????"222h045e60c623
OCD"UO"uvcvg"?????????????????"VGTOKPCVG
Cwvj"Uvcvwu"?????????????????"CWVJQTK\GF
```

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)



## Web-Based Authentication

---

- [Prerequisites for Web-based Authentication, page 84-1](#)
- [Restrictions for Web-based Authentication, page 84-1](#)
- [Information About Web-Based Authentication, page 84-2](#)
- [Default Web-Based Authentication Configuration, page 84-7](#)
- [How to Configure Web-Based Authentication, page 84-7](#)
- [Displaying Web-Based Authentication Status, page 84-15](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for Web-based Authentication

None.

## Restrictions for Web-based Authentication

- Web-based authentication is an ingress-only feature.
- You can configure web-based authentication only on access ports. Web-based authentication is not supported on trunk ports, EtherChannel member ports, or dynamic trunk ports.

- You must configure the default ACL on the interface before configuring web-based authentication. Configure a port ACL for a Layer 2 interface, or a Cisco IOS ACL for a Layer 3 interface.
- On Layer 2 interfaces, you cannot authenticate hosts with static ARP cache assignment. These hosts are not detected by the web-based authentication feature, because they do not send ARP messages.
- By default, the IP device tracking feature is disabled on a switch. You must enable the IP device tracking feature to use web-based authentication.
- You must configure at least one IP address to run the HTTP server on the switch. You must also configure routes to reach each host IP address. The HTTP server sends the HTTP login page to the host.
- Hosts that are more than one hop away may experience traffic disruption if an STP topology change results in the host traffic arriving on a different port. This is because ARP and DHCP updates may not be sent after a Layer 2 (STP) topology change.
- Web-based authentication does not support VLAN assignment as a downloadable host policy.
- Cisco IOS Release 15.4SY support downloadable ACLs (DACLS) from the RADIUS server.
- Web-based authentication is not supported for IPv6 traffic.

## Information About Web-Based Authentication

- [Web-Based Authentication Overview, page 84-2](#)
- [Device Roles, page 84-3](#)
- [Host Detection, page 84-3](#)
- [Session Creation, page 84-4](#)
- [Authentication Process, page 84-4](#)
- [AAA Fail Policy, page 84-5](#)
- [Customization of the Authentication Proxy Web Pages, page 84-5](#)
- [Web-based Authentication Interactions with Other Features, page 84-5](#)

## Web-Based Authentication Overview

The web-based authentication feature implements web-based authentication (also known as Web Authentication Proxy), which can function as part of the authentication, authorization, and accounting (AAA) system.

You can use the web-based authentication feature to authenticate end users on host systems that do not run the IEEE 802.1X supplicant. You can configure the web-based authentication feature on Layer 2 and Layer 3 interfaces.

When a user initiates an HTTP session, the web-based authentication feature intercepts ingress HTTP packets from the host and sends an HTML login page to the user. The user keys in their credentials, which the web-based authentication feature sends to the AAA server for authentication. If the authentication succeeds, web-based authentication sends a Login-Successful HTML page to the host and applies the access policies returned by the AAA server.



If the authentication fails, web-based authentication feature sends a Login-Fail HTML page to the user, which prompts the user to retry the login attempt. If the user exceeds the maximum number of failed login attempts, web-based authentication sends a Login-Expired HTML page to the host and the user is placed on a watch list for a waiting period.

## Device Roles

With web-based authentication, the devices in the network have specific roles as shown in [Figure 84-1](#).

**Figure 84-1**      *Web-based Authentication Device Roles*

The specific roles shown in [Figure 84-1](#) are as follows:

- *Client*—The device (workstation) that requests access to the LAN and switch services and responds to requests from the switch. The workstation must be running an HTML browser with Java Script enabled.
- *Authentication server*—Performs the actual authentication of the client. The authentication server validates the identity of the client and notifies the switch whether or not the client is authorized to access the LAN and switch services.
- *Switch*—Controls the physical access to the network based on the authentication status of the client. The switch acts as an intermediary (proxy) between the client and the authentication server, requesting identity information from the client, verifying that information with the authentication server, and relaying a response to the client.

## Host Detection

The switch maintains an IP device tracking table to store information about detected hosts.



### Note

By default, the IP device tracking feature is disabled on a switch. You must enable the IP device tracking feature to use web-based authentication.

For Layer 3 interfaces, web-based authentication sets an HTTP intercept ACL when the feature is configured on the interface (or when the interface is put in service).

For Layer 2 interfaces, web-based authentication detects IP hosts using the following mechanisms:

- ARP based trigger—ARP redirect ACL allows web-based authentication to detect hosts with static IP address or dynamically acquired IP address.

- Dynamic ARP Inspection
- DHCP snooping—Web-based authentication is notified when the switch creates a DHCP binding entry for the host.

## Session Creation

When web-based authentication detects a new host, it creates a session as follows:

- Checks the exception list  
If the host IP is included in the exception list, the policy from the exception list entry is applied, and the session is considered to be established.
- Checks for Auth bypass  
If the host IP is not on the exception list, web-based authentication sends a nonresponsive host (NRH) request to the server.  
If the server response is Access Accepted, authorization is bypassed for this host. The session is considered to be established.
- Sets up the HTTP Intercept ACL  
If the server response to the NRH request is Access Rejected, the HTTP intercept ACL is activated and the session waits for HTTP traffic from the host.

## Authentication Process

When web-based authentication is enabled, the following events occur:

- The user initiates an HTTP session.
- The HTTP traffic is intercepted, and authorization is initiated. The switch sends the login page to the user. The user enters a username and password on the login page, and the switch sends the entries to the authentication server.
- If the client identity is valid and the authentication succeeds, the switch downloads and activates the user's access policy from the authentication server. The login success page is sent to the user.
- If the authentication fails, the switch sends the login fail page. The user retries the login, but if the maximum number of attempts fail, the switch sends the login expired page and the host is placed in a watch list. After a watch list timeout, the user can retry the authentication process.
- If the authentication server does not respond to the switch, and if an AAA fail policy is configured, the switch will apply the failure access policy to the host. The login success page is sent to the user.

The switch reauthenticates a client when the host does not respond to an ARP probe on a Layer 2 interface, or the host does not send any traffic within the idle timeout on a Layer 3 interface.

- The feature applies the downloaded timeout or the locally configured session timeout.
- If the terminate action is RADIUS, the feature sends a nonresponsive host (NRH) request to the server. The terminate action is included in the response from the server.
- If the terminate action is default, the session is dismantled and the applied policy is removed.

## AAA Fail Policy

The AAA fail policy is a method for allowing a user to connect or to remain connected to the network if the AAA server is not available. If the AAA server cannot be reached when web-based authentication of a client is needed, instead of rejecting the user (that is, not providing the access to the network), an administrator can configure a default AAA fail policy that can be applied to the user.

This policy is advantageous for the following reasons:

- While AAA is unavailable, the user will still have connectivity to the network, although access may be restricted.
- When the AAA server is again available, a user can be revalidated, and the user's normal access policies can be downloaded from the AAA server.



**Note**

---

When the AAA server is down, the AAA fail policy is applied only if there is no existing policy associated with the user. Typically, if the AAA server is unavailable when a user session requires reauthentication, the policies currently in effect for the user are retained.

---

While the AAA fail policy is in effect, the session state is maintained as AAA Down.

## Customization of the Authentication Proxy Web Pages

The switch's internal HTTP server hosts four HTML pages for delivery to an authenticating client during the web-based authentication process. The four pages allow the server to notify the user of the following four states of the authentication process:

- Login—The user's credentials are requested
- Success—The login was successful
- Fail—The login has failed
- Expire—The login session has expired due to excessive login failures

You can substitute your custom HTML pages for the four default internal HTML pages, or you can specify a URL to which the user will be redirected upon successful authentication, effectively replacing the internal Success page.

## Web-based Authentication Interactions with Other Features

- [Port Security, page 84-6](#)
- [Gateway IP, page 84-6](#)
- [ACLs, page 84-6](#)
- [IP Source Guard, page 84-6](#)
- [EtherChannel, page 84-6](#)
- [Switchover, page 84-6](#)

## Port Security

You can configure web-based authentication and port security on the same port. (You configure port security on the port by using the **switchport port-security** interface configuration command.) When you enable port security and web-based authentication on a port, web-based authentication authenticates the port, and port security manages network access for all MAC addresses, including that of the client. You can then limit the number or group of clients that can access the network through the port.

For more information about enabling port security, see the [“How to Configure Port Security” section on page 85-4](#).

## Gateway IP

You cannot configure Gateway IP on a Layer 3 VLAN interface if web-based authentication is configured on any of the switch ports in the VLAN.

You can configure web-based authentication on the same Layer 3 interface as Gateway IP. The host policies for both features are applied in software. The GWIP policy overrides the web-based authentication host policy.

## ACLs

If you configure a VLAN ACL or Cisco IOS ACL on an interface, the ACL is applied to the host traffic only after the web-based authentication host policy is applied.

For Layer 2 web-based authentication, you must configure a port ACL (PACL) as the default access policy for ingress traffic from hosts connected to the port. After authentication, the web-based authentication host policy overrides the PACL.

You cannot configure a MAC ACL and web-based authentication on the same interface.

You cannot configure web-based authentication on a port whose access VLAN has VACL capture configured.

## IP Source Guard

Configuring IP Source Guard and web-based authentication on the same interface is not supported.

You can configure IP Source Guard and web-based authentication on the same interface. If DHCP snooping is also enabled on the access VLAN, you must enter the **platform acl tcam override dynamic dhcp-snooping** command in global configuration mode to avoid conflict between the two features. Other VLAN-based features are not supported when IP Source Guard and web-based authentication are combined.

## EtherChannel

You can configure web-based authentication on a Layer 2 EtherChannel interface. The web-based authentication configuration applies to all member channels.

## Switchover

In RPR redundancy mode, information about currently authenticated hosts is maintained during a switchover. Users will not need to reauthenticate.

# Default Web-Based Authentication Configuration

| Feature                             | Default Setting  |
|-------------------------------------|------------------|
| AAA                                 | Disabled         |
| RADIUS server                       |                  |
| • IP address                        | • None specified |
| • UDP authentication port           | • 1812           |
| • Key                               | • None specified |
| Default value of inactivity timeout | 3600 seconds     |
| Inactivity timeout                  | Enabled          |

## How to Configure Web-Based Authentication

- [Default Web-Based Authentication Configuration, page 84-7](#)
- [Web-based Authentication Configuration Task List, page 84-8](#)
- [Configuring the Authentication Rule and Interfaces, page 84-8](#)
- [Configuring AAA Authentication, page 84-9](#)
- [Configuring Switch-to-RADIUS-Server Communication, page 84-9](#)
- [Configuring the HTTP Server, page 84-11](#)
- [Configuring the Web-based Authentication Parameters, page 84-14](#)
- [Removing Web-based Authentication Cache Entries, page 84-14](#)

## Web-based Authentication Configuration Task List

- [Configuring the Authentication Rule and Interfaces, page 84-8](#)
- [Configuring AAA Authentication, page 84-9](#)
- [Configuring Switch-to-RADIUS-Server Communication, page 84-9](#)
- [Configuring the HTTP Server, page 84-11](#)
- [Configuring an AAA Fail Policy, page 84-13](#)
- [Configuring the Web-based Authentication Parameters, page 84-14](#)
- [Removing Web-based Authentication Cache Entries, page 84-14](#)

## Configuring the Authentication Rule and Interfaces

To configure web-based authentication, perform this task:

|        | Command                                                                                      | Purpose                                                                                                                                                                                                                                                      |
|--------|----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"kr"cfokuukqp"pcog"</b>name rtqz{"jvvr"</code>                       | Configures an authentication rule for web-based authorization.                                                                                                                                                                                               |
| Step 2 | <code>Tqwvgt*eqphki+%<b>"kpvgthceg"</b>type slot/port"</code>                                | Enters interface configuration mode and specifies the ingress Layer 2 or Layer 3 interface to be enabled for web-based authentication.                                                                                                                       |
| Step 3 | <code>Tqwvgt*eqphki/kh+%<b>"kr"ceeguu/itqwr"</b>pcog"</code>                                 | Applies the default ACL.                                                                                                                                                                                                                                     |
| Step 4 | <code>Tqwvgt*eqphki/kh+%<b>"kr"cfokuukqp"</b>name</code>                                     | Configures web-based authentication on the specified interface.                                                                                                                                                                                              |
| Step 5 | <code>Tqwvgt*eqphki/kh+%<b>"cwvjgvpvkecvkqp"qtfgt"</b>method1"<br/>]method2_]method3_</code> | (Optional) Specifies the fallback order of authentication methods to be used. The three values of <i>method</i> , in the default order, are <b>dot1x</b> , <b>mab</b> , and <b>webauth</b> .<br><br>Omitting a method disables that method on the interface. |
| Step 6 | <code>Tqwvgt*eqphki/kh+%<b>"gzkv"</b></code>                                                 | Returns to configuration mode.                                                                                                                                                                                                                               |
| Step 7 | <code>Tqwvgt*eqphki+%<b>"kr"fgxkeg"vtcemkpi</b></code>                                       | Enables the IP device tracking table.                                                                                                                                                                                                                        |
| Step 8 | <code>Tqwvgt*eqphki+%<b>"gpf"</b></code>                                                     | Returns to privileged EXEC mode.                                                                                                                                                                                                                             |

This example shows how to enable web-based authentication, while disabling 802.1X or MAB authentication, on port 5/1:

```
Tqwvgt*eqphki+%"kr"cfokuukqp"pcog"ygdchwj3"rtqz{"jvvr
```

```
Tqwvgt*eqphki+%"kpvgthceg"gigabitethernet"713
```

```
Tqwvgt*eqphki/kh+%"kr"cfokuukqp"ygdchwj3
```

```
Tqwvgt*eqphki/kh+%"cwvjgvpvkecvkqp"qtfgt"ygdchwj
```

```
Tqwvgt*eqphki/kh+%"gzkv"
```

```
Tqwvgt*eqphki+%"kr"fgxkeg"vtcemkpi
```

This example shows how to verify the configuration:

```
Tqwvgt%"ujqy"kr"cfokuukqp"eqphkiwtcvkqp
```

```
Cwvjgvpvkecvkqp"Rtqz{"Dcpggt"pgv"eqphkiwtgfg
```

```
Cwvjgvpvkecvkqp"inqdcn"ecejg"vkog"ku"82"okpwwgu
```

```
Cwvjgvpvkecvkqp"inqdcn"cdugnwvg"vkog"ku"2"okpwwgu
```

```

Cwvjgppvkecvkqp"inqdcn"kpkv"uvcvg"vkog"ku"4"okpwvgu
Cwvjgppvkecvkqp"Rtqz{"Ycvej/nkuv"ku"fkucdnf

Cwvjgppvkecvkqp"Rtqz{"Twng"Eqphkiwtcvkqp
"Cwvj/rtqz{"pcog"ygdwvj3
""jvvr"nkuv"pqv"urkehkgf"kpcevxxkv{/vkog"82"okpwvgu

Cwvjgppvkecvkqp"Rtqz{"Cwfkvpki"ku"fkucdnf
Ocz"Nqikp"cvvgorvu"rgt"wugt"ku"7

```

## Configuring AAA Authentication

To enable web-based authentication, you must enable AAA and specify the authentication method. perform this task:

|        | Command                                                                                     | Purpose                                                                                                                                                |
|--------|---------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "ccc"pgy/oqfgn</code>                                                 | Enables AAA functionality.                                                                                                                             |
| Step 2 | <code>Tqwvgt*eqphki+% "ccc"cwvjgppvkecvkqp"nqikp"fghcwnv"itqwr"}tacacs+"~"tcfkwu;</code>    | Defines the list of authentication methods at login.                                                                                                   |
| Step 3 | <code>Tqwvgt*eqphki+% "ccc"cwvjqtk cvkqp"cwvj/rtqz{"fghcwnv"itqwr"}tacacs+"~"tcfkwu;</code> | Creates an authorization method list for web-based authorization.                                                                                      |
| Step 4 | <code>Tqwvgt*eqphki+% "vceceu/ugtxgt"jquv"}jquvpog"~"kracfftguu;</code>                     | Specifies an AAA server. For Radius servers, see the section <a href="#">“Configuring Switch-to-RADIUS-Server Communication”</a> section on page 84-9. |
| Step 5 | <code>Tqwvgt*eqphki+% "vceceu/ugtxgt"mg{" "key-data;</code>                                 | Configures the authorization and encryption key used between the switch and the TACACS server.                                                         |

This example shows how to enable AAA:

```

Tqwvgt*eqphki+% "ccc"pgy/oqfgn
Tqwvgt*eqphki+% "ccc"cwvjgppvkecvkqp"nqikp"fghcwnv"itqwr"vceceu-
Tqwvgt*eqphki+% "ccc"cwvjqtk|cvkqp"cwvj/rtqz{"fghcwnv"itqwr"vceceu-

```

## Configuring Switch-to-RADIUS-Server Communication

RADIUS security servers are identified by any of the following:

- Host name
- Host IP address
- Host name and specific UDP port numbers
- IP address and specific UDP port numbers

The combination of the IP address and UDP port number creates a unique identifier, which enables RADIUS requests to be sent to multiple UDP ports on a server at the same IP address. If two different host entries on the same RADIUS server are configured for the same service (for example, authentication) the second host entry that is configured functions as the failover backup to the first one. The RADIUS host entries are chosen in the order that they were configured.

To configure the RADIUS server parameters, perform this task:

|        | Command                                                                                                 | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------|---------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+% "kr" tcfkwu"uqwteg/kpvgthceg" kpvgthcegapcog"</code>                              | Specifies that the RADIUS packets have the IP address of the indicated interface.                                                                                                                                                                                                                                                                                                                                                                |
| Step 2 | <code>Tqwvgt*eqphki+% "tcfkwu/ugtxgt" jquv" } jquvpcog" ~" ip-address; "vguv" wugtpcog" username</code> | Specifies the host name or IP address of the remote RADIUS server.<br><br>The <b>test username username</b> option enables automated testing of the RADIUS server connection. The specified <i>username</i> does not need to be a valid user name.<br><br>The <b>key</b> option specifies an authentication and encryption key to be used between the switch and the RADIUS server.<br><br>To use multiple RADIUS servers, reenter this command. |
| Step 3 | <code>Tqwvgt*eqphki+% "tcfkwu/ugtxgt" mg{ "string</code>                                                | Configures the authorization and encryption key used between the switch and the RADIUS daemon running on the RADIUS server.                                                                                                                                                                                                                                                                                                                      |
| Step 4 | <code>Tqwvgt*eqphki+% "tcfkwu/ugtxgt" xuc"ugpf" cwvjgpvkcecvkqp</code>                                  | Enables downloading of an ACL from the RADIUS server.                                                                                                                                                                                                                                                                                                                                                                                            |
| Step 5 | <code>Tqwvgt*eqphki+% "tcfkwu/ugtxgt" fgcf/etkvgtkc"vtkgu" num-tries</code>                             | Specifies the number of unanswered transmits to a RADIUS server before considering the server to be dead. The range of <i>num-tries</i> is 1 to 100.                                                                                                                                                                                                                                                                                             |

- Specify the **key string** on a separate command line.
- For **key string**, specify the authentication and encryption key used between the switch and the RADIUS daemon running on the RADIUS server. The key is a text string that must match the encryption key used on the RADIUS server.
- When you specify the **key string**, spaces within and at the end of the key are used. If you use spaces in the key, do not enclose the key in quotation marks unless the quotation marks are part of the key. This key must match the encryption used on the RADIUS daemon.
- You can globally configure the timeout, retransmission, and encryption key values for all RADIUS servers by using the **radius-server host** global configuration command. If you want to configure these options on a per-server basis, use the **radius-server timeout**, **radius-server retransmit**, and the **radius-server key** global configuration commands.



#### Note

You also need to configure some settings on the RADIUS server. These settings include the IP address of the switch, the key string to be shared by both the server and the switch, and the downloadable ACL. For more information, see the RADIUS server documentation.

This example shows how to configure the RADIUS server parameters on the switch:

```
Tqwvgt*eqphki+% "kr" tcfkwu"uqwteg/kpvgthceg" Xncp: 2
Tqwvgt*eqphki+% "tcfkwu/ugtxgt" jquv" 3940n4205; 068" vguv" wugtpcog" wugt3
Tqwvgt*eqphki+% "tcfkwu/ugtxgt" mg{ "tcf345
Tqwvgt*eqphki+% "tcfkwu/ugtxgt" fgcf/etkvgtkc"vtkgu" 4
```



## Configuring the HTTP Server

To use web-based authentication, you must enable the HTTP server within the switch. You can enable the server for either HTTP or HTTPS. To enable the server, perform one of these tasks in global configuration mode:

| Command                                                   | Purpose                                                                                                                                   |
|-----------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwvgt*eqphki+%<b>"kr"jvvr"ugtxgt</b></code>        | Enables the HTTP server. The web-based authentication feature uses the HTTP server to communicate with the hosts for user authentication. |
| <code>Tqwvgt*eqphki+%<b>"kr"jvvr"ugewtg/ugtxgt</b></code> | Enables HTTPS.                                                                                                                            |

You can optionally configure custom authentication proxy web pages or specify a redirection URL for successful login, as described in the following sections:

- [Customizing the Authentication Proxy Web Pages](#)
- [Specifying a Redirection URL for Successful Login](#)

## Customizing the Authentication Proxy Web Pages

You have the option to provide four substitute HTML pages to be displayed to the user in place of the switch's internal default HTML pages during web-based authentication.

To specify the use of your custom authentication proxy web pages, first store your custom HTML files on the switch's internal disk or flash memory, then perform this task in global configuration mode:

|        | Command                                                                                                                              | Purpose                                                                                                                                                                                           |
|--------|--------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%<b>"kr"cfokuukqp"rtqz{"jvvr"nqikp"</b></code><br><code><b>rcig"hknq" device:login-filename</b></code>           | Specifies the location in the switch memory file system of the custom HTML file to be used in place of the default login page. The <i>device:</i> is either disk or flash memory, such as disk0:. |
| Step 2 | <code>Tqwvgt*eqphki+%<b>"kr"cfokuukqp"rtqz{"jvvr"uweeguu"</b></code><br><code><b>rcig"hknq" device:succes-filename</b></code>        | Specifies the location of the custom HTML file to be used in place of the default login success page.                                                                                             |
| Step 3 | <code>Tqwvgt*eqphki+%<b>"kr"cfokuukqp"rtqz{"jvvr"hcknwtg"</b></code><br><code><b>rcig"hknq" device:fail-filename</b></code>          | Specifies the location of the custom HTML file to be used in place of the default login failure page.                                                                                             |
| Step 4 | <code>Tqwvgt*eqphki+%<b>"kr"cfokuukqp"rtqz{"jvvr"nqikp"</b></code><br><code><b>gxrktgf"rcig"hknq" device:expired-filename</b></code> | Specifies the location of the custom HTML file to be used in place of the default login expired page.                                                                                             |

- To enable the custom web pages feature, you must specify all four custom HTML files. If fewer than four files are specified, the internal default HTML pages will be used.
- The four custom HTML files must be present on the disk or flash of the switch.
- An image file has a size limit of 256 KB.
- All image files must have a filename that begins with “web\_auth\_” (like “web\_auth\_logo.jpg” instead of “logo.jpg”).
- All image file names must be less than 33 characters.

- Any images on the custom pages must be located on an accessible HTTP server. An intercept ACL must be configured within the admission rule to allow access to the HTTP server.
- Any external link from a custom page will require configuration of an intercept ACL within the admission rule.
- Any name resolution required for external links or images will require configuration of an intercept ACL within the admission rule to access a valid DNS server.
- If the custom web pages feature is enabled, a configured auth-proxy-banner will not be used.
- If the custom web pages feature is enabled, the redirection URL for successful login feature will not be available.
- To remove the specification of a custom file, use the **no** form of the command.

Because the custom login page is a public web form, consider the following guidelines for this page:

- The login form must accept user input for the username and password and must POST the data as **uname** and **pwd**.
- The custom login page should follow best practices for a web form, such as page timeout, hidden password, and prevention of redundant submissions.

The following example shows how to configure custom authentication proxy web pages:

```
Tqwvgt*eqphki+%"kr"cfokuukqp"rtqz{"jvvr"nqikp"rcig"hknq"fkum3<nqikp0jvo
Tqwvgt*eqphki+%"kr"cfokuukqp"rtqz{"jvvr"uweeguu"rcig"hknq"fkum3<uweeguu0jvo
Tqwvgt*eqphki+%"kr"cfokuukqp"rtqz{"jvvr"hc kn"rcig"hknq"fkum3<hc kn0jvo
Tqwvgt*eqphki+%"kr"cfokuukqp"rtqz{"jvvr"nqikp"gzrktgf"rcig"hknq"fkum3<gzrktgf0jvo
```

The following example shows how to verify the configuration of custom authentication proxy web pages:

```
Tqwvgt%"ujqy"kr"cfokuukqp"eqphkiwtcvkqp

Cwvjgppvkecvkqp"rtqz{"ygdrcig
"Nqikp"rcig"*****<"fkum3<nqikp0jvo
"Uweeguu"rcig"*****<"fkum3<uweeguu0jvo
"Hckn"Rcig"*****<"fkum3<hc kn0jvo
"Nqikp"gzrktgf"Rcig"*****<"fkum3<gzrktgf0jvo

Cwvjgppvkecvkqp"inqdcn"ecejg"vkog"ku"82"okpwvgu
Cwvjgppvkecvkqp"inqdcn"cdugnwvg"vkog"ku"2"okpwvgu
Cwvjgppvkecvkqp"inqdcn"kpkv"uvvcvg"vkog"ku"4"okpwvgu
Cwvjgppvkecvkqp"Rtqz{"Uguukqp"tcvgnkokv"ku"322
Cwvjgppvkecvkqp"Rtqz{"Ycvej/nkuv"ku"fkucdngf
Cwvjgppvkecvkqp"Rtqz{"Cwfkvpki"ku"fkucdngf
Ocz"Nqikp"cvvgorvu"rgt"wugt"ku"7
```

## Specifying a Redirection URL for Successful Login

You have the option to specify a URL to which the user will be redirected upon successful authentication, effectively replacing the internal Success HTML page.

To specify a redirection URL for successful login, perform this task in global configuration mode:

| Command                                                                                 | Purpose                                                                                 |
|-----------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|
| <code>Tqwvgt*eqphki+%<b>"kr"cfokuukqp"rtqz{"jvvr"uweeguu"tgfktgev"</b>url-string</code> | Specifies a URL for redirection of the user in place of the default login success page. |

When configuring a redirection URL for successful login, consider the following guidelines:

- If the custom authentication proxy web pages feature is enabled, the redirection URL feature is disabled and will not be available in the CLI. You can perform redirection in the custom login success page.
- If the redirection URL feature is enabled, a configured auth-proxy-banner will not be used.
- To remove the specification of a redirection URL, use the **no** form of the command.

The following example shows how to configure a redirection URL for successful login:

```
Tqvwgt*eqphki+%"kr"cfokuukqp"rtqz{"jvvr"uweeguu"tgfktgev"yyy0ekueq0eqo
```

The following example shows how to verify the redirection URL for successful login:

```
Tqvwgt%"ujqy"kr"cfokuukqp"eqphkiwtcvkqp

Cwvjgpkvkecvkqp"Rtqz{"Dcppt"pqv"eqphkiwtgf
Ewuvqok|cdng"Cwvjgpkvkecvkqp"Rtqz{"ygdrcig"pqv"eqphkiwtgf
JVVR"Cwvjgpkvkecvkqp"uweeguu"tgfktgev"vq"WTN<"jvvr<11yyy0ekueq0eqo
Cwvjgpkvkecvkqp"inqdcn"ecejg"vkog"ku"82"okpwwgu
Cwvjgpkvkecvkqp"inqdcn"cdugnwvg"vkog"ku"2"okpwwgu
Cwvjgpkvkecvkqp"inqdcn"kpkv"uvvvg"vkog"ku"4"okpwwgu
Cwvjgpkvkecvkqp"Rtqz{"Ycvej/nkuv"ku"fkucdnf
Cwvjgpkvkecvkqp"Rtqz{"Ocz"JVVR"rtqeguu"ku"9
Cwvjgpkvkecvkqp"Rtqz{"Cwfkvkpi"ku"fkucdnf
Ocz"Nqikp"cvvgorvu"rgt"wugt"ku"7
```

## Configuring an AAA Fail Policy

To configure an AAA fail policy, perform this task in global configuration mode:

|        | Command                                                                                                                                                         | Purpose                                                                                                                                                                                                                                                                                    |
|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <pre>Tqvwgt*eqphki+%<b>"kr"cfokuukqp"pcog"</b> <i>rule-name</i> <b>rtqz{"jvvr"gxgvp"vkogqvw"</b> <b>ccc"rqnke{"kfpgpvkv{"</b> <i>identity_policy_name</i></pre> | Creates an AAA fail rule and associates an identity policy to be applied to sessions when the AAA server is unreachable.<br><br>To remove the rule on the switch, use the <b>no ip admission name rule-name proxy http event timeout aaa policy identity</b> global configuration command. |
| Step 2 | <pre>Tqvwgt*eqphki+%<b>"kr"cfokuukqp"</b> <b>tcvgnkokv"ccc/fqyp"</b> <i>pwdgtaqhauguukqpu"</i></pre>                                                            | (Optional) To avoid flooding the AAA server when it returns to service, you can rate limit the authentication attempts from hosts in the AAA Down state.                                                                                                                                   |

The following example shows how to apply an AAA fail policy:

```
Tqvwgt*eqphki+%"kr"cfokuukqp"pcog"CCCaHCKNaRQNKE["rtqz{"jvvr"gxgvp"vkogqvw"ccc"rqnke{"
kfpgpvkv{"INQDCNaRQNKE[3
```

The following example shows how to determine whether any hosts are connected in the AAA Down state:

```
Tqvwgt%"ujqy"kr"cfokuukqp"ecejg
Cwvjgpkvkecvkqp"Rtqz{"Ecejg
"Enkgpv"KR"42;03870423033"Rgtv"2."vkogqvw"82."uvvvg"GVVCD"*CCC"Fqyp+
```

The following example shows how to view detailed information about a particular session based on the host IP address:

```
Tqvwgt%"ujqy"kr"cfokuukqp"ecejg"42;03870423033
Cfftguu""""""""""<"42;03870423033
OCE"Cfftguu""""""""""<"22220222202222
Kpvgthceg""""""""""<"Xncp555
Rqtv""""""""""<"5;;
Vkogqvw""""""""""<"82
Cig""""""""""<"3
Uvcvg""""""""""<"CCC"Fqyp
CCC"Fqyp"rqnke{ """"<"CCCaHCKNaRQNKKE [
```

## Configuring the Web-based Authentication Parameters

You can configure the maximum number of failed login attempts before the client is placed in a watch list for a waiting period.

To configure the web-based authentication parameters, perform this task:

|        | Command                                                                   | Purpose                                                                                                    |
|--------|---------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqvwgt*eqphki+% <b>"kr"cfokuukqp"ocz/nqikp/cvvgorvu"</b><br><i>number</i> | Sets the maximum number of failed login attempts. The range is 1 to 2147483647 attempts; the default is 5. |
| Step 2 | Tqvwgt*eqphki+% <b>"gpf"</b>                                              | Returns to privileged EXEC mode.                                                                           |

This example shows how to set the maximum number of failed login attempts to 10:

```
Tqvwgt*eqphki+%"kr"cfokuukqp"ocz/nqikp/cvvgorvu"32
```

## Removing Web-based Authentication Cache Entries

To delete existing session entries, perform either of these tasks:

| Command                                                                   | Purpose                                                                                                                                               |
|---------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| Tqvwgt%"engct" <b>kr"cwvj/rtqz{"ecejg"}</b> * ~" <i>host ip cfftguu</i> ; | Deletes authentication proxy entries. Use an asterisk to delete all cache entries. Enter a specific IP address to delete the entry for a single host. |
| Tqvwgt%"engct" <b>kr"cfokuukqp"ecejg"}</b> * ~" <i>host ip cfftguu</i> ;  | Deletes authentication proxy entries. Use an asterisk to delete all cache entries. Enter a specific IP address to delete the entry for a single host. |

This example shows how to remove the web-based authentication session for the client at a specific IP address:

```
Tqvwgt%"engct"kr"cwvj/rtqz{"ecejg"42;0387042303
```

# Displaying Web-Based Authentication Status

To display the web-based authentication settings for all interfaces or for specific ports, perform this task:

| Command                                                                               | Purpose                                                                                                                                                                                                                                                                                                      |
|---------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <code>Tqwgvt% "ujqy"ho"kr/cfokuukqp"n4jvvr"] cnn"~"kpvgtthceg type slot/port_"</code> | <p>Displays the web-based authentication settings.</p> <p>(Optional) Use the <b>all</b> keyword to display the settings for all interfaces using web-based authentication.</p> <p>(Optional) Use the <b>interface</b> keyword to display the web-based authentication settings for a specific interface.</p> |

This example shows how to view only the global web-based authentication status:

```
Tqwgvt% "ujqy"ho"kr/cfokuukqp"n4jvvr"cnn
```

This example shows how to view the web-based authentication settings for interface GigabitEthernet 3/27:

```
Tqwgvt% "ujqy"ho"kr/cfokuukqp"n4jvvr"kpvgtthceg"ikicdkvgvjgtpgv"5149
```



## Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)





## Port Security

---

- [Prerequisites for Port Security, page 85-1](#)
- [Restrictions for Port Security, page 85-1](#)
- [Information About Port Security, page 85-2](#)
- [Default Port Security Configuration, page 85-4](#)
- [How to Configure Port Security, page 85-4](#)
- [Verifying the Port Security Configuration, page 85-11](#)



### Note

- For complete syntax and usage information for the commands used in this chapter, see these publications:  
[http://www.cisco.com/en/US/products/ps11846/prod\\_command\\_reference\\_list.html](http://www.cisco.com/en/US/products/ps11846/prod_command_reference_list.html)
- Cisco IOS Release 15.4SY supports only Ethernet interfaces. Cisco IOS Release 15.4SY does not support any WAN features or commands.



### Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

[http://www.cisco.com/en/US/products/hw/switches/ps708/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html)

[Participate in the Technical Documentation Ideas forum](#)

## Prerequisites for Port Security

None.

## Restrictions for Port Security

- With the default port security configuration, to bring all secure ports out of the error-disabled state, enter the **errdisable recovery cause psecure-violation** global configuration command, or manually reenables the port by entering the **shutdown** and **no shut down** interface configuration commands.

- Enter the **clear port-security dynamic** global configuration command to clear all dynamically learned secure addresses.
- Port security learns unauthorized MAC addresses with a bit set that causes traffic to them or from them to be dropped. The **show mac address-table** command displays the unauthorized MAC addresses, but does not display the state of the bit. (CSCeb76844)
- To preserve dynamically learned sticky MAC addresses and configure them on a port following a bootup or a reload and after the dynamically learned sticky MAC addresses have been learned, you must enter a **write memory** or **copy running-config startup-config** command to save them in the startup-config file.
- Port security supports private VLAN (PVLAN) ports.
- Port security supports IEEE 802.1Q tunnel ports.
- Port security does not support Switch Port Analyzer (SPAN) destination ports.
- Port security supports access and trunking EtherChannel port-channel interfaces.
- You can configure port security and 802.1X port-based authentication on the same port.
- Port security supports nonnegotiating trunks.

- Port security only supports trunks configured with these commands:

**switchport**

**switchport trunk encapsulation**

**switchport mode trunk**

**switchport nonegotiate**

- If you reconfigure a secure access port as a trunk, port security converts all the sticky and static secure addresses on that port that were dynamically learned in the access VLAN to sticky or static secure addresses on the native VLAN of the trunk. Port security removes all secure addresses on the voice VLAN of the access port.
- If you reconfigure a secure trunk as an access port, port security converts all sticky and static addresses learned on the native VLAN to addresses learned on the access VLAN of the access port. Port security removes all addresses learned on VLANs other than the native VLAN.



**Note** Port security uses the VLAN ID configured with the **switchport trunk native vlan** command.

- Take care when you enable port security on the ports connected to the adjacent switches when there are redundant links running between the switches because port security might error-disable the ports due to port security violations.
- In Cisco IOS Release 15.1(1)SY2 and later releases, the options starting with the number 6 for the **radius-server attribute** command changed from 6, 61, 69 to 6, 61, 66, 67, and 69.

## Information About Port Security

- [Port Security with Dynamically Learned and Static MAC Addresses, page 85-3](#)
- [Port Security with Sticky MAC Addresses, page 85-3](#)
- [Port Security with IP Phones, page 85-4](#)



## Port Security with Dynamically Learned and Static MAC Addresses

You can use port security with dynamically learned and static MAC addresses to restrict a port's ingress traffic by limiting the MAC addresses that are allowed to send traffic into the port. When you assign secure MAC addresses to a secure port, the port does not forward ingress traffic that has source addresses outside the group of defined addresses. If you limit the number of secure MAC addresses to one and assign a single secure MAC address, the device attached to that port has the full bandwidth of the port.

A security violation occurs in these situations:

- When the maximum number of secure MAC addresses is reached on a secure port and the source MAC address of the ingress traffic is different from any of the identified secure MAC addresses, port security applies the configured violation mode.
- If traffic with a secure MAC address that is configured or learned on one secure port attempts to access another secure port in the same VLAN, applies the configured violation mode.



**Note** After a secure MAC address is configured or learned on one secure port, the sequence of events that occurs when port security detects that secure MAC address on a different port in the same VLAN is known as a MAC move violation.

- Running diagnostic tests with port security enabled.

See the [“Configuring the Port Security Violation Mode on a Port” section on page 85-6](#) for more information about the violation modes.

After you have set the maximum number of secure MAC addresses on a port, port security includes the secure addresses in the address table in one of these ways:

- You can statically configure all secure MAC addresses by using the **switchport port-security mac-address *mac\_address*** interface configuration command.
- You can allow the port to dynamically configure secure MAC addresses with the MAC addresses of connected devices.
- You can statically configure a number of addresses and allow the rest to be dynamically configured.

If the port has a link-down condition, all dynamically learned addresses are removed.

Following bootup, a reload, or a link-down condition, port security does not populate the address table with dynamically learned MAC addresses until the port receives ingress traffic.

A security violation occurs if the maximum number of secure MAC addresses have been added to the address table and the port receives traffic from a MAC address that is not in the address table.

You can configure the port for one of three violation modes: protect, restrict, or shutdown. See the [“How to Configure Port Security” section on page 85-4](#).

To ensure that an attached device has the full bandwidth of the port, set the maximum number of addresses to one and configure the MAC address of the attached device.


## Port Security with Sticky MAC Addresses

Port security with sticky MAC addresses provides many of the same benefits as port security with static MAC addresses, but sticky MAC addresses can be learned dynamically. Port security with sticky MAC addresses retains dynamically learned MAC addresses during a link-down condition.

If you enter a **write memory** or **copy running-config startup-config** command, then port security with sticky MAC addresses saves dynamically learned MAC addresses in the startup-config file and the port does not have to learn addresses from ingress traffic after bootup or a restart.

## Port Security with IP Phones

*Figure 85-1 Device Connected Through IP Phone*



Because the device is not directly connected to the switch, the switch cannot physically detect a loss of port link if the device is disconnected. Later Cisco IP phones send a Cisco Discovery Protocol (CDP) host presence type length value (TLV) to notify the switch of changes in the attached device's port link state. The switch recognizes the host presence TLV. Upon receiving a host presence TLV notification of a link down on the IP phone's data port, port security removes from the address table all static, sticky, and dynamically learned MAC addresses. The removed addresses are added again only when the addresses are learned dynamically or configured.

## Default Port Security Configuration

| Feature                                | Default Setting                                                                                                                   |
|----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| Port security                          | Disabled.                                                                                                                         |
| Maximum number of secure MAC addresses | 1.                                                                                                                                |
| Violation mode                         | Shutdown. The port shuts down when the maximum number of secure MAC addresses is exceeded, and an SNMP trap notification is sent. |

## How to Configure Port Security

- [Enabling Port Security, page 85-5](#)
- [Configuring the Port Security Violation Mode on a Port, page 85-6](#)
- [Configuring the Maximum Number of Secure MAC Addresses on a Port, page 85-7](#)
- [Enabling Port Security with Sticky MAC Addresses on a Port, page 85-8](#)
- [Configuring a Static Secure MAC Address on a Port, page 85-9](#)
- [Configuring Secure MAC Address Aging on a Port, page 85-10](#)





- **protect**—The PFC drops packets with unknown source addresses until you remove a sufficient number of secure MAC addresses to drop below the maximum value.
- **restrict**—The PFC drops packets with unknown source addresses until you remove a sufficient number of secure MAC addresses to drop below the maximum value and causes the security violation counter to increment.
- **shutdown**—Puts the interface into the error-disabled state immediately and sends an SNMP trap notification.

**Note**

To bring a secure port out of the error-disabled state, enter the **errdisable recovery cause violation\_mode** global configuration command, or you can manually reenab it by entering the **shutdown** and **no shut down** interface configuration commands.

This example shows how to configure the protect security violation mode on Gigabit Ethernet port 5/12:

```
Tqvwgt%eqphkiwtg"vgtokpcn
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0" "Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"7134
Tqvwgt*eqphki/kh+%"uykvejrgtv"rgtv/ugewtkv{"xkqncvkqp"rtqvgev"
Tqvwgt*eqphki/kh+%"fq"ujqy"rgtv/ugewtkv{"kpvgtthceg"ikicdkvgvjgtpgv"7134"~"kpenwfg"Rtqvgev
Xkqncvkqp"Oqfg"~"Rtqvgev"
```

This example shows how to configure the restrict security violation mode on Gigabit Ethernet port 5/12:

```
Tqvwgt%eqphkiwtg"vgtokpcn
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0" "Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%"kpvgtthceg"ikicdkvgvjgtpgv"7134
Tqvwgt*eqphki/kh+%"uykvejrgtv"rgtv/ugewtkv{"xkqncvkqp"tguvtkv"
Tqvwgt*eqphki/kh+%"fq"ujqy"rgtv/ugewtkv{"kpvgtthceg"ikicdkvgvjgtpgv"7134"~"kpenwfg"Tguvtkev
Xkqncvkqp"Oqfg"~"Tguvtkev"
```

## Configuring the Maximum Number of Secure MAC Addresses on a Port

To configure the maximum number of secure MAC addresses on a port, perform this task:

|        | Command                                                                                                    | Purpose                                                                                                                                             |
|--------|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Tqvwgt*eqphki+%"kpvgtthceg"<br>}type slot/port ~ rgtv/ejcppgn"ejcppgnapwodgt;"                             | Selects the interface to configure.                                                                                                                 |
| Step 2 | Tqvwgt*eqphki/kh+%"uykvejrgtv"rgtv/ugewtkv{"<br>oczko"pwodgtaqhacfftguugu"xncp }vlan_ID"~"<br>xncpatcpig;" | Sets the maximum number of secure MAC addresses for the port (default is 1).<br><br><b>Note</b> Per-VLAN configuration is supported only on trunks. |

- The range for *number\_of\_addresses* is 1 to 4,097.
- Port security supports trunks.
  - On a trunk, you can configure the maximum number of secure MAC addresses both on the trunk and for all the VLANs on the trunk.
  - You can configure the maximum number of secure MAC addresses on a single VLAN or a range of VLANs.
  - For a range of VLANs, enter a dash-separated pair of VLAN numbers.

- You can enter a comma-separated list of VLAN numbers and dash-separated pairs of VLAN numbers.

This example shows how to configure a maximum of 64 secure MAC addresses on Gigabit Ethernet port 5/12:

```
Tqwgvt%"eqphkiwtg"vgtokpcn
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv"7134
Tqwgvt*eqphki/kh+% "uykvejrgtv"rgtv/ugewtkv{"oczkwow"86"
Tqwgvt*eqphki/kh+% "fg"ujgy"rgtv/ugewtkv{"kpvgtthceg"ikicdkvgvjgtpgv"7134"~"kpenwfg"Oczkovo
Oczkovo"OCE"Cfftguugu""""<"86
```

## Enabling Port Security with Sticky MAC Addresses on a Port

To enable port security with sticky MAC addresses on a port, perform this task:

|        | Command                                                                                       | Purpose                                                    |
|--------|-----------------------------------------------------------------------------------------------|------------------------------------------------------------|
| Step 1 | <code>Tqwgvt*eqphki+% "kpvgtthceg"<br/>}type slot/port ~ rgtv/ejcppgn"ejcppgnapwodgt;"</code> | Selects the interface to configure.                        |
| Step 2 | <code>Tqwgvt*eqphki/kh+% "uykvejrgtv"rgtv/ugewtkv{"<br/>oce/cfftguu"uvkem{"</code>            | Enables port security with sticky MAC addresses on a port. |

- When you enter the **switchport port-security mac-address sticky** command:
  - All dynamically learned secure MAC addresses on the port are converted to sticky secure MAC addresses.
  - Static secure MAC addresses are not converted to sticky MAC addresses.
  - Secure MAC addresses dynamically learned in a voice VLAN are not converted to sticky MAC addresses.
  - New dynamically learned secure MAC addresses are sticky.
- When you enter the **no switchport port-security mac-address sticky** command, all sticky secure MAC addresses on the port are converted to dynamic secure MAC addresses.
- To preserve dynamically learned sticky MAC addresses and configure them on a port following a bootup or a reload, after the dynamically learned sticky MAC addresses have been learned, you must enter a **write memory** or **copy running-config startup-config** command to save them in the startup-config file.

This example shows how to enable port security with sticky MAC addresses on Gigabit Ethernet port 5/12:

```
Tqwgvt%"eqphkiwtg"vgtokpcn"
Gpvgt"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp0""Gpf"ykvj"EPVN1\0
Tqwgvt*eqphki+% "kpvgtthceg"ikicdkvgvjgtpgv"7134"
Tqwgvt*eqphki/kh+% "uykvejrgtv"rgtv/ugewtkv{"oce/cfftguu"uvkem{"
```

## Configuring a Static Secure MAC Address on a Port

To configure a static secure MAC address on a port, perform this task:

|        | Command                                                                                                     | Purpose                                                                                                                       |
|--------|-------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <code>Tqwvgt*eqphki+%"kpvgthceg"<br/>}type slot/port ~ rqtv/ejcppgn"ejcppgnapwodgt;"</code>                 | Selects the LAN port to configure.                                                                                            |
| Step 2 | <code>Tqwvgt*eqphki/kh+%"uykvejrtv"rqtv/ugewtkv{"<br/>oce/cfftguu"uvkem{"oceacfftguu"}xncp vlan_ID_"</code> | Configures a static MAC address as secure on the port.<br><br><b>Note</b> Per-VLAN configuration is supported only on trunks. |
| Step 3 | <code>Tqwvgt*eqphki/kh+%"gpf"</code>                                                                        | Exits configuration mode.                                                                                                     |

- You can configure sticky secure MAC addresses if port security with sticky MAC addresses is enabled (see the [“Enabling Port Security with Sticky MAC Addresses on a Port” section on page 85-8](#)).
- The maximum number of secure MAC addresses on the port, configured with the **switchport port-security maximum** command, defines how many secure MAC addresses you can configure.
- If you configure fewer secure MAC addresses than the maximum, the remaining MAC addresses are learned dynamically.
- Port security is supported on trunks.
  - On a trunk, you can configure a static secure MAC address in a VLAN.
  - On a trunk, if you do not configure a VLAN for a static secure MAC address, it is secure in the VLAN configured with the **switchport trunk native vlan** command.

This example shows how to configure a MAC address 1000.2000.3000 as secure on Gigabit Ethernet port 5/12 and verify the configuration:

```
Tqvwgt%"eqphkiwtg"vgtokpcn
GpvgT"eqphkiwtcvkqp"eqoocpfu."qpg"rgt"nkp00"0Gpf"ykvj"EPVN1\0
Tqvwgt*eqphki+%kpvgthceg"ikicdkvgvjgtpgv"7134
Tqvwgt*eqphki/kh+%uykvejrgtv"rgtv/ugewtkv{"oce/cfftguu"32220422205222
Tqvwgt*eqphki/kh+%gpf"
Tqvwgt%"ujqy"rgtv/ugewtkv{"cfftguu
"Ugewtg"Oce"Cfftguu"Vcdng
////////////////////////////////////
Xncp""Oce"Cfftguu""V{rg""Rqtvu
////////////////////////////////////
""3""32220422205222""UgewtgEqphkiwtqf""Ik7134
```





## Verifying the Port Security Configuration

| Command                                                                                                       | Purpose                                                                        |
|---------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------|
| <code>Tqvwgt%<b>"ujqy"rgtv/ugewtkv{" ] kpv gthceg"} }xncp"vlan_ID;" ~"}type slot/port;i _]cfftguu_</b></code> | Displays port security settings for the switch or for the specified interface. |

- ```
Tqwwgt%"ujqy"rqtv/ugewtkv{
Ugewtg"Rqtv"OczUgewtgCfft"EwttgpgvCfft"Ugewtkv{Xkqncvkqp"Ugewtkv{"Cevkqp
*****Eqwvp+*****Eqwvp+*****Eqwvp+
////////////////////////////////////
"Ik713"33"33"2"Ujwvfqyp
"Ik717"37"7"2"Tguvtkev
"Ik7133"7"6"2"Rtqggev
////////////////////////////////////

Vqvcn"Cfftguugu"kp"U{uvgo<"43
Ocz"Cfftguugu"nkokv"kp"U{uvgo<"34:
```

```
Tqwwgt%"ujqy"rqtv/ugewtkv{"cfftguu
"Ugewtg"Oce"Cfftguu"Vedng
////////////////////////////////////
```

```
Xncp"Oce"Cfftguu"V{rg"Rqtvu"Tgockkpi"Cig
*okpu+
////////////////////////////////////////
"3"22230222302223"UgewtgF{pcoke"Ik713"37"*K+
"3"22230222302224"UgewtgF{pcoke"Ik713"37"*K+
"3"22230222303333"UgewtgEqphkiwtgf"Ik713"38"*K+
"3"22230222303334"UgewtgEqphkiwtgf"Ik713"
"3"22230222303335"UgewtgEqphkiwtgf"Ik713"/
"3"22270222702223"UgewtgEqphkiwtgf"Ik717"45
"3"22270222702224"UgewtgEqphkiwtgf"Ik717"45
"3"22270222702225"UgewtgEqphkiwtgf"Ik717"45
"3"22330222302223"UgewtgEqphkiwtgf"Ik7133"47"*K+
"3"22330222302224"UgewtgEqphkiwtgf"Ik7133"47"*K+
////////////////////////////////////////
Vqvcn"Cfftguugu"kp"U{uvgo<"32
Ocz"Cfftguugu"nkokv"kp"U{uvgo<"34:
```



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

Participate in the Technical Documentation Ideas forum



Lawful Intercept

- [Prerequisites for Lawful Intercept, page 86-1](#)
- [Restrictions for Lawful Intercept, page 86-1](#)
- [Information About Lawful Intercept, page 86-3](#)
- [How to Configure Lawful Intercept Support, page 86-9](#)



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Prerequisites for Lawful Intercept

- You must be running images that support secure shell (SSH), for example, s72033-adventerprise9-mz. Lawful intercept is not supported on images that do not support SSH.
- You must be logged in to the switch with the highest access level (level 15). To log in with level-15 access, enter the **enable** command and specify the highest-level password defined for the switch.
- You must issue commands in global configuration mode at the command-line interface (CLI). You can configure lawful intercept globally on all interfaces or on a specific interface.
- The time of day on the switches and the mediation device must be synchronized; use Network Time Protocol (NTP) on both the switches and the mediation device.
- (Optional) It might be helpful to use a loopback interface for the interface through which the switch communicates with the mediation device. If you do not use a loopback interface, you must configure the mediation device with multiple physical interfaces on the switch to handle network failures.

Restrictions for Lawful Intercept

- [General Configuration Restrictions, page 86-2](#)
- [MIB Guidelines, page 86-3](#)

General Configuration Restrictions

- VSS mode does not support lawful intercept.
- If the network administrator expects lawful intercept to be deployed at a node, do not configure optimized ACL logging (OAL), VLAN access control list (VACL) capture, or Intrusion Detection System (IDS) at the node. Deploying lawful intercept at the node causes unpredictable behavior in OAL, VACL capture, and IDS.
- To maintain switch performance, lawful intercept is limited to no more than 0.2% of active calls. For example, if the switch is handling 4000 calls, 8 of those calls can be intercepted.
- The CISCO-IP-TAP-MIB does not support the virtual routing and forwarding (VRF) OID `citapStreamVRF`.
- Captured traffic is rate limited to protect the CPU usage at the route processor. The rate limit is 8500 pps.
- The interface index is used during provisioning to select the index to enable lawful intercept on only; when set to 0, lawful intercept is applied to all interfaces.
- (Optional) The domain name for both the switch and the mediation device may be registered in the Domain Name System (DNS).
- The mediation device must have an access function (AF).
- You must add the mediation device to the SNMP user group that has access to the CISCO-TAP2-MIB view. Specify the username of the mediation device as the user to add to the group.

When you add the mediation device as a CISCO-TAP2-MIB user, you must include the mediation device's authorization password. The password must be at least eight characters in length.

- Dedicate an interface for lawful intercept processing. For example, you should not configure the interface to perform processor-intensive tasks such as QoS or routing.
- Supported for IPv4 unicast traffic only. In addition, for traffic to be intercepted, the traffic must be IPv4 on both the ingress and egress interfaces. For example, lawful intercept cannot intercept traffic if the egress side is MPLS and the ingress side is IPv4.
- IPv4 multicast, IPv6 unicast, and IPv6 multicast flows are not supported.
- Not supported on Layer 2 interfaces. However, lawful intercept can intercept traffic on VLANs that run over the Layer 2 interface.
- Not supported for packets that are encapsulated within other packets (for example, tunneled packets or Q-in-Q packets).
- Not supported for Q-in-Q packets. There is no support for Layer 2 taps for lawful intercept.
- Not supported for packets that are subject to Layer 3 or Layer 4 rewrite (for example, Network Address Translation [NAT] or TCP reflexive).
- In the ingress direction, the switch intercepts and replicates packets even if the packets are later dropped (for example, due to rate limiting or an access control list [ACL] **deny** statement). In the egress direction, packets are not replicated if they are dropped (for example, by ACL).
- Lawful intercept ACLs are applied internally to both the ingress and the egress directions of an interface.
- To intercept traffic from a specific user, a typical configuration consists of two flows, one for each direction.
- Packets that are subject to hardware rate limiting are processed by lawful intercept as follows:

- Packets that are dropped by the rate limiter are not intercepted or processed.
 - Packets that are passed by the rate limiter are intercepted and processed.
- If multiple LEAs are using a single mediation device and each is executing a wiretap on the same target, the switch sends a single packet to the mediation device. It is up to the mediation device to duplicate the packet for each LEA.
- Lawful intercept can intercept IPv4 packets with values that match a combination of one or more of the following fields:
 - Destination IP address and mask
 - Destination port range
 - Source IP address and mask
 - Source port range
 - Protocol ID

MIB Guidelines

The following Cisco MIBs are used for lawful intercept processing. Include these MIBs in the SNMP view of lawful intercept MIBs to enable the mediation device to configure and execute wiretaps on traffic that flows through the switch.

- CISCO-TAP2-MIB—Required for both types of lawful intercepts: regular and broadband.
- CISCO-IP-TAP-MIB—Required for wiretaps on Layer 3 (IPv4) streams. Supported for regular and broadband lawful intercept.
- The CISCO-IP-TAB-MIB imposes limitations on the following features:
 - If one or all of the following features are configured and functioning and lawful intercept is enabled, lawful intercept takes precedence, and the feature behaves as follows:
 - Optimized ACL logging (OAL)—Does not function.
 - VLAN access control list (VACL) capturing—Does not function properly.
 - Intrusion detection system (IDS)—Does not function properly.
 - The feature starts to function after you disable or unconfigure lawful intercept.
 - IDS cannot capture traffic on its own, but captures traffic that has been intercepted by lawful intercept only.

Information About Lawful Intercept

- [Lawful Intercept Overview, page 86-4](#)
- [Benefits of Lawful Intercept, page 86-4](#)
- [CALEA for Voice, page 86-5](#)
- [Network Components Used for Lawful Intercept, page 86-5](#)
- [Lawful Intercept Processing, page 86-7](#)
- [Lawful Intercept MIBs, page 86-7](#)

**Caution**

This guide does not address legal obligations for the implementation of lawful intercept. As a service provider, you are responsible to ensure that your network complies with applicable lawful intercept statutes and regulations. We recommend that you seek legal advice to determine your obligations.

Lawful Intercept Overview

Lawful intercept is a process that enables a Law Enforcement Agency (LEA) to perform electronic surveillance on an individual (a target) as authorized by a judicial or administrative order. To facilitate the lawful intercept process, certain legislation and regulations require service providers (SPs) and Internet service providers (ISPs) to implement their networks to explicitly support authorized electronic surveillance.

The surveillance is performed through the use of wiretaps on traditional telecommunications and Internet services in voice, data, and multiservice networks. The LEA delivers a request for a wiretap to the target's service provider, who is responsible for intercepting data communication to and from the individual. The service provider uses the target's IP address to determine which of its edge switches handles the target's traffic (data communication). The service provider then intercepts the target's traffic as it passes through the switch, and sends a copy of the intercepted traffic to the LEA without the target's knowledge.

The Lawful Intercept feature supports the Communications Assistance for Law Enforcement Act (CALEA), which describes how service providers in the United States must support lawful intercept. Currently, lawful intercept is defined by the following standards:

- Telephone Industry Association (TIA) specification J-STD-025
- Packet Cable Electronic Surveillance Specification (PKT-SP-ESP-101-991229)

For information about the Cisco lawful intercept solution, contact your Cisco account representative.

**Note**

The Lawful Intercept feature supports the interception of IPv4 protocol as defined by the object `citapStreamprotocol` in the `CISCO-IP-TAB-MIB` that includes voice and data interception.

Benefits of Lawful Intercept

- Allows multiple LEAs to run a lawful intercept on the same target without each other's knowledge.
- Does not affect subscriber services on the switch.
- Supports wiretaps in both the input and output direction.
- Supports wiretaps of Layer 1 and Layer 3 traffic. Layer 2 traffic is supported as IP traffic over VLANs.
- Supports wiretaps of individual subscribers that share a single physical interface.
- Cannot be detected by the target. Neither the network administrator nor the calling parties is aware that packets are being copied or that the call is being tapped.
- Uses Simple Network Management Protocol Version 3 (SNMPv3) and security features such as the View-based Access Control Model (SNMP-VACM-MIB) and User-based Security Model (SNMP-USM-MIB) to restrict access to lawful intercept information and components.

- Hides information about lawful intercepts from all but the most privileged users. An administrator must set up access rights to enable privileged users to access lawful intercept information.
- Provides two secure interfaces for performing an intercept: one for setting up the wiretap and one for sending the intercepted traffic to the LEA.

CALEA for Voice

The Communications Assistance for Law Enforcement Act (CALEA) for Voice feature allows the lawful interception of voice conversations that are running on Voice over IP (VoIP). Although the switches are not voice gateway devices, VoIP packets traverse the switches at the edge of the service provider network.


When an approved government agency determines that a telephone conversation is interesting, CALEA for Voice copies the IP packets comprising the conversation and sends the duplicate packets to the appropriate monitoring device for further analysis.

Network Components Used for Lawful Intercept

- [Mediation Device](#)
- [Lawful Intercept Administration](#)
- [Intercept Access Point](#)
- [Content Intercept Access Point](#)

For information about lawful intercept processing, see the “[Lawful Intercept Processing](#)” section on [page 86-7](#).

Figure 86-1 *Lawful Intercept Overview*



Mediation Device

A mediation device (supplied by a third-party vendor) handles most of the processing for the lawful intercept. The mediation device:

- Provides the interface used to set up and provision the lawful intercept.
- Generates requests to other network devices to set up and run the lawful intercept.
- Converts the intercepted traffic into the format required by the LEA (which can vary from country to country) and sends a copy of the intercepted traffic to the LEA without the target's knowledge.



Note If multiple LEAs are performing intercepts on the same target, the mediation device must make a copy of the intercepted traffic for each LEA. The mediation device is also responsible for restarting any lawful intercepts that are disrupted due to a failure.

Lawful Intercept Administration

Lawful intercept administration (LIA) provides the authentication interface for lawful intercept or wiretap requests and administration.

Intercept Access Point

An intercept access point (IAP) is a device that provides information for the lawful intercept. There are two types of IAPs:

- Identification (ID) IAP—A device, such as an authentication, authorization, and accounting (AAA) server, that provides intercept-related information (IRI) for the intercept (for example, the target's username and system IP address) or call agents for voice over IP. The IRI helps the service provider determine which content IAP (switch) the target's traffic passes through.
- Content IAP—A device, such as the switch, that the target's traffic passes through. The content IAP:
 - Intercepts traffic to and from the target for the length of time specified in the court order. The switch continues to forward traffic to its destination to ensure that the wiretap is undetected.
 - Creates a copy of the intercepted traffic, encapsulates it in User Datagram Protocol (UDP) packets, and forwards the packets to the mediation device without the target's knowledge. IP option header is not supported.



Note The content IAP sends a single copy of intercepted traffic to the mediation device. If multiple LEAs are performing intercepts on the same target, the mediation device must make a copy of the intercepted traffic for each LEA.

Content Intercept Access Point

Content IAP intercepts the interested data stream, duplicates the content, and sends the duplicated content to the mediation device. The mediation device receives the data from the ID IAP and Content IAP, converts the information to the required format depending on country specific requirement and forwards it to law enforcement agency (LEA).

Lawful Intercept Processing

After acquiring a court order or warrant to perform surveillance, the LEA delivers a surveillance request to the target's service provider. Service provider personnel use an administration function that runs on the mediation device to configure a lawful intercept to monitor the target's electronic traffic for a specific period of time (as defined in the court order).

After the intercept is configured, user intervention is no longer required. The administration function communicates with other network devices to set up and execute the lawful intercept. The following sequence of events occurs during a lawful intercept:

1. The administration function contacts the ID IAP for intercept-related information (IRI), such as the target's username and the IP address of the system, to determine which content IAP (switch) the target's traffic passes through.
2. After identifying the switch that handles the target's traffic, the administration function sends SNMPv3 **get** and **set** requests to the switch's Management Information Base (MIB) to set up and activate the lawful intercept. The CISCO-TAP2-MIB is the supported lawful intercept MIB to provide per-subscriber intercepts.
3. During the lawful intercept, the switch:
 - a. Examines incoming and outgoing traffic and intercepts any traffic that matches the specifications of the lawful intercept request.
 - b. Creates a copy of the intercepted traffic and forwards the original traffic to its destination so the target does not suspect anything.
 - c. Encapsulates the intercepted traffic in UDP packets and forwards the packets to the mediation device without the target's knowledge.



Note The process of intercepting and duplicating the target's traffic adds no detectable latency in the traffic stream.

4. The mediation device converts the intercepted traffic into the required format and sends it to a collection function running at the LEA. Here, the intercepted traffic is stored and processed.



Note If the switch intercepts traffic that is not allowed by the judicial order, the mediation device filters out the excess traffic and sends the LEA only the traffic allowed by the judicial order.

5. When the lawful intercept expires, the switch stops intercepting the target's traffic.

Lawful Intercept MIBs

- [CISCO-TAP2-MIB](#)—Used for lawful intercept processing.
- [CISCO-IP-TAP-MIB](#)—Used for intercepting Layer 3 (IPv4) traffic.

CISCO-TAP2-MIB

The CISCO-TAP2-MIB contains SNMP management objects that control lawful intercepts. The mediation device uses the MIB to configure and run lawful intercepts on targets whose traffic passes through the switch.

The CISCO-TAP2-MIB contains several tables that provide information for lawful intercepts that are running on the switch:

- **cTap2MediationTable**—Contains information about each mediation device that is currently running a lawful intercept on the switch. Each table entry provides information that the switch uses to communicate with the mediation device (for example, the device's address, the interfaces to send intercepted traffic over, and the protocol to use to transmit the intercepted traffic).
- **cTap2StreamTable**—Contains information used to identify the traffic to intercept. Each table entry contains a pointer to a filter that is used to identify the traffic stream associated with the target of a lawful intercept. Traffic that matches the filter is intercepted, copied, and sent to the corresponding mediation device application (cTap2MediationContentId).

The cTap2StreamTable table also contains counts of the number of packets that were intercepted, and counts of dropped packets that should have been intercepted, but were not.

- **cTap2DebugTable**—Contains debug information for troubleshooting lawful intercept errors.

The CISCO-TAP2-MIB also contains several SNMP notifications for lawful intercept events. For detailed descriptions of MIB objects, see the MIB itself.

CISCO-TAP2-MIB Processing

The administration function (running on the mediation device) issues SNMPv3 **set** and **get** requests to the switch's CISCO-TAP2-MIB to set up and initiate a lawful intercept. To do this, the administration function performs the following actions:

1. Creates a cTap2MediationTable entry to define how the switch is to communicate with the mediation device executing the intercept.



Note The cTap2MediationNewIndex object provides a unique index for the mediation table entry.

2. Creates an entry in the cTap2StreamTable to identify the traffic stream to intercept.
3. Sets cTap2StreamInterceptEnable to true(1) to start the intercept. The switch intercepts traffic in the stream until the intercept expires (cTap2MediationTimeout).

CISCO-IP-TAP-MIB

The CISCO-IP-TAP-MIB contains the SNMP management objects to configure and execute lawful intercepts on IPv4 traffic streams that flow through the switch. This MIB is an extension to the CISCO-TAP2-MIB.

You can use the CISCO-IP-TAP-MIB to configure lawful intercept on the switch to intercept IPv4 packets with values that match a combination of one or more of the following fields:

- Destination IP address and mask
- Destination port range
- Source IP address and mask
- Source port range
- Protocol ID

CISCO-IP-TAP-MIB Processing

When data is intercepted, two streams are created. One stream is for packets that originate from the target IP address to any other IP address using any port. The second stream is created for packets that are routed to the target IP address from any other address using any port. For VoIP, two streams are created, one for RTP packets from target and the second stream is for the RTP packets to target using the specific source and destination IP addresses and ports specified in SDP information used to setup RTP stream.

How to Configure Lawful Intercept Support

- [Security Considerations, page 86-9](#)
- [Accessing the Lawful Intercept MIBs, page 86-9](#)
- [Configuring SNMPv3, page 86-10](#)
- [Creating a Restricted SNMP View of Lawful Intercept MIBs, page 86-10](#)
- [Enabling SNMP Notifications for Lawful Intercept, page 86-12](#)

Security Considerations

- SNMP notifications for lawful intercept must be sent to UDP port 161 on the mediation device, not port 162 (which is the SNMP default). See the [“Enabling SNMP Notifications for Lawful Intercept” section on page 86-12](#) for instructions.
- The only users who should be allowed to access the lawful intercept MIBs are the mediation device and system administrators who need to know about lawful intercepts on the switch. In addition, these users must have authPriv or authNoPriv access rights to access the lawful intercept MIBs. Users with NoAuthNoPriv access cannot access the lawful intercept MIBs.
- You cannot use the SNMP-VACM-MIB to create a view that includes the lawful intercept MIBs.
- The default SNMP view excludes the following MIBs:
 - CISCO-TAP2-MIB
 - CISCO-IP-TAP-MIB
 - SNMP-COMMUNITY-MIB
 - SNMP-USM-MIB
 - SNMP-VACM-MIB

Also see the [“Restrictions for Lawful Intercept” section on page 86-1](#) and the [“Prerequisites for Lawful Intercept” section on page 86-1](#).

Accessing the Lawful Intercept MIBs

Due to its sensitive nature, the Cisco lawful intercept MIBs are only available in software images that support the lawful intercept feature. These MIBs are not accessible through the Network Management Software MIBs Support page (<http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>).

Restricting Access to the Lawful Intercept MIBs

Only the mediation device and users who need to know about lawful intercepts should be allowed to access the lawful intercept MIBs. To restrict access to these MIBs, you must:

1. Create a view that includes the Cisco lawful intercept MIBs.
2. Create an SNMP user group that has read-and-write access to the view. Only users assigned to this user group can access information in the MIBs.
3. Add users to the Cisco lawful intercept user groups to define who can access the MIBs and any information related to lawful intercepts. Be sure to add the mediation device as a user in this group; otherwise, the switch cannot perform lawful intercepts.



Note

Access to the Cisco lawful intercept MIB view should be restricted to the mediation device and to system administrators who need to be aware of lawful intercepts on the switch. To access the MIB, users must have level-15 access rights on the switch.

Configuring SNMPv3

To perform the following procedures, SNMPv3 must be configured on the switch. See this publication:

<http://www.cisco.com/en/US/docs/ios-xml/ios/snmp/configuration/15-sy/snmp-15-sy-book.html>

Creating a Restricted SNMP View of Lawful Intercept MIBs

To create and assign users to an SNMP view that includes the Cisco lawful intercept MIBs, perform the following procedure at the CLI, in global configuration mode with level-15 access rights. For command examples, see the “Configuration Example” section on page 86-11.



Note

The command syntax in the following steps includes only those keywords required to perform each task. For details on command syntax, see the documents listed in the previous section (“Configuring SNMPv3”).

- Step 1** Make sure that SNMPv3 is configured on the switch. For instructions, see the documents listed in the “Configuring SNMPv3” section on page 86-10.
- Step 2** Create an SNMP view that includes the CISCO-TAP2-MIB (where *view_name* is the name of the view to create for the MIB). This MIB is required for both regular and broadband lawful intercept.

```
Tqwvgt*eqphki+% "upor/ugtxgt"xkgy"xkgyapcog"ekueqVcr4OKD"kpenwfgf"
```
- Step 3** Add one or both of the following MIBs to the SNMP view to configure support for wiretaps on IPv4 streams (where *view_name* is the name of the view you created in Step 2).

```
Tqwvgt*eqphki+% "upor/ugtxgt"xkgy"xkgyapcog"ekueqKrVcrOKD"kpenwfgf"
```
- Step 4** Create an SNMP user group (*groupname*) that has access to the lawful intercept MIB view and define the group's access rights to the view.

```
Tqwvgt*eqphki+% "upor/ugtxgt"itqwr"itqwrpcog"x5"pqcwvj"tgcf view_name ytkvg view_name
```

- Step 5** Add users to the user group you just created (where *username* is the user, *groupname* is the user group, and *auth_password* is the authentication password):

```
Tqwwgt*eqphki+% "upor/ugtxgt"wugt "wugtpcog" itqwrpcog"x5"cwvj"of7" cwvjarcuuyqtf"
```



Note Be sure to add the mediation device to the SNMP user group; otherwise, the switch cannot perform lawful intercepts. Access to the lawful intercept MIB view should be restricted to the mediation device and to system administrators who need to know about lawful intercepts on the switch.

The mediation device is now able to access the lawful intercept MIBs, and issue SNMP **set** and **get** requests to configure and run lawful intercepts on the switch.

For instructions on how to configure the switch to send SNMP notifications to the mediation device, see the [“Enabling SNMP Notifications for Lawful Intercept”](#) section on page 86-12.

Configuration Example

The following commands show an example of how to enable the mediation device to access the lawful intercept MIBs.

```
Tqwwgt*eqphki+% "upor/ugtxgt"xkgy"vcrX"ekueqVcr4OKD"kpenwfgf "
Tqwwgt*eqphki+% "upor/ugtxgt"xkgy"vcrX"ekueqKrVcrOKD"kpenwfgf "
```

1. Create a view (tapV) that includes the appropriate lawful intercept MIBs (CISCO-TAP2-MIB and the CISCO-IP-TAP-MIB).
2. Create a user group (tapGrp) that has read, write, and notify access to MIBs in the tapV view.
3. Add the mediation device (ss8user) to the user group, and specify MD5 authentication with a password (ss8passwd).
4. (Optional) Assign a 24-character SNMP engine ID (for example, 123400000000000000000000) to the switch for administration purposes. If you do not specify an engine ID, one is automatically generated. Note that you can omit the trailing zeros from the engine ID, as shown in the last line of the example above.



Note Changing an engine ID has consequences for SNMP user passwords and community strings.

Enabling SNMP Notifications for Lawful Intercept

SNMP automatically generates notifications for lawful intercept events (see Table 86-1). This is because the default value of the `cTap2MediationNotificationEnable` object is `true(1)`.

To configure the switch to send lawful intercept notifications to the mediation device, issue the following CLI commands in global-configuration mode with level-15 access rights (where *MD-ip-address* is the IP address of the mediation device and *community-string* is the password-like community string to send with the notification request):

```
Tqvwgt*eqphki+%"upor/ugtxgt"jquv"MD-ip-address"community-string"wfr/rqtv"383"upor"
Tqvwgt*eqphki+%"upor/ugtxgt"gpcdng"vtcru"upor"cwvjgvpvkecvkqp"nkpmwr"nkpmfqyp"eqnfuvctv"
yctouvctv"
```

- For lawful intercept, **udp-port** must be 161 and not 162 (the SNMP default).
- The second command configures the switch to send RFC 1157 notifications to the mediation device. These notifications indicate authentication failures, link status (up or down), and system restarts.

Table 86-1 *SNMP Notifications for Lawful Intercept Events*

Notification	Meaning
cTap2MIBActive	The switch is ready to intercept packets for a traffic stream configured in the CISCO-TAP2-MIB.
cTap2MediationTimedOut	A lawful intercept was terminated (for example, because cTap2MediationTimeout expired).
cTap2MediationDebug	Intervention is required for events related to cTap2MediationTable entries.
cTap2StreamDebug	Intervention is required for events related to cTap2StreamTable entries.

Disabling SNMP Notifications

You can disable SNMP notifications by entering the **no snmp-server enable traps** command.

To disable lawful intercept notifications, use SNMPv3 to set the CISCO-TAP2-MIB object `cTap2MediationNotificationEnable` to `false(2)`. To reenable lawful intercept notifications through SNMPv3, reset the object to `true(1)`.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Online Diagnostic Tests

- [Global Health-Monitoring Tests, page 1-2](#)
- [Per-Port Tests, page 1-8](#)
- [PFC Layer 2 Tests, page 1-15](#)
- [DFC Layer 2 Tests, page 1-17](#)
- [PFC Layer 3 Tests, page 1-22](#)
- [DFC Layer 3 Tests, page 1-28](#)
- [Replication Engine Tests, page 1-34](#)
- [Fabric Tests, page 1-35](#)
- [Exhaustive Memory Tests, page 1-39](#)
- [Service Module Tests, page 1-41](#)
- [Stress Tests, page 1-42](#)
- [General Tests, page 1-44](#)
- [Critical Recovery Tests, page 1-46](#)
- [ViSN Tests, page 1-47](#)



Note

- For information about configuring online diagnostic tests see [Chapter 16, “Online Diagnostics.”](#)
- Before you enable any online diagnostics tests, enable console logging to see all warning messages.
- We recommend that when you are running disruptive tests that you only run the tests when connected through console. When disruptive tests are complete a warning message on the console recommends that you reload the system to return to normal operation: strictly follow this warning.
- While tests are running, all ports are shut down as a stress test is being performed with looping ports internally and external traffic might affect the test results. The switch must be rebooted to bring the switch to normal operation. When you issue the command to reload the switch, the system will ask you if the configuration should be saved.
- Do not save the configuration.
- If you are running the tests on other modules, after the test is initiated and complete, you must reset the module.

**Tip**

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)

Global Health-Monitoring Tests

- [TestAsicSync, page 1-2](#)
- [TestEARLInternalTables, page 1-3](#)
- [TestErrorCounterMonitor, page 1-3](#)
- [TestFexModelLoopback, page 1-4](#)
- [TestIntPortLoopback, page 1-4](#)
- [TestL3TcamMonitoring, page 1-4](#)
- [TestLtlFpoeMemoryConsistency, page 1-5](#)
- [TestMacNotification, page 1-6](#)
- [TestPortTxMonitoring, page 1-6](#)
- [TestScratchRegister, page 1-7](#)
- [TestSnrMonitoring, page 1-7](#)
- [TestUnusedPortLoopback, page 1-8](#)

TestAsicSync

This test periodically verifies the status of bus and port synchronization ASICs.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	Reset the module. After the module has ten consecutive failures or three consecutive resets, it powers down.
Hardware support:	All modules.

TestEARLInternalTables

This test detects most PFC and DFC hardware table problems by running consistency checks on the PFC and DFC hardware tables. The test runs every 5 minutes.

A failure of the test for the PFC results in one of these actions:

- Failover to the redundant supervisor engine.
- If a redundant supervisor engine is not installed, shutdown of the supervisor engine.

A failure of the test for the DFC results in one of these actions:

- Up to two resets of the DFC-equipped switching module.
- Shutdown following a third failure.

A CallHome message is generated if CallHome is configured on the system.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	Reset the affected module.
Hardware support:	PFC and DFCs.

TestErrorCounterMonitor

This test monitors the errors and interrupts that occur on each module in the system by periodically polling for the error counters maintained in the module. If the errors exceed a threshold value, a syslog message is displayed with detailed information including the error-counter identifier, port number, total failures, consecutive failures, and the severity of the error counter.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable. This test is automatically disabled during CPU-usage spikes to maintain accuracy.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	Display a syslog message indicating the error-counters detected on that port.
Hardware support:	All modules including supervisor engines.

TestFexModeLoopback

This test verifies the data path between the inband port and ports that can support an IA client link. 802.1q packets are sent to the port being tested. After VNTag encapsulation and deencapsulation, the test packet is looped back on the test port to the inband port. This test skips ports with active IA parent-client links. The test typically disrupts traffic for less than one second.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	
Default:	Off. This test is run automatically on bootup. On-demand test also supported.
Initial Release:	15.1(2)SY
Corrective action:	Displays the “%CONST_DIAG-3-BOOTUP_TEST_FAIL: Module <i>number</i> : TesFexModeLoopback failed on port(s) <i>range</i> ” message.
Hardware support:	WS-X6904-40G-2T

TestIntPortLoopback

This test uses the switching module internal port to run a non-disruptive loopback test. It can be used to detect fabric channel failure and also port ASIC failure. This test is similar to TestFabricCh0Health. The test runs every 15 seconds.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not turn this test off. Use as a health-monitoring test.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	The module resets after 10 consecutive failures. Three consecutive resets powers down the module.
Hardware support:	WS-X6148E-GE-45AT, WS-X6148A-GE-TX, WS-X6148A-GE-45AF, WS-X6148-FE-SFP, WS-X6148A-RJ-45, WS-X6148A-45AF.

TestL3TcamMonitoring

This test verifies Layer 3 packet switching and monitors the health of both FIB and CL TCAM using the diagnostic lookup key. This test is nondisruptive and runs periodically every 15 seconds. Ten consecutive failures are treated as fatal, which cause the module to reload during runtime.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	After the module has ten consecutive failures, the module reloads during runtime.
Hardware support:	Supervisor engines.

TestLtlFpoeMemoryConsistency

This test verifies that the LTL and FPOE memories are working properly. The test runs every 15 seconds. Self-correction is applied if an error is detected. If self-correction fails, corrective action is triggered to reset the module. The module is powered-down on the third consecutive module reset. If self-correction passes, no action is taken. If too many self-corrections occur within a short period of time (more than three self-corrections in less than 300 seconds), the module is reset.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	Failure of this test causes the module to reset and power down after two resets.
Hardware support:	All modules including supervisor engines.

TestMacNotification

This test verifies the data and control path between DFC-equipped modules and supervisor engines. This test also ensures Layer 2 MAC address consistency across Layer 2 MAC address tables. The test runs every six seconds. Ten consecutive failures causes the module to reset during bootup or runtime (default). After three consecutive resets, the module powers down. This test runs every 15 seconds.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	Reset the module. After the module has ten consecutive failures or three consecutive resets, it powers down.
Hardware support:	DFC-equipped modules.

TestPortTxMonitoring

This test periodically polls the transmit counters on each port. The test displays a syslog message and error disables the port if no activity is seen for the configured time interval and failure threshold. You configure the time interval and threshold by entering the **diagnostic monitor interval** and **diagnostic monitor threshold** commands. The test does not source any packets, but leverages the CDP protocol that transmits packets periodically. If the CDP protocol is disabled, the polling for that port is not performed. The test runs every 75 seconds, and the failure threshold is set to five by default.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	Display a syslog message indicating the port(s) that failed. Error disable the port(s) that failed.
Hardware support:	All modules including supervisor engines.

TestScratchRegister

This test monitors the health of application-specific integrated circuits (ASICs) by writing values into registers and reading back the values from these registers. The test runs every 30 seconds. Five consecutive failures causes a supervisor engine to switchover (or reset), if you are testing the supervisor engine, or in the module powering down when testing a module.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable.
Default:	On.
Intitial Release:	15.0(1)SY.
Corrective action:	Reset the malfunctioning supervisor engine or power down the module.
Hardware support:	Active and standby supervisor engine, DFC-equipped modules, WS-X6148A-GE-TX, WS-X6148A-GE-45AF, WS-X6148-FE-SFP, WS-X6148A-RJ-45, WS-X6148A-45AF.

TestSnrMonitoring

This test monitors the SNR (signal-to-noise ratio) margin for a port, which varies between -12.7 dB to +12.7 dB. The test uses the following two threshold levels to compare SNR:

- Minor threshold at +1.0 dB
- Major threshold at 0.0 dB

When the SNR value drops below the minor threshold, the test logs a minor warning message. When the SNR value drops below the major threshold, the test logs a major warning message. Similarly, recovery messages are logged when SNR recovers the two threshold levels. The default interval for the test is 30 seconds and can be configured to as low as 10 seconds for faster monitoring. The TestSnrMonitoring is not a bootup test and cannot be run on demand.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable.
Default:	On.
Intitial Release:	15.0(1)SY.
Corrective action:	None.
Hardware support:	WS-X6816-10T-2T, WS-X6716-10T.

TestUnusedPortLoopback

This test periodically verifies the data path between the supervisor engine and the network ports of a module in the runtime. In this test, a Layer 2 packet is flooded onto the VLAN associated with the test port and the inband port of the supervisor engine. The packet loops back in the test port and returns to the supervisor engine on the same VLAN. This test is similar to TestLoopback but only runs on unused (admin down) network ports and on only one unused port per port ASIC. This test substitutes the lack of a nondisruptive loopback test in current ASICs. This test runs every 60 seconds.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable. This test is automatically disabled during CPU-usage spikes to maintain accuracy.
Default:	On.
Initial Release:	
Corrective action:	Display a syslog message indicating the port(s) that failed. For modules other than the supervisor engines, if all port groups fail (for example, at least one port per port ASIC fails more than the failure threshold for all port ASICs), the default action is to reset the module and power down the module after two resets.
Hardware support:	All modules including the supervisor engines.

Per-Port Tests

- [TestActiveToStandbyLoopback](#), page 1-9
- [TestCCPLoopback](#), page 1-9
- [TestDataPortLoopback](#), page 1-10
- [TestDCPLoopback](#), page 1-10
- [TestL2CTSLoopback](#), page 1-11
- [TestL3CTSLoopback](#), page 1-11
- [TestLoopback](#), page 1-12
- [TestMediaLoopback](#), page 1-12
- [TestMgmtPortsLoopback](#), page 1-13
- [TestNetflowInlineRewrite](#), page 1-13
- [TestNonDisruptiveLoopback](#), page 1-14
- [TestNPLoopback](#), page 1-14
- [TestTransceiverIntegrity](#), page 1-15

TestActiveToStandbyLoopback

This test verifies the data path between the active supervisor engine and the network ports of the standby supervisor engine. In this test, a Layer 2 packet is flooded onto a VLAN that consists of only the test port and the active supervisor engine's inband port. The test packets are looped back in the targeted port and are flooded back onto the bus with only the active supervisor engine's inband port listening in on the flooded VLAN.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the loopback port (for example, Spanning Tree Protocol).
Recommendation:	Schedule during downtime.
Default:	Runs at bootup or after OIR.
Initial Release:	15.0(1)SY.
Corrective action:	Error disable a port if the loopback test fails on the port. Reset the standby supervisor engine if all of the ports fail.
Hardware support:	Standby supervisor engine only.

TestCCPLoopback

This test checks the control plane data path. This test sends an online diagnostics packet from the supervisor engine to service or high availability port on the Wireless Services Module (WiSM2). The TestCCPLoopback checks whether the test packet loops back. If the test fails, a syslog message is displayed to indicate the error. This test also can be run as health monitoring, on-demand, and scheduled tests.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable.
Default:	On.
Initial Release:	15.0(1)SY1.
Corrective action:	A syslog message is displayed after five consecutive failures.
Hardware support:	WS-SVC-WISM2-K9.

TestDataPortLoopback

This test sends a packet from the inband port of the supervisor to the data port on the Firewall or NAM service module to verify the data packet path. The packet is looped back to the supervisor in hardware. If the packet does not return from the supervisor, hardware counters are polled to isolate the faulty path. This test runs every 45 seconds.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable. If the test fails for 10 consecutive times, the module is reset. If the test fails persistently, the module is powered down.
Default:	On.
Initial Release:	15.0(1)SY1.
Corrective action:	None.
Hardware support:	WS-SVC-ASA-SM1-K9 and WS-SVC-NAM3-6G-K9.

TestDCPLoopback

This test checks the data plane data path. This test sends an online diagnostics packet from the supervisor engine to data ports on the Wireless Services Module (WiSM2). This test checks whether the test packet loops back. If the test fails, a syslog message is displayed to indicate the error. This test also can be run as health monitoring, on-demand, and scheduled tests.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable.
Default:	On.
Initial Release:	15.0(1)SY1.
Corrective action:	A syslog message is displayed after five consecutive failures.
Hardware support:	WS-SVC-WISM2-K9.

TestL2CTSLoopback

This test provides encapsulation for Layer 2 Ethernet packets sent from the supervisor engine inband port to each port inside the Ganita ASIC. The test sends back the Layer 2 Ethernet packet to the supervisor engine inband port after decapsulation with its original content.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	This test is run automatically on bootup. On-demand test also supported.
Default:	Off. This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines.

TestL3CTSLoopback

This test provides encapsulation for Layer 3 IPv4 packets sent from the supervisor engine inband port to each port inside the Ganita ASIC and sends back the Layer 3 IPv4 packet to the supervisor engine inband port after decapsulation with its original content.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	This test is run automatically on bootup. On-demand test also supported.
Default:	Off. This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines.

TestLoopback

This test verifies the data path between the supervisor engine and the network ports of a module. In this test, a Layer 2 packet is flooded onto a VLAN that consists of only the test port and the supervisor engine's inband port. The packet loops back in the port and returns to the supervisor engine on that same VLAN.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of looped-back port (for example, Spanning Tree Protocol).
Recommendation:	Schedule during downtime.
Default:	Runs at bootup or after online insertion and removal (OIR).
Initial Release:	15.0(1)SY.
Corrective action:	Error disable a port if the loopback test fails on the port. Reset the module if all of the ports fail.
Hardware support:	All modules including supervisor engines.

TestMediaLoopback

This test verifies the data path of MediaNet-like traffic. Index direct UDP packets are sent out to the MediaNet interface under test. The packets are looped back and forwarded to the inband port of the module.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	Do not disable.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	WS-X6816-10T-2T, WS-X6716-10T, WS-X6816-10G-2T, WS-X6716-10GE, WS-X6848-SFP-2T, WS-X6748-SFP, WS-X6824-SFP-2T, WS-X6724-SFP, WS-X6848-TX-2T, WS-X6748-GE-TX.

TestMgmtPortsLoopback

This test sends a packet from the inband port of the supervisor to the Firewall or NAM service module to verify the health of the backplane ports. The packet is looped back to the supervisor in hardware. If the packet does not return from the supervisor, the service application is queried for the status of the packet and depending on the action suggested by the service module, a syslog message is displayed and the module is reset. This test runs every 30 seconds.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable. If the failure is isolated to the firewall module, then a syslog is printed indicating which port failed the test. If the test fails due to any other datapath issue for 10 consecutive times, the module is reset. If the test fails persistently, the module is powered down.
Default:	On.
Initial Release:	15.0(1)SY1.
Corrective action:	None.
Hardware support:	WS-SVC-ASA-SM1-K9 and WS-SVC-NAM3-6G-K9.

TestNetflowInlineRewrite

This test verifies the NetFlow lookup operation, the ACL permit and deny functionality, and the inline rewrite capabilities of the port ASIC. The test packet will undergo a NetFlow table lookup to obtain the rewrite information. The VLAN and the source and destination MAC addresses are rewritten when the packet reaches the targeted port.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on configuration of loopback port (for example, Spanning Tree Protocol).
Recommendation:	Schedule during downtime. Run this test during bootup only.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	All modules including supervisor engines.

TestNonDisruptiveLoopback

This test verifies the data path between the supervisor engine and the network ports of a module. In this test, a Layer 2 packet is flooded onto VLAN that contains a group of test ports. The test port group consists of one port per port ASIC channel. Each port in the test port group nondisruptively loops back the packet and directs it back to the supervisor engine's inband port. The ports in the test port group are tested in parallel.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	Error disable a port after 10 consecutive failures. Error disable a channel if all of its ports failed the test in one test cycle. Reset the module after a failure of all channels.
Hardware support:	WS-X6148-FE-SFP, WS-X6148A-GE-TX, WS-X6148A-RJ-45.

TestNPLoopback

This test checks the data path of the ACE30 module for data path errors. This test runs at bootup, and the default configuration is a health-monitoring test that runs every 15 seconds. If TestNPLoopback fails, an SCP (Switch-module Configuration Protocol) message is sent to the ACE30 module indicating which network processors have failed. Upon receipt of the SCP message, ACE30 will take corrective action. If the TestNPLoopback test fails for ten consecutive times, the ACE30 module is reset.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable.
Default:	On.
Initial Release:	15.0(1)SY1.
Corrective action:	A syslog message is displayed to inform the ACE30 about the port(s) that failed the test on the failure code. Depending on the failure code, the ACE30 decides whether to take corrective action or not. The suggested action for ACE30 is to collect core dumps from all network processors and reset the ACE30 module.
Hardware support:	ACE30-MOD-K9.

TestTransceiverIntegrity

This security test is performed on the transceiver during transceiver online insertion and removal (OIR) or module bootup to make sure that the transceiver is supported.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Not applicable.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	Error disable the port.
Hardware support:	All modules with transceivers.

PFC Layer 2 Tests

- [TestBadBpduTrap](#), page 1-15
- [TestDontConditionalLearn](#), page 1-16
- [TestMatchCapture](#), page 1-16
- [TestNewIndexLearn](#), page 1-17

TestBadBpduTrap

This test is a combination of the TestTrap and the TestBadBpdu tests, which are described in the “[DFC Layer 2 Tests](#)” section on page 1-17.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	If you experience problems with the Layer 2 forwarding engine learning capability, run this test on-demand to verify the Layer 2 learning functionality. This test can also be used as a health-monitoring test.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines only.

TestDontConditionalLearn

This test is a combination of the TestDontLearn and the TestConditionalLearn tests, which are described in the [“DFC Layer 2 Tests” section on page 1-17](#).

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	If you experience problems with the Layer 2 forwarding engine learning capability, run this test on-demand to verify the Layer 2 learning functionality. This test can also be used as a health monitoring test.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	DFC-equipped modules.

TestMatchCapture

This test is a combination of the TestProtocolMatchChannel and the TestCapture tests, which are described in the [“DFC Layer 2 Tests” section on page 1-17](#).

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Run this test on-demand to verify the Layer 2 learning functionality. This test can also be used as a health-monitoring test.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines only.

TestNewIndexLearn

This test is a combination of the TestNewLearn and the TestIndexLearn tests, which are described in the “DFC Layer 2 Tests” [section on page 1-17](#).

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	If you experience problems with the Layer 2 forwarding engine learning capability, run this test on-demand to verify the Layer 2 learning functionality. This test can also be used as a health-monitoring test.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines only.

DFC Layer 2 Tests

- [TestBadBpdu, page 1-18](#)
- [TestCapture, page 1-18](#)
- [TestConditionalLearn, page 1-19](#)
- [TestDontLearn, page 1-19](#)
- [TestIndexLearn, page 1-20](#)
- [TestNewLearn, page 1-20](#)
- [TestPortSecurity, page 1-21](#)
- [TestProtocolMatchChannel, page 1-21](#)
- [TestStaticEntry, page 1-22](#)
- [TestTrap, page 1-22](#)

TestBadBpdu

This test verifies the ability to trap or redirect packets to the switch processor. This test verifies that the Trap feature of the Layer 2 forwarding engine is working properly. When running the test on the supervisor engine, the diagnostic packet is sent from the supervisor engine's inband port and performs a packet lookup using the supervisor engine's Layer 2 forwarding engine. For DFC-equipped modules, the diagnostic packet is sent from the supervisor engine's inband port through the switch fabric and looped back from one of the DFC ports. The BPDU feature is verified during the diagnostic packet lookup by the Layer 2 forwarding engine.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	This test runs by default during bootup or after a reset or OIR.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	DFC-equipped modules.

TestCapture

This test verifies that the capture feature of Layer 2 forwarding engine is working properly. The capture functionality is used for multicast replication. When running the test on the supervisor engine, the diagnostic packet is sent from the supervisor engine's inband port and performs a packet lookup using the supervisor engine's Layer 2 forwarding engine. For DFC-equipped modules, the diagnostic packet is sent from the supervisor engine's inband port through the switch fabric and looped back from one of the DFC ports. The Capture feature is verified during the diagnostic packet lookup by the Layer 2 forwarding engine.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	Schedule during downtime.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	DFC-equipped modules.

TestConditionalLearn

This test verifies the ability to learn a Layer 2 source MAC address under specific conditions. When running the test on the supervisor engine, the diagnostic packet is sent from the supervisor engine's inband port and performs a packet lookup using the supervisor engine Layer 2 forwarding engine. For DFC-equipped modules, the diagnostic packet is sent from the supervisor engine's inband port through the switch fabric and looped back from one of the DFC ports. The Conditional Learn feature is verified during the diagnostic packet lookup by the Layer 2 forwarding engine.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	This test runs by default during bootup or after a reset or OIR.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	DFC-equipped modules.

TestDontLearn

This test verifies that new source MAC addresses are not populated in the MAC address table when they should not be learned. This test verifies that the "don't learn" feature of the Layer 2 forwarding engine is working properly. For DFC-equipped modules, the diagnostic packet is sent from the supervisor engine inband port through the switch fabric and looped back from one of the ports on the DFC-enabled module. The "don't learn" feature is verified during diagnostic packet lookup by the Layer 2 forwarding engine.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	Schedule during downtime.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	DFC-equipped modules.

TestIndexLearn

This test ensures that existing MAC address table entries can be updated. This test verifies the Index Learn feature of the Layer 2 forwarding engine is working properly. When running the test on the supervisor engine, the diagnostic packet is sent from the supervisor engine's inband port and performs a packet lookup using the supervisor engine Layer 2 forwarding engine. For DFC-equipped modules, the diagnostic packet is sent from the supervisor engine's inband port through the switch fabric and looped back from one of the DFC ports. The Index Learn feature is verified during the diagnostic packet lookup by the Layer 2 forwarding engine.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	This test runs by default during bootup or after a reset or OIR.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	DFC-equipped modules.

TestNewLearn

This test verifies the Layer 2 source MAC address learning functionality of the Layer 2 forwarding engine. For supervisor engines, a diagnostic packet is sent from the supervisor engine inband port to verify that the Layer 2 forwarding engine is learning the new source MAC address from the diagnostic packet. For DFC-equipped modules, a diagnostic packet is sent from the supervisor engine inband port through the switch fabric and looped backed from one of the ports on the DFC-enabled module. The Layer 2 learning functionality is verified during the diagnostic packet lookup by the Layer 2 forwarding engine.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	This test runs by default during bootup or after a reset or OIR.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	DFC-equipped modules.

TestPortSecurity

This test verifies the ability to redirect packets to the CPU if a secure MAC address is transmitting the packets from a different port. For the supervisor engine, a diagnostic packet is sent from the supervisor engine's inband port and the port security feature is verified during the diagnostic packet lookup by the Layer 2 forwarding engine. For DFC-equipped modules, a diagnostic packet is sent from the supervisor engine inband port through the fabric and is looped back in one of the ports on the DFC-equipped module. The port security feature is verified during the diagnostic packet lookup by the Layer 2 forwarding engine.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	None.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engine and DFC-equipped modules.

TestProtocolMatchChannel

This test verifies the ability to match specific Layer 2 protocols in the Layer 2 forwarding engine. When running the test on the supervisor engine, the diagnostic packet is sent from the supervisor engine's inband port and performs a packet lookup using the supervisor engine's Layer 2 forwarding engine. For DFC-equipped modules, the diagnostic packet is sent from the supervisor engine's inband port through the switch fabric and looped back from one of the DFC ports. The Match feature is verified during the diagnostic packet lookup by the Layer 2 forwarding engine.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	This test runs by default during bootup or after a reset or OIR.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	DFC-equipped modules.

TestStaticEntry

This test verifies the ability to populate static entries in the Layer 2 MAC address table. For DFC-equipped modules, the diagnostic packet is sent from the supervisor engine's inband port through the switch fabric and looped back from one of the DFC ports. The Static Entry feature is verified during the diagnostic packet lookup by the Layer 2 forwarding engine.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	This test runs by default during bootup or after a reset or OIR.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	DFC-equipped modules.

TestTrap

This test verifies the ability to trap or redirect packets to the switch processor. This test verifies that the Trap feature of the Layer 2 forwarding engine is working properly. When running the test on the supervisor engine, the diagnostic packet is sent from the supervisor engine's inband port and performs a packet lookup using the supervisor engine's Layer 2 forwarding engine. For DFC-equipped modules, the diagnostic packet is sent from the supervisor engine's inband port through the switch fabric and looped back from one of the DFC ports. The Trap feature is verified during the diagnostic packet lookup by the Layer 2 forwarding engine.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	This test runs by default during bootup or after a reset or OIR.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	DFC-equipped modules.

PFC Layer 3 Tests

- [TestAclDeny, page 1-23](#)
- [TestAclPermit, page 1-23](#)
- [TestAclRedirect, page 1-24](#)

- [TestDQUP](#), page 1-24
- [TestInbandEdit](#), page 1-25
- [TestIPv4FibShortcut](#), page 1-25
- [TestIPv6FibShortcut](#), page 1-26
- [TestL3Capture2](#), page 1-26
- [TestMPLSFibShortcut](#), page 1-27
- [TestNATFibShortcut](#), page 1-27
- [TestNetflowShortcut](#), page 1-28
- [TestRBAcl](#), page 1-28

TestAclDeny

This test verifies that the ACL deny feature of the Layer 2 and Layer 3 forwarding engine is working properly. The test uses different ACL deny scenarios such as input, output, Layer 2 redirect, Layer 3 redirect, and Layer 3 bridges to determine whether or not the ACL deny feature is working properly.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	Run this test on-demand.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	Automatic ASIC reset for recovery.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestAclPermit

This test verifies that the ACL permit functionality is working properly. An ACL entry permitting a specific diagnostics packet is installed in the ACL TCAM. The corresponding diagnostic packet is sent from the supervisor engine and looked up by the Layer 3 forwarding engine to make sure that it hits the ACL TCAM entry and gets permitted and forwarded appropriately.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	Run this test on-demand.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestAclRedirect

This test verifies the ACL redirect feature of the Layer 3 forwarding engine. This test verifies both ingress and egress Layer 3 redirect.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Run this test on-demand.
Default:	Off. This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestDQUP

This test verifies whether the DQUP and PUP packets can be generated when diagnostic packets hit QoS entry. This test receives the DQUP and PUP packets and ensures that the information in DQUP and PUP is correct.

Attributes	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	Run this test on-demand if you suspect that DQUP and PUP is not working properly.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestInbandEdit

This test verifies the InbandEdit packets of the Layer 3 forwarding engine. One diagnostic InbandEdit packet is sent to create one diagnostic NetFlow entry and an adjacency entry, and one diagnostic packet is sent to ensure that the InbandEdit packet is forwarded according to the rewritten MAC and VLAN.

Attributes	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	Test runs automatically on bootup. On-demand is also supported.
Default:	This test runs by default during bootup.
Intitial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestIPv4FibShortcut

This test does the following:

- Verifies whether the IPv4 FIB forwarding of the Layer 3 forwarding engine is working properly. One diagnostic IPv4 FIB and an adjacency entry are installed, and a diagnostic packet is sent to make sure that the diagnostic packet is forwarded according to rewritten MAC and VLAN information.
- Verifies whether the FIB TCAM and adjacency devices are functional. One FIB entry is installed on each FIB TCAM device. A diagnostic packet is sent to make sure that the diagnostic packet is switched by the FIB TCAM entry installed on the TCAM device. This is not an exhaustive TCAM device test; only one entry is installed on each TCAM device.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Run this test on-demand to verify the Layer 3 forwarding functionality if you experience problems with the routing capability. This test can also be used as a health-monitoring test.
Default:	This test runs by default during bootup or after a reset or OIR.
Intitial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestIPv6FibShortcut

This test verifies that the IPV6 FIB forwarding of the Layer 3 forwarding engine is working properly. One diagnostic IPV6 FIB and an adjacency entry is installed, and a diagnostic IPv6 packet is sent to make sure the diagnostic packet is forwarded according to rewritten MAC and VLAN information.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Run this test on-demand to verify the Layer 3 forwarding functionality if you experience problems with the routing capability. This test can also be used as a health-monitoring test.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestL3Capture2

This test verifies that the Layer 3 capture (capture 2) feature of the Layer 3 forwarding engine is working properly. This capture feature is used for ACL logging and VACL logging. One diagnostic FIB and an adjacency entry with a capture 2 bit set is installed, and a diagnostic packet is sent to make sure that the diagnostic packet is forwarded according to the capture bit information.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	This test can also be used as a health-monitoring test. Use as a health-monitoring test if you are using ACL or VACL logging.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestMPLSFibShortcut

This test does the following:

- Verifies that the MPLS forwarding of the Layer 3 forwarding engine is working properly. One diagnostic MPLS FIB and an adjacency entry is installed, and a diagnostic MPLS packet is sent to make sure that the diagnostic packet is forwarded according to the MPLS label from the adjacency entry.
- Verifies the EoMPLS forwarding of the Layer 3 forwarding engine. One diagnostic EoMPLS Layer 2 FIB and an adjacency entry are installed and a diagnostic Layer 2 packet is sent to the forwarding engine to make sure it is forwarded accordingly with the MPLS labels and the encapsulated Layer 2 packet.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	This test can also be used as a health-monitoring test. Use as a health-monitoring test if you are routing MPLS traffic.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestNATFibShortcut

This test verifies the ability to rewrite a packet based on the NAT adjacency information (rewrite destination IP address). One diagnostic NAT FIB and an adjacency entry is installed, and the diagnostic packet is sent to make sure that the diagnostic packet is forwarded according to the rewritten IP address.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	This test can also be used as a health-monitoring test. Use as a health-monitoring test if the destination IP address is being rewritten (for example, if you are using NAT).
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestNetflowShortcut

This test verifies that the NetFlow forwarding functionality of the Layer 3 forwarding engine is working properly. One diagnostic NetFlow entry and an adjacency entry is installed, and a diagnostic packet is sent to make sure it is forwarded according to the rewritten MAC and VLAN information.

Attributes	Description
Disruptive or Nondisruptive:	Disruptive for looped back ports. The disruption is 500 ms.
Recommendation:	Run this test on-demand if you suspect that NetFlow is not working properly.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestRBACL

This test verifies the role based ACL (RBACL) feature of the Layer 3 forwarding engine. This test uses SGT and DGT instead of src_ip/dest_ip to get ACL lookup results.

Attributes	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Test runs automatically on bootup. On-demand and health-monitoring tests are also supported.
Default:	This test runs by default during bootup.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

DFC Layer 3 Tests

- [TestAclDeny](#), page 1-29
- [TestAclPermit](#), page 1-29
- [TestAclRedirect](#), page 1-30
- [TestInbandEdit](#), page 1-30
- [TestIPv4FibShortcut](#), page 1-31
- [TestIPv6FibShortcut](#), page 1-31
- [TestL3Capture2](#), page 1-32
- [TestMPLSFibShortcut](#), page 1-32

- [TestNATFibShortcut, page 1-33](#)
- [TestNetflowShortcut, page 1-33](#)
- [TestRBAcl, page 1-34](#)

TestAclDeny

This test verifies that the ACL deny feature of the Layer 2 and Layer 3 forwarding engine is working properly. The test uses different ACL deny scenarios such as input and output Layer 2 redirect, Layer 3 redirect, and Layer 3 bridges.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	Schedule during downtime if you are using ACLs.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestAclPermit

This test verifies that the ACL permit functionality is working properly. An ACL entry permitting a specific diagnostics packet is installed in the ACL TCAM. The corresponding diagnostic packet is sent from the supervisor engine and is looked up by the Layer 3 forwarding engine to make sure it hits the ACL TCAM entry and gets permitted and forwarded correctly.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	This test runs by default during bootup or after a reset or OIR.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestAclRedirect

This test verifies the ACL redirect feature of the Layer 3 forwarding engine. This test verifies both ingress and egress Layer 3 redirect.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Run this test on-demand.
Default:	Off. This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	DFC-equipped modules.

TestInbandEdit

This test verifies the InbandEdit packets of the Layer 3 forwarding engine. One diagnostic InbandEdit packet is sent to create one diagnostic NetFlow entry and an adjacency entry, and one diagnostic packet is sent to ensure that the InbandEdit packet is forwarded accordingly with the rewritten MAC and VLAN.

Attributes	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	Test runs automatically on bootup. On-demand is also supported.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	DFC-equipped modules.

TestIPv4FibShortcut

These tests do the following:

- Verifies whether the IPv4 FIB forwarding of the Layer 3 forwarding engine is working properly. One diagnostic IPv4 FIB and an adjacency entry is installed, and a diagnostic packet is sent to make sure that the diagnostic packet is forwarded according to rewritten MAC and VLAN information.
- Verifies whether the FIB TCAM and adjacency devices are functional. One FIB entry is installed on each FIB TCAM device. A diagnostic packet is sent to make sure that the diagnostic packet is switched by the FIB TCAM entry installed on the TCAM device. This is not an exhaustive TCAM device test; only one entry is installed on each TCAM device.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	This test runs by default during bootup or after a reset or OIR.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestIPv6FibShortcut

This test verifies that the IPv6 FIB forwarding functionality of the Layer 3 forwarding engine is working properly. One diagnostic IPv6 FIB and an adjacency entry is installed, and a diagnostic IPv6 packet is sent to make sure that the diagnostic packet is forwarded according to rewritten MAC and VLAN information.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	This test runs by default during bootup or after a reset or OIR.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestL3Capture2

This test verifies that the Layer 3 capture (capture 2) feature of the Layer 3 forwarding engine is working properly. This capture feature is used for ACL logging and VACL logging. One diagnostic FIB and an adjacency entry with a capture 2-bit set is installed, and a diagnostic packet is sent to make sure that the diagnostic packet is forwarded according to capture bit information.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	This test runs by default during bootup or after a reset or OIR.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestMPLSFibShortcut

This test does the following:

- Verifies that the MPLS forwarding of the Layer 3 forwarding engine is working properly. One diagnostic MPLS FIB and an adjacency entry is installed, and a diagnostic MPLS packet is sent to make sure that the diagnostic packet is forwarded according to the MPLS label from the adjacency entry.
- Verifies the EoMPLS forwarding of the Layer 3 forwarding engine. One diagnostic EoMPLS Layer 2 FIB and an adjacency entry are installed and a diagnostic Layer 2 packet is sent to the forwarding engine to make sure it is forwarded accordingly with the MPLS labels and the encapsulated Layer 2 packet.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	This test runs by default during bootup or after a reset or OIR.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestNATFibShortcut

This test verifies the ability to rewrite a packet based on NAT adjacency information, such as the rewrite destination IP address. One diagnostic NAT FIB and an adjacency entry is installed, and a diagnostic packet is sent to the forwarding engine to make sure the diagnostic packet is forwarded according to the rewritten IP address.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second. Duration of the disruption depends on the configuration of the looped-back port (for example, Spanning Tree Protocol).
Recommendation:	This test runs by default during bootup or after a reset or OIR.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestNetflowShortcut

This test verifies that the NetFlow forwarding functionality of the Layer 3 forwarding engine is working properly. One diagnostic NetFlow entry and an adjacency entry is installed, and a diagnostic packet is sent to make sure it is forwarded according to the rewritten MAC and VLAN information.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for looped-back ports. Disruption is typically less than one second.
Recommendation:	Run this test on-demand if you suspect that NetFlow is not working properly.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestRBacl

This test verifies the role based ACL (RBACL) feature of the Layer 3 forwarding engine. This test uses SGT and DGT instead of src_ip/dest_ip to get ACL lookup results.

Attributes	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Test runs automatically on bootup. On-demand and health-monitoring tests are also supported.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	DFC-equipped modules.

Replication Engine Tests

- [TestEgressSpan, page 1-34](#)
- [TestIngressSpan, page 1-35](#)
- [TestL3VlanMet, page 1-35](#)

TestEgressSpan

This test verifies that the egress SPAN replication functionality of the rewrite engine for both SPAN queues is working properly.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for both SPAN sessions. Disruption is typically less than one second.
Recommendation:	Run this test on-demand.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines, DFC-equipped modules.

TestIngressSpan

This test ensures that the port ASIC is able to tag packets for ingress SPAN. This test also verifies that the ingress SPAN operation of the rewrite engine for both SPAN queues is working properly.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive for both SPAN sessions. Also disruptive for the loopback port on modules. Duration of the disruption depends on the configuration of the loopback port (for example, Spanning Tree Protocol).
Recommendation:	Run this test on-demand.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestL3VlanMet

This test verifies that the multicast functionality of the replication engine is working properly. The replication engine is configured to perform multicast replication of a diagnostic packet onto two different VLANs. After the diagnostic packet is sent out from the supervisor engine's inband port, the test verifies that two packets are received back in the inband port on the two VLANs configured in the replication engine.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive for supervisor engines. Disruptive for DFC-equipped modules. Disruption is typically less than one second on looped-back ports.
Recommendation:	Run this test on-demand to test the multicast replication abilities of the replication engine.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

Fabric Tests

- [TestFabricCh0Health](#), page 1-36
- [TestFabricCh1Health](#), page 1-36
- [TestFabricExternalSnake](#), page 1-37
- [TestFabricFlowControlStatus](#), page 1-37
- [TestFabricInternalSnake](#), page 1-38

- [TestFabricVlanLoopback](#), page 1-38
- [TestFexFabricLinkStatus](#), page 1-39
- [TestSynchedFabChannel](#), page 1-39

TestFabricCh0Health

This test constantly monitors the health of the ingress and egress data paths for fabric channel 0 on 10-gigabit modules. The test runs every five seconds. Ten consecutive failures are treated as fatal and the module resets; three consecutive reset cycles may result in a fabric switchover.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not turn this test off. Use as a health-monitoring test.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	The module resets after 10 consecutive failures. Three consecutive resets powers down the module.
Hardware support:	WS-X6704-10GE.

TestFabricCh1Health

This test constantly monitors the health of the ingress and egress data paths for fabric channel 1 on 10-gigabit modules. The test runs every five seconds. Ten consecutive failures are treated as fatal and the module resets; three consecutive reset cycles might result in a fabric switchover.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not turn this test off. Use as a health-monitoring test.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	The module resets after 10 consecutive failures. Three consecutive failures resets powers down the module.
Hardware support:	WS-X6704-10GE module.

TestFabricExternalSnake

This test is executed for the chassis-active supervisor engine only during regular OIR bootup diagnostic testing stage. This test generates the test packet through the inband port of the supervisor engine and the test data path involves the port ASIC, the rewrite engine ASIC inside the supervisor engine, and the fabric ASIC.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	After the supervisor engine is online, this test is supported to run by on-demand diagnostics for chassis-active supervisor engine but not for chassis-standby supervisor engine.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	If the test fails, the supervisor engine is power reset because it is a major diagnostic error.
Hardware support:	Active Supervisor engines.

TestFabricFlowControlStatus

This test reads the switch fabric ASIC registers to detect flow-control status for each fabric channel. Flow-control events are logged into the diagnostic events queue. By default, this test is disabled as a health-monitoring test, and when enabled, this test runs every 15 seconds. This test reports per-slot or per-channel rate reduction, current fabric channel utilization, peak fabric-channel utilization, and SP CPU utilization in both ingress and egress directions.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Use as a health-monitoring test. Use this test when you suspect a problem with the fabric channel.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	Flow control events are logged into the diagnostic event log.
Hardware support:	Supervisor engines.

TestFabricInternalSnake

This test is supported for a supervisor engine and module with a fabric switching ASIC. This test is executed by firmware INIT sequence code during bootup time when the firmware initializes the entire fabric ASIC.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	After the supervisor engine is online, this test is supported to run by on-demand diagnostics for chassis-standby supervisor engine but not for chassis-active supervisor engine. For modules with a fabric switching ASIC, this test is supported only for bootup diagnostic.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	If the test fails, firmware INIT sequence fails and the supervisor engine or module under test is power reset.
Hardware support:	Supervisor engines and fabric-enabled module.

TestFabricVlanLoopback

This test verifies the data path between the inband port of the module under test and the local fabric port responsible for switching traffic from and to the inband port through the per queue VLAN loopback feature provided by the hardware. When the test packet from the inband port arrives at the input queue of the local fabric port with matching VLAN to the pre-programmed VLAN loopback register, the test packet transverses the fabric, loops back to the output queue of the same fabric port, and forwards the test packet back to the inband port.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Test runs automatically on bootup. On-demand is also supported. Use this test to verify the data path between the local fabric channel and the inband port or use for debugging.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	Supervisor engines and DFC-equipped modules.

TestFexFabricLinkStatus

This test monitors the IA parent-client link and reports failure if the link port loses its connection to the associated IA client.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive health monitoring test.
Recommendation:	Do not disable.
Default:	On.
Initial Release:	15.1(2)SY
Corrective action:	Displays the “%CONST_DIAG-6-RSL_LINK_DOWN: RSL link on module <i>number</i> port <i>number</i> is down syslog” message.
Hardware support:	WS-X6904-40G-2T

TestSynchedFabChannel

This test periodically checks the fabric synchronization status for both the module and the fabric. This test is available only for fabric-enabled modules. This test is not a packet-switching test so it does not involve the data path. This test sends an SCP control message to the module and fabric to query the synchronization status.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not turn this test off. Use as a health-monitoring test.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	The module resets after five consecutive failures. Three consecutive reset cycles results in the module powering down. A fabric switchover may be triggered, depending on the type of failure.
Hardware support:	All fabric-enabled modules.

Exhaustive Memory Tests

- [TestAclQosTcam](#), page 1-40
- [TestAsicMemory](#), page 1-40
- [TestEarlMemOnBootup](#), page 1-41

**Note**

Because the supervisor engine must be rebooted after running memory tests, run memory tests on the other modules before running them on the supervisor engine. For more information about running on-demand online diagnostic tests see the [“Configuring On-Demand Online Diagnostics”](#) section on page 16-4.

TestAclQosTcam

This test tests all the bits and checks the location of both ACL and QoS TCAMs on the PFC.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive. Disruption is approximately one hour.
Recommendation:	Use this test only if you suspect a problem with the hardware or before putting the hardware into a live network. Do not run any traffic in the background on the module that you are testing. The supervisor engine must be rebooted after running this test.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	Not applicable.
Hardware support:	All modules including supervisor engines.

TestAsicMemory

This test uses an algorithm to test the memory on a module.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive. Disruption is approximately one hour.
Recommendation:	Use this test only if you suspect a problem with the hardware or before putting the hardware into a live network. Do not run any traffic in the background on the module that you are testing. The supervisor engine must be rebooted after running this test.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	Not applicable.
Hardware support:	All modules including supervisor engines.

TestEarlMemOnBootup

This test runs on bootup and tests all the bits and locations of EARL memories supported by the Generic Memory Testing Logic (GMTL). EARL memories are tested by drivers during bootup initialization. This test retrieves and displays the bootup test results from the drivers.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Not applicable.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	Not applicable.
Hardware support:	Supervisor engines and DFC-equipped modules.

Service Module Tests

- [TestPcLoopback, page 1-41](#)
- [TestPortASICLoopback, page 1-42](#)

TestPcLoopback

This test verifies the longest datapath between the supervisor and the NAM service module. A packet is sent from the supervisor to the module and is looped back by the PC to the supervisor engine.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	This test runs automatically during bootup.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	WS-SVC-NAM-1, WS-SVC-NAM-2.

TestPortASICLoopback

This test verifies the health of the ASIC ports on the NAM service module. A packet is sent from the supervisor engine and looped back at the ASIC.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	This test runs automatically during bootup.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	WS-SVC-NAM-1, WS-SVC-NAM-2.

Stress Tests

- [TestEobcStressPing](#), page 1-42
- [TestMicroburst](#), page 1-43
- [TestNVRAMBatteryMonitor](#), page 1-43
- [TestTrafficStress](#), page 1-44

TestEobcStressPing

This test stresses a module's EOBC link with the supervisor engine. The test is started when the supervisor engine initiates a number of sweep-ping processes (the default is one). The sweep-ping process pings the module with 20,000 SCP-ping packets. The test passes if all 20,000 packets respond before each packet-ping timeout, which is two seconds. If unsuccessful, the test allows five retries to account for traffic bursts on the EOBC bus during the test.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive. Disruption is several minutes.
Recommendation:	Use this test to qualify hardware before installing it in your network.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	Not applicable.
Hardware support:	Supervisor engines.

TestMicroburst

This test monitors packet microbursts in the port ASICs and logs them to SEA unless consecutive failures reach the threshold.

Attribute	Description
Disruptive or Nondisruptive:	NonDisruptive.
Recommendation:	Do not disable.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	Not applicable.
Hardware support:	Supervisor Engine 2T and DFC-equipped switching modules.

TestNVRAMBatteryMonitor

This test monitors the NVRAM battery status of the supervisor engine and logs every battery status change to OBFL. A syslog is printed if the battery voltage remains below a certain threshold for three consecutive days. Use the **show logging onboard** command and look for 'NVRAM battery power' to check change history of NVRAM battery status.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	This is an automatic health monitor test that runs every hour. It does not run at bootup and cannot be run on-demand.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	This test monitors the NVRAM battery status of the supervisor engine and logs battery status changes to on-board failure logging (OBFL). In the show logging onboard command output, the “NVRAM battery power” information is the NVRAM battery status history. After 72 consecutive test failures, a syslog advises module replacement.
Hardware support:	Supervisor Engine 2T.

TestTrafficStress

This test stress tests the switch and the installed modules by configuring all of the ports on the modules into pairs, which then pass packets between each other. After allowing the packets to pass through the switch for a predetermined period, the test verifies that the packets are not dropped.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive. Disruption is several minutes.
Recommendation:	Use this test to qualify hardware before installing it in your network.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	Not applicable.
Hardware support:	Supervisor engines.

General Tests

- [ScheduleSwitchover](#), page 1-44
- [TestCFRW](#), page 1-45
- [TestFirmwareDiagStatus](#), page 1-45
- [TestOBFL](#), page 1-45
- [TestRwEngineOverSubscription](#), page 1-46
- [TestVDB](#), page 1-46

ScheduleSwitchover

This test allows you to trigger a switchover at any time using the online diagnostics scheduling capability.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	Schedule this test during downtime to test the ability of the standby supervisor engine to take over after a switchover.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	None
Hardware support:	Supervisor engines.

TestCFRW

This test verifies the CompactFlash disk or disks on the supervisor engine. This test is performed during system boot-up or whenever a disk is inserted. A 128-byte temporary file is written to each disk present in the slot and read back. The content read back is checked and the temporary file is deleted. You can also execute this test from the CLI.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not disable. No traffic is affected.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	Format or replace the failed CompactFlash.
Hardware support:	Removable CompactFlash devices.

TestFirmwareDiagStatus

This test displays the results of the power-on diagnostic tests run by the firmware during the module bootup.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	This test can only be run at bootup.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide.
Hardware support:	All modules.

TestOBFL

This test verifies the on-board failure logging capabilities. During this test a diagnostic message is logged on the module.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	This test is run automatically during bootup and cannot be run on-demand.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	Not applicable.
Hardware support:	Supervisor engines, DFC-equipped switching modules, WS-SVC-WISM2.

TestRwEngineOverSubscription

This is a health-monitoring test that is not enabled by default. This test runs on the module every one second and checks if the rewrite engine gets oversubscribed by retrieving drop counters and generates a syslog message if the drops exceed the set threshold.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	This test is run only as a health-monitoring test.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	Not applicable.
Hardware support:	Supervisor engines, DFC-equipped modules.

TestVDB

This test is available on PoE-equipped modules. This test queries the result of diagnostic tests that run on the PoE daughter card.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	This test is run automatically during bootup.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	Not applicable.
Hardware support:	Modules with a PoE daughter card.

Critical Recovery Tests

- [TestTxPathMonitoring](#), page 1-47



Note

These tests are also considered critical recovery tests:

- [TestFabricCh0Health](#), page 1-36
- [TestFabricCh1Health](#), page 1-36
- [TestSynchedFabChannel](#), page 1-39

TestTxPathMonitoring

This test sends index-directed packets periodically to each port on the supervisor engine and supported modules to verify ASIC synchronization and correct any related problems. The test runs every two seconds.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive.
Recommendation:	Do not change the default settings.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	Not applicable (self-recovering).
Hardware support:	Supervisor engines and DFC-equipped modules.

ViSN Tests

- [TestRslHm, page 1-47](#)
- [TestVSActiveToStandbyLoopback, page 1-48](#)
- [TestVslBridgeLink, page 1-48](#)
- [TestVslLocalLoopback, page 1-49](#)
- [TestVslStatus, page 1-49](#)

TestRslHm

This test monitors the data and control links between the remote switch and core switches. A diagnostic packet is sent from the supervisor engine inband port on the remote switch to the supervisor engine inband port on the core switch and is pinged back along the reverse data path. This tests each RSL link between the remote switch and both active and standby core switches.

Attribute	Description
Disruptive or Nondisruptive:	Nondisruptive health monitoring test.
Recommendation:	Do not disable.
Default:	On.
Initial Release:	15.0(1)SY.
Corrective action:	None. See the system message guide for more information.
Hardware support:	VSL-capable modules.

TestVSActiveToStandbyLoopback

This test is the only GOLD test that tests the full data path across the virtual switch links. This test selects an uplink port in the standby virtual switch supervisor engine as the loopback point and sends the VLAN flood packet from the active virtual switch supervisor engine inband port to the system. Due to the configuration of the FPOE and LTL VLAN flood region for all VSL modules and VSL interfaces in the active and standby virtual switch, the packet goes across VSL and arrives at the uplink port of the standby virtual switch supervisor engines, and loops back from there. The packet comes back to the inband port of the active supervisor engine due to the preconfiguration of FPOE and LTL in the standby and active virtual switches. In case of a test failure, the error check is executed for SP CPU, fabric flow control, and other errors in both active and standby virtual switches.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	Disable all health monitoring tests before executing this test. This test is run only for on-demand diagnostic testing.
Default:	Off.
Initial Release:	15.0(1)SY.
Corrective action:	Not applicable.
Hardware support:	VSL-capable modules.

TestVslBridgeLink

This test provides diagnostic coverage for VSL-capable modules and the supervisor engine during module bootup. The data path of this test picks only one port corresponding to the local and remote bridge inband port as the loopback points. A diagnostic packet is sent from the inband port of the supervisor engine to the loopback points on the VSL module, and the packet traverses the bridge link between two fabric data path complexes to verify the hardware bridge link functionality.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	This test is run automatically during bootup.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	Not applicable.
Hardware support:	VSL-capable modules.

TestVslLocalLoopback

This test verifies the hardware functionality of each port on the VSL module before the VSL link interface is up. The data path of this test is constrained with the VSL module. A diagnostic packet is sent from the local inband port of the VSL module to each port to run a loopback test. This test is run only during module bootup.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	This test is run automatically during bootup and cannot be run on-demand.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	Not applicable.
Hardware support:	VSL-capable modules.

TestVslStatus

This test reports the status change detected by the VSLP protocol. When any link problem is detected by the VSLP protocol, the status of the link is changed and the result is updated accordingly. This test also triggers the loopback test to check the hardware status requested by the VSLP protocol.

Attribute	Description
Disruptive or Nondisruptive:	Disruptive.
Recommendation:	This test is effective once the VSL modules are online.
Default:	This test runs by default during bootup or after a reset or OIR.
Initial Release:	15.0(1)SY.
Corrective action:	Not applicable.
Hardware support:	VSL-capable modules.



Tip

For additional information about Cisco Catalyst 6500 Series Switches (including configuration examples and troubleshooting information), see the documents listed on this page:

http://www.cisco.com/en/US/products/hw/switches/ps708/tsd_products_support_series_home.html

[Participate in the Technical Documentation Ideas forum](#)



Numerics

- 4K VLANs (support for 4,096 VLANs) [26-2](#)
- 802.1AE Tagging [70-2](#)
- 802.1Q
 - Layer 2 protocol tunneling
 - See Layer 2 protocol tunneling
 - mapping to ISL VLANs [26-7](#)
 - trunks [21-4](#)
 - restrictions [21-2](#)
 - tunneling
 - configuration guidelines [29-1](#)
 - configuring tunnel ports [29-6](#)
 - overview [29-4](#)
- 802.1Q Ethertype
 - specifying custom [21-15](#)
- 802.1X [83-1](#)
- 802.1x accounting [83-43](#)
- 802.3ad
 - See LACP
- 802.3af [20-2](#)
- 802.3at [20-2](#)
- 802.3x Flow Control [10-9](#)

A

- AAA
 - fail policy [83-8, 84-5](#)
- AAA (authentication, authorization, and accounting). See also port-based authentication. [83-6, 84-2](#)
- aaa accounting dot1x command [83-44](#)
- aaa accounting system command [83-44](#)
- abbreviating commands [2-6](#)

- access, restricting MIB [86-10](#)
- access control entries and lists [69-1](#)
- access-enable host timeout (not supported) [69-4](#)
- access port, configuring [21-14](#)
- access rights [86-9](#)
- access setup, example [86-11](#)
- accounting
 - with 802.1x [83-43](#)
 - with IEEE 802.1x [83-16](#)
- ACEs and ACLs [69-1](#)
- ACLs
 - downloadable [84-2](#)
 - downloadable (dACLs) [83-24](#)
 - Filter-ID [83-25](#)
 - per-user [83-24](#)
 - port
 - defined [73-2](#)
 - redirect URL [83-25](#)
 - static sharing [83-25](#)
- acronyms, list of [1-1](#)
- activating lawful intercept [86-8](#)
- admin function (mediation device) [86-7, 86-8](#)
- administration, definition [86-6](#)
- advertisements, VTP [25-4](#)
- aggregate label [37-2, 37-5](#)
- aggregate policing [63-4](#)
- aging time
 - accelerated
 - for MSTP [31-45](#)
 - maximum
 - for MSTP [31-45, 31-46](#)
- alarms
 - major [15-7](#)

minor 15-7
 Allow DHCP Option 82 on Untrusted Port
 configuring 78-10
 understanding 78-5
 any transport over MPLS (AToM) 39-3
 Ethernet over MPLS 39-3
 ARP ACL 69-12
 ARP spoofing 80-3
 AToM 39-3
 audience 1-i
 authentication control-direction command 83-53
 authentication event command 83-45
 authentication failed VLAN
 See restricted VLAN
 authentication open comand 83-15
 authentication password, VTP 25-5
 authentication periodic command 83-38, 83-50
 authentication port-control command 83-45
 authentication timer reauthenticate command 83-38
 authorized ports with 802.1X 83-12
 auto enablement 83-30
 automatic QoS
 configuration guidelines and restrictions 66-2
 macros 66-4
 overview 66-2
 AutoQoS 66-1

B

BackboneFast
 See STP BackboneFast
 backup interfaces
 See Flex Links
 binding database, DHCP snooping
 See DHCP snooping binding database
 binding table, DHCP snooping
 See DHCP snooping binding database
 blocking state, STP 31-8
 BPDU

 RSTP format 31-16
 BPDU guard
 See STP BPDU guard
 BPDUs
 Bridge Assurance 32-5
 Shared Spanning Tree Protocol (SSTP) 32-20
 Bridge Assurance
 description 32-4 to 32-6
 inconsistent state 32-5
 supported protocols and link types 32-5
 bridge domain
 configuring 41-8
 bridge groups 35-1
 bridge ID
 See STP bridge ID
 bridge priority, STP 31-34
 bridge protocol data units
 see BPDUs
 bridging 35-1
 broadcast storms
 see traffic-storm control

C

CALEA, See Communications Assistance for Law Enforcement Act (CALEA)

CDP

 host presence detection 83-14, 85-4
 to configure Cisco phones 19-3

CEF

 configuring
 RP 33-5
 supervisor engine 33-4
 examples 33-3
 Layer 3 switching 33-2
 packet rewrite 33-2

channel-group group

 command 12-9, 12-13, 12-14, 12-15, 23-9, 23-14, 23-15, 23-16

- command example 23-9, 23-15
- Cisco Discovery Protocol
 - See CDP
- Cisco Emergency Responder 19-4
- Cisco EnergyWise 13-1
- Cisco Express Forwarding 37-3
- CISCO-IP-TAP-MIB
 - citapStreamVRF 86-2
 - overview 86-8
 - restricting access to 86-10, 86-11
- CISCO-TAP2-MIB
 - accessing 86-9
 - overview 86-8
 - restricting access to 86-10, 86-11
- CISP 83-30
- CIST regional root
 - See MSTP
- CIST root
 - See MSTP
- class command 63-9
- class map configuration 63-8, 64-11
- clear authentication sessions command 83-40
- clear counters command 10-12
- clear dot1x command 83-40
- clear interface command 10-13
- CLI
 - accessing 2-1
 - backing out one level 2-6
 - console configuration mode 2-5
 - getting list of commands 2-6
 - global configuration mode 2-5
 - history substitution 2-4
 - interface configuration mode 2-5
 - privileged EXEC mode 2-5
 - ROM monitor 2-7
 - software basics 2-4
- Client Information Signalling Protocol
 - See CISP
- collection function 86-6
- command line processing 2-3
- commands, getting list of 2-6
- Communications Assistance for Law Enforcement Act
 - CALEA for Voice 86-5
 - lawful intercept 86-4
- community ports 27-7
- community VLANs 27-6, 27-7
- configuration example
 - EoMPLS port mode 39-4, 39-7
 - EoMPLS VLAN mode 39-4
- configuration guidelines
 - EVCs 41-2
- configuring 63-9, 64-11
 - lawful intercept 86-10, 86-11, 86-12
 - SNMP 86-10
- console configuration mode 2-5
- content IAP 86-6
- control plane policing
 - See CoPP
- CoPP 77-1
 - applying QoS service policy to control plane 77-5
 - configuring
 - ACLs to match traffic 77-5
 - enabling MLS QoS 77-5
 - packet classification criteria 77-5
 - service-policy map 77-5
 - control plane configuration mode
 - entering 77-5
 - displaying
 - dynamic information 77-9
 - number of conforming bytes and packets 77-9
 - rate information 77-9
 - entering control plane configuration mode 77-5
 - monitoring statistics 77-9
 - overview 77-3
 - packet classification guidelines 77-2
 - traffic classification
 - defining 77-6
 - guidelines 77-7

- overview [77-6](#)
- sample ACLs [77-8](#)
- sample classes [77-6](#)

CoS

- override priority [19-6, 20-5](#)

counters

- clearing interface [10-12, 10-13](#)

- critical authentication [83-8](#)

- critical authentication, IEEE 802.1x [83-47](#)

- CSCsr62404 [10-9](#)

- CSCtx75254 [5-2](#)

- cTap2MediationDebug notification [86-12](#)

- cTap2MediationNewIndex object [86-8](#)

- cTap2MediationTable [86-8](#)

- cTap2MediationTimedOut notification [86-12](#)

- cTap2MIBActive notification [86-12](#)

- cTap2StreamDebug notification [86-12](#)

- cTap2StreamTable [86-8](#)

D

dACL

- See ACLs, downloadable [83-24](#)

- dCEF [33-4](#)

debug commands

- IP MMLS [44-31](#)

- DEC spanning-tree protocol [35-1](#)

default configuration

- 802.1X [83-31, 84-7](#)

- dynamic ARP inspection [80-6](#)

- EVCs [41-9](#)

- Flex Links [22-4](#)

- IP MMLS [44-15](#)

- MSTP [31-26](#)

- MVR [47-5](#)

- UDLD [11-4](#)

- voice VLAN [19-4](#)

- VTP [25-9](#)

- default VLAN [21-10](#)

- denial of service protection [76-1](#)

DHCP binding database

- See DHCP snooping binding database

DHCP binding table

- See DHCP snooping binding database

DHCP option 82

- circuit ID suboption [78-7](#)

- overview [78-5](#)

- packet format, suboption

- circuit ID [78-7](#)

- remote ID [78-7](#)

- remote ID suboption [78-7](#)

- DHCP option 82 allow on untrusted port [78-10](#)

DHCP snooping

- 802.1X data insertion [83-15](#)

- binding database

- See DHCP snooping binding database

- configuration guidelines [78-8](#)

- configuring [78-9](#)

- default configuration [78-8](#)

- displaying binding tables [78-18](#)

- enabling [78-9, 78-10, 78-11, 78-12, 78-13, 78-14](#)

- enabling the database agent [78-14](#)

- message exchange process [78-6](#)

- monitoring [79-5, 79-6](#)

- option 82 data insertion [78-5](#)

- overview [78-3](#)

- Snooping database agent [78-7](#)

DHCP snooping binding database

- described [78-5](#)

- entries [78-5](#)

DHCP snooping binding table

- See DHCP snooping binding database

DHCP Snooping Database Agent

- adding to the database (example) [78-18](#)

- enabling (example) [78-15](#)

- overview [78-7](#)

- reading from a TFTP file (example) [78-17](#)

- DHCP snooping increased bindings limit [78-14](#)

- DiffServ
 - configuring short pipe mode 67-30
 - configuring uniform mode 67-34
 - short pipe mode 67-27
 - uniform mode 67-28
- DiffServ tunneling modes 67-4
- Disabling PIM Snooping Designated Router Flooding 46-6
- distributed Cisco Express Forwarding
 - See dCEF
- distributed egress SPAN 56-10, 56-15
- DNS, See Domain Name System
- DNS, see Domain Name System
- documentation, related 1-i
- Domain Name System 86-2
- DoS protection 76-1
 - monitoring packet drop statistics
 - using monitor session commands 76-10
 - using VACL capture 76-12
 - QoS ACLs 76-2
 - security ACLs 76-2
 - uRPF check 76-6
- dot1x initialize interface command 83-39
- dot1x max-reauth-req command 83-43
- dot1x max-req command 83-42
- dot1x pae authenticator command 83-34
- dot1x re-authenticate interface command 83-39
- dot1x timeout quiet-period command 83-41
- DSCP-based queue mapping 65-14
- duplex command 10-5, 10-6
- duplex mode
 - autonegotiation status 10-6
 - configuring interface 10-4
- dynamic ARP inspection
 - ARP cache poisoning 80-3
 - ARP requests, described 80-3
 - ARP spoofing attack 80-3
 - configuration guidelines 80-2
 - configuring
 - log buffer 80-13, 80-15
 - logging system messages 80-14
 - rate limit for incoming ARP packets 80-5, 80-10
 - default configuration 80-6
 - denial-of-service attacks, preventing 80-10
 - described 80-3
 - DHCP snooping binding database 80-4
 - displaying
 - ARP ACLs 80-15
 - configuration and operating state 80-15
 - trust state and rate limit 80-15
 - error-disabled state for exceeding rate limit 80-5
 - function of 80-4
 - interface trust states 80-4
 - log buffer
 - configuring 80-13, 80-15
 - logging of dropped packets, described 80-6
 - logging system messages
 - configuring 80-14
 - man-in-the middle attack, described 80-4
 - network security issues and interface trust states 80-4
 - priority of ARP ACLs and DHCP snooping entries 80-6
 - rate limiting of ARP packets
 - configuring 80-10
 - described 80-5
 - error-disabled state 80-5
 - validation checks, performing 80-11
- Dynamic Host Configuration Protocol snooping 78-1

E

- EAC 70-2
- EAPOL. See also port-based authentication. 83-6
- eFSU, See Enhanced Fast Software Upgrade (eFSU)
- egress SPAN 56-10
- electronic traffic, monitoring 86-7
- enable mode 2-5

- enable sticky secure MAC address [85-8](#)
- enabling
 - IP MMLS
 - on router interfaces [44-16](#)
 - lawful intercept [86-8](#)
 - SNMP notifications [86-12](#)
- Endpoint Admission Control (EAC) [70-2](#)
- EnergyWise [13-1](#)
- enhanced Fast Software Upgrade (eFSU)
 - aborting (issu abortversion command) [5-13](#)
 - accepting the new software version [5-12](#)
 - committing the new software to standby RP (issu commitversion command) [5-12](#)
 - displaying maximum outage time for module [5-10](#)
 - error handling [5-5](#)
 - forcing a switchover (issu runversion command) [5-10](#)
 - issu loadversion command [5-8](#)
 - loading new software onto standby RP [5-8](#)
 - memory reservation on module [5-5](#)
 - memory reservation on module, prohibiting [5-4](#)
 - OIR not supported [5-3](#)
 - operation [5-3](#)
 - outage times [5-4](#)
 - performing [5-5](#)
 - steps [5-6](#)
 - usage guidelines and limitations [5-2](#)
 - verifying redundancy mode [5-7](#)
- environmental monitoring
 - LED indications [15-7](#)
 - SNMP traps [15-7](#)
 - supervisor engine and switching modules [15-7](#)
 - Syslog messages [15-7](#)
 - using CLI commands [15-1](#)
- EOBC
 - for MAC address table synchronization [21-3](#)
- EoMPLS [39-3](#)
 - configuring [39-4](#)
 - configuring VLAN mode [39-3](#)
 - guidelines and restrictions [39-2](#)
 - port mode [39-3](#)
 - VLAN mode [39-3](#)
- ERSPAN [56-1](#)
- EtherChannel
 - channel-group group
 - command [12-9, 12-14, 12-15, 23-9, 23-14, 23-15, 23-16](#)
 - command example [23-9, 23-15](#)
 - configuration guidelines [4-31, 23-2](#)
 - configuring
 - Layer 2 [23-9](#)
 - configuring (tasks) [4-31, 23-7](#)
 - interface port-channel
 - command example [23-8](#)
 - interface port-channel (command) [12-7, 12-8, 23-8](#)
 - lACP system-priority
 - command example [23-11](#)
 - Layer 2
 - configuring [23-9, 23-15](#)
 - load balancing
 - configuring [23-11](#)
 - understanding [23-7](#)
 - Min-Links [23-13, 23-14](#)
 - modes [23-4](#)
 - PAgP
 - understanding [23-5](#)
 - port-channel interfaces [23-7](#)
 - port-channel load-balance
 - command [23-11](#)
 - command example [23-12](#)
 - STP [23-7](#)
 - understanding [4-4, 23-3](#)
- EtherChannel Guard
 - See STP EtherChannel Guard
- Ethernet
 - setting port duplex [10-10](#)
- Ethernet flow point
 - See EFP

Ethernet over MPLS (EoMPLS) configuration

EoMPLS port mode [39-6](#)

EoMPLS VLAN mode [39-4](#)

Ethernet Virtual Connection

See EVC

EVC

broadcast domain [41-4](#)

configuration guidelines [41-2](#)

default configuration [41-9](#)

supported features [41-2](#)

EXP mutation [67-4](#)

extended range VLANs [26-2](#)

See VLANs

extended system ID

MSTP [31-39](#)

Extensible Authentication Protocol over LAN. See EAPOL.

F

fall-back bridging [35-1](#)

fast link notification

on VSL failure [4-15](#)

fiber-optic, detecting unidirectional links [11-1](#)

FIB TCAM [37-3](#)

figure

lawful intercept overview [86-5](#)

Flex Links [22-1](#)

configuration guidelines [22-2](#)

configuring [22-4](#)

default configuration [22-4](#)

description [22-2](#)

monitoring [22-6](#)

flex links

interface preemption [22-3](#)

flow control [10-9](#)

forward-delay time

MSTP [31-45](#)

forward-delay time, STP [31-35](#)

frame distribution

See EtherChannel load balancing

G

get requests [86-7, 86-8, 86-11](#)

global configuration mode [2-5](#)

guest VLAN and 802.1x [83-19](#)

H

hardware Layer 3 switching

guidelines [33-2](#)

hello time

MSTP [31-44](#)

hello time, STP [31-35](#)

High Capacity Power Supply Support [14-4](#)

history

CLI [2-4](#)

host mode

see port-based authentication

host ports

kinds of [27-7](#)

host presence CDP message [19-4, 83-14](#)

host presence TLV message [85-4](#)

http

[//www-tac.cisco.com/Teams/ks/c3/xmlkwery.php?srlid=612293409](http://www-tac.cisco.com/Teams/ks/c3/xmlkwery.php?srlid=612293409) [23-3](#)

I

IAP

content IAP [86-6](#)

definition [86-6](#)

content IAP [86-6](#)

identification IAP [86-6](#)

types of

ICMP unreachable messages [69-2](#)

ID IAP [86-6](#)

- IEEE 802.1Q Ethertype
 - specifying custom 21-15
- IEEE 802.1Q Tagging on a Per-Port Basis 29-7
- IEEE 802.1w
 - See RSTP
- IEEE 802.1x
 - accounting 83-16, 83-43
 - authentication failed VLAN 83-20
 - critical ports 83-21
 - DHCP snooping 83-15
 - guest VLAN 83-19
 - MAC authentication bypass 83-26
 - network admission control Layer 2 validation 83-27
 - port security interoperability 83-23
 - RADIUS-supplied session timeout 83-38
 - voice VLAN 83-22
 - wake-on-LAN support 83-28
- IEEE 802.3ad
 - See LACP
- IEEE 802.3af 20-2
- IEEE 802.3at 20-2
- IEEE 802.3x Flow Control 10-9
- IEEE bridging protocol 35-1
- IGMP 45-1
 - configuration guidelines 52-9
 - enabling 45-9
 - join messages 45-3
 - leave processing
 - enabling 45-13
 - queries 45-4
 - query interval
 - configuring 45-12
 - snooping
 - fast leave 45-6
 - joining multicast group 45-3, 48-4
 - leaving multicast group 45-5, 48-4
 - understanding 45-3, 48-3
 - snooping querier
 - enabling 45-9
 - understanding 45-3, 48-3
- IGMPv3 44-26
- IGMP v3lite 44-26
- ignore port trust 63-11
- inaccessible authentication bypass 83-21
- ingress SPAN 56-10
- intercept access point
 - See IAP
- intercept-related information (IRI) 86-6, 86-7
- intercepts, multiple 86-6
- interface
 - configuration mode 2-5
 - Layer 2 modes 21-4
 - number 10-2
- interface port-channel
 - command example 23-8
- interface port-channel (command) 12-7, 12-8, 23-8
- interfaces
 - configuring, duplex mode 10-3
 - configuring, speed 10-3
 - configururing, overview 10-2
 - counters, clearing 10-12, 10-13
 - displaying information about 10-12
 - maintaining 10-12
 - monitoring 10-12
 - range of 10-2
 - restarting 10-13
 - shutting down
 - task 10-13
- interfaces command 10-2
- interfaces range command 55-3
- interfaces range macro command 10-2
- internal VLANs 26-3
- Internet Group Management Protocol 45-1, 48-1
- IP accounting, IP MMLS and 44-2
- IP CEF
 - topology (figure) 33-4
- ip flow-export source command 58-3, 58-4, 58-5
- ip local policy route-map command 34-5

IP MMLS

- cache, overview [44-4](#)
- configuration guideline [44-1](#)
- debug commands [44-31](#)
- default configuration [44-15](#)
- enabling
 - on router interfaces [44-16](#)
- Layer 3 MLS cache [44-4](#)
- overview [44-2](#)
- packet rewrite [44-5](#)
- router
 - enabling globally [44-16](#)
 - enabling on interfaces [44-16](#)
 - PIM, enabling [44-16](#)

IP multicast

- IGMP snooping and [45-8](#)
- MLDv2 snooping and [52-9](#)
- overview [45-2, 48-2, 49-2](#)

IP multicast MLS

See IP MMLS

ip multicast-routing command

- enabling IP multicast [44-16](#)

IP phone

- configuring [19-5](#)

ip pim command

- enabling IP PIM [44-16](#)

ip policy route-map command [34-5](#)

IP Source Guard [79-1](#)

- configuring [79-3](#)
- configuring on private VLANs [79-5](#)
- displaying [79-5, 79-6](#)
- overview [79-2](#)

IP unnumbered [35-1](#)

IPv4 Multicast VPN [50-1](#)

IPv6 Multicast Layer 3 Switching [51-1](#)

IPv6 QoS [61-4](#)

ISL trunks [21-4](#)

isolated port [27-7](#)

isolated VLANs [27-6, 27-7](#)

J

join messages, IGMP [45-3](#)

jumbo frames [10-6](#)

K

keyboard shortcuts [2-3](#)

L

label edge router [37-2](#)

label switched path [39-1](#)

label switch router [37-2, 37-4](#)

LACP

- system ID [23-6](#)

Law Enforcement Agency (LEA) [86-4](#)

lawful intercept

- admin function [86-7, 86-8](#)
- collection function [86-6](#)
- configuring [86-10, 86-11, 86-12](#)
- enabling [86-8](#)
- IRI [86-6](#)
- mediation device [86-5](#)
- overview [86-4, 86-5](#)
- prerequisites [86-1](#)
- processing [86-7](#)
- security considerations [86-9](#)
- SNMP notifications [86-12](#)

lawful intercept processing [86-7](#)

Layer 2

- configuring interfaces [21-5](#)
 - access port [21-14](#)
 - trunk [21-8](#)
- defaults [21-5](#)
- interface modes [21-4](#)
- show interfaces [10-8, 10-9, 21-6, 21-13](#)
- switching
 - understanding [21-2](#)

- trunks
 - understanding [21-4](#)
 - VLAN
 - interface assignment [26-6](#)
 - Layer 2 Interfaces
 - configuring [21-1](#)
 - Layer 2 protocol tunneling
 - configuring Layer 2 tunnels [30-3](#)
 - overview [30-2](#)
 - Layer 2 Traceroute [59-1](#)
 - Layer 2 traceroute
 - and ARP [59-2](#)
 - and CDP [59-1](#)
 - described [59-2](#)
 - IP addresses and subnets [59-2](#)
 - MAC addresses and VLANs [59-2](#)
 - multicast traffic [59-2](#)
 - multiple devices on a port [59-2](#)
 - unicast traffic [59-2](#)
 - usage guidelines [59-1](#)
 - Layer 3
 - IP MMLS and MLS cache [44-4](#)
 - Layer 3 switched packet rewrite
 - CEF [33-2](#)
 - Layer 3 switching
 - CEF [33-2](#)
 - Layer 4 port operations (ACLs) [69-2](#)
 - leave processing, IGMP
 - enabling [45-13](#)
 - leave processing, MLDv2
 - enabling [52-12](#)
 - LERs [67-2, 67-6, 67-7](#)
 - Link Failure
 - detecting unidirectional [31-25](#)
 - link negotiation [10-5](#)
 - link redundancy
 - See Flex Links
 - LLDP-MED
 - configuring
 - TLVs [20-8](#)
 - load deferral
 - MEC traffic recovery [4-6](#)
 - Local Egress Replication [44-19](#)
 - logical operation unit
 - See LOU
 - loop guard
 - See STP loop guard
 - LOU
 - description [69-3](#)
 - determining maximum number of [69-3](#)
 - LSRs [67-2, 67-6](#)
-
- ## M
- mab command [83-45, 83-50](#)
 - MAC address-based blocking [72-1](#)
 - MAC address table notification [21-7](#)
 - MAC authentication bypass. See also port-based authentication. [83-26](#)
 - MAC move (port security) [85-3](#)
 - macros [3-1](#)
 - See Smartports macros
 - MACSec [70-2](#)
 - magic packet [83-28](#)
 - mapping 802.1Q VLANs to ISL VLANs [26-7](#)
 - markdown
 - see QoS markdown
 - match ip address command [34-4](#)
 - match length command [34-4](#)
 - maximum aging time
 - MSTP [31-45](#)
 - maximum aging time, STP [31-36](#)
 - maximum hop count, MSTP [31-46](#)
 - MEC
 - configuration [4-49](#)
 - described [4-15](#)
 - failure [4-16](#)
 - port load share deferral [4-17](#)

- mediation device
 - admin function 86-7, 86-8
 - definition 86-5
 - description 86-5
- MIBs
 - CISCO-IP-TAP-MIB 86-2, 86-8, 86-10
 - CISCO-TAP2-MIB 86-8, 86-9, 86-10
 - SNMP-COMMUNITY-MIB 86-9
 - SNMP-USM-MIB 86-4, 86-9
 - SNMP-VACM-MIB 86-4, 86-9
- microflow policing 63-4
- Mini Protocol Analyzer 60-1
- Min-Links 23-13
- MLD
 - report 52-5
- MLD snooping
 - query interval
 - configuring 52-10
- MLDv1 52-2
- MLDv2 52-1
 - enabling 52-11
 - leave processing
 - enabling 52-12
 - queries 52-6
 - snooping
 - fast leave 52-8
 - joining multicast group 52-5
 - leaving multicast group 52-7
 - understanding 52-3
 - snooping querier
 - enabling 52-10
 - understanding 52-3
- MLDv2 Snooping 52-1
- monitoring
 - Flex Links 22-6
 - MVR 47-8
 - private VLANs 27-16
- monitoring electronic traffic 86-7
- MPLS 37-1, 37-2
 - aggregate label 37-2
 - any transport over MPLS 39-3
 - basic configuration 37-9
 - core 37-4
 - DiffServ Tunneling Modes 67-26
 - egress 37-4
 - experimental field 67-3
 - hardware features 37-5
 - ingress 37-4
 - IP to MPLS path 37-4
 - labels 37-2
 - MPLS to IP path 37-4
 - MPLS to MPLS path 37-4
 - nonaggregate label 37-2
 - QoS default configuration 67-13
 - restrictions 37-1
 - VPN 67-11
 - VPN guidelines and restrictions 38-2
- MPLS QoS
 - Classification 67-2
 - Class of Service 67-2
 - commands 67-15
 - configuring a class map 67-17
 - configuring a policy map 67-20
 - configuring egress EXP mutation 67-24
 - configuring EXP Value Maps 67-25
 - Differentiated Services Code Point 67-2
 - displaying a policy map 67-24
 - E-LSP 67-2
 - EXP bits 67-2
 - features 67-2
 - IP Precedence 67-2
 - QoS Tags 67-2
 - queueing-only mode 67-17
- MPLS QoS configuration
 - class map to classify MPLS packets 67-17
- MPLS supported commands 37-2
- MPLS VPN
 - limitations and restrictions 38-2

MQC [62-1](#)

MST

interoperation with Rapid PVST+ [32-20](#)

root bridge [32-20](#)

MSTP

boundary ports

configuration guidelines [31-2](#)

described [31-22](#)

CIST, described [31-19](#)

CIST regional root [31-20](#)

CIST root [31-21](#)

configuration guidelines [31-2](#)

configuring

forward-delay time [31-45](#)

hello time [31-44](#)

link type for rapid convergence [31-46](#)

maximum aging time [31-45](#)

maximum hop count [31-46](#)

MST region [31-38](#)

neighbor type [31-46](#)

path cost [31-42](#)

port priority [31-41](#)

root switch [31-39](#)

secondary root switch [31-40](#)

switch priority [31-43](#)

CST

defined [31-19](#)

operations between regions [31-20](#)

default configuration [31-26](#)

displaying status [31-47](#)

enabling the mode [31-38](#)

extended system ID

effects on root switch [31-39](#)

effects on secondary root switch [31-40](#)

unexpected behavior [31-39](#)

IEEE 802.1s

implementation [31-23](#)

port role naming change [31-23](#)

terminology [31-21](#)

interoperability with IEEE 802.1D

described [31-24](#)

restarting migration process [31-47](#)

IST

defined [31-19](#)

master [31-20](#)

operations within a region [31-20](#)

mapping VLANs to MST instance [31-38](#)

MST region

CIST [31-19](#)

configuring [31-38](#)

described [31-19](#)

hop-count mechanism [31-22](#)

IST [31-19](#)

supported spanning-tree instances [31-19](#)

overview [31-18](#)

root switch

configuring [31-39](#)

effects of extended system ID [31-39](#)

unexpected behavior [31-39](#)

status, displaying [31-47](#)

MTU size (default) [26-3](#)

multiauthentication (multiauth). See also port-based authentication. [83-15](#)

multicast

IGMP snooping and [45-8](#)

MLDv2 snooping and [52-9](#)

non-RPF [44-7](#)

overview [45-2, 48-2, 49-2](#)

PIM snooping [46-4](#)

multicast flood blocking [82-1](#)

multicast groups

joining [45-3, 48-4](#)

leaving [45-5, 52-7](#)

multicast groups, IPv6

joining [52-5](#)

Multicast Listener Discovery version 2 [52-1](#)

Multicast Replication Mode Detection enhancement [44-18](#)

multicast storms
 see traffic-storm control

multicast television application [47-3](#)

multicast VLAN [47-2](#)

Multicast VLAN Registration [47-1](#)

multichassis EtherChannel
 see MEC [4-15](#)

Multidomain Authentication (MDA). See also port-based authentication. [83-14](#)

Multilayer MAC ACL QoS Filtering [69-9](#)

multiple path RPF check [76-7](#)

Multiple Spanning Tree
 See MST

MUX-UNI Support [37-7](#)

MUX-UNI support [37-7](#)

MVAP (Multi-VLAN Access Port). See also port-based authentication. [83-22](#)

MVR
 and IGMPv3 [47-2](#)
 configuring interfaces [47-6](#)
 default configuration [47-5](#)
 example application [47-3](#)
 in the switch stack [47-5](#)
 monitoring [47-8](#)
 multicast television application [47-3](#)
 restrictions [47-1](#)
 setting global parameters [47-6](#)

N

NAC
 agentless audit support [83-27](#)
 critical authentication [83-21, 83-47](#)
 IEEE 802.1x authentication using a RADIUS server [83-50](#)
 IEEE 802.1x validation using RADIUS server [83-50](#)
 inaccessible authentication bypass [83-47](#)
 Layer 2 IEEE 802.1x validation [83-50](#)
 Layer 2 IEEE802.1x validation [83-27](#)

native VLAN [21-11](#)

NDAC [70-2](#)

NEAT
 configuring [83-54](#)
 overview [83-30](#)

NetFlow
 table, displaying entries [33-5](#)

Network Device Admission Control (NDAC) [70-2](#)

Network Edge Access Topology
 See NEAT

network ports
 Bridge Assurance [32-5](#)
 description [32-2](#)

nonaggregate label [37-2, 37-5](#)

non-RPF multicast [44-7](#)

normal-range VLANs
 See VLANs

notifications, See SNMP notifications

NSF with SSO does not support IPv6 multicast traffic. [7-1, 8-1](#)

O

OIR [10-11](#)

online diagnostics
 CompactFlash disk verification [1-45](#)
 configuring [16-2](#)
 datapath verification [1-15](#)
 diagnostic sanity check [16-29](#)
 egress datapath test [1-5](#)
 error counter test [1-5](#)
 interrupt counter test [1-5](#)
 memory tests [16-29](#)
 overview [16-2](#)
 running tests [16-7](#)
 test descriptions [1-1](#)
 understanding [16-2](#)

online diagnostic tests [1-1](#)

online insertion and removal

See OIR

out-f-band MAC address table synchronization

configuring 21-6

in a VSS 4-2

out of profile

see QoS out of profile

P

packet capture 60-2

packet rewrite

CEF 33-2

IP MMLS and 44-5

packets

multicast 73-6

PAGP

understanding 23-5

path cost

MSTP 31-42

PBACLs 69-5

PBF 74-4

PBR (policy-based routing)

configuration (example) 34-7

enabling 34-4

peer inconsistent state

in PVST simulation 32-20

per-port VTP enable and disable 25-16

PFC

recirculation 37-5

PIM, IP MMLS and 44-16

PIM snooping

designated router flooding 46-6

enabling globally 46-5

enabling in a VLAN 46-5

overview 46-4

platform aging command

configuring IP MLS 53-3, 53-4

platform ip multicast command

enabling IP MMLS 44-17 to 44-27

PoE 20-2

Cisco prestandard 20-3

IEEE 802.3af 20-2

IEEE 802.3at 20-2

PoE management 20-3

power policing 20-4

power use measurement 20-4

police command 63-13, 63-14

policy-based ACLs (PBACLs) 69-5

policy-based forwarding (PBF) 75-2

policy-based routing (PBR)

configuring 34-1

policy map 63-9, 64-11

attaching to an interface 63-17, 64-17, 76-6

policy-map command 63-9

port ACLs

defined 73-2

port ACLs (PACLs) 73-1

Port Aggregation Protocol

see PAGP

port-based authentication

AAA authorization 83-33

accounting 83-16

configuring 83-43

authentication server

defined 83-7, 84-3

RADIUS server 83-7

client, defined 83-7, 84-3

configuration guidelines 83-2, 84-1

configuring

guest VLAN 83-45

inaccessible authentication bypass 83-47

initializing authentication of a client 83-39

manual reauthentication of a client 83-39

RADIUS server 83-35, 84-10

RADIUS server parameters on the switch 83-34, 84-9

restricted VLAN 83-46

- switch-to-authentication-server retransmission time 83-42
- switch-to-client EAP-request frame retransmission time 83-41
- switch-to-client frame-retransmission number 83-42, 83-43
- switch-to-client retransmission time 83-41
- user distribution 83-44
- VLAN group assignment 83-44
- default configuration 83-31, 84-7
- described 83-6
- device roles 83-7, 84-3
- DHCP snooping 83-15
- DHCP snooping and insertion 78-6
- displaying statistics 83-57, 84-15
- EAPOL-start frame 83-10
- EAP-request/identity frame 83-10
- EAP-response/identity frame 83-10
- enabling
 - 802.1X authentication 83-33, 83-34, 84-9
 - periodic reauthentication 83-38
- encapsulation 83-7
- guest VLAN
 - configuration guidelines 83-19, 83-20
 - described 83-19
- host mode 83-13
- inaccessible authentication bypass
 - configuring 83-47
 - described 83-21
 - guidelines 83-4
- initiation and message exchange 83-10
- MAC authentication bypass 83-26
- magic packet 83-28
- method lists 83-33
- modes 83-13
- multiauth mode, described 83-15
- multidomain authentication mode, described 83-14
- multiple-hosts mode, described 83-13
- ports
 - authorization state and dot1x port-control command 83-12
 - authorized and unauthorized 83-12
 - critical 83-21
 - voice VLAN 83-22
- port security
 - and voice VLAN 83-23
 - described 83-23
 - interactions 83-23
 - multiple-hosts mode 83-13
- pre-authentication open access 83-15, 83-36
- resetting to default values 83-57
- supplicant, defined 83-7
- switch
 - as proxy 83-7, 84-3
 - RADIUS client 83-7
- switch supplicant
 - configuring 83-54
 - overview 83-30
- user distribution
 - configuring 83-44
 - described 83-18
 - guidelines 83-4
- VLAN assignment
 - AAA authorization 83-33
 - characteristics 83-17
 - configuration tasks 83-18
 - described 83-17
- VLAN group
 - guidelines 83-4
- voice VLAN
 - described 83-22
 - PVID 83-22
 - VVID 83-22
 - wake-on-LAN, described 83-28
- port-based QoS features
 - see QoS
- port-channel
 - see EtherChannel

- port-channel load-balance
 - command [23-11](#)
 - command example [23-11, 23-12](#)
- port-channel load-defer command [4-49](#)
- port-channel port load-defer command [4-49](#)
- port cost, STP [31-32](#)
- port debounce timer
 - disabling [10-10](#)
 - displaying [10-10](#)
 - enabling [10-10](#)
- PortFast
 - edge ports [32-2](#)
 - network ports [32-2](#)
 - See STP PortFast
- PortFast Edge BPDU filtering
 - See STP PortFast Edge BPDU filtering
- PortFast port types
 - description [32-2, 32-2 to ??](#)
 - edge [32-2](#)
 - network [32-2](#)
- port mode [39-3](#)
- port negotiation [10-5](#)
- port priority
 - MSTP [31-41](#)
- port priority, STP [31-31](#)
- ports
 - setting the debounce timer [10-10](#)
- port security
 - aging [85-9, 85-10](#)
 - configuring [85-4](#)
 - described [85-3](#)
 - displaying [85-10](#)
 - enable sticky secure MAC address [85-8](#)
 - sticky MAC address [85-3](#)
 - violations [85-3](#)
- Port Security is supported on trunks [85-2, 85-5, 85-7, 85-9](#)
- port security MAC move [85-3](#)
- port security on PVLAN ports [85-2](#)
- Port Security with Sticky Secure MAC Addresses [85-3](#)
- power management
 - enabling/disabling redundancy [14-2](#)
 - overview [14-1](#)
 - powering modules up or down [14-3](#)
 - power policing [20-8](#)
- power negotiation
 - through LLDP [20-8](#)
- Power over Ethernet [20-2](#)
- power over ethernet [20-2](#)
- pre-authentication open access. See port-based authentication.
- preemption, default configuration [22-4](#)
- preemption delay, default configuration [22-4](#)
- prerequisites for lawful intercept [86-1](#)
- primary links [22-2](#)
- primary VLANs [27-6](#)
- priority
 - overriding CoS [19-6, 20-5](#)
- private hosts [28-1](#)
- private hosts feature
 - configuration guidelines [28-1](#)
 - configuring (detailed steps) [28-9](#)
 - configuring (summary) [28-8](#)
 - multicast operation [28-4](#)
 - overview [28-4](#)
 - port ACLs (PACLs) [28-7](#)
 - port types [28-5, 28-6](#)
 - protocol-independent MAC ACLs [28-4](#)
 - restricting traffic flow with PACLs [28-5](#)
 - spoofing protection [28-3](#)
- private VLANs [27-1](#)
 - across multiple switches [27-9](#)
 - and SVIs [27-10](#)
 - benefits of [27-5](#)
 - community VLANs [27-6, 27-7](#)
 - configuration guidelines [27-2, 27-4, 27-10](#)
 - configuring [27-10](#)
 - host ports [27-14](#)
 - promiscuous ports [27-15](#)

- routing secondary VLAN ingress traffic [27-13](#)
 - secondary VLANs with primary VLANs [27-12](#)
 - VLANs as private [27-11](#)
- end station access to [27-8](#)
- IP addressing [27-8](#)
- isolated VLANs [27-6, 27-7](#)
- monitoring [27-16](#)
- ports
 - community [27-7](#)
 - configuration guidelines [27-4](#)
 - isolated [27-7](#)
 - promiscuous [27-7](#)
- primary VLANs [27-6](#)
- secondary VLANs [27-6](#)
- subdomains [27-5](#)
- traffic in [27-10](#)
- privileged EXEC mode [2-5](#)
- promiscuous ports [27-7](#)
- protocol tunneling
 - See Layer 2 protocol tunneling [30-2](#)
- PVRST
 - See Rapid-PVST [31-3](#)
- PVST
 - description [31-3](#)
- PVST simulation
 - description [32-20](#)
 - peer inconsistent state [32-20](#)
 - root bridge [32-20](#)

Q

- QoS
 - auto-QoS
 - enabling for VoIP [66-4](#)
 - IPv6 [61-4](#)
 - See also automatic QoS [66-1](#)
- QoS CoS
 - port value, configuring [65-2](#)
- QoS default configuration [68-2](#)

- QoS DSCP
 - maps, configuring [65-7](#)
- QoS mapping
 - CoS values to DSCP values [65-4, 65-7](#)
 - DSCP markdown values [65-8, 67-14](#)
 - DSCP mutation [65-3, 67-25](#)
 - DSCP values to CoS values [65-9](#)
 - IP precedence values to DSCP values [65-7](#)
- QoS markdown [63-4](#)
- QoS out of profile [63-4](#)
- QoS policing rule
 - aggregate [63-4](#)
 - microflow [63-4](#)
- QoS port
 - trust state [65-10](#)
- QoS port-based or VLAN-based [65-12](#)
- QoS receive queue [65-18](#)
- QoS statistics data export [68-2](#)
 - configuring [68-2](#)
 - configuring destination host [68-7](#)
 - configuring time interval [68-6, 68-8](#)
- QoS transmit queues [64-6, 65-15, 65-16](#)
- QoS VLAN-based or port-based [65-12](#)
- queries, IGMP [45-4](#)
- queries, MLDv2 [52-6](#)

R

- RADIUS [78-6](#)
- RADIUS. See also port-based authentication. [83-7](#)
- range
 - command [55-3](#)
 - macro [10-2](#)
- rapid convergence [31-14](#)
- Rapid-PVST
 - enabling [31-36](#)
- Rapid PVST+
 - interoperation with MST [32-20](#)
- Rapid-PVST+

- overview [31-3](#)
- Rapid Spanning Tree
 - See RSTP
- Rapid Spanning Tree Protocol
 - See RSTP
- receive queues
 - see QoS receive queues
- recirculation [37-5](#)
- redirect URLs
 - described [83-25](#)
- reduced MAC address [31-3](#)
- redundancy (RPR+) [9-1](#)
 - configuring [9-4](#)
 - configuring supervisor engine [9-2](#)
 - displaying supervisor engine configuration [9-4](#)
- related documentation [1-i](#)
- Remote Authentication Dial-In User Service. See RADIUS.
- report, MLD [52-5](#)
- reserved-range VLANs
 - See VLANs
- restricted VLAN
 - configuring [83-46](#)
 - described [83-20](#)
 - using with IEEE 802.1x [83-20](#)
- restricting MIB access [86-10, 86-11](#)
- rewrite, packet
 - CEF [33-2](#)
 - IP MMLS [44-5](#)
- RIF cache monitoring [10-12](#)
- ROM monitor
 - CLI [2-7](#)
- root bridge
 - MST [32-20](#)
 - PVST simulation [32-20](#)
- root bridge, STP [31-29](#)
- root guard
 - See STP root guard
- root switch
 - MSTP [31-39](#)
- route-map (IP) command [34-4](#)
- route maps
 - defining [34-4](#)
- router guard [49-1](#)
- RPF
 - failure [44-7](#)
 - non-RPF multicast [44-7](#)
- RPR and RPR+ support IPv6 multicast traffic [9-1](#)
- RSTP
 - active topology [31-13](#)
 - BPDU
 - format [31-16](#)
 - processing [31-17](#)
 - designated port, defined [31-13](#)
 - designated switch, defined [31-13](#)
 - interoperability with IEEE 802.1D
 - described [31-24](#)
 - restarting migration process [31-47](#)
 - topology changes [31-17](#)
 - overview [31-13](#)
 - port roles
 - described [31-13](#)
 - synchronized [31-15](#)
 - proposal-agreement handshake process [31-14](#)
 - rapid convergence
 - described [31-14](#)
 - edge ports and Port Fast [31-14](#)
 - point-to-point links [31-14, 31-46](#)
 - root ports [31-14](#)
 - root port, defined [31-13](#)
 - See also MSTP

S

- secondary VLANs [27-6](#)
- Secure MAC Address Aging Type [85-10](#)
- security
 - configuring [71-1](#)

- security, port 85-3
- security considerations 86-9
- Security Exchange Protocol (SXP) 70-2
- Security Group Access Control List (SGACL) 70-2
- Security Group Tag (SGT) 70-2
- serial interfaces
 - clearing 10-13
 - synchronous
 - maintaining 10-13
- service instance
 - configuration mode 41-5
 - creating 41-4
 - defined 41-4
- service-policy input command 63-17, 64-17, 65-4, 65-6, 67-25, 76-6
- service-provider network, MSTP and RSTP 31-18
- set default interface command 34-4
- set interface command 34-4
- set ip default next-hop command 34-4
- set ip df command
 - PBR 34-4
- set ip next-hop command 34-4
- set ip precedence command
 - PBR 34-4
- set ip vrf command
 - PBR 34-4
- set power redundancy enable/disable command 14-2
- set requests 86-7, 86-8, 86-11
- setting up lawful intercept 86-7
- SGACL 70-2
- SGT 70-2
- short pipe mode
 - configuring 67-30
- show authentication command 83-58
- show catalyst6000 chassis-mac-address command 31-4
- show dot1x interface command 83-39
- show eobc command 10-12
- show history command 2-4
- show ibc command 10-12
- show interfaces command 10-8, 10-9, 10-12, 21-6, 21-13
 - clearing interface counters 10-12
 - displaying, speed and duplex mode 10-6
- show ip local policy command 34-5
- show mab command 83-61
- show module command 9-4
- show platform aging command 53-4
- show platform entry command 33-5
- show platform ip multicast group command
 - displaying IP MMLS group 44-27
- show platform ip multicast interface command
 - displaying IP MMLS interface 44-27
- show platform ip multicast source command
 - displaying IP MMLS source 44-27
- show platform ip multicast statistics command
 - displaying IP MMLS statistics 44-27
- show platform ip multicast summary
 - displaying IP MMLS configuration 44-27
- show protocols command 10-12
- show rif command 10-12
- show running-config command 10-12
 - displaying ACLs 73-7, 73-8
- show version command 10-12
- shutdown command 10-13
- shutdown interfaces
 - result 10-13
- slot number, description 10-2
- smart port macros 3-1
 - configuration guidelines 3-2
- Smartports macros
 - applying global parameter values 3-14
 - applying macros 3-14
 - creating 3-13
 - default configuration 3-4
 - defined 3-4
 - displaying 3-15
 - tracing 3-2
- SNMP
 - configuring 86-10

- default view 86-9
- get and set requests 86-7, 86-8, 86-11
- notifications 86-9, 86-12
- SNMP-COMMUNITY-MIB 86-9
- SNMP-USM-MIB 86-4, 86-9
- SNMP-VACM-MIB 86-4, 86-9
- snooping
 - See IGMP snooping
- software
 - upgrading router 5-5
- source specific multicast with IGMPv3, IGMP v3lite, and URD 44-26
- SPAN
 - configuration guidelines 56-2
 - configuring 56-12
 - sources 56-16, 56-19, 56-21, 56-22, 56-24, 56-25, 56-26, 56-28
 - VLAN filtering 56-30
 - destination port support on EtherChannels 56-12, 56-19, 56-22, 56-24, 56-25, 56-29
 - distributed egress 56-10, 56-15
 - modules that disable for ERSPAN 56-7
 - input packets with don't learn option
 - ERSPAN 56-28, 56-29
 - local SPAN 56-17, 56-18, 56-19
 - RSPAN 56-22, 56-23, 56-25
 - understanding 56-12
 - local SPAN egress session increase 56-3, 56-16
 - overview 56-7
- SPAN Destination Port Permit Lists 56-15
- spanning-tree backbonefast
 - command 32-15, 32-16
 - command example 32-15, 32-16
- spanning-tree cost
 - command 31-33
 - command example 31-33
- spanning-tree portfast
 - command 32-2, 32-3, 32-4
 - command example 32-3, 32-4
- spanning-tree portfast bpdu-guard
 - command 32-8
- spanning-tree port-priority
 - command 31-31
- spanning-tree protocol for bridging 35-1
- spanning-tree uplinkfast
 - command 32-13
 - command example 32-13
- spanning-tree vlan
 - command 31-27, 31-29, 31-30, 31-31, 32-8, 32-17
 - command example 31-28, 31-29, 31-30, 31-31
- spanning-tree vlan cost
 - command 31-33
- spanning-tree vlan forward-time
 - command 31-35
 - command example 31-35
- spanning-tree vlan hello-time
 - command 31-35
 - command example 31-35
- spanning-tree vlan max-age
 - command 31-36
 - command example 31-36
- spanning-tree vlan port-priority
 - command 31-31
 - command example 31-32
- spanning-tree vlan priority
 - command 31-34
 - command example 31-34
- speed
 - configuring interface 10-4
- speed command 10-4
- speed mode
 - autonegotiation status 10-6
- standards, lawful intercept 86-4
- standby links 22-2
- static sharing
 - description 83-25
- statistics
 - 802.1X 83-57, 84-15
- sticky ARP 76-9

- sticky MAC address [85-3](#)
- Sticky secure MAC addresses [85-8, 85-9](#)
- storm control
 - see traffic-storm control
- STP
 - configuring [31-26](#)
 - bridge priority [31-34](#)
 - enabling [31-27, 31-28](#)
 - forward-delay time [31-35](#)
 - hello time [31-35](#)
 - maximum aging time [31-36](#)
 - port cost [31-32](#)
 - port priority [31-31](#)
 - root bridge [31-29](#)
 - secondary root switch [31-30](#)
 - defaults [31-25](#)
 - EtherChannel [23-7](#)
 - normal ports [32-3](#)
 - understanding [31-2](#)
 - 802.1Q Trunks [31-12](#)
 - Blocking State [31-8](#)
 - BPDUs [31-4](#)
 - disabled state [31-12](#)
 - forwarding state [31-11](#)
 - learning state [31-10](#)
 - listening state [31-9](#)
 - overview [31-3](#)
 - port states [31-6](#)
 - protocol timers [31-5](#)
 - root bridge election [31-5](#)
 - topology [31-5](#)
- STP BackboneFast
 - configuring [32-15](#)
 - figure
 - adding a switch [32-18](#)
 - spanning-tree backbonefast
 - command [32-15, 32-16](#)
 - command example [32-15, 32-16](#)
 - understanding [32-13](#)
- STP BPDU Guard
 - configuring [32-7](#)
 - spanning-tree portfast bpdu-guard
 - command [32-8](#)
 - understanding [32-7](#)
- STP bridge ID [31-3](#)
- STP EtherChannel guard [32-16](#)
- STP extensions
 - description [?? to 32-20](#)
- STP loop guard
 - configuring [32-19](#)
 - overview [32-17](#)
- STP PortFast
 - BPDUs filter
 - configuring [32-10](#)
 - BPDUs filtering [32-9](#)
 - configuring [32-2](#)
 - spanning-tree portfast
 - command [32-2, 32-3, 32-4](#)
 - command example [32-3, 32-4](#)
 - understanding [32-2](#)
- STP port types
 - normal [32-3](#)
- STP root guard [32-17](#)
- STP UplinkFast
 - configuring [32-12](#)
 - spanning-tree uplinkfast
 - command [32-13](#)
 - command example [32-13](#)
 - understanding [32-11](#)
- subdomains, private VLAN [27-5](#)
- supervisor engine
 - environmental monitoring [15-1](#)
 - redundancy [9-1](#)
 - synchronizing configurations [9-4](#)
- supervisor engine redundancy
 - configuring [9-2](#)
- supervisor engines
 - displaying redundancy configuration [9-4](#)

suppliant 83-7
 surveillance 86-7
 Switched Port Analyzer 56-1
 switch fabric functionality 18-1
 monitoring 18-2
 switchport
 configuring 21-14
 example 21-13
 show interfaces 10-8, 10-9, 21-6, 21-13
 switchport access vlan 21-6, 21-7, 21-10, 21-14
 example 21-15
 switchport mode access 21-4, 21-6, 21-7, 21-14
 example 21-15
 switchport mode dynamic 21-9
 switchport mode dynamic auto 21-4
 switchport mode dynamic desirable 21-4
 default 21-5
 example 21-13
 switchport mode trunk 21-4, 21-9
 switchport nonegotiate 21-4
 switchport trunk allowed vlan 21-11
 switchport trunk encapsulation 21-7, 21-9
 switchport trunk encapsulation dot1q
 example 21-13
 switchport trunk encapsulation negotiate
 default 21-5
 switchport trunk native vlan 21-11
 switchport trunk pruning vlan 21-12
 switch priority
 MSTP 31-43
 switch TopN reports
 foreground execution 58-2
 running 58-3
 viewing 58-3
 SXP 70-2
 system event archive (SEA) 54-1

T

TDR
 checking cable connectivity 10-14
 enabling and disabling test 10-14
 guidelines 10-14
 Telnet
 accessing CLI 2-2
 Time Domain Reflectometer 10-14
 TLV
 host presence detection 19-4, 83-14, 85-4
 traceroute, Layer 2
 and ARP 59-2
 and CDP 59-1
 described 59-2
 IP addresses and subnets 59-2
 MAC addresses and VLANs 59-2
 multicast traffic 59-2
 multiple devices on a port 59-2
 unicast traffic 59-2
 usage guidelines 59-1
 traffic-storm control
 command
 broadcast 81-4
 described 81-2
 monitoring 81-5
 thresholds 81-2
 traffic suppression
 see traffic-storm control
 transmit queues
 see QoS transmit queues
 traps, see SNMP notifications
 trunks 21-4
 802.1Q Restrictions 21-2
 allowed VLANs 21-11
 configuring 21-8
 default interface configuration 21-6
 default VLAN 21-10
 different VTP domains 21-4

- native VLAN [21-11](#)
- to non-DTP device [21-4](#)
- VLAN 1 minimization [21-12](#)
- trusted boundary [19-6](#)
- trusted boundary (extended trust for CDP devices) [19-4](#)
- tunneling [67-4, 67-26](#)
- tunneling, 802.1Q
 - See 802.1Q [29-4](#)
- type length value
 - See TLV

U

- UDE
 - configuration [36-5](#)
 - overview [36-4](#)
- UDE and UDLR [36-1](#)
- UDLD
 - default configuration [11-4](#)
 - enabling
 - globally [11-5](#)
 - on ports [11-5, 11-6](#)
 - overview [11-2](#)
- UDLR [36-1](#)
 - back channel [36-3](#)
 - configuration [36-6](#)
 - tunnel
 - (example) [36-7](#)
 - ARP and NHRP [36-4](#)
- UDLR (unidirectional link routing) [36-1](#)
- UDP port for SNMP notifications [86-12](#)
- UMFB [82-2](#)
- unauthorized ports with 802.1X [83-12](#)
- unicast storms
 - see traffic-storm control
- Unidirectional Ethernet [36-1](#)
- unidirectional ethernet
 - example of setting [36-5](#)
- UniDirectional Link Detection Protocol

- see UDLD
- uniform mode
 - configuring [67-34](#)
- unknown multicast flood blocking
 - See UMFB
- unknown unicast and multicast flood blocking [82-1](#)
- unknown unicast flood blocking
 - See UUFb
- unknown unicast flood rate-limiting
 - See UUFRL
- UplinkFast
 - See STP UplinkFast
- URD [44-26](#)
- User-Based Rate Limiting [63-6, 63-15](#)
- user EXEC mode [2-5](#)
- UUFb [82-2](#)
- UUFRL [82-2](#)

V

- VACLs [74-2](#)
 - configuring
 - examples [74-5](#)
 - Layer 3 VLAN interfaces [74-5](#)
 - Layer 4 port operations [69-2](#)
 - logging
 - configuration example [74-8](#)
 - configuring [74-7](#)
 - restrictions [74-7](#)
 - MAC address based [74-2](#)
 - multicast packets [73-6](#)
 - SVIs [74-5](#)
 - WAN interfaces [74-2](#)
- vlan
 - command [26-5, 26-6, 56-20](#)
 - command example [26-6](#)
- VLAN Access Control Lists
 - See VACLs
- VLAN-based QoS filtering [69-10](#)

- VLAN-bridge spanning-tree protocol [35-1](#)
- vlan database
 - command [26-5, 26-6, 56-20](#)
- vlan group command [83-44](#)
- VLAN locking [26-4](#)
- vlan mapping dot1q
 - command [26-8, 26-9](#)
- VLAN maps
 - applying [73-8](#)
- VLAN mode [39-3](#)
- VLAN port provisioning verification [26-4](#)
- VLANs
 - allowed on trunk [21-11](#)
 - configuration guidelines [26-2](#)
 - configuring [26-1](#)
 - configuring (tasks) [26-4](#)
 - defaults [26-3](#)
 - extended range [26-3](#)
 - interface assignment [26-6](#)
 - multicast [47-2](#)
 - name (default) [26-3](#)
 - normal range [26-3](#)
 - reserved range [26-3](#)
 - support for 4,096 VLANs [26-2](#)
 - token ring [26-3](#)
 - trunks
 - understanding [21-4](#)
 - understanding [26-2](#)
 - VLAN 1 minimization [21-12](#)
 - VTP domain [26-4](#)
- VLAN translation
 - command example [26-9](#)
- voice VLAN
 - Cisco 7960 phone, port connections [19-2](#)
 - configuration guidelines [19-1](#)
 - configuring IP phone for data traffic
 - override CoS of incoming frame [19-6, 20-5](#)
 - configuring ports for voice traffic in
 - 802.1Q frames [19-5](#)
 - connecting to an IP phone [19-5](#)
 - default configuration [19-4](#)
 - overview [19-2](#)
- voice VLAN. See also port-based authentication. [83-22](#)
- VPN
 - configuration example [38-4](#)
 - guidelines and restrictions [38-2](#)
- VPN supported commands [38-2](#)
- VPN switching [38-1](#)
- VSS
 - dual-active detection
 - Enhanced PAgP, advantages [4-27](#)
 - Enhanced PAgP, description [4-28](#)
 - enhanced PAgP, description [4-50](#)
 - fast-hello, advantages [4-27](#)
 - fast-hello, description [4-28](#)
 - VSLP fast-hello, configuration [4-51](#)
- VSS Quad-Sup SSO (V4SO) [4-9](#)
- VTP
 - advertisements [25-4, 25-5](#)
 - client, configuring [25-15](#)
 - configuration guidelines [25-1](#)
 - default configuration [25-9](#)
 - disabling [25-15](#)
 - domains [25-3](#)
 - VLANs [26-4](#)
 - modes
 - client [25-4](#)
 - server [25-4](#)
 - transparent [25-4](#)
 - monitoring [25-17](#)
 - overview [25-2](#)
 - per-port enable and disable [25-16](#)
 - pruning
 - configuration [21-12](#)
 - configuring [25-12](#)
 - overview [25-7](#)
 - server, configuring [25-15](#)
 - statistics [25-17](#)

transparent mode, configuring [25-15](#)

version 2

enabling [25-13](#)

overview [25-5](#)

version 3

enabling [25-13](#)

overview [25-6](#)

server type, configuring [25-11](#)

W

wake-on-LAN. See also port-based authentication. [83-28](#)

web-based authentication

AAA fail policy [84-5](#)

description [84-2](#)

wiretaps [86-4](#)

