



Stack Manager and High Availability Commands

- [debug platform stack-manager](#), on page 2
- [maintenance-template](#), on page 3
- [main-cpu](#), on page 4
- [mode sso](#), on page 5
- [policy config-sync prc reload](#), on page 6
- [redundancy](#), on page 7
- [redundancy config-sync mismatched-commands](#), on page 8
- [redundancy force-switchover](#), on page 10
- [redundancy reload](#), on page 11
- [reload](#), on page 12
- [router routing protocol shutdown 12](#), on page 14
- [session](#), on page 15
- [show redundancy](#), on page 16
- [show redundancy config-sync](#), on page 20
- [show switch](#), on page 22
- [show switch stack-mode](#), on page 25
- [show switch stack-bandwidth](#), on page 26
- [show switch stack-ring speed](#), on page 27
- [show tech-support stack](#), on page 28
- [stack-mac persistent timer](#), on page 34
- [stack-mac update force](#), on page 36
- [standby console enable](#), on page 37
- [start maintenance](#), on page 38
- [stop maintenance](#), on page 39
- [switch clear stack-mode](#), on page 40
- [switch priority](#), on page 41
- [switch provision](#), on page 42
- [switch renumber](#), on page 44
- [switch renumber](#), on page 45
- [switch stack port](#), on page 46
- [switch stack-speed](#), on page 47
- [switch switch-number role](#), on page 48
- [system mode maintenance](#), on page 49

debug platform stack-manager

To enable debugging of the stack manager software, use the **debug platform stack-manager** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug platform stack-manager {all | rpc | sdp | sim | ssm | trace}

no debug platform stack-manager {all | rpc | sdp | sim | ssm | trace}

Syntax Description

all	Displays all stack manager debug messages.
rpc	Displays stack manager remote procedure call (RPC) usage debug messages.
sdp	Displays the Stack Discovery Protocol (SDP) debug messages.
sim	Displays the stack information module debug messages.
ssm	Displays the stack state-machine debug messages.
trace	Traces the stack manager entry and exit debug messages.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines

This command is supported only on stacking-capable switches.

The **undebug platform stack-manager** command is the same as the **no debug platform stack-manager** command.

When you enable debugging on a switch stack, it is enabled only on the stack master. To enable debugging on a stack member, you can start a session from the stack master by using the **session switch-number EXEC** command. Enter the **debug** command at the command-line prompt of the stack member. You also can use the **remote command stack-member-number LINE EXEC** command on the stack master switch to enable debugging on a member switch without first starting a session.

maintenance-template

To create a maintenance template, use the **maintenance-template** *template_name* command in the global configuration mode. To delete the template, use the **no** form of the command.

maintenance-template *template_name*
no maintenance-template *template_name*

Syntax Description	maintenance-template	Creates a template for GIR with a specific name.
	<i>template_name</i>	Name of the maintenance template.
Command Default	Disabled.	
Command Modes	Global configuration (config)	
Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Example:

The following example shows how to configure a maintenance template with the name g1:

```
Device(config)# maintenance template g1
```

main-cpu

To enter the redundancy main configuration submode and enable the standby switch, use the **main-cpu** command in redundancy configuration mode.

main-cpu

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Redundancy configuration (config-red)
----------------------	---------------------------------------

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines	From the redundancy main configuration submode, use the standby console enable command to enable the standby switch.
-------------------------	---

This example shows how to enter the redundancy main configuration submode and enable the standby switch:

```
Device (config) # redundancy
Device (config-red) # main-cpu
Device (config-r-mc) # standby console enable
Device#
```

mode sso

To set the redundancy mode to stateful switchover (SSO), use the **mode sso** command in redundancy configuration mode.

mode sso

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Redundancy configuration
----------------------	--------------------------

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines The **mode sso** command can be entered only from within redundancy configuration mode.

Follow these guidelines when configuring your system to SSO mode:

- You must use identical Cisco IOS images on the switches in the stack to support SSO mode. Redundancy may not work due to differences between the Cisco IOS releases.
- If you perform an online insertion and removal (OIR) of the module, the switch resets during the stateful switchover and the port states are restarted only if the module is in a transient state (any state other than Ready).
- The forwarding information base (FIB) tables are cleared on a switchover. Routed traffic is interrupted until route tables reconverge.

This example shows how to set the redundancy mode to SSO:

```
Device(config)# redundancy
Device(config-red) # mode sso
Device(config-red) #
```

policy config-sync prc reload

To reload the standby switch if a parser return code (PRC) failure occurs during configuration synchronization, use the **policy config-sync reload** command in redundancy configuration mode. To specify that the standby switch is not reloaded if a parser return code (PRC) failure occurs, use the **no** form of this command.

```
policy config-sync {bulk | lbl} prc reload
no policy config-sync {bulk | lbl} prc reload
```

Syntax Description	bulk Specifies bulk configuration mode.				
	lbl Specifies line-by-line (lbl) configuration mode.				
Command Default	The command is enabled by default.				
Command Modes	Redundancy configuration (config-red)				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Everest 16.5.1a</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Everest 16.5.1a	This command was introduced.
Release	Modification				
Cisco IOS XE Everest 16.5.1a	This command was introduced.				

This example shows how to specify that the standby switch is not reloaded if a parser return code (PRC) failure occurs during configuration synchronization:

```
Device(config-red)# no policy config-sync bulk prc reload
```

redundancy

To enter redundancy configuration mode, use the **redundancy** command in global configuration mode.

redundancy

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines The redundancy configuration mode is used to enter the main CPU submode, which is used to enable the standby switch.

To enter the main CPU submode, use the **main-cpu** command while in redundancy configuration mode.

From the main CPU submode, use the **standby console enable** command to enable the standby switch.

Use the **exit** command to exit redundancy configuration mode.

This example shows how to enter redundancy configuration mode:

```
(config)# redundancy
(config-red)#
```

This example shows how to enter the main CPU submode:

```
(config)# redundancy
(config-red)# main-cpu
(config-r-mc)#
```

Related Commands	Command	Description
	show redundancy	Displays redundancy facility information.

redundancy config-sync mismatched-commands

To allow the standby switch to join the stack if a configuration mismatch occurs between the active and standby switches, use the **redundancy config-sync mismatched-commands** command in privileged EXEC mode.

redundancy config-sync {ignore | validate} mismatched-commands

Syntax Description	
ignore	Ignores the mismatched command list.
validate	Revalidates the mismatched command list with the modified running-configuration.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines If the command syntax check in the running configuration of the active switch fails while the standby switch is booting, use the **redundancy config-sync mismatched-commands** command to display the Mismatched Command List (MCL) on the active switch and to reboot the standby switch.

The following is a log entry example for mismatched commands:

```
00:06:31: Config Sync: Bulk-sync failure due to Servicing Incompatibility. Please check
full list of mismatched commands via:
show redundancy config-sync failures mcl
00:06:31: Config Sync: Starting lines from MCL file:
interface GigabitEthernet7/7
! <submode> "interface"
- ip address 192.0.2.0 255.255.255.0
! </submode> "interface"
```

To display all mismatched commands, use the **show redundancy config-sync failures mcl** command.

To clean the MCL, follow these steps:

1. Remove all mismatched commands from the running configuration of the active switch.
2. Revalidate the MCL with a modified running configuration by using the **redundancy config-sync validate mismatched-commands** command.
3. Reload the standby switch.

You can ignore the MCL by doing the following:

1. Enter the **redundancy config-sync ignore mismatched-commands** command.
2. Reload the standby switch; the system changes to SSO mode.



Note If you ignore the mismatched commands, the out-of-sync configuration at the active switch and the standby switch still exists.

3. Verify the ignored MCL with the **show redundancy config-sync ignored mcl** command.

If SSO mode cannot be established between the active and standby switches because of an incompatibility in the configuration file, a mismatched command list (MCL) is generated at the active switch and a reload into route processor redundancy (RPR) mode is forced for the standby switch.

This example shows how to revalidate the mismatched command list with the modified configuration:

```
# redundancy config-sync validate mismatched-commands  
#
```

redundancy force-switchover

To force a switchover from the active switch to the standby switch, use the **redundancy force-switchover** command in privileged EXEC mode.

redundancy force-switchover

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines Use the **redundancy force-switchover** command to manually switch over to the redundant switch. The redundant switch becomes the new active switch that runs the Cisco IOS XE image, and the modules are reset to their default settings. The old active switch reboots with the new image.

If you use the **redundancy force-switchover** command on the active switch, the switchports on the active switch go down.

If you use this command on a switch that is in a partial ring stack, the following warning message appears:

```
Device# redundancy force-switchover

Stack is in Half ring setup; Reloading a switch might cause stack split
This will reload the active unit and force switchover to standby[confirm]
```

This example shows how to manually switch over from the active to the standby supervisor engine:

```
Device# redundancy force-switchover
Device#
```

redundancy reload

To force a reload of one or all of the switches in the stack, use the **redundancy reload** command in privileged EXEC mode.

redundancy reload {**peer** | **shelf**}

Syntax Description

peer Reloads the peer unit.

shelf Reboots all switches in the stack.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines

Before using this command, see the “Performing a Software Upgrade” section of the for additional information. Use the **redundancy reload shelf** command to reboot all the switches in the stack.

This example shows how to manually reload all switches in the stack:

```
# redundancy reload shelf
#
```

reload

To reload the stack member and to apply a configuration change, use the **reload** command in privileged EXEC mode.

reload [{/noverify | /verify}] [{LINE | at | cancel | in | slot *stack-member-number* | standby-cpu}]

Syntax Description		
/noverify	(Optional)	Specifies to not verify the file signature before the reload.
/verify	(Optional)	Verifies the file signature before the reload.
<i>LINE</i>	(Optional)	Reason for the reload.
at	(Optional)	Specifies the time in hh:mm for the reload to occur.
cancel	(Optional)	Cancels the pending reload.
in	(Optional)	Specifies a time interval for reloads to occur.
slot	(Optional)	Saves the changes on the specified stack member and then restarts it.
<i>stack-member-number</i>		
standby-cpu	(Optional)	Reloads the standby route processor (RP).

Command Default Immediately reloads the stack member and puts a configuration change into effect.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines If there is more than one switch in the switch stack, and you enter the **reload slot *stack-member-number*** command, you are not prompted to save the configuration.

Examples

This example shows how to reload the switch stack:

```
Device# reload
System configuration has been modified. Save? [yes/no]: y
Proceed to reload the whole Stack? [confirm] y
```

This example shows how to reload a specific stack member:

```
Device# reload slot 6
Proceed with reload? [confirm] y
```

This example shows how to reload a single-switch switch stack (there is only one member switch):

```
Device# reload slot 3
System configuration has been modified. Save? [yes/no]: y
Proceed to reload the whole Stack? [confirm] y
```

router routing protocol shutdown l2

To create instances that should be isolated within a maintenance template, use the **router** *routing_protocol instance_id* | **shutdown l2** command in the maintenance template configuration mode. To delete the instance, use the **no** form of the command.

```
{ router routing_protocol instance_id | shutdown l2 }
no{ router routing_protocol instance_id | shutdown l2 }
```

Syntax Description	router	Configures instance associated with routing protocol.
	<i>routing_protocol</i>	Routing protocol defined for the template.
	<i>instance_id</i>	Instance ID associated with the routing protocol.
	shutdown l2	Configures instance to shut down layer 2 interfaces.
Command Default	Disabled.	
Command Modes	Maintenance template configuration (config-maintenance-templ)	
Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Example:

The following example shows how to create an instance for ISIS with an instance ID of one under maintenance template temp1:

```
Device(config)# maintenance template g1
Device(config-maintenance-templ)# router isis 1
```

The following example shows how to create an instance for shutting down layer 2 interfaces under maintenance template g1:

```
Device(config)# maintenance template g1
Device(config-maintenance-templ)# shutdown l2
```

session

To access a specific stack member use the **session** command in privileged EXEC mode on the stack master.

session *stack-member-number*

Syntax Description

stack-member-number Stack member number to access from the .

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines

When you access the member, its member number is appended to the system prompt.

Use the **session** command from the master to access a member

Use the **session** command with **processor 1** from the master or a standalone switch to access the internal controller. A standalone is always member 1.

Examples

This example shows how to access stack member 3:

```
# session 3
-3#
```

show redundancy

To display redundancy facility information, use the **show redundancy** command in privileged EXEC mode

```
show redundancy [{clients | config-sync | counters | history [{reload | reverse}]] | slaves[slave-name]
{clients | counters} | states | switchover history [domain default]]]
```

Syntax Description	
clients	(Optional) Displays information about the redundancy facility client.
config-sync	(Optional) Displays a configuration synchronization failure or the ignored mismatched command list (MCL).
counters	(Optional) Displays information about the redundancy facility counter.
history	(Optional) Displays a log of past status and related information for the redundancy facility.
history reload	(Optional) Displays a log of past reload information for the redundancy facility.
history reverse	(Optional) Displays a reverse log of past status and related information for the redundancy facility.
slaves	(Optional) Displays all standby switches in the redundancy facility.
<i>slave-name</i>	(Optional) The name of the redundancy facility standby switch to display specific information for. Enter additional keywords to display all clients or counters in the specified standby switch.
clients	Displays all redundancy facility clients in the specified secondary switch.
counters	Displays all counters in the specified standby switch.
states	(Optional) Displays information about the redundancy facility state, such as disabled, initialization, standby or active.
switchover history	(Optional) Displays information about the redundancy facility switchover history.
domain default	(Optional) Displays the default domain as the domain to display switchover history for.

Command Default None

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

This example shows how to display information about the redundancy facility:

```
Device# show redundancy
```



```

Redundant System Information :
-----
    Available system uptime = 6 days, 5 hours, 28 minutes
Switchovers system experienced = 0
    Standby failures = 0
    Last switchover reason = none

    Hardware Mode = Duplex
Configured Redundancy Mode = sso
Operating Redundancy Mode = sso
Maintenance Mode = Disabled
Communications = Up

Current Processor Information :
-----
    Active Location = slot 5
    Current Software state = ACTIVE
    Uptime in current state = 6 days, 5 hours, 28 minutes
    Image Version = Cisco IOS Software, Catalyst L3 Switch Software
(CAT9K_IOSXE), Experimental Version 16.x.x [S2C-build-v16x_throttle-4064-/
nobackup/mcpre/BLD-BLD_V16x_THROTTLE_LATEST 102]
Copyright (c) 1986-201x by Cisco Systems, Inc.
Compiled Mon 07-Oct-xx 03:57 by mcpre
    BOOT = bootflash:packages.conf;
Configuration register = 0x102

Peer Processor Information :
-----
    Standby Location = slot 6
    Current Software state = STANDBY HOT
    Uptime in current state = 6 days, 5 hours, 25 minutes
    Image Version = Cisco IOS Software, Catalyst L3 Switch Software
(CAT9K_IOSXE), Experimental Version 16.x.x [S2C-build-v16x_throttle-4064-/
nobackup/mcpre/BLD-BLD_V16x_THROTTLE_LATEST_20191007_000645 102]
Copyright (c) 1986-201x by Cisco Systems, Inc.
Compiled Mon 07-Oct-xx 03:57 by mcpre
    BOOT = bootflash:packages.conf;
CONFIG_FILE =
Configuration register = 0x102

Device#

```

This example shows how to display redundancy facility client information:

```
Device# show redundancy clients
```

```

Group ID =      1
clientID = 29      clientSeq = 60      Redundancy Mode RF
clientID = 139     clientSeq = 62      IfIndex
clientID = 25      clientSeq = 71      CHKPT RF
clientID = 10001   clientSeq = 85      QEMU Platform RF
clientID = 77      clientSeq = 87      Event Manager
clientID = 1340    clientSeq = 104     RP Platform RF
clientID = 1501    clientSeq = 105     CWAN HA
clientID = 78      clientSeq = 109     TSPTUN HA
clientID = 305     clientSeq = 110     Multicast ISSU Consolidation RF
clientID = 304     clientSeq = 111     IP multicast RF Client
clientID = 22      clientSeq = 112     Network RF Client
clientID = 88      clientSeq = 113     HSRP
clientID = 114     clientSeq = 114     GLBP
clientID = 225     clientSeq = 115     VRRP
clientID = 4700    clientSeq = 118     COND_DEBUG RF
clientID = 1341    clientSeq = 119     IOSXE DPIDX
clientID = 1505    clientSeq = 120     IOSXE SPA TSM
clientID = 75      clientSeq = 130     Tableid HA

```

```
clientID = 501      clientSeq = 137      LAN-Switch VTP VLAN
```

<output truncated>

The output displays the following information:

- clientID displays the client's ID number.
- clientSeq displays the client's notification sequence number.
- Current redundancy facility state.

This example shows how to display the redundancy facility counter information:

```
Device# show redundancy counters
```

```
Redundancy Facility OMs
  comm link up = 0
  comm link down = 0

  invalid client tx = 0
  null tx by client = 0
  tx failures = 0
  tx msg length invalid = 0

  client not rxing msgs = 0
  rx peer msg routing errors = 0
  null peer msg rx = 0
  errored peer msg rx = 0

  buffers tx = 135884
  tx buffers unavailable = 0
  buffers rx = 135109
  buffer release errors = 0

  duplicate client registers = 0
  failed to register client = 0
  Invalid client syncs = 0
```

```
Device#
```

This example shows how to display redundancy facility history information:

```
Device# show redundancy history
```

```
00:00:04 client added: Redundancy Mode RF(29) seq=60
00:00:04 client added: IfIndex(139) seq=62
00:00:04 client added: CHKPT RF(25) seq=71
00:00:04 client added: QEMU Platform RF(10001) seq=85
00:00:04 client added: Event Manager(77) seq=87
00:00:04 client added: RP Platform RF(1340) seq=104
00:00:04 client added: CWAN HA(1501) seq=105
00:00:04 client added: Network RF Client(22) seq=112
00:00:04 client added: IOSXE SPA TSM(1505) seq=120
00:00:04 client added: LAN-Switch VTP VLAN(501) seq=137
00:00:04 client added: XDR RRP RF Client(71) seq=139
00:00:04 client added: CEF RRP RF Client(24) seq=140
00:00:04 client added: MFIB RRP RF Client(306) seq=150
00:00:04 client added: RFS RF(520) seq=163
00:00:04 client added: klib(33014) seq=167
00:00:04 client added: Config Sync RF client(5) seq=168
00:00:04 client added: NGWC FEC Rf client(10007) seq=173
00:00:04 client added: LAN-Switch Port Manager(502) seq=190
00:00:04 client added: Access Tunnel(530) seq=192
```

```
00:00:04 client added: Mac address Table Manager(519) seq=193
00:00:04 client added: DHCP(100) seq=238
00:00:04 client added: DHCP(101) seq=239
00:00:04 client added: SNMP RF Client(34) seq=251
00:00:04 client added: CWAN APS HA RF Client(1502) seq=252
00:00:04 client added: History RF Client(35) seq=261
```

<output truncated>

This example shows how to display information about the redundancy facility standby switches:

```
Device# show redundancy slaves
```

```
Group ID = 1
Slave/Process ID = 6107 Slave Name = [installer]
Slave/Process ID = 6109 Slave Name = [eicored]
Slave/Process ID = 6128 Slave Name = [snmp_subagent]
Slave/Process ID = 8897 Slave Name = [wcm]
Slave/Process ID = 8898 Slave Name = [table_mgr]
Slave/Process ID = 8901 Slave Name = [iosd]
```

```
Device#
```

This example shows how to display information about the redundancy facility state:

```
Device# show redundancy states
```

```
my state = 13 -ACTIVE
peer state = 8 -STANDBY HOT
Mode = Duplex
Unit = Primary
Unit ID = 5

Redundancy Mode (Operational) = sso
Redundancy Mode (Configured) = sso
Redundancy State = sso
Maintenance Mode = Disabled
Manual Swact = enabled
Communications = Up

client count = 115
client_notification_TMR = 30000 milliseconds
RF debug mask = 0x0

Device#
```

show redundancy config-sync

To display a configuration synchronization failure or the ignored mismatched command list (MCL), if any, use the **show redundancy config-sync** command in EXEC mode.

show redundancy config-sync {failures {bem | mcl | prc} | ignored failures mcl}

Syntax Description	failures	Displays MCL entries or best effort method (BEM)/Parser Return Code (PRC) failures.
	bem	Displays a BEM failed command list, and forces the standby switch to reboot.
	mcl	Displays commands that exist in the switch's running configuration but are not supported by the image on the standby switch, and forces the standby switch to reboot.
	prc	Displays a PRC failed command list and forces the standby switch to reboot.
	ignored failures mcl	Displays the ignored MCL failures.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines When two versions of Cisco IOS images are involved, the command sets supported by two images might differ. If any of those mismatched commands are executed on the active switch, the standby switch might not recognize those commands, which causes a configuration mismatch condition. If the syntax check for the command fails on the standby switch during a bulk synchronization, the command is moved into the MCL and the standby switch is reset. To display all the mismatched commands, use the **show redundancy config-sync failures mcl** command.

To clean the MCL, follow these steps:

1. Remove all mismatched commands from the active switch's running configuration.
2. Revalidate the MCL with a modified running configuration by using the **redundancy config-sync validate mismatched-commands** command.
3. Reload the standby switch.

Alternatively, you could ignore the MCL by following these steps:

1. Enter the **redundancy config-sync ignore mismatched-commands** command.
2. Reload the standby switch; the system transitions to SSO mode.



Note If you ignore the mismatched commands, the out-of-synchronization configuration on the active switch and the standby switch still exists.

3. You can verify the ignored MCL with the **show redundancy config-sync ignored mcl** command.

Each command sets a return code in the action function that implements the command. This return code indicates whether or not the command successfully executes. The active switch maintains the PRC after executing a command. The standby switch executes the command and sends the PRC back to the active switch. A PRC failure occurs if these two PRCs do not match. If a PRC error occurs at the standby switch either during bulk synchronization or line-by-line (LBL) synchronization, the standby switch is reset. To display all PRC failures, use the **show redundancy config-sync failures prc** command.

To display best effort method (BEM) errors, use the **show redundancy config-sync failures bem** command.

This example shows how to display the BEM failures:

```
Device> show redundancy config-sync failures bem
BEM Failed Command List
-----

The list is Empty
```

This example shows how to display the MCL failures:

```
Device> show redundancy config-sync failures mcl
Mismatched Command List
-----

The list is Empty
```

This example shows how to display the PRC failures:

```
Device# show redundancy config-sync failures prc
PRC Failed Command List
-----

The list is Empty
```

show switch

To display information that is related to the stack member or the switch stack, use the **show switch** command in EXEC mode.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.
	Cisco IOS XE Amsterdam 17.3.1	Added the keyword detail to the command – show switch stack-ports detail

Examples

This example shows how to display the member 6 summary information:

```
Device# show switch 6
Switch# Role      Mac Address      Priority   State
-----
6      Member      0003.e31a.1e00   1         Ready
```

This example shows how to display the neighbor information for a stack:

```
Device# show switch neighbors
Switch #   Port A   Port B
-----
6          None     8
8          6       None
```

This example shows how to display stack-port information:

```
Device# show switch stack-ports
Switch #   Port A   Port B
-----
6          Down     Ok
8          Ok       Down
```

This is an example output from the **show switch stack-ports detail** command.

```
Device# show switch stack-ports detail
1/1 is OK Loopback No
Cable Length 50cm      Neighbor 2
Link Ok Yes Sync Ok Yes Link Active Yes
Changes to LinkOK 1
Five minute input rate 430998 packets/sec
Five minute output rate 100989 packets/sec
2198108 packets input, 17584864 bytes
553113 packets output, 4424904 bytes
CRC Errors
      Data CRC 0
      Ringword CRC 0
      InvRingWord 0
```

```

PcsCodeWord 0
1/2 is OK Loopback No
Cable Length 50cm Neighbor 3
Link Ok Yes Sync Ok Yes Link Active Yes
Changes to LinkOK 1
Five minute input rate 743042 packets/sec
Five minute output rate 79830 packets/sec
3765816 packets input, 30126528 bytes
439001 packets output, 3512008 bytes
CRC Errors
Data CRC 0
Ringword CRC 0
InvRingWord 0
PcsCodeWord 0
...
...
...
...

```

Table 1: show switch stack-ports detail Command Output

Field	Description
Neighbor	Switch number of the active member at the other end of the stack cable.
Cable Length	Valid lengths are 50 cm, 1 m, or 3 m. If the switch cannot detect the cable length, the value is <i>Unknown</i> . The cable might not be connected, or the link might be unreliable.
Link OK	Whether the stack cable is connected and functional. There may or may not be a neighbor connected on the other end. The <i>link partner</i> is a stack port on a neighbor switch. <ul style="list-style-type: none"> • No: There is no stack cable connected to this port or the stack cable is not functional. • Yes: There is a functional stack cable connected to this port.
Link Active	Whether a neighbor is connected on the other end of the stack cable. <ul style="list-style-type: none"> • No: No neighbor is detected on the other end. The port cannot send traffic over this link. • Yes: A neighbor is detected on the other end. The port can send traffic over this link.
Sync OK	Whether the link partner sends valid protocol messages to the stack port. <ul style="list-style-type: none"> • No: The link partner does not send valid protocol messages to the stack port. • Yes: The link partner sends valid protocol messages to the port.
#Changes to LinkOK	The relative stability of the link. If a large number of changes occur in a short period of time, link flapping can occur.

Field	Description
Five minute input rate	The average rate (calculated over a five minute period) at which packets are received, measured in packets/sec.
Five minute output rate	The average rate (calculated over a five minute period) at which packets are transmitted, measured in packets/sec.
CRC Errors	<p>Different types of Cyclic Redundancy Check (CRC) errors that are seen on a stack interface:</p> <ul style="list-style-type: none"> • Data CRC: Stack interface data CRC error • Ringword CRC: Stack interface ring word CRC error • InvRingWord: Stack interface invalid ring word error • PcsCodeWord: Stack interface Physical Coding Sublayer (PCS) error <p>These errors normally occur when a stack interface state changes due to a switchover or a switch reload. You can ignore such errors.</p> <p>But when these error counters increase significantly or when they increase continuously over a period of time, check the stack cable for issues.</p> <p>Use the clear counters command to clear the stack counters for all ports.</p>

show switch stack-mode

To display and verify the current stack mode on a device, use the **show switch stack-mode** command in privileged EXEC mode.

show switch stack-mode

Command Default None

Command Modes privileged EXEC

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

The **show switch stack-mode** command displays detailed status of the currently running stack mode. Fields displayed for each one of the devices in the stack include: the role of the device, its MAC address, the stack mode after reboot, the current stack mode, and so on.

```
Device# show switch stack-mode
Switch  Role    Mac Address    Version  Mode    Configured  State
-----
1       Member  3c5e.c357.c880          1+1'    Active'  Ready
*2      Active  547c.69de.cd00    V05     1+1'    Standby'  Ready
3       Member  547c.6965.cf80    V05     1+1'    Member'   Ready
```

The Mode field indicates the current stack mode

The Configured field refers to the device state expected after a reboot.

Single quotation marks (') indicate that the stack mode has been changed.

show switch stack-bandwidth

to display the current switch stack bandwidth and the bandwidth after the next reload, use the **show switch stack-bandwidth** command in the Privileged EXEC mode.

show switch stack-bandwidth

Syntax Description	stack-bandwidth	Displays the current switch stack bandwidth and the bandwidth after the next reload.
Command Default	None.	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

The following example shows the sample output for **show switch stack-bandwidth** command.

```
Device#show switch stack-bandwidth
Stack Current Next-boot
Switch# Role Bandwidth State Bandwidth
-----
*1 Active 480G Ready 1000G
2 Standby 480G Ready 1000G
3 Member 480G Ready 1000G
```

show switch stack-ring speed

To display the current switch stack ring speed and the speed after the next reload, use the **show switch stack-speed** command in the Privileged EXEC mode.

show switch stack-ring speed

Syntax Description	speed	Displays the current switch stack ring speed and the speed after the next reload.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Bengaluru 17.5.1	This command was introduced.

The following example shows a sample output for the **switch stack-ring speed** command.

```
Device#show switch stack-ring speed
Stack Ring Speed : 1000G
Stack Ring Configuration: Full
Stack Ring Protocol : StackWise
Stack Ring Next-boot Speed: 1000G.
```

show tech-support stack

To display all switch stack-related information for use by technical support, use the **show tech-support stack** command in privileged EXEC mode.

show tech-support stack

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Gibraltar 16.12.1	The output for this command was enhanced to include more stack-related information.

Usage Guidelines

The **show tech-support stack** command captures the snapshot of stacking states and information for debug issues. Use this command, when stacking issues (such as stack cable issue, silent reload, switch not coming to ready state, stack crash, and so on) occur.

The output of the **show tech-support stack** command is very long. To better manage this output, you can redirect the output to a file (for example, **show tech-support stack | redirect flash:filename**) in the local writable storage file system or remote file system.

The output of the **show tech stack** command displays the output of the following commands:

Cisco Catalyst 9300 Series Switches

- **show clock**
- **show version**
- **show running-config**
- **show redundancy switchover history**
- **show switch stack-ports summary**
- **show switch stack-mode**
- **show switch stack-ring speed**
- **show switch stack-bandwidth**
- **show switch detail**
- **show switch neighbors**

The following commands are only available on stacked switches in ready state

- **show platform software stack-mgr switch**
- **show platform software sif switch**
- **show platform hardware fed switch**

- **dir crashinfo:**
- **dir flash:/core**

The following commands are only available on non-stackable switches in ready state:

- **show redundancy switchover history**
- **show platform software fed switch active**
- **show platform software fed switch standby**
- **show stackwise-virtual bandwidth**
- **show stackwise-virtual dual-active-detection**
- **show stackwise-virtual link**
- **show stackwise-virtual neighbors**
- **dir crashinfo:**
- **dir flash:/core**

Examples

The following is sample output from the **show tech-support stack** command:

```
Device# show tech-support stack
```

```
.
.
.
```

```
-----show switch stack-ports summary -----
```

Sw#/Port#	Port Status to LinkOK	Neighbor In Loopback	Cable Length	Link OK	Link Active	Sync OK	#Changes
1/1	OK No	3	50cm	Yes	Yes	Yes	1
1/2	OK No	2	50cm	Yes	Yes	Yes	1
2/1	OK No	1	50cm	Yes	Yes	Yes	1
2/2	OK No	3	50cm	Yes	Yes	Yes	1
3/1	OK No	2	50cm	Yes	Yes	Yes	1
3/2	OK No	1	50cm	Yes	Yes	Yes	1

```
----- show switch stack-mode -----
```

Switch#	Role	Mac Address	Version	Mode	Configured	State
*1	Active	046c.9d1e.f380		N+1	None	Ready
2	Member	0c75.bd11.5d80	V01	N+1	None	Ready
3	Standby	0c75.bd11.59ff	P1A	N+1	None	Ready

show tech-support stack

```
-----show switch stack-bandwidth -----
```

Switch#	Role	Stack Bandwidth	Current State	Next Boot Bandwidth
1	Standby	1000G	Ready	480G
*2	Active	1000G	Ready	480G
3	Member	1000G	Ready	480G

```
-----show switch stack-ring speed -----
```

```
Stack Ring Speed      : 1000G
Stack Ring Configuration: Full
Stack Ring Protocol   : StackWise
```

```
----- show switch detail -----
```

```
Switch/Stack Mac Address : 046c.9dle.f380 - Local Mac Address
Mac persistency wait time: Indefinite
```

Switch#	Role	Mac Address	Priority	H/W Version	Current State
*1	Active	046c.9dle.f380	1		Ready
2	Member	0c75.bd11.5d80	1	V01	Ready
3	Standby	0c75.bd11.59ff	1	PlA	Ready

Switch#	Stack Port Status		Neighbors	
	Port 1	Port 2	Port 1	Port 2
1	OK	OK	3	2
2	OK	OK	1	3
3	OK	OK	2	1

```
----- show switch neighbors -----
```

Switch #	Port 1	Port 2
1	3	2
2	1	3
3	2	1

```
----- show platform software stack-mgr switch 1 R0 oir-states --
```

Switch#	OIR State	Type	Provisioned
1	CHASSIS_COMPATIBLE	C9300-24U	YES
2	CHASSIS_COMPATIBLE	C9300-48U	YES

```
3          CHASSIS_COMPATIBLE      C9300-48U          YES
```

```
----- show platform software stack-mgr switch 1 R0 sdp-counters -----
```

```
Stack Discovery Protocol (SDP) Counters
```

```
-----
```

Message	Tx Success	Tx Fail	Rx Success	Rx Fail
Discovery	16	0	27	0
Neighbor	5	1	5	2
Keepalive	473	0	945	0
SEPPUKU	0	0	0	0
Standby Elect Req	1	0	0	0
Standby Elect Ack	0	0	1	0
Standby IOS State	0	0	2	0
Reload Req	0	0	0	0
Reload Ack	0	0	0	0
SESA Mesg	0	0	0	0
RTU Msg	1	0	4	0
Disc Timer Stop	1	0	2	0

```
-----
```

```
----- show platform software sif switch 1 R0 counters -----
```

```
Stack Interface (SIF) Counters
```

```
-----
```

```
Stack Discovery Protocol (SDP) Messages
```

```
-----
```

Message	Tx Success	Tx Fail	Rx Success	Rx Fail
Discovery	0	0	0	0
Neighbor	0	0	0	0
Forward	516	0	1040	0

```
-----
```

```
SIF Management Messages
```

```
-----
```

Message	Success	Fail
Link Status	4	0
Link Management	0	0
Chassis Num	1	0
Topo Change	2	0
Active Declare	1	0
Template set	0	0

```
-----
```

```
----- show platform software sif switch 1 R0 counters oob -----
```

show tech-support stack

SIF OOB Statistics

```

-----
Message                               Count
-----
TX LSMPI                               524
TX Enq Failed                           0
TX Copy Failed                           0
TX Ring Full                             0
TX Iter                                  516
TX Enq Success                           526
RX Process                               1042
RX Exception                             0
RX Total                                 1042
Dequeue Attempts                         986
Dequeue Success                          1043
-----

```

SIF Netdrv OOB Statistics

Unicast Messages

```

-----
Switch      Count
-----
2            42228
3            79287
-----
Broadcast messages count: 4
-----

```

```

----- show platform software sif switch 1 R0 counters cable -----

```

SIF Cable Statistics

```

-----
Direction    Remove    Insert
-----
East          0          1
West          0          1
-----

```

SIF Link Statistics

```

-----
ASIC          Port          State          Changes
-----
0             1             1             2
1             2             1             2
-----

```

```

----- show platform software sif switch 1 R0 exceptions -----

```

```

----- show platform software sif switch 1 R0 topo -----

```

Stack Interface (SIF) Topology

```

-----

```



```
Stacked Switch List
-----
Chassis#      MAC Address      Role
-----
3             0c75.bd11.59ff
2             0c75.bd11.5d80
1             046c.9d1e.f380      L,A

L: Local Switch;  A: Active Switch;
-----
.
.
.
```

The output fields are self-explanatory.

stack-mac persistent timer

To enable the persistent MAC address feature, use the **stack-mac persistent timer** command in global configuration mode on the switch stack or on a standalone switch. To disable the persistent MAC address feature, use the **no** form of this command.

```
stack-mac persistent timer [{0time-value}]
no stack-mac persistent timer
```

Syntax Description

0 (Optional) Continues using the MAC address of the current stack's active switch after a new stack's active switch takes over.

time-value (Optional) Time period in minutes before the stack MAC address changes to that of the new active. The range is 1 to 60 minutes.

Command Default

Persistent MAC address is disabled. The MAC address of the stack is always that of the first active switch.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines

By default, the stack MAC address will always be the MAC address of the first active switch, even if a new active switch takes over. The same behavior occurs when you enter the **stack-mac persistent timer** command or the **stack-mac persistent timer 0** command.



Note To avoid PAgP flaps, the stack MAC persistent wait timer should be configured as indefinite using the **stack-mac persistent timer 0**.

When you enter the **stack-mac persistent timer** command with a *time-value*, the stack MAC address will change to that of the new active switch after the period of time that you entered whenever a new switch becomes the active switch. If the previous active switch rejoins the stack during that time period, the stack retains its MAC address for as long as the switch that has that MAC address is in the stack.

If the whole stack reloads the MAC address of the active switch is the stack MAC address.



Note If you do not change the stack MAC address, Layer 3 interface flapping does not occur. This also means that a foreign MAC address (a MAC address that does not belong to any of the switches in the stack) could be the stack MAC address. If the switch with this foreign MAC address joins another stack as the active switch, two stacks will have the same stack MAC address. You must use the **stack-mac update force** command to resolve the conflict.

Examples

This example shows how to enable a persistent MAC address:

```
Device(config)# stack-mac persistent timer
```

You can verify your settings by entering the **show running-config** privileged EXEC command. If enabled, **stack-mac persistent timer** is shown in the output.

stack-mac update force

To update the stack MAC address to the MAC address of the active switch, use the **stack-mac update force** command in EXEC mode on the active switch.

stack-mac update force

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines By default, the stack MAC address is not changed to the MAC address of the new active switch during a high availability (HA) failover. Use the **stack-mac update force** command to force the stack MAC address to change to the MAC address of the new active switch.

If the switch with the same MAC address as the stack MAC address is currently a member of the stack, the **stack-mac update force** command has no effect. (It does not change the stack MAC address to the MAC address of the active switch.)



Note If you do not change the stack MAC address, Layer 3 interface flapping does not occur. It also means that a foreign MAC address (a MAC address that does not belong to any of the switches in the stack) could be the stack MAC address. If the switch with this foreign MAC address joins another stack as the active switch, two stacks will have the same stack MAC address. You must use the **stack-mac update force** command to resolve the conflict.

This example shows how to update the stack MAC address to the MAC address of the active switch:

```
> stack-mac update force
>
```

You can verify your settings by entering the **show switch** privileged EXEC command. The stack MAC address includes whether the MAC address is local or foreign.

standby console enable

To enable access to the standby console switch, use the **standby console enable** command in redundancy main configuration submode. To disable access to the standby console switch, use the **no** form of this command.

standby console enable
no standby console enable

Syntax Description This command has no arguments or keywords.

Command Default Access to the standby console switch is disabled.

Command Modes Redundancy main configuration submode

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines This command is used to collect and review specific data about the standby console. The command is useful primarily for Cisco technical support representatives troubleshooting the switch.

This example shows how to enter the redundancy main configuration submode and enable access to the standby console switch:

```
Device(config)# redundancy
Device(config-red)# main-cpu
Device(config-r-mc)# standby console enable
Device(config-r-mc)#
```

start maintenance

To put the system into maintenance mode, use the **start maintenance** command in the privileged EXEC mode.

start maintenance

Syntax Description	start maintenance	Puts the system into maintenance mode.
Command Default	Disabled.	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Example:

The following example shows how to start maintenance mode:

```
Device# start maintenance
```

stop maintenance

To put the system out of maintenance mode, use the **stop maintenance** command in the privileged EXEC mode.

stop maintenance

Command Default

Disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Example:

The following example shows how to stop maintenance mode:

```
Device# stop maintenance
```

switch clear stack-mode

To change the stack mode to N+1 and remove the active and standby assignments of the 1:1 mode, use the **switch clear stack-mode** command in privileged EXEC mode.

switch clear stack-mode

Command Default

None

Command Modes

privileged EXEC

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

Use this command to disable the 1:1 redundancy mode and set the stack to N+1 mode.

```
Device> enable
Device# switch clear stack-mode
WARNING: Clearing the chassis HA configuration will result in the chassis coming up in Stand
Alone mode after reboot.The HA configuration will remain the same on other chassis. Do you
wish to continue? [y/n]? [yes]:
```


switch priority

To change the stack member priority value, use the **switch priority** command in mode on the .

```
switch stack-member-number priority new-priority-value
```

Syntax Description

stack-member-number

new-priority-value New stack member priority value. The range is 1 to 15.

Command Default

The default priority value is 1.

Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines

The new priority value is a factor when a new is elected. When you change the priority value the is not changed immediately.

Examples

This example shows how to change the priority value of stack member 6 to 8:

```
switch 6 priority 8
Changing the Switch Priority of Switch Number 6 to 8
Do you want to continue?[confirm]
```

switch provision

To supply a configuration to a new switch before it joins the switch stack, use the **switch provision** command in global configuration mode on the . To delete all configuration information that is associated with the removed switch (a stack member that has left the stack), use the **no** form of this command.

switch *stack-member-number* **provision** *type*
no switch *stack-member-number* **provision**

Syntax Description	<i>stack-member-number</i>
	<i>type</i> Switch type of the new switch before it joins the stack.

Command Default The switch is not provisioned.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines

For *type*, enter the model number of a supported switch that is listed in the command-line help strings.

To avoid receiving an error message, you must remove the specified switch from the switch stack before using the **no** form of this command to delete a provisioned configuration.

To change the switch type, you must also remove the specified switch from the switch stack. You can change the stack member number of a provisioned switch that is physically present in the switch stack if you do not also change the switch type.

If the switch type of the provisioned switch does not match the switch type in the provisioned configuration on the stack, the switch stack applies the default configuration to the provisioned switch and adds it to the stack. The switch stack displays a message when it applies the default configuration.

Provisioned information appears in the running configuration of the switch stack. When you enter the **copy running-config startup-config** privileged EXEC command, the provisioned configuration is saved in the startup configuration file of the switch stack.



Caution When you use the **switch provision** command, memory is allocated for the provisioned configuration. When a new switch type is configured, the previously allocated memory is not fully released. Therefore, do not use this command more than approximately 200 times, or the switch will run out of memory and unexpected behavior will result.

Examples

This example shows how to provision a switch with a stack member number of 2 for the switch stack. The **show running-config** command output shows the interfaces associated with the provisioned switch.

```
(config)# switch 2 provision WS-xxxx
(config)# end
```

```
# show running-config | include switch 2
!
interface GigabitEthernet2/0/1
!
interface GigabitEthernet2/0/2
!
interface GigabitEthernet2/0/3
<output truncated>
```

You also can enter the **show switch** user EXEC command to display the provisioning status of the switch stack.

This example shows how to delete all configuration information about stack member 5 when the switch is removed from the stack:

```
(config)# no switch 5 provision
```

You can verify that the provisioned switch is added to or removed from the running configuration by entering the **show running-config** privileged EXEC command.

switch renumber

To change the stack member number, use the **switch renumber** command in mode on the .

switch *current-stack-member-number* **renumber** *new-stack-member-number*

Syntax Description	<i>current-stack-member-number</i>
	<i>new-stack-member-number</i>

Command Default The default stack member number is 1.

Command History	Release	Modification
	Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines If another stack member is already using the member number that you just specified, the assigns the lowest available number when you reload the stack member.



Note If you change the number of a stack member, and no configuration is associated with the new stack member number, that stack member loses its current configuration and resets to its default configuration.

Do not use the **switch** *current-stack-member-number* **renumber** *new-stack-member-number* command on a provisioned switch. If you do, the command is rejected.

Use the **reload slot** *current stack member number* privileged EXEC command to reload the stack member and to apply this configuration change.

Examples This example shows how to change the member number of stack member 6 to 7:

switch renumber

To change the stack member number, use the **switch renumber** command in mode on the .

switch *current-stack-member-number* **renumber** *new-stack-member-number*

Syntax Description

current-stack-member-number

new-stack-member-number

Command Default

The default stack member number is 1.

Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines

If another stack member is already using the member number that you just specified, the assigns the lowest available number when you reload the stack member.



Note If you change the number of a stack member, and no configuration is associated with the new stack member number, that stack member loses its current configuration and resets to its default configuration.

Do not use the **switch** *current-stack-member-number* **renumber** *new-stack-member-number* command on a provisioned switch. If you do, the command is rejected.

Use the **reload slot** *current stack member number* privileged EXEC command to reload the stack member and to apply this configuration change.

Examples

This example shows how to change the member number of stack member 6 to 7:

switch stack port

To disable or enable the specified stack port on the member, use the **switch** command in privileged EXEC mode on a stack member.

```
switch stack-member-number stack port port-number {disable | enable}
```

Syntax Description

stack-member-number

stack port *port-number* Specifies the stack port on the member. The range is 1 to 2.

disable Disables the specified port.

enable Enables the specified port.

Command Default

The stack port is enabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Everest 16.5.1a	This command was introduced.

Usage Guidelines

A stack is in the full-ring state when all members are connected through the stack ports and are in the ready state.

The stack is in the partial-ring state when the following occurs:

- All members are connected through their stack ports but some are not in the ready state.
- Some members are not connected through the stack ports.



Note Be careful when using the **switch** *stack-member-number* **stack port** *port-number* **disable** command. When you disable the stack port, the stack operates at half bandwidth.

If you enter the **switch** *stack-member-number* **stack port** *port-number* **disable** privileged EXEC command and the stack is in the full-ring state, you can disable only one stack port. This message appears:

```
Enabling/disabling a stack port may cause undesired stack changes. Continue?[confirm]
```

If you enter the **switch** *stack-member-number* **stack port** *port-number* **disable** privileged EXEC command and the stack is in the partial-ring state, you cannot disable the port. This message appears:

```
Disabling stack port not allowed with current stack configuration.
```

Examples

This example shows how to disable stack port 2 on member 4:

```
# switch 4 stack port 2 disable
```

switch stack-speed

To configure the bandwidth of the Standard Interchange Format (SIF) ports on a switch stack to 480 Gbps (legacy mode) or 1 Tbps (high speed mode) use the **switch stack-speed** [**high** | **low**] command in the Global configuration mode.

switch stack-speed [**high** | **low**]

Syntax Description	high	Configures the SIF port bandwidth to 1 Tbps.
	low	Configures the SIF port bandwidth to 480 Gbps.

Command Default The bandwidth is set to low by default.

Command Modes Global configuration mode.

Release	Modification
Cisco IOS XE Bengaluru 17.5.1	The command was introduced.

The following example show how to configure the stack speed to high.

```
Device(config)# switch stack-speed high
```

Related Commands	Command	Description
	show switch stack-ring speed	Displays the current stack ring speed and the speed after the next reboot.
	show switch stack-bandwidth	Displays the current stack bandwidth and what the bandwidth will be after the next reboot.

switch switch-number role

To change the role of the device in the stack to either active or standby, use the **switch** *switch-number* **role** command in privileged EXEC mode.

```
switch switch-number role {standby | active}
```

Syntax Description

Syntax Description		
<i>switch-number</i>		Stack member number.
standby		Designates the device as Standby Device for the stack.
active		Designates the device as Active Device for the stack.

Command Default

None

Command Modes

privileged EXEC

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

Use this command to set a device to active or standby role in the stack. The other devices in the stack remain as members of the stack.



Note Changing the role of the device results in redundancy mode being configured to 1:1 mode for the stack. If the configured active or standby device does not boot up, then the stack will not be able to boot.

The following example sets the device number 2 as active device and device number 1 as standby device for the stack.

```
Device> enable
Device# switch 2 role active
WARNING: Changing the switch role may result in redundancy mode being configured to 1+1 mode for this stack. If the configured Active or Standby switch numbers do not boot up, then the stack will not be able to boot. Do you want to continue?[y/n]? : yes
```

```
Device# switch 1 role standby
WARNING: Changing the switch role may result in redundancy mode being configured to 1+1 mode for this stack. If the configured Active or Standby switch numbers do not boot up, then the stack will not be able to boot. Do you want to continue?[y/n]? : yes
```


system mode maintenance

To enter the system mode maintenance configuration mode, use the **system mode maintenance** command in the global configuration mode.

system mode maintenance

Syntax Description	system mode maintenance	Enters the maintenance configuration mode.
Command Default	Disabled.	
Command Modes	Global configuration (config)	
Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Example:

The following example shows how to enter the maintenance configuration mode:

```
Device(config)# system mode maintenance
Device(config-maintenance)#
```

