



## **Interface and Hardware Components Configuration Guide, Cisco IOS XE 17.18.x (Catalyst 9300 Switches)**

**First Published:** 2025-08-08

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2025 Cisco Systems, Inc. All rights reserved.



## Preface

This preface describes the conventions of this document and information on how to obtain other documentation. It also provides information on what's new in Cisco product documentation.

- [Document Conventions](#) , on page iii
- [Related Documentation](#), on page v
- [Obtaining Documentation and Submitting a Service Request](#), on page v

## Document Conventions

This document uses the following conventions:

Convention	Description
^ or Ctrl	Both the ^ symbol and Ctrl represent the Control (Ctrl) key on a keyboard. For example, the key combination <b>^D</b> or <b>Ctrl-D</b> means that you hold down the Control key while you press the D key. (Keys are indicated in capital letters but are not case sensitive.)
<b>bold font</b>	Commands and keywords and user-entered text appear in <b>bold font</b> .
<i>Italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
Courier font	Terminal sessions and information the system displays appear in <code>courier font</code> .
<b>Bold Courier font</b>	<b>Bold Courier font</b> indicates text that the user must enter.
[x]	Elements in square brackets are optional.
...	An ellipsis (three consecutive nonbolded periods without spaces) after a syntax element indicates that the element can be repeated.
	A vertical line, called a pipe, indicates a choice within a set of keywords or arguments.
[x   y]	Optional alternative keywords are grouped in brackets and separated by vertical bars.

Convention	Description
{x   y}	Required alternative keywords are grouped in braces and separated by vertical bars.
[x {y   z}]	Nested set of square brackets or braces indicate optional or required choices within optional or required elements. Braces and a vertical bar within square brackets indicate a required choice within an optional element.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<>	Nonprinting characters such as passwords are in angle brackets.
[ ]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

### Reader Alert Conventions

This document may use the following conventions for reader alerts:



**Note** Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.



**Tip** Means *the following information will help you solve a problem*.



**Caution** Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.



**Timesaver** Means *the described action saves time*. You can save time by performing the action described in the paragraph.

Take note of the following general safety warnings:

**Warning****IMPORTANT SAFETY INSTRUCTIONS**

Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Read the installation instructions before using, installing, or connecting the system to the power source. Use the statement number at the beginning of each warning statement to locate its translation in the translated safety warnings for this device.

SAVE THESE INSTRUCTIONS



## Related Documentation

**Note**

Before installing or upgrading the device, refer to the device release notes.

- Cisco Catalyst 9300 Series Switches documentation, located at:  
<http://www.cisco.com/go/c9300>
- Cisco SFP and SFP+ modules documentation, including compatibility matrixes, located at:  
[http://www.cisco.com/en/US/products/hw/modules/ps5455/tsd\\_products\\_support\\_series\\_home.html](http://www.cisco.com/en/US/products/hw/modules/ps5455/tsd_products_support_series_home.html)
- Cisco Validated Designs documents, located at:  
<http://www.cisco.com/go/designzone>

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/c/en/us/td/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.





## CONTENTS

---

### PREFACE

#### **Preface** iii

Document Conventions iii

Related Documentation v

Obtaining Documentation and Submitting a Service Request v

---

### CHAPTER 1

#### **Configuring Interface Characteristics** 1

Information About Interface Characteristics 1

Interface Types 1

Port-Based VLANs 1

Switch Ports 2

Using the Switch USB Ports 6

USB Mini-Type B Console Port 6

Console Port Change Logs 7

USB Type A Port 7

Disabling USB Ports 7

Interface Connections 7

Interface Configuration Mode 8

Breakout Interfaces 9

Limitations for Breakout Interfaces 10

Default Ethernet Interface Configuration 10

Interface Speed and Duplex Mode 12

Speed and Duplex Configuration Guidelines 12

Port Settings 13

IEEE 802.3x Flow Control 14

Layer 3 Interfaces 14

How to Configure Interface Characteristics 15

Configuring an Interface	16
Adding a Description for an Interface	16
Configuring a Range of Interfaces	17
Configuring and Using Interface Range Macros	19
Setting the Interface Speed and Duplex Parameters	20
Configuring Port Settings for an Interface	22
Configuring a Breakout Interface	24
Configuring Forty Gigabit Ethernet Interface	28
Configuring the IEEE 802.3x Flow Control	29
Configuring a Layer 3 Interface	30
Configuring a Logical Layer 3 GRE Tunnel Interface	31
Configuring SVI Autostate Exclude	33
Shutting Down and Restarting an Interface	34
Configuring the Console Media Type	35
Configuring USB Inactivity Timeout	36
Disabling USB Ports	37
Monitoring Interface Characteristics	37
Monitoring Interface Status	37
Clearing and Resetting Interfaces and Counters	38
Configuration Examples for Interface Characteristics	39
Example: Adding a Description to an Interface	39
Example: Configuring Interfaces on a Stack-Capable Switch	39
Example: Configuring a Range of Interfaces	39
Example: Configuring and Using Interface Range Macros	40
Example: Setting Interface Speed and Duplex Mode	40
Example: Configuring a Layer 3 Interface	41
Example: Configuring a Breakout Interface	41
Example: Configuring the Console Media Type	46
Example: Configuring USB Inactivity Timeout	46
Additional References for Configuring Interface Characteristics	47
Feature History for Configuring Interface Characteristics	47

---

**CHAPTER 2**
**Configuring Auto-MDIX 51**

Prerequisites for Auto-MDIX	51
-----------------------------	----

Restrictions for Auto-MDIX	51
Information About Configuring Auto-MDIX	51
Auto-MDIX on an Interface	52
How to Configure Auto-MDIX	52
Configuring Auto-MDIX on an Interface	52
Example for Configuring Auto-MDIX	53
Auto-MDIX and Operational State	53
Additional References for Auto-MDIX	54
Feature History for Auto-MDIX	54

---

**CHAPTER 3****Configuring Ethernet Management Port 55**

Prerequisites for Ethernet Management Port	55
Ethernet Management Port Overview	55
Connecting the Ethernet Management Directly to a Device	55
Connecting the Ethernet Management Port to Stack Devices using a Hub	56
Ethernet Management Port and Routing	56
Supported Features on the Ethernet Management Port	57
How to Configure the Ethernet Management Port	58
Disabling and Enabling the Ethernet Management Port	58
Example for Configuring IP Address on the Ethernet Management Port	59
Additional References for Ethernet Management Port	60
Feature History for Ethernet Management Port	60

---

**CHAPTER 4****Checking Port Status and Connectivity 61**

Check Cable Status Using Time Domain Reflectometer	61
Running the TDR Test	61
TDR Guidelines	62
Feature History for Checking Port Status and Connectivity	62

---

**CHAPTER 5****Configuring LLDP, LLDP-MED, and Wired Location Service 65**

Restrictions for LLDP	65
Information About LLDP, LLDP-MED, and Wired Location Service	65
LLDP	65
LLDP Supported TLVs	66

LLDP-MED	66
LLDP-MED Supported TLVs	66
Wired Location Service	68
Default LLDP Configuration	69
How to Configure LLDP, LLDP-MED, and Wired Location Service	69
Enabling LLDP	69
Configuring LLDP Characteristics	70
Configuring LLDP-MED TLVs	72
Configuring Network-Policy TLV	73
Configuring Location TLV and Wired Location Service	75
Enabling Wired Location Service on the Device	77
Configuration Examples for LLDP, LLDP-MED, and Wired Location Service	78
Examples: Configuring Network-Policy TLV	78
Monitoring and Maintaining LLDP, LLDP-MED, and Wired Location Service	78
Additional References for LLDP, LLDP-MED, and Wired Location Service	79
Feature History for LLDP, LLDP-MED, and Wired Location Service	79

---

**CHAPTER 6****Configuring System MTU 81**

Information About the MTU	81
System MTU Value Application	81
How to Configure MTU	82
Configuring the System MTU	82
Configuring Protocol-Specific MTU	82
Configuration Examples for System MTU	83
Example: Configuring Protocol-Specific MTU	83
Example: Configuring the System MTU	84
Additional References for System MTU	84
Feature History for System MTU	84

---

**CHAPTER 7****Configuring Per-Port MTU 85**

Restrictions for Per-Port MTU	85
Information About Per-Port MTU	85
Configuring Per-Port MTU	86
Example: Configuring Per-Port MTU	86

Example: Verifying Per-Port MTU	87
Example: Disabling Per-Port MTU	87
Feature History for Per-Port MTU	87

**CHAPTER 8****Configuring Internal Power Supplies 89**

Information About Internal Power Supplies	89
How to Configure Internal Power Supplies	89
Configuring Internal Power Supply	89
Monitoring Internal Power Supplies	90
View Power Consumption	90
Configuration Examples for Internal Power Supplies	91
Additional References for Internal Power Supplies	92
Feature History for Internal Power Supplies	92

**CHAPTER 9****Configuring the Cisco Expandable Power System 2200 95**

Restrictions for Configuring the Expandable Power System 2200	95
Information About Cisco Expandable Power System 2200	95
Cisco eXpandable Power System (XPS) 2200 Overview	95
XPS 2200 Power Supply Modes	96
RPS Mode	96
Stack Power Mode	97
Mixed Modes	98
XPS 2200 System Defaults	98
How to Configure the Cisco Expandable Power System 2200	99
Configuring System Names	99
Configuring XPS Ports	100
Configuring XPS Power Supplies	101
Monitoring and Maintaining the Cisco Expandable Power System 2200	102
Additional References for Cisco Expandable Power System 2200	102
Feature History for Cisco Expandable Power System 2200	103

**CHAPTER 10****Configuring EEE 105**

Restrictions for EEE	105
Information About EEE	105

EEE Overview 106

Default EEE Configuration 106

How to Configure EEE 106

    Enabling or Disabling EEE 106

Monitoring EEE 107

Configuration Examples for Configuring EEE 108

Additional References for EEE 108

Feature History for Configuring EEE 108

---

**CHAPTER 11**

**Configuring Power over Ethernet 109**

Information About Power over Ethernet 109

PoE and PoE+ Ports 109

    Supported Protocols and Standards 110

    Powered-Device Detection and Initial Power Allocation 112

    Power Management Modes 113

    Cisco Universal Power Over Ethernet 116

How to Configure PoE and UPOE 116

    Configuring a Power Management Mode on a PoE Port 116

    Enabling Power on Signal and Spare Pairs 118

    Configuring Power Policing 118

    Enable the 802.3bt Mode on Type 3 Cisco UPOE Modules 120

Monitoring Power Status 121

Additional References for Power over Ethernet 125

Feature History for Power over Ethernet 125

---

**CHAPTER 12**

**Configuring Perpetual PoE and Fast POE 127**

Restrictions for Perpetual and Fast PoE 127

Information About Perpetual PoE 128

Fast POE 128

Configuring Perpetual and Fast PoE 128

Example: Configuring Perpetual and Fast PoE 129

Feature History for Perpetual PoE and Fast PoE 130

---

**CHAPTER 13**

**Configuring 2-event Classification 131**

Restrictions for 2-Event Classification	131
Information about 2-event Classification	131
Configuring 2-Event Classification	131
Example: Configuring 2-Event Classification	132
Feature History for 2-Event Classification	132

**CHAPTER 14****Configuring Auto SmartPorts 135**

Restrictions for Auto SmartPorts	135
Information about Auto SmartPorts	135
Auto SmartPort Macros	136
Customizing Device Classifier	136
Commands run by CISCO_LIGHT_AUTO_SMARTPORT	136
Enabling Auto SmartPort	137
How to Configure Auto SmartPorts	138
Configuring a Device Classifier Profile	138
Configuring Mapping Between Event Triggers and Built-in Macros	140
Configuration Examples for Auto SmartPorts	141
Example: Enabling Auto SmartPorts	141
Example: Configuring Mapping Between Event Triggers and Built-In Macros	141
Example: Configuring Device Classifier Profiles	141
Feature History for Auto SmartPorts	142

**CHAPTER 15****Configuring COAP Proxy Server 143**

Restrictions for the COAP Proxy Server	143
Information About the COAP Proxy Server	143
How to Configure the COAP Proxy Server	144
Configuring the COAP Proxy	144
Configuring COAP Endpoints	146
Configuration Examples for the COAP Proxy Server	147
Examples: Configuring the COAP Proxy Server	147
Monitoring COAP Proxy Server	151
Feature History for COAP	152

**CHAPTER 16****Configuring USB 3.0 SSD 153**

Information about USB 3.0 SSD	153
USB 3.0 SSD	153
File System on USB 3.0 SSD	154
Password Authentication on USB 3.0 SSD	154
How to Configure USB 3.0 SSD	154
Formatting USB 3.0 SSD	154
Unmounting USB 3.0 SSD from a Switch or a Switch Stack	154
Enabling Password Security on USB 3.0 SSD	155
Configuring USB 3.0 SSD Password on a Switch	156
Unlocking USB 3.0 SSD	157
Disabling Password Security on USB 3.0 SSD	157
Monitoring USB 3.0 SSD	157
Troubleshooting Tips	158
Troubleshooting USB 3.0 SSD Insertion and Removal	159
Troubleshooting Password Authentication	160
Configuration Examples for USB 3.0 SSD	161
Example: Displaying USB 3.0 SSD Authentication Status	161
Examples: Verifying the Filesystem	161
Examples: Verifying Physical Inventory Information	162
Examples: Verifying the Health of the Drive	162
Feature History for USB 3.0 SSD	163
<hr/>	
<b>CHAPTER 17</b>	<b>Configuring an External USB Bluetooth Dongle 165</b>
	Restrictions for Configuring an External USB Bluetooth Dongle 165
	Information About External USB Bluetooth Dongle 165
	Supported External USB Bluetooth Dongle 165
	How to Configure an External USB Bluetooth Dongle on a Switch 166
	Verifying Bluetooth Settings on a Device 167
	Feature History for Configuring an External Bluetooth Dongle 167
<hr/>	
<b>CHAPTER 18</b>	<b>Troubleshooting Interface and Hardware Components 169</b>
	Overview 169
	Support Articles 169
	Feedback Request (Reference) 170

[Disclaimer and Caution \(Reference\)](#) 170





# CHAPTER 1

## Configuring Interface Characteristics

- [Information About Interface Characteristics, on page 1](#)
- [How to Configure Interface Characteristics, on page 15](#)
- [Configuration Examples for Interface Characteristics, on page 39](#)
- [Additional References for Configuring Interface Characteristics, on page 47](#)
- [Feature History for Configuring Interface Characteristics, on page 47](#)

### Information About Interface Characteristics

The following sections provide information about interface characteristics.

#### Interface Types

This section describes the different types of interfaces supported by the device. The rest of the chapter describes configuration procedures for physical interface characteristics.



---

**Note** The stack ports on the rear of the stacking-capable devices are not Ethernet ports and cannot be configured.

---

#### Port-Based VLANs

A VLAN is a switched network that is logically segmented by function, team, or application, without regard to the physical location of the users. Packets received on a port are forwarded only to ports that belong to the same VLAN as the receiving port. Network devices in different VLANs cannot communicate with one another without a Layer 3 device to route traffic between the VLANs.

VLAN partitions provide hard firewalls for traffic in the VLAN, and each VLAN has its own MAC address table. A VLAN comes into existence when a local port is configured to be associated with the VLAN, when the VLAN Trunking Protocol (VTP) learns of its existence from a neighbor on a trunk, or when a user creates a VLAN. VLANs can be formed with ports across the stack.

To configure VLANs, use the **vlan *vlan-id*** global configuration command to enter VLAN configuration mode. The VLAN configurations for normal-range VLANs (VLAN IDs 1 to 1005) are saved in the VLAN database. If VTP is version 1 or 2, to configure extended-range VLANs (VLAN IDs 1006 to 4094), you must first set VTP mode to transparent. Extended-range VLANs created in transparent mode are not added to the VLAN database but are saved in the running configuration. With VTP version 3, you can create extended-range

VLANs in client or server mode in addition to transparent mode. These VLANs are saved in the VLAN database.

In a switch stack, the VLAN database is downloaded to all switches in a stack, and all switches in the stack build the same VLAN database. The running configuration and the saved configuration are the same for all switches in a stack.

Add ports to a VLAN by using the **switchport** command in interface configuration mode.

- Identify the interface.
- For a trunk port, set trunk characteristics, and, if desired, define the VLANs to which it can belong.
- For an access port, set and define the VLAN to which it belongs.

## Switch Ports

Switch ports are Layer 2-only interfaces associated with a physical port. Switch ports belong to one or more VLANs. A switch port can be an access port or a trunk port. You can configure a port as an access port or trunk port or let the Dynamic Trunking Protocol (DTP) operate on a per-port basis to set the switchport mode by negotiating with the port on the other end of the link. Switch ports are used for managing the physical interface and associated Layer 2 protocols and do not handle routing or bridging.

Configure switch ports by using the **switchport** interface configuration commands.

### Access Ports

An access port belongs to and carries the traffic of only one VLAN (unless it is configured as a voice VLAN port). Traffic is received and sent in native formats with no VLAN tagging. Traffic arriving on an access port is assumed to belong to the VLAN assigned to the port. If an access port receives a tagged packet (Inter-Switch Link [ISL] or IEEE 802.1Q tagged), the packet is dropped, and the source address is not learned.

The types of access ports supported are:

- Static access ports are manually assigned to a VLAN (or through a RADIUS server for use with IEEE 802.1x).

You can also configure an access port with an attached Cisco IP Phone to use one VLAN for voice traffic and another VLAN for data traffic from a device attached to the phone.

### Trunk Ports

A trunk port carries the traffic of multiple VLANs and by default is a member of all VLANs in the VLAN database. The IEEE 802.1Q trunk port type is supported. An IEEE 802.1Q trunk port supports simultaneous tagged and untagged traffic. An IEEE 802.1Q trunk port is assigned a default port VLAN ID (PVID), and all untagged traffic travels on the port default PVID. All untagged traffic and tagged traffic with a NULL VLAN ID are assumed to belong to the port default PVID. A packet with a VLAN ID equal to the outgoing port default PVID is sent untagged. All other traffic is sent with a VLAN tag.

Although by default, a trunk port is a member of every VLAN known to the VTP, you can limit VLAN membership by configuring an allowed list of VLANs for each trunk port. The list of allowed VLANs does not affect any other port but the associated trunk port. By default, all possible VLANs (VLAN ID 1 to 4094) are in the allowed list. A trunk port can become a member of a VLAN only if VTP knows of the VLAN and if the VLAN is in the enabled state. If VTP learns of a new, enabled VLAN and the VLAN is in the allowed list for a trunk port, the trunk port automatically becomes a member of that VLAN and traffic is forwarded to and from the trunk port for that VLAN. If VTP learns of a new, enabled VLAN that is not in the allowed

list for a trunk port, the port does not become a member of the VLAN, and no traffic for the VLAN is forwarded to or from the port.

## Tunnel Ports

Tunnel ports are used in IEEE 802.1Q tunneling to segregate the traffic of customers in a service-provider network from other customers who are using the same VLAN number. You configure an asymmetric link from a tunnel port on a service-provider edge switch to an IEEE 802.1Q trunk port on the customer switch. Packets entering the tunnel port on the edge switch, already IEEE 802.1Q-tagged with the customer VLANs, are encapsulated with another layer of an IEEE 802.1Q tag (called the metro tag), containing a VLAN ID unique in the service-provider network, for each customer. The double-tagged packets go through the service-provider network keeping the original customer VLANs separate from those of other customers. At the outbound interface, also a tunnel port, the metro tag is removed, and the original VLAN numbers from the customer network are retrieved.

Tunnel ports cannot be trunk ports or access ports and must belong to a VLAN unique to each customer.

## Routed Ports

A routed port is a physical port that acts like a port on a router; it does not have to be connected to a router. A routed port is not associated with a particular VLAN, as is an access port. A routed port behaves like a regular router interface, except that it does not support VLAN subinterfaces. Routed ports can be configured with a Layer 3 routing protocol. A routed port is a Layer 3 interface only and does not support Layer 2 protocols, such as DTP and STP.

Configure routed ports by putting the interface into Layer 3 mode with the **no switchport** interface configuration command. Then assign an IP address to the port, enable routing, and assign routing protocol characteristics by using the **ip routing** and **router protocol** global configuration commands.



---

**Note** Entering a **no switchport** interface configuration command shuts down the interface and then re-enables it, which might generate messages on the device to which the interface is connected. When you put an interface that is in Layer 2 mode into Layer 3 mode, the previous configuration information related to the affected interface might be lost.

---



---

**Note** A port configured as a switchport does not support MAC address configuration. It does not support the **mac-address x.x.x** command.

---

The number of routed ports that you can configure is not limited by software. However, the interrelationship between this number and the number of other features being configured might impact CPU performance because of hardware limitations.

## Switch Virtual Interfaces

A switch virtual interface (SVI) represents a VLAN of switch ports as one interface to the routing function in the system. You can associate only one SVI with a VLAN. You configure an SVI for a VLAN only to route between VLANs or to provide IP host connectivity to the device. By default, an SVI is created for the default VLAN (VLAN 1) to permit remote device administration. Additional SVIs must be explicitly configured.




---

**Note** You cannot delete interface VLAN 1.

---

SVIs provide IP host connectivity only to the system. SVIs are created the first time that you enter the **vlan** interface configuration command for a VLAN interface. The VLAN corresponds to the VLAN tag associated with data frames on an ISL or IEEE 802.1Q encapsulated trunk or the VLAN ID configured for an access port. Configure a VLAN interface for each VLAN for which you want to route traffic, and assign it an IP address.

You can also use the interface range command to configure existing VLAN SVIs within the range. The commands entered under the interface range command are applied to all existing VLAN SVIs within the range. You can enter the command **interface range create vlan** *x - y* to create all VLANs in the specified range that do not already exist. When the VLAN interface is created, **interface range vlan** *id* can be used to configure the VLAN interface.

Although the device stack or standalone device supports a total of 1005 VLANs and SVIs, the interrelationship between the number of SVIs and routed ports and the number of other features being configured might impact CPU performance because of hardware limitations.

When you create an SVI, it does not become active until it is associated with a physical port.

## EtherChannel Port Groups

EtherChannel port groups treat multiple switch ports as one switch port. These port groups act as a single logical port for high-bandwidth connections between devices or between devices and servers. An EtherChannel balances the traffic load across the links in the channel. If a link within the EtherChannel fails, traffic previously carried over the failed link changes to the remaining links. You can group multiple trunk ports into one logical trunk port, group multiple access ports into one logical access port, group multiple tunnel ports into one logical tunnel port, or group multiple routed ports into one logical routed port. Most protocols operate over either single ports or aggregated switch ports and do not recognize the physical ports within the port group. Exceptions are the DTP, the Cisco Discovery Protocol (CDP), and the Port Aggregation Protocol (PAgP), which operate only on physical ports.

When you configure an EtherChannel, you create a port-channel logical interface and assign an interface to the EtherChannel. For Layer 3 interfaces, you manually create the logical interface by using the **interface port-channel** global configuration command. Then you manually assign an interface to the EtherChannel by using the **channel-group** interface configuration command. For Layer 2 interfaces, use the **channel-group** interface configuration command to dynamically create the port-channel logical interface. This command binds the physical and logical ports together.

## Network Modules

The device supports four network modules that include one Gigabit Ethernet, 10-Gigabit Ethernet, 25-Gigabit Ethernet and 40-Gigabit Ethernet uplink ports. If you need an ethernet connection, use GLC-T/GLC-TE copper SFP for one Gigabit Ethernet on all modules.




---

**Note** Cisco Catalyst 9300L Series Switches do not support network modules. They only support fixed uplink SFP ports.

---

The following are the network modules supported on the Cisco Catalyst 9300 Series Switches:

- 4x1G

- 4x10G (Multigigabit Ethernet module)
- 8x10G
- 2x25G
- 2x40G

Cisco Catalyst 9300L Series Switches support only fixed uplink SFP ports of 4x1G and 4x10G.

The network modules that are supported on the Cisco Catalyst 9300X-HXN Series Switches are listed in the table. The ports that are usable on each network module and the releases for which the ports are usable have been listed.

Network Module	Cisco IOS XE Cupertino 17.7.1 and earlier releases	Cisco IOS XE Cupertino 17.8.1 and later releases
C9300X-NM-8Y (8x25G)	Ports 1–4 usable	Ports 1–6 usable (Ports 7 & 8 permanently disabled)
C9300X-NM-8M (8xmGig)	Ports 1–4 usable	Ports 1–6 usable (Ports 7 & 8 permanently disabled)
C9300X-NM-2C (2x100G/2x40G)	Ports 1–2 usable (No Breakout cable support)	Ports 1 & 2 usable (Breakout cable supported only on port 1. No support for breakout cable on port 2)

## Multigigabit Ethernet

The MultiGigabit Ethernet (mGig) feature allows you to configure speeds of 100 Mbps, 1 Gbps, 2.5 Gbps, and 5 Gbps with automatic bandwidth negotiation over traditional CAT5e cables and higher cable variants.

The following Cisco Catalyst 9300 series switches support the mGig feature:

- C9300-24UX
- C9300-48UN
- C9300-48UXM



**Note** Cisco Catalyst 9300L Series Switches do not support Multigigabit Ethernet.

Multigigabit Ethernet supports multi-rate speeds where the ports exchange auto-negotiation pages to establish a link at the highest speed that is supported by both ends of the channel. In a high-noise environment, when port speed downshifting is enabled on an interface, the line rate automatically downgrades to a lower speed when a higher speed link cannot be established or when an established link quality has degraded to a level where the PHY needs to reestablish the link. The following downshift speed values are recommended:

- 10Gbs (downshift to 5Gbs)
- 5Gbs (downshift to 2.5Gbs)
- 2.5Gbs (downshift to 1Gbs)

- 1Gbps (downshift to 100Mbps)

## Power over Ethernet

The Power over Ethernet (PoE) technology allows PoE (802.3af standard), PoE+ (802.3at), and PoE++ (802.3bt) ports to supply power for the operation of a device.

Cisco Universal Power Over Ethernet (Cisco UPoE) extends the IEEE PoE+ standard to double the power per port to 60 watts.

Cisco Universal Power Over Ethernet Plus (Cisco UPoE+) combines the new IEEE 802.3bt standard and Cisco UPoE to increase the power per port to 90 watts. The 802.3bt-compliant Type 4 powered devices support up to 90watts.




---

**Note** The following SKUs of Cisco Catalyst 9300 Series Switch do not support PoE:

- C9300-24T
  - C9300-48T
  - C9300-24S
  - C9300-48S
  - C9300L-24T
  - C9300L-48T
- 

For more information, see the *Configuring PoE* section of this guide.

## Using the Switch USB Ports

The device has two USB ports on the front panel: a USB mini-Type B console port and a USB Type A port and a USB 3.0 port on the rear panel.

### USB Mini-Type B Console Port

The device has the following console ports:

- USB mini-Type B console connection
- RJ-45 console port

Console output appears on devices connected to both ports, but console input is active on only one port at a time. By default, the USB connector takes precedence over the RJ-45 connector.




---

**Note** Windows PCs require a driver for the USB port. See the hardware installation guide for driver installation instructions.

---

Use the supplied USB Type A-to-USB mini-Type B cable to connect a PC or other device to the device. The connected device must include a terminal emulation application. When the device detects a valid USB

connection to a powered-on device that supports host functionality (such as a PC), input from the RJ-45 console is immediately disabled, and input from the USB console is enabled. Removing the USB connection immediately reenables input from the RJ-45 console connection. An LED on the device shows which console connection is in use.

## Console Port Change Logs

At software startup, a log shows whether the USB or the RJ-45 console is active. Each device in a stack issues this log. Every device always first displays the RJ-45 media type.

In the sample output, device 1 has a connected USB console cable. Because the bootloader did not change to the USB console, the first log from the device shows the RJ-45 console. A short time later, the console changes and the USB console log appears. device 2 and device 3 have connected RJ-45 console cables.

```
switch-stack-1
*Mar  1 00:01:00.171: %USB_CONSOLE-6-MEDIA_RJ45: Console media-type is RJ45.
*Mar  1 00:01:00.431: %USB_CONSOLE-6-MEDIA_USB: Console media-type is USB.
```

When the USB cable is removed or the PC de-activates the USB connection, the hardware automatically changes to the RJ-45 console interface:

You can configure the console type to always be RJ-45, and you can configure an inactivity timeout for the USB connector.

## USB Type A Port

The USB Type A port provides access to external USB flash devices, also known as thumb drives or USB keys. The port supports Cisco USB flash drives with capacities from 128 MB to 16 GB (USB devices with port densities of 128 MB, 256 MB, 1 GB, 4 GB, 8 GB, and 16 GB are supported). You can use standard Cisco IOS command-line interface (CLI) commands to read, write, erase, and copy to or from the flash device. You can also configure the devices to boot from the USB flash drive.

## Disabling USB Ports

From Cisco IOS XE Bengaluru 17.5.x, all the USB ports in a standalone or stacked device can be disabled using the **platform usb disable** command. To reenables the USB ports, use the **no platform usb disable** command.

When a USB port is disabled, no system messages are generated if a USB is inserted.




---


**Note** The **platform usb disable** command does not disable Bluetooth dongles connected to USB ports.

---

## Interface Connections

Devices within a single VLAN can communicate directly through any switch. Ports in different VLANs cannot exchange data without going through a routing device. With a standard Layer 2 device, ports in different VLANs have to exchange information through a router. By using the device with routing enabled, when you configure both VLAN 20 and VLAN 30 with an SVI to which an IP address is assigned, packets can be sent from Host A to Host B directly through the device with no need for an external router.

Figure 1: Connecting VLANs with a Switch



When the Network Advantage license is used on the device or the active device, the device uses the routing method to forward traffic between interfaces. If the Network Essentials license is used on the device or the active device, only basic routing (static routing and RIP) is supported. Whenever possible, to maintain high performance, forwarding is done by the device hardware. However, only IPv4 packets with Ethernet II encapsulation are routed in hardware.

The routing function can be enabled on all SVIs and routed ports. The device routes only IP traffic. When IP routing protocol parameters and address configuration are added to an SVI or routed port, any IP traffic received from these ports is routed.

## Interface Configuration Mode

The device supports these interface types:

- Physical ports: Device ports and routed ports
- VLANs: Switch virtual interfaces
- Port channels: EtherChannel interfaces

You can also configure a range of interfaces.

To configure a physical interface (port), specify the interface type, stack member number (only stacking-capable switches), module number, and device port number, and enter interface configuration mode.

- Type: Gigabit Ethernet (GigabitEthernet or gi) for 10/100/1000 Mbps Ethernet ports, 2.5-Gigabit Ethernet (TwoGigabitEthernet or tw) for 2.5 Gbps, 5-Gigabit Ethernet (FiveGigabitEthernet or fi) for 5 Gbps, 10-Gigabit Ethernet (TenGigabitEthernet or te) for 10 Gbps, 25-Gigabit Ethernet (TwentyFiveGigE or twe) for 25 Gbps, small form-factor pluggable (SFP) module Gigabit Ethernet and 10-Gigabit Ethernet interfaces and quad small-form-factor pluggable (QSFP) module 40-Gigabit Ethernet (FortyGigabitEthernet or fo) for 40 Gbps, and 100-Gigabit Ethernet (HundredGigE or hu) for 100 Gbps.



**Note** On a Cisco Catalyst 9300L Series Switch, the Type can be either Gigabit Ethernet or 10-Gigabit Ethernet.

- You can use the switch port LEDs in Stack mode to identify the stack member number of a device.

- Module number: The module or slot number on the device: switch (downlink) ports are 0, and uplink ports are 1.
- Port number: The interface number on the device. The 10/100/1000 port numbers always begin at 1, starting with the far left port when facing the front of the device, for example, GigabitEthernet1/0/1 or GigabitEthernet1/0/8.

On a device with SFP uplink ports, the module number is 1 and the port numbers restart. For example, if the device has 24 10/100/1000 ports, the SFP module ports are GigabitEthernet1/1/1 through GigabitEthernet1/1/4 or TenGigabitEthernet1/1/1 through TenGigabitEthernet1/1/4.

You can identify physical interfaces by physically checking the interface location on the device. You can also use the **show** privileged EXEC commands to display information about a specific interface or all the interfaces on the switch. The remainder of this chapter primarily provides physical interface configuration procedures.

These are examples of how to configure interfaces on stacking-capable and standalone device:

- To configure 10/100/1000 port 4 on a standalone device, enter this command:

```
Device# configure terminal  
Device(config)# interface GigabitEthernet1/0/4
```

- To configure 10-Gigabit Ethernet port 1 on a standalone device, enter this command:

```
Device# configure terminal  
Device(config)# interface TenGigabitEthernet 1/1/1
```

- To configure 10-Gigabit Ethernet port on stack member 3, enter this command:

```
Device# configure terminal  
Device(config)# interface TenGigabitEthernet 3/1/1
```

- To configure the first SFP module (uplink) port on a standalone device, enter this command:

```
Device# configure terminal  
Device(config)# interface GigabitEthernet 1/1/1
```

## Breakout Interfaces

Cisco Catalyst 9300 Series Switches support dual mode breakout cables. Dual mode breakout cables support both 4x10G conversion and straight 40G support. Breakout cables enable a single 40G QSFP+ interface to be split into four 10G SFP+ interfaces.

Breakout cable support is available only on the following switch models and network modules, with a few limitations.

### Switch Models

- C9300-24UX
- C9300-48UXM
- C9300-48UN
- C9300L-24UXG-2Q

- C9300L-48UXG-2Q
- C9300X-12Y
- C9300X-24Y
- C9300X-24HX
- C9300X-48HX
- C9300X-48TX
- C9300X-48HXN

### Network Modules

- C3850-NM-2-40G
- C9300-NM-2Q
- C9300X-NM-2C
- C9300X-NM-4C

## Limitations for Breakout Interfaces

- To enable breakout for dual mode QSFP breakout cables, the **hw-module breakout module slot port port-range switch switch-num** command must be configured on the two uplink ports of the switch. The range for the variables in the **hw-module breakout module slot port port-range switch switch-num** command are given below:
  - *slot*: Slot number of port depending on the chassis model. This can be only 1.
  - *port-range*: Single port or range of ports on which breakout is configured. The range is from 1 to 2. On the C9300X-NM-4C network module, the range of ports is from 1 to 4.
  - *switch-num*: Switch number in the stack. The range varies from 1 to 8.
- On the Cisco Catalyst C9300X-48HXN Series Switches, breakout cable is supported only on port 1 of the C9300X-NM-2C network module. Breakout cable is not supported on port 2 of the C9300X-NM-2C network module. Both port 1 and port 2 can be used for 40/100G SFPs.
- The C9300X-NM-2C and C9300X-NM-4C network modules does not support breakout cables for 100G QSFPs.
- See [Breakout Interfaces, on page 9](#) for the list of configurable interfaces.

## Default Ethernet Interface Configuration

To configure Layer 2 parameters, if the interface is in Layer 3 mode, you must enter the **switchport** interface configuration command without any parameters to put the interface into Layer 2 mode. This shuts down the interface and then re-enables it, which might generate messages on the device to which the interface is connected. When you put an interface that is in Layer 3 mode into Layer 2 mode, the previous configuration information related to the affected interface might be lost, and the interface is returned to its default configuration.

This table shows the Ethernet interface default configuration, including some features that apply only to Layer 2 interfaces.

**Table 1: Default Layer 2 Ethernet Interface Configuration**

Feature	Default Setting
Operating mode	Layer 2 or switching mode ( <b>switchport</b> command).
Allowed VLAN range	VLANs 1 to 4094.
Default VLAN (for access ports)	VLAN 1 (Layer 2 interfaces only).
Native VLAN (for IEEE 802.1Q trunks)	VLAN 1 (Layer 2 interfaces only).
VLAN trunking	Switchport mode dynamic auto (supports DTP) (Layer 2 interfaces only).
Port enable state	All ports are enabled.
Port description	None defined.
Speed	Autonegotiate. (Not supported on the 10-Gigabit interfaces, and also on the fiber SKUs: C9300-24S and C9300-48S.)
Duplex mode	Autonegotiate. (Not supported on the 10-Gigabit interfaces, and also on the fiber SKUs: C9300-24S and C9300-48S.)
Flow control	Flow control is set to <b>receive: on</b> . It is always off for sent packets.
EtherChannel (PAgP)	Disabled on all Ethernet ports.
Port blocking (unknown multicast and unknown unicast traffic)	Disabled (not blocked) (Layer 2 interfaces only).
Broadcast, multicast, and unicast storm control	Disabled.
Protected port	Disabled (Layer 2 interfaces only).
Port security	Disabled (Layer 2 interfaces only).
Port Fast	Disabled.
Auto-MDIX	Enabled.  <b>Note</b> The switch might not support a pre-standard powered device, such as Cisco IP phones and access points that do not fully support IEEE 802.3af, if that powered device is connected to the switch through a crossover cable. This is regardless of whether auto-MIDX is enabled on the switch port.
Power over Ethernet (PoE)	Enabled (auto).(Not supported on C9300-24T, C9300-48T, C9300-24S, and C9300-48S)

## Interface Speed and Duplex Mode

Ethernet interfaces on the switch operate at 10, 100, 1000 Mbps, 2.5 Gbps, 5 Gbps, 10 Gbps and in either full-duplex or half-duplex mode. In full-duplex mode, two stations can send and receive traffic at the same time. Normally, 10-Mbps ports operate in half-duplex mode, which means that stations can either receive or send traffic.

Switch modules include Gigabit Ethernet (10/100/1000-Mbps) ports. The switch also includes multigigabit ethernet ports which support speeds up to 2.5 Gbps (100/1000/2500-Mbps), 5 Gbps (100/1000/2500/5000-Mbps), 10 Gbps (100/1000/2500/5000/10000-Mbps); SFP modules that support speeds up to 1 Gbps, SFP+ modules that support speeds up to 10 Gbps, SFP28 modules that support speeds up to 25 Gbps.




---

**Note** Cisco Catalyst 9300L Series Switches support only SFP uplink ports with speeds up to 1Gbps and SFP+ uplink ports with speeds up to 10 Gbps.

---

## Speed and Duplex Configuration Guidelines

When configuring an interface speed and duplex mode, note these guidelines:

- Gigabit Ethernet (10/100/1000-Mb/s) ports support all speed options and all duplex options (auto, half, and full). However, Gigabit Ethernet ports operating at 1000 Mb/s and above do not support half-duplex mode.

Multigigabit ethernet ports (2.5 Gb/s, 5Gb/s, 10 Gb/s) support all speed options but only support auto and full duplex mode. These ports do not support half-duplex mode at any speed.

SFP ports operating at 1 Gb/s, SFP+ ports operating at 10 Gb/s, SFP28 ports operating at 25 Gb/s and QSFP ports operating at 40 Gb/s only **no speed nonegotiate** or **speed nonegotiate**. Duplex options are not supported.




---

**Note** SFP, SFP+ and SFP28 ports support speed (auto/10/100/100) and duplex (auto/full/half) options only if the 1000Base-T SFP or the GLC-GE-100FX modules are used.

---

QSFP ports operating at 40 Gb/s support all speed options but only support auto and full duplex.

- If both ends of the line support autonegotiation, we highly recommend the default setting of **auto** negotiation.
- If one interface supports autonegotiation and the other end does not, configure duplex and speed on both interfaces; do not use the **auto** setting on the supported side.
- When STP is enabled and a port is reconfigured, the device can take up to 30 seconds to check for loops. The port LED is amber while STP reconfigures. As best practice, we suggest configuring the speed and duplex options on a link to auto or to fixed on both the ends. If one side of the link is configured to auto and the other side is configured to fixed, the link may or may not be up and this is expected.



**Caution** Changing the interface speed and duplex mode configuration might shut down and re-enable the interface during the reconfiguration.

## Port Settings

The **port-settings** command can simultaneously or separately configure the speed, duplex, and auto negotiation for an interface, an interface range, or a port channel interface.

When using a single command to configure multiple parameters of the port-settings command, the order must be, **speed**, **duplex**, and **autoneg**. If you specify **speed** first, you can configure **duplex** and **autoneg** for the interface. If you specify **duplex** first, you can only configure **autoneg**. And, if you specify **autoneg** first, you cannot configure **speed** or **duplex**.

If the **port-settings** command is configured, this configuration is displayed only in the output of the **show running-config yang** command. The **show running-config** command output will not display information about this command.

For more information, see the section, Configuring Port Settings for an Interface.

### Comparison of Commands

The **port-settings** command can be used instead of the **speed**, **duplex**, and **negotiation auto** commands available in the interface configuration mode.

The **port-settings**, **speed**, **duplex**, and **negotiation auto** commands coexist in the CLI.

Because the same parameters for an interface can be configured through two commands, the last configured values are used by the configuration.

This table provides a one-to-one comparison of the existing and newly-added commands:

*Table 2: Command Comparison*

Existing Command	Newly-Added port-settings Command
<b>speed 10</b>	<b>port-settings speed 10</b>
<b>speed 100</b>	<b>port-settings speed 100</b>
<b>speed auto</b>	<b>port-settings speed auto</b>
<b>speed auto 10 100</b>	<b>port-settings speed auto-list 10 100</b>
<b>speed nonegotiate</b>	<b>port-settings autoneg disable</b>
<b>duplex half</b>	<b>port-settings duplex half</b>
<b>duplex full</b>	<b>port-settings duplex full</b>
<b>negotiation auto</b>	<b>port-settings autoneg enable</b>
<b>no negotiation auto</b>	<b>port-settings autoneg disable</b>

## IEEE 802.3x Flow Control

Flow control enables connected Ethernet ports to control traffic rates during congestion by allowing congested nodes to pause link operation at the other end. If one port experiences congestion and cannot receive any more traffic, it notifies the other port by sending a pause frame to stop sending until the condition clears. Upon receipt of a pause frame, the sending device stops sending any data packets, which prevents any loss of data packets during the congestion period.




---

**Note** The switch ports can receive, but not send, pause frames.

---

You use the **flowcontrol** interface configuration command to set the interface's ability to **receive** pause frames to **on**, **off**, or **desired**. The default state is **on**.

When set to **desired**, an interface can operate with an attached device that is required to send flow-control packets or with an attached device that is not required to but can send flow-control packets.

These rules apply to flow control settings on the device:

- **receive on** (or **desired**): The port cannot send pause frames but can operate with an attached device that is required to or can send pause frames; the port can receive pause frames.
- **receive off**: Flow control does not operate in either direction. In case of congestion, no indication is given to the link partner, and no pause frames are sent or received by either device.




---

**Note** For details on the command settings and the resulting flow control resolution on local and remote ports, see the **flowcontrol** interface configuration command in the command reference for this release.

---

## Layer 3 Interfaces

The device supports these types of Layer 3 interfaces:

- **SVIs**: You should configure SVIs for any VLANs for which you want to route traffic. SVIs are created when you enter a VLAN ID following the **interface vlan** global configuration command. To delete an SVI, use the **no interface vlan** global configuration command. You cannot delete interface VLAN 1.



- 
- Note**
- When you create an SVI, it does not become active until it is associated with a physical port.
  - SVI MAC addresses do not change after a device reload. This is expected behavior.
- 

When configuring SVIs, you can use the **switchport autostate exclude** command on a port to exclude that port from being included in determining SVI line-state. To disable autostate on the SVI, use the **no autostate** command on the SVI.

- Routed ports: Routed ports are physical ports configured to be in Layer 3 mode by using the **no switchport** interface configuration command. A routed port supports VLAN subinterfaces.

VLAN subinterface: A 802.1Q VLAN subinterface is a virtual Cisco IOS interface that is associated with a VLAN id on a routed physical interface. The parent interface is a physical port. Subinterfaces can be created only on Layer 3 physical interfaces. A subinterface can be associated with different functionalities such as IP addressing, forwarding policies, Quality of Service (QoS) policies, and security policies. Subinterfaces divide the parent interface into two or more virtual interfaces on which you can assign unique Layer 3 parameters such as IP addresses and dynamic routing protocols. The IP address for each subinterface should be in a different subnet from any other subinterface on the parent interface.

- Layer 3 EtherChannel ports: EtherChannel interfaces made up of routed ports.

A Layer 3 device can have an IP address assigned to each routed port and SVI.

There is no defined limit to the number of SVIs and routed ports that can be configured in a device or in a device stack. However, the interrelationship between the number of SVIs and routed ports and the number of other features being configured might have an impact on CPU usage because of hardware limitations. If the device is using its maximum hardware resources, attempts to create a routed port or SVI have these results:

- If you try to create a new routed port, the device generates a message that there are not enough resources to convert the interface to a routed port, and the interface remains as a switchport.
- If you try to create an extended-range VLAN, an error message is generated, and the extended-range VLAN is rejected.
- If the device is notified by VLAN Trunking Protocol (VTP) of a new VLAN, it sends a message that there are not enough hardware resources available and shuts down the VLAN. The output of the **show vlan** user EXEC command shows the VLAN in a suspended state.
- If the device attempts to boot up with a configuration that has more VLANs and routed ports than hardware can support, the VLANs are created, but the routed ports are shut down, and the device sends a message that this was due to insufficient hardware resources.



**Note** All Layer 3 interfaces require an IP address to route traffic. This procedure shows how to configure an interface as a Layer 3 interface and how to assign an IP address to an interface:

If the physical port is in Layer 2 mode (the default), you must enter the **no switchport** interface configuration command to put the interface into Layer 3 mode. Entering a **no switchport** command disables and then re-enables the interface, which might generate messages on the device to which the interface is connected. Furthermore, when you put an interface that is in Layer 2 mode into Layer 3 mode, the previous configuration information related to the affected interface might be lost, and the interface is returned to its default configuration.

## How to Configure Interface Characteristics

The following sections provide information about the various tasks that comprise the procedure to configure interface characteristics.

## Configuring an Interface

These general instructions apply to all interface configuration processes.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>interface</b> <b>Example:</b> Device(config)# <b>interface</b> <b>gigabitethernet1/0/1</b> Device(config-if)#	Identifies the interface type, the device number (only on stacking-capable switches), and the number of the connector. <b>Note</b> You do not need to add a space between the interface type and the interface number. For example, in the preceding line, you can specify either <b>gigabitethernet 1/0/1</b> , <b>gigabitethernet1/0/1</b> , <b>gi 1/0/1</b> , or <b>gi1/0/1</b> .
<b>Step 4</b>	Follow each <b>interface</b> command with the interface configuration commands that the interface requires.	Defines the protocols and applications that will run on the interface. The commands are collected and applied to the interface when you enter another interface command or enter <b>end</b> to return to privileged EXEC mode.
<b>Step 5</b>	<b>interface range</b> or <b>interface range macro</b>	(Optional) Configures a range of interfaces. <b>Note</b> Interfaces configured in a range must be the same type and must be configured with the same feature options.
<b>Step 6</b>	<b>show interfaces</b>	Displays a list of all interfaces on or configured for the switch. A report is provided for each interface that the device supports or for the specified interface.

## Adding a Description for an Interface

Follow these steps to add a description for an interface.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b>  Device> <b>enable</b>	Enables privileged EXEC mode.  Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b>  Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>interface</b> <i>interface-id</i> <b>Example:</b>  Device(config)# <b>interface</b> <b>gigabitethernet1/0/2</b>	Specifies the interface for which you are adding a description, and enter interface configuration mode.
<b>Step 4</b>	<b>description</b> <i>string</i> <b>Example:</b>  Device(config-if)# <b>description</b> <b>Connects</b> <b>to Marketing</b>	Adds a description for an interface.
<b>Step 5</b>	<b>end</b> <b>Example:</b>  Device(config-if)# <b>end</b>	Returns to privileged EXEC mode.
<b>Step 6</b>	<b>show interfaces</b> <i>interface-id</i> <b>description</b>	Verifies your entry.
<b>Step 7</b>	<b>copy running-config startup-config</b> <b>Example:</b>  Device# <b>copy running-config</b> <b>startup-config</b>	(Optional) Saves your entries in the configuration file.

## Configuring a Range of Interfaces

To configure multiple interfaces with the same configuration parameters, use the **interface range** global configuration command. When you enter the interface-range configuration mode, all command parameters that you enter are attributed to all interfaces within that range until you exit this mode.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>interface range</b> { <i>port-range</i>   <b>macro</b> <i>macro_name</i> } <b>Example:</b> Device(config)# <b>interface range macro</b>	Specifies the range of interfaces (VLANs or physical ports) to be configured, and enter interface-range configuration mode. <ul style="list-style-type: none"> <li>You can use the <b>interface range</b> command to configure up to five port ranges or a previously defined macro.</li> <li>The <b>macro</b> variable is explained in <a href="#">Configuring and Using Interface Range Macros</a>.</li> <li>In a comma-separated <i>port-range</i>, you must enter the interface type for each entry and enter spaces before and after the comma.</li> <li>In a hyphen-separated <i>port-range</i>, you do not need to re-enter the interface type, but you must enter a space before the hyphen.</li> </ul> <p><b>Note</b> Use the normal configuration commands to apply the configuration parameters to all interfaces in the range. Each command is executed as it is entered.</p>
<b>Step 4</b>	<b>end</b> <b>Example:</b> Device(config)# <b>end</b>	Returns to privileged EXEC mode.
<b>Step 5</b>	<b>show interfaces</b> [ <i>interface-id</i> ] <b>Example:</b> Device# <b>show interfaces</b>	Verifies the configuration of the interfaces in the range.

	Command or Action	Purpose
<b>Step 6</b>	<b>copy running-config startup-config</b> <b>Example:</b> <pre>Device# copy running-config startup-config</pre>	(Optional) Saves your entries in the configuration file.

## Configuring and Using Interface Range Macros

You can create an interface range macro to automatically select a range of interfaces for configuration. Before you can use the **macro** keyword in the **interface range macro** global configuration command string, you must use the **define interface-range** global configuration command to define the macro.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> <pre>Device&gt; enable</pre>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> <pre>Device# configure terminal</pre>	Enters global configuration mode.
<b>Step 3</b>	<b>define interface-range <i>macro_name</i></b> <i>interface-range</i> <b>Example:</b> <pre>Device(config)# define interface-range enet_list gigabitethernet1/0/1 - 2</pre>	Defines the interface-range macro, and saves it in NVRAM. <ul style="list-style-type: none"> <li>• The <i>macro_name</i> is a 32-character maximum character string.</li> <li>• A macro can contain up to five comma-separated interface ranges.</li> <li>• Each <i>interface-range</i> must consist of the same port type.</li> </ul> <p><b>Note</b> Before you can use the <b>macro</b> keyword in the <b>interface range macro</b> global configuration command string, you must use the <b>define interface-range</b> global configuration command to define the macro.</p>

	Command or Action	Purpose
<b>Step 4</b>	<b>interface range macro</b> <i>macro_name</i> <b>Example:</b> <pre>Device(config)# interface range macro enet_list</pre>	Selects the interface range to be configured using the values saved in the interface-range macro called <i>macro_name</i> . You can now use the normal configuration commands to apply the configuration to all interfaces in the defined macro.
<b>Step 5</b>	<b>end</b> <b>Example:</b> <pre>Device(config)# end</pre>	Returns to privileged EXEC mode.
<b>Step 6</b>	<b>show running-config   include define</b> <b>Example:</b> <pre>Device# show running-config   include define</pre>	Shows the defined interface range macro configuration.
<b>Step 7</b>	<b>copy running-config startup-config</b> <b>Example:</b> <pre>Device# copy running-config startup-config</pre>	(Optional) Saves your entries in the configuration file.

## Setting the Interface Speed and Duplex Parameters

Follow these steps to configure the interface speed and duplex parameters.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> <pre>Device&gt; enable</pre>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> <pre>Device# configure terminal</pre>	Enters global configuration mode.
<b>Step 3</b>	<b>interface</b> <i>interface-id</i> <b>Example:</b>	Specifies the physical interface to be configured, and enters interface configuration mode.

	Command or Action	Purpose
	<pre>Device(config)# interface gigabitethernet1/0/3</pre>	
<b>Step 4</b>	<p><b>speed</b> {10   100   1000   2500   5000   10000   auto [10   100   1000   2500   5000   10000]   nonegotiate}</p> <p><b>Example:</b></p> <pre>Device(config-if)# speed 10</pre>	<p>Enters the appropriate speed parameter for the interface:</p> <ul style="list-style-type: none"> <li>Enter <b>10</b>, <b>100</b>, <b>1000</b>, <b>2500</b>, <b>5000</b>, or <b>10000</b> to set a specific speed for the interface.</li> </ul> <p><b>Note</b> Cisco Catalyst 9300L Series Switches support only <b>10</b> Mb/s, <b>100</b>Mb/s, <b>1000</b>Mb/s, <b>10000</b> Mb/s, and <b>auto</b> speed options.</p> <ul style="list-style-type: none"> <li>Enter <b>auto</b> to enable the interface to autonegotiate speed with the connected device. If you specify a speed and also set the <b>auto</b> keyword, the port autonegotiates only at the specified speeds.</li> <li>The <b>nonegotiate</b> keyword is available only for SFP module ports. SFP module ports operate only at 1000 Mb/s but can be configured to not negotiate if connected to a device that does not support autonegotiation.</li> </ul>
<b>Step 5</b>	<p><b>duplex</b> {auto   full   half}</p> <p><b>Example:</b></p> <pre>Device(config-if)# duplex half</pre>	<p>Enters the duplex parameter for the interface.</p> <p>Enables half-duplex mode (for interfaces operating only at 10 or 100 Mb/s). Half duplex is not supported on multi-Gigabit Ethernet ports configured for speed of 1000 Mb/s.</p> <p>You can configure the duplex setting when the speed is set to <b>auto</b>.</p>
<b>Step 6</b>	<p><b>end</b></p> <p><b>Example:</b></p> <pre>Device(config-if)# end</pre>	<p>Returns to privileged EXEC mode.</p>
<b>Step 7</b>	<p><b>show interfaces</b> <i>interface-id</i></p> <p><b>Example:</b></p> <pre>Device# show interfaces gigabitethernet1/0/3</pre>	<p>Displays the interface speed and duplex mode configuration.</p>
<b>Step 8</b>	<p><b>copy running-config startup-config</b></p> <p><b>Example:</b></p>	<p>(Optional) Saves your entries in the configuration file.</p>

	Command or Action	Purpose
	Device# <code>copy running-config startup-config</code>	

## Configuring Port Settings for an Interface

Use the **port-settings** command to simultaneously or separately configure the speed, duplex, and auto negotiation for an interface.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<code>enable</code>	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password, if prompted.</li> </ul>
<b>Step 2</b>	<code>configure terminal</code>	Enters global configuration mode.
<b>Step 3</b>	<code>interface interface-name interface-ID</code>	Configures an interface, and enters interface configuration mode.
<b>Step 4</b>	<code>port-settings speed {10   100   1000   auto   auto-list}</code>	Enters the appropriate speed parameter for the interface.
<b>Step 5</b>	<code>port-settings duplex {auto   full   half}</code>	Configures duplex operation on an interface.
<b>Step 6</b>	<code>port-settings autoneg {enable   disable}</code>	Configures duplex operation on an interface.
<b>Step 7</b>	<code>port-settings speed 1000 duplex full autoneg enable</code>	Configures port settings for an interface. <ul style="list-style-type: none"> <li>• When configuring all port-setting parameters in a single command, the order must be <b>speed</b>, <b>duplex</b>, and <b>autoneg</b>.</li> </ul>
<b>Step 8</b>	<code>end</code>	Exits interface configuration mode and returns to privileged EXEC mode.
<b>Step 9</b>	<code>show running-config yang</code>	Displays the YANG-specific configurations on the device. <ul style="list-style-type: none"> <li>• The configured <b>port-settings</b> for the interface is displayed only in the output of the <b>show running-config yang</b> command.</li> </ul>

### Example

This example shows how to set the port settings for an interface.

```

Device# enable
Device# configure terminal
Device(config)# interface gigabitethernet 0/0
Device(config-if)# port-settings speed 1000
Device(config-if)# port-setting duplex full
Device(config-if)# port-setting autoneg enable
Device(config-if)# end

```

This example shows how to set all port setting parameters for an interface in a single command.

```

Device# enable
Device# configure terminal
Device(config)# interface gigabitethernet 0/0
Device(config-if)# port-settings speed 1000 duplex full autoneg enable
Device(config-if)# end

```

This sample output from the **show running-config yang** command, displays port settings configured for an interface.

```

Device# show running-config yang

Device# show running-config yang
Building configuration...
Current configuration : 19884 bytes
!!
Last configuration change at 23:53:04 UTC Tue Jun 11 2024 by platform
!
version 17.15
service timestamps debug datetime msec
service timestamps log datetime msec
!
hostname Device
!! vrf definition Mgmt-vrf
!
address-family ipv4
exit-address-family
!
address-family ipv6
exit-address-family
!
aaa new-model
!
aaa authentication login default local
aaa authorization exec default local
!
!
!
login on-success log
vtp domain GOV
vtp mode transparent
!!!!!!!
stackwise-virtual
  domain 1
!
crypto pki trustpoint SLA-TrustPoint
  enrollment pkcs12
  revocation-check crl
  hash sha256
!
!
!
interface Port-channel1

```

```

no shutdown
port-settings speed 1000 duplex full
!
interface GigabitEthernet0/0
vrf forwarding Mgmt-vrf
ip address 192.0.2.1 255.255.255.0
no shutdown
port-settings autoneg enable
!
interface GigabitEthernet1/1/0/1
no shutdown
!
line vty 0 4
exec-timeout 0 0
transport input ssh
line vty 5 15
transport input ssh
!
netconf-yang
end
Device#

```

## Configuring a Breakout Interface

For information about device compatibility, see the [Transceiver Module Group \(TMG\) Compatibility Matrix](#).

### C9300-NM-2Q Network Module

The default port connections for the C9300-NM-2Q module depends on whether you use a 40G QSFP module or a 4x10G breakout cable.

- If you use a 40G QSFP module, the ports default to 40G interfaces.
- If you use a 4x10G breakout cable, one 40G port is split into four 10G ports.
- You can use a combination of 40G QSFP modules and 4x10G breakout cables.
- For a 40G port —**FortyGigabitEthernet 1/1/***port-num*, the corresponding starting port in every set of the four 10G breakout ports is **TenGigabitEthernet 1/1/4***xport-num-3*, where *port-num* is the port number. For example, the starting port in the first set of 10G breakout ports is TenGigabitEthernet1/1/1, the starting port in the second set of 10G starting breakout ports is TenGigabitEthernet1/1/5 and so on.

The following tables list all the interfaces which are configurable depending on the type of module and cable used. Note that the **show interface status** command displays all the interfaces in the active state.

- In [Table 2](#), the 10G interfaces are displayed but are not active.
- In [Table 3](#), the 40G interfaces are displayed but are not active.

**Table 3: C9300-NM-2Q Module with two 40G QSFP Modules**

Interface	Action
FortyGigabitEthernet1/1/1	Configure this interface
FortyGigabitEthernet1/1/2	Configure this interface

Interface	Action
TenGigabitEthernet1/1/1	Disregard
TenGigabitEthernet1/1/2	Disregard
TenGigabitEthernet1/1/3	Disregard
TenGigabitEthernet1/1/4	Disregard
TenGigabitEthernet1/1/5	Disregard
TenGigabitEthernet1/1/6	Disregard
TenGigabitEthernet1/1/7	Disregard
TenGigabitEthernet1/1/8	Disregard

**Table 4: C9300-NM-2Q Module with two 4x10G Breakout Cables**

Interface	Action
FortyGigabitEthernet1/1/1	Disregard
FortyGigabitEthernet1/1/2	Disregard
TenGigabitEthernet1/1/1	Configure this interface
TenGigabitEthernet1/1/2	Configure this interface
TenGigabitEthernet1/1/3	Configure this interface
TenGigabitEthernet1/1/4	Configure this interface
TenGigabitEthernet1/1/5	Configure this interface
TenGigabitEthernet1/1/6	Configure this interface
TenGigabitEthernet1/1/7	Configure this interface
TenGigabitEthernet1/1/8	Configure this interface

### C9300-NM-2C and C9300-NM-4C Network Modules

The default port connections for the C9300-NM-2C and C9300-NM-4C modules depend on whether you use a 100G QSFP28 module or a 4x10G breakout cable or a 4x25G breakout cable.

- If you use a 100G QSFP28 module, the ports default to 100G interfaces.
- If you use a 4x10G breakout cable, one 100G port is split into four 10G ports. The ports are displayed as 25G ports but they will operate at 10G speed.
- If you use a 4x25G breakout cable, one 100G port is split into four 25G ports.
- You can use a combination of 100G QSFP28 modules and 4x10G breakout cables or 4x25G breakout cables.

- For a 100G port — **HundredGigabitEthernet 1/1/port-num**, the corresponding starting port in every set of the four 25G breakout ports is **TwentyfiveGigabitEthernet 1/1/4xport-num-3**, where *port-num* is the port number. For example, the starting port in the first set of 25G breakout ports is `TwentyfiveGigabitEthernet1/1/1`, the starting port in the second set of 25G starting breakout ports is `TwentyfiveGigabitEthernet1/1/5` and so on.

The following tables list all the interfaces which are configurable depending on the type of module and cable used. Note that the **show interface status** command displays all the interfaces in the active state.

**Table 5: C9300-NM-2C Module with two 100G QSFP Modules**

Interface	Action
HundredGigabitEthernet1/1/1	Configure this interface
HundredGigabitEthernet1/1/2	Configure this interface
TwentyFiveGigabitEthernet1/1/1	Disregard
TwentyFiveGigabitEthernet1/1/2	Disregard
TwentyFiveGigabitEthernet1/1/3	Disregard
TwentyFiveGigabitEthernet1/1/4	Disregard
TwentyFiveGigabitEthernet1/1/5	Disregard
TwentyFiveGigabitEthernet1/1/6	Disregard
TwentyFiveGigabitEthernet1/1/7	Disregard
TwentyFiveGigabitEthernet1/1/8	Disregard

**Table 6: C9300-NM-2Q Module with two 4x25G Breakout Cables**

Interface	Action
HundredGigabitEthernet1/1/1	Disregard
HundredGigabitEthernet1/1/2	Disregard
TwentyFiveGigabitEthernet1/1/1	Configure this interface
TwentyFiveGigabitEthernet1/1/2	Configure this interface
TwentyFiveGigabitEthernet1/1/3	Configure this interface
TwentyFiveGigabitEthernet1/1/4	Configure this interface
TwentyFiveGigabitEthernet1/1/5	Configure this interface
TwentyFiveGigabitEthernet1/1/6	Configure this interface
TwentyFiveGigabitEthernet1/1/7	Configure this interface

Interface	Action
TwentyFiveGigabitEthernet1/1/8	Configure this interface

**Table 7: C9300-NM-4C Module with four 100G QSFP Modules**

Interface	Action
HundredGigabitEthernet1/1/1	Configure this interface
HundredGigabitEthernet1/1/2	Configure this interface
HundredGigabitEthernet1/1/3	Configure this interface
HundredGigabitEthernet1/1/4	Configure this interface
TwentyFiveGigabitEthernet1/1/1	Disregard
TwentyFiveGigabitEthernet1/1/2	Disregard
TwentyFiveGigabitEthernet1/1/3	Disregard
TwentyFiveGigabitEthernet1/1/4	Disregard
TwentyFiveGigabitEthernet1/1/5	Disregard
TwentyFiveGigabitEthernet1/1/6	Disregard
TwentyFiveGigabitEthernet1/1/7	Disregard
TwentyFiveGigabitEthernet1/1/8	Disregard
TwentyFiveGigabitEthernet1/1/9	Disregard
TwentyFiveGigabitEthernet1/1/10	Disregard
TwentyFiveGigabitEthernet1/1/11	Disregard
TwentyFiveGigabitEthernet1/1/12	Disregard
TwentyFiveGigabitEthernet1/1/13	Disregard
TwentyFiveGigabitEthernet1/1/14	Disregard
TwentyFiveGigabitEthernet1/1/15	Disregard
TwentyFiveGigabitEthernet1/1/16	Disregard

**Table 8: C9300-NM-4C Module with two 4x25G Breakout Cables**

Interface	Action
HundredGigabitEthernet1/1/1	Disregard
HundredGigabitEthernet1/1/2	Disregard

Interface	Action
HundredGigabitEthernet1/1/3	Configure this interface
HundredGigabitEthernet1/1/4	Configure this interface
TwentyFiveGigabitEthernet1/1/1	Configure this interface
TwentyFiveGigabitEthernet1/1/2	Configure this interface
TwentyFiveGigabitEthernet1/1/3	Configure this interface
TwentyFiveGigabitEthernet1/1/4	Configure this interface
TwentyFiveGigabitEthernet1/1/5	Configure this interface
TwentyFiveGigabitEthernet1/1/6	Configure this interface
TwentyFiveGigabitEthernet1/1/7	Configure this interface
TwentyFiveGigabitEthernet1/1/8	Configure this interface
TwentyFiveGigabitEthernet1/1/9	Disregard
TwentyFiveGigabitEthernet1/1/10	Disregard
TwentyFiveGigabitEthernet1/1/11	Disregard
TwentyFiveGigabitEthernet1/1/12	Disregard
TwentyFiveGigabitEthernet1/1/13	Disregard
TwentyFiveGigabitEthernet1/1/14	Disregard
TwentyFiveGigabitEthernet1/1/15	Disregard
TwentyFiveGigabitEthernet1/1/16	Disregard

## Configuring Forty Gigabit Ethernet Interface

Follow these steps to configure the forty gigabit ethernet interface. Use the no form of the command to disable the fortygigabit ethernet interface.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b>  Device> <b>enable</b>	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>

	Command or Action	Purpose
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b>  Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>interface interface-id</b> <b>Example:</b>  Device(config)# <b>interface fortygigabitethernet1/0/9</b> Device(config-if)#	Specifies the interface type, that has to be configured.
<b>Step 4</b>	<b>end</b> <b>Example:</b>  Device(config)# <b>end</b>	Returns to privileged EXEC mode.

## Configuring the IEEE 802.3x Flow Control

Follow these steps to configure the IEEE 802.3x flow control.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b>  Device> <b>enable</b>	Enables privileged EXEC mode.  Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b>  Device# <b>configure terminal</b>	Enters global configuration mode
<b>Step 3</b>	<b>interface interface-id</b> <b>Example:</b>  Device(config)# <b>interface gigabitethernet1/0/1</b>	Specifies the physical interface to be configured, and enters interface configuration mode.
<b>Step 4</b>	<b>flowcontrol {receive} {on   off   desired}</b> <b>Example:</b>  Device(config-if)# <b>flowcontrol receive on</b>	Configures the flow control mode for the port.

	Command or Action	Purpose
<b>Step 5</b>	<b>end</b> <b>Example:</b>  Device (config-if) # <b>end</b>	Returns to privileged EXEC mode.
<b>Step 6</b>	<b>show flowcontrol interface</b> <i>interface-id</i> <b>Example:</b>  Device# <b>show flowcontrol interface</b> <b>GigabitEthernet1/0/1</b>	Verifies the specified interface flow control settings.
<b>Step 7</b>	<b>show flowcontrol module</b> <i>slot</i> <b>Example:</b>  Device# <b>show flowcontrol module 1</b>	Verifies the interface flow control settings on the module.
<b>Step 8</b>	<b>copy running-config startup-config</b> <b>Example:</b>  Device# <b>copy running-config</b> <b>startup-config</b>	(Optional) Saves your entries in the configuration file.

## Configuring a Layer 3 Interface

Follow these steps to configure a layer 3 interface.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b>  Device> <b>enable</b>	Enables privileged EXEC mode.  Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b>  Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>interface</b> { <b>gigabitethernet</b> <i>interface-id</i> }   { <b>vlan</b> <i>vlan-id</i> }   { <b>port-channel</b> <i>port-channel-number</i> } <b>Example:</b>  Device (config)# <b>interface</b> <b>gigabitethernet1/0/2</b>	Specifies the interface to be configured as a Layer 3 interface, and enters interface configuration mode.

	Command or Action	Purpose
<b>Step 4</b>	<b>no switchport</b> <b>Example:</b>  Device(config-if)# <b>no switchport</b>	(For physical ports only) Enters Layer 3 mode.
<b>Step 5</b>	<b>ip address ip_address subnet_mask</b> <b>Example:</b>  Device(config-if)# <b>ip address</b> <b>192.20.135.21 255.255.255.0</b>	Configures the IP address and IP subnet.
<b>Step 6</b>	<b>no shutdown</b> <b>Example:</b>  Device(config-if)# <b>no shutdown</b>	Enables the interface.
<b>Step 7</b>	<b>end</b> <b>Example:</b>  Device(config-if)# <b>end</b>	Returns to privileged EXEC mode.
<b>Step 8</b>	<b>show interfaces [interface-id]</b>	Verifies the configuration.
<b>Step 9</b>	<b>copy running-config startup-config</b> <b>Example:</b>  Device# <b>copy running-config</b> <b>startup-config</b>	(Optional) Saves your entries in the configuration file.

## Configuring a Logical Layer 3 GRE Tunnel Interface

### Before you begin

Generic Routing Encapsulation (GRE) is a tunneling protocol used to encapsulate network layer protocols inside virtual point-to-point links. A GRE tunnel only provides encapsulation and not encryption.

Because outer GRE packet cannot be fragmented, when GRE is configured on a switch, the maximum transmission unit (MTU) configured on the tunnel must be honored on the underlay physical network. This means that all links in the path from one end of the tunnel to the other must be equal to or greater than the tunnel MTU.



- Note**
- GRE tunnels are supported on the hardware on Cisco Catalyst 9000 switches. When GRE is configured without tunnel options, packets are hardware-switched. When GRE is configured with tunnel options (such as key, checksum, and so on), packets are switched in the software. A maximum of 100 GRE tunnels are supported.
  - Other features such as Access Control Lists (ACL) and Quality of Service (QoS) are not supported for the GRE tunnels.
  - The **tunnel path-mtu-discovery** command is not supported for GRE tunnels. To avoid fragmentation, you can set the maximum transmission unit (MTU) of both ends of the GRE tunnel to the lowest value by using the **ip mtu 256** command.

To configure a GRE tunnel, perform this task:

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>interface tunnel number</b> <b>Example:</b> Device(config)# <b>interface tunnel 2</b>	Enables tunneling on the interface.
<b>Step 4</b>	<b>ip address ip_address subnet_mask</b> <b>Example:</b> Device(config)# <b>ip address 100.1.1.1 255.255.255.0</b>	Configures the IP address and IP subnet.
<b>Step 5</b>	<b>tunnel source {ip_address   type_number}</b> <b>Example:</b> Device(config)# <b>tunnel source 10.10.10.1</b>	Configures the tunnel source.
<b>Step 6</b>	<b>tunnel destination {host_name   ip_address}</b> <b>Example:</b> Device(config)# <b>tunnel destination 10.10.10.2</b>	Configures the tunnel destination.
<b>Step 7</b>	<b>tunnel mode gre ip</b> <b>Example:</b>	Configures the tunnel mode.

	Command or Action	Purpose
	Device(config)# <b>tunnel mode gre ip</b>	
<b>Step 8</b>	<b>end</b> <b>Example:</b> Device(config)# <b>end</b>	Exits configuration mode.

## Configuring SVI Autostate Exclude

Follow these steps to exclude SVI autostate.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>interface <i>interface-id</i></b> <b>Example:</b> Device(config)# <b>interface</b> <b>gigabitethernet1/0/2</b>	Specifies a Layer 2 interface (physical port or port channel), and enters interface configuration mode.
<b>Step 4</b>	<b>switchport autostate exclude</b> <b>Example:</b> Device(config-if)# <b>switchport autostate</b> <b>exclude</b>	Excludes the access or trunk port when defining the status of an SVI line state (up or down)
<b>Step 5</b>	<b>end</b> <b>Example:</b> Device(config-if)# <b>end</b>	Returns to privileged EXEC mode.
<b>Step 6</b>	<b>show running config interface <i>interface-id</i></b> <b>Example:</b> Device# <b>show running config interface</b> <b>gigabitethernet1/0/2</b>	(Optional) Shows the running configuration. Verifies the configuration.

	Command or Action	Purpose
<b>Step 7</b>	<b>copy running-config startup-config</b> <b>Example:</b> <pre>Device# copy running-config startup-config</pre>	(Optional) Saves your entries in the configuration file.

## Shutting Down and Restarting an Interface

Shutting down an interface disables all functions on the specified interface and marks the interface as unavailable on all monitoring command displays. This information is communicated to other network servers through all dynamic routing protocols. The interface is not mentioned in any routing updates.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> <pre>Device&gt; enable</pre>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> <pre>Device# configure terminal</pre>	Enters global configuration mode.
<b>Step 3</b>	<b>interface {vlan vlan-id}   { gigabitethernet interface-id}   {port-channel port-channel-number}</b> <b>Example:</b> <pre>Device(config)# interface gigabitethernet1/0/2</pre>	Selects the interface to be configured.
<b>Step 4</b>	<b>shutdown</b> <b>Example:</b> <pre>Device(config-if)# shutdown</pre>	Shuts down an interface.
<b>Step 5</b>	<b>no shutdown</b> <b>Example:</b> <pre>Device(config-if)# no shutdown</pre>	Restarts an interface.
<b>Step 6</b>	<b>end</b> <b>Example:</b>	Returns to privileged EXEC mode.

	Command or Action	Purpose
	<code>Device(config-if)# end</code>	
<b>Step 7</b>	<b>show running-config</b> <b>Example:</b> <code>Device# show running-config</code>	Verifies your entries.

## Configuring the Console Media Type

Follow these steps to set the console media type to RJ-45. If you configure the console as RJ-45, USB console operation is disabled, and input comes only through the RJ-45 connector.

This configuration applies to all switches in a stack.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> <code>Device&gt; enable</code>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> <code>Device# configure terminal</code>	Enters global configuration mode.
<b>Step 3</b>	<b>line console 0</b> <b>Example:</b> <code>Device(config)# line console 0</code>	Configures the console and enters line configuration mode.
<b>Step 4</b>	<b>media-type rj45 switch <i>switch_number</i></b> <b>Example:</b> <code>Device(config-line)# media-type rj45 switch 1</code>	Configures the console media type to be only RJ-45 port. If you do not enter this command and both types are connected, the USB port is used by default.
<b>Step 5</b>	<b>end</b> <b>Example:</b> <code>Device(config)# end</code>	Returns to privileged EXEC mode.
<b>Step 6</b>	<b>copy running-config startup-config</b> <b>Example:</b>	(Optional) Saves your entries in the configuration file.

	Command or Action	Purpose
	Device# <code>copy running-config startup-config</code>	

## Configuring USB Inactivity Timeout

The configurable inactivity timeout reactivates the RJ-45 console port if the USB console port is activated but no input activity occurs on it for a specified time period. When the USB console port is deactivated due to a timeout, you can restore its operation by disconnecting and reconnecting the USB cable.



**Note** The configured inactivity timeout applies to all device in a stack. However, a timeout on one device does not cause a timeout on other device in the stack.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <code>enable</code>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <code>configure terminal</code>	Enters global configuration mode.
<b>Step 3</b>	<b>line console 0</b> <b>Example:</b> Device(config)# <code>line console 0</code>	Configures the console and enters line configuration mode.
<b>Step 4</b>	<b>usb-inactivity-timeout switch <i>switch_number</i> <i>timeout-minutes</i></b> <b>Example:</b> Device(config-line)# <code>usb-inactivity-timeout switch 1 30</code>	Specifies an inactivity timeout for the console port. The range is 1 to 240 minutes. The default is to have no timeout configured.
<b>Step 5</b>	<b>copy running-config startup-config</b> <b>Example:</b> Device# <code>copy running-config startup-config</code>	(Optional) Saves your entries in the configuration file.

## Disabling USB Ports

To disable all USB ports, perform this procedure.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b>  Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b>  Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>[no] platform usb disable</b> <b>Example:</b>  Device(config)# <b>platform usb disable</b>	Disables all the USB ports on the device. Use the <b>no platform usb disable</b> command to reenabling the USB ports.
<b>Step 4</b>	<b>exit</b> <b>Example:</b>  Device(config)# <b>exit</b>	Exits to privileged EXEC mode.
<b>Step 5</b>	<b>copy running-config startup-config</b> <b>Example:</b>  Device# <b>copy running-config startup-config</b>	(Optional) Saves your entries in the configuration file.

## Monitoring Interface Characteristics

The following sections provide information about monitoring interface characteristics.

### Monitoring Interface Status

Commands entered at the privileged EXEC prompt display information about the interface, including the versions of the software and the hardware, the configuration, and statistics about the interfaces.

*Table 9: show Commands for Interfaces*

Command	Purpose
<b>show interfaces interface-id status</b> [err-disabled]	Displays interface status or a list of interfaces in the error-disabled state.

Command	Purpose
<b>show interfaces</b> [ <i>interface-id</i> ] <b>switchport</b>	Displays administrative and operational status of switching (nonrouting) ports. You can use this command to find out if a port is in routing or in switching mode.
<b>show interfaces</b> [ <i>interface-id</i> ] <b>description</b>	Displays the description configured on an interface or all interfaces and the interface status.
<b>show ip interface</b> [ <i>interface-id</i> ]	Displays the usability status of all interfaces configured for IP routing or the specified interface.
<b>show interface</b> [ <i>interface-id</i> ] <b>stats</b>	Displays the input and output packets by the switching path for the interface.
<b>show interface</b> [ <i>interface-id</i> ] <b>link</b> [ <b>module number</b> ]	Displays the up time and down time of an interface or all interfaces.
<b>show interfaces</b> <i>interface-id</i>	(Optional) Displays speed and duplex on the interface.
<b>show interfaces transceiver dom-supported-list</b>	(Optional) Displays Digital Optical Monitoring (DOM) status on the connect SFP modules.
<b>show interfaces transceiver properties</b>	(Optional) Displays temperature, voltage, or amount of current on the interface.
<b>show interfaces</b> [ <i>interface-id</i> ] [{ <b>transceiver properties</b>   <b>detail</b> }] <i>module number</i>	Displays physical and operational status about an SFP module.
<b>show running-config interface</b> [ <i>interface-id</i> ]	Displays the running configuration in RAM for the interface.
<b>show version</b>	Displays the hardware configuration, software version, the names and sources of configuration files, and the boot images.
<b>show controllers ethernet-controller</b> <i>interface-id</i> <b>phy</b>	Displays the operational state of the auto-MDIX feature on the interface.

## Clearing and Resetting Interfaces and Counters

Table 10: *clear* Commands for Interfaces

Command	Purpose
<b>clear counters</b> [ <i>interface-id</i> ]	Clears interface counters.
<b>clear interface</b> <i>interface-id</i>	Resets the hardware logic on an interface.
<b>clear line</b> [ <i>number</i>   <b>console 0</b>   <b>vty number</b> ]	Resets the hardware logic on an asynchronous serial line.



**Note** The **clear counters** privileged EXEC command does not clear counters retrieved by using Simple Network Management Protocol (SNMP), but only those seen with the **show interface** privileged EXEC command.

# Configuration Examples for Interface Characteristics

The following sections provide examples of interface characteristics configurations.

## Example: Adding a Description to an Interface

The following example shows how to add a description to an interface:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTRL/Z.
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# description Connects to Marketing
Device(config-if)# end
Device# show interfaces gigabitethernet1/0/2 description

Interface Status          Protocol Description
Gi1/0/2    admin down        down      Connects to Marketing
```

## Example: Configuring Interfaces on a Stack-Capable Switch

The following example shows how to configure 10/100/1000 port 4 on a standalone switch:

```
Device(config)# interface gigabitethernet1/1/4
```

The following example shows how to configure the first SFP module uplink port on stack member 1:

```
Device(config)# interface gigabitethernet1/1/1
```

The following example shows how to configure 10-Gigabit Ethernet port on stack member 3:

```
Device(config)# interface tengigabitethernet3/0/1
```

## Example: Configuring a Range of Interfaces

The following example shows how to use the **interface range** global configuration command to set the speed to 100 Mb/s on ports 1 to 4 on switch 1:

```
Device# configure terminal
Device(config)# interface range gigabitethernet1/0/1 - 4
Device(config-if-range)# speed 100
```

The following example shows how to use a comma to add different interface type strings to the range to enable Gigabit Ethernet ports 1 to 3 and 10-Gigabit Ethernet ports 1 and 2 to receive flow-control pause frames:

```
Device# configure terminal
Device(config)# interface range gigabitethernet1/1/1 - 3 , tengigabitethernet1/1/1 - 2
Device(config-if-range)# flowcontrol receive on
```



**Note** If you enter multiple configuration commands while you are in interface-range mode, each command is executed as it is entered. The commands are not batched and executed after you exit interface-range mode. If you exit interface-range configuration mode while the commands are being executed, some commands might not be executed on all interfaces in the range. Wait until the command prompt reappears before exiting interface-range configuration mode.

## Example: Configuring and Using Interface Range Macros

The following example shows how to define an interface-range named *enet\_list* to include ports 1 and 2 on switch 1 and to verify the macro configuration:

```
Device# configure terminal
Device(config)# define interface-range enet_list gigabitethernet1/0/1 - 2
Device(config)# end
Device# show running-config | include define
define interface-range enet_list GigabitEthernet1/0/1 - 2
```

The following example shows how to create a multiple-interface macro named *macro1*:

```
Device# configure terminal
Device(config)# define interface-range macro1 gigabitethernet1/0/1 - 2, gigabitethernet1/0/5
- 7, tengigabitethernet1/1/1 -2
Device(config)# end
```

The following example shows how to enter interface-range configuration mode for the interface-range macro *enet\_list*:

```
Device# configure terminal
Device(config)# interface range macro enet_list
Device(config-if-range)#
```

The following example shows how to delete the interface-range macro *enet\_list* and to verify that it was deleted:

```
Device# configure terminal
Device(config)# no define interface-range enet_list
Device(config)# end
Device# show run | include define
Device#
```

## Example: Setting Interface Speed and Duplex Mode

The following example shows how to set the interface speed to 10 Mbps and the duplex mode to full, on a 10/100/1000 Mbps port:

```
Device# configure terminal
Device(config)# interface gigabitethernet1/0/3
Device(config-if)# speed 10
Device(config-if)# duplex full
```

The following example shows how to set the interface speed to 100 Mbps on a 10/100/1000 Mbps port:

```
Device# configure terminal
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# speed 100
```

## Example: Configuring a Layer 3 Interface

The following example shows how to configure a Layer 3 interface:

```
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# no switchport
Device(config-if)# ip address 192.20.135.21 255.255.255.0
Device(config-if)# no shutdown
```

## Example: Configuring a Breakout Interface

### Catalyst 9300 Series Switches

The following example shows a sample output of the **show interface status** command when a 40G QSFP module inserted in port1 is removed and a 4x10G breakout cable is inserted into port1.

```
Device# show interface status

Fo1/1/1                               notconnect  1           auto   auto unknown
Fo1/1/2                               notconnect  1           auto   auto unknown
Switch#
*Feb 11 18:01:09.492: %PLATFORM_PM-6-FRULINK_REMOVED: 1x40G Port1 uplink module removed
from switch 1 slot 1
*Feb 11 18:01:10.154: %PLATFORM_PM-6-FRULINK_INSERTED: BC:4x10G Port1 uplink module inserted
in the switch 1 slot 1
*Feb 11 18:01:11.492: %LINK-3-UPDOWN: Interface FortyGigabitEthernet1/1/1, changed state
to down
*Feb 11 18:01:13.160: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Tel/1/1
*Feb 11 18:01:15.867: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Tel/1/2
*Feb 11 18:01:18.571: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Tel/1/3
*Feb 11 18:01:21.276: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Tel/1/4
*Feb 11 18:01:23.358: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/1, changed state to
up
*Feb 11 18:01:23.448: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/2, changed state to
up
*Feb 11 18:01:23.538: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/3, changed state to
up
*Feb 11 18:01:23.630: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/4, changed state to
up
*Feb 11 18:01:24.358: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/1,
changed state to up
*Feb 11 18:01:24.449: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/2,
changed state to up
*Feb 11 18:01:24.539: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/3,
changed state to up
*Feb 11 18:01:24.552: %LINEPROTO-5-UPDOWN: Line protocol on Interface Vlan1, changed state
to up
```

## Example: Configuring a Breakout Interface

```
*Feb 11 18:01:24.630: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/4,
  changed state to up
Switch#show interfaces status | inc /1/
Fo1/1/2          notconnect    1              auto    auto unknown
Te1/1/1          connected     1              full    10G QSFP 4X10G AOCxM SFP
Te1/1/2          connected     1              full    10G
Te1/1/3          connected     1              full    10G
Te1/1/4          connected     1              full    10G
```

The following example shows a sample output of the **show interface status** command when a 4x10G breakout cable inserted into port1 is removed and a 40G QSFP module is inserted in port1.

```
Device# show interface status

*Feb 11 18:01:50.932: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Te1/1/1
  removed
*Feb 11 18:01:50.977: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Te1/1/2
  removed
*Feb 11 18:01:51.021: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Te1/1/3
  removed
*Feb 11 18:01:51.066: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Te1/1/4
  removed
*Feb 11 18:01:51.234: %PLATFORM_PM-6-FRULINK_REMOVED: BC:4x10G Port1 uplink module removed
  from switch 1 slot 1
*Feb 11 18:01:51.273: %PLATFORM_PM-6-FRULINK_INSERTED: 1x40G Port1 uplink module inserted
  in the switch 1 slot 1
*Feb 11 18:01:51.485: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/1,
  changed state to down
*Feb 11 18:01:51.551: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/2,
  changed state to down
*Feb 11 18:01:51.615: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/3,
  changed state to down
*Feb 11 18:01:51.682: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/4,
  changed state to down
*Feb 11 18:01:52.486: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/1, changed state to
  down
*Feb 11 18:01:52.552: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/2, changed state to
  down
*Feb 11 18:01:52.616: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/3, changed state to
  down
*Feb 11 18:01:52.681: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/4, changed state to
  down
Switch#show interfaces status | inc /1/
Fo1/1/1          notconnect    1              auto    auto unknown
Fo1/1/2          notconnect    1              auto    auto unknown
```

The following example shows a sample output of the **show interface status** command after enabling breakout on port 1 with 4x10G breakout cable inserted on port 1 using the **hw-module breakout port-num** command.

```
Device# show interface status
Device# show interfaces status | inc /1/

Fo1/1/1          connected     1              full    40G QSFP 40G SR4 SFP
Fo1/1/2          connected     1              full    40G QSFP 40G SR4 SFP
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# hw-module breakout module 1 port 1 switch 1
Device(config)# end

Device#
*Feb 11 18:03:11.673: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Fo1/1/1
  removed
*Feb 11 18:03:12.600: %SYS-5-CONFIG_I: Configured from console by console
*Feb 11 18:03:13.712: %PLATFORM_PM-6-FRULINK_REMOVED: 1x40G Port1 uplink module removed
  from switch 1 slot 1
```

```
*Feb 11 18:03:13.800: %LINEPROTO-5-UPDOWN: Line protocol on Interface
FortyGigabitEthernet1/1/1, changed state to down
*Feb 11 18:03:14.375: %PLATFORM_PM-6-FRULINK_INSERTED: BC:4x10G Port1 uplink module inserted
in the switch 1 slot 1
*Feb 11 18:03:14.800: %LINK-3-UPDOWN: Interface FortyGigabitEthernet1/1/1, changed state
to down
*Feb 11 18:03:17.376: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Tel/1/1
*Feb 11 18:03:20.078: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Tel/1/2
*Feb 11 18:03:22.781: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Tel/1/3
*Feb 11 18:03:25.487: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Tel/1/4
*Feb 11 18:03:27.569: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/1, changed state to
up
*Feb 11 18:03:27.660: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/2, changed state to
up
*Feb 11 18:03:27.751: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/3, changed state to
up
*Feb 11 18:03:27.843: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/4, changed state to
up
*Feb 11 18:03:28.569: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/1,
changed state to up
*Feb 11 18:03:28.659: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/2,
changed state to up
*Feb 11 18:03:28.751: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/3,
changed state to up
*Feb 11 18:03:28.843: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/4,
changed state to up
Switch#
```

The following example shows a sample output of the **show interface status** command after disabling breakout on port 1 with 4x10G breakout cable inserted on port 1 using the **no hw-module breakout port-num** command.

```
Device# show interface status
Device# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Device(config)# no hw-module breakout module 1 port 1 switch 1
Device(config)# end

*Feb 11 18:05:33.690: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Tel/1/1
removed
*Feb 11 18:05:33.736: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Tel/1/2
removed
*Feb 11 18:05:33.782: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Tel/1/3
removed
*Feb 11 18:05:33.828: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Tel/1/4
removed
*Feb 11 18:05:33.996: %PLATFORM_PM-6-FRULINK_REMOVED: BC:4x10G Port1 uplink module removed
from switch 1 slot 1
*Feb 11 18:05:34.065: %PLATFORM_PM-6-FRULINK_INSERTED: 1x40G Port1 uplink module inserted
in the switch 1 slot 1
*Feb 11 18:05:34.400: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/1,
changed state to down
*Feb 11 18:05:34.445: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/2,
changed state to down
*Feb 11 18:05:34.490: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/3,
changed state to down
*Feb 11 18:05:34.534: %LINEPROTO-5-UPDOWN: Line protocol on Interface TenGigabitEthernet1/1/4,
changed state to down
*Feb 11 18:05:35.401: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/1, changed state to
down
*Feb 11 18:05:35.446: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/2, changed state to
```

### Example: Configuring a Breakout Interface

```

down
*Feb 11 18:05:35.490: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/3, changed state to
down
*Feb 11 18:05:35.535: %LINK-3-UPDOWN: Interface TenGigabitEthernet1/1/4, changed state to
down

```

### Catalyst 9300X Series Switches

The following example shows a sample output of the **show interface status** command when a 100G QSFP28 module inserted in port 2 is removed and a 4x25G breakout cable is inserted into port 2.

```

Device# show interface status

*Jul 12 20:38:22.072: %PLATFORM_PM-6-FRULINK_REMOVED: 1x100G Port2 uplink module removed
from switch 1 slot 1
*Jul 12 20:38:24.073: %LINK-3-UPDOWN: Interface HundredGigE1/1/2, changed state to down
*Jul 12 20:38:24.344: %PLATFORM_PM-6-FRULINK_INSERTED: BC:4x25G Port2 uplink module inserted
in the switch 1 slot 1
*Jul 12 20:38:26.321: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Twel/1/5
*Jul 12 20:38:28.440: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Twel/1/6
*Jul 12 20:38:30.612: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Twel/1/7
*Jul 12 20:38:32.730: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Twel/1/8
*Jul 12 20:38:36.479: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/5, changed state to up
*Jul 12 20:38:36.768: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/6, changed state to up
*Jul 12 20:38:37.181: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/7, changed state to up
*Jul 12 20:38:37.480: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/5,
changed state to up
*Jul 12 20:38:37.542: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/8, changed state to up
*Jul 12 20:38:37.769: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/6,
changed state to up
*Jul 12 20:38:38.181: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/7,
changed state to up
*Jul 12 20:38:38.542: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/8,
changed state to up

```

The following example shows a sample output of the **show interface status** command when a 4x25G breakout cable inserted into port2 is removed and a 100G QSFP28 module is inserted in port2.

```

Device# show interface status

*Jul 12 20:40:26.116: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Twel/1/5
removed
*Jul 12 20:40:26.467: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Twel/1/6
removed
*Jul 12 20:40:26.733: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/5,
changed state to down
*Jul 12 20:40:26.734: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/6,
changed state to down
*Jul 12 20:40:26.737: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/7,
changed state to down
*Jul 12 20:40:26.737: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/8,
changed state to down
*Jul 12 20:40:26.822: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Twel/1/7
removed
*Jul 12 20:40:27.176: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Twel/1/8
removed
*Jul 12 20:40:27.179: %PLATFORM_PM-6-FRULINK_REMOVED: BC:4x25G Port2 uplink module removed
from switch 1 slot 1
*Jul 12 20:40:27.188: %PLATFORM_PM-6-FRULINK_INSERTED: 1x100G Port2 uplink module inserted
in the switch 1 slot 1

```

```
*Jul 12 20:40:27.733: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/5, changed state to down
*Jul 12 20:40:27.735: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/6, changed state to down
*Jul 12 20:40:27.736: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/7, changed state to down
*Jul 12 20:40:27.739: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/8, changed state to down
```

```
Device# show interfaces status | inc /1/
```

```
Hu1/1/1                notconnect  routed      full  100G unknown
Hu1/1/2                notconnect  1           full  100G unknown
```

The following example shows a sample output of the **show interface status** command when a 100G QSFP28 module inserted in port 2 is removed and a 4x10G breakout cable is inserted into port 2.

```
Device# show interface status
```

```
Hu1/1/1                notconnect  routed      full  100G unknown
Hu1/1/2                notconnect  1           full  40G unknown
C48-2019#
*Jul 12 21:56:14.208: %PLATFORM_PM-6-FRULINK_REMOVED: 1x100G Port2 uplink module removed
from switch 1 slot 1
*Jul 12 21:56:15.138: %PLATFORM_PM-6-FRULINK_INSERTED: BC:4x25G Port2 uplink module inserted
in the switch 1 slot 1
*Jul 12 21:56:16.208: %LINK-3-UPDOWN: Interface HundredGigE1/1/2, changed state to down
*Jul 12 21:56:17.911: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Twel1/1/5
*Jul 12 21:56:20.706: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Twel1/1/6
*Jul 12 21:56:23.504: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Twel1/1/7
*Jul 12 21:56:26.276: %PLATFORM_PM-6-MODULE_INSERTED: SFP module inserted with interface
name Twel1/1/8
*Jul 12 21:56:33.027: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/5, changed state to up
*Jul 12 21:56:33.607: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/6, changed state to up
*Jul 12 21:56:34.027: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/5,
changed state to up
*Jul 12 21:56:34.607: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/6,
changed state to up
*Jul 12 21:56:34.779: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/7, changed state to up
*Jul 12 21:56:35.541: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/8, changed state to up
*Jul 12 21:56:35.778: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/7,
changed state to up
*Jul 12 21:56:36.542: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/8,
changed state to up
```

```
Device# show interfaces status | inc /1/
```

```
Twel1/1/5              connected  1           full  10G QSFP 4X10G AOCxM SFP
Twel1/1/6              connected  1           full  10G
Twel1/1/7              connected  1           full  10G
Twel1/1/8              connected  1           full  10G
Hu1/1/1                notconnect  routed      full  100G unknown
```

The following example shows a sample output of the **show interface status** command when a 4x10G breakout cable inserted into port2 is removed and a 100G QSFP28 module is inserted in port2.

```
Device# show interface status
```

```
*Jul 12 22:00:09.958: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Twel1/1/5
removed
*Jul 12 22:00:10.177: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Twel1/1/6
removed
*Jul 12 22:00:10.397: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Twel1/1/7
removed
*Jul 12 22:00:10.617: %PLATFORM_PM-6-MODULE_REMOVED: SFP module with interface name Twel1/1/8
removed
```

**Example: Configuring the Console Media Type**

```
*Jul 12 22:00:10.619: %PLATFORM_PM-6-FRULINK_REMOVED: BC:4x25G Port2 uplink module removed
from switch 1 slot 1
*Jul 12 22:00:10.629: %PLATFORM_PM-6-FRULINK_INSERTED: 1x100G Port2 uplink module inserted
in the switch 1 slot 1
*Jul 12 22:00:10.726: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/5,
changed state to down
*Jul 12 22:00:10.727: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/6,
changed state to down
*Jul 12 22:00:10.730: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/7,
changed state to down
*Jul 12 22:00:10.730: %LINEPROTO-5-UPDOWN: Line protocol on Interface TwentyFiveGigE1/1/8,
changed state to down
*Jul 12 22:00:11.727: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/5, changed state to down
*Jul 12 22:00:11.729: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/6, changed state to down
*Jul 12 22:00:11.729: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/7, changed state to down
*Jul 12 22:00:11.732: %LINK-3-UPDOWN: Interface TwentyFiveGigE1/1/8, changed state to down

Device# show interfaces status | inc /1/

Hu1/1/1                notconnect    routed        full    100G unknown
Hu1/1/2                notconnect    1             full    100G unknown
```

## Example: Configuring the Console Media Type

The following example shows how to disable the USB console media type and enable the RJ-45 console media type:

```
Device# configure terminal
Device(config)# line console 0
Device(config-line)# media-type rj45 switch 1
```

This configuration terminates any active USB console media type in the stack. A log shows that this termination has occurred. This example shows that the console on switch 1 reverted to RJ-45.

```
*Mar  1 00:25:36.860: %USB_CONSOLE-6-CONFIG_DISABLE: Console media-type USB disabled by
system configuration, media-type reverted to RJ45.
```

At this point no switches in the stack allow a USB console to have input. A log entry shows when a console cable is attached. If a USB console cable is connected to switch 2, it is prevented from providing input.

```
*Mar  1 00:34:27.498: %USB_CONSOLE-6-CONFIG_DISALLOW: Console media-type USB is disallowed
by system configuration, media-type remains RJ45. (switch-stk-2)
```

The following example shows how to reverse the previous configuration and immediately activate any USB console that is connected:

```
Device# configure terminal
Device(config)# line console 0
Device(config-line)# no media-type rj45 switch 1
```

## Example: Configuring USB Inactivity Timeout

The following example shows how to configure the inactivity timeout to 30 minutes:

```
Device# configure terminal
Device(config)# line console 0
Device(config-line)# usb-inactivity-timeout switch 1 30
```

The following example shows how to disable the configuration:

```
Device# configure terminal
Device(config)# line console 0
Device(config-line)# no usb-inactivity-timeout switch 1
```

If there is no (input) activity on a USB console port for the configured number of minutes, the inactivity timeout setting applies to the RJ-45 port, and a log shows this occurrence:

```
*Mar 1 00:47:25.625: %USB_CONSOLE-6-INACTIVITY_DISABLE: Console media-type USB disabled
due to inactivity, media-type reverted to RJ45.
```

At this point, the only way to reactivate the USB console port is to disconnect and reconnect the cable.

When the USB cable on a switch is disconnected and reconnected, a log, which is similar to this, appears:

```
*Mar 1 00:48:28.640: %USB_CONSOLE-6-MEDIA_USB: Console media-type is USB.
```

## Additional References for Configuring Interface Characteristics

### Related Documents

Related Topic	Document Title
For complete syntax and usage information for the commands used in this chapter.	See the "Interface and Hardware Commands" section in the <i>Command Reference (Catalyst 9300 Series Switches)</i> .

## Feature History for Configuring Interface Characteristics

This table provides release and related information for the features explained in this module.

These features are available in all the releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Everest 16.5.1a	Interface Characteristics	Interface Characteristics includes interface types, connections, configuration modes, speed, and other aspects of configuring a physical interface on a device.  Support for this feature was introduced only on the 9300 switch models of the Cisco Catalyst 9300 Series Switches.

Release	Feature	Feature Information
Cisco IOS XE Everest 16.6.4	IEEE 802.3x Flow Control	The default value for <b>flowcontrol</b> interface configuration command was modified to <b>on</b> on all the models of the series.
Cisco IOS XE Fuji 16.8.1a	Breakout interfaces	Support for breakout interfaces was introduced on the following: <ul style="list-style-type: none"> <li>• Only the first four ports of C9300-24UX, C9300-48UXM and C9300-48UN models.</li> <li>• All the ports of the C9300-NM-2Q network module support breakout configuration</li> </ul>
Cisco IOS XE Fuji 16.9.1	Breakout interfaces	On Cisco Catalyst 9300 Series Switches, support for breakout configuration was introduced only on the first twelve ports of C9300-24UX, C9300-48UXM and C9300-48UN models.
Cisco IOS XE Gibraltar 16.10.1	Password Authentication on USB 3.0 SSD	Support for configuring password on a USB 3.0 SSD was enabled on all the models of the Cisco Catalyst 9300 Series Switches.
Cisco IOS XE Gibraltar 16.11.1c	Interface Characteristics	Support for configuration of interface characteristics was introduced on the 9300L switch models of the Cisco Catalyst 9300 Series Switches.
Cisco IOS XE Gibraltar 16.12.2	Breakout interfaces	Support for breakout configuration was introduced on the C9300L-24UXG-2Q and C9300L-48UXG-2Q models of the Cisco Catalyst 9300L Series Switches.
Cisco IOS XE Bengaluru 17.5.1	Disabling USB interfaces	Support to disable all USB ports on a standalone or stacked device was introduced.

Release	Feature	Feature Information
Cisco IOS XE Bengaluru 17.6.2	Breakout interfaces	Support for breakout configuration was introduced on the following: <ul style="list-style-type: none"> <li>• C9300X-12Y, C9300X-24Y, C9300X-48HX, C9300X-48TX, models of the Cisco Catalyst 9300X Series Switches.</li> <li>• C9300X-NM-2C and C9300X-NM-4C network modules.</li> </ul>
Cisco IOS XE Cupertino 17.7.1	Breakout interfaces	Support for breakout configuration was introduced on the following: <ul style="list-style-type: none"> <li>• C9300X-24HX model of the Cisco Catalyst 9300X Series Switches.</li> </ul>

Use the Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to <https://cfng.cisco.com/>.





## CHAPTER 2

# Configuring Auto-MDIX

- [Prerequisites for Auto-MDIX, on page 51](#)
- [Restrictions for Auto-MDIX, on page 51](#)
- [Information About Configuring Auto-MDIX, on page 51](#)
- [How to Configure Auto-MDIX, on page 52](#)
- [Example for Configuring Auto-MDIX, on page 53](#)
- [Auto-MDIX and Operational State, on page 53](#)
- [Additional References for Auto-MDIX, on page 54](#)
- [Feature History for Auto-MDIX, on page 54](#)

## Prerequisites for Auto-MDIX

To configure Layer 2 parameters, if the interface is in Layer 3 mode, you must enter the **switchport** interface configuration command without any parameters to put the interface into Layer 2 mode. This shuts down the interface and then re-enables it, which might generate messages on the device to which the interface is connected. When you put an interface that is in Layer 3 mode into Layer 2 mode, the previous configuration information related to the affected interface might be lost, and the interface is returned to its default configuration.

Automatic medium-dependent interface crossover (auto-MDIX) is enabled by default.

Auto-MDIX is supported on all 10/100/1000-Mb/s and on 10/100/1000BASE-TX small form-factor pluggable (SFP)-module interfaces. It is not supported on any other SFP, SFP+, or QSFP module interface.

## Restrictions for Auto-MDIX

The device might not support a pre-standard powered device—such as Cisco IP phones and access points that do not fully support IEEE 802.3af—if that powered device is connected to the device through a crossover cable. This is regardless of whether auto-MDIX is enabled on the switch port.

## Information About Configuring Auto-MDIX

The following sections provide information about Auto-MDIX.

## Auto-MDIX on an Interface

When automatic medium-dependent interface crossover (auto-MDIX) is enabled on an interface, the interface automatically detects the required cable connection type (straight through or crossover) and configures the connection appropriately. When connecting devices without the auto-MDIX feature, you must use straight-through cables to connect to devices such as servers, workstations, or routers and crossover cables to connect to other devices or repeaters. With auto-MDIX enabled, you can use either type of cable to connect to other devices, and the interface automatically corrects for any incorrect cabling. For more information about cabling requirements, see the hardware installation guide.



**Note** Auto-MDIX is enabled by default.

This table shows the link states that result from auto-MDIX settings and correct and incorrect cabling.

*Table 11: Link Conditions and Auto-MDIX Settings*

Local Side Auto-MDIX	Remote Side Auto-MDIX	With Correct Cabling	With Incorrect Cabling
On	On	Link up	Link up
On	Off	Link up	Link up
Off	On	Link up	Link up
Off	Off	Link up	Link down

## How to Configure Auto-MDIX

The following sections provide configurational information about Auto-MDIX.

### Configuring Auto-MDIX on an Interface

Auto MDIX is turned on by default. To disable Auto MDIX on a port, use the **no mdix auto** command under the interface configuration mode. To put it back to default, use the **mdix auto** command in the interface configuration mode. The following steps show how to enable the Auto MDIX.

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode

	Command or Action	Purpose
<b>Step 3</b>	<b>interface</b> <i>interface-id</i> <b>Example:</b> Device(config)# <b>interface</b> <b>gigabitethernet1/0/1</b>	Specifies the physical interface to be configured, and enter interface configuration mode.
<b>Step 4</b>	<b>mdix auto</b> <b>Example:</b> Device(config-if)# <b>mdix auto</b>	Enables the Auto MDIX feature.
<b>Step 5</b>	<b>end</b> <b>Example:</b> Device(config-if)# <b>end</b>	Returns to privileged EXEC mode.
<b>Step 6</b>	<b>copy running-config startup-config</b> <b>Example:</b> Device# <b>copy running-config</b> <b>startup-config</b>	(Optional) Saves your entries in the configuration file.

## Example for Configuring Auto-MDIX

This example shows how to enable auto-MDIX on a port:

```
Device# configure terminal
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# mdix auto
Device(config-if)# end
```

## Auto-MDIX and Operational State

Table 12: Auto-MDIX and Operational State

Auto-MDIX Setting and Operational State on an Interface	Description
Auto-MDIX on (operational: on)	Auto-MDIX is enabled and is fully functioning.
Auto-MDIX on (operational: off)	Auto-MDIX is enabled on this interface but it is not functioning. To allow auto-MDIX feature to function properly, you must also set the interface speed to be autonegotiated.
Auto-MDIX off	Auto-MDIX has been disabled with the <b>no mdix auto</b> command.

## Additional References for Auto-MDIX

### Related Documentation

Related Topic	Document Title
For complete syntax and usage information for the commands used in this chapter.	<i>Command Reference (Catalyst 9300 Series Switches)</i>
For information about the power supplies.	<i>Cisco Catalyst 9300 Series Switches Hardware Installation Guide</i>

## Feature History for Auto-MDIX

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Everest 16.5.1a	Auto-MDIX on an Interface	An automatic medium-dependent interface crossover (Auto-MDIX) enabled interface detects the required cable connection type (straight through or crossover) and configures the connection appropriately.

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to [Cisco Feature Navigator](#).



## CHAPTER 3

# Configuring Ethernet Management Port

The Ethernet management port functions as a Layer 3 host port dedicated to network management. It enables direct PC connections to the switch for management activities, offering an alternative to the console port. This module describes how to enable the Ethernet management port.

- [Prerequisites for Ethernet Management Port, on page 55](#)
- [Ethernet Management Port Overview, on page 55](#)
- [How to Configure the Ethernet Management Port, on page 58](#)
- [Example for Configuring IP Address on the Ethernet Management Port, on page 59](#)
- [Additional References for Ethernet Management Port, on page 60](#)
- [Feature History for Ethernet Management Port, on page 60](#)

## Prerequisites for Ethernet Management Port

Assign an IP address to the Ethernet management port, before connecting a PC to the port.

## Ethernet Management Port Overview

The Ethernet management port, known as the Gi0/0 or GigabitEthernet0/0 port, serves as a virtual routing and forwarding (VRF) interface to connect a PC. This port can be utilized for network management tasks as an alternative to the device console port.


When managing a device stack, connect the PC to the Ethernet management port on a stack member.

When managing a device stack, connect the PC to the Ethernet management port on a stack member.

## Connecting the Ethernet Management Directly to a Device

*Figure 2: Connecting a Device to a PC*

This figure displays the connection between the Ethernet management port and a PC for a device or a standalone device.




## Connecting the Ethernet Management Port to Stack Devices using a Hub

In a stack consisting only stack devices, all the Ethernet management ports on the stack members connect to a hub to which a PC is connected. The active link is from the Ethernet management port on the active device, through the hub, to the PC. If the active device fails and a new active device is elected, the active link is now from the Ethernet management port on the new active device, connecting to the PC.

**Figure 3: Connecting a Device Stack to a PC**

This figure illustrates how a PC connects to a device stack using a hub.



1	Switch stack	3	Hub
2	Management port	4	PC


## Ethernet Management Port and Routing

Typically, a device cannot route packets between the Ethernet management port and network ports. Network ports provide physical connections for devices such as computers, printers, and other network equipments, and these ports are available on switches, routers, and other networking devices.

Although the Ethernet management port does not inherently support routing, you may need to enable routing protocols on the port.

**Figure 4: Network Example with Routing Protocols Enabled**

Enable routing protocols on the Ethernet management port if the PC is multiple hops away from the device and packets must traverse multiple Layer 3 devices to reach the PC.



If the Ethernet management port and the network ports are associated with the same routing process

- routes from the Ethernet management port are propagated through the network ports to the network, and
- routes from the network ports are propagated through the Ethernet management port to the network.

However, since routing is not supported between the Ethernet management port and the network ports, traffic between these ports cannot be transmitted or received. This scenario can lead to data packet loops between the ports, which disrupt the device and network operation. To prevent such loops, configure route filters to block routes between the Ethernet management port and the network ports.

## Supported Features on the Ethernet Management Port

The Ethernet management port supports

- Cisco Discovery Protocol,
- express setup (only in device stacks),
- DHCP-based autoconfiguration,
- DHCP relay agent,
- interface features, such as,
  - speed: 10 Mb/s, 100 Mb/s, 1000 Mb/s, and autonegotiation,
  - duplex mode: full, half, and autonegotiation, and
  - loopback detection.
- IP ping,
- network assistant,
- Telnet with passwords,
- TFTP,
- Secure Shell (SSH), and
- SNMP (IF-MIB).



### Caution

Before enabling a feature on the Ethernet management port, verify if it is supported. Configuring an unsupported feature may result in improper functionality or device failure.

# How to Configure the Ethernet Management Port

This section outlines the procedures for configuring the Ethernet management port, including disabling and enabling the port.

## Disabling and Enabling the Ethernet Management Port

By default, the Ethernet management port is enabled.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. <ul style="list-style-type: none"><li>• Enter your password if prompted.</li></ul>
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>interface gigabitethernet0/0</b> <b>Example:</b> Device(config)# <b>interface gigabitethernet0/0</b>	Configures the Ethernet management port, and enters interface configuration mode.
<b>Step 4</b>	<b>shutdown</b> <b>Example:</b> Device(config-if)# <b>shutdown</b>	Disables the Ethernet management port.
<b>Step 5</b>	<b>no shutdown</b> <b>Example:</b> Device(config-if)# <b>no shutdown</b>	Enables the Ethernet management port.
<b>Step 6</b>	<b>end</b> <b>Example:</b> Device(config-if)# <b>end</b>	Exits interface configuration mode and returns to privileged EXEC mode.
<b>Step 7</b>	<b>show interfaces gigabitethernet0/0</b> <b>Example:</b> Device# <b>show interfaces gigabitethernet0/0</b>	Displays the link status.  To determine the link status to the PC, monitor the Ethernet management port LED. When the link is active, the LED will be green, and when the link is down, the LED will be off. An amber LED indicates a POST failure.

### What to do next

Proceed to manage or configure your device using the Ethernet management port.

## Example for Configuring IP Address on the Ethernet Management Port

This example shows how to configure an IP address on the GigabitEthernet0/0 management port.

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet0/0
Device(config-if)# vrf forwarding Mgmt-vrf
Device(config-if)# ip address 192.168.247.10 255.255.0.0
Device(config-if)# end
```

```
Device# show running-config interface gigabitethernet0/0
```

```
Building configuration...
```

```
Current configuration : 118 bytes
!
interface GigabitEthernet0/0
 vrf forwarding Mgmt-vrf
 ip address 192.168.247.10 255.255.0.0
 negotiation auto
end
```

This example shows how to configure an IP address on the TenGigabitEthernet0/1 management interface.

```
Device> enable
Device# configure terminal
Device(config)# interface TenGigabitEthernet0/1
Device(config-if)# vrf forwarding Mgmt-vrf
Device(config-if)# ip address 192.168.247.20 255.255.0.0
Device(config-if)# negotiation auto
Device(config-if)# end
```

```
Device# show running-config interface TenGigabitEthernet0/1
```

```
Building configuration...
```

```
Current configuration : 118 bytes
!
interface TenGigabitEthernet0/1
 vrf forwarding Mgmt-vrf
 ip address 192.168.247.20 255.255.0.0
 negotiation auto
end
```

## Additional References for Ethernet Management Port

### Related Documents

Related Topic	Document Title
<b>Bootloader configuration</b>	See the Performing Device Setup chapter of the <i>System Management Configuration Guide</i> .
<b>Bootloader commands</b>	See the <i>System Management Commands</i> section of the <i>Command Reference (Catalyst 9300 Series Switches)</i> .

## Feature History for Ethernet Management Port

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Everest 16.5.1a	Ethernet Management Port	The Ethernet management port is a VRF interface to which you can connect a PC. You can use the Ethernet management port instead of the device console port for network management.
Cisco IOS XE 17.17.1	LLDP Support on the Ethernet Management Port	During ZTP, automation tools use LLDP information from the management port is used to identify the device.  This feature was implemented on Cisco Catalyst 9300L Series Switches.

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to <https://cfnng.cisco.com/>.



## CHAPTER 4

# Checking Port Status and Connectivity

---

- [Check Cable Status Using Time Domain Reflectometer, on page 61](#)
- [Feature History for Checking Port Status and Connectivity, on page 62](#)

## Check Cable Status Using Time Domain Reflectometer

The Time Domain Reflectometer (TDR) feature allows you to determine if a cable is OPEN or SHORT when it is at fault.

With TDR, you can check the status of copper cables for the ports on the Catalyst 9300 Series Switches. TDR detects a cable fault by sending a signal through the cable and reading the signal that is reflected back. All or part of the signal can be reflected back due to defects in the cable.



---

**Note** Category 5 cable has four pairs. Each pair can assume one of these states: open (not connected), broken, shorted, or terminated. The TDR test detects all four states and displays the first three as “Fault” conditions, and displays the fourth as “Normal”.

TDR feature is supported on the following switches:

- Cisco Catalyst 9300 Series Switches
- Cisco Catalyst 9300L Series Switches
- Cisco Catalyst 9300X Series Switches

---

TDR detects a cable fault by sending a signal along its wires. Depending on the reflected signal, it can determine roughly where a cable fault could be. The variations on how TDR signal is reflected back determine the results on TDR. On Catalyst 9300 Series Switches, only these types of cable fault types are detected - OPEN, SHORT, and IMPEDANCE MISMATCH. Normal status is displayed in case the cable is properly terminated and this is done for illustrative purpose.

## Running the TDR Test

To start the TDR test, perform this task:

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	<b>test cable-diagnostics tdr</b> {interface { <i>interface-number</i> }}	Starts the TDR test.
<b>Step 2</b>	<b>show cable-diagnostics tdr</b> {interface <i>interface-number</i> }	Displays the TDR test counter information.

**TDR Guidelines**

The following guidelines apply to the use of TDR:

- Do not change the port configuration while the TDR test is running.
- If you connect a port undergoing a TDR test to an Auto-MDIX enabled port, the TDR result might be invalid.
- If you connect a port undergoing a TDR test to a 100BASE-T port such as that on the device, the unused pairs (4-5 and 7-8) are reported as faulty because the remote end does not terminate these pairs.
- Due to cable characteristics, you should run the TDR test multiple times to get accurate results.
- Do not change port status (for example, remove the cable at the near or far end) because the results might be inaccurate.
- TDR works best if the test cable is disconnected from the remote port. Otherwise, it might be difficult for you to interpret results correctly.
- TDR operates across four wires. Depending on the cable conditions, the status might show that one pair is OPEN or SHORT while all other wire pairs display as faulty. This operation is acceptable because you should declare a cable faulty provided one pair of wires is either OPEN or SHORT.
- TDR intent is to determine how poorly a cable is functioning rather than to locate a faulty cable.
- When TDR locates a faulty cable, you should still use an offline cable diagnosis tool to better diagnose the problem.
- TDR results might differ between runs on different switch models of Catalyst 9300 Series Switches because of the resolution difference of TDR implementations. When this occurs, you should refer to an offline cable diagnosis tool.

**Feature History for Checking Port Status and Connectivity**

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Gibraltar 16.11.1	Time Domain Reflectometer (TDR)	TDR allows you to determine if a cable is OPEN or SHORT when it is at fault.

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to [Cisco Feature Navigator](#).





## CHAPTER 5

# Configuring LLDP, LLDP-MED, and Wired Location Service

---

- [Restrictions for LLDP, on page 65](#)
- [Information About LLDP, LLDP-MED, and Wired Location Service, on page 65](#)
- [How to Configure LLDP, LLDP-MED, and Wired Location Service, on page 69](#)
- [Configuration Examples for LLDP, LLDP-MED, and Wired Location Service, on page 78](#)
- [Monitoring and Maintaining LLDP, LLDP-MED, and Wired Location Service, on page 78](#)
- [Additional References for LLDP, LLDP-MED, and Wired Location Service, on page 79](#)
- [Feature History for LLDP, LLDP-MED, and Wired Location Service, on page 79](#)

## Restrictions for LLDP

- If the interface is configured as a tunnel port, LLDP is automatically disabled.
- If you first configure a network-policy profile on an interface, you cannot apply the **switchport voice vlan** command on the interface. If the **switchport voice vlan *vlan-id*** is already configured on an interface, you can apply a network-policy profile on the interface. This way the interface has the voice or voice-signaling VLAN network-policy profile applied on the interface.
- You cannot configure static secure MAC addresses on an interface that has a network-policy profile.
- When Cisco Discovery Protocol and LLDP are both in use within the same switch, it is necessary to disable LLDP on interfaces where Cisco Discovery Protocol is in use for power negotiation. LLDP can be disabled at interface level with the commands **no lldp tlv-select power-management** or **no lldp transmit / no lldp receive**.

## Information About LLDP, LLDP-MED, and Wired Location Service

This section describes about LLDP, LLDP-MED, and wired location service.

### LLDP

The Cisco Discovery Protocol (CDP) is a device discovery protocol that runs over Layer 2 (the data link layer) on all Cisco-manufactured devices (routers, bridges, access servers, switches, and controllers). CDP allows

network management applications to automatically discover and learn about other Cisco devices connected to the network.

To support non-Cisco devices and to allow for interoperability between other devices, the device supports the IEEE 802.1AB Link Layer Discovery Protocol (LLDP). LLDP is a neighbor discovery protocol that is used for network devices to advertise information about themselves to other devices on the network. This protocol runs over the data-link layer, which allows two systems running different network layer protocols to learn about each other.

## LLDP Supported TLVs

LLDP supports a set of attributes that it uses to discover neighbor devices. These attributes contain type, length, and value descriptions and are referred to as TLVs. LLDP supported devices can use TLVs to receive and send information to their neighbors. This protocol can advertise details such as configuration information, device capabilities, and device identity.

The switch supports these basic management TLVs. These are mandatory LLDP TLVs.

- Port description TLV
- System name TLV
- System description TLV
- System capabilities TLV
- Management address TLV

These organizationally specific LLDP TLVs are also advertised to support LLDP-MED.

- Port VLAN ID TLV (IEEE 802.1 organizationally specific TLVs)
- MAC/PHY configuration/status TLV (IEEE 802.3 organizationally specific TLVs)

## LLDP-MED

LLDP for Media Endpoint Devices (LLDP-MED) is an extension to LLDP that operates between endpoint devices such as IP phones and network devices. It specifically provides support for voice over IP (VoIP) applications and provides additional TLVs for capabilities discovery, network policy, Power over Ethernet, inventory management and location information. By default, all LLDP-MED TLVs are enabled.

## LLDP-MED Supported TLVs

LLDP-MED supports these TLVs:

- LLDP-MED capabilities TLV

Allows LLDP-MED endpoints to determine the capabilities that the connected device supports and has enabled.

- Network policy TLV

Allows both network connectivity devices and endpoints to advertise VLAN configurations and associated Layer 2 and Layer 3 attributes for the specific application on that port. For example, the switch can notify a phone of the VLAN number that it should use. The phone can connect to any device, obtain its VLAN number, and then start communicating with the call control.

By defining a network-policy profile TLV, you can create a profile for voice and voice-signaling by specifying the values for VLAN, class of service (CoS), differentiated services code point (DSCP), and tagging mode. These profile attributes are then maintained centrally on the switch and propagated to the phone.

- Power management TLV

Enables advanced power management between LLDP-MED endpoint and network connectivity devices. Allows devices and phones to convey power information, such as how the device is powered, power priority, and how much power the device needs.

LLDP-MED also supports an extended power TLV to advertise fine-grained power requirements, end-point power priority, and end-point and network connectivity-device power status. LLDP is enabled and power is applied to a port, the power TLV determines the actual power requirement of the endpoint device so that the system power budget can be adjusted accordingly. The device processes the requests and either grants or denies power based on the current power budget. If the request is granted, the switch updates the power budget. If the request is denied, the device turns off power to the port, generates a syslog message, and updates the power budget. If LLDP-MED is disabled or if the endpoint does not support the LLDP-MED power TLV, the initial allocation value is used throughout the duration of the connection.

You can change power settings by entering the **power inline** {**auto** [**max** *max-wattage*] | **never** | **static** [**max** *max-wattage*] } interface configuration command. By default the PoE interface is in **auto** mode; If no value is specified, the maximum is allowed (30 W).

- Inventory management TLV

Allows an endpoint to send detailed inventory information about itself to the device, including information hardware revision, firmware version, software version, serial number, manufacturer name, model name, and asset ID TLV.

- Location TLV

Provides location information from the device to the endpoint device. The location TLV can send this information:

- Civic location information

Provides the civic address information and postal information. Examples of civic location information are street address, road name, and postal community name information.

- ELIN location information

Provides the location information of a caller. The location is determined by the Emergency location identifier number (ELIN), which is a phone number that routes an emergency call to the local public safety answering point (PSAP) and which the PSAP can use to call back the emergency caller.

- Geographic location information

Provides the geographical details of a switch location such as latitude, longitude, and altitude of a switch.

- custom location

Provides customized name and value of a switch location.

## Wired Location Service

The device uses the location service feature to send location and attachment tracking information for its connected devices to a Cisco Mobility Services Engine (MSE). The tracked device can be a wireless endpoint, a wired endpoint, or a wired device or controller. The device notifies the MSE of device link up and link down events through the Network Mobility Services Protocol (NMSP) location and attachment notifications.

The MSE starts the NMSP connection to the device, which opens a server port. When the MSE connects to the device there are a set of message exchanges to establish version compatibility and service exchange information followed by location information synchronization. After connection, the device periodically sends location and attachment notifications to the MSE. Any link up or link down events detected during an interval are aggregated and sent at the end of the interval.

When the device determines the presence or absence of a device on a link-up or link-down event, it obtains the client-specific information such as the MAC address, IP address, and username. If the client is LLDP-MED- or CDP-capable, the device obtains the serial number and UDI through the LLDP-MED location TLV or CDP.

Depending on the device capabilities, the device obtains this client information at link up:

- Slot and port specified in port connection
- MAC address specified in the client MAC address
- IP address specified in port connection
- 802.1X username if applicable
- Device category is specified as a *wired station*
- State is specified as *new*
- Serial number, UDI
- Model number
- Time in seconds since the device detected the association

Depending on the device capabilities, the device obtains this client information at link down:

- Slot and port that was disconnected
- MAC address
- IP address
- 802.1X username if applicable
- Device category is specified as a *wired station*
- State is specified as *delete*
- Serial number, UDI
- Time in seconds since the device detected the disassociation

When the device shuts down, it sends an attachment notification with the state *delete* and the IP address before closing the NMSP connection to the MSE. The MSE interprets this notification as disassociation for all the wired clients associated with the device.

If you change a location address on the device, the device sends an NMSP location notification message that identifies the affected ports and the changed address information.

## Default LLDP Configuration

Table 13: Default LLDP Configuration

Feature	Default Setting
LLDP global state	Disabled
LLDP holdtime (before discarding)	120 seconds
LLDP timer (packet update frequency)	30 seconds
LLDP reinitialization delay	2 seconds
LLDP tlv-select	Disabled to send and receive all TLVs
LLDP interface state	Disabled
LLDP receive	Disabled
LLDP transmit	Disabled
LLDP med-tlv-select	Disabled to send all LLDP-MED TLVs. When LLDP is glob LLDP-MED-TLV is also enabled.

## How to Configure LLDP, LLDP-MED, and Wired Location Service

This section provides the procedures to configure LLDP, LLDP-MED, and wired location service.

### Enabling LLDP

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>lldp run</b> <b>Example:</b>	Enables LLDP globally on the device.

	Command or Action	Purpose
	Device(config)# <b>lldp run</b>	
<b>Step 4</b>	<b>interface</b> <i>interface-id</i> <b>Example:</b> Device(config)# <b>interface</b> <b>gigabitethernet2/0/1</b>	Specifies the interface on which you are enabling LLDP, and enters interface configuration mode.
<b>Step 5</b>	<b>lldp transmit</b> <b>Example:</b> Device(config-if)# <b>lldp transmit</b>	Enables the interface to send LLDP packets.
<b>Step 6</b>	<b>lldp receive</b> <b>Example:</b> Device(config-if)# <b>lldp receive</b>	Enables the interface to receive LLDP packets.
<b>Step 7</b>	<b>end</b> <b>Example:</b> Device(config-if)# <b>end</b>	Exits interface configuration mode, and returns to privileged EXEC mode.
<b>Step 8</b>	<b>show lldp</b> <b>Example:</b> Device# <b>show lldp</b>	Verifies the configuration.
<b>Step 9</b>	<b>copy running-config startup-config</b> <b>Example:</b> Device# <b>copy running-config</b> <b>startup-config</b>	(Optional) Saves your entries in the configuration file.

## Configuring LLDP Characteristics

You can configure the frequency of LLDP updates, the amount of time to hold the information before discarding it, and the initialization delay time. You can also select the LLDP and LLDP-MED TLVs to send and receive.



**Note** Steps 3 through 6 are optional and can be performed in any order.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.

	Command or Action	Purpose
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>lldp holdtime seconds</b> <b>Example:</b> Device (config)# <b>lldp holdtime 120</b>	(Optional) Specifies the amount of time a receiving device should hold the information from your device before discarding it.  The range is 0 to 65535 seconds; the default is 120 seconds.
<b>Step 4</b>	<b>lldp reinit delay</b> <b>Example:</b> Device (config)# <b>lldp reinit 2</b>	(Optional) Specifies the delay time in seconds for LLDP to initialize on an interface.  The range is 2 to 5 seconds; the default is 2 seconds.
<b>Step 5</b>	<b>lldp timer rate</b> <b>Example:</b> Device (config)# <b>lldp timer 30</b>	(Optional) Sets the sending frequency of LLDP updates in seconds.  The range is 5 to 65534 seconds; the default is 30 seconds.
<b>Step 6</b>	<b>lldp tlv-select</b> <b>Example:</b> Device (config)# <b>tlv-select</b>	(Optional) Specifies the LLDP TLVs to send or receive.
<b>Step 7</b>	<b>interface interface-id</b> <b>Example:</b> Device (config)# <b>interface gigabitethernet2/0/1</b>	Specifies the interface on which you are enabling LLDP, and enters interface configuration mode.
<b>Step 8</b>	<b>lldp med-tlv-select</b> <b>Example:</b> Device (config-if)# <b>lldp med-tlv-select inventory management</b>	(Optional) Specifies the LLDP-MED TLVs to send or receive.
<b>Step 9</b>	<b>end</b> <b>Example:</b> Device (config-if)# <b>end</b>	Exits interface configuration mode, and returns to privileged EXEC mode.
<b>Step 10</b>	<b>show lldp</b> <b>Example:</b> Device# <b>show lldp</b>	Verifies the configuration.
<b>Step 11</b>	<b>copy running-config startup-config</b> <b>Example:</b> Device# <b>copy running-config startup-config</b>	(Optional) Saves your entries in the configuration file.

## Configuring LLDP-MED TLVs

By default, the device only sends LLDP packets until it receives LLDP-MED packets from the end device. It then sends LLDP packets with MED TLVs, as well. When the LLDP-MED entry has been aged out, it again only sends LLDP packets.

By using the **lldp** interface configuration command, you can configure the interface not to send the TLVs listed in the following table.

**Table 14: LLDP-MED TLVs**

LLDP-MED TLV	Description
inventory-management	LLDP-MED inventory management TLV
location	LLDP-MED location TLV
network-policy	LLDP-MED network policy TLV
power-management	LLDP-MED power management TLV

Follow these steps to enable a TLV on an interface:

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>interface <i>interface-id</i></b> <b>Example:</b> Device(config)# <b>interface</b> <b>gigabitethernet2/0/1</b>	Specifies the interface on which you are enabling LLDP, and enters interface configuration mode.
<b>Step 4</b>	<b>lldp med-tlv-select</b> <b>Example:</b> Device(config-if)# <b>lldp med-tlv-select</b> <b>inventory management</b>	Specifies the TLV to enable.
<b>Step 5</b>	<b>end</b> <b>Example:</b> Device(config-if)# <b>end</b>	Exits global configuration mode, and returns to privileged EXEC mode.

	Command or Action	Purpose
<b>Step 6</b>	<b>copy running-config startup-config</b> <b>Example:</b> Device# <code>copy running-config startup-config</code>	(Optional) Saves your entries in the configuration file.

## Configuring Network-Policy TLV

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <code>enable</code>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <code>configure terminal</code>	Enters global configuration mode.
<b>Step 3</b>	<b>network-policy profile</b> <i>profile number</i> <b>Example:</b> Device(config)# <code>network-policy profile 1</code>	Specifies the network-policy profile number, and enters network-policy configuration mode. The range is 1 to 4294967295.
<b>Step 4</b>	<b>{voice   voice-signaling} vlan</b> [ <i>vlan-id</i> { <i>cos cvalue</i>   <i>dscp dvalue</i> }]   [[ <i>dot1p</i> { <i>cos cvalue</i>   <i>dscp dvalue</i> }]   <i>none</i>   <i>untagged</i> ] <b>Example:</b> Device(config-network-policy)# <code>voice vlan 100 cos 4</code>	Configures the policy attributes: <ul style="list-style-type: none"> <li>• <b>voice</b>: Specifies the voice application type.</li> <li>• <b>voice-signaling</b>: Specifies the voice-signaling application type.</li> <li>• <b>vlan</b>: Specifies the native VLAN for voice traffic.</li> <li>• <i>vlan-id</i>: (Optional) Specifies the VLAN for voice traffic. The range is 1 to 4094.</li> <li>• <i>cos cvalue</i>: (Optional) Specifies the Layer 2 priority class of service (CoS) for the configured VLAN. The range is 0 to 7; the default is 5.</li> <li>• <i>dscp dvalue</i>: (Optional) Specifies the differentiated services code point (DSCP) value for the configured VLAN. The range is 0 to 63; the default is 46.</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• <b>dot1p:</b> (Optional) Configures the telephone to use IEEE 802.1p priority tagging and use VLAN 0 (the native VLAN).</li> <li>• <b>none:</b> (Optional) Do not instruct the IP telephone about the voice VLAN. The telephone uses the configuration from the telephone key pad.</li> <li>• <b>untagged:</b> (Optional) Configures the telephone to send untagged voice traffic. This is the default for the telephone.</li> </ul>
<b>Step 5</b>	<b>exit</b> <b>Example:</b> Device(config)# <b>exit</b>	Returns to global configuration mode.
<b>Step 6</b>	<b>interface <i>interface-id</i></b> <b>Example:</b> Device(config)# <b>interface</b> <b>gigabitethernet2/0/1</b>	Specifies the interface on which you are configuring a network-policy profile, and enters interface configuration mode.
<b>Step 7</b>	<b>network-policy <i>profile number</i></b> <b>Example:</b> Device(config-if)# <b>network-policy 1</b>	Specifies the network-policy profile number.
<b>Step 8</b>	<b>lldp med-tlv-select network-policy</b> <b>Example:</b> Device(config-if)# <b>lldp med-tlv-select</b> <b>network-policy</b>	Specifies the network-policy TLV.
<b>Step 9</b>	<b>end</b> <b>Example:</b> Device(config)# <b>end</b>	Returns to privileged EXEC mode.
<b>Step 10</b>	<b>show network-policy profile</b> <b>Example:</b> Device# <b>show network-policy profile</b>	Verifies the configuration.
<b>Step 11</b>	<b>copy running-config startup-config</b> <b>Example:</b> Device# <b>copy running-config</b> <b>startup-config</b>	(Optional) Saves your entries in the configuration file.

## Configuring Location TLV and Wired Location Service

Beginning in privileged EXEC mode, follow these steps to configure location information for an endpoint and to apply it to an interface.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 2</b>	<b>location</b> { <b>admin-tag</b> <i>string</i>   <b>civic-location identifier</b> { <i>id</i>   <b>host</b> }   <b>elin-location string identifier</b> <i>id</i>   <b>custom-location identifier</b> { <i>id</i>   <b>host</b> }   <b>geo-location identifier</b> { <i>id</i>   <b>host</b> }} <b>Example:</b> Device(config)# <b>location civic-location identifier 1</b>  Device(config-civic)# <b>number 3550</b> Device(config-civic)# <b>primary-road-name "Cisco Way"</b> Device(config-civic)# <b>city "San Jose"</b> Device(config-civic)# <b>state CA</b> Device(config-civic)# <b>building 19</b> Device(config-civic)# <b>room C6</b> Device(config-civic)# <b>county "Santa Clara"</b> Device(config-civic)# <b>country US</b>	Specifies the location information for an endpoint.  <ul style="list-style-type: none"> <li>• <b>admin-tag</b>: Specifies an administrative tag or site information.</li> <li>• <b>civic-location</b>: Specifies civic location information.</li> <li>• <b>elin-location</b>: Specifies emergency location information (ELIN).</li> <li>• <b>custom-location</b>: Specifies custom location information.</li> <li>• <b>geo-location</b>: Specifies geo-spatial location information.</li> <li>• <b>identifier id</b>: Specifies the ID for the civic, ELIN, custom, or geo location.</li> <li>• <b>host</b>: Specifies the host civic, custom, or geo location.</li> <li>• <b>string</b>: Specifies the site or location information in alphanumeric format.</li> </ul>
<b>Step 3</b>	<b>exit</b> <b>Example:</b> Device(config-civic)# <b>exit</b>	Returns to global configuration mode.
<b>Step 4</b>	<b>interface interface-id</b> <b>Example:</b> Device(config)# <b>interface gigabitethernet2/0/1</b>	Specifies the interface on which you are configuring the location information, and enters interface configuration mode.
<b>Step 5</b>	<b>location</b> { <b>additional-location-information word</b>   <b>civic-location-id</b> { <i>id</i>   <b>host</b> }	Enters location information for an interface:

	Command or Action	Purpose
	<p><b>elin-location-id</b> <i>id</i>   <b>custom-location-id</b> {<i>id</i>   <b>host</b>}   <b>geo-location-id</b> {<i>id</i>   <b>host</b>} }</p> <p><b>Example:</b></p> <pre>Device(config-if) # location elin-location-id 1</pre>	<ul style="list-style-type: none"> <li>• <b>additional-location-information:</b> Specifies additional information for a location or place.</li> <li>• <b>civic-location-id:</b> Specifies global civic location information for an interface.</li> <li>• <b>elin-location-id:</b> Specifies emergency location information for an interface.</li> <li>• <b>custom-location-id:</b> Specifies custom location information for an interface.</li> <li>• <b>geo-location-id:</b> Specifies geo-spatial location information for an interface.</li> <li>• <b>host:</b> Specifies the host location identifier.</li> <li>• <i>word:</i> Specifies a word or phrase with additional location information.</li> <li>• <i>id:</i> Specifies the ID for the civic, ELIN, custom, or geo location. The ID range is 1 to 4095.</li> </ul>
<b>Step 6</b>	<p><b>end</b></p> <p><b>Example:</b></p> <pre>Device(config-if) # end</pre>	Exits interface configuration mode, and returns to privileged EXEC mode.
<b>Step 7</b>	<p>Use one of the following:</p> <ul style="list-style-type: none"> <li>• <b>show location admin-tag</b> <i>string</i></li> <li>• <b>show location civic-location identifier</b> <i>id</i></li> <li>• <b>show location elin-location identifier</b> <i>id</i></li> </ul> <p><b>Example:</b></p> <pre>Device# show location admin-tag</pre> <p>OR</p> <pre>Device# show location civic-location identifier</pre> <p>OR</p> <pre>Device# show location elin-location identifier</pre>	Verifies the configuration.
<b>Step 8</b>	<p><b>copy running-config startup-config</b></p> <p><b>Example:</b></p> <pre>Device# copy running-config startup-config</pre>	(Optional) Saves your entries in the configuration file.

## Enabling Wired Location Service on the Device

### Before you begin

For wired location to function, you must first enter the **ip device tracking** global configuration command.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>nmosp notification interval {attachment   location} interval-seconds</b> <b>Example:</b> Device(config)# <b>nmosp notification interval location 10</b>	Specifies the NMSP notification interval. <b>attachment:</b> Specifies the attachment notification interval. <b>location:</b> Specifies the location notification interval. <i>interval-seconds:</i> Duration in seconds before the device sends the MSE the location or attachment updates. The range is 1 to 30; the default is 30.
<b>Step 4</b>	<b>end</b> <b>Example:</b> Device(config)# <b>end</b>	Exits global configuration mode, and returns to privileged EXEC mode.
<b>Step 5</b>	<b>show network-policy profile</b> <b>Example:</b> Device# <b>show network-policy profile</b>	Verifies the configuration.
<b>Step 6</b>	<b>copy running-config startup-config</b> <b>Example:</b> Device# <b>copy running-config startup-config</b>	(Optional) Saves your entries in the configuration file.

# Configuration Examples for LLDP, LLDP-MED, and Wired Location Service

This section provides configuration examples for LLDP, LLDP-MED, and wired location service.

## Examples: Configuring Network-Policy TLV

This example shows how to configure VLAN 100 for voice application with CoS and to enable the network-policy profile and network-policy TLV on an interface:

```
Device# configure terminal
Device(config)# network-policy 1
Device(config-network-policy)# voice vlan 100 cos 4
Device(config-network-policy)# exit
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# network-policy profile 1
Device(config-if)# lldp med-tlv-select network-policy
```

This example shows how to configure the voice application type for the native VLAN with priority tagging:

```
Device-config-network-policy)# voice vlan dot1p cos 4
Device-config-network-policy)# voice vlan dot1p dscp 34
```

## Monitoring and Maintaining LLDP, LLDP-MED, and Wired Location Service

Use the following commands for monitoring and maintaining LLDP, LLDP-MED, and wired location service.

Command	Description
<b>clear lldp counters</b>	Resets the traffic counters to zero.
<b>clear lldp table</b>	Deletes the LLDP neighbor information table.
<b>clear nmosp statistics</b>	Clears the NMSP statistic counters.
<b>show lldp</b>	Displays global information, such as frequency of transmissions, the holdtime for packets being sent, and the delay time before LLDP initializes on an interface.
<b>show lldp entry <i>entry-name</i></b>	Displays information about a specific neighbor.  You can enter an asterisk (*) to display all neighbors, or you can enter the neighbor name.

Command	Description
<b>show lldp interface</b> [ <i>interface-id</i> ]	Displays information about interfaces with LLDP enabled.  You can limit the display to a specific interface.
<b>show lldp neighbors</b> [ <i>interface-id</i> ] [ <b>detail</b> ]	Displays information about neighbors, including device type, interface type and number, holdtime settings, capabilities, and port ID.  You can limit the display to neighbors of a specific interface or expand the display for more detailed information.
<b>show lldp traffic</b>	Displays LLDP counters, including the number of packets sent and received, number of packets discarded, and number of unrecognized TLVs.
<b>show location admin-tag</b> <i>string</i>	Displays the location information for the specified administrative tag or site.
<b>show location civic-location identifier</b> <i>id</i>	Displays the location information for a specific global civic location.
<b>show location elin-location identifier</b> <i>id</i>	Displays the location information for an emergency location
<b>show network-policy profile</b>	Displays the configured network-policy profiles.
<b>show nmsp</b>	Displays the NMSP information

## Additional References for LLDP, LLDP-MED, and Wired Location Service

### Related Documents

Related Topic	Document Title
For complete syntax and usage information for the commands used in this chapter.	See the <i>Interface and Hardware Commands</i> section in the <i>Command Reference (Catalyst 9300 Series Switches)</i>

## Feature History for LLDP, LLDP-MED, and Wired Location Service

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Everest 16.5.1a	Link Layer Discovery Protocol (LLDP), LLDP-MED, Wired Location Service	<p>LLDP is a neighbor discovery protocol that is used for network devices to advertise information about themselves to other devices on the network. This protocol runs over the data-link layer, which allows two systems running different network layer protocols to learn about each other.</p> <p>LLDP-MED operates between endpoints and network devices.</p> <p>Wired Location Service lets you send tracking information of the connected devices to a Cisco Mobility Services Engine (MSE).</p>

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to <https://cfng.cisco.com/>.



## CHAPTER 6

# Configuring System MTU

- [Information About the MTU, on page 81](#)
- [How to Configure MTU , on page 82](#)
- [Configuration Examples for System MTU, on page 83](#)
- [Additional References for System MTU, on page 84](#)
- [Feature History for System MTU, on page 84](#)

## Information About the MTU

The default maximum transmission unit (MTU) size for payload received in Ethernet frame and sent on all device interfaces is 1500 bytes. The maximum value of System MTU is 9198 bytes.

## System MTU Value Application

This table shows how the MTU values are applied.

**Table 15: MTU Values**

Configuration	system mtu command	ip mtu command	ipv6 mtu command
Standalone switch or switch stack	You can enter the <b>system mtu</b> command on a switch or switch stack. It affects all ports.  The range is from 1500 to 9198 bytes.	Use the <b>ip mtu bytes</b> command.  The range is from 832 up to 1500 bytes.  <b>Note</b> The IP MTU value is the applied value, not the configured value.	Use the <b>ipv6 mtu bytes</b> command.  The range is from 1280 to the system jumbo MTU value (in bytes).  <b>Note</b> The IPv6 MTU value is the applied value, not the configured value.

The upper limit of the IP or IPv6 MTU value is based on the switch or switch stack configuration and refers to the currently applied system MTU value. For more information about setting the MTU sizes, see the **system mtu** global configuration command in the command reference for this release.

Beginning from Cisco IOS XE Amsterdam 17.3.x, the minimum IPv6 system MTU is fixed at 1280 as per RFC 8200.

# How to Configure MTU

The following tasks describe how you can configure MTU.

## Configuring the System MTU

Follow these steps to change the MTU size for switched packets:

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>system mtu bytes</b> <b>Example:</b> Device(config)# <b>system mtu 1900</b>	(Optional) Changes the MTU size for all Gigabit Ethernet and 10-Gigabit Ethernet interfaces.
<b>Step 4</b>	<b>end</b> <b>Example:</b> Device(config)# <b>end</b>	Enters global configuration mode, and returns to privileged EXEC mode.
<b>Step 5</b>	<b>copy running-config startup-config</b> <b>Example:</b> Device# <b>copy running-config startup-config</b>	Saves your entries in the configuration file.
<b>Step 6</b>	<b>show system mtu</b> <b>Example:</b> Device# <b>show system mtu</b>	Verifies your settings.

## Configuring Protocol-Specific MTU

To override system MTU values on routed interfaces, configure protocol-specific MTU under each routed interface. To change the MTU size for routed ports, perform this procedure.

## Procedure

	Command or Action	Purpose
Step 1	<b>configure terminal</b> <b>Example:</b> Device# <code>configure terminal</code>	Enters global configuration mode.
Step 2	<b>interface <i>interface</i></b> <b>Example:</b> Device(config)# <code>interface gigabitethernet0/0</code>	Enters interface configuration mode.
Step 3	<b>ip mtu <i>bytes</i></b> <b>Example:</b> Device(config-if)# <code>ip mtu 68</code>	Changes the IPv4 MTU size
Step 4	<b>ipv6 mtu <i>bytes</i></b> <b>Example:</b> Device(config-if)# <code>ipv6 mtu 1280</code>	(Optional) Changes the IPv6 MTU size.
Step 5	<b>end</b> <b>Example:</b> Device(config-if)# <code>end</code>	Exits interface configuration mode, and returns to privileged EXEC mode.
Step 6	<b>copy running-config startup-config</b> <b>Example:</b> Device# <code>copy running-config startup-config</code>	Saves your entries in the configuration file.
Step 7	<b>show system mtu</b> <b>Example:</b> Device# <code>show system mtu</code>	Verifies your settings.

## Configuration Examples for System MTU

### Example: Configuring Protocol-Specific MTU

This example shows how you can configure protocol-specific MTU:

```
Device# configure terminal
Device(config)# interface gigabitethernet 0/1
Device(config-if)# ip mtu 900
```

```
Device(config-if)# ipv6 mtu 1286
Device(config-if)# end
```

## Example: Configuring the System MTU

This example shows how you can configure the system MTU:

```
Device# configure terminal
Device(config)# system mtu 1600
Device(config)# exit
```

## Additional References for System MTU

### Related Documents

Related Topic	Document Title
For complete syntax and usage information for the commands used in this chapter.	See the <i>Interface and Hardware Commands</i> section in the <i>Command Reference (Catalyst 9300 Series Switches)</i>

### Standards and RFCs

Standard/RFC	Title
<a href="#">RFC 8200</a>	<i>Internet Protocol, Version 6 (IPv6) Specification</i>

## Feature History for System MTU

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Everest 16.5.1a	System MTU	System MTU defines the maximum transmission unit size for frames transmitted on all interfaces of a switch.

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to <https://cfnnng.cisco.com/>.



## CHAPTER

# 7

## Configuring Per-Port MTU

---

- [Restrictions for Per-Port MTU, on page 85](#)
- [Information About Per-Port MTU, on page 85](#)
- [Configuring Per-Port MTU, on page 86](#)
- [Example: Configuring Per-Port MTU, on page 86](#)
- [Example: Verifying Per-Port MTU, on page 87](#)
- [Example: Disabling Per-Port MTU, on page 87](#)
- [Feature History for Per-Port MTU, on page 87](#)

### Restrictions for Per-Port MTU

- Per-Port MTU cannot be configured on the management port.
- Per-Port MTU cannot be configured on SVL links.
- Members of a port channel cannot be configured with Per-Port MTU, they derive their MTU from the port-channel MTU configuration.
- Per-Port MTU is not supported on subinterfaces and port-channel subinterfaces.

### Information About Per-Port MTU

You can configure the MTU size for all interfaces on a device at the same time using the **system mtu** command. The default maximum transmission unit (MTU) size for frames received and transmitted on all interfaces is 1500 bytes. The **system mtu** command is a global command and does not allow MTU to be configured at a port level. Starting with Cisco IOS XE 17.1.1, you can configure Per-Port MTU. Per-Port MTU will support port level and port channel level MTU configuration. With Per-Port MTU you can set different MTU values for different interfaces as well as different port channel interfaces.

Once the Per-Port MTU value has been configured on a port, the protocol-specific MTU for that port is also changed to the Per-Port MTU value. When Per-Port MTU is configured on a port, you can still configure protocol-specific MTU on the interface in the range from 256 to Per-Port MTU value.

If the Per-Port MTU is disabled, the MTU for the port will revert to the system MTU value.

You can view the Per-Port MTU configurations on an interface using the **show interface mtu** command.

The following are expected behaviour if the Per-Port MTU configuration is changed on any interface:

- The interface flaps if the port-channel is in PAgP or LACP mode.
- The interface does not flap if the port channel is in the **on** mode.
- The interface does not flap if the interface is not a port channel.

You can disable Per-Port MTU by using the **no** form of the **mtubytes** command in the interface configuration mode.

## Configuring Per-Port MTU

Follow these steps to change the MTU size for switched packets on a particular port of an interface:

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>interface</b> <i>typeswitch-number/slot-number/port-number</i> <b>Example:</b> Device(config)# <b>int</b> <b>FortyGigabitEthernet2/5/0/20</b>	Configures the interface and enters interface configuration mode.
<b>Step 4</b>	<b>mtubytes</b> <b>Example:</b> Device(config-if)# <b>mtu 6666</b>	Configures the MTU size for a particular port on the interface.
<b>Step 5</b>	<b>end</b> <b>Example:</b> Device(config-if)# <b>end</b>	Exits interface configuration mode, and returns to privileged EXEC mode.

## Example: Configuring Per-Port MTU

This example shows how to configure Per-Port MTU on an interface:

```
Device# configure terminal
Device(config)# interface FortyGigabitEthernet2/5/0/20
Device(config-if)# mtu 6666
Device(config-if)# end
```

## Example: Verifying Per-Port MTU

This example shows how to verify Per-Port MTU on an interface using the **show interface mtu** command:

```
Device# show interface mtu

Port          Name          MTU
Fo2/5/0/19   Name          1500
Fo2/5/0/20   Name          6666
Fo2/5/0/21   ixia_7_21    1500
```

## Example: Disabling Per-Port MTU

This example shows how to disable Per-Port MTU on an interface:

```
Device# configure terminal
Device(config)# interface FortyGigabitEthernet2/5/0/20
Device(config-if)# no mtu
Device(config-if)# end
```

## Feature History for Per-Port MTU

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Amsterdam 17.1.1	Per-Port MTU	Per-Port MTU defines the maximum transmission unit size for frames received and transmitted on a particular port or port channel.

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to <https://cfngn.cisco.com/>.





## CHAPTER 8

# Configuring Internal Power Supplies

- [Information About Internal Power Supplies, on page 89](#)
- [How to Configure Internal Power Supplies, on page 89](#)
- [Monitoring Internal Power Supplies, on page 90](#)
- [View Power Consumption, on page 90](#)
- [Configuration Examples for Internal Power Supplies, on page 91](#)
- [Additional References for Internal Power Supplies, on page 92](#)
- [Feature History for Internal Power Supplies, on page 92](#)

## Information About Internal Power Supplies

See the device installation guide for information about the power supplies.

## How to Configure Internal Power Supplies

This section list the procedures to configure internal power supplies.

### Configuring Internal Power Supply

You can use the **power supply** EXEC command to configure and manage the internal power supply on the device. The device does not support the **no power supply** EXEC command.

Follow these steps beginning in user EXEC mode:

#### Procedure

	Command or Action	Purpose
Step 1	<b>power supply</b> <i>switch_number</i> <b>slot</b> {A   B} { <b>off</b>   <b>on</b> }  <b>Example:</b> Device# <b>power supply 1 slot A on</b>	Sets the specified power supply to <b>off</b> or <b>on</b> by using one of these keywords: <ul style="list-style-type: none"><li>• <b>A</b>: Selects the power supply in slot A.</li><li>• <b>B</b>: Selects power supply in slot B.</li></ul> <b>Note</b>

	Command or Action	Purpose
		Power supply slot B is the closest to the outer edge of the device. <ul style="list-style-type: none"> <li>• <b>off</b>: Sets the power supply off.</li> <li>• <b>on</b>: Sets the power supply on.</li> </ul> By default, the device power supply is <b>on</b> .
<b>Step 2</b>	<b>show environment power</b>  <b>Example:</b> Device# <code>show environment power</code>	Verifies your settings.

## Monitoring Internal Power Supplies

Table 16: Show Commands for Power Supplies

Command	Purpose
<b>show environment power</b> [ <b>all</b>   <b>switch</b> <i>switch_number</i> ]	(Optional) Displays the status of the internal power supplies for each device in the stack or for the specified device. The range is , depending on the device member numbers in the stack.  The device keywords are available only on stacking-capable devices.

## View Power Consumption

The device uses the supplied power for powering the system resources and also for Power over Ethernet (PoE). Before allocating the PoE power, the operating system allocates a specific amount of power to the system resources such as the power controllers, LEDs, chips, FPGAs, and so on. This is called budgeted power. Budgeted power shows the maximum power that is reserved for the system usage. You can check the actual power consumption and the budgeted power using the **show power detail** and **show power module** commands. These **show** commands also display the **Instantaneous Power**, **Reset Power**, **Peak Power**, **System Energy** and **System Meter Update Time**.

**Instantaneous Power** is the power that is utilized at any given time. **Peak Power** is the maximum power that is consumed by the system at the time it is powered up. **Reset Power** indicates the amount of power the system is allocated in the reset mode. **System Energy** is the power consumed by the system for a specific duration of time.

Here is a sample output of the **show power module** command:

```
Device# show power module

Automatic Module Shutdown : Enabled
Power Budget Mode = SP-PS

Mod  Model No          shutdown Power          Out of In
          Priority State      Budget Instantaneous Peak Reset  Reset
```

```

-----
1   C9300-48UXM           4           accepted  575     108           108     575     50
-----
Total 575

```

Here is a sample output of the **show power detail** command:

Device# **show power detail**

```

SW  PID                Serial#      Status      Sys Pwr  PoE Pwr  Watts
--  ---                -
1A  PWR-C1-1100WAC-P    DCC2505DH9Y OK          Good     Good     1100
1B  PWR-C1-1100WAC-P    ART2236FELZ OK          Good     Good     1100
2A  PWR-C1-1100WAC      DTN2203V17R OK          Good     Good     1100
2B  PWR-C1-1100WAC-P    DCC2505D6PJ OK          Good     Good     1100
3A  PWR-C1-1100WAC      LIT211227N2 OK          Good     Good     1100
3B  PWR-C1-350WAC       LIT18300WV1 Disabled    Bad      Bad      350

```

```

PS Configuration Mode : StackPower
PS Operating state    : StackPower

```

```

Power supplies currently active   : 5
Power supplies currently available : 6

```

Automatic Module Shutdown : Enabled

```

Mod  Model No          Priority  State      Budget  Instantaneous  Peak  Reset  Reset
--  -
1    C9300-48UXM        4        accepted  575     105            105  575   50
2    C9300X-24HX       4        accepted  365     129            129  365   50
3    C9300-24P         4        accepted  235     81             81   235   50
-----
Total                               1175    315

```

```

Power Summary
(in Watts)  Allocated  Consumed  Maximum
-----
System Power  1175      315      1670
POE Power     274       85       4180
-----
Total         1449     400     5850

```

```

Meter start time 2024-06-25 16:35:24 UTC
Energy Data For Last 180 Minute

```

```

Mod  Model No          System Energy  System Meter Update
-----
1    C9300-48UXM      1100738625   2024-06-25 20:41:50 UTC
2    C9300X-24HX     1338605237   2024-06-25 20:41:50 UTC
3    C9300-24P       862059874    2024-06-25 20:41:50 UTC

```

## Configuration Examples for Internal Power Supplies

This example shows how to set the power supply in slot A to off:

```

Device# power supply 1 slot A off
Disabling Power supply A may result in a power loss to PoE devices and/or switches ...
Continue? (yes/[no]): yes

```

```
Device#
Jun 10 04:52:54.389: %PLATFORM_ENV-6-FRU_PS_OIR: FRU Power Supply 1 powered off
Jun 10 04:52:56.717: %PLATFORM_ENV-1-FAN_NOT_PRESENT: Fan is not present
Device#
```

This example shows how to set the power supply in slot A to on:

```
Device# power supply 1 slot A on
Jun 10 04:54:39.600: %PLATFORM_ENV-6-FRU_PS_OIR: FRU Power Supply 1 powered on
```

This example shows the output of the **show env power** command:

**Table 17: show env power Status Descriptions**

Field	Description
OK	The power supply is present and power is good.
Not Present	No power supply is installed.
No Input Power	The power supply is present but there is no input power.
Disabled	The power supply and input power are present, but power supply is switched off by CLI.
Not Responding	The power supply is not recognizable or is faulty.
Failure-Fan	The power supply fan is faulty.

## Additional References for Internal Power Supplies

### Related Documentation

Related Topic	Document Title
For complete syntax and usage information for the commands used in this chapter.	<i>Command Reference (Catalyst 9300 Series Switches)</i>
For information about the power supplies.	<i>Cisco Catalyst 9300 Series Switches Hardware Installation Guide</i>

## Feature History for Internal Power Supplies

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Everest 16.5.1a	Internal Power Supplies	The switch operates with power supply modules which could be AC, DC or both. Refer the <i>Hardware Installation Guide</i> for more details on power supply units.
Cisco IOS XE Cupertino 17.8.1	Reporting System Power	<b>show power detail</b> and <b>show power module</b> commands were introduced to display the details of the system power usage.

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to <https://cfng.cisco.com/>.





## CHAPTER 9

# Configuring the Cisco Expandable Power System 2200

---

This module contains the following sections:

- [Restrictions for Configuring the Expandable Power System 2200, on page 95](#)
- [Information About Cisco Expandable Power System 2200, on page 95](#)
- [How to Configure the Cisco Expandable Power System 2200, on page 99](#)
- [Monitoring and Maintaining the Cisco Expandable Power System 2200, on page 102](#)
- [Additional References for Cisco Expandable Power System 2200, on page 102](#)
- [Feature History for Cisco Expandable Power System 2200, on page 103](#)

## Restrictions for Configuring the Expandable Power System 2200

- When using the Expandable Power System (XPS) power supplies in the RPS mode for backing up switch power supplies, the smallest power supply in the XPS must be greater than the largest power supply in a switch connected to an XPS port in RPS mode.
- In RPS mode, each XPS power supply can back up only one switch power supply, regardless of the size.
- If you remove a power supply from the power stack (from a switch or the XPS), be sure that removing it does not deplete available power enough to cause load shedding.
- Cisco Catalyst 9300L Series Switches do not support Stack Power and XPS 2200.
- Cisco Catalyst 9300X Series Switches do not support XPS 2200.

## Information About Cisco Expandable Power System 2200

The following sections provide an overview of XPS 2200 and its Power Supply Modes.

### Cisco eXpandable Power System (XPS) 2200 Overview

The Cisco eXpandable Power System (XPS) 2200 is a standalone power system that you can connect to Catalyst switches. The XPS 2200 can provide backup power to connected devices that experience a power supply failure or, in a Catalyst switch power stack, it can supply additional power to the power stack budget.

The XPS 2200 power ports and internal power supplies can operate in redundant power supply (RPS) mode or stack power (SP) mode.

Stack-power mode is used only on stacking-capable switches in a power stack. With no XPS, a power stack operates in ring topology with a maximum of four switches in the stack. If you merge two stacks, the total number of switches cannot exceed four. When an XPS is in the power stack, you can connect up to nine switches in the stack plus the XPS, providing power budgets to power stack members similar to stack-power ring topology operation.

All Catalyst switches connected to an XPS on SP ports are part of the same power stack, and all power from the XPS and the switch is shared across all switches in the stack. Power sharing is the default mode, but the XPS supports the same stack power modes that are supported in a ring topology (strict and nonstrict power-sharing or redundant modes).

When two power supplies are present, the system can operate in mixed mode, where one power supply operates in RPS mode and the other in SP mode. You can configure the ports and power supplies for the way that you plan to use the XPS 2200.

The XPS 2200 has nine power ports that can operate in an RPS role or in an automatic stack power (Auto-SP) role (the default), where mode of operation is determined by the type of switch connected to the port. You can also use the CLI to force the mode to be RPS for stackable switches.

- When a Catalyst (stackable) switch running the Network Essentials or Network Advantage license is connected to the port, the mode is SP, which enables the switch to be part of the stack power system.

You configure the XPS through any switch connected to a power port. You can use any XPS port for configuration, and you can configure any port from any switch connected to the XPS. If you enter XPS configuration commands on more than one switch, the last configuration applied takes effect.

Although all XPS configuration is done through a switch, the XPS 2200 also runs its own software. You can upgrade this software through the XPS Service Port.

## XPS 2200 Power Supply Modes

The XPS has two power supplies that can also be in either RPS or SP mode.

In SP mode, all SP ports on the XPS belong to the same power stack. When a power stack includes an XPS, the stack topology is a star topology and consists of up to nine member switches plus the XPS 2200. The XPS power supply or power supplies that are in SP mode are considered in the power budgeting. If both XPS power supplies are in RPS mode, the power stack consists only of the switches connected to XPS ports in SP mode, and the power budget is determined by the power supplies in these switches.

If there is a power supply role mismatch, for example, if an XPS port is configured for RPS and both power supplies are in SP mode, the XPS detects the mismatch, and an error message is sent.

### RPS Mode

When both XPS power supplies are in RPS mode, the XPS can back up two power supply failures for switch power supplies of equal value or less. The smallest power supply in the XPS must be greater than the largest power supply in a switch connected to an XPS port in RPS mode.

If only one supply is in RPS mode, the XPS can back up only one power supply, even when the failed power supply is much smaller. For example, if an XPS 1100 W power supply is in RPS mode and two 350 W switch power supplies fail, the XPS can back up only one of the switch power supplies.

When one XPS power supply in RPS mode is backing up a switch power supply and another switch power supply fails, a message appears that the XPS backup is not available. When the failed power supply comes up, the XPS becomes available to back up other power supplies.

If the XPS is backing up two failed power supplies in a single switch (both XPS power supplies in RPS mode), the XPS is not available to back up other switch power supplies until both of the failed supplies are repaired or replaced.

In mixed mode, with one power supply in RPS mode and one in SP mode, if two power supplies in a single switch fail, because the XPS can back up only one of them, it denies power to both power supplies, and the switch shuts down. This occurs only in mixed power mode.

If a switch is connected to a port configured as RPS, but neither of the power supplies is RPS, the RPS port configuration is rejected and the XPS attempts to add the switch to a power stack. If the switch is not capable of operating in SP mode (is not a stackable switch), the port is disabled.

Ports in RPS mode have a configurable priority. The default priority is based on the XPS port number, with port 1 as the highest priority port. A higher priority port has a higher precedence for backup than a lower priority port. If a switch connected to a higher priority port has a power supply failure while a switch connected to a low priority port is being backed up, the XPS drops power to the low priority port to supply power to the high priority port.

## Stack Power Mode

Stack-power mode is used only on Catalyst switches in a power stack. With no XPS, a power stack operates in ring topology with a maximum of four switches in the stack. When an XPS is in the power stack, you can connect up to nine switches in the stack plus the XPS, providing power budgets to power stack members similar to stack-power ring topology operation.

All Catalyst switches connected to an XPS on SP ports are part of the same power stack, and all power from the XPS and the switches is shared across all switches in the stack. Power sharing is the default mode, but the XPS supports the same stack power modes that are supported in a ring topology (strict and nonstrict power-sharing or redundant modes).

The XPS uses neighbor discovery to create the power stack. When it discovers a Catalyst switch on an unconfigured port, it marks the port as an SP port, and the switch joins the power stack. The XPS notifies the switch, begins the power-budgeting process, and assigns budgets to each switch in the power stack based on their requirements, priorities, current power allocations, and the stack aggregate power capability.

The XPS sends the power budget to each switch. If not enough input power is available to provide every switch with its maximum requested power, power is distributed based on priority. Switches with the highest priority receive required power first, followed by any powered devices that have already been allocated power, in order of their priority. Any remaining power is distributed equally through the stack.

The RPS port priority (1 through 9) does not affect stack power priority. Each switch participating in stack power has its own system priority and a high and low priority for devices connected to its ports. These priorities are used for stack power, as is the case in a ring topology. You configure stack power priority for the system and for high and low-priority ports by using the **power-priority switch**, **power-priority high**, and **power-priority low** commands in switch stack power configuration mode. If a system or set of powered devices are using the default priority, the XPS automatically assigns a priority (1 through 27), with lower MAC addresses receiving higher priorities.

There are four power stack modes: power sharing, strict power sharing, redundant, or strict redundant. You configure the power stack mode by using the **mode {power-sharing | redundant} [strict]** command in power-stack configuration mode. The **power-sharing** or **redundant** configurations affect the power budgeting

aspect of the stack; **strict** or non-strict affects the actions of the PoE application when a budget reduction does not result in load shedding.

- In power sharing modes (strict or nonstrict), the stack power budget is the cumulative capacity of all the power supplies in the stack (minus 30 W reserved power). This is the default.
- In redundant modes (strict or nonstrict), the stack power budget is the total available power (minus 30 W) after the capacity of the largest power supply in the power stack is subtracted. Redundant mode guarantees that no switch or powered device loses power or experiences load sheds if a single power supply fails, but load sheds can occur if more than one power supply fails.
- In strict modes, if a loss of input power results in reduced power budgets but does not result in any hardware load shedding, the XPS automatically begins denying power to low-priority powered devices and then the high-priority powered devices until the amount of allocated power is less than or equal to the amount of available PoE power.
- In nonstrict modes, in the event of a power reduction, the amount of allocated power is allowed to fall under budget.

For example, a system with a total PoE budget (available power) of 400 W can allocate 390 W of the budget (allocated power) to powered devices. The allocated power of a device is the maximum amount of power that the device needs. The actual power consumption (consumed power) for a set of powered devices is usually not equal to the allocated power. In this example, the actual power might be approximately 200 W. If a power loss in the stack reduces the available power to 210 W, this amount is enough to sustain the power being consumed by the powered devices, but less than the worst-case allocated power, which would put the system *under budget*. In strict mode, the stack would immediately deny power to powered devices until the allocated power was 210 W or less. In nonstrict mode, no action is taken, and the state is allowed to persist. In nonstrict mode if the actual power consumption becomes more than 210 W, this triggers a load shed and can result in the loss of power to all powered devices or switches with the lowest priority level.

## Mixed Modes

The XPS 2200 can also operate in mixed mode, where some ports connected to switches are RPS and others are SP. At least one power supply must be an RPS power supply in this configuration. The power supply in the XPS can back up only one switch power supply and the XPS supply must be greater than the largest power supply in a switch connected to an XPS port in RPS mode.

Switches connected to SP ports belong to a single power stack. If the SP switches have a large enough power budget, an SP power supply is not required on the XPS. When an XPS power supply is configured, its power is added to the power pool shared by the power stack.

## XPS 2200 System Defaults

The default role for a port is Auto-SP, where the power mode is determined by the switch connected to the port (SP for Catalyst switches with the Network Essentials or Network Advantage license)

The default for the XPS power supply A (PS1) is RPS mode. The default for power supply B (PS2) is SP mode.

The default mode for all ports and power supplies is enabled.

On ports configured for RPS, the default priority is the same as the port number.

# How to Configure the Cisco Expandable Power System 2200

You can configure the XPS from any switch connected to an XPS port. If you enter XPS configuration commands on more than one switch, the last configuration applied takes effect. Only the switch and port name are saved in the switch configuration file.

## Configuring System Names

### Procedure

	Command or Action	Purpose
Step 1	<code>enable</code>	Enables privileged EXEC mode. Enter your password, if prompted.
Step 2	<code>configure terminal</code>	Enters global configuration mode.
Step 3	<code>power xps switch-number name {name   serialnumber}</code>	<p><b>Note</b> In a stacked system, the switch-number entered must be the switch number of the active switch.</p> <p>Configures a name for the XPS 2200 system.</p> <ul style="list-style-type: none"> <li>• <b>name</b>: Enter a name for the XPS 2200 system. The name can have up to 20 characters.</li> <li>• <b>serialnumber</b>: Use the serial number of the XPS 2200 as the system name.</li> </ul>
Step 4	<code>power xps switch-number port {name   hostname   serialnumber}</code>	<p><b>Note</b> The <i>switch-number</i> appears only on Catalyst switches and represents the device number in the data stack,</p> <p>Configures a name for an XPS 2200 port connected to the device.</p> <ul style="list-style-type: none"> <li>• <b>name</b>: Enter a name for the XPS 2200 port.</li> <li>• <b>serialnumber</b>: Use the serial number of the device connected to the port.</li> <li>• <b>hostname</b>: Use the hostname of the device connected to the port.</li> </ul>
Step 5	<code>end</code>	Returns to privileged EXEC mode.
Step 6	<code>show env xps system</code>	Verifies the configured name of the system and ports.

	Command or Action	Purpose
Step 7	copy running-config startup-config	(Optional) Saves your entries in the configuration file.

## Configuring XPS Ports

### Procedure

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode. Enter your password, if prompted.
Step 2	power xps <i>switch-number</i> port { <i>number</i>   connected} mode {disable   enable}	<p><b>Note</b> The <i>switch-number</i> appears only on Catalyst switches and represents the switch number in the data stack, a value from 1 to 9.</p> <p>Sets the port to be enabled or disabled.</p> <ul style="list-style-type: none"> <li>• <i>number</i>: Enter the XPS 2200 port number. The range is 1 to 9.</li> <li>• <b>connected</b>: Enter this keyword if you do not know the port number to which the switch is connected.</li> <li>• <b>mode disable</b>: Disable (shut down) the XPS port.</li> </ul> <p><b>Note</b> Disabling an XPS port is like removing the cable and appears the same in the <b>show</b> command outputs. If the physical cable is connected, you can still use the <b>enable</b> keyword to enable the port.</p> <ul style="list-style-type: none"> <li>• <b>mode enable</b>: Enable the XPS port. This is the default.</li> </ul>
Step 3	power xps <i>switch-number</i> port { <i>number</i>   connected} role {auto   rps}	<p><b>Note</b> The <i>switch-number</i> represents the switch number in the data stack, a value from 1 to 9.</p> <p>Sets the role of the XPS port.</p> <ul style="list-style-type: none"> <li>• <b>role auto</b>: The port mode is determined by the switch connected to the port. This is the default.</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• <b>role RPS</b>: The XPS acts as a back up if the switch power supply fails. At least one RPS power supply must be in RPS mode for this configuration.</li> </ul>
<b>Step 4</b>	<b>power xps</b> <i>switch-number</i> <b>port</b> { <i>number</i>   <b>connected</b> } <b>priority</b> <i>port-priority</i>	<p><b>Note</b> The <i>switch-number</i> represents the switch number in the data stack, a value from 1 to 9.</p> <p>Sets the RPS priority of the port, where higher priority ports take precedence over low priority ports if multiple power supplies fail. This command takes effect only when the port mode is RPS. When the port mode is stack power, you set priority by using the stack power commands.</p> <ul style="list-style-type: none"> <li>• <b>priority</b> <i>port-priority</i>: Set the RPS priority of the port. The range is 1 to 9, with 1 being the highest priority. The default priority is the XPS port number.</li> </ul>
<b>Step 5</b>	<b>show env xps port</b>	Verifies the XPS configuration of the port.
<b>Step 6</b>	<b>copy running-config startup-config</b>	(Optional) Saves your entries in the configuration file.

## Configuring XPS Power Supplies

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>power xps</b> <i>switch-number</i> <b>supply</b> { <b>A</b>   <b>B</b> } <b>mode</b> { <b>rps</b>   <b>sp</b> }	<p><b>Note</b> The <i>switch-number</i> represents the switch number in the data stack, a value from 1 to 9.</p> <p>Sets the XPS power supply mode.</p> <ul style="list-style-type: none"> <li>• <b>supply</b> {<b>A</b>   <b>B</b>}: Select the power supply to configure. Power supply A is on the left (labeled PS1) and power supply B (PS2) is on the right.</li> <li>• <b>mode rps</b>: Set the power supply mode to RPS, to back up connected switches. This</li> </ul>

	Command or Action	Purpose
		<p>is the default setting for power supply A (PS1).</p> <ul style="list-style-type: none"> <li>• <b>mode sp</b>: Set the power supply mode to stack power (SP), to participate in the power stack. This is the default setting for power supply B (PS2).</li> </ul>
<b>Step 3</b>	<b>power xps <i>switch-number</i> supply {A   B} {on   off}</b>	<p><b>Note</b> The <i>switch-number</i> represents the switch number in the data stack, a value from 1 to 9.</p> <p>Sets the XPS power supply to be on or off. The default is for both power supplies to be on.</p>
<b>Step 4</b>	<b>end</b>	Returns to privileged EXEC mode.
<b>Step 5</b>	<b>show env xps power</b>	Displays the status of the XPS power supplies.

## Monitoring and Maintaining the Cisco Expandable Power System 2200

Command	Purpose
<b>show env xps system</b>	Verifies the configured name of the system and ports.
<b>show env xps port</b>	Verifies the XPS configuration of the port.
<b>show env xps power</b>	Displays the status of the XPS power supplies.

## Additional References for Cisco Expandable Power System 2200

### Related Documents

Related Topic	Document Title
For complete syntax and usage information for the commands used in this chapter.	See the <i>Interface and Hardware Commands</i> section of the <i>Command Reference (Catalyst 9300 Series Switches)</i> .

## Feature History for Cisco Expandable Power System 2200

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Everest 16.5.1a	Cisco Expandable Power System (XPS) 2200	<p>The XPS 2200 is a standalone power system that can provide backup power to connected devices that experience a power supply failure; or, in a Catalyst switch power stack, it can supply additional power to the power stack budget.</p> <p>Support for this feature was introduced only on the 9300 switch models of the Cisco Catalyst 9300 Series Switches.</p>

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to [Cisco Feature Navigator](#).





## CHAPTER 10

# Configuring EEE

---

- [Restrictions for EEE, on page 105](#)
- [Information About EEE, on page 105](#)
- [How to Configure EEE, on page 106](#)
- [Monitoring EEE, on page 107](#)
- [Configuration Examples for Configuring EEE, on page 108](#)
- [Additional References for EEE, on page 108](#)
- [Feature History for Configuring EEE, on page 108](#)

## Restrictions for EEE

Energy Efficient Ethernet (EEE) has the following restrictions:

- Changing the EEE configuration resets the interface because the device has to restart Layer 1 autonegotiation.
- We recommend that you enable Link Layer Discovery Protocol (LLDP) for devices that require longer wakeup times before they are able to accept data on their receive paths. This enables the device to negotiate for extended system wakeup times from the transmitting link partner.
- If a Multigigabit Ethernet port link is negotiated to 100 Mbps speeds, EEE will not initiate power-saving on the device.
- EEE is not supported on the following switches:
  - C9300-24S
  - C9300-48S

## Information About EEE

This section provides information about EEE.

## EEE Overview

Energy Efficient Ethernet (EEE) is an IEEE 802.3az standard that is designed to reduce power consumption in Ethernet networks during idle periods.

## Default EEE Configuration

EEE is disabled by default.

## How to Configure EEE

You can enable or disable EEE on an interface that is connected to an EEE-capable link partner.

## Enabling or Disabling EEE

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>configure terminal</b> <b>Example:</b>  Device# <code>configure terminal</code>	Enters global configuration mode.
<b>Step 2</b>	<b>interface <i>interface-id</i></b> <b>Example:</b>  Device (config)# <code>interface gigabitethernet 1/0/1</code>	Specifies the interface to be configured, and enters interface configuration mode.
<b>Step 3</b>	<b>power efficient-ethernet auto</b> <b>Example:</b>  Device (config-if)# <code>power efficient-ethernet auto</code>	Enables EEE on the specified interface. When EEE is enabled, the device advertises and autonegotiates EEE to its link partner.
<b>Step 4</b>	<b>no power efficient-ethernet auto</b> <b>Example:</b>  Device (config-if)# <code>no power efficient-ethernet auto</code>	Disables EEE on the specified interface.
<b>Step 5</b>	<b>end</b> <b>Example:</b>  Device (config-if)# <code>end</code>	Exits interface configuration mode, and returns to privileged EXEC mode.

	Command or Action	Purpose
<b>Step 6</b>	<b>copy running-config startup-config</b> <b>Example:</b> Device# <b>copy running-config startup-config</b>	(Optional) Saves your entries in the configuration file.

## Monitoring EEE

*Table 18: Commands for Displaying EEE Settings*

Command	Purpose
<b>show eee capabilities interface</b> <i>interface-id</i>	Displays EEE capabilities for the specified interface.
<b>show eee status interface</b> <i>interface-id</i>	Displays EEE status information for the specified interface.
<b>show eee counters interface</b> <i>interface-id</i>	Displays EEE counters for the specified interface.  <b>Note</b> Starting from Cisco IOS XE Gibraltar 16.12.1, the <b>show eee interface interface-id</b> command is not supported on switch Multigigabit (mGig) Ethernet ports.

Following are examples of the **show eee** commands:

```
Device# show eee capabilities interface gigabitEthernet2/0/1
```

```
Gi2/0/1
EEE(efficient-ethernet): yes (100-Tx and 1000T auto)
Link Partner : yes (100-Tx and 1000T auto)
```

```
ASIC/Interface : EEE Capable/EEE Enabled
```

```
Device# show eee status interface gigabitEthernet2/0/1
```

```
Gi2/0/1 is up
EEE(efficient-ethernet): Operational
Rx LPI Status : Low Power
Tx LPI Status : Low Power
Wake Error Count : 0
```

```
ASIC EEE STATUS
```

```
Rx LPI Status : Receiving LPI
Tx LPI Status : Transmitting LPI
Link Fault Status : Link Up
Sync Status : Code group synchronization with data stream intact
```

```
Device# show eee counters interface gigabitEthernet2/0/1
```

```
LP Active Tx Time (10us) : 66649648
LP Transitioning Tx : 462
LP Active Rx Time (10us) : 64911682
LP Transitioning Rx : 153
```

## Configuration Examples for Configuring EEE

This example shows how to enable EEE for an interface:

```
Device# configure terminal
Device(config)# interface gigabitethernet 1/0/1
Device(config-if)# power efficient-ethernet auto
```

This example shows how to disable EEE for an interface:

```
Device# configure terminal
Device(config)# interface gigabitethernet 1/0/1
Device(config-if)# no power efficient-ethernet auto
```

## Additional References for EEE

### Related Documents

Related Topic	Document Title
For complete syntax and usage information for the commands used in this chapter.	See the <i>Interface and Hardware Commands</i> section of the <i>Command Reference (Catalyst 9300 Series Switches)</i> .

## Feature History for Configuring EEE

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Everest 16.5.1a	Energy Efficient Ethernet	Energy Efficient Ethernet (EEE) is an IEEE 802.3az standard that is designed to reduce power consumption in Ethernet networks during idle periods.
Cisco IOS XE Gibraltar 16.12.1	EEE on Multigigabit (mGig) Ethernet ports	Energy Efficient Ethernet was introduced on switch models with mGig Ethernet ports.

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to [Cisco Feature Navigator](#).



## CHAPTER 11

# Configuring Power over Ethernet

---

- [Information About Power over Ethernet, on page 109](#)
- [How to Configure PoE and UPOE, on page 116](#)
- [Monitoring Power Status, on page 121](#)
- [Additional References for Power over Ethernet, on page 125](#)
- [Feature History for Power over Ethernet, on page 125](#)

## Information About Power over Ethernet

The following sections provide information about Power over Ethernet (PoE), the supported protocols, and standards and power management.

### PoE and PoE+ Ports

A PoE-capable switch port automatically supplies power to one of these connected devices if the switch senses that there is no power in the circuit:

- A Cisco prestandard powered device (such as a Cisco IP phone)
- An IEEE 802.3af-compliant powered device
- An IEEE 802.3at-compliant powered device
- An IEEE 802.3bt-compliant powered device

A powered device can receive redundant power when it is connected to a PoE switch port and to an AC power source. The device does not receive redundant power when it is only connected to the PoE port.



**Note** The following Cisco Catalyst 9300 Switches do not support PoE:

- C9300-24T
- C9300-48T
- C9300-24S
- C9300-48S
- C9300L-24T
- C9300L-48T

## Supported Protocols and Standards

The device uses the following protocols and standards to support PoE:

- **Cisco Discovery Protocol (CDP) with power consumption:** The powered device notifies the device of the amount of power it is consuming. The device does not reply to the power-consumption messages. The device can only supply power to or remove power from the PoE port.
- **Cisco intelligent power management:** The powered device and the device negotiate through power-negotiation CDP messages for an agreed-upon power-consumption level. The negotiation allows a high-power powered device, which consumes more than 7 W, to operate at its highest power mode. The powered device first boots up in low-power mode, consumes less than 7 W, and negotiates to obtain enough power to operate in high-power mode. The device changes to high-power mode only when it receives confirmation from the device.

High-power devices can operate in low-power mode on the device that do not support power-negotiation CDP.

Cisco intelligent power management is backward-compatible with CDP with power consumption; the device responds according to the CDP message that it receives. CDP is not supported on third party-powered devices. Therefore, the device uses the IEEE classification to determine the power usage of the device.

- **IEEE 802.3af:** The major features of this standard are powered-device discovery, power administration, disconnect detection, and optional powered-device power classification.
- **IEEE 802.3at:** The PoE+ standard increases the maximum power that can be drawn by a powered device from 15.4 W per port to 30 W per port.
- The **Cisco Universal Power Over Ethernet (UPOE)** feature provides the capability to source up to 60 W of power (2 x 30 W) over both signal and spare pairs of the RJ-45 Ethernet cable by using the Layer 2 power negotiation protocols such as CDP or LLDP. An LLDP and CDP request of 30 W and higher in the presence of the 4-wire Cisco proprietary spare-pair power type, length, and value descriptions (TLV) can provide power to the spare pair.

When enabled in IEEE 802.3bt mode, Cisco UPOE devices function as 802.3bt Type 3 devices, supporting up to Class 6 (see [IEEE Power Classification table](#) in the document) on every port.



**Note** Only the following UPOE switches are IEEE 802.3bt-complaint Type 3 devices:

- C9300-24U
- C9300-48U
- C9300-24UX
- C9300-48UXM
- C9300-48UN
- C9300L-24UXG-4X
- C9300L-24UXG-2Q
- C9300L-48UXG-4X
- C9300L-48UXG-2Q
- C9300LM-24U-4Y
- C9300LM-48U-4Y
- C9300LM-48UX-4Y

- **IEEE 802.3bt:** This new standard led to the introduction of new power sourcing equipment (PSE) that supports not just new capabilities but also compatibility with previous standards. Cisco introduced its 90-watt-capable line card on the Cisco Catalyst 9400 Series Switches that are in complete compliance with the IEEE 802.3bt standard and also support Cisco UPOE.

This standard enables delivery of up to 90 W to a powered device over four pairs of Category 5e and above cables. It also introduces additional classes of PSEs and powered devices, class 5 to class 8, with PSE output power ranging between 45 W to 90 W, and the powered device input power ranging from 40 W to 71.3 W. This standard introduces new types of PSEs or powered devices, that is, Type 3(60 W) and Type 4 (90 W).

The IEEE 802.3bt standard enables support for Dual Signature Powered Devices, Single Signature Powered Devices, and Single Pair Powered Devices. It also supports power demotion to handle scenarios where Type 4 Powered Device is connected to a Type 3 PSE.

For more information, see the [Additional References](#) section.

- **Cisco UPOE+:** Cisco UPOE+ combines the new IEEE 802.3bt standard and Cisco UPOE, which means Cisco UPOE+ switches are in complete compliance with the 802.3bt standard and also support all previous standards, such as 802.3af and IEE 802.3at, as well as Cisco UPOE. This feature provides the capability to source up to 90 W on the IEEE 802.3bt-compliant Type 4 devices.

A Type 3 PSE can power up a Type 4 powered device through a power demotion to 60 W.

Some legacy Cisco powered devices (such as 7910, 7940, 7960 IP phones and AP350 wireless access points) are incompatible with Type 4 Power Supply Equipments (PSEs), as defined in the IEEE 802.3bt standard. If connected, the PSE will report a Tstart or I<sub>max</sub> fault with each periodic attempt at providing power to the powered device. For continued use of these legacy Cisco powered devices, connect them to Cisco PoE+ or UPOE PSEs.

Powered devices that do not meet the standard detection signature capacitance (such as CIVS-IPC-6000P) can be detected properly with PoE+ or Cisco UPOE devices running in UPOE mode, but may not be detected properly when running in 802.3bt mode.

## Powered-Device Detection and Initial Power Allocation

The switch detects a Cisco prestandard or an IEEE-compliant powered device when the PoE-capable port is in the no-shutdown state, PoE is enabled (the default), and the connected device is not powered by an AC adaptor.

After device detection, the switch determines the device's power requirements based on its type:

- The initial power allocation is the maximum amount of power that a powered device requires. The switch initially allocates this amount of power when it detects and powers the powered device. Because the switch receives CDP messages from the powered device, and because the powered device negotiates power levels with the switch through CDP power-negotiation messages, the initial power allocation might be adjusted.
- The switch classifies the detected IEEE device within a power consumption class. Based on the available power in the power budget, the switch determines if a port can be powered. The following table lists these levels.

**Table 19: IEEE Power Classifications**

Class	Maximum Power Level Required from the Device
0 (class status unknown)	15.4 W
1	4 W
2	7 W
3	15.4 W
4	30 W
5	45 W
6	60 W
7	75 W
8	90 W

The switch monitors and tracks requests for power and grants power only when it is available. The switch tracks the power budget (the amount of power available on the device for PoE). The switch also performs power-accounting calculations when a port is granted or denied power to keep the power budget up to date.

After power is applied to the port, the switch uses CDP to determine the *CDP-specific* power consumption requirement of the connected Cisco powered devices, which is the amount of power to allocate based on the CDP messages. The switch adjusts the power budget accordingly. Note that CDP does not apply to third-party PoE devices. The switch processes a request, and either grants or denies power. If the request is granted, the switch updates the power budget. If the request is denied, the switch ensures that the power to the port is

turned off, generates a syslog message, and updates the LEDs. Powered devices can also negotiate with the switch for more power.

With PoE+, powered devices use IEEE 802.3at and LLDP power with medium-dependent interface (MDI) type, length, and value descriptions (TLVs) and power-via-MDI TLVs, for negotiating power up to 30 W. Cisco prestandard devices and Cisco IEEE powered devices can use CDP or the IEEE 802.3 at power-via-MDI power-negotiation mechanism to request power levels up to 30 W.



---

**Note** The initial allocation for Class 0, Class 3, and Class 4 powered devices is 15.4 W. When a device starts up and uses CDP or LLDP to send a request for more than 15.4 W, it can be allocated up to the maximum of 30 W.

---



---

**Note** The CDP-specific power consumption requirement is referred to as the *actual* power consumption requirement in the Cisco Catalyst Switches software configuration guides and command references.

---

If the switch detects a fault caused by an undervoltage, overvoltage, overtemperature, oscillator fault, or short-circuit condition, it turns off power to the port, generates a syslog message, and updates the power budget and LEDs.

The PoE feature operates the same whether or not the device is a stack member. The power budget is per device and independent of any other devices in the stack. Election of a new active device does not affect PoE operation. The active device keeps track of the PoE status for all devices and ports in the stack and includes the status in output displays.

The stacking-capable device also supports StackPower, which allows the power supplies to share the load across multiple systems in a stack when you connect the device with power stack cables. You can manage the power supplies of up to four stack members as one large power supply.



---

**Note** Cisco Catalyst 9300L Series Switches do not support StackPower.

---

## Power Management Modes

To configure the overall PoE budget of DIN rail switches, use the global configuration command **power inline wattage max***max-wattage*. Limiting the PoE budget prevents overdrawing power and exceeding the capacity of the power source.

The device supports these PoE modes:

- **auto**: The auto mode is the default setting. The device automatically detects if the connected device requires power. If the device discovers a powered device connected to the port, and if the device has enough power, it grants power, updates the power budget, and turns on power to the port on a first-come, first-served basis, and updates the LEDs. For LED information, see the hardware installation guide.

If the device has enough power for all the powered devices, they all come up. If enough power is available for all the powered devices connected to the device, power is turned on to all the devices. If enough PoE is not available, or if a device is disconnected and reconnected while other devices are waiting for power, it cannot be determined which devices are granted or are denied power.

If granting power exceeds the system's power budget, the device denies power, ensures that power to the port is turned off, generates a syslog message, and updates the LEDs. After power is denied, the device periodically rechecks the power budget and continues to attempt to grant the request for power.

If a device that is being powered by the device is then connected to wall power, the device might continue to power the device. The device might continue to report that it is still powering the device irrespective of whether the device is being powered by the device or receiving power from an AC power source.

If a powered device is removed, the device automatically detects the disconnect and removes power from the port. You can connect a nonpowered device without damaging it.

You can specify the maximum wattage that is allowed on the port. If the IEEE class maximum wattage of the powered device is greater than the configured maximum value, the device does not provide power to the port. If the device powers a powered device, but the powered device later requests, through CDP messages, more than the configured maximum value, the device removes power to the port. The power that was allocated to the powered device is reclaimed into the global power budget. If you do not specify a wattage, the device delivers the maximum value. Use the **auto** setting on any PoE port.

- **static:** The device preallocates power to the port (even when no powered device is connected) and guarantees that power will be available for the port. The device allocates the port-configured maximum wattage, and the amount is never adjusted through the IEEE class or by CDP messages from the powered device. Because power is preallocated, any powered device that uses less than or equal to the maximum wattage, is guaranteed to be powered when it is connected to the static port. The port no longer participates in the first-come, first-served model.

However, if the powered device's IEEE class is greater than the maximum wattage, the device does not supply power to it. If the device learns through CDP messages that the powered device is consuming more than the maximum wattage, the device shuts down the powered device.

If you do not specify a wattage, the device preallocates the maximum value. The device powers the port only if it discovers a powered device. Use the **static** setting on a high-priority interface.

- **never:** The device disables powered-device detection and never powers the PoE port even if an unpowered device is connected. Use this mode only when you want to make sure that power is never applied to a PoE-capable port, making the port a data-only port.

For most situations, the default configuration (**auto** mode) works well, providing plug-and-play operation. No further configuration is required. However, configure a PoE port for a higher priority, to make it data only, or to specify a maximum wattage to disallow high-power powered devices on a port.

Stacking-capable device also support StackPower, which allows device power supplies to share the load across multiple systems in a stack by connecting up to four device with power stack cables.

## Power Monitoring and Power Policing

When policing of the real-time power consumption is enabled, the device takes action when a powered device consumes more power than the maximum amount allocated, which is also referred to as the *cutoff-power value*.

When PoE is enabled, the device senses and monitors the real-time power consumption of the connected powered device. This is called *power monitoring* or *power sensing*. The device also polices the power usage with the *power policing* feature.

Power monitoring is backward-compatible with Cisco intelligent power management and CDP-based power consumption. It works with these features to ensure that the PoE port can supply power to a powered device.

The device senses the real-time power consumption of the connected device as follows:

1. The device monitors the real-time power consumption by individual ports.
2. The device records the power consumption, including peak power usage, and reports this information through the CISCO-POWER-ETHERNET-EXT-MIB.
3. If power policing is enabled, the device polices power usage by comparing the real-time power consumption with the maximum power allocated to the device. The maximum power consumption is also referred to as the *cutoff power* on a PoE port.

If the device uses more than the maximum power allocation on the port, the device can either turn off the power to the port, or can generate a syslog message and update the LEDs (the port LED is now blinking amber) while still providing power to the device based on the device configuration. By default, power-usage policing is disabled on all the PoE ports.

If error recovery from the PoE error-disabled state is enabled, the device automatically takes the PoE port out of the error-disabled state after the specified amount of time.

If error recovery is disabled, you can manually re-enable the PoE port by using the **shutdown** and **no shutdown** interface configuration commands.

4. If policing is disabled, no action occurs when the powered device consumes more than the maximum power allocation on the PoE port, which could adversely affect the device.

## Power Consumption Values

You can configure the initial power allocation and the maximum power allocation on a port. However, these values are the configured values that determine when the device should turn on or turn off power on the PoE port. The maximum power allocation is not the same as the actual power consumption of the powered device. The actual cutoff power value that the device uses for power policing is not equal to the configured power value.

When power policing is enabled, the device polices the power usage *at the switch port*, where the power consumption is greater than that by the device. When you manually set the maximum power allocation, you must consider the power loss over the cable from the switch port to the powered device. The cutoff power is the sum of the rated power consumption of the powered device and the worst-case power loss over the cable.

We recommend that you enable power policing when PoE is enabled on your device. For example, for a Class 1 device, if policing is disabled and you set the cutoff-power value by using the **power inline auto max 6300** interface configuration command, the configured maximum power allocation on the PoE port is 6.3 W (6300 mW). The device provides power to the connected devices on the port if the device needs up to 6.3 W. If the CDP power-negotiated value or the IEEE classification value exceeds the configured cutoff value, the device does not provide power to the connected device. After the device turns on the power on the PoE port, the device does not police the real-time power consumption of the device, and the device can consume more power than the maximum allocated amount, which could adversely affect the device and the devices connected to the other PoE ports.

Because a standalone device supports internal power supplies, the total amount of power available for the powered devices varies depending on the power supply configuration.

- If a power supply is removed and replaced by a new power supply with less power and the device does not have enough power for the powered devices, the device denies power to the PoE ports in auto mode in descending order of the port numbers. If the device still does not have enough power, the device then denies power to the PoE ports in static mode in descending order of the port numbers.
- If the new power supply supports more power than the previous one and the device now has more power available, the device grants power to the PoE ports in static mode in ascending order of the port numbers.

If it still has power available, the device then grants power to the PoE ports in auto mode in ascending order of the port numbers.

The stacking-capable device also supports StackPower, which allows power supplies to share the load across multiple systems in a stack by connecting the device with power stack cables. You can collectively manage the power supplies of up to four stack members as one large power supply.

## Cisco Universal Power Over Ethernet

Cisco Universal Power Over Ethernet (Cisco UPOE) is a Cisco-proprietary technology that extends the IEEE 802.3 at PoE standard to provide the capability to source up to 60 W of power over standard Ethernet cabling infrastructure (Class D or better) by using the spare pair of an RJ-45 cable (wires 4,5,7,8) with the signal pair (wires 1,2,3,6). Power on the spare pair is enabled when the switch port and end device mutually identify themselves as Cisco UPOE-capable using CDP or LLDP and the end device's requests for power to be enabled on the spare pair. When the spare pair is powered, the end device can negotiate up to 60 W of power from the switch using CDP or LLDP.

If the end device supports detection and classification on both signal and spare pairs, but does not support the CDP or LLDP extensions required for Cisco UPOE, a 4-pair forced mode configuration automatically enables power on both signal and spare pairs from the switch port.

## How to Configure PoE and UPOE

The following tasks describe how you can configure PoE and UPOE.

### Configuring a Power Management Mode on a PoE Port



**Note** When you make PoE configuration changes, the port that are being configured drops power. Depending on the new configuration, the state of the other PoE ports and the state of the power budget, the port might not be powered up again. For example, port 1 is in the auto and on state, and you configure it for static mode. The device removes power from port 1, detects the powered device, and repowers the port. If port 1 is in the auto and on state, and you configure it with a maximum wattage of 10 W, the device removes power from the port and then redetects the powered device. The device repowers the port only if the powered device is a class 1, class 2, or a Cisco-only powered device.

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.

	Command or Action	Purpose
Step 3	<p><b>interface</b> <i>interface-id</i></p> <p><b>Example:</b></p> <pre>Device(config)# <b>interface</b> gigabitethernet2/0/1</pre>	<p>Specifies the physical port to be configured, and enters interface configuration mode.</p>
Step 4	<p><b>power inline</b> {<b>auto</b> [<b>max</b> <i>max-wattage</i>]   <b>never</b>   <b>static</b> [<b>max</b> <i>max-wattage</i>] }</p> <p><b>Example:</b></p> <pre>Device(config-if)# <b>power inline auto</b></pre>	<p>Configures the PoE mode on the port. The following are the keywords:</p> <ul style="list-style-type: none"> <li>• <b>auto</b>: Enables detection of powered devices. If enough power is available, automatically allocates power to the PoE port after device detection. This is the default setting.</li> <li>• <b>max</b> <i>max-wattage</i>: Limits the power allowed on the port. The range for Cisco UPOE ports is 4000 to 60000 milliWatts (mW). If no value is specified, the maximum is allowed.</li> <li>• <b>never</b>: Disables device detection and power to the port.</li> </ul> <p><b>Note</b></p> <p>If a port has a Cisco-powered device connected to it, do not use the <b>power inline never</b> command to configure the port. A false link-up can occur, placing the port in the error-disabled state.</p> <ul style="list-style-type: none"> <li>• <b>static</b>: Enables detection of powered devices. Preallocate (reserve) power for a port before the device discovers the powered device. The device reserves power for this port even when no device is connected, and guarantees that power will be provided upon device detection.</li> </ul> <p>The device allocates power to a port configured in static mode before it allocates power to a port configured in auto mode.</p>
Step 5	<p><b>end</b></p> <p><b>Example:</b></p> <pre>Device(config-if)# <b>end</b></pre>	<p>Returns to privileged EXEC mode.</p>
Step 6	<p><b>show power inline</b> [<i>interface-id</i>   <b>module</b> <i>switch-number</i>]</p> <p><b>Example:</b></p>	<p>Displays the PoE status for a device or a device stack, for the specified interface, or for a specified stack member.</p>

	Command or Action	Purpose
	Device# <code>show power inline</code>	The <code>module switch-number</code> keywords are supported only on stacking-capable devices.
<b>Step 7</b>	<b>copy running-config startup-config</b>  <b>Example:</b> Device# <code>copy running-config startup-config</code>	(Optional) Saves your entries in the configuration file.

## Enabling Power on Signal and Spare Pairs



**Note** Do not perform this task if the end device cannot source inline power on the spare pair, or if the end device supports the CDP or LLDP extensions for Cisco UPOE.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>configure terminal</b>  <b>Example:</b> Device# <code>configure terminal</code>	Enters global configuration mode.
<b>Step 2</b>	<b>interface interface-id</b>  <b>Example:</b> Device(config)# <code>interface gigabitethernet2/0/1</code>	Specifies the physical port to be configured, and enters interface configuration mode.
<b>Step 3</b>	<b>power inline four-pair forced</b>  <b>Example:</b> Device(config-if)# <code>power inline four-pair forced</code>	(Optional) Enables power on both signal and spare pairs from a switch port.
<b>Step 4</b>	<b>end</b>  <b>Example:</b> Device(config-if)# <code>end</code>	Exits interface configuration mode, and returns to privileged EXEC mode.

## Configuring Power Policing

By default, the device monitors the real-time power consumption of connected powered devices. You can configure the device to police the power usage. By default, policing is disabled.

## Procedure

	Command or Action	Purpose
Step 1	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
Step 2	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
Step 3	<b>interface</b> <i>interface-id</i> <b>Example:</b> Device(config)# <b>interface</b> <b>gigabitethernet2/0/1</b>	Specifies the physical port to be configured, and enters interface configuration mode.
Step 4	<b>power inline police</b> [ <b>action</b> { <b>log</b>   <b>errdisable</b> }] <b>Example:</b> Device(config-if)# <b>power inline police</b>	Configures the device to take one of these actions if the real-time power consumption exceeds the maximum power allocation on the port: <ul style="list-style-type: none"> <li>• <b>power inline police</b>: Shuts down the PoE port, turns off power to it, and puts it in the error-disabled state.</li> </ul> <p><b>Note</b>            You can enable error detection for the PoE error-disabled cause by using the <b>errdisable detect cause inline-power</b> global configuration command. You can also enable the timer to recover from the PoE error-disabled state by using the <b>errdisable recovery cause inline-power interval</b> <i>interval</i> global configuration command.</p> <ul style="list-style-type: none"> <li>• <b>power inline police action errdisable</b>: Turns off power to the port if the real-time power consumption exceeds the maximum power allocation on the port.</li> <li>• <b>power inline police action log</b>: Generates a syslog message while still providing power to the port.</li> </ul> <p>If you do not enter the <b>action log</b> keywords, the default action shuts down the port and puts the port in the error-disabled state.</p>

	Command or Action	Purpose
<b>Step 5</b>	<b>exit</b> <b>Example:</b> Device(config-if)# <b>exit</b>	Exits interface configuration mode, and returns to global configuration mode.
<b>Step 6</b>	Use one of the following: <ul style="list-style-type: none"> <li>• <b>errdisable detect cause inline-power</b></li> <li>• <b>errdisable recovery cause inline-power</b></li> <li>• <b>errdisable recovery interval interval</b></li> </ul> <b>Example:</b> Device(config)# <b>errdisable detect cause inline-power</b> Device(config)# <b>errdisable recovery cause inline-power</b> Device(config)# <b>errdisable recovery interval 100</b>	(Optional) Enables error recovery from the PoE error-disabled state, and configures the PoE recovery mechanism variables. By default, the recovery interval is 300 seconds. <b>interval interval:</b> Specifies the time in seconds, to recover from the error-disabled state. The range is 30 to 86400.
<b>Step 7</b>	<b>exit</b> <b>Example:</b> Device(config)# <b>exit</b>	Returns to privileged EXEC mode.
<b>Step 8</b>	Use one of the following: <ul style="list-style-type: none"> <li>• <b>show power inline police</b></li> <li>• <b>show errdisable recovery</b></li> </ul> <b>Example:</b> Device# <b>show power inline police</b> Device# <b>show errdisable recovery</b>	Displays the power-monitoring status, and verifies the error recovery settings.
<b>Step 9</b>	<b>copy running-config startup-config</b> <b>Example:</b> Device# <b>copy running-config startup-config</b>	(Optional) Saves your entries in the configuration file.

## Enable the 802.3bt Mode on Type 3 Cisco UPOE Modules

The Cisco Catalyst 9300 UPOE switches that support IEEE 802.3bt standard for Type 3 powered devices are in 802.3at mode, by default. You can enable 802.3bt mode on them using the **hw-module switch switch\_no upoe-plus** command in the global configuration mode. Note that the **hw-module switch switch\_no upoe-plus** command power cycles the switch upon configuration.

```
Device(config)# hw-module switch 2 upoe-plus
!!!WARNING!!!This configuration will power cycle the switch to make it effective. Would you
like to continue y/n?
Device#y
```

You can revert to 802.3at mode using the **no** form of the command: **no hw-module switch switch\_no upoe-plus**.



**Note** C9300X-48HX, C9300X-24HX and C9300X-48HXN modules are Type 4 PSEs that supports IEEE 802.3bt standard. These modules are in 802.3bt mode by default. Therefore, the mode-conversion **hw-module slot slot upoe-plus** command is not supported on these modules.

## Monitoring Power Status

Use the following **show** commands to monitor and verify the PoE configuration.

**Table 20: show Commands for Power Status**

Command	Purpose
<b>show env power switch</b> [ <i>switch-number</i> ]	(Optional) Displays the status of the internal power supplies for each switch in the stack or for the specified switch.  The range is 1 to 9, depending on the switch member numbers in the stack. These keywords are available only on stacking-capable switches.
<b>show power inline</b> [ <i>interface-id</i>   <b>module switch-number</b> ]	Displays PoE status for a switch or switch stack, for an interface, or for a specific switch in the stack.
<b>show power inline police</b>	Displays power-policing data.
<b>show power inline meter</b>	Displays metered PoE power consumption.
<b>show power inline upoe-plus</b> [ <i>interface-id</i> ] [ <b>module</b> ]	Displays the PoE status for an interface that is enabled for 802.3bt-compliant mode.

### Examples

```
Device# show power inline upoe-plus
```

```
Module   Available      Used      Remaining
(Watts)   (Watts)       (Watts)
-----
3         1310.0         660.0     650.0
```

```
Codes: DS - Dual Signature device, SS - Single Signature device
       SP - Single Pairset device
```

```
Interface  Admin  Type  Oper-State      Power(Watts)  Class  Device Name
State      Alt-A,B  Allocated Utilized  Alt-A,B
-----
```

```
Te3/0/1    auto   DS    on,on           60.0    6.8    3,3    Ieee PD
Te3/0/2    auto   DS    on,on           60.0    6.7    3,3    Ieee PD
Te3/0/3    auto   DS    on,on           60.0    6.8    3,3    Ieee PD
Te3/0/4    auto   DS    on,on           60.0    6.8    3,3    Ieee PD
Te3/0/5    auto   DS    on,on           60.0    6.8    3,3    Ieee PD
Te3/0/6    auto   DS    on,on           60.0    6.8    3,3    Ieee PD
```

```
Codes: DS - Dual Signature device, SS - Single Signature device
       SP - Single Pairset device
```

```

Interface   Admin  Type Oper-State      Power(Watts)  Class  Device Name
           State                Alt-A,B      Allocated Utilized  Alt-A,B
-----
Te3/0/7    auto  DS  on,on           60.0    6.8    3,3    Ieee PD
Te3/0/8    auto  DS  on,on           60.0    6.8    3,3    Ieee PD
Te3/0/9    auto  n/a  off             0.0     0.0    n/a
Te3/0/10   auto  SS  on,off          30.0    5.4    4      Ieee PD
Te3/0/11   auto  SS  on,off          30.0    9.0    4      Ieee PD
Te3/0/12   auto  SS  on,off          30.0    9.7    4      Ieee PD
Te3/0/13   auto  n/a  off             0.0     0.0    n/a
Te3/0/14   auto  n/a  off             0.0     0.0    n/a
Te3/0/15   auto  n/a  off             0.0     0.0    n/a
Te3/0/16   auto  n/a  off             0.0     0.0    n/a
Te3/0/17   auto  n/a  off             0.0     0.0    n/a
Codes: DS - Dual Signature device, SS - Single Signature device
       SP - Single Pairset device
    
```

```

Interface   Admin  Type Oper-State      Power(Watts)  Class  Device Name
           State                Alt-A,B      Allocated Utilized  Alt-A,B
-----
Te3/0/18   auto  n/a  off             0.0     0.0    n/a
Te3/0/19   auto  n/a  off             0.0     0.0    n/a
Te3/0/20   auto  n/a  off             0.0     0.0    n/a
Te3/0/21   auto  n/a  off             0.0     0.0    n/a
Te3/0/22   auto  SS  on,off          30.0    12.0   4      Ieee PD
Te3/0/23   auto  SS  on,off          30.0    12.3   4      Ieee PD
Te3/0/24   auto  SS  on,off          30.0     5.3   4      Ieee PD
    
```

```
Totals:                14  on           660.0    107.9
```

The following are descriptions of the fields that you see in the output of the **show power inline upoe-plus** command:

**Table 21: Fields Displayed in the Output of the show power inline upoe-plus Command**

Field	Description
Type	Type of PD: Single Pairset device (SP), Single Signature device (SS), Dual Signature device (DS)
Oper-State	The state of each pair on the port
Power Allocated	Power allocated to the port
Power Utilized	Power consumed by the Powered Device on the port.
Class Alt-A, B	Signal, Spare-pair respectively
Device Name	Name of the Powered Device as advertised by CDP.

The **show power inline** command is enhanced to display 802.3bt-complaint device information such as the Operational Status of the device, IEEE Class of the device, Physical Assigned Class, Allocated Power, (Power) Measured at the port.

```
Device# show power inline Te3/0/1 detail
```

```

Interface: Te3/0/1
Inline Power Mode: auto
    
```

```

Operational status (Alt-A,B): on,on
Device Detected: yes
Device Type: Ieee PD
Connection Check: DS
IEEE Class (Alt-A,B): 3,3
Physical Assigned Class (Alt-A,B): 3,3
Discovery mechanism used/configured: Ieee and Cisco
Police: off

Power Allocated
Admin Value: 60.0
Power drawn from the source: 60.0
Power available to the device: 60.0
Allocated Power (Alt-A,B): 30.0,30.0

Actual consumption
Measured at the port(watts) (Alt-A,B): 3.4,3.3
Maximum Power drawn by the device since powered on: 6.9

Absent Counter: 0
Over Current Counter: 0
Short Current Counter: 0
Invalid Signature Counter: 0
Power Denied Counter: 0

Power Negotiation Used: None
LLDP Power Negotiation      --Sent to PD--      --Rcvd from PD--
Power Type:                  -                    -
Power Source:                 -                    -
Power Priority:                -                    -
Requested Power(W):          -                    -
Allocated Power(W):          -                    -

Four-Pair PoE Supported: Yes
Spare Pair Power Enabled: Yes
Four-Pair PD Architecture: Independent
    
```

The following is a sample output of the **show power inline police** command:

```

Device# show power inline police

Module      Available      Used      Remaining
(Watts)     (Watts)       (Watts)
-----
3           1310.0        660.0     650.0
Interface  Admin Oper      Admin   Oper      Cutoff Oper
State     State  State    Police  Police    Power  Power
-----
Te3/0/1   auto  on        none    n/a       n/a     6.8
Te3/0/2   auto  on        none    n/a       n/a     6.7
Te3/0/3   auto  on        none    n/a       n/a     6.9
Te3/0/4   auto  on        none    n/a       n/a     6.8
Te3/0/5   auto  on        none    n/a       n/a     6.8
Te3/0/6   auto  on        none    n/a       n/a     6.8
Te3/0/7   auto  on        none    n/a       n/a     6.8
Te3/0/8   auto  on        none    n/a       n/a     6.8
Te3/0/9   auto  off       none    n/a       n/a     n/a
Te3/0/10  auto  on        none    n/a       n/a     5.4
Te3/0/11  auto  on        none    n/a       n/a     8.9
Te3/0/12  auto  on        none    n/a       n/a     9.5
Te3/0/13  auto  off       none    n/a       n/a     n/a
Te3/0/14  auto  off       none    n/a       n/a     n/a
Te3/0/15  auto  off       none    n/a       n/a     n/a
Interface  Admin Oper      Admin   Oper      Cutoff Oper
State     State  State    Police  Police    Power  Power
    
```





Release	Feature	Feature Information
Cisco IOS XE Everest 16.5.1a	Power over Ethernet (PoE)	Power over Ethernet (PoE) allows the LAN switching infrastructure to provide power to an endpoint, called a powered device, over a copper Ethernet cable. The following types of end points can be powered through PoE: <ul style="list-style-type: none"> <li>• A Cisco prestandard powered device</li> <li>An IEEE 802.3af-compliant powered device</li> <li>An IEEE 802.3at-compliant powered device</li> </ul>
Cisco IOS XE Gibraltar 16.12.1	Support for IEEE 802.3bt Type 3	Support for 802.3bt Type 3 compliance on the Cisco Catalyst 9300 UPOE Series Switches was introduced. The command <b>hw-module switch upoe-plus</b> was introduced to enable the 802.3bt mode on the device.
Cisco IOS XE 17.15.1	Energy Consumption Visibility Enhancement	The <b>show power inline meter</b> command was introduced. The output displays the energy meter with values of the system's PoE energy consumed.

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to [Cisco Feature Navigator](#).



## CHAPTER 12

# Configuring Perpetual PoE and Fast POE

---

- [Restrictions for Perpetual and Fast PoE, on page 127](#)
- [Information About Perpetual PoE, on page 128](#)
- [Fast POE, on page 128](#)
- [Configuring Perpetual and Fast PoE, on page 128](#)
- [Example: Configuring Perpetual and Fast PoE, on page 129](#)
- [Feature History for Perpetual PoE and Fast PoE, on page 130](#)

## Restrictions for Perpetual and Fast PoE

The following restrictions apply to perpetual and fast PoE:

- Configuration of Fast PoE or Perpetual PoE has to be done before physically connecting any endpoint. Alternatively do a manual shut/no-shut of the ports drawing power.
- Power to the ports will be interrupted in case of MCU firmware upgrade and ports will be back up immediately after the upgrade.
- When the switches are power-stacked, perpetual and fast PoE functionalities may not work as expected. This is due to power budget shortage.
- The CREE light powered device (PD) may flap at regular intervals if not configured with IP assigned from the DHCP server.
- If the PD does not support LLDP user can configure with either static or 2-event to receive required power as per the PD specification.



---

**Note** Perpetual PoE and Fast PoE are not supported on the following Cisco Catalyst 9300 SKUs:

- C9300-24S
  - C9300-48S
-

## Information About Perpetual PoE

Perpetual PoE provides uninterrupted power to connected powered device even when a power sourcing equipment (PSE) switch is starting after a reload from executing the Cisco IOS software **reload** command.



**Caution** Power to the ports will be interrupted in case of M3 or PSE firmware upgrade, and power to the ports will be backed up after Cisco IOS software starts.

## Fast POE

This feature remembers the last power drawn from a particular PSE port and switches on power the moment AC power is plugged in (within 15 to 20 seconds of switching on power) without waiting for IOS to boot up. When **poe-ha** is enabled on a particular port, the switch on a recovery after power failure, provides power to the connected endpoint devices within short duration before even the IOS forwarding starts up.



**Note** In case of UPOE, even though Fast POE is available on the switch side, the PD endpoints may not be able to take advantage of the same, due to the reliance on LLDP to signal the UPOE power availability. This reliance on LLDP requires that the PD endpoint still needs to wait till the IOS comes up and LLDP packet exchanges can happen, signaling the availability of UPOE power.

## Configuring Perpetual and Fast PoE

To configure perpetual and Fast PoE, perform the following steps.

### Before you begin

Configure the **perpetual-poe-ha** command before connecting the powered device, or manually shut or unshut the port after configuring **poe-ha** command.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.

	Command or Action	Purpose
<b>Step 3</b>	<b>interface</b> <i>interface-id</i> <b>Example:</b>  Device(config)# <b>interface</b> gigabitethernet 2/0/1	Specifies the physical port to be configured, and enters interface configuration mode.
<b>Step 4</b>	<b>power inline port perpetual-poe-ha</b> <b>Example:</b>  Device(config-if)# <b>power inline port</b> <b>perpetual-poe-ha</b>	Configures perpetual PoE. When you configure perpetual PoE on a port connected to a powered device, the powered device remains powered on during reload.
<b>Step 5</b>	<b>power inline port poe-ha</b> <b>Example:</b>  Device(config-if)# <b>power inline port</b> <b>poe-ha</b>	Configures Fast PoE. When you configure Fast PoE, if the switch is power cycled, PD device is powered on within 10-15 seconds of plugging into a power source without waiting for IOS to boot up.  <b>Note</b> You should configure perpetual PoE using <b>power inline port perpetual-poe-ha</b> command before configuring Fast PoE using <b>power inline port poe-ha</b> command.
<b>Step 6</b>	<b>end</b> <b>Example:</b>  Device(config-if)# <b>end</b>	Returns to privileged EXEC mode.

## Example: Configuring Perpetual and Fast PoE

This example shows how you can configure perpetual PoE on a switch:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# power inline port perpetual-poe-ha
Device(config-if)# end
```

This example shows how you can configure fast PoE on the switch:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# power inline port perpetual-poe-ha
Device(config-if)# power inline port poe-ha
Device(config-if)# end
```

This example shows what happens if you configure fast PoE before configuring perpetual PoE:

```
Device> enable
Device# configure terminal
```

```

Device(config)# interface gigabitethernet2/0/1
Device(config-if)# power inline port poe-ha
Interface Gi2/0/1:INFO: Please execute "power inline port perpetual-poe-ha"
configuration command when "power inline port poe-ha" is configured on
the interface to enable fast poe
Device(config-if)# power inline port perpetual-poe-ha
Device(config-if)# end

```

This example shows what happens when you disable perpetual PoE without disabling fast PoE on the interface:

```

Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# power inline port poe-ha
Interface Gi2/0/1:INFO: Please execute "power inline port perpetual-poe-ha"
configuration command when "power inline port poe-ha" is configured on
the interface to enable fast poe
Device(config-if)# power inline port perpetual-poe-ha
Device(config-if)# no power inline port poe-ha
Device(config-if)# power inline port poe-ha
Device(config-if)# no power inline port perpetual-poe-ha
Interface Gi2/0/1:INFO: Please execute "no power inline port poe-ha"
configuration command, as fast poe has no effect without "power inline
port perpetual-poe-ha" configuration on the interface
Device(config-if)# end

```

## Feature History for Perpetual PoE and Fast PoE

This table provides release and related information for the features explained in this module.

These features are available in all the releases subsequent to the one they were introduced in, unless noted otherwise.

**Table 22: Feature History for Perpetual PoE and Fast PoE**

Releases	Feature	Feature Information
Cisco IOS XE Everest 16.5.1a	Perpetual and Fast PoE	Perpetual PoE provides uninterrupted power to a connected powered device even when the PSE switch is booting.  Fast PoE remembers the last power drawn from a particular PSE port and switches on power without waiting for IOS to boot up.

Use the Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to [Cisco Feature Navigator](#).



## CHAPTER 13

# Configuring 2-event Classification

- [Restrictions for 2-Event Classification, on page 131](#)
- [Information about 2-event Classification, on page 131](#)
- [Configuring 2-Event Classification, on page 131](#)
- [Example: Configuring 2-Event Classification, on page 132](#)
- [Feature History for 2-Event Classification, on page 132](#)

## Restrictions for 2-Event Classification

The following restrictions apply to 2-event classification:

- Configuration of 2-event classification has to be done before physically connecting any endpoint. Alternatively, do a manual shut and unshut of the ports drawing power.
- Power to the ports is interrupted in case of microcontroller unit firmware upgrade and ports will be back up immediately after the upgrade.

## Information about 2-event Classification

When a class 4 device gets detected, IOS allocates 30W without any CDP or LLDP negotiation. This means that even before the link comes up the class 4 power device gets 30W.

Also, on the hardware level the PSE does a 2-event classification which allows a class 4 PD to detect PSE capability of providing 30W from hardware, register itself and it can move up to PoE+ level without waiting for any CDP/LLDP packet exchange.

Once 2-event is enabled on a port, you need to manually shut/un-shut the port or connect the PD again to start the IEEE detection again. Power budget allocation for a class-4 device will be 30W if 2-event classification is enabled on the port, else it will be 15.4W.

## Configuring 2-Event Classification

To configure a device for a 2-event classification, perform the steps given below.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>interface <i>interface-id</i></b> <b>Example:</b> Device(config)# <b>interface</b> <b>gigabitethernet2/0/1</b>	Specifies the physical port to be configured, and enters interface configuration mode.
<b>Step 4</b>	<b>power inline port 2-event</b> <b>Example:</b> Device(config-if)# <b>power inline port</b> <b>2-event</b>	Configures 2-event classification on the device.
<b>Step 5</b>	<b>end</b> <b>Example:</b> Device(config-if)# <b>end</b>	Returns to privileged EXEC mode.

## Example: Configuring 2-Event Classification

This example shows how you can configure 2-event classification:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet2/0/1
Device(config-if)# power inline port 2-event
Device(config-if)# end
```

## Feature History for 2-Event Classification

This table provides release and related information for the features explained in this module.

These features are available in all the releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Everest 16.5.1a	2-Event Classification	When a class-4 device gets detected, Cisco IOS allocates 30W without any CDP or LLDP negotiation. This means that even before the link comes up, the class-4 power device gets 30W.

Use the Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to [Cisco Feature Navigator](#).





## CHAPTER 14

# Configuring Auto SmartPorts

- [Restrictions for Auto SmartPorts, on page 135](#)
- [Information about Auto SmartPorts, on page 135](#)
- [How to Configure Auto SmartPorts, on page 138](#)
- [Configuration Examples for Auto SmartPorts, on page 141](#)
- [Feature History for Auto SmartPorts, on page 142](#)

## Restrictions for Auto SmartPorts

- Although Auto SmartPort detects the Cisco switch it does not invoke the event trigger automatically. The event trigger needs to be manually invoked to map the switch to macros.

## Information about Auto SmartPorts

Auto SmartPort macros dynamically configure ports based on the device type detected on the port. When the switch detects a new device on a port, it applies the appropriate Auto SmartPorts macro. When a link-down event occurs on the port, the switch removes the macro. For example, when you connect a Cisco IP phone to a port, Auto SmartPorts automatically applies the Cisco IP phone macro. The Cisco IP phone macro enables quality of service (QoS), security features, and a dedicated voice VLAN to ensure proper treatment of delay-sensitive voice traffic.

Auto SmartPorts uses event triggers to map devices to macros. The most common event triggers are based on Cisco Discovery Protocol (CDP) messages received from connected devices. The detection of a device (Cisco IP phone, Cisco wireless access point, or Cisco router) invokes an event trigger for that device.

Link Layer Discovery Protocol (LLDP) is used to detect devices that do not support CDP. Other mechanisms used as event triggers include the 802.1X authentication result and MAC-address learned.

System built-in event triggers exist for various devices based mostly on CDP and LLDP messages and some MAC address. These triggers are enabled as long as Auto SmartPort is enabled.

You can configure user-defined trigger groups for profiles and devices. The name of the trigger group is used to associate a user-defined macro.

## Auto SmartPort Macros

The Auto SmartPort macros are groups of CLI commands. Detection of devices on a port triggers the application of the macro for the device. System built-in macros exist for various devices, and, by default, system built-in triggers are mapped to the corresponding built-in macros. You can change the mapping of built-in triggers or macros as needed.

A macro basically applies or removes a set of CLIs on an interface based on the link status. In a macro, the link status is checked. If the link is up, then a set of CLIs is applied; if the link is down, the set is removed (the no format of the CLIs are applied). The part of the macro that applies the set of CLIs is termed macro. The part that removes the CLIs (the no format of the CLIs) are termed antimacro.

When a device is connected to an Auto SmartPort, if it gets classified as a lighting end point, it invokes the event trigger **CISCO\_LIGHT\_EVENT**, and the macro **CISCO\_LIGHT\_AUTO\_SMARTPORT** is executed.

## Customizing Device Classifier

The device classifier collects information from protocols such as CDP, LLDP, and DHCP to identify devices. You must enable CDP and LLDP on a device. To make DHCP options information available to the device classifier, you must enable the DHCP Snooping feature on the device. The device attributes that are collected from these protocols are evaluated against a set of profiles available to the device classifier to find the best match. The best-matched profile is used for device identification.

The device classifier uses three types of profile definitions—built-in, default, and user-defined.

- Built-in profiles contain the device profiles that are known to the Auto SmartPort module that comprises a limited set of Cisco devices. They are built into Cisco IOS and cannot be changed.
- Default profiles are stored as a text file in nonvolatile storage and allow the device classifier to identify a much larger set of devices. Default profiles are updated as part of the Cisco IOS archive download.
- User-defined profiles support custom profiling based on users' input. The device classifier identifies rules, conditions, and profiles from the user input.

## Commands run by CISCO\_LIGHT\_AUTO\_SMARTPORT

When the macro is executed, it runs a series of commands on the switch.

The commands that are executed by running the macro **CISCO\_LIGHT\_AUTO\_SMARTPORT** are:

- switchport mode access
- switchport port-security violation restrict
- switchport port-security mac-address sticky
- switchport port-security
- power inline port poe-ha
- storm-control broadcast level 50.00
- storm-control multicast level 50.00
- storm-control unicast level 50.00

- spanning-tree portfast
- spanning-tree bpduguard enable

## Enabling Auto SmartPort



**Note** Auto SmartPorts are disabled by default.

To disable Auto SmartPort macros on a specific port, use the **no macro auto global processing** interface command before enabling Auto SmartPort globally.

To enable Auto SmartPort globally, use the **macro auto global processing** global configuration command.

To enable an Auto SmartPort, perform this task:

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>device classifier</b> <b>Example:</b> Device(config)# <b>device classifier</b>	Enables the device classifier. Use <b>no device classifier</b> command to disable the device classifier.
<b>Step 4</b>	<b>macro auto global processing</b> <b>Example:</b> Device(config)# <b>macro auto global processing</b>	Enables Auto SmartPorts on the switch globally. Use <b>no macro auto global processing</b> command to disable Auto SmartPort globally.
<b>Step 5</b>	<b>end</b> <b>Example:</b> Device(config)# <b>end</b>	Returns to privileged EXEC mode.
<b>Step 6</b>	<b>show running-config</b> <b>Example:</b> Device# <b>show running-config</b>	Verifies your entries.
<b>Step 7</b>	<b>copy running-config startup-config</b> <b>Example:</b>	(Optional) Saves your entries in the configuration file.

	Command or Action	Purpose
	Device# <code>copy running-config startup-config</code>	

## How to Configure Auto SmartPorts

The following section provides information about how to configure auto smartports.



**Note** Follow these guidelines when you are configuring Auto SmartPort Macros, performing active standby sync and configuring reload from primary to standby:

- Make sure there is no extra space in the configuration.
- Do not add extra parenthesis and tab in the configuration.
- Ensure that you do not use enter keyword more than required while configuring.

## Configuring a Device Classifier Profile

To customise device classifier profile, follow the steps:

### Before you begin

Disable device classifier before customising device classifier profiles. Use the **no device classifier** command to disable device classifier.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Device> <code>enable</code>	Enables privileged EXEC mode.  Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b>  <b>Example:</b> Device# <code>configure terminal</code>	Enters global configuration mode.
<b>Step 3</b>	<b>device classifier condition</b> <i>condition-name</i> [ <b>op</b> { <b>OR</b>   <b>AND</b> }]  <b>Example:</b> Device(config)# <code>device classifier condition ts-cond1</code>	Defines device classifier condition. <ul style="list-style-type: none"> <li>• <i>condition-name</i> sets the name of the condition for device classifier.</li> <li>• <b>op OR</b> defines OR operator of rules. If either of the protocols defined matches, the device gets classified.</li> </ul>

	Command or Action	Purpose
		<ul style="list-style-type: none"> <li>• <b>op AND</b> defines AND operator of rules. If all the protocols defined matches, the device gets classified.</li> </ul> <p><b>Note</b> If you change any of the parameters of the condition, it is considered as a new condition. In this case, default <b>AND</b> operator of rules is applied for both the conditions.</p>
<b>Step 4</b>	<p>{<b>cdp dhcp lldp</b>};<b>tlv-type</b> <i>number</i> <b>value</b> {<b>integer num</b> <b>string name</b> <b>regex</b> <i>regular expression</i>}</p> <p><b>Example:</b></p> <pre>Device(config-device-classifier-condition)# cdp tlv-type 1 value String TS01</pre>	<p>Configures profiling based on match of TLV for either integer or string value of the given protocol. The protocols supported are CDP, DHCP, and LLDP.</p> <ul style="list-style-type: none"> <li>• <b>tlv-type</b> <i>number</i> configures application TLV type information. The <i>number</i> range is 1 to 255.</li> <li>• <b>value</b> configures application TLV value information. You can set an integer, regular expression or a string value.</li> </ul> <p><b>Note</b> The supported protocols are CDP, DHCP, and LLDP. Protocols like HTTP, OUI are not supported in Cisco IOS XE Bengaluru 17.4.1.</p>
<b>Step 5</b>	<p><b>exit</b></p> <p><b>Example:</b></p> <pre>Device(config-device-classifier-condition)# exit</pre>	<p>Exits device classifier condition configuration mode.</p>
<b>Step 6</b>	<p><b>device classifier device-type</b> <i>profile-name</i></p> <p><b>Example:</b></p> <pre>Device(config)# device classifier device-type Terminal-Server</pre>	<p>Configures profile based on defined conditions.</p> <p><i>profile-name</i> defines a name for the device type. The device gets classified to the set <i>profile-name</i> if there is a match of the conditions.</p>
<b>Step 7</b>	<p><b>condition</b> <i>condition-name</i></p> <p><b>Example:</b></p> <pre>Device(config-device-classifier-dtype)# condition ts-cond1</pre>	<p>Enter name of the condition for the profile.</p>
<b>Step 8</b>	<p><b>end</b></p> <p><b>Example:</b></p> <pre>Device(config)# end</pre>	<p>Returns to privileged EXEC mode.</p>

## Configuring Mapping Between Event Triggers and Built-in Macros

To map an event trigger to a built-in macro, perform this task:

### Before you begin

You need to enable Auto SmartPort macros globally. You need to perform this task when a Cisco switch is connected to the Auto SmartPort.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b> <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>macro auto execute</b> <i>event trigger</i> <b>builtin</b> <i>builtin macro name</i> <b>Example:</b> Device(config)# <b>macro auto execute</b> <b>CISCO_SWITCH_EVENT builtin</b> <b>CISCO_SWITCH_AUTO_SMARTPORT</b>	Specifies a user-defined event trigger and a macro name. This action configures mapping from an event trigger to a built-in Auto Smartports macro.
<b>Step 4</b>	<b>macro auto trigger</b> <i>event trigger</i> <b>Example:</b> Device(config)# <b>macro auto trigger</b> <b>CISCO_SWITCH_EVENT</b>	Invokes the user-defined event trigger.
<b>Step 5</b>	<b>device</b> <i>device_ID</i> <b>Example:</b> Device(config)# <b>device cisco</b> <b>WS-C3560CX-8PT-S</b>	Matches the event trigger to the device identifier.
<b>Step 6</b>	<b>end</b> <b>Example:</b> Device(config)# <b>end</b>	Returns to privileged EXEC mode.
<b>Step 7</b>	<b>show shell triggers</b> <b>Example:</b> Device# <b>show shell triggers</b>	Displays the event triggers on the switch.
<b>Step 8</b>	<b>show running-config</b> <b>Example:</b>	Verifies your entries.

	Command or Action	Purpose
	Device# <code>show running-config</code>	
<b>Step 9</b>	<b>copy running-config startup-config</b>  <b>Example:</b> Device# <code>copy running-config startup-config</code>	(Optional) Saves your entries in the configuration file.

## Configuration Examples for Auto SmartPorts

The following sections provide configuration examples for Auto SmartPorts.

### Example: Enabling Auto SmartPorts

The following example shows how you can enable an Auto SmartPort.

```
Device> enable
Device# configure terminal
Device(config)# device classifier
Device(config)# macro auto global processing
Device(config)# end
```

### Example: Configuring Mapping Between Event Triggers and Built-In Macros

The following example shows how you can configure mapping between event triggers and built-in macros:

```
Device> enable
Device# configure terminal
Device(config)# macro auto execute CISCO_SWITCH_EVENT builtin CISCO_SWITCH_AUTO_SMARTPORT
Device(config)# macro auto trigger CISCO_SWITCH_EVENT
Device(config)# device cisco WS-C3560CX-8PT-S
Device(config)# end
```

### Example: Configuring Device Classifier Profiles

The following is a sample configuration for profiling of a CDP packet. After the match is found, the device gets classified as Terminal-Server.

```
Device> enable
Device# configure terminal
Device(config)# device classifier condition ts-cond1
Device(config-device-classifier-condition)# cdp tlv-type 1 value String TS01
Device(config-device-classifier-condition)# exit
Device(config)# device classifier device-type Terminal-Server
Device(config-device-classifier-dtype)# condition ts-cond1
```

The following is a sample configuration of profiling for two different protocols with device name TLV of CDP packet and system name TLV of LLDP packet. If both the protocol matches are found, the device gets classified as Terminal-Server.

```

Device> enable
Device# configure terminal
Device(config)# device classifier condition ts-cond2 op OR
Device(config-device-classifier-condition)# cdp tlv-type 1 value integer 0x0029
Device(config-device-classifier-condition)# lldp tlv-type 5 value String TS02
Device(config-device-classifier-condition)# lldp tlv-type 4 value regex fibre*
Device(config-device-classifier-condition)# exit
Device(config)# device classifier device-type Terminal-Server
Device(config-device-classifier-dtype)# condition ts-cond2

```

The following is a sample configuration of profiling for two different protocols with device name TLV of CDP packet and system name TLV of LLDP packet. If both the protocol matches are found, the device gets classified as Terminal-Server.

```

Device> enable
Device# configure terminal
Device(config)# device classifier condition ts-cond2 op AND
Device(config-device-classifier-condition)# cdp tlv-type 1 value integer 0x0001
Device(config-device-classifier-condition)# lldp tlv-type 5 value String TS02
Device(config-device-classifier-condition)# lldp tlv-type 4 value regex fibre*
Device(config-device-classifier-condition)# exit
Device(config)# device classifier device-type Terminal-Server
Device(config-device-classifier-dtype)# condition ts-cond3

```

## Feature History for Auto SmartPorts

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

**Table 23: Feature History for Auto SmartPorts**

Release	Feature	Feature Information
Cisco IOS XE Everest 16.5.1a	Auto SmartPorts	Auto SmartPort macros dynamically configure ports based on the device type detected on the port. When the switch detects a new device on a port, it applies the appropriate Auto SmartPorts macro.
Cisco IOS XE Bengaluru 17.4.1	Device Classifier Profiles	Allows you to configure the rules for matching and classifying the device using device classifier conditions.

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to [Cisco Feature Navigator](#).



## CHAPTER 15

# Configuring COAP Proxy Server

- [Restrictions for the COAP Proxy Server, on page 143](#)
- [Information About the COAP Proxy Server, on page 143](#)
- [How to Configure the COAP Proxy Server, on page 144](#)
- [Configuration Examples for the COAP Proxy Server, on page 147](#)
- [Monitoring COAP Proxy Server, on page 151](#)
- [Feature History for COAP, on page 152](#)

## Restrictions for the COAP Proxy Server

The following restrictions apply to COAP proxy server:

- Switch cannot advertise itself as CoAP client using ipv6 broadcast (CSCuw26467).
- Support for Observe Not Implemented.
- Blockwise requests are not supported. We handle block-wise responses and can generate block-wise responses.
- DTLS Support is for the following modes only RawPublicKey and Certificate Based.
- Switch does not act as DTLS client. DTLS for endpoints only.
- Endpoints are expected to handle and respond with CBOR payloads.
- Client side requests are expected to be in JSON.
- Switch cannot advertise itself to other Resource Directories as IPv6, due to an IPv6 broadcast issue.

## Information About the COAP Proxy Server

The COAP protocol is designed for use with constrained devices. COAP works in the same way on constrained devices as HTTP works on servers in accessing information.

The comparison of COAP and HTTP is shown below:

- In the case of a webserver: **HTTP** is the protocol; **TCP** is the transport; and **HTML** is the most common information format transported.

- In case of a constrained device: **COAP** is the protocol; **UDP** is the transport; and **JSON/link-format/CBOR** is the popular information format.

COAP provides a means to access and control device using a similar **GET/POST** metaphor and restful API as in HTTP.

## How to Configure the COAP Proxy Server

To configure the COAP proxy server, you can configure the COAP proxy and COAP endpoints in the configuration mode.

The commands are: **coap [proxy | endpoints]**.

### Configuring the COAP Proxy

To start or stop the COAP proxy on the switch, perform the steps given below:

#### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode.  Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b>  <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>coap proxy</b>  <b>Example:</b> Device(config)# <b>coap proxy</b>	Enters the COAP proxy sub mode.  <b>Note</b> To stop the coap proxy and delete all configurations under coap proxy, use the <b>no coap proxy</b> command.
<b>Step 4</b>	<b>security [none [[ ipv4   ipv6 ] {ip-address ip-mask/prefix}   list {ipv4-list name   ipv6-list-name}]   dtls [id-trustpoint {identity-trustpoint label}] [verification-trustpoint {verification-trustpoint}   [ ipv4   ipv6 {ip-address ip-mask/prefix}   list {ipv4-list name   ipv6-list-name}]]]</b>  <b>Example:</b> Device(config-coap-proxy)# <b>security none ipv4 1.1.0.0 255.255.0.0</b>	Takes the encryption type as argument. The two security modes supported are <b>none</b> and <b>dtls</b>  <ul style="list-style-type: none"> <li>• <b>none</b>: Indicates no security on that port. With <b>security none</b>, a maximum of 5 ipv4 and 5 ipv6 addresses can be associated.</li> <li>• <b>dtls</b>: The DTLS security takes RSA trustpoint and Verification trustpoint which are optional. Without Verification</li> </ul>

	Command or Action	Purpose
		<p>trustpoint it does the normal Public Key Exchange.</p> <p>With <b>security dtls</b>, a maximum of 5 ipv4 and 5 ipv6 addresses can be associated.</p> <p><b>Note</b> To delete all security configurations under coap proxy, use the <b>no security</b> command.</p>
<b>Step 5</b>	<p><b>max-endpoints</b> {<i>number</i>}</p> <p><b>Example:</b></p> <pre>Device (config-coap-proxy) # max-endpoints 10</pre>	<p>(Optional) Specifies the maximum number of endpoints that can be learnt on the switch. The default value is 10. The range is 1 to 500.</p> <p><b>Note</b> To delete all max-endpoints configured under coap proxy, use the <b>no max-endpoints</b> command.</p>
<b>Step 6</b>	<p><b>port-unsecure</b> {<i>port-num</i>}</p> <p><b>Example:</b></p> <pre>Device (config-coap-proxy) # port-unsecure 5683</pre>	<p>(Optional) Configures a port other than the default 5683. The range is 1 to 65000.</p> <p><b>Note</b> To delete all port configurations under coap proxy, use the <b>no port-unsecure</b> command.</p>
<b>Step 7</b>	<p><b>port-dtls</b> {<i>port-num</i>}</p> <p><b>Example:</b></p> <pre>Device (config-coap-proxy) # port-dtls 5864</pre>	<p>(Optional) Configures a port other than the default 5684.</p> <p><b>Note</b> To delete all dtls port configurations under coap proxy, use the <b>no port-dtls</b> command.</p>
<b>Step 8</b>	<p><b>resource-directory</b> [ ipv4   ipv6 ] {<i>ip-address</i> }</p> <p><b>Example:</b></p> <pre>Device (config-coap-proxy) # resource-directory ipv4 192.168.1.1</pre>	<p>Configures a unicast upstream resource directory server to which the switch can act as a COAP client.</p> <p>With <b>resource-directory</b>, a maximum of 5 of ipv4 and 5 ipv6, ip addresses can be configured.</p> <p><b>Note</b> To delete all resource directory configurations under coap proxy, use the <b>no resource-directory</b> command.</p>
<b>Step 9</b>	<p><b>list</b> [ ipv4   ipv6 ] {<i>list-name</i>}</p> <p><b>Example:</b></p> <pre>Device (config-coap-proxy) # list ipv4 trial_list</pre>	<p>(Optional) Restricts the IP address range where the lights and their resources can be learnt. Creates a named list of ip address/masks, to be used in the <b>security [ none   dtls ]</b> command options above.</p>

	Command or Action	Purpose
		With <b>list</b> , a maximum of 5 ip-lists can be configured, irrespective of ipv4 or ipv6. We can configure a max of 5 ip addresses per ip-list.  <b>Note</b> To delete any ip list on the COAP proxy server, use the <b>no list [ ipv4   ipv6 ] {list-name}</b> command.
<b>Step 10</b>	<b>start</b>  <b>Example:</b> Device (config-coap-proxy) # <b>start</b>	Starts the COAP proxy on this switch.
<b>Step 11</b>	<b>stop</b>  <b>Example:</b> Device (config-coap-proxy) # <b>stop</b>	Stops the COAP proxy on this switch.
<b>Step 12</b>	<b>exit</b>  <b>Example:</b> Device (config-coap-proxy) # <b>exit</b>	Exits the COAP proxy sub mode.
<b>Step 13</b>	<b>end</b>  <b>Example:</b> Device (config) # <b>end</b>	Returns to privileged EXEC mode.

## Configuring COAP Endpoints

To configure the COAP Proxy to support multiple IPv4/IPv6 static-endpoints, perform the steps given below:

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode.  Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b>  <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	<b>coap endpoint [ ipv4   ipv6 ] {ip-address}</b>  <b>Example:</b>	Configures the static endpoints on the switch.  • <b>ipv4</b> : Configures the IPv4 Static endpoints.

	Command or Action	Purpose
	<pre>Device(config)# coap endpoint ipv4 1.1.1.1 Device(config)# coap endpoint ipv6 2001::1</pre>	<ul style="list-style-type: none"> <li>• <b>ipv6</b>: Configures the IPv6 Static endpoints.</li> </ul> <p><b>Note</b> To stop the coap proxy on any endpoint, use the <b>no coap endpoint [ ipv4  ipv6 ] {ip-address}</b> command.</p>
<b>Step 4</b>	<p><b>exit</b></p> <p><b>Example:</b></p> <pre>Device(config-coap-endpoint)# exit</pre>	Exits the COAP endpoint sub mode.
<b>Step 5</b>	<p><b>end</b></p> <p><b>Example:</b></p> <pre>Device(config)# end</pre>	Returns to privileged EXEC mode.

## Configuration Examples for the COAP Proxy Server

### Examples: Configuring the COAP Proxy Server

This example shows how you can configure the port number 5683 to support a maximum of 10 endpoints.

```
Device# coap proxy security none ipv4 2.2.2.2 255.255.255.0 port 5683 max-endpoints 10
```

This example shows how to configure COAP proxy on *ipv4 1.1.0.0 255.255.0.0* with **no** security settings.

```
Device(config-coap-proxy)# security ?
  dtls  dtls
  none  no security
```

```
Device(config-coap-proxy)# security none ?
  ipv4   IP address range on which to learn lights
  ipv6   IPv6 address range on which to learn lights
  list   IP address range on which to learn lights
```

```
Device(config-coap-proxy)# security none ipv4 ?
  A.B.C.D {/nn || A.B.C.D} IP address range on which to learn lights
```

```
Device(config-coap-proxy)# security none ipv4 1.1.0.0 255.255.0.0
```

This example shows how to configure COAP proxy on *ipv4 1.1.0.0 255.255.0.0* with **dtls id trustpoint** security settings.

```
Device(config-coap-proxy)# security dtls ?
  id-trustpoint DTLS RSA and X.509 Trustpoint Labels
  ipv4 IP address range on which to learn lights
  ipv6 IPv6 address range on which to learn lights
  list IP address range on which to learn lights
```

```

Device(config-coap-proxy)# security dtls id-trustpoint ?
WORD Identity TrustPoint Label

Device(config-coap-proxy)# security dtls id-trustpoint RSA-TRUSTPOINT ?
verification-trustpoint Certificate Verification Label
<cr>

Device(config-coap-proxy)# security dtls id-trustpoint RSA-TRUSTPOINT

Device(config-coap-proxy)# security dtls ?
id-trustpoint DTLS RSA and X.509 Trustpoint Labels
ipv4 IP address range on which to learn lights
ipv6 IPv6 address range on which to learn lights
list IP address range on which to learn lights

Device(config-coap-proxy)# security dtls ipv4 1.1.0.0 255.255.0.0

```




---

**Note** For configuring **ipv4 / ipv6 / list**, the **id-trustpoint** and (optional) **verification-trustpoint**, should be pre-configured, else the system shows an error.

---

-----

This example shows how to configure a Trustpoint. This is a pre-requisite for COAP **security dtls** with **id trustpoint** configurations.

```

ip domain-name myDomain
crypto key generate rsa general-keys exportable label MyLabel modulus 2048

Device(config)# crypto pki trustpoint MY_TRUSTPOINT
Device(ca-trustpoint)# rsakeypair MyLabel 2048
Device(ca-trustpoint)# enrollment selfsigned
Device(ca-trustpoint)# exit

Device(config)# crypto pki enroll MY_TRUSTPOINT
% Include the router serial number in the subject name? [yes/no]: no
% Include an IP address in the subject name? [no]: no
Generate Self Signed Router Certificate? [yes/no]: yes

```

-----

This example shows how to configure COAP proxy on *ipv4 1.1.0.0 255.255.0.0* with **dtls verification trustpoint** (DTLS with certificates or verification trustpoints)

```

Device(config-coap-proxy)# security dtls ?
id-trustpoint DTLS RSA and X.509 Trustpoint Labels
ipv4 IP address range on which to learn lights
ipv6 IPv6 address range on which to learn lights
list IP address range on which to learn lights

Device(config-coap-proxy)# security dtls id-trustpoint ?
WORD Identity TrustPoint Label

Device(config-coap-proxy)# security dtls id-trustpoint RSA-TRUSTPOINT ?
verification-trustpoint Certificate Verification Label
<cr>

```

```
Device(config-coap-proxy)# security dtls id-trustpoint RSA-TRUSTPOINT verification-trustpoint
?
WORD Identity TrustPoint Label

Device(config-coap-proxy)# security dtls id-trustpoint RSA-TRUSTPOINT verification-trustpoint
CA-TRUSTPOINT ?
<Cr>
```

-----

This example shows how to configure Verification Trustpoint. This is a pre-requisite for COAP **security dtls** with **verification trustpoint** configurations.

```
Device(config)# crypto pki import CA-TRUSTPOINT pkcs12 flash:hostA.p12 password cisco123
% Importing pkcs12...
Source filename [hostA.p12]?
Reading file from flash:hostA.p12
CRYPTO_PKI: Imported PKCS12 file successfully.
```

-----

This example shows how to create a list named trial-list, to be used in the security [ none | dtls ] command options.

```
Device(config-coap-proxy)# list ipv4 trial_list
Device(config-coap-proxy-iplist)# 1.1.0.0 255.255.255.0
Device(config-coap-proxy-iplist)# 2.2.0.0 255.255.255.0
Device(config-coap-proxy-iplist)# 3.3.0.0 255.255.255.0
Device(config-coap-proxy-iplist)# exit
Device(config-coap-proxy)# security none list trial_list
```

-----

This example shows all the negation commands available in the coap-proxy sub mode.

```
Device(config-coap-proxy)# no ?
ip-list          Configure IP-List
max-endpoints    maximum number of endpoints supported
port-unsecure    Specify a port number to use
port-dtls        Specify a dtls-port number to use
resource-discovery Resource Discovery Server
security         CoAP Security features
```

-----

This example shows how you can configure multiple IPv4/IPv6 static-endpoints on the coap proxy.

```
Device(config)# coap endpoint ipv4 1.1.1.1
Device(config)# coap endpoint ipv4 2.1.1.1
Device(config)# coap endpoint ipv6 2001::1
```

-----

This example shows how you can display the COAP protocol details.

```
Device# show coap version

CoAP version 1.0.0
RFC 7252
```

-----

```
Device# show coap resources
```

```

Link format data =
</>
</1.1.1.6/cisco/context>
</1.1.1.6/cisco/actuator>
</1.1.1.6/cisco/sensor>
</1.1.1.6/cisco/lldp>
</1.1.1.5/cisco/context>
</1.1.1.5/cisco/actuator>
</1.1.1.5/cisco/sensor>
</1.1.1.5/cisco/lldp>
</cisco/flood>
</cisco/context>
</cisco/showtech>
</cisco/lldp>

```

```

-----
Device# show coap globals

```

```

Coap System Timer Values :
  Discovery   : 120 sec
  Cache Exp  : 5 sec
  Keep Alive  : 120 sec
  Client DB   : 60 sec
  Query Queue: 500 ms
  Ack delay   : 500 ms
  Timeout     : 5 sec

```

```

Max Endpoints      : 10
Resource Disc Mode : POST

```

```

-----
Device# show coap stats

```

```

Coap Stats :
Endpoints : 2
Requests : 20
Ext Queries : 0

```

```

-----
Device# show coap endpoints

```

```

List of all endpoints :

```

```

Code : D - Discovered , N - New

```

#	Status	Age(s)	LastWKC(s)	IP
1	D	10	94	1.1.1.6
2	D	6	34	1.1.1.5

```

Endpoints - Total : 2 Discovered : 2 New : 0

```

```

-----
Device# show coap dtls-endpoints

```

#	Index	State	String	State	Value	Port	IP
1	3	SSL	OK	3	48969	20.1.1.30	
2	2	SSL	OK	3	53430	20.1.1.31	
3	4	SSL	OK	3	54133	20.1.1.32	
4	7	SSL	OK	3	48236	20.1.1.33	

This example shows all options available to debug the COAP protocol.

```
Device# debug coap ?
all          Debug CoAP all
database     Debug CoAP Database
errors       Debug CoAP errors
events       Debug CoAP events
packet       Debug CoAP packet
trace        Debug CoAP Trace
warnings     Debug CoAP warnings
```

## Monitoring COAP Proxy Server

To display the COAP protocol details, use the commands in the following table:

**Table 24: Commands to Display to COAP specific data**

<b>show coap version</b>	Shows the IOS COAP version and the RFC information.
<b>show coap resources</b>	Shows the resources of the switch and those learnt by it.
<b>show coap endpoints</b>	Shows the endpoints which are discovered and learnt.
<b>show coap globals</b>	Shows the timer values and end point values.
<b>show coap stats</b>	Shows the message counts for endpoints, requests and external queries.
<b>show coap dtls-endpoints</b>	Shows the dtls endpoint status.

**Table 25: Commands to Clear COAP Commands**

<b>clear coap database</b>	Clears the COAP learnt on the switch, and the internal database of endpoint information.
----------------------------	--

To debug the COAP protocol, use the commands in the following table:

**Table 26: Commands to Debug COAP protocol**

<b>debug coap database</b>	Debugs the COAP database output.
<b>debug coap errors</b>	Debugs the COAP errors output.
<b>debug coap events</b>	Debugs the COAP events output.
<b>debug coap packets</b>	Debugs the COAP packets output.
<b>debug coap trace</b>	Debugs the COAP traces output.
<b>debug coap warnings</b>	Debugs the COAP warnings output.
<b>debug coap all</b>	Debugs all the COAP output.



---

**Note** If you wish to disable the debugs, prepend the command with a **no** keyword.

---

## Feature History for COAP

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Everest 16.5.1a	COAP	The COAP protocol is designed for use with constrained devices. COAP works in the same way on constrained devices as HTTP works on servers in accessing information.

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to [Cisco Feature Navigator](#).



## CHAPTER 16

# Configuring USB 3.0 SSD

- [Information about USB 3.0 SSD, on page 153](#)
- [How to Configure USB 3.0 SSD, on page 154](#)
- [Monitoring USB 3.0 SSD, on page 157](#)
- [Troubleshooting Tips, on page 158](#)
- [Configuration Examples for USB 3.0 SSD, on page 161](#)
- [Feature History for USB 3.0 SSD, on page 163](#)

## Information about USB 3.0 SSD

The following sections provide information about USB 3.0 SSD.

### USB 3.0 SSD

In Cisco IOS XE Fuji 16.9.1, support for USB 3.0 SSD is enabled on Cisco Catalyst 9300 Series Switches. USB 3.0 SSD provides extra 240 GB storage for application hosting. Applications can be hosted in Kernel Virtual Machines (KVM), Linux Containers (LXC), or Docker containers. The storage drive can also be used to save packet captures, trace logs generated by the operating system and third-party applications. USB 3.0 SSD can be used simultaneously as a general-purpose storage device and as an application-hosting device. You must use only Cisco USB drives; non-Cisco USB drives are not supported.



---

**Note** USB 3.0 SSD cannot be used to boot images, emergency install the images, or upgrade internal flash using (software maintenance update (SMU or **install** commands. Bootloader support for USB 3.0 SSD is not available.

---

USB 3.0 SSD is enabled with Self-Monitoring, Analysis and Reporting Technology (S.M.A.R.T) functionality for health monitoring of the drive. The purpose of S.M.A.R.T is to monitor the reliability of the drive and predict drive failures, and to carry out different types of drive self tests. SMART Disk Monitoring Daemon (smartd) is enabled immediately after the insertion of a USB 3.0 SSD and starts logging warnings and errors in the `/crashinfo/tracelogs/smart_errors.log`. These warnings and errors are also displayed on the console. On removing the USB 3.0 SSD, smartd stops running.

USB 3.0 SSD is supported as a field-replaceable unit (FRU) that offers flexible storage configurations. If SSD is used initially on a PC, the default partition on USB 3.0 SSD is created by the PC supporting all the file systems. If SSD is used initially on the switch, one partition of the drive is created to support EXT4 file system.

## File System on USB 3.0 SSD

USB 3.0 SSD is shipped as a raw device. When the device boots up, Cisco IOS software creates a partition with EXT4 as the default file system. However, the device supports all EXT-based file systems such as EXT2, EXT3, and EXT4. Non-EXT based file systems such as VFAT, NTFS, LVM, and so on are not supported.

The following file system operations are supported on the drive:

- Read
- Write
- Delete
- Copy
- Format

## Password Authentication on USB 3.0 SSD

To protect the drive from unauthorized access, you must enable security on USB 3.0 SSD by setting a user password. A USB 3.0 SSD supports the following security states:

- Security disabled: User password has not been configured on the drive. This is the out-of-box state which is the default for any new drive.
- Security enabled: User password has been configured on the drive.
- Locked: Security is enabled and the drive is inaccessible.
- Unlocked: Security is enabled or disabled, but the drive is accessible.

You can configure password authentication using the CLI as well as programmable NETCONF/YANG method.

## How to Configure USB 3.0 SSD

The following sections provide information about configuring USB 3.0 SSD:

### Formatting USB 3.0 SSD

Use the **format usbflash1: { ext2 | ext3 | ext4 | secure }** command to format the EXT file systems or the entire drive.

To format the USB 3.0 SSD drive in a device stack, use the **format usbflash1-switch\_num: { ext2 | ext3 | ext4 | secure }** command.

### Unmounting USB 3.0 SSD from a Switch or a Switch Stack

To safely remove the USB 3.0 SSD from a switch or a switch stack, use the **hw-module switch <switch\_num> usbflash1 unmount** command in privileged EXEC mode. This command unmounts the filesystem created

upon insertion, and notifies the system to complete pending read or write operations, if any, to safely remove the drive from the switch.

```
Device# hw-module switch 1 usbflash1 unmount
```

```
*Jan 5 22:21:32.723: %IOSXE-0-PLATFORM: Switch 1 R0/0: SSD_UNMOUNT_LOG: usbflash1:
has been unmounted. All the usbflash1 entries in IOS will now be cleared until the SSD
is plugged back into the switch.
```

```
*Jan 5 22:21:32.729: %IOSD_INFRA-6-IFS_DEVICE_OIR: Device usbflash1 removed
```

After you run this command, you will not be able to access the USB anymore. To use the USB again reinsert it into the switch.

If you run the **hw-module switch <switch\_num> usbflash1 unmount** command on a switch or switch stack without inserting the USB, the following error message is displayed.

```
Device# hw-module switch 1 usbflash1 unmount
```

```
*Jun 20 22:50:40.321:
ERROR: USB Not Present in this Slot 1
```

## Enabling Password Security on USB 3.0 SSD

The password authentication feature enables you to configure security on a USB 3.0 SSD in order to protect the drive from unauthorized access and associated risks. To enable security on a USB 3.0 SSD, follow these steps to set a password on the drive.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode.  Enter your password, if prompted.
<b>Step 2</b>	<b>hw-module switch switch-number usbflash1 security enable password usb-password</b>  <b>Example:</b> Device# <b>hw-module switch 1 usbflash1 security enable password 1234</b>	Configures a user-defined password on the USB 3.0 SSD.  <b>Note</b> Password security will take effect only after after Online Insertion and Removal (OIR) of the USB or a switch reload.

After Online Insertion and Removal (OIR) of the USB or a switch reload, the USB will be in *Enabled and Locked* state. To unlock and access the USB, you must configure the switch to use the USB 3.0 SSD password that you create in this task.

### What to do next

To configure the USB 3.0 SSD password on the switch, see [Configuring USB 3.0 SSD Password on a Switch, on page 156](#).

## Configuring USB 3.0 SSD Password on a Switch

To access a password protected USB 3.0 SSD using a switch, you must configure the same USB 3.0 SSD password on the switch. USB 3.0 SSD will be in locked state after a switch reset or OIR of the drive. To unlock and access the drive, the switch prompts you to enter the USB 3.0 SSD password saved on the switch. This procedure saves the password to the running configuration on the switch in type-6 encryption format.

Using the Encrypted Preshared Key feature, you can securely store plain text passwords in type-6 format in NVRAM using the command-line interface (CLI). Type-6 passwords are encrypted. Although the encrypted passwords can be seen or retrieved, it is difficult to decrypt them to find out the actual password.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode.  Enter your password, if prompted.
<b>Step 2</b>	<b>configure terminal</b>  <b>Example:</b> Device# <b>configure terminal</b>	Enters global configuration mode.
<b>Step 3</b>	(Optional) <b>key config-key password-encrypt password</b>  <b>Example:</b> Device(config)# <b>key config-key password-encrypt 123456789</b>	Configures the master key on the switch. The password configured using this command is the master encryption key that is used to encrypt all the other keys in the switch.  <b>Note</b> Skip this step if you have already configured the master key on the switch.
<b>Step 4</b>	[no] <b>hw-module switch switch-number usbflash1-password usb-password</b>  <b>Example:</b> Device(config)# <b>hw-module switch 1 usbflash1-password 1234</b>	<b>Note</b> Ensure the password matches the one that you have configured on the USB 3.0 SSD to enable security.  Encrypts the password internally using type-6 encryption.  Use the <b>no</b> form of the command to remove the USB 3.0 SSD password from the running configuration of the switch.
<b>Step 5</b>	<b>end</b>  <b>Example:</b> Device(config)# <b>end</b>	Exits global configuration mode, and returns to privileged EXEC mode.

## Unlocking USB 3.0 SSD

Follow these steps to unlock a USB 3.0 SSD:

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>hw-module switch <i>switch-number</i> usbflash1 security unlock password <i>usb-password</i></b> <b>Example:</b> Device# <b>hw-module switch 1 usbflash1 security unlock password 1234</b>	Unlocks the drive and makes the drive available for temporary access. Note that password security is still enabled on the drive and if you insert the drive on any other switch, the drive will be in locked state.

## Disabling Password Security on USB 3.0 SSD

Follow these steps to disable security or to change the password configured on a USB 3.0 SSD.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b> <b>Example:</b> Device> <b>enable</b>	Enables privileged EXEC mode. Enter your password, if prompted.
<b>Step 2</b>	<b>hw-module switch <i>switch-number</i> usbflash1 security disable password <i>usb-password</i></b> <b>Example:</b> Device# <b>hw-module switch 1 usbflash1 security disable password 1234</b>	Disables security on USB 3.0 SSD and makes the drive accessible. You do not have to reload the switch or perform OIR of the drive for the changes to take effect.  <b>Note</b> On a switch stack, enter the switch number of the switch on which you have inserted the USB 3.0 SSD.

## Monitoring USB 3.0 SSD

You can view the contents of the USB 3.0 SSD before working on its contents. For example, before copying a new configuration file, you might want to verify that the filesystem does not already contain a configuration file with the same name. To display information about files on a filesystem, use one of the privileged EXEC commands listed in the following table:

Table 27: Commands to Display Files on a Filesystem

Command Name	Description
<b>dir usbflash1:</b>	Displays the list of files on the USB flash filesystem on an active switch.  To access flash partitions of a standby switch or the device members in a stack, use <b>usbflash1-n</b> where <i>n</i> , is the standby switch number or the stack member number.
<b>dir usbflash1-switch_num:</b>	Displays the list of files on the filesystem in a stack setup.
<b>dir stby-usbflash1:</b>	Displays the list of files on the filesystem on the standby switch in a stack setup.
<b>show usbflash1: filesystem</b>	Displays more information about the filesystem.
<b>show inventory</b>	Displays the physical inventory information for the USB hardware.  After multiple switchovers, the <b>show inventory</b> command output might display the USB flash filesystem (usbflash1) for the active switch with the switch number.  <b>Note</b> The <b>show inventory</b> command displays "usbflash1" in the output only when the device is in "Disabled and Unlocked" state or "Enabled and Unlocked" state.
<b>more file-url</b>	Displays the logs with SMART errors and overall health of the drive.
<b>show hw-module usbflash1 security status</b>	Displays USB 3.0 SSD authentication status.

## Troubleshooting Tips

The following sections provide troubleshooting tips:

## Troubleshooting USB 3.0 SSD Insertion and Removal

Table 28: Errors and Troubleshooting

Error That You May Encounter	Troubleshooting
USB3.0 SSD not detected after insertion	<ul style="list-style-type: none"> <li>• Check if you are using a Cisco USB 3.0 SSD. If not, remove the drive from the device, and replace it with a Cisco USB 3.0 SSD.</li> <li>• If you are using a Cisco USB 3.0 SSD and the system is unable to detect the drive, remove and reinsert the USB 3.0 SSD. If it continues to fail, the USB might be defective.</li> </ul>
<p>Error messages displayed on the console after removing USB 3.0 SSD:</p> <pre>*Mar 20 00:48:16.353: %IOSXE-4-PLATFORM: Switch 1 R0/0: kernel: xhci_hcd 0000:00:14.0: Cannot set link state.  *Mar 20 00:48:16.353: %IOSXE-3-PLATFORM: Switch 1 R0/0: kernel: usb usb4-port1: cannot disable (err = -32)  *May 10 01:12:49.603: %IOSXE-3-PLATFORM: Switch 3 R0/0: kernel: JBD2: Error -5 detected when updating journal superblock for sdal-8.</pre>	<p>Remove the USB 3.0 SSD from the device after running the <b>unmount</b> command. For more information, see <a href="#">Unmounting USB 3.0 SSD from a Switch or a Switch Stack, on page 154</a>.</p>
<p>Error message displayed on the console on inserting a non-Cisco USB 3.0 SSD:</p> <pre>%IOSXEBOOT-4-SSD_MOUNT_LOG: (local/local): ***INFO: Not a CISCO SSD - Cannot be used***</pre>	<p>Remove the USB from the device, and replace it with a Cisco USB 3.0 SSD.</p>

## Troubleshooting Password Authentication

Table 29: Errors and Troubleshooting

Error That You May Encounter	Troubleshooting
USB3.0 SSD not detected after insertion	<p>Run the <b>show hw-module usbflash1 security status</b> command and check for USB Authentication Status fields in the output. If the USB Authentication Status field in the output displays Enabled and Locked, perform one of the following:</p> <ul style="list-style-type: none"> <li>• Unlock the drive temporarily using the <b>hw-module switch 1 switch-number usbflash1 security unlock password usb-password</b> command.</li> <li>• <a href="#">Configuring USB 3.0 SSD Password on a Switch, on page 156</a></li> <li>• Configure USB 3.0 SSD password on the switch. See .</li> </ul>
<p>USB 3.0 SSD password does not match the password saved in the running configuration of the switch. The switch displays the following error messages:</p> <pre>*Oct 19 19:32:04.094: %IOSD_INFRA-6-IFS_DEVICE_OIR: Device usbflash1 added  *Oct 19 19:32:04.138: Warning: Configured password on SWITCH does not match with that on DRIVE.  Please remove password from SWITCH first and then from DRIVE to re-configure.</pre>	<p>Perform the following:</p> <ul style="list-style-type: none"> <li>• Remove the password from the switch and reconfigure the switch to use the correct password. See <a href="#">Configuring USB 3.0 SSD Password on a Switch, on page 156</a>.</li> </ul>
<p>USB 3.0 SSD without a password inserted on a switch that has the drive password configured. An attempt to unlock the disk using the password configured on the switch fails and the switch displays the following messages:</p> <pre>*Dec 14 00:01:00.374: %IOSD_INFRA-6-IFS_DEVICE_OIR: Device usbflash1 added  *Dec 14 00:01:00.430: ERROR: No password configured on DRIVE. Remove password from SWITCH to re-configure.</pre>	<p>Perform the following steps:</p> <ol style="list-style-type: none"> <li>1. Enable security on the drive USB 3.0 SSD. See <a href="#">Enabling Password Security on USB 3.0 SSD, on page 155</a>.</li> <li>2. Reconfigure the password on the switch. See <a href="#">Configuring USB 3.0 SSD Password on a Switch, on page 156</a>.</li> </ol>

Error That You May Encounter	Troubleshooting
<p>USB 3.0 SSD configured with a password inserted on a switch that does not have the drive password configured. An attempt to unlock the disk fails and the switch displays the following messages:</p> <pre>*Oct 19 19:36:18.003: %IOSD_INFRA-6-IFS_DEVICE_OIR: Device usbflash1 added  *Oct 19 19:36:18.028: Warning: No password configured on SWITCH. Remove password from DRIVE to re-configure</pre>	<p>Do one of the following:</p> <ul style="list-style-type: none"> <li>• Disable the password configured on the drive. See <a href="#">Disabling Password Security on USB 3.0 SSD, on page 157</a>.</li> <li>• Configure password on the switch. See <a href="#">Configuring USB 3.0 SSD Password on a Switch, on page 156</a>.</li> </ul>
<p>A USB 3.0 SSD in Disabled and locked state indicates that the USB drive has become unusable because of corrupted hardware.</p>	<p>To unlock and enable the drive, contact TAC.</p>

## Configuration Examples for USB 3.0 SSD

The following sections provide configuration examples for USB 3.0 SSD:

### Example: Displaying USB 3.0 SSD Authentication Status

This example shows the USB 3.0 SSD authentication status on a switch stack with 4 switches.

```
Device# show hw-module usbflash1 security status
```

```
Device#   USB Authentication           Status
-----
1         USB Not Present                    USB 3.0 is not present
2         Disabled and Unlocked              Security is disabled & the drive in unlocked state
(Default state if USB is present)
3         Enabled and Locked                 Security Enabled and the drive in locked state
4         Enabled and Unlocked               Security Enabled and the drive in unlocked state
```

When the drive is in *Enabled and Unlocked* or *Disabled and Unlocked* state, you can format a drive and perform normal file system operations like read, write, delete, and copy.

### Examples: Verifying the Filesystem

The following example displays the output of the **dir usbflash1:/** command in privileged EXEC mode:

```
Device# dir usbflash1:
```

```
Directory of usbflash1:/
11 drwx          16384   Oct 9 2015 01:49:18 +00:00  lost+found
3145729 drwx           4096   Oct 9 2015 04:10:41 +00:00  test
118014062592 bytes total (111933120512 bytes free)
```

The following example displays the output of the **dir usbflash1:switch\_num:** command in a device stack:

```
Device# dir usbflash1-2:
Directory of usbflash1-2:/
```

```
11 drwx 16384 Jun 8 2018 21:35:39 +00:00 lost+found
118014083072 bytes total (111933390848 bytes free)
```

Alternately, you can use the **dir stby-usbflash1:** command to access the file system on a standby device:

```
Device# dir stby-usbflash1:
```

```
Directory of usbflash1-3:/
11 drwx      16384  May 16 2018 23:32:43 +00:00  lost+found
118014083072 bytes total (110358429696 bytes free)
```

To display the file system information for usbflash1, use the **show usbflash1: filesystem** command in privileged EXEC mode:

```
Device# show usbflash1: filesystem
```

```
Filesystem: usbflash1
Filesystem Path: /vol/usb1
Filesystem Type: ext4
```

## Examples: Verifying Physical Inventory Information

To display the physical inventory information for USB 3.0 SSD hardware, use the **show inventory** command:

```
Device# show inventory
```

```
NAME: "usbflash1", DESCR: "usbflash1"
PID: SSD-240G      , VID: STP21460FN9, SN: V01
```

The following is a sample output of the **show inventory** command in a device stack:

```
Device# show inventory
```

```
NAME: "usbflash1", DESCR: "usbflash1"
PID: SSD-240G      , VID: STP21460FN9, SN: V01
```

```
NAME: "usbflash1-3", DESCR: "usbflash1-3"
PID: SSD-240G      , VID: STP21310001, SN: V01
```

## Examples: Verifying the Health of the Drive

To check the overall health of the drive, use the **more flash:smart\_overall\_health.log** command in privileged EXEC mode:

```
Device# more flash:smart_overall_health.log
```

```
=== START OF READ SMART DATA SECTION ===
SMART overall-health self-assessment test result: PASSED
```

To check the health error logs, use the **more crashinfo:tracelogs/smart\_errors.log** command in privileged EXEC mode:

```
Device# more crashinfo:tracelogs/smart_errors.log
```

```
%IOSXEBOOT-4-SMART_LOG: (local/local): Mon Jan 4 00:13:10 Universal 2016 INFO: Starting
SMART daemon
```



**Note** The system might display warnings in the `smart_errors.log`. You can ignore these if the overall health self assessment in the `flash/smart_overall_health.log` displays `PASSED`.

## Feature History for USB 3.0 SSD


This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Fuji 16.9.1	USB 3.0 SSD	USB 3.0 SSD provides extra 120 GB storage to be used as a general-purpose storage device and as an application-hosting device.
Cisco IOS XE Fuji 16.9.6	USB 3.0 SSD storage	USB 3.0 SSD storage capacity increased to 240 GB in Cisco IOS XE Fuji 16.9.6 and later Cisco IOS XE Fuji 16.9 releases.
Cisco IOS XE Gibraltar 16.10.1	Password authentication	Password authentication feature enables you set a password on the USB 3.0 SSD device in order to protect the drive from unauthorized access and associated risks.
Cisco IOS XE Gibraltar 16.12.4	USB 3.0 SSD storage	USB 3.0 SSD storage capacity increased to 240 GB in Cisco IOS XE Gibraltar 16.12.4 and later Cisco IOS XE Gibraltar 16.12 releases.
Cisco IOS XE Amsterdam 17.3.1	USB 3.0 SSD storage	USB 3.0 SSD storage capacity increased to 240 GB in Cisco IOS XE Amsterdam 17.3.1 and all later releases.

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to [Cisco Feature Navigator](#).





## CHAPTER 17

# Configuring an External USB Bluetooth Dongle

- [Restrictions for Configuring an External USB Bluetooth Dongle](#) , on page 165
- [Information About External USB Bluetooth Dongle](#), on page 165
- [How to Configure an External USB Bluetooth Dongle on a Switch](#), on page 166
- [Verifying Bluetooth Settings on a Device](#), on page 167
- [Feature History for Configuring an External Bluetooth Dongle](#), on page 167

## Restrictions for Configuring an External USB Bluetooth Dongle

- Only Bluetooth version 4.0 is supported.
- External USB Bluetooth dongle is supported only on the Cisco Catalyst 9000 Series Switches that are configured within the IPv4 address range.
- In stacking mode, the external USB Bluetooth dongle needs to be enabled on an active switch.
- After a Stateful Switchover (SSO), the external USB Bluetooth dongle should be enabled on the new active switch interface.
- External USB Bluetooth dongle is not supported with the following configurations:
  - Quality of Service (QoS)
  - Access Control List (ACL)

## Information About External USB Bluetooth Dongle

The connected external USB Bluetooth dongle acts as a Bluetooth host for external devices and serves as a management port on the switch. You can pair an external USB Bluetooth dongle with your Bluetooth-enabled external devices such as smart phone, laptop, or tablet.

External USB Bluetooth dongle is supported on switches that are configured both in standalone mode or in stacking mode.

## Supported External USB Bluetooth Dongle

The following external USB Bluetooth dongles are supported:

- BTD-400 Bluetooth 4.0 Adapter by Kinivo
- Bluetooth 4.0 USB Adapter by Asus
- Mini Bluetooth Wireless USB 4.0 Dongle Adapter by Adnet
- Bluetooth 4.0 USB Adapter by Insignia

## How to Configure an External USB Bluetooth Dongle on a Switch

To configure an external USB Bluetooth dongle on a switch, perform this procedure:

### Procedure

**Step 1** Connect an external USB Bluetooth dongle to the USB Type A port on the switch.

#### Note

You can connect the external USB Bluetooth dongle either before powering up the device or when the device is running.

**Step 2** On your switch, enter the global configuration mode and verify that the external USB Bluetooth dongle is connected to the switch:

```
Device> enable
Device# show platform hardware bluetooth

Controller:0:1a:7d:da:71:13
Type:Primary
Bus:USB
State:DOWN
Name:HCI Version:
```

**Step 3** Enable Bluetooth interface using the **enable** command in interface configuration mode:

```
Device# configure terminal
Device(config)# interface bluetooth 0/4
Device(config-if)# enable
```

**Step 4** Enter the **no shutdown** command to restart the Bluetooth interface automatically after a device reboot:

```
Device(config-if)# no shutdown
```

**Step 5** Configure the pairing pin using the **bluetooth pin** *pin* command:

```
Device(config-if)# bluetooth pin 1111
```

or

```
Device(config-if)# exit
Device(config)# bluetooth pin 1111
```

#### Note

Cisco recommends using **bluetooth pin** command in global configuration mode.

**Step 6** Turn on the Bluetooth settings on your external device. On your external device, select the Bluetooth-enabled switch based on the hostname.

**Step 7** Enable the network settings on your external device to allow it to connect to the internet.

## Verifying Bluetooth Settings on a Device

This topic lists the commands used to monitor Bluetooth settings on a device.

Use the following commands in privileged EXEC mode to monitor Bluetooth settings.

**Table 30: Commands to Monitor Bluetooth Settings on a Device**

Command	Purpose
<code>show ip interface bluetooth 0/4</code>	Displays the usability status of a Bluetooth interface.
<code>show platform hardware bluetooth</code>	Displays information about a Bluetooth interface.
<code>show running   include pin</code>	Displays the current Bluetooth pin.

## Feature History for Configuring an External Bluetooth Dongle

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Gibraltar 16.12.1	Configuring an External Bluetooth Dongle	External USB Bluetooth dongle acts as a Bluetooth host for external devices and serves as a management port on the switch.

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to <https://cfng.cisco.com/>.





# CHAPTER 18

## Troubleshooting Interface and Hardware Components

---

- [Overview](#), on page 169
- [Support Articles](#), on page 169
- [Feedback Request \(Reference\)](#), on page 170
- [Disclaimer and Caution \(Reference\)](#), on page 170

### Overview

This chapter provides links to documents authored by Cisco subject matter experts (SMEs). They aim to help you resolve technical issues without requiring a support ticket. If these documents are unable to resolve your issue, we recommend visiting the applicable [Cisco Community](#). There is a wealth of information and advice available from fellow Cisco customers who may have experienced this issue already and provided a solution. If you are not able to find a resolution on the Community, it may be best that you raise a support ticket at [Cisco Support](#). In cases where a support ticket has to be raised, these documents provide guidance about the data that should be collected and added to the support ticket. Specify the support document you referred, and TAC can create an improvement request with the document owner.

### Support Articles

The documents in this section were created using specific software and hardware listed in the Components Used section of each article. However, this does not mean that they are limited to what is listed in Components Used, and generally remain relevant for later versions of software and hardware. Note that there could be some changes in the software or hardware that can cause commands to stop working, the syntax to change, or GUIs and CLIs to look different from one release to another.

The following are the support articles associated with this technology:

Document	Description
<a href="#">Configure and Troubleshoot StackPower and XPS 2200 on Catalyst 9300 Switches</a>	This document describes the configuration of Cisco StackPower and eXpandable Power System (XPS) 2200 and how to troubleshoot related issues.

Document	Description
<a href="#">Troubleshoot PoE on Catalyst 9000 Switches</a>	This document describes the troubleshooting workflow for PoE (Power over Ethernet) on Catalyst 9000 PoE-capable switching platforms.
<a href="#">Troubleshoot MTU on Catalyst 9000 Series Switches</a>	This document describes how to understand and troubleshoot MTU (Maximum Transmission Unit) on Catalyst 9000 series switches.
<a href="#">Understand why FCS Errors, Input Errors, or Packet Loss Can Occur when Connected to Multigigabit Ethernet Ports</a>	This document describes why you encounter frame check sequence (FCS) errors, input errors, or packet loss with devices that connect to Multigigabit Ethernet (mGig) ports on Catalyst 9000 series switches due to interpacket gap (IPG) or interframe gap (IFG) tolerance.
<a href="#">Troubleshoot Port Flaps on Catalyst 9000 Series Switches</a>	This document describes how to identify, collect useful logs, and troubleshoot problems that can occur with Port Flaps on Catalyst 9000 switches.

## Feedback Request (Reference)

Your input helps. A key aspect to improving these support documents is customer feedback. Note that these documents are owned and maintained by multiple teams within Cisco. If you find an issue specific to the document (unclear, confusing, information missing, etc):

- Provide feedback using the **Feedback** button located at the right panel of the corresponding article. The document owner will be notified, and will either update the article, or flag it for removal.
- Include information regarding the section, area, or issue you had with the document and what could be improved. Provide as much detail as possible.

## Disclaimer and Caution (Reference)

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, ensure that you understand the potential impact of any command.