



Interface and Hardware Commands

- [debug ilpower](#), on page 3
- [debug interface](#), on page 4
- [debug lldp packets](#), on page 5
- [debug platform poe](#), on page 6
- [duplex](#), on page 7
- [errdisable detect cause](#), on page 9
- [errdisable recovery cause](#), on page 11
- [errdisable recovery interval](#), on page 13
- [hw-module subslot mode](#), on page 14
- [interface](#), on page 16
- [interface range](#), on page 18
- [lldp \(interface configuration\)](#), on page 19
- [logging event power-inline-status](#), on page 21
- [mode \(power-stack configuration\)](#), on page 22
- [network-policy](#), on page 24
- [network-policy profile \(global configuration\)](#), on page 25
- [power efficient-ethernet auto](#), on page 26
- [power-priority](#) , on page 27
- [power inline](#), on page 29
- [power inline police](#), on page 32
- [power supply](#), on page 34
- [show eee](#), on page 36
- [show env](#), on page 39
- [show errdisable detect](#), on page 41
- [show errdisable recovery](#), on page 42
- [show hw-module subslot mode](#), on page 43
- [show id prom fan-tray](#), on page 44
- [show ip interface](#), on page 45
- [show interfaces](#), on page 50
- [show interfaces counters](#), on page 53
- [show interfaces switchport](#), on page 55
- [show interfaces transceiver](#), on page 57
- [show inventory](#), on page 59

- [show memory platform](#), on page 62
- [show module](#), on page 65
- [show mgmt-infra trace messages ilpower](#), on page 66
- [show mgmt-infra trace messages ilpower-ha](#), on page 68
- [show mgmt-infra trace messages platform-mgr-poe](#), on page 69
- [show network-policy profile](#), on page 70
- [show platform hardware fed active forward](#), on page 71
- [show platform hardware iomd lc-portmap brief](#), on page 73
- [show platform hardware iomd portgroups](#), on page 74
- [show platform resources](#), on page 76
- [show platform software ilpower](#), on page 77
- [show platform software process list](#), on page 79
- [show platform software process slot switch](#), on page 81
- [show platform software status control-processor](#), on page 83
- [show processes cpu platform monitor](#), on page 86
- [show processes memory](#), on page 88
- [show processes memory platform](#), on page 91
- [show system mtu](#), on page 94
- [show tech-support](#) , on page 95
- [speed](#), on page 97
- [switchport block](#), on page 99
- [system mtu](#), on page 100
- [voice-signaling vlan \(network-policy configuration\)](#), on page 101
- [voice vlan \(network-policy configuration\)](#), on page 103

debug ilpower

To enable debugging of the power controller and Power over Ethernet (PoE) system, use the **debug ilpower** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug ilpower **cdp** | **event** | **ha** | **port** | **powerman** | **registries** | **scp** | **sense**
no debug ilpower **cdp** | **event** | **ha** | **port** | **powerman** | **registries** | **scp** | **sense**

Syntax Description

cdp	Displays PoE Cisco Discovery Protocol (CDP) debug messages.
event	Displays PoE event debug messages.
ha	Displays PoE high-availability messages.
port	Displays PoE port manager debug messages.
powerman	Displays PoE power management debug messages.
registries	Displays PoE registries debug messages.
scp	Displays PoE SCP debug messages.
sense	Displays PoE sense debug messages.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

This command is supported only on PoE-capable switches.

When you enable debugging on a switch stack, it is enabled only on the active switch. To enable debugging on a member switch, you can start a session from the active switch by using the **session** *switch-number* EXEC command. Then enter the **debug** command at the command-line prompt of the member switch. You also can use the **remote command** *stack-member-number* *LINE* EXEC command on the active switch to enable debugging on a member switch without first starting a session.

debug interface

To enable debugging of interface-related activities, use the **debug interface** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug interface interface-id | counters exceptions | protocol memory | null interface-number |
port-channel port-channel-number | states | vlan vlan-id
no debug interface interface-id | counters exceptions | protocol memory | null interface-number |
port-channel port-channel-number | states | vlan vlan-id
```

Syntax Description

<i>interface-id</i>	ID of the physical interface. Displays debug messages for the specified physical port, identified by type switch number/module number/port, for example, gigabitethernet 1/0/2.
null <i>interface-number</i>	Displays debug messages for null interfaces. The interface number is always 0 .
port-channel <i>port-channel-number</i>	Displays debug messages for the specified EtherChannel port-channel interface. The <i>port-channel-number</i> range is 1 to 48.
vlan <i>vlan-id</i>	Displays debug messages for the specified VLAN. The vlan range is 1 to 4094.
counters	Displays counters debugging information.
exceptions	Displays debug messages when a recoverable exceptional condition occurs during the computation of the interface packet and data rate statistics.
protocol memory	Displays debug messages for memory operations of protocol counters.
states	Displays intermediary debug messages when an interface's state transitions.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

If you do not specify a keyword, all debug messages appear.

The **undebg interface** command is the same as the **no debug interface** command.

When you enable debugging on a switch stack, it is enabled only on the active switch. To enable debugging on a member switch, you can start a session from the active switch by using the **session** *switch-number* EXEC command. Then enter the **debug** command at the command-line prompt of the member switch. You also can use the **remote command** *stack-member-number* *LINE* EXEC command on the active switch to enable debugging on a member switch without first starting a session.

debug lldp packets

To enable debugging of Link Layer Discovery Protocol (LLDP) packets, use the **debug lldp packets** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug lldp packets
no debug lldp packets

Syntax Description This command has no arguments or keywords.

Command Default Debugging is disabled.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines The **undebg lldp packets** command is the same as the **no debug lldp packets** command.

When you enable debugging on a switch stack, it is enabled only on the . To enable debugging on a stack member, you can start a session from the by using the **session switch-number** EXEC command.

debug platform poe

To enable debugging of a Power over Ethernet (PoE) port, use the **debug platform poe** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug platform poe [error | info] [switch switch-number]  
no debug platform poe [error | info] [switch switch-number]
```

Syntax Description

error	(Optional) Displays PoE-related error debug messages.
info	(Optional) Displays PoE-related information debug messages.
switch <i>switch-number</i>	(Optional) Specifies the stack member. This keyword is supported only on stacking-capable switches.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

The **undebug platform poe** command is the same as the **no debug platform poe** command.

duplex

To specify the duplex mode of operation for a port, use the **duplex** command in interface configuration mode. To return to the default value, use the **no** form of this command.

duplex auto | full | half
no duplex auto | full | half

Syntax Description

auto Enables automatic duplex configuration. The port automatically detects whether it should run in full- or half-duplex mode, depending on the attached device mode.

full Enables full-duplex mode.

half Enables half-duplex mode (only for interfaces operating at 10 or 100 Mbps). You cannot configure half-duplex mode for interfaces operating at 1000 or 10,000 Mbps.

Command Default

For Gigabit Ethernet ports, the default is **auto**.

Command Modes

Interface configuration (config-if)

Command History

Release

Cisco IOS XE Everest 16.6.1

Modification

This command was introduced.

Usage Guidelines

For Gigabit Ethernet ports, setting the port to **auto** has the same effect as specifying **full** if the attached device does not autonegotiate the duplex parameter.

Duplex options are not supported on the 1000BASE-*x* or 10GBASE-*x* (where *x* is -BX, -CWDM, -LX, -SX, or -ZX) small form-factor pluggable (SFP) modules.



Note

Half-duplex mode is supported on Gigabit Ethernet interfaces if the duplex mode is **auto** and the connected device is operating at half duplex. However, you cannot configure these interfaces to operate in half-duplex mode.

Certain ports can be configured to be either full duplex or half duplex. How this command is applied depends on the device to which the switch is attached.

If both ends of the line support autonegotiation, we highly recommend using the default autonegotiation settings. If one interface supports autonegotiation and the other end does not, configure duplex and speed on both interfaces, and use the **auto** setting on the supported side.

If the speed is set to **auto**, the switch negotiates with the device at the other end of the link for the speed setting and then forces the speed setting to the negotiated value. The duplex setting remains as configured on each end of the link, which could result in a duplex setting mismatch.

You can configure the duplex setting when the speed is set to **auto**.

**Caution**

Changing the interface speed and duplex mode configuration might shut down and reenables the interface during the reconfiguration.

You can verify your setting by entering the **show interfaces** privileged EXEC command.

Examples

This example shows how to configure an interface for full-duplex operation:

```
Device> enable
Device# configure terminal
Device(config)# interface gigabitethernet 1/0/1
Device(config-if)# duplex full
```


errdisable detect cause

To enable error-disable detection for a specific cause or for all causes, use the **errdisable detect cause** command in global configuration mode. To disable the error-disable detection feature, use the **no** form of this command.

```
errdisable detect cause all | arp-inspection | bpduguard shutdown vlan | dhcp-rate-limit | dtp-flap
| gbic-invalid | inline-power | link-flap | loopback | pagp-flap | pppoe-ia-rate-limit | psp shutdown
vlan | security-violation shutdown vlan | sfp-config-mismatch
no errdisable detect cause all | arp-inspection | bpduguard shutdown vlan | dhcp-rate-limit | dtp-flap
| gbic-invalid | inline-power | link-flap | loopback | pagp-flap | pppoe-ia-rate-limit | psp shutdown
vlan | security-violation shutdown vlan | sfp-config-mismatch
```

Syntax	Description
all	Enables error detection for all error-disabled causes.
arp-inspection	Enables error detection for dynamic Address Resolution Protocol (ARP) inspection.
bpduguard shutdown vlan	Enables per-VLAN error-disable for BPDU guard.
dhcp-rate-limit	Enables error detection for DHCP snooping.
dtp-flap	Enables error detection for the Dynamic Trunking Protocol (DTP) flapping.
gbic-invalid	Enables error detection for an invalid Gigabit Interface Converter (GBIC) module. Note This error refers to an invalid small form-factor pluggable (SFP) module.
inline-power	Enables error detection for the Power over Ethernet (PoE) error-disabled cause. Note This keyword is supported only on switches with PoE ports.
link-flap	Enables error detection for link-state flapping.
loopback	Enables error detection for detected loopbacks.
pagp-flap	Enables error detection for the Port Aggregation Protocol (PAgP) flap error-disabled cause.
pppoe-ia-rate-limit	Enables error detection for the PPPoE Intermediate Agent rate-limit error-disabled cause.
psp shutdown vlan	Enables error detection for protocol storm protection (PSP).
security-violation shutdown vlan	Enables voice aware 802.1x security.
sfp-config-mismatch	Enables error detection on an SFP configuration mismatch.

Command Default Detection is enabled for all causes. All causes, except per-VLAN error disabling, are configured to shut down the entire port.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines A cause (such as a link-flap or dhcp-rate-limit) is the reason for the error-disabled state. When a cause is detected on an interface, the interface is placed in an error-disabled state, an operational state that is similar to a link-down state.

When a port is error-disabled, it is effectively shut down, and no traffic is sent or received on the port. For the bridge protocol data unit (BPDU) guard, voice-aware 802.1x security, and port-security features, you can configure the switch to shut down only the offending VLAN on the port when a violation occurs, instead of shutting down the entire port.

If you set a recovery mechanism for the cause by entering the **errdisable recovery** global configuration command, the interface is brought out of the error-disabled state and allowed to retry the operation when all causes have timed out. If you do not set a recovery mechanism, you must enter the **shutdown** and then the **no shutdown** commands to manually recover an interface from the error-disabled state.

For protocol storm protection, excess packets are dropped for a maximum of two virtual ports. Virtual port error disabling using the **psp** keyword is not supported for EtherChannel and Flexlink interfaces.

To verify your settings, enter the **show errdisable detect** privileged EXEC command.

This example shows how to enable error-disabled detection for the link-flap error-disabled cause:

```
Device(config)# errdisable detect cause link-flap
```

This command shows how to globally configure BPDU guard for a per-VLAN error-disabled state:

```
Device(config)# errdisable detect cause bpduguard shutdown vlan
```

This command shows how to globally configure voice-aware 802.1x security for a per-VLAN error-disabled state:

```
Device(config)# errdisable detect cause security-violation shutdown vlan
```

You can verify your setting by entering the **show errdisable detect** privileged EXEC command.

errdisable recovery cause

To enable the error-disabled mechanism to recover from a specific cause, use the **errdisable recovery cause** command in global configuration mode. To return to the default setting, use the **no** form of this command.

```
errdisable recovery cause all | arp-inspection | bpduguard | channel-misconfig | dhcp-rate-limit |
dtp-flap | gbic-invalid | inline-power | link-flap | loopback | mac-limit | pagp-flap | port-mode-failure |
pppoe-ia-rate-limit | psecure-violation | psp | security-violation | sfp-config-mismatch | storm-control |
udld
```

```
no errdisable recovery cause all | arp-inspection | bpduguard | channel-misconfig | dhcp-rate-limit |
dtp-flap | gbic-invalid | inline-power | link-flap | loopback | mac-limit | pagp-flap | port-mode-failure |
pppoe-ia-rate-limit | psecure-violation | psp | security-violation | sfp-config-mismatch | storm-control |
udld
```

Syntax Description		
all		Enables the timer to recover from all error-disabled causes.
arp-inspection		Enables the timer to recover from the Address Resolution Protocol (ARP) inspection error-disabled state.
bpduguard		Enables the timer to recover from the bridge protocol data unit (BPDU) guard error-disabled state.
channel-misconfig		Enables the timer to recover from the EtherChannel misconfiguration error-disabled state.
dhcp-rate-limit		Enables the timer to recover from the DHCP snooping error-disabled state.
dtp-flap		Enables the timer to recover from the Dynamic Trunking Protocol (DTP) flap error-disabled state.
gbic-invalid		Enables the timer to recover from an invalid Gigabit Interface Converter (GBIC) module error-disabled state. Note This error refers to an invalid small form-factor pluggable (SFP) error-disabled state.
inline-power		Enables the timer to recover from the Power over Ethernet (PoE) error-disabled state. This keyword is supported only on switches with PoE ports.
link-flap		Enables the timer to recover from the link-flap error-disabled state.
loopback		Enables the timer to recover from a loopback error-disabled state.
mac-limit		Enables the timer to recover from the mac limit error-disabled state.
pagp-flap		Enables the timer to recover from the Port Aggregation Protocol (PAgP)-flap error-disabled state.

port-mode-failure	Enables the timer to recover from the port mode change failure error-disabled state.
pppoe-ia-rate-limit	Enables the timer to recover from the PPPoE IA rate limit error-disabled state.
psecure-violation	Enables the timer to recover from a port security violation disable state.
psp	Enables the timer to recover from the protocol storm protection (PSP) error-disabled state.
security-violation	Enables the timer to recover from an IEEE 802.1x-violation disabled state.
sfp-config-mismatch	Enables error detection on an SFP configuration mismatch.
storm-control	Enables the timer to recover from a storm control error.
udld	Enables the timer to recover from the UniDirectional Link Detection (UDLD) error-disabled state.

Command Default Recovery is disabled for all causes.

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

A cause (such as all or BPDU guard) is defined as the reason that the error-disabled state occurred. When a cause is detected on an interface, the interface is placed in the error-disabled state, an operational state similar to link-down state.

When a port is error-disabled, it is effectively shut down, and no traffic is sent or received on the port. For the BPDU guard and port-security features, you can configure the switch to shut down only the offending VLAN on the port when a violation occurs, instead of shutting down the entire port.

If you do not enable the recovery for the cause, the interface stays in the error-disabled state until you enter the **shutdown** and the **no shutdown** interface configuration commands. If you enable the recovery for a cause, the interface is brought out of the error-disabled state and allowed to retry the operation again when all the causes have timed out.

Otherwise, you must enter the **shutdown** and then the **no shutdown** commands to manually recover an interface from the error-disabled state.

You can verify your settings by entering the **show errdisable recovery** privileged EXEC command.

Examples

This example shows how to enable the recovery timer for the BPDU guard error-disabled cause:

```
Device(config)# errdisable recovery cause bpduguard
```

errdisable recovery interval

To specify the time to recover from an error-disabled state, use the **errdisable recovery interval** command in global configuration mode. To return to the default setting, use the **no** form of this command.

errdisable recovery interval *timer-interval*
no errdisable recovery interval *timer-interval*

Syntax Description	<i>timer-interval</i> Time to recover from the error-disabled state. The range is 30 to 86400 seconds. The same interval is applied to all causes. The default interval is 300 seconds.
---------------------------	---

Command Default	The default recovery interval is 300 seconds.
------------------------	---

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines	The error-disabled recovery timer is initialized at a random differential from the configured interval value. The difference between the actual timeout value and the configured value can be up to 15 percent of the configured interval.
-------------------------	--

You can verify your settings by entering the **show errdisable recovery** privileged EXEC command.

Examples

This example shows how to set the timer to 500 seconds:

```
Device(config)# errdisable recovery interval 500
```

hw-module subslot mode

To control the subscriber line interface (SLI) traffic rate of a device, use the **hw-module subslot mode** command in global configuration mode. To return to the default mode, use the **no** form of this command.

Cisco IOS XE Gibraltar 16.10.x and Earlier Releases

```
hw-module subslot slot/subslot mode [dynamic | performance]
no hw-module subslot slot/subslot mode
```

Cisco IOS XE Gibraltar 16.11.1 and Later Releases

```
hw-module subslot slot/subslot mode [dynamic | performance | static]
no hw-module subslot slot/subslot mode
```

Syntax Description	
<i>slot</i>	Slot number. The range is from 0 to 10.
<i>subslot</i>	Subslot number. The range is from 0 to 0.
dynamic	(Optional) Sets the line card operation modes to dynamic mode.
performance	(Optional) Sets the line card operation modes to performance mode.
static	(Optional) Sets the line card operation modes to static mode.

Command Default	
	<ul style="list-style-type: none"> • Until Cisco IOS XE Gibraltar 16.10.x release, the default mode is static. • Starting in Cisco IOS XE Gibraltar 16.11.1 release, the default mode is dynamic.

Command Modes	
	Global Configuration (config)

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines	
	<ul style="list-style-type: none"> • Performance mode: Allows limited number of front panel interfaces to operate at full 64-byte 10G rate, while keeping the other interfaces in disabled state. For 7 slot chassis, 8 10G/MGig line card front panel interfaces get activated and provides full 64-byte 10G rate. For 10 slot chassis, 5 front panel interfaces get activated at full 64-byte 10G rate. The other line card interfaces are disabled and do not link up. Disabled front panel interfaces has amber LED on and the show interfaces command displays hardware in disabled state. • Dynamic mode: Monitors the system software on how many SLI links are active based on the front panel port link status, and dynamically configures SLI link 64-byte packet max traffic bandwidth. For 7 slot chassis, when the number of active SLI links exceed 8, system software limits SLI 64-byte packet traffic rate down to 7.5G for all 12 SLIs. For 10 slot chassis, when the number of active SLI links exceed 5, SLI 64-byte packet traffic rate is limited to 6.25G for all 8 SLIs. Otherwise, system software allows full 10G traffic with 64-byte packets on the active SLIs.

- **Static mode:** SLI traffic rate is fixed to 7.5G for both 7 slot chassis and 10 slot chassis.

Examples

The following example shows how to set the line card mode to performance:

```
Device> enable
Device# configure terminal
Device(config)# hw-module subslot 1/0 mode performance
```

Related Commands

Command	Description
show hw-module subslot mode	Displays the line card mode of the platform.
show platform hardware iomd portgroups	Displays the port grouping information of the platform.
show platform hardware iomd lc-portmap brief	Displays the line card port map information of the platform.

interface

To configure an interface, use the **interface** command.

interface **Auto-Template** *Auto-Template interface-number* | **GigabitEthernet** *Gigabit Ethernet interface number* | **Group VI** *Group VI interface number* **Internal Interface** *Internal Interface number* **Loopback** *Loopback interface number* **Null** *Null interface number* **Port-channel** *interface number* **Port-channel** *interface number* **TenGigabitEthernet** *interface number* **Tunnel** *interface number* **Vlan** *interface number*

Syntax Description		
Auto-Template <i>Auto-template interface-number</i>		Enables you to configure a auto-template interface. The range is 1 to 999.
GigabitEthernet <i>Gigabit Ethernet interface number</i>		Enables you to configure a Gigabit Ethernet IEEE 802.3z interface. The range is from 0 to 9.
Group VI <i>Group VI interface number</i>		Enables you to configure a Group VI interface. The range is from 0 to 9.
Internal Interface <i>Internal Interface</i>		Enables you to configure an internal interface.
Loopback <i>Loopback Interface number</i>		Enables you to configure a loopback interface. The range is from 0 to 2147483647.
Null <i>Null interface number</i>		Enables you to configure a null interface. The default value is 0.
Port-channel <i>interface number</i>		Enables you to configure a port-channel interface. The range is from 1 to 128.
TenGigabitEthernet <i>interface number</i>		Enables you to configure a 10-Gigabit Ethernet interface. The range is from 0 to 9.
Tunnel <i>interface number</i>		Enables you to configure a tunnel interface. The range is from 0 to 2147483647.
Vlan <i>interface number</i>		Enables you to configure a switch VLAN. The range is from 0 to 4098.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines You can not use the "no" form of this command.

The following example shows how to configure a tunnel interface:


```
Device# interface Tunnel 15
```

interface range

To configure an interface range, use the **interface range** command.

interface range **Gigabit Ethernet** *interface-number* | **Loopback** *interface-number* | **Port Channel** *interface-number* | **TenGigabit Ethernet** *interface-number* **Tunnel** *interface-number* **Vlan** *interface-number* **Macro** *WORD*

Syntax Description	Description
GigabitEthernet <i>interface-number</i>	Configures the Gigabit Ethernet IEEE 802.3z interface. Values range from 1 to 9.
Loopback <i>interface-number</i>	Configures the loopback interface. Values range from 0 to 2147483647.
Port-Channel <i>interface-number</i>	Configures 10-Gigabit Ethernet channel of interfaces. Values range from 1 to 128.
TenGigabit Ethernet <i>interface-number</i>	Configures 10-Gigabit Ethernet interfaces. Values range from 0 to 9.
Tunnel <i>interface-number</i>	Configures the tunnel interface. Values range from 0 to 2147483647.
VLAN <i>interface-number</i>	Configures the switch VLAN interfaces. Values range from 1 to 4095.
Macro <i>WORD</i>	Configures the keywords to interfaces. Support up to 32 characters.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

This example shows how you can configure interface range:

```
Device(config)# interface range vlan 1
```

lldp (interface configuration)

To enable Link Layer Discovery Protocol (LLDP) on an interface, use the **lldp** command in interface configuration mode. To disable LLDP on an interface, use the **no** form of this command.

lldp med-tlv-select *tlv* | **receive** | **tlv-select** **power-management** | **transmit**
no lldp med-tlv-select *tlv* | **receive** | **tlv-select** **power-management** | **transmit**

Syntax Description		
med-tlv-select		Selects an LLDP Media Endpoint Discovery (MED) time-length-value (TLV) element to send.
<i>tlv</i>		String that identifies the TLV element. Valid values are the following: <ul style="list-style-type: none"> • inventory-management— LLDP MED Inventory Management TLV. • location— LLDP MED Location TLV. • network-policy— LLDP MED Network Policy TLV. • power-management— LLDP MED Power Management TLV.
receive		Enables the interface to receive LLDP transmissions.
tlv-select		Selects the LLDP TLVs to send.
power-management		Sends the LLDP Power Management TLV.
transmit		Enables LLDP transmission on the interface.

Command Default LLDP is disabled.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines This command is supported on 802.1 media types.

If the interface is configured as a tunnel port, LLDP is automatically disabled.

The following example shows how to disable LLDP transmission on an interface:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# no lldp transmit
```

The following example shows how to enable LLDP transmission on an interface:

```
Device(config)# interface gigabitethernet1/0/1
```

```
Device(config-if)# lldp transmit
```

logging event power-inline-status

To enable the logging of Power over Ethernet (PoE) events, use the **logging event power-inline-status** command in interface configuration mode. To disable the logging of PoE status events, use the **no** form of this command.

logging event power-inline-status
no logging event power-inline-status

Syntax Description This command has no arguments or keywords.

Command Default Logging of PoE events is enabled.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines The **no** form of this command does not disable PoE error events.

Examples This example shows how to enable logging of PoE events on a port:

```
Device(config-if)# interface gigabitethernet1/0/1
Device(config-if)# logging event power-inline-status
Device(config-if)#
```

mode (power-stack configuration)

To configure power stack mode for the power stack, use the **mode** command in power-stack configuration mode. To return to the default settings, use the **no** form of the command.

mode power-shared | redundant [strict]
no mode

Syntax Description		
	power-shared	Sets the power stack to operate in power-shared mode. This is the default.
	redundant	Sets the power stack to operate in redundant mode. The largest power supply is removed from the power pool to be used as backup power in case one of the other power supplies fails.
	strict	(Optional) Configures the power stack mode to run a strict power budget. The stack power needs cannot exceed the available power.

Command Default The default modes are **power-shared** and nonstrict.

Command Modes Power-stack configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines This command is available only on switch stacks running the IP Base or IP Services feature set.

To access power-stack configuration mode, enter the **stack-power stack** *power stack name* global configuration command.

Entering the **no mode** command sets the switch to the defaults of **power-shared** and non-strict mode.



Note For stack power, available power is the total power available for PoE from all power supplies in the power stack, available power is the power allocated to all powered devices connected to PoE ports in the stack, and consumed power is the actual power consumed by the powered devices.

In **power-shared** mode, all of the input power can be used for loads, and the total available power appears as one large power supply. The power budget includes all power from all supplies. No power is set aside for power supply failures. If a power supply fails, load shedding (shutting down of powered devices or switches) might occur.

In **redundant** mode, the largest power supply is removed from the power pool to use as backup power in case one of the other power supplies fails. The available power budget is the total power minus the largest power supply. This reduces the available power in the pool for switches and powered devices, but in case of a failure or an extreme power load, there is less chance of having to shut down switches or powered devices.

In **strict** mode, when a power supply fails and the available power drops below the budgeted power, the system balances the budget through load shedding of powered devices, even if the actual power is less than the available power. In nonstrict mode, the power stack can run in an over-allocated state and is stable as long as

the actual power does not exceed the available power. In this mode, a powered device drawing more than normal power could cause the power stack to start shedding loads. This is normally not a problem because most devices do not run at full power. The chances of multiple powered devices in the stack requiring maximum power at the same time is small.

In both strict and nonstrict modes, power is denied when there is no power available in the power budget.

This is an example of setting the power stack mode for the stack named power1 to power-shared with strict power budgeting. All power in the stack is shared, but when the total available power is allotted, no more devices are allowed power.

```
Device(config)# stack-power stack power1  
Device(config-stackpower)# mode power-shared strict  
Device(config-stackpower)# exit
```

This is an example of setting the power stack mode for the stack named power2 to redundant. The largest power supply in the stack is removed from the power pool to provide redundancy in case one of the other supplies fails.

```
Device(config)# stack-power stack power2  
Device(config-stackpower)# mode redundant  
Device(config-stackpower)# exit
```

network-policy

To apply a network-policy profile to an interface, use the **network-policy** command in interface configuration mode. To remove the policy, use the **no** form of this command.

network-policy *profile-number*
no network-policy

Syntax Description

profile-number The network-policy profile number to apply to the interface.

Command Default

No network-policy profiles are applied.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

Use the **network-policy** *profile number* interface configuration command to apply a profile to an interface.

You cannot apply the **switchport voice vlan** command on an interface if you first configure a network-policy profile on it. However, if **switchport voice vlan** *vlan-id* is already configured on the interface, you can apply a network-policy profile on the interface. The interface then has the voice or voice-signaling VLAN network-policy profile applied.

This example shows how to apply network-policy profile 60 to an interface:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# network-policy 60
```


network-policy profile (global configuration)

To create a network-policy profile and to enter network-policy configuration mode, use the **network-policy profile** command in global configuration mode. To delete the policy and to return to global configuration mode, use the **no** form of this command.

network-policy profile *profile-number*
no network-policy profile *profile-number*

Syntax Description

profile-number Network-policy profile number. The range is 1 to 4294967295.

Command Default

No network-policy profiles are defined.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

Use the **network-policy profile** global configuration command to create a profile and to enter network-policy profile configuration mode.

To return to privileged EXEC mode from the network-policy profile configuration mode, enter the **exit** command.

When you are in network-policy profile configuration mode, you can create the profile for voice and voice signaling by specifying the values for VLAN, class of service (CoS), differentiated services code point (DSCP), and tagging mode.

These profile attributes are contained in the Link Layer Discovery Protocol for Media Endpoint Devices (LLDP-MED) network-policy time-length-value (TLV).

This example shows how to create network-policy profile 60:

```
Device(config)# network-policy profile 60
Device(config-network-policy)#
```

power efficient-ethernet auto

To enable Energy Efficient Ethernet (EEE) for an interface, use the **power efficient-ethernet auto** command in interface configuration mode. To disable EEE on an interface, use the **no** form of this command.

power efficient-ethernet auto
no power efficient-ethernet auto

Syntax Description This command has no arguments or keywords.

Command Default EEE is disabled.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines You can enable EEE on devices that support low power idle (LPI) mode. Such devices can save power by entering LPI mode during periods of low utilization. In LPI mode, systems on both ends of the link can save power by shutting down certain services. EEE provides the protocol needed to transition into and out of LPI mode in a way that is transparent to upper layer protocols and applications.

The **power efficient-ethernet auto** command is available only if the interface is EEE capable. To check if an interface is EEE capable, use the **show eee capabilities EXEC** command.

When EEE is enabled, the device advertises and autonegotiates EEE to its link partner. To view the current EEE status for an interface, use the **show eee status EXEC** command.

This command does not require a license.

This example shows how to enable EEE for an interface:

```
Device(config-if)# power efficient-ethernet auto
Device(config-if)#
```

This example shows how to disable EEE for an interface:

```
Device(config-if)# no power efficient-ethernet auto
Device(config-if)#
```

power-priority

To configure Cisco StackPower power-priority values for a switch in a power stack and for its high-priority and low-priority PoE ports, use the **power-priority** command in switch stack-power configuration mode. To return to the default setting, use the **no** form of the command.

power-priority high *value* | **low** *value* | **switch** *value*
no power-priority high | **low** | **switch**

Syntax Description	high <i>value</i>	low <i>value</i>	switch <i>value</i>
	Sets the power priority for the ports configured as high-priority ports. The range is 1 to 27, with 1 as the highest priority. The high value must be lower than the value set for the low-priority ports and higher than the value set for the switch.	Sets the power priority for the ports configured as low-priority ports. The range is 1 to 27. The low value must be higher than the value set for the high-priority ports and the value set for the switch.	Sets the power priority for the switch. The range is 1 to 27. The switch value must be lower than the values set for the low and high-priority ports.

Command Default If no values are configured, the power stack randomly determines a default priority. The default ranges are 1 to 9 for switches, 10 to 18 for high-priority ports, 19 to 27 for low-priority ports. On non-PoE switches, the high and low values (for port priority) have no effect.

Command Modes Switch stack-power configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines To access switch stack-power configuration mode, enter the **stack-power switch** *switch-number* global configuration command.

Cisco StackPower power-priority values determine the order for shutting down switches and ports when power is lost and load shedding must occur. Priority values are from 1 to 27; the highest numbers are shut down first.

We recommend that you configure different priority values for each switch and for its high priority ports and low priority ports to limit the number of devices shut down at one time during a loss of power. If you try to configure the same priority value on different switches in a power stack, the configuration is allowed, but you receive a warning message.



Note This command is available only on switch stacks running the IP Base or IP Services feature set.

Examples

This is an example of setting the power priority for switch 1 in power stack a to 7, for the high-priority ports to 11, and for the low-priority ports to 20.

```
Device(config)# stack-power switch 1  
Device(config-switch-stackpower)# stack-id power_stack_a  
Device(config-switch-stackpower)# power-priority high 11  
Device(config-switch-stackpower)# power-priority low 20  
Device(config-switch-stackpower)# power-priority switch 7  
Device(config-switch-stackpower)# exit
```

power inline

To configure the power management mode on Power over Ethernet (PoE) ports, use the **power inline** command in interface configuration mode. To return to the default settings, use the **no** form of this command.

power inline auto [**max** *max-wattage*] | **never** | **port priority high** | **low** | **static** [**max** *max-wattage*]
no power inline auto | **never** | **port priority high** | **low** | **static** [**max** *max-wattage*]

Syntax Description		
auto		Enables powered-device detection. If enough power is available, automatically allocates power to the PoE port after device detection. Allocation is first-come, first-serve.
max <i>max-wattage</i>		(Optional) Limits the power allowed on the port. The range is 4000 to 30000 mW. If no value is specified, the maximum is allowed.
never		Disables device detection, and disables power to the port.
port		Configures the power priority of the port. The default priority is low.
priority { high low }		Sets the power priority of the port. In case of a power supply failure, ports configured as low priority are turned off first and ports configured as high priority are turned off last. The default priority is low.
static		Enables powered-device detection. Pre-allocates (reserves) power for a port before the switch discovers the powered device. This action guarantees that the device connected to the interface receives enough power.

Command Default The default is **auto** (enabled).
The maximum wattage is 30,000 mW.
The default port priority is low.

Command Default Interface configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

This command is supported only on PoE-capable ports. If you enter this command on a port that does not support PoE, this error message appears:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# power inline auto
                        ^
% Invalid input detected at '^' marker.
```

In a switch stack, this command is supported on all ports in the stack that support PoE.

Use the **max max-wattage** option to disallow higher-power powered devices. With this configuration, when the powered device sends Cisco Discovery Protocol (CDP) messages requesting more power than the maximum wattage, the switch removes power from the port. If the powered-device IEEE class maximum is greater than the maximum wattage, the switch does not power the device. The power is reclaimed into the global power budget.

**Note**

The switch never powers any class 0 or class 3 device if the **power inline max max-wattage** command is configured for less than 30 W.

If the switch denies power to a powered device (the powered device requests more power through CDP messages or if the IEEE class maximum is greater than the maximum wattage), the PoE port is in a power-deny state. The switch generates a system message, and the Oper column in the **show power inline** privileged EXEC command output shows *power-deny*.

Use the **power inline static max max-wattage** command to give a port high priority. The switch allocates PoE to a port configured in static mode before allocating power to a port configured in auto mode. The switch reserves power for the static port when it is configured rather than upon device discovery. The switch reserves the power on a static port even when there is no connected device and whether or not the port is in a shutdown or in a no shutdown state. The switch allocates the configured maximum wattage to the port, and the amount is never adjusted through the IEEE class or by CDP messages from the powered device. Because power is pre-allocated, any powered device that uses less than or equal to the maximum wattage is guaranteed power when it is connected to a static port. However, if the powered device IEEE class is greater than the maximum wattage, the switch does not supply power to it. If the switch learns through CDP messages that the powered device needs more than the maximum wattage, the powered device is shut down.

If the switch cannot pre-allocate power when a port is in static mode (for example, because the entire power budget is already allocated to other auto or static ports), this message appears: Command rejected: power inline static: pwr not available. The port configuration remains unchanged.

When you configure a port by using the **power inline auto** or the **power inline static** interface configuration command, the port autonegotiates by using the configured speed and duplex settings. This is necessary to determine the power requirements of the connected device (whether or not it is a powered device). After the power requirements have been determined, the switch hardcodes the interface by using the configured speed and duplex settings without resetting the interface.

When you configure a port by using the **power inline never** command, the port reverts to the configured speed and duplex settings.

If a port has a Cisco powered device connected to it, you should not use the **power inline never** command to configure the port. A false link-up can occur, placing the port in an error-disabled state.

Use the **power inline port priority {high | low}** command to configure the power priority of a PoE port. Powered devices connected to ports with low port priority are shut down first in case of a power shortage.

You can verify your settings by entering the **show power inline EXEC** command.

Examples

This example shows how to enable detection of a powered device and to automatically power a PoE port on a switch:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# power inline auto
```

This example shows how to configure a PoE port on a switch to allow a class 1 or a class 2 powered device:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# power inline auto max 7000
```

This example shows how to disable powered-device detection and to not power a PoE port on a switch:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# power inline never
```

This example shows how to set the priority of a port to high, so that it would be one of the last ports to be shut down in case of power supply failure:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# power inline port priority high
```

power inline police

To enable policing of real-time power consumption on a powered device, use the **power inline police** command in interface configuration mode. To disable this feature, use the **no** form of this command

power inline police [**action errdisable** | **log**]
no power inline police

Syntax Description

action errdisable	(Optional) Configures the device to turn off power to the port if the real-time power consumption exceeds the maximum power allocation on the port. This is the default action.
action log	(Optional) Configures the device to generate a syslog message while still providing power to a connected device if the real-time power consumption exceeds the maximum power allocation on the port.

Command Default

Policing of the real-time power consumption of the powered device is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

This command is supported only on the LAN Base image.

This command is supported only on Power over Ethernet (PoE)-capable ports. If you enter this command on a device or port that does not support PoE, an error message appears.

In a switch stack, this command is supported on all switches or ports in the stack that support PoE and real-time power-consumption monitoring.

When policing of the real-time power consumption is enabled, the device takes action when a powered device consumes more power than the allocated maximum amount.

When PoE is enabled, the device senses the real-time power consumption of the powered device. This feature is called *power monitoring* or *power sensing*. The device also polices the power usage with the *power policing* feature.

When power policing is enabled, the device uses one of the these values as the cutoff power on the PoE port in this order:

1. The user-defined power level that limits the power allowed on the port when you enter the **power inline auto max** *max-wattage* or the **power inline static max** *max-wattage* interface configuration command
2. The device automatically sets the power usage of the device by using CDP power negotiation or by the IEEE classification and LLDP power negotiation.

If you do not manually configure the cutoff-power value, the device automatically determines it by using CDP power negotiation or the device IEEE classification and LLDP power negotiation. If CDP or LLDP are not enabled, the default value of 30 W is applied. However without CDP or LLDP, the device does not allow devices to consume more than 15.4 W of power because values from 15400 to 30000 mW are only allocated based on CDP or LLDP requests. If a powered device consumes more than 15.4 W without CDP or LLDP

negotiation, the device might be in violation of the maximum current *I_{max}* limitation and might experience an *I_{cut}* fault for drawing more current than the maximum. The port remains in the fault state for a time before attempting to power on again. If the port continuously draws more than 15.4 W, the cycle repeats.

When a powered device connected to a PoE+ port restarts and sends a CDP or LLDP packet with a power TLV, the device locks to the power-negotiation protocol of that first packet and does not respond to power requests from the other protocol. For example, if the device is locked to CDP, it does not provide power to devices that send LLDP requests. If CDP is disabled after the device has locked on it, the device does not respond to LLDP power requests and can no longer power on any accessories. In this case, you should restart the powered device.

If power policing is enabled, the device polices power usage by comparing the real-time power consumption to the maximum power allocated on the PoE port. If the device uses more than the maximum power allocation (or *cutoff power*) on the port, the device either turns power off to the port, or the device generates a syslog message and updates the LEDs (the port LEDs are blinking amber) while still providing power to the device.

- To configure the device to turn off power to the port and put the port in the error-disabled state, use the **power inline police** interface configuration command.
- To configure the device to generate a syslog message while still providing power to the device, use the **power inline police action log** command.

If you do not enter the **action log** keywords, the default action is to shut down the port, turn off power to it, and put the port in the PoE error-disabled state. To configure the PoE port to automatically recover from the error-disabled state, use the **errdisable detect cause inline-power** global configuration command to enable error-disabled detection for the PoE cause and the **errdisable recovery cause inline-power interval interval** global configuration command to enable the recovery timer for the PoE error-disabled cause.



Caution

If policing is disabled, no action occurs when the powered device consumes more than the maximum power allocation on the port, which could adversely affect the device.

You can verify your settings by entering the **show power inline police** privileged EXEC command.

Examples

This example shows how to enable policing of the power consumption and configuring the device to generate a syslog message on the PoE port on a device:

```
Device(config)# interface gigabitethernet1/0/2
Device(config-if)# power inline police action log
```

power supply

To configure and manage the internal power supplies on a switch, use the **power supply** command in privileged EXEC mode.

power supply *stack-member-number* **slot A | B** **off | on**

Syntax Description		
<i>stack-member-number</i>		Stack member number for which to configure the internal power supplies. The range is 1 to 9, depending on the number of switches in the stack. This parameter is available only on stacking-capable switches.
slot		Selects the switch power supply to set.
A		Selects the power supply in slot A.
B		Selects the power supply in slot B. Note Power supply slot B is the closest slot to the outer edge of the switch.
off		Sets the switch power supply to off.
on		Sets the switch power supply to on.

Command Default The switch power supply is on.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines The **power supply** command applies to a switch or to a switch stack where all switches are the same platform.

In a switch stack with the same platform switches, you must specify the stack member before entering the **slot {A | B} off** or **on** keywords.

To return to the default setting, use the **power supply stack-member-number on** command.

You can verify your settings by entering the **show env power** privileged EXEC command.

Examples

This example shows how to set the power supply in slot A to off:

```
Device> power supply 2 slot A off
Disabling Power supply A may result in a power loss to PoE devices and/or switches ...
Continue? (yes/[no]): yes
Device
Jun 10 04:52:54.389: %PLATFORM_ENV-6-FRU_PS_OIR: FRU Power Supply 1 powered off
Jun 10 04:52:56.717: %PLATFORM_ENV-1-FAN_NOT_PRESENT: Fan is not present
```

This example shows how to set the power supply in slot A to on:

```
Device> power supply 1 slot B on
Jun 10 04:54:39.600: %PLATFORM_ENV-6-FRU_PS_OIR: FRU Power Supply 1 powered on
```

This example shows the output of the show env power command:

```
Device> show env power
SW  PID                Serial#      Status      Sys Pwr  PoE Pwr  Watts
--  -----
1A  PWR-1RUC2-640WAC    DCB1705B05B OK          Good     Good     250/390
1B  Not Present
```

show eee

To display Energy Efficient Ethernet (EEE) information for an interface, use the **show eee** command in EXEC mode.

Syntax Description	capabilities	Displays EEE capabilities for the specified interface.
	status	Displays EEE status information for the specified interface.
	interface <i>interface-id</i>	Specifies the interface for which to display EEE capabilities or status information.
Command Default	None	
Command Modes	User EXEC	
	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

You can enable EEE on devices that support low power idle (LPI) mode. Such devices can save power by entering LPI mode during periods of low power utilization. In LPI mode, systems on both ends of the link can save power by shutting down certain services. EEE provides the protocol needed to transition into and out of LPI mode in a way that is transparent to upper layer protocols and applications.

To check if an interface is EEE capable, use the **show eee capabilities** command. You can enable EEE on an interface that is EEE capable by using the **power efficient-ethernet auto** interface configuration command.

To view the EEE status, LPI status, and wake error count information for an interface, use the **show eee status** command.

This is an example of output from the **show eee capabilities** command on an interface where EEE is enabled:

```
Device# show eee capabilities interface gigabitethernet1/0/1
Gi1/0/1
    EEE(efficient-ethernet):  yes (100-Tx and 1000T auto)
    Link Partner              :  yes (100-Tx and 1000T auto)
```

This is an example of output from the **show eee capabilities** command on an interface where EEE is not enabled:

```
Device# show eee capabilities interface gigabitethernet2/0/1
Gi2/0/1
    EEE(efficient-ethernet):  not enabled
    Link Partner              :  not enabled
```

This is an example of output from the **show eee status** command on an interface where EEE is enabled and operational. The table that follows describes the fields in the display.

```
Device# show eee status interface gigabitethernet1/0/4
Gi1/0/4 is up
  EEE(efficient-ethernet): Operational
  Rx LPI Status           : Received
  Tx LPI Status           : Received
```

This is an example of output from the **show eee status** command on an interface where EEE operational and the ports are in low power save mode:

```
Device# show eee status interface gigabitethernet1/0/3
Gi1/0/3 is up
  EEE(efficient-ethernet): Operational
  Rx LPI Status           : Low Power
  Tx LPI Status           : Low Power
  Wake Error Count       : 0
```

This is an example of output from the **show eee status** command on an interface where EEE is not enabled because a remote link partner is incompatible with EEE:

```
Device# show eee status interface gigabitethernet1/0/3
Gi1/0/3 is down
  EEE(efficient-ethernet): Disagreed
  Rx LPI Status           : None
  Tx LPI Status           : None
  Wake Error Count       : 0
```

Table 1: show eee status Field Descriptions

Field	Description
EEE (efficient-ethernet)	<p>The EEE status for the interface. This field can have any of the following values:</p> <ul style="list-style-type: none"> • N/A—The port is not capable of EEE. • Disabled—The port EEE is disabled. • Disagreed—The port EEE is not set because a remote link partner might be incompatible with EEE; either it is not EEE capable, or its EEE setting is incompatible. • Operational—The port EEE is enabled and operating. <p>If the interface speed is configured as 10 Mbps, EEE is disabled internally. When the interface speed moves back to auto, 100 Mbps or 1000 Mbps, EEE becomes active again.</p>

Field	Description
Rx/Tx LPI Status	<p>The Low Power Idle (LPI) status for the link partner. These fields can have any of the following values:</p> <ul style="list-style-type: none"> • N/A—The port is not capable of EEE. • Interrupted—The link partner is in the process of moving to low power mode. • Low Power—The link partner is in low power mode. • None— EEE is disabled or not capable at the link partner side. • Received—The link partner is in low power mode and there is traffic activity. <p>If an interface is configured as half-duplex, the LPI status is None, which means the interface cannot be in low power mode until it is configured as full-duplex.</p>
Wake Error Count	<p>The number of PHY wake-up faults that have occurred. A wake-up fault can occur when EEE is enabled and the connection to the link partner is broken.</p> <p>This information is useful for PHY debugging.</p>

show env

To display fan, temperature, and power information, use the **show env** command in EXEC mode.

```
show env all | fan | power [all | switch [stack-member-number]] | stack [stack-member-number] |
temperature [status]
```

Syntax Description	
all	Displays the fan and temperature environmental status and the status of the internal power supplies.
fan	Displays the switch fan status.
power	Displays the internal power status of the active switch.
all	(Optional) Displays the status of all the internal power supplies in a standalone switch when the command is entered on the switch, or in all the stack members when the command is entered on the active switch.
switch	(Optional) Displays the status of the internal power supplies for each switch in the stack or for the specified switch. This keyword is available only on stacking-capable switches.
<i>stack-member-number</i>	(Optional) Number of the stack member for which to display the status of the internal power supplies or the environmental status.
stack	Displays all environmental status for each switch in the stack or for the specified switch. This keyword is available only on stacking-capable switches.
temperature	Displays the switch temperature status.
status	(Optional) Displays the switch internal temperature (not the external temperature) and the threshold values.

Command Default None

Command Modes User EXEC

Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines Use the **show env** EXEC command to display the information for the switch being accessed—a standalone switch or the active switch. Use this command with the **stack** and **switch** keywords to display all information for the stack or for the specified stack member.

If you enter the **show env temperature status** command, the command output shows the switch temperature state and the threshold level.

You can also use the **show env temperature** command to display the switch temperature status. The command output shows the green and yellow states as *OK* and the red state as *FAULTY*. If you enter the **show env all** command, the command output is the same as the **show env temperature status** command output.

Examples

This is an example of output from the **show env all** command:

This is an example of output from the **show env fan** command:

This is an example of output from the **show env power all** command on the active switch:

This is an example of output from the **show env stack** command on the active switch:

This example shows how to display the temperature value, state, and the threshold values on a standalone switch. The table describes the temperature states in the command output.

Table 2: States in the show env temperature status Command Output

State	Description
Green	The switch temperature is in the <i>normal</i> operating range.
Yellow	The temperature is in the <i>warning</i> range. You should check the external temperature around the switch.
Red	The temperature is in the <i>critical</i> range. The switch might not run properly if the temperature is in this range.

show errdisable detect

To display error-disabled detection status, use the **show errdisable detect** command in EXEC mode.

show errdisable detect

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines A gbic-invalid error reason refers to an invalid small form-factor pluggable (SFP) module.

The error-disable reasons in the command output are listed in alphabetical order. The mode column shows how error-disable is configured for each feature.

You can configure error-disabled detection in these modes:

- port mode—The entire physical port is error-disabled if a violation occurs.
- vlan mode—The VLAN is error-disabled if a violation occurs.
- port/vlan mode—The entire physical port is error-disabled on some ports and is per-VLAN error-disabled on other ports.

show errdisable recovery

To display the error-disabled recovery timer information, use the **show errdisable recovery** command in EXEC mode.

show errdisable recovery

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines A gbic-invalid error-disable reason refers to an invalid small form-factor pluggable (SFP) module interface.



Note Though visible in the output, the unicast-flood field is not valid.

This is an example of output from the **show errdisable recovery** command:

show hw-module subslot mode

To display the line card mode of the platform, use the **show hw-module subslot mode** command in privileged EXEC mode.

show hw-module subslot *slot/subslot* mode

Syntax Description	<i>slot</i> Slot number. The range is from 0 to 10.
	<i>subslot</i> Subslot number. The range is from 0 to 0.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Examples

The following is sample output from the **show hw-module subslot mode** command:

```
Device# show hw-module subslot 1/0 mode
subslot [1/0] mode: dynamic
```

show id prom fan-tray

To display the serial number for the fan-tray component and the chassis, use the **show id prom fan-tray** command in privileged EXEC mode.

```
showid promfan-tray
```

Command Modes	Privileged EXEC (#)
---------------	---------------------

Command History	Release	Modification
-----------------	---------	--------------

Cisco IOS XE Everest 16.6.1	This command was introduced.
-----------------------------	------------------------------

The following is sample output from the **show id prom fan-tray** command:

```
Device#show id prom fan tray
Fan Tray Idprom:

Controller Type           : 3196
Hardware Revision        : 0.5
Top Assy. Revision       : 28
Deviation Number         : 0
PCB Serial Number        : FXS203603M6
RMA Test History         : 00
RMA Number               : 0-0-0-0
RMA History              : 00
CLEI Code                : 0
ECI Number               : 0
Product Identifier (PID) : C9407-FAN
Version Identifier (VID) : V00
Manufacturing Test Data  : 00 00 00 00 00 00 00 00
Field Diagnostics Data   : 00 00 00 00 00 00 00 00
Environment Monitor Data : 03 00 00 00 15 E1 5E 00
                          A9
Environment Monitor Data : 00 06 00 FA
```

show ip interface

To display the usability status of interfaces configured for IP, use the **show ip interface** command in privileged EXEC mode.

show ip interface [*type number*] [**brief**]

Syntax Description	<i>type</i>	(Optional) Interface type.
	<i>number</i>	(Optional) Interface number.
	brief	(Optional) Displays a summary of the usability status information for each interface.
Command Default	The full usability status is displayed for all interfaces configured for IP.	
Command Modes	Privileged EXEC (#)	
Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

The Cisco IOS software automatically enters a directly connected route in the routing table if the interface is usable (which means that it can send and receive packets). If an interface is not usable, the directly connected routing entry is removed from the routing table. Removing the entry lets the software use dynamic routing protocols to determine backup routes to the network, if any.

If the interface can provide two-way communication, the line protocol is marked "up." If the interface hardware is usable, the interface is marked "up."

If you specify an optional interface type, information for that specific interface is displayed. If you specify no optional arguments, information on all the interfaces is displayed.

When an asynchronous interface is encapsulated with PPP or Serial Line Internet Protocol (SLIP), IP fast switching is enabled. A **show ip interface** command on an asynchronous interface encapsulated with PPP or SLIP displays a message indicating that IP fast switching is enabled.

You can use the **show ip interface brief** command to display a summary of the device interfaces. This command displays the IP address, the interface status, and other information.

The **show ip interface brief** command does not display any information related to Unicast RPF.

Examples

The following example shows interface information on Gigabit Ethernet interface 1/0/1:

```
Device# show ip interface gigabitethernet 1/0/1

GigabitEthernet1/0/1 is up, line protocol is up
  Internet address is 10.1.1.1/16
  Broadcast address is 255.255.255.255
  Address determined by setup command
  MTU is 1500 bytes
  Helper address is not set
  Directed broadcast forwarding is disabled
```

```

Outgoing access list is not set
Inbound access list is not set
Proxy ARP is enabled
Local Proxy ARP is disabled
Security level is default
Split horizon is enabled
ICMP redirects are always sent
ICMP unreachable are always sent
ICMP mask replies are never sent
IP fast switching is enabled
IP fast switching on the same interface is disabled
IP Flow switching is disabled
IP CEF switching is enabled
IP Feature Fast switching turbo vector
IP VPN Flow CEF switching turbo vector
IP multicast fast switching is enabled
IP multicast distributed fast switching is disabled
IP route-cache flags are Fast, CEF
Router Discovery is disabled
IP output packet accounting is disabled
IP access violation accounting is disabled
TCP/IP header compression is disabled
RTP/IP header compression is disabled
Policy routing is enabled, using route map PBR
Network address translation is disabled
BGP Policy Mapping is disabled
IP Multi-Processor Forwarding is enabled
  IP Input features, "PBR",
    are not supported by MPF and are IGNORED
  IP Output features, "NetFlow",
    are not supported by MPF and are IGNORED

```

The following example shows how to display the usability status for a specific VLAN:

```

Device# show ip interface vlan 1

Vlan1 is up, line protocol is up
  Internet address is 10.0.0.4/24
  Broadcast address is 255.255.255.255
Address determined by non-volatile memory
MTU is 1500 bytes
Helper address is not set
Directed broadcast forwarding is disabled
Outgoing access list is not set
Inbound access list is not set
Proxy ARP is enabled
Local Proxy ARP is disabled
Security level is default
Split horizon is enabled
ICMP redirects are always sent
ICMP unreachable are always sent
ICMP mask replies are never sent
IP fast switching is enabled
IP fast switching on the same interface is disabled
IP Flow switching is disabled
IP CEF switching is enabled
IP Fast switching turbo vector
IP Normal CEF switching turbo vector
IP multicast fast switching is enabled
IP multicast distributed fast switching is disabled
IP route-cache flags are Fast, CEF
Router Discovery is disabled
IP output packet accounting is disabled

```

```

IP access violation accounting is disabled
TCP/IP header compression is disabled
RTP/IP header compression is disabled
Probe proxy name replies are disabled
Policy routing is disabled
Network address translation is disabled
WCCP Redirect outbound is disabled
WCCP Redirect inbound is disabled
WCCP Redirect exclude is disabled
BGP Policy Mapping is disabled
Sampled Netflow is disabled
IP multicast multilayer switching is disabled
Netflow Data Export (hardware) is enabled

```

The table below describes the significant fields shown in the display.

Table 3: show ip interface Field Descriptions

Field	Description
Broadcast address is	Broadcast address.
Peer address is	Peer address.
MTU is	MTU value set on the interface, in bytes.
Helper address	Helper address, if one is set.
Directed broadcast forwarding	Shows whether directed broadcast forwarding is enabled.
Outgoing access list	Shows whether the interface has an outgoing access list set.
Inbound access list	Shows whether the interface has an incoming access list set.
Proxy ARP	Shows whether Proxy Address Resolution Protocol (ARP) is enabled for the interface.
Security level	IP Security Option (IPSO) security level set for this interface.
Split horizon	Shows whether split horizon is enabled.
ICMP redirects	Shows whether redirect messages will be sent on this interface.
ICMP unreachable	Shows whether unreachable messages will be sent on this interface.
ICMP mask replies	Shows whether mask replies will be sent on this interface.
IP fast switching	Shows whether fast switching is enabled for this interface. It is generally enabled on serial interfaces, such as this one.
IP Flow switching	Shows whether Flow switching is enabled for this interface.
IP CEF switching	Shows whether Cisco Express Forwarding switching is enabled for the interface.
IP multicast fast switching	Shows whether multicast fast switching is enabled for the interface.

Field	Description
IP route-cache flags are Fast	Shows whether NetFlow is enabled on an interface. Displays "Flow init" to specify that NetFlow is enabled on the interface. Displays "Ingress Flow" to specify that NetFlow is enabled on a subinterface using the ip flow ingress command. Shows "Flow" to specify that NetFlow is enabled on a main interface using the ip route-cache flow command.
Router Discovery	Shows whether the discovery process is enabled for this interface. It is generally disabled on serial interfaces.
IP output packet accounting	Shows whether IP accounting is enabled for this interface and what the threshold (maximum number of entries) is.
TCP/IP header compression	Shows whether compression is enabled.
WCCP Redirect outbound is disabled	Shows the status of whether packets received on an interface are redirected to a cache engine. Displays "enabled" or "disabled."
WCCP Redirect exclude is disabled	Shows the status of whether packets targeted for an interface will be excluded from being redirected to a cache engine. Displays "enabled" or "disabled."
Netflow Data Export (hardware) is enabled	NetFlow Data Expert (NDE) hardware flow status on the interface.

The following example shows how to display a summary of the usability status information for each interface:

```
Device# show ip interface brief
```

```
Interface          IP-Address      OK? Method Status          Protocol
Vlan1              unassigned     YES NVRAM  administratively down  down
GigabitEthernet0/0 unassigned     YES NVRAM  down            down
GigabitEthernet1/0/1 unassigned     YES NVRAM  down            down
GigabitEthernet1/0/2 unassigned     YES unset   down            down
GigabitEthernet1/0/3 unassigned     YES unset   down            down
GigabitEthernet1/0/4 unassigned     YES unset   down            down
GigabitEthernet1/0/5 unassigned     YES unset   down            down
GigabitEthernet1/0/6 unassigned     YES unset   down            down
GigabitEthernet1/0/7 unassigned     YES unset   down            down
```

<output truncated>

Table 4: show ip interface brief Field Descriptions

Field	Description
Interface	Type of interface.
IP-Address	IP address assigned to the interface.
OK?	"Yes" means that the IP Address is valid. "No" means that the IP Address is not valid.

Field	Description
Method	<p>The Method field has the following possible values:</p> <ul style="list-style-type: none"> • RARP or SLARP: Reverse Address Resolution Protocol (RARP) or Serial Line Address Resolution Protocol (SLARP) request. • BOOTP: Bootstrap protocol. • TFTP: Configuration file obtained from the TFTP server. • manual: Manually changed by the command-line interface. • NVRAM: Configuration file in NVRAM. • IPCP: ip address negotiated command. • DHCP: ip address dhcp command. • unset: Unset. • other: Unknown.
Status	<p>Shows the status of the interface. Valid values and their meanings are:</p> <ul style="list-style-type: none"> • up: Interface is up. • down: Interface is down. • administratively down: Interface is administratively down.
Protocol	Shows the operational status of the routing protocol on this interface.

Related Commands

Command	Description
ip interface	Configures a virtual gateway IP interface on a Secure Socket Layer Virtual Private Network (SSL VPN) gateway
show interface status	Displays the status of the interface.

show interfaces

To display the administrative and operational status of all interfaces or for a specified interface, use the **show interfaces** command in the EXEC mode.

show interfaces [*interface-id* | **vlan** *vlan-id*] [**accounting** | **capabilities** [*module number*] | **debounce** | **description** | **etherchannel** | **flowcontrol** | **private-vlan mapping** | **pruning** | **stats** | **status** [**err-disabled**] | **trunk**]

Syntax	Description
<i>interface-id</i>	(Optional) ID of the interface. Valid interfaces include physical ports (including type, stack member for stacking-capable switches, module, and port number) and port channels. The port channel range is 1 to 48.
vlan <i>vlan-id</i>	(Optional) VLAN identification. The range is 1 to 4094.
accounting	(Optional) Displays accounting information on the interface, including active protocols and input and output packets and octets. Note The display shows only packets processed in software; hardware-switched packets do not appear.
capabilities	(Optional) Displays the capabilities of all interfaces or the specified interface, including the features and options that you can configure on the interface. Though visible in the command line help, this option is not available for VLAN IDs.
module <i>number</i>	(Optional) Displays capabilities of all interfaces on the switch or specified stack member. This option is not available if you entered a specific interface ID.
description	(Optional) Displays the administrative status and description set for interfaces.
etherchannel	(Optional) Displays interface EtherChannel information.
flowcontrol	(Optional) Displays interface flow control information.
pruning	(Optional) Displays trunk VTP pruning information for the interface.
stats	(Optional) Displays the input and output packets by switching the path for the interface.
status	(Optional) Displays the status of the interface. A status of unsupported in the Type field means that a non-Cisco small form-factor pluggable (SFP) module is inserted in the module slot.
err-disabled	(Optional) Displays interfaces in an error-disabled state.

trunk (Optional) Displays interface trunk information. If you do not specify an interface, only information for active trunking ports appears.



Note Though visible in the command-line help strings, the **crb**, **fair-queue**, **irb**, **mac-accounting**, **precedence**, **random-detect**, **rate-limit**, and **shape** keywords are not supported.

Command Default None

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines The **show interfaces capabilities** command with different keywords has these results:

- Use the **show interface capabilities module *number*** command to display the capabilities of all interfaces on that switch in the stack. If there is no switch with that module number in the stack, there is no output.
- Use the **show interfaces *interface-id* capabilities** to display the capabilities of the specified interface.
- Use the **show interfaces capabilities** (with no module number or interface ID) to display the capabilities of all interfaces in the stack.



Note The field **Last Input** displayed in the command output indicates the number of hours, minutes, and seconds since the last packet was successfully received by an interface and processed by the CPU on the device. This information can be used to know when a dead interface failed.

Last Input is not updated by fast-switched traffic.

The field **output** displayed in the command output indicates the number of hours, minutes, and seconds since the last packet was successfully transmitted by the interface. The information provided by this field can be useful for knowing when a dead interface failed.

This is an example of output from the **show interfaces *interface* description** command when the interface has been described as *Connects to Marketing* by using the **description** interface configuration command:

```
Device# show interfaces gigabitethernet1/0/2 description

Interface          Status      Protocol Description
Gil/0/2            up          down     Connects to Marketing
```

This is an example of output from the **show interfaces *interface-id* pruning** command when pruning is enabled in the VTP domain:

```
Device# show interfaces gigabitethernet1/0/2 pruning
```

```
Port      Vlans pruned for lack of request by neighbor
Gi1/0/2   3,4
```

```
Port      Vlans traffic requested of neighbor
Gi1/0/2   1-3
```

This is an example of output from the **show interfaces stats** command for a specified VLAN interface:

```
Device# show interfaces vlan 1 stats
```

Switching path	Pkts In	Chars In	Pkts Out	Chars Out
Processor	1165354	136205310	570800	91731594
Route cache	0	0	0	0
Total	1165354	136205310	570800	91731594

This is an example of output from the **show interfaces status err-disabled** command. It displays the status of interfaces in the error-disabled state:

```
Device# show interfaces status err-disabled
```

Port	Name	Status	Reason
Gi1/0/2		err-disabled	gbic-invalid
Gi2/0/3		err-disabled	dtp-flap

This is an example of output from the **show interfaces interface-id pruning** command:

```
Device# show interfaces gigabitethernet1/0/2 pruning
```

```
Port Vlans pruned for lack of request by neighbor
```

```
Device# show interfaces gigabitethernet1/0/1 trunk
```

Port	Mode	Encapsulation	Status	Native vlan
Gi1/0/1	on	802.1q	other	10

```
Port      Vlans allowed on trunk
Gi1/0/1   none
```

```
Port      Vlans allowed and active in management domain
Gi1/0/1   none
```

```
Port      Vlans in spanning tree forwarding state and not pruned
Gi1/0/1   none
```

show interfaces counters

To display various counters for the switch or for a specific interface, use the **show interfaces counters** command in privileged EXEC mode.

show interfaces [*interface-id*] **counters** [**errors** | **etherchannel** | **module** *stack-member-number* | **protocol status** | **trunk**]

Syntax Description

<i>interface-id</i>	(Optional) ID of the physical interface, including type, stack member (stacking-capable switches only) module, and port number.
errors	(Optional) Displays error counters.
etherchannel	(Optional) Displays EtherChannel counters, including octets, broadcast packets, multicast packets, and unicast packets received and sent.
module <i>stack-member-number</i>	(Optional) Displays counters for the specified stack member. Note In this command, the module keyword refers to the stack member number. The module number that is part of the interface ID is always zero.
protocol status	(Optional) Displays the status of protocols enabled on interfaces.
trunk	(Optional) Displays trunk counters.



Note Though visible in the command-line help string, the **vlan** *vlan-id* keyword is not supported.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

If you do not enter any keywords, all counters for all interfaces are included.

This is an example of partial output from the **show interfaces counters** command. It displays all counters for the switch.

```
Device# show interfaces counters
Port          InOctets      InUcastPkts   InMcastPkts   InBcastPkts
Gi1/0/1       0              0              0              0
Gi1/0/2       0              0              0              0
Gi1/0/3       95285341      43115         1178430       1950
Gi1/0/4       0              0              0              0
```

<output truncated>

This is an example of partial output from the **show interfaces counters module** command for stack member 2. It displays all counters for the specified switch in the stack.

```
Device# show interfaces counters module 2
Port          InOctets    InUcastPkts  InMcastPkts  InBcastPkts
Gi1/0/1       520         2            0            0
Gi1/0/2       520         2            0            0
Gi1/0/3       520         2            0            0
Gi1/0/4       520         2            0            0
```

<output truncated>

This is an example of partial output from the **show interfaces counters protocol status** command for all interfaces:

```
Device# show interfaces counters protocol status
Protocols allocated:
Vlan1: Other, IP
Vlan20: Other, IP, ARP
Vlan30: Other, IP, ARP
Vlan40: Other, IP, ARP
Vlan50: Other, IP, ARP
Vlan60: Other, IP, ARP
Vlan70: Other, IP, ARP
Vlan80: Other, IP, ARP
Vlan90: Other, IP, ARP
Vlan900: Other, IP, ARP
Vlan3000: Other, IP
Vlan3500: Other, IP
GigabitEthernet1/0/1: Other, IP, ARP, CDP
GigabitEthernet1/0/2: Other, IP
GigabitEthernet1/0/3: Other, IP
GigabitEthernet1/0/4: Other, IP
GigabitEthernet1/0/5: Other, IP
GigabitEthernet1/0/6: Other, IP
GigabitEthernet1/0/7: Other, IP
GigabitEthernet1/0/8: Other, IP
GigabitEthernet1/0/9: Other, IP
GigabitEthernet1/0/10: Other, IP, CDP
```

<output truncated>

This is an example of output from the **show interfaces counters trunk** command. It displays trunk counters for all interfaces.

```
Device# show interfaces counters trunk
Port          TrunkFramesTx  TrunkFramesRx  WrongEncap
Gi1/0/1       0              0              0
Gi1/0/2       0              0              0
Gi1/0/3       80678         0              0
Gi1/0/4       82320         0              0
Gi1/0/5       0              0              0
```

<output truncated>

show interfaces switchport

To display the administrative and operational status of a switching (nonrouting) port, including port blocking and port protection settings, use the **show interfaces switchport** command in privileged EXEC mode.

show interfaces [*interface-id*] **switchport** [**module number**]

Syntax Description	<p><i>interface-id</i> (Optional) ID of the interface. Valid interfaces include physical ports (including type, stack member for stacking-capable switches, module, and port number) and port channels. The port channel range is 1 to 48.</p> <hr/> <p>module number (Optional) Displays switchport configuration of all interfaces on the switch or specified stack member.</p> <p>This option is not available if you entered a specific interface ID.</p>				
Command Default	None				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Everest 16.6.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Everest 16.6.1	This command was introduced.
Release	Modification				
Cisco IOS XE Everest 16.6.1	This command was introduced.				

Usage Guidelines Use the **show interface switchport module number** command to display the switch port characteristics of all interfaces on that switch in the stack. If there is no switch with that module number in the stack, there is no output.

This is an example of output from the **show interfaces switchport** command for a port. The table that follows describes the fields in the display.



Note Private VLANs are not supported in this release, so those fields are not applicable.

```
Device# show interfaces gigabitethernet1/0/1 switchport
Name: Gi1/0/1
Switchport: Enabled
Administrative Mode: trunk
Operational Mode: down
Administrative Trunking Encapsulation: dot1q
Negotiation of Trunking: On
Access Mode VLAN: 1 (default)
Trunking Native Mode VLAN: 10 (VLAN0010)
Administrative Native VLAN tagging: enabled
Voice VLAN: none
Administrative private-vlan host-association: none
Administrative private-vlan mapping: none
Administrative private-vlan trunk native VLAN: none
Administrative private-vlan trunk Native VLAN tagging: enabled
Administrative private-vlan trunk encapsulation: dot1q
Administrative private-vlan trunk normal VLANs: none
Administrative private-vlan trunk associations: none
```

show interfaces switchport

```

Administrative private-vlan trunk mappings: none
Operational private-vlan: none
Trunking VLANs Enabled: 11-20
Pruning VLANs Enabled: 2-1001
Capture Mode Disabled
Capture VLANs Allowed: ALL

```

```

Protected: false
Unknown unicast blocked: disabled
Unknown multicast blocked: disabled
Appliance trust: none

```

Field	Description
Name	Displays the port name.
Switchport	Displays the administrative and operational status of the port. In this display, the port is in switchport mode.
Administrative Mode Operational Mode	Displays the administrative and operational modes.
Administrative Trunking Encapsulation Operational Trunking Encapsulation Negotiation of Trunking	Displays the administrative and operational encapsulation method and whether trunking negotiation is enabled.
Access Mode VLAN	Displays the VLAN ID to which the port is configured.
Trunking Native Mode VLAN Trunking VLANs Enabled Trunking VLANs Active	Lists the VLAN ID of the trunk that is in native mode. Lists the allowed VLANs on the trunk. Lists the active VLANs on the trunk.
Pruning VLANs Enabled	Lists the VLANs that are pruning-eligible.
Protected	Displays whether or not protected port is enabled (True) or disabled (False) on the interface.
Unknown unicast blocked Unknown multicast blocked	Displays whether or not unknown multicast and unknown unicast traffic is blocked on the interface.
Voice VLAN	Displays the VLAN ID on which voice VLAN is enabled.
Appliance trust	Displays the class of service (CoS) setting of the data packets of the IP phone.

show interfaces transceiver

To display the physical properties of a small form-factor pluggable (SFP) module interface, use the **show interfaces transceiver** command in EXEC mode.

show interfaces [*interface-id*] **transceiver** [**detail** | **module** *number* | **properties** | **supported-list** | **threshold-table**]

Syntax Description	
<i>interface-id</i>	(Optional) ID of the physical interface, including type, stack member (stacking-capable switches only) module, and port number.
detail	(Optional) Displays calibration properties, including high and low numbers and any alarm information for any Digital Optical Monitoring (DoM)-capable transceiver if one is installed in the switch.
module <i>number</i>	(Optional) Limits display to interfaces on module on the switch. This option is not available if you entered a specific interface ID.
properties	(Optional) Displays speed, duplex, and inline power settings on an interface.
supported-list	(Optional) Lists all supported transceivers.
threshold-table	(Optional) Displays alarm and warning threshold table.

Command Modes	
	User EXEC
	Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Examples

This is an example of output from the **show interfaces *interface-id* transceiver properties** command:

This is an example of output from the **show interfaces *interface-id* transceiver detail** command:

```
Device# show interfaces gigabitethernet1/1/1 transceiver detail
ITU Channel not available (Wavelength not available),
Transceiver is internally calibrated.
mA:milliamperes, dBm:decibels (milliwatts), N/A:not applicable.
++:high alarm, +:high warning, -:low warning, -- :low alarm.
A2D readouts (if they differ), are reported in parentheses.
The threshold values are uncalibrated.

          High Alarm  High Warn  Low Warn  Low Alarm
          Threshold  Threshold  Threshold  Threshold
Port      Temperature  (Celsius)  (Celsius)  (Celsius)  (Celsius)
-----
Gi1/1/1  29.9          74.0       70.0       0.0        -4.0

          High Alarm  High Warn  Low Warn  Low Alarm
          Threshold  Threshold  Threshold  Threshold
Port      Voltage     (Volts)   (Volts)   (Volts)   (Volts)
```

show interfaces transceiver

Port	Optical Transmit Power (dBm)	High Alarm Threshold (dBm)	High Warn Threshold (dBm)	Low Warn Threshold (dBm)	Low Alarm Threshold (dBm)
Gil/1/1	3.28	3.60	3.50	3.10	3.00
Gil/1/1	1.8	7.9	3.9	0.0	-4.0
Gil/1/1	-23.5	-5.0	-9.0	-28.2	-32.2

This is an example of output from the **show interfaces transceiver threshold-table** command:

```
Device# show interfaces transceiver threshold-table
```

	Optical Tx	Optical Rx	Temp	Laser Bias current	Voltage
DWDM GBIC					
Min1	-4.00	-32.00	-4	N/A	4.65
Min2	0.00	-28.00	0	N/A	4.75
Max2	4.00	-9.00	70	N/A	5.25
Max1	7.00	-5.00	74	N/A	5.40
DWDM SFP					
Min1	-4.00	-32.00	-4	N/A	3.00
Min2	0.00	-28.00	0	N/A	3.10
Max2	4.00	-9.00	70	N/A	3.50
Max1	8.00	-5.00	74	N/A	3.60
RX only WDM GBIC					
Min1	N/A	-32.00	-4	N/A	4.65
Min2	N/A	-28.30	0	N/A	4.75
Max2	N/A	-9.00	70	N/A	5.25
Max1	N/A	-5.00	74	N/A	5.40
DWDM XENPAK					
Min1	-5.00	-28.00	-4	N/A	N/A
Min2	-1.00	-24.00	0	N/A	N/A
Max2	3.00	-7.00	70	N/A	N/A
Max1	7.00	-3.00	74	N/A	N/A
DWDM X2					
Min1	-5.00	-28.00	-4	N/A	N/A
Min2	-1.00	-24.00	0	N/A	N/A
Max2	3.00	-7.00	70	N/A	N/A
Max1	7.00	-3.00	74	N/A	N/A
DWDM XFP					
Min1	-5.00	-28.00	-4	N/A	N/A
Min2	-1.00	-24.00	0	N/A	N/A
Max2	3.00	-7.00	70	N/A	N/A
Max1	7.00	-3.00	74	N/A	N/A
CWDM X2					
Min1	N/A	N/A	0	N/A	N/A
Min2	N/A	N/A	0	N/A	N/A
Max2	N/A	N/A	0	N/A	N/A
Max1	N/A	N/A	0	N/A	N/A

<output truncated>

show inventory

To display the product inventory listing of all Cisco products installed in the networking device, use the **show inventory** command in user EXEC or privileged EXEC mode.

show inventory fru | oid | raw [entity]

fru	(Optional) Retrieves information about all Field Replaceable Units (FRUs) installed in the Cisco networking device.
oid	(Optional) Retrieves information about the vendor specific hardware registration identifier referred to as object identifier (OID). The OID identifies the MIB object's location in the MIB hierarchy, and provides a means of accessing the MIB object in a network of managed devices
raw	(Optional) Retrieves information about all Cisco products referred to as entities installed in the Cisco networking device, even if the entities do not have a product ID (PID) value, a unique device identifier (UDI), or other physical identification.
<i>entity</i>	(Optional) Name of a Cisco entity (for example, chassis, backplane, module, or slot). A quoted string may be used to display very specific UDI information; for example "sfslot 1" will display the UDI information for slot 1 of an entity named sfslot.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.
Cisco IOS XE Everest 16.6.3	This command was enhanced to display the serial number for the chassis.

Usage Guidelines

The **show inventory** command retrieves and displays inventory information about each Cisco product in the form of a UDI. The UDI is a combination of three separate data elements: a product identifier (PID), a version identifier (VID), and the serial number (SN).

The PID is the name by which the product can be ordered; it has been historically called the "Product Name" or "Part Number." This is the identifier that one would use to order an exact replacement part.

The VID is the version of the product. Whenever a product has been revised, the VID will be incremented. The VID is incremented according to a rigorous process derived from Telcordia GR-209-CORE, an industry guideline that governs product change notices.

The SN is the vendor-unique serialization of the product. Each manufactured product will carry a unique serial number assigned at the factory, which cannot be changed in the field. This is the means by which to identify an individual, specific instance of a product.

The UDI refers to each product as an entity. Some entities, such as a chassis, will have subtentities like slots. Each entity will display on a separate line in a logically ordered presentation that is arranged hierarchically by Cisco entities.

Use the **show inventory** command without options to display a list of Cisco entities installed in the networking device that are assigned a PID.

The following is sample output from the **show inventory** command:

```
Device#show inventory
NAME: "Chassis", DESCR: "Cisco Catalyst 9400 Series 7 Slot Chassis"
PID: C9407R          , VID: V01  , SN: FXS2128Q13X

NAME: "Slot 2 - Linecard", DESCR: "Cisco Catalyst 9400 Series 48-Port UPOE 10/100/1000
(RJ-45)"
PID: C9400-LC-48U   , VID: V01  , SN: JAE213102KS

NAME: "Slot 5 - Linecard", DESCR: "Cisco Catalyst 9400 Series 48-Port UPOE 10/100/1000
(RJ-45)"
PID: C9400-LC-48U   , VID: V01  , SN: JAE2132070M

NAME: "Slot 3 - Supervisor", DESCR: "Cisco Catalyst 9400 Series Supervisor 1 Module"
PID: C9400-SUP-1    , VID:      , SN:

NAME: "TenGigabitEthernet3/0/1", DESCR: "10GE CU5M"
PID: N/A            , VID: T    , SN: TED2116C4SV

NAME: "Slot 4 - Supervisor", DESCR: "Cisco Catalyst 9400 Series Supervisor 1 Module"
PID: C9400-SUP-1    , VID: V01  , SN: JAE221703LD

NAME: "TenGigabitEthernet4/0/1", DESCR: "10GE CU5M"
PID: N/A            , VID: T    , SN: TED2116C4EG

NAME: "Power Supply Module 1", DESCR: "Cisco Catalyst 9400 Series 3200W AC Power Supply"
PID: C9400-PWR-3200AC , VID: V01  , SN: DTM212200X2

NAME: "Fan Tray", DESCR: "Cisco Catalyst 9400 Series 7 Slot Chassis Fan Tray"
PID: C9407-FAN      , VID: V01  , SN: FXS212206DG
```



Note The fan tray serial number displayed in the output does not match the serial number displayed in the output of **show idprom fan-tray** command. **show idprom fan-tray** command displays the old PCB serial number.

Table 5: show inventory Field Descriptions

Field	Description
NAME	Physical name (text string) assigned to the Cisco entity. For example, console or a simple component number (port or module number), such as "1," depending on the physical component naming syntax of the device.
DESCR	Physical description of the Cisco entity that characterizes the object. The physical description includes the hardware serial number and the hardware revision.
PID	Entity product identifier. Equivalent to the entPhysicalModelName MIB variable in RFC 2737.
VID	Entity version identifier. Equivalent to the entPhysicalHardwareRev MIB variable in RFC 2737.
SN	Entity serial number. Equivalent to the entPhysicalSerialNum MIB variable in RFC 2737.

For diagnostic purposes, the **show inventory** command can be used with the **raw** keyword to display every RFC 2737 entity including those without a PID, UDI, or other physical identification.



Note The **raw** keyword option is primarily intended for troubleshooting problems with the **show inventory** command itself.

Enter the **show inventory** command with an *entity* argument value to display the UDI information for a specific type of Cisco entity installed in the networking device. In this example, a list of Cisco entities that match the *sfslot* argument string is displayed. You can request even more specific UDI information with the *entity* argument value enclosed in quotation marks.

```
9407R#show inv "Slot 2 Linecard"  
NAME: "Slot 2 Linecard", DESCR: "Cisco Catalyst 9400 Series 48-Port UPOE 10/100/1000 (RJ-45)"  
PID: C9400-LC-48U      , VID: V01  , SN: JAE213102KS
```

show memory platform

To display memory statistics of a platform, use the **show memory platform** command in privileged EXEC mode.

show memory platform [**compressed-swap** | **information** | **page-merging**]

Syntax Description	
compressed-swap	(Optional) Displays platform memory compressed-swap information.
information	(Optional) Displays general information about the platform.
page-merging	(Optional) Displays platform memory page-merging information.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines Free memory is accurately computed and displayed in the Free Memory field of the command output.

Examples

The following is sample output from the **show memory platform** command:

```
Switch# show memory platform

Virtual memory   : 12874653696
Pages resident  : 627041
Major page faults: 2220
Minor page faults: 2348631

Architecture    : mips64
Memory (kB)
  Physical      : 3976852
  Total         : 3976852
  Used          : 2761276
  Free          : 1215576
  Active        : 2128196
  Inactive      : 1581856
  Inact-dirty   : 0
  Inact-clean   : 0
  Dirty         : 0
  AnonPages     : 1294984
  Bounce        : 0
  Cached        : 1978168
  Commit Limit  : 1988424
  Committed As  : 3343324
  High Total    : 0
  High Free     : 0
  Low Total     : 3976852
  Low Free      : 1215576
  Mapped        : 516316
  NFS Unstable  : 0
  Page Tables   : 17124
  Slab          : 0
```

```

VMmalloc Chunk : 1069542588
VMmalloc Total : 1069547512
VMmalloc Used  : 2588
Writeback      : 0
HugePages Total: 0
HugePages Free : 0
HugePages Rsvd : 0
HugePage Size  : 2048

Swap (kB)
Total          : 0
Used           : 0
Free           : 0
Cached         : 0

Buffers (kB)   : 437136

Load Average
1-Min          : 1.04
5-Min          : 1.16
15-Min         : 0.94

```

The following is sample output from the **show memory platform information** command:

```
Device# show memory platform information
```

```

Virtual memory : 12870438912
Pages resident : 626833
Major page faults: 2222
Minor page faults: 2362455

Architecture   : mips64
Memory (kB)
Physical       : 3976852
Total          : 3976852
Used           : 2761224
Free           : 1215628
Active         : 2128060
Inactive       : 1584444
Inact-dirty    : 0
Inact-clean    : 0
Dirty          : 284
AnonPages      : 1294656
Bounce         : 0
Cached         : 1979644
Commit Limit   : 1988424
Committed As   : 3342184
High Total     : 0
High Free      : 0
Low Total      : 3976852
Low Free       : 1215628
Mapped         : 516212
NFS Unstable   : 0
Page Tables    : 17096
Slab           : 0
VMmalloc Chunk : 1069542588
VMmalloc Total : 1069547512
VMmalloc Used  : 2588
Writeback      : 0
HugePages Total: 0
HugePages Free : 0
HugePages Rsvd : 0
HugePage Size  : 2048

```

show memory platform

```
Swap (kB)
  Total      : 0
  Used       : 0
  Free       : 0
  Cached     : 0

Buffers (kB) : 438228

Load Average
  1-Min      : 1.54
  5-Min      : 1.27
  15-Min     : 0.99
```


show module

To display module information such as switch number, model number, serial number, hardware revision number, software version, MAC address and so on, use this command in user EXEC or privileged EXEC mode.

```
show module [switch-num]
```

Syntax Description	<i>switch-num</i>	(Optional) Number of the switch.
Command Default	None	
Command Modes	User EXEC (>) Privileged EXEC (#)	
Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.
Usage Guidelines	Entering the show module command without the <i>switch-num</i> argument is the same as entering the show module all command.	
Examples	This example shows how to display information for all the modules on a Cisco Catalyst 3850 Series switch:	

show mgmt-infra trace messages ilpower

To display inline power messages within a trace buffer, use the **show mgmt-infra trace messages ilpower** command in privileged EXEC mode.

show mgmt-infra trace messages ilpower [*switch stack-member-number*]

Syntax Description	switch <i>stack-member-number</i> (Optional) Specifies the stack member number for which to display inline power messages within a trace buffer.	
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

This is an output example from the **show mgmt-infra trace messages ilpower** command:

```
Device# show mgmt-infra trace messages ilpower
[10/23/12 14:05:10.984 UTC 1 3] Initialized inline power system configuration fo
r slot 1.
[10/23/12 14:05:10.984 UTC 2 3] Initialized inline power system configuration fo
r slot 2.
[10/23/12 14:05:10.984 UTC 3 3] Initialized inline power system configuration fo
r slot 3.
[10/23/12 14:05:10.984 UTC 4 3] Initialized inline power system configuration fo
r slot 4.
[10/23/12 14:05:10.984 UTC 5 3] Initialized inline power system configuration fo
r slot 5.
[10/23/12 14:05:10.984 UTC 6 3] Initialized inline power system configuration fo
r slot 6.
[10/23/12 14:05:10.984 UTC 7 3] Initialized inline power system configuration fo
r slot 7.
[10/23/12 14:05:10.984 UTC 8 3] Initialized inline power system configuration fo
r slot 8.
[10/23/12 14:05:10.984 UTC 9 3] Initialized inline power system configuration fo
r slot 9.
[10/23/12 14:05:10.984 UTC a 3] Inline power subsystem initialized.
[10/23/12 14:05:18.908 UTC b 264] Create new power pool for slot 1
[10/23/12 14:05:18.909 UTC c 264] Set total inline power to 450 for slot 1
[10/23/12 14:05:20.273 UTC d 3] PoE is not supported on .
[10/23/12 14:05:20.288 UTC e 3] PoE is not supported on .
[10/23/12 14:05:20.299 UTC f 3] PoE is not supported on .
[10/23/12 14:05:20.311 UTC 10 3] PoE is not supported on .
[10/23/12 14:05:20.373 UTC 11 98] Inline power process post for switch 1
[10/23/12 14:05:20.373 UTC 12 98] PoE post passed on switch 1
[10/23/12 14:05:20.379 UTC 13 3] Slot #1: PoE initialization for board id 16387
[10/23/12 14:05:20.379 UTC 14 3] Set total inline power to 450 for slot 1
[10/23/12 14:05:20.379 UTC 15 3] Gi1/0/1 port config Initialized
[10/23/12 14:05:20.379 UTC 16 3] Interface Gi1/0/1 initialization done.
[10/23/12 14:05:20.380 UTC 17 3] Gi1/0/24 port config Initialized
[10/23/12 14:05:20.380 UTC 18 3] Interface Gi1/0/24 initialization done.
[10/23/12 14:05:20.380 UTC 19 3] Slot #1: initialization done.
```

```
[10/23/12 14:05:50.440 UTC 1a 3] Slot #1: PoE initialization for board id 16387  
[10/23/12 14:05:50.440 UTC 1b 3] Duplicate init event
```

show mgmt-infra trace messages ilpower-ha

To display inline power high availability messages within a trace buffer, use the **show mgmt-infra trace messages ilpower-ha** command in privileged EXEC mode.

show mgmt-infra trace messages ilpower-ha [**switch** *stack-member-number*]

Syntax Description	switch <i>stack-member-number</i> (Optional) Specifies the stack member number for which to display inline power messages within a trace buffer.				
Command Default	None				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Everest 16.6.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Everest 16.6.1	This command was introduced.
Release	Modification				
Cisco IOS XE Everest 16.6.1	This command was introduced.				

This is an output example from the **show mgmt-infra trace messages ilpower-ha** command:

```
Device# show mgmt-infra trace messages ilpower-ha
[10/23/12 14:04:48.087 UTC 1 3] NG3K_ILPOWER_HA: Created NGWC ILP CF client successfully.
```

show mgmt-infra trace messages platform-mgr-poe

To display platform manager Power over Ethernet (PoE) messages within a trace buffer, use the **show mgmt-infra trace messages platform-mgr-poe** privileged EXEC command.

show mgmt-infra trace messages platform-mgr-poe [*switch stack-member-number*]

Syntax Description	switch <i>stack-member-number</i> (Optional) Specifies the stack member number for which to display messages within a trace buffer.				
Command Default	None				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Everest 16.6.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Everest 16.6.1	This command was introduced.
Release	Modification				
Cisco IOS XE Everest 16.6.1	This command was introduced.				

This is an example of partial output from the **show mgmt-infra trace messages platform-mgr-poe** command:

```
Device# show mgmt-infra trace messages platform-mgr-poe
[10/23/12 14:04:06.431 UTC 1 5495] PoE Info: get power controller param sent:
[10/23/12 14:04:06.431 UTC 2 5495] PoE Info: POE_SHUT sent for port 1 (0:0)
[10/23/12 14:04:06.431 UTC 3 5495] PoE Info: POE_SHUT sent for port 2 (0:1)
[10/23/12 14:04:06.431 UTC 4 5495] PoE Info: POE_SHUT sent for port 3 (0:2)
[10/23/12 14:04:06.431 UTC 5 5495] PoE Info: POE_SHUT sent for port 4 (0:3)
[10/23/12 14:04:06.431 UTC 6 5495] PoE Info: POE_SHUT sent for port 5 (0:4)
[10/23/12 14:04:06.431 UTC 7 5495] PoE Info: POE_SHUT sent for port 6 (0:5)
[10/23/12 14:04:06.431 UTC 8 5495] PoE Info: POE_SHUT sent for port 7 (0:6)
[10/23/12 14:04:06.431 UTC 9 5495] PoE Info: POE_SHUT sent for port 8 (0:7)
[10/23/12 14:04:06.431 UTC a 5495] PoE Info: POE_SHUT sent for port 9 (0:8)
[10/23/12 14:04:06.431 UTC b 5495] PoE Info: POE_SHUT sent for port 10 (0:9)
[10/23/12 14:04:06.431 UTC c 5495] PoE Info: POE_SHUT sent for port 11 (0:10)
[10/23/12 14:04:06.431 UTC d 5495] PoE Info: POE_SHUT sent for port 12 (0:11)
[10/23/12 14:04:06.431 UTC e 5495] PoE Info: POE_SHUT sent for port 13 (e:0)
[10/23/12 14:04:06.431 UTC f 5495] PoE Info: POE_SHUT sent for port 14 (e:1)
[10/23/12 14:04:06.431 UTC 10 5495] PoE Info: POE_SHUT sent for port 15 (e:2)
[10/23/12 14:04:06.431 UTC 11 5495] PoE Info: POE_SHUT sent for port 16 (e:3)
[10/23/12 14:04:06.431 UTC 12 5495] PoE Info: POE_SHUT sent for port 17 (e:4)
[10/23/12 14:04:06.431 UTC 13 5495] PoE Info: POE_SHUT sent for port 18 (e:5)
[10/23/12 14:04:06.431 UTC 14 5495] PoE Info: POE_SHUT sent for port 19 (e:6)
[10/23/12 14:04:06.431 UTC 15 5495] PoE Info: POE_SHUT sent for port 20 (e:7)
[10/23/12 14:04:06.431 UTC 16 5495] PoE Info: POE_SHUT sent for port 21 (e:8)
[10/23/12 14:04:06.431 UTC 17 5495] PoE Info: POE_SHUT sent for port 22 (e:9)
[10/23/12 14:04:06.431 UTC 18 5495] PoE Info: POE_SHUT sent for port 23 (e:10)
```

show network-policy profile

To display the network-policy profiles, use the **show network policy profile** command in privileged EXEC mode.

show network-policy profile [*profile-number*] [**detail**]

Syntax Description	<i>profile-number</i> (Optional) Displays the network-policy profile number. If no profile is entered, all network-policy profiles appear.	
	detail (Optional) Displays detailed status and statistics information.	
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

This is an example of output from the **show network-policy profile** command:

```
Device# show network-policy profile
Network Policy Profile 10
  voice vlan 17 cos 4
  Interface:
    none
Network Policy Profile 30
  voice vlan 30 cos 5
  Interface:
    none
Network Policy Profile 36
  voice vlan 4 cos 3
  Interface:
    Interface_id
```

show platform hardware fed active forward

To display device-specific hardware information, use the **show platform hardware fed active** command.

This topic elaborates only the forwarding-specific options, that is, the options available with the **show platform hardware fed {active | standby } forward** command.

The output of the **show platform hardware fed active forward** displays all the details about the forwarding decision taken for the packet.

show platform hardware fed active | standby forward

Syntax Description	<p>{ active standby } The switch for which you want to display information. You have the following options :</p> <ul style="list-style-type: none"> • active—Displays information relating to the active switch. • standby—Displays information relating to the standby switch, if available. 				
	<p>forward Displays packet forwarding information.</p>				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Everest 16.6.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Everest 16.6.1	This command was introduced.
Release	Modification				
Cisco IOS XE Everest 16.6.1	This command was introduced.				

Usage Guidelines Do not use this command unless a technical support representative asks you to. Use this command only when you are working directly with a technical support representative while troubleshooting a problem.

Fields displayed in the command output are explained below.

- Station Index : The Station Index is the result of the layer 2 lookup and points to a station descriptor which provides the following:
 - Destination Index : Determines the egress port(s) to which the packets should be sent to. Global Port Number(GPN) can be used as the destination index. A destination index with 15 down to 12 bits set indicates the GPN to be used. For example, destination index - 0xF04E corresponds to GPN - 78 (0x4e).
 - Rewrite Index : Determines what needs to be done with the packets. For layer 2 switching, this is typically a bridging action
 - Flexible Lookup Pipeline Stages(FPS) : Indicates the forwarding decision that was taken for the packet - routing or bridging
 - Replication Bit Map : Determines if the packets should be sent to CPU or stack
 - Local Data Copy = 1
 - Remote Data copy = 0
 - Local CPU Copy = 0

show platform hardware fed active forward

- Remote CPU Copy = 0

show platform hardware iomd lc-portmap brief

To display the line card port map information of the platform, use the **show platform hardware iomd lc-portmap brief** command in privileged EXEC mode.

show platform hardware iomd *slot/card* lc-portmap brief

Syntax Description

slot Slot number. The range is from 0 to 10.

card Card number. The range is from 0 to 0.

Command Modes Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Examples

The following is sample output from the **show platform hardware iomd lc-portmap brief** command:

```
Device# show platform hardware iomd 1/0 lc-portmap brief
id 1 asic 0 port 0 intl_port_sup0 8 intl_port_sup1 0 max_speed DEV_PORT_SPEED_10G
id 2 asic 0 port 1 intl_port_sup0 8 intl_port_sup1 0 max_speed DEV_PORT_SPEED_10G
id 3 asic 0 port 2 intl_port_sup0 8 intl_port_sup1 0 max_speed DEV_PORT_SPEED_10G
id 4 asic 0 port 3 intl_port_sup0 10 intl_port_sup1 2 max_speed DEV_PORT_SPEED_10G
id 5 asic 0 port 4 intl_port_sup0 10 intl_port_sup1 2 max_speed DEV_PORT_SPEED_10G
id 6 asic 0 port 5 intl_port_sup0 10 intl_port_sup1 2 max_speed DEV_PORT_SPEED_10G
id 7 asic 1 port 6 intl_port_sup0 9 intl_port_sup1 1 max_speed DEV_PORT_SPEED_10G
id 8 asic 1 port 7 intl_port_sup0 9 intl_port_sup1 1 max_speed DEV_PORT_SPEED_10G
id 9 asic 1 port 8 intl_port_sup0 9 intl_port_sup1 1 max_speed DEV_PORT_SPEED_10G
id 10 asic 1 port 9 intl_port_sup0 10 intl_port_sup1 2 max_speed DEV_PORT_SPEED_10G
id 11 asic 1 port 10 intl_port_sup0 10 intl_port_sup1 2 max_speed DEV_PORT_SPEED_10G
id 12 asic 1 port 11 intl_port_sup0 10 intl_port_sup1 2 max_speed DEV_PORT_SPEED_10G
id 13 asic 2 port 12 intl_port_sup0 8 intl_port_sup1 0 max_speed DEV_PORT_SPEED_10G
id 14 asic 2 port 13 intl_port_sup0 8 intl_port_sup1 0 max_speed DEV_PORT_SPEED_10G
id 15 asic 2 port 14 intl_port_sup0 8 intl_port_sup1 0 max_speed DEV_PORT_SPEED_10G
id 16 asic 2 port 15 intl_port_sup0 10 intl_port_sup1 2 max_speed DEV_PORT_SPEED_10G
id 17 asic 2 port 16 intl_port_sup0 10 intl_port_sup1 2 max_speed DEV_PORT_SPEED_10G
id 18 asic 2 port 17 intl_port_sup0 10 intl_port_sup1 2 max_speed DEV_PORT_SPEED_10G
id 19 asic 3 port 18 intl_port_sup0 8 intl_port_sup1 0 max_speed DEV_PORT_SPEED_10G
id 20 asic 3 port 19 intl_port_sup0 8 intl_port_sup1 0 max_speed DEV_PORT_SPEED_10G
id 21 asic 3 port 20 intl_port_sup0 8 intl_port_sup1 0 max_speed DEV_PORT_SPEED_10G
id 22 asic 3 port 21 intl_port_sup0 10 intl_port_sup1 2 max_speed DEV_PORT_SPEED_10G
id 23 asic 3 port 22 intl_port_sup0 10 intl_port_sup1 2 max_speed DEV_PORT_SPEED_10G
id 24 asic 3 port 23 intl_port_sup0 10 intl_port_sup1 2 max_speed DEV_PORT_SPEED_10G
```

show platform hardware iomd portgroups

To display the port grouping information of the platform, use the **show platform hardware iomd portgroups** command in privileged EXEC mode.

show platform hardware iomd *slot/card* portgroups

Syntax Description	
<i>slot</i>	Slot number. The range is from 0 to 10.
<i>card</i>	Card number. The range is from 0 to 0.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Examples

The following is sample output from the **show platform hardware iomd portgroups** command:

Device# **show platform hardware iomd 1/0 portgroups**

Port Group	Interface	Status	Interface Bandwidth	Group Max Bandwidth
1	TenGigabitEthernet1/0/1	up	10G	
1	TenGigabitEthernet1/0/2	up	10G	
1	TenGigabitEthernet1/0/3	down	10G	10G
2	TenGigabitEthernet1/0/4	up	10G	
2	TenGigabitEthernet1/0/5	down	10G	
2	TenGigabitEthernet1/0/6	down	10G	10G
3	TenGigabitEthernet1/0/7	up	10G	
3	TenGigabitEthernet1/0/8	down	10G	
3	TenGigabitEthernet1/0/9	down	10G	10G
4	TenGigabitEthernet1/0/10	up	10G	
4	TenGigabitEthernet1/0/11	down	10G	
4	TenGigabitEthernet1/0/12	down	10G	10G
5	TenGigabitEthernet1/0/13	up	10G	
5	TenGigabitEthernet1/0/14	down	10G	
5	TenGigabitEthernet1/0/15	down	10G	10G
6	TenGigabitEthernet1/0/16	down	10G	
6	TenGigabitEthernet1/0/17	up	10G	
6	TenGigabitEthernet1/0/18	down	10G	10G
7	TenGigabitEthernet1/0/19	down	10G	
7	TenGigabitEthernet1/0/20	down	10G	
7	TenGigabitEthernet1/0/21	down	10G	10G
8	TenGigabitEthernet1/0/22	down	10G	
8	TenGigabitEthernet1/0/23	down	10G	

8	TenGigabitEthernet1/0/24	down	10G	10G
---	--------------------------	------	-----	-----

show platform resources

To display platform resource information, use the **show platform resources** command in privileged EXEC mode.

show platform resources

This command has no arguments or keywords.

Command Modes Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines The output of this command displays the used memory, which is total memory minus the accurate free memory.

Example

The following is sample output from the **show platform resources** command:

```
Switch# show platform resources
```

```
**State Acronym: H - Healthy, W - Warning, C - Critical
```

Resource State	Usage	Max	Warning	Critical
Control Processor H	7.20%	100%	90%	95%
DRAM H	2701MB (69%)	3883MB	90%	95%

show platform software ilpower

To display the inline power details of all the PoE ports on the device, use the **show platform software ilpower** command in privileged EXEC mode.

```
show platform software ilpower {details | port {GigabitEthernet interface-number } | system slot-number }
```

Syntax Description	details	Displays inline power details for all the interfaces.
	port	Displays inline power port configuration.
	GigabitEthernet <i>interface-number</i>	The GigabitEthernet interface number. Values range from 0 to 9.
	system <i>slot-number</i>	Displays inline power system configuration.
Command Modes	Privileged EXEC (#)	
Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	The command was introduced.

Examples

The following is sample output from the **show platform software ilpower details** command:

```
Device# show platform software ilpower details
ILP Port Configuration for interface Gi1/0/1
  Initialization Done:    Yes
  ILP Supported:         Yes
  ILP Enabled:           Yes
  POST:                  Yes
  Detect On:              No
  Powered Device Detected          No
  Powered Device Class Done        No
  Cisco Powered Device:            No
  Power is On:                      No
  Power Denied:                     No
  Powered Device Type:                Null
  Powerd Device Class:                Null
  Power State:                        NULL
  Current State:                      NGWC_ILP_DETECTING_S
  Previous State:                     NGWC_ILP_SHUT_OFF_S
  Requested Power in milli watts:    0
  Short Circuit Detected:             0
  Short Circuit Count:                0
  Cisco Powerd Device Detect Count:  0
  Spare Pair mode:                    0
    IEEE Detect:                      Stopped
    IEEE Short:                       Stopped
    Link Down:                         Stopped
  Voltage sense:                      Stopped
  Spare Pair Architecture:            1
  Signal Pair Power allocation in milli watts: 0
  Spare Pair Power On:                0
  Powered Device power state:         0
  Timer:
```

```
show platform software ilpower
```

```
Power Good:          Stopped
Power Denied:        Stopped
Cisco Powered Device Detect:  Stopped
```

show platform software process list

To display the list of running processes on a platform, use the **show platform software process list** command in privileged EXEC mode.

show platform software process list switch *switch-number* | **active** | **standby 0** | **F0** | **R0** [**name** *process-name* | **process-id** *process-ID* | **sort memory** | **summary**]

Syntax Description		
switch <i>switch-number</i>	Displays information about the switch. Valid values for <i>switch-number</i> argument are from 0 to 9.	
active	Displays information about the active instance of the switch.	
standby	Displays information about the standby instance of the switch.	
0	Displays information about the shared port adapters (SPA) Interface Processor slot 0.	
F0	Displays information about the Embedded Service Processor (ESP) slot 0.	
R0	Displays information about the Route Processor (RP) slot 0.	
name <i>process-name</i>	(Optional) Displays information about the specified process.	
process-id <i>process-ID</i>	(Optional) Displays information about the specified process ID.	
sort	(Optional) Displays information sorted according to processes.	
memory	(Optional) Displays information sorted according to memory.	
summary	(Optional) Displays a summary of the process memory of the host device.	

Command Modes Privileged EXE (#)

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	The command was introduced.

Usage Guidelines Prior to Cisco IOS XE Denali 16.3.1, the Free Memory displayed in the command output was obtained from the underlying Linux kernel. This value was not accurate because some memory chunks that was available for use was not considered as free memory.

In Cisco IOS XE Denali 16.3.1, the free memory is accurately computed and displayed in the Free Memory field of the command output.

Examples

The following is sample output from the **show platform software process list switch active R0** command:

```
Switch# show platform software process list switch active R0 summary

Total number of processes: 278
  Running                   : 2
```

show platform software process list

```

Sleeping           : 276
Disk sleeping     : 0
Zombies           : 0
Stopped           : 0
Paging            : 0

Up time           : 8318
Idle time         : 0
User time         : 216809
Kernel time       : 78931

Virtual memory    : 12933324800
Pages resident    : 634061
Major page faults: 2228
Minor page faults: 3491744

Architecture      : mips64
Memory (kB)
  Physical         : 3976852
  Total            : 3976852
  Used             : 2766952
  Free             : 1209900
  Active           : 2141344
  Inactive         : 1589672
  Inact-dirty      : 0
  Inact-clean      : 0
  Dirty           : 4
  AnonPages        : 1306800
  Bounce           : 0
  Cached           : 1984688
  Commit Limit     : 1988424
  Committed As     : 3358528
  High Total       : 0
  High Free        : 0
  Low Total        : 3976852
  Low Free         : 1209900
  Mapped           : 520528
  NFS Unstable     : 0
  Page Tables      : 17328
  Slab             : 0
  VMmalloc Chunk   : 1069542588
  VMmalloc Total   : 1069547512
  VMmalloc Used    : 2588
  Writeback        : 0
  HugePages Total  : 0
  HugePages Free   : 0
  HugePages Rsvd   : 0
  HugePage Size    : 2048

Swap (kB)
  Total            : 0
  Used             : 0
  Free             : 0
  Cached           : 0

Buffers (kB)      : 439528

Load Average
  1-Min            : 1.13
  5-Min            : 1.18
  15-Min           : 0.92

```


show platform software process slot switch

To display platform software process switch information, use the **show platform software process slot switch** command in privileged EXEC mode.

show platform software process slot switch *switch-number* | **active** | **standby 0** | **F0** | **R0** **monitor** [*cycles no-of-times* [*interval delay* [*lines number*]]]

Syntax Description		
	<i>switch-number</i>	Switch number.
	active	Specifies the active instance.
	standby	Specifies the standby instance.
	0	Specifies the shared port adapter (SPA) interface processor slot 0.
	F0	Specifies the Embedded Service Processor (ESP) slot 0.
	R0	Specifies the Route Processor (RP) slot 0.
	monitor	Monitors the running processes.
	cycles <i>no-of-times</i>	(Optional) Sets the number of times to run monitor command. Valid values are from 1 to 4294967295. The default is 5.
	interval <i>delay</i>	(Optional) Sets a delay after each . Valid values are from 0 to 300. The default is 3.
	lines <i>number</i>	(Optional) Sets the number of lines of output displayed. Valid values are from 0 to 512. The default is 0.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines The output of the **show platform software process slot switch** and **show processes cpu platform monitor location** commands display the output of the Linux **top** command. The output of these commands display Free memory and Used memory as displayed by the Linux **top** command. The values displayed for the Free memory and Used memory by these commands do not match the values displayed by the output of other platform-memory related CLIs.

Examples The following is sample output from the **show platform software process slot switch active R0 monitor** command:

show platform software process slot switch

```
Switch# show platform software process slot switch active R0 monitor
```

```
top - 00:01:52 up 1 day, 11:20, 0 users, load average: 0.50, 0.68, 0.83
Tasks: 311 total, 2 running, 309 sleeping, 0 stopped, 0 zombie
Cpu(s): 7.4%us, 3.3%sy, 0.0%ni, 89.2%id, 0.0%wa, 0.0%hi, 0.1%si, 0.0%st
Mem: 3976844k total, 3955036k used, 21808k free, 419312k buffers
Swap: 0k total, 0k used, 0k free, 1946764k cached
```

```

  PID USER      PR  NI  VIRT  RES  SHR  S  %CPU  %MEM    TIME+  COMMAND
  5693 root        20   0  3448 1368  912  R   7   0.0   0:00.07 top
 17546 root        20   0 2044m 244m  79m  S   7   6.3 186:49.08 fed main event
 18662 root        20   0 1806m 678m 263m  S   5  17.5 215:32.38 linux_iosd-imag
 30276 root        20   0  171m  42m  33m  S   5   1.1 125:06.77 repm
 17835 root        20   0  935m  74m  63m  S   4   1.9  82:28.31 sif_mgr
 18534 root        20   0  182m 150m  10m  S   2   3.9   8:12.08 smand
     1 root        20   0  8440 4740 2184  S   0   0.1   0:09.52 systemd
     2 root        20   0      0     0     0  S   0   0.0   0:00.00 kthreadd
     3 root        20   0      0     0     0  S   0   0.0   0:02.86 ksoftirqd/0
     5 root         0  -20      0     0     0  S   0   0.0   0:00.00 kworker/0:0H
     7 root        RT   0      0     0     0  S   0   0.0   0:01.44 migration/0
     8 root        20   0      0     0     0  S   0   0.0   0:00.00 rcu_bh
     9 root        20   0      0     0     0  S   0   0.0   0:23.08 rcu_sched
    10 root        20   0      0     0     0  S   0   0.0   0:58.04 rcuc/0
    11 root        20   0      0     0     0  S   0   0.0 21:35.60 rcuc/1
    12 root        RT   0      0     0     0  S   0   0.0   0:01.33 migration/1

```

Related Commands

Command	Description
show processes cpu platform monitor location	Displays information about the CPU utilization of the IOS-XE processes.

show platform software status control-processor

To display platform software control-processor status, use the **show platform software status control-processor** command in privileged EXEC mode.

show platform software status control-processor [brief]

Syntax Description	brief (Optional) Displays a summary of the platform control-processor status.
---------------------------	--

Command Modes	Privileged EXEC (#)
----------------------	---------------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines	Prior to Cisco IOS XE Denali 16.3.1, the Free Memory displayed in the command output was obtained from the underlying Linux kernel. This value was not accurate because some memory chunks that was available for use was not considered as free memory.
-------------------------	--

In Cisco IOS XE Denali 16.3.1, the free memory is accurately computed and displayed in the Free Memory field of the command output.

Examples

The following is sample output from the **show platform memory software status control-processor** command:

```
Switch# show platform software status control-processor

2-RP0: online, statistics updated 7 seconds ago
Load Average: healthy
  1-Min: 1.00, status: healthy, under 5.00
  5-Min: 1.21, status: healthy, under 5.00
 15-Min: 0.90, status: healthy, under 5.00
Memory (kb): healthy
  Total: 3976852
  Used: 2766284 (70%), status: healthy
  Free: 1210568 (30%)
  Committed: 3358008 (84%), under 95%
Per-core Statistics
CPU0: CPU Utilization (percentage of time spent)
  User: 4.40, System: 1.70, Nice: 0.00, Idle: 93.80
  IRQ: 0.00, SIRQ: 0.10, IOWait: 0.00
CPU1: CPU Utilization (percentage of time spent)
  User: 3.80, System: 1.20, Nice: 0.00, Idle: 94.90
  IRQ: 0.00, SIRQ: 0.10, IOWait: 0.00
CPU2: CPU Utilization (percentage of time spent)
  User: 7.00, System: 1.10, Nice: 0.00, Idle: 91.89
  IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU3: CPU Utilization (percentage of time spent)
  User: 4.49, System: 0.69, Nice: 0.00, Idle: 94.80
  IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00

3-RP0: unknown, statistics updated 2 seconds ago
Load Average: healthy
  1-Min: 0.24, status: healthy, under 5.00
  5-Min: 0.27, status: healthy, under 5.00
```

show platform software status control-processor

```

15-Min: 0.32, status: healthy, under 5.00
Memory (kb): healthy
Total: 3976852
Used: 2706768 (68%), status: healthy
Free: 1270084 (32%)
Committed: 3299332 (83%), under 95%
Per-core Statistics
CPU0: CPU Utilization (percentage of time spent)
User: 4.50, System: 1.20, Nice: 0.00, Idle: 94.20
IRQ: 0.00, SIRQ: 0.10, IOWait: 0.00
CPU1: CPU Utilization (percentage of time spent)
User: 5.20, System: 0.50, Nice: 0.00, Idle: 94.29
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU2: CPU Utilization (percentage of time spent)
User: 3.60, System: 0.70, Nice: 0.00, Idle: 95.69
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU3: CPU Utilization (percentage of time spent)
User: 3.00, System: 0.60, Nice: 0.00, Idle: 96.39
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00

4-RP0: unknown, statistics updated 2 seconds ago
Load Average: healthy
1-Min: 0.21, status: healthy, under 5.00
5-Min: 0.24, status: healthy, under 5.00
15-Min: 0.24, status: healthy, under 5.00
Memory (kb): healthy
Total: 3976852
Used: 1452404 (37%), status: healthy
Free: 2524448 (63%)
Committed: 1675120 (42%), under 95%
Per-core Statistics
CPU0: CPU Utilization (percentage of time spent)
User: 2.30, System: 0.40, Nice: 0.00, Idle: 97.30
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU1: CPU Utilization (percentage of time spent)
User: 4.19, System: 0.69, Nice: 0.00, Idle: 95.10
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU2: CPU Utilization (percentage of time spent)
User: 4.79, System: 0.79, Nice: 0.00, Idle: 94.40
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU3: CPU Utilization (percentage of time spent)
User: 2.10, System: 0.40, Nice: 0.00, Idle: 97.50
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00

9-RP0: unknown, statistics updated 4 seconds ago
Load Average: healthy
1-Min: 0.20, status: healthy, under 5.00
5-Min: 0.35, status: healthy, under 5.00
15-Min: 0.35, status: healthy, under 5.00
Memory (kb): healthy
Total: 3976852
Used: 1451328 (36%), status: healthy
Free: 2525524 (64%)
Committed: 1675932 (42%), under 95%
Per-core Statistics
CPU0: CPU Utilization (percentage of time spent)
User: 1.90, System: 0.50, Nice: 0.00, Idle: 97.60
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU1: CPU Utilization (percentage of time spent)
User: 4.39, System: 0.19, Nice: 0.00, Idle: 95.40
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00
CPU2: CPU Utilization (percentage of time spent)
User: 5.70, System: 1.00, Nice: 0.00, Idle: 93.30
IRQ: 0.00, SIRQ: 0.00, IOWait: 0.00

```

```

CPU3: CPU Utilization (percentage of time spent)
  User: 1.30, System: 0.60, Nice: 0.00, Idle: 98.00
  IRQ: 0.00, SIRQ: 0.10, IOWait: 0.00

```

The following is sample output from the **show platform memory software status control-processor brief** command:

```
Switch# show platform software status control-processor brief
```

```

Load Average
  Slot Status 1-Min 5-Min 15-Min
2-RP0 Healthy 1.10 1.21 0.91
3-RP0 Healthy 0.23 0.27 0.31
4-RP0 Healthy 0.11 0.21 0.22
9-RP0 Healthy 0.10 0.30 0.34

Memory (kB)
  Slot Status Total Used (Pct) Free (Pct) Committed (Pct)
2-RP0 Healthy 3976852 2766956 (70%) 1209896 (30%) 3358352 (84%)
3-RP0 Healthy 3976852 2706824 (68%) 1270028 (32%) 3299276 (83%)
4-RP0 Healthy 3976852 1451888 (37%) 2524964 (63%) 1675076 (42%)
9-RP0 Healthy 3976852 1451580 (37%) 2525272 (63%) 1675952 (42%)

CPU Utilization
  Slot CPU User System Nice Idle IRQ SIRQ IOWait
2-RP0 0 4.10 2.00 0.00 93.80 0.00 0.10 0.00
      1 4.60 1.00 0.00 94.30 0.00 0.10 0.00
      2 6.50 1.10 0.00 92.40 0.00 0.00 0.00
      3 5.59 1.19 0.00 93.20 0.00 0.00 0.00
3-RP0 0 2.80 1.20 0.00 95.90 0.00 0.10 0.00
      1 4.49 1.29 0.00 94.20 0.00 0.00 0.00
      2 5.30 1.60 0.00 93.10 0.00 0.00 0.00
      3 5.80 1.20 0.00 93.00 0.00 0.00 0.00
4-RP0 0 1.30 0.80 0.00 97.89 0.00 0.00 0.00
      1 1.30 0.20 0.00 98.50 0.00 0.00 0.00
      2 5.60 0.80 0.00 93.59 0.00 0.00 0.00
      3 5.09 0.19 0.00 94.70 0.00 0.00 0.00
9-RP0 0 3.99 0.69 0.00 95.30 0.00 0.00 0.00
      1 2.60 0.70 0.00 96.70 0.00 0.00 0.00
      2 4.49 0.89 0.00 94.60 0.00 0.00 0.00
      3 2.60 0.20 0.00 97.20 0.00 0.00 0.00

```

show processes cpu platform monitor

To displays information about the CPU utilization of the IOS-XE processes, use the **show processes cpu platform monitor** command in privileged EXEC mode.

show processes cpu platform monitor location switch *switch-number* | **active** | **standby** **0** | **F0** | **R0**

Syntax Description	Parameter	Description
	location	Displays information about the Field Replaceable Unit (FRU) location.
	switch	Specifies the switch.
	<i>switch-number</i>	Switch number.
	active	Specifies the active instance.
	standby	Specifies the standby instance.
	0	Specifies the shared port adapter (SPA) interface processor slot 0.
	F0	Specifies the Embedded Service Processor (ESP) slot 0.
	R0	Specifies the Route Processor (RP) slot 0.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	This command was introduced.

Usage Guidelines The output of the **show platform software process slot switch** and **show processes cpu platform monitor location** commands display the output of the Linux **top** command. The output of these commands display Free memory and Used memory as displayed by the Linux **top** command. The values displayed for the Free memory and Used memory by these commands do not match the values displayed by the output of other platform-memory related CLIs.

Examples

The following is sample output from the **show processes cpu monitor location switch active R0** command:

```
Switch# show processes cpu platform monitor location switch active R0

top - 00:04:21 up 1 day, 11:22,  0 users,  load average: 0.42, 0.60, 0.78
Tasks: 312 total,  4 running, 308 sleeping,  0 stopped,  0 zombie
Cpu(s):  7.4%us,  3.3%sy,  0.0%ni, 89.2%id,  0.0%wa,  0.0%hi,  0.1%si,  0.0%st
Mem:   3976844k total,  3956928k used,    19916k free,  419312k buffers
Swap:          0k total,          0k used,          0k free, 1947036k cached

  PID USER      PR  NI  VIRT  RES  SHR  S  %CPU  %MEM    TIME+  COMMAND
  6294 root        20   0  3448 1368  912  R   9.0   0.0   0:00.07 top
 17546 root        20   0 2044m 244m  79m  S   7.6   6.3 187:02.07 fed main event
30276 root        20   0  171m  42m  33m  S   7.1   1.1 125:15.54 repm
   16 root        20   0     0     0     0  S   5.0   0.0  22:07.92 rcuc/2
   21 root        20   0     0     0     0  R   5.0   0.0  22:13.24 rcuc/3
18662 root        20   0 1806m 678m 263m  R   5.0 17.5 215:47.59 linux_iods-imag
```

```

11 root      20  0      0      0      0 S    4  0.0  21:37.41 rcuc/1
10333 root     20  0  6420 3916 1492 S    4  0.1   4:47.03 btrace_rotate.s
 10 root     20  0      0      0      0 S    2  0.0   0:58.13 rcuc/0
6304 root     20  0   776   12      0 R    2  0.0   0:00.01 ls
17835 root    20  0  935m  74m   63m S    2  1.9  82:34.07 sif_mgr
  1 root     20  0  8440 4740 2184 S    0  0.1   0:09.52 systemd
  2 root     20  0      0      0      0 S    0  0.0   0:00.00 kthreadd
  3 root     20  0      0      0      0 S    0  0.0   0:02.86 ksoftirqd/0
  5 root      0 -20      0      0      0 S    0  0.0   0:00.00 kworker/0:0H
  7 root     RT  0      0      0      0 S    0  0.0   0:01.44 migration/0

```

Related Commands

Command	Description
show platform software process slot switch	Displays platform software process switch information.

show processes memory

To display the amount of memory used by each system process, use the **show processes memory** command in privileged EXEC mode.

```
show processes memory [ process-id | sorted [ allocated | getbufs | holding ] ]
```

Syntax Description

<i>process-id</i>	(Optional) Process ID (PID) of a specific process. When you specify a process ID, only details for the specified process will be shown.
sorted	(Optional) Displays memory data sorted by the Allocated, Get Buffers, or Holding column. If the sorted keyword is used by itself, data is sorted by the Holding column by default.
allocated	(Optional) Displays memory data sorted by the Allocated column.
getbufs	(Optional) Displays memory data sorted by the Getbufs (Get Buffers) column.
holding	(Optional) Displays memory data sorted by the Holding column. This keyword is the default.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

The **show processes memory** command and the **show processes memory sorted** command displays a summary of total, used, and free memory, followed by a list of processes and their memory impact.

If the standard **show processes memory *process-id*** command is used, processes are sorted by their PID. If the **show processes memory sorted** command is used, the default sorting is by the Holding value.



Note

Holding memory of a particular process can be allocated by other processes also, and so it can be greater than the allocated memory.

The following is sample output from the **show processes memory** command:

```
Device# show processes memory

Processor Pool Total: 25954228 Used: 8368640 Free: 17585588
PID TTY Allocated Freed Holding Getbufs Retbufs Process
0 0 8629528 689900 6751716 0 0 *Init*
0 0 24048 12928 24048 0 0 *Sched*
0 0 260 328 68 350080 0 *Dead*
1 0 0 0 12928 0 0 Chunk Manager
2 0 192 192 6928 0 0 Load Meter
3 0 214664 304 227288 0 0 Exec
4 0 0 0 12928 0 0 Check heaps
5 0 0 0 12928 0 0 Pool Manager
6 0 192 192 12928 0 0 Timers
7 0 192 192 12928 0 0 Serial Backgroun
```



```

 8 0      192      192      12928      0      0 AAA high-capacit
 9 0      0        0        24928      0      0 Policy Manager
10 0      0        0        12928      0      0 ARP Input
11 0     192      192      12928      0      0 DDR Timers
12 0      0        0        12928      0      0 Entity MIB API
13 0      0        0        12928      0      0 MPLS HC Counter
14 0      0        0        12928      0      0 SERIAL A'detect
.
.
.
78 0      0        0        12992      0      0 DHCPD Timer
79 0     160      0        13088      0      0 DHCPD Database
      8329440 Total

```

The table below describes the significant fields shown in the display.

Table 6: show processes memory Field Descriptions

Field	Description
Processor Pool Total	Total amount of memory, in kilobytes (KB), held for the Processor memory pool.
Used	Total amount of used memory, in KB, in the Processor memory pool.
Free	Total amount of free memory, in KB, in the Processor memory pool.
PID	Process ID.
TTY	Terminal that controls the process.
Allocated	Bytes of memory allocated by the process.
Freed	Bytes of memory freed by the process, regardless of who originally allocated it.
Holding	Amount of memory, in KB, currently allocated to the process. This includes memory allocated by the process and assigned to the process.
Getbufs	Number of times the process has requested a packet buffer.
Retbufs	Number of times the process has relinquished a packet buffer.
Process	Process name.
Init	System initialization process.
Sched	The scheduler process.
Dead	Processes as a group that are now dead.
<value> Total	Total amount of memory, in KB, held by all processes (sum of the “Holding” column).

The following is sample output from the **show processes memory** command when the **sorted** keyword is used. In this case, the output is sorted by the Holding column, from largest to smallest.

Device# **show processes memory sorted**

```

Processor Pool Total:  25954228  Used:    8371280  Free:    17582948
  PID TTY  Allocated    Freed    Holding    Getbufs  Retbufs Process
    0  0    8629528    689900   6751716         0         0 *Init*

```

show processes memory

```

 3  0  217304      304  229928        0      0 Exec
53  0  109248      192   96064        0      0 DHCPD Receive
56  0      0         0   32928        0      0 COPS
19  0   39048         0  25192        0      0 Net Background
42  0      0         0  24960        0      0 L2X Data Daemon
58  0    192      192   24928        0      0 X.25 Background
43  0    192      192   24928        0      0 PPP IP Route
49  0      0         0   24928        0      0 TCP Protocols
48  0      0         0   24928        0      0 TCP Timer
17  0    192      192   24928        0      0 XML Proxy Client
 9  0      0         0   24928        0      0 Policy Manager
40  0      0         0   24928        0      0 L2X SSS manager
29  0      0         0   24928        0      0 IP Input
44  0    192      192   24928        0      0 PPP IPCP
32  0    192      192   24928        0      0 PPP Hooks
34  0      0         0   24928        0      0 SSS Manager
41  0    192      192   24928        0      0 L2TP mgmt daemon
16  0    192      192   24928        0      0 Dialer event
35  0      0         0   24928        0      0 SSS Test Client
--More--

```

The following is sample output from the **show processes memory** command when a process ID (*process-id*) is specified:

```
Device# show processes memory 1
```

```

Process ID: 1
Process Name: Chunk Manager
Total Memory Held: 8428 bytes
Processor memory holding = 8428 bytes
pc = 0x60790654, size =    6044, count =    1
pc = 0x607A5084, size =    1544, count =    1
pc = 0x6076DBC4, size =     652, count =    1
pc = 0x6076FF18, size =     188, count =    1
I/O memory holding = 0 bytes

```

```
Device# show processes memory 2
```

```

Process ID: 2
Process Name: Load Meter
Total Memory Held: 3884 bytes
Processor memory holding = 3884 bytes
pc = 0x60790654, size =    3044, count =    1
pc = 0x6076DBC4, size =     652, count =    1
pc = 0x6076FF18, size =     188, count =    1
I/O memory holding = 0 bytes

```

Related Commands

Command	Description
show memory	Displays statistics about memory, including memory-free pool statistics.
show processes	Displays information about the active processes.

show processes memory platform

To display memory usage per Cisco IOS XE process, use the **show processes memory platform** command in privileged EXEC mode.

show processes memory platform [**detailed name** *process-name* | **process-id** *process-ID* [**location** | **maps** [*location*] | **smaps** [*location*]] | **location** | **sorted** [*location*]] **switch** *switch-number* | **active** | **standby** **0** | **F0** | **R0**

Syntax	Description
detailed <i>process-name</i>	(Optional) Displays detailed memory information for a specified Cisco IOS XE process.
name <i>process-name</i>	(Optional) Matches the Cisco IOS XE process name.
process-id <i>process-ID</i>	(Optional) Matches the Cisco IOS XE process ID.
location	(Optional) Displays information about the FRU location.
maps	(Optional) Displays memory maps of a process.
smaps	(Optional) Displays smaps of a process.
sorted	(Optional) Displays the sorted output based on the total memory used by Cisco IOS XE processes.
switch <i>switch-number</i>	Displays information about the device.
active	Displays information about the active instance of the switch.
standby	Displays information about the standby instance of the switch.
0	Displays information about the SPA-Inter-Processor slot 0.
F0	Displays information about the Embedded Service Processor (ESP) slot 0.
R0	Displays information about the Route Processor (RP) slot 0.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.1.1	The command was introduced.

show processes memory platform

Usage Guidelines

Prior to Cisco IOS XE Denali 16.3.1, the Free Memory displayed in the command output was obtained from the underlying Linux kernel. This value was not accurate because some memory chunks that was available for use was not considered as free memory.

In Cisco IOS XE Denali 16.3.1, the free memory is accurately computed and displayed in the Free Memory field of the command output.

Examples

The following is sample output from the **show processes memory platform** command:

```
Switch# show processes memory platform

System memory: 3976852K total, 2761580K used, 1215272K free,
Lowest: 1215272K
  Pid  Text      Data  Stack  Dynamic  RSS    Total  Name
-----
    1  1246     4400   132    1308    4400   8328   systemd
   96   233     2796   132     132    2796  12436  systemd-journal
  105   284     1796   132     176    1796   5208   systemd-udev
  707    52     2660   132     172    2660  11688  in.telnetd
  744   968     3264   132    1700    3264   5800   brelay.sh
  835    52     2660   132     172    2660  11688  in.telnetd
  863   968     3264   132    1700    3264   5800   brelay.sh
  928   968     3996   132    2312    3996   6412   reflector.sh
  933   968     3976   132    2312    3976   6412   droputil.sh
  934   968     2140   132     528    2140   4628   oom.sh
  936   173     936    132     132     936    3068   xinetd
  945   968     1472   132     132    1472   4168   libvirtd.sh
  947   592    43164   132   3096    43164  154716  repm
  954    45      932    132     132     932    3132   rpcbind
  986   482     3476   132     132    3476  169288  libvirtd
  988    66      940    132     132     940    2724   rpc.statd
  993   968     928    132     132     928    4232   boothelper_evt.
 1017   21      640    132     132     640    2500   inotifywait
 1089  102    1200    132     132    1200   3328   rpc.mountd
 1328    9     2940   132     148    2940  13844   rotee
 1353   39     532    132     132     532    2336   sleep

!
!
!
```

The following is sample output from the **show processes memory platform information** command:

```
Switch# show processes memory platform location switch active R0

System memory: 3976852K total, 2762844K used, 1214008K free,
Lowest: 1214008K
  Pid  Text      Data  Stack  Dynamic  RSS    Total  Name
-----
    1  1246     4400   132    1308    4400   8328   systemd
   96   233     2796   132     132    2796  12436  systemd-journal
  105   284     1796   132     176    1796   5208   systemd-udev
  707    52     2660   132     172    2660  11688  in.telnetd
  744   968     3264   132    1700    3264   5800   brelay.sh
  835    52     2660   132     172    2660  11688  in.telnetd
  863   968     3264   132    1700    3264   5800   brelay.sh
  928   968     3996   132    2312    3996   6412   reflector.sh
  933   968     3976   132    2312    3976   6412   droputil.sh

!
!
!
```

The following is sample output from the **show processes memory platform sorted** command:

```
Switch# show processes memory platform sorted

System memory: 3976852K total, 2762884K used, 1213968K free,
Lowest: 1213968K
  Pid   Text      Data  Stack  Dynamic    RSS    Total      Name
-----
  9655  3787     264964  136    18004    264964  2675968      wcm
 17261   324     248588  132    103908   248588  2093076    fed main event
  7885 149848    684864  136      80     684864  1853548  linux_iosd-imag
 17891   398     75772  136    1888     75772   958240     sif_mgr
 17067  1087     77912  136    1796     77912   702184     platform_mgr
  4268   391    102084  136    5596    102084   482656     cli_agent
  4856   357     93388  132    3680     93388   340052      dbm
 29842  8722     64428  132    8056     64428   297068     fman_fp_image
  5960  9509     76088  136    3200     76088   287156     fman_rp
!
!
!
```

The following is sample output from the **show processes memory platform sorted location switch active R0** command:

```
Switch# show processes memory platform sorted location switch active R0

System memory: 3976852K total, 2763584K used, 1213268K free,
Lowest: 1213268K
  Pid   Text      Data  Stack  Dynamic    RSS    Total      Name
-----
  9655  3787     264968  136    18004    264968  2675968      wcm
 17261   324     249020  132    103908   249020  2093076    fed main event
  7885 149848    684912  136      80     684912  1853548  linux_iosd-imag
 17891   398     75884  136    1888     75884   958240     sif_mgr
 17067  1087     77820  136    1796     77820   702184     platform_mgr
  4268   391    102084  136    5596    102084   482656     cli_agent
  4856   357     93388  132    3680     93388   340052      dbm
 29842  8722     64428  132    8056     64428   297068     fman_fp_image
  5960  9509     76088  136    3200     76088   287156     fman_rp
!
!
!
```

show system mtu

To display the global maximum transmission unit (MTU) or maximum packet size set for the switch, use the **show system mtu** command in privileged EXEC mode.

```
show system mtu
```

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines For information about the MTU values and the stack configurations that affect the MTU values, see the **system mtu** command.

Examples This is an example of output from the **show system mtu** command:

show tech-support

To automatically run **show** commands that display system information, use the **show tech-support** command in the privilege EXEC mode.

show tech-support [**cef** | **cft** | **eigrp** | **evc** | **fnf** | **ipc** | **ipmulticast** | **ipsec** | **mfib** | **nat** | **nbar** | **onep** | **ospf** | **page** | **password** | **rsvp** | **subscriber** | **vrrp** | **wccp**]

Syntax Description	
cef	(Optional) Displays CEF related information.
cft	(Optional) Displays CFT related information.
eigrp	(Optional) Displays EIGRP related information.
evc	(Optional) Displays EVC related information.
fnf	(Optional) Displays flexible netflow related information.
ipc	(Optional) Displays IPC related information.
ipmulticast	(Optional) Displays IP multicast related information.
ipsec	(Optional) Displays IPSEC related information.
mfib	(Optional) Displays MFIB related information.
nat	(Optional) Displays NAT related information.
nbar	(Optional) Displays NBAR related information.
onep	(Optional) Displays ONEP related information.
ospf	(Optional) Displays OSPF related information.
page	(Optional) Displays the command output on a single page at a time. Use the Return key to display the next line of output or use the space bar to display the next page of information. If not used, the output scrolls (that is, it does not stop for page breaks). Press the Ctrl-C keys to stop the command output.
password	(Optional) Leaves passwords and other security information in the output. If not used, passwords and other security-sensitive information in the output are replaced with the label "<removed>".
rsvp	(Optional) Displays IP RSVP related information.
subscriber	(Optional) Displays subscriber related information.
vrrp	(Optional) Displays VRRP related information.
wccp	(Optional) Displays WCCP related information.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.2	This command was enhanced to display of the outputs of the following commands in the output modifier : <ul style="list-style-type: none"> • show power inline • show platform software ilpower details • show power inline police • show stack-power budgeting
	Cisco IOS XE Denali 16.1.1	This command was reintroduced.

Usage Guidelines

The output from the **show tech-support** command is very long. To better manage this output, you can redirect the output to a file (for example, **show tech-support > filename**) in the local writable storage file system or the remote file system. Redirecting the output to a file also makes sending the output to your Cisco Technical Assistance Center (TAC) representative easier.

You can use one of the following redirection methods:

- **> filename** - Redirects the output to a file.
- **>> filename** - Redirects the output to a file in append mode.

speed

To specify the speed of a 10/100/1000/2500/5000 Mbps port, use the **speed** command in interface configuration mode. To return to the default value, use the **no** form of this command.

speed **10** | **100** | **1000** | **2500** | **5000** | **auto** [**10** | **100** | **1000** | **2500** | **5000**] | **nonegotiate**
no speed

Syntax Description	
10	Specifies that the port runs at 10 Mbps.
100	Specifies that the port runs at 100 Mbps.
1000	Specifies that the port runs at 1000 Mbps. This option is valid and visible only on 10/100/1000 Mb/s ports.
2500	Specifies that the port runs at 2500 Mbps. This option is valid and visible only on multi-Gigabit-supported Ethernet ports.
5000	Specifies that the port runs at 5000 Mbps. This option is valid and visible only on multi-Gigabit-supported Ethernet ports.
auto	Detects the speed at which the port should run, automatically, based on the port at the other end of the link. If you use the 10 , 100 , 1000 , 1000 , 2500 , or 5000 keyword with the auto keyword, the port autonegotiates only at the specified speeds.
nonegotiate	Disables autonegotiation, and the port runs at 1000 Mbps.

Command Default The default is **auto**.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.
	Cisco IOS XE Denali 16.3.1	This command was modified. The following keywords were added: 2500 and 5000 . These keywords are visible only on multi-Gigabit Ethernet port supporting devices.

Usage Guidelines You cannot configure speed on 10-Gigabit Ethernet ports.

Except for the 1000BASE-T small form-factor pluggable (SFP) modules, you can configure the speed to not negotiate (**nonegotiate**) when an SFP module port is connected to a device that does not support autonegotiation.

The new keywords, **2500** and **5000** are visible only on multi-Gigabit (m-Gig) Ethernet supporting devices.

If the speed is set to **auto**, the switch negotiates with the device at the other end of the link for the speed setting, and then forces the speed setting to the negotiated value. The duplex setting remains configured on each end of the link, which might result in a duplex setting mismatch.

If both ends of the line support autonegotiation, we highly recommend the default autonegotiation settings. If one interface supports autonegotiation and the other end does not, use the auto setting on the supported side, but set the duplex and speed on the other side.

**Caution**

Changing the interface speed and duplex mode configuration might shut down and re-enable the interface during the reconfiguration.

For guidelines on setting the switch speed and duplex parameters, see the “Configuring Interface Characteristics” chapter in the software configuration guide for this release.

Verify your settings using the **show interfaces** privileged EXEC command.

Examples

The following example shows how to set speed on a port to 100 Mbps:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# speed 100
```

The following example shows how to set a port to autonegotiate at only 10 Mbps:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# speed auto 10
```

The following example shows how to set a port to autonegotiate at only 10 or 100 Mbps:

```
Device(config)# interface gigabitethernet1/0/1
Device(config-if)# speed auto 10 100
```

switchport block

To prevent unknown multicast or unicast packets from being forwarded, use the **switchport block** command in interface configuration mode. To allow forwarding unknown multicast or unicast packets, use the **no** form of this command.

switchport block multicast | unicast
no switchport block multicast | unicast

Syntax Description	<p>multicast Specifies that unknown multicast traffic should be blocked.</p> <p>Note Only pure Layer 2 multicast traffic is blocked. Multicast packets that contain IPv4 or IPv6 information in the header are not blocked.</p> <p>unicast Specifies that unknown unicast traffic should be blocked.</p>				
Command Default	Unknown multicast and unicast traffic is not blocked.				
Command Modes	Interface configuration				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Everest 16.6.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Everest 16.6.1	This command was introduced.
Release	Modification				
Cisco IOS XE Everest 16.6.1	This command was introduced.				
Usage Guidelines	<p>By default, all traffic with unknown MAC addresses is sent to all ports. You can block unknown multicast or unicast traffic on protected or nonprotected ports. If unknown multicast or unicast traffic is not blocked on a protected port, there could be security issues.</p> <p>With multicast traffic, the port blocking feature blocks only pure Layer 2 packets. Multicast packets that contain IPv4 or IPv6 information in the header are not blocked.</p> <p>Blocking unknown multicast or unicast traffic is not automatically enabled on protected ports; you must explicitly configure it.</p> <p>For more information about blocking packets, see the software configuration guide for this release.</p> <p>This example shows how to block unknown unicast traffic on an interface:</p> <pre>Device(config-if)# switchport block unicast</pre> <p>You can verify your setting by entering the show interfaces interface-id switchport privileged EXEC command.</p>				

system mtu

Syntax Description *bytes*

Command Default The default MTU size for all ports is 1500 bytes.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines

You can verify your setting by entering the **show system mtu** privileged EXEC command.

The switch does not support the MTU on a per-interface basis.

If you enter a value that is outside the allowed range for the specific type of interface, the value is not accepted.

voice-signaling vlan (network-policy configuration)

To create a network-policy profile for the voice-signaling application type, use the **voice-signaling vlan** command in network-policy configuration mode. To delete the policy, use the **no** form of this command.

voice-signaling vlan *vlan-id* [**cos** *cos-value* | **dscp** *dscp-value*] | **dot1p** [**cos** *l2-priority* | **dscp** *dscp*] | **none** | **untagged**

Syntax Description	
<i>vlan-id</i>	(Optional) The VLAN for voice traffic. The range is 1 to 4094.
cos <i>cos-value</i>	(Optional) Specifies the Layer 2 priority class of service (CoS) for the configured VLAN. The range is 0 to 7; the default is 5.
dscp <i>dscp-value</i>	(Optional) Specifies the differentiated services code point (DSCP) value for the configured VLAN. The range is 0 to 63; the default is 46.
dot1p	(Optional) Configures the phone to use IEEE 802.1p priority tagging and to use VLAN 0 (the native VLAN).
none	(Optional) Does not instruct the Cisco IP phone about the voice VLAN. The phone uses the configuration from the phone key pad.
untagged	(Optional) Configures the phone to send untagged voice traffic. This is the default for the phone.

Command Default No network-policy profiles for the voice-signaling application type are defined.
 The default CoS value is 5.
 The default DSCP value is 46.
 The default tagging mode is untagged.

Command Modes Network-policy profile configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines Use the **network-policy profile** global configuration command to create a profile and to enter network-policy profile configuration mode.

The voice-signaling application type is for network topologies that require a different policy for voice signaling than for voice media. This application type should not be advertised if all of the same network policies apply as those advertised in the voice policy TLV.

When you are in network-policy profile configuration mode, you can create the profile for voice-signaling by specifying the values for VLAN, class of service (CoS), differentiated services code point (DSCP), and tagging mode.

These profile attributes are contained in the Link Layer Discovery Protocol for Media Endpoint Devices (LLDP-MED) network-policy time-length-value (TLV).

To return to privileged EXEC mode from the network-policy profile configuration mode, enter the **exit** command.

This example shows how to configure voice-signaling for VLAN 200 with a priority 2 CoS:

```
Device(config)# network-policy profile 1  
Device(config-network-policy)# voice-signaling vlan 200 cos 2
```

This example shows how to configure voice-signaling for VLAN 400 with a DSCP value of 45:

```
Device(config)# network-policy profile 1  
Device(config-network-policy)# voice-signaling vlan 400 dscp 45
```

This example shows how to configure voice-signaling for the native VLAN with priority tagging:

```
Device(config-network-policy)# voice-signaling vlan dot1p cos 4
```

voice vlan (network-policy configuration)

To create a network-policy profile for the voice application type, use the **voice vlan** command in network-policy configuration mode. To delete the policy, use the **no** form of this command.

```
voice vlan vlan-id [cos cos-value | dscp dscp-value] | dot1p [cos l2-priority | dscp dscp] | none | untagged
```

Syntax Description	
vlan-id	(Optional) The VLAN for voice traffic. The range is 1 to 4094.
cos <i>cos-value</i>	(Optional) Specifies the Layer 2 priority class of service (CoS) for the configured VLAN. The range is 0 to 7; the default is 5.
dscp <i>dscp-value</i>	(Optional) Specifies the differentiated services code point (DSCP) value for the configured VLAN. The range is 0 to 63; the default is 46.
dot1p	(Optional) Configures the phone to use IEEE 802.1p priority tagging and to use VLAN 0 (the native VLAN).
none	(Optional) Does not instruct the Cisco IP phone about the voice VLAN. The phone uses the configuration from the phone key pad.
untagged	(Optional) Configures the phone to send untagged voice traffic. This is the default for the phone.

Command Default No network-policy profiles for the voice application type are defined.
 The default CoS value is 5.
 The default DSCP value is 46.
 The default tagging mode is untagged.

Command Modes Network-policy profile configuration

Command History	Release	Modification
	Cisco IOS XE Everest 16.6.1	This command was introduced.

Usage Guidelines Use the **network-policy profile** global configuration command to create a profile and to enter network-policy profile configuration mode.

The voice application type is for dedicated IP telephones and similar devices that support interactive voice services. These devices are typically deployed on a separate VLAN for ease of deployment and enhanced security through isolation from data applications.

When you are in network-policy profile configuration mode, you can create the profile for voice by specifying the values for VLAN, class of service (CoS), differentiated services code point (DSCP), and tagging mode.

These profile attributes are contained in the Link Layer Discovery Protocol for Media Endpoint Devices (LLDP-MED) network-policy time-length-value (TLV).

To return to privileged EXEC mode from the network-policy profile configuration mode, enter the **exit** command.

This example shows how to configure the voice application type for VLAN 100 with a priority 4 CoS:

```
Device(config)# network-policy profile 1  
Device(config-network-policy)# voice vlan 100 cos 4
```

This example shows how to configure the voice application type for VLAN 100 with a DSCP value of 34:

```
Device(config)# network-policy profile 1  
Device(config-network-policy)# voice vlan 100 dscp 34
```

This example shows how to configure the voice application type for the native VLAN with priority tagging:

```
Device(config-network-policy)# voice vlan dot1p cos 4
```