



Environmental Monitoring and Power Management

- [About Environmental Monitoring](#), on page 1
- [Power Management](#), on page 6
- [Feature History for Environmental Monitoring and Power Management](#), on page 27

About Environmental Monitoring

Environmental monitoring of chassis components provides early warning indications of possible component failure. This warning helps you to ensure the safe and reliable operation of your system and avoid network interruptions.

This section describes how to monitor critical system components so that you can identify and rapidly correct hardware-related problems.

Using CLI Commands to Monitor your Environment

Enter the `show environment [all | counters | history | location | sensor | status | summary | table]` command to display system status information. Keyword descriptions are listed in the following table.

Table 1: show environment Keyword Descriptions

Keyword	Purpose
all	Displays a detailed listing of all the environmental monitor parameters (for example, the power supplies, temperature readings, voltage readings, and so on). This is the default.
counters	Displays operational counters.
history	Displays the sensor state change history.
location	Displays sensors by location.
sensor	Displays the sensor summary.

Keyword	Purpose
status	Displays field-replaceable unit (FRU) operational status and power and power supply fan sensor information.
summary	Displays the summary of all the environment monitoring sensors.
table	Displays a sensor state table.

Displaying Environment Conditions

Supervisor modules and their associated line cards support multiple temperature sensors per card. The environment condition output includes the temperature reading from each sensor and the temperature thresholds for each sensor. These line cards support three thresholds: warning, critical, and shutdown.

The following example illustrates how to display the environment condition on a supervisor module. The thresholds appear within parentheses.

```
Device# show environment
```

```
Number of Critical alarms: 0
Number of Major alarms: 0
Number of Minor alarms: 0
```

Slot	Sensor	Current State	Reading	Threshold (Minor, Major, Critical, Shutdown)
R0	HotSwap: Volts	Normal	53	V DC na
R0	HotSwap: Power	Normal	231	Watts na
R0	Temp: Coretemp	Normal	46	Celsius (107,117,123,125) (Celsius)
R0	Temp: DopplerD	Normal	55	Celsius (107,117,123,125) (Celsius)
R0	V1: VX1	Normal	845	mV na
R0	V1: VX2	Normal	1499	mV na
R0	V1: VX3	Normal	1058	mV na
R0	V1: VX4	Normal	849	mV na
R0	V1: VX5	Normal	1517	mV na
R0	V1: VX6	Normal	1306	mV na
R0	V1: VX7	Normal	1007	mV na
R0	V1: VX8	Normal	1098	mV na
R0	V1: VX9	Normal	1205	mV na
R0	V1: VX10	Normal	1704	mV na
R0	V1: VX11	Normal	1208	mV na
R0	V1: VX12	Normal	1804	mV na
R0	V1: VX13	Normal	2518	mV na
R0	V1: VX14	Normal	3288	mV na
R0	Temp: outlet	Normal	39	Celsius (55 ,65 ,75 ,100) (Celsius)
R0	Temp: inlet	Normal	35	Celsius (45 ,55 ,65 ,72) (Celsius)

The following example illustrates how to display the LED status on a supervisor module.

```
Device# show hardware led
```

```
Current Mode: STATUS
```

```
SWITCH: C9407R
SYSTEM: AMBER
```

```
SUPERVISOR: ACTIVE
```

```
STATUS: (10) Te3/0/1:BLACK Te3/0/2:BLACK Te3/0/3:BLACK Te3/0/4:BLACK Te3/0/5:BLACK
Te3/0/6:BLACK Te3/0/7:BLACK Te3/0/8:BLACK Fo3/0/9:BLACK Fo3/0/10:BLACK
BEACON: BLACK
```

```
RJ45 CONSOLE: GREEN
FANTRAY STATUS: GREEN
FANTRAY BEACON: BLACK
POWER-SUPPLY 1 BEACON: BLACK
POWER-SUPPLY 3 BEACON: BLACK
```

Displaying On Board Failure Logging (OBFL) information

The OBFL feature records operating temperatures, hardware uptime, interrupts, and other important events and messages that can assist with diagnosing problems with line cards and supervisor modules installed in a switch. Data is logged to files stored in nonvolatile memory. When the onboard hardware is started up, a first record is made for each area monitored and becomes a base value for subsequent records. The OBFL feature provides a circular updating scheme for collecting continuous records and archiving older (historical) records, ensuring accurate data about the system. Data is recorded in one of two formats: continuous information that displays a snapshot of measurements and samples in a continuous file, and summary information that provides details about the data being collected. The data is displayed using the **show logging onboard** command. The message “No historical data to display” is seen when historical data is not available.

```
Switch#show logging onboard RP active voltage detail
```

```
-----
VOLTAGE SUMMARY INFORMATION
-----
```

```
Number of sensors      : 16
-----
```

Sensor	ID	Normal Range	Maximum Sensor Value
SYSTEM Rail-5.0	0	0 - 5	0
SYSTEM Rail-0.9PEX	1	0 - 5	1
SYSTEM Rail-0.9	2	0 - 5	1
SYSTEM Rail-1.8	3	0 - 5	0
SYSTEM Rail-3.3	4	0 - 5	1
SYSTEM Rail-2.5	5	0 - 5	1
SYSTEM Rail-1.5CPU	6	0 - 5	1
SYSTEM Rail-1.5	7	0 - 5	1
SYSTEM Rail-1.2	8	0 - 5	1
SYSTEM Rail-1.1	9	0 - 5	1
SYSTEM Rail-1.0	10	0 - 5	1
SYSTEM Rail-0.9CPU	11	0 - 5	1
SYSTEM Rail-0.85	12	0 - 5	2
SYSTEM Rail-0.85DOPv			
13		0 - 5	3
SYSTEM Rail-0.85DOPv^N	14	0 - 5	5
SYSTEM Rail-0.85DOPv^O	15	0 - 5	0

```
-----
Sensor Value
Total Time of each Sensor
-----
```

```
-----
No historical data
-----
```

```
-----
VOLTAGE CONTINUOUS INFORMATION
-----
```

```
Sensor                ID
-----
```

```
SYSTEM Rail-5.0      0
SYSTEM Rail-0.9PEX   1
SYSTEM Rail-0.9      2
SYSTEM Rail-1.8      3
SYSTEM Rail-3.3      4
SYSTEM Rail-2.5      5
SYSTEM Rail-1.5CPU   6
SYSTEM Rail-1.5      7
SYSTEM Rail-1.2      8
SYSTEM Rail-1.1      9
SYSTEM Rail-1.0     10
SYSTEM Rail-0.9CPU  11
SYSTEM Rail-0.85    12
SYSTEM Rail-0.85DOPv
13
SYSTEM Rail-0.85DOPv^N 14
SYSTEM Rail-0.85DOPv^O 15
-----
```

```
Time Stamp | Sensor Voltage 0V
MM/DD/YYYY HH:MM:SS | Sensor Value
-----
```

```
05/06/2015 16:42:51 0 1 1 0 1 1 1 1 1 1 1 1 2 3 5 0
05/06/2015 18:24:24 0 1 1 0 1 1 1 1 1 1 1 1 2 3 5 0
05/10/2015 17:53:42 0 1 1 0 1 1 1 1 1 1 1 1 2 3 5 0
08/30/2017 16:14:40 0 1 1 0 1 1 1 1 1 1 1 1 2 3 5 0
08/30/2017 23:34:24 0 1 1 0 1 1 1 1 1 1 1 1 2 3 5 0
08/31/2017 22:16:23 0 1 1 0 1 1 1 1 1 1 1 1 2 3 5 0
09/01/2017 00:57:15 0 1 1 0 1 1 1 1 1 1 1 1 2 3 5 0
-----
```

Emergency Actions

The chassis can power down a single card, providing a detailed response to over-temperature conditions on line cards. However, the chassis cannot safely operate when the temperature of the supervisor module itself exceeds the critical threshold. The supervisor module turns off the chassis' power supplies to protect itself from overheating. When this happens, you can recover the switch only by cycling the power on and off switches on the power supplies or by cycling the AC or DC inputs to the power supplies.

Shutdown temperature emergencies on a supervisor will trigger chassis shutdown. Shutdown temperature emergencies on a linecard will shut down the linecard but not the chassis. Critical temperature emergencies will trigger a warning message and the fan will be at its highest speed, but the chassis will not shut down. This applies to all slots.

The following table lists temperature emergencies but does not distinguish between critical and shutdown emergencies.

Table 2: Emergency and Action

Case 1. Complete fan failure emergency.	SYSLOG message displays and the chassis shuts down.
Case 2. Temperature emergency on a line card.	Power down the line card.

Case 3. Temperature emergency on a power supply. When the shutdown alarm threshold is exceeded, all the power supplies will shut down.	Power cycle the device to recover from power supply shut down.
Case 4. Temperature emergency on the active supervisor module.	Power down the chassis.

System Alarms

Any system has two types of alarms: major and minor. A major alarm indicates a critical problem that could lead to system shutdown. A minor alarm is informational—it alerts you to a problem that could become critical if corrective action is not taken.

The following table lists the possible environment alarms.

Table 3: Possible Environmental Alarms

A temperature sensor over its warning threshold	minor
A temperature sensor over its critical threshold	major
A temperature sensor over its shutdown threshold	major
A partial fan failure	minor
A complete fan failure	major
Note A complete fan failure alarm does not result in system shutdown.	

Fan failure alarms are issued as soon as the fan failure condition is detected and are canceled when the fan failure condition clears. Temperature alarms are issued as soon as the temperature reaches the threshold temperature. An LED on the supervisor module indicates whether an alarm has been issued.

When the system issues a major alarm, it starts a timer whose duration depends on the alarm. If the alarm is not canceled before the timer expires, the system takes emergency action to protect itself from the effects of overheating. The timer values and the emergency actions depend on the type of supervisor module.



Note Refer to the *Hardware Installation Guide* for information on LEDs, including the startup behavior of the supervisor module system LED.

Table 4: Alarms on Supervisor Module

Event	Alarm Type	Supervisor LED Color	Description and Action
Card temperature exceeds the critical threshold.	Major	Red	Syslog message displays when the alarm is issued.
Card temperature exceeds the shutdown threshold.	Major	Red	Syslog message displays when the alarm is issued.

Event	Alarm Type	Supervisor LED Color	Description and Action
Chassis temperature exceeds the warning threshold.	Minor	Orange	Syslog message displays when the alarm is issued.
Chassis fan tray experiences partial failure.	Minor	Orange	Syslog message displays when the alarm is issued.
Chassis fan tray experiences complete failure.	Major	Red	Syslog message displays when the alarm is issued.

Power Management

This section describes the power management feature in the Cisco Catalyst 9400 Series Switches and the aspects of power management that you can control and configure. For information about the hardware, including installation, removal and power supply specifications, see the *Cisco Catalyst 9400 Series Switches Hardware Installation Guide*.

Power Supply Modes

Cisco Catalyst 9400 Series Switches offer combined and redundant configuration modes for power supplies.

Combined Mode

This is the default power supply mode.

The system operates on one to eight power supplies. All available power supplies are active and sharing power and can operate at up to 100 percent capacity.

Available power in the combined mode is the sum of the individual power supplies.

Redundant Mode

In a redundant configuration, a given power supply module can be either active, or in standby mode, and switch to active when required.

You can configure an n+1 or an n+n redundant mode.

- n+1 redundant Mode—n number of power supply modules are active (n can be one to seven power supply modules). +1 is the power supply module reserved for redundancy.

The default standby power supply slot is PS8. Specify a standby slot, by entering the **power redundancy-mode redundant n+1 standby-PSslot** command.

- n+n redundant Mode—n number of power supplies are active and n number of power supply modules are configured as standby.

The default standby slots for this mode are PS5 through PS8. Specify the standby slots, by entering the **power redundancy-mode redundant n+n standby-PSslots** command.

Enter the **show power detail** command in privileged EXEC mode, to display detailed information about the currently configured power supply mode. See [show power detail, on page 8](#).

Operating States

The operating state refers to the system's capacity to respond to a situation where all active power supply modules fail. The system deems the chassis operating state as full protected, normal protected, or combined depending on these factors:

- Total active output power, which is the total output power that is available from all the active power supply modules in the chassis.
- Required budgeted power, which is the power the system requires only for the supervisor modules, switching modules (line cards), and fan tray to operate in the chassis.

In the **show** command outputs (**show power**, **show power detail**), this is displayed as `System Power`.

- Total standby output power, which is the total output power that is available from all the power supply modules in the chassis that are configured as standby.

Whether in the n+1 or n+n mode, the system considers the chassis in a full protected state, when ALL of these conditions are met:

- Total active output power is greater than the required budgeted power
- Total standby output power is greater than or equal to total active output power

Whether in the n+1 or n+n mode, the system considers the chassis in a normal protected state, when ALL of these conditions are met:

- Total active output power is greater than the required budgeted power
- Total standby output power is lesser than the total active output power

The system operates in a combined state, when it encounters these conditions (any redundancy configuration is rejected):

- Total active output power is lesser than the required budgeted power
- A standby power supply module is not configured or installed.

Example: Operating State

The following sample output of the **show power** command, shows a power supply configuration that is in a full protected state.

Here, the power supply modules in slots 1 and 2 are active and sharing power; power supply modules in slots 7 and 8 are in standby. The required budgeted power is 2115W and inline power requires 3185W. The switch is in a full protected state because

- Total active output power (`PS1 Capacity + PS2 Capacity`) is greater than the required budgeted power (`System Power - Maximim Used 2115`) and
- Total standby output power (`PS7 Capacity + PS8 Capacity`) is equal to total active output power (`PS1 Capacity + PS2 Capacity`).

show power detail

```

Device# show power
Power          Model No          Type Capacity Status      1    2    3    4
Supply
-----
PS1           C9400-PWR-3200AC AC   3200 W   active    good good good good
PS2           C9400-PWR-3200AC AC   3200 W   active    good good good good
PS7           C9400-PWR-3200AC AC   3200 W   standby   n.a. n.a. n.a. n.a.
PS8           C9400-PWR-3200AC AC   3200 W   standby   n.a. n.a. n.a. n.a.

```

```

PS Current Configuration Mode: N+N redundant
PS Current Operating State: Full protected

```

```

Power supplies currently active: 2
Power supplies currently available: 3

```

```

Power Summary Maximum
(in Watts) Used Available
-----
System Power 2115 2115
Inline Power 3185 4285
-----

```

```

Total 5300 6400
Automatic Linecard Shutdown: Enabled
Power Budget Mode : Dual Sup

```

```
<output truncated>
```

Information about the operating state is also displayed in the **show power detail** command output. See [show power detail, on page 8](#).

show power detail

The **show power detail** command includes the output of **show power** and **show power module** privileged EXEC commands.

The following is sample output of the **show power detail** command with a different type power supply module in each example. In all the examples, The power supply mode and operating state is combined:

```

Switch# show power detail
Power          Model No          Type Capacity Status      Fan States
Supply         1    2    3    4
-----
PS1           C9400-PWR-3200DC dc   3200 W   active    good good good good
PS2           C9400-PWR-3200DC dc   3200 W   active    good good good good
PS3           C9400-PWR-3200DC dc   3200 W   active    good good good good
PS4           C9400-PWR-3200DC dc   3200 W   active    good good good good
PS5           C9400-PWR-3200DC dc   3200 W   active    good good good good
PS6           C9400-PWR-3200DC dc   3200 W   active    good good good good
PS7           C9400-PWR-3200DC dc   3200 W   active    good good good good
PS8           C9400-PWR-3200DC dc   3200 W   active    good good good good

```

```

PS Current Configuration Mode : Combined
PS Current Operating State    : Combined

```

```

Power supplies currently active : 8
Power supplies currently available : 8

```

```

Power Summary Maximum
(in Watts) Used Available
-----

```



```

System Power  2030  2030
Inline Power  106  23570
-----
Total         2136  25600
    
```

Automatic Linecard Shutdown : Enabled
 Power Budget Mode : Dual Sup

Mod	Model No	autoLC Priority	Power State	Budget	Instantaneous	Peak	Out of Reset	In Reset
1	C9400-LC-24XS	0	accepted	200	87	88	200	10
2	C9400-LC-48T	1	accepted	65	35	43	65	5
3	C9400-SUP-1	0	accepted	400	235	253	400	130
4	C9400-SUP-1	0	accepted	400	235	253	400	130
5	C9400-LC-48T	2	accepted	65	35	37	65	5
6	C9400-LC-24XS	3	accepted	200	87	88	200	10
7	C9400-LC-48UX	4	accepted	350	189	203	350	15
--	Fan Tray	0	accepted	350	--	--	350	--

Total	2030							

Switch# show power detail

Power Supply	Model No	Type	Capacity	Status	Fan States			
					1	2	3	4
PS1	C9400-PWR-2100AC	AC	2100 W	active	good	good	good	good
PS2	C9400-PWR-2100AC	AC	2100 W	active	good	good	good	good
PS3	C9400-PWR-2100AC	AC	2100 W	active	good	good	good	good
PS4	C9400-PWR-2100AC	AC	2100 W	active	good	good	good	good
PS5	C9400-PWR-2100AC	AC	2100 W	active	good	good	good	good
PS6	C9400-PWR-2100AC	AC	2100 W	active	good	good	good	good
PS7	C9400-PWR-2100AC	AC	2100 W	active	good	good	good	good
PS8	C9400-PWR-2100AC	AC	2100 W	active	good	good	good	good

PS Current Configuration Mode : Combined
 PS Current Operating State : Combined

Power supplies currently active : 8
 Power supplies currently available : 8

```

Power Summary          Maximum
(in Watts)  Used  Available
-----
System Power  2030  2030
Inline Power  106  14770
-----
Total         2136  16800
    
```

Automatic Linecard Shutdown : Enabled
 Power Budget Mode : Dual Sup

Mod	Model No	autoLC Priority	Power State	Budget	Instantaneous	Peak	Out of Reset	In Reset
1	C9400-LC-24XS	0	accepted	200	87	88	200	10
2	C9400-LC-48T	1	accepted	65	35	43	65	5
3	C9400-SUP-1	0	accepted	400	235	253	400	130
4	C9400-SUP-1	0	accepted	400	235	253	400	130

Power Management Considerations

```

5    C9400-LC-48T      2    accepted  65    35    37    65    5
6    C9400-LC-24XS    3    accepted  200   87    88    200  10
7    C9400-LC-48UX    4    accepted  350  189   203   350  15
--   Fan Tray         0    accepted  350   --    --    350  --
-----
Total  2030

```

Switch# **show power detail**

```

Power
Supply  Model No          Type  Capacity  Status  Fan States
-----  -----
1      2      3      4
-----  -----
PS1    C9400-PWR-3200AC  AC    3200 W   active  good good good good
PS2    C9400-PWR-3200AC  AC    3200 W   active  good good good good
PS3    C9400-PWR-3200AC  AC    3200 W   active  good good good good
PS4    C9400-PWR-3200AC  AC    3200 W   active  good good good good
PS5    C9400-PWR-3200AC  AC    3200 W   active  good good good good
PS6    C9400-PWR-3200AC  AC    3200 W   active  good good good good
PS7    C9400-PWR-3200AC  AC    3200 W   active  good good good good
PS8    C9400-PWR-3200AC  AC    3200 W   active  good good good good

```

```

PS Current Configuration Mode : Combined
PS Current Operating State    : Combined

```

```

Power supplies currently active   : 8
Power supplies currently available : 8

```

```

Power Summary          Maximum
(in Watts)            Used    Available
-----
System Power          2030    2030
Inline Power          106     23570
-----
Total                  2136    25600

```

```

Automatic Linecard Shutdown : Enabled
Power Budget Mode           : Dual Sup

```

```

Mod  Model No          autoLC  Power  Budget  Instantaneous  Peak  Out of  In
-----  -----  -----  -----  -----  -----  -----  -----  -----
1     C9400-LC-24XS      0     accepted  200    87    43    200    10
2     C9400-LC-48T      1     accepted  65    35    43    65    5
3     C9400-SUP-1        0     accepted  400   235   253   400   130
4     C9400-SUP-1        0     accepted  400   235   253   400   130
5     C9400-LC-48T      2     accepted  65    35    37    65    5
6     C9400-LC-24XS      3     accepted  200   87    88    200   10
7     C9400-LC-48UX      4     accepted  350  189   203   350   15
--   Fan Tray         0     accepted  350   --    --    350   --
-----
Total  2030

```

Power Management Considerations

It is possible to configure a switch that requires more power than the power supplies provide.

- The power requirements for the installed modules exceed the power provided by the power supplies.

- If the switch has a single power supply module that is unable to meet power requirements, the following error message is displayed:

```
Insufficient power supplies present for specified configuration
```

The **show power** command output will also indicate this state of insufficient input power.

- If the switch has more than one power supply module, and requirements for the installed modules still exceed the power provided by the power supplies, the following error message is displayed:

```
Insufficient number of power supplies (2) are installed for power redundancy mode
```

The **show power** command output will also indicate this state of insufficient input power.

If you attempt to insert additional modules into your switch and exceed the power supply, the switch immediately places the newly inserted module into reset mode, and the following error message is displayed:

```
Power doesn't meet minimum system power requirement.
```

Additionally, if you power down a functioning chassis and insert an additional linecard or change the module configuration so that the power requirements exceed the available power, one or more linecards enter reset mode when you power on the switch again.

- The power requirements for the PoE exceed the PoE provided by the power supplies

If you have too many IP phones drawing power from the system, power to IP phones is cut, and some phones may be powered down to reduce the power requirements to match the power supplies.

A module in reset mode continues to draw power as long as it is installed in the chassis; use the **show power module** command to determine how much power is required to bring the module online.

To compute the power requirements for your system and verify that your system has enough power, add the power consumed by the supervisor module(s), the fan trays, and the installed linecards (including PoE). For PoE, total the requirements for all the phones.

The 802.3at-compliant PoE modules can consume up to 60W of PoE. Be sure to add 60W to your PoE requirements for each 802.3at-compliant PoE module to ensure that the system has adequate power for the PDs connected to the switch.

For all POE supported line cards (C9400-LC-48UX, C9400-LC-48U, C9400-LC-48P), PoE consumption is equal to the administrative PoE.

If a powered device (PD) consumes more power than allocated power, the following Imax error is generated; further the port is shutdown and in a faulty state:

```
*Jun 21 10:06:06.149: %ILPOWER-3-CONTROLLER_PORT_ERR: Controller port error, Interface
Gi7/0/13: Power Controller reports power Imax error
*Jun 21 10:06:06.208: %ILPOWER-5-IEEE_DISCONNECT: Interface Gi7/0/13: PD removed
Device# show power inline 7/0/13
Gi7/0/13 auto faulty 0.0 0.0 n/a n/a
```

Selecting a Power Supply Mode

Your switch hardware configuration dictates which power supply or supplies you should use. For example, if your switch configuration requires more power than a single power supply provides, use the [Cisco power calculator](#) on cisco.com to help determine the number of power supplies that is required for either combined or redundant mode.

Configuring the Redundant Mode

By default, the power supplies in the switch are set to operate in combined mode. To effectively use redundant mode, note the following:

- If you have the power supply mode set to redundant mode and only one power supply installed, your switch accepts the configuration but operates without redundancy.
- Choose a power supply module that is powerful enough to support the switch configuration.
- Use the [Cisco Power Calculator](#) to help assess the number of power supplies required by the system. Ensure that you install a sufficient number of power supply modules, so that the chassis and PoE requirements are less than the maximum available power. Power supplies automatically adjust the power resources at startup to accommodate the chassis and PoE requirements. Modules are brought up first, followed by IP phones.
- For optimal use of system power, choose power supply modules of the same capacity when configuring a redundant mode on the switch.

To configure redundant mode, perform this task:

SUMMARY STEPS

1. **configure terminal**
2. **power redundancy-mode redundant** [**n+1** *standby-PSslot* | **n+1** *standby-PSslot*]
3. **end**
4. **show power**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters the global configuration mode.
Step 2	power redundancy-mode redundant [n+1 <i>standby-PSslot</i> n+1 <i>standby-PSslot</i>] Example: Device(config)# power redundancy-mode redundant n+1 5 OR Device(config)# power redundancy-mode redundant n+n 5 6 7 8	You can choose from these options: <ul style="list-style-type: none"> • power redundancy-mode redundant n+1 <i>standby-PSslot</i>—Configures the n+1 redundant mode. Enter the standby power supply module slot number. The default standby slot in this redundant mode is 8. In the n+1 example here, the power supply module in slot PS5 (and not the default PS8) is the designated standby module and has been configured accordingly. Operational power supply modules installed in all other slots, are active. • power redundancy-mode redundant n+n <i>standby-PSslot</i>—Configures the n+n redundant mode. Enter the standby power supply module slot numbers. The default standby slots in this redundant mode are 5 through 8.

	Command or Action	Purpose
		<p>In the n+n example here, the power supply modules in slots PS5, PS6, PS7, and PS8 are being used as standby modules, and have been configured accordingly. Operational power supply modules installed in all other slots, are active.</p> <p>If you are using power supply modules of different capacities, you must also observe these guidelines:</p> <ul style="list-style-type: none"> • For the n+1 redundant mode, configure the power supply module with the highest wattage or capacity as the standby. • For the n+n redundant mode – Ensure that the total standby output power is greater than or equal to the total active output power.
Step 3	<p>end</p> <p>Example: Device(config)# end</p>	Exits global configuration mode.
Step 4	<p>show power</p> <p>Example: Device# show power</p>	Displays the power redundancy mode information.

Configuring the Combined Mode

To use the combined mode effectively, follow these guidelines:

- Choose a power supply module that provides enough power so that the chassis and PoE requirements are less than the maximum available power. Power supply modules automatically adjust the power resources at startup, to accommodate the chassis and PoE requirements.
- If you have the power supply mode set to combined mode and only one power supply installed, your switch accepts the configuration, but power is available from only one power supply.
- When your switch is configured to combined mode, available power is the sum of the individual power supplies

To configure combined mode on your switch, perform this task:

Before you begin

Note that this mode utilizes the available power from all the power supplies; however, your switch has no power redundancy.

SUMMARY STEPS

1. **configure terminal**
2. **power redundancy-mode combined**

3. `end`
4. `show power`

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: Device# <code>configure terminal</code>	Enters the global configuration mode.
Step 2	power redundancy-mode combined Example: Device(config)# <code>power redundancy-mode combined</code>	Sets the power supply mode to combined mode.
Step 3	end Example: Device(config)# <code>end</code>	Exits global configuration mode.
Step 4	show power Example: Device# <code>show power</code>	Displays the power redundancy mode information.

Power Budgeting for Supervisor Modules

The power budget, or required budgeted power, is the power the system *requires* and *reserves* for supervisor modules, switching modules (line cards), and the fan tray to operate in the chassis. In the **show power**, and **show power detail** command outputs, this is displayed as `System Power`. The system does not allow any part of this required budgeted power to be automatically redirected for use by other components in the system.

This section describes how power budgeting works with respect to supervisor modules and the configuration options that are available.

By default, the system reserves power for a redundant setup, to ensure high availability. This means that the system reserves the power required by both the supervisor modules in the chassis, as part of the required budgeted power (`System Power`).

You can also configure the system to reserve power for a single supervisor. This configuration option is suited to situations where a single supervisor is installed and the total available power is not sufficient to enable all line cards and PoE ports. In such a scenario, configuring the switch to reserve power for a single supervisor enables you to free-up power and use it for other components, such as PoE ports, or line cards instead.

Note the following restrictions and guidelines:

- If you have installed both supervisor modules, you cannot configure the power budget mode for a single supervisor. The system rejects the configuration and following message is displayed: `cannot enable single sup mode when remote supervisor is present`.
- If you have installed both supervisor modules and the default setting is effective, you must install the necessary number of power supply modules to meet overall system requirements (including line cards,

fan tray and POE ports). Do not remove the second supervisor to remedy a situation where there is an insufficient number of power supply modules.

- If you have installed a single supervisor module and configured the power budget mode for a single supervisor, do not install a second supervisor. If you do, one of two things may happen:
 - The system may reject configuration, accompanied by the following error message: `ERROR: Remote supervisor has been detected in slot 6. System is configured to SINGLE-SUP power mode. Remove remote supervisor IMMEDIATELY.`
 - If this action is accompanied by a low power condition where the system does not have sufficient power for the second supervisor, the system may shut down.

For information about how to safely move from a single to a dual supervisor setup, see task *Moving from a Single to a Dual Supervisor Setup* below.

The following tasks describe the available configuration options:

Configuring the Power Budget Mode for a Single Supervisor

Beginning in the privileged EXEC mode, perform these steps to configure the power budget mode for a single supervisor setup:

Before you begin

Ensure that these prerequisites are met:

- You have installed only one supervisor module in the chassis.
- You have installed a blank in the second supervisor slot.

SUMMARY STEPS

1. `configure terminal`
2. `power budget mode {single-sup}`
3. `end`

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: Device# <code>configure terminal</code>	Enters the global configuration mode.
Step 2	power budget mode {single-sup} Example: Device(config)# <code>power budget mode single-sup</code>	Reserves power for one supervisor module in the chassis.
Step 3	end Example: Device(config)# <code>end</code>	Exits the global configuration mode.

Moving from a Single to a Dual Supervisor Setup

Beginning in the privileged EXEC mode, perform these steps to move from single to a dual supervisor setup:

Before you begin

Calculate the required power for a dual supervisor setup. Cisco Power Calculator (CPC) enables you to calculate the power supply requirements for a specified configuration:

1. Go to <https://cpc.cloudapps.cisco.com/cpc> → **Launch Cisco Power Calculator**.
2. Select applicable values for the `Product Family`, `Chassis`, `Supervisor Engine` (both supervisor slots), `Input Voltage`, and `Line Card` fields. Click **Next** to display results.
3. In the results that are displayed, locate the `Configuration Details` section and note the `Output Power` for the supervisor module. This is the amount of spare power that must be available in the system to safely install the second supervisor.
4. Enter the **show power** command in privileged EXEC mode.

This command displays power supply configuration information.

In the output, check the difference between the `Total Maximum Available` and `Total Used`, this must be greater than what the CPC says in the `Output Power` column for the supervisor module. If this is the case, proceed with the task, if not, first install the required number of additional power supply modules.

SUMMARY STEPS

1. **configure terminal**
2. **no power budget mode {single-sup}**
3. **end**
4. Insert the second supervisor module in the supervisor slot.

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters the global configuration mode.
Step 2	no power budget mode {single-sup} Example: Device(config)# no power budget mode single-sup	Reverts to the default setting where the system reserves power for both the supervisor modules in the chassis.
Step 3	end Example: Device(config)# end	Exits configuration mode.
Step 4	Insert the second supervisor module in the supervisor slot.	For detailed steps, see the Supervisor Module Installation Note → Removal and Replacement Procedures, on cisco.com.

Enabling Auto Line Card Shutdown

Auto line card shutdown or autoLC, is disabled by default. This feature allows you to configure line card power priority. It enables the hardware to automatically shut down line cards in the event of a power constraint, until the total available power becomes greater than or equal to the total used power displayed in the power summary of the **show power** command. This feature provides deterministic behavior of the switch in case of power supply failure events and prioritized line card shutdown events.

To configure autoLC shutdown and line card power priority, perform the following task:

SUMMARY STEPS

1. **configure terminal**
2. **power supply autoLC shutdown**
3. **power supply autoLCpriority***physical-slot-number*
4. **end**
5. **show power module**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters the global configuration mode.
Step 2	power supply autoLC shutdown Example: Device(config)# power supply autoLC shutdown	(Optional) Enables automatic shutdown of line cards in case of a power supply failure event.
Step 3	power supply autoLCpriority <i>physical-slot-number</i> Example: Device(config)# power supply autoLC priority 1 2 5 6 7	(Optional) Configures line card power priority. Enter the line card slot numbers to indicate their autoLC shutdown priority. The system assigns the highest priority (0) to the slot number you enter first, and this is the <i>last</i> to be shut down in case of a failure. The system does not accept a partial list of line card slot numbers. For example, for a 7-slot chassis, you must mention all the five line card slots. In the example configuration provided on the left, the physical slot number order and system-assigned priority for a 7-slot chassis is as follows:

Configured Order	autoLC Priority
1	0 (shuts down last)
2	1
5	2
6	3

	Command or Action	Purpose	
		Configured Order	autoLC Priority
		7	4 (shuts down first)
		<p>If you do not specify an order and autoLC shutdown is enabled, then by default the system shuts down line cards from the highest to the lowest physical slot number. Accordingly, default configuration is as follows:</p> <ul style="list-style-type: none"> • 4-slot chassis: power supply autoLC priority 1 4 • 7-slot chassis: power supply autoLC priority 1 2 5 6 7 • 10-slot chassis: power supply autoLC priority 1 2 3 4 7 8 9 10 	
Step 4	end Example: Device(config)# end	Exits global configuration mode.	
Step 5	show power module Example: Device# show power module	Displays power redundancy mode information, and includes information about whether the autoLC is enabled.	

Powering Down a Line Card

If your system does not have enough power for all modules installed in the switch, you can power down one or more line cards and place them in power-off mode.

To power down a line card, perform this task:

SUMMARY STEPS

1. **configure terminal**
2. **hw-module subslot *card slot/subslot number* shutdown unpowered**
3. **end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	configure terminal Example: Device# configure terminal	Enters the global configuration mode.

	Command or Action	Purpose
Step 2	hw-module subslot card slot/subslot number shutdown unpowered Example: Device(config)# hw-module subslot 1/0 shutdown unpowered	Powers down the specified module by placing it in low power mode.
Step 3	end Example: Device(config)# end	Exits the global configuration mode

Configuration Examples for Power Supply Modes and Operating States

The examples in this section illustrate different power supply setups. They describe how the [Power Supply Module Installation Considerations](#) in the *Cisco Catalyst 9400 Series Switches Hardware Installation Guide* and the *Operating States* section in this document affect possible power supply mode configurations. Both combined and redundant power supply modes, and the resulting operating states are covered.

Example: Combined Mode and State (AC- and DC-Input)

The table below represents the two rows of power supply slots in a Cisco Catalyst 9400 Series chassis. Power supply slots are indicated as PS1, PS2, and so on. For this example, power supply modules of the same capacity (3200W) have been installed in slots 1 through 8. Slots 1 through 4 have AC-input power supply modules and slots 5 through 8 have DC-input power supply modules.

PS1 (Active) C9400-PWR-3200AC	PS2 (Active) C9400-PWR-3200AC	PS3 (Active) C9400-PWR-3200AC	PS4 (Active) C9400-PWR-3200AC
PS5 (Active) C9400-PWR-3200DC	PS6 (Active) C9400-PWR-3200DC	PS7 (Active) C9400-PWR-3200DC	PS8 (Active) C9400-PWR-3200DC

All available power supply modules are active and sharing power and can operate at up to 100 percent capacity. The switch is in a combined operating state, because a standby power supply module is not configured. This is a valid configuration for the combined mode, because:

- All installed power supply modules are active and available.
In the sample output, see `Status= active`.
- All installed power supply modules are of the same capacity.
In the sample output, see `Capacity = 3200 W`.
- All installed AC-input power supply modules have an AC-input voltage of 220 VAC
In the sample output, the `Capacity` fields for the AC-input modules reflect this.

The following is sample output of this setup (the **show power** privileged EXEC command):

```
Switch# show power
```

```
Power
```

```
Fan States
```

Example: Combined Mode and State (DC-Input Only)

```

Supply  Model No          Type  Capacity  Status      1      2
-----  -
PS1     C9400-PWR-3200AC      ac    3200 W    active      good  good
PS2     C9400-PWR-3200AC      ac    3200 W    active      good  good
PS3     C9400-PWR-3200AC      ac    3200 W    active      good  good
PS4     C9400-PWR-3200AC      ac    3200 W    active      good  good
PS5     C9400-PWR-3200DC      dc    3200 W    active      good  good
PS6     C9400-PWR-3200DC      dc    3200 W    active      good  good
PS7     C9400-PWR-3200DC      dc    3200 W    active      good  good
PS8     C9400-PWR-3200DC      dc    3200 W    active      good  good

```

```

PS Current Configuration Mode : Combined
PS Current Operating State    : Combined

```

```

Power supplies currently active   : 8
Power supplies currently available : 8

```

```

Power Summary          Maximum
(in Watts)            Used    Available
-----
System Power          3505    3505
Inline Power           0      22095
-----
Total                  3505    25600

```

In case of failure in the combined mode, each operational power supply increases its output. If the output power does not meet system requirements and the **power supply autolc shutdown** command is disabled, then all the operational power supply modules may be overloaded and go into overcurrent shutdown. All system power is then lost. We recommend enabling the **power supply autolc shutdown** command.

Other valid configuration options for the combined mode:

- All installed modules are DC-input power supply modules; all modules are configured as active.
- All installed modules are AC-input power supply modules of the same capacity and with the same AC-input voltage level; all modules are configured as active.

Example: Combined Mode and State (DC-Input Only)

The table below represents the two rows of power supply slots in a Cisco Catalyst 9400 Series chassis. Power supply slots are indicated as PS1, PS2, and so on. For this example, power supply modules of the same capacity and type (C9400-PWR-3200DC) have been installed in slots 1 through 8.

PS1 (Active) C9400-PWR-3200DC	PS2 (Active) C9400-PWR-3200DC	PS3 (Active) C9400-PWR-3200DC	PS4 (Active) C9400-PWR-3200DC
PS5 (Active) C9400-PWR-3200DC	PS6 (Active) C9400-PWR-3200DC	PS7 (Active) C9400-PWR-3200DC	PS8 (Active) C9400-PWR-3200DC

All available power supply modules are active and sharing power and can operate at up to 100 percent capacity. The switch is in a combined operating state, because a standby power supply module is not configured. There are no other conditions to consider for this setup.

The following is sample output of this setup (the **show power** privileged EXEC command):

```
Switch# show power
```

Power Supply	Model No	Type	Capacity	Status	Fan States			
					1	2	3	4
PS1	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good
PS2	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good
PS3	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good
PS4	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good
PS5	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good
PS6	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good
PS7	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good
PS8	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good

PS Current Configuration Mode : Combined
 PS Current Operating State : Combined

Power supplies currently active : 8
 Power supplies currently available : 8

Power Summary (in Watts)	Used	Maximum Available
System Power	2030	2030
Inline Power	106	23570
Total	2136	25600

Automatic Linecard Shutdown : Enabled
 Power Budget Mode : Dual Sup

Mod	Model No	autoLC Priority	Power State	Budget	Instantaneous	Peak	Out of Reset	In Reset
1	C9400-LC-48XS	0	accepted	200	85	90	200	10
2	C9400-LC-48T	1	accepted	65	35	43	65	5
3	C9400-SUP-1	0	accepted	400	235	253	400	130
4	C9400-SUP-1	0	accepted	400	235	253	400	130
5	C9400-LC-48T	2	accepted	65	35	37	65	5
6	C9400-LC-24XS	3	accepted	200	87	88	200	10
7	C9400-LC-48UX	4	accepted	350	189	203	350	15
--	Fan Tray	0	accepted	350	--	--	350	--
Total	2030							

In case of failure in the combined mode, each operational power supply increases its output. If the output power does not meet system requirements and the **power supply autolc shutdown** command is disabled, then all the operational power supply modules may be overloaded and go into overcurrent shutdown. All system power is then lost. We recommend enabling the **power supply autolc shutdown** command.

Other valid configuration options for the combined mode:

- A mix of AC- and DC-input power supply modules are installed and they are all of the same capacity. Further, all the AC-input modules in this setup have the same AC-input voltage level; all modules are configured as active.
- All installed modules are AC-input power supply modules of the same capacity and with the same AC-input voltage level; all modules are configured as active.

Example: n+1 Redundant Mode (Power Supply Modules of the Same Capacity but Different Types + Normal Protected State)

The table below represents the two rows of power supply slots in a Cisco Catalyst 9400 Series chassis. Power supply slots are indicated as PS1, PS2, and so on. For this example, power supply modules of the same capacity (3200W) have been installed in slots 1 through 8. Slots 1 through 4 have AC-input power supply modules and slots 5 through 8 have DC-input power supply modules. Slot 8 has the +1 standby power supply module.

PS1 (Active) C9400-PWR-3200AC	PS2 (Active) C9400-PWR-3200AC	PS3 (Active) C9400-PWR-3200AC	PS4 (Active) C9400-PWR-3200AC
PS5 (Active) C9400-PWR-3200DC	PS6 (Active) C9400-PWR-3200DC	PS7 (Active) C9400-PWR-3200DC	PS8 (Standby) C9400-PWR-3200DC

The switch meets all the required conditions for an n+1 redundant mode with a normal protected state.

- It is in an n+1 redundant mode, because one power supply module is configured as standby.

It also meets all the n+1 redundant mode conditions:

- A mix of AC-input and DC-input power supply modules are installed and all modules are of the same capacity.

In the same output, see `Capacity = 3200 W`.

- All installed AC-input power supply modules have an AC-input voltage of 220 VAC (the `Capacity` fields for the AC-input modules reflect this).

- It is in a normal protected state, because:

Total standby output power (3200 W) is lesser than total active output power (22400).

and

Total active output power (22400) is greater than the required budgeted power (3505)

```
Switch# show power
Power
Supply Model No          Type Capacity Status      Fan States
-----
PS1    C9400-PWR-3200AC      ac   3200 W   active     good  good
PS2    C9400-PWR-3200AC      ac   3200 W   active     good  good
PS3    C9400-PWR-3200AC      ac   3200 W   active     good  good
PS4    C9400-PWR-3200AC      ac   3200 W   active     good  good
PS5    C9400-PWR-3200DC      dc   3200 W   active     good  good
PS6    C9400-PWR-3200DC      dc   3200 W   active     good  good
PS7    C9400-PWR-3200DC      dc   3200 W   active     good  good
PS8    C9400-PWR-3200DC      dc   3200 W   standby    good  good
```

```
PS Current Configuration Mode : N+1 redundant
PS Current Operating State    : Normal protected
PS Slots Configured standby   : PS8
```

```
Power supplies currently active : 7
Power supplies currently available : 8
```

```
Power Summary          Maximum
(in Watts)           Used   Available
-----

```

System Power	3505	3505
Inline Power	0	18895
-----	-----	-----
Total	3505	22400

Other valid configuration options for the n+1 mode:

- All installed modules are AC-input power supply modules of the same capacity and with the same AC-input voltage level; one module is configured as standby.
- All installed modules are DC-input power supply modules of the same capacity; one module is configured as standby.

Example: n+1 Redundant Mode (Power Supply Modules of the Same Capacity and Type + Normal Protected State

The table below represents the two rows of power supply slots in a Cisco Catalyst 9400 Series chassis. Power supply slots are indicated as PS1, PS2, and so on. For this example, power supply modules of the same capacity and type (C9400-PWR-3200DC) have been installed in slots 1 through 8. Slot 8 has the +1 standby power supply module.

PS1 (Active) C9400-PWR-3200DC	PS2 (Active) C9400-PWR-3200DC	PS3 (Active) C9400-PWR-3200DC	PS4 (Active) C9400-PWR-3200DC
PS5 (Active) C9400-PWR-3200DC	PS6 (Active) C9400-PWR-3200DC	PS7 (Active) C9400-PWR-3200DC	PS8 (Standby) C9400-PWR-3200DC

The switch meets all the required conditions for an n+1 redundant mode with a normal protected state.

- It is in an n+1 redundant mode, because one power supply module is configured as standby.
There are no other n+1 redundant mode conditions to meet, since all installed modules are DC-input power supply modules.
- It is in a normal protected state, because:
Total standby output power (3200 W) is lesser than total active output power (22400).
and
Total active output power (22400) is greater than the required budgeted power (2030)

Switch# **show power**

Power Supply	Model No	Type	Capacity	Status	Fan States			
-----	-----	---	-----	-----	1	2	3	4
PS1	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good
PS2	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good
PS3	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good
PS4	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good
PS5	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good
PS6	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good
PS7	C9400-PWR-3200DC	dc	3200 W	active	good	good	good	good
PS8	C9400-PWR-3200DC	dc	3200 W	standby	n.a.	n.a.	n.a.	n.a.

Example: n+n Redundant Mode (Power Supply Modules of the Same Capacity + Full Protected State)

```

PS Current Configuration Mode : N+1 redundant
PS Current Operating State    : Normal protected
PS Slots Configured standby   : PS8

```

```

Power supplies currently active : 7
Power supplies currently available : 8

```

Power Summary (in Watts)	Used	Maximum Available
System Power	2030	2030
Inline Power	106	20370
Total	2136	22400

Other valid configuration options for the n+1 mode:

- All installed modules are AC-input power supply modules of the same capacity and with the same AC-input voltage level; one module is configured as standby.
- A mix of AC-input and DC-input power supply modules are installed where all modules are of the same capacity and all installed AC-input power supply modules have an AC-input voltage of 220 VAC.

Example: n+n Redundant Mode (Power Supply Modules of the Same Capacity + Full Protected State)

The table below represents the two rows of power supply slots in a Cisco Catalyst 9400 Series chassis. Power supply slots are indicated as PS1, PS2, and so on. For this example, power supply modules of the same capacity (3200W) have been installed in slots 1 through 8. Slots 1 through 4 have AC-input power supply modules and all are configured as active. Slots 5 through 8 have DC-input power supply modules and all are configured as standby.

PS1 (Active) C9400-PWR-3200AC	PS2 (Active) C9400-PWR-3200AC	PS3 (Active) C9400-PWR-3200AC	PS4 (Active) C9400-PWR-3200AC
PS5 (Standby) C9400-PWR-3200DC	PS6 (Standby) C9400-PWR-3200DC	PS7 (Standby) C9400-PWR-3200DC	PS8 (Standby) C9400-PWR-3200DC

The switch meets all the required conditions for an n+n redundant mode with a full protected state.

- It is in an n+n redundant mode, because n number of power supply modules are configured as active, and the same number, as standby.

It also meets all the n+n redundant mode conditions:

- All power supply modules configured as active are of the same type; all modules configured as standby are of the same type.
- A mix of AC-input and DC-input power supply modules are installed and all installed AC-input power supply modules in the chassis are of the same capacity and have the same AC-input voltage level.

In the sample output where `Type= ac`, `Capacity = 3200 w` for all modules. The `Capacity` field for the AC-input modules also reflect that voltage is at 220 VAC.

- A mix of AC-input and DC-input power supply modules are installed, and all installed DC-input power supply modules are configured as standby.
- It is in a full protected state, because:
 - Total active output power (12800) is greater than the required budgeted power (3505).
 - and
 - Total standby output power (12800) is equal to total active output power (12800).

```
Switch# show power
Power
Supply  Model No          Type  Capacity  Status  Fan States
-----  -
PS1     C9400-PWR-3200AC   ac    3200 W    active  good good
PS2     C9400-PWR-3200AC   ac    3200 W    active  good good
PS3     C9400-PWR-3200AC   ac    3200 W    active  good good
PS4     C9400-PWR-3200AC   ac    3200 W    active  good good
PS5     C9400-PWR-3200DC   dc    3200 W    standby good good
PS6     C9400-PWR-3200DC   dc    3200 W    standby good good
PS7     C9400-PWR-3200DC   dc    3200 W    standby good good
PS8     C9400-PWR-3200DC   dc    3200 W    standby good good

PS Current Configuration Mode : N+N redundant
PS Current Operating State    : Full protected
PS Slots Configured standby   : PS5, PS6, PS7, PS8

Power supplies currently active : 4
Power supplies currently available : 8
```

```
Power Summary          Maximum
(in Watts)  Used  Available
-----
System Power  3505  3505
Inline Power  0      9295
-----
Total         3505  12800
```

Other valid configuration options for the n+n mode:

- All installed modules are AC-input power supply modules of the same capacity and with the same AC-input voltage level; n number of modules configured as active and n, as standby.
- All installed modules are DC-input power supply modules of the same capacity; n number of modules configured as active and n, as standby.

Example: n+n Redundant Mode (Power Supply Modules of Different Capacities + Normal Protected State)

The table below represents the two rows of power supply slots in a Cisco Catalyst 9400 Series chassis. Power supply slots are indicated as PS1, PS2, and so on. For this example, slots 1 through 4 have AC-input power supply modules of the same capacity (2100W) and all are configured as active. Slots 5 through 8 have DC-input power supply modules and all are configured as standby.

PS1 (Active)	PS2 (Active)	PS3 (Active)	PS4 (Active)
C9400-PWR-2100AC	C9400-PWR-2100AC	C9400-PWR-2100AC	C9400-PWR-2100AC

Example: n+n Redundant Mode (Power Supply Modules of Different Capacities + Normal Protected State)

PS5 (Standby)	PS6 (Standby)	PS7 (Standby)	PS8 (Standby)
C9400-PWR-3200DC	C9400-PWR-3200DC	C9400-PWR-3200DC	C9400-PWR-3200DC

The switch meets all the required conditions for an n+n redundant mode with a full protected state.

- It is in an n+n redundant mode, because n number of power supply modules are configured as active, and the same number, as standby.

It also meets all the n+n redundant mode conditions:

- All power supply modules configured as active are of the same type; all modules configured as standby are of the same type.
- A mix of AC-input and DC-input power supply modules are installed and all installed AC-input power supply modules in the chassis are of the same capacity and have the same AC-input voltage level.

In the sample output where `Type= ac`, `Capacity = 2100 w` for all modules. The `Capacity` field for the AC-input modules also reflect that voltage is at 220 VAC.

- A mix of AC-input and DC-input power supply modules are installed, and all installed DC-input power supply modules are configured as standby.
- Power supply modules of different capacities are installed, but the higher capacity modules are configured as standby.
- Although the setup and configuration in this example satisfy all the conditions, a full protected state is not guaranteed.



Note When the system detects power supply modules of different capacities, the system always considers and displays the operating state as normal protected.

```
Switch# show power
Power
Supply Model No          Type Capacity Status      Fan States
-----
PS1    C9400-PWR-2100AC      ac   2100 W   active     good  good
PS2    C9400-PWR-2100AC      ac   2100 W   active     good  good
PS3    C9400-PWR-2100AC      ac   2100 W   active     good  good
PS4    C9400-PWR-2100AC      ac   2100 W   active     good  good
PS5    C9400-PWR-3200DC      dc   3200 W   standby    good  good
PS6    C9400-PWR-3200DC      dc   3200 W   standby    good  good
PS7    C9400-PWR-3200DC      dc   3200 W   standby    good  good
PS8    C9400-PWR-3200DC      dc   3200 W   standby    good  good

PS Current Configuration Mode : N+N redundant
PS Current Operating State    : Normal protected
PS Slots Configured standby   : PS5, PS6, PS7, PS8

Power supplies currently active : 4
Power supplies currently available : 8

Power Summary          Maximum
(in Watts)           Used   Available
-----

```

```

System Power   3505   3505
Inline Power   0       4895
-----
Total          3505   8400

```

Other valid configuration options for the n+n mode:

- All installed modules are AC-input power supply modules of the same capacity and with the same AC-input voltage level; n number of modules configured as active and n, as standby.
- All installed modules are DC-input power supply modules of the same capacity; n number of modules configured as active and n, as standby.

Feature History for Environmental Monitoring and Power Management

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Everest 16.6.1	Environmental Monitoring and Power Management	Environmental monitoring of chassis components provides early warning indications of possible component failure. This warning helps you to ensure the safe and reliable operation of your system and avoid network interruptions.
Cisco IOS XE Fuji 16.8.1a	Power Budget Mode	The power budget mode was introduced Support for the 2100W AC-Input power supply module was introduced (C9400-PWR-2100AC).
Cisco IOS XE Fuji 16.9.1	3200W DC-Input Power Supply Module	Support for the 3200W DC-Input power supply module was introduced (C9400-PWR-3200DC).

Use Cisco Feature Navigator to find information about platform and software image support. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>.

