



Cisco Intersight VIC Configuration Guide

First Published: 2024-09-11

Last Modified: 2025-09-29

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883



CONTENTS

CHAPTER 1

Overview of Cisco Virtual Interface Card (VIC) Configuration Guide 1

Overview 1

RDMA Over Converged Ethernet (RoCE) Version 2 1

Single Root I/O Virtualization (SR-IOV) 1

CHAPTER 2

Guidelines, Limitations, and Requirements 3

RoCEv2 for Windows 3

Guidelines for Using SMB Direct support on Windows using RDMA over converged Ethernet (RoCE)
v2 3

Windows Requirements 5

RoCEv2 for Linux 5

Guidelines for using NVMe over Fabrics (NVMeoF) with RoCE v2 on Linux 5

Linux Requirements 6

RoCEv2 For ESXi 7

Guidelines for using NVMeoF with RoCE v2 on ESXi 7

ESXi Requirements 8

SR-IOV For ESXi 8

Guidelines and Limitations 8

SR-IOV ESXi Requirements 9

SR-IOV For Linux 9

Guidelines and Limitations 9

SR-IOV Linux Requirements 10

CHAPTER 3

Configuring RDMA Over Converged Ethernet (RoCE) v2 11

Configuring SMB Direct with RoCE v2 in Windows 11

Configuring Mode 1 on Cisco Intersight 11

Enabling RoCE Settings in LAN Connectivity Policy	12
Configuring SMB Direct Mode 1 on the Host System	15
Configuring Mode 2 on Cisco Intersight	18
Configuring Mode 2 on the Host System	22
Deleting the RoCE v2 Interface in Cisco Intersight	25
Configuring NVMe over Fabrics (NVMeoF) with RoCE v2 in Linux	26
Configuring RoCE v2 for NVMeoF on Cisco Intersight	26
Enabling RoCE Settings in LAN Connectivity Policy	27
Enabling an IOMMU BIOS Settings	30
Configuring RoCE v2 for NVMeoF on the Host System	32
Installing Cisco enic and enic_rdma Drivers	32
Discovering the NVMe Target	33
Setting Up Device Mapper Multipath	35
Deleting the RoCE v2 Interface in Cisco Intersight	36
Configuring NVMe with RoCEv2 in ESXi	36
Configuring RoCE v2 for NVMeoF on Cisco Intersight	36
Enabling RoCE Settings in LAN Connectivity Policy	38
NENIC Driver Installation	40
ESXi NVMe RDMA Host Side Configuration	40
NENIC RDMA Functionality	40
Create Network Connectivity Switches	41
Create VMVHBA Ports in ESXi	43
Displaying vmnic and vmrdma Interfaces	44
NVMe Fabrics and Namespace Discovery	45
Deleting the RoCE v2 Interface in Cisco Intersight	46
Known Issues	47
Windows	47
Linux	48
ESXi	48

CHAPTER 4
Configuring Single Root I/O Virtualization (SR-IOV) 49

Configuring BIOS and SR-IOV VFs	49
Enabling BIOS Parameters	49
Create Ethernet Adapter Policy for SR-IOV	50

Enabling SR-IOV VFs using Cisco Intersight GUI	50
Disabling SR-IOV VFs Using Cisco Intersight GUI	62
Configuring SR-IOV VFs on the EXSi Host Server	63
Installing Cisco eNIC Driver	63
Verifying the SR-IOV VFs Per Ports on the Host	63
Creating SR-IOV VFs on the Host	64
Configuring the Switch	65
Creating a Virtual Port	67
Creating a New Virtual Machine (VM)	67
Adding SR-IOV VF on the Virtual Machine	68
Installing OS on Guest VM on ESXi	68
Configuring SR-IOV VFs on the Linux Host Server	69
Installing Cisco eNIC Driver and Enabling IOMMU in Linux Kernel	69
Verifying the Total number of SR-IOV VFs per Port on the Host	70
Creating SR-IOV VFs on the Host	71
Creating a New Virtual Machine (VM)	72
Adding SR-IOV VF on the Virtual Machine	73



CHAPTER 1

Overview of Cisco Virtual Interface Card (VIC) Configuration Guide

- [Overview, on page 1](#)
- [RDMA Over Converged Ethernet \(RoCE\) Version 2, on page 1](#)
- [Single Root I/O Virtualization \(SR-IOV\), on page 1](#)

Overview

A Cisco UCS network adapter can be installed to provide options for I/O consolidation and virtualization support. This guide contains configuration details on RDMA over Converged Ethernet version 2 (RoCEv2) and Single Root I/O Virtualization (SR-IOV).

RDMA Over Converged Ethernet (RoCE) Version 2

RDMA over Converged Ethernet version 2 (RoCEv2) is a network protocol that allows for Remote Direct Memory Access (RDMA) over Ethernet networks. It enables low-latency and high-bandwidth communication between servers or storage systems by leveraging the benefits of RDMA technology. RoCEv2 eliminates the need for traditional TCP/IP networking stack overhead, resulting in improved performance and reduced latency. It allows for efficient data transfers and enables applications to directly access remote memory, enhancing overall network efficiency and scalability. RoCEv2 is often used in data centers and high-performance computing environments to optimize network performance and accelerate data-intensive workloads.

RoCE v2 is supported on Windows, Linux, and ESXi platforms.

Single Root I/O Virtualization (SR-IOV)

Single Root I/O Virtualization (SR-IOV) allows multiple VMs running a variety of Linux guest operating systems to share a single PCIe network adapter within a host server. SR-IOV allows a VM to move data directly to and from the vNIC, bypassing the hypervisor for increased network throughput and lower server CPU overhead.



CHAPTER 2

Guidelines, Limitations, and Requirements

- [RoCEv2 for Windows](#), on page 3
- [RoCEv2 for Linux](#), on page 5
- [RoCEv2 For ESXi](#), on page 7
- [SR-IOV For ESXi](#), on page 8
- [SR-IOV For Linux](#), on page 9

RoCEv2 for Windows

Guidelines for Using SMB Direct support on Windows using RDMA over converged Ethernet (RoCE) v2

General Guidelines and Limitations:

- Cisco Intersight Managed Mode support Microsoft SMB Direct with RoCE v2 on Microsoft Windows Server 2019 and later. Cisco recommends that you have all KB updates from Microsoft for your Windows Server release.



Note

- RoCE v2 is not supported on Microsoft Windows Server 2016.
- Refer to [Windows Requirements](#) for specific supported Operating System(OS).

- Microsoft SMB Direct with RoCE v2 is supported only with Cisco UCS VIC 1400 Series, VIC 14000, and VIC 15000 Series adapters. It is not supported with UCS VIC 1200 Series and VIC 1300 Series adapters. SMB Direct with RoCE v2 is supported on all UCS Fabric Interconnects.



Note

RoCE v1 is not supported on Cisco UCS VIC 1400 Series, VIC 14000 Series, and VIC 15000 series adapters.

- RoCE v2 configuration is supported only between Cisco adapters. Interoperability between Cisco adapters and third party adapters is not supported.
- RoCE v2 supports two RoCE v2 enabled vNIC per adapter and four virtual ports per adapter interface, independent of SET switch configuration.
- RoCE v2 enabled vNIC interfaces must have the no-drop QoS system class enabled in Cisco Intersight Managed Mode domain profile.
- The RoCE Properties queue pairs setting must for be a minimum of four queue pairs and maximum number of queue pairs per adapter is 2048.
- The QoS No Drop class configuration must be properly configured on upstream switches such as Cisco Nexus 9000 series switches. QoS configurations will vary between different upstream switches.
- The maximum number of memory regions per rNIC interface is 131072.
- SMB Direct with RoCE v2 is supported on both IPv4 and IPv6.
- RoCE v2 cannot be used on the same vNIC interface as NVGRE, NetFlow, and VMQ features.
- RoCE v2 cannot be used with usNIC.
- RoCE v2 cannot be used with GENEVE offload.

MTU Properties:

- In older versions of the VIC driver, the MTU was derived from either a Cisco Intersight server profile or from the Cisco IMC vNIC MTU setting in standalone mode. This behavior varies for Cisco UCS VIC 1400 Series, VIC 14000 Series, and VIC 15000 Series adapters, where MTU is controlled from the Windows OS Jumbo Packet advanced property.
- The RoCE v2 MTU value is always power-of-two and its maximum limit is 4096.
- RoCE v2 MTU is derived from the Ethernet MTU.
- RoCE v2 MTU is the highest power-of-two that is less than the Ethernet MTU. For example:
 - If the Ethernet value is 1500, then the RoCE v2 MTU value is 1024
 - If the Ethernet value is 4096, then the RoCE v2 MTU value is 4096
 - If the Ethernet value is 9000, then the RoCE v2 MTU value is 4096

Windows NDPKI Modes of Operation:

- Cisco's implementation of Network Direct Kernel Provider Interface (NDPKI) supports two modes of operation: Mode 1 and Mode 2. Implementation of Network Direct Kernel Provider Interface (NDKPI) differs in Mode 1 and Mode 2 of operation: Mode 1 is native RDMA, and Mode 2 involves configuration for the virtual port with RDMA. Cisco does not support NDPKI Mode 3 operation.
- The recommended default adapter policy for RoCE v2 Mode 1 is Win-HPN-SMBd.
- The recommended default adapter policy for RoCE v2 Mode 2 is MQ-SMBd.
- RoCE v2 enabled vNICs for Mode 2 operation require the QoS host control policy set to full.
- Mode 2 is inclusive of Mode 1: Mode 1 must be enabled to operate Mode 2.

- On Windows, the RoCE v2 interface supports both MSI & MSIx interrupts mode. Default interrupt mode is MSIx. Cisco recommends you avoid changing interrupt mode when the interface is configured with RoCE v2 properties.

Downgrade Limitations:

- Cisco recommends you remove the RoCE v2 configuration before downgrading to any non-supported firmware release. If the configuration is not removed or disabled, downgrade will fail.

Windows Requirements

Configuration and use of RDMA over Converged Ethernet for RoCE v2 in Windows Server requires the following:

- Windows 2019 or Windows Server 2022 or Windows 2025 with latest Microsoft updates
- VIC Driver version 5.4.0.x or later
- Cisco UCS M5 B-Series and C-Series with Cisco UCS 1400 Series adapters.
- Cisco UCS M6 B-Series, C-Series, or X-Series servers with Cisco UCS VIC 1400, VIC 14000, or VIC 15000 series adapters.
- Cisco UCS M7 C-Series, or X-Series servers with Cisco UCS VIC 1400, VIC 14000, or VIC 15000 series adapters.
- Cisco UCS M8 C-Series, , or X-Series servers with Cisco VIC 15000 series adapters.

**Note**

All Powershell commands or advanced property configurations are common across Windows 2019 and 2022 unless explicitly mentioned.

RoCEv2 for Linux

Guidelines for using NVMe over Fabrics (NVMeoF) with RoCE v2 on Linux

General Guidelines and Limitations:

- Cisco recommends you check [UCS Hardware and Software Compatibility](#) to determine support for NVMeoF. NVMeoF is supported on Cisco UCS B-Series, C-Series, and X-Series servers.
- NVMe over RDMA with RoCE v2 is supported with the Cisco UCS VIC 1400, VIC 14000, and VIC 15000 Series adapters.
- When creating RoCE v2 interfaces, use Cisco Intersight provided Linux-NVMe-RoCE adapter policy.
- In the Ethernet Adapter policy, do not change values of Queue Pairs, Memory Regions, Resource Groups, and Priority settings other than to Cisco provided default values. NVMeoF functionality may not be guaranteed with different settings for Queue Pairs, Memory Regions, Resource Groups, and Priority.

- When configuring RoCE v2 interfaces, use both the enic and enic_rdma binary drivers downloaded from Cisco.com and install the matched set of enic and enic_rdma drivers. Attempting to use the binary enic_rdma driver downloaded from Cisco.com with an inbox enic driver will not work.
- RoCE v2 supports maximum two RoCE v2 enabled interfaces per adapter.
- Booting from an NVMeoF namespace is not supported.
- RoCEv2 cannot be used with GENEVE offload.
- RoCEv2 cannot be used with QinQ.
- Layer 3 routing is not supported.
- RoCE v2 does not support bonding.
- Saving a crashdump to an NVMeoF namespace during a system crash is not supported.
- NVMeoF cannot be used with usNIC, VxLAN, VMQ, VMMQ, NVGRE, GENEVE Offload, and DPDK features.
- Cisco Intersight does not support fabric failover for vNICs with RoCE v2 enabled.
- The Quality of Service (QoS) no drop class configuration must be properly configured on upstream switches such as Cisco Nexus 9000 series switches. QoS configurations will vary between different upstream switches.
- Spanning Tree Protocol (STP) may cause temporary loss of network connectivity when a failover or failback event occurs. To prevent this issue from occurring, disable STP on uplink switches.

Linux Requirements

Configuration and use of RoCEv2 in Linux requires the following:

- InfiniBand kernel API module ib_core
- nvme-cli package
- Minimum VIC firmware 5.1(2x) or later for IPv6 support
- Cisco UCS B-series, Cisco UCS C-series, and Cisco UCS X-series servers with Cisco UCS VIC 1400 or Cisco UCS VIC 15000 Series adapters
- A storage array that supports NVMeoF connection
- eNIC driver version 4.0.0.10-802.34 or later and enic_rdma driver version 1.0.0.10-802.34 or later



Note Ubuntu 24.04.1 with kernel 6.8.0-51-generic starts supporting RoCE v2 from eNIC driver version 4.8.0.0-1128.4 and enic_rdma driver version 1.8.0.0-1128.4.

- Red Hat Enterprise Linux 8.x, 9.x and 10.x versions

Interrupts

- Linux RoCEv2 interface supports only MSIx interrupt mode. Cisco recommends avoiding changing interrupt mode when the interface is configured with RoCEv2 properties.
- The minimum interrupt count for using RoCEv2 with Linux is 8.

RoCEv2 For ESXi

Guidelines for using NVMeoF with RoCE v2 on ESXi

General Guidelines and Limitations:

- Cisco recommends checking the [UCS Hardware and Software Compatibility](#) to determine support for NVMeoF. NVMeoF is supported on Cisco UCS B-Series, C-Series, and X-Series servers.
- Nonvolatile Memory Express (NVMe) over RDMA with RoCE v2 is currently supported only with Cisco VIC 15000 Series adapters.
- When creating RoCE v2 interfaces, use Cisco Intersight provided VMWareNVMeRoCEv2 adapter policy.
- When creating RoCE v2 interfaces, use Cisco recommended Queue Pairs, Memory Regions, Resource Groups, and Class of Service settings. NVMeoF functionality may not be guaranteed with different settings for Queue Pairs, Memory Regions, Resource Groups, and Class of Service.
- RoCE v2 supports maximum two RoCE v2 enabled interfaces per adapter.
- Booting from an NVMeoF namespace is not supported.
- RoCEv2 cannot be used with GENEVE offload.
- RoCEv2 cannot be used with QinQ.
- SR-IOV cannot be configured on the same vNIC with VXLAN, Geneve Offload, QinQ, VMQ/VMMQ, RoCE, or usNIC.
- Layer 3 routing is not supported.
- Saving a crashdump to an NVMeoF namespace during a system crash is not supported.
- NVMeoF with RoCE v2 cannot be used with usNIC, VxLAN, VMQ, VMMQ, NVGRE, GENEVE Offload, ENS, and DPDK features.
- Cisco Intersight does not support fabric failover for vNICs with RoCE v2 enabled.
- The Quality of Service (QoS) no drop class configuration must be properly configured on upstream switches such as Cisco Nexus 9000 series switches. QoS configurations will vary between different upstream switches.
- During the failover or failback event, the Spanning Tree Protocol (STP) can result temporary loss of network connectivity. To prevent this connectivity issue, disable STP on uplink switches.

ESXi Requirements

Configuration and use of RoCE v2 in ESXi requires the following:

- VMware ESXi 7.0 U3 and 8.0 or later
- VIC firmware 5.2(3x) or later versions.
- The driver version, *nenic-2.0.4.0-IOEM.700.1.0.15843807.x86_64.vib* that provides both standard eNIC and RDMA support
- A storage array that supports NVMeoF connection.
- Cisco UCS M5 and later B or C-series servers with Cisco UCS VIC 1400 or Cisco UCS VIC 15000 Series adapters

SR-IOV For ESXi

Guidelines and Limitations

- Cisco recommends checking the [UCS Hardware and Software Compatibility](#) to determine support for SR-IOV.
- SR-IOV is supported with Cisco UCS AMD®/Intel® based B-Series, C-Series, and X-Series servers.
 - SR-IOV is not supported in Physical NIC mode.
 - SR-IOV does not support VLAN Access mode.
- Each vNIC supports up to 64 Virtual Functions (VFs). For each VF, the configuration includes: Up to 8 RQs, Up to 8 WQs, Up to 16 CQs, and Up to 16 interrupts
- SR-IOV cannot be configured on the same vNIC with VXLAN, Geneve Offload, QinQ, VMQ/VMMQ, RoCE, or usNIC.
- Cisco IMM does not limit the total number of VFs, Receive Queue Count Per VF, Transmit Queue Count Per VF, Completion Queue Count Per VF, and Interrupt Count Per VF values. However, if any one of the resources exceed the adapter limit, the Server Profile deployment will fail with a resource error. In this case, either reduce the number of VFs or adjust the failed resource value accordingly.
- For ESXi hosts using SR-IOV with VFs on vNICs and VMs, the system may crash with a PSOD during cold or warm reboots. This behavior is related to the handling of VFs in the environment.
- Enabling some of the features concurrently with SR-IOV will lead to a Server Profile Deployment failure. Ensure the following features are disabled when configuring SR-IOV on a vNIC:
 - VMQ
 - usNIC
 - Geneve Offload
 - RoCE
 - QinQ Tunnelling

- NVGRE
- VXLAN

The following features are not supported on SR-IOV:

- aRFS
- iSCSI Boot
- DPDK when the host has Linux OS
- Precision Time Protocol (PTP)



Note SR-IOV interface supports Message-Signaled Interrupts (MSIs) interrupt mode.

SR-IOV ESXi Requirements

Configuration and use of SR-IOV in ESXi requires the following:

- Cisco VIC firmware version 5.3(2.32) or later
- VMware ESXi 7.0 U3, 8.0, 9.0 or later
- VMs with RHEL 8.7, 9.0, and 10.0 or later
- Cisco VMware nENIC driver version 2.0.10.0 for ESXi 7.0 U3, 2.0.11.0 for ESXi 8.0 U3, and 2.0.18.0 for ESXi 9.0 or later
- Cisco RHEL ENIC driver version 4.4.0.1-930.10 for RHEL 8.7 and 9.0 and later
- Cisco RHEL ENIC driver version 4.9.0.1-1160.11 for RHEL 9.6 and 10.0 and later



Note SR-IOV is not supported on Cisco UCS VIC 1200 and Cisco UCS VIC 1300 series adapters.

SR-IOV For Linux

Guidelines and Limitations

- Cisco recommends checking the [UCS Hardware and Software Compatibility](#) to determine support for SR-IOV.
- SR-IOV is supported with AMD[®]/Intel[®] based Cisco UCS C-Series, B-Series, and X-Series servers.
- SR-IOV is not supported in Physical NIC mode.
- SR-IOV does not support VLAN Access mode.

- SR-IOV cannot be configured on the same vNIC with VXLAN, Geneve Offload, QinQ, VMQ/VMMQ, RoCE, or usNIC.
- aRFS is not supported on SR-IOV VF.
- iSCSI boot is not supported on SR-IOV VF.
- DPDK on SRIOV VF is not supported when the host has Linux OS.
- SR-IOV interface supports MSIx interrupt mode.
- Precision Time Protocol (PTP) is not supported on SR-IOV VF.
- The system may experience a PSOD when multiple vNICs are configured with SR-IOV and VMs are enumerated with Virtual Functions (VFs), especially when either cold or warm boots are performed. For Linux operating systems, after a system reboot, the VFs need to be reconfigured because they are not persistent across reboots.

SR-IOV Linux Requirements

Configuration and use of SR-IOV in Linux requires the following:

- Host OS: Red Hat Enterprise Linux 8.10, 9.4 or later, 10.0 or later, and Ubuntu 22.0.4.2 LTS or later
- Guest OS: Red Hat Enterprise Linux 8.10, 9.4 or later, 10.0 or later, and Ubuntu 22.0.4.2 LTS or later
- Virtualization Packages installed on the host
- eNIC driver version 4.7.0.5-1076.6 or later
- Cisco UCS Manager Release 4.3(5a) or later
- Cisco VIC firmware 5.3(4.75) or later



CHAPTER 3

Configuring RDMA Over Converged Ethernet (RoCE) v2

- [Configuring SMB Direct with RoCE v2 in Windows, on page 11](#)
- [Configuring NVMe over Fabrics \(NVMeoF\) with RoCE v2 in Linux, on page 26](#)
- [Configuring NVMe with RoCEv2 in ESXi, on page 36](#)
- [Known Issues, on page 47](#)

Configuring SMB Direct with RoCE v2 in Windows

Configuring Mode 1 on Cisco Intersight

Use these steps to configure the RoCE v2 Mode 1 interface on Cisco Intersight.

To avoid possible RDMA packet drops, ensure same no-drop COS is configured across the network. The following steps allow you to configure a no-drop class in System QoS policies and use it for RDMA supported interfaces.

For Cisco UCS M8 C-Series or X-Series servers, the VIC 15000 series is supported, while the Cisco UCS VIC 1400 Series, 14000 Series is not compatible with M8 servers.

Procedure

Step 1 Navigate to **CONFIGURE > Policies**. Click **Create Policy**, select **UCS Domain** platform type, search or choose **System QoS**, and click **Start**.


Step 2 In the **General** page, enter the policy name and click **Next**, and then in the **Policy Details** page, configure the property setting for System QoS policy as follows:

- For **Priority**, choose **Platinum**
- For **Allow Packet Drops**, uncheck the check box.

Note


For more information on MTU field, see *MTU Properties* in [Guidelines for Using SMB Direct support on Windows using RDMA over converged Ethernet \(RoCE\) v2, on page 3](#)

Enabling RoCE Settings in LAN Connectivity Policy



Step 3
Step 4

Click **Create**
Associate the System QoS policy to the Domain Profile and deploy.



Note
For more information, see *Creating System QoS Policy* in [Configuring Domain Policies](#) and [Configuring Domain Profiles](#).

The System QoS Policy is successfully created and deployed to the Domain Profile.

What to do next

Configure the server profile with RoCE v2 vNIC settings in LAN Connectivity policy.

Enabling RoCE Settings in LAN Connectivity Policy

Use these steps to configure the RoCE v2 vNIC settings in Mode 1. In Cisco Intersight LAN Connectivity policy, you can enable the RoCE settings on **Ethernet QoS** policy and **Ethernet Adapter** policy for Mode 1 configuration as follows:

Procedure

- Step 1** Navigate to **CONFIGURE > Policies**. Click **Create Policy**, select **UCS Server** platform type, search or choose **LAN Connectivity** policy, and click **Start**.
- Step 2** In the policy **General** page, enter the policy name, select the Target Platform as **UCS Server (Standalone)** or **UCS Server (FI-Attached)**, and click **Next**.
- Step 3** In the **Policy Details** page, click **Add vNIC** to create a new vNIC.
- Step 4** In the **Add vNIC** page, follow the configuration parameters to enable the RoCE vNIC settings:

- In the **General** section, provide a name for virtual ethernet interface.
- In the **Consistent Device Naming (CDN)** section of the Standalone server or the **Failover** section of FI-attached server, do the following:
 - Click **Select Policy** link below the **Ethernet QoS**. Use the **Create New** button to create a new Ethernet QoS policy with the following property settings:

- For **MTU**, choose or enter **1500, 4096, or 9000**
- For **Priority**, choose **Platinum** or **any no-drop**
- For **Class of Service**, choose or enter **5**

Note

This property is available only on Standalone servers.


- Slide to **Enable Trust Host CoS** toggle button.

Note

This property is available only on Intersight Managed Mode servers.

The screenshot displays the Cisco Intersight web interface for creating a new Ethernet QoS policy. The main content area is titled 'Create' and shows the 'Policy Details' section. Under 'QoS Settings', the following values are configured: MTU (9000), Rate Limit (0), Class of Service (5), Burst (10240), and Priority (Platinum). The 'Enable Trust Host CoS' toggle is turned on. The left sidebar shows the navigation menu with 'Policies' selected. The bottom right has 'Back' and 'Create' buttons.

- Click **Select Policy** link below the **Ethernet Adapter**. Follow on to click Create an Ethernet Adapter Policy:
- **Use the Default Configuration:** Click **Create New** to create a new policy. In the **General** page, enter the name of the policy and under Ethernet Adapter Default Configuration click **Select Default Configuration** to search and select **Win-HPN-SMBd**, the pre-defined Ethernet Adapter Default Configuration. Click **Next** and then **Create**.



- **Configure RoCE Settings in the policy:** Click **Create New** to create a new policy. In the **General** page, enter the name of the policy. Under Policy Details page on right pane, use the following property settings, then click **Next**, and then **Create**.
 - For **Enable RDMA over Converged Ethernet**, slide to enable.
 - For **Queue Pairs**, choose or enter **256**
 - For **Memory Regions**, choose or enter **131072**
 - For **Resource Groups**, choose or enter **2**
 - For **Version**, select **Version 2**

The screenshot shows the 'Create Ethernet Adapter' configuration page in the Cisco Intersight interface. The page is divided into several sections for configuring the vNIC settings:

- General:** Includes 'Enable RoCE over Converged Ethernet' (checked), 'Queue Pairs' (256), 'Memory Regions' (131072), and 'Resource Group' (2).
- Interrupt Settings:** Includes 'Version' (Version 2), 'Class Of Service' (0), 'Interrupts' (512), 'Interrupt Mode' (MSIX), and 'Interrupt Time-out us' (125).
- Receive:** Includes 'Receive Queue Count' (4) and 'Receive Ring Size' (912).
- Transmit:** Includes 'Transmit Queue Count' (1) and 'Transmit Ring Size' (256).
- Completion:** Includes 'Completion Queue Count' (5) and 'Completion Ring Size' (1).
- Update Pollback Timeout (seconds):** Set to 5.

The left sidebar shows the navigation menu with options like Overview, Policies, Servers, Profiles, and Templates. The 'Policies' section is currently selected.

- Click **Add** to add and save the new vNIC settings.

Note

All the fields with * are mandatory for creating LAN Connectivity Policy. Ensure they are filled out or selected with appropriate policies.

Step 5 Click **Create** to complete the LAN Connectivity policy with RoCE v2 property settings.

Step 6 Associate the LAN Connectivity policy to the server profile and deploy.

Note

For more information, see *Creating a LAN Connectivity Policy*, *Creating an Ethernet QoS Policy*, and *Creating an Ethernet Adapter Policy* in [Configuring UCS Server Policies](#) and [Configuring UCS Server Profiles](#).

The LAN Connectivity policy with the Ethernet QoS policy and Ethernet Adapter policy vNIC setting is successfully created and the server profile is deployed to enable RoCE v2 configuration.

What to do next

Once the policy configuration for RoCE v2 is complete, proceed to enable IOMMU in the BIOS policy.

Configuring SMB Direct Mode 1 on the Host System


You will configure connection between smb-client and smb-server on two host interfaces. For each of these servers, smb-client and smb-server, configure the RoCE v2-enabled vNIC as described below.

Before you begin

Configure RoCE v2 for Mode 1 in Cisco Intersight.

Procedure

- Step 1** In the Windows host, go to the Device Manager and select the appropriate Cisco VIC Internet Interface.
- Step 2** Go to **Tools > Computer Management > Device Manager > Network Adapter** > click on **VIC Network Adapter > Properties > Advanced > Network Direct Functionality**. Perform this operation for both the smb-server and smb-client vNICs.



- Step 3** Verify that RoCE is enabled on the host operating system using PowerShell.

The `Get-NetOffloadGlobalSetting` command shows NetworkDirect is enabled.

```
PS C:\Users\Administrator> Get-NetOffloadGlobalSetting
```

```
ReceiveSideScaling      : Enabled
ReceiveSegmentCoalescing : Enabled
Chimney                 : Disabled
```

```
TaskOffload           : Enabled
NetworkDirect         : Enabled
NetworkDirectAcrossIPSubnets : Blocked
PacketCoalescingFilter : Disabled
```

Note

If the NetworkDirect setting is showing as disabled, enable it using the command: `Set-NetOffloadGlobalSetting -NetworkDirect enabled`

Step 4 Bring up Powershell and enter the command:

```
get-SmbClientNetworkInterface
```

```
PS C:\Users\Administrator>
PS C:\Users\Administrator> Get-SmbClientNetworkInterface
```

Interface	Index	RSS Capable	RDMA Capable	Speed	IpAddresses	Friendly Name
14		True	False	40 Gbps	{10.37.60.162}	vEthernet (vswitch)
26		True	True	40 Gbps	{10.37.60.158}	vEthernet (vp1)
9		True	True	40 Gbps	{50.37.61.23}	Ethernet 2
5		False	False	40 Gbps	{169.254.10.5}	Ethernet (Kernel Debugger)
8		True	False	40 Gbps	{169.254.4.26}	Ethernet 3

```
PS C:\Users\Administrator>
```

Step 5 Enter **enable - netadapterrdma [-name] ["Ethernetname"]****Step 6** Verify the overall RoCE v2 Mode 1 configuration at the Host as follows:


- Use the Powershell command **netstat -xan** to verify the listeners in both the smb-client and smb-server Windows host; listeners will be shown in the command output.

```
PS C:\Users\Administrator>
PS C:\Users\Administrator> netstat -xan
```

Mode	IfIndex	Type	Local Address	Foreign Address	PID
Kernel	9	Listener	50.37.61.23:445	NA	0
Kernel	26	Listener	10.37.60.158:445	NA	0

```
PS C:\Users\Administrator>
```

- Go to the smb-client server fileshare and start an I/O operation.
- Go to the performance monitor and check that it displays the RDMA activity.



- Step 7** In the Powershell command window, check the connection entries with the **netstat -xan** output command to make sure they are displayed. You can also run **netstat -xan** from the command prompt. If the connection entry shows up in netstat-xan output, the RoCE v2 model connections are correctly established between client and server.

```
PS C:\Users\Administrator> netstat -xan
```

Active NetworkDirect Connections, Listeners, SharedEndpoints

Mode	IfIndex	Type	Local Address	Foreign Address	PID
Kernel	4	Connection	50.37.61.22:445	50.37.61.71:2240	0
Kernel	4	Connection	50.37.61.22:445	50.37.61.71:2496	0
Kernel	11	Connection	50.37.61.122:445	50.37.61.71:2752	0
Kernel	11	Connection	50.37.61.122:445	50.37.61.71:3008	0
Kernel	32	Connection	10.37.60.155:445	50.37.60.61:49092	0
Kernel	32	Connection	10.37.60.155:445	50.37.60.61:49348	0
Kernel	26	Connection	50.37.60.32:445	50.37.60.61:48580	0
Kernel	26	Connection	50.37.60.32:445	50.37.60.61:48836	0
Kernel	4	Listener	50.37.61.22:445	NA	0
Kernel	11	Listener	50.37.61.122:445	NA	0
Kernel	32	Listener	10.37.60.155:445	NA	0
Kernel	26	Listener	50.37.60.32:445	NA	0

Note

IP values are representative only.

- Step 8** By default, Microsoft's SMB Direct establishes two RDMA connections per RDMA interface. You can change the number of RDMA connections per RDMA interface to one or any number of connections.

For example, to increase the number of RDMA connections to 4, type the following command in PowerShell:

```
PS C:\Users\Administrator> Set-ItemProperty -Path `
"HKLM:\SYSTEM\CurrentControlSet\Services\LanmanWorkstation\Parameters"
ConnectionCountPerRdmaNetworkInterface -Type DWORD -Value 4 -Force
```

Configuring Mode 2 on Cisco Intersight

Use these steps to configure the RoCE v2 policies in Mode 2. In Cisco Intersight LAN Connectivity Policy, you can enable the RoCE settings on **Ethernet QoS** policy and **Ethernet Adapter** policy, and **VMMQ Adapter** policy for Mode 2 configuration as follows:

You will apply the VMQ Connection Policy as vmmq.

Before you begin

Configure RoCE v2 Policies in Mode 1.

Use the pre-defined default adapter policy "MQ-SMBd", or configure a user-defined Ethernet adapter policy with the following recommended RoCE-specific parameters:

- RoCE: Enabled
- Version 1: disabled
- Version 2: enabled
- Queue Pairs: 256
- Memory Regions: 65536
- Resource Groups: 2


- Priority: Platinum

Create a VMQ connection policy with the following values:

- Multi queue: Enabled
- Number of sub-vNIC: 16
- VMMQ adapter policy: MQ-SMBd

Procedure

-
- Step 1** Navigate to **CONFIGURE > Policies**. Click **Create Policy**, select **UCS Server** platform type, search or choose **LAN Connectivity** policy, and click **Start**.
- Step 2** In the policy **General** page, enter the policy name, select the Target Platform as **UCS Server (Standalone)** or **UCS Server (FI-Attached)**, and click **Next**.
- Step 3** In the **Policy Details** page, click **Add vNIC** to create a new vNIC.
- Step 4** In the **Add vNIC** page, follow the configuration parameters to enable the RoCE vNIC settings:
- a) In the **General** section, provide a name for virtual ethernet interface.
 - b) In the **Consistent Device Naming (CDN)** section of the Standalone server or the **Failover** section of FI-attached server, do the following:
 - Click **Select Policy** link below the **Ethernet QoS**. Use the **Create New** button to create a new Ethernet QoS policy with the following property settings:
 - **MTU**—The Maximum Transmission Unit (MTU) or packet size that the virtual interface accepts. For **MTU**, choose or enter **1500, 4096, or 9000**
 - **Rate Limit, Mbps**—The value in Mbps (0-10G/40G/100G depending on Adapter Model) to use for limiting the data rate on the virtual interface.
 - **Class of Service**—Class of Service to be associated to the traffic on the virtual interface.
 - **Burst**—The burst traffic, in bytes, allowed on the vNIC.
 - For **Priority**, choose or enter **Best-effort**
 - **Enable Trust Host CoS**, slide to enable




- Click **Select Policy** link below the **Ethernet Adapter**. Use **Create New** button to create a new Ethernet Adapter policy with the following property settings:
 - For **Enable RDMA over Converged Ethernet**, slide to enable.
 - For **Queue Pairs**, select or enter **256**
 - For **Memory Regions**, select or enter **65536**
 - For **Resource Groups**, select or enter **2**
 - For **Version**, choose **Version 2**
 - For **Class of Service**, choose or enter **5**

- In the **Connection** section, use the following property setting for VMQ Connection and to create VMMQ Adapter policy:
 - For connection, select **VMQ**.
 - **Enable Virtual Machine Multi-Queue** using slider button.
 - For **Number of Sub vNICs**, select or enter **4**
 - For **VMMQ Adapter Policy**, click **Select Policy** link below the VMMQ Adapter Policy and do the following:
 - Click **Create New** to create a new policy. In the **General** page, enter the name of the policy and click **Select Default Configuration** to search and select **MQ-SMBd**, the pre-defined VMMQ Adapter default configuration.

Attention

Do not modify the pre-defined parameters under Policy Details page, retain the default settings.

- Click **Next** and then **Create**.



- Click **Add** to add and save the new vNIC settings.

Note

All the fields with * are mandatory and ensure it is filled out or selected with appropriate policies.

Step 5 Click **Create** to complete the LAN Connectivity policy with RoCE v2 property settings.

Step 6 Associate the LAN Connectivity policy to the server profile.

Note

For more information on *Creating an Ethernet QoS, Ethernet Adapter Policy, and VMMQ Adapter Policy*, see [Configuring UCS Server Policies](#) and [Configuring UCS Server Profiles](#).

The LAN Connectivity Policy with Ethernet QoS Policy, Ethernet Adapter Policy, and VMMQ Adapter Policy are successfully created and deployed to enable RoCE v2 configuration.

What to do next

Once the policy configuration for RoCE v2 is complete, reboot the server and proceed with the RoCE v2 Mode 2 configuration on the host operating system.

Configuring Mode 2 on the Host System

This task uses Hyper-V virtualization software that is compatible with Windows Server 2019 and Windows Server 2022.


Follow the below procedure for the host operating system configuration for RoCEv2 Mode 2.

Before you begin

- Configure and confirm the connection for Mode 1 for both Cisco Intersight and Host.
- Configure Mode 2 in Cisco Intersight.

Procedure

- Step 1** Go the Hyper-V switch manager.
- Step 2** Create a new Virtual Network Switch (vswitch) for the RoCE v2-enabled Ethernet interface.
- Choose **External Network** and select **VIC Ethernet Interface 2** and **Allow management operating system to share this network adapter**.
 - Click **OK** to create the create the virtual switch.



Bring up the Powershell interface.

Step 3 Configure the non-default vport and enable RDMA with the following Powershell commands:

```
add-vmNetworkAdapter -switchname vswitch -name vp1 -managementOS
enable-netAdapterRdma -name "vEthernet (vp1)"
```

```
PS C:\Users\Administrator>
PS C:\Users\Administrator> add-vmNetworkAdapter -switchName vswitch -name vp1 -managementOS
PS C:\Users\Administrator> enable-netAdapterRdma -name "vEthernet (vp1)"
PS C:\Users\Administrator>
```

a) Configure set-switch using the following Powershell command.

```
new-vmswitch -name setswitch -netAdapterName "Ethernet x" -enableEmbeddedTeam $true
```

This creates the switch. Use the following to display the interfaces:

```
get-netadapterrdma
```

```
add-vmNetworkAdapter -switchname setswitch -name svp1
```

You will see the new vport when you again enter

```
get-netadapterrdma
```

b) Add a vport.

```
add-vmNetworkAdapter -switchname setswitch -name svp1
```

You will see the new vport when you again enter

```
get-netadapterrdma
```

c) Enable the RDMA on the vport:

```
enable-netAdapterRdma -name "vEthernet (svp1)"
```

Step 4 Configure the IPV4 addresses on the RDMA enabled vport in both servers.

Step 5 Create a share in smb-server and map the share in the smb-client.

- For smb-client and smb-server in the host system, configure the RoCE v2-enabled vNIC as described above.
- Configure the IPV4 addresses of the primary fabric and sub-vNICs in both servers, using the same IP subnet and same unique vlan for both.
- Create a share in smb-server and map the share in the smb-client.

Step 6 Verify the Mode 2 configuration.

a) Use the Powershell command **netstat -xan** to display listeners and their associated IP addresses.


```
PS C:\Users\Administrator>
PS C:\Users\Administrator> netstat -xan

Active NetworkDirect Connections, Listeners, SharedEndpoints
```

Mode	IfIndex	Type	Local Address	Foreign Address	PID
Kernel	9	Listener	50.37.61.23:445	NA	0
Kernel	26	Listener	10.37.60.158:445	NA	0

```
PS C:\Users\Administrator>
```

b) Start any RDMA I/O in the file share in smb-client.



- c) Issue the **netstat -xan** command again and check for the connection entries to verify they are displayed.

```
PS C:\Users\Administrator>
PS C:\Users\Administrator> netstat -xan

Active NetworkDirect Connections, Listeners, SharedEndpoints

Mode    IfIndex Type           Local Address      Foreign Address     PID
-----
Kernel  9 Connection    50.37.61.23:192     50.37.61.184:445    0
Kernel  9 Connection    50.37.61.23:448     50.37.61.184:445    0
Kernel  9 Connection    50.37.61.23:704     50.37.61.214:445    0
Kernel  9 Connection    50.37.61.23:960     50.37.61.214:445    0
Kernel  9 Connection    50.37.61.23:1216    50.37.61.224:445    0
Kernel  9 Connection    50.37.61.23:1472    50.37.61.224:445    0
Kernel  9 Connection    50.37.61.23:1728    50.37.61.234:445    0
Kernel  9 Connection    50.37.61.23:1984    50.37.61.234:445    0
Kernel  9 Listener      50.37.61.23:445     NA                   0
Kernel  26 Listener     10.37.60.158:445    NA                   0
PS C:\Users\Administrator>
```

What to do next


Troubleshoot any items if necessary.

Deleting the RoCE v2 Interface in Cisco Intersight

Use these steps to remove the RoCE v2 interface.

Procedure

- Step 1** Navigate to **CONFIGURE > Policies**. In the **Add Filter** field, select **Type: LAN Connectivity**.
- Step 2** Select the appropriate LAN Connectivity policy created for RoCE V2 configuration and use the delete icon on the top or bottom of the policy list.
- Step 3** Click **Delete** to delete the policy.



Step 4 Upon deleting the RoCE v2 configuration, re-deploy the server profile and reboot the server.

Configuring NVMe over Fabrics (NVMeoF) with RoCE v2 in Linux

Configuring RoCE v2 for NVMeoF on Cisco Intersight

Use these steps to configure the RoCE v2 interface on Cisco Intersight.

To avoid possible RDMA packet drops, ensure same the no-drop COS is configured across the network. The following steps allow you to configure a no-drop class in System QoS policies and use it for RDMA supported interfaces.

Procedure

- Step 1** Navigate to **CONFIGURE > Policies**. Click **Create Policy**, select **UCS Domain** platform type, search or choose **System QoS**, and click **Start**.
- Step 2** In the **General** page, enter the policy name and click **Next**, and then in the **Policy Details** page, configure the property setting for System QoS policy as follows:
- For **Priority**, choose **Platinum**
 - For **Allow Packet Drops**, uncheck the check box.
 - For **MTU**, set the value as **9216**.

Step 3 Click **Create**.

Step 4 Associate the System QoS policy to the Domain Profile.

Note

For more information, see *Creating System QoS Policy* in [Configuring Domain Policies](#) and [Configuring Domain Profiles](#).

The System QoS Policy is successfully created and deployed to the Domain Profile.

What to do next

Configure the server profile with RoCE v2 vNIC settings in LAN Connectivity policy.

Enabling RoCE Settings in LAN Connectivity Policy

Use these steps to configure the RoCE v2 vNIC settings in Mode 1. In Cisco Intersight LAN Connectivity policy, you can enable the RoCE settings on **Ethernet QoS** policy and **Ethernet Adapter** policy for Mode 1 configuration as follows:

Procedure

- Step 1** Navigate to **CONFIGURE > Policies**. Click **Create Policy**, select **UCS Server** platform type, search or choose **LAN Connectivity** policy, and click **Start**.
- Step 2** In the policy **General** page, enter the policy name, select the Target Platform as **UCS Server (Standalone)** or **UCS Server (FI-Attached)**, and click **Next**.
- Step 3** In the **Policy Details** page, click **Add vNIC** to create a new vNIC.
- Step 4** In the **Add vNIC** page, follow the configuration parameters to enable the RoCE vNIC settings:
- In the **General** section, provide a name for virtual ethernet interface.
 - In the **Consistent Device Naming (CDN)** section of the Standalone server or the **Failover** section of FI-attached server, do the following:
 - Click **Select Policy** link below the **Ethernet QoS**. Use the **Create New** button to create a new Ethernet QoS policy with the following property settings:
 - For **MTU**, choose or enter **1500, 4096, or 9000**
 - For **Priority**, choose **Platinum** or **any no-drop**
 - For **Class of Service**, choose or enter **5**


Note

This property is available only on Standalone servers.


- Slide to **Enable Trust Host CoS** toggle button.

Note

This property is available only on Intersight Managed Mode servers.



- Click **Select Policy** link below the **Ethernet Adapter**. Follow on to click Create an Ethernet Adapter Policy:
- **Use the Default Configuration:** Click **Create New** to create a new policy. In the **General** page, enter the name of the policy and under Ethernet Adapter Default Configuration click **Select Default Configuration** to search and select **Win-HPN-SMBd**, the pre-defined Ethernet Adapter Default Configuration. Click **Next** and then **Create**.



- **Configure RoCE Settings in the policy:** Click **Create New** to create a new policy. In the **General** page, enter the name of the policy. Under Policy Details page on right pane, use the following property settings, then click **Next**, and then **Create**.
 - For **Enable RDMA over Converged Ethernet**, slide to enable.
 - For **Queue Pairs**, choose or enter **256**
 - For **Memory Regions**, choose or enter **131072**
 - For **Resource Groups**, choose or enter **2**
 - For **Version**, select **Version 2**

Enabling an IOMMU BIOS Settings

The screenshot shows the 'Create Ethernet Adapter' configuration page in the Cisco Intersight interface. The page is divided into several sections for configuring the adapter's properties:

- General:** Includes 'Enable RDMA over Converged Ethernet' (checked), 'Guest Pairs' (256), 'Memory Region' (131072), and 'Resource Groups' (2).
- Interrupt Settings:** Includes 'Version' (Version 2), 'Class Of Service' (5), 'Interrupts' (512), 'Interrupt Mode' (Mtx), and 'Interrupt Timeout us' (125).
- Receive:** Includes 'Receive Queue Count' (4) and 'Receive Ring Size' (512).
- Transmit:** Includes 'Transmit Queue Count' (5) and 'Transmit Ring Size' (256).
- Completion:** Includes 'Completion Queue Count' (5) and 'Completion Ring Size' (5).
- Update Pollback Timeout (seconds):** Set to 5.

The 'Policy Details' section on the left sidebar shows the 'General' tab selected. The 'Create' button is visible at the bottom right of the configuration area.

- Click **Add** to add and save the new vNIC settings.

Note

All the fields with * are mandatory for creating LAN Connectivity Policy. Ensure they are filled out or selected with appropriate policies.

Step 5 Click **Create** to complete the LAN Connectivity policy with RoCE v2 property settings.

Step 6 Associate the LAN Connectivity policy to the server profile and deploy.

Note

For more information, see *Creating a LAN Connectivity Policy*, *Creating an Ethernet QoS Policy*, and *Creating an Ethernet Adapter Policy* in [Configuring UCS Server Policies](#) and [Configuring UCS Server Profiles](#).

The LAN Connectivity policy with the Ethernet QoS policy and Ethernet Adapter policy vNIC setting is successfully created and the server profile is deployed to enable RoCE v2 configuration.

What to do next


Once the policy configuration for RoCE v2 is complete, proceed to enable IOMMU in the BIOS policy.

Enabling an IOMMU BIOS Settings

Use the following steps to configure the server profile with the RoCE v2 vNIC and enable the IOMMU BIOS policy before enabling the IOMMU in the Linux kernel.

Procedure

- Step 1** Navigate to **CONFIGURE > Policies**. Click **Create Policy**, select **UCS Server** platform type, search or choose **BIOS**, and click **Start**.
- Step 2** On the **General** page, enter the policy name and click **Next**.
- Step 3** On the **Policy Details** page, configure the following BIOS:
- Select **All Platforms**.
 - For a server with an Intel CPU, enable **Intel VT for Directed I/O** under the **Intel Directed I/O** drop-down list and enable **Intel(R) VT** under the **Processor** drop-down list.
 - For a server with an AMD CPU, enable **IOMMU** under the **Memory** drop-down list and enable **SVM Mode** under the **Processor** drop-down list.



- Step 4** Click **Create**.
- Step 5** Associate the BIOS policy to the server profile and reboot the server.

Note

For more information, see *Creating a BIOS Policy* in [Configuring Server Policies](#) and [Configuring Server Profile](#).

The BIOS Policy is successfully created and deployed on the server profile.

What to do next

Configure RoCE v2 for NVMeoF on the Host System.

Configuring RoCE v2 for NVMeoF on the Host System

Before you begin

Configure the Server Profile with RoCE v2 vNIC and the IOMMU enabled BIOS policy.

Procedure

Step 1 Open the `/etc/default/grub` file for editing.

Step 2 Add `intel_iommu=on` to the end of `GRUB_CMDLINE_LINUX`.

```
sample /etc/default/grub configuration file after adding intel_iommu=on:
# cat /etc/default/grub
GRUB_TIMEOUT=5
GRUB_DISTRIBUTOR="$(sed 's, release .*$,,g' /etc/system-release)"
GRUB_DEFAULT=saved
GRUB_DISABLE_SUBMENU=true
GRUB_TERMINAL_OUTPUT="console"
GRUB_CMDLINE_LINUX="crashkernel=auto rd.lvm.lv=rhel/root rd.lvm.lv=rhel/swap biosdevname=1 rhgb quiet
    intel_iommu=on
GRUB_DISABLE_RECOVERY="true"
```

Step 3 After saving the file, generate a new `grub.cfg` file.

For Legacy boot:

```
# grub2-mkconfig -o /boot/grub2/grub.cfg
```

For UEFI boot:

```
# grub2-mkconfig -o /boot/grub2/efi/EFI/redhat/grub.cfg
```

Step 4 Reboot the server. You must reboot your server for the changes to take after enabling IOMMU.

Step 5 Verify the server is booted with `intel_iommu=on` option.

```
cat /proc/cmdline | grep iommu
```

Note its inclusion at the end of the output.

```
[root@localhost basic-setup]# cat /proc/cmdline | grep iommu
BOOT_IMAGE=vmlinuz-3.10.0-957.27.2.el7.x86_64 root=/dev/mapper/rhel-root ro crashkernel=auto
rd.lvm.lv=rhel/root rd.lvm.lv=rhel/swap rhgb quiet intel_iommu=on LANG=en_US.UTF-8
```

What to do next

Download the `enic` and `enic_rdma` drivers.

Installing Cisco `enic` and `enic_rdma` Drivers

The `enic_rdma` driver requires `enic` driver. When installing `enic` and `enic_rdma` drivers, download and use the matched set of `enic` and `enic_rdma` drivers on Cisco.com. Attempting to use the binary `enic_rdma` driver downloaded from Cisco.com with an inbox `enic` driver, will not work.

Procedure

Step 1 Install the enic and enic_rdma rpm packages:

```
# rpm -ivh kmod-enic-<version>.x86_64.rpm kmod-enic_rdma-<version>.x86_64.rpm
```

Note

During enic_rdma installation, the enic_rdmalibnvdimm module may fail to install on RHEL 7.7 because the nvdimm-security.conf dracut module needs spaces in the add_drivers value. For workaround, please follow the instruction from the following links:

<https://access.redhat.com/solutions/4386041>

https://bugzilla.redhat.com/show_bug.cgi?id=1740383

Step 2 The enic_rdma driver is now installed but not loaded in the running kernel. Reboot the server to load enic_rdma driver into the running kernel.

Step 3 Verify the installation of enic_rdma driver and RoCE v2 interface:

```
[root@localhost ~]# dmesg | grep enic_rdma
[  3.137083] enic_rdma: Cisco VIC Ethernet NIC RDMA Driver, ver 1.2.0.28-877.2
2 init
[  3.242663] enic 0000:1b:00.1 eno6: enic_rdma: FW v3 RoCEv2 enabled
[  3.284856] enic 0000:1b:00.4 eno9: enic_rdma: FW v3 RoCEv2 enabled
[ 16.441662] enic 0000:1b:00.1 eno6: enic_rdma: Link UP on enic_rdma_0
[ 16.458754] enic 0000:1b:00.4 eno9: enic_rdma: Link UP on enic_rdma_1
```

Step 4 Load the nvme-rdma kernel module:

```
# modprobe nvme-rdma
```

After server reboot, nvme-rdma kernel module is unloaded. To load nvme-rdma kernel module every server reboot, create nvme_rdma.conf file using:

```
# echo nvme_rdma > /etc/modules-load.d/nvme_rdma.conf
```

Note

For more information about enic_rdma after installation, use the `rpm -q -l kmod-enic_rdma` command to extract the README file.

What to do next

Discover targets and connect to NVMe namespaces. If your system needs multipath access to the storage, go to the section for [Setting Up Device Mapper Multipath, on page 35](#).

Discovering the NVMe Target

Use this procedure to discover the NVMe target and connect NVMe namespaces.

Before you begin

Install **nvme-cli** version 1.6 or later if it is not installed already.

Configure the IP address on the RoCE v2 interface and make sure the interface can ping the target IP.

Procedure

Step 1 Create an nvme folder in /etc, then manually generate host nqn.

```
# mkdir /etc/nvme
# nvme gen-hostnqn > /etc/nvme/hostnqn
```

Step 2 Create a settos.sh file and run the script to set priority flow control (PFC) in IB frames.

Note

To avoid failure of sending NVMeoF traffic, you *must* create and run this script after *every* server reboot.

```
# cat settos.sh
#!/bin/bash
for f in `ls /sys/class/infiniband`;
do
    echo "setting TOS for IB interface:" $f
    mkdir -p /sys/kernel/config/rdma_cm/$f/ports/1
    echo 186 > /sys/kernel/config/rdma_cm/$f/ports/1/default_roce_tos
done
```

Step 3 Discover the NVMe target by entering the following command.

```
nvme discover --transport=rdma --traddr=<IP address of transport target port>
```

For example, to discover the target at 50.2.85.200:

```
# nvme discover --transport=rdma --traddr=50.2.85.200

Discovery Log Number of Records 1, Generation counter 2
=====Discovery Log Entry 0=====
trtype:  rdma
adrfam:  ipv4
subtype: nvme subsystem
treq:    not required
portid:  3
trsvcid: 4420
subnqn:  nqn.2010-06.com.purestorage:flasharray.9a703295ee2954e
traddr:  50.2.85.200
rdma_prtype: roce-v2
rdma_qptype: connected
rdma_cms:   rdma-cm
rdma_pkey: 0x0000
```

Note

To discover the NVMe target using IPv6, put the IPv6 target address next to the `traddr` option.

Step 4 Connect to the discovered NVMe target by entering the following command.

```
nvme connect --transport=rdma --traddr=<IP address of transport target port>> -n <subnqn value from
nvme discover>
```

For example, to discover the target at 50.2.85.200 and the subnqn value found above:

```
# nvme connect --transport=rdma --traddr=50.2.85.200 -n
nqn.2010-06.com.purestorage:flasharray.9a703295ee2954e
```

Note

To connect to the discovered NVMe target using IPv6, put the IPv6 target address next to the `traddr` option.

Step 5 Use the **nvme list** command to check mapped namespaces:

```
# nvme list
```

Node	SN	Model	Namespace	Usage
	Format	FW Rev		

/dev/nvme0n1	09A703295EE2954E	Pure Storage FlashArray	72656	4.29 GB
/ 4.29 GB	512 B + 0 B	99.9.9		
/dev/nvme0n2	09A703295EE2954E	Pure Storage FlashArray	72657	5.37 GB
/ 5.37 GB	512 B + 0 B	99.9.9		

Setting Up Device Mapper Multipath

If your system is configured with Device Mapper multipathing (DM Multipath), use the following steps to set up Device Mapper multipath.

Procedure

Step 1 Install the **device-mapper-multipath** package if it is not installed already

Step 2 Enable and start multipathd:

```
# mpathconf --enable --with_multipathd y
```

Step 3 Edit the **etc/multipath.conf** file to use the following values :

```
defaults {
    polling_interval      10
    path_selector         "queue-length 0"
    path_grouping_policy  multibus
    fast_io_fail_tmo      10
    no_path_retry         0
    features              0
    dev_loss_tmo          60
    user_friendly_names   yes
}
```

Step 4 Flush with the updated multipath device maps.

```
# multipath -F
```

Step 5 Restart multipath service:

```
# systemctl restart multipathd.service
```

Step 6 Rescan multipath devices:

```
# multipath -v2
```

Step 7 Check the multipath status:


```
# multipath -ll
```

Deleting the RoCE v2 Interface in Cisco Intersight

Use these steps to remove the RoCE v2 interface.

Procedure

- Step 1** Navigate to **CONFIGURE > Policies**. In the **Add Filter** field, select **Type: LAN Connectivity**.
- Step 2** Select the appropriate LAN Connectivity policy created for RoCE V2 configuration and use the delete icon on the top or bottom of the policy list.
- Step 3** Click **Delete** to delete the policy.



- Step 4** Upon deleting the RoCE v2 configuration, re-deploy the server profile and reboot the server.

Configuring NVMe with RoCEv2 in ESXi

Configuring RoCE v2 for NVMeoF on Cisco Intersight

Use these steps to configure the RoCE v2 interface on Cisco Intersight.


To avoid possible RDMA packet drops, ensure same no-drop COS is configured across the network. The following steps allow you to configure a no-drop class in System QoS policies and use it for RDMA supported interfaces.

Procedure

- Step 1** Navigate to **CONFIGURE > Policies**. Click **Create Policy**, select **UCS Domain** platform type, search or choose **System QoS**, and click **Start**.


Step 2 In the **General** page, enter the policy name and click **Next**, and then in the **Policy Details** page, configure the property setting for System QoS policy as follows:

- For **Priority**, choose **Platinum**
- For **Allow Packet Drops**, uncheck the check box.
- For **MTU**, set the value as **9216**.



Step 3 Click **Create**.

Step 4 Associate the System QoS policy to the Domain Profile.



Note

For more information, see *Creating System QoS Policy* in [Configuring Domain Policies](#) and [Configuring Domain Profiles](#).

The System QoS Policy is successfully created and deployed to the Domain Profile.

What to do next

Configure the server profile with RoCE v2 vNIC settings in LAN Connectivity policy.


Enabling RoCE Settings in LAN Connectivity Policy

Use the following steps to configure the RoCE v2 vNIC. In Cisco Intersight LAN Connectivity policy, you can enable the RoCE settings on **Ethernet Adapter policy** for Linux configuration as follows:

Procedure

-
- Step 1** Navigate to **CONFIGURE > Policies**. Click **Create Policy**, select **UCS Server** platform type, search or choose **LAN Connectivity policy**, and click **Start**.
- Step 2** In the policy **General** page, enter the policy name, select the Target Platform as **UCS Server (Standalone)** or **UCS Server (FI-Attached)**, and click **Next**.
- Step 3** In the **Policy Details** page, click **Add vNIC** to create a new vNIC.
- Step 4** In the **Add vNIC** page, follow the configuration parameters to enable the RoCE v2 vNIC:
- In the **General** section, provide a name for virtual ethernet interface.
 - In case of a Standalone server, click the **Consistent Device Naming (CDN)** or click the **Failover** of a FI-attached server, and do the following:
 - Click **Select Policy** under **Ethernet Adapter**.
 - In the **Select Policy** window, click **Create New** to create an Ethernet Adapter policy.
 - In the **General** page of the Ethernet Adapter Policy, enter the policy name and click **Next**.
 - In the **Policy Details** page of the Ethernet Adapter Policy, modify the following property setting:
 - RoCE Settings**
 - For **Enable RDMA over Converged Ethernet**, slide to enable and set the RoCE on this virtual interface.
 - For **Queue Pairs**, select or enter **1024**
 - For **Memory Regions**, select or enter **131072**
 - For **Resource Groups**, select or enter **8**
 - For **Version**, select **Version 2**
 - For **Class of Service**, select **5**
 - Interrupt Settings**
 - For **Interrupts**, select or enter **256**.
 - For **Interrupt mode**, select **MSIX**.
 - For **Interrupt Timer, us**, select **125**.
 - For **Interrupt Coalescing Type**, select **Min**.

- **Receive Settings**
 - For **Receive Queue Count**, select or enter **1**.
 - For **Receiving Ring Size**, select or enter **512**.
- **Transmit Settings**
 - For **Transmit Queue Count**, select or enter **1**.
 - For **Transmit Ring Size**, select or enter **256**.
- **Completion Settings**
 - For **Completion Queue Count**, select or enter **2**.
 - For **Completion Ring Size**, select or enter **1**.
 - For **Uplink Failback Timeout(seconds)**, select or enter **5**
- Click **Create** to create an Ethernet Adapter Policy with the above defined settings.



- Click **Add** to save the setting and add the new vNIC.

Note

All the fields with * are mandatory and ensure it is filled out or selected with appropriate policies.

Step 5 Click **Create** to complete the LAN Connectivity policy with RoCE v2 settings.

Step 6 Associate the LAN Connectivity policy to the Server Profile.

Note

For more information, see *Creating a LAN Connectivity Policy* and *Creating an Ethernet Adapter Policy* in [Configuring UCS Server Policies](#) and [Configuring UCS Server Profiles](#).

The LAN Connectivity Policy with the Ethernet Adapter policy vNIC setting is successfully created and deployed to enable RoCE v2 configuration.

What to do next

Once the policy configuration for RoCE v2 is complete, configure RoCE v2 for NVMeoF on the Host System.

NENIC Driver Installation

Before you begin

The Ethernet Network Interface Card (eNIC) Remote Direct Memory Access (RDMA) driver requires nenic driver.

Procedure

Step 1 Copy the eNIC vSphere Installation Bundle (VIB) or offline bundle to the ESXi server.

Step 2 Use the command to install nenic driver:

```
esxcli software vib install -v {VIBFILE}  
or  
esxcli software vib install -d {OFFLINE_BUNDLE}
```

Example:

```
esxcli software vib install -v /tmp/nenic-2.0.4.0-10EM.700.1.0.15843807.x86_64.vib
```

Note

Depending on the certificate used to sign the VIB, you may need to change the host acceptance level. To do this, use the command:

```
esxcli software acceptance set --level=<level>
```

Depending on the type of VIB installed, you may need to put ESX into maintenance mode. This can be done through the client, or by adding the *--maintenance-mode* option to the above *esxcli*.

What to do next

Configure the Host side for ESXi NVMe RDMA.

ESXi NVMe RDMA Host Side Configuration

NENIC RDMA Functionality

One of the major difference between RDMA on Linux and ESXi is listed below:

- In ESXi, the physical interface (vmnic) MAC is not used for RoCEv2 traffic. Instead, the VMkernel port (vmk) MAC is used.

Outgoing RoCE packets use the vmk MAC in the Ethernet source MAC field, and incoming RoCE packets use the vmk MAC in the Ethernet destination mac field. The vmk MAC address is a VMware MAC address assigned to the vmk interface when it is created.

- In Linux, the physical interface MAC is used in source MAC address field in the ROCE packets. This Linux MAC is usually a Cisco MAC address configured to the VNIC using UCS Manager.

If you ssh into the host and use the **esxcli network ip interface list** command, you can see the MAC address.

```
vmk0
Name: vmk0
MAC Address: 2c:f8:9b:a1:4c:e7
Enabled: true
Portset: vSwitch0
Portgroup: Management Network
Netstack Instance: defaultTcpipStack
VDS Name: N/A
VDS UUID: N/A
VDS Port: N/A
VDS Connection: -1
Opaque Network ID: N/A
Opaque Network Type: N/A
External ID: N/A
MTU: 1500
TSO MSS: 65535
RXDispQueue Size: 2
Port ID: 67108881
```

You must create a vSphere Standard Switch to provide network connectivity for hosts, virtual machines, and to handle VMkernel traffic. Depending on the connection type that you want to create, you can create a new vSphere Standard Switch with a VMkernel adapter, only connect physical network adapters to the new switch, or create the switch with a virtual machine port group.

Create Network Connectivity Switches

Use these steps to create a vSphere Standard Switch to provide network connectivity for hosts, virtual machines, and to handle VMkernel traffic.

Before you begin

Ensure you have nenic drivers. Download and install nenic drivers before proceeding with below steps:

Procedure

- Step 1** In the vSphere Client, navigate to the host.
- Step 2** On the **Configure** tab, expand **Networking** and select **Virtual Switches**.
- Step 3** Click on **Add Networking**.

The available network adapter connection types are:

- **Vmkernel Network Adapter**

Creates a new VMkernel adapter to handle host management traffic

- **Physical Network Adapter**

Adds physical network adapters to a new or existing standard switch.

- **Virtual Machine Port Group for a Standard Switch**

Creates a new port group for virtual machine networking.

Step 4 Select connection type **Vmkernel Network Adapter**.

Step 5 Select **New Standard Switch** and click **Next**.

Step 6 Add physical adapters to the new standard switch.

- Under **Assigned Adapters**, select **New Adapters**.
- Select one or more adapters from the list and click **OK**. To promote higher throughput and create redundancy, add two or more physical network adapters to the Active list.
- (Optional) Use the up and down arrow keys to change the position of the adapter in the Assigned Adapters list.
- Click **Next**.

Step 7 For the new standard switch you just created for the VMadapter or a port group, enter the connection settings for the adapter or port group.

- Enter a label that represents the traffic type for the VMkernel adapter.
- Set a VLAN ID to identify the VLAN the VMkernel uses for routing network traffic.
- Select IPV4 or IPV6 or both.
- Select an MTU size from the drop-down menu. Select Custom if you wish to enter a specific MTU size. The maximum MTU size is 9000 bytes.

Note

You can enable Jumbo Frames by setting an MTU greater than 1500.

- After setting the TCP/IP stack for the VMkernel adapter, select a TCP/IP stack.

To use the default TCP/IP stack, select it from the available services.

Note

Be aware that the TCP/IP stack for the VMkernel adapter cannot be changed later.

- Configure IPV4 and/or IPV6 settings.

Step 8 On the **Ready to Complete** page, click **Finish**.

Step 9 Check the VMkernel ports for the VM Adapters or port groups with NVMe RDMA in the vSphere client, as shown in the Results below.

The VMkernel ports for the VM Adapters or port groups with NVMe RDMA are shown below.

Summary	Monitor	Configure	Permissions	VMs	Resource Pools	Datastores	Networks	Updates
VMkernel adapters								
ADD NETWORKING... REFRESH								
	Device	Network Label	Switch	IP Address	TCP/IP Stack	Enabled Services		
⋮ >>	vmk0	Management Network	vSwitch0	10.193.176.52	Default	Management		
⋮ >>	vmk1	vmk284	vSwitch1	50.284.210	Default	--		
⋮ >>	vmk2	vmk283	vSwitch2	50.2.83.210	Default	--		

The VRDMA Port groups created with NVMeRDMA supported vmnic appear as below.

Summary	Monitor	Configure	Permissions	VMs	Resource Pools	Datastores	Networks	Updates
RDMA adapters								
Name	Driver	State	Paired UpLink	RoCE v1	RoCE v2	IWARP		
vmrdma0	nmic	Active	vmnic2	Disabled	Enabled	Disabled		
vmrdma1	nmic	Active	vmnic3	Disabled	Enabled	Disabled		

RDMA Device: vmrdma1		
Properties		
Bound VMkernel Adapters		
VMkernel Adapter	TCP/IP Stack	IP Address
vmk2	Default	50 2 B3 210

What to do next

Create vmhba ports on top of vmrdma ports.

Create VMVHBA Ports in ESXi

Use the following steps for creating vmhba ports on top of the vmrdma adapter ports.

Before you begin

Create the adapter ports for storage connectivity.

Procedure

Step 1 Go to vCenter where your ESXi host is connected.

Step 2 Click on **Host>Configure>Storage adapters**.

Summary Monitor Configure Permissions VMs Resource Pools Datastores Networks Updates

Storage

Storage Adapters

+ Add Software Adapter Refresh Rescan Storage... Rescan Adapter X Remove

Adapter	Type	Status	Identifier	Targets	Devices	Paths
Model: Cisco 12G Modular Raid Controller with 2GB cache						
vmhba5	SAS	Unknown	--	2	2	2
Model: Cisco UCS VIC Fric Controller						
vmhba0	Fibre Channel	Offline	10 00 2c f8 9e 79 88 b8 20 00 2c f8 9e 79 88 b8	0	0	0
vmhba2	Fibre Channel	Offline	10 00 2c f8 9e 79 88 bf 20 00 2c f8 9e 79 88 bf	0	0	0
vmhba3	Fibre Channel	Offline	10 00 2c f8 9e 51 b3 3c 20 00 2c f8 9e 51 b3 3c	0	0	0
vmhba4	Fibre Channel	Offline	10 00 2c f8 9e 51 b3 3d 20 00 2c f8 9e 51 b3 3d	0	0	0
Model: Lewisburg SATA AHCI Controller						
vmhba1	Block SCSI	Unknown	--	0	0	0

Copy All 8 Items

Networking

Virtual switches

VMkernel adapters

Physical adapters

RDMA adapters

TCP/IP configuration

Virtual Machines

VM Startup/Shutdown


Agent VM Settings

Default VM Compatibility

Swap File Location

Step 3 Click **+Add Software Adapter**. The following dialog box will appear.


Displaying vmnic and vmdma Interfaces



Step 4 Select **Add software NVMe over RDMA adapter** and the vmdma port you want to use.

Step 5 Click **OK**

The vmhba ports for the VMware NVMe over RDMA storage adapter will be shown as in the example below



Displaying vmnic and vmdma Interfaces

ESXi creates a vmnic interface for each nenic VNIC configured to the host.

Before you begin

Create Network Adapters and VHBA ports.

Procedure

Step 1 Use `ssh` to access the host system.

Step 2 Enter `esxcfg-nics -l` to list the vmnics on ESXi.

Name	PCI	Driver	Link	Speed	Duplex	MAC Address	MTU	Description
vmnic0	0000:3b:00.0	ixgben	Down	0Mbps	Half	2c:f8:9b:a1:4c:e6	1500	Intel(R) Ethernet Controller X550
vmnic1	0000:3b:00.1	ixgben	Up	1000Mbps	Full	2c:f8:9b:a1:4c:e7	1500	Intel(R) Ethernet Controller X550
vmnic2	0000:1d:00.0	nenic	Up	50000Mbps	Full	2c:f8:9b:79:8d:bc	1500	Cisco Systems Inc Cisco VIC Ethernet NIC
vmnic3	0000:1d:00.1	nenic	Up	50000Mbps	Full	2c:f8:9b:79:8d:bd	1500	Cisco Systems Inc Cisco VIC Ethernet NIC
vmnic4	0000:63:00.0	nenic	Down	0Mbps	Half	2c:f8:9b:51:b3:3a	1500	Cisco Systems Inc Cisco VIC Ethernet NIC
vmnic5	0000:63:00.1	nenic	Down	0Mbps	Half	2c:f8:9b:51:b3:3b	1500	Cisco Systems Inc Cisco VIC Ethernet NIC

esxcli network nic list

Name	PCI Device	Driver	Admin Status	Link Status	Speed	Duplex	MAC Address	MTU	Description
vmnic0	0000:3b:00.0	ixgben	Up	Down	0	Half	2c:f8:9b:a1:4c:e6	1500	Intel(R) Ethernet Controller X550
vmnic1	0000:3b:00.1	ixgben	Up	Up	1000	Full	2c:f8:9b:a1:4c:e7	1500	Intel(R) Ethernet Controller X550
vmnic2	0000:1d:00.0	nenic	Up	Up	50000	Full	2c:f8:9b:79:8d:bc	1500	Cisco Systems Inc Cisco VIC Ethernet NIC
vmnic3	0000:1d:00.1	nenic	Up	Up	50000	Full	2c:f8:9b:79:8d:bd	1500	Cisco Systems Inc Cisco VIC Ethernet NIC
vmnic4	0000:63:00.0	nenic	Up	Down	0	Half	2c:f8:9b:51:b3:3a	1500	Cisco Systems Inc Cisco VIC Ethernet NIC
vmnic5	0000:63:00.1	nenic	Up	Down	0	Half	2c:f8:9b:51:b3:3b	1500	Cisco Systems Inc Cisco VIC Ethernet NIC

Step 3 Use `esxcli rdma device list` to list the vmrdma devices. When the enic driver registers with ESXi the RDMA device for a RDMA capable VNIC, ESXi creates a vmrdma device and links it to the corresponding vmnic.

```
[root@ESXi7U3 ~]# esxcli rdma device list
Name      Driver  State  MTU  Speed  Paired Uplink  Description
-----
vmrdma0   nenic   Active 4096 50 Gbps  vmnic1         Cisco UCS VIC 15XXX (A0)
vmrdma1   nenic   Active 4096 50 Gbps  vmnic2         Cisco UCS VIC 15XXX (A0)
[root@ESXi7U3 ~]# esxcli rdma device vmknics list
Device    Vmknics  NetStack
-----
vmrdma0   vmk1     defaultTcpipStack
vmrdma1   vmk2     defaultTcpipStack
```

Step 4 Use `esxcli rdma device protocol list` to check the protocols supported by the vmrdma interface.

For enic, RoCE v2 is the only protocol supported from this list. The output of this command should match the RoCEv2 configuration on the VNIC.

Step 5 Use `esxcli nvme adapter list` to list the NVMe adapters and the vmrdma and vmnic interfaces it is configured on.

```
[root@ESXi7U3 ~]# esxcli nvme adapter list
Adapter  Adapter Qualified Name  Transport Type  Driver  Associated Devices
-----
vmhba64  aqn:nvme:2c-f8-9b-79-8d-bc  RDMA           nvme:rdma  vmrdma0, vmnic2
vmhba65  aqn:nvme:2c-f8-9b-79-8d-bd  RDMA           nvme:rdma  vmrdma1, vmnic3
[root@ESXi7U3 ~]#
```

Step 6 All vmhbases in the system can be listed using `esxcli storage core adapter list`. The vmhba configured over RDMA.

Note

For vmhba64 and vmhba65, you may observe that the driver's Link State displays *link-n/a* instead of *Online*. This is a known issue in ESXi 7.0 Update 3. For more information, see [Known Issues - ESXi](#).

NVMe Fabrics and Namespace Discovery

This process is performed through the ESXi command line interface.

Before you begin

Create and configure the Ethernet Adapter Policy.

Procedure

- Step 1** Check and enable Nonvolatile Memory Express (NVMe) on the vmrdma device. If NVMe is enabled, the system returns the following message.

Example:

```
esxcli nvme fabrics enable -p RDMA -d vmrdma0
```

- Step 2** Discover the NVMe on the array by entering the following command.

```
esxcli nvme fabrics discover -a vmhba64 -l transport_address figure with esxcli nvme fabrics discover -a vmhba64 -l 50.2.84.100
```

The NVMe controller displays the output that include Transport Type, Address Family, Subsystem Type, Controller ID, Admin Queue, Max Size, Transport Address, Transport Service ID, and Subsystem NQN.

You will see output on the NVMe controller.

- Step 3** Perform NVMe fabric interconnect.

```
esxcli nvme fabrics discover -a vmhba64 -l transport_address p Transport Service ID -s Subsystem NQN
```

- Step 4** The NVMe controller displays a list of the controllers connected to NVMe. The NVMe namespace list should shows all the NVMe drivers discovered.

```
esxcli nvme fabrics discover -a vmhba64 -l transport_address p Transport Service ID -s Subsystem NQN
```

The following example shows esxcli discovery commands executed on the server.

Example:

```
[root@ESXiUCSA:~] esxcli nvme fabrics enable -p RDMA -d vmrdma0
NVMe already enabled on vmrdma0 [root@ESXiUCSA:~] esxcli nvme fabrics discover -a vmhba64 -l 50.2.84.100
Transport Type Address Family Subsystem Type Controller ID Admin Queue Max Size Transport
Address Transport Service ID Subsystem NQN
-----
RDMA IPV4 NVM 65535 31 50.2.84.100
4420 nq.210-06.com.purestorage:flasharray:2dp1239anjkl484
[root@ESXiUCSA:~] esxcli nvme fabrics discover -a vmhba64 -l 50.2.84.100 p 4420 -s
nq.210-06.com.purestorage:flasharray:2dp1239anjkl484
Controller already connected
```


Deleting the RoCE v2 Interface in Cisco Intersight

Use these steps to remove the RoCE v2 interface.

Procedure

- Step 1** Navigate to **CONFIGURE > Policies**. In the **Add Filter** field, select **Type: LAN Connectivity**.

- Step 2** Select the appropriate LAN Connectivity policy created for RoCE V2 configuration and use the delete icon on the top or bottom of the policy list.
- Step 3** Click **Delete** to delete the policy.



- Step 4** Upon deleting the RoCE v2 configuration, re-deploy the server profile and reboot the server.

Known Issues

Windows

Symptom	Conditions	Workaround
On VIC 1400 Series adapters, the neNIC driver for Windows 2019 can be installed on Windows 2016 and the Windows 2016 driver can be installed on Windows 2019. However, this is an unsupported configuration.	<p>Case 1 : Installing Windows 2019 nenic driver on Windows 2016 succeeds-but on Windows 2016 RDMA is not supported.</p> <p>Case 2 : Installing Windows 2016 nenic driver on Windows 2019 succeeds-but on Windows 2019 RDMA comes with default disabled state, instead of enabled state.</p>	The driver binaries for Windows 2016 and Windows 2019 are in folders that are named accordingly. Install the correct binary on the platform that is being built/upgraded.

Linux

Symptom	Conditions	Workaround
When sending high bandwidth NVMe traffic on some Cisco Nexus 9000 switches, the switch port that connected to the storage sometimes reaches the max PFC peak and does not automatically clear the buffers. In Nexus 9000 switches, the nxos command "show hardware internal buffer info pkt-stats input peak" shows that the <code>Peak_cell</code> or <code>PeakQos</code> value for the port reaches more than 1000.	The NVMe traffic will drop.	To recover the switch from this error mode. <ol style="list-style-type: none"> 1. Log into the switch. 2. Locate the port that connected to the storage and shut down the port using "shutdown" command 3. Execute the following commands one by one: <pre># clear counters # clear counter buffers module 1 # clear qos statistics</pre> 4. Run no shutdown on the port that was shut down.

ESXi

Symptom	Conditions	Workaround
When using the command esxcli storage core adapter list to list the vmhba, the Driver's Link State for vmhba64 and vmhba65 rdma ports displays <i>Link-n/a</i> instead of <i>Online</i> . Note VMware Developer Center Partner Network (DCPN) Case ID - 00113157	This is a known issue in ESXi 7.0 Update 3.	None



CHAPTER 4

Configuring Single Root I/O Virtualization (SR-IOV)

- [Configuring BIOS and SR-IOV VFs, on page 49](#)
- [Configuring SR-IOV VFs on the EXSi Host Server , on page 63](#)
- [Configuring SR-IOV VFs on the Linux Host Server , on page 69](#)

Configuring BIOS and SR-IOV VFs

Enabling BIOS Parameters

Before you begin

- Ensure your BIOS policy is set up with the following options:
 - For Intel based servers, enable **Intel VT for directed IO** under **Intel Directed IO** tab.



Note Intel VT for directed IO is not available for Intel C220 M8 and Intel C240 M8 platforms.

- For AMD based servers, enable **IOMMU** and **SVM Mode** under **Processor** tab.

To update BIOS options, see, [Cisco UCS Server BIOS Tokens in Intersight Managed Mode](#).

- You must have a server profile already created for SR-IOV configuration. To create a Server Profile see [Creating a UCS Server Profile](#). Once the Server Profile is created, follow the steps in this procedure to enable the BIOS policy.

Procedure

- Step 1** Log in to Cisco Intersight.
- Step 2** Navigate to **Configure > Policies > Create a Policy**

- Step 3** On the **Select Policy Type** page, select **BIOS**, click **Start**.
- Step 4** At the **General** page, enter the policy name, and click **Next**.
- Step 5** On the **Policy Details** page, configure the following BIOS settings:
- Select **All Platforms**.
 - For a server with an Intel CPU, configure the BIOS settings as follows:
 - Enable **Intel VT for Directed IO** under the **Intel Directed IO** drop-down list.
 - Enable **Intel(R) VT** under the **Processor** drop-down list.
 - For a server with AMD CPU, configure the BIOS settings as follows:
 - Enable **IOMMU** under **Memory** drop-down list.
 - Enable **SVM Mode** under **Processor** drop-down list.
- Step 6** Click **Create**.
- Step 7** Associate the BIOS policy to the server profile, and reboot the server.

Note

For more information, see [Creating a BIOS Policy](#) and [Configuring Server Profile](#).

Create Ethernet Adapter Policy for SR-IOV

Procedure

- Step 1** Log in to Cisco Intersight.
- Step 2** In the **Navigation** pane, choose **Configure > Policies**, and then click **Create Policy**.
- Step 3** Select **Ethernet Adapter**, and then click **Start**.
- Step 4** At the **General** page, enter the policy name.
- Step 5** Click **Select Cisco Provided Configuration**, choose **SRIOV-HPN**, and click **Select**.
- Step 6** Click **Next**.
- Step 7** Click **Create**.
-

Enabling SR-IOV VFs using Cisco Intersight GUI

To enable SR-IOV from Cisco Intersight, you must

- Create an SRIOV HPN Connection Policy with desired number of VFs.
- Assign the SRIOV HPN Connection Policy to a Server Profile.

Before you begin

- Ensure that the required BIOS options are enabled before performing this procedure.

Procedure

- Step 1** Log in to Cisco Intersight.
- Step 2** In the **Navigation** pane, choose **Configure > Policies**, and then click **Create Policy**.
- Step 3** Select **LAN Connectivity**, and then click **Start**.
- Step 4** On the **General** page, enter the following information:
- **Name** of your policy.
 - **Target Platform** for which the policy is applicable. This can be **Standalone** servers or **FI Attached** servers.
A LAN Connectivity Policy created for Standalone servers cannot be deployed on FI Attached servers. Similarly, a LAN Connectivity Policy created for FI Attached servers cannot be deployed on Standalone servers.
 - **Set Tags** for the policy. Tags must be in the key:value format. For example, Org: IT or Site: APJ.
 - **Description** to help identify the policy.
- Step 5** Click **Next**.
- Step 6** On the **Policy Details** page, configure the following:
- To set up a vNIC without using a template, click **Add vNIC** and configure the following parameters:

Table 1: For Standalone Servers

Property	Description
Add vNIC Ensure that you configure eth0 and eth1 interfaces for each VIC adapter you configure. You can add additional vNICs depending on your network requirements.	
Name	vNIC name.
Placement Placement Settings for the virtual interface.	
Simple When you select Simple Placement, the Slot ID and PCI Link are determined automatically by the system. vNICs are deployed on the first VIC. The slot ID determines the first VIC. Slot ID numbering begins with MLOM, and thereafter it keeps incrementing by 1, starting from 1. The PCI link is always set to 0.	
Slot ID	When automatic slot ID assignment is disabled, the slot ID needs to be entered manually. Supported values are (1-15) and MLOM.
Uplink Port	Adapter port on which the virtual interface will be created.

Property	Description
PCI link The PCI link used as transport for the virtual interface. Note The host device order can get impacted when using both the PCI links and while adding or removing vNICs.	
PCI Order	The order in which the virtual interface is brought up. The order assigned to an interface should be unique and in sequence starting with "0" for all the Ethernet and Fibre-Channel interfaces on each PCI link on a VIC adapter. The maximum value of PCI order is limited by the number of virtual interfaces (Ethernet and Fibre-Channel) on each PCI link on a VIC adapter. Note You cannot change the PCI order of two vNICs without deleting and recreating the vNICs.
Consistent Device Naming (CDN) Consistent Device Naming configuration for the virtual NIC.	
Source	Whether the source of the CDN name is the name of the vNIC instance or a user-defined name.
Ethernet Network	Relationship to the Ethernet Network Policy. Select the created Ethernet adapter policy from above. Note This sub-policy is applicable only for the LAN Connectivity Policy on Standalone servers. Select or create an Ethernet Network policy.
Ethernet QoS	Relationship to the Ethernet QoS Policy. Select or create an Ethernet QoS policy.
Ethernet Adapter	Relationship to the Ethernet Adapter Policy. Select or create an Ethernet Adapter for SR-IOV from above.
Connection	
Disabled	Configuration is disabled.
usNIC	
Number of usNICs	Number of usNIC interfaces to be created. When usNIC is enabled, the valid values are from 1 to 225. When usNIC is disabled, the default value is 0.

Property	Description
usNIC Adapter Policy	Ethernet Adapter policy to be associated with the usNICs. select policy
Class of Service	Class of Service to be used for traffic on the usNIC.
VMQ	
Enable Virtual Machine Multi-Queue	Enables Virtual Machine Multi-Queue feature on the virtual interface. VMMQ allows configuration of multiple I/O queues for a single VM and thus distributes traffic across multiple CPU cores in a VM.
Number of Interrupts	<p>The number of interrupt resources to be allocated. Recommended value is the number of CPU threads or logical processors available in the server.</p> <p>Note Number of Interrupts overrides the Interrupts value in the selected Ethernet Adapter Policy. Number of Virtual Machine Queues overrides Receive Queue Count, Transmit Queue Count, and Completion Queue Count values of the selected Ethernet Adapter Policy.</p>
Number of Virtual Machine Queues	The number of hardware Virtual Machine Queues to be allocated. The number of VMQs per adapter must be one more than the maximum number of VM NICs.
SR-IOV <p>Single Root Input/Output Virtualization (SR-IOV) allows multiple VMs running a variety of Linux guest operating systems to share a single PCIe network adapter within a host server. SR-IOV allows a VM to move data directly to and from the vNIC, bypassing the hypervisor for increased network throughput and lower server CPU overhead.</p> <p>Note SR-IOV setting for Windows Target OS is not supported.</p>	
Number of VFs	Number of VFs to create. Enter a value between 1 and 64. Default value is 64.
Receive Queue Count Per VF	Number of Receive Queue resources to configure for each VF. Enter a value between 1 to 8. Default value is 4.
Transmit Queue Count Per VF	Number of Transmit Queue resources to configure for each VF. Enter a value between 1 to 8. Default value is 1.
Completion Queue Count Per VF	Number of Completion Queue resources to configure for each VF. Enter a value between 1 to 16. Default value is 5.
Interrupt Count Per VF	Number of Interrupt count to configure for each VF. Enter a value between 1 to 16. Default value is 8.

Table 2: For FI-Attached Servers

Property	Description
Enable Azure Stack Host QoS	Enabling AzureStack-Host QoS on an adapter allows the user to carve out traffic classes for RDMA traffic which ensures that a desired portion of the bandwidth is allocated to it.
IQN	
None	This option ensures the IQN name is not associated with the policy.
Pool	
IQN Pool	Relationship to the iSCSI Qualified Name Pool. Select or create an IQN pool.
Static	
If you select this option, enter a static IQN for use as initiator identifiers by iSCSI vNICs in a Fabric Interconnect domain	
IQN Identifier	User provided static iSCSI Qualified Name (IQN) for use as initiator identifiers by iSCSI vNICs in a Fabric Interconnect domain.
vNIC Configuration	
Manual vNICs Placement	<p>If you select this option, you must manually specify the placement for each vNIC. You can also use the Graphic vNICs Editor to create and specify the placement for each vNIC manually by adding vNICs and slots, and defining the connection between them.</p> <p>Note For manual placement, PCI Link is not supported on UCS VIC 1400 Series adapters.</p> <p>If a LAN Connectivity Policy has both Simple and Advanced placements, ensure the number provided in PCI Order is appropriate to prevent Server Profile deployment failure.</p>
Auto vNICs Placement	If you select this option, vNIC placement will be done automatically during profile deployment. This option is available only for Cisco Intersight Managed FI Attached servers.
Add vNIC	
Ensure that you configure eth0 and eth1 interfaces for each VIC adapter you configure. You can add additional vNICs depending on your network requirements.	
Name	Name of the virtual ethernet interface.

Property	Description
Pin Group Name	Pingroup name associated to vNIC for static pinning. LCP deploy will resolve pingroup name and fetches the corresponding uplink port/port channel to pin the vNIC traffic.
MAC	
Pool	If you select this option, select the MAC pool that you want to associate with the LAN Connectivity policy.
MAC Pool	The MAC pool that is assigned. Select or create a MAC pool.
Static	Click Static and enter a static MAC address for MAC address assignment. This option is available only for Cisco Intersight Managed FI-Attached servers.
Static MAC Address	The MAC address must be in hexadecimal format xx:xx:xx:xx:xx:xx. To ensure uniqueness of MACs in the LAN fabric, you are strongly encouraged to use the following MAC prefix 00:25:B5:xx:xx:xx.
Placement	
Simple When you select Simple Placement, the Slot ID and PCI Link are determined automatically by the system. vNICs are deployed on the first VIC. The slot ID determines the first VIC. Slot ID numbering begins with MLOM, and thereafter it keeps incrementing by 1, starting from 1. The PCI link is always set to 0. Note Not applicable for Auto vNIC Placement.	
Switch ID	Refers to the Fabric Interconnect that carries the vNIC traffic.
PCI Order	The order in which the virtual interface is brought up. The order assigned to an interface should be unique for all the Ethernet and Fibre-Channel interfaces on each PCI link on a VIC adapter. The order should start from zero with no overlaps. The maximum value of PCI order is limited by the number of virtual interfaces (Ethernet and Fibre-Channel) on each PCI link on a VIC adapter. All VIC adapters have a single PCI link except VIC 1340, VIC 1380 and VIC 1385 which have two. Note You cannot change the PCI order of two vNICs without deleting and recreating the vNICs. Not applicable for Auto vNIC Placement.

Property	Description
Consistent Device Naming (CDN) Consistent Device Naming configuration for the virtual NIC.	
Source	Whether the source of the CDN name is the name of the vNIC instance or a user-defined name.
Failover	Enabling failover ensures that traffic automatically fails over from one uplink to another in case of an uplink failure.
Enabled	Enabling failover ensures that traffic from the vNIC automatically fails over to the secondary Fabric Interconnect, in case the specified Fabric Interconnect path goes down. Failover applies only to Cisco VICs that are connected to a Fabric Interconnect cluster.
Ethernet Network Group	<p>Select or create an Ethernet Network Group policy. You can add multiple Ethernet Network Group Policies (ENGPs) on vNICs. The maximum number of ethernet network group policies is restricted to 50 including shared policies.</p> <p>Note This sub-policy is applicable only for the LAN Connectivity Policy on FI-attached servers.</p> <p>You can associate only one ethernet network group policy with a vNIC if QinQ is configured.</p> <p>The native VLAN must be the same across all ethernet network group policies, or must be set in only one ethernet network group policy.</p> <p>Relationship to the Fabric Ethernet Group Policy. Select or create an ethernet network group policy.</p>
Ethernet Network Control	<p>Relationship to the Fabric Ethernet Network Policy. Select or create an ethernet network control policy.</p>
Ethernet QoS	<p>Relationship to the Ethernet QoS Policy. Select or create an ethernet QoS policy.</p>
Ethernet Adapter	<p>Relationship to the the Ethernet Adapter Policy. Select or create an ethernet adapter policy.</p>

Property	Description
iSCSI Boot	<p>Relationship to the boot iSCSI Policy.</p> <ul style="list-style-type: none"> • Not applicable to SR-IOV. • This sub-policy is applicable only for the LAN Connectivity Policy on FI-attached servers. <p>Select or create an iSCSI boot policy.</p>
Connection	
Disabled	Configuration is disabled.
usNIC	
Number of usNICs	Number of usNIC interfaces to be created. When usNIC is enabled, the valid values are from 1 to 225. When usNIC is disabled, the default value is 0.
usNIC Adapter Policy	<p>Ethernet Adapter policy to be associated with the usNICs.</p> <p>Select or create a usNIC adapter policy.</p>
VMQ	
Enable Virtual Machine Multi-Queue	Enables Virtual Machine Multi-Queue feature on the virtual interface. VMMQ allows configuration of multiple I/O queues for a single VM and thus distributes traffic across multiple CPU cores in a VM.
Number of Interrupts	<p>The number of interrupt resources to be allocated. Recommended value is the number of CPU threads or logical processors available in the server.</p> <p>Note Number of Interrupts overrides the Interrupts value in the selected Ethernet Adapter Policy. Number of Virtual Machine Queues overrides Receive Queue Count, Transmit Queue Count, and Completion Queue Count values of the selected Ethernet Adapter Policy.</p>
Number of Virtual Machine Queues	The number of hardware Virtual Machine Queues to be allocated. The number of VMQs per adapter must be one more than the maximum number of VM NICs.
<p>SR-IOV</p> <p>Single Root Input/Output Virtualization (SR-IOV) allows multiple VMs running a variety of Linux guest operating systems to share a single PCIe network adapter within a host server. SR-IOV allows a VM to move data directly to and from the vNIC, bypassing the hypervisor for increased network throughput and lower server CPU overhead.</p> <p>Note SR-IOV setting for Windows Target OS is not supported.</p>	

Property	Description
Number of VFs	Number of VFs to create. Enter a value between 1 and 64. Default value is 64.
Receive Queue Count Per VF	Number of Receive Queue resources to configure for each VF. Enter a value between 1 to 8. Default value is 4.
Transmit Queue Count Per VF	Number of Transmit Queue resources to configure for each VF. Enter a value between 1 to 8. Default value is 1.
Completion Queue Count Per VF	Number of Completion Queue resources to configure for each VF. Enter a value between 1 to 16. Default value is 5.
Interrupt Count Per VF	Number of Interrupt count to configure for each VF. Enter a value between 1 to 16. Default value is 8.
Placement - Advanced	
Automatic Slot ID Assignment	When enabled, slot ID is determined automatically by the system.
Slot ID	When automatic slot ID assignment is disabled, the slot ID needs to be entered manually. Supported values are (1-15) and MLOM.
Automatic PCI link Assignment	When enabled, PCI link is determined automatically by the system. Note If Automatic assignment is enabled for both Slot ID and PCI link, then the behavior is same as Simple placement. All the vNICs are placed on the same PCI link (link 0). If Automatic Slot ID assignment is disabled but automatic PCI link assignment is enabled, then you need to provide the slot ID and the vNIC will be placed on PCI link 0.
Load Balanced	When Automatic PCI link assignment is disabled and Load Balanced is enabled, the system uniformly distributes the interfaces across the PCI Links. If automatic PCI link assignment is disabled and automatic Slot ID is enabled, you need to specify the PCI order to load balance the vNICs. If both automatic PCI link assignment and automatic Slot ID are disabled, you need to specify the slot and the PCI order to load balance the vNICs. Note You cannot change the PCI link mode of two vNICs from Load Balanced mode to Custom mode without deleting and recreating the vNICs. Enter the following fields for Load Balanced option: Switch ID, PCI Order.

Property	Description
Custom	<p>If automatic PCI link assignment is disabled and automatic Slot ID is enabled, you need to provide the value of the PCI order, PCI link, and Switch ID.</p> <p>If both automatic PCI link assignment and automatic Slot ID assignment are disabled, you need to provide the values of the Slot ID, PCI order and the PCI link.</p> <p>Note You cannot change the PCI link mode of two vNICs from Custom mode to Load Balanced mode without deleting and recreating the vNICs. Enter the following fields for Custom option: PCI Link, Switch ID, PCI Order.</p>
PCI Link	<p>The PCI Link used as transport for the virtual interface. PCI Link is only applicable for select Cisco UCS VIC 1300 models (UCSC-PCIE-C40Q-03, UCSB-MLOM-40G-03, UCSB-VIC-M83-8P) that support two PCI links. The value, if specified, for any other VIC model will be ignored.</p> <p>Note Not applicable for Auto vNIC Placement.</p>
Switch ID	The fabric port to which the vNICs will be associated.
PCI Order	<p>The order in which the virtual interface is brought up. The order assigned to an interface should be unique and in sequence starting with "0" for all the Ethernet and Fibre-Channel interfaces on each PCI link on a VIC adapter. The maximum value of PCI order is limited by the number of virtual interfaces (Ethernet and Fibre-Channel) on each PCI link on a VIC adapter.</p> <p>Note You cannot change the PCI order of two vNICs without deleting and recreating the vNICs. Not applicable for Auto vNIC Placement.</p>
Consistent Device Naming (CDN) Consistent Device Naming configuration for the virtual NIC.	
Source	Whether the source of the CDN name is the name of the vNIC instance or a user-defined name.
Failover Enabling failover ensures that traffic automatically fails over from one uplink to another in case of an uplink failure.	

Property	Description
Enabled	Enabling failover ensures that traffic from the vNIC automatically fails over to the secondary Fabric Interconnect, in case the specified Fabric Interconnect path goes down. Failover applies only to Cisco VICs that are connected to a Fabric Interconnect cluster.
Ethernet Network Group	<p>Select or create an Ethernet Network Group policy. You can add multiple Ethernet Network Group Policies (ENGPs) on vNICs. The maximum number of ethernet network group policies is restricted to 50 including shared policies.</p> <p>Note This sub-policy is applicable only for the LAN Connectivity Policy on FI-attached servers.</p> <p>You can associate only one ethernet network group policy with a vNIC if QinQ is configured.</p> <p>The native VLAN must be the same across all ethernet network group policies, or must be set in only one ethernet network group policy.</p> <p>Relationship to the Fabric Ethernet Group Policy. Select or create an ethernet network group policy.</p>
Ethernet Network Control	<p>Relationship to the Fabric Ethernet Network Control Policy. Select or create an ethernet network control policy.</p> <p>Note This sub-policy is applicable only for the LAN Connectivity Policy on FI-attached servers.</p>
Ethernet QoS	<p>Relationship to the Ethernet QoS Policy. Select or create an ethernet QoS policy.</p>
Ethernet Adapter	<p>Relationship to the Ethernet Adapter Policy. Select or create an ethernet adapter policy.</p>
iSCSI Boot	<p>Relationship to the boot iSCSI Policy.</p> <ul style="list-style-type: none"> • Not applicable to SR-IOV. • This sub-policy is applicable only for the LAN Connectivity Policy on FI-attached servers. <p>Select or create an iSCSI boot policy.</p>
Connection	
Disabled	Configuration is disabled.

Property	Description
usNIC	
Number of usNICs	Number of usNIC interfaces to be created. When usNIC is enabled, the valid values are from 1 to 225. When usNIC is disabled, the default value is 0.
usNIC Adapter Policy	Ethernet Adapter policy to be associated with the usNICs. select policy
VMQ	
Enable Virtual Machine Multi-Queue	Enables Virtual Machine Multi-Queue feature on the virtual interface. VMMQ allows configuration of multiple I/O queues for a single VM and thus distributes traffic across multiple CPU cores in a VM.
Number of Interrupts	The number of interrupt resources to be allocated. Recommended value is the number of CPU threads or logical processors available in the server. Note Number of Interrupts overrides the Interrupts value in the selected Ethernet Adapter Policy. Number of Virtual Machine Queues overrides Receive Queue Count, Transmit Queue Count, and Completion Queue Count values of the selected Ethernet Adapter Policy.
Number of Virtual Machine Queues	The number of hardware Virtual Machine Queues to be allocated. The number of VMQs per adapter must be one more than the maximum number of VM NICs.
SR-IOV Single Root Input/Output Virtualization (SR-IOV) allows multiple VMs running a variety of Linux guest operating systems to share a single PCIe network adapter within a host server. SR-IOV allows a VM to move data directly to and from the vNIC, bypassing the hypervisor for increased network throughput and lower server CPU overhead. Note SR-IOV setting for Windows Target OS is not supported.	
Number of VFs	Number of VFs to create. Enter a value between 1 and 64. Default value is 64.
Receive Queue Count Per VF	Number of Receive Queue resources to configure for each VF. Enter a value between 1 to 8. Default value is 4.
Transmit Queue Count Per VF	Number of Transmit Queue resources to configure for each VF. Enter a value between 1 to 8. Default value is 1.
Completion Queue Count Per VF	Number of Completion Queue resources to configure for each VF. Enter a value between 1 to 16. Default value is 5.

Property	Description
Interrupt Count Per VF	Number of Interrupt count to configure for each VF. Enter a value between 1 to 16. Default value is 8.
Template	Setting up a vNIC using a template.
Add vNIC from Template The source vNIC template to apply to the vNIC instance. All configuration settings from the vNIC template will be applied to the vNIC instance except the overridden list of configurations.	
Name	vNIC name.
vNIC Template	The source vNIC template to apply to the vNIC instance. All configuration settings from the vNIC template will be applied to the vNIC instance except the overridden list of configurations. Select or create an vNIC Template.
Graphics vNIC Editor	Displays the graphics vNIC editor details.

Step 7 Click **Add** and then click **Create**.

Disabling SR-IOV VFs Using Cisco Intersight GUI

Procedure

- Step 1** In the **Navigation** pane, click **Policies**.
- Step 2** On the **Policies** page, click **Search**.
- Step 3** Enter the name of created LAN Connectivity policy from above.
- Step 4** Click the **policy**.
- Step 5** From **Actions**, select **Edit**.
- Step 6** Click **Next**.
- Step 7** Select vNIC that you want to disable SR-IOV VFs, and click **Edit**.
- Step 8** From **Connection**, click **Disabled**, and then **Update**.
- Step 9** Click **Save & Proceed**.

Configuring SR-IOV VFs on the EXSi Host Server

Installing Cisco eNIC Driver

Before you begin

Ensure that the required BIOS parameters and SR-IOV VFs configurations are completed.

The inbox driver does not support SR-IOV functionality. To enable SR-IOV, you must install the appropriate driver. For example, Cisco recommends using the enic drivers for SR-IOV functionality.

Procedure

Step 1 Install the enic driver on the host.

The following example shows the installation of eNIC driver on ESXi:

```
[root@localhost:/vmfs/volumes/645c8bdd-c655e553-8ba0-e8d32272f6c0] esxcli software vib install -v /vmfs/volumes/C240M7-Standalone/CIS_bootbank_nenic_2.0.15.0-10EM.800.1.0.20613240.vib --no-sig-check
```

Installation Result

Message: The update completed successfully, but the system needs to be rebooted for the changes to be effective.

VIBs Installed: CIS_bootbank_nenic_2.0.15.0-10EM.800.1.0.20613240

VIBs Removed: CIS_bootbank_nenic_2.0.16.0-10EM.800.1.0.20613240

VIBs Skipped:

Reboot Required: true

DPU Results:

```
[root@localhost:/vmfs/volumes/645c8bdd-c655e553-8ba0-e8d32272f6c0]
```

Step 2 Reboot the server to load the enic driver into the running kernel.

Step 3 After reboot, execute the command `esxcli software vib list | grep nenic` to check the driver version.

For more information, see [Installing Cisco enic and enic_rdma Drivers, on page 32](#).

Verifying the SR-IOV VFs Per Ports on the Host

You can verify the total number of SR-IOV VFs in the following two ways:

Procedure

Step 1 Verify by logging into the VMware ESXi Host Client.:

- Login to the VMware ESXi Host Client.
- Execute the following command to check the vNIC with SR-IOV capability:

```
root@localhost:~] esxcli network sriovnic list
```

Name	PCI Device	Driver	Link	Speed	Duplex	MAC Address	MTU	Description
vmnic0	0000:1b:00.0	nenic	Up	50000	Full	f4:ee:31:30:80:40	1500	Cisco Systems Inc Cisco VIC Ethernet NIC

The following output shows the number of VF configured on vNIC:

```
[root@localhost:~] esxcli network sriovnic vf list -n vmnic0
```

VF ID	Active	PCI Address	Owner	World ID
0	false	00000:027:00.1	-	-
1	false	00000:027:00.2	-	-
2	false	00000:027:00.3	-	-
3	false	00000:027:00.4	-	-
4	false	00000:027:00.5	-	-
5	false	00000:027:00.6	-	-
6	false	00000:027:00.7	-	-
7	false	00000:027:01.0	-	-

Step 2 Alternatively, you can also access your host from vSphere vCenter Client.

For more information on configuring SR-IOV VFs on the host, see [Creating SR-IOV VFs on the Host](#).

After you reboot the host server, do the following:

- Login to the ESXi Host Client, and choose **Networking > Virtual Switches**.
- Click **Add Standard Virtual Switch**.
- Add a switch name in the **vSwitch Name** field, select the vmnic with SR-IOV capability, and click **Add**.
The maximum number of Virtual Functions (VFs) is set to 10.
- In the **Port Groups** tab, click **Add Port Group**.
- In the **Add Port Group** dialog-box, add a new port group and select the switch from the **Virtual Switch** drop-down.

Creating SR-IOV VFs on the Host

Procedure

Step 1 Login to your VMware ESXi Host Client.

Alternatively, you can also access your host from vSphere vCenter Client and browse to **Configure > Networking > Physical adapters**.

Step 2 Go to **Host > Manage** and select the **Hardware** tab.

Step 3 Select **PCI Devices** from the list.

Step 4 From the drop-down list, select **SR-IOV Capable**.

The list shows all the SR-IOV capable devices.

Step 5 Select the vNIC for which you wish to create the VFs.

Step 6 Click **Configure SR-IOV**.

Configure SR-IOV for Cisco VIC Ethernet NIC window is displayed.

Step 7 Perform the following:

Field	Description
Enabled radio button	Select Yes to enable the configuration.
Virtual functions field	Number of VFs as configured on SRIOV connection policy that are available for the configuration. Enter an integer between 1 and 64.

Step 8 Click **Save** and then reboot the host server.

Configuring the Switch

Before you begin

Ensure that the SR-IOV VFs are configured.

Procedure

Step 1 Login to your VMware ESXi Host Client.

Step 2 Navigate to **Host > Networking** and select the **Virtual switches** tab.

Step 3 Click **Add Standard Virtual Switch**.

Step 4 Enter the name for the switch.

Step 5 Select a SR-IOV Capable Vmnic from the list.

Step 6 Click **Add**.

Step 7 Complete the following:

Field	Description
vSwitch Name field	Enter a suitable name for the virtual switch.
MTU field	Enter the maximum transmission unit. The default is 1500 bytes.
Uplink 1 drop-down list	From the drop-down list, select the PCIe devices for which you created the SR-IOVs.

Field	Description
Link Discovery	<p>From the drop-down list, select the Mode and the Protocol.</p> <p>Note These fields remain as default.</p>
Security	<p>Choose from the following options:</p> <ul style="list-style-type: none"> • Promiscuous mode—Accept, Reject, or Inherit from vSwitch. • MAC address changes—Accept, Reject, or Inherit from vSwitch. • Forged trasmits—Accept, Reject, or Inherit from vSwitch.
NIC teaming	<p>Choose from the following:</p> <ul style="list-style-type: none"> • Load balancing—From the drop-down list choose the Load balancing. Values are: Inherit from vSwitch, • Network failover detection—From the drop-down list choose the network failover detection. Values are: Inherit from vSwitch, • Notify switches—Choose the notify switches. Values are Yes, No, Inherit from vSwitch. • Fallback—Choose the fallback. Values are Yes, No, Inherit from vSwitch. • Override failover order—From the drop-down list choose the override failover order. Values are Yes or No, • Failover order—Choose the failover order.
Traffic Shaping	<p>Perform the following:</p> <ul style="list-style-type: none"> • Status—Choose the status. Values are Enabled, Disabled, Inherit from vSwitch. • Average bandwidth—Enter the average bandwidth. • Peek bandwidth—Enter the peek bandwidth. • Burst size—Enter the burst size. <p>Note Traffic shaping policy is applied to the traffic of each virtual network adapter attached to the virtual switch.</p>

What to do next

[Creating a Virtual Port, on page 67](#)

Creating a Virtual Port

Before you begin

Ensure that the SR-IOV VFs are configured.

Procedure

- Step 1** Login to your VMware ESXi Host Client.
- Step 2** Go to **Host > Networking** and select the **Port Groups** tab.
- Step 3** Click **Add port group**.
Add port group-New port group window is displayed
- Step 4** Complete the following:

Field	Description
Name field	Enter a suitable name for the virtual port.
VLAN ID field	Enter the VLAN ID.
Virtual Switch drop-down list	From the drop-down list, select the virtual switch.
Security	Choose from the following options: <ul style="list-style-type: none">• Promiscuous mode—Accept, Reject, or Inherit from vSwitch.• MAC address changes—Accept, Reject, or Inherit from vSwitch.• Forged trasmits—Accept, Reject, or Inherit from vSwitch.

- Step 5** Click **Add**.

Creating a New Virtual Machine (VM)

Before you begin

- Login to vCenter using the credentials
- OS ISO image is copied to the datastore of the host server.

Procedure

[Installing OS on Guest VM on ESXi.](#)

Adding SR-IOV VF on the Virtual Machine

Before you begin

Power off the Virtual Machine.

Procedure

- Step 1** In the Virtual Machine Manager, right-click on the Virtual Machine and select **Open**.
- Step 2** Click the **Show Virtual Hardware Detail** icon next to **Monitor** icon.
- Step 3** Click **Add Hardware**.
- Step 4** In the **Add New Virtual Hardware** window, select **PCI Host Device**. Under the **PCI Device Details** tab, assign a created SR-IOV VF to the Virtual Machine.
- Step 5** Click **Finish**.
- Step 6** Power on the Virtual Machine.

What to do next

You can now log into the virtual machine, install Cisco eNIC driver version, reboot the virtual machine, and then use the ip link command to verify the added SR-IOV VF. For more information, see [Installing Cisco eNIC Driver](#).

Installing OS on Guest VM on ESXi

Before you begin

Upload the Linux operating system ISO on the datastore.

Procedure

- Step 1** Right-click the host node and navigate to **vCenter > New Virtual machine**.
- Step 2** Select a **Creation Type > Create New Virtual Machine**, and click **Next**.
- Step 3** Enter a name for the folder, and click **Next**.
- Step 4** Select a compute resource, choose a node and click **Next**.
- Step 5** Select Storage and check the datastore radio-button, and click **Next**.

- Step 6** Select the compatibility ESXi 8.0 or later and click **Next**.
- Step 7** Select a guest OS version as **RHEL Linux9 (64-bit)**, and click **Next**.
- Step 8** Customize the hardware set **CPU** to 2, and **Memory** values to 4 GB.
- Step 9** Expand the **Memory** tab, and check **Reserve all guest memory (All lockset)** check box.
- Step 10** Select **New CD/DVD Drive (Datastore ISO file)**, and check the **Connect At Power On** check box.
- Step 11** Under **CD/DVD Media**, browse and select the Linux ISO image and click **Next**.
- Step 12** Click **Finish**.

Configuring SR-IOV VFs on the Linux Host Server

Installing Cisco eNIC Driver and Enabling IOMMU in Linux Kernel

Before you begin

Ensure that the required BIOS parameters and SR-IOV VFs configurations are completed.

Procedure

- Step 1** Install the enic driver on the host.

Following example shows the installation of eNIC driver on RHEL:

```
[user@rack-111 drivers]# rpm -ivh kmod-enic-4.7.0.5-1076.6.rhel9u4_5.14.0_427.13.1.x86_64.rpm
Verifying... ##### [100%]
Preparing... ##### [100%]
Updating / installing...
 1:kmod-enic-4.7.0.5-1076.6.rhel9u4_##### [100%]
[user@rack-111 drivers]#
```

- Step 2** Enable IOMMU on the host using **grubby** command.

Following example shows how to enable IOMMU on RHEL:

```
[user@rack-111 drivers]# grubby --update-kernel=ALL --args="intel_iommu=on iommu=pt"
```

- Step 3** Reboot the server to load the enic driver into the running kernel.

- Step 4** Execute **modinfo enic** to check enic driver is loaded.

Following example shows the output of **modinfo enic** command:

```
[user@rack-111 drivers]# modinfo enic
filename:      /lib/modules/5.14.0-427.13.1.el9_4.x86_64/extra/enic/enic.ko
version:      4.7.0.5-1076.6
retpoline:    Y
license:      GPL v2
author:       Scott Feldman scofeldm@cisco.com
description:  Cisco VIC Ethernet NIC Driver
rhelversion:  9.4
srcversion:   3A1B1E81C9641925B34D1B2
alias:        pci:v00001137d000002B7sv*sd*bc*sc*i*
alias:        pci:v00001137d00000071sv*sd*bc*sc*i*
```

```

alias:          pci:v00001137d000000044sv*sd*bc*sc*i*
alias:          pci:v00001137d000000043sv*sd*bc*sc*i*
depends:
retpoline:      Y
name:           enic
vermagic:        5.14.0-427.13.1.el9_4.x86_64 SMP preempt mod_unload modversions
sig_id:          PKCS#7
signer:          Cisco UCS Driver Signing REL Cert
sig_key:         D0:54:9A:88:88:DD:0E:7A
sig_hashalgo:    sha256
signature:       89:9C:DA:53:D1:FF:0A:DA:98:9A:7F:AF:63:29:66:EB:FF:0C:D6:65:
                 39:6C:15:40:30:6E:99:4B:2C:F0:54:2E:EB:A4:8A:33:D5:9C:41:7A:
                 A4:DB:C8:52:55:74:3A:68:F3:22:36:7B:2A:7C:7C:40:8B:7F:6D:9E:
                 A5:CF:06:F1:23:42:E6:60:DB:78:0E:46:C9:0C:BC:06:9B:02:A0:AA:
                 5A:FC:36:A3:FB:B0:FE:76:F2:EB:2F:AD:AD:84:89:61:30:7D:E9:2F:
                 5D:E1:3E:EA:7C:10:B2:42:94:CD:4F:74:19:A6:16:FE:75:B6:78:49:
                 E8:F0:4A:A9:01:BB:92:44:A9:FE:C7:CE:DB:E8:F5:08:AF:36:1E:5F:
                 30:D3:B1:5F:70:62:56:6F:C2:38:8E:F2:88:28:0F:44:29:E5:44:66:
                 34:B7:5C:A7:5E:21:C3:5D:42:D8:C0:87:CA:40:5E:C4:C0:2C:DA:26:
                 D2:25:9B:58:A8:84:C6:A6:41:B3:24:9C:D7:E6:4A:79:42:00:32:82:
                 7A:CB:36:D8:79:1D:41:1A:9E:1C:A8:0D:39:6D:C8:F1:0D:44:FA:00:
                 93:1E:A3:C9:61:AA:DE:25:4A:38:68:C3:9C:14:55:5B:D3:AC:1C:85:
                 00:FE:57:F1:DE:F7:A8:04:64:0E:5D:35:D8:AF:CF:A4
parm:           rxcopybreak:Maximum size of packet that is copied to a new buffer on receive (uint)
[user@rack-111 drivers]#

```

Verifying the Total number of SR-IOV VFs per Port on the Host

Before you begin

Ensure that Cisco eNIC driver is installed.

Procedure

Log into the host server and run the following command and replace *interface_name* with actual interface name on the host.

```
# cat /sys/class/net/interface_name/device/sriov_totalvfs
```

Example

Following example shows the total number for SR-IOV VFs created from SRIOV HPN Connection Policy on plp1 interface:

```

[user@rack-111 ~]# cat /sys/class/net/plp1/device/sriov_totalvfs
32
[user@rack-111 ~]#

```

Creating SR-IOV VFs on the Host

Enabling SR-IOV VFs from SRIOV HPN Connection Policy does not create SR-IOV VFs on the host by default. To create SR-IOV VFs on the host, use the following procedure:

Procedure

Step 1 Execute the following command to create SR-IOV VFs on the host:
echo number_of_sriov_devices > /sys/class/net/sriov interface_name/device/sriov_numvfs

Example:

Following example shows the creation of 6 SR-IOV VFs on p1p1 interface.

```
[user@rack-111 ~]# echo 6 > /sys/class/net/plp1/device/sriov_numvfs
[user@rack-111 ~]#
```

Step 2 Execute the following command to verify the SR-IOV VFs created:
cat /sys/class/net/interface_name/device/sriov_numvfs

Example:

Following example shows the verification of SR-IOV VFs on p1p1 interface.

```
[user@rack-111 ~]# cat /sys/class/net/plp1/device/sriov_numvfs
6
[user@rack-111 ~]#
```

Step 3 (Optional) Alternatively, IP link command shows created SR-IOV VFs.
ip link show interface_name

Example:

Following example shows created 6 SR-IOV VFs on p1p1 interface.

```
[user@rack-111 ~]# ip link show plp1
2: plp1: <BROADCAST, MULTICAST, UP, LOWER_UP>mtu 9000 qdisc mq state UP mode
DEFAULT group default qlen 10 00
link/ether 98: a2:c0:66:32:80 brd ff:ff:ff:ff:ff:ff
vf 0 link/ether 00:00:00:00:00:00 brd ff:ff:ff:ff:ff:ff, spoof checking off,
link-state auto, trust off, query_rss off
vf 1 link/ether 00:00:00:00:00:00 brd ff:ff:ff:ff:ff:ff, spoof checking off,
link-state auto, trust off, query_rss off
vf 2 link/ether 00:00:00:00:00:00 brd ff:ff:ff:ff:ff:ff, spoof checking off,
link-state auto, trust off, query_rss off
vf 3 link/ether 00:00:00:00:00:00 brd ff:ff:ff:ff:ff:ff, spoof checking off,
link-state auto, trust off, query_rss off
vf 4 link/ether 00:00:00:00:00:00 brd ff:ff:ff:ff:ff:ff, spoof checking off,
link-state auto, trust off, query_rss off
vf 5 link/ether 00:00:00:00:00:00 brd ff:ff:ff:ff:ff:ff, spoof checking off,
link-state auto, trust off, query_rss off
altname enp9s0
altname eno5
[user@rack-111 ~]#
```

Note

After the host server reboots, the created SR-IOV VFs are removed from the host. By adding the command from Step 1 to rc.local file, the same number of SR-IOV VFs can be created each time the host server boots up.

What to do next

You can create a new virtual machine.

Creating a New Virtual Machine (VM)

Before you begin

- Host with Desktop Environment
- Virtualization packages are installed
- Copy OS ISO image to the sever datastore

Procedure

Step 1 Verify the virtualization is enabled on the host server by using this command.

lscpu | grep Virtualization

Example:

This example shows the Intel's virtualization technology VT-x is enabled.

```
[user@rack-111 ~]$ lscpu | grep Virtualization
Virtualization: VT-x
[user@rack-111 ~]$
```

Step 2 Verify the KVM modules are loaded by using this command.

lsmod | grep kvm

Example:

This example shows KVM modules are loaded in the host server.

```
[user@rack-111 ~]$ lsmod | grep kvm
kvm_intel      409600      8
kvm            1134592      1 kvm_intel
irqbypass      6384        290 vfio_pci_core, kvm
[user@rack-111 ~]$
```

Step 3 Type **virt-manager** command at the terminal to launch Virtual Machine Manager GUI.

Step 4 At the Virtual Machine Manager, click **File > New Virtual Machine** to create a new virtual machine.

Step 5 At **New VM window**, select **Local install media (ISO image or CDROM)** option and click **Forward**.

Step 6 At **Choose ISO or CDROM install media**, click **Browse**.

Step 7 At **Locate ISO media volume** window, click **Browser Local**.

Step 8 Go to the folder that has ISO image. Select ISO image and click **Open**.

- Step 9** Click **Forward**.
- Step 10** Select the desired Memory and CPU settings for the VM and click **Forward**.
- Step 11** Choose the VM's disk image size and click **Forward**.
- Step 12** Enter a name for the VM in the **Name** field and click **Finish**.
- You may monitor the OS installation progress.
-

Adding SR-IOV VF on the Virtual Machine

Before you begin

Power off the Virtual Machine.

Procedure

- Step 1** In the Virtual Machine Manager, right-click on the Virtual Machine and select **Open**.
- Step 2** Click the **Show Virtual Hardware Detail** icon next to **Monitor** icon.
- Step 3** Click **Add Hardware**.
- Step 4** In the **Add New Virtual Hardware** window, select **PCI Host Device**. Under the **PCI Device Details** tab, assign a created SR-IOV VF to the Virtual Machine.
- Step 5** Click **Finish**.
- Step 6** Power on the Virtual Machine.
-

What to do next

You can now log into the virtual machine, install Cisco eNIC driver version, reboot the virtual machine, and then use the `ip link` command to verify the added SR-IOV VF. For more information, see [Installing Cisco eNIC Driver](#).

