



# Viewing Server Properties

---

This chapter includes the following sections:

- [Viewing Server Properties, page 1](#)
- [Viewing CIMC Information, page 2](#)
- [Viewing CPU Properties, page 3](#)
- [Viewing Memory Properties, page 3](#)
- [Viewing Power Supply Properties, page 5](#)
- [Viewing Storage Properties, page 6](#)
- [Viewing PCI Adapter Properties, page 7](#)

## Viewing Server Properties

### Procedure

---

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Summary**.
- Step 3** In the **Server Properties** area of the **Server Summary** pane, review the following information:

Name	Description
<b>Product Name</b> field	The model name of the server.
<b>Serial Number</b> field	The serial number for the server.
<b>PID</b> field	The product ID.
<b>UUID</b> field	The UUID assigned to the server.
<b>BIOS Version</b> field	The version of the BIOS running on the server.

Name	Description
Description field	A user-defined description for the server.

## Viewing CIMC Information

### Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Summary**.
- Step 3** In the **Cisco Integrated Management Controller (CIMC) Information** area of the **Server Summary** pane, review the following information:

Name	Description
Hostname field	A user-defined hostname for the CIMC.
IP Address field	The IP address for the CIMC.
MAC Address field	The MAC address assigned to the active network interface to the CIMC.
Firmware Version field	The current CIMC firmware version.
Current Time field	The current date and time according to the CIMC clock.  <b>Note</b> CIMC gets the current date and time from the server BIOS. To change this information, reboot the server and press F2 when prompted to access the BIOS configuration menu. Then change the date or time using the options on the main BIOS configuration tab.

# Viewing CPU Properties

## Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Inventory**.
- Step 3** In the **Inventory** pane, click the **CPUs** tab.
- Step 4** Review the following information for each CPU:

Name	Description
<b>Socket Name</b> field	The socket in which the CPU is installed.
<b>Vendor</b> field	The vendor for the CPU.
<b>Status</b> field	The status of the CPU.
<b>Family</b> field	The family to which this CPU belongs.
<b>Speed</b> field	The CPU speed, in megahertz.
<b>Version</b> field	The CPU version.
<b>Number of Cores</b> field	The number of cores in the CPU.
<b>Signature</b> field	The signature information for the CPU.
<b>Number of Threads</b> field	The maximum number of threads that the CPU can process concurrently.

# Viewing Memory Properties

## Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Inventory**.
- Step 3** In the **Inventory** pane, click the **Memory** tab.
- Step 4** In the **Memory Summary** area, review the following summary information about memory:

Name	Description
<b>Memory Speed</b> field	The memory speed, in megahertz.

Name	Description
<b>Failed Memory</b> field	The amount of memory that is currently failing, in megabytes.
<b>Total Memory</b> field	The total amount of memory available on the server if all DIMMs are fully functional.
<b>Ignored Memory</b> field	The amount of memory currently not available for use, in megabytes.
<b>Effective Memory</b> field	The actual amount of memory currently available to the server.
<b>Number of Ignored DIMMs</b> field	The number of DIMMs that the server cannot access.
<b>Redundant Memory</b> field	The amount of memory used for redundant storage.
<b>Number of Failed DIMMs</b> field	The number of DIMMs that have failed and cannot be used.
<b>Memory RAS Possible</b> field	Details about the RAS memory configuration that the server supports.
<b>Memory Configuration</b> field	The current memory configuration. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Maximum Performance</b>—The system automatically optimizes the memory performance.</li> <li>• <b>Mirroring</b>—The server maintains two identical copies of the data in memory. This option effectively halves the available memory on the server, as one half is automatically reserved for mirrored copy.</li> <li>• <b>Sparing</b>—The system reserves some memory for use in the event a DIMM fails. If that happens, the server takes the DIMM offline and replaces it with the reserved memory. This option provides less redundancy than mirroring, but it leaves more of the memory available for programs running on the server.</li> </ul>

**Step 5** In the **Memory Details** table, review the following detailed information about each DIMM:

**Tip** Click a column header to sort the table rows, according to the entries in that column.

Name	Description
<b>Name</b> column	The name of the DIMM slot in which the memory module is installed.
<b>Capacity</b> column	The size of the DIMM.
<b>Channel Speed</b> column	The clock speed of the memory channel, in megahertz.
<b>Channel Type</b> column	The type of memory channel.
<b>Memory Type Detail</b> column	The type of memory used in the device.

Name	Description
<b>Bank Locator</b> column	The location of the DIMM within the memory bank.
<b>Manufacturer</b> column	The vendor ID of the manufacturer. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>0x2C00</b>—Micron Technology, Inc.</li> <li>• <b>0x5105</b>—Qimonda AG i. In.</li> <li>• <b>0x802C</b>—Micron Technology, Inc.</li> <li>• <b>0x80AD</b>—Hynix Semiconductor Inc.</li> <li>• <b>0x80CE</b>—Samsung Electronics, Inc.</li> <li>• <b>0x8551</b>—Qimonda AG i. In.</li> <li>• <b>0xAD00</b>—Hynix Semiconductor Inc.</li> <li>• <b>0xCE00</b>—Samsung Electronics, Inc.</li> </ul>
<b>Serial Number</b> column	The serial number of the DIMM.
<b>Asset Tag</b> column	The asset tag associated with the DIMM, if any.
<b>Part Number</b> column	The part number for the DIMM assigned by the vendor.
<b>Visibility</b> column	Whether the DIMM is available to the server.
<b>Operability</b> column	Whether the DIMM is currently operating correctly.
<b>Data Width</b> column	The amount of data the DIMM supports, in bits.

## Viewing Power Supply Properties

### Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Inventory**.
- Step 3** In the **Inventory** pane, click the **Power Supplies** tab.
- Step 4** Review the following information for each power supply:
  - Tip** Click a column header to sort the table rows, according to the entries in that column.

Name	Description
<b>Device ID</b> column	The identifier for the power supply unit.
<b>Input</b> column	The input into the power supply, in watts.
<b>Max Output</b> column	The maximum output from the power supply, in watts.
<b>FW Version</b> column	The firmware version for the power supply.
<b>Product ID</b> column	The product identifier for the power supply assigned by the vendor.

## Viewing Storage Properties

### Procedure

- Step 1** In the **Navigation** pane, click the **Server** tab.
- Step 2** On the **Server** tab, click **Inventory**.
- Step 3** In the **Inventory** pane, click the **Storage** tab.
- Step 4** In the **Storage Adapters** area, review the information about the available adapter cards. This area contains a table listing all MegaRAID and Cisco Flexible Flash controllers on the server that can be managed through CIMC. To view details about a particular storage device, select it in the table and view the information in the tabs below.
- If a particular storage device does not appear on this tab it cannot be managed through CIMC. To view the status of an unsupported device, see the documentation for that device.
- Tip** Click a column header to sort the table rows, according to the entries in that column.
- Step 5** In the **Storage Adapters** area, click a row to view the detailed properties of that adapter. The properties of the selected storage adapter appear in the tabbed menu below the **Storage Adapters** area.
- Step 6** Select the **Controller Info** tab and review the information. This tab displays information about the MegaRAID controller or Cisco Flexible Flash controller selected in the **Storage Adapters** table.
- Note** For detailed descriptions of the fields displayed in this tab and the following tabs, see the online help provided in the UCSM GUI.
- Step 7** Select the **Physical Drive Info** tab and review the information. This tab shows the following information for the controller selected in the **Storage Adapters** table.
- General drive information
  - Identification information
  - Drive status

**Step 8** Select the **Virtual Drive Info** tab and review the information.

This tab shows the following information for the controller selected in the **Storage Adapters** table.

- General drive information
- RAID information
- Physical drive information

**Step 9** Select the **Battery Backup Unit** tab and review the information.

This tab shows information about the backup battery on the controller selected in the **Storage Adapters** table.

**Note** This tab does not apply if you select a Cisco Flexible Flash controller in the **Storage Adapters** table.

## Viewing PCI Adapter Properties

### Before You Begin

The server must be powered on, or the properties will not display.

### Procedure

**Step 1** In the **Navigation** pane, click the **Server** tab.

**Step 2** On the **Server** tab, click **Inventory**.

**Step 3** In the **Inventory** pane, click the **PCI Adapters** tab.

**Step 4** In the **PCI Adapters** area, review the following information for the installed PCI adapters:

Name	Description
Slot ID column	The slot in which the adapter resides.
Product Name column	The name of the adapter.
Vendor ID column	The adapter ID assigned by the vendor.
Sub Vendor ID column	The secondary adapter ID assigned by the vendor.
Device ID column	The device ID assigned by the vendor.
Sub Device ID column	The secondary device ID assigned by the vendor.

