



Configuring Chassis Related Settings

This chapter includes the following sections:

- [Managing Server Power, on page 1](#)
- [Pinging a Hostname/IP Address from the Web UI, on page 2](#)
- [Toggling the Locator LEDs, on page 2](#)
- [Selecting a Time Zone, on page 3](#)

Managing Server Power

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

- Step 1** In the **Navigation** pane, click the **Chassis** menu.
- Step 2** In the **Chassis** menu, click **Summary**.
- Step 3** In the toolbar above the work pane, click the **Host Power** link.
- Step 4** From the drop-down list, select one of the following options:

Actions	Description
Power On	Powers on the chosen server.
Power Off	Powers off the chosen server, even if tasks are running on that server. Important If any firmware or BIOS updates are in progress, do not power off or reset the server until those tasks are complete.
Power Cycle	Powers off and powers on chosen server.
Hard Reset	Reboots the chosen server.

Actions	Description
Shut Down	Shuts down the chosen server if the operating system supports that feature.

Pinging a Hostname/IP Address from the Web UI

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

Step 1 In the toolbar above the work pane, click the **Ping** icon.

Step 2 In the **Ping Details** dialog box, update the following fields:

Actions	Description
* Hostname/IP Address field	Hostname or IP address you want to reach out to.
* Number of Retries field	The maximum number of retries allowed to ping the IP address. The default value is 3. The valid range is from 1 to 10.
* Timeout field	The maximum response time for a pinging activity. The default value is 10 seconds. The valid range is from 1 to 20 seconds.
Ping Status field	Displays results of the pinging activity.
Details button	Displays details of the pinging activity.
Ping button	Pings the IP address.
Cancel button	Closes the dialog box without pinging.

Step 3 Click **Ping**.

Toggling the Locator LEDs

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

- Step 1** In the **Navigation** pane, click the **Chassis** menu.
 - Step 2** In the **Chassis** menu, click **Summary**.
 - Step 3** In the toolbar above the work pane, click the **Locator LED** link.
 - Step 4** Select **Turn On Locator LED** or **Turn Off Locator LED**.
-

Selecting a Time Zone

Before you begin

You must log in with admin privileges to perform this task.

Procedure

- Step 1** In the **Navigation** pane, click the **Chassis** menu.
 - Step 2** In the **Chassis** menu, click **Summary**.
 - Step 3** In the **Cisco Integrated Management Controller (Cisco IMC) Information** area, click **Select Timezone**.
Select Timezone screen appears.
 - Step 4** In the **Select Timezone** pop-up screen, mouse over the map and click on the location to select your time zone or choose your time zone from the **Timezone** drop-down menu.
 - Step 5** Click **OK**.
-

