



Overview

This chapter includes the following sections:

- [Cisco UCS E-Series Servers and the Cisco UCS E-Series Network Compute Engine Overview, on page 1](#)
- [Server Software, on page 2](#)
- [Cisco Integrated Management Controller, on page 3](#)
- [Overview of the Cisco IMC User Interface, on page 4](#)

Cisco UCS E-Series Servers and the Cisco UCS E-Series Network Compute Engine Overview

The Cisco UCS E-Series Servers (E-Series Servers) and Cisco UCS E-Series Network Compute Engine (NCE) are a family of size-, weight-, and power-efficient blade servers that are housed within the Generation 2 Cisco Integrated Services Routers (Cisco ISR G2) and the Cisco ISR 4000 series. These servers provide a general purpose compute platform for branch-office applications deployed either as bare-metal on operating systems, such as Microsoft Windows or Linux, or as virtual machines on hypervisors, such as VMware vSphere Hypervisor, Microsoft Hyper-V, or Citrix XenServer.

The E-Series Servers are purpose-built with powerful Intel Xeon processors for general purpose compute. They come in two form factors: single-wide and double-wide. The single-wide E-Series Server fits into one service module (SM) slot, and the double-wide E-Series Server fits into two SM slots.

The NCEs are price-to-power optimized modules that are built to host Cisco network applications and other lightweight general-purpose applications. They come in three form factors: SM, NIM, and EHWIC. The SM E-Series NCE fits into one SM slot, the NIM E-Series NCE fits into one NIM slot, and the EHWIC E-Series NCE fits into two EHWIC slots.



Note

- The EHWIC E-Series NCE can be installed in the the Cisco ISR G2 only.
 - The NIM E-Series NCE can be installed in the Cisco ISR 4000 series only.
 - The Cisco ISR 4331 has one SM slot. The Cisco ISR 4321 and the Cisco ISR 4431 have no SM slots.
 - Citrix XenServer is supported on the E-Series Servers only.
 - CIMC 3.2.x is not supported on EHWIC NCEs.
-



Note For information about the supported E-Series Servers and NCE, and the maximum number of servers that can be installed per router, see the "Hardware Requirements" section in the *Hardware Installation Guide for Cisco UCS E-Series Servers and the Cisco UCS E-Series Network Compute Engine*.

Server Software

E-Series Servers and NCE require three major software systems:

- CIMC firmware
- BIOS firmware
- Operating system or hypervisor

CIMC Firmware

Cisco Integrated Management Controller (CIMC) is a separate management module built into the motherboard of the E-Series Server or NCE. A dedicated ARM-based processor, separate from the main server CPU, runs the CIMC firmware. The system ships with a running version of the CIMC firmware. You can update the CIMC firmware, but no initial installation is needed.

CIMC is the management service for the E-Series Servers and NCE. You can use a web-based GUI or SSH-based CLI to access, configure, administer, and monitor the server.

BIOS Firmware

BIOS initializes the hardware in the system, discovers bootable devices, and boots them in the provided sequence. It boots the operating system and configures the hardware for the operating system to use. BIOS manageability features allow you to interact with the hardware and use it. In addition, BIOS provides options to configure the system, manage firmware, and create BIOS error reports.

The system ships with a running version of the BIOS firmware. You can update the BIOS firmware, but no initial installation is needed.

Operating System or Hypervisor

The main server CPU runs on an operating system, such as Microsoft Windows or Linux; or on a hypervisor. You can purchase an E-Series Server or NCE with a preinstalled Microsoft Windows Server or VMware vSphere Hypervisor, or you can install your own platform.



Note For information about the platforms that have been tested on the E-Series Servers or NCE, see the "Software Requirements" section in the *Release Notes for Cisco UCS E-Series Servers and the Cisco UCS E-Series Network Compute Engine*.

Cisco Integrated Management Controller

The Cisco IMC is the management service for the E-Series servers. Cisco IMC runs within the server.



Note The management service is used only when the server is operating in Standalone Mode. If your E-Series server is integrated into a UCS system, you must manage it using UCS Manager. For information about using UCS Manager, see the configuration guides listed in the *Cisco UCS E-Series Servers Documentation Roadmap* at http://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/e/1-0/roadmap/e_series_road_map.html.

Management Interfaces

You can use a web-based GUI or SSH-based CLI or an XML-based API to access, configure, administer, and monitor the server. Almost all tasks can be performed in either interface, and the results of tasks performed in one interface are displayed in another. However, you cannot do the following:

- Use GUI to invoke CLI
- View a command that has been invoked through CLI in GUI
- Generate CLI output from GUI

Tasks You Can Perform in

You can use to perform the following chassis management tasks:

- Power on, power off, power cycle, reset and shut down the server
- Toggle the locator LED
- Configure the server boot order
- View server properties and sensors
- Manage remote presence
- Create and manage local user accounts, and enable remote user authentication through Active Directory
- Configure network-related settings, including NIC properties, IPv4, VLANs, and network security
- Configure communication services, including HTTP, SSH, IPMI Over LAN, and SNMP.
- Manage certificates
- Configure platform event filters
- Update firmware
- Monitor faults, alarms, and server status
- Set time zone and view local time
- Install and activate firmware
- Install and activate BIOS firmware

- Install and activate CMC firmware

You can use to perform the following server management tasks:

- Manage remote presence
- Create and manage local user accounts, and enable remote user authentication through Active Directory
- Configure network-related settings, including NIC properties, IPv4, VLANs, and network security
- Configure communication services, including HTTP, SSH, IPMI Over LAN, and SNMP.
- Manage certificates
- Configure platform event filters
- Update firmware
- Monitor faults, alarms, and server status
- Set time zone and view local time

No Operating System or Application Provisioning or Management

provisions servers, and as a result, exists below the operating system on a server. Therefore, you cannot use it to provision or manage operating systems or applications on servers. For example, you cannot do the following:

- Deploy an OS, such as Windows or Linux
- Deploy patches for software, such as an OS or an application
- Install base software components, such as anti-virus software, monitoring agents, or backup clients
- Install software applications, such as databases, application server software, or web servers
- Perform operator actions, including restarting an Oracle database, restarting printer queues, or handling non- user accounts
- Configure or manage external storage on the SAN or NAS storage

Overview of the Cisco IMC User Interface

The Cisco IMC user interface is a web-based management interface for Cisco E-Series servers. The web user interface is developed using HTML5 with the eXtensible Widget Framework (XWT) framework. You can launch the user interface and manage the server from any remote host that meets the following minimum requirements:


- Microsoft Internet Explorer 6.0 or higher, Mozilla Firefox 3.0 or higher
- Microsoft Windows 7, Microsoft Windows XP, Microsoft Windows Vista, Apple Mac OS X v10.6, Red Hat Enterprise Linux 5.0 or higher operating systems
- Transport Layer Security (TLS) version 1.2



Note In case you lose or forget the password that you use to log in to Cisco IMC, see the password recovery instructions in the Hardware Installation Guide for Cisco UCS E-Series Servers and the Cisco UCS E-Series Network Compute Engine. This guide is available at http://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/e/1-0/roadmap/e_series_road_map.html.

Cisco IMC Home Page

When you first log into , the user interface looks similar to the following illustration:



Navigation and Work Panes

The Cisco Integrated Management Controller GUI comprises the **Navigation** pane on the left hand side of the screen and the **Work** pane on the right hand side of the screen. Clicking links on the **Server**, **Chassis**, **Compute**, **Storage** or **Admin** menu in the **Navigation** pane displays the associated tabs in the **Work** pane on the right.

The **Navigation** pane header displays action buttons that allow you to view the navigation map of the entire GUI, view the index, or select a favorite work pane to go to, directly. The **Pin** icon prevents the **Navigation** pane from sliding in once the **Work** pane displays.

The **Favorite** icon is a star shaped button which allows you to make any specific work pane in the application as your favorite. To do this, navigate to the work pane of your choice and click the **Favorite** icon. To access this work pane directly from anywhere else in the application, click the **Favorite** icon again.

The GUI header displays information about the overall status of the chassis and user login information.

The GUI header also displays the total number of faults (indicated in green or red), with a **Bell** icon next to it. However, clicking this icon displays the summary of only the critical and major faults of various components. To view all the faults, click the **View All** button to display the **Fault Summary** pane.



Note User interface options may vary depending on the server.

The **Navigation** pane has the following menus:

- **Chassis** Menu
- **Compute** Menu
- **Storage** Menu
- **Admin** Menu

Chassis Menu

Each node in the **Chassis** menu leads to one or more tabs that display in the **Work** pane. These tabs provides access to the following information:

Chassis Menu Node Name	Work Pane Tabs Provide Information About...
Inventory	Servers, power supplies, Cisco VIC adapters, and Dynamic Storage management information.
Sensors	Power supply, fan, temperature, voltage, current, and LED readings.
Faults and Logs	Fault summary, fault history, system event log, Cisco IMC logs, and logging controls.

Compute Menu

The **Compute** menu contains information about the server, and the following information is displayed in the **Work** pane.

Compute Menu Node Name	Work Pane Tabs Provide Information About...
Inventory	Installed CPUs, memory cards, PCI adapters, Cisco VIC adapters, vNICs, storage information and trusted platform module (TPM).
BIOS	The installed BIOS firmware version and the server boot order.
Remote Management	KVM, virtual media, and Serial over LAN settings.
Troubleshooting	Bootstrap processing, Crash recording, and a player to view the last saved bootstrap process.
Power Policies	Power restore policy settings.
Host Image Mapping	Host image mapping information.

Storage Menu

Each node in the **Storage** menu corresponds to the LSI MegaRAID controllers that are installed in the Cisco UCS E-Series Rack-Mount Servers. Each node leads to one or more tabs that display in the **Work** pane and provide information about the installed controllers.

Storage Menu Node Name	Work Pane Tabs Provide Information About...
Controller Info	General information about the selected LSI MegaRAID controller.
Physical Drive Info	General drive information, identification information, and drive status!
Virtual Drive Info	General drive information, RAID information, and physical drive information.
Battery Backup Unit	Backup battery information for the selected MegaRAID controller.
Storage Log	Storage messages.

Admin Menu

Each node in the **Admin** menu leads to one or more tabs that display in the **Work** pane. These tabs provides access to the following information:

Admin Menu Node Name	Work Pane Tabs Provide Information About...
User Management	Locally-defined user accounts, Active Directory settings, and current user session information.
Networking	NIC, IPv4, IPv6, VLAN, and LOM properties, along with network security and NTP settings.
Communication Services	HTTP, XML API, SSH, Redfish, IPMI over LAN, and SNMP settings.
Certificate Management	Security certificate information and management.
Event Management	Platform event management.
Firmware Management	Cisco IMC and BIOS firmware information and management.
Utilities	Technical support data collection, system configuration import and export options, and restore factory defaults settings.

Toolbar

The toolbar displays above the **Work** pane.

Button Name	Description
Refresh	Refreshes the current page.
Host Power	Displays the drop-down menu for you to choose power options.

Button Name	Description
Launch KVM	Displays the drop-down menu to launch the Java based or HTML based KVM console.
Ping	Launches the Ping Details pop-up window.
Reboot	Enables you to reboot Cisco IMC.

Cisco Integrated Management Controller Online Help Overview

The GUI for the Cisco Integrated Management Controller (Cisco IMC) software is divided into two main sections, a Navigation pane on the left and a Work pane on the right.

This help system describes the fields on each Cisco IMC GUI page and in each dialog box.

To access the page help, do one of the following:

- In a particular tab in the Cisco IMC GUI, click the **Help** icon in the toolbar above the Work pane.
- In a dialog box, click the **Help** button in that dialog box.

Logging into Cisco IMC

Before you begin

If not installed, install Adobe Flash Player 10 or later on your local machine.

Procedure

Step 1 In your web browser, type or select the web link for .

Step 2 If a security dialog box displays, do the following:

- (Optional) Check the check box to accept all content from Cisco.
- Click **Yes** to accept the certificate and continue.

Step 3 In the log in window, enter your username and password.

Tip When logging in for the first time to an unconfigured system, use **admin** as the username and **password** as the password.

The following situations occur when you login to the Web UI for the first time:

- You cannot perform any operation until you change default admin credentials on the Web UI.
- You cannot close or cancel the password change pop-up window and opening it in a tab or refreshing the browser page will continue to display the pop-up window. This pop-up window appears when you login after a factory reset.
- You cannot choose the word 'password' as your new password. If this creates problems for any scripts you may be running, you could change it to password by logging back into the user management options, but this is ENTIRELY at your own risk. It is not recommended by Cisco.

Step 4 Click **Log In**.

Logging out of Cisco IMC

Procedure

- Step 1** In the upper right of , click **Log Out**.
Logging out returns you to the log in page.
- Step 2** (Optional) Log back in or close your web browser.
-

