



# Viewing Server Properties

This chapter includes the following sections:

- [Viewing Server Properties, on page 1](#)
- [Viewing the Actual Boot Order, on page 2](#)
- [Viewing CIMC Information, on page 3](#)
- [Viewing SD Card Information, on page 3](#)
- [Viewing CPU Properties, on page 4](#)
- [Viewing Memory Properties, on page 5](#)
- [Viewing Power Supply Properties, on page 6](#)
- [Viewing Storage Properties, on page 7](#)
- [Viewing PCI Adapter Properties, on page 10](#)
- [Viewing Power Policy Statistics, on page 11](#)
- [Viewing Hard Drive Presence, on page 12](#)
- [Viewing the MAC Address of an Interface, on page 12](#)
- [Viewing the Status of CIMC Network Connections, on page 13](#)

## Viewing Server Properties

### Before you begin

The server must be powered on, or the properties will not display.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show detail</b>	Displays server properties.

### Example

This example displays server properties:

```

Server# scope chassis
Server /chassis # show detail
Chassis:
  Power: on
  Power Button: unlocked
  IOS Lockout: unlocked
  Serial Number: FOC16161F1P
  Product Name: E160D
  PID : UCS-E160D-M1/K9
  UUID: 1255F7F0-9F17-0000-E312-94E74999D9E7
  Description

```

## Viewing the Actual Boot Order

### SUMMARY STEPS

1. Server# scope bios
2. Server /bios # show actual-boot-order

### DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope bios	Enters the BIOS command mode.
Step 2	Server /bios # show actual-boot-order	Displays details of the BIOS status.

### Example

The following examples display actual boot order:

```

E160S/bios# scope bios
Server /bios # show actual-boot-order
Boot Order  Type                               Boot Device
-----
1           Internal EFI Shell                       Internal EFI Shell
2           CD/DVD                                  Cisco vKVM-Mapped vDVD1.22
3           CD/DVD                                  Cisco CIMC-Mapped vDVD1.22
4           Network Device (PXE)                   TE2 - 10G Port 2
5           Network Device (PXE)                   TE3 - 10G Port 3
6           Network Device (PXE)                   GE0 - 1G Internal Port 0
7           Network Device (PXE)                   GE1 - 1G Internal Port 1
8           FDD                                    Internal Flash
9           FDD                                    Cisco vKVM-Mapped vFDD1.22
10          HDD                                    Cisco vKVM-Mapped vHDD1.22
11          HDD                                    Cisco CIMC-Mapped vHDD1.22
12          HDD                                    RAID Adapter

E1120D/bios# scope bios
Server /bios # show actual-boot-order
Boot Order  Type                               Boot Device
-----
1           CD/DVD                                  Cisco vKVM-Mapped vDVD1.22
2           CD/DVD                                  Cisco CIMC-Mapped vDVD1.22
3           HDD                                    RAID Adapter

```

4	HDD	Cisco
5	HDD	Cisco vKVM-Mapped vHDD1.22
6	HDD	Cisco CIMC-Mapped vHDD1.22
7	FDD	Cisco vKVM-Mapped vFDD1.22
8	Network Device (PXE)	IBA XE Slot 0300 v2358
9	Network Device (PXE)	IBA XE Slot 0301 v2358
10	Network Device (PXE)	BRCM MBA Slot 0500 v15.2.7
11	Network Device (PXE)	BRCM MBA Slot 0501 v15.2.7
12	Internal EFI Shell	Internal EFI Shell

## Viewing CIMC Information

### Before you begin

Install the CIMC firmware on the server.

### SUMMARY STEPS

1. Server# **scope cimc**
2. Server /cimc # **show [detail]**

### DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope cimc</b>	Enters CIMC command mode.
<b>Step 2</b>	Server /cimc # <b>show [detail]</b>	Displays the CIMC firmware, current time, and boot loader version.

### Example

This example shows information about the CIMC:

```
Server# scope cimc
Server /cimc # show detail
CIMC:
  Firmware Version: 1.0(1.20120417172632)
  Current Time: Thu Apr 26 12:11:44 2012
  Boot-loader Version: 1.0(1.20120417172632).16
```

## Viewing SD Card Information

### Before you begin

Install the CIMC firmware on the server.

**Note**

SD card is not supported on the M3 modules (UCS-E160S-M3, UCS-E180D-M3, and UCS-E1120D-M3).

**SUMMARY STEPS**

1. Server# **scope cimc**
2. Server /cimc # **show sd detail**

**DETAILED STEPS**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server# <b>scope cimc</b>	Enters CIMC command mode.
<b>Step 2</b>	Server /cimc # <b>show sd detail</b>	Displays the following information about the SD card: manufacturer and application ID, serial number, hardware and firmware revision, manufacture date, and whether the SD card is detected. If the card detected status is <b>yes</b> , it indicates that the SD card is present and is functional.

**Example**

This example shows information about the CIMC:

```
Server# scope cimc
Server /cimc # show sd detail
Manufacturer ID: Unigen 0x000045
  OEM/Application ID: 0x0024
  Serial Number: 0x39500025
  Hardware Revision: 0x2
  Firmware Revision: 0x0
  Manufacture Date: 06/2013
  Card Detected: yes
```

## Viewing CPU Properties

**Before you begin**

The server must be powered on, or the properties will not display.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show cpu [detail]</b>	Displays CPU properties.

**Example**

This example displays CPU properties:

```
Server# scope chassis
Server /chassis # show cpu
Name          Cores    Version
-----
CPU1          4        Intel(R) Xeon(R) CPU    E5-2418L 0 @ 2.00GHz

Server /chassis #
```

## Viewing Memory Properties

**Before you begin**

The server must be powered on, or the properties will not display.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show dimm [detail]</b>	Displays memory properties.

**Example**

This example displays memory properties:

```
Server# scope chassis
Server /chassis # show dimm
Name          Capacity    Channel Speed (MHz) Channel Type
-----
Node0_Dimm0   8192 MB     1333          DDR3
Node0_Dimm1   8192 MB     1333          DDR3
Node0_Dimm2   8192 MB     1333          DDR3
```

This example displays detailed information about memory properties:

```
Server# scope chassis
Server /chassis # show dimm detail
Name Node0_Dimm0:
Capacity: 8192 MB
Channel Speed (MHz): 1333
Channel Type: DDR3
Memory Type Detail: Registered (Buffered)
Bank Locator: Node0_Bank0
Visibility: Yes
Operability: Operable
Manufacturer: Samsung
Part Number: M393E1K70DH0-
Serial Number: 86A7D514
Asset Tag: Dimm0_AssetTag
```

```
Data Width: 64 bits
Name Node0_Dimm1:
Capacity: 8192 MB
```

# Viewing Power Supply Properties

## Before you begin

The server must be powered on, or the properties will not display.



**Note** Power-cap is not supported on ISR44XX. It is supported only on ISR-G2.

## SUMMARY STEPS

1. Server# **scope power-cap**
2. Server /power-cap # **show [detail]**

## DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope power-cap</b>	Enters the power cap command mode.
<b>Step 2</b>	Server /power-cap # <b>show [detail]</b>	Displays the server power consumption information.

## Example

This example displays the detailed power supply properties for a single-wide E-Series Server:

```
Server# scope power-cap
Server /power-cap # show detail
  Cur Consumption (W): 36.10 W
  Max Consumption (W): 075
  Min Consumption (W): 36.10 W
Server /power-cap #
```

This example displays the detailed power supply properties for a double-wide E-Series Server:

```
Server# scope power-cap
Server /power-cap # show detail
  Cur Consumption (W): 43.1 W
  Max Consumption (W): 160
  Min Consumption (W): 43.1 W
Server /power-cap #
```

# Viewing Storage Properties

## Viewing Storage Adapter Properties

### Before you begin

The server must be powered on, or the properties will not display.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show storageadapter [slot] [detail]</b>	Displays installed storage cards.  <b>Note</b> This command displays all MegaRAID controllers on the server that can be managed through the CIMC. If an installed controller or storage device is not displayed, then it cannot be managed through the CIMC.
<b>Step 3</b>	Server /chassis # <b>scope storageadapter SLOT-5</b>	Enters command mode for an installed storage card.
<b>Step 4</b>	Server /chassis/storageadapter # <b>show capabilities [detail]</b>	Displays RAID levels supported by the storage card.
<b>Step 5</b>	Server /chassis/storageadapter # <b>show error-counters [detail]</b>	Displays number of errors seen by the storage card.
<b>Step 6</b>	Server /chassis/storageadapter # <b>show firmware-versions [detail]</b>	Displays firmware version information for the storage card.
<b>Step 7</b>	Server /chassis/storageadapter # <b>show hw-config [detail]</b>	Displays hardware information for the storage card.
<b>Step 8</b>	Server /chassis/storageadapter # <b>show pci-info [detail]</b>	Displays adapter PCI information for the storage card.
<b>Step 9</b>	Server /chassis/storageadapter # <b>show running-firmware-images [detail]</b>	Displays running firmware information for the storage card.
<b>Step 10</b>	Server /chassis/storageadapter # <b>show settings [detail]</b>	Displays adapter firmware settings for the storage card.

### Example

This example displays storage properties:

```
Server# scope chassis
Server /chassis # show storageadapter
```

```
Controller Product Name          Firmware Package Build Product ID    Cache Memory
Size
-----
```

SLOT-5

LSI MegaRAID SAS 2004 ROMB 20.10.1-0092

LSI Logic

0 MB

## Viewing Physical Drive Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope storageadapter SLOT-5</b>	Enters command mode for an installed storage card.
<b>Step 3</b>	Server /chassis/storageadapter # <b>show physical-drive [slot-number] [detail]</b>	Displays physical drive information for the storage card.
<b>Step 4</b>	Server /chassis/storageadapter # <b>show physical-drive-count [detail]</b>	Displays the number of physical drives on the storage card.
<b>Step 5</b>	Server /chassis/storageadapter # <b>scope physical-drive slot-number</b>	Enters command mode for the specified physical drive.
<b>Step 6</b>	Server /chassis/storageadapter/physical-drive # <b>show general [detail]</b>	Displays general information about the specified physical drive.
<b>Step 7</b>	Server /chassis/storageadapter/physical-drive # <b>show status [detail]</b>	Displays status information about the specified physical drive.

### Example

This example displays general information about the physical drive number 1 on the storage card named SLOT-5:

```
Server# scope chassis
Server /chassis # scope storageadapter SLOT-5
Server /chassis/storageadapter # scope physical-drive 1
Server /chassis/storageadapter/physical-drive # show general
Slot Number 1:
  Controller: SLOT-5
  Enclosure Device ID: 64
  Device ID: 3
  Sequence Number: 2
  Media Error Count: 0
  Other Error Count: 12
  Predictive Failure Count: 0
  Link Speed: 6.0 Gb/s
  Interface Type: SATA
  Media Type: HDD
  Block Size: 512
  Block Count: 1953525168
  Raw Size: 953869 MB
  Non Coerced Size: 953357 MB
  Coerced Size: 952720 MB
  SAS Address 0: 4433221100000000
```



```
SAS Address 1:
Connected Port 0:
Connected Port 1:
Connected Port 2:
Connected Port 3:
Connected Port 4:
```

This example provides status information about the physical drive number 1 on the storage card named SLOT-5:

```
Server# scope chassis
Server /chassis # scope storageadapter SLOT-5
Server /chassis/storageadapter # scope physical-drive 1
Server /chassis/storageadapter/physical-drive # show status
Slot Number 1:
  Controller: SLOT-5
  State: system
  Online: true
  Fault: false
```

## Viewing Virtual Drive Properties

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>scope storageadapter SLOT-5</b>	Enters command mode for an installed storage card.
<b>Step 3</b>	Server /chassis/storageadapter # <b>show virtual-drive</b> [drive-number] [detail]	Displays virtual drive information for the storage card.
<b>Step 4</b>	Server /chassis/storageadapter # <b>show virtual-drive-count</b> [detail]	Displays the number of virtual drives configured on the storage card.
<b>Step 5</b>	Server /chassis/storageadapter # <b>scope virtual-drive</b> drive-number	Enters command mode for the specified virtual drive.
<b>Step 6</b>	Server /chassis/storageadapter/virtual-drive # <b>show</b> <b>physical-drive</b> [detail]	Displays physical drive information about the specified virtual drive.

### Example

This example displays power supply properties:

```
Server# scope chassis
Server /chassis # scope storageadapter SLOT-5
Server /chassis/storageadapter # show virtual-drive
Virtual Drive  Status      Name                               Size      RAID Level
-----
0                Optimal                          571250 MB RAID 1

Server /chassis/storageadapter # show virtual-drive-count
PCI Slot SLOT-5:
```

```

Virtual Drive Count: 1
Degraded Virtual Drive Count: 0
Offline Virtual Drive Count: 0
Server /chassis/storageadapter # scope virtual-drive 0
Server /chassis/storageadapter/virtual-drive # show physical-drive
Span  Physical Drive Status      Starting Block Number Of Blocks
-----
0      2              online      0              1169920000
0      1              online      0              1169920000

```

## Viewing PCI Adapter Properties

### Before you begin

The server must be powered on, or the properties will not display.

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **show pci-adapter [detail]**

### DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show pci-adapter [detail]</b>	Displays PCI adapter properties.

### Example

This example displays PCI adapter properties:

```

Server# scope chassis
Server /chassis # show pci-adapter
Name                Slot  Vendor ID  Device ID  Product Name
-----
PCIe Adapter1      1    0x1137    0x0042    Cisco UCS P81E Virtual...
PCIe Adapter2      5    0x1077    0x2432    Qlogic QLE2462 4Gb dua...

Server /chassis #

```

# Viewing Power Policy Statistics

## Before you begin



**Note** This is applicable only on ISR-G2 platforms.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>show power-cap [detail]</b>	Displays the server power consumption statistics and the power cap policy.

The displayed fields are described in the following table:

Name	Description
<b>Current Consumption</b>	The power currently being used by the server, in watts.
<b>Maximum Consumption</b>	The maximum number of watts consumed by the server since the last time it was rebooted.
<b>Minimum Consumption</b>	The minimum number of watts consumed by the server since the last time it was rebooted.

## Example

This example displays the detailed power statistics for a single-wide E-Series Server:

```
Server# scope power-cap
Server /power-cap # show detail
  Cur Consumption (W): 36.10 W
  Max Consumption (W): 075
  Min Consumption (W): 36.10 W
Server /power-cap #
```

This example displays the detailed power statistics for a double-wide E-Series Server:

```
Server# scope power-cap
Server /power-cap # show detail
  Cur Consumption (W): 43.1 W
  Max Consumption (W): 160
  Min Consumption (W): 43.1 W
Server /power-cap #
```

# Viewing Hard Drive Presence

## Before you begin

The server must be powered on, or the properties will not display.

## SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **show hdd**

## DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope chassis</b>	Enters the chassis command mode.
<b>Step 2</b>	Server /chassis # <b>show hdd</b>	Displays the hard drives.

## Example

This example displays power supply properties:

```
Server# scope chassis
Server /chassis # show hdd
      Name                Status
-----
HDD1_PRS                 inserted
HDD2_PRS                 inserted
HDD3_PRS                 inserted
```

# Viewing the MAC Address of an Interface

You can view the system defined interface names and the MAC address that is assigned to each host interface.

## SUMMARY STEPS

1. Server# **scope cimc**
2. Server /cimc # **scope network**
3. Server /cimc/network # **show lom-mac-list [detail]**

## DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	Server# <b>scope cimc</b>	Enters CIMC command mode.

	Command or Action	Purpose
Step 2	Server /cimc # <b>scope network</b>	Enters network command mode.
Step 3	Server /cimc/network # <b>show lom-mac-list [detail]</b>	Displays the system defined interface names and the MAC address that is assigned to each host interface.

### Example

This example shows how to display the system defined interface names and the MAC address that is assigned to each host interface:

```
Server# scope cimc
Server /cimc # scope network
Server /cimc/network # show lom-mac-list
Interface                               MAC Address
-----
Console                                00:24:c4:f4:89:ee
GE1                                     00:24:c4:f4:89:ef
GE2                                     00:24:c4:f4:89:f0
GE3                                     00:24:c4:f4:89:f1
```

For M3 servers, the interface GE is replaced by TE. This example shows the output for M3 servers:

```
Server# scope cimc
Server /cimc # scope network
Server /cimc/network # show lom-mac-list
Interface                               MAC Address
-----
Console                                28:6f:7f:ee:ac:0a
GE1                                     28:6f:7f:ee:ac:0b
TE2                                     28:6f:7f:ee:ac:0c
TE3                                     28:6f:7f:ee:ac:0d
```

## Viewing the Status of CIMC Network Connections

### Before you begin

You must log in as a user with admin privileges to view the status of the CIMC network connections; whether the link is detected (physical cable is connected to the network interface) or not detected.

### SUMMARY STEPS

1. Server# **scope cimc**
2. Server /cimc # **scope network**
3. Server /cimc/network # **show link state [detail]**

### DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# <b>scope cimc</b>	Enters CIMC command mode.

	Command or Action	Purpose
<b>Step 2</b>	Server /cimc # <b>scope network</b>	Enters CIMC network command mode.
<b>Step 3</b>	Server /cimc/network # <b>show link state [detail]</b>	Displays the status of the CIMC network connections; whether the link is detected (physical cable is connected to the network interface) or not detected.

### Example

This example displays the status of the CIMC network connections:

```
Server# scope cimc
Server /cimc # scope network
Server /cimc/network # show link state
Interface                               State
-----
Console                                 Link Detected
GE1                                     No Link Detected
GE2                                     No Link Detected
GE3                                     No Link Detected
Dedicated                               Link Detected

Server /cimc/network # show link-state detail
Link State:
  Interface: Console
  State: Link Detected
Link State:
  Interface: GE1
  State: No Link Detected
Link State:
  Interface: GE2
  State: No Link Detected
Link State:
  Interface: GE3
  State: No Link Detected
Link State:
  Interface: Dedicated
  State: Link Detected
```

For M3 servers, the interface GE is replaced by TE. This example shows the output for M3 servers:

```
Server# scope cimc
Server /cimc # scope network
Server /cimc/network # show link state
Interface                               State
-----
Console                                 Link Detected
GE1                                     Link Detected
TE2                                     No Link Detected
TE3                                     No Link Detected
Dedicated                               No Link Detected
```