



Configuring Quality of Service

This chapter includes the following sections:

- [Quality of Service, page 1](#)
- [System Classes, page 1](#)
- [Quality of Service Policies, page 2](#)
- [Flow Control Policies, page 2](#)
- [Configuring a System Class, page 3](#)
- [Disabling a System Class, page 4](#)
- [Configuring a QoS Policy, page 4](#)
- [Deleting a QoS Policy, page 5](#)
- [Configuring a Flow Control Policy, page 5](#)
- [Deleting a Flow Control Policy, page 7](#)

Quality of Service

Cisco UCS provides the following methods to implement quality of service:

- System classes that specify the global configuration for certain types of traffic across the entire system
- QoS policies that assign system classes for individual vNICs
- Flow control policies that determine how uplink Ethernet ports handle pause frames

System Classes

Cisco UCS uses Data Center Ethernet (DCE) to handle all traffic inside a Cisco UCS instance. This industry standard enhancement to Ethernet divides the bandwidth of the Ethernet pipe into eight virtual lanes. System classes determine how the DCE bandwidth in these virtual lanes is allocated across the entire Cisco UCS instance.

Each system class reserves a specific segment of the bandwidth for a specific type of traffic. This provides a level of traffic management, even in an oversubscribed system. For example, you can configure the Fibre Channel Priority system class to determine the percentage of DCE bandwidth allocated to FCoE traffic.

The following table describes the system classes:

System Class	Description
Platinum Priority Gold Priority Silver Priority Bronze Priority	A configurable set of system classes that you can include in the QoS policy for a service profile. Each system class manages one lane of traffic. All properties of these system classes are available for you to assign custom settings and policies.
Best Effort Priority	A system class that sets the quality of service for the lane reserved for Basic Ethernet traffic. Some properties of this system class are preset and cannot be modified. For example, this class has a drop policy that allows it to drop data packets if required.
Fibre Channel Priority	A system class that sets the quality of service for the lane reserved for Fibre Channel over Ethernet traffic. Some properties of this system class are preset and cannot be modified. For example, this class has a no-drop policy that ensures it never drops data packets.

Quality of Service Policies

QoS policies assign a system class to the outgoing traffic for a vNIC or vHBA. This system class determines the quality of service for that traffic.

You must include a QoS policy in a vNIC policy or vHBA policy and then include that policy in a service profile to configure the vNIC or vHBA.

Flow Control Policies

Flow control policies determine whether the uplink Ethernet ports in a Cisco UCS instance send and receive IEEE 802.3x pause frames when the receive buffer for a port fills. These pause frames request that the transmitting port stop sending data for a few milliseconds until the buffer clears.

For flow control to work between a LAN port and an uplink Ethernet port, you must enable the corresponding receive and send flow control parameters for both ports. For Cisco UCS, the flow control policies configure these parameters.

When you enable the send function, the uplink Ethernet port sends a pause request to the network port if the incoming packet rate becomes too high. The pause remains in effect for a few milliseconds before traffic is reset to normal levels. If you enable the receive function, the uplink Ethernet port honors all pause requests from the network port. All traffic is halted on that uplink port until the network port cancels the pause request.

Because you assign the flow control policy to the port, changes to the policy have an immediate effect on how the port reacts to a pause frame or a full receive buffer.

Configuring a System Class

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope eth-server	Enters Ethernet server mode.
Step 2	UCS-A /eth-server # scope qos	Enters Ethernet server QoS mode.
Step 3	UCS-A /eth-server/qos # scope eth-classified {bronze gold platinum silver}	Enters Ethernet server QoS Ethernet classified mode for the specified system class.
Step 4	UCS-A /eth-server/qos/eth-classified # enable	Enables the specified system class.
Step 5	UCS-A /eth-server/qos/eth-classified # set cos cos-value	Specifies the class of service for the specified system class. Valid class of service values are 0 to 6; higher values indicate more important traffic.
Step 6	UCS-A /eth-server/qos/eth-classified # set drop {drop no-drop}	Specifies whether the channel can drop packets or not. Note Only one system class can use the no-drop option.
Step 7	UCS-A /eth-server/qos/eth-classified # set mtu {mtu-value fc normal}	Specifies the maximum transmission unit (MTU) for the specified system class. Valid MTU values are 1538 to 9216.
Step 8	UCS-A /eth-server/qos/eth-classified # set multicast-optimize {no yes}	Specifies whether the class is optimized to for sending multicast packets.
Step 9	UCS-A /eth-server/qos/eth-classified # set weight {weight-value best-effort none}	Specifies the relative weight for the specified system class. Valid weight values are 0 to 10.
Step 10	UCS-A /eth-server/qos/eth-classified # commit-buffer	Commits the transaction to the system configuration.

The following example enables the platinum system class, allows the channel to drop packets, sets the class of service to 6, sets the MTU to normal, optimizes the class for sending multicast packets, sets the relative weight to 5, and commits the transaction:

```
UCS-A# scope eth-server
UCS-A /eth-server # scope qos
UCS-A /eth-server/qos # scope eth-classified platinum
UCS-A /eth-server/qos/eth-classified # enable
UCS-A /eth-server/qos/eth-classified* # set drop drop
UCS-A /eth-server/qos/eth-classified* # set cos 6
UCS-A /eth-server/qos/eth-classified* # set mtu normal
UCS-A /eth-server/qos/eth-classified* # set multicast-optimize yes
UCS-A /eth-server/qos/eth-classified* # set weight 5
UCS-A /eth-server/qos/eth-classified* # commit-buffer
UCS-A /eth-server/qos/eth-classified #
```

Disabling a System Class

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope eth-server	Enters Ethernet server mode.
Step 2	UCS-A /eth-server # scope qos	Enters Ethernet server QoS mode.
Step 3	UCS-A /eth-server/qos # scope eth-classified {bronze gold platinum silver}	Enters Ethernet server QoS Ethernet classified mode for the specified system class.
Step 4	UCS-A /eth-server/qos/eth-classified # disable	Disables the specified system class.
Step 5	UCS-A /eth-server/qos/eth-classified # commit-buffer	Commits the transaction to the system configuration.

The following example disables the platinum system class and commits the transaction:

```
UCS-A# scope eth-server
UCS-A /eth-server # scope qos
UCS-A /eth-server/qos # scope eth-classified platinum
UCS-A /eth-server/qos/eth-classified # disable
UCS-A /eth-server/qos/eth-classified* # commit-buffer
UCS-A /eth-server/qos/eth-classified #
```

Configuring a QoS Policy

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope org org-name	Enters organization mode for the specified organization. To enter the root organization mode, type / as the <i>org-name</i> .
Step 2	UCS-A /org # create qos-policy policy-name	Creates a QoS policy with the specified policy name, and enters organization QoS policy mode.
Step 3	UCS-A /org/qos-policy # create vnic-egress-policy	Creates a vNIC egress policy to be used for the QoS policy and enters organization QoS policy vNIC egress policy mode.
Step 4	UCS-A /org/qos-policy/vnic-egress-policy # set prio {best-effort bronze gold platinum silver}	Specifies the name of the system class to be used for the vNIC egress policy.
Step 5	UCS-A /org/qos-policy/vnic-egress-policy # commit-buffer	Commits the transaction to the system configuration.

The following example assigns the best effort system class to the vNIC egress policy of the QoS policy and commits the transaction:

```
UCS-A# scope org /
UCS-A /org # create qos-policy QosPolicy34
UCS-A /org/qos-policy* # create vnic-egress-policy
UCS-A /org/qos-policy/vnic-egress-policy* # set prio best-effort
UCS-A /org/qos-policy/vnic-egress-policy* # commit-buffer
UCS-A /org/qos-policy/vnic-egress-policy #
```

What to Do Next

Include the QoS policy in a vNIC template.

Deleting a QoS Policy

If you delete a QoS policy that is in use or disable a system class that is used in a QoS policy, any vNIC which uses that QoS policy is assigned to the Best Effort Priority system class. In a system that implements multi-tenancy, Cisco UCS Manager first attempts to find a matching QoS policy in the organization hierarchy.

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope org <i>org-name</i>	Enters organization mode for the specified organization. To enter the root organization mode, type / as the <i>org-name</i> .
Step 2	UCS-A /org # delete qos-policy <i>policy-name</i>	Deletes the specified QoS policy.
Step 3	UCS-A /org # commit-buffer	Commits the transaction to the system configuration.

The following deletes the QoS policy named QosPolicy34 and commits the transaction:

```
UCS-A# scope org /
UCS-A /org # delete qos-policy QosPolicy34
UCS-A /org* # commit-buffer
UCS-A /org #
```

Configuring a Flow Control Policy

Before You Begin

Configure the network port with the corresponding setting for the flow control that you need. For example, if you enable the send setting for flow-control pause frames in the policy, make sure that the receive parameter in the network port is set to on or desired. If you want the Cisco UCS port to receive flow-control frames, make sure that the network port has a send parameter set to on or desired. If you do not want to use flow control, you can set the send and receive parameters on the network port to off.

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope eth-uplink	Enters Ethernet uplink mode.
Step 2	UCS-A /eth-uplink # scope flow-control	Enters Ethernet uplink flow control mode.
Step 3	UCS-A /eth-uplink/flow-control # create policy policy-name	Creates the specified flow control policy.
Step 4	UCS-A /eth-uplink/flow-control/policy # set prio prio-option	Specifies one of the following flow control priority options: <ul style="list-style-type: none"> • auto—The Cisco UCS system and the network negotiate whether PPP will be used on this fabric interconnect. • on—PPP is enabled on this fabric interconnect.
Step 5	UCS-A /eth-uplink/flow-control/policy # set receive receive-option	Specifies one of the following flow control receive options: <ul style="list-style-type: none"> • off—Pause requests from the network are ignored and traffic flow continues as normal. • on—Pause requests are honored and all traffic is halted on that uplink port until the network cancels the pause request.
Step 6	UCS-A /eth-uplink/flow-control/policy # set send send-option	Specifies one of the following flow control send options: <ul style="list-style-type: none"> • off—Traffic on the port flows normally regardless of the packet load. • on—The Cisco UCS system sends a pause request to the network if the incoming packet rate becomes too high. The pause remains in effect for a few milliseconds before traffic is reset to normal levels.
Step 7	UCS-A /org/qos-policy/vnic-egress-policy # commit-buffer	Commits the transaction to the system configuration.

The following configures a flow control policy and commits the transaction:

```
UCS-A# scope eth-uplink
UCS-A /eth-uplink* # scope flow-control
UCS-A /eth-uplink/flow-control* # create policy FlowControlPolicy23
UCS-A /eth-uplink/flow-control/policy* # set prio auto
UCS-A /eth-uplink/flow-control/policy* # set receive on
UCS-A /eth-uplink/flow-control/policy* # set send on
UCS-A /eth-uplink/flow-control/policy* # commit-buffer
UCS-A /eth-uplink/flow-control/policy #
```

What to Do Next

Associate the flow control policy with an uplink Ethernet port or port channel.

Deleting a Flow Control Policy

Procedure

	Command or Action	Purpose
Step 1	UCS-A# scope eth-uplink	Enters Ethernet uplink mode.
Step 2	UCS-A /eth-uplink # scope flow-control	Enters Ethernet uplink flow control mode.
Step 3	UCS-A /eth-uplink/flow-control # delete policy <i>policy-name</i>	Deletes the specified flow control policy.
Step 4	UCS-A /eth-uplink/flow-control # commit-buffer	Commits the transaction to the system configuration.

The following example deletes the flow control policy named FlowControlPolicy23 and commits the transaction:

```
UCS-A# scope eth-uplink
UCS-A /eth-uplink* # scope flow-control
UCS-A /eth-uplink/flow-control* # delete policy FlowControlPolicy23
UCS-A /eth-uplink/flow-control* # commit-buffer
UCS-A /eth-uplink/flow-control #
```

