



# Configuring Policies

---

- [Configuring Dynamic vNIC Connection Policies, on page 1](#)
- [Creating a Custom Ethernet Adapter Policy for SR-IOV, on page 5](#)

## Configuring Dynamic vNIC Connection Policies

### Dynamic vNIC Connection Policy

The dynamic vNIC connection policy determines how the connectivity between VMs and dynamic vNICs is configured. This policy is required for Cisco UCS domains that include servers with VIC adapters on which you have installed VMs and configured dynamic vNICs.

#### Ethernet Adapter Policy

Each dynamic vNIC connection policy includes an Ethernet adapter policy and designates the number of vNICs that can be configured for any server associated with a service profile that includes the policy.

#### Server Migration



---

**Note** If you migrate a server that is configured with dynamic vNICs, the dynamic interface used by the vNICs fails and notifies you of that failure.

When the server comes back up, assigns new dynamic vNICs to the server. If you are monitoring traffic on the dynamic vNIC, you must reconfigure the monitoring source.

---

## Creating a Dynamic vNIC Connection Policy

### SUMMARY STEPS

1. In the **Navigation** pane, click **LAN**.
2. Expand **LAN > Policies**.
3. Expand the node for the organization where you want to create the policy.

4. Right-click the **Dynamic vNIC Connection Policies** node and choose **Create Dynamic vNIC Connection Policy**.
5. In the **Create Dynamic vNIC Connection Policy** dialog box, complete the following fields:
6. Click **OK**.
7. If a confirmation dialog box appears, click **Yes**.

## DETAILED STEPS

- Step 1** In the **Navigation** pane, click **LAN**.
- Step 2** Expand **LAN > Policies**.
- Step 3** Expand the node for the organization where you want to create the policy.  
If the system does not include multitenancy, expand the **root** node.
- Step 4** Right-click the **Dynamic vNIC Connection Policies** node and choose **Create Dynamic vNIC Connection Policy**.
- Step 5** In the **Create Dynamic vNIC Connection Policy** dialog box, complete the following fields:

Name	Description
<b>Name field</b>	<p>The name of the policy.</p> <p>This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters other than - (hyphen), _ (underscore), : (colon), and . (period), and you cannot change this name after the object is saved.</p> <p><b>Note</b> Do not specify "default" as the value for the dynamic vNIC connection policy name. Cisco UCS Manager automatically resolves any empty policy references to "default". Any service profiles or service profile templates with only static vNICs defined will automatically reference the policy "default" when it is present. If you specify "default" for the dynamic vNIC connection policy name, then unexpected dynamic vNICs might be created on those service profiles or service profile templates.</p>
<b>Description field</b>	<p>A description of the policy. Cisco recommends including information about where and when to use the policy.</p> <p>Enter up to 256 characters. You can use any characters or spaces except ` (accent mark), \ (backslash), ^ (carat), " (double quote), = (equal sign), &gt; (greater than), &lt; (less than), or ' (single quote).</p>
<b>Number of Dynamic vNICs field</b>	<p>The number of dynamic vNICs that this policy affects.</p> <p>Enter an integer between 0 and 256. The default is 54.</p> <p><b>Note</b> Components of your system might limit this number to fewer than 256 vNICs.</p>
<b>Adapter Policy drop-down list</b>	The adapter policy for Dynamic vNIC Connection Policy.

Name	Description
Protection field	<p>Dynamic vNICs are always protected in Cisco UCS, but this field allows you to select a preferred fabric, if any. You can choose one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Protected Pref A</b>—Cisco UCS attempts to use fabric A but fails over to fabric B if necessary</li> <li>• <b>Protected Pref B</b>—Cisco UCS attempts to use fabric B but fails over to fabric A if necessary</li> <li>• <b>Protected</b>—Cisco UCS uses whichever fabric is available</li> </ul>

**Step 6** Click **OK**.

**Step 7** If a confirmation dialog box appears, click **Yes**.

## Changing a Dynamic vNIC Connection Policy

### SUMMARY STEPS

1. In the **Navigation** pane, click **LAN**.
2. Expand **LAN > Policies**.
3. Expand the node for the organization that contains the policy that you want to change.
4. Expand the **Dynamic vNIC Connection Policies** node and click the policy that you want to change.
5. In the **Work** pane, click the **General** tab.
6. Change one or more of the following fields:
7. Click **Save Changes**.
8. If a confirmation dialog box displays, click **Yes**.

### DETAILED STEPS

**Step 1** In the **Navigation** pane, click **LAN**.

**Step 2** Expand **LAN > Policies**.

**Step 3** Expand the node for the organization that contains the policy that you want to change.

If the system does not include multitenancy, expand the **root** node.

**Step 4** Expand the **Dynamic vNIC Connection Policies** node and click the policy that you want to change.

**Step 5** In the **Work** pane, click the **General** tab.

**Step 6** Change one or more of the following fields:

Name	Description
Description field	A description of the policy. Cisco recommends including information about where and when to use the policy.  Enter up to 256 characters. You can use any characters or spaces except ` (accent mark), \ (backslash), ^ (carat), " (double quote), = (equal sign), > (greater than), < (less than), or ' (single quote).
Number of Dynamic vNICs field	The number of dynamic vNICs that this policy affects.  Enter an integer between 0 and 256. The default is 54.  <b>Note</b> Components of your system might limit this number to fewer than 256 vNICs.
Adapter Policy drop-down list	The adapter policy for Dynamic vNIC Connection Policy.

You cannot change the other properties of the policy, such as the **Name** field.

**Step 7** Click **Save Changes**.

**Step 8** If a confirmation dialog box displays, click **Yes**.

## Deleting a Dynamic vNIC Connection Policy

You can delete a dynamic vNIC connection policy.

### SUMMARY STEPS

1. In the **Navigation** pane, click **LAN**.
2. Expand **LAN > Policies > *Organization\_Name***.
3. Expand the **Dynamic vNIC Connection Policies** node.
4. Right-click the policy that you want to delete and choose **Delete**.
5. If a confirmation dialog box displays, click **Yes**.

### DETAILED STEPS

- Step 1** In the **Navigation** pane, click **LAN**.
- Step 2** Expand **LAN > Policies > *Organization\_Name***.
- Step 3** Expand the **Dynamic vNIC Connection Policies** node.
- Step 4** Right-click the policy that you want to delete and choose **Delete**.
- Step 5** If a confirmation dialog box displays, click **Yes**.

## Viewing Dynamic vNIC Properties in a VM

You can view dynamic vNIC properties in a VM.

### Before you begin

The VM must be operational.

### SUMMARY STEPS

1. In the **Navigation** pane, click **VM**.
2. On the VM tab, expand **All**.
3. Expand **Virtual Machines**.
4. Expand the virtual machine that contains the dynamic vNIC.
5. Choose the dynamic vNIC.
6. In the **Work** pane, click the **General** tab.

### DETAILED STEPS

- 
- Step 1** In the **Navigation** pane, click **VM**.
- Step 2** On the VM tab, expand **All**.
- Step 3** Expand **Virtual Machines**.
- Step 4** Expand the virtual machine that contains the dynamic vNIC.
- Step 5** Choose the dynamic vNIC.
- Step 6** In the **Work** pane, click the **General** tab.
- In the **Properties** area, the vNIC properties appear.
- 

## Creating a Custom Ethernet Adapter Policy for SR-IOV

The predefined **SRIOV** Ethernet adapter policy supports up to 32 CPU threads. If the server has more than 32 CPU threads, you must follow this procedure to create and specify a custom adapter policy that supports a number of interrupts equal to the number of CPU threads.

For more information about creating an adapter policy, see "Configuring Ethernet Adapter Policies" in the .



---

**Tip** If the fields in an area do not display, click the **Expand** icon to the right of the heading.

---

### Before you begin

Determine the number of CPU threads used by your server. You can find this information by navigating to **Equipment > Chassis > Servers** and viewing the **Threads** heading for your server in the **Servers** table.

## SUMMARY STEPS

1. If you opened the **Create Ethernet Adapter Policy** directly from another menu, skip to Step 6.
2. In the **Navigation** pane, click **Servers**.
3. Expand **Servers > Policies**.
4. Expand the node for the organization where you want to create the policy.
5. Right-click **Adapter Policies** and choose **Create Ethernet Adapter Policy**.
6. Enter a name and description for the policy in the following fields:
7. In the **Resources** area, configure the following values as shown:
8. In the **Options** area, configure the following values as shown:
9. Click **OK**.
10. If a confirmation dialog box displays, click **Yes**.

## DETAILED STEPS

**Step 1** If you opened the **Create Ethernet Adapter Policy** directly from another menu, skip to Step 6.

**Step 2** In the **Navigation** pane, click **Servers**.

**Step 3** Expand **Servers > Policies**.

**Step 4** Expand the node for the organization where you want to create the policy.

If the system does not include multitenancy, expand the **root** node.

**Step 5** Right-click **Adapter Policies** and choose **Create Ethernet Adapter Policy**.

**Step 6** Enter a name and description for the policy in the following fields:

Name	Description
<b>Name</b> field	The name of the policy.  This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters other than - (hyphen) and _ (underscore), and you cannot change this name after the object has been saved.
<b>Description</b> field	A description of the policy. Cisco recommends including information about where and when to use the policy.  Enter up to 256 characters. You can use any characters or spaces except ` (accent mark), \ (backslash), ^ (carat), " (double quote), = (equal sign), > (greater than), < (less than), or ' (single quote).

**Step 7** In the **Resources** area, configure the following values as shown:

Name	Setting
Transmit Queues	1
Ring Size	256
Receive Queues	4
Ring Size	512
Completion Queues	5

Name	Setting
Interrupts	Enter the number of CPU threads used by the server.

**Step 8**

In the **Options** area, configure the following values as shown:

Name	Setting
Transmit Checksum Offload	Enabled
Receive Checksum Offload	Enabled
TCP Segmentation Offload	Enabled
TCP Large Receive Offload	Enabled
Receive Side Scaling (RSS)	Disabled
Accelerated Receive Flow Steering	Disabled
Network Virtualization using Generic Routing Encapsulation	Disabled
Virtual Extensible LAN	Disabled
Fallback Timeout	5 seconds
Interrupt Mode	MSI X
Interrupt Coalescing Type	Min
Advance Filter	Disabled
Advance Filter	Disabled
Advance Filter	Disabled
Interrupt Scaling	Disabled

**Step 9**

Click **OK**.

**Step 10**

If a confirmation dialog box displays, click **Yes**.

