



## Start Here

---

**Revised: May 4, 2015**

Topics in this section explain how to maintain and administer your DMP.

- [Concepts, page 7-1](#)
- [Procedures, page 7-2](#)
- [Reference, page 7-8](#)

## Concepts

- [DMPDM Workflow, page 7-1](#)
- [DMPDM 5.4 Differences by DMP Model, page 7-2](#)

## DMPDM Workflow

The typical workflow in DMPDM assumes that you will test settings before you commit to them.

Settings in DMPDM might revert to their most recent state after your DMP restarts. This occurs by design, so that you can test new settings. If your changes cause unforeseen problems, you can abandon them without consequence. And, when your changes are satisfactory, you can commit to them.

- Click **Apply** to test new values for a condition or setting. After this click, the change takes effect. However, this change is temporary and reversible. The values that you overwrote will return the next time that your DMP restarts, unless you commit to them explicitly.
- Choose **Administration > Save and Restart DMP** to store changed settings permanently. When the Save and Restart DMP page appears, you must click **Save** to actually save your work. After this click, the changes persist even after your DMP restarts.

### Related Topics

- [“Save Configured Settings” section on page 7-3](#)

## DMPDM 5.4 Differences by DMP Model

Your DMP model dictates which elements and supported features you see in DMPDM 5.4.

**DMP 4305G**

DMP Mode
<input type="button" value="Show IP"/> <input type="button" value="Video"/> <input type="button" value="Browser"/>
Settings
Startup
Browser
Display Attributes
Display Dimensions
Fallover
Internal Storage
Network
NTP
Syslog
Video
Display Actions
Media Playback
Transparency
URL To Be Displayed
Administration
DMP Management
DMP Service Account
Manage WAAS Share
Restore Default Settings
Save and Restart DMP
Upgrade Firmware
About DMP
Unique Device Identifier (UDI)
Hardware and Firmware Versions

**DMP 4400G**

DMP Mode
<input type="button" value="Show IP"/> <input type="button" value="Video"/> <input type="button" value="Browser"/>
Settings
Startup
Browser
Display Attributes
Display Dimensions
Fallover
Internal Storage
Network
NTP
Syslog
Video
Medianet
Wireless Configuration
Touch Screens
Display Actions
Media Playback
Transparency
URL To Be Displayed
Administration
DMP Management
DMP Service Account
Manage WAAS Share
Restore Default Settings
Save and Restart DMP
Upgrade Firmware
About DMP
Hardware and Firmware Versions

**DMP 4310G**

DMP Mode
<input type="button" value="Show IP"/>
Settings
Startup
Display Attributes
Fallover
Flash
Internal Storage
Medianet
Network
NTP
Remote Mappings
Syslog
Touch Screens
Video
Display Actions
Flash Playback
Media Playback
Serial Interface
Administration
DMP Management
DMP Service Account
Manage WAAS Share
Restore Default Settings
Save and Restart DMP
Upgrade Firmware
About DMP
Hardware and Firmware Versions

## Procedures

- [Log in to DMPDM, page 7-3](#)
- [Save Configured Settings, page 7-3](#)
- [Restart Your DMP, page 7-4](#)
- [Rare but Essential Tasks, page 7-5](#)

## Log in to DMPDM

### Before You Begin

- This procedure assumes that you connected your DMP to its presentation system, and now they are both turned On.

### Procedure

**Step 1** While your presentation system shows the Cisco logo and shows an IP address for your DMP, write down the IP address.

**Step 2** Point your browser to the IP address that you wrote down.



**Note** **Use HTTPS as the connection protocol.** The connection fails when you use HTTP instead of HTTPS. This failure occurs by design, to support security in your network.

**Step 3** Respond to the prompt. It sometimes varies.

- **Does it ask you to EDIT a password before you can log in?**

*The first time that you start DMPDM, it prompts you to change its factory-defined master password. You will never see this prompt again, unless you restore your DMP to its factory-default settings.*

- a. Enter a new master password that contains at least eight characters, which combine uppercase and lowercase letters with numerals
- b. Click **Activate**.

- **Does it ask you to ENTER a password so that you can log in?**

- a. Use the login name **admin**.
- b. Use whichever master password you saved most recently.

**Step 4** Stop. Remain logged in. You have completed this procedure.

## Save Configured Settings

You can save every change that you made to the values for every option in DMPDM since the last time that you clicked Save or the last time that you restarted the DMP.



### Tip

**Changes to some DMP configuration settings do not take effect until after the DMP restarts.** Check the instructions for a procedure to see if you must restart your DMP after you change a setting.

**Procedure**

- Step 1** Complete whichever variation of this step applies to you. It might vary between any two DMP models, and also between the model-specific firmware versions from any two maintenance releases.

		<b>DMP Model</b>		
		<b>DMP 4310G</b>	<b>DMP 4400G</b>	<b>DMP 4305G</b>
<b>Firmware Version</b>				
	5.4.0	<ol style="list-style-type: none"> <li>a. Click <b>Save and Restart DMP</b> in the Administration list.</li> <li>b. Click <b>Save</b>.</li> <li>c. Click <b>Restart</b>.</li> </ol>		

The saved configuration persists even after your DMP restarts.

- Step 2** Stop. You have completed this procedure.

**Related Topics**

- [Restart Your DMP, page 7-4](#)
- [DMPDM Workflow, page 7-1](#)

## Restart Your DMP

**Procedure**

- Step 1** Complete whichever variation of this step applies to you. It might vary between any two DMP models, and also between the model-specific firmware versions from any two maintenance releases.

		<b>DMP Model</b>		
		<b>DMP 4310G</b>	<b>DMP 4400G</b>	<b>DMP 4305G</b>
<b>Firmware Version</b>				
	5.4.0	<ol style="list-style-type: none"> <li>a. Click <b>Save and Restart DMP</b> in the Administration list.</li> <li>b. Click <b>Restart</b>.</li> </ol> <p><b>Note</b> Alternatively, press the <a href="#">Reset</a> button.</p>		

- Step 2** Stop. You have completed this procedure.

## Rare but Essential Tasks

- [Configure NTP Settings for Time-Dependent Features, As Needed](#), page 7-5
- [Restore Factory Default Settings](#), page 7-6
- [Upgrade or Downgrade DMP Firmware](#), page 7-7
- [View DMP Hardware and Firmware Versions](#), page 7-8

### Configure NTP Settings for Time-Dependent Features, As Needed

IP-enabled devices including DMPs can use *network time protocol* (NTP) to synchronize themselves with radio and atomic clocks located on the Internet. Thus, the accuracy of their local time-keeping is ensured. NTP can synchronize distributed clocks within milliseconds over long time periods. You must configure NTP settings on any DMP through which you will provide:

- IPTV services with *Cisco Cast*.
- Proof-of-play services with *Cisco Digital Signs*.
- Any other service that is dependent upon accurate Start and Stop times.

#### Before You Begin

- [Log in to DMPDM](#).

#### Procedure

- 
- Step 1** Click **NTP** in the Settings list.
- Step 2** Choose **On** from the Enable NTP Service list.
- Step 3** Use the fields marked Hostname 1, Hostname 2, and Hostname 3 to specify which NTP servers your DMP should use.
- Hostname 1—Enter the DNS-resolvable name of the network time server to use by default. This is your primary time server. Your DMP will not use any other time server while this one is available.
-  **Note** We recommend that you set the default NTP hostname to [pool.ntp.org](http://pool.ntp.org).
- Hostname 2—Enter the DNS-resolvable name of a network time server to use whenever the primary time server is not available.
  - Hostname 3—Enter the DNS-resolvable name of a network time server to use whenever the secondary time server is not available.
- Step 4** Choose from the Time Zone list the time zone that is correct and local for your DMP at its location.
- Step 5** Enter in the Refresh Interval field the maximum number of milliseconds that are permitted to elapse before your DMP retrieves a fresh time stamp from its NTP server. The factory-default maximum is 17 ms.
- Step 6** Click **Apply** to confirm and test your choices.
- Your entries are recorded to volatile memory and take effect—but only until you change them or restart your DMP.

- Step 7** When you are satisfied that you chose the correct settings, click **Save Configuration** in the Administration list, and then click **Save**.
- Your entries take effect permanently and will persist even after your DMP restarts.
- Step 8** Stop. You have completed this procedure.

#### Related Topics

- [Log in to DMPDM, page 7-3](#)

## Restore Factory Default Settings

You can restore factory settings to your DMP.



#### Caution

**When you restore the factory settings to your DMP, you delete your configuration of every setting.** If you delete your settings accidentally, you must reenter every value manually.

#### Procedure

- Step 1** Do one of the following.
- *Would you like to use DMPDM?* **When you will use the software reset**
    - Click **Restore Default Settings** in the Administration list.
    - Click **Restore** when the Restore Default Settings page appears.
    - Your DMP restarts automatically and its factory settings are restored.
  - *Would you like to use the Reset button on a DMP?* **When you will use the hardware reset**
    - Press and hold the Reset button for *at least* 10 seconds.
    - Wait for your DMP to beep twice (unless it is a DMP 4310G, which does not beep).
- Step 2** **(Optional)** *Will you deploy your DMP where there is no local DHCP server?* Do one of the following.
- *Would you like to set a static IP address?* **When you prefer to use a static address**
    - See the “[Prepare Your DMP to Use a Static IP Address Over Ethernet](#)” section on page 10-17.
  - *Would you like to set a pseudo-random IP address?* **When you prefer to use a pseudo-random address**
    - See the “[Understand Pseudo-random IP Addressing](#)” section on page 5-2
- Step 3** Log in with the factory default username **admin**.

**Step 4** Reconfigure your DMP and change its default passwords, when prompted.

To learn how, see *Getting Started Guide for Cisco Digital Media Players* at [http://cisco.com/en/US/docs/video/digital\\_media\\_systems/dmp/getting/started/guide/5\\_4\\_x/GSG\\_all\\_DMPs.html](http://cisco.com/en/US/docs/video/digital_media_systems/dmp/getting/started/guide/5_4_x/GSG_all_DMPs.html).

**Step 5** Stop. You have completed this procedure.

---

## Investigate Which DMP Firmware Updates Are Available

### Procedure

---

**Step 1** Log in to your Cisco.com account.

**Step 2** Go to <http://www.cisco.com/cisco/software/navigator.html?mdfid=280936311&flowid=21001>.

**Step 3** Click a DMP model to see a selection tree that lists its available firmware versions. (Its newest release is selected by default.)

**Step 4** Expand the tree as needed, and then click a release number to see its details.



**Note** Every firmware file is DMP model-specific.

---

**Step 5** Follow the prompts to download your preferred firmware within a compressed archive file.

**Step 6** Decompress the archive.

It contains a README file, which:

- States how the new firmware might affect your equipment and network.
- Includes installation procedures.

**Step 7** Complete procedures that the README file recommends for you.

**Step 8** Stop. You have completed this procedure.

---

## Upgrade or Downgrade DMP Firmware

You can install an update to the firmware for your DMP.

**OR**

When your DMP firmware is so comparatively recent that it does not work well with older software on your DMM server, you can install older firmware on your DMP.

### Before You Begin

- Investigate which DMP firmware releases are available on Cisco.com.
- Confirm that the “Enable Cisco TAC Troubleshooting Access” feature is enabled in DMPDM. If you must enable it manually, you must *also* restart your DMP before this change can take effect.

### Procedure

---

- Step 1** Click **Upgrade Firmware** in the Administration list.
- Step 2** Click **Browse**—or its equivalent if your browser applies a different name to this button—when the Upgrade Firmware page appears.
- Step 3** Navigate to the firmware update that you downloaded, and then choose it.
- Step 4** Click **Start Upgrade**.



**Note** Do not close or browse away from this page until messages in DMPDM state that your DMP has loaded the firmware image and started to burn it. Otherwise, upgrade fails.

---

- Step 5** Stop. You have completed this procedure.
- 

### Related Topics

- [Enable or Disable Types of Access to Your DMP, page 8-5](#)
- [UI Reference: Elements to Upgrade or Downgrade DMP Firmware, page 7-9](#)

## View DMP Hardware and Firmware Versions

### Procedure

---

- Step 1** Click **Hardware and Firmware Versions** to see information about your DMP.  
You cannot change the information.
- Step 2** Stop. You have completed this procedure.
- 

## Reference

- [UI Reference Topics, page 7-8](#)

## UI Reference Topics

- [UI Reference: Elements to Upgrade or Downgrade DMP Firmware, page 7-9](#)

## UI Reference: Elements to Upgrade or Downgrade DMP Firmware

**Table 7-1** Elements on the Upgrade Firmware Page

Field	Description
<b>Upgrade Firmware</b>	
Image File	The full pathname to the binary file. If you do not know the full pathname, click <b>Browse</b> .
<b>Upgrade Status</b>	
Status	Indicates whether a firmware upgrade is in progress: <ul style="list-style-type: none"><li>• <b>Firmware upgrade not active</b>—There is no upgrade in progress.</li><li>• <b>Burn in progress</b>—An upgrade is in progress.</li></ul>
Progress	Status indicator for an upgrade in progress.

