



Setting Up a Nortel Meridian 1 Digital PIMG Integration with Cisco Unity Connection

- [Setting Up a Nortel Meridian 1 Digital PIMG Integration](#), page 1

Setting Up a Nortel Meridian 1 Digital PIMG Integration

Task List for Nortel Meridian 1 PIMG Phone System Integration

Before doing the following tasks to integrate Unity Connection with the Nortel Meridian 1 phone system using PIMG units (media gateways), confirm that the Unity Connection server is ready for the integration after completing the server installation, following the tasks in the “[Installing Cisco Unity Connection](#)” chapter of the Install, Upgrade, and Maintenance Guide for Cisco Unity Connection, Release 11.x, available at https://www.cisco.com/c/en/us/td/docs/voice_ip_comm/connection/11x/install_upgrade/guide/b_11xcuciumg/b_11xcuciumg_chapter_00.html.

- 1 Review the system and equipment requirements to confirm that all phone system and Cisco Unity Connection server requirements have been met. See the [Requirements](#) section.
- 2 Plan how the voice messaging ports are used by Unity Connection. See the [Planning the Usage of Voice Messaging Ports](#) chapter.
- 3 Program the Nortel Meridian 1 phone system and extensions. See the [Programming Nortel Meridian 1 PIMG Phone System Integration](#) section.
- 4 Set up the PIMG units. See the [Setting Up Digital PIMG Units](#) section.
- 5 Create the integration. See the [Configuring Unity Connection for Integration with Nortel Meridian 1 Phone System](#), on page 29 section .
- 6 Test the integration. See the [Testing the Integration](#) chapter.
- 7 If this integration is a second or subsequent integration, add the applicable new user templates for the new phone system. See the [Integrations with Multiple Phone Systems](#) chapter.

Requirements

This integration supports configurations of the following components:

Phone System

- One of the following models:
 - Nortel Meridian 1 phone system (Option 11, 21, 51, 61, 71, or 81), software release 17 or later.
 - Nortel Succession (CS 1000) phone system, software release 3.0 or later.
 - The Nortel SL 1 phone system, when upgraded to Meridian 1 so that it is compatible with the M2616 digital phone.
- The following software option packages installed:
 - Package 19, Digit Display Software (DDSP)
 - Package 46, Message Waiting Center (MWC)
- One or more digital lines that are compatible with the M2616 digital phone for connecting to the PIMG units.
- One or more of the applicable PIMG units. For details, see the [“Introduction”](#) chapter.
- The voice messaging ports in the phone system connected by digital lines to the ports on the PIMG units.

To simplify troubleshooting, we recommend that you connect the voice messaging ports on the phone system to the ports on the PIMG units in a planned manner. For example, connect the first phone system voice messaging port to the first port on the first PIMG unit, connect the second phone system voice messaging port to the second port on the first PIMG unit, and so on. Alternatively, if you have multiple PIMG units, you can reduce answer times in the event of a PIMG unit failure by connecting the phone system ports to the PIMG units in a round-robin fashion. For example, connect the first phone system voice messaging port to the first port on the first PIMG unit, connect the second phone system voice messaging port to the first port on the second PIMG unit, and so on.

- The PIMG units connected to the same LAN or WAN that Unity Connection is connected to.
- If the PIMG units connect to a WAN, the requirements for the WAN network connections are:
 - For G.729a codec formatting, a minimum of 32.76 Kbps guaranteed bandwidth for each voice messaging port.
 - For G.711 codec formatting, a minimum of 91.56 Kbps guaranteed bandwidth for each voice messaging port.
 - No network devices that implement network address translation (NAT).
 - A maximum 200 ms one-way network latency.

Unity Connection Server

- Unity Connection installed following the tasks in the “[Installing Cisco Unity Connection](#)” chapter of the Install, Upgrade, and Maintenance Guide for Cisco Unity Connection, Release 11.x, available at https://www.cisco.com/c/en/us/td/docs/voice_ip_comm/connection/11x/install_upgrade/guide/b_11xcuciumg.html.
- A license that enables the applicable number of voice messaging ports.

Programming Nortel Meridian 1 PIMG Phone System Integration

The following programming instructions are provided as an example only. The specific programming for your phone system may vary depending on its configuration.



Caution

In programming the phone system, do not send calls to voice messaging ports in Unity Connection that cannot answer calls (voice messaging ports that are not set to Answer Calls). For example, if a voice messaging port is set only to Send MWI Requests, do not send calls to it.

Do the following steps to program the Nortel Meridian 1 phone system.

Step 1 Assign extensions for the voice messaging ports.

Step 2 Confirm that the software on the phone system has the necessary following option packages using overlay 22:

- DDSP (Package 19, Digit Display Software)
- MWC (Package 46, Message Waiting Center)

If either of these options is missing, contact your sales representative.

Step 3 On overlay 11, set the following options to create the M2616 digital set emulation for the first port.

Table 1: Digital Set Emulation Options for the Second Port

Option	Setting
REQ	Enter NEW .
TYPE	Enter 2616 .
TN	Enter 0 0 6 2 .
CUST	Enter 0 .
CLS	Enter ADD HFD CNDA HTA MWA .
HUNT	Enter the extension of the second port on the PIMG unit.

Option	Setting
KEY 00 SCR	Enter the primary number for this PIMG unit. Enter any valid unused number.
KEY 13 MIK	
KEY 14 MCK	
KEY 15 TRN	

Step 4 Set the following options to create the digital set emulation for the second port.

Table 2: Digital Set Emulation Options for the Second Port

Option	Setting
REQ	Enter NEW .
TYPE	Enter 2616 .
TN	Enter 0 0 6 3 .
CUST	Enter 0 .
CLS	Enter ADD HFD CNDA HTA MWA .
HUNT	Enter the extension of the next port on the PIMG unit.
KEY 00 SCR	Enter the extension for this PIMG unit port. Enter any valid unused number.
KEY 13 MIK	
KEY 14 MCK	
KEY 15 TRN	

Step 5 Repeat [Step 4](#) for all remaining ports on the PIMG units.

Step 6 On overlay 95, set the following options to enable display of a four-letter code that represents why the call was forwarded.

Table 3: Calling Party Display Options

Option	Setting
REQ	Enter CHG .
TYPE	Enter CPND .

Option	Setting
CUST	Enter the customer number.
RESN	Enter YES .
CFWD	Enter CFWD .
CFNA	Enter CFNA .
HUNT	Enter HUNT .
XFER	Enter T .
AAA	Enter A .

Step 7 On each subscriber phone, program the phone to forward calls to the pilot number assigned to the voice messaging ports, based on one of the Unity Connection call transfer types shown in [Table 4: Call Transfer Types](#).

Table 4: Call Transfer Types

Transfer Type	Usage
Release transfer (blind transfer)	Program the phone to forward calls to the pilot number when: <ul style="list-style-type: none"> • The extension is busy • The call is not answered
Supervised transfer	Program the user station to forward calls to the pilot number only when the call is not answered (on the phone system, the number of rings before forwarding must be more than the number of rings to supervise the call). Confirm that call forwarding is disabled when the extension is busy.

Step 8 Use [Table 5: Hunt Methods for the Nortel Meridian 1 Phone System](#) to determine the hunt method that you want to use, and do the applicable procedure.

Table 5: Hunt Methods for the Nortel Meridian 1 Phone System

Hunt Method	Procedure
<p>Hunting Group</p> <ul style="list-style-type: none"> • Use for systems with up to 30 voice messaging ports. • The search route calls to the next idle PIMG port in the group when a call encounters a busy port. • When the search reaches a PIMG port that has been disabled or has lost its Unity Connection to the PIMG unit, the search stops at this port. The call rings until the caller hangs up. 	<p>See the Setting Up Hunt Group for Up to 30 Ports.</p>
<p>ACD Hunt Group</p> <ul style="list-style-type: none"> • Use for systems with more than 30 voice messaging ports. • The search route calls to the next idle PIMG port in the group when a call encounters a busy port. • When the search reaches a PIMG port that has been disabled or has lost its Unity Connection to the PIMG unit, the search stops at this port. The call rings until the caller hangs up. 	<p>See the Setting Up ACD Hunt Group for More Than 30 Ports.</p>
<p>Group Hunt Feature</p> <ul style="list-style-type: none"> • Use for systems with any number of voice messaging ports. • Software option package 120 must be installed on the phone system. • The search route calls to the next idle PIMG port in the group when a call encounters a busy port. • When the search reaches a PIMG port that has been disabled or has lost its Unity Connection to the PIMG unit, the search continues to the next available port. 	<p>See the Setting Up ACD Hunt Group for More Than 30 Ports.</p>

Setting Up Hunt Group for Up to 30 Ports

See [Table 5: Hunt Methods for the Nortel Meridian 1 Phone System](#) for considerations about using this procedure.

-
- Step 1** Set up the first voice messaging port as the pilot number of the hunt group.
- Step 2** Set the first voice messaging port to hunt to the second voice messaging port.
- Step 3** Set the second voice messaging port to hunt to the third, then continue up to the 30th.
- Step 4** Set the 30th voice messaging port to hunt to the first voice messaging port. See the example in [Table 6: Example of a 30-Port Hunt Group](#).

Table 6: Example of a 30-Port Hunt Group

Device	Setting	Destination
Port 1	HUNT	Port 2
Port 2	HUNT	Port 3
Port 3	HUNT	Port 4
...	HUNT	<additional ports>
Port 29	HUNT	Port 30
Port 30	HUNT	Port 1

Setting Up ACD Hunt Group for More Than 30 Ports

See [Table 5: Hunt Methods for the Nortel Meridian 1 Phone System](#) for considerations about using this procedure.

-
- Step 1** Set up ACD 1 as the pilot number of the hunt group.
- Step 2** With the Night Call Forward Destination (NCFW) command, set ACD 1 to forward to the first voice messaging port.
- Step 3** Set the first voice messaging port to hunt to the second, then continue up to the 30th.
- Step 4** Set the 30th voice messaging port to hunt to ACD 2.
- Step 5** With the NCFW command, set ACD 2 to forward to the 31st voice messaging port.
- Step 6** Set the 31st voice messaging port to hunt to the 32nd, and so on.
- Step 7** Continue creating 30-port hunt groups in this manner until the last voice messaging port.
- Step 8** Set the last voice messaging port to hunt to ACD 1. See the example in [Table 7: Example of a 72-Port ACD Hunt Group](#).

Table 7: Example of a 72-Port ACD Hunt Group

Device	Settings	Destination
ACD 1 (pilot number)	NCFW	Port 1
Port 1	HUNT	Port 2
Port 2	HUNT	Port 3
<additional ports>		<additional ports>
Port 29	HUNT	Port 30
Port 30	HUNT	ACD 2
ACD 2	NCFW	Port 31
Port 31	HUNT	Port 32
<additional ports>		<additional ports>
Port 59	HUNT	Port 60
Port 60	HUNT	ACD 3
ACD 3	NCFW	Port 61
Port 61	HUNT	Port 62
<additional ports>		<additional ports>

Device	Settings	Destination
Port 71	HUNT	Port 72
Port 72	HUNT	ACD 1

Setting Up the Group Hunt Feature

See [Table 5: Hunt Methods for the Nortel Meridian 1 Phone System](#) for considerations about using this procedure.

Step 1 In LD 22, verify that software package 120 is equipped.

Table 8: Entries for LD 22

Prompt	Entry
REQ:	Enter PRT to start a print request.
TYPE:	Enter PKG to print the list of equipped packages.

Step 2 In LD 18, create a Group Hunt list number.

Table 9: Entries for LD 18

Prompt	Entry
REQ:	Enter NEW .
TYPE:	Enter GHT .
LSNO:	Enter the list number for the Group Hunt list. For example, enter 1.
CUST:	Enter the customer number as defined in LD 15.
DNSZ:	Enter the maximum length of DN allowed for Group Hunt list.
SIZE:	Enter the maximum number of DNs in the Group Hunt list.
WRT:	Enter YES to write the information to the data store.

Prompt	Entry
STOR:	Press Enter .

Step 3 In LD 57, define the Pilot DN (PLDN) and associate it with the number for the Group Hunt list.

Table 10: Entries for LD 57

Prompt	Entry
REQ:	Enter CHG .
TYPE:	Enter FFC .
CUST:	Enter the customer number as defined in LD 15.
FFCT:	Press Enter .
CODE:	Enter PLDN for the Pilot DN.
PLDN:	Enter the DN that is the pilot for the Group Hunt list.
USE:	Enter GPHT .
LSNO:	Enter the Group Hunt list number that you created in LD 18.
HTYP:	Do one of the following: <ul style="list-style-type: none"> • If you want linear hunting, enter LIN. • If you want round robin hunting, enter RRB.
CFWI:	Do one of the following: <ul style="list-style-type: none"> • If you want Group Hunting to skip idle stations with Call Forward All Calls active, enter NO. • If you want Group Hunting to terminate on idle stations with Call Forward All Calls active, enter YES.
MQUE:	Do one of the following to configure the maximum number of calls allowed in the Pilot DN queue: <ul style="list-style-type: none"> • If you want to no calls in the queue, enter 0. • If you want only one call in the queue at a time, enter 1. • If you want no limit on the number of calls in the queue, enter ALL. • If you want the number of calls in the queue to be less than or equal to the number of active members of the Group Hunt list, enter ACTM.

Step 4 In LD 18, modify the Group Hunt list number.

Table 11: Entries for LD 18

Prompt	Entry
REQ:	Enter CHG .
TYPE:	Enter GHT .
LSNO:	Enter the list number for the Group Hunt list that you created in Step 2 . For example, enter 1.
SIZE:	Enter the maximum number of DNs in the Group Hunt list.
WRT:	Enter YES to write the information to the data store.
STOR:	Enter the first DN in the Group Hunt list in the following format: x...x y...y For example, enter 00 2216.
WRT:	Enter YES to write the information to the data store.
STOR:	Enter the second DN in the Group Hunt list in the following format: x...x y...y For example, enter 01 2217.
WRT:	Enter YES to write the information to the data store.
STOR:	Enter the third DN in the Group Hunt list in the following format: x...x y...y For example, enter 02 2218.
...	Add more DNs in the Group Hunt list.
WRT:	Enter YES to write the information to the data store.
STOR:	Enter the last DN in the Group Hunt list in the following format: x...x y...y For example, enter 07 2223.

Step 5 In LD 11, enter a Group Hunt Pilot DN (PLDN) for each DN in the Group Hunt list that connects to a PIMG port.

Table 12: Entries for LD 11

Prompt	Entry
REQ:	Enter CHG .
TYPE:	Enter the first DN in the Group Hunt list. For example, enter 2616.
TN:	Enter 1 0 0 7 .
ECHG:	Enter YES .
	Enter FDN <extension> for the PLDN that you configured in Step 3 .
	Enter HUNT <extension> for the PLDN that you configured in Step 3 .
	If applicable, enter EHT <extension> for the PLDN that you configured in Step 3 .
	If applicable, enter EFD <extension> for the PLDN that you configured in Step 3 .

Step 6 Repeat [Step 5](#) for all remaining DNs in the Group Hunt list.

Setting Up Digital PIMG Units

Do the following procedures to set up the digital PIMG units that are connected to the Nortel Meridian 1 phone system.

These procedures require that the following tasks have already been completed:

- The phone system is connected to the PIMG units using digital lines.
- The PIMG units are ready to be connected to the LAN or WAN.
- The PIMG units are connected to a power source.

Fields that are not mentioned in the following procedures must keep their default values. For the default values of all fields, see the manufacturer documentation for the PIMG units.

Downloading the PIMG firmware update files for digital PIMG units

<http://software.cisco.com/download/navigator.html?mdfid=280082558&i=rm>.

**Note**

To access the software download page, you must be signed in to Cisco.com as a registered user.

This procedure describes the steps when using Internet Explorer as your web browser. If you are using a different web browser, the steps may differ.

- 1 In the tree control on the Downloads Home page, expand Unified Communications> **Unified Communications Applications** > **Messaging** > **Cisco Unity** and select **Cisco Unity Telephony Integration**.
- 2 On the Log In page, enter your username and password, then select **Log In**.
- 3 On the Select a Release page, under Latest Releases, select the most recent release.
- 4 In the right column, select the version of the firmware for digital PIMG units.
- 5 On the Download Image page, select **Download**.
- 6 On the Supporting Document(s) page, select **Agree**.
- 7 In the File Download dialog box, select **Save**.
- 8 In the Save As dialog box, browse to the Windows workstation that have access the PIMG units, browse to a directory where you want to save the file, and select **Save**.
- 9 In the Download Complete dialog box, select **Open**. The window for extracting the PIMG firmware update files appears and select **Extract**.
- 10 In the Extract dialog box, browse to the directory where you want the extracted files, and select **Extract**.
- 11 Close the window for the extracting application.

On a Windows workstation that have access to the PIMG units, go to the following link:

Setting Up Digital PIMG Units (Firmware Version 6.x)

-
- Step 1** On the Windows workstation, add a temporary route to enable access to the PIMG units.
- a) On the Windows Start menu, select **Run**.
 - b) Enter **cmd**, and press **Enter**. The Command Prompt window appears.
 - c) At the command prompt, enter **route add 10.12.13.74 <IP Address of Workstation>**, and press **Enter**.
For example, if the IP address of the workstation is 198.1.3.25, enter “route add 10.12.13.74<space>198.1.3.25” in the Command Prompt window.
 - d) Close the Command Prompt window.
- Step 2** Connect a PIMG unit to the network.
- Step 3** In the web browser, go to **http://10.12.13.74**.
- Step 4** To sign in, enter the following case-sensitive settings.

Table 13: Sign-in Settings

Field	Setting
Username	Enter admin .
Password	Enter IpodAdmin .

- Step 5** Select **OK**.
- Step 6** On the System menu, select **Upgrade**.
- Step 7** On the Upgrade page, select **Browse**.
- Step 8** In the Choose File dialog box, browse to the directory on the Windows workstation that has the extracted PIMG firmware update files.
- Step 9** Select **Ami<xx> .app** (where <xx> is multiple digits), and select **Open**.
- Step 10** On the Upgrade page, select **Install File**.
- Step 11** After the file is installed, a message prompting you to restart the PIMG unit appears. Select **Cancel**. Do not restart the PIMG unit until you are instructed to do so later in this procedure, even if the file installation fails. Restarting the PIMG unit at this step may prevent the PIMG unit from functioning correctly.
- Step 12** Repeat **Step 6** through **Step 11** for each of the following files:
- Ami_<xx>.fsh
 - Run<xx>FskEcho.dsp
 - iNim<xx>.ibt
 - iNim<xx>.ilc
 - iNim<xx>.iap
- Step 13** On the Configuration menu, select **Import/Export**.
- Step 14** On the Import/Export page, select **Browse**.
- Step 15** In the Choose File dialog box, browse to the file DNI_Cfg_Generic.ini.
- Step 16** Select **DNI_Cfg_Generic.ini**, and select **Open**.
- Step 17** On the Import/Export page, select **Import File**.
- Step 18** After the file is imported, a message prompting you to restart the PIMG unit appears. Select **OK**.
- Step 19** In the web browser, go to **http://10.12.13.74**.
- Step 20** To sign in, enter the following case-sensitive settings.

Table 14: Sign-in Settings

Field	Setting
Username	Enter admin .
Password	Enter IpodAdmin .

Step 21 Select **OK**.

Step 22 Do the following substeps to configure an RTP port range of 16384 to 32767. You must set the RTP port range for the PIMG units if your system uses an RTP port range of 16384 to 32767. Otherwise, Unity Connection cannot answer calls and callers hear ringing or silence.

Note The default RTP port range for PIMG units is 49000 to 50000. Some Unity Connection configurations require a different RTP port range.

- a) On the Configuration menu, select **Import/Export**.
- b) On the Import/Export page, under Export Settings, select **Export All Settings**.
- c) In the File Download dialog box, select **Save**.
- d) In the Save As dialog box, browse to the Windows workstation that has access to the PIMG units, browse to a directory where you want to save the file, and select **Save**.
- e) In the Download Complete dialog box, select **Open**. Notepad opens the file Config.ini that you saved.
- f)
- g)
- h) Locate the line with the following parameter:

```
gwRTPStartPort
```

- i) Change the value of the parameter to **16384** so that the line reads as follows:

```
gwRTPStartPort = 16384
```

- j) Locate the line with the following parameter:

```
gwRTPEndPort
```

- k) Change the value of the parameter to **32767** so that the line reads as follows:

```
gwRTPEndPort = 32767
```

- l) Save the file, and exit Notepad.
- m) On the Configuration menu of the PIMG unit, select **Import/Export**.
- n) On the Import/Export page, under Browse for Import File, select **Browse**.
- o) In the Choose File dialog box, browse to the file Config.ini that you saved.
- p) Select **Config.ini**, and select **Open**.
- q) On the Import/Export page, select **Import File**.
- r) When prompted to restart the PIMG unit, select **OK**.
- s) When the PIMG unit has restarted, in the web browser, go to **http://10.12.13.74**.
- t) To sign in, enter the following case-sensitive settings.

Table 15: Sign-in Settings

Field	Setting
Username	Enter admin .
Password	Enter IpodAdmin .

u) Select **OK**.

Step 23 On the System menu, select **Password**.

Step 24 On the Change Password page, enter the following settings.

Table 16: Change Password Page Settings

Field	Setting
Old Password	Enter IpodAdmin . (This setting is case sensitive.)
New Password	Enter your new password. (This setting is case sensitive.)
Confirm Password	Enter your new password. (This setting is case sensitive.)

Step 25 Select **Change**.

Step 26 On the Configuration menu, select **Routing Table**.

Step 27 On the Routing Table page, under Router Configuration, select **VoIP Host Groups**.

Step 28 Under VoIP Host Groups, enter the following settings for the first VoIP Host Group.

Table 17: First VoIP Host Group Settings

Field	Settings
Name	Accept the default or enter another descriptive name of the VoIP host group.
Load-Balanced	(Unity Connection <i>without a cluster</i>) Select False . (Unity Connection <i>with a cluster configured</i>) Select False .
Fault-Tolerant	(Unity Connection <i>without a cluster</i>) Select False . (Unity Connection <i>with a cluster configured</i>) Select True .

Step 29 For Unity Connection without a cluster, under Host List, enter the host name or IP address of the Unity Connection server and the server port in the format <host name or IP address>:5060.

For Unity Connection with a cluster configured, under Host List, enter the host name or IP address of the subscriber server (the second Unity Connection server that you installed) and the server port in the format <host name or IP address>:5060.

Step 30 For Unity Connection without a cluster, continue to [Step 32](#). For Unity Connection with a cluster configured, select **Add Host**.

Step 31 In the second field, enter the host name or IP address of the publisher server (the first Unity Connection server that you installed) and the server port in the format <host name or IP address>:5060.

Do not add a third host under Host List or a second host group under VoIP Host Groups. Otherwise, the Unity Connection cluster may not function correctly.

Step 32 Select **Submit**.

Step 33 Under Router Configuration, select **TDM Trunk Groups**.

Step 34 Under TDM Trunk Groups, select **Add Trunk Group**.

Step 35 Under TDM Trunk Groups, enter the following settings for the first TDM trunk group.

Table 18: First TDM Trunk Group Settings (Inbound Calls)

Field	Settings
Name	Enter Inbound_PBX_Calls or another unique name. This TDM trunk group handles all incoming calls from the phone system.
Selection Direction	Select Ascending .
Selection Mode	Select Linear .
Port/Channel Content	Enter the numbers of the PIMG ports that handles inbound calls. For example, enter "*" for all PIMG ports, or enter "1-6" for the first six PIMG ports.

Step 36 Under TDM Trunk Groups, select **Add Trunk Group**.

Step 37 Enter the following settings for the second TDM trunk group.

Table 19: Second TDM Trunk Group Settings (MWIs)

Field	Settings
Name	Enter MWIs or another unique name. This TDM trunk group handles outbound MWI calls (where applicable).
Selection Direction	Select Ascending .
Selection Mode	Select Cyclic .
Port/Channel Content	Enter the numbers of the PIMG ports that dial out MWIs. For example, enter "*" for all PIMG ports, or enter "7,8" for the last two PIMG ports.

Step 38 Under TDM Trunk Groups, select **Add Trunk Group**.

Step 39 Enter the following settings for the third TDM trunk group.

Table 20: Third TDM Trunk Group Settings (Outbound Calls)

Field	Settings
Name	Enter Outbound_PBX_Calls or another unique name. This TDM trunk group handles all outbound calls from Unity Connection.
Selection Direction	Select Descending .
Selection Mode	Select Linear .
Port/Channel Content	Enter * for all channels in all ports. Enter the numbers of the PIMG ports that handle outbound (dialout) calls. For example, enter "*" for all PIMG ports, or enter "7,8" for the last two PIMG ports.

Step 40 Select **Submit**.

Step 41 Under Router Configuration, select **Inbound VoIP Rules**.

Step 42 Under Inbound VoIP Rules, uncheck the **Enabled** check box for the default rule.

Step 43 Select **Add Rule**.

Step 44 Under Inbound VoIP Rules, enter the following settings for the first new inbound VoIP rule.

Table 21: First New Inbound VoIP Rule Settings (MWIs)

Field	Settings
Enable	Check this check box.
Rule Label	Enter MWI_Calls or another name. This inbound VoIP rule handles all MWI calls from Unity Connection.
Request Type	Select Message .
Originating VoIP Host Address	Enter *.

Step 45 Under Inbound VoIP Request Matching, enter the following settings.
The rule that you created in [Step 44](#) must be selected. Otherwise, any changes you make apply to another inbound VoIP rule.

Table 22: Inbound VoIP Request Matching Settings

Field	Settings
Calling Number	Enter *.

Field	Settings
Calling Name	Enter *.
Called Number	Enter *.
Called Name	Enter *.
Redirect Number	Enter *.
Redirect Name	Enter *.

- Step 46** Under Outbound Routes, enter the following settings.
The rule that you created in [Step 44](#) must be selected. Otherwise, any changes you make apply to another rule.

Table 23: Outbound Routes Settings

Field	Settings
Device Selection	
Outbound Destination	Select TDM .
Trunk Group	Select the name of the TDM trunk group that you created for MWIs in Step 37 . For example, select "MWIs."
CPID Manipulation	
Calling Number	Enter S .
Calling Name	Enter S .
Called Number	Enter D .
Called Name	Enter D .
Redirect Number	Enter R .
Redirect Name	Enter R .
Select Primary/Alternate Route	
Primary	Select Primary .

- Step 47** Under Inbound VoIP Rules, select **Add Rule**.

- Step 48** Under Inbound VoIP Rules, enter the following settings for the second new inbound VoIP rule.

Table 24: Second New Inbound VoIP Rule Settings (Outbound Calls)

Field	Settings
Enable	Check this check box.
Rule Label	Enter Outbound_UC_Calls or another name. This inbound VoIP rule handles all outbound calls from Unity Connection.
Request Type	Select Call .
Originating VoIP Host Address	Enter *.

- Step 49** Under Inbound VoIP Request Matching, enter the following settings.
The rule that you created in [Step 48](#) must be selected. Otherwise, any changes you make apply to another rule.

s

Table 25: Inbound VoIP Request Matching Settings

Field	Settings
Calling Number	Enter *.
Calling Name	Enter *.
Called Number	Enter *.
Called Name	Enter *.
Redirect Number	Enter *.
Redirect Name	Enter *.

- Step 50** Under Outbound Routes, enter the following settings.
The rule that you created in [Step 48](#) must be selected. Otherwise, any changes you make apply to another rule.

Table 26: Outbound Routes Settings

Field	Settings
Device Selection	
Outbound Destination	Select TDM .

Field	Settings
Trunk Group	Select the name of the TDM trunk group that you created for outbound calls in Step 39 . For example, select "Outbound_PBX_Calls."
CPID Manipulation	
Calling Number	Enter S .
Calling Name	Enter S .
Called Number	Enter D .
Called Name	Enter D .
Redirect Number	Enter R .
Redirect Name	Enter R .
Select Primary/Alternate Route	
Primary	Select Primary .

Step 51 Select **Submit**.

Step 52 Under Router Configuration, select **Inbound TDM Rules**.

Step 53 Under Inbound TDM Rules, enter the following settings for the first inbound TDM rule.

Table 27: First Inbound TDM Rule Settings

Field	Settings
Enable	Check this check box.
Rule Label	Enter Inbound_Rule_1 or another name. This inbound TDM rule handles all incoming calls from the phone system.
Request Type	Select Call .
Trunk Group	Select the name of the TDM trunk group that you created for incoming calls from the phone system in Step 35 . For example, select "Inbound_PBX_Calls."

Step 54 Under Inbound TDM Request Matching, enter the following settings.

The rule that you created in [Step 53](#) must be selected. Otherwise, any changes you make apply to another rule.

Table 28: Inbound TDM Request Matching Settings

Field	Settings
Calling Number	Enter the applicable matching rule used. For example, enter "*" for all.
Calling Name	Enter the applicable matching rule used. For example, enter "*" for all.
Called Number	Enter the applicable matching rule used. For example, enter "*" for all.
Called Name	Enter the applicable matching rule used. For example, enter "*" for all.
Redirect Number	Enter the applicable matching rule used. For example, enter "*" for all.
Redirect Name	Enter the applicable matching rule used. For example, enter "*" for all.

- Step 55** Under Outbound Routes, enter the following settings.
The rule that you created in [Step 53](#) must be selected. Otherwise, any changes you make apply to another rule.

Table 29: Outbound Routes Settings

Field	Settings
Device Selection	
Outbound Destination	Select VoIP .
Host Group	Select the name of the VoIP host group that you created for Unity Connection in Step 28 .
CPID Manipulation	
Calling Number	Enter S.
Calling Name	Enter S.
Called Number	Enter D.
Called Name	Enter D.
Redirect Number	Enter R.
Redirect Name	Enter R.
Select Primary/Alternate Route	
Primary	Select Primary .

- Step 56** If you want to create more Inbound TDM rules, under Inbound TDM Rules, select **Add Rule**. Otherwise, continue to [Step 58](#).
- Step 57** Repeat [Step 53](#) through [Step 56](#) for all remaining inbound TDM rules that you want to create.
- Step 58** Select **Submit**.
- Step 59** On the Configuration menu, select **TDM > Digital**.
- Step 60** On the Digital Telephony page, in the Telephony Switch Type field, select M1.
- Step 61** Select **Submit**.
- Step 62** On the Configuration menu, select **TDM > General**.
- Step 63** On the TDM General Settings page, enter the following settings.

Table 30: TDM General Settings Page Settings

Field	Settings
PCM Coding	Select uLaw .
Minimum Call Party Delay (ms)	Enter 500 .
Maximum Call Party Delay (ms)	Enter 2000 .
Dial Digit on Time (ms)	Enter 100 .
Dial Inter-Digit Time (ms)	Enter 100 .
Dial Pause Time (ms)	Enter 2000 .
Turn MWI On FAC	Leave this field blank.
Turn MWI Off FAC	Leave this field blank.
Outbound Call Connect Timeout (ms)	Enter 10000 .
Wait for Ringback/Connect on Blind Transfer	Select Yes .
Hunt Group Extension	Enter the pilot number of the Unity Connection voice messaging ports.
Disconnect on Fax Cleardown Tone	Select No .

- Step 64** Select **Submit**.
- Step 65** On the Configuration menu, select **TDM > Port Enable**.
- Step 66** On the TDM Port Enabling page, select **No** for the ports that you want to disable on the PIMG unit.
- Step 67** Confirm that **Yes** is selected for all other ports on the PIMG unit.
- Step 68** Select **Submit**.
- Step 69** On the Configuration menu, select **VoIP > General**.
- Step 70** On the VoIP General Settings page, enter the following settings.

Table 31: VoIP General Settings Page Settings

Field	Setting
User-Agent	
Host and Domain Name	Enter the host and domain name of the PIMG unit.
Transport Type	Select UDP .
Call as Domain Name	Select No .
SIPS URI Scheme Enabled	Select No .
Invite Expiration (sec)	Enter 120 .
Server	
DNS Server Address	Enter the IP Address of the Domain Name Server that the PIMG unit uses.
DNS Translation of Phone Numbers	Select No .
Registration Server Address	Leave this field blank.
Registration Server Port	Enter 5060 .
Registration Expiration (sec)	Enter 3600 .
TCP/UDP	
UDP/TCP Transports Enabled	Select Yes .
TCP/UDP Server Port	Enter 5060 .

Field	Setting
TCP Inactivity Timer (sec)	Enter 30 .
TLS	
TLS Transport Enabled	Select No .
TLS Server Port	Enter 5061 .
SSL TLS Protocol	Select SSLv3 TLSv1 .
Mutual TLS Authentication Required	Select Yes .
TLS Inactivity Timer (sec)	Enter 30 .
Verify TLS Peer Certificate Date	Select Yes .
Verify TLS Peer Certificate Trust	Select Yes .
Proxy	
Primary Proxy Server Address	Leave this field blank. Unity Connection
Primary Proxy Server Port	Not applicable. Leave the default setting.
Backup Proxy Server Address	Not applicable. Leave the default setting.
Backup Proxy Server Port	Not applicable. Leave the default setting.
Proxy Query Interval	Enter 10 .
Timing	
T1 Time (ms)	Enter 400 .
T2 Time (ms)	Enter 3000 .
T4 Time (ms)	Enter 5000 .
Monitoring	

Field	Setting
Monitor Call Connections	Select No.
Call Monitor Interval (sec)	
Monitor VoIP Hosts	
VoIP Host Monitor Interval (sec)	

Step 71 Select **Submit**.

Step 72 On the Configuration menu, select **VoIP > Media**.

Step 73 On the VoIP Media Settings page, enter the following settings.

Table 32: VoIP Media Settings Page Settings

Field	Settings
Audio	
Audio Compression	Select the preferred codec for audio compression.
RTP Digit Relay Mode	Select RFC2833 .
RTP Fax/Modem Tone Relay Mode	Select RFC2833 .
RTP Source IP Address Validation	Select Off .
RTP Source UDP Port Validation	Select Off .
Signaling Digit Relay Mode	Select Off .
Voice Activity Detection	Select Off .
RFC 3960 Early Media Support	Select On Demand .
Frame Size	Select the applicable setting: <ul style="list-style-type: none"> • G.711—20 • G.729AB—10 <p>Failure to use the correct setting results in recorded messages containing nothing but silence.</p>

Field	Settings
Frames Per Packet	Select the applicable setting: <ul style="list-style-type: none"> • G.711—1 • G.729AB—2 Failure to use the correct setting results in recorded messages containing nothing but silence.
Fax	
Fax IP-Transport Mode	
SRTP	
SRTP Preference	Select RTP Only .
MKI on Transmit Stream	Select Yes .
Key Derivation Enable	Select Yes .
Key Derivation Rate	Enter 16 .
Anti-replay Window Size Hint	Enter 64 .
Cipher Mode	Select AES_Counter_Mode .
Authentication Type	Select SHA1 .
Authentication Tag Length	Select SHA1_80_bit .

Step 74 Select **Submit**.

Step 75 On the Configuration menu, select **VoIP > QOS**.

Step 76 On the VoIP QOS Configuration page, enter the following settings.

Table 33: VoIP QOS Configurative Page Settings

Field	Settings
Call Control QOS Byte	Enter 104 .
RTP QOS Byte	Enter 184 .

- Step 77** Select **Submit**.
- Step 78** On the Configuration menu, select **IP**.
- Step 79** On the IP Settings page, enter the following settings.

Table 34: IP Settings Page Settings

Field	Settings
Client IP Address	Enter the new IP address you want to use for the PIMG unit. (This is the IP address that you enter in Cisco Unity Connection Administration when you create the integration.)
Client Subnet Mask	Enter the new subnet mask, if the subnet mask is different from the default IP address.
Default Network Gateway Address	Enter the IP address of the default network gateway router that the PIMG units use.
BOOTP Enabled	Select No .
SNTP Server IP Address	

- Step 80** Select **Submit**.
- Step 81** On the Configuration menu, select **Tone Detection**.
- Step 82** On the Tone Detection page, under Call Progress Tone - Learn, in the Learn Tone Event field, select **Busy** and do the following substeps to verify that the tone is correct.
- From a available phone, call a second phone.
 - Answer the second phone when it rings, and leave both handsets off so that both phones are busy.
 - From a third phone, dial one of the busy phones.
 - Confirm that you hear a busy tone.
 - Hang up the third phone but leave the handsets for the other two phones off.
- Step 83** Under Call Progress Tone - Learn, in the Dial String field, enter the extension that you dialed in [Step 82c](#). from the third phone.
- Step 84** Select **Learn**.
- Step 85** On the Tone Detection page, under Call Progress Tone - Learn, in the Learn field, select **Error** and do the following substeps to verify that the tone is correct.
- From an available phone, dial an extension that does not exist.
 - Confirm that you hear the reorder or error tone.
 - Hang up the phone.
- Step 86** Under Call Progress Tone - Learn, in the Dial String field, enter the extension that you dialed in [Step 85a](#).
- Step 87** Select **Learn**.
- Step 88** On the Tone Detection page, under Call Progress Tone - Learn, in the Learn field, select **Ringback** and do the following substeps to verify that the tone is correct.
- From an available phone, dial an extension that does exist

- b) Confirm that you hear the ringback tone.
- c) Hang up the phone.

- Step 89** Under Call Progress Tone - Learn, in the Dial String field, enter the extension that you dialed in [Step 88a](#).
- Step 90** Select **Learn**.
- Step 91** Select **Submit**.
- Step 92** Hang up the phones that you used in [Step 82](#).
- Step 93** On the System menu, select **Restart**.
- Step 94** On the Restart page, select **Restart Unit Now**.
- Step 95** Repeat [Step 2](#) through [Step 94](#) on all remaining PIMG units.

Configuring Unity Connection for Integration with Nortel Meridian 1 Phone System

After ensuring that the Nortel Meridian 1 phone system, the PIMG units, and Unity Connection are ready for the integration, do the following procedure to set up the integration and to enter the port settings.

Creating an Integration

- Step 1** In Cisco Unity Connection Administration, expand **Telephony Integrations**, then select **Phone System**.
- Step 2** On the Search Phone Systems page, under Display Name, select the name of the default phone system.
- Step 3** On the Phone System Basics page, in the Phone System Name field, enter the descriptive name that you want for the phone system.
- Step 4** If you want to use this phone system as the default for TRaP connections so that administrators and users without voicemail boxes can record and playback through the phone in Unity Connection web applications, check the **Default TRAP Switch** check box. If you want to use another phone system as the default for TRaP connections, uncheck this check box.
- Step 5** Under Message Waiting Indicator Settings, select **Use Same Port for Enabling and Disabling MWIs**.
- Step 6** Select **Save**.
- Step 7** On the Phone System Basics page, in the Related Links drop-down box, select **Add Port Group** and select **Go**.
- Step 8** On the New Port Group page, enter the applicable settings and select **Save**.

Table 35: Settings for the New Port Group Page

Field	Setting
Phone System	Select the name of the phone system that you entered in Step 3 .
Create From	Select Port Group Template and select SIP to DMG/PIMG/TIMG in the drop-down box.

Field	Setting
Display Name	Enter a descriptive name for the port group. You can accept the default name or enter the name that you want.
SIP Security Profile	Select 5060 .
SIP Transport Protocol	Select the SIP transport protocol that Unity Connection uses.
IP Address or Host Name	Enter the IP address of the PIMG unit that you are integrating with Unity Connection.
Port	Enter the SIP port of the PIMG unit that Unity Connection connects to. We recommend that you use the default setting. This name must match the setting in the TCP/UDP Server Port field on the Configuration > VoIP > General page of the PIMG unit. Otherwise, the integration cannot function correctly.

Step 9 On the Port Group Basics page, under Message Waiting Indicator Settings, uncheck the **Enable Message Waiting Indicators** check box and select **Save**.

Step 10 In the Related Links drop-down box, select **Add Ports** and select **Go**.

Step 11 On the New Port page, enter the following settings and select **Save**.

Table 36: Settings for the New Port Page

Field	Considerations
Enabled	Check this check box.
Number of Ports	Enter 8 . (If you want to use fewer than eight voice messaging ports, enter the number of voice messaging ports that you want to use on this PIMG unit.) Note For a Unity Connection cluster, the server must have the number of voice messaging ports that are set up on the phone system for the PIMG integration so that this server can handle all voice messaging traffic for the cluster if one of the servers stops functioning. For example, if the phone system is set up with 16 voice messaging ports, this server must have 16 voice messaging ports.
Phone System	Select the name of the phone system that you entered in Step 3 .
Port Group	Select the name of the port group that you added in Step 8 .

Step 12 On the Search Ports page, select the display name of the first voice messaging port that you created for this phone system integration.

Note By default, the display names for the voice messaging ports are composed of the port group display name followed by incrementing numbers.

- Step 13** On the Port Basics page, set the voice messaging port settings as applicable. The fields in the following table are the ones that you can change.

Table 37: Settings for the Voice Messaging Ports

Field	Considerations
Enabled	Check this check box to enable the port. The port is enabled during normal operation. Uncheck this check box to disable the port. When the port is disabled, calls to the port get a ringing tone but are not answered. Typically, the port is disabled only by the installer during testing.
Extension	Enter the extension for the port as assigned on the phone system.
Answer Calls	Check this check box to designate the port for answering calls. These calls can be incoming calls from unidentified callers or from users.
Perform Message Notification	Check this check box to designate the port for notifying users of messages. Assign Perform Message Notification to the least busy ports.
Send MWI Requests	(Serial integrations only) Uncheck this check box. Otherwise, the integration may not function correctly. (Digital and analog integrations only) Check this check box to designate the port for turning MWIs on and off. Assign Send MWI Requests to the least busy ports
Allow TRAP Connections	Check this check box so that users can use the port for recording and playback through the phone in Unity Connection web applications. Assign Allow TRAP Connections to the least busy ports.
Outgoing Hunt Order	Enter the priority order in which Unity Connection uses the ports when dialing out (for example, if the Perform Message Notification, Send MWI Requests, or Allow TRAP Connections check box is checked). The highest numbers are used first. However, when multiple ports have the same Outgoing Hunt Order number, Unity Connection uses the port that has been idle the longest.

- Step 14** Select **Save**.

- Step 15** Select **Next**.

- Step 16** Repeat [Step 13](#) through [Step 15](#) for all remaining voice messaging ports for the phone system.

- Step 17** In Cisco Unity Connection Administration, expand **Telephony Integrations**, then select **Phone System**.

- Step 18** On the Search Phone Systems page, under Display Name, select the name of the phone system that you entered in [Step 3](#).

- Step 19** Repeat [Step 7](#) through [Step 18](#) for each remaining PIMG unit integrated with Unity Connection.

Note Each PIMG unit is connected to one port group with the applicable voice messaging ports. For example, a system that uses five PIMG units requires five port groups, one port group for each PIMG unit.

- Step 20** To create a port group for MWIs, do the following substeps.

Note All MWI requests are handled by the master PIMG unit and sent to the phone system over the RS-232 serial cable (without using voice messaging ports). So the following substeps create a separate port group without voice messaging ports and enable the port group for MWIs that are "not port specific" (they do not use ports).

- a) In Cisco Unity Connection Administration expand **Telephony Integration** then select **Port Group** .
- b) On the Search Port Groups page, select **Add New**.
- c) On the New Port Group page, enter the applicable settings and select **Save**.

Table 38: Settings for the New Port Group Page (MWIs)

Field	Setting
Phone System	Select the name of the phone system that you entered in Step 3.
Create From	Select Port Group Template and select SIP to DMG/PIMG/TIMG SIP to in the drop-down box.
Display Name	Enter a MWI Port Group or another descriptive name for the port group.
SIP Security Profile	Select 5060 .
SIP Transport Protocol	Select the SIP transport protocol that Unity Connection uses.
IPv4 Address or Host Name	Enter the IP address of the master PIMG unit.
IPv6 Address or Host Name	Do not enter a value in this field. IPv6 is not supported for PIMG integrations.
IP Address or Host Name	Enter the IP address of the master PIMG unit.
Port	Enter the SIP port of the master PIMG unit. Caution This name must match the setting in the TCP/UDP Server Port field on the Configuration > VoIP > General page of the PIMG unit. Otherwise, the integration cannot function correctly.

- d) On the Port Group Basics page, on the Edit menu, select **Advanced Settings**.
- e) On the Edit Advanced Settings page, under SIP MWI Requests, select **Not Port Specific** then select **Save**.
- f) On the Edit menu, select **Port Group Basics**.
- g) Under Port Group, select **Reset**.
- h) Under Message Waiting Indicator Settings, confirm that the **Enable Message Waiting Indicator** check box is checked and select **Save**.

Step 21 If another phone system integration exists, in Cisco Unity Connection Administration, expand **Telephony Integrations**, then select **Trunk**. Otherwise, skip to [Step 25](#).

Step 22 On the Search Phone System Trunks page, on the Phone System Trunk menu, select **New Phone System Trunk**.

Step 23 On the New Phone System Trunk page, enter the following settings for the phone system trunk and select **Save**.

Table 39: Settings for the Phone System Trunk

Field	Setting
From Phone System	Enter the display name of the phone system that you are creating a trunk for.

Field	Setting
To Phone System	Enter the display name of the previously existing phone system that the trunk connects to.
Trunk Access Code	Enter the extra digits that Unity Connection must dial to transfer calls through the gateway to extensions on the previously existing phone system.

Step 24 Repeat [Step 22](#) and [Step 23](#) for all remaining phone system trunks that you want to create.

Step 25 In the Related Links drop-down list, select **Check Telephony Configuration** and select **Go** to confirm the phone system integration settings.

If the test is not successful, the Task Execution Results displays one or more messages with troubleshooting steps. After correcting the problems, test the connection again.

Step 26 In the Task Execution Results window, select **Close**.
