



Configure Service Parameters

- [Service Parameters Overview, on page 1](#)
- [Service Parameters Configuration Task Flow, on page 1](#)

Service Parameters Overview

Service parameters let you configure different services on selected Unified Communications Manager servers. Unlike enterprise parameters, which apply to all services, each service gets configured with a separate set of service parameters.

Service parameters let you configure settings for the following two types of services, both of which can be activated within Cisco Unified Serviceability:

- **Feature Services** - These services are used to run certain system features. You must turn feature services on in order to use them.
- **Network Services** - Network services are on by default, but you can stop and start (or restart) a network service for troubleshooting purposes. These services includes services that allow system components like the database and platform to function properly.

You can view service parameter field descriptions for service parameters by clicking the ? icon within the **Service Parameter Configuration** window, or by clicking on one of the parameter names.



Note If you deactivate a service, Unified Communications Manager retains any updated service parameter values. If you start the service again, Unified Communications Manager sets the service parameters to the changed values.

Service Parameters Configuration Task Flow

Procedure

	Command or Action	Purpose
Step 1	Activate Essential Services, on page 2	You can activate and deactivate services on the node using Cisco Unified Serviceability. For a

	Command or Action	Purpose
		list of the recommended services for publisher nodes, see Recommended Services for Publisher Nodes, on page 2 . For a list of the recommended services for subscriber nodes, see Recommended Services for Subscriber Nodes, on page 4 .
Step 2	Configure Service Parameters, on page 4	Configure service parameters for the Cisco Unified Communications Manager publisher node and for subscriber nodes in the cluster.
Step 3	View Clusterwide Service Parameter Settings, on page 5	You can display the services for your nodes using Cisco Unified Communications Manager Administration and Cisco Unified Serviceability. To view service parameter settings and parameter descriptions, use Cisco Unified Communications Manager Administration.

Activate Essential Services

Use this procedure to activate services across the cluster.

For a list of recommended services for publisher nodes and subscriber nodes, see the following topics:

- [Recommended Services for Publisher Nodes, on page 2](#)
- [Recommended Services for Subscriber Nodes, on page 4](#)

Procedure

Step 1 From Cisco Unified Serviceability, choose **Tools > Service Activation**.

Step 2 Select a **Server** from the drop-down menu and click **Go**.

The services and their current status display.

Step 3 Activate and deactivate the services that you want:

- To activate a service, check the check box beside the service that you want to activate.
- To deactivate a service, uncheck the check box beside the service that you want to deactivate.

Step 4 Click **Save**.

Service activation may take a few minutes to complete. refresh the page to confirm the status change.

Recommended Services for Publisher Nodes

The following table lists recommended services for a Unified Communications Manager publisher node when using a non-dedicated TFTP server.

Table 1: Recommended Publisher Node Services for Non-Dedicated TFTP Server Deployments

Type	Service Name
CM Services	Cisco CallManager
	Cisco Unified Mobile Voice Access Services
	Cisco IP Voice Media Streaming App
	Cisco CTIManager
	Cisco Extended Functions
	Cisco Intercluster Lookup Service
	Cisco Location Bandwidth Manager
	Cisco TFTP
CTI Services	Cisco IP Manager Assistant
	Cisco WebDialer Web Service
CDR Services	Cisco SOAP - CDRonDemand Service
	Cisco CAR Web Service
Database and Admin Services	Cisco Bulk Provisioning Service
	AXL Web Service
	Cisco URL Web Service
Performance and Monitoring Services	Cisco Serviceability Reporter
	Cisco Certificate Authority Proxy Function
Directory Services	Cisco DirSync



Tip You can safely disable the following services if you do not plan to use them:

- Cisco Messaging Interface
- Cisco DHCP Monitor Service
- Cisco TAPS Service
- Cisco Directory Number Alias Sync
- Cisco Directory Number Alias SyncCisco Dialed Number Analyzer Server
- Cisco Dialed Number Analyzer
- Self Provisioning IVR

Recommended Services for Subscriber Nodes

The following table lists recommended services for a Unified Communications Manager subscriber node when using a non-dedicated TFTP server.



Tip You can safely disable the other services if you don't plan to use them.

Table 2: Recommended Subscriber Node Services for Non-Dedicated TFTP Server Deployments

Type	Service Name
CM Services	Cisco CallManager
	Cisco IP Voice Media Streaming App
	Cisco CTIManager
	Cisco Extension Mobility
	Cisco Extended Functions
	Cisco TFTP

You must activate the following services on each IM and Presence Service node in your cluster.

- Cisco SIP Proxy
- Cisco Presence Engine
- Cisco XCP Connection Manager
- Cisco XCP Authentication Service

Configure Service Parameters

You can configure the service parameters on the node using Cisco Unified Communications Manager Administration. Service parameters that are marked as cluster-wide affect all nodes in the cluster.



Caution Some changes to service parameters can cause system failure. We recommend that you do not make any changes to service parameters unless you fully understand the feature that you are changing or unless the Cisco Technical Assistance Center (TAC) specifies the changes.

Before you begin

- Make sure that the Unified Communications Manager nodes are configured.
- Make sure that the service is active. For details, see [Activate Essential Services, on page 2](#).

Procedure

Step 1 From Cisco Unified CM Administration, choose **System > Service Parameters**.

Step 2 Select a node in the **Server** drop-down list.

Step 3 Select a service in the **Service** drop-down list.

Tip Click the ? icon in the **Service Parameter Configuration** window to view a list of service parameters along with their descriptions.

Step 4 Click **Advanced** to view the full list of parameters.

Step 5 Modify the service parameters and then click **Save**.

The window refreshes and the service parameter values are updated.

You can click the **Set to Default** button to update all parameters to the suggested value that appears after the **Parameter Value** field. If a parameter does not have a suggested value, the service parameter value does not change when you click the **Set to Default** button.

View Clusterwide Service Parameter Settings

You can use Cisco Unified Communications Manager Assistant and Cisco Unified Serviceability to view the status of services for nodes in your cluster. To view service parameter settings and parameter descriptions, use Cisco Unified Communications Manager Assistant.

Procedure

Step 1 To display services and view service parameter settings for a node using Cisco Unified Communications Manager Assistant, perform the following steps.

- a) Select **System > Service Parameters**.
- b) In the **Service Parameters Configuration** window, select a node in the **Server** drop-down box.
- c) Select a service in the **Service** drop-down box.

All parameters that apply to the selected node appear. Parameters that appear in the **Clusterwide Parameters (General)** section apply to all nodes in the cluster.

- d) Click the (?) icon in the **Service Parameter Configuration** window to view a list of service parameters along with their descriptions.

Step 2 To display the service parameters for a particular service on all nodes in a cluster, select **Parameters for All Servers** in the **Related Links** drop-down box in the **Service Parameters Configuration** window, then click **Go**.

The **Parameters for All Servers** window appears. You can click on a server name that is listed or on a parameter value to open the related **Service Parameter Configuration** window.

Step 3 To display out-of-sync service parameters for a particular service on all nodes in a cluster, select **Out of Sync Parameters for All Servers** in the **Related Links** drop-down box in the **Parameters for All Servers** window, then click **Go**.

The **Out of Sync Parameters for All Servers** window appears. You can click on a server name that is listed or on a parameter value to open the related **Service Parameter Configuration** window.
