



## VPN Feature Setup

---

This chapter provides information about the VPN feature configuration parameters.



---

**Note** The VPN menu and its options are not available in the U.S. export unrestricted version of Cisco Unified Communications Manager.

---

- [About VPN Feature Setup, on page 1](#)
- [Configure VPN Feature Parameters, on page 1](#)
- [VPN Feature Parameters, on page 2](#)

## About VPN Feature Setup

The **VPN Feature Configuration** window contains the common configuration settings for the VPN feature that the system uses when you do not associate a VPN Profile with a Common Phone Profile. If you define a VPN Profile as part of configuring a Common Phone Profile, the VPN Profile settings take precedence over the VPN Feature Configuration settings.

## Configure VPN Feature Parameters

### Procedure

---

- Step 1** From Cisco Unified CM Administration, choose **Advanced Features > VPN > VPN Feature Configuration**.
- Step 2** Configure the fields in the **VPN Feature Configuration** window. For more information, see [VPN Feature Parameters, on page 2](#).
- Step 3** Click **Save**.
- 

### What to do next

Perform the following tasks:

- Upgrade the firmware for Cisco Unified IP Phones to a version that supports VPN. For more information about upgrading the firmware, see *Cisco Unified IP Phone Administration Guide* for your model.
- Using a supported , establish the VPN connection.

## VPN Feature Parameters

**Table 1: VPN Feature Parameters**

Field	Default
Enable Auto Network Detect	When True, the VPN client can only run when it detects that it is out of the corporate network. Default: False
MTU	This field specifies the maximum transmission unit: Default: 1290 bytes Minimum: 256 bytes Maximum: 1406 bytes
Keep Alive	This field specifies the rate at which the system sends the keep alive message. <b>Note</b> If it is non zero and less than the value specified in , the keep alive setting in the VPN concentrator overwrites this setting. Default: 60 seconds Minimum: 0 Maximum: 120 seconds
Fail to Connect	This field specifies the amount of time to wait for login or connect operations to complete while the system creates the VPN tunnel. Default: 30 seconds Minimum: 0 Maximum: 600 seconds
Client Authentication Method	From the drop-down list, choose the client authentication method: <ul style="list-style-type: none"> <li>• User and password</li> <li>• Password only</li> <li>• Certificate (LSC or MIC)</li> </ul> Default: User And Password

Field	Default
Enable Password Persistence	When True, a user password gets saved in the phone until either a failed login attempt occurs, a user manually clears the password, or the phone resets or loses power. Default: False
Enable Host ID Check	When True, the gateway certificate subjectAltName or CN must match the URL to which the VPN client is connected. Default: True

