



CHAPTER 12

Configuring Digest Authentication for the SIP Phone

When you enable digest authentication for a phone, Cisco Unified Communications Manager challenges all requests except keepalive messages for phones that are running SIP. Cisco Unified Communications Manager uses the digest credentials for the end user, as configured in the End User Configuration window, to validate the credentials that the phone offers.

If the phone supports extension mobility, Cisco Unified Communications Manager uses the digest credentials for the extension mobility end user, as configured in the End User Configuration window, when the extension mobility user logs in.

For additional information on how digest authentication works for phones that are running SIP, see the [“Digest Authentication” section on page 1-19](#).

For information about configuring digest authentication for non-Cisco phones that are running SIP, refer to Appendix C in the *Cisco Unified Communications Manager Administration Guide*.

This chapter contains information on the following topics:

- [SIP Phone Digest Authentication Configuration Checklist, page 12-1](#)
- [Configuring Digest Authentication Service Parameters, page 12-2](#)
- [Configuring Digest Credentials in the End User Configuration Window, page 12-3](#)
- [End User Digest Credential Configuration Settings, page 12-3](#)
- [Configuring the Digest User in the Phone Configuration Window, page 12-4](#)
- [Where to Find More Information, page 12-4](#)

SIP Phone Digest Authentication Configuration Checklist

[Table 12-1](#) describes the tasks to configure digest authentication for phones that are running SIP.

Table 12-1 SIP Phone Digest Authentication Configuration Checklist

Configuration Steps		Related Procedures and Topics
Step 1	Configure the security profiles for phones that are running SIP; make sure that you check the Enable Digest Authentication check box.	Configuring a Phone Security Profile, page 7-1

Table 12-1 SIP Phone Digest Authentication Configuration Checklist (continued)

Configuration Steps		Related Procedures and Topics
Step 2	Apply a security profile to the phone that is running SIP.	Configuring a Phone Security Profile, page 7-1
Step 3	If you want to update the default setting, configure service parameters that are related to digest authentication; for example, configure the SIP Station Realm service parameter.	Configuring Digest Authentication Service Parameters, page 12-2
Step 4	Configure the digest credentials in the End User Configuration window.	<ul style="list-style-type: none"> • Configuring Digest Credentials in the End User Configuration Window, page 12-3 • End User Digest Credential Configuration Settings, page 12-3
Step 5	Choose the Digest User in the Phone Configuration window. Choosing a digest user for these phones that are running SIP ensures that the digest credentials get included in the phone configuration file: Cisco Unified IP Phones 7970G, 7971G, 7971G-GE, 7975G, 7961G, 7961G-GE, 7962G, 7965G, 7945G, 7941G, 7941G-GE, 7942G, 7945G, and 7911G.	Configuring the Digest User in the Phone Configuration Window, page 12-4
Step 6	On Cisco Unified IP Phones 7940G or 7960G (SIP only), enter the digest credentials that you configured in the End User Configuration window.	For information on how to enter the authentication name and password on the phone, refer to the <i>Cisco Unified IP Phone Administrator Guide</i> that supports this version of Cisco Unified Communications Manager.

Configuring Digest Authentication Service Parameters

You configure the SIP Realm for challenges to phones with the service parameter SIP Station Realm. At installation, Cisco Unified Communications Manager provides a default setting, ccmsipline. For additional information on the parameter, click the question mark or the parameter name link that displays in the Service Parameter Configuration window.

To update digest authentication service parameters, for example, the SIP Realm Station parameter, perform the following procedure:

Procedure

-
- Step 1** In Cisco Unified Communications Manager Administration, choose **System > Service Parameters**.
 - Step 2** From the Server drop-down list box, choose a node where you activated the Cisco CallManager service.
 - Step 3** From the Service drop-down list box, choose the Cisco CallManager service. Verify that the word “Active” displays next to the service name.
 - Step 4** Update the **SIP Realm Station** parameter, as described in the help. To display help for the parameter, click the question mark or the parameter name link.
 - Step 5** Click **Save**.
-

Additional Information

See the [“Related Topics”](#) section on page 12-4.

Configuring Digest Credentials in the End User Configuration Window

The following procedure assumes that the end user exists in the Cisco Unified Communications Manager database. To configure digest credentials for the end user, perform the following procedure:

Procedure

-
- Step 1** Find the end user, as described in the *Cisco Unified Communications Manager Administration Guide*.
 - Step 2** After the specific End User Configuration window displays, enter the appropriate settings, as described in [Table 12-2](#).
 - Step 3** Click **Save**.
 - Step 4** To configure digest credentials for additional end users, repeat the procedure.
-

Next Steps

After you configure digest credentials in the End User Configuration window, choose the digest user for the phone by accessing the Phone Configuration window.

After you choose the digest user, enter the digest authentication credentials that you get from the End User Configuration window on the Cisco Unified IP Phone 7960G or 7940G (SIP only).

Additional Information

See the [“Related Topics”](#) section on page 12-4.

End User Digest Credential Configuration Settings

[Table 12-2](#) describes the settings for the digest credential settings in the End User Configuration window in Cisco Unified Communications Manager Administration. For related procedures, see the [“Configuring the Digest User in the Phone Configuration Window”](#) section on page 12-4.

Table 12-2 *Digest Credentials*

Setting	Description
Digest Credentials	Enter a string of alphanumeric characters.
Confirm Digest Credentials	To confirm that you entered the digest credentials correctly, enter the credentials in this field.

Configuring the Digest User in the Phone Configuration Window

To associate a digest user with a phone, perform the following procedure:

Procedure

- Step 1** Find the phone, as described in the *Cisco Unified Communications Manager Administration Guide*.
- Step 2** After the specific Phone Configuration window displays, locate the **Digest User** setting and choose the end user that you want to associate with the phone.
- Step 3** Click **Save**.
- Step 4** Click **Reset**.

After you associate the end user with the phone, save the configuration and reset the phone.

Additional Information

See the “[Related Topics](#)” section on page 12-4.

Where to Find More Information

Related Topics

- [Digest Authentication](#), page 1-19
- [Configuring a Phone Security Profile](#), page 7-1
- [SIP Phone Digest Authentication Configuration Checklist](#), page 12-1
- [Configuring Digest Authentication Service Parameters](#), page 12-2
- [Configuring Digest Credentials in the End User Configuration Window](#), page 12-3
- [End User Digest Credential Configuration Settings](#), page 12-3
- [Configuring the Digest User in the Phone Configuration Window](#), page 12-4

Related Cisco Documentation

Cisco SIP IP Phone Administrator Guide