

# Index

---

## A

- Alert tone [42](#)
- Answer button [20](#)
- answering a call [20](#)
- Assistant Console
  - accessing without assisting managers [7](#)
  - call control buttons [8](#)
  - customizing layout [14](#)
  - going offline and back online [7](#)
  - handling calls from [19](#)
  - keyboard shortcuts for [16](#)
  - launching [6](#)
  - logging in [6](#)
  - menu [8](#)
  - operating with mouse and keyboard [15](#)
  - using intercom from [16](#)
- assistant selection, understanding [39](#)
- Assistant Watch
  - for managers [40](#)
  - using Intrcpt softkey with [43](#)
- assistants
  - choosing (for managers) [39](#)
  - customizing phone ringer for [34](#)
  - default [50](#)
  - identifying (for managers) [39](#)
  - phone lines for [10](#)

## B

- blind transfer [21](#)
- buttons, identifying [8](#)

## C

- call control buttons [8, 27](#)
- call control status, monitoring [14](#)
- call filtering
  - description [44](#)
  - lists for [51](#)
  - modes [51](#)
  - with Divert All [52](#)
- call handling
  - from the Assistant Console [19](#)
  - from the assistant phone [25](#)
  - from the manager phone [38, 43](#)
  - with call control buttons [8, 27](#)
- call hold
  - putting a call on hold [20](#)
  - removing a call from hold [21](#)
- calls, how displayed [10](#)
- Cisco Unified Communications Manager Assistant, description [1](#)
- Cisco Unified IP Phone
  - assistants [25](#)
  - documentation [viii](#)

- proxy-line, for managers [38](#)
- shared-line (for managers) [37](#)
- softkeys on (assistants) [25](#)
- softkeys on (manager phones) [38](#)
- status window, on manager phones [40](#)
- conference calls, placing [22](#)
- connected status
  - changing [7](#)
  - monitoring [14](#)
- Console
  - dialing from [19](#)
- Consult Transfer button [21](#)

## D

- default assistant, assigning [50](#)
- dialing a number [19](#)
- directory
  - using [13](#)
- Directory panel [13](#)
- distinctive ringing [34](#)
- DivAll softkey
  - manager target for [50](#)
  - using [43](#)
- Divert All
  - with call filtering [52](#)
- Divert target, configuring
  - assistants [23](#)
  - managers [50](#)
- diverting a call
  - assistants [23](#)
  - for managers [38](#)
  - managers [43](#)

- DND softkey [47](#)
- Do Not Disturb feature [47](#)

## E

- ending a call [20](#)
- Exclusive filter
  - creating filter lists [51](#)
  - description [12](#)

## F

- filtering
  - description [44](#)
  - lists for [51](#)
- forwarding all calls [43](#)

## H

- Hang Up button [20](#)
- hanging up a call [20](#)
- Hold button [20](#)
- holding a call [20](#)

## I

- icons on phone
  - Divert All, on manager phones [43](#)
  - Do Not Disturb, on manager phones [47](#)
  - feature settings, on manager phones [41](#)
  - filtering, on manager phones [45](#)
- IMM DIV button
  - using [23](#)

Immediate Divert button, assistants using and configuring [23](#)

Inclusive filter

creating filter lists [51](#)

description [12](#)

intercepting a call [43](#)

intercom

using from the Assistant Console [16](#)

using on the phone (for managers) [46](#)

Intrcpt softkey, on manager phones [43](#)

## K

keyboard shortcuts [16](#)

keyboard, operating Console with [15](#)

## L

log in, assistants [6](#)

## M

Manager Configuration window

using [49](#)

Manager lines

in My Calls panel [10](#)

in My Managers panel [11](#)

manager proxy lines [10](#)

managers

configuring features for [49](#)

feature status for [11](#)

monitoring [11](#)

online status of [11](#)

menu bar, on Assistant Console [8](#)

mouse, operating Assistant Console with [15](#)  
muting phone [47](#)

My Calls panel [10](#)

My Managers panel [11](#)

## O

Offline button [7](#)

offline status

monitoring [14](#)

online help, using [vii](#)

## P

placing a call [19](#)

pop-to-top feature [14](#)

proxy-line

status window on a manager phone [3](#)

using a manager phone [38](#)

using Manager Assistant in the proxy-line mode [2](#)

## R

Redirect softkey

manager target for [50](#)

managers [43](#)

on manager phones [38](#)

Resume button [21](#)

## S

server

- connection to [14](#)
- settings [14](#)
- settings
  - administrative [14](#)
- shared-line
  - status window on a manager phone [3](#)
  - using a manager phone [37](#)
  - using Manager Assistant in the shared-line mode [2](#)
- softkeys
  - for manager phones [38](#)
- speed dials [13](#)
- status bar
  - using [14](#)
- status window
  - managers [40](#)

- sending a call (for managers) [44](#)
- sending a call to (assistants) [24](#)
- sending a call to managers [38](#)

## W

- wildcards
  - in filter lists [51](#)

## T

- TRA VM button [24](#)
- Transfer button [21](#)
- Transfer VM button [24](#)
- transferring a call [21](#)
- TrnsfVM softkey
  - managers [44](#)
  - on manager phones [38](#)

## U

- unhold [21](#)

## V

- voice mail