



Configuring SNMP Settings

- [About SNMP, on page 1](#)
- [Adding, Editing, and Deleting an SNMP Community String, on page 1](#)
- [Adding, Editing, and Removing an SNMP Trap Host, on page 2](#)
- [Enabling SNMP Traps, on page 3](#)
- [Displaying MIBs, on page 3](#)
- [Editing the SNMPv2-MIB, on page 4](#)

About SNMP

Cisco Unified SIP Proxy supports SNMP MIBs and traps for monitoring its status. Cisco Unified SIP Proxy supports the following SNMP MIBs and traps:

- CISCO-USP-MIB
- CISCO-PROCESS-MIB

Adding, Editing, and Deleting an SNMP Community String

Use this procedure to add or edit an SNMP community. Communities can either be read-only or read-write only.



Restriction

You can only define up to five read-only community strings and up to five read-write community strings.

SUMMARY STEPS

1. Choose **System > SNMP > Communities**.
2. To add an SNMP community string, do the following:
3. To edit an existing SNMP community string, do the following:
4. To remove an SNMP community string, do the following:

DETAILED STEPS

Step 1 Choose **System > SNMP > Communities**.

The system displays the SNMP Communities page.

Step 2 To add an SNMP community string, do the following:

a) In an empty space, enter the SNMP community string.

If there are no empty spaces, you must first delete another SNMP community string before you can add a new one. You can only define up to five read-only community strings and up to five read-write community strings.

b) Click **Update**.

Step 3 To edit an existing SNMP community string, do the following:

a) Go to the SNMP community string to edit and edit the name.

b) Click **Update**.

Step 4 To remove an SNMP community string, do the following:

a) Go to the SNMP community string to delete and highlight the name.

b) Click **Delete** on your keyboard.

c) Click **Update**.

Related Topics

[About SNMP](#), on page 1

Adding, Editing, and Removing an SNMP Trap Host

Configure an SNMP trap host to be notified of SNMP events. The system is configured to send all SNMP traps as they occur.



Restriction

- The hostname that you enter must be found in the DNS.
- You cannot edit the hostname after it has been entered and saved.

Before you begin

Gather the following information:

- The hostname of the SNMP trap host
- The community string of the SNMP trap host

SUMMARY STEPS

1. Choose **System > SNMP > Hosts**.
2. To add an SNMP trap host, do the following:
3. To edit an existing SNMP trap host, do the following:

4. To remove an SNMP trap host, do the following:

DETAILED STEPS

- Step 1** Choose **System > SNMP > Hosts**.
The system displays the SNMP Trap Hosts page.
- Step 2** To add an SNMP trap host, do the following:
- a) Click **Add**.
The system displays the SNMP Host Profile page.
 - b) Enter the hostname and the community string for the SNMP trap.
 - c) Click **Update**.
- Step 3** To edit an existing SNMP trap host, do the following:
- a) Click the underlined hostname of the SNMP trap host to edit.
The system displays the SNMP Host Profile page.
 - b) Edit the community string for the SNMP trap.
 - c) Click **Update**.
- Step 4** To remove an SNMP trap host, do the following:
- a) Check the check box next to the SNMP trap host.
 - b) Click **Remove**.

Related Topics

[Enabling SNMP Traps](#), on page 3

Enabling SNMP Traps

- Step 1** Choose **System > SNMP > Traps**.
The system displays the SNMP Trap page.
- Step 2** Select if you want to enable or disable SNMP traps.
Check **Select All** to select all traps available.
- Step 3** Click **Update**.
-

Displaying MIBs

Use this procedure to display a list of the MIBs for Cisco Unified SIP Proxy.

SUMMARY STEPS

1. Choose **System > SNMP > MIBs**.
2. To enable the traps for all the SNMP MIBs, check **Enable SNMP Traps** and click **Update**.

DETAILED STEPS

Step 1 Choose **System > SNMP > MIBs**.

The system displays the SNMP MIBs page.

Step 2 To enable the traps for all the SNMP MIBs, check **Enable SNMP Traps** and click **Update**.

Editing the SNMPv2-MIB



Restriction The only MIB that you can edit is the SNMPv2-MIB.

SUMMARY STEPS

1. Choose **System > SNMP > MIBs**.
2. Click the underlined name of the SNMPv2-MIB.
3. Enter or update the contact or location for the SNMPv2-MIB.
4. Click **Update**.

DETAILED STEPS

Step 1 Choose **System > SNMP > MIBs**.

The system displays the SNMP MIBs page.

Step 2 Click the underlined name of the SNMPv2-MIB.

The system displays the SNMPv2-MIB page.

Step 3 Enter or update the contact or location for the SNMPv2-MIB.

Step 4 Click **Update**.
