



Configuring Call-In Numbers

Perform the following tasks from the System Call-in Number window:

- [Viewing a List of Call-in Numbers](#)
- [Displaying or Modifying Call-in Numbers](#)
- [Adding a Call-in Number](#)
- [Using Wildcard Trigger Patterns](#)

Viewing a List of Call-in Numbers

Use this procedure to view a list of the numbers that callers dial to reach system applications, such as voice mail, the auto attendant, and the [Administration via Telephone \(AvT\)](#) system.

Step 1 Choose **System > Call-in Numbers**.

Step 2 The window shows the configured call-in numbers with the fields shown below:

- Call-in Number—Extension that the caller dials to access a system application. These numbers can also be entered when configuring the auto attendant (see [Configuring Voice-Mail Call-Handling Parameters](#)) or configuring call-handling voice-mail parameters (see [Configuring Voice-Mail Call-Handling Parameters](#)).

You can also use wildcard trigger patterns when configuring call-in numbers (see [Using Wildcard Trigger Patterns](#)).

- Application—Application reached when the call-in number is dialed. Valid values are any custom applications you have created, and the system defaults:
 - voicemail—Default voice-mail application.
 - autoattendant—Default auto attendant application.
 - promptmgmt—Default Administration via Telephone (AvT) application
 - Enabled—Shows whether the application is enabled.
 - [Maximum Sessions](#)
 - [Language](#)
-

Displaying or Modifying Call-in Numbers

Use this procedure to display or modify the numbers that callers dial to reach system applications, such as voice mail, the auto attendant, and the Administration via Telephone (AvT) system.

-
- Step 1** Choose **System > Call-in Numbers**.
- Step 2** Click the call-in number that you want to modify or view. The Call-in Number Profile window displays the following fields:
- Step 3** To modify, edit the following fields:
- Call-in Number—Extension that the caller dials to access a system application. These numbers can also be entered when configuring the auto attendant (see [Configuring Voice-Mail Call-Handling Parameters](#)) or configuring call-handling voice-mail parameters (see [Configuring Voice-Mail Call-Handling Parameters](#)).
- You can also use wildcard trigger patterns when configuring call-in numbers (see [Using Wildcard Trigger Patterns](#)).
- Application—Application reached when the call-in number is dialed. Valid values are any custom applications you have created, and the system defaults:
 - voicemail—Default voice-mail application.
 - autoattendant—Default auto attendant application.
 - promptmgmt—Default Administration via Telephone (AvT) application
 - Enabled—Shows whether the application is enabled.
 - [Maximum Sessions](#)
 - Language
- Step 4** Click **Apply**.
- Step 5** Click **Ok** to save.
-

Adding a Call-in Number

Use this procedure to add a call-in number, or a number that callers dial to reach system applications. These applications include voice mail, the auto attendant, and the Administration via Telephone (AvT) system.

-
- Step 1** Choose **System > Call-in Numbers**.
- Step 2** Click **Add**.
- Step 3** Enter the data in the following fields:
- Application—Application reached when the call-in number is dialed. Valid values are any custom applications you have created, and the system defaults:
 - voicemail—Default voice mail application.
 - autoattendant—Default auto attendant application.
 - promptmgmt—Default Administration via Telephone (AvT) application.

Table 4 **Trigger Pattern Wildcards and Special Characters (continued)**

Character	Description	Examples
-	The hyphen (-) character, used with the square brackets, denotes a range of values.	The trigger pattern 813510[0-5] matches all numbers in the range 8135100 through 8135105.
^	The circumflex (^) character, used with the square brackets, negates a range of values. Ensure that it is the first character following the opening bracket ([]. Each trigger pattern can have only one ^ character.	The trigger pattern 813510[^0-5] matches all numbers in the range 8135106 through 8135109.