



# MME SGs Service Configuration Mode Commands

---

The MME SGs Service Configuration Mode is used to create and manage the LTE Mobility Management Entity (MME) SGs services on this system. The SGs service creates an SGs interface between the MME and a Mobile Switching Center/Visitor Location Register (MSC/VLR).

## Command Modes

Exec > Global Configuration > Context Configuration > MME SGs Service Configuration

**configure** > **context** *context\_name* > **sgs-service** *service\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-sgs-service) #
```



## Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

---

- [associate, page 3](#)
- [bind, page 5](#)
- [end, page 7](#)
- [exit, page 8](#)
- [ip, page 9](#)
- [non-pool-area, page 10](#)
- [pool-area, page 12](#)
- [sctp, page 14](#)
- [tac-to-lac-mapping, page 15](#)
- [timer, page 17](#)
- [vlr, page 19](#)

- [vlr-failure](#), page 21

# associate

Associates or disassociates a Stream Control Transmission Protocol (SCTP) parameter template with the SGs service.

**Product** MME

**Privilege** Administrator

**Command Modes** Exec > Global Configuration > Context Configuration > MME SGs Service Configuration  
**configure** > **context** *context\_name* > **sgs-service** *service\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name (config-sgs-service) #
```

**Syntax Description** **associate sctp-param-template** *template\_name*  
**no associate sctp-param-template**

**no**

Removes the SCTP parameter template association.

***template\_name***

Associates an SCTP parameter template with the SGs service.

*template\_name* specifies the name for a pre-configured SCTP parameter template to associate with this SGs service as an alphanumeric string of 1 through 63 characters. For more information on the SCTP parameter template, refer to the **sctp-param-template** command in the *Global Configuration Mode Commands* chapter and the *SCTP Parameter Template Configuration Mode Commands* chapter.

**Usage Guidelines** Use this command to associate a pre-configured SCTP parameter template with the SGs service.



**Caution**

This is a critical configuration. Any change to this configuration will cause the SGs service to restart.



**Important**

If no SCTP parameter template is specified, all default settings for the configurable parameters in the SCTP Parameter Template Configuration Mode apply.

**Examples**

The following command associates a pre-configured SCTP parameter template called *sctp-3* to the SGs service:  
**associate sctp-param-template sctp-3**

# bind

Binds the service to a logical IP interface serving as the SGs interface.

## Product

MME

## Privilege

Administrator

## Command Modes

Exec > Global Configuration > Context Configuration > MME SGs Service Configuration

**configure** > **context** *context\_name* > **sgs-service** *service\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name (config-sgs-service) #
```

## Syntax Description

**bind** { **ipv4-address** *ipv4\_address* [ **ipv4-address** *ipv4\_address* ] | **ipv6-address** *ipv6\_address* [ **ipv6-address** *ipv6\_address* ] }

**no bind**

**no bind**

Removes the interface binding from this service.

**ipv4-address** *ipv4\_address* [ **ipv4-address** *ipv4\_address* ]

Specifies the IP address of the SGs interface in IPv4 dotted-decimal notation. n.

A secondary IPv4 address can be configured to support SCTP multi-homing.

**ipv6-address** *ipv6\_address* [ **ipv6-address** *ipv6\_address* ]

Specifies the IP address of the SGs interface in IPv6 colon-separated-hexadecimal notation.

A secondary IPv6 address can be configured to support SCTP multi-homing.

## Usage Guidelines

Associate the SGs service to a specific logical IP address. The logical IP address or interface takes on the characteristics of an SGs interface that provides the session connectivity for circuit switched fallback (CSFB) to/from a Mobile Switching Center/Visitor Location Register (MSC/VLR). Only one interface can be bound to a service. The interface should be configured prior to issuing this command

**Caution**

---

This is a critical configuration. Any change to this configuration will cause the SGs service to restart. Removing or disabling this configuration will stop the SGs service.

---

**Examples**

The following command binds the logical IP interface with the IPv4 address of *192.68.10.22* to the SGs service:

```
bind ipv4-address 192.68.10.22
```

# end

Exits the current configuration mode and returns to the Exec mode.

**Product** All

**Privilege** Security Administrator, Administrator

**Syntax Description** end

**Usage Guidelines** Use this command to return to the Exec mode.

# exit

Exits the current mode and returns to the parent configuration mode.

**Product** All

**Privilege** Security Administrator, Administrator

**Syntax Description** exit

**Usage Guidelines** Use this command to return to the parent configuration mode.

# ip

This command configures the IP parameters on the SGs interface.

## Product

MME

## Privilege

Security Administrator, Administrator

## Command Modes

Exec > Global Configuration > Context Configuration > MME SGs Service Configuration

**configure** > **context** *context\_name* > **sgs-service** *service\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name (config-sgs-service) #
```

## Syntax Description

[ **no** ] **ip qos-dscp** *dscp\_value*

**no**

Removes IP parameter configuration from the SGs service/interface.

**qos-dscp** *dscp\_value*

The **qos-dscp** keyword designates the Quality of Service - Differentiated Services Code Point value to the packet leaving through the SGs interface.

*dscp\_value* is a value assigned to the packet for DSCP marking. The value can be a pre-defined DSCP value or an arbitrary value ranging from 0x01 to 0x3F.

## Usage Guidelines

SGs interface allows Differentiated Services Code Point (DSCP) marking functionality. DSCP marking helps in packet traffic management. DSCP marking can be performed on both IPv4 and IPv6 packets leaving the SGs interface.

Either the pre-defined DSCP values can be used for marking, or any arbitrary value ranging from 0x01 to 0x3F can be assigned. The default DSCP value is 0x00 or be (Best Effort). The default DSCP value is automatically set when the configuration is disabled.

## Examples

The following command shows the IP configuration for DSCP marking on the SGs service.

**ip qos-dscp ef**

## non-pool-area

Configures a non-pool area where a group of Location Area Code (LAC) values use a specific visitor Location Register (VLR).

**Product** MME

**Privilege** Administrator

**Command Modes** Exec > Global Configuration > Context Configuration > MME SGs Service Configuration

**configure** > **context** *context\_name* > **sgs-service** *service\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-sgs-service)#
```

**Syntax Description** **non-pool-area** *name* **use-vlr** *vlr\_name* [ **lac** *value(s)* ] [ **plmnid** { **any** | **mcc** *mcc\_value* **mnc** *mnc\_value* } ]  
**no non-pool-area** *name* [ **lac** *value(s)* ]

**no non-pool-area** *name* [ **lac** *value(s)* ]

Removes the configured non-pool-area from this service. Optionally, removes a specific LAC or LACs from this non-pool area. *name* is the name of an existing non-pool-area expressed as an alphanumeric string of 1 through 63 characters. *value(s)* is an existing LAC integer value from 1 through 65535.

***name***

Specifies the name of the non-pool area as an alphanumeric string of 1 through 63 characters.

**use-vlr** *vlr\_name*

Specifies the VLR to be used in this non-pool area configuration as an alphanumeric string of 1 through 63 characters.

**lac** *value(s)*

Specifies the location area code or codes to be used with the configured VLR in this non-pool area configuration. *value(s)* is an integer(s) from 1 through 65535.

In Release 12.2 and later, a maximum of 96 areas can be added per non pool area (in a single line, or separately). In older releases, a total of 16 area codes can be added (in a single line, or separately).

**plmnid** { **any** | **mcc** *mcc\_value* **mnc** *mnc\_value* }

Specifies the Public Land Mobile Network (PLMN) identifier to be used with the VLR in this non-pool area configuration.

**any**: Specifies that any PLMN ID can be used with the VLR in this configuration.

**mcc** *mcc\_value* **mnc** *mnc\_value*: Specifies the mobile country code (MCC) and mobile network code (MNC) of the PLMN identifier. *mcc\_value* must be an integer from 101 through 998. *mnc\_value* must be a 2- or 3-digit integer from 00 through 998.

### Usage Guidelines

Use this command to configure a non-pool area where LAC values and/or PLMN IDs are associated with a specific VLR.

In Release 12.2 and later, a maximum of 48 combined non pool areas and pool areas can be created. In older releases, a maximum of 8 combined non pool areas and pool areas can be created.

### Examples

The following command creates a non-pool area named *svlr1* associated with a VLR named *vlr1* and containing LAC values of 1, 2, 3, 4, 5, 6, 7, and 8:

```
non-pool-area svlr1 use-vlr vlr1 lac 1 2 3 4 5 6 7 8
```

# pool-area

Creates a location area code (LAC) pool area configuration or specifies an existing pool area and enters the LAC Pool Area Configuration Mode.

**Product** MME

**Privilege** Administrator

**Command Modes** Exec > Global Configuration > Context Configuration > MME SGs Service Configuration  
**configure** > **context** *context\_name* > **sgs-service** *service\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-sgs-service)#
```

**Syntax Description** [ **no** ] **pool-area** *pool\_name* [ **-noconfirm** ]

**no**

Removes the selected pool area configuration from the SGs service.

***pool\_name***

Specifies the name of the LAC pool area configuration. If *pool\_name* does not refer to an existing pool, a new pool is created. *pool\_name* must be an alphanumeric string of 1 through 64 characters.

## Usage Guidelines

Use this command to enter the LAC Pool Area Configuration Mode for an existing pool area configuration or for a newly defined pool area configuration. This command is also used to remove an existing pool area configuration.

In Release 12.2 and later, a maximum of 48 combined pool areas and non pool areas can be created. In older releases, a maximum of 8 combined pool areas and non pool areas can be created.

Entering this command results in the following prompt:

```
[context_name]hostname(config-sgs-pool-area)#
```

LAC Pool Area Configuration Mode commands are defined in the *MME LAC Pool Area Configuration Mode Commands* chapter.

**Examples**

The following command enters the LAC Pool Area Configuration Mode for a new or existing pool area configuration named *pool1*:

```
pool-area pool1
```

# sctp

Configures the Stream Control Transmission Protocol (SCTP) port number for this service.

## Product

MME

## Privilege

Administrator

## Command Modes

Exec > Global Configuration > Context Configuration > MME SGs Service Configuration

**configure** > **context** *context\_name* > **sgs-service** *service\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-sgs-service)#
```

## Syntax Description

**sctp port** *port\_number*

**no sctp**

**no**

Removes the SCTP configuration for this service.

**port** *port\_number*

Specifies the SCTP port number used to communicate with the MSC/VLR using the SGs interface as an integer from 1 through 65535.

## Usage Guidelines

Use this command to assign the SCTP port with SCTP socket to communicate with the MSC/VLR through the SGs interface. A maximum of one SCTP port can be associated with one SGs service.

## Examples

The following command sets the SCTP port to *29118* for this service:

**sctp port 29118**

# tac-to-lac-mapping

Maps any Tracking Area Code (TAC) value or a specific TAC value to a LAC value.

## Product

MME

## Privilege

Administrator

## Command Modes

Exec > Global Configuration > Context Configuration > MME SGs Service Configuration

**configure** > **context** *context\_name* > **sgs-service** *service\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name (config-sgs-service) #
```

## Syntax Description

**tac-to-lac-mapping** { **any-tac** | **tac** *value* } **map-to lac** *value* +  
**no tac-to-lac-mapping** { **any-tac** | { **tac** *value* } + }

**any-tac** | **tac** *value*

Specifies the TAC to map to the LAC.

**any-tac**: Specifies that any TAC value is to be mapped to the specified LAC.

**tac** *value*: Maps a specific TAC value to a LAC value expressed as an integer from 1 through 65535. For specific TAC values, multiple mappings can be entered on the same line (see Example).

**map-to lac** *value*

Specifies the LAC value that the selected TAC value, or any TAC value is mapped as an integer from 1 through 65535. For specific TAC values, multiple mappings can be entered on the same line (see Example).

For releases 19 and higher, the number of TAC to LAC mappings are increased from 512 to 1024 entries.

## Usage Guidelines

Use this command to map TAC values to LAC values.

Enter up to 8 mappings per line.

In Release 12.2 and later, a maximum of 64 mapping lists can be created. In older releases, a maximum of 32 mapping lists can be created.

If no mapping is entered, the default behavior is TAC equals LAC.

**Examples**

The following command maps a TAC value of 2 to a LAC value of 3, a TAC value of 4 to a LAC value of 5, and a TAC value of 6 to a LAC value of 7:

```
tac-to-lac-mapping tac 2 map-to lac 3 tac 4 map-to lac 5 tac 6 map-to lac 7
```

# timer

Configures the SGs-AP timer values.

## Product

MME

## Privilege

Administrator

## Command Modes

Exec > Global Configuration > Context Configuration > MME SGs Service Configuration

**configure** > **context** *context\_name* > **sgs-service** *service\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name (config-sgs-service) #
```

## Syntax Description

**timer** { *ts6-1 value* | *ts10 value* | *ts12-1 value* | *ts12-2 value* | *ts13 value* | *ts8 value* | *ts9 value* }  
**default timer** { *ts10* | *ts12-1* | *ts12-2* | *ts13* | *ts6-1* | *ts8* | *ts9* }

**default timer** { *ts10* | *ts12-1* | *ts12-2* | *ts13* | *ts6-1* | *ts8* | *ts9* }

Returns the timer to its default setting.

### **ts10 value**

Specifies the Ts10 timer value (in seconds) as an integer from 1 through 30. This timer is used to guard the Implicit IMSI detach from non-EPS services procedure.

Default: 4.

### **ts12-1 value**

Specifies the Ts12-1 timer value (in seconds) as an integer from 8 through 23048. This timer is used to control the reset of the 'MME-Reset' variable. It is expected to take a value greater than the longest periodic tracking area update timer running on the MME, plus the transmission delay on the radio interface.

Default: 36000.

### **ts12-2 value**

Specifies the Ts12-2 timer value (in seconds) as an integer from 1 through 120. This timer is used to guard the MME reset procedure. There is one Ts12-2 timer per VLR for which the MME has an SGs association.

Default: 4.

**ts13 value**

Specifies the Ts13 timer value (in seconds) as an integer from 1 through 30. This timer configures the retransmission interval for sending SGs message SGsAP-EPS-DETACH-INDICATION to MSC/VLR due to an Implicit IMSI detach from EPS services. If no SGsAP-EPS-DETACH-ACK is received, the MME will resend SGsAP-EPS-DETACH-INDICATION message upon expiry of this timer.

Default: 4.

**ts6-1 value**

Specifies the Ts6-1 timer value (in seconds) as an integer from 10 through 90. This timer is used to guard the Location Update procedure. It is expected to take a value greater than 2 times the maximum transmission time in the SGs interface, plus the supervision timer of the Update Location procedure (as defined in 3GPP TS 29.002 [15]).

Default: 15.

**ts8 value**

Specifies the Ts8 timer value (in seconds) as an integer from 1 through 30. This timer is used to guard the Explicit IMSI detach from EPS services procedure.

Default: 4.

**ts9 value**

Specifies the Ts9 timer value (in seconds) as an integer from 1 through 30. This timer guards the Explicit IMSI detach from non-EPS services procedure.

Default: 4.

**Usage Guidelines**

Use this command to configure the SGs-AP timers.

**Examples**

The following command sets the SGs-AP Ts6-1 timer to 20 seconds:

**timer ts6-1 20**

# vlr

Configures the Visitor Location Register (VLR) to be used by this service.

## Product

MME

## Privilege

Administrator

## Command Modes

Exec > Global Configuration > Context Configuration > MME SGs Service Configuration

**configure** > **context** *context\_name* > **sgs-service** *service\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-sgs-service)#
```

## Syntax Description

**vlr** *vlr\_name* { **ipv4-address** *ipv4\_address* [ **ipv4-address** *ipv4\_address* ] | **ipv6-address** *ipv6\_address* [ **ipv6-address** *ipv6\_address* ] } **port** *port\_number*  
**no vlr** *vlr\_name*

**no**

Removes the configured VLR from this service.

*vlr\_name*

Specifies the name of the VLR as an alphanumeric string of 1 through 63 characters.

**ipv4-address** *ipv4\_address* [ **ipv4-address** *ipv4\_address* ]

Specifies the IP address of the VLR in IPv4 dotted-decimal notation.

A secondary IPv4 address can be configured to support SCTP multi-homing.

**ipv6-address** *ipv6\_address* [ **ipv6-address** *ipv6\_address* ]

Specifies the IPv6 address of the VLR. *ipv6\_address* must be entered in colon-separated-hexadecimal notation.

A secondary IPv6 address can be configured to support SCTP multi-homing.

**port** *port\_number*

Specifies the SCTP port number as an integer from 1 through 65535.

## Usage Guidelines

Use this command to configure the VLR used by this SGs service.

In Release 12.2 and later, a maximum of 48 separate VLRs can be created. In older releases, a maximum of 32 separate VLRs can be created.

Each individual VLR can be defined with up to 10 separate associations to a single MSS pool. Each of these associations support SCTP multi-homing by defining a primary/secondary IP address. Application layer messages are transmitted to the first available association for a particular VLR. If a complete failure of the underlying SCTP layer for a given association (for example, both SCTP paths in a multi-homed configuration) occurs, the VLR association is removed as a candidate for application message transmission until it recovers. A given MMS (VLR) will remain available as long as at least one related association remains available.

### Examples

The following command configures a VLR to be used by this service with a name of *vlr1*, with an SCTP multi-homed primary IPv4 address of *10.2.3.4*, a secondary IPv4 address of *10.2.10.1*, and a port number of *29118*:

```
vlr vlr1 ipv4-address 10.2.3.4 ipv4-address 10.2.10.1 port 29118
```

# vlr-failure

Configures automatic VLR failure handling for the SGs service

## Product

MME

## Privilege

Administrator

## Command Modes

Exec > Global Configuration > Context Configuration > MME SGs Service Configuration

**configure** > **context** *context\_name* > **sgs-service** *service\_name*

Entering the above command sequence results in the following prompt:

```
[context_name]host_name (config-sgs-service) #
```

## Syntax Description

[ **no** ] **vlr-failure** **duration** *minutes* **backoff-timer** *seconds* **detach-rate** *number* [ **-noconfirm** ]

### **no**

Removes the configuration from this service, which disables automatic detection and offload of VLRs when an SGs association failure occurs.

### **duration** *minutes*

Specifies the amount of time in minutes during which all qualifying UEs will be detached.

The MME splits this duration into *n* intervals, 5 seconds apart. For example, a setting of 2 minutes with 100 subscribers would result in the MME processing all subscribers in the first 2 intervals (10) seconds. Any subscribers remaining at the expiry of the duration will not be processed.

If no detach rate is defined using the **detach-rate** keyword, a maximum of 50 subscribers are processed per interval. Any remaining UEs will remain attached until detached by other means (UE/network detach, etc).

*minutes* must be an integer from 1 through 3000.

### **backoff-timer** *seconds*

Specifies the period of time the MME will wait following the detection of a VLR condition before starting the controlled release of affected UEs. The MME begins offloading UEs following the expiry of this backoff timer. If the VLR has recovered before the backoff timer expires, no offloading is performed.

*seconds* must be an integer from 1 to 3000.

**detach-rate *number***

This optional keyword specifies a maximum number of detaches to perform per 5 second cycle.

For example, if 12,000 subscribers are to be detached during a 5 minute window (duration = 5 minutes), the MME calculates 60 cycles (5 minutes / 5-second cycles) which results in 200 UEs to detach per cycle.

If the detach-rate is configured to 100, the MME will only detach 100 per 5 second cycle for, resulting in a total of 6000 detaches. Any remaining UEs will remain attached until detached by other means (UE/network detach, etc).

*number* must be an integer from 1 to 2000.

**Usage Guidelines**

This command requires that a valid MME Resiliency license key be installed. Contact your Cisco Account or Support representative for information on how to obtain a license.

This command configures the MME to automatically initiate the VLR offload feature when a SGs association failure is detected.

This command provides equivalent functionality to the **sgs vlr-failure** Exec Mode command. The differences are that the Exec Mode command must be applied manually, while this Config Mode command is applied automatically when a failure condition is detected.

Both commands cannot be enabled simultaneously. An error message is reported to the operator if this is attempted.

**Examples**

The following command enables automatic SGs failure handling functionality. After detecting an SGs association failure, the MME will wait 180 seconds before starting to detach UEs over a 60 minute window, without exceeding a detachment rate of 100 UEs per 5-second cycle.

**vlr-failure duration 60 backoff-timer 180 detach-rate 100**