



# Network Service Virtual Link Configuration Mode Commands

## Command Modes

The Network Service Virtual Link configuration mode is a sub-mode of the Network Service Entity - IP configuration mode. This sub-mode provides the commands and parameters to define the NSVL of the Gb interface between a BSS and an SGSN in a 2.5G GPRS IP network connection.

Exec > Global Configuration > Network Service Entity - IP Configuration > NSVL Configuration

**configure** > **network-service-entity ip** > **nsvl instance** *nsvl\_id*

Entering the above command sequence results in the following prompt:

```
[local]host_name(nse-ip-local-nsvl-nsvl_instance)#
```



## Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

- [do show, on page 1](#)
- [end, on page 2](#)
- [exit, on page 2](#)
- [nsvl-address, on page 2](#)
- [weight, on page 3](#)

## do show

Executes all **show** commands while in Configuration mode.

## Product

All

## Privilege

Security Administrator, Administrator

## Syntax Description

**do show**

## Usage Guidelines

Use this command to run all Exec mode **show** commands while in Configuration mode. It is not necessary to exit the Config mode to run a **show** command.

**end**

The pipe character | is only available if the command is valid in the Exec mode.

**Caution**

There are some Exec mode **show** commands which are too resource intensive to run from Config mode. These include: **do show support collection**, **do show support details**, **do show support record** and **do show support summary**. If there is a restriction on a specific **show** command, the following error message is displayed:

```
Failure: Cannot execute 'do show support' command from Config mode.
```

## end

Exits the current configuration mode and returns to the Exec mode.

**Product**

SGSN

**Privilege**

Security Administrator, Administrator

**Syntax Description****end****Usage Guidelines**

Return to the Exec mode.

## exit

Exits the current configuration mode and returns to the previous configuration mode.

**Product**

SGSN

**Privilege**

Security Administrator, Administrator

**Syntax Description****exit****Usage Guidelines**

Return to the network service entity - IP configuration mode. mode.

## nsvl-address

This command configures the IP address of the NSVL. end-point.

**Product**

SGSN

**Privilege**

Security Administrator, Administrator

**Command Modes**

Exec > Global Configuration > Network Service Entity - IP Configuration > NSVL Configuration  
**configure > network-service-entity ip > nsvl instance** *nsvl\_id*

Entering the above command sequence results in the following prompt:

```
[local]host_name(nse-ip-local-nsvl-nsvl_instance)#
```

---

**Syntax Description** `nsvl-address ip-address ip_address context ctxt_name port port_num`

**ip-address ip\_address**

Identifies the address of the NSVL.

*ip\_address*: Must be specified using the standard IPv4 dotted decimal notation or colon notation for IPv6.

**context ctxt\_name**

Identifies the specific context associated with this NSVL address.

*ctxt\_name*: Enter up to 79 alphanumeric characters.

**port port\_num**

Specifies the UDP port to associate with the NSVL end-point.

*port\_num*: Must be an integer from 1 to 65535.

---

**Usage Guidelines** Use this command to configure the IP address, context name and port number for the NSVL end-point.

**Example**

```
nsvl-address ip-address 1.1.1.1 context sgsn2 port 3735
```

## weight

This command configures the signaling or data weight for NSVL.

---

**Product** SGSN

---

**Privilege** Security Administrator, Administrator

---

**Command Modes** Exec > Global Configuration > Network Service Entity - IP Configuration > NSVL Configuration

**configure > network-service-entity ip > nsvl instance nsvl\_id**

Entering the above command sequence results in the following prompt:

```
[local]host_name(nse-ip-local-nsvl-nsvl_instance)#
```

---

**Syntax Description** `weight { data data_weight | signaling signaling_weight }`

**data data\_weight**

Defines the data weight for the NSVL.

*data\_weight*: Must be an integer from 0 to 255. Default is 1.

**signaling *signaling\_weight***

Defines the signaling weight for the NSVL.

*signaling\_weight*: Must be an integer from 0 to 255. Default is 1.

---

**Usage Guidelines**

Configure the weight of the signaling or data for the NSVL.

**Example**

```
weight data 234
```