



# IPNE Endpoint Configuration Mode Commands

## Command Modes

The IPNE Endpoint Configuration Mode provides the commands to configure the parameters for an IPNE Endpoint in an IPNE Service.

Exec > Global Configuration > Context Configuration > IPNE Service Configuration > IPNE Endpoint Configuration

**configure > context** *context\_name* > **ipne-service** *ipne\_service\_name* > **ipne-endpoint**

Entering the above command sequence results in the following prompt:

```
[ context_name]host_name (config-ipne-endpoint)#
```



## Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

- [bind, on page 1](#)
- [end, on page 2](#)
- [exit, on page 2](#)
- [peer, on page 2](#)

## bind

This command binds the IPNE client socket to the IPNE endpoint.

## Product

MME

## Privilege

Security Administrator, Administrator

## Command Modes

Exec > Global Configuration > Context Configuration > IPNE Service Configuration > IPNE Endpoint Configuration

**configure > context** *context\_name* > **ipne-service** *ipne\_service\_name* > **ipne-endpoint**

Entering the above command sequence results in the following prompt:

```
[ context_name]host_name (config-ipne-endpoint)#
```

## Syntax Description

```
[ no ] bind { ipv4-address | ipv6-address } ip_address
```

**end****no**

When included as a command prefix, the system removes the bind address from the IPNE endpoint configuration.

**ipv4-address | ipv6-address**

Identifies whether the bind address uses IPv4 or IPv6 format.

**ip\_address**

Enter either an IPv4 dotted-decimal address or an IPv6 colon-separated hexadecimal notation

**Usage Guidelines**

The **bind** command defines the IP address of the IPNE client socket as the local address.

**Example**

Use a command similar to the following to bind the IPNE client socket to the IPNE endpoint.

```
bind ipv4-address 123.123.123.1
```

**end**

Exits the current configuration mode and returns to the Exec mode.

**Product**

All

**Privilege**

Security Administrator, Administrator

**Syntax Description**

**end**

**Usage Guidelines**

Use this command to return to the Exec mode.

**exit**

Exits the current mode and returns to the parent configuration mode.

**Product**

All

**Privilege**

Security Administrator, Administrator

**Syntax Description**

**exit**

**Usage Guidelines**

Use this command to return to the parent configuration mode.

**peer**

Identifies the MINE server as a peer for the IPNE endpoint.

<b>Product</b>	MME
<b>Privilege</b>	Security Administrator, Administrator
<b>Command Modes</b>	Exec > Global Configuration > Context Configuration > IPNE Service Configuration > IPNE Endpoint Configuration  <b>configure &gt; context <i>context_name</i> &gt; ipne-service <i>ipne_service_name</i> &gt; ipne-endpoint</b>  Entering the above command sequence results in the following prompt:  [ <i>context_name</i> ] <i>host_name</i> (config-ipne-endpoint)#
<b>Syntax Description</b>	<b>[ no ] peer { ipv4-address   ipv6-address } <i>ip_address</i></b>  <b>no</b> Removes the peer address from the IPNE endpoint configuration.  <b>ipv4-address   ipv6-address</b> Informs the system of the format of the peer address.  <b><i>ip_address</i></b> Enter either an IPv4 dotted-decimal address or an IPv6 colon-separated hexadecimal notation.
<b>Usage Guidelines</b>	Use the <b>peer</b> command to configure a MINE server IP address as the peer for the IPNE endpoint.  <b>Example</b> Enter an IPv4 address for the MINE server: <b>peer ipv4-address 221.221.221.1</b>

peer