



Consolidated Platform Command Reference, Cisco IOS XE Release 3.3SE (Cisco WLC 5700 Series)

First Published: January 29, 2013

Last Modified: October 25, 2013

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Text Part Number: OL-29471-02

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2013 Cisco Systems, Inc. All rights reserved.



CONTENTS

Preface

Preface xxv

Document Conventions xxv

Related Documentation xxvii

Obtaining Documentation and Submitting a Service Request xxvii

CHAPTER 1

Using the Command-Line Interface 1

Information About Using the Command-Line Interface 1

Command Modes 1

Using the Help System 3

Understanding Abbreviated Commands 4

No and Default Forms of Commands 5

CLI Error Messages 5

Configuration Logging 5

How to Use the CLI to Configure Features 6

Configuring the Command History 6

Changing the Command History Buffer Size 6

Recalling Commands 6

Disabling the Command History Feature 7

Enabling and Disabling Editing Features 7

Editing Commands Through Keystrokes 9

Editing Command Lines That Wrap 10

Searching and Filtering Output of show and more Commands 11

Accessing the CLI Through a Console Connection or Through Telnet 12

PART I

System Management 13

CHAPTER 2

Cisco 5700 Series System Management Commands 15

arp 18
boot 19
cat 21
clear location 22
clear location statistics 23
clear nmsp statistics 24
clear wireless ccx statistics 25
clear wireless client tsm dot11 26
clear wireless location s69 statistics 27
copy 28
debug call-admission wireless all 29
debug rfid 30
debug voice diagnostics mac-address 31
debug wps mfp 32
delete 33
dir 34
emergency-install 36
exit 38
help 39
license right-to-use 40
location 42
location algorithm 46
location expiry 47
location notify-threshold 48
location plm calibrating 49
location rfid 50
location rssi-half-life 51
mac address-table control-packet-learn 52
logging smartlog 53
mgmt_init 55
mkdir 56
more 57
nmsp notification interval 58
rename 60
reset 61

rmdir	62
set	63
show avc client	66
show avc wlan	67
show cable-diagnostics tdr	69
show flow monitor	72
show license right-to-use	74
show location	76
show location ap-detect	77
show mac address-table control-packet-learn	79
show mac address-table move update	80
show nmsp	81
show tech-support wireless	83
show wireless band-select	85
show wireless client calls	86
show wireless client dot11	87
show wireless client location-calibration	88
show wireless client probing	89
show wireless client summary	90
show wireless client timers	91
show wireless client voice diagnostics	92
show wireless country	93
show wireless detail	96
show wireless dtls connections	97
show wireless flow-control	98
show wireless flow-control statistics	99
show wireless load-balancing	100
show wireless performance	101
show wireless pmk-cache	102
show wireless probe	103
show wireless sip preferred-call-no	104
show wireless summary	105
shutdown	106
system env temperature threshold yellow	107
test cable-diagnostics tdr	109

traceroute mac 110
 traceroute mac ip 113
 trapflags 115
 trapflags client 116
 type 117
 unset 118
 version 120
 wireless client 121
 wireless client mac-address deauthenticate 123
 wireless client mac-address 124
 wireless load-balancing 129
 wireless sip preferred-call-no 130

PART II
QoS 131

CHAPTER 3
QoS Commands 133

class 134
 class-map 137
 match (class-map configuration) 139
 match non-client-nrt 142
 match wlan user-priority 143
 policy-map 144
 priority 147
 queue-buffers ratio 149
 queue-limit 151
 qos wireless-default untrust 153
 service-policy (Wired) 155
 service-policy (WLAN) 157
 set 159
 show ap name service-policy 166
 show ap name dot11 167
 show class-map 170
 show wireless client calls 171
 show wireless client dot11 172
 show wireless client mac-address (Call Control) 173

show wireless client mac-address (TCLAS) 174
 show wireless client voice diagnostics 175
 show policy-map 176
 show wlan 180
 trust device 183

PART III
Interface 185

CHAPTER 4
Interface Commands 187

client vlan 189
 clear nmsp statistics 190
 debug ilpower 191
 debug interface 192
 debug lldp packets 194
 debug platform fallback-bridging 195
 duplex 197
 interface 199
 interface auto-template 201
 interface range 202
 location 203
 logging event power-inline-status 207
 show CAPWAP summary 208
 show env 209
 show errdisable detect 211
 show errdisable recovery 212
 show interfaces 213
 show interfaces counters 217
 show location 219
 show mgmt-infra trace messages ilpower-ha 221
 show network-policy profile 222
 show nmsp 223
 show platform CAPWAP summary 226
 show network-policy profile 227
 show wireless interface summary 228
 system mtu 229

wireless ap-manager interface 230
 wireless exclusionlist 231
 wireless linktest 232
 wireless management interface 233
 wireless peer-blocking forward-upstream 234

PART IV
VLAN 235

CHAPTER 5
VLAN Commands 237

client vlan 238
 clear vmps statistics 239
 clear vtp counters 240
 debug sw-vlan 241
 debug sw-vlan ifs 243
 debug sw-vlan notification 244
 debug sw-vlan vtp 246
 interface vlan 248
 remote-span 250
 show vlan 252
 show vlan filter 256
 show vlan group 257
 show vtp 258
 show wireless vlan group 264
 spanning-tree vlan 265
 wireless broadcast vlan 268
 wireless vlan group 269
 wlan 270

PART V
VideoStream 271

CHAPTER 6
VideoStream Commands 273

ap dot11 media-stream multicast-direct 274
 show ap dot11 275
 show wireless media-stream group 276
 wireless media-stream multicast-direct 277

wireless media-stream 278

PART VI**Multicast 281**

CHAPTER 7**IP Multicast Commands 283**

cache-memory-max 285

ip igmp filter 286

ip igmp max-groups 287

ip igmp profile 289

ip igmp snooping 291

ip igmp snooping last-member-query-count 292

ip igmp snooping querier 294

ip igmp snooping report-suppression 296

ip igmp snooping vlan mrouter 298

ip igmp snooping vlan static 299

ip multicast vlan 301

match message-type 302

match service-instance 303

match service-type 304

service-list mdns-sd 305

service-routing mdns-sd 307

service-policy 308

redistribute mdns-sd 309

service-policy-query 310

show ip igmp filter 311

show ip igmp profile 312

show ip igmp snooping 313

show ip igmp snooping groups 315

show ip igmp snooping igmpv2-tracking 317

show ip igmp snooping mrouter 318

show ip igmp snooping querier 319

show ip igmp snooping wireless mcast-spi-count 321

show ip igmp snooping wireless mgid 322

show mdns cache 323

show mdns requests 325

show mdns statistics 326
 show wireless multicast 327
 show wireless multicast group 328
 wireless multicast 329
 wireless mdns-bridging 330

PART VII
Security 331

CHAPTER 8
Security Commands 333

aaa accounting dot1x 336
 aaa accounting identity 338
 aaa authentication dot1x 340
 aaa authorization network 341
 authentication host-mode 342
 authentication mac-move permit 344
 authentication priority 345
 authentication violation 348
 cisp enable 350
 clear errdisable interface vlan 352
 clear mac address-table 354
 deny (MAC access-list configuration) 356
 device-role (IPv6 snooping) 360
 device-role (IPv6 nd inspection) 361
 dot1x critical (global configuration) 362
 dot1x pae 363
 dot1x supplicant force-multicast 364
 dot1x test eapol-capable 365
 dot1x test timeout 366
 dot1x timeout 367
 epm access-control open 370
 ip admission 371
 ip admission name 372
 ip device tracking maximum 375
 ip device tracking probe 376
 ip dhcp snooping database 377

ip dhcp snooping information option format remote-id 379
ip dhcp snooping verify no-relay-agent-address 380
ip source binding 381
ip verify source 382
ipv6 snooping policy 384
limit address-count 386
mab request format attribute 32 387
match (access-map configuration) 389
no authentication logging verbose 391
no dot1x logging verbose 392
no mab logging verbose 393
permit (MAC access-list configuration) 394
protocol (IPv6 snooping) 398
security level (IPv6 snooping) 399
show aaa clients 400
show aaa command handler 401
show aaa local 402
show aaa servers 404
show aaa sessions 405
show authentication sessions 406
show cisp 409
show dot1x 411
show eap pac peer 413
show ip dhcp snooping statistics 414
show radius server-group 417
show vlan access-map 419
show vlan group 420
show wireless wps rogue ap summary 421
show wireless wps rogue client detailed 422
show wireless wps wips statistics 423
show wireless wps wips summary 424
tracking (IPv6 snooping) 425
trusted-port 427
wireless security web-auth retries 428
wireless dot11-padding 429

wireless wps rogue rule 430
 wireless wps rogue detection 432
 vlan access-map 433
 vlan filter 435
 vlan group 437

PART VIII

Layer 2 (Link Aggregation) 439**CHAPTER 9****Layer 2/3 Commands 441**

channel-group 443
 channel-protocol 446
 clear lacp 448
 clear pagp 449
 debug etherchannel 450
 debug lacp 452
 debug pagp 453
 debug platform pm 455
 debug platform udd 457
 interface port-channel 458
 lacp max-bundle 460
 lacp port-priority 461
 lacp system-priority 463
 pagp learn-method 465
 pagp port-priority 467
 port-channel load-balance 469
 port-channel load-balance extended 471
 port-channel min-links 473
 show etherchannel 475
 show lacp 478
 show pagp 483
 show platform etherchannel 485
 show platform pm 486
 show udd 487
 switchport 491
 switchport access vlan 493

switchport mode 494
switchport nonegotiate 497
udld 499
udld port 501
udld reset 503

PART IX

WLAN 505**CHAPTER 10****WLAN Commands 507**

aaa-override 509
accounting-list 510
assisted-roaming 511
band-select 513
broadcast-ssid 514
call-snoop 515
channel-scan defer-priority 517
channel-scan defer-time 518
chd 519
client association limit 520
client vlan 522
cex aironet-iesupport 523
datalink flow monitor 524
default 526
dtim dot11 529
exclusionlist 530
exit 531
exit (WLAN AP Group) 532
ip access-group 533
ip flow monitor 534
ip verify source mac-check 535
load-balance 536
mobility anchor 537
nac 539
passive-client 540
peer-blocking 541

radio 542
 radio-policy 544
 roamed-voice-client re-anchor 546
 security ft 547
 security pmf 549
 security web-auth 551
 security wpa akm 552
 service-policy (WLAN) 554
 session-timeout 556
 show wlan 557
 shutdown 560
 sip-cac 561
 static-ip tunneling 562
 vlan 563
 wgb non-cisco 564
 wifidirect policy 565
 wlan (AP Group Configuration) 566
 wlan 567
 wlan shutdown 568
 wmm 569

PART X
Radio Resource Management 571

CHAPTER 11
Radio Resource Management Commands 573

ap dot11 rrm 574
 ap dot11 rrm ccx 577
 ap dot11 rrm channel 578
 ap dot11 24ghz or 5ghz rrm channel dca add 580
 ap dot11 24ghz or 5ghz rrm channel dca remove 581
 ap dot11 5ghz rrm channel dca chan-width-11n 582
 ap dot11 rrm coverage 583
 ap dot11 rrm group-member 585
 ap dot11 rrm monitor 586
 ap dot11 rrm profile 588
 ap dot11 rrm tpc-threshold 589

ap dot11 rrm txpower 590
show ap dot11 24ghz 591
show ap dot11 5ghz 593

PART XI**Lightweight Access Points 595**

CHAPTER 12**Cisco Lightweight Access Point Commands 597**

ap auth-list ap-policy 603
ap bridging 604
ap capwap backup 605
ap capwap multicast 606
ap capwap retransmit 607
ap capwap timers 608
ap cdp 610
ap core-dump 612
ap country 613
ap crash-file 614
ap dot11 24ghz preamble 615
ap dot11 24ghz dot11g 616
ap dot11 5ghz channelswitch mode 617
ap dot11 5ghz power-constraint 618
ap dot11 beaconperiod 619
ap dot11 beamforming 620
ap dot11 cac media-stream 622
ap dot11 cac multimedia 625
ap dot11 cac video 627
ap dot11 cac voice 629
ap dot11 cleanair 632
ap dot11 cleanair alarm air-quality 633
ap dot11 cleanair alarm device 634
ap dot11 cleanair device 636
ap dot11 dot11n 638
ap dot11 dtpc 641
ap dot11 edca-parameters 643
ap dot11 rrm group-mode 645

ap dot11 rrm channel cleanair-event 646
ap dot11 l2roam rf-params 647
ap dot11 media-stream 649
ap dot11 rrm ccx location-measurement 651
ap dot11 rrm channel dca 652
ap dot11 rrm group-member 654
ap dot11 rrm logging 655
ap dot11 rrm monitor 657
ap dot11 rrm ndp-type 659
ap dot1x max-sessions 660
ap dot1x username 661
ap ethernet duplex 662
ap group 663
ap image 664
ap ipv6 tcp adjust-mss 665
ap led 666
ap link-encryption 667
ap link-latency 668
ap mgmtuser username 669
ap name ap-groupname 671
ap name bhrate 672
ap name bridgegroupname 673
ap name capwap retransmit 674
ap name command 675
ap name core-dump 676
ap name country 677
ap name crash-file 678
ap name dot11 24ghz rrm coverage 679
ap name dot11 49ghz rrm profile 681
ap name dot11 5ghz rrm channel 683
ap name dot11 antenna 684
ap name dot11 antenna extantgain 686
ap name dot11 cleanair 687
ap name dot11 dot11n antenna 688
ap name dot11 dual-band cleanair 689

ap name dot11 dual-band shutdown **690**
ap name dot11 rrm ccx **691**
ap name dot11 rrm profile **692**
ap name dot11 txpower **694**
ap name dot1x-user **695**
ap name ethernet **697**
ap name ethernet duplex **698**
ap name image **699**
ap name ipv6 tcp adjust-mss **700**
ap name led **701**
ap name location **702**
ap name mgmtuser **703**
ap name mode **705**
ap name monitor-mode **707**
ap name monitor-mode dot11b **708**
ap name name **709**
ap name bridging **710**
ap name cdp interface **711**
ap name console-redirect **712**
ap name no dot11 shutdown **713**
ap name link-encryption **714**
ap name link-latency **715**
ap name power **716**
ap name shutdown **717**
ap name slot shutdown **718**
ap name sniff **719**
ap name ssh **720**
ap name telnet **721**
ap name power injector **722**
ap name power pre-standard **723**
ap name reset-button **724**
ap name reset **725**
ap name slot **726**
ap name static-ip **728**
ap name stats-timer **730**

ap name syslog host 731
ap name syslog level 732
ap name tcp-adjust-mss 733
ap name tftp-downgrade 734
ap power injector 735
ap power pre-standard 736
ap reporting-period 737
ap reset-button 738
ap static-ip 739
ap syslog 740
ap tcp-adjust-mss size 742
ap tftp-downgrade 743
clear ap name tsm dot11 all 744
clear ap config 745
clear ap eventlog-all 746
clear ap join statistics 747
clear ap mac-address 748
clear ap name wlan statistics 749
show ap cac voice 750
show ap capwap 752
show ap cdp 754
show ap config dot11 755
show ap config dot11 dual-band summary 756
show ap config fnf 757
show ap config 758
show ap crash-file 759
show ap data-plane 760
show ap dot11 l2roam 761
show ap dot11 cleanair air-quality 762
show ap dot11 cleanair config 763
show ap dot11 cleanair summary 765
show ap dot11 766
show ap ethernet statistics 771
show ap groups 772
show ap groups extended 773

[show ap image](#) 774

[show ap join stats summary](#) 775

[show ap link-encryption](#) 776

[show ap mac-address](#) 777

[show ap monitor-mode summary](#) 779

[show ap name auto-rf](#) 780

[show ap name bhmode](#) 783

[show ap name bhrate](#) 784

[show ap name cac voice](#) 785

[show ap name config fnf](#) 786

[show ap name dot11 call-control](#) 787

[show ap name capwap retransmit](#) 788

[show ap name ccx rm](#) 789

[show ap name cdp](#) 790

[show ap name channel](#) 791

[show ap name config](#) 792

[show ap name config dot11](#) 794

[show ap name config slot](#) 798

[show ap name core-dump](#) 802

[show ap name data-plane](#) 803

[show ap name dot11](#) 804

[show ap name dot11 cleanair](#) 807

[show ap name ethernet statistics](#) 808

[show ap name eventlog](#) 809

[show ap name image](#) 810

[show ap name inventory](#) 811

[show ap name link-encryption](#) 812

[show ap name service-policy](#) 813

[show ap name tcp-adjust-mss](#) 814

[show ap name wlan](#) 815

[show ap slots](#) 817

[show ap summary](#) 818

[show ap tcp-adjust-mss](#) 819

[show ap uptime](#) 820

[show wireless client ap](#) 821

test ap name 822
 test capwap ap name 823
 trapflags ap 824

PART XII
CleanAir 825

CHAPTER 13
CleanAir Commands 827

ap dot11 5ghz cleanair 829
 ap dot11 5ghz cleanair alarm air-quality 830
 ap dot11 5ghz cleanair alarm device 831
 default ap dot11 5ghz cleanair device 833
 ap dot11 5ghz rrm channel cleanair-event 835
 ap dot11 5ghz rrm channel device 836
 ap dot11 24ghz cleanair 837
 ap dot11 24ghz cleanair alarm air-quality 838
 ap dot11 24ghz cleanair alarm device 839
 default ap dot11 24ghz cleanair device 841
 ap dot11 24ghz rrm channel cleanair-event 843
 ap dot11 24ghz rrm channel device 844
 ap name mode se-connect 845
 default ap dot11 5ghz cleanair device 846
 default ap dot11 5ghz rrm channel cleanair-event 848
 default ap dot11 5ghz rrm channel device 849
 default ap dot11 24ghz cleanair alarm device 850
 default ap dot11 24ghz cleanair device 852
 default ap dot11 24ghz rrm channel cleanair-event 854
 show ap dot11 5ghz cleanair air-quality summary 855
 show ap dot11 5ghz cleanair air-quality worst 856
 show ap dot11 5ghz cleanair config 857
 show ap dot11 5ghz cleanair device type 859
 show ap dot11 24ghz cleanair air-quality summary 861
 show ap dot11 24ghz cleanair air-quality worst 862
 show ap dot11 24ghz cleanair config 863
 show ap dot11 24ghz cleanair summary 865

PART XIII**Mobility 867**

CHAPTER 14**Mobility Commands 869**

- mobility anchor 870
- wireless mobility 872
- wireless mobility group keepalive 873
- wireless mobility group member ip 874
- wireless mobility group name 875
- wireless mobility oracle ip 876
- show wireless mobility 877
- clear wireless mobility statistics 879

PART XIV**IPv6 881**

CHAPTER 15**IPv6 Commands 883**

- ipv6 flow monitor 884
- ipv6 traffic-filter 885
- show wireless ipv6 statistics 886

PART XV**Flexible Netflow 887**

CHAPTER 16**Flexible NetFlow Commands 889**

- cache 891
- clear flow exporter 893
- clear flow monitor 894
- collect 896
- collect counter 898
- collect interface 899
- collect timestamp absolute 900
- collect transport tcp flags 901
- datalink flow monitor 902
- debug flow exporter 903
- debug flow monitor 904
- debug flow record 905

- debug sampler 906
- description 907
- destination 908
- dscp 909
- export-protocol netflow-v9 910
- exporter 911
- flow exporter 912
- flow monitor 913
- flow record 914
- ip flow monitor 915
- ipv6 flow monitor 917
- match datalink ethertype 919
- match datalink mac 920
- match datalink vlan 921
- match flow direction 922
- match interface 923
- match ipv4 924
- match ipv4 destination address 925
- match ipv4 source address 926
- match ipv4 ttl 927
- match ipv6 928
- match ipv6 destination address 929
- match ipv6 hop-limit 930
- match ipv6 source address 931
- match transport 932
- match transport icmp ipv4 933
- match transport icmp ipv6 934
- mode random 1 out-of 935
- option 936
- record 938
- sampler 939
- show flow exporter 940
- show flow interface 942
- show flow monitor 944
- show flow record 946

show sampler 947
 source 949
 template data timeout 951
 transport 952
 ttl 953

PART XVI

High Availability 955**CHAPTER 17****High Availability Commands 957**

debug platform stack-manager 958
 main-cpu 959
 mode sso 960
 policy config-sync pre reload 961
 redundancy 962
 redundancy config-sync mismatched-commands 963
 redundancy force-switchover 965
 redundancy reload 966
 reload 967
 session 969
 show platform stack-manager 970
 show redundancy 971
 show redundancy config-sync 975
 show switch 977
 stack-mac persistent timer 978
 stack-mac update force 979
 standby console enable 980
 switch stack port 981
 switch priority 983
 switch provision 984
 switch renumber 986

PART XVII

Network Management 987**CHAPTER 18****Network Management Commands 989**

monitor capture (interface/control plane) 991

monitor capture buffer	995
monitor capture clear	996
monitor capture export	997
monitor capture file	998
monitor capture limit	1000
monitor capture match	1001
monitor capture start	1002
monitor capture stop	1003
monitor session	1004
monitor session destination	1006
monitor session filter	1010
monitor session source	1012
show monitor	1015
show monitor capture	1017
snmp-server enable traps	1019
snmp-server enable traps bridge	1023
snmp-server enable traps call-home	1024
snmp-server enable traps cpu	1025
snmp-server enable traps envmon	1026
snmp-server enable traps errdisable	1027
snmp-server enable traps flash	1028
snmp-server enable traps license	1029
snmp-server enable traps mac-notification	1030
snmp-server enable traps port-security	1031
snmp-server enable traps power-ethernet	1032
snmp-server enable traps snmp	1033
snmp-server enable traps stackwise	1034
snmp-server enable traps storm-control	1036
snmp-server enable traps stpx	1037
snmp-server enable traps transceiver	1038
snmp-server enable traps vstack	1039
snmp-server enable traps wireless	1040
snmp-server engineID	1042
snmp-server host	1043
trapflags	1048



Preface

- [Document Conventions](#), page xxv
- [Related Documentation](#), page xxvii
- [Obtaining Documentation and Submitting a Service Request](#), page xxvii

Document Conventions

This document uses the following conventions:

Convention	Description
<code>^</code> or <code>Ctrl</code>	Both the <code>^</code> symbol and <code>Ctrl</code> represent the Control (Ctrl) key on a keyboard. For example, the key combination <code>^D</code> or <code>Ctrl-D</code> means that you hold down the Control key while you press the D key. (Keys are indicated in capital letters but are not case sensitive.)
bold font	Commands and keywords and user-entered text appear in bold font .
<i>Italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
<code>Courier font</code>	Terminal sessions and information the system displays appear in <code>courier font</code> .
Bold Courier font	Bold Courier font indicates text that the user must enter.
[x]	Elements in square brackets are optional.
...	An ellipsis (three consecutive nonbolded periods without spaces) after a syntax element indicates that the element can be repeated.
	A vertical line, called a pipe, indicates a choice within a set of keywords or arguments.
[x y]	Optional alternative keywords are grouped in brackets and separated by vertical bars.

Convention	Description
{x y}	Required alternative keywords are grouped in braces and separated by vertical bars.
[x {y z}]	Nested set of square brackets or braces indicate optional or required choices within optional or required elements. Braces and a vertical bar within square brackets indicate a required choice within an optional element.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<>	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

Reader Alert Conventions

This document may use the following conventions for reader alerts:



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Tip

Means *the following information will help you solve a problem*.



Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.



Timesaver

Means *the described action saves time*. You can save time by performing the action described in the paragraph.



Warning

Means *reader be warned*. In this situation, you might perform an action that could result in bodily injury.

Related Documentation

**Note**

Before installing or upgrading the controller, refer to the controller release notes.

- Cisco 5700 Series Wireless Controller documentation, located at:
http://www.cisco.com/go/wlc5700_sw
- Cisco Validated Designs documents, located at:
<http://www.cisco.com/go/designzone>
- Error Message Decoder, located at:
<https://www.cisco.com/cgi-bin/Support/Errordecoder/index.cgi>

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.



Using the Command-Line Interface

This chapter contains the following topics:

- [Information About Using the Command-Line Interface, page 1](#)
- [How to Use the CLI to Configure Features, page 6](#)

Information About Using the Command-Line Interface

Command Modes

The Cisco IOS user interface is divided into many different modes. The commands available to you depend on which mode you are currently in. Enter a question mark (?) at the system prompt to obtain a list of commands available for each command mode.

You can start a CLI session through a console connection, through Telnet, a SSH, or by using the browser.

When you start a session, you begin in user mode, often called user EXEC mode. Only a limited subset of the commands are available in user EXEC mode. For example, most of the user EXEC commands are one-time commands, such as **show** commands, which show the current configuration status, and **clear** commands, which clear counters or interfaces. The user EXEC commands are not saved when the controller reboots.

To have access to all commands, you must enter privileged EXEC mode. Normally, you must enter a password to enter privileged EXEC mode. From this mode, you can enter any privileged EXEC command or enter global configuration mode.

Using the configuration modes (global, interface, and line), you can make changes to the running configuration. If you save the configuration, these commands are stored and used when the controller reboots. To access the various configuration modes, you must start at global configuration mode. From global configuration mode, you can enter interface configuration mode and line configuration mode.

This table describes the main command modes, how to access each one, the prompt you see in that mode, and how to exit the mode.

Table 1: Command Mode Summary

Mode	Access Method	Prompt	Exit Method	About This Mode
User EXEC	Begin a session using Telnet, SSH, or console.	Controller>	Enter logout or quit .	Use this mode to <ul style="list-style-type: none"> • Change terminal settings. • Perform basic tests. • Display system information.
Privileged EXEC	While in user EXEC mode, enter the enable command.	Controller#	Enter disable to exit.	Use this mode to verify commands that you have entered. Use a password to protect access to this mode. Use this mode to execute privilege EXEC commands for access points. These commands are not part of the running config of the controller, they are sent to the IOS config of the access point.
Global configuration	While in privileged EXEC mode, enter the configure command.	Controller(config)#	To exit to privileged EXEC mode, enter exit or end , or press Ctrl-Z .	Use this mode to configure parameters that apply to the entire controller. Use this mode to configure access point commands that are part of the running config of the controller.
VLAN configuration	While in global configuration mode, enter the vlan <i>vlan-id</i> command.	Controller(config-vlan)#		

Mode	Access Method	Prompt	Exit Method	About This Mode
			To exit to global configuration mode, enter the exit command. To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to configure VLAN parameters. When VTP mode is transparent, you can create extended-range VLANs (VLAN IDs greater than 1005) and save configurations in the controller startup configuration file.
Interface configuration	While in global configuration mode, enter the interface command (with a specific interface).	Controller(config-if)#	To exit to global configuration mode, enter exit . To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to configure parameters for the Ethernet ports.
Line configuration	While in global configuration mode, specify a line with the line vty or line console command.	Controller(config-line)#	To exit to global configuration mode, enter exit . To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to configure parameters for the terminal line.

Using the Help System

You can enter a question mark (?) at the system prompt to display a list of commands available for each command mode. You can also obtain a list of associated keywords and arguments for any command.

SUMMARY STEPS

1. **help**
2. *abbreviated-command-entry ?*
3. *abbreviated-command-entry <Tab>*
4. **?**
5. *command ?*
6. *command keyword ?*

DETAILED STEPS

	Command or Action	Purpose
Step 1	help Example: Controller# help	Obtains a brief description of the help system in any command mode.
Step 2	<i>abbreviated-command-entry ?</i> Example: Controller# di? dir disable disconnect	Obtains a list of commands that begin with a particular character string.
Step 3	<i>abbreviated-command-entry <Tab></i> Example: Controller# sh conf<tab> Controller# show configuration	Completes a partial command name.
Step 4	? Example: Controller> ?	Lists all commands available for a particular command mode.
Step 5	<i>command ?</i> Example: Controller> show ?	Lists the associated keywords for a command.
Step 6	<i>command keyword ?</i> Example: Controller(config)# cdp holdtime ? <10-255> Length of time (in sec) that receiver must keep this packet	Lists the associated arguments for a keyword.

Understanding Abbreviated Commands

You need to enter only enough characters for the controller to recognize the command as unique.

This example shows how to enter the **show configuration** privileged EXEC command in an abbreviated form:

```
Controller# show conf
```

No and Default Forms of Commands

Almost every configuration command also has a **no** form. In general, use the **no** form to disable a feature or function or reverse the action of a command. For example, the **no shutdown** interface configuration command reverses the shutdown of an interface. Use the command without the keyword **no** to reenable a disabled feature or to enable a feature that is disabled by default.

Configuration commands can also have a **default** form. The **default** form of a command returns the command setting to its default. Most commands are disabled by default, so the **default** form is the same as the **no** form. However, some commands are enabled by default and have variables set to certain default values. In these cases, the **default** command enables the command and sets variables to their default values.

CLI Error Messages

This table lists some error messages that you might encounter while using the CLI to configure your controller.

Table 2: Common CLI Error Messages

Error Message	Meaning	How to Get Help
% Ambiguous command: "show con"	You did not enter enough characters for your controller to recognize the command.	Reenter the command followed by a question mark (?) without any space between the command and the question mark. The possible keywords that you can enter with the command appear.
% Incomplete command.	You did not enter all of the keywords or values required by this command.	Reenter the command followed by a question mark (?) with a space between the command and the question mark. The possible keywords that you can enter with the command appear.
% Invalid input detected at '^' marker.	You entered the command incorrectly. The caret (^) marks the point of the error.	Enter a question mark (?) to display all of the commands that are available in this command mode. The possible keywords that you can enter with the command appear.

Configuration Logging

You can log and view changes to the controller configuration. You can use the Configuration Change Logging and Notification feature to track changes on a per-session and per-user basis. The logger tracks each configuration command that is applied, the user who entered the command, the time that the command was entered, and the parser return code for the command. This feature includes a mechanism for asynchronous

notification to registered applications whenever the configuration changes. You can choose to have the notifications sent to the syslog.



Note Only CLI or HTTP changes are logged.

How to Use the CLI to Configure Features

Configuring the Command History

The software provides a history or record of commands that you have entered. The command history feature is particularly useful for recalling long or complex commands or entries, including access lists. You can customize this feature to suit your needs.

Changing the Command History Buffer Size

By default, the controller records ten command lines in its history buffer. You can alter this number for a current terminal session or for all sessions on a particular line. This procedure is optional.

SUMMARY STEPS

1. `terminal history [size number-of-lines]`

DETAILED STEPS

	Command or Action	Purpose
Step 1	<code>terminal history [size number-of-lines]</code> Example: Controller# <code>terminal history size 200</code>	Changes the number of command lines that the controller records during the current terminal session in privileged EXEC mode. You can configure the size from 0 to 256.

Recalling Commands

To recall commands from the history buffer, perform one of the actions listed in this table. These actions are optional.



Note The arrow keys function only on ANSI-compatible terminals such as VT100s.

SUMMARY STEPS

1. **Ctrl-P** or use the **up arrow** key
2. **Ctrl-N** or use the **down arrow** key
3. **show history**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Ctrl-P or use the up arrow key	Recalls commands in the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Step 2	Ctrl-N or use the down arrow key	Returns to more recent commands in the history buffer after recalling commands with Ctrl-P or the up arrow key. Repeat the key sequence to recall successively more recent commands.
Step 3	show history Example: Controller# <code>show history</code>	Lists the last several commands that you just entered in privileged EXEC mode. The number of commands that appear is controlled by the setting of the terminal history global configuration command and the history line configuration command.

Disabling the Command History Feature

The command history feature is automatically enabled. You can disable it for the current terminal session or for the command line. This procedure is optional.

SUMMARY STEPS

1. **terminal no history**

DETAILED STEPS

	Command or Action	Purpose
Step 1	terminal no history Example: Controller# <code>terminal no history</code>	Disables the feature during the current terminal session in privileged EXEC mode.

Enabling and Disabling Editing Features

Although enhanced editing mode is automatically enabled, you can disable it and reenble it.

SUMMARY STEPS

1. `terminal editing`
2. `terminal no editing`

DETAILED STEPS

	Command or Action	Purpose
Step 1	terminal editing Example: Controller# <code>terminal editing</code>	Reenables the enhanced editing mode for the current terminal session in privileged EXEC mode.
Step 2	terminal no editing Example: Controller# <code>terminal no editing</code>	Disables the enhanced editing mode for the current terminal session in privileged EXEC mode.

Editing Commands Through Keystrokes

The keystrokes help you to edit the command lines. These keystrokes are optional.


Note

The arrow keys function only on ANSI-compatible terminals such as VT100s.

Table 3: Editing Commands

Editing Commands	Description
Ctrl-B or use the left arrow key	Moves the cursor back one character.
Ctrl-F or use the right arrow key	Moves the cursor forward one character.
Ctrl-A	Moves the cursor to the beginning of the command line.
Ctrl-E	Moves the cursor to the end of the command line.
Esc B	Moves the cursor back one word.
Esc F	Moves the cursor forward one word.
Ctrl-T	Transposes the character to the left of the cursor with the character located at the cursor.
Delete or Backspace key	Erases the character to the left of the cursor.
Ctrl-D	Deletes the character at the cursor.
Ctrl-K	Deletes all characters from the cursor to the end of the command line.
Ctrl-U or Ctrl-X	Deletes all characters from the cursor to the beginning of the command line.
Ctrl-W	Deletes the word to the left of the cursor.
Esc D	Deletes from the cursor to the end of the word.
Esc C	Capitalizes at the cursor.
Esc L	Changes the word at the cursor to lowercase.
Esc U	Capitalizes letters from the cursor to the end of the word.

Ctrl-V or Esc Q	Designates a particular keystroke as an executable command, perhaps as a shortcut.
Return key	Scrolls down a line or screen on displays that are longer than the terminal screen can display. Note The More prompt is used for any output that has more lines than can be displayed on the terminal screen, including show command output. You can use the Return and Space bar keystrokes whenever you see the More prompt.
Space bar	Scrolls down one screen.
Ctrl-L or Ctrl-R	Redisplays the current command line if the controller suddenly sends a message to your screen.

Editing Command Lines That Wrap

You can use a wraparound feature for commands that extend beyond a single line on the screen. When the cursor reaches the right margin, the command line shifts ten spaces to the left. You cannot see the first ten characters of the line, but you can scroll back and check the syntax at the beginning of the command. The keystroke actions are optional.

To scroll back to the beginning of the command entry, press **Ctrl-B** or the left arrow key repeatedly. You can also press **Ctrl-A** to immediately move to the beginning of the line.



Note

The arrow keys function only on ANSI-compatible terminals such as VT100s.

The following example shows how to wrap a command line that extends beyond a single line on the screen.

SUMMARY STEPS

1. **access-list**
2. **Ctrl-A**
3. **Return** key

DETAILED STEPS

	Command or Action	Purpose
Step 1	access-list Example: Controller(config)# access-list 101 permit	Displays the global configuration command entry that extends beyond one line. When the cursor first reaches the end of the line, the line is shifted ten spaces to the left and redisplayed. The dollar sign (\$) shows that the

	Command or Action	Purpose
	<pre>tcp 10.15.22.25 255.255.255.0 10.15.22.35 Controller(config)# \$ 101 permit tcp 10.15.22.25 255.255.255.0 10.15.22.35 255.25 Controller(config)# \$t tcp 10.15.22.25 255.255.255.0 131.108.1.20 255.255.255.0 eq Controller(config)# \$15.22.25 255.255.255.0 10.15.22.35 255.255.255.0 eq 45</pre>	<p>line has been scrolled to the left. Each time the cursor reaches the end of the line, the line is again shifted ten spaces to the left.</p>
Step 2	<p>Ctrl-A</p> <p>Example:</p> <pre>Controller(config)# access-list 101 permit tcp 10.15.22.25 255.255.255.0 10.15.2\$</pre>	<p>Checks the complete syntax.</p> <p>The dollar sign (\$) appears at the end of the line to show that the line has been scrolled to the right.</p>
Step 3	<p>Return key</p>	<p>Execute the commands.</p> <p>The software assumes that you have a terminal screen that is 80 columns wide. If you have a different width, use the terminal width privileged EXEC command to set the width of your terminal.</p> <p>Use line wrapping with the command history feature to recall and modify previous complex command entries.</p>

Searching and Filtering Output of show and more Commands

You can search and filter the output for **show** and **more** commands. This is useful when you need to sort through large amounts of output or if you want to exclude output that you do not need to see. Using these commands is optional.

SUMMARY STEPS

1. `{show | more} command | {begin | include | exclude} regular-expression`

DETAILED STEPS

	Command or Action	Purpose
Step 1	<pre>{show more} command {begin include exclude} regular-expression</pre> <p>Example:</p> <pre>Controller# show interfaces include protocol Vlan1 is up, line protocol is up Vlan10 is up, line protocol is down GigabitEthernet1/0/1 is up, line protocol is down GigabitEthernet1/0/2 is up, line protocol is up</pre>	<p>Searches and filters the output.</p> <p>Expressions are case sensitive. For example, if you enter exclude output, the lines that contain output are not displayed, but the lines that contain output appear.</p>

Accessing the CLI Through a Console Connection or Through Telnet

Before you can access the CLI, you must connect a terminal or a PC to the controller console or connect a PC to the Ethernet management port and then power on the controller, as described in the hardware installation guide that shipped with your controller.

If your controller is already configured, you can access the CLI through a local console connection or through a remote Telnet session, but your controller must first be configured for this type of access.

You can use one of these methods to establish a connection with the controller:

- Connect the controller console port to a management station or dial-up modem, or connect the Ethernet management port to a PC. For information about connecting to the console or Ethernet management port, see the controller hardware installation guide.
- Use any Telnet TCP/IP or encrypted Secure Shell (SSH) package from a remote management station. The controller must have network connectivity with the Telnet or SSH client, and the controller must have an enable secret password configured.
 - The controller supports up to 16 simultaneous Telnet sessions. Changes made by one Telnet user are reflected in all other Telnet sessions.
 - The controller supports up to five simultaneous secure SSH sessions.

After you connect through the console port, through the Ethernet management port, through a Telnet session or through an SSH session, the user EXEC prompt appears on the management station.



PART **I**

System Management

- [Cisco 5700 Series System Management Commands, page 15](#)



Cisco 5700 Series System Management Commands

This module contains the following commands:

- [arp](#), page 18
- [boot](#), page 19
- [cat](#), page 21
- [clear location](#), page 22
- [clear location statistics](#), page 23
- [clear nmsp statistics](#), page 24
- [clear wireless ccx statistics](#), page 25
- [clear wireless client tsm dot11](#), page 26
- [clear wireless location s69 statistics](#), page 27
- [copy](#), page 28
- [debug call-admission wireless all](#), page 29
- [debug rfid](#), page 30
- [debug voice diagnostics mac-address](#), page 31
- [debug wps mfp](#), page 32
- [delete](#), page 33
- [dir](#), page 34
- [emergency-install](#), page 36
- [exit](#), page 38
- [help](#), page 39
- [license right-to-use](#), page 40
- [location](#), page 42

- [location algorithm](#), page 46
- [location expiry](#), page 47
- [location notify-threshold](#), page 48
- [location plm calibrating](#), page 49
- [location rfid](#), page 50
- [location rssi-half-life](#), page 51
- [mac address-table control-packet-learn](#), page 52
- [logging smartlog](#), page 53
- [mgmt_init](#), page 55
- [mkdir](#), page 56
- [more](#), page 57
- [nmsp notification interval](#), page 58
- [rename](#), page 60
- [reset](#), page 61
- [rmdir](#), page 62
- [set](#), page 63
- [show avc client](#), page 66
- [show avc wlan](#), page 67
- [show cable-diagnostics tdr](#), page 69
- [show flow monitor](#), page 72
- [show license right-to-use](#), page 74
- [show location](#), page 76
- [show location ap-detect](#), page 77
- [show mac address-table control-packet-learn](#), page 79
- [show mac address-table move update](#), page 80
- [show nmsp](#), page 81
- [show tech-support wireless](#), page 83
- [show wireless band-select](#), page 85
- [show wireless client calls](#), page 86
- [show wireless client dot11](#), page 87
- [show wireless client location-calibration](#), page 88
- [show wireless client probing](#), page 89
- [show wireless client summary](#), page 90

- [show wireless client timers, page 91](#)
- [show wireless client voice diagnostics, page 92](#)
- [show wireless country, page 93](#)
- [show wireless detail, page 96](#)
- [show wireless dtls connections, page 97](#)
- [show wireless flow-control, page 98](#)
- [show wireless flow-control statistics, page 99](#)
- [show wireless load-balancing, page 100](#)
- [show wireless performance, page 101](#)
- [show wireless pmk-cache, page 102](#)
- [show wireless probe, page 103](#)
- [show wireless sip preferred-call-no, page 104](#)
- [show wireless summary, page 105](#)
- [shutdown, page 106](#)
- [system env temperature threshold yellow, page 107](#)
- [test cable-diagnostics tdr, page 109](#)
- [traceroute mac, page 110](#)
- [traceroute mac ip, page 113](#)
- [trapflags, page 115](#)
- [trapflags client, page 116](#)
- [type, page 117](#)
- [unset, page 118](#)
- [version, page 120](#)
- [wireless client, page 121](#)
- [wireless client mac-address deauthenticate, page 123](#)
- [wireless client mac-address, page 124](#)
- [wireless load-balancing, page 129](#)
- [wireless sip preferred-call-no, page 130](#)

arp

To display the contents of the Address Resolution Protocol (ARP) table, use the **arp** command in boot loader mode.

arp [*ip_address*]

Syntax Description

<i>ip_address</i>	(Optional) Shows the ARP table or the mapping for a specific IP address.
-------------------	--

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The ARP table contains the IP-address-to-MAC-address mappings.

Examples

This example shows how to display the ARP table:

```
Controller: arp 172.20.136.8
arp'ing 172.20.136.8...
172.20.136.8 is at 00:1b:78:d1:25:ae, via port 0
```

boot

To load and boot an executable image and display the command-line interface (CLI), use the **boot** command in boot loader mode.

boot [-post | -n | -p | *flag*].*filesystem*:*/file-url*...

Syntax Description

-post	(Optional) Run the loaded image with an extended or comprehensive power-on self-test (POST). Using this keyword causes POST to take longer to complete.
-n	(Optional) Pause for the Cisco IOS Debugger immediately after launching.
-p	(Optional) Pause for the JTAG Debugger right after loading the image.
<i>filesystem</i> :	Alias for a file system. Use flash : for the system board flash device; use usbflash0 : for USB memory sticks.
<i>/file-url</i>	Path (directory) and name of a bootable image. Separate image names with a semicolon.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

When you enter the **boot** command without any arguments, the controller attempts to automatically boot the system by using the information in the BOOT environment variable, if any.

If you supply an image name for the *file-url* variable, the **boot** command attempts to boot the specified image.

When you specify boot loader **boot** command options, they are executed immediately and apply only to the current boot loader session.

These settings are not saved for the next boot operation.

Filenames and directory names are case sensitive.

Examples

This example shows how to boot the controller using the *new-image.bin* image:

```
Controller: set BOOT flash:/new-images/new-image.bin
Controller: boot
```

After entering this command, you are prompted to start the setup program.

cat

To display the contents of one or more files, use the **cat** command in boot loader mode.

cat *filesystem:/file-url...*

Syntax Description

<i>filesystem:</i>	Specifies a file system.
<i>/file-url</i>	Specifies the path (directory) and name of the files to display. Separate each filename with a space.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Filenames and directory names are case sensitive.

If you specify a list of files, the contents of each file appears sequentially.

Examples

This example shows how to display the contents of an image file:

```
Controller: cat flash:image_file_name
version_suffix: universal-122-xx.SEx
version_directory: image_file_name
image_system_type_id: 0x00000002
image_name: image_file_name.bin
ios_image_file_size: 8919552
total_image_file_size: 11592192
image_feature: IP|LAYER_3|PLUS|MIN_DRAM_MEG=128
image_family: family
stacking_number: 1.34
board_ids: 0x00000068 0x00000069 0x0000006a 0x0000006b
info_end:
```

clear location

To clear a specific radio frequency identification (RFID) tag or all of the RFID tags information in the entire database, use the **clear location** command in EXEC mode.

clear location [**mac-address** *mac-address* | **rfid**]

Syntax Description

mac-address <i>mac-address</i>	MAC address of a specific RFID tag.
rfid	Specifies all of the RFID tags in the database.

Command Default

No default behavior or values.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to clear information about all of the RFID tags in the database:

```
Controller> clear location rfid
```

clear location statistics

To clear radio-frequency identification (RFID) statistics, use the **clear location statistics** command in EXEC mode.

clear location statistics

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples The following is sample output from the **clear location rfid** command and shows how to clear RFID statistics:

```
Controller> clear location statistics
```

clear nmsp statistics

To clear the Network Mobility Services Protocol (NMSP) statistics, use the **clear nmsp statistics** command in EXEC mode.

clear nmsp statistics

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes
User Exec
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples The following is sample output from the **clear nmsp statistics** command and shows how to clear all statistics about NMSP information exchanged between the controller and the connected Cisco Mobility Services Engine (MSE):

```
Controller> clear nmsp statistics
```

clear wireless ccx statistics

To clear CCX statistics, use the **clear wireless ccx statistics** command in EXEC mode.

clear wireless ccx statistics

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes
User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples The following is sample output from the **clear wireless ccx statistics** command and shows how to clear all collected statistics about CCX clients:

```
Controller> clear wireless ccx statistics
```

clear wireless client tsm dot11

To clear the traffic stream metrics (TSM) statistics for a particular access point or all of the access points to which this client is associated, use the **clear wireless client tsm dot11** command in EXEC mode.

```
clear wireless client tsm dot11 {24ghz| 5ghz} client-mac-addr {all| name ap-name}
```

Syntax Description

24ghz	Specifies the 802.11a network.
5ghz	Specifies the 802.11b network.
<i>client-mac-addr</i>	MAC address of the client.
all	Specifies all access points.
name ap-name	Name of a Cisco lightweight access point.

Command Default

No default behavior or values.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **clear wireless client tsm dot11** command and shows how to clear the TSM for the MAC address 00:40:96:a8:f7:98 on all of the access points 5-GHz radios where this client is known:

```
Controller> clear wireless client tsm dot11 5ghz 00:40:96:a8:f7:98 all
```

clear wireless location s69 statistics

To clear statistics about S69 exchanges with CCXv5 clients, use the **clear wireless location s69 statistics** command in EXEC mode.

clear wireless location s69 statistics

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines S69 messages are exchanged between CCXv5 clients and the wireless infrastructure. The CCXv5 client uses S69 message to request location information, that is then returned by the wireless infrastructure through a S69 response message.

Examples The following is sample output from the **clear wireless location s69 statistics** command and shows how to clear statistics about S69 exchanges with CCXv5 clients:

```
Controller> clear wireless location s69 statistics
```

copy

To copy a file from a source to a destination, use the **copy** command in boot loader mode.

copy *filesystem:/source-file-url filesystem:/destination-file-url*

Syntax Description

<i>filesystem:</i>	Alias for a file system. Use usbflash0: for USB memory sticks.
<i>/source-file-url</i>	Path (directory) and filename (source) to be copied.
<i>/destination-file-url</i>	Path (directory) and filename of the destination.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Filenames and directory names are case sensitive.

Directory names are limited to 127 characters between the slashes (/); the name cannot contain control characters, spaces, deletes, slashes, quotes, semicolons, or colons.

Filenames are limited to 127 characters; the name cannot contain control characters, spaces, deletes, slashes, quotes, semicolons, or colons.

If you are copying a file to a new directory, the directory must already exist.

Examples

This example shows how to copy a file at the root:

```
Controller: copy usbflash0:test1.text usbflash0:test4.text
File "usbflash0:test1.text" successfully copied to "usbflash0:test4.text"
```

You can verify that the file was copied by entering the **dir filesystem:** boot loader command.

debug call-admission wireless all

To enable debugging of the wireless Call Admission Control (CAC) feature, use the **debug call-admission wireless all** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug call-admission wireless all [**switch** *switch*]

no debug call-admission wireless all [**switch** *switch*]

Syntax Description	switch	Configures debugging options for all wireless CAC messages associated to a particular switch.
Command Default	No default behavior or values.	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **debug call-admission wireless switch** command and shows how to enable debugging options for CAC messages:

```
Controller# debug call-admission wireless switch 1 all
```

debug rfid

To configure radio-frequency identification (RFID) debug options, use the **debug rfid** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug rfid {*debug_leaf_name* | **all** | **detail** | **error** | **nmsp** | **receive**} [**filter** | **switch** *switch*]

no debug rfid {*debug_leaf_name* | **all** | **detail** | **error** | **nmsp** | **receive**} [**filter** | **switch** *switch*]

Syntax Description

<i>debug_leaf_name</i>	Debug leaf name.
all	Configures debugging of all RFID.
detail	Configures debugging of RFID detail.
error	Configures debugging of RFID error messages.
nmsp	Configures debugging of RFID Network Mobility Services Protocol (NMSP) messages.
receive	Configures debugging of incoming RFID tag messages.
<i>filter</i>	Debug flag filter name.
switch <i>switch</i>	Configures RFID debugging for controller.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **debug rfid** command and shows how to enable debugging of RFID error messages:

```
Controller# debug rfid error switch 1
```

debug voice diagnostics mac-address

To enable debugging of voice diagnostics for voice clients, use the **debug voice diagnostics mac-address** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug voice diagnostics mac-address *mac-address1* **verbose** **mac-address** *mac-address2* **verbose**
nodebug voice diagnostics mac-address *mac-address1* **verbose** **mac-address** *mac-address2* **verbose**

Syntax Description		
	voice diagnostics	Configures voice debugging for voice clients.
	mac-address <i>mac-address1</i> mac-address <i>mac-address2</i>	Specifies MAC addresses of the voice clients.
	verbose	Enables verbose mode for voice diagnostics.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples The following is sample output from the **debug voice diagnostics mac-address** command and shows how to enable debugging of voice diagnostics for voice client with MAC address of 00:1f:ca:cf:b6:60:

```
Controller# debug voice diagnostics mac-address 00:1f:ca:cf:b6:60
```

debug wps mfp

To enable WPS MFP debugging options, use the **debug wps mfp** command in privileged EXEC mode. To disable debugging, use the no form of this command.

debug wps mfp {**all** | **capwap**| **client** | **detail**| **mm**| **report**} [**switch** *switch*]

Syntax Description

wps mfp	Configures WPS MFP debugging options.
all	Displays all WPS MFP debugging messages.
capwap	Displays MFP messages.
client	Displays client MFP messages.
detail	Displays detailed MFP CAPWAP messages.
mm	Displays MFP mobility (inter-controller) messages.
report	Displays MFP reports.
switch <i>switch</i>	Displays the WPS MFP debugging for the controller.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable WPS MFP debugging options for client:

```
Controller# debug wps mfp client switch 1
```

delete

To delete one or more files from the specified file system, use the **delete** command in boot loader mode.

delete *filesystem:/file-url...*

Syntax Description

<i>filesystem:</i>	Alias for a file system. Use usbflash0: for USB memory sticks.
<i>/file-url...</i>	Path (directory) and filename to delete. Separate each filename with a space.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Filenames and directory names are case sensitive.

The controller prompts you for confirmation before deleting each file.

Examples

This example shows how to delete two files:

```
Controller: delete usbflash0:test2.text usbflash0:test5.text
Are you sure you want to delete "usbflash0:test2.text" (y/n)?y
File "usbflash0:test2.text" deleted
Are you sure you want to delete "usbflash0:test5.text" (y/n)?y
File "usbflash0:test2.text" deleted
```

You can verify that the files were deleted by entering the **dir usbflash0:** boot loader command.

dir

To display the list of files and directories on the specified file system, use the **dir** command in boot loader mode.

dir *filesystem:/file-url*

Syntax Description

<i>filesystem:</i>	Alias for a file system. Use flash: for the system board flash device; use usbflash0: for USB memory sticks.
<i>/file-url</i>	(Optional) Path (directory) and directory name that contain the contents you want to display. Separate each directory name with a space.

Command Default

No default behavior or values.

Command Modes

Boot Loader
Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Directory names are case sensitive.

Examples

This example shows how to display the files in flash memory:

```

Controller: dir flash:
Directory of flash:/
  2  -rwx      561   Mar 01 2013 00:48:15  express_setup.debug
  3  -rwx  2160256   Mar 01 2013 04:18:48  c2960x-dmon-mz-150-2r.EX
  4  -rwx      1048   Mar 01 2013 00:01:39  multiple-fs
  6  drwx       512   Mar 01 2013 23:11:42  c2960x-universalk9-mz.150-2.EX
645 drwx       512   Mar 01 2013 00:01:11  dc_profile_dir
647 -rwx      4316   Mar 01 2013 01:14:05  config.text
648 -rwx         5   Mar 01 2013 00:01:39  private-config.text

96453632 bytes available (25732096 bytes used)

```

Table 4: dir Field Descriptions

Field	Description
2	Index number of the file.

Field	Description
-rwx	File permission, which can be any or all of the following: <ul style="list-style-type: none">• d—directory• r—readable• w—writable• x—executable
1644045	Size of the file.
<date>	Last modification date.
env_vars	Filename.

exit

To return to the previous mode or exit from the CLI EXEC mode, use the **exit** command.

exit

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes
Privileged EXEC
Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how to exit the configuration mode:

```
Controller(config)# exit
Controller#
```

help

To display the available commands, use the **help** command in boot loader mode.

help

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Boot loader

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how to display a list of available boot loader commands:

```

Controller:help
? -- Present list of available commands
arp -- Show arp table or arp-resolve an address
boot -- Load and boot an executable image
cat -- Concatenate (type) file(s)
copy -- Copy a file
delete -- Delete file(s)
dir -- List files in directories
emergency-install -- Initiate Disaster Recovery
...
...
...
unset -- Unset one or more environment variables
version -- Display boot loader version

```

license right-to-use

To configure right-to-use access point adder licenses on the controller, use the **license right-to-use** command in privileged EXEC mode.

license right-to-use {**activate** | **deactivate**} **ap-count** {*count* | **slot** *slot-number* | **acceptEULA** | **evaluation**}

Syntax Description

activate	Activates permanent or evaluation ap-count licenses.
deactivate	Deactivates permanent or evaluation ap-count licenses.
ap-count <i>count</i>	Specifies the number of ap-count licenses added. You can configure the number of adder licenses from 50 to 500.
slot <i>slot-number</i>	Specifies the slot number in the controller. The slot number is always 1 for the controller.
acceptEULA	Accepts the end-user license agreement (EULA) automatically for the added ap-count licenses. Note By default during activation, the EULA gets displayed. If the acceptEULA is passed, the EULA content is not displayed, and you can activate the evaluation license. This option is useful for automation and scripting.
evaluation	Specifies evaluation ap-count licenses.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to activate an ap-count evaluation license:

```
Controller# license right-to-use activate ap-count evaluation
Controller# end
```

This example shows how to activate an ap-count permanent license:

```
Controller# license right-to-use deactivate ap-count evaluation  
Controller# end
```

This example shows how to add a new ap-count license:

```
Controller# license right-to-use activate ap-count 500 slot 1  
Controller# end
```

location

To configure location information for an endpoint, use the **location** command in global configuration mode. To remove the location information, use the **no** form of this command.

```
location {admin-tag string| algorithm| civic-location identifier {host| id}| civic-location identifier {host| id}| elin-location {string| identifier id}|
expiry {calibrating-client timeout-value| client timeout-value| rogue-aps timeout-value| tag timeout-value}|
geo-location identifier {host| id}| notify-threshold {client db| rogue-aps db| tags db}| plm {calibrating|
{multiband| uniband}| client burst-interval}| prefer {cdp weight priority-value| lldp-med
weight priority-value| static config weight priority-value}| rfid {status
| timeout| fid-timeout-value| vendor-name name}| rssi-half-life {
calibrating-client seconds| client seconds| rogue-aps seconds| tags seconds}

no location {admin-tag string| algorithm| civic-location identifier {host| id}| civic-location identifier
{host| id}| elin-location {string| identifier id}|
expiry {calibrating-client timeout-value| client timeout-value| rogue-aps timeout-value| tag timeout-value}|
geo-location identifier {host| id}| notify-threshold {client db| rogue-aps db| tags db}| plm {calibrating|
{multiband| uniband}| client burst-interval}| prefer {cdp weight priority-value| lldp-med
weight priority-value| static config weight priority-value}| rfid {status
| timeout| fid-timeout-value| vendor-name name}| rssi-half-life {
calibrating-client seconds| client seconds| rogue-aps seconds| tags seconds}
```

Syntax Description

admin-tag <i>string</i>	Configures administrative tag or site information. Site or location information in alphanumeric format.
algorithm	Configures the algorithm used to average RSSI and SNR values.
civic-location	Configures civic location information.
identifier	Specifies the name of the civic location, emergency, or geographical location.
host	Defines the host civic or geo-spatial location.
<i>id</i>	Name of the civic, emergency, or geographical location. Note The identifier for the civic location in the LLDP-MED controller TLV is limited to 250 bytes or less. To avoid error messages about available buffer space during controller configuration, be sure that the total length of all civic-location information specified for each civic-location identifier does not exceed 250 bytes.
elin-location	Configures emergency location information (ELIN).

expiry { calibrating-client client rogue-aps tags } <i>timeout-value</i>	Configures the timeout for RSSI values for calibrating clients, clients, rogue access points, and RFID tags. The valid range for the timeout parameter for calibrating clients is 1 to 3600 seconds, and the default value is 5 seconds. The valid range for the timeout parameter for clients, rogue access points, and RFID tags is 5 to 3600 seconds, and the default value is 5 seconds
geo-location	Configures geo-spatial location information.
notify-threshold { client rogue-aps tags } <i>db</i>	Configures the NMSP notification threshold for RSSI measurements. The valid range for the threshold parameter is 0 to 10 dB, and the default value is 0 dB.
calibrating { multiband uniband } client <i>seconds</i>	Configures path loss measurement (CCX S60) request for calibrating clients and burst interval for clients. The valid range for the burst interval parameter is 0 to 3600 seconds.
prefer	Sets location information source priority.
rfid	Configures RFID tag tracking for a location.
rssi-half-life	Configures the RSSI half life for various devices.

Command Default No default behavior or values.

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

After entering the **location civic-location identifier** global configuration command, you enter civic location configuration mode. After entering the **location geo-location identifier** global configuration command, you enter geo location configuration mode.

The civic-location identifier must not exceed 250 bytes.

The host identifier configures the host civic or geo-spatial location. If the identifier is not a host, the identifier only defines a civic location or geo-spatial template that can be referenced on the interface.

The **host** keyword defines the device location. The civic location options available for configuration using the **identifier** and the **host** keyword are the same. You can specify the following civic location options in civic location configuration mode:

- **additional-code**—Sets an additional civic location code.
- **additional-location-information**—Sets additional civic location information.
- **branch-road-name**—Sets the branch road name.
- **building**—Sets building information.
- **city**—Sets the city name.
- **country**—Sets the two-letter ISO 3166 country code.
- **county**—Sets the county name.
- **default**—Sets a command to its defaults.
- **division**—Sets the city division name.
- **exit**—Exits from the civic location configuration mode.
- **floor**—Sets the floor number.
- **landmark**—Sets landmark information.
- **leading-street-dir**—Sets the leading street direction.
- **name**—Sets the resident name.
- **neighborhood**—Sets neighborhood information.
- **no**—Negates the specified civic location data and sets the default value.
- **number**—Sets the street number.
- **post-office-box**—Sets the post office box.
- **postal-code**—Sets the postal code.
- **postal-community-name**—Sets the postal community name.
- **primary-road-name**—Sets the primary road name.
- **road-section**—Sets the road section.
- **room**—Sets room information.
- **seat**—Sets seat information.
- **state**—Sets the state name.
- **street-group**—Sets the street group.
- **street-name-postmodifier**—Sets the street name postmodifier.
- **street-name-premodifier**—Sets the street name premodifier.
- **street-number-suffix**—Sets the street number suffix.
- **street-suffix**—Sets the street suffix.
- **sub-branch-road-name**—Sets the sub-branch road name.
- **trailing-street-suffix**—Sets the trailing street suffix.
- **type-of-place**—Sets the type of place.

- **unit**—Sets the unit.

You can specify the following geo-spatial location information in geo-location configuration mode:

- **altitude**—Sets altitude information in units of floor, meters, or feet.
- **latitude**—Sets latitude information in degrees, minutes, and seconds. The range is from -90 degrees to 90 degrees. Positive numbers indicate locations north of the equator.
- **longitude**—Sets longitude information in degrees, minutes, and seconds. The range is from -180 degrees to 180 degrees. Positive numbers indicate locations east of the prime meridian.
- **resolution**—Sets the resolution for latitude and longitude. If the resolution value is not specified, default value of 10 meters is applied to latitude and longitude resolution parameters. For latitude and longitude, the resolution unit is measured in meters. The resolution value can also be a fraction.
- **default**—Sets the geographical location to its default attribute.
- **exit**—Exits from geographical location configuration mode.
- **no**—Negates the specified geographical parameters and sets the default value.

Use the **no lldp med-tlv-select location information** interface configuration command to disable the location TLV. The location TLV is enabled by default.

Examples

This example shows how to configure civic location information on the controller:

```
Controller(config)# location civic-location identifier 1
Controller(config-civic)# number 3550
Controller(config-civic)# primary-road-name "Cisco Way"
Controller(config-civic)# city "San Jose"
Controller(config-civic)# state CA
Controller(config-civic)# building 19
Controller(config-civic)# room C6
Controller(config-civic)# county "Santa Clara"
Controller(config-civic)# country US
Controller(config-civic)# end
```

You can verify your settings by entering the **show location civic-location** privileged EXEC command.

This example shows how to configure the emergency location information on the controller:

```
Controller(config)# location elin-location 14085553881 identifier 1
```

You can verify your settings by entering the **show location elin** privileged EXEC command.

The example shows how to configure geo-spatial location information on the controller:

```
Controller(config)# location geo-location identifier host
Controller(config-geo)# latitude 12.34
Controller(config-geo)# longitude 37.23
Controller(config-geo)# altitude 5 floor
Controller(config-geo)# resolution 12.34
```

You can use the **show location geo-location identifier** command to display the configured geo-spatial location details.

location algorithm

To configure the algorithm used to average RSSI and SNR values, use the **location algorithm** command in global configuration mode. To remove the algorithm used to average RSSI and SNR values, use the **no** form of this command.

location algorithm {**rssi-average** | **simple**}

no location algorithm {**rssi-average** | **simple**}

Syntax Description

rssi-average	Specifies a more accurate algorithm but with more CPU overhead.
simple	Specifies faster algorithm with smaller CPU overhead but less accuracy.

Command Default

RSSI average

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure a more accurate algorithm but with more CPU overhead:

```
Controller# configure terminal
Controller(config)# location algorithm rssi-average
Controller(config)# end
```

location expiry

To configure the timeout for RSSI values, use the **location expiry** command in global configuration mode.

location expiry { **calibrating-client** | **client** | **rogue-aps** | **tags** } *timeout-value*

Syntax Description

calibrating-client	Specifies the RSSI timeout value for calibrating clients.
client	(Optional) Specifies the RSSI timeout value for clients.
rogue-aps	Specifies the RSSI timeout value for rogue access points.
tags	Specifies the RSSI timeout value for RFID tags.
<i>timeout-value</i>	The valid range for the timeout parameter for calibrating clients is 1 to 3600 seconds, and the default value is 5 seconds. The valid range for the timeout parameter for clients, rogue access points, and RFID tags is 5 to 3600 seconds, and the default value is 5 seconds.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to set the RSSI timeout value for wireless clients:

```
Controller# configure terminal
Controller(config)# location expiry client 1000
Controller(config)# end
```

location notify-threshold

To configure the NMSP notification threshold for RSSI measurements, use the **location notify-threshold** command in global configuration mode. To remove the NMSP notification threshold for RSSI measurements, use the **no** form of this command.

location notify-threshold {client | rogue-aps | tags } *db*

no location notify-threshold {client | rogue-aps | tags }

Syntax Description

client	Specifies the NMSP notification threshold (in dB) for clients and rogue clients. The valid range for the threshold parameter is 0 to 10 dB, and the default value is 0 dB.
rogue-aps	Specifies the NMSP notification threshold (in dB) for rogue access points. The valid range for the threshold parameter is 0 to 10 dB, and the default value is 0 dB.
tags	Specifies the NMSP notification threshold (in dB) for RFID tags. The valid range for the threshold parameter is 0 to 10 dB, and the default value is 0 dB.
<i>db</i>	The valid range for the threshold parameter is 0 to 10 dB, and the default value is 0 dB.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the NMSP notification threshold to 10 dB for clients. A notification NMSP message is sent to MSE as soon as the client RSSI changes by 10 dB:

```
Controller# configure terminal
Controller(config)# location notify-threshold client 10
Controller(config)# end
```

location plm calibrating

To configure path loss measurement (CCX S60) request for calibrating clients, use the **location plm calibrating** command in global configuration mode.

location plm calibrating {**multiband** | **uniband**}

Syntax Description

multiband	Specifies the path loss measurement request for calibrating clients on the associated 802.11a or 802.11b/g radio.
uniband	Specifies the path loss measurement request for calibrating clients on the associated 802.11a/b/g radio.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The uniband is useful for single radio clients (even if the radio is a dual band and can operate in the 2.4-GHz and the 5-GHz bands). The multiband is useful for multiple radio clients.

Examples

This example shows how to configure the path loss measurement request for calibrating clients on the associated 802.11a/b/g radio:

```
Controller# configure terminal
Controller(config)# location plm calibrating uniband
Controller(config)# end
```

location rfid

To configure RFID tag tracking for a location, use the **location rfid** command in global configuration mode. To remove a RFID tag tracking for a location, use the **no** form of this command.

location rfid { **status**| **timeout** *seconds*| **vendor-name** *name*}

no location rfid { **status**| **timeout** *seconds*| **vendor-name**}

Syntax Description

status	Enables location tracking for RFID tags. The no location rfid status command disables location tracking for tags.
timeout <i>seconds</i>	Specifies the location RFID timeout value. Determines the amount of time for which a detected RFID location information is considered as valid. Any RSSI change (below the RSSI threshold) in the configured interval do not result in a new location computation and a message is sent to the MSE. The valid timeout range is from 60 through 7200 seconds.
vendor-name <i>name</i>	Specifies the RFID tag vendor name.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **no location rfid status** command disables location RFID status. The **no location rfid timeout** command returns to the default timeout value. The **no location rfid vendor-name** disables tracking for a particular vendor.

Examples

The example shows how to configure the static RFID tag data timeout:

```
Controller# configure terminal
Controller(config)# location rfid timeout 1000
Controller(config)# end
```

location rssi-half-life

To configure the RSSI half life for various devices, use the **location rssi-half-life** command in global configuration mode. To remove a RSSI half life for various devices, use the **no** form of this command.

location rssi-half-life { **calibrating-client** | **client** | **rogue-aps** | **tags** } *seconds*

no location rssi-half-life { **calibrating-client** | **client** | **rogue-aps** | **tags** }

Syntax Description

calibrating-client	Specifies the RSSI half life for calibrating clients.
client	Specifies the RSSI half life for clients.
rogue-aps	Specifies the RSSI half life for rogue access points.
tags	Specifies the RSSI half life for RFID tags.
<i>seconds</i>	The valid range for the half-life parameter is 0, 1, 2, 5, 10, 20, 30, 60, 90, 120, 180, or 300 seconds, and the default value is 0 seconds.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the half life value for a client RSSI to 100 seconds:

```
Controller# configure terminal
Controller(config)# location rssi-half-life client 100
Controller(config)# end
```

mac address-table control-packet-learn

To enable MAC learning based on control packets, use the **mac address-table control-packet-learn** command in global configuration mode. Use the **no** form of this command to disable this feature.

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how to enable control packet MAC learning:

```
Controller(config)# mac address-table control-packet-learn
Control Pkt Mac learning Enable Successful
```

You can verify your setting by entering the **show mac address-table control-packet-learn** privileged EXEC command.

logging smartlog

To enable smart logging, use the **logging smartlog** command in global configuration mode on the controller. Smart logging sends the contents of specified dropped packets to a Cisco IOS Flexible NetFlow collector. To disable smart logging or return to the default setting, use the **no** form of this command.

logging smartlog [*exporter name* | **packet capture size** *bytes*]

no logging smartlog [*exporter name* | **packet capture size** *bytes*]

Syntax Description

exporter name	(Optional) Identifies the Cisco IOS NetFlow exporter (collector) to which contents of dropped packets are sent. You must have already configured the exporter using the Flexible NetFlow CLI. If the exporter name does not exist, you receive an error message. By default, the controller sends data to the collector every 60 seconds.
packet capture size bytes	(Optional) Specifies the size of the smart log packet sent to the collector in the number of bytes. The range is from 64 to 1024 bytes in 4-byte increments. The default size is 64 bytes. Increasing the packet capture size reduces the number of flow records per packet.

Command Default

By default, smart logging is not enabled.

Command Modes

Global configuration.

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must configure a NetFlow collector before you enable smart logging. For information on configuring Cisco Flexible NetFlow, see the *Cisco IOS Flexible NetFlow Configuration Guide*.

You can configure smart logging of packets dropped due to DHCP snooping violations, Dynamic ARP inspection violations, IP source guard denied traffic, or ACL permitted or denied traffic.

You can verify the configuration by entering the **show logging smartlog** privileged EXEC command.

Examples

This example shows a typical smart logging configuration. It assumes that you have already used the Flexible NetFlow CLI to configure the NetFlow exporter *cisco*, and configures smart logging to capture the first 128 bytes of the packets:

```
Controller(config)# logging smartlog
```

```
Controller(config)# logging smartlog cisco  
Controller(config)# logging smartlog packet capture size 128
```

mgmt_init

To initialize the Ethernet management port, use the **mgmt_init** command in boot loader mode.

mgmt_init

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Boot loader

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Use the **mgmt_init** command only during debugging of the Ethernet management port.

Examples This example shows how to initialize the Ethernet management port:

```
Controller: mgmt_init
```

mkdir

To create one or more directories on the specified file system, use the **mkdir** command in boot loader mode.

mkdir *filesystem:/directory-url...*

Syntax Description

<i>filesystem:</i>	Alias for a file system. Use usbflash0: for USB memory sticks.
<i>/directory-url...</i>	Name of the directories to create. Separate each directory name with a space.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Directory names are case sensitive.

Directory names are limited to 127 characters between the slashes (/); the name cannot contain control characters, spaces, deletes, slashes, quotes, semicolons, or colons.

Examples

This example shows how to make a directory called Saved_Configs:

```
Controller: mkdir usbflash0:Saved_Configs
Directory "usbflash0:Saved_Configs" created
```

more

To display the contents of one or more files, use the **more** command in boot loader mode.

more *filesystem:/file-url...*

Syntax Description

<i>filesystem:</i>	Alias for a file system. Use flash: for the system board flash device.
<i>/file-url...</i>	Path (directory) and name of the files to display. Separate each filename with a space.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Filenames and directory names are case sensitive.

If you specify a list of files, the contents of each file appears sequentially.

Examples

This example shows how to display the contents of a file:

```
Controller: more flash:image_file_name
version_suffix: universal-122-xx.SEx
version_directory: image_file_name
image_system_type_id: 0x00000002
image_name: image_file_name.bin
ios_image_file_size: 8919552
total_image_file_size: 11592192
image_feature: IP|LAYER_3|PLUS|MIN_DRAM_MEG=128
image_family: family
stacking_number: 1.34
board_ids: 0x00000068 0x00000069 0x0000006a 0x0000006b
info_end:
```

nmsp notification interval

To modify the Network Mobility Services Protocol (NMSP) notification interval value on the controller to address latency in the network, use the **nmsp notification interval** command in global configuration mode.

nmsp notification interval { **attachment** | **location** | **rfid** | **rogues** { **ap** | **client** } } }

Syntax Description

attachment	Specifies the time used to aggregate attachment information.
location	Specifies the time used to aggregate location information.
rfid	Specifies the time used to aggregate RSSI information.
clients	Specifies the time interval for clients.
rfid	Specifies the time interval for rfid tags.
rogues	Specifies the time interval for rogue APs and rogue clients .
ap	Specifies the time used to aggregate rogue APs .
client	Specifies the time used to aggregate rogue clients.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to set the NMSP notification interval for the active RFID tags to 25 seconds:

```
Controller# configure terminal
Controller(config)# nmsp notification-interval rfid 25
Controller(config)# end
```

This example shows how to modify NMSP notification intervals for device attachment (connecting to the network or disconnecting from the network) every 10 seconds:

```
Controller# configure terminal
```

```
Controller(config)# nmosp notification-interval attachment 10  
Controller(config)# end
```

This example shows how to configure NMSP notification intervals for location parameters (location change) every 20 seconds:

```
Controller# configure terminal  
Controller(config)# nmosp notification-interval location 20  
Controller(config)# end
```

rename

To rename a file, use the **rename** command in boot loader mode.

```
rename filesystem:/source-file-url filesystem:/destination-file-url
```

Syntax Description

<i>filesystem:</i>	Alias for a file system. Use usbflash0: for USB memory sticks.
<i>/source-file-url</i>	Original path (directory) and filename.
<i>/destination-file-url</i>	New path (directory) and filename.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Filenames and directory names are case sensitive.

Directory names are limited to 127 characters between the slashes (/); the name cannot contain control characters, spaces, deletes, slashes, quotes, semicolons, or colons.

Filenames are limited to 127 characters; the name cannot contain control characters, spaces, deletes, slashes, quotes, semicolons, or colons.

Examples

This example shows a file named *config.text* being renamed to *config1.text*:

```
Controller: rename usbflash0:config.text usbflash0:config1.text
```

You can verify that the file was renamed by entering the **dir filesystem:** boot loader command.

reset

To perform a hard reset on the system, use the **reset** command in boot loader mode. A hard reset is similar to power-cycling the controller; it clears the processor, registers, and memory.

reset

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Boot loader

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how to reset the system:

```
Controller: reset
Are you sure you want to reset the system (y/n)? y
System resetting...
```

rmdir

To remove one or more empty directories from the specified file system, use the **rmdir** command in boot loader mode.

rmdir *filesystem:/directory-url...*

Syntax Description

<i>filesystem:</i>	Alias for a file system. Use usbflash0: for USB memory sticks.
<i>/directory-url...</i>	Path (directory) and name of the empty directories to remove. Separate each directory name with a space.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Directory names are case sensitive and limited to 45 characters between the slashes (/); the name cannot contain control characters, spaces, deletes, slashes, quotes, semicolons, or colons.

Before removing a directory, you must first delete all of the files in the directory.

The controller prompts you for confirmation before deleting each directory.

Examples

This example shows how to remove a directory:

```
Controller: rmdir usbflash0:Test
```

You can verify that the directory was deleted by entering the **dir filesystem:** boot loader command.

set

To set or display environment variables, use the **set** command in boot loader mode. Environment variables can be used to control the boot loader or any other software running on the controller.

set *variable value*

Syntax Description

<i>variable</i>	Use one of the following keywords for <i>variable</i> and the appropriate value for <i>value</i> :
<i>value</i>	<p>MANUAL_BOOT—Decides whether the controller automatically or manually boots. Valid values are 1/Yes and 0/No. If it is set to 0 or No, the boot loader attempts to automatically boot the system. If it is set to anything else, you must manually boot the controller from the boot loader mode.</p> <p>BOOT <i>filesystem:/file-url</i>—Identifies a semicolon-separated list of executable files to try to load and execute when automatically booting. If the BOOT environment variable is not set, the system attempts to load and execute the first executable image it can find by using a recursive, depth-first search through the flash: file system. If the BOOT variable is set but the specified images cannot be loaded, the system attempts to boot the first bootable file that it can find in the flash: file system.</p> <p>ENABLE_BREAK—Allows the automatic boot process to be interrupted when the user presses the Break key on the console. Valid values are 1, Yes, On, 0, No, and Off. If set to 1, Yes, or On, you can interrupt the automatic boot process by pressing the Break key on the console after the flash: file system has initialized.</p> <p>HELPER <i>filesystem:/file-url</i>—Identifies a semicolon-separated list of loadable files to dynamically load during the boot loader initialization. Helper files extend or patch the functionality of the boot loader.</p> <p>PS1 <i>prompt</i>—Specifies a string that is used as the command-line prompt in boot loader mode.</p> <p>CONFIG_FILE flash: <i>/file-url</i>—Specifies the filename that Cisco IOS uses to read and write a nonvolatile copy of the system configuration.</p> <p>BAUD <i>rate</i>—Specifies the number of bits per second (b/s) that is used for the baud rate for the console. The Cisco IOS software inherits the baud rate setting from the boot loader and continues to use this value unless the configuration file specifies another setting. The range is from 0 to 128000 b/s. Valid values are 50, 75, 110, 150, 300, 600, 1200, 1800, 2000, 2400, 3600, 4800, 7200, 9600, 14400, 19200, 28800, 38400, 56000, 57600, 115200, and 128000. The most commonly used values are 300, 1200, 2400, 9600, 19200, 57600, and 115200.</p> <p>SWITCH_NUMBER <i>stack-member-number</i>—Changes the member number of a stack member.</p> <p>SWITCH_PRIORITY <i>priority-number</i>—Changes the priority value of a stack member.</p>

Command Default

The environment variables have these default values:

MANUAL_BOOT: No (0)

BOOT: Null string

ENABLE_BREAK: No (Off or 0) (the automatic boot process cannot be interrupted by pressing the **Break** key on the console).

HELPER: No default value (helper files are not automatically loaded).

PS1 controller:

CONFIG_FILE: config.text

BAUD: 9600 b/s

SWITCH_NUMBER: 1

SWITCH_PRIORITY: 1

**Note**

Environment variables that have values are stored in the flash: file system in various files. Each line in the files contains an environment variable name and an equal sign followed by the value of the variable.

A variable has no value if it is not listed in these files; it has a value if it is listed even if the value is a null string. A variable that is set to a null string (for example, “ ”) is a variable with a value.

Many environment variables are predefined and have default values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Environment variables are case sensitive and must be entered as documented.

Environment variables that have values are stored in flash memory outside of the flash: file system.

Under typical circumstances, it is not necessary to alter the setting of the environment variables.

The MANUAL_BOOT environment variable can also be set by using the **boot manual** global configuration command.

The BOOT environment variable can also be set by using the **boot system filesystem:/file-url** global configuration command.

The ENABLE_BREAK environment variable can also be set by using the **boot enable-break** global configuration command.

The HELPER environment variable can also be set by using the **boot helper filesystem: /file-url** global configuration command.

The CONFIG_FILE environment variable can also be set by using the **boot config-file flash: /file-url** global configuration command.

The SWITCH_NUMBER environment variable can also be set by using the **switch current-stack-member-number renumber new-stack-member-number** global configuration command.

The SWITCH_PRIORITY environment variable can also be set by using the controller **stack-member-number priority priority-number** global configuration command.

The boot loader prompt string (PS1) can be up to 120 printable characters not including the equal sign (=).

Examples

This example shows how to set the SWITCH_PRIORITY environment variable:

```
Controller: set SWITCH_PRIORITY 2
```

You can verify your setting by using the **set** boot loader command.

show avc client

To display information about top number of applications, use the **show avc client** command in privileged EXEC mode.

show avc client *client-mac* **top n application** [**aggregate** | **upstream** | **downstream**]

Syntax Description

client <i>client-mac</i>	Specifies the client MAC address.
top n application	Specifies the number of top "N" applications for the given client.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

The following is sample output from the **show avc client** command:

```
Controller# sh avc client 0040.96ae.65ec top 10 application aggregate
```

Cumulative Stats:

No.	AppName	Packet-Count	Byte-Count	AvgPkt-Size	usage%
1	skinny	7343	449860	61	94
2	unknown	99	13631	137	3
3	dhcp	18	8752	486	2
4	http	18	3264	181	1
5	tftp	9	534	59	0
6	dns	2	224	112	0

Last Interval (90 seconds) Stats:

No.	AppName	Packet-Count	Byte-Count	AvgPkt-Size	usage%
1	skinny	9	540	60	100

show avc wlan

To display information about top applications and users using the applications, use the **show avc wlan** command in privileged EXEC mode.

show avc wlan ssid top n application [aggregate | upstream | downstream]

Syntax Description

wlan ssid	Specifies the Service Set Identifier (SSID) for WLAN.
top n application	Specifies the number of top "N" applications.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

The following is sample output from the **show avc wlan** command:

```
Controller# show avc wlan Lobby_WLAN top 10 application aggregate
```

Cumulative Stats:

No.	AppName	Packet-Count	Byte-Count	AvgPkt-Size	usage%
1	ssl	10598677	1979525706	997	42
2	vnc	5550900	3764612847	678	14
3	http	3043131	2691327197	884	10
4	unknown	1856297	1140264956	614	4
5	video-over-http	1625019	2063335150	1269	8
6	binary-over-http	1329115	1744190344	1312	6
7	webex-meeting	1146872	540713787	471	2
8	rtp	923900	635650544	688	2
9	unknown	752341	911000213	1210	3
10	youtube	631085	706636186	1119	3

Last Interval (90 seconds) Stats:

No.	AppName	Packet-Count	Byte-Count	AvgPkt-Size	usage%
1	vnc	687093	602731844	877	68
2	video-over-http	213272	279831588	1312	31
3	ssl	6515	5029365	771	1
4	webex-meeting	3649	1722663	472	0
5	http	2634	1334355	506	0
6	unknown	1436	99412	69	0
7	google-services	722	378121	523	0
8	linkedin	655	393263	600	0
9	exchange	432	167390	387	0

10	gtalk-chat	330	17330	52	0
----	------------	-----	-------	----	---

show cable-diagnostics tdr

To display the Time Domain Reflector (TDR) results, use the **show cable-diagnostics tdr** command in privileged EXEC mode.

show cable-diagnostics tdr interface *interface-id*

Syntax Description	<i>interface-id</i>	Specifies the interface on which TDR is run.
---------------------------	---------------------	--

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines TDR is supported only on 10/100/100 copper Ethernet ports. It is not supported on 10-Gigabit Ethernet ports and small form-factor pluggable (SFP) module ports.

Examples This example shows the output from the **show cable-diagnostics tdr interface** *interface-id* command on a controller:

```

Controller# show cable-diagnostics tdr interface gigabitethernet1/0/23
TDR test last run on: March 01 00:04:08
Interface Speed Local pair Pair length Remote pair Pair status
-----
Gi1/0/23 1000M Pair A 1 +/- 1 meters Pair A Normal
          Pair B 1 +/- 1 meters Pair B Normal
          Pair C 1 +/- 1 meters Pair C Normal
          Pair D 1 +/- 1 meters Pair D Normal

```

Table 5: Field Descriptions for the show cable-diagnostics tdr Command Output

Field	Description
Interface	The interface on which TDR is run.
Speed	The speed of connection.
Local pair	The name of the pair of wires that TDR is testing on the local interface.

Field	Description
Pair length	<p>The location of the problem on the cable, with respect to your controller. TDR can only find the location in one of these cases:</p> <ul style="list-style-type: none"> • The cable is properly connected, the link is up, and the interface speed is 1000 Mb/s. • The cable is open. • The cable has a short.
Remote pair	<p>The name of the pair of wires to which the local pair is connected. TDR can learn about the remote pair only when the cable is properly connected and the link is up.</p>
Pair status	<p>The status of the pair of wires on which TDR is running:</p> <ul style="list-style-type: none"> • Normal—The pair of wires is properly connected. • Not completed—The test is running and is not completed. • Not supported—The interface does not support TDR. • Open—The pair of wires is open. • Shorted—The pair of wires is shorted. • ImpedanceMis—The impedance is mismatched. • Short/Impedance Mismatched—The impedance mismatched or the cable is short. • InProgress—The diagnostic test is in progress.

This example shows the output from the **show interface** *interface-id* command when TDR is running:

```
Controller# show interface gigabitethernet1/0/2
gigabitethernet1/0/2 is up, line protocol is up (connected: TDR in Progress)
```

This example shows the output from the **show cable-diagnostics tdr interface** *interface-id* command when TDR is not running:

```
Controller# show cable-diagnostics tdr interface gigabitethernet1/0/2
% TDR test was never issued on gigabitethernet1/0/2
```

If an interface does not support TDR, this message appears:

```
% TDR test is not supported on controller 1
```

show flow monitor

To display the status and statistics for a flow monitor, use the **show flow monitor** command in privileged EXEC mode.

Syntax Description

name	(Optional) Specifies the name of a flow monitor.
<i>monitor-name</i>	(Optional) Name of a flow monitor that was previously configured.
cache	(Optional) Displays the contents of the cache for the flow monitor.
format	(Optional) Specifies the use of one of the format options for formatting the display output.
csv	(Optional) Displays the flow monitor cache contents in comma-separated variables (CSV) format.
record	(Optional) Displays the flow monitor cache contents in record format.
table	(Optional) Displays the flow monitor cache contents in table format.
statistics	(Optional) Displays the statistics for the flow monitor.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **cache** keyword uses the record format by default.

The uppercase field names in the display output of the **show flowmonitor monitor-name cache** command are key fields that uses to differentiate flows. The lowercase field names in the display output of the **show flow monitor monitor-name cache** command are nonkey fields from which collects values as additional data for the cache.

Examples

The following example displays the status for a flow monitor:

```
Controller# show flow monitor FLOW-MONITOR-1

Flow Monitor FLOW-MONITOR-1:
  Description:      Used for basic traffic analysis
  Flow Record:     flow-record-1
  Flow Exporter:   flow-exporter-1
                  flow-exporter-2
  Cache:
```

```

Type:          normal
Status:        allocated
Size:          4096 entries / 311316 bytes
Inactive Timeout: 15 secs
Active Timeout: 1800 secs

```

This table describes the significant fields shown in the display.

Table 6: show flow monitor monitor-name Field Descriptions

Field	Description
Flow Monitor	Name of the flow monitor that you configured.
Description	Description that you configured or the monitor, or the default description User defined.
Flow Record	Flow record assigned to the flow monitor.
Flow Exporter	Exporters that are assigned to the flow monitor.
Cache	Information about the cache for the flow monitor.
Type	Flow monitor cache type. The value is always normal, as it is the only supported cache type.
Status	Status of the flow monitor cache. The possible values are: <ul style="list-style-type: none"> • allocated—The cache is allocated. • being deleted—The cache is being deleted. • not allocated—The cache is not allocated.
Size	Current cache size.
Inactive Timeout	Current value for the inactive timeout in seconds.
Active Timeout	Current value for the active timeout in seconds.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1:

This table describes the significant fields shown in the display.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1 in a table format:

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-IPv6 (the cache contains IPv6 data) in record format:

The following example displays the status and statistics for a flow monitor:

show license right-to-use

To display detailed information for ap-count adder licenses installed on the controller, use the **show license right-to-use** command in privileged EXEC mode.

show licenseright-to-use {default| detail| eula | mismatch| slot| summary| usage }

Syntax Description

default	Displays the default license.
detail	Displays details of all of the licenses.
eula	Displays the EULA content for the adder and evaluation ap-count licenses.
mismatch	Displays mismatch license information.
slot	Specifies the switch number.
summary	Displays consolidated stack-wide license information.
usage	Displays the usage details of all licenses.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **show license right-to-use** command and displays all of the available licenses:

```

Controller# show license right-to-use
Slot#  License name  Type      Count  Period left
-----
1      apcount           evaluation 1000   Expired
1      apcount           adder      125    Lifetime

```

The following is sample output from the **show license right-to-use usage** command and displays the usage of licenses:

```
Controller# show license right-to-use usage
Slot# License Name      Type      usage-duration(y:m:d)  In-Use  EULA
-----
1      apcount              evaluation  0 :2 :14                no      no
1      apcount              adder      0 :0 :1                  yes     yes
```

The following is sample output from the **show license right-to-use detail** command and displays the detailed information of licenses:

```
Controller# show license right-to-use detail

Index 1: License Name: apcount
         Period left: 16
         License Type: evaluation
         License State: Not Activated
         License Count: 1000
         License Location: Slot 1
Index 2: License Name: apcount
         Period left: Lifetime
         License Type: adder
         License State: Active, In use
         License Count: 125
         License Location: Slot 1
```

The following is sample output from the **show license right-to-use summary** command when the evaluation license is active:

```
Controller# show license right-to-use summary
License Name      Type      Count  Period left
-----
apcount          evaluation  1000   50

-----

Evaluation AP-Count: Enabled
Total AP Count Licenses: 1000
AP Count Licenses In-use: 100
AP Count Licenses Remaining: 900
```

The following is sample output from the **show license right-to-use summary** command when the adder licenses are active:

```
Controller#
License Name      Type      Count  Period left
-----
apcount          adder      125    Lifetime

-----

Evaluation AP-Count: Disabled
Total AP Count Licenses: 125
AP Count Licenses In-use: 100
AP Count Licenses Remaining: 25
```

show location

To display location information, use the **show location** command in privileged EXEC mode.

```
show location {detail mac-addr| plm| statistics| summary rfid| rfid {client| config| detail MAC-addr| summary}}
```

Syntax Description

detail <i>mac-addr</i>	Displays detailed location information with the RSSI table for a particular client.
plm	Displays location path loss measurement (CCX S60) configuration.
statistics	Displays location-based system statistics.
summary	Displays location-based system summary information.
rfid	Displays the RFID tag tracking information.
client	Displays the summary of RFID tags that are clients.
config	Displays the configuration options for RFID tag tracking.
detail <i>MAC-addr</i>	Displays the detailed information for one rfid tag.
summary	Displays summary information for all known rfid tags.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **show location plm** command:

```
Controller# show location plm
Location Path Loss Configuration

Calbration client      : Disabled, Radio: Multiband
Normal clients        : Disabled
Burst interval        : 60
```

show location ap-detect

To display the location information detected by specified access point, use the **show location ap-detect** command in privileged EXEC mode.

show location ap-detect {**all**| **client**| **rfid**| **rogue-ap**| **rogue-client**} *ap-name*

Syntax Description

all	Displays information of the client, RFID, rogue access point, and rogue client.
client	Displays the client information.
rfid	Displays RFID information.
rogue-ap	Displays rogue access point information.
rogue-client	Displays rogue client information.
<i>ap-name</i>	Specified access point name.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **show location ap-detect client** command:

```
Controller# show location ap-detect client AP02
Clients
-----
MAC Address      Status           Slot  Antenna  RSSI
-----
2477.0389.96ac  Associated       1     0        -60
2477.0389.96ac  Associated       1     1        -61
2477.0389.96ac  Associated       0     0        -46
2477.0389.96ac  Associated       0     1        -41

RFID Tags

Rogue AP's
```

Rogue Clients

MAC Address	State	Slot	Rssi
0040.96b3.bce6	Alert	1	-58
586d.8ff0.891a	Alert	1	-72

show mac address-table control-packet-learn

To display MAC learning based on control packets, use the **show mac address-table control-packet-learn** command in privileged EXEC mode. Use the **no** form of this command to disable this feature.

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows the output from the **show mac address-table control-packet-learn** command:

```
Controller(config)# show mac address-table control-packet-learn
Control Packet Mac Learning is Enabled
```

show mac address-table move update

To display the MAC address-table move update information on the controller, use the **show mac address-table move update** command in EXEC mode.

show mac address-table move update

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows the output from the **show mac address-table move update** command:

```
Controller# show mac address-table move update
Switch-ID : 010b.4630.1780
Dst mac-address : 0180.c200.0010
Vlans/Macs supported : 1023/8320
Default/Current settings: Rcv Off/On, Xmt Off/On
Max packets per min : Rcv 40, Xmt 60
Rcv packet count : 10
Rcv conforming packet count : 5
Rcv invalid packet count : 0
Rcv packet count this min : 0
Rcv threshold exceed count : 0
Rcv last sequence# this min : 0
Rcv last interface : Po2
Rcv last src-mac-address : 0003.fd6a.8701
Rcv last switch-ID : 0303.fd63.7600
Xmt packet count : 0
Xmt packet count this min : 0
Xmt threshold exceed count : 0
Xmt pak buf unavail cnt : 0
Xmt last interface : None
```

show nmosp

To display the Network Mobility Services Protocol (NMSP) configuration settings, use the **show nmosp** command.

show nmosp {**attachment** | {**suppress interfaces**} | **capability**| **notification interval**| **statistics** {**connection**| **summary**} | **status**| **subscription detail** [*ip-addr*]| **summary**}

Syntax Description

attachment suppress interfaces	Displays attachment suppress interfaces.
capability	Displays NMSP capabilities.
notification interval	Displays the NMSP notification interval.
statistics connection	Displays all connection-specific counters.
statistics summary	Displays the NMSP counters.
status	Displays status of active NMSP connections.
subscription detail <i>ip-addr</i>	The details are only for the NMSP services subscribed to by a specific IP address.
subscription summary	Displays details for all of the NMSP services to which the controller is subscribed. The details are only for the NMSP services subscribed to by a specific IP address.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **show nmosp notification interval** command:

```
Controller# show nmosp notification interval
NMSP Notification Intervals
-----
RSSI Interval:
  Client           : 2 sec
  RFID             : 2 sec
```

```
Rogue AP           : 2 sec  
Rogue Client       : 2 sec  
Attachment Interval : 30 sec  
Location Interval  : 30 sec
```

show tech-support wireless

To display Cisco wireless LAN controller variables frequently requested by Cisco Technical Assistance Center (TAC), use the **show tech-support wireless** command in privileged EXEC mode.

show tech-support wireless

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **show tech-support wireless** command:

```
Controller# show tech-support wireless
*** show ap capwap timers ***
```

```
Cisco AP CAPWAP timers
```

```
AP Discovery timer      : 10
AP Heart Beat timeout  : 30
Primary Discovery timer : 120
Primed Join timeout    : 0
Fast Heartbeat         : Disabled
Fast Heartbeat timeout : 1
```

```
*** show ap capwap retransmit ***
```

```
Global control packet retransmit interval : 3
Global control packet retransmit count : 5
```

AP Name	Retransmit Interval	Retransmit Count
TSIM_AP-2	3	5
TSIM_AP-3	3	5

```
-----
*** show ap dot11 24ghz cleanair air-quality summary ***
```

```
AQ = Air Quality
DFS = Dynamic Frequency Selection
```

```
*** show ap dot11 24ghz cleanair air-quality worst ***
```

```
AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel  Avg AQ  Min AQ  Interferers  DFS
-----
```

```
0           0       0       0       0             No
```

```
*** show ap dot11 24ghz cleanair config ***
```

```
Clean Air Solution..... : Disabled
Air Quality Settings:
  Air Quality Reporting..... : Disabled
```

```

Air Quality Reporting Period (min)..... : 15
Air Quality Alarms..... : Enabled
Air Quality Alarm Threshold..... : 10
Interference Device Settings:
Interference Device Reporting..... : Enabled
Bluetooth Link..... : Enabled
Microwave Oven..... : Enabled
802.11 FH..... : Enabled
Bluetooth Discovery..... : Enabled
TDD Transmitter..... : Enabled
Jammer..... : Enabled
Continuous Transmitter..... : Enabled
DECT-like Phone..... : Enabled
Video Camera..... : Enabled
802.15.4..... : Enabled
WiFi Inverted..... : Enabled
WiFi Invalid Channel..... : Enabled
SuperAG..... : Enabled
Canopy..... : Enabled
Microsoft Device..... : Enabled
WiMax Mobile..... : Enabled
WiMax Fixed..... : Enabled
Interference Device Types Triggering Alarms:
Bluetooth Link..... : Disabled
Microwave Oven..... : Disabled
802.11 FH..... : Disabled
Bluetooth Discovery..... : Disabled
TDD Transmitter..... : Disabled
Jammer..... : Disabled
Continuous Transmitter..... : Disabled
DECT-like Phone..... : Disabled
Video Camera..... : Disabled
802.15.4..... : Disabled
WiFi Inverted..... : Enabled
WiFi Invalid Channel..... : Enabled
SuperAG..... : Disabled
Canopy..... : Disabled
Microsoft Device..... : Disabled
WiMax Mobile..... : Disabled
WiMax Fixed..... : Disabled
Interference Device Alarms..... : Enabled
Additional Clean Air Settings:
CleanAir Event-driven RRM State..... : Disabled
CleanAir Driven RRM Sensitivity..... : LOW
CleanAir Persistent Devices state..... : Disabled

```

show wireless band-select

To display the status of the band-select configuration, use the **show wireless band-select** command in privileged EXEC mode.

show wireless band-select

Syntax Description

This command has no arguments or keywords.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **show wireless band-select** command:

```
Controller# show wireless band-select
Band Select Probe Response    : per WLAN enabling
Cycle Count                   : 2
Cycle Threshold (millisec)    : 200
Age Out Suppression (sec)     : 20
Age Out Dual Band (sec)       : 60
Client RSSI (dBm)             : 80
```

show wireless client calls

To display the total number of active or rejected calls on the controller, use the **show wireless client calls** command in privileged EXEC mode.

show wireless client calls {active | rejected}

Syntax Description

active	Displays active calls.
rejected	Displays rejected calls.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **show wireless client calls** command:

```
controller# show wireless client calls active
```

```
TSPEC Calls:
```

```
-----
MAC Address      AP Name          Status           WLAN  Authenticated
-----
0000.1515.000f   AP-2            Associated       1    Yes
```

```
SIP Calls:
```

```
-----
Number of Active TSPEC calls on 802.11a and 802.11b/g: 1
Number of Active SIP calls on 802.11a and 802.11b/g: 0
```

show wireless client dot11

To display the total number of active or rejected calls for a specific band (2.4 Ghz or 5 Ghz), use the **show wireless client dot11** command in privileged EXEC mode.

show wireless client dot11 {24ghz | 5ghz} calls {active | rejected}

Syntax Description

24ghz	Displays the 802.11b/g network.
5ghz	Displays the 802.11a network.
calls	Displays the wireless client calls.
active	Displays active calls.
rejected	Displays rejected calls.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **show wireless client dot11** command:

```
Controller# show wireless client dot11 5ghz calls active
```

```
TSPEC Calls:
-----
```

```
SIP Calls:
-----
```

```
Number of Active TSPEC calls on 802.11a: 0
Number of Active SIP calls on 802.11a: 0
```

show wireless client location-calibration

To display the list of clients currently used to perform location calibration, use the **show wireless client location-calibration** command in privileged EXEC mode.

show wireless client location-calibration

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples The following is sample output from the **show wireless client location-calibration** command:

```
Controller# show wireless client location-calibration
```

show wireless client probing

To display the number of probing clients, use the **show wireless client probing** command in privileged EXEC mode.

show wireless client probing

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples The following is sample output from the **show wireless client probing** command:

```
Controller# show wireless client probing
MAC Address
-----
000b.cd15.0001
000b.cd15.0002
000b.cd15.0003
000b.cd15.0004
000b.cd15.0005
000b.cd15.0006
```

show wireless client summary

To display a summary of active clients associated with the controller, use the **show wireless client summary** command in privileged EXEC mode.

show wireless client summary

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines The following is sample output from the **show wireless client summary** command:
Use the **show wireless exclusionlist** command to display clients on the exclusion list (blacklisted).

Examples

```
Controller# show wireless client summary
Number of Local Clients : 1
```

```
MAC Address      AP Name          WLAN State      Protocol
-----
0000.1515.000f  AP-2             1 UP             11a
```

show wireless client timers

To display 802.11 system timers, use the **show wireless client timers** command in privileged EXEC mode.

show wireless client timers

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples The following is sample output from the **show wireless client timers** command:

```
Controller# show wireless client timers
Authentication Response Timeout (seconds)      : 10
```

show wireless client voice diagnostics

To display wireless client voice diagnostic parameters, use the **show wireless client voice diagnostics** command in privileged EXEC mode.

show wireless client voice diagnostics {**qos-map** | **roam-history** | **rsi** | **status** | **tspec**}

Syntax Description

qos-map	Displays information about the QoS and DSCP mapping and packet statistics in each of the four queues: VO, VI, BE, BK. The different DSCP values are also displayed.
roam-history	Displays information about the last 3 roaming histories for each known client. The output contains the timestamp, access point associated with roaming, roaming reason, and if there is a roaming failure, a reason for the roaming failure.
rsi	Displays the client's RSSI values in the last 5 seconds when voice diagnostics are enabled.
status	Displays status of voice diagnostics for clients.
tspec	Displays voice diagnostics that are enabled for TSPEC clients.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Debug voice diagnostics must be enabled for voice diagnostics to work.

Examples

The following is sample output from the **show wireless client voice diagnostics status** command:

```
Controller# show wireless client voice diagnostics status
Voice Diagnostics Status: FALSE
```

show wireless country

To display the configured country and the radio types supported, use the **show wireless country** command in privileged EXEC mode.

show wireless country {channels| configured| supported [tx-power]}

Syntax Description		
channels	Displays the list of possible channels for each band, and the list of channels allowed in the configured countries.	
configured	Display configured countries.	
supported tx-power	Displays the list of allowed Tx powers in each supported country.	

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **show wireless country channels** command:

```

Controller# show wireless country channels
  Configured Country.....: US - United States
  KEY: * = Channel is legal in this country and may be configured manually.
       A = Channel is the Auto-RF default in this country.
       . = Channel is not legal in this country.
       C = Channel has been configured for use by Auto-RF.
       x = Channel is available to be configured for use by Auto-RF.
       (-,-) = (indoor, outdoor) regulatory domain allowed by this country.
-----:+++++-----
      802.11bg
      Channels          :          1 1 1 1 1
      : 1 2 3 4 5 6 7 8 9 0 1 2 3 4
-----:+++++-----
(-A , -AB ) US : A * * * * A * * * * A . . .
Auto-RF       : . . . . .
-----:+++++-----
      802.11a
      Channels          :          1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
      : 3 3 3 4 4 4 4 4 4 5 5 6 6 0 0 0 1 1 2 2 2 3 3 4 4 5 5 6 6
      : 4 6 8 0 2 4 6 8 2 6 0 4 0 4 8 2 6 0 4 8 2 6 0 9 3 7 1 5
-----:+++++-----
(-A , -AB ) US : . A . A . A . A A A A A * * * * . . . * * * A A A A *
Auto-RF       : . . . . .
-----:+++++-----
      4.9GHz 802.11a
      Channels          :          1 1 1 1 1 1 1 1 1 1 2 2 2 2 2 2
      : 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
  
```



```

(-JPU , -JPU ) J3 : 23 23 23 23 23 23 23 23 23 23 23 23 23 23
(-JPQU, -PQ ) J4 : 23 23 23 23 23 23 23 23 23 23 23 23 23 23
(-E , - ) JO : 20 20 20 20 20 20 20 20 20 20 20 20 20 20
(-JPU , -JPU ) JP : 23 23 23 23 23 23 23 23 23 23 23 23 23 23
(-ACE , -ACEK) KE : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) KN : 20 20 20 20 20 20 20 20 20 20 20 20 20 20
(-ACE , -ACEK) KR : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) KW : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) KZ : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) LB : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) LI : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) LK : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) LT : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) LU : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) LV : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) MC : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) ME : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) MK : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) MO : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) MT : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-A , -NA ) MX : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-ACE , -AEC ) MY : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) NL : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) NO : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-A , -NA ) NZ : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-E , -E ) OM : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-A , -AR ) PA : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-A , -AR ) PE : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-A , -ABN ) PH : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-A , -ABN ) PH2 : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-E , -E ) PK : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) PL : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-A , -A ) PR : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-E , -E ) PT : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-A , -A ) PY : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-E , -E ) QA : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) RO : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) RS : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-AER , -ER ) RU : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-AE , -AE ) SA : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) SE : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -SE ) SG : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) SI : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) SK : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -ER ) TH : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) TN : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-EI , -E ) TR : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-A , -ANT ) TW : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-E , -E ) UA : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-A , -AB ) US : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-A , -AB ) US2 : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-A , -AB ) USL : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-A , - ) USX : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-A , -A ) UY : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-A , -AR ) VE : 27 27 27 27 27 27 27 27 27 27 27 27 27
(-E , -E ) VN : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) ZA : 20 20 20 20 20 20 20 20 20 20 20 20 20

```

show wireless detail

To display the details of the wireless parameters configured, use the **show wireless detail** command in privileged EXEC mode.

show wireless detail

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines The following parameters are displayed:

- The wireless user idle timeout
- The controller configured RF group name
- Fast SSID change

Examples The following is sample output from the **show wireless detail** command:

```
Controller# show wireless detail
User Timeout      : 300
RF network        : default
Fast SSID         : Disabled
```

show wireless dtls connections

To display the Datagram Transport Layer Security (DTLS) server status, use the **show wireless dtls connections** command in privileged EXEC mode.

show wireless dtls connections

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **show wireless dtls connections** command:

```

Controller# show wireless dtls connections
AP Name           Local Port  Peer IP    Peer Port  Ciphersuite
-----
AP-2              Capwap_Ctrl 10.0.0.16  52346     TLS_RSA_WITH_AES_128_CBC_SHA
AP-3              Capwap_Ctrl 10.0.0.17  52347     TLS_RSA_WITH_AES_128_CBC_SHA

```

show wireless flow-control

To display the information about flow control on a particular channel, use the **show wireless flow-control** command in privileged EXEC mode.

show wireless flow-control *channel-id*

Syntax Description	<i>channel-id</i>	Identification number for a channel through which flow control is monitored.
Command Default	No default behavior or values.	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Examples

The following is sample output from the **show wireless flow-control** *channel-id* command:

```
Controller# show wireless flow-control 3
Channel Name           : CAPWAP
FC State                : Disabled
Remote Server State    : Enabled
Pass-thru Mode         : Disabled
EnQ Disabled           : Disabled
Queue Depth            : 2048
Max Retries            : 5
Min Retry Gap (mSec)   : 3
```

show wireless flow-control statistics

To display the complete information about flow control on a particular channel, use the **show wireless flow-control statistics** command in privileged EXEC mode.

show wireless flow-control *channel-id* **statistics**

Syntax Description	<i>channel-id</i>	Identification number for a channel through which flow control is monitored.
Command Default	No default behavior or values.	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Examples

The following is sample output from the **show wireless flow-control channel-id statistics** command:

```
Controller# show wireless flow-control 3 statistics
Channel Name                : CAPWAP
# of times channel went into FC      : 0
# of times channel came out of FC    : 0
Total msg count received by the FC Infra : 1
Pass-thru msgs send count           : 0
Pass-thru msgs fail count           : 0
# of msgs successfully queued        : 0
# of msgs for which queuing failed   : 0
# of msgs sent thru after queuing    : 0
# of msgs sent w/o queuing           : 1
# of msgs for which send failed      : 0
# of invalid EAGAINS received        : 0
Highest watermark reached            : 0
# of times Q hit max capacity        : 0
Avg time channel stays in FC (mSec)  : 0
```

show wireless load-balancing

To display the status of the load-balancing feature, use the **show wireless load-balancing** command in privileged EXEC mode.

show wireless load-balancing

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples The following is sample output from the **show wireless load-balancing** command:

```
> show wireless load-balancing
Aggressive Load Balancing.....: per WLAN enabling
Aggressive Load Balancing Window (clients).....: 5
Aggressive Load Balancing Denial Count.....: 3

Statistics
Total Denied Count (clients).....: 0
Total Denial Sent (messages).....: 0
Exceeded Denial Max Limit Count (times).....: 0
None 5G Candidate Count (times).....: 0
None 2.4G Candidate Count (times).....: 0
```

show wireless performance

To display aggressive load balancing configuration, use the **show wireless performance** command in privileged EXEC mode.

show wireless performance {ap| client} summary

Syntax Description

ap summary	Displays aggressive load balancing configuration of access points configured to the controller.
client summary	Displays aggressive load balancing configuration details of the clients.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **show wireless performance ap summary** command.

```
Controller# show wireless performance ap summary
Number of APs:
```

The following is sample output from the **show wireless performance client summary** command.

```
Controller# show wireless performance client summary
Number of Clients:
```

```
MAC Address      AP Name          Status          WLAN/Guest-Lan Auth Protocol Port Wired
-----
```

show wireless pmk-cache

To display information about the pairwise master key (PMK) cache, use the **show wireless pmk-cache** command in privileged EXEC mode.

show wireless pmk-cache[**mac-address** *mac-addr*]

Syntax Description

mac-address *mac-addr* (Optional) Information about a single entry in the PMK cache.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **show wireless pmk-cache mac-address** command:

```
Controller# show wireless pmk-cache mac-address H.H.H
Number of PMK caches in total : 0
```

show wireless probe

To display the advanced probe request filtering configuration and the number of probes sent to the WLAN controller per access point per client and the probe interval in milliseconds, use the **show wireless probe** command in privileged EXEC mode.

show wireless probe

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples The following is sample output from the **show wireless probe** command:

```

Controller# show wireless probe
Probe request filtering           : Enabled
Number of probes per client per radio fwd from AP: 2
Probe request rate-limiting interval : 500 msec
Aggregate probe request interval   : 500 msec

```

show wireless sip preferred-call-no

To display SIP preferred call numbers, use the **show wireless sip preferred-call-no** command in privileged EXEC mode.

show wireless sip preferred-call-no

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples The following is sample output from the **show wireless sip preferred-call-no** command:

```
Controller# show wireless sip preferred-call-no
Index Preferred-Number
-----
1      1031
2      1032
4      1034
```

show wireless summary

To display the number of access points, radios and wireless clients known to the controller, use the **show wireless summary** command in privileged EXEC mode.

show wireless summary

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples The following is sample output from the **show wireless summary** command:

```

Controller# show wireless summary

Access Point Summary

-----
                Total      Up      Down
-----
802.11a/n         2         2         0
802.11b/g/n         2         2         0
All APs           2         2         0

Client Summary

Current Clients : 1
Excluded Clients: 0
Disabled Clients: 0

```

shutdown

To shut down VLAN switching, use the **shutdown** command in global configuration mode. To disable the configuration set, use the **no** form of this command.

shutdown [**vlan** *vlan-id*]

no shutdown

Syntax Description

vlan <i>vlan-id</i>	VLAN ID of VLAN to shutdown.
----------------------------	------------------------------

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to shutdown a VLAN:

```
Controller(config)# vlan open1
Controller(config-wlan)# shutdown
```

This example shows that the access point is not shut down:

```
Controller# configure terminal
Controller(config)# ap name 3602a no shutdown
```

system env temperature threshold yellow

To configure the difference between the yellow and red temperature thresholds that determines the value of yellow threshold, use the **system env temperature threshold yellow** command in global configuration mode. To return to the default value, use the **no** form of this command.

system env temperature threshold yellow *value*

no system env temperature threshold yellow *value*

Syntax Description

value Specifies the difference between the yellow and red threshold values (in Celsius). The range is 10 to 25.

Command Default

These are the default values

Table 7: Default Values for the Temperature Thresholds

Controller	Difference between Yellow and Red	Red ¹
	14°C	60°C

¹ You cannot configure the red temperature threshold.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You cannot configure the green and red thresholds but can configure the yellow threshold. Use the **system env temperature threshold yellow** *value* global configuration command to specify the difference between the yellow and red thresholds and to configure the yellow threshold. For example, if the red threshold is 66 degrees C and you want to configure the yellow threshold as 51 degrees C, set the difference between the thresholds as 15 by using the **system env temperature threshold yellow 15** command. For example, if the red threshold is 60 degrees C and you want to configure the yellow threshold as 51 degrees C, set the difference between the thresholds as 15 by using the **system env temperature threshold yellow 9** command.



Note

The internal temperature sensor in the controller measures the internal system temperature and might vary ± 5 degrees C.

Examples

This example sets 15 as the difference between the yellow and red thresholds:

```
Controller(config)# system env temperature threshold yellow 15
Controller(config)#
```

test cable-diagnostics tdr

To run the Time Domain Reflector (TDR) feature on an interface, use the **test cable-diagnostics tdr** command in privileged EXEC mode.

test cable-diagnostics tdr interface *interface-id*

Syntax Description

<i>interface-id</i>	The interface on which to run TDR.
---------------------	------------------------------------

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

TDR is supported only on 10/100/100 copper Ethernet ports. It is not supported on 10-Gigabit Ethernet ports or small form-factor pluggable (SFP) module ports.

After you run TDR by using the **test cable-diagnostics tdr interface** *interface-id* command, use the **show cable-diagnostics tdr interface** *interface-id* privileged EXEC command to display the results.

Examples

This example shows how to run TDR on an interface:

```
Controller# test cable-diagnostics tdr interface gigabitethernet1/0/2
TDR test started on interface Gi1/0/2
A TDR test can take a few seconds to run on an interface
Use 'show cable-diagnostics tdr' to read the TDR results
```

If you enter the **test cable-diagnostics tdr interface** *interface-id* command on an interface that has an link up status and a speed of 10 or 100 Mb/s, these messages appear:

```
Controller# test cable-diagnostics tdr interface gigabitethernet1/0/3
TDR test on Gi1/0/9 will affect link state and traffic
TDR test started on interface Gi1/0/3
A TDR test can take a few seconds to run on an interface
Use 'show cable-diagnostics tdr' to read the TDR results.
```

tracert mac

To display the Layer 2 path taken by the packets from the specified source MAC address to the specified destination MAC address, use the **tracert mac** command in privileged EXEC mode.

tracert mac [**interface** *interface-id*] *source-mac-address* [**interface** *interface-id*] *destination-mac-address* [**vlan** *vlan-id*] [**detail**]

Syntax Description

interface <i>interface-id</i>	(Optional) Specifies an interface on the source or destination controller.
<i>source-mac-address</i>	The MAC address of the source controller in hexadecimal format.
<i>destination-mac-address</i>	The MAC address of the destination controller in hexadecimal format.
vlan <i>vlan-id</i>	(Optional) Specifies the VLAN on which to trace the Layer 2 path that the packets take from the source controller to the destination controller. Valid VLAN IDs are 1 to 4094.
detail	(Optional) Specifies that detailed information appears.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

For Layer 2 tracert to function properly, Cisco Discovery Protocol (CDP) must be enabled on all of the controllers in the network. Do not disable CDP.

When the controller detects a device in the Layer 2 path that does not support Layer 2 tracert, the controller continues to send Layer 2 trace queries and lets them time out.

The maximum number of hops identified in the path is ten.

Layer 2 tracert supports only unicast traffic. If you specify a multicast source or destination MAC address, the physical path is not identified, and an error message appears.

The **tracert mac** command output shows the Layer 2 path when the specified source and destination addresses belong to the same VLAN.

If you specify source and destination addresses that belong to different VLANs, the Layer 2 path is not identified, and an error message appears.

If the source or destination MAC address belongs to multiple VLANs, you must specify the VLAN to which both the source and destination MAC addresses belong.

If the VLAN is not specified, the path is not identified, and an error message appears.

The Layer 2 traceroute feature is not supported when multiple devices are attached to one port through hubs (for example, multiple CDP neighbors are detected on a port).

When more than one CDP neighbor is detected on a port, the Layer 2 path is not identified, and an error message appears.

This feature is not supported in Token Ring VLANs.

Examples

This example shows how to display the Layer 2 path by specifying the source and destination MAC addresses:

```
Controller# tracert mac 0000.0201.0601 0000.0201.0201
Source 0000.0201.0601 found on con6[WS-C3750E-24PD] (2.2.6.6)
con6 (2.2.6.6) :Gi0/0/1 => Gi0/0/3
con5          (2.2.5.5       ) :   Gi0/0/3 => Gi0/0/1
con1          (2.2.1.1       ) :   Gi0/0/1 => Gi0/0/2
con2          (2.2.2.2       ) :   Gi0/0/2 => Gi0/0/1
Destination 0000.0201.0201 found on con2[WS-C3550-24] (2.2.2.2)
Layer 2 trace completed
```

This example shows how to display the Layer 2 path by using the **detail** keyword:

```
Controller# tracert mac 0000.0201.0601 0000.0201.0201 detail
Source 0000.0201.0601 found on con6[WS-C3750E-24PD] (2.2.6.6)
con6 / WS-C3750E-24PD / 2.2.6.6 :
    Gi0/0/2 [auto, auto] => Gi0/0/3 [auto, auto]
con5 / WS-C2950G-24-EI / 2.2.5.5 :
    Fa0/3 [auto, auto] => Gi0/1 [auto, auto]
con1 / WS-C3550-12G / 2.2.1.1 :
    Gi0/1 [auto, auto] => Gi0/2 [auto, auto]
con2 / WS-C3550-24 / 2.2.2.2 :
    Gi0/2 [auto, auto] => Fa0/1 [auto, auto]
Destination 0000.0201.0201 found on con2[WS-C3550-24] (2.2.2.2)
Layer 2 trace completed.
```

This example shows how to display the Layer 2 path by specifying the interfaces on the source and destination controllers:

```
Controller# tracert mac interface fastethernet0/1 0000.0201.0601 interface fastethernet0/3
0000.0201.0201
Source 0000.0201.0601 found on con6[WS-C3750E-24PD] (2.2.6.6)
con6 (2.2.6.6) :Gi0/0/1 => Gi0/0/3
con5          (2.2.5.5       ) :   Gi0/0/3 => Gi0/0/1
con1          (2.2.1.1       ) :   Gi0/0/1 => Gi0/0/2
con2          (2.2.2.2       ) :   Gi0/0/2 => Gi0/0/1
Destination 0000.0201.0201 found on con2[WS-C3550-24] (2.2.2.2)
Layer 2 trace completed
```

This example shows the Layer 2 path when the controller is not connected to the source controller:

```
Controller# tracert mac 0000.0201.0501 0000.0201.0201 detail
Source not directly connected, tracing source .....
Source 0000.0201.0501 found on con5[WS-C3750E-24TD] (2.2.5.5)
con5 / WS-C3750E-24TD / 2.2.5.5 :
    Gi0/0/1 [auto, auto] => Gi0/0/3 [auto, auto]
con1 / WS-C3550-12G / 2.2.1.1 :
    Gi0/1 [auto, auto] => Gi0/2 [auto, auto]
con2 / WS-C3550-24 / 2.2.2.2 :
```

```
Gi0/2 [auto, auto] => Fa0/1 [auto, auto]
Destination 0000.0201.0201 found on con2[WS-C3550-24] (2.2.2.2)
Layer 2 trace completed.
```

This example shows the Layer 2 path when the controller cannot find the destination port for the source MAC address:

```
Controller# tracert mac 0000.0011.1111 0000.0201.0201
Error:Source Mac address not found.
Layer2 trace aborted.
```

This example shows the Layer 2 path when the source and destination devices are in different VLANs:

```
Controller# tracert mac 0000.0201.0601 0000.0301.0201
Error:Source and destination macs are on different vlans.
Layer2 trace aborted.
```

This example shows the Layer 2 path when the destination MAC address is a multicast address:

```
Controller# tracert mac 0000.0201.0601 0100.0201.0201
Invalid destination mac address
```

This example shows the Layer 2 path when source and destination controllers belong to multiple VLANs:

```
Controller# tracert mac 0000.0201.0601 0000.0201.0201
Error:Mac found on multiple vlans.
Layer2 trace aborted.
```

traceroute mac ip

To display the Layer 2 path taken by the packets from the specified source IP address or hostname to the specified destination IP address or hostname, use the **traceroute mac ip** command in privileged EXEC mode.

traceroute mac ip {*source-ip-address* | *source-hostname*} {*destination-ip-address* | *destination-hostname*} [**detail**]

Syntax Description

<i>source-ip-address</i>	The IP address of the source controller as a 32-bit quantity in dotted-decimal format.
<i>source-hostname</i>	The IP hostname of the source controller.
<i>destination-ip-address</i>	The IP address of the destination controller as a 32-bit quantity in dotted-decimal format.
<i>destination-hostname</i>	The IP hostname of the destination controller.
detail	(Optional) Specifies that detailed information appears.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

For Layer 2 traceroute to function properly, Cisco Discovery Protocol (CDP) must be enabled on each controller in the network. Do not disable CDP.

When the controller detects a device in the Layer 2 path that does not support Layer 2 traceroute, the controller continues to send Layer 2 trace queries and lets them time out.

The maximum number of hops identified in the path is ten.

The **traceroute mac ip** command output shows the Layer 2 path when the specified source and destination IP addresses are in the same subnet.

When you specify the IP addresses, the controller uses Address Resolution Protocol (ARP) to associate the IP addresses with the corresponding MAC addresses and the VLAN IDs.

- If an ARP entry exists for the specified IP address, the controller uses the associated MAC address and identifies the physical path.

- If an ARP entry does not exist, the controller sends an ARP query and tries to resolve the IP address. The IP addresses must be in the same subnet. If the IP address is not resolved, the path is not identified, and an error message appears.

The Layer 2 traceroute feature is not supported when multiple devices are attached to one port through hubs (for example, multiple CDP neighbors are detected on a port).

When more than one CDP neighbor is detected on a port, the Layer 2 path is not identified, and an error message appears.

This feature is not supported in Token Ring VLANs.

Examples

This example shows how to display the Layer 2 path by specifying the source and destination IP addresses and by using the **detail** keyword:

```
Controller# tracert mac ip 2.2.66.66 2.2.22.22 detail
Translating IP to mac .....
2.2.66.66 => 0000.0201.0601
2.2.22.22 => 0000.0201.0201

Source 0000.0201.0601 found on con6[WS-C2950G-24-EI] (2.2.6.6)
con6 / WS-C3750E-24TD / 2.2.6.6 :
      Gi0/0/1 [auto, auto] => Gi0/0/3 [auto, auto]
con5 / WS-C2950G-24-EI / 2.2.5.5 :
      Fa0/3 [auto, auto] => Gi0/1 [auto, auto]
con1 / WS-C3550-12G / 2.2.1.1 :
      Gi0/1 [auto, auto] => Gi0/2 [auto, auto]
con2 / WS-C3550-24 / 2.2.2.2 :
      Gi0/2 [auto, auto] => Fa0/1 [auto, auto]
Destination 0000.0201.0201 found on con2[WS-C3550-24] (2.2.2.2)
Layer 2 trace completed.
```

This example shows how to display the Layer 2 path by specifying the source and destination hostnames:

```
Controller# tracert mac ip con6 con2
Translating IP to mac .....
2.2.66.66 => 0000.0201.0601
2.2.22.22 => 0000.0201.0201

Source 0000.0201.0601 found on con6
con6 (2.2.6.6) :Gi0/0/1 => Gi0/0/3
con5          (2.2.5.5      ) :   Gi0/0/3 => Gi0/1
con1          (2.2.1.1      ) :   Gi0/0/1 => Gi0/2
con2          (2.2.2.2      ) :   Gi0/0/2 => Fa0/1
Destination 0000.0201.0201 found on con2
Layer 2 trace completed
```

This example shows the Layer 2 path when ARP cannot associate the source IP address with the corresponding MAC address:

```
Controller# tracert mac ip 2.2.66.66 2.2.77.77
Arp failed for destination 2.2.77.77.
Layer2 trace aborted.
```

trapflags

To enable sending rogue access point detection traps, use the **trapflags** command in privileged EXEC mode. To disable sending rogue access point detection traps, use the **no** form of this command.

trapflags rogueap
no trapflags rogueap

Syntax Description	rogueap	Enables sending rogue access point detection traps.
Command Default	Enabled.	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to disable the sending of rogue access point detection traps:

```
Controller# configure terminal
Controller(config)# no trapflags rogueap
Controller(config)# end
```

trapflags client

To enable the sending of client-related DOT11 traps, use the **trapflags client** command in privileged EXEC mode. To disable the sending of client-related DOT11 traps, use the **no** form of this command.

trapflags client [**dot11** {**assocfail**| **associate**| **authfail**| **deauthenticate**| **disassociate**}| **excluded**]

no trapflags client [**dot11** {**assocfail**| **associate**| **authfail**| **deauthenticate**| **disassociate**}| **excluded**]

Syntax Description

dot11	Client-related DOT11 traps.
assocfail	Enables the sending of Dot11 association fail traps to clients.
associate	Enables the sending of Dot11 association traps to clients.
authfail	Enables the sending of Dot11 authentication fail traps to clients.
deauthenticate	Enables the sending of Dot11 deauthentication traps to clients.
disassociate	Enables the sending of Dot11 disassociation traps to clients.
excluded	Enables the sending of excluded trap to clients.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable the sending of Dot11 disassociation trap to clients:

```
Controller# configure terminal
Controller(config)# trapflags client dot11 disassociate
Controller(config)# end
```

type

To display the contents of one or more files, use the **type** command in boot loader mode.

type *filesystem:/file-url...*

Syntax Description

<i>filesystem:</i>	Alias for a file system. Use flash: for the system board flash device; use usbflash0: for USB memory sticks.
<i>/file-url...</i>	Path (directory) and name of the files to display. Separate each filename with a space.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Filenames and directory names are case sensitive.

If you specify a list of files, the contents of each file appear sequentially.

Examples

This example shows how to display the contents of a file:

```
Controller: type flash:image_file_name
version_suffix: universal-122-xx.SEx
version_directory: image_file_name
image_system_type_id: 0x00000002
image_name: image_file_name.bin
ios_image_file_size: 8919552
total_image_file_size: 11592192
image_feature: IP|LAYER_3|PLUS|MIN_DRAM_MEG=128
image_family: family
stacking_number: 1.34
board_ids: 0x00000068 0x00000069 0x0000006a 0x0000006b
info_end:
```

unset

To reset one or more environment variables, use the **unset** command in boot loader mode.

unset *variable*...

Syntax Description

<i>variable</i>	Use one of these keywords for <i>variable</i> : MANUAL_BOOT —Specifies whether the controller automatically or manually boots.
	BOOT —Resets the list of executable files to try to load and execute when automatically booting. If the BOOT environment variable is not set, the system attempts to load and execute the first executable image it can find by using a recursive, depth-first search through the flash: file system. If the BOOT variable is set but the specified images cannot be loaded, the system attempts to boot the first bootable file that it can find in the flash: file system.
	ENABLE_BREAK —Specifies whether the automatic boot process can be interrupted by using the Break key on the console after the flash: file system has been initialized.
	HELPER —Identifies the semicolon-separated list of loadable files to dynamically load during the boot loader initialization. Helper files extend or patch the functionality of the boot loader.
	PS1 —Specifies the string that is used as the command-line prompt in boot loader mode.
	CONFIG_FILE —Resets the filename that Cisco IOS uses to read and write a nonvolatile copy of the system configuration.
	BAUD —Resets the rate in bits per second (b/s) used for the console. The Cisco IOS software inherits the baud rate setting from the boot loader and continues to use this value unless the configuration file specifies another setting.

Command Default

No default behavior or values.

Command Modes

Boot loader

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Under typical circumstances, it is not necessary to alter the setting of the environment variables.

The MANUAL_BOOT environment variable can also be reset by using the **no boot manual** global configuration command.

The BOOT environment variable can also be reset by using the **no boot system** global configuration command.

The ENABLE_BREAK environment variable can also be reset by using the **no boot enable-break** global configuration command.

The HELPER environment variable can also be reset by using the **no boot helper** global configuration command.

The CONFIG_FILE environment variable can also be reset by using the **no boot config-file** global configuration command.

Examples

This example shows how to unset the SWITCH_PRIORITY environment variable:

```
Controller: unset SWITCH_PRIORITY
```

version

To display the boot loader version, use the **version** command in boot loader mode.

version

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Boot loader

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the boot loader version on a controller:

```
Controller: version
CT5760 Boot Loader (CT5760-HBOOT-M) Version 1.0, RELEASE SOFTWARE (P)
  Compiled Thu 22-Aug-13 06:18 by rel
```

wireless client

To configure client parameters, use the **wireless client** command in global configuration mode.

wireless client {**association limit** *assoc-number* **interval** *interval*| **band-select** {**client-rssi** *rssi*| **cycle-count** *count*| **cycle-threshold** *threshold*| **expire dual-band** *timeout*| **expire suppression** *timeout*}| **max-user-login** *max-user-login*| **timers** **auth-timeout** *seconds*| **user-timeout** *user-timeout*}

Syntax Description

association limit <i>assoc-number</i> interval <i>interval</i>	Enables association request limit per access point slot at a given interval and configures the association request limit interval. You can configure number of association request per access point slot at a given interval from one through 100. You can configure client association request limit interval from 100 through 10000 milliseconds.
band-select	Configures band select options for the client.
client-rssi <i>rssi</i>	Sets the client received signal strength indicator (RSSI) threshold for band select. Minimum dBm of a client RSSI to respond to probe between -90 and -20.
cycle-count <i>count</i>	Sets the band select probe cycle count. You can configure the cycle count from one through 10.
cycle-threshold <i>threshold</i>	Sets the time threshold for a new scanning cycle. You can configure the cycle threshold from one through 1000 milliseconds.
expire dual-band <i>timeout</i>	Sets the timeout before stopping to try to push a given client to the 5-GHz band. You can configure the timeout from 10 through 300 seconds, and the default value is 60 seconds.
expire suppression <i>timeout</i>	Sets the expiration time for pruning previously known dual-band clients. You can configure the suppression from 10 through 200 seconds, and the default timeout value is 20 seconds.
max-user-login <i>max-user-login</i>	Configures the maximum number of login sessions for a user.
timers auth-timeout <i>seconds</i>	Configures client timers.
user-timeout <i>user-timeout</i>	Configures the idle client timeout.

Command Default No default behavior or values.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how to set the probe cycle count for band select to 8:

```
Controller# configure terminal
Controller(config)# wireless client band-select cycle-count 8
Controller(config)# end
```

This example shows how to set the time threshold for a new scanning cycle with threshold value of 700 milliseconds:

```
Controller# configure terminal
Controller(config)# wireless client band-select cycle-threshold 700
Controller(config)# end
```

This example shows how to suppress dual-band clients from the dual-band database after 70 seconds:

```
Controller# configure terminal
Controller(config)# wireless client band-select expire suppression 70
Controller(config)# end
```

wireless client mac-address deauthenticate

To disconnect a wireless client, use the **wireless client mac-address deauthenticate** command in global configuration mode.

wirelessclientmac-address *mac-addr***deauthenticate**

Syntax Description	mac-address <i>mac-addr</i>	Wireless client MAC address.
Command Default	No default behavior or values.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to disconnect a wireless client:

```
Controller# configure terminal
Controller(config)# wireless client mac-address 00:1f:ca:cf:b6:60 deauthenticate
Controller(config)# end
```

wireless client mac-address

To configure the wireless client settings, use the **wireless client mac-address** command in global configuration mode.

```
wireless client mac-address mac-addr ccx {clear-reports| clear-results| default-gw-ping| dhcp-test|
dns-ping| dns-resolve hostname host-name| get-client-capability| get-manufacturer-info|
get-operating-parameters| get-profiles| log-request {roam| rsna| syslog}| send-message message-id|
stats-request measurement-duration {dot11| security}| test-abort| test-association ssid bssid dot11 channel|
test-dot1x [ profile-id ] bssid dot11 channel| test-profile {any| profile-id }
```

Syntax Description

<i>mac-addr</i>	MAC address of the client.
ccx	Cisco client extension (CCX).
clear-reports	Clears the client reporting information.
clear-results	Clears the test results on the controller.
default-gw-ping	Sends a request to the client to perform the default gateway ping test.
dhcp-test	Sends a request to the client to perform the DHCP test.
dns-ping	Sends a request to the client to perform the Domain Name System (DNS) server IP address ping test.
dns-resolve hostname <i>host-name</i>	Sends a request to the client to perform the Domain Name System (DNS) resolution test to the specified hostname.
get-client-capability	Sends a request to the client to send its capability information.
get-manufacturer-info	Sends a request to the client to send the manufacturer's information.
get-operating-parameters	Sends a request to the client to send its current operating parameters.
get-profiles	Sends a request to the client to send its profiles.
log-request	Configures a CCX log request for a specified client device.
roam	(Optional) Specifies the request to specify the client CCX roaming log
rsna	(Optional) Specifies the request to specify the client CCX RSNA log.
syslog	(Optional) Specifies the request to specify the client CCX system log.

send-message *message-id*

Sends a message to the client.

Message type that involves one of the following:

- 1—The SSID is invalid
- 2—The network settings are invalid.
- 3—There is a WLAN credibility mismatch.
- 4—The user credentials are incorrect.
- 5—Please call support.
- 6—The problem is resolved.
- 7—The problem has not been resolved.
- 8—Please try again later.
- 9—Please correct the indicated problem.
- 10—Troubleshooting is refused by the network.
- 11—Retrieving client reports.
- 12—Retrieving client logs.
- 13—Retrieval complete.
- 14—Beginning association test.
- 15—Beginning DHCP test.
- 16—Beginning network connectivity test.
- 17—Beginning DNS ping test.
- 18—Beginning name resolution test.
- 19—Beginning 802.1X authentication test.
- 20—Redirecting client to a specific profile.
- 21—Test complete.
- 22—Test passed.
- 23—Test failed.
- 24—Cancel diagnostic channel operation or select a WLAN profile to resume normal operation.
- 25—Log retrieval refused by the client.
- 26—Client report retrieval refused by the client.
- 27—Test request refused by the client.
- 28—Invalid network (IP) setting.
- 29—There is a known outage or problem with the network.
- 30—Scheduled maintenance period.

- 31—The WLAN security method is not correct.
- 32—The WLAN encryption method is not correct.
- 33—The WLAN authentication method is not correct.

stats-request <i>measurement-duration</i>	Sends a request for statistics.
dot11	Optional) Specifies dot11 counters.
security	(Optional) Specifies security counters.
test-abort	Sends a request to the client to abort the current test.
test-association <i>ssid bssid</i> <i>dot11 channel</i>	Sends a request to the client to perform the association test.
test-dot1x	Sends a request to the client to perform the 802.1x test.
<i>profile-id</i>	(Optional) Test profile name.
<i>bssid</i>	Basic SSID.
<i>dot11</i>	Specifies the 802.11a, 802.11b, or 802.11g network.
<i>channel</i>	Channel number.
test-profile	Sends a request to the client to perform the profile redirect test.
any	Sends a request to the client to perform the profile redirect test.
<i>profile-id</i>	Test profile name. Note The profile ID should be from one of the client profiles for which client reporting is enabled.

Command Default No default behavior or values.

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines The **default-gw-ping** test does not require the client to use the diagnostic channel.

Examples

This example shows how to clear the reporting information of the client MAC address 00:1f:ca:cf:b6:60:

```
Controller# configure terminal  
Controller(config)# wireless client mac-address 00:1f:ca:cf:b6:60 ccx clear-reports  
Controller(config)# end
```

wireless load-balancing

To globally configure aggressive load balancing on the controller, use the **wireless load-balancing** command in global configuration mode.

wireless load-balancing {**denial** *denial-count*|**window** *client-count*}

Syntax Description

denial <i>denial-count</i>	Specifies the number of association denials during load balancing. Maximum number of association denials during load balancing is from 1 to 10 and the default value is 3.
window <i>client-count</i>	Specifies the aggressive load balancing client window, with the number of clients needed to trigger aggressive load balancing on a given access point. Aggressive load balancing client window with the number of clients is from 0 to 20 and the default value is 5.

Command Default

Disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Load-balancing-enabled WLANs do not support time-sensitive applications like voice and video because of roaming delays.

When you use Cisco 7921 and 7920 Wireless IP Phones with controllers, make sure that aggressive load balancing is disabled on the voice WLANs for each controller. Otherwise, the initial roam attempt by the phone might fail, causing a disruption in the audio path.

Examples

This example shows how to configure association denials during load balancing:

```
Controller# configure terminal
Controller(config)# wireless load-balancing denial 5
Controller(config)# end
```

wireless sip preferred-call-no

To add a new preferred call or configure voice prioritization, use the **wireless sip preferred-call-no** command in global configuration mode. To remove a preferred call, use the **no** form of this command.

wireless sip preferred-call-no *callIndex* *call-no*

no wireless sip preferred-call-no *callIndex*

Syntax Description

<i>callIndex</i>	Call index with valid values between 1 and 6.
<i>call-no</i>	Preferred call number that can contain up to 27 characters.

Command Default

No default behavior or values.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Before you configure voice prioritization, you must complete the following prerequisites:

- Set WLAN QoS to allow voice calls to pass through.
- Enable ACM for the radio.
- Enable SIP call snooping on the WLAN.

Examples

This example shows how to add a new preferred call or configure voice prioritization:

```
Controller# configure terminal
Controller(config)# wireless sip preferred-call-no 2 0123456789
Controller(config)# end
```



PART **II**

QoS

- [QoS Commands, page 133](#)



QoS Commands

- [class](#), page 134
- [class-map](#), page 137
- [match \(class-map configuration\)](#), page 139
- [match non-client-nrt](#), page 142
- [match wlan user-priority](#), page 143
- [policy-map](#), page 144
- [priority](#), page 147
- [queue-buffers ratio](#), page 149
- [queue-limit](#), page 151
- [qos wireless-default untrust](#), page 153
- [service-policy \(Wired\)](#), page 155
- [service-policy \(WLAN\)](#), page 157
- [set](#), page 159
- [show ap name service-policy](#), page 166
- [show ap name dot11](#), page 167
- [show class-map](#), page 170
- [show wireless client calls](#), page 171
- [show wireless client dot11](#), page 172
- [show wireless client mac-address \(Call Control\)](#), page 173
- [show wireless client mac-address \(TCLAS\)](#), page 174
- [show wireless client voice diagnostics](#), page 175
- [show policy-map](#), page 176
- [show wlan](#), page 180
- [trust device](#), page 183

class

To define a traffic classification match criteria for the specified class-map name, use the **class** command in policy-map configuration mode. Use the **no** form of this command to delete an existing class map.

class {*class-map-name* | **class-default**}

no class {*class-map-name* | **class-default**}

Syntax Description

<i>class-map-name</i>	The class map name.
class-default	Refers to a system default class that matches unclassified packets.

Command Default

No policy map class-maps are defined.

Command Modes

Policy-map configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Before using the **class** command, you must use the **policy-map** global configuration command to identify the policy map and enter policy-map configuration mode. After specifying a policy map, you can configure a policy for new classes or modify a policy for any existing classes in that policy map. You attach the policy map to a port by using the **service-policy** interface configuration command.

After entering the **class** command, you enter the policy-map class configuration mode. These configuration commands are available:

- **admit**—Admits a request for Call Admission Control (CAC)
- **bandwidth**—Specifies the bandwidth allocated to the class.
- **exit**—Exits the policy-map class configuration mode and returns to policy-map configuration mode.
- **no**—Returns a command to its default setting.
- **police**—Defines a policer or aggregate policer for the classified traffic. The policer specifies the bandwidth limitations and the action to take when the limits are exceeded. For more information about this command, see *Cisco IOS Quality of Service Solutions Command Reference* available on Cisco.com.
- **priority**—Assigns scheduling priority to a class of traffic belonging to a policy map.
- **queue-buffers**—Configures the queue buffer for the class.

- **queue-limit**—Specifies the maximum number of packets the queue can hold for a class policy configured in a policy map.
- **service-policy**—Configures a QoS service policy.
- **set**—Specifies a value to be assigned to the classified traffic. For more information, see [set](#), on page 159
- **shape**—Specifies average or peak rate traffic shaping. For more information about this command, see *Cisco IOS Quality of Service Solutions Command Reference* available on Cisco.com.

To return to policy-map configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

The **class** command performs the same function as the **class-map** global configuration command. Use the **class** command when a new classification, which is not shared with any other ports, is needed. Use the **class-map** command when the map is shared among many ports.

You can configure a default class by using the **class class-default** policy-map configuration command. Unclassified traffic (traffic that does not meet the match criteria specified in the traffic classes) is treated as default traffic.

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Examples

This example shows how to create a policy map called policy1. When attached to the ingress direction, it matches all the incoming traffic defined in class1, sets the IP Differentiated Services Code Point (DSCP) to 10, and polices the traffic at an average rate of 1 Mb/s and bursts at 20 KB. Traffic exceeding the profile is marked down to a DSCP value gotten from the policed-DSCP map and then sent.

```
Controller(config)# policy-map policy1
Controller(config-pmap)# class class1
Controller(config-pmap-c)# set dscp 10
Controller(config-pmap-c)# police 1000000 20000 exceed-action policed-dscp-transmit
Controller(config-pmap-c)# exit
```

This example shows how to configure a default traffic class to a policy map. It also shows how the default traffic class is automatically placed at the end of policy-map pm3 even though **class-default** was configured first:

```
Controller# configure terminal
Controller(config)# class-map cm-3
Controller(config-cmap)# match ip dscp 30
Controller(config-cmap)# exit

Controller(config)# class-map cm-4
Controller(config-cmap)# match ip dscp 40
Controller(config-cmap)# exit

Controller(config)# policy-map pm3
Controller(config-pmap)# class class-default
Controller(config-pmap-c)# set dscp 10
Controller(config-pmap-c)# exit

Controller(config-pmap)# class cm-3
Controller(config-pmap-c)# set dscp 4
Controller(config-pmap-c)# exit

Controller(config-pmap)# class cm-4
Controller(config-pmap-c)# set precedence 5
Controller(config-pmap-c)# exit
Controller(config-pmap)# exit

Controller# show policy-map pm3
```

```

Policy Map pm3
  Class cm-3
    set dscp 4
  Class cm-4
    set precedence 5
  Class class-default
    set dscp af11

```

Related Commands

Command	Description
class-map	Creates a class map to be used for matching packets to the class whose name you specify and enters class-map configuration mode.
policy-map	Creates or modifies a policy map that can be attached to multiple physical ports or SVIs and enters policy-map configuration mode.
show policy-map	Displays QoS policy maps.
set	Classifies IP traffic by setting a DSCP or an IP-precedence value in the packet.

class-map

To create a class map to be used for matching packets to the class whose name you specify and to enter class-map configuration mode, use the **class-map** command in global configuration mode. Use the **no** form of this command to delete an existing class map and to return to global or policy map configuration mode.

class-map [**match-any** | *type*] *class-map-name*

no class-map [**match-any** | *type*] *class-map-name*

Syntax Description

match-any	(Optional) Perform a logical-OR of the matching statements under this class map. One or more criteria must be matched.
type	(Optional) Configures the CPL class map.
<i>class-map-name</i>	The class map name.

Command Default

No class maps are defined.

Command Modes

Global configuration
Policy map configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.
Cisco IOS XE 3.3SE	The type keyword was added.

Usage Guidelines

Use this command to specify the name of the class for which you want to create or modify class-map match criteria and to enter class-map configuration mode.

The **class-map** command and its subcommands are used to define packet classification, marking, and aggregate policing as part of a globally named service policy applied on a per-port basis.

After you are in quality of service (QoS) class-map configuration mode, these configuration commands are available:

- **description**—Describes the class map (up to 200 characters). The **show class-map** privileged EXEC command displays the description and the name of the class map.
- **exit**—Exits from QoS class-map configuration mode.
- **match**—Configures classification criteria.
- **no**—Removes a match statement from a class map.

If you enter the **match-any** keyword, you can only use it to specify an extended named access control list (ACL) with the **match access-group** class-map configuration command.

To define packet classification on a physical-port basis, only one **match** command per class map is supported. The ACL can have multiple access control entries (ACEs).

Examples

This example shows how to configure the class map called class1 with one match criterion, which is an access list called 103:

```
Controller(config)# access-list 103 permit ip any any dscp 10
Controller(config)# class-map class1
Controller(config-cmap)# match access-group 103
Controller(config-cmap)# exit
```

This example shows how to delete the class map class1:

```
Controller(config)# no class-map class1
```

You can verify your settings by entering the **show class-map** privileged EXEC command.

Related Commands

Command	Description
policy-map	Creates or modifies a policy map that can be attached to multiple physical ports or SVIs and enters policy-map configuration mode.
show policy-map	Displays QoS policy maps.

match (class-map configuration)

To define the match criteria to classify traffic, use the **match** command in class-map configuration mode. Use the **no** form of this command to remove the match criteria.

```
match {access-group {nameacl-name | acl-index} | class-map class-map-name} cos cos-value | dscp dscp-value |
[ ip ] dscp dscp-list | [ ip ] precedence ip-precedence-list | precedence precedence-value1...value4 | qos-group
qos-group-value | vlan vlan-id}
```

```
no match {access-group {nameacl-name | acl-index} | class-map class-map-name} cos cos-value | dscp
dscp-value | [ ip ] dscp dscp-list | [ ip ] precedence ip-precedence-list | precedence precedence-value1...value4 |
qos-group qos-group-value | vlan vlan-id}
```

Syntax Description

access-group	Specifies an access group.
name <i>acl-name</i>	Specifies the name of an IP standard or extended access control list (ACL) or MAC ACL.
<i>acl-index</i>	Specifies the number of an IP standard or extended access control list (ACL) or MAC ACL. For an IP standard ACL, the ACL index range is 1 to 99 and 1300 to 1999. For an IP extended ACL, the ACL index range is 100 to 199 and 2000 to 2699.
class-map <i>class-map-name</i>	Uses a traffic class as a classification policy and specifies a traffic class name to use as the match criterion.
cos <i>cos-value</i>	Matches a packet on the basis of a Layer 2 class of service (CoS)/Inter-Switch Link (ISL) marking. The <i>cos-value</i> is from 0 to 7. You can specify up to four CoS values in one match cos statement, separated by a space.
dscp <i>dscp-value</i>	Specifies the parameters for each DSCP value. You can specify a value in the range 0 to 63 specifying the differentiated services code point value.
ip dscp <i>dscp-list</i>	Specifies a list of up to eight IP Differentiated Services Code Point (DSCP) values to match against incoming packets. Separate each value with a space. The range is 0 to 63. You also can enter a mnemonic name for a commonly used value.
ip precedence <i>ip-precedence-list</i>	Specifies a list of up to eight IP-precedence values to match against incoming packets. Separate each value with a space. The range is 0 to 7. You also can enter a mnemonic name for a commonly used value.

precedence <i>precedence-value1...value4</i>	Assigns an IP precedence value to the classified traffic. The range is 0 to 7. You also can enter a mnemonic name for a commonly used value.
qos-group <i>qos-group-value</i>	Identifies a specific QoS group value as a match criterion. The range is 0 to 31.
vlan <i>vlan-id</i>	Identifies a specific VLAN as a match criterion. The range is 1 to 4095.

Command Default No match criteria are defined.

Command Modes Class-map configuration

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.
Cisco IOS XE 3.3SE	The class-map <i>class-map-name</i> , cos <i>cos-value</i> , qos-group <i>qos-group-value</i> , and vlan <i>vlan-id</i> keywords were added.

Usage Guidelines The **match** command is used to specify which fields in the incoming packets are examined to classify the packets. Only the IP access group or the MAC access group matching to the Ether Type/Len are supported. If you enter the **class-map match-any***class-map-name* global configuration command, you can enter the following **match** commands:

- **match access-group** *name acl-name*



Note The ACL must be an extended named ACL.

- **match ip dscp** *dscp-list*
- **match ip precedence** *ip-precedence-list*

The **match access-group** *acl-index* command is not supported.

To define packet classification on a physical-port basis, only one **match** command per class map is supported. In this situation, the **match-any** keyword is equivalent.

For the **match ip dscp** *dscp-list* or the **match ip precedence** *ip-precedence-list* command, you can enter a mnemonic name for a commonly used value. For example, you can enter the **match ip dscp af11** command, which is the same as entering the **match ip dscp 10** command. You can enter the **match ip precedence critical** command, which is the same as entering the **match ip precedence 5** command. For a list of supported

mnemonics, enter the **match ip dscp ?** or the **match ip precedence ?** command to see the command-line help strings.

Use the **input-interface** *interface-id-list* keyword when you are configuring an interface-level class map in a hierarchical policy map. For the *interface-id-list*, you can specify up to six entries.

Examples

This example shows how to create a class map called class2, which matches all the incoming traffic with DSCP values of 10, 11, and 12:

```
Controller(config)# class-map class2
Controller(config-cmap)# match ip dscp 10 11 12
Controller(config-cmap)# exit
```

This example shows how to create a class map called class3, which matches all the incoming traffic with IP-precedence values of 5, 6, and 7:

```
Controller(config)# class-map class3
Controller(config-cmap)# match ip precedence 5 6 7
Controller(config-cmap)# exit
```

This example shows how to delete the IP-precedence match criteria and to classify traffic using acl1:

```
Controller(config)# class-map class2
Controller(config-cmap)# match ip precedence 5 6 7
Controller(config-cmap)# no match ip precedence
Controller(config-cmap)# match access-group acl1
Controller(config-cmap)# exit
```

This example shows how to specify a list of physical ports to which an interface-level class map in a hierarchical policy map applies:

```
Controller(config)# class-map match-any class4
Controller(config-cmap)# match cos 4
Controller(config-cmap)# exit
```

This example shows how to specify a range of physical ports to which an interface-level class map in a hierarchical policy map applies:

```
Controller(config)# class-map match-any class4
Controller(config-cmap)# match cos 4
Controller(config-cmap)# exit
```

You can verify your settings by entering the **show class-map** privileged EXEC command.

match non-client-nrt

To match non-client NRT (non-real-time), use the **match non-client-nrt** command in class-map configuration mode. Use the **no** form of this command to return to the default setting.

match non-client-nrt

no match non-client-nrt

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Class-map

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines None

Examples This example show how you can configure non-client NRT:

```
Controller(config)# class-map test_1000
Controller(config-cmap)# match non-client-nrt
```

match wlan user-priority

To match 802.11 specific values, use the **match wlan user-priority** command in class-map configuration mode. Use the **no** form of this command to return to the default setting.

match wlan user-priority *wlan-value* [*wlan-value*] [*wlan-value*] [*wlan-value*]

no match wlan user-priority *wlan-value* [*wlan-value*] [*wlan-value*] [*wlan-value*]

Syntax Description	<i>wlan-value</i>	The 802.11-specific values. Enter the user priority 802.11 TID user priority (0-7). (Optional) Enter up to three user priority values separated by white-spaces.
---------------------------	-------------------	--

Command Default	None
------------------------	------

Command Modes	Class-map
----------------------	-----------

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines	None
-------------------------	------

Examples This example show how you can configure user-priority values:

```
Controller(config)# class-map test_1000
Controller(config-cmap)# match wlan user-priority 7
```

policy-map

To create or modify a policy map that can be attached to multiple physical ports or switch virtual interfaces (SVIs) and to enter policy-map configuration mode, use the **policy-map** command in global configuration mode. Use the **no** form of this command to delete an existing policy map and to return to global configuration mode.

policy-map *policy-map-name*

no policy-map *policy-map-name*

Syntax Description

<i>policy-map-name</i>	Name of the policy map.
------------------------	-------------------------

Command Default

No policy maps are defined.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

After entering the **policy-map** command, you enter policy-map configuration mode, and these configuration commands are available:

- **class**—Defines the classification match criteria for the specified class map.
- **description**—Describes the policy map (up to 200 characters).
- **exit**—Exits policy-map configuration mode and returns you to global configuration mode.
- **no**—Removes a previously defined policy map.
- **sequence-interval**—Enables sequence number capability.

To return to global configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

Before configuring policies for classes whose match criteria are defined in a class map, use the **policy-map** command to specify the name of the policy map to be created, added to, or modified. Entering the **policy-map** command also enables the policy-map configuration mode in which you can configure or modify the class policies for that policy map.

You can configure class policies in a policy map only if the classes have match criteria defined for them. To configure the match criteria for a class, use the **class-map** global configuration and **match** class-map configuration commands. You define packet classification on a physical-port basis.

Only one policy map per ingress port is supported. You can apply the same policy map to multiple physical ports.

You can apply a nonhierarchical policy maps to physical ports. A nonhierarchical policy map is the same as the port-based policy maps in the controller.

A hierarchical policy map has two levels in the format of a parent-child policy. The parent policy cannot be modified but the child policy (port-child policy) can be modified to suit the QoS configuration.

In VLAN-based QoS, a service policy is applied to an SVI interface. All physical interfaces belonging to a VLAN policy map then need to be configured to refer to the VLAN-based policy maps instead of the port-based policy map.


Note

Not all MQC QoS combinations are supported for wired and wireless ports. For information about these restrictions, see chapters "Restrictions for QoS on Wired Targets" and "Restrictions for QoS on Wireless Targets" in the QoS configuration guide.

Examples

This example shows how to create a policy map called policy1. When attached to the ingress port, it matches all the incoming traffic defined in class1, sets the IP DSCP to 10, and polices the traffic at an average rate of 1 Mb/s and bursts at 20 KB. Traffic less than the profile is sent.

```
Controller(config)# policy-map policy1
Controller(config-pmap)# class class1
Controller(config-pmap-c)# set dscp 10
Controller(config-pmap-c)# police 1000000 20000 conform-action transmit
Controller(config-pmap-c)# exit
```

This example show you how to configure hierarchical polices:

```
Switch# configure terminal
Controller(config)# class-map c1
Controller(config-cmap)# exit

Controller(config)# class-map c2
Controller(config-cmap)# exit

Controller(config)# policy-map child
Controller(config-pmap)# class c1
Controller(config-pmap-c)# priority level 1
Controller(config-pmap-c)# police rate percent 20 conform-action transmit exceed action
drop
Controller(config-pmap-c-police)# exit
Controller(config-pmap-c)# exit

Controller(config-pmap)# class c2
Controller(config-pmap-c)# bandwidth 20000
Controller(config-pmap-c)# exit

Controller(config-pmap)# class class-default
Controller(config-pmap-c)# bandwidth 20000
Controller(config-pmap-c)# exit
Controller(config-pmap)# exit

Controller(config)# policy-map parent
Controller(config-pmap)# class class-default
Controller(config-pmap-c)# shape average 1000000
Controller(config-pmap-c)# service-policy child
Controllerconfig-pmap-c)# end
```

This example shows how to delete a policy map:

```
Controller(config)# no policy-map policymap2
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Related Commands

Command	Description
class	Defines a traffic classification match criteria for the specified class-map name.
class-map	Creates a class map to be used for matching packets to the class whose name you specify and enters class-map configuration mode.
service-policy (Wired)	Applies a policy map to a physical port or an SVI.
show policy-map	Displays QoS policy maps.

priority

To assign priority to a class of traffic belonging to a policy map, use the **priority** command in policy-map class configuration mode. To remove a previously specified priority for a class, use the **no** form of this command.

priority [*Kbps* [*burst -in-bytes*] | **level** *level-value* [*Kbps* [*burst -in-bytes*]] | **percent** *percentage* [*Kb/s* [*burst -in-bytes*]]]

no priority [*Kb/s* [*burst -in-bytes*] | **level** *level value* [*Kb/s* [*burst -in-bytes*]] | **percent** *percentage* [*Kb/s* [*burst -in-bytes*]]]

Syntax Description

<i>Kb/s</i>	(Optional) Guaranteed allowed bandwidth, in kilobits per second (kbps), for the priority traffic. The amount of guaranteed bandwidth varies according to the interface and platform in use. Beyond the guaranteed bandwidth, the priority traffic will be dropped in the event of congestion to ensure that the nonpriority traffic is not starved. The value must be between 1 and 2,000,000 kbps.
<i>burst -in-bytes</i>	(Optional) Burst size in bytes. The burst size configures the network to accommodate temporary bursts of traffic. The default burst value, which is computed as 200 milliseconds of traffic at the configured bandwidth rate, is used when the burst argument is not specified. The range of the burst is from 32 to 2000000 bytes.
level <i>level-value</i>	(Optional) Assigns priority level. Available values for <i>level-value</i> are 1 and 2. Level 1 is a higher priority than Level 2. Level 1 reserves bandwidth and goes first, so latency is very low. Reserve the bandwidth even if you do not use it. Both levels 1 and 2 can reserve bandwidth.
percent <i>percentage</i>	(Optional) Specifies the amount of guaranteed bandwidth to be specified by the percent of available bandwidth.

Command Default

No priority is set.

Command Modes

Policy-map class configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.
Cisco IOS XE 3.3SE	The <i>Kbps</i> , <i>burst -in-bytes</i> , and percent percentage keywords were added.

Usage Guidelines

This command configures low latency queuing (LLQ), providing strict priority queuing (PQ) for class-based weighted fair queuing (CBWFQ). Strict PQ allows delay-sensitive data such as voice to be dequeued and sent before packets in other queues are dequeued.

The priority command allows you to set up classes based on a variety of criteria (not just User Datagram Ports [UDP] ports) and assign priority to them, and is available for use on serial interfaces and ATM permanent virtual circuits (PVCs). A similar command, the **ip rtp priority** command, allows you to stipulate priority flows based only on UDP port numbers and is not available for ATM PVCs.

When the device is not congested, the priority class traffic is allowed to exceed its allocated bandwidth. When the device is congested, the priority class traffic above the allocated bandwidth is discarded.

The bandwidth and priority commands cannot be used in the same class, within the same policy map. However, these commands can be used together in the same policy map.

Within a policy map, you can give one or more classes priority status. When multiple classes within a single policy map are configured as priority classes, all traffic from these classes is queued to the same, single, priority queue.

When the policy map containing class policy configurations is attached to the interface to stipulate the service policy for that interface, available bandwidth is assessed. If a policy map cannot be attached to a particular interface because of insufficient interface bandwidth, the policy is removed from all interfaces to which it was successfully attached.

Examples

The following example shows how to configure the priority of the class in policy map policy1:

```

Controller(config)# class-map cm1
Controller(config-cmap)#match precedence 2
Controller(config-cmap)#exit

Controller(config)#class-map cm2
Controller(config-cmap)#match dscp 30
Controller(config-cmap)#exit

Controller(config)# policy-map policy1
Controller(config-pmap)# class cm1
Controller(config-pmap-c)# priority level 1
Controller(config-pmap-c)# police 1m
Controller(config-pmap-c-police)#exit
Controller(config-pmap-c)#exit
Controller(config-pmap)#exit

Controller(config)#policy-map policy1
Controller(config-pmap)#class cm2
Controller(config-pmap-c)#priority level 2
Controller(config-pmap-c)#police 1m

```

queue-buffers ratio

To configure the queue buffer for the class, use the **queue-buffers ratio** command in policy-map class configuration mode. Use the **no** form of this command to remove the ratio limit.

queue-buffers ratio *ratio limit*

no queue-buffers ratio *ratio limit*

Syntax Description

ratio limit (Optional) Configures the queue buffer for the class. Enter the queue buffers ratio limit (0-100).

Command Default

No queue buffer for the class is defined.

Command Modes

Policy-map class configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Either the **bandwidth**, **shape**, or **priority** command must be used before using this command. For more information about these commands, see *Cisco IOS Quality of Service Solutions Command Reference* available on Cisco.com

The controller allows you to allocate buffers to queues. If buffers are not allocated, then they are divided equally amongst all queues. You can use the queue-buffer ratio to divide it in a particular ratio. The buffers are soft buffers because Dynamic Threshold and Scaling (DTS) is active on all queues by default.



Note

The queue-buffer ratio is supported on both wired and wireless ports, but the queue-buffer ratio cannot be configured with a queue-limit.

Examples

The following example sets the queue buffers ratio to 10 percent:

```

Controller(config)# policy-map policy_queuebuf01
Controller(config-pmap)# class-map class_queuebuf01
Controller(config-cmap)# exit
Controller(config)# policy policy_queuebuf01
Controller(config-pmap)# class class_queuebuf01
Controller(config-pmap-c)# bandwidth percent 80
Controller(config-pmap-c)# queue-buffers ratio 10
Controller(config-pmap)# end

```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Related Commands

Command	Description
show policy-map	Displays QoS policy maps.

queue-limit

To specify or modify the maximum number of packets the queue can hold for a class policy configured in a policy map, use the **queue-limit** policy-map class configuration command. To remove the queue packet limit from a class, use the **no** form of this command.

queue-limit *queue-limit-size* [**packets**] {**cos** *cos-value*| **dscp** *dscp-value*} **percent** *percentage-of-packets*
no queue-limit *queue-limit-size* [**packets**] {**cos** *cos-value*| **dscp** *dscp-value*} **percent** *percentage-of-packets*

Syntax Description

<i>queue-limit-size</i>	The maximum size of the queue. The maximum varies according to the optional unit of measure keyword specified (bytes, ms, us, or packets).
cos <i>cos-value</i>	Specifies parameters for each cos value. CoS values are from 0 to 7.
dscp <i>dscp-value</i>	Specifies parameters for each DSCP value. You can specify a value in the range 0 to 63 specifying the differentiated services code point value for the type of queue limit .
percent <i>percentage-of-packets</i>	A percentage in the range 1 to 100 specifying the maximum percentage of packets that the queue for this class can accumulate.

Command Default

None

Command Modes

Policy-map class configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Although visible in the command line help-strings, the **packets** unit of measure is not supported; use the **percent** unit of measure.



Note

This command is supported only on wired ports in the egress direction.

Weighted fair queuing (WFQ) creates a queue for every class for which a class map is defined. Packets satisfying the match criteria for a class accumulate in the queue reserved for the class until they are sent, which occurs when the queue is serviced by the fair queuing process. When the maximum packet threshold you defined for the class is reached, queuing of any further packets to the class queue causes tail drop.

You use queue limits to configure Weighted Tail Drop (WTD). WTD ensures the configuration of more than one threshold per queue. Each class of service is dropped at a different threshold value to provide for QoS differentiation.

You can configure the maximum queue thresholds for the different subclasses of traffic, that is, DSCP and CoS and configure the maximum queue thresholds for each subclass.

Examples

The following example configures a policy map called port-queue to contain policy for a class called dscp-1. The policy for this class is set so that the queue reserved for it has a maximum packet limit of 20 percent:

```
Controller(config)# policy-map policy11
Controller(config-pmap)# class dscp-1
Controller(config-pmap-c)# bandwidth percent 20
Controller(config-pmap-c)# queue-limit dscp 1 percent 20
```

qos wireless-default untrust

To configure the default trust behavior to untrust wireless packets, use the **qos wireless-default untrust** command. To configure the default trust behavior of wireless traffic to trust, use the **no** form of the command.

qos wireless-default-untrust

no qos wireless-default-untrust

Syntax Description This command has no arguments or keywords.

Command Default By default, the wireless traffic is untrusted.
To check the trust behavior on the controller, use the **show running-config | sec qos** or the **show run | include untrust** command.

Command Modes Configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Note The default trust behavior of wireless traffic was untrusted in the Cisco IOS XE 3.2 SE release.



Note If you upgrade from Cisco IOS XE 3.2 SE Release to a later release, the default behavior of the wireless traffic is still untrusted. In this situation, you can use the **no qos wireless-default untrust** command to enable trust behavior for wireless traffic. However, if you install Cisco IOS XE 3.3 SE or a later release on the controller, the default QoS behavior for wireless traffic is trust. Starting with Cisco IOS XE 3.3 SE Release and later, the packet markings are preserved in both egress and ingress directions for new installations (not upgrades) for wireless traffic.

The Cisco IOS XE 3.2 Release supported different trust defaults for wired and wireless ports. The trust default for wired ports was the same as for this software release. For wireless ports, the default system behavior was non-trust, which meant that when the controller came up, all markings for the wireless ports were defaulted to zero and no traffic received priority treatment. For compatibility with an existing wired controller, all traffic went to the best-effort queue by default. The access point performed priority queuing by default. In the downstream direction, the access point maintained voice, video, best-effort, and background queues for queuing. The access selected the queuing strategy based on the 11e tag information. By default, the access point treated all wireless packets as best effort.

Examples

The following command changes the default behavior for trusting wireless traffic to untrust.

```
Controller(config)# qos wireless-default-untrust
```

service-policy (Wired)

To apply a policy map to a physical port or a switch virtual interface (SVI), use the **service-policy** command in interface configuration mode. Use the **no** form of this command to remove the policy map and port association.

service-policy {input | output} *policy-map-name*

no service-policy {input | output} *policy-map-name*

Syntax Description

input <i>policy-map-name</i>	Apply the specified policy map to the input of a physical port or an SVI.
output <i>policy-map-name</i>	Apply the specified policy map to the output of a physical port or an SVI.

Command Default

No policy maps are attached to the port.

Command Modes

WLAN interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A policy map is defined by the **policy map** command.

Only one policy map is supported per port, per direction. In other words, only one input policy and one output policy is allowed on any one port.

You can apply a policy map to incoming traffic on a physical port or on an SVI. *QoS Configuration Guide (Cisco WLC 5700 Series)*.



Note

Though visible in the command-line help strings, the **history** keyword is not supported, and you should ignore the statistics that it gathers.

Examples

This example shows how to apply plcmap1 to an physical ingress port:

```
Controller(config)# interface gigabitethernet2/0/1
Controller(config-if)# service-policy input plcmap1
```

This example shows how to remove plcmap2 from a physical port:

```
Controller(config)# interface gigabitEthernet2/0/2
Controller(config-if)# no service-policy input plcmap2
```

The following example displays a VLAN policer configuration. At the end of this configuration, the VLAN policy map is applied to an interface for QoS:

```
Controller# configure terminal
Controller(config)# class-map vlan100
Controller(config-cmap)# match vlan 100
Controller(config-cmap)# exit
Controller(config)# policy-map vlan100
Controller(config-pmap)# policy-map class vlan100
Controller(config-pmap-c)# police 100000 bc conform-action transmit exceed-action drop
Controller(config-pmap-c-police)# end
Controller# configure terminal
Controller(config)# interface gigabitEthernet1/0/5
Controller(config-if)# service-policy input vlan100
```

You can verify your settings by entering the **show running-config** privileged EXEC command.

Related Commands

Command	Description
policy-map	Creates or modifies a policy map that can be attached to multiple physical ports or SVIs and enters policy-map configuration mode.
show policy-map	Displays QoS policy maps.

service-policy (WLAN)

To configure the WLAN quality of service (QoS) service policy, use the **service-policy** command. To disable a QoS policy on a WLAN, use the **no** form of this command.

service-policy [**client**] {**input**|**output**} *policy-name*

no service-policy [**client**] {**input**|**output**} *policy-name*

Syntax Description	
client	(Optional) Assigns a policy map to all clients in the WLAN.
input	Assigns an input policy map.
output	Assigns an output policy map.
<i>policy-name</i>	The policy name.

Command Default No policies are assigned and the state assigned to the policy is None.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples This example shows how to configure the input QoS service policy on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# service-policy input policy-test
```

This example shows how to disable the input QoS service policy on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no service-policy input policy-test
```

This example shows how to configure the output QoS service policy on a WLAN to platinum (precious metal policy):

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
```

```
Controller(config)# wlan wlan1  
Controller(config-wlan)# service-policy output platinum
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.
wlan	Creates or disables a WLAN.

set

To classify IP traffic by setting a Differentiated Services Code Point (DSCP) or an IP-precedence value in the packet, use the **set** command in policy-map class configuration mode. Use the **no** form of this command to remove traffic classification.

set cos| dscp| precedence| ip| qos-group| wlan

set cos {*cos-value* } | {**cos| dscp| precedence| qos-group| wlan**} [**table** *table-map-name*]

set dscp {*dscp-value* } | {**cos| dscp| precedence| qos-group| wlan**} [**table** *table-map-name*]

set ip {**dscp| precedence**}

set precedence {*precedence-value* } | {**cos| dscp| precedence| qos-group**} [**table** *table-map-name*]

set qos-group {*qos-group-value*| **dscp** [**table** *table-map-name*]| **precedence** [**table** *table-map-name*]}

set wlan user-priority*user-priority-value*| **cost***table table-map-name*| **dscp***table table-map-name*| **qos-group***table table-map-name*| **wlan***table table-map-name*

Syntax Description**cos**

Sets the Layer 2 class of service (CoS) value or user priority of an outgoing packet. You can specify these values:

- *cos-value*—CoS value from 0 to 7. You also can enter a mnemonic name for a commonly used value.
- Specify a packet-marking category to set the CoS value of the packet. If you also configure a table map for mapping and converting packet-marking values, this establishes the "map from" packet-marking category. Packet-marking category keywords:
 - **cos**—Sets a value from the CoS value or user priority.
 - **dscp**—Sets a value from packet differentiated services code point (DSCP).
 - **precedence**—Sets a value from packet precedence.
 - **qos-group**—Sets a value from the QoS group.
 - **wlan**—Sets the WLAN user priority values.
- (Optional) **table** *table-map-name*—Indicates that the values set in a specified table map are used to set the CoS value. Enter the name of the table map used to specify the CoS value. The table map name can be a maximum of 64 alphanumeric characters.

If you specify a packet-marking category but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the CoS value. For example, if you enter the **set cos precedence** command, the precedence (packet-marking category) value is copied and used as the CoS value.

dscp	<p>Sets the differentiated services code point (DSCP) value to mark IP(v4) and IPv6 packets. You can specify these values:</p> <ul style="list-style-type: none"> • <i>cos-value</i>—Number that sets the DSCP value. The range is from 0 to 63. You also can enter a mnemonic name for a commonly used value. • Specify a packet-marking category to set the DSCP value of the packet. If you also configure a table map for mapping and converting packet-marking values, this establishes the "map from" packet-marking category. Packet-marking category keywords: <ul style="list-style-type: none"> ◦ cos—Sets a value from the CoS value or user priority. ◦ dscp—Sets a value from packet differentiated services code point (DSCP). ◦ precedence—Sets a value from packet precedence. ◦ qos-group—Sets a value from the QoS group. ◦ wlan—Sets a value from WLAN. • (Optional) table <i>table-map-name</i>—Indicates that the values set in a specified table map will be used to set the DSCP value. Enter the name of the table map used to specify the DSCP value. The table map name can be a maximum of 64 alphanumeric characters. <p>If you specify a packet-marking category but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the DSCP value. For example, if you enter the set dscp cos command, the CoS value (packet-marking category) is copied and used as the DSCP value.</p>
-------------	--

ip	<p>Sets IP values to the classified traffic. You can specify these values:</p> <ul style="list-style-type: none"> • dscp—Specify an IP DSCP value from 0 to 63 or a packet marking category. • precedence—Specify a precedence-bit value in the IP header; valid values are from 0 to 7 or specify a packet marking category.
-----------	---

precedence

Sets the precedence value in the packet header. You can specify these values:

- *precedence-value*— Sets the precedence bit in the packet header; valid values are from 0 to 7. You also can enter a mnemonic name for a commonly used value.
- Specify a packet marking category to set the precedence value of the packet.
 - **cos**—Sets a value from the CoS or user priority.
 - **dscp**—Sets a value from packet differentiated services code point (DSCP).
 - **precedence**—Sets a value from packet precedence.
 - **qos-group**—Sets a value from the QoS group.
- (Optional)**table** *table-map-name*—Indicates that the values set in a specified table map will be used to set the precedence value. Enter the name of the table map used to specify the precedence value. The table map name can be a maximum of 64 alphanumeric characters.

If you specify a packet-marking category but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the precedence value. For example, if you enter the **set precedence cos** command, the CoS value (packet-marking category) is copied and used as the precedence value.

qos-group

Assigns a QoS group identifier that can be used later to classify packets.

- *qos-group-value*—Sets a QoS value to the classified traffic. The range is 0 to 31. You also can enter a mnemonic name for a commonly used value.
- **dscp**—Sets the original DSCP field value of the packet as the QoS group value.
- **precedence**—Sets the original precedence field value of the packet as the QoS group value.
- (Optional) **table** *table-map-name*—Indicates that the values set in a specified table map will be used to set the DSCP or precedence value. Enter the name of the table map used to specify the value. The table map name can be a maximum of 64 alphanumeric characters.

If you specify a packet-marking category (**dscp** or **precedence**) but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the QoS group value. For example, if you enter the **set qos-group precedence** command, the precedence value (packet-marking category) is copied and used as the QoS group value.

wlan user-priority *wlan-user-priority*

Assigns a WLAN user-priority to the classified traffic. You can specify these values:

- *wlan-user-priority*—Sets a WLAN user priority to the classified traffic. The range is 0 to 7.
- **cos**—Sets the Layer 2 CoS field value as the WLAN user priority.
- **dscp**—Sets the DSCP field value as the WLAN user priority.
- **precedence**—Sets the precedence field value as the WLAN user priority.
- **wlan**—Sets the WLAN user priority field value as the WLAN user priority.
- (Optional) **table** *table-map-name*—Indicates that the values set in a specified table map will be used to set the WLAN user priority value. Enter the name of the table map used to specify the value. The table map name can be a maximum of 64 alphanumeric characters.

If you specify a packet-marking category but do not specify the table map, the default action is to copy the value associated with the packet-marking category as the WLAN user priority. For example, if you enter the **set wlan user-priority cos** command, the cos value (packet-marking category) is copied and used as the WLAN user priority.

Command Default

No traffic classification is defined.

Command Modes

Policy-map class configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.
Cisco IOS XE 3.3SE	The cos , dscp , qos-group , wlan <i>table-map-name</i> , keywords were added.

Usage Guidelines

For the **set dscp** *dscp-value* command, the **set cos** *cos-value* command, and the **set ip precedence** *precedence-value* command, you can enter a mnemonic name for a commonly used value. For example, you

can enter the **set dscp af11** command, which is the same as entering the **set dscp 10** command. You can enter the **set ip precedence critical** command, which is the same as entering the **set ip precedence 5** command. For a list of supported mnemonics, enter the **set dscp ?** or the **set ip precedence ?** command to see the command-line help strings.

When you configure the **set dscp cos** command, note the following: The CoS value is a 3-bit field, and the DSCP value is a 6-bit field. Only the three bits of the CoS field are used.

When you configure the **set dscp qos-group** command, note the following:

- The valid range for the DSCP value is a number from 0 to 63. The valid value range for the QoS group is a number from 0 to 99.
- If a QoS group value falls within both value ranges (for example, 44), the packet-marking value is copied and the packets is marked.
- If QoS group value exceeds the DSCP range (for example, 77), the packet-marking value is not be copied and the packet is not marked. No action is taken.

The **set qos-group** command cannot be applied until you create a service policy in policy-map configuration mode and then attach the service policy to an interface or ATM virtual circuit (VC).

To return to policy-map configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

Examples

This example shows how to assign DSCP 10 to all FTP traffic without any policers:

```
Controller(config)# policy-map policy_ftp
Controller(config-pmap)# class-map ftp_class
Controller(config-cmap)# exit
Controller(config)# policy policy_ftp
Controller(config-pmap)# class ftp_class
Controller(config-pmap-c)# set dscp 10
Controller(config-pmap)# exit
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Related Commands

Command	Description
class	Defines a traffic classification match criteria for the specified class-map name.
policy-map	Creates or modifies a policy map that can be attached to multiple physical ports or SVIs and enters policy-map configuration mode.
show policy-map	Displays QoS policy maps.

show ap name service-policy

To display service-policy information for a specific Cisco lightweight access point, use the **show ap name service-policy** command.

show ap name *ap-name* service-policy

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display service-policy information for a specific Cisco lightweight access point:

```
Controller# show ap name 3502b service-policy
```

```
NAME: Cisco AP      , DESCR: Cisco Wireless Access Point
PID: 3502I  , VID: V01, SN: FTX1525E94A
```

```
NAME: Dot11Radio0  , DESCR: 802.11N 2.4GHz Radio
PID: UNKNOWN, VID:  , SN: FOC1522BLNA
```

```
NAME: Dot11Radio1  , DESCR: 802.11N 5GHz Radio
PID: UNKNOWN, VID:  , SN: FOC1522BLNA
```

show ap name dot11

To display 802.11a or 802.11b configuration information that corresponds to specific Cisco lightweight access points, use the **show ap name dot11** command.

```
show ap name ap-name dot11 {24ghz| 5ghz} {ccx| cdp| profile| service-policy output| stats| tsm {all|
client-mac}}
```

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.
ccx	Displays the Cisco Client eXtensions (CCX) radio management status information.
cdp	Displays Cisco Discovery Protocol (CDP) information.
profile	Displays configuration and statistics of 802.11 profiling.
service-policy output	Displays downstream service policy information.
stats	Displays Cisco lightweight access point statistics.
tsm	Displays 802.11 traffic stream metrics statistics.
all	Displays the list of all access points to which the client has associations.
<i>client-mac</i>	MAC address of the client.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the service policy that is associated with the access point:

```
Controller# show ap name test-ap dot11 24ghz service-policy output
Policy Name : test-ap1
```

Policy State : Installed

This example shows how to display the CCX RRM 802.11 configuration for a specific access point:

```
Controller# show ap name AP01 dot11 24ghz ccx
```

This example show how to display CDP information for a specific access point:

```
Controller# show ap name AP01 dot11 24ghz cdp
```

```
AP Name                AP CDP State
-----
AP03                   Disabled
```

This example show how to display the configuration and statistics of 802.11b profiling for a specific access point:

```
Controller# show ap name AP01 dot11 24ghz profile
```

```
802.11b Cisco AP performance profile mode           : GLOBAL
802.11b Cisco AP Interference threshold            : 10 %
802.11b Cisco AP noise threshold                   : -70 dBm
802.11b Cisco AP RF utilization threshold          : 80 %
802.11b Cisco AP throughput threshold             : 1000000 bps
802.11b Cisco AP clients threshold                : 12 clients
```

This example show how to display downstream service policy information for a specific access point:

```
Controller# show ap name AP01 dot11 24ghz service-policy output
```

```
Policy Name : def-1lgn
Policy State : Installed
```

This example show how to display statistics for a specific access point:

```
Controller# show ap name AP01 dot11 24ghz stats
```

```
Number of Users.....: 0
TxFragmentCount.....: 0
MulticastTxFrameCnt.....: 0
FailedCount.....: 0
RetryCount.....: 0
MultipleRetryCount.....: 0
FrameDuplicateCount.....: 0
RtsSuccessCount.....: 0
RtsFailureCount.....: 0
AckFailureCount.....: 0
RxIncompleteFragment.....: 0
MulticastRxFrameCnt.....: 0
FcsErrorCount.....: 0
TxFrameCount.....: 0
WepUndecryptableCount.....: 0
TxFramesDropped.....: 0

Call Admission Control (CAC) Stats
  Voice Bandwidth in use(% of config bw).....: 0
  Video Bandwidth in use(% of config bw).....: 0
  Total BW in use for Voice(%).....: 0
  Total BW in use for SIP Preferred call(%).....: 0

Load based Voice Call Stats
  Total channel MT free.....: 0
  Total voice MT free.....: 0
  Na Direct.....: 0
  Na Roam.....: 0

WMM TSPEC CAC Call Stats
  Total num of voice calls in progress.....: 0
  Num of roaming voice calls in progress.....: 0
  Total Num of voice calls since AP joined.....: 0
  Total Num of roaming calls since AP joined.....: 0
```

```

Total Num of exp bw requests received.....: 0
Total Num of exp bw requests admitted.....: 0
Num of voice calls rejected since AP joined....: 0
Num of roam calls rejected since AP joined.....: 0
Num of calls rejected due to insufficient bw....: 0
Num of calls rejected due to invalid params....: 0
Num of calls rejected due to PHY rate.....: 0
Num of calls rejected due to QoS policy.....: 0

SIP CAC Call Stats
Total Num of calls in progress.....: 0
Num of roaming calls in progress.....: 0
Total Num of calls since AP joined.....: 0
Total Num of roaming calls since AP joined.....: 0
Total Num of Preferred calls received.....: 0
Total Num of Preferred calls accepted.....: 0
Total Num of ongoing Preferred calls.....: 0
Total Num of calls rejected(Insuff BW).....: 0
Total Num of roam calls rejected(Insuff BW)....: 0

Band Select Stats
Num of dual band client .....: 0
Num of dual band client added.....: 0
Num of dual band client expired .....: 0
Num of dual band client replaced.....: 0
Num of dual band client detected .....: 0
Num of suppressed client .....: 0
Num of suppressed client expired.....: 0
Num of suppressed client replaced.....: 0

```

This example show how to display the traffic stream configuration for all clients that correspond to a specific access point:

```
Controller# show ap name AP01 dot11 24ghz tsm all
```

show class-map

To display quality of service (QoS) class maps, which define the match criteria to classify traffic, use the **show class-map** command in EXEC mode.

show class-map [*class-map-name*]

Syntax Description

<i>class-map-name</i>	(Optional) The class map name.
-----------------------	--------------------------------

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This is an example of output from the **show class-map** command:

```
Controller# show class-map
Class Map match-any videowizard_10-10-10-10 (id 2)
  Match access-group name videowizard_10-10-10-10

Class Map match-any class-default (id 0)
  Match any
Class Map match-any dscp5 (id 3)
  Match ip dscp 5
```

Related Commands

Command	Description
class-map	Creates a class map to be used for matching packets to the class whose name you specify and enters class-map configuration mode.

show wireless client calls

To display the total number of active or rejected calls on the controller, use the **show wireless client calls** command in privileged EXEC mode.

show wireless client calls {active | rejected}

Syntax Description

active	Displays active calls.
rejected	Displays rejected calls.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **show wireless client calls** command:

```
controller# show wireless client calls active
```

```
TSPEC Calls:
```

```
-----
MAC Address      AP Name          Status           WLAN  Authenticated
-----
0000.1515.000f   AP-2             Associated       1    Yes
```

```
SIP Calls:
```

```
-----
Number of Active TSPEC calls on 802.11a and 802.11b/g: 1
Number of Active SIP calls on 802.11a and 802.11b/g: 0
```

show wireless client dot11

To display the total number of active or rejected calls for a specific band (2.4 Ghz or 5 Ghz), use the **show wireless client dot11** command in privileged EXEC mode.

show wireless client dot11 {24ghz | 5ghz} calls {active | rejected}

Syntax Description

24ghz	Displays the 802.11b/g network.
5ghz	Displays the 802.11a network.
calls	Displays the wireless client calls.
active	Displays active calls.
rejected	Displays rejected calls.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following is sample output from the **show wireless client dot11** command:

```
Controller# show wireless client dot11 5ghz calls active
```

```
TSPEC Calls:
-----
```

```
SIP Calls:
-----
```

```
Number of Active TSPEC calls on 802.11a: 0
Number of Active SIP calls on 802.11a: 0
```

show wireless client mac-address (Call Control)

To view call control information related to clients, use the **show wireless client mac-address** command in privileged EXEC mode.

show wireless client mac-address *mac-address* **call-control call-info**

Syntax Description	
<i>mac-address</i>	The client MAC address.
call-control call-info	Displays the call control and IP-related information about a client.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display call control and IP-related information about a client:

```

Controller# show wireless client mac-address 30e4.db41.6157 call-control call-info
Client MAC Address      : 30E4DB416157

Call 1 Statistics

Uplink IP Address      : 209.165.200.225
Downlink IP Address    : 209.165.200.226
Uplink Port            : 29052
Downlink Port         : 27538
Call ID               : c40acb4d-3b3b0.3d27dale-356bed03
Called Party          : sip:1011
Calling Party         : sip:1012
Priority              : 6
Call On Hold          : false
Call Duration         : 30

Call 2 Statistics

No Active Call

```

show wireless client mac-address (TCLAS)

To view information about TCLAS and user priority, use the **show wireless client mac-address** command in privileged EXEC mode.

show wireless client mac-address *mac-address* **tclas**

Syntax Description

<i>mac-address</i>	The client MAC address.
tclas	Displays TCLAS and user priority-related information about a client.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the TCLAS and user priority-related information about a client:

```
Controller# show wireless client mac-address 30e4.db41.6157 tclas
MAC Address      UP TID Mask Source IP Addr  Dest IP Addr  SrcPort DstPort Proto
-----
30e4.db41.6157   4  4  95 167838052      2164326668    5060    5060    6
30e4.db41.6157   6  1  31 0              2164326668     0      27538   17
```

show wireless client voice diagnostics

To display wireless client voice diagnostic parameters, use the **show wireless client voice diagnostics** command in privileged EXEC mode.

show wireless client voice diagnostics {qos-map | roam-history | rssi | status | tspec}

Syntax Description

qos-map	Displays information about the QoS and DSCP mapping and packet statistics in each of the four queues: VO, VI, BE, BK. The different DSCP values are also displayed.
roam-history	Displays information about the last 3 roaming histories for each known client. The output contains the timestamp, access point associated with roaming, roaming reason, and if there is a roaming failure, a reason for the roaming failure.
rssi	Displays the client's RSSI values in the last 5 seconds when voice diagnostics are enabled.
status	Displays status of voice diagnostics for clients.
tspec	Displays voice diagnostics that are enabled for TSPEC clients.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Debug voice diagnostics must be enabled for voice diagnostics to work.

Examples

The following is sample output from the **show wireless client voice diagnostics status** command:

```
Controller# show wireless client voice diagnostics status
Voice Diagnostics Status: FALSE
```

show policy-map

To display quality of service (QoS) policy maps, which define classification criteria for incoming traffic, use the **show policy-map** command in EXEC mode.

show policy-map [*policy-map-name*] **interface** *interface-id*

Syntax Description

<i>policy-map-name</i>	(Optional) Name of the policy-map.
interface <i>interface-id</i>	(Optional) Identifies the interface.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.
Cisco IOS XE 3.3SE	The interface <i>interface-id</i> keyword was added.

Usage Guidelines

Policy maps can include policers that specify the bandwidth limitations and the action to take if the limits are exceeded.



Note

Though visible in the command-line help string, the **control-plane**, **session**, and **type** keywords are not supported, and the statistics shown in the display should be ignored.

To display classification counters for ternary content addressable memory (TCAM) (marking or policing) based policies, enter the interface ID. Classification counters have the following restrictions:

- Classification counters are supported only on wired ports (in the ingress and egress directions).
- Classification counters count packets instead of bytes.
- Only QoS configurations with marking or policing trigger the classification counter.
- As long as there is policing or marking action in the policy, the class-default will have classification counters.
- Classification counters are not port based. The counters are shared across targets sharing the same policy map. This means that the classification counter aggregates all packets belonging to the same class of the same policy which attach to different interfaces.

Examples

This is an example of output from the **show policy-map interface** command, where classification counters are displayed:

```

Controller# show policy-map interface gigabitEthernet1/0/1

GigabitEthernet1/0/1

Service-policy input: AutoQos-4.0-CiscoPhone-Input-Policy

Class-map: AutoQos-4.0-Voip-Data-CiscoPhone-Class (match-any)
 0 packets
 Match: cos 5
       0 packets, 0 bytes
       5 minute rate 0 bps
 QoS Set
 dscp ef
 police:
   cir 128000 bps, bc 8000 bytes
   conformed 0 bytes; actions:
     transmit
   exceeded 0 bytes; actions:
     set-dscp-transmit dscp table policed-dscp
   conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Voip-Signal-CiscoPhone-Class (match-any)
 0 packets
 Match: cos 3
       0 packets, 0 bytes
       5 minute rate 0 bps
 QoS Set
 dscp cs3
 police:
   cir 32000 bps, bc 8000 bytes
   conformed 0 bytes; actions:
     transmit
   exceeded 0 bytes; actions:
     set-dscp-transmit dscp table policed-dscp
   conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Default-Class (match-any)
 0 packets
 Match: access-group name AutoQos-4.0-Acl-Default
       0 packets, 0 bytes
       5 minute rate 0 bps
 QoS Set
 dscp default

Class-map: class-default (match-any)
 0 packets
 Match: any
       0 packets, 0 bytes
       5 minute rate 0 bps

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
 Queueing
 priority level 1

 (total drops) 0
 (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
 0 packets
 Match: dscp cs4 (32) cs5 (40) ef (46)
       0 packets, 0 bytes
       5 minute rate 0 bps
 Match: cos 5
       0 packets, 0 bytes
       5 minute rate 0 bps

```

```

Priority: 30% (300000 kbps), burst bytes 7500000,
Priority Level: 1
Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
    queue-limit dscp 16 percent 80
    queue-limit dscp 24 percent 90
    queue-limit dscp 48 percent 100
    queue-limit dscp 56 percent 100

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%

  queue-buffers ratio 10
Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
  0 packets
  Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 4
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10
Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
  0 packets
  Match: dscp af21 (18) af22 (20) af23 (22)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 2
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10
Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
  0 packets
  Match: dscp af11 (10) af12 (12) af13 (14)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 1
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 4%
  queue-buffers ratio 10
Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
  0 packets
  Match: dscp cs1 (8)
    0 packets, 0 bytes

```

```

    5 minute rate 0 bps
    Queueing

    (total drops) 0
    (bytes output) 0
    bandwidth remaining 1%
    queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
  0 packets
  Match: dscp af31 (26) af32 (28) af33 (30)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%
  queue-buffers ratio 10

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 25%
  queue-buffers ratio 25

```

Related Commands

Command	Description
policy-map	Creates or modifies a policy map that can be attached to multiple physical ports or SVIs and enters policy-map configuration mode.

show wlan

To view WLAN parameters, use the **show wlan** command.

show wlan {**all** | **id** *wlan-id* | **name** *wlan-name* | **summary**}

Syntax Description

all	Displays a summary of parameters of all configured WLANs. The list is ordered by the ascending order of the WLAN IDs.
id <i>wlan-id</i>	Specifies the wireless LAN identifier. The range is from 1 to 512.
name <i>wlan-name</i>	Specifies the WLAN profile name. The name is from 1 to 32 characters.
summary	Displays a summary of the parameters configured on a WLAN.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display a summary of the WLANs configured on the device:

```
Controller# show wlan summary
Number of WLANs: 1
```

```
WLAN Profile Name          SSID                      VLAN Status
-----
45  test-wlan                test-wlan-ssid           1    UP
```

This example shows how to display a summary of parameters configured on a particular WLAN:

```
Controller# show wlan name test-wlan
WLAN Identifier             : 45
Profile Name                : test-wlan
Network Name (SSID)        : test-wlan-ssid
Status                      : Enabled
Broadcast SSID              : Enabled
Maximum number of Associated Clients : 0
AAA Policy Override         : Disabled
Network Admission Control
  NAC-State                  : Disabled
Number of Active Clients    : 0
Exclusionlist Timeout       : 60
Session Timeout             : 1800 seconds
```

```

CHD per WLAN : Enabled
Webauth DHCP exclusion : Disabled
Interface : default
Interface Status : Up
Multicast Interface : test
WLAN IPv4 ACL : test
WLAN IPv6 ACL : unconfigured
DHCP Server : Default
DHCP Address Assignment Required : Disabled
DHCP Option 82 : Disabled
DHCP Option 82 Format : ap-mac
DHCP Option 82 Ascii Mode : Disabled
DHCP Option 82 Rid Mode : Disabled
QoS Service Policy - Input
  Policy Name : unknown
  Policy State : None
QoS Service Policy - Output
  Policy Name : unknown
  Policy State : None
QoS Client Service Policy
  Input Policy Name : unknown
  Output Policy Name : unknown
WifiDirect : Disabled
WMM : Disabled
Channel Scan Defer Priority:
  Priority (default) : 4
  Priority (default) : 5
  Priority (default) : 6
Scan Defer Time (msecs) : 100
Media Stream Multicast-direct : Disabled
CCX - AironetIe Support : Enabled
CCX - Gratuitous ProbeResponse (GPR) : Disabled
CCX - Diagnostics Channel Capability : Disabled
Dot11-Phone Mode (7920) : Invalid
Wired Protocol : None
Peer-to-Peer Blocking Action : Disabled
Radio Policy : All
DTIM period for 802.11a radio : 1
DTIM period for 802.11b radio : 1
Local EAP Authentication : Disabled
Mac Filter Authorization list name : Disabled
Accounting list name : Disabled
802.1x authentication list name : Disabled
Security
  802.11 Authentication : Open System
  Static WEP Keys : Disabled
  802.1X : Disabled
  Wi-Fi Protected Access (WPA/WPA2) : Enabled
    WPA (SSN IE) : Disabled
    WPA2 (RSN IE) : Enabled
    TKIP Cipher : Disabled
    AES Cipher : Enabled
  Auth Key Management
    802.1x : Enabled
    PSK : Disabled
    CCKM : Disabled
  IP Security : Disabled
  IP Security Passthru : Disabled
  L2TP : Disabled
  Web Based Authentication : Disabled
  Conditional Web Redirect : Disabled
  Splash-Page Web Redirect : Disabled
  Auto Anchor : Disabled
  Sticky Anchoring : Enabled
  Cranite Passthru : Disabled
  Fortress Passthru : Disabled
  PPTP : Disabled
  Infrastructure MFP protection : Enabled
  Client MFP : Optional
  Webauth On-mac-filter Failure : Disabled
  Webauth Authentication List Name : Disabled
  Webauth Parameter Map : Disabled
  Tkip MIC Countermeasure Hold-down Timer : 60

```

```
Call Snooping           : Disabled
Passive Client          : Disabled
Non Cisco WGB          : Disabled
Band Select             : Disabled
Load Balancing          : Disabled
IP Source Guard         : Disabled
Netflow Monitor        : test
    Direction           : Input
    Traffic              : Datalink

Mobility Anchor List
IP Address
-----
```

trust device

To configure trust for supported devices connected to an interface, use the **trust device** command in interface configuration mode. Use the **no** form of this command to disable trust for the connected device.

```
trust device {cisco-phone | cts | ip-camera | media-player}
```

```
no trust device {cisco-phone | cts | ip-camera | media-player}
```

Syntax Description

cisco-phone	Configures a Cisco IP phone
cts	Configures a Cisco TelePresence System
ip-camera	Configures an IP Video Surveillance Camera (IPVSC)
media-player	Configures a Cisco Digital Media Player (DMP)

Command Default

Trust disabled

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use the **trust device** command on the following types of interfaces:

- **Auto**— auto-template interface
- **Capwap**—CAPWAP tunnel interface
- **GigabitEthernet**—Gigabit Ethernet IEEE 802
- **GroupVI**—Group virtual interface
- **Internal Interface**—Internal interface
- **Loopback**—Loopback interface
- **Null**—Null interface
- **Port-channel**—Ethernet Channel interface
- **TenGigabitEthernet--10-Gigabit Ethernet**
- **Tunnel**—Tunnel interface

- **Vlan**—Catalyst VLANs
- **range**—**interface range** command

Examples

The following example configures trust for a Cisco IP phone in Interface GigabitEthernet 1/0/1:

```
Controller(config)# interface GigabitEthernet1/0/1  
Controller(config-if)# trust device cisco-phone
```

You can verify your settings by entering the **show interface status** privileged EXEC command.



PART 

Interface

- [Interface Commands, page 187](#)



Interface Commands

This chapter displays the following commands:

-
- [client vlan](#) , page 189
- [clear nmsp statistics](#), page 190
- [debug ilpower](#), page 191
- [debug interface](#), page 192
- [debug lldp packets](#), page 194
- [debug platform fallback-bridging](#), page 195
- [duplex](#), page 197
- [interface](#), page 199
- [interface auto-template](#), page 201
- [interface range](#), page 202
- [location](#), page 203
- [logging event power-inline-status](#), page 207
- [show CAPWAP summary](#), page 208
- [show env](#), page 209
- [show errdisable detect](#), page 211
- [show errdisable recovery](#), page 212
- [show interfaces](#), page 213
- [show interfaces counters](#), page 217
- [show location](#), page 219
- [show mgmt-infra trace messages ilpower-ha](#), page 221
- [show network-policy profile](#), page 222
- [show nmsp](#), page 223

- [show platform CAPWAP summary, page 226](#)
- [show network-policy profile, page 227](#)
- [show wireless interface summary, page 228](#)
- [system mtu, page 229](#)
- [wireless ap-manager interface, page 230](#)
- [wireless exclusionlist, page 231](#)
- [wireless linktest, page 232](#)
- [wireless management interface, page 233](#)
- [wireless peer-blocking forward-upstream, page 234](#)

client vlan

To configure a wireless LAN interface, use the **client vlan** command. To remove a wireless LAN interface, use the **no** form of the command.

client vlan *interface-name*

no client vlan

Syntax Description

vlan <i>interface-name</i>	Specifies the name of the interface.
-----------------------------------	--------------------------------------

Command Default

Disabled

Command Modes

Configuration mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure vlan10 on an interface:

```
Controller# client vlan vlan10
```

clear nmsp statistics

To clear the Network Mobility Services Protocol (NMSP) statistics, use the **clear nmsp statistics** command in privileged EXEC mode.

clear nmsp statistics

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to clear NMSP statistics:

```
Controller# clear nmsp statistics
```

You can verify that information was deleted by entering the **show nmsp statistics** privileged EXEC command.

debug ilpower

To enable debugging of the power controller and Power over Ethernet (PoE) system, use the **debug ilpower** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

```
debug ilpower {cdp| controller| event| ha| port| powerman| registries| scp | sense}
no debug ilpower {cdp| controller| event| ha| port| powerman| registries| scp | sense}
```

Syntax Description

cdp	Displays PoE Cisco Discovery Protocol (CDP) debug messages.
controller	Displays PoE controller debug messages.
event	Displays PoE event debug messages.
ha	Displays PoE high-availability messages.
port	Displays PoE port manager debug messages.
powerman	Displays PoE power management debug messages.
registries	Displays PoE registries debug messages.
scp	Displays PoE SCP debug messages.
sense	Displays PoE sense debug messages.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

This command is supported only on PoE-capable switches.

When you enable debugging on a switch stack, it is enabled only on the stack master. To enable debugging on a stack member, you can start a session from the stack master by using the **session** *switch-number* EXEC command. Then enter the **debug** command at the command-line prompt of the stack member. You also can use the **remote command** *stack-member-number* *LINE* EXEC command on the stack master switch to enable debugging on a member switch without first starting a session.

debug interface

To enable debugging of interface-related activities, use the **debug interface** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug interface *{interface-id}* **counters** *{exceptions|protocol memory}* | **null** *interface-number* | **port-channel** *port-channel-number* | **states** | **vlan** *vlan-id*}

no debug interface *{interface-id}* **counters** *{exceptions|protocol memory}* | **null** *interface-number* | **port-channel** *port-channel-number* | **states** | **vlan** *vlan-id*}

Syntax Description

<i>interface-id</i>	ID of the physical interface. Displays debug messages for the specified physical port, identified by type switch number/module number/port, for example, gigabitethernet 1/0/2.
null <i>interface-number</i>	Displays debug messages for null interfaces. The interface number is always 0 .
port-channel <i>port-channel-number</i>	Displays debug messages for the specified EtherChannel port-channel interface. The <i>port-channel-number</i> range is 1 to 48.
vlan <i>vlan-id</i>	Displays debug messages for the specified VLAN. The vlan range is 1 to 4094.
counters	Displays counters debugging information.
exceptions	Displays debug messages when a recoverable exceptional condition occurs during the computation of the interface packet and data rate statistics.
protocol memory	Displays debug messages for memory operations of protocol counters.
states	Displays intermediary debug messages when an interface's state transitions.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

If you do not specify a keyword, all debug messages appear.

The **undebug interface** command is the same as the **no debug interface** command.

When you enable debugging on a switch stack, it is enabled only on the stack master. To enable debugging on a stack member, you can start a session from the stack master by using the **session** *switch-number* EXEC command. Then enter the **debug** command at the command-line prompt of the stack member. You also can use the **remote command** *stack-member-number* *LINE* EXEC command on the stack master switch to enable debugging on a member switch without first starting a session.

debug lldp packets

To enable debugging of Link Layer Discovery Protocol (LLDP) packets, use the **debug lldp packets** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug lldp packets

no debug lldp packets

Syntax Description This command has no arguments or keywords.

Command Default Debugging is disabled.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines The **undebug lldp packets** command is the same as the **no debug lldp packets** command. When you enable debugging on a switch stack, it is enabled only on the . To enable debugging on a stack member, you can start a session from the by using the **session switch-number** EXEC command.

debug platform fallback-bridging

To enable debugging of the platform-dependent fallback bridging manager, use the **debug platform fallback-bridging** command in EXEC mode. To disable debugging, use the **no** form of this command.

debug platform fallback-bridging [**error**| **retry**| **rpc** {**events**| **messages**}]

no debug platform fallback-bridging [**error**| **retry**| **rpc** {**events**| **messages**}]

Syntax Description

error	(Optional) Displays fallback bridging manager error condition messages.
retry	(Optional) Displays fallback bridging manager retry messages.
rpc { events messages }	(Optional) Displays fallback bridging debugging information. The keywords have these meanings: <ul style="list-style-type: none"> • events—Displays remote procedure call (RPC) events. • messages —Displays RPC messages.

Command Default

Debugging is disabled.

Command Modes

User EXEC

Privileged EXEC

Command History

Release	Modification
15.0	This command was introduced.

Usage Guidelines

If you do not specify a keyword, all fallback bridging manager debug messages appear.

The **undebug platform fallback-bridging** command is the same as the **no debug platform fallback-bridging** command.

When you enable debugging on a switch stack, it is enabled only on the stack master. To enable debugging on a stack member, you can start a session from the stack master by using the **session switch-number** EXEC command. Then enter the **debug** command at the command-line prompt of the stack member. You also can use the **remote command stack-member-number LINE** EXEC command on the stack master switch to enable debugging on a member switch without first starting a session.

Related Commands

Command	Description
show debugging	Displays information about the types of debugging that are enabled.

duplex

To specify the duplex mode of operation for a port, use the **duplex** command in interface configuration mode. To return to the default value, use the **no** form of this command.

duplex {**auto**| **full**| **half**}

no duplex {**auto**| **full**| **half**}

Syntax Description

auto	Enables automatic duplex configuration. The port automatically detects whether it should run in full- or half-duplex mode, depending on the attached device mode.
full	Enables full-duplex mode.
half	Enables half-duplex mode (only for interfaces operating at 10 or 100 Mb/s). You cannot configure half-duplex mode for interfaces operating at 1000 or 10,000 Mb/s.

Command Default

The default is **auto** for Gigabit Ethernet ports.

Duplex options are not supported on the 1000BASE-*x* or 10GBASE-*x* (where *x* is -BX, -CWDM, -LX, -SX, or -ZX) small form-factor pluggable (SFP) modules.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

For Gigabit Ethernet ports, setting the port to **auto** has the same effect as specifying **full** if the attached device does not autonegotiate the duplex parameter.



Note

Half-duplex mode is supported on Gigabit Ethernet interfaces if the duplex mode is **auto** and the connected device is operating at half duplex. However, you cannot configure these interfaces to operate in half-duplex mode.

Certain ports can be configured to be either full duplex or half duplex. How this command is applied depends on the device to which the switch is attached.

If both ends of the line support autonegotiation, we highly recommend using the default autonegotiation settings. If one interface supports autonegotiation and the other end does not, configure duplex and speed on both interfaces, and use the **auto** setting on the supported side.

If the speed is set to **auto**, the switch negotiates with the device at the other end of the link for the speed setting and then forces the speed setting to the negotiated value. The duplex setting remains as configured on each end of the link, which could result in a duplex setting mismatch.

You can configure the duplex setting when the speed is set to **auto**.

**Caution**

Changing the interface speed and duplex mode configuration might shut down and reenables the interface during the reconfiguration.

You can verify your setting by entering the **show interfaces** privileged EXEC command.

Examples

This example shows how to configure an interface for full-duplex operation:

```
Controller(config)# interface gigabitethernet1/0/1
Controller(config-if)# duplex full
```

interface

To configure an interface, use the **interface** command.

interface {**Auto-Template** *Auto-Template interface-number* | **Capwap** *Capwap interface-number* | **Gigabit Ethernet** *Gigabit Ethernet interface number* | **Group VI** *Group VI interface number* | **Internal Interface** *Internal Interface number* | **Loopback** *Loopback interface number* | **Null** *Null interface number* | **Port-channel** *interface number* | **TenGigabit Ethernet** *interface number* | **Tunnel** *interface number* | **Vlan** *interface number*}

Syntax Description

Auto-Template <i>Auto-template interface-number</i>	Enables you to configure auto-template interface. Values range from 1 to 999.
Capwap <i>Capwap interface number</i>	Enables you to configure CAPWAP tunnel interface. Values range from 0 to 2147483647.
GigabitEthernet <i>Gigabit Ethernet interface number</i>	Enables you to configure Gigabit Ethernet IEEE 802.3z interface. Values range from 0 to 9.
Group VI <i>Group VI interface number</i>	Enables you to configure the internal interface. Values range from 0 to 9.
Internal Interface <i>Internal Interface</i>	Enables you to configure internal interface.
Loopback <i>Loopback Interface number</i>	Enables you to configure loopback interface. Values range from 0 to 2147483647.
Null <i>Null interface number</i>	Enables you to configure null interface. Value is 0.
Port-channel <i>interface number</i>	Enables you to configure Ethernet channel interfaces. Values range from 1 to 128.
TenGigabitEthernet <i>interface number</i>	Enables you to configure a 10-Gigabit Ethernet interface. Values range from 0 to 9.
Tunnel <i>interface number</i>	Enables you to configure the tunnel interface. Values range from 0 to 2147483647.
Vlan <i>interface number</i>	Enables you to configure switch VLAN interfaces. Values range from 0 to 4098.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can not use the "no" form of this command.

Examples

This example shows how you can configure interface:

```
Controller# interface Tunnel 15
```

interface auto-template

To configure an auto-template interface, use the **interface auto-template** command.

```
interface auto-template interface-name
```

Syntax Description

<i>interface-name</i>	Specifies the interface number.
-----------------------	---------------------------------

Command Default

Disabled

Command Modes

Global configuration mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure interface auto-template:

```
# interface auto-template
```

interface range

To configure an interface range, use the **interface range** command.

interface range {**Gigabit Ethernet** *interface-number* | **Loopback** *interface-number* | **Port Channel** *interface-number* | **TenGigabit Ethernet** *interface-number* **Tunnel** *interface-number* **Vlan** *interface-number* **Macro** *WORD*}

Syntax Description

GigabitEthernet <i>interface-number</i>	Configures the Gigabit Ethernet IEEE 802.3z interface. Values range from 1 to 9.
Loopback <i>interface-number</i>	Configures the loopback interface. Values range from 0 to 2147483647.
Port-Channel <i>interface-number</i>	Configures 10-Gigabit Ethernet channel of interfaces. Values range from 1 to 128.
TenGigabit Ethernet <i>interface-number</i>	Configures 10-Gigabit Ethernet interfaces. Values range from 0 to 9.
Tunnel <i>interface-number</i>	Configures the tunnel interface. Values range from 0 to 2147483647.
VLAN <i>interface-number</i>	Configures the switch VLAN interfaces. Values range from 1 to 4095.
Macro <i>WORD</i>	Configures the keywords to interfaces. Support up to 32 characters.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how you can configure interface range:

```
Controller(config)# interface range vlan 1
```

location

To configure location information for an endpoint, use the **location** command in global configuration mode. To remove the location information, use the **no** form of this command.

location {**admin-tag** *string*| **civic-location identifier** {**host** *id*}| **elin-location** *string identifier id*| **geo-location identifier** {**host** *id*}}

no location {**admin-tag** *string*| **civic-location identifier** {**host** *id*}| **elin-location** *string identifier id*| **geo-location identifier** {**host** *id*}}

Syntax Description

admin-tag	Configures administrative tag or site information.
<i>string</i>	Site or location information in alphanumeric format.
civic-location	Configures civic location information.
identifier	Specifies the name of the civic location, emergency, or geographical location.
host	Defines the host civic or geo-spatial location.
<i>id</i>	Name of the civic, emergency, or geographical location. Note The identifier for the civic location in the LLDP-MED controller TLV is limited to 250 bytes or less. To avoid error messages about available buffer space during controller configuration, be sure that the total length of all civic-location information specified for each civic-location identifier does not exceed 250 bytes.
elin-location	Configures emergency location information (ELIN).
geo-location	Configures geo-spatial location information.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

After entering the **location civic-location identifier** global configuration command, you enter civic location configuration mode. After entering the **location geo-location identifier** global configuration command, you enter geo location configuration mode.

The civic-location identifier must not exceed 250 bytes.

The host identifier configures the host civic or geo-spatial location. If the identifier is not a host, the identifier only defines a civic location or geo-spatial template that can be referenced on the interface.

The **host** keyword defines the device location. The civic location options available for configuration using the **identifier** and the **host** keyword are the same. You can specify the following civic location options in civic location configuration mode:

- **additional-code**—Sets an additional civic location code.
- **additional-location-information**—Sets additional civic location information.
- **branch-road-name**—Sets the branch road name.
- **building**—Sets building information.
- **city**—Sets the city name.
- **country**—Sets the two-letter ISO 3166 country code.
- **county**—Sets the county name.
- **default**—Sets a command to its defaults.
- **division**—Sets the city division name.
- **exit**—Exits from the civic location configuration mode.
- **floor**—Sets the floor number.
- **landmark**—Sets landmark information.
- **leading-street-dir**—Sets the leading street direction.
- **name**—Sets the resident name.
- **neighborhood**—Sets neighborhood information.
- **no**—Negates the specified civic location data and sets the default value.
- **number**—Sets the street number.
- **post-office-box**—Sets the post office box.
- **postal-code**—Sets the postal code.
- **postal-community-name**—Sets the postal community name.
- **primary-road-name**—Sets the primary road name.
- **road-section**—Sets the road section.
- **room**—Sets room information.
- **seat**—Sets seat information.
- **state**—Sets the state name.

- **street-group**—Sets the street group.
- **street-name-postmodifier**—Sets the street name postmodifier.
- **street-name-premodifier**—Sets the street name premodifier.
- **street-number-suffix**—Sets the street number suffix.
- **street-suffix**—Sets the street suffix.
- **sub-branch-road-name**—Sets the sub-branch road name.
- **trailing-street-suffix**—Sets the trailing street suffix.
- **type-of-place**—Sets the type of place.
- **unit**—Sets the unit.

You can specify the following geo-spatial location information in geo-location configuration mode:

- **altitude**—Sets altitude information in units of floor, meters, or feet.
- **latitude**—Sets latitude information in degrees, minutes, and seconds. The range is from -90 degrees to 90 degrees. Positive numbers indicate locations north of the equator.
- **longitude**—Sets longitude information in degrees, minutes, and seconds. The range is from -180 degrees to 180 degrees. Positive numbers indicate locations east of the prime meridian.
- **resolution**—Sets the resolution for latitude and longitude. If the resolution value is not specified, default value of 10 meters is applied to latitude and longitude resolution parameters. For latitude and longitude, the resolution unit is measured in meters. The resolution value can also be a fraction.
- **default**—Sets the geographical location to its default attribute.
- **exit**—Exits from geographical location configuration mode.
- **no**—Negates the specified geographical parameters and sets the default value.

Use the **no lldp med-tlv-select location information** interface configuration command to disable the location TLV. The location TLV is enabled by default.

Examples

This example shows how to configure civic location information on the controller:

```
Controller(config)# location civic-location identifier 1
Controller(config-civic)# number 3550
Controller(config-civic)# primary-road-name "Cisco Way"
Controller(config-civic)# city "San Jose"
Controller(config-civic)# state CA
Controller(config-civic)# building 19
Controller(config-civic)# room C6
Controller(config-civic)# county "Santa Clara"
Controller(config-civic)# country US
Controller(config-civic)# end
```

You can verify your settings by entering the **show location civic-location** privileged EXEC command.

This example shows how to configure the emergency location information on the controller:

```
Controller(config)# location elin-location 14085553881 identifier 1
```

You can verify your settings by entering the **show location elin** privileged EXEC command.

The following example shows how to configure geo-spatial location information on the controller:

```
Controller(config)# location geo-location identifier host
Controller(config-geo)# latitude 12.34
Controller(config-geo)# longitude 37.23
Controller(config-geo)# altitude 5 floor
Controller(config-geo)# resolution 12.34
```

You can use the **show location geo-location identifier** command to display the configured geo-spatial location details.

logging event power-inline-status

To enable the logging of Power over Ethernet (PoE) events, use the **logging event power-inline-status** command in interface configuration mode. To disable the logging of PoE status events, use the **no** form of this command.

logging event power-inline-status

no logging event power-inline-status

Syntax Description This command has no arguments or keywords.

Command Default Logging of PoE events is enabled.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines The **no** form of this command does not disable PoE error events.

Examples This example shows how to enable logging of PoE events on a port:

```
Controller(config-if)# interface gigabitethernet1/0/1
Controller(config-if)# logging event power-inline-status
Controller(config-if)#
```

show CAPWAP summary

To display all the CAPWAP tunnels established by the controller to access points and other mobility controllers use the **show CAPWAP summary** command.

show CAPWAP summary

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how to display CAPWAP tunnels established by the controllers to the access points and other controllers.

```

Controller# show capwap summary
CAPWAP Tunnels General Statistics:
Number of Capwap Data Tunnels = 8
Number of Capwap Mobility Tunnels = 0
Number of Capwap Multicast Tunnels = 0
Name APName Type PhyPortIf Mode McastIf
-----
Ca4 AP-Behind-Router data - unicast -
Ca0 AP1142-kat data - unicast -
Ca5 APRFCHAMBER2-EDISON data - unicast -
Ca6 KATANA_2_RF data - unicast -
Ca1 AP-1040-RF data - unicast -
Ca7 KATANA_1_RF data - unicast -
Ca2 AP3500-2027 data - unicast -
Ca3 AP-1040-out data - unicast -

```

show env

To display fan, temperature, and power information, use the **show env** command in EXEC mode.

```
show env {all|fan|power [all]|switch [stack-member-number]} stack [stack-member-number] | temperature [status]
```

Syntax Description

all	Displays the fan and temperature environmental status and the status of the internal power supplies.
fan	Displays the switch fan status.
power	Displays the internal power status of the active switch.
all	(Optional) Displays the status of all the internal power supplies in a standalone switch when the command is entered on the switch, or in all the stack members when the command is entered on the .
switch	(Optional) Displays the status of the internal power supplies for each switch in the stack or for the specified switch. This keyword is available only on stacking-capable switches.
<i>stack-member-number</i>	(Optional) Number of the stack member for which to display the status of the internal power supplies or the environmental status.
stack	Displays all environmental status for each switch in the stack or for the specified switch. This keyword is available only on stacking-capable switches.
temperature	Displays the switch temperature status.
status	(Optional) Displays the switch internal temperature (not the external temperature) and the threshold values.

Command Default

None

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use the **show env EXEC** command to display the information for the switch being accessed—a standalone switch or the . Use this command with the **stack** and **switch** keywords to display all information for the stack or for the specified stack member.

If you enter the **show env temperature status** command, the command output shows the switch temperature state and the threshold level.

You can also use the **show env temperature** command to display the switch temperature status. The command output shows the green and yellow states as *OK* and the red state as *FAULTY*. If you enter the **show env all** command, the command output is the same as the **show env temperature status** command output.

Examples

This is an example of output from the **show env all** command:

This is an example of output from the **show env fan** command:

This is an example of output from the **show env power all** command on the :

This is an example of output from the **show env stack** command on the :

This example shows how to display the temperature value, state, and the threshold values on a standalone switch. The table describes the temperature states in the command output.

Table 8: States in the show env temperature status Command Output

State	Description
Green	The switch temperature is in the <i>normal</i> operating range.
Yellow	The temperature is in the <i>warning</i> range. You should check the external temperature around the switch.
Red	The temperature is in the <i>critical</i> range. The switch might not run properly if the temperature is in this range.

show errdisable detect

To display error-disabled detection status, use the **show errdisable detect** command in EXEC mode.

show errdisable detect

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines A gbic-invalid error reason refers to an invalid small form-factor pluggable (SFP) module. The error-disable reasons in the command output are listed in alphabetical order. The mode column shows how error-disable is configured for each feature.

You can configure error-disabled detection in these modes:

- port mode—The entire physical port is error-disabled if a violation occurs.
- vlan mode—The VLAN is error-disabled if a violation occurs.
- port/vlan mode—The entire physical port is error-disabled on some ports and is per-VLAN error-disabled on other ports.

Examples This is an example of output from the **show errdisable detect** command:

show errdisable recovery

To display the error-disabled recovery timer information, use the **show errdisable recovery** command in EXEC mode.

show errdisable recovery

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines A gbic-invalid error-disable reason refers to an invalid small form-factor pluggable (SFP) module interface.



Note Though visible in the output, the unicast-flood field is not valid.

Examples This is an example of output from the **show errdisable recovery** command:

show interfaces

To display the administrative and operational status of all interfaces or for a specified interface, use the **show interfaces** command in privileged EXEC mode.

show interfaces [*interface-id*] **vlan** *vlan-id*] [**accounting**| **capabilities** [**module** *number*]] **debounce**| **description**| **etherchannel**| **flowcontrol**| **private-vlan mapping**| **pruning**| **stats**| **status** [**err-disabled**]] **trunk**]

Syntax Description

<i>interface-id</i>	(Optional) ID of the interface. Valid interfaces include physical ports (including type, stack member for stacking-capable switches, module, and port number) and port channels. The port channel range is 1 to 48.
vlan <i>vlan-id</i>	(Optional) VLAN identification. The range is 1 to 4094.
accounting	(Optional) Displays accounting information on the interface, including active protocols and input and output packets and octets. Note The display shows only packets processed in software; hardware-switched packets do not appear.
capabilities	(Optional) Displays the capabilities of all interfaces or the specified interface, including the features and options that you can configure on the interface. Though visible in the command line help, this option is not available for VLAN IDs.
module <i>number</i>	(Optional) Displays capabilities of all interfaces on the switch or specified stack member. This option is not available if you entered a specific interface ID.
description	(Optional) Displays the administrative status and description set for an interface.
etherchannel	(Optional) Displays interface EtherChannel information.
flowcontrol	(Optional) Displays interface flow control information.
private-vlan mapping	(Optional) Displays private-VLAN mapping information for the VLAN switch virtual interfaces (SVIs). This keyword is not available if the switch is running the LAN base feature set.
pruning	(Optional) Displays trunk VTP pruning information for the interface.
stats	(Optional) Displays the input and output packets by switching the path for the interface.
status	(Optional) Displays the status of the interface. A status of unsupported in the Type field means that a non-Cisco small form-factor pluggable (SFP) module is inserted in the module slot.

err-disabled	(Optional) Displays interfaces in an error-disabled state.
trunk	(Optional) Displays interface trunk information. If you do not specify an interface, only information for active trunking ports appears.

**Note**

Though visible in the command-line help strings, the **crb**, **fair-queue**, **irb**, **mac-accounting**, **precedence**, **random-detect**, **rate-limit**, and **shape** keywords are not supported.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **show interfaces capabilities** command with different keywords has these results:

- Use the **show interface capabilities module *number*** command to display the capabilities of all interfaces on that switch in the stack. If there is no switch with that module number in the stack, there is no output.
- Use the **show interfaces *interface-id* capabilities** to display the capabilities of the specified interface.
- Use the **show interfaces capabilities** (with no module number or interface ID) to display the capabilities of all interfaces in the stack.

Examples

This is an example of output from the **show interfaces** command for an interface on stack member 3:

```
Controller# show interfaces gigabitethernet3/0/2
GigabitEthernet3/0/2 is down, line protocol is down (notconnect)
  Hardware is Gigabit Ethernet, address is 2037.064d.4381 (bia 2037.064d.4381)
  MTU 1500 bytes, BW 1000000 Kbit/sec, DLY 10 usec,
    reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation ARPA, loopback not set
  Keepalive set (10 sec)
  Auto-duplex, Auto-speed, media type is 10/100/1000BaseTX
  input flow-control is off, output flow-control is unsupported
  ARP type: ARPA, ARP Timeout 04:00:00
  Last input never, output never, output hang never
  Last clearing of "show interface" counters never
  Input queue: 0/2000/0/0 (size/max/drops/flushes); Total output drops: 0
  Queueing strategy: fifo
  Output queue: 0/40 (size/max)
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes, 0 no buffer
```

```

Received 0 broadcasts (0 multicasts)
0 runts, 0 giants, 0 throttles
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
0 watchdog, 0 multicast, 0 pause input
0 input packets with dribble condition detected
0 packets output, 0 bytes, 0 underruns
0 output errors, 0 collisions, 1 interface resets
0 unknown protocol drops
0 babbles, 0 late collision, 0 deferred
0 lost carrier, 0 no carrier, 0 pause output
0 output buffer failures, 0 output buffers swapped out

```

This is an example of output from the **show interfaces accounting** command:

This is an example of output from the **show interfaces capabilities** command for an interface:

This is an example of output from the **show interfaces interface description** command when the interface has been described as *Connects to Marketing* by using the **description** interface configuration command:

```

Controller# show interfaces gigabitethernet1/0/2 description
Interface          Status      Protocol Description
Gi1/0/2            up          down      Connects to Marketing

```

This is an example of output from the **show interfaces etherchannel** command when port channels are configured on the switch:

```

Controller# show interfaces etherchannel
-----
Port-channel34:
Age of the Port-channel   = 28d:18h:51m:46s
Logical slot/port        = 12/34          Number of ports = 0
GC                       = 0x00000000      HotStandBy port = null
Passive port list        =
Port state                = Port-channel L3-Ag Ag-Not-Inuse
Protocol                  = -
Port security              = Disabled

```

This is an example of output from the **show interfaces interface-id pruning** command when pruning is enabled in the VTP domain:

```

Controller# show interfaces gigabitethernet1/0/2 pruning
Port      Vlans pruned for lack of request by neighbor
Gi1/0/2   3,4

Port      Vlans traffic requested of neighbor
Gi1/0/2   1-3

```

This is an example of output from the **show interfaces stats** command for a specified VLAN interface:

```

Controller# show interfaces vlan 1 stats
Switching path  Pkts In   Chars In   Pkts Out   Chars Out
  Processor    1165354   136205310   570800     91731594
  Route cache      0         0           0           0
  Total        1165354   136205310   570800     91731594

```

This is an example of partial output from the **show interfaces status** command. It displays the status of all interfaces:

```

Controller# show interfaces status
Port      Name          Status      Vlan      Duplex  Speed      Type
Gi1/0/1   seTX          notconnect  1         auto    auto       10/100/1000Ba
Gi1/0/2   seTX          notconnect  1         auto    100        10/100/1000Ba
Gi1/0/3   seTX          notconnect  1         auto    1000       10/100/1000Ba
Gi1/0/4   seTX          notconnect  1         auto    auto       10/100/1000Ba
Gi1/0/5   seTX          notconnect  1         auto    auto       10/100/1000Ba
Gi1/0/6   seTX          notconnect  1         auto    10         10/100/1000Ba

```

```

seTX
Gi1/0/7                notconnect  1          auto    auto 10/100/1000Ba
seTX
Gi1/0/8                notconnect  1          auto    auto 10/100/1000Ba
seTX
Gi1/0/9                notconnect  1          auto    auto 10/100/1000Ba
seTX
Gi1/0/10               notconnect  1          auto    auto 10/100/1000Ba
seTX

```

These are examples of output from the **show interfaces status** command for a specific interface when private VLANs are configured. Port 22 is configured as a private-VLAN host port. It is associated with primary VLAN 20 and secondary VLAN 25:

```

Controller# show interfaces gigabitethernet1/0/22 status
Port      Name      Status      Vlan      Duplex      Speed      Type
Gi1/0/22                connected   20,25     a-full     a-100     10/100BaseTX

```

In this example, port 20 is configured as a private-VLAN promiscuous port. The display shows only the primary VLAN 20:

```

Controller# show interfaces gigabitethernet1/0/20 status
Port      Name      Status      Vlan      Duplex      Speed      Type
Gi1/0/20                connected   20        a-full     a-100     10/100BaseTX

```

This is an example of output from the **show interfaces status err-disabled** command. It displays the status of interfaces in the error-disabled state:

```

Controller# show interfaces status err-disabled
Port      Name      Status      Reason
Gi1/0/2   err-disabled  gbic-invalid
Gi2/0/3   err-disabled  dtp-flap

```

This is an example of output from the **show interfaces interface-id pruning** command:

```

Controller# show interfaces gigabitethernet1/0/2 pruning
Port Vlans pruned for lack of request by neighbor

```

This is an example of output from the **show interfaces interface-id trunk** command. It displays trunking information for the port.

```

Controller# show interfaces gigabitethernet1/0/1 trunk
Port      Mode      Encapsulation  Status      Native vlan
Gi1/0/1   on        802.1q         other       10

Port      Vlans allowed on trunk
Gi1/0/1   none

Port      Vlans allowed and active in management domain
Gi1/0/1   none

Port      Vlans in spanning tree forwarding state and not pruned
Gi1/0/1   none

```

show interfaces counters

To display various counters for the switch or for a specific interface, use the **show interfaces counters** command in privileged EXEC mode.

show interfaces [*interface-id*] **counters** [**errors**| **etherchannel**| **module** *stack-member-number*] **protocol status**| **trunk**]

Syntax Description

<i>interface-id</i>	(Optional) ID of the physical interface, including type, stack member (stacking-capable switches only) module, and port number.
errors	(Optional) Displays error counters.
etherchannel	(Optional) Displays EtherChannel counters, including octets, broadcast packets, multicast packets, and unicast packets received and sent.
module <i>stack-member-number</i>	(Optional) Displays counters for the specified stack member. Note In this command, the module keyword refers to the stack member number. The module number that is part of the interface ID is always zero.
protocol status	(Optional) Displays the status of protocols enabled on interfaces.
trunk	(Optional) Displays trunk counters.



Note

Though visible in the command-line help string, the **vlan** *vlan-id* keyword is not supported.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

If you do not enter any keywords, all counters for all interfaces are included.

Examples

This is an example of partial output from the **show interfaces counters** command. It displays all counters for the switch.

```
Controller# show interfaces counters
Port          InOctets      InUcastPkts    InMcastPkts    InBcastPkts
Gi1/0/1       0              0              0              0
Gi1/0/2       0              0              0              0
Gi1/0/3       95285341     43115          1178430        1950
Gi1/0/4       0              0              0              0
```

<output truncated>

This is an example of partial output from the **show interfaces counters module** command for stack member 2. It displays all counters for the specified switch in the stack.

```
Controller# show interfaces counters module 2
Port          InOctets      InUcastPkts    InMcastPkts    InBcastPkts
Gi1/0/1       520           2              0              0
Gi1/0/2       520           2              0              0
Gi1/0/3       520           2              0              0
Gi1/0/4       520           2              0              0
```

<output truncated>

This is an example of partial output from the **show interfaces counters protocol status** command for all interfaces:

```
Controller# show interfaces counters protocol status
Protocols allocated:
Vlan1: Other, IP
Vlan20: Other, IP, ARP
Vlan30: Other, IP, ARP
Vlan40: Other, IP, ARP
Vlan50: Other, IP, ARP
Vlan60: Other, IP, ARP
Vlan70: Other, IP, ARP
Vlan80: Other, IP, ARP
Vlan90: Other, IP, ARP
Vlan900: Other, IP, ARP
Vlan3000: Other, IP
Vlan3500: Other, IP
GigabitEthernet1/0/1: Other, IP, ARP, CDP
GigabitEthernet1/0/2: Other, IP
GigabitEthernet1/0/3: Other, IP
GigabitEthernet1/0/4: Other, IP
GigabitEthernet1/0/5: Other, IP
GigabitEthernet1/0/6: Other, IP
GigabitEthernet1/0/7: Other, IP
GigabitEthernet1/0/8: Other, IP
GigabitEthernet1/0/9: Other, IP
GigabitEthernet1/0/10: Other, IP, CDP
```

<output truncated>

This is an example of output from the **show interfaces counters trunk** command. It displays trunk counters for all interfaces.

```
Controller# show interfaces counters trunk
Port          TrunkFramesTx  TrunkFramesRx  WrongEncap
Gi1/0/1       0              0              0
Gi1/0/2       0              0              0
Gi1/0/3       80678          0              0
Gi1/0/4       82320          0              0
Gi1/0/5       0              0              0
```

<output truncated>

show location

To display location information for an endpoint, use the **show location** command in EXEC mode.

show location admin-tag

show location civic-location identifier *string* interface *interface-id* static

show location elin-location identifier *string* interface *interface-id* static

Syntax Description

admin-tag	Displays administrative tag or site information.
civic-location	Displays civic location information.
elin-location	Displays emergency location information (ELIN).
identifier <i>string</i>	Specifies the ID for the civic location or the ELIN location. The range is 1 to 4095.
interface <i>interface-id</i>	Displays location information for the specified interface or all interfaces. Valid interfaces include physical ports.
static	Displays static configuration information.

Command Modes

User EXEC

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This is an example of output from the **show location civic-location** command that displays location information for an interface:

```
Controller# show location civic-location interface gigabitethernet2/0/1
Civic location information
-----
Identifier           : 1
County               : Santa Clara
Street number       : 3550
Building             : 19
Room                 : C6
Primary road name   : Cisco Way
City                 : San Jose
State                : CA
Country              : US
```

This is an example of output from the **show location civic-location** command that displays all the civic location information:

```

Controller# show location civic-location static
Civic location information
-----
Identifier          : 1
County              : Santa Clara
Street number       : 3550
Building            : 19
Room                : C6
Primary road name   : Cisco Way
City                 : San Jose
State                : CA
Country             : US
Ports               : Gi2/0/1
-----
Identifier          : 2
Street number       : 24568
Street number suffix : West
Landmark            : Golden Gate Bridge
Primary road name   : 19th Ave
City                 : San Francisco
Country             : US
-----

```

This is an example of output from the **show location elin-location** command that displays the emergency location information:

```

Controller# show location elin-location identifier 1
Elin location information
-----
Identifier : 1
Elin       : 14085553881
Ports      : Gi2/0/2

```

This is an example of output from the **show location elin-location static** command that displays all emergency location information:

```

Controller# show location elin-location static
Elin location information
-----
Identifier : 1
Elin       : 14085553881
Ports      : Gi2/0/2
-----
Identifier : 2
Elin       : 18002228999
-----

```

show mgmt-infra trace messages ilpower-ha

To display inline power high availability messages within a trace buffer, use the **show mgmt-infra trace messages ilpower-ha** command in privileged EXEC mode.

show mgmt-infra trace messages ilpower-ha [**switch** *stack-member-number*]

Syntax Description	switch <i>stack-member-number</i>	(Optional) Specifies the stack member number for which to display inline power messages within a trace buffer.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This is an output example from the **show mgmt-infra trace messages ilpower-ha** command:

```
Controller# show mgmt-infra trace messages ilpower-ha
[10/23/12 14:04:48.087 UTC 1 3] NG3K_ILPOWER_HA: Created NGWC ILP CF client successfully.
```

show network-policy profile

To display the network-policy profiles, use the **show network policy profile** command in privileged EXEC mode.

show network-policy profile [*profile-number*] [**detail**]

Syntax Description

<i>profile-number</i>	(Optional) Displays the network-policy profile number. If no profile is entered, all network-policy profiles appear.
detail	(Optional) Displays detailed status and statistics information.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This is an example of output from the **show network-policy profile** command:

```
Controller# show network-policy profile
Network Policy Profile 10
  voice vlan 17 cos 4
  Interface:
  none
Network Policy Profile 30
  voice vlan 30 cos 5
  Interface:
  none
Network Policy Profile 36
  voice vlan 4 cos 3
  Interface:
  Interface_id
```

show nmsp

To display the Network Mobility Services Protocol (NMSP) information for the switch, use the **show nmsp** command in privileged EXEC mode.

show nmsp {**attachment suppress interface**| **capability**| **notification interval**| **statistics** {**connection**| **summary**}}| **status**| **subscription** {**detail**| **summary**}}

Syntax Description

attachment suppress interface	Displays attachment suppress interfaces.
capability	Displays switch capabilities including the supported services and subservices.
notification interval	Displays the notification intervals of the supported services.
statistics	Displays the NMSP statistics information.
connection	Displays the message counters on each connection.
summary	Displays the global counters.
status	Displays information about the NMSP connections.
subscription	Displays the subscription information on each NMSP connection.
detail	Displays all services and subservices subscribed on each connection.
summary	Displays all services subscribed on each connection.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This is an example of output from the **show nmsp attachment suppress interface** command:

```
Controller# show nmsp attachment suppress interface
NMSF Attachment Suppression Interfaces
-----
GigabitEthernet1/0/1
```

GigabitEthernet1/0/3

This is an example of output from the **show nmosp capability** command:

```
Controller# show nmosp capability
Service          Subservice
-----
RSSI             Mobile Station, Tags, Rogue
Info            Mobile Station, Rogue
Statistics       Mobile Station, Tags
Attachment       Wired Station
Location         Subscription
AP Monitor       Subscription
IDS Services     WIPS
```

This is an example of output from the **show nmosp notification interval** command:

```
Controller# show nmosp notification interval
NMSP Notification Intervals
-----

RSSI Interval:
  Client          : 2 sec
  RFID            : 2 sec
  Rogue AP        : 2 sec
  Rogue Client    : 2 sec
Attachment Interval : 30 sec
Location Interval  : 30 sec
```

This is an example of output from the **show nmosp statistics summary** command:

```
Controller# show nmosp statistics summary
NMSP Global Counters
-----

Client measure send fail          : 0
Send RSSI with no entry           : 0
Application message too big       : 0
Failed select on accept socket    : 0
Failed SSL write                   : 0
Partial SSL write                  : 0
SSL write returned zero            : 0
SSL write attempts to want read   : 0
SSL write attempts to want write  : 0
SSL write got default error       : 0
SSL write max data length sent    : 0
SSL write max attempts to write in loop : 0
SSL read returned zero            : 0
SSL read attempts to want read    : 0
SSL read attempts to want write   : 0
SSL read got default error        : 0
Failed SSL read - con rx buf freed : 0
Failed SSL read - con/SSL freed    : 0
Max records read before exiting SSL read : 0
Highest priority tx queue full    : 0
Normal priority tx queue full     : 0
Highest priority tx queue count   : 0
Normal priority tx queue count    : 0
APP sent message to highest priority queue : 0
Max measure notify message        : 0
Max info notify message           : 0
Max highest priority tx queue count : 0
Max normal priority tx queue count : 0
Max receive queue count           : 3
Max info notify queue count       : 0
Max client info notify delay      : 0
Max rogue AP info notify delay    : 0
Max rogue client info notify delay : 0
Max client measure notify delay   : 0
Max tag measure notify delay      : 0
Max rogue AP measure notify delay : 0
Max rogue client measure notify delay : 0
Max client stats notify delay     : 0
```

```
Max RFID stats notify delay      : 0
RFID measurement periodic        : 0
RFID measurement immediate       : 0
SSL handshake failed             : 0
NMSP rx detected connection failure : 0
NMSP tx detected connection failure : 0
NMSP tx buf size exceeded        : 0
Reconnect before connection Timeout : 0
```

show platform CAPWAP summary

To display the tunnel identifier and the type all the CAPWAP tunnels established by the controller to the access points and other mobility controllers, use the **show platform CAPWAP summary** command.

show platform CAPWAP summary

Syntax Description This command has no arguments or keywords.

Command Default

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example displays the tunnel identifier and details:

```
Controller# show platform capwap summary
Tunnel ID | Type | Src IP | Dst IP | SPrt | DPrt | S | A
-----
0x0088498000000983 data 9.6.44.61 9.12.138.101 5247 41894 1 1
0x00966dc000000010 data 9.6.44.61 9.6.47.101 5247 62526 1 2
0x00938e800000095b data 9.6.44.61 9.12.138.100 5247 45697 1 1
0x00ab1a8000000bd1 data 9.6.44.61 9.12.139.101 5247 38906 1 0
0x00896e40000000bd data 9.6.44.61 9.12.136.100 5247 1836 1 1
```

show network-policy profile

To display the network-policy profiles, use the **show network policy profile** command in privileged EXEC mode.

show network-policy profile [*profile-number*] [**detail**]

Syntax Description

<i>profile-number</i>	(Optional) Displays the network-policy profile number. If no profile is entered, all network-policy profiles appear.
detail	(Optional) Displays detailed status and statistics information.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This is an example of output from the **show network-policy profile** command:

```
Controller# show network-policy profile
Network Policy Profile 10
  voice vlan 17 cos 4
  Interface:
    none
Network Policy Profile 30
  voice vlan 30 cos 5
  Interface:
    none
Network Policy Profile 36
  voice vlan 4 cos 3
  Interface:
    Interface_id
```

show wireless interface summary

To display the wireless interface status and configuration, use the **show wireless interface summary** command.

The command displays the total number of packets that are sent or received by the controllers.

show wireless interface summary

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the summary of wireless interfaces.

```
Controller# show wireless interface summary
```

```
Interface Name Interface Type VLAN ID IP Address IP Netmask MAC Address
```

```
-----
```

```
Vlan10 Management 10 3.1.1.1 255.255.255.0 0006.f6b9.b5c6
```

```
Controller#
```

system mtu

Syntax Description

bytes

Command Default

The default MTU size for all ports is 1500 bytes.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can verify your setting by entering the **show system mtu** privileged EXEC command.

The switch does not support the MTU on a per-interface basis.

If you enter a value that is outside the allowed range for the specific type of interface, the value is not accepted.

wireless ap-manager interface

To configure the wireless AP-manager interface, use the **wireless ap-manager interface** command.

wireless ap-manager interface { **TenGigabitEthernet** *interface-number* | **Vlan** *interface-number* }

Syntax Description

TenGigabitEthernet <i>interface-name</i>	Configures 10-Gigabit Ethernet interface. Values range from 0 to 9.
Vlan <i>interface-name</i>	Configures VLANs. Values range from 1 to 4095.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the wireless AP-manager:

```
Controller# wireless ap-manager interface vlan
<1-4095> Vlan interface number
```

This example shows how to configure the wireless AP-manager:

```
Controller# #wireless ap-manager interface vlan 10
```

wireless exclusionlist

To manage exclusion list entries, use the **wireless exclusionlist** global configuration command. To remove the exclusion list entries, use the **no** form of the command.

wireless exclusionlist *mac-addr* **description** *description*

no wireless exclusionlist *mac-addr*

Syntax Description

<i>mac-addr</i>	The MAC address of the local excluded entry.
description <i>description</i>	Specifies the description for an exclusion-list entry.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to create a local exclusion list entry for the MAC address xxx.xxx.xxx:

```
Controller# wireless exclusionlist xxx.xxx.xxx
```

This example shows how to create a description for the local exclusion list entry for the MAC address xxx.xxx.xxx:

```
Controller# wireless exclusionlist xxx.xxx.xxx description sample
```

wireless linktest

To configure linktest frame size and number of frames to send, use the **wireless linktest** command.

wireless linktest {**frame-size** *size*|**number-of-frames** *value*}

Syntax Description

frame-size <i>size</i>	Specifies the link test frame size for each packet. The values range from 1 to 1400.
number-of-frames <i>value</i>	Specifies the number of frames to be sent for the link test. The values range from 1 to 100.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the link test frame size of each frame as 10:

```
Controller# wireless linktest frame-size 10
```

wireless management interface

To configure wireless management parameters on an interface, use the **wireless management interface** global configuration command. To remove a wireless management parameters on an interface, use the **no** form of the command.

wireless management interface *interface-name* {**TenGigabitEthernet** *interface-name*| **Vlan** *interface-name*}
no wireless management interface

Syntax Description

<i>interface-name</i>	The interface number.
TenGigabitEthernet <i>interface-name</i>	The 10-Gigabit Ethernet interface number. The values range from 0 to 9.
Vlan <i>interface-name</i>	The VLAN interface number. The values range from 1 to 4095.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure VLAN 10 on the wireless interface:

```
Controller# wireless management interface Vlan 10
```

wireless peer-blocking forward-upstream

To configure peer-to-peer blocking for forward upstream, use the **wireless peer-blocking forward-upstream** command. To remove a peer-to-peer blocking, use the **no** form of the command.

wireless peer-blocking forward-upstream *interface* {**GigabitEthernet** *interface-number* **TenGigabitEthernet** *interface-number*}

no wireless peer-blocking forward-upstream {**GigabitEthernet** *interface-number* **TenGigabitEthernet** *interface-number*}

Syntax Description

GigabitEthernet <i>interface</i>	The Gigabit Ethernet interface number. Values range from 0 to 9.
TenGigabitEthernet <i>interface</i>	The 10-Gigabit Ethernet interface number. Values range from 0 to 9.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure peer-to-peer blocking for interface 10-gigabit ethernet interface:

```
Controller(config)# wireless peer-blocking forward-upstream TenGigabitEthernet 1/1/4
```



PART **IV**

VLAN

- [VLAN Commands, page 237](#)



VLAN Commands

- [client vlan](#), page 238
- [clear vmmps statistics](#), page 239
- [clear vtp counters](#), page 240
- [debug sw-vlan](#), page 241
- [debug sw-vlan ifs](#), page 243
- [debug sw-vlan notification](#), page 244
- [debug sw-vlan vtp](#), page 246
- [interface vlan](#), page 248
- [remote-span](#), page 250
- [show vlan](#), page 252
- [show vlan filter](#), page 256
- [show vlan group](#), page 257
- [show vtp](#), page 258
- [show wireless vlan group](#), page 264
- [spanning-tree vlan](#), page 265
- [wireless broadcast vlan](#), page 268
- [wireless vlan group](#), page 269
- [wlan](#), page 270

client vlan

To configure a WLAN interface or an interface group, use the **client vlan** command. To disable the WLAN interface, use the **no** form of this command.

client vlan *interface-id-name-or-group-name*

no client vlan

Syntax Description

<i>interface--id-name-or-group-name</i>	Interface ID, name, or VLAN group name.
---	---

Command Default

The default interface is configured.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to enable a client VLAN on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# client vlan client-vlan1
Controller(config-wlan)# end
```

This example shows how to disable a client association limit on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no client vlan
Controller(config-wlan)# end
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.

clear vmmps statistics

To clear the VLAN Membership Policy Server (VMPS) statistics maintained by the VLAN Query Protocol (VQP) client, use the **clear vmmps statistics** command in privileged EXEC mode.

clear vmmps statistics

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how to clear VLAN Membership Policy Server (VMPS) statistics:

```
Controller# clear vmmps statistics
```

You can verify that information was deleted by entering the **show vmmps statistics** privileged EXEC command.

clear vtp counters

To clear the VLAN Trunking Protocol (VTP) and pruning counters, use the **clear vtp counters** command in privileged EXEC mode.

clear vtp counters

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how to clear the VTP counters:

```
Controller# clear vtp counters
```

You can verify that information was deleted by entering the **show vtp counters** privileged EXEC command.

Related Commands	Command	Description
	show vtp	Displays general information about VTP management domain, status, and counters.

debug sw-vlan

To enable debugging of VLAN manager activities, use the **debug sw-vlan** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug sw-vlan {badpmcookies| cfg-vlan {bootup| cli}| events| ifs| mapping| notification| packets| redundancy| registries| vtp}

no debug sw-vlan {badpmcookies| cfg-vlan {bootup| cli}| events| ifs| mapping| notification| packets| redundancy| registries| vtp}

Syntax Description

badpmcookies	Displays debug messages for VLAN manager incidents of bad port manager cookies.
cfg-vlan	Displays VLAN configuration debug messages.
bootup	Displays messages when the switch is booting up.
cli	Displays messages when the command-line interface (CLI) is in VLAN configuration mode.
events	Displays debug messages for VLAN manager events.
ifs	Displays debug messages for the VLAN manager IOS file system (IFS). See debug sw-vlan ifs , on page 243 for more information.
mapping	Displays debug messages for VLAN mapping.
notification	Displays debug messages for VLAN manager notifications. See debug sw-vlan notification , on page 244 for more information.
packets	Displays debug messages for packet handling and encapsulation processes.
redundancy	Displays debug messages for VTP VLAN redundancy.
registries	Displays debug messages for VLAN manager registries.
vtp	Displays debug messages for the VLAN Trunking Protocol (VTP) code. See debug sw-vlan vtp , on page 246 for more information.

Command Default Debugging is disabled.

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **undebug sw-vlan** command is the same as the **no debug sw-vlan** command.

Examples

This example shows how to display debug messages for VLAN manager events:

```
Controller# debug sw-vlan events
```

Related Commands

Command	Description
debug sw-vlan ifs	Enables debugging of the VLAN manager IOS file system (IFS) error tests.
debug sw-vlan notification	Enables debugging of VLAN manager notifications.
debug sw-vlan vtp	Enables debugging of the VTP code.
show vlan	Displays the parameters for all configured VLANs or one VLAN (if the VLAN ID or name is specified) in the administrative domain.
show vtp	Displays general information about VTP management domain, status, and counters.

debug sw-vlan ifs

To enable debugging of the VLAN manager IOS file system (IFS) error tests, use the **debug sw-vlan ifs** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug sw-vlan ifs {open {read| write}| read {1| 2| 3| 4}| write}

no debug sw-vlan ifs {open {read| write}| read {1| 2| 3| 4}| write}

Syntax Description

open read	Displays VLAN manager IFS file-read operation debug messages.
open write	Displays VLAN manager IFS file-write operation debug messages.
read	Displays file-read operation debug messages for the specified error test (1 , 2 , 3 , or 4).
write	Displays file-write operation debug messages.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **undebug sw-vlan ifs** command is the same as the **no debug sw-vlan ifs** command.

When selecting the file read operation, Operation **1** reads the file header, which contains the header verification word and the file version number. Operation **2** reads the main body of the file, which contains most of the domain and VLAN information. Operation **3** reads type length version (TLV) descriptor structures. Operation **4** reads TLV data.

Examples

This example shows how to display file-write operation debug messages:

```
Controller# debug sw-vlan ifs write
```

Related Commands

Command	Description
show vlan	Displays the parameters for all configured VLANs or one VLAN (if the VLAN ID or name is specified) in the administrative domain.

debug sw-vlan notification

To enable debugging of VLAN manager notifications, use the **debug sw-vlan notification** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug sw-vlan notification {accfwdchange| allowedvlanfgchange| fwdchange| linkchange| modechange| pruningfgchange| statechange}

no debug sw-vlan notification {accfwdchange| allowedvlanfgchange| fwdchange| linkchange| modechange| pruningfgchange| statechange}

Syntax Description

accfwdchange	Displays debug messages for VLAN manager notification of aggregated access interface spanning-tree forward changes.
allowedvlanfgchange	Displays debug messages for VLAN manager notification of changes to the allowed VLAN configuration.
fwdchange	Displays debug messages for VLAN manager notification of spanning-tree forwarding changes.
linkchange	Displays debug messages for VLAN manager notification of interface link-state changes.
modechange	Displays debug messages for VLAN manager notification of interface mode changes.
pruningfgchange	Displays debug messages for VLAN manager notification of changes to the pruning configuration.
statechange	Displays debug messages for VLAN manager notification of interface state changes.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **undebug sw-vlan notification** command is the same as the **no debug sw-vlan notification** command.

Examples

This example shows how to display debug messages for VLAN manager notification of interface mode changes:

```
Controller# debug sw-vlan notification
```

Related Commands

Command	Description
show vlan	Displays the parameters for all configured VLANs or one VLAN (if the VLAN ID or name is specified) in the administrative domain.

debug sw-vlan vtp

To enable debugging of the VLAN Trunking Protocol (VTP) code, use the **debug sw-vlan vtp** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug sw-vlan vtp {events| packets| pruning [packets| xmit]} redundancy| xmit}

no debug sw-vlan vtp {events| packets| pruning| redundancy| xmit}

Syntax Description

events	Displays debug messages for general-purpose logic flow and detailed VTP messages generated by the VTP_LOG_RUNTIME macro in the VTP code.
packets	Displays debug messages for the contents of all incoming VTP packets that have been passed into the VTP code from the Cisco IOS VTP platform-dependent layer, except for pruning packets.
pruning	Displays debug messages generated by the pruning segment of the VTP code.
packets	(Optional) Displays debug messages for the contents of all incoming VTP pruning packets that have been passed into the VTP code from the Cisco IOS VTP platform-dependent layer.
xmit	(Optional) Displays debug messages for the contents of all outgoing VTP packets that the VTP code requests the Cisco IOS VTP platform-dependent layer to send.
redundancy	Displays debug messages for VTP redundancy.
xmit	Displays debug messages for the contents of all outgoing VTP packets that the VTP code requests the Cisco IOS VTP platform-dependent layer to send, except for pruning packets.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **undebug sw-vlan vtp** command is the same as the **no debug sw-vlan vtp** command.

If no additional parameters are entered after the **pruning** keyword, VTP pruning debugging messages appear. They are generated by the VTP_PRUNING_LOG_NOTICE, VTP_PRUNING_LOG_INFO, VTP_PRUNING_LOG_DEBUG, VTP_PRUNING_LOG_ALERT, and VTP_PRUNING_LOG_WARNING macros in the VTP pruning code.

Examples

This example shows how to display debug messages for VTP redundancy:

```
Controller# debug sw-vlan vtp redundancy
```

Related Commands

Command	Description
show vtp	Displays general information about VTP management domain, status, and counters.

interface vlan

To create or access a dynamic switch virtual interface (SVI) and to enter interface configuration mode, use the **interface vlan** command in global configuration mode. To delete an SVI, use the **no** form of this command.

interface vlan *vlan-id*

no interface vlan *vlan-id*

Syntax Description

<i>vlan-id</i>	VLAN number. The range is 1 to 4094.
----------------	--------------------------------------

Command Default

The default VLAN interface is VLAN 1.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

SVIs are created the first time you enter the **interface vlan** *vlan-id* command for a particular VLAN. The *vlan-id* corresponds to the VLAN-tag associated with data frames on an IEEE 802.1Q encapsulated trunk or the VLAN ID configured for an access port.



Note

When you create an SVI, it does not become active until it is associated with a physical port.

If you delete an SVI using the **no interface vlan** *vlan-id* command, it is no longer visible in the output from the **show interfaces** privileged EXEC command.



Note

You cannot delete the VLAN 1 interface.

You can reinstate a deleted SVI by entering the **interface vlan** *vlan-id* command for the deleted interface. The interface comes back up, but the previous configuration is gone.

The interrelationship between the number of SVIs configured on a switch or a switch stack and the number of other features being configured might have an impact on CPU utilization due to hardware limitations. You can use the **sdm prefer** global configuration command to reallocate system hardware resources based on templates and feature tables.

You can verify your setting by entering the **show interfaces** and **show interfaces vlan** *vlan-id* privileged EXEC commands.

Examples

This example shows how to create a new SVI with VLAN ID 23 and enter interface configuration mode:

```
Controller(config)# interface vlan 23  
Controller(config-if)#
```

Related Commands

Command	Description
show interfaces	Displays the administrative and operational status of all interfaces or a specified interface.

remote-span

To configure a VLAN as a Remote Switched Port Analyzer (RSPAN) VLAN, use the **remote-span** command in VLAN configuration mode on the switch stack or on a standalone switch. To remove the RSPAN designation from the VLAN, use the **no** form of this command.

remote-span

no remote-span

Syntax Description This command has no arguments or keywords.

Command Default No RSPAN VLANs are defined.

Command Modes VLAN configuration (config-VLAN)

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

If VLAN Trunking Protocol (VTP) is enabled, the RSPAN feature is propagated by VTP for VLAN IDs that are lower than 1005. If the RSPAN VLAN ID is in the extended range, you must manually configure intermediate switches (those in the RSPAN VLAN between the source switch and the destination switch).

Before you configure the RSPAN **remote-span** command, use the **vlan** (global configuration) command to create the VLAN.

The RSPAN VLAN has these characteristics:

- No MAC address learning occurs on it.
- RSPAN VLAN traffic flows only on trunk ports.
- Spanning Tree Protocol (STP) can run in the RSPAN VLAN, but it does not run on RSPAN destination ports.

When an existing VLAN is configured as an RSPAN VLAN, the VLAN is first deleted and then recreated as an RSPAN VLAN. Any access ports are made inactive until the RSPAN feature is disabled.

Examples

This example shows how to configure a VLAN as an RSPAN VLAN:

```
Controller(config)# vlan 901
Controller(config-vlan)# remote-span
```

This example shows how to remove the RSPAN feature from a VLAN:

```
Controller(config)# vlan 901
Controller(config-vlan)# no remote-span
```

You can verify your settings by entering the **show vlan remote-span** user EXEC command.

Related Commands

Command	Description
monitor session destination	Configures a FSPAN or FRSPAN destination session.
monitor session filter	Configures a FSPAN or FRSPAN session filter.
monitor session source	Configures a FSPAN or FRSPAN source session.
show vlan	Displays the parameters for all configured VLANs or one VLAN (if the VLAN ID or name is specified) in the administrative domain.
vlan	Adds a VLAN and enters the VLAN configuration mode.

show vlan

To display the parameters for all configured VLANs or one VLAN (if the VLAN ID or name is specified) on the switch, use the **show vlan** command in user EXEC mode.

show vlan [**brief**] **group** | **id** *vlan-id* | **group-name** *WORD user_count* | **mtu** | **name** *vlan-name* | **remote-span** | **summary**]

Syntax Description

brief	(Optional) Displays one line for each VLAN with the VLAN name, status, and its ports.
group	(Optional) Displays information about VLAN groups.
id <i>vlan-id</i>	(Optional) Displays information about a single VLAN identified by the VLAN ID number. For <i>vlan-id</i> , the range is 1 to 4094.
group-name <i>WORD vlan-id vlan-id</i>	(Optional) Displays information about a specific VLAN group.
mtu	(Optional) Displays a list of VLANs and the minimum and maximum transmission unit (MTU) sizes configured on ports in the VLAN.
name <i>vlan-name</i>	(Optional) Displays information about a single VLAN identified by the VLAN name. The VLAN name is an ASCII string from 1 to 32 characters.
remote-span	(Optional) Displays information about Remote SPAN (RSPAN) VLANs.
summary	(Optional) Displays VLAN summary information.



Note

The **ifindex** keyword is not supported, even though it is visible in the command-line help string.

Command Default

None

Command Modes

User EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

In the **show vlan mtu** command output, the `MTU_Mismatch` column shows whether all the ports in the VLAN have the same MTU. When `yes` appears in the column, it means that the VLAN has ports with different MTUs, and packets that are switched from a port with a larger MTU to a port with a smaller MTU might be dropped. If the VLAN does not have an SVI, the hyphen (-) symbol appears in the `SVI_MTU` column. If the `MTU-Mismatch` column displays `yes`, the names of the ports with the `MinMTU` and the `MaxMTU` appear.

Examples

This is an example of output from the **show vlan** command. See the table that follows for descriptions of the fields in the display.

```

Controller> show vlan
VLAN Name                               Status      Ports
-----
1    default                               active     Gi1/0/2, Gi1/0/3, Gi1/0/4
                                           Gi1/0/5, Gi1/0/6, Gi1/0/7
                                           Gi1/0/8, Gi1/0/9, Gi1/0/10
                                           Gi1/0/11, Gi1/0/12, Gi1/0/13
                                           Gi1/0/14, Gi1/0/15, Gi1/0/16
                                           Gi1/0/17, Gi1/0/18, Gi1/0/19
                                           Gi1/0/20, Gi1/0/21, Gi1/0/22
                                           Gi1/0/23, Gi1/0/24, Gi1/0/25
                                           Gi1/0/26, Gi1/0/27, Gi1/0/28
                                           Gi1/0/29, Gi1/0/30, Gi1/0/31
                                           Gi1/0/32, Gi1/0/33, Gi1/0/34
                                           Gi1/0/35, Gi1/0/36, Gi1/0/37
                                           Gi1/0/38, Gi1/0/39, Gi1/0/40
                                           Gi1/0/41, Gi1/0/42, Gi1/0/43
                                           Gi1/0/44, Gi1/0/45, Gi1/0/46
                                           Gi1/0/47, Gi1/0/48
2    VLAN0002                               active
40   vlan-40                                 active
300  VLAN0300                               active
1002 fddi-default                          act/unsup
1003 token-ring-default                  act/unsup
1004 fddinet-default                    act/unsup
1005 trnet-default                      act/unsup

VLAN Type  SAID      MTU   Parent  RingNo  BridgeNo  Stp   BrdgMode  Trans1  Trans2
-----
1    enet  100001   1500  -       -       -       -       -       0       0
2    enet  100002   1500  -       -       -       -       -       0       0
40   enet  100040   1500  -       -       -       -       -       0       0
300  enet  100300   1500  -       -       -       -       -       0       0
1002 fddi  101002   1500  -       -       -       -       -       0       0
1003 tr   101003   1500  -       -       -       -       -       0       0
1004 fdnet 101004   1500  -       -       -       ieee  -       0       0
1005 trnet 101005   1500  -       -       -       ibm   -       0       0
2000 enet  102000   1500  -       -       -       -       -       0       0
3000 enet  103000   1500  -       -       -       -       -       0       0

Remote SPAN VLANs
-----
2000,3000

Primary Secondary Type           Ports
-----

```

Table 9: show vlan Command Output Fields

Field	Description
VLAN	VLAN number.

Field	Description
Name	Name, if configured, of the VLAN.
Status	Status of the VLAN (active or suspend).
Ports	Ports that belong to the VLAN.
Type	Media type of the VLAN.
SAID	Security association ID value for the VLAN.
MTU	Maximum transmission unit size for the VLAN.
Parent	Parent VLAN, if one exists.
RingNo	Ring number for the VLAN, if applicable.
BrdgNo	Bridge number for the VLAN, if applicable.
Stp	Spanning Tree Protocol type used on the VLAN.
BrdgMode	Bridging mode for this VLAN—possible values are source-route bridging (SRB) and source-route transparent (SRT); the default is SRB.
Trans1	Translation bridge 1.
Trans2	Translation bridge 2.
Remote SPAN VLANs	Identifies any RSPAN VLANs that have been configured.

This is an example of output from the **show vlan summary** command:

```
Controller> show vlan summary
Number of existing VLANs           : 45
Number of existing VTP VLANs      : 45
Number of existing extended VLANs : 0
```

This is an example of output from the **show vlan id** command:

```
Controller# show vlan id 2
VLAN Name                Status    Ports
-----
2    VLAN0200                active    Gi1/0/7, Gi1/0/8
2    VLAN0200                active    Gi2/0/1, Gi2/0/2

VLAN Type  SAID      MTU   Parent  RingNo BridgeNo  Stp   BrdgMode Trans1 Trans2
-----
2    enet    100002   1500   -       -       -     -       -       0     0

Remote SPAN VLANs
-----
Disabled
```

Related Commands

Command	Description
switchport mode	Configures the VLAN membership mode of a port.
vlan	Adds a VLAN and enters the VLAN configuration mode.

show vlan filter

To display information about all VLAN filters or about a particular VLAN or VLAN access map, use the **show vlan filter** command in privileged EXEC mode.

show vlan filter {**access-map** *name*| **vlan** *vlan-id*}

Syntax Description

access-map <i>name</i>	(Optional) Displays filtering information for the specified VLAN access map.
vlan <i>vlan-id</i>	(Optional) Displays filtering information for the specified VLAN. The range is 1 to 4094.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This is an example of output from the **show vlan filter** command:

```
Controller# show vlan filter
VLAN Map map_1 is filtering VLANs:
 20-22
```

Related Commands

Command	Description
show vlan access-map	Displays the VLAN access maps created on the switch.
vlan access-map	Defines a VLAN map and enters access-map configuration mode where you can specify a MAC ACL to match and the action to be taken.
vlan filter	Applies a VLAN map to one or more VLANs.

show vlan group

To display the VLANs that are mapped to VLAN groups, use the **show vlan group** command in privileged EXEC mode.

```
show vlan group [group-name vlan-group-name [user_count]]
```

Syntax Description	
group-name <i>vlan-group-name</i>	(Optional) Displays the VLANs mapped to the specified VLAN group.
user_count	(Optional) Displays the number of users in each VLAN mapped to a specified VLAN group.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines The **show vlan group** command displays the existing VLAN groups and lists the VLANs and VLAN ranges that are members of each VLAN group. If you enter the **group-name** keyword, only the members of the specified VLAN group are displayed.

Examples This example shows how to display the members of a specified VLAN group:

Related Commands	Command	Description
	vlan group	Creates or modifies a VLAN group.

show vtp

To display general information about the VLAN Trunking Protocol (VTP) management domain, status, and counters, use the **show vtp** command in EXEC mode.

show vtp {**counters**| **devices** [**conflicts**]| **interface** [*interface-id*] **password**| **status**}

Syntax Description

counters	Displays the VTP statistics for the controller.
devices	Displays information about all VTP version 3 devices in the domain. This keyword applies only if the controller is not running VTP version 3.
conflicts	(Optional) Displays information about VTP version 3 devices that have conflicting primary servers. This command is ignored when the controller is in VTP transparent or VTP off mode.
interface	Displays VTP status and configuration for all interfaces or the specified interface.
<i>interface-id</i>	(Optional) Interface for which to display VTP status and configuration. This can be a physical interface or a port channel.
password	Displays the configured VTP password (available in privileged EXEC mode only).
status	Displays general information about the VTP management domain status.

Command Default

None

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

When you enter the **show vtp password** command when the controller is running VTP version 3, the display follows these rules:

- If the **password** *password* global configuration command did not specify the **hidden** keyword and encryption is not enabled on the controller, the password appears in clear text.

- If the **password** *password* command did not specify the **hidden** keyword and encryption is enabled on the controller, the encrypted password appears.
- If the **password** *password* command is included the **hidden** keyword, the hexadecimal secret key is displayed.

Examples

This is an example of output from the **show vtp devices** command. A Yes in the Conflict column indicates that the responding server is in conflict with the local server for the feature; that is, when two controllers in the same domain do not have the same primary server for a database.

```

Controller# show vtp devices
Retrieving information from the VTP domain. Waiting for 5 seconds.
VTP Database Conf controller ID      Primary Server Revision  System Name
-----
VLAN          Yes  00b0.8e50.d000 000c.0412.6300 12354      main.cisco.com
MST           No   00b0.8e50.d000 0004.AB45.6000 24         main.cisco.com
VLAN          Yes  000c.0412.6300=000c.0412.6300 67         qwerty.cisco.com

```

This is an example of output from the **show vtp counters** command. The table that follows describes each field in the display.

```

Controller> show vtp counters
VTP statistics:
Summary advertisements received      : 0
Subset advertisements received      : 0
Request advertisements received     : 0
Summary advertisements transmitted  : 0
Subset advertisements transmitted   : 0
Request advertisements transmitted  : 0
Number of config revision errors    : 0
Number of config digest errors      : 0
Number of V1 summary errors         : 0

VTP pruning statistics:

Trunk          Join Transmitted Join Received  Summary advts received from
-----          -----          -----          non-pruning-capable device
Gi1/0/47       0                0                0
Gi1/0/48       0                0                0
Gi2/0/1        0                0                0
Gi3/0/2        0                0                0

```

Table 10: show vtp counters Field Descriptions

Field	Description
Summary advertisements received	Number of summary advertisements received by this controller on its trunk ports. Summary advertisements contain the management domain name, the configuration revision number, the update timestamp and identity, the authentication checksum, and the number of subset advertisements to follow.
Subset advertisements received	Number of subset advertisements received by this controller on its trunk ports. Subset advertisements contain all the information for one or more VLANs.

Field	Description
Request advertisements received	Number of advertisement requests received by this controller on its trunk ports. Advertisement requests normally request information on all VLANs. They can also request information on a subset of VLANs.
Summary advertisements transmitted	Number of summary advertisements sent by this controller on its trunk ports. Summary advertisements contain the management domain name, the configuration revision number, the update timestamp and identity, the authentication checksum, and the number of subset advertisements to follow.
Subset advertisements transmitted	Number of subset advertisements sent by this controller on its trunk ports. Subset advertisements contain all the information for one or more VLANs.
Request advertisements transmitted	Number of advertisement requests sent by this controller on its trunk ports. Advertisement requests normally request information on all VLANs. They can also request information on a subset of VLANs.
Number of configuration revision errors	<p>Number of revision errors.</p> <p>Whenever you define a new VLAN, delete an existing one, suspend or resume an existing VLAN, or modify the parameters on an existing VLAN, the configuration revision number of the controller increments.</p> <p>Revision errors increment whenever the controller receives an advertisement whose revision number matches the revision number of the controller, but the MD5 digest values do not match. This error means that the VTP password in the two controllers is different or that the controllers have different configurations.</p> <p>These errors indicate that the controller is filtering incoming advertisements, which causes the VTP database to become unsynchronized across the network.</p>

Field	Description
Number of configuration digest errors	<p>Number of MD5 digest errors.</p> <p>Digest errors increment whenever the MD5 digest in the summary packet and the MD5 digest of the received advertisement calculated by the controller do not match. This error usually means that the VTP password in the two controllers is different. To solve this problem, make sure the VTP password on all controllers is the same.</p> <p>These errors indicate that the controller is filtering incoming advertisements, which causes the VTP database to become unsynchronized across the network.</p>
Number of V1 summary errors	<p>Number of Version 1 errors.</p> <p>Version 1 summary errors increment whenever a controller in VTP V2 mode receives a VTP Version 1 frame. These errors indicate that at least one neighboring controller is either running VTP Version 1 or VTP Version 2 with V2-mode disabled. To solve this problem, change the configuration of the controllers in VTP V2-mode to disabled.</p>
Join Transmitted	Number of VTP pruning messages sent on the trunk.
Join Received	Number of VTP pruning messages received on the trunk.
Summary Advts Received from non-pruning-capable device	Number of VTP summary messages received on the trunk from devices that do not support pruning.

This is an example of output from the **show vtp status** command. The table that follows describes each field in the display.

```

Controller> show vtp status
VTP Version capable      : 1 to 3
VTP version running     : 1
VTP Domain Name         :
VTP Pruning Mode        : Disabled
VTP Traps Generation    : Disabled
Device ID                : 2037.06ce.3580
Configuration last modified by 192.168.1.1 at 10-10-12 04:34:02
Local updater ID is 192.168.1.1 on interface LIIN0 (first layer3 interface found
)

```

Feature VLAN:

```

-----
VTP Operating Mode      : Server
Maximum VLANs supported locally : 1005
Number of existing VLANs : 7
Configuration Revision  : 2
MD5 digest              : 0xA0 0xA1 0xFE 0x4E 0x7E 0x5D 0x97 0x41
                        : 0x89 0xB9 0x9B 0x70 0x03 0x61 0xE9 0x27

```

Table 11: show vtp status Field Descriptions

Field	Description
VTP Version capable	Displays the VTP versions that are capable of operating on the controller.
VTP Version running	Displays the VTP version operating on the controller. By default, the controller implements Version 1 but can be set to Version 2.
VTP Domain Name	Name that identifies the administrative domain for the controller.
VTP Pruning Mode	Displays whether pruning is enabled or disabled. Enabling pruning on a VTP server enables pruning for the entire management domain. Pruning restricts flooded traffic to those trunk links that the traffic must use to access the appropriate network devices.
VTP Traps Generation	Displays whether VTP traps are sent to a network management station.
Device ID	Displays the MAC address of the local device.
Configuration last modified	Displays the date and time of the last configuration modification. Displays the IP address of the controller that caused the configuration change to the database.

Field	Description
VTP Operating Mode	<p>Displays the VTP operating mode, which can be server, client, or transparent.</p> <p>Server—A controller in VTP server mode is enabled for VTP and sends advertisements. You can configure VLANs on it. The controller guarantees that it can recover all the VLAN information in the current VTP database from NVRAM after reboot. By default, every controller is a VTP server.</p> <p>Note The controller automatically changes from VTP server mode to VTP client mode if it detects a failure while writing the configuration to NVRAM and cannot return to server mode until the NVRAM is functioning.</p> <p>Client—A controller in VTP client mode is enabled for VTP, can send advertisements, but does not have enough nonvolatile storage to store VLAN configurations. You cannot configure VLANs on it. When a VTP client starts up, it does not send VTP advertisements until it receives advertisements to initialize its VLAN database.</p> <p>Transparent—A controller in VTP transparent mode is disabled for VTP, does not send or learn from advertisements sent by other devices, and cannot affect VLAN configurations on other devices in the network. The controller receives VTP advertisements and forwards them on all trunk ports except the one on which the advertisement was received.</p>
Maximum VLANs Supported Locally	Maximum number of VLANs supported locally.
Number of Existing VLANs	Number of existing VLANs.
Configuration Revision	Current configuration revision number on this controller.
MD5 Digest	A 16-byte checksum of the VTP configuration.

This is an example of output from the **show vtp status** command for a controller running VTP version 3:

Related Commands

Command	Description
clear vtp counters	Clears the VLAN Trunking Protocol (VTP) and pruning counters.

show wireless vlan group

To display the detailed list of VLANs in a VLAN group and the status of the DHCP failed vlans, use the **show wireless vlan group** command in privileged EXEC mode.

show wireless vlan group *group-name*

Syntax Description

<i>group-name</i>	Name of the wireless VLAN group.
-------------------	----------------------------------

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Enter this command in the global configuration mode only.

Examples

This example shows how to display the summary of a VLAN group:

```
Controller# show wireless vlan group grp1
```

```
Member Vlans Configured
```

```
-----
VLAN      VLAN Name      DHCP Failed
100       VLAN0100       No
101       VLAN0101       Yes
102       VLAN0102       No
103       VLAN0103       No
104       VLAN0104       Yes
105       VLAN0105       No
```

spanning-tree vlan

To configure spanning tree on a per-VLAN basis, use the **spanning-tree vlan** command in global configuration mode on the switch stack or on a standalone switch. To return to the default setting, use the **no** form of this command.

spanning-tree vlan *vlan-id* [**forward-time** *seconds*| **hello-time** *seconds*| **max-age** *seconds*| **priority** *priority*| **root** {**primary**| **secondary**} [**diameter** *net-diameter* [**hello-time** *seconds*]]]

no spanning-tree vlan *vlan-id* [**forward-time**| **hello-time**| **max-age**| **priority**| **root**]

Syntax Description

<i>vlan-id</i>	VLAN range associated with a spanning-tree instance. You can specify a single VLAN identified by VLAN ID number, a range of VLANs separated by a hyphen, or a series of VLANs separated by a comma. The range is 1 to 4094.
forward-time <i>seconds</i>	(Optional) Sets the forward-delay time for the specified spanning-tree instance. The forwarding time specifies how long each of the listening and learning states last before the interface begins forwarding. The range is 4 to 30 seconds.
hello-time <i>seconds</i>	(Optional) Sets the interval between hello bridge protocol data units (BPDUs) sent by the root switch configuration messages. The range is 1 to 10 seconds.
max-age <i>seconds</i>	(Optional) Sets the interval between messages the spanning tree receives from the root switch. If a switch does not receive a BPDU message from the root switch within this interval, it recomputes the spanning-tree topology. The range is 6 to 40 seconds.
priority <i>priority</i>	(Optional) Sets the switch priority for the specified spanning-tree instance. This setting affects the likelihood that the switch is selected as the root switch. A lower value increases the probability that the switch is selected as the root switch. The range is 0 to 61440 in increments of 4096. Valid priority values are 4096, 8192, 12288, 16384, 20480, 24576, 28672, 32768, 36864, 40960, 45056, 49152, 53248, 57344, and 61440. All other values are rejected.
root primary	(Optional) Forces this switch to be the root switch.
root secondary	(Optional) Sets this switch to be the root switch should the primary root switch fail.
diameter <i>net-diameter</i>	(Optional) Sets the maximum number of switches between any two end stations. The range is 2 to 7.

Command Default

Spanning tree is enabled on all VLANs.
The forward-delay time is 15 seconds.
The hello time is 2 seconds.

The max-age is 20 seconds.

The primary root switch priority is 24576.

The secondary root switch priority is 28672.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Disabling the STP causes the VLAN to stop participating in the spanning-tree topology. Interfaces that are administratively down remain down. Received BPDUs are forwarded like other multicast frames. The VLAN does not detect and prevent loops when STP is disabled.

You can disable the STP on a VLAN that is not currently active and verify the change by using the **show running-config** or the **show spanning-tree vlan *vlan-id*** privileged EXEC command. The setting takes effect when the VLAN is activated.

When disabling or reenabling the STP, you can specify a range of VLANs that you want to disable or enable.

When a VLAN is disabled and then enabled, all assigned VLANs continue to be its members. However, all spanning-tree bridge parameters are returned to their previous settings (the last setting before the VLAN was disabled).

You can enable spanning-tree options on a VLAN that has no interfaces assigned to it. The setting takes effect when you assign interfaces to it.

When setting the **max-age *seconds***, if a switch does not receive BPDUs from the root switch within the specified interval, it recomputes the spanning-tree topology. The max-age setting must be greater than the hello-time setting.

The **spanning-tree vlan *vlan-id* root** command should be used only on backbone switches.

When you enter the **spanning-tree vlan *vlan-id* root** command, the software checks the switch priority of the current root switch for each VLAN. Because of the extended system ID support, the switch sets the switch priority for the specified VLAN to 24576 if this value will cause this switch to become the root for the specified VLAN. If any root switch for the specified VLAN has a switch priority lower than 24576, the switch sets its own priority for the specified VLAN to 4096 less than the lowest switch priority. (4096 is the value of the least-significant bit of a 4-bit switch priority value.)

When you enter the **spanning-tree vlan *vlan-id* root secondary** command, because of support for the extended system ID, the software changes the switch priority from the default value (32768) to 28672. If the root switch should fail, this switch becomes the next root switch (if the other switches in the network use the default switch priority of 32768, and therefore, are unlikely to become the root switch).

Examples

This example shows how to disable the STP on VLAN 5:

```
Controller(config)# no spanning-tree vlan 5
```

You can verify your setting by entering the **show spanning-tree** privileged EXEC command. In this instance, VLAN 5 does not appear in the list.

This example shows how to set the spanning-tree forwarding time to 18 seconds for VLANs 20 and 25:

```
Controller(config)# spanning-tree vlan 20,25 forward-time 18
```

This example shows how to set the spanning-tree hello-delay time to 3 seconds for VLANs 20 to 24:

```
Controller(config)# spanning-tree vlan 20-24 hello-time 3
```

This example shows how to set spanning-tree max-age to 30 seconds for VLAN 20:

```
Controller(config)# spanning-tree vlan 20 max-age 30
```

This example shows how to reset the max-age parameter to the default value for spanning-tree instance 100 and 105 to 108:

```
Controller(config)# no spanning-tree vlan 100, 105-108 max-age
```

This example shows how to set the spanning-tree priority to 8192 for VLAN 20:

```
Controller(config)# spanning-tree vlan 20 priority 8192
```

This example shows how to configure the switch as the root for VLAN 10 with a network diameter of 4:

```
Controller(config)# spanning-tree vlan 10 root primary diameter 4
```

This example shows how to configure the switch as the secondary root switch for VLAN 10 with a network diameter of 4:

```
Controller(config)# spanning-tree vlan 10 root secondary diameter 4
```

You can verify your settings by entering the **show spanning-tree vlan *vlan-id*** privileged EXEC command.

wireless broadcast vlan

To enable broadcast support on a VLAN, use the **wireless broadcast vlan** command in global configuration mode. To disable Ethernet broadcast support, use the **no** form of the command.

wireless broadcast vlan [*vlan-id*]

no wireless broadcast vlan [*vlan-id*]

Syntax Description	<i>vlan-id</i>	(Optional) Specifies the VLAN ID to enable broadcast support to that VLAN. The value ranges from 1 to 4095.
---------------------------	----------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines	Use this command in the global configuration mode only.
-------------------------	---

Examples	This example shows how to enable broadcasting on VLAN 20:
-----------------	---

```
Controller(config)# wireless broadcast vlan 20
```

wireless vlan group

To create a wireless VLAN group, use the **wireless vlan group** command in interface configuration mode.

wireless vlan group *group-name* **vlan-list** *vlan-id*

Syntax Description

<i>group-name</i>	Name of the VLAN group.
<i>vlan-id</i>	Range of the VLAN IDs to be added to the group.

Command Default

None

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The VLAN must be available to be grouped.

Examples

This example shows how to map VLANs 91 through 125 to a wireless VLAN group:

```
Controller(config)# wireless vlan group grp1 vlan-list 91-125
```

wlan

To create a wireless LAN, use the **wlan** command. To disable a wireless LAN, use the **no** form of this command.

wlan [*wlan-name*] *wlan-name wlan-id* | *wlan-name wlan-id wlan-ssid*

no wlan [*wlan-name*] *wlan-name wlan-id* | *wlan-name wlan-id wlan-ssid*

Syntax Description

<i>wlan-name</i>	WLAN profile name. The name is from 1 to 32 alphanumeric characters.
<i>wlan-id</i>	Wireless LAN identifier. The range is from 1 to 512.
<i>wlan-ssid</i>	SSID. The range is from 1 to 32 alphanumeric characters.

Command Default

WLAN is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

If you do not specify an SSID, the profile name parameter is used for both the profile name and the SSID. If the management and AP-manager interfaces are mapped to the same port and are members of the same VLAN, you must disable the WLAN before making a port-mapping change to either interface. If the management and AP-manager (Access Point Manager) interfaces are assigned to different VLANs, you do not need to disable the WLAN.

An error message appears if you try to delete a WLAN that is assigned to an access point group. If you proceed, the WLAN is removed from the access point group and from the access point's radio.

Examples

This example shows how to create a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config)# wlan test-wlan-cr 67 test-wlan-cr-ssid
```

This example shows how to delete a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config)# no wlan test-wlan-cr 67 test-wlan-cr-ssid
```



PART **V**

VideoStream

- [VideoStream Commands, page 273](#)



VideoStream Commands

- [ap dot11 media-stream multicast-direct, page 274](#)
- [show ap dot11, page 275](#)
- [show wireless media-stream group, page 276](#)
- [wireless media-stream multicast-direct, page 277](#)
- [wireless media-stream, page 278](#)

ap dot11 media-stream multicast-direct

To configure multicast-direct for 2.4-GHz/5-GHz band, use the **ap dot11 media-stream multicast-direct** command.

```
ap dot11 {24ghz|5ghz} media-stream {multicast-direct {admission-besteffort| client-maximum value|
radio-maximum value}| video-redirect}
```

Syntax Description

multicast-direct	Configure multicast-direct for 802.11 band
admission-besteffort	Admits media stream to best-effort queue.
client-maximum <i>value</i>	Specifies the maximum number of streams allowed on a client.
radio-maximum <i>value</i>	Specifies the maximum number of streams allowed on a 2.4-GHz or a 5-GHz band.
video-redirect	Redirect non Multicast-direct video to BestEffort queue over the air.

Command Default

None.

Command Modes

config

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Before you configure the media stream multicast-direct parameters on a 802.11 network, ensure that the network is nonoperational.

Examples

This example shows how to configure multicast-direct for the 2.4-GHz band.

```
Controller#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)#ap dot11 24ghz media-stream multicast-direct
```

show ap dot11

To display 802.11 band parameters, use the **show ap dot11** command.

show ap dot11 {24ghz| 5ghz} {media-stream rrc| network| profile| summary}

Syntax Description		
media-stream rrc		Displays Media Stream configurations.
network		Shows network configuration.
profile		Shows profiling information for all Cisco APs.
summary		Shows configuration and statistics of 802.11b and 802.11a Cisco APs.

Command Default None.

Command Modes User EXEC command mode or Privileged EXEC command mode

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines None.

Examples This example shows how to display 802.11 Media Resource Reservation Control configurations.

```

Controller#show ap dot11 24ghz media-stream rrc

Multicast-direct           : Disabled
Best Effort                 : Disabled
Video Re-Direct           : Disabled
Max Allowed Streams Per Radio : Auto
Max Allowed Streams Per Client : Auto
Max Video Bandwidth        : 0
Max Voice Bandwidth        : 75
Max Media Bandwidth        : 85
Min PHY Rate (Kbps)        : 6000
Max Retry Percentage       : 80

```

show wireless media-stream group

To display the wireless media-stream group information, use the **show wireless media-stream group** command.

show wireless media-stream group {*detail groupName*| **summary**}

Syntax Description

detail <i>groupName</i>	Display media-stream group configuration details of the group mentioned in the command.
summary	Display media-stream group configuration summary

Command Default

None

Command Modes

User EXEC mode or Privileged EXEC mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None.

Examples

This example shows how to display the details of the media-stream group named GRP1.

```
Controller#show wireless media-stream group detail GRP1
```

wireless media-stream multicast-direct

To configure multicast-direct status, use the **media-stream multicast-direct** command. To remove the multicast-direct status, use the no form of the command.

no wireless media-stream multicast-direct

Command Default

None.

Command Modes

config

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Media stream multicast-direct requires load based Call Admission Control (CAC) to run. WLAN quality of service (QoS) needs to be set to either gold or platinum.

Examples

This example shows how to configure multicast-direct for a wireless LAN media stream.

```
Controller#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)#wireless media-stream multicast-direct
```

wireless media-stream

To configure various parameters, use the **wireless media-stream** command.

wireless media-stream group *groupName* [*startipAddr endipAddr*]

wireless media-stream group { *avg-packet-size* *default* *exit* *max-bandwidth* *no* *policy* *qos*}

wireless media-stream { **multicast-direct** | **message** [**phone** *phone* | **URL** *URL* | **Notes** *Notes* | **Email** *Email*] }

Syntax Description

group <i>groupName</i>	Configure multicast-direct status for a group.
<i>startipAddr</i>	Specifies the start IP Address for the group.
<i>endipAddr</i>	Specifies the End IP Address for the group.
group <i>avg-packet-size</i>	Configure average packet size.
group <i>default</i>	Set a command to its defaults.
group <i>exit</i>	Exit sub-mode.
group <i>max-bandwidth</i>	Configure maximum expected stream bandwidth in Kbps.
group <i>no</i>	Negate a command or set its defaults.
group <i>policy</i>	Configure media stream admission policy.
group <i>qos</i>	Configure over the air QoS class, <'video'> ONLY.
multicast-direct	Configure multicast-direct status.
message	Configure Session Announcement Message.
phone <i>phone</i>	Configure Session Announcement Phone number.
URL <i>URL</i>	Configure Session Announcement URL.
Notes <i>Notes</i>	Configure Session Announcement notes.
Email <i>Email</i>	Configure Session Announcement Email.

Command Default Disabled

Command Modes config

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Media-stream multicast-direct requires load-based Call Admission Control (CAC) to run.

Examples

This example shows how to configure each media stream and its parameters like expected multicast destination addresses, stream bandwidth consumption and stream priority parameters.

```
Controller#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
Controller(config)#wireless media-stream group GROUP1 231.1.1.1 231.1.1.10
```




PART VI

Multicast

- [IP Multicast Commands, page 283](#)



IP Multicast Commands

- [cache-memory-max](#), page 285
- [ip igmp filter](#), page 286
- [ip igmp max-groups](#), page 287
- [ip igmp profile](#), page 289
- [ip igmp snooping](#), page 291
- [ip igmp snooping last-member-query-count](#), page 292
- [ip igmp snooping querier](#), page 294
- [ip igmp snooping report-suppression](#), page 296
- [ip igmp snooping vlan mrouter](#), page 298
- [ip igmp snooping vlan static](#), page 299
- [ip multicast vlan](#), page 301
- [match message-type](#), page 302
- [match service-instance](#), page 303
- [match service-type](#), page 304
- [service-list mdns-sd](#), page 305
- [service-routing mdns-sd](#), page 307
- [service-policy](#), page 308
- [redistribute mdns-sd](#), page 309
- [service-policy-query](#), page 310
- [show ip igmp filter](#), page 311
- [show ip igmp profile](#), page 312
- [show ip igmp snooping](#), page 313
- [show ip igmp snooping groups](#), page 315
- [show ip igmp snooping igmpv2-tracking](#), page 317

- [show ip igmp snooping mrouter](#), page 318
- [show ip igmp snooping querier](#), page 319
- [show ip igmp snooping wireless mcast-spi-count](#), page 321
- [show ip igmp snooping wireless mgid](#), page 322
- [show mdns cache](#), page 323
- [show mdns requests](#), page 325
- [show mdns statistics](#), page 326
- [show wireless multicast](#), page 327
- [show wireless multicast group](#), page 328
- [wireless multicast](#), page 329
- [wireless mdns-bridging](#), page 330

cache-memory-max

To set a percentage of the system memory for cache, use the **cache-memory-max** command. To remove a percentage of system memory for cache, use the **no** form of this command.

cache-memory-max *cache-config-percentage*

no cache-memory-max *cache-config-percentage*

Syntax Description	<i>cache-config-percentage</i>	A percentage of the system memory for cache.
Command Default	10 percent.	
Command Modes	mDNS configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The number of services learned in a network could be large, so there is an upper limit on the amount of cache memory that can be used. The memory is set by default to a maximum of 10 percent of the system memory.



Note

You can override the default value by using this command.

When you try to add new records, and the cache is full, the records in the cache that are close to expiring are deleted to provide space for the new records.

Examples

This example sets 20 percent of the system memory for cache:

```
Controller(config-mdns) # cache-memory-max 20
```

ip igmp filter

To control whether or not all hosts on a Layer 2 interface can join one or more IP multicast groups by applying an Internet Group Management Protocol (IGMP) profile to the interface, use the **ip igmp filter** interface configuration command on the controller stack or on a standalone controller. To remove the specified profile from the interface, use the **no** form of this command.

ip igmp filter *profile number*

no ip igmp filter

Syntax Description

<i>profile number</i>	The IGMP profile number to be applied. The range is 1 to 4294967295.
-----------------------	--

Command Default

No IGMP filters are applied.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can apply IGMP filters only to Layer 2 physical interfaces; you cannot apply IGMP filters to routed ports, switch virtual interfaces (SVIs), or ports that belong to an EtherChannel group.

An IGMP profile can be applied to one or more controller port interfaces, but one port can have only one profile applied to it.

Examples

You can verify your setting by using the **show running-config** privileged EXEC command and by specifying an interface.

Related Commands

Command	Description
ip igmp profile	Configures and enters IGMP Filter Profile configuration mode.
show ip dhcp snooping statistics	Displays DHCP snooping statistics.

ip igmp max-groups

To set the maximum number of Internet Group Management Protocol (IGMP) groups that a Layer 2 interface can join or to configure the IGMP throttling action when the maximum number of entries is in the forwarding table, use the **ip igmp max-groups** interface configuration command on the controller stack or on a standalone controller. To set the maximum back to the default, which is to have no maximum limit, or to return to the default throttling action, which is to drop the report, use the **no** form of this command.

ip igmp max-groups {*max number* | **action** { **deny** | **replace** } }

no ip igmp max-groups {*max number* | **action** }

Syntax Description

<i>max number</i>	The maximum number of IGMP groups that an interface can join. The range is 0 to 4294967294. The default is no limit.
action deny	Drops the next IGMP join report when the maximum number of entries is in the IGMP snooping forwarding table. This is the default action.
action replace	Replaces the existing group with the new group for which the IGMP report was received when the maximum number of entries is in the IGMP snooping forwarding table.

Command Default

The default maximum number of groups is no limit.

After the controller learns the maximum number of IGMP group entries on an interface, the default throttling action is to drop the next IGMP report that the interface receives and to not add an entry for the IGMP group to the interface.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can use this command only on Layer 2 physical interfaces and on logical EtherChannel interfaces. You cannot set IGMP maximum groups for routed ports, switch virtual interfaces (SVIs), or ports that belong to an EtherChannel group.

Follow these guidelines when configuring the IGMP throttling action:

- If you configure the throttling action as deny and set the maximum group limitation, the entries that were previously in the forwarding table are not removed but are aged out. After these entries are aged out, when the maximum number of entries is in the forwarding table, the controller drops the next IGMP report received on the interface.

- If you configure the throttling action as replace and set the maximum group limitation, the entries that were previously in the forwarding table are removed. When the maximum number of entries is in the forwarding table, the controller replaces a randomly selected multicast entry with the received IGMP report.
- When the maximum group limitation is set to the default (no maximum), entering the **ip igmp max-groups {deny | replace}** command has no effect.

Examples

This example shows how to limit to 25 the number of IGMP groups that a port can join:

```
Controller(config)# interface gigabitethernet1/0/2
Controller(config-if)# ip igmp max-groups 25
```

This example shows how to configure the controller to replace the existing group with the new group for which the IGMP report was received when the maximum number of entries is in the forwarding table:

```
Controller(config)# interface gigabitethernet2/0/1
Controller(config-if)# ip igmp max-groups action replace
```

You can verify your setting by using the **show running-config** privileged EXEC command and by specifying an interface.

ip igmp profile

To create an Internet Group Management Protocol (IGMP) profile and enter IGMP profile configuration mode, use the **ip igmp profile** global configuration command on the controller stack or on a standalone controller. From this mode, you can specify the configuration of the IGMP profile to be used for filtering IGMP membership reports from a switch port. To delete the IGMP profile, use the **no** form of this command.

ip igmp profile *profile number*

no ip igmp profile *profile number*

Syntax Description

<i>profile number</i>	The IGMP profile number being configured. The range is from 1 to 4294967295.
-----------------------	--

Command Default

No IGMP profiles are defined. When configured, the default action for matching an IGMP profile is to deny matching addresses.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

When you are in IGMP profile configuration mode, you can create the profile by using these commands:

- **deny**—Specifies that matching addresses are denied; this is the default condition.
- **exit**—Exits from igmp-profile configuration mode.
- **no**—Negates a command or resets to its defaults.
- **permit**—Specifies that matching addresses are permitted.
- **range**—Specifies a range of IP addresses for the profile. This can be a single IP address or a range with a start and an end address.

When entering a range, enter the low IP multicast address, a space, and the high IP multicast address.

You can apply an IGMP profile to one or more Layer 2 interfaces, but each interface can have only one profile applied to it.

Examples

This example shows how to configure IGMP profile 40 that permits the specified range of IP multicast addresses:

```
Controller(config)# ip igmp profile 40
Controller(config-igmp-profile)# permit
Controller(config-igmp-profile)# range 233.1.1.1 233.255.255.255
```

You can verify your settings by using the **show ip igmp profile** privileged EXEC command.

Related Commands

Command	Description
ip igmp filter	Applies IGMP profile to the interface.
show ip igmp profile	Displays configured IGMP profiles specified by the command.

ip igmp snooping

To globally enable Internet Group Management Protocol (IGMP) snooping on the controller or to enable it on a per-VLAN basis, use the **ip igmp snooping** global configuration command on the controller stack or on a standalone controller. To return to the default setting, use the **no** form of this command.

ip igmp snooping [*vlan vlan-id*]

no ip igmp snooping [*vlan vlan-id*]

Syntax Description

vlan <i>vlan-id</i>	(Optional) Enables IGMP snooping on the specified VLAN. The range is 1 to 1001 and 1006 to 4094.
----------------------------	--

Command Default

IGMP snooping is globally enabled on the controller.
IGMP snooping is enabled on VLAN interfaces.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

When IGMP snooping is enabled globally, it is enabled in all of the existing VLAN interfaces. When IGMP snooping is globally disabled, it is disabled on all of the existing VLAN interfaces.

VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping.

Examples

This example shows how to globally enable IGMP snooping:

```
Controller(config)# ip igmp snooping
```

This example shows how to enable IGMP snooping on VLAN 1:

```
Controller(config)# ip igmp snooping vlan 1
```

You can verify your settings by entering the **show ip igmp snooping** privileged EXEC command.

Related Commands

Command	Description
ip igmp snooping report-suppression	Enables IGMP report suppression.
show ip igmp snooping	Displays IGMP snooping configurations.

ip igmp snooping last-member-query-count

To configure how often Internet Group Management Protocol (IGMP) snooping will send query messages in response to receiving an IGMP leave message, use the **ip igmp snooping last-member-query-count** command in global configuration mode. To set *count* to the default value, use the **no** form of the command.

ip igmp snooping [*vlan vlan-id*] **last-member-query-count** *count*

no ip igmp snooping [*vlan vlan-id*] **last-member-query-count** *count*

Syntax Description

<i>vlan vlan-id</i>	(Optional) Sets the count value on a specific VLAN ID. The range is from 1 to 1001. Do not enter leading zeroes.
<i>count</i>	The interval at which query messages are sent, in milliseconds. The range is from 1 to 7. The default is 2.

Command Default

A query is sent every 2 milliseconds.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

When a multicast host leaves a group, the host sends an IGMP leave message. To check if this host is the last to leave the group, IGMP query messages are sent when the leave message is seen until the **last-member-query-interval** timeout period expires. If no response to the last-member queries are received before the timeout period expires, the group record is deleted.

Use the **ip igmp snooping last-member-query-interval** command to configure the timeout period.

When both IGMP snooping immediate-leave processing and the query count are configured, immediate-leave processing takes precedence.



Note

Do not set the count to 1 because the loss of a single packet (the query packet from the controller to the host or the report packet from the host to the controller) may result in traffic forwarding being stopped even if there is still a receiver. Traffic continues to be forwarded after the next general query is sent by the controller, but the interval during which a receiver may not receive the query could be as long as 1 minute (with the default query interval).

The leave latency in Cisco IOS software may increase by up to one last-member-query-interval (LMQI) value when the controller is processing more than one leave within an LMQI. In this case, the average leave latency

is determined by the $(\text{count} + 0.5) * \text{LMQI}$. The result is that the default leave latency can range from 2.0 to 3.0 seconds with an average of 2.5 seconds under a higher load of IGMP leave processing. The leave latency under load for the minimum LMQI value of 100 milliseconds and a count of 1 is from 100 to 200 milliseconds, with an average of 150 milliseconds. This is done to limit the impact of higher rates of IGMP leave messages.

Examples

The following example sets the last member query count to 5:

```
Controller(config)# ip igmp snooping last-member-query-count 5
```

ip igmp snooping querier

To globally enable the Internet Group Management Protocol (IGMP) querier function in Layer 2 networks, use the **ip igmp snooping querier** global configuration command. Use the command with keywords to enable and configure the IGMP querier feature on a VLAN interface. To return to the default settings, use the **no** form of this command.

ip igmp snooping [**vlan** *vlan-id*] **querier** [**address** *ip-address* | **max-response-time** *response-time* | **query-interval** *interval-count* | **tcn query** {**count** *count* | **interval** *interval*} | **timer expiry** *expiry-time* | **version** *version*]

no ip igmp snooping [**vlan** *vlan-id*] **querier** [**address** | **max-response-time** | **query-interval** | **tcn query** {**count** | **interval**} | **timer expiry** | **version**]

Syntax Description

vlan <i>vlan-id</i>	(Optional) Enables IGMP snooping and the IGMP querier function on the specified VLAN. The range is 1 to 1001 and 1006 to 4094.
address <i>ip-address</i>	(Optional) Specifies a source IP address. If you do not specify an IP address, the querier tries to use the global IP address configured for the IGMP querier.
max-response-time <i>response-time</i>	(Optional) Sets the maximum time to wait for an IGMP querier report. The range is 1 to 25 seconds.
query-interval <i>interval-count</i>	(Optional) Sets the interval between IGMP queries. The range is 1 to 18000 seconds.
tcn query	(Optional) Sets parameters related to Topology Change Notifications (TCNs).
count <i>count</i>	Sets the number of TCN queries to be executed during the TCN interval time. The range is 1 to 10.
interval <i>interval</i>	Sets the TCN query interval time. The range is 1 to 255.
timer expiry <i>expiry-time</i>	(Optional) Sets the length of time until the IGMP querier expires. The range is 60 to 300 seconds.
version <i>version</i>	(Optional) Selects the IGMP version number that the querier feature uses. Select 1 or 2.

Command Default

The IGMP snooping querier feature is globally disabled on the controller.

When enabled, the IGMP snooping querier disables itself if it detects IGMP traffic from a multicast router.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use this command to enable IGMP snooping to detect the IGMP version and IP address of a device that sends IGMP query messages, which is also called a querier.

By default, the IGMP snooping querier is configured to detect devices that use IGMP Version 2 (IGMPv2) but does not detect clients that are using IGMP Version 1 (IGMPv1). You can manually configure the max-response-time value when devices use IGMPv2. You cannot configure the max-response-time when devices use IGMPv1. (The value cannot be configured and is set to zero).

Non-RFC compliant devices running IGMPv1 might reject IGMP general query messages that have a non-zero value as the max-response-time value. If you want the devices to accept the IGMP general query messages, configure the IGMP snooping querier to run IGMPv1.

VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping.

Examples

This example shows how to globally enable the IGMP snooping querier feature:

```
Controller(config)# ip igmp snooping querier
```

This example shows how to set the IGMP snooping querier maximum response time to 25 seconds:

```
Controller(config)# ip igmp snooping querier max-response-time 25
```

This example shows how to set the IGMP snooping querier interval time to 60 seconds:

```
Controller(config)# ip igmp snooping querier query-interval 60
```

This example shows how to set the IGMP snooping querier TCN query count to 25:

```
Controller(config)# ip igmp snooping querier tcn count 25
```

This example shows how to set the IGMP snooping querier timeout to 60 seconds:

```
Controller(config)# ip igmp snooping querier timer expiry 60
```

This example shows how to set the IGMP snooping querier feature to version 2:

```
Controller(config)# ip igmp snooping querier version 2
```

You can verify your settings by entering the **show ip igmp snooping** privileged EXEC command.

Related Commands

Command	Description
ip igmp snooping report-suppression	Enables IGMP report suppression.
show ip igmp snooping	Displays IGMP snooping configurations.
show ip igmp snooping groups	Displays the IGMP snooping multicast table.

ip igmp snooping report-suppression

To enable Internet Group Management Protocol (IGMP) report suppression, use the **ip igmp snooping report-suppression** global configuration command on the controller stack or on a standalone controller. To disable IGMP report suppression and to forward all IGMP reports to multicast routers, use the **no** form of this command.

ip igmp snooping report-suppression

no ip igmp snooping report-suppression

Syntax Description This command has no arguments or keywords.

Command Default IGMP report suppression is enabled.

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

IGMP report suppression is supported only when the multicast query has IGMPv1 and IGMPv2 reports. This feature is not supported when the query includes IGMPv3 reports.

The controller uses IGMP report suppression to forward only one IGMP report per multicast router query to multicast devices. When IGMP report suppression is enabled (the default), the controller sends the first IGMP report from all hosts for a group to all the multicast routers. The controller does not send the remaining IGMP reports for the group to the multicast routers. This feature prevents duplicate reports from being sent to the multicast devices.

If the multicast router query includes requests only for IGMPv1 and IGMPv2 reports, the controller forwards only the first IGMPv1 or IGMPv2 report from all hosts for a group to all of the multicast routers. If the multicast router query also includes requests for IGMPv3 reports, the controller forwards all IGMPv1, IGMPv2, and IGMPv3 reports for a group to the multicast devices.

If you disable IGMP report suppression by entering the **no ip igmp snooping report-suppression** command, all IGMP reports are forwarded to all of the multicast routers.

Examples

This example shows how to disable report suppression:

```
Controller(config)# no ip igmp snooping report-suppression
```

You can verify your settings by entering the **show ip igmp snooping** privileged EXEC command.

Related Commands

Command	Description
show ip igmp snooping	Displays IGMP snooping configurations.

ip igmp snooping vlan mrouter

To add a multicast router port, use the **ip igmp snooping mrouter** global configuration command on the controller stack or on a standalone controller. To return to the default settings, use the **no** form of this command.

Command Default By default, there are no multicast router ports.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping. The configuration is saved in NVRAM.

Examples This example shows how to configure a port as a multicast router port:
 Controller(config)# **ip igmp snooping vlan 1 mrouter interface gigabitethernet1/0/2**
 You can verify your settings by entering the **show ip igmp snooping** privileged EXEC command.

Related Commands	Command	Description
	ip igmp snooping report-suppression	Enables IGMP report suppression.
	show ip igmp snooping	Displays IGMP snooping configurations.
	show ip igmp snooping groups	Displays the IGMP snooping multicast table.
	show ip igmp snooping mrouter	Displays the IGMP snooping multicast router ports.
	show ip igmp snooping querier	Displays the configuration and operation information for the IGMP querier.

ip igmp snooping vlan static

To enable Internet Group Management Protocol (IGMP) snooping and to statically add a Layer 2 port as a member of a multicast group, use the **ip igmp snooping vlan static** global configuration command on the controller stack or on a standalone controller. Use the **no** form of this command to remove ports specified as members of a static multicast group.

ip igmp snooping vlan *vlan-id* **static** *ip-address* **interface** *interface-id*

no ip igmp snooping vlan *vlan-id* **static** *ip-address* **interface** *interface-id*

Syntax Description

<i>vlan-id</i>	Enables IGMP snooping on the specified VLAN. The range is 1 to 1001 and 1006 to 4094.
<i>ip-address</i>	Adds a Layer 2 port as a member of a multicast group with the specified group IP address.
interface <i>interface-id</i>	Specifies the interface of the member port. The <i>interface-id</i> value has these options: <ul style="list-style-type: none"> • <i>fastethernet interface number</i>—A Fast Ethernet IEEE 802.3 interface. • <i>gigabitethernet interface number</i>—A Gigabit Ethernet IEEE 802.3z interface. • <i>tengigabitethernet interface number</i>—A 10-Gigabit Ethernet IEEE 802.3z interface. • <i>port-channel interface number</i>—A channel interface. The range is 0 to 128.

Command Default

By default, there are no ports statically configured as members of a multicast group.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping. The configuration is saved in NVRAM.

Examples

This example shows how to statically configure a host on an interface:

```
Controller(config)# ip igmp snooping vlan 1 static 224.2.4.12 interface
gigabitEthernet1/0/1
Configuring port gigabitEthernet1/0/1 on group 224.2.4.12
```

You can verify your settings by entering the **show ip igmp snooping** privileged EXEC command.

Related Commands

Command	Description
ip igmp snooping report-suppression	Enables IGMP report suppression.
show ip igmp snooping	Displays IGMP snooping configurations.
show ip igmp snooping groups	Displays the IGMP snooping multicast table.
show ip igmp snooping mrouter	Displays the IGMP snooping multicast router ports.
show ip igmp snooping querier	Displays the configuration and operation information for the IGMP querier.

ip multicast vlan

To configure IP multicast on a single VLAN, use the **ip multicast vlan** command in global configuration mode. To remove the VLAN from the WLAN, use the **no** form of the command.

ip multicast vlan {*vlan-name* | *vlan-id*}

no ip multicast vlan {*vlan-name* | *vlan-id*}

Syntax Description

<i>vlan-name</i>	Specifies the VLAN name.
<i>vlan-id</i>	Specifies the VLAN ID.

Command Default

Disabled.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None

Examples

This example configures `vlan_id01` as a multicast VLAN.

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wireless multicast
Controller(config)# wlan test-wlan 1
Controller(config-wlan)# ip multicast vlan vlan_id01
```

match message-type

To set the message type to match for a service list, use the **match message-type** command.

match message-type {**announcement**| **any**| **query**}

Syntax Description

announcement	Allows only service advertisements or announcements for the device.
any	Allows any match type.
query	Allows only a query from the client for a certain device in the network.

Command Default

None

Command Modes

Service list configuration.

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Multiple service maps of the same name with different sequence numbers can be created and the evaluation of the filters will be ordered on the sequence number. Service lists are an ordered sequence of individual statements, each one has a permit or deny result. Evaluation of service list consists of a list scan, in a predetermined order, and an evaluation of the criteria of each statement that matches. A list scan is stopped once the first statement match is found and an action permit/deny associated with the statement match is performed. The default action after scanning through the entire list is to deny.



Note It is not possible to use the **match** command if you have used the **service-list mdns-sd service-list-name query** command. The **match** command can be used only for the **permit** or **deny** option.

Examples

This example shows how to set the announcement message type to be matched:

```
Controller(config-mdns-sd-sl)# match message-type announcement
```

match service-instance

To set the service instance to match for a service list, use the **match service-instance** command.

match service-instance *line*

Syntax Description

<i>line</i>	Regular expression to match service instance in packets.
-------------	--

Command Default

None

Command Modes

Service list configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

It is not possible to use the **match** command if you have used the **service-list mdns-sd** *service-list-name* **query** command. The **match** command can be used only for the **permit** or **deny** option.

Examples

This example shows how to set the service instance to match:

```
Controller(config-mdns-sd-sl)# match service-instance servInst 1
```

match service-type

To set the value of the mDNS service type string to match, use the **match service-type** command.

match service-type *line*

Syntax Description

<i>line</i>	Regular expression to match service type in packets.
-------------	--

Command Default

None

Command Modes

Service list configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

It is not possible to use the **match** command if you have used the **service-list mdns-sd** *service-list-name* **query** command. The **match** command can be used only for the **permit** or **deny** option.

Examples

This example shows how to set the value of the mDNS service type string to match:

```
Controller(config-mdns-sd-sl)# match service-type _ipp._tcp
```

service-list mdns-sd

To enter mDNS service discovery service-list mode on the controller, use the **service-list mdns-sd** command. To exit mDNS service discovery service-list mode, use the **no** form of the command.

service-list mdns-sd *service-list-name* {**permit** | **deny**} *sequence-number* [**query**]

no service-list mdns-sd *service-list-name* {**permit** | **deny**} *sequence-number* [**query**]

Syntax Description

<i>service-list-name</i>	Name of the service list.
permit <i>sequence number</i>	Permits a filter on the service list to be applied to the sequence number.
deny <i>sequence number</i>	Denies a filter on the service list to be applied to the sequence number.
query	Associates a query for the service list name.

Command Default

Disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Service filters are modeled around access lists and route maps.

Multiple service maps of the same name with different sequence numbers can be created and the evaluation of the filters will be ordered on the sequence number. Service lists are an ordered sequence of individual statements, each has a permit or deny result. Evaluation of a service list consists of a list scan, in a predetermined order, and an evaluation of the criteria of each statement that matches. A list scan is aborted once the first statement match is found and an action, permit or deny associated with the statement match is performed. Default action after scanning through the entire list will be to deny.

This command can be used to enter mDNS service discovery service-list mode.

In this mode you can:

- Create a service list and apply a filter on the service list according to the **permit** or **deny** option applied to the sequence number.

Examples

This example shows how to create a service list and apply a filter on the service list according to the **permit** or **deny** option applied to the sequence number:

```
Controller(config)# service-list mdns-sd s11 permit 3
```

service-routing mdns-sd

To enable mDNS gateway functionality for a device and enter multicast DNS configuration mode, use the **service-routing mdns-sd** command. To restore default settings and return to global config mode, enter the **no** form of the command.

service-routing mdns-sd

no service-routing mdns-sd

This command has no arguments or keywords.

Command Default

Disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

mDNS gateway functionality can only be enabled or disabled globally, not on a per-interface basis. The service filter policy and redistribution can be configured globally as well as on a per-interface basis. Any interface specific configuration overrides the global configuration.

Examples

This example shows how to enable mDNS gateway functionality for a device and enter multicast DNS configuration mode:

```
Controller(config)# service-routing mdns-sd
```

Related Commands

Command	Description
match message-type	Sets the message type to match.
match service-instance	Sets the service instance to match.
match service-type	Sets the value of the mDNS service type string to match.

service-policy

To apply a filter on incoming or outgoing service discovery information on a service list, use the **service-policy** command. To remove the filter, use the **no** form of the command.

service-policy *service-policy-name* {**IN** | **OUT**}

no service-policy *service-policy-name* {**IN** | **OUT**}

Syntax Description

service-policy-name **IN** Applies a filter on incoming service discovery information.

service-policy-name **OUT** Applies a filter on outgoing service discovery information.

Command Default

Disabled.

Command Modes

mDNS configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The Controller intercepts mDNS packets. If they are mDNS messages destined to a wireless client (for example, the destination MAC is client's MAC address), and the client's mobility state is either local or foreign, the destination MAC address is overwritten with the client's MAC address and enqueues the packet to be sent out on the associated CAPWAP tunnel.

Examples

This example applies a filter on incoming service discovery information on a service list:

```
Controller(config-mdns)# service-policy serv-poll IN
```

redistribute mdns-sd

To redistribute services or service announcements across subnets, use the **redistribute mdns-sd** command. To disable redistribution of services or service announcements across subnets, use the **no** form of this command.

redistribute mdns-sd

no redistribute mdns-sd

This command has no arguments or keywords.

Command Default

The redistribution of services or service announcements across subnets is disabled.

Command Modes

mDNS configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

To redistribute service announcements across interfaces, use the **redistribute mdns-sd** command. This command sends out unsolicited announcements received on one interface to all of the other interfaces. The outgoing announcements are filtered as per the out-service policy defined for the interface or in absence of a per-interface service policy based on the global out-service policy.

In the absence of a redistribute option, services can be discovered by querying in a Layer 3 domain that is not local to the service provider.

Examples

This example shows how to redistribute services or service announcements across subnets:

```
Controller(config-mdns)# redistribute mdns-sd
```



Note

If redistribution is enabled globally, global configuration is given higher priority than interface configuration.

service-policy-query

To configure service list query periodicity, use the **service-policy-query** command. To delete the configuration, use the **no** form of this command.

service-policy-query [*service-list-query-name service-list-query-periodicity*]

no service-policy-query

Syntax Description

service-list-query-name service-list-query-periodicity (Optional) Configures the service list query periodicity.

Command Default

Disabled.

Command Modes

mDNS configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

As there are devices that do not send unsolicited announcements and to force learning of services and to keep them refreshed in the cache, this command contains an active query feature which ensures that services listed in the active query list will be queried.

Examples

This example shows how to configure service list query periodicity:

```
Controller(config-mdns)# service-policy-query sl-query1 100
```

show ip igmp filter

To display Internet Group Management Protocol (IGMP) filter information, use the **show ip igmp filter** command in privileged EXEC command mode.

show ip igmp [vrf *vrf-name*] filter

Syntax Description

vrf <i>vrf-name</i>	(Optional) Supports the multicast VPN routing and forwarding (VRF) instance.
----------------------------	--

Command Default

IGMP filters are enabled by default.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **show ip igmp filter** command displays information about all filters defined on the controller.

Examples

The following is sample output from the **show ip igmp filter** command:

```
Controller# show ip igmp filter
IGMP filter enabled
```

show ip igmp profile

To display all configured Internet Group Management Protocol (IGMP) profiles or a specified IGMP profile, use the **show ip igmp profile** privileged EXEC command.

show ip igmp [*vrf vrf-name*] **profile** [*profile number*]

Syntax Description

<i>vrf vrf-name</i>	(Optional) Supports the multicast VPN routing and forwarding (VRF) instance.
<i>profile number</i>	(Optional) The IGMP profile number to be displayed. The range is 1 to 4294967295. If no profile number is entered, all IGMP profiles are displayed.

Command Default

IGMP profiles undefined by default.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None

Examples

The following example shows the output of the **show ip igmp profile** privileged EXEC command for profile number 40 on the controller:

```
Controller# show ip igmp profile 40
IGMP Profile 40
  permit
  range 233.1.1.1 233.255.255.255
```

This example shows the output of the **show ip igmp profile** privileged EXEC command for all profiles configured on the controller:

```
Controller# show ip igmp profile

IGMP Profile 3
  range 230.9.9.0 230.9.9.0
IGMP Profile 4
  permit
  range 229.9.9.0 229.255.255.255
```

Related Commands

Command	Description
ip igmp profile	Configures and enters IGMP Filter Profile configuration mode.

show ip igmp snooping

To display the Internet Group Management Protocol (IGMP) snooping configuration of the controller or the VLAN, use the **show ip igmp snooping** command in user or privileged EXEC command mode.

show ip igmp snooping [**groups** | **mrouter** | **querier**] [**vlan** *vlan-id*] [**detail**]

Syntax Description	
groups	(Optional) Displays the IGMP snooping multicast table.
mrouter	(Optional) Displays the IGMP snooping multicast router ports.
querier	(Optional) Displays the configuration and operation information for the IGMP querier.
vlan <i>vlan-id</i>	(Optional) Specifies a VLAN; the range is 1 to 1001 and 1006 to 4094.
detail	(Optional) Displays operational state information.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping. Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain output do not appear, but the lines that contain Output appear.

Examples This is an example of output from the **show ip igmp snooping vlan 1** command. It shows snooping characteristics for a specific VLAN:

```
Controller# show ip igmp snooping vlan 1

Global IGMP Snooping configuration:
-----
IGMP snooping           : Enabled
IGMPv3 snooping (minimal) : Enabled
Report suppression      : Enabled
TCN solicit query       : Disabled
TCN flood query count    : 2
```

```
Robustness variable      : 2
Last member query count : 2
Last member query interval : 1000
```

Vlan 1:

```
-----
IGMP snooping           : Enabled
IGMPv2 immediate leave  : Disabled
Multicast router learning mode : pim-dvmrp
CGMP interoperability mode : IGMP_ONLY
Robustness variable     : 2
Last member query count : 2
Last member query interval : 1000
```

This is an example of output from the **show ip igmp snooping** command. It displays snooping characteristics for all VLANs on the controller:

```
Controller# show ip igmp snooping
Global IGMP Snooping configuration:
-----
IGMP snooping           : Enabled
IGMPv3 snooping (minimal) : Enabled
Report suppression     : Enabled
TCN solicit query      : Disabled
TCN flood query count  : 2
Robustness variable    : 2
Last member query count : 2
Last member query interval : 1000
```

Vlan 1:

```
-----
IGMP snooping           : Enabled
IGMPv2 immediate leave  : Disabled
Multicast router learning mode : pim-dvmrp
CGMP interoperability mode : IGMP_ONLY
Robustness variable     : 2
Last member query count : 2
Last member query interval : 1000
```

Vlan 2:

```
-----
IGMP snooping           : Enabled
IGMPv2 immediate leave  : Disabled
Multicast router learning mode : pim-dvmrp
CGMP interoperability mode : IGMP_ONLY
Robustness variable     : 2
Last member query count : 2
Last member query interval : 1000
<output truncated>
```

Related Commands

Command	Description
ip igmp snooping	Enables IGMP snooping.
show ip igmp snooping groups	Displays the IGMP snooping multicast table.
show ip igmp snooping mrouter	Displays the IGMP snooping multicast router ports.
show ip igmp snooping querier	Displays the configuration and operation information for the IGMP querier.

show ip igmp snooping groups

To display the Internet Group Management Protocol (IGMP) snooping multicast table for the controller or the multicast information, use the **show ip igmp snooping groups** privileged EXEC command.

```
show ip igmp snooping groups [vlan vlan-id] [[count] | ip_address]
```

Syntax Description

vlan <i>vlan-id</i>	(Optional) Specifies a VLAN; the range is 1 to 1001 and 1006 to 4094. Use this option to display the multicast table for a specified multicast VLAN or specific multicast information.
count	(Optional) Displays the total number of entries for the specified command options instead of the actual entries.
<i>ip_address</i>	(Optional) Characteristics of the multicast group with the specified group IP address.

Command Modes

Privileged EXEC
User EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain output do not appear, but the lines that contain Output appear.

Examples

This is an example of output from the **show ip igmp snooping groups** command without any keywords. It displays the multicast table for the controller:

```
Controller# show ip igmp snooping groups
Vlan      Group          Type      Version  Port List
-----
1         224.1.4.4      igmp
1         224.1.4.5      igmp
2         224.0.1.40     igmp      v2       Gi1/0/15
104      224.1.4.2      igmp      v2       Gi2/0/1, Gi2/0/2
104      224.1.4.3      igmp      v2       Gi2/0/1, Gi2/0/2
```

This is an example of output from the **show ip igmp snooping groups count** command. It displays the total number of multicast groups on the controller:

```
Controller# show ip igmp snooping groups count
Total number of multicast groups: 2
```

This is an example of output from the **show ip igmp snooping groups vlan vlan-id ip-address** command. It shows the entries for the group with the specified IP address:

```

Controller# show ip igmp snooping groups vlan 104 224.1.4.2
Vlan      Group      Type      Version    Port List
-----
104       224.1.4.2  igmp      v2         Gi2/0/1, Gi1/0/15

```

Related Commands

Command	Description
ip igmp snooping	Enables IGMP snooping.
show ip igmp snooping	Displays IGMP snooping configurations.

show ip igmp snooping igmpv2-tracking

To display group and IP address entries, use the **show ip igmp snooping igmpv2-tracking** command in privileged EXEC mode.



Note

The command displays group and IP address entries only for wireless multicast IGMP joins and not for wired joins. This command also displays output only if wireless multicast is enabled.

show ip igmp snooping igmpv2-tracking

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

show ip igmp snooping mrouter

To display the Internet Group Management Protocol (IGMP) snooping dynamically learned and manually configured multicast router ports for the controller or for the specified multicast VLAN, use the **show ip igmp snooping mrouter** privileged EXEC command.

show ip igmp snooping mrouter [*vlan vlan-id*]

Syntax Description

vlan vlan-id (Optional) Specifies a VLAN; the range is 1 to 1001 and 1006 to 4094.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping. When multicast VLAN registration (MVR) is enabled, the **show ip igmp snooping mrouter** command displays MVR multicast router information and IGMP snooping information. Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain output do not appear, but the lines that contain Output appear.

Examples

This is an example of output from the **show ip igmp snooping mrouter** command. It shows how to display multicast router ports on the controller:

```
Controller# show ip igmp snooping mrouter
Vlan      ports
----      -
 1        Gi2/0/1 (dynamic)
```

Related Commands

Command	Description
ip igmp snooping	Enables IGMP snooping.
show ip igmp snooping	Displays IGMP snooping configurations.
show ip igmp snooping groups	Displays the IGMP snooping multicast table.

show ip igmp snooping querier

To display the configuration and operation information for the IGMP querier configured on a controller, use the **show ip igmp snooping querier** user EXEC command.

show ip igmp snooping querier [**vlan** *vlan-id*] [**detail**]

Syntax Description	
vlan <i>vlan-id</i>	(Optional) Specifies a VLAN; the range is 1 to 1001 and 1006 to 4094.
detail	(Optional) Displays detailed IGMP querier information.

Command Modes	
	User EXEC
	Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use the **show ip igmp snooping querier** command to display the IGMP version and the IP address of a detected device, also called a querier, that sends IGMP query messages. A subnet can have multiple multicast routers but has only one IGMP querier. In a subnet running IGMPv2, one of the multicast routers is elected as the querier. The querier can be a Layer 3 controller.

The **show ip igmp snooping querier** command output also shows the VLAN and the interface on which the querier was detected. If the querier is the controller, the output shows the Port field as Router. If the querier is a router, the output shows the port number on which the querier is learned in the Port field.

The **show ip igmp snooping querier detail** user EXEC command is similar to the **show ip igmp snooping querier** command. However, the **show ip igmp snooping querier** command displays only the device IP address most recently detected by the controller querier.

The **show ip igmp snooping querier detail** command displays the device IP address most recently detected by the controller querier and this additional information:

- The elected IGMP querier in the VLAN
- The configuration and operational information pertaining to the controller querier (if any) that is configured in the VLAN

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain output do not appear, but the lines that contain Output appear.

Examples

This is an example of output from the **show ip igmp snooping querier** command:

```
Controller> show ip igmp snooping querier
Vlan      IP Address      IGMP Version      Port
-----
1         172.20.50.11   v3                 Gi1/0/1
2         172.20.40.20   v2                 Router
```

This is an example of output from the **show ip igmp snooping querier detail** command:

```
Controller> show ip igmp snooping querier detail
Vlan      IP Address      IGMP Version      Port
-----
1         1.1.1.1        v2                 Fa8/0/1
Global IGMP controller querier status
-----
admin state           : Enabled
admin version         : 2
source IP address     : 0.0.0.0
query-interval (sec)  : 60
max-response-time (sec) : 10
querier-timeout (sec) : 120
tcn query count       : 2
tcn query interval (sec) : 10
Vlan 1: IGMP controller querier status
-----
elected querier is 1.1.1.1          on port Fa8/0/1
-----
admin state           : Enabled
admin version         : 2
source IP address     : 10.1.1.65
query-interval (sec)  : 60
max-response-time (sec) : 10
querier-timeout (sec) : 120
tcn query count       : 2
tcn query interval (sec) : 10
operational state     : Non-Querier
operational version   : 2
tcn query pending count : 0
```

Related Commands

Command	Description
ip igmp snooping	Enables IGMP snooping.
ip igmp snooping querier	Globally enables the IGMP querier function.
show ip igmp snooping	Displays IGMP snooping configurations.

show ip igmp snooping wireless mcast-spi-count

To display the statistics of the number of multicast stateful packet inspections (SPIs) per multicast group ID (MGID) sent to the controller, use the **show ip igmp snooping wireless mcast-spi-count** command in privileged EXEC mode.

show ip igmp snooping wireless mcast-spi-count

This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines None

Examples

This is an example of output from the **show ip igmp snooping wireless mcast-spi-count** command:

```
Controller# show ip igmp snooping wireless mcast-spi-count
Stats for Mcast Client Add/Delete SPI Messages Sent to WCM
MGID      ADD MSGs      Del MSGs
-----
4160      1323          667
```

show ip igmp snooping wireless mgid

To display multicast group ID (MGID) mappings, use the **show ip igmp snooping wireless mgid** command in privileged EXEC mode.

show ip igmp snooping wireless mgid

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines None

Examples This is an example of output from the **show ip igmp snooping wireless mgid** command:

```

Controller# show ip igmp snooping wireless mgid

Total number of L2-MGIDs      = 0

Total number of MCAST MGIDs = 0

Wireless multicast is Enabled in the system
Vlan      bcast    nonip-mcast  mcast    mgid      Stdbdy Flags
1         Disabled  Disabled    Enabled   Disabled  0:0:1:0
25        Disabled  Disabled    Enabled   Disabled  0:0:1:0
34        Disabled  Disabled    Enabled   Disabled  0:0:1:0
200       Disabled  Disabled    Enabled   Disabled  0:0:1:0
1002      Enabled   Enabled     Enabled   Disabled  0:0:1:0
1003      Enabled   Enabled     Enabled   Disabled  0:0:1:0
1004      Enabled   Enabled     Enabled   Disabled  0:0:1:0
1005      Enabled   Enabled     Enabled   Disabled  0:0:1:0

Index  MGID                               (S, G, V)
-----

```

show mdns cache

To display mDNS cache information for the controller, use the **show mdns cache** privileged EXEC command.

show mdns cache [**interface** *type number* | **name** *record-name* [**type** *record-type*] | **type** *record-type*]

Syntax Description

interface <i>type-number</i>	(Optional) Specifies a particular interface type and number for which mDNS cache information is to be displayed.
name <i>record-name</i>	(Optional) Specifies a particular name for which mDNS cache information is to be displayed.
type <i>record-type</i>	(Optional) Specifies a particular type for which mDNS cache information is to be displayed.

Command Default

None

Command Modes

Privileged EXEC
User EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain output do not appear, but the lines that contain output appear.

Examples

This is an example of output from the **show mdns cache** command without any keywords:

```
Controller# show mdns cache
```

```

[<NAME>]                               [<TYPE>] [<CLASS>] [<TTL>/Remaining] [Accessed] [If-name] [Mac
Address] [<RR Record Data>]

  _airplay._tcp.local                    PTR      IN      4500/4455      0      V1121
b878.2e33.c7c5 CAMPUS APPLE TV1._airplay._tcp.local

CAMPUS APPLE TV1._airplay._tcp.local SRV      IN      120/75        2      V1121
b878.2e33.c7c5 CAMPUS-APPLE-TV1.local

CAMPUS-APPLE-TV1.local                  A        IN      120/75        2      V1121
b878.2e33.c7c5 121.1.0.254

CAMPUS APPLE TV1._airplay._tcp.local TXT      IN      4500/4455      2      V1121
b878.2e33.c7c5 (162) 'deviceid=B8:78:2E:33:C7:C6'
```

```

      'features=0x5a7ffff7''flags=0x4'
      'model=AppleT~'~
_ipp._tcp.local PTR IN 4500/4465 2 V12
2894.0fed.447f EPSON XP-400 Series._ipp._tcp.local
EPSON XP-400 Series._ipp._tcp.local SRV IN 120/85 2 V12
2894.0fed.447f EPSONC053AA.local
EPSONC053AA.local A IN 120/85 2 V12
2894.0fed.447f 121.1.0.251
EPSON XP-400 Series._ipp._tcp.local TXT IN 4500/4465 2 V12
2894.0fed.447f (384)'txtVers=1' N XP-400 Series' 'usbFG=EPSON''usb_MDL=XP~'~
_smb._tcp.local PTR IN 4500/4465 2 V12
2894.0fed.447f EPSON XP-400 Series._smb._tcp.local
EPSON XP-400 Series._smb._tcp.local SRV IN 120/85 2 V12
2894.0fed.447f EPSONC053AA.local
EPSON XP-400 Series._smb._tcp.local TXT IN 4500/4465 2 V12
2894.0fed.447f (1)'R2-Access1#

```

show mdns requests

To display information for outstanding mDNS requests, including record name and record type information, for the controller, use the **show mdns requests** privileged EXEC command.

show mdns requests [**detail** | **name** *record-name* | **type** *record-type* [**name** *record-name*]]

Syntax Description

detail	Displays detailed mDNS requests information.
name <i>record-name</i>	Displays detailed mDNS requests information based on name.
type <i>record-type</i>	Displays detailed mDNS requests information based on type.

Command Default

None

Command Modes

Privileged EXEC
User EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain output do not appear, but the lines that contain output appear.

Examples

This is an example of output from the **show mdns requests** command without any keywords:

```
Controller# show mdns requests
MDNS Outstanding Requests
=====
Request name :   _airplay._tcp.local
Request type  :   PTR
Request class :   IN
-----
Request name :   *.*
Request type  :   PTR
Request class :   IN
```

show mdns statistics

To display mDNS statistics for the controller, use the **show mdns statistics** privileged EXEC command.

show mdns statistics {**all** | **service-list** *list-name* | **service-policy** {**all** | **interface** *type-number* }}

Syntax Description

all	Displays the service policy, service list, and interface information.
service-list <i>list-name</i>	Displays the service list information.
service-policy	Displays the service policy information.
interface <i>type number</i>	Displays interface information.

Command Default

None

Command Modes

Privileged EXEC
User EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain output do not appear, but the lines that contain output appear.

Examples

This is an example of output from the **show mdns statistics all** command:

```
Controller# show mdns statistics all
mDNS Statistics
mDNS packets sent      : 0
mDNS packets received  : 0
mDNS packets dropped   : 0
mDNS cache memory in use: 64224(bytes)
```

show wireless multicast

To display wireless multicast information, use the **show wireless multicast** command in privileged EXEC mode.

show wireless multicast [**source** *source-ip* **group** *group-ip* **vlan** *vlan-id* | **group** *group-ip* **vlan** *vlan-id*]

Syntax Description

source <i>source-ip</i>	(Optional) Specifies the source IPv4 and IPv6 address of multicast traffic.
group <i>group-ip</i>	(Optional) Specifies the destination group and group IP of multicast traffic.
vlan <i>vlan-id</i>	Displays the client information on VLAN with the specific VLAN ID.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None

Examples

This example shows how to display the wireless multicast information:

```

Controller# show wireless multicast

Multicast                               : Enabled
AP Capwap Multicast                     : Unicast
Wireless Broadcast                       : Disabled
Wireless Multicast non-ip-mcast         : Disabled

Vlan      Non-ip-mcast      Broadcast      MGID
-----
1          Enabled         Enabled        Enabled
2          Enabled         Enabled        Disabled
94         Enabled         Enabled        Disabled

```

show wireless multicast group

To display the information of the wireless-multicast non-ip VLANs or the group, use the **show wireless multicast group** command in privileged EXEC mode.

show wireless multicast group {**summary** | *group-ip* **vlan** *vlan-id*}

Syntax Description

summary	Displays wireless-multicast non-ip group summary.
<i>group-ip</i>	Specifies the group IP address.
vlan <i>vlan-id</i>	Specifies the destination group IPv4/IPv6 Address of multicast traffic.

Command Default

None.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None.

Examples

This example shows how to display the wireless-multicast non-ip group summary.

```
Controller# show wireless multicast group summary
```

wireless multicast

To enable Ethernet multicast support, use the **wireless multicast** command.

wireless multicast [**non-ip** [**vlan** *vlan-id*]]

Syntax Description

non-ip	(Optional) Configures multicast non-IP support.
vlan <i>vlan-id</i>	(Optional) Specifies multicast non-IP for a VLAN. The interface number ranges between 1 and 4095.

Command Default

Disabled

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None

Examples

This example shows how to configure multicast non-IP VLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wireless multicast non-ip vlan 20
```

wireless mdns-bridging

To enable Ethernet mDNS support, use the **wireless mdns-bridging** command. To disable Ethernet mDNS support, use the **no** form of this command.

wireless mdns-bridging

no wireless mdns-bridging

This command has no keywords or arguments.

Command Default Ethernet mDNS support is enabled by default.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines Use this command only if you have enabled wireless multicast.

Examples This example shows how to enable Ethernet mDNS support:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wireless multicast
Controller(config)# wireless mdns-bridging
```



PART VII

Security

- [Security Commands, page 333](#)



Security Commands

- [aaa accounting dot1x, page 336](#)
- [aaa accounting identity, page 338](#)
- [aaa authentication dot1x, page 340](#)
- [aaa authorization network, page 341](#)
- [authentication host-mode, page 342](#)
- [authentication mac-move permit, page 344](#)
- [authentication priority, page 345](#)
- [authentication violation, page 348](#)
- [cisp enable, page 350](#)
- [clear errdisable interface vlan, page 352](#)
- [clear mac address-table, page 354](#)
- [deny \(MAC access-list configuration\), page 356](#)
- [device-role \(IPv6 snooping\), page 360](#)
- [device-role \(IPv6 nd inspection\), page 361](#)
- [dot1x critical \(global configuration\), page 362](#)
- [dot1x pae, page 363](#)
- [dot1x supplicant force-multicast, page 364](#)
- [dot1x test eapol-capable, page 365](#)
- [dot1x test timeout, page 366](#)
- [dot1x timeout, page 367](#)
- [epm access-control open, page 370](#)
- [ip admission, page 371](#)
- [ip admission name, page 372](#)
- [ip device tracking maximum, page 375](#)

- ip device tracking probe, page 376
- ip dhcp snooping database, page 377
- ip dhcp snooping information option format remote-id, page 379
- ip dhcp snooping verify no-relay-agent-address, page 380
- ip source binding, page 381
- ip verify source, page 382
- ipv6 snooping policy, page 384
- limit address-count, page 386
- mab request format attribute 32, page 387
- match (access-map configuration), page 389
- no authentication logging verbose, page 391
- no dot1x logging verbose, page 392
- no mab logging verbose, page 393
- permit (MAC access-list configuration), page 394
- protocol (IPv6 snooping), page 398
- security level (IPv6 snooping), page 399
- show aaa clients, page 400
- show aaa command handler, page 401
- show aaa local, page 402
- show aaa servers, page 404
- show aaa sessions, page 405
- show authentication sessions, page 406
- show cisp, page 409
- show dot1x, page 411
- show eap pac peer, page 413
- show ip dhcp snooping statistics, page 414
- show radius server-group, page 417
- show vlan access-map, page 419
- show vlan group, page 420
- show wireless wps rogue ap summary , page 421
- show wireless wps rogue client detailed, page 422
- show wireless wps wips statistics, page 423
- show wireless wps wips summary, page 424

- [tracking \(IPv6 snooping\), page 425](#)
- [trusted-port, page 427](#)
- [wireless security web-auth retries, page 428](#)
- [wireless dot11-padding, page 429](#)
- [wireless wps rogue rule, page 430](#)
- [wireless wps rogue detection, page 432](#)
- [vlan access-map, page 433](#)
- [vlan filter, page 435](#)
- [vlan group, page 437](#)

aaa accounting dot1x

To enable authentication, authorization, and accounting (AAA) accounting and to create method lists defining specific accounting methods on a per-line or per-interface basis for IEEE 802.1x sessions, use the **aaa accounting dot1x** command in global configuration mode. To disable IEEE 802.1x accounting, use the **no** form of this command.

```
aaa accounting dot1x {name | default } start-stop {broadcast group {name | radius | tacacs+} [group
{name | radius | tacacs+} ... ] | group {name | radius | tacacs+} [group {name | radius | tacacs+}... ]}
no aaa accounting dot1x {name | default }
```

Syntax Description

<i>name</i>	Name of a server group. This is optional when you enter it after the broadcast group and group keywords.
default	Specifies the accounting methods that follow as the default list for accounting services.
start-stop	Sends a start accounting notice at the beginning of a process and a stop accounting notice at the end of a process. The start accounting record is sent in the background. The requested user process begins regardless of whether or not the start accounting notice was received by the accounting server.
broadcast	Enables accounting records to be sent to multiple AAA servers and sends accounting records to the first server in each group. If the first server is unavailable, the switch uses the list of backup servers to identify the first server.
group	Specifies the server group to be used for accounting services. These are valid server group names: <ul style="list-style-type: none"> • <i>name</i> — Name of a server group. • radius — Lists of all RADIUS hosts. • tacacs+ — Lists of all TACACS+ hosts. <p>The group keyword is optional when you enter it after the broadcast group and group keywords. You can enter more than optional group keyword.</p>
radius	(Optional) Enables RADIUS accounting.
tacacs+	(Optional) Enables TACACS+ accounting.

Command Default

AAA accounting is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

This command requires access to a RADIUS server.

We recommend that you enter the **dot1x reauthentication** interface configuration command before configuring IEEE 802.1x RADIUS accounting on an interface.

Examples

This example shows how to configure IEEE 802.1x accounting:

```
Controller(config)# aaa new-model  
Controller(config)# aaa accounting dot1x default start-stop group radius
```

aaa accounting identity

To enable authentication, authorization, and accounting (AAA) accounting for IEEE 802.1x, MAC authentication bypass (MAB), and web authentication sessions, use the **aaa accounting identity** command in global configuration mode. To disable IEEE 802.1x accounting, use the **no** form of this command.

```
aaa accounting identity {name | default } start-stop {broadcast group {name | radius | tacacs+} [group {name | radius | tacacs+} ... ] | group {name | radius | tacacs+} [group {name | radius | tacacs+}... ]}
```

```
no aaa accounting identity {name | default }
```

Syntax Description

<i>name</i>	Name of a server group. This is optional when you enter it after the broadcast group and group keywords.
default	Uses the accounting methods that follow as the default list for accounting services.
start-stop	Sends a start accounting notice at the beginning of a process and a stop accounting notice at the end of a process. The start accounting record is sent in the background. The requested-user process begins regardless of whether or not the start accounting notice was received by the accounting server.
broadcast	Enables accounting records to be sent to multiple AAA servers and send accounting records to the first server in each group. If the first server is unavailable, the switch uses the list of backup servers to identify the first server.
group	Specifies the server group to be used for accounting services. These are valid server group names: <ul style="list-style-type: none"> • <i>name</i> — Name of a server group. • radius — Lists of all RADIUS hosts. • tacacs+ — Lists of all TACACS+ hosts. <p>The group keyword is optional when you enter it after the broadcast group and group keywords. You can enter more than optional group keyword.</p>
radius	(Optional) Enables RADIUS authorization.
tacacs+	(Optional) Enables TACACS+ accounting.

Command Default

AAA accounting is disabled.

Command Modes

Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines To enable AAA accounting identity, you need to enable policy mode. To enable policy mode, enter the **authentication display new-style** command in privileged EXEC mode.

Examples This example shows how to configure IEEE 802.1x accounting identity:

```
Controller# authentication display new-style
```

Please note that while you can revert to legacy style configuration at any time unless you have explicitly entered new-style configuration, the following caveats should be carefully read and understood.

- (1) If you save the config in this mode, it will be written to NVRAM in NEW-style config, and if you subsequently reload the router without reverting to legacy config and saving that, you will no longer be able to revert.
- (2) In this and legacy mode, Webauth is not IPv6-capable. It will only become IPv6-capable once you have entered new-style config manually, or have reloaded with config saved in 'authentication display new' mode.

```
Controller# configure terminal
```

```
Controller(config)# aaa accounting identity default start-stop group radius
```

aaa authentication dot1x

To specify the authentication, authorization, and accounting (AAA) method to use on ports complying with the IEEE 802.1x authentication, use the **aaa authentication dot1x** command in global configuration mode on the switch stack or on a standalone switch. To disable authentication, use the **no** form of this command.

aaa authentication dot1x {default} *method1*

no aaa authentication dot1x {default} *method1*

Syntax Description

default	The default method when a user logs in. Use the listed authentication method that follows this argument.
<i>method1</i>	Specifies the server authentication. Enter the group radius keywords to use the list of all RADIUS servers for authentication.
Note	Though other keywords are visible in the command-line help strings, only the default and group radius keywords are supported.

Command Default

No authentication is performed.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **method** argument identifies the method that the authentication algorithm tries in the specified sequence to validate the password provided by the client. The only method that is IEEE 802.1x-compliant is the **group radius** method, in which the client data is validated against a RADIUS authentication server.

If you specify **group radius**, you must configure the RADIUS server by entering the **radius-server host** global configuration command.

Use the **show running-config** privileged EXEC command to display the configured lists of authentication methods.

Examples

This example shows how to enable AAA and how to create an IEEE 802.1x-compliant authentication list. This authentication first tries to contact a RADIUS server. If this action returns an error, the user is not allowed access to the network.

```
Controller(config)# aaa new-model
Controller(config)# aaa authentication dot1x default group radius
```

aaa authorization network

To configure the switch to use user-RADIUS authorization for all network-related service requests, such as IEEE 802.1x VLAN assignment, use the **aaa authorization network** command in global configuration mode. To disable RADIUS user authorization, use the **no** form of this command

aaa authorization network default group radius

no aaa authorization network default

Syntax Description

default group radius	Use the list of all RADIUS hosts in the server group as the default authorization list.
-----------------------------	---

Command Default

Authorization is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use the **aaa authorization network default group radius** global configuration command to allow the switch to download IEEE 802.1x authorization parameters from the RADIUS servers in the default authorization list. The authorization parameters are used by features such as VLAN assignment to get parameters from the RADIUS servers.

Use the **show running-config** privileged EXEC command to display the configured lists of authorization methods.

Examples

This example shows how to configure the switch for user RADIUS authorization for all network-related service requests:

```
Controller(config)# aaa authorization network default group radius
```

authentication host-mode

To set the authorization manager mode on a port, use the **authentication host-mode** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

authentication host-mode {**multi-auth** | **multi-domain** | **multi-host** | **single-host**}

no authentication host-mode

Syntax Description

multi-auth	Enables multiple-authorization mode (multi-auth mode) on the port.
multi-domain	Enables multiple-domain mode on the port.
multi-host	Enables multiple-host mode on the port.
single-host	Enables single-host mode on the port.

Command Default

Single host mode is enabled.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Single-host mode should be configured if only one data host is connected. Do not connect a voice device to authenticate on a single-host port. Voice device authorization fails if no voice VLAN is configured on the port.

Multi-domain mode should be configured if data host is connected through an IP phone to the port. Multi-domain mode should be configured if the voice device needs to be authenticated.

Multi-auth mode should be configured to allow devices behind a hub to obtain secured port access through individual authentication. Only one voice device can be authenticated in this mode if a voice VLAN is configured.

Multi-host mode also offers port access for multiple hosts behind a hub, but multi-host mode gives unrestricted port access to the devices after the first user gets authenticated.

Examples

This example shows how to enable multi-auth mode on a port:

```
Controller(config-if)# authentication host-mode multi-auth
```

This example shows how to enable multi-domain mode on a port:

```
Controller(config-if)# authentication host-mode multi-domain
```

This example shows how to enable multi-host mode on a port:

```
Controller(config-if)# authentication host-mode multi-host
```

This example shows how to enable single-host mode on a port:

```
Controller(config-if)# authentication host-mode single-host
```

You can verify your settings by entering the **show authentication sessions interface *interface* details** privileged EXEC command.

authentication mac-move permit

To enable MAC move on a controller, use the **authentication mac-move permit** command in global configuration mode. To disable MAC move, use the **no** form of this command.

authentication mac-move permit

no authentication mac-move permit

Syntax Description This command has no arguments or keywords.

Command Default MAC move is enabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines The command enables authenticated hosts to move between ports on a controller. For example, if there is a device between an authenticated host and port, and that host moves to another port, the authentication session is deleted from the first port, and the host is reauthenticated on the new port.

If MAC move is disabled, and an authenticated host moves to another port, it is not reauthenticated, and a violation error occurs.

Examples This example shows how to enable MAC move on a controller:

```
Controller(config)# authentication mac-move permit
```

authentication priority

To add an authentication method to the port-priority list, use the **authentication priority** command in interface configuration mode. To return to the default, use the **no** form of this command.

authentication priority [**dot1x** | **mab**] {**webauth**}

no authentication priority [**dot1x** | **mab**] {**webauth**}

Syntax Description

dot1x	(Optional) Adds 802.1x to the order of authentication methods.
mab	(Optional) Adds MAC authentication bypass (MAB) to the order of authentication methods.
webauth	Adds web authentication to the order of authentication methods.

Command Default

The default priority is 802.1x authentication, followed by MAC authentication bypass and web authentication.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Ordering sets the order of methods that the switch attempts when trying to authenticate a new device is connected to a port.

When configuring multiple fallback methods on a port, set web authentication (webauth) last.

Assigning priorities to different authentication methods allows a higher-priority method to interrupt an in-progress authentication method with a lower priority.



Note

If a client is already authenticated, it might be reauthenticated if an interruption from a higher-priority method occurs.

The default priority of an authentication method is equivalent to its position in execution-list order: 802.1x authentication, MAC authentication bypass (MAB), and web authentication. Use the **dot1x**, **mab**, and **webauth** keywords to change this default order.

Examples

This example shows how to set 802.1x as the first authentication method and web authentication as the second authentication method:

```
Controller(config-if) # authentication priority dotx webauth
```

This example shows how to set MAB as the first authentication method and web authentication as the second authentication method:

```
Controller(config-if) # authentication priority mab webauth
```

Related Commands

Command	Description
authentication control-direction	Configures the port mode as unidirectional or bidirectional.
authentication event fail	Specifies how the Auth Manager handles authentication failures as a result of unrecognized user credentials.
authentication event no-response action	Specifies how the Auth Manager handles authentication failures as a result of a nonresponsive host.
authentication event server alive action reinitialize	Reinitializes an authorized Auth Manager session when a previously unreachable authentication, authorization, and accounting server becomes available.
authentication event server dead action authorize	Authorizes Auth Manager sessions when the authentication, authorization, and accounting server becomes unreachable.
authentication fallback	Enables a web authentication fallback method.
authentication host-mode	Allows hosts to gain access to a controlled port.
authentication open	Enables open access on a port.
authentication order	Specifies the order in which the Auth Manager attempts to authenticate a client on a port.
authentication periodic	Enables automatic reauthentication on a port.
authentication port-control	Configures the authorization state of a controlled port.
authentication timer inactivity	Configures the time after which an inactive Auth Manager session is terminated.
authentication timer reauthenticate	Specifies the period of time between which the Auth Manager attempts to reauthenticate authorized ports.

Command	Description
authentication timer restart	Specifies the period of time after which the Auth Manager attempts to authenticate an unauthorized port.
authentication violation	Specifies the action to be taken when a security violation occurs on a port.
mab	Enables MAC authentication bypass on a port.
show authentication registrations	Displays information about the authentication methods that are registered with the Auth Manager.
show authentication sessions	Displays information about current Auth Manager sessions.
show authentication sessions interface	Displays information about the Auth Manager for a given interface.

authentication violation

To configure the violation modes that occur when a new device connects to a port or when a new device connects to a port after the maximum number of devices are connected to that port, use the **authentication violation** command in interface configuration mode.

authentication violation { **protect**|**replace**|**restrict**|**shutdown** }

no authentication violation { **protect**|**replace**|**restrict**|**shutdown** }

Syntax Description

protect	Drops unexpected incoming MAC addresses. No syslog errors are generated.
replace	Removes the current session and initiates authentication with the new host.
restrict	Generates a syslog error when a violation error occurs.
shutdown	Error-disables the port or the virtual port on which an unexpected MAC address occurs.

Command Default

Authentication violation shutdown mode is enabled.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use the **authentication violation** command to specify the action to be taken when a security violation occurs on a port.

Examples

This example shows how to configure an IEEE 802.1x-enabled port as error-disabled and to shut down when a new device connects it:

```
Controller(config-if) # authentication violation shutdown
```

This example shows how to configure an 802.1x-enabled port to generate a system error message and to change the port to restricted mode when a new device connects to it:

```
Controller(config-if) # authentication violation restrict
```

This example shows how to configure an 802.1x-enabled port to ignore a new device when it connects to the port:

```
Controller(config-if)# authentication violation protect
```

This example shows how to configure an 802.1x-enabled port to remove the current session and initiate authentication with a new device when it connects to the port:

```
Controller(config-if)# authentication violation replace
```

You can verify your settings by entering the **show authentication** privileged EXEC command.

cisp enable

To enable Client Information Signaling Protocol (CISP) on a switch so that it acts as an authenticator to a supplicant switch, use the **cisp enable** global configuration command.

cisp enable

no cisp enable

Syntax Description This command has no arguments or keywords.

Command Default No default behavior or values.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines The link between the authenticator and supplicant switch is a trunk. When you enable VTP on both switches, the VTP domain name must be the same, and the VTP mode must be server.

To avoid the MD5 checksum mismatch error when you configure VTP mode, verify that:

- VLANs are not configured on two different switches, which can be caused by two VTP servers in the same domain.
- Both switches have different configuration revision numbers.

Examples This example shows how to enable CISP:

```
Controller(config)# cisp enable
```

Related Commands

Command	Description
dot1x credentials <i>profile</i>	Configures a profile on a supplicant switch.
dot1x supplicant force-multicast	Forces 802.1X supplicant to send multicast packets.
dot1x supplicant controlled transient	Configures controlled access by 802.1X supplicant.
show cisp	Displays CISP information for a specified interface.

clear errdisable interface vlan

To reenable a VLAN that was error-disabled, use the **clear errdisable interface** command in privileged EXEC mode.

clear errdisable interface *interface-id* **vlan** [*vlan-list*]

Syntax Description

<i>interface-id</i>	Specifies an interface.
<i>vlan list</i>	(Optional) Specifies a list of VLANs to be reenabled. If a VLAN list is not specified, then all VLANs are reenabled.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can reenable a port by using the **shutdown** and **no shutdown** interface configuration commands, or you can clear error-disable for VLANs by using the **clear errdisable** interface command.

Examples

This example shows how to reenable all VLANs that were error-disabled on Gigabit Ethernet port 4/0/2:

```
Controller# clear errdisable interface gigabitethernet4/0/2 vlan
```

Related Commands

Command	Description
errdisable detect cause	Enables error-disabled detection for a specific cause or all causes.
errdisable recovery	Configures the recovery mechanism variables.
show errdisable detect	Displays error-disabled detection status.
show errdisable recovery	Displays error-disabled recovery timer information.

Command	Description
show interfaces status err-disabled	Displays interface status of a list of interfaces in error-disabled state.

clear mac address-table

To delete from the MAC address table a specific dynamic address, all dynamic addresses on a particular interface, all dynamic addresses on stack members, or all dynamic addresses on a particular VLAN, use the **clear mac address-table** command in privileged EXEC mode. This command also clears the MAC address notification global counters.

clear mac address-table {**dynamic** [**address** *mac-addr* | **interface** *interface-id* | **vlan** *vlan-id*] | **move update** | **notification**}

Syntax Description

dynamic	Deletes all dynamic MAC addresses.
address <i>mac-addr</i>	(Optional) Deletes the specified dynamic MAC address.
interface <i>interface-id</i>	(Optional) Deletes all dynamic MAC addresses on the specified physical port or port channel.
vlan <i>vlan-id</i>	(Optional) Deletes all dynamic MAC addresses for the specified VLAN. The range is 1 to 4094.
move update	Clears the MAC address table move-update counters.
notification	Clears the notifications in the history table and reset the counters.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can verify that the information was deleted by entering the **show mac address-table** privileged EXEC command.

Examples

This example shows how to remove a specific MAC address from the dynamic address table:

```
Controller# clear mac address-table dynamic address 0008.0070.0007
```

Related Commands

Command	Description
mac address-table notification	Enables the MAC address notification feature.
mac address-table move update {receive transmit}	Configures MAC address-table move update on the switch.
show mac address-table	Displays the MAC address table static and dynamic entries.
show mac address-table move update	Displays the MAC address-table move update information on the switch.
show mac address-table notification	Displays the MAC address notification settings for all interfaces or on the specified interface when the interface keyword is appended.
snmp trap mac-notification change	Enables the SNMP MAC address notification trap on a specific interface.

deny (MAC access-list configuration)

To prevent non-IP traffic from being forwarded if the conditions are matched, use the **deny** MAC access-list configuration command on the switch stack or on a standalone switch. To remove a deny condition from the named MAC access list, use the **no** form of this command.

```
deny {any | host src-MAC-addr | src-MAC-addr mask} {any | host dst-MAC-addr | dst-MAC-addr mask}
[type mask | aarp | amber | appletalk | dec-spanning | decnet-iv | diagnostic | dsm | etype-6000 | etype-8042
| lat | lavr-sca | lsap lsap mask | mop-console | mop-dump | msdos | mumps | netbios | vines-echo | vines-ip
| xns-idp][cos cos]
```

```
no deny {any | host src-MAC-addr | src-MAC-addr mask} {any | host dst-MAC-addr | dst-MAC-addr mask}
[type mask | aarp | amber | appletalk | dec-spanning | decnet-iv | diagnostic | dsm | etype-6000 | etype-8042
| lat | lavr-sca | lsap lsap mask | mop-console | mop-dump | msdos | mumps | netbios | vines-echo | vines-ip
| xns-idp][cos cos]
```

Syntax Description

any	Denies any source or destination MAC address.
host <i>src-MAC-addr</i> <i>src-MAC-addr mask</i>	Defines a host MAC address and optional subnet mask. If the source address for a packet matches the defined address, non-IP traffic from that address is denied.
host <i>dst-MAC-addr</i> <i>dst-MAC-addr mask</i>	Defines a destination MAC address and optional subnet mask. If the destination address for a packet matches the defined address, non-IP traffic to that address is denied.
<i>type mask</i>	(Optional) Specifies the EtherType number of a packet with Ethernet II or SNAP encapsulation to identify the protocol of the packet. The type is 0 to 65535, specified in hexadecimal. The mask is a mask of don't care bits applied to the EtherType before testing for a match.
aarp	(Optional) Specifies EtherType AppleTalk Address Resolution Protocol that maps a data-link address to a network address.
amber	(Optional) Specifies EtherType DEC-Amber.
appletalk	(Optional) Specifies EtherType AppleTalk/EtherTalk.
dec-spanning	(Optional) Specifies EtherType Digital Equipment Corporation (DEC) spanning tree.
decnet-iv	(Optional) Specifies EtherType DECnet Phase IV protocol.
diagnostic	(Optional) Specifies EtherType DEC-Diagnostic.

dsm	(Optional) Specifies EtherType DEC-DSM.
etype-6000	(Optional) Specifies EtherType 0x6000.
etype-8042	(Optional) Specifies EtherType 0x8042.
lat	(Optional) Specifies EtherType DEC-LAT.
lavc-sca	(Optional) Specifies EtherType DEC-LAVC-SCA.
lsap <i>lsap-number mask</i>	(Optional) Specifies the LSAP number (0 to 65535) of a packet with 802.2 encapsulation to identify the protocol of the packet. <i>mask</i> is a mask of don't care bits applied to the LSAP number before testing for a match.
mop-console	(Optional) Specifies EtherType DEC-MOP Remote Console.
mop-dump	(Optional) Specifies EtherType DEC-MOP Dump.
msdos	(Optional) Specifies EtherType DEC-MSDOS.
mumps	(Optional) Specifies EtherType DEC-MUMPS.
netbios	(Optional) Specifies EtherType DEC- Network Basic Input/Output System (NetBIOS).
vines-echo	(Optional) Specifies EtherType Virtual Integrated Network Service (VINES) Echo from Banyan Systems.
vines-ip	(Optional) Specifies EtherType VINES IP.
xns-idp	(Optional) Specifies EtherType Xerox Network Systems (XNS) protocol suite (0 to 65535), an arbitrary EtherType in decimal, hexadecimal, or octal.
cos <i>cos</i>	(Optional) Specifies a class of service (CoS) number from 0 to 7 to set priority. Filtering on CoS can be performed only in hardware. A warning message reminds the user if the cos option is configured.

Command Default

This command has no defaults. However, the default action for a MAC-named ACL is to deny.

Command Modes

Mac-access list configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You enter MAC-access list configuration mode by using the **mac access-list extended** global configuration command.

If you use the **host** keyword, you cannot enter an address mask; if you do not use the **host** keyword, you must enter an address mask.

When an access control entry (ACE) is added to an access control list, an implied **deny-any-any** condition exists at the end of the list. That is, if there are no matches, the packets are denied. However, before the first ACE is added, the list permits all packets.

To filter IPX traffic, you use the *type mask* or **lsap lsap mask** keywords, depending on the type of IPX encapsulation being used. Filter criteria for IPX encapsulation types as specified in Novell terminology and Cisco IOS terminology are listed in the table.

Table 12: IPX Filtering Criteria

IPX Encapsulation Type		Filter Criterion
Cisco IOS Name	Novel Name	
arpa	Ethernet II	EtherType 0x8137
snap	Ethernet-snap	EtherType 0x8137
sap	Ethernet 802.2	LSAP 0xE0E0
novell-ether	Ethernet 802.3	LSAP 0xFFFF

Examples

This example shows how to define the named MAC extended access list to deny NETBIOS traffic from any source to MAC address 00c0.00a0.03fa. Traffic matching this list is denied.

```
Controller(config-ext-macl)# deny any host 00c0.00a0.03fa netbios.
```

This example shows how to remove the deny condition from the named MAC extended access list:

```
Controller(config-ext-macl)# no deny any 00c0.00a0.03fa 0000.0000.0000 netbios.
```

This example denies all packets with EtherType 0x4321:

```
Controller(config-ext-macl)# deny any any 0x4321 0
```

You can verify your settings by entering the **show access-lists** privileged EXEC command.

Related Commands

Command	Description
mac access-list extended	Creates an access list based on MAC addresses for non-IP traffic.
permit	Permits from the MAC access-list configuration. Permits non-IP traffic to be forwarded if conditions are matched.
show access-lists	Displays access control lists configured on a switch.

device-role (IPv6 snooping)

To specify the role of the device attached to the port, use the **device-role** command in IPv6 snooping configuration mode.

device-role {**node** | **switch**}

Syntax Description

node	Sets the role of the attached device to node.
switch	Sets the role of the attached device to switch.

Command Default

The device role is node.

Command Modes

IPv6 snooping configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **device-role** command specifies the role of the device attached to the port. By default, the device role is node.

The **switch** keyword indicates that the remote device is a switch and that the local switch is now operating in multiswitch mode; binding entries learned from the port will be marked with trunk_port preference level. If the port is configured as a trust-port, binding entries will be marked with trunk_trusted_port preference level.

Examples

This example shows how to define an IPv6 snooping policy name as policy1, place the device in IPv6 snooping configuration mode, and configure the device as the node:

```
Controller(config)# ipv6 snooping policy policy1
Controller(config-ipv6-snooping)# device-role node
```

device-role (IPv6 nd inspection)

To specify the role of the device attached to the port, use the **device-role** command in neighbor discovery (ND) inspection policy configuration mode.

device-role {**host** | **monitor** | **router** | **switch**}

Syntax Description

host	Sets the role of the attached device to host.
monitor	Sets the role of the attached device to monitor.
router	Sets the role of the attached device to router.
switch	Sets the role of the attached device to switch.

Command Default

The device role is host.

Command Modes

ND inspection policy configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **device-role** command specifies the role of the device attached to the port. By default, the device role is host, and therefore all the inbound router advertisement and redirect messages are blocked. If the device role is enabled using the **router** keyword, all messages (router solicitation [RS], router advertisement [RA], or redirect) are allowed on this port.

When the **router** or **monitor** keyword is used, the multicast RS messages are bridged on the port, regardless of whether limited broadcast is enabled. However, the monitor keyword does not allow inbound RA or redirect messages. When the monitor keyword is used, devices that need these messages will receive them.

The **switch** keyword indicates that the remote device is a switch and that the local switch is now operating in multiswitch mode; binding entries learned from the port will be marked with trunk_port preference level. If the port is configured as a trust-port, binding entries will be marked with trunk_trusted_port preference level.

Examples

The following example defines a Neighbor Discovery Protocol (NDP) policy name as policy1, places the device in ND inspection policy configuration mode, and configures the device as the host:

```
Controller(config)# ipv6 nd inspection policy policy1
Controller(config-nd-inspection)# device-role host
```

dot1x critical (global configuration)

To configure the IEEE 802.1X critical authentication parameters, use the **dot1x critical** command in global configuration mode.

dot1x critical eapol

Syntax Description

eapol	Specifies that the switch send an EAPOL-Success message when the switch successfully authenticates the critical port.
--------------	---

Command Default

eapol is disabled

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to specify that the switch sends an EAPOL-Success message when the switch successfully authenticates the critical port:

```
Controller(config)# dot1x critical eapol
```

dot1x pae

To set the Port Access Entity (PAE) type, use the **dot1x pae** command in interface configuration mode. To disable the PAE type that was set, use the **no** form of this command.

dot1x pae {supplicant | authenticator}

no dot1x pae {supplicant | authenticator}

Syntax Description

supplicant	The interface acts only as a supplicant and will not respond to messages that are meant for an authenticator.
authenticator	The interface acts only as an authenticator and will not respond to any messages meant for a supplicant.

Command Default

PAE type is not set.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use the **no dot1x pae** interface configuration command to disable IEEE 802.1x authentication on the port.

When you configure IEEE 802.1x authentication on a port, such as by entering the **dot1x port-control** interface configuration command, the switch automatically configures the port as an IEEE 802.1x authenticator. After the **no dot1x pae** interface configuration command is entered, the Authenticator PAE operation is disabled.

Examples

The following example shows that the interface has been set to act as a supplicant:

```
Controller(config)# interface g1/0/3
Controller(config-if)# dot1x pae supplicant
```

dot1x supplicant force-multicast

To force a supplicant switch to send only multicast Extensible Authentication Protocol over LAN (EAPOL) packets whenever it receives multicast or unicast EAPOL packets, use the **dot1x supplicant force-multicast** command in global configuration mode. To return to the default setting, use the **no** form of this command.

dot1x supplicant force-multicast

no dot1x supplicant force-multicast

Syntax Description

This command has no arguments or keywords.

Command Default

The supplicant switch sends unicast EAPOL packets when it receives unicast EAPOL packets. Similarly, it sends multicast EAPOL packets when it receives multicast EAPOL packets.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Enable this command on the supplicant switch for Network Edge Access Topology (NEAT) to work in all host modes.

Examples

This example shows how force a supplicant switch to send multicast EAPOL packets to the authenticator switch:

```
Controller(config)# dot1x supplicant force-multicast
```

Related Commands

Command	Description
cisp enable	Enable Client Information Signalling Protocol (CISP) on a switch so that it acts as an authenticator to a supplicant switch.
dot1x credentials	Configure the 802.1x supplicant credentials on the port.
dot1x pae supplicant	Configure an interface to act only as a supplicant.

dot1x test eapol-capable

To monitor IEEE 802.1x activity on all the switch ports and to display information about the devices that are connected to the ports that support IEEE 802.1x, use the **dot1x test eapol-capable** command in privileged EXEC mode on the switch stack or on a standalone switch.

dot1x test eapol-capable [**interface** *interface-id*]

Syntax Description

interface <i>interface-id</i>	(Optional) Port to be queried.
--------------------------------------	--------------------------------

Command Default

There is no default setting.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use this command to test the IEEE 802.1x capability of the devices connected to all ports or to specific ports on a switch.

There is not a no form of this command.

Examples

This example shows how to enable the IEEE 802.1x readiness check on a switch to query a port. It also shows the response received from the queried port verifying that the device connected to it is IEEE 802.1x-capable:

```
Controller# dot1x test eapol-capable interface gigabitethernet1/0/13
```

```
DOT1X_PORT_EAPOL_CAPABLE:DOT1X: MAC 00-01-02-4b-f1-a3 on gigabitethernet1/0/13 is EAPOL capable
```

Related Commands

Command	Description
dot1x test timeout <i>timeout</i>	Configures the timeout used to wait for EAPOL response to an IEEE 802.1x readiness query.

dot1x test timeout

To configure the timeout used to wait for EAPOL response from a port being queried for IEEE 802.1x readiness, use the **dot1x test timeout** command in global configuration mode on the switch stack or on a standalone switch.

dot1x test timeout *timeout*

Syntax Description

timeout

Time in seconds to wait for an EAPOL response. The range is from 1 to 65535 seconds.

Command Default

The default setting is 10 seconds.

Command Modes

Global configuration

Command History

Release

Cisco IOS XE 3.2SE

Modification

This command was introduced.

Usage Guidelines

Use this command to configure the timeout used to wait for EAPOL response.

There is not a no form of this command.

Examples

This example shows how to configure the switch to wait 27 seconds for an EAPOL response:

```
Controller# dot1x test timeout 27
```

You can verify the timeout configuration status by entering the **show run** privileged EXEC command.

Related Commands

Command	Description
dot1x test eapol-capable [interface interface-id]	Checks for IEEE 802.1x readiness on devices connected to all or to specified IEEE 802.1x-capable ports.

dot1x timeout

To configure the value for retry timeouts, use the **dot1x timeout** command in global configuration or interface configuration mode. To return to the default value for retry timeouts, use the **no** form of this command.

dot1x timeout {**auth-period** *seconds* | **held-period** *seconds* | **quiet-period** *seconds* | **ratelimit-period** *seconds* | **server-timeout** *seconds* | **start-period** *seconds* | **supp-timeout** *seconds* | **tx-period** *seconds*}

Syntax Description

auth-period <i>seconds</i>	Configures the time, in seconds for which a supplicant will stay in the HELD state (that is, the length of time it will wait before trying to send the credentials again after a failed attempt). The range is from 1 to 65535. The default is 30.
held-period <i>seconds</i>	Configures the time, in seconds for which a supplicant will stay in the HELD state (that is, the length of time it will wait before trying to send the credentials again after a failed attempt). The range is from 1 to 65535. The default is 60.
quiet-period <i>seconds</i>	Configures the time, in seconds, that the authenticator (server) remains quiet (in the HELD state) following a failed authentication exchange before trying to reauthenticate the client. The range is from 1 to 65535. The default is 60.
ratelimit-period <i>seconds</i>	Throttles the EAP-START packets that are sent from misbehaving client PCs (for example, PCs that send EAP-START packets that result in the wasting of switch processing power). <ul style="list-style-type: none"> • The authenticator ignores EAPOL-Start packets from clients that have successfully authenticated for the rate-limit period duration. • The range is from 1 to 65535. By default, rate limiting is disabled.
server-timeout <i>seconds</i>	Configures the interval, in seconds, between two successive EAPOL-Start frames when they are being retransmitted. <ul style="list-style-type: none"> • The range is from 1 to 65535. The default is 30. <p>If the server does not send a response to an 802.1X packet within the specified period, the packet is sent again.</p>
start-period <i>seconds</i>	Configures the interval, in seconds, between two successive EAPOL-Start frames when they are being retransmitted. The range is from 1 to 65535. The default is 30.

supp-timeout <i>seconds</i>	Sets the authenticator-to-supplicant retransmission time for all EAP messages other than EAP Request ID. The range is from 1 to 65535. The default is 30.
tx-period <i>seconds</i>	Configures the number of seconds between retransmission of EAP request ID packets (assuming that no response is received) to the client. <ul style="list-style-type: none"> • The range is from 1 to 65535. The default is 30. • If an 802.1X packet is sent to the supplicant and the supplicant does not send a response after the retry period, the packet will be sent again.

Command Default

Periodic reauthentication and periodic rate-limiting are done.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You should change the default value of this command only to adjust for unusual circumstances such as unreliable links or specific behavioral problems with certain clients and authentication servers.

The **dot1x timeout reauth-period** interface configuration command affects the behavior of the switch only if you have enabled periodic re-authentication by using the **dot1x reauthentication** interface configuration command.

During the quiet period, the switch does not accept or initiate any authentication requests. If you want to provide a faster response time to the user, enter a number smaller than the default.

When the **ratelimit-period** is set to 0 (the default), the switch does not ignore EAPOL packets from clients that have been successfully authenticated and forwards them to the RADIUS server.

Examples

The following example shows that various 802.1X retransmission and timeout periods have been set:

```

Controller(config)# configure terminal
Controller(config)# interface g1/0/3
Controller(config-if)# dot1x port-control auto
Controller(config-if)# dot1x timeout auth-period 2000
Controller(config-if)# dot1x timeout held-period 2400
Controller(config-if)# dot1x timeout quiet-period 600
Controller(config-if)# dot1x timeout start-period 90
Controller(config-if)# dot1x timeout supp-timeout 300
Controller(config-if)# dot1x timeout tx-period 60

```

```
Controller(config-if)# dot1x timeout server-timeout 60
```

epm access-control open

To configure an open directive for ports that do not have an access control list (ACL) configured, use the **epm access-control open** command in global configuration mode. To disable the open directive, use the **no** form of this command.

epm access-control open
no epm access-control open

Syntax Description This command has no arguments or keywords.

Command Default The default directive applies.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Use this command to configure an open directive that allows hosts without an authorization policy to access ports configured with a static ACL. If you do not configure this command, the port applies the policies of the configured ACL to the traffic. If no static ACL is configured on a port, both the default and open directives allow access to the port.

You can verify your settings by entering the **show running-config** privileged EXEC command.

Examples This example shows how to configure an open directive.

```
Controller(config)# epm access-control open
```

Related Commands

Command	Description
show running-config	Displays the contents of the current running configuration file.

ip admission

To enable web authentication, use the **ip admission** command in interface configuration mode. You can also use this command in fallback-profile configuration mode. To disable web authentication, use the **no** form of this command.

ip admission *rule*

no ip admission *rule*

Syntax Description

<i>rule</i>	IP admission rule name.
-------------	-------------------------

Command Default

Web authentication is disabled.

Command Modes

Interface configuration
Fallback-profile configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **ip admission** command applies a web authentication rule to a switch port.

Examples

This example shows how to apply a web authentication rule to a switchport:

```
Controller# configure terminal
Controller(config)# interface gigabitethernet1/0/1
Controller(config-if)# ip admission rule1
```

This example shows how to apply a web authentication rule to a fallback profile for use on an IEEE 802.1x enabled switch port.

```
Controller# configure terminal
Controller(config)# fallback profile profile1
Controller(config-fallback-profile)# ip admission rule1
```

ip admission name

To enable web authentication, use the **ip admission name** command in global configuration mode. To disable web authentication, use the **no** form of this command.

ip admission name *name* {**consent** | **proxy http**} [**absolute timer** *minutes* | **inactivity-time** *minutes* | **list** {*acl* | *acl-name*} | **service-policy type tag** *service-policy-name*]

no ip admission name *name* {**consent** | **proxy http**} [**absolute timer** *minutes* | **inactivity-time** *minutes* | **list** {*acl* | *acl-name*} | **service-policy type tag** *service-policy-name*]

Syntax Description

<i>name</i>	Name of network admission control rule.
consent	Associates an authentication proxy consent web page with the IP admission rule specified using the <i>admission-name</i> argument.
proxy http	Configures web authentication custom page.
absolute-timer <i>minutes</i>	(Optional) Elapsed time, in minutes, before the external server times out.
inactivity-time <i>minutes</i>	(Optional) Elapsed time, in minutes, before the external file server is deemed unreachable.
list	(Optional) Associates the named rule with an access control list (ACL).
<i>acl</i>	Applies a standard, extended list to a named admission control rule. The value ranges from 1 through 199, or from 1300 through 2699 for expanded range.
<i>acl-name</i>	Applies a named access list to a named admission control rule.
service-policy type tag	(Optional) A control plane service policy is to be configured.
<i>service-policy-name</i>	Control plane tag service policy that is configured using the policy-map type control tag <i>policyname</i> command, keyword, and argument. This policy map is used to apply the actions on the host when a tag is received.

Command Default

Web authentication is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines The **ip admission name** command globally enables web authentication on a switch. After you enable web authentication on a switch, use the **ip access-group in** and **ip admission web-rule** interface configuration commands to enable web authentication on a specific interface.

Examples This example shows how to configure only web authentication on a switch port:

```
Controller# configure terminal
Controller(config) ip admission name http-rule proxy http
Controller(config) # interface gigabitethernet1/0/1
Controller(config-if) # ip access-group 101 in
Controller(config-if) # ip admission rule
Controller(config-if) # end
```

This example shows how to configure IEEE 802.1x authentication with web authentication as a fallback mechanism on a switch port:

```
Controller# configure terminal
Controller(config) # ip admission name rule2 proxy http
Controller(config) # fallback profile profile1
Controller(config) # ip access group 101 in
Controller(config) # ip admission name rule2
Controller(config) # interface gigabitethernet1/0/1
Controller(config-if) # dot1x port-control auto
Controller(config-if) # dot1x fallback profile1
Controller(config-if) # end
```

Related Commands

Command	Description
dot1x fallback	Configures a port to use web authentication as a fallback method for clients that do not support IEEE 802.1x authentication.
fallback profile	Creates a web authentication fallback profile.
ip admission	Enables web authentication on a port.
show authentication sessions interface <i>interface</i> detail	Displays information about the web authentication session status.

Command	Description
show ip admission	Displays information about NAC cached entries or the NAC configuration.

ip device tracking maximum

To configure IP device tracking parameters on a Layer 2 access port, use the **ip device tracking maximum** command in interface configuration mode. To remove the maximum value, use the **no** form of the command.

ip device tracking maximum *number*

no ip device tracking maximum

Syntax Description	<i>number</i>	Number of bindings created in the IP device tracking table for a port. The range is 0 (disabled) to 65535.
Command Default	None	
Command Modes	Interface configuration mode	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

To remove the maximum value, use the **no ip device tracking maximum** command.

To disable IP device tracking, use the **ip device tracking maximum 0** command.

Examples

This example shows how to configure IP device tracking parameters on a Layer 2 access port:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# ip device tracking
Controller(config)# interface gigabitethernet1/0/3
Controller(config-if)# switchport mode access
Controller(config-if)# switchport access vlan 1
Controller(config-if)# ip device tracking maximum 5
Controller(config-if)# switchport port-security
Controller(config-if)# switchport port-security maximum 5
Controller(config-if)# end
```

ip device tracking probe

To configure the IP device tracking table for Address Resolution Protocol (ARP) probes, use the **ip device tracking probe** command in global configuration mode. To disable ARP probes, use the **no** form of this command.

ip device tracking probe {*count number*| *delay seconds*| *interval seconds*| *use-svi address*}

no ip device tracking probe {*count number*| *delay seconds*| *interval seconds*| *use-svi address*}

Syntax Description

count <i>number</i>	Sets the number of times that the controller sends the ARP probe. The range is from 1 to 255.
delay <i>seconds</i>	Sets the number of seconds that the controller waits before sending the ARP probe. The range is from 1 to 120.
interval <i>seconds</i>	Sets the number of seconds that the controller waits for a response before resending the ARP probe. The range is from 30 to 1814400 seconds.
use-svi	Uses the switch virtual interface (SVI) IP address as source of ARP probes.

Command Default

The count number is 3.

There is no delay.

The interval is 30 seconds.

The ARP probe default source IP address is the Layer 3 interface and 0.0.0.0 for switchports.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use the **use-svi** keyword to configure the IP device tracking table to use the SVI IP address for ARP probes in cases when the default source IP address 0.0.0.0 for switch ports is used and the ARP probes drop.

Examples

This example shows how to set SVI as the source for ARP probes:

```
Controller(config)# ip device tracking probe use-svi
```

ip dhcp snooping database

To configure the Dynamic Host Configuration Protocol (DHCP)-snooping database, use the **ip dhcp snooping database** command in global configuration mode. To disable the DHCP-snooping database, use the **no** form of this command.

no ip dhcp snooping database [timeout | write-delay]

Syntax Description

flash:url	Specifies the database URL for storing entries using flash.
ftp:url	Specifies the database URL for storing entries using FTP.
http:url	Specifies the database URL for storing entries using HTTP.
https:url	Specifies the database URL for storing entries using secure HTTP (https).
rcp:url	Specifies the database URL for storing entries using remote copy (rcp).
scp:url	Specifies the database URL for storing entries using Secure Copy (SCP).
tftp:url	Specifies the database URL for storing entries using TFTP.
timeout seconds	Specifies the abort timeout interval; valid values are from 0 to 86400 seconds.
write-delay seconds	Specifies the amount of time before writing the DHCP-snooping entries to an external server after a change is seen in the local DHCP-snooping database; valid values are from 15 to 86400 seconds.

Command Default

The DHCP-snooping database is not configured.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You must enable DHCP snooping on the interface before entering this command. Use the **ip dhcp snooping** command to enable DHCP snooping.

Examples This example shows how to specify the database URL using TFTP:

```
Controller(config)# ip dhcp snooping database tftp://10.90.90.90/snooping-rp2
```

This example shows how to specify the amount of time before writing DHCP snooping entries to an external server:

```
Controller(config)# ip dhcp snooping database write-delay 15
```

ip dhcp snooping information option format remote-id

To configure the option-82 remote-ID suboption, use the **ip dhcp snooping information option format remote-id** command in global configuration mode on the switch to configure the option-82 remote-ID suboption. To configure the default remote-ID suboption, use the **no** form of this command.

```
ip dhcp snooping information option format remote-id {hostname | string string}
no ip dhcp snooping information option format remote-id {hostname | string string}
```

Syntax Description

hostname	Specify the switch hostname as the remote ID.
string string	Specify a remote ID, using from 1 to 63 ASCII characters (no spaces).

Command Default

The switch MAC address is the remote ID.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must globally enable DHCP snooping by using the **ip dhcp snooping** global configuration command for any DHCP snooping configuration to take effect.

When the option-82 feature is enabled, the default remote-ID suboption is the switch MAC address. This command allows you to configure either the switch hostname or a string of up to 63 ASCII characters (but no spaces) to be the remote ID.



Note

If the hostname exceeds 63 characters, it will be truncated to 63 characters in the remote-ID configuration.

Examples

This example shows how to configure the option- 82 remote-ID suboption:

```
Controller(config)# ip dhcp snooping information option format remote-id hostname
```

ip dhcp snooping verify no-relay-agent-address

To disable the DHCP snooping feature from verifying that the relay agent address (giaddr) in a DHCP client message matches the client hardware address on an untrusted port, use the **ip dhcp snooping verify no-relay-agent-address** command in global configuration mode. To enable verification, use the **no** form of this command.

ip dhcp snooping verify no-relay-agent-address

no ip dhcp snooping verify no-relay-agent-address

Syntax Description This command has no arguments or keywords.

Command Default The DHCP snooping feature verifies that the relay-agent IP address (giaddr) field in DHCP client message on an untrusted port is 0.

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

By default, the DHCP snooping feature verifies that the relay-agent IP address (giaddr) field in DHCP client message on an untrusted port is 0; the message is dropped if the giaddr field is not 0. Use the **ip dhcp snooping verify no-relay-agent-address** command to disable the verification. Use the **no ip dhcp snooping verify no-relay-agent-address** to reenable verification.

Examples

This example shows how to enable verification of the giaddr in a DHCP client message:

```
Controller(config)# no ip dhcp snooping verify no-relay-agent-address
```

ip source binding

To add a static IP source binding entry, use the **ip source binding** command. Use the **no** form of this command to delete a static IP source binding entry

ip source binding *mac-address* **vlan** *vlan-id* *ip-address* **interface** *interface-id*

no ip source binding *mac-address* **vlan** *vlan-id* *ip-address* **interface** *interface-id*

Syntax Description		
	<i>mac-address</i>	Binding MAC address.
	vlan <i>vlan-id</i>	Specifies the Layer 2 VLAN identification; valid values are from 1 to 4094.
	<i>ip-address</i>	Binding IP address.
	interface <i>interface-id</i>	ID of the physical interface.

Command Default No IP source bindings are configured.

Command Modes Global configuration.

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You can use this command to add a static IP source binding entry only.

The **no** format deletes the corresponding IP source binding entry. It requires the exact match of all required parameter in order for the deletion to be successful. Note that each static IP binding entry is keyed by a MAC address and a VLAN number. If the command contains the existing MAC address and VLAN number, the existing binding entry is updated with the new parameters instead of creating a separate binding entry.

Examples This example shows how to add a static IP source binding entry:

```
Controller# configure terminal
Controller(config) ip source binding 0100.0230.0002 vlan 11 10.0.0.4 interface
gigabitethernet1/0/1
```

ip verify source

To enable IP source guard on an interface, use the **ip verify source** command in interface configuration mode. To disable IP source guard, use the **no** form of this command.

ip verify source

no ip verify source

Syntax Description

mac-check	(Optional) Enables IP source guard with MAC address verification.
------------------	---

Command Default

IP source guard is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

To enable IP source guard with source IP address filtering, use the **ip verify source** interface configuration command.

Examples

This example shows how to enable IP source guard with source IP address filtering on an interface:

```

Controller(config)# interface gigabitethernet1/0/1
Controller(config-if)# ip verify source

Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# ip dhcp snooping
Controller(config)# ip dhcp snooping vlan 10 20
Controller(config)# interface gigabitethernet1/0/1
Controller(config-if)# switchport trunk encapsulation dot1q
Controller(config-if)# switchport mode trunk
Controller(config-if)# switchport trunk native vlan 10
Controller(config-if)# switchport trunk allowed vlan 11-20
Controller(config-if)# no ip dhcp snooping trust
Controller(config-if)# ip verify source vlan dhcp-snooping
Controller(config)# end
Controller# show ip verify source interface fastethernet0/1
Interface  Filter-type  Filter-mode  IP-address  Mac-address  Vlan
-----
Gil/0/1    ip-mac       active       10.0.0.1   -----
Gil/0/1    ip-mac       active       deny-all   -----
Controller#

```

```

Controller# configure terminal

```

```
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# ip device tracking
Controller(config)# interface gigabitethernet1/0/3
Controller(config-if)# switchport mode access
Controller(config-if)# switchport access vlan 1
Controller(config-if)# ip device tracking maximum 5
Controller(config-if)# switchport port-security
Controller(config-if)# switchport port-security maximum 5
Controller(config-if)# ip verify source tracking port-security
Controller(config-if)# end
```

You can verify your settings by entering the **show ip verify source** privileged EXEC command.

ipv6 snooping policy

To configure an IPv6 snooping policy and enter IPv6 snooping configuration mode, use the **ipv6 snooping policy** command in global configuration mode. To delete an IPv6 snooping policy, use the **no** form of this command.

ipv6 snooping policy *snooping-policy*
no ipv6 snooping policy *snooping-policy*

Syntax Description

<i>snooping-policy</i>	User-defined name of the snooping policy. The policy name can be a symbolic string (such as Engineering) or an integer (such as 0).
------------------------	---

Command Default

An IPv6 snooping policy is not configured.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use the **ipv6 snooping policy** command to create an IPv6 snooping policy. When the **ipv6 snooping policy** command is enabled, the configuration mode changes to IPv6 snooping configuration mode. In this mode, the administrator can configure the following IPv6 first-hop security commands:

- The **device-role** command specifies the role of the device attached to the port.
- The **limit address-count** *maximum* command limits the number of IPv6 addresses allowed to be used on the port.
- The **protocol** command specifies that addresses should be gleaned with Dynamic Host Configuration Protocol (DHCP) or Neighbor Discovery Protocol (NDP).
- The **security-level** command specifies the level of security enforced.
- The **tracking** command overrides the default tracking policy on a port.
- The **trusted-port** command configures a port to become a trusted port; that is, limited or no verification is performed when messages are received.

Examples

This example shows how to configure an IPv6 snooping policy:

```
Controller(config)# ipv6 snooping policy policy1
```

```
Controller(config-ipv6-snooping)#
```

limit address-count

To limit the number of IPv6 addresses allowed to be used on the port, use the **limit address-count** command in Neighbor Discovery Protocol (NDP) inspection policy configuration mode or IPv6 snooping configuration mode. To return to the default, use the **no** form of this command.

limit address-count *maximum*

no limit address-count

Syntax Description

<i>maximum</i>	The number of addresses allowed on the port. The range is from 1 to 10000.
----------------	--

Command Default

The default is no limit.

Command Modes

ND inspection policy configuration
IPv6 snooping configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **limit address-count** command limits the number of IPv6 addresses allowed to be used on the port on which the policy is applied. Limiting the number of IPv6 addresses on a port helps limit the binding table size. The range is from 1 to 10000.

Examples

This example shows how to define an NDP policy name as policy1, place the switch in NDP inspection policy configuration mode, and limit the number of IPv6 addresses allowed on the port to 25:

```
Controller(config)# ipv6 nd inspection policy policy1
Controller(config-nd-inspection)# limit address-count 25
```

This example shows how to define an IPv6 snooping policy name as policy1, place the switch in IPv6 snooping policy configuration mode, and limit the number of IPv6 addresses allowed on the port to 25:

```
Controller(config)# ipv6 snooping policy policy1
Controller(config-ipv6-snooping)# limit address-count 25
```

mab request format attribute 32

To enable VLAN ID-based MAC authentication on a switch, use the **mab request format attribute 32 vlan access-vlan** command in global configuration mode. To return to the default setting, use the **no** form of this command.

mab request format attribute 32 vlan access-vlan

no mab request format attribute 32 vlan access-vlan

Syntax Description This command has no arguments or keywords.

Command Default VLAN-ID based MAC authentication is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	

Usage Guidelines Use this command to allow a RADIUS server to authenticate a new user based on the host MAC address and VLAN.

Use this feature on networks with the Microsoft IAS RADIUS server. The Cisco ACS ignores this command.

Examples This example shows how to enable VLAN-ID based MAC authentication on a switch:

```
Controller(config)# mab request format attribute 32 vlan access-vlan
```

Related Commands

Command	Description
authentication event	Sets the action for specific authentication events.
authentication fallback	Configures a port to use web authentication as a fallback method for clients that do not support IEEE 802.1x authentication.
authentication host-mode	Sets the authorization manager mode on a port.
authentication open	Enables or disables open access on a port.
authentication order	Sets the order of authentication methods used on a port.

Command	Description
authentication periodic	Enables or disables reauthentication on a port.
authentication port-control	Enables manual control of the port authorization state.
authentication priority	Adds an authentication method to the port-priority list.
authentication timer	Configures the timeout and reauthentication parameters for an 802.1x-enabled port.
authentication violation	Configures the violation modes that occur when a new device connects to a port or when a new device connects to a port with the maximum number of devices already connected to that port.
mab	Enables MAC-based authentication on a port.
mab eap	Configures a port to use the Extensible Authentication Protocol (EAP).
show authentication	Displays information about authentication manager events on the switch.

match (access-map configuration)

To set the VLAN map to match packets against one or more access lists, use the **match** command in access-map configuration mode on the switch stack or on a standalone switch. To remove the match parameters, use the **no** form of this command.

```
match {ip address {name|number} [name|number] [name|number]...|mac address {name} [name] [name]...}
no match {ip address {name|number} [name|number] [name|number]...|mac address {name} [name] [name]...}
```

Syntax Description

ip address	Sets the access map to match packets against an IP address access list.
mac address	Sets the access map to match packets against a MAC address access list.
<i>name</i>	Name of the access list to match packets against.
<i>number</i>	Number of the access list to match packets against. This option is not valid for MAC access lists.

Command Default

The default action is to have no match parameters applied to a VLAN map.

Command Modes

Access-map configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You enter access-map configuration mode by using the **vlan access-map** global configuration command.

You must enter one access list name or number; others are optional. You can match packets against one or more access lists. Matching any of the lists counts as a match of the entry.

In access-map configuration mode, use the **match** command to define the match conditions for a VLAN map applied to a VLAN. Use the **action** command to set the action that occurs when the packet matches the conditions.

Packets are matched only against access lists of the same protocol type; IP packets are matched against IP access lists, and all other packets are matched against MAC access lists.

Both IP and MAC addresses can be specified for the same map entry.

Examples

This example shows how to define and apply a VLAN access map vmap4 to VLANs 5 and 6 that will cause the interface to drop an IP packet if the packet matches the conditions defined in access list a12:

```
Controller(config)# vlan access-map vmap4
Controller(config-access-map)# match ip address a12
Controller(config-access-map)# action drop
Controller(config-access-map)# exit
Controller(config)# vlan filter vmap4 vlan-list 5-6
```

You can verify your settings by entering the **show vlan access-map** privileged EXEC command.

Related Commands

Command	Description
action	Sets the action for the VLAN access map entry.
show vlan access-map	Displays the VLAN access maps created on the switch.
vlan access-map	Defines a VLAN map and enters access-map configuration mode where you can specify a MAC ACL to match and the action to be taken.

no authentication logging verbose

To filter detailed information from authentication system messages, use the **no authentication logging verbose** command in global configuration mode on the switch stack or on a standalone switch.

no authentication logging verbose

Syntax Description This command has no arguments or keywords.

Command Default All details are displayed in the system messages.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines This command filters details, such as anticipated success, from authentication system messages. Failure messages are not filtered.

Examples To filter verbose authentication system messages:

```
Controller(config)# no authentication logging verbose
```

You can verify your settings by entering the **show running-config** privileged EXEC command.

Related Commands	Command	Description
	no authentication logging verbose	Filters details from authentication system messages.
	no dot1x logging verbose	Filters details from 802.1x system messages.
	no mab logging verbose	Filters details from MAC authentication bypass (MAB) system messages.

no dot1x logging verbose

To filter detailed information from 802.1x system messages, use the **no dot1x logging verbose** command in global configuration mode on the switch stack or on a standalone switch.

no dot1x logging verbose

Syntax Description This command has no arguments or keywords.

Command Default All details are displayed in the system messages.

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

This command filters details, such as anticipated success, from 802.1x system messages. Failure messages are not filtered.

Examples

To filter verbose 802.1x system messages:

```
Controller(config)# no dot1x logging verbose
```

You can verify your settings by entering the **show running-config** privileged EXEC command.

Related Commands

Command	Description
no authentication logging verbose	Filters details from authentication system messages.
no dot1x logging verbose	Filters details from 802.1x system messages.
no mab logging verbose	Filters details from MAC authentication bypass (MAB) system messages.

no mab logging verbose

To filter detailed information from MAC authentication bypass (MAB) system messages, use the **no mab logging verbose** command in global configuration mode on the switch stack or on a standalone switch.

no mab logging verbose

Syntax Description This command has no arguments or keywords.

Command Default All details are displayed in the system messages.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines This command filters details, such as anticipated success, from MAC authentication bypass (MAB) system messages. Failure messages are not filtered.

Examples To filter verbose MAB system messages:

```
Controller(config)# no mab logging verbose
```

You can verify your settings by entering the **show running-config** privileged EXEC command.

Related Commands

Command	Description
no authentication logging verbose	Filters details from authentication system messages.
no dot1x logging verbose	Filters details from 802.1x system messages.
no mab logging verbose	Filters details from MAC authentication bypass (MAB) system messages.

permit (MAC access-list configuration)

To allow non-IP traffic to be forwarded if the conditions are matched, use the **permit** MAC access-list configuration command on the switch stack or on a standalone switch. To remove a permit condition from the extended MAC access list, use the **no** form of this command.

```
{permit {any | hostsrc-MAC-addr | src-MAC-addr mask} {any | hostdst-MAC-addr | dst-MAC-addr mask}
[type mask | aarp | amber | appletalk | dec-spanning | decnet-iv | diagnostic | dsm | etype-6000 | etype-8042
| lat | larc-sca | lsaplsap mask | mop-console | mop-dump | msdos | mumps | netbios | vines-echo | vines-ip
| xns-idp][coscos]
```

```
nopermit {any | host src-MAC-addr | src-MAC-addr mask} {any | host dst-MAC-addr | dst-MAC-addr mask}
[type mask | aarp | amber | appletalk | dec-spanning | decnet-iv | diagnostic | dsm | etype-6000 | etype-8042
| lat | larc-sca | lsap lsap mask | mop-console | mop-dump | msdos | mumps | netbios | vines-echo | vines-ip
| xns-idp][coscos]
```

Syntax Description

any	Denies any source or destination MAC address.
host <i>src-MAC-addr</i> <i>src-MAC-addr mask</i>	Specifies a host MAC address and optional subnet mask. If the source address for a packet matches the defined address, non-IP traffic from that address is denied.
host <i>dst-MAC-addr</i> <i>dst-MAC-addr mask</i>	Specifies a destination MAC address and optional subnet mask. If the destination address for a packet matches the defined address, non-IP traffic to that address is denied.
<i>type mask</i>	(Optional) Specifies the EtherType number of a packet with Ethernet II or SNAP encapsulation to identify the protocol of the packet. <ul style="list-style-type: none"> • <i>type</i> is 0 to 65535, specified in hexadecimal. • <i>mask</i> is a mask of don't care bits applied to the EtherType before testing for a match.
aarp	(Optional) Specifies EtherType AppleTalk Address Resolution Protocol that maps a data-link address to a network address.
amber	(Optional) Specifies EtherType DEC-Amber.
appletalk	(Optional) Specifies EtherType AppleTalk/EtherTalk.
dec-spanning	(Optional) Specifies EtherType Digital Equipment Corporation (DEC) spanning tree.
decnet-iv	(Optional) Specifies EtherType DECnet Phase IV protocol.
diagnostic	(Optional) Specifies EtherType DEC-Diagnostic.
dsm	(Optional) Specifies EtherType DEC-DSM.

etype-6000	(Optional) Specifies EtherType 0x6000.
etype-8042	(Optional) Specifies EtherType 0x8042.
lat	(Optional) Specifies EtherType DEC-LAT.
lavc-sca	(Optional) Specifies EtherType DEC-LAVC-SCA.
lsap <i>lsap-number mask</i>	(Optional) Specifies the LSAP number (0 to 65535) of a packet with 802.2 encapsulation to identify the protocol of the packet. The <i>mask</i> is a mask of don't care bits applied to the LSAP number before testing for a match.
mop-console	(Optional) Specifies EtherType DEC-MOP Remote Console.
mop-dump	(Optional) Specifies EtherType DEC-MOP Dump.
msdos	(Optional) Specifies EtherType DEC-MSDOS.
mumps	(Optional) Specifies EtherType DEC-MUMPS.
netbios	(Optional) Specifies EtherType DEC- Network Basic Input/Output System (NetBIOS).
vines-echo	(Optional) Specifies EtherType Virtual Integrated Network Service (VINES) Echo from Banyan Systems.
vines-ip	(Optional) Specifies EtherType VINES IP.
xns-idp	(Optional) Specifies EtherType Xerox Network Systems (XNS) protocol suite.
cos <i>cos</i>	(Optional) Specifies an arbitrary class of service (CoS) number from 0 to 7 to set priority. Filtering on CoS can be performed only in hardware. A warning message appears if the cos option is configured.

Command Default

This command has no defaults. However, the default action for a MAC-named ACL is to deny.

Command Modes

Mac-access list configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Though visible in the command-line help strings, **appletalk** is not supported as a matching condition.

You enter MAC access-list configuration mode by using the **mac access-list extended** global configuration command.

If you use the **host** keyword, you cannot enter an address mask; if you do not use the **any** or **host** keywords, you must enter an address mask.

After an access control entry (ACE) is added to an access control list, an implied **deny-any-any** condition exists at the end of the list. That is, if there are no matches, the packets are denied. However, before the first ACE is added, the list permits all packets.

To filter IPX traffic, you use the *type mask* or **lsap lsap mask** keywords, depending on the type of IPX encapsulation being used. Filter criteria for IPX encapsulation types as specified in Novell terminology and Cisco IOS terminology are listed in the following table.

Table 13: IPX Filtering Criteria

IPX Encapsulation Type		Filter Criterion
Cisco IOS Name	Novell Name	
arpa	Ethernet II	EtherType 0x8137
snap	Ethernet-snap	EtherType 0x8137
sap	Ethernet 802.2	LSAP 0xE0E0
novell-ether	Ethernet 802.3	LSAP 0xFFFF

Examples

This example shows how to define the MAC-named extended access list to allow NetBIOS traffic from any source to MAC address 00c0.00a0.03fa. Traffic matching this list is allowed.

```
Controller(config-ext-macl)# permit any host 00c0.00a0.03fa netbios
```

This example shows how to remove the permit condition from the MAC-named extended access list:

```
Controller(config-ext-macl)# no permit any 00c0.00a0.03fa 0000.0000.0000 netbios
```

This example permits all packets with EtherType 0x4321:

```
Controller(config-ext-macl)# permit any any 0x4321 0
```

You can verify your settings by entering the **show access-lists** privileged EXEC command.

Related Commands

Command	Description
deny	Denies from the MAC access-list configuration. Denies non-IP traffic to be forwarded if conditions are matched.

Command	Description
mac access-list extended	Creates an access list based on MAC addresses for non-IP traffic.
show access-lists	Displays access control lists configured on a switch.

protocol (IPv6 snooping)

To specify that addresses should be gleaned with Dynamic Host Configuration Protocol (DHCP) or Neighbor Discovery Protocol (NDP), or to associate the protocol with an IPv6 prefix list, use the **protocol** command. To disable address gleaning with DHCP or NDP, use the **no** form of the command.

protocol {**dhcp** | **ndp**}

no protocol {**dhcp** | **ndp**}

Syntax Description

dhcp	Specifies that addresses should be gleaned in Dynamic Host Configuration Protocol (DHCP) packets.
ndp	Specifies that addresses should be gleaned in Neighbor Discovery Protocol (NDP) packets.

Command Default

Snooping and recovery are attempted using both DHCP and NDP.

Command Modes

IPv6 snooping configuration mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

If an address does not match the prefix list associated with DHCP or NDP, then control packets will be dropped and recovery of the binding table entry will not be attempted with that protocol.

- Using the **no protocol {dhcp | ndp}** command indicates that a protocol will not be used for snooping or gleaning.
- If the **no protocol dhcp** command is used, DHCP can still be used for binding table recovery.
- Data glean can recover with DHCP and NDP, though destination guard will only recovery through DHCP.

Examples

This example shows how to define an IPv6 snooping policy name as `policy1`, place the switch in IPv6 snooping policy configuration mode, and configure the port to use DHCP to glean addresses:

```
Controller(config)# ipv6 snooping policy policy1
Controller(config-ipv6-snooping)# protocol dhcp
```

security level (IPv6 snooping)

To specify the level of security enforced, use the **security-level** command in IPv6 snooping policy configuration mode.

security level {**glean** | **guard** | **inspect**}

Syntax Description

glean	Extracts addresses from the messages and installs them into the binding table without performing any verification.
guard	Performs both glean and inspect. Additionally, RA and DHCP server messages are rejected unless they are received on a trusted port or another policy authorizes them.
inspect	Validates messages for consistency and conformance; in particular, address ownership is enforced. Invalid messages are dropped.

Command Default

The default security level is guard.

Command Modes

IPv6 snooping configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to define an IPv6 snooping policy name as policy1, place the device in IPv6 snooping configuration mode, and configure the security level as inspect:

```
Controller(config)# ipv6 snooping policy policy1
Controller(config-ipv6-snooping)# security-level inspect
```

show aaa clients

To show AAA client statistics, use the **show aaa clients** command.

show aaa clients [detailed]

Syntax Description

detailed	(Optional) Shows detailed AAA client statistics.
-----------------	--

Command Modes

User EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This is an example of output from the **show aaa clients** command:

```
Controller# show aaa clients
Dropped request packets: 0
```

show aaa command handler

To show AAA command handler statistics, use the **show aaa command handler** command.

show aaa command handler

Syntax Description This command has no arguments or keywords.

Command Modes User EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This is an example of output from the **show aaa command handler** command:

```

Controller# show aaa command handler

AAA Command Handler Statistics:
  account-logon: 0, account-logout: 0
  account-query: 0, pod: 0
  service-logon: 0, service-logout: 0
  user-profile-push: 0, session-state-log: 0
  reauthenticate: 0, bounce-host-port: 0
  disable-host-port: 0, update-rbacl: 0
  update-sgt: 0, update-cts-policies: 0
  invalid commands: 0
  async message not sent: 0

```

show aaa local

To show AAA local method options, use the **show aaa local** command.

show aaa local {netuser {*name* | all } | statistics | user lockout}

Syntax Description

netuser	Specifies the AAA local network or guest user database.
<i>name</i>	Network user name.
all	Specifies the network and guest user information.
statistics	Displays statistics for local authentication.
user lockout	Specifies the AAA local locked-out user.

Command Modes

User EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This is an example of output from the **show aaa local statistics** command:

```
Controller# show aaa local statistics
```

```
Local EAP statistics
```

EAP Method	Success	Fail
Unknown	0	0
EAP-MD5	0	0
EAP-GTC	0	0
LEAP	0	0
PEAP	0	0
EAP-TLS	0	0
EAP-MSCHAPV2	0	0
EAP-FAST	0	0

```
Requests received from AAA:          0
Responses returned from EAP:        0
Requests dropped (no EAP AVP):      0
Requests dropped (other reasons):    0
Authentication timeouts from EAP:   0
```

```
Credential request statistics
Requests sent to backend:            0
Requests failed (unable to send):    0
Authorization results received
```

```
Success:                             0
```

Fail:

0

show aaa servers

To shows all AAA servers as seen by the AAA server MIB, use the **show aaa servers** command.

show aaa servers [**private|public**[[**detailed**]]

Syntax Description

detailed	(Optional) Displays private AAA servers as seen by the AAA Server MIB.
public	(Optional) Displays public AAA servers as seen by the AAA Server MIB.
detailed	(Optional) Displays detailed AAA server statistics.

Command Modes

User EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This is an example of output from the **show aaa servers** command:

```

Controller# show aaa servers
RADIUS: id 1, priority 1, host 172.20.128.2, auth-port 1645, acct-port 1646
State: current UP, duration 9s, previous duration 0s
Dead: total time 0s, count 0
Quarantined: No
Authen: request 0, timeouts 0, failover 0, retransmission 0
Response: accept 0, reject 0, challenge 0
Response: unexpected 0, server error 0, incorrect 0, time 0ms
Transaction: success 0, failure 0
Throttled: transaction 0, timeout 0, failure 0
Author: request 0, timeouts 0, failover 0, retransmission 0
Response: accept 0, reject 0, challenge 0
Response: unexpected 0, server error 0, incorrect 0, time 0ms
Transaction: success 0, failure 0
Throttled: transaction 0, timeout 0, failure 0
Account: request 0, timeouts 0, failover 0, retransmission 0
Request: start 0, interim 0, stop 0
Response: start 0, interim 0, stop 0
Response: unexpected 0, server error 0, incorrect 0, time 0ms
Transaction: success 0, failure 0
Throttled: transaction 0, timeout 0, failure 0
Elapsed time since counters last cleared: 0m
Estimated Outstanding Access Transactions: 0
Estimated Outstanding Accounting Transactions: 0
Estimated Throttled Access Transactions: 0
Estimated Throttled Accounting Transactions: 0
Maximum Throttled Transactions: access 0, accounting 0

```

show aaa sessions

To show AAA sessions as seen by the AAA Session MIB, use the **show aaa sessions** command.

show aaa sessions

Syntax Description This command has no arguments or keywords.

Command Modes User EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This is an example of output from the **show aaa sessions** command:

```

Controller# show aaa sessions
Total sessions since last reload: 7
Session Id: 4007
  Unique Id: 4025
  User Name: *not available*
  IP Address: 0.0.0.0
  Idle Time: 0
  CT Call Handle: 0

```

show authentication sessions

To display information about current Auth Manager sessions, use the **show authentication sessions** command.

show authentication sessions [**database**][**handle** *handle-id* [**details**]][**interface** *type number* [**details**][**mac** *mac-address* [**interface** *type number*][**method** *method-name* [**interface** *type number* [**details**] [**session-id** *session-id* [**details**]]]

Syntax Description

database	(Optional) Shows only data stored in session database.
handle <i>handle-id</i>	(Optional) Specifies the particular handle for which Auth Manager information is to be displayed.
details	(Optional) Shows detailed information.
interface <i>type number</i>	(Optional) Specifies a particular interface type and number for which Auth Manager information is to be displayed.
mac <i>mac-address</i>	(Optional) Specifies the particular MAC address for which you want to display information.
method <i>method-name</i>	(Optional) Specifies the particular authentication method for which Auth Manager information is to be displayed. If you specify a method (dot1x , mab , or webauth), you may also specify an interface.
session-id <i>session-id</i>	(Optional) Specifies the particular session for which Auth Manager information is to be displayed.

Command Modes

User EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use the **show authentication sessions** command to display information about all current Auth Manager sessions. To display information about specific Auth Manager sessions, use one or more of the keywords.

This table shows the possible operating states for the reported authentication sessions.

Table 14: Authentication Method States

State	Description
Not run	The method has not run for this session.
Running	The method is running for this session.
Failed over	The method has failed and the next method is expected to provide a result.
Success	The method has provided a successful authentication result for the session.
Authc Failed	The method has provided a failed authentication result for the session.

This table shows the possible authentication methods.

Table 15: Authentication Method States

State	Description
dot1x	802.1X
mab	MAC authentication bypass
webauth	web authentication

Examples

The following example shows how to display all authentication sessions on the switch:

```
Controller# show authentication sessions
Interface  MAC Address  Method  Domain  Status  Session ID
Gi1/0/48   0015.63b0.f676  dot1x   DATA   Authz Success  0A3462B1000000102983C05C
Gi1/0/5    000f.23c4.a401  mab     DATA   Authz Success  0A3462B10000000D24F80B58
Gi1/0/5    0014.bf5d.d26d  dot1x   DATA   Authz Success  0A3462B10000000E29811B94
```

The following example shows how to display all authentication sessions on an interface:

```
Controller# show authentication sessions interface gigabitethernet2/0/47
Interface: GigabitEthernet2/0/47
MAC Address: Unknown
IP Address: Unknown
Status: Authz Success
Domain: DATA
Oper host mode: multi-host
Oper control dir: both
Authorized By: Guest Vlan
Vlan Policy: 20
Session timeout: N/A
Idle timeout: N/A
Common Session ID: 0A3462C80000000000002763C
Acct Session ID: 0x00000002
```

```
                Handle: 0x25000000
Runnable methods list:
  Method  State
  mab     Failed over
  dot1x   Failed over
-----
                Interface: GigabitEthernet2/0/47
                MAC Address: 0005.5e7c.da05
                IP Address: Unknown
                User-Name: 00055e7cda05
                Status: Authz Success
                Domain: VOICE
                Oper host mode: multi-domain
                Oper control dir: both
                Authorized By: Authentication Server
                Session timeout: N/A
                Idle timeout: N/A
                Common Session ID: 0A3462C8000000010002A238
                Acct Session ID: 0x00000003
                Handle: 0x91000001
Runnable methods list:
  Method  State
  mab     Authc Success
  dot1x   Not run
```

show cisp

To display CISP information for a specified interface, use the **show cisp** command in privileged EXEC mode.

show cisp {[clients | interface *interface-id*] | registrations | summary}

Syntax Description

clients	(Optional) Display CISP client details.
interface <i>interface-id</i>	(Optional) Display CISP information about the specified interface. Valid interfaces include physical ports and port channels.
registrations	Displays CISP registrations.
summary	(Optional) Displays CISP summary.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows output from the **show cisp interface** command:

```
Controller# show cisp interface fast 0
CISP not enabled on specified interface
```

This example shows output from the **show cisp registration** command:

```
Controller# show cisp registrations
Interface(s) with CISP registered user(s):
-----
Fa1/0/13
Auth Mgr (Authenticator)
Gi2/0/1
Auth Mgr (Authenticator)
Gi2/0/2
Auth Mgr (Authenticator)
Gi2/0/3
Auth Mgr (Authenticator)
Gi2/0/5
Auth Mgr (Authenticator)
Gi2/0/9
Auth Mgr (Authenticator)
Gi2/0/11
Auth Mgr (Authenticator)
Gi2/0/13
Auth Mgr (Authenticator)
Gi3/0/3
Gi3/0/5
```

Gi3/0/23

Related Commands

Command	Description
cisp enable	Enable Client Information Signalling Protocol (CISP)
dot1x credentials <i>profile</i>	Configure a profile on a supplicant switch

show dot1x

To display IEEE 802.1x statistics, administrative status, and operational status for the switch or for the specified port, use the **show dot1x** command in user EXEC mode.

show dot1x [**all** [**count** | **details** | **statistics** | **summary**]] [**interface** *type number* [**details** | **statistics**]] [**statistics**]

Syntax Description

all	(Optional) Displays the IEEE 802.1x information for all interfaces.
count	(Optional) Displays total number of authorized and unauthorized clients.
details	(Optional) Displays the IEEE 802.1x interface details.
statistics	(Optional) Displays the IEEE 802.1x statistics for all interfaces.
summary	(Optional) Displays the IEEE 802.1x summary for all interfaces.
interface <i>type number</i>	(Optional) Displays the IEEE 802.1x status for the specified port.

Command Modes

User EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This is an example of output from the **show dot1x all** command:

```
Controller# show dot1x all
Sysauthcontrol           Enabled
Dot1x Protocol Version   3
```

This is an example of output from the **show dot1x all count** command:

```
Controller# show dot1x all count
Number of Dot1x sessions
-----
Authorized Clients       = 0
UnAuthorized Clients     = 0
Total No of Client      = 0
```

This is an example of output from the **show dot1x all statistics** command:

```
Controller# show dot1x statistics
Dot1x Global Statistics for
```

```
-----  
RxStart = 0      RxLogoff = 0      RxResp = 0      RxRespID = 0  
RxReq = 0        RxInvalid = 0      RxLenErr = 0  
RxTotal = 0  
  
TxStart = 0      TxLogoff = 0      TxResp = 0  
TxReq = 0        ReTxReq = 0        ReTxReqFail = 0  
TxReqID = 0      ReTxReqID = 0      ReTxReqIDFail = 0  
TxTotal = 0
```

show eap pac peer

To display stored Protected Access Credentials (PAC) for Extensible Authentication Protocol (EAP) Flexible Authentication via Secure Tunneling (FAST) peers, use the **show eap pac peer** command in privileged EXEC mode.

show eap pac peer

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This is an example of output from the **show eap pac peers** privileged EXEC command:

```
Controller> show eap pac peers
No PACs stored
```

Related Commands	Command	Description
	clear eap sessions	Clears EAP session information for the switch or for the specified port.

show ip dhcp snooping statistics

To display DHCP snooping statistics in summary or detail form, use the **show ip dhcp snooping statistics** command in user EXEC mode.

show ip dhcp snooping statistics [detail]

Syntax Description

detail	(Optional) Displays detailed statistics information.
---------------	--

Command Modes

User EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

In a switch stack, all statistics are generated on the stack master. If a new active switch is elected, the statistics counters reset.

Examples

This is an example of output from the **show ip dhcp snooping statistics** command:

```
Controller> show ip dhcp snooping statistics
Packets Forwarded                = 0
Packets Dropped                   = 0
Packets Dropped From untrusted ports = 0
```

This is an example of output from the **show ip dhcp snooping statistics detail** command:

```
Controller> show ip dhcp snooping statistics detail
Packets Processed by DHCP Snooping          = 0
Packets Dropped Because
  IDB not known                             = 0
  Queue full                                = 0
  Interface is in errdisabled                = 0
  Rate limit exceeded                       = 0
  Received on untrusted ports                = 0
  Nonzero giaddr                             = 0
  Source mac not equal to chaddr             = 0
  Binding mismatch                           = 0
  Insertion of opt82 fail                    = 0
  Interface Down                             = 0
  Unknown output interface                   = 0
  Reply output port equal to input port      = 0
  Packet denied by platform                  = 0
```

This table shows the DHCP snooping statistics and their descriptions:

Table 16: DHCP Snooping Statistics

DHCP Snooping Statistic	Description
Packets Processed by DHCP Snooping	Total number of packets handled by DHCP snooping, including forwarded and dropped packets.
Packets Dropped Because IDB not known	Number of errors when the input interface of the packet cannot be determined.
Queue full	Number of errors when an internal queue used to process the packets is full. This might happen if DHCP packets are received at an excessively high rate and rate limiting is not enabled on the ingress ports.
Interface is in errdisabled	Number of times a packet was received on a port that has been marked as error disabled. This might happen if packets are in the processing queue when a port is put into the error-disabled state and those packets are subsequently processed.
Rate limit exceeded	Number of times the rate limit configured on the port was exceeded and the interface was put into the error-disabled state.
Received on untrusted ports	Number of times a DHCP server packet (OFFER, ACK, NAK, or LEASEQUERY) was received on an untrusted port and was dropped.
Nonzero giaddr	Number of times the relay agent address field (giaddr) in the DHCP packet received on an untrusted port was not zero, or the no ip dhcp snooping information option allow-untrusted global configuration command is not configured and a packet received on an untrusted port contained option-82 data.
Source mac not equal to chaddr	Number of times the client MAC address field of the DHCP packet (chaddr) does not match the packet source MAC address and the ip dhcp snooping verify mac-address global configuration command is configured.
Binding mismatch	Number of times a RELEASE or DECLINE packet was received on a port that is different than the port in the binding for that MAC address-VLAN pair. This indicates someone might be trying to spoof the real client, or it could mean that the client has moved to another port on the switch and issued a RELEASE or DECLINE. The MAC address is taken from the chaddr field of the DHCP packet, not the source MAC address in the Ethernet header.
Insertion of opt82 fail	Number of times the option-82 insertion into a packet failed. The insertion might fail if the packet with the option-82 data exceeds the size of a single physical packet on the internet.

DHCP Snooping Statistic	Description
Interface Down	Number of times the packet is a reply to the DHCP relay agent, but the SVI interface for the relay agent is down. This is an unlikely error that occurs if the SVI goes down between sending the client request to the DHCP server and receiving the response.
Unknown output interface	Number of times the output interface for a DHCP reply packet cannot be determined by either option-82 data or a lookup in the MAC address table. The packet is dropped. This can happen if option 82 is not used and the client MAC address has aged out. If IPSG is enabled with the port-security option and option 82 is not enabled, the MAC address of the client is not learned, and the reply packets will be dropped.
Reply output port equal to input port	Number of times the output port for a DHCP reply packet is the same as the input port, causing a possible loop. Indicates a possible network misconfiguration or misuse of trust settings on ports.
Packet denied by platform	Number of times the packet has been denied by a platform-specific registry.

show radius server-group

To display properties for the RADIUS server group, use the **show radius server-group** command.

show radius server-group {*name* | **all**}

Syntax Description

<i>name</i>	Name of the server group. The character string used to name the group of servers must be defined using the aaa group server radius command.
all	Displays properties for all of the server groups.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use the **show radius server-group** command to display the server groups that you defined by using the **aaa group server radius** command.

Examples

This is an example of output from the **show radius server-group all** command:

```
Controller# show radius server-group all
Server group radius
  Sharecount = 1  sg_unconfigured = FALSE
  Type = standard  Memlocks = 1
```

This table describes the significant fields shown in the display.

Table 17: show radius server-group command Field Descriptions

Field	Description
Server group	Name of the server group.
Sharecount	Number of method lists that are sharing this server group. For example, if one method list uses a particular server group, the sharecount would be 1. If two method lists use the same server group, the sharecount would be 2.

Field	Description
sg_unconfigured	Server group has been unconfigured.
Type	The type can be either standard or nonstandard. The type indicates whether the servers in the group accept nonstandard attributes. If all servers within the group are configured with the nonstandard option, the type will be shown as "nonstandard".
Memlocks	An internal reference count for the server-group structure that is in memory. The number represents how many internal data structure packets or transactions are holding references to this server group. Memlocks is used internally for memory management purposes.

show vlan access-map

To display information about a particular VLAN access map or for all VLAN access maps, use the **show vlan access-map** command in privileged EXEC mode.

show vlan access-map [*map-name*]

Syntax Description	<i>map-name</i> (Optional) Name of a specific VLAN access map.				
Command Default	None				
Command Modes	Privileged EXEC				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.2SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.2SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.2SE	This command was introduced.				

Examples

This is an example of output from the **show vlan access-map** command:

```
Controller# show vlan access-map
Vlan access-map "vmap4" 10
  Match clauses:
    ip address: a12
  Action:
    forward
Vlan access-map "vmap4" 20
  Match clauses:
    ip address: a12
  Action:
    forward
```

Related Commands	Command	Description
	show vlan filter	Displays information about all VLAN filters or about a particular VLAN or VLAN access map.
	vlan access-map	Defines a VLAN map and enters access-map configuration mode where you can specify a MAC ACL to match and the action to be taken.
	vlan filter	Applies a VLAN map to one or more VLANs.

show vlan group

To display the VLANs that are mapped to VLAN groups, use the **show vlan group** command in privileged EXEC mode.

show vlan group [**group-name** *vlan-group-name* [**user_count**]]

Syntax Description

group-name <i>vlan-group-name</i>	(Optional) Displays the VLANs mapped to the specified VLAN group.
user_count	(Optional) Displays the number of users in each VLAN mapped to a specified VLAN group.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **show vlan group** command displays the existing VLAN groups and lists the VLANs and VLAN ranges that are members of each VLAN group. If you enter the **group-name** keyword, only the members of the specified VLAN group are displayed.

Examples

This example shows how to display the members of a specified VLAN group:

Related Commands

Command	Description
vlan group	Creates or modifies a VLAN group.

show wireless wps rogue ap summary

To display a list of all rogue access points detected by the controller, use the **show wireless wps rogue ap summary** command.

show wireless wps rogue ap summary

Command Default None.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

Examples This example shows how to display a list of all rogue access points detected by the controller:

```
Controller# show wireless wps rogue ap summary
Rogue Location Discovery Protocol      : Disabled
Rogue on wire Auto-Contain            : Disabled
Rogue using our SSID Auto-Contain     : Disabled
Valid client on rogue AP Auto-Contain : Disabled
Rogue AP timeout                      : 1200
Rogue Detection Report Interval       : 10
Rogue AP minimum RSSI                 : -128
Rogue AP minimum transient time       : 0
```

Number of rogue APs detected : 624

MAC Address	Classification	# APs	# Clients	Last Heard
0018.e78d.250a	Unclassified	1	0	Thu Jul 25 05:04:01 2013
0019.0705.d5bc	Unclassified	1	0	Thu Jul 25 05:16:26 2013
0019.0705.d5bd	Unclassified	1	0	Thu Jul 25 05:10:28 2013
0019.0705.d5bf	Unclassified	1	0	Thu Jul 25 05:16:26 2013

show wireless wps rogue client detailed

To view the detailed information of a specific rogue client, use the **show wireless wps rogue client detailed** *client-mac* command.

show wireless wps rogue client detailed *client-mac*

Syntax Description

<i>client-mac</i>	MAC address of the rogue client.
-------------------	----------------------------------

Command Default

None.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

None.

Examples

This example shows how to display the detailed information for a specific rogue client:

```

Controller# show wireless wps rogue client detail 0024.d7f1.2558
Rogue BSSID                : 64d8.146f.379f
Rogue Radio Type           : 802.11n - 5GHz
State                       : Alert
First Time Rogue was Reported : Wed Aug  7 12:51:43 2013
Last Time Rogue was Reported  : Wed Aug  7 12:51:43 2013
Reported by
  AP 2
    MAC Address             : 3cce.7309.0370
    Name                    : AP3502-talwar-ccie
    Radio Type              : 802.11a
    RSSI                    : -42 dBm
    SNR                     : 47 dB
    Channel                 : 52
    Last reported by this AP : Wed Aug  7 12:51:43 2013
  
```

show wireless wps wips statistics

To display the current state of the Cisco Wireless Intrusion Prevention System (wIPS) operation on the controller, use the **show wireless wps wips statistics** command.

show wireless wps wips statistics

Command Default None.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

Examples This example shows how to display the statistics of the wIPS operation:

```

Controller# show wireless wps wips statistics
Policy Assignment Requests..... 1
Policy Assignment Responses..... 1
Policy Update Requests..... 0
Policy Update Responses..... 0
Policy Delete Requests..... 0
Policy Delete Responses..... 0
Alarm Updates..... 13572
Device Updates..... 8376
Device Update Requests..... 0
Device Update Responses..... 0
Forensic Updates..... 1001
Invalid WIPS Payloads..... 0
Invalid Messages Received..... 0
CAPWAP Enqueue failed ..... 0
NMSP Enqueue failed ..... 0
NMSP Transmitted Packets..... 22950
NMSP Transmit Packets Dropped..... 0
NMSP Largest Packet..... 1377

```

show wireless wps wips summary

To display the adaptive Cisco Wireless Intrusion Prevention System (wIPS) configuration that the Wireless Control System (WCS) forwards to the controller, use the **show wireless wps wips summary** command.

show wireless wps wips summary

Command Default None.

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

Examples This example shows how to display a summary of the wIPS configuration:

```
Controller# show wireless wps wips summary
Policy Name..... Default
Policy Version..... 3
```

tracking (IPv6 snooping)

To override the default tracking policy on a port, use the **tracking** command in IPv6 snooping policy configuration mode.

tracking {**enable** [**reachable-lifetime** {*value* | **infinite**}] | **disable** [**stale-lifetime** {*value* | **infinite**}]}

Syntax Description

enable	Enables tracking.
reachable-lifetime	(Optional) Specifies the maximum amount of time a reachable entry is considered to be directly or indirectly reachable without proof of reachability. <ul style="list-style-type: none"> The reachable-lifetime keyword can be used only with the enable keyword. Use of the reachable-lifetime keyword overrides the global reachable lifetime configured by the ipv6 neighbor binding reachable-lifetime command.
<i>value</i>	Lifetime value, in seconds. The range is from 1 to 86400, and the default is 300.
infinite	Keeps an entry in a reachable or stale state for an infinite amount of time.
disable	Disables tracking.
stale-lifetime	(Optional) Keeps the time entry in a stale state, which overwrites the global stale-lifetime configuration. <ul style="list-style-type: none"> The stale lifetime is 86,400 seconds. The stale-lifetime keyword can be used only with the disable keyword. Use of the stale-lifetime keyword overrides the global stale lifetime configured by the ipv6 neighbor binding stale-lifetime command.

Command Default The time entry is kept in a reachable state.

Command Modes IPv6 snooping configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **tracking** command overrides the default tracking policy set by the **ipv6 neighbor tracking** command on the port on which this policy applies. This function is useful on trusted ports where, for example, you may not want to track entries but want an entry to stay in the binding table to prevent it from being stolen.

The **reachable-lifetime** keyword is the maximum time an entry will be considered reachable without proof of reachability, either directly through tracking or indirectly through IPv6 snooping. After the **reachable-lifetime** value is reached, the entry is moved to stale. Use of the **reachable-lifetime** keyword with the tracking command overrides the global reachable lifetime configured by the **ipv6 neighbor binding reachable-lifetime** command.

The **stale-lifetime** keyword is the maximum time an entry is kept in the table before it is deleted or the entry is proven to be reachable, either directly or indirectly. Use of the **reachable-lifetime** keyword with the **tracking** command overrides the global stale lifetime configured by the **ipv6 neighbor binding stale-lifetime** command.

Examples

This example shows how to define an IPv6 snooping policy name as policy1, place the switch in IPv6 snooping policy configuration mode, and configure an entry to stay in the binding table for an infinite length of time on a trusted port:

```
Controller(config)# ipv6 snooping policy policy1
Controller(config-ipv6-snooping)# tracking disable stale-lifetime infinite
```

trusted-port

To configure a port to become a trusted port, use the **trusted-port** command in IPv6 snooping policy mode or ND inspection policy configuration mode. To disable this function, use the **no** form of this command.

trusted-port

no trusted-port

Syntax Description This command has no arguments or keywords.

Command Default No ports are trusted.

Command Modes ND inspection policy configuration
IPv6 snooping configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines When the **trusted-port** command is enabled, limited or no verification is performed when messages are received on ports that have this policy. However, to protect against address spoofing, messages are analyzed so that the binding information that they carry can be used to maintain the binding table. Bindings discovered from these ports will be considered more trustworthy than bindings received from ports that are not configured to be trusted.

Examples This example shows how to define an NDP policy name as policy1, place the switch in NDP inspection policy configuration mode, and configure the port to be trusted:

```
Controller(config)# ipv6 nd inspection policy1
Controller(config-nd-inspection)# trusted-port
```

This example shows how to define an IPv6 snooping policy name as policy1, place the switch in IPv6 snooping policy configuration mode, and configure the port to be trusted:

```
Controller(config)# ipv6 snooping policy policy1
Controller(config-ipv6-snooping)# trusted-port
```

wireless security web-auth retries

To enable web authentication retry on a particular WLAN, use the **wireless wireless security web-auth retries** command. To disable, use the **no** form of the command.

wireless security web-auth retries *retries*
no wireless security web-auth retries

Syntax Description

wireless security web-auth	Enables web authentication on a particular WLAN.
retries <i>retries</i>	Specifies maximum number of web authentication request retries. The range is from 0 through 30. The default value is 3.

Command Default

Command Modes

config

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None.

Examples

This example shows how to enable web authentication retry on a particular WLAN.

```
Controller#configure terminal
Controller# wireless security web-auth retries 10
```

wireless dot11-padding

To enable over-the-air frame padding, use the **wireless dot11-padding** command. To disable, use the **no** form of the command.

wireless dot11-padding

no wireless dot11-padding

Command Default

Disabled.

Command Modes

config

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None.

Examples

This example shows how to enable over-the-air frame padding

```
Controller#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)#wireless dot11-padding
```

wireless wps rogue rule

To configure rogue classification rule, use the **wireless wps rogue rule** command.

wireless wps rogue rule *rule-name* **priority** *priority* {**classify** {**friendly**|**malicious**} | **condition** {**client-count** **number**| **duration**| **encryption**| **infrastructure**| **rfssi**| **ssid**} | **default** | **exit** | **match** {**all**|**any**} | **no** | **shutdown**}

Syntax Description

rule <i>rule-name</i>	Specifies a rule name.
priority <i>priority</i>	Changes the priority of a specific rule and shifts others in the list accordingly.
classify	Specifies the classification of a rule.
friendly	Classifies a rule as friendly.
malicious	Classifies a rule as malicious.
condition { client-count number duration encryption infrastructure rfssi ssid }	Specifies the conditions for a rule that the rogue access point must meet. Type of the condition to be configured. The condition types are listed below: <ul style="list-style-type: none"> • client-count—Requires that a minimum number of clients be associated to a rogue access point. The valid range is 1 to 10 (inclusive). • duration—Requires that a rogue access point be detected for a minimum period of time. The valid range is 0 to 3600 seconds (inclusive). • encryption—Requires that the advertised WLAN does not have encryption enabled. • infrastructure—Requires the SSID to be known to the controller • rfssi—Requires that a rogue access point have a minimum RSSI value. The range is from -95 to -50 dBm (inclusive). • ssid—Requires that a rogue access point have a specific SSID.
default	Sets the command to its default settings.
exit	Exits the sub-mode.
match { all any }	Configures matching criteria for a rule. Specifies whether a detected rogue access point must meet all or any of the conditions specified by the rule in order for the rule to be matched and the rogue access point to adopt the classification type of the rule.
no	Negates a command or set its defaults.
shutdown	Shuts down the system.

Command Default

None.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

None.

Examples

This example shows how to create a rule that can organize and display rogue access points as Friendly:

```
Controller# configure terminal
Controller(config)# wireless wps rogue rule ap1 priority 1
Controller(config-rule)# classify friendly
Controller(config)# end
```

wireless wps rogue detection

To configure various rouge detection parameters, use the **wireless wps rogue detection** command.

wireless wps rogue detection [**min-rssi** *rsssi* | **min-transient-time** *transtime*]

Syntax Description

min-rssi <i>rsssi</i>	Configures the minimum RSSI value that rogues should have for APs to detect and for rogue entry to be created in the controller.
min-transient-time <i>transtime</i>	Configures the time interval at which rogues have to be consistently scanned for by APs after the first time the rogues are scanned.

Command Default

None.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

None.

Examples

This example shows how to configure rogue detection minimum RSSI value and minimum transient time:

```
Controller# configure terminal
Controller(config)# wireless wps rogue detection min-rssi 100
Controller(config)# wireless wps rogue detection min-transient-time 500
Controller(config)# end
```

vlan access-map

To create or modify a VLAN map entry for VLAN packet filtering, and change the mode to the VLAN access-map configuration, use the **vlan access-map** command in global configuration mode on the switch stack or on a standalone switch. To delete a VLAN map entry, use the **no** form of this command.

vlan access-map *name* [*number*]

no vlan access-map *name* [*number*]



Note

This command is not supported on switches running the LAN Base feature set.

Syntax Description

<i>name</i>	Name of the VLAN map.
<i>number</i>	(Optional) The sequence number of the map entry that you want to create or modify (0 to 65535). If you are creating a VLAN map and the sequence number is not specified, it is automatically assigned in increments of 10, starting from 10. This number is the sequence to insert to, or delete from, a VLAN access-map entry.

Command Default

There are no VLAN map entries and no VLAN maps applied to a VLAN.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

In global configuration mode, use this command to create or modify a VLAN map. This entry changes the mode to VLAN access-map configuration, where you can use the **match** access-map configuration command to specify the access lists for IP or non-IP traffic to match and use the **action** command to set whether a match causes the packet to be forwarded or dropped.

In VLAN access-map configuration mode, these commands are available:

- **action**—Sets the action to be taken (forward or drop).
- **default**—Sets a command to its defaults.
- **exit**—Exits from VLAN access-map configuration mode.
- **match**—Sets the values to match (IP address or MAC address).

- **no**—Negates a command or set its defaults.

When you do not specify an entry number (sequence number), it is added to the end of the map.

There can be only one VLAN map per VLAN and it is applied as packets are received by a VLAN.

You can use the **no vlan access-map** *name* [*number*] command with a sequence number to delete a single entry.

Use the **vlan filter** interface configuration command to apply a VLAN map to one or more VLANs.

For more information about VLAN map entries, see the software configuration guide for this release.

Examples

This example shows how to create a VLAN map named vac1 and apply matching conditions and actions to it. If no other entries already exist in the map, this will be entry 10.

```
Controller(config)# vlan access-map vac1
Controller(config-access-map)# match ip address acl1
Controller(config-access-map)# action forward
```

This example shows how to delete VLAN map vac1:

```
Controller(config)# no vlan access-map vac1
```

Related Commands

Command	Description
action	Sets the action for the VLAN access map entry.
match (access-map configuration)	Sets the VLAN map to match packets against one or more access lists.
show vlan access-map	Displays the VLAN access maps created on the switch.
vlan filter	Applies a VLAN map to one or more VLANs.

vlan filter

To apply a VLAN map to one or more VLANs, use the **vlan filter** command in global configuration mode on the switch stack or on a standalone switch. To remove the map, use the **no** form of this command.

vlan filter *mapname* **vlan-list** [*list*] **all**

no vlan filter *mapname* **vlan-list** [*list*] **all**



Note

This command is not supported on switches running the LAN Base feature set.

Syntax Description

<i>mapname</i>	Name of the VLAN map entry.
vlan-list	Specifies which VLANs to apply the map to.
<i>list</i>	The list of one or more VLANs in the form tt, uu-vv, xx, yy-zz, where spaces around commas and dashes are optional. The range is 1 to 4094.
all	Adds the map to all VLANs.

Command Default

There are no VLAN filters.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

To avoid accidentally dropping too many packets and disabling connectivity in the middle of the configuration process, we recommend that you completely define the VLAN access map before applying it to a VLAN.

For more information about VLAN map entries, see the software configuration guide for this release.

Examples

This example applies VLAN map entry map1 to VLANs 20 and 30:

```
Controller(config)# vlan filter map1 vlan-list 20, 30
```

This example shows how to delete VLAN map entry mac1 from VLAN 20:

```
Controller(config)# no vlan filter map1 vlan-list 20
```

You can verify your settings by entering the **show vlan filter** privileged EXEC command.

Related Commands

Command	Description
show vlan access-map	Displays the VLAN access maps created on the switch.
show vlan filter	Displays information about all VLAN filters or about a particular VLAN or VLAN access map.
vlan access-map	Defines a VLAN map and enters access-map configuration mode where you can specify a MAC ACL to match and the action to be taken.

vlan group

To create or modify a VLAN group, use the **vlan group** command in global configuration mode. To remove a VLAN list from the VLAN group, use the **no** form of this command.

vlan group *group-name* **vlan-list** *vlan-list*

no vlan group *group-name* **vlan-list** *vlan-list*

Syntax Description

<i>group-name</i>	Name of the VLAN group. The group name may contain up to 32 characters and must begin with a letter.
vlan-list <i>vlan-list</i>	Specifies one or more VLANs to be added to the VLAN group. The <i>vlan-list</i> argument can be a single VLAN ID, a list of VLAN IDs, or VLAN ID range. Multiple entries are separated by a hyphen (-) or a comma (,).

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

If the named VLAN group does not exist, the **vlan group** command creates the group and maps the specified VLAN list to the group. If the named VLAN group exists, the specified VLAN list is mapped to the group.

The **no** form of the **vlan group** command removes the specified VLAN list from the VLAN group. When you remove the last VLAN from the VLAN group, the VLAN group is deleted.

A maximum of 100 VLAN groups can be configured, and a maximum of 4094 VLANs can be mapped to a VLAN group.

Examples

This example shows how to map VLANs 7 through 9 and 11 to a VLAN group:

```
Controller(config)# vlan group group1 vlan-list 7-9,11
```

This example shows how to remove VLAN 7 from the VLAN group:

```
Controller(config)# no vlan group group1 vlan-list 7
```

Related Commands

Command	Description
show vlan group	Displays the VLANs mapped to VLAN groups.



PART **VIII**

Layer 2 (Link Aggregation)

- [Layer 2/3 Commands, page 441](#)



Layer 2/3 Commands

- [channel-group](#), page 443
- [channel-protocol](#), page 446
- [clear lacp](#), page 448
- [clear pagp](#), page 449
- [debug etherchannel](#), page 450
- [debug lacp](#), page 452
- [debug pagp](#), page 453
- [debug platform pm](#), page 455
- [debug platform udd](#), page 457
- [interface port-channel](#), page 458
- [lacp max-bundle](#), page 460
- [lacp port-priority](#), page 461
- [lacp system-priority](#), page 463
- [pagp learn-method](#), page 465
- [pagp port-priority](#), page 467
- [port-channel load-balance](#), page 469
- [port-channel load-balance extended](#), page 471
- [port-channel min-links](#), page 473
- [show etherchannel](#), page 475
- [show lacp](#), page 478
- [show pagp](#), page 483
- [show platform etherchannel](#), page 485
- [show platform pm](#), page 486
- [show udd](#), page 487

- [switchport](#), page 491
- [switchport access vlan](#), page 493
- [switchport mode](#), page 494
- [switchport nonegotiate](#), page 497
- [udld](#), page 499
- [udld port](#), page 501
- [udld reset](#), page 503

channel-group

To assign an Ethernet port to an EtherChannel group, or to enable an EtherChannel mode, or both, use the **channel-group** command in interface configuration mode. To remove an Ethernet port from an EtherChannel group, use the **no** form of this command.

channel-group *channel-group-number* **mode** {**active**|**auto** [**non-silent**]|**desirable** [**non-silent**]|**on**|**passive**}

no channel-group

Syntax Description

<i>channel-group-number</i>	Channel group number. The range is 1 to 128.
mode	Specifies the EtherChannel mode.
active	Unconditionally enables Link Aggregation Control Protocol (LACP).
auto	Enables the Port Aggregation Protocol (PAgP) only if a PAgP device is detected.
non-silent	(Optional) Configures the interface for nonsilent operation when connected to a partner that is PAgP-capable. Use in PAgP mode with the auto or desirable keyword when traffic is expected from the other device.
desirable	Unconditionally enables PAgP.
on	Enables the on mode.
passive	Enables LACP only if a LACP device is detected.

Command Default

No channel groups are assigned.
No mode is configured.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

For Layer 2 EtherChannels, the **channel-group** command automatically creates the port-channel interface when the channel group gets its first physical port. You do not have to use the **interface port-channel** command in global configuration mode to manually create a port-channel interface. If you create the port-channel

interface first, the *channel-group-number* can be the same as the *port-channel-number*, or you can use a new number. If you use a new number, the **channel-group** command dynamically creates a new port channel.

Although it is not necessary to disable the IP address that is assigned to a physical port that is part of a channel group, we strongly recommend that you do so.

You create Layer 3 port channels by using the **interface port-channel** command followed by the **no switchport** interface configuration command. Manually configure the port-channel logical interface before putting the interface into the channel group.

After you configure an EtherChannel, configuration changes that you make on the port-channel interface apply to all the physical ports assigned to the port-channel interface. Configuration changes applied to the physical port affect only the port where you apply the configuration. To change the parameters of all ports in an EtherChannel, apply configuration commands to the port-channel interface, for example, spanning-tree commands or commands to configure a Layer 2 EtherChannel as a trunk.

Active mode places a port into a negotiating state in which the port initiates negotiations with other ports by sending LACP packets. A channel is formed with another port group in either the active or passive mode.

Auto mode places a port into a passive negotiating state in which the port responds to PAgP packets it receives but does not start PAgP packet negotiation. A channel is formed only with another port group in desirable mode. When auto is enabled, silent operation is the default.

Desirable mode places a port into an active negotiating state in which the port starts negotiations with other ports by sending PAgP packets. An EtherChannel is formed with another port group that is in the desirable or auto mode. When desirable is enabled, silent operation is the default.

If you do not specify non-silent with the auto or desirable mode, silent is assumed. The silent mode is used when the controller is connected to a device that is not PAgP-capable and rarely, if ever, sends packets. An example of a silent partner is a file server or a packet analyzer that is not generating traffic. In this case, running PAgP on a physical port prevents that port from ever becoming operational. However, it allows PAgP to operate, to attach the port to a channel group, and to use the port for transmission. Both ends of the link cannot be set to silent.

In on mode, a usable EtherChannel exists only when both connected port groups are in the on mode.



Caution

Use care when using the on mode. This is a manual configuration, and ports on both ends of the EtherChannel must have the same configuration. If the group is misconfigured, packet loss or spanning-tree loops can occur.

Passive mode places a port into a negotiating state in which the port responds to received LACP packets but does not initiate LACP packet negotiation. A channel is formed only with another port group in active mode.

Do not configure an EtherChannel in both the PAgP and LACP modes. EtherChannel groups running PAgP and LACP can coexist on the same controller or on different controllers in the stack (but not in a cross-stack configuration). Individual EtherChannel groups can run either PAgP or LACP, but they cannot interoperate.

If you set the protocol by using the **channel-protocol** interface configuration command, the setting is not overridden by the **channel-group** interface configuration command.

Do not configure a port that is an active or a not-yet-active member of an EtherChannel as an IEEE 802.1x port. If you try to enable IEEE 802.1x authentication on an EtherChannel port, an error message appears, and IEEE 802.1x authentication is not enabled.

Do not configure a secure port as part of an EtherChannel or configure an EtherChannel port as a secure port.

For a complete list of configuration guidelines, see the “Configuring EtherChannels” chapter in the software configuration guide for this release.

**Caution**

Do not enable Layer 3 addresses on the physical EtherChannel ports. Do not assign bridge groups on the physical EtherChannel ports because it creates loops.

Examples

This example shows how to configure an EtherChannel on a single controller in the stack. It assigns two static-access ports in VLAN 10 to channel 5 with the PAgP mode desirable:

```
Controller# configure terminal
Controller(config)# interface range gigabitethernet2/0/1 -2
Controller(config-if-range)# switchport mode access
Controller(config-if-range)# switchport access vlan 10
Controller(config-if-range)# channel-group 5 mode desirable
Controller(config-if-range)# end
```

This example shows how to configure an EtherChannel on a single controller in the stack. It assigns two static-access ports in VLAN 10 to channel 5 with the LACP mode active:

```
Controller# configure terminal
Controller(config)# interface range gigabitethernet2/0/1 -2
Controller(config-if-range)# switchport mode access
Controller(config-if-range)# switchport access vlan 10
Controller(config-if-range)# channel-group 5 mode active
Controller(config-if-range)# end
```

This example shows how to configure a cross-stack EtherChannel in a controller stack. It uses LACP passive mode and assigns two ports on stack member 2 and one port on stack member 3 as static-access ports in VLAN 10 to channel 5:

```
Controller# configure terminal
Controller(config)# interface range gigabitethernet2/0/4 -5
Controller(config-if-range)# switchport mode access
Controller(config-if-range)# switchport access vlan 10
Controller(config-if-range)# channel-group 5 mode passive
Controller(config-if-range)# exit
Controller(config)# interface gigabitethernet3/0/3
Controller(config-if)# switchport mode access
Controller(config-if)# switchport access vlan 10
Controller(config-if)# channel-group 5 mode passive
Controller(config-if)# exit
```

You can verify your settings by entering the **show running-config** privileged EXEC command.

Related Commands

Command	Description
channel-protocol	Restricts the protocol used on a port to manage channeling.
interface port-channel	Accesses or creates a port channel.
show etherchannel	Displays EtherChannel information for a channel.
show lacp	Displays LACP channel-group information.
show pagp	Displays Port Aggregation Protocol (PAgP) channel-group information.

channel-protocol

To restrict the protocol used on a port to manage channeling, use the **channel-protocol** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

channel-protocol {lacp| pagp}

no channel-protocol

Syntax Description

lacp	Configures an EtherChannel with the Link Aggregation Control Protocol (LACP).
pagp	Configures an EtherChannel with the Port Aggregation Protocol (PAgP).

Command Default

No protocol is assigned to the EtherChannel.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use the **channel-protocol** command only to restrict a channel to LACP or PAgP. If you set the protocol by using the **channel-protocol** command, the setting is not overridden by the **channel-group** interface configuration command.

You must use the **channel-group** interface configuration command to configure the EtherChannel parameters. The **channel-group** command also can set the mode for the EtherChannel.

You cannot enable both the PAgP and LACP modes on an EtherChannel group.

PAgP and LACP are not compatible; both ends of a channel must use the same protocol.

You cannot configure PAgP on cross-stack configurations.

Examples

This example shows how to specify LACP as the protocol that manages the EtherChannel:

```
Controller(config-if)# channel-protocol lacp
```

You can verify your settings by entering the **show etherchannel** [*channel-group-number*] **protocol** privileged EXEC command.

Related Commands

Command	Description
channel-group	Assigns an Ethernet port to an EtherChannel group, or enables an EtherChannel mode, or both.
show etherchannel	Displays EtherChannel information for a channel.

clear lacp

To clear Link Aggregation Control Protocol (LACP) channel-group counters, use the **clear lacp** command in privileged EXEC mode.

clear lacp [*channel-group-number*] **counters**

Syntax Description

<i>channel-group-number</i>	(Optional) Channel group number. The range is 1 to 128.
counters	Clears traffic counters.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can clear all counters by using the **clear lacp counters** command, or you can clear only the counters for the specified channel group by using the **clear lacp *channel-group-number* counters** command.

Examples

This example shows how to clear all channel-group information:

```
Controller# clear lacp counters
```

This example shows how to clear LACP traffic counters for group 4:

```
Controller# clear lacp 4 counters
```

You can verify that the information was deleted by entering the **show lacp counters** or the **show lacp *channel-group-number* counters** privileged EXEC command.

Related Commands

Command	Description
show lacp	Displays LACP channel-group information.

clear pagp

To clear the Port Aggregation Protocol (PAgP) channel-group information, use the **clear pagp** command in privileged EXEC mode.

clear pagp [*channel-group-number*] **counters**

Syntax Description

<i>channel-group-number</i>	(Optional) Channel group number. The range is 1 to 128.
counters	Clears traffic counters.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can clear all counters by using the **clear pagp counters** command, or you can clear only the counters for the specified channel group by using the **clear pagp channel-group-number counters** command.

Examples

This example shows how to clear all channel-group information:

```
Controller# clear pagp counters
```

This example shows how to clear PAgP traffic counters for group 10:

```
Controller# clear pagp 10 counters
```

You can verify that the information was deleted by entering the **show pagp** privileged EXEC command.

Related Commands

Command	Description
debug pagp	Enables debugging of PAgP.
show pagp	Displays Port Aggregation Protocol (PAgP) channel-group information.

debug etherchannel

To enable debugging of EtherChannels, use the **debug etherchannel** command in privileged EXEC mode. To disable debugging, use the **no** form of the command.

debug etherchannel [**all** | **detail** | **error** | **event** | **idb**]

no debug etherchannel [**all** | **detail** | **error** | **event** | **idb**]

Syntax Description

all	(Optional) Displays all EtherChannel debug messages.
detail	(Optional) Displays detailed EtherChannel debug messages.
error	(Optional) Displays EtherChannel error debug messages.
event	(Optional) Displays EtherChannel event messages.
idb	(Optional) Displays PAgP interface descriptor block debug messages.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **undebug etherchannel** command is the same as the **no debug etherchannel** command.



Note

Although the **linecard** keyword is displayed in the command-line help, it is not supported.

When you enable debugging on a stack, it is enabled only on the active controller. To enable debugging on the standby controller, start a session from the active controller by using the **session switch-number** command in privileged EXEC mode. Enter the **debug** command at the command-line prompt of the standby controller.

To enable debugging on the standby controller without first starting a session on the active controller, use the **remote command switch-number LINE** command in privileged EXEC mode.

Examples

This example shows how to display all EtherChannel debug messages:

```
Controller# debug etherchannel all
```

This example shows how to display debug messages related to EtherChannel events:

```
Controller# debug etherchannel event
```

Related Commands

Command	Description
show etherchannel	Displays EtherChannel information for a channel.

debug lacp

To enable debugging of Link Aggregation Control Protocol (LACP) activity, use the **debug lacp** command in privileged EXEC mode. To disable LACP debugging, use the **no** form of this command.

debug lacp [**all** | **event** | **fsm** | **misc** | **packet**]

no debug lacp [**all** | **event** | **fsm** | **misc** | **packet**]

Syntax Description

all	(Optional) Displays all LACP debug messages.
event	(Optional) Displays LACP event debug messages.
fsm	(Optional) Displays messages about changes within the LACP finite state machine.
misc	(Optional) Displays miscellaneous LACP debug messages.
packet	(Optional) Displays the receiving and transmitting LACP control packets.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **undebug etherchannel** command is the same as the **no debug etherchannel** command.

When you enable debugging on a stack, it is enabled only on the active controller. To enable debugging on the standby controller, start a session from the active controller by using the **session switch-number** command in privileged EXEC mode. Enter the **debug** command at the command-line prompt of the standby controller.

To enable debugging on the standby controller without first starting a session on the active controller, use the **remote command switch-number LINE** command in privileged EXEC mode.

Examples

This example shows how to display all LACP debug messages:

```
Controller# debug LACP all
```

This example shows how to display debug messages related to LACP events:

```
Controller# debug LACP event
```

debug pagp

To enable debugging of Port Aggregation Protocol (PAgP) activity, use the **debug pagp** command in privileged EXEC mode. To disable PAgP debugging, use the **no** form of this command.

debug pagp [**all** | **dual-active** | **event** | **fsm** | **misc** | **packet**]

no debug pagp [**all** | **dual-active** | **event** | **fsm** | **misc** | **packet**]

Syntax Description

all	(Optional) Displays all PAgP debug messages.
dual-active	(Optional) Displays dual-active detection messages.
event	(Optional) Displays PAgP event debug messages.
fsm	(Optional) Displays messages about changes within the PAgP finite state machine.
misc	(Optional) Displays miscellaneous PAgP debug messages.
packet	(Optional) Displays the receiving and transmitting PAgP control packets.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **undebg pagp** command is the same as the **no debug pagp** command.

When you enable debugging on a stack, it is enabled only on the active controller. To enable debugging on the standby controller, start a session from the active controller by using the **session switch-number** command in privileged EXEC mode. Enter the **debug** command at the command-line prompt of the standby controller.

To enable debugging on the standby controller without first starting a session on the active controller, use the **remote command switch-number LINE** command in privileged EXEC mode.

Examples

This example shows how to display all PAgP debug messages:

```
Controller# debug pagp all
```

This example shows how to display debug messages related to PAgP events:

```
Controller# debug pagp event
```

debug platform pm

To enable debugging of the platform-dependent port manager software module, use the **debug platform pm** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug platform pm {all| counters| errdisable| fec| if-numbers| l2-control| link-status| platform| pm-spi| pm-vectors [detail]| ses| vlans}

no debug platform pm {all| counters| errdisable| fec| if-numbers| l2-control| link-status| platform| pm-spi| pm-vectors [detail]| ses| vlans}

Syntax Description

all	Displays all port manager debug messages.
counters	Displays counters for remote procedure call (RPC) debug messages.
errdisable	Displays error-disabled-related events debug messages.
fec	Displays forwarding equivalence class (FEC) platform-related events debug messages.
if-numbers	Displays interface-number translation event debug messages.
l2-control	Displays Layer 2 control infra debug messages.
link-status	Displays interface link-detection event debug messages.
platform	Displays port manager function event debug messages.
pm-spi	Displays port manager stateful packet inspection (SPI) event debug messages.
pm-vectors	Displays port manager vector-related event debug messages.
detail	(Optional) Displays vector-function details.
ses	Displays service expansion shelf (SES) related event debug messages.
vlans	Displays VLAN creation and deletion event debug messages.

Command Default Debugging is disabled.

Command Modes Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **undebg platform pm** command is the same as the **no debug platform pm** command.

When you enable debugging on a stack, it is enabled only on the active controller. To enable debugging on the standby controller, start a session from the active controller by using the **session switch-number** command in privileged EXEC mode. Enter the **debug** command at the command-line prompt of the standby controller.

To enable debugging on the standby controller without first starting a session on the active controller, use the **remote command switch-number LINE** command in privileged EXEC mode.

Examples

This example shows how to display debug messages related to the creation and deletion of VLANs:

```
Controller# debug platform pm vlans
```

debug platform udd

To enable debugging of the platform-dependent UniDirectional Link Detection (UDLD) software, use the **debug platform udd** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug platform udd [**error**| **event**] [**switch** *switch-number*]

no debug platform udd [**error**| **event**] [**switch** *switch-number*]

Syntax Description

error	(Optional) Displays error condition debug messages.
event	(Optional) Displays UDLD-related platform event debug messages.
switch <i>switch-number</i>	(Optional) Displays UDLD debug messages for the specified stack member.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **undebg platform udd** command is the same as the **no debug platform udd** command.

interface port-channel

To access or create a port channel, use the **interface port-channel** command in global configuration mode. Use the **no** form of this command to remove the port channel.

interface port-channel *port-channel-number*

no interface port-channel

Syntax Description

<i>port-channel-number</i>	Channel group number. The range is 1 to 128.
----------------------------	--

Command Default

No port channel logical interfaces are defined.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

For Layer 2 EtherChannels, you do not have to create a port-channel interface before assigning physical ports to a channel group. Instead, you can use the **channel-group** interface configuration command, which automatically creates the port-channel interface when the channel group obtains its first physical port. If you create the port-channel interface first, the *channel-group-number* can be the same as the *port-channel-number*, or you can use a new number. If you use a new number, the **channel-group** command dynamically creates a new port channel.

You create Layer 3 port channels by using the **interface port-channel** command followed by the **no switchport** interface configuration command. You should manually configure the port-channel logical interface before putting the interface into the channel group.

Only one port channel in a channel group is allowed.



Caution

When using a port-channel interface as a routed port, do not assign Layer 3 addresses on the physical ports that are assigned to the channel group.



Caution

Do not assign bridge groups on the physical ports in a channel group used as a Layer 3 port channel interface because it creates loops. You must also disable spanning tree.

Follow these guidelines when you use the **interface port-channel** command:

- If you want to use the Cisco Discovery Protocol (CDP), you must configure it on the physical port and not on the port channel interface.
- Do not configure a port that is an active member of an EtherChannel as an IEEE 802.1x port. If IEEE 802.1x is enabled on a not-yet active port of an EtherChannel, the port does not join the EtherChannel.

For a complete list of configuration guidelines, see the “Configuring EtherChannels” chapter in the software configuration guide for this release.

Examples

This example shows how to create a port channel interface with a port channel number of 5:

```
Controller(config)# interface port-channel 5
```

You can verify your setting by entering the **show running-config** privileged EXEC or **show etherchannel channel-group-number detail** privileged EXEC command.

Related Commands

Command	Description
channel-group	Assigns an Ethernet port to an EtherChannel group, or enables an EtherChannel mode, or both.
show etherchannel	Displays EtherChannel information for a channel.

lACP max-bundle

To define the maximum number of active LACP ports allowed in a port channel, use the **lACP max-bundle** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

lACP max-bundle *max_bundle_number*

no lACP max-bundle

Syntax Description

<i>max_bundle_number</i>	The maximum number of active LACP ports in the port channel. The range is 1 to 8. The default is 8.
--------------------------	---

Command Default

None

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

An LACP channel group can have up to 16 Ethernet ports of the same type. Up to eight ports can be active, and up to eight ports can be in hot-standby mode. When there are more than eight ports in an LACP channel group, the controller on the controlling end of the link uses port priorities to determine which ports are bundled into the channel and which ports are put in hot-standby mode. Port priorities on the other controller (the noncontrolling end of the link) are ignored.

The **lACP max-bundle** command must specify a number greater than the number specified by the **port-channel min-links** command.

Use the **show etherchannel summary** privileged EXEC command to see which ports are in the hot-standby mode (denoted with an H port-state flag in the output display).

Examples

This example shows how to specify a maximum of five active LACP ports in port channel 2:

```
Controller(config)# interface port-channel 2
Controller(config-if)# lACP max-bundle 5
```

Related Commands

Command	Description
port-channel min-links	Specifies the minimum number of LACP ports that must be in the link-up state and bundled in the EtherChannel in order for the port channel to become active.

lACP port-priority

To configure the port priority for the Link Aggregation Control Protocol (LACP), use the **lACP port-priority** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

lACP port-priority *priority*

no lACP port-priority

Syntax Description

priority Port priority for LACP. The range is 1 to 65535.

Command Default

The default is 32768.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **lACP port-priority** interface configuration command determines which ports are bundled and which ports are put in hot-standby mode when there are more than eight ports in an LACP channel group.

An LACP channel group can have up to 16 Ethernet ports of the same type. Up to eight ports can be active, and up to eight ports can be in standby mode.

In port-priority comparisons, a numerically lower value has a higher priority: When there are more than eight ports in an LACP channel group, the eight ports with the numerically lowest values (highest priority values) for LACP port priority are bundled into the channel group, and the lower-priority ports are put in hot-standby mode. If two or more ports have the same LACP port priority (for example, they are configured with the default setting of 65535), then an internal value for the port number determines the priority.



Note

The LACP port priorities are only effective if the ports are on the controller that controls the LACP link. See the **lACP system-priority** global configuration command for determining which controller controls the link.

Use the **show lACP internal** privileged EXEC command to display LACP port priorities and internal port number values.

For information about configuring LACP on physical ports, see the configuration guide for this release.

Examples

This example shows how to configure the LACP port priority on a port:

```
Controller# interface gigabitEthernet2/0/1
Controller(config-if)# lacp port-priority 1000
```

You can verify your settings by entering the **show lacp** [*channel-group-number*] **internal** privileged EXEC command.

Related Commands

Command	Description
channel-group	Assigns an Ethernet port to an EtherChannel group, or enables an EtherChannel mode, or both.
lacp system-priority	Configures the LACP system priority.
show lacp	Displays LACP channel-group information.

lACP system-priority

To configure the system priority for the Link Aggregation Control Protocol (LACP), use the **lACP system-priority** command in global configuration mode on the controller. To return to the default setting, use the **no** form of this command.

lACP system-priority *priority*

no lACP system-priority

Syntax Description

priority System priority for LACP. The range is 1 to 65535.

Command Default

The default is 32768.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **lACP system-priority** command determines which controller in an LACP link controls port priorities.

An LACP channel group can have up to 16 Ethernet ports of the same type. Up to eight ports can be active, and up to eight ports can be in standby mode. When there are more than eight ports in an LACP channel group, the controller on the controlling end of the link uses port priorities to determine which ports are bundled into the channel and which ports are put in hot-standby mode. Port priorities on the other controller (the noncontrolling end of the link) are ignored.

In priority comparisons, numerically lower values have a higher priority. Therefore, the system with the numerically lower value (higher priority value) for LACP system priority becomes the controlling system. If both controllers have the same LACP system priority (for example, they are both configured with the default setting of 32768), the LACP system ID (the controller MAC address) determines which controller is in control.

The **lACP system-priority** command applies to all LACP EtherChannels on the controller.

Use the **show etherchannel summary** privileged EXEC command to see which ports are in the hot-standby mode (denoted with an H port-state flag in the output display).

Examples

This example shows how to set the LACP system priority:

```
Controller(config)# lACP system-priority 20000
```

You can verify your settings by entering the **show lACP sys-id** privileged EXEC command.

Related Commands

Command	Description
channel-group	Assigns an Ethernet port to an EtherChannel group, or enables an EtherChannel mode, or both.
lacp port-priority	Configures the port priority for the Link Aggregation Control Protocol (LACP).
show lacp	Displays LACP channel-group information.

pagp learn-method

To learn the source address of incoming packets received from an EtherChannel port, use the **pagp learn-method** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

pagp learn-method {aggregation-port| physical-port}

no pagp learn-method

Syntax Description

aggregation-port	Specifies address learning on the logical port channel. The controller sends packets to the source using any port in the EtherChannel. This setting is the default. With aggregation-port learning, it is not important on which physical port the packet arrives.
physical-port	Specifies address learning on the physical port within the EtherChannel. The controller sends packets to the source using the same port in the EtherChannel from which it learned the source address. The other end of the channel uses the same port in the channel for a particular destination MAC or IP address.

Command Default

The default is aggregation-port (logical port channel).

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The learn method must be configured the same at both ends of the link.

The controller supports address learning only on aggregate ports even though the **physical-port** keyword is provided in the command-line interface (CLI). The **pagp learn-method** and the **pagp port-priority** interface configuration commands have no effect on the controller hardware, but they are required for PAgP interoperability with devices that only support address learning by physical ports.

When the link partner to the controller is a physical learner, we recommend that you configure the controller as a physical-port learner by using the **pagp learn-method physical-port** interface configuration command. We also recommend that you set the load-distribution method based on the source MAC address by using the **port-channel load-balance src-mac** global configuration command. Use the **pagp learn-method** interface configuration command only in this situation.

Examples

This example shows how to set the learning method to learn the address on the physical port within the EtherChannel:

```
Controller(config-if) # pagp learn-method physical-port
```

This example shows how to set the learning method to learn the address on the port channel within the EtherChannel:

```
Controller(config-if) # pagp learn-method aggregation-port
```

You can verify your settings by entering the **show running-config** privileged EXEC command or the **show pagp channel-group-number internal** privileged EXEC command.

Related Commands

Command	Description
pagp port-priority	Selects a port over which all traffic through the EtherChannel is sent.
show pagp	Displays Port Aggregation Protocol (PAgP) channel-group information.

pagp port-priority

To select a port over which all Port Aggregation Protocol (PAgP) traffic through the EtherChannel is sent, use the **pagp port-priority** command in interface configuration mode. If all unused ports in the EtherChannel are in hot-standby mode, they can be placed into operation if the currently selected port and link fails. To return to the default setting, use the **no** form of this command.

pagp port-priority *priority*

no pagp port-priority

Syntax Description	<i>priority</i>	Priority number. The range is from 0 to 255.
Command Default	The default is 128.	
Command Modes	Interface configuration	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines The physical port with the highest priority that is operational and has membership in the same EtherChannel is the one selected for PAgP transmission.

The controller supports address learning only on aggregate ports even though the **physical-port** keyword is provided in the command-line interface (CLI). The **pagp learn-method** and the **pagp port-priority** interface configuration commands have no effect on the controller hardware, but they are required for PAgP interoperability with devices that only support address learning by physical ports, such as the Catalyst 1900 switch.

When the link partner to the controller is a physical learner, we recommend that you configure the controller as a physical-port learner by using the **pagp learn-method physical-port** interface configuration command. We also recommend that you set the load-distribution method based on the source MAC address by using the **port-channel load-balance src-mac** global configuration command. Use the **pagp learn-method** interface configuration command only in this situation.

Examples

This example shows how to set the port priority to 200:

```
Controller(config-if)# pagp port-priority 200
```

You can verify your setting by entering the **show running-config** privileged EXEC command or the **show pagp channel-group-number internal** privileged EXEC command.

Related Commands

Command	Description
pagp learn-method	Provides the ability to learn the source address of incoming packets.
port-channel load-balance	Sets the load-distribution method among the ports in the EtherChannel.
show pagp	Displays Port Aggregation Protocol (PAgP) channel-group information.

port-channel load-balance

To set the load-distribution method among the ports in the EtherChannel, use the **port-channel load-balance** command in global configuration mode. To reset the load-balancing mechanism to the default setting, use the **no** form of this command.

port-channel load-balance { **dst-ip**| **dst-mac**| **dst-mixed-ip-port**| **dst-port**| **extended**| **src-dst-ip**| **src-dst-mac**| **src-dst-mixed-ip-port**| **src-dst-port**| **src-ip**| **src-mac**| **src-mixed-ip-port**| **src-port**}

no port-channel load-balance

Syntax Description

dst-ip	Specifies load distribution based on the destination host IP address.
dst-mac	Specifies load distribution based on the destination host MAC address. Packets to the same destination are sent on the same port, but packets to different destinations are sent on different ports in the channel.
dst-mixed-ip-port	Specifies load distribution based on the destination IPv4 or IPv6 address and the TCP/UDP (Layer 4) port number.
dst-port	Specifies load distribution based on the destination TCP/UDP (Layer 4) port number for both IPv4 and IPv6.
extended	Sets extended load balance methods among the ports in the EtherChannel. See the port-channel load-balance extended command.
src-dst-ip	Specifies load distribution based on the source and destination host IP address.
src-dst-mac	Specifies load distribution based on the source and destination host MAC address.
src-dst-mixed-ip-port	Specifies load distribution based on the source and destination host IP address and TCP/UDP (layer 4) port number.
src-dst-port	Specifies load distribution based on the source and destination TCP/UDP (Layer 4) port number.
src-ip	Specifies load distribution based on the source host IP address.
src-mac	Specifies load distribution based on the source MAC address. Packets from different hosts use different ports in the channel, but packets from the same host use the same port.
src-mixed-ip-port	Specifies load distribution based on the source host IP address and TCP/UDP (Layer 4) port number.
src-port	Specifies load distribution based on the TCP/UDP (Layer 4) port number.

Command Default The default is **src-mac**.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You can verify your setting by entering the **show running-config** privileged EXEC command or the **show etherchannel load-balance** privileged EXEC command.

Examples This example shows how to set the load-distribution method to dst-mac:

```
Controller(config)# port-channel load-balance dst-mac
```

port-channel load-balance extended

To set combinations of load-distribution methods among the ports in the EtherChannel, use the **port-channel load-balance extended** command in global configuration mode. To reset the extended load-balancing mechanism to the default setting, use the **no** form of this command.

port-channel load-balance extended[*dst-ip* | *dst-mac* | *dst-port* | *ipv6-label* | *l3-proto* | *src-ip* | *src-mac* | *src-port*]

no port-channel load-balance extended

Syntax Description

dst-ip	(Optional) Specifies load distribution based on the destination host IP address.
dst-mac	(Optional) Specifies load distribution based on the destination host MAC address. Packets to the same destination are sent on the same port, but packets to different destinations are sent on different ports in the channel.
dst-port	(Optional) Specifies load distribution based on the destination TCP/UDP (Layer 4) port number for both IPv4 and IPv6.
ipv6-label	(Optional) Specifies load distribution based on the source MAC address and IPv6 flow label.
l3-proto	(Optional) Specifies load distribution based on the source MAC address and Layer 3 protocols.
src-ip	(Optional) Specifies load distribution based on the source host IP address.
src-mac	(Optional) Specifies load distribution based on the source MAC address. Packets from different hosts use different ports in the channel, but packets from the same host use the same port.
src-port	(Optional) Specifies load distribution based on the TCP/UDP (Layer 4) port number.

Command Default

The default is **src-mac**.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

For information about when to use these forwarding methods, see the *Layer 2 Configuration Guide (Cisco WLC 5700 Series)* for this release.

You can verify your setting by entering the **show running-config** privileged EXEC command or the **show etherchannel load-balance** privileged EXEC command.

Examples

This example shows how to set the extended load-distribution method:

```
Controller(config)# port-channel load-balance extended dst-ip dst-mac src-ip
```

port-channel min-links

To define the minimum number of LACP ports that must be bundled in the link-up state and bundled in the EtherChannel in order that a port channel becomes active, use the **port-channel min-links** command in interface configuration mode. To return to the default setting, use the **no** form of this command.

port-channel min-links *min_links_number*

no port-channel min-links

Syntax Description	<i>min_links_number</i>	The minimum number of active LACP ports in the port channel. The range is 2 to 8. The default is 1.
---------------------------	-------------------------	---

Command Default	None
------------------------	------

Command Modes	Interface configuration
----------------------	-------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

An LACP channel group can have up to 16 Ethernet ports of the same type. Up to eight ports can be active, and up to eight ports can be in hot-standby mode. When there are more than eight ports in an LACP channel group, the controller on the controlling end of the link uses port priorities to determine which ports are bundled into the channel and which ports are put in hot-standby mode. Port priorities on the other controller (the noncontrolling end of the link) are ignored.

The **port-channel min-links** command must specify a number a less than the number specified by the **lacp max-bundle** command.

Use the **show etherchannel summary** privileged EXEC command to see which ports are in the hot-standby mode (denoted with an H port-state flag in the output display).

Examples

This example shows how to specify a minimum of three active LACP ports before port channel 2 becomes active:

```
Controller(config)# interface port-channel 2
Controller(config-if)# port-channel min-links 3
```

Related Commands

Command	Description
lacp max-bundle	Specifies the maximum number of LACP ports allowed in a port channel.

show etherchannel

To display EtherChannel information for a channel, use the **show etherchannel** command in user EXEC mode.

show etherchannel [*channel-group-number* | {**detail** | **port** | **port-channel** | **protocol** | **summary** }] | [**detail** | **load-balance** | **port** | **port-channel** | **protocol** | **summary**]

Syntax Description

<i>channel-group-number</i>	(Optional) Channel group number. The range is 1 to 128.
detail	(Optional) Displays detailed EtherChannel information.
load-balance	(Optional) Displays the load-balance or frame-distribution scheme among ports in the port channel.
port	(Optional) Displays EtherChannel port information.
port-channel	(Optional) Displays port-channel information.
protocol	(Optional) Displays the protocol that is being used in the channel.
summary	(Optional) Displays a one-line summary per channel group.

Command Default

None

Command Modes

User EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

If you do not specify a channel group number, all channel groups are displayed.

In the output, the passive port list field is displayed only for Layer 3 port channels. This field means that the physical port, which is still not up, is configured to be in the channel group (and indirectly is in the only port channel in the channel group).

Examples

This is an example of output from the **show etherchannel** *channel-group-number* **detail** command:

```
Controller> show etherchannel 1 detail
Group state = L2
Ports: 2   Maxports = 16
```

```

Port-channels: 1 Max Port-channels = 16
Protocol:      LACP
              Ports in the group:
              -----
Port: Gi1/0/1
-----
Port state     = Up Mstr In-Bndl
Channel group = 1      Mode = Active      Gcchange = -
Port-channel  =      PolGC = -          Pseudo port-channel = Pol
Port index    =      OLoad = 0x00       Protocol = LACP

Flags: S - Device is sending Slow LACPDU   F - Device is sending fast LACPDU
      A - Device is in active mode.         P - Device is in passive mode.

Local information:

Port      Flags  State  LACP port  Admin  Oper  Port  Port
         State Priority Key      Key    Key  Number State
Gi1/0/1  SA     bndl   32768     0x1   0x1   0x101 0x3D
Gi1/0/2  A      bndl   32768     0x0   0x1   0x0    0x3D

Age of the port in the current state: 01d:20h:06m:04s

              Ports in the group:
              -----

Port-channel: Pol (Primary Aggregator)

Age of the Port-channel = 01d:20h:20m:26s
Logical slot/port = 10/1      Number of ports = 2
HotStandBy port = null
Port state = Port-channel Ag-Inuse
Protocol = LACP

Ports in the Port-channel:

Index  Load  Port      EC state      No of bits
-----+-----+-----+-----+-----
  0     00   Gi1/0/1   Active        0
  0     00   Gi1/0/2   Active        0

Time since last port bundled: 01d:20h:24m:44s Gi1/0/2

```

This is an example of output from the **show etherchannel channel-group-number summary** command:

```

Controller> show etherchannel 1 summary
Flags: D - down P - in port-channel
      I - stand-alone s - suspended
      H - Hot-standby (LACP only)
      R - Layer3 S - Layer2
      u - unsuitable for bundling
      U - in use f - failed to allocate aggregator
      d - default port

Number of channel-groups in use: 1
Number of aggregators: 1

```

```

Group  Port-channel  Protocol  Ports
-----+-----+-----+-----
  1    Pol(SU)      LACP      Gi1/0/1(P) Gi1/0/2(P)

```

This is an example of output from the **show etherchannel channel-group-number port-channel** command:

```

Controller> show etherchannel 1 port-channel
Port-channels in the group:
-----
Port-channel: Pol (Primary Aggregator)
-----
Age of the Port-channel = 01d:20h:24m:50s
Logical slot/port = 10/1 Number of ports = 2
Logical slot/port = 10/1 Number of ports = 2
Port state = Port-channel Ag-Inuse
Protocol = LACP

```

Ports in the Port-channel:

Index	Load	Port	EC state	No of bits
0	00	Gi1/0/1	Active	0
0	00	Gi1/0/2	Active	0

Time since last port bundled: 01d:20h:24m:44s Gi1/0/2

This is an example of output from **show etherchannel protocol** command:

```
Controller# show etherchannel protocol
Channel-group listing:
```

```
-----
Group: 1
-----
Protocol: LACP
Group: 2
-----
Protocol: PAgP
```

Related Commands

Command	Description
channel-group	Assigns an Ethernet port to an EtherChannel group, or enables an EtherChannel mode, or both.
channel-protocol	Restricts the protocol used on a port to manage channeling.
interface port-channel	Accesses or creates a port channel.

show lacp

To display Link Aggregation Control Protocol (LACP) channel-group information, use the **show lacp** command in user EXEC mode.

show lacp [*channel-group-number*] {**counters**| **internal**| **neighbor**| **sys-id**}

Syntax Description

<i>channel-group-number</i>	(Optional) Channel group number. The range is 1 to 128.
counters	Displays traffic information.
internal	Displays internal information.
neighbor	Displays neighbor information.
sys-id	Displays the system identifier that is being used by LACP. The system identifier consists of the LACP system priority and the controller MAC address.

Command Default

None

Command Modes

User EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can enter any **show lacp** command to display the active channel-group information. To display specific channel information, enter the **show lacp** command with a channel-group number.

If you do not specify a channel group, information for all channel groups appears.

You can enter the *channel-group-number* to specify a channel group for all keywords except **sys-id**.

Examples

This is an example of output from the **show lacp counters** user EXEC command. The table that follows describes the fields in the display.

```

Controller> show lacp counters
          LACPDU      Marker      Marker Response  LACPDU
Port      Sent  Recv      Sent  Recv      Sent  Recv      Pkts  Err
-----
Channel group:1
Gi2/0/1      19   10         0    0         0    0         0
Gi2/0/2      14    6         0    0         0    0         0

```

Table 18: show lacp counters Field Descriptions

Field	Description
LACPDUs Sent and Recv	The number of LACP packets sent and received by a port.
Marker Sent and Recv	The number of LACP marker packets sent and received by a port.
Marker Response Sent and Recv	The number of LACP marker response packets sent and received by a port.
LACPDUs Pkts and Err	The number of unknown and illegal packets received by LACP for a port.

This is an example of output from the **show lacp internal** command:

```

Controller> show lacp 1 internal
Flags: S - Device is requesting Slow LACPDUs
       F - Device is requesting Fast LACPDUs
       A - Device is in Active mode           P - Device is in Passive mode

Channel group 1
Port      Flags  State  LACP port  Admin  Oper  Port  Port
Gi2/0/1   SA     bndl   32768      0x3    0x3   0x4   0x3D
Gi2/0/2   SA     bndl   32768      0x3    0x3   0x5   0x3D

```

The following table describes the fields in the display:

Table 19: show lacp internal Field Descriptions

Field	Description
State	<p>State of the specific port. These are the allowed values:</p> <ul style="list-style-type: none"> • --—Port is in an unknown state. • bncl—Port is attached to an aggregator and bundled with other ports. • susp—Port is in a suspended state; it is not attached to any aggregator. • hot-sby—Port is in a hot-standby state. • indiv—Port is incapable of bundling with any other port. • indep—Port is in an independent state (not bundled but able to handle data traffic. In this case, LACP is not running on the partner port). • down—Port is down.
LACP Port Priority	Port priority setting. LACP uses the port priority to put ports in standby mode when there is a hardware limitation that prevents all compatible ports from aggregating.
Admin Key	Administrative key assigned to this port. LACP automatically generates an administrative key value as a hexadecimal number. The administrative key defines the ability of a port to aggregate with other ports. A port's ability to aggregate with other ports is determined by the port physical characteristics (for example, data rate and duplex capability) and configuration restrictions that you establish.
Oper Key	Runtime operational key that is being used by this port. LACP automatically generates this value as a hexadecimal number.
Port Number	Port number.

Field	Description
Port State	<p>State variables for the port, encoded as individual bits within a single octet with these meanings:</p> <ul style="list-style-type: none"> • bit0: LACP_Activity • bit1: LACP_Timeout • bit2: Aggregation • bit3: Synchronization • bit4: Collecting • bit5: Distributing • bit6: Defaulted • bit7: Expired <p>Note In the list above, bit7 is the MSB and bit0 is the LSB.</p>

This is an example of output from the **show lacp neighbor** command:

```

Controller> show lacp neighbor
Flags: S - Device is sending Slow LACPDUs   F - Device is sending Fast LACPDUs
       A - Device is in Active mode         P - Device is in Passive mode

```

Channel group 3 neighbors

Partner's information:

Port	Partner System ID	Partner Port Number	Age	Partner Flags
Gi2/0/1	32768,0007.eb49.5e80	0xC	19s	SP
	LACP Partner Port Priority	Partner Oper Key	Partner Port State	
	32768	0x3	0x3C	

Partner's information:

Port	Partner System ID	Partner Port Number	Age	Partner Flags
Gi2/0/2	32768,0007.eb49.5e80	0xD	15s	SP
	LACP Partner Port Priority	Partner Oper Key	Partner Port State	
	32768	0x3	0x3C	

This is an example of output from the **show lacp sys-id** command:

```

Controller> show lacp sys-id
32765,0002.4b29.3a00

```

The system identification is made up of the system priority and the system MAC address. The first two bytes are the system priority, and the last six bytes are the globally administered individual MAC address associated to the system.

Related Commands

Command	Description
clear lacp	Clears the LACP channel-group information.
lacp port-priority	Configures the port priority for the Link Aggregation Control Protocol (LACP).
lacp system-priority	Configures the LACP system priority.

show pagp

To display Port Aggregation Protocol (PAgP) channel-group information, use the **show pagp** command in EXEC mode.

show pagp [*channel-group-number*] {**counters**| **dual-active**| **internal**| **neighbor**}

Syntax Description

<i>channel-group-number</i>	(Optional) Channel group number. The range is 1 to 128.
counters	Displays traffic information.
dual-active	Displays the dual-active status.
internal	Displays internal information.
neighbor	Displays neighbor information.

Command Default

None

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can enter any **show pagp** command to display the active channel-group information. To display the nonactive information, enter the **show pagp** command with a channel-group number.

Examples

This is an example of output from the **show pagp 1 counters** command:

```
Controller> show pagp 1 counters
          Information          Flush
Port      Sent  Recv    Sent  Recv
-----
Channel group: 1
  Gi1/0/1  45   42     0     0
  Gi1/0/2  45   41     0     0
```

This is an example of output from the **show pagp dual-active** command:

```
Controller> show pagp dual-active
PAgP dual-active detection enabled: Yes
PAgP dual-active version: 1.1
```

```

Channel group 1
  Dual-Active Partner Partner Partner
  Detect Capable Name Port Version
Gi1/0/1 No Controller Gi3/0/3 N/A
Gi1/0/2 No Controller Gi3/0/4 N/A
<output truncated>

```

This is an example of output from the **show pagp 1 internal** command:

```

Controller> show pagp 1 internal
Flags: S - Device is sending Slow hello. C - Device is in Consistent state.
      A - Device is in Auto mode.
Timers: H - Hello timer is running. Q - Quit timer is running.
      S - Switching timer is running. I - Interface timer is running.

Channel group 1
Port      Flags State  Timers  Hello  Partner  PAgP  Learning  Group
          SC   U6/S7  H       30s   Count  Priority Method  Ifindex
Gi1/0/1   SC   U6/S7  H       30s   1       128   Any      16
Gi1/0/2   SC   U6/S7  H       30s   1       128   Any      16

```

This is an example of output from the **show pagp 1 neighbor** command:

```

Controller> show pagp 1 neighbor

Flags: S - Device is sending Slow hello. C - Device is in Consistent state.
      A - Device is in Auto mode. P - Device learns on physical port.

Channel group 1 neighbors
Port      Partner      Partner      Partner      Group
          Name       Device ID    Port         Age  Flags  Cap.
Gi1/0/1   controller-p2 0002.4b29.4600 Gi01//1     9s  SC    10001
Gi1/0/2   controller-p2 0002.4b29.4600 Gi1/0/2     24s SC    10001

```

Related Commands

Command	Description
clear pagp	Clears PAgP channel-group information.

show platform etherchannel

To display platform-dependent EtherChannel information, use the **show platform etherchannel** command in privileged EXEC mode.

```
show platform etherchannel channel-group-number {group-mask| load-balance mac src-mac dst-mac [ip src-ip dst-ip [port src-port dst-port]]}
```

Syntax Description

<i>channel-group-number</i>	Channel group number. The range is 1 to 128.
group-mask	Displays EtherChannel group mask.
load-balance	Tests EtherChannel load-balance hash algorithm.
mac <i>src-mac dst-mac</i>	Specifies the source and destination MAC addresses.
ip <i>src-ip dst-ip</i>	(Optional) Specifies the source and destination IP addresses.
port <i>src-port dst-port</i>	(Optional) Specifies the source and destination layer port numbers.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use this command only when you are working directly with a technical support representative while troubleshooting a problem.

Do not use this command unless a technical support representative asks you to do so.

show platform pm

To display platform-dependent port manager information, use the **show platform pm** command in privileged EXEC mode.

show platform pm {**etherchannel** *channel-group-number* **group-mask**| **interface-numbers**| **port-data** *interface-id*| **port-state**| **spi-info**| **spi-req-q**}

Syntax Description

etherchannel <i>channel-group-number</i> group-mask	Displays the EtherChannel group-mask table for the specified channel group. The range is 1 to 128.
interface-numbers	Displays interface numbers information.
port-data <i>interface-id</i>	Displays port data information for the specified interface.
port-state	Displays port state information.
spi-info	Displays stateful packet inspection (SPI) information.
spi-req-q	Displays stateful packet inspection (SPI) maximum wait time for acknowledgment.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use this command only when you are working directly with your technical support representative while troubleshooting a problem.

Do not use this command unless your technical support representative asks you to do so.

show uddl

To display UniDirectional Link Detection (UDLD) administrative and operational status for all ports or the specified port, use the **show uddl** command in user EXEC mode.

show uddl [**Auto-Template** | **Capwap** | **GigabitEthernet** | **GroupVI** | **InternalInterface** | **Loopback** | **Null** | **Port-channel** | **TenGigabitEthernet** | **Tunnel** | **Vlan**] *interface_number*

show uddl neighbors

Syntax Description

Auto-Template	(Optional) Displays UDLD operational status of the auto-template interface. The range is from 1 to 999.
Capwap	(Optional) Displays UDLD operational status of the CAPWAP interface. The range is from 0 to 2147483647.
GigabitEthernet	(Optional) Displays UDLD operational status of the GigabitEthernet interface. The range is from 0 to 9.
GroupVI	(Optional) Displays UDLD operational status of the group virtual interface. The range is from 1 to 255.
InternalInterface	(Optional) Displays UDLD operational status of the internal interface. The range is from 0 to 9.
Loopback	(Optional) Displays UDLD operational status of the loopback interface. The range is from 0 to 2147483647.
Null	(Optional) Displays UDLD operational status of the null interface.
Port-channel	(Optional) Displays UDLD operational status of the Ethernet channel interfaces. The range is from 1 to 128.
TenGigabitEthernet	(Optional) Displays UDLD operational status of the Ten Gigabit Ethernet interface. The range is from 0 to 9.
Tunnel	(Optional) Displays UDLD operational status of the tunnel interface. The range is from 0 to 2147483647.
Vlan	(Optional) Displays UDLD operational status of the VLAN interface. The range is from 1 to 4095.
<i>interface-id</i>	(Optional) ID of the interface and port number. Valid interfaces include physical ports, VLANs, and port channels.
neighbors	(Optional) Displays neighbor information only.

Command Default None

Command Modes User EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines If you do not enter an interface ID, administrative and operational UDLD status for all interfaces appear.

Examples This is an example of output from the **show udld interface-id** command. For this display, UDLD is enabled on both ends of the link, and UDLD detects that the link is bidirectional. The table that follows describes the fields in this display.

```

Controller> show udld gigabitethernet2/0/1
Interface gi2/0/1
---
Port enable administrative configuration setting: Follows device default
Port enable operational state: Enabled
Current bidirectional state: Bidirectional
Current operational state: Advertisement - Single Neighbor detected
Message interval: 60
Time out interval: 5
Entry 1
Expiration time: 146
Device ID: 1
Current neighbor state: Bidirectional
Device name: Switch-A
Port ID: Gi2/0/1
Neighbor echo 1 device: Switch-B
Neighbor echo 1 port: Gi2/0/2
Message interval: 5
CDP Device name: Switch-A

```

Table 20: show udld Field Descriptions

Field	Description
Interface	The interface on the local device configured for UDLD.
Port enable administrative configuration setting	How UDLD is configured on the port. If UDLD is enabled or disabled, the port enable configuration setting is the same as the operational enable state. Otherwise, the enable operational setting depends on the global enable setting.
Port enable operational state	Operational state that shows whether UDLD is actually running on this port.

Field	Description
Current bidirectional state	The bidirectional state of the link. An unknown state appears if the link is down or if it is connected to an UDLD-incapable device. A bidirectional state appears if the link is a normal two-way connection to a UDLD-capable device. All other values mean miswiring.
Current operational state	The current phase of the UDLD state machine. For a normal bidirectional link, the state machine is most often in the Advertisement phase.
Message interval	How often advertisement messages are sent from the local device. Measured in seconds.
Time out interval	The time period, in seconds, that UDLD waits for echoes from a neighbor device during the detection window.
Entry 1	Information from the first cache entry, which contains a copy of echo information received from the neighbor.
Expiration time	The amount of time in seconds remaining before this cache entry is aged out.
Device ID	The neighbor device identification.
Current neighbor state	The neighbor's current state. If both the local and neighbor devices are running UDLD normally, the neighbor state and local state should be bidirectional. If the link is down or the neighbor is not UDLD-capable, no cache entries appear.
Device name	The device name or the system serial number of the neighbor. The system serial number appears if the device name is not set or is set to the default (Switch).
Port ID	The neighbor port ID enabled for UDLD.
Neighbor echo 1 device	The device name of the neighbors' neighbor from which the echo originated.
Neighbor echo 1 port	The port number ID of the neighbor from which the echo originated.
Message interval	The rate, in seconds, at which the neighbor is sending advertisement messages.

Field	Description
CDP device name	The CDP device name or the system serial number. The system serial number appears if the device name is not set or is set to the default (Switch).

This is an example of output from the **show udd neighbors** command:

```

Controller# show udd neighbors
Port      Device Name      Device ID  Port-ID  OperState
-----
Gi2/0/1   Switch-A         1         Gi2/0/1  Bidirectional
Gi3/0/1   Switch-A         2         Gi3/0/1  Bidirectional

```

Related Commands

Command	Description
udd	Enables aggressive or normal mode in UDLD or sets the configurable message timer time.
udd port	Enables UDLD on an individual interface or prevents a fiber-optic interface from being enabled by the udd global configuration command.
udd reset	Resets all interfaces shut down by UDLD and permits traffic to pass through again.

switchport

To put an interface that is in Layer 3 mode into Layer 2 mode for Layer 2 configuration, use the **switchport** command in interface configuration mode. To put an interface in Layer 3 mode, use the **no** form of this command.

switchport

no switchport

Syntax Description This command has no arguments or keywords.

Command Default By default, all interfaces are in Layer 2 mode.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Use the **no switchport** command (without parameters) to set the interface to the routed-interface status and to erase all Layer 2 configurations. You must use this command before assigning an IP address to a routed port.



Note

This command is not supported on controllers running the LAN Base feature set.

Entering the **no switchport** command shuts the port down and then reenables it, which might generate messages on the device to which the port is connected.

When you put an interface that is in Layer 2 mode into Layer 3 mode (or the reverse), the previous configuration information related to the affected interface might be lost, and the interface is returned to its default configuration.



Note

If an interface is configured as a Layer 3 interface, you must first enter the **switchport** command to configure the interface as a Layer 2 port. Then you can enter the **switchport access vlan** and **switchport mode** commands.

The **switchport** command is not used on platforms that do not support Cisco-routed ports. All physical ports on such platforms are assumed to be Layer 2-switched interfaces.

You can verify the port status of an interface by entering the **show running-config** privileged EXEC command.

Examples

This example shows how to cause an interface to cease operating as a Layer 2 port and become a Cisco-routed port:

```
Controller(config-if) # no switchport
```

This example shows how to cause the port interface to cease operating as a Cisco-routed port and convert to a Layer 2 switched interface:

```
Controller(config-if) # switchport
```

switchport access vlan

To configure a port as a static-access port, use the **switchport access vlan** command in interface configuration mode. To reset the access mode to the default VLAN mode for the controller, use the **no** form of this command.

switchport access vlan *vlan-id*

no switchport access vlan

Syntax Description

<i>vlan-id</i>	VLAN ID of the access mode VLAN; the range is 1 to 4094.
----------------	--

Command Default

The default access VLAN and trunk interface native VLAN is a default VLAN corresponding to the platform or interface hardware.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The port must be in access mode before the **switchport access vlan** command can take effect.

If the switchport mode is set to **access vlan** *vlan-id*, the port operates as a member of the specified VLAN. An access port can be assigned to only one VLAN.

The **no switchport access** command resets the access mode VLAN to the appropriate default VLAN for the device.

Examples

This example shows how to change a switched port interface that is operating in access mode to operate in VLAN 2 instead of the default VLAN:

```
Controller(config-if)# switchport access vlan 2
```

Related Commands

Command	Description
switchport mode	Configures the VLAN membership mode of a port.

switchport mode

To configure the VLAN membership mode of a port, use the **switchport mode** command in interface configuration mode. To reset the mode to the appropriate default for the device, use the **no** form of this command.

switchport mode {access| dynamic | {auto| desirable}| trunk}

noswitchport mode {access| dynamic | {auto| desirable}| trunk}

Syntax Description

access	Sets the port to access mode (either static-access or dynamic-access depending on the setting of the switchport access vlan interface configuration command). The port is set to access unconditionally and operates as a nontrunking, single VLAN interface that sends and receives nonencapsulated (non-tagged) frames. An access port can be assigned to only one VLAN.
dynamic auto	Sets the port trunking mode dynamic parameter to auto to specify that the interface convert the link to a trunk link. This is the default switchport mode.
dynamic desirable	Sets the port trunking mode dynamic parameter to desirable to specify that the interface actively attempt to convert the link to a trunk link.
trunk	Sets the port to trunk unconditionally. The port is a trunking VLAN Layer 2 interface. The port sends and receives encapsulated (tagged) frames that identify the VLAN of origination. A trunk is a point-to-point link between two controllers or between a controller and a router.

Command Default

The default mode is **dynamic auto**.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Note

Although visible in the CLI, the **dot1q-tunnel** keyword is not supported.

A configuration that uses the **access**, or **trunk** keywords takes effect only when you configure the port in the appropriate mode by using the **switchport mode** command. The static-access and trunk configuration are saved, but only one configuration is active at a time.

When you enter **access** mode, the interface changes to permanent nontrunking mode and negotiates to convert the link into a nontrunk link even if the neighboring interface does not agree to the change.

When you enter **trunk** mode, the interface changes to permanent trunking mode and negotiates to convert the link into a trunk link even if the interface connecting to it does not agree to the change.

When you enter **dynamic auto** mode, the interface converts the link to a trunk link if the neighboring interface is set to **trunk** or **desirable** mode.

When you enter **dynamic desirable** mode, the interface becomes a trunk interface if the neighboring interface is set to **trunk**, **desirable**, or **auto** mode.

To autonegotiate trunking, the interfaces must be in the same VLAN Trunking Protocol (VTP) domain. Trunk negotiation is managed by the Dynamic Trunking Protocol (DTP), which is a point-to-point protocol. However, some internetworking devices might forward DTP frames improperly, which could cause misconfigurations. To avoid this problem, configure interfaces connected to devices that do not support DTP to not forward DTP frames, which turns off DTP.

- If you do not intend to trunk across those links, use the **switchport mode access** interface configuration command to disable trunking.
- To enable trunking to a device that does not support DTP, use the **switchport mode trunk** and **switchport nonegotiate** interface configuration commands to cause the interface to become a trunk but to not generate DTP frames.

Access ports and trunk ports are mutually exclusive.

The IEEE 802.1x feature interacts with switchport modes in these ways:

- If you try to enable IEEE 802.1x on a trunk port, an error message appears, and IEEE 802.1x is not enabled. If you try to change the mode of an IEEE 802.1x-enabled port to trunk, the port mode is not changed.
- If you try to enable IEEE 802.1x on a port set to **dynamic auto** or **dynamic desirable**, an error message appears, and IEEE 802.1x is not enabled. If you try to change the mode of an IEEE 802.1x-enabled port to **dynamic auto** or **dynamic desirable**, the port mode is not changed.
- If you try to enable IEEE 802.1x on a dynamic-access (VLAN Query Protocol [VQP]) port, an error message appears, and IEEE 802.1x is not enabled. If you try to change an IEEE 802.1x-enabled port to dynamic VLAN assignment, an error message appears, and the VLAN configuration is not changed.

You can verify your settings by entering the **show interfaces interface-id switchport** privileged EXEC command and examining information in the *Administrative Mode* and *Operational Mode* rows.

Examples

This example shows how to configure a port for access mode:

```
Controller(config)# interface gigabitethernet2/0/1
Controller(config-if)# switchport mode access
```

This example shows how set the port to dynamic desirable mode:

```
Controller(config)# interface gigabitethernet2/0/1
Controller(config-if)# switchport mode dynamic desirable
```

This example shows how to configure a port for trunk mode:

```
Controller(config)# interface gigabitethernet2/0/1
Controller(config-if)# switchport mode trunk
```

Related Commands

Command	Description
switchport access vlan	Configures a port as a static-access port.

switchport nonegotiate

To specify that Dynamic Trunking Protocol (DTP) negotiation packets are not sent on the Layer 2 interface, use the **switchport nonegotiate** command in interface configuration mode. Use the **no** form of this command to return to the default setting.

switchport nonegotiate

no switchport nonegotiate

Syntax Description

This command has no arguments or keywords.

Command Default

The default is to use DTP negotiation to learn the trunking status.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **no switchport nonegotiate** command removes nonegotiate status.

This command is valid only when the interface switchport mode is access or trunk (configured by using the **switchport mode access** or the **switchport mode trunk** interface configuration command). This command returns an error if you attempt to execute it in dynamic (auto or desirable) mode.

Internetworking devices that do not support DTP might forward DTP frames improperly and cause misconfigurations. To avoid this problem, turn off DTP by using the **switchport nonegotiate** command to configure the interfaces connected to devices that do not support DTP to not forward DTP frames.

When you enter the **switchport nonegotiate** command, DTP negotiation packets are not sent on the interface. The device does or does not trunk according to the **mode** parameter: **access** or **trunk**.

- If you do not intend to trunk across those links, use the **switchport mode access** interface configuration command to disable trunking.
- To enable trunking on a device that does not support DTP, use the **switchport mode trunk** and **switchport nonegotiate** interface configuration commands to cause the interface to become a trunk but to not generate DTP frames.

Examples

This example shows how to cause a port to refrain from negotiating trunking mode and to act as a trunk or access port (depending on the mode set):

```
Controller(config)# interface gigabitethernet2/0/1
Controller(config-if)# switchport nonegotiate
```

You can verify your setting by entering the **show interfaces *interface-id* switchport** privileged EXEC command.

Related Commands

Command	Description
switchport mode	Configures the VLAN membership mode of a port.

udld

To enable aggressive or normal mode in the UniDirectional Link Detection (UDLD) and to set the configurable message timer time, use the **udld** command in global configuration mode. To disable aggressive or normal mode UDLD on all fiber-optic ports, use the **no** form of the command.

udld {**aggressive**| **enable**| **message time** *message-timer-interval*}

no udld {**aggressive**| **enable**| **message**}

Syntax Description

aggressive	Enables UDLD in aggressive mode on all fiber-optic interfaces.
enable	Enables UDLD in normal mode on all fiber-optic interfaces.
message time <i>message-timer-interval</i>	Configures the period of time between UDLD probe messages on ports that are in the advertisement phase and are determined to be bidirectional. The range is 1 to 90 seconds. The default is 15 seconds.

Command Default

UDLD is disabled on all interfaces.

The message timer is set at 15 seconds.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

UDLD supports two modes of operation: normal (the default) and aggressive. In normal mode, UDLD detects unidirectional links due to misconnected interfaces on fiber-optic connections. In aggressive mode, UDLD also detects unidirectional links due to one-way traffic on fiber-optic and twisted-pair links and due to misconnected interfaces on fiber-optic links. For information about normal and aggressive modes, see the *Catalyst 2960-X Switch Layer 2 Configuration Guide*, *Catalyst 2960-XR Switch Layer 2 Configuration Guide*, and *Layer 2 Configuration Guide (Cisco WLC 5700 Series)*.

If you change the message time between probe packets, you are making a compromise between the detection speed and the CPU load. By decreasing the time, you can make the detection-response faster but increase the load on the CPU.

This command affects fiber-optic interfaces only. Use the **udld** interface configuration command to enable UDLD on other interface types.

You can use these commands to reset an interface shut down by UDLD:

- The **udld reset** privileged EXEC command to reset all interfaces shut down by UDLD.

- The **shutdown** and **no shutdown** interface configuration commands.
- The **no udld enable** global configuration command followed by the **udld {aggressive | enable}** global configuration command to reenabte UDLD globally.
- The **no udld port** interface configuration command followed by the **udld port** or **udld port aggressive** interface configuration command to reenabte UDLD on the specified interface.
- The **errdisable recovery cause udld** and **errdisable recovery interval *interval*** global configuration commands to automatically recover from the UDLD error-disabled state.

Examples

This example shows how to enable UDLD on all fiber-optic interfaces:

```
Controller(config)# udld enable
```

You can verify your setting by entering the **show udld** privileged EXEC command.

Related Commands

Command	Description
show udld	Displays UDLD administrative and operational status for all ports or the specified port.
udld port	Enables UDLD on an individual interface or prevents a fiber-optic interface from being enabled by the udld global configuration command.
udld reset	Resets all interfaces shut down by UDLD and permits traffic to pass through again.

udld port

To enable UniDirectional Link Detection (UDLD) on an individual interface or to prevent a fiber-optic interface from being enabled by the **udld** global configuration command, use the **udld port** command in interface configuration mode. To return to the **udld** global configuration command setting or to disable UDLD if entered for a nonfiber-optic port, use the **no** form of this command.

udld port [aggressive]

no udld port [aggressive]

Syntax Description

aggressive	(Optional) Enables UDLD in aggressive mode on the specified interface.
-------------------	--

Command Default

On fiber-optic interfaces, UDLD is disabled and fiber-optic interfaces enable UDLD according to the state of the **udld enable** or **udld aggressive** global configuration command.

On nonfiber-optic interfaces, UDLD is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A UDLD-capable port cannot detect a unidirectional link if it is connected to a UDLD-incapable port of another controller.

UDLD supports two modes of operation: normal (the default) and aggressive. In normal mode, UDLD detects unidirectional links due to misconnected interfaces on fiber-optic connections. In aggressive mode, UDLD also detects unidirectional links due to one-way traffic on fiber-optic and twisted-pair links and due to misconnected interfaces on fiber-optic links.

To enable UDLD in normal mode, use the **udld port** interface configuration command. To enable UDLD in aggressive mode, use the **udld port aggressive** interface configuration command.

Use the **no udld port** command on fiber-optic ports to return control of UDLD to the **udld enable** global configuration command or to disable UDLD on nonfiber-optic ports.

Use the **udld port aggressive** command on fiber-optic ports to override the setting of the **udld enable** or **udld aggressive** global configuration command. Use the **no** form on fiber-optic ports to remove this setting and to return control of UDLD enabling to the **udld** global configuration command or to disable UDLD on nonfiber-optic ports.

You can use these commands to reset an interface shut down by UDLD:

- The **udld reset** privileged EXEC command resets all interfaces shut down by UDLD.

- The **shutdown** and **no shutdown** interface configuration commands.
- The **no udld enable** global configuration command, followed by the **udld {aggressive | enable}** global configuration command reenables UDLD globally.
- The **no udld port** interface configuration command, followed by the **udld port** or **udld port aggressive** interface configuration command reenables UDLD on the specified interface.
- The **errdisable recovery cause udld** and **errdisable recovery interval *interval*** global configuration commands automatically recover from the UDLD error-disabled state.

Examples

This example shows how to enable UDLD on an port:

```
Controller(config)# interface gigabitethernet6/0/1
Controller(config-if)# udld port
```

This example shows how to disable UDLD on a fiber-optic interface despite the setting of the **udld** global configuration command:

```
Controller(config)# interface gigabitethernet6/0/1
Controller(config-if)# no udld port
```

You can verify your settings by entering the **show running-config** or the **show udld interface** privileged EXEC command.

Related Commands

Command	Description
show udld	Displays UDLD administrative and operational status for all ports or the specified port.
udld	Enables aggressive or normal mode in UDLD or sets the configurable message timer time.
udld reset	Resets all interfaces shut down by UDLD and permits traffic to pass through again.

udld reset

To reset all interfaces disabled by UniDirectional Link Detection (UDLD) and permit traffic to begin passing through them again (though other features, such as spanning tree, Port Aggregation Protocol (PAgP), and Dynamic Trunking Protocol (DTP) still have their normal effects, if enabled), use the **udld reset** command in privileged EXEC mode.

udld reset

Syntax Description

This command has no arguments or keywords.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

If the interface configuration is still enabled for UDLD, these ports begin to run UDLD again and are disabled for the same reason if the problem has not been corrected.

Examples

This example shows how to reset all interfaces disabled by UDLD:

```
Controller# udld reset
1 ports shutdown by UDLD were reset.
```

Related Commands

Command	Description
show udld	Displays UDLD administrative and operational status for all ports or the specified port.
udld	Enables aggressive or normal mode in UDLD or sets the configurable message timer time.
udld port	Enables UDLD on an individual interface or prevents a fiber-optic interface from being enabled by the udld global configuration command.



PART IX

WLAN

- [WLAN Commands, page 507](#)



WLAN Commands

- [aaa-override](#), page 509
- [accounting-list](#), page 510
- [assisted-roaming](#), page 511
- [band-select](#), page 513
- [broadcast-ssid](#), page 514
- [call-snoop](#), page 515
- [channel-scan defer-priority](#), page 517
- [channel-scan defer-time](#), page 518
- [chd](#), page 519
- [client association limit](#), page 520
- [client vlan](#), page 522
- [cex aironet-iesupport](#), page 523
- [datalink flow monitor](#), page 524
- [default](#), page 526
- [dtim dot11](#), page 529
- [exclusionlist](#), page 530
- [exit](#), page 531
- [exit \(WLAN AP Group\)](#), page 532
- [ip access-group](#), page 533
- [ip flow monitor](#), page 534
- [ip verify source mac-check](#), page 535
- [load-balance](#), page 536
- [mobility anchor](#), page 537
- [nac](#), page 539

- [passive-client](#), page 540
- [peer-blocking](#), page 541
- [radio](#), page 542
- [radio-policy](#), page 544
- [roamed-voice-client re-anchor](#), page 546
- [security ft](#), page 547
- [security pmf](#), page 549
- [security web-auth](#), page 551
- [security wpa akm](#), page 552
- [service-policy \(WLAN\)](#), page 554
- [session-timeout](#), page 556
- [show wlan](#), page 557
- [shutdown](#), page 560
- [sip-cac](#), page 561
- [static-ip tunneling](#), page 562
- [vlan](#), page 563
- [wgb non-cisco](#), page 564
- [wifidirect policy](#), page 565
- [wlan \(AP Group Configuration\)](#), page 566
- [wlan](#), page 567
- [wlan shutdown](#), page 568
- [wmm](#), page 569

aaa-override

To enable AAA override on the WLAN, use the **aaa-override** command. To disable AAA override, use the **no** form of this command.

aaa-override

no aaa-override

Syntax Description This command has no keywords or arguments.

Command Default AAA is disabled by default.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples This example shows how to enable AAA on a WLAN:

```

Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# shutdown
Controller(config-wlan)# aaa-override
Controller(config-wlan)# no shutdown
Controller(config-wlan)# end

```

This example shows how to disable AAA on a WLAN:

```

Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# shutdown
Controller(config-wlan)# no aaa-override
Controller(config-wlan)# no shutdown
Controller(config-wlan)# end

```

Related Commands	Command	Description
	wlan	Creates or disables a WLAN.

accounting-list

To configure RADIUS accounting servers on a WLAN, use the **accounting-list** command. To disable RADIUS server accounting, use the **no** form of this command.

accounting-list *radius-server-acct*

no accounting-list

Syntax Description

<i>radius-server-acct</i>	Accounting RADIUS server name.
---------------------------	--------------------------------

Command Default

RADIUS server accounting is disabled by default.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to configure RADIUS server accounting on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# accounting-list test
Controller(config-wlan)# end
```

This example shows how to disable RADIUS server accounting on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no accounting-list test
Controller(config-wlan)# end
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.

assisted-roaming

To configure assisted roaming using 802.11k on a WLAN, use the **assisted-roaming** command. To disable assisted roaming, use the **no** form of this command.

assisted-roaming {**dual-list**| **neighbor-list**| **prediction**}

no assisted-roaming {**dual-list**| **neighbor-list**| **prediction**}

Syntax Description

dual-list	Configures a dual band 802.11k neighbor list for a WLAN. The default is the band that the client is currently associated with.
neighbor-list	Configures an 802.11k neighbor list for a WLAN.
prediction	Configures assisted roaming optimization prediction for a WLAN.

Command Default

Neighbor list and dual band support are enabled by default. The default is the band that the client is currently associated with.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

When you enable the assisted roaming prediction list, a warning appears and load balancing is disabled for the WLAN if load balancing is already enabled on the WLAN. To make changes to the WLAN, the WLAN must be in disabled state.

Examples

The following example shows how to configure a 802.11k neighbor list on a WLAN:

```
Controller(config-wlan)#assisted-roaming neighbor-list
```

The following example shows the warning message when load balancing is enabled on a WLAN. Load balancing must be disabled if it is already enabled when configuring assisted roaming:

```
Controller(config)#wlan test-prediction 2 test-prediction
Controller(config-wlan)#client vlan 43
Controller(config-wlan)#no security wpa
Controller(config-wlan)#load-balance
Controller(config-wlan)#assisted-roaming prediction
WARNING: Enabling neighbor list prediction optimization may slow association and impact
VOICE client perform.
Are you sure you want to continue? (y/n)[y]: y
```

% Request aborted - Must first disable Load Balancing before enabling Assisted Roaming Prediction Optimization on this WLAN.

band-select

To configure band selection on a WLAN, use the **band-select** command. To disable band selection, use the **no** form of this command.

band-select

no band-select

Syntax Description This command has no keywords or arguments.

Command Default Band selection is disabled by default.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines When you enable band select on a WLAN, the access point suppresses client probes on 2.4GHz and moves the dual band clients to the 5-GHz spectrum. The band-selection algorithm directs dual-band clients only from the 2.4-GHz radio to the 5-GHz radio of the same access point, and it only runs on an access point when both the 2.4-GHz and 5-GHz radios are up and running.

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples This example shows how to enable band select on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# band-select
Controller(config-wlan)# end
```

This example shows how to disable band selection on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no band-select
Controller(config-wlan)# end
```

Related Commands	Command	Description
	wlan	Creates or disables a WLAN.

broadcast-ssid

To enable a Service Set Identifier (SSID) on a WLAN, use the **broadcast-ssid** command. To disable broadcasting of SSID, use the **no** form of this command.

broadcast-ssid

no broadcast-ssid

Syntax Description This command has no keywords or arguments.

Command Default The SSIDs of WLANs are broadcasted by default.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples This example shows how to enable a broadcast SSID on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# broadcast-ssid
Controller(config-wlan)# end
```

This example shows how to disable a broadcast SSID on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no broadcast-ssid
Controller(config-wlan)# end
```

Related Commands	Command	Description
	wlan	Creates or disables a WLAN.

call-snoop

To enable Voice over IP (VoIP) snooping on a WLAN, use the **call-snoop** command. To disable Voice over IP (VoIP), use the **no** form of this command.

call-snoop

no call-snoop

Syntax Description This command has no keywords or arguments.

Command Default VoIP snooping is disabled by default.

Command Modes WLAN configuration

Usage Guidelines You must disable the WLAN before using this command. See the Related Commands section for more information on how to disable a WLAN.

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines The WLAN on which call snooping is configured must be configured with Platinum QoS. You must disable quality of service before using this command. See Related Commands section for more information on configuring QoS service-policy.

Examples This example shows how to enable VoIP on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# call-snoop
Controller(config-wlan)# end
```

This example shows how to disable VoIP on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no call-snoop
Controller(config-wlan)# end
```

Related Commands	Command	Description
	service-policy (WLAN)	Configures the QoS Policy on a WLAN.

Command	Description
wlan	Creates or disables a WLAN.

channel-scan defer-priority

To configure the device to defer priority markings for packets that can defer off-channel scanning, use the **channel-scan defer-priority** command. To disable the device to defer priority markings for packets that can defer off-channel scanning, use the **no** form of this command.

channel-scan defer-priority *priority*

no channel-scan defer-priority *priority*

Syntax Description	<i>priority</i>	Channel priority value. The range is 0 to 7. The default is 3.
Command Default	Channel scan defer is enabled.	
Command Modes	WLAN configuration	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable channel scan defer priority on a WLAN and set it to a priority value 4:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# channel-scan defer-priority 4
Controller(config-wlan)# end
```

This example shows how to disable channel scan defer priority on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no channel-scan defer-priority 4
Controller(config-wlan)# end
```

channel-scan defer-time

To assign a channel scan defer time, use the **channel-scan defer-time** command. To disable the channel scan defer time, use the **no** form of this command.

channel-scan defer-time *msecs*

no channel-scan defer-time

Syntax Description

<i>msecs</i>	Deferral time in milliseconds. The range is from 0 to 60000. The default is 100.
--------------	--

Command Default

Channel-scan defer time is enabled.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The time value in milliseconds should match the requirements of the equipment on the WLAN.

Examples

This example shows how to enable a channel scan on the WLAN and set the scan deferral time to 300 milliseconds:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# channel-scan defer-time 300
Controller(config-wlan)# end
```

This example shows how to disable channel scan defer time on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no channel-scan defer-time
Controller(config-wlan)# end
```

chd

To enable coverage hole detection on a WLAN, use the **chd** command. To disable coverage hole detection, use the **no** form of this command.

chd

no chd

Syntax Description This command has no keywords or arguments.

Command Default Coverage hole detection is enabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable coverage hole detection on a WLAN:

```

Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# chd
Controller(config-wlan)# end

```

This example shows how to disable coverage hole detection on a WLAN:

```

Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no chd
Controller(config-wlan)# end

```

client association limit

To configure the maximum number of client connections, clients per access points, or clients per access point radio on a WLAN, use the **client association limit** command. To disable clients on the WLAN, use the **no** form of this command.

client association limit {*association-limit*| **ap** *ap-limit*| **radio** *max-ap-radio-limit*}

no client association limit {*association-limit*| **ap** *ap-limit*| **radio** *max-ap-radio-limit*}

Syntax Description

<i>association-limit</i>	Number of client connections to be accepted. The range is from 0 to 12000. A value of zero (0) indicates no set limit.
ap	Maximum number of clients per access point.
<i>ap-limit</i>	Configures the maximum number of client connections to be accepted per access point radio. The valid range is from 0 to 400.
radio	Configures the maximum number of clients per AP radio.
<i>max-ap-radio-limit</i>	Maximum number of client connections to be accepted per access point radio. The valid range is from 0 - 200.

Command Default

The maximum number of client connections is set to 0 (no limit).

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.
Cisco IOS XE 3.3SE	The command was modified. The ap and radio keywords were added.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to configure a client association limit on a WLAN and configure the client limit to 200:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# shutdown
Controller(config-wlan)# client association limit 200
Controller(config-wlan)# no shutdown
Controller(config-wlan)# end
```

This example shows how to disable a client association limit on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# shutdown
Controller(config-wlan)# no client association limit
Controller(config-wlan)# no shutdown
Controller(config-wlan)# end
```

This example shows how to configure a client association limit per radio on a WLAN and configure the client limit to 200:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# client association limit radio 200
Controller(config-wlan)# no shutdown
Controller(config-wlan)# end
```

This example shows how to configure a client association limit per AP on a WLAN and configure the client limit to 300::

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# client association limit ap 300
Controller(config-wlan)# no shutdown
Controller(config-wlan)# end
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.

client vlan

To configure a WLAN interface or an interface group, use the **client vlan** command. To disable the WLAN interface, use the **no** form of this command.

client vlan *interface-id-name-or-group-name*

no client vlan

Syntax Description

<i>interface--id-name-or-group-name</i>	Interface ID, name, or VLAN group name.
---	---

Command Default

The default interface is configured.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to enable a client VLAN on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# client vlan client-vlan1
Controller(config-wlan)# end
```

This example shows how to disable a client association limit on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no client vlan
Controller(config-wlan)# end
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.

ccx aironet-iesupport

To enable Aironet Information Elements (IEs) for a WLAN, use the **ccx aironet-iesupport** command. To disable Aironet Information Elements (IEs), use the **no** form of this command.

ccx aironet-iesupport

no ccx aironet-iesupport

Syntax Description

This command has no keywords or arguments.

Command Default

Aironet IE support is enabled.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to enable an Aironet IE for a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# ccx aironet-iesupport
Controller(config-wlan)# end
```

This example shows how to disable an Aironet IE on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no ccx aironet-iesupport
Controller(config-wlan)# end
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.

datalink flow monitor

To enable NetFlow monitoring in a WLAN, use the **datalink flow monitor** command. To disable NetFlow monitoring, use the **no** form of this command.

datalink flow monitor *datalink-monitor-name* {**input**| **output**}

no datalink flow monitor *datalink-monitor-name* {**input**| **output**}

Syntax Description

<i>datalink-monitor-name</i>	Flow monitor name. The datalink monitor name can have up to 31 characters.
input	Specifies the NetFlow monitor for ingress traffic.
output	Specifies the NetFlow monitor for egress traffic.

Command Default

None.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to enable NetFlow monitoring on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# datalink flow monitor test output
Controller(config-wlan)# end
```

This example shows how to disable NetFlow monitoring on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no datalink flow monitor test output
Controller(config-wlan)# end
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.

default

To set the parameters to their default values, use the **default** command.

```
default {aaa-override| accounting-list| band-select| broadcast-ssid| call-snoop| ccx| channel-scan|
parameters| chd| client| datalink| diag-channel| dtim| exclusionlist| ip| ipv6| load-balance| local-auth|
mac-filtering| media-stream| mfp| mobility| nac| passive-client| peer-blocking| radio| roamed-voice-client|
security| service-policy| session-timeout| shutdown| sip-cac| static-ip| uapsd| wgb| wmm}
```

Syntax Description

aaa-override	Sets the AAA override parameter to its default value.
accounting-list	Sets the accounting parameter and its attributes to their default values.
band-select	Sets the band selection parameter to its default values.
broadcast-ssid	Sets the broadcast Service Set Identifier (SSID) parameter to its default value.
call-snoop	Sets the call snoop parameter to its default value.
ccx	Sets the Cisco client extension (Cisco Aironet IE) parameters and attributes to their default values.
channel-scan	Sets the channel scan parameters and attributes to their default values.
chd	Sets the coverage hold detection parameter to its default value.
client	Sets the client parameters and attributes to their default values.
datalink	Sets the datalink parameters and attributes to their default values.
diag-channel	Sets the diagnostic channel parameters and attributes to their default values.
dtim	Sets the Delivery Traffic Indicator Message (DTIM) parameter to its default value.
exclusionlist	Sets the client exclusion timeout parameter to its default value.
ip	Sets the IP parameters to their default values.
ipv6	Sets the IPv6 parameters and attributes to their default values.
load-balance	Sets the load-balancing parameter to its default value.
local-auth	Sets the Extensible Authentication Protocol (EAP) profile parameters and attributes to their default values.
mac-filtering	Sets the MAC filtering parameters and attributes to their default values.

media-stream	Sets the media stream parameters and attributes to their default values.
mfp	Sets the Management Frame Protection (MPF) parameters and attributes to their default values.
mobility	Sets the mobility parameters and attributes to their default values.
nac	Sets the RADIUS Network Admission Control (NAC) parameter to its default value.
passive-client	Sets the passive client parameter to its default value.
peer-blocking	Sets the peer to peer blocking parameters and attributes to their default values.
radio	Sets the radio policy parameters and attributes to their default values.
roamed-voice-client	Sets the roamed voice client parameters and attributes to their default values.
security	Sets the security policy parameters and attributes to their default values.
service-policy	Sets the WLAN quality of service (QoS) policy parameters and attributes to their default values.
session-timeout	Sets the client session timeout parameter to its default value.
shutdown	Sets the shutdown parameter to its default value.
sip-cac	Sets the Session Initiation Protocol (SIP) Call Admission Control (CAC) parameters and attributes to their default values.
static-ip	Sets the static IP client tunneling parameters and their attributes to their default values.
uapsd	Sets the Wi-Fi Multimedia (WMM) Unscheduled Automatic Power Save Delivery (UAPSD) parameters and attributes to their default values.
wgb	Sets the Workgroup Bridges (WGB) parameter to its default value.
wmm	Sets the WMM parameters and attributes to their default values.

Command Default None.

Command Modes WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to set the Cisco Client Extension parameter to its default value:

```
Controller(config-wlan) # default ccx aironet-iesupport
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.

dtim dot11

To configure the Delivery Traffic Indicator Message (DTIM) period for a WLAN, use the **dtim dot11** command. To disable DTIM, use the **no** form of this command.

```
dtim dot11 {5ghz| 24ghz} dtim-period
no dtim dot11 {5ghz| 24ghz} dtim-period
```

Syntax Description	
5ghz	Configures the DTIM period on the 5-GHz band.
24ghz	Configures the DTIM period on the 2.4-GHz band.
<i>dtim-period</i>	Value for the DTIM period. The range is from 1 to 255.

Command Default The DTIM period is set to 1.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples This example shows how to enable the DTIM period on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# dtim dot11 24ghz 3
```

This example shows how to disable the DTIM period on a WLAN on the 2.4-GHz band:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no dtim dot11 24ghz 3
```

Related Commands	Command	Description
	wlan	Creates or disables a WLAN.

exclusionlist

To configure an exclusion list on a wireless LAN, use the **exclusionlist** command. To disable an exclusion list, use the **no** form of this command.

exclusionlist [*timeout seconds*]

no exclusionlist [*timeout*]

Syntax Description

timeout <i>seconds</i>	(Optional) Specifies an exclusion list timeout in seconds. The range is from 0 to 2147483647. A value of zero (0) specifies no timeout.
-------------------------------	---

Command Default

The exclusion list is set to 60 seconds.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to configure a client exclusion list for a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# exclusionlist timeout 345
```

This example shows how to disable a client exclusion list on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no exclusionlist timeout 345
```

exit

To exit the WLAN configuration submode, use the **exit** command.

exit

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how to exit the WLAN configuration submode:

```

Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# exit
Controller(config)#

```

exit (WLAN AP Group)

To exit the WLAN access point group submode, use the **exit** command.

exit

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes WLAN AP Group configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to exit the WLAN AP group submode:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# ap group test
Controller(config-apgroup)# exit
```

ip access-group

To configure WLAN access control group (ACL), use the **ip access-group** command. To remove a WLAN ACL group, use the **no** form of the command.

ip access-group [web] *acl-name*

no ip access-group [web]

Syntax Description	web	(Optional) Configures the IPv4 web ACL.
	<i>acl-name</i>	Specify the preauth ACL used for the WLAN with the security type value as webauth.
Command Default	None	
Command Modes	WLAN configuration	
Usage Guidelines	You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.
Examples	<p>This example shows how to configure a WLAN ACL:</p> <pre>Controller#configure terminal Enter configuration commands, one per line. End with CNTL/Z. Controller(config)#wlan wlan1 Controller(config-wlan)#ip access-group test-acl</pre> <p>This example shows how to configure an IPv4 WLAN web ACL:</p> <pre>Controller# configure terminal Enter configuration commands, one per line. End with CNTL/Z. Controller(config)# wlan wlan1 Controller(config-wlan)# ip access-group web test Controller(config-wlan)#</pre>	
Related Commands	Command	Description
	wlan	Creates or disables a WLAN.

ip flow monitor

To configure IP NetFlow monitoring, use the **ip flow monitor** command. To remove IP NetFlow monitoring, use the **no** form of this command.

ip flow monitor *ip-monitor-name* {**input**| **output**}

no ip flow monitor *ip-monitor-name* {**input**| **output**}

Syntax Description		
	<i>ip-monitor-name</i>	Flow monitor name.
	input	Enables a flow monitor for ingress traffic.
	output	Enables a flow monitor for egress traffic.

Command Default None

Command Modes WLAN configuration

Usage Guidelines You must disable the WLAN before using this command.

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure an IP flow monitor for the ingress traffic:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# ip flow monitor test input
```

This example shows how to disable an IP flow monitor:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no ip flow monitor test input
```

ip verify source mac-check

To enable IPv4 Source Guard (IPSG) on a WLAN, use the **ip verify source mac-check** command. To disable IPSG, use the **no** form of this command.

ip verify source mac-check

no ip verify source mac-check

Syntax Description This command has no keywords or arguments.

Command Default IPSG is disabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Use this feature to restrict traffic from a host to a specific interface that is based on the host's IP address. The feature can also be configured to bind the source MAC and IP of a host so that IP spoofing is prevented.

Use this feature to bind the IP and MAC address of a wireless host that is based on information received from DHCP snooping, ARP, and Dataglean. Dataglean is the process of extracting location information such as host hardware address, ports that lead to the host, and so on from DHCP messages as they are forwarded by the DHCP relay agent. If a wireless host tries to send traffic with IP address and MAC address combination that has not been learned by the controller, this traffic is dropped in the hardware. IPSG is not supported on DHCP packets. IPSG is not supported for foreign clients in a foreign controller.

You must disable the WLAN before using this command.

Examples This example shows how to enable IPSG:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# ip verify source mac-check
```

This example shows how to disable IPSG:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no ip verify source mac-check
```

load-balance

To enable load balancing on a WLAN, use the **load-balance** command. To disable load balancing, use the **no** form of this command.

load-balance

no load-balance

Syntax Description This command has no keywords or arguments.

Command Default Load balancing is disabled by default.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	The command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples This example shows how to enable load balancing on a WLAN:

```

Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# shutdown
Controller(config)# wlan wlan1
Controller(config-wlan)# load-balance
Controller(config)# no shutdown
Controller(config-wlan)# end

```

This example shows how to disable load balancing on a WLAN:

```

Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# shutdown
Controller(config)# wlan wlan1
Controller(config-wlan)# no load-balance
Controller(config)# no shutdown
Controller(config-wlan)# end

```

Related Commands	Command	Description
	wlan	Creates or disables a WLAN.

mobility anchor

To configure mobility sticky anchoring, use the **mobility anchor sticky** command. To disable the sticky anchoring, use the **no** form of the command.

To configure guest anchoring, use the **mobility anchor ip-address** command.

To delete the guest anchor, use the **no** form of the command.

To configure the device as an auto-anchor, use the **mobility anchor** command.

mobility anchor {*ip-address*| **sticky**}

no mobility anchor {*ip-address*| **sticky** }

Syntax Description

sticky	The client is anchored to the first switch that it associates. Note This command is by default enabled and ensures low roaming latency. This ensures that the point of presence for the client does not change when the client joins the mobility domain and roams within the domain.
<i>ip-address</i>	Configures the IP address for the guest anchor controller to this WLAN.

Command Default

Sticky configuration is enabled by default.

Command Modes

WLAN Configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.
Cisco IOS XE 3.3SE	The auto-anchor configuration required the device IP address to be entered prior to the Cisco IOS XE 3.3SE release; with this release, if no IP address is given, the device itself becomes an anchor; you do not have to explicitly specify the IP address.

Usage Guidelines

- The wlan_id or guest_lan_id must exist and be disabled.
- Auto-anchor mobility is enabled for the WLAN or wired guest LAN when you configure the first mobility anchor.
- Deleting the last anchor disables the auto-anchor mobility feature and resumes normal mobility for new associations.
- Mobility uses the following ports, that are allowed through the firewall:
 - 16666

- 16667
- 16668

Examples

This example shows how to enable the sticky mobility anchor:

```
Controller(config-wlan)# mobility anchor sticky
```

This example shows how to configure guest anchoring:

```
Controller(config-wlan)# mobility anchor 209.165.200.224
```

This example shows how to configure the device as an auto-anchor:

```
Controller(config-wlan)# mobility anchor
```

nac

To enable RADIUS Network Admission Control (NAC) support for a WLAN, use the **nac** command. To disable NAC out-of-band support, use the **no** form of this command.

nac
no nac

Syntax Description This command has no keywords or arguments.

Command Default NAC is disabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You should enable AAA override before you enable the RADIUS NAC state.

Examples This example shows how to configure RADIUS NAC on the WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# aaa-override
Controller(config-wlan)# nac
```

This example shows how to disable RADIUS NAC on the WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no nac
Controller(config-wlan)# no aaa-override
```

Related Commands	Command	Description
	aaa-override	Enables or disables AAA override on a WLAN.

passive-client

To enable the passive client feature on a WLAN, use the **passive-client** command. To disable the passive client feature, use the **no** form of this command.

passive-client

no passive-client

Syntax Description This command has no keywords or arguments.

Command Default Passive client feature is disabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You must enable the global multicast mode and multicast-multicast mode before entering this command. Both multicast-multicast mode and multicast unicast modes are supported. The multicast-multicast mode is recommended.

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples This show how to enable the passive client feature on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wireless multicast
Controller(config)# wlan test-wlan
Controller(config-wlan)# passive-client
```

This example shows how to disable the passive client feature on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wireless multicast
Controller(config)# wlan test-wlan
Controller(config-wlan)# no passive-client
```

Related Commands	Command	Description
	wlan	Creates or disables a WLAN.

peer-blocking

To configure peer-to-peer blocking on a WLAN, use the **peer-blocking** command. To disable peer-to-peer blocking, use the **no** form of this command.

peer-blocking {**drop**|**forward-upstream**}

no peer-blocking

Syntax Description	
drop	Specifies the controller to discard the packets.
forward-upstream	Specifies the packets to be forwarded on the upstream VLAN. The device next in the hierarchy to the controller decides what action to take regarding the packets.

Command Default Peer blocking is disabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples This example shows how to enable the drop and forward-upstream options for peer-to-peer blocking:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# peer-blocking drop
Controller(config-wlan)# peer-blocking forward-upstream
```

This example shows how to disable the drop and forward-upstream options for peer-to-peer blocking:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no peer-blocking drop
Controller(config-wlan)# no peer-blocking forward-upstream
```

Related Commands	Command	Description
	wlan	Creates or disables a WLAN.

radio

To enable the Cisco radio policy on a WLAN, use the **radio** command. To disable the Cisco radio policy on a WLAN, use the **no** form of this command.

radio {**all**| **dot11a**| **dot11ag**| **dot11bg**| **dot11g**}

no radio

Syntax Description

all	Configures the WLAN on all radio bands.
dot11a	Configures the WLAN on only 802.11a radio bands.
dot11ag	Configures the WLAN on 802.11a/g radio bands.
dot11bg	Configures the wireless LAN on only 802.11b/g radio bands (only 802.11b if 802.11g is disabled).
dot11g	Configures the wireless LAN on 802.11g radio bands only.

Command Default

Radio policy is enabled on all bands.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to configure the WLAN on all radio bands:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# radio all
```

This example shows how to disable all radio bands on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no radio all
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.

radio-policy

To configure the radio policy on a WLAN access point group, use the **radio-policy** command. To disable the radio policy on the WLAN, use the **no** form of this command.

radio-policy {all| dot11a| dot11bg| dot11g}

no radio {all| dot11a| dot11bg| dot11g}

Syntax Description

all	Configures the wireless LAN on all radio bands.
dot11a	Configures the wireless LAN on only 802.11a radio bands.
dot11bg	Configures the wireless LAN on only 802.11b/g (only 802.11b if 802.11g is disabled) radio bands.
dot11g	Configures the wireless LAN on only 802.11g radio bands.

Command Default

Radio policy is enabled on all the bands.

Command Modes

WLAN AP Group configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The WLAN must be restarted for the changes to take effect. See Related Commands section for more information on how to shutdown a WLAN.

Examples

This example shows how to enable the radio policy on the 802.11b band for an AP group:

```
Controller(config)# ap group test
Controller(config-apgroup)# wlan test-wlan
Controller(config-wlan-apgroup)# radio-policy dot11b
```

This example shows how to disable the radio policy on the 802.11b band of an AP group:

```
Controller(config)# ap group test
Controller(config-apgroup)# wlan test-wlan
Controller(config-wlan-apgroup)# no radio-policy dot11bg
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.
wlan shutdown	Disables a WLAN.

roamed-voice-client re-anchor

To enable the roamed-voice-client re-anchor feature, use the **roamed-voice-client re-anchor** command. To disable the roamed-voice-client re-anchor feature, use the **no** form of this command.

roamed-voice-client re-anchor

no roamed-voice-client re-anchor

Syntax Description This command has no keywords or arguments.

Command Default Roamed voice client reanchor feature is disabled.

Command Modes WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to enable the roamed voice client re-anchor feature:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# roamed-voice-client re-anchor
```

This example shows how to disable the roamed voice client re-anchor feature:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no roamed-voice-client re-anchor
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.

security ft

To configure 802.11r fast transition parameters, use the **security ft** command. To configure fast transition **over the air**, use the **no security ft over-the-ds** command.

security ft [**over-the-ds**| **reassociation-timeout** *timeout-jn-seconds*]

no security ft [**over-the-ds**| **reassociation-timeout**]

Syntax Description		
over-the-ds	(Optional) Specifies that the 802.11r fast transition occurs over a distributed system. The no form of the command with this parameter configures security ft over the air.	
reassociation-timeout	(Optional) Configures the reassociation timeout interval.	
<i>timeout-in-seconds</i>	(Optional) Specifies the reassociation timeout interval in seconds. The valid range is between 1 to 100. The default value is 20.	

Command Default The feature is disabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None
WLAN Security must be enabled.

Examples The following example configures security FT configuration for an open WLAN:

```
Controller#wlan test
Controller(config-wlan)# client vlan 0140
Controller(config-wlan)# no mobility anchor sticky
Controller(config-wlan)# no security wpa
Controller(config-wlan)# no security wpa akm dot1x
Controller(config-wlan)# no security wpa wpa2
Controller(config-wlan)# no security wpa wpa2 ciphers aes
Controller(config-wlan)# security ft
Controller(config-wlan)# shutdown
```

The following example shows a sample security FT on a WPA-enabled WLAN:

```
Controller# wlan test
```

```
Controller(config-wlan)# client vlan 0140  
Controller(config-wlan)# no security wpa akm dot1x  
Controller(config-wlan)# security wpa akm ft psk  
Controller(config-wlan)# security wpa akm psk set-key ascii 0 test-test  
Controller(config-wlan)# security ft  
Controller(config-wlan)# no shutdown
```

security pmf

To configure 802.11w Management Frame Protection (PMF) on a WLAN, use the **security pmf** command. To disable management frame protection, use the **no** form of the command.

security pmf {**association-comeback** *association-comeback-time-seconds*| **mandatory**| **optional**| **saquery-retry-time** *saquery-retry-time-milliseconds*}

no security pmf [**association-comeback** *association-comeback-time-seconds*| **mandatory**| **optional**| **saquery-retry-time** *saquery-retry-time-milliseconds*]

Syntax Description

association-comeback	Configures the 802.11w association comeback time.
<i>association-comeback-time-seconds</i>	Association comeback interval in seconds. Time interval that an associated client must wait before the association is tried again after it is denied with a status code 30. The status code 30 message is "Association request rejected temporarily; Try again later." The range is from 1 through 20 seconds.
mandatory	Specifies that clients are required to negotiate 802.1w PMF protection on the WLAN.
optional	Specifies that the WLAN does not mandate 802.11w support on clients. Clients with no 802.11w capability can also join.
saquery-retry-time	Time interval identified before which the SA query response is expected. If the controller does not get a response, another SA query is tried.
<i>saquery-retry-time-milliseconds</i>	The saquery retry time in milliseconds. The range is from 100 to 500 ms. The value must be specified in multiples of 100 milliseconds.

Command Default

PMF is disabled.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You must have WPA (Wi-Fi Protected Access) and AKM (Authentication Key Management) configured to use this feature. See Related Command section for more information on configuring the security parameters. 802.11w introduces an Integrity Group Temporal Key (IGTK) that is used to protect broadcast or multicast robust management frames. IGTK is a random value, assigned by the authenticator station (controller) used to protect MAC management protocol data units (MMPDUs) from the source STA. The 802.11w IGTK key is derived using the four-way handshake and is used only on WLANs that are configured with WPA2 security at Layer 2.

Examples

This example shows how to enable the association comeback value at 15 seconds.

```
Controller(config-wlan)# security pmf association-comeback 15
```

This example shows how to configure mandatory 802.11w MPF protection for clients on a WLAN:

```
Controller(config-wlan)# security pmf mandatory
```

This example shows how to configure optional 802.11w MPF protection for clients on a WLAN:

```
Controller(config-wlan)# security pmf optional
```

This example shows how to configure the saquery parameter:

```
Controller(config-wlan)# security pmf saquery-retry-time 100
```

This example shows how to disable the PMF feature:

```
Controller(config-wlan)# no security pmf
```

Related Commands

Command	Description
security wpa akm	Configures authentication key-management using Cisco Centralized Key Management on a WLAN.

security web-auth

To change the status of web authentication used on a WLAN, use the **security web-auth** command. To disable web authentication on a WLAN, use the **no** form of the command.

security web-auth [**authentication-list** *authentication-list-name*] **on-macfilter-failure** **parameter-map** *parameter-map-name*]

no security web-auth [**authentication-list** [*authentication-list-name*]] **on-macfilter-failure** **parameter-map** [*parameter-name*]]

Syntax Description

authentication-list <i>authentication-list-name</i>	Sets the authentication list for IEEE 802.1x.
on-macfilter-failure	Enables web authentication on MAC failure.
parameter-map <i>parameter-map-name</i>	Configures the parameter map.

Command Default

Web authentication is disabled.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following example shows how to configure the authentication-list web authentication on a WLAN:

```
Controller(config-wlan)# security web-auth authentication-list test
```

security wpa akm

To configure authentication key management using Cisco Centralized Key Management (CCKM), use the **security wpa akm** command. To disable the authentication key management for Cisco Centralized Key Management, use the **no** form of the command.

```
security wpa [akm {cckm| dot1x| ft| pmf| psk}] wpa1 [ciphers {aes| tkip}] wpa2 [ciphers {aes| tkip}]
no security wpa [akm {cckm| dot1x| ft| pmf| psk}] wpa1 [ciphers {aes| tkip}] wpa2 [ciphers {aes| tkip}]
```

Syntax Description

akm	Configures the Authentication Key Management (AKM) parameters.
aes	Configures AES (Advanced Encryption Standard) encryption support.
cckm	Configures Cisco Centralized Key Management support.
ciphers	Configures WPA ciphers.
dot1x	Configures 802.1x support.
ft	Configures fast transition using 802.11r.
pmf	Configures 802.11w management frame protection.
psk	Configures 802.11r fast transition pre-shared key (PSK) support.
tkip	Configures Temporal Key Integrity Protocol (TKIP) encryption support.
wpa2	Configures Wi-Fi Protected Access 2 (WPA2) support.

Command Default

By default Wi-Fi Protected Access2, 802.1x are enabled. WPA2, PSK, CCKM, FT dot1x, FT PSK, PMF dot1x, PMF PSK, FT Support are disabled. The FT Reassociation timeout is set to 20 seconds, PMF SA Query time is set to 200.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

The following example shows how to configure CCKM on the WLAN.

```
Controller(config-wlan)#security wpa akm cckm
```

service-policy (WLAN)

To configure the WLAN quality of service (QoS) service policy, use the **service-policy** command. To disable a QoS policy on a WLAN, use the **no** form of this command.

service-policy [**client**] {**input**| **output**} *policy-name*

no service-policy [**client**] {**input**| **output**} *policy-name*

Syntax Description

client	(Optional) Assigns a policy map to all clients in the WLAN.
input	Assigns an input policy map.
output	Assigns an output policy map.
<i>policy-name</i>	The policy name.

Command Default

No policies are assigned and the state assigned to the policy is None.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to configure the input QoS service policy on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# service-policy input policy-test
```

This example shows how to disable the input QoS service policy on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no service-policy input policy-test
```

This example shows how to configure the output QoS service policy on a WLAN to platinum (precious metal policy):

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
```

```
Controller(config)# wlan wlan1  
Controller(config-wlan)# service-policy output platinum
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.
wlan	Creates or disables a WLAN.

session-timeout

To configure session timeout for clients associated to a WLAN, use the **session-timeout** command. To disable a session timeout for clients that are associated to a WLAN, use the **no** form of this command.

session-timeout seconds

no session-timeout

Syntax Description

<i>seconds</i>	Timeout or session duration in seconds. A value of zero (0) is equivalent to no timeout. The range is from 300 to 86400.
----------------	--

Command Default

The client timeout is set to 1800 seconds for WLANs that are configured with dot1x security. The client timeout is set to 0 for open WLANs.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure a session timeout to 300 seconds:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# session-timeout 300
```

This example shows how to disable a session timeout:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no session-timeout
```

show wlan

To view WLAN parameters, use the **show wlan** command.

show wlan {**all** | **id** *wlan-id* | **name** *wlan-name* | **summary**}

Syntax Description

all	Displays a summary of parameters of all configured WLANs. The list is ordered by the ascending order of the WLAN IDs.
id <i>wlan-id</i>	Specifies the wireless LAN identifier. The range is from 1 to 512.
name <i>wlan-name</i>	Specifies the WLAN profile name. The name is from 1 to 32 characters.
summary	Displays a summary of the parameters configured on a WLAN.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display a summary of the WLANs configured on the device:

```
Controller# show wlan summary
Number of WLANs: 1
```

```
WLAN Profile Name          SSID                      VLAN Status
-----
45  test-wlan                test-wlan-ssid           1    UP
```

This example shows how to display a summary of parameters configured on a particular WLAN:

```
Controller# show wlan name test-wlan
WLAN Identifier             : 45
Profile Name                : test-wlan
Network Name (SSID)        : test-wlan-ssid
Status                      : Enabled
Broadcast SSID             : Enabled
Maximum number of Associated Clients : 0
AAA Policy Override        : Disabled
Network Admission Control
  NAC-State                 : Disabled
Number of Active Clients    : 0
Exclusionlist Timeout       : 60
Session Timeout            : 1800 seconds
```

```

CHD per WLAN : Enabled
Webauth DHCP exclusion : Disabled
Interface : default
Interface Status : Up
Multicast Interface : test
WLAN IPv4 ACL : test
WLAN IPv6 ACL : unconfigured
DHCP Server : Default
DHCP Address Assignment Required : Disabled
DHCP Option 82 : Disabled
DHCP Option 82 Format : ap-mac
DHCP Option 82 Ascii Mode : Disabled
DHCP Option 82 Rid Mode : Disabled
QoS Service Policy - Input
  Policy Name : unknown
  Policy State : None
QoS Service Policy - Output
  Policy Name : unknown
  Policy State : None
QoS Client Service Policy
  Input Policy Name : unknown
  Output Policy Name : unknown
WifiDirect : Disabled
WMM : Disabled
Channel Scan Defer Priority:
  Priority (default) : 4
  Priority (default) : 5
  Priority (default) : 6
Scan Defer Time (msecs) : 100
Media Stream Multicast-direct : Disabled
CCX - AironetIe Support : Enabled
CCX - Gratuitous ProbeResponse (GPR) : Disabled
CCX - Diagnostics Channel Capability : Disabled
Dot11-Phone Mode (7920) : Invalid
Wired Protocol : None
Peer-to-Peer Blocking Action : Disabled
Radio Policy : All
DTIM period for 802.11a radio : 1
DTIM period for 802.11b radio : 1
Local EAP Authentication : Disabled
Mac Filter Authorization list name : Disabled
Accounting list name : Disabled
802.1x authentication list name : Disabled
Security
  802.11 Authentication : Open System
  Static WEP Keys : Disabled
  802.1X : Disabled
  Wi-Fi Protected Access (WPA/WPA2) : Enabled
    WPA (SSN IE) : Disabled
    WPA2 (RSN IE) : Enabled
    TKIP Cipher : Disabled
    AES Cipher : Enabled
  Auth Key Management
    802.1x : Enabled
    PSK : Disabled
    CCKM : Disabled
  IP Security : Disabled
  IP Security Passthru : Disabled
  L2TP : Disabled
  Web Based Authentication : Disabled
  Conditional Web Redirect : Disabled
  Splash-Page Web Redirect : Disabled
  Auto Anchor : Disabled
  Sticky Anchoring : Enabled
  Cranite Passthru : Disabled
  Fortress Passthru : Disabled
  PPTP : Disabled
  Infrastructure MFP protection : Enabled
  Client MFP : Optional
  Webauth On-mac-filter Failure : Disabled
  Webauth Authentication List Name : Disabled
  Webauth Parameter Map : Disabled
  Tkip MIC Countermeasure Hold-down Timer : 60

```

```
Call Snooping           : Disabled
Passive Client          : Disabled
Non Cisco WGB           : Disabled
Band Select             : Disabled
Load Balancing          : Disabled
IP Source Guard         : Disabled
Netflow Monitor        : test
    Direction           : Input
    Traffic              : Datalink

Mobility Anchor List
IP Address
-----
```

shutdown

To disable a WLAN, use the **shutdown** command. To enable a WLAN, use the **no** form of this command.

shutdown

no shutdown

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to disable a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan test-wlan
Controller(config-wlan)# shutdown
Controller(config-wlan)# end
Controller# show wlan summary
Number of WLANs: 1
```

WLAN Profile Name	SSID	VLAN Status
45 test-wlan	test-wlan-ssid	1 DOWN

This example shows how to enable a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan test-wlan
Controller(config-wlan)# no shutdown
Controller(config-wlan)# end
Controller# show wlan summary
Number of WLANs: 1
```

WLAN Profile Name	SSID	VLAN Status
45 test-wlan	test-wlan-ssid	1 UP

sip-cac

To configure the Session Initiation Protocol (SIP) Call Admission Control (CAC) feature on a WLAN, use the **sip-cac** command. To disable the SIP CAC feature, use the **no** form of this command.

sip-cac {**disassoc-client**| **send-486busy**}

no sip-cac {**disassoc-client**| **send-486busy**}

Syntax Description		
disassoc-client		Enables a client disassociation if a CAC failure occurs.
send-486busy		Sends a SIP 486 busy message if a CAC failure occurs.

Command Default None

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples This example shows how to enable a client disassociation and 486 busy message on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# sip-cac disassoc-client
Controller(config-wlan)# sip-cac send-486busy
```

This example shows how to disable a client association and 486 busy message on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no sip-cac disassoc-client
Controller(config-wlan)# no sip-cac send-486busy
```

Related Commands	Command	Description
	wlan	Creates or disables a WLAN.

static-ip tunneling

To enable static IP tunneling on a WLAN, use the **static-ip tunneling** command. To disable the static IP tunneling feature, use the **no** form of this command.

static-ip tunneling

no static-ip tunneling

Syntax Description This command has no keywords or arguments.

Command Default None

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable static-IP tunneling:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# static-ip tunneling
```

This example shows how to disable static-IP tunneling:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no static-ip tunneling
```

vlan

To assign a VLAN to an AP group, use the **vlan** command. To remove a VLAN ID, use the **no** form of this command.

vlan *interface-name*

no vlan

Syntax Description

<i>interface-name</i>	VLAN interface name.
-----------------------	----------------------

Command Default

No VALN is assigned to the AP group. See Related Commands section for more information on how to disable a WLAN.

Command Modes

WLAN AP Group configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command.

Examples

This example shows how to configure a VLAN on an AP group:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# ap group ap-group-1
Controller(config-apgroup)# wlan test-wlan
Controller(config-wlan-apgroup)# vlan 3
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.

wgb non-cisco

To enable non-Cisco Workgroup Bridges (WGB) clients on the WLAN, use the **wgb non-cisco** command. To disable support for non-Cisco WGB clients, use the **no** form of this command.

wgb non-cisco

no wgb non-cisco

Syntax Description This command has no keywords or arguments.

Command Default Non-Cisco WGB clients are disabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples This example shows how to enable non-Cisco WGBs on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# shutdown
Controller(config-wlan)# wgb non-cisco
Controller(config-wlan)# no shutdown
```

This example shows how to disable support for non-Cisco WGB clients on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# shutdown
Controller(config-wlan)# no wgb non-cisco
Controller(config-wlan)# no shutdown
```

wifidirect policy

To configure Wi-Fi Direct client policy on a WLAN, use the **wifidirect policy** command. To disable Wi-Fi Direct Client policy, use the **no** form of the command.

wifidirect policy {permit| deny}

Syntax Description

permit	Enables Wi-Fi Direct clients to associate with the WLAN.
deny	<p>When the Wi-Fi Direct policy is configured as "deny", the controller permits or denies Wi-Fi Direct devices based on the device capabilities. A Wi-Fi Direct device reports these capabilities in its association request to the controller and these are based on the Wi-Fi capabilities of the device. These include:</p> <ul style="list-style-type: none"> • Concurrent Operation • Cross connection <p>If the Wi-Fi device supports either concurrent operations or cross connections or both, the client association is denied. The client can associate if the device does not support concurrent operations and cross connections.</p>

Command Default

Wi-Fi Direct is disabled.

Command Modes

WLAN configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

The following example shows how to enable Wi-Fi Direct and configure the Wi-Fi Direct clients to associate with the WLAN:

```
Controller(config-wlan)# wifidirect policy permit
```

wlan (AP Group Configuration)

To configure WLAN parameters of a WLAN in an access point (AP) group, use the **wlan** command. To remove a WLAN from the AP group, use the **no** form of this command.

wlan *wlan-name*

no wlan *wlan-name*

Syntax Description

<i>wlan-name</i>	WLAN profile name. The range is from 1 to 32 alphanumeric characters.
------------------	---

Command Default

WLAN parameters are not configured for an AP group.

Command Modes

AP Group configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to configure WLAN related parameters in the AP group configuration mode:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# ap group test
Controller(config-apgroup)# wlan qos-wlan
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.

wlan

To create a wireless LAN, use the **wlan** command. To disable a wireless LAN, use the **no** form of this command.

wlan [*wlan-name*| *wlan-name wlan-id*| *wlan-name wlan-id wlan-ssid*]

no wlan [*wlan-name*| *wlan-name wlan-id*| *wlan-name wlan-id wlan-ssid*]

Syntax Description	
<i>wlan-name</i>	WLAN profile name. The name is from 1 to 32 alphanumeric characters.
<i>wlan-id</i>	Wireless LAN identifier. The range is from 1 to 512.
<i>wlan-ssid</i>	SSID. The range is from 1 to 32 alphanumeric characters.

Command Default WLAN is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines If you do not specify an SSID, the profile name parameter is used for both the profile name and the SSID. If the management and AP-manager interfaces are mapped to the same port and are members of the same VLAN, you must disable the WLAN before making a port-mapping change to either interface. If the management and AP-manager (Access Point Manager) interfaces are assigned to different VLANs, you do not need to disable the WLAN.

An error message appears if you try to delete a WLAN that is assigned to an access point group. If you proceed, the WLAN is removed from the access point group and from the access point's radio.

Examples

This example shows how to create a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config)# wlan test-wlan-cr 67 test-wlan-cr-ssid
```

This example shows how to delete a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config)# no wlan test-wlan-cr 67 test-wlan-cr-ssid
```

wlan shutdown

To disable a WLAN, use the **wlan shutdown** command. To enable a WLAN, use the **no** form of this command.

wlan shutdown

no wlan shutdown

Command Default

The WLAN is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to shut down a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# shutdown
```

Related Commands

Command	Description
wlan	Creates or disables a WLAN.

wmm

To enable Wi-Fi Multimedia (WMM) on a WLAN, use the **wmm** command. To disable WMM on a WLAN, use the **no** form of this command.

wmm {allowed|require}

no wmm

Syntax Description	
allowed	Allows WMM on a WLAN.
require	Mandates that clients use WMM on the WLAN.

Command Default WMM is enabled.

Command Modes WLAN configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines When the controller is in Layer 2 mode and WMM is enabled, you must put the access points on a trunk port in order to allow them to join the controller.

You must disable the WLAN before using this command. See Related Commands section for more information on how to disable a WLAN.

Examples

This example shows how to enable WMM on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# wmm allowed
```

This example shows how to disable WMM on a WLAN:

```
Controller# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)# wlan wlan1
Controller(config-wlan)# no wmm
```


Related Commands	Command	Description
	wlan	Creates or disables a WLAN.



PART **X**

Radio Resource Management

- [Radio Resource Management Commands, page 573](#)



Radio Resource Management Commands

- [ap dot11 rrm, page 574](#)
- [ap dot11 rrm ccx, page 577](#)
- [ap dot11 rrm channel, page 578](#)
- [ap dot11 24ghz or 5ghz rrm channel dca add, page 580](#)
- [ap dot11 24ghz or 5ghz rrm channel dca remove, page 581](#)
- [ap dot11 5ghz rrm channel dca chan-width-11n, page 582](#)
- [ap dot11 rrm coverage, page 583](#)
- [ap dot11 rrm group-member, page 585](#)
- [ap dot11 rrm monitor, page 586](#)
- [ap dot11 rrm profile, page 588](#)
- [ap dot11 rrm tpc-threshold, page 589](#)
- [ap dot11 rrm txpower, page 590](#)
- [show ap dot11 24ghz, page 591](#)
- [show ap dot11 5ghz, page 593](#)

ap dot11 rrm

To configure basic and advanced radio resource management settings for 802.11 devices, use the **ap dot11 rrm** command.

```
ap dot11 {24ghz|5ghz} rrm {ccx location-measurement sec| channel {cleanair-event| dca| device| foreign|
load| noise| outdoor-ap-dca}| coverage {data fail-percentage pct| data packet-count count| data
rssi-threshold threshold}| exception global percentage| level global number| voice {fail-percentage
percentage| packet-count number| rssi-threshold threshold}}
```

Syntax Description

ccx	Configures Advanced (RRM) 802.11 CCX options.
location-measurement	Specifies 802.11 CCX Client Location Measurements in seconds. The range is between 10 and 32400 seconds.
channel	Configure advanced 802.11-channel assignment parameters.
cleanair-event	Configures cleanair event-driven RRM parameters.
dca	Configures 802.11-dynamic channel assignment algorithm parameters.
device	Configures persistent non-WiFi device avoidance in the 802.11-channel assignment.
foreign	Enables foreign AP 802.11-interference avoidance in the channel assignment.
load	Enables Cisco AP 802.11-load avoidance in the channel assignment.
noise	Enables non-802.11-noise avoidance in the channel assignment.
outdoor-ap-dca	Configures 802.11 DCA list option for outdoor AP.

coverage	Configures 802.11 coverage Hole-Detection.
data fail-percentage <i>pct</i>	Configures 802.11 coverage failure-rate threshold for uplink data packets. The range is between 1 and 100
data packet-count <i>count</i>	Configures 802.11 coverage minimum-failure-count threshold for uplinkdata packets.
data rssi-threshold <i>threshold</i>	Configures 802.11 minimum-receive-coverage level for voice packets.
exception global <i>percentage</i>	Configures 802.11 Cisco APs coverage-exception level. The range is between 0 and 100 percent.
level global <i>number</i>	Configures 802.11 Cisco AP client-minimum-exception level between 1 and 75 clients.
voice	Configures 802.11 coverage Hole-Detection for voice packets.
fail-percentage <i>percentage</i>	Configures 802.11 coverage failure rate threshold for uplink voice packets.
packet-count <i>number</i>	Configures 802.11 coverage minimum-uplink-failure count threshold for voice packets.
rssi-threshold <i>threshold</i>	Configures 802.11 minimum receive coverage level for voice packets.

Command Default

Disabled

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

This command applies for both 802.11a and 802.11b bands. But the appropriate commands must be chosen for configuring the parameter.

Examples

This example shows how to configure various RRM settings.

```

Controller#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)#ap dot11 5ghz rrm ?
  ccx           Configure Advanced(RRM) 802.11a CCX options
  channel       Configure advanced 802.11a channel assignment parameters
  coverage      802.11a Coverage Hole Detection
  group-member  Configure members in 802.11a static RF group
  group-mode    802.11a RF group selection mode
  logging       802.11a event logging
  monitor       802.11a statistics monitoring
  ndp-type      Neighbor discovery type Protected/Transparent
  profile       802.11a performance profile
  tpc-threshold Configures the Tx Power Control Threshold used by RRM for auto
                power assignment
  txpower       Configures the 802.11a Tx Power Level

```

ap dot11 rrm ccx

To configure radio resource management CCX options for 2.4 GHz and 5GHz devices, use the **ap dot11 rrm ccx** command.

ap dot11 {24ghz|5ghz} rrm ccx location-measurement *interval*

Syntax Description	location-measurement <i>interval</i>	Specifies the CCX client-location measurement interval value. The range is between 10 and 32400 seconds.
Command Default	None.	
Command Modes	Interface configuration.	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.
Usage Guidelines	None.	
Examples	This example shows how to set CCX location-measurement interval for a 5-GHz device.	
	<pre> Controller#configure terminal Enter configuration commands, one per line. End with CNTL/Z. Controller(config)#ap dot11 5ghz rrm ccx location-measurement 10 </pre>	

ap dot11 rrm channel

To enable radio resource management channel for 2.4 GHz and 5GHz devices, use the **ap dot11 rrm channel** command. To disable the radio resource management for 2.4 GHz and 5 GHz devices, use the **no** form of the command.

ap dot11 {24ghz| 5ghz} rrm channel {cleanair-event| dca| device| foreign| load| noise}

no ap dot11 {24ghz| 5ghz} rrm channel {cleanair-event| dca| device| foreign| load| noise}

Syntax Description

cleanair-event	Specifies the cleanair event-driven RRM parameters
dca	Specifies the 802.11 dynamic channel assignment algorithm parameters
device	Specifies the persistent non-WiFi device avoidance in the 802.11-channel assignment.
foreign	Enables foreign AP 802.11-interference avoidance in the channel assignment.
load	Enables Cisco AP 802.11-load avoidance in the channel assignment.
noise	Enables non-802.11-noise avoidance in the channel assignment.

Command Default

None.

Command Modes

Interface configuration.

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None.

Examples

This example shows all the parameters available for **Channel**.

```

Controller#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)#ap dot11 24ghz rrm channel ?
  cleanair-event  Configure cleanair event-driven RRM parameters
  dca             Config 802.11b dynamic channel assignment algorithm
                 parameters
  device         Configure persistent non-WiFi device avoidance in the 802.11b
                 channel assignment
  foreign        Configure foreign AP 802.11b interference avoidance in the

```

	channel assignment
load	Configure Cisco AP 802.11b load avoidance in the channel assignment
noise	Configure 802.11b noise avoidance in the channel assignment

ap dot11 24ghz or 5ghz rrm channel dca add

To add non-default radio resource management DCA channels to the DCA channel list for 2.4 GHz or 5 GHz devices, use the **ap dot11 {24ghz | 5ghz } rrm channel dca add** command. To remove a default channel from the DCA list, use the **no** form of the command. The DCA channel list contains standard channels matching your country of operation. For example, a regulatory default channel list contains channels 1, 6, and 11.

ap dot11 [24ghz| 5ghz] rrm channel dca add *number*

no ap dot11 [24ghz| 5ghz] rrm channel dca add *number*

Syntax Description

<i>number</i>	DCA channel number.
---------------	---------------------

Command Default

None.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

None.

Examples

This example shows how to add a non-default radio resource management DCA channel to the DCA list for a 2.4 GHz device, using the **ap dot11 24ghz rrm channel dca add 10** command:

```
Controller(config)# ap dot11 24ghz rrm channel dca add 10
```

ap dot11 24ghz or 5ghz rrm channel dca remove

To remove a default radio resource management DCA channels from the DCA channel list for 2.4 GHz or 5 GHz devices, use the **ap dot11 {24ghz | 5ghz} rrm channel dca remove *number*** command. To add a default DCA channel back to the DCA channel list, use the **no** form of the command.

ap dot11 [24ghz| 5ghz] rrm channel dca remove *number*

no ap dot11 [24ghz| 5ghz] rrm channel dca remove *number*

Syntax Description	<i>number</i>	Specifies the radio resource management DCA channel.
---------------------------	---------------	--

Command Default	None.
------------------------	-------

Command Modes	Global configuration.
----------------------	-----------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples This example shows how to remove default radio resource management DCA channel from the DCA list for a 2.4 GHz device, using the **ap dot11 24ghz rrm channel dca remove** command:

```
Controller(config)#ap dot11 24ghz rrm channel dca remove 11
```

ap dot11 5ghz rrm channel dca chan-width-11n

To configure DCA channel width for all 802.11n radios in the 5-GHz band, enter the **ap dot11 5ghz rrm channel dca chan-width-11n** *width* command. To disable DCA channel width for all 802.11n radios in the 5-GHz band, use the **no** form of the command.

```
ap dot11 5ghzrrm channel dca chan-width-11n {20|40}
```

```
noap dot11 5ghzrrm channel dca chan-width-11n {20|40}
```

Syntax Description

chan-width-11n	Specifies DCA channel width for all 802.11n radios in the 5-GHz band.
20	Sets the channel width for 802.11n radios to 20 MHz.
40	Sets the channel width for 802.11n radios to 40 MHz.

Command Default

The default channel width is 20.

Command Modes

Global configuration.

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

None.

Examples

This example shows how to set the channel width for the 802.11n radios to 40 MHz, using the **ap dot11 5ghz rrm channel dca chan-width-11n** command:

```
Controller(config)#ap dot11 5ghz rrm channel dca chan-width-11n 40
```

ap dot11 rrm coverage

To enable 802.11 coverage hole detection, use the **ap dot11 rrm coverage** command.

ap dot11 {24ghz|5ghz} **rrm coverage** [**data** {fail-percentage *percentage*| packet-count *count*| rssi-threshold *threshold*}| **exceptional global** *value*| **level global** *value*| **voice** {fail-percentage *percentage*| packet-count *packet-count*| rssi-threshold *threshold*}]

Syntax	Description
data	Specifies 802.11 coverage hole-detection data packets.
fail-percentage <i>percentage</i>	Specifies 802.11 coverage failure-rate threshold for uplink data packets. The range is between 1 and 100
packet-count <i>count</i>	Specifies 802.11 coverage minimum-failure-count threshold for uplink data packets.
rssi-threshold <i>threshold</i>	Specifies 802.11 minimum-receive-coverage level for voice packets.
exceptional global <i>value</i>	Specifies 802.11 Cisco APs coverage-exception level. The range is between 0 and 100 percent.
level global <i>value</i>	Specifies 802.11 Cisco AP client-minimum-exception level between 1 and 75 clients.
voice	Specifies 802.11 coverage Hole-Detection for voice packets.
fail-percentage <i>percentage</i>	Specifies 802.11 coverage failure rate threshold for uplink voice packets.
packet-count <i>packet-count</i>	Specifies 802.11 coverage minimum-uplink-failure count threshold for voice packets.
rssi-threshold <i>threshold</i>	Specifies 802.11 minimum receive coverage level for voice packets.

Command Default None.

Command Modes Interface configuration.

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

If you enable coverage hole-detection, the controller automatically determines, based on data that is received from the access points, whether any access points have clients that are potentially located in areas with poor coverage.

If both the number and percentage of failed packets exceed the values that you entered in the **ap dot11 {24ghz | 5ghz} rrm coverage packet-count** and **ap dot11 {24ghz | 5ghz} rrm coverage fail-percentage** commands for a 5-second period, the client is considered to be in a pre-alarm condition. The controller uses this information to distinguish between real and false coverage holes and excludes clients with poor roaming logic. A coverage hole is detected if both the number and percentage of failed clients meet or exceed the values entered in the **ap dot11 {24ghz | 5ghz} rrm coverage level-global** and **ap dot11 {24ghz | 5ghz} rrm coverage exceptional-global** commands over a 90-second period. The controller determines whether the coverage hole can be corrected and, if appropriate, mitigate the coverage hole by increasing the transmit power level for that specific access point.

Examples

This example shows how to set the RSSI-threshold for data in 5-GHz band.

```
Controller#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)#ap dot11 5ghz rrm coverage data rssi-threshold -80
```

ap dot11 rrm group-member

To configure members in 802.11 static RF group, use the **ap dot11 rrm group-member** command. To remove the member, use the **no** form of the command.

ap dot11 {24ghz| 5ghz} **rrm group-member** *controller-name controller-ip*

no ap dot11 {24ghz| 5ghz} **rrm group-member** *controller-name controller-ip*

Syntax Description		
	<i>controller-name</i>	Specifies the name of the controller to be added.
	<i>controller-ip</i>	Specifies the IP address of the controller to be added.

Command Default None.

Command Modes Interface configuration.

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines None.

Examples This example shows how to add a controller in the 5-GHz automatic-RF group

```
Controller#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)#ap dot11 5ghz rrm group-member ABC 10.1.1.1
```

ap dot11 rrm monitor

To monitor the 802.11-band statistics, use the **ap dot11 rrm monitor** command. To disable, use the **no** form of the command.

ap dot11 {24ghz| 5ghz} rrm monitor {channel-list| {all| country| dca}| coverage| load| noise| signal}
no ap dot11 {24ghz| 5ghz} rrm monitor {channel-list| coverage| load| noise| signal}

Syntax Description

channel-list	Sets the 802.11 noise/interference/rogue monitoring channel-list.
all	Specifies to monitor all the channels.
country	Specifies to monitor channels used in configured country code
dca	Specifies to monitor channels used by dynamic channel assignment.
coverage	Specifies 802.11 coverage measurement interval. The range is between 60 and 3600 in seconds
load	Specifies 802.11 load measurement interval. The range is between 60 and 3600 in seconds
noise	Specifies 802.11 noise measurement interval (channel scan interval). The range is between 60 and 3600 in seconds
signal	Specifies 802.11 signal measurement interval (neighbor packet frequency). The range is between 60 and 3600 in seconds

Command Default

None.

Command Modes

Interface Configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None.

Examples

This example shows how to enable monitoring all the 5-GHz band channels.

```
Controller#configure terminal
```

Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)#**ap dot11 5ghz rrm monitor channel-list all**

ap dot11 rrm profile

To configure Cisco lightweight access point profile settings on supported 802.11 networks, use the **ap dot11 rrm profile** command.

ap dot11 {24ghz| 5ghz} **rrm profile** {**customize**| **foreign value**| **noise value**| **throughput value**| **utilization value**}

Syntax Description

customize	Enables performance profiles.
foreign value	Specifies the 802.11 foreign 802.11 interference threshold value. The range is between 0 and 100 percent.
noise value	Specifies the 802.11 foreign noise threshold value. The range is between -127 and 0 dBm
throughput value	Specifies the 802.11a Cisco AP throughput threshold value. The range is between 1000 and 10000000 bytes per second
utilization value	Specifies the 802.11a RF utilization threshold value. The range is between 0 and 100 percent

Command Default

Disabled.

Command Modes

Interface configuration.

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None.

Examples

This example shows how to set the threshold value for the noise parameter.

```
Controller#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)#ap dot11 5ghz rrm profile noise -50
```

ap dot11 rrm tpc-threshold

To configure the tx-power control threshold used by RRM for auto power assignment, use the **ap dot11 rrm tpc-threshold** command. To disable, use the **no** form of the command.

ap dot11 {24ghz| 5ghz} rrm tpc-threshold *value*

no ap dot11 {24ghz| 5ghz} rrm tpc-threshold

Syntax Description	<i>value</i>	Specifies the power value. The range is between -80 and -50.
Command Default	None.	
Command Modes	Interface configuration.	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.
Usage Guidelines	None.	
Examples	<p>This example shows how to configure the tx-power control threshold used by RRM for auto power assignment.</p> <pre> Controller#configure terminal Enter configuration commands, one per line. End with CNTL/Z. Controller(config)#ap dot11 5ghz rrm tpc-threshold -60 </pre>	

ap dot11 rrm txpower

To configure the 802.11 tx-power level, use the **ap dot11 rrm txpower** command. To disable the 802.11 tx-power level, use the **no** form of the command.

ap dot11 {24ghz| 5ghz} **rrm txpower** {auto| max *powerLevel*| min *powerLevel*| once| *power-level*}

no ap dot11 {24ghz| 5ghz} **rrm txpower** {auto| max *powerLevel*| min *powerLevel*| once| *power-level*}

Syntax Description

auto	Enables auto-RF.
max <i>powerLevel</i>	Configures maximum auto-RF tx power. The range is between -10 to -30.
min <i>powerLevel</i>	Configures minimum auto-RF tx power. The range is between -10 to -30.
once	Enables one-time auto-RF.

Command Default

None.

Command Modes

Interface configuration.

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.
Cisco IOS XE 3.3SE	The no form of the command is introduced.

Usage Guidelines

None.

Examples

This example shows how to enable auto-RF once.

```
Controller#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Controller(config)#ap dot11 5ghz rrm txpower once
```

show ap dot11 24ghz

To display the 2.4 GHz RRM parameters, use the **show ap dot11 24ghz** command.

```
show ap dot11 24ghz {ccx| channel| coverage| group| l2roam| logging| monitor| profile| receiver| summary| txpower}
```

Syntax Description

ccx	Displays the 802.11b CCX information for all Cisco APs.
channel	Displays the configuration and statistics of the 802.11b channel assignment.
coverage	Displays the configuration and statistics of the 802.11b coverage.
group	Displays the configuration and statistics of the 802.11b grouping.
l2roam	Displays 802.11b l2roam information.
logging	Displays the configuration and statistics of the 802.11b event logging.
monitor	Displays the configuration and statistics of the 802.11b monitoring.
profile	Displays 802.11b profiling information for all Cisco APs.
receiver	Displays the configuration and statistics of the 802.11b receiver.
summary	Displays the configuration and statistics of the 802.11b Cisco APs.
txpower	Displays the configuration and statistics of the 802.11b transmit power control.

Command Default

None.

Command Modes

Global configuration.

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None.

Examples

This example shows how to display configuration and statistics of the 802.11b coverage.

```
Controller#show ap dot11 24ghz coverage
```

```
Coverage Hole Detection
 802.11b Coverage Hole Detection Mode      : Enabled
 802.11b Coverage Voice Packet Count      : 100 packet(s)
 802.11b Coverage Voice Packet Percentage : 50%
 802.11b Coverage Voice RSSI Threshold    : -80 dBm
 802.11b Coverage Data Packet Count      : 50 packet(s)
 802.11b Coverage Data Packet Percentage  : 50%
 802.11b Coverage Data RSSI Threshold    : -80 dBm
 802.11b Global coverage exception level  : 25 %
 802.11b Global client minimum exception level : 3 clients
```

show ap dot11 5ghz

To display the 5GHz RRM parameters, use the **show ap dot11 5ghz** command.

```
show ap dot11 5ghz {ccx| channel| coverage| group| l2roam| logging| monitor| profile| receiver| summary| txpower}
```

Syntax Description

ccx	Displays the 802.11a CCX information for all Cisco APs.
channel	Displays the configuration and statistics of the 802.11a channel assignment.
coverage	Displays the configuration and statistics of the 802.11a coverage.
group	Displays the configuration and statistics of the 802.11a grouping.
l2roam	Displays 802.11a l2roam information.
logging	Displays the configuration and statistics of the 802.11a event logging.
monitor	Displays the configuration and statistics of the 802.11a monitoring.
profile	Displays 802.11a profiling information for all Cisco APs.
receiver	Displays the configuration and statistics of the 802.11a receiver.
summary	Displays the configuration and statistics of the 802.11a Cisco APs.
txpower	Displays the configuration and statistics of the 802.11a transmit power control.

Command Default

None.

Command Modes

Global configuration.

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None.

Examples

This example shows configuration and statistics of 802.11a channel assignment.

```

Controller#show ap dot11 5ghz channel

Automatic Channel Assignment
Channel Assignment Mode           : AUTO
Channel Update Interval          : 12 Hours
Anchor time (Hour of the day)    : 20
Channel Update Contribution      : SNI..
Channel Assignment Leader        : web (9.9.9.2)
Last Run                          : 16534 seconds ago
DCA Sensitivity Level             : MEDIUM (15 dB)
DCA 802.11n Channel Width        : 40 Mhz
Channel Energy Levels
  Minimum                         : unknown
  Average                         : unknown
  Maximum                         : unknown
Channel Dwell Times
  Minimum                         : unknown
  Average                         : unknown
  Maximum                         : unknown
802.11a 5 GHz Auto-RF Channel List
Allowed Channel List              : 36,40,44,48,52,56,60,64,149,153,1
                                   57,161
Unused Channel List               : 100,104,108,112,116,132,136,140,1
                                   65
802.11a 4.9 GHz Auto-RF Channel List
Allowed Channel List              :
Unused Channel List               : 1,2,3,4,5,6,7,8,9,10,11,12,13,14,
                                   15,16,17,18,19,20,21,22,23,24,25,26
DCA Outdoor AP option             : Disabled

```



PART **XI**

Lightweight Access Points

- [Cisco Lightweight Access Point Commands, page 597](#)



Cisco Lightweight Access Point Commands

- [ap auth-list ap-policy, page 603](#)
- [ap bridging, page 604](#)
- [ap capwap backup, page 605](#)
- [ap capwap multicast, page 606](#)
- [ap capwap retransmit, page 607](#)
- [ap capwap timers, page 608](#)
- [ap cdp, page 610](#)
- [ap core-dump, page 612](#)
- [ap country, page 613](#)
- [ap crash-file, page 614](#)
- [ap dot11 24ghz preamble, page 615](#)
- [ap dot11 24ghz dot11g, page 616](#)
- [ap dot11 5ghz channelswitch mode, page 617](#)
- [ap dot11 5ghz power-constraint, page 618](#)
- [ap dot11 beaconperiod, page 619](#)
- [ap dot11 beamforming, page 620](#)
- [ap dot11 cac media-stream, page 622](#)
- [ap dot11 cac multimedia, page 625](#)
- [ap dot11 cac video, page 627](#)
- [ap dot11 cac voice, page 629](#)
- [ap dot11 cleanair, page 632](#)
- [ap dot11 cleanair alarm air-quality, page 633](#)
- [ap dot11 cleanair alarm device, page 634](#)
- [ap dot11 cleanair device, page 636](#)

- ap dot11 dot11n, page 638
- ap dot11 dtpc, page 641
- ap dot11 edca-parameters, page 643
- ap dot11 rrm group-mode, page 645
- ap dot11 rrm channel cleanair-event, page 646
- ap dot11 l2roam rf-params, page 647
- ap dot11 media-stream, page 649
- ap dot11 rrm ccx location-measurement, page 651
- ap dot11 rrm channel dca, page 652
- ap dot11 rrm group-member, page 654
- ap dot11 rrm logging, page 655
- ap dot11 rrm monitor, page 657
- ap dot11 rrm ndp-type, page 659
- ap dot1x max-sessions, page 660
- ap dot1x username, page 661
- ap ethernet duplex, page 662
- ap group, page 663
- ap image, page 664
- ap ipv6 tcp adjust-mss, page 665
- ap led, page 666
- ap link-encryption, page 667
- ap link-latency, page 668
- ap mgmtuser username, page 669
- ap name ap-groupname, page 671
- ap name bhrate, page 672
- ap name bridgegroupname, page 673
- ap name capwap retransmit, page 674
- ap name command, page 675
- ap name core-dump, page 676
- ap name country, page 677
- ap name crash-file, page 678
- ap name dot11 24ghz rrm coverage, page 679
- ap name dot11 49ghz rrm profile, page 681

- [ap name dot11 5ghz rrm channel, page 683](#)
- [ap name dot11 antenna, page 684](#)
- [ap name dot11 antenna extantgain, page 686](#)
- [ap name dot11 cleanair, page 687](#)
- [ap name dot11 dot11n antenna, page 688](#)
- [ap name dot11 dual-band cleanair, page 689](#)
- [ap name dot11 dual-band shutdown, page 690](#)
- [ap name dot11 rrm ccx, page 691](#)
- [ap name dot11 rrm profile, page 692](#)
- [ap name dot11 txpower, page 694](#)
- [ap name dot1x-user, page 695](#)
- [ap name ethernet, page 697](#)
- [ap name ethernet duplex, page 698](#)
- [ap name image, page 699](#)
- [ap name ipv6 tcp adjust-mss, page 700](#)
- [ap name led, page 701](#)
- [ap name location, page 702](#)
- [ap name mgmtuser, page 703](#)
- [ap name mode, page 705](#)
- [ap name monitor-mode, page 707](#)
- [ap name monitor-mode dot11b, page 708](#)
- [ap name name, page 709](#)
- [ap name bridging, page 710](#)
- [ap name cdp interface, page 711](#)
- [ap name console-redirect, page 712](#)
- [ap name no dot11 shutdown, page 713](#)
- [ap name link-encryption, page 714](#)
- [ap name link-latency, page 715](#)
- [ap name power, page 716](#)
- [ap name shutdown, page 717](#)
- [ap name slot shutdown, page 718](#)
- [ap name sniff, page 719](#)
- [ap name ssh, page 720](#)

- [ap name telnet, page 721](#)
- [ap name power injector, page 722](#)
- [ap name power pre-standard, page 723](#)
- [ap name reset-button, page 724](#)
- [ap name reset, page 725](#)
- [ap name slot, page 726](#)
- [ap name static-ip, page 728](#)
- [ap name stats-timer, page 730](#)
- [ap name syslog host, page 731](#)
- [ap name syslog level, page 732](#)
- [ap name tcp-adjust-mss, page 733](#)
- [ap name tftp-downgrade, page 734](#)
- [ap power injector, page 735](#)
- [ap power pre-standard, page 736](#)
- [ap reporting-period, page 737](#)
- [ap reset-button, page 738](#)
- [ap static-ip, page 739](#)
- [ap syslog, page 740](#)
- [ap tcp-adjust-mss size, page 742](#)
- [ap tftp-downgrade, page 743](#)
- [clear ap name tsm dot11 all, page 744](#)
- [clear ap config, page 745](#)
- [clear ap eventlog-all, page 746](#)
- [clear ap join statistics, page 747](#)
- [clear ap mac-address, page 748](#)
- [clear ap name wlan statistics, page 749](#)
- [show ap cac voice, page 750](#)
- [show ap capwap, page 752](#)
- [show ap cdp, page 754](#)
- [show ap config dot11, page 755](#)
- [show ap config dot11 dual-band summary, page 756](#)
- [show ap config fnf, page 757](#)
- [show ap config, page 758](#)

- [show ap crash-file, page 759](#)
- [show ap data-plane, page 760](#)
- [show ap dot11 l2roam, page 761](#)
- [show ap dot11 cleanair air-quality, page 762](#)
- [show ap dot11 cleanair config, page 763](#)
- [show ap dot11 cleanair summary, page 765](#)
- [show ap dot11, page 766](#)
- [show ap ethernet statistics, page 771](#)
- [show ap groups, page 772](#)
- [show ap groups extended, page 773](#)
- [show ap image, page 774](#)
- [show ap join stats summary, page 775](#)
- [show ap link-encryption, page 776](#)
- [show ap mac-address, page 777](#)
- [show ap monitor-mode summary, page 779](#)
- [show ap name auto-rf, page 780](#)
- [show ap name bhmode, page 783](#)
- [show ap name bhrate, page 784](#)
- [show ap name cac voice, page 785](#)
- [show ap name config fnf, page 786](#)
- [show ap name dot11 call-control, page 787](#)
- [show ap name capwap retransmit, page 788](#)
- [show ap name ccx rm, page 789](#)
- [show ap name cdp, page 790](#)
- [show ap name channel, page 791](#)
- [show ap name config, page 792](#)
- [show ap name config dot11, page 794](#)
- [show ap name config slot, page 798](#)
- [show ap name core-dump, page 802](#)
- [show ap name data-plane, page 803](#)
- [show ap name dot11, page 804](#)
- [show ap name dot11 cleanair, page 807](#)
- [show ap name ethernet statistics, page 808](#)

- [show ap name eventlog](#), page 809
- [show ap name image](#), page 810
- [show ap name inventory](#), page 811
- [show ap name link-encryption](#), page 812
- [show ap name service-policy](#), page 813
- [show ap name tcp-adjust-mss](#), page 814
- [show ap name wlan](#), page 815
- [show ap slots](#), page 817
- [show ap summary](#), page 818
- [show ap tcp-adjust-mss](#), page 819
- [show ap uptime](#), page 820
- [show wireless client ap](#), page 821
- [test ap name](#), page 822
- [test capwap ap name](#), page 823
- [trapflags ap](#), page 824

ap auth-list ap-policy

To configure authorization policy for all Cisco lightweight access points joined to the controller, use the **ap auth-list ap-policy** command. To disable authorization policy for all Cisco lightweight access points joined to the controller, use the **no** form of this command.

ap auth-list ap-policy {**authorize-ap**| **authorize-lsc-ap**| **lsc**| **mic**| **ssc**}

no ap auth-list ap-policy {**authorize-ap**| **authorize-lsc-ap**| **lsc**| **mic**| **ssc**}

Syntax Description

authorize-ap	Enables the authorization policy.
authorize-lsc-ap	Enables the locally significant certificate authorization policy.
lsc	Enables access points with locally significant certificates to connect.
mic	Enables access points with manufacture-installed certificates to connect.
ssc	Enables access points with self signed certificates to connect.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable the access point authorization policy:

```
Controller(config)# ap auth-list ap-policy authorize-ap
```

This example shows how to enable the locally significant certificate authorization policy:

```
Controller(config)# ap auth-list ap-policy authorize-lsc-ap
```

This example shows how to enable access points with locally significant certificates to connect:

```
Controller(config)# ap auth-list ap-policy lsc
```

This example shows how to enable access points with manufacture-installed certificates to connect:

```
Controller(config)# ap auth-list ap-policy mic
```

This example shows how to enable access points with self-signed certificates to connect:

```
Controller(config)# ap auth-list ap-policy ssc
```

ap bridging

To enable Ethernet to 802.11 bridging on a Cisco lightweight access point, use the **ap bridging** command. To disable Ethernet to 802.11 bridging on a Cisco lightweight access point, use the **no** form of this command.

ap bridging

no ap bridging

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable Ethernet-to-Ethernet bridging on a lightweight access point:

```
Controller(config)# ap bridging
```

This example shows how to disable Ethernet-to-Ethernet bridging on a lightweight access point:

```
Controller(config)# no ap bridging
```

ap capwap backup

To configure a primary or secondary backup controller for all access points that are joined to a specific controller, use the **ap capwap backup** command.

ap capwap backup {**primary** *primary-controller-name primary-controller-ip-address* | **secondary** *secondary-controller-name secondary-controller-ip-address*}

Syntax Description

primary	Specifies the primary backup controller.
<i>primary-controller-name</i>	Primary backup controller name.
<i>primary-controller-ip-address</i>	Primary backup controller IP address.
secondary	Specifies the secondary backup controller.
<i>secondary-controller-name</i>	Secondary backup controller name.
<i>secondary-controller-ip-address</i>	Secondary backup controller IP address.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure a primary backup controller for all access points that are joined to a specific controller:

```
Controller(config)# ap capwap backup primary controller1 192.0.2.51
```

This example shows how to configure a secondary backup controller for all access points that are joined to a specific controller:

```
Controller(config)# ap capwap backup secondary controller1 192.0.2.52
```

ap capwap multicast

To configure the multicast address used by all access points to receive multicast traffic when multicast forwarding is enabled and to configure the outer Quality of Service (QoS) level of those multicast packets sent to the access points, use the **ap capwap multicast** command.

ap capwap multicast {*multicast-ip-address*| **service-policy output** *pollicymap-name*}

Syntax Description

<i>multicast-ip-address</i>	Multicast IP address.
service-policy	Specifies the tunnel QoS policy for multicast access points.
output	Assigns a policy map name to the output.
<i>pollicymap-name</i>	Service policy map name.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure a multicast address used by all access points to receive multicast traffic when multicast forwarding is enabled:

```
Controller(config)# ap capwap multicast 239.2.2.2
```

This example shows how to configure a tunnel multicast QoS service policy for multicast access points:

```
Controller(config)# ap capwap multicast service-policy output tunnmulpolicy
```

ap capwap retransmit

To configure Control and Provisioning of Wireless Access Points (CAPWAP) control packet retransmit count and control packet retransmit interval, use the **ap capwap retransmit** command.

ap capwap retransmit {**count** *retransmit-count* | **interval** *retransmit-interval*}

Syntax Description

count <i>retransmit-count</i>	Specifies the access point CAPWAP control packet retransmit count. Note The count is from 3 to 8 seconds.
interval <i>retransmit-interval</i>	Specifies the access point CAPWAP control packet retransmit interval. Note The interval is from 2 to 5 seconds.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the CAPWAP control packet retransmit count for an access point:

```
Controller# ap capwap retransmit count 3
```

This example shows how to configure the CAPWAP control packet retransmit interval for an access point:

```
Controller# ap capwap retransmit interval 5
```

ap capwap timers

To configure advanced timer settings, use the **ap capwap timers** command.

```
ap capwap timers {discovery-timeout seconds| fast-heartbeat-timeout local seconds| heartbeat-timeout seconds| primary-discovery-timeout seconds| primed-join-timeout seconds}
```

Syntax Description

discovery-timeout	Specifies the Cisco lightweight access point discovery timeout. Note The Cisco lightweight access point discovery timeout is how long a Cisco controller waits for an unresponsive access point to answer before considering that the access point failed to respond.
<i>seconds</i>	Cisco lightweight access point discovery timeout from 1 to 10 seconds. Note The default is 10 seconds.
fast-heartbeat-timeout local	Enables the fast heartbeat timer that reduces the amount of time it takes to detect a controller failure for local or all access points.
<i>seconds</i>	Small heartbeat interval (from 1 to 10 seconds) that reduces the amount of time it takes to detect a controller failure. Note The fast heartbeat time-out interval is disabled by default.
heartbeat-timeout	Specifies the Cisco lightweight access point heartbeat timeout. Note The Cisco lightweight access point heartbeat timeout controls how often the Cisco lightweight access point sends a heartbeat keep-alive signal to the Cisco controller. This value should be at least three times larger than the fast heartbeat timer.
<i>seconds</i>	Cisco lightweight access point heartbeat timeout value from 1 to 30 seconds. Note The default is 30 seconds.
primary-discovery-timeout	Specifies the access point primary discovery request timer. The timer determines the amount of time taken by an access point to discover the configured primary, secondary, or tertiary controller.
<i>seconds</i>	Access point primary discovery request timer from 30 to 3600 seconds. Note The default is 120 seconds.
primed-join-timeout	Specifies the authentication timeout. Determines the time taken by an access point to determine that the primary controller has become unresponsive. The access point makes no further attempts to join the controller until the connection to the controller is restored.

seconds Authentication response timeout from 120 to 43200 seconds.

Note The default is 120 seconds.

Command Default None

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure an access point discovery timeout with the timeout value of 7:

```
Controller(config)# ap capwap timers discovery-timeout 7
```

This example shows how to enable the fast heartbeat interval for all access points:

```
Controller(config)# ap capwap timers fast-heartbeat-timeout 6
```

This example shows how to configure an access point heartbeat timeout to 20:

```
Controller(config)# ap capwap timers heartbeat-timeout 20
```

This example shows how to configure the access point primary discovery request timer to 1200 seconds:

```
Controller(config)# ap capwap timers primary-discovery-timeout 1200
```

This example shows how to configure the authentication timeout to 360 seconds:

```
Controller(config)# ap capwap timers primed-join-timeout 360
```

ap cdp

To enable the Cisco Discovery Protocol (CDP) on a Cisco lightweight access point, use the **ap cdp** command. To disable the Cisco Discovery Protocol (CDP) on a Cisco lightweight access point, use the **no** form of this command.

ap cdp [interface {ethernet *ethernet-id*| radio *radio-id*}]

no ap cdp [interface {ethernet *ethernet-id*| radio *radio-id*}]

Syntax Description

interface	(Optional) Specifies CDP in a specific interface.
ethernet	Specifies CDP for an Ethernet interface.
<i>ethernet-id</i>	Ethernet interface number from 0 to 3.
radio	Specifies CDP for a radio interface.
<i>radio-id</i>	Radio number from 0 to 3.

Command Default

Disabled on all access points.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **no ap cdp** command disables CDP on all access points that are joined to the controller and all access points that join in the future. CDP remains disabled on both current and future access points even after the controller or access point reboots. To enable CDP, enter the **ap cdp** command.



Note

CDP over Ethernet/radio interfaces is available only when CDP is enabled. After you enable CDP on all access points joined to the controller, you can disable and then reenabling CDP on individual access points using the **ap name Cisco-AP cdp** command. After you disable CDP on all access points joined to the controller, you can enable and then disable CDP on individual access points.

Examples

This example shows how to enable CDP on all access points:

```
Controller(config)# ap cdp
```

This example shows how to enable CDP for Ethernet interface number 0 on all access points:

```
Controller(config)# ap cdp ethernet 0
```

ap core-dump

To enable a Cisco lightweight access point's memory core dump settings, use the **ap core-dump** command. To disable a Cisco lightweight access point's memory core dump settings, use the **no** form of this command.

ap core-dump *tftp-ip-addr filename* {**compress**| **uncompress**}

no ap core-dump

Syntax Description

<i>tftp-ip-addr</i>	IP address of the TFTP server to which the access point sends core dump files.
<i>filename</i>	Name that the access point uses to label the core file.
compress	Compresses the core dump file.
uncompress	Uncompresses the core dump file.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The access point must be able to reach the TFTP server.

Examples

This example shows how to configure and compress the core dump file:

```
Controller(config)# ap core-dump 192.0.2.51 log compress
```

ap country

To configure one or more country codes for a controller, use the **ap country** command.

ap country *country-code*

Syntax Description

<i>country-code</i>	Two-letter or three-letter country code or several country codes separated by a comma.
---------------------	--

Command Default

US (country code of the United States of America).

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The Cisco controller must be installed by a network administrator or qualified IT professional and the installer must select the proper country code. Following installation, access to the unit should be password protected by the installer to maintain compliance with regulatory requirements and to ensure proper unit functionality. See the related product guide for the most recent country codes and regulatory domains.

Examples

This example shows how to configure country codes on the controller to IN (India) and FR (France):

```
Controller(config)# ap country IN,FR
```

ap crash-file

To delete crash and radio core dump files, use the **ap crash-file** command.

ap crash-file {**clear-all**| **delete** *filename*}

Syntax Description

clear-all	Deletes all the crash and radio core dump files.
delete	Deletes a single crash and radio core dump file.
<i>filename</i>	Name of the file to delete.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to delete all crash files:

```
Controller# ap crash-file clear-all
```

This example shows how to delete crash file 1:

```
Controller# ap crash-file delete crash-file-1
```

ap dot11 24ghz preamble

To enable only a short preamble as defined in subclause 17.2.2.2 , use the **ap dot11 24ghz preamble** command. To enable long preambles (for backward compatibility with pre-802.11b devices, if these devices are still present in your network) or short preambles (recommended unless legacy pre-802.11b devices are present in the network), use the **no** form of this command.

ap dot11 24ghz preamble short

no ap dot11 24ghz preamble short

Syntax Description

short	Specifies the short 802.11b preamble.
--------------	---------------------------------------

Command Default

short preambles

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Note

You must reboot the Cisco controller (reset system) with the **Save** command before you can use the **ap dot11 24ghz preamble** command.

This parameter may need to be set to long to optimize this Cisco controller for some legacy clients, including SpectraLink NetLink telephones.

This command can be used any time that the CLI interface is active.

Examples

This example shows how to enable both long and short preamblest:

```
Controller(config)# no ap dot11 24ghz preamble short
```

ap dot11 24ghz dot11g

To enable the Cisco wireless LAN solution 802.11g network, use the **ap dot11 24ghz dot11g** command. To disable the Cisco wireless LAN solution 802.11g network, use the **no** form of this command.

ap dot11 24ghz dot11g

no ap dot11 24ghz dot11g

Syntax Description

This command has no keywords and arguments.

Command Default

Enabled

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Before you enter the **ap dot11 24ghz dot11g** command, disable the 802.11 Cisco radio with the **ap dot11 24ghz shutdown** command.

After you configure the support for the 802.11g network, use the **no ap dot11 24ghz shutdown** command to enable the 802.11 2.4 Ghz radio.

Examples

This example shows how to enable the 802.11g network:

```
Controller(config)# ap dot11 24ghz dot11g
```

ap dot11 5ghz channelswitch mode

To configure a 802.11h channel switch announcement, use the **ap dot11 5ghz channelswitch mode** command. To disable a 802.11h channel switch announcement, use the **no** form of this command.

ap dot11 5ghz channelswitch mode *value*

no ap dot11 5ghz channelswitch mode

Syntax Description

value 802.11h channel announcement value.

Note You can specify anyone of the following two values:

- 0—Indicates that the channel switch announcement is disabled.
- 1—Indicates that the channel switch announcement is enabled.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable the 802.11h switch announcement:

```
Controller(config)# ap dot11 5ghz channelswitch mode 1
```

ap dot11 5ghz power-constraint

To configure the 802.11h power constraint value, use the **ap dot11 5ghz power-constraint** command. To remove the 802.11h power constraint value, use the **no** form of this command.

ap dot11 5ghz power-constraint *value*

no ap dot11 5ghz power-constraint

Syntax Description

<i>value</i>	802.11h power constraint value.
Note	The range is from 0 to 30 dBm.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the 802.11h power constraint to 5 dBm:

```
Controller(config)# ap dot11 5ghz power-constraint 5
```

ap dot11 beaconperiod

To change the beacon period globally for 2.4 GHz or 5 GHz bands, use the **ap dot11 beaconperiod** command.



Note

Disable the 802.11 network before using this command. See the “Usage Guidelines” section.

ap dot11 {24ghz|5ghz} **beaconperiod** *time*

Syntax Description

24ghz	Specifies the settings for 2.4 GHz band.
5ghz	Specifies the settings for 5 GHz band.
beaconperiod	Specifies the beacon for a network globally.
<i>time</i>	Beacon interval in time units (TU). One TU is 1024 microseconds. The range is from 20 to 1000.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

In Cisco wireless LAN 802.11 networks, all Cisco lightweight access point wireless LANs broadcast a beacon at regular intervals. This beacon notifies clients that the wireless service is available and allows the clients to synchronize with the lightweight access point.

Before you change the beacon period, make sure that you have disabled the 802.11 network by using the **ap dot11 {24ghz|5ghz} shutdown** command. After changing the beacon period, enable the 802.11 network by using the **no ap dot11 {24ghz|5ghz} shutdown** command.

Examples

This example shows how to configure the 5 GHz band for a beacon period of 120 time units:

```
Controller(config)# ap dot11 5ghz beaconperiod 120
```

ap dot11 beamforming

To enable beamforming on the network or on individual radios, use the **ap dot11 beamforming** command.

ap dot11 {24ghz| 5ghz} beamforming

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
beamforming	Specifies beamforming on the network.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

When you enable beamforming on the network, it is automatically enabled for all the radios applicable to that network type.

Follow these guidelines for using beamforming:

- Beamforming is supported for legacy orthogonal frequency-division multiplexing (OFDM) data rates (6, 9, 12, 18, 24, 36, 48, and 54 Mbps).



Note Beamforming is not supported for Direct Sequence Spread Spectrum data rates (1 and 2 Mbps) and Complementary-Code Key (CCK) data rates (5.5 and 11 Mbps).

- Beamforming is supported only on access points that support 802.11n (AP1260, AP3500, and AP3600).
- Two or more antennas must be enabled for transmission.
- All three antennas must be enabled for reception.
- OFDM rates must be enabled.

If the antenna configuration restricts operation to a single transmit antenna, or if OFDM rates are disabled, beamforming is not used.

Examples

This example shows how to enable beamforming on the 5 GHz band:

```
Controller(config)# ap dot11 5ghz beamforming
```

ap dot11 cac media-stream

To configure media stream Call Admission Control (CAC) voice and video quality parameters for 2.4 GHz and 5 GHz bands, use the **ap dot11 cac media-stream** command.

```
ap dot11 {24ghz| 5ghz} cac media-stream multicast-direct {max-retry-percent retryPercent
min-client-rate {eighteen| eleven| fiftyFour| fivePointFive| fortyEight| nine| oneFifty|
oneFortyFourPointFour| oneThirty| oneThirtyFive| seventyTwoPointTwo| six| sixtyFive| thirtySix|
threeHundred| twelve| twentyFour| two| twoSeventy}}
```

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
multicast-direct	Specifies CAC parameters for multicast-direct media streams.
max-retry-percent	Specifies the percentage of maximum retries that are allowed for multicast-direct media streams.
<i>retryPercent</i>	Percentage of maximum retries that are allowed for multicast-direct media streams. Note The range is from 0 to 100.
min-client-rate	Specifies the minimum transmission data rate to the client for multicast-direct media streams (rate at which the client must transmit in order to receive multicast-direct unicast streams). If the transmission rate is below this rate, either the video will not start or the client may be classified as a bad client. The bad client video can be demoted for better effort QoS or subject to denial.

min-client-rate

You can choose the following rates:

- **eighteen**
 - **eleven**
 - **fiftyFour**
 - **fivePointFive**
 - **fortyEight**
 - **nine**
 - **one**
 - **oneFifty**
 - **oneFortyFourPointFour**
 - **oneThirty**
 - **oneThirtyFive**
 - **seventyTwoPointTwo**
 - **six**
 - **sixtyFive**
 - **thirtySix**
 - **threeHundred**
 - **twelve**
 - **twentyFour**
 - **two**
 - **twoSeventy**
-

Command Default

The default value for the maximum retry percent is 80. If it exceeds 80, either the video will not start or the client might be classified as a bad client. The bad client video will be demoted for better effort QoS or is subject to denial.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **wlan *wlan_name* shutdown** command.
- Disable the radio network you want to configure by entering the **ap dot11 {24ghz | 5ghz} shutdown** command.
- Save the new configuration.
- Enable voice or video CAC for the network you want to configure by entering the **ap dot11 {24ghz | 5ghz} cac voice acm** or **ap dot11 {24ghz | 5ghz} cac video acm** commands.

Examples

This example shows how to configure the maximum retry percent for multicast-direct media streams as 90 on a 802.11a network:

```
Controller(config)# ap dot11 5ghz cac media-stream multicast max-retry-percent 90
```

ap dot11 cac multimedia

To configure multimedia Call Admission Control (CAC) voice and video quality parameters for 2.4 GHz and 5 GHz bands, use the **ap dot11 cac multimedia** command.

ap dot11 {24ghz| 5ghz} cac multimedia max-bandwidth *bandwidth*

Syntax Description		
24ghz		Specifies the 2.4 GHz band.
5ghz		Specifies the 5 GHz band.
max-bandwidth		Specifies the percentage of maximum bandwidth allocated to Wi-Fi Multimedia (WMM) clients for voice and video applications on the 2.4 GHz or 5 GHz band.
<i>bandwidth</i>		Percentage of the maximum bandwidth allocated to WMM clients for voice and video applications on the 802.11a or 802.11b/g network. Once the client reaches the specified value, the access point rejects new multimedia flows this radio band. The range is from 5 to 85%.

Command Default The default value is 75%.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **wlan wlan_name shutdown** command.
- Disable the radio network you want to configure by entering the **ap dot11 {24ghz | 5ghz} shutdown** command.
- Save the new configuration.
- Enable voice or video CAC for the network you want to configure by entering the **ap dot11 {24ghz | 5ghz} cac voice acm** or **ap dot11 {24ghz | 5ghz} cac video acm** commands.

Examples

This example shows how to configure the percentage of the maximum bandwidth allocated to WMM clients for voice and video applications on the 5 GHz band:

```
Controller(config)# ap dot11 5ghz cac multimedia max-bandwidth 5
```

ap dot11 cac video

To configure Call Admission Control (CAC) parameters for the video category, use the **ap dot11 cac video** command. To disable the CAC parameters for video category, use the **no** form of this command.

```
ap dot11 {24ghz| 5ghz} cac video {acm| max-bandwidth value| roam-bandwidth value}
no ap dot11 {24ghz| 5ghz} cac video {acm| max-bandwidth value| roam-bandwidth value}
```

Syntax Description		
24ghz		Specifies the 2.4 GHz band.
5ghz		Specifies the 5 GHz band.
acm		Enables bandwidth-based video CAC for the 2.4 GHz or 5 GHz band. Note To disable bandwidth-based video CAC for the 2.4 GHz or 5 GHz band, use the no ap dot11 {24ghz 5ghz} cac video acm command.
max-bandwidth		Sets the percentage of the maximum bandwidth allocated to clients for video applications on the 2.4 GHz or 5 GHz band.
<i>value</i>		Bandwidth percentage value from 5 to 85%.
roam-bandwidth		Sets the percentage of the CAC maximum allocated bandwidth reserved for roaming video clients on the 2.4 GHz or 5 GHz band.
<i>value</i>		Bandwidth percentage value from 0 to 85%.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **wlan wlan_name shutdown** command.
- Disable the radio network you want to configure by entering the **ap dot11 {24ghz | 5ghz} shutdown** command.

- Save the new configuration.
- Enable voice or video CAC for the network you want to configure by entering the **ap dot11 {24ghz | 5ghz} cac voice acm** or **ap dot11 {24ghz | 5ghz} cac video acm** command.

Examples

This example shows how to enable the bandwidth-based CAC:

```
Controller(config)# ap dot11 24ghz cac video acm
```

This example shows how to specify the percentage of the maximum allocated bandwidth for video applications on the selected radio band:

```
Controller(config)# ap dot11 24ghz cac video max-bandwidth 50
```

This example shows how to configure the percentage of the maximum allocated bandwidth reserved for roaming video clients on the selected radio band:

```
Controller(config)# ap dot11 24ghz cac video roam-bandwidth 10
```

ap dot11 cac voice

To configure Call Admission Control (CAC) parameters for the voice category, use the **ap dot11 cac voice** command.

```
ap dot11 {24ghz| 5ghz} cac voice {acm| load-based| max-bandwidth value| roam-bandwidth value| sip
[bandwidth bw] sample-interval value| stream-size x max-streams y| tspec-inactivity-timeout {enable|
ignore}}
```

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
acm	Enables bandwidth-based voice CAC for the 2.4 GHz or 5 GHz band. Note To disable bandwidth-based voice CAC for the 2.4 GHz or 5 GHz band, use the no ap dot11 {24ghz 5ghz} cac voice acm command.
load-based	Enable load-based CAC on voice access category. Note To disable load-based CAC on voice access category for the 2.4 GHz or 5 GHz band, use the no ap dot11 {24ghz 5ghz} cac voice load-based command.
max-bandwidth	Sets the percentage of the maximum bandwidth allocated to clients for voice applications on the 2.4 GHz or 5 GHz band.
<i>value</i>	Bandwidth percentage value from 5 to 85%.
roam-bandwidth	Sets the percentage of the CAC maximum allocated bandwidth reserved for roaming voice clients on the 2.4 GHz or 5 GHz band.
<i>value</i>	Bandwidth percentage value from 0 to 85%.
sip	Specifies the CAC codec name and sample interval as parameters and calculates the required bandwidth per call for the 802.11 networks.
bandwidth	(Optional) Specifies bandwidth for a SIP-based call.

<i>bw</i>	Bandwidth in kbps. The following bandwidth values specify parameters for the SIP codecs: <ul style="list-style-type: none"> • 64kbps—Specifies CAC parameters for the SIP G711 codec. • 8kbps—Specifies CAC parameters for the SIP G729 codec. <p>Note The default value is 64 Kbps.</p>
sample-interval	Specifies the packetization interval for SIP codec.
<i>value</i>	Packetization interval in msec. The sample interval for SIP codec value is 20 seconds.
stream-size	Specifies the number of aggregated voice Wi-Fi Multimedia (WMM) traffic specification (TSPEC) streams at a specified data rate for the 2.4 GHz or 5 GHz band.
<i>x</i>	Stream size. The range of the stream size is from 84000 to 92100.
max-streams	Specifies the maximum number of streams per TSPEC.
<i>y</i>	Number (1 to 5) of voice streams. <p>Note The default number of streams is 2 and the mean data rate of a stream is 84 kbps.</p>
tspec-inactivity-timeout	Specifies TSPEC inactivity timeout processing mode. <p>Note Use this keyword to process or ignore the Wi-Fi Multimedia (WMM) traffic specifications (TSPEC) inactivity timeout received from an access point. When the inactivity timeout is ignored, a client TSPEC is not deleted even if the access point reports an inactivity timeout for that client.</p>
enable	Processes the TSPEC inactivity timeout messages.
ignore	Ignores the TSPEC inactivity timeout messages. <p>Note The default is ignore (disabled).</p>

Command Default None

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

CAC commands require that the WLAN you are planning to modify is configured for the Wi-Fi Multimedia (WMM) protocol and the quality of service (QoS) level be set to Platinum.

Before you can configure CAC parameters on a network, you must complete the following prerequisites:

- Disable all WLANs with WMM enabled by entering the **wlan wlan_name shutdown** command.
- Disable the radio network you want to configure by entering the **ap dot11 {24ghz | 5ghz} shutdown** command.
- Save the new configuration.
- Enable voice or video CAC for the network you want to configure by entering the **ap dot11 {24ghz | 5ghz} cac voice acm** or **ap dot11 {24ghz | 5ghz} cac video acm** commands.

Examples

This example shows how to enable the bandwidth-based CAC:

```
Controller(config)# ap dot11 24ghz cac voice acm
```

This example shows how to enable the load-based CAC on the voice access category:

```
Controller(config)# ap dot11 24ghz cac voice load-based
```

This example shows how to specify the percentage of the maximum allocated bandwidth for voice applications on the selected radio band:

```
Controller(config)# ap dot11 24ghz cac voice max-bandwidth 50
```

This example shows how to configure the percentage of the maximum allocated bandwidth reserved for roaming voice clients on the selected radio band:

```
Controller(config)# ap dot11 24ghz cac voice roam-bandwidth 10
```

This example shows how to configure the bandwidth and voice packetization interval for the G729 SIP codec on a 2.4 GHz band:

```
Controller(config)# ap dot11 24ghz cac voice sip bandwidth 8 sample-interval 40
```

This example shows how to configure the number of aggregated voice traffic specifications stream with a stream size of 85000 and with a maximum of 5 streams:

```
Controller(config)# ap dot11 24ghz cac voice stream-size 85000 max-streams 5
```

This example shows how to enable the voice TSPEC inactivity timeout messages received from an access point:

```
Controller(config)# ap dot11 24ghz cac voice tspec-inactivity-timeout enable
```

ap dot11 cleanair

To configure CleanAir on 802.11 networks, use the **ap dot11 cleanair** command. To disable CleanAir on 802.11 networks, use the **no** form of this command.

ap dot11 {24ghz| 5ghz} cleanair

no ap dot11 {24ghz| 5ghz} cleanair

Syntax Description		
24ghz		Specifies the 2.4 GHz band.
5ghz		Specifies the 5 GHz band.
cleanair		Specifies CleanAir on the 2.4 GHz or 5 GHz band.

Command Default Disabled

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how to enable the CleanAir settings on the 2.4 GHz band:

```
Controller(config)# ap dot11 24ghz cleanair
```

ap dot11 cleanair alarm air-quality

To configure CleanAir air-quality alarms for Cisco lightweight access points, use the **ap dot11 cleanair alarm air-quality** command.

ap dot11 {24ghz| 5ghz} **cleanair alarm air-quality** [**threshold** *value*]

Syntax Description		
24ghz		Specifies the 2.4 GHz band.
5ghz		Specifies the 5 GHz band.
threshold		Specifies the air-quality alarm threshold.
<i>value</i>		Air quality alarm threshold (1 is bad air quality, and 100 is good air quality).

Command Default Disabled

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the CleanAir 2.4 GHz air-quality threshold to 90:

```
Controller(config)# ap dot11 24ghz cleanair alarm air-quality threshold 90
```

ap dot11 cleanair alarm device

To configure the CleanAir interference devices alarms on the 2.4 GHz or 5 GHz bands, use the **ap dot11 cleanair alarm device** command. To disable the CleanAir interference devices alarms on the 802.11 networks, use the **no** form of this command.

```
ap dot11 {24ghz| 5ghz} cleanair alarm device {all| bt-discovery| bt-link| canopy| cont-tx| dect-like| fh|
inv| jammer| mw-oven| nonstd| superag| tdd-tx| video| wimax-fixed| wimax-mobile| xbox| zigbee}
```

```
no ap dot11 {24ghz| 5ghz} cleanair
```

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
all	Specifies all the device types at once.
bt-discovery	Specifies the Bluetooth device in discovery mode.
bt-link	Specifies the Bluetooth active link.
canopy	Specifies the Canopy devices.
cont-tx	Specifies the continuous transmitter.
dect-like	Specifies a Digital Enhanced Cordless Communication (DECT)-like phone.
fh	Specifies the frequency hopping devices.
inv	Specifies the devices using spectrally inverted Wi-Fi signals.
jammer	Specifies the jammer.
mw-oven	Specifies the microwave oven devices.
nonstd	Specifies the devices using nonstandard Wi-Fi channels.
superag	Specifies 802.11 SuperAG devices.
tdd-tx	Specifies the TDD transmitter.
video	Specifies video cameras.
wimax-fixed	Specifies a WiMax fixed device.
wimax-mobile	Specifies a WiMax mobile device.
xbox	Specifies the Xbox device.

zigbee	Specifies the ZigBee device.
---------------	------------------------------

Command Default Disabled

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to disable alarms for ZigBee interference detection:

```
Controller(config)# no ap dot11 24ghz cleanair alarm device zigbee
```

This example shows how to enable alarms for detection of Bluetooth links:

```
Controller(config)# ap dot11 24ghz cleanair alarm device bt-link
```

ap dot11 cleanair device

To configure CleanAir interference device types, use the **ap dot11 cleanair device** command.

ap dot11 24ghz cleanair device [**all**| **bt-discovery**| **bt-link**| **canopy**| **cont-tx**| **dect-like**| **fh**| **inv**| **jammer**| **mw-oven**| **nonstd**| **superag**| **tdd-tx**| **video**| **wimax-fixed**| **wimax-mobile**| **xbox**| **zigbee**]

Syntax Description

all	Specifies all device types.
device	Specifies the CleanAir interference device type.
bt-discovery	Specifies the Bluetooth device in discovery mode.
bt-link	Specifies the Bluetooth active link.
canopy	Specifies the Canopy devices.
cont-tx	Specifies the continuous transmitter.
dect-like	Specifies a Digital Enhanced Cordless Communication (DECT)-like phone.
fh	Specifies the 802.11 frequency hopping devices.
inv	Specifies the devices using spectrally inverted Wi-Fi signals.
jammer	Specifies the jammer.
mw-oven	Specifies the microwave oven devices.
nonstd	Specifies the devices using nonstandard Wi-Fi channels.
superag	Specifies 802.11 SuperAG devices.
tdd-tx	Specifies the TDD transmitter.
video	Specifies video cameras.
wimax-fixed	Specifies a WiMax fixed device.
wimax-mobile	Specifies a WiMax mobile device.
xbox	Specifies the Xbox device.
zigbee	Specifies the ZigBee device.

Command Default

None

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the controller to monitor ZigBee interferences:

```
Controller(config)# ap dot11 24ghz cleanair device zigbee
```

ap dot11 dot11n

To configure settings for an 802.11n network, use the **ap dot11 dot11n** command.

```
ap dot11 {24ghz|5ghz} dot11n {a-mpdu tx priority {priority_value|all}| a-msdu tx priority {priority_value|all}| guard-interval {any|long}| mcs tx rate| rifs rx}
```

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
dot11n	Enables 802.11n support.
a-mpdu tx priority	Specifies the traffic that is associated with the priority level that uses A-MPDU transmission.
<i>priority_value</i>	Aggregated MAC protocol data unit priority level from 0 to 7.
all	Specifies all of the priority levels at once.
a-msdu tx priority	Specifies the traffic that is associated with the priority level that uses A-MSDU transmission.
<i>priority_value</i>	Aggregated MAC protocol data unit priority level from 0 to 7.
all	Specifies all of the priority levels at once.
guard-interval	Specifies the guard interval.
any	Enables either a short or a long guard interval.
long	Enables only a long guard interval.
mcs tx rate	Specifies the modulation and coding scheme (MCS) rates at which data can be transmitted between the access point and the client.
<i>rate</i>	Specifies the modulation and coding scheme data rates. Note The range is from 0 to 23.
rifs rx	Specifies the Reduced Interframe Space (RIFS) between data frames.

Command Default

By default, priority 0 is enabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Aggregation is the process of grouping packet data frames together rather than transmitting them separately. Two aggregation methods are available: Aggregated MAC Protocol Data Unit (A-MPDU) and Aggregated MAC Service Data Unit (A-MSDU). A-MPDU is performed in the software; A-MSDU is performed in the hardware.

Aggregated MAC Protocol Data Unit priority levels assigned per traffic type are as follows:

- 0—Best effort
- 1—Background
- 2—Spare
- 3—Excellent effort
- 4—Controlled load
- 5—Video, less than 100-ms latency and jitter
- 6—Voice, less than 10-ms latency and jitter
- 7—Network control
- all—Configure all of the priority levels at once.



Note Configure the priority levels to match the aggregation method used by the clients.

Examples This example shows how to enable 802.11n support on a 2.4 GHz band:

```
Controller(config)# ap dot11 24ghz dot11n
```

This example shows how to configure all the priority levels at once so that the traffic that is associated with the priority level uses A-MSDU transmission:

```
Controller(config)# ap dot11 24ghz dot11n a-msdu tx priority all
```

This example shows how to enable only long guard intervals:

```
Controller(config)# ap dot11 24ghz dot11n guard-interval long
```

This example shows how to specify MCS rates:

```
Controller(config)# ap dot11 24ghz dot11n mcs tx 5
```

This example shows how to enable RIFS:

```
Controller(config)# ap dot11 24ghz dot11n rifs rx
```

ap dot11 dtpc

To configure Dynamic Transmit Power Control (DTPC) settings, Cisco Client eXtension (CCX) version 5 expedited bandwidth request feature, and the fragmentation threshold on an 802.11 network, use the **ap dot11 dtpc** command.

ap dot11 {24ghz| 5ghz} {dtpc| exp-bwreq| fragmentation *threshold*}

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
dtpc	Specifies Dynamic Transport Power Control (DTPC) settings. Note This option is enabled by default.
exp-bwreq	Specifies Cisco Client eXtension (CCX) version 5 expedited bandwidth request feature. Note The expedited bandwidth request feature is disabled by default.
fragmentation <i>threshold</i>	Specifies the fragmentation threshold. Note This option can only used be when the network is disabled using the ap dot11 {24ghz 5ghz} shutdown command.
<i>threshold</i>	Threshold. The range is from 256 to 2346 bytes (inclusive).

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

When the CCX version 5 expedited bandwidth request feature is enabled, the controller configures all joining access points for this feature.

Examples

This example shows how to enable DTPC for the 5 GHz band:

```
Controller(config)# ap dot11 5ghz dtpc
```

This example shows how to enable the CCX expedited bandwidth settings:

```
Controller(config)# ap dot11 5ghz exp-bwrep
```

This example shows how to configure the fragmentation threshold on the 5 GHz band with the threshold number of 1500 bytes:

```
Controller(config)# ap dot11 5ghz fragmentation 1500
```

ap dot11 edca-parameters

To enable a specific enhanced distributed channel access (EDCA) profile on the 2.4 GHz or 5 GHz bands, use the **ap dot11 edca-parameters** command. To disable an EDCA profile on the 2.4 GHz or 5 GHz bands, use the **no** form of this command.

```
ap dot11 {24ghz|5ghz} edca-parameters {custom-voice|optimized-video-voice|optimized-voice|svp-voice|wmm-default}
```

```
no ap dot11 {24ghz|5ghz} edca-parameters {custom-voice|optimized-video-voice|optimized-voice|svp-voice|wmm-default}
```

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
edca-parameters	Specifies a specific enhanced distributed channel access (EDCA) profile on the 802.11 networks.
custom-voice	Enables custom voice EDCA parameters.
optimized-video-voice	Enables EDCA voice- and video-optimized profile parameters. Choose this option when both voice and video services are deployed on your network.
optimized-voice	Enables EDCA voice-optimized profile parameters. Choose this option when voice services other than SpectraLink are deployed on your network.
svp-voice	Enables SpectraLink voice priority parameters. Choose this option if SpectraLink phones are deployed on your network to improve the quality of calls.
wmm-default	Enables the Wi-Fi Multimedia (WMM) default parameters. Choose this option when voice or video services are not deployed on your network.

Command Default

wmm-default

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable SpectraLink voice priority parameters:

```
Controller(config) # ap dot11 24ghz edca-parameters svp-voice
```

ap dot11 rrm group-mode

To set the 802.11 automatic RF group selection mode on, use the **ap dot11 rrm group-mode** command. To set the 802.11 automatic RF group selection mode off, use the **no** form of this command.

ap dot11 {5ghz| 24ghz} rrm group-mode {auto| leader| off} restart}

no ap dot11 {5ghz| 24ghz} rrm group-mode

Syntax Description

5ghz	Specifies the 2.4 GHz band.
24ghz	Specifies the 5 GHz band.
auto	Sets the 802.11 RF group selection to automatic update mode.
leader	Sets the 802.11 RF group selection to static mode, and sets this controller as the group leader.
off	Sets the 802.11 RF group selection to off.
restart	Restarts the 802.11 RF group selection.

Command Default

auto

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to turn the auto RF group selection mode on the 5 GHz band:

```
Controller(config)# ap dot11 5ghz rrm group-mode auto
```

ap dot11 rrm channel cleanair-event

To configure CleanAir event-driven Radio Resource Management (RRM) parameters for all 802.11 Cisco lightweight access points, use the **ap dot11 rrm channel cleanair-event** command. When this parameter is configured, CleanAir access points can change their channel when a source of interference degrades the operations, even if the RRM interval has not expired yet.

ap dot11 {24ghz|5ghz} **rrm channel** {cleanair-event sensitivity *value*}

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
sensitivity	Sets the sensitivity for CleanAir event-driven RRM.
<i>value</i>	Sensitivity value. You can specify any one of the following three optional sensitivity values: <ul style="list-style-type: none"> • low—Specifies low sensitivity. • medium—Specifies medium sensitivity. • high—Specifies high sensitivity.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to set the high sensitivity for CleanAir event-driven RRM:

```
Controller(config)# ap dot11 24ghz rrm channel cleanair-event sensitivity high
```

ap dot11 l2roam rf-params

To configure the 2.4 GHz or 5 GHz Layer 2 client roaming parameters, use the **ap dot11 l2roam rf-params** command.

ap dot11 {24ghz|5ghz} **l2roam rf-params custom** *min-rssi roam-hyst scan-thresh trans-time*

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
custom	Specifies custom Layer 2 client roaming RF parameters.
<i>min-rssi</i>	Minimum received signal strength indicator (RSSI) that is required for the client to associate to the access point. If the client's average received signal power dips below this threshold, reliable communication is usually impossible. Clients must already have found and roamed to another access point with a stronger signal before the minimum RSSI value is reached. The valid range is -80 to -90 dBm, and the default value is -85 dBm.
<i>roam-hyst</i>	How much greater the signal strength of a neighboring access point must be in order for the client to roam to it. This parameter is intended to reduce the amount of roaming between access points if the client is physically located on or near the border between the two access points. The valid range is 2 to 4 dB, and the default value is 2 dB.
<i>scan-thresh</i>	Minimum RSSI that is allowed before the client should roam to a better access point. When the RSSI drops below the specified value, the client must be able to roam to a better access point within the specified transition time. This parameter also provides a power-save method to minimize the time that the client spends in active or passive scanning. For example, the client can scan slowly when the RSSI is above the threshold and scan more rapidly when the RSSI is below the threshold. The valid range is -70 to -77 dBm, and the default value is -72 dBm.
<i>trans-time</i>	Maximum time allowed for the client to detect a suitable neighboring access point to roam to and to complete the roam, whenever the RSSI from the client's associated access point is below the scan threshold. The valid range is 1 to 10 seconds, and the default value is 5 seconds.

Command Default

<i>min-rssi</i>	-85
<i>roam-hyst</i>	2
<i>scan-thresh</i>	-72
<i>trans-time</i>	5

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure custom Layer 2 client roaming parameters on an 802.11a network:

```
Controller(config)# ap dot11 5ghz l2roam rf-params custom -80 2 -70 7
```

ap dot11 media-stream

To configure media stream multicast-direct and video-direct settings on an 802.11 network, use the **ap dot11 media-stream** command.

```
ap dot11 {24ghz| 5ghz} media-stream {multicast-direct {admission-besteffort| client-maximum value|
radio-maximum value}| video-redirect}
```

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
multicast-direct	Specifies the multicast-direct for the 2.4 GHz or a 5 GHz band.
admission-besteffort	Admits the media stream to the best-effort queue.
client-maximum <i>value</i>	Specifies the maximum number of streams allowed on a client.
radio-maximum <i>value</i>	Specifies the maximum number of streams allowed on a 2.4 GHz or a 5 GHz band.
video-redirect	Specifies the media stream video-redirect for the 2.4 GHz or a 5 GHz band.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Before you configure the media stream multicast-direct or video-redirect on a 802.11 network, ensure that the network is nonoperational.

Examples

This example shows how to enable media stream multicast-direct settings on the 5 GHz band:

```
Controller(config)# ap dot11 5ghz media-stream multicast-direct
```

This example shows how to admit the media stream to the best-effort queue if there is not enough bandwidth to prioritize the flow:

```
Controller(config)# ap dot11 5ghz media-stream multicast-direct admission-besteffort
```

This example shows how to set the maximum number of streams allowed on a client:

```
Controller(config)# ap dot11 5ghz media-stream multicast-direct client-maximum 10
```

This example shows how to enable media stream traffic redirection on the 5 GHz band:

```
Controller(config)# ap dot11 5ghz media-stream video-redirect
```

ap dot11 rrm ccx location-measurement

To configure cisco client Extensions (CCX) client location measurements for 2.4 GHz and 5 GHz bands, use the **ap dot11 rrm ccx location-measurement** command.

ap dot11 {24ghz|5ghz} **rrm ccx location-measurement** {disable|interval}

Syntax Description		
24ghz		Specifies the 2.4-GHz band.
5ghz		Specifies the 5-GHz band.
disable		Disables support for CCX client location measurements.
<i>interval</i>		Interval from 10 to 32400.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how to disable support for 2.4 GHz CCX client location measurements:

```
Controller(config)# no ap dot11 24ghz rrm ccx location-measurement
```

ap dot11 rrm channel dca

To configure Dynamic Channel Assignment (DCA) algorithm parameters on 802.11 networks, use the **ap dot11 rrm channel dca** command.

```
ap dot11 {24ghz|5ghz} rrm channel dca {channel_number| anchor-time value| global {auto| once}| interval value| min-metric value| sensitivity {high| low| medium}}
```

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
<i>channel_number</i>	Channel number to be added to the DCA list. Note The range is from 1 to 14.
anchor-time	Specifies the anchor time for DCA.
<i>value</i>	Hour of time between 0 and 23. These values represent the hour from 12:00 a.m. to 11:00 p.m.
global	Specifies the global DCA mode for the access points in the 802.11 networks.
auto	Enables auto-RF.
once	Enables one-time auto-RF.
interval	Specifies how often the DCA is allowed to run.
<i>value</i>	Interval between the times when DCA is allowed to run. Valid values are 0, 1, 2, 3, 4, 6, 8, 12, or 24 hours. 0 is 10 minutes (600 seconds). Default value is 0 (10 minutes).
min-metric	Specifies the DCA minimum RSSI energy metric.
<i>value</i>	Minimum RSSI energy metric value from -100 to -60.
sensitivity	Specifies how sensitive the DCA algorithm is to environmental changes (for example, signal, load, noise, and interference) when determining whether or not to change channels.
high	Specifies that the DCA algorithm is not particularly sensitive to environmental changes. See the "Usage Guidelines" section for more information.
low	Specifies that the DCA algorithm is moderately sensitive to environmental changes. See the "Usage Guidelines" section for more information.
medium	Specifies that the DCA algorithm is highly sensitive to environmental changes. See the "Usage Guidelines" section for more information.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines The DCA sensitivity thresholds vary by radio band as shown in the table below. To aid in troubleshooting, the output of this command shows an error code for any failed calls. The table below explains the possible error codes for failed calls.

Table 21: DCA Sensitivity Threshold

Sensitivity	2.4 Ghz DCA Sensitivity Threshold	5 Ghz DCA Sensitivity Threshold
High	5 dB	5 dB
Medium	15 dB	20 dB
Low	30 dB	35 dB

Examples This example shows how to configure the controller to start running DCA at 5 pm for the 2.4 GHz band:

```
Controller(config)# ap dot11 24ghz rrm channel dca anchor-time 17
```

This example shows how to set the DCA algorithm to run every 10 minutes for the 2.4 GHz band:

```
Controller(config)# ap dot11 24ghz rrm channel dca interval 0
```

This example shows how to configure the value of DCA algorithm's sensitivity to low on the 2.4 GHz band:

```
Controller(config)# ap dot11 24ghz rrm channel dca sensitivity low
```

ap dot11 rrm group-member

To configure members in an 802.11 static RF group, use the **ap dot11 rrm group-member** command. To remove members from 802.11 RF group, use the **no** form of this command.

ap dot11 {24ghz| 5ghz} **rrm group-member** *controller-name controller-ip*

no ap dot11 {24ghz| 5ghz} **rrm group-member** *controller-name controller-ip*

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
<i>controller-name</i>	Name of the controller to be added.
<i>controller-ip</i>	IP address of the controller to be added.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to add a controller in the 5 GHz band RF group:

```
Controller(config)# ap dot11 5ghz rrm group-member cisco-controller 192.0.2.54
```

ap dot11 rrm logging

To configure report log settings on supported 802.11 networks, use the **ap dot11 rrm logging** command.

ap dot11 {24ghz| 5ghz} **rrm logging** {channel| coverage| foreign| load| noise| performance| txpower}

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
channel	Turns the channel change logging mode on or off. The default mode is off (Disabled).
coverage	Turns the coverage profile logging mode on or off. The default mode is off (Disabled).
foreign	Turns the foreign interference profile logging mode on or off. The default mode is off (Disabled).
load	Turns the load profile logging mode on or off. The default mode is off (Disabled).
noise	Turns the noise profile logging mode on or off. The default mode is off (Disabled).
performance	Turns the performance profile logging mode on or off. The default mode is off (Disabled).
txpower	Turns the transit power change logging mode on or off. The default mode is off (Disabled).

Command Default

Disabled

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to turn the 5 GHz logging channel selection mode on:

```
Controller(config)# ap dot11 5ghz rrm logging channel
```

This example shows how to turn the 5 GHz coverage profile violation logging selection mode on:

```
Controller(config)# ap dot11 5ghz rrm logging coverage
```

This example shows how to turn the 5 GHz foreign interference profile violation logging selection mode on:

```
Controller(config)# ap dot11 5ghz rrm logging foreign
```

This example shows how to turn the 5 GHz load profile logging mode on:

```
Controller(config)# ap dot11 5ghz rrm logging load
```

This example shows how to turn the 5 GHz noise profile logging mode on:

```
Controller(config)# ap dot11 5ghz rrm logging noise
```

This example shows how to turn the 5 GHz performance profile logging mode on:

```
Controller(config)# ap dot11 5ghz rrm logging performance
```

This example shows how to turn the 5 GHz transmit power change mode on:

```
Controller(config)# ap dot11 5ghz rrm logging txpower
```

ap dot11 rrm monitor

To Configure monitor settings on the 802.11 networks, use the **ap dot11 rrm monitor** command.

```
ap dot11 {24ghz| 5ghz} rrm monitor {channel-list {all| country| dca} | coverage| load| noise| signal}
seconds
```

Syntax Description

24ghz	Specifies the 802.11b parameters.
5ghz	Specifies the 802.11a parameters.
channel-list all	Monitors the noise, interference, and rogue monitoring channel list for all channels.
channel-list country	Monitors the noise, interference, and rogue monitoring channel list for the channels used in the configured country code.
channel-list dca	Monitors the noise, interference, and rogue monitoring channel list for the channels used by automatic channel assignment.
coverage	Specifies the coverage measurement interval.
load	Specifies the load measurement interval.
noise	Specifies the noise measurement interval.
signal	Specifies the signal measurement interval.
<i>seconds</i>	Measurement interval time from 60 to 3600 seconds.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to monitor the channels used in the configured country:

```
Controller(config)# ap dot11 24ghz rrm monitor channel-list country
```

This example shows how to set the coverage measurement interval to 60 seconds:

```
Controller(config)# ap dot11 24ghz rrm monitor coverage 60
```

ap dot11 rrm ndp-type

To configure the 802.11 access point radio resource management neighbor discovery protocol type, use the `ap dot11 rrm ndp-type` command.

```
ap dot11 {24ghz| 5ghz} rrm ndp-type {protected| transparent}
```

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
protected	Specifies the Tx RRM protected (encrypted) neighbor discovery protocol.
transparent	Specifies the Tx RRM transparent (not encrypted) neighbor discovery protocol.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Before you configure the 802.11 access point RRM neighbor discovery protocol type, ensure that you have disabled the network by entering the `ap dot11 {24ghz | 5ghz} shutdown` command.

Examples

This example shows how to enable the 802.11a access point RRM neighbor discovery protocol type as protected:

```
Controller(config)# ap dot11 5ghz rrm ndp-type protected
```

ap dot1x max-sessions

To configure the maximum number of simultaneous 802.1X sessions allowed per access point, use the **ap dot1x max-sessions** command.

ap dot1x max-sessions *num-of-sessions*

Syntax Description

<i>num-of-sessions</i>	Number of maximum 802.1X sessions initiated per AP at a time. The range is from 0 to 255, where 0 indicates unlimited.
------------------------	--

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

It is required to limit the number of simultaneous 802.1X sessions initiated per access point to protect against flooding attacks caused by using 802.1X messages.

Examples

This example shows how to configure the maximum number of simultaneous 802.1X sessions:

```
Controller(config)# ap dot1x max-sessions 100
```

ap dot1x username

To configure the 802.1X username and password for all access points that are currently joined to the controller and any access points that join the controller in the future, use the **ap dot1x username** command. To disable the 802.1X username and password for all access points that are currently joined to the controller, use the **no** form of this command.

ap dot1x username *user-id* **password** {0|8} *password-string*

no ap dot1x username *user-id* **password** {0|8} *password-string*

Syntax Description

<i>user-id</i>	Username.
password	Specifies an 802.1X password for all access points.
0	Specifies an unencrypted password.
8	Specifies an AES encrypted password.
<i>password_string</i>	Password.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You should enter a strong password. Strong passwords have the following characteristics:

- They are at least eight characters long.
- They contain a combination of uppercase and lowercase letters, numbers, and symbols.
- They are not words in any language.

You can set the values for a specific access point.

Examples

This example shows how to configure the global authentication username and password for all access points:

```
Controller(config)# ap dot1x username cisco123 password 0 cisco2020
```

ap ethernet duplex

To configure the Ethernet port duplex and speed settings of the lightweight access points, use the **ap ethernet duplex** command. To disable the Ethernet port duplex and speed settings of lightweight access points, use the **no** form of this command.

ap ethernet duplex *duplex speed speed*

no ap ethernet

Syntax Description

<i>duplex</i>	Ethernet port duplex settings. You can specify the following options to configure the duplex settings: <ul style="list-style-type: none"> • auto—Specifies the Ethernet port duplex auto settings. • half—Specifies the Ethernet port duplex half settings. • full—Specifies the Ethernet port duplex full settings.
speed	Specifies the Ethernet port speed settings.
<i>speed</i>	Ethernet port speed settings. You can specify the following options to configure the speed settings: <ul style="list-style-type: none"> • auto—Specifies the Ethernet port speed to auto. • 10—Specifies the Ethernet port speed to 10 Mbps. • 100—Specifies the Ethernet port speed to 100 Mbps. • 1000—Specifies the Ethernet port speed to 1000 Mbps.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the Ethernet port duplex full settings as 1000 Mbps for all access points:

```
Controller(config)# ap ethernet duplex full speed 1000
```

ap group

To create a new access point group, use the **ap group** command. To remove an access point group, use the **no** form of this command.

ap group *group-name*

no ap group *group-name*

Syntax Description

<i>group-name</i>	Access point group name.
-------------------	--------------------------

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

An error message appears if you try to delete an access point group that is used by at least one access point. Before you can delete an AP group, move all APs in this group to another group. The access points are not moved to the default-group access point group automatically. To see the APs, enter the **show ap summary** command. To move access points, enter the **ap name Cisco-AP ap-groupname Group-Name** command.

Examples

This example shows how to create a new access point group:

```
Controller(config)# ap group sampleapgroup
```

ap image

To configure an image on all access points that are associated to the controller, use the **ap image** command.

ap image {predownload| reset| swap}

Syntax Description

predownload	Instructs all the access points to start predownloading an image.
reset	Instructs all the access points to reboot.
swap	Instructs all the access points to swap the image.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to predownload an image to all access points:

```
Controller# ap image predownload
```

This example shows how to reboot all access points:

```
Controller# ap image reset
```

This example shows how to swap the access point's primary and secondary images:

```
Controller# ap image swap
```

ap ipv6 tcp adjust-mss

To configure IPv6 TCP maximum segment size (MSS) value for all Cisco APs, use the **ap ipv6 tcp adjust-mss** command.

ap ipv6 tcp adjust-mss *size*

no ap ipv6 tcp adjust-mss *size*

Syntax Description		
	adjust-mss	Configures IPv6 TCP MSS settings for all Cisco APs.
	<i>size</i>	MSS value in the range of 500 to 1440.

Command Default None

Command Modes Global configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines The MSS value must be in the range of 500 to 1440.

Examples This example shows how to configure the IPv6 TCP MSS value to 600 for all Cisco APs:

```
Controller(config)# ap ipv6 tcp adjust-mss 600
```

ap led

To enable the LED state for an access point, use the **ap led** command. To disable the LED state for an access point, use the **no** form of this command.

ap led

no ap led

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable the LED state for an access point:

```
Controller(config)# ap led
```

ap link-encryption

To enable Datagram Transport Layer Security (DTLS) data encryption for access points, use the **ap link-encryption** command. To disable the DTLS data encryption for access points, use the **no** form of this command.

ap link-encryption

no ap link-encryption

Syntax Description

This command has no keywords and arguments.

Command Default

Disabled

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable data encryption for all the access points that are joined to the controller:

```
Controller(config)# ap link-encryption
```

ap link-latency

To enable link latency for all access points that are currently associated to the controller, use the **ap link-latency** command. To disable link latency all access points that are currently associated to the controller, use the **no** form of this command.

ap link-latency [reset]

no ap link-latency

Syntax Description

reset	(Optional) Resets all link latency for all access points.
--------------	---

Command Default

Link latency is disabled by default.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

This command enables or disables link latency only for those access points that are currently joined to the controller. It does not apply to access points that join in the future.

Examples

This example shows how to enable the link latency for all access points:

```
Controller(config)# ap link-latency
```

ap mgmtuser username

To configure the username, password, and secret password for access point management, use the **ap mgmtuser username** command.

ap mgmtuser username *username* **password** *password_type* *password* **secret** *secret_type* *secret*

Syntax Description

<i>username</i>	Specifies the username for access point management.
password	Specifies the password for access point management.
<i>password_type</i>	<p>Password type. You can specify any one of the following two password types:</p> <ul style="list-style-type: none"> • 0—Specifies that an unencrypted password will follow. • 8—Specifies that an AES encrypted password will follow.
<i>password</i>	<p>Access point management password.</p> <p>Note The password does not get encrypted by service-password encryption.</p>
secret	Specifies the secret password for privileged access point management.
<i>secret_type</i>	<p>Secret type. You can specify any one of the following two secret types:</p> <ul style="list-style-type: none"> • 0—Specifies that an unencrypted secret password will follow. • 8—Specifies that an AES encrypted secret password will follow.
<i>secret</i>	Access point management secret password.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

To specify a strong password, the following password requirements should be met:

- The password should contain characters from at least three of the following classes: lowercase letters, uppercase letters, digits, and special characters.
- No character in the password can be repeated more than three times consecutively.
- The password should not contain a management username or the reverse of a username.
- The password should not contain words such as Cisco, oscic, admin, nimda or any variant obtained by changing the capitalization of letters by substituting l, |, or ! or substituting 0 for o or substituting \$ for s.

To specify a strong secret password, the following requirement should be met:

- The secret password should contain characters from at least three of the following classes: lowercase letters, uppercase letters, digits, or special characters.

Examples

This example shows how to add a username, password, and secret password for access point management:

```
Controller(config)# ap mgmtuser username glbusr password 0 Arc_1234 secret 0 Mid_1234
```

ap name ap-groupname

To add a Cisco lightweight access point to a specific access point group, use the **ap name ap-groupname** command.

ap name *ap-name* **ap-groupname** *group-name*

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
<i>group-name</i>	Descriptive name for the access point group.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The Cisco lightweight access point must be disabled before changing this parameter.

Examples

This example shows how to add the access point AP01 to the access point group superusers:

```
Controller# ap name AP01 ap-groupname superusers
```

ap name bhrate

To configure the Cisco bridge backhaul Tx rate, use the **ap name bhrate** command.

ap name *ap-name* **bhrate** *kbps*

Syntax Description

<i>ap-name</i>	Name of the Cisco access point.
<i>kbps</i>	Cisco bridge backhaul Tx rate in kbps. The valid values are 6000, 12000, 18000, 24000, 36000, 48000, and 54000.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the Cisco bridge backhaul Tx rate to 54000 kbps:

```
Controller# ap name AP02 bhrate 54000
```

ap name bridgegroupname

To set a bridge group name on a Cisco lightweight access point, use the **ap name bridgegroupname** command. To delete a bridge group name on a Cisco lightweight access point, use the **no** form of this command.

ap name *ap-name* **bridgegroupname** *bridge_group_name*

ap name *ap-name* **no bridgegroupname**

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Only access points with the same bridge group name can connect to each other. Changing the access point bridgegroupname may strand the bridge access point.

Examples

This example shows how to set a bridge group name on Cisco access point's bridge group name AP02:

```
Controller# ap name AP02 bridgegroupname West
```

This example shows how to delete a bridge group name on Cisco access point's bridge group name AP02:

```
Controller# ap name AP02 no bridgegroupname
```

ap name capwap retransmit

To configure the access point control packet retransmission interval and control packet retransmission count, use the **ap name capwap retransmit** command.

ap name *ap-name* **capwap retransmit** {**count** *count-value*| **interval** *interval-time*}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
count	Sets the number of times control packet will be retransmitted.
<i>count-value</i>	Number of times that the control packet will be retransmitted from 3 to 8.
interval	Sets the control packet retransmission timeout interval.
<i>interval-time</i>	Control packet retransmission timeout from 2 to 5 seconds.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the retransmission interval for an access point:

```
Controller# ap name AP01 capwap retransmit interval 5
```

This example shows how to configure the retransmission retry count for a specific access point:

```
Controller# ap name AP01 capwap retransmit count 5
```

ap name command

To execute a command remotely on a specific Cisco access point, use the **ap name command** command.

ap name *ap-name* **command** *command*

Syntax Description

<i>ap-name</i>	Name of the Cisco access point.
<i>command</i>	Command to be executed on a Cisco access point.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to remotely enter the **show ip interface brief** command on the Cisco access point named TSIM_AP2:

```
Controller# ap name AP2 command show ip interface brief
```

ap name core-dump

To configure a Cisco lightweight access point's memory core dump, use the **ap name core-dump** command. To disable a Cisco lightweight access point's memory core dump, use the **no** form of this command.

ap name *ap-name* **core-dump** *tftp-ip-addr filename* {**compress**|**uncompress**}

ap name *ap-name* [**no**]**core-dump**

Syntax Description

<i>ap-name</i>	Name of the access point.
<i>tftp-ip-addr</i>	IP address of the TFTP server to which the access point sends core dump files.
<i>filename</i>	Name that the access point used to label the core file.
compress	Compresses the core dump file.
uncompress	Uncompresses the core dump file.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The access point must be able to reach the TFTP server before you can use this command.

Examples

This example shows how to configure and compress the core dump file:

```
Controller# ap name AP2 core-dump 192.1.1.1 log compress
```

ap name country

To configure the country of operation for a Cisco lightweight access point, use the **ap name country** command.

ap name *ap-name* **country** *country-code*

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
<i>country-code</i>	Two-letter or three-letter country code.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Cisco controllers must be installed by a network administrator or qualified IT professional and the installer must select the proper country code. Following installation, access to the unit should be password protected by the installer to maintain compliance with regulatory requirements and to ensure proper unit functionality. See the related product guide for the most recent country codes and regulatory domains. Also, access point regulatory domains are defined during the access point manufacturing process. You can change the access point country code if the new country code matches a country that is valid within the access point regulatory domain. If you try to enter a country that is not valid to the access point regulatory domain, the command fails.

Examples

This example shows how to configure the Cisco lightweight access point's country code to DE:

```
Controller# ap name AP2 country JP
```

ap name crash-file

To manage crash data and radio core files for the Cisco access point, use the **ap name crash-file** command.

ap name *ap-name* **crash-file** {**get-crash-data**|**get-radio-core-dump** {**slot 0**|**slot 1**}}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
get-crash-data	Collects the latest crash data for a Cisco lightweight access point.
get-radio-core-dump	Gets a Cisco lightweight access point's radio core dump
slot	Slot ID for Cisco access point.
0	Specifies Slot 0.
1	Specifies Slot 1.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to collect the latest crash data for access point AP3:

```
Controller# ap name AP3 crash-file get-crash-data
```

This example shows how to collect the radio core dump for access point AP02 and slot 0:

```
Controller# ap name AP02 crash-file get-radio-core-dump slot 0
```

ap name dot11 24ghz rrm coverage

To configure coverage hole detection settings on the 2.4 GHz band, use the **ap name dot11 24ghz rrm coverage** command.

ap name *ap-name* **dot11 24ghz rrm coverage** {**exception** *value*| **level** *value*}

Syntax Description

<i>ap-name</i>	Name of the Cisco access point.
exception	Specifies the percentage of clients on an access point that are experiencing a low signal level but cannot roam to another access point.
<i>value</i>	Percentage of clients. Valid values are from 0 to 100%. Note The default is 25%.
level	Specifies the minimum number of clients on an access point with a received signal strength indication (RSSI) value at or below the data or voice RSSI threshold.
<i>value</i>	Minimum number of clients. Valid values are from 1 to 75. Note The default is 3.

Command Default

The default for the *exception* parameter is 25% and the default for the *level* parameter is 3.

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

If you enable coverage hole detection, the controller automatically determines, based on data that is received from the access points, whether any access points have clients that are potentially located in areas with poor coverage.

If both the number and percentage of failed packets exceed the values that you entered in the **ap dot11 24ghz rrm coverage data packet-count** *count* and **ap dot11 24ghz rrm coverage data fail-percentage** *percentage* commands for a 5-second period, the client is considered to be in a pre-alarm condition. The controller uses this information to distinguish between real and false coverage holes and excludes clients with poor roaming logic. A coverage hole is detected if both the number and percentage of failed clients meet or exceed the values entered in the **ap dot11 24ghz rrm coverage exception** and **ap dot11 24ghz rrm coverage level** commands over a 90-second period. The controller determines whether the coverage hole can be corrected

and, if appropriate, mitigates the coverage hole by increasing the transmit power level for that specific access point.

Examples

This example shows how to specify the percentage of clients for an access point 2.4 GHz radio that is experiencing a low signal level:

```
Controller# ap name AP2 dot11 24ghz rrm coverage exception 25%
```

This example shows how to specify the minimum number of clients on an 802.11b access point with an RSSI value at or below the RSSI threshold:

```
Controller# ap name AP2 dot11 24ghz rrm coverage level 60
```

ap name dot11 49ghz rrm profile

To configure Radio Resource Management (RRM) performance profile settings for a Cisco lightweight access point on a 4.9 GHz public safety channel, use the **ap name dot11 49ghz rrm profile** command.

ap name *ap-name* **dot11 49ghz rrm profile** {**clients** *value*| **customize**| **exception** *value*| **foreign** *value*| **level** *value*| **noise** *value*| **throughput** *value*| **utilization** *value*}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
clients	Sets the access point client threshold.
<i>value</i>	Access point client threshold from 1 to 75 clients. Note The default client threshold is 12.
customize	Turns on performance profile customization for an access point. Note Performance profile customization is off by default.
exception <i>value</i>	Sets the 802.11a Cisco access point coverage exception level from 0 to 100 percent.
foreign	Sets the foreign 802.11 transmitter interference threshold.
<i>value</i>	Foreign 802.11 transmitter interference threshold from 0 to 100 percent. Note The default is 10 percent.
level <i>value</i>	Sets the 802.11a Cisco access point client minimum exception level from 1 to 75 clients.
noise	Sets the 802.11 foreign noise threshold.
<i>value</i>	802.11 foreign noise threshold from -127 to 0 dBm. Note The default is -70 dBm.
throughput	Sets the data-rate throughput threshold.
<i>value</i>	802.11 throughput threshold from 1000 to 10000000 bytes per second. Note The default is 1,000,000 bytes per second.
utilization	Sets the RF utilization threshold. Note The operating system generates a trap when this threshold is exceeded.

<i>value</i>	802.11 RF utilization threshold from 0 to 100 percent.
	Note The default is 80 percent.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to set the AP1 clients threshold to 75 clients:

```
Controller# ap name AP1 dot11 49ghz rrm profile clients 75
```

This example shows how to turn performance on profile customization for Cisco lightweight access point AP1 on the 4.9 GHz channel:

```
Controller# ap name AP1 dot11 49ghz rrm profile customize
```

This example shows how to set the foreign transmitter interference threshold for AP1 to 0 percent:

```
Controller# ap name AP1 dot11 49ghz rrm profile foreign 0
```

This example shows how to set the foreign noise threshold for AP1 to 0 dBm:

```
Controller# ap name AP1 dot11 49ghz rrm profile noise 0
```

This example shows how to set the AP1 data-rate threshold to 10000000 bytes per second:

```
Controller# ap name AP1 dot11 49ghz rrm profile throughput 10000000
```

This example shows how to set the RF utilization threshold for AP1 to 100 percent:

```
Controller# ap name AP1 dot11 49ghz rrm profile utilization 100
```

ap name dot11 5ghz rrm channel

To configure a new channel using an 802.11h channel announcement, use the **ap name dot11 5ghz rrm channel** command.

ap name *ap-name* **dot11 5ghz rrm channel** *channel*

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.
<i>channel</i>	New channel.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure a new channel using the 802.11h channel:

```
Controller# ap name AP01 dot11 5ghz rrm channel 140
```

ap name dot11 antenna

To configure radio antenna settings for Cisco lightweight access points on different 802.11 networks, use the **ap name dot11 antenna** command.

```
ap name ap-name dot11 {24ghz|5ghz} antenna {ext-ant-gain gain| mode {omni|sectorA|sectorB}|
selection {external|internal}}
```

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
ext-ant-gain	Specifies the external antenna gain for an 802.11 network. Note Before you enter this command, disable the Cisco radio by using the ap dot11 {24ghz 5ghz} shutdown command. After you enter this command, reenable the Cisco radio by using the no ap dot11 {24ghz 5ghz} shutdown command.
<i>gain</i>	Antenna gain in 0.5 dBm units (for example, 2.5 dBm = 5).
mode	Specifies that the Cisco lightweight access point is to use one internal antenna for an 802.11 sectorized 180-degree coverage pattern or both internal antennas for an 802.11 360-degree omnidirectional pattern.
omni	Specifies to use both internal antennas.
sectorA	Specifies to use only the side A internal antenna.
sectorB	Specifies to use only the side B internal antenna.
selection	Selects the internal or external antenna selection for a Cisco lightweight access point on an 802.11 network.
external	Specifies the external antenna.
internal	Specifies the internal antenna.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure a 5 GHz external antenna gain of 0.5 dBm for AP1:

```
Controller# ap name AP1 dot11 5ghz antenna ext-ant-gain 0.5
```

This example shows how to configure access point AP01 antennas for a 360-degree omnidirectional pattern on a 2.4 GHz band:

```
Controller# ap name AP01 dot11 24ghz antenna mode omni
```

This example shows how to configure access point AP02 on a 2.4 GHz band to use the internal antenna:

```
Controller# ap name AP02 dot11 24ghz antenna selection interval
```

ap name dot11 antenna extantgain

To configure radio antenna settings for Cisco lightweight access points on 4.9 GHz and 5.8 GHz public safety channels, use the **ap name dot11 antenna extantgain** command.

ap name *ap-name* **dot11** {49ghz| 58ghz} {antenna extantgain *gain*}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
49ghz	Specifies 4.9 GHz public safety channel settings.
58ghz	Specifies 5.8 GHz public safety channel settings.
<i>gain</i>	Antenna gain in 0.5 dBm units (for example, 2.5 dBm = 5).

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Before you enter this command, disable the Cisco radio by using the **ap dot11 {24ghz | 5ghz} shutdown** command. After you enter this command, reenables the Cisco radio by using the **no ap dot11 {24ghz | 5ghz} shutdown** command.

Examples

This example shows how to configure an external antenna gain of 0.5 dBm for AP1 on a 4.9 GHz public safety channel:

```
Controller# ap name AP1 dot11 49ghz antenna extantgain 0.5
```

ap name dot11 cleanair

To configure CleanAir settings for a specific Cisco lightweight access point on 802.11 networks, use the **ap name dot11 cleanair** command.

ap name *ap-name* **dot11** {**24ghz**|**5ghz**} **cleanair**

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.

Command Default

Disabled.

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable CleanAir on the 2.4 GHz band:

```
Controller# ap name AP01 dot11 24ghz cleanair
```

ap name dot11 dot11n antenna

To configure an access point to use a specific antenna, use the **ap name dot11 dot11n antenna** command.

ap name *ap-name* **dot11** {24ghz| 5ghz} **dot11n antenna** {A| B| C| D}

Syntax Description

<i>ap-name</i>	Access point name.
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
A	Specifies antenna port A.
B	Specifies antenna port B.
C	Specifies antenna port C.
D	Specifies antenna port D.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable antenna B on access point AP02:

```
Controller# ap name AP02 dot11 5ghz dot11n antenna B
```

This example shows how to disable antenna C on access point AP02:

```
Controller# ap name AP02 no dot11 5ghz dot11n C
```

ap name dot11 dual-band cleanair

To configure CleanAir for a dual band radio, use the **ap name dot11 dual-band cleanair** command.

ap name *ap-name* **dot11 dual-band cleanair**

ap name *ap-name* **no dot11 dual-band cleanair**

Syntax Description

<i>ap-name</i>	Name of the Cisco AP.
cleanair	Specifies the CleanAir feature.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

This example shows how to enable CleanAir for a dual band radio of the access point AP01:

```
Controller# ap name AP01 dot11 dual-band cleanair
```

ap name dot11 dual-band shutdown

To disable dual band radio on a Cisco AP, use the **ap name dot11 dual-band shutdown** command.

ap name *ap-name* **dot11 dual-band shutdown**

ap name *ap-name* **no dot11 dual-band shutdown**

Syntax Description

<i>ap-name</i>	Name of the Cisco AP.
shutdown	Disables the dual band radio on the Cisco AP.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

This example shows how to disable dual band radio on the Cisco access point AP01:

```
Controller# ap name AP01 dot11 dual-band shutdown
```

ap name dot11 rrm ccx

To configure Cisco Client eXtension (CCX) Radio Resource Management (RRM) settings for specific Cisco lightweight access points on 802.11 networks, use the **ap name dot11 rrm ccx** command.

ap name *ap-name* **dot11** {**24ghz**|**5ghz**} **rrm ccx** {**customize**|**location-measurement** *interval*}

Syntax Description		
	<i>ap-name</i>	Name of the Cisco lightweight access point.
	24ghz	Specifies the 2.4 GHz band.
	5ghz	Specifies the 5 GHz band.
	customize	Enables 802.11 CCX options.
	location-measurement	Configures the CCX client location measurements.
	<i>interval</i>	Interval from 10 to 32400.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how to configure CCX client location measurements for an access point in the 2.4 GHz band:

```
Controller# ap name AP01 dot11 24ghz rrm ccx location-measurement 3200
```

ap name dot11 rrm profile

To configure Radio Resource Management (RRM) performance profile settings for a Cisco lightweight access point, use the **ap name dot11 rrm profile** command.

```
ap name ap-name dot11 {24ghz| 5ghz} rrm profile {clients value| customize| foreign value| noise value| throughput value| utilization value}
```

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
clients	Sets the access point client threshold.
<i>value</i>	Access point client threshold from 1 to 75 clients. Note The default client threshold is 12.
customize	Turns on performance profile customization for an access point. Note Performance profile customization is off by default.
foreign	Sets the foreign 802.11 transmitter interference threshold.
<i>value</i>	Foreign 802.11 transmitter interference threshold from 0 to 100 percent. Note The default is 10 percent.
noise	Sets the 802.11 foreign noise threshold.
<i>value</i>	802.11 foreign noise threshold between -127 and 0 dBm. Note The default is -70 dBm.
throughput	Sets the data-rate throughput threshold.
<i>value</i>	802.11 throughput threshold from 1000 to 10000000 bytes per second. Note The default is 1,000,000 bytes per second.
utilization	Sets the RF utilization threshold. Note The operating system generates a trap when this threshold is exceeded.
<i>value</i>	802.11 RF utilization threshold from 0 to 100 percent. Note The default is 80 percent.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to set the AP1 clients threshold to 75 clients:

```
Controller# ap name AP1 dot11 24ghz rrm profile clients 75
```

This example shows how to turn performance profile customization on for 802.11a Cisco lightweight access point AP1:

```
Controller# ap name AP1 dot11 5ghz rrm profile customize
```

This example shows how to set the foreign 802.11a transmitter interference threshold for AP1 to 0 percent:

```
Controller# ap name AP1 dot11 5ghz rrm profile foreign 0
```

This example shows how to set the 802.11a foreign noise threshold for AP1 to 0 dBm:

```
Controller# ap name AP1 dot11 5ghz rrm profile noise 0
```

This example shows how to set the AP1 data-rate threshold to 10000000 bytes per second:

```
Controller# ap name AP1 dot11 5ghz rrm profile throughput 10000000
```

This example shows how to set the RF utilization threshold for AP1 to 100 percent:

```
Controller# ap name AP1 dot11 5ghz rrm profile utilization 100
```

ap name dot11 txpower

To configure the transmit power level for a single access point in an 802.11 network, use the **ap name dot11 txpower** command.

```
ap name ap-name dot11 {24ghz|5ghz} {shutdown|txpower {auto|power-level}}
```

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
shutdown	Disables the 802.11 networks.
auto	Specifies the power level is automatically set by Radio Resource Management (RRM) for the 802.11 Cisco radio.
<i>power-level</i>	Manual transmit power level number for the access point.

Command Default

The command default (txpower auto) is for automatic configuration by RRM.

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to automatically set the 2.4 GHz radio transmit power for access point AP1:

```
Controller# ap name AP1 dot11 24ghz txpower auto
```

ap name dot1x-user

To configure the global authentication username and password for an access point that is currently joined to the controller, use the **ap name dot1x-user** command. To disable 802.1X authentication for a specific access point, use the **no** form of this command.

```
ap name ap-name dot1x-user {global-override| username user-id password passwd}
```

```
ap name ap-name [no] dot1x-user
```

Syntax Description

<i>ap-name</i>	Name of the access point.
global-override	Forces the access point to use the controller's global authentication settings.
username	Specifies to add a username.
<i>user-id</i>	Username.
password	Specifies to add a password.
<i>passwd</i>	Password.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You should enter a strong password. Strong passwords have the following characteristics:

- They are at least eight characters long.
- They contain a combination of uppercase and lowercase letters, numbers, and symbols.
- They are not words in any language.

You can set the values for a specific access point.

You can disable 802.1X authentication for a specific access point only if global 802.1X authentication is not enabled. If global 802.1X authentication is enabled, you can disable 802.1X for all access points only.

Examples

This example shows how to configure a specific username and password for dot1x authentication:

```
Controller# ap name AP02 dot1x-user username Cisco123 password Cisco2020
```

This example shows how to disable the authentication for access point cisco_ap1:

```
Controller# ap name cisco_ap1 no dot1x-user
```

ap name ethernet

To configure ethernet port settings of a Cisco lightweight access point, use the **ap name ethernet** command. To remove configured port settings or set of defaults, use the **no** form of this command.

ap name *ap-name* **ethernet** *intf-number* **mode** {**access** *vlan-id* | **trunk** [**add** | **delete**]} **native-vlan** *vlan-id*
ap name *ap-name* **no ethernet** *intf-number* **mode** {**access** | **trunk native-vlan**}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
<i>intf-number</i>	Ethernet interface number from 0 to 3.
mode	Configures access or trunk mode.
access	Configures the port in access mode.
<i>vlan-id</i>	VLAN identifier.
trunk	Specifies the port in trunk mode.
add	(Optional) Adds a VLAN or trunk mode.
delete	(Optional) Deletes a VLAN or trunk mode.
native-vlan	Specifies a native VLAN.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure access mode for a Cisco access point.

```
Controller# ap name AP2 ethernet 0 mode access 1
```

ap name ethernet duplex

To configure the Ethernet port duplex and speed settings of the lightweight access points, use the **ap name ethernet duplex** command.

ap name *ap-name* **ethernet duplex** {**auto**|**full**|**half**} **speed** {**10**|**100**|**1000**|**auto**}

Syntax Description

<i>ap-name</i>	Name of the Cisco access point.
auto	Specifies the Ethernet port duplex auto settings.
full	Specifies the Ethernet port duplex full settings.
half	Specifies the Ethernet port duplex half settings.
speed	Specifies the Ethernet port speed settings.
10	Specifies the Ethernet port speed to 10 Mbps.
100	Specifies the Ethernet port speed to 100 Mbps.
1000	Specifies the Ethernet port speed to 1000 Mbps.
auto	Specifies the Ethernet port setting for all connected access points.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the Ethernet port to full duplex and 1 Gbps for an access point:

```
Controller# ap name AP2 ethernet duplex full 1000
```

ap name image

To configure an image on a specific access point, use the **ap name image** command.

ap name *ap-name* **image** {**predownload**|**swap**}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
predownload	Instructs the access point to start the image predownload.
swap	Instructs the access point to swap the image.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to predownload an image to an access point:

```
Controller# ap name AP2 image predownload
```

This example shows how to swap an access point's primary and secondary images:

```
Controller# ap name AP2 image swap
```

ap name ipv6 tcp adjust-mss

To configure IPv6 TCP maximum segment size (MSS) value for a Cisco AP, use the **ap name ipv6 tcp adjust-mss** command.

ap name *ap-name* **ipv6 tcp adjust-mss** *size*

ap name *ap-name* **no ipv6 tcp adjust-mss**

Syntax Description

<i>ap-name</i>	Name of the Cisco AP.
adjust-mss	Configures IPv6 TCP MSS settings for all Cisco APs.
<i>size</i>	MSS value in the range of 500 to 1440.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

The MSS value must be in the range of 500 to 1440.

Examples

This example shows how to configure the IPv6 TCP MSS value to 600 for a Cisco access point AP01:

```
Controller# ap name AP01 ipv6 tcp adjust-mss 600
```

ap name led

To enable the LED state for an access point, use the **ap name led** command. To disable the LED state for an access point, use the **no** form of this command.

ap name *ap-name* **led**
no ap name *ap-name* [**led**] **led**

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.
led	Enables the access point's LED state.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable the LED state for an access point:

```
Controller# ap name AP2 led
```

This example shows how to disable the LED state for an access point:

```
Controller# ap name AP2 no led
```

ap name location

To modify the descriptive location of a Cisco lightweight access point, use the **ap name location** command.

ap name *ap-name* **location** *location*

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
<i>location</i>	Location name of the access point (enclosed by double quotation marks).

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The Cisco lightweight access point must be disabled before changing this parameter.

Examples

This example shows how to configure the descriptive location for access point AP1:

```
Controller# ap name AP1 location Building1
```

ap name mgmtuser

To configure the username, password, and secret password for access point management, use the **ap name mgmtuser** command. To force a specific access point to use the controller's global credentials, use the **no** form of this command.

ap name *ap-name* **mgmtuser** **username** *username* **password** *password* **secret** *secret*

ap name *ap-name* **no mgmtuser**

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
username	Specifies the username for access point management.
<i>username</i>	Management username.
password	Specifies the password for access point management.
<i>password</i>	Access point management password.
secret	Specifies the secret password for privileged access point management.
<i>secret</i>	Access point management secret password.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

To specify a strong password, you should adhere to the following requirements:

- The password should contain characters from at least three of the following classes: lowercase letters, uppercase letters, digits, and special characters.
- No character in the password can be repeated more than three times consecutively.
- The password cannot contain a management username or the reverse of a username.
- The password cannot contain words such as Cisco, oscic, admin, nimda or any variant obtained by changing the capitalization of letters by substituting 1, |, or ! or substituting 0 for o or substituting \$ for s.

The following requirement is enforced on the secret password:

- The secret password cannot contain characters from at least three of the following classes: lowercase letters, uppercase letters, digits, or special characters.

Examples

This example shows how to add a username, password, and secret password for access point management:

```
Controller# ap name AP01 mgmtuser username acd password Arc_1234 secret Mid_1234
```

ap name mode

To change a Cisco controller communication option for an individual Cisco lightweight access point, use the **ap name mode** command.

ap name *ap-name* **mode** {**local** **submode** {**none**| **wips**}| **monitor** **submode** {**none**| **wips**}| **rogue**| **se-connect**| **sniffer**}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
local	Converts from an indoor mesh access point (MAP or RAP) to a nonmesh lightweight access point (local mode).
submode	Specifies WIPS submode on an access point.
none	Disables the WIPS on an access point.
monitor	Specifies monitor mode settings.
wips	Enables the WIPS submode on an access point.
rogue	Enables wired rogue detector mode on an access point.
se-connect	Enables spectrum expert mode on an access point.
sniffer	Enables wireless sniffer mode on an access point.

Command Default

Local

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The sniffer mode captures and forwards all the packets from the clients on that channel to a remote machine that runs AiroPeek or other supported packet analyzer software. It includes information on the timestamp, signal strength, packet size and so on.

Examples

This example shows how to set the controller to communicate with access point AP01 in local mode:

```
Controller# ap name AP01 mode local submode none
```

This example shows how to set the controller to communicate with access point AP01 in a wired rogue access point detector mode:

```
Controller# ap name AP01 mode rogue
```

This example shows how to set the controller to communicate with access point AP02 in wireless sniffer mode:

```
Controller# ap name AP02 mode sniffer
```

ap name monitor-mode

To configure Cisco lightweight access point channel optimization, use the **ap name monitor-mode** command.

ap name *ap-name* **monitor-mode** {**no-optimization**| **tracking-opt**| **wips-optimized**}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
no-optimization	Specifies no channel scanning optimization for the access point.
tracking-opt	Enables tracking optimized channel scanning for the access point.
wips-optimized	Enables wIPS optimized channel scanning for the access point.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure a Cisco wireless intrusion prevention system (wIPS) monitor mode on access point AP01:

```
Controller# ap name AP01 monitor-mode wips
```

ap name monitor-mode dot11b

To configure 802.11b scanning channels for a monitor-mode access point, use the **ap name monitor-mode dot11b** command.

ap name *ap-name* **monitor-mode dot11b fast-channel** *channel1* [*channel2*] [*channel3*] [*channel4*]

Syntax Description

<i>ap-name</i>	Name of the access point.
fast-channel	Specifies the 2.4 GHz band scanning channel (or channels) for a monitor-mode access point.
<i>channel1</i>	Scanning channel1.
<i>channel2</i>	(Optional) Scanning channel2.
<i>channel3</i>	(Optional) Scanning channel3.
<i>channel4</i>	(Optional) Scanning channel4.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure an access point in tracking optimized mode to listen to channels 1, 6, and 11:

```
Controller# ap name AP01 monitor-mode dot11b fast-channel 1 6 11
```

ap name name

To modify the name of a Cisco lightweight access point, use the **ap name name** command.

ap name *ap-name* **name** *new-name*

Syntax Description

<i>ap-name</i>	Current Cisco lightweight access point name.
<i>new-name</i>	Desired Cisco lightweight access point name.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to modify the name of access point AP1 to AP2:

```
Controller# ap name AP1 name AP2
```

ap name bridging

To enable Ethernet-to-Ethernet bridging on a Cisco lightweight access point, use the **ap name bridging** command. To disable Ethernet-to-Ethernet bridging on a Cisco lightweight access point, use the **no** form of this command.

ap name *ap-name* **bridging**

ap name *ap-name* **no bridging**

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable Ethernet-to-Ethernet bridging on an access point:

```
Controller# ap name TSIM_AP2 bridging
```

ap name cdp interface

To enable the Cisco Discovery Protocol (CDP) on a Cisco lightweight access point, use the **ap name** command. To disable the Cisco Discovery Protocol (CDP) on a Cisco lightweight access point, use the **no** form of this command.

ap name *ap-name* **cdp interface** {**ethernet** *ethernet-id*| **radio** *radio-id*}

ap name *ap-name* [**no**] **cdp interface** {**ethernet** *ethernet-id*| **radio** *radio-id*}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
ethernet	Enables CDP on an Ethernet interface.
<i>ethernet-id</i>	Ethernet interface number from 0 to 3.
radio	Enables CDP for a radio interface.
<i>radio-id</i>	Radio ID slot number from 0 to 3.

Command Default

Disabled on all access points.

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

CDP over Ethernet/radio interfaces is available only when CDP is enabled. After you enable CDP on all access points that are joined to the controller, you can disable and then reenables CDP on individual access points by using the **ap name** *ap-name* **cdp interface ethernet** *ethernet-id* **cisco_ap** command. After you disable CDP on all access points that are joined to the controller, you cannot enable and then disable CDP on individual access points.

Examples

This example shows how to enable CDP for Ethernet interface number 0 on an access point:

```
Controller# ap name TSIM_AP2 cdp interface ethernet 0
```

ap name console-redirect

To redirect the remote debug output of a Cisco lightweight access point to the console, use the **ap name console-redirect** command. To disable the redirection of the remote debug output of a Cisco lightweight access point to the console, use the **no** form of this command.

ap name *ap-name* **console-redirect**

ap name *ap-name* [**no**] **console-redirect**

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable redirecting remote debug output of a Cisco access point named AP02 to the console:

```
Controller# ap name AP02 console-redirect
```

ap name no dot11 shutdown

To enable radio transmission for an individual Cisco radio on an 802.11 network, use the **ap name no dot11 shutdown** command.

ap name *ap-name* **no dot11** {24ghz| 5ghz} **shutdown**

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Specifies the 2.4 GHz radios.
5ghz	Specifies the 5 GHz radios.

Command Default

The transmission is enabled for the entire network by default.

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines



Note

Use this command with the **ap name Cisco-AP dot11 5ghz shutdown** command when configuring 802.11 settings.

This command can be used any time that the CLI interface is active.

Examples

This example shows how to enable radio transmission on the 5 GHz band for access point AP1:

```
Controller# ap name AP1 no dot11 5ghz shutdown
```

ap name link-encryption

To enable Datagram Transport Layer Security (DTLS) data encryption for specific Cisco lightweight access points, use the **ap name link-encryption** command. To disable DTLS data encryption for specific Cisco lightweight access points, use the **no** form of this command.

ap name *ap-name* **link-encryption**

ap name *ap-name* **no link-encryption**

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable data encryption for an access point:

```
Controller# ap name AP02 link-encryption
```

ap name link-latency

To enable link latency for a specific Cisco lightweight access point that is currently associated to the controller, use the **ap name link-latency** command. To disable link latency for a specific Cisco lightweight access point that is currently associated to the controller, use the **no** form of this command.

ap name *ap-name* **link-latency**

ap name *ap-name* **no link-latency**

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

Link latency is disabled by default.

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

This command enables or disables link latency only for access points that are currently joined to the controller. It does not apply to access points that join in the future.

Examples

This example shows how to enable link latency on access points:

```
Controller# ap name AP2 link-latency
```

ap name power

To enable the Cisco Power over Ethernet (PoE) feature for access points, use the **ap name power** command. To disable the Cisco PoE feature for access points, use the **no** form of this command.

ap name *ap-name* **power** {injector| pre-standard}

ap name *ap-name* **no power** {injector| pre-standard}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
injector	Specifies the power injector state for an access point.
pre-standard	Enables the inline power Cisco prestandard switch state for an access point.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable the power injector state for all access points:

```
Controller# ap name AP01 power injector
```

This example shows how to enable the inline power Cisco prestandard switch state for access point AP02:

```
Controller# ap name AP02 power pre-standard
```

ap name shutdown

To disable a Cisco lightweight access point, use the **ap name shutdown** command. To enable a Cisco lightweight access point, use the **no** form of this command.

ap name *ap-name* shutdown

ap name *ap-name* no shutdown

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to disable a specific Cisco lightweight access point:

```
Controller# ap name AP2 shutdown
```

ap name slot shutdown

To disable a slot on a Cisco lightweight access point, use the **ap name slot shutdown** command. To enable a slot on a Cisco lightweight access point, use the **no** form of the command.

ap name *ap-name* slot {0| 1| 2| 3} shutdown

ap name *ap-name* no slot {0| 1| 2| 3} shutdown

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
0	Enables slot number 0 on a Cisco lightweight access point.
1	Enables slot number 1 on a Cisco lightweight access point.
2	Enables slot number 2 on a Cisco lightweight access point.
3	Enables slot number 3 on a Cisco lightweight access point.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable slot 0 on a Cisco access point named TSIM_AP2:

```
Controller# ap name TSIM_AP2 no slot 0 shutdown
```

ap name sniff

To enable sniffing on an access point, use the **ap name sniff** command. To disable sniffing on an access point, use the **no** form of this command.

ap name *ap-name* **sniff** {**dot11a**|**dot11b**}

ap name *ap-name* **no sniff** {**dot11a**|**dot11b**}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
dot11a	Specifies the 2.4 GHz band.
dot11b	Specifies the 5 GHz band.
<i>channel</i>	Valid channel to be sniffed. For the 5 GHz band, the range is 36 to 165. For the 2.4 GHz band, the range is 1 to 14.
<i>server-ip-address</i>	IP address of the remote machine running Omnippeek, Airopeek, AirMagnet, or Wireshark software.

Command Default

Channel 36

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

When the sniffer feature is enabled on an access point, it starts sniffing the signal on the given channel. It captures and forwards all the packets to the remote computer that runs Omnippeek, Airopeek, AirMagnet, or Wireshark software. It includes information about the timestamp, signal strength, packet size and so on.

Before an access point can act as a sniffer, a remote computer that runs one of the listed packet analyzers must be set up so that it can receive packets that are sent by the access point.

Examples

This example shows how to enable the sniffing on the 5 GHz band for an access point on the primary wireless LAN controller:

```
Controller# ap name AP2 sniff dot11a 36 192.0.2.54
```

ap name ssh

To enable Secure Shell (SSH) connectivity on a specific Cisco lightweight access point, use the **ap name ssh** command. To disable SSH connectivity on a specific Cisco lightweight access point, use the **no** form of this command.

ap name *ap-name* **ssh**

ap name *ap-name* **no ssh**

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The Cisco lightweight access point associates with this Cisco controller for all network operations and in the event of a hardware reset.

Examples

This example shows how to enable SSH connectivity on access point Cisco_ap2:

```
Controller# ap name Cisco_ap2 ssh
```

ap name telnet

To enable Telnet connectivity on an access point, use the **ap name telnet** command. To disable Telnet connectivity on an access point, use the **no** form of this command.

ap name *ap-name* **telnet**

ap name *ap-name* **no telnet**

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to disable Telnet connectivity on access point cisco_ap1:

```
Controller# ap name cisco_ap1 no telnet
```

ap name power injector

To configure the power injector state for an access point, use the **ap name power injector** command. To disable the Cisco Power over Ethernet (PoE) feature for access points, use the **no** form of this command.

ap name *ap-name* power injector {installed| override| switch-mac-address *switch-MAC-address*}

ap name *ap-name* no power injector

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
installed	Detects the MAC address of the current switch port that has a power injector.
override	Overrides the safety checks and assumes a power injector is always installed.
switch-mac-address	Specifies the MAC address of the switch port with an installed power injector.
<i>switch-MAC-address</i>	MAC address of the switch port with an installed power injector.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable the power injector state for an access point:

```
Controller# ap name AP01 power injector switch-mac-address aaaa.bbbb.cccc
```

ap name power pre-standard

To enable the inline power Cisco prestandard switch state for an access point, use the **ap name power pre-standard** command. To disable the inline power Cisco prestandard switch state for an access point, use the **no** form of this command.

ap name *ap-name* **power pre-standard**

ap name *ap-name* **no power pre-standard**

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable the inline power Cisco prestandard switch state for access point AP02:

```
Controller# ap name AP02 power pre-standard
```

This example shows how to disable the inline power Cisco prestandard switch state for access point AP02:

```
Controller# ap name AP02 no power pre-standard
```

ap name reset-button

To configure the Reset button for an access point, use the **ap name reset-button** command.

ap name *ap-name* **reset-button**

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable the Reset button for access point AP03:

```
Controller# ap name AP03 reset-button
```

ap name reset

To reset a specific Cisco lightweight access point, use the **ap name reset** command.

ap name *ap-name* **reset**

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to reset a Cisco lightweight access point named AP2:

```
Controller# ap name AP2 reset
```

ap name slot

To configure various slot parameters, use the **ap name slot** command. To disable a slot on a Cisco lightweight access point, use the **no** form of this command.

ap name *ap-name* **slot** *slot-number* {**channel** {**global**| **number** *channel-number*| **width** *channel-width*}| **rtsthreshold** *value*| **shutdown**| **txpower** {**global**| *channel-level*}}

ap name *ap-name* **no slot** {**0**| **1**| **2**| **3**} **shutdown**

Syntax Description

<i>ap-name</i>	Name of the Cisco access point.
<i>slot-number</i>	Slot downlink radio to which the channel is assigned. You can specify the following slot numbers: <ul style="list-style-type: none"> • 0—Enables slot number 0 on a Cisco lightweight access point. • 1—Enables slot number 1 on a Cisco lightweight access point. • 2—Enables slot number 2 on a Cisco lightweight access point. • 3—Enables slot number 3 on a Cisco lightweight access point.
channel	Specifies the channel for the slot.
global	Specifies channel global properties for the slot.
number	Specifies the channel number for the slot.
<i>channel-number</i>	Channel number from 1 to 169.
width	Specifies the channel width for the slot.
<i>channel-width</i>	Channel width from 20 to 40.
rtsthreshold	Specifies the RTS/CTS threshold for an access point.
<i>value</i>	RTS/CTS threshold value from 0 to 65535.
shutdown	Shuts down the slot.
txpower	Specifies Tx power for the slot.
global	Specifies auto-RF for the slot.
<i>channel-level</i>	Transmit power level for the slot from 1 to 7.

Command Default

None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how to enable slot 3 for the access point abc:

```
Controller# ap name abc slot 3
```

This example shows how to configure RTS for the access point abc:

```
Controller# ap name abc slot 3 rtsthreshold 54
```

ap name static-ip

To configure lightweight access point static IP settings, use the **ap name static-ip** command. To disable the Cisco lightweight access point static IP address, use the **no** form of this command.

ap name *ap-name* **static-ip** {**domain** *domain-name*| **ip-address** *ip-address* **netmask** *netmask* **gateway** *gateway*| **nameserver** *ip-address*}

ap name *ap-name* **no static-ip**

Syntax Description

<i>ap-name</i>	Name of the access point.
domain	Specifies the Cisco access point domain name.
<i>domain-name</i>	Domain to which a specific access point belongs.
ip-address	Specifies the Cisco access point static IP address.
<i>ip-address</i>	Cisco access point static IP address.
netmask	Specifies the Cisco access point static IP netmask.
<i>netmask</i>	Cisco access point static IP netmask.
gateway	Specifies the Cisco access point gateway.
<i>gateway</i>	IP address of the Cisco access point gateway.
nameserver	Specifies a DNS server so that a specific access point can discover the controller using DNS resolution.
<i>ip-address</i>	IP address of the DNS server.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

An access point cannot discover the controller using Domain Name System (DNS) resolution if a static IP address is configured for the access point unless you specify a DNS server and the domain to which the access point belongs.

Examples

This example shows how to configure an access point static IP address:

```
Controller# ap name AP2 static-ip ip-address 192.0.2.54 netmask 255.255.255.0 gateway  
192.0.2.1
```

ap name stats-timer

To set the time in seconds that the Cisco lightweight access point sends its DOT11 statistics to the Cisco controller, use the **ap name stats-timer** command.

ap name *ap-name* **stats-timer** *timer-value*

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
<i>timer-value</i>	Time in seconds from 0 to 65535. A zero value disables the timer.

Command Default

0 (Disabled).

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A value of 0 (zero) means that the Cisco lightweight access point does not send any DOT11 statistics. The acceptable range for the timer is from 0 to 65535 seconds, and the Cisco lightweight access point must be disabled to set this value.

Examples

This example shows how to set the stats timer to 600 seconds for access point AP2:

```
Controller# ap name AP2 stats-timer 600
```

ap name syslog host

To configure a syslog server for a specific Cisco lightweight access point, use the **ap name syslog host** command.

ap name *ap-name* **syslog host** *syslog-host-ip-address*

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
<i>syslog-host-ip-address</i>	IP address of the syslog server.

Command Default

255.255.255.255

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

By default, the syslog server IP address for each access point is 255.255.255.255, which indicates that it is not yet set. When the default value is used, the global access point syslog server IP address is pushed to the access point.

Examples

This example shows how to configure a syslog server:

```
Controller# ap name AP2 syslog host 192.0.2.54
```

ap name syslog level

To configure the system logging level, use the **ap name syslog level** command.

ap name *ap-name* **syslog level** {**alert**| **critical**| **debug**| **emergency**| **errors**| **information**| **notification**| **warning**}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
alert	Specifies alert level system logging.
critical	Specifies critical level system logging.
debug	Specifies debug level system logging.
emergency	Specifies emergency level system logging.
errors	Specifies error level system logging.
information	Specifies information level system logging.
notification	Specifies notification level system logging.
warning	Specifies warning level system logging.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure alert level system logging:

```
Controller# ap name AP2 syslog level alert
```

ap name tcp-adjust-mss

To enable or disable the TCP maximum segment size (MSS) on a particular access point, use the **ap name tcp-adjust-mss** command. To disable the TCP maximum segment size (MSS) on a particular access point, use the **no** form of this command.

ap name *ap-name* **tcp-adjust-mss size** *size*

ap name *ap-name* **no tcp-adjust-mss**

Syntax Description

<i>ap-name</i>	Name of the access point.
<i>size</i>	Maximum segment size, from 536 to 1363 bytes.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

When you enable this feature, the access point checks for TCP packets to and from wireless clients in its data path. If the MSS of these packets is greater than the value that you configured or greater than the default value for the Control and Provisioning of Wireless Access Points (CAPWAP) tunnel, the access point changes the MSS to the new configured value. If the MSS of these packets is greater than the value that you have configured or greater than the default value for the CAPWAP tunnel, the access point changes the MSS to the newly configured value.

Examples

This example shows how to enable the TCP MSS on access point Cisco_ap1:

```
Controller# ap name ciscoap tcp-adjust-mss size 1200
```

ap name tftp-downgrade

To configure the settings used for downgrading a lightweight access point to an autonomous access point, use the **ap name tftp-downgrade** command.

ap name *ap-name* **tftp-downgrade** *tftp-server-ip filename*

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
<i>tftp-server-ip</i>	IP address of the TFTP server.
<i>filename</i>	Filename of the access point image file on the TFTP server.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the settings for downgrading access point AP1:

```
Controller# ap name Ap01 tftp-downgrade 172.21.12.45 ap3g1-k9w7-tar.124-25d.JA.tar
```

ap power injector

To configure the power injector state for all the Cisco lightweight access points that are joined to the controller, use the **ap power injector** command. To delete the power injector state for all access points, use the **no** form of this command.

ap power injector {**installed**| **override**| **switch-mac-address** *switch-MAC-addr*}

no ap power injector

Syntax Description

installed	Detects the MAC address of the current switch port that has a power injector.
override	Overrides the safety checks and assumes a power injector is always installed.
switch-mac-address	Specifies the MAC address of the switch port with an installed power injector.
<i>switch-MAC-address</i>	Specifies the MAC address of the switch port with an installed power injector.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable the power injector state for all the Cisco lightweight access points that are joined to the controller:

```
Controller(config)# ap power injector switch-mac-address aaaa.bbbb.cccc
```

ap power pre-standard

To set the Cisco lightweight access points that are joined to the controller to be powered by a high-power Cisco switch, use the **ap power pre-standard** command. To disable the pre standard power for all access points, use the **no** form of this command.

ap power pre-standard

no ap power pre-standard

Syntax Description

This command has no keywords and arguments.

Command Default

Disabled

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable the inline power Cisco prestandard switch state for access point AP02:

```
Controller(config)# ap power pre-standard
```

ap reporting-period

To configure the access point rogue/error reporting period, use the **ap reporting-period** command. To disable the access point rogue/error reporting period, use the **no** form of this command.

ap reporting-period *value*

no ap reporting-period

Syntax Description

<i>value</i>	Time period in seconds from 10 to 120.
--------------	--

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example show how to configure the access point rogue/error reporting:

```
Controller(config)# ap reporting-period 100
```

This example show how to disable the access point rogue/error reporting:

```
Controller(config)# no ap reporting-period 100
```

ap reset-button

To configure the Reset button for all Cisco lightweight access points that are joined to the controller, use the **ap reset-button** command. To disable the Reset button for all access points, use the **no** form of this command.

ap reset-button

no ap reset-button

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the Reset button for all access points that are joined to the controller:

```
Controller(config)# ap reset-button
```

ap static-ip

To configure Cisco lightweight access point static IP address settings, use the **ap static-ip** command. To disable access point static IP settings, use the **no** form of this command.

ap static-ip {**domain** *domain-name*| **name-server** *ip-address*}

no ap static-ip {**domain**| **name-server**}

Syntax Description		
domain		Specifies the domain to which a specific access point or all access points belong.
<i>domain-name</i>		Domain name.
name-server		Specifies a DNS server so that a specific access point or all access points can discover the controller using DNS resolution.
<i>ip-address</i>		DNS server IP address.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines An access point cannot discover the controller using Domain Name System (DNS) resolution if a static IP address is configured for the access point, unless you specify a DNS server and the domain to which the access point belongs.

Examples This example shows how to configure a static IP address for all access points:

```
Controller(config)# ap static-ip domain cisco.com
```

ap syslog

To configure the system logging settings for all Cisco lightweight access points that are joined to the controller, use the **ap syslog** command.

```
ap syslog {host ipaddress| level{alert| critical| debug| emergency| errors| information| notification| warning}}
```

Syntax Description

host	Specifies a global syslog server for all access points that join the controller.
<i>ipaddress</i>	IP address of the syslog server.
level	Specifies the system logging level for all the access points joined to the controller.
alert	Specifies alert level system logging for all Cisco access points.
critical	Specifies critical level system logging for all Cisco access points.
debug	Specifies debug level system logging for all Cisco access points.
emergency	Specifies emergency level system logging for all Cisco access points.
errors	Specifies errors level system logging for all Cisco access points.
information	Specifies information level system logging for all Cisco access points.
notification	Specifies notification level system logging for all Cisco access points.
warning	Specifies warning level system logging for all Cisco access points.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

By default, the global syslog server IP address for all access points is 255.255.255.255. Make sure that the access points can reach the subnet on which the syslog server resides before configuring the syslog server on

the controller. If the access points cannot reach this subnet, the access points are unable to send out syslog messages.

Examples

This example shows how to configure a global syslog server for all access points:

```
Controller(config)# ap syslog host 172.21.34.45
```

ap tcp-adjust-mss size

To enable the TCP maximum segment size (MSS) on all Cisco lightweight access points, use the **ap tcp-adjust-mss size** command. To disable the TCP maximum segment size (MSS) on all Cisco lightweight access points **no** form of this command.

ap tcp-adjust-mss size *size*

no ap tcp-adjust-mss

Syntax Description

<i>size</i>	Maximum segment size, from 536 to 1363 bytes.
-------------	---

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

When you enable this feature, the access point checks for TCP packets to and from wireless clients in its data path. If the MSS of these packets is greater than the value that you configured or greater than the default value for the Control and Provisioning of Wireless Access Points (CAPWAP) tunnel, the access point changes the MSS to the new configured value.

Examples

This example shows how to enable the TCP MSS on all access points with a segment size of 1200:

```
Controller(config)# ap tcp-adjust-mss 1200
```

ap tftp-downgrade

To configure the settings used for downgrading a lightweight access point to an autonomous access point, use the **ap tftp-downgrade** command. To disable the settings used for downgrading a lightweight access point to an autonomous access point, use the **no** form of this command.

ap tftp-downgrade *tftp-server-ip filename*

no ap tftp-downgrade

Syntax Description

<i>tftp-server-ip</i>	IP address of the TFTP server.
<i>filename</i>	Filename of the access point image file on the TFTP server.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure the settings for downgrading all access points:

```
Controller(config)# ap tftp-downgrade 172.21.23.45 ap3g1-k9w7-tar.124-25d.JA.tar
```

clear ap name tsm dot11 all

To clear the traffic stream metrics (TSM) statistics for a particular access point or all the access points, use the **clear ap name tsm dot11 all** command.

clear ap name *ap-name* **tsm dot11** {**24ghz**|**5ghz**} **all**

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
all	Specifies all access points.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to clear the TSM statistics for an access point on the 2.4 GHz band:

```
Controller# clear ap name AP1 tsm dot11 24ghz all
```

clear ap config

To clear (reset to the default values) a lightweight access point's configuration settings, use the **clear ap config** command.

clear ap config *ap-name* [**eventlog**] **keep-ip-config**

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
eventlog	(Optional) Deletes the existing event log and creates an empty event log file for a specific access point or for all access points joined to the controller.
keep-ip-config	(Optional) Specifies not to erase the static IP configuration of the Cisco access point.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Entering this command does not clear the static IP address of the access point.

Examples

This example shows how to clear the access point's configuration settings for the access point named AP01:

```
Controller# clear ap config AP01
```

clear ap eventlog-all

To delete the existing event log and create an empty event log file for all access points, use the **clear ap eventlog-all** command.

clear ap eventlog-all

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to delete the event log for all access points:

```
Controller# clear ap eventlog-all
```

clear ap join statistics

To clear the join statistics for all access points or for a specific access point, use the **clear ap join statistics** command.

clear ap join statistics

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to clear the join statistics of all the access points:

```
Controller# clear ap join statistics
```

clear ap mac-address

To clear the MAC address for the join statistics for a specific Cisco lightweight access point, use the **clear ap mac-address** command.

clear ap mac-address *mac* **join statistics**

Syntax Description

<i>mac</i>	Access point MAC address.
join statistics	Clears join statistics.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to clear the join statistics of an access point:

```
Controller# clear ap mac-address aaaa.bbbb.cccc join statistics
```

clear ap name wlan statistics

To clear WLAN statistics, use the **clear ap name wlan statistics** command.

clear ap name *ap-name* wlan statistics

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.

Command Default	None
-----------------	------

Command Modes	Any command mode
---------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to clear the WLAN configuration elements of the access point `cisco_ap`:

```
Controller# clear ap name cisco_ap wlan statistics
```

show ap cac voice

To display the list of all access points with brief voice statistics, which include bandwidth used, maximum bandwidth available, and the call information, use the **show ap cac voice** command.

show ap cac voice

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display voice CAC details that correspond to Cisco lightweight access points:

```
controller# show ap cac voice
```

```
1) AP Name: AP01
```

```
=====
```

```
Wireless Bandwidth (In MeanTime mt)
```

Slot#	Radio	Calls	BW-Max	BW-Alloc	Bw-InUse (%age)
1	0	802.11b/g	0	23437	0
2	1	802.11a	0	23437	0

```
Wired Bandwidth (in Kbps)
```

Slot#	Wlan-ID	Wlan-Name	BW-Config	BW-Avail
1	0	1	maria-open	0
2	0	12	24	0
3	1	1	maria-open	0
4	1	12	24	0

```
2) AP Name: AP02
```

```
=====
```

```
Wireless Bandwidth (In MeanTime mt)
```

Slot#	Radio	Calls	BW-Max	BW-Alloc	Bw-InUse (%age)
1	0	802.11b/g	0	23437	0
2	1	802.11a	0	23437	0

```
Wired Bandwidth (in Kbps)
```

	Slot#	Wlan-ID	Wlan-Name	BW-Config	BW-Avail
1	0	1	maria-open	0	0
2	0	12	24	0	0
3	1	1	maria-open	0	0
4	1	12	24	0	0

show ap capwap

To display the Control and Provisioning of Wireless Access Points (CAPWAP) configuration that is applied to all access points, use the **show ap capwap** command.

show ap capwap {retransmit| timers| summary}

Syntax Description

retransmit	Displays the access point CAPWAP retransmit parameters.
timers	Displays the rogue access point entry timers.
summary	Displays the network configuration of the Cisco controller.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the access point CAPWAP retransmit parameters:

```
Controller# show ap capwap retransmit
```

```
Global control packet retransmit interval : 3
Global control packet retransmit count : 5
```

AP Name	Retransmit Interval	Retransmit Count
AP01	3	5
AP02	3	5
AP03	3	5
AP04	3	5
AP05	3	5
AP07	3	5
AP08	3	5
AP09	3	5
AP10	3	5
AP11	3	5

AP12

3

5

This example shows how to display the rogue access point entry timers:

```
Controller# show ap capwap timers

AP Discovery timer      : 10
AP Heart Beat timeout  : 30
Primary Discovery timer : 120
Primed Join timeout    : 0
Fast Heartbeat         : Disabled
Fast Heartbeat timeout : 1
```

This example shows how to display the the network configuration of the Cisco controller:

```
Controller# show ap capwap summary

AP Fallback           : Enabled
AP Join Priority      : Disabled
AP Master             : Disabled
Primary backup Controller Name :
Primary backup Controller IP  : 0.0.0.0
Secondary backup Controller Name :
Secondary backup Controller IP  : 0.0.0.0
```

show ap cdp

To display the Cisco Discovery Protocol (CDP) information for all Cisco lightweight access points that are joined to the controller, use the **show ap cdp** command.

show ap cdp [neighbors [detail]]

Syntax Description

neighbors	(Optional) Displays neighbors using CDP.
detail	(Optional) Displays details about a specific access point neighbor that is using CDP.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the CDP status of all access points:

```
Controller# show ap cdp
```

This example shows how to display details about all neighbors that are using CDP:

```
Controller# show ap cdp neighbors
```

show ap config dot11

To display the detailed configuration of 802.11-58G radios on Cisco lightweight access points, use the **show ap config dot11** command.

show ap config dot11 58ghz summary

Syntax Description		
58ghz		Displays the 802.11-58G radios.
summary		Displays a summary of the radios on the access points.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how to display the detailed configuration of 802.11a-58G radios on access points:
 Controller# **show ap config dot11 58ghz summary**

show ap config dot11 dual-band summary

To view a summary of configuration settings for dual band radios of Cisco APs, use the **show ap config dot11 dual-band summary** command.

show ap config dot11 dual-band summary

Syntax Description

dual-band	Specifies the dual band radio.
summary	Displays a summary of configuration settings for dual band radios of Cisco APs.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

show ap config fnf

To view Netflow input and output monitors for all Cisco APs, use the **show ap config fnf** command.

show ap config fnf

Syntax Description

fnf	Netflow input and output monitors for all Cisco APs.
------------	--

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

show ap config

To display configuration settings for all access points that join the controller, use the **show ap config** command.

show ap config {ethernet| general| global}

Syntax Description

ethernet	Displays ethernet VLAN tagging information for all Cisco APs.
general	Displays common information for all Cisco APs.
global	Displays global settings for all Cisco APs.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display global syslog server settings:

```
Controller# show ap config global
```

```
AP global system logging host                : 255.255.255.255
```

show ap crash-file

To display the list of both crash and radio core dump files generated by lightweight access points, use the **show ap crash-file** command.

show ap crash-file

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the crash file generated by the access point:

```
Controller# show ap crash-file
```

show ap data-plane

To display the data plane status, use the **show ap data-plane** command.

show ap data-plane

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example show how to display the data plane status for all access points:

```
Controller# show ap data-plane
```

show ap dot11 l2roam

To display 802.11a or 802.11b/g Layer 2 client roaming information, use the **show ap dot11 l2roam** command.

```
show ap dot11 {24ghz| 5ghz} l2roam {mac-address mac-address statistics| rf-param| statistics}
```

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
mac-address mac-address statistics	Specifies the MAC address of a Cisco lightweight access point.
rf-param	Specifies the Layer 2 frequency parameters.
statistics	Specifies the Layer 2 client roaming statistics.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display 802.11b Layer 2 client roaming information:

```
Controller# show ap dot11 24ghz l2roam rf-param
```

```
L2Roam 802.11bg RF Parameters
  Config Mode       : Default
  Minimum RSSI      : -85
  Roam Hysteresis   : 2
  Scan Threshold    : -72
  Transition time    : 5
```

show ap dot11 cleanair air-quality

To display the air-quality summary information and air-quality worst information for the 802.11 networks, use the **show ap dot11 cleanair air-quality** command.

show ap dot11 {24ghz| 5ghz} cleanair air-quality {summary| worst}

Syntax Description

24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.
summary	Displays a summary of 802.11 radio band air-quality information.
worst	Displays the worst air-quality information for 802.11 networks.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the worst air-quality information for the 5 GHz band:

```
Controller# show ap dot11 5ghz cleanair air-quality worst
```

```
AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
-----
CISCO_AP3500 36      95      70      0          40
```

This example shows how to display the worst air-quality information for the 2.4 GHz band:

```
Controller# show ap dot11 24ghz cleanair air-quality worst
```

```
AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
-----
CISCO_AP3500 1        83      57      3          5
```

show ap dot11 cleanair config

To display the CleanAir configuration for the 802.11 networks, use the **show ap dot11 cleanair config** command.

show ap dot11 {24ghz|5ghz} cleanair config

Syntax Description	24ghz	Displays the 2.4 GHz band.
	5ghz	Displays the 5 GHz band.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the CleanAir configuration for the 2.4 GHz band:

```

Controller# show ap dot11 24ghz cleanair config
Clean Air Solution..... : Disabled
Air Quality Settings:
  Air Quality Reporting..... : Disabled
  Air Quality Reporting Period (min)..... : 15
  Air Quality Alarms..... : Enabled
  Air Quality Alarm Threshold..... : 10
Interference Device Settings:
  Interference Device Reporting..... : Enabled
  Bluetooth Link..... : Enabled
  Microwave Oven..... : Enabled
  802.11 FH..... : Enabled
  Bluetooth Discovery..... : Enabled
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  802.15.4..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  Microsoft Device..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
Interference Device Types Triggering Alarms:
  Bluetooth Link..... : Disabled
  Microwave Oven..... : Disabled
  802.11 FH..... : Disabled

```

```

Bluetooth Discovery..... : Disabled
TDD Transmitter..... : Disabled
Jammer..... : Disabled
Continuous Transmitter..... : Disabled
DECT-like Phone..... : Disabled
Video Camera..... : Disabled
802.15.4..... : Disabled
WiFi Inverted..... : Enabled
WiFi Invalid Channel..... : Enabled
SuperAG..... : Disabled
Canopy..... : Disabled
Microsoft Device..... : Disabled
WiMax Mobile..... : Disabled
WiMax Fixed..... : Disabled
Interference Device Alarms..... : Enabled
Additional Clean Air Settings:
CleanAir Event-driven RRM State..... : Disabled
CleanAir Driven RRM Sensitivity..... : LOW
CleanAir Persistent Devices state..... : Disabled
    
```

show ap dot11 cleanair summary

To view CleanAir configurations for all 802.11a Cisco APs, use the **show ap dot11 cleanair summary** command.

show ap dot11 {24ghz| 5ghz} cleanair summary

Syntax Description		
24ghz		Specifies the 2.4-GHz band
5ghz		Specifies the 5-GHz band
cleanair summary		Summary of CleanAir configurations for all 802.11a Cisco APs

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

show ap dot11

To view 802.11a or 802.11b configuration information, use the **show ap dot11** command.

show ap dot11 {24ghz| 5ghz} {channel| coverage| group| load-info| logging| media-stream| monitor| network| profile| receiver| service-policy| summary| txpower| ccx global}

Syntax Description

24ghz	Specifies the 2.4 GHz band.
5ghz	Specifies the 5 GHz band.
channel	Displays the automatic channel assignment configuration and statistics.
coverage	Displays the configuration and statistics for coverage hole detection.
group	Displays 802.11a or 802.11b Cisco radio RF grouping.
load-info	Displays channel utilization and client count information for all Cisco APs.
logging	Displays 802.11a or 802.11b RF event and performance logging.
media-stream	Display 802.11a or 802.11b Media Resource Reservation Control configurations.
monitor	Displays the 802.11a or 802.11b default Cisco radio monitoring.
network	Displays the 802.11a or 802.11b network configuration.
profile	Displays the 802.11a or 802.11b lightweight access point performance profiles.
receiver	Displays the configuration and statistics of the 802.11a or 802.11b receiver.
service-policy	Displays the Quality of Service (QoS) service policies for 802.11a or 802.11b radio for all Cisco access points.
summary	Displays the 802.11a or 802.11b Cisco lightweight access point name, channel, and transmit level summary.
txpower	Displays the 802.11a or 802.11b automatic transmit power assignment.

ccx global	Displays 802.11a or 802.11b Cisco Client eXtensions (CCX) information for all Cisco access points that are joined to the controller.
-------------------	--

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.
	Cisco IOS XE 3.3SE	The load-info parameter was added.

Examples

This example shows how to display the automatic channel assignment configuration and statistics:

```

Controller# show ap dot11 5ghz channel
Automatic Channel Assignment
  Channel Assignment Mode           : AUTO
  Channel Update Interval          : 12 Hours
  Anchor time (Hour of the day)    : 20
  Channel Update Contribution      : SNI.
  Channel Assignment Leader        : web (9.9.9.2)
  Last Run                         : 13105 seconds ago
  DCA Sensitivity Level            : MEDIUM (15 dB)
  DCA 802.11n Channel Width        : 40 Mhz
  Channel Energy Levels
    Minimum                        : unknown
    Average                        : unknown
    Maximum                        : unknown
  Channel Dwell Times
    Minimum                        : unknown
    Average                        : unknown
    Maximum                        : unknown
  802.11a 5 GHz Auto-RF Channel List
  Allowed Channel List             : 36,40,44,48,52,56,60,64,149,153,1
  57,161
  Unused Channel List             : 100,104,108,112,116,132,136,140,1
  65
  802.11a 4.9 GHz Auto-RF Channel List
  Allowed Channel List             :
  Unused Channel List             : 1,2,3,4,5,6,7,8,9,10,11,12,13,14,
  15,16,17,18,19,20,21,22,23,24,25,26
  DCA Outdoor AP option           : Disabled

```

This example shows how to display the statistics for coverage hole detection:

```

Controller# show ap dot11 5ghz coverage
Coverage Hole Detection
  802.11a Coverage Hole Detection Mode : Enabled
  802.11a Coverage Voice Packet Count : 100 packet(s)
  802.11a Coverage Voice Packet Percentage : 50 %
  802.11a Coverage Voice RSSI Threshold : -80dBm
  802.11a Coverage Data Packet Count : 50 packet(s)
  802.11a Coverage Data Packet Percentage : 50 %
  802.11a Coverage Data RSSI Threshold : -80dBm
  802.11a Global coverage exception level : 25

```

```
802.11a Global client minimum exception level : 3 clients
```

This example shows how to display Cisco radio RF group settings:

```
Controller# show ap dot11 5ghz group
Radio RF Grouping

802.11a Group Mode           : STATIC
802.11a Group Update Interval : 600 seconds
802.11a Group Leader        : web (10.10.10.1)
802.11a Group Member        : web (10.10.10.1)
                             nb1 (172.13.21.45) (*Unreachable)
802.11a Last Run            : 438 seconds ago
```

```
Mobility Agents RF membership information
-----
```

```
No of 802.11a MA RF-members : 0
```

This example shows how to display 802.11a RF event and performance logging:

```
Controller# show ap dot11 5ghz logging
RF Event and Performance Logging

Channel Update Logging      : Off
Coverage Profile Logging    : Off
Foreign Profile Logging     : Off
Load Profile Logging        : Off
Noise Profile Logging       : Off
Performance Profile Logging : Off
TxPower Update Logging     : Off
```

This example shows how to display the 802.11a media stream configuration:

```
Controller# show ap dot11 5ghz media-stream
Multicast-direct           : Disabled
Best Effort                 : Disabled
Video Re-Direct            : Disabled
Max Allowed Streams Per Radio : Auto
Max Allowed Streams Per Client : Auto
Max Video Bandwidth         : 0
Max Voice Bandwidth         : 75
Max Media Bandwidth         : 85
Min PHY Rate (Kbps)         : 6000
Max Retry Percentage        : 80
```

This example shows how to display the radio monitoring for the 802.11b network:

```
Controller# show ap dot11 5ghz monitor
Default 802.11a AP monitoring

802.11a Monitor Mode           : Enabled
802.11a Monitor Mode for Mesh AP Backhaul : disabled
802.11a Monitor Channels       : Country channels
802.11a RRM Neighbor Discover Type : Transparent
802.11a AP Coverage Interval   : 180 seconds
802.11a AP Load Interval      : 60 seconds
802.11a AP Noise Interval     : 180 seconds
802.11a AP Signal Strength Interval : 60 seconds
```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```
Controller# show ap dot11 5ghz profile
Default 802.11a AP performance profiles
802.11a Global Interference threshold..... 10%
802.11a Global noise threshold..... -70 dBm
802.11a Global RF utilization threshold..... 80%
802.11a Global throughput threshold..... 1000000 bps
802.11a Global clients threshold..... 12 clients
802.11a Global coverage threshold..... 12 dB
802.11a Global coverage exception level..... 80%
802.11a Global client minimum exception lev..... 3 clients
```

This example shows how to display the network configuration of an 802.11a profile:

```

Controller# show ap dot11 5ghz network
802.11a Network : Enabled
11nSupport : Enabled
    802.11a Low Band : Enabled
    802.11a Mid Band : Enabled
    802.11a High Band : Enabled

802.11a Operational Rates
    802.11a 6M : Mandatory
    802.11a 9M : Supported
    802.11a 12M : Mandatory
    802.11a 18M : Supported
    802.11a 24M : Mandatory
    802.11a 36M : Supported
    802.11a 48M : Supported
    802.11a 54M : Supported

802.11n MCS Settings:
    MCS 0 : Supported
    MCS 1 : Supported
    MCS 2 : Supported
    MCS 3 : Supported
    MCS 4 : Supported
    MCS 5 : Supported
    MCS 6 : Supported
    MCS 7 : Supported
    MCS 8 : Supported
    MCS 9 : Supported
    MCS 10 : Supported
    MCS 11 : Supported
    MCS 12 : Supported
    MCS 13 : Supported
    MCS 14 : Supported
    MCS 15 : Supported
    MCS 16 : Supported
    MCS 17 : Supported
    MCS 18 : Supported
    MCS 19 : Supported
    MCS 20 : Supported
    MCS 21 : Supported
    MCS 22 : Supported
    MCS 23 : Supported

802.11n Status:
    A-MPDU Tx:
        Priority 0 : Enabled
        Priority 1 : Disabled
        Priority 2 : Disabled
        Priority 3 : Disabled
        Priority 4 : Enabled
        Priority 5 : Enabled
        Priority 6 : Disabled
        Priority 7 : Disabled
    A-MSDU Tx:
        Priority 0 : Enabled
        Priority 1 : Enabled
        Priority 2 : Enabled
        Priority 3 : Enabled
        Priority 4 : Enabled
        Priority 5 : Enabled
        Priority 6 : Disabled
        Priority 7 : Disabled
    Guard Interval : Any
    Rifs Rx : Enabled
    Beacon Interval : 100
    CF Pollable mandatory : Disabled
    CF Poll Request Mandatory : Disabled
    CFP Period : 4
    CFP Maximum Duration : 60
    Default Channel : 36
    Default Tx Power Level : 1
    DTPC Status : Enabled
    Fragmentation Threshold : 2346

```

```

Pico-Cell Status : Disabled
Pico-Cell-V2 Status : Disabled
TI Threshold : 0
Legacy Tx Beamforming setting : Disabled
Traffic Stream Metrics Status : Disabled
Expedited BW Request Status : Disabled
EDCA profile type check : default-wmm
Call Admission Control (CAC) configuration
Voice AC
  Voice AC - Admission control (ACM) : Disabled
  Voice Stream-Size : 84000
  Voice Max-Streams : 2
  Voice Max RF Bandwidth : 75
  Voice Reserved Roaming Bandwidth : 6
  Voice Load-Based CAC mode : Enabled
  Voice tspec inactivity timeout : Enabled
CAC SIP-Voice configuration
  SIP based CAC : Disabled
  SIP call bandwidth : 64
  SIP call bandwidth sample-size : 20
Video AC
  Video AC - Admission control (ACM) : Disabled
  Video max RF bandwidth : Infinite
  Video reserved roaming bandwidth : 0

```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```

Controller# show ap dot11 5ghz receiver
Default 802.11a AP performance profiles
802.11a Global Interference threshold..... 10%
802.11a Global noise threshold..... -70 dBm
802.11a Global RF utilization threshold..... 80%
802.11a Global throughput threshold..... 1000000 bps
802.11a Global clients threshold..... 12 clients
802.11a Global coverage threshold..... 12 dB
802.11a Global coverage exception level..... 80%
802.11a Global client minimum exception lev..... 3 clients

```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```

Controller# show ap dot11 5ghz service-policy

```

This example shows how to display a summary of the 802.11b access point settings:

```

Controller# show ap dot11 5ghz summary
AP Name MAC Address      Admin State Operation State Channel TxPower
-----
CJ-1240 00:21:1b:ea:36:60 ENABLED    UP          161      1( )
CJ-1130 00:1f:ca:cf:b6:60 ENABLED    UP          56*     1(*)

```

This example shows how to display the configuration and statistics of the 802.11a transmit power cost:

```

Controller# show ap dot11 5ghz txpower
Automatic Transmit Power Assignment

Transmit Power Assignment Mode      : AUTO
Transmit Power Update Interval      : 600 seconds
Transmit Power Threshold            : -70 dBm
Transmit Power Neighbor Count       : 3 APs
Min Transmit Power                  : -10 dBm
Max Transmit Power                  : 30 dBm
Transmit Power Update Contribution  : SNI.
Transmit Power Assignment Leader    : web (10.10.10.1)
Last Run                            : 437 seconds ago

```

This example shows how to display the configuration and statistics of the 802.11a transmit power cost:

```

Controller# show ap dot11 5ghz ccx global
 802.11a Client Beacon Measurements:
  disabled

```

show ap ethernet statistics

To display Ethernet statistics for all Cisco lightweight access points, use the **show ap ethernet statistics** command.

show ap ethernet statistics

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display Ethernet statistics for all access points:

```
Controller# show ap ethernet statistics
```

show ap groups

To display information about all access point groups that are defined in the system, use the **show ap groups** command.

show ap groups

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display information about all access point groups:

```
Controller# show ap groups
```

show ap groups extended

To view information about all AP groups defined in the system in detail, use the **show ap groups extended** command.

show ap groups extended

Syntax Description	extended	Displays information about all AP groups defined in the system in detail.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

show ap image

To display the images present on Cisco lightweight access points, use the **show ap image** command.

show ap image

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display images on the access points:

```
Controller# show ap image
```

show ap join stats summary

To display the last join error detail for a specific access point, use the **show ap join stats summary** command.

show ap join stats summary

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

To obtain the MAC address of the 802.11 radio interface, enter the **show interface** command on the access point.

Examples

This example shows how to display specific join information for an access point:

```
Controller# show ap join stats summary
Number of APs : 1
```

Base MAC	Ethernet MAC	AP Name	IP Address	Status
c8f9.f91a.aa80	0000.0000.0000	N A	0.0.0.0	Not Joined

show ap link-encryption

To display the link encryption status, use the **show ap link-encryption** command.

show ap link-encryption

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example show how to display the link-encryption status:

```
Controller# show ap link-encryption
```

show ap mac-address

To display join-related statistics collected and last join error details for access points, use the **show ap mac-address** command.

show ap mac-address *mac-address* **join stats** {**detailed**|**summary**}

Syntax Description

<i>mac-address</i>	Access point Ethernet MAC address or the MAC address of the 802.11 radio interface.
join stats	Displays join information and statistics for Cisco access points.
detailed	Displays all join-related statistics collected.
summary	Displays the last join error detail.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display join information for a specific access point that is trying to join the controller:

```
Controller# show ap mac-address d0c2.8267.8b00 join stats detailed

Discovery phase statistics
  Discovery requests received           : 6
  Successful discovery responses sent   : 6
  Unsuccessful discovery request processing : 0
  Reason for last unsuccessful discovery attempt : Not applicable
  Time at last successful discovery attempt : Nov 20 17:25:10.841
  Time at last unsuccessful discovery attempt : Not applicable

Join phase statistics
  Join requests received           : 3
  Successful join responses sent   : 3
  Unsuccessful join request processing : 0
  Reason for last unsuccessful join attempt : Not applicable
  Time at last successful join attempt : Nov 20 17:25:20.998
  Time at last unsuccessful join attempt : Not applicable

Configuration phase statistics
  Configuration requests received           : 8
  Successful configuration responses sent   : 3
  Unsuccessful configuration request processing : 0
```

```

Reason for last unsuccessful configuration attempt      : Not applicable
Time at last successful configuration attempt         : Nov 20 17:25:21.177
Time at last unsuccessful configuration attempt       : Not applicable

Last AP message decryption failure details
Reason for last message decryption failure           : Not applicable

Last AP disconnect details
Reason for last AP connection failure               : Number of message retransmission
to the AP has reached maximum

Last join error summary
Type of error that occurred last                     : AP got or has been disconnected

Reason for error that occurred last                  : Number of message retransmission
to the AP has reached maximum
Time at which the last join error occurred           : Nov 20 17:22:36.438

```

This example shows how to display specific join information for an access point:

```
Controller# show ap mac-address d0c2.8267.8b00 join stats detailed
```

```

Is the AP currently connected to controller..... No
Time at which the AP joined this controller last time..... Aug 21 12:50:36:061
Type of error that occurred last..... Lwapp join request
rejected
Reason for error that occurred last..... RADIUS authorization
is pending for the AP
Time at which the last join error occurred..... Aug 21 12:50:34:374

```

show ap monitor-mode summary

To display the current channel-optimized monitor mode settings, use the **show ap monitor-mode summary** command.

show ap monitor-mode summary

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display current channel-optimized monitor mode settings:

```
Controller# show ap monitor-mode summary
```

```
AP Name Ethernet MAC      Status  Scanning Channel List
-----
AP_004  xx:xx:xx:xx:xx:xx Tracking 1,6,11, 4
```

show ap name auto-rf

To display the auto-RF settings for a Cisco lightweight access point, use the **show ap name auto-rf** command.

show ap name *ap-name* auto-rf dot11 {24ghz| 5ghz}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.

Command Default

None

Command Modes

Privileged EXEC.

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display auto-RF information for an access point:

```

Controller# show ap name AP01 auto-rf dot11 24ghz

Number of Slots                : 2
AP Name                        : TSIM_AP-1
MAC Address                    : 0000.2000.02f0
Slot ID                        : 0
Radio Type                     : 802.11b/g
Subband Type                   : All

Noise Information
  Noise Profile                : Failed
  Channel 1                    : 24 dBm
  Channel 2                    : 48 dBm
  Channel 3                    : 72 dBm
  Channel 4                    : 96 dBm
  Channel 5                    : 120 dBm
  Channel 6                    : -112 dBm
  Channel 7                    : -88 dBm
  Channel 8                    : -64 dBm
  Channel 9                    : -40 dBm
  Channel 10                   : -16 dBm
  Channel 11                   : 8 dBm

Interference Information
  Interference Profile         : Passed
  Channel 1                    : -128 dBm @ 0% busy
  Channel 2                    : -71 dBm @ 1% busy
  Channel 3                    : -72 dBm @ 1% busy
  Channel 4                    : -73 dBm @ 2% busy

```

```

Channel 5 : -74 dBm @ 3% busy
Channel 6 : -75 dBm @ 4% busy
Channel 7 : -76 dBm @ 5% busy
Channel 8 : -77 dBm @ 5% busy
Channel 9 : -78 dBm @ 6% busy
Channel 10 : -79 dBm @ 7% busy
Channel 11 : -80 dBm @ 8% busy

Rogue Histogram (20/40_ABOVE/40_BELOW)
Channel 36 : 27/ 4/ 0
Channel 40 : 13/ 0/ 0
Channel 44 : 5/ 0/ 0
Channel 48 : 6/ 0/ 1
Channel 52 : 4/ 0/ 0
Channel 56 : 5/ 0/ 0
Channel 60 : 1/ 3/ 0
Channel 64 : 3/ 0/ 0
Channel 100 : 0/ 0/ 0
Channel 104 : 0/ 0/ 0
Channel 108 : 0/ 1/ 0

Load Information
Load Profile : Passed
Receive Utilization : 10%
Transmit Utilization : 20%
Channel Utilization : 50%
Attached Clients : 0 clients

Coverage Information
Coverage Profile : Passed
Failed Clients : 0 clients

Client Signal Strengths
RSSI -100 dBm : 0 clients
RSSI -92 dBm : 0 clients
RSSI -84 dBm : 0 clients
RSSI -76 dBm : 0 clients
RSSI -68 dBm : 0 clients
RSSI -60 dBm : 0 clients
RSSI -52 dBm : 0 clients

Client Signal to Noise Ratios
SNR 0 dB : 0 clients
SNR 5 dB : 0 clients
SNR 10 dB : 0 clients
SNR 15 dB : 0 clients
SNR 20 dB : 0 clients
SNR 25 dB : 0 clients
SNR 30 dB : 0 clients
SNR 35 dB : 0 clients
SNR 40 dB : 0 clients
SNR 45 dB : 0 clients

Nearby APs
AP 0000.2000.0300 slot 0 : -68 dBm on 11 (10.10.10.1)
AP 0000.2000.0400 slot 0 : -68 dBm on 11 (10.10.10.1)
AP 0000.2000.0600 slot 0 : -68 dBm on 11 (10.10.10.1)

Radar Information

Channel Assignment Information
Current Channel Average Energy : 0 dBm
Previous Channel Average Energy : 0 dBm
Channel Change Count : 0
Last Channel Change Time : Wed Oct 17 08:13:36 2012
Recommended Best Channel : 11

RF Parameter Recommendations
Power Level : 1
RTS/CTS Threshold : 2347
Fragmentation Threshold : 2346
Antenna Pattern : 0

```

Persistent Interference Devices

show ap name bhmode

To display Cisco bridge backhaul mode, use the **show ap name bhmode** command.

show ap name *ap-name* bhmode

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display Cisco bridge backhaul mode of an access point:

```
Controller# show ap name TSIM_AP-1 bhmode
```

show ap name bhrate

To display the Cisco bridge backhaul rate, use the **show ap name bhrate** command.

show ap name *ap-name* bhrate

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the Cisco bridge backhaul rate for an access point:

```
Controller# show ap name AP01 bhrate
```

show ap name cac voice

To display voice call admission control details for a specific Cisco lightweight access point, use the **show ap name cac voice** command.

show ap name *ap-name* **cac voice**

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display voice call admission control details for an access point:

```
Controller# show ap name AP01 cac voice
```

```
1) AP Name: AP01
```

```
=====
```

```
Wireless Bandwidth (In MeanTime mt)
```

Slot#	Radio	Calls	BW-Max	BW-Alloc	Bw-InUse (%age)
1	0	802.11b/g	0	23437	0
2	1	802.11a	0	23437	0

```
Wired Bandwidth (in Kbps)
```

Slot#	Wlan-ID	Wlan-Name	BW-Config	BW-Avail
1	0	1	maria-open	0
2	0	12	24	0
3	1	1	maria-open	0
4	1	12	24	0

show ap name config fnf

To view the Netflow input and output monitors for a Cisco AP, use the **show ap name config fnf** command.

show ap name *ap-name* config fnf

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point
fnf	Netflow input and output monitors for a Cisco AP

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

show ap name dot11 call-control

To display call control information and the metrics for successful calls, use the **show ap name dot11 call-control** command.

```
show ap name ap-name dot11 {24ghz|5ghz} call-control {call-info|metrics}
```

Syntax Description		
<i>ap-name</i>		Name of the Cisco lightweight access point
24ghz		Displays the 2.4 GHz band.
5ghz		Displays the 5 GHz band.
call-info		Displays call information.
metrics		Displays call metrics.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display metrics for successful calls for an access point:

```
Controller# show ap name AP01 dot11 24ghz call-control metrics
```

```
Slot#    Call Count    Call Duration
-----
0         0              0
```

show ap name capwap retransmit

To display Control and Provisioning of Wireless Access Points (CAPWAP) retransmit settings, use the **show ap name capwap retransmit** command.

show ap name *ap-name* capwap retransmit

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display CAPWAP retransmit settings of an access point:

```
Controller# show ap name AP01 capwap retransmit
```

```
AP Name      Retransmit Interval Retransmit Count
-----
AP01         3                   5
```

show ap name ccx rm

To display an access point's Cisco Client eXtensions (CCX) radio management status information, use the **show ap name ccx rm** command.

show ap name *ap-name* ccx rm status

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display CCX radio management information for an access point:

```
Controller# show ap name AP01 ccx rm status
```

```
802.11b/g Radio
  Beacon Request           : Disabled
  Channel Load Request     : Disabled
  Frame Request            : Disabled
  Noise Histogram Request  : Disabled
  Path Loss Request       : Disabled
  Interval                  : 60
  Iteration                 : 0

802.11a Radio
  Beacon Request           : Disabled
  Channel Load Request     : Disabled
  Frame Request            : Disabled
  Noise Histogram Request  : Disabled
  Path Loss Request       : Disabled
  Interval                  : 60
  Iteration                 : 0
```

show ap name cdp

To display the Cisco Discovery Protocol (CDP) information for an access point, use the **show ap name cdp** command.

show ap name *ap-name* **cdp** [**neighbors** [**detail**]]

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
neighbors	(Optional) Displays neighbors that are using CDP.
detail	(Optional) Displays details about a specific access point neighbor that is using CDP.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display CDP information for an access point:

```
Controller# show ap name AP01 cdp neighbors detail
```

show ap name channel

To display the available channels for a specific mesh access point, use the **show ap name channel** command.

show ap name *ap-name* **channel**

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the available channels for a particular access point:

```
Controller# show ap name AP01 channel
```

```
Slot ID          : 0
Allowed Channel List : 1, 2, 3, 4, 5, 6, 7, 8, 9
                   10, 11
Slot ID          : 1
Allowed Channel List : 36, 40, 44, 48, 52, 56, 60, 64, 100
                   104, 108, 112, 116, 132, 136, 140, 149,
                   153
                   157, 161
```

show ap name config

To display common information and Ethernet VLAN tagging information for a specific Cisco lightweight access point, use the **show ap name config** command.

show ap name *ap-name* config {ethernet|general}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
ethernet	Displays Ethernet tagging configuration information for an access point.
general	Displays common information for an access point.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display Ethernet tagging information for an access point:

```
Controller# show ap name AP01 config ethernet
```

```
VLAN Tagging Information for AP01
```

This example shows how to display common information for an access point:

```
Controller# show ap name AP01 config general
```

```
Cisco AP Name                : AP01
Cisco AP Identifier          : 5
Country Code                 : US - United States
Regulatory Domain Allowed by Country : 802.11bg:-A      802.11a:-A
AP Country Code              : US - United States
AP Regulatory Domain         : Unconfigured
Switch Port Number           : Tel/0/1
MAC Address                   : 0000.2000.02f0
IP Address Configuration     : Static IP assigned
IP Address                   : 10.10.10.12
IP Netmask                    : 255.255.0.0
Gateway IP Address           : 10.10.10.1
Fallback IP Address Being Used : 10.10.10.12
Domain                        : Cisco
Name Server                   : 0.0.0.0
CAPWAP Path MTU              : 1485
Telnet State                  : Enabled
SSH State                     : Disabled
Cisco AP Location            : sanjose
```

```

Cisco AP Group Name           : default-group
Primary Cisco Controller Name : CAPWAP Controller
Primary Cisco Controller IP Address : 10.10.10.1
Secondary Cisco Controller Name :
Secondary Cisco Controller IP Address : Not Configured
Tertiary Cisco Controller Name :
Tertiary Cisco Controller IP Address : Not Configured
Administrative State          : Enabled
Operation State               : Registered
AP Mode                       : Local
AP Submode                    : Not Configured
Remote AP Debug               : Disabled
Logging Trap Severity Level   : informational
Software Version               : 7.4.0.5
Boot Version                   : 7.4.0.5
Stats Reporting Period        : 180
LED State                     : Enabled
PoE Pre-Standard Switch       : Disabled
PoE Power Injector MAC Address : Disabled
Power Type/Mode               : Power Injector/Normal Mode
Number of Slots                : 2
AP Model                      : 1140AG
AP Image                      : C1140-K9W8-M
IOS Version                   :
Reset Button                   :
AP Serial Number              : SIM1140K001
AP Certificate Type           : Manufacture Installed
Management Frame Protection Validation : Disabled
AP User Mode                  : Customized
AP User Name                  : cisco
AP 802.1X User Mode           : Not Configured
AP 802.1X User Name           : Not Configured
Cisco AP System Logging Host   : 255.255.255.255
AP Up Time                    : 15 days 16 hours 19 minutes 57
seconds
AP CAPWAP Up Time             : 4 minutes 56 seconds
Join Date and Time            : 10/18/2012 04:48:56
Join Taken Time               : 15 days 16 hours 15 minutes 0
seconds
Join Priority                  : 1
Ethernet Port Duplex          : Auto
Ethernet Port Speed           : Auto
AP Link Latency               : Disabled
Rogue Detection                : Disabled
AP TCP MSS Adjust             : Disabled
AP TCP MSS Size               : 6146

```

show ap name config dot11

To display 802.11 configuration information that corresponds to specific Cisco lightweight access points, use the **show ap name config dot11** command.

show ap name *ap-name* config dot11 {24ghz|49ghz|58ghz|5ghz|dual-band}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Displays the 2.4 GHz band.
49ghz	Displays 802.11-4.9G network settings.
58ghz	Displays 802.11-5.8G network settings.
5ghz	Displays the 5 GHz band settings.
dual-band	Displays the dual band radio settings.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.
Cisco IOS XE 3.3SE	The dual-band parameter was added.

Examples

This example shows how to display 802.11b configuration information that corresponds to a specific Cisco lightweight access point:

```

Controller# show ap name AP01 config dot11 24ghz

Cisco AP Identifier           : 5
Cisco AP Name                 : AP01
Country Code                  : US - United States
Regulatory Domain Allowed by Country : 802.11bg:-A      802.11a:-A
AP Country Code               : US - United States
AP Regulatory Domain          : -A
Switch Port Number           : Te1/0/1
MAC Address                   : 0000.2000.02f0
IP Address Configuration      : Static IP assigned
IP Address                    : 10.10.10.12
IP Netmask                    : 255.255.0.0
Gateway IP Address            : 10.10.10.1
Fallback IP Address Being Used : 10.10.10.12

```

```

Domain : Cisco
Name Server : 0.0.0.0
CAPWAP Path MTU : 1485
Telnet State : Enabled
SSH State : Disabled
Cisco AP Location : sanjose
Cisco AP Group Name : default-group
Administrative State : Enabled
Operation State : Registered
AP Mode : Local
AP Submode : Not Configured
Remote AP Debug : Disabled
Logging Trap Severity Level : informational
Software Version : 7.4.0.5
Boot Version : 7.4.0.5
Mini IOS Version : 3.0.51.0
Stats Reporting Period : 180
LED State : Enabled
PoE Pre-Standard Switch : Disabled
PoE Power Injector MAC Address : Disabled
Power Type/Mode : Power Injector/Normal Mode
Number of Slots : 2
AP Model : 1140AG
AP Image : C1140-K9W8-M
IOS Version :
Reset Button :
AP Serial Number : SIM1140K001
AP Certificate Type : Manufacture Installed
Management Frame Protection Validation : Disabled
AP User Mode : Customized
AP User Name : cisco
AP 802.1X User Mode : Not Configured
AP 802.1X User Name : Not Configured
Cisco AP System Logging Host : 255.255.255.255
AP Up Time : 15 days 17 hours 9 minutes 41
seconds
AP CAPWAP Up Time : 54 minutes 40 seconds
Join Date and Time : 10/18/2012 04:48:56
Join Taken Time : 15 days 16 hours 15 minutes 0
seconds

Attributes for Slot 0
Radio Type : 802.11n - 2.4 GHz
Administrative State : Enabled
Operation State : Up
Cell ID : 0

Station Configuration
Configuration : Automatic
Number of WLANs : 1
Medium Occupancy Limit : 100
CFP Period : 4
CFP Maximum Duration : 60
BSSID : 000020000200

Operation Rate Set
1000 Kbps : MANDATORY
2000 Kbps : MANDATORY
5500 Kbps : MANDATORY
11000 Kbps : MANDATORY
6000 Kbps : SUPPORTED
9000 Kbps : SUPPORTED
12000 Kbps : SUPPORTED
18000 Kbps : SUPPORTED
24000 Kbps : SUPPORTED
36000 Kbps : SUPPORTED
48000 Kbps : SUPPORTED
54000 Kbps : SUPPORTED

MCS Set
MCS 0 : SUPPORTED
MCS 1 : SUPPORTED
MCS 2 : SUPPORTED

```

```

MCS 3 : SUPPORTED
MCS 4 : SUPPORTED
MCS 5 : SUPPORTED
MCS 6 : SUPPORTED
MCS 7 : SUPPORTED
MCS 8 : SUPPORTED
MCS 9 : SUPPORTED
MCS 10 : SUPPORTED
MCS 11 : SUPPORTED
MCS 12 : SUPPORTED
MCS 13 : SUPPORTED
MCS 14 : SUPPORTED
MCS 15 : SUPPORTED
MCS 16 : DISABLED
MCS 17 : DISABLED
MCS 18 : DISABLED
MCS 19 : DISABLED
MCS 20 : DISABLED
MCS 21 : DISABLED
MCS 22 : DISABLED
MCS 23 : DISABLED

Beacon Period : 100
Fragmentation Threshold : 2346
Multi Domain Capability Implemented : True
Multi Domain Capability Enabled : True
Country String : US

Multi Domain Capability
Configuration : Automatic
First Channel : 0
Number of Channels : 0
Country String : US

MAC Operation Parameters
Configuration : Automatic
Fragmentation Threshold : 2346
Packet Retry Limit : 64
Legacy Tx Beamforming Setting : Disabled

Tx Power
Number of Supported Power Levels : 8
Tx Power Level 1 : 20 dBm
Tx Power Level 2 : 17 dBm
Tx Power Level 3 : 14 dBm
Tx Power Level 4 : 11 dBm
Tx Power Level 5 : 8 dBm
Tx Power Level 6 : 5 dBm
Tx Power Level 7 : 2 dBm
Tx Power Level 8 : -1 dBm
Tx Power Configuration : Automatic
Current Tx Power Level : 1

Phy OFDM Parameters
Configuration : Automatic
Current Channel : 11
Extension Channel : None
Channel Width : 20 MHz
Allowed Channel List : 1, 2, 3, 4, 5, 6, 7, 8, 9
10, 11
TI Threshold : 0
Antenna Type : Internal
Internal Antenna Gain (in .5 dBi units) : 0
Diversity : Diversity enabled

802.11n Antennas
Tx : A, B, C
Rx : A, B, C

Performance Profile Parameters
Configuration : Automatic
Interference Threshold : 10%
Noise Threshold : -70 dBm

```

```
RF Utilization Threshold           : 80%
Data Rate Threshold                : 1000000 bps
Client Threshold                   : 12 clients
Coverage SNR Threshold             : 15 dB
Coverage Exception Level           : 25%
Client Minimum Exception Level     : 3 clients
RTS/CTS Threshold                  : 2347
Short Retry Limit                  : 7
Long Retry Limit                   : 4
Max Tx MSDU Lifetime               : 512
Max Rx Lifetime                    : 512

CleanAir Management Information
CleanAir Capable                   : Yes
CleanAir Management Admin State    : Enabled
CleanAir Management Operation State : Up
Rapid Update Mode                  : Disabled
Spectrum Expert connection         : Disabled
CleanAir NSI Key                   : 377313C8F290E246E640C4EF177BED
88
Spectrum Expert connections counter : 0
CleanAir Sensor State              : Configured

Rogue Containment Information
Containment Count                   : 0
```

show ap name config slot

To display configuration information for slots on a specific Cisco lightweight access point, use the **show ap name config slot** command.

show ap name *ap-name* config slot {0|1|2|3}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
0	Displays slot number 0.
1	Displays slot number 1.
2	Displays slot number 2.
3	Displays slot number 3.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display configuration information for slots on an access point:

```
Controller# show ap name AP01 config slot 0

Cisco AP Identifier           : 3
Cisco AP Name                 : AP01
Country Code                  : US - United States
Regulatory Domain Allowed by Country : 802.11bg:-A 802.11a:-A
AP Country Code               : US - United States
AP Regulatory Domain          : -A
Switch Port Number            : Tel1/0/1
MAC Address                    : 0000.2000.02f0
IP Address Configuration      : Static IP assigned
IP Address                    : 10.10.10.12
IP Netmask                    : 255.255.0.0
Gateway IP Address            : 10.10.10.1
Fallback IP Address Being Used : 10.10.10.12
Domain                         : Cisco
Name Server                   : 0.0.0.0
CAPWAP Path MTU               : 1485
Telnet State                   : Enabled
SSH State                      : Disabled
Cisco AP Location              : sanjose
Cisco AP Group Name            : default-group
```

```

Administrative State           : Enabled
Operation State               : Registered
AP Mode                       : Local
AP Submode                    : Not Configured
Remote AP Debug               : Disabled
Logging Trap Severity Level   : informational
Software Version              : 7.4.0.5
Boot Version                  : 7.4.0.5
Mini IOS Version              : 3.0.51.0
Stats Reporting Period        : 180
LED State                     : Enabled
PoE Pre-Standard Switch       : Disabled
PoE Power Injector MAC Address : Disabled
Power Type/Mode               : Power Injector/Normal Mode
Number of Slots               : 2
AP Model                      : 1140AG
AP Image                      : C1140-K9W8-M
IOS Version                   :
Reset Button                  :
AP Serial Number              : SIM1140K001
AP Certificate Type           : Manufacture Installed
Management Frame Protection Validation : Disabled
AP User Mode                  : Customized
AP User Name                  : cisco
AP 802.1X User Mode           : Not Configured
AP 802.1X User Name           : Not Configured
Cisco AP System Logging Host  : 255.255.255.255
AP Up Time                    : 15 days 16 hours 1 minute 19 s
econds
AP CAPWAP Up Time            : 20 hours 21 minutes 37 seconds

Join Date and Time            : 10/17/2012 08:13:36
Join Taken Time               : 14 days 19 hours 39 minutes 41
seconds

Attributes for Slot 0
Radio Type                    : 802.11n - 2.4 GHz
Administrative State          : Enabled
Operation State               : Up
Cell ID                       : 0

Station Configuration
Configuration                  : Automatic
Number of WLANs               : 1
Medium Occupancy Limit        : 100
CFP Period                    : 4
CFP Maximum Duration          : 60
BSSID                         : 000020000200

Operation Rate Set
1000 Kbps                     : MANDATORY
2000 Kbps                     : MANDATORY
5500 Kbps                     : MANDATORY
11000 Kbps                    : MANDATORY
6000 Kbps                     : SUPPORTED
9000 Kbps                     : SUPPORTED
12000 Kbps                    : SUPPORTED
18000 Kbps                    : SUPPORTED
24000 Kbps                    : SUPPORTED
36000 Kbps                    : SUPPORTED
48000 Kbps                    : SUPPORTED
54000 Kbps                    : SUPPORTED

MCS Set
MCS 0                         : SUPPORTED
MCS 1                         : SUPPORTED
MCS 2                         : SUPPORTED
MCS 3                         : SUPPORTED
MCS 4                         : SUPPORTED
MCS 5                         : SUPPORTED
MCS 6                         : SUPPORTED
MCS 7                         : SUPPORTED
MCS 8                         : SUPPORTED

```

```

MCS 9 : SUPPORTED
MCS 10 : SUPPORTED
MCS 11 : SUPPORTED
MCS 12 : SUPPORTED
MCS 13 : SUPPORTED
MCS 14 : SUPPORTED
MCS 15 : SUPPORTED
MCS 16 : DISABLED
MCS 17 : DISABLED
MCS 18 : DISABLED
MCS 19 : DISABLED
MCS 20 : DISABLED
MCS 21 : DISABLED
MCS 22 : DISABLED
MCS 23 : DISABLED

Beacon Period : 100
Fragmentation Threshold : 2346
Multi Domain Capability Implemented : True
Multi Domain Capability Enabled : True
Country String : US

Multi Domain Capability
Configuration : Automatic
First Channel : 0
Number of Channels : 0
Country String : US

MAC Operation Parameters
Configuration : Automatic
Fragmentation Threshold : 2346
Packet Retry Limit : 64

Tx Power
Number of Supported Power Levels : 8
Tx Power Level 1 : 20 dBm
Tx Power Level 2 : 17 dBm
Tx Power Level 3 : 14 dBm
Tx Power Level 4 : 11 dBm
Tx Power Level 5 : 8 dBm
Tx Power Level 6 : 5 dBm
Tx Power Level 7 : 2 dBm
Tx Power Level 8 : -1 dBm
Tx Power Configuration : Automatic
Current Tx Power Level : 1

Phy OFDM Parameters
Configuration : Automatic
Current Channel : 11
Extension Channel : None
Channel Width : 20 MHz
Allowed Channel List : 1, 2, 3, 4, 5, 6, 7, 8, 9
10, 11
TI Threshold : 0
Antenna Type : Internal
Internal Antenna Gain (in .5 dBi units) : 0
Diversity : Diversity enabled

802.11n Antennas
Tx : A, B, C
Rx : A, B, C

Performance Profile Parameters
Configuration : Automatic
Interference Threshold : 10%
Noise Threshold : -70 dBm
RF Utilization Threshold : 80%
Data Rate Threshold : 1000000 bps
Client Threshold : 12 clients
Coverage SNR Threshold : 15 dB
Coverage Exception Level : 25%
Client Minimum Exception Level : 3 clients

```

```
Rogue Containment Information  
  Containment Count           : 0
```

show ap name core-dump

To display the memory core dump information for a lightweight access point, use the **show ap name core-dump** command.

show ap name *ap-name* core-dump

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the memory core dump information:

```
Controller# show ap name 3602a core-dump
```

```
TFTP server IP : 172.31.25.21
Memory core dump file : 3602a.dump
Memory core dump file compressed : Disabled
```

show ap name data-plane

To display the data plane status of a specific Cisco lightweight access point, use the **show ap name data-plane** command.

show ap name *ap-name* **data-plane**

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the data plane status of an access point:

```
Controller# show ap name AP01 data-plane
```

AP Name	Min Data Round Trip	Data Round Trip	Max Data Round Trip	Last Update
AP01	0.000s	0.000s	0.000s	00:00:00

show ap name dot11

To display 802.11a or 802.11b configuration information that corresponds to specific Cisco lightweight access points, use the **show ap name dot11** command.

```
show ap name ap-name dot11 {24ghz|5ghz} {ccx|cdp|profile|service-policy output|stats|tsm {all|client-mac}}
```

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.
ccx	Displays the Cisco Client eXtensions (CCX) radio management status information.
cdp	Displays Cisco Discovery Protocol (CDP) information.
profile	Displays configuration and statistics of 802.11 profiling.
service-policy output	Displays downstream service policy information.
stats	Displays Cisco lightweight access point statistics.
tsm	Displays 802.11 traffic stream metrics statistics.
all	Displays the list of all access points to which the client has associations.
<i>client-mac</i>	MAC address of the client.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the service policy that is associated with the access point:

```
Controller# show ap name test-ap dot11 24ghz service-policy output
Policy Name : test-ap1
```

Policy State : Installed

This example shows how to display the CCX RRM 802.11 configuration for a specific access point:

```
Controller# show ap name AP01 dot11 24ghz ccx
```

This example show how to display CDP information for a specific access point:

```
Controller# show ap name AP01 dot11 24ghz cdp
```

```
AP Name                AP CDP State
-----
AP03                   Disabled
```

This example show how to display the configuration and statistics of 802.11b profiling for a specific access point:

```
Controller# show ap name AP01 dot11 24ghz profile
```

```
802.11b Cisco AP performance profile mode      : GLOBAL
802.11b Cisco AP Interference threshold       : 10 %
802.11b Cisco AP noise threshold              : -70 dBm
802.11b Cisco AP RF utilization threshold      : 80 %
802.11b Cisco AP throughput threshold         : 1000000 bps
802.11b Cisco AP clients threshold            : 12 clients
```

This example show how to display downstream service policy information for a specific access point:

```
Controller# show ap name AP01 dot11 24ghz service-policy output
```

```
Policy Name  : def-11gn
Policy State : Installed
```

This example show how to display statistics for a specific access point:

```
Controller# show ap name AP01 dot11 24ghz stats
```

```
Number of Users.....: 0
TxFragmentCount.....: 0
MulticastTxFrameCnt.....: 0
FailedCount.....: 0
RetryCount.....: 0
MultipleRetryCount.....: 0
FrameDuplicateCount.....: 0
RtsSuccessCount.....: 0
RtsFailureCount.....: 0
AckFailureCount.....: 0
RxIncompleteFragment.....: 0
MulticastRxFrameCnt.....: 0
FcsErrorCount.....: 0
TxFrameCount.....: 0
WepUndecryptableCount.....: 0
TxFramesDropped.....: 0

Call Admission Control (CAC) Stats
  Voice Bandwidth in use(% of config bw).....: 0
  Video Bandwidth in use(% of config bw).....: 0
  Total BW in use for Voice(%).....: 0
  Total BW in use for SIP Preferred call(%).....: 0

Load based Voice Call Stats
  Total channel MT free.....: 0
  Total voice MT free.....: 0
  Na Direct.....: 0
  Na Roam.....: 0

WMM TSPEC CAC Call Stats
  Total num of voice calls in progress.....: 0
  Num of roaming voice calls in progress.....: 0
  Total Num of voice calls since AP joined.....: 0
  Total Num of roaming calls since AP joined.....: 0
```

```

Total Num of exp bw requests received.....: 0
Total Num of exp bw requests admitted.....: 0
Num of voice calls rejected since AP joined....: 0
Num of roam calls rejected since AP joined.....: 0
Num of calls rejected due to insufficient bw....: 0
Num of calls rejected due to invalid params....: 0
Num of calls rejected due to PHY rate.....: 0
Num of calls rejected due to QoS policy.....: 0

SIP CAC Call Stats
Total Num of calls in progress.....: 0
Num of roaming calls in progress.....: 0
Total Num of calls since AP joined.....: 0
Total Num of roaming calls since AP joined.....: 0
Total Num of Preferred calls received.....: 0
Total Num of Preferred calls accepted.....: 0
Total Num of ongoing Preferred calls.....: 0
Total Num of calls rejected(Insuff BW).....: 0
Total Num of roam calls rejected(Insuff BW)....: 0

Band Select Stats
Num of dual band client .....: 0
Num of dual band client added.....: 0
Num of dual band client expired .....: 0
Num of dual band client replaced.....: 0
Num of dual band client detected .....: 0
Num of suppressed client .....: 0
Num of suppressed client expired.....: 0
Num of suppressed client replaced.....: 0

```

This example show how to display the traffic stream configuration for all clients that correspond to a specific access point:

```
Controller# show ap name AP01 dot11 24ghz tsm all
```

show ap name dot11 cleanair

To display CleanAir configuration information that corresponds to an access point, use the **show ap name dot11 cleanair** command.

```
show ap name ap-name dot11 {24ghz|5ghz} cleanair {air-quality|device}
```

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.
24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.
cleanair	Displays CleanAir configuration information.
air-quality	Displays CleanAir air-quality (AQ) data.
device	Displays CleanAir interferers for an access point on the 5 GHz band.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display CleanAir air-quality information for an access point in the 802.11b network:

```
Controller# show ap name AP01 dot11 24ghz cleanair air-quality
```

```
AQ = Air Quality
DFS = Dynamic Frequency Selection
```

This example shows how to display CleanAir interferers information for an access point in the 802.11b network:

```
Controller# show ap name AP01 dot11 24ghz cleanair device
```

```
DC    = Duty Cycle (%)
ISI   = Interference Severity Index (1-Low Interference, 100-High Interference)
RSSI  = Received Signal Strength Index (dBm)
DevID = Device ID
```

```
No ClusterID DevID Type AP Name ISI RSSI DC Channel
-- -
```

show ap name ethernet statistics

To display the Ethernet statistics of a specific Cisco lightweight access point, use the **show ap name ethernet statistics** command.

show ap name *ap-name* ethernet statistics

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the Ethernet statistics of an access point:

```
Controller# show ap name 3602a ethernet statistics
```

```
Ethernet Stats for AP 3602a
```

Interface Name	Status	Speed	Rx Packets	Tx Packets	Discarded Packets

GigabitEthernet0	UP	1000 Mbps	3793	5036	0

show ap name eventlog

To download and display the event log of a specific Cisco lightweight access point, use the **show ap name eventlog** command.

show ap name *ap-name* **eventlog**

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.

Command Default	None
-----------------	------

Command Modes	Any command mode
---------------	------------------

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the event log for a specific access point:

```
Controller# show ap name AP01 eventlog
```

show ap name image

To display the detailed information about the predownloaded image for specified access points, use the **show ap name image** command.

show ap name *ap-name* image

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display images present on all access points:

```
Controller# show ap name 3602a image
```

```
Total number of APs : 1
```

```
Number of APs
  Initiated           : 0
  Predownloading      : 0
  Completed predownloading : 0
  Not Supported       : 1
  Failed to Predownload : 0
```

AP Name	Primary Image	Backup Image	Predownload Status	Predownload Ver...	Next
Retry Time	Retry Count				
3602a	10.0.1.234	0.0.0.0	Not supported	None	NA
		0			

show ap name inventory

To display inventory information for an access point, use the **show ap name inventory** command.

show ap name *ap-name* inventory

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display inventory information for an access point:

```
Controller# show ap name 3502b inventory
```

```
NAME: Cisco AP , DESCR: Cisco Wireless Access Point
PID: 1140AG , VID: V01, SN: SIM1140K001
```

```
NAME: , DESCR:
PID: , VID: , SN:
```

```
NAME: , DESCR:
PID: , VID: , SN:
NAME: Cisco AP , DESCR: Cisco Wireless Access Point
PID: 3502I , VID: V01, SN: FTX1525E94A
```

```
NAME: Dot11Radio0 , DESCR: 802.11N 2.4GHz Radio
PID: UNKNOWN, VID: , SN: FOC1522BLNA
```

```
NAME: Dot11Radio1 , DESCR: 802.11N 5GHz Radio
PID: UNKNOWN, VID: , SN: FOC1522BLNA
```

show ap name link-encryption

To display the link-encryption status for a specific Cisco lightweight access point, use the **show ap name link-encryption** command.

show ap name *ap-name* link-encryption

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the link-encryption status for a specific Cisco lightweight access point:

```
Controller# show ap name AP01 link-encryption
```

AP Name	Encryption State	Dnstream Count	Upstream Count	Last Update
AP01	Disabled	0	0	Never

show ap name service-policy

To display service-policy information for a specific Cisco lightweight access point, use the **show ap name service-policy** command.

show ap name *ap-name* **service-policy**

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display service-policy information for a specific Cisco lightweight access point:

```
Controller# show ap name 3502b service-policy
```

```
NAME: Cisco AP , DESCR: Cisco Wireless Access Point
PID: 3502I , VID: V01, SN: FTX1525E94A
```

```
NAME: Dot11Radio0 , DESCR: 802.11N 2.4GHz Radio
PID: UNKNOWN, VID: , SN: FOC1522BLNA
```

```
NAME: Dot11Radio1 , DESCR: 802.11N 5GHz Radio
PID: UNKNOWN, VID: , SN: FOC1522BLNA
```

show ap name tcp-adjust-mss

To display TCP maximum segment size (MSS) for an access point, use the **show ap name tcp-adjust-mss** command.

show ap name *ap-name* tcp-adjust-mss

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
----------------	---

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display TCP MSS for an access point:

```
Controller# show ap name AP01 tcp-adjust-mss
```

AP Name	TCP State	MSS Size
AP01	Disabled	6146

show ap name wlan

To display the Basic Service Set Identifier (BSSID) value for each WLAN defined on an access point and to display WLAN statistics, use the **show ap name wlan** command.

```
show ap name ap-name wlan {dot11 {24ghz|5ghz}| statistic}
```

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
dot11	Displays 802.11 parameters.
24ghz	Displays 802.11b network settings.
5ghz	Displays 802.11a network settings.
statistic	Displays WLAN statistics.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display BSSID information of an access point in an 802.11b network:

```
Controller# show ap name AP01 wlan dot11 24ghz

Site Name                : default-group
Site Description         :

WLAN ID  Interface  BSSID
-----
1        default    00:00:20:00:02:00
12       default    00:00:20:00:02:0b
```

This example shows how to display WLAN statistics for an access point:

```
Controller# show ap name AP01 wlan statistic

WLAN ID : 1
WLAN Profile Name : maria-open

EAP Id Request Msg Timeouts           : 0
EAP Id Request Msg Timeouts Failures  : 0
EAP Request Msg Timeouts               : 0
EAP Request Msg Timeouts Failures     : 0
EAP Key Msg Timeouts                   : 0
```

EAP Key Msg Timeouts Failures : 0

WLAN ID : 12

WLAN Profile Name : 24

EAP Id Request Msg Timeouts : 0

EAP Id Request Msg Timeouts Failures : 0

EAP Request Msg Timeouts : 0

EAP Request Msg Timeouts Failures : 0

EAP Key Msg Timeouts : 0

EAP Key Msg Timeouts Failures : 0

show ap slots

To display a slot summary of all connected Cisco lightweight access points, use the **show ap slots** command.

show ap slots

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display a slot summary of all connected Cisco lightweight access points:

```
Controller# show ap slots
```

AP Name	Slots	AP Model	Slot0	Slot1	Slot2	Slot3
3602a	2	3502I	802.11b/g	802.11a	Unknown	Unknown

show ap summary

To display the status summary of all Cisco lightweight access points attached to the controller, use the **show ap summary** command.

show ap summary

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use this command to display a list that contains each lightweight access point name, number of slots, manufacturer, MAC address, location, and the controller port number.

Examples

This example shows how to display a summary of all connected access points:

```
Controller# show ap summary
```

```
Number of APs: 1
```

```
Global AP User Name: Cisco
```

```
Global AP Dot1x User Name: Not configured
```

AP Name	AP Model	Ethernet MAC	Radio MAC	State
3602a	3502I	003a.99eb.3fa8	d0c2.8267.8b00	Registered

show ap tcp-adjust-mss

To display information about the Cisco lightweight access point TCP Maximum Segment Size (MSS), use the **show ap tcp-adjust-mss** command.

show ap tcp-adjust-mss

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display information about the access point TCP MSS information:

```
Controller# show ap tcp-adjust-mss
```

```
AP Name                TCP State      MSS Size
-----
3602a                  Disabled      0
```

show ap uptime

To display the up time of all connected Cisco lightweight access points, use the **show ap uptime** command.

show ap uptime

Syntax Description

This command has no keywords and arguments.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to the display up time of all connected access points:

```
Controller# show ap uptime
```

```
Number of APs : 1
```

```
Global AP User Name : Cisco
```

```
Global AP Dot1x User Name : Not configured
```

```
AP Name Ethernet MAC      AP Up Time                Association Up Time
-----
3602a  003a.99eb.3fa8  5 hours 13 minutes 40 seconds  5 hours 12 minutes 15 seconds
```

show wireless client ap

To display the clients on a Cisco lightweight access point, use the **show wireless client ap** command.

```
show wireless client ap [name ap-name] dot11 {24ghz| 5ghz}
```

Syntax Description

name <i>ap-name</i>	(Optional) Displays the name of the Cisco lightweight access point.
dot11	Displays 802.11 parameters.
24ghz	Displays the 2.4 GHz band.
5ghz	Displays the 5 GHz band.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **show client ap** command might list the status of automatically disabled clients. Use the **show exclusionlist** command to view clients on the exclusion list (blacklisted).

Examples

This example shows how to display client information on a specific Cisco lightweight access point in the 2.4 GHz band:

```
Controller# show wireless client ap name AP01 dot11 24ghz
MAC Address      AP Id  Status      WLAN Id  Authenticated
-----
xx:xx:xx:xx:xx:xx 1      Associated  1        No
```

test ap name

To enable automatic testing of the path Maximum Transmit Unit (MTU) between the access point and the controller, use the **test ap name** command.

test ap name *ap-name* **pmtu** {**disable size** *size*| **enable**}

Syntax Description

<i>ap-name</i>	Name of the target Cisco lightweight access point.
pmtu	Tests the MTU configuration for the access point.
disable	Disables path MTU testing and manually configures the MTU value in bytes.
size <i>size</i>	Specifies the path MTU size. Note The range is from 576 to 1700.
enable	Enables the path MTU testing for the access point.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to disable the path MTU configuration for all access points associated to the controller:

```
Controller# test ap name 3602a pmtu enable
```

test capwap ap name

To test Control and Provisioning of Wireless Access Points (CAPWAP) parameters for a specific Cisco lightweight access points, use the **test capwap ap name** command.

test capwap ap name *ap-name* {**encryption** {**enable**|**disable**}}| **message** *token*}

Syntax Description

<i>ap-name</i>	Name of the Cisco lightweight access point.
encryption	Tests the Datagram Transport Layer Security (DTLS) encryption.
enable	Tests if DTLS encryption is enabled.
disable	Tests if DTLS encryption is disabled.
message <i>token</i>	Specifies an RRM neighbor message to send.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to test if DTLS encryption is enabled for a specific access point:

```
Controller# test capwap ap name 3602a encryption enable
```

This example shows how to test if DTLS encryption is disabled for a specific access point:

```
Controller# test capwap ap name 3602a encryption disable
```

trapflags ap

To enable the sending of specific Cisco lightweight access point traps, use the **trapflags ap** command. To disable the sending of Cisco lightweight access point traps, use the **no** form of this command.

trapflags ap {register| interfaceup}

no trapflags ap {register| interfaceup}

Syntax Description

register	Enables sending a trap when a Cisco lightweight access point registers with a Cisco switch.
interfaceup	Enables sending a trap when a Cisco lightweight access point interface (A or B) comes up.

Command Default

Enabled

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to prevent traps from sending access point-related traps:

```
Controller(config)# no trapflags ap register
```



PART **XII**

CleanAir

- [CleanAir Commands, page 827](#)



CleanAir Commands

- [ap dot11 5ghz cleanair](#) , page 829
- [ap dot11 5ghz cleanair alarm air-quality](#), page 830
- [ap dot11 5ghz cleanair alarm device](#), page 831
- [default ap dot11 5ghz cleanair device](#), page 833
- [ap dot11 5ghz rrm channel cleanair-event](#), page 835
- [ap dot11 5ghz rrm channel device](#), page 836
- [ap dot11 24ghz cleanair](#), page 837
- [ap dot11 24ghz cleanair alarm air-quality](#), page 838
- [ap dot11 24ghz cleanair alarm device](#), page 839
- [default ap dot11 24ghz cleanair device](#), page 841
- [ap dot11 24ghz rrm channel cleanair-event](#), page 843
- [ap dot11 24ghz rrm channel device](#), page 844
- [ap name mode se-connect](#), page 845
- [default ap dot11 5ghz cleanair device](#), page 846
- [default ap dot11 5ghz rrm channel cleanair-event](#), page 848
- [default ap dot11 5ghz rrm channel device](#), page 849
- [default ap dot11 24ghz cleanair alarm device](#), page 850
- [default ap dot11 24ghz cleanair device](#), page 852
- [default ap dot11 24ghz rrm channel cleanair-event](#), page 854
- [show ap dot11 5ghz cleanair air-quality summary](#), page 855
- [show ap dot11 5ghz cleanair air-quality worst](#), page 856
- [show ap dot11 5ghz cleanair config](#), page 857
- [show ap dot11 5ghz cleanair device type](#), page 859
- [show ap dot11 24ghz cleanair air-quality summary](#), page 861

- [show ap dot11 24ghz cleanair air-quality worst](#), page 862
- [show ap dot11 24ghz cleanair config](#), page 863
- [show ap dot11 24ghz cleanair summary](#), page 865

ap dot11 5ghz cleanair

To enable CleanAir for detecting 5-GHz devices, use the **ap dot11 5ghz cleanair** command in global configuration mode.

ap dot11 5ghz cleanair

Command Default

Disabled.

Command Modes

Global configuration.

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must enable this CleanAir command before you configure other CleanAir commands.

Examples

This example shows how to enable CleanAir for 5-GHz devices:

```
Controller(config)# ap dot11 5ghz cleanair
```

ap dot11 5ghz cleanair alarm air-quality

To configure the alarm when the Air Quality (AQ) reaches the threshold value for the 5-GHz devices, use the **ap dot11 5ghz cleanair alarm air-quality** command. To disable the alarm when the AQ reaches the threshold value for the 5-GHz devices, use the **no** form of this command.

ap dot11 5ghz cleanair alarm air-quality threshold *threshold _value*

Syntax Description

threshold <i>threshold _value</i>	Configures the threshold value for air quality. The range is from 1 to 100.
--	---

Command Default

The default threshold value for AQ is 10.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must enable CleanAir using the **ap dot11 5ghz cleanair** command before you configure this command.

Examples

This example shows how to set the threshold value for the AQ:

```
Controller(config)# ap dot11 5ghz cleanair alarm air-quality threshold 30
```

ap dot11 5ghz cleanair alarm device

To configure the alarm for the 5-GHz interference devices, use the **ap dot11 5ghz cleanair alarm device** command.

ap dot11 5ghz cleanair alarm device {**canopy** | **cont-tx** | **dect-like** | **inv** | **jammer** | **nonstd** | **radar** | **superag** | **tdd-tx** | **video** | **wimax-fixed** | **wimax-mobile**}

Syntax Description

canopy	Configures the alarm for canopy interference devices.
cont-tx	Configures the alarm for continuous transmitters.
dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
jammer	Configures the alarm for jammer interference devices.
nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
radar	Configures the alarm for radars.
superag	Configures the alarm for 802.11 SuperAG interference devices.
tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
video	Configures the alarm for video cameras.
wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.

Command Default

The alarm for Wi-Fi inverted devices is enabled and for all other interference devices is disabled.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must enable CleanAir using the **ap dot11 5ghz cleanair** command before you configure this command.

Examples

This example shows how to enable the alarm to notify interferences from a radar device:

```
Controller(config)# ap dot11 5ghz cleanair alarm device radar
```

default ap dot11 5ghz cleanair device

To configure the default state of the alarm for 5-GHz interference devices, use the **default ap dot11 5ghz cleanair device** command in global configuration mode.

default ap dot11 5ghz cleanair device {**canopy** | **cont-tx** | **dect-like** | **inv** | **jammer** | **nonstd** | **radar** | **report** | **superag** | **tdd-tx** | **video** | **wimax-fixed** | **wimax-mobile**}

Syntax Description

canopy	Configures the alarm for canopy interference devices.
cont-tx	Configures the alarm for continuous transmitters.
dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
jammer	Configures the alarm for jammer interference devices.
nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
radar	Configures the alarm for radars.
report	Enables interference device reports.
superag	Configures the alarm for 802.11 SuperAG interference devices.
tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
video	Configures the alarm for video cameras.
wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.

Command Default

The alarm for Wi-Fi inverted devices is enabled. The alarm for all other interference devices is disabled.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must enable CleanAir using the **ap dot11 5ghz cleanair** command before you configure this command.

Examples

This example shows how to enable CleanAir to report when a video camera interferes:

```
Controller(config)# default ap dot11 5ghz cleanair device video
```

ap dot11 5ghz rrm channel cleanair-event

To enable Event-Driven RRM (EDRRM) and configure the sensitivity for 5-GHz devices, use the **ap dot11 5ghz rrm channel cleanair-event** command in global configuration mode. To disable EDRRM, use the **no** form of the command.

ap dot11 5ghz rrm channel cleanair-event [sensitivity {high| low| medium}]

no ap dot11 5ghz rrm channel cleanair-event [sensitivity {high| low| medium}]

Syntax Description

sensitivity	(Optional) Configures the EDRRM sensitivity of the CleanAir event.
high	(Optional) Specifies the highest sensitivity to non-Wi-Fi interference as indicated by the air quality (AQ) value.
low	(Optional) Specifies the least sensitivity to non-Wi-Fi interference as indicated by the AQ value.
medium	(Optional) Specifies medium sensitivity to non-Wi-Fi interference as indicated by the AQ value.

Command Default

EDRRM is disabled and the EDRRM sensitivity is low.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must enable EDRRM using the **ap dot11 5ghz rrm channel cleanair-event** command before you configure the sensitivity.

Examples

This example shows how to enable EDRRM and set the EDRRM sensitivity to high:

```
Controller(config)# ap dot11 5ghz rrm channel cleanair-event
Controller(config)# ap dot11 5ghz rrm channel cleanair-event sensitivity high
```

ap dot11 5ghz rrm channel device

To configure persistent non-Wi-Fi device avoidance in the 802.11a channel, use the **ap dot11 5ghz rrm channel device** command in global configuration mode. To disable persistent device avoidance, use the **no** form of this command.

ap dot11 5ghz rrm channel device

no ap dot11 5ghz rrm channel device

Syntax Description This command has no arguments or keywords.

Command Default The CleanAir persistent device state is disabled.

Command Modes Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines CleanAir-capable monitor mode access points collect information about persistent devices on all configured channels and stores the information in the controller. Local and bridge mode access points detect interference devices on the serving channels only.

Examples This example shows how to enable persistent device avoidance on 802.11a devices:

```
Controller(config)# ap dot11 5ghz rrm channel device
```

ap dot11 24ghz cleanair

To enable CleanAir for detecting 2.4-GHz devices, use the **ap dot11 24ghz cleanair** command in global configuration mode. To disable CleanAir for detecting 2.4-GHz devices, use the **no** form of this command.

ap dot11 24ghz cleanair

Syntax Description This command has no arguments or keywords.

Command Default Disabled.

Command Modes Global configuration (config).

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You must enable this CleanAir command before you configure other CleanAir commands.

Examples This example shows how to enable CleanAir for 2.4-GHz devices:

```
Controller(config)# ap dot11 24ghz cleanair
```

ap dot11 24ghz cleanair alarm air-quality

To configure the alarm for the threshold value of Air Quality (AQ) for all 2.4-GHz devices, use the **ap dot11 24ghz cleanair alarm air-quality** command in global configuration mode. To disable the alarm for the threshold value of AQ for all 2.4-GHz devices, use the **no** form of this command.

ap dot11 24ghz cleanair alarm air-quality threshold *threshold_value*

Syntax Description

threshold <i>threshold_value</i>	Configures the threshold value for AQ. The range is from 1 to 100.
---	--

Command Default

The default threshold value for AQ is 10.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must enable CleanAir using the **ap dot11 24ghz cleanair** command before you configure this command.

Examples

This example shows how to set the threshold value for the AQ:

```
Controller(config)# ap dot11 24ghz cleanair alarm air-quality threshold 50
```

ap dot11 24ghz cleanair alarm device

To configure the alarm for the 2.4-GHz interference devices, use the **ap dot11 24ghz cleanair alarm device** command in global configuration mode. To disable the alarm for the 2.4-GHz interference devices, use the **no** form of this command.

ap dot11 24ghz cleanairalarm {**device** | **bt-discovery** | **bt-link canopy**| **cont-tx** | **dect-like** | **fh** | **inv** | **jammer** | **mw-oven** | **nonstd** | **superag** | **tdd-tx video** | **wimax-fixed** | **wimax-mobile** | **xbox** | **zigbee**}

Syntax Description

bt-discovery	Configures the alarm for Bluetooth interference devices.
bt-link	Configures the alarm for any Bluetooth link.
canopy	Configures the alarm for canopy interference devices.
cont-tx	Configures the alarm for continuous transmitters.
dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
fh	Configures the alarm for 802.11 frequency hopping (FH) devices.
inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
jammer	Configures the alarm for jammer interference devices.
mw-oven	Configures the alarm for microwave ovens.
nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
superag	Configures the alarm for 802.11 SuperAG interference devices.
tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
video	Configures the alarm for video cameras.
wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.
xbox	Configures the alarm for Xbox interference devices.
zigbee	Configures the alarm for 802.15.4 interference devices.

Command Default

The alarm for Wi-Fi inverted devices is enabled. The alarm for all other devices is disabled.

Command Modes Global configuration (config).

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You must enable CleanAir using the **ap dot11 24ghz cleanair** command before you configure this command.

Examples This example shows how to enable the alarm to notify interferences from a Zigbee device:

```
Controller(config)# ap dot11 24ghz cleanair alarm device zigbee
```

default ap dot11 24ghz cleanair device

To configure the default state of report generation for 2.4-GHz interference devices, use the **default ap dot11 24ghz cleanair device** command in global configuration mode.

```
default ap dot11 24ghz cleanair device {bt-discovery | bt-link | canopy | cont-tx | dect-like | fh | inv |
jammer | mw-oven | nonstd | report | superag | tdd-tx | video | wimax-fixed | wimax-mobile | xbox |
zigbee}
```

Syntax Description

bt-discovery	Configures the alarm for Bluetooth interference devices.
bt-link	Configures the alarm for any Bluetooth link.
canopy	Configures the alarm for canopy interference devices.
cont-tx	Configures the alarm for continuous transmitters.
dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
fh	Configures the alarm for 802.11 frequency hopping devices.
inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
jammer	Configures the alarm for jammer interference devices.
mw-oven	Configures the alarm for microwave ovens.
nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
superag	Configures the alarm for 802.11 SuperAG interference devices.
tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
video	Configures the alarm for video cameras.
wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.
xbox	Configures the alarm for Xbox interference devices.
zigbee	Configures the alarm for 802.15.4 interference devices.

Command Default

The alarm for Wi-Fi inverted devices is enabled. The alarm for all other devices is disabled.

Command Modes Global configuration (config).

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You must enable CleanAir using the **ap dot11 24ghz cleanair** command before you configure this command.

Examples This example shows how to enable CleanAir to report when a video camera interferes:

```
Controller(config)# default ap dot11 24ghz cleanair device video
```

ap dot11 24ghz rrm channel cleanair-event

To enable Event-Driven RRM (EDRRM) and the sensitivity for 2.4-GHz devices, use the **ap dot11 24ghz rrm channel cleanair-event** command in global configuration mode. To disable EDRRM, use the **no** form of this command.

ap dot11 24ghz rrm channel cleanair-event sensitivity {high | low | medium}

no ap dot11 24ghz rrm channel cleanair-event [sensitivity {high | low | medium}]

Syntax Description

sensitivity	(Optional) Configures the EDRRM sensitivity of the CleanAir event.
high	(Optional) Specifies the highest sensitivity to non-Wi-Fi interference as indicated by the air quality (AQ) value.
low	(Optional) Specifies the least sensitivity to non-Wi-Fi interference as indicated by the AQ value.
medium	(Optional) Specifies medium sensitivity to non-Wi-Fi interference as indicated by the AQ value.

Command Default

EDRRM is disabled and the sensitivity is low.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must enable EDRRM using the **ap dot11 24ghz rrm channel cleanair-event** command before you configure the sensitivity.

Examples

This example shows how to enable EDRRM and set the EDRRM sensitivity to low:

```
Controller(config)# ap dot11 24ghz rrm channel cleanair-event
Controller(config)# ap dot11 24ghz rrm channel cleanair-event sensitivity low
```

ap dot11 24ghz rrm channel device

To configure persistent non-Wi-Fi device avoidance in the 802.11b channel, use the **ap dot11 24ghz rrm channel device** command in global configuration mode. To disable persistent device avoidance, use the **no** form of this command.

ap dot11 24ghz rrm channel device

no ap dot11 24ghz rrm channel device

Syntax Description This command has no arguments or keywords.

Command Default Persistent device avoidance is disabled.

Command Modes Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

CleanAir-capable monitor mode access points collect information about persistent devices on all configured channels and stores the information in the controller. Local and bridge mode access points detect interference devices on the serving channels only.

Examples

This example shows how to enable persistent device avoidance:

```
Controller(config)# ap dot11 24ghz rrm channel device
```

ap name mode se-connect

To configure the access point for SE-Connect mode, use the **ap name *ap_name* mode se-connect** command in privileged exec mode.

ap name *ap_name* mode se-connect

Syntax Description

<i>ap_name</i>	Name of the access point.
----------------	---------------------------

Command Default

No access point is configured for SE-Connect mode.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The access point will reboot after you change the mode.

SE-connect mode enables a user to connect a Spectrum Expert application running on an external Microsoft Windows XP or Vista PC to a Cisco CleanAir-enabled access point in order to display and analyze detailed spectrum data. The Spectrum Expert application connects directly to the access point, by passing the controller. An access point in SE-Connect mode does not provide any Wi-Fi, RF, or spectrum data to the controller. All CleanAir system functionality is suspended while the AP is in this mode, and no clients are served. This mode is intended for remote troubleshooting only.

Examples

This example shows how to change the mode of the access point to SE-Connect:

```
Controller# ap name AS-5508-5-AP3 mode se-connect
```

```
Changing the AP's mode will cause the AP to reboot.
```

```
Are you sure you want to continue? (y/n)[y]: y
```

```
% switch-1:wcm: Cisco AP does not support the seconnect mode
```

default ap dot11 5ghz cleanair device

To configure the default state of the alarm for 5-GHz interference devices, use the **default ap dot11 5ghz cleanair device** command in global configuration mode.

default ap dot11 5ghz cleanair device {canopy | cont-tx | dect-like | inv | jammer | nonstd | radar | report | superag | tdd-tx | video | wimax-fixed | wimax-mobile}

Syntax Description

canopy	Configures the alarm for canopy interference devices.
cont-tx	Configures the alarm for continuous transmitters.
dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
jammer	Configures the alarm for jammer interference devices.
nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
radar	Configures the alarm for radars.
report	Enables interference device reports.
superag	Configures the alarm for 802.11 SuperAG interference devices.
tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
video	Configures the alarm for video cameras.
wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.

Command Default

The alarm for Wi-Fi inverted devices is enabled. The alarm for all other interference devices is disabled.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must enable CleanAir using the **ap dot11 5ghz cleanair** command before you configure this command.

Examples

This example shows how to enable CleanAir to report when a video camera interferes:

```
Controller(config)# default ap dot11 5ghz cleanair device video
```

default ap dot11 5ghz rrm channel cleanair-event

To configure the default state of Event-Driven radio resource management (EDRRM) and the EDRRM sensitivity for 5-GHz devices, use the **default ap dot11 5ghz rrm channel cleanair-event** command in global configuration mode.

default ap dot11 5ghz rrm channel cleanair-event [sensitivity {high | low | medium}]

Syntax Description

sensitivity	(Optional) Configures the EDRRM sensitivity of the CleanAir event.
high	(Optional) Specifies the highest sensitivity to non-Wi-Fi interference as indicated by the Air Quality (AQ) value.
low	(Optional) Specifies the least sensitivity to non-Wi-Fi interference as indicated by the AQ value.
medium	(Optional) Specifies medium sensitivity to non-Wi-Fi interference as indicated by the AQ value.

Command Default

EDRRM is disabled and the sensitivity is low.

Command Modes

Global configuration (config).

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must enable EDRRM before you configure the sensitivity.

Examples

This example shows how to set the default EDRRM state and sensitivity:

```
Controller(config)# default ap dot11 5ghz rrm channel cleanair-event
Controller(config)# default ap dot11 5ghz rrm channel cleanair-event sensitivity
```

default ap dot11 5ghz rrm channel device

To configure the default state of the persistent non-Wi-Fi device avoidance in the 802.11a channels, use the **default ap dot11 5ghz rrm channel device** command in global configuration mode.

default ap dot11 5ghz rrm channel device

Syntax Description This command has no arguments or keywords.

Command Default Persistent device state is disabled.

Command Modes Global configuration (config)

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Examples This example shows how to configure persistent non-Wi-Fi device avoidance in the 802.11a channels:

```
Controller(config)# default ap dot11 5ghz rrm channel device
```

default ap dot11 24ghz cleanair alarm device

To configure the default value of the alarm for 2.4-GHz interference devices, use the **default ap dot11 24ghz cleanair alarm device** command in global configuration mode.

default ap dot11 24ghz cleanair alarm device {**bt-discovery** | **bt-link** | **canopy** | **cont-tx** | **dect-like** | **fh** | **inv** | **jammer** | **mw-oven** | **nonstd** | **superag** | **tdd-tx** | **video** | **wimax-fixed** | **wimax-mobile** | **xbox** | **zigbee**}

Syntax Description

bt-discovery	Configures the alarm for Bluetooth interference devices.
bt-link	Configures the alarm for any Bluetooth link.
canopy	Configures the alarm for canopy interference devices.
cont-tx	Configures the alarm for continuous transmitters.
dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
fh	Configures the alarm for 802.11 frequency hopping (FH) devices.
inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
jammer	Configures the alarm for jammer interference devices.
mw-oven	Configures the alarm for microwave ovens.
nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
superag	Configures the alarm for 802.11 SuperAG interference devices.
tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
video	Configures the alarm for video cameras.
wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.
xbox	Configures the alarm for Xbox interference devices.
zigbee	Configures the alarm for 802.15.4 interference devices.

Command Default

The alarm for Wi-Fi inverted devices is enabled. The alarm for all the other devices is disabled.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

You must enable CleanAir using the **ap dot11 24ghz cleanair** command before you configure this command.

Examples

This example shows how to configure the default CleanAir 2.4-GHz interference devices alarm:

```
Controller(config)# default ap dot11 24ghz cleanair alarm device inv
```

default ap dot11 24ghz cleanair device

To configure the default state of report generation for 2.4-GHz interference devices, use the **default ap dot11 24ghz cleanair device** command in global configuration mode.

```
default ap dot11 24ghz cleanair device {bt-discovery | bt-link | canopy | cont-tx | dect-like | fh | inv | jammer | mw-oven | nonstd | report | superag | tdd-tx | video | wimax-fixed | wimax-mobile | xbox | zigbee}
```

Syntax Description

bt-discovery	Configures the alarm for Bluetooth interference devices.
bt-link	Configures the alarm for any Bluetooth link.
canopy	Configures the alarm for canopy interference devices.
cont-tx	Configures the alarm for continuous transmitters.
dect-like	Configures the alarm for Digital Enhanced Cordless Communication (DECT)-like phones.
fh	Configures the alarm for 802.11 frequency hopping devices.
inv	Configures the alarm for devices using spectrally inverted Wi-Fi signals.
jammer	Configures the alarm for jammer interference devices.
mw-oven	Configures the alarm for microwave ovens.
nonstd	Configures the alarm for devices using nonstandard Wi-Fi channels.
superag	Configures the alarm for 802.11 SuperAG interference devices.
tdd-tx	Configures the alarm for Time Division Duplex (TDD) transmitters.
video	Configures the alarm for video cameras.
wimax-fixed	Configures the alarm for WiMax fixed interference devices.
wimax-mobile	Configures the alarm for WiMax mobile interference devices.
xbox	Configures the alarm for Xbox interference devices.
zigbee	Configures the alarm for 802.15.4 interference devices.

Command Default

The alarm for Wi-Fi inverted devices is enabled. The alarm for all other devices is disabled.

Command Modes Global configuration (config).

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You must enable CleanAir using the **ap dot11 24ghz cleanair** command before you configure this command.

Examples This example shows how to enable CleanAir to report when a video camera interferes:

```
Controller(config)# default ap dot11 24ghz cleanair device video
```

default ap dot11 24ghz rrm channel cleanair-event

To configure the default Event-Driven radio resource management (EDRRM) state and sensitivity for 2.4-GHz devices, use the **default ap dot11 24ghz rrm channel cleanair-event** command in global configuration mode.

default ap dot11 24ghz rrm channel cleanair-event [sensitivity {high | low | medium}]

Syntax Description

sensitivity	Configures the EDRRM sensitivity of the CleanAir event.
high	Specifies the highest sensitivity to non-Wi-Fi interference as indicated by the Air Quality (AQ) value.
low	Specifies the least sensitivity to non-Wi-Fi interference as indicated by the AQ value.
medium	Specifies medium sensitivity to non-Wi-Fi interference as indicated by the AQ value.

Command Default

EDRRM is disabled and the sensitivity is low.

Command Modes

Global configuration (config)

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to enable EDRRM and set the default EDRRM sensitivity:

```
Controller(config)# default ap dot11 24ghz rrm channel cleanair-event
Controller(config)# default ap dot11 24ghz rrm channel cleanair-event sensitivity
```

show ap dot11 5ghz cleanair air-quality summary

To display the CleanAir AQ data for 5-GHz band, use the **show ap dot11 5ghz cleanair air-quality summary** command in user EXEC mode or privileged EXEC mode.

show ap dot11 5ghz cleanair air-quality summary

This command has no arguments or keywords.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the CleanAir AQ data for 5-GHz band:

```
Controller# show ap dot11 5ghz cleanair air-quality summary
```

AQ = Air Quality

DFS = Dynamic Frequency Selection

AP Name	Channel	Avg AQ	Min AQ	Interferers	DFS
AP270ca.9b86.4546	1	99	99	0	No
AP2894.0f26.22df	6	98	97	0	No
AP2894.0f58.cc6b	11	99	99	0	No
AP2894.0f39.1040	6	97	97	0	No
AP2894.0f63.c6da	11	99	99	0	No
AP2894.0f58.d013	6	97	97	0	No

show ap dot11 5ghz cleanair air-quality worst

To display the worst AQ data for 5-GHz band, use the **show ap dot11 5ghz cleanair air-quality worst** command in user EXEC mode or privileged EXEC mode.

show ap dot11 5ghz cleanair air-quality worst

This command has no arguments or keywords.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the worst AQ data for 5-GHz band:

```
Controller# show ap dot11 5ghz cleanair air-quality worst
```

AQ = Air Quality

DFS = Dynamic Frequency Selection

AP Name	Channel	Avg AQ	Min AQ	Interferers	DFS
AP2894.0f39.1040	6	97	97	0	No

show ap dot11 5ghz cleanair config

To display the CleanAir configuration for 5-GHz band, use the **show ap dot11 5ghz cleanair config** command.

show ap dot11 5ghz cleanair config

This command has no arguments or keywords.

Command Modes	User EXEC (>) Privileged EXEC (#)
----------------------	--------------------------------------

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines In Release 3.3SE, you can configure this command on the Mobility Agent (MA).

Examples This example shows how to display the CleanAir configuration for 5-GHz band on the Mobility Controller:

```

Controller# show ap dot11 5ghz cleanair config

CleanAir Solution..... : Enabled
Air Quality Settings:
  Air Quality Reporting..... : Enabled
  Air Quality Reporting Period (min)..... : 15
  Air Quality Alarms..... : Enabled
  Air Quality Alarm Threshold..... : 1
Interference Device Settings:
  Interference Device Reporting..... : Enabled
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
Interference Device Types Triggering Alarms:
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
Interference Device Alarms..... : Enabled
Additional CleanAir Settings:
  CleanAir Event-driven RRM State..... : Enabled
  CleanAir Driven RRM Sensitivity..... : HIGH

```

```
CleanAir Persistent Devices state..... : Enabled
```

This example shows how to display the CleanAir configuration for 5-GHz band on the Mobility Agent:

```
Controller# show ap dot11 5ghz cleanair config

Mobility Controller Link Status..... : UP
CleanAir Solution..... : Enabled
Air Quality Settings:
  Air Quality Reporting..... : Enabled
  Air Quality Reporting Period (min)..... : 15
  Air Quality Alarms..... : Enabled
  Air Quality Alarm Threshold..... : 10
Interference Device Settings:
  Interference Device Reporting..... : Enabled
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
  Interference Device Types Triggering Alarms:
    TDD Transmitter..... : Disabled
    Jammer..... : Disabled
    Continuous Transmitter..... : Disabled
    DECT-like Phone..... : Disabled
    Video Camera..... : Disabled
    WiFi Inverted..... : Enabled
    WiFi Invalid Channel..... : Enabled
    SuperAG..... : Enabled
    Canopy..... : Disabled
    WiMax Mobile..... : Disabled
    WiMax Fixed..... : Disabled
  Interference Device Alarms..... : Enabled
Additional CleanAir Settings:
  CleanAir Event-driven RRM State..... : Disabled
  CleanAir Driven RRM Sensitivity..... : LOW
  CleanAir Persistent Devices state..... : Disabled
```

show ap dot11 5ghz cleanair device type

To display the 5-GHz interference devices, use the **show ap dot11 5ghz cleanair device type** command.

show ap dot11 5ghz cleanair device type {all | canopy | cont-tx | dect-like | inv | jammer | nonstd | persistent | superag | tdd-tx | video | wimax-fixed | wimax-mobile}

Syntax Description

all	Displays all CleanAir interferer devices for 5-GHz band.
canopy	Displays CleanAir interferers of type canopy for 5-GHz band.
cont-tx	Displays CleanAir interferers of type continuous transmitter for 5-GHz band.
dect-like	Displays CleanAir interferers of type Digital Enhanced Cordless Communication (DECT)-like phone for 5-GHz band.
inv	Displays CleanAir interferer devices using spectrally inverted WiFi signals for 5-GHz band.
jammer	Displays CleanAir interferers of type jammer for 5-GHz band.
nonstd	Displays CleanAir interferer devices using non-standard Wi-Fi channels for 5-GHz band.
persistent	Displays CleanAir persistent device interferers for 5-GHz band.
superag	Displays CleanAir interferers of type SuperAG for 5-GHz band.
tdd-tx	Displays CleanAir Time Division Duplex (TDD) transmitters for 5-GHz band.
video	Displays CleanAir interferers of type video camera for 5-GHz band.
wimax-fixed	Displays CleanAir interferers of type WiMax fixed for 5-GHz band.
wimax-mobile	Displays CleanAir interferers of type WiMax mobile for 5-GHz band.

Command Modes

User EXEC (>)
Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Interference devices are listed only if there is an interference from any 5-GHz devices.

Examples

This example shows how to view all the 5-GHz interference devices:

```
Controller# show ap dot11 5ghz cleanair device type all
```

```
DC      = Duty Cycle (%)
```

```
ISI     = Interference Severity Index (1-Low Interference, 100-High Interference)
```

```
RSSI    = Received Signal Strength Index (dBm)
```

```
DevID   = Device ID
```

```
No      ClusterID      DevID  Type      AP Name      ISI  RSSI  DC
Channel
```

show ap dot11 24ghz cleanair air-quality summary

To display the CleanAir AQ data for 2.4-GHz band, use the **show ap dot11 24ghz cleanair air-quality summary** command in user EXEC mode or privileged EXEC mode.

show ap dot11 24ghz cleanair air-quality summary

This command has no arguments or keywords.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the CleanAir AQ data for 2.4-GHz band:

```
Controller# show ap dot11 24ghz cleanair air-quality summary
```

AQ = Air Quality

DFS = Dynamic Frequency Selection

AP Name	Channel	Avg AQ	Min AQ	Interferers	DFS
AP270ca.9b86.4546	1	99	99	0	No
AP2894.0f26.22df	6	98	97	0	No
AP2894.0f58.cc6b	11	99	99	0	No
AP2894.0f39.1040	6	97	97	0	No
AP2894.0f63.c6da	11	99	99	0	No

show ap dot11 24ghz cleanair air-quality worst

To display the worst air quality data for 2.4-GHz band, use the **show ap dot11 24ghz cleanair air-quality worst** command in user EXEC mode or privileged EXEC mode.

show ap dot11 24ghz cleanair air-quality worst

This command has no arguments or keywords.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display the worst AQ data for 2.4-GHz band:

```
Controller# show ap dot11 24ghz cleanair air-quality worst
```

AQ = Air Quality

DFS = Dynamic Frequency Selection

AP Name	Channel	Avg AQ	Min AQ	Interferers	DFS
AP2895.0f39.1040	6	97	97	0	No

show ap dot11 24ghz cleanair config

To display the CleanAir configuration for 2.4-GHz band, use the **show ap dot11 24ghz cleanair config** command in user EXEC mode or privileged EXEC mode.

show ap dot11 24ghz cleanair config

This command has no arguments or keywords.

Command Modes	User EXEC (>) Privileged EXEC (#)
----------------------	--------------------------------------

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines In Release 3.3SE, you can configure this command on the Mobility Agent (MA).

Examples This example shows how to display the CleanAir configuration for 2.4-GHz band on the Mobility Controller:

```

Controller# show ap dot11 24ghz cleanair config

CleanAir Solution..... : Enabled
Air Quality Settings:
  Air Quality Reporting..... : Enabled
  Air Quality Reporting Period (min)..... : 15
  Air Quality Alarms..... : Enabled
  Air Quality Alarm Threshold..... : 1
Interference Device Settings:
  Interference Device Reporting..... : Enabled
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
Interference Device Types Triggering Alarms:
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
Interference Device Alarms..... : Enabled
Additional CleanAir Settings:

```

```

CleanAir Event-driven RRM State..... : Enabled
CleanAir Driven RRM Sensitivity..... : HIGH
CleanAir Persistent Devices state..... : Enabled

```

This example shows how to display the CleanAir configuration for 2.4-GHz band on the Mobility Agent:

```

Controller# show ap dot11 24ghz cleanair config

Mobility Controller Link Status..... : UP
CleanAir Solution..... : Enabled
Air Quality Settings:
  Air Quality Reporting..... : Enabled
  Air Quality Reporting Period (min)..... : 15
  Air Quality Alarms..... : Enabled
  Air Quality Alarm Threshold..... : 10
Interference Device Settings:
  Interference Device Reporting..... : Enabled
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
Interference Device Types Triggering Alarms:
  TDD Transmitter..... : Disabled
  Jammer..... : Disabled
  Continuous Transmitter..... : Disabled
  DECT-like Phone..... : Disabled
  Video Camera..... : Disabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Disabled
  WiMax Mobile..... : Disabled
  WiMax Fixed..... : Disabled
Interference Device Alarms..... : Enabled
Additional CleanAir Settings:
  CleanAir Event-driven RRM State..... : Disabled
  CleanAir Driven RRM Sensitivity..... : LOW
  CleanAir Persistent Devices state..... : Disabled

```

show ap dot11 24ghz cleanair summary

To display a summary of 2.4-GHz CleanAir devices, use the **show ap dot11 24ghz cleanair summary** command in user EXEC mode or privileged EXEC mode.

show ap dot11 24ghz cleanair summary

This command has no arguments or keywords.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

This is an example of output from the **show ap dot11 24ghz cleanair summary** command:

```
Controller# show ap dot11 24ghz cleanair summary
```

AP Name Spectrum Oper State	MAC Address	Slot ID	Spectrum Capable	Spectrum Intelligence
AP1cdf.0f95.1719 Down	0817.35c7.1a60	0	Disabled	Disabled
AS-5508-5-AP3 Down	0817.35dd.9f40	0	Disabled	Disabled
AP270ca.9b86.4546 Up	0c85.259e.c350	0	Enabled	Enabled
AP2894.0f26.22df Up	0c85.25ab.cca0	0	Enabled	Enabled
AP2894.0f58.cc6b Up	0c85.25c7.b7a0	0	Enabled	Enabled
AP2894.0f39.1040 Up	0c85.25de.2c10	0	Enabled	Enabled
AP2894.0f63.c6da Up	0c85.25de.c8e0	0	Enabled	Enabled



PART XIII

Mobility

- [Mobility Commands, page 869](#)



Mobility Commands

- [mobility anchor, page 870](#)
- [wireless mobility, page 872](#)
- [wireless mobility group keepalive, page 873](#)
- [wireless mobility group member ip, page 874](#)
- [wireless mobility group name , page 875](#)
- [wireless mobility oracle ip, page 876](#)
- [show wireless mobility, page 877](#)
- [clear wireless mobility statistics, page 879](#)

mobility anchor

To configure mobility sticky anchoring, use the **mobility anchor sticky** command. To disable the sticky anchoring, use the **no** form of the command.

To configure guest anchoring, use the **mobility anchor ip-address** command.

To delete the guest anchor, use the **no** form of the command.

To configure the device as an auto-anchor, use the **mobility anchor** command.

mobility anchor {*ip-address*| **sticky**}

no mobility anchor {*ip-address*| **sticky** }

Syntax Description

sticky	The client is anchored to the first switch that it associates. Note This command is by default enabled and ensures low roaming latency. This ensures that the point of presence for the client does not change when the client joins the mobility domain and roams within the domain.
<i>ip-address</i>	Configures the IP address for the guest anchor controller to this WLAN.

Command Default

Sticky configuration is enabled by default.

Command Modes

WLAN Configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.
Cisco IOS XE 3.3SE	The auto-anchor configuration required the device IP address to be entered prior to the Cisco IOS XE 3.3SE release; with this release, if no IP address is given, the device itself becomes an anchor; you do not have to explicitly specify the IP address.

Usage Guidelines

- The wlan_id or guest_lan_id must exist and be disabled.
- Auto-anchor mobility is enabled for the WLAN or wired guest LAN when you configure the first mobility anchor.
- Deleting the last anchor disables the auto-anchor mobility feature and resumes normal mobility for new associations.
- Mobility uses the following ports, that are allowed through the firewall:
 - 16666

- 16667
- 16668

Examples

This example shows how to enable the sticky mobility anchor:

```
Controller(config-wlan)# mobility anchor sticky
```

This example shows how to configure guest anchoring:

```
Controller(config-wlan)# mobility anchor 209.165.200.224
```

This example shows how to configure the device as an auto-anchor:

```
Controller(config-wlan)# mobility anchor
```

wireless mobility

To configure the intercontroller mobility manager, use the **wireless mobility** command.

wireless mobility {*dscp value*}

Syntax Description

dscp <i>value</i>	Configures the Mobility intercontroller DSCP value.
--------------------------	---

Command Default

The default DSCP value is 48.

Command Modes

Global Configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure mobility intercontroller DSCP with an value of 20:

```
Controller(config)# wireless mobility dscp 20
```

wireless mobility group keepalive

To configure the mobility group parameter and keep alive its ping parameters, use the **wireless mobility group keepalive** command. To remove a mobility group parameter, use the **no** form of the command.

wireless mobility group keepalive {**count** *number* | **interval** *interval*}

no wireless mobility group keepalive {**count** *number* | **interval** *interval*}

Syntax Description

count <i>number</i>	Number of times that a ping request is sent to a mobility group member before the member is considered unreachable. The range is from 3 to 20. The default is 3.
interval <i>interval</i>	Interval of time between each ping request sent to a mobility group member. The range is from 1 to 30 seconds. The default value is 10 seconds.

Command Default

3 seconds for count and 10 seconds for interval.

Command Modes

Global Configuration.

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The default values for *interval* is ten seconds and the default for *retries* is set to three.

Examples

This example shows how to specify the amount of time between each ping request sent to a mobility group member to 10 seconds:

```
Controller(config)# wireless mobility group keepalive count 10
```

wireless mobility group member ip

To add or delete users from mobility group member list, use the **wireless mobility group member ip** command. To remove a member from the mobility group, use the **no** form of the command.

wireless mobility group member ip *ip-address* [**public-ip** *public-ip-address*] [**group** *group-name*]
no wireless mobility group member ip *ip-address*

Syntax Description

<i>ip-address</i>	The IP address of the member controller.
public-ip <i>public-ip-address</i>	(Optional) Member controller public IP address. Note This command is used only when the member is behind a NAT. Only static IP NAT is supported.
group <i>group-name</i>	(Optional) Member controller group name. Note This command is used only when the member added in not in the same group as the local mobility controller.

Command Default

None.

Command Modes

Global Configuration.

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The mobility group is used when there is more than one Mobility Controller (MC) in a given deployment. The mobility group can be assigned with a name or it can use the default group name. The mobility group members need to be configured on all the members of the group to roam within the group.

Examples

This example shows how to add a member in a mobility group:

```
Controller(config)# wireless mobility group member ip 10.104.171.101 group TestDocGroup
```

wireless mobility group name

To configure the mobility domain name, use the **wireless mobility group name** command. To remove the mobility domain name, use the **no** form of the command.



Note

If you are configuring the mobility group in a network where network address translation (NAT) is enabled, enter the IP address that is sent to the controller from the NAT device rather than the controller's management interface IP address. Otherwise, mobility will fail among controllers in the mobility group.

wireless mobility group name *domain-name*

no wireless mobility group name

Syntax Description

<i>domain-name</i>	Creates a mobility group by entering this command. The domain name can be up to 31 case-sensitive characters.
--------------------	---

Command Default

Default.

Command Modes

Global Configuration.

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to configure a mobility domain name lab1:

```
Controller(config)# mobility group domain lab1
```

wireless mobility oracle ip

To configure mobility oracle settings, use the **wireless mobility oracle ip** command. To remove the mobility oracle settings, use the **no** form of the command.

To configure the device itself as a mobility oracle, use the **wireless mobility oracle** command.

wireless mobility oracle ip *mo-ip-address*

no wireless mobility oracle ip *mo-ip-address*

Syntax Description

<i>mo-ip-address</i>	IP address of the mobility oracle.
----------------------	------------------------------------

Command Default

The device is not configured as a mobility oracle by default.

Command Modes

Global Configuration.

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

- A peer mobility controller must be configured for mobility to work.
- The mobility oracle is recommended when more than one mobility controller in a configuration is allowed a fast client join and roaming across the subdomains. The mobility oracle must be enabled on one of the mobility controllers and the remaining mobility controllers in the sub-domain must point to that mobility oracle.

Examples

This example shows how to configure the mobility oracle:

```
Controller(config)#wireless mobility oracle ip 209.165.200.225
```

show wireless mobility

To view the wireless mobility summary, use the **show wireless mobility** command.

show wireless mobility { **agent** *mobility-agent-ip* **client summary** | **ap-list** *ip-address ip-address* | **controller client summary** | **dtls connections** | **oracle summary** | **statistics summary** }

Syntax Description

agent <i>mobility-agent-ip</i> client summary	Shows the active clients on a mobility agent.
ap-list <i>ip-address ip-address</i>	Shows the list of Cisco APs known to the mobility group.
controller client summary	Shows the active clients in the subdomain.
dtls connections	Shows the DTLS server status.
oracle summary	Displays the status of the mobility-controllers known to the mobility-oracle.
mobility oracle client summary	Shows the mobility-oracle client and status database.
statistics	Shows the statistics for the Mobility manager.
summary	Shows the summary of the mobility manager.

Command Default

None

Command Modes

Global Configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display a summary of the mobility manager:

```
Controller (config)# show wireless mobility ap-list
```

AP name	AP radio MAC	Controller IP	Learnt from
TSIM_AP-101	0000.2000.6600	9.9.9.2	Self
TSIM_AP-102	0000.2000.6700	9.9.9.2	Self
TSIM_AP-103	0000.2000.6800	9.9.9.2	Self
TSIM_AP-400	0000.2001.9100	9.9.9.2	Self
TSIM_AP-402	0000.2001.9300	9.9.9.2	Self
TSIM_AP-403	0000.2001.9400	9.9.9.2	Self
TSIM_AP-406	0000.2001.9700	9.9.9.2	Self
TSIM_AP-407	0000.2001.9800	9.9.9.2	Self

TSIM_AP-409	0000.2001.9a00	9.9.9.2	Self
-------------	----------------	---------	------

clear wireless mobility statistics

To clear wireless statistics, use the **clear wireless mobility statistics** command.

clear wireless mobility statistics

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines You can clear all the information by using the **clear wireless mobility statistics** command.

Examples This example shows how to clear wireless mobility statistics:

```
Controller (config)# clear wireless mobility statistics
```




PART **XIV**

IPv6

- [IPv6 Commands, page 883](#)



IPv6 Commands

- [ipv6 flow monitor](#) , page 884
- [ipv6 traffic-filter](#) , page 885
- [show wireless ipv6 statistics](#) , page 886

ipv6 flow monitor

This command activates a previously created flow monitor by assigning it to the interface to analyze incoming or outgoing traffic.

To activate a previously created flow monitor, use the **ipv6 flow monitor** command. To de-activate a flow monitor, use the **no** form of the command.

ipv6 flow monitor *ipv6-monitor-name* [**sampler** *ipv6-sampler-name*] {**input**| **output**}

no ipv6 flow monitor *ipv6-monitor-name* [**sampler** *ipv6-sampler-name*] {**input**| **output**}

Syntax Description

<i>ipv6-monitor-name</i>	Activates a previously created flow monitor by assigning it to the interface to analyze incoming or outgoing traffic.
sampler <i>ipv6-sampler-name</i>	Applies the flow monitor sampler.
input	Applies the flow monitor on input traffic.
output	Applies the flow monitor on output traffic.

Command Default

IPv6 flow monitor is not activated until it is assigned to an interface.

Command Modes

Interface Configuration.

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You cannot attach a NetFlow monitor to a port channel interface. If both service module interfaces are part of an EtherChannel, you should attach the monitor to both physical interfaces.

Examples

This example shows how to apply a flow monitor to an interface:

```
Controller(config)# interface gigabitethernet 1/1/2
Controller(config-if)# ip flow monitor FLOW-MONITOR-1 input
Controller(config-if)# ip flow monitor FLOW-MONITOR-2 output
Controller(config-if)# end
```

ipv6 traffic-filter

This command enables IPv6 traffic filter.

To enable the filtering of IPv6 traffic on an interface, use the **ipv6 traffic-filter** command. To disable the filtering of IPv6 traffic on an interface, use the **no** form of the command.

Use the **ipv6 traffic-filter** interface configuration command on the switch stack or on a standalone switch to filter IPv6 traffic on an interface. The type and direction of traffic that you can filter depends on the feature set running on the switch stack. Use the **no** form of this command to disable the filtering of IPv6 traffic on an interface.

ipv6 traffic-filter [web] *acl-name*

no ipv6 traffic-filter [web]

Syntax Description		
	web	(Optional) Specifies an IPv6 access name for the WLAN Web ACL.
	<i>acl-name</i>	Specifies an IPv6 access name.

Command Default Filtering of IPv6 traffic on an interface is not configured.

Command Modes wlan

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

To configure the dual IPv4 and IPv6 template, enter the **sdm prefer dual-ipv4-and-ipv6 {default | vlan}** global configuration command and reload the switch.

You can use the **ipv6 traffic-filter** command on physical interfaces (Layer 2 or Layer 3 ports), Layer 3 port channels, or switch virtual interfaces (SVIs).

You can apply an ACL to outbound or inbound traffic on Layer 3 interfaces (port ACLs), or to inbound traffic on Layer 2 interfaces (router ACLs).

If **any** port ACL (IPv4, IPv6, or MAC) is applied to an interface, that port ACL is used to filter packets, and any router ACLs attached to the SVI of the port VLAN are ignored.

Examples This example shows how to filter IPv6 traffic on an interface:

```
Controller(config-wlan)# ipv6 traffic-filter TestDocTrafficFilter
```

show wireless ipv6 statistics

This command is used to display the IPv6 packet counter statistics.

To view IPv6 packet counter statistics, use the **show wireless ipv6 statistics** command.

show wireless ipv6 statistics

Command Default

None.

Command Modes

User EXEC.

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following example shows the summary of the IPv6 packet counter statistics:

```

Controller# show wireless ipv6 statistics
NS Forwarding to wireless clients           : Enabled

RS count                                   : 0
RA count                                   : 0
NS count                                   : 0
NA count                                   : 0
Other NDP packet count                     : 0
-----
Non-IPv6 packets count                    : 0
Non-IPv6 Multicast Destination MAC packet count : 0
Invalid length packets count              : 0
Null packets count                        : 0
Invalid Source MAC packets count          : 0
-----
TCP packets count                         : 0
UDP packets count                         : 0
Fragmented packets count                  : 0
No next header packets count              : 0
Other type packets count                  : 0
-----
Total packets count                       : 0
-----
Blocked RA packets count                  : 0
Blocked NS packets count                  : 0

```



PART **XV**

Flexible Netflow

- [Flexible NetFlow Commands, page 889](#)



Flexible NetFlow Commands

- [cache](#), page 891
- [clear flow exporter](#), page 893
- [clear flow monitor](#), page 894
- [collect](#), page 896
- [collect counter](#), page 898
- [collect interface](#), page 899
- [collect timestamp absolute](#), page 900
- [collect transport tcp flags](#), page 901
- [datalink flow monitor](#), page 902
- [debug flow exporter](#), page 903
- [debug flow monitor](#), page 904
- [debug flow record](#), page 905
- [debug sampler](#), page 906
- [description](#), page 907
- [destination](#), page 908
- [dscp](#), page 909
- [export-protocol netflow-v9](#), page 910
- [exporter](#), page 911
- [flow exporter](#), page 912
- [flow monitor](#), page 913
- [flow record](#), page 914
- [ip flow monitor](#), page 915
- [ipv6 flow monitor](#), page 917
- [match datalink ethertype](#), page 919

- [match datalink mac, page 920](#)
- [match datalink vlan, page 921](#)
- [match flow direction, page 922](#)
- [match interface, page 923](#)
- [match ipv4, page 924](#)
- [match ipv4 destination address, page 925](#)
- [match ipv4 source address, page 926](#)
- [match ipv4 ttl, page 927](#)
- [match ipv6, page 928](#)
- [match ipv6 destination address, page 929](#)
- [match ipv6 hop-limit, page 930](#)
- [match ipv6 source address, page 931](#)
- [match transport, page 932](#)
- [match transport icmp ipv4, page 933](#)
- [match transport icmp ipv6, page 934](#)
- [mode random 1 out-of, page 935](#)
- [option, page 936](#)
- [record, page 938](#)
- [sampler, page 939](#)
- [show flow exporter, page 940](#)
- [show flow interface, page 942](#)
- [show flow monitor, page 944](#)
- [show flow record, page 946](#)
- [show sampler, page 947](#)
- [source, page 949](#)
- [template data timeout, page 951](#)
- [transport, page 952](#)
- [ttl, page 953](#)

cache

To configure a flow cache parameter for a flow monitor, use the **cache** command in flow monitor configuration mode. To remove a flow cache parameter for a flow monitor, use the **no** form of this command.

cache {**timeout** {**active**|**inactive**} *seconds*| **type normal**}

no cache {**timeout** {**active**|**inactive**} | **type**}

Syntax Description

timeout	Specifies the flow timeout.
active	Specifies the active flow timeout.
inactive	Specifies the inactive flow timeout.
<i>seconds</i>	The timeout value in seconds. The range is 1 to 604800 (7 days).
type	Specifies the type of the flow cache.
normal	Configures a normal cache type. The entries in the flow cache will be aged out according to the timeout active seconds and timeout inactive seconds settings. This is the default cache type.

Command Default

The default flow monitor flow cache parameters are used.

The following flow cache parameters for a flow monitor are enabled:

- Cache type: normal
- Active flow timeout: 1800 seconds

Command Modes

Flow monitor configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Each flow monitor has a cache that it uses to store all the flows it monitors. Each cache has various configurable elements, such as the time that a flow is allowed to remain in it. When a flow times out, it is removed from the cache and sent to any exporters that are configured for the corresponding flow monitor.

The **cache timeout active** command controls the aging behavior of the normal type of cache. If a flow has been active for a long time, it is usually desirable to age it out (starting a new flow for any subsequent packets in the flow). This age out process allows the monitoring application that is receiving the exports to remain up

to date. By default, this timeout is 1800 seconds (30 minutes), but it can be adjusted according to system requirements. A larger value ensures that long-lived flows are accounted for in a single flow record; a smaller value results in a shorter delay between starting a new long-lived flow and exporting some data for it. When you change the active flow timeout, the new timeout value takes effect immediately.

The **cache timeout inactive** command also controls the aging behavior of the normal type of cache. If a flow has not seen any activity for a specified amount of time, that flow will be aged out. By default, this timeout is 15 seconds, but this value can be adjusted depending on the type of traffic expected. If a large number of short-lived flows is consuming many cache entries, reducing the inactive timeout can reduce this overhead. If a large number of flows frequently get aged out before they have finished collecting their data, increasing this timeout can result in better flow correlation. When you change the inactive flow timeout, the new timeout value takes effect immediately.

The **cache type normal** command specifies the normal cache type. This is the default cache type. The entries in the cache will be aged out according to the **timeout active seconds** and **timeout inactive seconds** settings. When a cache entry is aged out, it is removed from the cache and exported via any exporters configured for the monitor associated with the cache.

To return a cache to its default settings, use the **default cache** flow monitor configuration command.


Note

When a cache becomes full, new flows will not be monitored.

Examples

The following example shows how to configure the active timeout for the flow monitor cache:

```
Controller(config)# flow monitor FLOW-MONITOR-1
Controller(config-flow-monitor)# cache timeout active 4800
```

The following example shows how to configure the inactive timer for the flow monitor cache:

```
Controller(config)# flow monitor FLOW-MONITOR-1
Controller(config-flow-monitor)# cache timeout inactive 30
```

The following example shows how to configure a normal cache:

```
Controller(config)# flow monitor FLOW-MONITOR-1
Controller(config-flow-monitor)# cache type normal
```

clear flow exporter

To clear the statistics for a flow exporter, use the **clear flow exporter** command in privileged EXEC mode.

clear flow exporter [[name] *exporter-name*] **statistics**

Syntax Description

name	(Optional) Specifies the name of a flow exporter.
<i>exporter-name</i>	(Optional) Name of a flow exporter that was previously configured.
statistics	Clears the flow exporter statistics.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **clear flow exporter** command removes all statistics from the flow exporter. These statistics will not be exported and the data gathered in the cache will be lost.

You can view the flow exporter statistics by using the **show flow exporter statistics** privileged EXEC command.

Examples

The following example clears the statistics for all of the flow exporters configured on the controller:

```
Controller# clear flow exporter statistics
```

The following example clears the statistics for the flow exporter named FLOW-EXPORTER-1:

```
Controller# clear flow exporter FLOW-EXPORTER-1 statistics
```

clear flow monitor

To clear a flow monitor cache or flow monitor statistics and to force the export of the data in the flow monitor cache, use the **clear flow monitor** command in privileged EXEC mode.

clear flow monitor [**name**] *monitor-name* [[**cache**] **force-export**| **statistics**]

Syntax Description

name	Specifies the name of a flow monitor.
<i>monitor-name</i>	Name of a flow monitor that was previously configured.
cache	(Optional) Clears the flow monitor cache information.
force-export	(Optional) Forces the export of the flow monitor cache statistics.
statistics	(Optional) Clears the flow monitor statistics.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **clear flow monitor cache** command removes all entries from the flow monitor cache. These entries will not be exported and the data gathered in the cache will be lost.



Note

The statistics for the cleared cache entries are maintained.

The **clear flow monitor force-export** command removes all entries from the flow monitor cache and exports them using all flow exporters assigned to the flow monitor. This action can result in a short-term increase in CPU usage. Use this command with caution.

The **clear flow monitor statistics** command clears the statistics for this flow monitor.



Note

The current entries statistic will not be cleared by the **clear flow monitor statistics** command because this is an indicator of how many entries are in the cache and the cache is not cleared with this command.

You can view the flow monitor statistics by using the **show flow monitor statistics** privileged EXEC command.

Examples

The following example clears the statistics and cache entries for the flow monitor named FLOW-MONITOR-1:

```
Controller# clear flow monitor name FLOW-MONITOR-1
```

The following example clears the statistics and cache entries for the flow monitor named FLOW-MONITOR-1 and forces an export:

```
Controller# clear flow monitor name FLOW-MONITOR-1 force-export
```

The following example clears the cache for the flow monitor named FLOW-MONITOR-1 and forces an export:

```
Controller# clear flow monitor name FLOW-MONITOR-1 cache force-export
```

The following example clears the statistics for the flow monitor named FLOW-MONITOR-1:

```
Controller# clear flow monitor name FLOW-MONITOR-1 statistics
```

collect

To configure non-key fields for the flow monitor record and to enable capturing the values in the fields for the flow created with the record, use the **collect** command in flow record configuration mode.

collect {**counter**|**interface**|**timestamp**|**transport**}

Syntax Description

counter	Configures the number of bytes or packets in a flow as a non-key field for a flow record. For more information, see collect counter, on page 898 .
interface	Configures the input and output interface name as a non-key field for a flow record. For more information, see collect interface, on page 899 .
timestamp	Configures the absolute time of the first seen or last seen packet in a flow as a non-key field for a flow record. For more information, see collect timestamp absolute, on page 900 .
transport	Enables the collecting of transport TCP flags from a flow record. For more information, see collect transport tcp flags, on page 901 .

Command Default

Non-key fields are not configured for the flow monitor record.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The values in non-key fields are added to flows to provide additional information about the traffic in the flows. A change in the value of a non-key field does not create a new flow. In most cases, the values for non-key fields are taken from only the first packet in the flow.

The **collect** commands are used to configure non-key fields for the flow monitor record and to enable capturing the values in the fields for the flow created with the record. The values in non-key fields are added to flows to provide additional information about the traffic in the flows. A change in the value of a non-key field does not create a new flow. In most cases the values for non-key fields are taken from only the first packet in the flow.



Note

Although it is visible in the command-line help string, the **flow username** keyword is not supported.

Examples

The following example configures the total number of bytes in the flows as a non-key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# collect counter bytes long
```

collect counter

To configure the number of bytes or packets in a flow as a non-key field for a flow record, use the **collect counter** command in flow record configuration mode. To disable the use of the number of bytes or packets in a flow (counters) as a non-key field for a flow record, use the **no** form of this command.

Command Default

The number of bytes or packets in a flow is not configured as a non-key field.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

To return this command to its default settings, use the **no collect counter** or **default collect counter** flow record configuration command.

Examples

The following example configures the total number of bytes in the flows as a non-key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# collect counter bytes long
```

The following example configures the total number of packets from the flows as a non-key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# collect counter packets long
```

collect interface

To configure the input interface name as a non-key field for a flow record, use the **collect interface** command in flow record configuration mode. To disable the use of the input interface as a non-key field for a flow record, use the **no** form of this command.

collect interface input

no collect interface input

Syntax Description

input	Configures the input interface name as a non-key field and enables collecting the input interface from the flows.
--------------	---

Command Default

The input interface name is not configured as a non-key field.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The Flexible NetFlow **collect** commands are used to configure non-key fields for the flow monitor record and to enable capturing the values in the fields for the flow created with the record. The values in non-key fields are added to flows to provide additional information about the traffic in the flows. A change in the value of a non-key field does not create a new flow. In most cases, the values for non-key fields are taken from only the first packet in the flow.

To return this command to its default settings, use the **no collect interface** or **default collect interface** flow record configuration command.

Examples

The following example configures the input interface as a non-key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# collect interface input
```

collect timestamp absolute

To configure the absolute time of the first seen or last seen packet in a flow as a non-key field for a flow record, use the **collect timestamp absolute** command in flow record configuration mode. To disable the use of the first seen or last seen packet in a flow as a non-key field for a flow record, use the **no** form of this command.

collect timestamp absolute {first|last}

no collect timestamp absolute {first|last}

Syntax Description

first	Configures the absolute time of the first seen packet in a flow as a non-key field and enables collecting time stamps from the flows.
last	Configures the absolute time of the last seen packet in a flow as a non-key field and enables collecting time stamps from the flows.

Command Default

The absolute time field is not configured as a non-key field.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **collect** commands are used to configure non-key fields for the flow monitor record and to enable capturing the values in the fields for the flow created with the record. The values in non-key fields are added to flows to provide additional information about the traffic in the flows. A change in the value of a non-key field does not create a new flow. In most cases the values for non-key fields are taken from only the first packet in the flow.

Examples

The following example configures time stamps based on the absolute time of the first seen packet in a flow as a non-key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# collect timestamp absolute first
```

The following example configures time stamps based on the absolute time of the last seen packet in a flow as a non-key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# collect timestamp absolute last
```

collect transport tcp flags

To enable the collecting of transport TCP flags from a flow, use the **collect transport tcp flags** command in flow record configuration mode. To disable the collecting of transport TCP flags from the flow, use the **no** form of this command.

collect transport tcp flags

no collect transport tcp flags

Syntax Description

This command has no arguments or keywords.

Command Default

The transport layer fields are not configured as a non-key field.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The values of the transport layer fields are taken from all packets in the flow. You cannot specify which TCP flag to collect. You can only specify to collect transport TCP flags. All TCP flags will be collected with this command. The following transport TCP flags are collected:

- **ack**—TCP acknowledgement flag
- **cwr**—TCP congestion window reduced flag
- **ece**—TCP ECN echo flag
- **fin**—TCP finish flag
- **psh**—TCP push flag
- **rst**—TCP reset flag
- **syn**—TCP synchronize flag
- **urg**—TCP urgent flag

To return this command to its default settings, use the **no collect collect transport tcp flags** or **default collect collect transport tcp flags** flow record configuration command.

Examples

The following example collects the TCP flags from a flow:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# collect transport tcp flags
```

datalink flow monitor

To apply a Flexible NetFlow flow monitor to an interface, use the **datalink flow monitor** command in interface configuration mode. To disable a Flexible NetFlow flow monitor, use the **no** form of this command.

datalink flow monitor *monitor-name* **sampler** *sampler-name* **input**
no datalink flow monitor *monitor-name* **sampler** *sampler-name* **input**

Syntax Description	
<i>monitor-name</i>	Name of the flow monitor to apply to the interface.
sampler <i>sampler-name</i>	Enables the specified flow sampler for the flow monitor.
input	Monitors traffic that the switch receives on the interface.

Command Default A flow monitor is not enabled.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Before you apply a flow monitor to an interface with the **datalink flow monitor** command, you must have already created the flow monitor using the **flow monitor** global configuration command and the flow sampler using the **sampler** global configuration command.

To enable a flow sampler for the flow monitor, you must have already created the sampler.



Note The **datalink flow monitor** command only monitors non-IPv4 and non-IPv6 traffic. To monitor IPv4 traffic, use the **ip flow monitor** command. To monitor IPv6 traffic, use the **ipv6 flow monitor** command.

Examples This example shows how to enable Flexible NetFlow datalink monitoring on an interface:

```
Controller(config)# interface gigabitethernet1/0/1
Controller(config-if)# datalink flow monitor FLOW-MONITOR-1 sampler FLOW-SAMPLER-1 input
```

debug flow exporter

To enable debugging output for flow exporters, use the **debug flow exporter** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug flow exporter [[name] *exporter-name*] [**error**| **event**| **packets** *number*]

no debug flow exporter [[name] *exporter-name*] [**error**| **event**| **packets** *number*]

Syntax Description

name	(Optional) Specifies the name of a flow exporter.
<i>exporter-name</i>	(Optional) The name of a flow exporter that was previously configured.
error	(Optional) Enables debugging for flow exporter errors.
event	(Optional) Enables debugging for flow exporter events.
packets	(Optional) Enables packet-level debugging for flow exporters.
<i>number</i>	(Optional) The number of packets to debug for packet-level debugging of flow exporters. The range is 1 to 65535.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following example indicates that a flow exporter packet has been queued for process send:

```
Controller# debug flow exporter
May 21 21:29:12.603: FLOW EXP: Packet queued for process send
```

debug flow monitor

To enable debugging output for flow monitors, use the **debug flow monitor** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug flow monitor [**error**] [**name**] *monitor-name* [**cache** [**error**]| **error**| **packets** *packets*]

no debug flow monitor [**error**] [**name**] *monitor-name* [**cache** [**error**]| **error**| **packets** *packets*]

Syntax Description

error	(Optional) Enables debugging for flow monitor errors for all flow monitors or for the specified flow monitor.
name	(Optional) Specifies the name of a flow monitor.
<i>monitor-name</i>	(Optional) Name of a flow monitor that was previously configured.
cache	(Optional) Enables debugging for the flow monitor cache.
cache error	(Optional) Enables debugging for flow monitor cache errors.
packets	(Optional) Enables packet-level debugging for flow monitors.
<i>packets</i>	(Optional) Number of packets to debug for packet-level debugging of flow monitors. The range is 1 to 65535.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following example shows that the cache for FLOW-MONITOR-1 was deleted:

```
Controller# debug flow monitor FLOW-MONITOR-1 cache
May 21 21:53:02.839: FLOW MON: 'FLOW-MONITOR-1' deleted cache
```

debug flow record

To enable debugging output for flow records, use the **debug flow record** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug flow record [[**name**] *record-name* | **options** {**sampler-table**} | [**detailed** | **error**]]

no debug flow record [[**name**] *record-name* | **options** {**sampler-table**} | [**detailed** | **error**]]

Syntax Description

name	(Optional) Specifies the name of a flow record.
<i>record-name</i>	(Optional) Name of a user-defined flow record that was previously configured.
options	(Optional) Includes information on other flow record options.
sampler-table	(Optional) Includes information on the sampler tables.
detailed	(Optional) Displays detailed information.
error	(Optional) Displays errors only.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following example enables debugging for the flow record:

```
Controller# debug flow record FLOW-record-1
```

debug sampler

To enable debugging output for samplers, use the **debug sampler** command in privileged EXEC mode. To disable debugging output, use the **no** form of this command.

debug sampler [**detailed**| **error**| [**name**] *sampler-name* [**detailed**| **error**| **sampling** *samples*]]

no debug sampler [**detailed**| **error**| [**name**] *sampler-name* [**detailed**| **error**| **sampling**]]

Syntax Description

detailed	(Optional) Enables detailed debugging for sampler elements.
error	(Optional) Enables debugging for sampler errors.
name	(Optional) Specifies the name of a sampler.
<i>sampler-name</i>	(Optional) Name of a sampler that was previously configured.
sampling <i>samples</i>	(Optional) Enables debugging for sampling and specifies the number of samples to debug.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following sample output shows that the debug process has obtained the ID for the sampler named SAMPLER-1:

```
Controller# debug sampler detailed
*May 28 04:14:30.883: Sampler: Sampler(SAMPLER-1: flow monitor FLOW-MONITOR-1 (ip,Et1/0,0)
  get ID succeeded:1
*May 28 04:14:30.971: Sampler: Sampler(SAMPLER-1: flow monitor FLOW-MONITOR-1 (ip,Et0/0,I)
  get ID succeeded:1
```

description

To configure a description for a flow monitor, flow exporter, or flow record, use the **description** command in the appropriate configuration mode. To remove a description, use the **no** form of this command.

description *description*

no description *description*

Syntax Description

<i>description</i>	Text string that describes the flow monitor, flow exporter, or flow record.
--------------------	---

Command Default

The default description for a flow sampler, flow monitor, flow exporter, or flow record is "User defined."

Command Modes

The following command modes are supported:

Flow exporter configuration

Flow monitor configuration

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

To return this command to its default setting, use the **no description** or **default description** command in the appropriate configuration mode.

Examples

The following example configures a description for a flow monitor:

```
Controller(config)# flow monitor FLOW-MONITOR-1
Controller(config-flow-monitor)# description Monitors traffic to 172.16.0.1 255.255.0.0
```

destination

To configure an export destination for a flow exporter, use the **destination** command in flow exporter configuration mode. To remove an export destination for a flow exporter, use the **no** form of this command.

destination {*hostname*| *ip-address*}

no destination {*hostname*| *ip-address*}

Syntax Description

<i>hostname</i>	Hostname of the device to which you want to send the NetFlow information.
<i>ip-address</i>	IPv4 address of the workstation to which you want to send the NetFlow information.

Command Default

An export destination is not configured.

Command Modes

Flow exporter configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Each flow exporter can have only one destination address or hostname.

When you configure a hostname instead of the IP address for the device, the hostname is resolved immediately and the IPv4 address is stored in the running configuration. If the hostname-to-IP-address mapping that was used for the original Domain Name System (DNS) name resolution changes dynamically on the DNS server, the controller does not detect this, and the exported data continues to be sent to the original IP address, resulting in a loss of data.

To return this command to its default setting, use the **no destination** or **default destination** command in flow exporter configuration mode.

Examples

The following example shows how to configure the networking device to export the cache entry to a destination system:

```
Controller(config)# flow exporter FLOW-EXPORTER-1
Controller(config-flow-exporter)# destination 10.0.0.4
```

dscp

To configure a differentiated services code point (DSCP) value for flow exporter datagrams, use the **dscp** command in flow exporter configuration mode. To remove a DSCP value for flow exporter datagrams, use the **no** form of this command.

dscp *dscp*

no dscp *dscp*

Syntax Description

<i>dscp</i>	DSCP to be used in the DSCP field in exported datagrams. The range is 0 to 63. The default is 0.
-------------	--

Command Default

The differentiated services code point (DSCP) value is 0.

Command Modes

Flow exporter configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

To return this command to its default setting, use the **no dscp** or **default dscp** flow exporter configuration command.

Examples

The following example sets 22 as the value of the DSCP field in exported datagrams:

```
Controller(config)# flow exporter FLOW-EXPORTER-1
Controller(config-flow-exporter)# dscp 22
```

export-protocol netflow-v9

To configure NetFlow Version 9 export as the export protocol for a Flexible NetFlow exporter, use the **export-protocol netflow-v9** command in flow exporter configuration mode.

export-protocol netflow-v9

Syntax Description This command has no arguments or keywords.

Command Default NetFlow Version 9 is enabled.

Command Modes Flow exporter configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines The controller does not support NetFlow v5 export format, only NetFlow v9 export format is supported.

Examples

The following example configures NetFlow Version 9 export as the export protocol for a NetFlow exporter:

```
Controller(config)# flow exporter FLOW-EXPORTER-1
Controller(config-flow-exporter)# export-protocol netflow-v9
```

exporter

To add a flow exporter for a flow monitor, use the **exporter** command in the appropriate configuration mode. To remove a flow exporter for a flow monitor, use the **no** form of this command.

exporter *exporter-name*

no exporter *exporter-name*

Syntax Description

<i>exporter-name</i>	Name of a flow exporter that was previously configured.
----------------------	---

Command Default

An exporter is not configured.

Command Modes

Flow monitor configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You must have already created a flow exporter by using the **flow exporter** command before you can apply the flow exporter to a flow monitor with the **exporter** command.

To return this command to its default settings, use the **no exporter** or **default exporter** flow monitor configuration command.

Examples

The following example configures an exporter for a flow monitor:

```
Controller(config)# flow monitor FLOW-MONITOR-1
Controller(config-flow-monitor)# exporter EXPORTER-1
```

flow exporter

To create a flow exporter, or to modify an existing flow exporter, and enter flow exporter configuration mode, use the **flow exporter** command in global configuration mode. To remove a flow exporter, use the **no** form of this command.

flow exporter *exporter-name*

no flow exporter *exporter-name*

Syntax Description

<i>exporter-name</i>	Name of the flow exporter that is being created or modified.
----------------------	--

Command Default

flow exporters are not present in the configuration.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Flow exporters export the data in the flow monitor cache to a remote system, such as a server running NetFlow collector, for analysis and storage. Flow exporters are created as separate entities in the configuration. Flow exporters are assigned to flow monitors to provide data export capability for the flow monitors. You can create several flow exporters and assign them to one or more flow monitors to provide several export destinations. You can create one flow exporter and apply it to several flow monitors.

Examples

The following example creates a flow exporter named FLOW-EXPORTER-1 and enters flow exporter configuration mode:

```
Controller(config)# flow exporter FLOW-EXPORTER-1
Controller(config-flow-exporter)#
```

flow monitor

To create a flow monitor, or to modify an existing flow monitor, and enter flow monitor configuration mode, use the **flow monitor** command in global configuration mode. To remove a flow monitor, use the **no** form of this command.

flow monitor *monitor-name*

no flow monitor *monitor-name*

Syntax Description

<i>monitor-name</i>	Name of the flow monitor that is being created or modified.
---------------------	---

Command Default

flow monitors are not present in the configuration.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Flow monitors are the component that is applied to interfaces to perform network traffic monitoring. Flow monitors consist of a flow record and a cache. You add the record to the flow monitor after you create the flow monitor. The flow monitor cache is automatically created at the time the flow monitor is applied to the first interface. Flow data is collected from the network traffic during the monitoring process based on the key and nonkey fields in the flow monitor's record and stored in the flow monitor cache.

Examples

The following example creates a flow monitor named FLOW-MONITOR-1 and enters flow monitor configuration mode:

```
Controller(config)# flow monitor FLOW-MONITOR-1
Controller(config-flow-monitor)#
```

flow record

To create a flow record, or to modify an existing flow record, and enter flow record configuration mode, use the **flow record** command in global configuration mode. To remove a record, use the **no** form of this command.

flow record *record-name*

no flow record *record-name*

Syntax Description

<i>record-name</i>	Name of the flow record that is being created or modified.
--------------------	--

Command Default

A flow record is not configured.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A flow record defines the keys that uses to identify packets in the flow, as well as other fields of interest that gathers for the flow. You can define a flow record with any combination of keys and fields of interest. The controller supports a rich set of keys. A flow record also defines the types of counters gathered per flow. You can configure 64-bit packet or byte counters.

Examples

The following example creates a flow record named FLOW-RECORD-1, and enters flow record configuration mode:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)#
```

ip flow monitor

To enable a Flexible NetFlow flow monitor for IPv4 traffic that the controller is receiving, use the **ip flow monitor** command in interface configuration mode. To disable a flow monitor, use the **no** form of this command.

ip flow monitor *monitor-name* [**sampler** *sampler-name*] **input**

no ip flow monitor *monitor-name* [**sampler** *sampler-name*] **input**

Syntax Description

<i>monitor-name</i>	Name of the flow monitor to apply to the interface.
sampler <i>sampler-name</i>	(Optional) Enables the specified flow sampler for the flow monitor.
input	Monitors IPv4 traffic that the controller receives on the interface.

Command Default

A flow monitor is not enabled.

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Before you can apply a flow monitor to an interface with the **ip flow monitor** command, you must have already created the flow monitor using the **flow monitor** global configuration command.

When you add a sampler to a flow monitor, only packets that are selected by the named sampler will be entered into the cache to form flows. Each use of a sampler causes separate statistics to be stored for that usage.

You cannot add a sampler to a flow monitor after the flow monitor has been enabled on the interface. You must first remove the flow monitor from the interface and then enable the same flow monitor with a sampler.



Note

The statistics for each flow must be scaled to give the expected true usage. For example, with a 1 in 100 sampler it is expected that the packet and byte counters will have to be multiplied by 100.

Examples

The following example enables a flow monitor for monitoring input traffic:

```
Controller(config)# interface gigabitethernet1/0/1
Controller(config-if)# ip flow monitor FLOW-MONITOR-1 input
```

The following example enables a flow monitor for monitoring input traffic, with a sampler to limit the input packets that are sampled:

```
Controller(config)# interface gigabitethernet1/0/1
Controller(config-if)# ip flow monitor FLOW-MONITOR-1 sampler SAMPLER-1 input
```

The following example shows what happens when you try to add a sampler to a flow monitor that has already been enabled on an interface without a sampler:

```
Controller(config)# interface gigabitethernet1/0/1
Controller(config-if)# ip flow monitor FLOW-MONITOR-1 sampler SAMPLER-2 input
% Flow Monitor: Flow Monitor 'FLOW-MONITOR-1' is already on in full mode and cannot be
enabled with a sampler.
```

The following example shows how to remove a flow monitor from an interface so that it can be enabled with the sampler:

```
Controller(config)# interface gigabitethernet1/0/1
Controller(config-if)# no ip flow monitor FLOW-MONITOR-1 input
Controller(config-if)# ip flow monitor FLOW-MONITOR-1 sampler SAMPLER-2 input
```

ipv6 flow monitor

To enable a flow monitor for IPv6 traffic that the controller is receiving, use the **ipv6 flow monitor** command in interface configuration mode. To disable a flow monitor, use the **no** form of this command.

ipv6 flow monitor *monitor-name* [**sampler** *sampler-name*] **input**

no ipv6 flow monitor *monitor-name* [**sampler** *sampler-name*] **input**

Syntax Description	
<i>monitor-name</i>	Name of the flow monitor to apply to the interface.
sampler <i>sampler-name</i>	(Optional) Enables the specified flow sampler for the flow monitor.
input	Monitors IPv6 traffic that the controller receives on the interface.

Command Default A flow monitor is not enabled.

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Before you can apply a flow monitor to the interface with the **ipv6 flow monitor** command, you must have already created the flow monitor using the **flow monitor** global configuration command.

When you add a sampler to a flow monitor, only packets that are selected by the named sampler will be entered into the cache to form flows. Each use of a sampler causes separate statistics to be stored for that usage.

You cannot add a sampler to a flow monitor after the flow monitor has been enabled on the interface. You must first remove the flow monitor from the interface and then enable the same flow monitor with a sampler.



Note The statistics for each flow must be scaled to give the expected true usage. For example, with a 1 in 100 sampler it is expected that the packet and byte counters will have to be multiplied by 100.

Examples The following example enables a flow monitor for monitoring input traffic:

```
Controller(config)# interface gigabitethernet1/0/1
Controller(config-if)# ipv6 flow monitor FLOW-MONITOR-1 input
```

The following example enables a flow monitor for monitoring input traffic, with a sampler to limit the input packets that are sampled:

```
Controller(config)# interface gigabitethernet1/0/1
Controller(config-if)# ipv6 flow monitor FLOW-MONITOR-1 sampler SAMPLER-1 input
```

The following example shows what happens when you try to add a sampler to a flow monitor that has already been enabled on an interface without a sampler:

```
Controller(config)# interface gigabitethernet1/0/1
Controller(config-if)# ipv6 flow monitor FLOW-MONITOR-1 sampler SAMPLER-2 input
% Flow Monitor: Flow Monitor 'FLOW-MONITOR-1' is already on in full mode and cannot be
enabled with a sampler.
```

The following example shows how to remove a flow monitor from an interface so that it can be enabled with the sampler:

```
Controller(config)# interface gigabitethernet1/0/1
Controller(config-if)# no ipv6 flow monitor FLOW-MONITOR-1 input
Controller(config-if)# ipv6 flow monitor FLOW-MONITOR-1 sampler SAMPLER-2 input
```

match datalink ethertype

To configure the EtherType of the packet as a key field for a flow record, use the **match datalink ethertype** command in flow record configuration mode. To disable the EtherType of the packet as a key field for a flow record, use the **no** form of this command.

match datalink ethertype

no match datalink ethertype

Syntax Description

This command has no arguments or keywords.

Command Default

The EtherType of the packet is not configured as a key field.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

When you configure the EtherType of the packet as a key field for a flow record using the **match datalink ethertype** command, the traffic flow that is created is based on the type of flow monitor that is assigned to the interface:

- When a datalink flow monitor is assigned to an interface using the **datalink flow monitor** interface configuration command, it creates unique flows for different Layer 2 protocols.
- When an IP flow monitor is assigned to an interface using the **ip flow monitor** interface configuration command, it creates unique flows for different IPv4 protocols.
- When an IPv6 flow monitor is assigned to an interface using the **ipv6 flow monitor** interface configuration command, it creates unique flows for different IPv6 protocols.

To return this command to its default settings, use the **no match datalink ethertype** or **default match datalink ethertype** flow record configuration command.

Examples

The following example configures the EtherType of the packet as a key field for a flow record:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match datalink ethertype
```

match datalink mac

To configure the use of MAC addresses as a key field for a flow record, use the **match datalink mac** command in flow record configuration mode. To disable the use of MAC addresses as a key field for a flow record, use the **no** form of this command.

match datalink mac {destination address input| source address input}

no match datalink mac {destination address input| source address input}

Syntax Description

destination address	Configures the use of the destination MAC address as a key field.
input	Specifies the MAC address of input packets.
source address	Configures the use of the source MAC address as a key field.

Command Default

MAC addresses are not configured as a key field.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

The **input** keyword is used to specify the observation point that is used by the **match datalink mac** command to create flows based on the unique MAC addresses in the network traffic.



Note

When a datalink flow monitor is assigned to an interface or VLAN record, it creates flows only for non-IPv6 or non-IPv4 traffic.

To return this command to its default settings, use the **no match datalink mac** or **default match datalink mac** flow record configuration command.

Examples

The following example configures the use of the destination MAC address of packets that are received by the controller as a key field for a flow record:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match datalink mac destination address input
```

match datalink vlan

To configure the VLAN ID as a key field for a flow record, use the **match datalink vlan** command in flow record configuration mode. To disable the use of the VLAN ID value as a key field for a flow record, use the **no** form of this command.

match datalink vlan input

no match datalink vlan input

Syntax Description

input	Configures the VLAN ID of traffic being received by the controller as a key field.
--------------	--

Command Default

The VLAN ID is not configured as a key field.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

The **input** keyword is used to specify the observation point that is used by the **match datalink vlan** command to create flows based on the unique VLAN IDs in the network traffic.

Examples

The following example configures the VLAN ID of traffic being received by the controller as a key field for a flow record:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match datalink vlan input
```

match flow direction

To configure the flow direction as key fields for a flow record, use the **match flow direction** command in flow record configuration mode. To disable the use of the flow direction as key fields for a flow record, use the **no** form of this command.

match flow direction

no match flow direction

Syntax Description This command has no arguments or keywords.

Command Default The flow direction is not configured as key fields.

Command Modes Flow record configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

The **match flow direction** command captures the direction of the flow as a key field. This feature is most useful when a single flow monitor is configured for input and output flows. It can be used to find and eliminate flows that are being monitored twice, once on input and once on output. This command can help to match up pairs of flows in the exported data when the two flows are flowing in opposite directions.

Examples The following example configures the direction the flow was monitored in as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match flow direction
```

match interface

To configure the input and output interfaces as key fields for a flow record, use the **match interface** command in flow record configuration mode. To disable the use of the input and output interfaces as key fields for a flow record, use the **no** form of this command.

match interface {input| output}

no match interface {input| output}

Syntax Description

input	Configures the input interface as a key field.
output	Configures the output interface as a key field.

Command Default

The input and output interfaces are not configured as key fields.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples

The following example configures the input interface as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match interface input
```

The following example configures the output interface as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match interface output
```

match ipv4

To configure one or more of the IPv4 fields as a key field for a flow record, use the **match ipv4** command in flow record configuration mode. To disable the use of one or more of the IPv4 fields as a key field for a flow record, use the **no** form of this command.

match ipv4 {destination address| protocol| source address| tos| version}

no match ipv4 {destination address| protocol| source address| tos| version}

Syntax Description

destination address	Configures the IPv4 destination address as a key field. For more information see match ipv4 destination address, on page 925 .
protocol	Configures the IPv4 protocol as a key field.
source address	Configures the IPv4 destination address as a key field. For more information see match ipv4 source address, on page 926 .
tos	Configures the IPv4 ToS as a key field.
version	Configures the IP version from IPv4 header as a key field.

Command Default

The use of one or more of the IPv4 fields as a key field for a user-defined flow record is not enabled.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples

The following example configures the IPv4 protocol as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match ipv4 protocol
```

match ipv4 destination address

To configure the IPv4 destination address as a key field for a flow record, use the **match ipv4 destination address** command in flow record configuration mode. To disable the IPv4 destination address as a key field for a flow record, use the **no** form of this command.

match ipv4 destination address

no match ipv4 destination address

Syntax Description This command has no arguments or keywords.

Command Default The IPv4 destination address is not configured as a key field.

Command Modes Flow record configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

To return this command to its default settings, use the **no match ipv4 destination address** or **default match ipv4 destination address** flow record configuration command.

Examples The following example configures the IPv4 destination address as a key field for a flow record:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match ipv4 destination address
```

match ipv4 source address

To configure the IPv4 source address as a key field for a flow record, use the **match ipv4 source address** command in flow record configuration mode. To disable the use of the IPv4 source address as a key field for a flow record, use the **no** form of this command.

match ipv4 source address

no match ipv4 source address

Syntax Description This command has no arguments or keywords.

Command Default The IPv4 source address is not configured as a key field.

Command Modes Flow record configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

To return this command to its default settings, use the **no match ipv4 source address** or **default match ipv4 source address** flow record configuration command.

Examples The following example configures the IPv4 source address as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match ipv4 source address
```

match ipv4 ttl

To configure the IPv4 time-to-live (TTL) field as a key field for a flow record, use the **match ipv4 ttl** command in flow record configuration mode. To disable the use of the IPv4 TTL field as a key field for a flow record, use the **no** form of this command.

match ipv4 ttl

no match ipv4 ttl

Syntax Description

This command has no arguments or keywords.

Command Default

The IPv4 time-to-live (TTL) field is not configured as a key field.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match ipv4 ttl** command.

Examples

The following example configures IPv4 TTL as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match ipv4 ttl
```

match ipv6

To configure one or more of the IPv6 fields as a key field for a flow record, use the **match ipv6** command in flow record configuration mode. To disable the use of one or more of the IPv6 fields as a key field for a flow record, use the **no** form of this command.

match ipv6 {destination address| protocol| source address| traffic-class| version}

no match ipv6 {destination address| protocol| source address| traffic-class| version}

Syntax Description

destination address	Configures the IPv4 destination address as a key field. For more information see match ipv6 destination address, on page 929 .
protocol	Configures the IPv6 protocol as a key field.
source address	Configures the IPv4 destination address as a key field. For more information see match ipv6 source address, on page 931 .

Command Default

The IPv6 fields are not configured as a key field.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples

The following example configures the IPv6 protocol field as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match ipv6 protocol
```

match ipv6 destination address

To configure the IPv6 destination address as a key field for a flow record, use the **match ipv6 destination address** command in flow record configuration mode. To disable the IPv6 destination address as a key field for a flow record, use the **no** form of this command.

match ipv6 destination address

no match ipv6 destination address

Syntax Description This command has no arguments or keywords.

Command Default The IPv6 destination address is not configured as a key field.

Command Modes Flow record configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

To return this command to its default settings, use the **no match ipv6 destination address** or **default match ipv6 destination address** flow record configuration command.

Examples The following example configures the IPv6 destination address as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match ipv6 destination address
```

match ipv6 hop-limit

To configure the IPv6 hop limit as a key field for a flow record, use the **match ipv6 hop-limit** command in flow record configuration mode. To disable the use of a section of an IPv6 packet as a key field for a flow record, use the **no** form of this command.

match ipv6 hop-limit

no match ipv6 hop-limit

Syntax Description This command has no arguments or keywords.

Command Default The use of the IPv6 hop limit as a key field for a user-defined flow record is not enabled by default.

Command Modes Flow record configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples The following example configures the hop limit of the packets in the flow as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match ipv6 hop-limit
```

match ipv6 source address

To configure the IPv6 source address as a key field for a flow record, use the **match ipv6 source address** command in flow record configuration mode. To disable the use of the IPv6 source address as a key field for a flow record, use the **no** form of this command.

match ipv6 source address

no match ipv6 source address

Syntax Description This command has no arguments or keywords.

Command Default The IPv6 source address is not configured as a key field.

Command Modes Flow record configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

To return this command to its default settings, use the **no match ipv6 source address** or **default match ipv6 source address** flow record configuration command.

Examples The following example configures a IPv6 source address as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match ipv6 source address
```

match transport

To configure one or more of the transport fields as a key field for a flow record, use the **match transport** command in flow record configuration mode. To disable the use of one or more of the transport fields as a key field for a flow record, use the **no** form of this command.

Syntax Description

destination-port	Configures the transport destination port as a key field.
source-port	Configures the transport source port as a key field.

Command Default

The transport fields are not configured as a key field.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples

The following example configures the destination port as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match transport destination-port
```

The following example configures the source port as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match transport source-port
```

match transport icmp ipv4

To configure the ICMP IPv4 type field and the code field as key fields for a flow record, use the **match transport icmp ipv4** command in flow record configuration mode. To disable the use of the ICMP IPv4 type field and code field as key fields for a flow record, use the **no** form of this command.

```
match transport icmp ipv4 {code| type}
```

```
no match transport icmp ipv4 {code| type}
```

Syntax Description

code	Configures the IPv4 ICMP code as a key field.
type	Configures the IPv4 ICMP type as a key field.

Command Default

The ICMP IPv4 type field and the code field are not configured as key fields.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples

The following example configures the IPv4 ICMP code field as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match transport icmp ipv4 code
```

The following example configures the IPv4 ICMP type field as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match transport icmp ipv4 type
```

match transport icmp ipv6

To configure the ICMP IPv6 type field and the code field as key fields for a flow record, use the **match transport icmp ipv6** command in flow record configuration mode. To disable the use of the ICMP IPv6 type field and code field as key fields for a flow record, use the **no** form of this command.

match transport icmp ipv6 {code| type}

no match transport icmp ipv6 {code| type}

Syntax Description

code	Configures the IPv6 ICMP code as a key field.
type	Configures the IPv6 ICMP type as a key field.

Command Default

The ICMP IPv6 type field and the code field are not configured as key fields.

Command Modes

Flow record configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A flow record requires at least one key field before it can be used in a flow monitor. The key fields distinguish flows, with each flow having a unique set of values for the key fields. The key fields are defined using the **match** command.

Examples

The following example configures the IPv6 ICMP code field as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match transport icmp ipv6 code
```

The following example configures the IPv6 ICMP type field as a key field:

```
Controller(config)# flow record FLOW-RECORD-1
Controller(config-flow-record)# match transport icmp ipv6 type
```

mode random 1 out-of

To enable random sampling and to specify the packet interval for a sampler, use the **mode random 1 out-of** command in sampler configuration mode. To remove the packet interval information for a sampler, use the **no** form of this command.

mode random 1 out-of *window-size*

no mode

Syntax Description

<i>window-size</i>	Specifies the window size from which to select packets. The range is 2 to 1024.
--------------------	---

Command Default

The mode and the packet interval for a sampler are not configured.

Command Modes

Sampler configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A total of four unique samplers are supported on the controller. Packets are chosen in a manner that should eliminate any bias from traffic patterns and counter any attempt by users to avoid monitoring.



Note

The **deterministic** keyword is not supported, even though it is visible in the command-line help string.

Examples

The following example enables random sampling with a window size of 1000:

```
Controller(config)# sampler SAMPLER-1
Controller(config-sampler)# mode random 1 out-of 1000
```

option

To configure optional data parameters for a flow exporter for , use the **option** command in flow exporter configuration mode. To remove optional data parameters for a flow exporter, use the **no** form of this command.

option {**exporter-stats**| **interface-table**| **sampler-table**} [**timeout** *seconds*]

no option {**exporter-stats**| **interface-table**| **sampler-table**}

Syntax Description

exporter-stats	Configures the exporter statistics option for flow exporters.
interface-table	Configures the interface table option for flow exporters.
sampler-table	Configures the export sampler table option for flow exporters.
timeout <i>seconds</i>	(Optional) Configures the option resend time in seconds for flow exporters. The range is 1 to 86400. The default is 600.

Command Default

The timeout is 600 seconds. All other optional data parameters are not configured.

Command Modes

Flow exporter configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.
Cisco IOS XE 3.3SE	The application-table and usermac-table keywords were added.

Usage Guidelines

The **option exporter-stats** command causes the periodic sending of the exporter statistics, including the number of records, bytes, and packets sent. This command allows the collector to estimate packet loss for the export records it receives. The optional timeout alters the frequency at which the reports are sent.

The **option interface-table** command causes the periodic sending of an options table, which allows the collector to map the interface SNMP indexes provided in the flow records to interface names. The optional timeout can alter the frequency at which the reports are sent.

The **option sampler-table** command causes the periodic sending of an options table, which details the configuration of each sampler and allows the collector to map the sampler ID provided in any flow record to a configuration that it can use to scale up the flow statistics. The optional timeout can alter the frequency at which the reports are sent.

To return this command to its default settings, use the **no option** or **default option** flow exporter configuration command.

Examples

The following example shows how to enable the periodic sending of the sampler option table, which allows the collector to map the sampler ID to the sampler type and rate:

```
Controller(config)# flow exporter FLOW-EXPORTER-1
Controller(config-flow-exporter)# option sampler-table
```

The following example shows how to enable the periodic sending of the exporter statistics, including the number of records, bytes, and packets sent:

```
Controller(config)# flow exporter FLOW-EXPORTER-1
Controller(config-flow-exporter)# option exporter-stats
```

The following example shows how to enable the periodic sending of an options table, which allows the collector to map the interface SNMP indexes provided in the flow records to interface names:

```
Controller(config)# flow exporter FLOW-EXPORTER-1
Controller(config-flow-exporter)# option interface-table
```

record

To add a flow record for a flow monitor, use the **record** command in flow monitor configuration mode. To remove a flow record for a flow monitor, use the **no** form of this command.

record *record-name*

no record

Syntax Description

<i>record-name</i>	Name of a user-defined flow record that was previously configured.
--------------------	--

Command Default

A flow record is not configured.

Command Modes

Flow monitor configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Each flow monitor requires a record to define the contents and layout of its cache entries. The flow monitor can use one of the wide range of predefined record formats, or advanced users may create their own record formats.



Note

You must use the **no ip flow monitor** command to remove a flow monitor from all of the interfaces to which you have applied it before you can modify the parameters for the **record** command for the flow monitor.

Examples

The following example configures the flow monitor to use FLOW-RECORD-1:

```
Controller(config)# flow monitor FLOW-MONITOR-1
Controller(config-flow-monitor)# record FLOW-RECORD-1
```

sampler

To create a flow sampler, or to modify an existing flow sampler, and to enter sampler configuration mode, use the **sampler** command in global configuration mode. To remove a sampler, use the **no** form of this command.

sampler *sampler-name*

no sampler *sampler-name*

Syntax Description

<i>sampler-name</i>	Name of the flow sampler that is being created or modified.
---------------------	---

Command Default

flow samplers are not configured.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Flow samplers are used to reduce the load placed by on the networking device to monitor traffic by limiting the number of packets that are analyzed. You configure a rate of sampling that is 1 out of a range of packets. Flow samplers are applied to interfaces in conjunction with a flow monitor to implement sampled .

To enable flow sampling, you configure the record that you want to use for traffic analysis and assign it to a flow monitor. When you apply a flow monitor with a sampler to an interface, the sampled packets are analyzed at the rate specified by the sampler and compared with the flow record associated with the flow monitor. If the analyzed packets meet the criteria specified by the flow record, they are added to the flow monitor cache.

Examples

The following example creates a flow sampler name SAMPLER-1:

```
Controller(config)# sampler SAMPLER-1
Controller(config-sampler)#
```

show flow exporter

To display flow exporter status and statistics, use the **show flow exporter** command in privileged EXEC mode.

show flow exporter [**export-ids netflow-v9**] [**name**] *exporter-name* [**statistics**| **templates**]| **statistics**| **templates**]

Syntax Description

export-ids netflow-v9	(Optional) Displays the NetFlow Version 9 export fields that can be exported and their IDs.
name	(Optional) Specifies the name of a flow exporter.
<i>exporter-name</i>	(Optional) Name of a flow exporter that was previously configured.
statistics	(Optional) Displays statistics for all flow exporters or for the specified flow exporter.
templates	(Optional) Displays template information for all flow exporters or for the specified flow exporter.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following example displays the status and statistics for all of the flow exporters configured on a controller:

```
Controller# show flow exporter
Flow Exporter FLOW-EXPORTER-1:
  Description:           Exports to the datacenter
  Export protocol:       NetFlow Version 9
  Transport Configuration:
    Destination IP address: 192.168.0.1
    Source IP address:     192.168.0.2
    Transport Protocol:    UDP
    Destination Port:      9995
    Source Port:           55864
    DSCP:                  0x0
    TTL:                   255
    Output Features:       Used
```

This table describes the significant fields shown in the display:

Table 22: show flow exporter Field Descriptions

Field	Description
Flow Exporter	The name of the flow exporter that you configured.
Description	The description that you configured for the exporter, or the default description User defined.
Transport Configuration	The transport configuration fields for this exporter.
Destination IP address	The IP address of the destination host.
Source IP address	The source IP address used by the exported packets.
Transport Protocol	The transport layer protocol used by the exported packets.
Destination Port	The destination UDP port to which the exported packets are sent.
Source Port	The source UDP port from which the exported packets are sent.
DSCP	The differentiated services code point (DSCP) value.
TTL	The time-to-live value.
Output Features	Specifies whether the output-features command, which causes the output features to be run on Flexible NetFlow export packets, has been used or not.

The following example displays the status and statistics for all of the flow exporters configured on a controller:

```

Controller# show flow exporter name FLOW-EXPORTER-1 statistics
Flow Exporter FLOW-EXPORTER-1:
  Packet send statistics (last cleared 2w6d ago):
    Successfully sent:          0          (0 bytes)

```

show flow interface

To display the configuration and status for an interface, use the **show flow interface** command in privileged EXEC mode.

show flow interface [*type number*]

Syntax Description

<i>type</i>	(Optional) The type of interface on which you want to display accounting configuration information.
<i>number</i>	(Optional) The number of the interface on which you want to display accounting configuration information.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following example displays the accounting configuration on Ethernet interfaces 0/0 and 0/1:

```
Controller# show flow interface gigabitethernet1/0/1

Interface Ethernet1/0
  monitor:          FLOW-MONITOR-1
  direction:        Output
  traffic(ip):      on
Controller# show flow interface gigabitethernet1/0/2
Interface Ethernet0/0
  monitor:          FLOW-MONITOR-1
  direction:        Input
  traffic(ip):      sampler SAMPLER-2#
```

The table below describes the significant fields shown in the display.

Table 23: show flow interface Field Descriptions

Field	Description
Interface	The interface to which the information applies.
monitor	The name of the flow monitor that is configured on the interface.

Field	Description
direction:	<p>The direction of traffic that is being monitored by the flow monitor.</p> <p>The possible values are:</p> <ul style="list-style-type: none">• Input—Traffic is being received by the interface.• Output—Traffic is being transmitted by the interface.
traffic(ip)	<p>Indicates if the flow monitor is in normal mode or sampler mode.</p> <p>The possible values are:</p> <ul style="list-style-type: none">• on—The flow monitor is in normal mode.• sampler—The flow monitor is in sampler mode (the name of the sampler will be included in the display).

show flow monitor

To display the status and statistics for a flow monitor, use the **show flow monitor** command in privileged EXEC mode.

Syntax Description

name	(Optional) Specifies the name of a flow monitor.
<i>monitor-name</i>	(Optional) Name of a flow monitor that was previously configured.
cache	(Optional) Displays the contents of the cache for the flow monitor.
format	(Optional) Specifies the use of one of the format options for formatting the display output.
csv	(Optional) Displays the flow monitor cache contents in comma-separated variables (CSV) format.
record	(Optional) Displays the flow monitor cache contents in record format.
table	(Optional) Displays the flow monitor cache contents in table format.
statistics	(Optional) Displays the statistics for the flow monitor.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **cache** keyword uses the record format by default.

The uppercase field names in the display output of the **show flowmonitor monitor-name cache** command are key fields that uses to differentiate flows. The lowercase field names in the display output of the **show flow monitor monitor-name cache** command are nonkey fields from which collects values as additional data for the cache.

Examples

The following example displays the status for a flow monitor:

```
Controller# show flow monitor FLOW-MONITOR-1

Flow Monitor FLOW-MONITOR-1:
  Description:      Used for basic traffic analysis
  Flow Record:     flow-record-1
  Flow Exporter:   flow-exporter-1
                  flow-exporter-2
  Cache:
```

```

Type:          normal
Status:        allocated
Size:          4096 entries / 311316 bytes
Inactive Timeout: 15 secs
Active Timeout: 1800 secs

```

This table describes the significant fields shown in the display.

Table 24: show flow monitor monitor-name Field Descriptions

Field	Description
Flow Monitor	Name of the flow monitor that you configured.
Description	Description that you configured or the monitor, or the default description User defined.
Flow Record	Flow record assigned to the flow monitor.
Flow Exporter	Exporters that are assigned to the flow monitor.
Cache	Information about the cache for the flow monitor.
Type	Flow monitor cache type. The value is always normal, as it is the only supported cache type.
Status	Status of the flow monitor cache. The possible values are: <ul style="list-style-type: none"> • allocated—The cache is allocated. • being deleted—The cache is being deleted. • not allocated—The cache is not allocated.
Size	Current cache size.
Inactive Timeout	Current value for the inactive timeout in seconds.
Active Timeout	Current value for the active timeout in seconds.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1:

This table describes the significant fields shown in the display.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1 in a table format:

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-IPv6 (the cache contains IPv6 data) in record format:

The following example displays the status and statistics for a flow monitor:

show flow record

To display the status and statistics for a flow record, use the **show flow record** command in privileged EXEC mode.

show flow record *[[name] record-name]*

Syntax Description

name	(Optional) Specifies the name of a flow record.
<i>record-name</i>	(Optional) Name of a user-defined flow record that was previously configured.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following example displays the status and statistics for FLOW-RECORD-1:

```
Controller# show flow record FLOW-RECORD-1
flow record FLOW-RECORD-1:
  Description:      User defined
  No. of users:    0
  Total field space: 24 bytes
  Fields:
    match ipv6 destination address
    match transport source-port
    collect interface input
```

show sampler

To display the status and statistics for a sampler, use the **show sampler** command in privileged EXEC mode.

show sampler *[[name] sampler-name]*

Syntax Description	
name	(Optional) Specifies the name of a sampler.
<i>sampler-name</i>	(Optional) Name of a sampler that was previously configured.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

The following example displays the status and statistics for all of the flow samplers configured:

```

Controller# show sampler
Sampler SAMPLER-1:
  ID:                2083940135
  export ID:         0
  Description:       User defined
  Type:              Invalid (not in use)
  Rate:              1 out of 32
  Samples:           0
  Requests:          0
  Users (0):

Sampler SAMPLER-2:
  ID:                3800923489
  export ID:         1
  Description:       User defined
  Type:              random
  Rate:              1 out of 100
  Samples:           1
  Requests:          124
  Users (1):
    flow monitor FLOW-MONITOR-1 (datalink,vlan1) 0 out of 0

```

This table describes the significant fields shown in the display.

Table 25: show sampler Field Descriptions

Field	Description
ID	ID number of the flow sampler.

Field	Description
Export ID	ID of the flow sampler export.
Description	Description that you configured for the flow sampler, or the default description User defined.
Type	Sampling mode that you configured for the flow sampler.
Rate	Window size (for packet selection) that you configured for the flow sampler. The range is 2 to 32768.
Samples	Number of packets sampled since the flow sampler was configured or the controller was restarted. This is equivalent to the number of times a positive response was received when the sampler was queried to determine if the traffic needed to be sampled. See the explanation of the Requests field in this table.
Requests	Number of times the flow sampler was queried to determine if the traffic needed to be sampled.
Users	Interfaces on which the flow sampler is configured.

source

To configure the source IP address interface for all of the packets sent by a flow exporter, use the **source** command in flow exporter configuration mode. To remove the source IP address interface for all of the packets sent by a flow exporter, use the **no** form of this command.

source *interface-type interface-number*

no source

Syntax Description

<i>interface-type</i>	Type of interface whose IP address you want to use for the source IP address of the packets sent by a flow exporter.
<i>interface-number</i>	Interface number whose IP address you want to use for the source IP address of the packets sent by a flow exporter.

Command Default

The IP address of the interface over which the datagram is transmitted is used as the source IP address.

Command Modes

Flow exporter configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The benefits of using a consistent IP source address for the datagrams that sends include the following:

- The source IP address of the datagrams exported by is used by the destination system to determine from which controller the data is arriving. If your network has two or more paths that can be used to send datagrams from the controller to the destination system and you do not specify the source interface from which the source IP address is to be obtained, the controller uses the IP address of the interface over which the datagram is transmitted as the source IP address of the datagram. In this situation the destination system might receive datagrams from the same controller, but with different source IP addresses. When the destination system receives datagrams from the same controller with different source IP addresses, the destination system treats the datagrams as if they were being sent from different controllers. To avoid having the destination system treat the datagrams as if they were being sent from different controllers, you must configure the destination system to aggregate the datagrams it receives from all of the possible source IP addresses in the controller into a single flow.
- If your controller has multiple interfaces that can be used to transmit datagrams to the destination system, and you do not configure the **source** command, you will have to add an entry for the IP address of each interface into any access lists that you create for permitting traffic. Creating and maintaining access lists for permitting traffic from known sources and blocking it from unknown sources is easier when

you limit the source IP address for datagrams to a single IP address for each controller that is exporting traffic.

**Caution**

The interface that you configure as the **source** interface must have an IP address configured, and it must be up.

**Tip**

When a transient outage occurs on the interface that you configured with the **source** command, the exporter reverts to the default behavior of using the IP address of the interface over which the datagrams are being transmitted as the source IP address for the datagrams. To avoid this problem, use a loopback interface as the source interface because loopback interfaces are not subject to the transient outages that can occur on physical interfaces.

To return this command to its default settings, use the **no source** or **default source** flow exporter configuration command.

Examples

The following example shows how to configure to use a loopback interface as the source interface for NetFlow traffic:

```
Controller(config)# flow exporter FLOW-EXPORTER-1
Controller(config-flow-exporter)# source loopback 0
```

template data timeout

To specify a timeout period for resending flow exporter template data, use the **template data timeout** command in flow exporter configuration mode. To remove the template resend timeout for a flow exporter, use the **no** form of this command.

template data timeout *seconds*

no template data timeout *seconds*

Syntax Description

<i>seconds</i>	Timeout value in seconds. The range is 1 to 86400. The default is 600.
----------------	--

Command Default

The default template resend timeout for a flow exporter is 600 seconds.

Command Modes

Flow exporter configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Flow exporter template data describes the exported data records. Data records cannot be decoded without the corresponding template. The **template data timeout** command controls how often those templates are exported.

To return this command to its default settings, use the **no template data timeout** or **default template data timeout** flow record exporter command.

Examples

The following example configures resending templates based on a timeout of 1000 seconds:

```
Controller(config)# flow exporter FLOW-EXPORTER-1
Controller(config-flow-exporter)# template data timeout 1000
```

transport

To configure the transport protocol for a flow exporter for , use the **transport** command in flow exporter configuration mode. To remove the transport protocol for a flow exporter, use the **no** form of this command.

transport udp *udp-port*

no transport udp *udp-port*

Syntax Description

udp <i>udp-port</i>	Specifies User Datagram Protocol (UDP) as the transport protocol and the UDP port number.
----------------------------	---

Command Default

Flow exporters use UDP on port 9995.

Command Modes

Flow exporter configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

To return this command to its default settings, use the **no transport** or **default transport flow exporter** configuration command.

Examples

The following example configures UDP as the transport protocol and a UDP port number of 250:

```
Controller(config)# flow exporter FLOW-EXPORTER-1
Controller(config-flow-exporter)# transport udp 250
```

ttl

To configure the time-to-live (TTL) value, use the **ttl** command in flow exporter configuration mode. To remove the TTL value, use the **no** form of this command.

ttl *ttl*

no ttl *ttl*

Syntax Description	<i>ttl</i>	Time-to-live (TTL) value for exported datagrams. The range is 1 to 255. The default is 255.
---------------------------	------------	---

Command Default Flow exporters use a TTL of 255.

Command Modes Flow exporter configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines To return this command to its default settings, use the **no ttl** or **default ttl** flow exporter configuration command.

Examples The following example specifies a TTL of 15:

```
Controller(config)# flow exporter FLOW-EXPORTER-1
Controller(config-flow-exporter)# ttl 15
```




PART **XVI**

High Availability

- [High Availability Commands, page 957](#)



High Availability Commands

- [debug platform stack-manager](#), page 958
- [main-cpu](#), page 959
- [mode sso](#), page 960
- [policy config-sync prc reload](#), page 961
- [redundancy](#), page 962
- [redundancy config-sync mismatched-commands](#), page 963
- [redundancy force-switchover](#), page 965
- [redundancy reload](#), page 966
- [reload](#), page 967
- [session](#), page 969
- [show platform stack-manager](#), page 970
- [show redundancy](#), page 971
- [show redundancy config-sync](#), page 975
- [show switch](#), page 977
- [stack-mac persistent timer](#), page 978
- [stack-mac update force](#), page 979
- [standby console enable](#), page 980
- [switch stack port](#), page 981
- [switch priority](#), page 983
- [switch provision](#), page 984
- [switch renumber](#), page 986

debug platform stack-manager

To enable debugging of the stack manager software, use the **debug platform stack-manager** command in privileged EXEC mode. To disable debugging, use the **no** form of this command.

debug platform stack-manager {all|rpc|sdp|sim|ssm|trace}

no debug platform stack-manager {all|rpc|sdp|sim|ssm|trace}

Syntax Description

all	Displays all stack manager debug messages.
rpc	Displays stack manager remote procedure call (RPC) usage debug messages.
sdp	Displays the Stack Discovery Protocol (SDP) debug messages.
sim	Displays the stack information module debug messages.
ssm	Displays the stack state-machine debug messages.
trace	Traces the stack manager entry and exit debug messages.

Command Default

Debugging is disabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

This command is supported only on stacking-capable switches.

The **undebug platform stack-manager** command is the same as the **no debug platform stack-manager** command.

When you enable debugging on a switch stack, it is enabled only on the stack master. To enable debugging on a stack member, you can start a session from the stack master by using the **session switch-number** EXEC command. Enter the **debug** command at the command-line prompt of the stack member. You also can use the **remote command stack-member-number LINE** EXEC command on the stack master switch to enable debugging on a member switch without first starting a session.

main-cpu

To enter the redundancy main configuration submode and enable the standby switch, use the **main-cpu** command in redundancy configuration mode.

main-cpu

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Redundancy configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines From the redundancy main configuration submode, use the **standby console enable** command to enable the standby switch.

Examples This example shows how to enter the redundancy main configuration submode and enable the standby switch:

```
Controller(config)# redundancy
Controller(config-red)# main-cpu
Controller(config-r-mc)# standby console enable
Controller#
```

mode sso

To set the redundancy mode to stateful switchover (SSO), use the **mode sso** command in redundancy configuration mode.

mode sso

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Redundancy configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The **mode sso** command can be entered only from within redundancy configuration mode.

Follow these guidelines when configuring your system to SSO mode:

- You must use identical Cisco IOS images on the switches in the stack to support SSO mode. Redundancy may not work due to differences between the Cisco IOS releases.
- If you perform an online insertion and removal (OIR) of the module, the switch resets during the stateful switchover and the port states are restarted only if the module is in a transient state (any state other than Ready).
- The forwarding information base (FIB) tables are cleared on a switchover. Routed traffic is interrupted until route tables reconverge.

Examples

This example shows how to set the redundancy mode to SSO:

```
Controller(config)# redundancy
Controller(config-red)# mode sso
Controller(config-red)#
```

policy config-sync prc reload

To reload the standby switch if a parser return code (PRC) failure occurs during configuration synchronization, use the **policy config-sync reload** command in redundancy configuration mode. To specify that the standby switch is not reloaded if a parser return code (PRC) failure occurs, use the **no** form of this command.

policy config-sync {bulk| lbl} prc reload

no policy config-sync {bulk| lbl} prc reload

Syntax Description

bulk	Specifies bulk configuration mode.
lbl	Specifies line-by-line (lbl) configuration mode.

Command Default

The command is enabled by default.

Command Modes

Redundancy configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to specify that the standby switch is not reloaded if a parser return code (PRC) failure occurs during configuration synchronization:

```
Controller(config-red)# no policy config-sync bulk prc reload
```

redundancy

To enter redundancy configuration mode, use the **redundancy** command in global configuration mode.

redundancy

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines The redundancy configuration mode is used to enter the main CPU submode, which is used to enable the standby switch.

To enter the main CPU submode, use the **main-cpu** command while in redundancy configuration mode.

From the main CPU submode, use the **standby console enable** command to enable the standby switch.

Use the **exit** command to exit redundancy configuration mode.

Examples This example shows how to enter redundancy configuration mode:

```
Controller(config)# redundancy
Controller(config-red)#
```

This example shows how to enter the main CPU submode:

```
Controller(config)# redundancy
Controller(config-red)# main-cpu
Controller(config-r-mc)#
```

redundancy config-sync mismatched-commands

To allow the standby switch to join the stack if a configuration mismatch occurs between the active and standby switches, use the **redundancy config-sync mismatched-commands** command in privileged EXEC mode.

redundancy config-sync {ignore| validate} mismatched-commands

Syntax Description

ignore	Ignores the mismatched command list.
validate	Revalidates the mismatched command list with the modified running-configuration.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

If the command syntax check in the running configuration of the active switch fails while the standby switch is booting, use the **redundancy config-sync mismatched-commands** command to display the Mismatched Command List (MCL) on the active switch and to reboot the standby switch.

The following is a log entry example for mismatched commands:

```
00:06:31: Config Sync: Bulk-sync failure due to Servicing Incompatibility. Please check
full list of mismatched commands via:
show redundancy config-sync failures mcl
00:06:31: Config Sync: Starting lines from MCL file:
interface GigabitEthernet7/7
! <submode> "interface"
- ip address 192.0.2.0 255.255.255.0
! </submode> "interface"
```

To display all mismatched commands, use the **show redundancy config-sync failures mcl** command.

To clean the MCL, follow these steps:

- 1 Remove all mismatched commands from the running configuration of the active switch.
- 2 Revalidate the MCL with a modified running configuration by using the **redundancy config-sync validate mismatched-commands** command.
- 3 Reload the standby switch.

You can ignore the MCL by doing the following:

- 1 Enter the **redundancy config-sync ignore mismatched-commands** command.
- 2 Reload the standby switch; the system changes to SSO mode.



Note If you ignore the mismatched commands, the out-of-sync configuration at the active switch and the standby switch still exists.

- 3 Verify the ignored MCL with the **show redundancy config-sync ignored mcl** command.

If SSO mode cannot be established between the active and standby switches because of an incompatibility in the configuration file, a mismatched command list (MCL) is generated at the active switch and a reload into route processor redundancy (RPR) mode is forced for the standby switch.



Note RPR mode is supported on Catalyst 3850 switches as a fallback in case of errors. It is not configurable.

If you attempt to establish an SSO after removing the offending configuration and rebooting the standby switch with the same image, the C3K_REDUNDANCY-2-IOS_VERSION_CHECK_FAIL and ISSU-3-PEER_IMAGE_INCOMPATIBLE messages appear because the peer image is listed as incompatible. You can clear the peer image from the incompatible list with the **redundancy config-sync ignore mismatched-commands EXEC** command while the peer is in a standby cold (RPR) state. This action allows the standby switch to boot in a standby hot (SSO) state when it reloads.

Examples

This example shows how to revalidate the mismatched command list with the modified configuration:

```
Controller# redundancy config-sync validate mismatched-commands
Controller#
```

redundancy force-switchover

To force a switchover from the active switch to the standby switch, use the **redundancy force-switchover** command in privileged EXEC mode on a switch stack.

redundancy force-switchover

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Use the **redundancy force-switchover** command to manually switch over to the redundant switch. The redundant switch becomes the new active switch that runs the Cisco IOS image, and the modules are reset to their default settings.

The old active switch reboots with the new image and joins the stack.

If you use the **redundancy force-switchover** command on the active switch, the switchports on the active switch go down.

If you use this command on a switch that is in a partial ring stack, the following warning message appears:

```
Controller# redundancy force-switchover
Stack is in Half ring setup; Reloading a switch might cause stack split
This will reload the active unit and force switchover to standby[confirm]
```

Examples This example shows how to manually switch over from the active to the standby supervisor engine:

```
Controller# redundancy force-switchover
Controller#
```

redundancy reload

To force a reload of one or all of the switches in the stack, use the **redundancy reload** command in privileged EXEC mode.

redundancy reload {peer| shelf}

Syntax Description

peer	Reloads the peer unit.
shelf	Reboots all switches in the stack.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Before using this command, see the “Performing a Software Upgrade” section of the *Stack Manager Configuration Guide (Platform—Cisco WLC 5700 Series)* for additional information.

Use the **redundancy reload shelf** command to reboot all the switches in the stack.

Examples

This example shows how to manually reload all switches in the stack:

```
Controller# redundancy reload shelf
Controller#
```

reload

To reload the stack member and to apply a configuration change, use the **reload** command in privileged EXEC mode.

reload [/noverify|/verify] [*LINE*] at|cancel|in|slot *stack-member-number*|standby-cpu]

Syntax Description

/noverify	(Optional) Specifies to not verify the file signature before the reload.
/verify	(Optional) Verifies the file signature before the reload.
<i>LINE</i>	(Optional) Reason for the reload.
at	(Optional) Specifies the time in hh:mm for the reload to occur.
cancel	(Optional) Cancels the pending reload.
in	(Optional) Specifies a time interval for reloads to occur.
slot	(Optional) Saves the changes on the specified stack member and then restarts it.
<i>stack-member-number</i>	
standby-cpu	(Optional) Reloads the standby route processor (RP).

Command Default

Immediately reloads the stack member and puts a configuration change into effect.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

If there is more than one switch in the switch stack, and you enter the **reload slot** *stack-member-number* command, you are not prompted to save the configuration.

Examples

This example shows how to reload the switch stack:

```
Controller# reload
System configuration has been modified. Save? [yes/no]: y
Proceed to reload the whole Stack? [confirm] y
```

This example shows how to reload a specific stack member:

```
Controller# reload slot 6  
Proceed with reload? [confirm] y
```

This example shows how to reload a single-switch switch stack (there is only one member switch):

```
Controller# reload slot 3  
System configuration has been modified. Save? [yes/no]: y  
Proceed to reload the whole Stack? [confirm] y
```

session

To access a specific stack member use the **session** command in privileged EXEC mode on the stack master.

session *stack-member-number*

Syntax Description

<i>stack-member-number</i>	Stack member number to access from the .
----------------------------	--

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

When you access the member, its member number is appended to the system prompt.

Use the **session** command from the master to access a member Controller

Use the **session** command with **processor 1** from the master or a standalone switch to access the internal controller. A standalone Controller is always member 1.

Examples

This example shows how to access stack member 3:

```
Controller# session 3
Controller-3#
```

show platform stack-manager

To display platform-dependent switch-stack information, use the **show platform stack-manager** command in privileged EXEC mode.

show platform stack-manager {**oir-states**|**sdp-counters**|**sif-counters**} **switch** *stack-member-number*

Syntax Description

oir-states	Displays Online Insertion and Removal (OIR) state information
sdp-counters	Displays Stack Discovery Protocol (SDP) counter information.
sif-counters	Displays Stack Interface (SIF) counter information.
switch <i>stack-member-number</i>	Specifies the stack member for which to display stack-manager information.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Use the **show platform stack-manager** command to collect data and statistics for the switch stack.

Use this command only when you are working directly with your technical support representative while troubleshooting a problem. Do not use this command unless your technical support representative asks you to do so.

show redundancy

To display redundancy facility information, use the **show redundancy** command in privileged EXEC mode

```
show redundancy [clients| config-sync| counters| history [reload| reverse]] slaves[slave-name] {clients|
counters}| states| switchover history [domain default]]
```

Syntax Description

clients	(Optional) Displays information about the redundancy facility client.
config-sync	(Optional) Displays a configuration synchronization failure or the ignored mismatched command list (MCL). For more information, see show redundancy config-sync , on page 975.
counters	(Optional) Displays information about the redundancy facility counter.
history	(Optional) Displays a log of past status and related information for the redundancy facility.
history reload	(Optional) Displays a log of past reload information for the redundancy facility.
history reverse	(Optional) Displays a reverse log of past status and related information for the redundancy facility.
slaves	(Optional) Displays all slaves in the redundancy facility.
<i>slave-name</i>	(Optional) The name of the redundancy facility slave to display specific information for. Enter additional keywords to display all clients or counters in the specified slave.
clients	Displays all redundancy facility clients in the specified slave.
counters	Displays all counters in the specified slave.
states	(Optional) Displays information about the redundancy facility state, such as disabled, initialization, standby or active.
switchover history	(Optional) Displays information about the redundancy facility switchover history.
domain default	(Optional) Displays the default domain as the domain to display switchover history for.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display information about the redundancy facility:

```

Controller# show redundancy
Redundant System Information :
-----
    Available system uptime = 6 days, 9 hours, 23 minutes
Switchovers system experienced = 0
    Standby failures = 0
    Last switchover reason = not known

    Hardware Mode = Simplex
Configured Redundancy Mode = SSO
Operating Redundancy Mode = SSO
Maintenance Mode = Disabled
Communications = Down          Reason: Simplex mode

Current Processor Information :
-----
    Active Location = slot 1
    Current Software state = ACTIVE
    Uptime in current state = 6 days, 9 hours, 23 minutes
    Image Version = Cisco IOS Software, IOS-XE Software, Catalyst 3
850 L3 Switch Software (CAT3850-UNIVERSALK9-M), Version 03.08.59.EMD EARLY DEPLO
YMENT ENGINEERING NOVA_WEEKLY BUILD, synced to DSGS_PI2_POSTPC_FLO_DSBU7_NG3K_11
05
Copyright (c) 1986-2012 by Cisco Systems, Inc.
Compiled Sun 16-S
    Configuration register = 0x102

Peer (slot: 0) information is not available because it is in 'DISABLED' state
Controller#

```

This example shows how to display redundancy facility client information:

```

Controller# show redundancy clients
Group ID = 1
clientID = 20002   clientSeq = 4   EICORE HA Client
clientID = 24100   clientSeq = 5   WCM_CAPWAP
clientID = 24101   clientSeq = 6   WCM_RRM HA
clientID = 24103   clientSeq = 8   WCM_QOS HA
clientID = 24105   clientSeq = 10  WCM_MOBILITY
clientID = 24106   clientSeq = 11  WCM_DOT1X
clientID = 24107   clientSeq = 12  WCM_APPFROGUE
clientID = 24110   clientSeq = 15  WCM_CIDS
clientID = 24111   clientSeq = 16  WCM_NETFLOW
clientID = 24112   clientSeq = 17  WCM_MCAST
clientID = 24120   clientSeq = 18  wcm_comet
clientID = 24001   clientSeq = 21  Table Manager Client
clientID = 20010   clientSeq = 24  SNMP SA HA Client
clientID = 20007   clientSeq = 27  Installer HA Client
clientID = 29      clientSeq = 60  Redundancy Mode RF
clientID = 139     clientSeq = 61  IfIndex
clientID = 3300    clientSeq = 62  Persistent Variable
clientID = 25      clientSeq = 68  CHKPT RF
clientID = 20005   clientSeq = 74  IIF-shim
clientID = 10001   clientSeq = 82  QEMU Platform RF

<output truncated>

```

The output displays the following information:

- clientID displays the client's ID number.
- clientSeq displays the client's notification sequence number.
- Current redundancy facility state.

This example shows how to display the redundancy facility counter information:

```

Controller# show redundancy counters
Redundancy Facility OMs

      comm link up = 0
      comm link down = 0
      invalid client tx = 0
      null tx by client = 0
      tx failures = 0
      tx msg length invalid = 0

      client not rxing msgs = 0
      rx peer msg routing errors = 0
      null peer msg rx = 0
      errored peer msg rx = 0

      buffers tx = 0
      tx buffers unavailable = 0
      buffers rx = 0
      buffer release errors = 0

      duplicate client registers = 0
      failed to register client = 0
      Invalid client syncs = 0

```

Controller#

This example shows how to display redundancy facility history information:

```

Controller# show redundancy history
00:00:00 *my state = INITIALIZATION(2) peer state = DISABLED(1)
00:00:00 RF_EVENT_INITIALIZATION(524) op=0 rc=0
00:00:00 *my state = NEGOTIATION(3) peer state = DISABLED(1)
00:00:01 client added: Table Manager Client(24001) seq=21
00:00:01 client added: SNMP SA HA Client(20010) seq=24
00:00:06 client added: WCM_CAPWAP(24100) seq=5
00:00:06 client added: WCM_QOS HA(24103) seq=8
00:00:07 client added: WCM_DOT1X(24106) seq=11
00:00:07 client added: EICORE HA Client(20002) seq=4
00:00:09 client added: WCM_MOBILITY(24105) seq=10
00:00:09 client added: WCM_NETFLOW(24111) seq=16
00:00:09 client added: WCM_APPFROGUE(24107) seq=12
00:00:09 client added: WCM_RRM HA(24101) seq=6
00:00:09 client added: WCM_MCAST(24112) seq=17
00:00:09 client added: WCM_CIDS(24110) seq=15
00:00:09 client added: wcm_comet(24120) seq=18
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) First Slave(0) op=0 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) Slave(6107) op=0 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) Slave(6109) op=0 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) Slave(6128) op=0 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) Slave(8897) op=0 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) Slave(8898) op=0 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) Slave(8901) op=0 rc=0
00:00:22 RF_EVENT_SLAVE_STATUS_DONE(523) First Slave(0) op=405 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) Redundancy Mode RF(29) op=0 rc=0
00:00:22 RF_STATUS_REDUNDANCY_MODE_CHANGE(405) IfIndex(139) op=0 rc=0

```

<output truncated>

This example shows how to display information about the redundancy facility slaves:

```

Controller# show redundancy slaves
Group ID = 1
Slave/Process ID = 6107 Slave Name = [installer]

```

```
Slave/Process ID = 6109   Slave Name = [eicored]
Slave/Process ID = 6128   Slave Name = [snmp_subagent]
Slave/Process ID = 8897   Slave Name = [wcm]
Slave/Process ID = 8898   Slave Name = [table_mgr]
Slave/Process ID = 8901   Slave Name = [iosd]
```

Controller#

This example shows how to display information about the redundancy facility state:

```
Controller# show redundancy states
  my state = 13 -ACTIVE
  peer state = 1 -DISABLED
    Mode = Simplex
    Unit ID = 1

Redundancy Mode (Operational) = SSO
Redundancy Mode (Configured) = SSO
  Redundancy State = Non Redundant
    Manual Swact = disabled (system is simplex (no peer unit))

Communications = Down      Reason: Simplex mode

  client count = 75
  client_notification_TMR = 360000 milliseconds
  keep_alive TMR = 9000 milliseconds
  keep_alive count = 0
  keep_alive threshold = 18
  RF debug mask = 0

Controller#
```

show redundancy config-sync

To display a configuration synchronization failure or the ignored mismatched command list (MCL), if any, use the **show redundancy config-sync** command in EXEC mode.

show redundancy config-sync {failures {bem| mcl| prc}| ignored failures mcl}

Syntax Description

failures	Displays MCL entries or best effort method (BEM)/Parser Return Code (PRC) failures.
bem	Displays a BEM failed command list, and forces the standby switch to reboot.
mcl	Displays commands that exist in the switch's running configuration but are not supported by the image on the standby switch, and forces the standby switch to reboot.
prc	Displays a PRC failed command list and forces the standby switch to reboot.
ignored failures mcl	Displays the ignored MCL failures.

Command Default

None

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

When two versions of Cisco IOS images are involved, the command sets supported by two images might differ. If any of those mismatched commands are executed on the active switch, the standby switch might not recognize those commands, which causes a configuration mismatch condition. If the syntax check for the command fails on the standby switch during a bulk synchronization, the command is moved into the MCL and the standby switch is reset. To display all the mismatched commands, use the **show redundancy config-sync failures mcl** command.

To clean the MCL, follow these steps:

- 1 Remove all mismatched commands from the active switch's running configuration.
- 2 Revalidate the MCL with a modified running configuration by using the **redundancy config-sync validate mismatched-commands** command.

- 3 Reload the standby switch.

Alternatively, you could ignore the MCL by following these steps:

- 1 Enter the **redundancy config-sync ignore mismatched-commands** command.
- 2 Reload the standby switch; the system transitions to SSO mode.


Note

If you ignore the mismatched commands, the out-of-synchronization configuration on the active switch and the standby switch still exists.

- 3 You can verify the ignored MCL with the **show redundancy config-sync ignored mcl** command.

Each command sets a return code in the action function that implements the command. This return code indicates whether or not the command successfully executes. The active switch maintains the PRC after executing a command. The standby switch executes the command and sends the PRC back to the active switch. A PRC failure occurs if these two PRCs do not match. If a PRC error occurs at the standby switch either during bulk synchronization or line-by-line (LBL) synchronization, the standby switch is reset. To display all PRC failures, use the **show redundancy config-sync failures prc** command.

To display best effort method (BEM) errors, use the **show redundancy config-sync failures bem** command.

Examples

This example shows how to display the BEM failures:

```
Controller> show redundancy config-sync failures bem
BEM Failed Command List
-----

The list is Empty
```

This example shows how to display the MCL failures:

```
Controller> show redundancy config-sync failures mcl
Mismatched Command List
-----

The list is Empty
```

This example shows how to display the PRC failures:

```
Controller# show redundancy config-sync failures prc
PRC Failed Command List
-----

The list is Empty
```

show switch

To display information that is related to the stack member or the switch stack, use the **show switch** command in EXEC mode.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how to display summary stack information:

This example shows how to display detailed stack information:

This example shows how to display the member 6 summary information:

```
Controller# show switch 6
Switch#  Role      Mac Address      Priority    State
-----  -
6         Member    0003.e31a.1e00   1          Ready
```

This example shows how to display the neighbor information for a stack:

```
Controller# show switch neighbors
Switch #   Port A      Port B
-----  -
6         None       8
8         6          None
```

This example shows how to display stack-port information:

```
Controller# show switch stack-ports
Switch #   Port A      Port B
-----  -
6         Down       Ok
8         Ok        Down
```

stack-mac persistent timer

To enable the persistent MAC address feature, use the **stack-mac persistent timer** command in global configuration mode on the switch stack or on a standalone switch. To disable the persistent MAC address feature, use the **no** form of this command.

stack-mac persistent timer [**0**| *time-value*]

no stack-mac persistent timer

Syntax Description

0

time-value

(Optional) Time period in minutes before the stack MAC address changes to that of the new . The range is 1 to 60 minutes.

Command Default

Persistent MAC address is disabled. The MAC address of the stack is always that of the first .

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

stack-mac update force

To update the stack MAC address to the MAC address of the active switch, use the **stack-mac update force** command in EXEC mode on the active switch.

stack-mac update force

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes User EXEC
Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines By default, the stack MAC address is not changed to the MAC address of the new active switch during a high availability (HA) failover. Use the **stack-mac update force** command to force the stack MAC address to change to the MAC address of the new active switch.

If the switch with the same MAC address as the stack MAC address is currently a member of the stack, the **stack-mac update force** command has no effect. (It does not change the stack MAC address to the MAC address of the active switch.)



Note If you do not change the stack MAC address, Layer 3 interface flapping does not occur. It also means that a foreign MAC address (a MAC address that does not belong to any of the switches in the stack) could be the stack MAC address. If the switch with this foreign MAC address joins another stack as the active switch, two stacks will have the same stack MAC address. You must use the **stack-mac update force** command to resolve the conflict.

Examples This example shows how to update the stack MAC address to the MAC address of the active switch:

```
Controller> stack-mac update force
Controller>
```

You can verify your settings by entering the **show switch** privileged EXEC command. The stack MAC address includes whether the MAC address is local or foreign.

standby console enable

To enable access to the standby console switch, use the **standby console enable** command in redundancy main configuration submode. To disable access to the standby console switch, use the **no** form of this command.

standby console enable

no standby console enable

Syntax Description This command has no arguments or keywords.

Command Default Access to the standby console switch is disabled.

Command Modes Redundancy main configuration submode

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines This command is used to collect and review specific data about the standby console. The command is useful primarily for Cisco technical support representatives troubleshooting the switch.

Examples This example shows how to enter the redundancy main configuration submode and enable access to the standby console switch:

```
Controller(config)# redundancy
Controller(config-red)# main-cpu
Controller(config-r-mc)# standby console enable
Controller(config-r-mc)#
```

switch stack port

To disable or enable the specified stack port on the member, use the **switch** command in privileged EXEC mode on a stack member.

```
switch stack-member-number stack port port-number {disable|enable}
```

Syntax Description

<i>stack-member-number</i>	
stack port <i>port-number</i>	Specifies the stack port on the member. The range is 1 to 2.
disable	Disables the specified port.
enable	Enables the specified port.

Command Default

The stack port is enabled.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

A stack is in the full-ring state when all members are connected through the stack ports and are in the ready state.

The stack is in the partial-ring state when the following occurs:

- All members are connected through their stack ports but some are not in the ready state.
- Some members are not connected through the stack ports.



Note

Be careful when using the **switch** *stack-member-number* **stack port** *port-number* **disable** command. When you disable the stack port, the stack operates at half bandwidth.

If you enter the **switch** *stack-member-number* **stack port** *port-number* **disable** privileged EXEC command and the stack is in the full-ring state, you can disable only one stack port. This message appears:

```
Enabling/disabling a stack port may cause undesired stack changes. Continue?[confirm]
```

If you enter the **switch** *stack-member-number* **stack port** *port-number* **disable** privileged EXEC command and the stack is in the partial-ring state, you cannot disable the port. This message appears:

```
Disabling stack port not allowed with current stack configuration.
```

Examples

This example shows how to disable stack port 2 on member 4:

```
Controller# switch 4 stack port 2 disable
```

switch priority

To change the stack member priority value, use the **switch priority** command in mode on the .

switch *stack-member-number* **priority** *new-priority-value*

Syntax Description

<i>stack-member-number</i>	Current stack member number. The range is 1 to 2.
<i>new-priority-value</i>	New stack member priority value. The range is 1 to 15. The stack member with higher priority value receives high priority in the stack.

Command Default

The default priority value is 1.

Command Modes

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The new priority value is a factor when a new is elected. When you change the priority value the is not changed immediately.

Examples

This example shows how to change the priority value of stack member 6 to 8:

```
Controller switch 6 priority 8
Changing the Switch Priority of Switch Number 6 to 8
Do you want to continue?[confirm]
```

switch provision

To supply a configuration to a new switch before it joins the switch stack, use the **switch provision** command in global configuration mode on the . To delete all configuration information that is associated with the removed switch (a stack member that has left the stack), use the **no** form of this command.

switch *stack-member-number* **provision** *type*

no switch *stack-member-number* **provision**

Syntax Description

<i>stack-member-number</i>	Stack member number. The range is 1 to 2.
<i>type</i>	Switch type of the new switch before it joins the stack.

Command Default

The switch is not provisioned.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

For *type*, enter the model number of a supported switch that is listed in the command-line help strings.

To avoid receiving an error message, you must remove the specified switch from the switch stack before using the **no** form of this command to delete a provisioned configuration.

To change the switch type, you must also remove the specified switch from the switch stack. You can change the stack member number of a provisioned switch that is physically present in the switch stack if you do not also change the switch type.

If the switch type of the provisioned switch does not match the switch type in the provisioned configuration on the stack, the switch stack applies the default configuration to the provisioned switch and adds it to the stack. The switch stack displays a message when it applies the default configuration.

Provisioned information appears in the running configuration of the switch stack. When you enter the **copy running-config startup-config** privileged EXEC command, the provisioned configuration is saved in the startup configuration file of the switch stack.

**Caution**

When you use the **switch provision** command, memory is allocated for the provisioned configuration. When a new switch type is configured, the previously allocated memory is not fully released. Therefore, do not use this command more than approximately 200 times, or the switch will run out of memory and unexpected behavior will result.

Examples

This example shows how to provision a switch with a stack member number of 2 for the switch stack. The **show running-config** command output shows the interfaces associated with the provisioned switch.

```
Controller(config)# switch 2 provision WS-xxxx
Controller(config)# end
Controller# show running-config | include switch 2
!
interface GigabitEthernet2/0/1
!
interface GigabitEthernet2/0/2
!
interface GigabitEthernet2/0/3
<output truncated>
```

You also can enter the **show switch** user EXEC command to display the provisioning status of the switch stack.

This example shows how to delete all configuration information about stack member 5 when the switch is removed from the stack:

```
Controller(config)# no switch 5 provision
```

You can verify that the provisioned switch is added to or removed from the running configuration by entering the **show running-config** privileged EXEC command.

switch renumber

To change the stack member number, use the **switch renumber** command in mode on the .

switch *current-stack-member-number* **renumber** *new-stack-member-number*

Syntax Description

current-stack-member-number

new-stack-member-number

Command Default

The default stack member number is 1.

Command Modes

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

If another stack member is already using the member number that you just specified, the assigns the lowest available number when you reload the stack member.



Note

If you change the number of a stack member, and no configuration is associated with the new stack member number, that stack member loses its current configuration and resets to its default configuration.

Do not use the **switch** *current-stack-member-number* **renumber** *new-stack-member-number* command on a provisioned switch. If you do, the command is rejected.

Use the **reload slot** *current stack member number* privileged EXEC command to reload the stack member and to apply this configuration change.

Examples

This example shows how to change the member number of stack member 6 to 7:



PART **XVII**

Network Management

- [Network Management Commands, page 989](#)



Network Management Commands

- [monitor capture \(interface/control plane\), page 991](#)
- [monitor capture buffer, page 995](#)
- [monitor capture clear, page 996](#)
- [monitor capture export, page 997](#)
- [monitor capture file, page 998](#)
- [monitor capture limit, page 1000](#)
- [monitor capture match, page 1001](#)
- [monitor capture start, page 1002](#)
- [monitor capture stop, page 1003](#)
- [monitor session, page 1004](#)
- [monitor session destination, page 1006](#)
- [monitor session filter, page 1010](#)
- [monitor session source, page 1012](#)
- [show monitor, page 1015](#)
- [show monitor capture, page 1017](#)
- [snmp-server enable traps, page 1019](#)
- [snmp-server enable traps bridge, page 1023](#)
- [snmp-server enable traps call-home, page 1024](#)
- [snmp-server enable traps cpu, page 1025](#)
- [snmp-server enable traps envmon, page 1026](#)
- [snmp-server enable traps errdisable, page 1027](#)
- [snmp-server enable traps flash, page 1028](#)
- [snmp-server enable traps license, page 1029](#)
- [snmp-server enable traps mac-notification, page 1030](#)

- [snmp-server enable traps port-security, page 1031](#)
- [snmp-server enable traps power-ethernet, page 1032](#)
- [snmp-server enable traps snmp, page 1033](#)
- [snmp-server enable traps stackwise, page 1034](#)
- [snmp-server enable traps storm-control, page 1036](#)
- [snmp-server enable traps stpx, page 1037](#)
- [snmp-server enable traps transceiver, page 1038](#)
- [snmp-server enable traps vstack, page 1039](#)
- [snmp-server enable traps wireless, page 1040](#)
- [snmp-server engineID, page 1042](#)
- [snmp-server host, page 1043](#)
- [trapflags, page 1048](#)

monitor capture (interface/control plane)

To configure monitor capture points specifying an attachment point and the packet flow direction or add more attachment points to a capture point, use the **monitor capture** command in privileged EXEC mode. To disable the monitor capture with the specified attachment point and the packet flow direction or disable one of multiple attachment points on a capture point, use the **no** form of this command.

```
monitor capture {capture-name} {interface interface-type interface-id | control-plane} {in | out | both}
no monitor capture {capture-name} {interface interface-type interface-id | control-plane} {in | out | both}
```

Syntax Description

<i>capture-name</i>	The name of the capture to be defined.
interface <i>interface-type interface-id</i>	Specifies an interface with <i>interface-type</i> and <i>interface-id</i> as an attachment point. The arguments have these meanings: <ul style="list-style-type: none"> • GigabitEthernet <i>interface-id</i>—A Gigabit Ethernet IEEE 802.3z interface. • vlan <i>vlan-id</i>—A VLAN. The range for <i>vlan-id</i> is 1 to 4095. • capwap <i>capwap-id</i>—Specifies a Control and Provisioning of Wireless Access Points Protocol (CAPWAP) tunneling interface. For a list of CAPWAP tunnels that can be used as attachment points, use the show capwap summary command. <p>Note This is the only attachment point that can be used for a wireless capture. When using this interface as an attachment point, no other interface types can be used as attachment points on the same capture point.</p>
control-plane	Specifies the control plane as an attachment point.
in out both	Specifies the traffic direction to be captured.

Command Default

A Wireshark capture is not configured.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Once an attachment point has been associated with a capture point using this command, the only way to change its direction is to remove the attachment point using the **no** form of the command and reattach the attachment point with the new direction. An attachment point's direction cannot be overridden.

If an attachment point is removed from a capture point and only one attachment point is associated with it, the capture point is effectively deleted.

Multiple attachment points can be associated with a capture point by re-running this command with another attachment point. An example is provided below.

Multiple capture points can be defined, but only one can be active at a time. In other words, you have to stop one before you can start the other.

Packets captured in the output direction of an interface might not reflect the changes made by switch rewrite (includes TTL, VLAN tag, CoS, checksum, MAC addresses, DSCP, precedent, UP, etc.).

No specific order applies when defining a capture point; you can define capture point parameters in any order. The Wireshark CLI allows as many parameters as possible on a single line. This limits the number of commands required to define a capture point.

Neither VRFs, management ports, nor private VLANs can be used as attachment points.

Wireshark cannot capture packets on a destination SPAN port.

When a VLAN is used as a Wireshark attachment point, packets are captured in the input direction only.

Wireless (CAPWAP) Usage Considerations

The only form of wireless capture is a CAPWAP tunnel capture.

When capturing CAPWAP tunnels, no other interface types can be used as attachment points on the same capture point. Also, the only different type of attachment point allowed on the same capture point is the control plane. The combination of control plane and CAPWAP tunnel attachment points should be able to capture all wireless-related traffic.

Capturing multiple CAPWAP tunnels is supported. ACLs for each CAPWAP tunnel will be combined and sent to the switch as a single ACL.

Core filters will not be applied and can be omitted when capturing a CAPWAP tunnel. When control plane and CAPWAP tunnels are mixed, the core filter will not be applied on the control plane packets either.

To capture a CAPWAP non-data tunnel, capture traffic on the management VLAN and apply an appropriate ACL to filter the traffic. Note that this ACL will be combined with the core filter ACL and assigned to the switch as a single ACL.

Examples

To define a capture point using a physical interface as an attachment point:

```
Controller# monitor capture mycap interface GigabitEthernet1/0/1 in
Controller# monitor capture mycap match ipv4 any any
```

**Note**

The second command defines the core filter for the capture point. This is required for a functioning capture point unless you are using a CAPWAP tunneling attachment point in your capture point.

If you are using CAPWAP tunneling attachment points in your capture point, you cannot use core filters.

To define a capture point with multiple attachment points:

```
Controller# monitor capture mycap interface GigabitEthernet1/0/1 in
Controller# monitor capture mycap match ipv4 any any
Controller# monitor capture mycap control-plane in
Controller# show monitor capture mycap parameter
monitor capture mycap interface GigabitEthernet1/0/1 in
monitor capture mycap control-plane in
```

To remove an attachment point from a capture point defined with multiple attachment points:

```
Controller# show monitor capture mycap parameter
monitor capture mycap interface GigabitEthernet1/0/1 in
monitor capture mycap control-plane in
Controller# no monitor capture mycap control-plane
Controller# show monitor capture mycap parameter
monitor capture mycap interface GigabitEthernet1/0/1 in
```

To define a capture point with a CAPWAP attachment point:

```
Controller# show capwap summary
```

```
CAPWAP Tunnels General Statistics:
Number of Capwap Data Tunnels      = 1
Number of Capwap Mobility Tunnels   = 0
Number of Capwap Multicast Tunnels = 0
```

Name	APName	Type	PhyPortIf	Mode	McastIf
Ca0	AP442b.03a9.6715	data	Gi3/0/6	unicast	-

Name	SrcIP	SrcPort	DestIP	DstPort	DtlsEn	MTU	Xact
Ca0	10.10.14.32	5247	10.10.14.2	38514	No	1449	0

```
Controller# monitor capture mycap interface capwap 0 both
Controller# monitor capture mycap file location flash:mycap.pcap
Controller# monitor capture mycap file buffer-size 1
Controller# monitor capture mycap start
```

```
*Aug 20 11:02:21.983: %BUFCAP-6-ENABLE: Capture Point mycap enabled.on
```

```
Controller# show monitor capture mycap parameter
monitor capture mycap interface capwap 0 in
monitor capture mycap interface capwap 0 out
monitor capture mycap file location flash:mycap.pcap buffer-size 1
Controller#
Controller# show monitor capture mycap
```

```
Status Information for Capture mycap
Target Type:
Interface: CAPWAP,
Ingress:
0
Egress:
0
Status : Active
Filter Details:
Capture all packets
Buffer Details:
Buffer Type: LINEAR (default)
File Details:
Associated file name: flash:mycap.pcap
Size of buffer(in MB): 1
Limit Details:
Number of Packets to capture: 0 (no limit)
Packet Capture duration: 0 (no limit)
Packet Size to capture: 0 (no limit)
Packets per second: 0 (no limit)
Packet sampling rate: 0 (no sampling)
Controller#
```

```

Controller# show monitor capture file flash:mycap.pcap
 1  0.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 2  0.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 3  2.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 4  2.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 5  3.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 6  4.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 7  4.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 8  5.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 9  5.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
10  6.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
11  8.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
12  9.225986 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
13  9.225986 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
14  9.225986 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
15  9.231998 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
16  9.231998 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
17  9.231998 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
18  9.236987 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
19 10.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
20 10.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
21 12.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
22 12.239993 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
23 12.244997 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
24 12.244997 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
25 12.250994 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
26 12.256990 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
27 12.262987 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
28 12.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
29 12.802012 10.10.14.3 -> 10.10.14.255 NBNS Name query NB WPAD.<00>
30 13.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....

```

Related Commands

Command	Description
monitor capture buffer	Configures the buffer for monitor capture (WireShark).
monitor capture file	Configures monitor capture (WireShark) storage file attributes.
show monitor capture	show monitor capture

monitor capture buffer

To configure the buffer for monitor capture (WireShark), use the **monitor capture buffer** command in privileged EXEC mode. To disable the monitor capture buffer or change the buffer back to a default linear buffer from a circular buffer, use the **no** form of this command.

```
monitor capture {capture-name} buffer {circular [size buffer-size ] | size buffer-size}
no monitor capture {capture-name} buffer [circular ]
```

Syntax Description

<i>capture-name</i>	The name of the capture whose buffer is to be configured.
circular	Specifies that the buffer is of a circular type. The circular type of buffer continues to capture data, even after the buffer is consumed, by overwriting the data captured previously.
size <i>buffer-size</i>	(Optional) Specifies the size of the buffer. The range is from 1 MB to 100 MB.

Command Default

A linear buffer is configured.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

When you first configure a WireShark capture, a circular buffer of a small size is suggested.

Examples

To configure a circular buffer with a size of 1 MB:

```
Controller# monitor capture mycap buffer circular size 1
```

Related Commands

Command	Description
monitor capture (interface/control plane)	Configures monitor capture (WireShark) specifying an attachment point and the packet flow direction.
monitor capture file	Configures monitor capture (WireShark) storage file attributes.
show monitor capture	show monitor capture

monitor capture clear

To clear the monitor capture (WireShark) buffer, use the **monitor capture clear** command in privileged EXEC mode.

monitor capture *{capture-name}* **clear**

Syntax Description

<i>capture-name</i>	The name of the capture whose buffer is to be cleared.
---------------------	--

Command Default

The buffer content is not cleared.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **monitor capture clear** command either during capture or after the capture has stopped either because one or more end conditions has been met, or you entered the **monitor capture stop** command. If you enter the **monitor capture clear** command after the capture has stopped, the **monitor capture export** command that is used to store the contents of the captured packets in a file will have no impact because the buffer has no captured packets.

If you have more than one capture that is storing packets in a buffer, clear the buffer before starting a new capture to avoid memory loss.

Examples

To clear the buffer contents for capture mycap:

```
Controller# monitor capture mycap clear
```

monitor capture export

To export a monitor capture (WireShark) to a file, use the **monitor capture export** command in privileged EXEC mode.

monitor capture {*capture-name*} **export** *file-location* : *file-name*

Syntax Description

<i>capture-name</i>	The name of the capture to be exported.
<i>file-location</i> : <i>file-name</i>	(Optional) Specifies the location and file name of the capture storage file. Acceptable values for <i>file-location</i> : <ul style="list-style-type: none"> • flash—On-board flash storage • (usbflash0:)— USB drive

Command Default

The captured packets are not stored.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **monitor capture export** command only when the storage destination is a capture buffer. The file may be stored either remotely or locally. Use this command either during capture or after the packet capture has stopped. The packet capture is stopped when one or more end conditions have been met or you entered the **monitor capture stop** command.

When WireShark is used on switches in a stack, packet captures can be stored only on the devices specified for *file-location* above that are connected to the active switch. Example: flash1 is connected to the active switch. flash2 is connected to the secondary switch. Only flash1 can be used to store packet captures.



Note

Attempts to store packet captures on unsupported devices or devices not connected to the active switch will probably result in errors.

Examples

To export the capture buffer contents to mycap.pcap on a flash drive:

```
Controller# monitor capture mycap export flash:mycap.pcap
```

monitor capture file

To configure monitor capture (WireShark) storage file attributes, use the **monitor capture file** command in privileged EXEC mode. To remove a storage file attribute, use the **no** form of this command.

monitor capture {*capture-name*} **file** {[**buffer-size** *temp-buffer-size*][**location** *file-location* : *file-name*]}[**ring** *number-of-ring-files*][**size** *total-size*]}

no monitor capture {*capture-name*} **file** {[**buffer-size**][**location**][**ring**][**size**]}

Syntax Description

<i>capture-name</i>	The name of the capture to be modified.
buffer-size <i>temp-buffer-size</i>	(Optional) Specifies the size of the temporary buffer. The range for <i>temp-buffer-size</i> is 1 to 100 MB. This is specified to reduce packet loss.
location <i>file-location</i> : <i>file-name</i>	(Optional) Specifies the location and file name of the capture storage file. Acceptable values for <i>file-location</i> : <ul style="list-style-type: none"> • flash—On-board flash storage • (usbflash0:)— USB drive
ring <i>number-of-ring-files</i>	(Optional) Specifies that the capture is to be stored in a circular file chain and the number of files in the file ring.
size <i>total-size</i>	(Optional) Specifies the total size of the capture files.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **monitor capture file** command only when the storage destination is a file. The file may be stored either remotely or locally. Use this command after the packet capture has stopped. The packet capture is stopped when one or more end conditions have been met or you entered the **monitor capture stop** command.

When WireShark is used on switches in a stack, packet captures can be stored only on the devices specified for *file-location* above that are connected to the active switch. Example: flash1 is connected to the active switch. flash2 is connected to the secondary switch. Only flash1 can be used to store packet captures.

**Note**

Attempts to store packet captures on unsupported devices or devices not connected to the active switch will probably result in errors.

Examples

To specify that the storage file name is mycap.pcap, stored on a flash drive:

```
Controller# monitor capture mycap file location flash:mycap.pcap
```

Related Commands

Command	Description
monitor capture (interface/control plane)	Configures monitor capture (WireShark) specifying an attachment point and the packet flow direction.
monitor capture buffer	Configures the buffer for monitor capture (WireShark).
show monitor capture	show monitor capture

monitor capture limit

To configure capture limits, use the **monitor capture limit** command in privileged EXEC mode. To remove the capture limits, use the **no** form of this command.

monitor capture {*capture-name*} **limit** {[**duration** *seconds*][**packet-length** *size*][**packets** *num*]}

no monitor capture {*capture-name*} **limit** [**duration**][**packet-length**][**packets**]

Syntax Description

<i>capture-name</i>	The name of the capture to be assigned capture limits.
duration <i>seconds</i>	(Optional) Specifies the duration of the capture, in seconds. The range is from 1 to 1000000.
packet-length <i>size</i>	(Optional) Specifies the packet length, in bytes. If the actual packet is longer than the specified length, only the first set of bytes whose number is denoted by the bytes argument is stored.
packets <i>num</i>	(Optional) Specifies the number of packets to be processed for capture.

Command Default

Capture limits are not configured.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

To configure a session limit of 60 seconds and a packet segment length of 400 bytes:

```
Controllor# monitor capture mycap limit duration 60 packet-len 400
```

monitor capture match



Note Do not use this command when capturing a CAPWAP tunnel. Also, when control plane and CAPWAP tunnels are mixed, this command will have no effect.

To define an explicit inline core filter for a monitor (Wireshark) capture, use the **monitor capture match** command in privileged EXEC mode. To remove this filter, use the **no** form of this command.

monitor capture *{capture-name}* **match** {**any** | **mac** *mac-match-string* | **ipv4** {**any** | **host** | **protocol**} {**any** | **host**} | **ipv6** {**any** | **host** | **protocol**} {**any** | **host**}}

no monitor capture *{capture-name}* **match**

Syntax Description

<i>capture-name</i>	The name of the capture to be assigned a core filter.
any	Specifies all packets.
mac <i>mac-match-string</i>	Specifies a Layer 2 packet.
ipv4	Specifies IPv4 packets.
host	Specifies the host.
protocol	Specifies the protocol.
ipv6	Specifies IPv6 packets.

Command Default

A core filter is not configured.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

To define a capture point and the core filter for the capture point that matches to any IP version 4 packets on the source or destination:

```
Controller# monitor capture mycap interface GigabitEthernet1/0/1 in
Controller# monitor capture mycap match ipv4 any
```

monitor capture start

To start the capture of packet data at a traffic trace point into a buffer, use the **monitor capture start** command in privileged EXEC mode.

monitor capture *{capture-name}* **start**

Syntax Description

<i>capture-name</i>	The name of the capture to be started.
---------------------	--

Command Default

The buffer content is not cleared.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **monitor capture clear** command to enable the packet data capture after the capture point is defined. To stop the capture of packet data, use the **monitor capture stop** command.

Ensure that system resources such as CPU and memory are available before starting a capture.

Examples

To start capturing buffer contents:

```
Controller# monitor capture mycap start
```

monitor capture stop

To stop the capture of packet data at a traffic trace point, use the **monitor capture stop** command in privileged EXEC mode.

monitor capture *{capture-name}* **stop**

Syntax Description

<i>capture-name</i>	The name of the capture to be stopped.
---------------------	--

Command Default

The packet data capture is ongoing.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **monitor capture stop** command to stop the capture of packet data that you started using the **monitor capture start** command. You can configure two types of capture buffers: linear and circular. When the linear buffer is full, data capture stops automatically. When the circular buffer is full, data capture starts from the beginning and the data is overwritten.

Examples

To stop capturing buffer contents:

```
Controller# monitor capture mycap stop
```

monitor session

To create a new Ethernet Switched Port Analyzer (SPAN) or a Remote Switched Port Analyzer (RSPAN) session configuration for analyzing traffic between ports or add to an existing session configuration, use the **monitor session** global configuration command. To clear SPAN or RSPAN sessions, use the **no** form of this command.

monitor session *session-number* {**destination** | **filter** | **source**}

no monitor session {*session-number* [**destination** | **filter** | **source**] | **all** | **local** | **range** *session-range* | **remote**}

Syntax Description

session-number

all	Clears all monitor sessions.
local	Clears all local monitor sessions.
range <i>session-range</i>	Clears monitor sessions in the specified range.
remote	Clears all remote monitor sessions.

Command Default

No monitor sessions are configured.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can verify your settings by entering the **show monitor** privileged EXEC command. You can display SPAN, RSPAN, FSPAN, and FRSPAN configuration on the switch by entering the **show running-config** privileged EXEC command. SPAN information appears near the end of the output.

Examples

This example shows how to create a local SPAN session 1 to monitor traffic on Po13 (an EtherChannel port) and limit SPAN traffic in the session only to VLAN 1281. Egress traffic replicates the source; ingress forwarding is not enabled.

```
Controller(config)# monitor session 1 source interface Po13
Controller(config)# monitor session 1 filter vlan 1281
Controller(config)# monitor session 1 destination interface GigabitEthernet2/0/36
encapsulation replicate
Controller(config)# monitor session 1 destination interface GigabitEthernet3/0/36
```

encapsulation replicate

The following is the output of a **show monitor session all** command after completing these setup instructions:

```

Controller# show monitor session all

Session 1
-----
Type                : Local Session
Source Ports        :
  Both              : Po13
Destination Ports   : Gi2/0/36,Gi3/0/36
  Encapsulation     : Replicate
  Ingress           : Disabled
Filter VLANs        : 1281
...

```

Related Commands

Command	Description
monitor session destination	Configures a FSPAN or FRSPAN destination session.
monitor session filter	Configures a FSPAN or FRSPAN session filter.
monitor session source	Configures a FSPAN or FRSPAN source session.
show monitor	Displays information about all SPAN and RSPAN sessions.

monitor session destination

To start a new Switched Port Analyzer (SPAN) session or Remote SPAN (RSPAN) destination session, to enable ingress traffic on the destination port for a network security device (such as a Cisco IDS Sensor Appliance), and to add or delete interfaces or VLANs to or from an existing SPAN or RSPAN session, use the **monitor session destination** global configuration command. To remove the SPAN or RSPAN session or to remove destination interfaces from the SPAN or RSPAN session, use the **no** form of this command.

monitor session *session-number* **destination** {**interface** *interface-id* [,|-] [**encapsulation** {**replicate** | **dot1q**}] {**ingress** [**dot1q** | **untagged**] } | {**remote**} **vlan** *vlan-id*

no monitor session *session-number* **destination** {**interface** *interface-id* [,|-] [**encapsulation** {**replicate** | **dot1q**}] {**ingress** [**dot1q** | **untagged**] } | {**remote**} **vlan** *vlan-id*

Syntax Description

<i>session-number</i>	
interface <i>interface-id</i>	Specifies the destination or source interface for a SPAN or RSPAN session. Valid interfaces are physical ports (including type, stack member, module, and port number). For source interface, port channel is also a valid interface type, and the valid range is 1 to 128.
,	(Optional) Specifies a series of interfaces or VLANs, or separates a range of interfaces or VLANs from a previous range. Enter a space before and after the comma.
-	(Optional) Specifies a range of interfaces or VLANs. Enter a space before and after the hyphen.
encapsulation replicate	(Optional) Specifies that the destination interface replicates the source interface encapsulation method. If not selected, the default is to send packets in native form (untagged). These keywords are valid only for local SPAN. For RSPAN, the RSPAN VLAN ID overwrites the original VLAN ID; therefore, packets are always sent untagged. The encapsulation options are ignored with the no form of the command.
encapsulation dot1q	(Optional) Specifies that the destination interface accepts the source interface incoming packets with IEEE 802.1Q encapsulation. These keywords are valid only for local SPAN. For RSPAN, the RSPAN VLAN ID overwrites the original VLAN ID; therefore, packets are always sent untagged. The encapsulation options are ignored with the no form of the command.
ingress	Enables ingress traffic forwarding.

dot1q	(Optional) Accepts incoming packets with IEEE 802.1Q encapsulation with the specified VLAN as the default VLAN.
untagged	(Optional) Accepts incoming packets with untagged encapsulation with the specified VLAN as the default VLAN.
isl	Specifies ingress forwarding using ISL encapsulation.
remote	Specifies the remote VLAN for an RSPAN source or destination session. The range is 2 to 1001 and 1006 to 4094. The RSPAN VLAN cannot be VLAN 1 (the default VLAN) or VLAN IDs 1002 to 1005 (reserved for Token Ring and FDDI VLANs).
vlan <i>vlan-id</i>	Sets the default VLAN for ingress traffic when used with only the ingress keyword.

Command Default

No monitor sessions are configured.

If **encapsulation replicate** is not specified on a local SPAN destination port, packets are sent in native form with no encapsulation tag.

Ingress forwarding is disabled on destination ports.

You can specify **all**, **local**, **range *session-range***, or **remote** with the **no monitor session** command to clear all SPAN and RSPAN, all local SPAN, a range, or all RSPAN sessions.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can set a combined maximum of 8 local SPAN sessions and RSPAN source sessions. You can have a total of 66 SPAN and RSPAN sessions on a switch or switch stack.

A SPAN or RSPAN destination must be a physical port.

You can have a maximum of 64 destination ports on a switch or a switch stack.

Each session can include multiple ingress or egress source ports or VLANs, but you cannot combine source ports and source VLANs in a single session. Each session can include multiple destination ports.

When you use VLAN-based SPAN (VSPAN) to analyze network traffic in a VLAN or set of VLANs, all active ports in the source VLANs become source ports for the SPAN or RSPAN session. Trunk ports are included as source ports for VSPAN, and only packets with the monitored VLAN ID are sent to the destination port.

You can monitor traffic on a single port or VLAN or on a series or range of ports or VLANs. You select a series or range of interfaces or VLANs by using the [, | -] options.

If you specify a series of VLANs or interfaces, you must enter a space before and after the comma. If you specify a range of VLANs or interfaces, you must enter a space before and after the hyphen (-).

EtherChannel ports can be configured as SPAN or RSPAN destination ports. A physical port that is a member of an EtherChannel group can be used as a destination port, but it cannot participate in the EtherChannel group while it is as a SPAN destination.

A port used as a destination port cannot be a SPAN or RSPAN source, nor can a port be a destination port for more than one session at a time.

You can enable IEEE 802.1x authentication on a port that is a SPAN or RSPAN destination port; however, IEEE 802.1x authentication is disabled until the port is removed as a SPAN destination. If IEEE 802.1x authentication is not available on the port, the switch returns an error message. You can enable IEEE 802.1x authentication on a SPAN or RSPAN source port.

If ingress traffic forwarding is enabled for a network security device, the destination port forwards traffic at Layer 2.

Destination ports can be configured to function in these ways:

- When you enter **monitor session *session_number* destination interface *interface-id*** with no other keywords, egress encapsulation is untagged, and ingress forwarding is not enabled.
- When you enter **monitor session *session_number* destination interface *interface-id* ingress**, egress encapsulation is untagged; ingress encapsulation depends on the keywords that follow—**dot1q** or **untagged**.
- When you enter **monitor session *session_number* destination interface *interface-id* encapsulation replicate** with no other keywords, egress encapsulation replicates the source interface encapsulation; ingress forwarding is not enabled. (This applies to local SPAN only; RSPAN does not support encapsulation replication.)
- When you enter **monitor session *session_number* destination interface *interface-id* encapsulation replicate ingress**, egress encapsulation replicates the source interface encapsulation; ingress encapsulation depends on the keywords that follow—**dot1q** or **untagged**. (This applies to local SPAN only; RSPAN does not support encapsulation replication.)

You can verify your settings by entering the **show monitor** privileged EXEC command. You can display SPAN, RSPAN, FSPAN, and FRSPAN configuration on the switch by entering the **show running-config** privileged EXEC command. SPAN information appears near the end of the output.

Examples

This example shows how to create a local SPAN session 1 to monitor both sent and received traffic on source port 1 on stack member 1 to destination port 2 on stack member 2:

```
Controller(config)# monitor session 1 source interface gigabitethernet1/0/1 both
Controller(config)# monitor session 1 destination interface gigabitethernet1/0/2
```

This example shows how to delete a destination port from an existing local SPAN session:

```
Controller(config)# no monitor session 2 destination interface gigabitethernet1/0/2
```

This example shows how to configure RSPAN source session 1 to monitor a source interface and to configure the destination RSPAN VLAN 900:

```
Controller(config)# monitor session 1 source interface gigabitethernet1/0/1
Controller(config)# monitor session 1 destination remote vlan 900
Controller(config)# end
```

This example shows how to configure an RSPAN destination session 10 in the switch receiving the monitored traffic:

```
Controller(config)# monitor session 10 source remote vlan 900
Controller(config)# monitor session 10 destination interface gigabitethernet1/0/2
```

This example shows how to configure the destination port for ingress traffic on VLAN 5 by using a security device that supports IEEE 802.1Q encapsulation. Egress traffic replicates the source; ingress traffic uses IEEE 802.1Q encapsulation.

```
Controller(config)# monitor session 2 destination interface gigabitethernet1/0/2 encapsulation
dot1q ingress dot1q vlan 5
```

This example shows how to configure the destination port for ingress traffic on VLAN 5 by using a security device that does not support encapsulation. Egress traffic and ingress traffic are untagged.

```
Controller(config)# monitor session 2 destination interface gigabitethernet1/0/2 ingress
untagged vlan 5
```

Related Commands

Command	Description
monitor session	Configures a new SPAN or RSPAN session.
monitor session filter	Configures a FSPAN or FRSPAN session filter.
monitor session source	Configures a FSPAN or FRSPAN source session.
show monitor	Displays information about all SPAN and RSPAN sessions.

monitor session filter

To start a new flow-based SPAN (FSPAN) session or flow-based RSPAN (FRSPAN) source or destination session, or to limit (filter) SPAN source traffic to specific VLANs, use the **monitor session filter** global configuration command. To remove filters from the SPAN or RSPAN session, use the **no** form of this command.

monitor session *session-number* **filter** {**vlan** *vlan-id* [, | -] }

no monitor session *session-number* **filter** {**vlan** *vlan-id* [, | -] }

Syntax Description

session-number

vlan <i>vlan-id</i>	Specifies a list of VLANs as filters on trunk source ports to limit SPAN source traffic to specific VLANs. The <i>vlan-id</i> range is 1 to 4094.
,	(Optional) Specifies a series of VLANs, or separates a range of VLANs from a previous range. Enter a space before and after the comma.
-	(Optional) Specifies a range of VLANs. Enter a space before and after the hyphen.

Command Default

No monitor sessions are configured.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can monitor traffic on a single VLAN or on a series or range of ports or VLANs. You select a series or range of VLANs by using the [, | -] options.

If you specify a series of VLANs, you must enter a space before and after the comma. If you specify a range of VLANs, you must enter a space before and after the hyphen (-).

VLAN filtering refers to analyzing network traffic on a selected set of VLANs on trunk source ports. By default, all VLANs are monitored on trunk source ports. You can use the **monitor session session number filter vlan vlan-id** command to limit SPAN traffic on trunk source ports to only the specified VLANs.

VLAN monitoring and VLAN filtering are mutually exclusive. If a VLAN is a source, VLAN filtering cannot be enabled. If VLAN filtering is configured, a VLAN cannot become a source.

You can verify your settings by entering the **show monitor** privileged EXEC command. You can display SPAN, RSPAN, FSPAN, and FRSPAN configuration on the switch by entering the **show running-config** privileged EXEC command. SPAN information appears near the end of the output.

Examples

This example shows how to limit SPAN traffic in an existing session only to specific VLANs:

```
Switch(config)# monitor session 1 filter vlan 100 - 110
```

This example shows how to create a local SPAN session 1 to monitor both sent and received traffic on source port 1 on stack member 1 to destination port 2 on stack member 2 and to filter IPv4 traffic using access list number 122 in an FSPAN session:

```
Switch(config)# monitor session 1 source interface gigabitethernet1/0/1 both
Switch(config)# monitor session 1 destination interface gigabitethernet1/0/2
Switch(config)# monitor session 1 filter ip access-group 122
```

Related Commands

Command	Description
monitor session	Configures a new SPAN or RSPAN session.
monitor session destination	Configures a FSPAN or FRSPAN destination session.
monitor session source	Configures a FSPAN or FRSPAN source session.
show monitor	Displays information about all SPAN and RSPAN sessions.

monitor session source

To start a new Switched Port Analyzer (SPAN) session or Remote SPAN (RSPAN) source session, or to add or delete interfaces or VLANs to or from an existing SPAN or RSPAN session, use the **monitor session source** global configuration command. To remove the SPAN or RSPAN session or to remove source interfaces from the SPAN or RSPAN session, use the **no** form of this command.

monitor session *session_number* **source** {**interface** *interface-id* [, | -] [**both** | **rx** | **tx**] | [**remote**] **vlan** *vlan-id* [, | -] [**both** | **rx** | **tx**]}

no monitor session *session_number* **source** {**interface** *interface-id* [, | -] [**both** | **rx** | **tx**] | [**remote**] **vlan** *vlan-id* [, | -] [**both** | **rx** | **tx**]}

Syntax Description

<i>session_number</i>	
interface <i>interface-id</i>	Specifies the source interface for a SPAN or RSPAN session. Valid interfaces are physical ports (including type, stack member, module, and port number). For source interface, port channel is also a valid interface type, and the valid range is 1 to 48.
,	(Optional) Specifies a series of interfaces or VLANs, or separates a range of interfaces or VLANs from a previous range. Enter a space before and after the comma.
-	(Optional) Specifies a range of interfaces or VLANs. Enter a space before and after the hyphen.
both rx tx	(Optional) Specifies the traffic direction to monitor. If you do not specify a traffic direction, the source interface sends both transmitted and received traffic.
remote	(Optional) Specifies the remote VLAN for an RSPAN source or destination session. The range is 2 to 1001 and 1006 to 4094. The RSPAN VLAN cannot be VLAN 1 (the default VLAN) or VLAN IDs 1002 to 1005 (reserved for Token Ring and FDDI VLANs).
vlan <i>vlan-id</i>	When used with only the ingress keyword, sets default VLAN for ingress traffic.

Command Default

No monitor sessions are configured.

On a source interface, the default is to monitor both received and transmitted traffic.

On a trunk interface used as a source port, all VLANs are monitored.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Traffic that enters or leaves source ports or source VLANs can be monitored by using SPAN or RSPAN. Traffic routed to source ports or source VLANs cannot be monitored.

A source can be a physical port, a port channel, or a VLAN.

Each session can include multiple ingress or egress source ports or VLANs, but you cannot combine source ports and source VLANs in a single session. Each session can include multiple destination ports.

When you use VLAN-based SPAN (VSPAN) to analyze network traffic in a VLAN or set of VLANs, all active ports in the source VLANs become source ports for the SPAN or RSPAN session. Trunk ports are included as source ports for VSPAN, and only packets with the monitored VLAN ID are sent to the destination port.

You can monitor traffic on a single port or VLAN or on a series or range of ports or VLANs. You select a series or range of interfaces or VLANs by using the [, | -] options.

If you specify a series of VLANs or interfaces, you must enter a space before and after the comma. If you specify a range of VLANs or interfaces, you must enter a space before and after the hyphen (-).

You can monitor individual ports while they participate in an EtherChannel, or you can monitor the entire EtherChannel bundle by specifying the **port-channel** number as the RSPAN source interface.

A port used as a destination port cannot be a SPAN or RSPAN source, nor can a port be a destination port for more than one session at a time.

You can enable IEEE 802.1x authentication on a SPAN or RSPAN source port.

You can verify your settings by entering the **show monitor** privileged EXEC command. You can display SPAN, RSPAN, FSPAN, and FRSPAN configuration on the switch by entering the **show running-config** privileged EXEC command. SPAN information appears near the end of the output.

Examples

This example shows how to create a local SPAN session 1 to monitor both sent and received traffic on source port 1 on stack member 1 to destination port 2 on stack member 2:

```
Switch(config)# monitor session 1 source interface gigabitethernet1/0/1 both
Switch(config)# monitor session 1 destination interface gigabitethernet1/0/2
```

This example shows how to configure RSPAN source session 1 to monitor multiple source interfaces and to configure the destination RSPAN VLAN 900.

```
Switch(config)# monitor session 1 source interface gigabitethernet1/0/1
Switch(config)# monitor session 1 source interface port-channel 2 tx
Switch(config)# monitor session 1 destination remote vlan 900
Switch(config)# end
```

Related Commands

Command	Description
monitor session	Configures a new SPAN or RSPAN session.
monitor session destination	Configures a FSPAN or FRSPAN destination session.
monitor session filter	Configures a FSPAN or FRSPAN session filter.
show monitor	Displays information about all SPAN and RSPAN sessions.

show monitor

To display information about all Switched Port Analyzer (SPAN) and Remote SPAN (RSPAN) sessions, use the **show monitor** command in EXEC mode.

show monitor [**session** {*session_number* | **all** | **local** | **range list** | **remote**} [**detail**]]

Syntax Description

session	(Optional) Displays information about specified SPAN sessions.
<i>session_number</i>	
all	(Optional) Displays all SPAN sessions.
local	(Optional) Displays only local SPAN sessions.
range list	(Optional) Displays a range of SPAN sessions, where <i>list</i> is the range of valid sessions. The range is either a single session or a range of sessions described by two numbers, the lower one first, separated by a hyphen. Do not enter any spaces between comma-separated parameters or in hyphen-specified ranges. Note This keyword is available only in privileged EXEC mode.
remote	(Optional) Displays only remote SPAN sessions.
detail	(Optional) Displays detailed information about the specified sessions.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The output is the same for the **show monitor** command and the **show monitor session all** command.

Examples

This is an example of output for the **show monitor** user EXEC command:

```
Controller# show monitor
```

```

Session 1
-----
Type : Local Session
Source Ports :
RX Only : Gi4/0/1
Both : Gi4/0/2-3,Gi4/0/5-6
Destination Ports : Gi4/0/20
Encapsulation : Replicate
Ingress : Disabled
Session 2
-----
Type : Remote Source Session
Source VLANs :
TX Only : 10
Both : 1-9
Dest RSPAN VLAN : 105

```

This is an example of output for the **show monitor** user EXEC command for local SPAN source session 1:

```

Controller# show monitor session 1
Session 1
-----
Type : Local Session
Source Ports :
RX Only : Gi4/0/1
Both : Gi4/0/2-3,Gi4/0/5-6
Destination Ports : Gi4/0/20
Encapsulation : Replicate
Ingress : Disabled

```

This is an example of output for the **show monitor session all** user EXEC command when ingress traffic forwarding is enabled:

```

Controller# show monitor session all
Session 1
-----
Type : Local Session
Source Ports :
Both : Gi4/0/2
Destination Ports : Gi4/0/3
Encapsulation : Native
Ingress : Enabled, default VLAN = 5
Ingress encap : DOT1Q
Session 2
-----
Type : Local Session
Source Ports :
Both : Gi4/0/8
Destination Ports : Gi4/0/12
Encapsulation : Replicate
Ingress : Enabled, default VLAN = 4
Ingress encap : Untagged

```

Related Commands

Command	Description
monitor session	Configures a new SPAN or RSPAN session.
monitor session destination	Configures a FSPAN or FRSPAN destination session.
monitor session filter	Configures a FSPAN or FRSPAN session filter.
monitor session source	Configures a FSPAN or FRSPAN source session.

show monitor capture

To display monitor capture (WireShark) content, use the **show monitor capture file** command in privileged EXEC mode.

show monitor capture [*capture-name* [**buffer**] | **file** *file-location* : *file-name*][**brief** | **detailed** | **display-filter** *display-filter-string*]

Syntax Description

<i>capture-name</i>	(Optional) Specifies the name of the capture to be displayed.
buffer	(Optional) Specifies that a buffer associated with the named capture is to be displayed.
file <i>file-location</i> : <i>file-name</i>	(Optional) Specifies the file location and name of the capture storage file to be displayed.
brief	(Optional) Specifies the display content in brief.
detailed	(Optional) Specifies detailed display content.
display-filter <i>display-filter-string</i>	Filters the display content according to the <i>display-filter-string</i> .

Command Default

Displays all capture content.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

none

Examples

To display the capture for a capture called mycap:

```
Controller# show monitor capture mycap
```

```
Status Information for Capture mycap
```

```
  Target Type:
  Interface: CAPWAP,
  Ingress:
```

```
0
```

```
  Egress:
```

```
0
```

```
  Status : Active
  Filter Details:
```

```

Capture all packets
Buffer Details:
  Buffer Type: LINEAR (default)
File Details:
  Associated file name: flash:mycap.pcap
  Size of buffer(in MB): 1
Limit Details:
  Number of Packets to capture: 0 (no limit)
  Packet Capture duration: 0 (no limit)
  Packet Size to capture: 0 (no limit)
  Packets per second: 0 (no limit)
  Packet sampling rate: 0 (no sampling)

```

Related Commands

Command	Description
monitor capture (interface/control plane)	Configures monitor capture (WireShark) specifying an attachment point and the packet flow direction.
monitor capture buffer	Configures the buffer for monitor capture (WireShark).
monitor capture file	Configures monitor capture (WireShark) storage file attributes.

snmp-server enable traps

To enable the controller to send Simple Network Management Protocol (SNMP) notifications for various traps or inform requests to the network management system (NMS), use the **snmp-server enable traps** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps [auth-framework [sec-violation] | bridge | call-home | cluster | config | config-copy | config-ctid | copy-config | cpu | dot1x | energywise | entity | envmon | errdisable | event-manager | flash | fru-ctrl | license | mac-notification | port-security | power-ethernet | rep | snmp | stackwise | storm-control | stpx | syslog | transceiver | tty | vlan-membership | vlancreate | vlandelete | vstack | vtp]

no snmp-server enable traps [auth-framework [sec-violation] | bridge | call-home | cluster | config | config-copy | config-ctid | copy-config | cpu | dot1x | energywise | entity | envmon | errdisable | event-manager | flash | fru-ctrl | license | mac-notification | port-security | power-ethernet | rep | snmp | stackwise | storm-control | stpx | syslog | transceiver | tty | vlan-membership | vlancreate | vlandelete | vstack | vtp]

Syntax Description

auth-framework	(Optional) Enables SNMP CISCO-AUTH-FRAMEWORK-MIB traps.
sec-violation	(Optional) Enables SNMP camSecurityViolationNotif notifications.
bridge	(Optional) Enables SNMP STP Bridge MIB traps.*
call-home	(Optional) Enables SNMP CISCO-CALLHOME-MIB traps.*
cluster	(Optional) Enables SNMP cluster traps.
config	(Optional) Enables SNMP configuration traps.
config-copy	(Optional) Enables SNMP configuration copy traps.
config-ctid	(Optional) Enables SNMP configuration CTID traps.
copy-config	(Optional) Enables SNMP copy-configuration traps.
cpu	(Optional) Enables CPU notification traps.*
dot1x	(Optional) Enables SNMP dot1x traps.*
energywise	(Optional) Enables SNMP energywise traps.*
entity	(Optional) Enables SNMP entity traps.
envmon	(Optional) Enables SNMP environmental monitor traps.*
errdisable	(Optional) Enables SNMP errdisable notification traps.*
event-manager	(Optional) Enables SNMP Embedded Event Manager traps.

flash	(Optional) Enables SNMP FLASH notification traps.*
fru-ctrl	(Optional) Generates entity field-replaceable unit (FRU) control traps. In a controller stack, this trap refers to the insertion or removal of a controller in the stack.
license	(Optional) Enables license traps.*
mac-notification	(Optional) Enables SNMP MAC Notification traps.*
port-security	(Optional) Enables SNMP port security traps.*
power-ethernet	(Optional) Enables SNMP power Ethernet traps.*
rep	(Optional) Enables SNMP Resilient Ethernet Protocol traps.
snmp	(Optional) Enables SNMP traps.*
stackwise	(Optional) Enables SNMP stackwise traps.*
storm-control	(Optional) Enables SNMP storm-control trap parameters.*
stpx	(Optional) Enables SNMP STPX MIB traps.*
syslog	(Optional) Enables SNMP syslog traps.
transceiver	(Optional) Enables SNMP transceiver traps.*
tty	(Optional) Sends TCP connection traps. This is enabled by default.
vlan-membership	(Optional) Enables SNMP VLAN membership traps.
vlancreate	(Optional) Enables SNMP VLAN-created traps.
vlandelete	(Optional) Enables SNMP VLAN-deleted traps.
vstack	(Optional) Enables SNMP Smart Install traps.*
vtp	(Optional) Enables VLAN Trunking Protocol (VTP) traps.

Command Default The sending of SNMP traps is disabled.

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The command options marked with an asterisk in the table above have subcommands. For more information on these subcommands, see the Related Commands section below.

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.

When supported, use the **snmp-server enable traps** command to enable sending of traps or informs.

**Note**

Though visible in the command-line help strings, the **fru-ctrl**, **insertion**, and **removal** keywords are not supported on the controller. The **snmp-server enable informs** global configuration command is not supported. To enable the sending of SNMP inform notifications, use the **snmp-server enable traps** global configuration command combined with the **snmp-server host *host-addr* informs** global configuration command.

**Note**

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to enable more than one type of SNMP trap:

```
Controller(config)# snmp-server enable traps cluster
Controller(config)# snmp-server enable traps config
Controller(config)# snmp-server enable traps vtp
```

Related Commands

Command	Description
snmp-server enable traps bridge	Generates STP bridge MIB traps.
snmp-server enable traps call-home	Enables SNMP CISCO-CALLHOME-MIB traps.
snmp-server enable traps cpu	Enables CPU notifications.
snmp-server enable traps envmon	Enables SNMP environmental traps.
snmp-server enable traps errdisable	Enables SNMP errdisable notifications.
snmp-server enable traps flash	Enables SNMP flash notifications.
snmp-server enable traps license	Enables license traps.
snmp-server enable traps mac-notification	Enables SNMP MAC notification traps.
snmp-server enable traps port-security	Enables SNMP port security traps.

Command	Description
snmp-server enable traps power-ethernet	Enables SNMP PoE traps.
snmp-server enable traps snmp	Enables SNMP traps.
snmp-server enable traps stackwise	Enables SNMP StackWise traps.
snmp-server enable traps storm-control	Enables SNMP storm-control trap parameters.
snmp-server enable traps stpx	Enables SNMP STPX MIB traps.
snmp-server enable traps transceiver	Enable SNMP transceiver traps.
snmp-server enable traps vstack	Enables SNMP smart install traps.
snmp-server host	Specifies the recipient (host) of a SNMP notification operation.

snmp-server enable traps bridge

To generate STP bridge MIB traps, use the **snmp-server enable traps bridge** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps bridge [**newroot**] [**topologychange**]

no snmp-server enable traps bridge [**newroot**] [**topologychange**]

Syntax Description

newroot	(Optional) Enables SNMP STP bridge MIB new root traps.
topologychange	(Optional) Enables SNMP STP bridge MIB topology change traps.

Command Default

The sending of bridge SNMP traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to send bridge new root traps to the NMS:

```
Controller(config)# snmp-server enable traps bridge newroot
```

snmp-server enable traps call-home

To enable SNMP CISCO-CALLHOME-MIB traps, use the **snmp-server enable traps call-home** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps call-home [**message-send-fail** | **server-fail**]

no snmp-server enable traps call-home [**message-send-fail** | **server-fail**]

Syntax Description

message-send-fail	(Optional) Enables SNMP message-send-fail traps.
server-fail	(Optional) Enables SNMP server-fail traps.

Command Default

The sending of SNMP CISCO-CALLHOME-MIB traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP message-send-fail traps:

```
Controller(config)# snmp-server enable traps call-home message-send-fail
```

snmp-server enable traps cpu

To enable CPU notifications, use the **snmp-server enable traps cpu** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps cpu [**threshold**]

no snmp-server enable traps cpu [**threshold**]

Syntax Description	threshold	(Optional) Enables CPU threshold notification.
Command Default	The sending of CPU notifications is disabled.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate CPU threshold notifications:

```
Controller(config)# snmp-server enable traps cpu threshold
```

snmp-server enable traps envmon

To enable SNMP environmental traps, use the **snmp-server enable traps envmon** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps envmon [**fan**][**shutdown**][**status**] [**supply**][**temperature**]

no snmp-server enable traps envmon [**fan**][**shutdown**][**status**] [**supply**][**temperature**]

Syntax Description

fan	(Optional) Enables fan traps.
shutdown	(Optional) Enables environmental monitor shutdown traps.
status	(Optional) Enables SNMP environmental status-change traps.
supply	(Optional) Enables environmental monitor power-supply traps.
temperature	(Optional) Enables environmental monitor temperature traps.

Command Default

The sending of environmental SNMP traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Inform traps are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate fan traps:

```
Controller(config)# snmp-server enable traps envmon fan
```

snmp-server enable traps errdisable

To enable SNMP notifications of error-disabling, use the **snmp-server enable traps errdisable** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps errdisable [**notification-rate** *number-of-notifications*]

no snmp-server enable traps errdisable [**notification-rate** *number-of-notifications*]

Syntax Description	<p>notification-rate <i>number-of-notifications</i> (Optional) Specifies number of notifications per minute as the notification rate. Accepted values are from 0 to 10000.</p>
---------------------------	---

Command Default The sending of SNMP notifications of error-disabling is disabled.

Command Modes Global configuration

Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.2SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.2SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.2SE	This command was introduced.				

Usage Guidelines Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples This example shows how to set the number SNMP notifications of error-disabling to 2:

```
Controller(config)# snmp-server enable traps errdisable notification-rate 2
```

snmp-server enable traps flash

To enable SNMP flash notifications, use the **snmp-server enable traps flash** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps flash [insertion][removal]

no snmp-server enable traps flash [insertion][removal]

Syntax Description

insertion (Optional) Enables SNMP flash insertion notifications.

removal (Optional) Enables SNMP flash removal notifications.

Command Default

The sending of SNMP flash notifications is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP flash insertion notifications:

```
Controller(config)# snmp-server enable traps flash insertion
```

snmp-server enable traps license

To enable license traps, use the **snmp-server enable traps license** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps license [**deploy**][**error**][**usage**]

no snmp-server enable traps license [**deploy**][**error**][**usage**]

Syntax Description

deploy	(Optional) Enables license deployment traps.
error	(Optional) Enables license error traps.
usage	(Optional) Enables license usage traps.

Command Default

The sending of license traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate license deployment traps:

```
Controller(config)# snmp-server enable traps license deploy
```

snmp-server enable traps mac-notification

To enable SNMP MAC notification traps, use the **snmp-server enable traps mac-notification** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps mac-notification [**change**][**move**][**threshold**]

no snmp-server enable traps mac-notification [**change**][**move**][**threshold**]

Syntax Description

change	(Optional) Enables SNMP MAC change traps.
move	(Optional) Enables SNMP MAC move traps.
threshold	(Optional) Enables SNMP MAC threshold traps.

Command Default

The sending of SNMP MAC notification traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Inform is not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP MAC notification change traps:

```
Controller(config)# snmp-server enable traps mac-notification change
```

snmp-server enable traps port-security

To enable SNMP port security traps, use the **snmp-server enable traps port-security** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps port-security [*trap-rate value*]

no snmp-server enable traps port-security [*trap-rate value*]

Syntax Description

trap-rate <i>value</i>	(Optional) Sets the maximum number of port-security traps sent per second. The range is from 0 to 1000; the default is 0 (no limit imposed; a trap is sent at every occurrence).
-------------------------------	--

Command Default

The sending of port security SNMP traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to enable port-security traps at a rate of 200 per second:

```
Controller(config)# snmp-server enable traps port-security trap-rate 200
```

snmp-server enable traps power-ethernet

To enable SNMP power-over-Ethernet (PoE) traps, use the **snmp-server enable traps power-ethernet** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps power-ethernet {group *number* | **police**}

no snmp-server enable traps power-ethernet {group *number* | **police**}

Syntax Description

group <i>number</i>	Enables inline power group-based traps for the specified group number. Accepted values are from 1 to 9.
police	Enables inline power policing traps.

Command Default

The sending of power-over-Ethernet SNMP traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to enable power-over-Ethernet traps for group 1:

```
Controller(config)# snmp-server enable traps poe power-over-ethernet group 1
```

snmp-server enable traps snmp

To enable SNMP traps, use the **snmp-server enable traps snmp** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps snmp [authentication][coldstart][linkdown] [linkup][warmstart]
no snmp-server enable traps snmp [authentication][coldstart][linkdown] [linkup][warmstart]

Syntax Description	
authentication	(Optional) Enables authentication traps.
coldstart	(Optional) Enables cold start traps.
linkdown	(Optional) Enables linkdown traps.
linkup	(Optional) Enables linkup traps.
warmstart	(Optional) Enables warmstart traps.

Command Default The sending of SNMP traps is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples This example shows how to enable a warmstart SNMP trap:

```
Controller(config)# snmp-server enable traps snmp warmstart
```

snmp-server enable traps stackwise

To enable SNMP StackWise traps, use the **snmp-server enable traps stackwise** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps stackwise [GLS][ILS][SRLS] [insufficient-power][invalid-input-current]
[invalid-output-current][member-removed][member-upgrade-notification] [new-master][new-member]
[port-change][power-budget-warning][power-invalid-topology]
[power-link-status-changed][power-oper-status-changed]
[power-priority-conflict][power-version-mismatch][ring-redundant]
[stack-mismatch][unbalanced-power-supplies][under-budget][under-voltage]

no snmp-server enable traps stackwise [GLS][ILS][SRLS] [insufficient-power][invalid-input-current]
[invalid-output-current][member-removed][member-upgrade-notification] [new-master][new-member]
[port-change][power-budget-warning][power-invalid-topology]
[power-link-status-changed][power-oper-status-changed]
[power-priority-conflict][power-version-mismatch][ring-redundant]
[stack-mismatch][unbalanced-power-supplies][under-budget][under-voltage]
```

Syntax Description

GLS	(Optional) Enables StackWise stack power GLS trap.
ILS	(Optional) Enables StackWise stack power ILS trap.
SRLS	(Optional) Enables StackWise stack power SRLS trap.
insufficient-power	(Optional) Enables StackWise stack power unbalanced power supplies trap.
invalid-input-current	(Optional) Enables StackWise stack power invalid input current trap.
invalid-output-current	(Optional) Enables StackWise stack power invalid output current trap.
member-removed	(Optional) Enables StackWise stack member removed trap.
member-upgrade-notification	(Optional) Enables StackWise member to be reloaded for upgrade trap.
new-master	(Optional) Enables StackWise new master trap.
new-member	(Optional) Enables StackWise stack new member trap.
port-change	(Optional) Enables StackWise stack port change trap.
power-budget-warning	(Optional) Enables StackWise stack power budget warning trap.
power-invalid-topology	(Optional) Enables StackWise stack power invalid topology trap.
power-link-status-changed	(Optional) Enables StackWise stack power link status changed trap.

power-oper-status-changed	(Optional) Enables StackWise stack power port oper status changed trap.
power-priority-conflict	(Optional) Enables StackWise stack power priority conflict trap.
power-version-mismatch	(Optional) Enables StackWise stack power version mismatch discovered trap.
ring-redundant	(Optional) Enables StackWise stack ring redundant trap.
stack-mismatch	(Optional) Enables StackWise stack mismatch trap.
unbalanced-power-supplies	(Optional) Enables StackWise stack power unbalanced power supplies trap.
under-budget	(Optional) Enables StackWise stack power under budget trap.
under-voltage	(Optional) Enables StackWise stack power under voltage trap.

Command Default The sending of SNMP StackWise traps is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples This example shows how to generate StackWise stack power GLS traps:

```
Controller(config)# snmp-server enable traps stackwise GLS
```

snmp-server enable traps storm-control

To enable SNMP storm-control trap parameters, use the **snmp-server enable traps storm-control** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps storm-control {*trap-rate number-of-minutes*}

no snmp-server enable traps storm-control {*trap-rate*}

Syntax Description

trap-rate <i>number-of-minutes</i>	(Optional) Specifies the SNMP storm-control trap rate in minutes. Accepted values are from 0 to 1000.
---	---

Command Default

The sending of SNMP storm-control trap parameters is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to set the SNMP storm-control trap rate to 10 traps per minute:

```
Controller(config)# snmp-server enable traps storm-control trap-rate 10
```

snmp-server enable traps stpx

To enable SNMP STPX MIB traps, use the **snmp-server enable traps stpx** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps stpx [inconsistency][loop-inconsistency][root-inconsistency]
no snmp-server enable traps stpx [inconsistency][loop-inconsistency][root-inconsistency]

Syntax Description	
inconsistency	(Optional) Enables SNMP STPX MIB inconsistency update traps.
loop-inconsistency	(Optional) Enables SNMP STPX MIB loop inconsistency update traps.
root-inconsistency	(Optional) Enables SNMP STPX MIB root inconsistency update traps.

Command Default The sending of SNMP STPX MIB traps is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples This example shows how to generate SNMP STPX MIB inconsistency update traps:

```
Controller(config)# snmp-server enable traps stpx inconsistency
```

snmp-server enable traps transceiver

To enable SNMP transceiver traps, use the **snmp-server enable traps transceiver** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps transceiver {all}

no snmp-server enable traps transceiver {all}

Syntax Description

all (Optional) Enables all SNMP transceiver traps.

Command Default

The sending of SNMP transceiver traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to set all SNMP transceiver traps:

```
Controller(config)# snmp-server enable traps transceiver all
```

snmp-server enable traps vstack

To enable SNMP smart install traps, use the **snmp-server enable traps vstack** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps vstack [**addition**][**failure**][**lost**][**operation**]

no snmp-server enable traps vstack [**addition**][**failure**][**lost**][**operation**]

Syntax Description

addition	(Optional) Enables client added traps.
failure	(Optional) Enables file upload and download failure traps.
lost	(Optional) Enables client lost trap.
operation	(Optional) Enables operation mode change traps.

Command Default

The sending of SNMP smart install traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP Smart Install client-added traps:

```
Controller(config)# snmp-server enable traps vstack addition
```

snmp-server enable traps wireless

To enable sending Simple Network Management Protocol (SNMP) notifications for various wireless traps or inform requests to the network management system (NMS), use the **snmp-server enable traps wireless** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps wireless [AP | RRM | bsn80211SecurityTrap | bsnAPPParamUpdate | bsnAPPProfile | bsnAccessPoint | bsnMobileStation | bsnRogue | client | mfp | rogue]

no snmp-server enable traps wireless [AP | RRM | bsn80211SecurityTrap | bsnAPPParamUpdate | bsnAPPProfile | bsnAccessPoint | bsnMobileStation | bsnRogue | client | mfp | rogue]

Syntax Description

AP	(Optional) Enables sending of AP related traps.
RRM	(Optional) Enables sending of RRM traps.
bsn80211SecurityTrap	(Optional) Enables security-related traps.
bsnAPPParamUpdate	(Optional) Enables sending of traps for AP parameters that get updated.
bsnAPPProfile	(Optional) Enables BSN AP profile traps.
bsnAccessPoint	(Optional) Enables access point traps.
bsnMobileStation	(Optional) Controls wireless client traps.
bsnRogue	(Optional) Enables rogue-related traps.
client	(Optional) Enables client traps.
mfp	(Optional) Enables MFP traps.
rogue	(Optional) Enables rogue traps.

Command Default

Disabled

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.

**Note**

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate sending AP related wireless traps:

```
Controller(config)# snmp-server enable traps wireless ap
```

snmp-server engineID

To configure a name for either the local or remote copy of SNMP, use the **snmp-server engineID** command in global configuration mode.

snmp-server engineID {**local** *engineid-string* | **remote** *ip-address* [**udp-port** *port-number*] *engineid-string*}

Syntax Description

local <i>engineid-string</i>	Specifies a 24-character ID string with the name of the copy of SNMP. You need not specify the entire 24-character engine ID if it has trailing zeros. Specify only the portion of the engine ID up to the point where only zeros remain in the value.
remote <i>ip-address</i>	Specifies the remote SNMP copy. Specify the <i>ip-address</i> of the device that contains the remote copy of SNMP.
udp-port <i>port-number</i>	(Optional) Specifies the User Datagram Protocol (UDP) port on the remote device. The default is 162.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None

Examples

The following example configures a local engine ID of 123400000000000000000000:

```
Controller(config)# snmp-server engineID local 1234
```

snmp-server host

To specify the recipient (host) of a Simple Network Management Protocol (SNMP) notification operation, use the **snmp-server host** global configuration command on the controller. Use the **no** form of this command to remove the specified host.

```
snmp-server host {host-addr} [vrf vrf-instance] [informs | traps] [version {1 | 2c | 3 {auth | noauth | priv} } ] {community-string [notification-type] }
```

```
no snmp-server host {host-addr} [vrf vrf-instance] [informs | traps] [version {1 | 2c | 3 {auth | noauth | priv} } ] {community-string [notification-type] }
```

Syntax Description

<i>host-addr</i>	Name or Internet address of the host (the targeted recipient).
vrf <i>vrf-instance</i>	(Optional) Specifies the virtual private network (VPN) routing instance and name for this host.
informs traps	(Optional) Sends SNMP traps or informs to this host.
version 1 2c 3	(Optional) Specifies the version of the SNMP used to send the traps. 1 —SNMPv1. This option is not available with informs. 2c —SNMPv2C. 3 —SNMPv3. One of the authorization keywords (see next table row) must follow the Version 3 keyword.
auth noauth priv	auth (Optional)—Enables Message Digest 5 (MD5) and Secure Hash Algorithm (SHA) packet authentication. noauth (Default)—The noAuthNoPriv security level. This is the default if the auth noauth priv keyword choice is not specified. priv (Optional)—Enables Data Encryption Standard (DES) packet encryption (also called privacy).
<i>community-string</i>	Password-like community string sent with the notification operation. Though you can set this string by using the snmp-server host command, we recommend that you define this string by using the snmp-server community global configuration command before using the snmp-server host command. Note The @ symbol is used for delimiting the context information. Avoid using the @ symbol as part of the SNMP community string when configuring this command.

notification-type (Optional) Type of notification to be sent to the host. If no type is specified, all notifications are sent. The notification type can be one or more of the these keywords:

- **auth-framework**—Sends SNMP CISCO-AUTH-FRAMEWORK-MIB traps.
 - **bridge**—Sends SNMP Spanning Tree Protocol (STP) bridge MIB traps.
 - **bulkstat**—Sends Data-Collection-MIB Collection notification traps.
 - **call-home**—Sends SNMP CISCO-CALLHOME-MIB traps.
 - **cef**—Sends SNMP CEF traps.
 - **config**—Sends SNMP configuration traps.
 - **config-copy**—Sends SNMP config-copy traps.
 - **config-ctid**—Sends SNMP config-ctid traps.
 - **copy-config**—Sends SNMP copy configuration traps.
 - **cpu**—Sends CPU notification traps.
 - **cpu threshold**—Sends CPU threshold notification traps.
 - **entity**—Sends SNMP entity traps.
-

- **envmon**—Sends environmental monitor traps.
- **errdisable**—Sends SNMP errdisable notification traps.
- **event-manager**—Sends SNMP Embedded Event Manager traps.
- **flash**—Sends SNMP FLASH notifications.
- **flowmon**—Sends SNMP flowmon notification traps.
- **ipmulticast**—Sends SNMP IP multicast routing traps.
- **ipsla**—Sends SNMP IP SLA traps.
- **license**—Sends license traps.
- **local-auth**—Sends SNMP local auth traps.
- **mac-notification**—Sends SNMP MAC notification traps.
- **pim**—Sends SNMP Protocol-Independent Multicast (PIM) traps.
- **power-ethernet**—Sends SNMP power Ethernet traps.
- **snmp**—Sends SNMP-type traps.
- **storm-control**—Sends SNMP storm-control traps.
- **stpx**—Sends SNMP STP extended MIB traps.
- **syslog**—Sends SNMP syslog traps.
- **transceiver**—Sends SNMP transceiver traps.
- **tty**—Sends TCP connection traps.
- **vlan-membership**—Sends SNMP VLAN membership traps.
- **vlancreate**—Sends SNMP VLAN-created traps.
- **vlandelete**—Sends SNMP VLAN-deleted traps.
- **vrfmib**—Sends SNMP vrfmib traps.
- **vtp**—Sends SNMP VLAN Trunking Protocol (VTP) traps.
- **wireless**—Sends wireless traps.

Command Default

This command is disabled by default. No notifications are sent.

If you enter this command with no keywords, the default is to send all trap types to the host. No informs are sent to this host.

If no **version** keyword is present, the default is Version 1.

If Version 3 is selected and no authentication keyword is entered, the default is the **noauth** (noAuthNoPriv) security level.

**Note**

Though visible in the command-line help strings, the **fru-ctrl** keyword is not supported.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

SNMP notifications can be sent as traps or inform requests. Traps are unreliable because the receiver does not send acknowledgments when it receives traps. The sender cannot determine if the traps were received. However, an SNMP entity that receives an inform request acknowledges the message with an SNMP response PDU. If the sender never receives the response, the inform request can be sent again, so that informs are more likely to reach their intended destinations.

However, informs consume more resources in the agent and in the network. Unlike a trap, which is discarded as soon as it is sent, an inform request must be held in memory until a response is received or the request times out. Traps are also sent only once, but an inform might be retried several times. The retries increase traffic and contribute to a higher overhead on the network.

If you do not enter an **snmp-server host** command, no notifications are sent. To configure the controller to send SNMP notifications, you must enter at least one **snmp-server host** command. If you enter the command with no keywords, all trap types are enabled for the host. To enable multiple hosts, you must enter a separate **snmp-server host** command for each host. You can specify multiple notification types in the command for each host.

If a local user is not associated with a remote host, the controller does not send informs for the **auth** (authNoPriv) and the **priv** (authPriv) authentication levels.

When multiple **snmp-server host** commands are given for the same host and kind of notification (trap or inform), each succeeding command overwrites the previous command. Only the last **snmp-server host** command is in effect. For example, if you enter an **snmp-server host inform** command for a host and then enter another **snmp-server host inform** command for the same host, the second command replaces the first.

The **snmp-server host** command is used with the **snmp-server enable traps** global configuration command. Use the **snmp-server enable traps** command to specify which SNMP notifications are sent globally. For a host to receive most notifications, at least one **snmp-server enable traps** command and the **snmp-server host** command for that host must be enabled. Some notification types cannot be controlled with the **snmp-server enable traps** command. For example, some notification types are always enabled. Other notification types are enabled by a different command.

The **no snmp-server host** command with no keywords disables traps, but not informs, to the host. To disable informs, use the **no snmp-server host informs** command.

Examples

This example shows how to configure a unique SNMP community string named comaccess for traps and prevent SNMP polling access with this string through access-list 10:

```
Controller(config)# snmp-server community comaccess ro 10
```

```
Controller(config)# snmp-server host 172.20.2.160 comaccess
Controller(config)# access-list 10 deny any
```

This example shows how to send the SNMP traps to the host specified by the name myhost.cisco.com. The community string is defined as comaccess:

```
Controller(config)# snmp-server enable traps
Controller(config)# snmp-server host myhost.cisco.com comaccess snmp
```

This example shows how to enable the controller to send all traps to the host myhost.cisco.com by using the community string public:

```
Controller(config)# snmp-server enable traps
Controller(config)# snmp-server host myhost.cisco.com public
```

You can verify your settings by entering the **show running-config** privileged EXEC command.

Related Commands

Command	Description
snmp-server enable traps	Enables the controller to send SNMP notifications for various traps or inform requests to the NMS.

trapflags

To enable trapflags for various parameters, use the **trapflags** command. To disable, use the **no** form of the command.

```
trapflags {ap | {interfaceup | register}| client | {dot11 | excluded}| dot11-security | {ids-sig-attack |
wep-decrypt-error}| mesh | rougeap | rrm-params | {channels | tx-power}| rrm-profile | {coverage |
interference | load | noise}}
```

```
no trapflags {ap | {interfaceup | register}| client | {dot11 | excluded}| dot11-security | {ids-sig-attack |
wep-decrypt-error}| mesh | rougeap | rrm-params | {channels | tx-power}| rrm-profile | {coverage |
interference | load | noise}}
```

Syntax Description

ap	Enables sending of AP-related traps.
interfaceup	Enables the trap when a Cisco AP interface (A or B) comes up.
register	Enables the trap when a Cisco AP registers with a Cisco controller.
client	Enables sending of client-related Dot11 traps.
dot11	Enables dot11 traps for clients.
excluded	Enables excluded traps for clients.
dot11-security	Enables sending of 802.11 security-related traps.
ids-sig-attack	Enables IDS signature attack traps.
wep-decrypt-error	Enables WEP decrypt error for clients.
mesh	Enables mesh trap.
rougeap	Enables rogueAP detection trap.
rrm-params	Enables sending of RRM parameter update-related traps.
channels	Enables trap when RF Manager automatically changes the channel number for the Cisco AP interface.
tx-power	Enables trap when RF Manager automatically changes Tx-Power Level for the Cisco AP interface.
rrm-profile	Enables sending of RRM profile-related traps.
coverage	Enables trap when the coverage profile maintained by RF Manager fails.
interference	Enables trap when the interference profile maintained by RF Manager fails.

load	Enables trap when the load profile maintained by RF Manager fails.
noise	Enables trap when the noise profile maintained by RF Manager fails.

Command Default Disabled

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Examples This example shows how the trap is enabled for the ids-sig-attach parameter in dot11 security.

```
Controller(config)# trapflags dot11-security ids-sig-attack
```




INDEX

A

- aaa-override command [509](#)
- accounting-list command [510](#)
- ap auth-list ap-policy [603](#)
- ap bridging [604](#)
- ap capwap backup [605](#)
- ap capwap multicast [606](#)
- ap capwap retransmit [607](#)
- ap capwap timers [608](#)
- ap cdp [610](#)
- ap core-dump [612](#)
- ap country [613](#)
- ap crash-file [614](#)
- ap dot11 2.4 GHz CleanAir alarm device [850](#)
- ap dot11 24ghz [615](#)
- ap dot11 24ghz cleanair [839](#)
- ap dot11 24ghz cleanair command [837](#), [838](#), [841](#), [852](#)
- ap dot11 24ghz dot11g [616](#)
- ap dot11 24ghz or 5ghz rrm channel dca add command [580](#)
- ap dot11 24ghz or 5ghz rrm channel dca remove number [581](#)
- ap dot11 24ghz rrm coverage command [583](#)
- ap dot11 5ghz channelswitch mode [617](#)
- ap dot11 5ghz cleanair [829](#), [830](#)
- ap dot11 5ghz cleanair command [831](#), [833](#), [846](#)
- ap dot11 5ghz power-constraint [618](#)
- ap dot11 5ghz rrm channel dca chan-width-11n [582](#)
- ap dot11 5ghz rrm channel device command [836](#)
- ap dot11 5ghz rrm command [574](#)
- ap dot11 5ghz rrm group-member command [585](#)
- ap dot11 5ghz rrm profile command [588](#)
- ap dot11 5ghz rrm tpc-threshold command [589](#)
- ap dot11 5ghz rrm txpower command [590](#)
- ap dot11 beaconperiod [619](#)
- ap dot11 beamforming [620](#)
- ap dot11 cac media-stream [622](#)
- ap dot11 cac video [627](#)
- ap dot11 cac voice [629](#)
- ap dot11 cleanair [632](#)
- ap dot11 cleanair alarm air-quality [633](#)
- ap dot11 cleanair alarm device [634](#)
- ap dot11 cleanair device [636](#)
- ap dot11 command [274](#)
- ap dot11 dot11n [638](#)
- ap dot11 dtpc [641](#)
- ap dot11 dual-band cleanair [689](#)
- ap dot11 edcs-parameters [643](#)
- ap dot11 l2roam rf-params [647](#)
- ap dot11 media-stream [649](#)
- ap dot11 multimedia [625](#)
- ap dot11 rrm ccx command [577](#)
- ap dot11 rrm ccx location-measurement [651](#)
- ap dot11 rrm channel cleanair-event [646](#)
- ap dot11 rrm channel command [578](#), [835](#), [843](#), [844](#)
- ap dot11 rrm channel dca [652](#)
- ap dot11 rrm group-member [654](#)
- ap dot11 rrm group-mode [645](#)
- ap dot11 rrm logging [655](#)
- ap dot11 rrm monitor [657](#)
- ap dot11 rrm monitor mode command [586](#)
- ap dot11 rrm ndp-type [659](#)
- ap dot1x max-sessions [660](#)
- ap dot1x username [661](#)
- ap ethernet duplex [662](#)
- ap group [663](#)
- ap image [664](#)
- ap led [666](#)
- ap link-encryption [667](#)
- ap link-latency [668](#)
- ap mgmtuser username [669](#)
- ap name 49ghz rrm profile [681](#)
- ap name ap-groupname [671](#)
- ap name bhrate [672](#)
- ap name bridgegroupname [673](#)
- ap name bridging [710](#)
- ap name capwap retransmit [674](#)
- ap name command [675](#)
- ap name console-redirect [712](#)
- ap name core-dump [676](#)
- ap name country [677](#)
- ap name crash-file [678](#)
- ap name dot11 24ghz rrm coverage [679](#)
- ap name dot11 5ghz rrm channel [683](#)
- ap name dot11 antenna [684](#)

ap name dot11 antenna extantgain [686](#)
 ap name dot11 cleanair [687](#)
 ap name dot11 dot11n antenna [688](#)
 ap name dot11 rrm ccx [691](#)
 ap name dot11 rrm profile [692](#)
 ap name dot11 txpower [694](#)
 ap name dot1xuser [695](#)
 ap name ethernet [697](#)
 ap name ethernet duplex [698](#)
 ap name image [699](#)
 ap name led [701](#)
 ap name link-encryption [714](#)
 ap name link-latency [715](#)
 ap name location [702](#)
 ap name mgmtuser [703](#)
 ap name mode [705](#)
 ap name monitor-mode [707](#)
 ap name monitor-mode dot11b [708](#)
 ap name name [709](#)
 ap name no cdp interface [711](#)
 ap name no dot11 shutdown [713](#)
 ap name no telnet [721](#)
 ap name power command [716](#)
 ap name power injector [722](#)
 ap name power pre-standard [723](#)
 ap name reset [725](#)
 ap name reset-button [724](#)
 ap name shutdown [717](#)
 ap name slot [726](#)
 ap name slot shutdown [718](#)
 ap name sniff [719](#)
 ap name ssh [720](#)
 ap name static-ip [728](#)
 ap name stats-timer [730](#)
 ap name syslog host [731](#)
 ap name syslog level [732](#)
 ap name tcp-adjust-mss [733](#)
 ap name tftp-downgrade [734](#)
 ap power injector [735](#)
 ap power pre-standard [736](#)
 ap reporting-period [737](#)
 ap reset-button [738](#)
 ap static-ip [739](#)
 ap syslog [740](#)
 ap tcp-adjust-mss size [742](#)
 ap tftp-downgrade [743](#)
 arp command [18](#)
 assisted-roaming command [511](#)
 authentication mac-move permit command [344](#)
 authentication priority command [345](#)

B

band-select command [513](#)
 boot command [19](#)
 broadcast-ssid command [514](#)

C

cache command [891](#)
 cache-memory-max command [285](#)
 call-snoop command [515](#)
 cat command [21](#)
 ccx aironet-iesupport command [523](#)
 channel-group command [443](#)
 channel-protocol command [446](#)
 channel-scan defer-priority command [517](#)
 channel-scan defer-time command [518](#)
 chd command [519](#)
 cisp enable [350](#)
 class command [134](#)
 class-map command [137](#)
 clear ap config [745](#)
 clear ap eventlog-all [746](#)
 clear ap join statistics [747](#)
 clear ap mac-address [748](#)
 clear ap name tsm dot11 all [744](#)
 clear ap name wlan statistics [749](#)
 clear errdisable interface vlan [352](#)
 clear lacp command [448](#)
 clear location command [22](#)
 clear location statistics command [23](#)
 clear mac address-table command [354](#)
 clear nmsp statistics command [24, 190](#)
 clear pagp command [449](#)
 clear vmpls statistics command [239](#)
 clear vtp counters command [240](#)
 clear wireless ccx statistics command [25](#)
 clear wireless client tsm dot11 command [26](#)
 clear wireless location s69 statistics command [27](#)
 clear wireless mobility statistics [879](#)
 client association limit command [520](#)
 client vlan command [189, 201, 238, 522](#)
 collect command [896](#)
 collect counter command [898](#)
 collect interface command [899](#)
 collect timestamp absolute command [900](#)
 collect transport tcp flags command [901](#)
 copy command [28](#)

D

datalink flow monitor command [524, 902](#)
 debug etherchannel command [450](#)
 debug flow exporter command [903](#)
 debug flow monitor command [904](#)
 debug ilpower command [191](#)
 debug interface command [192](#)
 debug lacp command [452](#)
 debug lldp packets command [194](#)
 debug pagp command [453](#)
 debug platform fallback-bridging command [195](#)
 debug platform pm command [455](#)
 debug platform stack-manager command [958](#)
 debug platform uddl command [457](#)
 debug sw-vlan command [241](#)
 debug sw-vlan ifs command [243](#)
 debug sw-vlan notification command [244](#)
 debug sw-vlan vtp command [246](#)
 default ap dot11 rrm channel [849](#)
 default ap dot11 rrm channel cleanair-event [848](#)
 default ap dot11 rrm channel command [854](#)
 default command [526](#)
 delete command [33](#)
 deny command [356](#)
 description command [907](#)
 destination command [908](#)
 dir command [34](#)
 dot1x supplicant force-multicast command [364](#)
 dot1x test timeout [366](#)
 dscp command [909](#)
 dtim dot11 command [529](#)
 duplex command [197](#)

E

emergency-install command [36](#)
 epm access-control open command [370](#)
 exclusionlist command [530](#)
 exit command [38, 531, 532](#)
 export-protocol netflow-v9 command [910](#)

F

flow-based RSPAN (FRSPAN) session [1010](#)
 flow-based SPAN (FSPAN) session [1010](#)
 full-ring state [981](#)

H

help command [39](#)

I

interface command [199](#)
 interface port-channel command [458](#)
 interface range command [202](#)
 interface vlan command [248](#)
 ip access-group command [533](#)
 ip admission name command [372](#)
 ip device tracking maximum command [375](#)
 ip device tracking probe command [376](#)
 ip dhcp snooping verify no-relay-agent-address [380](#)
 ip flow monitor command [534, 915](#)
 ip igmp snooping last-member-query-count command [292](#)
 ip multicast vlan command [301](#)
 ip verify source command [382](#)
 ip verify source mac-check command [535](#)
 ipv6 flow monitor command [884, 917](#)
 ipv6 traffic-filter command [885](#)

L

lacp max-bundle command [460](#)
 lacp port-priority command [461](#)
 lacp system-priority command [463](#)
 load-balance command [536](#)
 location algorithm command [46](#)
 location command [203](#)
 location expiry command [47](#)
 location notify-threshold command [48](#)
 location plm calibrating command [49](#)
 location rfid command [50](#)
 location rssi-half-life command [51](#)
 logging event power-inline-status command [207](#)
 logging smartlog command [53](#)

M

mab request format attribute 32 command [387](#)
 mac address-table control-packet-learn command [52](#)
 main-cpu command [959](#)
 match (access-map configuration) command [389](#)
 match (class-map configuration) command [139](#)
 match datalink ethertype command [919](#)
 match datalink mac command [920](#)
 match datalink vlan command [921](#)
 match flow direction command [922](#)

match interface command [923](#)
 match ipv4 command [924](#)
 match ipv4 destination address command [925](#)
 match ipv4 source address command [926](#)
 match ipv4 ttl command [927](#)
 match ipv6 command [928](#)
 match ipv6 destination address command [929](#)
 match ipv6 hop-limit command [930](#)
 match ipv6 source command [931](#)
 match non-client-nrt command [142](#)
 match transport command [932](#)
 match transport icmp ipv4 command [933](#)
 match transport icmp ipv6 command [934](#)
 match wlan user-priority command [143](#)
 maximum transmission unit (MTU) [229](#)
 media-stream multicast-direct command [277](#)
 mgmt_init command [55](#)
 mkdir command [56](#)
 mobility anchor [537, 870](#)
 monitor session command [1004, 1006](#)
 monitor session filter command [1010](#)
 monitor session source command [1012](#)
 more command [57](#)

N

nac command [539](#)
 Network Mobility Services Protocol (NMSP) [190, 223](#)
 network-policy profiles [222, 227](#)
 nmsp notification interval command [58](#)
 no authentication logging verbose [391](#)
 no dot1x logging verbose [392](#)
 no mab logging verbose [393](#)

O

option command [936](#)

P

pagp learn-method command [465](#)
 pagp port-priority command [467](#)
 partial-ring state [981](#)
 passive-client command [540](#)
 peer-blocking command [541](#)
 permit command [394](#)
 persistent MAC address [978](#)
 policy config-sync prc reload command [961](#)
 policy-map command [144](#)
 port-channel load-balance command [469](#)

port-channel load-balance extended command [471](#)
 port-channel min-links command [473](#)

Q

queue-limit command [151](#)

R

radio command [542](#)
 radio-policy command [544](#)
 redistribute mdns-sd command [309](#)
 redundancy command [962](#)
 redundancy config-sync mismatched-commands command [963](#)
 redundancy force-switchover command [965](#)
 redundancy reload command [966](#)
 reload command [967](#)
 Remote SPAN (RSPAN) sessions [1015](#)
 remote-span command [250](#)
 rename command [60](#)
 reset command [61](#)
 rmdir command [62](#)
 roamed-voice-client re-anchor command [546](#)
 RSPAN [1004, 1006, 1010, 1012](#)
 sessions [1004, 1006, 1012](#)
 add interfaces to [1004, 1006, 1012](#)
 start new [1004, 1006, 1012](#)

S

security web-auth command [551](#)
 service-list mdns-sd service-list-name command [305](#)
 service-policy command [155, 157, 308, 554](#)
 service-policy-query command [310](#)
 service-routing mdns-sd command [307](#)
 session command [969](#)
 session-timeout command [556](#)
 set command [63, 159](#)
 show ap cac voice [750](#)
 show ap capwap [752](#)
 show ap cdp [754](#)
 show ap config dot11 [755](#)
 show ap config fnf [757](#)
 show ap config global [758](#)
 show ap crash-file [759](#)
 show ap data-plane [760](#)
 show ap dot11 [762, 763](#)
 show ap dot11 24ghz cleanair device type command [591](#)
 show ap dot11 24ghz cleanair summary command [865](#)
 show ap dot11 24ghz command [275](#)

- show ap dot11 5ghz [593, 766](#)
- show ap dot11 5ghz cleanair device type command [859](#)
- show ap dot11 cleanair summary [765](#)
- show ap dot11 l2roam [761](#)
- show ap ethernet statistics [771](#)
- show ap groups [772](#)
- show ap image [774](#)
- show ap join stats summary [775](#)
- show ap link-encryption [776](#)
- show ap mac-address [777](#)
- show ap monitor-mode summary [779](#)
- show ap name [810](#)
- show ap name auto-rf [780](#)
- show ap name bhrate [784](#)
- show ap name cac voice [785](#)
- show ap name capwap retransmit [788](#)
- show ap name ccx rm [789](#)
- show ap name cdp neighbors [790](#)
- show ap name channel [791](#)
- show ap name command [783](#)
- show ap name config [792](#)
- show ap name config dot11 [794](#)
- show ap name config fnf [786](#)
- show ap name config slot [798](#)
- show ap name core-dump [802](#)
- show ap name data-plane [803](#)
- show ap name dot11 [167, 804](#)
- show ap name dot11 call-control [787](#)
- show ap name dot11 cleanair [807](#)
- show ap name ethernet statistics [808](#)
- show ap name eventlog [809](#)
- show ap name inventory [811](#)
- show ap name link-encryption [812](#)
- show ap name service-policy [166, 813](#)
- show ap name tcp-adjust-mss [814](#)
- show ap name wlan [815](#)
- show ap slots [817](#)
- show ap summary [818](#)
- show ap tcp-adjust-mss [819](#)
- show ap uptime [820](#)
- show avc client command [66](#)
- show avc wlan command [67](#)
- show cable-diagnostics tdr command [69](#)
- show capwap summary [208](#)
- show cisp command [409](#)
- show class-map command [170](#)
- show eap command [413](#)
- show env command [209](#)
- show errdisable detect command [211](#)
- show errdisable recovery command [212](#)
- show etherchannel command [475](#)
- show flow exporter command [940](#)
- show flow record command [946](#)
- show interfaces command [213](#)
- show interfaces counters command [217](#)
- show ip igmp snooping igmpv2-tracking command [317](#)
- show ip igmp snooping wireless mcast-spi-count command [321](#)
- show ip igmp snooping wireless mgid command [322](#)
- show lacp command [478](#)
- show license right-to-use [74](#)
- show location ap-detect command [77](#)
- show location command [76, 219](#)
- show mac address-table control-packet-learn command [79](#)
- show mac address-table move update command [80](#)
- show mgmt-infra trace messages ilpower-ha command [221](#)
- show monitor command [1015](#)
- show network-policy profile command [222, 227](#)
- show nmsp command [81, 223](#)
- show pagp command [483](#)
- show platform capwap summary [226](#)
- show platform etherchannel command [485](#)
- show platform pm command [486](#)
- show platform stack-manager command [970](#)
- show policy-map command [176](#)
- show redundancy command [971](#)
- show redundancy config-sync command [975](#)
- show sampler command [947](#)
- show switch command [977](#)
- show tech-support wireless command [83](#)
- show udd command [487](#)
- show vlan access-map command [419](#)
- show vlan command [252](#)
- show vlan filter command [256](#)
- show vlan group command [257, 420](#)
- show vtp command [258](#)
- show wireless band-select command [85](#)
- show wireless client ap [821](#)
- show wireless client calls command [86, 171](#)
- show wireless client dot11 command [87, 172](#)
- show wireless client location-calibration command [88](#)
- show wireless client mac-address command [173, 174](#)
- show wireless client probing command [89](#)
- show wireless client summary command [90](#)
- show wireless client timers command [91](#)
- show wireless client voice diagnostics command [92, 175](#)
- show wireless country command [93](#)
- show wireless detail command [96](#)
- show wireless dtls connections command [97](#)
- show wireless interface summary command [228](#)
- show wireless ipv6 statistics command [886](#)
- show wireless load-balancing command [100](#)
- show wireless media-stream group command [276](#)
- show wireless mobility [877](#)
- show wireless multicast command [327](#)
- show wireless multicast group command [328](#)
- show wireless performance command [101](#)
- show wireless pmk-cache command [102](#)
- show wireless probe command [103](#)

show wireless sip preferred-call-no command [104](#)
 show wireless summary command [105](#)
 show wireless vlan group command [264, 269](#)
 show wireless wps rogue ap command [421](#)
 show wireless wps rogue client detailed command [422](#)
 show wireless wps wips statistics command [423](#)
 show wlan command [180, 557](#)
 shutdown command [106, 560](#)
 sip-cac command [561](#)
 snmp-server enable traps bridge command [1023](#)
 snmp-server enable traps call-home command [1024](#)
 snmp-server enable traps command [1019](#)
 snmp-server enable traps CPU command [1025](#)
 snmp-server enable traps envmon command [1026](#)
 snmp-server enable traps errdisable command [1027](#)
 snmp-server enable traps flash command [1028](#)
 snmp-server enable traps license command [1029](#)
 snmp-server enable traps mac-notification command [1030](#)
 snmp-server enable traps port-security command [1031](#)
 snmp-server enable traps power-ethernet command [1032](#)
 snmp-server enable traps snmp command [1033](#)
 snmp-server enable traps stackwise command [1034](#)
 snmp-server enable traps storm-control command [1036](#)
 snmp-server enable traps stpx command [1037](#)
 snmp-server enable traps transceiver command [1038](#)
 snmp-server enable traps vstack command [1039](#)
 snmp-server enable traps wireless command [1040](#)
 snmp-server engineID command [1042](#)
 snmp-server host command [1043](#)
 spanning-tree vlan command [265](#)
 sshow wireless wps wips summary command [424](#)
 stack member number [986](#)
 stack member priority [983](#)
 stack-mac persistent timer command [978](#)
 stack-mac update force command [979](#)
 standby console enable command [980](#)
 static-ip tunneling command [562](#)
 switch priority command [983](#)
 switch provision command [984](#)
 switch renumber command [986](#)
 switch stack port command [981](#)
 Switched Port Analyzer (SPAN) sessions [1015](#)
 switchport access vlan command [493](#)
 switchport command [491](#)
 switchport mode command [494](#)
 switchport nonegotiate command [497](#)
 system env temperature threshold yellow command [107](#)
 system mtu command [229](#)

T

template data timeout command [951](#)

test ap name [822](#)
 test cable-diagnostics tdr command [109](#)
 test capwap ap name [823](#)
 traceroute mac command [110](#)
 traceroute mac ip command [113](#)
 transport command [952](#)
 trapflags [1048](#)
 trapflags ap [824](#)
 trapflags client command [116](#)
 trapflags command [115](#)
 ttl command [953](#)
 type command [117](#)

U

uddl command [499](#)
 uddl port command [501](#)
 uddl reset command [503](#)
 unset command [118](#)

V

version command [120](#)
 vlan access-map command [433](#)
 vlan command [563](#)
 vlan filter command [435](#)
 vlan group command [437](#)

W

wgb non-cisco command [564](#)
 wireless ap-manager interface [230](#)
 wireless broadcast vlan command [268](#)
 wireless client command [121](#)
 wireless client mac-address command [124](#)
 wireless dot11-padding command [429](#)
 wireless exclusionlist command [231](#)
 wireless linktest command [232](#)
 wireless load-balancing command [129](#)
 wireless management interface command [233](#)
 wireless media-stream command [278](#)
 wireless mobility [872](#)
 wireless mobility group keepalive [873](#)
 wireless mobility group member ip [874](#)
 wireless mobility group name [875](#)
 wireless mobility oracle ip [876](#)
 wireless multicast command [329](#)
 wireless peer-blocking forward-upstream command [234](#)
 wireless security web-auth retries command [428](#)
 wireless sip preferred-call-no command [130](#)

wireless wps rogue detection command [432](#)
wireless wps rogue rule command [430](#)
wlan command [270](#), [566](#), [567](#)

wlan shutdown command [568](#)
wmm command [569](#)

