



Network Management Command Reference, Cisco IOS XE Release 3SE (Cisco WLC 5700 Series)

First Published: January 29, 2013

Last Modified: October 07, 2013

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Text Part Number: OL-28522-02

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2013 Cisco Systems, Inc. All rights reserved.



CONTENTS

Preface

Preface v

Document Conventions v

Related Documentation vii

Obtaining Documentation and Submitting a Service Request vii

CHAPTER 1

Using the Command-Line Interface 1

Information About Using the Command-Line Interface 1

Command Modes 1

Using the Help System 3

Understanding Abbreviated Commands 4

No and Default Forms of Commands 5

CLI Error Messages 5

Configuration Logging 5

How to Use the CLI to Configure Features 6

Configuring the Command History 6

Changing the Command History Buffer Size 6

Recalling Commands 6

Disabling the Command History Feature 7

Enabling and Disabling Editing Features 7

Editing Commands Through Keystrokes 9

Editing Command Lines That Wrap 10

Searching and Filtering Output of show and more Commands 11

Accessing the CLI Through a Console Connection or Through Telnet 12

CHAPTER 2

Network Management Commands 13

monitor capture (interface/control plane) 15

monitor capture buffer 19

monitor capture clear	20
monitor capture export	21
monitor capture file	22
monitor capture limit	24
monitor capture match	25
monitor capture start	26
monitor capture stop	27
monitor session	28
monitor session destination	30
monitor session filter	34
monitor session source	36
show monitor	39
show monitor capture	42
snmp-server enable traps	44
snmp-server enable traps bridge	48
snmp-server enable traps call-home	49
snmp-server enable traps cpu	50
snmp-server enable traps envmon	51
snmp-server enable traps errdisable	52
snmp-server enable traps flash	53
snmp-server enable traps license	54
snmp-server enable traps mac-notification	55
snmp-server enable traps port-security	56
snmp-server enable traps power-ethernet	57
snmp-server enable traps snmp	58
snmp-server enable traps stackwise	59
snmp-server enable traps storm-control	61
snmp-server enable traps stpx	62
snmp-server enable traps transceiver	63
snmp-server enable traps vstack	64
snmp-server enable traps wireless	65
snmp-server engineID	67
snmp-server host	68
trapflags	73



Preface

- [Document Conventions](#), page v
- [Related Documentation](#), page vii
- [Obtaining Documentation and Submitting a Service Request](#), page vii

Document Conventions

This document uses the following conventions:

Convention	Description
<code>^</code> or <code>Ctrl</code>	Both the <code>^</code> symbol and <code>Ctrl</code> represent the Control (<code>Ctrl</code>) key on a keyboard. For example, the key combination <code>^D</code> or <code>Ctrl-D</code> means that you hold down the Control key while you press the D key. (Keys are indicated in capital letters but are not case sensitive.)
bold font	Commands and keywords and user-entered text appear in bold font .
<i>Italic font</i>	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic font</i> .
<code>Courier font</code>	Terminal sessions and information the system displays appear in <code>courier font</code> .
Bold Courier font	Bold Courier font indicates text that the user must enter.
[x]	Elements in square brackets are optional.
...	An ellipsis (three consecutive nonbolded periods without spaces) after a syntax element indicates that the element can be repeated.
	A vertical line, called a pipe, indicates a choice within a set of keywords or arguments.
[x y]	Optional alternative keywords are grouped in brackets and separated by vertical bars.

Convention	Description
{x y}	Required alternative keywords are grouped in braces and separated by vertical bars.
[x {y z}]	Nested set of square brackets or braces indicate optional or required choices within optional or required elements. Braces and a vertical bar within square brackets indicate a required choice within an optional element.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
< >	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.

Reader Alert Conventions

This document may use the following conventions for reader alerts:



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the manual.



Tip

Means *the following information will help you solve a problem*.



Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.



Timesaver

Means *the described action saves time*. You can save time by performing the action described in the paragraph.



Warning

Means *reader be warned*. In this situation, you might perform an action that could result in bodily injury.

Related Documentation

**Note**

Before installing or upgrading the controller, refer to the controller release notes.

- Cisco 5700 Series Wireless Controller documentation, located at:
http://www.cisco.com/go/wlc5700_sw
- Cisco Validated Designs documents, located at:
<http://www.cisco.com/go/designzone>
- Error Message Decoder, located at:
<https://www.cisco.com/cgi-bin/Support/Errordecoder/index.cgi>

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.



Using the Command-Line Interface

- [Information About Using the Command-Line Interface, page 1](#)
- [How to Use the CLI to Configure Features, page 6](#)

Information About Using the Command-Line Interface

Command Modes

The Cisco IOS user interface is divided into many different modes. The commands available to you depend on which mode you are currently in. Enter a question mark (?) at the system prompt to obtain a list of commands available for each command mode.

You can start a CLI session through a console connection, through Telnet, a SSH, or by using the browser.

When you start a session, you begin in user mode, often called user EXEC mode. Only a limited subset of the commands are available in user EXEC mode. For example, most of the user EXEC commands are one-time commands, such as **show** commands, which show the current configuration status, and **clear** commands, which clear counters or interfaces. The user EXEC commands are not saved when the controller reboots.

To have access to all commands, you must enter privileged EXEC mode. Normally, you must enter a password to enter privileged EXEC mode. From this mode, you can enter any privileged EXEC command or enter global configuration mode.

Using the configuration modes (global, interface, and line), you can make changes to the running configuration. If you save the configuration, these commands are stored and used when the controller reboots. To access the various configuration modes, you must start at global configuration mode. From global configuration mode, you can enter interface configuration mode and line configuration mode.

This table describes the main command modes, how to access each one, the prompt you see in that mode, and how to exit the mode.

Table 1: Command Mode Summary

Mode	Access Method	Prompt	Exit Method	About This Mode
User EXEC	Begin a session using Telnet, SSH, or console.	Controller>	Enter logout or quit .	Use this mode to <ul style="list-style-type: none"> • Change terminal settings. • Perform basic tests. • Display system information.
Privileged EXEC	While in user EXEC mode, enter the enable command.	Controller#	Enter disable to exit.	Use this mode to verify commands that you have entered. Use a password to protect access to this mode. Use this mode to execute privilege EXEC commands for access points. These commands are not part of the running config of the controller, they are sent to the IOS config of the access point.
Global configuration	While in privileged EXEC mode, enter the configure command.	Controller(config)#	To exit to privileged EXEC mode, enter exit or end , or press Ctrl-Z .	Use this mode to configure parameters that apply to the entire controller. Use this mode to configure access point commands that are part of the running config of the controller.
VLAN configuration	While in global configuration mode, enter the vlan <i>vlan-id</i> command.	Controller(config-vlan)#		

Mode	Access Method	Prompt	Exit Method	About This Mode
			<p>To exit to global configuration mode, enter the exit command.</p> <p>To return to privileged EXEC mode, press Ctrl-Z or enter end.</p>	Use this mode to configure VLAN parameters. When VTP mode is transparent, you can create extended-range VLANs (VLAN IDs greater than 1005) and save configurations in the controller startup configuration file.
Interface configuration	While in global configuration mode, enter the interface command (with a specific interface).	Controller(config-if)#	<p>To exit to global configuration mode, enter exit.</p> <p>To return to privileged EXEC mode, press Ctrl-Z or enter end.</p>	Use this mode to configure parameters for the Ethernet ports.
Line configuration	While in global configuration mode, specify a line with the line vty or line console command.	Controller(config-line)#	<p>To exit to global configuration mode, enter exit.</p> <p>To return to privileged EXEC mode, press Ctrl-Z or enter end.</p>	Use this mode to configure parameters for the terminal line.

Using the Help System

You can enter a question mark (?) at the system prompt to display a list of commands available for each command mode. You can also obtain a list of associated keywords and arguments for any command.

SUMMARY STEPS

1. **help**
2. *abbreviated-command-entry ?*
3. *abbreviated-command-entry <Tab>*
4. **?**
5. *command ?*
6. *command keyword ?*

DETAILED STEPS

	Command or Action	Purpose
Step 1	help Example: Controller# help	Obtains a brief description of the help system in any command mode.
Step 2	<i>abbreviated-command-entry</i> ? Example: Controller# di? dir disable disconnect	Obtains a list of commands that begin with a particular character string.
Step 3	<i>abbreviated-command-entry</i> <Tab> Example: Controller# sh conf <tab> Controller# show configuration	Completes a partial command name.
Step 4	? Example: Controller> ?	Lists all commands available for a particular command mode.
Step 5	<i>command</i> ? Example: Controller> show ?	Lists the associated keywords for a command.
Step 6	<i>command keyword</i> ? Example: Controller(config)# cdp holdtime ? <10-255> Length of time (in sec) that receiver must keep this packet	Lists the associated arguments for a keyword.

Understanding Abbreviated Commands

You need to enter only enough characters for the controller to recognize the command as unique.

This example shows how to enter the **show configuration** privileged EXEC command in an abbreviated form:

```
Controller# show conf
```

No and Default Forms of Commands

Almost every configuration command also has a **no** form. In general, use the **no** form to disable a feature or function or reverse the action of a command. For example, the **no shutdown** interface configuration command reverses the shutdown of an interface. Use the command without the keyword **no** to reenable a disabled feature or to enable a feature that is disabled by default.

Configuration commands can also have a **default** form. The **default** form of a command returns the command setting to its default. Most commands are disabled by default, so the **default** form is the same as the **no** form. However, some commands are enabled by default and have variables set to certain default values. In these cases, the **default** command enables the command and sets variables to their default values.

CLI Error Messages

This table lists some error messages that you might encounter while using the CLI to configure your controller.

Table 2: Common CLI Error Messages

Error Message	Meaning	How to Get Help
% Ambiguous command: "show con"	You did not enter enough characters for your controller to recognize the command.	Reenter the command followed by a question mark (?) without any space between the command and the question mark. The possible keywords that you can enter with the command appear.
% Incomplete command.	You did not enter all of the keywords or values required by this command.	Reenter the command followed by a question mark (?) with a space between the command and the question mark. The possible keywords that you can enter with the command appear.
% Invalid input detected at '^' marker.	You entered the command incorrectly. The caret (^) marks the point of the error.	Enter a question mark (?) to display all of the commands that are available in this command mode. The possible keywords that you can enter with the command appear.

Configuration Logging

You can log and view changes to the controller configuration. You can use the Configuration Change Logging and Notification feature to track changes on a per-session and per-user basis. The logger tracks each configuration command that is applied, the user who entered the command, the time that the command was entered, and the parser return code for the command. This feature includes a mechanism for asynchronous

notification to registered applications whenever the configuration changes. You can choose to have the notifications sent to the syslog.

**Note**

Only CLI or HTTP changes are logged.

How to Use the CLI to Configure Features

Configuring the Command History

The software provides a history or record of commands that you have entered. The command history feature is particularly useful for recalling long or complex commands or entries, including access lists. You can customize this feature to suit your needs.

Changing the Command History Buffer Size

By default, the controller records ten command lines in its history buffer. You can alter this number for a current terminal session or for all sessions on a particular line. This procedure is optional.

SUMMARY STEPS

1. **terminal history** [*size number-of-lines*]

DETAILED STEPS

	Command or Action	Purpose
Step 1	terminal history [<i>size number-of-lines</i>] Example: Controller# terminal history size 200	Changes the number of command lines that the controller records during the current terminal session in privileged EXEC mode. You can configure the size from 0 to 256.

Recalling Commands

To recall commands from the history buffer, perform one of the actions listed in this table. These actions are optional.

**Note**

The arrow keys function only on ANSI-compatible terminals such as VT100s.

SUMMARY STEPS

1. **Ctrl-P** or use the **up arrow** key
2. **Ctrl-N** or use the **down arrow** key
3. **show history**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Ctrl-P or use the up arrow key	Recalls commands in the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Step 2	Ctrl-N or use the down arrow key	Returns to more recent commands in the history buffer after recalling commands with Ctrl-P or the up arrow key. Repeat the key sequence to recall successively more recent commands.
Step 3	show history Example: Controller# show history	Lists the last several commands that you just entered in privileged EXEC mode. The number of commands that appear is controlled by the setting of the terminal history global configuration command and the history line configuration command.

Disabling the Command History Feature

The command history feature is automatically enabled. You can disable it for the current terminal session or for the command line. This procedure is optional.

SUMMARY STEPS

1. **terminal no history**

DETAILED STEPS

	Command or Action	Purpose
Step 1	terminal no history Example: Controller# terminal no history	Disables the feature during the current terminal session in privileged EXEC mode.

Enabling and Disabling Editing Features

Although enhanced editing mode is automatically enabled, you can disable it and reenable it.

SUMMARY STEPS

1. `terminal editing`
2. `terminal no editing`

DETAILED STEPS

	Command or Action	Purpose
Step 1	terminal editing Example: <code>Controller# terminal editing</code>	Reenables the enhanced editing mode for the current terminal session in privileged EXEC mode.
Step 2	terminal no editing Example: <code>Controller# terminal no editing</code>	Disables the enhanced editing mode for the current terminal session in privileged EXEC mode.

Editing Commands Through Keystrokes

The keystrokes help you to edit the command lines. These keystrokes are optional.


Note

The arrow keys function only on ANSI-compatible terminals such as VT100s.

Table 3: Editing Commands

Editing Commands	Description
Ctrl-B or use the left arrow key	Moves the cursor back one character.
Ctrl-F or use the right arrow key	Moves the cursor forward one character.
Ctrl-A	Moves the cursor to the beginning of the command line.
Ctrl-E	Moves the cursor to the end of the command line.
Esc B	Moves the cursor back one word.
Esc F	Moves the cursor forward one word.
Ctrl-T	Transposes the character to the left of the cursor with the character located at the cursor.
Delete or Backspace key	Erases the character to the left of the cursor.
Ctrl-D	Deletes the character at the cursor.
Ctrl-K	Deletes all characters from the cursor to the end of the command line.
Ctrl-U or Ctrl-X	Deletes all characters from the cursor to the beginning of the command line.
Ctrl-W	Deletes the word to the left of the cursor.
Esc D	Deletes from the cursor to the end of the word.
Esc C	Capitalizes at the cursor.
Esc L	Changes the word at the cursor to lowercase.
Esc U	Capitalizes letters from the cursor to the end of the word.

Ctrl-V or Esc Q	Designates a particular keystroke as an executable command, perhaps as a shortcut.
Return key	<p>Scrolls down a line or screen on displays that are longer than the terminal screen can display.</p> <p>Note The More prompt is used for any output that has more lines than can be displayed on the terminal screen, including show command output. You can use the Return and Space bar keystrokes whenever you see the More prompt.</p>
Space bar	Scrolls down one screen.
Ctrl-L or Ctrl-R	Redisplays the current command line if the controller suddenly sends a message to your screen.

Editing Command Lines That Wrap

You can use a wraparound feature for commands that extend beyond a single line on the screen. When the cursor reaches the right margin, the command line shifts ten spaces to the left. You cannot see the first ten characters of the line, but you can scroll back and check the syntax at the beginning of the command. The keystroke actions are optional.

To scroll back to the beginning of the command entry, press **Ctrl-B** or the left arrow key repeatedly. You can also press **Ctrl-A** to immediately move to the beginning of the line.



Note

The arrow keys function only on ANSI-compatible terminals such as VT100s.

The following example shows how to wrap a command line that extends beyond a single line on the screen.

SUMMARY STEPS

1. **access-list**
2. **Ctrl-A**
3. **Return** key

DETAILED STEPS

	Command or Action	Purpose
Step 1	access-list Example: <code>Controller(config)# access-list 101 permit</code>	<p>Displays the global configuration command entry that extends beyond one line.</p> <p>When the cursor first reaches the end of the line, the line is shifted ten spaces to the left and redisplayed. The dollar sign (\$) shows that the</p>

	Command or Action	Purpose
	<pre> tcp 10.15.22.25 255.255.255.0 10.15.22.35 Controller(config)# \$ 101 permit tcp 10.15.22.25 255.255.255.0 10.15.22.35 255.25 Controller(config)# \$t tcp 10.15.22.25 255.255.255.0 131.108.1.20 255.255.255.0 eq Controller(config)# \$15.22.25 255.255.255.0 10.15.22.35 255.255.255.0 eq 45 </pre>	line has been scrolled to the left. Each time the cursor reaches the end of the line, the line is again shifted ten spaces to the left.
Step 2	Ctrl-A Example: <pre> Controller(config)# access-list 101 permit tcp 10.15.22.25 255.255.255.0 10.15.2\$ </pre>	<p>Checks the complete syntax.</p> <p>The dollar sign (\$) appears at the end of the line to show that the line has been scrolled to the right.</p>
Step 3	Return key	<p>Execute the commands.</p> <p>The software assumes that you have a terminal screen that is 80 columns wide. If you have a different width, use the terminal width privileged EXEC command to set the width of your terminal.</p> <p>Use line wrapping with the command history feature to recall and modify previous complex command entries.</p>

Searching and Filtering Output of show and more Commands

You can search and filter the output for **show** and **more** commands. This is useful when you need to sort through large amounts of output or if you want to exclude output that you do not need to see. Using these commands is optional.

SUMMARY STEPS

1. `{show | more} command | {begin | include | exclude} regular-expression`

DETAILED STEPS

	Command or Action	Purpose
Step 1	<pre> {show more} command {begin include exclude} regular-expression </pre> Example: <pre> Controller# show interfaces include protocol Vlan1 is up, line protocol is up Vlan10 is up, line protocol is down GigabitEthernet1/0/1 is up, line protocol is down GigabitEthernet1/0/2 is up, line protocol is up </pre>	<p>Searches and filters the output.</p> <p>Expressions are case sensitive. For example, if you enter exclude output, the lines that contain output are not displayed, but the lines that contain output appear.</p>

Accessing the CLI Through a Console Connection or Through Telnet

Before you can access the CLI, you must connect a terminal or a PC to the controller console or connect a PC to the Ethernet management port and then power on the controller, as described in the hardware installation guide that shipped with your controller.

If your controller is already configured, you can access the CLI through a local console connection or through a remote Telnet session, but your controller must first be configured for this type of access.

You can use one of these methods to establish a connection with the controller:

- Connect the controller console port to a management station or dial-up modem, or connect the Ethernet management port to a PC. For information about connecting to the console or Ethernet management port, see the controller hardware installation guide.
- Use any Telnet TCP/IP or encrypted Secure Shell (SSH) package from a remote management station. The controller must have network connectivity with the Telnet or SSH client, and the controller must have an enable secret password configured.
 - The controller supports up to 16 simultaneous Telnet sessions. Changes made by one Telnet user are reflected in all other Telnet sessions.
 - The controller supports up to five simultaneous secure SSH sessions.

After you connect through the console port, through the Ethernet management port, through a Telnet session or through an SSH session, the user EXEC prompt appears on the management station.



Network Management Commands

- [monitor capture \(interface/control plane\), page 15](#)
- [monitor capture buffer, page 19](#)
- [monitor capture clear, page 20](#)
- [monitor capture export, page 21](#)
- [monitor capture file, page 22](#)
- [monitor capture limit, page 24](#)
- [monitor capture match, page 25](#)
- [monitor capture start, page 26](#)
- [monitor capture stop, page 27](#)
- [monitor session, page 28](#)
- [monitor session destination, page 30](#)
- [monitor session filter, page 34](#)
- [monitor session source, page 36](#)
- [show monitor, page 39](#)
- [show monitor capture, page 42](#)
- [snmp-server enable traps, page 44](#)
- [snmp-server enable traps bridge, page 48](#)
- [snmp-server enable traps call-home, page 49](#)
- [snmp-server enable traps cpu, page 50](#)
- [snmp-server enable traps envmon, page 51](#)
- [snmp-server enable traps errdisable, page 52](#)
- [snmp-server enable traps flash, page 53](#)
- [snmp-server enable traps license, page 54](#)
- [snmp-server enable traps mac-notification, page 55](#)

- [snmp-server enable traps port-security, page 56](#)
- [snmp-server enable traps power-ethernet, page 57](#)
- [snmp-server enable traps snmp, page 58](#)
- [snmp-server enable traps stackwise, page 59](#)
- [snmp-server enable traps storm-control, page 61](#)
- [snmp-server enable traps stpx, page 62](#)
- [snmp-server enable traps transceiver, page 63](#)
- [snmp-server enable traps vstack, page 64](#)
- [snmp-server enable traps wireless, page 65](#)
- [snmp-server engineID, page 67](#)
- [snmp-server host, page 68](#)
- [trapflags, page 73](#)

monitor capture (interface/control plane)

To configure monitor capture points specifying an attachment point and the packet flow direction or add more attachment points to a capture point, use the **monitor capture** command in privileged EXEC mode. To disable the monitor capture with the specified attachment point and the packet flow direction or disable one of multiple attachment points on a capture point, use the **no** form of this command.

monitor capture {*capture-name*} {**interface** *interface-type* *interface-id* | **control-plane**} {**in** | **out** | **both**}

no monitor capture {*capture-name*} {**interface** *interface-type* *interface-id* | **control-plane**} {**in** | **out** | **both**}

Syntax Description

<i>capture-name</i>	The name of the capture to be defined.
interface <i>interface-type</i> <i>interface-id</i>	Specifies an interface with <i>interface-type</i> and <i>interface-id</i> as an attachment point. The arguments have these meanings: <ul style="list-style-type: none"> • GigabitEthernet <i>interface-id</i>—A Gigabit Ethernet IEEE 802.3z interface. • vlan <i>vlan-id</i>—A VLAN. The range for <i>vlan-id</i> is 1 to 4095. • capwap <i>capwap-id</i>—Specifies a Control and Provisioning of Wireless Access Points Protocol (CAPWAP) tunneling interface. For a list of CAPWAP tunnels that can be used as attachment points, use the show capwap summary command. <p>Note This is the only attachment point that can be used for a wireless capture. When using this interface as an attachment point, no other interface types can be used as attachment points on the same capture point.</p>
control-plane	Specifies the control plane as an attachment point.
in out both	Specifies the traffic direction to be captured.

Command Default

A Wireshark capture is not configured.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Once an attachment point has been associated with a capture point using this command, the only way to change its direction is to remove the attachment point using the **no** form of the command and reattach the attachment point with the new direction. An attachment point's direction cannot be overridden.

If an attachment point is removed from a capture point and only one attachment point is associated with it, the capture point is effectively deleted.

Multiple attachment points can be associated with a capture point by re-running this command with another attachment point. An example is provided below.

Multiple capture points can be defined, but only one can be active at a time. In other words, you have to stop one before you can start the other.

Packets captured in the output direction of an interface might not reflect the changes made by switch rewrite (includes TTL, VLAN tag, CoS, checksum, MAC addresses, DSCP, precedent, UP, etc.).

No specific order applies when defining a capture point; you can define capture point parameters in any order. The Wireshark CLI allows as many parameters as possible on a single line. This limits the number of commands required to define a capture point.

Neither VRFs, management ports, nor private VLANs can be used as attachment points.

Wireshark cannot capture packets on a destination SPAN port.

When a VLAN is used as a Wireshark attachment point, packets are captured in the input direction only.

Wireless (CAPWAP) Usage Considerations

The only form of wireless capture is a CAPWAP tunnel capture.

When capturing CAPWAP tunnels, no other interface types can be used as attachment points on the same capture point. Also, the only different type of attachment point allowed on the same capture point is the control plane. The combination of control plane and CAPWAP tunnel attachment points should be able to capture all wireless-related traffic.

Capturing multiple CAPWAP tunnels is supported. ACLs for each CAPWAP tunnel will be combined and sent to the switch as a single ACL.

Core filters will not be applied and can be omitted when capturing a CAPWAP tunnel. When control plane and CAPWAP tunnels are mixed, the core filter will not be applied on the control plane packets either.

To capture a CAPWAP non-data tunnel, capture traffic on the management VLAN and apply an appropriate ACL to filter the traffic. Note that this ACL will be combined with the core filter ACL and assigned to the switch as a single ACL.

Examples

To define a capture point using a physical interface as an attachment point:

```
Controller# monitor capture mycap interface GigabitEthernet1/0/1 in
Controller# monitor capture mycap match ipv4 any any
```

**Note**

The second command defines the core filter for the capture point. This is required for a functioning capture point unless you are using a CAPWAP tunneling attachment point in your capture point.

If you are using CAPWAP tunneling attachment points in your capture point, you cannot use core filters.

To define a capture point with multiple attachment points:

```
Controller# monitor capture mycap interface GigabitEthernet1/0/1 in
Controller# monitor capture mycap match ipv4 any any
Controller# monitor capture mycap control-plane in
Controller# show monitor capture mycap parameter
    monitor capture mycap interface GigabitEthernet1/0/1 in
    monitor capture mycap control-plane in
```

To remove an attachment point from a capture point defined with multiple attachment points:

```
Controller# show monitor capture mycap parameter
    monitor capture mycap interface GigabitEthernet1/0/1 in
    monitor capture mycap control-plane in
Controller# no monitor capture mycap control-plane
Controller# show monitor capture mycap parameter
    monitor capture mycap interface GigabitEthernet1/0/1 in
```

To define a capture point with a CAPWAP attachment point:

```
Controller# show capwap summary
```

```
CAPWAP Tunnels General Statistics:
  Number of Capwap Data Tunnels      = 1
  Number of Capwap Mobility Tunnels   = 0
  Number of Capwap Multicast Tunnels  = 0
```

Name	APName	Type	PhyPortIf	Mode	McastIf
Ca0	AP442b.03a9.6715	data	Gi3/0/6	unicast	-

Name	SrcIP	SrcPort	DestIP	DstPort	DtlsEn	MTU	Xact
Ca0	10.10.14.32	5247	10.10.14.2	38514	No	1449	0

```
Controller# monitor capture mycap interface capwap 0 both
Controller# monitor capture mycap file location flash:mycap.pcap
Controller# monitor capture mycap file buffer-size 1
Controller# monitor capture mycap start
```

```
*Aug 20 11:02:21.983: %BUFCAP-6-ENABLE: Capture Point mycap enabled.on
```

```
Controller# show monitor capture mycap parameter
    monitor capture mycap interface capwap 0 in
    monitor capture mycap interface capwap 0 out
    monitor capture mycap file location flash:mycap.pcap buffer-size 1
Controller#
Controller# show monitor capture mycap
```

```
Status Information for Capture mycap
  Target Type:
  Interface: CAPWAP,
  Ingress:
  0
  Egress:
  0
  Status : Active
  Filter Details:
    Capture all packets
  Buffer Details:
    Buffer Type: LINEAR (default)
  File Details:
    Associated file name: flash:mycap.pcap
    Size of buffer(in MB): 1
  Limit Details:
    Number of Packets to capture: 0 (no limit)
    Packet Capture duration: 0 (no limit)
    Packet Size to capture: 0 (no limit)
    Packets per second: 0 (no limit)
    Packet sampling rate: 0 (no sampling)
Controller#
```

monitor capture (interface/control plane)

```

Controller# show monitor capture file flash:mycap.pcap
 1 0.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 2 0.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 3 2.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 4 2.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 5 3.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 6 4.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 7 4.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 8 5.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
 9 5.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
10 6.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
11 8.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
12 9.225986 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
13 9.225986 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
14 9.225986 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
15 9.231998 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
16 9.231998 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
17 9.231998 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
18 9.236987 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
19 10.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
20 10.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
21 12.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
22 12.239993 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
23 12.244997 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
24 12.244997 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
25 12.250994 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
26 12.256990 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
27 12.262987 10.10.14.2 -> 10.10.14.32 DTLSv1.0 Application Data
28 12.499974 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....
29 12.802012 10.10.14.3 -> 10.10.14.255 NBNS Name query NB WPAD.<00>
30 13.000000 00:00:00:00:00:00 -> 3c:ce:73:39:c6:60 IEEE 802.11 Probe Request, SN=0, FN=0,
Flags=.....

```

Related Commands

Command	Description
monitor capture buffer	Configures the buffer for monitor capture (WireShark).
monitor capture file	Configures monitor capture (WireShark) storage file attributes.
show monitor capture	show monitor capture

monitor capture buffer

To configure the buffer for monitor capture (WireShark), use the **monitor capture buffer** command in privileged EXEC mode. To disable the monitor capture buffer or change the buffer back to a default linear buffer from a circular buffer, use the **no** form of this command.

monitor capture {*capture-name*} **buffer** {**circular** [*size buffer-size*] | *size buffer-size*}

no monitor capture {*capture-name*} **buffer** [**circular**]

Syntax Description

<i>capture-name</i>	The name of the capture whose buffer is to be configured.
circular	Specifies that the buffer is of a circular type. The circular type of buffer continues to capture data, even after the buffer is consumed, by overwriting the data captured previously.
<i>size buffer-size</i>	(Optional) Specifies the size of the buffer. The range is from 1 MB to 100 MB.

Command Default

A linear buffer is configured.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

When you first configure a WireShark capture, a circular buffer of a small size is suggested.

Examples

To configure a circular buffer with a size of 1 MB:

```
Controller# monitor capture mycap buffer circular size 1
```

Related Commands

Command	Description
monitor capture (interface/control plane)	Configures monitor capture (WireShark) specifying an attachment point and the packet flow direction.
monitor capture file	Configures monitor capture (WireShark) storage file attributes.
show monitor capture	show monitor capture

monitor capture clear

To clears the monitor capture (WireShark) buffer, use the **monitor capture clear** command in privileged EXEC mode.

monitor capture *{capture-name}* **clear**

Syntax Description	<i>capture-name</i>	The name of the capture whose buffer is to be cleared.
--------------------	---------------------	--

Command Default	The buffer content is not cleared.
-----------------	------------------------------------

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **monitor capture clear** command either during capture or after the capture has stopped either because one or more end conditions has been met, or you entered the **monitor capture stop** command. If you enter the **monitor capture clear** command after the capture has stopped, the **monitor capture export** command that is used to store the contents of the captured packets in a file will have no impact because the buffer has no captured packets.

If you have more than one capture that is storing packets in a buffer, clear the buffer before starting a new capture to avoid memory loss.

Examples

To clear the buffer contents for capture mycap:

```
Controller# monitor capture mycap clear
```

monitor capture export

To export a monitor capture (WireShark) to a file, use the **monitor capture export** command in privileged EXEC mode.

monitor capture {*capture-name*} **export** *file-location* : *file-name*

Syntax Description

<i>capture-name</i>	The name of the capture to be exported.
<i>file-location</i> : <i>file-name</i>	(Optional) Specifies the location and file name of the capture storage file. Acceptable values for <i>file-location</i> : <ul style="list-style-type: none"> • flash—On-board flash storage • (usbflash0:)— USB drive

Command Default

The captured packets are not stored.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **monitor capture export** command only when the storage destination is a capture buffer. The file may be stored either remotely or locally. Use this command either during capture or after the packet capture has stopped. The packet capture is stopped when one or more end conditions have been met or you entered the **monitor capture stop** command.

When WireShark is used on switches in a stack, packet captures can be stored only on the devices specified for *file-location* above that are connected to the active switch. Example: flash1 is connected to the active switch. flash2 is connected to the secondary switch. Only flash1 can be used to store packet captures.



Note

Attempts to store packet captures on unsupported devices or devices not connected to the active switch will probably result in errors.

Examples

To export the capture buffer contents to mycap.pcap on a flash drive:

```
Controller# monitor capture mycap export flash:mycap.pcap
```

monitor capture file

To configure monitor capture (WireShark) storage file attributes, use the **monitor capture file** command in privileged EXEC mode. To remove a storage file attribute, use the **no** form of this command.

monitor capture {*capture-name*} **file** {[**buffer-size** *temp-buffer-size*][**location** *file-location* : *file-name*][**ring** *number-of-ring-files*][**size** *total-size*]}

no monitor capture {*capture-name*} **file** {[**buffer-size**][**location**][**ring**][**size**]}

Syntax Description

<i>capture-name</i>	The name of the capture to be modified.
buffer-size <i>temp-buffer-size</i>	(Optional) Specifies the size of the temporary buffer. The range for <i>temp-buffer-size</i> is 1 to 100 MB. This is specified to reduce packet loss.
location <i>file-location</i> : <i>file-name</i>	(Optional) Specifies the location and file name of the capture storage file. Acceptable values for <i>file-location</i> : <ul style="list-style-type: none"> • flash—On-board flash storage • (usbflash0:)— USB drive
ring <i>number-of-ring-files</i>	(Optional) Specifies that the capture is to be stored in a circular file chain and the number of files in the file ring.
size <i>total-size</i>	(Optional) Specifies the total size of the capture files.

Command Default

None

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **monitor capture file** command only when the storage destination is a file. The file may be stored either remotely or locally. Use this command after the packet capture has stopped. The packet capture is stopped when one or more end conditions have been met or you entered the **monitor capture stop** command.

When WireShark is used on switches in a stack, packet captures can be stored only on the devices specified for *file-location* above that are connected to the active switch. Example: flash1 is connected to the active switch. flash2 is connected to the secondary switch. Only flash1 can be used to store packet captures.

**Note**

Attempts to store packet captures on unsupported devices or devices not connected to the active switch will probably result in errors.

Examples

To specify that the storage file name is mycap.pcap, stored on a flash drive:

```
Controller# monitor capture mycap file location flash:mycap.pcap
```

Related Commands

Command	Description
monitor capture (interface/control plane)	Configures monitor capture (WireShark) specifying an attachment point and the packet flow direction.
monitor capture buffer	Configures the buffer for monitor capture (WireShark).
show monitor capture	show monitor capture

monitor capture limit

To configure capture limits, use the **monitor capture limit** command in privileged EXEC mode. To remove the capture limits, use the **no** form of this command.

monitor capture {*capture-name*} **limit** {[**duration** *seconds*][**packet-length** *size*][**packets** *num*]}

no monitor capture {*capture-name*} **limit** [**duration**][**packet-length**][**packets**]

Syntax Description

<i>capture-name</i>	The name of the capture to be assigned capture limits.
duration <i>seconds</i>	(Optional) Specifies the duration of the capture, in seconds. The range is from 1 to 1000000.
packet-length <i>size</i>	(Optional) Specifies the packet length, in bytes. If the actual packet is longer than the specified length, only the first set of bytes whose number is denoted by the bytes argument is stored.
packets <i>num</i>	(Optional) Specifies the number of packets to be processed for capture.

Command Default

Capture limits are not configured.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

To configure a session limit of 60 seconds and a packet segment length of 400 bytes:

```
Controller# monitor capture mycap limit duration 60 packet-len 400
```


monitor capture match



Note

Do not use this command when capturing a CAPWAP tunnel. Also, when control plane and CAPWAP tunnels are mixed, this command will have no effect.

To define an explicit inline core filter for a monitor (Wireshark) capture, use the **monitor capture match** command in privileged EXEC mode. To remove this filter, use the **no** form of this command.

monitor capture {*capture-name*} **match** {**any** | **mac** *mac-match-string* | **ipv4** {**any** | **host** | **protocol**} {**any** | **host**} | **ipv6** {**any** | **host** | **protocol**} {**any** | **host**}}

no monitor capture {*capture-name*} **match**

Syntax Description

<i>capture-name</i>	The name of the capture to be assigned a core filter.
any	Specifies all packets.
mac <i>mac-match-string</i>	Specifies a Layer 2 packet.
ipv4	Specifies IPv4 packets.
host	Specifies the host.
protocol	Specifies the protocol.
ipv6	Specifies IPv6 packets.

Command Default

A core filter is not configured.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Examples

To define a capture point and the core filter for the capture point that matches to any IP version 4 packets on the source or destination:

```
Controller# monitor capture mycap interface GigabitEthernet1/0/1 in
Controller# monitor capture mycap match ipv4 any any
```

monitor capture start

To start the capture of packet data at a traffic trace point into a buffer, use the **monitor capture start** command in privileged EXEC mode.

monitor capture *{capture-name}* **start**

Syntax Description	<i>capture-name</i>	The name of the capture to be started.
--------------------	---------------------	--

Command Default	The buffer content is not cleared.
-----------------	------------------------------------

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **monitor capture clear** command to enable the packet data capture after the capture point is defined. To stop the capture of packet data, use the **monitor capture stop** command.

Ensure that system resources such as CPU and memory are available before starting a capture.

Examples

To start capturing buffer contents:

```
Controller# monitor capture mycap start
```

monitor capture stop

To stop the capture of packet data at a traffic trace point, use the **monitor capture stop** command in privileged EXEC mode.

monitor capture {*capture-name*} **stop**

Syntax Description

<i>capture-name</i>	The name of the capture to be stopped.
---------------------	--

Command Default

The packet data capture is ongoing.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

Use the **monitor capture stop** command to stop the capture of packet data that you started using the **monitor capture start** command. You can configure two types of capture buffers: linear and circular. When the linear buffer is full, data capture stops automatically. When the circular buffer is full, data capture starts from the beginning and the data is overwritten.

Examples

To stop capturing buffer contents:

```
Controller# monitor capture mycap stop
```

monitor session

To create a new Ethernet Switched Port Analyzer (SPAN) or a Remote Switched Port Analyzer (RSPAN) session configuration for analyzing traffic between ports or add to an existing session configuration, use the **monitor session** global configuration command. To clear SPAN or RSPAN sessions, use the **no** form of this command.

```
monitor session session-number {destination | filter | source}
no monitor session {session-number [destination | filter | source] | all | local | range session-range | remote}
```

Syntax Description

<i>session-number</i>	
all	Clears all monitor sessions.
local	Clears all local monitor sessions.
range <i>session-range</i>	Clears monitor sessions in the specified range.
remote	Clears all remote monitor sessions.

Command Default

No monitor sessions are configured.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can verify your settings by entering the **show monitor** privileged EXEC command. You can display SPAN, RSPAN, FSPAN, and FRSPAN configuration on the switch by entering the **show running-config** privileged EXEC command. SPAN information appears near the end of the output.

Examples

This example shows how to create a local SPAN session 1 to monitor traffic on Po13 (an EtherChannel port) and limit SPAN traffic in the session only to VLAN 1281. Egress traffic replicates the source; ingress forwarding is not enabled.

```
Controller(config)# monitor session 1 source interface Po13
Controller(config)# monitor session 1 filter vlan 1281
Controller(config)# monitor session 1 destination interface GigabitEthernet2/0/36
encapsulation replicate
Controller(config)# monitor session 1 destination interface GigabitEthernet3/0/36
```

encapsulation replicate

The following is the output of a **show monitor session all** command after completing these setup instructions:

```
Controller# show monitor session all

Session 1
-----
Type                : Local Session
Source Ports        :
  Both              : Po13
Destination Ports   : Gi2/0/36,Gi3/0/36
  Encapsulation     : Replicate
    Ingress         : Disabled
Filter VLANs        : 1281
...
```

Related Commands

Command	Description
monitor session destination	Configures a FSPAN or FRSPAN destination session.
monitor session filter	Configures a FSPAN or FRSPAN session filter.
monitor session source	Configures a FSPAN or FRSPAN source session.
show monitor	Displays information about all SPAN and RSPAN sessions.

monitor session destination

To start a new Switched Port Analyzer (SPAN) session or Remote SPAN (RSPAN) destination session, to enable ingress traffic on the destination port for a network security device (such as a Cisco IDS Sensor Appliance), and to add or delete interfaces or VLANs to or from an existing SPAN or RSPAN session, use the **monitor session destination** global configuration command. To remove the SPAN or RSPAN session or to remove destination interfaces from the SPAN or RSPAN session, use the **no** form of this command.

monitor session *session-number* **destination** {**interface** *interface-id* [, | -] [**encapsulation** {**replicate** | **dot1q**}] {**ingress** [**dot1q** | **untagged**] } } | {**remote**} **vlan** *vlan-id*

no monitor session *session-number* **destination** {**interface** *interface-id* [, | -] [**encapsulation** {**replicate** | **dot1q**}] {**ingress** [**dot1q** | **untagged**] } } | {**remote**} **vlan** *vlan-id*

Syntax Description

<i>session-number</i>	
interface <i>interface-id</i>	Specifies the destination or source interface for a SPAN or RSPAN session. Valid interfaces are physical ports (including type, stack member, module, and port number). For source interface, port channel is also a valid interface type, and the valid range is 1 to 128.
,	(Optional) Specifies a series of interfaces or VLANs, or separates a range of interfaces or VLANs from a previous range. Enter a space before and after the comma.
-	(Optional) Specifies a range of interfaces or VLANs. Enter a space before and after the hyphen.
encapsulation replicate	(Optional) Specifies that the destination interface replicates the source interface encapsulation method. If not selected, the default is to send packets in native form (untagged). These keywords are valid only for local SPAN. For RSPAN, the RSPAN VLAN ID overwrites the original VLAN ID; therefore, packets are always sent untagged. The encapsulation options are ignored with the no form of the command.
encapsulation dot1q	(Optional) Specifies that the destination interface accepts the source interface incoming packets with IEEE 802.1Q encapsulation. These keywords are valid only for local SPAN. For RSPAN, the RSPAN VLAN ID overwrites the original VLAN ID; therefore, packets are always sent untagged. The encapsulation options are ignored with the no form of the command.
ingress	Enables ingress traffic forwarding.

dot1q	(Optional) Accepts incoming packets with IEEE 802.1Q encapsulation with the specified VLAN as the default VLAN.
untagged	(Optional) Accepts incoming packets with untagged encapsulation with the specified VLAN as the default VLAN.
isl	Specifies ingress forwarding using ISL encapsulation.
remote	Specifies the remote VLAN for an RSPAN source or destination session. The range is 2 to 1001 and 1006 to 4094. The RSPAN VLAN cannot be VLAN 1 (the default VLAN) or VLAN IDs 1002 to 1005 (reserved for Token Ring and FDDI VLANs).
vlan <i>vlan-id</i>	Sets the default VLAN for ingress traffic when used with only the ingress keyword.

Command Default

No monitor sessions are configured.

If **encapsulation replicate** is not specified on a local SPAN destination port, packets are sent in native form with no encapsulation tag.

Ingress forwarding is disabled on destination ports.

You can specify **all**, **local**, **range *session-range***, or **remote** with the **no monitor session** command to clear all SPAN and RSPAN, all local SPAN, a range, or all RSPAN sessions.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can set a combined maximum of 8 local SPAN sessions and RSPAN source sessions. You can have a total of 66 SPAN and RSPAN sessions on a switch or switch stack.

A SPAN or RSPAN destination must be a physical port.

You can have a maximum of 64 destination ports on a switch or a switch stack.

Each session can include multiple ingress or egress source ports or VLANs, but you cannot combine source ports and source VLANs in a single session. Each session can include multiple destination ports.

When you use VLAN-based SPAN (VSPAN) to analyze network traffic in a VLAN or set of VLANs, all active ports in the source VLANs become source ports for the SPAN or RSPAN session. Trunk ports are included as source ports for VSPAN, and only packets with the monitored VLAN ID are sent to the destination port.

You can monitor traffic on a single port or VLAN or on a series or range of ports or VLANs. You select a series or range of interfaces or VLANs by using the [, | -] options.

If you specify a series of VLANs or interfaces, you must enter a space before and after the comma. If you specify a range of VLANs or interfaces, you must enter a space before and after the hyphen (-).

EtherChannel ports can be configured as SPAN or RSPAN destination ports. A physical port that is a member of an EtherChannel group can be used as a destination port, but it cannot participate in the EtherChannel group while it is as a SPAN destination.

A port used as a destination port cannot be a SPAN or RSPAN source, nor can a port be a destination port for more than one session at a time.

You can enable IEEE 802.1x authentication on a port that is a SPAN or RSPAN destination port; however, IEEE 802.1x authentication is disabled until the port is removed as a SPAN destination. If IEEE 802.1x authentication is not available on the port, the switch returns an error message. You can enable IEEE 802.1x authentication on a SPAN or RSPAN source port.

If ingress traffic forwarding is enabled for a network security device, the destination port forwards traffic at Layer 2.

Destination ports can be configured to function in these ways:

- When you enter **monitor session session_number destination interface interface-id** with no other keywords, egress encapsulation is untagged, and ingress forwarding is not enabled.
- When you enter **monitor session session_number destination interface interface-id ingress**, egress encapsulation is untagged; ingress encapsulation depends on the keywords that follow—**dot1q** or **untagged**.
- When you enter **monitor session session_number destination interface interface-id encapsulation replicate** with no other keywords, egress encapsulation replicates the source interface encapsulation; ingress forwarding is not enabled. (This applies to local SPAN only; RSPAN does not support encapsulation replication.)
- When you enter **monitor session session_number destination interface interface-id encapsulation replicate ingress**, egress encapsulation replicates the source interface encapsulation; ingress encapsulation depends on the keywords that follow—**dot1q** or **untagged**. (This applies to local SPAN only; RSPAN does not support encapsulation replication.)

You can verify your settings by entering the **show monitor** privileged EXEC command. You can display SPAN, RSPAN, FSPAN, and FRSPAN configuration on the switch by entering the **show running-config** privileged EXEC command. SPAN information appears near the end of the output.

Examples

This example shows how to create a local SPAN session 1 to monitor both sent and received traffic on source port 1 on stack member 1 to destination port 2 on stack member 2:

```
Controller(config)# monitor session 1 source interface gigabitethernet1/0/1 both
Controller(config)# monitor session 1 destination interface gigabitethernet1/0/2
```

This example shows how to delete a destination port from an existing local SPAN session:

```
Controller(config)# no monitor session 2 destination interface gigabitethernet1/0/2
```


This example shows how to configure RSPAN source session 1 to monitor a source interface and to configure the destination RSPAN VLAN 900:

```
Controller(config)# monitor session 1 source interface gigabitethernet1/0/1
Controller(config)# monitor session 1 destination remote vlan 900
Controller(config)# end
```

This example shows how to configure an RSPAN destination session 10 in the switch receiving the monitored traffic:

```
Controller(config)# monitor session 10 source remote vlan 900
Controller(config)# monitor session 10 destination interface gigabitethernet1/0/2
```

This example shows how to configure the destination port for ingress traffic on VLAN 5 by using a security device that supports IEEE 802.1Q encapsulation. Egress traffic replicates the source; ingress traffic uses IEEE 802.1Q encapsulation.

```
Controller(config)# monitor session 2 destination interface gigabitethernet1/0/2 encapsulation
dot1q ingress dot1q vlan 5
```

This example shows how to configure the destination port for ingress traffic on VLAN 5 by using a security device that does not support encapsulation. Egress traffic and ingress traffic are untagged.

```
Controller(config)# monitor session 2 destination interface gigabitethernet1/0/2 ingress
untagged vlan 5
```

Related Commands

Command	Description
monitor session	Configures a new SPAN or RSPAN session.
monitor session filter	Configures a FSPAN or FRSPAN session filter.
monitor session source	Configures a FSPAN or FRSPAN source session.
show monitor	Displays information about all SPAN and RSPAN sessions.

monitor session filter

To start a new flow-based SPAN (FSPAN) session or flow-based RSPAN (FRSPAN) source or destination session, or to limit (filter) SPAN source traffic to specific VLANs, use the **monitor session filter** global configuration command. To remove filters from the SPAN or RSPAN session, use the **no** form of this command.

```
monitor session session-number filter {vlan vlan-id [, | -] }
no monitor session session-number filter {vlan vlan-id [, | -] }
```

Syntax Description	session-number	
	vlan vlan-id	Specifies a list of VLANs as filters on trunk source ports to limit SPAN source traffic to specific VLANs. The <i>vlan-id</i> range is 1 to 4094.
	,	(Optional) Specifies a series of VLANs, or separates a range of VLANs from a previous range. Enter a space before and after the comma.
	-	(Optional) Specifies a range of VLANs. Enter a space before and after the hyphen.

Command Default No monitor sessions are configured.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

You can monitor traffic on a single VLAN or on a series or range of ports or VLANs. You select a series or range of VLANs by using the [, | -] options.

If you specify a series of VLANs, you must enter a space before and after the comma. If you specify a range of VLANs, you must enter a space before and after the hyphen (-).

VLAN filtering refers to analyzing network traffic on a selected set of VLANs on trunk source ports. By default, all VLANs are monitored on trunk source ports. You can use the **monitor session session_number filter vlan vlan-id** command to limit SPAN traffic on trunk source ports to only the specified VLANs.

VLAN monitoring and VLAN filtering are mutually exclusive. If a VLAN is a source, VLAN filtering cannot be enabled. If VLAN filtering is configured, a VLAN cannot become a source.

You can verify your settings by entering the **show monitor** privileged EXEC command. You can display SPAN, RSPAN, FSPAN, and FRSPAN configuration on the switch by entering the **show running-config** privileged EXEC command. SPAN information appears near the end of the output.

Examples

This example shows how to limit SPAN traffic in an existing session only to specific VLANs:

```
Switch(config)# monitor session 1 filter vlan 100 - 110
```

This example shows how to create a local SPAN session 1 to monitor both sent and received traffic on source port 1 on stack member 1 to destination port 2 on stack member 2 and to filter IPv4 traffic using access list number 122 in an FSPAN session:

```
Switch(config)# monitor session 1 source interface gigabitethernet1/0/1 both
Switch(config)# monitor session 1 destination interface gigabitethernet1/0/2
Switch(config)# monitor session 1 filter ip access-group 122
```

Related Commands

Command	Description
monitor session	Configures a new SPAN or RSPAN session.
monitor session destination	Configures a FSPAN or FRSPAN destination session.
monitor session source	Configures a FSPAN or FRSPAN source session.
show monitor	Displays information about all SPAN and RSPAN sessions.

monitor session source

To start a new Switched Port Analyzer (SPAN) session or Remote SPAN (RSPAN) source session, or to add or delete interfaces or VLANs to or from an existing SPAN or RSPAN session, use the **monitor session source** global configuration command. To remove the SPAN or RSPAN session or to remove source interfaces from the SPAN or RSPAN session, use the **no** form of this command.

```
monitor session session_number source {interface interface-id [, | -] [both | rx | tx] | [remote] vlan vlan-id [, | -] [both | rx | tx]}
no monitor session session_number source {interface interface-id [, | -] [both | rx | tx] | [remote] vlan vlan-id [, | -] [both | rx | tx]}
```

Syntax Description

<i>session_number</i>	
interface <i>interface-id</i>	Specifies the source interface for a SPAN or RSPAN session. Valid interfaces are physical ports (including type, stack member, module, and port number). For source interface, port channel is also a valid interface type, and the valid range is 1 to 48.
,	(Optional) Specifies a series of interfaces or VLANs, or separates a range of interfaces or VLANs from a previous range. Enter a space before and after the comma.
-	(Optional) Specifies a range of interfaces or VLANs. Enter a space before and after the hyphen.
both rx tx	(Optional) Specifies the traffic direction to monitor. If you do not specify a traffic direction, the source interface sends both transmitted and received traffic.
remote	(Optional) Specifies the remote VLAN for an RSPAN source or destination session. The range is 2 to 1001 and 1006 to 4094. The RSPAN VLAN cannot be VLAN 1 (the default VLAN) or VLAN IDs 1002 to 1005 (reserved for Token Ring and FDDI VLANs).
vlan <i>vlan-id</i>	When used with only the ingress keyword, sets default VLAN for ingress traffic.

Command Default

No monitor sessions are configured.

On a source interface, the default is to monitor both received and transmitted traffic.

On a trunk interface used as a source port, all VLANs are monitored.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Traffic that enters or leaves source ports or source VLANs can be monitored by using SPAN or RSPAN. Traffic routed to source ports or source VLANs cannot be monitored.

A source can be a physical port, a port channel, or a VLAN.

Each session can include multiple ingress or egress source ports or VLANs, but you cannot combine source ports and source VLANs in a single session. Each session can include multiple destination ports.

When you use VLAN-based SPAN (VSPAN) to analyze network traffic in a VLAN or set of VLANs, all active ports in the source VLANs become source ports for the SPAN or RSPAN session. Trunk ports are included as source ports for VSPAN, and only packets with the monitored VLAN ID are sent to the destination port.

You can monitor traffic on a single port or VLAN or on a series or range of ports or VLANs. You select a series or range of interfaces or VLANs by using the [, | -] options.

If you specify a series of VLANs or interfaces, you must enter a space before and after the comma. If you specify a range of VLANs or interfaces, you must enter a space before and after the hyphen (-).

You can monitor individual ports while they participate in an EtherChannel, or you can monitor the entire EtherChannel bundle by specifying the **port-channel** number as the RSPAN source interface.

A port used as a destination port cannot be a SPAN or RSPAN source, nor can a port be a destination port for more than one session at a time.

You can enable IEEE 802.1x authentication on a SPAN or RSPAN source port.

You can verify your settings by entering the **show monitor** privileged EXEC command. You can display SPAN, RSPAN, FSPAN, and FRSPAN configuration on the switch by entering the **show running-config** privileged EXEC command. SPAN information appears near the end of the output.

Examples

This example shows how to create a local SPAN session 1 to monitor both sent and received traffic on source port 1 on stack member 1 to destination port 2 on stack member 2:

```
Switch(config)# monitor session 1 source interface gigabitethernet1/0/1 both
Switch(config)# monitor session 1 destination interface gigabitethernet1/0/2
```

This example shows how to configure RSPAN source session 1 to monitor multiple source interfaces and to configure the destination RSPAN VLAN 900.

```
Switch(config)# monitor session 1 source interface gigabitethernet1/0/1
Switch(config)# monitor session 1 source interface port-channel 2 tx
Switch(config)# monitor session 1 destination remote vlan 900
Switch(config)# end
```

Related Commands

Command	Description
monitor session	Configures a new SPAN or RSPAN session.
monitor session destination	Configures a FSPAN or FRSPAN destination session.
monitor session filter	Configures a FSPAN or FRSPAN session filter.
show monitor	Displays information about all SPAN and RSPAN sessions.

show monitor

To display information about all Switched Port Analyzer (SPAN) and Remote SPAN (RSPAN) sessions, use the **show monitor** command in EXEC mode.

show monitor [**session** {*session_number* | **all** | **local** | **range list** | **remote**} [**detail**]]

Syntax Description

session	(Optional) Displays information about specified SPAN sessions.
<i>session_number</i>	
all	(Optional) Displays all SPAN sessions.
local	(Optional) Displays only local SPAN sessions.
range list	(Optional) Displays a range of SPAN sessions, where <i>list</i> is the range of valid sessions. The range is either a single session or a range of sessions described by two numbers, the lower one first, separated by a hyphen. Do not enter any spaces between comma-separated parameters or in hyphen-specified ranges. Note This keyword is available only in privileged EXEC mode.
remote	(Optional) Displays only remote SPAN sessions.
detail	(Optional) Displays detailed information about the specified sessions.

Command Modes

User EXEC
Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The output is the same for the **show monitor** command and the **show monitor session all** command.

Examples

This is an example of output for the **show monitor** user EXEC command:

```
Controller# show monitor
Session 1
-----
Type : Local Session
Source Ports :
RX Only : Gi4/0/1
Both : Gi4/0/2-3,Gi4/0/5-6
Destination Ports : Gi4/0/20
Encapsulation : Replicate
Ingress : Disabled
Session 2
-----
Type : Remote Source Session
Source VLANs :
TX Only : 10
Both : 1-9
Dest RSPAN VLAN : 105
```

This is an example of output for the **show monitor** user EXEC command for local SPAN source session 1:

```
Controller# show monitor session 1
Session 1
-----
Type : Local Session
Source Ports :
RX Only : Gi4/0/1
Both : Gi4/0/2-3,Gi4/0/5-6
Destination Ports : Gi4/0/20
Encapsulation : Replicate
Ingress : Disabled
```

This is an example of output for the **show monitor session all** user EXEC command when ingress traffic forwarding is enabled:

```
Controller# show monitor session all
Session 1
-----
Type : Local Session
Source Ports :
Both : Gi4/0/2
Destination Ports : Gi4/0/3
Encapsulation : Native
Ingress : Enabled, default VLAN = 5
Ingress encap : DOT1Q
Session 2
-----
Type : Local Session
Source Ports :
Both : Gi4/0/8
Destination Ports : Gi4/0/12
Encapsulation : Replicate
Ingress : Enabled, default VLAN = 4
Ingress encap : Untagged
```

Related Commands

Command	Description
monitor session	Configures a new SPAN or RSPAN session.
monitor session destination	Configures a FSPAN or FRSPAN destination session.

Command	Description
monitor session filter	Configures a FSPAN or FRSPAN session filter.
monitor session source	Configures a FSPAN or FRSPAN source session.

show monitor capture

To display monitor capture (WireShark) content, use the **show monitor capture file** command in privileged EXEC mode.

show monitor capture [*capture-name* [**buffer**] | **file** *file-location* : *file-name*] [**brief** | **detailed** | **display-filter** *display-filter-string*]

Syntax Description

<i>capture-name</i>	(Optional) Specifies the name of the capture to be displayed.
buffer	(Optional) Specifies that a buffer associated with the named capture is to be displayed.
file <i>file-location</i> : <i>file-name</i>	(Optional) Specifies the file location and name of the capture storage file to be displayed.
brief	(Optional) Specifies the display content in brief.
detailed	(Optional) Specifies detailed display content.
display-filter <i>display-filter-string</i>	Filters the display content according to the <i>display-filter-string</i> .

Command Default

Displays all capture content.

Command Modes

Privileged EXEC

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

none

Examples

To display the capture for a capture called mycap:

```

Controller# show monitor capture mycap

Status Information for Capture mycap
  Target Type:
  Interface: CAPWAP,
  Ingress:
0
  Egress:
0
  Status : Active

```

```
Filter Details:
  Capture all packets
Buffer Details:
  Buffer Type: LINEAR (default)
File Details:
  Associated file name: flash:mycap.pcap
  Size of buffer(in MB): 1
Limit Details:
  Number of Packets to capture: 0 (no limit)
  Packet Capture duration: 0 (no limit)
  Packet Size to capture: 0 (no limit)
  Packets per second: 0 (no limit)
  Packet sampling rate: 0 (no sampling)
```

Related Commands

Command	Description
monitor capture (interface/control plane)	Configures monitor capture (WireShark) specifying an attachment point and the packet flow direction.
monitor capture buffer	Configures the buffer for monitor capture (WireShark).
monitor capture file	Configures monitor capture (WireShark) storage file attributes.

snmp-server enable traps

To enable the controller to send Simple Network Management Protocol (SNMP) notifications for various traps or inform requests to the network management system (NMS), use the **snmp-server enable traps** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps [auth-framework [sec-violation] | bridge | call-home | cluster | config | config-copy | config-ctid | copy-config | cpu | dot1x | energywise | entity | envmon | errdisable | event-manager | flash | fru-ctrl | license | mac-notification | port-security | power-ethernet | rep | snmp | stackwise | storm-control | stpx | syslog | transceiver | tty | vlan-membership | vlancreate | vlandelete | vstack | vtp]

no snmp-server enable traps [auth-framework [sec-violation] | bridge | call-home | cluster | config | config-copy | config-ctid | copy-config | cpu | dot1x | energywise | entity | envmon | errdisable | event-manager | flash | fru-ctrl | license | mac-notification | port-security | power-ethernet | rep | snmp | stackwise | storm-control | stpx | syslog | transceiver | tty | vlan-membership | vlancreate | vlandelete | vstack | vtp]

Syntax Description

auth-framework	(Optional) Enables SNMP CISCO-AUTH-FRAMEWORK-MIB traps.
sec-violation	(Optional) Enables SNMP camSecurityViolationNotif notifications.
bridge	(Optional) Enables SNMP STP Bridge MIB traps.*
call-home	(Optional) Enables SNMP CISCO-CALLHOME-MIB traps.*
cluster	(Optional) Enables SNMP cluster traps.
config	(Optional) Enables SNMP configuration traps.
config-copy	(Optional) Enables SNMP configuration copy traps.
config-ctid	(Optional) Enables SNMP configuration CTID traps.
copy-config	(Optional) Enables SNMP copy-configuration traps.
cpu	(Optional) Enables CPU notification traps.*
dot1x	(Optional) Enables SNMP dot1x traps.*
energywise	(Optional) Enables SNMP energywise traps.*
entity	(Optional) Enables SNMP entity traps.
envmon	(Optional) Enables SNMP environmental monitor traps.*
errdisable	(Optional) Enables SNMP errdisable notification traps.*

event-manager	(Optional) Enables SNMP Embedded Event Manager traps.
flash	(Optional) Enables SNMP FLASH notification traps.*
fru-ctrl	(Optional) Generates entity field-replaceable unit (FRU) control traps. In a controller stack, this trap refers to the insertion or removal of a controller in the stack.
license	(Optional) Enables license traps.*
mac-notification	(Optional) Enables SNMP MAC Notification traps.*
port-security	(Optional) Enables SNMP port security traps.*
power-ethernet	(Optional) Enables SNMP power Ethernet traps.*
rep	(Optional) Enables SNMP Resilient Ethernet Protocol traps.
snmp	(Optional) Enables SNMP traps.*
stackwise	(Optional) Enables SNMP stackwise traps.*
storm-control	(Optional) Enables SNMP storm-control trap parameters.*
stpx	(Optional) Enables SNMP STPX MIB traps.*
syslog	(Optional) Enables SNMP syslog traps.
transceiver	(Optional) Enables SNMP transceiver traps.*
tty	(Optional) Sends TCP connection traps. This is enabled by default.
vlan-membership	(Optional) Enables SNMP VLAN membership traps.
vlancreate	(Optional) Enables SNMP VLAN-created traps.
vlandelete	(Optional) Enables SNMP VLAN-deleted traps.
vstack	(Optional) Enables SNMP Smart Install traps.*
vtp	(Optional) Enables VLAN Trunking Protocol (VTP) traps.

Command Default The sending of SNMP traps is disabled.

Command Modes Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

The command options marked with an asterisk in the table above have subcommands. For more information on these subcommands, see the Related Commands section below.

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.

When supported, use the **snmp-server enable traps** command to enable sending of traps or informs.

**Note**

Though visible in the command-line help strings, the **fru-ctrl**, **insertion**, and **removal** keywords are not supported on the controller. The **snmp-server enable informs** global configuration command is not supported. To enable the sending of SNMP inform notifications, use the **snmp-server enable traps** global configuration command combined with the **snmp-server host *host-addr* informs** global configuration command.

**Note**

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to enable more than one type of SNMP trap:

```
Controller(config) # snmp-server enable traps cluster
Controller(config) # snmp-server enable traps config
Controller(config) # snmp-server enable traps vtp
```

Related Commands

Command	Description
snmp-server enable traps bridge	Generates STP bridge MIB traps.
snmp-server enable traps call-home	Enables SNMP CISCO-CALLHOME-MIB traps.
snmp-server enable traps cpu	Enables CPU notifications.
snmp-server enable traps envmon	Enables SNMP environmental traps.
snmp-server enable traps errdisable	Enables SNMP errdisable notifications.
snmp-server enable traps flash	Enables SNMP flash notifications.

Command	Description
snmp-server enable traps license	Enables license traps.
snmp-server enable traps mac-notification	Enables SNMP MAC notification traps.
snmp-server enable traps port-security	Enables SNMP port security traps.
snmp-server enable traps power-ethernet	Enables SNMP PoE traps.
snmp-server enable traps snmp	Enables SNMP traps.
snmp-server enable traps stackwise	Enables SNMP StackWise traps.
snmp-server enable traps storm-control	Enables SNMP storm-control trap parameters.
snmp-server enable traps stpx	Enables SNMP STPX MIB traps.
snmp-server enable traps transceiver	Enable SNMP transceiver traps.
snmp-server enable traps vstack	Enables SNMP smart install traps.
snmp-server host	Specifies the recipient (host) of a SNMP notification operation.

snmp-server enable traps bridge

To generate STP bridge MIB traps, use the **snmp-server enable traps bridge** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps bridge [newroot] [topologychange]
no snmp-server enable traps bridge [newroot] [topologychange]
```

Syntax Description	newroot	(Optional) Enables SNMP STP bridge MIB new root traps.
	topologychange	(Optional) Enables SNMP STP bridge MIB topology change traps.

Command Default The sending of bridge SNMP traps is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples This example shows how to send bridge new root traps to the NMS:

```
Controller(config) # snmp-server enable traps bridge newroot
```


snmp-server enable traps call-home

To enable SNMP CISCO-CALLHOME-MIB traps, use the **snmp-server enable traps call-home** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps call-home [**message-send-fail** | **server-fail**]

no snmp-server enable traps call-home [**message-send-fail** | **server-fail**]

Syntax Description

message-send-fail	(Optional) Enables SNMP message-send-fail traps.
server-fail	(Optional) Enables SNMP server-fail traps.

Command Default

The sending of SNMP CISCO-CALLHOME-MIB traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP message-send-fail traps:

```
Controller(config)# snmp-server enable traps call-home message-send-fail
```

snmp-server enable traps cpu

To enable CPU notifications, use the **snmp-server enable traps cpu** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps cpu [threshold]
no snmp-server enable traps cpu [threshold]
```


Syntax Description	threshold (Optional) Enables CPU threshold notification.
--------------------	--

Command Default	The sending of CPU notifications is disabled.
-----------------	---

Command Modes	Global configuration
---------------	----------------------

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples This example shows how to generate CPU threshold notifications:

```
Controller(config) # snmp-server enable traps cpu threshold
```

snmp-server enable traps envmon

To enable SNMP environmental traps, use the **snmp-server enable traps envmon** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps envmon [**fan**][**shutdown**][**status**] [**supply**][**temperature**]

no snmp-server enable traps envmon [**fan**][**shutdown**][**status**] [**supply**][**temperature**]

Syntax Description

fan	(Optional) Enables fan traps.
shutdown	(Optional) Enables environmental monitor shutdown traps.
status	(Optional) Enables SNMP environmental status-change traps.
supply	(Optional) Enables environmental monitor power-supply traps.
temperature	(Optional) Enables environmental monitor temperature traps.

Command Default

The sending of environmental SNMP traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate fan traps:

```
Controller(config)# snmp-server enable traps envmon fan
```

snmp-server enable traps errdisable

To enable SNMP notifications of error-disabling, use the **snmp-server enable traps errdisable** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps errdisable [notification-rate number-of-notifications]
no snmp-server enable traps errdisable [notification-rate number-of-notifications]
```


Syntax Description	<div> notification-rate <i>number-of-notifications</i> </div> <div> (Optional) Specifies number of notifications per minute as the notification rate. Accepted values are from 0 to 10000. </div>
--------------------	---

Command Default	The sending of SNMP notifications of error-disabling is disabled.
-----------------	---

Command Modes	Global configuration
---------------	----------------------

Command History	<table> <tr> <th>Release</th><th>Modification</th></tr> <tr> <td>Cisco IOS XE 3.2SE</td><td>This command was introduced.</td></tr> </table>	Release	Modification	Cisco IOS XE 3.2SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.2SE	This command was introduced.				

Usage Guidelines Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples This example shows how to set the number SNMP notifications of error-disabling to 2:

```
Controller(config)# snmp-server enable traps errdisable notification-rate 2
```

snmp-server enable traps flash

To enable SNMP flash notifications, use the **snmp-server enable traps flash** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps flash [insertion][removal]

no snmp-server enable traps flash [insertion][removal]

Syntax Description

insertion	(Optional) Enables SNMP flash insertion notifications.
removal	(Optional) Enables SNMP flash removal notifications.

Command Default

The sending of SNMP flash notifications is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP flash insertion notifications:

```
Controller(config)# snmp-server enable traps flash insertion
```

snmp-server enable traps license

To enable license traps, use the **snmp-server enable traps license** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps license [deploy][error][usage]
no snmp-server enable traps license [deploy][error][usage]
```

Syntax Description

deploy	(Optional) Enables license deployment traps.
error	(Optional) Enables license error traps.
usage	(Optional) Enables license usage traps.

Command Default

The sending of license traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

 To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate license deployment traps:

```
Controller(config)# snmp-server enable traps license deploy
```

snmp-server enable traps mac-notification

To enable SNMP MAC notification traps, use the **snmp-server enable traps mac-notification** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps mac-notification [**change**][**move**][**threshold**]

no snmp-server enable traps mac-notification [**change**][**move**][**threshold**]

Syntax Description

change	(Optional) Enables SNMP MAC change traps.
move	(Optional) Enables SNMP MAC move traps.
threshold	(Optional) Enables SNMP MAC threshold traps.

Command Default

The sending of SNMP MAC notification traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP MAC notification change traps:

```
Controller(config)# snmp-server enable traps mac-notification change
```

snmp-server enable traps port-security

To enable SNMP port security traps, use the **snmp-server enable traps port-security** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps port-security [trap-rate value]
no snmp-server enable traps port-security [trap-rate value]
```


Syntax Description	<div> <div>trap-rate value</div> <div>(Optional) Sets the maximum number of port-security traps sent per second. The range is from 0 to 1000; the default is 0 (no limit imposed; a trap is sent at every occurrence).</div> </div>
--------------------	---

Command Default	The sending of port security SNMP traps is disabled.
-----------------	--

Command Modes	Global configuration
---------------	----------------------

Command History	<div> <div>Release</div> <div>Modification</div> </div>
	<div> <div>Cisco IOS XE 3.2SE</div> <div>This command was introduced.</div> </div>

Usage Guidelines Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples This example shows how to enable port-security traps at a rate of 200 per second:

```
Controller(config) # snmp-server enable traps port-security trap-rate 200
```


snmp-server enable traps power-ethernet

To enable SNMP power-over-Ethernet (PoE) traps, use the **snmp-server enable traps power-ethernet** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps power-ethernet {group *number* | police}

no snmp-server enable traps power-ethernet {group *number* | police}

Syntax Description

group <i>number</i>	Enables inline power group-based traps for the specified group number. Accepted values are from 1 to 9.
police	Enables inline power policing traps.

Command Default

The sending of power-over-Ethernet SNMP traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to enable power-over-Ethernet traps for group 1:

```
Controller(config)# snmp-server enable traps power-over-ethernet group 1
```

snmp-server enable traps snmp

To enable SNMP traps, use the **snmp-server enable traps snmp** command in global configuration mode. Use the **no** form of this command to return to the default setting.

```
snmp-server enable traps snmp [authentication ][coldstart ][linkdown ] [linkup ][warmstart]
no snmp-server enable traps snmp [authentication ][coldstart ][linkdown ] [linkup ][warmstart]
```

Syntax Description

authentication	(Optional) Enables authentication traps.
coldstart	(Optional) Enables cold start traps.
linkdown	(Optional) Enables linkdown traps.
linkup	(Optional) Enables linkup traps.
warmstart	(Optional) Enables warmstart traps.

Command Default

The sending of SNMP traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to enable a warmstart SNMP trap:

```
Controller(config)# snmp-server enable traps snmp warmstart
```

snmp-server enable traps stackwise

To enable SNMP StackWise traps, use the **snmp-server enable traps stackwise** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps stackwise [GLS][ILS][SRLS] [insufficient-power][invalid-input-current][invalid-output-current][member-removed][member-upgrade-notification] [new-master][new-member][port-change][power-budget-warning][power-invalid-topology][power-link-status-changed][power-oper-status-changed][power-priority-conflict][power-version-mismatch][ring-redundant][stack-mismatch][unbalanced-power-supplies][under-budget][under-voltage]

no snmp-server enable traps stackwise [GLS][ILS][SRLS] [insufficient-power][invalid-input-current][invalid-output-current][member-removed][member-upgrade-notification] [new-master][new-member][port-change][power-budget-warning][power-invalid-topology][power-link-status-changed][power-oper-status-changed][power-priority-conflict][power-version-mismatch][ring-redundant][stack-mismatch][unbalanced-power-supplies][under-budget][under-voltage]

Syntax Description

GLS	(Optional) Enables StackWise stack power GLS trap.
ILS	(Optional) Enables StackWise stack power ILS trap.
SRLS	(Optional) Enables StackWise stack power SRLS trap.
insufficient-power	(Optional) Enables StackWise stack power unbalanced power supplies trap.
invalid-input-current	(Optional) Enables StackWise stack power invalid input current trap.
invalid-output-current	(Optional) Enables StackWise stack power invalid output current trap.
member-removed	(Optional) Enables StackWise stack member removed trap.
member-upgrade-notification	(Optional) Enables StackWise member to be reloaded for upgrade trap.
new-master	(Optional) Enables StackWise new master trap.
new-member	(Optional) Enables StackWise stack new member trap.
port-change	(Optional) Enables StackWise stack port change trap.
power-budget-warning	(Optional) Enables StackWise stack power budget warning trap.
power-invalid-topology	(Optional) Enables StackWise stack power invalid topology trap.
power-link-status-changed	(Optional) Enables StackWise stack power link status changed trap.

power-oper-status-changed	(Optional) Enables StackWise stack power port oper status changed trap.
power-priority-conflict	(Optional) Enables StackWise stack power priority conflict trap.
power-version-mismatch	(Optional) Enables StackWise stack power version mismatch discovered trap.
ring-redundant	(Optional) Enables StackWise stack ring redundant trap.
stack-mismatch	(Optional) Enables StackWise stack mismatch trap.
unbalanced-power-supplies	(Optional) Enables StackWise stack power unbalanced power supplies trap.
under-budget	(Optional) Enables StackWise stack power under budget trap.
under-voltage	(Optional) Enables StackWise stack power under voltage trap.

Command Default The sending of SNMP StackWise traps is disabled.

Command Modes Global configuration

Command History	Release	Modification
	Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples This example shows how to generate StackWise stack power GLS traps:

```
Controller(config)# snmp-server enable traps stackwise GLS
```

snmp-server enable traps storm-control

To enable SNMP storm-control trap parameters, use the **snmp-server enable traps storm-control** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps storm-control {*trap-rate number-of-minutes*}

no snmp-server enable traps storm-control {*trap-rate*}

Syntax Description

trap-rate <i>number-of-minutes</i>	(Optional) Specifies the SNMP storm-control trap rate in minutes. Accepted values are from 0 to 1000.
---	---

Command Default

The sending of SNMP storm-control trap parameters is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to set the SNMP storm-control trap rate to 10 traps per minute:

```
Controller(config)# snmp-server enable traps storm-control trap-rate 10
```

snmp-server enable traps stpx

To enable SNMP STPX MIB traps, use the **snmp-server enable traps stpx** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps stpx [**inconsistency**][**loop-inconsistency**][**root-inconsistency**]

no snmp-server enable traps stpx [**inconsistency**][**loop-inconsistency**][**root-inconsistency**]

Syntax Description

inconsistency	(Optional) Enables SNMP STPX MIB inconsistency update traps.
loop-inconsistency	(Optional) Enables SNMP STPX MIB loop inconsistency update traps.
root-inconsistency	(Optional) Enables SNMP STPX MIB root inconsistency update traps.

Command Default

The sending of SNMP STPX MIB traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP STPX MIB inconsistency update traps:

```
Controller(config)# snmp-server enable traps stpx inconsistency
```

snmp-server enable traps transceiver

To enable SNMP transceiver traps, use the **snmp-server enable traps transceiver** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps transceiver {all}

no snmp-server enable traps transceiver {all}

Syntax Description

all	(Optional) Enables all SNMP transceiver traps.
------------	--

Command Default

The sending of SNMP transceiver traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to set all SNMP transceiver traps:

```
Controller(config)# snmp-server enable traps transceiver all
```

snmp-server enable traps vstack

To enable SNMP smart install traps, use the **snmp-server enable traps vstack** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps vstack [**addition**][**failure**][**lost**][**operation**]
no snmp-server enable traps vstack [**addition**][**failure**][**lost**][**operation**]

Syntax Description

addition	(Optional) Enables client added traps.
failure	(Optional) Enables file upload and download failure traps.
lost	(Optional) Enables client lost trap.
operation	(Optional) Enables operation mode change traps.

Command Default

The sending of SNMP smart install traps is disabled.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.



Note

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate SNMP Smart Install client-added traps:

```
Controller(config)# snmp-server enable traps vstack addition
```


snmp-server enable traps wireless

To enable sending Simple Network Management Protocol (SNMP) notifications for various wireless traps or inform requests to the network management system (NMS), use the **snmp-server enable traps wireless** command in global configuration mode. Use the **no** form of this command to return to the default setting.

snmp-server enable traps wireless [AP | RRM | bsn80211SecurityTrap | bsnAPPParamUpdate | bsnAPPProfile | bsnAccessPoint | bsnMobileStation | bsnRogue | client | mfp | rogue]

no snmp-server enable traps wireless [AP | RRM | bsn80211SecurityTrap | bsnAPPParamUpdate | bsnAPPProfile | bsnAccessPoint | bsnMobileStation | bsnRogue | client | mfp | rogue]

Syntax Description

AP	(Optional) Enables sending of AP related traps.
RRM	(Optional) Enables sending of RRM traps.
bsn80211SecurityTrap	(Optional) Enables security-related traps.
bsnAPPParamUpdate	(Optional) Enables sending of traps for AP parameters that get updated.
bsnAPPProfile	(Optional) Enables BSN AP profile traps.
bsnAccessPoint	(Optional) Enables access point traps.
bsnMobileStation	(Optional) Controls wireless client traps.
bsnRogue	(Optional) Enables rogue-related traps.
client	(Optional) Enables client traps.
mfp	(Optional) Enables MFP traps.
rogue	(Optional) Enables rogue traps.

Command Default

Disabled

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

Specify the host (NMS) that receives the traps by using the **snmp-server host** global configuration command. If no trap types are specified, all trap types are sent.

**Note**

Informs are not supported in SNMPv1.

To enable more than one type of trap, you must enter a separate **snmp-server enable traps** command for each trap type.

Examples

This example shows how to generate sending AP related wireless traps:

```
Controller(config)# snmp-server enable traps wireless ap
```

snmp-server engineID

To configure a name for either the local or remote copy of SNMP, use the **snmp-server engineID** command in global configuration mode.

snmp-server engineID {**local** *engineid-string* | **remote** *ip-address* [**udp-port** *port-number*] *engineid-string*}

Syntax Description

local <i>engineid-string</i>	Specifies a 24-character ID string with the name of the copy of SNMP. You need not specify the entire 24-character engine ID if it has trailing zeros. Specify only the portion of the engine ID up to the point where only zeros remain in the value.
remote <i>ip-address</i>	Specifies the remote SNMP copy. Specify the <i>ip-address</i> of the device that contains the remote copy of SNMP.
udp-port <i>port-number</i>	(Optional) Specifies the User Datagram Protocol (UDP) port on the remote device. The default is 162.

Command Default

None

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

None

Examples

The following example configures a local engine ID of 123400000000000000000000:

```
Controller(config)# snmp-server engineID local 1234
```

snmp-server host

To specify the recipient (host) of a Simple Network Management Protocol (SNMP) notification operation, use the **snmp-server host** global configuration command on the controller. Use the **no** form of this command to remove the specified host.

snmp-server host {*host-addr*} [**vrf** *vrf-instance*] [**informs** | **traps**] [**version** {**1** | **2c** | **3** {**auth** | **noauth** | **priv**} }] {*community-string* [*notification-type*] }

no snmp-server host {*host-addr*} [**vrf** *vrf-instance*] [**informs** | **traps**] [**version** {**1** | **2c** | **3** {**auth** | **noauth** | **priv**} }] {*community-string* [*notification-type*] }

Syntax Description

<i>host-addr</i>	Name or Internet address of the host (the targeted recipient).
vrf <i>vrf-instance</i>	(Optional) Specifies the virtual private network (VPN) routing instance and name for this host.
informs traps	(Optional) Sends SNMP traps or informs to this host.
version 1 2c 3	(Optional) Specifies the version of the SNMP used to send the traps. 1 —SNMPv1. This option is not available with informs. 2c —SNMPv2C. 3 —SNMPv3. One of the authorization keywords (see next table row) must follow the Version 3 keyword.
auth noauth priv	auth (Optional)—Enables Message Digest 5 (MD5) and Secure Hash Algorithm (SHA) packet authentication. noauth (Default)—The noAuthNoPriv security level. This is the default if the auth noauth priv keyword choice is not specified. priv (Optional)—Enables Data Encryption Standard (DES) packet encryption (also called privacy).
<i>community-string</i>	Password-like community string sent with the notification operation. Though you can set this string by using the snmp-server host command, we recommend that you define this string by using the snmp-server community global configuration command before using the snmp-server host command. Note The @ symbol is used for delimiting the context information. Avoid using the @ symbol as part of the SNMP community string when configuring this command.

notification-type (Optional) Type of notification to be sent to the host. If no type is specified, all notifications are sent. The notification type can be one or more of the these keywords:

- **auth-framework**—Sends SNMP CISCO-AUTH-FRAMEWORK-MIB traps.
 - **bridge**—Sends SNMP Spanning Tree Protocol (STP) bridge MIB traps.
 - **bulkstat**—Sends Data-Collection-MIB Collection notification traps.
 - **call-home**—Sends SNMP CISCO-CALLHOME-MIB traps.
 - **cef**—Sends SNMP CEF traps.
 - **config**—Sends SNMP configuration traps.
 - **config-copy**—Sends SNMP config-copy traps.
 - **config-ctid**—Sends SNMP config-ctid traps.
 - **copy-config**—Sends SNMP copy configuration traps.
 - **cpu**—Sends CPU notification traps.
 - **cpu threshold**—Sends CPU threshold notification traps.
 - **entity**—Sends SNMP entity traps.
-

-
- **envmon**—Sends environmental monitor traps.
 - **errdisable**—Sends SNMP errdisable notification traps.
 - **event-manager**—Sends SNMP Embedded Event Manager traps.
 - **flash**—Sends SNMP FLASH notifications.
 - **flowmon**—Sends SNMP flowmon notification traps.
 - **ipmulticast**—Sends SNMP IP multicast routing traps.
 - **ipsla**—Sends SNMP IP SLA traps.
 - **license**—Sends license traps.
 - **local-auth**—Sends SNMP local auth traps.
 - **mac-notification**—Sends SNMP MAC notification traps.
 - **pim**—Sends SNMP Protocol-Independent Multicast (PIM) traps.
 - **power-ethernet**—Sends SNMP power Ethernet traps.
 - **snmp**—Sends SNMP-type traps.
 - **storm-control**—Sends SNMP storm-control traps.
 - **stpx**—Sends SNMP STP extended MIB traps.
 - **syslog**—Sends SNMP syslog traps.
 - **transceiver**—Sends SNMP transceiver traps.
 - **tty**—Sends TCP connection traps.
 - **vlan-membership**—Sends SNMP VLAN membership traps.
 - **vlancreate**—Sends SNMP VLAN-created traps.
 - **vlandelete**—Sends SNMP VLAN-deleted traps.
 - **vrfmib**—Sends SNMP vrfmib traps.
 - **vtp**—Sends SNMP VLAN Trunking Protocol (VTP) traps.
 - **wireless**—Sends wireless traps.
-

Command Default

This command is disabled by default. No notifications are sent.

If you enter this command with no keywords, the default is to send all trap types to the host. No informs are sent to this host.

If no **version** keyword is present, the default is Version 1.

If Version 3 is selected and no authentication keyword is entered, the default is the **noauth** (noAuthNoPriv) security level.

**Note**

Though visible in the command-line help strings, the **fru-ctrl** keyword is not supported.

Command Modes

Global configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Usage Guidelines

SNMP notifications can be sent as traps or inform requests. Traps are unreliable because the receiver does not send acknowledgments when it receives traps. The sender cannot determine if the traps were received. However, an SNMP entity that receives an inform request acknowledges the message with an SNMP response PDU. If the sender never receives the response, the inform request can be sent again, so that informs are more likely to reach their intended destinations.

However, informs consume more resources in the agent and in the network. Unlike a trap, which is discarded as soon as it is sent, an inform request must be held in memory until a response is received or the request times out. Traps are also sent only once, but an inform might be retried several times. The retries increase traffic and contribute to a higher overhead on the network.

If you do not enter an **snmp-server host** command, no notifications are sent. To configure the controller to send SNMP notifications, you must enter at least one **snmp-server host** command. If you enter the command with no keywords, all trap types are enabled for the host. To enable multiple hosts, you must enter a separate **snmp-server host** command for each host. You can specify multiple notification types in the command for each host.

If a local user is not associated with a remote host, the controller does not send informs for the **auth** (authNoPriv) and the **priv** (authPriv) authentication levels.

When multiple **snmp-server host** commands are given for the same host and kind of notification (trap or inform), each succeeding command overwrites the previous command. Only the last **snmp-server host** command is in effect. For example, if you enter an **snmp-server host inform** command for a host and then enter another **snmp-server host inform** command for the same host, the second command replaces the first.

The **snmp-server host** command is used with the **snmp-server enable traps** global configuration command. Use the **snmp-server enable traps** command to specify which SNMP notifications are sent globally. For a host to receive most notifications, at least one **snmp-server enable traps** command and the **snmp-server host** command for that host must be enabled. Some notification types cannot be controlled with the **snmp-server enable traps** command. For example, some notification types are always enabled. Other notification types are enabled by a different command.

The **no snmp-server host** command with no keywords disables traps, but not informs, to the host. To disable informs, use the **no snmp-server host informs** command.

Examples

This example shows how to configure a unique SNMP community string named comaccess for traps and prevent SNMP polling access with this string through access-list 10:

```
Controller(config)# snmp-server community comaccess ro 10
```

```
Controller(config)# snmp-server host 172.20.2.160 comaccess
Controller(config)# access-list 10 deny any
```

This example shows how to send the SNMP traps to the host specified by the name myhost.cisco.com. The community string is defined as comaccess:

```
Controller(config)# snmp-server enable traps
Controller(config)# snmp-server host myhost.cisco.com comaccess snmp
```

This example shows how to enable the controller to send all traps to the host myhost.cisco.com by using the community string public:

```
Controller(config)# snmp-server enable traps
Controller(config)# snmp-server host myhost.cisco.com public
```

You can verify your settings by entering the **show running-config** privileged EXEC command.

Related Commands

Command	Description
snmp-server enable traps	Enables the controller to send SNMP notifications for various traps or inform requests to the NMS.

trapflags

To enable trapflags for various parameters, use the **trapflags** command. To disable, use the **no** form of the command.

trapflags {ap | {interfaceup | register} | client | {dot11 | excluded} | dot11-security | {ids-sig-attack | wep-decrypt-error} | mesh | rougeap | rrm-params | {channels | tx-power} | rrm-profile | {coverage | interference | load | noise}}

no trapflags {ap | {interfaceup | register} | client | {dot11 | excluded} | dot11-security | {ids-sig-attack | wep-decrypt-error} | mesh | rougeap | rrm-params | {channels | tx-power} | rrm-profile | {coverage | interference | load | noise}}

Syntax Description

ap	Enables sending of AP-related traps.
interfaceup	Enables the trap when a Cisco AP interface (A or B) comes up.
register	Enables the trap when a Cisco AP registers with a Cisco controller.
client	Enables sending of client-related Dot11 traps.
dot11	Enables dot11 traps for clients.
excluded	Enables excluded traps for clients.
dot11-security	Enables sending of 802.11 security-related traps.
ids-sig-attack	Enables IDS signature attack traps.
wep-decrypt-error	Enables WEP decrypt error for clients.
mesh	Enables mesh trap.
rougeap	Enables rogueAP detection trap.
rrm-params	Enables sending of RRM parameter update-related traps.
channels	Enables trap when RF Manager automatically changes the channel number for the Cisco AP interface.
tx-power	Enables trap when RF Manager automatically changes Tx-Power Level for the Cisco AP interface.
rrm-profile	Enables sending of RRM profile-related traps.
coverage	Enables trap when the coverage profile maintained by RF Manager fails.
interference	Enables trap when the interference profile maintained by RF Manager fails.

trapflags

load	Enables trap when the load profile maintained by RF Manager fails.
noise	Enables trap when the noise profile maintained by RF Manager fails.

Command Default

Disabled

Command Modes

Interface configuration

Command History

Release	Modification
Cisco IOS XE 3.2SE	This command was introduced.

Examples

This example shows how the trap is enabled for the ids-sig-attach parameter in dot11 security.

```
Controller(config) # trapflags dot11-security ids-sig-attack
```



INDEX

F

flow-based RSPAN (FRSPAN) session [34](#)
flow-based SPAN (FSPAN) session [34](#)

M

monitor session command [28, 30](#)
monitor session filter command [34](#)
monitor session source command [36](#)

R

Remote SPAN (RSPAN) sessions [39](#)
RSPAN [28, 30, 34, 36](#)
 sessions [28, 30, 36](#)
 add interfaces to [28, 30, 36](#)
 start new [28, 30, 36](#)

S

show monitor command [39](#)
snmp-server enable traps bridge command [48](#)

snmp-server enable traps call-home command [49](#)
snmp-server enable traps command [44](#)
snmp-server enable traps CPU command [50](#)
snmp-server enable traps envmon command [51](#)
snmp-server enable traps errdisable command [52](#)
snmp-server enable traps flash command [53](#)
snmp-server enable traps license command [54](#)
snmp-server enable traps mac-notification command [55](#)
snmp-server enable traps port-security command [56](#)
snmp-server enable traps power-ethernet command [57](#)
snmp-server enable traps snmp command [58](#)
snmp-server enable traps stackwise command [59](#)
snmp-server enable traps storm-control command [61](#)
snmp-server enable traps stpx command [62](#)
snmp-server enable traps transceiver command [63](#)
snmp-server enable traps vstack command [64](#)
snmp-server enable traps wireless command [65](#)
snmp-server engineID command [67](#)
snmp-server host command [68](#)
Switched Port Analyzer (SPAN) sessions [39](#)

T

trapflags [73](#)

