



## Show Commands

---

- [show aaa dead-criteria radius](#), on page 8
- [show access-list](#), on page 10
- [show ap airtime-fairness summary](#), on page 12
- [show ap auth-list](#), on page 13
- [show ap auto-rf](#), on page 14
- [show ap ble cmx detail ip](#), on page 17
- [show ap ble cmx summary](#), on page 18
- [show ap ble summary](#), on page 19
- [show ap config](#), on page 20
- [show ap config general](#), on page 21
- [show ap crash-file](#), on page 22
- [show ap dot11](#), on page 23
- [show ap dot11](#), on page 29
- [show ap dot11 24ghz](#), on page 30
- [show ap dot11 24ghz SI config](#), on page 32
- [show ap dot11 24ghz SI device type](#), on page 33
- [show ap dot11 5ghz](#), on page 34
- [show ap dot11 24ghz cleanair air-quality](#), on page 36
- [show ap dot11 24ghz cleanair air-quality](#), on page 37
- [show ap dot11 cleanair config](#), on page 38
- [show ap dot11 cleanair summary](#), on page 40
- [show ap dot11 dual-band summary](#), on page 41
- [show ap environment](#), on page 42
- [show ap filters active](#), on page 43
- [show ap filters all](#), on page 44
- [show ap fra](#), on page 45
- [show ap gps location](#), on page 46
- [show ap group hyperlocation](#), on page 47
- [show history channel interface dot11Radio all](#), on page 49
- [show ap hyperlocation](#), on page 50
- [show ap hyperlocation cmx summary](#), on page 52
- [show ap image](#), on page 53
- [show ap image file summary](#), on page 54

- [show ap image site summary](#), on page 56
- [show ap link-encryption](#), on page 57
- [show ap master list](#), on page 58
- [show ap mesh cac access](#), on page 59
- [show ap mesh cac bwused voice](#), on page 60
- [show ap mesh cac callpath](#), on page 61
- [show ap mesh cac rejected](#), on page 62
- [show ap monitor-mode summary](#), on page 63
- [show ap multicast mom \(multicast over multicast\)](#), on page 64
- [show ap name auto-rf](#), on page 65
- [show ap name ble detail](#), on page 68
- [show ap name cablemodem](#), on page 69
- [show ap name config](#), on page 70
- [show ap name config ethernet](#), on page 72
- [show ap name dot11](#), on page 73
- [show ap name environment](#), on page 76
- [show ap name gps location](#), on page 77
- [show ap name hyperlocation](#), on page 78
- [show ap name mesh backhaul](#), on page 79
- [show ap name mesh bhrate](#), on page 80
- [show ap name mesh linktest](#), on page 81
- [show ap name mesh neighbor detail](#), on page 82
- [show ap name mesh path](#), on page 83
- [show ap name mesh stats](#), on page 84
- [show ap name tunnel eogre events](#), on page 85
- [show ap name tunnel eogre domain detailed](#), on page 86
- [show ap name tunnel eogre domain summary](#), on page 87
- [show ap name tunnel eogre gateway detailed](#), on page 88
- [show ap name tunnel eogre gateway summary](#), on page 89
- [show ap name wlan](#), on page 90
- [show ap name ble detail](#), on page 92
- [show ap profile](#), on page 93
- [show ap rf-profile name](#), on page 94
- [show ap rf-profile summary](#), on page 96
- [show ap summary](#), on page 97
- [show ap summary sort ascending client-count](#), on page 98
- [show ap summary sort ascending data-usage](#), on page 99
- [show ap summary sort ascending throughput](#), on page 100
- [show ap summary sort descending client-count](#), on page 101
- [show ap summary sort descending data-usage](#), on page 102
- [show ap summary sort descending throughput](#), on page 103
- [show ap tag sources](#), on page 104
- [show ap tag summary](#), on page 105
- [show ap upgrade](#), on page 106
- [show arp](#), on page 107
- [show arp summary](#), on page 108

- [show ap tunnel eogre events](#), on page 109
- [show ap tunnel eogre domain detailed](#), on page 110
- [show ap name tunnel eogre domain summary](#), on page 111
- [show ap tunnel eogre gateway detailed](#), on page 112
- [show ap tunnel eogre gateway summary](#), on page 113
- [show avc client](#), on page 114
- [show avc wlan](#), on page 115
- [show chassis](#), on page 116
- [show chassis rmi](#), on page 117
- [show checkpoint](#), on page 118
- [show etherchannel summary](#), on page 125
- [show fips authorization-key](#), on page 126
- [show fips status](#), on page 127
- [show flow exporter](#), on page 128
- [show flow interface](#), on page 130
- [show flow monitor](#), on page 132
- [show flow record](#), on page 134
- [show flow record wireless avc basic](#), on page 135
- [show flow record wireless avc ipv6 basic](#), on page 136
- [show interfaces](#), on page 137
- [show ip](#), on page 141
- [show ip igmp snooping igmpv2-tracking](#), on page 142
- [show ip igmp snooping querier](#), on page 143
- [show ip igmp snooping wireless mcast-spi-count](#), on page 145
- [show ip igmp snooping wireless mgid](#), on page 146
- [show ip nbar protocol-discovery wlan](#), on page 147
- [show ipv6 access-list](#), on page 148
- [show ipv6 mld snooping](#), on page 151
- [show ipv6 mld snooping querier vlan](#), on page 153
- [show ipv6 mld snooping wireless mgid](#), on page 154
- [show ldap attributes](#), on page 155
- [show ldap server](#), on page 156
- [show license all](#), on page 157
- [show license authorization](#), on page 161
- [show license data conversion](#), on page 166
- [show license eventlog](#), on page 167
- [show license history message](#), on page 168
- [show license reservation](#), on page 169
- [show license status](#), on page 170
- [show license summary](#), on page 179
- [show license tech](#), on page 181
- [show license udi](#), on page 187
- [show license usage](#), on page 188
- [show platform software sl-infra](#), on page 191
- [show platform software tls client summary](#), on page 192
- [show platform software client detail](#), on page 193

- [show platform software tls statistics, on page 195](#)
- [show platform software tls session summary, on page 197](#)
- [show lisp site detail, on page 198](#)
- [show logging profile wireless end timestamp, on page 199](#)
- [show logging profile wireless filter, on page 200](#)
- [show logging profile wireless fru, on page 201](#)
- [show logging profile wireless internal, on page 202](#)
- [show logging profile wireless level, on page 203](#)
- [show logging profile wireless module, on page 204](#)
- [show logging profile wireless reverse, on page 205](#)
- [show logging profile wireless start, on page 206](#)
- [show logging profile wireless switch, on page 207](#)
- [show logging profile wireless to-file, on page 208](#)
- [show mdns-sd cache, on page 209](#)
- [show mdns-sd cache detail, on page 210](#)
- [show mdns-sd cache upn shared, on page 211](#)
- [show mdns-sd cache upn detail, on page 213](#)
- [show mdns-sd flexconnect summary , on page 214](#)
- [show mdns-sd statistics, on page 215](#)
- [show mdns-sd summary, on page 216](#)
- [show mobility, on page 217](#)
- [show nmsp, on page 219](#)
- [show nmsp cloud-services statistics, on page 220](#)
- [show nmsp cloud-services summary, on page 221](#)
- [show nmsp subscription group detail ap-list, on page 222](#)
- [show nmsp subscription group detail services, on page 223](#)
- [show nmsp subscription group summary, on page 224](#)
- [show platform conditions, on page 225](#)
- [show platform hardware , on page 226](#)
- [show platform hardware chassis active qfp feature dns-snoop-agent client enabled-intf, on page 227](#)
- [show platform hardware chassis active qfp feature dns-snoop-agent client hw-pattern-list, on page 228](#)
- [show platform hardware chassis active qfp feature dns-snoop-agent client info, on page 229](#)
- [show platform hardware chassis active qfp feature dns-snoop-agent client pattern-list, on page 230](#)
- [show platform hardware chassis active qfp feature dns-snoop-agent datapath ip-cache, on page 231](#)
- [show platform hardware chassis active qfp feature dns-snoop-agent datapath memory, on page 232](#)
- [show platform hardware chassis active qfp feature dns-snoop-agent datapath regexp-table, on page 233](#)
- [show platform hardware chassis active qfp feature dns-snoop-agent datapath stats, on page 234](#)
- [show platform hardware chassis active qfp feature et-analytics datapath runtime, on page 235](#)
- [show platform hardware chassis active qfp feature et-analytics datapath memory, on page 236](#)
- [show platform hardware chassis active qfp feature et-analytics datapath stats export, on page 237](#)
- [show platform hardware chassis active qfp feature et-analytics datapath stats flow, on page 238](#)
- [show platform hardware chassis active qfp feature wireless et-analytics eta-pending-client-tree, on page 239](#)
- [show platform hardware chassis active qfp feature wireless et-analytics statistics, on page 240](#)
- [show platform software audit, on page 241](#)
- [show platform software system all, on page 243](#)

- show platform software trace filter-binary, on page 244
- show platform software trace filter-binary, on page 245
- show platform software trace level, on page 246
- show platform software trace message, on page 249
- show platform software trace message license-manager chassis active R0, on page 251
- show platform software trace message license-manager , on page 254
- show platform software utd chassis active F0 et-analytics global, on page 257
- show platform software et-analytics global, on page 258
- show parameter-map type umbrella global, on page 259
- show policy-map, on page 260
- show remote-lan all, on page 265
- show remote-lan id, on page 266
- show remote-lan name, on page 267
- show remote-lan policy detail, on page 268
- show remote-lan policy summary, on page 270
- show remote-lan summary, on page 271
- show ssh , on page 272
- show tech-support wireless, on page 273
- show tech-support wireless ap, on page 275
- show tech-support wireless client, on page 285
- **show tech-support wireless datapath**, on page 289
- show tech-support wireless fabric, on page 310
- **show tech-support wireless mobility**, on page 311
- show tech-support wireless radio, on page 323
- show tunnel eogre global-configuration, on page 334
- show tunnel eogre domain detailed, on page 335
- show tunnel eogre domain summary, on page 336
- show tunnel eogre gateway summary, on page 337
- show tunnel eogre gateway detailed , on page 338
- show tunnel eogre manager stats global, on page 339
- show tunnel eogre manager stats instance, on page 341
- show umbrella config, on page 343
- show umbrella deviceid, on page 344
- show umbrella deviceid detailed, on page 345
- show umbrella dnscrypt, on page 346
- show vlan, on page 347
- show vlan access-map, on page 350
- show vlan filter, on page 351
- show vlan group, on page 352
- show wireless band-select, on page 353
- show wireless client , on page 354
- show wireless client mac-address , on page 355
- show wireless client mac-address (Call Control), on page 357
- show wireless client mac-address (TCLAS), on page 358
- show wireless client mac-address mobility history, on page 359
- show wireless client summary, on page 360

- [show wireless client timers](#), on page 361
- [show wireless country](#), on page 362
- [show wireless detail](#), on page 365
- [show wireless dot11h](#) , on page 366
- [show wireless dtls connections](#), on page 367
- [show wireless exclusionlist](#) , on page 368
- [show wireless fabric summary](#), on page 369
- [show wireless fabric client summary](#) , on page 370
- [show wireless fabric vnid mapping](#), on page 371
- [show wireless flow-control](#), on page 372
- [show wireless flow-control statistics](#), on page 373
- [show wireless load-balancing](#), on page 374
- [show wireless media-stream client detail](#) , on page 375
- [show wireless media-stream group](#), on page 376
- [show wireless media-stream message details](#) , on page 377
- [show wireless mobility controller ap](#), on page 378
- [show wireless media-stream multicast-direct state](#) , on page 379
- [show wireless mesh ap](#) , on page 380
- [show wireless mesh ap summary](#) , on page 381
- [show wireless mesh ap tree](#) , on page 382
- [show wireless mesh ap tree](#), on page 383
- [show wireless mesh cac summary](#), on page 384
- [show wireless mesh config](#) , on page 385
- [show wireless mesh neighbor](#) , on page 386
- [show wireless mobility](#), on page 387
- [show wireless mobility peer ip](#) , on page 388
- [show wireless multicast group summary](#) , on page 389
- [show wireless mobility summary](#) , on page 390
- [show wireless multicast](#), on page 391
- [show wireless multicast group](#), on page 392
- [show wireless performance](#), on page 393
- [show wireless pmk-cache](#), on page 394
- [show wireless probe](#), on page 395
- [show wireless profile airtime-fairness mapping](#), on page 396
- [show wireless profile airtime-fairness summary](#), on page 397
- [show wireless profile ap packet-capture](#), on page 398
- [show wireless profile calendar-profile detailed](#), on page 400
- [show wireless profile calendar-profile summary](#), on page 401
- [show wireless profile fabric detailed](#), on page 402
- [show wireless profile flex](#) , on page 403
- [show wireless profile policy detailed](#) , on page 404
- [show wireless profile tunnel summary](#), on page 405
- [show wireless redundancy statistics](#) , on page 406
- [show wireless rfid](#), on page 407
- [show wireless statistics mobility](#) , on page 408
- [show wireless stats mesh packet error](#) , on page 409

- [show wireless stats mesh security and queue](#), on page 410
- [show wireless stats client detail](#), on page 411
- [show wireless summary](#), on page 412
- [show wireless tag rf](#), on page 413
- [show wireless urlfilter details](#), on page 414
- [show wireless urlfilter summary](#), on page 415
- [show wireless vlan details](#) , on page 416
- [show wireless wgb mac-address](#) , on page 417
- [show wireless wgb summary](#) , on page 418
- [show wireless wps mfp ap summary](#), on page 419
- [show wireless wps mfp statistics](#), on page 420
- [show wireless wps mfp summary](#), on page 421
- [show wireless wps rogue](#) , on page 422
- [show wireless wps rogue ap summary](#) , on page 423
- [show wireless wps rogue client detailed](#), on page 424
- [show wireless wps rogue client summary](#), on page 425
- [show wireless wps summary](#), on page 426
- [show wlan summary sort ascending client-count](#), on page 427
- [show wlan summary sort descending client-count](#), on page 428
- [show wlan summary sort ascending data-usage](#), on page 429
- [show wlan summary sort descending data-usage](#), on page 430
- [show wps summary](#), on page 431
- [shutdown](#), on page 432

# show aaa dead-criteria radius

To verify the dead-server-detection information for a RADIUS server, use the **show aaa dead-criteria radius** command.

**show aaa dead-criteria radius** *ipaddr* **auth-port** *authport* **acct-port** *acctport*

<b>Syntax Description</b>	<i>ipaddr</i> IP address.				
	<i>authport</i> Authentication port.				
	<i>acctport</i> Accounting port.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.10.1</td> <td>This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.
Release	Modification				
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.				
<b>Usage Guidelines</b>	The <b>show aaa dead-criteria radius</b> <i>ipaddr</i> command displays output only if default ports are used. For non-default ports, use the <b>show aaa dead-criteria radius</b> <i>ipaddr</i> <b>auth-port</b> <i>authport</i> <b>acct-port</b> <i>acctport</i> command.				

## Example

The following example shows how to see the dead-server-detection information for a RADIUS server with non-default authorization and accounting ports:

```
Device# show aaa dead-criteria radius 4.4.4.4 auth-port 4444 acct-port 3333

RADIUS: No server group specified. Using radius
RADIUS Server Dead Criteria:
=====
Server Details:
Address : 4.4.4.4
Auth Port : 4444
Acct Port : 3333
Server Group : radius
Dead Criteria Details:
Configured Retransmits : 3
Configured Timeout : 5
Estimated Outstanding Access Transactions: 0
Estimated Outstanding Accounting Transactions: 0
Dead Detect Time : 10s
Computed Retransmit Tries: 10
Statistics Gathered Since Last Successful Transaction
=====
Max Computed Outstanding Transactions: 0
Max Computed Dead Detect Time: 0s
```



```
Max Computed Retransmits : 0
```

The following example shows how to see the dead-server-detection information for a RADIUS server using default ports:

```
Device# show aaa dead-criteria radius 9.3.13.37

RADIUS: No server group specified. Using radius
RADIUS Server Dead Criteria:
=====
Server Details:
Address : 9.3.13.37
Auth Port : 1812
Acct Port : 1813
Server Group : radius
Dead Criteria Details:
Configured Retransmits : 3
Configured Timeout : 30
Estimated Outstanding Access Transactions: 1
Estimated Outstanding Accounting Transactions: 0
Dead Detect Time : 10s
Computed Retransmit Tries: 10
Statistics Gathered Since Last Successful Transaction
=====
Max Computed Outstanding Transactions: 4
Max Computed Dead Detect Time: 48s
Max Computed Retransmits : 30
```

# show access-list

To display access control lists (ACLs) configured on the device, use the **show access-lists** command in privileged EXEC mode.

**show access-lists**[*{namenumber | hardware counters | ipc}*]

Syntax Description	
<i>number</i>	(Optional) ACL number. The range is 1 to 2799.
<i>name</i>	(Optional) Name of the ACL.
<b>hardware counters</b>	(Optional) Displays the access list hardware counters.
<b>ipc</b>	(Optional) Display Interprocess Communication (IPC) protocol access-list configuration download information

## Command Default

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Usage Guidelines

Though visible in the command-line help strings, the **rate-limit** keyword is not supported

The device supports only IP standard and extended access lists. Therefore, the allowed numbers are only 1 to 199 and 1300 to 2799.

This command also displays the MAC ACLs that are configured.

This is an example of output from the **show access-lists** command:

```
Device# show access-lists

Extended IP access list 103
  10 permit ip any any dscp af11
Extended IP access list ssm-range
  10 deny ip any 232.0.0.0 0.255.255.255
  20 permit ip any any
Extended MAC access list macl
```

This is an example of output from the **show access-lists hardware counters** command:

```
Device# show access-lists hardware counters
L3 ACL INPUT Statistics
  All Drop:                               frame count: 0
  All Bridge Only:                         frame count: 0
  All Forwarding To CPU:                   frame count: 294674
  All Forwarded:                           frame count: 2577677
```

```
All Drop And Log:          frame count: 0
All Bridge Only And Log:   frame count: 0
All Forwarded And Log:    frame count: 0
All IPv6 Drop:            frame count: 0
All IPv6 Bridge Only:     frame count: 0
All IPv6 Forwarding To CPU: frame count: 0
All IPv6 Forwarded:       frame count: 102
All IPv6 Drop And Log:    frame count: 0
All IPv6 Bridge Only And Log: frame count: 0
All IPv6 Forwarded And Log: frame count: 0
```

### L3 ACL OUTPUT Statistics

```
All Drop:                  frame count: 0
All Bridge Only:          frame count: 0
All Forwarding To CPU:    frame count: 0
All Forwarded:            frame count: 266050
All Drop And Log:        frame count: 0
All Bridge Only And Log:  frame count: 0
All Forwarded And Log:    frame count: 0
All IPv6 Drop:            frame count: 0
All IPv6 Bridge Only:     frame count: 0
All IPv6 Forwarding To CPU: frame count: 0
All IPv6 Forwarded:       frame count: 0
All IPv6 Drop And Log:    frame count: 0
All IPv6 Bridge Only And Log: frame count: 0
All IPv6 Forwarded And Log: frame count: 0
```

# show ap airtime-fairness summary

To view the ATF configuration summary of all radios, use the **show ap airtime-fairness summary** command.

**show ap airtime-fairness summary**

<b>Syntax Description</b>	This command has no arguments.
---------------------------	--------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ATF configuration summary of all radios:

```
Device# show ap airtime-fairness summary
```

# show ap auth-list

To see the access point authorization list, use the **show ap auth-list** command.

```
show ap auth-list [chassis {chassis-number | active | standby} R0]
```

## Syntax Description

*chassis-number* Chassis number as either 1 or 2.

**active R0** Active instance in Route-processor slot 0.

**standby R0** Standby instance in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the access point authorization list:

```
Device# show ap auth-list
```

# show ap auto-rf

To display the auto-RF settings for a Cisco lightweight access point, use the **show ap auto-rf** command.

```
show ap auto-rf dot11 {24ghz | 5ghz | dual-band} cisco_ap
```

Syntax Description		
	<b>24ghz</b>	Specifies the 802.11b AP.
	<b>5ghz</b>	Specifies the 802.11a AP.
	<b>dual-band</b>	Specifies dual bands.

**Command Default** None

**Usage Guidelines** The **show ap auto-rf** command output will not display neighbor AP names.

The following example shows how to display auto-RF information for an access point:

```
Device# show ap auto-rf dot11 24ghz AP1

#####

Number of Slots                : 3
AP Name                        : APA023.9FD8.EA22
MAC Address                    : 40ce.24bf.8ca0
Ethernet MAC Address          : a023.9fd8.ea22
  Slot ID                      : 0
  Radio Type                   : 802.11n - 2.4 GHz
  Current TX/RX Band           : 2.4Ghz band
  Subband Type                 : All
Noise Information
  Noise Profile                : Passed
  Channel 1                    : -91 dBm
  Channel 2                    : -67 dBm
  Channel 3                    : -54 dBm
  Channel 4                    : -55 dBm
  Channel 5                    : -71 dBm
  Channel 6                    : -85 dBm
  Channel 7                    : -50 dBm
  Channel 8                    : -54 dBm
  Channel 9                    : -77 dBm
  Channel 10                   : -88 dBm
  Channel 11                   : -65 dBm
Interference Information
  Interference Profile         : Failed
  Channel 1                    : -47 dBm @ 21% busy
  Channel 2                    : -45 dBm @ 2% busy
  Channel 3                    : -128 dBm @ 0% busy
  Channel 4                    : -128 dBm @ 0% busy
  Channel 5                    : -48 dBm @ 2% busy
  Channel 6                    : -45 dBm @ 2% busy
  Channel 7                    : -42 dBm @ 3% busy
  Channel 8                    : -128 dBm @ 0% busy
  Channel 9                    : -128 dBm @ 0% busy
  Channel 10                   : -39 dBm @ 3% busy
  Channel 11                   : -46 dBm @ 3% busy
Rogue Histogram (20)
  Channel 1                    : 36
```

```

Channel 2 : 0
Channel 3 : 0
Channel 4 : 1
Channel 5 : 0
Channel 6 : 11
Channel 7 : 0
Channel 8 : 1
Channel 9 : 3
Channel 10 : 0
Channel 11 : 14
Load Information
Load Profile : Failed
Receive Utilization : 0%
Transmit Utilization : 0%
Channel Utilization : 98%
Attached Clients : 0 clients
Coverage Information
Coverage Profile : Passed
Failed Clients : 0 clients
Client Signal Strengths
RSSI -100 dBm : 0 clients
RSSI -92 dBm : 0 clients
RSSI -84 dBm : 0 clients
RSSI -76 dBm : 0 clients
RSSI -68 dBm : 0 clients
RSSI -60 dBm : 0 clients
RSSI -52 dBm : 0 clients
Client Signal to Noise Ratios
SNR 0 dB : 0 clients
SNR 5 dB : 0 clients
SNR 10 dB : 0 clients
SNR 15 dB : 0 clients
SNR 20 dB : 0 clients
SNR 25 dB : 0 clients
SNR 30 dB : 0 clients
SNR 35 dB : 0 clients
SNR 40 dB : 0 clients
SNR 45 dB : 0 clients
Nearby APs
AP d0ec.3572.b9a0 slot 0 : -23 dBm on ( 11, 20 MHz) (181.22.0.22)
AP 0c75.bdb3.9000 slot 0 : -28 dBm on ( 11, 20 MHz) (181.21.0.21)
AP a4b2.3980.3740 slot 0 : -28 dBm on ( 1, 20 MHz) (181.21.0.21)
AP d0ec.3576.8320 slot 0 : -33 dBm on ( 11, 20 MHz) (50.1.1.122)
AP a0f8.49dc.9780 slot 0 : -34 dBm on ( 1, 20 MHz) (9.9.57.94)
AP a0f8.49dc.8260 slot 0 : -34 dBm on ( 6, 20 MHz) (9.9.57.94)
AP d0ec.3573.7c80 slot 0 : -36 dBm on ( 6, 20 MHz) (192.185.183.44)

AP 00b0.e192.9d20 slot 0 : -36 dBm on ( 11, 20 MHz) (9.9.42.47)
AP a4b2.397f.41c0 slot 0 : -36 dBm on ( 1, 20 MHz) (185.10.0.10)
AP 2c5a.0fd5.b8c0 slot 0 : -36 dBm on ( 6, 20 MHz) (9.7.97.51)
AP a488.7351.4740 slot 0 : -36 dBm on ( 11, 20 MHz) (9.7.97.51)
AP 10b3.d5e9.c8e0 slot 0 : -36 dBm on ( 1, 20 MHz) (50.1.1.122)
AP 0c75.bdb3.ab00 slot 0 : -37 dBm on ( 6, 20 MHz) (185.10.0.10)
AP 68ca.e451.5120 slot 0 : -37 dBm on ( 1, 20 MHz) (9.4.155.15)
AP a0f8.49dc.97a0 slot 0 : -37 dBm on ( 11, 20 MHz) (9.9.57.94)
AP 188b.4501.7940 slot 0 : -38 dBm on ( 11, 20 MHz) (9.9.57.94)
AP 002c.c88a.f8e0 slot 0 : -38 dBm on ( 11, 20 MHz) (9.9.50.55)
AP 7069.5a78.4960 slot 0 : -38 dBm on ( 11, 20 MHz) (9.7.97.51)
AP 3c41.0ea7.0880 slot 0 : -39 dBm on ( 11, 20 MHz) (185.10.0.10)
AP a0f8.49dc.93a0 slot 0 : -39 dBm on ( 6, 20 MHz) (9.9.57.94)
AP f4db.e685.7360 slot 0 : -39 dBm on ( 6, 20 MHz) (50.1.1.122)
AP 7070.8bb4.4120 slot 0 : -40 dBm on ( 11, 20 MHz) (9.9.57.94)
AP 707d.b93e.39e0 slot 0 : -40 dBm on ( 1, 20 MHz) (4.4.4.1)
AP 706d.150c.6860 slot 0 : -40 dBm on ( 11, 20 MHz) (50.1.1.122)

```

```
Radar Information
Channel Assignment Information via DCA
  Current Channel Average Energy      : -50 dBm
  Previous Channel Average Energy     : -50 dBm
  Channel Change Count                : 9
  Last Channel Change Time            : 02/14/2021 20:54:57
  Recommended Best Channel            : 1
RF Parameter Recommendations
  Power Level                         : 8
  RTS/CTS Threshold                   : 2347
  Fragmentation Threshold              : 2346
  Antenna Pattern                     : 0
Persistent Interference Devices
Class Type      Channel  DC (%)  RSSI (dBm)  Last Update Time
-----
All third party trademarks are the property of their respective owners.
```



# show ap ble cmx detail ip

To view the BLE management feature related global values for a specific CMX along with all the APs associated to that CMX, use the **show ap ble cmx detail ip** command.

**show ap ble cmx detail ip** *CMX-IP*

<b>Syntax Description</b>	<i>CMX-IP</i> Specifies the IPv4 address.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.11.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.				

## Usage Guidelines

This example shows how to display the BLE management feature related global values for a specific CMX along with all the APs associated to that CMX:

```
Device# show ap ble cmx detail ip 10.1.2.3
BLE administrative status: Up
BLE operational status: Up
Scanning interval: 10
```

AP Name	Interface	Status
AP4001.7AB2.C39A	Integrated	Open

# show ap ble cmx summary

To view the list of all CMXs registered for BLE Management feature and their global values for BLE, use the **show ap ble cmx summary** command.

## show ap ble cmx summary

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Usage Guidelines

This example shows how to view the list of all CMXs registered for BLE Management feature and their global values for BLE:

```
Device# show ap ble cmx summary
CMX IP: 10.1.2.3
-----
BLE administrative status: Up
BLE operational status: Up
Scanning interval: 12

CMX IP: 10.1.2.4
-----
BLE administrative status: Down
BLE operational status: Down
Reason: BLE is administratively down
Scanning interval: 0

CMX IP: 10.1.2.5
-----
BLE administrative status: Up
BLE operational status: Down
Reason: CMX is not subscribed to AP Monitor and RSSI services, or NMSP connection is down
Scanning interval: 10
```

# show ap ble summary

To view the list of joined APs that support BLE Management feature along with the BLE details for each AP, use the **show ap ble summary** command.

**show ap ble summary**

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.
<b>Usage Guidelines</b>	The BLE Management feature is enabled and APs are displayed only when the CMX is registered with the controller, and BLE is enabled on CMX.	

This example shows how to view the list of joined APs that support BLE Management feature along with the BLE details for each AP:

```
Device# show ap ble summary
AP Name                               Interface           Status             CMX IP
-----
AP4001.7AB2.C39A                      Integrated          Open               10.1.2.3
AP4001.7AB2.C39B                      Integrated          Closed             10.1.2.4
```

# show ap config

To display configuration settings for all access points that join the device, use the **show ap config** command.

```
show ap config {general | global}
```

Syntax Description	
<b>ethernet</b>	Displays ethernet VLAN tagging information for all Cisco APs.
<b>general</b>	Displays common information for all Cisco APs.
<b>global</b>	Displays global settings for all Cisco APs.

Command Default	None
-----------------	------

Command Modes	Any command mode
---------------	------------------

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display global syslog server settings:

```
Device# show ap config global
```

```
AP global system logging host                : 255.255.255.255
```

# show ap config general

To display the AP and DHCP server details, use the **show ap config general** command.

## show ap config general

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Usage Guidelines

This example shows how to display the AP and DHCP server details:

```
Device# show ap config general

Cisco AP Name      : AP4C77.6DF2.D588
=====
<SNIP>
Dhcp Server                : Enabled
```

## show ap crash-file

To display the list of both crash and radio core dump files generated by lightweight access points, use the **show ap crash-file** command.

**show ap crash-file***chassis chassis-number <1-2>***active standby**

Syntax Description		
<b>chassis</b>	Displays the chassis details.	
<i>chassis-number</i>	Specifies the chassis number, either 1 or 2.	
<b>active</b>	Specifies an active instance.	
<b>standby</b>	Specifies a standby instance.	
Command Default	None	
Command Modes	Any command mode	
Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display the crash file generated by the access point:

```
Device# show ap crash-file
```

# show ap dot11

To view 802.11a or 802.11b configuration information, use the **show ap dot11** command.

```
show ap dot11 {24ghz | 5ghz} {channel | coverage | group | load-info | logging | media-stream | monitor | network | profile | receiver | service-policy | summary | txpower | ccx global}
```

Syntax	Description
<b>24ghz</b>	Specifies the 2.4 GHz band.
<b>5ghz</b>	Specifies the 5 GHz band.
<b>channel</b>	Displays the automatic channel assignment configuration and statistics.
<b>coverage</b>	Displays the configuration and statistics for coverage hole detection.
<b>group</b>	Displays 802.11a or 802.11b Cisco radio RF grouping.
<b>load-info</b>	Displays channel utilization and client count information for all Cisco APs.
<b>logging</b>	Displays 802.11a or 802.11b RF event and performance logging.
<b>media-stream</b>	Display 802.11a or 802.11b Media Resource Reservation Control configurations.
<b>monitor</b>	Displays the 802.11a or 802.11b default Cisco radio monitoring.
<b>network</b>	Displays the 802.11a or 802.11b network configuration.
<b>profile</b>	Displays the 802.11a or 802.11b lightweight access point performance profiles.
<b>receiver</b>	Displays the configuration and statistics of the 802.11a or 802.11b receiver.
<b>service-policy</b>	Displays the Quality of Service (QoS) service policies for 802.11a or 802.11b radio for all Cisco access points.
<b>summary</b>	Displays the 802.11a or 802.11b Cisco lightweight access point name, channel, and transmit level summary.
<b>txpower</b>	Displays the 802.11a or 802.11b automatic transmit power assignment.
<b>ccx global</b>	Displays 802.11a or 802.11b Cisco Client eXtensions (CCX) information for all Cisco access points that are joined to the device.

---

**Command Default**    None

---

**Command Modes**    Any command mode

---

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	Cisco IOS XE Gibraltar 16.12.2s
		This command was introduced.
		The <b>load-info</b> parameter was added.

---

This example shows how to display the automatic channel assignment configuration and statistics:

```
Device# show ap dot11 5ghz channel
Automatic Channel Assignment
  Channel Assignment Mode           : AUTO
  Channel Update Interval          : 12 Hours
  Anchor time (Hour of the day)    : 20
  Channel Update Contribution      : SNI.
  Channel Assignment Leader        : web (9.9.9.2)
  Last Run                         : 13105 seconds ago
  DCA Sensitivity Level            : MEDIUM (15 dB)
  DCA 802.11n Channel Width       : 40 Mhz
  Channel Energy Levels
    Minimum                       : unknown
    Average                       : unknown
    Maximum                       : unknown
  Channel Dwell Times
    Minimum                       : unknown
    Average                       : unknown
    Maximum                       : unknown
  802.11a 5 GHz Auto-RF Channel List
  Allowed Channel List             : 36,40,44,48,52,56,60,64,149,153,1
  57,161
  Unused Channel List             : 100,104,108,112,116,132,136,140,1
  65
  802.11a 4.9 GHz Auto-RF Channel List
  Allowed Channel List             :
  Unused Channel List             : 1,2,3,4,5,6,7,8,9,10,11,12,13,14,
  15,16,17,18,19,20,21,22,23,24,25,26
  DCA Outdoor AP option           : Disabled
```

This example shows how to display the statistics for coverage hole detection:

```
Device# show ap dot11 5ghz coverage
Coverage Hole Detection
  802.11a Coverage Hole Detection Mode : Enabled
  802.11a Coverage Voice Packet Count  : 100 packet(s)
  802.11a Coverage Voice Packet Percentage : 50 %
  802.11a Coverage Voice RSSI Threshold : -80dBm
  802.11a Coverage Data Packet Count   : 50 packet(s)
  802.11a Coverage Data Packet Percentage : 50 %
  802.11a Coverage Data RSSI Threshold : -80dBm
  802.11a Global coverage exception level : 25
  802.11a Global client minimum exception level : 3 clients
```

This example shows how to display Cisco radio RF group settings:

```
Device# show ap dot11 5ghz group
Radio RF Grouping
  802.11a Group Mode                : STATIC
```



```

802.11a Group Update Interval      : 600 seconds
802.11a Group Leader               : web (10.10.10.1)
802.11a Group Member              : web(10.10.10.1)
                                   nb1(172.13.21.45) (*Unreachable)
802.11a Last Run                   : 438 seconds ago

```

Mobility Agents RF membership information

```
-----
No of 802.11a MA RF-members : 0
```

This example shows how to display 802.11a RF event and performance logging:

```

Device# show ap dot11 5ghz logging
RF Event and Performance Logging

Channel Update Logging           : Off
Coverage Profile Logging         : Off
Foreign Profile Logging          : Off
Load Profile Logging             : Off
Noise Profile Logging            : Off
Performance Profile Logging      : Off
TxPower Update Logging           : Off

```

This example shows how to display the 802.11a media stream configuration:

```

Device# show ap dot11 5ghz media-stream
Multicast-direct                 : Disabled
Best Effort                      : Disabled
Video Re-Direct                 : Disabled
Max Allowed Streams Per Radio    : Auto
Max Allowed Streams Per Client   : Auto
Max Video Bandwidth              : 0
Max Voice Bandwidth              : 75
Max Media Bandwidth              : 85
Min PHY Rate (Kbps)              : 6000
Max Retry Percentage             : 80

```

This example shows how to display the radio monitoring for the 802.11b network:

```

Device# show ap dot11 5ghz monitor
Default 802.11a AP monitoring

802.11a Monitor Mode              : Enabled
802.11a Monitor Mode for Mesh AP Backhaul : disabled
802.11a Monitor Channels          : Country channels
802.11a RRM Neighbor Discover Type : Transparent
802.11a AP Coverage Interval     : 180 seconds
802.11a AP Load Interval         : 60 seconds
802.11a AP Noise Interval        : 180 seconds
802.11a AP Signal Strength Interval : 60 seconds

```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```

Device# show ap dot11 5ghz profile
Default 802.11a AP performance profiles
802.11a Global Interference threshold..... 10%
802.11a Global noise threshold..... -70 dBm
802.11a Global RF utilization threshold..... 80%
802.11a Global throughput threshold..... 1000000 bps
802.11a Global clients threshold..... 12 clients
802.11a Global coverage threshold..... 12 dB

```

```
802.11a Global coverage exception level..... 80%
802.11a Global client minimum exception lev..... 3 clients
```

This example shows how to display the network configuration of an 802.11a profile:

```
Device# show ap dot11 5ghz network
```

```
802.11a Network : Enabled
11nSupport : Enabled
  802.11a Low Band : Enabled
  802.11a Mid Band : Enabled
  802.11a High Band : Enabled
```

```
802.11a Operational Rates
```

```
  802.11a 6M : Mandatory
  802.11a 9M : Supported
  802.11a 12M : Mandatory
  802.11a 18M : Supported
  802.11a 24M : Mandatory
  802.11a 36M : Supported
  802.11a 48M : Supported
  802.11a 54M : Supported
```

```
802.11n MCS Settings:
```

```
MCS 0 : Supported
MCS 1 : Supported
MCS 2 : Supported
MCS 3 : Supported
MCS 4 : Supported
MCS 5 : Supported
MCS 6 : Supported
MCS 7 : Supported
MCS 8 : Supported
MCS 9 : Supported
MCS 10 : Supported
MCS 11 : Supported
MCS 12 : Supported
MCS 13 : Supported
MCS 14 : Supported
MCS 15 : Supported
MCS 16 : Supported
MCS 17 : Supported
MCS 18 : Supported
MCS 19 : Supported
MCS 20 : Supported
MCS 21 : Supported
MCS 22 : Supported
MCS 23 : Supported
```

```
802.11n Status:
```

```
A-MPDU Tx:
  Priority 0 : Enabled
  Priority 1 : Disabled
  Priority 2 : Disabled
  Priority 3 : Disabled
  Priority 4 : Enabled
  Priority 5 : Enabled
  Priority 6 : Disabled
  Priority 7 : Disabled
```

```
A-MSDU Tx:
  Priority 0 : Enabled
  Priority 1 : Enabled
  Priority 2 : Enabled
  Priority 3 : Enabled
  Priority 4 : Enabled
  Priority 5 : Enabled
  Priority 6 : Disabled
```

```

    Priority 7 : Disabled
    Guard Interval : Any
    Rifs Rx : Enabled
    Beacon Interval : 100
    CF Pollable mandatory : Disabled
    CF Poll Request Mandatory : Disabled
    CFP Period : 4
    CFP Maximum Duration : 60
    Default Channel : 36
    Default Tx Power Level : 1
    DTPC Status : Enabled
    Fragmentation Threshold : 2346
    Pico-Cell Status : Disabled
    Pico-Cell-V2 Status : Disabled
    TI Threshold : 0
    Legacy Tx Beamforming setting : Disabled
    Traffic Stream Metrics Status : Disabled
    Expedited BW Request Status : Disabled
    EDCA profile type check : default-wmm
    Call Admission Control (CAC) configuration
    Voice AC
      Voice AC - Admission control (ACM) : Disabled
      Voice Stream-Size : 84000
      Voice Max-Streams : 2
      Voice Max RF Bandwidth : 75
      Voice Reserved Roaming Bandwidth : 6
      Voice Load-Based CAC mode : Enabled
      Voice tspec inactivity timeout : Enabled
    CAC SIP-Voice configuration
      SIP based CAC : Disabled
      SIP call bandwidth : 64
      SIP call bandwidth sample-size : 20
    Video AC
      Video AC - Admission control (ACM) : Disabled
      Video max RF bandwidth : Infinite
      Video reserved roaming bandwidth : 0

```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```

Device# show ap dot11 5ghz receiver
Default 802.11a AP performance profiles
802.11a Global Interference threshold..... 10%
802.11a Global noise threshold..... -70 dBm
802.11a Global RF utilization threshold..... 80%
802.11a Global throughput threshold..... 1000000 bps
802.11a Global clients threshold..... 12 clients
802.11a Global coverage threshold..... 12 dB
802.11a Global coverage exception level..... 80%
802.11a Global client minimum exception lev..... 3 clients

```

This example shows how to display the global configuration and statistics of an 802.11a profile:

```

Device# show ap dot11 5ghz service-policy

```

This example shows how to display a summary of the 802.11b access point settings:

```

Device# show ap dot11 5ghz summary
AP Name MAC Address      Admin State Operation State Channel TxPower
-----
CJ-1240 00:21:1b:ea:36:60  ENABLED      UP              161      1 ( )
CJ-1130 00:1f:ca:cf:b6:60  ENABLED      UP              56*     1 (*)

```

This example shows how to display the configuration and statistics of the 802.11a transmit power cost:

```
Device# show ap dot11 5ghz txpower
Automatic Transmit Power Assignment

Transmit Power Assignment Mode      : AUTO
Transmit Power Update Interval      : 600 seconds
Transmit Power Threshold             : -70 dBm
Transmit Power Neighbor Count       : 3 APs
Min Transmit Power                   : -10 dBm
Max Transmit Power                   : 30 dBm
Transmit Power Update Contribution   : SNI.
Transmit Power Assignment Leader     : web (10.10.10.1)
Last Run                             : 437 seconds ago
```

This example shows how to display the configuration and statistics of the 802.11a transmit power cost:

```
Device# show ap dot11 5ghz ccx global
802.11a Client Beacon Measurements:
  disabled
```

# show ap dot11

To display 802.11 band parameters, use the **show ap dot11** command.

```
show ap dot11 {24ghz | 5ghz} {media-stream rrc | network | profile | summary}
```

<b>Syntax Description</b>	<b>media-stream rrc</b> Displays Media Stream configurations.
	<b>network</b> Shows network configuration.
	<b>profile</b> Shows profiling information for all Cisco APs.
	<b>summary</b> Shows configuration and statistics of 802.11b and 802.11a Cisco APs.
<b>Command Default</b>	None
<b>Command Modes</b>	User EXEC command mode or Privileged EXEC command mode
<b>Usage Guidelines</b>	None.

The following is a sample output of the **show ap dot11 24ghz media-stream rrc** command.

```
Device#show ap dot11 24ghz media-stream rrc

Multicast-direct           : Disabled
Best Effort                 : Disabled
Video Re-Direct           : Disabled
Max Allowed Streams Per Radio : Auto
Max Allowed Streams Per Client : Auto
Max Video Bandwidth        : 0
Max Voice Bandwidth        : 75
Max Media Bandwidth        : 85
Min PHY Rate (Kbps)        : 6000
Max Retry Percentage       : 80
```

# show ap dot11 24ghz

To display the 2.4 GHz RRM parameters, use the **show ap dot11 24ghz** command.

**show ap dot11 24ghz** {**ccx** | **channel** | **coverage** | **group** | **l2roam** | **logging** | **monitor** | **profile** | **receiver** | **summary** | **txpower**}

## Syntax Description

<b>ccx</b>	Displays the 802.11b CCX information for all Cisco APs.
<b>channel</b>	Displays the configuration and statistics of the 802.11b channel assignment.
<b>coverage</b>	Displays the configuration and statistics of the 802.11b coverage.
<b>group</b>	Displays the configuration and statistics of the 802.11b grouping.
<b>l2roam</b>	Displays 802.11b l2roam information.
<b>logging</b>	Displays the configuration and statistics of the 802.11b event logging.
<b>monitor</b>	Displays the configuration and statistics of the 802.11b monitoring.
<b>profile</b>	Displays 802.11b profiling information for all Cisco APs.
<b>receiver</b>	Displays the configuration and statistics of the 802.11b receiver.
<b>summary</b>	Displays the configuration and statistics of the 802.11b Cisco APs.
<b>txpower</b>	Displays the configuration and statistics of the 802.11b transmit power control.

## Command Default

None.

## Command Modes

Global configuration.

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Usage Guidelines

None.

This example shows how to display configuration and statistics of the 802.11b coverage.

```
Device#show ap dot11 24ghz coverage
```

```
Coverage Hole Detection
 802.11b Coverage Hole Detection Mode      : Enabled
 802.11b Coverage Voice Packet Count      : 100 packet(s)
 802.11b Coverage Voice Packet Percentage  : 50%
 802.11b Coverage Voice RSSI Threshold    : -80 dBm
 802.11b Coverage Data Packet Count       : 50 packet(s)
 802.11b Coverage Data Packet Percentage  : 50%
 802.11b Coverage Data RSSI Threshold     : -80 dBm
```

```
802.11b Global coverage exception level      : 25 %  
802.11b Global client minimum exception level : 3 clients
```

## show ap dot11 24ghz SI config

To see the spectrum intelligence (SI) configuration details for the 2.4-GHz band, use the **show ap dot11 24ghz SI config** command.

**show ap dot11 24ghz SI config** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description	
<i>chassis-number</i>	Chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the configuration in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the configuration in Route-processor slot 0.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

### Examples

The following example shows how to see the SI configuration details for the 2.4-GHz band:

```
Device# show ap dot11 24ghz SI config chassis 1 R0
```



## show ap dot11 24ghz SI device type

To see the spectrum intelligence (SI) interferers of different types for the 2.4-GHz band, use the **show ap dot11 24ghz SI device type** command.

```
show ap dot11 24ghz SI device type {cont_tx | mw_oven | si_fhss} [chassis {chassis-number
| active | standby} R0]
```

Syntax Description	cont_tx	SI interferers of type Continuous transmitter for the 2.4-GHz band.
	mw_oven	SI interferers of type microwave oven for the 2.4-GHz band.
	si_fhss	SI interferers of type Frequency Hopping Spread Spectrum for the 2.4-GHz band.
	<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
	active R0	Active instance of the configuration in Route-processor slot 0.
	standby R0	Standby instance of the configuration in Route-processor slot 0.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

### Examples

The following example shows how to see the details of SI interferers of type microwave oven in the 2.4-GHz band:

```
Device# show ap dot11 24ghz SI device type mw_oven chassis 1 R0
```

# show ap dot11 5ghz

To display the 5GHz RRM parameters, use the **show ap dot11 5ghz** command.

**show ap dot11 5ghz** {**ccx** | **channel** | **coverage** | **group** | **l2roam** | **logging** | **monitor** | **profile** | **receiver** | **summary** | **txpower**}

## Syntax Description

<b>ccx</b>	Displays the 802.11a CCX information for all Cisco APs.
<b>channel</b>	Displays the configuration and statistics of the 802.11a channel assignment.
<b>coverage</b>	Displays the configuration and statistics of the 802.11a coverage.
<b>group</b>	Displays the configuration and statistics of the 802.11a grouping.
<b>l2roam</b>	Displays 802.11a l2roam information.
<b>logging</b>	Displays the configuration and statistics of the 802.11a event logging.
<b>monitor</b>	Displays the configuration and statistics of the 802.11a monitoring.
<b>profile</b>	Displays 802.11a profiling information for all Cisco APs.
<b>receiver</b>	Displays the configuration and statistics of the 802.11a receiver.
<b>summary</b>	Displays the configuration and statistics of the 802.11a Cisco APs.
<b>txpower</b>	Displays the configuration and statistics of the 802.11a transmit power control.

## Command Default

None.

## Command Modes

Global configuration.

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Usage Guidelines

None.

This example shows configuration and statistics of 802.11a channel assignment.

```
Device#show ap dot11 5ghz channel
```

```
Automatic Channel Assignment
Channel Assignment Mode           : AUTO
Channel Update Interval          : 12 Hours
Anchor time (Hour of the day)    : 20
Channel Update Contribution      : SNI..
Channel Assignment Leader        : web (9.9.9.2)
Last Run                         : 16534 seconds ago
DCA Sensitivity Level            : MEDIUM (15 dB)
DCA 802.11n Channel Width       : 40 Mhz
```

```
Channel Energy Levels
  Minimum           : unknown
  Average           : unknown
  Maximum           : unknown
Channel Dwell Times
  Minimum           : unknown
  Average           : unknown
  Maximum           : unknown
802.11a 5 GHz Auto-RF Channel List
Allowed Channel List      : 36,40,44,48,52,56,60,64,149,153,1
                           57,161
Unused Channel List      : 100,104,108,112,116,132,136,140,1
                           65
802.11a 4.9 GHz Auto-RF Channel List
Allowed Channel List      :
Unused Channel List      : 1,2,3,4,5,6,7,8,9,10,11,12,13,14,
                           15,16,17,18,19,20,21,22,23,24,25,26
DCA Outdoor AP option    : Disabled
```

# show ap dot11 24ghz cleanair air-quality

To display the air-quality summary information and air-quality worst information for the 802.11 networks, use the **show ap dot11 cleanair** command.

**show ap dot11** {24ghz | 5ghz | dual-band} cleanair {air-quality | config | device | summary}

Syntax Description		
<b>24ghz</b>	Displays the 2.4 GHz band.	
<b>5ghz</b>	Displays the 5 GHz band.	
<b>dual-band</b>	Displays 802.11 dual-band radios.	
<b>cleanair</b>	Displays cleanair configurations.	
<b>air-quality</b>	Displays the Cleanair Air-Quality (AQ) data for 2.4GHz band.	
<b>device</b>	Displays the CleanAir Interferers of device for 2.4GHz band.	
<b>config</b>	Displays CleanAir Configuration for 2.4GHz band.	
<b>summary</b>	Displays cleanair configurations for all 802.11a Cisco APs.	

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display the worst air-quality information for the 5 GHz band:

```
Device# show ap dot11 5ghz cleanair air-quality worst
```

```
AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
-----
CISCO_AP3500 36      95      70      0          40
```

This example shows how to display the worst air-quality information for the 2.4 GHz band:

```
Device# show ap dot11 24ghz cleanair air-quality worst
```

```
AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
-----
CISCO_AP3500 1        83      57      3          5
```

## show ap dot11 24ghz cleanair air-quality

To display the air-quality summary information and air-quality worst information for the 802.11 networks, use the **show ap dot11 cleanair air-quality** command.

```
show ap dot11 {24ghz | 5ghz} cleanair air-quality {summary | worst}
```

Syntax Description	24ghz	Displays the 2.4 GHz band.
	5ghz	Displays the 5 GHz band.
	summary	Displays a summary of 802.11 radio band air-quality information.
	worst	Displays the worst air-quality information for 802.11 networks.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display the worst air-quality information for the 5 GHz band:

```
Device# show ap dot11 5ghz cleanair air-quality worst
```

```
AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
-----
CISCO_AP3500 36      95      70      0          40
```

This example shows how to display the worst air-quality information for the 2.4 GHz band:

```
Device# show ap dot11 24ghz cleanair air-quality worst
```

```
AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel Avg AQ Min AQ Interferers DFS
-----
CISCO_AP3500 1       83      57      3          5
```

# show ap dot11 cleanair config

To display the CleanAir configuration for the 802.11 networks, use the **show ap dot11 cleanair config** command.

**show ap dot11 {24ghz | 5ghz} cleanair config**

Syntax Description	
<b>24ghz</b>	Displays the 2.4 GHz band.
<b>5ghz</b>	Displays the 5 GHz band.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display the CleanAir configuration for the 2.4 GHz band:

```
Device# show ap dot11 24ghz cleanair config
Clean Air Solution..... : Disabled
Air Quality Settings:
  Air Quality Reporting..... : Disabled
  Air Quality Reporting Period (min)..... : 15
  Air Quality Alarms..... : Enabled
  Air Quality Alarm Threshold..... : 10
Interference Device Settings:
  Interference Device Reporting..... : Enabled
  Bluetooth Link..... : Enabled
  Microwave Oven..... : Enabled
  802.11 FH..... : Enabled
  Bluetooth Discovery..... : Enabled
  TDD Transmitter..... : Enabled
  Jammer..... : Enabled
  Continuous Transmitter..... : Enabled
  DECT-like Phone..... : Enabled
  Video Camera..... : Enabled
  802.15.4..... : Enabled
  WiFi Inverted..... : Enabled
  WiFi Invalid Channel..... : Enabled
  SuperAG..... : Enabled
  Canopy..... : Enabled
  Microsoft Device..... : Enabled
  WiMax Mobile..... : Enabled
  WiMax Fixed..... : Enabled
Interference Device Types Triggering Alarms:
  Bluetooth Link..... : Disabled
  Microwave Oven..... : Disabled
  802.11 FH..... : Disabled
  Bluetooth Discovery..... : Disabled
  TDD Transmitter..... : Disabled
  Jammer..... : Disabled
  Continuous Transmitter..... : Disabled
  DECT-like Phone..... : Disabled
```

```
Video Camera..... : Disabled
802.15.4..... : Disabled
WiFi Inverted..... : Enabled
WiFi Invalid Channel..... : Enabled
SuperAG..... : Disabled
Canopy..... : Disabled
Microsoft Device..... : Disabled
WiMax Mobile..... : Disabled
WiMax Fixed..... : Disabled
Interference Device Alarms..... : Enabled
Additional Clean Air Settings:
CleanAir Event-driven RRM State..... : Disabled
CleanAir Driven RRM Sensitivity..... : LOW
CleanAir Persistent Devices state..... : Disabled
```

## show ap dot11 cleanair summary

To view CleanAir configurations for all 802.11a Cisco APs, use the **show ap dot11 cleanair summary** command.

**show ap dot11 {24ghz | 5ghz} cleanair summary**

<b>Syntax Description</b>	<b>24ghz</b>	Specifies the 2.4-GHz band
	<b>5ghz</b>	Specifies the 5-GHz band
	<b>cleanair summary</b>	Summary of CleanAir configurations for all 802.11a Cisco APs
<b>Command Default</b>	None	
<b>Command Modes</b>	Any command mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
		This command was introduced.



# show ap dot11 dual-band summary

To view a brief summary of access points with dual-band radios, use the **show ap dot11 dual-band summary** command.

**show ap dot11 dual-band summary**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC				
<b>Command History</b>	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE Gibraltar 16.12.1</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE Gibraltar 16.12.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.				

## Example

The following example shows how to view brief summary of tag names:

```
Device# show ap dot11 dual-band summary
```

# show ap environment

To see the AP environment information of all APs, use the **show ap environment** command.

**show ap environment** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

## Syntax Description

*chassis-number* Enter the chassis number as either 1 or 2.

**active R0** Active instance of the AP filters in Route-processor slot 0.

**standby R0** Standby instance of the AP filters in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the AP environment information:

```
Device# show ap environment
```

# show ap filters active

To see the details of active AP filters, use the **show ap filters active** command.

```
show ap filters active [chassis {chassis-number | active | standby} R0]
```

## Syntax Description

*chassis-number* Chassis number as either 1 or 2.

**active R0** Active instance of the active AP filters in Route-processor slot 0.

**standby R0** Standby instance of the active AP filters in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the details of the active AP filters for the active instance:

```
Device# show ap filters active chassis active R0
```

# show ap filters all

To see the details of all AP filters, use the **show ap filters all** command.

**show ap filters all** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

## Syntax Description

*chassis-number* Enter the chassis number as either 1 or 2.

**active R0** Active instance of the AP filters in Route-processor slot 0.

**standby R0** Standby instance of the AP filters in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the details of all the AP filters for the active instance:

```
Device# show ap filters all chassis active R0
```

# show ap fra

To see the flexible radio assignment (FRA) configurations in APs, use the **show ap fra** command.

```
show ap fra [chassis {chassis-number | active | standby} R0]
```

## Syntax Description

*chassis-number* Chassis number as either 1 or 2.

**active R0** Active instance in Route-processor slot 0.

**standby R0** Standby instance in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the FRA configurations in APs:

```
Device# show ap fra
```

# show ap gps location

To see the GPS location of all APs, use the **show ap gps location** command.

**show ap gps location** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

## Syntax Description

*chassis-number* Enter the chassis number as either 1 or 2.

**active R0** Active instance of the AP filters in Route-processor slot 0.

**standby R0** Standby instance of the AP filters in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the GPS location of all APs:

```
Device# show ap gps location
```

# show ap group hyperlocation

To view a summary or detailed information of Hyperlocation configuration for an AP group, use the **show ap group *ap-group-name* hyperlocation** command.

**show ap group hyperlocation** { **summary** | **detail** }

Syntax Description	summary	Shows the overall configuration values (AP group specific) and operational status and parameters for the AP group.
	<b>detail</b>	Shows both overall (AP group specific) and per-AP configuration values and operational status for the AP group. The APs listed are only those that belong to the AP group.
Command Modes	User EXEC Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

This example shows how to view a summary of Hyperlocation configuration for an AP group:

```
Device# show ap group my-ap-group hyperlocation summary

Site Name: my-ap-group
Site Description: This is an AP group
Hyperlocation operational status: Up
Reason: N/A
Hyperlocation NTP server: 9.0.0.4
Hyperlocation admin status: Enabled
Hyperlocation detection threshold: -100 dBm
Hyperlocation trigger threshold: 11
Hyperlocation reset threshold: 9
```



**Note** For Hyperlocation to be operational, the following conditions must be met:

- At least one Cisco CMX with Hyperlocation enabled
- Hyperlocation admin state operational
- Either AP NTP or IOS NTP configured

This example shows how to view detailed information about Hyperlocation configuration for an AP group:

```
Device# show ap group my-ap-group hyperlocation detail
```

```
Site Name: my-ap-group  
Site Description: This is an AP group  
Hyperlocation operational status: Up  
Reason: N/A  
Hyperlocation NTP server: 9.0.0.4  
Hyperlocation admin status: Enabled  
Hyperlocation detection threshold: -100 dBm  
Hyperlocation trigger threshold: 11  
Hyperlocation reset threshold: 9
```

```
Values for APs in all AP Groups:
```

AP Name	Radio MAC	Method	Hyperlocation
APf07f.0635.2d40	f07f.0676.3b89	WSM	Enabled
APf4cf.e272.4ed0	f4cf.e223.ba31	Local	Enabled



# show history channel interface dot11Radio all

To check channel change or trigger reason and history, use the **show history channel interface dot11Radio all** command.

**show history channel interface dot11Radio all**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Amsterdam 17.2.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Amsterdam 17.2.1	This command was introduced.
Release	Modification				
Cisco IOS XE Amsterdam 17.2.1	This command was introduced.				

## Examples

This example shows how to check channel change or trigger reason and history:

```
Device# show history channel interface dot11Radio all

          Timestamp Slot Client count Channel Trigger
Fri May 31 12:57:04 2019    0         0      11 RRM-DCA
Fri May 31 13:10:02 2019    0         0       1 RRM-DCA
Fri May 31 12:57:04 2019    1         0      60 Manual
Fri May 31 13:00:16 2019    1         0     149   DFS
```

# show ap hyperlocation

To view a summary or detailed information about the hyperlocation configuration, use the **show ap hyperlocation** command.

**show ap hyperlocation** {**summary** | **detail**}

Syntax Description	summary	Shows the overall configuration and operational values.
	<b>detail</b>	Shows the overall configuration and operation values as well as detailed information about each AP.

**Command Default** None

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.
	Cisco IOS XE Denali 16.3.1	This command was modified. The <b>ble-beacon</b> keyword was added.

## Usage Guidelines

For hyperlocation to be operational, the following conditions must be met:

- At least one Cisco Connected Mobile Experiences (CMX) must be present with hyperlocation enabled.
- The hyperlocation admin state should be operational.
- Either AP Network Time Protocol (NTP) or IOS NTP should be configured.

## Example

This example shows how to view a summary of the hyperlocation configuration:

```
Device# show ap hyperlocation summary

Hyperlocation operational status: Up
Hyperlocation NTP server currently used: 9.0.0.4
Hyperlocation admin status: Enabled
Hyperlocation detection threshold: -100 dBm
Hyperlocation trigger threshold: 10
Hyperlocation reset threshold: 8
```

This example shows how to view detailed information about hyperlocation configuration:

```
Device# show ap hyperlocation detail

Hyperlocation operational status: Up
Hyperlocation NTP server currently used: 9.0.0.4
Hyperlocation admin status: Enabled
Hyperlocation detection threshold: -100 dBm
Hyperlocation trigger threshold: 10
Hyperlocation reset threshold: 8
```

AP Name	Radio MAC	Method	Hyperlocation
AP84b8.0252.b930	84b8.0216.c721	HALO	Enabled
AP84b8.0265.5540	84b8.0243.8796	WSM	Enabled
APf07f.0635.2d40	f07f.0676.3b89	WSM	Enabled
APf4cf.e272.4ed0	f4cf.e223.ba31	HALO	Enabled

## show ap hyperlocation cmx summary

To see a summary of CMX information with Hyperlocation enabled, use the **show ap hyperlocation cmx summary** command.

**show ap hyperlocation cmx summary** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

### Syntax Description

*chassis-number* Enter the chassis number as either 1 or 2.

**active R0** Active instance of the AP filters in Route-processor slot 0.

**standby R0** Standby instance of the AP filters in Route-processor slot 0.

### Command Default

None

### Command Modes

Privileged EXEC

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

### Examples

The following example shows how to see a summary of CMX information with Hyperlocation enabled:

```
Device# show ap hyperlocation cmx summary
```

# show ap image

To display the images present on Cisco lightweight access points, use the **show ap image** command.

**show ap image**

<b>Syntax Description</b>	This command has no keywords and arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Any command mode				
<b>Command History</b>	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE Gibraltar 16.10.1</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.				

This example shows how to display images on the access points:

```
Device# show ap image
```

# show ap image file summary

To see the summary of an access point's (AP) software install files, use the **show ap image file summary** command.

## show ap image file summary

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.11.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.				

## Example

The following example shows how to display the summary of an AP's software install files:

```
Device# show ap image file summary

AP Image Active List
=====
Install File Name: base_image.bin
-----
AP Image Type           Capwap Version
-----
    ap1g1                16.11.1.19
    ap1g2                16.11.1.19
    ap1g3                16.11.1.19
    ap1g4                16.11.1.19
    ap1g5                16.11.1.19
    ap1g6                16.11.1.19

AP Image Prepare List**
=====
Install File Name: base_image.bin
-----
AP Image Type           Capwap Version
-----
    ap1g1                16.11.1.19
    ap1g2                16.11.1.19
    ap1g3                16.11.1.19
    ap1g4                16.11.1.19
```

```
ap1g5          16.11.1.19
ap1g6          16.11.1.19
```

\*\*Difference of Active and Prepare list gives images being predownloaded to Access Points.

# show ap image site summary

To see the summary of an access point's (AP) site-filtered upgrades, use the **show ap image site summary** command.

## show ap image site summary

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Example

The following example shows how to display the summary of an AP's site-filtered upgrades:

```
Device# show ap image site summary
```

```
Image name: smul.bin
```

Site Tag	Prepared	Activated	Committed
BGL18	yes	ongoing	no
BGL17	yes	ongoing	no



# show ap link-encryption

To display the link encryption status, use the **show ap link-encryption** command.

```
show ap link-encryption [{chassis | {chassis-number | active | standby} | R0}]
```

Syntax Description	
<i>chassis-number</i>	Chassis number as either 1 or 2.
<b>active R0</b>	Active instance in Route-processor slot 0.
<b>standby R0</b>	Standby instance in Route-processor slot 0.

Command Default	None
-----------------	------

Command Modes	Any command mode
---------------	------------------

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example show how to display the link-encryption status:

```
Device# show Cisco IOS XE Gibraltar 16.12.2s link-encryption
```

# show ap master list

To see the AP master list, use the **show ap master list** command.

```
show ap master list[{chassis | {chassis-number | active | standby} | R0}]
```

## Syntax Description

<i>chassis-number</i>	Chassis number as either 1 or 2.
<b>active R0</b>	Active instance in Route-processor slot 0.
<b>standby R0</b>	Standby instance in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the AP master list:

```
Device# show ap master list
```

# show ap mesh cac access

To view the number of active calls on access radio for a given AP and its Mesh tree, use **show ap mesh cac access** command.

**show ap** *ap-name* **mesh cac access**

<b>Syntax Description</b>	<i>ap-name</i> Name of the access point.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Usage Guidelines

### Example

This example shows how to display the number of active calls on access radio for a given AP and its Mesh tree:

Device# **show ap <ap-name> mesh cac access**

Depth	AP Name	Slot	Radio	BW Used	Call
0	AALUKKAL-1562-RAP	0	802.11b/g	0	0
		1	802.11a	0	0
1	AP380E.4DBF.C6B0	0	802.11b/g	1072	2
		1	802.11a	0	0

# show ap mesh cac bwused voice

To view the voice bandwidth utilization of a given AP and its Mesh tree, use the **show ap mesh cac bwused voice** command.

**show ap** *ap-name* **mesh cac bwused voice**

Syntax Description	
<i>ap-name</i>	Name of the access point.

Command Default	
	None

Command Modes	
	Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Usage Guidelines

### Example

This example shows how to display the voice bandwidth utilization of a given AP and its Mesh tree:

```
Device# show ap <ap-name> mesh cac bwused voice
```

Depth	AP Name	Slot	Radio	BW Used
1	APA023.9FA9.D920	0	802.11b/g	1140
		1	802.11a	0
2	AP380E.4DBF.C80C	0	802.11b/g	570
		1	802.11a	2144
2	AP380E.4DBF.C816	0	802.11b/g	0
		1	802.11a	0
2	APA023.9FA9.B702	0	802.11b/g	0
		1	802.11a	0

# show ap mesh cac callpath

To view the number of active calls in access as well as backhaul for a given AP and its Mesh tree, use the **show ap mesh cac callpath** command.

**show ap** *ap-name* **mesh cac callpath**

## Syntax Description

*ap-name* Name of the access point.

## Command Default

None

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Usage Guidelines

### Example

This example shows how to display the number of active calls in access as well as backhaul for a given AP and its Mesh tree:

```
Device# show ap <ap-name> mesh cac callpath
```

Depth	AP Name	Slot	Radio	Call
1	APA023.9FA9.D920	0	802.11b/g	2
		1	802.11a	0
2	AP380E.4DBF.C80C	0	802.11b/g	0
		1	802.11a	2
2	AP380E.4DBF.C816	0	802.11b/g	0
		1	802.11a	0
2	APA023.9FA9.B702	0	802.11b/g	0
		1	802.11a	0

# show ap mesh cac rejected

To view the number of rejected calls on access as well as backhaul for a given AP and its Mesh tree, use **show ap mesh cac rejected** command.

**show ap** *ap-name* **mesh cac rejected**

<b>Syntax Description</b>	<i>ap-name</i> Name of the access point.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Usage Guidelines

### Example

This example shows how to display the number of rejected calls on access as well as backhaul for a given AP and its Mesh tree:

```
Device# show ap <ap-name> mesh cac rejected
```

# show ap monitor-mode summary

To display the current channel-optimized monitor mode settings, use the **show ap monitor-mode summary** command.

**show ap monitor-mode summary**

<b>Syntax Description</b>	This command has no keywords and arguments.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display current channel-optimized monitor mode settings:

```
Device# show ap monitor-mode summary
```

```
AP Name Ethernet MAC      Status  Scanning Channel List
-----
AP_004  xx:xx:xx:xx:xx:xx Tracking 1,6,11, 4
```

## show ap multicast mom (multicast over multicast)

To verify the multicast mode on the controller, use the **show ap multicast mom** command.

<b>Syntax Description</b>	This command has no keywords and arguments.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Amsterdam 17.2	This command was introduced.

This example shows how to verify the multicast mode:

```
Device# show ap multicast mom
```

AP Name	MOM-IP	TYPE	MOM-	STATUS
SS-E-1	IPv4		Up	
SS-E-2	IPv4		Up	
9130E-r3-sw2-g1012	IPv4		Up	
9115i-r3-sw2-te1-0-38	IPv4		Up	
AP9120-r3-sw3-Gi1-0-46	IPv4		Up	
ap3800i-r2-sw1-te2-0-2	IPv4		Up	



# show ap name auto-rf

To display the auto-RF settings for a Cisco lightweight access point, use the **show ap name auto-rf** command.

```
show ap name ap-name auto-rf dot11 {24ghz | 5ghz | dual-band}
```

Syntax Description	<i>ap-name</i>	Name of the Cisco lightweight access point.
	<b>24ghz</b>	Displays the 2.4 GHz band.
	<b>5ghz</b>	Displays the 5 GHz band.
	<b>dual-band</b>	Displays dual band.
Command Default	None	
Command Modes	Privileged EXEC.	
Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display auto-RF information for an access point:

```
Device# show ap name AP01 auto-rf dot11 24ghz

Number of Slots                : 2
AP Name                        : TSIM_AP-1
MAC Address                    : 0000.2000.02f0
Slot ID                        : 0
Radio Type                     : 802.11b/g
Subband Type                   : All

Noise Information
  Noise Profile                 : Failed
  Channel 1                    : 24 dBm
  Channel 2                    : 48 dBm
  Channel 3                    : 72 dBm
  Channel 4                    : 96 dBm
  Channel 5                    : 120 dBm
  Channel 6                    : -112 dBm
  Channel 7                    : -88 dBm
  Channel 8                    : -64 dBm
  Channel 9                    : -40 dBm
  Channel 10                   : -16 dBm
  Channel 11                   : 8 dBm

Interference Information
  Interference Profile          : Passed
  Channel 1                    : -128 dBm @ 0% busy
  Channel 2                    : -71 dBm @ 1% busy
  Channel 3                    : -72 dBm @ 1% busy
  Channel 4                    : -73 dBm @ 2% busy
  Channel 5                    : -74 dBm @ 3% busy
  Channel 6                    : -75 dBm @ 4% busy
  Channel 7                    : -76 dBm @ 5% busy
```

## show ap name auto-rf

```

Channel 8 : -77 dBm @ 5% busy
Channel 9 : -78 dBm @ 6% busy
Channel 10 : -79 dBm @ 7% busy
Channel 11 : -80 dBm @ 8% busy

Rogue Histogram (20/40_ABOVE/40_BELOW)
Channel 36 : 27/ 4/ 0
Channel 40 : 13/ 0/ 0
Channel 44 : 5/ 0/ 0
Channel 48 : 6/ 0/ 1
Channel 52 : 4/ 0/ 0
Channel 56 : 5/ 0/ 0
Channel 60 : 1/ 3/ 0
Channel 64 : 3/ 0/ 0
Channel 100 : 0/ 0/ 0
Channel 104 : 0/ 0/ 0
Channel 108 : 0/ 1/ 0

Load Information
Load Profile : Passed
Receive Utilization : 10%
Transmit Utilization : 20%
Channel Utilization : 50%
Attached Clients : 0 clients

Coverage Information
Coverage Profile : Passed
Failed Clients : 0 clients

Client Signal Strengths
RSSI -100 dBm : 0 clients
RSSI -92 dBm : 0 clients
RSSI -84 dBm : 0 clients
RSSI -76 dBm : 0 clients
RSSI -68 dBm : 0 clients
RSSI -60 dBm : 0 clients
RSSI -52 dBm : 0 clients

Client Signal to Noise Ratios
SNR 0 dB : 0 clients
SNR 5 dB : 0 clients
SNR 10 dB : 0 clients
SNR 15 dB : 0 clients
SNR 20 dB : 0 clients
SNR 25 dB : 0 clients
SNR 30 dB : 0 clients
SNR 35 dB : 0 clients
SNR 40 dB : 0 clients
SNR 45 dB : 0 clients

Nearby APs
AP 0000.2000.0300 slot 0 : -68 dBm on 11 (10.10.10.1)
AP 0000.2000.0400 slot 0 : -68 dBm on 11 (10.10.10.1)
AP 0000.2000.0600 slot 0 : -68 dBm on 11 (10.10.10.1)

Radar Information

Channel Assignment Information
Current Channel Average Energy : 0 dBm
Previous Channel Average Energy : 0 dBm
Channel Change Count : 0
Last Channel Change Time : Wed Oct 17 08:13:36 2012
Recommended Best Channel : 11

```

```
RF Parameter Recommendations
  Power Level                : 1
  RTS/CTS Threshold          : 2347
  Fragmentation Threshold    : 2346
  Antenna Pattern            : 0

Persistent Interference Devices
```

# show ap name ble detail

To display BLE management details, use the **show ap name ble detail** command.

**show ap name** *ap-name* **ble detail**

<b>Syntax Description</b>	<i>ap-name</i> Specifies the name of the AP.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Amsterdam 17.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Amsterdam 17.3.1	This command was introduced.
Release	Modification				
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.				
<b>Usage Guidelines</b>	None				

## Example

The following example shows how to display the BLE management details:

```
Device(config)# show ap name ap-name ble detail
```

## show ap name cablemodem

To see cable modem information of an AP, use the **show ap name *ap-name* cablemodem** command.

```
show ap name ap-name cablemodem [chassis {chassis-number | active | standby} R0]
```

### Syntax Description

<i>ap-name</i>	Name of the AP.
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the AP filters in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the AP filters in Route-processor slot 0.

### Command Default

None

### Command Modes

Privileged EXEC

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

### Examples

The following example shows how to see cable modem information of an AP:

```
Device# show ap name my-ap cablemodem
```

# show ap name config

To display common information and Ethernet VLAN tagging information for a specific Cisco lightweight access point, use the **show ap name config** command.

```
show ap name ap-name config {ethernet | general}
```

Syntax Description					
<b>ap-name</b>	Name of the Cisco lightweight access point.				
<b>ethernet</b>	Displays Ethernet tagging configuration information for an access point.				
<b>general</b>	Displays common information for an access point.				
Command Default	None				
Command Modes	Any command mode				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.10.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.				

This example shows how to display Ethernet tagging information for an access point:

```
Device# show ap name AP01 config ethernet
```

```
VLAN Tagging Information for AP01
```

This example shows how to display common information for an access point:

```
Device# show ap name AP01 config general
```

```
Cisco AP Name : AP01
Cisco AP Identifier : 5
Country Code : US - United States
Regulatory Domain Allowed by Country : 802.11bg:-A 802.11a:-A
AP Country Code : US - United States
AP Regulatory Domain : Unconfigured
Switch Port Number : Tel1/0/1
MAC Address : 0000.2000.02f0
IP Address Configuration : Static IP assigned
IP Address : 10.10.10.12
IP Netmask : 255.255.0.0
Gateway IP Address : 10.10.10.1
Fallback IP Address Being Used : 10.10.10.12
Domain : Cisco
Name Server : 0.0.0.0
CAPWAP Path MTU : 1485
Telnet State : Enabled
SSH State : Disabled
Cisco AP Location : sanjose
Cisco AP Group Name : default-group
Primary Cisco Controller Name : CAPWAP Controller
Primary Cisco Controller IP Address : 10.10.10.1
Secondary Cisco Controller Name :
Secondary Cisco Controller IP Address : Not Configured
```

```
Tertiary Cisco Controller Name           :
Tertiary Cisco Controller IP Address    : Not Configured
Administrative State                     : Enabled
Operation State                          : Registered
AP Mode                                  : Local
AP Submode                               : Not Configured
Remote AP Debug                          : Disabled
Logging Trap Severity Level             : informational
Software Version                         : 7.4.0.5
Boot Version                             : 7.4.0.5
Stats Reporting Period                   : 180
LED State                                : Enabled
PoE Pre-Standard Switch                  : Disabled
PoE Power Injector MAC Address           : Disabled
Power Type/Mode                          : Power Injector/Normal Mode
Number of Slots                          : 2
AP Model                                  : 1140AG
AP Image                                  : C1140-K9W8-M
IOS Version                               :
Reset Button                             :
AP Serial Number                         : SIM1140K001
AP Certificate Type                      : Manufacture Installed
Management Frame Protection Validation    : Disabled
AP User Mode                             : Customized
AP User Name                             : cisco
AP 802.1X User Mode                      : Not Configured
AP 802.1X User Name                      : Not Configured
Cisco AP System Logging Host             : 255.255.255.255
AP Up Time                               : 15 days 16 hours 19 minutes 57
seconds
AP CAPWAP Up Time                       : 4 minutes 56 seconds
Join Date and Time                       : 10/18/2012 04:48:56
Join Taken Time                          : 15 days 16 hours 15 minutes 0
seconds
Join Priority                             : 1
Ethernet Port Duplex                     : Auto
Ethernet Port Speed                      : Auto
AP Link Latency                          : Disabled
Rogue Detection                          : Disabled
AP TCP MSS Adjust                        : Disabled
AP TCP MSS Size                          : 6146
```

# show ap name config ethernet

To see Ethernet related configuration information of an AP, use the **show ap name *ap-name* config ethernet** command.

**show ap name *ap-name* config ethernet** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description	
<i>ap-name</i>	Name of the AP.
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the AP filters in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the AP filters in Route-processor slot 0.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see Ethernet related configuration information of an AP:

```
Device# show ap name my-ap config ethernet
```



# show ap name dot11

To display 802.11a or 802.11b configuration information that corresponds to specific Cisco lightweight access points, use the **show ap name dot11** command.

```
show ap name ap-name dot11 {24ghz | 5ghz} {ccx | cdp | profile | service-policy output | stats | tsm
{allclient-mac}}
```

Syntax	Description
<i>ap-name</i>	Name of the Cisco lightweight access point.
<b>24ghz</b>	Displays the 2.4 GHz band.
<b>5ghz</b>	Displays the 5 GHz band.
<b>ccx</b>	Displays the Cisco Client eXtensions (CCX) radio management status information.
<b>cdp</b>	Displays Cisco Discovery Protocol (CDP) information.
<b>profile</b>	Displays configuration and statistics of 802.11 profiling.
<b>service-policy output</b>	Displays downstream service policy information.
<b>stats</b>	Displays Cisco lightweight access point statistics.
<b>tsm</b>	Displays 802.11 traffic stream metrics statistics.
<b>all</b>	Displays the list of all access points to which the client has associations.
<i>client-mac</i>	MAC address of the client.
<b>SI</b>	Displays the SI configurations.
<b>airtime-fairness</b>	Displays the stats of 24Ghz or 5Ghz airtime-fairness.
<b>call-control</b>	Displays the call control information.
<b>radio-reset</b>	Displays radio-reset.
<b>slot</b>	Displays slot information.
<b>voice</b>	Displays voice information.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display the service policy that is associated with the access point:

```
Device# show ap name test-ap dot11 24ghz service-policy output
```

```
Policy Name : test-ap1
Policy State : Installed
```

This example shows how to display the CCX RRM 802.11 configuration for a specific access point:

```
Device# show ap name AP01 dot11 24ghz ccx
```

This example show how to display CDP information for a specific access point:

```
Device# show ap name AP01 dot11 24ghz cdp
```

```
AP Name                AP CDP State
-----
AP03                   Disabled
```

This example show how to display the configuration and statistics of 802.11b profiling for a specific access point:

```
Device# show ap name AP01 dot11 24ghz profile
```

```
802.11b Cisco AP performance profile mode      : GLOBAL
802.11b Cisco AP Interference threshold       : 10 %
802.11b Cisco AP noise threshold              : -70 dBm
802.11b Cisco AP RF utilization threshold      : 80 %
802.11b Cisco AP throughput threshold         : 1000000 bps
802.11b Cisco AP clients threshold            : 12 clients
```

This example show how to display downstream service policy information for a specific access point:

```
Device# show ap name AP01 dot11 24ghz service-policy output
```

```
Policy Name : def-11gn
Policy State : Installed
```

This example show how to display statistics for a specific access point:

```
Device# show ap name AP01 dot11 24ghz stats
```

```
Number of Users.....: 0
TxFragmentCount.....: 0
MulticastTxFrameCnt.....: 0
FailedCount.....: 0
RetryCount.....: 0
MultipleRetryCount.....: 0
FrameDuplicateCount.....: 0
RtsSuccessCount.....: 0
RtsFailureCount.....: 0
AckFailureCount.....: 0
RxIncompleteFragment.....: 0
MulticastRxFrameCnt.....: 0
FcsErrorCount.....: 0
TxFrameCount.....: 0
WepUndecryptableCount.....: 0
TxFramesDropped.....: 0

Call Admission Control (CAC) Stats
  Voice Bandwidth in use(% of config bw).....: 0
  Video Bandwidth in use(% of config bw).....: 0
```

```

Total BW in use for Voice(%).....: 0
Total BW in use for SIP Preferred call(%).....: 0

Load based Voice Call Stats
Total channel MT free.....: 0
Total voice MT free.....: 0
Na Direct.....: 0
Na Roam.....: 0

WMM TSPEC CAC Call Stats
Total num of voice calls in progress.....: 0
Num of roaming voice calls in progress.....: 0
Total Num of voice calls since AP joined.....: 0
Total Num of roaming calls since AP joined.....: 0
Total Num of exp bw requests received.....: 0
Total Num of exp bw requests admitted.....: 0
Num of voice calls rejected since AP joined.....: 0
Num of roam calls rejected since AP joined.....: 0
Num of calls rejected due to insufficient bw....: 0
Num of calls rejected due to invalid params....: 0
Num of calls rejected due to PHY rate.....: 0
Num of calls rejected due to QoS policy.....: 0

SIP CAC Call Stats
Total Num of calls in progress.....: 0
Num of roaming calls in progress.....: 0
Total Num of calls since AP joined.....: 0
Total Num of roaming calls since AP joined.....: 0
Total Num of Preferred calls received.....: 0
Total Num of Preferred calls accepted.....: 0
Total Num of ongoing Preferred calls.....: 0
Total Num of calls rejected(Insuff BW).....: 0
Total Num of roam calls rejected(Insuff BW)....: 0

Band Select Stats
Num of dual band client .....: 0
Num of dual band client added.....: 0
Num of dual band client expired .....: 0
Num of dual band client replaced.....: 0
Num of dual band client detected .....: 0
Num of suppressed client .....: 0
Num of suppressed client expired.....: 0
Num of suppressed client replaced.....: 0

```

This example show how to display the traffic stream configuration for all clients that correspond to a specific access point:

```
Device# show ap name AP01 dot11 24ghz tsm all
```

# show ap name environment

To see the AP environment information of an AP, use the **show ap name *ap-name* environment** command.

**show ap name *ap-name* environment [chassis {*chassis-number* | active | standby} R0]**

## Syntax Description

<i>ap-name</i>	Name of the AP.
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the AP filters in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the AP filters in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the AP environment information of an AP:

```
Device# show ap name my-ap environment
```

# show ap name gps location

To see the GPS location of the AP, use the **show ap name gps location** command.

```
show ap name ap-name gps location [ {chassis-number | active | standby} R0
```

## Syntax Description

<i>ap-name</i>	Name of the Access Point
<b>gps</b>	See the GPS information of a Cisco AP
<b>location</b>	Shows the Mesh linktest data
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the active AP filters in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the configuration in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the GPS location of an AP:

```
Device# show ap name mesh-profile-name gps location
```

# show ap name hyperlocation

To view a summary or detailed information about the hyperlocation configuration for an access point (AP), use the **show ap name hyperlocation** command.

**show ap name *ap-name* hyperlocation ble-beacon**

Syntax Description		
	<i>ap-name</i>	Access point name.
	<b>hyperlocation</b>	Displays AP hyperlocation information.
	<b>ble-beacon</b>	Displays BLE beacon configuration of an AP.
Command Modes	Privileged EXEC (#)	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

## Example

This example shows how to view the BLE beacon configuration of an AP:

```
Device# show ap name test-ap hyperlocation ble-beacon
```

```
ID Major Minor TX Power (dBm)
-----
0 0 0 0
1 0 0 0
2 0 0 0
3 0 0 0
```

# show ap name mesh backhaul

To see mesh backhaul statistics of an AP, use the **show ap name *ap-name* mesh backhaul** command.

**show ap name *ap-name* mesh backhaul** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

## Syntax Description

*chassis-number* Enter the chassis number as either 1 or 2.

**active R0** Active instance of the AP filters in Route-processor slot 0.

**standby R0** Standby instance of the AP filters in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see mesh backhaul statistics of an AP:

```
Device# show ap name mymeshap mesh backhaul
```

## show ap name mesh bhrate

To see mesh backhaul data rate for an AP, use the **show ap name *ap-name* mesh bhrate** command.

**show ap name *ap-name* mesh bhrate** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

<i>ap-name</i>	Name of the AP.
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the AP filters in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the AP filters in Route-processor slot 0.

**Command Default** None

**Command Modes** Privileged EXEC

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

### Examples

The following example shows how to see mesh backhaul data rate for an AP:

```
Device# show ap name mymeshap mesh bhrate
```



# show ap name mesh linktest

To see the mesh linktest data, use the **show ap name mesh linktest data** command.

**show ap name** *ap-name* **mesh linktest data** *dest-mac* [**chassis** {*chassis-number* | **active** | **standby**}**R0**]

Syntax Description	
<i>ap-name</i>	Name of the Access Point
<b>linktest</b>	Shows the Mesh linktest
<b>data</b>	Shows the Mesh linktest data
<i>dest-mac</i>	Enter the AP MAC address.
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the configuration in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the configuration in Route-processor slot 0.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the mesh linktest data of an AP:

```
Device# show ap name mesh-profile-name mesh linktest data 83-88-15-0C-83-72
```

# show ap name mesh neighbor detail

To see detailed information about a neighbor of a mesh AP, use the **show ap name *ap-name* mesh neighbor detail** command.

**show ap name *ap-name* mesh neighbor detail** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description	
<i>ap-name</i>	Name of the AP.
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the AP filters in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the AP filters in Route-processor slot 0.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see detailed information about a neighbor of a mesh AP:

```
Device# show ap name mymeshap mesh neighbor detail
```

## show ap name mesh path

To see information about the mesh AP's path, use the **show ap name *ap-name* mesh path** command.

**show ap name *ap-name* mesh path** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

### Syntax Description

*chassis-number* Enter the chassis number as either 1 or 2.

**active R0** Active instance of the AP filters in Route-processor slot 0.

**standby R0** Standby instance of the AP filters in Route-processor slot 0.

### Command Default

None

### Command Modes

Privileged EXEC

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

### Examples

The following example shows how to see information about the mesh AP's path:

```
Device# show ap name mymeshap mesh path
```

# show ap name mesh stats

To see mesh statistics, use the **show ap name *ap-name* mesh stats** command.

```
show ap name ap-name [{packet error | queue | security}]
```

Syntax Description	
<i>ap-name</i>	Name of the AP.
<b>packet error</b>	Mesh packet error statistics.
<b>queue</b>	Mesh queue statistics.
<b>security</b>	Mesh security statistics.
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the AP filters in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the AP filters in Route-processor slot 0.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see mesh statistics:

```
Device# show ap name mymeshap mesh stats
```

## show ap name tunnel eogre events

To display the Ethernet over GRE (EoGRE) events on an AP, use the **show ap name tunnel eogre events** command.

**show ap name** *ap-name* **tunnel eogre events**

<b>Syntax Description</b>	<i>ap-name</i> AP name.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.11.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.				

### Example

This example shows how to display the EoGRE tunnel events on an AP:

```
Device# show ap name ap1 tunnel eogre events
```

```
AP 80e8.6fd4.9520 Event history
Timestamp          #Times  Event                               RC Context
-----
02/18/2019 23:50:26.341 6      IAPP_STATS                          0 GW Tunnel2 uptime:0s
02/18/2019 23:49:40.222 2      CLIENT_JOIN                          0 74da.3828.88b0, (eogre_domain/2121)
02/18/2019 23:48:43.549 1      CLIENT_LEAVE                         0 74da.3828.88b0, (eogre_domain/2121)
02/18/2019 23:47:33.127 1      DOMAIN_STATUS                       0 eogre_domain Active GW: Tunnel1
02/18/2019 23:47:33.124 4      AP_TUNNEL_STATUS                    0 Tunnel2 Dn
02/18/2019 23:47:33.124 1      MSG_CLIENT_DEL                      0 GW Tunnel2 (IP: 9.51.1.12)
02/18/2019 23:47:33.124 2      TUNNEL_ADD                          0 GW Tunnel2
02/18/2019 23:47:33.120 3      MSG_CLIENT_DEL_PD                   0 GW Tunnel1 (IP: 9.51.1.11)
02/18/2019 23:47:31.763 2      AP_DOMAIN_PUSH                      0 Delete:eogre_domain_set, 0 GWs
02/18/2019 23:47:31.753 4      AP_VAP_PUSH                          0 profile:'eogre_tunnel',
wlan:pyats_eogre
```

# show ap name tunnel eogre domain detailed

To display the detailed information of the Ethernet over GRE (EoGRE) tunnel domain status on an AP, use the **show ap name tunnel eogre domain detailed** command.

**show ap name** *ap-name* **tunnel eogre domain detailed** *domain-name*

Syntax Description		
	<i>ap-name</i>	AP name.
	<i>domain-name</i>	EoGRE domain name.

**Command Default** None

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Example

This example shows how to display the detailed information of the EoGRE tunnel domain status on an AP:

```
Device# show ap name ap1 tunnel eogre domain detailed eogre_domain
```

```
Domain Name      : eogre_domain
Primary GW       : Tunnel1
Secondary GW     : Tunnel2
Active GW        : Tunnel1
Redundancy       : Non-Revertive
AdminState       : Up
```

# show ap name tunnel eogre domain summary

To display the summary information of the Ethernet over GRE (EoGRE) tunnel domain on an AP, use the **show ap name tunnel eogre domain summary** command.

**show ap name** *ap-name* **tunnel eogre domain summary**

<b>Syntax Description</b>	<i>ap-name</i> AP name.
<b>Command Default</b>	None
<b>Command Modes</b>	Privileged EXEC (#)
<b>Command History</b>	<b>Release</b>
	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1 This command was introduced.

## Example

This example shows how to display the summary information of the EoGRE tunnel domain on an AP:

```
Device# show ap name ap1 tunnel eogre domain summary
```

```
AP MAC           Domain           Active Gateway
-----
80e8.6fd4.9520  eogre_domain
```

# show ap name tunnel eogre gateway detailed

To display the detailed information of the Ethernet over GRE (EoGRE) tunnel gateway status on an AP, use the **show ap name tunnel eogre gateway detailed** command.

**show ap name** *ap-name* **tunnel eogre gateway detailed** *gateway-name*

Syntax Description		
	<i>ap-name</i>	AP name.
	<i>gateway-name</i>	EoGRE gateway name.

**Command Default** None

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Example

This example shows how to display the detailed information of the EoGRE tunnel gateway status on an AP:

```
Device# show ap name ap1 tunnel eogre gateway detailed Tunnel2
```

```
Gateway : Tunnel2
Mode    : IPv4
IP      : 9.51.1.12
State   : Down
MTU     : 0
AP MAC  : 80e8.6fd4.9520

Clients
Total Number of Wireless Clients      : 0
Traffic
Total Number of Received Packets     : 0
Total Number of Received Bytes       : 0
Total Number of Transmitted Packets   : 0
Total Number of Transmitted Bytes     : 0
Total Number of Lost Keepalive       : 151
```



# show ap name tunnel eogre gateway summary

To display the summary information of the Ethernet over GRE (EoGRE) tunnel gateway on an AP, use the **show ap name tunnel eogre gateway summary** command.

**show ap name** *ap-name* **tunnel eogre gateway summary**

<b>Syntax Description</b>	<i>ap-name</i> AP name.
---------------------------	-------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Example

This example shows how to display the summary information of the EoGRE tunnel gateway on an AP:

```
Device# show ap name ap1 tunnel eogre gateway summary
```

AP MAC	Gateway	Type	IP	State	Clients
80e8.6fd4.9520	Tunnel1	IPv4	9.51.1.11	Up	1
80e8.6fd4.9520	Tunnel2	IPv4	9.51.1.12	Down	0

# show ap name wlan

To display the Basic Service Set Identifier (BSSID) value for each WLAN defined on an access point and to display WLAN statistics, use the **show ap name wlan** command.

```
show ap name ap-name wlan {dot11 {24ghz | 5ghz} | statistic}
```

Syntax Description	
<i>ap-name</i>	Name of the Cisco lightweight access point.
<b>dot11</b>	Displays 802.11 parameters.
<b>24ghz</b>	Displays 802.11b network settings.
<b>5ghz</b>	Displays 802.11a network settings.
<b>statistic</b>	Displays WLAN statistics.

**Command Default** None

**Command Modes** Any command mode

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display BSSID information of an access point in an 802.11b network:

```
Device# show ap name AP01 wlan dot11 24ghz

Site Name                : default-group
Site Description         :

WLAN ID  Interface  BSSID
-----
1        default    00:00:20:00:02:00
12       default    00:00:20:00:02:0b
```

This example shows how to display WLAN statistics for an access point:

```
Device# show ap name AP01 wlan statistic

WLAN ID : 1
WLAN Profile Name : maria-open

EAP Id Request Msg Timeouts : 0
EAP Id Request Msg Timeouts Failures : 0
EAP Request Msg Timeouts : 0
EAP Request Msg Timeouts Failures : 0
EAP Key Msg Timeouts : 0
EAP Key Msg Timeouts Failures : 0

WLAN ID : 12
WLAN Profile Name : 24
```

```
EAP Id Request Msg Timeouts          : 0
EAP Id Request Msg Timeouts Failures : 0
EAP Request Msg Timeouts              : 0
EAP Request Msg Timeouts Failures     : 0
EAP Key Msg Timeouts                  : 0
EAP Key Msg Timeouts Failures         : 0
```

# show ap name ble detail

To view the CMX associated with an AP, use the **show ap name ble detail** command.

**show ap name** *ap-name* **ble detail**

<b>Syntax Description</b>	<i>ap-name</i> Specifies the name of the AP.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Usage Guidelines

This example shows how to display the global values for BLE and BLE details for a specific AP:

```
Device# show ap name AP4001.7AB2.C39A ble detail
CMX IP: 9.9.71.100
```

```
-----
BLE administrative status: Up
BLE operational status: Up
Scanning interval: 10
```

AP Name	Interface	Status
AP4001.7AB2.C39A	Integrated	Open

# show ap profile

To see overall status of Hyperlocation for an AP profile, use the **show ap profile** command.

```
show ap profile profile-name {detailed | hyperlocation {ble-beacon | detail | summary}} [chassis
{chassis-number | active | standby} R0]
```

## Syntax Description

<i>profile-name</i>	AP profile name.
<b>detailed</b>	Shows the detailed parameters of the AP join profile.
<b>hyperlocation</b>	Shows Hyperlocation information for the AP profile.
<b>ble-beacon</b>	Show the list of configured BLE beacons for the AP profile.
<b>detail</b>	Shows detailed status of Hyperlocation for the AP profile.
<b>summary</b>	Shows overall status of Hyperlocation for the AP profile
<i>chassis-number</i>	Chassis number as either 1 or 2.
<b>active R0</b>	Active instance in Route-processor slot 0.
<b>standby R0</b>	Standby instance in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the overall status of Hyperlocation for an AP profile:

```
Device# show ap profile my-ap-profile detailed
```

# show ap rf-profile name

To display the selected ap RF-Profile details, use the **show ap rf-profile name** command.

**show ap rf-profile name** *profile-name* **detail**

Syntax Description		
	<i>profile-name</i>	Name of the RF-Profile.
	<b>detail</b>	Show detail of selected RF Profile.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

**Usage Guidelines** None

This example shows how to display the details of the selected RF-Profile.

```

Device#show ap rf-profile name doctest detail
Description :
AP Group Names :
RF Profile Name : doctest
Band : 2.4 GHz
802.11n client only : Disabled
Transmit Power Threshold v1: -70 dBm
Min Transmit Power: -10 dBm
Max Transmit Power: 30 dBm
Operational Rates
 802.11b 1M Rate : Mandatory
 802.11b 2M Rate : Mandatory
 802.11b 5.5M Rate : Mandatory
 802.11b 11M Rate : Mandatory
 802.11b 6M Rate : Mandatory
 802.11b 9M Rate : Supported
 802.11b 12M Rate : Supported
 802.11b 18M Rate : Supported
 802.11b 24M Rate : Supported
 802.11b 36M Rate : Supported
 802.11b 48M Rate : Supported
 802.11b 54M Rate : Supported
Max Clients : 200
Wlan name                               Max Clients
-----
Trap Threshold
  Clients: 12 clients
  Interference: 10%
  Noise: -70 dBm
  Utilization: 80%
Multicast Data Rate: auto
Rx SOP Threshold : auto
Band Select

```

```
Probe Response: Disabled
Cycle Count: 2 cycles
Cycle Threshold: 200 milliseconds
Expire Suppression: 20 seconds
Expire Dual Band: 60 seconds
Client RSSI: -80 dBm
Client Mid RSSI: -80 dBm
Load Balancing
Window: 5 clients
Denial: 3 count
Coverage Data
Data: -80 dBm
Voice: -80 dBm
Minimum Client Level: 3 clients
Exception Level: 25%
DCA Channel List : 1,5,9,13
DCA Foreign AP Contribution : Enabled
802.11n MCS Rates
MCS 0 : Enabled
MCS 1 : Enabled
MCS 2 : Enabled
MCS 3 : Enabled
MCS 4 : Enabled
MCS 5 : Enabled
MCS 6 : Enabled
MCS 7 : Enabled
MCS 8 : Enabled
MCS 9 : Enabled
MCS 10 : Enabled
MCS 11 : Enabled
MCS 12 : Enabled
MCS 13 : Enabled
MCS 14 : Enabled
MCS 15 : Enabled
MCS 16 : Enabled
MCS 17 : Enabled
MCS 18 : Enabled
MCS 19 : Enabled
MCS 20 : Enabled
MCS 21 : Enabled
MCS 22 : Enabled
MCS 23 : Enabled
MCS 24 : Enabled
MCS 25 : Enabled
MCS 26 : Enabled
MCS 27 : Enabled
MCS 28 : Enabled
MCS 29 : Enabled
MCS 30 : Enabled
MCS 31 : Enabled
State : Down
```

# show ap rf-profile summary

To display the ap RF-Profile summary, use the **show ap rf-profile summary** command.

## show ap rf-profile summary

<b>Syntax Description</b>	<b>summary</b>	Show summary of RF Profiles
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Denali 16.3.1	This command was introduced.
<b>Usage Guidelines</b>	None	

This example shows how to display the ap RF-Profile summary .

```
Device#show ap rf-profile summary
```

```
Number of RF Profiles : 1
```

RF Profile Name	Band	Description	Applied	State
doctest	2.4 GHz		No	Down



# show ap summary

To display the status summary of all Cisco lightweight access points attached to the device, use the **show ap summary** command.

**show ap summary**

<b>Syntax Description</b>	This command has no keywords and arguments.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Any command mode
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

<b>Usage Guidelines</b>	Use this command to display a list that contains each lightweight access point name, number of slots, manufacturer, MAC address, location, and the device port number.
-------------------------	--

This example shows how to display a summary of all connected access points:

```
Controller# show ap summary
```

```
Number of APs: 1
```

```
Global AP User Name: Cisco
```

```
Global AP Dot1x User Name: Not configured
```

AP Name	AP Model	Ethernet MAC	Radio MAC	State
3602a	3502I	003a.99eb.3fa8	d0c2.8267.8b00	Registered

# show ap summary sort ascending client-count

To view the AP summary sorted ascendingly based on the client count, use the **show ap summary sort ascending client-count** command.

**show ap summary sort ascending client-count**

---

**Syntax Description** This command has no keywords or arguments.

---



---

**Command Default** None

---



---

**Command Modes** Privileged EXEC

---



---

Command History	Release	Modification
	Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

---

This example shows how to view the AP summary sorted ascendingly based on the client count:

Device# **show ap summary sort ascending client-count**

AP-name	Through-Put	Admin-State	AP-mac	Client count	Data Usage
L2_3802I_1	11	Enabled	7872.5d27.b8c0	1	622358
L2_1815w_1	1422	Enabled	707d.b99e.c2e0	2	5871836

# show ap summary sort ascending data-usage

To view the AP summary sorted ascendingly based on the data usage, use the **show ap summary sort ascending data-usage** command.

**show ap summary sort ascending data-usage**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the AP summary sorted ascendingly based on the data usage:

Device# **show ap summary sort ascending data-usage**

AP-name	Through-Put	Admin-State	AP-mac	Client count	Data Usage
L2_3802I_1	4	Enabled	7872.5d27.b8c0	1	622600
L2_1815w_1	281	Enabled	707d.b99e.c2e0	2	6102216

# show ap summary sort ascending throughput

To view the AP summary sorted ascendingly based on the throughput, use the **show ap summary sort ascending throughput** command.

**show ap summary sort ascending throughput**

---

**Syntax Description** This command has no keywords or arguments.

---



---

**Command Default** None

---

**Command Modes** Privileged EXEC

---

Command History	Release	Modification
	Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

---

This example shows how to view the AP summary sorted ascendingly based on the throughput:

Device# **show ap summary sort ascending throughput**

AP-name	Through-Put	Admin-State	AP-mac	Client count	Data Usage
L2_3802I_1	6	Enabled	7872.5d27.b8c0	1	6749385
L2_1815w_1	35	Enabled	707d.b99e.c2e0	2	94748042

# show ap summary sort descending client-count

To view the AP summary sorted descendingly based on the client count, use the **show ap summary sort descending client-count** command.

**show ap summary sort descending client-count**

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the AP summary sorted descendingly based on the client count:

Device# **show ap summary sort descending client-count**

AP-name	Through-Put	Admin-State	AP-mac	Client count	Data Usage
L2_1815w_1			707d.b99e.c2e0	2	94753989
46		Enabled			
L2_3802I_1			7872.5d27.b8c0	1	6750526
6		Enabled			

# show ap summary sort descending data-usage

To view the AP summary sorted descendingly based on the data usage, use the **show ap summary sort descending data-usage** command.

**show ap summary sort descending data-usage**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the AP summary sorted descendingly based on the data usage:

Device# **show ap summary sort descending data-usage**

AP-name	Through-Put	Admin-State	AP-mac	Client count	Data Usage
L2_1815w_1	47	Enabled	707d.b99e.c2e0	2	94756618
L2_3802I_1	6	Enabled	7872.5d27.b8c0	0	6750526

# show ap summary sort descending throughput

To view the AP summary sorted descendingly based on the throughput, use the **show ap summary sort descending throughput** command.

**show ap summary sort descending throughput**

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the AP summary sorted descendingly based on the throughput:

Device# **show ap summary sort descending throughput**

AP-name	Through-Put	Admin-State	AP-mac	Client count	Data Usage
L2_1815w_1	23	Enabled	707d.b99e.c2e0	2	94758750
L2_3802I_1	6	Enabled	7872.5d27.b8c0	0	6750526

## show ap tag sources

To see AP tag sources with priorities, use the **show ap tag sources** command.

**show ap tag sources** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

### Syntax Description

*chassis-number* Chassis number as either 1 or 2.

**active R0** Active instance of the AP filters in Route-processor slot 0.

**standby R0** Standby instance of the AP filters in Route-processor slot 0.

### Command Default

None

### Command Modes

Privileged EXEC

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

### Examples

The following example shows how to see the AP tag sources with priorities for the active instance:

```
Device# show ap tag sources chassis active R0
```



# show ap tag summary

To view brief summary of tag names, use the **show ap tag summary** command.

**show ap tag summary**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC				
<b>Command History</b>	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE Gibraltar 16.10.1</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.				

## Example

The following example shows how to view brief summary of tag names:

```
Device# show ap tag summary
```

# show ap upgrade

To see AP upgrade information, use the **show ap upgrade** command.

**show ap upgrade** [{**name** *ap-upgrade-report-name* | **summary** | **chassis** {*chassis-number* | **active** | **standby**}]

## Syntax Description

<b>name</b> <i>ap-upgrade-report-name</i>	Enter the name of the AP upgrade report.
<b>summary</b>	Shows a summary of AP upgrade information.
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
<b>active R0</b>	Active instance in Route-processor slot 0.
<b>standby R0</b>	Standby instance in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see a summary of the AP upgrade information:

```
Device# show ap upgrade summary
```

# show arp

To view the ARP table, use the **show arp** command.

## show arp

<b>Syntax Description</b>	<b>arp</b> Shows ARP table
<b>Command Modes</b>	User EXEC (>) Privileged EXEC (#)
<b>Command History</b>	<b>Release</b> <b>Modification</b>
	8.1.111.0 This command was introduced.

The following example shows a sample output of the command:

```
cisco-wave2-ap# show arp

Address Age (min)      Hardware Addr
 9.11.8.1             0 84:80:2D:A0:D2:E6
9.11.32.111           0 3C:77:E6:02:33:3F
```

# show arp summary

To see the ARP table summary, use the **show arp summary** command.

```
show arp summary
```

---

**Command Default**

None

---

**Command Modes**

Privileged EXEC

---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

---

## Examples

The following example shows how to see the ARP table summary:

```
Device# show arp summary
```

# show ap tunnel eogre events

To display the Ethernet over GRE (EoGRE) tunnel events, use the **show ap tunnel eogre events** command.

## show ap tunnel eogre events

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.11.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.				

## Example

This example shows how to display the EoGRE tunnel events:

```
Device# show ap tunnel eogre events
```

```
AP 80e8.6fd4.9520  Event history
Timestamp          #Times  Event                               RC Context
-----
02/18/2019 23:50:26.341 6      IAPP_STATS                          0 GW Tunnel2 uptime:0s
02/18/2019 23:49:40.222 2      CLIENT_JOIN                          0 74da.3828.88b0, (eogre_domain/2121)
02/18/2019 23:48:43.549 1      CLIENT_LEAVE                         0 74da.3828.88b0, (eogre_domain/2121)
02/18/2019 23:47:33.127 1      DOMAIN_STATUS                       0 eogre_domain Active GW: Tunnel1
02/18/2019 23:47:33.124 4      AP_TUNNEL_STATUS                    0 Tunnel2 Dn
02/18/2019 23:47:33.124 1      MSG_CLIENT_DEL                      0 GW Tunnel2 (IP: 9.51.1.12)
02/18/2019 23:47:33.124 2      TUNNEL_ADD                          0 GW Tunnel2
02/18/2019 23:47:33.120 3      MSG_CLIENT_DEL_PD                   0 GW Tunnel1 (IP: 9.51.1.11)
02/18/2019 23:47:31.763 2      AP_DOMAIN_PUSH                      0 Delete:eogre_domain_set, 0 GWs
02/18/2019 23:47:31.753 4      AP_VAP_PUSH                         0 profile:'eogre_tunnel',
wlan:pyats_eogre
```

# show ap tunnel eogre domain detailed

To display the detailed information of the Ethernet over GRE (EoGRE) tunnel domain status on an AP, use the **show ap tunnel eogre domain detailed** command.

**show ap tunnel eogre domain detailed** *domain-name*

<b>Syntax Description</b>	<i>domain-name</i> EoGRE domain name.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.11.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.				

## Example

This example shows how to display the detailed information of the EoGRE tunnel domain status:

```
Device# show ap tunnel eogre domain detailed Tunnell
```

```
Gateway : Tunnell
Mode    : IPv4
IP      : 9.51.1.11
State   : Up
MTU     : 1476
Up Time: 14 hours 25 minutes 2 seconds
AP MAC  : 80e8.6fd4.9520

Clients
  Total Number of Wireless Clients      : 1
Traffic
  Total Number of Received Packets      : 6
  Total Number of Received Bytes        : 2643
  Total Number of Transmitted Packets    : 94
  Total Number of Transmitted Bytes      : 20629
  Total Number of Lost Keepalive        : 3
```

# show ap name tunnel eogre domain summary

To display the summary information of the Ethernet over GRE (EoGRE) tunnel domain on an AP, use the **show ap name tunnel eogre domain summary** command.

**show ap name** *ap-name* **tunnel eogre domain summary**

<b>Syntax Description</b>	<i>ap-name</i> AP name.
<b>Command Default</b>	None
<b>Command Modes</b>	Privileged EXEC (#)
<b>Command History</b>	<b>Release</b>
	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1 This command was introduced.

## Example

This example shows how to display the summary information of the EoGRE tunnel domain on an AP:

```
Device# show ap name ap1 tunnel eogre domain summary
```

```
AP MAC           Domain           Active Gateway
-----
80e8.6fd4.9520  eogre_domain    Tunnel1
```

# show ap tunnel eogre gateway detailed

To display the detailed information of the Ethernet over GRE (EoGRE) tunnel gateway status on an AP, use the **show ap name tunnel eogre gateway detailed** command.

**show ap name** *ap-name* **tunnel eogre gateway detailed** *gateway-name*

<b>Syntax Description</b>	<i>ap-name</i>	AP name.
	<i>gateway-name</i>	EoGRE domain name.
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Example

This example shows how to display the detailed information of the EoGRE tunnel gateway status on an AP:

```
Device# show ap name ap1 tunnel eogre gateway detailed Tunnell
```

```
Gateway : Tunnell
Mode    : IPv4
IP      : 9.51.1.11
State   : Up
MTU     : 1476
Up Time: 14 hours 25 minutes 2 seconds
AP MAC  : 80e8.6fd4.9520

Clients
  Total Number of Wireless Clients      : 1
Traffic
  Total Number of Received Packets     : 6
  Total Number of Received Bytes       : 2643
  Total Number of Transmitted Packets  : 94
  Total Number of Transmitted Bytes    : 20629
  Total Number of Lost Keepalive       : 3
```



# show ap tunnel eogre gateway summary

To display the summary information of the Ethernet over GRE (EoGRE) tunnel gateway, use the **show ap tunnel eogre gateway summary** command.

**show ap tunnel eogre gateway summary**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.11.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.				

## Example

This example shows how to display the summary information of the EoGRE tunnel gateway:

```
Device# show ap tunnel eogre gateway summary
```

AP MAC	Gateway	Type	IP	State	Clients
80e8.6fd4.9520	Tunnel1	IPv4	9.51.1.11	Up	1
80e8.6fd4.9520	Tunnel2	IPv4	9.51.1.12	Down	0

# show avc client

To display information about top number of applications, use the **show avc client** command in privileged EXEC mode.

**show avc client** *client-mac* **top n application** [**aggregate** | **upstream** | **downstream**]

## Syntax Description

**client** *client-mac* Specifies the client MAC address.

**top n application** Specifies the number of top "N" applications for the given client.

## Command Default

No default behavior or values.

## Command Modes

Privileged EXEC

## Command History

### Release

### Modification

Cisco IOS XE Gibraltar 16.10.1 This command was introduced.

The following is sample output from the **show avc client** command:

```
Device# sh avc client 0040.96ae.65ec top 10 application aggregate
```

Cumulative Stats:

No.	AppName	Packet-Count	Byte-Count	AvgPkt-Size	usage%
1	skinny	7343	449860	61	94
2	unknown	99	13631	137	3
3	dhcp	18	8752	486	2
4	http	18	3264	181	1
5	tftp	9	534	59	0
6	dns	2	224	112	0

Last Interval(90 seconds) Stats:

No.	AppName	Packet-Count	Byte-Count	AvgPkt-Size	usage%
1	skinny	9	540	60	100

# show avc wlan

To display information about top applications and users using the applications, use the **show avc wlan** command in privileged EXEC mode.

**show avc wlan ssid top n application** [**aggregate** | **upstream** | **downstream**]

<b>Syntax Description</b>	<b>wlan ssid</b> Specifies the Service Set Identifier (SSID) for WLAN.
	<b>top n application</b> Specifies the number of top "N" applications.

**Command Default** No default behavior or values.

**Command Modes** Privileged EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show avc wlan** command:

Device# **show avc wlan Lobby\_WLAN top 10 application aggregate**

Cumulative Stats:

No.	AppName	Packet-Count	Byte-Count	AvgPkt-Size	usage%
1	ssl	10598677	1979525706	997	42
2	vnc	5550900	3764612847	678	14
3	http	3043131	2691327197	884	10
4	unknown	1856297	1140264956	614	4
5	video-over-http	1625019	2063335150	1269	8
6	binary-over-http	1329115	1744190344	1312	6
7	webex-meeting	1146872	540713787	471	2
8	rtp	923900	635650544	688	2
9	unknown	752341	911000213	1210	3
10	youtube	631085	706636186	1119	3

Last Interval (90 seconds) Stats:

No.	AppName	Packet-Count	Byte-Count	AvgPkt-Size	usage%
1	vnc	687093	602731844	877	68
2	video-over-http	213272	279831588	1312	31
3	ssl	6515	5029365	771	1
4	webex-meeting	3649	1722663	472	0
5	http	2634	1334355	506	0
6	unknown	1436	99412	69	0
7	google-services	722	378121	523	0
8	linkedin	655	393263	600	0
9	exchange	432	167390	387	0
10	gtalk-chat	330	17330	52	0

# show chassis

To see the chassis information, use the **show chassis** command.

```
show chassis [{1 | 2} | detail | mode | neighbors | ha-status {active | local | standby}]
```

## Syntax Description

<b>{1   2}</b>	Chassis number as 1 or 2 to see the information about the relevant chassis.
<b>detail</b>	Shows detailed information about the chassis.
<b>mode</b>	Shows information about the chassis mode.
<b>neighbors</b>	Shows information about the chassis neighbors.
<b>ha-status</b>	Option to see information about the High Availability (HA) status.
<b>active</b>	Shows HA status on the chassis that is in active state.
<b>local</b>	Shows HA status on the local chassis.
<b>standby</b>	Shows HA status on the chassis that is in standby state.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the HA status on the active chassis:

```
Device# show chassis ha-status active
```

# show chassis rmi

To verify the chassis Redundancy Management Interface (RMI) configuration for an active controller, use the **show chassis rmi** command.

**show chassis rmi**

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Amsterdam 17.1.1	This command was introduced.

This example shows how to verify the chassis Redundancy Management Interface (RMI) configuration for an active controller:

```
Device# show chassis rmi
Chassis/Stack Mac Address : 000c.2964.1eb6 - Local Mac Address
Mac persistency wait time: Indefinite
H/W Current
Chassis# Role Mac Address Priority Version State IP RMI-IP
-----
*1 Active 000c.2964.1eb6 1 V02 Ready 169.254.90.147 9.10.90.147
2 Standby 000c.2975.3aa6 1 V02 Ready 169.254.90.149 9.10.90.149
```

# show checkpoint

To display information about the Checkpoint Facility (CF) subsystem, use the **show checkpoint** command.

**show checkpoint** { **clients** *client-ID* <0-381> | **entities** *entity-ID* <1-7> | **statistics** **buffer-usage** }

## Syntax Description

<b>clients</b>	Displays detailed information about checkpoint clients.
<b>entities</b>	Displays detailed information about checkpoint entities.
<b>statistics</b>	Displays detailed information about checkpoint statistics.
<b>buffer-usage</b>	Displays the checkpoint statistics of clients using large number of buffers.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display all the CF clients.

```

Client residing in process : 8135
-----
Checkpoint client: WCM_MOBILITY
  Client ID                : 24105
  Total DB inserts         : 0
  Total DB updates         : 0
  Total DB deletes         : 0
  Total DB reads           : 0
  Number of tables         : 6
  Client residing in process : 8135
-----
Checkpoint client: WCM_DOT1X
  Client ID                : 24106
  Total DB inserts         : 2
  Total DB updates         : 1312
  Total DB deletes         : 2
  Total DB reads           : 0
  Number of tables         : 1
  Client residing in process : 8135
-----
Checkpoint client: WCM_APFROGUE
  Client ID                : 24107
  Total DB inserts         : 0
  Total DB updates         : 0
  Total DB deletes         : 0
  Total DB reads           : 0
  Number of tables         : 1
  Client residing in process : 8135
-----
Checkpoint client: WCM_CIDS
  Client ID                : 24110
  Total DB inserts         : 0

```

```
Total DB updates      : 0
Total DB deletes      : 0
Total DB reads        : 0
Number of tables      : 0
Client residing in process : 8135
```

```
-----
Checkpoint client: WCM_NETFLOW
Client ID              : 24111
Total DB inserts       : 7
Total DB updates       : 0
Total DB deletes       : 0
Total DB reads         : 0
Number of tables       : 1
Client residing in process : 8135
```

```
-----
Checkpoint client: WCM_MCAST
Client ID              : 24112
Total DB inserts       : 0
Total DB updates       : 0
Total DB deletes       : 0
Total DB reads         : 0
Number of tables       : 1
Client residing in process : 8135
```

```
-----
Checkpoint client: wcm_comet
Client ID              : 24150
Total DB inserts       : 0
Total DB updates       : 0
Total DB deletes       : 0
Total DB reads         : 0
Number of tables       : 0
Client residing in process : 8135
```

All iosd checkpoint clients

```
-----
Client Name           Client      Entity      Bundle
                    ID           ID           Mode
-----
```

Client Name	Client ID	Entity ID	Bundle Mode
Network RF Client	3	--	Off

```
-----
Total API Messages Sent: 0
Total Transport Messages Sent: 0
Length of Sent Messages: 0
Total Blocked Messages Sent: 0
Length of Sent Blocked Messages: 0
Total Non-blocked Messages Sent: 0
Length of Sent Non-blocked Messages: 0
Total Bytes Allocated: 0
Buffers Held: 0
Buffers Held Peak: 0
Huge Buffers Requested: 0
Transport Frag Count: 0
Transport Frag Peak: 0
Transport Sends w/Flow Off: 0
Send Errs: 0
Send Peer Errs: 0
Rcv Xform Errs: 0
Xmit Xform Errs: 0
Incompatible Messages: 0
Client Unbundles to Process Memory: T
```

```
-----
Client Name           Client      Entity      Bundle
```

## show checkpoint

```

-----
                ID      ID      Mode
-----
SNMP CF Client      12      --      Off

Total API Messages Sent:          0
Total Transport Messages Sent:    0
Length of Sent Messages:          0
Total Blocked Messages Sent:      0
Length of Sent Blocked Messages:  0
Total Non-blocked Messages Sent:  0
Length of Sent Non-blocked Messages: 0
Total Bytes Allocated:            0
Buffers Held:                     0
Buffers Held Peak:                0
Huge Buffers Requested:           0
Transport Frag Count:              0
Transport Frag Peak:              0
Transport Sends w/Flow Off:       0
Send Errs:                        0
Send Peer Errs:                   0
Rcv Xform Errs:                   0
Xmit Xform Errs:                  0
Incompatible Messages:            0
Client Unbundles to Process Memory: T
-----

Client Name      Client  Entity  Bundle
                ID      ID      Mode
-----
Online Diags HA      14      --      Off

Total API Messages Sent:          0
Total Transport Messages Sent:    0
Length of Sent Messages:          0
Total Blocked Messages Sent:      0
Length of Sent Blocked Messages:  0
Total Non-blocked Messages Sent:  0
Length of Sent Non-blocked Messages: 0
Total Bytes Allocated:            0
Buffers Held:                     0
Buffers Held Peak:                0
Huge Buffers Requested:           0
Transport Frag Count:              0
Transport Frag Peak:              0
Transport Sends w/Flow Off:       0
Send Errs:                        0
Send Peer Errs:                   0
Rcv Xform Errs:                   0
Xmit Xform Errs:                  0
Incompatible Messages:            0
Client Unbundles to Process Memory: T
-----

Client Name      Client  Entity  Bundle
                ID      ID      Mode
-----
ARP              22      --      Off

Total API Messages Sent:          0
Total Transport Messages Sent:    0
Length of Sent Messages:          0
Total Blocked Messages Sent:      0
Length of Sent Blocked Messages:  0
Total Non-blocked Messages Sent:  0
Length of Sent Non-blocked Messages: 0
Total Bytes Allocated:            0

```



```

Buffers Held: 0
Buffers Held Peak: 0
Huge Buffers Requested: 0
Transport Frag Count: 0
Transport Frag Peak: 0
Transport Sends w/Flow Off: 0
Send Errs: 0
Send Peer Errs: 0
Rcv Xform Errs: 0
Xmit Xform Errs: 0
Incompatible Messages: 0
Client Unbundles to Process Memory: T
    
```

---

Client Name	Client ID	Entity ID	Bundle Mode
Tableid CF	27	--	Off

---

```

Total API Messages Sent: 0
Total Transport Messages Sent: 0
Length of Sent Messages: 0
Total Blocked Messages Sent: 0
Length of Sent Blocked Messages: 0
Total Non-blocked Messages Sent: 0
Length of Sent Non-blocked Messages: 0
Total Bytes Allocated: 0
Buffers Held: 0
Buffers Held Peak: 0
Huge Buffers Requested: 0
Transport Frag Count: 0
Transport Frag Peak: 0
Transport Sends w/Flow Off: 0
Send Errs: 0
Send Peer Errs: 0
Rcv Xform Errs: 0
Xmit Xform Errs: 0
Incompatible Messages: 0
Client Unbundles to Process Memory: T
    
```

---

Client Name	Client ID	Entity ID	Bundle Mode
Event Manager	33	0	Off

---

```

Total API Messages Sent: 0
Total Transport Messages Sent: --
Length of Sent Messages: 0
Total Blocked Messages Sent: 0
Length of Sent Blocked Messages: 0
Total Non-blocked Messages Sent: 0
Length of Sent Non-blocked Messages: 0
Total Bytes Allocated: 0
Buffers Held: 0
Buffers Held Peak: 0
Huge Buffers Requested: 0
Transport Frag Count: 0
Transport Frag Peak: 0
Transport Sends w/Flow Off: 0
Send Errs: 0
Send Peer Errs: 0
Rcv Xform Errs: 0
Xmit Xform Errs: 0
Incompatible Messages: 0
Client Unbundles to Process Memory: T
    
```

## show checkpoint

```

-----
Client Name          Client      Entity      Bundle
                   ID          ID          Mode
-----
LAN-Switch Port Mana 35          0          Off

Total API Messages Sent:          0
Total Transport Messages Sent:    --
Length of Sent Messages:          0
Total Blocked Messages Sent:      0
Length of Sent Blocked Messages:  0
Total Non-blocked Messages Sent:  0
Length of Sent Non-blocked Messages: 0
Total Bytes Allocated:            0
Buffers Held:                     0
Buffers Held Peak:                0
Huge Buffers Requested:           0
Transport Frag Count:             0
Transport Frag Peak:              0
Transport Sends w/Flow Off:       0
Send Errs:                        0
Send Peer Errs:                  0
Rcv Xform Errs:                  0
Xmit Xform Errs:                  0
Incompatible Messages:            0
Client Unbundles to Process Memory: T
-----

```

```

-----
Client Name          Client      Entity      Bundle
                   ID          ID          Mode
-----
LAN-Switch PAgP/LACP 36          0          Off

Total API Messages Sent:          0
Total Transport Messages Sent:    --
Length of Sent Messages:          0
Total Blocked Messages Sent:      0
Length of Sent Blocked Messages:  0
Total Non-blocked Messages Sent:  0
Length of Sent Non-blocked Messages: 0
Total Bytes Allocated:            0
Buffers Held:                     0
Buffers Held Peak:                0
Huge Buffers Requested:           0
Transport Frag Count:             0
Transport Frag Peak:              0
Transport Sends w/Flow Off:       0
Send Errs:                        0
Send Peer Errs:                  0
Rcv Xform Errs:                  0
Xmit Xform Errs:                  0
Incompatible Messages:            0
Client Unbundles to Process Memory: T
-----

```

```

-----
Client Name          Client      Entity      Bundle
                   ID          ID          Mode
-----
LAN-Switch VLANs    39          0          Off

Total API Messages Sent:          0
Total Transport Messages Sent:    --
Length of Sent Messages:          0
Total Blocked Messages Sent:      0
Length of Sent Blocked Messages:  0
Total Non-blocked Messages Sent:  0
-----

```

```

Length of Sent Non-blocked Messages:      0
Total Bytes Allocated:                    0
Buffers Held:                             0
Buffers Held Peak:                       0
Huge Buffers Requested:                  0
Transport Frag Count:                     0
Transport Frag Peak:                     0
Transport Sends w/Flow Off:               0
Send Errs:                               0
Send Peer Errs:                          0
Rcv Xform Errs:                           0

```

This example shows how to display all the CF entities.

```

KATANA_DOC#show checkpoint entities
                        Check Point List of Entities

```

CHKPT on ACTIVE server.

```

-----
Entity ID      Entity Name
-----
          0      CHKPT_DEFAULT_ENTITY

Total API Messages Sent:      0
Total Messages Sent:         0
Total Sent Message Len:      0
Total Bytes Allocated:       0
Total Number of Members:     10

Member(s) of entity 0 are:
  Client ID      Client Name
-----
          168      DHCP Snooping
          167      IGMP Snooping
           41      Spanning-tree
           40      AUTH MGR CHKPT CLIEN
           39      LAN-Switch VLANs
           33      Event Manager
           35      LAN-Switch Port Mana
           36      LAN-Switch PAGP/LACP
          158      Inline Power Checkpoint

```

This example shows how to display the CF statistics.

```

KATANA_DOC#show checkpoint statistics
                        IOSd Check Point Status
CHKPT on ACTIVE server.

Number Of Msgs In Hold Q:      0
CHKPT MAX Message Size:       0
TP MAX Message Size:          65503
CHKPT Pending Msg Timer:      100 ms

FLOW_ON total:                0
FLOW_OFF total:               0
Current FLOW status is:      ON
Total API Messages Sent:      0
Total Messages Sent:         0
Total Sent Message Len:      0
Total Bytes Allocated:       0
Rcv Msg Q Peak:              0
Hold Msg Q Peak:              0

```

**show checkpoint**

```
Buffers Held Peak:          0
Current Buffers Held:      0
Huge Buffers Requested:    0
```

# show etherchannel summary

To show details on the ports, port-channel, and protocols in the controller, use the **show etherchannel summary** command.

## show ethernet summary

This command has no arguments or keywords.

### Command Default

None

### Command Modes

Privileged Mode.

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows the details on the ports, port-channel, and protocols in the controller.

```
controller#show etherchannel summary
Flags:  D - down          P - bundled in port-channel
        I - stand-alone  s - suspended
        H - Hot-standby (LACP only)
        R - Layer3       S - Layer2
        U - in use       f - failed to allocate aggregator

        M - not in use, minimum links not met
        u - unsuitable for bundling
        w - waiting to be aggregated
        d - default port
```

```
Number of channel-groups in use: 2
Number of aggregators:          2
```

```
Group  Port-channel  Protocol  Ports
-----+-----+-----+-----
2      Po2 (SD)         -         -
23     Po23 (SD)        -         -
```

# show fips authorization-key

To view the installed authorization key, use the **show fips authorization-key** command.

## show fips authorization-key

---

**Command Default**      None

---

**Command Modes**      Privileged EXEC

---

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

---

This example shows how to view the installed authorization key:

```
Device# show fips authorization-key
FIPS: Stored key (16) : 12345678901234567890123456789012
```

# show fips status

To view the status of FIPS on the device, use the **show fips status** command.

**show fips status**

---

**Command Default**

None

---

**Command Modes**

Privileged EXEC

---

**Command History**

<b>Release</b>	<b>Modification</b>
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

---

This example shows how to view the status of FIPS on the device:

```
Device# show fips status  
Chassis is running in fips mode
```

# show flow exporter

To display flow exporter status and statistics, use the **show flow exporter** command in privileged EXEC mode.

```
show flow exporter [{export-ids netflow-v9 | [name] exporter-name [{statistics | templates}]}] statistics | templates}]
```

## Syntax Description

<b>export-ids netflow-v9</b>	(Optional) Displays the NetFlow Version 9 export fields that can be exported and their IDs.
<b>name</b>	(Optional) Specifies the name of a flow exporter.
<i>exporter-name</i>	(Optional) Name of a flow exporter that was previously configured.
<b>statistics</b>	(Optional) Displays statistics for all flow exporters or for the specified flow exporter.
<b>templates</b>	(Optional) Displays template information for all flow exporters or for the specified flow exporter.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following example displays the status and statistics for all of the flow exporters configured on a device:

```
Device# show flow exporter
Flow Exporter FLOW-EXPORTER-1:
  Description:                Exports to the datacenter
  Export protocol:            NetFlow Version 9
  Transport Configuration:
    Destination IP address:    192.168.0.1
    Source IP address:        192.168.0.2
    Transport Protocol:        UDP
    Destination Port:         9995
    Source Port:               55864
    DSCP:                      0x0
    TTL:                       255
    Output Features:           Used
```

This table describes the significant fields shown in the display:

**Table 1: show flow exporter Field Descriptions**

Field	Description
Flow Exporter	The name of the flow exporter that you configured.



Field	Description
Description	The description that you configured for the exporter, or the default description User defined.
Transport Configuration	The transport configuration fields for this exporter.
Destination IP address	The IP address of the destination host.
Source IP address	The source IP address used by the exported packets.
Transport Protocol	The transport layer protocol used by the exported packets.
Destination Port	The destination UDP port to which the exported packets are sent.
Source Port	The source UDP port from which the exported packets are sent.
DSCP	The differentiated services code point (DSCP) value.
TTL	The time-to-live value.
Output Features	Specifies whether the <b>output-features</b> command, which causes the output features to be run on Flexible NetFlow export packets, has been used or not.

The following example displays the status and statistics for all of the flow exporters configured on a device:

```
Device# show flow exporter name FLOW-EXPORTER-1 statistics
Flow Exporter FLOW-EXPORTER-1:
  Packet send statistics (last cleared 2w6d ago):
    Successfully sent:          0                (0 bytes)
```

# show flow interface

To display the configuration and status for an interface, use the **show flow interface** command in privileged EXEC mode.

**show flow interface** [*type number*]

Syntax Description	
<i>type</i>	(Optional) The type of interface on which you want to display accounting configuration information.
<i>number</i>	(Optional) The number of the interface on which you want to display accounting configuration information.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Examples

The following example displays the accounting configuration on Ethernet interfaces 0/0 and 0/1:

```
Device# show flow interface gigabitethernet1/0/1

Interface Ethernet1/0
  monitor:          FLOW-MONITOR-1
  direction:        Output
  traffic(ip):      on
Device# show flow interface gigabitethernet1/0/2
Interface Ethernet0/0
  monitor:          FLOW-MONITOR-1
  direction:        Input
  traffic(ip):      sampler SAMPLER-2#
```

The table below describes the significant fields shown in the display.

**Table 2: show flow interface Field Descriptions**

Field	Description
Interface	The interface to which the information applies.
monitor	The name of the flow monitor that is configured on the interface.
direction:	The direction of traffic that is being monitored by the flow monitor. The possible values are: <ul style="list-style-type: none"> <li>• Input—Traffic is being received by the interface.</li> <li>• Output—Traffic is being transmitted by the interface.</li> </ul>

Field	Description
traffic(ip)	<p>Indicates if the flow monitor is in normal mode or sampler mode.</p> <p>The possible values are:</p> <ul style="list-style-type: none"><li>• on—The flow monitor is in normal mode.</li><li>• sampler—The flow monitor is in sampler mode (the name of the sampler will be included in the display).</li></ul>

# show flow monitor

To display the status and statistics for a flow monitor, use the **show flow monitor** command in privileged EXEC mode.

Syntax Description	name	(Optional) Specifies the name of a flow monitor.
	<i>monitor-name</i>	(Optional) Name of a flow monitor that was previously configured.
	<b>cache</b>	(Optional) Displays the contents of the cache for the flow monitor.
	<b>format</b>	(Optional) Specifies the use of one of the format options for formatting the display output.
	<b>csv</b>	(Optional) Displays the flow monitor cache contents in comma-separated variables (CSV) format.
	<b>record</b>	(Optional) Displays the flow monitor cache contents in record format.
	<b>table</b>	(Optional) Displays the flow monitor cache contents in table format.
	<b>statistics</b>	(Optional) Displays the statistics for the flow monitor.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

**Usage Guidelines** The **cache** keyword uses the record format by default.

The uppercase field names in the display output of the **show flowmonitor monitor-name cache** command are key fields that uses to differentiate flows. The lowercase field names in the display output of the **show flow monitor monitor-name cache** command are nonkey fields from which collects values as additional data for the cache.

## Examples

The following example displays the status for a flow monitor:

```
Device# show flow monitor FLOW-MONITOR-1

Flow Monitor FLOW-MONITOR-1:
  Description:      Used for basic traffic analysis
  Flow Record:     flow-record-1
  Flow Exporter:   flow-exporter-1
                  flow-exporter-2

Cache:
  Type:            normal
  Status:         allocated
  Size:           4096 entries / 311316 bytes
  Inactive Timeout: 15 secs
  Active Timeout: 1800 secs
```

This table describes the significant fields shown in the display.

**Table 3: show flow monitor monitor-name Field Descriptions**

Field	Description
Flow Monitor	Name of the flow monitor that you configured.
Description	Description that you configured or the monitor, or the default description User defined.
Flow Record	Flow record assigned to the flow monitor.
Flow Exporter	Exporters that are assigned to the flow monitor.
Cache	Information about the cache for the flow monitor.
Type	Flow monitor cache type. The value is always normal, as it is the only supported cache type.
Status	Status of the flow monitor cache. The possible values are: <ul style="list-style-type: none"> <li>• allocated—The cache is allocated.</li> <li>• being deleted—The cache is being deleted.</li> <li>• not allocated—The cache is not allocated.</li> </ul>
Size	Current cache size.
Inactive Timeout	Current value for the inactive timeout in seconds.
Active Timeout	Current value for the active timeout in seconds.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1:

This table describes the significant fields shown in the display.

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-1 in a table format:

The following example displays the status, statistics, and data for the flow monitor named FLOW-MONITOR-IPv6 (the cache contains IPv6 data) in record format:

The following example displays the status and statistics for a flow monitor:

# show flow record

To display the status and statistics for a flow record, use the **show flow record** command in privileged EXEC mode.

```
show flow record [{name] record-name}]
```

<b>Syntax Description</b>	<b>name</b> (Optional) Specifies the name of a flow record.
	<i>record-name</i> (Optional) Name of a user-defined flow record that was previously configured.
<b>Command Default</b>	None
<b>Command Modes</b>	Privileged EXEC
<b>Command History</b>	<b>Release</b>
	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1 This command was introduced.

The following example displays the status and statistics for FLOW-RECORD-1:

```
Device# show flow record FLOW-RECORD-1
flow record FLOW-RECORD-1:
  Description:      User defined
  No. of users:    0
  Total field space: 24 bytes
  Fields:
    match ipv6 destination address
    match transport source-port
    collect interface input
```

# show flow record wireless avc basic

To view information about the flow records for wireless avc basic, use the **show flow record wireless avc basic** command.

**show flow record wireless avc basic**

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Example

The following example shows how to see information about the flow records for wireless avc basic:

```
Device# show flow record wireless avc basic

flow record wireless avc basic:
  Description:          Basic Wireless AVC template
  No. of users:        1
  Total field space:   78 bytes
  Fields:
    match ipv4 protocol
    match ipv4 source address
    match ipv4 destination address
    match transport source-port
    match transport destination-port
    match flow direction
    match application name
    match wireless ssid
    collect counter bytes long
    collect counter packets long
    collect wireless ap mac address
    collect wireless client mac address
```

# show flow record wireless avc ipv6 basic

To view information about the flow records for wireless avc ipv6 basic, use the **show flow record wireless avc ipv6 basic** command.

## show flow record wireless avc ipv6 basic

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Example

The following example shows how to see information about the flow records for wireless avc ipv6 basic:

```
Device# show flow record wireless avc ipv6 basic

flow record wireless avc ipv6 basic:
  Description:          Ipv6 Wireless AVC flow template
  No. of users:         1
  Total field space:   102 bytes
  Fields:
    match ipv6 protocol
    match ipv6 source address
    match ipv6 destination address
    match transport source-port
    match transport destination-port
    match flow direction
    match wireless ssid
    collect counter bytes long
    collect counter packets long
    collect application name
    collect wireless ap mac address
    collect wireless client mac address
```



# show interfaces

To display the administrative and operational status of all interfaces or for a specified interface, use the **show interfaces** command in privileged EXEC mode.

```
show interfaces [{interface-id | vlan vlan-id}] [{accounting | capabilities [module number] | debounce
| description | etherchannel | flowcontrol | private-vlan mapping | pruning | stats | status [{err-disabled}]
| trunk}]
```

Syntax	Description
<i>interface-id</i>	(Optional) ID of the interface. Valid interfaces include physical ports (including type, stack member, module, and port number) and port channels. The port channel range is 1 to 48.
<b>vlan</b> <i>vlan-id</i>	(Optional) VLAN identification. The range is 1 to 4094.
<b>accounting</b>	(Optional) Displays accounting information on the interface, including active protocols and input and output packets and octets.  <b>Note</b> The display shows only packets processed in software; hardware-switched packets do not appear.
<b>capabilities</b>	(Optional) Displays the capabilities of all interfaces or the specified interface, including the features and options that you can configure on the interface. Though visible in the command line help, this option is not available for VLAN IDs.
<b>module</b> <i>number</i>	(Optional) Displays capabilities of all interfaces on the switch or specified stack member.  This option is not available if you entered a specific interface ID.
<b>description</b>	(Optional) Displays the administrative status and description set for an interface.
<b>etherchannel</b>	(Optional) Displays interface EtherChannel information.
<b>flowcontrol</b>	(Optional) Displays interface flow control information.
<b>private-vlan mapping</b>	(Optional) Displays private-VLAN mapping information for the VLAN switch virtual interfaces (SVIs). This keyword is not available if the switch is running the LAN base feature set.
<b>pruning</b>	(Optional) Displays trunk VTP pruning information for the interface.
<b>stats</b>	(Optional) Displays the input and output packets by switching the path for the interface.
<b>status</b>	(Optional) Displays the status of the interface. A status of unsupported in the Type field means that a non-Cisco small form-factor pluggable (SFP) module is inserted in the module slot.

<b>err-disabled</b>	(Optional) Displays interfaces in an error-disabled state.
<b>trunk</b>	(Optional) Displays interface trunk information. If you do not specify an interface, only information for active trunking ports appears.



**Note** Though visible in the command-line help strings, the **crb**, **fair-queue**, **irb**, **mac-accounting**, **precedence**, **random-detect**, **rate-limit**, and **shape** keywords are not supported.

**Command Default** None

**Command Modes** Privileged EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

### Usage Guidelines

The **show interfaces capabilities** command with different keywords has these results:

- Use the **show interface capabilities module *number*** command to display the capabilities of all interfaces on that chassis in the stack. If there is no chassis with that module number in the stack, there is no output.
- Use the **show interfaces *interface-id* capabilities** to display the capabilities of the specified interface.
- Use the **show interfaces capabilities** (with no module number or interface ID) to display the capabilities of all interfaces in the stack.

This is an example of output from the **show interfaces** command for an interface on stack member 3:

```
Device# show interfaces gigabitethernet3/0/2
GigabitEthernet3/0/2 is down, line protocol is down (notconnect)
  Hardware is Gigabit Ethernet, address is 2037.064d.4381 (bia 2037.064d.4381)
  MTU 1500 bytes, BW 1000000 Kbit/sec, DLY 10 usec,
    reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation ARPA, loopback not set
  Keepalive set (10 sec)
  Auto-duplex, Auto-speed, media type is 10/100/1000BaseTX
  input flow-control is off, output flow-control is unsupported
  ARP type: ARPA, ARP Timeout 04:00:00
  Last input never, output hang never
  Last clearing of "show interface" counters never
  Input queue: 0/2000/0/0 (size/max/drops/flushes); Total output drops: 0
  Queueing strategy: fifo
  Output queue: 0/40 (size/max)
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes, 0 no buffer
    Received 0 broadcasts (0 multicasts)
    0 runts, 0 giants, 0 throttles
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
    0 watchdog, 0 multicast, 0 pause input
    0 input packets with dribble condition detected
    0 packets output, 0 bytes, 0 underruns
```

```

0 output errors, 0 collisions, 1 interface resets
0 unknown protocol drops
0 babbles, 0 late collision, 0 deferred
0 lost carrier, 0 no carrier, 0 pause output
0 output buffer failures, 0 output buffers swapped out

```

This is an example of output from the **show interfaces interface description** command when the interface has been described as *Connects to Marketing* by using the **description** interface configuration command:

```

Device# show interfaces gigabitethernet1/0/2 description
Interface                Status      Protocol Description
Gi1/0/2                  up         down     Connects to Marketing

```

This is an example of output from the **show interfaces interface-id pruning** command when pruning is enabled in the VTP domain:

```

Device# show interfaces gigabitethernet1/0/2 pruning
Port      Vlans pruned for lack of request by neighbor
Gi1/0/2   3,4

Port      Vlans traffic requested of neighbor
Gi1/0/2   1-3

```

This is an example of output from the **show interfaces stats** command for a specified VLAN interface:

```

Device# show interfaces vlan 1 stats
Switching path  Pkts In   Chars In   Pkts Out   Chars Out
Processor       1165354   136205310  570800     91731594
Route cache     0         0          0          0
Total          1165354   136205310  570800     91731594

```

These are examples of output from the **show interfaces status** command for a specific interface when private VLANs are configured. Port 22 is configured as a private-VLAN host port. It is associated with primary VLAN 20 and secondary VLAN 25:

```

Device# show interfaces gigabitethernet1/0/22 status
Port   Name      Status      Vlan      Duplex  Speed  Type
Gi1/0/22      connected  20,25     a-full   a-100  10/100BaseTX

```

In this example, port 20 is configured as a private-VLAN promiscuous port. The display shows only the primary VLAN 20:

```

Device# show interfaces gigabitethernet1/0/20 status
Port   Name      Status      Vlan      Duplex  Speed  Type
Gi1/0/20      connected  20         a-full   a-100  10/100BaseTX

```

This is an example of output from the **show interfaces status err-disabled** command. It displays the status of interfaces in the error-disabled state:

```

Device# show interfaces status err-disabled
Port   Name      Status      Reason
Gi1/0/2      err-disabled  gbic-invalid
Gi2/0/3      err-disabled  dtp-flap

```

This is an example of output from the **show interfaces interface-id pruning** command:

```
Device# show interfaces gigabitethernet1/0/2 pruning
Port Vlans pruned for lack of request by neighbor
```

```
Device# show interfaces gigabitethernet1/0/1 trunk
Port      Mode      Encapsulation  Status      Native vlan
Gi1/0/1   on        802.1q         other       10

Port      Vlans allowed on trunk
Gi1/0/1   none

Port      Vlans allowed and active in management domain
Gi1/0/1   none

Port      Vlans in spanning tree forwarding state and not pruned
Gi1/0/1   none
```

# show ip

To view the IP information, use the **show ip** command.

Syntax	Description
<b>access-lists</b>	Lists the IP access lists
<b>interface</b>	Displays the IP interface status and configuration
<b>brief</b>	Displays the brief summary of IP status and configuration
<b>route</b>	Displays the IP routing table
<b>tunnel</b>	Displays the IP tunnel information
<b>eogre</b>	Displays the EoGRE tunnel information
<b>domain</b>	Displays the EoGRE tunnel domain information
<b>forwarding-table</b>	Displays the EoGRE tunnel encapsulation and decapsulation information
<b>gateway</b>	Displays the EoGRE tunnel gateway information
<b>fabric</b>	Displays the IP fabric tunnel information
<b>summary</b>	Displays the information for all tunnels

Command Modes
User EXEC (>)
Privileged EXEC (#)

Command History	Release	Modification
	8.1.111.0	This command was introduced.

The following example shows how to view information about the lists the IP access lists:

```
cisco-wave2-ap# show ip access-lists
```

# show ip igmp snooping igmpv2-tracking

To display group and IP address entries, use the **show ip igmp snooping igmpv2-tracking** command in privileged EXEC mode.



**Note** The command displays group and IP address entries only for wireless multicast IGMP joins and not for wired joins. This command also displays output only if wireless multicast is enabled.

## show ip igmp snooping igmpv2-tracking

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

# show ip igmp snooping querier

To display the configuration and operation information for the IGMP querier that is configured on a device, use the **show ip igmp snooping querier** command in user EXEC mode.

```
show ip igmp snooping querier [vlan vlan-id] [detail ]
```

<b>Syntax Description</b>	<b>vlan <i>vlan-id</i></b> (Optional) Specifies a VLAN; Ranges are from 1—1001 and 1006—4094.
	<b>detail</b> (Optional) Displays detailed IGMP querier information.

<b>Command Modes</b>	User EXEC Privileged EXEC
----------------------	------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

**Usage Guidelines** Use the **show ip igmp snooping querier** command to display the IGMP version and the IP address of a detected device, also called a querier, that sends IGMP query messages. A subnet can have multiple multicast routers but only one IGMP querier. In a subnet running IGMPv2, one of the multicast routers is elected as the querier. The querier can be a Layer 3 device.

The **show ip igmp snooping querier** command output also shows the VLAN and the interface on which the querier was detected. If the querier is the device, the output shows the Port field as Router. If the querier is a router, the output shows the port number on which the querier was detected in the Port field.

The **show ip igmp snooping querier detail** user EXEC command is similar to the **show ip igmp snooping querier** command. However, the **show ip igmp snooping querier** command displays only the device IP address most recently detected by the device querier.

The **show ip igmp snooping querier detail** command displays the device IP address most recently detected by the device querier and this additional information:

- The elected IGMP querier in the VLAN
- The configuration and operational information pertaining to the device querier (if any) that is configured in the VLAN

Expressions are case sensitive, for example, if you enter | **exclude output**, the lines that contain "output" do not appear, but the lines that contain "Output" appear.

## Examples

The following is a sample output from the **show ip igmp snooping querier** command:

```
Device> show ip igmp snooping querier
Vlan      IP Address      IGMP Version      Port
-----
1         172.20.50.11    v3                 Gi1/0/1
2         172.20.40.20    v2                 Router
```

The following is a sample output from the **show ip igmp snooping querier detail** command:

```
Device> show ip igmp snooping querier detail

Vlan      IP Address      IGMP Version  Port
-----
1         1.1.1.1        v2           Fa8/0/1
Global IGMP device querier status

-----
admin state           : Enabled
admin version         : 2
source IP address     : 0.0.0.0
query-interval (sec) : 60
max-response-time (sec) : 10
querier-timeout (sec) : 120
tcn query count       : 2
tcn query interval (sec) : 10
Vlan 1:  IGMP device querier status

-----
elected querier is 1.1.1.1      on port Fa8/0/1
-----
admin state           : Enabled
admin version         : 2
source IP address     : 10.1.1.65
query-interval (sec) : 60
max-response-time (sec) : 10
querier-timeout (sec) : 120
tcn query count       : 2
tcn query interval (sec) : 10
operational state     : Non-Querier
operational version   : 2
tcn query pending count : 0
```



# show ip igmp snooping wireless mcast-spi-count

To display the statistics of the number of multicast stateful packet inspections (SPIs) per multicast group ID (MGID) sent to the device, use the **show ip igmp snooping wireless mcast-spi-count** command in privileged EXEC mode.

**show ip igmp snooping wireless mcast-spi-count**

This command has no arguments or keywords.

---

**Command Default**

None

---

**Command Modes**

Privileged EXEC

---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

---

**Usage Guidelines**

None

## Examples

This is an example of output from the **show ip igmp snooping wireless mcast-spi-count** command:

```
Device# show ip igmp snooping wireless mcast-spi-count

Stats for Mcast Client Add/Delete SPI Messages Sent to WCM

MGID      ADD MSGs      Del MSGs
-----
4160      1323          667
```

# show ip igmp snooping wireless mgid

To display multicast group ID (MGID) mappings, use the **show ip igmp snooping wireless mgid** command in privileged EXEC mode.

**show ip igmp snooping wireless mgid**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

**Usage Guidelines** None

## Examples

This is an example of output from the **show ip igmp snooping wireless mgid** command:

```
Device# show ip igmp snooping wireless mgid

Total number of L2-MGIDs      = 0

Total number of MCAST MGIDs = 0

Wireless multicast is Enabled in the system
Vlan    bcast    nonip-mcast    mcast    mgid    Stdbby Flags
1       Disabled  Disabled      Enabled   Disabled 0:0:1:0
25      Disabled  Disabled      Enabled   Disabled 0:0:1:0
34      Disabled  Disabled      Enabled   Disabled 0:0:1:0
200     Disabled  Disabled      Enabled   Disabled 0:0:1:0
1002    Enabled   Enabled       Enabled   Disabled 0:0:1:0
1003    Enabled   Enabled       Enabled   Disabled 0:0:1:0
1004    Enabled   Enabled       Enabled   Disabled 0:0:1:0
1005    Enabled   Enabled       Enabled   Disabled 0:0:1:0

Index  MGID                               (S, G, V)
-----
```

# show ip nbar protocol-discovery wlan

To see NBAR protocol discovery statistics for a WLAN, use the **show ip nbar protocol-discovery wlan** command.

```
show ip nbar protocol-discovery wlan wlan-name
```

<b>Syntax Description</b>	<i>wlan-name</i>	Name of the WLAN.
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the NBAR protocol discovery statistics for a WLAN named *mywlan*:

```
Device# show ip nbar protocol-discovery wlan mywlan
```

## show ipv6 access-list

To display the contents of all current IPv6 access lists, use the **show ipv6 access-list** command in user EXEC or privileged EXEC mode.

**show ipv6 access-list** [*access-list-name*]

<b>Syntax Description</b>	<i>access-list-name</i> (Optional) Name of access list.
---------------------------	---

<b>Command Default</b>	All IPv6 access lists are displayed.
------------------------	--------------------------------------

<b>Command Modes</b>	User EXEC Privileged EXEC
----------------------	------------------------------

### Command History

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

### Usage Guidelines

The **show ipv6 access-list** command provides output similar to the **show ip access-list** command, except that it is IPv6-specific.

### Examples

The following output from the **show ipv6 access-list** command shows IPv6 access lists named inbound, tcptraffic, and outbound:

```
Device# show ipv6 access-list
IPv6 access list inbound
  permit tcp any any eq bgp reflect tcptraffic (8 matches) sequence 10
  permit tcp any any eq telnet reflect tcptraffic (15 matches) sequence 20
  permit udp any any reflect udptraffic sequence 30
IPv6 access list tcptraffic (reflexive) (per-user)
  permit tcp host 2001:0DB8:1::1 eq bgp host 2001:0DB8:1::2 eq 11000 timeout 300 (time
    left 243) sequence 1
  permit tcp host 2001:0DB8:1::1 eq telnet host 2001:0DB8:1::2 eq 11001 timeout 300
    (time left 296) sequence 2
IPv6 access list outbound
  evaluate udptraffic
  evaluate tcptraffic
```

The following sample output shows IPv6 access list information for use with IPsec:

```
Device# show ipv6 access-list
IPv6 access list Tunnel0-head-0-ACL (crypto)
  permit ipv6 any any (34 matches) sequence 1
IPv6 access list Ethernet2/0-ipsecv6-ACL (crypto)
  permit 89 FE80::/10 any (85 matches) sequence 1
```

The table below describes the significant fields shown in the display.

Table 4: show ipv6 access-list Field Descriptions

Field	Description
ipv6 access list inbound	Name of the IPv6 access list, for example, inbound.
permit	Permits any packet that matches the specified protocol type.
tcp	Transmission Control Protocol. The higher-level (Layer 4) protocol type that the packet must match.
any	Equal to ::/0.
eq	An equal operand that compares the source or destination ports of TCP or UDP packets.
bgp	Border Gateway Protocol. The lower-level (Layer 3) protocol type that the packet must be equal to.
reflect	Indicates a reflexive IPv6 access list.
tcptraffic (8 matches)	The name of the reflexive IPv6 access list and the number of matches for the access list. The <b>clear ipv6 access-list</b> privileged EXEC command resets the IPv6 access list match counters.
sequence 10	Sequence in which an incoming packet is compared to lines in an access list. Lines in an access list are ordered from first priority (lowest number, for example, 10) to last priority (highest number, for example, 80).
host 2001:0DB8:1::1	The source IPv6 host address that the source address of the packet must match.
host 2001:0DB8:1::2	The destination IPv6 host address that the destination address of the packet must match.
11000	The ephemeral source port number for the outgoing connection.
timeout 300	The total interval of idle time (in seconds) after which the temporary IPv6 reflexive access list named tcptraffic will time out for the indicated session.
(time left 243)	The amount of idle time (in seconds) remaining before the temporary IPv6 reflexive access list named tcptraffic is deleted for the indicated session. Additional received traffic that matches the indicated session resets this value to 300 seconds.
evaluate udptraffic	Indicates the IPv6 reflexive access list named udptraffic is nested in the IPv6 access list named outbound.

## Related Commands

Command	Description
<b>clear ipv6 access-list</b>	Resets the IPv6 access list match counters.
<b>hardware statistics</b>	Enables the collection of hardware statistics.
<b>show ip access-list</b>	Displays the contents of all current IP access lists.

Command	Description
<b>show ip prefix-list</b>	Displays information about a prefix list or prefix list entries.
<b>show ipv6 prefix-list</b>	Displays information about an IPv6 prefix list or IPv6 prefix list entries.

# show ipv6 mld snooping

Use the **show ipv6 mld snooping** command in EXEC mode to display IP version 6 (IPv6) Multicast Listener Discovery (MLD) snooping configuration of the switch or the VLAN.

```
show ipv6 mld snooping [vlan vlan-id]
```

Syntax Description	vlan	<i>vlan-id</i>	(Optional) Specify a VLAN; the range is 1 to 1001 and 1006 to 4094.
--------------------	------	----------------	---

## Command Modes

User EXEC

Privileged EXEC

## Command History

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Usage Guidelines

Use this command to display MLD snooping configuration for the switch or for a specific VLAN.

VLAN numbers 1002 through 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in MLD snooping.

To configure the dual IPv4 and IPv6 template, enter the **sdm prefer dual-ipv4-and-ipv6** global configuration command and reload the switch.

## Examples

This is an example of output from the show ipv6 mld snooping vlan command. It shows snooping characteristics for a specific VLAN.

```
Device# show ipv6 mld snooping vlan 100
Global MLD Snooping configuration:
-----
MLD snooping : Enabled
MLDv2 snooping (minimal) : Enabled
Listener message suppression : Enabled
TCN solicit query : Disabled
TCN flood query count : 2
Robustness variable : 3
Last listener query count : 2
Last listener query interval : 1000
Vlan 100:
-----
MLD snooping : Disabled
MLDv1 immediate leave : Disabled
Explicit host tracking : Enabled
Multicast router learning mode : pim-dvmrp
Robustness variable : 3
Last listener query count : 2
Last listener query interval : 1000
```

This is an example of output from the **show ipv6 mld snooping** command. It displays snooping characteristics for all VLANs on the switch.

```
Device# show ipv6 mld snooping
Global MLD Snooping configuration:
-----
MLD snooping : Enabled
MLDv2 snooping (minimal) : Enabled
Listener message suppression : Enabled
TCN solicit query : Disabled
TCN flood query count : 2
Robustness variable : 3
Last listener query count : 2
Last listener query interval : 1000

Vlan 1:
-----
MLD snooping : Disabled
MLDv1 immediate leave : Disabled
Explicit host tracking : Enabled
Multicast router learning mode : pim-dvmrp
Robustness variable : 1
Last listener query count : 2
Last listener query interval : 1000

<output truncated>

Vlan 951:
-----
MLD snooping : Disabled
MLDv1 immediate leave : Disabled
Explicit host tracking : Enabled
Multicast router learning mode : pim-dvmrp
Robustness variable : 3
Last listener query count : 2
Last listener query interval : 1000
```

#### Related Commands

Command	Description
<b>ipv6 mld snooping</b>	Enables and configures MLD snooping on the switch or on a VLAN.
<b>sdm prefer</b>	Configures an SDM template to optimize system resources based on how the switch is being used.



# show ipv6 mld snooping querier vlan

To see IPv6 MLD querier information in a VLAN, use the **show ipv6 mld snooping querier vlan** command.

```
show ipv6 mld snooping querier vlan vlan-id
```

---

**Syntax Description**

*vlan-id* VLAN ID. Valid range is 1 to 1001 and 1006 to 4094.

---

---

**Command Default**

None

---

**Command Modes**

Privileged EXEC

---

---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

---

## Examples

The following example shows how to see the IPv6 MLD querier information in a VLAN whose ID is 3:

```
Device# show ipv6 mld snooping querier vlan 3
```

# show ipv6 mld snooping wireless mgid

To see multicast group identifier (MGID) mapping information in the IPv6 MLD wireless related snooping events, use the **show ipv6 mld snooping wireless mgid** command.

**show ipv6 mld snooping wireless mgid**

---

## Command Default

None

---

## Command Modes

Privileged EXEC

---

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see multicast group identifier (MGID) mapping information in the IPv6 MLD wireless related snooping events:

```
Device# show ipv6 mld snooping wireless mgid
```

# show ldap attributes

To view information about the default LDAP attribute mapping, use the **show ldap attributes** command.

**show ldap attributes**

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view information about the default LDAP attribute mapping:

```

Device# show ldap attributes
LDAP Attribute          Format      AAA Attribute
=====
airespaceBwDataBurstContract  Ulong     bsn-data-bandwidth-burst-contr
userPassword             String     password
airespaceBwRealBurstContract  Ulong     bsn-realtime-bandwidth-burst-c
employeeType             String     employee-type
airespaceServiceType      Ulong     service-type
airespaceACLName          String     bsn-acl-name
priv-lvl                  Ulong     priv-lvl
memberOf                  String DN  supplicant-group
cn                        String     username
airespaceDSCP              Ulong     bsn-dscp
policyTag                  String     tag-name
airespaceQOSLevel          Ulong     bsn-qos-level
airespace8021PType         Ulong     bsn-8021p-type
airespaceBwRealAveContract  Ulong     bsn-realtime-bandwidth-average
airespaceVlanInterfaceName  String     bsn-vlan-interface-name
airespaceVapId             Ulong     bsn-wlan-id
airespaceBwDataAveContract  Ulong     bsn-data-bandwidth-average-con
sAMAccountName            String     sam-account-name
meetingContactInfo         String     contact-info
telephoneNumber            String     telephone-number
Map: att_map_1
department                 String DN  element-req-qos
    
```

# show ldap server

To view the LDAP server state information and various other counters for the server, use the **show ldap server** command.

**show ldap server**

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the LDAP server state information and various other counters for the server:

```
Device# show ldap server
```

# show license all

To display all licensing information enter the **show license all** command in Privileged EXEC mode. This command displays status, authorization, UDI, and usage information, all combined.

## show license all

### Syntax Description

This command has no keywords or arguments

### Command Modes

Privileged EXEC

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to display information relating to Smart Licensing Using Policy.  Command output no longer displays Smart Account and Virtual account information.

### Usage Guidelines

**Smart Licensing Using Policy:** If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2 or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

**Smart Licensing:** If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

### Example (Smart Licensing Using Policy)

The following is sample output of the **show license all** command on a Cisco Catalyst 9800-CL Wireless Controller. Similar output is displayed on all supported Cisco Catalyst Wireless Controllers.

```
Device# show license all

Smart Licensing Status
=====

Smart Licensing is ENABLED
License Reservation is ENABLED

Export Authorization Key:
  Features Authorized:
    <none>

Utility:
  Status: DISABLED

Smart Licensing Using Policy:
  Status: ENABLED

Data Privacy:
  Sending Hostname: yes
  Callhome hostname privacy: DISABLED
  Smart Licensing hostname privacy: DISABLED
```

```

Version privacy: DISABLED

Transport:
  Type: Transport Off

Miscellaneous:
  Custom Id: <empty>

Policy:
  Policy in use: Merged from multiple sources.
  Reporting ACK required: yes (CISCO default)
  Unenforced/Non-Export Perpetual Attributes:
    First report requirement (days): 365 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Unenforced/Non-Export Subscription Attributes:
    First report requirement (days): 90 (CISCO default)
    Reporting frequency (days): 90 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Enforced (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)
  Export (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)

Usage Reporting:
  Last ACK received: <none>
  Next ACK deadline: <none>
  Reporting push interval: 0 (no reporting)
  Next ACK push check: Nov 01 20:31:46 2020 IST
  Next report push: <none>
  Last report push: <none>
  Last report file write: <none>

Trust Code Installed: <none>

License Usage
=====

air-network-advantage (DNA_NWStack):
  Description: air-network-advantage
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-network-advantage
  Feature Description: air-network-advantage
  Enforcement type: NOT ENFORCED
  License type: Perpetual
  Reservation:
    Reservation status: SPECIFIC INSTALLED
    Total reserved count: 20

air-dna-advantage (AIR-DNA-A):
  Description: air-dna-advantage
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-dna-advantage
  Feature Description: air-dna-advantage

```

```
Enforcement type: NOT ENFORCED
License type: Perpetual
Reservation:
  Reservation status: SPECIFIC INSTALLED
  Total reserved count: 20
```

Product Information

=====

UDI: PID:C9800-CL-K9,SN:93BBAH93MGS

HA UDI List:

```
Active:PID:C9800-CL-K9,SN:93BBAH93MGS
Standby:PID:C9800-CL-K9,SN:9XECPSUU4XN
```

Agent Version

=====

Smart Agent for Licensing: 5.0.6\_rel/47

License Authorizations

=====

Overall status:

```
Active: PID:C9800-CL-K9,SN:93BBAH93MGS
  Status: SPECIFIC INSTALLED on Nov 02 03:16:01 2020 IST
  Last Confirmation code: 102fc949
Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
  Status: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
  Last Confirmation code: ad4382fe
```

Specified license reservations:

```
Aironet DNA Advantage Term Licenses (AIR-DNA-A):
  Description: DNA Advantage for Wireless
  Total reserved count: 20
  Enforcement type: NOT ENFORCED
  Term information:
    Active: PID:C9800-CL-K9,SN:93BBAH93MGS
      Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
      License type: TERM
      Start Date: 2020-OCT-14 UTC
      End Date: 2021-APR-12 UTC
      Term Count: 5
      Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
      License type: TERM
      Start Date: 2020-JUN-18 UTC
      End Date: 2020-DEC-15 UTC
      Term Count: 5
    Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
      Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
      License type: TERM
      Start Date: 2020-OCT-14 UTC
      End Date: 2021-APR-12 UTC
      Term Count: 10
AP Perpetual Networkstack Advantage (DNA_NWStack):
  Description: AP Perpetual Network Stack entitled with DNA-A
  Total reserved count: 20
  Enforcement type: NOT ENFORCED
  Term information:
    Active: PID:C9800-CL-K9,SN:93BBAH93MGS
      Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
      License type: TERM
      Start Date: 2020-OCT-14 UTC
      End Date: 2021-APR-12 UTC
      Term Count: 5
      Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
      License type: TERM
```

**show license all**

```
Start Date: 2020-JUN-18 UTC
End Date: 2020-DEC-15 UTC
Term Count: 5
Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
License type: TERM
Start Date: 2020-OCT-14 UTC
End Date: 2021-APR-12 UTC
Term Count: 10
```

```
Purchased Licenses:
No Purchase Information Available
```



# show license authorization

To display authorization-related information for (export-controlled and enforced) licenses, enter the **show license authorization** command in privileged EXEC mode.

## show license authorization

### Syntax Description

This command has no keywords or arguments

### Command Modes

Privileged EXEC

### Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.2a	This command was introduced.

### Usage Guidelines

Only export-controlled or enforced licenses require authorization before use.

While there are no export-controlled or enforced licenses on Cisco Catalyst Wireless Controllers, you can use this command to display migrated SLR authorization codes.

### Examples

See [Table 5: show license authorization Field Descriptions, on page 162](#) for information about fields shown in the display.

See [show license authorization Displaying Migrated Authorization Code, on page 164](#) for sample output.

Table 5: show license authorization Field Descriptions

Field	Description
Overall Status	<p>Header for UDI information for all product instances in the set-up, the type of authorization that is installed, and configuration errors, if any.</p> <p>In a High Availability set-up, all UDIs in the set-up are listed.</p>
Active: Status:	<p>The active product instance UDI, followed by the status of the authorization code installation for this UDI.</p> <p>If the status indicates that the authorization code is installed and there is a confirmation code, this is also displayed.</p>
Standby: Status:	<p>The standby product instance UDI, followed by the status of the authorization code installation for this UDI.</p> <p>If the status indicates that the authorization code is installed and there is a confirmation code, this is also displayed.</p>
Member: Status:	<p>The member product instance UDI, followed by the status of the authorization code installation for this UDI.</p> <p>If the status indicates that the authorization code is installed and there is a confirmation code, this is also displayed.</p>
ERROR:	<p>Configuration errors or discrepancies in the High Availability set-up, if any.</p>

Field	Description
Authorizations	<p>Header for detailed license authorization information. All licenses, their enforcement types, and validity durations are displayed. Errors are displayed for each product instance if its authorization or mode does not match what is installed on the active.</p> <p>This section is displayed only if the product instance is using a license with an authorization code.</p>
():	License name and a shortened form of the license name.
Description	License description.
Total available count:	<p>Total count of licenses that are available to consume.</p> <p>This includes licenses of all durations (perpetual and subscription), including expired subscription licenses, for all the product instances in a High Availability setup.</p>
Enforcement type	<p>Enforcement type for the license. This may be one of the following:</p> <ul style="list-style-type: none"> <li>• Enforced</li> <li>• Not enforced</li> <li>• Export-Controlled</li> </ul>
Term information:	

Field		Description
		<p>Header providing license duration information. The following fields maybe included under this header:</p> <ul style="list-style-type: none"> <li>• Active: The active product instance UDI, followed by the status of the authorization code installation for this UDI.</li> <li>• Authorization type: Type of authorization code installed and date of installation. The type can be: SLAC, UNIVERSAL, SPECIFIED, PAK, RTU.</li> <li>• Start Date: Displays validity start date if the license is for a specific term or time period.</li> <li>• Start Date: Displays validity end date if the license is for a specific term or time period.</li> <li>• Term Count: License count.</li> <li>• Subscription ID: Displays ID if the license is for a specific term or time period.</li> <li>• License type: License duration. This can be: SUBSCRIPTION or PERPETUAL.</li> <li>• Standby: The standby product instance UDI, followed by the status of the authorization code installation for this UDI.</li> <li>• Member: The member product instance UDI, followed by the status of the authorization code installation for this UDI.</li> </ul> <p>For more information about the duration or term of a license's validity, see <a href="#">&lt;link tbd&gt;</a>.</p>
Purchased Licenses	Header for license purchase information.	
	Active:	The active product instance and its the UDI.
	Count:	License count.
	Description:	License description.
	License type:	License duration. This can be: SUBSCRIPTION or PERPETUAL.
	Standby:	The standby product instance UDI.
	Member:	The member product instance UDI.

### show license authorization Displaying Migrated Authorization Code

The following is sample output of the **show license authorization** command on a Cisco Catalyst 9800-CL Wireless Controller. The `Last Confirmation code:` shows that SLR authorization code is available after migration. Similar output is displayed on all supported Cisco Catalyst Wireless Controllers.

```
Device# show license authorization
Overall status:
  Active: PID:C9800-CL-K9,SN:93BBAH93MGS
    Status: SPECIFIC INSTALLED on Nov 02 03:16:01 2020 IST
    Last Confirmation code: 102fc949
  Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
    Status: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
    Last Confirmation code: ad4382fe

Specified license reservations:
  Aironet DNA Advantage Term Licenses (AIR-DNA-A):
    Description: DNA Advantage for Wireless
    Total reserved count: 20
    Enforcement type: NOT ENFORCED
    Term information:
      Active: PID:C9800-CL-K9,SN:93BBAH93MGS
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
        Start Date: 2020-OCT-14 UTC
        End Date: 2021-APR-12 UTC
        Term Count: 5
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
        Start Date: 2020-JUN-18 UTC
        End Date: 2020-DEC-15 UTC
        Term Count: 5
      Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
        Start Date: 2020-OCT-14 UTC
        End Date: 2021-APR-12 UTC
        Term Count: 10
  AP Perpetual Networkstack Advantage (DNA_NWStack):
    Description: AP Perpetual Network Stack entitled with DNA-A
    Total reserved count: 20
    Enforcement type: NOT ENFORCED
    Term information:
      Active: PID:C9800-CL-K9,SN:93BBAH93MGS
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
        Start Date: 2020-OCT-14 UTC
        End Date: 2021-APR-12 UTC
        Term Count: 5
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
        Start Date: 2020-JUN-18 UTC
        End Date: 2020-DEC-15 UTC
        Term Count: 5
      Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
        Authorization type: SPECIFIC INSTALLED on Nov 02 03:15:45 2020 IST
        License type: TERM
        Start Date: 2020-OCT-14 UTC
        End Date: 2021-APR-12 UTC
        Term Count: 10

Purchased Licenses:
  No Purchase Information Available
```

# show license data conversion

To display license data conversion information, enter the **show license data** command in privileged EXEC mode.

**show license data conversion**

---

**Syntax Description** This command has no keywords or arguments

---



---

**Command Modes** Privileged EXEC (Device#)

---



---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
	Cisco IOS XE Amsterdam 17.3.2a	This command continues to be available with the introduction of Smart Licensing Using Policy.

---



---

**Usage Guidelines** Although visible on the CLI, this command is not applicable to Cisco Catalyst Wireless Controllers.

# show license eventlog

To display event logs relating to Smart Licensing Using Policy, enter the **show license eventlog** command in privileged EXEC mode.

**show license eventlog** [ *days* ]

<b>Syntax Description</b>	<i>days</i> Enter the number of days for which you want to display event logs. The valid value range is from 0 to 2147483647.	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
	Cisco IOS XE Amsterdam 17.3.2a	Additional events were added with the introduction of Smart Licensing Using Policy: <ul style="list-style-type: none"> <li>• Installation and removal of a policy</li> <li>• Request, installation and removal of an authorization code.</li> <li>• Installation and removal of a trust code.</li> <li>• Addition of authorization source information for license usage.</li> </ul>
<b>Usage Guidelines</b>	<p><b>Smart Licensing Using Policy:</b> If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.</p> <p><b>Smart Licensing:</b> If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.</p>	

# show license history message

To display communication history between the product instance and CSSM or CSLU (as the case may be), enter the **show license history message** command in privileged EXEC mode. The output of this command is used by the technical support team, for troubleshooting.

**show license history message**

## Syntax Description

This command has no arguments or keywords.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.2a	This command was introduced.

## Usage Guidelines

When you encounter an error message that you are not able to resolve, along with a copy of the message that appears on the console or in the system log, provide your Cisco technical support representative with sample output of these commands: **show license tech support**, **show license history message**, and the **show platform software sl-infra** privileged EXEC commands.



# show license reservation

To display license reservation information, enter the **show license reservation** command in privileged EXEC mode.

**show license reservation**

---

**Syntax Description**

This command has no keywords or arguments

---

**Command Modes**

Privileged EXEC

---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	This command continues to be available with the introduction of Smart Licensing Using Policy.

---

**Usage Guidelines**

The command continues to be available on the CLI and corresponding output is displayed, but with the introduction of Smart Licensing Using Policy, the notion of reservation is not longer applicable. Use the **show license all** command in privileged EXEC mode, to display *migrated* SLR licenses instead (the SLR authorization code is migrated to Smart Licensing Using Policy).

# show license status

To display information about licensing settings such as data privacy, policy, transport, usage reporting and trust codes, enter the **show license status** command in privileged EXEC mode.

## show license status

### Syntax Description

This command has no keywords or arguments

### Command Modes

Privileged EXEC (Device#)

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to reflect new fields that are applicable to Smart Licensing Using Policy. This includes <code>Trust code installed:</code> , <code>Policy in use</code> , <code>Policy name:</code> , reporting requirements as in the policy ( <code>Attributes:</code> ), and fields related to usage reporting.  Command output no longer displays Smart Account and Virtual account information.

### Usage Guidelines

**Smart Licensing Using Policy:** If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

**Smart Licensing:** If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

### Examples

See [Table 6: show license status Field Descriptions for Smart Licensing Using Policy](#), on page 171 for information about fields shown in the display.

[show license status with Cisco Default Policy \(Smart Licensing Using Policy\)](#), on page 176

[show license status with Custom Policy \(Smart Licensing Using Policy\)](#), on page 177

Table 6: show license status Field Descriptions for Smart Licensing Using Policy

Field	Description
Utility	Header for utility settings that are configured on the product instance.
	Status: Status
	Utility report: Last attempt:
	Customer Information: The following fields are displayed: <ul style="list-style-type: none"> <li>• Id:</li> <li>• Name:</li> <li>• Street</li> <li>• City:</li> <li>• State:</li> <li>• Country:</li> <li>• Postal Code:</li> </ul>
Smart Licensing Using Policy:	Header for policy settings on the product instance.
	Status: Indicates if Smart Licensing Using Policy is enabled. Smart Licensing Using Policy is supported starting from Cisco IOS XE Amsterdam 17.3.2 and is always enabled on supported software images.
Data Privacy:	Header for privacy settings that are configured on the product instance.
	Sending Hostname: A <i>yes</i> or <i>no</i> value which shows if the hostname is sent in usage reports.
	Callhome hostname privacy: Indicates if the Call Home feature is configured as the mode of transport for reporting. If configured, one of these values is displayed: <ul style="list-style-type: none"> <li>• ENABLED</li> <li>• DISABLED</li> </ul>
	Smart Licensing hostname privacy: One of these values is displayed: <ul style="list-style-type: none"> <li>• ENABLED</li> <li>• DISABLED</li> </ul>
	Version privacy: One of these values is displayed: <ul style="list-style-type: none"> <li>• ENABLED</li> <li>• DISABLED</li> </ul>

Field		Description
Transport:		Header for transport settings that are configured on the product instance.
	Type:	Mode of transport that is in use.  Additional fields are displayed for certain transport modes. For example, if transport type is set to CSLU, the CSLU address is also displayed.

Field	Description
Policy:	Header for policy information that is applicable to the product instance.
Policy in use:	Policy that is applied  This can be one of the following: Cisco default, Product default, Permanent License Reservation, Specific License Reservation, PAK license, Installed on <date>, Controller.
Policy name:	Name of the policy
Reporting ACK required:	A <i>yes</i> or <i>no</i> value which specifies if the report for this product instance requires CSSM acknowledgement (ACK) or not. The default policy is always set to “yes”.
Unenforced/Non-Export Perpetual Attributes	Displays policy values for perpetual licenses. <ul style="list-style-type: none"> <li>• First report requirement (days): The maximum amount of time available before the first report must be sent, followed by policy name.</li> <li>• Reporting frequency (days): The maximum amount of time available before the subsequent report must be sent, followed by policy name.</li> <li>• Report on change (days): he maximum amount of time available to send a report in case of a change in license usage, followed by policy name</li> </ul>
Unenforced/Non-Export Subscription Attributes	Displays policy values for subscription licenses. <ul style="list-style-type: none"> <li>• First report requirement (days): The maximum amount of time available before the first report must be sent, followed by policy name.</li> <li>• Reporting frequency (days): The maximum amount of time available before the subsequent report must be sent, followed by policy name.</li> <li>• Report on change (days): he maximum amount of time available to send a report in case of a change in license usage, followed by policy name</li> </ul>
Enforced (Perpetual/Subscription) License Attributes	

Field		Description
		<p>Displays policy values for enforced licenses.</p> <ul style="list-style-type: none"> <li>• First report requirement (days): The maximum amount of time available before the first report must be sent, followed by policy name.</li> <li>• Reporting frequency (days): The maximum amount of time available before the subsequent report must be sent, followed by policy name.</li> <li>• Report on change (days): The maximum amount of time available to send a report in case of a change in license usage, followed by policy name</li> </ul>
	Export (Perpetual/Subscription) License Attributes	<p>Displays policy values for export-controlled licenses.</p> <ul style="list-style-type: none"> <li>• First report requirement (days): The maximum amount of time available before the first report must be sent, followed by policy name.</li> <li>• Reporting frequency (days): The maximum amount of time available before the subsequent report must be sent, followed by policy name.</li> <li>• Report on change (days): The maximum amount of time available to send a report in case of a change in license usage, followed by policy name</li> </ul>
Miscellaneous	Header for custom ID.	
	Custom Id:	ID

Field	Description
Usage Reporting:	Header for usage reporting (RUM reports) information.
Last ACK received:	Date and time of last ACK received, in the local time zone.
Next ACK deadline:	Date and time for next ACK. If the policy states that an ACK is not required then this field displays <code>none</code> .  <b>Note</b> If an ACK is required and is not received by this deadline, a syslog is displayed.
Reporting Interval:	Reporting interval in days  The value displayed here depends on what you configure in the <b>license smart usage interval</b> <code>interval_in_days</code> and the policy value. For more information, see the corresponding Syntax Description: <a href="#">license smart (global config)</a> .
Next ACK push check:	Date and time when the product instance will submit the next polling request for an ACK. Date and time are in the local time zone.  This applies only to product instance- initiated communication to CSSM or CSLU. If the reporting interval is zero, or if no ACK polling is pending, then this field displays <code>none</code> .
Next report push:	Date and time when the product instance will send the next RUM report. Date and time are in the local time zone. If the reporting interval is zero, or if there are no pending RUM reports, then this field displays <code>none</code> .
Last report push:	Date and time for when the product instance sent the last RUM report. Date and time are in the local time zone.
Last report file write:	Date and time for when the product instance last saved an offline RUM report. Date and time are in the local time zone.
Last report pull:	Date and time for when usage reporting information was retrieved using data models. Date and time are in the local time zone.

Field	Description
Trust Code Installed:	Header for trust code-related information.  Displays date and time if trust code is installed. Date and time are in the local time zone.  If a trust code is not installed, then this field displays <i>none</i> .
Active:	Active product instance.  In a High Availability set-up, the the UDIs of all product instances in the set-up, along with corresponding trust code installation dates and times are displayed.
Standby:	Standby product instance.
Member:	Member product instance

### show license status with Cisco Default Policy (Smart Licensing Using Policy)

The following is sample output of the **show license status** command; a default is policy applied here.

```
Device# show license status

Utility:
  Status: DISABLED

Smart Licensing Using Policy:
  Status: ENABLED

Data Privacy:
  Sending Hostname: yes
  Callhome hostname privacy: DISABLED
  Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Smart
  URL: https://smartreceiver.cisco.com/licservice/license
  Proxy:
    Not Configured

Policy:
  Policy in use: Merged from multiple sources.
  Reporting ACK required: yes (CISCO default)
  Unenforced/Non-Export Perpetual Attributes:
    First report requirement (days): 365 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Unenforced/Non-Export Subscription Attributes:
    First report requirement (days): 90 (CISCO default)
    Reporting frequency (days): 90 (CISCO default)
    Report on change (days): 90 (CISCO default)
  Enforced (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
    Report on change (days): 0 (CISCO default)
  Export (Perpetual/Subscription) License Attributes:
    First report requirement (days): 0 (CISCO default)
    Reporting frequency (days): 0 (CISCO default)
```



```

    Report on change (days): 0 (CISCO default)

Miscellaneous:
    Custom Id: <empty>

Usage Reporting:
    Last ACK received: <none>
    Next ACK deadline: <none>
    Reporting push interval: 0 (no reporting)
    Next ACK push check: <none>
    Next report push: <none>
    Last report push: <none>
    Last report file write: <none>

Trust Code Installed: <none>

```

### show license status with Custom Policy (Smart Licensing Using Policy)

The following is sample output of the **show license status** command; a custom policy applied here.

```

Device# show license status
Utility:
    Status: DISABLED

Smart Licensing Using Policy:
    Status: ENABLED

Data Privacy:
    Sending Hostname: yes
    Callhome hostname privacy: DISABLED
    Smart Licensing hostname privacy: DISABLED
    Version privacy: DISABLED

Transport:
    Type: Smart
    URL: https://smartreceiver.cisco.com/licservice/license
    Proxy:
        Not Configured

Policy:
    Policy in use: Installed On Nov 02 05:09:31 2020 IST
    Policy name: SLE Policy
    Reporting ACK required: yes (Customer Policy)
    Unenforced/Non-Export Perpetual Attributes:
        First report requirement (days): 60 (Customer Policy)
        Reporting frequency (days): 60 (Customer Policy)
        Report on change (days): 60 (Customer Policy)
    Unenforced/Non-Export Subscription Attributes:
        First report requirement (days): 30 (Customer Policy)
        Reporting frequency (days): 30 (Customer Policy)
        Report on change (days): 30 (Customer Policy)
    Enforced (Perpetual/Subscription) License Attributes:
        First report requirement (days): 0 (CISCO default)
        Reporting frequency (days): 90 (Customer Policy)
        Report on change (days): 90 (Customer Policy)
    Export (Perpetual/Subscription) License Attributes:
        First report requirement (days): 0 (CISCO default)
        Reporting frequency (days): 90 (Customer Policy)
        Report on change (days): 90 (Customer Policy)

Miscellaneous:
    Custom Id: <empty>

```

```
Usage Reporting:
  Last ACK received: <none>
  Next ACK deadline: <none>
  Reporting push interval: 0 (no reporting)
  Next ACK push check: <none>
  Next report push: <none>
  Last report push: <none>
  Last report file write: <none>
```

```
Trust Code Installed:
  Active: PID:C9800-CL-K9,SN:93BBAH93MGS
         INSTALLED on Nov 02 05:09:31 2020 IST
  Standby: PID:C9800-CL-K9,SN:9XECPSUU4XN
         INSTALLED on Nov 02 05:09:31 2020 IST
```

# show license summary

To display a brief summary of license usage, which includes information about licenses being used, the count, and status, enter the **show license summary** command in privileged EXEC mode.

**show license summary**

<b>Syntax Description</b>	This command has no keywords or arguments
---------------------------	---

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
	Cisco IOS XE Amsterdam 17.3.2a	<p>Command output was updated to reflect valid license status for Smart Licensing Using Policy. Valid license statuses include: IN USE, NOT IN USE, NOT AUTHORIZED.</p> <p>Command output was also updated to remove registration and authorization information.</p> <p>Command output no longer displays Smart Account and Virtual account information.</p>

<b>Usage Guidelines</b>	<p><b>Smart Licensing Using Policy:</b> If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.</p>
-------------------------	--

The licenses on Cisco Catalyst Wireless Controllers are never NOT AUTHORIZED, because none of the available licenses are export-controlled or enforced (Only these licenses require authorization before use).

**Smart Licensing:** If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

## Examples

See [Table 7: show license summary Field Descriptions, on page 179](#) for information about fields shown in the display.

[show license summary: IN USE \(Smart Licensing Using Policy\), on page 180](#)

[show license summary: NOT IN USE \(Smart Licensing Using Policy\), on page 180](#)

**Table 7: show license summary Field Descriptions**

Field	Description
License	Name of the licenses in use
Entitlement Tag	Short name for license
Count	License count

Field	Description
Status	<p>License status can be one of the following</p> <ul style="list-style-type: none"> <li>• In-Use: Valid license, and in-use.</li> <li>• Not In-Use</li> <li>• Not Authorized: Means that the license requires installation of SLAC before use.</li> </ul>

### show license summary: IN USE (Smart Licensing Using Policy)

The following is sample output of the **show license summary** command where all licenses are in-use.

```
Device# show license summary
```

```
License Usage:
  License                               Entitlement Tag                               Count Status
-----
  air-network-essentials (DNA_NWSTACK_E)                               1 IN USE
  air-dna-essentials      (AIR-DNA-E)                                   1 IN USE
```

### show license summary: NOT IN USE (Smart Licensing Using Policy)

The following is sample output of the **show license summary** command, where none of the APs have joined the controller. Current consumption (Count) is therefore zero, and the `Status` field shows that the licenses are NOT IN USE:

```
Device# show license summary
```

```
Device#show license summary
License Reservation is ENABLED
```

```
License Usage:
  License                               Entitlement Tag                               Count Status
-----
  Aironet DNA Advantag... (AIR-DNA-A)                               0 NOT IN USE
  AP Perpetual Network... (DNA_NWStack)                             0 NOT IN USE
```

# show license tech

To display licensing information to help the technical support team to solve a problem, enter the **show license tech** command in privileged EXEC mode. The output for this command includes outputs of several other **show license** commands and more.

```
show license tech { data { conversion } | eventlog [{ days } ] | reservation | support }
```

## Syntax Description

<b>data { conversion }</b>	Displays license data conversion information.
<b>eventlog [{ days } ]</b>	Displays event logs related to Smart Licensing Using Policy. For <i>days</i> , enter the number of days for which you want to display event logs. The valid value range is from 0 to 2147483647.
<b>reservation</b>	Displays license reservation information.
<b>support</b>	Displays licensing information that helps the technical support team to debug a problem.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	Command output was updated to reflect new fields that are applicable to Smart Licensing Using Policy.

## Usage Guidelines

**Smart Licensing Using Policy:** If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

When you encounter an error message that you are not able to resolve, along with a copy of the message that appears on the console or in the system log, provide your Cisco technical support representative with sample output of these commands: **show license tech support**, **show license history message**, and the **show platform software sl-infra all** privileged EXEC commands.

**Smart Licensing:** If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing (whether smart licensing is enabled, all associated licensing certificates, compliance status, and so on).

### Example (Smart Licensing Using Policy)

The following is sample output from the **show license tech support** command.

```
Device# show license tech support
Smart Licensing Tech Support info
Smart Licensing Status
=====
Smart Licensing is ENABLED
```

```

License Reservation is ENABLED

Registration:
  Status: REGISTERED - SPECIFIC LICENSE RESERVATION
  Export-Controlled Functionality: ALLOWED
  Initial Registration: SUCCEEDED on Nov 02 03:16:01 2020 IST

License Authorization:
  Status: AUTHORIZED - RESERVED on Nov 02 03:16:01 2020 IST

Export Authorization Key:
  Features Authorized:
    <none>

Utility:
  Status: DISABLED

Data Privacy:
  Sending Hostname: yes
  Callhome hostname privacy: DISABLED
  Smart Licensing hostname privacy: DISABLED
  Version privacy: DISABLED

Transport:
  Type: Smart
  URL: https://smartreceiver.cisco.com/licservice/license

Evaluation Period:
  Evaluation Mode: Not In Use
  Evaluation Period Remaining: 89 days, 23 hours, 42 minutes, 47 seconds

License Usage
=====
Handle: 1
  License: AP Perpetual Networkstack Advantage
  Entitlement tag:
  regid.2018-06.com.cisco.DNA_NWStack,1.0_e7244e71-3ad5-4608-8bf0-d12f67c80896
  Description: AP Perpetual Network Stack entitled with DNA-A
  Count: 1
  Version: 1.0
  Status: AUTHORIZED(3)
  Status time: Nov 02 03:16:01 2020 IST
  Request Time: Nov 02 02:55:34 2020 IST
  Export status: NOT RESTRICTED
  Soft Enforced: True

Handle: 2
  License: Aironet DNA Advantage Term Licenses
  Entitlement tag: regid.2017-08.com.cisco.AIR-DNA-A,1.0_b6308627-3ab0-4a11-a3d9-586911a0d790

  Description: DNA Advantage for Wireless
  Count: 1
  Version: 1.0
  Status: AUTHORIZED(3)
  Status time: Nov 02 03:16:01 2020 IST
  Request Time: Nov 02 02:55:34 2020 IST
  Export status: NOT RESTRICTED
  Soft Enforced: True

Product Information
=====
UDI: PID:C9800-CL-K9,SN:93BBAH93MGS

HA UDI List:

```







```
Term Count: 10
Subscription ID: <none>
```

```
Other Info
```

```
=====
```

```
Software ID: regid.2018-05.com.cisco.WLC_9500C,1.0_85665885-b865-4e32-8184-5510412fcb54
Agent State: authorized
TS enable: True
Transport: Smart
  Default URL: https://smartreceiver.cisco.com/licservice/license
Locale: en_US.UTF-8
Debug flags: 0x7
Privacy Send Hostname: True
Privacy Send IP: True
Build type:: Production
sizeof(char) : 1
sizeof(int) : 4
sizeof(long) : 4
sizeof(char *): 8
sizeof(time_t): 4
sizeof(size_t): 8
Endian: Big
Write Erase Occurred: False
XOS version: 0.12.0.0
Config Persist Received: False
Message Version: 1.3
connect_info.name: <empty>
connect_info.version: <empty>
connect_info.additional: <empty>
connect_info.prod: False
connect_info.capabilities: <empty>
agent.capabilities: UTILITY, DLC, AppHA, MULTITIER, EXPORT_2, OK_TRY_AGAIN
SmartAgentClientWaitForServer: 2000
SmartAgentCmReTrySend: True
SmartAgentClientIsUnified: True
SmartAgentCmClient: True
SmartAgentClientName: UnifiedClient
builtInEncryption: True
enableOnInit: True
routingReadyByEvent: True
systemInitByEvent: True
SmartAgentFederalLicense: True
SmartAgent_Crypto_Exit_CB: 0x55B353357A20
SmartAgent_Crypto_Start_CB: 0x55B353357A10
SmartAgentMultiTenant: False
attr365DayEvalSyslog: True
checkPointWriteOnly: False
SmartAgentDelayCertValidation: False
enableByDefault: False
conversionAutomatic: True
conversionAllowed: False
storageEncryptDisable: False
storageLoadUnencryptedDisable: False
TSPluginDisable: False
bypassUDICheck: False
loggingAddTStamp: False
loggingAddTid: True
platformOverrideEvent: UnknownPlatformEvent
WaitForHaRole: False
standbyIsHot: True
chkPtType: 2
delayCommInit: False
roleByEvent: True
maxTraceLength: 150
```

```
traceAlwaysOn: True
debugFlags: 0
Event log max size: 5120 KB
Event log current size: 21 KB

Platform Provided Mapping Table
=====
<empty>
```

# show license udi

To display Unique Device Identifier (UDI) information for a product instance, enter the **show license udi** command in privileged EXEC mode. In a High Availability set-up, the output displays UDI information for all connected product instances.

## show license udi

### Syntax Description

This command has no keywords or arguments

### Command Modes

Privileged EXEC

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Cisco IOS XE Amsterdam 17.3.2a	This command continues to be available with the introduction of Smart Licensing Using Policy.

### Usage Guidelines

**Smart Licensing Using Policy:** If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

**Smart Licensing:** If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

### Examples

[show license udi with Standalone Product Instance, on page 187](#)

[show license udi with Active and Standby, on page 187](#)

#### show license udi with Standalone Product Instance

The following is sample output from the **show license udi** command on a standalone product instance.

```
Device# show license udi
UDI: PID:C9800-L-F-K9,SN:FCW2323W016
```

#### show license udi with Active and Standby

The following is sample output from the **show license udi** command in a High Availability set-up where an active and a standby product instances exist. UDI information is displayed for both.

```
Device# show license udi
UDI: PID:C9800-CL-K9,SN:93BBAH93MGS
HA UDI List:
  Active:PID:C9800-CL-K9,SN:93BBAH93MGS
  Standby:PID:C9800-CL-K9,SN:9XECPSUU4XN
```

# show license usage

To display license usage information such as status, a count of licenses being used, and enforcement type, enter the **show license usage** command in privileged EXEC mode.

## show license usage

### Syntax Description

This command has no keywords or arguments

### Command Modes

Privileged EXEC

### Command History

#### Release

This command was introduced in a release earlier than Cisco IOS XE Amsterdam 17.3.2

#### Modification

This command was introduced.

Cisco IOS XE Amsterdam 17.3.2a

Command output was updated to reflect new fields that are applicable to Smart Licensing Using Policy. This includes the `Status`, `Enforcement type` fields.

Command output was also updated to remove reservation related information, authorization status information, and export status information.

### Usage Guidelines

**Smart Licensing Using Policy:** If the software version on the device (also referred to as a product instance) is Cisco IOS XE Amsterdam 17.3.2a or a later release, command output displays fields pertinent to Smart Licensing Using Policy.

**Smart Licensing:** If the software version on the device is Cisco IOS XE Amsterdam 17.3.1 or an earlier release, command output displays fields pertinent to Smart Licensing.

### Examples

See [Table 8: show license usage Field Descriptions, on page 188](#) for information about fields shown in the display.

[show license usage with unenforced licenses \(Smart Licensing Using Policy\), on page 189](#)

[show license usage with unenforced SLR licenses \(Smart Licensing Using Policy\), on page 190](#)

**Table 8: show license usage Field Descriptions**

Field	Description
License Authorization: Status:	Displays overall authorization status.
():	Name of the license as in CSSM.  If this license is one that requires an authorization code, the name of the license comes from the code.

Field	Description
Description	Description of the license as in CSSM.
Count	License count. If the license is not in-use, the count is reflected as zero.
Version	Version.
Status	License status can be one of the following <ul style="list-style-type: none"> <li>• In-Use: Valid license, and in-use.</li> <li>• Not In-Use</li> <li>• Not Authorized: Means that the license requires installation of SLAC before use. For more information, see</li> </ul>
Export Status:	Indicates if this license is export-controlled or not. Accordingly, one of the following statuses is displayed: <ul style="list-style-type: none"> <li>• RESTRICTED - ALLOWED</li> <li>• RESTRICTED - NOT ALLOWED</li> <li>• NOT RESTRICTED</li> </ul>
Feature name	Name of the feature that uses this license.
Feature Description:	Description of the feature that uses this license.
Utility Subscription id:	ID Not applicable, because the corresponding configuration option is not supported.
Enforcement type	Enforcement type status for the license. This may be one of the following: <ul style="list-style-type: none"> <li>• ENFORCED</li> <li>• NOT ENFORCED</li> <li>• EXPORT RESTRICTED - ALLOWED</li> <li>• EXPORT RESTRICTED - NOT ALLOWED</li> </ul> For more information about enforcement types, see <link tbd>

### show license usage with unenforced licenses (Smart Licensing Using Policy)

The following is sample output of the **show license usage** command. Unenforced licenses are in-use here.

```

Device# show license usage

License Authorization:
  Status: Not Applicable

air-network-essentials (DNA_NWSTACK_E):
  Description: air-network-essentials
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-network-essentials
  Feature Description: air-network-essentials
  Enforcement type: NOT ENFORCED
  License type: Perpetual

air-dna-essentials (AIR-DNA-E):
  Description: air-dna-essentials
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-dna-essentials
  Feature Description: air-dna-essentials
  Enforcement type: NOT ENFORCED
  License type: Perpetual

```

### show license usage with unenforced SLR licenses (Smart Licensing Using Policy)

The following is sample output of the **show license usage** command. Migrated SLR licenses are in-use here:

```

Device# show license usage

air-network-advantage (DNA_NWStack):
  Description: air-network-advantage
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-network-advantage
  Feature Description: air-network-advantage
  Enforcement type: NOT ENFORCED
  License type: Perpetual
  Reservation:
    Reservation status: SPECIFIC INSTALLED
    Total reserved count: 20

air-dna-advantage (AIR-DNA-A):
  Description: air-dna-advantage
  Count: 1
  Version: 1.0
  Status: IN USE
  Export status: NOT RESTRICTED
  Feature Name: air-dna-advantage
  Feature Description: air-dna-advantage
  Enforcement type: NOT ENFORCED
  License type: Perpetual
  Reservation:
    Reservation status: SPECIFIC INSTALLED
    Total reserved count: 20

```

## show platform software sl-infra

To display troubleshooting information and for debugging, enter the **show platform software sl-infra** command in privileged EXEC mode. The output of this command is used by the technical support team, for troubleshooting and debugging.

**license call-home** { **all** | **current** | **debug** | **stored** }

### Syntax Description

**all** Displays current, debugging, and stored information.

**current** Displays current license-related information.

**debug** Enables debugging

**stored** Displays information that is stored on the product instance.

### Command Modes

Privileged EXEC

### Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.2a	This command was introduced.

### Usage Guidelines

When you encounter an error message that you are not able to resolve, along with a copy of the message that appears on the console or in the system log, provide your Cisco technical support representative with sample output of these commands: **show license tech support**, **show license history message**, and the **show platform software sl-infra all** privileged EXEC commands.

# show platform software tls client summary

To view the TLS client summary details, use the **show platform software tls client summary** command.

**show platform software tls client summary**

## Syntax Description

This command has no keywords or arguments.

## Command Modes

Global configuration

## Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

## Examples

This example shows how to view the TLS client summary details:

```
Device # show platform software tls client summary
```

Name	ID	Gateway	Port	Auth	Trustpoint	DPD Time	Rekey Time	Retry Time
fqdn	0		8443	PSK	N/A	60	300	20



# show platform software client detail

To display a summary of TLS client session detail, session statistics, tunnel statistics, and DNS counters, use the **show platform software client detail** command.

## show platform software client detail

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

### Examples

This example shows how to view the TLS client summary details:

```
Device # show platform software client detail

TLS Client          : Session Detail
Session Name       : fqdn
FQDN resolved IP   : 10.194.234.149
ID                 : 0
Created            : 04/20/21 00:36:42
Updated           : 04/22/21 05:56:03
State              : Up (Rekey)
Up Time            : 04/21/21 20:30:21 ( 9 hours 25 minutes 45 seconds )
Down Time          : 04/21/21 20:30:01
Rekey Time         : 04/22/21 05:55:51 ( 15 seconds )

TLS Session Statistics

Up Notifications   : 3
Down Notifications : 2
Rekey Notifications : 636
DP State Updates   : 0
DPD Cleanups       : 0

Packets From      Packets To  Packet Errors To  Bytes From      Bytes To
-----
BinOS              80          0
IOSd               0          0                0                0

TLS Client         0          0                0                0

TLS Tunnel Statistics
Type              Tx Packets      Rx Packets
-----
Total             0                80
CSTP Ctrl        3836            3836
CSTP Data         80                0

Type              Requests        Responses
-----
```

## show platform software client detail

```
CSTP Cfg          639          639
CSTP DPD          3197         3197

Invalid CSTP Rx           : 0
Injected Packet Success  : 0
Injected Packet Failed   : 0
Consumed Packets         : 0

TLS Tunnel DNS Counters
DNS Resolve Request Success Count : 641
DNS Resolve Request Failure Count : 0
DNS Resolve Success Count         : 639
DNS Resolve Failure Count         : 2
```

# show platform software tls statistics

To view the TLS client global statistic details, use the **show platform software tls statistics** command.

## show platform software tls statistics

### Syntax Description

This command has no keywords or arguments.

### Command Modes

Global configuration

### Command History

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

### Examples

This example shows how to view the TLS client summary details:

```
Device # show platform software tls statistics

TLS Client - Global Statistics
Session Statistics
Up/Down          : 5/2
Rekeys           : 636
DP Updates       : 0
DPD Cleanups     : 0

Packets From    Packets To    Packet Errors To    Bytes From    Bytes To
-----
BinOS           85              0                  0             0
IOSd 0          0               0                  0             0
TLS Client 0    0               0                  0             0

Tunnel Statistics
SSL Handshake Init/Done : 641/641
TCP Connection Req/Done : 641/641

Tunnel Packets
Rx/Tx              : 85/0
Injected / Failed  : 0/0
Consumed           : 0

CSTP Packets
Control Rx/Tx      : 3839 / 3839
Data Rx/Tx         : 0 / 85
Config Req/Resp    : 641 / 641
DPD Req/Resp       : 3198 / 3198
Invalid Rx         : 0

FQDN Counters
Req/Resp/Success   : 0/0/0

NAT Counters
Transalte In/Out   : 0/0
Ignore In/Out      : 0/0
Failed             : 0
Invalid            : 0
```

```
No Entry          : 0
Unsupported       : 0
```

```
Internal Counters
Type              Allocated          Freed
-----
EV                1299                1295
Tunnel            5                   4
Conn              643                642
Sess              3                   2
```

```
Config Message Related Counters
Type              Success          Failed
-----
Create            3                 0
Delete            2                 0
```

# show platform software tls session summary

To view the tls client session summary, use the **show platform software tls session summary** command.

**show platform software tls session summary**

---

**Syntax Description**

This command has no keywords or arguments.

---

---

**Command Modes**

Global configuration

---

---

**Command History**

Release	Modification
Cisco IOS XE Bengaluru 17.6.1	This command was introduced.

---

---

**Examples**

This example shows how to view the TLS client summary details:

```
Device # show platform software tls session summary
```

```
TLS Client - Session Summary
```

Name	ID	Created	State	Since	Elapsed
fqdn	0	04/20/21 00:36:42	Up	04/21/21 20:30:21	9 hours 26 minutes 44 seconds

# show lisp site detail

To see detailed Locator ID Separation Protocol (LISP) site information on a map server, use the **show lisp site detail** command.

```
show lisp site detail [{eid-table {default | vlan vlan-id | vrf vrf-name } | instance-id id-number |
internal {eid-table {default | vlan vlan-id | vrf vrf-name} | instance-id id-number}]
```

Syntax Description	Option	Description
	<b>eid-table</b>	Option to enter the EID table.
	<b>default</b>	Shows the information for the default VRF.
	<b>vlan</b> <i>vlan-id</i>	Enter the VLAN information.
	<b>vrf</b> <i>vrf-name</i>	Enter the VRF name.
	<b>instance-id</b> <i>id-number</i>	Enter the EID instance ID.
	<b>internal</b>	Shows the site's detailed internal information.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see detailed Locator ID Separation Protocol (LISP) site information on a map server:

```
Device # show lisp site detail
```

# show logging profile wireless end timestamp

To specify log filtering end location timestamp for filtering, use the **show logging profile wireless end timestamp** command.

**show logging profile wireless end timestamp** *time-stamp*

<b>Syntax Description</b>	<i>time-stamp</i> Time to end the filtering. For example, 2017/02/10 14:41:50.849.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

<b>Usage Guidelines</b>	Ensure that you enable internal keyword using the <b>show logging profile wireless internal</b> command to get the trace output.
-------------------------	--

## Example

The following example shows how to specify log filtering end location timestamp for filtering:

```
Device# show logging profile wireless end timestamp 2017/02/10 14:41:50.849
```

# show logging profile wireless filter

To specify filter for logs, use the **show logging profile wireless filter** command.

**show logging profile wireless filter** { **ipv4** | **mac** | **string** | **uuid** }

## Syntax Description

**ipv4** Selects logs with specific IP address app context.

**mac** Selects logs with specific MAC app context.

**string** Selects logs with specific string app context.

**uuid** Selects logs with specific Universally Unique Identifier (UUID) app context.

## Command Default

None

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

## Example

The following example shows how to specify filter for logs:

```
Device# show logging profile wireless filter ipv4 10.10.11.1
```



# show logging profile wireless fru

To specify field-replaceable unit (FRU) specific commands, use the **show logging profile wireless fru** command.

```
show logging profile wireless fru {0 {reverse | to-file}| chassis} {0 {reverse | to-file} | chassis}
```

Syntax Description	
<b>0</b>	SPA-Inter-Processor slot 0.
<b>reverse</b>	Shows logs in reverse chronological order.
<b>to-file</b>	Decodes files stored in disk and write output to file.
<b>chassis</b>	Chassis name.

**Command Default** None

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

**Usage Guidelines** Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

## Example

The following example shows how to specify FRU specific commands:

```
Device# show logging profile wireless fru 0
```

# show logging profile wireless internal

To select all the logs, use the **show logging profile wireless internal** command.

## show logging profile wireless internal

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

<b>Usage Guidelines</b>	Ensure that you enable <b>internal</b> keyword using the <b>show logging profile wireless internal</b> command to get the trace output.
-------------------------	---

Without the **internal** keyword, only customer curated logs are displayed.

### Example

The following example shows how to display all the logs:

```
Device# show logging profile wireless internal
```

# show logging profile wireless level

To select logs above a specific level, use the **show logging profile wireless level** command.

```
show logging profile wireless level { debug | emergency | error | info | noise | notice | verbose | warning }

```

Syntax Description	Option	Description
	<b>debug</b>	Selects debug messages.
	<b>emergency</b>	Selects emergency possible messages.
	<b>error</b>	Selects error messages.
	<b>info</b>	Selects informational messages.
	<b>noise</b>	Selects maximum possible messages.
	<b>notice</b>	Selects notice messages.
	<b>verbose</b>	Selects verbose debug messages.
	<b>warning</b>	Selects warning messages.

**Command Default** None

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

**Usage Guidelines** Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

## Example

The following example shows how to select logs above a specific level:

```
Device# show logging profile wireless level info

```

# show logging profile wireless module

To select logs for specific modules, use the **show logging profile wireless module** command.

**show logging profile wireless module** *module-name*

<b>Syntax Description</b>	<i>module-name</i> A comma or space separated list of module names. For example, dbal, tdllib or "dbal tdllib".				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.10.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.				
<b>Usage Guidelines</b>	<p>Ensure that you enable <b>internal</b> keyword using the <b>show logging profile wireless internal</b> command to get the trace output.</p> <p>Without the <b>internal</b> keyword, only customer curated logs are displayed.</p>				

## Example

The following example shows how to select logs for specific modules:

```
Device# show logging profile wireless module dbal
```

# show logging profile wireless reverse

To view logs in reverse chronological order, use the **show logging profile wireless reverse** command.

**show logging profile wireless reverse**

---

**Syntax Description**

This command has no keywords or arguments.

---

**Command Default**

None

---

**Command Modes**

Privileged EXEC (#)

---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

---

**Usage Guidelines**

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

**Example**

The following example shows how to view logs in reverse chronological order:

```
Device# show logging profile wireless reverse
```

# show logging profile wireless start

To specify log filtering start location, use the **show logging profile wireless start** command.

**show logging profile wireless start** { **marker** *marker* | **timestamp** *time-stamp* }

## Syntax Description

**marker** The marker to start filtering from. It must match with previously set marker.

**timestamp** The timestamp for filtering. for example, "2017/02/10 14:41:50.849".

## Command Default

None

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

## Example

The following example shows how to specify log filtering start location:

```
Device# show logging profile wireless start timestamp 2017/02/10 14:41:50.849
```

# show logging profile wireless switch

To specify the switch to look for logs, use the **show logging profile wireless switch** command.

**show logging profile wireless switch** { *switch-num* | **active** | **standby** }

## Syntax Description

<i>chassis-num</i>	Chassis number.
<b>active</b>	Selects the active instance.
<b>standby</b>	Selects the standby instance.

## Command Default

None

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Usage Guidelines

Ensure that you enable **internal** keyword using the **show logging profile wireless internal** command to get the trace output.

Without the **internal** keyword, only customer curated logs are displayed.

## Example

The following example shows how to specify the chassis number to look for logs:

```
Device# show logging profile wireless switch active
```

# show logging profile wireless to-file

To decode files stored in disk and write the output to a file, use the **show logging profile wireless to-file** command.

**show logging profile wireless to-file** *output-file-name*

---

<b>Syntax Description</b>	<i>output-file-name</i> Output file name. File with this name will be created in the flash memory.
---------------------------	--

---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

---

<b>Usage Guidelines</b>	Ensure that you enable <b>internal</b> keyword using the <b>show logging profile wireless internal</b> command to get the trace output.
-------------------------	---

Without the **internal** keyword, only customer curated logs are displayed.

## Example

The following example shows how to decode files stored in disk and write the output to a file:

```
Device# show logging profile wireless to-file testfile
```



# show mdns-sd cache

To view mDNS cache details, use the **show mdns-sd cache** command.

```
show mdns-sd cache { ap-mac mac-address (H.H.H) | client-mac client-mac-address (H.H.H) |
detail | glan-id <1 - 5> | location-group <0 - 4096> | mdns-ap mdns-ap mac address (H.H.H)
| rlan-id <1 - 128> | statistics | type { A-AAAA | PTR | SRV | TXT } | udn
{ <1 - 4294967295> | shared } | wired | wlan-id <0 - 4096> }
```

## Syntax Description

<b>ap-mac</b> <i>mac-address (H.H.H)</i>	Specifies the AP Ethernet MAC address.
<b>client-mac</b> <i>client-mac-address (H.H.H)</i>	Specifies the client MAC address.
<b>detail</b>	Specifies the cache in detail.
<b>location-group</b> <i>&lt;0 - 4096&gt;</i>	Specifies the location group. The value range is from 0 to 4096.
<b>mdns-ap</b> <i>mdns-ap mac address (H.H.H)</i>	Specifies the cache learnt from a specific mDNS AP.
<b>rlan-id</b> <i>&lt;1 - 128&gt;</i>	Specifies the remote LAN ID. The value range is from 1 - 128.
<b>statistics</b>	Specifies the mDNS cache statistics.
<b>type</b>	Specifies the mDNS record type. The record types are, A-AAAA, PTR, SRV, and TXT.
<b>udn</b> <i>&lt;1 - 4294967295&gt;</i>	Specifies the UDN ID. The value range is from 1 to 4294967295.
<b>shared</b>	Specifies the UDN shared services.
<b>wired</b>	Specifies the mDNS services from wired clients.
<b>wlan-id</b> <i>&lt;0 - 4096&gt;</i>	Specifies the WLAN ID. The value range is from 1 to 4096.

## Command Default

None

## Command Modes

Privileged EXEC mode

## Command History

Release	Modification
Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

## Usage Guidelines

None

## Example

The following example shows how to view the mDNS cache details:

```
Device# show mdns-sd cache
```

# show mdns-sd cache detail

To view the multicast DNS (mDNS) cache details, use the **show mdns-sd cache detail** command.

## show mdns-sd cache detail

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

## Example

The following is sample output from the **show mdns-sd cache detail** command:

```
Device# show mdns-sd cache detail

Name: _printer._tcp.local
Type: PTR
TTL: 4500
VLAN: 21
Client MAC: ace2.d3bc.047e
Remaining-Time: 4383
mDNS Service Policy: default-mdns-service-policy
Rdata: HP OfficeJet Pro 8720 [BC047E] (2)._printer._tcp.local
```

# show mdns-sd cache upn shared

To view the multicast DNS (mDNS) cache user personal network shared services details, use the **show mdns-sd cache upn shared** command.

## show mdns-sd cache upn shared

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

### Example

The following is sample output from the **show mdns-sd cache upn shared** command that displays the mDNS cache UPN shared services details:

```
Device# show mdns-sd cache upn shared
----- PTR Records -----
RECORD-NAME                                TTL      TYPE      ID      CLIENT-MAC
RR-RECORD-DATA
-----
9.1.1.7.5.D.E.F.F.F.6.C.7.E.2.1.0.0.0.0.0.0 4500     WLAN      2       10e7.c6d5.7119
HP10E7C6D57119-2860.local
_services._dns-sd._udp.local                4500     WLAN      2       10e7.c6d5.7119
_ipps._tcp.local                             4500     WLAN      2       10e7.c6d5.7119
_universal._sub._ipps._tcp.local            4500     WLAN      2       10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipps._tcp._
_print._sub._ipps._tcp.local                4500     WLAN      2       10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipps._tcp._
_ePCL._sub._ipps._tcp.local                 4500     WLAN      2       10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipps._tcp._
_ipps._tcp.local                             4500     WLAN      2       10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipps._tcp._
_services._dns-sd._udp.local                4500     WLAN      2       10e7.c6d5.7119
_ipp._tcp.local                              4500     WLAN      2       10e7.c6d5.7119
_universal._sub._ipp._tcp.local             4500     WLAN      2       10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipp._tcp.l
_print._sub._ipp._tcp.local                 4500     WLAN      2       10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipp._tcp.l
_ePCL._sub._ipp._tcp.local                 4500     WLAN      2       10e7.c6d5.7119
HP DeskJet 5000 series [D57119] (3127)._ipp._tcp.l
.
.
.
----- SRV Records -----
RECORD-NAME                                TTL      TYPE      ID      CLIENT-MAC
```

## show mdns-sd cache upn shared

## RR-RECORD-DATA

HP DeskJet 5000 series [D57119] (3127)._ipp._	4500	WLAN	2	10e7.c6d5.7119	0
0 631 HP10E7C6D57119-2860.local					
HP DeskJet 5000 series [D57119] (3127)._http.	4500	WLAN	2	10e7.c6d5.7119	0
0 80 HP10E7C6D57119-2860.local					
HP DeskJet 5000 series [D57119] (3127)._ipps.	4500	WLAN	2	10e7.c6d5.7119	0
0 631 HP10E7C6D57119-2860.local					
HP DeskJet 5000 series [D57119] (3127)._uscan	4500	WLAN	2	10e7.c6d5.7119	0
0 8080 HP10E7C6D57119-2860.local					
HP DeskJet 5000 series [D57119] (3127)._prive	4500	WLAN	2	10e7.c6d5.7119	0
0 80 HP10E7C6D57119-2860.local					
HP DeskJet 5000 series [D57119] (3127)._uscan	4500	WLAN	2	10e7.c6d5.7119	0
0 443 HP10E7C6D57119-2860.local					
HP DeskJet 5000 series [D57119] (3127)._scann	4500	WLAN	2	10e7.c6d5.7119	0
0 8080 HP10E7C6D57119-2860.local					
HP DeskJet 5000 series [D57119] (3127)._pdl-d	4500	WLAN	2	10e7.c6d5.7119	0
0 9100 HP10E7C6D57119-2860.local					

## ----- A/AAAA Records

RECORD-NAME	TTL	TYPE	ID	CLIENT-MAC
RR-RECORD-DATA				
HP10E7C6D57119-2860.local	4500	WLAN	2	10e7.c6d5.7119
8.16.16.99				

## ----- TXT Records

RECORD-NAME	TTL	TYPE	ID	CLIENT-MAC
RR-RECORD-DATA				
HP DeskJet 5000 series [D57119] (3127)._ipp._	4500	WLAN	2	10e7.c6d5.7119
[502]'txtvers=1'adminurl=http://HP10E7C6D57119-28				
HP DeskJet 5000 series [D57119] (3127)._http.	4500	WLAN	2	10e7.c6d5.7119
[1]''				
HP DeskJet 5000 series [D57119] (3127)._ipps.	4500	WLAN	2	10e7.c6d5.7119
[502]'txtvers=1'adminurl=http://HP10E7C6D57119-28				
HP DeskJet 5000 series [D57119] (3127)._uscan	4500	WLAN	2	10e7.c6d5.7119
[280]'txtvers=1'adminurl=http://HP10E7C6D57119-28				
HP DeskJet 5000 series [D57119] (3127)._prive	4500	WLAN	2	10e7.c6d5.7119
[124]'txtvers=1'ty=HP DeskJet 5000 series [D57119				
HP DeskJet 5000 series [D57119] (3127)._uscan	4500	WLAN	2	10e7.c6d5.7119
[280]'txtvers=1'adminurl=http://HP10E7C6D57119-28				
HP DeskJet 5000 series [D57119] (3127)._scann	4500	WLAN	2	10e7.c6d5.7119
[177]'txtvers=1'adminurl=http://HP10E7C6D57119-28				
HP DeskJet 5000 series [D57119] (3127)._pdl-d	4500	WLAN	2	10e7.c6d5.7119
[211]'txtvers=1'rp='priority=40'UUID=9fe36149-9				

# show mdns-sd cache upn detail

To view the multicast DNS (mDNS) cache user personal network identifier details, use the **show mdns-sd cache upn detail** command.

## show mdns-sd cache upn *upn-id* detail

<b>Syntax Description</b>	<i>upn-id</i> User personal network identifier.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Amsterdam 17.1.1s</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.
Release	Modification				
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.				

## Example

The following is sample output from the **show mdns-sd cache upn detail** command that displays the mDNS cache UPN identifier details:

```
Device# show mdns-sd cache upn 777 detail
Name: _services._dns-sd._udp.local
Type: PTR
TTL: 4500
WLAN: 2
WLAN Name: mdns-psk
VLAN: 16
Client MAC: f4f9.51e2.a6a6
AP Ethernet MAC: 002a.1087.d68a
Remaining-Time: 4486
Site-Tag: default-site-tag
mDNS Service Policy: madhu-mDNS-Policy
Overriding mDNS Service Policy: NO
UPN-ID: 7777
UPN-Status: Enabled
Rdata: _airplay._tcp.local
```

# show mdns-sd flexconnect summary

To view the summary of the mDNS flexconnect sites, use the **show mdns-sd flexconnect summary** command.

## show mdns-sd flexconnect summary

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC mode
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

<b>Usage Guidelines</b>	None
-------------------------	------

### Example

The following example shows how to view the summary of mDNS flexconnect sites:

```
Device# show mdns-sd flexconnect summary
```

## show mdns-sd statistics

To view the mDNS statistics, use the **show mdns-sd statistics** command.

```
show mdns-sd statistics { debug | flexconnect | rlan-id <1 - 128> wired | wlan-id <1 - 4096>
}
```

Syntax Description	Option	Description
	<b>debug</b>	Specifies the mDNS debug statistics.
	<b>flexconnect</b>	Specifies the mDNS flexconnect statistics.
	<b>rlan-id</b> <1 - 128>	Specifies the remote LAN (RLAN) ID. The value range is from 1 to 128.
	<b>wired</b>	Specifies the mDNS wired statistics.
	<b>wlan-id</b> <1 - 4096>	Specifies the WLAN ID. The value range is from 1 to 4096.

**Command Default** None

**Command Modes** Privileged EXEC mode

Command History	Release	Modification
	Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

**Usage Guidelines** None

### Example

The following example shows how to view the mDNS statistics:

```
Device# show mdns-sd statistics
```

# show mdns-sd summary

To view the summary of mDNS service discovery configuration, use the **show mdns-sd summary** command.

**show mdns-sd summary**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC mode
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Amsterdam 17.3.1	This command was introduced.

<b>Usage Guidelines</b>	None
-------------------------	------

## Example

The following example shows how to view the summary of mDNS service discovery configuration:

```
Device# show mdns-sd summary
```



# show mobility

To display information about the Layer 3 mobility and the wireless network, use the **show mobility** command in privileged EXEC mode.

```
show mobility {ap [ip-address]|mn [ip ip-address]|mac mac-address|network network-id|status}
```

Syntax Description	Parameter	Description
	<b>ap</b>	Displays information about the access point.
	<i>ip-address</i>	(Optional) IP address.
	<b>mn</b>	Displays information about the mobile node.
	<b>ip</b> <i>ip-address</i>	(Optional) Displays information about the IP database thread.
	<b>mac</b> <i>mac-address</i>	Displays information about the MAC database thread.
	<b>network</b> <i>network-id</i>	Displays information for a specific wireless network ID.
	<b>status</b>	Displays status information.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	12.2(18)SXD	This command was introduced on the Supervisor Engine 720.
	12.2(18)SXD3	The output of this command was changed to include the TCP adjust-mss status.
	12.2(33)SRA	This command was integrated into Cisco IOS Release 12.2(33)SRA.

**Usage Guidelines** This command is supported on Cisco 7600 series routers that are configured with a WLSM only.

## Examples

This example shows how to display information about the access point:

```
Router# show mobility
  ap
AP IP Address    AP Mac Address Wireless Network-ID
-----
10.1.1.2 000d.29a2.a852 101 102 109 103
```

This example shows how to display information about the access points for a specific network ID:

```
Router# show mobility
  ap 172.16.1.2 detail
IP Address : 172.16.1.2
MAC Address : 000d.29a2.a852
Participating Wireless Tunnels: 101, 102, 109, 103
Registered Mobile Nodes on AP {172.16.1.2, 000d.29a2.a852} :
MN Mac Address MN IP Address AP IP Address Wireless Network-ID
-----
000a.8afa.85c9 10.1.3.11 172.16.1.2 103
```

```

000d.bdb7.83f7 10.1.2.11 172.16.1.2 102
000d.bdb7.83fb 10.1.1.11 172.16.1.2 101
Router# show mobility
  network-id 101
Wireless Network ID : 101
Wireless Tunnel Source IP Address : 10.1.1.1
Wireless Network Properties : Trusted
Wireless Network State : Up
Registered Access Point on Wireless Network 101:
AP IP Address AP Mac Address Wireless Network-ID
-----
176.16.1.2 000d.29a2.a852 101 102 109 103
Registered Mobile Nodes on Wireless Network 101:
MN Mac Address MN IP Address AP IP Address Wireless Network-ID
-----
000d.bdb7.83fb 10.1.1.11 176.16.1.2 101
Router# show mobility
  status
WLAN Module is located in Slot: 4 (HSRP State: Active) LCP
Communication status      : up
MAC address used for Proxy ARP: 0030.a349.d800
Number of Wireless Tunnels   : 1
Number of Access Points     : 2
Number of Mobile Nodes      : 0
Wireless Tunnel Bindings:
Src IP Address   Wireless Network-ID   Flags
-----
10.1.1.1         101                                   B
Flags: T=Trusted, B=IP Broadcast enabled, A=TCP Adjust-mss enabled

```

**Related Commands**

Command	Description
<b>mobility</b>	Configures the wireless mGRE tunnels.

# show nmosp

To display the Network Mobility Services Protocol (NMSP) configuration settings, use the **show nmosp** command.

```
show nmosp {attachment | {suppress interfaces} | capability | notification interval | statistics
{connection | summary} | status | subscription detail [ip-addr ] | summary}
```

Syntax Description		
<b>attachment suppress interfaces</b>		Displays attachment suppress interfaces.
<b>capability</b>		Displays NMSP capabilities.
<b>notification interval</b>		Displays the NMSP notification interval.
<b>statistics connection</b>		Displays all connection-specific counters.
<b>statistics summary</b>		Displays the NMSP counters.
<b>status</b>		Displays status of active NMSP connections.
<b>subscription detail ip-addr</b>		The details are only for the NMSP services subscribed to by a specific IP address.
<b>subscription summary</b>		Displays details for all of the NMSP services to which the controller is subscribed. The details are only for the NMSP services subscribed to by a specific IP address.

**Command Default** No default behavior or values.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show nmosp notification interval** command:

```
Device# show nmosp notification interval
NMSP Notification Intervals
-----

RSSI Interval:
  Client           : 2 sec
  RFID             : 2 sec
  Rogue AP         : 2 sec
  Rogue Client     : 2 sec
Attachment Interval : 30 sec
Location Interval  : 30 sec
```

# show nmosp cloud-services statistics

To see NMSP cloud-service statistics, use the **show nmosp cloud-services statistics** command.

**show nmosp cloud-services statistics** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description	
<i>chassis-number</i>	Chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the active NMSP cloud services in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the active NMSP cloud services in Route-processor slot 0.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

This example shows how to see NMSP cloud-service statistics:

```
Device# show nmosp cloud-services statistics
```

## show nmsp cloud-services summary

To see a summary of information about NMSP cloud-services, use the **show nmsp cloud-services summary** command.

**show nmsp cloud-services summary** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

### Syntax Description

*chassis-number* Chassis number as either 1 or 2.

**active R0** Active instance of the NMSP cloud services in Route-processor slot 0.

**standby R0** Standby instance of the active NMSP cloud services in Route-processor slot 0.

### Command Default

None

### Command Modes

Privileged EXEC

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

### Examples

This example shows how to see NMSP cloud-service summary information:

```
Device# show nmsp cloud-services summary
```

# show nmsp subscription group detail ap-list

To display the AP MAC list subscribed for a group by a CMX connection, use the **show nmsp subscription group detail ap-list** command.

**show nmsp subscription group detail ap-list** *group-name cmx-IP-address*

<b>Syntax Description</b>	<i>group-name</i>	CMX AP group name.
	<i>cmx-IP-address</i>	CMX IP address.
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Example

The following example shows how to verify the AP MAC list subscribed for a group by a CMX connection.

```
Device# show nmsp subscription group detail ap-list Group1 127.0.0.1

CMX IP address: 127.0.0.1
CMX Group name: Group1
CMX Group AP MACs:
: 00:00:00:00:70:02 00:00:00:00:66:02 00:99:00:00:00:02 00:00:00:bb:00:02
  00:00:00:00:55:02 00:00:00:00:50:02 00:33:00:00:00:02 00:d0:00:00:00:02
  00:10:00:10:00:02 00:00:00:06:00:02 00:00:00:02:00:02 00:00:00:00:40:02
  00:00:00:99:00:02 00:00:00:00:a0:02 00:00:77:00:00:02 00:22:00:00:00:02
  00:00:00:00:00:92 00:00:00:00:00:82 00:00:00:00:03:02 aa:00:00:00:00:02
  00:00:00:50:00:42 00:00:0d:00:00:02 00:00:00:00:00:32 00:00:00:cc:00:02
  00:00:00:88:00:02 20:00:00:00:00:02 10:00:00:00:00:02 01:00:00:00:00:02
  00:00:00:00:00:02 00:00:00:00:00:01 00:00:00:00:00:00
```

# show nmsp subscription group detail services

To display the services subscribed for a group by a CMX connection, use the **show nmsp subscription group detail services** command.

**show nmsp subscription group detail services** *group-name cmx-IP-address*

## Syntax Description

*group-name* CMX AP group name.

*cmx-IP-address* CMX IP address.

## Command Default

None

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Example

The following example shows how to verify the services subscribed for a group by a CMX connection.

```
Device# show nmsp subscription group detail services Group1 127.0.0.1

CMX IP address: 127.0.0.1
CMX Group name: Group1
CMX Group filtered services:
Service          Subservice
-----
RSSI              Mobile Station,
Spectrum
Info
Statistics
```

# show nmsp subscription group summary

To display the mobility services group subscription summary of all CMX connections, use the **show nmsp subscription group summary** command.

## show nmsp subscription group summary

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Example

The following example shows how to verify the mobility services group subscription summary of all CMX connections.

```
Device# show nmsp subscription group summary
CMX IP address: 127.0.0.1
Groups subscribed by this CMX server:
Group name: Group1
```



# show platform conditions

To see information about conditional debugs, use the **show platform conditions** command.

**show platform conditions**

---

**Command Default**

None

---

**Command Modes**

Privileged EXEC

---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

---

## Examples

The following example shows how to see information about conditional debugs:

```
Device# show platform conditions
```

# show platform hardware

To see the hardware platform Quantum flow processor datapath statistics, use the **show platform hardware chassis active qfp feature wireless wlclient datapath cpp-if-handle statistics** command.

**show hardware chassis active qfp feature wireless wlclient datapath cpp-if-handle** *client-cpp-value* **statistics** {**clear** | **start** | **stop**}

Syntax Description	active	Active instance.
	qfp	Quantum Flow Processor.
	wlclient	QFP wireless client.
	cpp-if-handle	client cpp interface handle.
	<i>client-cpp-value</i>	Client cpp if-handle value. The range is between 1 and 4294967295.
	statistics	Show Client Statistics.
	clear	Shows and Clears the Client Statistics.
	start	Start Client Statistics collection.
	stop	Stop Client Statistics collection.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to start client statistics collection:

```
Device# show platform hardware chassis active qfp feature wireless wlclient datapath
cpp-if-handle cpp-if-handle value statistics start
```

# show platform hardware chassis active qfp feature dns-snoop-agent client enabled-intf

To view the DSA enabled interfaces, use the **show platform hardware chassis active qfp feature dns-snoop-agent client enabled-intf** command.

```
show platform hardware chassis active qfp feature dns-snoop-agent client enabled-intf
```

---

**Syntax Description**

This command has no arguments.

---

---

**Command Default**

None

---

**Command Modes**

Global configuration

---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

---

This example shows how to view the DSA enabled interfaces:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent client enabled-intf
Interface name: GigabitEthernet0/0/0, handle: 5
```

# show platform hardware chassis active qfp feature dns-snoop-agent client hw-pattern-list

To view the OpenDNS string or FQDN filter for the pattern list, use the **show platform hardware chassis active qfp feature dns-snoop-agent client hw-pattern-list** command.

```
show platform hardware chassis active qfp feature dns-snoop-agent client hw-pattern-list
{fqdn-filter fqdn_filter_ID | odns_string}
```

<b>Syntax Description</b>	<b>fqdn-filter</b> Displays the FQDN filter for the pattern list.
	<i>fqdn_filter_ID</i> Refers to the FQDN filter ID. The valid range is from 1 to 16.
	<b>odns_string</b> Displays the OpenDNS string for the pattern list.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the FQDN filter for the pattern list:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent client
hw-pattern-list fqdn-filter 1
Filter Name: url1list_flex_preauth

Name: url1.dns.com
Feature mask: 16, Dirty: 0, Ref count: 0, Match count: 0
```

# show platform hardware chassis active qfp feature dns-snoop-agent client info

To view the DSA client details, use the **show platform hardware chassis active qfp feature dns-snoop-agent client info** command.

**show platform hardware chassis active qfp feature dns-snoop-agent client info**

## Syntax Description

This command has no arguments.

## Command Default

None

## Command Modes

Global configuration

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the DSA client details:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent client info
Number of patterns added/deleted/total: 2/0/2
Number of re_table rebuilt : : 0
Number of str_table rebuilt: : 2
Registered clients: 0x001ffff0
Number of transaction started/ended: 2/2
Memory pool size/limit: 512/81920
Pending Deletion Pattern List:
```

# show platform hardware chassis active qfp feature dns-snoop-agent client pattern-list

To view the OpenDNS string or FQDN filter for the pattern list, use the **show platform hardware chassis active qfp feature dns-snoop-agent client pattern-list** command.

```
show platform hardware chassis active qfp feature dns-snoop-agent client pattern-list {fqdn-filter
fqdn_filter_ID | odns_string}
```

<b>Syntax Description</b>	<b>fqdn-filter</b> Displays the FQDN filter for the pattern list.
	<b>fqdn_filter_ID</b> Refers to the FQDN filter ID. The valid range is from 1 to 16.
	<b>odns_string</b> Displays the OpenDNS string for the pattern list.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the FQDN filter for the pattern list:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent client pattern-list
fqdn-filter 1
Filter Name: url1list_flex_preauth
Pattern List in CPP client: 1

Name: url1.dns.com
feature_mask: 0x00000010, hw_ptr: 0xdf86d510
```

# show platform hardware chassis active qfp feature dns-snoop-agent datapath ip-cache

To view the DSA IP cache table details, use the **show platform hardware chassis active qfp feature dns-snoop-agent datapath ip-cache** command.

```
show platform hardware chassis active qfp feature dns-snoop-agent datapath ip-cache {address
[ipv4 ipv4_address | ipv6 ipv6_address] | all | pattern regex_pattern}
```

Syntax Description	address [ipv4 ipv4_address   ipv6 ipv6_address]	Displays the DSA address entry details
	<b>all</b>	Displays all the DSA IP cache address details
	<b>pattern</b> <i>regex_pattern</i>	Displays the DSA IP cache pattern details

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the DSA address entry details:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent datapath ip-cache
address ipv4 104.122.2.194
IP address: 104.122.2.194, client(s): 32, regex: www.adobe.com, expire in 0 seconds
```

This example shows how to view all the DSA IP cache address details:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent datapath ip-cache
all
IP Address          Client(s)  Expire    Match          RegexId      Dirty
-----
172.217.13.228     2          132      .*google.com   0x4d7f9e20   0x0
```

This example shows how to view the DSA IP cache pattern details:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent datapath ip-cache
pattern .*google*
1 IP Addresses matching pattern .*google*
IP Address          Client(s)  Expire    Match          RegexId      Dirty
-----
2607:f8b0:4004:800:0:0:2004  32         13       .*google*     0x31156220   0x0
```

# show platform hardware chassis active qfp feature dns-snoop-agent datapath memory

To view the DSA datapath memory details, use the **show platform hardware chassis active qfp feature dns-snoop-agent datapath memory** command.

**show platform hardware chassis active qfp feature dns-snoop-agent datapath memory**

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the DSA datapath memory details:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent datapath memory
Table-Name  Address      Size
-----
IP Cache DB  0xda5bb420  512
IP Hash      0xda41f400  1024
String Table 0xdec6ac10
String Table 0xda41f010

==DSA Chunk info==
Chunk-Pool  Allocated  Total_Free  Init-Num  Low_Wat
-----
ip cache chunk  0          512        512       512

==DSA Runtime Info==
-----
dsa init state 0x7   dsa client mask 0x100010
```



# show platform hardware chassis active qfp feature dns-snoop-agent datapath regexp-table

To view the DSA regular expression table, use the **show platform hardware chassis active qfp feature dns-snoop-agent datapath regexp-table** command.

**show platform hardware chassis active qfp feature dns-snoop-agent datapath regexp-table**

## Syntax Description

This command has no arguments.

## Command Default

None

## Command Modes

Global configuration

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the DSA regular expression table:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent datapath
regexp-table
String Table 0xdec6ac10      WLS_FQDN_GRP_1
String Table 0xda41f010      ODNS String
```

# show platform hardware chassis active qfp feature dns-snoop-agent datapath stats

To view the DSA statistics, use the **show platform hardware chassis active qfp feature dns-snoop-agent datapath stats** command.

**show platform hardware chassis active qfp feature dns-snoop-agent datapath stats**

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the DSA statistics:

```
Device# show platform hardware chassis active qfp feature dns-snoop-agent datapath stats
DNS Snoop Agent Stats:
  parser unknown pkt: 0
  parser not needed: 0
  parser fmt error: 0
  parser pa error: 0
  parser non resp: 0
  parser multiple name: 0
  parser dns name err: 0
  parser matched ip: 0
  parser redirect: 0
  parser whitelist redirect: 0
  parser blacklist redirect: 0
  parser invalid redirect ip: 0
  parser skip: 0
  regex locked: 0
  regex not matched: 0
  pkt drop whitelist no redirect ip: 0
  pkt drop blacklist no redirect ip: 0
  entries in use: 0
  ip cache allocation fail: 0
  ip addr add: 0
  ip addr update: 0
  ip addr delete: 0
  ip addr cache hit: 0
  ip addr cache miss: 0
  ip addr bad param: 0
  ip addr delete not found: 0
  ip cache not initialized: 0
```

# show platform hardware chassis active qfp feature et-analytics datapath runtime

To view the ETA global state in datapath, use the **show platform hardware chassis active qfp feature et-analytics datapath runtime** command.

**show platform hardware chassis active qfp feature et-analytics datapath runtime**

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

This example shows how to view the ETA global and interface details:

```
Device# show platform hardware chassis active qfp feature et-analytics datapath runtime
ET-Analytics run-time information:
  Feature state: initialized (0x00000004)
  Inactive timeout : 15 secs (default 15 secs)
  WhiteList information :
    flag: False
    cgacl w0 : n/a
    cgacl w1 : n/a
  Flow CFG information :
    instance ID : 0x0
    feature ID : 0x1
    feature object ID : 0x1
    chunk ID : 0xC
```

# show platform hardware chassis active qfp feature et-analytics datapath memory

To view the ETA memory details, use the **show platform hardware chassis active qfp feature et-analytics datapath memory** command.

**show platform hardware chassis active qfp feature et-analytics datapath memory**

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ETA memory details:

```
Device# show platform hardware chassis active qfp feature et-analytics datapath memory
ET-Analytics memory information:
  Size of FO : 3200 bytes
  No. of FO allocs : 0
  No. of FO frees : 0
```

# show platform hardware chassis active qfp feature et-analytics datapath stats export

To view the ETA flow export in datapath, use the **show platform hardware chassis active qfp feature et-analytics datapath stats export** command.

**show platform hardware chassis active qfp feature et-analytics datapath stats export**

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ETA flow export in datapath:

```
Device# show platform hardware chassis active qfp feature et-analytics datapath stats export
ET-Analytics 192.168.5.2:2055 vrf 0 Stats:
  Export statistics:
    Total records exported : 5179231
    Total packets exported : 3124873
    Total bytes exported : 3783900196
    Total dropped records : 0
    Total dropped packets : 0
    Total dropped bytes : 0
    Total IDP records exported :
      initiator->responder : 1285146
      responder->initiator : 979284
    Total SPLT records exported:
      initiator->responder : 1285146
      responder->initiator : 979284
    Total SALT records exported:
      initiator->responder : 0
      responder->initiator : 0
    Total BD records exported :
      initiator->responder : 0
      responder->initiator : 0
    Total TLS records exported :
      initiator->responder : 309937
      responder->initiator : 329469
```

# show platform hardware chassis active qfp feature et-analytics datapath stats flow

To view the ETA flow statistics, use the **show platform hardware chassis active qfp feature et-analytics datapath stats flow** command.

**show platform hardware chassis active qfp feature et-analytics datapath stats flow**

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ETA flow statistics:

```
Device# show platform hardware chassis active qfp feature et-analytics datapath stats flow
ET-Analytics Stats:
  Flow statistics:
    feature object allocs : 0
    feature object frees : 0
    flow create requests : 0
    flow create matching : 0
    flow create successful: 0
    flow create failed, CFT handle: 0
    flow create failed, getting FO: 0
    flow create failed, malloc FO : 0
    flow create failed, attach FO : 0
    flow create failed, match flow: 0
    flow create, aging already set: 0
    flow ageout requests : 0
    flow ageout failed, freeing FO: 0
    flow ipv4 ageout requests : 0
    flow ipv6 ageout requests : 0
    flow whitelist traffic match : 0
```

# show platform hardware chassis active qfp feature wireless et-analytics eta-pending-client-tree

To view clients in the ETA pending wireless client tree, use the **show platform hardware chassis active qfp feature wireless et-analytics eta-pending-client-tree** command.

**show platform hardware chassis active qfp feature wireless et-analytics eta-pending-client-tree**

**Syntax Description** This command has no arguments.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view clients in the ETA pending wireless client tree:

```
Device# show platform hardware chassis active qfp feature wireless et-analytics
eta-pending-client-tree
CPP IF_H      DPIDX      MAC Address  VLAN   AS  MS  WLAN      POA
-----
0X2A         0XA0000001  2c33.7a5b.827b  160   RN  LC  ewlc_ssid 0x90000003
0X2B         0XA0000002  2c33.7a5b.80fb  160   RN  LC  ewlc_ssid 0x90000003
```

# show platform hardware chassis active qfp feature wireless et-analytics statistics

To view the ETA pending wireless client tree statistics, use the **show platform hardware chassis active qfp feature wireless et-analytics statistics** command.

**show platform hardware chassis active qfp feature wireless et-analytics statistics**

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ETA pending wireless client tree statistics:

```
Device# show platform hardware chassis active qfp feature wireless et-analytics statistics
Wireless ETA cpp-client plumbing statistics
Number of ETA pending clients : 2
Counter                                     Value
-----
Enable ETA on wireless client called        0
Delete ETA on wireless client called        0
ETA global cfg init cb TVI FIA enable error 0
ETA global cfg init cb output SB read error 0
ETA global cfg init cb output SB write error 0
ETA global cfg init cb input SB read error  0
ETA global cfg init cb input SB write error 0
ETA global cfg init cb TVI FIA enable success 0
ETA global cfg uninit cb ingress feat disable 0
ETA global cfg uninit cb ingress cfg delete 0
ETA global cfg uninit cb egress feat disable 0
ETA global cfg uninit cb egress cfg delete er 0
ETA pending list insert entry called        4
ETA pending list insert invalid arg error   0
ETA pending list insert entry exists error  0
ETA pending list insert no memory error     0
ETA pending list insert entry failed        0
ETA pending list insert entry success       4
ETA pending list delete entry called        2
ETA pending list delete invalid arg error   0
ETA pending list delete entry missing       0
ETA pending list delete entry remove error  0
ETA pending list delete entry success       2
```



# show platform software audit

To display the Security Enhanced Linux (SELinux) audit logs, use the **show platform software audit** command in privileged EXEC mode.

**show platform software audit** {all | summary | 0 | 1 | 2 | F0 | R0 | FP active | RP active}

Syntax Description	
<b>all</b>	Shows the audit log from all the slots.
<b>summary</b>	Shows the audit log summary count from all the slots.
<b>0</b>	Shows the audit log for the SM-Inter-Processor slot 0.
<b>1</b>	Shows the audit log for the SM-Inter-Processor slot 1.
<b>2</b>	Shows the audit log for the SM-Inter-Processor slot 2.
<b>F0</b>	Shows the audit log for the Embedded-Service-Processor slot 0.
<b>R0</b>	Shows the audit log for the Route-Processor slot 0.
<b>FP active</b>	Shows the audit log for the active Embedded-Service-Processor slot.
<b>RP active</b>	Shows the audit log for the active Route-Processor slot.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced on Cisco ISR 4000 series routers, Cisco CSR 1000V series routers, and Cisco 1000 ISR series routers running time-sensitive networking (TSN).
	Cisco IOS XE Gibraltar 16.12.1	This command was implemented on Cisco Catalyst 9800 Series Wireless Controller.

**Usage Guidelines** The **show platform software audit** command displays the system logs containing the access violation events. In Cisco IOS XE Gibraltar 16.11.1, operation in a permissive mode is available - with the intent of confining specific components (process or application) of the IOS-XE platform. In the permissive mode, access violation events are detected and system logs are generated, but the event or operation itself is not blocked. The solution operates mainly in an access violation detection mode.

The following is a sample output of the **show software platform software audit summary** command:

```
Device# show platform software audit summary
=====
AUDIT LOG ON ACTIVE
-----
AVC Denial count: 7
```

The following is a sample output of the **show software platform software audit all** command. This command displays the information in the `audit.log` file.

```
Device# show platform software audit all
=====
AUDIT LOG ON ACTIVE
-----
===== START =====
type=DAEMON_START msg=audit(1553837190.262:3031): op=start ver=2.6.6 format=raw kernel=4.4.172
  auid=4294967295 pid=446 subj=system_u:system_r:auditd_t:s0 res=success
type=NETFILTER_CFG msg=audit(1553837185.956:2): table=nat family=2 entries=0
type=MAC_STATUS msg=audit(1553837186.523:3): enforcing=1 old_enforcing=0 auid=4294967295
ses=4294967295
type=SYSCALL msg=audit(1553837186.523:3): arch=c000003e syscall=1 success=yes exit=1 a0=3
a1=7ffcflc22070 a2=1 a3=0 items=0 ppid=203 pid=205 auid=4294967295 uid=0 gid=0 euid=0 suid=0
  fsuid=0 egid=0 sgid=0 fsgid=0 tty=(none) ses=4294967295 comm="load_policy"
exe="/usr/sbin/load_policy" subj=kernel key=(null)
type=PROCTITLE msg=audit(1553837186.523:3):
proctitle=2F7573722F7362696E2F6C6F61645F706F6C696379002D69
type=MAC_POLICY_LOAD msg=audit(1553837186.528:4): policy loaded auid=4294967295 ses=4294967295
type=SYSCALL msg=audit(1553837186.528:4): arch=c000003e syscall=1 success=yes exit=1693637
  a0=4 a1=7f792d1d6000 a2=19d7c5 a3=f items=0 ppid=203 pid=205 auid=4294967295 uid=0 gid=0
euid=0 suid=0 fsuid=0 egid=0 sgid=0 fsgid=0 tty=(none) ses=4294967295 comm="load_policy"
exe="/usr/sbin/load_policy" subj=system_u:system_r:kernel_t:s0 key=(null)
...

```

You can use the output of this command to copy the contents of `audit.log` to a file to then transfer to a remote host.

```
Device# show platform software audit all | redirect bootflash:audi_123.log

Device#dir bootflash:audi_123.log
Directory of bootflash:/audi_123.log
 27  -rw-          35305  Mar 29 2019 22:16:36 +00:00  audi_123.log

3249049600 bytes total (538112000 bytes free)

```

# show platform software system all

To check status of the current virtual machine and look for performance issues due to inadequate resources (or other issues with the hosting environment), use the **set platform software system all** command in privileged EXEC mode.

## show platform software system all

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Examples

This example shows how to check status of the current virtual machine and its resources:

```
Device# show platform software system all

Processor Details
=====
Number of Processors : 6
Processor : 1 - 6
vendor_id : GenuineIntel
cpu MHz : 2593.750
cache size : 35840 KB
Crypto Supported : Yes
model name : Intel(R) Xeon(R) CPU E5-2690 v4 @ 2.60GHz

Memory Details
=====
Physical Memory : 16363904KB

VNIC Details
=====
Name      Mac Address  Status Platform MTU
GigabitEthernet1 000c.2964.7126  UP 1500
GigabitEthernet2 000c.2964.7130  UP 1500

Hypervisor Details
=====
Hypervisor: VMWARE
Manufacturer: VMware, Inc.
Product Name: VMware Virtual Platform
Serial Number: VMware-56 4d e5 0a a7 dd 27 2b-0e 2f 36 6e 0f 64 71 26
UUID: 564DE50A-A7DD-272B-0E2F-366E0F647126
image_variant :

Boot Details
=====
Boot mode: BIOS
Bootloader version: 1.1
```

# show platform software trace filter-binary

To display the most recent trace information for a specific module, use the **show platform software trace filter-binary** command in privileged EXEC or user EXEC mode.

**show platform software trace filter-binary***modules* [**context** *mac-address*]

<b>Syntax Description</b>	<b>context</b> <i>mac-address</i>	Represents the context used to filter. Additionally, you can filter based on module names and trace levels. The context keyword accepts either a MAC address or any other argument based on which a trace is tagged.
---------------------------	-----------------------------------	--

<b>Command Modes</b>	User EXEC (>) Privileged EXEC (#)
----------------------	--------------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

<b>Usage Guidelines</b>	This command collates and sorts all the logs present in the <code>/tmp/.../</code> across all the processes relevant to the module. The trace logs of all the processes relevant to the specified module are printed to the console. This command also generates a file named <code>collated_log_{system time}</code> with the same content, in the <code>/crashinfo/tracelogs</code> directory.
-------------------------	--

<b>Examples</b>	This example shows how to display the trace information for a wireless module:
-----------------	--

```
Device# show platform software trace filter-binary wireless
```

# show platform software trace filter-binary

To display the most recent trace information for a specific module, use the **show platform software trace filter-binary** command in privileged EXEC or user EXEC mode.

```
show platform software trace filter-binary modules [context mac-address]
```

<b>Syntax Description</b>	<b>context</b> <i>mac-address</i>	Represents the context used to filter. Additionally, you can filter based on module names and trace levels. The context keyword accepts either a MAC address or any other argument based on which a trace is tagged.
---------------------------	-----------------------------------	--

<b>Command Modes</b>	User EXEC (>) Privileged EXEC (#)
----------------------	--------------------------------------

<b>Command History</b>	<b>Release</b> <b>Modification</b>
	This command was introduced.

<b>Usage Guidelines</b>	This command collates and sorts all the logs present in the <code>/tmp/...</code> across all the processes relevant to the module. The trace logs of all the processes relevant to the specified module are printed to the console. This command also generates a file named <code>collated_log_{system time}</code> with the same content, in the <code>/crashinfo/tracelogs</code> directory.
-------------------------	---

<b>Examples</b>	This example shows how to display the trace information for a wireless module:
-----------------	--

```
Device# show platform software trace filter-binary wireless
```

## show platform software trace level

To view the trace levels for all the modules under a specific process, use the **show platform software trace level** command in privileged EXEC or user EXEC mode.

**show platform software trace level wireless** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

---

### Syntax Description

*process*

Process whose tracing level is being set. Options include:

- **chassis-manager**—The Chassis Manager process.
  - **cli-agent**—The CLI Agent process.
  - **cmm**—The CMM process.
  - **dbm**—The Database Manager process.
  - **emd**—The Environmental Monitoring process.
  - **fed**—The Forwarding Engine Driver process.
  - **forwarding-manager**—The Forwarding Manager process.
  - **geo**—The Geo Manager process.
  - **host-manager**—The Host Manager process.
  - **interface-manager**—The Interface Manager process.
  - **iomd**—The Input/Output Module daemon (IOMd) process.
  - **ios**—The IOS process.
  - **license-manager**—The License Manager process.
  - **logger**—The Logging Manager process.
  - **platform-mgr**—The Platform Manager process.
  - **pluggable-services**—The Pluggable Services process.
  - **replication-mgr**—The Replication Manager process.
  - **shell-manager**—The Shell Manager process.
  - **sif**—The Stack Interface (SIF) Manager process.
  - **smd**—The Session Manager process.
  - **stack-mgr**—The Stack Manager process.
  - **table-manager**—The Table Manager Server.
  - **thread-test**—The Multithread Manager process.
  - **virt-manager**—The Virtualization Manager process.
  - **wireless**—The wireless controller module process.
-

<i>slot</i>	<p>Hardware slot where the process for which the trace level is set, is running. Options include:</p> <ul style="list-style-type: none"> <li>• <i>number</i>—Number of the SIP slot of the hardware module where the trace level is set. For instance, if you want to specify the SIP in SIP slot 2 of the switch, enter 2.</li> <li>• <i>SIP-slot / SPA-bay</i>—Number of the SIP switch slot and the number of the shared port adapter (SPA) bay of that SIP. For instance, if you want to specify the SPA in bay 2 of the SIP in switch slot 3, enter 3/2.</li> <li>• <b>F0</b>—The Embedded Service Processor in slot 0.</li> <li>• <b>F1</b>—The Embedded Service Processor in slot 1.</li> <li>• <b>FP active</b>—The active Embedded Service Processor.</li> <li>• <b>R0</b>—The route processor in slot 0.</li> <li>• <b>RP active</b>—The active route processor.</li> <li>• <b>switch &lt;number&gt;</b> —The switch, with its number specified.</li> <li>• <b>switch active</b>—The active switch.</li> <li>• <b>switch standby</b>—The standby switch. <ul style="list-style-type: none"> <li>• <i>number</i>—Number of the SIP slot of the hardware module where the trace level is set. For instance, if you want to specify the SIP in SIP slot 2 of the switch, enter 2.</li> <li>• <i>SIP-slot / SPA-bay</i>—Number of the SIP switch slot and the number of the shared port adapter (SPA) bay of that SIP. For instance, if you want to specify the SPA in bay 2 of the SIP in switch slot 3, enter 3/2.</li> <li>• <b>F0</b>—The Embedded Service Processor in slot 0.</li> <li>• <b>FP active</b>—The active Embedded Service Processor.</li> <li>• <b>R0</b>—The route processor in slot 0.</li> <li>• <b>RP active</b>—The active route processor.</li> </ul> </li> </ul>
-------------	---

**Syntax Description**

<i>chassis-number</i>	Chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the AP filters in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the AP filters in Route-processor slot 0.

**Command Modes**

User EXEC (>)  
Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

### Examples

This example shows how to view the trace level:

```
Device# show platform software trace level dbm switch active R0
Module Name                               Trace Level
-----
binos                                       Notice
binos/brand                               Notice
bipc                                       Notice
btrace                                     Notice
bump_ptr_alloc                             Notice
cdllib                                     Notice
chasfs                                     Notice
dbal                                       Informational
dbm                                         Debug
evlib                                       Notice
evutil                                     Notice
file_alloc                                 Notice
green-be                                   Notice
ios-avl                                    Notice
klib                                        Debug
services                                   Notice
sw_wdog                                    Notice
syshw                                       Notice
tdl_cdlcore_message                       Notice
tdl_dbal_root_message                     Notice
tdl_dbal_root_type                         Notice
```



# show platform software trace message

To display the trace messages for a process, use the **set platform software trace** command in privileged EXEC or user EXEC mode.

**show platform software trace message** *process slot*

**Command Modes**

User EXEC (>)

Privileged EXEC (#)

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Examples

This example shows how to display the trace messages for the Stack Manager and the Forwarding Engine Driver processes:

```
Device# show platform software trace message stack_mgr switch active R0
10/30 09:42:48.767 [btrace] [8974]: (note): Successfully registered module [97] [uiutil]
10/30 09:42:48.762 [btrace] [8974]: (note): Successfully registered module [98]
[tdl_cdlcore_message]
10/29 13:28:19.023 [stack_mgr] [8974]: (note): Examining peer state
10/29 13:28:19.023 [stack_mgr] [8974]: (note): no switch eligible for standby election
presently
10/29 13:28:19.022 [stack_mgr] [8974]: (note): Posting event
stack_fsm_event_wait_standby_elect_timer_expired, curstate stack_fsm_state_active_ready
10/29 13:28:19.022 [stack_mgr] [8974]: (note): Timer HDL - STACK_WAIT_STANDBY_ELECT_TIMER
expired
10/29 13:26:46.584 [btrace] [8974]: (note): Successfully registered module [99]
[tdl_ui_message]
10/29 13:26:46.582 [bipc] [8974]: (note): Pending connection to server 10.129.1.0
10/29 13:26:36.582 [evutil] [8974]: (ERR): Connection attempt for sman-ui-serv (uipeer
uplink to slot 1) failed, invoking disconnect
10/29 13:26:36.582 [evutil] [8974]: (ERR): Asynchronous connect failed for [uipeer uplink
to slot 1] (fd == -1)
10/29 13:26:36.581 [bipc] [8974]: (note): Pending connection to server 10.129.1.0
10/29 13:26:26.581 [evutil] [8974]: (ERR): Connection attempt for sman-ui-serv (uipeer
uplink to slot 1) failed, invoking disconnect

Device# show platform software trace message fed switch active
11/02 10:55:01.832 [btrace]: [11310]: UUID: 0, ra: 0 (note): Successfully registered module
[86] [uiutil]
11/02 10:55:01.848 [btrace]: [11310]: UUID: 0, ra: 0 (note): Single message size is greater
than 1024
11/02 10:55:01.822 [btrace]: [11310]: UUID: 0, ra: 0 (note): Successfully registered module
[87] [tdl_cdlcore_message]
11/01 09:54:41.474 [btrace]: [12312]: UUID: 0, ra: 0 (note): Successfully registered module
[88] [tdl_ngwc_gold_message]
11/01 09:54:11.228 [btrace]: [12312]: UUID: 0, ra: 0 (note): Successfully registered module
[89] [tdl_doppler_iosd_matm_type]
11/01 09:53:37.454 [btrace]: [11310]: UUID: 0, ra: 0 (note): Successfully registered module
[90] [tdl_ui_message]
11/01 09:53:37.382 [bipc]: [11310]: UUID: 0, ra: 0 (note): Pending connection to server
10.129.1.0
11/01 09:53:34.227 [xcvr]: [18846]: UUID: 0, ra: 0 (ERR): FRU hardware authentication Fail,
```

```
result = 1.  
11/01 09:53:33.775 [ng3k_scc]: [18846]: UUID: 0, ra: 0 (ERR): SMART COOKIE: SCC I2C receive  
failed: rc=10  
11/01 09:53:33.775 [ng3k_scc]: [18846]: UUID: 0, ra: 0 (ERR):  
SMART COOKIE receive failed, try again  
11/01 09:53:33.585 [ng3k_scc]: [18846]: UUID: 0, ra: 0 (ERR):
```

# show platform software trace message license-manager chassis active R0

To display the trace message for license-manager process of active route processor, use the **show platform software trace message license-manager chassis active R0** command in privileged EXEC mode.

```
show platform software trace message license-manager chassis {chassis-number
| active | standby}R0reverse
```

This command has no arguments or keywords.

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Example

This example shows how to display the trace messages for the Forwarding Engine Driver processes:

```
Device# show platform software trace message license-manager chassis active R0
.....
2018/06/25 07:16:53.121 {lman_R0-0}{1}: [btrace] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Decode of the file /tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy completed in 35
msecs
/tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy: DECODE(50:50:0:7)
2018/06/25 07:16:53.088 {lman_R0-0}{1}: [btrace] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Decode of file [/tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy] returned [0]
2018/06/25 06:53:20.421 {lman_R0-0}{1}: [btrace] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Decode of the file /tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy completed in 34
msecs
2018/06/25 06:53:20.389 {lman_R0-0}{1}: [btrace] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Decode of file [/tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy] returned [0]
2018/06/20 07:55:10.540 {lman_R0-0}{1}: [trccfg] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Processing all-modules
2018/06/20 07:55:10.540 {lman_R0-0}{1}: [trccfg] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Empty trace conf file
2018/06/20 07:54:46.453 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Constructing domain iosd_lmrp for RP/0/0 to RP/0/0
2018/06/20 07:54:46.453 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Received registration msg from [IOS]
2018/06/20 07:54:46.449 {lman_R0-0}{1}: [bipc] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Received a connection from client for path /tmp/rp/lipc/license_mgr_socket
2018/06/20 07:54:45.557 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:44.556 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:43.556 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:42.555 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:41.554 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
```

## show platform software trace message license-manager chassis active R0

```

2018/06/20 07:54:40.553 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:39.553 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:38.552 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:37.551 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:36.550 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:35.550 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:34.549 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:33.548 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:32.547 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:31.547 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:30.547 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:30.537 {lman_R0-0}{1}: [bipc] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Pending connection to server 10.0.1.0
2018/06/20 07:54:29.546 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:28.545 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:27.545 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:26.544 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:25.543 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:24.542 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:23.542 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:22.541 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:21.540 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:20.633 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): Peer
attach: from location R0:0 is successful
2018/06/20 07:54:20.633 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): Not
setting domain for cmand
2018/06/20 07:54:20.625 {lman_R0-0}{1}: [bipc] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Received a connection from client for path /tmp/rp/lipc/lman_lic_serv_socket
2018/06/20 07:54:20.624 {lman_R0-0}{1}: [tdllib] [21231]: UUID: 0, ra: 0, TID: 0 (note):
epoch file read /tmp/tldlresolve/epoch_dir//2018_06_20_07_54_2413.epoch
2018/06/20 07:54:20.624 {lman_R0-0}{1}: [tdllib] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Detect newly epoch file generated: new epoch:
/tmp/tldlresolve/epoch_dir//2018_06_20_07_54_2413.epoch
2018/06/20 07:54:20.624 {lman_R0-0}{1}: [tdllib] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Flag tdlh stale epoch for all tdl handles
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Chasfs Watch on rp/0/0/rtu_licensing for platform to create RTU properties
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): The
chassis product id: 'ISR4461/K9'
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): The
chassis serial number: 'FDO2213A0GL'
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [bcrdu] [21231]: UUID: 0, ra: 0, TID: 0 (note):
CRDU
/tmp/sw/mount/isr4400v2-mono-universalk9.BLD_V169_THROTTLE_LATEST_20180618_044856_V16_9_0_163.SSA.pkg/usr/binos/bin/lman

```

```
proc path is /tmp/patch/CRDU/BPROC_LM_RP/
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [bcrdu] [21231]: UUID: 0, ra: 0, TID: 0 (note):
CRDU
/tmp/sw/mount/isr4400v2-mono-universalk9.ELD_V169_THROTTLE_LATEST_20180618_044856_V16_9_0_163.SSA.pkg/usr/binos/bin/lman
procstr is BPROC_LM_RP
2018/06/20 07:54:20.533 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): No
licensing objects present in chasfs to delete
2018/06/20 07:54:20.533 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Deleting any existing licensing chasfs objects under [rp/0/0/licensing]
2018/06/20 07:54:20.532 {lman_R0-0}{1}: [syshw] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): syshw
build device: could not add register 7 dev:
/sys/bus/platform/devices/cpld/reg_rp_sku_register (No such file or directory) due to No
such file or directory
2018/06/20 07:54:20.532 {lman_R0-0}{1}: [syshw] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): syshw
build device: could not add register 5 dev: /sys/bus/platform/devices/cpld/phys_slot_number
(No such file or directory) due to No such file or directory

Total messages : 49
```

# show platform software trace message license-manager

To display the trace message for license-manager process of router processor, use the **show platform software trace message license-manager** command in privileged EXEC mode.

**show platform software trace message license-manager** [ **chassis** { *chassis-number* | **active** | **standby** } **R0** ]

Syntax Description	
<b>active R0</b>	Active instance in Route-processor slot 0.
<b>standby R0</b>	Standby instance in Route-processor slot 0.

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.12.2s	This command was introduced.

## Example

This example shows how to display the trace messages for the Forwarding Engine Driver processes:

```
Device# show platform software trace message license-manager chassis active R0
.....
2018/06/25 06:53:20.421 {lman_R0-0}{1}: [btrace] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Decode of the file /tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy completed in 34
msecs
/tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy: DECODE(48:48:0:7)
2018/06/25 06:53:20.389 {lman_R0-0}{1}: [btrace] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Decode of file [/tmp/rp/trace/lman_R0-0.21231_0.20180620075420.bin.copy] returned [0]
2018/06/20 07:55:10.540 {lman_R0-0}{1}: [trccfg] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Processing all-modules
2018/06/20 07:55:10.540 {lman_R0-0}{1}: [trccfg] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Empty trace conf file
2018/06/20 07:54:46.453 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Constructing domain iosd_lmrp for RP/0/0 to RP/0/0
2018/06/20 07:54:46.453 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Received registration msg from [IOS]
2018/06/20 07:54:46.449 {lman_R0-0}{1}: [bipc] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Received a connection from client for path /tmp/rp/lipc/license_mgr_socket
2018/06/20 07:54:45.557 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:44.556 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:43.556 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:42.555 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:41.554 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:40.553 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:39.553 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
```

```

2018/06/20 07:54:38.552 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:37.551 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:36.550 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:35.550 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:34.549 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:33.548 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:32.547 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:31.547 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:30.547 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:30.537 {lman_R0-0}{1}: [bipc] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Pending connection to server 10.0.1.0
2018/06/20 07:54:29.546 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:28.545 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:27.545 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:26.544 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:25.543 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:24.542 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:23.542 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:22.541 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:21.540 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): The
ipc information for IOS is invalid
2018/06/20 07:54:20.633 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): Peer
attach: from location R0:0 is successful
2018/06/20 07:54:20.633 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): Not
setting domain for cmand
2018/06/20 07:54:20.625 {lman_R0-0}{1}: [bipc] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Received a connection from client for path /tmp/rp/lipc/lman_lic_serv_socket
2018/06/20 07:54:20.624 {lman_R0-0}{1}: [tdllib] [21231]: UUID: 0, ra: 0, TID: 0 (note):
epoch file read /tmp/tdlresolve/epoch_dir//2018_06_20_07_54_2413.epoch
2018/06/20 07:54:20.624 {lman_R0-0}{1}: [tdllib] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Detect newly epoch file generated: new epoch:
/tmp/tdlresolve/epoch_dir//2018_06_20_07_54_2413.epoch
2018/06/20 07:54:20.624 {lman_R0-0}{1}: [tdllib] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Flag tdlh stale epoch for all tdl handles
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Chasfs Watch on rp/0/0/rtu_licensing for platform to create RTU properties
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): The
chassis product id: 'ISR4461/K9'
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): The
chassis serial number: 'FDO2213A0GL'
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [bcrdu] [21231]: UUID: 0, ra: 0, TID: 0 (note):
CRDU
/tmp/sw/mount/isr4400v2-mono-universalk9.BLD_V169_THROTTLE_LATEST_20180618_044856_V16_9_0_163.SSA.pkg/usr/binos/bin/lman
proc path is /tmp/patch/CRDU/BPROC_LM_RP/
2018/06/20 07:54:20.536 {lman_R0-0}{1}: [bcrdu] [21231]: UUID: 0, ra: 0, TID: 0 (note):
CRDU
/tmp/sw/mount/isr4400v2-mono-universalk9.BLD_V169_THROTTLE_LATEST_20180618_044856_V16_9_0_163.SSA.pkg/usr/binos/bin/lman

```

```
procstr is BPROC_LM_RP
2018/06/20 07:54:20.533 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note): No
licensing objects present in chasfs to delete
2018/06/20 07:54:20.533 {lman_R0-0}{1}: [lman] [21231]: UUID: 0, ra: 0, TID: 0 (note):
Deleting any existing licensing chasfs objects under [rp/0/0/licensing]
2018/06/20 07:54:20.532 {lman_R0-0}{1}: [syshw] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): syshw
build device: could not add register 7 dev:
/sys/bus/platform/devices/cpld/reg_rp_sku_register (No such file or directory) due to No
such file or directory
2018/06/20 07:54:20.532 {lman_R0-0}{1}: [syshw] [21231]: UUID: 0, ra: 0, TID: 0 (ERR): syshw
build device: could not add register 5 dev: /sys/bus/platform/devices/cpld/phys_slot_number
(No such file or directory) due to No such file or directory
```



# show platform software utd chassis active F0 et-analytics global

To view the ETA global and interface details, use the **show platform software utd chassis active F0 et-analytics global** command.

```
show platform software utd chassis active F0 et-analytics global
```

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ETA global and interface details:

```
Device# show platform software utd chassis active F0 et-analytics global
ET Analytics Global Configuration
ID: 1
All Interfaces: Off
IP address and port and vrf: 192.168.5.2:2055:0
```

# show platform software et-analytics global

To view the ETA global configuration, use the **show platform software et-analytics global** command.



**Note** The **show platform software et-analytics global** command does not display the ETA enabled wireless client interfaces.

**show platform software et-analytics global**

**Syntax Description** This command has no arguments.

**Command Default** None

**Command Modes** Global configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ETA global and interface details:

```
Device# show platform software et-analytics global
ET-Analytics Global state
=====
All Interfaces : Off
IP Flow-record Destination: 192.168.5.2 : 2055
Inactive timer: 15
```

# show parameter-map type umbrella global

To view the Umbrella global parameter map details, use the **show parameter-map type umbrella global** command.

**show parameter-map type umbrella global**

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the Umbrella global parameter map details:

```
Device# show parameter-map type umbrella global
parameter-map type umbrella global
  token 57CC80106C087FB1B2A7BAB4F2F4373C00247166
  local-domain dns_wl
  dnscrypt
  udp-timeout 2
  resolver ipv4 208.67.220.220
  resolver ipv4 208.67.222.222
  resolver ipv6 2620:119:53::53
  resolver ipv6 2620:119:35::35
```

# show policy-map

To display quality of service (QoS) policy maps, which define classification criteria for incoming traffic, use the **show policy-map** command in EXEC mode.

```
show policy-map [{policy-map-name | interface interface-id}]
```

```
show policy-map interface {Auto-template | Capwap | GigabitEthernet | GroupVI |
InternalInterface | Loopback | Lspvif | Null | Port-channel | TenGigabitEthernet | Tunnel
| Vlan | brief | class | input | output}
```

```
show policy-map interface {ap name ap_name | client mac mac_address | radio type {24ghz |
5ghz} ap name ap_name | ssid name ssid_name {ap name ap_name | radio type {24ghz | 5ghz}
ap name ap_name}}
```

Syntax Description		
	<i>policy-map-name</i>	(Optional) Name of the policy-map.
	<b>interface</b> <i>interface-id</i>	(Optional) Displays the statistics and the configurations of the input and output policies that are attached to the interface.
	<b>ap name</b> <i>ap_name</i>	Displays SSID policy configuration of an access point.
	<b>client mac</b> <i>mac_address</i>	Displays information about the policies for all the client targets.
	<b>radio type</b> {24ghz   5ghz}	Displays policy configuration of the access point in the specified radio type.
	<b>ssid name</b> <i>ssid_name</i>	Displays policy configuration of an SSID.

Command Modes	
	User EXEC
	Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

Usage Guidelines	
	Policy maps can include policers that specify the bandwidth limitations and the action to take if the limits are exceeded.



**Note** Though visible in the command-line help string, the **control-plane**, **session**, and **type** keywords are not supported, and the statistics shown in the display should be ignored.

To display classification counters for ternary content addressable memory (TCAM) (marking or policing) based policies, enter the interface ID. Classification counters have the following restrictions:

- Classification counters are supported only on wired ports (in the ingress and egress directions).
- Classification counters count packets instead of bytes.
- Only QoS configurations with marking or policing trigger the classification counter.
- As long as there is policing or marking action in the policy, the class-default will have classification counters.
- Classification counters are not port based. The counters are shared across targets sharing the same policy map. This means that the classification counter aggregates all packets belonging to the same class of the same policy which attach to different interfaces.

This is an example of output from the **show policy-map interface** command, where classification counters are displayed:

```
Device# show policy-map interface gigabitethernet1/0/1

GigabitEthernet1/0/1

Service-policy input: AutoQos-4.0-CiscoPhone-Input-Policy

Class-map: AutoQos-4.0-Voip-Data-CiscoPhone-Class (match-any)
  0 packets
  Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp ef
  police:
    cir 128000 bps, bc 8000 bytes
    conformed 0 bytes; actions:
      transmit
    exceeded 0 bytes; actions:
      set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps

Class-map: AutoQos-4.0-Voip-Signal-CiscoPhone-Class (match-any)
  0 packets
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp cs3
  police:
    cir 32000 bps, bc 8000 bytes
    conformed 0 bytes; actions:
      transmit
    exceeded 0 bytes; actions:
      set-dscp-transmit dscp table policed-dscp
    conformed 0000 bps, exceed 0000 bps
```

```

Class-map: AutoQos-4.0-Default-Class (match-any)
  0 packets
  Match: access-group name AutoQos-4.0-Acl-Default
    0 packets, 0 bytes
    5 minute rate 0 bps
  QoS Set
    dscp default

Class-map: class-default (match-any)
  0 packets
  Match: any
    0 packets, 0 bytes
    5 minute rate 0 bps

Service-policy output: AutoQos-4.0-Output-Policy

queue stats for all priority classes:
  Queueing
  priority level 1

  (total drops) 0
  (bytes output) 0

Class-map: AutoQos-4.0-Output-Priority-Queue (match-any)
  0 packets
  Match: dscp cs4 (32) cs5 (40) ef (46)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 5
    0 packets, 0 bytes
    5 minute rate 0 bps
  Priority: 30% (300000 kbps), burst bytes 7500000,

  Priority Level: 1

Class-map: AutoQos-4.0-Output-Control-Mgmt-Queue (match-any)
  0 packets
  Match: dscp cs2 (16) cs3 (24) cs6 (48) cs7 (56)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 3
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing
  queue-limit dscp 16 percent 80
  queue-limit dscp 24 percent 90
  queue-limit dscp 48 percent 100
  queue-limit dscp 56 percent 100

  (total drops) 0
  (bytes output) 0
  bandwidth remaining 10%

  queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Conf-Queue (match-any)
  0 packets
  Match: dscp af41 (34) af42 (36) af43 (38)
    0 packets, 0 bytes
    5 minute rate 0 bps
  Match: cos 4
    0 packets, 0 bytes
    5 minute rate 0 bps
  Queueing

```

```
(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Trans-Data-Queue (match-any)
 0 packets
Match: dscp af21 (18) af22 (20) af23 (22)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 2
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Bulk-Data-Queue (match-any)
 0 packets
Match: dscp af11 (10) af12 (12) af13 (14)
 0 packets, 0 bytes
 5 minute rate 0 bps
Match: cos 1
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 4%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Scavenger-Queue (match-any)
 0 packets
Match: dscp cs1 (8)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 1%
queue-buffers ratio 10

Class-map: AutoQos-4.0-Output-Multimedia-Strm-Queue (match-any)
 0 packets
Match: dscp af31 (26) af32 (28) af33 (30)
 0 packets, 0 bytes
 5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 10%
queue-buffers ratio 10

Class-map: class-default (match-any)
 0 packets
Match: any
 0 packets, 0 bytes
```

```
5 minute rate 0 bps
Queueing

(total drops) 0
(bytes output) 0
bandwidth remaining 25%
queue-buffers ratio 25
```



# show remote-lan all

To view the detailed output of all RLANs, use the **show remote-lan all** command.

**show remote-lan all**

**Command Default**

None

**Command Modes**

Global configuration

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the detailed output of all RLANs:

```

Device# show remote-lan all
Remote-LAN Profile Name      : rlan_test_1
=====
Identifier                   : 1
Status                       : Enabled
Mac-filtering                : Not Configured
Number of Active Clients     : 1
Security_8021X               : Disabled
8021.x Authentication list name : Not Configured
Local Auth eap Profile Name  : Not Configured
Web Auth Security           : Disabled
Webauth Authentication list name : Not Configured
Web Auth Parameter Map      : Not Configured
Client association limit     : 0
Ipv4 Web Pre Auth Acl       : Not Configured
Ipv6 Web Pre Auth Acl       : Not Configured

Remote-LAN Profile Name      : rlan_test_2
=====
Identifier                   : 2
Status                       : Enabled
Mac-filtering                : Not Configured
Number of Active Clients     : 1
Security_8021X               : Disabled
8021.x Authentication list name : Not Configured
Local Auth eap Profile Name  : Not Configured
Web Auth Security           : Disabled
Webauth Authentication list name : Not Configured
Web Auth Parameter Map      : Not Configured
Client association limit     : 0
Ipv4 Web Pre Auth Acl       : Not Configured
Ipv6 Web Pre Auth Acl       : Not Configured
    
```

## show remote-lan id

To view the RLAN configuration by ID, use the **show remote-lan id** command.

**show remote-lan id** *id*

---

**Command Default**    None

---

**Command Modes**    Global configuration

---

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

---

This example shows how to view the RLAN configuration by ID:

```
Device# show remote-lan id <id>
Remote-LAN Profile Name      : rlan_test_1
=====
Identifier                    : 1
Status                       : Enabled
Mac-filtering                 : Not Configured
Number of Active Clients      : 1
Security_8021X                : Disabled
8021.x Authentication list name : Not Configured
Local Auth eap Profile Name   : Not Configured
Web Auth Security             : Disabled
Webauth Authentication list name : Not Configured
Web Auth Parameter Map        : Not Configured
Client association limit       : 0
Ipv4 Web Pre Auth Acl         : Not Configured
Ipv6 Web Pre Auth Acl         : Not Configured
```

## show remote-lan name

To view the RLAN configuration by profile name, use the **show remote-lan name** command.

**show remote-lan name** *profile-name*

---

**Command Default**

None

---

**Command Modes**

Global configuration

---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the RLAN configuration by profile name:

```
Device# show remote-lan name <profile-name>
Remote-LAN Profile Name      : rlan_test_1
=====
Identifier                    : 1
Status                        : Enabled
Mac-filtering                 : Not Configured
Number of Active Clients      : 1
Security_8021X                : Disabled
8021.x Authentication list name : Not Configured
Local Auth eap Profile Name   : Not Configured
Web Auth Security             : Disabled
Webauth Authentication list name : Not Configured
Web Auth Parameter Map        : Not Configured
Client association limit       : 0
Ipv4 Web Pre Auth Acl         : Not Configured
Ipv6 Web Pre Auth Acl         : Not Configured
```

## show remote-lan policy detail

To view the RLAN policy profile details by profile name, use the **show remote-lan policy detail** command.

**show remote-lan policy detail** *rlan\_profile\_name*

<b>Command Default</b>	None				
<b>Command Modes</b>	Global configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.10.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.				

This example shows how to view the RLAN policy profile details by profile name:

```
Device# show remote-lan policy detail <rlan_profile_name>
Profile Name           : rlan_named_pp1
Status                 : Enabled
Description            :
REMOTE-LAN ACL
  IPv4 ACL name        : Not Configured
  IPv6 ACL name        : Not Configured
AAA Policy Params
  AAA Override         : Disabled
  AAA Policy name      : default-aaa-policy
RLAN Switching policy
  Central Switching    : Enabled
  Central Dhcp         : Enabled
VLAN                   : 20
Pre Authentication     : Disabled
Session Time out      : 1800
Violation Mode         : REPLACE
Host Mode              : SINGLE_HOST_MODE
Host mode VLANs
  Voice Vlan Id        : Not Configured
  Data Vlan Id         : Not Configured
Exclusionlist Params
  Exclusionlist         : Enabled
  Exclusion Timeout     : 60
Flow Monitor IPv4
  Flow Monitor Ingress Name : Not Configured
  Flow Monitor Egress Name  : Not Configured
  Flow Monitor Ingress status : Disabled
  Flow Monitor egress status : Disabled
Flow Monitor IPv6
  Flow Monitor Ingress Name : Not Configured
  Flow Monitor Egress Name  : Not Configured
  Flow Monitor Ingress status : Disabled
  Flow Monitor egress status : Disabled
Split Tunnel Parameters
  Status               : Disabled
  ACL name             : Not Configured
  Override Status      : Disabled
  Gateway Address      : Not Configured
  Netmask Address      : Not Configured
DHCP
```

```
DHCP Required           : Disabled
DHCP Server            : Not Configured
Accounting List        : Not Configured
```

# show remote-lan policy summary

To view the summary of policy profile for all RLANs, use the **show remote-lan policy summary** command.

**show remote-lan policy summary**

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the summary of policy profile for all RLANs:

```
Device# show remote-lan policy summary
Number of Policy Profiles: 1
```

Profile Name	Description	Status
rlan_named_pp1	Testing RLAN policy profile	Enabled

# show remote-lan summary

To view the summary of all RLANs, use the **show remote-lan summary** command.

**show remote-lan summary**

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the summary of all RLANs:

```
Device# show remote-lan summary
Number of RLANs: 1
```

RLAN	Profile Name	Status
1	rlan_test_1	Enabled

# show ssh

To see the SSH connection status, use the **show ssh** command.

```
show ssh {connection-number | {vtty connection-number } }
```

---

## Syntax Description

*connection-number* SSH connection number. Valid range is 0 to 530.

---

## Command Default

None

## Command Modes

Privileged EXEC

---

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

---

## Examples

The following example shows how to see the SSH connection status:

```
Device# show ssh connection-number
```



# show tech-support wireless

To display Cisco wireless LAN controller variables frequently requested by Cisco Technical Assistance Center (TAC), use the **show tech-support wireless** command in privileged EXEC mode.

## show tech-support wireless

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behavior or values.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show tech-support wireless** command:

```

Device# show tech-support wireless
*** show ap capwap timers ***

Cisco AP CAPWAP timers

AP Discovery timer           : 10
AP Heart Beat timeout       : 30
Primary Discovery timer     : 120
Primed Join timeout         : 0
Fast Heartbeat               : Disabled
Fast Heartbeat timeout      : 1
*** show ap capwap retransmit ***
Global control packet retransmit interval : 3
Global control packet retransmit count : 5

AP Name                      Retransmit Interval      Retransmit Count
-----
TSIM_AP-2                    3                          5
TSIM_AP-3                    3                          5
*** show ap dot11 24ghz cleanair air-quality summary ***

AQ = Air Quality
DFS = Dynamic Frequency Selection

*** show ap dot11 24ghz cleanair air-quality worst ***

AQ = Air Quality
DFS = Dynamic Frequency Selection
AP Name      Channel  Avg AQ  Min AQ  Interferers  DFS
-----
              0         0       0       0             0       No
*** show ap dot11 24ghz cleanair config ***

Clean Air Solution..... : Disabled
Air Quality Settings:
  Air Quality Reporting..... : Disabled
  Air Quality Reporting Period (min)..... : 15
    
```

```

Air Quality Alarms..... : Enabled
Air Quality Alarm Threshold..... : 10
Interference Device Settings:
  Interference Device Reporting..... : Enabled
    Bluetooth Link..... : Enabled
    Microwave Oven..... : Enabled
    802.11 FH..... : Enabled
    Bluetooth Discovery..... : Enabled
    TDD Transmitter..... : Enabled
    Jammer..... : Enabled
    Continuous Transmitter..... : Enabled
    DECT-like Phone..... : Enabled
    Video Camera..... : Enabled
    802.15.4..... : Enabled
    WiFi Inverted..... : Enabled
    WiFi Invalid Channel..... : Enabled
    SuperAG..... : Enabled
    Canopy..... : Enabled
    Microsoft Device..... : Enabled
    WiMax Mobile..... : Enabled
    WiMax Fixed..... : Enabled
  Interference Device Types Triggering Alarms:
    Bluetooth Link..... : Disabled
    Microwave Oven..... : Disabled
    802.11 FH..... : Disabled
    Bluetooth Discovery..... : Disabled
    TDD Transmitter..... : Disabled
    Jammer..... : Disabled
    Continuous Transmitter..... : Disabled
    DECT-like Phone..... : Disabled
    Video Camera..... : Disabled
    802.15.4..... : Disabled
    WiFi Inverted..... : Enabled
    WiFi Invalid Channel..... : Enabled
    SuperAG..... : Disabled
    Canopy..... : Disabled
    Microsoft Device..... : Disabled
    WiMax Mobile..... : Disabled
    WiMax Fixed..... : Disabled
  Interference Device Alarms..... : Enabled
Additional Clean Air Settings:
  CleanAir Event-driven RRM State..... : Disabled
  CleanAir Driven RRM Sensitivity..... : LOW
  CleanAir Persistent Devices state..... : Disabled

```

# show tech-support wireless ap

To display specific information about the Cisco APs variables frequently requested by Cisco Technical Assistance Center (TAC), use the **show tech-support wireless ap** command in privileged EXEC mode.

## show tech-support wireless ap

<b>Syntax Description</b>	This command has no arguments or keywords.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

**Usage Guidelines** The output of the following commands are displayed as part of **show tech-support wireless ap** command:

- show ap session termination statistics
- show ap status
- show ap tag summary
- show platform software bssid chassis active F0 statistics
- show platform software bssid chassis active R0 statistics
- show platform software capwap chassis active F0 statistics
- show platform software capwap chassis active R0 statistics
- show platform software dtls chassis active F0 statistics
- show platform software dtls chassis active R0 statistics
- show platform software radio chassis active F0 statistics
- show platform software radio chassis active R0 statistics

### Example

The following is sample output from the **show tech-support wireless ap** command

```
Device# show tech-support wireless ap
----- show platform software dtls chassis active R0 statistics -----
DTLS Counters      (Success/Failure)
-----
Create              0/0
```

```
Delete                0/0
```

```
Switch 1:
OM Create              0/0
OM Delete              0/0
Ack Nack Notify       0/0
```

```
----- show platform software radio chassis active R0 statistics
-----
```

```
Switch 1:
NACK Notify           0/0
  Create Failure      0
  Delete Failure      0
```

```
----- show platform software bssid chassis active R0 statistics
-----
```

```
Switch 1:
NACK Notify           0/0
  Create Failure      0
  Delete Failure      0
```

```
----- show platform software capwap chassis active R0 statistics
-----
```

```
Capwap Counters      (Success/Failure)
-----
```

```
Create                0/0
Delete                0/0
Modify                0/0
```

```
Switch 1:
OM Create              0/0
OM Delete              0/0
ACK-NACK Notify       0/0
  Tunnel State        0/0
  Tunnel Create       0/0
  Tunnel Modify       0/0
  Tunnel Delete       0/0
```

```
----- show platform software dtls chassis active F0 statistics -----
```

```
DTLS Counters        (Success/Failure)
-----
```

```
Create                0/0
Delete                0/0
HW Create              0/0
HW Modify              0/0
HW Delete              0/0
Create Ack             0/0
Modify Ack             0/0
Delete Ack             0/0
Ack Ack Notify        0/0
```

```

Ack Nack Notify      0/0
Nack Notify          0/0
HA Seq GET           665/0
HA Seq SET           0/0
HA Seq Crypto GET    0/0
HA Seq Crypto SET    0/0
HA Seq Crypto Callback 0/0

```

```

HA Seq last Responded 0
HA Seq Pending         0
HA Seq Outstanding cb 0

```

```

----- show platform software radio chassis active F0 statistics
-----

```

```

Radio Counters      (Success/Failure)
-----

```

```

Create              0/0
Delete              0/0
HW Create           0/0
HW Modify           0/0
HW Delete           0/0
Create Ack          0/0
Modify Ack          0/0
Delete Ack          0/0
Nack Notify         0/0

```

```

----- show platform software bssid chassis active F0 statistics
-----

```

```

Bssid Counters     (Success/Failure)
-----

```

```

Create              0/0
Delete              0/0
HW Create           0/0
HW Modify           0/0
HW Delete           0/0
Create Ack          0/0
Modify Ack          0/0
Delete Ack          0/0
Nack Notify         0/0

```

```

----- show platform software capwap chassis active F0 statistics
-----

```

```

Capwap Counters    (Success/Failure)
-----

```

```

Create              0/0
Delete              0/0
HW Create           0/0
HW Modify           0/0
HW Delete           0/0
Create Ack          0/0
Modify Ack          0/0
Delete Ack          0/0
Ack Ack Notify     0/0
Ack Nack Notify    0/0
Nack Notify         0/0

```

```
----- show ap auto-rf dot11 24ghz -----
```

```
----- show ap auto-rf dot11 5ghz -----
```

```
----- show ap capwap retransmit -----
```

```
----- show ap config dot11 dual-band summary -----
```

```
----- show ap config general -----
```

```
----- show ap dot11 24ghz channel -----
```

#### Leader Automatic Channel Assignment

```

Channel Assignment Mode           : AUTO
Channel Update Interval          : 600 seconds
Anchor time (Hour of the day)    : 0
Channel Update Contribution
  Noise                           : Enable
  Interference                     : Enable
  Load                             : Disable
  Device Aware                     : Disable
CleanAir Event-driven RRM option  : Disabled
Channel Assignment Leader        : ewlc-doc (9.12.32.10)
Last Run                          : 25 seconds ago

DCA Sensitivity Level            : MEDIUM : 10 dB
DCA Minimum Energy Limit        : -95 dBm
Channel Energy Levels
  Minimum                          : unknown
  Average                          : unknown
  Maximum                          : -128 dBm
Channel Dwell Times
  Minimum                          : unknown
  Average                          : unknown

```

```
----- show ap dot11 24ghz group -----
```

#### Radio RF Grouping

```

802.11b Group Mode               : AUTO
802.11b Group Update Interval    : 600 seconds
802.11b Group Leader            : ewlc-doc (9.12.32.10)
802.11b Last Run                 : 26 seconds ago

```

#### RF Group Members

```
Controller name                  Controller IP
```

```

-----
ewlc-doc                               9.12.32.10

----- show ap dot11 24ghz load-info -----

----- show ap dot11 24ghz monitor -----

Default 802.11b AP monitoring
 802.11b Monitor Mode                : Enabled
 802.11b Monitor Channels            : Country channels
 802.11b RRM Neighbor Discover Type  : Transparent
 802.11b AP Coverage Interval       : 180 seconds
 802.11b AP Load Interval           : 60 seconds
 802.11b AP Noise Interval          : 180 seconds
 802.11b AP Signal Strength Interval : 60 seconds
 802.11b NDP RSSI Normalization     : Enabled

----- show ap dot11 24ghz network -----

802.11b Network                      : Enabled
11gSupport                           : Enabled
11nSupport                           : Enabled
802.11b/g Operational Rates
 802.11b 1M                          : Mandatory
 802.11b 2M                          : Mandatory
 802.11b 5.5M                        : Mandatory
 802.11b 11M                         : Mandatory
 802.11g 6M                          : Supported
 802.11g 9M                          : Supported
 802.11g 12M                         : Supported
 802.11g 18M                         : Supported
 802.11g 24M                         : Supported
 802.11g 36M                         : Supported
 802.11g 48M                         : Supported
 802.11g 54M                         : Supported
802.11n MCS Settings:
MCS 0 : Supported
MCS 1 : Supported
MCS 2 : Supported
MCS 3 : Supported

----- show ap dot11 24ghz profile -----

Default 802.11b AP performance profiles
 802.11b Global Interference threshold : 10 %
 802.11b Global noise threshold       : -70 dBm
 802.11b Global RF utilization threshold : 80 %
 802.11b Global throughput threshold  : 1000000 bps
 802.11b Global clients threshold     : 12 clients

----- show ap dot11 24ghz summary -----

```

```
----- show ap dot11 24ghz txpower -----
```

Automatic Transmit Power Assignment

```

Transmit Power Assignment Mode      : AUTO
Transmit Power Update Interval      : 600 seconds
Transmit Power Threshold             : -70 dBm
Transmit Power Neighbor Count       : 3 APs
Min Transmit Power                   : -10 dBm
Max Transmit Power                   : 30 dBm
Update Contribution
  Noise                               : Enable
  Interference                         : Enable
  Load                                : Disable
  Device Aware                         : Disable
Transmit Power Assignment Leader     : ewlc-doc (9.12.32.10)
Last Run                             : 27 seconds ago

```

```
----- show ap dot11 5ghz channel -----
```

Leader Automatic Channel Assignment

```

Channel Assignment Mode              : AUTO
Channel Update Interval              : 600 seconds
Anchor time (Hour of the day)       : 0
Channel Update Contribution
  Noise                               : Enable
  Interference                         : Enable
  Load                                : Disable
  Device Aware                         : Disable
CleanAir Event-driven RRM option    : Disabled
Channel Assignment Leader            : ewlc-doc (9.12.32.10)
Last Run                             : 27 seconds ago

DCA Sensitivity Level                : MEDIUM : 15 dB
DCA 802.11n/ac Channel Width        : 20 MHz
DCA Minimum Energy Limit             : -95 dBm
Channel Energy Levels
  Minimum                             : unknown
  Average                             : unknown
  Maximum                             : -128 dBm
Channel Dwell Times
  Minimum                             : unknown

```

```
----- show ap dot11 5ghz group -----
```

Radio RF Grouping

```

802.11a Group Mode                   : AUTO
802.11a Group Update Interval       : 600 seconds
802.11a Group Leader                : ewlc-doc (9.12.32.10)
802.11a Last Run                    : 28 seconds ago

```

RF Group Members

```

Controller name                      Controller IP

```



```

-----
ewlc-doc                               9.12.32.10

----- show ap dot11 5ghz load-info -----

----- show ap dot11 5ghz monitor -----

Default 802.11a AP monitoring
 802.11a Monitor Mode                   : Enabled
 802.11a Monitor Channels               : Country channels
 802.11a RRM Neighbor Discover Type    : Transparent
 802.11a AP Coverage Interval          : 180 seconds
 802.11a AP Load Interval              : 60 seconds
 802.11a AP Noise Interval             : 180 seconds
 802.11a AP Signal Strength Interval   : 60 seconds
 802.11a NDP RSSI Normalization        : Enabled

----- show ap dot11 5ghz network -----

802.11a Network                        : Enabled
11nSupport                             : Enabled
 802.11a Low Band                      : Enabled
 802.11a Mid Band                      : Enabled
 802.11a High Band                    : Enabled
802.11a Operational Rates
 802.11a 6M                           : Mandatory
 802.11a 9M                           : Supported
 802.11a 12M                          : Mandatory
 802.11a 18M                          : Supported
 802.11a 24M                          : Mandatory
 802.11a 36M                          : Supported
 802.11a 48M                          : Supported
 802.11a 54M                          : Supported
802.11n MCS Settings:
MCS 0 : Supported
MCS 1 : Supported
MCS 2 : Supported
MCS 3 : Supported
MCS 4 : Supported
MCS 5 : Supported

----- show ap dot11 5ghz profile -----

Default 802.11a AP performance profiles

 802.11a Global Interference threshold : 10 %
 802.11a Global noise threshold       : -70 dBm
 802.11a Global RF utilization threshold : 80 %
 802.11a Global throughput threshold  : 1000000 bps
 802.11a Global clients threshold     : 12 clients

----- show ap dot11 5ghz summary -----

```

```
----- show ap dot11 5ghz txpower -----
```

```
Automatic Transmit Power Assignment
```

```
Transmit Power Assignment Mode      : AUTO
Transmit Power Update Interval      : 600 seconds
Transmit Power Threshold            : -70 dBm
Transmit Power Neighbor Count       : 3 APs
Min Transmit Power                  : -10 dBm
Max Transmit Power                  : 30 dBm
Update Contribution
  Noise                             : Enable
  Interference                       : Enable
  Load                              : Disable
  Device Aware                       : Disable
Transmit Power Assignment Leader    : ewlc-doc (9.12.32.10)
Last Run                            : 28 seconds ago
```

```
----- show ap image -----
```

```
----- show wireless stats ap join summary -----
```

```
Number of APs: 0
```

Base MAC	Ethernet MAC	AP Name	IP Address	Status
Last Failure Type	Last Disconnect Reason			

```
----- show ap rf-profile summary -----
```

```
Number of RF-profiles: 6
```

RF Profile Name	Band	Description	State
Low_Client_Density_rf_5gh	5 GHz	pre configured Low Client Density rf	Up
High_Client_Density_rf_5gh	5 GHz	pre configured High Client Density r	Up
Low_Client_Density_rf_24gh	2.4 GHz	pre configured Low Client Density rf	Up
High_Client_Density_rf_24gh	2.4 GHz	pre configured High Client Density r	Up
Typical_Client_Density_rf_5gh	5 GHz	pre configured Typical Density rfpro	Up
Typical_Client_Density_rf_24gh	2.4 GHz	pre configured Typical Client Densit	Up

```
----- show ap slots -----
```

```
----- show ap summary -----
```

```
Number of APs: 0
```

```
----- show ap uptime -----
```

```
Number of APs: 0
```

```
----- show ap tag summary -----
```

```
Number of APs: 0
```

```
----- show ap status -----
```

```
----- show ap cdp neighbors -----
```

```
Number of neighbors: 0
```

```
----- show ap ap-join-profile summary -----
```

```
Number of AP Profiles: 1
```

AP Profile Name	Description
default-ap-profile	default ap profile

```
----- show ap link-encryption -----
```

```
----- show wireless stats ap session termination -----
```

```
----- show wireless loadbalance ap affinity wncd 0 -----
```

```
----- show wireless loadbalance ap affinity wncd 1 -----
```

```
----- show wireless loadbalance ap affinity wncd 2 -----
```

```
----- show wireless loadbalance ap affinity wncd 3 -----
```

```
----- show wireless loadbalance ap affinity wncd 4 -----
```

```
----- show wireless loadbalance ap affinity wncd 5 -----
```

```
----- show wireless loadbalance ap affinity wncd 6 -----
```

```
----- show wireless loadbalance ap affinity wncd 7 -----
```

# show tech-support wireless client

To print the data related to all clients or a particular client, use the **show tech-support wireless client** command in privileged EXEC mode.

## show tech-support wireless client

### Syntax Description

**mac-address** Client MAC address.

### Command Default

None

### Command Modes

Privileged EXEC (#)

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

### Usage Guidelines

The output of the following commands are displayed as part of **show tech-support wireless client** command:

- show platform software wireless-client chassis active F0 statistics
- show platform software wireless-client chassis active R0 statistics
- show wireless client calls active
- show wireless client calls rejected
- show wireless client client-statistics summary
- show wireless client device summary
- show wireless client mac <mac-addr> details
- show wireless client probing
- show wireless client sleeping-client
- show wireless client statistic
- show wireless client steering
- show wireless client summary
- show wireless exclusionlist
- show wireless pmk-cache



### Note

The **show tech-support wireless client** command does not display the output of **show wireless client summary detail** command.

**Example**

The following is sample output from the **show tech-support wireless client** command

```

Device# show tech-support wireless client

----- show wireless stats client summary -----

Number of Local Clients : 0

MAC Address      AP Name          WLAN UpTime(secs) Rx Pkts Tx Pkts RSSI SNR
Data Retries
-----

----- show wireless client summary -----

Number of Local Clients: 0

Number of Excluded Clients: 0

----- show wireless client device summary -----

----- show wireless client steering -----

Client Steering Configuration Information
Macro to micro transition threshold      : -55 dBm
Micro to Macro transition threshold     : -65 dBm
Micro-Macro transition minimum client count : 3
Micro-Macro transition client balancing window : 3
Probe suppression mode                  : Disabled
Probe suppression validity window       : 100 s
Probe suppression aggregate window      : 200 ms
Probe suppression transition aggressiveness : 3
Probe suppression hysteresis            : -6 dBm

WLAN Configuration Information

----- show wireless client calls active -----

----- show wireless client calls rejected -----

----- show wireless client sleeping-client -----

Total number of sleeping-client entries: 0

```

----- show wireless client probing -----

----- show wireless client ap dot11 24ghz -----

----- show wireless client ap dot11 5ghz -----

----- show wireless pmk-cache -----

Number of PMK caches in total : 0

Type	Station	Entry Lifetime	VLAN Override	IP Override
Audit-Session-Id				

----- show wireless exclusionlist -----

----- show wireless country configured -----

Configured Country..... US - United States  
 Configured Country Codes  
     US - United States                      802.11a Indoor/ 802.11b Indoor/ 802.11g Indoor

----- show wireless tag rf summary -----

Number of RF Tags: 1

RF tag name	Description
default-rf-tag	default RF tag

----- show platform software wireless-client chassis active R0 statistics -----

Client Counters	(Success/Failure)
Create	0/0
Delete	0/0
Modify	0/0
Switch 1:	
OM Create	0/0
OM Delete	0/0

## show tech-support wireless client

```

NACK Notify          0/0
  Create Failure     0
  Modify Failure     0
  Delete Failure     0

```

```

----- show platform software wireless-client chassis active F0 statistics
-----

```

```

Client Counters      (Success/Failure)
-----
Create                0/0
Delete                0/0
HW Create              0/0
HW Modify              0/0
HW Delete              0/0
Create Ack             0/0
Modify Ack             0/0
Delete Ack             0/0
NACK Notify           0/0

```

```

----- show platform hardware chassis active qfp feature wireless wlclient
cpp-client summary -----

```

```

----- show platform hardware chassis active qfp feature wireless wlclient
datapath summary -----

```

```

Vlan  pal_if_hdl  mac          Input Uidb Output Uidb
-----

```



# show tech-support wireless datapath

To print the data related to CPP datapath, use the **show tech-support wireless datapath** command in privileged EXEC mode.

## show tech-support wireless datapath

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
<b>Usage Guidelines</b>	<p>This command is available only on the platforms that have CPP datapath architecture, such as Cisco vEWLC, Cisco 9540 WLC, and Cisco 9880 WLC.</p> <p>The output of the following commands are displayed as part of <b>show tech-support wireless datapath</b> command:</p> <ul style="list-style-type: none"> <li>• show platform hardware chassis active qfp feature wireless bssid summary</li> <li>• show platform hardware chassis active qfp feature wireless capwap cpp-client statistics</li> <li>• show platform hardware chassis active qfp feature wireless capwap cpp-client summary</li> <li>• show platform hardware chassis active qfp feature wireless capwap datapath statistics drop</li> <li>• show platform hardware chassis active qfp feature wireless capwap datapath statistics fragmentation</li> <li>• show platform hardware chassis active qfp feature wireless capwap datapath statistics reassembly</li> <li>• show platform hardware chassis active qfp feature wireless capwap datapath summary</li> <li>• show platform hardware chassis active qfp feature wireless dtls cpp-client statistics</li> <li>• show platform hardware chassis active qfp feature wireless dtls cpp-client summary</li> <li>• show platform hardware chassis active qfp feature wireless dtls datapath statistics</li> <li>• show platform hardware chassis active qfp feature wireless dtls datapath summary</li> <li>• show platform hardware chassis active qfp feature wireless et-analytics eta-pending-client-tree</li> <li>• show platform hardware chassis active qfp feature wireless et-analytics statistics</li> <li>• show platform hardware chassis active qfp feature wireless fqdn-filter summary</li> <li>• show platform hardware chassis active qfp feature wireless halo statistics</li> <li>• show platform hardware chassis active qfp feature wireless ipsg cpp-client statistics</li> </ul>	

- show platform hardware chassis active qfp feature wireless ipsg cpp-client table ipv4 all
- show platform hardware chassis active qfp feature wireless ipsg cpp-client table ipv6 all
- show platform hardware chassis active qfp feature wireless ipsg datapath statistics global
- show platform hardware chassis active qfp feature wireless ipsg datapath table ipv4 all
- show platform hardware chassis active qfp feature wireless ipsg datapath table ipv6 all
- show platform hardware chassis active qfp feature wireless mgmt-intf cpp-client summary
- show platform hardware chassis active qfp feature wireless mgmt-intf datapath summary
- show platform hardware chassis active qfp feature wireless punt statistics
- show platform hardware chassis active qfp feature wireless wlan summary
- show platform hardware chassis active qfp feature wireless wlclient cpp-client statistics
- show platform hardware chassis active qfp feature wireless wlclient cpp-client summary
- show platform hardware chassis active qfp feature wireless wlclient datapath statistic drop
- show platform hardware chassis active qfp feature wireless wlclient datapath summary
- show platform hardware chassis active qfp feature wireless wlclient datapath table dataglean all
- show platform hardware chassis active qfp infrastructure punt statistics type per-cause
- show platform hardware chassis active qfp statistics drop
- show platform software bssid chassis active F0
- show platform software bssid chassis active F0 statistics
- show platform software capwap chassis active F0
- show platform software capwap chassis active F0 statistics
- show platform software dtls chassis active F0
- show platform software dtls chassis active F0 statistics
- show platform software wireless-client chassis active F0
- show platform software wireless-client chassis active F0 statistics
- show platform software wlan chassis active F0

In the presence of standby node, the following datapath commands are also displayed:

- show platform hardware chassis standby qfp feature wireless bssid summary
- show platform hardware chassis standby qfp feature wireless capwap cpp-client statistics
- show platform hardware chassis standby qfp feature wireless capwap cpp-client summary
- show platform hardware chassis standby qfp feature wireless capwap datapath statistics drop
- show platform hardware chassis standby qfp feature wireless capwap datapath statistics fragmentation
- show platform hardware chassis standby qfp feature wireless capwap datapath statistics reassembly

- show platform hardware chassis standby qfp feature wireless capwap datapath summary
- show platform hardware chassis standby qfp feature wireless dtls cpp-client statistics
- show platform hardware chassis standby qfp feature wireless dtls cpp-client summary
- show platform hardware chassis standby qfp feature wireless dtls datapath statistics
- show platform hardware chassis standby qfp feature wireless dtls datapath summary
- show platform hardware chassis standby qfp feature wireless halo statistics
- show platform hardware chassis standby qfp feature wireless ipsg cpp-client statistics
- show platform hardware chassis standby qfp feature wireless ipsg cpp-client table ipv4 all
- show platform hardware chassis standby qfp feature wireless ipsg cpp-client table ipv6 all
- show platform hardware chassis standby qfp feature wireless ipsg datapath statistics global
- show platform hardware chassis standby qfp feature wireless ipsg datapath table ipv4 all
- show platform hardware chassis standby qfp feature wireless ipsg datapath table ipv6 all
- show platform hardware chassis standby qfp feature wireless mgmt-intf cpp-client summary
- show platform hardware chassis standby qfp feature wireless mgmt-intf datapath summary
- show platform hardware chassis standby qfp feature wireless punt statistics
- show platform hardware chassis standby qfp feature wireless wlan summary
- show platform hardware chassis standby qfp feature wireless wlclient cpp-client statistics
- show platform hardware chassis standby qfp feature wireless wlclient cpp-client summary
- show platform hardware chassis standby qfp feature wireless wlclient datapath statistic drop
- show platform hardware chassis standby qfp feature wireless wlclient datapath summary
- show platform hardware chassis standby qfp feature wireless wlclient datapath table dataglean all
- show platform hardware chassis standby qfp statistics drop
- show platform software bssid chassis standby F0
- show platform software bssid chassis standby F0 statistics
- show platform software capwap chassis standby F0
- show platform software capwap chassis standby F0 statistics
- show platform software dtls chassis standby F0
- show platform software dtls chassis standby F0 statistics
- show platform software wireless-client chassis standby F0
- show platform software wireless-client chassis standby F0 statistics
- show platform software wlan chassis standby F0

**Example**

The following is sample output from the **show tech-support wireless datapath** command

```
Device# show tech-support wireless datapath
```

```
----- show platform hardware chassis active qfp statistics drop
-----
```

Global Drop Stats	Packets	Octets
Disabled	22230	2045194
InvL2Hdr	4765368	744492240
Ipv4NoAdj	6	736
Ipv4NoRoute	18	2358
Ipv6mcNoRoute	3	270
SWPortDrop	14432	2886027
SWPortSrcFilter	53265	53992718
SWPortStpState	42041	3269790
SWPortVlanNotCfg	5515542	674079804
SwitchL2m	78	10062
SwitchL2mIGMP	18866	1283348
SwitchL2mUnconfigWireless	78	11622
WlsCapwapNoTunnel	3	627

```
----- show platform hardware chassis active qfp feature wireless punt statistics
-----
```

```
CPP Wireless Punt stats:
```

App Tag	Packet Count
CAPWAP_PKT_TYPE_DOT11_PROBE_REQ	0
CAPWAP_PKT_TYPE_DOT11_MGMT	56
CAPWAP_PKT_TYPE_DOT11_IAPP	22177
CAPWAP_PKT_TYPE_DOT11_RFID	0
CAPWAP_PKT_TYPE_DOT11_RRM	0
CAPWAP_PKT_TYPE_DOT11_DOT1X	0
CAPWAP_PKT_TYPE_CAPWAP_KEEPALIVE	0
CAPWAP_PKT_TYPE_MOBILITY_KEEPALIVE	0
CAPWAP_PKT_TYPE_CAPWAP_CNTRL	303661
CAPWAP_PKT_TYPE_CAPWAP_DATA	0
CAPWAP_PKT_TYPE_MOBILITY_CNTRL	0
WLS_SMD_WEBAUTH	0
SISF_PKT_TYPE_ARP	303
SISF_PKT_TYPE_DHCP	282
SISF_PKT_TYPE_DHCP6	0
SISF_PKT_TYPE_IPV6_ND	0
SISF_PKT_TYPE_DATA_GLEAN	0
SISF_PKT_TYPE_DATA_GLEAN_V6	0
SISF_PKT_TYPE_DHCP_RELAY	0
CAPWAP_PKT_TYPE_CAPWAP_RESERVED	0

```
----- show platform hardware chassis active qfp infrastructure punt statistics
type per-cause -----
```

```
Global Per Cause Statistics
```

Number of punt causes = 136

Per Punt Cause Statistics

Counter ID	Punt Cause Name	Packets Received	Packets Transmitted
000	Reserved	0	0
001	MPLS ICMP Can't Fragment	0	0
002	IPv4 Options	0	0
003	Layer2 control and legacy	0	0
004	PPP Control	0	0
005	CLNS IS-IS Control	0	0
006	HDLC keepalives	0	0
007	ARP request or response	2687	2687
008	Reverse ARP request or response	0	0
009	Frame-relay LMI Control	0	0
010	Incomplete adjacency	0	0
011	For-us data	0	0
012	Mcast Directly Connected Source	0	0
013	Mcast IPv4 Options data packet	0	0
014	Skip egress processing	0	0
015	MPLS TTL expired	0	0
016	MPLS Reserved label (ie: 0-15)	0	0
017	IPv6 Bad hop limit	0	0
018	IPV6 Hop-by-hop Options	0	0
019	Mcast Internal Copy	0	0
020	Generic QFP generated packet	0	0
021	RP<->QFP keepalive	46691	46691
022	QFP Fwall generated packet	0	0
023	Mcast IGMP Unroutable	0	0
024	Glean adjacency	2557	2556
025	Mcast PIM signaling	0	0
026	QFP ICMP generated packet	0	0
027	Subscriber session control	0	0

028	Subscriber data switching back	0	0
029	RP handled ICMP	0	0
030	RP injected For-us data	0	0
031	Punt adjacency	0	0
032	SBC RTP DTMF	0	0
033	Pseudowire VCCV control channel	0	0
034	Generic QFP generated packet (keep GPM)	0	0
035	Ethernet slow protocol (ie: LACP, OAM)	0	0
036	Ethernet OAM Loopback	0	0
037	UNUSED	0	0
038	SPA IPC packet	0	0
039	Punt and replicate	0	0
040	PPPoE control	0	0
041	PPPoE session	0	0
042	L2TP control	0	0
043	IP Subscriber control (ie: FSOL, keepali	0	0
044	L2TP session	0	0
045	BFD control	0	0
046	MVPN non-RPF signaling packet	0	0
047	MVPN PIM signalling packet	0	0
048	Mcast punt to RP	0	0
049	SBC generated packet	0	0
050	IPv6 packet	0	0
051	DMVPN NHRP redirect	0	0
052	PFR monitored prefix logging	0	0
053	PFR top talkers logging	0	0
054	PFR top talkers application logging	0	0
055	For-us control	0	0
056	RP injected for-us control	0	0
057	QFP VTCP generated packet	0	0
058	Layer2 bridge domain data packet	0	0
059	QFP Stile generated packet	0	0

060	IP subnet or broadcast packet	167	167
061	Ethernet CFM packet	0	0
062	Ethernet CFM notify packet	0	0
063	LISP LSB NOTIFICATION	0	0
064	Service Engine packet	0	0
065	L2BD Control packet from FIA	0	0
066	L2BD Control Message from CPP	0	0
067	MFR_LIP_CONTROL	0	0
068	Media Monitoring record punted from CPP	0	0
069	OTV Control packet	0	0
070	OTV ARP packet	0	0
071	REP control	0	0
072	IP MTU EXCEPTION	0	0
073	STP BPDU's	186832	186832
074	ACL log	0	0
075	EPC	0	0
076	Lisp Dynamic eid	0	0
077	L2 Control packet	122389	122389
078	WAAS CPP to CPP punt	0	0
079	dhcp snoop	0	0
080	Metric Mediation Agent record punted fro	0	0
081	IPv6 DMVPN NHRP redirect	0	0
082	Ethernet CFM packet from core	0	0
083	Ethernet CFM punt fwd packet	0	0
084	PTP punt fwd packet	0	0
085	ISDN D-Channel raw packet	0	0
086	Service controller SCG punt pkt	0	0
087	IPv6 FHS SG dropped packet	0	0
088	IPv6 FHS Data glean packet	0	0
089	SBC DSP pkts	0	0
090	Raw Socket Data packet	0	0
091	SSLVPN session control	0	0

092	ICMP unreachable for ACL denied packets	0	0
093	CENT Smart Probe packet	0	0
094	AppNav vPATH pktless API generated pkt	0	0
095	Autonomic Network Channel Discovery pack	0	0
096	Layer2 control protocols	0	0
097	Packets to LFTS	22177	22177
098	VLAN Auto Sense FSOL	0	0
099	ZTP Discovery packet	0	0
100	cable arp filter	0	0
101	Cable L3 mobility	0	0
102	Source Verify inconclusive	0	0
103	cable modem pre reg	0	0
104	mpls receive adj	0	0
105	MKA EAPoL packet	0	0
106	ICMP Unreachable	0	0
107	Cable DHCP	0	0
108	Snooping packet	0	0
109	snoop packets	0	0
110	msg Indicating ppp intf assigned ip addr	0	0
111	msg indicating there is another common h	0	0
112	QoS CAC Flow Report	0	0
113	Active identity	0	0
114	BGP Overlay Tunnel packet	0	0
115	Lisp gsmr enabled	0	0
116	Async TS	0	0
117	Metric Mediation Agent Packet	0	0
118	Cable DHCPV6 Solicit	0	0
119	Cable DHCPV6 Request	0	0
120	SBC RTP FWD DTMF	0	0
121	Path Manager	0	0
122	L2 LISP VXLAN	0	0
123	dialer-list	0	0



124	Dialer update time	0	0
125	Cable RPHY CTRL	0	0
126	OpenFlow SDN	0	0
127	Path Manager TTL expired	0	0
128	L3 PTP message	0	0
129	wls 802.11 Packets to LFTS	56	56
130	wls CAPWAP Packets to LFTS	303661	303661
131	wls MOBILITY Packets to LFTS	0	0
132	wls SISF Packets to LFTS	585	585
133	cable DHCPv6 subscriber-side	0	0
134	cable DHCPv4 subscriber-side	0	0
135	cable DHCPv4 sub-side disc/req	0	0

Number of inject causes = 49

Per Inject Cause Statistics

Counter ID	Inject Cause Name	Packets Received	Packets Transmitted
000	RESERVED	0	0
001	L2 control/legacy	3115	3115
002	QFP destination lookup	0	0
003	QFP IPv4/v6 nexthop lookup	0	0
004	QFP generated packet	0	0
005	QFP <->RP keepalive	46691	0
006	QFP Fwall generated packet	0	0
007	QFP adjacency-id lookup	0	0
008	Mcast specific inject packet	0	0
009	QFP ICMP generated packet	0	0
010	QFP/RP->QFP Subscriber data packet	0	0
011	SBC DTMF	0	0
012	ARP request or response	3637	3637
013	Ethernet OAM loopback packet	0	0

## show tech-support wireless datapath

014	UNUSED	0	0
015	PPPoE discovery packet	0	0
016	PPPoE session packet	0	0
017	QFP inject for pp_index lookup	0	0
018	QFP inject replicate	0	0
019	QFP inject PIT lookup	0	0
020	SBC generated packets	0	0
021	QFP VTCP generated packet	0	0
022	QFP Stile generated packet	0	0
023	Service Engine generated packet	0	0
024	Layer2 frame to EFP	0	0
025	Layer2 frame to BD	0	0
026	QFP Asym Routing redirected pkt	0	0
027	Compressed packet from WAAS	0	0
028	Media (e.g. voice) associated with a ses	0	0
029	service controller scg packet	0	0
030	Packet for 14 port Serial IM	0	0
031	Subscriber generated TCP reset packet	0	0
032	Layer2 frame to INPUT EFP	0	0
033	SSLVPN inject control	0	0
034	injected packet from UTD SP	0	0
035	injected packet from DPSS SN	0	0
036	injected packet by AppNav vPath	0	0
037	Uncompressed packet from WAAS	0	0
038	Autonomic Network Channel Discovery pack	0	0
039	Cable Bundle Flood Inject	0	0
040	Cable L2 unicast inject	0	0
041	downstream jib packet	0	0
042	switch port layer 2 control packet	6254	6253
043	Applications Injecting Pkts using LFTS	303874	303269
044	Enhanced ping and traceroute	0	0
045	Applications Injecting packets with SGT	0	0

```

046      CoPP packets from EPC_WS          0          0
047      Async TS                          0          0
048      Layer2 frame to VLAN              0          0
    
```

----- show platform hardware chassis active qfp feature wireless mgmt-intf  
cpp-client summary -----

Wireless Management Interface Info

```

CPP IF_H  VLAN  MAC Address
-----
0XF      78    001e.1405.2bff
    
```

----- show platform hardware chassis active qfp feature wireless mgmt-intf  
datapath summary -----

Wireless Management Interface Info

```

IF_H      VLAN  MAC Address
-----
0xF      78    001e.1405.2bff
    
```

----- show platform software wlan chassis active F0 -----

WLAN Interface ID	WLAN ID	WLAN Name	AOM ID	Status
0xf0400001	1	att	275	Done
0xf0400002	2	verizon	292	Done

----- show platform hardware chassis active qfp feature wireless wlan summary  
-----

CPP Wlan Database Summary

Total number of wlan interfaces : 2

if_name ssid	cpp_if_hdl	pal_if_hdl	in_uidb	out_uidb
WLAN-IF-0x00f0400001 att	0X74	0XF0400001	0X1768E	0X1768C
WLAN-IF-0x00f0400002 verizon	0X78	0XF0400002	0X1768A	0X17688

----- show platform software bssid chassis active F0 statistics  
-----

Bssid Counters (Success/Failure)

```

-----
Create          0/0
Delete          0/0
HW Create       0/0
    
```

## show tech-support wireless datapath

```

HW Modify          0/0
HW Delete          0/0
Create Ack         0/0
Modify Ack         0/0
Delete Ack        0/0
Nack Notify       0/0

```

```
----- show platform software bssid chassis active F0 -----
```

```
----- show platform hardware chassis active qfp feature wireless bssid summary
-----
```

```
----- show platform software capwap chassis active F0 statistics
-----
```

```
Capwap Counters (Success/Failure)
```

```
-----
Create          424/0
Delete          420/0
HW Create       424/0
HW Modify       0/0
HW Delete       420/0
Create Ack      424/0
Modify Ack      0/0
Delete Ack      420/0
Ack Ack Notify  0/0
Ack Nack Notify 0/0
Nack Notify     0/0

```

```
----- show platform software capwap chassis active F0 -----
```

```

Tunnel ID  AP MAC           Type           IP             Port      AOM ID  Status
-----
0x90000042 00a8.2200.0200 Data           78.1.50.1     52345    3271   Done
0xa0000002 0000.0000.0000 Mobility Data  78.1.1.23    16667    1426   Done
0xa0000003 0000.0000.0000 Mobility Data  78.1.1.24    16667    1427   Done
0xa0000004 0000.0000.0000 Mobility Data  78.1.1.25    16667    1428   Done

```

```
----- show platform hardware chassis active qfp feature wireless capwap
cpp-client statistics -----
```

```
CAPWAP cpp-client plumbing statistics
Number Msg in = ack + nak + ack fail + nak fail + errors
```

```

Counter                               Value
-----
Create from fp                         424

```

```

Modify from fp                0
Delete from fp                420
Create ack to fp              424
Create ack fail to fp         0
Create nack to fp             0
Create nack fail to fp        0
Modify ack to fp              0
Modify ack fail to fp         0
Modify nack to fp             0
Modify nack fail to fp        0
Delete ack to fp              420
Delete ack fail to fp         0
Delete nack to fp             0
Delete nak fail to fp         0
    
```

----- show platform hardware chassis active qfp feature wireless capwap  
cpp-client summary -----

cpp_if_hdl Tun Type	pal_if_hdl	AP MAC	Src IP	Dst IP	Dst Port
0X108 DATA	0X90000042	00a8.2200.0200	78.1.1.7	78.1.50.1	52345
0X10B MOBILITY	0XA0000002	0000.0000.0000	78.1.1.7	78.1.1.23	16667
0X10C MOBILITY	0XA0000003	0000.0000.0000	78.1.1.7	78.1.1.24	16667
0X10D MOBILITY	0XA0000004	0000.0000.0000	78.1.1.7	78.1.1.25	16667

----- show platform hardware chassis active qfp feature wireless capwap datapath  
summary -----

Vrf	Src Port	Dst IP	Dsp Port	Input Uidb	Output Uidb	Instance Id
0	16667	78.1.1.25	16667	95733	95731	0
0	5247	78.1.50.1	52345	95738	95736	3
0	16667	78.1.1.24	16667	95734	95732	0
0	16667	78.1.1.23	16667	95735	95733	0

----- show platform hardware chassis active qfp feature wireless capwap datapath  
statistics drop -----

Drop Cause Octets	Packets
Wls Capwap unsupported link type Error 0	0
Wls Capwap invalid tunnel Error 0	0
Wls Capwap input config missing Error 0	0
Wls Capwap invalid TPID Error 0	0
Wls Capwap ingress parsing Error 0	0

## show tech-support wireless datapath

```

Wls Capwap invalid FC subtype Error          0
      0
Wls Capwap SNAP Invalid HLEN Error          0
      0
Wls Client V6 Max Address Error             0
      0

```

```

----- show platform hardware chassis active qfp feature wireless capwap datapath
statistics fragmentation -----

```

CPP Wireless Fragmentation stats:

Description	Packet Count	Octet Count
-----	-----	-----
Capwap Packets to be Fragmented (RX)	0	0
Capwap Fragments to be Recycled	0	0
Capwap Fragments Recycled (TX)	0	0
Error: Original Packet Too Big	0	0
Error: CAPWAP MTU Not Valid	0	0
Error: Recycle Queue Full	0	0
Error: Recycle Queue Not Valid	0	0
Error: GPM Memory Init Failure	0	0
Error: Multipass Requeue Failure	0	0

```

----- show platform hardware chassis active qfp feature wireless capwap datapath
statistics reassembly -----

```

CPP Wireless Reassembly Memory stats:

Description	Count
-----	-----
Free info chunk	32768
Allocated info chunks	32768
Free fragment chunks	131072
Allocated fragment chunks	131072

CPP Wireless Reassembly Packet stats: (outstanding pkt\_cnt 0)

Description	Packet Count	Octet Count
-----	-----	-----
Capwap Reassembled Packets	0	0
Capwap Fragments Received	0	0
Capwap Fragments Consumed (Saved)	0	0
Capwap Fragments Dropped	0	0
Capwap Reassembly Timeouts	0	0
Error - Early-drop fragments	0	0
Error - Invalid packet size	0	0
Error - Fragment size too big	0	0
Error - Too many fragments	0	0
Error - Overlap offset fragments	0	0
Error - Duplicated fragments	0	0
Error - Allocate info chunk memory	0	0
Error - Allocate frag chunk memory	0	0
Error - Hash bucket threshold	0	0
Error - Cannot save and gather pkts	0	0
Error - Get recycle reass_info NULL	0	0
Error - BQS memory alloc NULL	0	0
Error - BQS memory free NULL	0	0

```

DEBUG - # of lock sync aquired          2          2
DEBUG - # of lock released                2          2
DEBUG - CPP_CW_BQS_MX_ALLOC #            0          0
DEBUG - CPP_CW_BQS_MX_FREE #             0          0
DEBUG - CPP_REASS_INFO_ALLOC #           0          0
DEBUG - CPP_REASS_INFO_FREE #            0          0
DEBUG - CPP_REASS_FRAG_ALLOC #           0          0
DEBUG - CPP_REASS_FRAG_FREE #            0          0
    
```

----- show platform software dtls chassis active F0 statistics -----

```

DTLS Counters      (Success/Failure)
-----
Create              847/0
Delete              424/0
HW Create           425/0
HW Modify           422/0
HW Delete           424/0
Create Ack          425/0
Modify Ack          422/0
Delete Ack          424/0
Ack Ack Notify     1271/0
Ack Nack Notify    0/0
Nack Notify        0/0
HA Seq GET         782/0
HA Seq SET         0/0
HA Seq Crypto GET  1542/0
HA Seq Crypto SET  0/0
HA Seq Crypto Callback 1542/0

HA Seq last Responded 0
HA Seq Pending        0
HA Seq Outstanding cb 0
Total DTLS CTX count  1
    
```

----- show platform software dtls chassis active F0 -----

Forwarding Manager DTLS Session Summary

Session ID	Type	Peer IP	Port	AOM ID	Status
0x0300000000000001	AP Control	78.1.50.1	52345	3270	Done

----- show platform hardware chassis active qfp feature wireless dtls cpp-client statistics -----

```

DTLS cpp-client plumbing statistics
Number Msg in = ack + nak + ack fail + nak fail + errors

Counter              Value
-----
Create from fp      425
Modify from fp      422
Delete from fp      424
    
```

show tech-support wireless datapath

```

Create ack to fp          425
Create ack fail to fp    0
Create nack to fp        0
Create nack fail to fp   0
Modify ack to fp         422
Modify ack fail to fp    0
Modify nack to fp        0
Modify nack fail to fp   0
Delete ack to fp         424
Delete ack fail to fp    0
Delete nack to fp        0
Delete nak fail to fp    0
    
```

----- show platform hardware chassis active qfp feature wireless dtls cpp-client summary -----

Session ID	CDH Handle	Session Type	Parent if-h	Instance id
0x0300000000000001	0x00000000D902D9E0	AP Control	0	3

----- show platform hardware chassis active qfp feature wireless dtls datapath summary -----

Src IP	Dst IP	Src Port	Dst Port	Crypto HDL	Instance Id
78.1.1.7	78.1.50.1	5246	52345	0xd902d9e0	3

----- show platform hardware chassis active qfp feature wireless dtls datapath statistics -----

CPP Wireless DTLS Feature Stats

Description	Packet Count	Octet Count
DTLS Packets To Encrypt	286494	8860778
DTLS Packets Encrypted	286494	35681366
DTLS Packets To Decrypt	286734	41001830
DTLS Packets Decrypted	286734	33401602
Skip Encryption - Handshake	0	0
Skip Encryption - Not AppData	0	0
Skip Encryption - No Hash Entry	0	0
Skip Encryption - No Crypto Handle	0	0
Skip Encryption - No DTLS header	563	76419
Skip Encryption - Requested by RP	16234	5042852
Skip Decryption - Handshake	0	0
Skip Decryption - Not AppData	2949	996248
Skip Decryption - No Hash Entry	447	56474
Skip Decryption - No Crypto Handle	13024	3626640
Skip Decryption - No DTLS header	507	116600
Skip Decryption - Multiple Records	0	0
Error - Encrypt Invalid Length	0	0
Error - Encrypt Header Restore	0	0
Error - DataEncrypt No Crypto Handle	0	0
Error - DataEncrypt Header Restore	0	0
Error - Decrypt Invalid Length	0	0
Error - Decrypt Header Restore	0	0
Error - DataDecrypt Zero Epoch	0	0



```
Error - DataDecrypt No Hash Entry          0          0
Error - DataDecrypt No Crypto Handle       0          0
Error - DataDecrypt Header Restore        0          0
```

----- show platform software wireless-client chassis active F0 statistics -----

```
Client Counters (Success/Failure)
-----
Create          112/0
Delete          55/0
HW Create       56/0
HW Modify       56/0
HW Delete       55/0
Create Ack      56/0
Modify Ack      56/0
Delete Ack      55/0
NACK Notify     0/0
```

----- show platform software wireless-client chassis active F0 -----

ID	MAC Address	WLAN	Client State	AOM ID	Status
0xa0000001	0028.b122.0001	1	Run	3272	Done

----- show platform hardware chassis active qfp feature wireless wlclient cpp-client statistics -----

Wlclient cpp-client plumbing statistics  
 Number Msg in = ack + nak + ack fail + nak fail + errors

Counter	Value
Create from fp	56
Modify from fp	56
Delete from fp	55
Create ack to fp	56
Create ack fail to fp	0
Create nack to fp	0
Create nack fail to fp	0
Modify ack to fp	56
Modify ack fail to fp	0
Modify nack to fp	0
Modify nack fail to fp	0
Delete ack to fp	55
Delete ack fail to fp	0
Delete nack to fp	0
Delete nak fail to fp	0

----- show platform hardware chassis active qfp feature wireless wlclient cpp-client summary -----

Auth State Abbreviations:  
 UK - UNKNOWN IP - LEARN IP  
 L3 - L3 AUTH RN - RUN

show tech-support wireless datapath

```

IV - INVALID
Mobility State Abbreviations:
  UK - UNKNOWN  IN - INIT
  LC - LOCAL    AN - ANCHOR
  FR - FOREIGN  MT - MTE
  IV - INVALID
CPP IF_H      DPIDX      MAC Address      VLAN  AS  MS              WLAN
POA
-----
0X102      0XA0000001  0028.b122.0001  177  RN  LC              att
0x90000042

```

```

----- show platform hardware chassis active qfp feature wireless wlclient
datapath summary -----

```

Vlan	pal_if_hdl	mac	Input Uidb	Output Uidb
177	0xa0000001	0028.b122.0001	95744	95742

```

----- show platform hardware chassis active qfp feature wireless wlclient
datapath statistic drop -----

```

Drop Cause	Octets	Packets
Wls Client V6 Max Address Error	0	0
Wls Client IPGlean Counter Index Error	0	0
Wls Client IPGlean Counter Unchanged Error	0	0
Wls Client IPGlean alloc no memory Error	0	0
Wls Client invalid punt packet error	0	0
Wls Client input subblock missing error	0	0
Wls Client input config missing	0	0
Wls Client global mac address fetch error	0	0
Wls Client header add error	0	0
Wls Client IP entry theft error	0	0
Wls Client IPSG input subblock missing error	0	0
Wls Client DOT1Q Hdr add anchor error	0	0
Wls Client DOT1Q Hdr add anchor avc error	0	0
Wls Client Guest Foreign Multicast error	0	0

```

----- show platform hardware chassis active qfp feature wireless wlclient
datapath table dataglean all -----

```

CPP Wireless IPv6 Data Gleaning Table:

IP Address	VLAN	uIDB	Interface
------------	------	------	-----------

----- show platform hardware chassis active qfp feature wireless ipsg cpp-client statistics -----

CPP Wireless IPSG CPP-client Statistics

Counter	Value
Total IPv4 Address Count	1
Total IPv6 Address Count	0
IPv4 Entry Add Success	56
IPv4 Entry Add Fail	0
IPv4 Entry Delete Success	55
IPv4 Entry Delete Fail	0
IPv6 Entry Add Success	0
IPv6 Entry Add Fail	0
IPv6 Entry Delete Success	0
IPv6 Entry Delete Fail	0
IP Entry Override	0
IP Entry Add Req Skip	0
Data Glean Memory Req Recv	0
Data Glean Memory Req Fail	0
Data Glean Memory Reg Send	0
Data Glean Memory Ret Recv	0
Data Glean Memory Ret Send	0
Data Glean Entry Send	0
IPSG Subblock Allocate	0
IPSG Subblock Allocate Fail	0
IPSG Subblock Free	0
IPSG Subblock Free Fail	0
IPSG FIA Enable	0
IPSG FIA Enable Fail	0
IPSG FIA Disable	0
IPSG FIA Disable Fail	0
IPSG Feature Enable	0
IPSG Feature Enable Fail	0
IPSG Feature Disable	0
IPSG Feature Disable Fail	0

----- show platform hardware chassis active qfp feature wireless ipsg cpp-client table ipv4 all -----

CPP Wireless IPSG Table Summary

Total number of address entries: 1

IP Address	VLAN	uIDB
177.1.0.7	177	95744

----- show platform hardware chassis active qfp feature wireless ipsg cpp-client table ipv6 all -----

CPP Wireless IPSG Table Summary

Total number of address entries: 0

----- show platform hardware chassis active qfp feature wireless ipsg datapath

```
statistics global -----
```

```
Wireless IPSG Global Statistics
```

```
-----
IPv6 Dataglean entry add      : 0
IPv6 Dataglean entry remove   : 0
IPv6 Dataglean allocation fail : 0
IPv6 Dataglean pool req send  : 0
IPv6 Dataglean pool req send fail : 0
IPv6 Dataglean pool req resp  : 0
IPv6 Dataglean pool ret send  : 0
IPv6 Dataglean pool ret send fail : 0
IPv6 Dataglean punt packet    : 0
IPv6 Dataglean drop packet    : 0
```

```
----- show platform hardware chassis active qfp feature wireless ipsg datapath
table ipv4 all -----
```

```
CPP Wireless IPSG IPv4 Table:
```

IP Address	VLAN	uIDB	Interface
177.1.0.7	177	95744	WLCLIENT-IF-0x00a0000001

```
----- show platform hardware chassis active qfp feature wireless ipsg datapath
table ipv6 all -----
```

```
CPP Wireless IPSG IPv6 Table:
```

IP Address	VLAN	uIDB	Interface
------------	------	------	-----------

```
----- show platform hardware chassis active qfp feature wireless halo statistics
-----
```

```
Wireless HALO Statistics
```

Rx Packet Count	0
Rx Packet Bytes	0

```
----- show platform hardware chassis active qfp feature wireless fqdn-filter
summary -----
```

```
CPP Wireless FQDN Filter Info:
```

ID	Type	DSA_hdl	Redirect_IPv4	Virtual_IPv4
----	------	---------	---------------	--------------

```
----- show platform hardware chassis active qfp feature wireless et-analytics
statistics -----
```

```
Wireless ETA cpp-client plumbing statistics
Number of ETA pending clients : 0
```

Counter	Value
---------	-------

```
-----  
Enable ETA on wireless client called      0  
Delete ETA on wireless client called      0  
ETA global cfg init cb TVI FIA enable error 0  
ETA global cfg init cb output SB read error 0  
ETA global cfg init cb output SB write error 0  
ETA global cfg init cb input SB read error 0  
ETA global cfg init cb input SB write error 0  
ETA global cfg init cb TVI FIA enable success 0  
ETA global cfg uninit cb ingress feat disable 0  
ETA global cfg uninit cb ingress cfg delete e 0  
ETA global cfg uninit cb egress feat disable 0  
ETA global cfg uninit cb egress cfg delete er 0  
ETA pending list insert entry called      0  
ETA pending list insert invalid arg error 0  
ETA pending list insert entry exists error 0  
ETA pending list insert no memory error   0  
ETA pending list insert entry failed      0  
ETA pending list insert entry success     0  
ETA pending list delete entry called      0  
ETA pending list delete invalid arg error 0  
ETA pending list delete entry missing     0  
ETA pending list delete entry remove error 0  
ETA pending list delete entry success     0
```

```
----- show platform hardware chassis active qfp feature wireless et-analytics  
eta-pending-client-tree -----
```

# show tech-support wireless fabric

To display global fabric parameters, use the **show tech-support wireless fabric** command in privileged EXEC mode.

## show tech-support wireless fabric

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
<b>Usage Guidelines</b>	<p>The output of the following commands are displayed as part of <b>show tech-support wireless fabric</b> command:</p> <ul style="list-style-type: none"> <li>• show wireless fabric summary</li> <li>• show wireless profile fabric summary</li> <li>• show fabric wlan summary</li> <li>• show fabric ap summary</li> <li>• show wireless fabric client summary</li> <li>• show wireless fabric media-stream client summary</li> <li>• show wireless stats fabric memory</li> <li>• show wireless stats fabric control-plane all</li> </ul>	

### Example

The following is sample output from the **show tech-support wireless fabric** command

# show tech-support wireless mobility

To print the data related to mobility, use the **show tech-support wireless mobility** command in privileged EXEC mode.

## show tech-support wireless mobility

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

**Usage Guidelines** The output of the following commands are displayed as part of **show tech-support wireless mobility** command:

- show platform hardware chassis active qfp feature wireless capwap cpp-client summary
- show platform hardware chassis active qfp feature wireless capwap datapath summary
- show platform hardware chassis active qfp feature wireless dtls cpp-client summary
- show platform hardware chassis active qfp feature wireless dtls datapath statistics
- show platform hardware chassis active qfp feature wireless dtls datapath summary
- show platform software capwap chassis active f0
- show platform software capwap chassis active r0
- show platform software dtls chassis active f0
- show platform software dtls chassis active r0
- show platform software ipc queue-based mobilityd chassis active R0 connection
- show platform software memory messaging mobilityd chassis active R0
- show platform software memory mobilityd chassis active R0 brief
- show wireless mobility ap-list
- show wireless mobility summary
- show wireless stats mobility
- show wireless stats mobility messages

In the presence of standby node, the output of the following mobility commands are also be displayed:

- show platform hardware chassis standby qfp feature wireless capwap cpp-client summary

- show platform hardware chassis standby qfp feature wireless capwap datapath summary
- show platform hardware chassis standby qfp feature wireless dtls cpp-client summary
- show platform hardware chassis standby qfp feature wireless dtls datapath statistics
- show platform hardware chassis standby qfp feature wireless dtls datapath summary
- show platform software capwap chassis standby f0
- show platform software capwap chassis standby r0
- show platform software dtls chassis standby f0
- show platform software dtls chassis standby r0
- show platform software ipc queue-based mobilityd chassis standby R0 connection
- show platform software memory messaging mobilityd chassis standby R0
- show platform software memory mobilityd chassis standby R0 brief
- show wireless stats mobility messages chassis standby r0

### Example

The following is sample output from the **show tech-support wireless mobility** command

```
Device# show tech-support wireless mobility
----- show wireless stats mobility -----

Mobility event statistics:
  Joined as
    Local                : 0
    Foreign              : 0
    Export foreign       : 0
    Export anchor        : 0
  Delete
    Local                : 0
    Remote               : 0
  Role changes
    Local to anchor      : 0
    Anchor to local      : 0
  Roam stats
    L2 roam count        : 0
    L3 roam count        : 0
    Flex client roam count : 0
    Inter-WNCd roam count : 0
    Intra-WNCd roam count : 0
  Anchor Request
    Sent                 : 0
    Grant received       : 0
    Deny received        : 0
  Received
    Grant sent           : 0
    Deny sent            : 0
  Handoff Status Received
    Success              : 0
    Group mismatch       : 0
```



```

Client unknown           : 0
Client blacklisted      : 0
SSID mismatch           : 0
Denied                   : 0
Handoff Status Sent
  Success                : 0
  Group mismatch         : 0
  Client unknown        : 0
  Client blacklisted    : 0
  SSID mismatch         : 0
  Denied                 : 0
Export Anchor
  Request Sent           : 0
  Response Received      :
    Ok                   : 0
    Deny - generic       : 0
    Client blacklisted   : 0
    Client limit reached : 0
    Profile mismatch     : 0
    Deny - unknown reason : 0
  Request Received      : 0
  Response Sent         :
    Ok                   : 0
    Deny - generic       : 0
    Client blacklisted   : 0
    Client limit reached : 0
    Profile mismatch     : 0
MM mobility event statistics:
  Event data allocs     : 0
  Event data frees      : 0
  FSM set allocs        : 0
  FSM set frees         : 0
  Timer allocs          : 0
  Timer frees           : 0
  Timer starts          : 0
  Timer stops           : 0
  Invalid events        : 0
  Internal errors       : 0

MMIF mobility event statistics:
  Event data allocs     : 0
  Event data frees      : 0
  Invalid events        : 0
  Unkown events         : 0
  Event schedule errors : 0
  Internal errors       : 0

```

----- show wireless stats mobility messages -----

```

MM datagram message statistics:
  Message Type      Built Tx   Rx   Processed Tx Error Rx Error Forwarded
  Retry Drops Allocs Frees
-----
  Mobile Announce   0    0   0    0         0       0         0
0    0    0    0
  Mobile Announce Nak 0    0   0    0         0       0         0
0    0    0    0

```

show tech-support wireless mobility

Static IP Mobile Annc	0	0	0	0	0	0	0	0
0 0 0 0								
Static IP Mobile Annc Rsp	0	0	0	0	0	0	0	0
0 0 0 0								
Handoff	0	0	0	0	0	0	0	0
0 0 0 0								
Handoff End	0	0	0	0	0	0	0	0
0 0 0 0								
Handoff End Ack	0	0	0	0	0	0	0	0
0 0 0 0								
Anchor Req	0	0	0	0	0	0	0	0
0 0 0 0								
Anchor Grant	0	0	0	0	0	0	0	0
0 0 0 0								
Anchor Xfer	0	0	0	0	0	0	0	0
0 0 0 0								
Anchor Xfer Ack	0	0	0	0	0	0	0	0
0 0 0 0								
Export Anchor Req	0	0	0	0	0	0	0	0
0 0 0 0								
Export Anchor Rsp	0	0	0	0	0	0	0	0
0 0 0 0								
AAA Handoff	0	0	0	0	0	0	0	0
0 0 0 0								
AAA Handoff Ack	0	0	0	0	0	0	0	0
0 0 0 0								
IPv4 Addr Update	0	0	0	0	0	0	0	0
0 0 0 0								
IPv4 Addr Update Ack	0	0	0	0	0	0	0	0
0 0 0 0								
IPv6 ND Packet	0	0	0	0	0	0	0	0
0 0 0 0								
IPv6 Addr Update	0	0	0	0	0	0	0	0
0 0 0 0								
IPv6 Addr Update Ack	0	0	0	0	0	0	0	0
0 0 0 0								
Client Add	0	0	0	0	0	0	0	0
0 0 0 0								
Client Delete	0	0	0	0	0	0	0	0
0 0 0 0								
Keepalive Ctrl Req	0	0	0	0	0	0	0	0
0 0 0 0								
Keepalive Ctrl Resp	0	0	0	0	0	0	0	0
0 0 0 0								
AP List Update	0	0	0	0	0	0	0	0
0 0 0 0								
Client Device Profile Info	0	0	0	0	0	0	0	0
0 0 0 0								
PMK Update	0	0	0	0	0	0	0	0
0 0 0 0								
PMK Delete	0	0	0	0	0	0	0	0
0 0 0 0								
PMK 11r Nonce Update	0	0	0	0	0	0	0	0
0 0 0 0								
Device cache Update	0	0	0	0	0	0	0	0
0 0 0 0								
HA SSO Announce	0	0	0	0	0	0	0	0
0 0 0 0								
HA SSO Announce Resp	0	0	0	0	0	0	0	0
0 0 0 0								

MM IPC message statistics:

Message Type	Built	Tx	Rx	Processed	Tx Error	Rx Error	Forwarded
Drops Allocs Frees							

```

-----
Mobile Announce          0    0    0    0    0    0    0
0      0      0
Mobile Announce Nak     0    0    0    0    0    0    0
0      0      0
Static IP Mobile Annc   0    0    0    0    0    0    0
0      0      0
Static IP Mobile Annc Rsp 0    0    0    0    0    0    0
0      0      0
Handoff                  0    0    0    0    0    0    0
0      0      0
Handoff End              0    0    0    0    0    0    0
0      0      0
Handoff End Ack         0    0    0    0    0    0    0
0      0      0
Anchor Req               0    0    0    0    0    0    0
0      0      0
Anchor Grant             0    0    0    0    0    0    0
0      0      0
Anchor Xfer              0    0    0    0    0    0    0
0      0      0
Anchor Xfer Ack         0    0    0    0    0    0    0
0      0      0
Export Anchor Req       0    0    0    0    0    0    0
0      0      0
Export Anchor Rsp       0    0    0    0    0    0    0
0      0      0
AAA Handoff              0    0    0    0    0    0    0
0      0      0
AAA Handoff Ack         0    0    0    0    0    0    0
0      0      0
IPv4 Addr Update        0    0    0    0    0    0    0
0      0      0
IPv4 Addr Update Ack    0    0    0    0    0    0    0
0      0      0
IPv6 ND Packet          0    0    0    0    0    0    0
0      0      0
IPv6 Addr Update        0    0    0    0    0    0    0
0      0      0
IPv6 Addr Update Ack    0    0    0    0    0    0    0
0      0      0
Client Add               0    0    0    0    0    0    0
0      0      0
Client Delete           0    0    0    0    0    0    0
0      0      0
Keepalive Ctrl Req      0    0    0    0    0    0    0
0      0      0
Keepalive Ctrl Resp     0    0    0    0    0    0    0
0      0      0
AP List Update          0    0    0    0    0    0    0
0      0      0
Client Device Profile Info 0    0    0    0    0    0    0
0      0      0
PMK Update               0    0    0    0    0    0    0
0      0      0
PMK Delete              0    0    0    0    0    0    0
0      0      0
PMK 11r Nonce Update    0    0    0    0    0    0    0
0      0      0
Device cache Update     0    0    0    0    0    0    0
0      0      0
HA SSO Announce         0    0    0    0    0    0    0

```

show tech-support wireless mobility

```

0      0      0
  HA SSO Announce Resp      0      0      0      0      0      0
0      0      0
  
```

MMIF IPC message statistics:

Message Type Frees	Built	Tx	Rx	Processed	Tx Error	Rx Error	Drops	Allocs
-----								
Mobile Announce 0	0	0	0	0	0	0	0	0
Mobile Announce Nak 0	0	0	0	0	0	0	0	0
Static IP Mobile Annc 0	0	0	0	0	0	0	0	0
Static IP Mobile Annc Rsp 0	0	0	0	0	0	0	0	0
Handoff 0	0	0	0	0	0	0	0	0
Handoff End 0	0	0	0	0	0	0	0	0
Handoff End Ack 0	0	0	0	0	0	0	0	0
Anchor Req 0	0	0	0	0	0	0	0	0
Anchor Grant 0	0	0	0	0	0	0	0	0
Anchor Xfer 0	0	0	0	0	0	0	0	0
Anchor Xfer Ack 0	0	0	0	0	0	0	0	0
Export Anchor Req 0	0	0	0	0	0	0	0	0
Export Anchor Rsp 0	0	0	0	0	0	0	0	0
AAA Handoff 0	0	0	0	0	0	0	0	0
AAA Handoff Ack 0	0	0	0	0	0	0	0	0
IPv4 Addr Update 0	0	0	0	0	0	0	0	0
IPv4 Addr Update Ack 0	0	0	0	0	0	0	0	0
IPv6 ND Packet 0	0	0	0	0	0	0	0	0
IPv6 Addr Update 0	0	0	0	0	0	0	0	0
IPv6 Addr Update Ack 0	0	0	0	0	0	0	0	0
Client Add 0	0	0	0	0	0	0	0	0
Client Delete 0	0	0	0	0	0	0	0	0
Keepalive Ctrl Req 0	0	0	0	0	0	0	0	0
Keepalive Ctrl Resp 0	0	0	0	0	0	0	0	0
AP List Update 0	0	0	0	0	0	0	0	0
Client Device Profile Info 0	0	0	0	0	0	0	0	0
PMK Update 0	0	0	0	0	0	0	0	0

```

PMK Delete          0      0      0      0      0      0      0      0      0
0
PMK 11r Nonce Update 0      0      0      0      0      0      0      0      0
0
Device cache Update 0      0      0      0      0      0      0      0      0
0
HA SSO Announce     0      0      0      0      0      0      0      0      0
0
HA SSO Announce Resp 0      0      0      0      0      0      0      0      0
0
    
```

----- show wireless mobility summary -----

Mobility Summary

```

Wireless Management VLAN: 32
Wireless Management IP Address: 9.12.32.10
Mobility Control Message DSCP Value: 48
Mobility Keepalive Interval/Count: 10/3
Mobility Group Name: default
Mobility Multicast Ipv4 address: 0.0.0.0
Mobility Multicast Ipv6 address: ::
Mobility MAC Address: 001e.f6c1.f6ff
    
```

Controllers configured in the Mobility Domain:

IP Multicast IPv6	Public Ip	Group Name	Status	Multicast IPv4 PMTU
9.12.32.10	N/A	default	N/A	0.0.0.0 N/A
				::

----- show wireless mobility ap-list -----

----- show platform software capwap chassis active r0 -----

----- show platform software capwap chassis active f0 -----

----- show platform software dtls chassis active r0 -----

----- show platform software dtls chassis active f0 -----

----- show platform hardware chassis active qfp feature wireless capwap  
cpp-client summary -----

----- show platform hardware chassis active qfp feature wireless dtls cpp-client  
summary -----

```
----- show platform hardware chassis active qfp feature wireless capwap datapath
summary -----
```

```
Vrf Src Port Dst IP          Dsp Port Input Uidb Output Uidb Instance Id
---  -----  -----  -----  -----  -----  -----
```

```
----- show platform hardware chassis active qfp feature wireless dtls datapath
statistics -----
```

#### CPP Wireless DTLS Feature Stats

Description	Packet Count	Octet Count
DTLS Packets To Encrypt	0	0
DTLS Packets Encrypted	0	0
DTLS Packets To Decrypt	0	0
DTLS Packets Decrypted	0	0
Skip Encryption - Handshake	0	0
Skip Encryption - Not AppData	0	0
Skip Encryption - No Hash Entry	0	0
Skip Encryption - No Crypto Handle	0	0
Skip Encryption - No DTLS header	0	0
Skip Encryption - Requested by RP	0	0
Skip Decryption - Handshake	0	0
Skip Decryption - Not AppData	0	0
Skip Decryption - No Hash Entry	0	0
Skip Decryption - No Crypto Handle	0	0
Skip Decryption - No DTLS header	0	0
Skip Decryption - Multiple Records	0	0
Error - Encrypt Invalid Length	0	0
Error - Encrypt Header Restore	0	0
Error - DataEncrypt No Crypto Handle	0	0
Error - DataEncrypt Header Restore	0	0
Error - Decrypt Invalid Length	0	0
Error - Decrypt Header Restore	0	0
Error - DataDecrypt Zero Epoch	0	0
Error - DataDecrypt No Hash Entry	0	0
Error - DataDecrypt No Crypto Handle	0	0
Error - DataDecrypt Header Restore	0	0

```
----- show platform hardware chassis active qfp feature wireless dtls datapath
summary -----
```

```
Src IP          Dst IP          Src Port Dst Port  Crypto HDL      Instance Id
-----  -----  -----  -----  -----  -----
```

```
----- show platform software ipc queue-based mobilityd chassis active R0
connection -----
```

```
Name: -mobilityd_to_wncd-b0
Number      : 0
Mode        : writer
Created on  : 03/22/18 05:35:06
Queue Size  : 524288 bytes, 0 bytes currently used
Enqueued    : 12 msgs, 432 bytes, 0 err, 0 back-pressures,
              360 bytes max queue utilization,
              0 times reached above 90%, 0 times reached above 75%
```

```
Name: -mobilityd_to_wncd-b1
Number      : 1
Mode        : writer
Created on  : 03/22/18 05:35:06
Queue Size  : 524288 bytes, 0 bytes currently used
Enqueued    : 12 msgs, 432 bytes, 0 err, 0 back-pressures,
              360 bytes max queue utilization,
              0 times reached above 90%, 0 times reached above 75%

Name: -mobilityd_to_wncd-b2
Number      : 2
Mode        : writer
Created on  : 03/22/18 05:35:06
Queue Size  : 524288 bytes, 0 bytes currently used
Enqueued    : 12 msgs, 432 bytes, 0 err, 0 back-pressures,
              360 bytes max queue utilization,
              0 times reached above 90%, 0 times reached above 75%

Name: -mobilityd_to_fman_rp-b0
Number      : 3
Mode        : writer
Created on  : 03/22/18 05:35:06
Queue Size  : 524288 bytes, 0 bytes currently used
Enqueued    : 0 msgs, 0 bytes, 0 err, 0 back-pressures,
              0 bytes max queue utilization,
              0 times reached above 90%, 0 times reached above 75%

Name: -mobilityd_to_iosd_rp-b0
Number      : 4
Mode        : writer
Created on  : 03/22/18 05:35:06
Queue Size  : 524288 bytes, 0 bytes currently used
Enqueued    : 204647 msgs, 15757819 bytes, 0 err, 0 back-pressures,
              81 bytes max queue utilization,
              0 times reached above 90%, 0 times reached above 75%

Name: -mobilityd_to_wncmgrd-b0
Number      : 5
Mode        : writer
Created on  : 03/22/18 05:35:06
Queue Size  : 524288 bytes, 0 bytes currently used
Enqueued    : 12 msgs, 432 bytes, 0 err, 0 back-pressures,
              360 bytes max queue utilization,
              0 times reached above 90%, 0 times reached above 75%

Name: -odm_clnt2svr_data-mobilityd-000-1
Number      : 6
Mode        : writer
Created on  : 03/22/18 05:35:06
Queue Size  : 2097152 bytes, 0 bytes currently used
Enqueued    : 33 msgs, 12535 bytes, 0 err, 0 back-pressures,
              3769 bytes max queue utilization,
              0 times reached above 90%, 0 times reached above 75%

Name: -odm_svr2clnt_data-mobilityd-000-1
Number      : 7
Mode        : reader
Created on  : 03/22/18 05:35:06
Queue Size  : 2097152 bytes, 0 bytes currently used
Dequeued    : 0 msgs, 0 bytes, 0 err

Name: -fman_rp_to_mobilityd-b0
Number      : 8
Mode        : reader
```

## show tech-support wireless mobility

```

Created on : 03/22/18 05:35:08
Queue Size : 524288 bytes, 0 bytes currently used
Dequeued  : 0 msgs, 0 bytes, 0 err

Name: -wncd_to_mobilityd-b0
Number   : 9
Mode     : reader
Created on : 03/22/18 05:35:13
Queue Size : 524288 bytes, 0 bytes currently used
Dequeued  : 39 msgs, 1404 bytes, 0 err

Name: -wncd_to_mobilityd-b1
Number   : 10
Mode     : reader
Created on : 03/22/18 05:35:13
Queue Size : 524288 bytes, 0 bytes currently used
Dequeued  : 39 msgs, 1404 bytes, 0 err

Name: -wncd_to_mobilityd-b2
Number   : 11
Mode     : reader
Created on : 03/22/18 05:35:14
Queue Size : 524288 bytes, 0 bytes currently used
Dequeued  : 39 msgs, 1404 bytes, 0 err

Name: -wncmgrd_to_mobilityd-b0
Number   : 12
Mode     : reader
Created on : 03/22/18 05:35:14
Queue Size : 524288 bytes, 0 bytes currently used
Dequeued  : 18 msgs, 648 bytes, 0 err

Name: -iosd_rp_to_mobilityd-b0
Number   : 13
Mode     : reader
Created on : 03/22/18 05:35:30
Queue Size : 1048576 bytes, 0 bytes currently used
Dequeued  : 204647 msgs, 18827524 bytes, 0 err

Name: -odm_clnt2svr_data-ifid-005-1
Number   : 14
Mode     : writer
Created on : 03/22/18 05:35:37
Queue Size : 2097152 bytes, 0 bytes currently used
Enqueued  : 0 msgs, 0 bytes, 0 err, 0 back-pressures,
           0 bytes max queue utilization,
           0 times reached above 90%, 0 times reached above 75%

Name: -odm_svr2clnt_data-ifid-005-1
Number   : 15
Mode     : reader
Created on : 03/22/18 05:35:37
Queue Size : 2097152 bytes, 0 bytes currently used
Dequeued  : 0 msgs, 0 bytes, 0 err

----- show platform software memory messaging mobilityd chassis active R0
-----

[tdl_toc] type toc_table_info/47da701cd9c36de7e888ca6d8dd80390/0 created:3 destroyed:3
diff:0
[tdl_sr] type repl_table_name/29184a6d15c1ball1acb2d0bd22eb6e36/0 created:33 destroyed:33
diff:0

```



```

[tldl_sr] type repl_database_name/e9118a691a20b4b8f1118bc37a894603/0 created:33 destroyed:33
diff:0
[tldl_sr] type repl_pkey_tdl/83de2d20ec3ca19b8ae9a89147480a25/1 created:33 destroyed:33
diff:0
[tldl_sr] type repl_blob_tdl/016a67083ea407334130436c855ae237/0 created:33 destroyed:33
diff:0
[tldl_sr] type repl_luid/b9c9d9f4876af528cb82273df98479d6/0 created:33 destroyed:33 diff:0
[tldl_sr] type repl_objinfo/6c8800fedf8d71512f9b6c9754db3a70/0 created:33 destroyed:33 diff:0
[tldl_sr] message repl_trec_update/15fe2a39409473179c9e7111851b2196/0 created:33 destroyed:33
diff:0
[pki_ssl] type buff/941d8a519d6f23d27067617119f1bb38/0 created:613944 destroyed:613944
diff:0
[pki_ssl] type get_certid_params/0d7bcce690f74649c2e33bbf341e2229/0 created:204648
destroyed:204648 diff:0
[pki_ssl] type get_certid_callback_params/708b7fb964ace7971d90a452c830488c/0 created:204648
destroyed:204648 diff:0
[pki_ssl] message get_certid/ee3bfe6b93901440346417a4ad67fa63/0 created:204648
destroyed:204648 diff:0
[pki_ssl] message get_certid_callback/372218059d7a753ba73f7b06f18532e9/0 created:204648
destroyed:204648 diff:0
[svc_defs] type svc_loc/929237802cf26e862f8e8716169e31ef/0 created:40952 destroyed:40951
diff:1
[ui_shr] type ui_client/bec7457db0c33cae9eeebbf80073b771/0 created:3 destroyed:2 diff:1
[ui] type ui_info/4b8b42a883fabbb98ec8b919f60e4ad6/0 created:40949 destroyed:40949 diff:0
[ui] type ui_req/69f1e2a5943e050f0aa12df8639ba442/0 created:3 destroyed:2 diff:1
[ui] type event_statistics/7f346ee47165c035a72e139b84afb2a0/0 created:40948 destroyed:40948
diff:0
[ui] type hostinfo_data/54d5a8b0cd4d29d575b2fc0d91695b5e/0 created:3 destroyed:3 diff:0
[ui] message ui_info_msg/bec533dd713e0222cb8fe5df868031f0/0 created:1 destroyed:1 diff:0
[ui] message ui_req_msg/ac9905cc4488c976847affab56d8b50c/0 created:3 destroyed:2 diff:1
[ui] message process_event_statistics/65d07aa3a04ad950cddd46444df6bc02/0 created:40948
destroyed:40948 diff:0
[ui] message hostinfo_notify/2e9d975712b85b41bc489a6adbc4a46c/0 created:3 destroyed:3 diff:0
[uipeer_comm_ui] type mqipc_enqueue_stats/8f41e408c97a799a5e431d2279acd8de/0 created:8
destroyed:8 diff:0
[uipeer_comm_ui] type mqipc_dequeue_stats/aafe5d0a37ba9652d68550efa26eb0b6/0 created:8
destroyed:8 diff:0
[uipeer_comm_ui] type mqipc_connection_properties/35bd274fd85f7359066f898f25c853ee/0
created:16 destroyed:16 diff:0
[uipeer_comm_ui] message mqipc_connection/a1b22c74b279335b895531ce708c804b/0 created:16
destroyed:16 diff:0
[mem_stats_ui] type tdl_variant_stat/bd85e4b89fb10501e68c1a3cedb9f321/0 created:1 destroyed:0
diff:1
[mem_stats_ui] message tdl_mem_stats/60ffd9d51213767d041b543869df15d2/0 created:1 destroyed:0
diff:1
[cdlcore] type cdl_params/a3e74327d37abf27f799f2b5155f4923/0 created:2 destroyed:1 diff:1
[cdlcore] message cdl_message/35205e535c7ab2cdcb3c265ac788f973/0 created:2 destroyed:1
diff:1
[odm_defs] type odm_context/73aeeeb77a1ccb6e44f690745cdafe0d/1 created:23 destroyed:23
diff:0
[odm_defs] type odm_register_info/48a7d590e9df0cc9d150801315c50307/1 created:4 destroyed:4
diff:0
[odm_defs] type odm_table_register_info/4f355a34615affd49af9f90b679d8ce5/1 created:17
destroyed:17 diff:0
[odm_defs] type odm_register_result/53ba304bc0a71a7d2a044518c21f662a/0 created:2 destroyed:2
diff:0
[odm_defs] message odm_register/2c98272b43d973fa08bbf5acdf3106b0/0 created:2 destroyed:2
diff:0
[odm_defs] message odm_table_register/46694ec1005c3b084337748eeb3768cd/0 created:17
destroyed:17 diff:0
[odm_defs] message odm_register_done/1f6c8f81fcbb8a3052428bab7588e8b5/0 created:2 destroyed:2
diff:0
[odm_defs] message odm_register_ack/03b8040ed4f7b03517b410c32568ecaa/0 created:2 destroyed:2
diff:0

```

```
----- show platform software memory mobilityd chassis active R0 brief
-----
```

module	allocated	requested	allocs	frees
Summary	620441	617113	233	25
unknown	198515	198435	5	0
chunk	139689	139209	30	0
eventutil	118939	118299	48	8
process	67642	67594	3	0
odm-db-ctx	29950	28430	100	5
uipeer	22672	22592	11	6
odm-ipc-ctx	20272	19984	18	0
unknown	18024	18008	1	0
odm-client-ctx	1872	1824	3	0
cdllib	1688	1672	3	2
trccfg	512	496	5	4
bidb	472	456	1	0
unknown	96	48	3	0
bcrdu_avl	72	56	1	0
orchestrator_main	26	10	1	0

# show tech-support wireless radio

To print the data related to the radio, use the **show tech-support wireless radio** command in privileged EXEC mode.

## show tech-support wireless radio

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

**Usage Guidelines** The output of the following commands are displayed as part of **show tech-support wireless radio** command:

- show ap auto-rf dot11 24ghz
- show ap auto-rf dot11 5ghz
- show ap config dot11 dual-band summary
- show ap config general
- show ap dot11 24ghz channel
- show ap dot11 24ghz coverage
- show ap dot11 24ghz group
- show ap dot11 24ghz high-density
- show ap dot11 24ghz load-info
- show ap dot11 24ghz monitor
- show ap dot11 24ghz network
- show ap dot11 24ghz summary
- show ap dot11 24ghz txpower
- show ap dot11 5ghz channel
- show ap dot11 5ghz coverage
- show ap dot11 5ghz group
- show ap dot11 5ghz high-density
- show ap dot11 5ghz load-info

- show ap dot11 5ghz monitor
- show ap dot11 5ghz network
- show ap dot11 5ghz summary
- show ap dot11 5ghz txpower
- show ap fra
- show ap rf-profile name Rfl detail
- show ap rf-profile summary
- show ap summary
- show wireless band-select

### Example

The following is sample output from the **show tech-support wireless radio** command

```
Device# show tech-support wireless radio
----- show ap summary -----

Number of APs: 0

----- show ap dot11 24ghz summary -----

----- show ap dot11 5ghz summary -----

----- show ap config dot11 dual-band summary -----

----- show ap dot11 24ghz channel -----

Leader Automatic Channel Assignment
Channel Assignment Mode           : AUTO
Channel Update Interval           : 600 seconds
Anchor time (Hour of the day)     : 0
Channel Update Contribution
  Noise                           : Enable
  Interference                     : Enable
  Load                            : Disable
  Device Aware                    : Disable
CleanAir Event-driven RRM option  : Disabled
Channel Assignment Leader         : ewlc-doc (9.12.32.10)
Last Run                          : 550 seconds ago

DCA Sensitivity Level             : MEDIUM : 10 dB
DCA Minimum Energy Limit          : -95 dBm
Channel Energy Levels
```

```

Minimum : unknown
Average : unknown
Maximum : -128 dBm
Channel Dwell Times
Minimum : unknown
Average : unknown
Maximum : unknown
802.11b 2.4 GHz Auto-RF Channel List
Allowed Channel List : 1,6,11
Unused Channel List : 2,3,4,5,7,8,9,10

```

----- show ap dot11 5ghz channel -----

```

Leader Automatic Channel Assignment
Channel Assignment Mode : AUTO
Channel Update Interval : 600 seconds
Anchor time (Hour of the day) : 0
Channel Update Contribution
  Noise : Enable
  Interference : Enable
  Load : Disable
  Device Aware : Disable
CleanAir Event-driven RRM option : Disabled
Channel Assignment Leader : ewlc-doc (9.12.32.10)
Last Run : 552 seconds ago

DCA Sensitivity Level : MEDIUM : 15 dB
DCA 802.11n/ac Channel Width : 20 MHz
DCA Minimum Energy Limit : -95 dBm
Channel Energy Levels
  Minimum : unknown
  Average : unknown
  Maximum : -128 dBm
Channel Dwell Times
  Minimum : unknown
  Average : unknown
  Maximum : unknown
802.11a 5 GHz Auto-RF Channel List
Allowed Channel List :
36,40,44,48,52,56,60,64,100,104,108,112,116,120,124,128,132,136,140,144,149,153,157,161
Unused Channel List : 165

```

----- show ap dot11 24ghz coverage -----

```

Coverage Hole Detection
802.11b Coverage Hole Detection Mode : Enabled
802.11b Coverage Voice Packet Count : 100 packet(s)
802.11b Coverage Voice Packet Percentage : 50%
802.11b Coverage Voice RSSI Threshold : -80 dBm
802.11b Coverage Data Packet Count : 50 packet(s)
802.11b Coverage Data Packet Percentage : 50%
802.11b Coverage Data RSSI Threshold : -80 dBm
802.11b Global coverage exception level : 25 %
802.11b Global client minimum exception level : 3 clients

```

----- show ap dot11 5ghz coverage -----

```

Coverage Hole Detection

```

```

802.11a Coverage Hole Detection Mode      : Enabled
802.11a Coverage Voice Packet Count     : 100 packet(s)
802.11a Coverage Voice Packet Percentage : 50 %
802.11a Coverage Voice RSSI Threshold   : -80dBm
802.11a Coverage Data Packet Count      : 50 packet(s)
802.11a Coverage Data Packet Percentage : 50 %
802.11a Coverage Data RSSI Threshold    : -80dBm
802.11a Global coverage exception level  : 25 %
802.11a Global client minimum exception level : 3 clients

```

```
----- show ap dot11 24ghz group -----
```

## Radio RF Grouping

```

802.11b Group Mode           : AUTO
802.11b Group Update Interval : 600 seconds
802.11b Group Leader         : ewlc-doc (9.12.32.10)
802.11b Last Run             : 553 seconds ago

```

## RF Group Members

```

Controller name           Controller IP
-----
ewlc-doc                  9.12.32.10

```

```
----- show ap dot11 5ghz group -----
```

## Radio RF Grouping

```

802.11a Group Mode           : AUTO
802.11a Group Update Interval : 600 seconds
802.11a Group Leader         : ewlc-doc (9.12.32.10)
802.11a Last Run             : 553 seconds ago

```

## RF Group Members

```

Controller name           Controller IP
-----
ewlc-doc                  9.12.32.10

```

```
----- show ap dot11 24ghz high-density -----
```

```
----- show ap dot11 5ghz high-density -----
```

```
----- show ap dot11 5ghz load-info -----
```

```
----- show ap dot11 24ghz load-info -----
```

----- show ap dot11 24ghz profile -----

```
Default 802.11b AP performance profiles
802.11b Global Interference threshold : 10 %
802.11b Global noise threshold       : -70 dBm
802.11b Global RF utilization threshold : 80 %
802.11b Global throughput threshold  : 1000000 bps
802.11b Global clients threshold     : 12 clients
```

----- show ap dot11 5ghz profile -----

```
Default 802.11a AP performance profiles

802.11a Global Interference threshold : 10 %
802.11a Global noise threshold       : -70 dBm
802.11a Global RF utilization threshold : 80 %
802.11a Global throughput threshold  : 1000000 bps
802.11a Global clients threshold     : 12 clients
```

----- show ap dot11 24ghz monitor -----

```
Default 802.11b AP monitoring
802.11b Monitor Mode           : Enabled
802.11b Monitor Channels       : Country channels
802.11b RRM Neighbor Discover Type : Transparent
802.11b AP Coverage Interval   : 180 seconds
802.11b AP Load Interval      : 60 seconds
802.11b AP Noise Interval     : 180 seconds
802.11b AP Signal Strength Interval : 60 seconds
802.11b NDP RSSI Normalization  : Enabled
```

----- show ap dot11 5ghz monitor -----

```
Default 802.11a AP monitoring
802.11a Monitor Mode           : Enabled
802.11a Monitor Channels       : Country channels
802.11a RRM Neighbor Discover Type : Transparent
802.11a AP Coverage Interval   : 180 seconds
802.11a AP Load Interval      : 60 seconds
802.11a AP Noise Interval     : 180 seconds
802.11a AP Signal Strength Interval : 60 seconds
802.11a NDP RSSI Normalization  : Enabled
```

----- show ap dot11 24ghz network -----

```
802.11b Network           : Enabled
11gSupport                 : Enabled
11nSupport                 : Enabled
802.11b/g Operational Rates
802.11b 1M                 : Mandatory
```

## show tech-support wireless radio

```

802.11b 2M : Mandatory
802.11b 5.5M : Mandatory
802.11b 11M : Mandatory
802.11g 6M : Supported
802.11g 9M : Supported
802.11g 12M : Supported
802.11g 18M : Supported
802.11g 24M : Supported
802.11g 36M : Supported
802.11g 48M : Supported
802.11g 54M : Supported
802.11n MCS Settings:
MCS 0 : Supported
MCS 1 : Supported
MCS 2 : Supported
MCS 3 : Supported
MCS 4 : Supported
MCS 5 : Supported
MCS 6 : Supported
MCS 7 : Supported
MCS 8 : Supported
MCS 9 : Supported
MCS 10 : Supported
MCS 11 : Supported
MCS 12 : Supported
MCS 13 : Supported
MCS 14 : Supported
MCS 15 : Supported
MCS 16 : Supported
MCS 17 : Supported
MCS 18 : Supported
MCS 19 : Supported
MCS 20 : Supported
MCS 21 : Supported
MCS 22 : Supported
MCS 23 : Supported
MCS 24 : Supported
MCS 25 : Supported
MCS 26 : Supported
MCS 27 : Supported
MCS 28 : Supported
MCS 29 : Supported
MCS 30 : Supported
MCS 31 : Supported
802.11n Status:
A-MPDU Tx:
Priority 0 : Enabled
Priority 1 : Disabled
Priority 2 : Disabled
Priority 3 : Disabled
Priority 4 : Enabled
Priority 5 : Enabled
Priority 6 : Disabled
Priority 7 : Disabled
Aggregation scheduler : Enabled
Realtime timeout : 10
A-MSDU Tx:
Priority 0 : Enable
Priority 1 : Enable
Priority 2 : Enable
Priority 3 : Enable
Priority 4 : Enable
Priority 5 : Enable
Priority 6 : Disable

```



```

Priority 7 : Disable
Guard Interval : Any
Rifs Rx : Enabled
Beacon Interval : 100
CF Pollable mandatory : Disabled
CF Poll Request Mandatory : Disabled
CFP Period : 4
CFP Maximum Duration : 60
Default Channel : 1
Default Tx Power Level : 1
DTPC Status : Enabled
Call Admission Limit :
G711 CU Quantum :
ED Threshold : -50
Fragmentation Threshold : 2346
RSSI Low Check : Disabled
RSSI Threshold : -127 dbm
PBCC Mandatory : unknown
Pico-Cell-V2 Status : unknown
RTS Threshold : 2347
Short Preamble Mandatory : Enabled
Short Retry Limit : 7
Legacy Tx Beamforming setting : Disabled
Traffic Stream Metrics Status : Disabled
Expedited BW Request Status : Disabled
EDCA profile type check : default-wmm
Call Admission Control (CAC) configuration
Voice AC
Voice AC - Admission control (ACM) : Disabled
Voice Stream-Size : 84000
Voice Max-Streams : 2
Voice Max RF Bandwidth : 75
Voice Reserved Roaming Bandwidth : 6
Voice Load-Based CAC mode : Enabled
Voice tspec inactivity timeout : Enabled
CAC SIP-Voice configuration
SIP based CAC : Disabled
SIP call bandwidth : 64
SIP call bandwidth sample-size : 20
Maximum Number of Clients per AP Radio : 200

```

```
----- show ap dot11 5ghz network -----
```

```

802.11a Network : Enabled
11nSupport : Enabled
802.11a Low Band : Enabled
802.11a Mid Band : Enabled
802.11a High Band : Enabled
802.11a Operational Rates
802.11a 6M : Mandatory
802.11a 9M : Supported
802.11a 12M : Mandatory
802.11a 18M : Supported
802.11a 24M : Mandatory
802.11a 36M : Supported
802.11a 48M : Supported
802.11a 54M : Supported
802.11n MCS Settings:
MCS 0 : Supported
MCS 1 : Supported
MCS 2 : Supported

```

```

MCS 3 : Supported
MCS 4 : Supported
MCS 5 : Supported
MCS 6 : Supported
MCS 7 : Supported
MCS 8 : Supported
MCS 9 : Supported
MCS 10 : Supported
MCS 11 : Supported
MCS 12 : Supported
MCS 13 : Supported
MCS 14 : Supported
MCS 15 : Supported
MCS 16 : Supported
MCS 17 : Supported
MCS 18 : Supported
MCS 19 : Supported
MCS 20 : Supported
MCS 21 : Supported
MCS 22 : Supported
MCS 23 : Supported
MCS 24 : Supported
MCS 25 : Supported
MCS 26 : Supported
MCS 27 : Supported
MCS 28 : Supported
MCS 29 : Supported
MCS 30 : Supported
MCS 31 : Supported
802.11n Status:
A-MPDU Tx:
  Priority 0 : Enabled
  Priority 1 : Disabled
  Priority 2 : Disabled
  Priority 3 : Disabled
  Priority 4 : Enabled
  Priority 5 : Enabled
  Priority 6 : Disabled
  Priority 7 : Disabled
  Aggregation scheduler : Enabled
  Realtime timeout : 10
A-MSDU Tx:
  Priority 0 : Enable
  Priority 1 : Enable
  Priority 2 : Enable
  Priority 3 : Enable
  Priority 4 : Enable
  Priority 5 : Enable
  Priority 6 : Disable
  Priority 7 : Disable
  Guard Interval : Any
Rifs Rx : Enabled
802.11ac : Enabled
  Frame burst : Automatic
802.11ac MCS Settings:
Beacon Interval : 100
CF Pollable mandatory : Disabled
CF Poll Request Mandatory : Disabled
CFP Period : 4
CFP Maximum Duration : 60
Default Channel : 36
Default Tx Power Level : 1
DTPC Status : Enabled
Fragmentation Threshold : 2346

```

```

RSSI Low Check                : Disabled
RSSI Threshold                 : -127 dbm
Pico-Cell-V2 Status           : unknown
TI Threshold                   :
Legacy Tx Beamforming setting  : Disabled
Traffic Stream Metrics Status  : Disabled
Expedited BW Request Status    : Disabled
EDCA profile type check        : default-wmm
Call Admission Control (CAC) configuration
Voice AC
  Voice AC - Admission control (ACM) : Disabled
  Voice Stream-Size                 : 84000
  Voice Max-Streams                  : 2
  Voice Max RF Bandwidth             : 75
  Voice Reserved Roaming Bandwidth   : 6
  Voice Load-Based CAC mode          : Enabled
  Voice tspec inactivity timeout     : Enabled
CAC SIP-Voice configuration
  SIP based CAC                     : Disabled
  SIP call bandwidth                 : 64
  SIP call bandwidth sample-size     : 20
Maximum Number of Clients per AP Radio : 200

```

```
----- show ap dot11 24ghz txpower -----
```

#### Automatic Transmit Power Assignment

```

Transmit Power Assignment Mode : AUTO
Transmit Power Update Interval : 600 seconds
Transmit Power Threshold       : -70 dBm
Transmit Power Neighbor Count  : 3 APs
Min Transmit Power              : -10 dBm
Max Transmit Power              : 30 dBm
Update Contribution
  Noise                          : Enable
  Interference                    : Enable
  Load                            : Disable
  Device Aware                    : Disable
Transmit Power Assignment Leader : ewlc-doc (9.12.32.10)
Last Run                         : 558 seconds ago

```

```
----- show ap dot11 5ghz txpower -----
```

#### Automatic Transmit Power Assignment

```

Transmit Power Assignment Mode : AUTO
Transmit Power Update Interval : 600 seconds
Transmit Power Threshold       : -70 dBm
Transmit Power Neighbor Count  : 3 APs
Min Transmit Power              : -10 dBm
Max Transmit Power              : 30 dBm
Update Contribution
  Noise                          : Enable
  Interference                    : Enable
  Load                            : Disable
  Device Aware                    : Disable
Transmit Power Assignment Leader : ewlc-doc (9.12.32.10)
Last Run                         : 558 seconds ago

```

```
----- show ap auto-rf dot11 5ghz -----
```

```
----- show ap auto-rf dot11 24ghz -----
```

```
----- show ap config general -----
```

```
----- show ap dot11 5ghz optimized-roaming -----
```

802.11a OptimizedRoaming

```
Mode                               : Disabled
Reporting Interval                 : 90 seconds
Rate Threshold                     : Disabled
Hysteresis                         : 6 db
```

```
----- show ap rf-profile summary -----
```

Number of RF-profiles: 6

RF Profile Name	Band	Description	State
Low_Client_Density_rf_5gh	5 GHz	pre configured Low Client Density rf	Up
High_Client_Density_rf_5gh	5 GHz	pre configured High Client Density r	Up
Low_Client_Density_rf_24gh	2.4 GHz	pre configured Low Client Density rf	Up
High_Client_Density_rf_24gh	2.4 GHz	pre configured High Client Density r	Up
Typical_Client_Density_rf_5gh	5 GHz	pre configured Typical Density rfpro	Up
Typical_Client_Density_rf_24gh	2.4 GHz	pre configured Typical Client Densit	Up

```
----- show ap fra -----
```

```
FRA State                          : Disabled
FRA Sensitivity                    : medium (95%)
FRA Interval                       : 1 Hour(s)
  Last Run                         : 2299 seconds ago
  Last Run time                    : 0 seconds
```

AP Name	MAC Address	Slot ID	Current-Band	COF %	Suggested Mode
---------	-------------	---------	--------------	-------	----------------

COF : Coverage Overlap Factor

```
----- show wireless band-select -----
```

```
Band Select Probe Response         : per WLAN enabling
Cycle Count                        : 2
Cycle Threshold (millisec)        : 200
Age Out Suppression (sec)         : 20
Age Out Dual Band (sec)           : 60
Client RSSI (dBm)                 : -80
Client Mid RSSI (dBm)             : -80
```

```
----- show wireless country configure -----
```

```
Configured Country..... US - United States
Configured Country Codes
    US - United States          802.11a Indoor/ 802.11b Indoor/ 802.11g Indoor
```

```
----- show wireless tag rf summary -----
```

```
Number of RF Tags: 1
```

```
RF tag name          Description
-----
default-rf-tag      default RF tag
```

```
----- show ap tag summary -----
```

```
Number of APs: 0
```

```
----- show ap status -----
```

```
----- show ap uptime -----
```

```
Number of APs: 0
```

# show tunnel eogre global-configuration

To display the Ethernet over GRE (EoGRE) global configuration, use the **show tunnel eogre global-configuration** command.

**show tunnel eogre global-configuration**

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Example

This example shows how to display the EoGRE global configuration:

```
Device# show tunnel eogre global-configuration

Heartbeat interval      : 60
Max Heartbeat skip count : 3
Source Interface        : (none)
```

# show tunnel eogre domain detailed

To display the detailed information of the Ethernet over GRE (EoGRE) tunnel domain, use the **show tunnel eogre domain detailed** command.

**show tunnel eogre domain detailed** *domain-name*

<b>Syntax Description</b>	<i>domain-name</i> EoGRE domain name.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.11.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.				

## Example

This example shows how to display the detailed information of the EoGRE tunnel domain:

```
Device# show tunnel eogre domain detailed eogre_domain

Domain Name      : eogre_domain
Primary GW       : Tunnel1
Secondary GW     : Tunnel2
Active GW        : Tunnel1
Redundancy       : Non-Revertive
```

# show tunnel eogre domain summary

To display the summary information of the Ethernet over GRE (EoGRE) tunnel domain, use the **show tunnel eogre domain summary** command.

## show tunnel eogre domain summary

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC (#)
----------------------	---------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Example

This example shows how to display the summary information of the EoGRE tunnel domain:

```
Device# show tunnel eogre domain summary
```

Domain Name	Primary GW	Secondary GW	Active GW	Redundancy
domain1	Tunnel1	Tunnel2	Tunnel1	Non-Revertive
eogre_domain	Tunnel1	Tunnel2	Tunnel1	Non-Revertive



# show tunnel eogre gateway summary

To display the summary information of the Ethernet over GRE (EoGRE) tunnel gateway, use the **show tunnel eogre gateway summary** command.

**show tunnel eogre gateway summary**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.11.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.				

## Example

This example shows how to display the summary information of the EoGRE tunnel gateway:

```
Device# show tunnel eogre gateway summary
```

Name	Type	Address	AdminState	State	Clients
Tunnel1	IPv4	9.51.1.11	Up	Up	0
Tunnel2	IPv4	9.51.1.12	Up	Down	0
Tunnel10	IPv6	fd09:9:8:21::90	Down	Down	0
Tunnel11	IPv4	9.51.1.11	Up	Up	0
Tunnel12	IPv6	fd09:9:8:21::90	Up	Down	0
Tunnel100	IPv4	9.51.1.100	Up	Down	0

# show tunnel eogre gateway detailed

To display the detailed information of the Ethernet over GRE (EoGRE) tunnel domain, use the **show tunnel eogre gateway detailed** command.

**show tunnel eogre gateway detailed** *gateway-name*

<b>Syntax Description</b>	<i>gateway-name</i> EoGRE gateway name.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.11.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.				

## Example

This example shows how to display the detailed information of the EoGRE tunnel gateway:

```
Device# show tunnel eogre domain detailed Tunnell
```

```
Gateway : Tunnell
Mode    : IPv4
IP      : 9.51.1.11
Source  : Vlan51 / 9.51.1.1
State   : Up
SLA ID  : 56
MTU     : 1480
Up Time: 4 minutes 45 seconds

Clients
  Total Number of Wireless Clients      : 0
Traffic
  Total Number of Received Packets      : 0
  Total Number of Received Bytes        : 0
  Total Number of Transmitted Packets    : 0
  Total Number of Transmitted Bytes     : 0
Keepalives
  Total Number of Lost Keepalives       : 0
  Total Number of Received Keepalives   : 5
  Total Number of Transmitted Keepalives: 5
Windows
  Transmitted Keepalives in last window : 2
  Received Keepalives in last window    : 2
```

# show tunnel eogre manager stats global

To display the global tunnel manager statistics, use the **show tunnel eogre manager stats global** command.

## show tunnel eogre manager stats global

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

### Example

This example shows how to display the global tunnel manager statistics:

```
Device# show tunnel eogre manager stats global

Tunnel Global Statistics
Last Updated                : 02/18/2019 23:50:35
EoGRE Objects
  Gateways                  : 6
  Domains                   : 2

EoGRE Flex Objects
  AP Gateways               : 2
  AP Domains                : 1
  AP Gateways HA inconsistencies : 0
  AP Domains HA inconsistencies : 0

Config events
  IOS Tunnel updates        : 806
  IOS Domain updates        : 88
  Global updates            : 48
  Tunnel Profile updates    : 120
  Tunnel Rule updates       : 16
  AAA proxy key updates     : 0

AP events
  Flex AP Join              : 1
  Flex AP Leave             : 0
  Local AP Join             : 0
  Local AP leave            : 0
  Tunnel status (rx)        : 4
  Domain status (rx)        : 1
  IAPP stats msg (rx)       : 3
  Client count (rx)         : 6
  VAP Payload msg (tx)      : 4
  Domain config (tx)        : 1
  Global config (tx)        : 1
  Client delete (tx)        : 1
```

## show tunnel eogre manager stats global

```

Client delete per domain (tx) : 3
DHCP option 82 (tx) : 4

Client events
Add-mobile : 2
Run-State : 3
Delete : 1
Cleanup : 0
Join : 2
Plumb : 0
Join Errors : 0
HandOff : 0
MsPayload : 2
FT Recover : 0
Zombie GW counter increase : 0
Zombie GW counter decrease : 0
Tunnel Profile reset : 88
Client deauth : 0
HA reconciliation : 0

Client Join Events
Generic Error : 0
MSPayload Fail : 0
Invalid VLAN : 0
Invalid Domain : 0
No GWs in Domain : 0
Domain Shut : 0
Invalid GWs : 0
GWs Down : 0
Rule Match Error : 0
AAA-override : 0
Flex No Active GW : 0
Open Auth join attempt : 2
Dotlx join attempt : 2
Mobility join attempt : 0
Tunnel Profile not valid : 2
Tunnel Profile valid : 2
No rule match : 0
Rule match : 2
AAA proxy : 0
AAA proxy accounting : 0
AAA eogre attributes : 0
Has aaa override : 0
Error in handoff payload : 0
Handoff AAA override : 0
Handoff no AAA override : 0
Handoff payload received : 0
Handoff payload sent : 0

SNMP Traps
Client : 0
Tunnel : 2
Domain : 0

IPC
IOSd TX messages : 0

Zombie Client
Entries : 0

```

# show tunnel eogre manager stats instance

To display the tunnel manager statistics for a specific WNCd instance, use the **show tunnel eogre manager stats instance** command.

**show tunnel eogre manager stats instance** *instance-number*

<b>Syntax Description</b>	<i>instance-number</i> WNCd instance number.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC (#)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.11.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.11.1	This command was introduced.				

## Example

This example shows how to display the tunnel manager statistics for a specific WNCd instance:

```
Device# show tunnel eogre manager stats instance 0

Tunnel Manager statistics for process instance : 0
Last Updated                               : 02/18/2019 23:50:35
EoGRE Objects
  Gateways                                  : 6
  Domains                                   : 2

EoGRE Flex Objects
  AP Gateways                               : 2
  AP Domains                                : 1
  AP Gateways HA inconsistencies            : 0
  AP Domains HA inconsistencies            : 0

Config events
  IOS Tunnel updates                        : 102
  IOS Domain updates                       : 11
  Global updates                            : 6
  Tunnel Profile updates                    : 15
  Tunnel Rule updates                      : 2
  AAA proxy key updates                    : 0

AP events
  Flex AP Join                              : 1
  Flex AP Leave                             : 0
  Local AP Join                             : 0
  Local AP leave                            : 0
  Tunnel status (rx)                       : 4
  Domain status (rx)                       : 1
  IAPP stats msg (rx)                      : 3
  Client count (rx)                        : 6
  VAP Payload msg (tx)                     : 4
```

## show tunnel eogre manager stats instance

```

Domain config (tx)           : 1
Global config (tx)          : 1
Client delete (tx)          : 1
Client delete per domain (tx) : 3
DHCP option 82 (tx)         : 4

Client events
Add-mobile                   : 2
Run-State                    : 3
Delete                       : 1
Cleanup                      : 0
Join                         : 2
Plumb                        : 0
Join Errors                  : 0
HandOff                      : 0
MsPayload                    : 2
FT Recover                   : 0
Zombie GW counter increase   : 0
Zombie GW counter decrease   : 0
Tunnel Profile reset         : 11
Client deauth                : 0
HA reconciliation            : 0

Client Join Events
Generic Error                : 0
MSPayload Fail               : 0
Invalid VLAN                 : 0
Invalid Domain               : 0
No GWs in Domain             : 0
Domain Shut                  : 0
Invalid GWs                  : 0
GWs Down                     : 0
Rule Match Error             : 0
AAA-override                 : 0
Flex No Active GW           : 0
Open Auth join attempt       : 2
Dot1x join attempt           : 2
Mobility join attempt        : 0
Tunnel Profile not valid     : 2
Tunnel Profile valid         : 2
No rule match                : 0
Rule match                   : 2
AAA proxy                    : 0
AAA proxy accounting         : 0
AAA eogre attributes         : 0
Has aaa override             : 0
Error in handoff payload     : 0
Handoff AAA override         : 0
Handoff no AAA override      : 0
Handoff payload received     : 0
Handoff payload sent         : 0

SNMP Traps
Client                       : 0
Tunnel                       : 2
Domain                       : 0

IPC
IOSd TX messages             : 0

Zombie Client
Entries                      : 0

```

# show umbrella config

To view the Umbrella configuration details, use the **show umbrella config** command.

## show umbrella config

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the Umbrella configuration details:

```
Device# show umbrella config
Umbrella Configuration
=====
Token: 57CC80106C087FB1B2A7BAB4F2F4373C00247166
OrganizationID: 1892929
Local Domain Regex parameter-map name: dns_wl
DNSCrypt: Enabled
Public-key: B735:1140:206F:225D:3E2B:D822:D7FD:691E:A1C3:3CC8:D666:8D0C:BE04:BFAB:CA43:FB79

UDP Timeout: 2 seconds
Resolver address:
 1. 208.67.220.220
 2. 208.67.222.222
 3. 2620:119:53::53
 4. 2620:119:35::35
```

# show umbrella deviceid

To view the device registration details, use the **show umbrella deviceid** command.

**show umbrella deviceid**

<b>Syntax Description</b>	This command has no arguments.
---------------------------	--------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the device registration details:

```
Device# show umbrella deviceid
Device registration details
Profile Name           Tag           Status           Device-id
GigabitEthernet0/0/0  guest        200 SUCCESS      010a470b042a072d
```



# show umbrella deviceid detailed

To view the detailed description for the Umbrella device ID, use the **show umbrella deviceid detailed** command.

**show umbrella deviceid** *detailed*

<b>Syntax Description</b>	This command has no arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Global configuration				
<b>Command History</b>	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE Gibraltar 16.10.1</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.				

This example shows how to view the detailed description for the Umbrella device ID:

```
Device# show umbrella deviceid detailed
Device registration details
 1.GigabitEthernet0/0/0
   Tag           : guest
   Device-id     : 010a470b042a072d
   Description   : Device Id recieved successfully
```

# show umbrella dnscrypt

To view the Umbrella DNSCrypt details, use the **show umbrella dnscrypt** command.

## show umbrella dnscrypt

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the Umbrella DNSCrypt details:

```
Device# show umbrella dnscrypt
DNSCrypt: Enabled
Public-key: B735:1140:206F:225D:3E2B:D822:D7FD:691E:A1C3:3CC8:D666:8DOC:BE04:BFAB:CA43:FB79

Certificate Update Status:
  Last Successfull Attempt: 17:45:57 IST Nov 9 2017
Certificate Details:
Certificate Magic      : DNSC
Major Version         : 0x0001
Minor Version         : 0x0000
Query Magic           : 0x713156774457306E
Serial Number         : 1490391488
Start Time            : 1490391488 (03:08:08 IST Mar 25 2017)
End Time              : 1521927488 (03:08:08 IST Mar 25 2018)
Server Public Key     :
E7F8:4477:BF89:1434:1ECE:23F0:D6A6:6EB9:4F45:3167:D71F:80BB:4E80:A04F:F180:F778
Client Secret Key Hash:
F1A5:1993:F729:5416:53B7:94E3:6509:8182:A708:0561:8050:6CE0:DFA1:5C94:6EE4:0010
Client Public key     :
BC6D:3758:48B6:120B:D2F5:F25B:2979:564D:F52C:5EFA:B0BD:76FE:3CD6:828B:44D2:FF3A
NM key Hash           :
1FF7:2E1E:EFB9:7987:9CB4:3EF8:A25B:4DAD:10FC:7DF7:6985:6E8E:6E4D:D56A:1C70:B9EB
```

# show vlan

To display the parameters for all configured VLANs or one VLAN (if the VLAN ID or name is specified) on the switch, use the **show vlan** command in user EXEC mode.

```
show vlan [{brief | group | id vlan-id | mtu | name vlan-name | remote-span | summary}]
```

Syntax Description		
<b>brief</b>		(Optional) Displays one line for each VLAN with the VLAN name, status, and its ports.
<b>group</b>		(Optional) Displays information about VLAN groups.
<b>id</b> <i>vlan-id</i>		(Optional) Displays information about a single VLAN identified by the VLAN ID number. For <i>vlan-id</i> , the range is 1 to 4094.
<b>mtu</b>		(Optional) Displays a list of VLANs and the minimum and maximum transmission unit (MTU) sizes configured on ports in the VLAN.
<b>name</b> <i>vlan-name</i>		(Optional) Displays information about a single VLAN identified by the VLAN name. The VLAN name is an ASCII string from 1 to 32 characters.
<b>remote-span</b>		(Optional) Displays information about Remote SPAN (RSPAN) VLANs.
<b>summary</b>		(Optional) Displays VLAN summary information.



**Note** The **ifindex** keyword is not supported, even though it is visible in the command-line help string.

**Command Default** None

**Command Modes** User EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

**Usage Guidelines** In the **show vlan mtu** command output, the MTU\_Mismatch column shows whether all the ports in the VLAN have the same MTU. When yes appears in the column, it means that the VLAN has ports with different MTUs, and packets that are switched from a port with a larger MTU to a port with a smaller MTU might be dropped. If the VLAN does not have an SVI, the hyphen (-) symbol appears in the SVI\_MTU column. If the MTU-Mismatch column displays yes, the names of the ports with the MinMTU and the MaxMTU appear.

This is an example of output from the **show vlan** command. See the table that follows for descriptions of the fields in the display.

```

Device> show vlan
VLAN Name                Status      Ports
-----
1    default                active     Gi1/0/2, Gi1/0/3, Gi1/0/4
                                           Gi1/0/5, Gi1/0/6, Gi1/0/7
                                           Gi1/0/8, Gi1/0/9, Gi1/0/10
                                           Gi1/0/11, Gi1/0/12, Gi1/0/13
                                           Gi1/0/14, Gi1/0/15, Gi1/0/16
                                           Gi1/0/17, Gi1/0/18, Gi1/0/19
                                           Gi1/0/20, Gi1/0/21, Gi1/0/22
                                           Gi1/0/23, Gi1/0/24, Gi1/0/25
                                           Gi1/0/26, Gi1/0/27, Gi1/0/28
                                           Gi1/0/29, Gi1/0/30, Gi1/0/31
                                           Gi1/0/32, Gi1/0/33, Gi1/0/34
                                           Gi1/0/35, Gi1/0/36, Gi1/0/37
                                           Gi1/0/38, Gi1/0/39, Gi1/0/40
                                           Gi1/0/41, Gi1/0/42, Gi1/0/43
                                           Gi1/0/44, Gi1/0/45, Gi1/0/46
                                           Gi1/0/47, Gi1/0/48

2    VLAN0002              active
40   vlan-40                active
300  VLAN0300              active
1002 fddi-default          act/unsup
1003 token-ring-default  act/unsup
1004 fddinet-default     act/unsup
1005 trnet-default       act/unsup

VLAN Type  SAID      MTU   Parent RingNo BridgeNo Stp  BrdgMode Trans1 Trans2
-----
1    enet     100001    1500 -     -     -     -   -         0      0
2    enet     100002    1500 -     -     -     -   -         0      0
40   enet     100040    1500 -     -     -     -   -         0      0
300  enet     100300    1500 -     -     -     -   -         0      0
1002 fddi     101002    1500 -     -     -     -   -         0      0
1003 tr      101003    1500 -     -     -     -   -         0      0
1004 fdnet  101004    1500 -     -     -     -   ieee      0      0
1005 trnet  101005    1500 -     -     -     -   ibm       0      0
2000 enet     102000    1500 -     -     -     -   -         0      0
3000 enet     103000    1500 -     -     -     -   -         0      0

Remote SPAN VLANs
-----
2000,3000

Primary Secondary Type          Ports
-----

```

Table 9: show vlan Command Output Fields

Field	Description
VLAN	VLAN number.
Name	Name, if configured, of the VLAN.
Status	Status of the VLAN (active or suspend).
Ports	Ports that belong to the VLAN.
Type	Media type of the VLAN.

Field	Description
SAID	Security association ID value for the VLAN.
MTU	Maximum transmission unit size for the VLAN.
Parent	Parent VLAN, if one exists.
RingNo	Ring number for the VLAN, if applicable.
BrdgNo	Bridge number for the VLAN, if applicable.
Stp	Spanning Tree Protocol type used on the VLAN.
BrdgMode	Bridging mode for this VLAN—possible values are source-route bridging (SRB) and source-route transparent (SRT); the default is SRB.
Trans1	Translation bridge 1.
Trans2	Translation bridge 2.
Remote SPAN VLANs	Identifies any RSPAN VLANs that have been configured.

This is an example of output from the **show vlan summary** command:

```
Device> show vlan summary
Number of existing VLANs           : 45
Number of existing VTP VLANs      : 45
Number of existing extended VLANs : 0
```

This is an example of output from the **show vlan id** command:

```
Device# show vlan id 2
VLAN Name                Status      Ports
-----
2    VLAN0200                active     Gi1/0/7, Gi1/0/8
2    VLAN0200                active     Gi2/0/1, Gi2/0/2

VLAN Type  SAID      MTU   Parent RingNo BridgeNo  Stp  BrdgMode Trans1 Trans2
-----
2    enet  100002   1500  -     -       -    -    -        0     0

Remote SPAN VLANs
-----
Disabled
```

## show vlan access-map

To display information about a particular VLAN access map or for all VLAN access maps, use the **show vlan access-map** command in privileged EXEC mode.

**show vlan access-map** [*map-name*]

<b>Syntax Description</b>	<i>map-name</i> (Optional) Name of a specific VLAN access map.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This is an example of output from the **show vlan access-map** command:

```
Device# show vlan access-map
Vlan access-map "vmap4" 10
  Match clauses:
    ip address: a12
  Action:
    forward
Vlan access-map "vmap4" 20
  Match clauses:
    ip address: a12
  Action:
    forward
```

# show vlan filter

To display information about all VLAN filters or about a particular VLAN or VLAN access map, use the **show vlan filter** command in privileged EXEC mode.

```
show vlan filter {access-map name | vlan vlan-id}
```

<b>Syntax Description</b>	<b>access-map</b> <i>name</i> (Optional) Displays filtering information for the specified VLAN access map.	
	<b>vlan</b> <i>vlan-id</i> (Optional) Displays filtering information for the specified VLAN. The range is 1 to 4094.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This is an example of output from the **show vlan filter** command:

```
Device# show vlan filter
VLAN Map map_1 is filtering VLANs:
 20-22
```

# show vlan group

To display the VLANs that are mapped to VLAN groups, use the **show vlan group** command in privileged EXEC mode.

```
show vlan group [{group-name vlan-group-name [user_count]}]
```

## Syntax Description

**group-name** *vlan-group-name* (Optional) Displays the VLANs mapped to the specified VLAN group.

**user\_count** (Optional) Displays the number of users in each VLAN mapped to a specified VLAN group.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

### Release

Cisco IOS XE Gibraltar 16.10.1

### Modification

This command was introduced.

## Usage Guidelines

The **show vlan group** command displays the existing VLAN groups and lists the VLANs and VLAN ranges that are members of each VLAN group. If you enter the **group-name** keyword, only the members of the specified VLAN group are displayed.

This example shows how to display the members of a specified VLAN group:



# show wireless band-select

To display the status of the band-select configuration, use the **show wireless band-select** command in privileged EXEC mode.

**show wireless band-select**

---

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

---

---

<b>Command Default</b>	No default behavior or values.
------------------------	--------------------------------

---

---

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

---

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

---

The following is sample output from the **show wireless band-select** command:

```
Device# show wireless band-select
Band Select Probe Response      : per WLAN enabling
Cycle Count                     : 2
Cycle Threshold (millisec)     : 200
Age Out Suppression (sec)      : 20
Age Out Dual Band (sec)        : 60
Client RSSI (dBm)              : 80
```

# show wireless client

To see the summary of the classified devices, use the **show wireless client** command.

```
show wireless client device {cache | count | summary } | {steering} [{chassis{chassis-number | active | standby }}]R0
```

Syntax Description	Parameter	Description
	<b>device</b>	Shows classified devices.
	<b>steering</b>	Wireless client steering information
	<b>cache</b>	Shows the cached classified device summary.
	<b>count</b>	Shows the wireless device count.
	<b>summary</b>	Shows the active classified device summary.
	<i>chassis-number</i>	Chassis number. Valid range is 1–2.
	<b>active</b>	Active instance.
	<b>standby</b>	Standby instance.
	<b>R0</b>	Route-Processor slot 0.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the summary of the classified devices:

```
Device# show wireless client device summary
```

# show wireless client mac-address

To view detailed information of a client using its mac-address, use the **show wireless client mac-address detail** command.

**show wireless client mac-address** *mac-address* **detail** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description	
<i>mac-address</i>	Client MAC address.
<i>chassis-number</i>	Chassis number. Valid range is 1–2.
<b>active</b>	Active instance.
<b>standby</b>	Standby instance.
<b>R0</b>	Route-Processor slot 0.

**Command Default** None

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

**Usage Guidelines** The Client Scan Reports section in the output of the **show wireless client mac-address detail** is populated only for the following Apple devices:

- Any iPhone 7 and running iOS 11.0 or higher
- Any iPad after iPad Pro (1st gen, 12.9-inch, 2015) and running iOS 11.0 or higher

Other client devices, even if it supports 802.11k or is Wi-Fi Agile Multiband (MBO) certified, are not currently supported to populate the Client Scan Reports section.

Client ACLs shown under **show wireless client mac-address** *<mac address>* **detail** are ACLs applied on the client in Flexconnect local authentication case with MAB+Web authentication WLAN with AAA override enabled. This is applicable only for Express Wi-Fi by Facebook Policy on Controller. For more information about Facebook policy, see [Express Wi-Fi by Facebook](#).

From Cisco IOS XE Amsterdam 17.3.1 onwards, the controller retains client session for 10 seconds. This feature is applicable for clients in the RUN state and is supported on central authentication with local and flex mode.

In idle state, 10 sec represents idle state timeout and 09 sec represent remaining time out of 10 sec. An example is given below:

```
Idle state timeout : 10 sec (Remaining time: 09 sec)
```

### Examples

The following example shows how to see detailed client information using its MAC address:

```
Device# show wireless client mac-address 98-XX-7B-XX-EF-XX detail
```

## show wireless client mac-address (Call Control)

To view call control information related to clients, use the **show wireless client mac-address** command in privileged EXEC mode.

**show wireless client mac-address** *mac-address* **call-control call-info**

<b>Syntax Description</b>	<i>mac-address</i>	The client MAC address.
	<b>call-control call-info</b>	Displays the call control and IP-related information about a client.
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1 This command was introduced.	

This example shows how to display call control and IP-related information about a client:

```
Device# show wireless client mac-address 30e4.db41.6157 call-control call-info
Client MAC Address      : 30E4DB416157

Call 1 Statistics

Uplink IP Address      : 209.165.200.225
Downlink IP Address    : 209.165.200.226
Uplink Port            : 29052
Downlink Port          : 27538
Call ID                : c40acb4d-3b3b0.3d27dale-356bed03
Called Party           : sip:1011
Calling Party          : sip:1012
Priority                : 6
Call On Hold           : false
Call Duration          : 30

Call 2 Statistics

No Active Call
```

## show wireless client mac-address (TCLAS)

To view information about TCLAS and user priority, use the **show wireless client mac-address** command in privileged EXEC mode.

**show wireless client mac-address** *mac-address* **tclas**

Syntax Description	
<i>mac-address</i>	The client MAC address.
<b>tclas</b>	Displays TCLAS and user priority-related information about a client.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display the TCLAS and user priority-related information about a client:

```
Device# show wireless client mac-address 30e4.db41.6157 tclas
MAC Address      UP TID Mask Source IP Addr  Dest IP Addr  SrcPort DstPort Proto
-----
30e4.db41.6157   4  4  95 167838052      2164326668    5060     5060     6
30e4.db41.6157   6  1  31 0              2164326668     0       27538    17
```

# show wireless client mac-address mobility history

To see roam history of an active client in subdomain, use the **show wireless client mac-address *mac-address* mobility history** command.

**show wireless client mac-address *mac-address* mobility history** [{chassis {*chassis-number* | active | standby} R0] | events [chassis {*chassis-number* | active | standby} R0]]

<b>Syntax Description</b>	<i>mac-address</i>	MAC address of the client.
	<i>chassis-number</i>	Chassis number as either 1 or 2.
	<b>active R0</b>	Active instance of the client in Route-processor slot 0.
	<b>standby R0</b>	Standby instance of the client in Route-processor slot 0.
	<b>events</b>	Shows client FSM event history.
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

This example shows how to see roam history of an active client in subdomain:

```
Device# show wireless client mac-address 00:0d:ed:dd:35:80 mobility history
```

# show wireless client summary

To display a summary of active clients associated with the controller, use the **show wireless client summary** command in privileged EXEC mode.

**show wireless client summary**

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behavior or values.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

**Usage Guidelines** The following is sample output from the **show wireless client summary** command:

Use the **show wireless exclusionlist** command to display clients on the exclusion list.

```
Device# show wireless client summary
Number of Local Clients : 1
```

MAC Address	AP Name	WLAN State	Protocol
0000.1515.000f	AP-2	1 UP	11a



# show wireless client timers

To display 802.11 system timers, use the **show wireless client timers** command in privileged EXEC mode.

**show wireless client timers**

---

**Syntax Description** This command has no arguments or keywords.

---

**Command Default** No default behavior or values.

---

**Command Modes** Privileged EXEC

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

---

The following is sample output from the **show wireless client timers** command:

```
Device# show wireless client timers
Authentication Response Timeout (seconds)      : 10
```



The following is sample output from the **show wireless country configured** command:

```
Device# show wireless country configured
Configured Country.....: US - United States
Configured Country Codes
    US - United States : 802.11a Indoor,Outdoor/ 802.11b / 802.11g
```

The following is sample output from the **show wireless country supported tx-power** command:

```
Device# show wireless country supported tx-power
KEY: ##      = Tx Power in dBm.
     ##*     = Channel supports radar detection .
     .       = Channel is not legal in this country.
     (-)     = Regulatory Domains allowed by this country.
     (-,-)   = (indoor, outdoor) regulatory Domains allowed by this country.
-----:+++++-----:
      802.11bg      :
      Channels      :                1 1 1 1 1
                   : 1 2 3 4 5 6 7 8 9 0 1 2 3 4
-----:+++++-----:
(-CE , -CE ) AE  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) AL  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -AR ) AR  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -E  ) AT  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -NA ) AU  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -   ) BA  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) BE  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) BG  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -   ) BH  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -A  ) BO  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-A  , -AR ) BR  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -   ) BY  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -ABN ) CA  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-A  , -ABN ) CA2 : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -E  ) CH  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-AER , -AR ) CL  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) CM  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-CE  , -CE ) CN  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -AR ) CO  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-A  , -AB  ) CR  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -E  ) CY  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) CZ  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) DE  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) DK  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -ABN ) DO  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -   ) DZ  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -AB  ) EC  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -E  ) EE  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) EG  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) ES  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) FI  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) FR  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) GB  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) GI  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) GR  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A  , -NA ) HK  : 27 27 27 27 27 27 27 27 27 27 27 27 27 27 .
(-E  , -   ) HR  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) HU  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -ER ) ID  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E  , -E  ) IE  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
(-EI  , -IE ) IL  : 20 20 20 20 20 20 20 20 20 20 20 20 20 20 .
```

## show wireless country

```

(-I , -I ) ILO : . . . . 20 20 20 20 20 20 20 20 20 20 .
(-A , -AN ) IN : 27 27 27 27 27 27 27 27 27 27 . . .
(-E , -E ) IQ : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) IS : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) IT : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-JPU , -JPU ) J2 : 23 23 23 23 23 23 23 23 23 23 23 23 23
(-JPU , -JPU ) J3 : 23 23 23 23 23 23 23 23 23 23 23 23 23
(-JPQU , -PQ ) J4 : 23 23 23 23 23 23 23 23 23 23 23 23 23
(-E , - ) JO : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-JPU , -JPU ) JP : 23 23 23 23 23 23 23 23 23 23 23 23 23
(-ACE , -ACEK) KE : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) KN : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-ACE , -ACEK) KR : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) KW : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) KZ : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) LB : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) LI : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , ) LK : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) LT : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) LU : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) LV : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) MC : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) ME : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) MK : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , ) MO : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) MT : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A , -NA ) MX : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-ACE , -AEC) MY : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) NL : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) NO : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A , -NA ) NZ : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-E , -E ) OM : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A , -AR ) PA : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , -AR ) PE : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , -ABN ) PH : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , -ABN ) PH2 : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-E , -E ) PK : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) PL : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A , -A ) PR : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-E , -E ) PT : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A , -A ) PY : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-E , -E ) QA : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) RO : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) RS : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-AER , -ER ) RU : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-AE , -AE ) SA : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) SE : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -SE ) SG : 20 20 20 20 20 20 20 20 20 20 20 20 20
(-E , -E ) SI : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) SK : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -ER ) TH : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) TN : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-EI , -E ) TR : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A , -ANT ) TW : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-E , -E ) UA : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-A , -AB ) US : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , -AB ) US2 : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , -AB ) USL : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , - ) USX : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , -A ) UY : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-A , -AR ) VE : 27 27 27 27 27 27 27 27 27 27 27 . . .
(-E , -E ) VN : 20 20 20 20 20 20 20 20 20 20 20 20 .
(-E , -E ) ZA : 20 20 20 20 20 20 20 20 20 20 20 20 .

```

# show wireless detail

To display the details of the wireless parameters configured, use the **show wireless detail** command in privileged EXEC mode.

**show wireless detail**

---

**Syntax Description** This command has no arguments or keywords.

---

**Command Default** No default behavior or values.

---

**Command Modes** Privileged EXEC

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

---

---

**Usage Guidelines** The following parameters are displayed:

- The wireless user idle timeout
- The controller configured RF group name
- Fast SSID change

The following is sample output from the **show wireless detail** command:

```
Device# show wireless detail
User Timeout           : 300
RF network              : default
Fast SSID              : Disabled
```

# show wireless dot11h

To see 802.11h configuration details, use the **show wireless dot11h** command.

**show wireless dot11h** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

Syntax Description	
<i>chassis-number</i>	Chassis number. Valid range is 1–2.
<b>active</b>	Active instance.
<b>standby</b>	Standby instance.
<b>R0</b>	Route-Processor slot 0.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the 802.11h configuration details:

```
Device# show wireless dot11h
```

# show wireless dtls connections

To display the Datagram Transport Layer Security (DTLS) server status, use the **show wireless dtls connections** command in privileged EXEC mode.

## show wireless dtls connections

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behavior or values.

**Command Modes** Privileged EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless dtls connections** command:

```
Device# show wireless dtls connections
AP Name      Local Port  Peer IP     Peer Port  Ciphersuite
-----
AP-2         Capwap_Ctrl 10.0.0.16   52346     TLS_RSA_WITH_AES_128_CBC_SHA
AP-3         Capwap_Ctrl 10.0.0.17   52347     TLS_RSA_WITH_AES_128_CBC_SHA
```

# show wireless exclusionlist

To see the wireless exclusion list, use the **show wireless exclusionlist** command.

**show wireless exclusionlist** [{**client mac-address** *client-mac-addr* **detail** }] [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

## Syntax Description

*client-mac-addr* SI interferers of type microwave oven for the 2.4-GHz band.

*chassis-number* Enter the chassis number as either 1 or 2.

**active R0** Active instance of the configuration in Route-processor slot 0.

**standby R0** Standby instance of the configuration in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the wireless exclusion list:

```
Device# show wireless exclusionlist
```



# show wireless fabric summary

To view the fabric status, use the **show wireless fabric summary** command.

## show wireless fabric summary

<b>Syntax Description</b>	This command has no arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Global configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.10.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.				

This example shows how to view fabric status:

```
Device# show wireless fabric summary
Fabric Status      : Enabled
```

```
Control-plane:
Name                IP-address        Key                Status
-----
test-map            10.12.13.14      test1              Down
```

```
Fabric VNID Mapping:
Name                L2-VNID          L3-VNID          IP Address        Subnet
Control plane name
-----
test1                12                10                10.6.8.9          255.255.255.236
test2
```

# show wireless fabric client summary

To see the summary of a fabric enabled wireless client, use the **show wireless fabric client summary** command.

**show wireless fabric client summary**

---

## Command Default

None

---

## Command Modes

Privileged EXEC

---

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the fabric enabled wireless client summary:

```
Device# show wireless fabric client summary
```

# show wireless fabric vnid mapping

To view all the VNID mapping details, use the **show wireless fabric vnid mapping** command.

**show wireless fabric vnid mapping**

## Syntax Description

This command has no arguments.

## Command Default

None

## Command Modes

Global configuration

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view all the VNID mapping details:

```
Device# show wireless fabric vnid mapping
Fabric VNID Mapping:
  Name          L2-VNID      L3-VNID      IP Address    Subnet
Control plane name
-----
  test1         12           10           10.6.8.9     255.255.255.236
  test2
```

# show wireless flow-control

To display the information about flow control on a particular channel, use the **show wireless flow-control** command in privileged EXEC mode.

**show wireless flow-control** *channel-id*

<b>Syntax Description</b>	<i>channel-id</i> Identification number for a channel through which flow control is monitored.
---------------------------	--

<b>Command Default</b>	No default behavior or values.
------------------------	--------------------------------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless flow-control** *channel-id* command:

```
Device# show wireless flow-control 3
Channel Name           : CAPWAP
FC State               : Disabled
Remote Server State   : Enabled
Pass-thru Mode        : Disabled
EnQ Disabled          : Disabled
Queue Depth           : 2048
Max Retries           : 5
Min Retry Gap (mSec)  : 3
```

# show wireless flow-control statistics

To display the complete information about flow control on a particular channel, use the **show wireless flow-control statistics** command in privileged EXEC mode.

**show wireless flow-control** *channel-id* **statistics**

<b>Syntax Description</b>	<i>channel-id</i> Identification number for a channel through which flow control is monitored.				
<b>Command Default</b>	No default behavior or values.				
<b>Command Modes</b>	Privileged EXEC				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE Gibraltar 16.10.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.				

The following is sample output from the **show wireless flow-control** *channel-id* **statistics** command:

```
Device# show wireless flow-control 3 statistics
Channel Name                : CAPWAP
# of times channel went into FC      : 0
# of times channel came out of FC    : 0
Total msg count received by the FC Infra : 1
Pass-thru msgs send count          : 0
Pass-thru msgs fail count          : 0
# of msgs successfully queued       : 0
# of msgs for which queuing failed  : 0
# of msgs sent thru after queuing   : 0
# of msgs sent w/o queuing          : 1
# of msgs for which send failed     : 0
# of invalid EAGAINS received       : 0
Highest watermark reached           : 0
# of times Q hit max capacity       : 0
Avg time channel stays in FC (mSec) : 0
```

# show wireless load-balancing

To display the status of the load-balancing feature, use the **show wireless load-balancing** command in privileged EXEC mode.

## show wireless load-balancing

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	No default behavior or values.
------------------------	--------------------------------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless load-balancing** command:

```
> show wireless load-balancing
Aggressive Load Balancing.....: per WLAN enabling
Aggressive Load Balancing Window (clients).....: 5
Aggressive Load Balancing Denial Count.....: 3

Statistics
Total Denied Count (clients).....: 0
Total Denial Sent (messages).....: 0
Exceeded Denial Max Limit Count (times).....: 0
None 5G Candidate Count (times).....: 0
None 2.4G Candidate Count (times).....: 0
```

# show wireless media-stream client detail

To see the media stream clients information by stream name, use the **show wireless media-stream client detail** command.

**show wireless media-stream client detail**

---

**Command Default**

None

---

**Command Modes**

Privileged EXEC

---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

---

## Examples

The following example shows how to see media stream clients information by stream name:

```
Device# show wireless media-stream client detail
```

# show wireless media-stream group

To display the wireless media-stream group information, use the **show wireless media-stream group** command.

**show wireless media-stream group** {*detail groupName* | *summary*}

Syntax Description	
<b>detail</b> <i>groupName</i>	Display media-stream group configuration details of the group mentioned in the command.
<b>summary</b>	Display media-stream group configuration summary

**Command Default** None

**Command Modes** User EXEC mode or Privileged EXEC mode

**Usage Guidelines** None.

The following is a sample output of the **show wireless media-stream group detail GRP1** command.

```
Device#show wireless media-stream group detail GRP1
Device#show wireless media-stream group detail GRP1
Media Stream Name : GRP1
Start IP Address : 234.1.1.1
End IP Address : 234.1.1.5
RRC Parameters:
Avg Packet Size(Bytes) : 1200
Expected Bandwidth(Kbps) : 1000
Policy : Admitted
RRC re-evaluation : Initial
QoS : video
Status : Multicast-direct
```

The following is a sample output of the **show wireless media-stream group summary** command.

```
Device#show wireless media-stream group summary
Number of Groups:: 1
Stream Name          Start IP              End IP
Status
-----
GRP1                  234.1.1.1             234.1.1.5
Enabled
```



# show wireless media-stream message details

To see the wireless multicast-direct session announcement message details, use the **show wireless media-stream message details** command.

**show wireless media-stream message details**

---

**Command Default**

None

---

**Command Modes**

Privileged EXEC

---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

---

## Examples

The following example shows how to see the wireless multicast-direct session announcement message details:

```
Device# show wireless media-stream message details
```

# show wireless mobility controller ap

To display the list of access points which have joined the sub-domain, use the **wireless mobility controller ap** command.

## show wireless mobility controller ap

<b>Syntax Description</b>	<b>ap</b>	Show joined Access Point in sub-domain.
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Denali 16.3.1	This command was introduced.
<b>Usage Guidelines</b>	None	

This example shows how to list the access points which have joined the sub-domain.

```
Device#show wireless mobility controller ap
Number of AP entries in the sub-domain      : 2
```

AP name	AP radio MAC	Controller IP	Location
bos2kk	00f2.8c42.f520	default-group	default-group
IosAP1	34ed.522f.7e60	default-group	default-group

# show wireless media-stream multicast-direct state

To see the state of the wireless multicast-direct configuration, use the **show wireless media-stream multicast-direct state** command.

```
show wireless media-stream multicast-direct state
```

---

**Command Default**

None

---

**Command Modes**

Privileged EXEC

---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

---

## Examples

The following example shows how to see the state of the wireless multicast-direct configuration:

```
Device# show wireless media-stream multicast-direct state
```

# show wireless mesh ap

To see the mesh AP related information, use the **show wireless mesh ap** command.

**show wireless mesh ap** { **summary** | **tree** | **backhaul** } [**chassis** {*chassis-number* | **active** | **standby**}**R0**]

Syntax Description		
<b>summary</b>	Shows the summary of all connected mesh APs.	
<b>tree</b>	Shows the Mesh AP tree.	
<b>backhaul</b>	Shows the mesh APs backhaul info.	
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.	
<b>active R0</b>	Active instance of the configuration in Route-processor slot 0.	
<b>standby R0</b>	Standby instance of the configuration in Route-processor slot 0.	

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the summary of all the connected mesh APs:

```
Device# show wireless mesh ap summary
```

## show wireless mesh ap summary

To see the summary of all connected mesh APs, use the **show wireless mesh ap summary** command.

```
show wireless mesh ap summary [chassis {chassis-number | active | standby} R0]
```

### Syntax Description

<b>summary</b>	Shows the summary of all connected mesh APs.
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the active AP filters in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the active AP filters in Route-processor slot 0.

### Command Default

None

### Command Modes

Privileged EXEC

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

### Examples

The following example shows how to see the summary of all connected mesh APs:

```
Device# wireless mesh ap summary
```

# show wireless mesh ap tree

To see the mesh AP tree, use the **show wireless mesh ap tree** command.

## show wireless mesh ap tree

<b>Syntax Description</b>	<b>tree</b> Shows the mesh AP tree.
---------------------------	-------------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the mesh AP tree:

```
Device# wireless mesh ap tree
```

# show wireless mesh ap tree

To see the mesh AP tree, use the **show wireless mesh ap tree** command.

**show wireless mesh ap tree**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Example

The following example shows how to view the wireless mesh AP tree:

```
Device # show wireless mesh ap tree
```

# show wireless mesh cac summary

To view the total number of voice calls and bandwidth utilization of APs in the Mesh network, use the **show wireless mesh cac summary** command.

## show wireless mesh cac summary

---

**Syntax Description** This command has no keywords or arguments.

---

**Command Default** None

**Command Modes** Privileged EXEC (#)

---

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

---

## Usage Guidelines

### Example

This example shows how to display the total number of voice calls and bandwidth utilization of APs in the Mesh network:

```
Device# show wireless mesh cac summary
```

AP Name	Slot	Radio	BW Used	Call
APA023.9FA9.B702	0	802.11b/g	0	0
	1	802.11a	0	0
APA023.9FA9.D920	0	802.11b/g	1140	2
	1	802.11a	0	0
AP380E.4DBF.C6A6	0	802.11b/g	0	0
	1	802.11a	0	0
AP380E.4DBF.C80C	0	802.11b/g	570	0
	1	802.11a	2144	2
AP380E.4DBF.C816	0	802.11b/g	0	0
	1	802.11a	0	0



## show wireless mesh config

To see the mesh configurations, use the **show wireless mesh config** command.

```
show wireless mesh config [chassis {chassis-number | active | standby} R0]
```

### Syntax Description

<b>config</b>	Shows the mesh configurations.
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the active AP filters in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the active AP filters in Route-processor slot 0.

### Command Default

None

### Command Modes

Privileged EXEC

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

### Examples

The following example shows how to see the mesh configurations:

```
Device# wireless mesh config
```

# show wireless mesh neighbor

To see the neighbors of all connected mesh APs, use the **show wireless mesh neighbor** command.

**show wireless mesh neighbor** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

## Syntax Description

<b>neighbor</b>	Shows the neighbors of all connected mesh APs.
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the active AP filters in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the active AP filters in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the neighbors of all connected mesh APs:

```
Device# wireless mesh neighbor
```

# show wireless mobility

To view the wireless mobility summary, use the **show wireless mobility** command.

**show wireless mobility** { **agent** *mobility-agent-ip* **client summary** | **ap-list ip-address** *ip-address* | **controller client summary** | **dtls connections** | **statistics summary** }

Syntax Description	
<b>agent</b> <i>mobility-agent-ip</i> <b>client summary</b>	Shows the active clients on a mobility agent.
<b>ap-list ip-address</b> <i>ip-address</i>	Shows the list of Cisco APs known to the mobility group.
<b>controller client summary</b>	Shows the active clients in the subdomain.
<b>dtls connections</b>	Shows the DTLS server status.
<b>statistics</b>	Shows the statistics for the Mobility manager.
<b>summary</b>	Shows the summary of the mobility manager.

**Command Default** None

**Command Modes** Global Configuration

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to display a summary of the mobility manager:

```
Device (config)# show wireless mobility ap-list
```

AP name	AP radio MAC	Controller IP	Learnt from
TSIM_AP-101	0000.2000.6600	9.9.9.2	Self
TSIM_AP-102	0000.2000.6700	9.9.9.2	Self
TSIM_AP-103	0000.2000.6800	9.9.9.2	Self
TSIM_AP-400	0000.2001.9100	9.9.9.2	Self
TSIM_AP-402	0000.2001.9300	9.9.9.2	Self
TSIM_AP-403	0000.2001.9400	9.9.9.2	Self
TSIM_AP-406	0000.2001.9700	9.9.9.2	Self
TSIM_AP-407	0000.2001.9800	9.9.9.2	Self
TSIM_AP-409	0000.2001.9a00	9.9.9.2	Self

# show wireless mobility peer ip

To see the details of the mobility peer using its IP address, use the **show wireless mobility peer ip** command.

**show wireless mobility peer ip** *ip-address*

<b>Syntax Description</b>	<i>ip-address</i> Mobility peer IPv4 IP address.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the details of the wireless mobility peer using its IP address:

```
Device# show wireless mobility peer ip 209.165.200.224
```

# show wireless multicast group summary

To see the wireless multicast group summary, use the **show wireless multicast group summary** command.

**show wireless multicast group summary**

---

**Command Default**

None

---

**Command Modes**

Privileged EXEC

---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

---

## Examples

The following example shows how to see the summary of the wireless multicast group:

```
Device# show wireless multicast group summary
```

# show wireless mobility summary

To see the wireless mobility manager summary, use the **show wireless mobility summary** command.

**show wireless mobility summary**

---

**Command Default**

None

---

**Command Modes**

Privileged EXEC

---

**Command History**

<b>Release</b>	<b>Modification</b>
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

---

## Examples

The following example shows how to see the wireless mobility manager's summary:

```
Device# show wireless mobility summary
```

# show wireless multicast

To display wireless multicast information, use the **show wireless multicast** command in privileged EXEC mode.

**show wireless multicast** [**source** *source-ip* **group** *group-ip* **vlan** *vlan-id* | **group** *group-ip* **vlan** *vlan-id*]

Syntax Description	
<b>source</b> <i>source-ip</i>	(Optional) Specifies the source IPv4 and IPv6 address of multicast traffic.
<b>group</b> <i>group-ip</i>	(Optional) Specifies the destination group and group IP of multicast traffic.
<b>vlan</b> <i>vlan-id</i>	Displays the client information on VLAN with the specific VLAN ID.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

**Usage Guidelines** None

This example shows how to display the wireless multicast information:

```
Device# show wireless multicast

Multicast                               : Enabled
AP Capwap Multicast                     : Unicast
Wireless Broadcast                       : Disabled
Wireless Multicast non-ip-mcast         : Disabled

Vlan      Non-ip-mcast      Broadcast      MGID
-----
1          Enabled        Enabled        Enabled
2          Enabled        Enabled        Disabled
94         Enabled        Enabled        Disabled
```

# show wireless multicast group

To display the information of the wireless-multicast non-ip VLANs or the group, use the **show wireless multicast group** command in privileged EXEC mode.

```
show wireless multicast group {summary | group-ip vlan vlan-id}
```

Syntax Description	
<b>summary</b>	Displays wireless-multicast non-ip group summary.
<i>group-ip</i>	Specifies the group IP address.
<b>vlan</b> <i>vlan-id</i>	Specifies the destination group IPv4/IPv6 Address of multicast traffic.

**Command Default** None.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

**Usage Guidelines** None.

## Examples

This example shows how to display the wireless-multicast non-ip group summary.

```
Device# show wireless multicast group summary
```



# show wireless performance

To display aggressive load balancing configuration, use the **show wireless performance** command in privileged EXEC mode.

**show wireless performance {ap | client} summary**

<b>Syntax Description</b>	<b>ap summary</b>	Displays aggressive load balancing configuration of access points configured to the controller.
	<b>client summary</b>	Displays aggressive load balancing configuration details of the clients.
<b>Command Default</b>	No default behavior or values.	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless performance ap summary** command.

```
Device# show wireless performance ap summary
Number of APs:
```

The following is sample output from the **show wireless performance client summary** command.

```
Device# show wireless performance client summary
Number of Clients:

MAC Address          AP Name              Status              WLAN/Guest-Lan Auth Protocol Port Wired
-----
```

# show wireless pmk-cache

To display information about the pairwise master key (PMK) cache, use the **show wireless pmk-cache** command in privileged EXEC mode.

```
show wireless pmk-cache[mac-address mac-addr]
```

<b>Syntax Description</b>	<b>mac-address</b> <i>mac-addr</i> (Optional) Information about a single entry in the PMK cache.
<b>Command Default</b>	No default behavior or values.
<b>Command Modes</b>	Privileged EXEC
<b>Command History</b>	<b>Release</b>
	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1 This command was introduced.

The following is sample output from the **show wireless pmk-cache mac-address** command:

```
Device# show wireless pmk-cache mac-address H.H.H
Number of PMK caches in total : 0
```

## show wireless probe

To display the advanced probe request filtering configuration and the number of probes sent to the WLAN controller per access point per client and the probe interval in milliseconds, use the **show wireless probe** command in privileged EXEC mode.

**show wireless probe**

---

**Syntax Description**

This command has no arguments or keywords.

---

**Command Default**

No default behavior or values.

---

**Command Modes**

Privileged EXEC

---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless probe** command:

```
Device# show wireless probe
Probe request filtering           : Enabled
Number of probes per client per radio fwd from AP: 2
Probe request rate-limiting interval : 500 msec
Aggregate probe request interval   : 500 msec
```

# show wireless profile airtime-fairness mapping

To view the ATF policy mapping with the wireless profiles, use the **show wireless profile airtime-fairness mapping** command.

**show wireless profile airtime-fairness mapping**

<b>Syntax Description</b>	This command has no arguments.
---------------------------	--------------------------------

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the ATF policy mapping with the wireless profiles:

```
Device# show wireless profile airtime-fairness mapping
Policy Profile           Band      ATF Policy           Weight
Client Sharing  Availability
```

Policy Profile	Client Sharing	Availability	Band	ATF Policy	Weight
WGB		No	2.4GHz		-
WGB		No	5GHz		-
Policy1		No	2.4GHz		-
Policy1		No	5GHz		-
Test WBG		No	2.4GHz		-
Test WBG		No	5GHz		-
profile-name	Enabled	Yes	2.4GHz	atf-policy-name	5

## show wireless profile airtime-fairness summary

To view the summary of air time fairness profiles, use the **show wireless profile airtime-fairness summary** command.

**show wireless profile airtime-fairness summary**

---

### Syntax Description

This command has no arguments.

---



---

### Command Default

None

---

### Command Modes

Global configuration

---

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

---

This example shows how to view the summary of air time fairness profiles:

```
Device# show wireless profile airtime-fairness summary
Policy Id      Policy Name      Weight      Client Sharing
-----
1              atf-policy-name  5           Enabled
```

# show wireless profile ap packet-capture

To view the AP packet capture information, use the **show wireless profile ap packet-capture** command.

**show wireless profile ap packet-capture** { *detailed profile-name* | **summary** }

<b>Syntax Description</b>	<i>profile-name</i> AP packet capture profile.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Usage Guidelines

### Example

The following example shows how to view the AP packet capture information:

```
Device# show wireless profile ap packet-capture summary
Number of AP packet capture profiles: 3
```

Profile Name	Buffer	Duration(M	Packet Len	FTP IP
test	1200	20	0	9.1.0.101
test1	2048	10	0	0.0.0.0
tets1	1024	10	0	0.0.0.0

### Example

The following example shows how to view the detailed AP packet capture information of an AP profile:

```
Device# show wireless profile ap packet-capture detailed test1
```

```
Profile Name : test1
Description :
-----
Buffer Size      : 2048 KB
Capture Duration : 10 Minutes
Truncate Length  : packet length
FTP Server IP    : 0.0.0.0
FTP path         :
FTP Username     :

Packet Classifiers
 802.11 Control  : Enabled
 802.11 Mgmt     : Enabled
 802.11 Data     : Disabled
Dot1x           : Disabled
```

```
ARP           : Disabled
IAPP          : Disabled
IP            : Disabled
TCP           : Disabled
TCP port      : all
UDP           : Disabled
UDP port      : all
Broadcast     : Disabled
Multicast     : Disabled
```

# show wireless profile calendar-profile detailed

To view the calendar profile details for a specific profile name, use the **show wireless profile calendar-profile detailed** command.

**show wireless profile calendar-profile detailed** *profile-name*

<b>Syntax Description</b>	<i>profile-name</i> Specifies the calendar profile name.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows how to view the calendar profile details for a specific profile name:

```
Device# show wireless profile calendar-profile detailed daily_calendar_profile
Calendar profiles : daily_calendar_profile
-----
Recurrence : DAILY
Start Time : 09:00:00
End Time : 17:00:00
```



# show wireless profile calendar-profile summary

To view the summary of calendar profiles, use the **show wireless profile calendar-profile summary** command.

**show wireless profile calendar-profile summary**

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows the summary of calendar profiles:

```
Device# show wireless profile calendar-profile summary
Number of Calendar Profiles: 3
Profile-Name
-----
monthly_25_profile
weekly_mon_profile
daily_calendar_profile
```

# show wireless profile fabric detailed

To view the details of a given fabric profile name, use the **show wireless profile fabric detailed** command.

**show wireless profile fabric detailed** *fabric\_profile\_name*

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the details of a given fabric profile name:

```
Device# show wireless profile fabric detailed test1
Profile-name      : test-fabric
VNID              : 12
SGT               : 5
```

# show wireless profile flex

To see the flex parameters of an wireless profile, use the **show wireless profile flex** command.

```
show wireless profile flex { detailed flex-profile-name chassis {chassis-number | active | standby } R0
} | summary chassis {chassis-number | active | standby} R0}
```

## Syntax Description

<b>detailed</b>	Shows the flex-profile detailed parameters
<b>summary</b>	Show the flex-profile summary.
<i>chassis-number</i>	Chassis number. Valid range is 1–2.
<b>active</b>	Active instance.
<b>standby</b>	Standby instance.
<b>R0</b>	Route-Processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the flex parameter's summary of the wireless profile:

```
Device# show wireless profile flex summary
```

# show wireless profile policy detailed

To display the wireless policy profile details, use the **show wireless profile policy detailed** command.

**show wireless profile policy detailed** *policy-profile-name*

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privilege EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Amsterdam 17.2.1	This command was introduced.

## Example

This example displays the wireless policy profile details:

```
Device#show wireless profile policy detailed policy-profile-name
```

# show wireless profile tunnel summary

To display the wireless tunnel-profile summary, use the **show wireless profile tunnel summary** command.

## show wireless profile tunnel summary

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC (#)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.11.1	This command was introduced.

## Example

This example shows how to display the wireless tunnel profile summary:

```
Device# show wireless profile tunnel summary
```

```
Profile Name          AAA-Override AAA-Proxy DHCP Opt82 Enabled
-----
eogre_tunnel          No           No       Yes       Yes
eogre_tunnel_set      No           No       Yes       No
eogre_tunnel_snmp     No           No       No        No
```

# show wireless redundancy statistics

To see the high availability statistics, use the **show wireless redundancy statistics** command.

```
show wireless redundancy statistics {ap-group | wncd} all chassis {chassis-num | active | standby} R0
{ap-recovery | {instance-id | all | chassis {chassis-num | active | standby} R0}}
{client-group | wncd} all chassis {chassis-num | active | standby} R0
{client-recovery | {mobilityd | sisf} chassis {chassis-num | active | standby} R0}
{wncd | {instance-id | all | chassis {chassis-num | active | standby} R0}}
```

## Syntax Description

*chassis-number* Enter the chassis number as either 1 or 2.

**active R0** Active instance of the configuration in Route-processor slot 0.

**standby R0** Standby instance of the configuration in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see all the statistics for WNCd :

# show wireless rfid

To display RFID tag information, use the **show wireless rfid** command in privileged EXEC mode.

**show wireless rfid** { **client** | **detail** *rfid-mac-address* | **stats** | **summary** }

Syntax	Description
<b>client</b>	Displays the summary of RFID tags that are clients.
<b>detail</b>	Displays information about a particular RFID tag.
<b>stats</b>	Displays RFID statistics.
<b>summary</b>	Displays summary information for all known RFID tags.
<i>rfid-mac-address</i>	RFID MAC address.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Example

This example shows how to view RFID information:

```
Device# show wireless rfid summary
```

```
Total RFID entries: : 16
Total Unique RFID entries : 16
RFID ID VENDOR Closet AP RSSI Time Since Last Heard
0012.b80a.c791 Cisco 7069.5a63.0520 -31 1 minute 40 seconds ago
0012.b80a.c953 Cisco 7069.5a63.0460 -33 2 minutes 15 seconds ago
0012.b80b.806c Cisco 7069.5a63.0260 -45 22 seconds ago
0012.b80d.e9f9 Cisco 7069.5a63.0460 -38 2 minutes 37 seconds ago
0012.b80d.ea03 Cisco 7069.5a63.0520 -43 2 minutes 38 seconds ago
0012.b80d.ea6b Cisco 7069.5a63.0460 -39 2 minutes 35 seconds ago
0012.b80d.ebe8 Cisco 7069.5a63.0520 -43 1 minute 31 seconds ago
0012.b80d.ebeb Cisco 7069.5a63.0520 -43 2 minutes 37 seconds ago
0012.b80d.ec48 Cisco 7069.5a63.0460 -42 2 minutes 16 seconds ago
0012.b80d.ec55 Cisco 7069.5a63.0520 -41 1 second ago
```

# show wireless statistics mobility

To see the wireless mobility manager statistics, use the **show wireless stats mobility** command.

**show wireless stats mobility** {**dtls** | **messages**} [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

## Syntax Description

<b>dtls</b>	View the mobility dtls messages statistics.
<b>messages</b>	View the mobility messages statistics.
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
<b>active</b>	Active instance of the configuration in Route-processor slot 0.
<b>standby</b>	Standby instance of the configuration in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the statistics of the wireless mobility manager:

```
Device# show wireless stats mobility
```



# show wireless stats mesh packet error

To see the packet statistics of all connected mesh APs, use the **show wireless stats mesh packet error** command.

```
show wireless stats mesh packet error [ chassis {chassis-number | active | standby} R0]
```

Syntax Description	
<b>packet</b>	Shows packet statistics information.
<b>error</b>	Shows packet statistics of all connected mesh APs.
<b>active R0</b>	Active instance of the active AP filters in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the active AP filters in Route-processor slot 0.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the packet error statistics of all connected mesh APs:

```
Device# show wireless stats mesh packet error
```

# show wireless stats mesh security and queue

To see the mesh queue and security statistics of all connected mesh APs, use the **show wireless stats mesh** command.

**show wireless stats mesh** {**security** | **queue**} [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

## Syntax Description

<b>queue</b>	Shows queue statistics of all connected mesh APs.
<b>security</b>	Shows security statistics of all connected mesh APs.
<i>chassis-number</i>	Enter the chassis number as either 1 or 2.
<b>active R0</b>	Active instance of the active AP filters in Route-processor slot 0.
<b>standby R0</b>	Standby instance of the active AP filters in Route-processor slot 0.

## Command Default

None

## Command Modes

Privileged EXEC

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the security statistics of all connected mesh APs:

```
Device# show wireless stats mesh security
```

# show wireless stats client detail

To verify the statistics about client, use the **show wireless stats client detail** command.

## show wireless stats client detail

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Amsterdam 17.1.1	This command was introduced.

This example shows how to verify the statistics about client:

```
Device# show wireless stats client detail
[...]
Total L3 VLAN Override vlan change received : 1
Total L3 VLAN Override disassociations sent : 1
Total L3 VLAN Override re-associations received : 1
Total L3 VLAN Override successful VLAN change : 1
[...]
L3 VLAN Override connection timeout : 0
```

# show wireless summary

To display the number of access points, radios and wireless clients known to the controller, use the **show wireless summary** command in privileged EXEC mode.

## show wireless summary

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behavior or values.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

The following is sample output from the **show wireless summary** command:

```
Device# show wireless summary
```

```
Access Point Summary
```

	Total	Up	Down
802.11a/n	2	2	0
802.11b/g/n	2	2	0
All APs	2	2	0

```
Client Summary
```

```
Current Clients : 1
Excluded Clients: 0
Disabled Clients: 0
```

# show wireless tag rf

To display the details of wireless RF tag, use the **show wireless tag rf** command.

**show wireless tag rf** { **summary** | **detailed** } *rf-tag-name*

Syntax Description		
<b>summary</b>	Disaplys	the summary of all RF tags.
<b>detailed</b>	Disaplys	details of an RF tag.
<i>rf-tag-name</i>	RF tag	name.

**Command Default** None

**Command Modes** Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

## Example

The following example shows the sample output of **show wireless tag rf summary** command:

```
Device# show wireless tag rf summary
```

```
Number of RF Tags: 1
```

```
RF tag name           Description
-----
default-rf-tag       default RF tag
```

## show wireless urlfilter details

To view the details of a specified wireless URL filter, use the **show wireless urlfilter details** command.

**show wireless urlfilter details** *list-name*

<b>Syntax Description</b>	This command has no arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

This example shows how to view the details of a specified wireless URL filter:

```
Device# show wireless urlfilter details urllist_flex_preauth
List Name..... : urllist_flex_preauth
Filter ID..... : 1
Filter Type..... : PRE-AUTH
Action..... : PERMIT
Redirect server ipv4..... : 8.8.8.8
Redirect server ipv6..... : 2001:0300:0008:0000:0000:0000:0000:0081
Configured List of URLs
  URL..... : url1.dns.com
```

# show wireless urlfilter summary

To view the summary of all wireless URL filters, use the **show wireless urlfilter summary** command.

**show wireless urlfilter summary**

---

## Syntax Description

This command has no arguments.

---



---

## Command Default

None

---

## Command Modes

Global configuration

---

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

---

This example shows how to view the summary of all wireless URL filters:

```
Device# show wireless urlfilter summary
```

```
Black-list - DENY
```

```
White-list - PERMIT
```

```
Filter-Type - Specific to Local Mode
```

```
URL-List ID Filter-Type Action Redirect-ipv4 Redirect-ipv6
```

---

```
urllist_flex_preauth 1 PRE-AUTH PERMIT 8.8.8.8
```

```
2001:0300:0008:0000:0000:0000:0000:0081
```

# show wireless vlan details

To see the VLAN details, use the **show wireless vlan details** command.

**show wireless vlan details** [**chassis** {*chassis-number* | **active** | **standby**} **R0**]

---

## Command Default

None

---

## Command Modes

Privileged EXEC

---

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the VLAN details:

```
Device# show wireless vlan details chassis active r0
```



## show wireless wgb mac-address

To view all the clients of the wireless workgroup bridge (WGB) using its MAC address, use the **show wireless wgb mac-address** command.

**show wireless wgb mac-address** *mac-address* **detail**

---

**Syntax Description**

*mac-address* MAC address of the WGB.

**detail** View clients of the wireless WGB.

---

---

**Command Default**

None

---

**Command Modes**

Privileged EXEC

---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

---

### Examples

The following example shows how to see the clients of the wireless WGB:

```
Device# show wireless wgb mac-address 98-C7-7B-09-EF-ED detail
```

# show wireless wgb summary

To see the active workgroup bridges (WGB), use the **show wireless wgb summary** command.

**show wireless wgb summary**

---

## Command Default

None

---

## Command Modes

Privileged EXEC

---

## Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the active workgroup bridges (WGB):

```
Device# show wireless wgb summary
```

# show wireless wps mfp ap summary

To verify, if access points support Management Frame Protection (MFP) validation and protection, use the **show wireless wps mfp ap summary** command.

**show wireless wps mfp ap summary**

---

**Syntax Description** This command has no keywords or arguments.

---



---

**Command Default** None

---



---

**Command Modes** Privileged EXEC

---



---

**Command History**

Release	Modification
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

---

This example shows the access points that support MFP validation and protection:

```
Device# show wireless wps mfp ap summary
AP Name                               Radio MAC                               Validation                               Protection
-----
AP002A.1087.CBF4                       00a2.eefd.bdc0                           Enabled                                   Enabled
AP58AC.78DE.9946                         00a2.eeb8.4ae0                           Enabled                                   Enabled
APb4de.3196.caac                         4c77.6d83.6b90                           Enabled                                   Enabled
```

# show wireless wps mfp statistics

To view the Management Frame Protection (MFP) statistics, use the **show wireless wps mfp statistics** command.

## show wireless wps mfp statistics

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows the Management Frame Protection (MFP) statistics:

```
Device# show wireless wps mfp statistics
BSSID          Radio DetectorAP          LastSourceAddr Error          Count
      FrameTypes
aabb.ccdd.eeff a      AP3800
      Beacon, Probe Response          aabb.ccdd.eeff Invalid MIC          10
                                          Invalid MIC          20
      Beacon, Probe Response
```

# show wireless wps mfp summary

To view the detailed information of Management Frame Protection (MFP), use the **show wireless wps mfp summary** command.

**show wireless wps mfp summary**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC				
<b>Command History</b>	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE Gibraltar 16.12.1</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE Gibraltar 16.12.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 16.12.1	This command was introduced.				

This example shows the detailed information of Management Frame Protection (MFP):

```
Device# show wireless wps mfp summary
Management Frame Protection
  Global Infrastructure MFP state : Enabled
  AP Impersonation detection    : Disabled
  Key refresh interval          : 15
```

# show wireless wps rogue

To see the Rogue AP and Client information, use the **show wireless wps rogue** command.

## See Adhoc Rogues (IBSS) information

**show wireless wps rogue** {*adhoc* | {*detailedmac-addr*} | *summary*}

## See rogue AP information

**show wireless wps rogueap**{*clientsmac-addr* | *customsummary* | *detailedmac-addr* | *friendlysummary* | *listmac-addressmac-addr* | *malicious summary* | *summary* | *unclassifiedsummary* | *rldp*{*summary* | *in-progress* | *detailedrogue-ap-mac-addr*}}

## See rogue auto-containment information

**show wireless wps rogueauto-contain**

## See rogue client information

**show wireless wps rogueclient**{*summary* | *detailedmac-addr*}

## See rogue ignore list

**show wireless wps rogueignore-list**

## See classification rule information

**show wireless wps roguerule**{*detailedrule-name* | *summary*}

## See statistics about rogue feature

**show wireless wps rogestats**[{*internal*}]

### Syntax Description

*mac-address* MAC address of the client.

### Command Default

None

### Command Modes

Privileged EXEC

### Command History

Release	Modification
Cisco IOS XE Gibraltar 16.10.1	This command was introduced in a release earlier than Cisco IOS XE Gibraltar 16.10.1.

## Examples

The following example shows how to see the rogue feature statistics:

```
Device# show wireless wps rogue stats
```

# show wireless wps rogue ap summary

To display a list of all rogue access points detected by the device, use the **show wireless wps rogue ap summary** command.

**show wireless wps rogue ap summary**

**Command Default** None.

**Command Modes** Privileged EXEC

Command History	Release	Modification
		This command was introduced.

**Usage Guidelines** None.

This example shows how to display a list of all rogue access points detected by the device:

```

Device# show wireless wps rogue ap summary
Rogue Location Discovery Protocol      : Disabled
Rogue on wire Auto-Contain             : Disabled
Rogue using our SSID Auto-Contain     : Disabled
Valid client on rogue AP Auto-Contain : Disabled
Rogue AP timeout                      : 1200
Rogue Detection Report Interval       : 10
Rogue AP minimum RSSI                 : -128
Rogue AP minimum transient time       : 0

Number of rogue APs detected : 624

MAC Address      Classification      # APs      # Clients      Last Heard
-----
0018.e78d.250a   Unclassified      1          0              Thu Jul 25 05:04:01 2013
0019.0705.d5bc   Unclassified      1          0              Thu Jul 25 05:16:26 2013
0019.0705.d5bd   Unclassified      1          0              Thu Jul 25 05:10:28 2013
0019.0705.d5bf   Unclassified      1          0              Thu Jul 25 05:16:26 2013
    
```

# show wireless wps rogue client detailed

To view the detailed information of a specific rogue client, use the **show wireless wps rogue client detailed** *client-mac* command.

**show wireless wps rogue client detailed** *client-mac*

<b>Syntax Description</b>	<i>client-mac</i> MAC address of the rogue client.	
<b>Command Default</b>	None.	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.
<b>Usage Guidelines</b>	None.	

This example shows how to display the detailed information for a specific rogue client:

```
Device# show wireless wps rogue client detail 0024.d7f1.2558
Rogue BSSID                : 64d8.146f.379f
Rogue Radio Type           : 802.11n - 5GHz
State                      : Alert
First Time Rogue was Reported : Wed Aug  7 12:51:43 2013
Last Time Rogue was Reported  : Wed Aug  7 12:51:43 2013
Reported by
  AP 2
    MAC Address             : 3cce.7309.0370
    Name                    : AP3502-talwar-ccie
    Radio Type              : 802.11a
    RSSI                    : -42 dBm
    SNR                     : 47 dB
    Channel                 : 52
    Last reported by this AP : Wed Aug  7 12:51:43 2013
```



# show wireless wps rogue client summary

To display summary of WPS rogue clients, use the **show wireless wps rogue client summary** command.

**show wireless wps rogue client summary**

---

**Command Default**      None

---

**Command Modes**      Privileged EXEC

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.10.1	This command was introduced.

---

---

## Usage Guidelines

### Example

The following displays the output of the **show wireless wps rogue client summary** command:

```
Device# show wireless wps rogue client summary
Validate rogue clients against AAA : Disabled
Validate rogue clients against MSE : Enabled
Number of rogue clients detected : 0
```

# show wireless wps summary

To view the detailed information of wps, use the **show wireless wps summary** command.

## show wireless wps summary

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Gibraltar 16.12.1	This command was introduced.

This example shows if the Management Frame Protection (MFP) is enabled or disabled :

```
Device# show wireless wps summary
Client Exclusion Policy
  Excessive 802.11-association failures : unknown
  Excessive 802.11-authentication failures: unknown
  Excessive 802.1x-authentication      : unknown
  IP-theft                             : unknown
  Excessive Web authentication failure  : unknown
  Failed Qos Policy                    : unknown

Management Frame Protection
  Global Infrastructure MFP state : Enabled
  AP Impersonation detection     : Disabled
  Key refresh interval           : 15
```

# show wlan summary sort ascending client-count

To view the WLAN summary sorted ascendingly based on the client count, use the **show wlan summary sort ascending client-count** command.

**show wlan summary sort ascending client-count**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC				
<b>Command History</b>	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE Amsterdam 17.1.1s</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.
Release	Modification				
Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.				

This example shows how to view the WLAN summary sorted ascendingly based on the client count:

```
Device# show wlan summary sort ascending client-count
```

```
-----  
Wlan-name                               ID           Client count   Data Usage  
-----  
r1an_test_1                             1            1              6277  
WLAN_CA_WPA2_AES_DOT1X                 70           1              167781  
-----
```

# show wlan summary sort descending client-count

To view the WLAN summary sorted descendingly based on the client count, use the **show wlan summary sort descending client-count** command.

**show wlan summary sort descending client-count**

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

This example shows how to view the WLAN summary sorted descendingly based on the client count:

```
Device# show wlan summary sort descending client-count
```

```
-----
Wlan-name                ID           Client count      Data Usage
-----
rlan_test_1              1            1                  6277
WLAN_CA_WPA2_AES_DOT1X  70           1                  167781
-----
```

# show wlan summary sort ascending data-usage

To view the wlan summary sorted ascendingly based on the data usage, use the **show wlan summary sort ascending data-usage** command.

**show wlan summary sort ascending data-usage**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Privileged EXEC				
<b>Command History</b>	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>Cisco IOS XE Gibraltar 17.1.1</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	Cisco IOS XE Gibraltar 17.1.1	This command was introduced.
Release	Modification				
Cisco IOS XE Gibraltar 17.1.1	This command was introduced.				

This example shows how to view the wlan summary sorted ascendingly based on the data usage:

```
Device# show wlan summary sort ascending data-usage
```

```
-----  
Wlan-name                ID          Client count    Data Usage  
-----  
r1an_test_1              1          1               6277  
WLAN_CA_WPA2_AES_DOT1X  70        1               167781  
-----
```

# show wlan summary sort descending data-usage

To view the WLAN summary sorted descendingly based on the data usage, use the **show wlan summary sort descending data-usage** command.

**show wlan summary sort descending data-usage**

---

**Syntax Description** This command has no keywords or arguments.

---



---

**Command Default** None

---



---

**Command Modes** Privileged EXEC

---



---

Command History	Release	Modification
	Cisco IOS XE Amsterdam 17.1.1s	This command was introduced.

---

This example shows how to view the WLAN summary sorted descendingly based on the data usage:

```
Device# show wlan summary sort descending data-usage
```

```
-----
Wlan-name                ID          Client count    Data Usage
-----
WLAN_CA_WPA2_AES_DOT1X  70         1               167781
rln_test_1               1          1               6277
-----
```

## show wps summary

To display Wireless Protection System (WPS) summary information, use the **show wps summary** command.

### show wps summary

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

The following example shows how to display WPS summary information:

```
(Cisco Controller) > show wps summary
Auto-Immune
  Auto-Immune..... Disabled
Client Exclusion Policy
  Excessive 802.11-association failures..... Enabled
  Excessive 802.11-authentication failures..... Enabled
  Excessive 802.1x-authentication..... Enabled
  IP-theft..... Enabled
  Excessive Web authentication failure..... Enabled
Trusted AP Policy
  Management Frame Protection..... Disabled
  Mis-configured AP Action..... Alarm Only
    Enforced encryption policy..... none
    Enforced preamble policy..... none
    Enforced radio type policy..... none
  Validate SSID..... Disabled
  Alert if Trusted AP is missing..... Disabled
  Trusted AP timeout..... 120
Untrusted AP Policy
  Rogue Location Discovery Protocol..... Disabled
    RLDP Action..... Alarm Only
Rogue APs
  Rogues AP advertising my SSID..... Alarm Only
  Detect and report Ad-Hoc Networks..... Enabled
Rogue Clients
  Validate rogue clients against AAA..... Enabled
  Detect trusted clients on rogue APs..... Alarm Only
  Rogue AP timeout..... 1300
Signature Policy
  Signature Processing..... Enabled
...
```

# shutdown

To close the RF Profile and disable the network, use the **shutdown** command. To disable shutdown execution, use the **no** form of this command.

## shutdown

<b>Syntax Description</b>	<b>shutdown</b>	Shuts down the profile and disables network.
<b>Command Default</b>	None	
<b>Command Modes</b>	config-rf-profile	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XE Denali 16.3.1	This command was introduced.
<b>Usage Guidelines</b>	None	

This example shows how to close a RF Profile and disable the network.

```
Device (config-rf-profile) #shutdown
```