



IW Monitor User Guide, Release 2.2.0

First Published: 2025-08-08

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883



CONTENTS

P R E F A C E

Preface v

About this Guide v

Related Documentation v

Communications, Services, and Additional Information v

C H A P T E R 1

Overview of the IW Monitor 1

IW Monitor Overview 1

C H A P T E R 2

Supported Network Devices and Firmware for IW Monitor 3

Supported Network Devices and Firmware for IW Monitor 3

C H A P T E R 3

Installing IW Monitor Docker on Host 5

Host and Network Requirements 5

Installing Docker on Host 7

Installing and Running Docker Container 8

Downloading and installing the Docker application 8

Downloading the IW Monitor Image 8

Loading the IW Monitor Image File to the IW Monitor Server 9

Running the Docker Container for the First Time 9

Logging to the IW Monitor for the First Time 10

C H A P T E R 4

Adding Devices to the IW Monitor 19

Adding Devices to the IW Monitor 19

| | | |
|-------------------|---|-----------|
| CHAPTER 5 | Managing Sections | 23 |
| | Create a new Section | 23 |
| | Set maximum number of devices | 24 |
| | Editing a Section | 25 |
| | Deleting a Section | 26 |
| <hr/> | | |
| CHAPTER 6 | Managing Devices | 27 |
| | Editing the Device Configuration Parameters using Configurator Interface | 27 |
| | Detaching the Device from the IW Monitor | 28 |
| <hr/> | | |
| CHAPTER 7 | Monitoring Network Performance | 31 |
| | Viewing the Network Statistics | 31 |
| | Viewing the Devices using Table View | 32 |
| | Viewing the Uplink and Downlink Information for a Device | 36 |
| | Viewing Device Statistics in Real Time | 39 |
| | Viewing the Devices from Topology | 42 |
| | Filtering and Viewing Network Events | 47 |
| | Exporting a Network Event Log as a CSV File | 50 |
| <hr/> | | |
| CHAPTER 8 | Configuring IW Monitor Database Settings | 51 |
| | Defining Hard Disk Storage Capacity and Overwrite Cycle Period for the IW Monitor Statistics Database | 51 |
| | Backing up the IW Monitor Statistics Database | 53 |
| | Deleting the recent IW Monitor Statistics Data | 54 |
| <hr/> | | |
| CHAPTER 9 | Configuring IW Monitor Statistical Settings | 57 |
| | Changing the Interval at which Statistical Data is Logged | 57 |
| | Customizing Event-Logging Settings | 59 |
| | Setting Performance Thresholds | 61 |
| | Setting Performance Thresholds for Each Section | 62 |
| <hr/> | | |
| CHAPTER 10 | Managing User Accounts | 65 |
| | Modifying an Existing User Account | 65 |

Viewing, Adding, and Deleting Users **66**

 Reset a password for another user **67**

CHAPTER 11

Updating IW Monitor **69**

 Updating IW Monitor **69**

CHAPTER 12

Uninstalling IW Monitor **71**

 Uninstalling IW Monitor **71**



Preface

This preface describes this guide and provides information about how to use IW Monitor, and related documentation.

It includes the following sections:

- [About this Guide, on page v](#)
- [Related Documentation, on page v](#)
- [Communications, Services, and Additional Information, on page v](#)

About this Guide

This guide details Cisco Industrial Wireless (IW) Monitor, an on-premises monitoring tool for maintaining and monitoring one or multiple Ultra-Reliable Wireless Backhaul (URWB) networks. IW Monitor displays data and situational alerts from every URWB device in a network in real-time. This is the first release of IW Monitor, and it manages Industrial Wireless (IW) and Fluidmesh devices.

Related Documentation

For more details about Regulatory Compliance and Safety Information, see [Regulatory Compliance and Safety Information](#).

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you’re looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions, and services, visit [Cisco DevNet](#).
- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

Cisco Bug Search Tool

[Cisco Bug Search Tool](#) (BST) is a gateway to the Cisco bug-tracking system, which maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. The BST provides you with detailed defect information about your products and software.

Documentation Feedback

To provide feedback about Cisco technical documentation, use the feedback form available in the right pane of every online document.



CHAPTER 1

Overview of the IW Monitor

- [IW Monitor Overview, on page 1](#)


IW Monitor Overview

IW Monitor application is an on-premises monitoring tool for Industrial Wireless (IW) and Fluidmesh devices and it is designed to be used along with IoT Operations Dashboard (OD) with IW Service. The IW Service allows you to configure and provision the Industrial Wireless devices, whereas IW Monitor displays real-time data and alerts for URWB devices in the network. The functionality of the two interfaces differs as follows:

- IW Service is the cloud-based interface used to do online and offline configuration of IW devices.
- IW Monitor is a virtual-image-based diagnostic and analysis interface, with the virtual image installed in Docker format to monitor Fluidmesh and Industrial Wireless devices.

The functionalities of IW Monitor application are:

- Monitor the real time condition of networks.
- Generate statistics from network history.
- Verify if the device configuration settings are optimal for current network conditions.
- Detect network related events for diagnostic and generate alerts if network related faults arise.
- Analyze network data, with the goal of increasing system uptime and maintaining optimum network performance.



To configure the IW devices, you can use any of the following methods:

- To add and configure devices using cloud-based IW Service, see [IoT OD IW documentation](#).
- To manually configure devices by using the device's built-in Configurator interface or through CLI, see [Cisco Ultra-Reliable Wireless Backhaul for Catalyst IW Access Points, Software Configuration Guide](#) or [Cisco IEC6400 Edge Compute Appliance Installation and Configuration Guide](#).



CHAPTER 2

Supported Network Devices and Firmware for IW Monitor

- [Supported Network Devices and Firmware for IW Monitor, on page 3](#)

Supported Network Devices and Firmware for IW Monitor

The following table shows the supported device models and the recommended firmware versions:

| Device Model | Recommended Software Version |
|---------------------|------------------------------|
| Catalyst IW9167 | 17.12.1 (17.12.1.5) or later |
| Catalyst IW9165 | 17.12.1 (17.12.1.5) or later |
| FM 3500 and FM 4500 | 9.4 or later |
| FM 3200 and FM 4200 | 8.5 or later |
| FM 1200 VOLO | 7.9 or later |
| FM PONTE | 1.2.7 or later |
| FM1000 and FM10000 | 1.3.0 or later |
| FM10000 GEN2 | 2.3.0 or later |
| IEC-6400 | 1.1.0.7 or later |



CHAPTER 3

Installing IW Monitor Docker on Host

- Host and Network Requirements, on page 5
- Installing Docker on Host, on page 7
- Installing and Running Docker Container, on page 8
- Downloading and installing the Docker application, on page 8
- Downloading the IW Monitor Image, on page 8
- Loading the IW Monitor Image File to the IW Monitor Server, on page 9
- Running the Docker Container for the First Time, on page 9
- Logging to the IW Monitor for the First Time, on page 10

Host and Network Requirements

Host requirements



Note It is recommended to have a high-speed, high bandwidth internet connection for installation of Docker and the IW Monitor image file.

If an internet connection is not available, the Docker application and IW Monitor image file can be installed manually. See [Installing and Running Docker Container, on page 8](#).

Make sure the following host requirements are met to run the Docker container:

| | | | |
|---------------------------|--------------------|--------------------------|---|
| Operating System | Windows 7 or later | Mac OS X 10.9.x or later | Linux (32-bit or 64-bit): <ul style="list-style-type: none">• Ubuntu 14.04 or later• Debian 9 or later• OpenSuSE 14.2 or later• Fedora Linux 19 or later |
| Docker Application | Yes | Yes | Yes |

| | | | |
|--|---|---|---|
| Base System | Virtual machine or bare metal | Virtual machine or bare metal | Virtual machine or bare metal |
| Processor | Intel Core i7 or Xeon (any frequency and mandatory minimum of four cores) | Intel Core i7 or Xeon (any frequency and mandatory minimum of four cores) | Intel Core i7 or Xeon (any frequency and mandatory minimum of four cores) |
| RAM | 16 GB minimum | 16 GB minimum | 16 GB minimum |
| Hard Disk | 100 GB minimum* 1 TB or greater recommended | 100 GB minimum* 1 TB or greater recommended | 100 GB minimum* 1 TB or greater recommended |
| High speed connection to local networks and devices | Preferred | Preferred | Preferred |
| Screen Resolution | 1024 x 768 pixel minimum | 1024 x 768 pixel minimum | 1024 x 768 pixel minimum |



Note Using a hard disk of at least 100 GB capacity is recommended. If a hard disk of less than 100 GB capacity must be used, adjust the maximum capacity available for statistics storage as mentioned in [Defining Hard Disk Storage Capacity and Overwrite Cycle Period for the IW Monitor Statistics Database, on page 51](#).

Browser requirements

Use the latest version of a supported web browsers to access the IW Monitor:

| Browser | Supported Version |
|-----------------------------|-------------------|
| Mozilla Firefox | Latest |
| Microsoft Internet Explorer | Latest |
| Microsoft Edge | Latest |
| Google Chrome | Latest |
| Apple Safari | Latest |



Note If needed, upgrade your browser to the latest version.

Installing Docker on Host

A Docker image is a standard, self-contained unit of software that packages code and its dependencies that lets the application run quickly and reliably from one computing environment to another. Docker images become containers at runtime when they run on the Docker engine.

Prerequisites to install Docker on the IW Monitor host

When Docker is installed on the IW Monitor host, make sure that the host's CPU supports virtualization and second-level address translation (SLAT).



Note Intel's version of SLAT is called EPT (Extended page tables).

To check if the host's processor or processors meets the requirement:

1. Go to [Microsoft Sysinternals](#), download the `Coreinfo` package.
2. Unzip the downloaded program folder to the root of the host's `C:\` drive
3. Open the command prompt using administrator privileges.
4. Enter the command: `coreinfo.exe -v`
 - If an Intel CPU supports SLAT, an asterisk (*) is shown in the EPT row (below):

```

Administrator: Command Prompt
Microsoft Windows [Version 6.1.7601]
Copyright <c> 2009 Microsoft Corporation. All rights reserved.

C:\Windows\system32>cd c:\
c:\>coreinfo.exe -v

Coreinfo v3.0 - Dump information on system CPU and memory topology
Copyright <C> 2008-2011 Mark Russinovich
Sysinternals - www.sysinternals.com

Intel(R) Core(TM) i7 CPU         930 @ 2.80GHz
Intel64 Family 6 Model 26 Stepping 5, GenuineIntel
HYPERVISOR      - Hypervisor is present
VMX            * Supports Intel hardware-assisted virtualization
EPT            * Supports Intel extended page tables

c:\>

```

- If your CPU does not support SLAT, a dash (-) is shown in the EPT row.

To check if CPU supports SLAT:

1. Go to [Intel Product Specification](#).
2. Select the respective CPU, and check its specifications.

Installing and Running Docker Container



Important Before you install and run the docker container on a Microsoft operating system, make sure that Microsoft virtual machine capability (Hyper V) is running. Also, VMware is supported.



Important Do not install the Docker container on your local computer. Docker must only be installed on the host assigned to run the IW Monitor. To view the minimum hardware specifications of the host, see [Host and Network Requirements, on page 5](#).



Note Oracle VM VirtualBox is not supported.

To install Docker, you must open these protocols and ports in the firewall to ensure MONITOR works correctly.

- UDP from MONITOR to devices. Port 6600 is used for devices association.
- UDP from MONITOR to devices. Port 6610 is used for latency and jitter computation.
- Secure WebSocket from devices to MONITOR. The customer configures the port with the docker run command, usually 8443.

Downloading and installing the Docker application

Procedure

Step 1 Go to the Docker application [download page](#).

Step 2 Download the correct Docker application package.

Step 3 Install the Docker application on the IW Monitor host.

Downloading the IW Monitor Image

Procedure

Step 1 Go to [software downloads](#).

Step 2 Download the IW Monitor image file (iw-monitor-dockerv1. x.x.tar).

Loading the IW Monitor Image File to the IW Monitor Server

Procedure

Step 1 Open a command-line window.

Step 2 Enter the command: `docker load -i iw-monitor-dockerv1. x.x.tar`

Step 3 Enter the command to check if the IW Monitor image file is loaded: `docker images`

A list of the Docker image files currently installed on the IW Monitor host are shown.

Step 4 To get the image ID value for the IW Monitor image file:

- Open a command-line window.
- Enter the command: `docker images`

A list of the Docker image files currently installed on the IW Monitor host are shown.

- Search the REPOSITORY column of the Docker image file list for the **iw-monitor image** file.
Make a note of the IMAGE ID value of the IW Monitor Docker image.

Running the Docker Container for the First Time

Procedure

Step 1 Open a command-line window.

Step 2 Enter the command: `docker run -d --name iw_monitor -p 8443:8443 --restart always X` where X is the IMAGE ID value of the IW Monitor Docker image.

Note

By default, the port numbers of the IW Monitor which runs on within the Docker container are:

- Port 8443 (https with SSL)
- Encryption / HTTPS is required

Note

If you fail to use the default host port numbers due to security policy settings or the needed host port is assigned to another service, modify the `docker run` command to include an unused host port.

Note


For example, a run command that specifies port 3000: `docker run -d --name iw_monitor -p 3000:8443 iw_monitor`

Logging to the IW Monitor for the First Time

Step 3 If you have modified the Docker run command to specify a different host port, then you must specify the port number used by IW Monitor. For more information, see [Adding Devices to the IW Monitor, on page 19](#).

Step 4 Open the web browser.

Step 5 Navigate to the URL <https://X:Y> where X is the IP address of the IW Monitor host, and Y is the host port number. IW Monitor Docker container is successfully launched and the welcome page is shown as



below:


Logging to the IW Monitor for the First Time

Procedure

Step 1 Open the web browser.

Step 2 Enter the URL with IP address and port number of the computer on which the IW Monitor image file: [https://\[IP address\]:\[host port number\]](https://[IP address]:[host port number])

If you are running IW Monitor for the first time, the following initialization page appears:

**Step 3**

Fill your first name, last name, e-mail address and login password in the respective fields.

Step 4

Click **Next**.

The **Add new device** screen appears.

1. Welcome 2. Report 3. Complete

Configure server settings

Server IP * 203.0.113.24

Port * 8443

Attach devices

Enter one or more IP addresses separated by comma

203.0.113.27 X 203.0.113.28 X e.g. 192.168.0.1, 192.168.0.2

Associate devices

Next

Step 5

(Optional) If required, fill the IP address of the IW Monitor server in the **Server IP** field and port number in **Port** field.

Step 6

Fill the IP addresses of all the devices that you want to monitor in the **IP addresses** field.


Note

Press **Enter** after entering each IP address, including the last IP address.

Step 7

Click **Associate devices**.


A confirmation screen appears showing that the devices are associated with the IW Monitor interface.

**Step 8**

Click **Close**.

The list of devices associated with the IW Monitor interface are shown as below:

Logging to the IW Monitor for the First Time



The screenshot shows the 'Report' step of the IW Monitor setup process. The interface has a top navigation bar with three steps: '1. Welcome', '2. Report' (which is the active step), and '3. Complete'. A sub-header 'Devices: 2' is displayed above a table. A status bar at the top right shows 'Server IP: 64.103.77.16 | Port 8443'. A search bar labeled 'Search Table' is present. The table lists two devices:

| <input type="checkbox"/> | Name | IP Address | Mesh ID | Model | Role | Status |
|--------------------------|----------------|---------------|--------------|--------------|-------------------------------|--------------------------------------|
| <input type="checkbox"/> | Cisco | 10.115.11.90 | 5.0.178.95 | 4200 | Fluidity Infra | ● |
| <input type="checkbox"/> | Cisco-test-1_7 | 10.115.11.116 | 5.21.200.136 | IW9167EH-ROW | Fixed Infra Fluidity Infra | ● |


Below the table, it says '2 Records'. At the bottom right is a 'Next' button.

Step 9

Make sure that all the devices are listed on the screen. If any device is missing, follow the steps to add the device:

- Click **Add Device**.


The **Add new device** screen appears.



- b) Fill the IP address of the devices in the **IP addresses** field.
- c) Click **Save**.

Logging to the IW Monitor for the First Time

A confirmation screen appears showing that the devices are associated with the IW Monitor interface.




d) Click **Close**.

Step 10


Click **Next**.

The IW Monitor analyzes the network and once the network analysis is complete and then the **Complete** screen appears:



Step 11 Click **Done** to complete the network setup.

The IW Monitor dashboard appears:





CHAPTER 4

Adding Devices to the IW Monitor

- [Adding Devices to the IW Monitor, on page 19](#)

Adding Devices to the IW Monitor

Procedure

Step 1 Click on the  **settings** icon at the top right.
A new settings screen is shown.

Step 2 Click **Devices**.
A table with the list of configured devices are shown.


Step 3 Click on the  **edit** icon at the top right to configure the IP address of the main server of the network.
A pop-up appears.

Step 4 If needed, add the server IP address in the **Server IP** field.

Step 5 If the IW Monitor host is configured to use HTTPS (secure socket layer) data transfer, enable the SSL.


Step 6 Fill the correct port number of the Docker container in the **Port** field.
For example:

- **-p 8443:8443** maps to Port 8443
- **-p 443:8443** maps to Port 443
- **-p 3000:8443** maps to Port 3000



Step 7 Click **Save changes**.
Step 8 Click **Add Devices**.

A new pop-up **Add new device** appears to add the IP addresses of the devices.



Step 9 Add the IP addresses of the devices, separated by comma and a space. Alternatively, open an Excel file and add all the IP addresses in a column. Copy the whole column and paste it.

For example: 192.168.0.1, 192.168.0.2, 192.168.0.3


Note

If the IP address is not reachable, an error shows that the devices failed to attach appears. Check if the IP address is correct and reachable and/or if any firewall is blocking.

If you try to add an already associated device, an error shows that the device failed to add.

Step 10 Click Save.

The newly added devices appear in the table.



CHAPTER 5

Managing Sections

- [Create a new Section, on page 23](#)
- [Editing a Section, on page 25](#)
- [Deleting a Section, on page 26](#)

Create a new Section

Procedure

Step 1 Click + ADD SECTION.

Type section name

Info 

Select URWB devices
Tick the box to add a device to this section. Untick the box to remove the device. Devices already added in other sections are not displayed.

Find URWB device Show selected devices only Select all

Cisco 5.0.178.85 10.115.11.90 Fluidity Infra

Cisco 5.27.123.26 192.168.0.10 Fluidity Infra

Cisco-158.92.156 5.158.92.156 10.115.11.234 Disabled (R1) | Fixed Infra (R2)

0 selected units

Step 2 Click  edit icon and enter a name for the new section.

Step 3 Search for the device using the mesh ID, assigned device name (label), or the device's IP address.

Step 4 Select the devices to be added to the section. You can also select the devices from the uncategorized list and check **Show selected devices only** checkbox.

The uncategorized devices are devices that are not yet assigned to any section. These uncategorized devices are shown independently as shown below.

Note

Devices that are already added in other sections will not appear here.

Set maximum number of devices



Step 5 Click **Confirm**.

The selected devices are added to the new section.


Set maximum number of devices

You can set the maximum number of devices that can be included in a section. The default value for each section is 200 devices.

Procedure

Step 1 Navigate to **Settings > Customisation**.

Step 2 Set the **Maximum number of devices** for the section.



Step 3 Click **Save changes**.

Editing a Section

Procedure

Step 1 Click on the  **edit** icon of the section that you want to edit.
A detailed screen appears.

Step 2 Update the required fields like name of the section and/or list of devices.

Step 3 Click **Confirm**.

Deleting a Section

Procedure

Step 1 Click on the  edit icon of the section that you want to delete.

A detailed screen appears.

Step 2 Click  which is on the top right corner of the section.

A confirmation pop-up appears.

Step 3 Click **Delete**.



CHAPTER 6

Managing Devices

- [Editing the Device Configuration Parameters using Configurator Interface, on page 27](#)
- [Detaching the Device from the IW Monitor, on page 28](#)

Editing the Device Configuration Parameters using Configurator Interface

Procedure

Step 1



Click **Table View** to see the list of devices.


A new screen as below appears:

Step 2

In the **More** column, click of the device for which you want to edit the configuration parameters.

Detaching the Device from the IW Monitor

A detailed section appears:



Step 3 Click Device Configuration page.

The web browser opens a new page with a prompt to enter the device's user name and password.

Step 4 Enter the correct user name and password and click Enter.

The offline web interface (Configurator) opens for the device. To edit device configuration parameters using Configurator interface, see [Cisco Ultra-Reliable Wireless Backhaul for Catalyst IW Access Points, Software Configuration Guide](#).

Detaching the Device from the IW Monitor

Procedure

Step 1 Click on the settings icon at the top right.

A new settings screen is shown.

Step 2 Click Devices.


A table with the list of attached devices are shown.

| | Name | IP Address | Mesh ID | Model | Role | Status |
|-------------------------------------|-------------------|---------------|--------------|----------------------|----------------------|--------|
| <input type="checkbox"/> | 10.115.11.233 | 5.158.92.168 | IW9165E-B | Fixed Infrastructure | ● | |
| <input checked="" type="checkbox"/> | 10.115.11.141 | 5.21.201.60 | IW9167EH-Q | Gateway | ● | |
| <input checked="" type="checkbox"/> | Cisco-127.234.232 | 10.115.11.147 | IW9165E-B | Gateway | ● | |
| <input type="checkbox"/> | Cisco-21.200.24 | 10.115.11.119 | IW9167EH-B | Gateway | ● | |
| <input type="checkbox"/> | Cisco-212.77.244 | 10.115.11.133 | IW9167EH-B | Gateway | ● | |
| <input type="checkbox"/> | Cisco-test-tenant | 10.115.11.128 | 5.21.201.112 | IW9167EH-ROW | Fixed Infrastructure | ● |
| <input type="checkbox"/> | CiscoURWB-name | 10.115.11.231 | 5.158.92.176 | IW9165E-B | Gateway | ● |

Step 3 Search for the device using the mesh ID number, assigned device name, device model, or the device's IP address. Or, select the device(s) you want to detach from the IW Monitor.


Step 4 Click **Detach**.

The selected devices are successfully detached with the following confirmation pop-up:



Step 5

To remove a device from the IW Monitor using the Configurator interface's detach function, see [Cisco Ultra-Reliable Wireless Backhaul for Catalyst IW Access Points, Software Configuration Guide](#).




CHAPTER 7

Monitoring Network Performance

- Viewing the Network Statistics, on page 31
- Viewing the Devices using Table View, on page 32
- Viewing the Uplink and Downlink Information for a Device, on page 36
- Viewing Device Statistics in Real Time, on page 39
- Viewing the Devices from Topology, on page 42
- Filtering and Viewing Network Events, on page 47
- Exporting a Network Event Log as a CSV File, on page 50

Viewing the Network Statistics




The real-time monitoring shows the performance of the combined network. Each box shows information about performance of a specified network section. In each network section, the blocks show operating parameters of the devices in the network such as:

- Number of devices currently connected to IW Monitor, in relation to the total number of devices associated to IW Monitor.

Viewing the Devices using Table View

- Device latency (**Average latency**) values across the network or section during the last six hours.
- Aggregate network throughput transmitted (**Throughput TX**) by all devices in the network during the last six hours.
- Aggregate network throughput received (**Throughput RX**) by all devices in the network during the last six hours.
- Aggregate number of data packets sent (**Sent Packets/s**) by all devices in the network during the last six hours.
- Aggregate number of data packets received (**Received Packets/s**) by all devices in the network during the last six hours.
- Current number of edge devices (**Edge devices**).
- Average network or section uptime value (**Average uptime**). The average uptime value is the combined percentage of time for each network device or section connected to the IW Monitor in the last seven days.

A thin red box appears around the section if any performance-related faults arise and need immediate investigation. The **+ ADD SECTION** at the bottom allows you to customize the section with the device information you want to monitor. To add a new section to an existing network, see [Create a new Section, on page 23](#).



Viewing the Devices using Table View

Procedure

Step 1 Click  **Table View** to see the list of devices.

The screenshot shows the IW Monitor v2.2 interface with the 'Table View' selected. The top navigation bar includes 'MONITOR v2.2', 'Dashboard', 'Table View' (selected), 'Data Analysis', 'Topology', and 'Log'. The 'Table View' section has a search bar 'Search by Mesh ID, label or IP address' and a filter 'Filter by status' with options for Critical (red), Warning (orange), and Disconnected (grey). Below these are two tables:

Fixed (2)

| Status | Label | IP Address | Mesh ID | FW version | Role | Frequency | TX Power | Max TX power | Channel width | More | |
|--------|-----------------|-------------|-------------|------------|----------|----------------------------|----------------------|------------------|---------------|------------------|-----|
| Mp | Cisco-21.201.88 | 10.58.28.80 | 5.21.201.88 | 8.8.1.10 | R1 R2 | Fixed Infra Fixed Infra | 5500 MHz 5500 MHz | 27 dBm 20 dBm | AUTO AUTO | 80 MHz 80 MHz | ... |
| ME | AP-01B | 10.58.28.52 | 5.246.2.28 | 17.16.0.88 | R1 R2 | Disabled Fixed Infra | - 5500 MHz | - 17 dBm | - Level: 2 | - 20 MHz | ... |

Fluidity (3)

| Status | Label | IP Address | Mesh ID | FW version | Role | Frequency | TX Power | Max TX power | Channel width | More |
|--------|-----------------|-------------|--------------|------------|------------------|-----------|----------|--------------|---------------|------|
| MP | VEHICLE-58.32-P | 10.58.28.32 | 5.1.49.180 P | 9.4.2 | Fluidity Vehicle | 5785 MHz | 15 dBm | 15 dBm | 20 MHz | ... |
| MP | VEHICLE-58.33-S | 10.58.28.33 | 5.1.49.179 S | 9.4.2 | Fluidity Vehicle | 5785 MHz | 15 dBm | 15 dBm | 20 MHz | ... |
| MP | VEHICLE-58.36-P | 10.58.28.36 | 5.1.49.184 P | 9.4.2 | Fluidity Vehicle | 5785 MHz | 15 dBm | 15 dBm | 20 MHz | ... |

- All the devices that are not assigned to any specific sections are shown under **Uncategorized**. To add uncategorized devices to a specific section, see [Create a new Section, on page 23](#).
- The devices that are assigned to specific network sections are shown in the relevant section.
- Following table describes each column:

Viewing the Devices using Table View

| Parameter | Description |
|--|---|
| Status (icon color and designation) | <p>Icon colors represent the following device status:</p> <ul style="list-style-type: none"> • Green: Device is online and connected to an IW Monitor with all the performance levels in an acceptable range. • Gray: Device is disconnected from IW Monitor. • Orange: Device is online and connected to the IW Monitor but has one or more problems that cause it to perform at a lower-than-optimal level. • Red: Device is online and connected to IW Monitor but has one or more problems that cause unacceptably low performance. If a device icon is orange or red, the device may have one or more of the following problems: <ul style="list-style-type: none"> • Unusually high packet error rate • Unusually high link error rate • Unusually low received signal strength • Unusually high traffic latency <p>Icon designation are as follows:</p> <ul style="list-style-type: none"> • ME: Device is configured as a mesh end. • MP: Device is configured as a mesh point. • BR: Device is configured as a wireless bridge device. • PONTE: This is applicable only for FM PONTE devices. • GGW: Gateway is configured as a Global Gateway. |
| Label | <p>This is the user assigned device name.</p> <p>Note You cannot change the device name using IW Monitor. Use IoT OD IW service, the device offline web interface (Configurator), or the device's command-line interface (CLI) to change the device's name.</p> |
| IP Address | Shows the IP address of the device. |

| Parameter | Description |
|---------------------|--|
| Mesh ID | <p>Every device has a unique, factory set mesh identification number, for example: 5.a.b.c</p> <ul style="list-style-type: none"> • If the device is set as the primary vehicle-mounted network device, then letter P is mentioned next to the Mesh ID. • If the device is set as a secondary device (a subordinate device within a vehicle-mounted network), then the letter S is mentioned next to the Mesh ID. |
| FW Version | Shows value of the firmware release number. |
| Role | <p>Role designations represent the following device status:</p> <ul style="list-style-type: none"> • Fixed Infra: Device is part of a fixed based infrastructure. • Fluidity Vehicle: Device is part of a Fluidity network, and installed in a moving vehicle. • Fluidity Infra: Device is part of a Fluidity network, and installed as part of a fixed infrastructure. <p>Note For Cisco Catalyst IW9165 and IW9167 devices, the Role parameter is specified for each radio interface. If the radio interface is disabled, it shows as Disabled.</p> |
| Frequency | <p>Shows the device's current operating frequency.</p> <p>Note For dual-radio devices, the Frequency parameter is shown for each radio interface.</p> |
| TX Power | <p>Shows the current value in dBm of the radio device's transmission power.</p> <p>Note For dual-radio devices, the TX Power parameter is shown for each radio interface.</p> |
| Max TX Power | <p>Shows the user-defined value of the radio device's maximum transmission power level.</p> <p>Note For dual-radio devices, the Max TX Power parameter is shown for each radio interface.</p> |

Viewing the Uplink and Downlink Information for a Device

| Parameter | Description |
|----------------------|--|
| Channel width | Shows the value of the radio device's operating channel width. Note For dual-radio devices, the Channel width parameter is shown for each radio interface. |

Step 2 Search for any device using the mesh ID number, assigned device name, or the device's IP address.

Step 3 Or, filter the devices based on status such as **Critical**, **Warning**, **Disconnected**. Also, you can select the tabs for a quick view of the section.



- The **Critical** filter allows you to view the list of devices for which the thresholds are beyond the upper threshold limit.
- The **Warning** filter allows you to view the list of devices for which the thresholds are between the upper and lower threshold limits.
- The **Disconnected** filter allows you to view the devices which are disconnected from IW Monitor.

Viewing the Uplink and Downlink Information for a Device

Procedure

In the **More** column, click (...) of the device to view more detailed uplink and downlink information.

MONITOR

1.x-dev

Dashboard Table View Data Analysis Topology Log

ME Fluidmesh 10.115.11.64 5.1.79.77 8.6-rc10 Fixed Infra 5180 MHz 24 dBm 40 MHz ***

ME Trailer-8-A1-testAAA 10.115.11.63 5.0.180.16 9.4 Fluidity Infra 5825 MHz 23 dBm 20 MHz ***

Latency Jitter Installed plugins (12)

0.45 ms 19.38 ms FM-AES BW (30 Mbps) PMCL BW (UNLIMITED)

PTP BW (UNLIMITED) FM-L2TP FM-LF

FM-MOB FLUIDITY-MOB BW (UNLIMITED) FLUIDITY-TRK BW (60 Mbps)

FM-TITAN FM-UNII2 FM-VLAN

Device configuration page

Realtime links

| Link | Total Tpt. | Throughput | M.C.S. (rate) | L.E.R. | P.E.R. | RSSI |
|---|------------|---------------------|--|----------|----------|---------------|
| Trailer-8-A1-testAAA 10.115.11.63 → Cisco-0.180.19 5.0.180.19 | 0.03 Mbps | 0 Mbps 0.03 Mbps | 7/2 SGI 20 MHz (144 Mbps) 7/2 SGI 20 MHz (144 Mbps) | 0 % - | 0 % - | -60 dBm RX |

Frequency: 5825 MHz

Channel utilization breakdown

5.0.180.19 0.05 % TX free 99.95 % RX

Edge devices (18)

| | | | | | | | | | | |
|---------------|---------------|--------------|---------------|---------------|---------------|---------------|---------------|--------------|---------------|--------------|
| 10.115.11.92 | 10.115.11.55 | 10.115.11.60 | 10.115.11.115 | 10.115.11.174 | 10.115.11.230 | 10.115.11.81 | 10.115.11.176 | 10.115.11.87 | 192.168.10.92 | 10.115.11.80 |
| 10.115.11.147 | 10.115.11.158 | 10.115.11.1 | 10.115.11.111 | 10.115.11.160 | 10.115.11.159 | 10.115.11.180 | | | | |

1 - 7 1 >>

Following table describes each column with detailed explanation:

| Parameter | Description |
|--------------------------|---|
| Installed plugins | List of the software plug-ins currently installed on the device, and it is only applicable for the legacy Fluidmesh products. |
| License | Shows the device's license level and is applicable only for Catalyst IW9165, IW9167, and IEC-6400 gateway. The License level can be Essential , Advantage , or Premier . |
| Latency | Shows the current network latency (the delay period between data transmission by the IW Monitor host and reception of a reply by a radio device). The latency value is calculated as half of the round-trip time of the relevant packets. |
| Jitter | Shows the current amount of network jitter (the deviation from the true periodicity of periodic data signals in relation to a reference clock signal). |
| Link | Shows the two endpoints of the wireless link. |

Viewing the Uplink and Downlink Information for a Device

| Parameter | Description |
|--------------------------------------|--|
| Role | <p>Role designations are as follows:</p> <ul style="list-style-type: none"> • Fixed Infrastructure: The radio unit is part of a wired LAN based infrastructure. • Fluidity Infrastructure: The radio unit is part of a Fluidity network, and installed in a moving vehicle. • Fluidity Vehicle: The radio unit is part of a Fluidity network, and installed as part of a fixed infrastructure. |
| Total Throughput (Total Tpt.) | Shows the combined throughput rate per second for the uplink and downlink. |
| Throughput | Upper value shows the throughput rate per second for the downlink. The lower value shows the throughput rate per second for the uplink. |
| M.C.S. (Rate) | Shows the modulation and coding schema used by the relevant uplink or downlink. |
| L.E.R. | Shows the link error rate for the relevant uplink or downlink. |
| P.E.R. | Shows the packet error rate for the relevant uplink or downlink. |
| RSSI | Shows the received signal strength indication for the relevant uplink or downlink. |
| Channel utilization breakdown | <ul style="list-style-type: none"> • The total width of the bar represents the total bandwidth of the channel carrying the uplink and downlink. • The solid portion represents the portion of bandwidth currently being used to transmit data. • The striped portion represents the portion of bandwidth currently being used to receive data. • The gray portion represents the portion of bandwidth that is currently not utilized. • Numerical percentage readouts are also given for transmission, reception and non utilization. |
| Attached devices | This is a list of devices that are part of the section. |


Viewing Device Statistics in Real Time

IW Monitor has network statistics that allow you to view the network-related performance of any device in the current network. The statistical details for a device can be viewed in real-time as they occur. You can also view a performance graph that displays the device's previous performance on a historical timeline.

Procedure

Step 1 Click **Data Analysis**.

A new screen extends as shown below:



Step 2 For step 1: **TIME**, you can switch between real (live) and historical data for the data analysis.

a) To view statistics of a device for a particular period, select **History** tab.

From and **To** time fields and **Custom time range** field appears.

1. TIME

You can view historical or real-time data

Live

History

 Custom time range

Start date-time

19 / 01 / 2023

End date-time

20 / 01 / 2023

b) Select the date and time for both **From** and **To** fields.


Note

The selected duration can't be more than 1 hour.

Step 3 For step 2: **SEARCH DEVICE**, search for the device using the mesh ID number, assigned device name, or the device's IP address.


Step 4 For step 3: **ANALYSE**, click **Confirm**.

Viewing Device Statistics in Real Time



A real-time statistical view of the device appears. For **History** tab selection, a time slider for the chosen period also appears.

- The first graph shows received signal strengths of the device and other radio units that the device could potentially connect with:



- The upper left corner of the graph shows whether the device currently accepts handoff requests.
- If the chosen device is currently connected to a Fluidity-enabled (vehicle-mounted) radio unit, a thick, dashed black line is superimposed over the Fluidity device's RSSI line. This line is the RSSI envelope and represents the strongest available signal.


Note

In the right-hand section of the graph, devices to which the current device is connected are listed in descending order of received signal strength (RSSI).

- The Throughput graphs show the throughput statistics as a function of Mbps/time. The throughput is shown for the selected device and the device to which the chosen device is currently connected.

Note


The left graph shows uplink statistics (data flow from the current unit), while the right graph shows downlink statistics (data flow to the current unit).



- c. The LER / PER graphs shows the current link error and packet error rates (expressed in percentages over time) and the comparative signal modulation rates. LER and PER are shown for the selected device and the device to which the selected device is currently connected.

Note

The left graph shows uplink statistics (data flow from the current device), while the right graph shows downlink statistics (data flow to the current device).




- d. The graphs in the fourth row shows the modulation and coding schemas (MCS) for the selected device and the device to which the selected device is currently connected.

Note

The left graph shows uplink statistics (MCS of the current device), while the right graph shows downlink statistics (MCS of the unit to which the current device is connected).

- e. The upper left corner of the graph shows whether the device currently accepts handoff requests.

Viewing the Devices from Topology



Note

This graph is shown only for vehicles.

Step 5 Click **Edit** to view the statistical view for another device.

Viewing the Devices from Topology

Procedure

Step 1 Click  **Topology**.


A new screen appears with topology.



Step 2 Click on the device for more details.


Step 3 Click on the wireless link or a mobile unit.

A new screen appears as shown.



Step 4 Click on the Fluidity Vehicle Unit.

A new screen appears as shown.




Step 5 Click on **Web page** and it redirects to the respective web interface of the device.

Step 6 Click **Settings** to change the information displaying in the topology view:


a) In the **Appearance** tab, you can edit the following:

- **EDIT MODE**: The toggle button allows you to lock or unlock the position of any device on the topology map.
- **SHOW LINKS**: If the toggle button is enabled, the links not in use as routes are shown.
- **KPI VALUES ON ROUTES**: If the toggle button is enabled, the selected KPIs (**L.E.R**, **P.E.R**, **RSSI**, and **Link Utilization**) mentioned below will be shown for all wireless routes.
- **RESET TOPOLOGY SETTINGS**: Click **Clear Settings and reset view** to clear all the topology settings.


Viewing the Devices from Topology



b) In the **Layout** tab, you can choose a predefined template to set up the view based on the use case.




c) In the **Background** tab, you can customize the background of the topology view.



d) In the **Positioning** tab, you can choose between the two below options:


- **Automatic (hierarchy)** - Allows the devices to automatically positioned as a tree.
- **Coordinates (CSV file)** - You can upload a CSV file with the list of coordinates for each device (latitude and longitude). Then, position any two devices in the panel and all the other devices will be automatically positioned based on the geo coordinates in the CSV file.



Step 7 Click **Edit Mode** to change the topology view based on devices or background.

The following pop-up appears once you click on **Edit Mode**:


a) Click **Continue to Edit Mode**.



- In **Devices** view, you will see the devices.

Viewing the Devices from Topology

- In **Background** view, you can adjust the background scale and transparency to concentrate on a particular section of the topology view.



- Click **Save changes**.

Step 8

Click **Zoom** to zoom in/out the topology view.

Step 9

Enable MPO.

- Click **Settings** icon at the top right corner of the screen.
- Select **MPO > Enable MPO Processing**.
- Select **Time Window** and granularity. For example, 1 minute to 59 minutes and 1 hour to 24 hours.
- Click **Save Changes**.


Step 10

Enable MPO telemetry on both Mesh Ends and Fluidity. See the [Software Configuration Guide](#) to use the CLI commands.

Step 11

Click Fluidity Vehicle Unit in the topology.

If the MPO telemetry is not enabled, you see warning messages.



If MPO telemetry is enabled, you should see the following metrics:

| Metrics | Description |
|-----------------------------|---|
| Lost on Primary Path only | This metrics provides details about number of packets lost, or received out-of-order on the primary MPO path only, over the total number of packets sent on the primary path. |
| Received on alternate paths | This metrics provides details about the number of packets accepted on any of the MPO alternate paths over the number of packets sent on all the paths. |

Filtering and Viewing Network Events

Procedure

Step 1 Click  to view a log of network events for the current device.

A new screen extends as shown below:



Step 2 For step 1: Select the available time range options from the **Custom time range** drop-down list or set the start date and time and end date and time as required.

Step 3 For step 2: Click **Confirm**.

A log of network related events is shown for the chosen date/time range.

Filtering and Viewing Network Events

MONITOR v2.0

11/2/2023 - 15:51 to 11/2/2023 - 15:52

Events: All

Level: Info

Connected new edge devices
3:51:44 PM

New edge devices (IP addresses: 192.168.1.187) are attached to Fluidmesh device Cisco-81.161.152 - 192.168.1.10 / 5.81.161.152. Full list of edge devices connected to this Fluidmesh unit.

| IP Address | VLAN ID |
|---------------|---------|
| 192.168.1.120 | 0 |
| 192.168.1.103 | 0 |
| 192.168.1.191 | 0 |
| 192.168.1.102 | 0 |
| 192.168.1.187 | 0 |
| 192.168.1.194 | 0 |
| 192.168.1.104 | 0 |
| 192.168.1.105 | 0 |
| 192.168.1.172 | 0 |

Disconnected edge devices
3:51:39 PM

Edge devices (IP addresses: 192.168.1.187) are not attached anymore to Fluidmesh device Cisco-81.161.152 - 192.168.1.10 / 5.81.161.152. Full list of edge devices connected to this Fluidmesh unit.

Step 4 If required, click **Level** to choose the overall criticality level of the shown list of network events.

Level: All

Events: All

Critical Warning Info Trace

The levels are as below:

- **Critical** - Critical level events have an immediate, negative impact on system performance and/or system integrity, and must be addressed immediately.
- **Warning** - Warning level events have a potentially negative impact on system performance, and should be addressed as soon as practically possible.
- **Info** - Info level events are normal system events. This is the default event display level.
- **Trace** - Trace level events are considered trivial, but can be useful for diagnostic troubleshooting.

Note

Criticality levels are inclusive of the chosen level, and all levels below the chosen level. For example:

- If you select **Critical**, only **Critical** events are shown.
- If you select **Warning**, then **Critical** and **Warning** events are shown.
- If you select **Info**, then **Critical**, **Warning** and **Information** events are shown.
- If you select **Trace**, then **Critical**, **Warning**, **Information** and **Trace** events are shown.

Step 5 Choose the specific network event types as below:

- Click **Events**.

A pop-up appears.

b) In the pop-up, click the relevant category from left pane, and select the check-boxes for the required network event.
c) Click **Apply**.

All the specified network-related events are shown in descending chronological order (more recent events are shown at the top of the log).

d) (Optional) To clear the applied filters, click **Clear Filters**.
e) (Optional) To edit the time range of the log, click **Edit**.

The screenshot shows a left sidebar with a tree view of event categories and their selection status, and a right pane with a detailed list of RADIUS events and their checkboxes.

Left Sidebar (Event Categories):

- RADIUS events (8/8 selected)
- Network events/failures (12/12 selected)
- Titan (Fast-Failover) (6/6 selected)
- License management (4/4 selected)
- System (3/3 selected)
- Network performance (14/14 selected)
- Devices management (8/8 selected)
- Device Credentials (4/4 selected)
- Ethernet Port (2/2 selected)
- Database (9/9 selected)
- Settings (19/19 selected)
- Configuration changes (116/116 selected)
- Users account management (6/6 selected)

Right Pane (RADIUS Events):

- RADIUS configuration mismatch
- RADIUS failed authentication renewal
- RADIUS failed authentication
- RADIUS successful authentication
- RADIUS Authentication request
- RADIUS Mode Changed
- RADIUS authentication renewal request
- RADIUS successful authentication renewal

RADIUS events
Deselect all

Exporting a Network Event Log as a CSV File

Procedure

Step 1 Request the log of network events as mentioned in [Filtering and Viewing Network Events, on page 47](#).

Step 2 Click  [Export](#).

A **Export Log** pop-up appears.

Step 3 Check the date/time range shown in the **Export Log** pop-up, and click **Export**.

Step 4 Select the location in your computer to save the file.



CHAPTER 8

Configuring IW Monitor Database Settings

- [Defining Hard Disk Storage Capacity and Overwrite Cycle Period for the IW Monitor Statistics Database, on page 51](#)
- [Backing up the IW Monitor Statistics Database, on page 53](#)
- [Deleting the recent IW Monitor Statistics Data, on page 54](#)

Defining Hard Disk Storage Capacity and Overwrite Cycle Period for the IW Monitor Statistics Database

Procedure

Step 1 Click  **Settings** in the top right corner.

The database settings page is shown.

Defining Hard Disk Storage Capacity and Overwrite Cycle Period for the IW Monitor Statistics Database

The screenshot shows the IW Monitor Statistics Database configuration interface. The left sidebar has a dark blue header with the word 'MONITOR' and a 52edc7618 ID. Below it are several menu items: Dashboard, Table View, Data Analysis, Topology, and Log. The 'Database' item is selected and highlighted in blue. The main content area is titled 'Database' and contains the following configuration options:

- MAXIMUM DATABASE SIZE**: Set to 80 Gigabytes. A note says: 'MONITOR checks periodically that historical data are not exceeding maximum database size'. Below it, 'Current usage 0MB/80 GB' is shown.
- TIME THRESHOLD**: Set to 7 Days, 0 Hours. A note says: 'Least recent statistics and events in database are automatically cleaned by the application'. Below it, 'Maximum time threshold is 90 days' is shown.
- BACKUP DATABASE**: A note says: 'Backups allow you to share your data and keep a copy of your database.' A 'Backup' button is present.
- CLEAN OLDEST DATA**: A note says: 'Force cleaning of oldest statistics and events in database. Typically this is not necessary since it is automatic.' A 'Delete history' button is present.

At the bottom of the main panel, there is a button labeled 'Report MONITOR Issues' with an exclamation mark icon.

Step 2 Set the **MAXIMUM DATABASE SIZE** value manually.

The IW Monitor periodically checks the historical data is within this defined maximum database value.

Important

The allocated hard disk space cannot be less than the amount of currently occupied hard disk space or more than the hard disk's total capacity.

Note

If the amount of network statistics data currently stored on the hard disk reaches the specified value but is recorded over less than the time specified by the **TIME THRESHOLD** value, the IW Monitor will overwrite the old data with the new data in real-time.

It is highly recommended that you use a hard disk of at least 100 GB capacity for network statistics storage. If you must use a hard disk of less than 100 GB capacity, assign no more than 75% of the drive's free capacity to network statistics storage. IW Monitor may encounter performance issues if you assign more than this amount.

Step 3 Set the **TIME THRESHOLD** value manually.

The time threshold shows the time period for which network statistics are recorded before the old statistics data is overwritten.

Note


The minimum amount of time-related network-statistics data that can be stored before overwrite is one hour, and the maximum amount of time-related data that can be stored before overwrite is 90 days.

Backing up the IW Monitor Statistics Database

Procedure

Step 1 Click  **Settings** in the top right corner.

The database settings page is shown.



MONITOR
52edc7618

Dashboard Table View Data Analysis Topology Log

Database

MAXIMUM DATABASE SIZE
MONITOR checks periodically that historical data are not exceeding maximum database size

Gigabytes
80
Current usage 0MB/80 GB

TIME THRESHOLD
Least recent statistics and events in database are automatically cleaned by the application

Days
7
Hours
0
Maximum time threshold is 90 days

BACKUP DATABASE
Make a full copy of your database

Backups allow you to share your data and keep a copy of your database.

Backup

CLEAN OLDEST DATA
Force cleaning of oldest statistics and events in database. Typically this is not necessary since it is automatic.

A backup highly suggested before proceeding.
This will erase part of your data.

Delete history

Report MONITOR Issues

Step 2 In the **BACKUP DATABASE**, click **Backup**.

A confirmation pop-up appears.

Backup database



Choose an action before leaving this page

Are you sure you want to backup your database? The backup may take a while. Please, click **Backup** button to continue.

[Close](#)

[Backup](#)

Step 3 In the pop-up, click **Backup**.

Step 4 After successful backup, click **Download** to download the backup to your computer.

Deleting the recent IW Monitor Statistics Data

You can manually delete the oldest statistics and event data in the IW Monitor database if you feel that excessive amounts of network statistics data are being written to the hard disk in short periods of time.



Important It is strongly recommended that you back up the database before you delete the statistics data. If the current network statistics record is deleted, it cannot be retrieved. For more information on how to back up, see [Backing up the IW Monitor Statistics Database, on page 53](#).

Procedure

Step 1 Click **Settings** in the top right corner.

The database settings page is shown.

MAXIMUM DATABASE SIZE
MONITOR checks periodically that historical data are not exceeding maximum database size

TIME THRESHOLD
Least recent statistics and events in database are automatically cleaned by the application

BACKUP DATABASE
Make a full copy of your database

CLEAN OLDEST DATA
Force cleaning of oldest statistics and events in database. Typically this is not necessary since it is automatic.

MAXIMUM DATABASE SIZE
Gigabytes
80
Current usage 0MB/80 GB

TIME THRESHOLD
Days
7
Hours
0
Maximum time threshold is 90 days

BACKUP DATABASE
Backups allow you to share your data and keep a copy of your database.
[Backup](#)

CLEAN OLDEST DATA
A backup highly suggested before proceeding.
This will erase part of your data.
[Delete history](#)

Step 2 Click **Delete history**.

A confirmation pop-up appears.

Clean history

Choose an action before leaving this page

Are you sure you want to clean your oldest historical data? A backup is highly recommended before proceeding. This will erase your data.

[Close](#)

[Clean history](#)

Step 3 In the pop-up, click **Clean history**.

Note

The network statistics data is only deleted if the amount of stored data exceeds the thresholds set by the **MAXIMUM DATABASE SIZE** and/or the **TIME THRESHOLD**. In this case, the oldest 10% of the currently stored network statistics data will be deleted.

■ Deleting the recent IW Monitor Statistics Data



CHAPTER 9

Configuring IW Monitor Statistical Settings

- [Changing the Interval at which Statistical Data is Logged, on page 57](#)
- [Customizing Event-Logging Settings, on page 59](#)
- [Setting Performance Thresholds, on page 61](#)
- [Setting Performance Thresholds for Each Section, on page 62](#)

Changing the Interval at which Statistical Data is Logged

Procedure

Step 1 Click  **Settings** in the top right corner.

A new settings page is shown.

Step 2 Click  **Statistics**.

A new statistics settings page is shown.

Changing the Interval at which Statistical Data is Logged

SAMPLING PERIOD (FLUIDITY)
This period will be set for all Fluidity devices (both AP and vehicles). The lower the period you choose, the higher the storage you require

Very high High Standard
330ms 1s 5s

SAMPLING PERIOD (FIXED INFRASTRUCTURE)
This period will be set for all Fixed Infrastructure devices (Fluidity disabled).

Very high High Standard
330ms 1s 5s

UDP PACKET PERIOD
These packets are used to calculate end-to-end latency and jitter in your network.

Very high High Normal Off
100ms 1s 10s Never

ADVANCED DIAGNOSTIC DATA
Enable it if you need to record advanced fine-grained data for troubleshooting. This will require more storage.

Debug data is not recorded.

Step 3

To change the time interval at which statistical data is logged, click-and-drag the **SAMPLING PERIOD** (Fluidity devices) slider and/or the **SAMPLING PERIOD** (Fixed infrastructure) slider.

The recommended data-logging frequency intervals are:

- 330 ms (Fluidity)
- 5 s (Fixed)

Note

Logging data at a higher-than-normal frequency increases the rate at which the IW Monitor database occupies the hard disk space.

- Higher data-logging frequency gives a more detailed statistical log with less possibility of missed errors.
- Lower data-logging frequency uses less hard disk space.

Step 4

To collecting debugging data:

- Enable **ADVANCED DIAGNOSTIC DATA** to log debugging data for quicker and more advanced technical support.


ADVANCED DIAGNOSTIC DATA
Enable it if you need to record advanced fine-grained data for troubleshooting. This will require more storage.

Debug data is not recorded.

Step 5

To increase the accuracy with which the IW Monitor host calculates network latency and jitter:

- Click-and-drag the **UDP PACKET PERIOD** slider.



b) To disable the UDP packet transmission, click-and-drag the **UDP PACKET PERIOD** slider to **Off**.

The higher UDP packet frequency sampling gives more accurate latency and jitter readings, and the lower UDP packet frequency sampling helps reduce network congestion.

Note

The minimum interval at which UDP packets are sent is every 100 ms, and the maximum interval at which UDP packets are sent is every 10 s.

Customizing Event-Logging Settings

Procedure


Step 1 Click  **Settings** in the top right corner.

A new settings page is shown.


Step 2 Click  **Log**.

The log settings page is shown.

Step 3 Enable the **Log Storage** toggle.




Step 4 Enable the **Remote Syslog** to collect the system logs remotely.




A new screen with **Remote Syslog** settings appears.

a. Fill the remote syslog **server IP address**, **port**, and change the settings based on the requirement.

Customizing Event-Logging Settings



Step 5 Click-and-drag the LOGGING LEVEL slider based on the required logging level.



The four logging levels are:

- **Trace** - Trace-level events are considered trivial, but can be useful for diagnostic troubleshooting.
- **Info** - Info-level events are normal system events. This is the default event display level.
- **Warning** - Warning-level events are those that have a potentially negative impact on system performance, and should be addressed as soon as practically possible.
- **Critical** - Critical-level events are those that have an immediate, negative impact on system performance and/or system integrity, and should be addressed immediately.

Step 6 In the Event section, check and uncheck the type of events you want to log.

All network event types are grouped into one of the following categories:

- Users account management
- RADIUS events
- Devices credentials
- Network events/failures
- Settings
- Device management
- Configuration changes
- Network performance
- License management
- Database
- System
- Titan (Fast-Failover)
- Ethernet Port

Step 7 Click **Save Changes**.


Setting Performance Thresholds

Procedure

If you want to apply the same performance-alert thresholds to all sections that are part of the network, adjust the performance thresholds by doing the steps that follow:

Each performance threshold slider has two buttons that can be clicked and dragged.

- a) Click-and-drag the left-side button to set the lower performance threshold. If the relevant parameter falls below this threshold, the relevant **Status** icons will turn red.
- b) Click-and-drag the right-side button to set the upper performance threshold. If the relevant parameter falls below this threshold, the relevant **Status** icons will turn yellow.



If radio signal strength, link error rate, packet error rate or network latency drop below the specified levels, the **Status** icons of individual devices in the table view shows the relevant status.

Setting Performance Thresholds for Each Section

| Status | Label |
|--------|-----------------------|
| ME | Cisco |
| 1 - 1 | |
| Status | Label |
| MP | Cisco- 21.201.156 |
| ME | Cisco- prodstaging |

Setting Performance Thresholds for Each Section

To apply different performance thresholds to different sections of the network, follow these steps:

Procedure

- Step 1** Click  **Settings** in the top right corner.
A new settings page is shown.
- Step 2** Click .
The network KPI settings page is shown.
- Step 3** Enable the **PERFORMANCE CHECK** switch to **On**.
The default thresholds section is shown.
- Step 4** Make sure that the current network is partitioned into two or more sections. To know more on how to partition the network into sections, see [Create a new Section, on page 23](#).
- Step 5** If the network is partitioned, tabs are created for each network section under **Global Thresholds** sliders as shown below:

Set thresholds for specific sections by selecting a section below:

Tunnel-01

Trains-A1

Trains-A2

MAGNUM


Test

Step 6

Select the network section for which you want to alter the performance thresholds.

A separate group of performance-alert threshold sliders will be shown for the specified network section. For more information about thresholds, see [Setting Performance Thresholds, on page 61](#).

Trains-A1 (1 devices)



Step 7

Click-and-drag the sliders to adjust the performance-alert thresholds for the specified network.

Step 8

Repeat the steps above for all network sections.



CHAPTER 10

Managing User Accounts

You can update your details, access password, and also add other users to the IW Monitor.

- [Modifying an Existing User Account, on page 65](#)
- [Viewing, Adding, and Deleting Users, on page 66](#)

Modifying an Existing User Account

Procedure

Step 1 Click  **Settings** in the top right corner.

A new settings page is shown.

Step 2 Click  **Account**.

The user account settings page is shown.

Step 3 To change your first name and/or last name details, do the following steps:

- Update the **First name** and **Last name** fields as required.
- Click **Save Changes**.

Note

You cannot change the listed e-mail address using the user account settings page.

Step 4 To change your access password details, do the following steps:

- Enter your current access password in the **Current password** field.

Note

Passwords are case-sensitive.

- Enter the new access password in the **New password** field.

Note

The new passwords must be a minimum of eight characters, and must include at least one uppercase letter, one lowercase letter, and one digit.

c) Click **Save Changes**.

Viewing, Adding, and Deleting Users

Procedure

Step 1 Click  **Settings** in the top right corner.

A new settings page is shown.

Step 2 Click  **Account**.

The user account settings page with the list of existing user accounts is shown.

Step 3 To add a new user, do the following steps:

- Fill the new user's e-mail address in the **Email** field.
- Fill the new user's first name in the **First name** field.
- Fill the new user's last name in the **Last name** field.
- Select the user specific role in the **Role** dropdown field, either **Admin** or **Viewmode**.

- Admin: The user can perform all operations available in IW-MONITOR.
- Viewmode: The user has read-only access to IW-MONITOR.

Viewmode users do not have access to these operations:

- Create, edit, or delete sections
- Save time range in Data Analysis - History
- Update positions of the nodes in topology
- Update topology settings
- Update MONITOR settings
- Invite other users
- Upgrade MONITOR
- Attach new devices to MONITOR
- Detach devices from MONITOR

Note

The first user registered to IW-MONITOR through the wizard is assigned the Admin role only.

e) Confirm that the details are correct and click the  **Add**.

The new user will be added to the **Other users** list. The status of the new user listing will be shown as **Pending**.

Note

A random access password will be generated for the new user.

- f) Click  (eye icon) to view the generated password for the new user.
- g) Send the generated password to the new user. The system prompts the user to change the password when they log in for the first time.

Step 4

To delete a user, do the following steps:

- a) View the list of existing user accounts in the **Other users** section.
- b) Click on the **X** to the right of the user listing.

A **Remove User** pop-up appears for confirmation.

- c) Click **Remove**.

Reset a password for another user

Reset a user's password in case of security concerns or if the user forgets their password.

Before you begin

- Only Admin users can reset passwords for other users.

Procedure

Step 1 Navigate to **Settings > Account**.**Step 2** In the **Other Users** table, select the user whose password you want to reset.**Step 3** If the user does not have a temporary password, "reset" icon appears automatically, click on it.

Reset a password for another user

MONITOR v2.2

Dashboard Table View Data Analysis Topology Log

Database Statistics Network KPI MPO Account Log Customisation Devices Upgrade API documentation Report MONITOR Issues

CHANGE PASSWORD

Choose a new password

Current Password SHOW

New Password SHOW

Repeat New Password SHOW

Your new password has to be 12 characters minimum. It has to include at least one uppercase letter, one lowercase letter and one digit.

PASSWORD EXPIRATION SETTINGS

Password Expiration Policy Password expiration policy disabled.

PASSWORD REUSE SETTINGS

Password Reuse Policy Password Reuse policy disabled.

OTHER USERS

Add or remove users here. New user will have to use the one time password for their first login.

| Email | First name | Last name | Role | Status |
|---|---|--|---|---|
| viewmode@local.secure | bob | doe | View Mode | Pending   |
| admin@local.secure | alice | foo | Admin | Active   |
| <input type="text" value="name@email.com *"/> | <input type="text" value="First name *"/> | <input type="text" value="Last name *"/> | <input type="text" value="Role * Admin"/> |  |

Save changes

Step 4 Click **Confirm** to proceed.

The system generates a temporary secure password for the user.

Step 5 Provide the temporary password to the user.

Note

The temporary password does not expire.

Step 6 When the user logs in with the temporary password, they will be required to set a new password.



CHAPTER 11

Updating IW Monitor

- [Updating IW Monitor, on page 69](#)

Updating IW Monitor

For best performance, it is recommended that you always use the latest version of IW Monitor application. Updated versions may include new features, improved operation, and bug fixes.

Procedure

Step 1 To download the latest image file:

- Go to [software downloads](#).
- Download the latest IW Monitor image file (**iw-monitor-upgrade-toX.Y.Z.mon**).

Step 2 Log in to the IW Monitor.

Step 3 Click  **Settings** in the top right corner.
A new settings page is shown.

Step 4 Click  **Upgrade**.
The upgrade page is shown.

Step 5 Locate the correct image file on your computer or drag and drop the image file.

Drag and drop your .mon file or
[click here to manually select it from your machine.](#)

Note

The image files have an *.MON file extension.

The IW Monitor server initialization page opens and the IW Monitor application is updated.



CHAPTER 12

Uninstalling IW Monitor

- [Uninstalling IW Monitor, on page 71](#)

Uninstalling IW Monitor

Procedure

Step 1 Open a command-line window on the IW Monitor host.

Step 2 Enter the command: `docker ps -a`

The command-line interface shows the **CONTAINER_ID** value of the IW Monitor installation.

Step 3 Enter the command: `docker rm -f <CONTAINER_ID>`

The Docker container is removed from the IW Monitor host.

Step 4 Enter the command: `docker images`

The command-line interface shows the **IMAGE_ID** value of the IW Monitor Docker image.

Step 5 Enter the command: `docker rmi -f <IMAGE_ID>`

The IW Monitor Docker image is removed from the IW Monitor host.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2025 Cisco Systems, Inc. All rights reserved.

