



Device Initial Configuration in Provisioning Mode

- [Provisioning mode, on page 1](#)
- [How Provisioning mode works, on page 1](#)
- [Handling DHCP and IP Address in Provisioning mode, on page 2](#)
- [Configure fallback IP address using GUI, on page 2](#)
- [Configure fallback IP address using CLI, on page 3](#)
- [Configure the AP using GUI \(Offline\), on page 4](#)
- [Configure the AP using IW Service \(Online Cloud-Managed\), on page 4](#)
- [Verify the AP status using GUI, on page 5](#)
- [Verify the AP status using CLI, on page 6](#)
- [Verify DHCP connection status using CLI, on page 7](#)
- [LED behavior, on page 8](#)
- [Troubleshoot IW Service connectivity in Provisioning mode, on page 9](#)
- [Reset the Device to Factory Default using GUI, on page 9](#)
- [Reboot the Device using GUI, on page 11](#)
- [Save and restore the device settings, on page 11](#)
- [Configure general settings, on page 12](#)
- [Connect to the Access Point Console Port, on page 14](#)

Provisioning mode

From UIW Release 17.16.1, IoT OD IW is changed and called as IW Service. Catalyst IW access point (AP) running in URWB mode supports configuration either from:

- Online Cloud-Managed: configure the device using Industrial Wireless (IW) Service, or
- Offline: configure the device using local management interfaces (GUI or CLI).

By default, an AP with no configuration starts in Provisioning mode. In this mode, the IW Service provides the initial configuration.

How Provisioning mode works

In Provisioning mode, an AP attempts to request the network configuration using DHCP and then connects to the IW Service.

- If network connectivity exists, AP connects to the IW Service.
 - Configure AP using the IW Service: If the AP obtains network connectivity, it attempts to connect to IW Service. IW Service uses DNS geo-location to direct APs to the appropriate cluster (US or EU). Ensure your IW Service organization is configured to the correct cluster.
- If there is no network connectivity, AP can be configured locally. Local management can be accessible using the console port or SSH.
 - Configure AP using the Local configuration: If network connectivity is unavailable, the AP can be configured locally via GUI or CLI, accessible through the console port or SSH.

Use these default credentials to log either into the GUI or CLI:

- Username: Cisco
- Password: Cisco

Handling DHCP and IP Address in Provisioning mode

When the device is in Provisioning mode, it tries to get an IP address from DHCP. If this process fails or DHCP is unavailable, these options apply:

- If the device fails to receive an IP address through DHCP, it switches to the fallback IP address: 192.168.0.10/24.
- If DHCP is unavailable and configuration through IW Service is needed, then you can manually configure the IP address, subnet, default gateway, and DNS.



Note DHCP is used only during provisioning mode. For regular tasks, use a static IP address.

Configure fallback IP address using GUI

Perform this task to configure a fallback IP address that the device will use if it fails to obtain an IP address from the DHCP server. This ensures continued device operation in the absence of dynamic IP assignment.

Before you begin

The fallback IP address acts as a static IP address that the device defaults to when DHCP fails to assign one. This feature is critical for maintaining connectivity in scenarios where the DHCP server is unavailable.

Procedure

-
- Step 1** Launch the computer's web browser and enter the URL to open the URWB configurator login page.
- Step 2** Enter the username and password in the respective fields.

- Step 3** Click **Login**.
After successfully logging into the GUI, the URWB configurator page is displayed.
- Step 4** Click **IW Service** on the URWB configurator page and navigate to **Configure DHCP to connect to IW Service** section.
- Step 5** Enter the appropriate IP addresses in the respective fields:

- Fallback Local
- Local Netmask
- Default Gateway
- Local Primary DNS
- Local Secondary DNS

Configure DHCP to connect to IW Service

Use this section to connect the radio to the Internet via DHCP to use IW Service Cloud Management. Set fallback IP settings if DHCP is not available.

DHCP fall-back configuration

Local IP:

Local Netmask:

Default Gateway:

Local Dns 1:

Local Dns 2:

Save fallback IP

- Step 6** Click **Save fallback IP** to complete the configuration.

Configure fallback IP address using CLI

Before you begin

When an AP fails to obtain an IP address from a DHCP server, it reverts to a pre-configured fallback IP address.

Procedure

Perform this task to configure fallback IP address on the AP.

Use the `configure ap address ipv4 static IP address static netmask IP address of gateway dns1 ip IP address dns2 ip IP address` command to configure fallback IP address on the device.

```
Device#configure ap address ipv4 [ static IP address [ static netmask [ IP address of default gateway
[ dns1 ip [ dns2 ip ] ] ] ] ]
```

Example:

```
Device#configure ap address ipv4 static 192.168.10.2 255.255.255.0 192.168.10.1 192.168.10.200  
192.168.10.201
```

Configure the AP using GUI (Offline)

Procedure

- Step 1** Launch the computer's web browser and enter the URL to open the URWB configurator login page.
 - Step 2** Enter the username and password in their respective fields.
 - Step 3** Click **Login**.
After successfully logging into the GUI, the URWB configurator page is displayed.
 - Step 4** Click **IW Service**.
IW Service Configuration Mode page appears.
 - Step 5** Select **Offline**.
The device exits from Provisioning mode and switch to Fallback IP address.
-

Configure the AP using IW Service (Online Cloud-Managed)

This task explains how to configure the access point in online cloud-managed mode through the IW Service. This mode allows the device to be managed from the IW Service cloud server if connected to the internet.

Procedure

- Step 1** Launch the computer's web browser and enter the URL to open the URWB configurator login page.
- Step 2** Enter the username and password in their respective fields.
- Step 3** Click **Login**.
After successfully logging into the GUI, the URWB configurator page is displayed.
- Step 4** Click **IW Service**.
IW Service Configuration Mode page appears.
- Step 5** By default, the device is shown as Online Cloud-Managed.
The device can be managed from IW Service cloud server (if it is connected to the internet). The device exits Provisioning mode only if the user pushes the configuration from IW service or switches to offline mode.

Cisco URWB IW9165E Configurator
5.81.160.148 - MESH POINT MODE

IW Service Cloud-Managed
IW Monitor Enabled

GENERAL SETTINGS

- general mode
- wireless radio
- antenna alignment and stats

NETWORK CONTROL

- advanced tools

ADVANCED SETTINGS

- advanced radio settings
- static routes
- allowlist / blocklist
- snmp
- radius
- ntp
- ethernet filter
- l2tp configuration
- vlan settings
- Fluidity
- misc settings

MANAGEMENT SETTINGS

- remote access
- status
- reboot
- logout

IW Service Management

IW Service Configuration Mode

Provisioning: This is the initial configuration phase. The access point is configured using IW Service ([Industrial Wireless \(IW\) Service US](#), [Industrial Wireless \(IW\) Service EU](#)) if connected successfully or locally if *Offline* mode is selected.

Offline Configuration: This mode allows for location configuration changes locally using the access point WebUI (this interface) or CLI. Configuration is also possible by downloading a single-file configuration from IW Service ([Industrial Wireless \(IW\) Service US](#), [Industrial Wireless \(IW\) Service EU](#)).

Online Cloud-Managed Configuration: in this mode the access point is configured using IW Service ([Industrial Wireless \(IW\) Service US](#) or [Industrial Wireless \(IW\) Service EU](#)). The local WebUI and CLI are read-only.

☒ Online Cloud-Managed ☐ Offline

IW Service Cloud connection info

Server Host:	Industrial Wireless Service
Status:	Connected
Cluster Config:	auto

Current IP Configuration


Current IP:	10.58.58.55
Current Netmask:	255.255.255.0

The device exits provisioning mode only when the configuration is pushed from IW Service or the mode is switched to offline.

Verify the AP status using GUI


Procedure

- Step 1** Launch the computer's web browser and enter the URL to open the URWB configurator login page.
- Step 2** Enter the username and password in their respective fields.
- Step 3** Click **Login**.
After successfully logging into the GUI, the URWB configurator page is displayed.
- Provisioning mode




- Device configurator in connected status

If the connection to IW Service is successful, status is shown as **Connected**.



- Device configurator in disconnected status.


If the connection to IW Service is failed, status is shown as **Disconnected**.



- Offline mode



- Online cloud-managed



Verify the AP status using CLI

Use this task to verify the current operational status of an AP within the URWB configurator.

Procedure

Use the `show iw-service status` command to verify the status of the device.

```
Device#show iw-service status
```

Example:

- Device in Provisioning mode

```
Device#show iw-service status
```

```
IW Service mode: Provisioning
```

```
Status: Connected
```

- Device in Offline mode

```
Device#show iw-service status
```

```
IW Service mode: Offline
```

- Device in Online Cloud-Managed

```
Device#show iw-service status
```

```
IW Service mode: Online Cloud-Managed
```

```
Status: Connected
```

Verify DHCP connection status using CLI

Procedure

Step 1

This CLI example shows that the device is in provisioning mode and retrieved the IP address from the DHCP server:

Use the `show ip` to view the status of DHCP.

- Example: DHCP Success

```
Device#show ip
```

```
IP: 192.168.0.10
```

```
Network: 255.255.255.0
```

```
Gateway:
```

```
Nameservers:
```

```

DHCP Address (PROVISIONING Mode):

IP: 10.0.0.2

Network: 255.255.255.0

Gateway: 10.0.0.1

Nameservers: 8.8.8.8

Fallback Address (PROVISIONING Mode):

IP: 169.254.201.72

Network: 255.255.0.0

```

Step 2

This CLI example shows the device is in provisioning mode fails to retrieve the IP address from the DHCP server and then device uses the default fallback IP address 192.168.0.10:

Use the `show ip` to view the status of DHCP.

- Example: DHCP Failure (uses default Fallback IP)

```

Device#show ip

IP: 192.168.0.10

Network: 255.255.255.0

Gateway:

Nameservers:

DHCP Address (PROVISIONING Mode):

IP: 192.168.0.10

Network: 255.255.255.0

Gateway:

Nameservers: 127.0.0.1

Fallback Address (PROVISIONING Mode):

IP: 169.254.201.72

Network: 255.255.0.0

```

LED behavior

The device's status LEDs blink continuously in a repeating cycle until the device enters a fallback condition, online cloud-managed mode, or offline mode. Refer to ["LED Pattern for Catalyst IW9165"](#) or ["LED Pattern for Catalyst IW9167"](#) for specific LED patterns.

Troubleshoot IW Service connectivity in Provisioning mode

If the device fails to connect to IW Service, try these steps:

Procedure

-
- Step 1** Physical Connection: Verify the Ethernet cable is correctly connected.
- Step 2** DNS Resolution: Ensures
- device.ciscoiot.com
 - us.ciscoiot.com
 - eu.ciscoiot.com
- Step 3** Outbound HTTPS: Confirm the access point allows outbound HTTPS connections on tcp/443 for the domains listed in step2.
- Step 4** Local Configuration: If IW Service remains offline, perform a local (offline) configuration using the device's configurator interface.
-

Reset the Device to Factory Default using GUI

You can reset the device to factory default either by pressing a reset button for 30 seconds when power is supplied to the access point or through configurator interface. For more information about reset button, see [Using the Reset Button](#).



Note A hard reset reverts all device configuration settings, including the device IP address and administrator password to factory defaults. Instead if you want to reboot the device, see [Reboot the Device using GUI, on page 11](#).

1. In the **MANAGEMENT SETTINGS**, click **reset factory default**.

Reset the Device to Factory Default using GUI

The screenshot shows the Cisco URWB IW9165E Configurator web interface. The top header includes the Cisco logo and the text "Cisco URWB IW9165E Configurator 5.81.160.244 - MESH POINT MODE". On the left sidebar, there are sections for "IOTOD IW" (Offline) and "IW-MONITOR" (Disabled), followed by a list of settings categories: GENERAL SETTINGS, NETWORK CONTROL, ADVANCED SETTINGS, and MANAGEMENT SETTINGS. The main content area displays a confirmation dialog: "Are you sure you want to reset to factory default settings?" with two buttons: "NO" and "YES".

2. Click **YES** in the confirmation pop-up window. To abort the factory reset, click **NO**.
3. If you have previously saved a configuration file for the device, you can restore the saved configuration settings to the device, see [Save and restore the device settings, on page 11](#).



Note Do not perform a hard reset unless the device requires reconfiguration using its factory configuration as the starting point. Hard reset resets the device's IP address, administrator password, and it disconnects the device from the network.

Reset the Device to Factory Default using CLI

To reset of the device configuration, use the following CLI command:

```
device#configure factory reset config
WARNING: "configure factory reset config" will clear config and reboot.
Do you want to proceed? (y/n)
```

Enter **y** in the CLI command to start the device reset process or alternatively enter **n** to abort the process.

To reset the device configuration and data wipe, use the following CLI command:

```
Device#configure factory reset default
WARNING: "configure factory reset default" will take minutes to perform DATA WIPE.
```

The following files are cleared as part of this process:

- 1) Config, Bak config files
- 2) Crashfiles
- 3) syslogs
- 4) Boot variables

```

5) Pktlogs
6) Manually created files
Do you want to proceed? (y/n)


```

Enter `y` in the CLI command to start the device reset of the configuration and data wipe or alternatively enter `n` to abort the process.

Reboot the Device using GUI

To reboot the device's operating system, follow these steps:

1. In the **MANAGEMENT SETTINGS**, click **reboot**.



2. In the confirmation pop-up window, click **Yes**. To abort the reboot, click **No**.

Reboot the Device using CLI

To perform reboot, use the following CLI command:

```

Device#reload
Proceed with reload command (cold)? [confirm]

```

Enter `confirm` in the CLI command to start the device reboot process.

Save and restore the device settings

The **LOAD OR RESTORE SETTINGS** window allows you to perform the following tasks:

- Save the device's existing software configuration as a configuration (*.conf) file.
- Upload and apply a saved configuration file to the current device.



Note Device software configuration (*.conf) files are not interchangeable with IoT OD configuration setup (*.iwconf) files.




Tip Saved configuration files are reused for all devices of the same type. These saved configuration files act as configuration backup files to speed up redeployment if you need to replace the damaged device with a new device of the same type.

To download the device's existing configuration settings to your computer, follow these steps:

1. In the **MANAGEMENT SETTINGS**, click **configuration settings**.

The **LOAD OR RESTORE SETTINGS** window appears.



2. Click **Save** to download the device configuration (*.conf).

To upload a saved configuration file to the device, follow these steps:

1. Click **Browse** to upload the configuration (*.conf) file to the device.
2. Click **Restore** to apply the configuration settings to the device.

Configure general settings

To change the **General Mode** settings, follow these steps:

1. In the **GENERAL SETTINGS**, click **general mode**.

The screenshot shows the Cisco IOT IWB IW-MONITOR interface. The top header includes the Cisco logo and the text 'Cisco URWB IW9165E Configurator 5.81.160.244 - MESH POINT MODE'. The left sidebar contains a menu with categories like 'GENERAL SETTINGS', 'NETWORK CONTROL', 'ADVANCED SETTINGS', and 'MANAGEMENT SETTINGS'. The main content area is titled 'GENERAL MODE' and contains a 'General Mode' section with a radio button selection for 'mesh point' (selected), 'mesh end', and 'gateway'. Below this is a 'Radio-off' checkbox. The 'LAN Parameters' section includes input fields for 'Local IP' (10.115.11.180), 'Local Netmask' (255.255.255.0), 'Default Gateway' (10.115.11.1), 'Local Dns 1' (8.8.8.8), and 'Local Dns 2'. At the bottom of the form are 'Reset' and 'Save' buttons.

The **General Mode** has the operational mode controls. Devices capable of operating in a mesh radio network are shipped in **mesh point** mode.



Note

When designing the required network layout, there must be at least one mesh end device. This device performs control and administrative functions, such as license management. This is necessary for correct network operation, even if the network consists of only two devices.

To change the device's operational mode, select any one of the following mode:

- **Gateway** - This mode is applicable for advanced Layer 3 mobility deployments, and it is not used in most networks.
- **Mesh Point** - This mode is applicable for the remaining access points in the network. These access points establish links to other access points with the same network passphrase configured as mesh end or mesh point using wireless links or wired links. In this scenario, the access point has Layer 2 visibility of other access points.
- **Mesh End** - This mode configures the access point to perform control and administrative network functions. There must be at least one mesh end in each network. This access point is typically installed in the most central point where the wireless and wired networks converge.

Configure general settings using CLI

To configure general settings, use the following CLI command:

```
Device#configure modeconfig mode
gateway layer 3 global gateway mode
meshend mesh end mode
meshpoint mesh point mode
```

```
Device#configure modeconfig mode meshend
mpls          MPLS support
radio-off     disable radio interfaces
```

Change the LAN parameters

The LAN parameters has entry controls for local address setting. Perform the following to change the LAN parameters:

1. Once the **General Mode** window is opened for the first time, the **Local IP** and **Local Netmask** LAN parameters are shown with factory-set default values.
2. If needed, enter the local primary DNS address in the **Dns 1** field, and enter the local secondary DNS address in the **Dns 2** field.
3. Click **Save** to save the LAN settings. To clear the settings, click **Reset**.

Configure LAN parameters using CLI

To configure LAN parameters, use the following CLI command:

Example:

```
device#configure ip address ipv4 static
192.168.10.2 255.255.255.0 192.168.10.1 192.168.10.200 192.168.10.201
```

Connect to the Access Point Console Port

To configure the access point locally (without connecting to a wired LAN), connect the computer to the access point's console port using a DB-9 to RJ-45 serial cable and to open the CLI by connecting to the access point's console port, follow these steps:

1. Connect a nine-pin, female DB-9 to RJ-45 serial cable to the RJ-45 serial port on the access point and to the COM port on a computer.
2. Set up a terminal emulator to communicate with the access point. In the terminal emulator, use the following settings:

Parameter	Value
Baud rate	115200 bps
Data	Eight bits
Parity	No
Stop	One stop bit
Flow Control	No

3. There are two available command-prompt modes: standard command prompt (>) and privileged command prompt (#). When logged in for the first time, it directs you to standard command prompt (>) mode to execute unprivileged commands.

To access privileged command-prompt (#) mode, enter the enable command (abbreviated as en) and enter the enable password (the privilege mode login password is different from the standard login password).

Use these default credentials to log in:

- Username: Cisco
- Password: Cisco



Note Once the initial configuration completes, ensure to remove the serial cable from the access point.
