Ripristino di SD-WAN vSmart e vBond Access

Sommario

Introduzione Prerequisiti Requisiti Componenti usati Problema Soluzione Passaggio 1. Sbloccare le credenziali, se necessario Opzione A. Sblocco delle credenziali dalla GUI vManage Opzione B. SSH sul dispositivo che ha configurato una credenziale aggiuntiva Passaggio 2. Ripristino dell'accesso con un modello CLI Opzione A. Caricare la configurazione in esecuzione direttamente nel modello CLI Opzione B. Caricamento della configurazione dal database vManage Passaggio 3. Nuove credenziali Opzione A. Modifica della password persa Opzione B. Aggiungere un nuovo nome utente e password con privilegi Netadmin Passaggio 4. Push del modello sul dispositivo

Introduzione

Questo documento descrive come recuperare l'accesso SD-WAN vSmart e vBond dopo la perdita delle credenziali.

Prerequisiti

Requisiti

Nessun requisito specifico previsto per questo documento.

Componenti usati

Il documento può essere consultato per tutte le versioni software o hardware.

Le informazioni discusse in questo documento fanno riferimento a dispositivi usati in uno specifico ambiente di emulazione. Su tutti i dispositivi menzionati nel documento la configurazione è stata ripristinata ai valori predefiniti. Se la rete è operativa, valutare attentamente eventuali conseguenze derivanti dall'uso dei comandi.

Problema

L'accesso a vBonds e vSmarts è stato perso. Ciò si verifica quando non si conoscono o si ricordano le credenziali oppure quando l'accesso viene bloccato dopo un numero eccessivo di

tentativi di accesso non riusciti a entrambe le interfacce. Allo stesso tempo, le connessioni di controllo tra vManage, vSmarts e vBonds sono ancora stabilite.

Soluzione

Passaggio 1. Sbloccare le credenziali, se necessario

Questa procedura consente di identificare un nome utente bloccato e di sbloccarlo.

 Se l'account è stato bloccato a causa di un numero eccessivo di tentativi di accesso non riusciti, è possibile visualizzare il messaggio 'Account bloccato a causa di X accessi non riusciti' ogni volta che si digita il nome utente.

host:~pc-host\$ ssh admin@172.18.121.104 -p 22255 viptela 20.6.3									
(admin@172.18.121.105) Account locked due to 6 failed loging	5 <<<								
😑 💿 👘 🦉 Keyboard Interactive Authentication									
Keyboard Interactive prompt for admin@172.18.121.104.	ОК								
Account locked due to 6 failed logins Password:	Cancel								

Opzione A. Sblocco delle credenziali dalla GUI vManage

Dopo aver confermato che le credenziali sono bloccate, è necessario sbloccarle. vManage consente di eseguire facilmente questa operazione.

• Èpossibile sbloccare manualmente le credenziali dall'interfaccia grafica di vManage per qualsiasi dispositivo.

Selezionare vManage > Tools > Operational Commands > Device > ... > Reset Locked User > Select User > Reset

0 :	Select Resource	Group+		Tools · Open	ational Comma	ands					0 0
									Show	Admin Tech Li	ist
											∇
anage			· .								
									Tota	I Rows: 6 😧	0
P	Device Model	Chassis Number/ID	State	Reachability	Site ID	BFD	Control	Version	Up Since	Device Grc	
	vManage	f1310071-c808-47aa-bd11	8-22 🔘	reachable	10		1	20.6.4	18 Oct 2022 1:49:00 PM CDT	No groups +-	
	vSmart	13fafb25-b8c1-4083-835d	-27 💿	reachable	10		1	20.6.4	18 Oct 2022 1:51:00 PM CDT	No groups ++	
	vEdge Cloud (v8	5006354P-7055-4954-804		rescholde	10			20.64	18 Oct 2022 1:50:00 PM CDT	No groups +-	
	vEdge Cloud	668841a2 Rese	et Lock	ked User				×	17 Sep 2022 7:44:00 AM CDT	No groups	
	vEdge Cloud	764ca17c							17 Sep 2022 7:45:00 AM CDT	No groups	
	vEdge Cloud	671fe279- Usen ad	imin •						17 Sep 2022 7:46:00 AM CDT	No groups ++	
					Reset		Cancel				
			_			_		_			

Opzione B. SSH sul dispositivo che ha configurato una credenziale aggiuntiva

Se si dispone di una connettività SSH con una credenziale Netadmin aggiuntiva nel dispositivo in cui si conferma che le credenziali bloccate sono, è comunque possibile sbloccarle dalla CLI.

• Èpossibile eseguire il comando:

request aaa unlock-user username

 Se le credenziali sono state sbloccate e l'accesso non riesce, è necessario modificare la password.

Passaggio 2. Ripristino dell'accesso con un modello CLI

Ènecessario creare i modelli CLI che consentono di modificare la password dei dispositivi. Se un modello CLI è già stato creato e associato al dispositivo, è possibile andare al passo 3.

Opzione A. Caricare la configurazione in esecuzione direttamente nel modello CLI

vManage consente di caricare facilmente la configurazione in esecuzione dai dispositivi nel modello CLI.

Nota: questa opzione non può essere disponibile in base alla versione di vManage. È possibile esaminare l'opzione B.

Crea un nuovo modello CLI

Selezionare vManage > Configuration > Templates > Create Template > CLI template

Cisco vManage	O Select Reso	ource Gro	sup.+		Cont	figuration · Template	5				\bigcirc	Ξ	0	4
					•	vice Feature								
Q. Search													5	7
Create Template ~ From Feature Template CLI Template										Tota	il Rows: 2	2	ø	۲
Name .	Description	Type	Device Model	Device Role	Resource Group	Feature Templates	Draft Mode	Devices Attached	Updated By	Last Updated	Ter	mpla		

• In base al modello di dispositivo selezionato, è possibile scegliere tra quale dispositivo vManage carica la configurazione in esecuzione.



• Per creare il modello, è necessario immettere i valori Modello dispositivo, Nome modello e Descrizione.

■ Cisco vManage	Select Resource Group+	Configuration · Template	2S		\bigcirc	≡ ⊘ ¢		
		Device Feature						
Device Model	vSmart ~							
Template Name	vSmart_recover_password							
Description New CLI template to recover password								
CLI Configuration Load Running config from reachable device: 3.3.3.1 - vSmart1 🗸 Q. Search (x) Create Variable 🔒 Encrypt Type6 🗎 Select a File								
Config Preview								
2 host-name 3 system-tp 4 site-id 5 admin-tech-name 7 organization-name 8 clock timezone Ameri 9 vbond 172.18.121.104 10 aua 11 auth-order loo 12 usergroup basic 13 task interface rec 14 task interface rec 15 ! 16 usergroup basic 17 task system read 18 usergroup netadmin 17 ! 18 usergroup netadmin 18 usergroup netadmin 17 task system read 20 task interface rec 21 task security read 23 task security read 24 task security read 25 usergroup tenantad 26 i 27 user admin 28 password \$6\$75f482 29 !	vSmart1 'e yy (carretatt port 32595 cal radius tacacs id id id it in its i825de4ada305b/9R340279MjxutEyihgKUU/CIA7mAH4dPN34	R5y90eYMIRX1E . F422QsJdLKZYKntaVkL fmySSPbpQz . 98kMn/	7					

• Non appena la configurazione viene generata nel modello CLI, è possibile rivedere il passo 4 per modificare la password.

Opzione B. Caricamento della configurazione dal database vManage

Nel caso in cui non sia possibile caricare la configurazione automaticamente nella CLI, è comunque possibile ottenere manualmente la configurazione del dispositivo e creare il modello CLI da tali informazioni.

• vManage dispone sempre di una configurazione di backup da tutti i dispositivi archiviati nel relativo database.

Selezionare vManage>Configuration>Controllers>Device> ... >Running Configuration vManage>Configuration>Controllers>Device> ... >Local Configuration.

Nota: esecuzione rispetto alla configurazione locale. Se si esegue Configuration, vManage deve richiedere le informazioni di configurazione per il dispositivo. Configurazione locale

indica che vManage visualizza le informazioni già archiviate nel relativo database.

• Dopo la visualizzazione della configurazione locale, è possibile copiare l'intera configurazione in un Blocco note.

Local Configuration

no confg system - system - no route-consistency-check no route-consistency-check no route-consistency-check no route-consistency-check no route-consistency-check cock timezone - America/Detroit vecong anization - name clock timezone - America/Detroit vecong posite clock timezone - America/Detroit vecong posite vecong posite clock timezone - America/Det	
config system	no config
system ip bost-name system ip alle-id admin-tech-on-failure no route-consistency-check no no vrrp.adv.with-phymac organization-name CISCORTPLAB clock timezone America/Detroit vbond 192.168,25195 local aas auth-order local radius tacacs usergroup basic task system read task interface read usergroup operator task system read task interface read task interface read task sinterface read task suiter read task suiter read task souting read task s	config
host-name system-ip system-ip site-id admin-tech-on-failure no route-consistency-check no vrp-advt-with-phymac organization-name organization-name organization-name organization-name cliscottime.cone dramet.cone organization-name cliscottime.cone aaa auth-order local radius tacacs usergroup basic task system read task interface read ! usergroup operator task system read task interface read ! usergroup tenantadmin ! usergroup tenantadmin ! usergroup tenantadmin ! usergroup tenantadmin ! usergroup tenantadmin ! usergroup tenantadmin ! usergroup tenantadmin ! usergroup tenantadmin ! usergroup tenantadmin ! usergroup tenantadmin ! isototacrw-user true ! logging disk enable	system
syster-id 1 site-id 1 site	host-name
she d 1 admin-tech-on-failure no rotute-consistency-check no vrm-advt-with-phymac organization-name CISCORTPLAB clock timezone America/Detroit vbond 192.168.25.195 local asa auth-order local radius tacacs usergroup basic task system read task interface read ! usergroup netadmin ! usergroup netadmin ! usergroup netadmin ! usergroup tenantadmin ! usergroup tenantadm	system-ip
admin-tech-on-failure no route-consistency-check	site-id 1
no route-consistency-check no vrrp-advt-with-phymac organization-name clock timezone America/Detroit vbond 192.168.25.195 local aaa auth-order local radius tacacs usergroup basic task system read task interface read ! usergroup perator task system read task interface read task interface read task system read task socurity read ! usergroup tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d,IX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! cliscotacrv-user true cliscotacrv-user true cliscotacrw-user true i logging disk enable	admin-tech-on-failure
no vrp-advt-with-phymac organization-name CISCORTPLAB clock timesca/Detroit vbond 192.168.25.195 local aaa auth-order local radius tacacs usergroup basic task system read task interface read ! usergroup petadmin ! usergroup petador task system read task interface read task system read task system read task system read task security read ! usergroup tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d,IX4JV66yFKaYfcWTJPQO0qRIU79FbPd80 ! ciscotacro-user true ciscotacrw-user true isotacrw-user true ciscotacrw-user true isotacrw-user true isotacrw-user true inp np math parent no enable	no route-consistency-check
organization-name CISCORTPLAB clock timezone America/Detroit vbond 192:168.25.195 local asa auth-order local radius tacacs usergroup basic task system read task interface read ! usergroup operator task system read task interface read task interface read task system rea	no vrrp-advt-with-phymac
<pre>clock timezone America/Detroit vbond 192.168.25.195 local aaa auth-order local radius tacacs usergroup basic task system read task interface read ! usergroup operator task system read task interface read task system read task interface read task system read</pre>	organization-name CISCORTPLAB
vbond 192.168.25.195 local aaa auth-order local radius tacacs usergroup basic task system read task interface read ! usergroup operator task system read task netrace read task netrace read task noting read task noting read task noting read task socuting read task secuting read task secutin	clock timezone America/Detroit
aaa auth-order local radius tacacs usergroup basic task system read task interface read ! usergroup netadmin ! usergroup netadmin ! usergroup operator task system read task notify read task notify read task sourity read ! usergroup tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d,JX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ciscotacrw-user true logging disk enable ! ntp parent no enable	vbond 192.168.25.195 local
auth-order local radius tacacs usergroup basic task system read task interface read ! usergroup operator task system read task interface read task policy read task notting read task notting read task security read ! usergroup tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ciscotacro-user true ciscotacro-user true i logging disk enable ! ntp parent ncp	888
usergroup basic task system read task interface read ! usergroup perator task system read task interface read task interface read task interface read task interface read task routing read task socurity read ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.JX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ciscotacrw-user true ! logging disk enable ! ntp parent ncp nable	auth-order local radius tacacs
task system read task interface read ! usergroup netadmin ! usergroup operator task system read task interface read task interface read task policy read task scutting read task security read ! user group tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! clscotacro-user true clscotacro-user true clscotacro-user true l logging disk enable ! ! ntp parent nce nable	usergroup basic
task interface read usergroup netadmin usergroup operator task system read task system read task system read task interface read task notifice read task routing read task routing read task security read usergroup tenantadmin user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ciscotacro-user true ciscotacrw-user true logging disk enable l l ntp parent no enable	task system read
! usergroup netadmin ! usergroup operator task system read task system read task interface read task policy read task security read ! usergroup tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d,jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ciscotacro-user true !	task interface read
usergroup netadmin ! usergroup operator task system read task interface read task interface read task policy read task security read ! usergroup tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ciscotacrw-user true ! logging disk enable ! ntp parent nc enable	
I usergroup operator task system read task interface read task interface read task policy read task routing read task security read I usergroup tenantadmin I user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 I ciscotacro-user true ciscotacrw-user true I logging disk enable I I parent no enable	usergroup netadmin
usergroup operator task system read task interface read task policy read task policy read task security read ! usergroup tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ciscotacro-user true ciscotacrw-user true ! logging disk enable ! ntp parent no enable	1
task system read task interface read task policy read task policy read task security read ! usergroup tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ciscotacrw-user true ! logging disk enable ! ! ntp parent no enable	usergroup operator
task interface read task policy read task policy read task security read task security read ! usergroup tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ciscotacro-user true ! logging disk enable ! ! ntp parent no enable	task system read
task policy read task routing read task security read ! usergroup tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ciscotacrw-user true ! logging disk enable ! ! ntp parent no enable	task interface read
task routing read task security read ! usergroup tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ciscotacro-user true iscotacrw-user true ! logging disk enable ! ! ntp parent no enable	task policy read
task security read ! usergroup tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! clscotacro-user true clscotacrw-user true ! logging dlsk enable ! I ntp parent no enable	task routing read
! usergroup tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ciscotacrw-user true ! logging disk enable ! ntp parent no enable	task security read
usergroup tenantadmin ! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d,jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ciscotacrw-user true ! logging disk enable ! t ntp parent no enable	1
! user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ciscotacrw-user true ! logging disk enable ! ntp parent no enable	usergroup tenantadmin
user admin password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ciscotacrw-user true ! logging disk enable ! ntp parent no enable	!
password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80 ! ciscotacro-user true ! logging disk enable ! ! ntp parent no enable	user admin
! ciscotacro-user true ciscotacrw-user true ! logging disk enable ! ntp parent no enable	password \$6\$9d6a880c2a69979f\$D1ag5jX.F279uqaRDxFNbCMICBy7hoWIFpd5Etp.AsYR7Taelc9d.jX4jV66yFKaYfcWTJPQO0qRiU79FbPd80
ciscotacro-user true ciscotacrw-user true ! logging disk enable ! ! ntp parent no enable	!
ciscotacrw-user true	ciscotacro-user true
! logging disk enable ! ! ntp parent no enable	ciscotacrw-user true
logging disk enable ! ! ntp parent no enable	1
disk enable ! ! ntp parent no enable	logging
enable ! ! ntp parent no enable	disk
! Intp parent no enable	enable
! ntp parent no enable	1
ntp parent no enable	
parent no enable	ntp
no enable	parent
	no enable

• ènecessario creare un nuovo modello CLI.

Passare a vManage>Configuration>Templates>Create Template>CLI template (Configurazione>Modelli>Crea modello>Modello CLI).

E Cisco vManage	() Select Res	ource Gro	- 10		Com	Inguration · Templat	**			0	5 =	0	0
						Testure							
Q. Seath												2	7
Create Template v From Foulure Template QU Template										Total R	ant 2	0	•
Name a	Description	1,04	Denice Model	Device Role	Resource Group	Pearlure Templates	Dolt-Mode	Onlos Attached	Updated By	Les append	lanyis		

 Per creare il modello, è necessario immettere i valori Modello dispositivo, Nome modello, Descrizione e Anteprima configurazione. La configurazione copiata dalla configurazione locale deve essere incollata nell'anteprima della configurazione.

Attenzione: per vBond è necessario selezionare vEdge cloud. Ogni altro dispositivo ha il proprio modello specifico.

Device	Model	vEdge Cloud v	1		
Templa	te Name	vBond_recover_password			
Descrip	tion	vBond with new password			
CLI Con	figuration			Load Running config from reachable device:	- Select -
Config F	Preview				
1	system				
4	nost-name				
2	system-1p				
4	admin_tach_on_fail	1170			
6	no noute-consister	cu-check			
7	no vern-adut-with	nhumac			
8	organization-name	CISCORTPLAR			
9	clock timezone Ame	rica/Detroit			
10	vbond 192, 168, 25, 1	195 local			
11	000				
12	auth-order 1	local radius tacacs			
13	usergroup basic				
14	task system read	1			
15	task interface r	read			
16	1				
17	usergroup netadmi	in			
18	!				
19	usergroup operato	or .			
20	task system read	1			
21	task interface r	read			
23	task policy read	a d			
24	task security re	ad			
25	1				
26	usergroup tenanta	admin			
27	1				
28	user admin				
29	password \$659d6d	1880c2a69979f \$ D1ag5jX.F279uqaRD	XFNbCMICBy7hoWIFpd	SEtp.AstR/Taelc9d.jX4jV66yFKatfcWTJPQ00qR	LU79FbPd80
30	i ciscotocro-usor t	710			
32	ciscotacrw-user t	rue			
33	1				
34	logging				
35	disk				
36	enable				
37	1				
38	!				
39	ntp				
40	parent				
41	no endble				
42	evit				
44	server ntp.esl.ci	sco.com			
45	source-interface				
46	vpn	0			
47	version	4			
48	exit				
49	1				
50	1				
51	omp				

Passaggio 3. Nuove credenziali

Dopo aver creato il modello, è possibile sostituire la password crittografata o aggiungere nuove credenziali.

Opzione A. Modifica della password persa

Èpossibile modificare la configurazione per assicurarsi di utilizzare una password nota.

• Èpossibile evidenziare e sostituire la password crittografata con una password in testo normale.

27	!
28	user admin
29	password Cisc0123
30	1

Nota: questa password in testo normale viene crittografata dopo il push del modello.

Opzione B. Aggiungere un nuovo nome utente e password con privilegi Netadmin

Se le modifiche alla password non sono consentite, è possibile aggiungere nuove credenziali per garantire l'accessibilità.



user newusername < Creates username password password < Creates the password group netadmin < Assigns read-write privileges

• Fare clic su Add per salvare il modello.

Passaggio 4. Push del modello sul dispositivo

Il passaggio successivo consiste nel spingere il modello CLI sul dispositivo per modificare la configurazione in esecuzione.

• Dopo aver salvato il modello, è possibile collegarlo al dispositivo.

Cisco vMana	ge 🔿 Sele	ct Resou	irce Group+			Configuration · Ten	nplates				⊜ ₫	0	0
						Cevice Feature							
Q. Search												1	\overline{V}
Create Template ~ Template Type Non-De	fault v										Total Rows: 1	ø	6
Name	Description	Type	Device Model	Device Role	Resource Group	Feature Templates	Draft Mode	Devices Attached	Updated By	Last Updated	Template Status	_	Ĩ
vBond_recover_passwor	d vBond with ne	CU	vEdge Cloud		global	0	Disabled	0	admin	19 Oct 2022 12:	In Sync		

Passare a vManage>Configuration>Templates> Select the Template>... >Select the device > Attach (vManage>Configurazione>Modelli> Selezionare il modello >... >Selezionare il dispositivo > Connetti).

Attach Devices

Attach device from the list bel	low					1 Items Selected
Available Devices		Select All	Selected Devices			Select All
All	Q Search	V	All	• Q Sea	rch	∇
Name	Device IP		Name		Device IP	
e8bbd848-ba58-f432-7df1 eb051e95-42e3-7112-ddd ec3066f8-2392-a036-94e1 f1fad728-c2a5-4824-749a- f97c57d8-f6ae-bb65-4154	-a3a39113ac15 9-4a9c8b48e3ca -07d644ea662d -22fa99c57602 -6e836b9d10e0					
Minimum allowed: 1						
					Attach	Cancel

- Fare clic su Attach (Allega) per esaminare l'anteprima della configurazione.
- Se si seleziona l'opzione di configurazione Diff, è possibile verificare se la password è stata modificata o se sono state aggiunte nuove credenziali.

Cisco vManage	0.8	Select He	Source Group • Configuration • Templates		0 2 0 4
vBond_recover_password	Total 1	Config P	Contig Dat		Inline Diff Intent
Device list (Total: 1 devices)			Local Configuration		New Configuration
Fitter/Search		1	system	1	system
50003348-1955-4256-594e- trodis4e45190 vbond_20,8,412.2.2.1		2 3 4 5 6 9 9 00 11 12 13 14 15 15 15 15 15 10 17 18 19 20 21 22 22 23 24	host-mame system-ip: site-id admin-tech-on-failure no route-consistency-check no vorp-advi-with-phymac sp-organisation-mame CISCONTPLAB organisation-mame CISCONTPLAB clock timezone Americs/Detroit vbond 192.164.25.155 local port 12346 ama awth-order local radius tacaes usergroup basic task system read task interface read task interface read task interface read task interface read task interface read task policy read	2 3 4 5 6 7 8 9 9 10 10 11 12 13 14 15 15 16 15 16 10 20 21 22 22 22 23 24	host-name system-ip site-id admin-tech-on-falure no route-consistency-check no vroute-consistency-check no vroute-detruith-physec sp-organisation-name CISCONTPLAB organisation-name CISCONTPLAB clock timescome America/Detroit vbood 192.164.25.155 local port 12346 ame awth-order local radius tacaes usergroup basic task system read task interface read 1 usergroup operator task interface read task interface read
		25 26 27 28 29 30	task security read I usergroup tenastadnin I user admin passwood 545546a880c2a65939fDD1ag5jX.T279vqaRDxFNBCKDCByThoWIFyd5Exp. AryRrTselc9d.jX4jV66yFKaYfcWTJFQ00qRiUT9FDed80	25 26 27 28 29 30 31	taxk security read I usergroup tenantadmin I user admin password 445464x880c2x45975f101xg5jx.r275uqx8DxFNbCRICBy7heMIPpdSEty Av%7Fbacls4ujx4jv46yrKarfcWZUPQ00q81073Fbadd0 I
		31	1 ciscotarro-user true	32 33 34 35 36	user admin-2 password Cinc0123 group metadmin 1 ciscolarre-user true
		33 34 35 36 37	disotary-user true 1 logging dist enable	37 38 29 40 41	elsoptarw-user true 1 logging disk enable
Configure Device Rollback Time	۰ I.				

- Per eseguire il push del modello, fare clic su Configura dispositivi.
- Dopo la conferma da parte di vManage del completamento del push di Ttemplate, è possibile usare le nuove credenziali per accedere al dispositivo tramite SSH.

Informazioni su questa traduzione

Cisco ha tradotto questo documento utilizzando una combinazione di tecnologie automatiche e umane per offrire ai nostri utenti in tutto il mondo contenuti di supporto nella propria lingua. Si noti che anche la migliore traduzione automatica non sarà mai accurata come quella fornita da un traduttore professionista. Cisco Systems, Inc. non si assume alcuna responsabilità per l'accuratezza di queste traduzioni e consiglia di consultare sempre il documento originale in inglese (disponibile al link fornito).