# Configurazione del clustering FTD su FP9300 (all'interno dello chassis)

## Sommario

Introduzione **Prerequisiti** Requisiti Componenti usati Pre<u>messe</u> **Configurazione** Esempio di rete Task 1. Creazione delle interfacce necessarie per il cluster FTD Attività 2. Creazione del cluster FTD Attività 3. Registra cluster FTD in FMC Attività 4. Configurazione delle sottointerfacce porta-canale su FMC Attività 5. Verifica della connettività di base Acquisizione cluster dall'interfaccia utente di Gestione chassis Attività 6. Eliminare un dispositivo slave dal cluster Verifica Risoluzione dei problemi Informazioni correlate

## Introduzione

In questo documento viene descritto come configurare e verificare la funzionalità cluster sul dispositivo FPR9300.

**Attenzione:** Le informazioni fornite in questo documento riguardano l'installazione/configurazione iniziale del cluster. Questo documento non è applicabile alla procedura di sostituzione di un'unità (autorizzazione restituzione materiale - RMA)

## Prerequisiti

#### Requisiti

Nessun requisito specifico previsto per questo documento.

#### Componenti usati

Le informazioni fornite in questo documento si basano sulle seguenti versioni software e hardware:

- Appliance di sicurezza Cisco Firepower 9300 con 1.1(4.95)
- Firepower Threat Defense (FTD) con versione 6.0.1 (build 1213)
- FireSIGHT Management Center (FMC) con versione 6.0.1.1 (build 1023)

Ora di completamento del laboratorio: 1 ora.

Le informazioni discusse in questo documento fanno riferimento a dispositivi usati in uno specifico ambiente di emulazione. Su tutti i dispositivi menzionati nel documento la configurazione è stata ripristinata ai valori predefiniti. Se la rete è operativa, valutare attentamente eventuali conseguenze derivanti dall'uso dei comandi.

#### Premesse

- Sull'accessorio FPR9300 con FTD è possibile configurare il clustering all'interno dello chassis su tutte le versioni supportate.
- Il clustering tra chassis è stato introdotto nella versione 6.2.
- Port-channel 48 viene creato come collegamento di controllo del cluster. Per il clustering all'interno dello chassis, questo collegamento utilizza il backplane Firepower 9300 per le comunicazioni cluster.
- Le singole interfacce dati non sono supportate, ad eccezione dell'interfaccia di gestione.
- L'interfaccia di gestione è assegnata a tutte le unità nel cluster.

## Configurazione

#### Esempio di rete



## Task 1. Creazione delle interfacce necessarie per il cluster FTD

Attività richiesta:

Creare un cluster, un'interfaccia di gestione e un'interfaccia dati del canale della porta.

Soluzione:

Passaggio 1. Creare un'interfaccia dati del canale della porta.

Per creare una nuova interfaccia, è necessario accedere a FPR9300 Chassis Manager e passare alla scheda **Interfacce**.

Selezionare Add Port Channel e creare una nuova interfaccia Port Channel con questi parametri:

ID canale porta	5
Тіро	Dati
Attiva	Sì
ID membro	Ethernet 1/3, Ethernet 1/4

Selezionare OK per salvare la configurazione come mostrato nell'immagine.

Add Port Channel		? X
Port Channel ID: 5	C Enable	
Type: Data	▼	
Speed: 1gbps	▼	
Interfaces		
Available Interface	Member ID	
Search	Ethernet1/3	
Ethernet1/2	Ethernet1/4	
Ethernet1/3		
Ethernet1/4		
Ethernet1/5		
Ethernet1/6		
Ethernet1/7	Add Interface	
Ethernet1/8		
Ethernet2/1		
Ethernet2/2		
Ethernet2/3		
Ethernet2/4		
Ethernet3/1		
Ethernet3/2		
		_
	OK Cancel	

Passaggio 2. Creare un'interfaccia di gestione.

Nella scheda **Interfacce**, scegliere l'interfaccia, fare clic su **Modifica** e configurare l'interfaccia del tipo di gestione.

Fare clic su **OK** per salvare la configurazione come mostrato nell'immagine.

Edit Interface - Ethernet1/1				
Name:	Ethernet1/1 ZEnable			
Type:	mgmt	*		
Speed: 1gbps		*		
	OK Car	ncel		

Passaggio 3. Creare un'interfaccia di collegamento di controllo del cluster.

Fare clic sul pulsante **Add Port Channel** e creare una nuova Port Channel Interface con questi parametri e come mostrato nell'immagine.

ID canale porta	48
Tipo	Cluster
Attiva	Sì
ID membro	-

Add Port Cha	annel				? ×
Port Channel ID:	48	Enable			
Type:	Cluster	•			
Speed:	1gbps 👻	•	1.00		
Interfaces					
Av	ailable Interface		Member ID		
	Search	]			
	Ethernet1/2				
	Ethernet1/5				
	Ethernet1/6				
	Ethernet1/7				
	Ethernet1/8				
	Ethernet2/1	Add Interface			
	Ethernet2/2				
	Ethernet2/3				
	Ethernet2/4				
	Ethernet3/1				
	Ethernet3/2				
	Ethernet3/3				
	Ethernet3/4				
				ОК	Cancel

## Attività 2. Creazione del cluster FTD

Attività richiesta:

Creare un'unità cluster FTD.

Soluzione:

Passaggio 1. Passare a Logical Devices e fare clic sul pulsante Add Device.

Creare il clustering FTD nel modo seguente:

Nome dispositivo	FTD_cluster
Modello	Cisco Firepower Threat Defense
Versione immagine	6.0.1.1213
Modalità periferica	Cluster

Per aggiungere la periferica, fare clic su OK, come mostrato nell'immagine.

Add Device			?×
Device Name:	FTD_cluster		
Template:	Cisco Firepower Threat Defense	~	
Image Version:	6.0.1.1213	~	
Device Mode:	🔵 Standalone 💿 Cluster		
	ОК		Cancel

Passaggio 2. Configurare e distribuire il cluster FTD.

Dopo aver creato un dispositivo FTD, si viene reindirizzati alla finestra Provisioning-nome\_dispositivo.

Fare clic sull'icona del dispositivo per avviare la configurazione come mostrato nell'immagine.

0	verview	Interfaces Log	ical Devices	Security Mor	ules Platform Settings					System Tools	Help av	ámin
e l	rovisionin ustered   (	g - FTD_cluster Cisco Firepower 1	hreat Defense	6.0.1.1213						Save	Canosi	
D	ata Ports	-										
1	Ethernet1/2											
10	Ethernet1/S											
10	Ethernet1/6						C		<u></u>			
0	Ethernet1/7											
	Ethernet1/8											
	Ethernet2/1											
	Ethernet2/2						FTD - 6.0.	1.1213				
	Ethernet2/3						Security Mod	ule 1,2,3				
	Ethernet2/4											
	Ethernet3/2								J			
	Ethernet3/3											
	Ethernet3/4											
	Port-channel5											
				_								_
	Security I	todule Applic	ation	Version	Management IP	Gateway	Management Port	Status				
1	Security M	odule 1 FTD		6.0.1.1213								
a	Security M	odule 2 FTD		6.0.1.1213								
a	Security M	odule 3 PTD		6.0.1.1213								

Configurare la scheda **Informazioni cluster** FTD con queste impostazioni e come mostrato nell'immagine.

Chiave cluster	cisco
Nome gruppo cluster	FTD_cluster
Interfaccia di gestione	Ethernet 1/1

Cisco Firepower Thre	Cisco Firepower Threat Defense - Configuration 🔹				
Cluster Information Setti	ngs Interface Information Agreement				
Security Module(SM)					
Security Module-1,Security M	Iodule-2,Security Module-3				
Interface Information					
Cluster Key:					
Cluster Group Name:	FTD_cluster				
Management Interface:	Ethernet1/1				
	OK Cancel				

Configurare la scheda Impostazioni FTD con queste impostazioni e come mostrato nell'immagine.

Chiave di registrazione	cisco
Password	Admin123
IP di Firepower Management	10 62 148 73
Center	10.02.140.75
Cerca domini	cisco.com
Modalità firewall	Stesura
Server DNS	173.38.200.100
Nome host completo	ksec-fpr9k-1-1-3.cisco.com
Interfaccia eventi	Nessuna

Cisco Firepower Threat Defense - Configuration			
Cluster Information Settings	Interface Information	Agreement	
Registration Key:	••••		
Password:	•••••		
Firepower Management Center IP:	10.62.148.73		
Search domains:	cisco.com		
Firewall Mode:	Routed	~	
DNS Servers:	173.38.200.100		
Fully Qualified Hostname:	ksec-fpr9k-1-1-3.cisco.co	m	
Eventing Interface:	None	~	
		_	
	ОК	Cancel	

Configurare la scheda **Informazioni interfaccia** FTD con queste impostazioni e come mostrato nell'immagine.

Tipo di indirizzo	Solo IPv4
Modulo di sicurezza 1	
IP di gestione	10.62.148.67
Network mask	255.255.255.128
Gateway	10.62.148.1
Modulo di sicurezza 2	
IP di gestione	10.62.148.68
Network mask	255.255.255.128
Gateway	10.62.148.1
Modulo di sicurezza 3	
IP di gestione	10.62.148.69
Network mask	255.255.255.128
Gateway	10.62.148.1

Cisco Firepower Threat Defense - Configuration					
Cluster Information Settings	Interface Information Agreement				
Address Type:	IPv4 only				
Security Module 1					
Management IP:	10.62.148.67				
Network Mask:	255.255.255.128				
Gateway:	10.62.148.1				
Security Module 2					
Management IP:	10.62.148.68				
Network Mask:	255.255.255.128				
Gateway:	10.62.148.1				
Security Module 3					
Management IP:	10.62.148.69				
Network Mask:	255.255.255.128				
Gateway:	10.62.148.1				
	OK Cancel				

Accettare il contratto nella scheda Contratto e fare clic su OK, come illustrato nell'immagine.

Cisco Firepower Threat Defense - Configuration 2
End User License Agreement
IMPORTANT: PLEASE READ THIS END USER LICENSE AGREEMENT CAREFULLY. IT IS VERY IMPORTANT THAT YOU CHECK THAT YOU ARE PURCHASING CISCO SOFTWARE OR EQUIPMENT FROM AN APPROVED SOURCE AND THAT YOU, OR THE ENTITY YOU REPRESENT (COLLECTIVELY, THE "CUSTOMER") HAVE BEEN REGISTERED AS THE END USER FOR THE PURPOSES OF THIS CISCO END USER LICENSE AGREEMENT. IF YOU ARE NOT REGISTERED AS THE END USER YOU HAVE NO LICENSE TO USE THE SOFTWARE AND THE LIMITED WARRANTY IN THIS END USER LICENSE AGREEMENT DOES NOT APPLY. ASSUMING YOU HAVE PURCHASED FROM AN APPROVED SOURCE, DOWNLOADING, INSTALLING OR USING CISCO OR CISCO-SUPPLIED SOFTWARE CONSTITUTES ACCEPTANCE OF THIS AGREEMENT.
CISCO SYSTEMS, INC. OR ITS SUBSIDIARY LICENSING THE SOFTWARE INSTEAD OF CISCO SYSTEMS, INC. ("CISCO") IS WILLING TO LICENSE THIS SOFTWARE TO YOU ONLY UPON THE CONDITION THAT YOU PURCHASED THE SOFTWARE
✓ I understand and accept the agreement
OK Cancel

Passaggio 3. Assegnare le interfacce dati a FTD.

Espandere l'area Porte dati e fare clic su ciascuna interfaccia che si desidera assegnare a FTD. Al termine, selezionare **Salva** per creare un cluster FTD come mostrato nell'immagine.

c	verview Interfaces	Logical Device	Security Modules Pla	tform Settings				System Tools	Help admin
P	rovisioning - FTD_clu lustered   Cisco Firep	uster power Threat Defens	se   6.0.1.1213					Save	Cancel
D	ata Ports								1
	Ethernet1/7								
I,	Ethernet1/8								
IJ	Ethernet2/1								
II,	Ethernet2/2								
ļ	Ethernet2/3			Port- channel5		_			
II.	Ethernet2/4	_1							
ŀ	Ethernet3/1					FTD - 6.0.1	.1213		
ŀ	Ethernet3/2	_				Security Mod	ie 1,2,3		
ŀ	Ethernet3/3	-1		channel48					
	EthernetJy4	-1							
	Port-channel%								
2									
	Security Module	Application	Version	Management IP	Gateway	Management Port	Status		
	Security Module 1	FTD	6.0.1.1213	10.62.148.67	10.62.148.1	Ethernet1/1			
	Cluster Interfaces:	Port-channel48							
	Security Module 2	FTD	6.0.1.1213	10.62.148.68	10.62.148.1	Ethernet1/1			
	Cluster Interfaces:	Port-channel48							
۲	Security Module 3	FTD	6.0.1.1213	10.62.148.69	10.62.148.1	Ethernet1/1			
	Cluster Interfaces:	Port-channel48							

Attendere alcuni minuti prima di distribuire il cluster, dopodiché verrà eseguita la scelta dell'unità

master.

Verifica:

#### • Dalla GUI dell'FPR9300 come mostrato nell'immagine.

0	verview Interface	Logical Devi	ces Security Modu	les Platform Settings				System Tools Help admin
								C Refresh O Add Device
	FTD_cluster	Clustered	Status: ok					/% 🥒 B 🕈
	Security Module	Application	Version	Management IP	Gateway	Management Port	Status	
6	Security Module 1	FTD	6.0.1.1213	10.62.148.67	10.62.148.1	Ethernet1/1	online	Enabled 🕘 🍌
	Ports: Data Interfaces Cluster Interfac	: Port-channel5 es: Port-channel4	3	Attributes: Cluster Operational Si Firepower Managemen Cluster Role Management URL, UUID	atus : in-cluster tt IP : 10.62.148.67 ; primary : https://10.62.148.73/ ; b2a42bba-5da0-11e6-	sf1e-efdb62t3esb1		
6	Security Module 2	FTD	6.0.1.1213	10.62.148.68	10.62.148.1	Ethernet1/1	Online	(Endled 🕒 🏞
	Ports: Data Interfaces Cluster Interfac	: Port-channel5 es: Port-channel4	3	Attributes: Cluster Operational Si Firepower Managemes Cluster Role Management URL UUID	atus : in-cluster It IP : 10.62.148.68 ; secondary : https://10.62.148.73/ : b2c13764-5da0-11e6-	1795-e46a69506c19		
8	Security Module 3	FTD	6.0.1.1213	10.62.148.69	10.62.148.1	Ethernet1/1	online	(Enabled 🕒 🍌
	Ports: Data Interfaces Cluster Interfac	: Port-channel5 es: Port-channel4i	1	Attributes: Cluster Operational Si Firepower Managemen Cluster Role Management URL UUID	atus : in-cluster nt IP : 10.62.148.69 : secondary : ?#tps://10.62.148.73/ : beb5ca66-5da0-11e6-	2866-05061616340		

#### • Dalla CLI di FPR9300

FPR9K-1-A# FPR9K-1-A# <b>scope ssa</b> FPR9K-1-A /ssa # <b>show app-instance</b>								
Application Name	Slot ID	Admin State	Operational State	Running Version	Startup			
Version Cluster Oper	State							
ftd	1	Enabled	Online	6.0.1.1213	6.0.1.1213			
In Cluster								
ftd	2	Enabled	Online	6.0.1.1213	6.0.1.1213			
In Cluster								
ftd	3	Enabled	Online	6.0.1.1213	6.0.1.1213			
In Cluster								

• Dalla CLI di LINA (ASA)

#### firepower# show cluster info

Cluster FTD\_cluster: On Interface mode: spanned This is "unit-1-1" in state MASTER ID : 0 Version : 9.6(1)Serial No.: FLM19216KK6 CCL IP : 127.2.1.1 CCL MAC : 0015.c500.016f Last join : 21:51:03 CEST Aug 8 2016 Last leave: N/A Other members in the cluster: Unit "unit-1-3" in state SLAVE ID : 1 Version : 9.6(1) Serial No.: FLM19206H7T CCL IP : 127.2.1.3 CCL MAC : 0015.c500.018f Last join : 21:51:05 CEST Aug 8 2016

Last leave: N/A Unit "unit-1-2" in state SLAVE ID : 2 Version : 9.6(1) Serial No.: FLM19206H71 : 127.2.1.2 CCL IP CCL MAC : 0015.c500.019f Last join : 21:51:30 CEST Aug 8 2016 Last leave: N/A firepower# cluster exec show cluster interface-mode cluster interface-mode spanned cluster interface-mode spanned cluster interface-mode spanned firepower# firepower# cluster exec show cluster history \_\_\_\_\_ To State From State Reason \_\_\_\_\_ 21:49:25 CEST Aug 8 2016 DISABLED DISABLED Disabled at startup 21:50:18 CEST Aug 8 2016 Enabled from CLI DISABLED ELECTION 21:51:03 CEST Aug 8 2016 ELECTION MASTER\_POST\_CONFIG Enabled from CLI 21:51:03 CEST Aug 8 2016 MASTER\_POST\_CONFIG MASTER Master post config done and waiting for ntfy \_\_\_\_\_ \_\_\_\_\_ To State From State Reason \_\_\_\_\_ 21:49:44 CEST Aug 8 2016 DISABLED DISABLED Disabled at startup 21:50:37 CEST Aug 8 2016 DISABLED ELECTION Enabled from CLI 21:50:37 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:50:41 CEST Aug 8 2016 Received cluster control message ONCALL ELECTION 21:50:41 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:50:46 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message

21:50:46 CEST Aug 8 2016 ELECTION Received cluster control message ONCALL 21:50:51 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:50:51 CEST Aug 8 2016 ELECTION Received cluster control message ONCALL 21:50:56 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:50:56 CEST Aug 8 2016 ELECTION Received cluster control message ONCALL 21:51:01 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:51:01 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:51:04 CEST Aug 8 2016 ONCALL SLAVE\_COLD Received cluster control message 21:51:04 CEST Aug 8 2016 SLAVE\_COLD SLAVE\_APP\_SYNC Client progression done 21:51:05 CEST Aug 8 2016 SLAVE CONFIG Slave application configuration sync done SLAVE\_APP\_SYNC 21:51:17 CEST Aug 8 2016 SLAVE\_CONFIG SLAVE\_BULK\_SYNC Configuration replication finished 21:51:29 CEST Aug 8 2016 SLAVE\_BULK\_SYNC SLAVE Configuration replication finished \_\_\_\_\_ \_\_\_\_\_ To State Reason From State 21:49:24 CEST Aug 8 2016 DISABLED DISABLED Disabled at startup 21:50:16 CEST Aug 8 2016 DISABLED ELECTION Enabled from CLI 21:50:17 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:50:21 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:50:21 CEST Aug 8 2016 ELECTION Received cluster control message ONCALL 21:50:26 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:50:26 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message

21:50:31 CEST Aug 8 2016 Received cluster control message ONCALL ELECTION 21:50:31 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:50:36 CEST Aug 8 2016 Received cluster control message ONCALL ELECTION 21:50:36 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:50:41 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:50:41 CEST Aug 8 2016 ELECTION Received cluster control message ONCALL 21:50:46 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:50:46 CEST Aug 8 2016 ELECTION Received cluster control message ONCALL 21:50:51 CEST Aug 8 2016 ONCALL Received cluster control message ELECTION 21:50:51 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:50:56 CEST Aug 8 2016 ONCALL Received cluster control message ELECTION 21:50:56 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:51:01 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:51:01 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:51:06 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:51:06 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:51:12 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message 21:51:12 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:51:17 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:51:17 CEST Aug 8 2016 ELECTION ONCALL Received cluster control message 21:51:22 CEST Aug 8 2016 ONCALL ELECTION Received cluster control message

21:51:22 CEST Aug 8 2016

```
ELECTION
                 ONCALL
                                   Received cluster control message
21:51:27 CEST Aug 8 2016
                                  Received cluster control message
ONCALL
                ELECTION
21:51:27 CEST Aug 8 2016
                           Received cluster control message
ELECTION
                ONCALL
21:51:30 CEST Aug 8 2016
ONCALL
                SLAVE_COLD
                             Received cluster control message
21:51:30 CEST Aug 8 2016
                SLAVE_APP_SYNC
SLAVE_COLD
                                  Client progression done
21:51:31 CEST Aug 8 2016
SLAVE_APP_SYNC SLAVE_CONFIG Slave application configuration sync done
21:51:43 CEST Aug 8 2016
SLAVE_CONFIG
                SLAVE_BULK_SYNC Configuration replication finished
21:51:55 CEST Aug 8 2016
SLAVE_BULK_SYNC SLAVE
                                     Configuration replication finished
```

firepower#

## Attività 3. Registra cluster FTD in FMC

Attività richiesta:

Aggiungere le periferiche logiche al FMC e quindi raggrupparle in un cluster.

\_\_\_\_\_

Soluzione:

Passaggio 1. Aggiungere dispositivi logici al CCP. A partire dalla versione 6.3 di FMC, è necessario registrare un solo dispositivo FTD (si consiglia di utilizzarlo come dispositivo master). Gli altri FTD vengono rilevati automaticamente dal FMC.

Accedere al FMC e selezionare **Devices > Device Management**, quindi fare clic su **Add Device** (Aggiungi dispositivo).

Aggiungere la prima periferica logica con le impostazioni indicate nell'immagine.

Fare clic su Register (Registrati) per avviare la registrazione.

Add Device		?)	×	
Host:	10.62.148.67			
Display Name:	FTD1			
Registration Key:	cisco			
Group:	None	~		
Access Control Policy:	FTD9300	~		
Smart Licensing Malware:				
URL Filtering:				
Advanced				
On version 5.4 devices or earlier, the licensing options will need to be specified from licensing page.				
	Register Cano	el		

La verifica è come mostrato nell'immagine.

Cisco Firepower 9000 Series SM-36 Threat Defense Cluster			/ 8
FTD1(primary) 10.62.148.67 - Cisco Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed	Cisco Firepower 9000 Series SM-36 Thre Base, Threat, Malware, URL Filtering	FTD9300	
PTD2 10.62.148.68 - Cisco Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed	Cisco Firepower 9000 Series SM-36 Thre Base, Threat, Malware, URL Filtering	FTD9300	÷.
FTD3 10.62.148.69 - Cisco Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed	Cisco Firepower 9000 Series SM-36 Thre Base, Threat, Malware, URL Filtering	FTD9300	8

## Attività 4. Configurazione delle sottointerfacce porta-canale su FMC

Attività richiesta:

Configurare le sottointerfacce per l'interfaccia dati del canale porta.

Soluzione:

Passaggio 1. Dall'interfaccia utente di FMC, selezionare il pulsante FTD\_cluster Edit.

Passare alla scheda Interfacce e fare clic su **Add Interfaces > Sub Interface** come mostrato nell'immagine.

Overview Analysis Policies Devi	ces Objects AMP			Deploy 🧕	System Help 🛪 olga 🛪
Device Management NAT VPN	Platform Settings				
FTD_cluster					Seve Cancel
Cisco Firepower 9000 Series SM-36 Threat Defer	se				
Cluster Devices Routing NA	Totorfaces Inline Sets	DHCP			
2					Add Interfaces •
Interface	Logical Name	Type Security Zone	Mar Address (Artius (Standbu)	TD Address	O Sub Interface
Thermole Part-channels	Logical Hame	EtherChannel	Hac Audress(Acure, Scanuby)	ar Mooress	
III Part-channeld		EtherChannel			
W Port-channelite		enerchannel			
Ethernet1/1	diagnostic	Physical			

Configurare la prima sottointerfaccia con questi dettagli. Selezionate **OK** per applicare le modifiche e come mostrato nelle immagini.

Nome	Interno
Scheda Generale	
Interfaccia	Port-channel5
ID sottointerfaccia	201
ID VLAN	201
Scheda IPv4	
Tipo IP	Usa IP statico
Indirizzo IP	192.168.75.10/24

Add Sub Interface			? ×
Name: Inside	Enabled	Management Only	r
Security Zone:	~	-	
Description:			
General IPv4 IPv6	Advanced		
MTU:	1500	(64 - 9000)	
Interface *:	Port-channel5	🗹 Enabled	
Sub-Interface ID *:	201	(1 - 4294967295)	
VLAN ID:	201	(1 - 4094)	
			OK Cancel

Add Sub Interfac	e ? ×	
Name: Insid	de Catalog Management Only	
Security Zone:	~	
Description:		
General IPv4 I	Pv6 Advanced	
IP Type:	Use Static IP	
IP Address:	eg. 1.1.1.1/255.255.255.228 or 1.1.1.1/25	
	OK Cancel	

Configurare la seconda sottointerfaccia con questi dettagli.

Esterno
Port-channel5
210
210
Usa IP statico
192.168.76.10/24

Fare clic su **OK** per creare l'interfaccia secondaria. Fare clic su **Save**, quindi su **Deploy** changes to the FTD\_cluster, come mostrato nell'immagine.

Verifica:

Overview Analysis Policies Devices Obje	ects AMP			Deploy 🧕 System Help 🔹 olga 🔹				
Device Management NAT VPN Platform	Settings							
FTD_cluster	FTD_cluster							
Cisco Firepower 9000 Series SM-36 Threat Defense								
Cluster Devices Routing NAT Inter	aces Inline Sets DHCP							
2				Add Interfaces •				
Interface Logi	cal Name Type	Security Zone Mac Addre	ss(Active/Standby) IP Address					
Port-channel5	EtherChannel			1				
Port-channel48	EtherChannel			·				
Ethernet1/1 diagr	nostic Physical			1				
Port-channel5.201 Inside	e SubInterface		192.168.75.10	/24(Static) 🥜 🗑				
Port-channel5.210 Outsi	de SubInterface		192.168.76.10	/24(Static) 🥜 🗑				

#### Attività 5. Verifica della connettività di base

Attività richiesta:

Creare un'acquisizione e controllare la connettività tra due VM.

Soluzione:

Passaggio 1. Creare acquisizioni in tutte le unità cluster.

Passare alla CLI LINA (ASA) dell'unità master e creare clip per le interfacce interna ed esterna.

firepower# firepower# cluster exec capture capi interface inside match icmp any any firepower# firepower# cluster exec capture capo interface outside match icmp any any firepower# Verifica: firepower# cluster exec show capture capture capi type raw-data interface Inside [Capturing - 0 bytes] match icmp any any capture capo type raw-data interface Outside [Capturing - 0 bytes] match icmp any any capture capi type raw-data interface Inside [Capturing - 0 bytes] match icmp any any

capture capo type raw-data interface Outside [Capturing - 0 bytes]
match icmp any any

Passaggio 2. Eseguire il ping tra VM1 e VM2.

Eseguire il test con 4 pacchetti. Controllare l'output di acquisizione dopo il test:

firepower# cluster exec show capture capture capi type raw-data interface Inside [Capturing - 0 bytes] match icmp any any capture capo type raw-data interface Outside [Capturing - 0 bytes] match icmp any any capture capi type raw-data interface Inside [Capturing - 752 bytes] match icmp any any capture capo type raw-data interface Outside [Capturing - 752 bytes] match icmp any any capture capi type raw-data interface Inside [Capturing - 0 bytes] match icmp any any capture capo type raw-data interface Outside [Capturing - 0 bytes] match icmp any any firepower#

Eseguire il comando per verificare l'output di acquisizione sull'unità specifica:

#### firepower# cluster exec unit unit-1-3 show capture capi

8 packets captured

1:	12:58:36.162253	802.1Q	vlan#201	PO	192.168.75.100	>	192.168.76.100:	icmp:	echo	
reques	request									
2:	12:58:36.162955	802.1Q	vlan#201	PO	192.168.76.100	>	192.168.75.100:	icmp:	echo	reply
3:	12:58:37.173834	802.1Q	vlan#201	PO	192.168.75.100	>	192.168.76.100:	icmp:	echo	
reques	st									
4:	12:58:37.174368	802.1Q	vlan#201	PO	192.168.76.100	>	192.168.75.100:	icmp:	echo	reply
5:	12:58:38.187642	802.1Q	vlan#201	PO	192.168.75.100	>	192.168.76.100:	icmp:	echo	
reques	st									
6:	12:58:38.188115	802.1Q	vlan#201	РO	192.168.76.100	>	192.168.75.100:	icmp:	echo	reply
7:	12:58:39.201832	802.1Q	vlan#201	PO	192.168.75.100	>	192.168.76.100:	icmp:	echo	
request										
8:	12:58:39.202321	802.1Q	vlan#201	PO	192.168.76.100	>	192.168.75.100:	icmp:	echo	reply
8 pack	kets shown									

firepower# cluster exec unit unit-1-3 show capture capo

8 packets captured

1: 12:58:36.162543 802.1Q vlan#210 P0 192.168.75.100 > 192.168.76.100: icmp: echo

request 2: 12:58:36.162894 802.1Q vlan#210 P0 192.168.76.100 > 192.168.75.100: icmp: echo reply 3: 12:58:37.174002 802.1Q vlan#210 P0 192.168.75.100 > 192.168.76.100: icmp: echo request 4: 12:58:37.174307 802.10 vlan#210 P0 192.168.76.100 > 192.168.75.100: icmp: echo reply 5: 12:58:38.187764 802.1Q vlan#210 P0 192.168.75.100 > 192.168.76.100: icmp: echo request 802.10 vlan#210 P0 192.168.76.100 > 192.168.75.100: icmp: echo reply 6: 12:58:38.188085 802.1Q vlan#210 P0 192.168.75.100 > 192.168.76.100: icmp: echo 7: 12:58:39.201954 request 8: 12:58:39.202290 802.10 vlan#210 P0 192.168.76.100 > 192.168.75.100: icmp: echo reply 8 packets shown firepower#

Al termine dell'operazione, eliminare le clip con il comando successivo:

Passaggio 3. Scaricare un file da VM2 a VM1.

VM1 è stato preconfigurato come server FTP, VM2 come client FTP.

Crea nuove clip con queste:

#### Controllare l'output show conn:

UI

...... TCP cluster 127.2.1.3:59588 NP Identity Ifc 127.2.1.1:10850, idle 0:00:33, bytes 132, flags UO

TCP Outside 192.168.76.100:49175 Inside 192.168.75.100:21, idle 0:00:34, bytes 0, flags y
TCP cluster 127.2.1.1:10851 NP Identity Ifc 127.2.1.3:48493, idle 0:00:52, bytes 224, flags UI
.......
TCP cluster 127.2.1.1:64070 NP Identity Ifc 127.2.1.3:10847, idle 0:00:11, bytes 806, flags U0

TCP cluster 127.2.1.1:10851 NP Identity Ifc 127.2.1.2:64136, idle 0:00:53, bytes 224, flags UI ...... TCP cluster 127.2.1.1:15859 NP Identity Ifc 127.2.1.2:10847, idle 0:00:11, bytes 807, flags UO

#### Mostra output acquisizione:

#### Acquisizione cluster dall'interfaccia utente di Gestione chassis

Nell'immagine seguente è illustrato un cluster di 3 unità in FPR9300 con 2 canali porta (8 e 48). Le periferiche logiche sono appliance ASA, ma nel caso di FTD si tratta dello stesso concetto.È importante ricordare che, sebbene esistano **3 unità cluster**, dal punto di vista dell'acquisizione esiste solo **una periferica logica**:

0	verview	Interfaces	Logical Devices	Security Mo	dules Platform Sett	tings		Syst	tem Tools Help admin
Lo	jical Dev	vice List						d	Refresh 🕢 Add Device
	ASA	C	Clustered	Status:ok					<b>F.</b> 🖉 E 💌
	Securi	ty Module	Application	Version	Management IP	Gateway	Management Port	Status	
E	Securit	y Module 1	ASA	9.6.2.7	0.0.0.0	0.0.0.0	Ethernet1/1	💮 online	🕶 💱
	Port Da Cl	<b>ts:</b> ata Interfaces: uster Interfaces:	Port-channel8 Port-channel48	<i>,</i>	Attributes: Cluster Operational Statu Management IP VIRTUAL Cluster Role Management URL Management IP	s: in-cluster : 10.111.8.206 : master : https://10.111.8.206/ : 10.111.8.193			
G	Securit	y Module 2	ASA	9.6.2.7	0.0.0.0	0.0.0.0	Ethernet1/1	💮 online	💌 🏂 🌧
	Port Da Cl	<b>ts:</b> ata Interfaces: uster Interfaces:	Port-channel8 Port-channel48	,	<b>Attributes:</b> Cluster Operational Statu Management IP VIRTUAL Cluster Role Management URL Management IP	s: in-cluster : 10.111.8.206 : slave : https://10.111.8.206/ : 10.111.8.189			
G	Securit	y Module 3	ASA	9.6.2.7	0.0.0.0	0.0.0.0	Ethernet1/1	💮 online	🕶 🎉 🥕
	Port Da CI	<b>ts:</b> ata Interfaces: uster Interfaces:	Port-channel8 Port-channel48		<b>Attributes:</b> Cluster Operational Statu Management IP VIRTUAL Cluster Role Management URL Management IP	s: in-cluster : 10.111.8.206 : slave : https://10.111.8.206/ : 10.111.8.190			

Overview Interfaces	Logical Devices	Security Modules	Platform Settings		System	Fools Help admin
						Packet Capture
			Save and Run	Save	Cancel	
ASA				Session Name*	ARP Ethernet1/5	
Ethernet1/1				Buffer Size	256 MB	~
Ethernet1/8 (Portchannel48)		_		Snap length:	1518	Bytes
Ethernet1/7 (Portchannel48)				Store Packets	Overwrite	Append
Ethernet1/6 (Portchannel48)				Capture Filter	Apply Filter	Capture All
Ethernet1/5 [		Ethernet1/9. Eth	ASA ASA ernet1/10. Ethernet1/11.			
Ethernet1/4 (Portchannel48)		Ethernet1/12, Et	hernet1/13, Ethernet1/14			
Ethernet1/3 (Portchannel48)						
Ethernet1/2 (Portchannel48)						
Ethernet2/2 (Portchannel8)						
Ethernet2/1 (Portchannel8)						

### Attività 6. Eliminare un dispositivo slave dal cluster

Attività richiesta:

Accedere al CCP ed eliminare l'unità slave dal cluster.

Soluzione:

Passaggio 1. Accedere al FMC e selezionare **Device > Device Management** (Gestione dispositivi).

Fare clic sull'icona del cestino accanto all'unità slave, come mostrato nell'immagine.

Cisco Firepower 9000 Series SM-36 Threat Defense Cluster			<i>2</i> 8
FTD1(primary) 10.62.148.67 - Cisco Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed	Cisco Firepower 9000 Series SM-36 Thre Base, Threat, Malware, URL Filtering	FTD9300	
FTD2 10.62.148.68 - Cisco Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed	Cisco Firepower 9000 Series SM-36 Thre Base, Threat, Malware, URL Filtering	FTD9300	6
FTD3 10.62.148.69 - Cisco Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed	Cisco Firepower 9000 Series SM-36 Thre Base, Threat, Malware, URL Filtering	FTD9300	6

Viene visualizzata la finestra di conferma. Selezionare **Sì** per confermare come mostrato nell'immagine.



Verifica:

#### • Dal CCP come illustrato nell'immagine.

- 6	FTD_cluster Cisco Firepower 9000 Series SM-36 Threat Defense Cluster	1	8
	FTD1(primary)     10.62.148.67 - Cisco     Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed     Cisco     Firepower 9000 Series SM-36 Threat,     Malware,     URL Filtering     FTD9300		
	FTD3 10.62.148.69 - Cisco Firepower 9000 Series SM-36 Threat Defense - v6.0.1 - routed Cisco Firepower 9000 Series SM-36 Threat, Malware, URL Filtering FTD9300	8	

• Dalla CLI di FXOS.

PR9K-1-A# <b>scope ssa</b>									
<pre>FPR9K-1-A /ssa # show app-instance</pre>									
Application Name	Slot ID	Admin State	Operational State	Running Version	n Startup				
Version Cluster Op	ersion Cluster Oper State								
ftd	1	Enabled	Online	6.0.1.1213	6.0.1.1213				
In Cluster									
ftd	2	Enabled	Online	6.0.1.1213	6.0.1.1213				
In Cluster									
ftd	3	Enabled	Online	6.0.1.1213	6.0.1.1213				
In Cluster									

• Dalla CLI di LINA (ASA).

#### firepower# show cluster info Cluster FTD\_cluster: On Interface mode: spanned This is "unit-1-1" in state MASTER ID : 0 Version : 9.6(1) Serial No.: FLM19216KK6 CCL IP : 127.2.1.1 CCL MAC : 0015.c500.016f Last join : 21:51:03 CEST Aug 8 2016 Last leave: N/A Other members in the cluster: Unit "unit-1-3" in state SLAVE ID : 1 Version : 9.6(1) Serial No.: FLM19206H7T CCL IP : 127.2.1.3 CCL MAC : 0015.c500.018f Last join : 21:51:05 CEST Aug 8 2016 Last leave: N/A Unit "unit-1-2" in state SLAVE ΤD : 2 Version : 9.6(1) Serial No.: FLM19206H71 CCL IP : 127.2.1.2 CCL MAC : 0015.c500.019f

```
Last join : 21:51:30 CEST Aug 8 2016
Last leave: N/A
firepower#
```

**Nota:** La registrazione del dispositivo è stata annullata dal FMC, ma il dispositivo è ancora un membro del cluster nel FPR9300.

## Verifica

Fare riferimento a questa sezione per verificare che la configurazione funzioni correttamente.

La verifica è completata e trattata in singoli compiti.

## Risoluzione dei problemi

Al momento non sono disponibili informazioni specifiche per la risoluzione dei problemi di questa configurazione.

## Informazioni correlate

• Tutte le versioni della guida alla configurazione di Cisco Firepower Management Center sono disponibili qui:

https://www.cisco.com/c/en/us/td/docs/security/firepower/roadmap/firepower-roadmap.html#id\_47280.

• Tutte le versioni delle guide alla configurazione di FXOS Chassis Manager e CLI sono disponibili qui:

https://www.cisco.com/c/en/us/td/docs/security/firepower/fxos/roadmap/fxos-roadmap.html#pgfld-121950.

Il centro Cisco Global Technical Assistance Center (TAC) consiglia di consultare questa guida grafica per approfondire le conoscenze pratiche della tecnologia di sicurezza dei Cisco Firepower di nuova generazione, inclusi i prodotti menzionati in questo articolo:

http://www.ciscopress.com/title/9781587144806.

• Per tutte le note tecniche sulla configurazione e la risoluzione dei problemi relative alle tecnologie Firepower.

https://www.cisco.com/c/en/us/support/security/defense-center/tsd-products-support-serieshome.html.

Documentazione e supporto tecnico – Cisco Systems